

SERVICE MANUAL

imageCLASS
MF249dw
MF247dw
MF244dw
MF236n
MF232w



Canon

July 13, 2016
Rev. 1

Introduction

Important Notices

Application

This manual has been issued by Canon Inc. for qualified persons to learn technical theory, installation, maintenance, and repair of products.

This manual covers all localities where the products are sold. For this reason, there may be information in this manual that does not apply to your locality.

Corrections

This manual may contain technical inaccuracies or typographical errors due to improvements or changes in products. When changes occur in applicable products or in the contents of this manual, Canon will release technical information as the need arises. In the event of major changes in the contents of this manual over a long or short period, Canon will issue a new edition of this manual.

The following paragraph does not apply to any countries where such provisions are inconsistent with local law.

Trademarks

The product names and company names used in this manual are the registered trademarks of the individual companies.

Copyright

This manual is copyrighted with all rights reserved. Under the copyright laws, this manual may not be copied, reproduced or translated into another language, in whole or in part, without the consent of Canon Inc.







Copyright CANON INC. 2016















Caution

Use of this manual should be strictly supervised to avoid disclosure of confidential information.



Explanation of Symbols

The following symbols are used throughout this Service Manual.

| Symbols | Explanation | Symbols | Explanation |
|---|-----------------|--|------------------|
|  | Check. |  | Remove the claw. |
|  | Check visually. |  | Insert the claw. |
|  | Check a sound. |  | Push the part. |

| Symbols | Explanation | Symbols | Explanation |
|---|--|--|-----------------------------|
|  | Disconnect the connector. |  | Connect the power cable. |
|  | Connect the connector. |  | Disconnect the power cable. |
|  | Remove the cable/wire from the cable guide or wire saddle. |  | Turn on the power. |
|  | Install the cable/wire to the cable guide or wire saddle. |  | Turn off the power. |
|  | Remove the screw. |  | Loosen the screw. |
|  | Install the screw. |  | Tighten the screw. |
|  | Cleaning is needed. |  | Measurement is needed. |

The following rules apply throughout this Service Manual:

- Each chapter contains sections explaining the purpose of specific functions and the relationship between electrical and mechanical systems with reference to the timing of operation.
In the diagrams,  represents the path of mechanical drive; where a signal name accompanies the symbol, the arrow  indicates the direction of the electric signal.
The expression "turn on the power" means flipping on the power switch, closing the front door, and closing the delivery unit door, which results in supplying the machine with power.
- In the digital circuits, '1' is used to indicate that the voltage level of a given signal is "High", while '0' is used to indicate "Low". (The voltage value, however, differs from circuit to circuit.) In addition, the asterisk (*) as in "DRMD*" indicates that the DRMD signal goes on when '0'.
In practically all cases, the internal mechanisms of a microprocessor cannot be checked in the field. Therefore, the operations of the microprocessors used in the machines are not discussed: they are explained in terms of from sensors to the input of the DC controller PCB and from the output of the DC controller PCB to the loads.

The descriptions in this Service Manual are subject to change without notice for product improvement or other purposes, and major changes will be communicated in the form of Service Information bulletins.

All service persons are expected to have a good understanding of the contents of this Service Manual and all relevant Service Information bulletins and be able to identify and isolate faults in the machine.

Contents

| | |
|--|-----------|
| Safety Precautions | 1 |
| Laser Safety..... | 2 |
| How to Handle the Laser Scanner Unit..... | 2 |
| Toner Safety..... | 2 |
| About Toner..... | 2 |
| Handling Adhered Toner..... | 2 |
| Notes When Handling a Lithium Battery..... | 3 |
| Notes on Assembly/Disassembly..... | 3 |
| 1. Product Overview | 4 |
| Product Lineups..... | 5 |
| Main Unit..... | 5 |
| Options..... | 5 |
| Manufacture Sketch Drawing..... | 6 |
| Features..... | 7 |
| Features..... | 7 |
| Product Specifications..... | 8 |
| Main Unit Specifications..... | 8 |
| Wireless LAN Specifications..... | 10 |
| SADF/DADF Specifications..... | 11 |
| FAX Specifications (FAX model Only)..... | 12 |
| Name of Parts..... | 13 |
| External View..... | 13 |
| Cross Section..... | 17 |
| Control Panel..... | 19 |
| 2. Technology | 22 |
| Basic Configuration..... | 23 |
| Configuration function..... | 23 |
| Basic Sequence..... | 23 |
| Controller System..... | 25 |
| Main Controller..... | 25 |
| Engine Controller..... | 25 |
| Document Exposure/Feeder System..... | 27 |
| Document Exposure System..... | 27 |
| Document Feeder System..... | 28 |
| Laser Exposure System..... | 31 |
| Overview..... | 31 |
| Controlling the Laser Activation Timing..... | 32 |
| Laser Control..... | 33 |
| Laser Scanner Motor Control..... | 33 |
| Image Formation System..... | 35 |
| Overview/Configuration..... | 35 |
| High-Voltage Control..... | 39 |

| | |
|---|-----------|
| Toner Cartridge..... | 40 |
| Fixing System..... | 43 |
| Overview..... | 43 |
| Main Parts of Fixing assembly..... | 43 |
| Various Control Mechanisms..... | 44 |
| Other Functions..... | 45 |
| Pickup And Feeding System..... | 47 |
| Overview..... | 47 |
| Detecting Jams..... | 48 |
| External And Controls System..... | 54 |
| Power Supply..... | 54 |
| 3. Periodical Service..... | 56 |
| Periodically Replaced Parts..... | 57 |
| Periodically Replaced Parts..... | 57 |
| Consumables..... | 58 |
| Consumables..... | 58 |
| Periodical Service..... | 59 |
| Scheduled Servicing..... | 59 |
| 4. Disassembly/Assembly..... | 60 |
| Introduction..... | 62 |
| Outline..... | 62 |
| List of Parts..... | 63 |
| External View..... | 63 |
| List of Main Unit..... | 67 |
| Electrical Components..... | 71 |
| Simplex Printer Unit..... | 77 |
| Connectors Layout Drawing..... | 82 |
| DADF Unit and Reader Unit..... | 82 |
| SADF Unit and Reader Unit..... | 82 |
| Copyboard Unit and Reader Unit..... | 83 |
| Duplex Printer Unit..... | 84 |
| Simplex Printer Unit..... | 86 |
| Original Exposure/Feed System (DADF Model)..... | 88 |
| Layout Drawing..... | 88 |
| Removing the DADF Unit + Reader Unit..... | 89 |
| Disconnecting the DADF Unit + Reader Unit..... | 92 |
| Removing the DADF Pickup Unit..... | 95 |
| Removing the DADF Motor Unit..... | 99 |
| Removing the DADF Solenoid Unit..... | 101 |
| Removing the DADF Pickup Roller Unit..... | 103 |
| Removing the DADF Separation Pad..... | 106 |
| Removing the Copyboard Glass (DADF Model)..... | 109 |
| Removing the Contact Image Sensor (DADF Model)..... | 112 |
| Removing the Flat Bed Motor Unit (DADF Model)..... | 114 |
| Original Exposure/Feed System (SADF Model)..... | 118 |
| Layout Drawing..... | 118 |
| Removing the SADF Unit + Reader Unit..... | 119 |

| | |
|--|-----|
| Disconnecting the SADF Unit and the Reader Unit..... | 122 |
| Removing the SADF Upper Cover Unit..... | 125 |
| Removing the SADF Pickup Unit..... | 129 |
| Removing the SADF Motor..... | 130 |
| Removing the SADF Pickup Roller Unit..... | 132 |
| Removing the SADF Separation Pad..... | 136 |
| Removing the Copyboard Glass (SADF Model)..... | 139 |
| Removing the Contact Image Sensor (SADF Model)..... | 142 |
| Removing the Flat Bed Motor Unit (SADF Model)..... | 144 |
| Original Exposure/Feed System (Copyboard Model)..... | 148 |
| Layout Drawing..... | 148 |
| Removing the Copyboard Cover..... | 148 |
| Removing the Copyboard Cover + Reader Unit..... | 149 |
| Removing the Copyboard Glass (Copyboard Model)..... | 152 |
| Removing the Contact Image Sensor (Copyboard Model)..... | 155 |
| Removing the Flat Bed Motor Unit (Copyboard Model)..... | 157 |
| External Cover/Internal System (Duplex Model)..... | 161 |
| Layout Drawing..... | 161 |
| Removing the Left Cover (Duplex Model)..... | 162 |
| Removing the Right Cover (Duplex Model)..... | 164 |
| Removing the Front Cover Unit (Duplex Model)..... | 166 |
| Removing the Upper Cover Unit (Duplex Model)..... | 167 |
| Removing the Duplex Feed Guide Unit. (Duplex Model)..... | 169 |
| Controller System (Duplex Model)..... | 172 |
| Layout Drawing..... | 172 |
| Removing the Control Panel Unit (Duplex Model)..... | 173 |
| Removing the Main Motor (Duplex Model)..... | 174 |
| Removing the Main Fan (Duplex Model)..... | 178 |
| Removing the Edge Left Cooling Fan (Duplex Model)..... | 182 |
| Removing the Edge Right Cooling Fan (Duplex Model)..... | 184 |
| Removing the Engine Controller PCB (Duplex Model)..... | 186 |
| Removing the Main Controller PCB (Duplex Model)..... | 191 |
| Removing the FAX NCU PCB (Fax Model 120V/230V) (Duplex Model)..... | 194 |
| Removing the Wirelss LAN PCB (Wifi Model + Duplex Model)..... | 195 |
| Removing the Paper Leading Edge Sensor PCB (Duplex Model)..... | 196 |
| Removing the Fixing Delivery/Paper Width Sensor PCB (Duplex Model)..... | 200 |
| Removing the Toner Sensor and Multi Pickup Sensor Unit (Fax Model + Duplex Model)..... | 204 |
| Removing the Speaker (Fax Model + Duplex Model)..... | 206 |
| Laser Exposure System (Duplex Model)..... | 209 |
| Layout Drawing..... | 209 |
| Removing the Laser Scanner Unit (Duplex Model)..... | 209 |
| Image Formation System (Duplex Model)..... | 212 |
| Layout Drawing..... | 212 |
| Removing the Transfer Roller (Duplex Model)..... | 212 |
| Fixing System (Duplex Model)..... | 215 |
| Layout Drawing..... | 215 |
| Removing the Fixing Assembly (Duplex Model)..... | 215 |
| Pickup Feed System (Duplex Model)..... | 222 |
| Layout Drawing..... | 222 |
| Removing the Pickup Unit (Duplex Model)..... | 222 |
| Removing the Pickup Tray Unit (Duplex Model)..... | 229 |

| | |
|---|------------|
| Removing the Pickup Roller (Duplex Model)..... | 231 |
| Removing the Separation Pad (Duplex Model)..... | 233 |
| Removing the Delivery Slave Roller Unit (Duplex Model)..... | 234 |
| Removing the Pickup Solenoid (Duplex Model)..... | 235 |
| Removing the Duplex Solenoid (Duplex Model)..... | 240 |
| External Cover/Internal System (Simplex Model)..... | 243 |
| Layout Drawing..... | 243 |
| Removing the Left Cover (Simplex Model)..... | 244 |
| Removing the Right Cover (Simplex Model)..... | 246 |
| Removing the Front Cover Unit (Simplex Model)..... | 248 |
| Removing the Upper Cover (Simplex Model)..... | 249 |
| Removing the Rear Cover (Simplex Model)..... | 251 |
| Controller System (Simplex Model)..... | 253 |
| Layout Drawing..... | 253 |
| Removing the Control Panel Unit (Simplex Model)..... | 254 |
| Removing the Main Motor (Simplex Model)..... | 255 |
| Removing the Engine Controller PCB (Simplex Model)..... | 258 |
| Removing the Main Controller PCB (Simplex Model)..... | 263 |
| Removing the FAX NCU PCB (Fax Model 120V/230V + Simplex Model)..... | 266 |
| Removing the Wireless LAN PCB (Wifi Model + Simplex Model)..... | 267 |
| Removing the Paper Leading Edge Sensor (Simplex Model)..... | 267 |
| Removing the Fixing Delivery/Paper Width Sensor PCB (Simplex Model)..... | 271 |
| Removing the Toner Sensor and Multi Pickup Sensor Unit (Fax Model + Simplex Model)..... | 274 |
| Removing the Speaker (Fax Model + Simplex Model)..... | 277 |
| Laser Exposure System (Simplex Model)..... | 280 |
| Layout Drawing..... | 280 |
| Removing the Laser Scanner Unit (Simplex Model)..... | 280 |
| Image Formation System (Simplex Model)..... | 283 |
| Layout Drawing..... | 283 |
| Removing the Transfer Roller (Simplex Model)..... | 283 |
| Fixing System (Simplex Model)..... | 286 |
| Layout Drawing..... | 286 |
| Removing the Fixing Assembly (Simplex Model)..... | 286 |
| Pickup Feed System (Simplex Model)..... | 292 |
| Layout Drawing..... | 292 |
| Removing the Pickup Unit (Simplex Model)..... | 292 |
| Removing the Pickup Tray Unit (Simplex Model)..... | 298 |
| Removing the Pickup Roller (Simplex Model)..... | 300 |
| Removing the Separation Pad (Simplex Model)..... | 302 |
| Removing the Delivery Slave Roller Unit (Simplex Model)..... | 303 |
| Removing the Pickup Solenoid (Simplex Model)..... | 304 |
| 5. Adjustment..... | 309 |
| Mechanical Adjustment..... | 310 |
| Confirming Nip Width..... | 310 |
| 6. Troubleshooting..... | 311 |
| Test Print..... | 312 |
| Test Print Function..... | 312 |

| | |
|---|------------|
| Troubleshooting Items..... | 313 |
| Remedy for Image Failure..... | 313 |
| Intervals of Soiling, White Spots, Etc. That Occur on Images..... | 313 |
| Version Upgrade..... | 314 |
| Overview..... | 314 |
| Upgrading of Firmware..... | 314 |
| Upgrading via Internet..... | 314 |
| Log Collect Tool..... | 315 |
| Outline | 315 |
| Operation Procedure..... | 316 |
| 7. Error/Jam/Alarm..... | 318 |
| Overview..... | 319 |
| Error Codes..... | 320 |
| Jam Codes..... | 322 |
| 8. Service Mode..... | 323 |
| Overview..... | 324 |
| Entering Service Mode..... | 324 |
| Service Mode Menu..... | 324 |
| Screen flow of Service mode..... | 324 |
| COPIER..... | 326 |
| DISPLAY..... | 326 |
| I/O..... | 327 |
| ADJUST..... | 327 |
| FUNCTION..... | 328 |
| OPTION..... | 331 |
| COUNTER..... | 333 |
| FEEDER..... | 335 |
| ADJUST..... | 335 |
| FUNCTION..... | 335 |
| FAX..... | 336 |
| List of SSSW..... | 336 |
| List of MENU..... | 339 |
| List of NUM..... | 340 |
| List of NCU..... | 342 |
| TESTMODE..... | 348 |
| SYSTEM..... | 348 |
| SCAN..... | 348 |
| FAX..... | 349 |
| PANEL..... | 350 |
| APPENDICES..... | 351 |
| Solvent/Oil List..... | 352 |
| General Circuit Diagram..... | 353 |
| General Timing Chart..... | 354 |
| Backup Data..... | 355 |

Safety Precautions

| | |
|---|---|
| Laser Safety..... | 2 |
| How to Handle the Laser Scanner Unit | 2 |
| Toner Safety..... | 2 |
| Notes When Handling a Lithium Battery..... | 3 |
| Notes on Assembly/Disassembly..... | 3 |

Laser Safety

Since radiation emitted inside the machine is completely confined within protective housings and external covers, the laser beam cannot escape from the machine during any phase of user operation.

Therefore this machine is classified in Class 1 laser products that are regarded as safe during normal use according to International Standard IEC60825-1.

How to Handle the Laser Scanner Unit

This machine is classified in Class 1 laser products.

However, inside the scanner unit, there is source of Class 3B laser beam and the laser beam is hazardous when entered into an eye. So, be sure not to disassemble the laser scanner unit. No adjustment can be made to the laser scanner unit in this machine in the field.


The label show in the following figure is attached on the laser scanner unit.

The following warnings are given to comply with Safety Principles (EN60950-1).

Diese Maschine ist der Klasse 1 der Laserprodukte zugeordnet.

Innerhalb der Scannereinheit befindet sich jedoch die Laserstrahlquelle der Klasse 3B und es ist gefährlich, wenn dieser Strahl in die Augen gerät. Die Laserscannereinheit darf unter keinen Umständen entfernt werden. Es dürfen in diesem Umfeld der Maschine keine Justagen an der Laserscannereinheit vorgenommen werden.

Das Etikett in folgendem Bild ist auf der Laserscannereinheit angebracht.



Toner Safety

About Toner

Toner is a nontoxic matter composed of plastic, iron and a trace of pigments.

CAUTION:

Never throw toner in flames to avoid explosion.

Handling Adhered Toner

- Use dry tissue paper to wipe off toner adhered to skin or clothes and wash in water.
- Never use warm water for cleaning up toner to prevent toner particles from being gelated to soak into fibers permanently.
- Toner particles are reactive with vinyl polymers. Avoid contacting these materials.

Notes When Handling a Lithium Battery

Dispose of used batteries according to the instructions.

⚠ CAUTION:

Risk of explosion if battery is replaced by an incorrect type.

The following warnings are given to comply with Safety Principles (EN60950-1).

⚠ CAUTION:

Wenn mit dem falschen Typ ausgewechselt, besteht Explosionsgefahr.
Gebrauchte Batterien gemäß der Anleitung beseitigen.

警告
如果更換不正確之電池型式會有爆炸的風險
請依製造商說明書處理用過之電池

Notes on Assembly/Disassembly

Follow the items below to assemble/disassemble the device.

1. Disconnect the power plug to avoid any potential dangers during assembling/disassembling works.
2. If not specially instructed, reverse the order of disassembly to reinstall.
3. Ensure to use the right screw type (length, diameter, etc.) at the right position when assembling.
4. To keep electric conduction, binding screws with washers are used to attach the grounding wire and the varistor. Ensure to use the right screw type when assembling.
5. Unless it is specially needed, do not operate the device with some parts removed.
6. Never remove the paint-locked screws when disassembling.

CAUTION:

Double pole/neutral fusing

CAUTION
DOUBLE POLE/NEUTRAL FUSING

ACHTUNG
Zweipolige bzw. Neutraleiter-Sicherung



Product Overview

| | |
|---------------------------------|----|
| Product Lineups..... | 5 |
| Manufacture Sketch Drawing..... | 6 |
| Features..... | 7 |
| Product Specifications..... | 8 |
| Name of Parts..... | 13 |

Product Lineups

Main Unit


| Model | MF249dw | MF247dw | MF246dn | MF244dw | MF243d | MF242dw | MF241d |
|------------------|---------------------------|---------------------------|---------------------------|-------------|-------------|-------------|-------------|
| DF | DADF | SADF | SADF | SADF | SADF | Copyboard | Copyboard |
| Engine | 2-Sided | 2-Sided | 2-Sided | 2-Sided | 2-Sided | 2-Sided | 2-Sided |
| LAN port | Yes | Yes | Yes | Yes | No | Yes | No |
| Wireless LAN | Yes | Yes | No | Yes | No | Yes | No |
| FAX | Yes | Yes | Yes | No | No | No | No |
| Display | 6 lined LCD + Touch panel | 6 lined LCD + Touch panel | 6 lined LCD + Touch panel | 5 lined LCD | 5 lined LCD | 5 lined LCD | 5 lined LCD |
| Handset (Option) | Yes | Yes | Yes | No | No | No | No |

| Model | MF237w | MF236n | MF235 | MF233n | MF232w | MF231 | D570 |
|------------------|---------------------------|---------------------------|---------------------------|-------------|-------------|-------------|-------------|
| DF | SADF | SADF | SADF | Copyboard | Copyboard | Copyboard | Copyboard |
| Engine | 1-Sided | 1-Sided | 1-Sided | 1-Sided | 1-Sided | 1-Sided | 2-Sided |
| LAN port | Yes | Yes | No | Yes | Yes | No | Yes |
| Wireless LAN | Yes | No | No | No | Yes | No | Yes |
| FAX | Yes | Yes | Yes | No | No | No | No |
| Display | 6 lined LCD + Touch panel | 6 lined LCD + Touch panel | 6 lined LCD + Touch panel | 5 lined LCD | 5 lined LCD | 5 lined LCD | 5 lined LCD |
| Handset (Option) | Yes | Yes | Yes | No | No | No | No |


Options

- Handset (FAX model only)


Manufacture Sketch Drawing



Duplex Model




Simplex Model



LCD Panel Model


Touch Panel Model



Edge Cooling Fan

Duplex Model


Simplex Model



DADF Model

SADF Model

Copyboard Model




Duplex Solenoid

Main Fan

Duplex Model


Simplex Model



Duplex Relay PCB

Duplex Model

Simplex Model



Intake hole of the main fan

Duplex Model

Simplex Model

Features

Features

1. Small-size, high-speed monochrome printer
This equipment has a compact body that realizes high-speed print.
 - Duplex model: 27 ppm (A4) / 28 ppm (LTR).
 - Simplex model: 23 ppm (A4) / 24 ppm (LTR)
2. Automatic duplex print
Automatic two-sided printing is available with standard equipped duplex unit.
3. Reduction in standby time and energy consumption
This equipment employs on-demand fixing where the heater activates only during printing, resulting in a reduction in standby time and energy consumption on this mode.
4. Realization of noise reduction and stable image quality
This equipment employs a belt drive method for transmitting the drive of the main motor. This enables lower noise and more stable image quality compared to the conventional gear drive method. (See NOTE)
5. Improved Usability
In this equipment maintenance (jam removal, replacing the cartridge) can be performed by accessing one point of the delivery tray.

NOTE:

Changing the drive method from gear to belt reduces uneven pitch due to varied rotation speed of the photosensitive drum, which realizes stable image quality.

Product Specifications

Main Unit Specifications

| Item | Specifications / Function |
|--|--|
| Copyboard | Fixed |
| Device Installation | Personal Desktop |
| Light source | LED (RGB) |
| Image scanning | CIS (color) |
| Photoreceptor | OPC drum (24 mm dia.) |
| Light exposure method | Laser beam exposure (semiconductor laser) |
| Charging method | Roller charging |
| Developing method | Toner projection developing method |
| Transfer method | Direct transfer to the transfer member |
| Separation method | Curvature separation |
| Paper feed method | Pickup Tray : Semilunar-shaped Pickup Roller + Pad separation method (pressure release mechanism is not available) Multi-purpose Tray : Semilunar-shaped Pickup Roller + Pad separation method (pressure release mechanism is not available) |
| Paper delivery method | Face-down |
| Drum cleaning method | Cleaning blade |
| Fixing method | SURF fixing method with the Ceramic Heater |
| Toner supply method | All-in-one cartridge with drum |
| Toner level sensor | Fax model: Yes (magnetic sensor) |
| Document types | Sheets, Book, Height of document: 20 mm, Weight: up to 2 Kg |
| Maximum document size | Fixation: to A4 ADF: to LGL |
| Image size magnification | <ul style="list-style-type: none"> • 100% Direct • 400% (Max), 200%, 129% STMT->LTR • 64% LTR->STMT, 50%, 25%(Min) |
| Zoom | 25 to 400 % (1 % increment) |
| Reading resolution | <ul style="list-style-type: none"> • Optical: Up to 600 dpi x 600 dpi • Driver (digital): Up to 9600 dpi x 9600 dpi |
| Print resolution | 600 dpi x 600 dpi (1,200 dpi equivalent x 1,200 dpi equivalent) |
| Warm-up Time | <ul style="list-style-type: none"> • 12.0 seconds or less (Copyboard model) • 13.5 seconds or less (ADF model) |
| First print time | 6.0 seconds or less |
| First copy time | <ul style="list-style-type: none"> • 9.0 seconds or less (A4) • 8.7 seconds or less (LTR) |
| Print Speed | <ul style="list-style-type: none"> • MF249dw / MF247dw / MF246dn / MF244dw / MF243d / MF242dw / MF241d / D570 Simplex Print: 28 ppm(LTR), 27 ppm(A4) Duplex Print: 16 ppm(8 sheets per minutes)(LTR), 15 ppm(7.7 sheets per minutes)(A4) • MF237w / MF236n / MF235 / MF233n / MF232w / MF231 Simplex Print: 24 ppm(LTR), 23 ppm(A4) Duplex Print: Non Duplex Print |
| Copy Speed | <ul style="list-style-type: none"> • MF249dw / MF247dw / MF246dn / MF244dw / MF243d / MF242dw / MF241d / D570 Simplex Print: 28 ppm(LTR), 27 ppm(A4) Duplex Print: 16 ppm(8 sheets per minutes)(LTR), 15 ppm(7.7 sheets per minutes)(A4) • MF237w / MF236n / MF235 / MF233n / MF232w / MF231 Simplex Print: 24 ppm(LTR), 23 ppm(A4) Duplex Print: Non Duplex Print |
| Available paper size in Paper Cassette | Fixed size: A4*4, B5, A5, Legal*4, Letter*4, Statement, Executive, Officio*4, B-Officio*4, M-Officio*4, Government - Letter, Government - Legal, Indian-Legal*4, Foolscap*4, Australian-Foolscap, 16K, Envelope COM10, Envelope C5, Envelope DL Custom paper size: <ul style="list-style-type: none"> • Width: 76.2 to 216.0 mm • Length: 210.0 to 356.0 mm |

| Item | Specifications / Function | |
|--|--|--|
| Available paper size in multi-purpose tray | Fixed size: A4*4, B5, A5Legal*4, Letter*4, Statement, Executive, Officio*4, B-Officio*4, M-Officio*4, Government - Letter, Government - Legal, Indian-Legal*4, Foolscap*4, Australian-foolscap, 16K, 3x5inch, Envelope COM10, Envelope Monarch, Envelope C5, Envelope DL Custom paper size: <ul style="list-style-type: none"> • Width: 76.2 to 216.0 mm • Length: 127.0 to 356.0 mm | |
| Paper types for Paper Cassette | Plain paper(60 to 90 g/m ² (16 to 24 lb Bond))*1, Heavy paper(90 to 163 g/m ² (24 to 60 lb Bond))*2, Recycled paper(60 to 90 g/m ² (16 to 24 lb Bond))*1, Color paper(60 to 90 g/m ² (16 to 24 lb Bond))*1, Bond paper(60 to 163 g/m ² (16 lb Bond to 60 lb Cover))*3, Index card, Label, Envelope | |
| Paper types for Multi-Purpose Tray | Plain paper(60 to 90 g/m ² (16 to 24 lb Bond))*1, Heavy paper(90 to 163 g/m ² (24 to 60 lb Bond))*2, Recycled paper(60 to 90 g/m ² (16 to 24 lb Bond))*1, Color paper(60 to 90 g/m ² (16 to 24 lb Bond))*1, Bond paper(60 to 163 g/m ² (16 lb Bond to 60 lb Cover))*3, Index card, Label, Envelope | |
| Stack capacity of Paper Cassette | About 250 sheets (60 to 80 g/m ²) | |
| Stack capacity of Multi-purpose Tray | 1 sheet | |
| Output tray stacking capacity | About 100 sheets (60 to 80g/m ²) | |
| Allowable environmental temperature | 10 - 30 deg C(50 to 86°F) | |
| Allowable humidity | 20 - 80% | |
| Interface | <ul style="list-style-type: none"> • 100BASE-TX • 10BASE-T • Hi-Speed USB • IEEE 802.11 b/g/n (Infrastructure mode)*5 | |
| Hard Disk | Standard: none, Option: none | |
| Power Supply | AC110~127 V: 50/60 Hz AC220~240 V: 50/60 Hz (Power requirements differ depending on the country in which you purchased the product) | |
| Power Consumption | Simplex model (120V) | Maximum <ul style="list-style-type: none"> • 1,050W or less Average (in Copying) <ul style="list-style-type: none"> • Approx. 420W Average (Standby mode) <ul style="list-style-type: none"> • Approx. 4.0W (Non FAX model) • Approx. 5.1W (FAX model) Average (Sleep mode) <ul style="list-style-type: none"> • Approx. 1.1W (USB) • Approx. 1.3W (Wired) • Approx. 1.8W (Wireless) When the power switch is turned OFF <ul style="list-style-type: none"> • 0.5W or less |
| | Duplex model (120V) | Maximum <ul style="list-style-type: none"> • 1,050W or less Average (in Copying) <ul style="list-style-type: none"> • Approx. 480W Average (Standby mode) <ul style="list-style-type: none"> • Approx. 4.1W (Non FAX model) • Approx. 5.6W (FAX model) Average (Sleep mode) <ul style="list-style-type: none"> • Approx. 1.2W (USB) • Approx. 1.3W (Wired) • Approx. 2.0W (Wireless) When the power switch is turned OFF <ul style="list-style-type: none"> • 0.5W or less |

| Item | Specifications / Function | |
|------------------------------------|--|--|
| Power Consumption | Simplex model (230V) | Maximum <ul style="list-style-type: none"> • 1,120W or less Average (in Copying) <ul style="list-style-type: none"> • Approx. 420W Average (Standby mode) <ul style="list-style-type: none"> • Approx. 4.2W (Non FAX model) • Approx. 5.1W (FAX model) Average (Sleep mode) <ul style="list-style-type: none"> • Approx. 1.2W (USB) • Approx. 1.3W (Wired) • Approx. 2.0W (Wireless) When the power switch is turned OFF <ul style="list-style-type: none"> • 0.5W or less |
| | Duplex model (230V) | Maximum <ul style="list-style-type: none"> • 1,150W or less Average (in Copying) <ul style="list-style-type: none"> • Approx. 490W Average (Standby mode) <ul style="list-style-type: none"> • Approx. 4.1W (Non FAX model) • Approx. 5.7W (FAX model) Average (Sleep mode) <ul style="list-style-type: none"> • Approx. 1.3W (USB) • Approx. 1.4W (Wired) • Approx. 2.1W (Wireless) When the power switch is turned OFF <ul style="list-style-type: none"> • 0.5W or less |
| Dimensions (W* x D x H) | <ul style="list-style-type: none"> • MF249dw 390 mm x 378 mm x 360 mm (Cassette closed) 390 mm x 448 mm x 360 mm (Cassette opened) • MF247dw / MF246dn / MF244dw / MF243d / MF237w / MF236n / MF235 390 mm x 371 mm x 360 mm (Cassette closed) 390 mm x 441 mm x 360 mm (Cassette opened) • MF242dw / MF241d / MF233n / MF232w / MF231 / D570 390 mm x 371 mm x 312 mm (Cassette closed) 390 mm x 441 mm x 312 mm (Cassette opened) <p style="margin-left: 20px;">* W: 472mm (With Handset)</p> | |
| Weight (Including toner cartridge) | <ul style="list-style-type: none"> • MF249dw: Approx. 13.7 kg • MF247dw / MF246dn: Approx. 12.8 kg • MF244dw / MF243d: Approx. 12.7 kg • MF242dw / MF241d / D570: Approx. 11.4 kg • MF237w / MF236n: Approx. 12.1 kg • MF235: Approx. 12.0 kg • MF233n / MF232w: Approx. 10.8 kg • MF231: Approx. 10.7 kg | |

*1: Automatic 2-sided printing is available without replacing paper.

*2: Automatic 2-sided printing is available for heavy paper 1 (90 to 120 g/m²).

*3: Automatic 2-sided printing is available for bond paper 1 (60 to 90 g/m²) and bond paper 2 (90 to 120 g/m²).

*4: Only in Duplex Model, automatic 2-sided printing is available

*5: Wireless LAN model only

Wireless LAN Specifications

| | |
|-----------------|--|
| Standard | IEEE 802.11g, IEEE 802.11b, IEEE 802.11n |
| Frequency Range | 2,412 to 2,462 MHz |

| | |
|------------------------|--|
| Data Transmission Rate | <ul style="list-style-type: none"> • IEEE 802.11g 6/9/12/18/24/36/48/54 Mbps • IEEE 802.11b 1/2/5.5/11 Mbps • IEEE 802.11n SGI Invalidated 20 MHz: 6.5/13/19.5/26/39/52/58.5/65 Mbps SGI Validated 20 MHz: 7.2/14.4/21.7/28.9/43.3/57.8/72.2 Mbps |
| Communication Mode | Infrastructure Mode |
| Security | WEP 64/128 bit, WPA-PSK (TKIP/AES), WPA2-PSK (AES), 802.1x (LEAP, EAP-FAST, PEAP, EAP-TLS, EAP-TTLS) |
| Connection Method | WPS (Wi-Fi Protected Setup), Manual setup |

* WPS (Wi-Fi Protected Setup), Connection can be established by manually setting values.

SADF/DADF Specifications

| | | |
|----------------------------------|--------------------|---|
| Document pickup method | Auto pickup method | |
| Document setting direction | face-up method | |
| Document type | Sheet document | |
| Document size | DADF | Size: A4R/B5R/A5/B6 (landscape)/LGL/LTRR 2-sided: A4R/B5R/A5/LTRR/LGL/B6 (landscape only) <ul style="list-style-type: none"> • Feed direction : 127 mm to 356 mm • Width direction : 140 mm to 216 mm |
| | SADF | Size: A4R/B5R/A5/B6 (landscape)/LGL/LTRR <ul style="list-style-type: none"> • Feed direction : 105 mm to 356 mm • Width direction : 148 mm to 216 mm |
| Document processing mode | SADF | 1-sided document -> 1-sided copy, 1-sided document -> 2-sided copy |
| | DADF | 1-sided document -> 1-sided copy, 1-sided document -> 2-sided copy, 2-sided document -> 1-sided copy, 2-sided document -> 2-sided copy |
| Document weight | Continuous feed | 1-sided : 50 to 105 g/m ² |
| | Continuous reading | 2-sided : 60 to 105 g/m ² |
| Document stack capacity * | DADF | S size: 50 Sheets/ L size : 10 Sheets |
| | SADF | S size: 35 Sheets/ L size : 10 Sheets |
| Document setting position | Center reference | |
| Document reading method | Stream reading | |
| Mixed paper reading | None | |
| Document size sensor | None | |
| Document AE sensor | None | |
| Stamp function | None | |
| Document feed speed (at reading) | 100 % | DADF: 129.34 mm/s SADF: 113.38 mm/s |
| Document processing speed | Mono | <ul style="list-style-type: none"> • 1-sided constant speed, DADF 22 ipm(A4) / 23 ipm(LTR) (sheets/min) • 1-sided constant speed, SADF 20 ipm(A4) / 21 ipm(LTR) (sheets/min) • 2-sided constant speed, DADF 8 ipm(A4/LTR) (sheets/min) |
| | Color | <ul style="list-style-type: none"> • 1-sided constant speed, DADF 15 ipm(A4/LTR) (sheets/min) • 1-sided constant speed, SADF 15 ipm(A4/LTR) (sheets/min) • 2-sided constant speed, DADF 5 ipm(A4/LTR) (sheets/min) |

*:
S size: A4R, B5R, A5R, B6, LTRR, STMTR, 16KR
L size: LGL

FAX Specifications (FAX model Only)

| | |
|---|--|
| Line Used | Public Switched Telephone Network (PSTN)*1 |
| Communication Mode | Super G3, G3 |
| Compression Method | MH, MR, MMR |
| Modem Speed | Super G3: 33.6 Kbps, G3: 14.4 Kbps Automatic Fallback |
| Transmission Speed | Approx. 3 seconds per page*2 (ECM-MMR, transmitting from the memory at 33.6 Kbps) |
| Sending from Memory/Receiving in Memory | Maximum approx. 256 pages*2 (Total pages of transmission/reception) (Maximum number of fax jobs that can be sent from the memory: 10 jobs/Maximum number of fax jobs that can be received into the memory: 90 jobs) |
| Fax Resolution | <ul style="list-style-type: none"> • Normal: 200 x 100 dpi • Fine: 200 x 200 dpi • Photo: 200 x 200 dpi • Superfine: 200 x 400 dpi |
| Dialing | <ul style="list-style-type: none"> • One-touch keys (4 destinations) • Coded dialing (100 destinations) • Group dialing (103 groups) • Address Book dialing • Regular dialing (with numeric keys) • Automatic redialing • Manual redialing • Sequential broadcast (114 destinations) |
| Receiving | <ul style="list-style-type: none"> • Automatic reception • Remote reception by telephone (Default ID: 25) |
| Reports | <ul style="list-style-type: none"> • Send Results • Transmission management report (By default, auto output every 40 destinations) • RX Results |
| Telephone Type | External telephone/External telephone with the built-in answer function/Data modem |


*1 The Public Switched Telephone Network (PSTN) currently supports 28.8 Kbps modem speed or lower. Note that speeds can vary depending on the telephone line conditions.

*2 Based on ITU-T (ITU Telecommunication Standardization Sector) Standard Chart No. 1, MMR standard mode.

Name of Parts


External View

■ DADF Unit and Reader Unit



| No. | Name | Remarks |
|------|------------------------------|---------|
| [1] | DADF Upper Cover | - |
| [2] | DADF Rear Cover | - |
| [3] | Side Guide Plate | - |
| [4] | Original Feed Tray | - |
| [5] | Original Feed Auxiliary Tray | - |
| [6] | Original Delivery Tray | - |
| [7] | DADF Front Cover | - |
| [8] | Document Reading Glass | - |
| [9] | Copyboard Guide Holder | - |
| [10] | White Guide Plate | - |
| [11] | White Plate | - |
| [12] | Copyboard Glass | - |
| [13] | Copyboard Upper Cover | - |

■ SADF Unit and Reader Unit



| No. | Name | Remarks |
|------|------------------------------|---------|
| [1] | SADF Upper Cover | - |
| [2] | SADF Rear Cover | - |
| [3] | Side Guide Plate | - |
| [4] | Original Feed Tray | - |
| [5] | Original Feed Auxiliary Tray | - |
| [6] | Original Delivery Tray | - |
| [7] | SADF Front Cover | - |
| [8] | Document Reading Glass | - |
| [9] | Copyboard Guide Holder | - |
| [10] | White Guide Plate | - |
| [11] | White Plate | - |
| [12] | Copyboard Glass | - |
| [13] | Copyboard Upper Cover | - |


■ Copyboard Unit and Reader Unit



| No. | Name | Remarks |
|-----|------------------------|---------|
| [1] | Copyboard Upper Cover | - |
| [2] | Copyboard Guide Holder | - |
| [3] | White Plate | - |
| [4] | Copyboard Glass | - |
| [5] | Copyboard Upper Cover | - |


■ Printer Unit (Duplex)

● Front Side (Duplex)



| No. | Name | Remarks |
|------|-------------------------------------|---------|
| [1] | Control Panel Unit | - |
| [2] | Delivery Auxiliary Tray | - |
| [3] | Pickup Tray | - |
| [4] | Trailing Edge Paper Guides | - |
| [5] | Pickup Tray Side Guide Plate | - |
| [6] | Power Switch | - |
| [7] | Upper Cover | - |
| [8] | Delivery Tray | - |
| [9] | Front Cover Unit | - |
| [10] | Multi-Purpose Tray | - |
| [11] | Tray Cover | - |
| [12] | Multi-Purpose Tray Side Guide Plate | - |

● Rear Side (Duplex)




| No. | Name | Remarks |
|------|------------------------|---------|
| [13] | Left Cover | - |
| [14] | Hinge Face Cover | - |
| [15] | Duplex Feed Guide Unit | - |
| [16] | Right Cover | - |

| No. | Name | Remarks |
|------|------------------------|----------------|
| [17] | USB Device Port | - |
| [18] | LAN Port | Model with NET |
| [19] | External Device Jack | Model with FAX |
| [20] | Telephone Line Jack | Model with FAX |
| [21] | Power Supply Cord Slot | - |


■ Printer Unit (Simplex)

● Front Side (Simplex)



| No. | Name | Remarks |
|------|-------------------------------------|---------|
| [1] | Control Panel Unit | - |
| [2] | Delivery Auxiliary Tray | - |
| [3] | Pickup Tray | - |
| [4] | Trailing Edge Paper Guides | - |
| [5] | Pickup Tray Side Guide Plate | - |
| [6] | Power Switch | - |
| [7] | Upper Cover | - |
| [8] | Delivery Tray | - |
| [9] | Front Cover Unit | - |
| [10] | Multi-Purpose Tray | - |
| [11] | Tray Cover | - |
| [12] | Multi-Purpose Tray Side Guide Plate | - |


• Rear Side (Simplex)



| No. | Name | Remarks |
|------|------------------------|----------------|
| [13] | Left Cover | - |
| [14] | Hinge Face Cover | - |
| [15] | Rear Cover | - |
| [16] | Right Cover | - |
| [17] | USB Device Port | - |
| [18] | LAN Port | Model with NET |
| [19] | External Device Jack | Model with FAX |
| [20] | Telephone Line Jack | Model with FAX |
| [21] | Power Supply Cord Slot | - |


● Cross Section

■ DADF




| No. | Name |
|-----|------------------------|
| [1] | DADF Pickup Roller |
| [2] | DADF Separation Roller |
| [3] | DADF Separation Pad |
| [4] | DADF Delivery Roller |
| [5] | DADF Feed Roller |

■ SADF




| No. | Name |
|-----|------------------------|
| [1] | SADF Pickup Roller |
| [2] | SADF Separation Roller |
| [3] | SADF Separation Pad |
| [4] | SADF Delivery Roller |
| [5] | SADF Feed Roller |

■ Reader



| No. | Name |
|-----|----------------------|
| [1] | Contact Image Sensor |


■ Printer(Duplex Model)



| No. | Name | No. | Name |
|-----|------------------------|------|---------------------|
| [1] | Duplex Feed Unit | [9] | Pickup Tray |
| [2] | Duplex Feed Roller | [10] | Multi-Purpose Tray |
| [3] | Fixing Pressure Roller | [11] | Photosensitive Drum |
| [4] | Fixing Film Unit | [12] | Pickup Roller |
| [5] | Delivery Roller | [13] | Separation Pad |
| [6] | Fixing Assembly | [14] | Feed Roller |
| [7] | Laser Scanner Unit | [15] | Transfer Roller |

| No. | Name | No. | Name |
|-----|-------------------------|-----|------|
| [8] | Delivery Auxiliary Tray | | |


■ Printer(Simplex Model)



| No. | Name | No. | Name |
|-----|-------------------------|------|---------------------|
| [1] | Fixing Pressure Roller | [8] | Multi-Purpose Tray |
| [2] | Fixing Film Unit | [9] | Photosensitive Drum |
| [3] | Delivery Roller | [10] | Pickup Roller |
| [4] | Fixing Assembly | [11] | Separation Pad |
| [5] | Laser Scanner Unit | [12] | Feed Roller |
| [6] | Delivery Auxiliary Tray | [13] | Transfer Roller |
| [7] | Pickup Tray | | |

● Control Panel


■ Touch Panel



| No. | Key/LED Name | Function |
|-----|----------------------|---|
| [1] | [HOME] key | Press to display the <Home> Screen. |
| [2] | [Status Monitor] key | Press to check the status of printing or faxing, to view the usage history, or to view the network settings such as the IP address of the machine. You can also check the status of the machine, such as the remaining amounts of paper and toner, or whether any errors occurred. |

| No. | Key/LED Name | Function |
|------|-----------------------------|--|
| [3] | [Back] key | Press to return to the previous screen. If you press this key when specifying settings, for example, the settings are not applied and the display returns to the previous screen. |
| [4] | Touch Panel | You can view the progress of copy, fax, and other jobs and error statuses. The display is a touch panel, allowing you to operate the screen by touch to specify settings. |
| [5] | [Reset] key | Press to cancel the settings and restore the previously specified settings. |
| [6] | [Clear] key | Press to delete the entered numbers and text. |
| [7] | Numeric keys ([0]-[9] keys) | Press to enter numbers and text. |
| [8] | [Stop] key | Press to cancel copying, faxing, and other operations. |
| [9] | [Symbols] key ([#] key) | Press to enter symbols such as "@" or "/". |
| [10] | [Stop] key | Press to cancel copying, faxing, and other operations. |
| [11] | [Start] key | Press to scan or copy documents. |
| [12] | [Energy Saver] key | Press to put the machine into sleep mode. The key lights up green when the machine is in sleep mode. Press the key again to exit sleep mode. |
| [13] | [Quiet Mode] key | Press to put the machine into quiet mode. While in quiet mode this key is lit in green. Press the key again to exit quiet mode. |
| [14] | [Processing/Data] indicator | Blinks while operations such as sending or printing are being performed. Lights up when there are documents waiting to be processed. |
| [15] | Wi-Fi indicator | Lights up when the machine is connected to wireless LAN. |
| [16] | [Error] indicator | Blinks or lights up when an error such as a paper jam occurs |

■ LCD Panel



| No. | Key/LED Name | Function |
|-----|----------------------|---|
| [1] | [COPY/SCAN] key | Press to switch the mode to copy or scan. |
| [2] | [Menu] key | Press to start specifying many of the settings for the machine, such as <Timer Settings> or <Preferences>. |
| [3] | [ID Card Copy] key | Press to enter a mode for copying the front and back sides of a driver's license or other ID card onto the same side of a page at actual size. |
| [4] | [Paper Setting] key | Press to select the paper you want to use, or to set the size and type of paper loaded in the paper source. |
| [5] | [Status Monitor] key | Press to check the status of printing or copy to view the usage history. You can also check the status of the machine, such as the remaining amounts of paper and toner, or whether any errors occurred. |
| [6] | Display | Displays the operation and status screens for copying and other functions, as well as the status of the machine and error information. Also, view the screen when specifying the settings of the machine. |
| [7] | [Reset] key | Press to cancel the settings and restore the previously specified settings. |

| No. | Key/LED Name | Function |
|------|--------------------------------|--|
| [8] | [UP]/[Down]/[Left]/[Right] key | <p>[Left] key</p> <ul style="list-style-type: none"> • When specifying settings, press to return to the previous screen. • When entering text, press to move the cursor to the left. • Press to decrease a setting value such as density for scanning, copying, etc. <p>[Right] key</p> <ul style="list-style-type: none"> • When specifying settings, press to proceed to the next screen. When entering text, press to move the cursor to the right. Press to increase the sound volume or a setting value such as density for scanning, copying, etc. <p>[UP] key</p> <ul style="list-style-type: none"> • When specifying settings, press to select the item above the currently selected item. • When changing setting values, press to increase a value. <p>[Down] key</p> <ul style="list-style-type: none"> • When specifying settings, press to select the item below the currently selected item. • When changing setting values, press to decrease a value. |
| [9] | [OK] key | Press to apply settings or specified details. |
| [10] | [Back] key | Press to return to the previous screen. If you press this key when specifying settings, for example, the settings are not applied and the display returns to the previous screen. |
| [11] | [Clear] key | Press to delete the entered numbers and text. |
| [12] | Numeric keys ([0]-[9] keys) | Press to enter numbers and text. |
| [13] | [Tone] Key [*] key | Press to switch the type of text that is entered. |
| [14] | [Symbols] Key [#] key | Press to enter symbols such as "@" or "/". |
| [15] | [Stop] key | Press to cancel copying, scanning, and other operations. |
| [16] | [Start] key | Press to scan or copy documents. |
| [17] | [Energy Saver] key | Press to put the machine into sleep mode. The key lights up green when the machine is in sleep mode. Press the key again to exit sleep mode. |
| [18] | [Quiet Mode] key | Press to put the machine into quiet mode. While in quiet mode this key is lit in green. Press the key again to exit quiet mode. |
| [19] | [Scan -> PC1] Key | Press to send the scanned documents to the registered computer for each key. |
| [20] | [Scan -> PC2] Key | Press to send the scanned documents to the registered computer for each key. |
| | [Paper Save Copy] Key | 2in1 Simplex -> Duplex, 4in1 Simplex -> Duplex, 2in1 Simplex -> Simplex, 4in1 Simplex -> When I set Simplex, I push it |
| [21] | [Processing/Data] indicator | Blinks while operations such as sending or printing are being performed. Lights up when there are documents waiting to be processed. |
| [22] | Wi-Fi indicator | Lights up when the machine is connected to wireless LAN. |
| [23] | [Error] indicator | Blinks or lights up when an error such as a paper jam occurs |




Technology

| | |
|--|----|
| Basic Configuration..... | 23 |
| Controller System..... | 25 |
| Document Exposure/Feeder System | 27 |
| Laser Exposure System..... | 31 |
| Image Formation System..... | 35 |
| Fixing System..... | 43 |
| Pickup And Feeding System..... | 47 |
| External And Controls System..... | 54 |

Basic Configuration

Configuration function

The machine may be broadly divided into the following 7 functional blocks: engine control system, document exposure/feeding system, laser exposure system, image formation system, pickup/transport/delivery system, fixing system, and externals/auxiliary control system.



Basic Sequence

Basic Sequence of Operation

The engine controller controls the operation sequence. The following table provides an outline of machine operation occurring from when the power switch is turned on to when printing ends and motors stop, indicating the purposes of intervals and engine operation. For details of various loads, see the timing chart.

| | Interval | Purpose | Remarks |
|----------------------------|--|--|---|
| WAIT (Wait) | From power-ON until initial drive for main motor is completed. | To clear potential from the drum surface and to clean the transfer roller. Also to bring the heater temperature up to the targeted temperature. | Detect whether the Toner cartridge is installed or not. |
| STBY (Standby) | From the end of the WAIT period or the LSTR period until the print command is sent from the main controller. Or, from the end of the LSTR period until power switch is turned OFF. | To keep the printer ready to print. | |
| INTR (initial rotation) | From the input of the print command from the main controller until the pick-up solenoid is turned ON. | To stabilize the photosensitive drum sensitivity in preparation for printing. Also to clean the transfer roller. | |
| PRINT (print) | From the end of the INTR period until the top of page sensor detects the trailing edge of paper. | To form image on the photosensitive drum based on the VIDEO (/VD01, /VD02, VD01, VD02) signals input from the main controller, and to transfer the toner image onto paper. | |


| | Interval | Purpose | Remarks |
|-------------------------|--|--|--|
| LSTR (last rotation) | From the end of PRINT period until the Main motor stops. | To deliver the last paper completely out of the printer. | Return to the INTR period as soon as another print command is sent from the main controller. |

Controller System

Main Controller

General description

The Main Controller receives print information from the Reader and ADF, Fax, and network. Video data is created from the received print information and is sent to the Engine Controller.



Engine Controller


General description

Engine controller is the circuit to control the operation sequence of the host machine and it is controlled by the CPU inside the engine controller.

When the power is turned ON and DC power is supplied through the low voltage power inside engine controller, CPU starts the printer operation control.

Then, CPU drives the loads such as laser diode, motors and solenoids etc. according to the image data that is input by the main controller when status becomes stand-by mode.

The following is the block diagram of this circuit.



Document Exposure/Feeder System

Document Exposure System

Overview


| Item | Function / Method |
|---------------------------------|---|
| Document exposure | LED |
| Document scan | Book mode: scan by the shift of the contact image sensor (CIS) SADF/DADF: document stream reading by fixed contact image sensor (CIS) |
| Copey Board Scanning resolution | 600 dpi X 600 dpi |
| ADF Scanning resolution | 300 dpi X 300 dpi |
| Number of gradations | 256 gradations |
| Magnification | 50% to 400% Horizontal: Image processing by Main controller PCB Vertical: Change of carriage shift speed, image processing by Main controller PCB |
| Lens | Rod lens array |
| CMOS sensor | Number of lines: 1 line Number of pixels: 5184 pixels as total pixels (5126 pixels as effective pixels) Maximum document scanning width: 216 mm |
| CS drive control | Drive control by Reader motor |
| Document size detection | None |

Major Components

Followings are the major components for Document Exposure System.

- The contact image sensor to scan document
- The Reader motor, the drive pulley, the drive belt, to shift the contact image sensor

In image scanning control, the contact sensor is shifted by rotating the Reader motor based on the drive signal from the SCNT PCB and scan the original on the copyboard glass. When ADF is in use, image is scanned by feeding the originals by ADF instead of shifting the contact image sensor.




Document Feeder System

■ Overview

● SADF

The Single-side Auto Document Feeder (SADF) mounted onto this host machine is dedicated to stream-reading. 1 motor (SADF motor) is engaged in pickup/feeding/delivery.

At the start of copy/fax/scan, the SADF motor is driven by the drive command from the Main controller to pickup/feed the originals set face up on the original tray one by one in order from the top. The original is scanned by the contact image sensor when moving through the copyboard glass, and then delivered face down to the original delivery assembly.




● DADF

Pickup/Feed/Delivery Operation


The Double-side Auto Document Feeder (DADF) mounted onto this host machine is dedicated to stream-reading. 1 motor (DADF motor) is engaged in pickup/feeding/delivery.

At the start of copy/fax/scan, the DADF motor is driven by the drive command from the Main controller to pickup/feed the originals set face up on the original tray one by one in order from the top. The original is scanned by the contact image sensor when moving through the copyboard glass, and then delivered face down to the original delivery assembly.




Operation at duplex reading


- Pickup to Reading of the 1st side



- Reverse to Reading of the 2nd side



- Delivery



■ Various Control

● Original Detection

There are two types of original detection in this equipment.

1. Original Presence / Absence Detection

Detected by DS (Document Sensor)

As the actuator is pushed up by placing an original on the Original Tray, DS of SADP is turned ON (light is blocked => light is transmitted) and DS of DADF is turned OFF (light is transmitted => light is blocked) so that presence of an original is detected.

2. Detection of the End of the Original


Detected by the DES (Document End Sensor)

The leading edge of the original that is fed pushes up the actuator, activating the DES (light shielded => light transmitted) and resulting in detection of the reach of the leading edge of original. Furthermore, when the trailing edge of the original passes the actuator position, the actuator returns to the original position, inactivating the DES (light transmitted => light shielded). The trailing edge of the original is detected by this mechanism. The original length that can be scanned with this equipment is less than 400 mm. Passing of the original longer than this results in jam stop. The original length is calculated by the time it takes from detection of the leading edge of the original to detection of the trailing edge of the original.


NOTE:

There is no function to detect the original size (original width, length) in this equipment.

In the case of SADF



In the case of DADF



• Jam Detection

The following cases are judged as jam.

1. In case of delay in reaching DS/DES or stationary during scanning of original
2. In case DS/DES is detected as ON at power-on (residual paper jam)
3. In case of detecting original of which length is 400 mm or longer

- Operation after Detection of Jam

The host machine stops scanning operation and displays "CHECK DOCUMENT" on the control panel. No jam code is displayed. In case of the model equipped with fax function (with built-in speaker), the warning beep occurs at the detection of jam.


- How to release Jam

Remove the jammed paper and open / close the SADF/DADF upper cover

Laser Exposure System

Overview

The laser exposure system forms static latent images on the photosensitive drum according to the VIDEO signals sent from the main controller, and is comprised of the laser driver and scanner motor, etc. These are controlled by the engine controller. The following is the outline.



The operational sequence of the laser scanner unit is described below.


1. When the Main controller sends print instruction command, the Engine controller rotates the Four-faced mirror, causing the Scanner motor to rotate.
2. When the Scanner motor starts to rotate, the Engine controller emits the laser forcibly using the Laser control signal, causing the Engine controller to start rotation control for the Scanner motor.
3. The Engine controller controls to keep a constant speed of rotation of the Scanner motor using the Scanner motor speed control signal.
4. After the rotation speed of the Scanner motor reaches its target, the Main controller sends VIDEO signals to the Laser driver PCB.
5. The Laser driver emits laser diode according to these signals.
6. The laser beam passes through the collimator lens and the cylindrical lens and enters the Four-faced mirror rotating at a constant speed.
7. The laser beam reflected by the Four-faced mirror is focused on the Photosensitive drum via the image-forming lens at the front of the Four-faced mirror.
8. When the Four-faced mirror rotates at a constant speed, the laser beam on the Photosensitive drum is scanned on the Photosensitive drum at a constant speed.
9. When the Photosensitive drum rotates at a constant speed and the laser beam is scanned on the Photosensitive drum at a constant speed, latent images are formed on the Photosensitive drum.

Controlling the Laser Activation Timing

Laser ON/OFF Control

In this control, the laser driver turns on/off the 2 laser diodes (LD1, LD2) according to the laser control signal sent from the engine controller.

The following is the circuit diagram of the laser control.



The engine controller sends the laser control signals (CNT0, CNT1, CNT2) for changing the operation mode of the laser to the logic circuit in the laser driver IC, as well as the video signals (VDO1, /VDO1, VDO2, /VDO2) for image formation.

The laser driver IC executes laser control according to the combination of the CNT0, CNT1, CNT2 signals.

The following is the combination of the laser control signal (CNT0, CNT1, CNT2).

| Operation mode | CNT0 | CNT1 | CNT2 | Details |
|----------------|------|------|------|--|
| Standby | L | L | L | Laser control OFF |
| Print | H | H | H | Can emit the laser according to the video signal |
| LD1 forced ON | L | H | L | LD1 forcibly turned ON |
| LD2 forced ON | H | L | L | LD2 forcibly turned ON |
| LD forced OFF | H | H | L | LD1, LD2 forcibly turned OFF |

Horizontal Sync Control

This is the control to adjust the writing position in the image horizontal direction.

The following is the details of control procedure.

1. The engine controller controls the laser control signal during unblanking (*) to emit the laser diode (LD) forcibly.
2. The BD PCB exists on the scanning route of the laser beam, which is sent to the BD PCB.
3. The BD PCB detects this laser beam, creates BD input signal (/BDI) and sends it to the engine controller.

4. The engine controller creates horizontal sync signals (/BD) based on /BDI signal and sends the /BD signal to the main controller.
5. When /BD signal is input, the main controller outputs the video signal (VD0, /VD0) to the engine controller to adjust the writing position in image horizontal direction.
 - *: Unblanking period
The period during which the laser diode is emitted in non-image area.

Laser Control

■ Auto Power Control (APC)

This is the control to emit a constant level of laser diode.

There are two types of APC; initial APC (note 1), and line space APC (note 2). The laser driver executes the same procedure for both controls. The following is the details of the control procedure.

1. When the laser control signal enters LD1 forced ON mode (CNT0, CNT1, CNT2), the laser driver emits LD1 forcibly.
2. The emission level of LD1 is detected with photo diode (PD), converted from current output to voltage, and compared with the standard voltage (voltage equivalent to the target laser level) with the comparator.
3. The laser driver controls the laser current to achieve the voltage of LD1 target level.
4. When the laser control signal enters LD forced OFF mode, the LD1 is forcibly turned off. The laser driver saves the adjusted laser intensity of the capacitor (C16).
5. When the adjustment of LD1 laser intensity is completed, the laser control signal enters LD2 forced ON mode; the laser driver emits LD2 forcibly.
The laser driver adjusts the LD2 laser intensity as in the case of LD1 and saves the adjusted laser intensity to the capacitor (C18).

CAUTION:


1. Initial APC
APC that is executed during initial rotation. APC adjusts laser intensity and detects faults in the laser.
2. Line space APC
APC that is executed during printing. Laser intensity for one line is adjusted before writing one line.

Laser Scanner Motor Control

■ Overview

This is the control to rotate the scanner motor at a constant speed to emit the laser beam on the correct position on the photosensitive drum.

The following is the control circuit of the scanner motor.



The engine controller creates standard clock based on oscillation frequency of the oscillator (X300); the cycles of the standard clock is compared with that of BD input signal (/BDI) with a frequency comparator and the rotations of the scanner motor is monitored.

The engine controller sends the scanner motor acceleration signal (ACC) and scanner motor deceleration signal (DEC) to the scanner motor driver according to the detected rotation speed to control the rotation speed.

■ Scanner Motor Fault Detection

This is the detection of faults in the laser scanner unit.

When the laser scanner unit falls into either of the following status, the engine controller judges it as a fault in the laser scanner unit system and notices the status of fault to the main controller.

The operations of the host machine are stopped.

1. Fault in BD input
At startup of the scanner, /BDI signal cannot be detected within the specified period of time from the completion of forced acceleration of the scanner motor.
2. Fault in startup
During activating the scanner motor at startup of the scanner, the motor rotation exceeds the specified range.
3. Fault in control
After startup of the scanner completes correctly, /BDI signal exceeds the specified value of cycle 2000 msec consecutive times.

Image Formation System

Overview/Configuration


Overview

The image formation system is the core of this equipment; it forms toner images on papers.

The image formation system is comprised of the following components.

The engine controller controls the laser scanner unit and high-voltage power supply circuit and forms images based on the video signals on papers.

The following are the details of print process for this equipment and the functions of image formation.



Print Process

This explains the basic process of the operations that a printer executes for image formation.


The print process of this equipment is divided largely into 5 blocks, 7 steps.

Toner images are formed on papers by executing the steps of each block in order.

The following are the blocks of print process and the steps.

1. Static latent image formation block
 - Step 1: Primary charging
 - Step 2: Laser beam exposure
2. Development block
 - Step 3: Development
3. Transfer block
 - Step 4: Transfer
 - Step 5: Separation
4. Fixing block
 - Step 6: Fixing


5. Drum cleaning block
Step 7: Drum cleaning



■ Static Latent Image Formation Block

This block is comprised of two steps and forms static latent images on the photosensitive drum.


When the final step of this block completes, negative charge remains at dark areas on the drum surface where laser beam has not been exposed, and negative charge is eliminated from bright areas on the drum surface with laser beam exposed. The images on the drum with negative charge are called static latent images because human eyes cannot detect them.



Step 1: Primary charging

For preparation of latent image formation, the surface of photosensitive drum is charged with even negative potential. In this primary charging, the charge is applied from the primary charging roller directly to the photosensitive drum.


DC bias is applied to the primary charging roller to maintain an even potential on the surface of the photosensitive drum.



Step 2: Laser beam exposure

In this step, static latent images are formed on the photosensitive drum with laser beam.

When laser beams are scanned on the photosensitive drum negatively charged, bright areas lose their charges, eliminating negative potential on the surface of the photosensitive drum; on those portions, static latent images are formed.



■ Development Block

This block is comprised of one step; it puts toners to the static latent images on the surface of the photosensitive drum and visualizes the images using toner projection development. The toner projection development makes the toner jump on the surface of the photosensitive drum and develops the images.

The toner (developer) used for this equipment is a one-component toner that comprises magnetic body and resin, etc.


Step 3: Development

Toner is affixed to static latent images on the surface of the photosensitive drum.

The toner is charged negatively by friction between the developing cylinder and the surface of the developing blade.

An area on the photosensitive drum exposed with laser beam has higher potential than the developing cylinder; the potential difference between the drum surface and the cylinder enables the toner to jump on the drum surface and makes them visible images.

AC bias superimposed with the development DC negative bias is applied to the developing cylinder.




■ Transfer Block

This block is comprised of two steps; it transfers toner images on the surface of the photosensitive drum to papers.

Step 4: Transfer


In this step, toner images on the photosensitive drum are transferred to papers.

This equipment applies DC positive bias to the transfer roller facing the photosensitive drum and charges papers positively. This enables toner negatively charged on the surface of the photosensitive drum to be transferred to papers.



Step 5: Separation

In this step, DC negative bias is applied to the static eliminator according to the elasticity of papers to separate the papers from the photosensitive drum. The static eliminator is used to stabilize the paper feed system (prevention of toner stray that appears as polka-dots on print images in a low-temperature, low-humidity environment), and neutralizes the electric charge at the back of papers.




■ Fixing Block

This block applies pressure and heat to papers and the toner on them to fix toner images to the papers.

Step 6: Fixing

This step employs on-demand fixing that fixes toner images transferred to papers on the papers.



■ Drum Cleaning Block


The drum cleaning block removes the toner remained on the photosensitive drum.

Step 7: Drum cleaning

In this step, toner remained on the photosensitive drum is removed.

The cleaning blade scrapes the leftover toner on the surface of the photosensitive drum; the toner is collected into the cleaner container.

By implementing the above step, the surface of the photosensitive drum is cleaned.




High-Voltage Control

■ Overview

This circuit is comprised of the circuits that apply biases to the primary charging roller, developing cylinder, transfer roller, and the fixing control circuit. The CPU of the engine controller controls the high-voltage power supply circuit to generate these biases. The fixing control circuit executes heater control of the fixing assembly according to the instruction by the CPU of the engine controller.

The following is the block diagram of this circuit.



■ Generating Primary Charging Bias

The primary charging bias (PRI) is a DC negative bias that is output to apply an even negative potential to the surface of the photosensitive drum. The primary charging high-voltage generating circuit in the high-voltage power supply circuit generates this bias.

The high-voltage power supply circuit applies the generated primary charging bias to the primary charging roller at a specified timing.

The primary charging bias varies in conjunction with the developing bias according to the information of image density sent from the main controller.

■ Generating Developing Bias

The developing bias is a DC negative bias that is output to affix toner to the static latent images formed on the photosensitive drum. This bias is a development DC and AC superimposed bias and generated by the development high-voltage generating circuit in the high-voltage power supply circuit.

The high-voltage power supply circuit applies the generated developing bias to the developing cylinder at a specified timing.

The developing bias varies in conjunction with the primary charging bias according to the information of image density sent from the main controller.

■ Generating Transfer Bias

Transfer bias (TR) is a bias that is output to transfer toner to papers. There are two types of bias; DC positive bias and DC negative bias, and generated by the transfer high-voltage generating circuit in the high-voltage power supply circuit. The DC positive bias is output at the time of toner transfer, and the DC negative bias at the time of cleaning the photosensitive drum.

The high-voltage power supply circuit applies the generated transfer bias to the transfer roller according to each print sequence. Each print sequence is described below.

- Cleaning bias:

The bias to move (clean) the toner attached to the transfer roller to the photosensitive drum at the time of warming up or last rotation sequence.

The transfer negative bias is applied to the transfer roller.

- Paper intervals bias:
The bias to prevent the toner remained on the photosensitive drum from attaching to the transfer roller at paper intervals during continuous printing. A minor transfer positive bias is applied to the transfer roller.
- Print bias:
The bias to transfer the toner on the surface of the photosensitive drum to papers at the time of print sequence. The transfer positive bias is applied to the transfer roller.

Toner Cartridge

■ Toner Level Detection

● 4in1 Model

Toner level is detected by the Toner Sensor (Magnetic Sensor). When a Toner Cartridge is installed, the Toner Sensor contacts with the lower side of the cartridge and it converts the magnetic changes in the cartridge into voltage.

Then, CPU of engine controller PCB compares the output voltage of the Toner Sensor with the reference value to detect the toner level.

Toner level detection is performed at startup of the Main Motor.

The toner level detection sequence starts after the Main Motor is started up and stabilization time has passed. The toner level detection sequence continues until the Main Motor stops. There are following 2 types of toner level detection sequence: sequence at warm-up rotation when opening door or turning ON the power, and sequence at normal rotation.

1. Sequence at normal rotation
From the start of detection, detection value of magnetic toner is sampled.
Remaining toner level is judged based on the average value and ripple value (V Peak to Peak) of the Magnetic Sensor output while the Stirring Stick makes a full turn.
2. Sequence at warm-up rotation
Conditions of sampling and remaining toner level judgment are the same as those mentioned above.
However, in the case that toner Low is detected even at once during warm-up rotation sequence, toner Low is remained to be displayed.

● 3in1 Model

This equipment has no function of toner level detection.

■ Specification of Toner level display

Toner level can be checked by pressing Status Monitor/Cancel key and selecting toner level.

The display of toner level is just a rough indication.

In the case of 4-in-1 models, the toner level is corrected depending on the usage conditions.

In the case of 3-in-1 models, a predicted value is displayed because they do not have the function to correct the level.

In the following cases, status of toner level is considered as unidentified, and OK (100%) is displayed on the panel.

- After power-on
- Right after recovery from engine sleep mode
- During opening/closing the door
- When the cartridge is not installed

● 4in1 Model

| Display | Handling | Complement |
|------------------------|---|------------|
| <Prepare a cartridge.> | This message notifies you that a toner cartridge needs to be replaced soon. Shake the toner cartridge to evenly distribute the toner inside the cartridge. Replace the toner cartridge if you see this message before you start to print a large job. | |

| Display | Handling | Complement |
|--|--|---|
| <The amount remaining in the cartridge is very low.> | The toner cartridge is about to reach the end of its lifetime. Shake the toner cartridge to evenly distribute the toner inside the cartridge. If this does not improve the print quality, replace the toner cartridge. | <ul style="list-style-type: none"> If this message is displayed, the incoming fax will be stored in the memory without being printed. Also, reports are not printed, even if they are set to be printed automatically. You can continue printing when this message is displayed, but the print quality may deteriorate. <p>When a message is displayed</p> <ul style="list-style-type: none"> If the message is displayed when the machine is receiving a fax or automatic report output is set, received faxes and reports will be stored in the machine so that they do not appear faded after they are printed. To continue printing even if the toner is running low, set <Continue Print. When Near Cart. Life End> to <On>. |

• 3in1 Model

| Display | Handling |
|---|--|
| <Preparing a cartridge is recommended.> | This message notifies you that a toner cartridge needs to be replaced soon. Shake the toner cartridge to evenly distribute the toner inside the cartridge. Replace the toner cartridge if you see this message before you start to print a large job. You can continue printing when this message is displayed, but the print quality may deteriorate. |

■ Operation when toner level is Low/Nearly Out

Operation when toner level is Low or Nearly Out is as follow. If another job which can be processed is introduced while there is a job which is stopped due to "Nearly Out", the job is output by overtaking the preceding job.

List of stop processing according to toner level

| Copy | | PDL | | Receive print | | Manual report | | Auto report | |
|------|------------|-----|------------|---------------|------------|---------------|------------|-------------|------------|
| Low | Nearly Out | Low | Nearly Out | Low | Nearly Out | Low | Nearly Out | Low | Nearly Out |
| Yes | Yes | Yes | Yes | Yes | No | Yes | Yes | Yes | No |

Yes: Continues


No: Page output is stopped immediately after detection, but it can be continued by user mode.

■ Toner Cartridge Absence/Presence Detection

The engine controller detects the position of the Toner cartridge detection flag to judge the absence/presence of the Toner cartridge.

At the time of turning on the power or closing the upper cover, the engine controller judges the position of the Toner cartridge flag based on the output result of the leading edge sensor (PS751).

When the output result of the leading edge sensor (PS751) is L, it is judged that the Toner cartridge is absent; If being H, it is judged that the Toner cartridge is present.



The leading edge sensor performs both this detection and paper feed detection. Therefore, the engine controller cannot make a judgment of 'Toner cartridge absent' or 'jam occurrence' when jam occurs.

The engine controller judges this case as 'Toner cartridge absent' and notices it to the main controller.

If jam occurs when 'Toner cartridge absent' is detected, check if there is a fault in the leading edge sensor and the detection flag.

Fixing System


Overview

Fixing/delivery system consists of the fixing film unit, pressure roller and delivery roller etc.

These rollers are driven by the main motor (M1).


The paper that toner is transferred to are heated by the fixing heater of the fixing film unit and pressured by the pressure roller.

The paper that toner is fused on is delivered from the fixing assembly, detected by the fixing delivery sensor (PS701) and the paper width sensor (PS702), and then delivered to the delivery tray by the delivery roller.



- [1] Delivery Roller
- [2] Fixing Film Unit
- [3] Fixing Pressure Roller
- PS701 Fixing delivery sensor
- PS702 Paper width sensor
- M1 Main motor

Main Parts of Fixing assembly



| | | | |
|-----|------------------|--|------|
| H1 | Fixing heater | For heating the fixing film (ceramic heater) | 1 pc |
| TH1 | Main thermistor | For controlling the fixing heater temperature (contact type thermistor) | 1 pc |
| TP1 | Temperature fuse | For detecting the fixing heater overheat (non-contact type fuse) When the heater overheats, the fuse melts to cut the power supply to the heater. | 1 pc |

Various Control Mechanisms


■ Fixing Temperature Control

● Heater Temperature Control

The heater temperature control is to keep the fixing heater in the fixing film unit to the specified temperature.

The engine controller monitors the fixing heater temperature detection signal (FSRTH) and outputs the fixing heater drive signal (FSRD) according to the detected temperature.

The fixing heater drive PCB controls the fixing heater according to this signal to keep the fixing heater temperature within the target values.



There are 11 types of target fixing temperature depending on the fixing mode. These types are according to the paper type settings and resolution settings on a driver.

■ Protective Functions

● Protective Function of fixing assembly

Host machine carries the following 3 functions to prevent the fixing heater from overheating.

1. Protective function by CPU
CPU of engine controller monitors the thermistor (TH1) temperature consistently. When TH1 reaches excessive temperature, CPU determines that the fixing heater is overheating and stops the fixing heater drive signal (FSRD) output and also turns OFF relays to shut the power supply to fixing heater.
2. Protection function by fixing heater safety circuit
Fixing heater safety circuit monitors the thermistor (TH1) temperature consistently. When TH1 reaches excessive temperature, it determines that the fixing heater is overheating and the fixing heater safety circuit turns OFF the relay drive circuit to shut the power supply to the fixing heater.
3. Protection function by temperature fuse (TP1)
When the fixing heater temperature rises abnormally and temperature fuse (TP1) temperature reaches abnormal temperature, TP1 opens to shut the power supply to the fixing heater.

● Failure detection

With this machine, 8 types of failure detection are available.

1. Initial startup failure detection
When temperature of the Fixing Assembly does not exceed 50 deg C within the specified period of time after the start of temperature control performed at initial rotation, it is judged as initial startup failure.

2. Initial Thermistor open detection
When temperature of the Fixing Assembly does not exceed 35 deg C within the specified period of time after the start of temperature control at warm-up rotation temperature control or at cleaning mode, it is judged as Thermistor open failure.
3. Short circuit of Thermistor/abnormal high temperature detection
When temperature of the Fixing Assembly is 220 deg C or higher for 30 consecutive times by monitoring the temperature for every specified period of time, it is judged as Thermistor short circuit failure. In addition, this function also doubles as abnormal high temperature detection function of the Fixing Assembly.
4. Abnormal low temperature detection
After temperature of the Fixing Assembly exceeds 50 deg C at least once, monitor temperature of the Thermistor for every specified period of time. It is judged as heater abnormal low temperature when the following condition is detected 240 consecutive times: the temperature is 100 deg C or lower while paper is at fixing nip, or it is 55 deg C or lower during paper interval temperature control or at cleaning mode.
5. Thermistor open detection
After temperature of the Fixing Assembly exceeds 50 deg C, monitor temperature of the Thermistor for every specified period of time. When it is detected that the temperature is lower than 20 deg C for 6 consecutive times, it is judged as Thermistor open failure.
6. Startup failure detection
If temperature of the Fixing Assembly is 100 deg C or higher when the machine becomes in pickup enabled state after entering fixing low voltage inlet sequence, it is judged as startup failure.
7. Thermistor low temperature detection 2)
Temperature of the Thermistor is monitored for every specified period of time when paper is at fixing nip during the Fixing Assembly control. When the temperature is lower than 135 deg C (120 deg C), increase the value of low temperature detection counter by 1 (+1). When it is 135 deg C (120 deg C) or higher, decrease the value by 1 (-1). When the value of low temperature counter becomes +150, it is judged as Thermistor low temperature failure. The default and minimum value of low temperature detection counter is 0.
8. Frequency detection circuit error (230V models only)
When frequency measurement is not completed within the specified period of time after the completion of previous frequency measurement, it is judged as frequency detection circuit error.

● Processing after failure detection

If the Main Motor is in driving state when Fixing Assembly failure is detected, rotation of the motor is maintained for specified period of time after the machine moves in Fixing Assembly failure state. Then, drive systems (Main Motor system, Laser/Scanner system, high voltage system, and fixing system) are stopped immediately and the machine moves in failure state.

If the Main Motor is not in driving state, drive systems are stopped immediately and the machine moves in failure state.

● Other Functions

■ Throughput Down Control

This machine performs the throughput down control that extends the paper interval and lower the printing speed to prevent the edge of the fixing heater from overheating at continuous printing of small paper (the paper with narrow width) and to prevent the fixing heater unit from overheating at high-volume continuous printing.

An extended paper interval lowers the fixing heater temperature between the papers, preventing the edge of the roller of fixing assembly and the delivery unit from overheating.

This control has the following (1) to (6) modes and the operation sequence differs depending on each modes.

| Paper Type | Paper Size | | | | |
|---------------|---|---|---|---|-----------------------|
| | Large-sized | Small-sized or Narrow | Long and Narrow | | 16K |
| | Length: 271 mm or more Width: 190 mm or more | Length: less than 271 mm (Width: less than 190 mm) | Length: less than 313 mm Width: less than 190 mm | Length: 313 mm or more Width: less than 190 mm | Length: 270 +/- 15 mm |
| Plain Paper | 25 (Full speed) -> 12 (half speed) *1 | (2) | 3 ppm (half speed) | 1 ppm (half speed) *2 | (5) |
| Plain Paper L | 25 (Full speed) -> 12 (Half speed) *1 | (2) | 3 ppm (half speed) | 1 ppm (half speed) *2 | (5) |
| Heavy Paper | - | (1) | 3 ppm (half speed) | 1 ppm (half speed) *2 | (6) |
| Rough Paper 1 | - | (1) | 3 ppm (half speed) | 1 ppm (half speed) *2 | (6) |

| Paper Type | Paper Size | | | | |
|---------------|-------------|-----------------------|-----------------------|--------------------------|-----|
| | Large-sized | Small-sized or Narrow | Long and Narrow | | 16K |
| Rough Paper 2 | - | (1) | 3 ppm (half speed) | 1 ppm (half speed) *2 | (6) |
| Label Paper | - | - | - | - | - |
| Transparency | - | - | - | - | - |
| Postcard | (4) | (4) | - | - | - |
| Envelope | - | (1) | - | - | - |

*1 : When the number of fed paper reaches 270 after starting from Cold state, the speed changes from full speed to half speed, and the throughput changes from 25ppm to 12ppm. The number of fed paper at which the throughput changes from full speed to half speed may vary according to temperature control of the Fixing Assembly.

*2 : Measures against wrinkle and curl.


| Number of Fed Sheets | (1) | (2) | (3) | (4) |
|----------------------|------------|------------|------------|------------|
| | Half speed | Half speed | Half speed | Half speed |
| 1 to 2 | 11 ppm | 12 ppm | - | 7 ppm |
| 3 | 9 ppm | 12 ppm | - | 7 ppm |
| 4 to 5 | 9 ppm | 12 ppm | - | 5 ppm |
| 6 to 10 | 8 ppm | 11 ppm | - | 4 ppm |
| 11 to 15 | 6 ppm | 11 ppm | - | 4 ppm |
| 16 to 20 | 6 ppm | 8 ppm | - | 4 ppm |
| 21 to 30 | 6 ppm | 8 ppm | - | 4 ppm |
| 31 to 40 | 4 ppm | 7 ppm | - | 4 ppm |
| 41 to 75 | 4 ppm | 6 ppm | - | 4 ppm |
| From 76 | 4 ppm | 6 ppm | - | 4 ppm |

| Number of Fed Sheets | (5) | (6) |
|----------------------|------------|------------|
| | Full speed | Half speed |
| 1 to 55 | 20 ppm | - |
| 56 to 110 | 16 ppm | - |
| 111 to 120 | 13 ppm | - |
| 121 to 150 | 11 ppm | 12 ppm |
| 151 to 250 | 10 ppm | 10 ppm |
| From 251 | 8 ppm | 8 ppm |


Pickup And Feeding System

Overview

■ Duplex Feed



■ Single Feed



The pickup and feeding system executes pickup and feeding of papers and is composed of the main motor, solenoid, and rollers. In this equipment, pickup from the pickup tray and manual feed tray is available. There is only a face-down delivery.

Papers set on the pickup tray and manual feed tray are fed by the same pickup roller. The papers are fed to the photosensitive drum, the transfer charging roller, the fixing sleeve unit, the pressure roller and then to delivery roller in this order; and then they are delivered to the delivery tray.

The feeding route of papers has three photointerrupters; the leading edge sensor (PS801), the fixing delivery sensor (PS701), the paper width sensor (PS702). They detect arrival and passing of papers.

If a paper does not reach or pass through each sensor within a specified time, the engine controller judges this status as jam and notices the jam occurrence to the main controller.

PS701: Fixing delivery sensor

PS702: Paper width sensor

PS801: Leading edge sensor

M1: Main motor

SL1: Pickup solenoid

SL2: Duplex Reverse solenoid

PS6: Tray sensor


● Detecting Jams

■ Jam Detection Outline

● Overview

The following sensors are installed to detect absence/presence of papers and whether papers are correctly fed.

- Fixing delivery sensor (PS701)
- Paper width sensor (PS702)
- Leading edge sensor (PS751)



Whether jam occurs or not is judged according to whether a paper is absent/present on the sensor at the check timing that has been stored in the CPU of the engine controller.

When the engine controller judged that jam has occurred, print operation is stopped and jam occurrence is noticed to the main controller.

■ Delay Jams

● Delivery Delay Jam

There are 3 types of delivery delay jam detections as follows:

A. When there is no preceding paper

B. When there is a preceding paper 1


In the case of narrow paper interval with the preceding paper

C. When there is a preceding paper 2

In the case of wide paper interval with the preceding paper

A. When there is no preceding paper

If the delivery sensor (PS701) detects no paper from 700 (1400) ms to 1235 (2470) ms after detection by the TOP sensor (PS751), a delivery delay jam is determined.




NOTE:

"700 (1400) ms" was calculated from the distance of 104.8 mm from the leading edge of the TOP sensor (PS751) to the fixing nip.


"1235 (2470) ms" was calculated from the distance of 135.5 mm from the leading edge of the TOP sensor (PS751) to that of the delivery sensor (PS701) and the delivery delay jam margin of 50 mm. Since the distance from the fixing nip to the delivery sensor (PS701) is 30.7 mm, the length of wrapping from the leading edge will be 80.7 mm. Since one lap of the film is 18.2π (57.2) mm, the length of wrapping is more than one lap. Considering paper looping, sensor accuracy, and thick-paper delivery, however, the value cannot be made smaller.

B. When there is a preceding paper 1



When there is preceding paper at the delivery sensor (PS701) 700 (1400) ms after paper detection by the TOP sensor (PS751) and the delivery sensor (PS701) does not detect the no-paper status until 1165 (2400) ms later, a delivery delay jam is determined.

C. When there is a preceding paper 2



When there is preceding paper at the delivery sensor (PS701) 700 (1400) ms after paper detection by the TOP sensor (PS751) and the delivery sensor (PS701) detects the no-paper status by 1165 (2400) ms later, a delivery delay jam is determined only if the delivery sensor (PS701) does not detect paper in the period from 70 ms after no paper detection by the delivery sensor (PS701) until 1235 (2470) ms after paper detection by the TOP sensor (PS751).

NOTE:

"1165 (2400) ms" is the balance of subtracting a margin of 70 ms from the delivery delay jam detection end time of 1235 (2470) ms by considering chattering from the trailing edge of the preceding paper is at the delivery sensor until the leading edge of the next paper is detected.

• Reversal Delay Jam

A reversal delay jam is determined when the Fixing Delivery Sensor (PS701) detects absence of paper at the time of 440 msec elapsed after the start of reversal operation.

NOTE:

The jam margin is 30 mm.

The sum of the distance from the reversing position to the leading edge detection position of the delivery sensor (PS701) plus the jam margin of 30 mm is equal to 520 ms at full speed and 1040 ms at half speed in terms of time. From the times, the delivery sensor (PS701) detection time of 30 ms is subtracted to calculate the jam judgment time.

• Re-pickup Delay Jam

After the start of reversal, if the TOP sensor (PS751) does not detect paper within 2445 (4895) ms after paper detection by the delivery sensor (PS701), a re-pickup delay jam is determined.

NOTE:

The jam margin is 90 mm. This margin is set long because the paper path after reversal between paper detection by the delivery sensor (PS701) and that by the TOP sensor (PS751) is long, the paper path length depends on the paper quality, and the stop time at the registration shutter prepared on the path for skew correction depends on the delivered paper.

• Delivery Delay Jam during auto delivery


A delivery delay jam is determined if the Paper Lead Edge Sensor (PS751) detects presence of paper and the Fixing Delivery Sensor (PS701) detects absence of paper at the time of 1115 msec elapsed after the start of auto delivery.

NOTE:

The auto delivery start timing is when the scanner stops.

• Delivery Delay during cleaning

A delivery delay jam is determined if the Fixing Delivery Sensor (PS701) fails to detect presence of paper within 1235 msec since the Paper Lead Edge Sensor (PS751) detected presence of paper.



• Multi-purpose tray pickup delay jam

When the multi-purpose tray (MPT) is specified as the paper source and paper is at the multi-purpose tray sensor, a feed delay jam is determined if the TOP sensor (PS751) does not detect fed paper with 1370 ms after the start of paper feed from the multi-purpose tray.

When the specified paper source is MPT, no jam status is output but the MPT no-paper status of the video interface.

■ Stationary Jams

• Pickup Stationary Jam

Without pre-feed, a feed stationary jam is determined if the TOP sensor (PS751) cannot detect the trailing edge of paper within 3960 (7920) ms after the leading edge is detected by the TOP sensor (PS751).

With pre-feed, a feed stationary jam is determined if the TOP sensor (PS751) cannot detect the trailing edge of paper within 4740 (9480) ms after the leading edge is detected by the TOP sensor (PS751).

NOTE:

"4740 ms" is the time equivalent of two LGL sheets. If LGL sheets are fed after A4-size standard continuous printing at pre-feed, the second LGL sheet may be fed as an A4-size standard sheet and therefore two LGL sheets may be fed almost with no break. To prevent this from stopping the machine by a jam, the feed stationary jam detection time during pre-feed is set to 4740 ms at full speed.

• Delivery Stationary Jam

The delivery sensor (PS701) is monitored for 265 (530) ms from 715 (1430) ms after no-paper detection by the TOP sensor (PS751), a delivery stationary jam is determined.

NOTE:

The margin is set to 20 mm because paper may spring up.

• Reversal Stationary Jam

After the start of reversal, if the delivery sensor (PS701) does not detect the no-paper status within 2570 (5140) ms after paper detection, a reverse stationary jam is determined.

NOTE:

This jam is determined if the delivery sensor (PS701) keeps detecting sensor for the time of delivering LEGAL + 30 mm.

● Pickup Stationary Jam during auto delivery

A pickup stationary jam is determined if the Paper Lead Edge Sensor (PS751) detects presence of paper at the time of 1115 msec elapsed after the start of auto delivery and then the Paper Lead Edge Sensor (PS751) detects presence of paper after the paper continued to be fed for 2730 msec.

● Delivery Stationary Jam during auto delivery

If there is no paper at the TOP sensor (PS751) 1235 (2470) ms after the start of auto delivery and there is paper at the delivery sensor (PS701) after further paper delivery of 980 (1965) ms, a delivery stationary jam is determined.

If there is paper at the TOP sensor (PS751) 1235 (2470) ms after the start of auto delivery and there is paper at the delivery sensor (PS701) after further paper delivery of 3075 (7410) ms, a delivery stationary jam is determined.

● Delivery Stationary Jam during cleaning


A delivery stationary jam is determined if the Fixing Delivery Sensor (PS701) fails to detect absence of paper within 2535 msec since the Main Motor started rotating after the cleaning step.

● Delivery Stationary Jam during warm-up rotation

If the delivery sensor (PS701) detects paper during warm-up rotation, a delivery stationary jam is determined.

■ Other Jams

● Fixing Wrap Jam



A fixing wrap jam is determined if the Fixing Delivery Sensor (PS701) detects absence of paper between the time of 50 msec after the Fixing Delivery Sensor (PS701) detected presence of paper and the time of 635 msec after the Paper Lead Edge Sensor (PS751) detected absence of paper.

NOTE:

The leading edge detection margin is 8 mm and the trailing edge detection margin is 20 mm. The leading edge margin is set to prevent the erroneous detection of a wrapping jam during chattering at paper entry. The trailing edge margin is set long because the detection time is not stable due to paper springing or other.

● Initial Paper Jam during printing

An initial paper jam is determined if either the Fixing Delivery Sensor (PS701) or the Paper Width Sensor (PS702) detects presence of paper immediately before the Print Main Motor started its rotation.


● Door Open Jam

A door open jam is determined when printing is interrupted due to the door open detection during printing while there is paper at the Paper Lead Edge Sensor (PS751) or the Fixing Delivery Sensor (PS702). The status value is retained if any jam has been already reported to the jam status.

● Initial paper presence Jam during warm-up rotation

If either the delivery sensor (PS701) or the paper width sensor (PS702) detects paper at the start of warm-up rotation, an initial paper presence jam is determined.

- **No-paper detection during cleaning**




If the TOP sensor (PS751) does not detect paper for 1370 ms from 200 ms after the start of paper feed, the no-paper status is determined.

External And Controls System

Power Supply

Power Supply



Protective Functions

Power protective function

Low voltage power circuit carries the overcurrent preventive function against and overvoltage preventive function that block the voltage output automatically to prevent the power circuit brokerage when the overcurrent or overvoltage occur due to load errors such as short circuit etc.

Thus, when the DC power cannot be output from the low voltage circuit, the protective function against overcurrent or overvoltage may be working. Since the secondary SW is used as the power SW, the power supply cord needs to be disconnected when fixing a trouble on the load side.

Also the circuit carries the 2 fuses (FU201, FU202) as a preventive function (see note 2). The fuses blow to block the power supply when overcurrent occurs in AC line.

⚠ CAUTION:

When restoring the low voltage power after protective function is activated, leave it for 2 minutes plugging out before turning ON.

- **Safety function**

The host machine equips the function of stopping 24V of fixing assembly and the high voltage power unit to avoid users and engineers from getting burned or electric shock.

When the cartridge door is opened, the interlock switch (SW501) is turned off and 24V supplied to fixing assembly and the high voltage power unit is shut.

Engine controller CPU determines the door open when each interlock switch is turned OFF.



Periodical Service

| | |
|----------------------------------|----|
| Periodically Replaced Parts..... | 57 |
| Consumables..... | 58 |
| Periodical Service..... | 59 |

Periodically Replaced Parts

Periodically Replaced Parts

There is no periodically replaced part with this machine.

Consumables

Consumables

There is no consumable with this machine.

Periodical Service

Scheduled Servicing

There is no portion that requires schedule servicing in this equipment.

4

Disassembly/ Assembly

| | |
|---|-----|
| Introduction..... | 62 |
| List of Parts..... | 63 |
| Connectors Layout Drawing..... | 82 |
| Original Exposure/Feed System (DADF Model)..... | 88 |
| Original Exposure/Feed System (SADF Model)..... | 118 |
| Original Exposure/Feed System (Copyboard Model)..... | 148 |
| External Cover/Internal System (Duplex Model)..... | 161 |
| Controller System (Duplex Model).... | 172 |
| Laser Exposure System (Duplex Model)..... | 209 |
| Image Formation System (Duplex Model)..... | 212 |
| Fixing System (Duplex Model)..... | 215 |
| Pickup Feed System (Duplex Model) | 222 |
| External Cover/Internal System (Simplex Model)..... | 243 |
| Controller System (Simplex Model)... | 253 |
| Laser Exposure System (Simplex Model)..... | 280 |

| | |
|---|-----|
| Image Formation System (Simplex Model)..... | 283 |
| Fixing System (Simplex Model)..... | 286 |
| Pickup Feed System (Simplex Model)..... | 292 |

Introduction

Outline

This chapter describes disassembling/assembling procedure of this equipment.

The service technician is to identify the cause of the failures according to "Chapter 6 Troubleshooting" and to replace the faulty parts by following the disassembling procedure. In addition, replace the consumable parts by following the same disassembling procedure.


Note the following precautions when working.

1. CAUTION: Be sure to disconnect the power plug before disassembling/assembling for safety.
2. When disassembling/assembling or transporting the machine, be sure to remove the cartridge beforehand as needed.
However, when the cartridge is removed from the machine, be sure to put the Photosensitive Drum in a protective bag even in a short period of time to prevent the adverse effect of light.
3. When assembling, perform the disassembling procedure in reverse order unless otherwise specified.
4. When assembling, be sure to tighten the screws to their appropriate locations according to the screw types (length, diameter).
5. Do not run the machine with any parts removed as a general rule.
6. When handling the PCB, be sure to touch the metal part of the printer to ground yourself to prevent damaging the PCB by static electricity.
7. When replacing the part with the rating name plate, be sure to affix it to the new part.

List of Parts


External View

■ DADF Unit and Reader Unit



| No. | Name | Reference | Remarks |
|------|------------------------------|---|---------|
| [1] | DADF Upper Cover | | - |
| [2] | DADF Rear Cover | | - |
| [3] | Side Guide Plate | | - |
| [4] | Original Feed Tray | | - |
| [5] | Original Feed Auxiliary Tray | | - |
| [6] | Original Delivery Tray | | - |
| [7] | DADF Front Cover | | - |
| [8] | Document Reading Glass | | - |
| [9] | Copyboard Guide Holder | | - |
| [10] | White Guide Plate | | - |
| [11] | White Plate | | - |
| [12] | Copyboard Glass | "Removing the Copyboard Glass (DADF Model)" on page 109 | - |
| [13] | Copyboard Upper Cover | | - |

■ SADF Unit and Reader Unit



| No. | Name | Reference | Remarks |
|------|------------------------------|---|---------|
| [1] | SADF Upper Cover | "Removing the SADF Upper Cover Unit" on page 125 | - |
| [2] | SADF Rear Cover | | - |
| [3] | Side Guide Plate | | - |
| [4] | Original Feed Tray | | - |
| [5] | Original Feed Auxiliary Tray | | - |
| [6] | Original Delivery Tray | | - |
| [7] | SADF Front Cover | | - |
| [8] | Document Reading Glass | | - |
| [9] | Copyboard Guide Holder | | - |
| [10] | White Guide Plate | | - |
| [11] | White Plate | | - |
| [12] | Copyboard Glass | "Removing the Copyboard Glass (SADF Model)" on page 139 | - |
| [13] | Copyboard Upper Cover | | - |


■ Copyboard Unit and Reader Unit



| No. | Name | Reference | Remarks |
|-----|------------------------|--|---------|
| [1] | Copyboard Cover | "Removing the Copyboard Cover" on page 148 | - |
| [2] | Copyboard Guide Holder | | - |
| [3] | White Plate | | - |
| [4] | Copyboard Glass | "Removing the Copyboard Glass (Copyboard Model)" on page 152 | - |
| [5] | Copyboard Upper Cover | | - |


■ Duplex Printer Unit

● Front Side



| No. | Name | Reference | Remarks |
|------|-------------------------------------|--|---------|
| [1] | Control Panel Unit | "Removing the Control Panel Unit (Duplex Model)" on page 173 | - |
| [2] | Delivery Auxiliary Tray | | - |
| [3] | Pickup Tray | | - |
| [4] | Trailing Edge Paper Guides | | - |
| [5] | Pickup Tray Side Guide Plate | | - |
| [6] | Power Switch | | - |
| [7] | Upper Cover | "Removing the Upper Cover Unit (Duplex Model)" on page 167 | - |
| [8] | Delivery Tray | "Removing the Upper Cover Unit (Duplex Model)" on page 167 | - |
| [9] | Front Cover Unit | "Removing the Front Cover Unit (Duplex Model)" on page 166 | - |
| [10] | Multi-Purpose Tray | | - |
| [11] | Tray Cover | | - |
| [12] | Multi-Purpose Tray Side Guide Plate | | - |


● Rear Side



| No. | Name | Reference | Remarks |
|------|------------------------|---|----------------|
| [13] | Left Cover | "Removing the Left Cover (Duplex Model)" on page 162 | - |
| [14] | Hinge Face Cover | | - |
| [15] | Duplex Feed Guide Unit | "Removing the Duplex Feed Guide Unit. (Duplex Model)" on page 169 | - |
| [16] | Right Cover | "Removing the Right Cover (Duplex Model)" on page 164 | - |
| [17] | USB Device Port | | - |
| [18] | LAN Port | | Model with NET |
| [19] | External Device Jack | | Model with FAX |
| [20] | Telephone Line Jack | | Model with FAX |
| [21] | Power Supply Cord Slot | | - |


■ Simplex Printer Unit

● Front Side



| No. | Name | Reference | Remarks |
|------|-------------------------------------|---|---------|
| [1] | Control Panel Unit | "Removing the Control Panel Unit (Simplex Model)" on page 254 | - |
| [2] | Delivery Auxiliary Tray | | - |
| [3] | Pickup Tray | | - |
| [4] | Trailing Edge Paper Guides | | - |
| [5] | Pickup Tray Side Guide Plate | | - |
| [6] | Power Switch | | - |
| [7] | Upper Cover | "Removing the Upper Cover (Simplex Model)" on page 249 | - |
| [8] | Delivery Tray | "Removing the Upper Cover (Simplex Model)" on page 249 | - |
| [9] | Front Cover Unit | "Removing the Front Cover Unit (Simplex Model)" on page 248 | - |
| [10] | Multi-Purpose Tray | | - |
| [11] | Tray Cover | | - |
| [12] | Multi-Purpose Tray Side Guide Plate | | - |


● Rear Side



| No. | Name | Reference | Remarks |
|------|------------------------|--|----------------|
| [13] | Left Cover | "Removing the Left Cover (Simplex Model)" on page 244 | - |
| [14] | Hinge Face Cover | | - |
| [15] | Rear Cover | "Removing the Rear Cover (Simplex Model)" on page 251 | - |
| [16] | Right Cover | "Removing the Right Cover (Simplex Model)" on page 246 | - |
| [17] | USB Device Port | | - |
| [18] | LAN Port | | Model with NET |
| [19] | External Device Jack | | Model with FAX |
| [20] | Telephone Line Jack | | Model with FAX |
| [21] | Power Supply Cord Slot | | - |


● List of Main Unit

■ DADF Unit and Reader Unit




| No. | Name | Reference | Remarks |
|-----|--------------------|--|---------|
| [1] | DADF Unit | "Disconnecting the DADF Unit + Reader Unit" on page 92 | - |
| [2] | Control Panel Unit | "Removing the Control Panel Unit (Duplex Model)" on page 173 | - |
| [3] | Reader Unit | "Disconnecting the DADF Unit + Reader Unit" on page 92 | - |

■ SADF Unit and Reader Unit




| No. | Name | Reference | Remarks |
|-----|--------------------|---|---------------|
| [1] | SADF Unit | "Disconnecting the SADF Unit and the Reader Unit" on page 122 | - |
| [2] | Control Panel Unit | "Removing the Control Panel Unit (Duplex Model)" on page 173 | Duplex Model |
| | | "Removing the Control Panel Unit (Simplex Model)" on page 254 | Simplex Model |
| [3] | Reader Unit | "Disconnecting the SADF Unit and the Reader Unit" on page 122 | - |

■ Copyboard Unit and Reader Unit




| No. | Name | Reference | Remarks |
|-----|--------------------|---|---------------|
| [1] | Copyboard Cover | “Removing the Copyboard Cover” on page 148 | - |
| [2] | Control Panel Unit | “Removing the Control Panel Unit (Duplex Model)” on page 173 | Duplex Model |
| | | “Removing the Control Panel Unit (Simplex Model)” on page 254 | Simplex Model |
| [3] | Reader Unit | “Removing the Copyboard Cover + Reader Unit” on page 149 | |

■ Duplex Printer Unit



| No. | Name | Reference | Remarks |
|-----|------------------------|---|---------|
| [1] | Duplex Feed Guide Unit | "Removing the Duplex Feed Guide Unit. (Duplex Model)" on page 169 | - |
| [2] | Fixing Assembly | "Removing the Fixing Assembly (Duplex Model)" on page 215 | - |
| [3] | Main Drive Unit | | - |
| [4] | Laser Scanner Unit | "Removing the Laser Scanner Unit (Duplex Model)" on page 209 | - |
| [5] | Pickup Tray Unit | "Removing the Pickup Tray Unit (Duplex Model)" on page 229 | - |
| [6] | Pickup Unit | "Removing the Pickup Unit (Duplex Model)" on page 222 | - |


■ Simplex Printer Unit



| No. | Name | Reference | Remarks |
|-----|--------------------|---|---------|
| [1] | Fixing Assembly | "Removing the Fixing Assembly (Duplex Model)" on page 215 | - |
| [2] | Main Drive Unit | | - |
| [3] | Laser Scanner Unit | "Removing the Laser Scanner Unit (Simplex Model)" on page 280 | - |
| [4] | Pickup Tray Unit | "Removing the Pickup Tray Unit (Simplex Model)" on page 298 | - |
| [5] | Pickup Unit | "Removing the Pickup Unit (Simplex Model)" on page 292 | - |


Electrical Components

■ DADF Unit and Reader Unit



| Key | E-No. | Name | Reference | Remarks |
|-----|-------|---------------------------|--|---------|
| [1] | CIS | Contact Image Sensor | "Removing the Contact Image Sensor (DADF Model)" on page 112 | |
| [2] | M3 | Flatbed Motor Unit | "Removing the Flat Bed Motor Unit (DADF Model)" on page 114 | |
| [3] | PS2 | DADF Original Sensor | | |
| [4] | M4 | DADF Motor Unit | "Removing the DADF Motor Unit" on page 99 | |
| [5] | PS3 | DADF Original Edge Sensor | | |
| [6] | SL3 | DADF Solenoid Unit | "Removing the DADF Solenoid Unit" on page 101 | |


■ SADF Unit and Reader Unit



| Key | E-No. | Name | Reference | Remarks |
|-----|-------|----------------------|--|---------|
| [1] | CIS | Contact Image Sensor | "Removing the Contact Image Sensor (SADF Model)" on page 142 | |
| [2] | M3 | Flatbed Motor Unit | "Removing the Flat Bed Motor Unit (SADF Model)" on page 144 | |
| [3] | M5 | SADF Motor Unit | "Removing the SADF Motor" on page 130 | |

| Key | E-No. | Name | Reference | Remarks |
|-----|-------|---------------------------|-----------|---------|
| [4] | PS5 | SADF Original Edge Sensor | | |
| [5] | PS4 | SADF Original Sensor | | |


■ Copyboard Unit and Reader Unit



| Key | E-No. | Name | Reference | Remarks |
|-----|-------|----------------------|---|---------|
| [1] | CIS | Contact Image Sensor | "Removing the Contact Image Sensor (Copyboard Model)" on page 155 | |
| [2] | M3 | Flatbed Motor Unit | "Removing the Flat Bed Motor Unit (Copyboard Model)" on page 157 | |

■ Duplex Printer Unit


● Motor/Fan (Duplex Model)



| Key | E-No. | Name | Reference | Remarks |
|-----|-------|------------|--|---------|
| [1] | M1 | Main Motor | "Removing the Main Motor (Duplex Model)" on page 174 | |
| [2] | FM1 | Main Fan | "Removing the Main Fan (Duplex Model)" on page 178 | |


| Key | E-No. | Name | Reference | Remarks |
|-----|-------|------------------------|--|---------|
| [3] | M2 | Laser Scanner Motor | | |
| [4] | FM3 | Edge Left Cooling Fan | "Removing the Edge Left Cooling Fan (Duplex Model)" on page 182 | |
| [5] | FM2 | Edge Right Cooling Fan | "Removing the Edge Right Cooling Fan (Duplex Model)" on page 184 | |

• Solenoid (Duplex Model)




| Key | E-No. | Name | Reference | Remarks |
|-----|-------|-----------------|---|---------|
| [1] | SL1 | Duplex Solenoid | "Removing the Duplex Solenoid (Duplex Model)" on page 240 | |
| [2] | SL2 | Pickup Solenoid | "Removing the Pickup Solenoid (Duplex Model)" on page 235 | |

- Sensor (Duplex Model)




| Key | E-No. | Name | Reference | Remarks |
|-----|--------|---------------------------|---|-----------|
| [1] | PS1151 | Encoder Sensor | | |
| [2] | PS1 | Multi Pickup Sensor | "Removing the Toner Sensor and Multi Pickup Sensor Unit (Fax Model + Duplex Model)" on page 204 | |
| [3] | PS6 | Tray Sensor | - | |
| [4] | SR1 | Toner Sensor | "Removing the Toner Sensor and Multi Pickup Sensor Unit (Fax Model + Duplex Model)" on page 204 | FAX Model |
| [5] | PS751 | Paper Leading Edge Sensor | "Removing the Paper Leading Edge Sensor PCB (Duplex Model)" on page 196 | |
| [6] | PS702 | Paper Width Sensor | "Removing the Fixing Delivery/Paper Width Sensor PCB (Duplex Model)" on page 200 | |
| [7] | PS701 | Fixing Delivery Sensor | "Removing the Fixing Delivery/Paper Width Sensor PCB (Duplex Model)" on page 200 | |

• Switch and Speaker (Duplex Model)




| Key | E-No. | Name | Reference | Remarks |
|-----|-------|--------------|---|-----------|
| [1] | SP1 | Speaker | "Removing the Speaker (Fax Model + Duplex Model)" on page 206 | FAX Model |
| [2] | UNIT3 | Power Switch | | |
| [3] | SW501 | Door Switch | | |

• Heater/Thermoswitch/Thermistor (Duplex Model)



| Key | E-No. | Name | Reference | Remarks |
|-----|-------|---------------|-----------|---------|
| [1] | TP1 | Thermoswitch | | |
| [2] | H1 | Fixing Heater | | |
| [3] | TH1 | Thermistor | | |

• PCB (Duplex Model)




| Key | E-No. | Name | Reference | Remarks |
|------|---------------|-------------------------------|--|-------------------|
| [1] | UNIT15 | Control Panel PCB | "Removing the Control Panel Unit (Duplex Model)" on page 173 | Touch Panel Model |
| [2] | UNIT16 | Touch Panel | | Touch Panel Model |
| [3] | DSP2 | Display | | Touch Panel Model |
| [4] | UNIT19 | Control Panel PCB | | LCD Panel Model |
| [5] | DISP1 | Display | | LCD Panel Model |
| [6] | UNIT8 | Bias | | |
| [7] | UNIT4 | Duplex Driver PCB | | |
| [8] | UNIT5 | Motor Driver PCB | | |
| [9] | UNIT6 | Laser Driver PCB | | |
| [10] | UNIT2 / UNIT3 | Power Switch PCB | | |
| [11] | UNIT14 | Wireless LAN PCB | "Removing the Wirelss LAN PCB (Wifi Model + Duplex Model)" on page 195 | Wifi Model |
| [12] | UNIT17 | FAX NCU PCB | "Removing the FAX NCU PCB (Fax Model 120V/ 230V) (Duplex Model)" on page 194 | FAX Model |
| [13] | UNIT12 | Main controller PCB | "Removing the Main Controller PCB (Duplex Model)" on page 191 | |
| [14] | UNIT1 | Engine Controller PCB | "Removing the Engine Controller PCB (Duplex Model)" on page 186 | |
| [15] | UNIT11 | Paper Leading Edge Sensor PCB | "Removing the Paper Leading Edge Sensor PCB (Duplex Model)" on page 196 | |

| Key | E-No. | Name | Reference | Remarks |
|------|--------|--|--|---------|
| [16] | UNIT10 | Fixing Delivery/Paper Width Sensor PCB | “Removing the Fixing Delivery/Paper Width Sensor PCB (Duplex Model)” on page 200 | |


Simplex Printer Unit

■ Motor/Fan (Simplex Model)




| Key | E-No. | Name | Reference | Remarks |
|-----|-------|---------------------|---|---------|
| [1] | M1 | Main Motor | “Removing the Main Motor (Simplex Model)” on page 255 | |
| [2] | M2 | Laser Scanner Motor | | |

■ Solenoid (Simplex Model)




| Key | E-No. | Name | Reference | Remarks |
|-----|-------|-----------------|--|---------|
| [1] | SL1 | Pickup Solenoid | "Removing the Pickup Solenoid (Simplex Model)" on page 304 | |

■ Sensor (Simplex Model)




| Key | E-No. | Name | Reference | Remarks |
|-----|--------|---------------------------|--|-----------|
| [1] | PS1151 | Encoder Sensor | | |
| [2] | PS1 | Multi Pickup Sensor | "Removing the Toner Sensor and Multi Pickup Sensor Unit (Fax Model + Simplex Model)" on page 274 | |
| [3] | PS6 | Tray Sensor | - | |
| [4] | SR1 | Toner Sensor | "Removing the Toner Sensor and Multi Pickup Sensor Unit (Fax Model + Simplex Model)" on page 274 | FAX Model |
| [5] | PS751 | Paper Leading Edge Sensor | "Removing the Paper Leading Edge Sensor (Simplex Model)" on page 267 | |
| [6] | PS702 | Paper Width Sensor | "Removing the Fixing Delivery/Paper Width Sensor PCB (Simplex Model)" on page 271 | |
| [7] | PS701 | Fixing Delivery Sensor | "Removing the Fixing Delivery/Paper Width Sensor PCB (Simplex Model)" on page 271 | |

■ Switch and Speaker (Simplex Model)




| Key | E-No. | Name | Reference | Remarks |
|-----|-------|--------------|--|-----------|
| [1] | SP1 | Speaker | "Removing the Speaker (Fax Model + Simplex Model)" on page 277 | FAX Model |
| [2] | UNIT3 | Power Switch | | |
| [3] | SW501 | Door Switch | | |

■ Heater/Thermoswitch/Thermistor (Simplex Model)



| Key | E-No. | Name | Reference | Remarks |
|-----|-------|---------------|-----------|---------|
| [1] | TP1 | Thermoswitch | | |
| [2] | H1 | Fixing Heater | | |
| [3] | TH1 | Thermistor | | |

■ PCB (Simplex Model)




| Key | E-No. | Name | Reference | Remarks |
|------|---------------|-------------------------------|--|-------------------|
| [1] | UNIT15 | Control Panel PCB | "Removing the Control Panel Unit (Simplex Model)" on page 254 | Touch Panel Model |
| [2] | UNIT16 | Touch Panel | | Touch Panel Model |
| [3] | DSP2 | Display | | Touch Panel Model |
| [4] | UNIT19 | Control Panel PCB | | LCD Panel Model |
| [5] | DISP1 | Display | | LCD Panel Model |
| [6] | UNIT8 | Bias | | |
| [7] | UNIT5 | Motor Driver PCB | | |
| [8] | UNIT6 | Laser Driver PCB | | |
| [9] | UNIT2 / UNIT3 | Power Switch PCB | | |
| [10] | UNIT14 | WiFi Module PCB | "Removing the Wireless LAN PCB (Wifi Model + Simplex Model)" on page 267 | Wifi Model |
| [11] | UNIT17 | FAX-NCU PCB | "Removing the FAX NCU PCB (Fax Model 120V/230V + Simplex Model)" on page 266 | FAX Model |
| [12] | UNIT12 | Main Controller PCB | "Removing the Main Controller PCB (Simplex Model)" on page 263 | |
| [13] | UNIT1 | Engine Controller PCB | "Removing the Engine Controller PCB (Simplex Model)" on page 258 | |
| [14] | UNIT11 | Paper Leading Edge Sensor PCB | "Removing the Paper Leading Edge Sensor (Simplex Model)" on page 267 | |

| Key | E-No. | Name | Reference | Remarks |
|------|--------|--|---|---------|
| [15] | UNIT10 | Fixing Delivery/Paper Width Sensor PCB | “Removing the Fixing Delivery/Paper Width Sensor PCB (Simplex Model)” on page 271 | |


Connectors Layout Drawing

DADF Unit and Reader Unit




| J No. | Symbol | Name | Relay connector | J No. | Symbol | Name | Remarks |
|-------|--------|---------------------|-----------------|-------|--------|----------------------|---------|
| J2 | UNIT11 | Main controller PCB | | J1601 | CIS | CIS Sensor | |
| J7 | UNIT11 | Main controller PCB | | J1402 | PS2 | Original Sensor | |
| J7 | UNIT11 | Main controller PCB | | J1403 | PS3 | Original Edge Sensor | |
| J8 | UNIT11 | Main controller PCB | | - | SL3 | DADF Solenoid Unit | |
| J11 | UNIT11 | Main controller PCB | | - | M3 | Flatbed Motor Unit | |
| J12 | UNIT11 | Main controller PCB | | J1401 | M4 | DADF Motor Unit | |

SADF Unit and Reader Unit




| J No. | Symbol | Name | Relay connector | J No. | Symbol | Name | Remarks |
|-------|--------|---------------------|-----------------|-------|--------|----------------------|---------|
| J2 | UNIT11 | Main controller PCB | | J1601 | CIS | CIS Sensor | |
| J7 | UNIT11 | Main controller PCB | | J1406 | PS4 | Original Sensor | |
| J7 | UNIT11 | Main controller PCB | | J1407 | PS5 | Original Edge Sensor | |
| J11 | UNIT11 | Main controller PCB | | - | M3 | Flatbed Motor Unit | |
| J12 | UNIT11 | Main controller PCB | | - | M5 | SADF Motor Unit | |


Copyboard Unit and Reader Unit



| J No. | Symbol | Name | Relay connector | J No. | Symbol | Name | Remarks |
|-------|--------|---------------------|-----------------|-------|--------|--------------------|---------|
| J2 | UNIT11 | Main controller PCB | | J1601 | CIS | CIS Sensor | |
| J11 | UNIT11 | Main controller PCB | | - | M3 | Flatbed Motor Unit | |


Duplex Printer Unit



| J No. | Symbol | Name | Relay connector | J No. | Symbol | Name | Remarks |
|-------|--------|-----------------------|-----------------|-------|---------------|--|-------------|
| J101 | UNIT1 | Engine Controller PCB | | - | TP1 | Thermoswitch | |
| J542 | UNIT1 | Engine Controller PCB | | J801 | UNIT6 | Laser Driver PCB | |
| J551 | UNIT1 | Engine Controller PCB | | - | UNIT11 | Paper Leading Edge Sensor PCB | PS751 |
| J552 | UNIT1 | Engine Controller PCB | | - | UNIT10 | Fixing Delivery/Paper Width Sensor PCB | PS701,PS702 |
| J562 | UNIT1 | Engine Controller PCB | | - | SL2 | Pickup Solenoid | |
| J571 | UNIT1 | Engine Controller PCB | | - | UNIT5 | Motor Driver PCB | |
| J581 | UNIT1 | Engine Controller PCB | | J3 | - | TAG | |
| J912 | UNIT1 | Engine Controller PCB | | J1104 | UNIT2 / UNIT3 | Power Switch PCB | |
| - | UNIT1 | Engine Controller PCB | | J1 | - | INLET | |
| J1153 | UNIT5 | Motor Driver PCB | | J802 | M2 | Laser Scanner Unit | |
| J1154 | UNIT5 | Motor Driver PCB | | - | UNIT4 | Duplex Driver PCB | |
| J1102 | UNIT4 | Duplex Driver PCB | | - | SL1 | Duplex Solenoid | |
| J1103 | UNIT4 | Duplex Driver PCB | | - | FM1 | Main Fan | |
| - | TH1 | Thermistor | | J702 | UNIT10 | Fixing Delivery/Paper Width Sensor PCB | PS701,PS702 |




| J No. | Symbol | Name | Relay connector | J No. | Symbol | Name | Remarks |
|-------|--------|-----------------------|-----------------|-------|--------|------------------------|------------|
| J901 | UNIT1 | Engine Controller PCB | | J1417 | SR1 | Toner Sensor | FAX Model |
| J905 | UNIT1 | Engine Controller PCB | | J1416 | PS1 | Multi Pickup Sensor | |
| J1 | UNIT12 | Main controller PCB | | J401 | UNIT15 | Control Panel PCB | |
| J3 | UNIT12 | Main controller PCB | | J902 | UNIT1 | Engine Controller PCB | |
| J4 | UNIT12 | Main controller PCB | | J1 | UNIT14 | Wireless LAN PCB | Wifi Model |
| J10 | UNIT12 | Main controller PCB | J103 | J103 | FM3 | Edge Front Cooling Fan | |
| J10 | UNIT12 | Main controller PCB | J102 | J102 | FM2 | Edge Rear Cooling Fan | |
| J15 | UNIT12 | Main controller PCB | | - | PS6 | Tray Sensor | |
| J901 | UNIT12 | Main controller PCB | | J1204 | UNIT17 | FAX NCU PCB | FAX Model |
| J903 | UNIT12 | Main controller PCB | | J1201 | UNIT17 | FAX NCU PCB | FAX Model |
| J904 | UNIT12 | Main controller PCB | | - | SP1 | Speaker | FAX Model |
| J1152 | UNIT5 | Motor Driver PCB | | - | M1 | Main Motor | |
| J402 | UNIT15 | Control Panel PCB | | - | DISP1 | Display | |
| J403 | UNIT15 | Control Panel PCB | | - | DISP2 | Display | |

| J No. | Symbol | Name | Relay connector | J No. | Symbol | Name | Remarks |
|-------|--------|-------------------|-----------------|-------|--------|-------------|-------------------|
| J404 | UNIT15 | Control Panel PCB | | - | UNIT16 | Touch Panel | Touch Panel Model |

Simplex Printer Unit




| J No. | Symbol | Name | Relay connector | J No. | Symbol | Name | Remarks |
|-------|--------|-----------------------|-----------------|-------|--------------|--|-------------|
| J101 | UNIT1 | Engine Controller PCB | | - | TP1 | Thermoswitch | |
| J542 | UNIT1 | Engine Controller PCB | | J801 | UNIT6 | Laser Driver PCB | |
| J551 | UNIT1 | Engine Controller PCB | | J751 | UNIT11 | Paper Leading Edge Sensor PCB | PS751 |
| J552 | UNIT1 | Engine Controller PCB | | J701 | UNIT10 | Fixing Delivery/Paper Width Sensor PCB | PS701,PS702 |
| J562 | UNIT1 | Engine Controller PCB | | - | SL2 | Pickup Solenoid | |
| J571 | UNIT1 | Engine Controller PCB | | J1151 | UNIT5 | Motor Driver PCB | |
| J581 | UNIT1 | Engine Controller PCB | | J3 | - | TAG | |
| J912 | UNIT1 | Engine Controller PCB | | J1104 | UNIT2 /UNIT3 | Power Switch PCB | |
| J104 | UNIT1 | Engine Controller PCB | | J1 | - | INLET | |
| J1153 | UNIT5 | Motor Driver PCB | | J802 | M2 | Laser Scanner Unit | |
| - | TH1 | Thermistor | | J702 | UNIT10 | Fixing Delivery/Paper Width Sensor PCB | PS701,PS702 |



| J No. | Symbol | Name | Relay connector | J No. | Symbol | Name | Remarks |
|-------|--------|-----------------------|-----------------|-------|--------|-----------------------|-------------------|
| J901 | UNIT1 | Engine Controller PCB | | J1417 | SR1 | Toner Sensor | FAX Model |
| J905 | UNIT1 | Engine Controller PCB | | J1416 | PS1 | Multi Pickup Sensor | |
| J1 | UNIT12 | Main controller PCB | | J401 | UNIT15 | Control Panel PCB | |
| J3 | UNIT12 | Main controller PCB | | J902 | UNIT1 | Engine Controller PCB | |
| J4 | UNIT12 | Main controller PCB | | J1 | UNIT14 | Wireless LAN PCB | Wifi Model |
| J15 | UNIT12 | Main controller PCB | | - | PS6 | Tray Sensor | |
| J901 | UNIT12 | Main controller PCB | | J1204 | UNIT17 | FAX NCU PCB | FAX Model |
| J903 | UNIT12 | Main controller PCB | | J1201 | UNIT17 | FAX NCU PCB | FAX Model |
| J904 | UNIT12 | Main controller PCB | | - | SP1 | Speaker | FAX Model |
| J1152 | UNIT5 | Motor Driver PCB | | - | M1 | Main Motor | |
| J402 | UNIT15 | Control Panel PCB | | - | DISP1 | Display | |
| J403 | UNIT15 | Control Panel PCB | | - | DISP2 | Display | |
| J404 | UNIT15 | Control Panel PCB | | - | UNIT16 | Touch Panel | Touch Panel Model |

Original Exposure/Feed System (DADF Model)

Layout Drawing



| No. | Name | Reference | Remarks |
|------|---------------------------|--|---------|
| [1] | DADF Unit and Reader Unit | "Removing the DADF Unit + Reader Unit" on page 89 | |
| [2] | DADF Unit | "Disconnecting the DADF Unit + Reader Unit" on page 92 | |
| [3] | DADF Pickup Unit | "Removing the DADF Pickup Unit" on page 95 | |
| [4] | DADF Pickup Roller Unit | "Removing the DADF Pickup Roller Unit" on page 103 | |
| [5] | DADF Solenoid Unit | "Removing the DADF Solenoid Unit" on page 101 | |
| [6] | DADF Separation Pad | "Removing the DADF Separation Pad" on page 106 | |
| [7] | DADF Motor Unit | "Removing the DADF Motor Unit" on page 99 | |
| [8] | Copyboard Glass | "Removing the Copyboard Glass (DADF Model)" on page 109 | |
| [9] | Contact Image Sensor | "Removing the Contact Image Sensor (DADF Model)" on page 112 | |
| [10] | Flatbed Motor Unit | "Removing the Flat Bed Motor Unit (DADF Model)" on page 114 | |

● Removing the DADF Unit + Reader Unit




■ Preparation


1. Remove the Left Cover (Duplex Model) "Removing the Left Cover (Duplex Model)" on page 162.

■ Procedure

1. Close the DADF Unit + Reader Unit [1].
2. Remove the Reader Harness Cover [2].
 - 2 Shafts [3]




3. Disconnect the 2 terminals [1] and the 4 connectors [4] of the Grounding Wire, and free the Grounding Wire and the harness [5] from the Harness Guide [A].
 - 1 Screw (black TP) [2]
 - 1 Wire Saddle [3]



4. Free the 2 Flat Cables [1] from the Harness Guide [A].

- 4 Ferrite Cores [2]
- 4 Claws [3]


**5. Open the DADF Unit + Reader Unit [1].**

6. Remove the DADF Unit + Reader Unit [1].



- 2 Claws [2]

CAUTION:

- Be sure to install/remove the unit carefully so as not to damage the Flat Cable [3] and harness [4] with the [A] part.




- Be sure to place the unit so as not to damage the Flat Cable [3] and harness [4].




NOTE:

How to assemble the DADF Unit + Reader Unit

Be sure to secure the 2 claws [1] of the Hinge Arm to the 2 hooks [2] of the Reader Unit.

**NOTE:**

The following shows how to route the harness.



● Disconnecting the DADF Unit + Reader Unit




■ Preparation

1. Remove the Left Cover (Duplex Model) **“Removing the Left Cover (Duplex Model)”** on page 162.
2. Remove the DADF Unit + Reader Unit **“Removing the DADF Unit + Reader Unit”** on page 89.

■ Procedure

CAUTION:


Do not damage the White Sheet [1] and White Guide Plate [2].



1. Change the orientation of the Control Panel Unit [1] so that it is facing down.


CAUTION:

Be sure to put a piece of paper [2] and place the Control Panel Unit [1] on it carefully so as not to damage it.




2. Remove the Harness Cover [1].

- 4 Claws [2]




3. Free the harness [1] from the guide [A].



NOTE:


How to Assemble the Harness Cover

As for the guide [A], be sure to install the Harness Cover after routing the harness [2] on the back side of the Flat Cable [1].




4. Change the orientation of the Reader Unit so that its bottom surface [1] is facing down.


5. Release the lock [2] on the lower left front side of the Reader Unit, and open the DADF Unit [3].



6. Separate the DADF Unit [1] and the Reader Unit [2].



● Removing the DADF Pickup Unit




■ Preparation

1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)”](#) on page 162.
2. Remove the DADF Unit + Reader Unit [“Removing the DADF Unit + Reader Unit”](#) on page 89.
3. Disconnecting the DADF Unit + Reader Unit [“Disconnecting the DADF Unit + Reader Unit”](#) on page 92.


■ Procedure

CAUTION:

Do not damage the White Guide Plate [1].




1. Open the DADF Pickup Auxiliary Tray [1] and DADF Upper Cover Unit [2].




2. Close the DADF Pickup Auxiliary Tray, and remove the DADF Pickup Tray Unit [1].

- 1 Claw [2]



3. Remove the DADF Rear Cover [1].

- 1 Boss [2]
- 3 Hooks [3]





4. Remove the DADF Front Cover [1].

- 1 Boss [2]
- 4 Claws [3]

NOTE:

The locations of the 4 claws [3] of the DADF Front Cover are shown here.



NOTE:


How to assemble the DADF Front Cover

Be sure to align the 2 claws [3] on the left side with the holes [A] of the DADF Front Cover to install the cover.




5. Remove the DADF Pickup Front Cover [1].


- 1 Claw [2]
- 3 Hooks [3]



6. Remove the Wire Saddle [1], the Harness Guide [2], and the 4 screws [3].




7. Close the DADF Upper Cover Unit [1], and remove the DADF Pickup Unit [2].




8. Remove the DADF Upper Cover Unit [1].

- 2 Shafts [2]



● Removing the DADF Motor Unit




■ Preparation

1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)”](#) on page 162.
2. Remove the DADF Unit + Reader Unit [“Removing the DADF Unit + Reader Unit”](#) on page 89.
3. Disconnecting the DADF Unit + Reader Unit [“Disconnecting the DADF Unit + Reader Unit”](#) on page 92.
4. Removing the DADF Pickup Unit [“Removing the DADF Pickup Unit”](#) on page 95.

■ Procedure

1. Remove the 2 connectors [1] and the Grounding Terminal [2] of the DADF Communication Cable.

- 1 Screw [3]
- 1 Edge Saddle [4]
- 1 Harness Guide [A].




2. Remove the DADF Motor Unit [1].

- 3 Screws [2]

CAUTION:


Be sure to perform work carefully so as to displace the gear phase.



NOTE:


How to assemble the DADF Motor Unit

1. Assemble it in the following order.




- [1] Separation Swing Arm
- [2] Separation Gear 21T/42T
- [3] Gear 17T/51T
- [4] Gear 23T/46T
- [5] Gear 20T
- [6] DADF Motor Unit

2. Ensure that the 2 points [A] in the DADF Pickup Unit and DADF Motor Unit are in contact with the 2 edges of the shafts.



● Removing the DADF Solenoid Unit



■ Preparation

1. Remove the Left Cover (Duplex Model) “Removing the Left Cover (Duplex Model)” on page 162.

2. Remove the DADF Unit + Reader Unit “Removing the DADF Unit + Reader Unit” on page 89.
3. Disconnecting the DADF Unit + Reader Unit “Disconnecting the DADF Unit + Reader Unit” on page 92.
4. Removing the DADF Pickup Unit “Removing the DADF Pickup Unit” on page 95.
5. Remove the DADF Motor Unit “Removing the DADF Motor Unit” on page 99.


■ Procedure

CAUTION:

Be sure to perform work carefully so as to displace the gear phase.

1. Remove the DADF Solenoid Unit [1].


- 1 E-ring [2]
- 2 Screws [3]
- 3 Harness Bands [4]




NOTE:

How to assemble the DADF Solenoid Unit

- Pass the Solenoid Shaft [1] through the hole [A] of the Solenoid Arm.
- Ensure that the 2 points on the DADF Pickup Unit Shaft [2] and the 2 contact points [B] on the DADF Solenoid Unit are in contact with each other.



● Removing the DADF Pickup Roller Unit




■ Procedure

CAUTION:


Do not touch the surface of the Pickup Roller.

1. Open the Original Feed Auxiliary Tray [1] and DADF Upper Cover Unit [2].




2. Remove the DADF Upper Cover Unit [1].

- 2 Bosses [2]
- 7 Hooks [3]




3. Remove the gear [1].


- 1 Claw [2]




4. Remove the 2 E-rings [1] and the 2 bushings [2].



5. Move the bushing [1], and remove the Pickup Roller [2].




6. Remove the spring [1] and the bushing [2].


**NOTE:**

How to assemble the DADF Pickup Roller Unit

1. Assemble it by aligning the spring [1] with the boss [2].



2. Be sure to align the orientation of the edge [A] of the 2 bushings [1] in the vertical direction.
 - 1 E-ring [2]
3. Be sure to align the gear [3] with the D-cut [B] of the DADF Pickup Roller Shaft.




● Removing the DADF Separation Pad




■ Procedure

CAUTION:

- Do not touch the pad surface.
- Do not lose the spring [1] on the back side of the DADF Separation Pad.




1. Open the Original Feed Auxiliary Tray [1], the DADF Upper Cover Unit [2], and the DADF Inner Guide [3].




2. Hold the 2 protrusions [A] of the DADF Separation Pad, and remove the DADF Separation Pad Cover [1].


- 2 Screws [2]

**3. Remove the DADF Separation Pad [1].**

- 2 Shafts [2]




4. Remove the spring [2] from the DADF Separation Pad [1].




NOTE:

How to assemble the DADF Separation Pad


1. Insert the spring [1] into the boss [2].




2. Install the DADF Separation Pad Cover [1].
 - 2 Screws [2]



3. Assemble it by pressing the DADF Separation Pad [1] and hooking the claw [2].



● Removing the Copyboard Glass (DADF Model)




■ Preparation

1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)”](#) on page 162.
2. Remove the DADF Unit + Reader Unit [“Removing the DADF Unit + Reader Unit”](#) on page 89.
3. Disconnecting the DADF Unit + Reader Unit [“Disconnecting the DADF Unit + Reader Unit”](#) on page 92.


■ Procedure

CAUTION:

- Be sure to place the removed Copyboard Glass on a cloth, etc. to avoid damaging the bottom sheet.
- When removing the Copyboard Glass, be careful not to touch the glass surface.
- If the surface becomes dirty, clean it with lint free paper.




1. Remove the 2 screws [1].



2. Remove the Copyboard Guide Holder [1].

- 1 Claw [2]
- 1 Hook [3]





3. Remove the Reader Upper Cover Unit [1].

- 2 Screws [2]
- 5 Claws A [3]
- 1 Claw B [4]

NOTE:



The following shows the 5 claws A [3] and the claw B [4] of the Reader Upper Cover Unit.



4. Remove the Copyboard Glass [1].

CAUTION:

- Do not lose the 2 spacers [1] of the Contact Image Sensor Unit.
- Do not touch the document reading part [A] of the Contact Image Sensor Unit.



● Removing the Contact Image Sensor (DADF Model)




■ Preparation

1. Remove the Left Cover (Duplex Model) “[Removing the Left Cover \(Duplex Model\)](#)” on page 162.
2. Remove the DADF Unit + Reader Unit “[Removing the DADF Unit + Reader Unit](#)” on page 89.
3. Disconnecting the DADF Unit + Reader Unit “[Disconnecting the DADF Unit + Reader Unit](#)” on page 92.
4. Remove the Copyboard Glass (DADF Model) “[Removing the Copyboard Glass \(DADF Model\)](#)” on page 109.


■ Procedure

CAUTION:

- Do not lose the 2 spacers [1] of the Contact Image Sensor Unit.
- Do not touch the document reading part [A] of the Contact Image Sensor Unit.




1. Move the Contact Image Sensor Unit [1].




2. Remove the 2 spacers [1] and the Flat Cable [2].

- 1 Guide [A]




3. Remove the Contact Image Sensor [1].


- 2 Shafts [2]

**CAUTION:**

If the Contact Image Sensor Unit comes off, be sure to put the tooth [1] of the belt in the groove [2] on the bottom of the Contact Image Sensor to install the unit.



● Removing the Flat Bed Motor Unit (DADF Model)




■ Preparation

1. Remove the Left Cover (Duplex Model) “[Removing the Left Cover \(Duplex Model\)](#)” on page 162.
2. Remove the DADF Unit + Reader Unit “[Removing the DADF Unit + Reader Unit](#)” on page 89.
3. Disconnecting the DADF Unit + Reader Unit “[Disconnecting the DADF Unit + Reader Unit](#)” on page 92.
4. Remove the Copyboard Glass (DADF Model) “[Removing the Copyboard Glass \(DADF Model\)](#)” on page 109.


■ Procedure

CAUTION:

- Do not lose the 2 spacers [1] of the Contact Image Sensor Unit.
- Do not touch the document reading part [A] of the Contact Image Sensor Unit.





1. Move the Contact Image Sensor Unit [1].



2. Press the gear [1] to bend the belt [2], and remove the belt [2] from the gear [3].


CAUTION:

Grease is applied on the shaft [4] of the Contact Image Sensor, so be careful not to let the belt [2] come in contact with the shaft.




3. Remove the Guide Cover [1].

- 1 Claw [2]




4. Free the harness [1] and the Grounding Wire [2] from the hole [A] of the Reader Unit and the Harness Guide [B].




5. Remove the Flat Bed Motor Unit [1].

- 2 Screws [2]




CAUTION:

If the Contact Image Sensor Unit comes off, be sure to put the tooth [1] of the belt in the groove [2] on the bottom of the Contact Image Sensor to install the unit.



Original Exposure/Feed System (SADF Model)

Layout Drawing



| No. | Name | Reference | Remarks |
|------|---------------------------|---|---------|
| [1] | SADF Unit and Reader Unit | "Removing the SADF Unit + Reader Unit." on page 119 | |
| [2] | SADF Unit | "Disconnecting the SADF Unit and the Reader Unit" on page 122 | |
| [3] | SADF Pickup Unit | "Removing the SADF Pickup Unit" on page 129 | |
| [4] | SADF Upper Cover Unit | "Removing the SADF Upper Cover Unit" on page 125 | |
| [5] | SADF Pickup Roller Unit | "Removing the SADF Pickup Roller Unit" on page 132 | |
| [6] | SADF Separation Pad | "Removing the SADF Separation Pad" on page 136 | |
| [7] | SADF Motor Unit | "Removing the SADF Motor" on page 130 | |
| [8] | Copyboard Glass | "Removing the Copyboard Glass (SADF Model)" on page 139 | |
| [9] | Contact Image Sensor | "Removing the Contact Image Sensor (SADF Model)" on page 142 | |
| [10] | Flatbed Motor Unit | "Removing the Flat Bed Motor Unit (SADF Model)" on page 144 | |

● Removing the SADF Unit + Reader Unit.



■ Preparation

● Duplex Model

1. Remove the Left Cover (Duplex Model) “Removing the Left Cover (Duplex Model)” on page 162.


● Simplex Model

1. Remove the Left Cover (Simplex Model) “Removing the Left Cover (Simplex Model)” on page 244.

■ Procedure


1. Disconnect the 2 terminals [1] and the 3 connectors [4] of the Grounding Wire, and free the Grounding Wire and the harness [5] from the Harness Guide [A].

- 1 Screw (black TP) [2]
- 1 Wire Saddle [3]



2. Free the 2 Flat Cables [1] from the Harness Guide [A].

- 4 Ferrite Cores [2]
- 4 Claws [3]




3. Remove the SADF Unit + Reader Unit [1].



- 2 Claws [2]

CAUTION:

- Be sure to install/remove the unit carefully so as not to damage the Flat Cable [3] and harness [4] with the [A] part.




- Be sure to place the unit so as not to damage the Flat Cable [3] and harness [4].




NOTE:

How to assemble the SADF Unit + Reader Unit

Be sure to secure the 2 claws [1] of the Hinge Arm to the 2 hooks [2] of the Reader Unit.

**NOTE:**

The following shows how to route the harness.



● Disconnecting the SADF Unit and the Reader Unit



■ Preparation

● Duplex Model

1. Remove the Left Cover (Duplex Model) “Removing the Left Cover (Duplex Model)” on page 162.
2. Remove the SADF Unit + Reader Unit “Removing the SADF Unit + Reader Unit.” on page 119.

● Simplex Model


1. Remove the Left Cover (Simplex Model) “Removing the Left Cover (Simplex Model)” on page 244.
2. Remove the SADF Unit + Reader Unit “Removing the SADF Unit + Reader Unit.” on page 119.

■ Procedure

1. Change the orientation of the Control Panel Unit [1] so that it is facing down.


CAUTION:

Be sure to put a piece of paper and place the Control Panel Unit [1] on it carefully so as not to damage it.




2. Remove the Harness Cover [1].

- 2 Claws [2]




3. Free the harness [1] from the guide [A].



NOTE:


How to Assemble the Harness Cover

As for the guide [A], be sure to install the Harness Cover after routing the harness [2] on the back side of the Flat Cable [1].



4. Change the orientation of the Reader Unit so that its bottom surface [1] is facing down.

5. Release the lock [2] and open the SADF Unit [3].




6. Separate the SADF Unit [1] and the Reader Unit [4].

- 1 Boss [2]
- 1 Claw [3]

CAUTION:

Do not damage the White Sheet [1] and White Guide Plate [2].



Removing the SADF Upper Cover Unit



■ Preparation

● Duplex Model

1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)”](#) on page 162.
2. Remove the SADF Unit + Reader Unit [“Removing the SADF Unit + Reader Unit.”](#) on page 119.
3. Separate the SADF Unit and the Reader Unit [“Disconnecting the SADF Unit and the Reader Unit”](#) on page 122.


● Simplex Model

1. Remove the Left Cover (Simplex Model) [“Removing the Left Cover \(Simplex Model\)”](#) on page 244.


2. Remove the SADF Unit + Reader Unit “Removing the SADF Unit + Reader Unit.” on page 119.
3. Separate the SADF Unit and the Reader Unit “Disconnecting the SADF Unit and the Reader Unit” on page 122.

■ Procedure

1. Open the SADF Pickup Auxiliary Tray [1] and SADF Upper Cover Unit [2].
2. Close the SADF Pickup Auxiliary Tray [1].




3. Remove the SADF Pickup Tray Unit [1].
 - 1 Claw [2]



4. Remove the SADF Rear Cover [1].

- 3 Claws [2]





5. Remove the SADF Front Cover [1].

- 1 Boss [2]
- 3 Claws [3]

NOTE:

SADF Front Cover


The locations of the 3 claws [3] of the SADF Front Cover are shown here.



NOTE:


How to assemble the SADF Front Cover

Be sure to align the claw [3] on the left side with the hole [A] of the SADF Front Cover to install the cover.




6. Remove the SADF Upper Cover Unit [1].

- 1 Boss [2]
- 2 Shafts [3]



● Removing the SADF Pickup Unit



■ Preparation

● Duplex Model

1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)”](#) on page 162.
2. Remove the SADF Unit + Reader Unit [“Removing the SADF Unit + Reader Unit.”](#) on page 119.
3. Separate the SADF Unit and the Reader Unit [“Disconnecting the SADF Unit and the Reader Unit”](#) on page 122.
4. Remove the SADF Upper Cover Unit [“Removing the SADF Upper Cover Unit”](#) on page 125.


● Simplex Model

1. Remove the Left Cover (Simplex Model) [“Removing the Left Cover \(Simplex Model\)”](#) on page 244.
2. Remove the SADF Unit + Reader Unit [“Removing the SADF Unit + Reader Unit.”](#) on page 119.
3. Separate the SADF Unit and the Reader Unit [“Disconnecting the SADF Unit and the Reader Unit”](#) on page 122.
4. Remove the SADF Upper Cover Unit [“Removing the SADF Upper Cover Unit”](#) on page 125.

■ Procedure


CAUTION:

Do not damage the White Guide Plate [1].




1. Remove the SADF Pickup Unit [1].

- 5 Screws (B Tightening) [2]
- Guide [A]



● Removing the SADF Motor



■ Preparation

● Duplex Model


1. Remove the Left Cover (Duplex Model) "[Removing the Left Cover \(Duplex Model\)](#)" on page 162.
2. Remove the SADF Unit + Reader Unit "[Removing the SADF Unit + Reader Unit.](#)" on page 119.
3. Separate the SADF Unit and the Reader Unit "[Disconnecting the SADF Unit and the Reader Unit](#)" on page 122.

• Simplex Model

1. Remove the Left Cover (Simplex Model) “Removing the Left Cover (Simplex Model)” on page 244.
2. Remove the SADF Unit + Reader Unit “Removing the SADF Unit + Reader Unit.” on page 119.
3. Separate the SADF Unit and the Reader Unit “Disconnecting the SADF Unit and the Reader Unit” on page 122.


■ Procedure

1. Open the SADF Pickup Auxiliary Tray [1] and the SADF Upper Cover Unit [2].




2. Remove the SADF Rear Cover [1].

- 3 Claws [2]




3. Remove the SADF Motor [1].

- 2 Screws [2]
- 2 Harness Bands [3]



Removing the SADF Pickup Roller Unit



■ Preparation

● Duplex Model

1. Remove the Left Cover (Duplex Model) “[Removing the Left Cover \(Duplex Model\)](#)” on page 162.
2. Remove the SADF Unit + Reader Unit “[Removing the SADF Unit + Reader Unit.](#)” on page 119.
3. Separate the SADF Unit and the Reader Unit “[Disconnecting the SADF Unit and the Reader Unit](#)” on page 122.
4. Remove the SADF Upper Cover Unit “[Removing the SADF Upper Cover Unit](#)” on page 125.


● Simplex Model

1. Remove the Left Cover (Simplex Model) “[Removing the Left Cover \(Simplex Model\)](#)” on page 244.
2. Remove the SADF Unit + Reader Unit “[Removing the SADF Unit + Reader Unit.](#)” on page 119.
3. Separate the SADF Unit and the Reader Unit “[Disconnecting the SADF Unit and the Reader Unit](#)” on page 122.
4. Remove the SADF Upper Cover Unit “[Removing the SADF Upper Cover Unit](#)” on page 125.

■ Procedure


1. Remove the SADF Upper Cover [1].

- 1 Screw (B Tightening) [2]
- 1 Claw [3]
- 5 Hooks [4]




2. Remove the gear [1].


- 1 Claw [2]




3. Remove the 2 E-rings [1] and the 2 bushings [2].



4. Move the bushing [1], and remove the Pickup Roller [2].




5. Remove the spring [1] and the bushing [2] from the Pickup Roller Unit.




NOTE:

How to assemble the SADF Pickup Roller Unit

1. Assemble it by aligning the spring [1] with the boss [2].



2. Be sure to align the orientation of the edge [A] of the 2 bushings [1] in the vertical direction.
 - 1 E-ring [2]
3. Be sure to align the gear [3] with the D-cut [B] of the Pickup Roller Shaft.



● Removing the SADF Separation Pad



■ Preparation

● Duplex Model

1. Remove the Left Cover (Duplex Model) “Removing the Left Cover (Duplex Model)” on page 162.
2. Remove the SADF Unit + Reader Unit “Removing the SADF Unit + Reader Unit.” on page 119.
3. Separate the SADF Unit and the Reader Unit “Disconnecting the SADF Unit and the Reader Unit” on page 122.
4. Remove the SADF Upper Cover Unit “Removing the SADF Upper Cover Unit” on page 125.


● Simplex Model

1. Remove the Left Cover (Simplex Model) “Removing the Left Cover (Simplex Model)” on page 244.
2. Remove the SADF Unit + Reader Unit “Removing the SADF Unit + Reader Unit.” on page 119.
3. Separate the SADF Unit and the Reader Unit “Disconnecting the SADF Unit and the Reader Unit” on page 122.
4. Remove the SADF Upper Cover Unit “Removing the SADF Upper Cover Unit” on page 125.

■ Procedure


CAUTION:

- Do not touch the surface of the Separation Pad.
- Do not lose the spring [3] on the back side of the Separation Pad.




1. Remove the SADF Pickup Guide Unit [1].

- 4 Screws (B Tightening) [2]




2. Release the 2 claws [2] of the Separation Pad [1].




3. Remove the Separation Pad Holder [1].

- 2 Claws [2]
- 2 Hooks [3]



4. Remove the Separation Pad [1].


- 2 Shafts [2]




NOTE:

How to assemble the Separation Pad


1. Insert the spring [1] into the boss [2].




2. Install the SADF Separation Pad Cover [1].
 - 2 Hooks [2]
 - 2 Claws [3]



3. Assemble it by pressing the DADF Separation Pad [1] and hooking the claw [2].



● Removing the Copyboard Glass (SADF Model)



■ Preparation

● Duplex Model

1. Remove the Left Cover (Duplex Model) “Removing the Left Cover (Duplex Model)” on page 162.
2. Remove the SADF Unit + Reader Unit “Removing the SADF Unit + Reader Unit.” on page 119.
3. Separate the SADF Unit and the Reader Unit “Disconnecting the SADF Unit and the Reader Unit” on page 122.


● Simplex Model

1. Remove the Left Cover (Simplex Model) “Removing the Left Cover (Simplex Model)” on page 244.
2. Remove the SADF Unit + Reader Unit “Removing the SADF Unit + Reader Unit.” on page 119.
3. Separate the SADF Unit and the Reader Unit “Disconnecting the SADF Unit and the Reader Unit” on page 122.


■ Procedure

CAUTION:

- Be sure to place the removed Copyboard Glass on a cloth, etc. to avoid damaging the bottom sheet.
- When removing the Copyboard Glass, be careful not to touch the glass surface.
- If the surface becomes dirty, clean it with lint free paper.




1. Remove the 2 screws [1].



2. Remove the Copyboard Guide Holder [1].

- 1 Claw [2]
- 1 Hook [3]





3. Remove the Reader Upper Cover Unit [1].

- 2 Screws [2]
- 5 Claws A [3]
- 1 Claw B [4]

NOTE:



The following shows the 5 claws A [3] and the claw B [4] of the Reader Upper Cover Unit.



4. Remove the Copyboard Glass [1].

CAUTION:

- Do not lose the 2 spacers [1] of the Contact Image Sensor Unit.
- Do not touch the document reading part [A] of the Contact Image Sensor Unit.



● Removing the Contact Image Sensor (SADF Model)



■ Preparation

● Duplex Model

1. Remove the Left Cover (Duplex Model) “[Removing the Left Cover \(Duplex Model\)](#)” on page 162.
2. Remove the SADF Unit + Reader Unit “[Removing the SADF Unit + Reader Unit.](#)” on page 119.
3. Separate the SADF Unit and the Reader Unit “[Disconnecting the SADF Unit and the Reader Unit](#)” on page 122.
4. Remove the Copyboard Glass (SADF Model) “[Removing the Copyboard Glass \(SADF Model\)](#)” on page 139.

● Simplex Model


1. Remove the Left Cover (Simplex Model) “[Removing the Left Cover \(Simplex Model\)](#)” on page 244.
2. Remove the SADF Unit + Reader Unit “[Removing the SADF Unit + Reader Unit.](#)” on page 119.
3. Separate the SADF Unit and the Reader Unit “[Disconnecting the SADF Unit and the Reader Unit](#)” on page 122.

4. Remove the Copyboard Glass (SADF Model) “Removing the Copyboard Glass (SADF Model)” on page 139.


■ Procedure

CAUTION:

- Do not lose the 2 spacers [1] of the Contact Image Sensor Unit.
- Do not touch the document reading part [A] of the Contact Image Sensor Unit.




1. Move the Contact Image Sensor Unit [1].




2. Remove the 2 spacers [1] and the Flat Cable [2].

- 1 Guide [A]




3. Remove the Contact Image Sensor [1].


- 2 Shafts [2]

**CAUTION:**

If the Contact Image Sensor Unit comes off, be sure to put the tooth [1] of the belt in the groove [2] on the bottom of the Contact Image Sensor to install the unit.



● Removing the Flat Bed Motor Unit (SADF Model)



■ Preparation

● Duplex Model

1. Remove the Left Cover (Duplex Model) “[Removing the Left Cover \(Duplex Model\)](#)” on page 162.
2. Remove the SADF Unit + Reader Unit “[Removing the SADF Unit + Reader Unit.](#)” on page 119.
3. Separate the SADF Unit and the Reader Unit “[Disconnecting the SADF Unit and the Reader Unit](#)” on page 122.
4. Remove the Copyboard Glass (SADF Model) “[Removing the Copyboard Glass \(SADF Model\)](#)” on page 139.

● Simplex Model


1. Remove the Left Cover (Simplex Model) “[Removing the Left Cover \(Simplex Model\)](#)” on page 244.

2. Remove the SADF Unit + Reader Unit “Removing the SADF Unit + Reader Unit.” on page 119.
3. Separate the SADF Unit and the Reader Unit “Disconnecting the SADF Unit and the Reader Unit” on page 122.
4. Remove the Copyboard Glass (SADF Model) “Removing the Copyboard Glass (SADF Model)” on page 139.


■ Procedure

CAUTION:

- Do not lose the 2 spacers [1] of the Contact Image Sensor Unit.
- Do not touch the document reading part [A] of the Contact Image Sensor Unit.





1. Move the Contact Image Sensor Unit [1].



2. Press the gear [1] to bend the belt [2], and remove the belt [2] from the gear [3].


CAUTION:

Grease is applied on the shaft [4] of the Contact Image Sensor, so be careful not to let the belt [2] come in contact with the shaft.




3. Remove the Guide Cover [1].

- 1 Claw [2]




4. Free the harness [1] and the Grounding Wire [2] from the hole [A] of the Reader Unit and the Harness Guide [B].




5. Remove the Flat Bed Motor Unit [1].

- 2 Screws [2]




CAUTION:

If the Contact Image Sensor Unit comes off, be sure to put the tooth [1] of the belt in the groove [2] on the bottom of the Contact Image Sensor to install the unit.



Original Exposure/Feed System (Copyboard Model)

Layout Drawing




| No. | Name | Reference | Remarks |
|-----|----------------------------------|---|---------|
| [1] | Copyboard Covert and Reader Unit | "Removing the Copyboard Cover + Reader Unit" on page 149 | |
| [2] | Copyboard Cover | "Removing the Copyboard Cover" on page 148 | |
| [3] | Copyboard Glass | "Removing the Copyboard Glass (Copyboard Model)" on page 152 | |
| [4] | Contact Image Sensor | "Removing the Contact Image Sensor (Copyboard Model)" on page 155 | |
| [5] | Flatbed Motor Unit | "Removing the Flat Bed Motor Unit (Copyboard Model)" on page 157 | |

Removing the Copyboard Cover



■ Procedure

1. Remove the Copyboard Cover [1].
 - 2 Claws [2]



● Removing the Copyboard Cover + Reader Unit



■ Preparation

● Duplex Model

1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)”](#) on page 162.


● Simplex Model

1. Remove the Left Cover (Simplex Model) [“Removing the Left Cover \(Simplex Model\)”](#) on page 244.

■ Procedure


1. Disconnect the terminal [1] and the 3 connectors [4] of the Grounding Wire, and free the Grounding Wire and the harness [5] from the Harness Guide [A].

- 1 Screw (black TP) [2]
- 1 Wire Saddle [3]



2. Free the 2 Flat Cables [1] from the Harness Guide [A].

- 4 Ferrite Cores [2]
- 4 Claws [3]




3. Remove the Copyboard Cover + Reader Unit [1].



- 2 Claws [2]

CAUTION:

- Be sure to install/remove the unit carefully so as not to damage the Flat Cable [3] and harness [4] with the [A] part.




- Be sure to place the unit so as not to damage the Flat Cable [3] and harness [4].




NOTE:

How to assemble the Reader Unit


Be sure to secure the 2 claws [1] of the Hinge Arm to the 2 hooks [2] of the Reader Unit.

**NOTE:**

The following shows how to route the harness.



● Removing the Copyboard Glass (Copyboard Model)



■ Preparation

1. Remove the Copyboard Cover “[Removing the Copyboard Cover](#)” on page 148.


■ Procedure

CAUTION:

- Be sure to place the removed Copyboard Glass on a cloth, etc. to avoid damaging the bottom sheet.
- When removing the Copyboard Glass, be careful not to touch the glass surface.
- If the surface becomes dirty, clean it with lint free paper.




1. Remove the 2 screws [1].



2. Remove the Copyboard Guide Holder [1].

- 1 Claw [2]
- 1 Hook [3]





3. Remove the Reader Upper Cover Unit [1].

- 2 Screws [2]
- 5 Claws A [3]
- 1 Claw B [4]

NOTE:



The following shows the 5 claws A [3] and the claw B [4] of the Reader Upper Cover Unit.



4. Remove the Copyboard Glass [1].

CAUTION:

- Do not lose the 2 spacers [1] of the Contact Image Sensor Unit.
- Do not touch the document reading part [A] of the Contact Image Sensor Unit.



● Removing the Contact Image Sensor (Copyboard Model)




■ Preparation

1. Remove the Copyboard Cover “[Removing the Copyboard Cover](#)” on page 148.
2. Remove the Copyboard Glass (Copyboard Model) “[Removing the Copyboard Glass \(Copyboard Model\)](#)” on page 152.


■ Procedure

CAUTION:

- Do not lose the 2 spacers [1] of the Contact Image Sensor Unit.
- Do not touch the document reading part [A] of the Contact Image Sensor Unit.




1. Move the Contact Image Sensor Unit [1].




2. Remove the 2 spacers [1] and the Flat Cable [2].

- 1 Guide [A]




3. Remove the Contact Image Sensor [1].


- 2 Shafts [2]

**CAUTION:**

If the Contact Image Sensor Unit comes off, be sure to put the tooth [1] of the belt in the groove [2] on the bottom of the Contact Image Sensor to install the unit.



● Removing the Flat Bed Motor Unit (Copyboard Model)



■ Preparation

● Duplex Model

1. Remove the Left Cover (Duplex Model) “[Removing the Left Cover \(Duplex Model\)](#)” on page 162.
2. Removing the Copyboard Cover + Reader Unit “[Removing the Copyboard Cover + Reader Unit](#)” on page 149.
3. Remove the Copyboard Cover “[Removing the Copyboard Cover](#)” on page 148.
4. Remove the Copyboard Glass (Copyboard Model) “[Removing the Copyboard Glass \(Copyboard Model\)](#)” on page 152.


● Simplex Model

1. Remove the Left Cover (Simplex Model) “Removing the Left Cover (Simplex Model)” on page 244.
2. Removing the Copyboard Cover + Reader Unit “Removing the Copyboard Cover + Reader Unit” on page 149.
3. Remove the Copyboard Cover “Removing the Copyboard Cover” on page 148.
4. Remove the Copyboard Glass (Copyboard Model) “Removing the Copyboard Glass (Copyboard Model)” on page 152.


■ Procedure

CAUTION:

- Do not lose the 2 spacers [1] of the Contact Image Sensor Unit.
- Do not touch the document reading part [A] of the Contact Image Sensor Unit.





1. Move the Contact Image Sensor Unit [1].



2. Press the gear [1] to bend the belt [2], and remove the belt [2] from the gear [3].


CAUTION:

Grease is applied on the shaft [4] of the Contact Image Sensor, so be careful not to let the belt [2] come in contact with the shaft.




3. Remove the Guide Cover [1].

- 1 Claw [2]




4. Free the harness [1] and the Grounding Wire [2] from the hole [A] of the Reader Unit and the Harness Guide [B].




5. Remove the Flat Bed Motor Unit [1].

- 2 Screws [2]



CAUTION:


If the Contact Image Sensor Unit comes off, be sure to put the tooth [1] of the belt in the groove [2] on the bottom of the Contact Image Sensor to install the unit.



External Cover/Internal System (Duplex Model)


Layout Drawing

■ Front Side



| No. | Name | Reference | Remarks |
|------|-------------------------------------|--|---------|
| [1] | Control Panel Unit | "Removing the Control Panel Unit (Duplex Model)" on page 173 | - |
| [2] | Delivery Auxiliary Tray | | - |
| [3] | Pickup Tray | | - |
| [4] | Trailing Edge Paper Guides | | - |
| [5] | Pickup Tray Side Guide Plate | | - |
| [6] | Power Switch | | - |
| [7] | Upper Cover | "Removing the Upper Cover Unit (Duplex Model)" on page 167 | - |
| [8] | Delivery Tray | "Removing the Upper Cover Unit (Duplex Model)" on page 167 | - |
| [9] | Front Cover Unit | "Removing the Front Cover Unit (Duplex Model)" on page 166 | - |
| [10] | Multi-Purpose Tray | | - |
| [11] | Tray Cover | | - |
| [12] | Multi-Purpose Tray Side Guide Plate | | - |

■ Rear Side



| No. | Name | Reference | Remarks |
|------|------------------------|---|----------------|
| [13] | Left Cover | “Removing the Left Cover (Duplex Model)” on page 162 | - |
| [14] | Hinge Face Cover | | - |
| [15] | Duplex Feed Guide Unit | “Removing the Duplex Feed Guide Unit. (Duplex Model)” on page 169 | - |
| [16] | Right Cover | “Removing the Right Cover (Duplex Model)” on page 164 | - |
| [17] | USB Device Port | | - |
| [18] | LAN Port | | Model with NET |
| [19] | External Device Jack | | Model with FAX |
| [20] | Telephone Line Jack | | Model with FAX |
| [21] | Power Supply Cord Slot | | - |


● Removing the Left Cover (Duplex Model)




■ Procedure

NOTE:


The following shows the 5 claws [1] and 3 hooks [2] of the Left Cover.



1. Open the Rear Cover [1], and remove the screw (black TP) [2].



2. Release the 2 claws [1] at the rear side and the claw [2] at the lower side.




3. Depending on the model, perform one of the following operation.

1. Open the DADF Unit + Reader Unit [1] (DADF Model).
2. Open the SADF Unit + Reader Unit [1] (SADF Model).
3. Open the Copyboard Cover + Reader Unit [1] (Copyboard Model).



4. Release the 2 claws [1] at the upper side and remove the Left Cover [3] while releasing the 3 hooks [2].




● Removing the Right Cover (Duplex Model)




■ Procedure

NOTE:


The following shows the 5 claws [1] and 3 hooks [2] of the Right Cover.



1. Open the Rear Cover [1], and remove the screw (black TP) [2].



2. Release the 2 claws [1] at the rear side and the claw [2] at the lower side.




3. Depending on the model, perform one of the following operation.


1. Open the DADF Unit + Reader Unit [1] (DADF Model).
2. Open the SADF Unit + Reader Unit [1] (SADF Model).
3. Open the Copyboard Cover + Reader Unit [1] (Copyboard Model).



4. Release the 2 claws [1] at the upper side and remove the Left Cover [3] while releasing the 3 hooks [2].



● Removing the Front Cover Unit (Duplex Model)




■ Preparation

1. Remove the Left Cover (Duplex Model) “[Removing the Left Cover \(Duplex Model\)](#)” on page 162.
2. Remove the Right Cover (Duplex Model) “[Removing the Right Cover \(Duplex Model\)](#)” on page 164.

■ Procedure

1. Remove the Front Cover Unit [1].

- 1 Connector [2]
- 2 Bosses [3]
- 2 Claws [4]



● Removing the Upper Cover Unit (Duplex Model)



■ Preparation



1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)”](#) on page 162.
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) [“Removing the DADF Unit + Reader Unit”](#) on page 89.
 2. Remove the SADF Unit + Reader Unit (SADF Model) [“Removing the SADF Unit + Reader Unit.”](#) on page 119.
 3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) [“Removing the Copyboard Cover + Reader Unit”](#) on page 149.
3. Remove the Right Cover (Duplex Model) [“Removing the Right Cover \(Duplex Model\)”](#) on page 164.
4. Remove the Front Cover Unit (Duplex Model) [“Removing the Front Cover Unit \(Duplex Model\)”](#) on page 166.

■ Procedure

1. Open the Delivery Tray [1].
2. Remove the Cartridge Arm [2].


3. Remove the 2 Fixing Pressure Arms [3].**CAUTION:**

Be careful not to lose the Cartridge Arm [2] and the 2 Fixing Pressure Arms [3].

**4. Remove the Delivery Tray [1].**


5. Remove the Upper Cover Unit [1].

- 4 Screws (black TP) [2]

**NOTE:**

How to assemble the Delivery Tray

1. Pass the Cartridge Arm [1] through the hole [A] of the Upper Cover Unit.
2. Install the Cartridge Arm [1] and the 2 Fixing Pressure Arms [2] to the Delivery Tray [3].



● Removing the Duplex Feed Guide Unit. (Duplex Model)



■ Preparation


1. Remove the Left Cover (Duplex Model) “[Removing the Left Cover \(Duplex Model\)](#)” on page 162.
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) “[Removing the DADF Unit + Reader Unit](#)” on page 89.

2. Remove the SADF Unit + Reader Unit (SADF Model) [“Removing the SADF Unit + Reader Unit.”](#) on page 119.
3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) [“Removing the Copyboard Cover + Reader Unit”](#) on page 149.
3. Remove the Right Cover (Duplex Model) [“Removing the Right Cover \(Duplex Model\)”](#) on page 164.
4. Remove the Front Cover Unit (Duplex Model) [“Removing the Front Cover Unit \(Duplex Model\)”](#) on page 166.
5. Remove the Upper Cover Unit (Duplex Model) [“Removing the Upper Cover Unit \(Duplex Model\)”](#) on page 167.


■ Procedure

1. Remove the Duplex Guide [1].

- 2 Claws [2]




2. Remove the 2 screws (TP) [1] and the 2 screws (tapping) [2] using a stubby screwdriver.



3. Close the Rear Cover [1].


4. Remove the Duplex Feed Guide Unit [2].

- 1 Claw [3]
- 2 Hooks [4]



Controller System (Duplex Model)

Layout Drawing



| No. | Name | Reference | Remarks |
|------|---|---|---------------------|
| [1] | Main Motor | "Removing the Main Motor (Duplex Model)" on page 174 | |
| [2] | Main Fan | "Removing the Main Fan (Duplex Model)" on page 178 | |
| [3] | Speaker | "Removing the Speaker (Fax Model + Duplex Model)" on page 206 | Fax Model |
| [4] | Control Panel Unit | "Removing the Control Panel Unit (Duplex Model)" on page 173 | |
| [5] | Toner Sensor and Multi Pickup Sensor Unit | "Removing the Toner Sensor and Multi Pickup Sensor Unit (Fax Model + Duplex Model)" on page 204 | Fax Model |
| [6] | Wireless LAN PCB | "Removing the Wireless LAN PCB (Wifi Model + Duplex Model)" on page 195 | Wifi Model |
| [7] | FAX NCU PCB | "Removing the FAX NCU PCB (Fax Model 120V/230V) (Duplex Model)" on page 194 | Fax Model 120V/230V |
| [8] | Main Controller PCB | "Removing the Main Controller PCB (Duplex Model)" on page 191 | |
| [9] | Engine Controller PCB | "Removing the Engine Controller PCB (Duplex Model)" on page 186 | |
| [10] | Edge Left Cooling Fan | "Removing the Edge Left Cooling Fan (Duplex Model)" on page 182 | |
| [11] | Paper Leading Edge Sensor PCB | "Removing the Paper Leading Edge Sensor PCB (Duplex Model)" on page 196 | |
| [12] | Fixing Delivery/Paper Width Sensor PCB | "Removing the Fixing Delivery/Paper Width Sensor PCB (Duplex Model)" on page 200 | |

| No. | Name | Reference | Remarks |
|------|------------------------|--|---------|
| [13] | Edge Right Cooling Fan | "Removing the Edge Right Cooling Fan (Duplex Model)" on page 184 | |

● Removing the Control Panel Unit (Duplex Model)




■ Procedure


1. Depending on the model, perform one of the following operation.

1. Open the DADF Unit + Reader Unit [1] (DADF Model).
2. Open the SADF Unit + Reader Unit [1] (SADF Model).
3. Open the Copyboard Cover + Reader Unit [1] (Copyboard Model).

2. Lift the Control Panel Unit [2].




3. Remove the 4 Screws [1].




4. Depending on the model, perform one of the following operation.

1. Close the Reader Unit [1], and open the DADF Unit [2] (DADF Model).
2. Close the Reader Unit [1], and open the SADF Unit [2] (SADF Model).
3. Close the Reader Unit [1], and open the Copyboard Unit [2] (Copyboard Model).



5. Remove the Control Panel Unit [1].

- 6 Claws [2]
- 1 Flat Cable [3]



● Removing the Main Motor (Duplex Model)



■ Preparation


1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)”](#) on page 162.
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) [“Removing the DADF Unit + Reader Unit”](#) on page 89.
 2. Remove the SADF Unit + Reader Unit (SADF Model) [“Removing the SADF Unit + Reader Unit.”](#) on page 119.
 3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) [“Removing the Copyboard Cover + Reader Unit”](#) on page 149.
3. Remove the Right Cover (Duplex Model) [“Removing the Right Cover \(Duplex Model\)”](#) on page 164.

4. Remove the Front Cover Unit (Duplex Model) “Removing the Front Cover Unit (Duplex Model)” on page 166.
5. Remove the Upper Cover Unit (Duplex Model) “Removing the Upper Cover Unit (Duplex Model)” on page 167.

■ Procedure

1. Remove the Scanner Cover [1].


- 2 Screws (black TP) [2]




NOTE:

How to assemble the Scanner Cover

1. Be sure to pass the Shutter Open/Close Lever [3] through the hole [A] of the Scanner Cover.




2. Be sure that the Shutter Open/Close Lever [3] can move vertically.




2. Remove the Motor Driver PCB [1].


- 3 Connectors [2]
- 2 Claws [3]
- 1 Hook [4]

**3. Free the harness [1] from the Harness Guide [A].****4. Remove the Duplex Relay PCB [2].**

- 1 Claw [3]
- 1 Hook [4]


5. Free the harness [5] from the Harness Guide [B].**6. Free the Motor Harness [1] from the Harness Guide [A].****7. Remove the Motor Guide [2].**

- 1 Screw [3]
- 1 Hook [4]




8. Remove the Tension Unit [1].

- 1 Screw [2]



9. Remove the Main Motor [1].

- 2 Screws (with plain washer) [2]




NOTE:


How to assemble the Main Motor

Be sure to assemble it with the harness [1] routed upwards.

(Otherwise, the connector of the Speaker Harness cannot reach the Motor Driver PCB.)



Removing the Main Fan (Duplex Model)




■ Preparation

1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)”](#) on page 162.
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) [“Removing the DADF Unit + Reader Unit”](#) on page 89.
 2. Remove the SADF Unit + Reader Unit (SADF Model) [“Removing the SADF Unit + Reader Unit.”](#) on page 119.
 3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) [“Removing the Copyboard Cover + Reader Unit”](#) on page 149.
3. Remove the Right Cover (Duplex Model) [“Removing the Right Cover \(Duplex Model\)”](#) on page 164.
4. Remove the Front Cover Unit (Duplex Model) [“Removing the Front Cover Unit \(Duplex Model\)”](#) on page 166.
5. Remove the Upper Cover Unit (Duplex Model) [“Removing the Upper Cover Unit \(Duplex Model\)”](#) on page 167.

■ Procedure

1. Remove the Scanner Cover [1].


- 2 Screws (black TP) [2]




NOTE:

How to assemble the Scanner Cover

1. Be sure to pass the Shutter Open/Close Lever [3] through the hole [A] of the Scanner Cover.




2. Be sure that the Shutter Open/Close Lever [3] can move vertically.



2. Free the Fan Harness [1] from the Harness Guide [A].


- 1 Connector [2]

3. Pass the Fan Harness [1] through the hole [B] of the Right Plate to the outside.



4. Free the harness [1] from the guide [A], and remove the Main Fan [2].



- 2 Claws [3]




NOTE:

How to assemble the Main Fan

Assemble it by aligning the arrow [1] of the Fan Guide with the arrow [2] of the fan and installing the harness [3] to the upper right side.



● Removing the Edge Left Cooling Fan (Duplex Model)




■ Preparation

1. Remove the Left Cover (Duplex Model) “Removing the Left Cover (Duplex Model)” on page 162.
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) “Removing the DADF Unit + Reader Unit” on page 89.
 2. Remove the SADF Unit + Reader Unit (SADF Model) “Removing the SADF Unit + Reader Unit.” on page 119.
 3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) “Removing the Copyboard Cover + Reader Unit” on page 149.
3. Remove the Right Cover (Duplex Model) “Removing the Right Cover (Duplex Model)” on page 164.
4. Remove the Front Cover Unit (Duplex Model) “Removing the Front Cover Unit (Duplex Model)” on page 166.
5. Remove the Upper Cover Unit (Duplex Model) “Removing the Upper Cover Unit (Duplex Model)” on page 167.
6. Remove the Duplex Feed Guide Unit (Duplex Model) “Removing the Duplex Feed Guide Unit. (Duplex Model)” on page 169.


■ Procedure

1. Remove the Front Fixing Reinforcing Plate [1].
 - 2 Screws (black TP) [2]



2. Remove the Edge Left Cooling Fan [1].



- 1 Left Fan Earth Spring [2]
- 1 Connector [3]
- 1 Harness Guide [A]
- 2 Claws [4]




NOTE:

How to assemble the Edge Left Cooling Fan

Assemble it by aligning the arrow [1] of the fan with the arrow [2] of the Fan Holder.



Removing the Edge Right Cooling Fan (Duplex Model)




■ Preparation

1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)”](#) on page 162.
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) [“Removing the DADF Unit + Reader Unit”](#) on page 89.
 2. Remove the SADF Unit + Reader Unit (SADF Model) [“Removing the SADF Unit + Reader Unit.”](#) on page 119.
 3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) [“Removing the Copyboard Cover + Reader Unit”](#) on page 149.
3. Remove the Right Cover (Duplex Model) [“Removing the Right Cover \(Duplex Model\)”](#) on page 164.
4. Remove the Front Cover Unit (Duplex Model) [“Removing the Front Cover Unit \(Duplex Model\)”](#) on page 166.
5. Remove the Upper Cover Unit (Duplex Model) [“Removing the Upper Cover Unit \(Duplex Model\)”](#) on page 167.
6. Remove the Duplex Feed Guide Unit (Duplex Model) [“Removing the Duplex Feed Guide Unit. \(Duplex Model\)”](#) on page 169.

■ Procedure

1. Remove the Edge Right Cooling Fan [1].



- 1 Right Fan Earth Spring [2]
- 1 Connector [3]
- 1 Harness Guide [A]
- 2 Claws [4]




NOTE:

How to assemble the Edge Right Cooling Fan

Assemble it by aligning the arrow [1] of the fan with the arrow [2] of the Fan Holder.



● Removing the Engine Controller PCB (Duplex Model)




■ Preparation

1. Remove the Left Cover (Duplex Model) “Removing the Left Cover (Duplex Model)” on page 162.
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) “Removing the DADF Unit + Reader Unit” on page 89.
 2. Remove the SADF Unit + Reader Unit (SADF Model) “Removing the SADF Unit + Reader Unit.” on page 119.
 3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) “Removing the Copyboard Cover + Reader Unit” on page 149.
3. Remove the Right Cover (Duplex Model) “Removing the Right Cover (Duplex Model)” on page 164.
4. Remove the Front Cover Unit (Duplex Model) “Removing the Front Cover Unit (Duplex Model)” on page 166.
5. Remove the Upper Cover Unit (Duplex Model) “Removing the Upper Cover Unit (Duplex Model)” on page 167.
6. Remove the Duplex Feed Guide Unit (Duplex Model) “Removing the Duplex Feed Guide Unit. (Duplex Model)” on page 169.
7. Remove the Main Controller PCB (Duplex Model) “Removing the Main Motor (Duplex Model)” on page 174.
8. Remove the FAX NCU PCB (FAX Model 120/230V) (Duplex Model) “Removing the FAX NCU PCB (Fax Model 120V/230V) (Duplex Model)” on page 194.
9. Remove the Edge Left Cooling Fan (Duplex Model) “Removing the Edge Left Cooling Fan (Duplex Model)” on page 182.


■ Procedure

1. Remove the Wireless LAN Unit [1] (Wifi Model).
 - 1 Screw (black TP) [2]
 - 2 Hooks [3]



2. Remove the Main Controller PCB Installation Plate [1].


- 1 Relay Connector [2]
- Harness Guide [A]
- 1 Wire Saddle [3]
- 4 Screws (with washer) [4]
- 2 Screws (black TP) [5]



3. Free the harness [1] from the Harness Guide [A].


4. Remove the Edge Left Cooling Fan Holder [2].

- 1 Screw [3]




5. Free the harness [1] from the Harness Guide [A].

- 1 Terminal [2]




CAUTION:


Be sure that the terminal [2] is in contact with the Contact Spring [3].




6. Remove the Harness Retaining Spring [1] from the 2 hooks [2].



7. Remove the 3 Flat Cables [2], the 6 connectors [3], and the connector [4] (Fax Model) installed on the Engine Controller PCB [1].




8. Free the harness [1] from the Harness Guide [A].




9. Remove the Engine Controller PCB [1].

- 2 Screws (with plain washer) [2]
- 1 Screw (with toothed lock washer) [3]
- 1 Screw (black TP) [4]
- 2 Hooks [5]


**NOTE:**

How to assemble the Engine Controller PCB

- Put the Switchboard [2] in the lower part of the Switch Arm [1], and hook the Engine Controller PCB on the hook [3].




- Be sure that the Switch Arm [1] can move vertically.




CAUTION:

Be careful not to install the Flat Cable [1] in the wrong direction.



● Removing the Main Controller PCB (Duplex Model)



■ Before Replacing

1. Before starting the replacement, output a status print.

After replacing the Main Controller, the serial number of the host machine needs to be written to the Main Controller.

2. Ask the user to perform the following operations if possible.


- Ask the user to print the user data list.
[Menu] > [Output Report] > [Output Rprt.] > [User Data List]
- Ask the user to save the address book from remote UI.
 1. Start remote UI and log in in administrator mode.
 2. Click [Settings/Registration] > [Import/Export] > [Export] > [Start Exporting].
 3. Follow the instructions on the screen to specify the location to save the address book.

■ Preparation

1. Remove the Left Cover (Duplex Model) "[Removing the Left Cover \(Duplex Model\)](#)" on page 162.


■ Procedure

1. Disconnect all the Flat Cables [1] and connectors [2] installed on the Main Controller PCB.




2. Remove the Main Controller PCB [1].

- 1 Screw [2]
- 5 Screws (black TP) [3]

**NOTE:**

The layout of the connectors on the Main Controller PCB is shown below.




| J No. | J No. | Symbol | Name | Remarks |
|-------|-------|--------|------------------------|------------|
| J1 | J401 | UNIT14 | Control Panel PCB | |
| J2 | J1601 | CIS | CIS Sensor | |
| J3 | J902 | UNIT2 | Engine Controller PCB | |
| J4 | J1 | UNIT13 | Wireless LAN PCB | WIFI Model |
| J6 | - | - | - | |
| J7 | J1402 | PS2 | Original Sensor | DADF Model |
| J7 | J1403 | PS3 | Original Edge Sensor | DADF Model |
| J7 | J1406 | PS4 | Original Sensor | SADF Model |
| J7 | J1407 | PS5 | Original Edge Sensor | SADF Model |
| J8 | - | SL3 | DADF Solenoid Unit | DADF Model |
| J10 | J102 | FM2 | Edge Right Cooling Fan | |
| J10 | J103 | FM3 | Edge Left Cooling Fan | |
| J11 | - | M3 | Flatbed Motor Unit | |
| J12 | J1401 | M4 | DADF Motor Unit | DADF Model |
| J12 | J1401 | M5 | SADF Motor Unit | SADF Model |
| J14 | - | - | USB | |
| J15 | - | PS6 | Tray Sensor | |
| J22 | - | - | - | |
| J600 | - | - | LAN | |
| J901 | J1204 | UNIT16 | FAX NCU PCB | FAX Model |
| J903 | J1201 | UNIT16 | FAX NCU PCB | FAX Model |
| J904 | - | SP1 | Speaker | FAX Model |

■ After Replacing

1. After replacing the PCB, enter the serial number in "Location " of System Management Settings from remote UI or local UI, and confirm the serial number.
2. Check that OK is displayed in COPIER > OPTION > SERIAL > SN-MAIN.
 - For the detailed procedure, refer to the chapter on service mode.
3. **COPIER > OPTION > BODY > LOCALE**
 To set country group.
 - 1: Japan
 - 2: North America
 - 3: Korea
 - 4: China
 - 5: Taiwan
 - 6: Europe
 - 7: Asia
 Setting range: 1 - 7 (Service part default value: 2)
4. **Execute the following service mode to enable this setting.**
 COPIER > FUNCTION > CLEAR > ALL
5. **If the user has printed the user data list and saved the address book before the replacement, ask the user to return the settings back to the original values.**
 - Ask the user to load the address book from remote UI.
 1. Start remote UI and log in in administrator mode.
 2. [Settings/Registration] > [Import/Export] > [Import]
 3. Select the address book file to be imported, and click [Start Importing].
 4. Click [OK].

● Removing the FAX NCU PCB (Fax Model 120V/230V) (Duplex Model)




■ Preparation

1. Remove the Left Cover (Duplex Model) "[Removing the Left Cover \(Duplex Model\)](#)" on page 162.


■ Procedure

1. Remove the FAX NCU PCB [1].

- 1 Flat Cable [2]
- 1 Connector [3]
- 3 Screws [4]



● Removing the Wirelss LAN PCB (Wifi Model + Duplex Model)




■ Preparation

1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)”](#) on page 162.


■ Procedure

1. Remove the Wireless LAN PCB [1].

- 1 Flat Cable [2]
- 1 Screw (black TP) [3]



● Removing the Paper Leading Edge Sensor PCB (Duplex Model)




■ Preparation

1. Remove the Left Cover (Duplex Model) “Removing the Left Cover (Duplex Model)” on page 162.
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) “Removing the DADF Unit + Reader Unit” on page 89.
 2. Remove the SADF Unit + Reader Unit (SADF Model) “Removing the SADF Unit + Reader Unit.” on page 119.
 3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) “Removing the Copyboard Cover + Reader Unit” on page 149.
3. Remove the Right Cover (Duplex Model) “Removing the Right Cover (Duplex Model)” on page 164.
4. Remove the Front Cover Unit (Duplex Model) “Removing the Front Cover Unit (Duplex Model)” on page 166.
5. Remove the Upper Cover Unit (Duplex Model) “Removing the Upper Cover Unit (Duplex Model)” on page 167.
6. Remove the Duplex Feed Guide Unit (Duplex Model) “Removing the Duplex Feed Guide Unit. (Duplex Model)” on page 169.
7. Remove the Main Controller PCB (Duplex Model) “Removing the Main Motor (Duplex Model)” on page 174.
8. Remove the FAX NCU PCB (FAX Model 120/230V) (Duplex Model) “Removing the FAX NCU PCB (Fax Model 120V/230V) (Duplex Model)” on page 194.
9. Remove the Edge Left Cooling Fan (Duplex Model) “Removing the Edge Left Cooling Fan (Duplex Model)” on page 182.


■ Procedure

1. Remove the Wireless LAN Unit [1] (Wifi Model).
 - 1 Screw (black TP) [2]
 - 2 Hooks [3]



2. Remove the Main Controller PCB Installation Plate [1].


- 1 Relay Connector [2]
- Harness Guide [A]
- 1 Wire Saddle [3]
- 4 Screws (with washer) [4]
- 2 Screws (black TP) [5]



NOTE:

The Front Fixing Reinforcing Plate [1] should be removed before removing the Edge Left Cooling Fan Holder.


- 2 Screws (black TP) [2]



3. Free the harness [1] from the Harness Guide [A].


4. Remove the Edge Left Cooling Fan Holder [2].

- 1 Screw [3]




5. Free the harness [1] from the Harness Guide [A].

- 1 Terminal [2]




CAUTION:


Be sure that the terminal [2] is in contact with the Contact Spring [3].



6. Remove the Harness Retaining Spring [1] from the 2 hooks [2].




7. Disconnect the 4 connectors [1].



8. Free the harness [1] from the Harness Guide [A].


9. Remove the Paper Leading Edge Sensor PCB [2].

- 2 Claws [3]




NOTE:

The following shows how to route the harness.



Removing the Fixing Delivery/Paper Width Sensor PCB (Duplex Model)




■ Preparation

1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)”](#) on page 162.
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) [“Removing the DADF Unit + Reader Unit”](#) on page 89.
 2. Remove the SADF Unit + Reader Unit (SADF Model) [“Removing the SADF Unit + Reader Unit.”](#) on page 119.
 3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) [“Removing the Copyboard Cover + Reader Unit”](#) on page 149.
3. Remove the Right Cover (Duplex Model) [“Removing the Right Cover \(Duplex Model\)”](#) on page 164.
4. Remove the Front Cover Unit (Duplex Model) [“Removing the Front Cover Unit \(Duplex Model\)”](#) on page 166.
5. Remove the Upper Cover Unit (Duplex Model) [“Removing the Upper Cover Unit \(Duplex Model\)”](#) on page 167.
6. Remove the Duplex Feed Guide Unit (Duplex Model) [“Removing the Duplex Feed Guide Unit. \(Duplex Model\)”](#) on page 169.
7. Remove the Main Controller PCB (Duplex Model) [“Removing the Main Motor \(Duplex Model\)”](#) on page 174.
8. Remove the FAX NCU PCB (FAX Model 120/230V) (Duplex Model) [“Removing the FAX NCU PCB \(Fax Model 120V/ 230V\) \(Duplex Model\)”](#) on page 194.
9. Remove the Edge Left Cooling Fan (Duplex Model) [“Removing the Edge Left Cooling Fan \(Duplex Model\)”](#) on page 182.


■ Procedure

1. Remove the Wireless LAN Unit [1] (Wifi Model).
 - 1 Screw (black TP) [2]
 - 2 Hooks [3]



2. Remove the Main Controller PCB Installation Plate [1].


- 1 Relay Connector [2]
- Harness Guide [A]
- 1 Wire Saddle [3]
- 4 Screws (with washer) [4]
- 2 Screws (black TP) [5]



NOTE:

The Front Fixing Reinforcing Plate [1] should be removed before removing the Edge Left Cooling Fan Holder.


- 2 Screws (black TP) [2]



3. Free the harness [1] from the Harness Guide [A].


4. Remove the Edge Left Cooling Fan Holder [2].

- 1 Screw [3]




5. Free the harness [1] from the Harness Guide [A].

- 1 Terminal [2]




CAUTION:


Be sure that the terminal [2] is in contact with the Contact Spring [3].



6. Remove the Harness Retaining Spring [1] from the 2 hooks [2].




7. Disconnect the 4 connectors [1].




8. Free the harness [1] from the Harness Guide [A].

9. Remove the Fixing Delivery/Paper Width Sensor PCB [2].


- 1 Connector [3]
- 2 Claws [4]

**NOTE:**

The following shows how to route the harness.



● Removing the Toner Sensor and Multi Pickup Sensor Unit (Fax Model + Duplex Model)




■ Preparation

1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)”](#) on page 162.
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) [“Removing the DADF Unit + Reader Unit”](#) on page 89.
 2. Remove the SADF Unit + Reader Unit (SADF Model) [“Removing the SADF Unit + Reader Unit.”](#) on page 119.
 3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) [“Removing the Copyboard Cover + Reader Unit”](#) on page 149.
3. Remove the Right Cover (Duplex Model) [“Removing the Right Cover \(Duplex Model\)”](#) on page 164.
4. Remove the Front Cover Unit (Duplex Model) [“Removing the Front Cover Unit \(Duplex Model\)”](#) on page 166.
5. Remove the Upper Cover Unit (Duplex Model) [“Removing the Upper Cover Unit \(Duplex Model\)”](#) on page 167.

■ Procedure


1. Remove the Wireless LAN Unit [1] (Wifi Model).

- 1 Flat Cable [2]
- 1 Screw (black TP) [3]
- 2 Hooks [4]




2. Remove the Scanner Cover [1].

- 2 Screws (black TP) [2]


**NOTE:**

How to assemble the Scanner Cover

1. Be sure to pass the Shutter Open/Close Lever [3] through the hole [A] of the Scanner Cover.




2. Be sure that the Shutter Open/Close Lever [3] can move vertically.




3. Pass the harness [1] through the hole [A] of the Left Side Plate to the inside.

- 1 Connector [2]
- 1 Connector [3] (Fax Model)




4. Remove the Multi Pickup Sensor Unit [1].

- 1 Wire Saddle [2]
- 1 Claw [3]
- 3 Hooks [4]



● Removing the Speaker (Fax Model + Duplex Model)




■ Preparation

1. Remove the Left Cover (Duplex Model) “Removing the Left Cover (Duplex Model)” on page 162.
2. Remove the Right Cover (Duplex Model) “Removing the Right Cover (Duplex Model)” on page 164.
3. Remove the Front Cover Unit (Duplex Model) “Removing the Front Cover Unit (Duplex Model)” on page 166.


■ Procedure

1. Disconnect the Speaker Harness [1], and pass it through the hole [A] of the Left Side Plate to the inside.

- 1 Connector [2]
- 1 Wire Saddle [3]




2. Free the Speaker Harness [1] from the Harness Guide [A], and pass it through the hole [B] of the Right Plate to the outside.



3. Remove the speaker [1].

- 1 Screw [2]
- 2 Hook[3]




NOTE:

How to assemble the speaker


Be sure to assemble it with the harness [1] routed upwards.

(Otherwise, the connector of the Speaker Harness cannot reach the Main Controller.)



Laser Exposure System (Duplex Model)

Layout Drawing



| No. | Name | Reference | Remarks |
|-----|--------------------|--|---------|
| [1] | Laser Scanner Unit | "Removing the Laser Scanner Unit (Duplex Model)" on page 209 | |

Removing the Laser Scanner Unit (Duplex Model)



■ Preparation

1. Remove the Left Cover (Duplex Model) "[Removing the Left Cover \(Duplex Model\)](#)" on page 162.
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) "[Removing the DADF Unit + Reader Unit](#)" on page 89.
 2. Remove the SADF Unit + Reader Unit (SADF Model) "[Removing the SADF Unit + Reader Unit.](#)" on page 119.
 3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) "[Removing the Copyboard Cover + Reader Unit](#)" on page 149.
3. Remove the Right Cover (Duplex Model) "[Removing the Right Cover \(Duplex Model\)](#)" on page 164.
4. Remove the Front Cover Unit (Duplex Model) "[Removing the Front Cover Unit \(Duplex Model\)](#)" on page 166.
5. Remove the Upper Cover Unit (Duplex Model) "[Removing the Upper Cover Unit \(Duplex Model\)](#)" on page 167.


■ Procedure

CAUTION:

Do not disassemble the Laser Scanner Unit because it requires adjustment.


1. Remove the Scanner Cover [1].

- 2 Screws (black TP) [2]


**NOTE:**

How to assemble the Scanner Cover

1. Be sure to pass the Shutter Open/Close Lever [3] through the hole [A] of the Scanner Cover.



2. Be sure that the Shutter Open/Close Lever [3] can move vertically.

**2. Move the Laser Scanner Unit [1].**

- 4 Screws [2]

3. Remove the Laser Scanner Unit [1].

- 1 Flat Cable [3]
- 1 Sponge [4]
- 1 Connector [5]





Image Formation System (Duplex Model)

Layout Drawing



| No. | Name | Reference | Remarks |
|-----|-----------------|---|---------|
| [1] | Transfer Roller | "Removing the Transfer Roller (Duplex Model)" on page 212 | |

Removing the Transfer Roller (Duplex Model)



■ Procedure

CAUTION:


Do not touch the surface of the Transfer Roller.

1. Depending on the model, perform one of the following operation.


1. Open the DADF Unit + Reader Unit [1] and Delivery Tray [2] (DADF Model).
2. Open the SADF Unit + Reader Unit [1] and Delivery Tray [2] (SADF Model).
3. Open the Copyboard Cover + Reader Unit [1] and Delivery Tray [2] (Copyboard Model).

2. Remove the bushing [3] of the Transfer Roller.

- 2 Claws [4]




3. Hold both ends of the shaft [1] of the Transfer Roller, and remove the Transfer Roller [2].



CAUTION:


Be sure that the bushing [1] is facing the correct direction when assembling.



NOTE:


How to assemble the Transfer Roller

Be sure to assemble it by aligning the spring [1] with the boss [2].




Fixing System (Duplex Model)

Layout Drawing



| No. | Name | Reference | Remarks |
|-----|-------------|---|---------|
| [1] | Fixing Unit | "Removing the Fixing Assembly (Duplex Model)" on page 215 | |

Removing the Fixing Assembly (Duplex Model)



■ Preparation

1. Remove the Left Cover (Duplex Model) "[Removing the Left Cover \(Duplex Model\)](#)" on page 162.
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) "[Removing the DADF Unit + Reader Unit](#)" on page 89.
 2. Remove the SADF Unit + Reader Unit (SADF Model) "[Removing the SADF Unit + Reader Unit.](#)" on page 119.
 3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) "[Removing the Copyboard Cover + Reader Unit](#)" on page 149.
3. Remove the Right Cover (Duplex Model) "[Removing the Right Cover \(Duplex Model\)](#)" on page 164.
4. Remove the Front Cover Unit (Duplex Model) "[Removing the Front Cover Unit \(Duplex Model\)](#)" on page 166.
5. Remove the Upper Cover Unit (Duplex Model) "[Removing the Upper Cover Unit \(Duplex Model\)](#)" on page 167.
6. Remove the Duplex Feed Guide Unit (Duplex Model) "[Removing the Duplex Feed Guide Unit. \(Duplex Model\)](#)" on page 169.
7. Remove the Main Controller PCB (Duplex Model) "[Removing the Main Motor \(Duplex Model\)](#)" on page 174.
8. Remove the FAX NCU PCB (FAX Model 120/230V) (Duplex Model) "[Removing the FAX NCU PCB \(Fax Model 120V/ 230V\) \(Duplex Model\)](#)" on page 194.
9. Remove the Edge Left Cooling Fan (Duplex Model) "[Removing the Edge Left Cooling Fan \(Duplex Model\)](#)" on page 182.

10. Remove the Edge Right Cooling Fan (Duplex Model) “Removing the Edge Right Cooling Fan (Duplex Model)” on page 184.


■ Procedure

CAUTION:

- Be sure to start work after the Fixing Assembly is cooled down enough.
- The Fixing Assembly right after printing may cause burn injury.
- Do not disassemble the Fixing Assembly because it requires adjustment.


1. Remove the Wireless LAN Unit [1] (Wifi Model).

- 1 Screw (black TP) [2]
- 2 Hooks [3]



2. Remove the Main Controller PCB Installation Plate [1].


- 1 Relay Connector [2]
- Harness Guide [A]
- 1 Wire Saddle [3]
- 4 Screws (with washer) [4]
- 2 Screws (black TP) [5]



NOTE:

The Front Fixing Reinforcing Plate [1] should be removed before removing the Edge Left Cooling Fan Holder.


- 2 Screws (black TP) [2]



3. Free the harness [1] from the Harness Guide [A].


4. Remove the Edge Left Cooling Fan Holder [2].

- 1 Screw [3]




5. Free the harness [1] from the Harness Guide [A].

- 1 Terminal [2]




CAUTION:


Be sure that the terminal [2] is in contact with the Contact Spring [3].



6. Remove the Harness Retaining Spring [1] from the 2 hooks [2].




7. Disconnect the 4 connectors [1].




8. Free the harness [1] from the Harness Guide [A].

9. Free the Fixing Harness [2] from the Harness Holder [3].





10. Remove the Harness Holder [1].

- 1 Claw [2]




11. Remove the Rear Reinforcing Plate [1].

- 2 Screws (black TP) [2]

**12. Remove the Shaft Support [1] of the Delivery Roller.**


13. Remove the Fixing Assembly [1].

- 3 Screws [2]


**NOTE:**

How to install the Fixing Harness

1. Wrap the Fixing Harness [2] around the protrusion [1] of the Harness Holder.
2. Pass it through the Harness Guide [A], and then connect the connector [3].


**NOTE:**

The following shows how to route the harness.




Pickup Feed System (Duplex Model)

Layout Drawing



| No. | Name | Reference | Remarks |
|-----|----------------------------|--|---------|
| [1] | Delivery Slave Roller Unit | “Removing the Delivery Slave Roller Unit (Duplex Model)” on page 234 | |
| [2] | Pickup Unit | “Removing the Pickup Unit (Duplex Model)” on page 222 | |
| [3] | Duplex Solenoid | “Removing the Duplex Solenoid (Duplex Model)” on page 240 | |
| [4] | Pickup Tray Unit | “Removing the Pickup Tray Unit (Duplex Model)” on page 229 | |
| [5] | Separation Pad | “Removing the Separation Pad (Duplex Model)” on page 233 | |
| [6] | Pickup Roller | “Removing the Pickup Roller (Duplex Model)” on page 231 | |
| [7] | Pickup Solenoid | “Removing the Pickup Solenoid (Duplex Model)” on page 235 | |

Removing the Pickup Unit (Duplex Model)



■ Preparation


1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)” on page 162.](#)
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) [“Removing the DADF Unit + Reader Unit” on page 89.](#)

2. Remove the SADF Unit + Reader Unit (SADF Model) “Removing the SADF Unit + Reader Unit.” on page 119.
3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) “Removing the Copyboard Cover + Reader Unit” on page 149.
3. Remove the Right Cover (Duplex Model) “Removing the Right Cover (Duplex Model)” on page 164.
4. Remove the Front Cover Unit (Duplex Model) “Removing the Front Cover Unit (Duplex Model)” on page 166.
5. Remove the Upper Cover Unit (Duplex Model) “Removing the Upper Cover Unit (Duplex Model)” on page 167.
6. Remove the Duplex Feed Guide Unit (Duplex Model) “Removing the Duplex Feed Guide Unit. (Duplex Model)” on page 169.
7. Remove the Main Controller PCB (Duplex Model) “Removing the Main Motor (Duplex Model)” on page 174.
8. Remove the FAX NCU PCB (FAX Model 120/230V) (Duplex Model) “Removing the FAX NCU PCB (Fax Model 120V/ 230V) (Duplex Model)” on page 194.
9. Remove the Edge Left Cooling Fan (Duplex Model) “Removing the Edge Left Cooling Fan (Duplex Model)” on page 182.
10. Remove the Separation Pad (Duplex Model) “Removing the Separation Pad (Duplex Model)” on page 233.

■ Procedure


1. Remove the Wireless LAN Unit [1] (Wifi Model).

- 1 Screw (black TP) [2]
- 2 Hooks [3]



2. Remove the Main Controller PCB Installation Plate [1].


- 1 Relay Connector [2]
- Harness Guide [A]
- 1 Wire Saddle [3]
- 4 Screws (with washer) [4]
- 2 Screws (black TP) [5]



NOTE:

The Front Fixing Reinforcing Plate [1] should be removed before removing the Edge Left Cooling Fan Holder.


- 2 Screws (black TP) [2]



3. Free the harness [1] from the Harness Guide [A].


4. Remove the Edge Left Cooling Fan Holder [2].

- 1 Screw [3]




5. Free the harness [1] from the Harness Guide [A].

- 1 Terminal [2]




CAUTION:


Be sure that the terminal [2] is in contact with the Contact Spring [3].




6. Remove the Harness Retaining Spring [1] from the 2 hooks [2].




7. Disconnect the 4 connectors [1].




8. Free the harness [1] from the Harness Guide [A].




9. Remove the Shaft Retainer [1].




10. Turn the machine so that it is placed with its front side down.



11. Remove the 6 screws (TP) [1] and the screw (with toothed lock washer) [2].




12. Remove the Pickup Unit [2] while holding the Pickup Unit [1] toward the front.




CAUTION:

- When installing the Pickup Unit [1], be sure that the Contact Spring [2] is in contact with the [A] part.
- Be sure to make the contact point [3] of the grounding come in contact with the [B] part.
- Be sure to install the Pickup Unit while holding the Pickup Tray [4] toward the front.
(This is because the tension of the spring is applied to the Pickup Tray.)




NOTE:

The following shows how to route the harness.



● Removing the Pickup Tray Unit (Duplex Model)




■ Preparation

1. Remove the Left Cover (Duplex Model) “Removing the Left Cover (Duplex Model)” on page 162.
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) “Removing the DADF Unit + Reader Unit” on page 89.
 2. Remove the SADF Unit + Reader Unit (SADF Model) “Removing the SADF Unit + Reader Unit.” on page 119.
 3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) “Removing the Copyboard Cover + Reader Unit” on page 149.
3. Remove the Right Cover (Duplex Model) “Removing the Right Cover (Duplex Model)” on page 164.
4. Remove the Front Cover Unit (Duplex Model) “Removing the Front Cover Unit (Duplex Model)” on page 166.
5. Remove the Upper Cover Unit (Duplex Model) “Removing the Upper Cover Unit (Duplex Model)” on page 167.
6. Remove the Duplex Feed Guide Unit (Duplex Model) “Removing the Duplex Feed Guide Unit. (Duplex Model)” on page 169.
7. Remove the Separation Pad (Duplex Model) “Removing the Separation Pad (Duplex Model)” on page 233.


■ Procedure

1. Remove the 4 screws (black TP) [1] and the 6 screws [2].



2. Remove the Pickup Unit [2] while holding the Pickup Tray Unit [1] toward the front.


- 2 Boss Holes [3]
- 2 Hooks [4]
- 2 Bosses [5]




NOTE:

How to assemble the Pickup Tray Unit

1. While holding the pickup tray [1] together, assemble it by aligning the 2 hooks [4] with the 2 Boss Holes [3] and the 2 bosses [5] with the Pickup Unit [2].



2. Fix the 6 screws [6] in the following order.
3. Be sure to check the positioning of the 6 bosses [7] when installing the Pickup Tray Unit.




● Removing the Pickup Roller (Duplex Model)



■ Procedure

CAUTION:

- Do not touch the surface of the Pickup Roller.
- Do not touch the Transfer Roller [1].




1. Depending on the model, perform one of the following operation.

1. Open the DADF Unit + Reader Unit [1] and Delivery Tray [2] (DADF Model).
2. Open the SADF Unit + Reader Unit [1] and Delivery Tray [2] (SADF Model).
3. Open the Copyboard Cover + Reader Unit [1] and Delivery Tray [2] (Copyboard Model).

2. Remove the Pickup Roller [3].

- 2 Claws [4]



● Removing the Separation Pad (Duplex Model)



■ Procedure



CAUTION:

Do not touch the surface of the Separation Pad.

1. Turn the machine so that it is placed with its left side down.
2. Depending on the model, perform one of the following operation.
 1. Hold and open the DADF Unit + Reader Unit [1] (DADF Model).
 2. Hold and open the SADF Unit + Reader Unit [1] (SADF Model).
 3. Hold and open the Copyboard Unit + Reader Unit [1] (Copyboard Model).


CAUTION:

Turning the machine sideways may release the tension of the hinge of the SADF Unit [2] and cause the units to open suddenly.




3. Remove the Separation Pad [1].

- 2 Screws [2]
- 2 Hooks [3]




● Removing the Delivery Slave Roller Unit (Duplex Model)



■ Procedure

1. Depending on the model, perform one of the following operation.

1. Open the DADF Unit + Reader Unit [1] and Delivery Tray [2] (DADF Model).
2. Open the SADF Unit + Reader Unit [1] and Delivery Tray [2] (SADF Model).
3. Open the Copyboard Cover + Reader Unit [1] and Delivery Tray [2] (Copyboard Model).





2. Remove the Delivery Slave Roller Unit [1].


- 2 Shafts [2]

CAUTION:

Do not damage the Delivery Slave Roller Unit [1] by bending it too much.



Removing the Pickup Solenoid (Duplex Model)



■ Preparation


1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)”](#) on page 162.
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) [“Removing the DADF Unit + Reader Unit”](#) on page 89.
 2. Remove the SADF Unit + Reader Unit (SADF Model) [“Removing the SADF Unit + Reader Unit.”](#) on page 119.

3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) “Removing the Copyboard Cover + Reader Unit” on page 149.
3. Remove the Right Cover (Duplex Model) “Removing the Right Cover (Duplex Model)” on page 164.
4. Remove the Front Cover Unit (Duplex Model) “Removing the Front Cover Unit (Duplex Model)” on page 166.
5. Remove the Upper Cover Unit (Duplex Model) “Removing the Upper Cover Unit (Duplex Model)” on page 167.
6. Remove the Duplex Feed Guide Unit (Duplex Model) “Removing the Duplex Feed Guide Unit. (Duplex Model)” on page 169.
7. Remove the Main Controller PCB (Duplex Model) “Removing the Main Motor (Duplex Model)” on page 174.
8. Remove the FAX NCU PCB (FAX Model 120/230V) (Duplex Model) “Removing the FAX NCU PCB (Fax Model 120V/ 230V) (Duplex Model)” on page 194.
9. Remove the Edge Left Cooling Fan (Duplex Model) “Removing the Edge Left Cooling Fan (Duplex Model)” on page 182.

■ Procedure


1. Remove the Wireless LAN Unit [1] (Wifi Model).

- 1 Screw (black TP) [2]
- 2 Hooks [3]



2. Remove the Main Controller PCB Installation Plate [1].


- 1 Relay Connector [2]
- Harness Guide [A]
- 1 Wire Saddle [3]
- 4 Screws (with washer) [4]
- 2 Screws (black TP) [5]



NOTE:

The Front Fixing Reinforcing Plate [1] should be removed before removing the Edge Left Cooling Fan Holder.


- 2 Screws (black TP) [2]



3. Free the harness [1] from the Harness Guide [A].


4. Remove the Edge Left Cooling Fan Holder [2].

- 1 Screw [3]




5. Free the harness [1] from the Harness Guide [A].

- 1 Terminal [2]




CAUTION:


Be sure that the terminal [2] is in contact with the Contact Spring [3].




6. Remove the Harness Retaining Spring [1] from the 2 hooks [2].



7. Disconnect the 4 connectors [1].




8. Free the Pickup Solenoid Harness [1] from the Harness Guide [A].




9. Move the Solenoid Arm [1] and remove the Pickup Solenoid [2].


- 1 Screw [3]

**NOTE:**

The following shows how to route the harness.



● Removing the Duplex Solenoid (Duplex Model)



■ Preparation


1. Remove the Left Cover (Duplex Model) [“Removing the Left Cover \(Duplex Model\)”](#) on page 162.
2. Depending on the model, perform one of the following operation.
 1. Remove the DADF Unit + Reader Unit (DADF Model) [“Removing the DADF Unit + Reader Unit”](#) on page 89.
 2. Remove the SADF Unit + Reader Unit (SADF Model) [“Removing the SADF Unit + Reader Unit.”](#) on page 119.
 3. Remove the Copyboard Cover + Reader Unit (Copyboard Model) [“Removing the Copyboard Cover + Reader Unit”](#) on page 149.

3. Remove the Right Cover (Duplex Model) “Removing the Right Cover (Duplex Model)” on page 164.
4. Remove the Front Cover Unit (Duplex Model) “Removing the Front Cover Unit (Duplex Model)” on page 166.
5. Remove the Upper Cover Unit (Duplex Model) “Removing the Upper Cover Unit (Duplex Model)” on page 167.

■ Procedure

1. Remove the Scanner Cover [1].


- 2 Screws (black TP) [2]




NOTE:

How to assemble the Scanner Cover

1. Be sure to pass the Shutter Open/Close Lever [3] through the hole [A] of the Scanner Cover.




2. Be sure that the Shutter Open/Close Lever [3] can move vertically.




2. Free the Solenoid Harness [1] from the guide [A], and pass it through the hole [B] of the Right Plate to the outside.

- 1 Connector [2]



3. Remove the Duplex Solenoid [1].


- 1 Screw [2]



NOTE:

How to assemble the Duplex Solenoid


Be sure to align the Solenoid Lever [1] with the groove [2] of the link, and fit the 2 Solenoid Positioning Bosses [3] in the 2 positioning holes [4] of the Side Plate.



External Cover/Internal System (Simplex Model)


Layout Drawing

■ Front Side



| No. | Name | Reference | Remarks |
|------|-------------------------------------|---|---------|
| [1] | Control Panel Unit | "Removing the Control Panel Unit (Simplex Model)" on page 254 | - |
| [2] | Delivery Auxiliary Tray | | - |
| [3] | Pickup Tray | | - |
| [4] | Trailing Edge Paper Guides | | - |
| [5] | Pickup Tray Side Guide Plate | | - |
| [6] | Power Switch | | - |
| [7] | Upper Cover | "Removing the Upper Cover (Simplex Model)" on page 249 | - |
| [8] | Delivery Tray | "Removing the Upper Cover (Simplex Model)" on page 249 | - |
| [9] | Front Cover Unit | "Removing the Front Cover Unit (Simplex Model)" on page 248 | - |
| [10] | Multi-Purpose Tray | | - |
| [11] | Tray Cover | | - |
| [12] | Multi-Purpose Tray Side Guide Plate | | - |

■ Rear Side



| No. | Name | Reference | Remarks |
|------|------------------------|--|----------------|
| [13] | Left Cover | "Removing the Left Cover (Simplex Model)" on page 244 | - |
| [14] | Hinge Face Cover | | - |
| [15] | Rear Cover | "Removing the Rear Cover (Simplex Model)" on page 251 | - |
| [16] | Right Cover | "Removing the Right Cover (Simplex Model)" on page 246 | - |
| [17] | USB Device Port | | - |
| [18] | LAN Port | | Model with NET |
| [19] | External Device Jack | | Model with FAX |
| [20] | Telephone Line Jack | | Model with FAX |
| [21] | Power Supply Cord Slot | | - |


● Removing the Left Cover (Simplex Model)




■ Procedure

NOTE:


The following shows the 5 claws [1] and 3 hooks [2] of the Left Cover.



1. Remove the screw (black TP) [1].




2. Release the 2 claws [1] at the rear side and the claw [2] at the lower side.




3. Depending on the model, perform one of the following operation.

1. Open the SADF Unit + Reader Unit [1] (SADF Model).
2. Open the Copyboard Cover + Reader Unit [1] (Copyboard Model).



4. Release the 2 claws [1] at the upper side and remove the Left Cover [3] while releasing the 3 hooks [2].




● Removing the Right Cover (Simplex Model)




■ Procedure

NOTE:


The following shows the 5 claws [1] and 3 hooks [2] of the Right Cover.



1. Remove the screw (black TP) [1].



2. Release the 2 claws [1] at the rear side and the claw [2] at the lower side.




3. Depending on the model, perform one of the following operation.


1. Open the SADF Unit + Reader Unit [1] (SADF Model).
2. Open the Copyboard Cover + Reader Unit [1] (Copyboard Model).



4. Release the 2 claws [1] at the upper side and remove the Left Cover [3] while releasing the 3 hooks [2].



● Removing the Front Cover Unit (Simplex Model)




■ Preparation

1. Remove the Left Cover (Simplex Model) “Removing the Left Cover (Simplex Model)” on page 244.
2. Remove the Right Cover (Simplex Model) “Removing the Upper Cover (Simplex Model)” on page 249.


■ Procedure

1. Remove the Front Cover Unit [1].

- 1 Connector [2]
- 2 Bosses [3]
- 2 Claws [4]



● Removing the Upper Cover (Simplex Model)



■ Preparation



1. Remove the Left Cover (Simplex Model) [“Removing the Left Cover \(Simplex Model\)” on page 244.](#)
2. Depending on the model, perform one of the following operation.
 1. Remove the SADF Unit + Reader Unit (SADF Model) [“Removing the SADF Unit + Reader Unit.” on page 119.](#)
 2. Remove the Copyboard Cover + Reader Unit (Copyboard Model) [“Removing the Copyboard Cover + Reader Unit” on page 149.](#)
3. Remove the Right Cover (Simplex Model) [“Removing the Upper Cover \(Simplex Model\)” on page 249.](#)
4. Remove the Front Cover Unit (Simplex Model) [“Removing the Front Cover Unit \(Simplex Model\)” on page 248.](#)

■ Procedure

1. Open the Delivery Tray [1].
2. Remove the Cartridge Arm [2].


3. Remove the 2 Fixing Pressure Arms [3].**CAUTION:**

Be careful not to lose the Cartridge Arm [2] and the 2 Fixing Pressure Arms [3].

**4. Remove the Delivery Tray [1].**


5. Remove the Upper Cover Unit [1].

- 4 Screws (black TP) [2]

**NOTE:**

How to assemble the Delivery Tray

1. Pass the Cartridge Arm [1] through the hole [A] of the Upper Cover Unit.
2. Install the Cartridge Arm [1] and the 2 Fixing Pressure Arms [2] on the Delivery Tray [3].



● Removing the Rear Cover (Simplex Model)




■ Preparation

1. Remove the Left Cover (Simplex Model) **“Removing the Left Cover (Simplex Model)”** on page 244.
2. Depending on the model, perform one of the following operation.
 1. Remove the SADF Unit + Reader Unit (SADF Model) **“Removing the SADF Unit + Reader Unit.”** on page 119.

2. Remove the Copyboard Cover + Reader Unit (Copyboard Model) “Removing the Copyboard Cover + Reader Unit” on page 149.
3. Remove the Right Cover (Simplex Model) “Removing the Upper Cover (Simplex Model)” on page 249.
4. Remove the Front Cover Unit (Simplex Model) “Removing the Front Cover Unit (Simplex Model)” on page 248.
5. Remove the Upper Cover (Simplex Model) “Removing the Upper Cover (Simplex Model)” on page 249.


■ Procedure

1. Remove the 2 screws (black TP) [1].




2. Remove the Rear Cover [1].

- 1 Claw [2]
- 2 Hooks [3]




Controller System (Simplex Model)

Layout Drawing




| No. | Name | Reference | Remarks |
|------|---|--|---------------------|
| [1] | Main Motor | "Removing the Main Motor (Simplex Model)" on page 255 | |
| [2] | Speaker | "Removing the Speaker (Fax Model + Simplex Model)" on page 277 | Fax Model |
| [3] | Control Panel Unit | "Removing the Control Panel Unit (Simplex Model)" on page 254 | |
| [4] | Toner Sensor and Multi Pickup Sensor Unit | "Removing the Toner Sensor and Multi Pickup Sensor Unit (Fax Model + Simplex Model)" on page 274 | Fax Model |
| [5] | Wireless LAN PCB | "Removing the Wireless LAN PCB (Wifi Model + Simplex Model)" on page 267 | Wifi Model |
| [6] | FAX NCU PCB | "Removing the FAX NCU PCB (Fax Model 120V/230V + Simplex Model)" on page 266 | Fax Model 120V/230V |
| [7] | Main Controller PCB | "Removing the Main Controller PCB (Simplex Model)" on page 263 | |
| [8] | Engine Controller PCB | "Removing the Engine Controller PCB (Simplex Model)" on page 258 | |
| [9] | Paper Leading Edge Sensor PCB | "Removing the Paper Leading Edge Sensor (Simplex Model)" on page 267 | |
| [10] | Fixing Delivery/Paper Width Sensor PCB | "Removing the Fixing Delivery/Paper Width Sensor PCB (Simplex Model)" on page 271 | |

● Removing the Control Panel Unit (Simplex Model)




■ Procedure


1. Depending on the model, perform one of the following operation.
 1. Open the SADF Unit + Reader Unit [1] (SADF Model).
 2. Open the Copyboard Cover + Reader Unit [1] (Copyboard Model).
2. Lift the Control Panel Unit [2].



3. Remove the 4 Screws [1].




4. Depending on the model, perform one of the following operation.
 1. Close the Reader Unit [1], and open the SADF Unit [2] (SADF Model).
 2. Close the Reader Unit [1], and open the Copyboard Unit 1 [2] (Copyboard Model).




5. Remove the Control Panel Unit [1].

- 6 Claws [2]
- 1 Flat Cable [3]



● Removing the Main Motor (Simplex Model)




■ Preparation

1. Remove the Left Cover (Simplex Model) [“Removing the Left Cover \(Simplex Model\)”](#) on page 244.
2. Depending on the model, perform one of the following operation.
 1. Remove the SADF Unit + Reader Unit (SADF Model) [“Removing the SADF Unit + Reader Unit.”](#) on page 119.
 2. Remove the Copyboard Cover + Reader Unit (Copyboard Model) [“Removing the Copyboard Cover + Reader Unit”](#) on page 149.
3. Remove the Right Cover (Simplex Model) [“Removing the Upper Cover \(Simplex Model\)”](#) on page 249.

4. Remove the Front Cover Unit (Simplex Model) “Removing the Front Cover Unit (Simplex Model)” on page 248.
5. Remove the Upper Cover (Simplex Model) “Removing the Upper Cover (Simplex Model)” on page 249.

■ Procedure


1. Remove the Scanner Cover [1].
 - 2 Screws (black TP) [2]




NOTE:

How to assemble the Scanner Cover

1. Be sure to pass the Shutter Open/Close Lever [3] through the hole [A] of the Scanner Cover.





2. Be sure that the Shutter Open/Close Lever [3] can move vertically.




2. Remove the Motor Driver PCB [1].


- 2 Connectors [2]
- 2 Claws [3]
- 1 Hook [4]

**3. Free the Motor Harness [1] from the Harness Guide [A].****4. Remove the Motor Guide [2].**

- 1 Screw [3]
- 1 Hook [4]


**5. Remove the Tension Unit [1].**

- 1 Screw [2]



6. Remove the Main Motor [1].


- 2 Screws (with plain washer) [2]

**NOTE:**


How to assemble the Main Motor

Be sure to assemble it with the harness [1] routed upwards.

(Otherwise, the connector of the Speaker Harness cannot reach the Motor Driver PCB.)



● Removing the Engine Controller PCB (Simplex Model)



■ Preparation


1. Remove the Left Cover (Simplex Model) [“Removing the Left Cover \(Simplex Model\)”](#) on page 244.
2. Depending on the model, perform one of the following operation.
 1. Remove the SADF Unit + Reader Unit (SADF Model) [“Removing the SADF Unit + Reader Unit.”](#) on page 119.
 2. Remove the Copyboard Cover + Reader Unit (Copyboard Model) [“Removing the Copyboard Cover + Reader Unit”](#) on page 149.
3. Remove the Right Cover (Simplex Model) [“Removing the Upper Cover \(Simplex Model\)”](#) on page 249.
4. Remove the Front Cover Unit (Simplex Model) [“Removing the Front Cover Unit \(Simplex Model\)”](#) on page 248.
5. Remove the Upper Cover (Simplex Model) [“Removing the Upper Cover \(Simplex Model\)”](#) on page 249.

6. Remove the Rear Cover (Simplex Model) [“Removing the Rear Cover \(Simplex Model\)”](#) on page 251.
7. Remove the Main Controller PCB (Simplex Model) [“Removing the Main Controller PCB \(Simplex Model\)”](#) on page 263.
8. Remove the FAX NCU PCB (FAX Model 120/230V) (Simplex Model) [“Removing the FAX NCU PCB \(Fax Model 120V/230V + Simplex Model\)”](#) on page 266.

■ Procedure


1. Remove the Wireless LAN Unit [1] (Wifi Model).

- 1 Screw (black TP) [2]
- 2 Hooks [3]




2. Remove the Main Controller PCB Installation Plate [1].

- 1 Wire Saddle [2]
- 4 Screws (with washer) [3]
- 2 Screws (black TP) [4]




3. Free the harness [1] from the Harness Guide [A].

- 1 Terminal [2]




CAUTION:


Be sure that the terminal [2] is in contact with the Contact Spring [3].




4. Remove the Harness Retaining Spring [1] from the 2 hooks [2].



5. Remove the 3 Flat Cables [2], the 6 connectors [3], and the connector [4] (Fax Model) installed on the Engine Controller PCB [1].




6. Free the harness [1] from the guide [A].




7. Remove the Engine Controller PCB [1].

- 2 Screws (with plain washer) [2]
- 1 Screw (with toothed lock washer) [3]
- 1 Screw (black TP) [4]
- 2 Hooks [5]


**NOTE:**

How to assemble the Engine Controller PCB

- Put the Switchboard [2] in the lower part of the Switch Arm [1], and hook the Engine Controller PCB on the hook [3].




- Be sure that the Switch Arm [1] can move vertically.




CAUTION:

Be careful not to install the Flat Cable [1] in the wrong direction.



● Removing the Main Controller PCB (Simplex Model)



■ Before Replacing

1. Before starting the replacement, output a status print.

After replacing the Main Controller, the serial number of the host machine needs to be written to the Main Controller.

2. Ask the user to perform the following operations if possible.


- Ask the user to print the user data list.
[Menu] > [Output Report] > [Output Rprt.] > [User Data List]
- Ask the user to save the address book from remote UI.
 1. Start remote UI and log in in administrator mode.
 2. Click [Settings/Registration] > [Import/Export] > [Export] > [Start Exporting].
 3. Follow the instructions on the screen to specify the location to save the address book.

■ Preparation

1. Remove the Left Cover (Simplex Model) “[Removing the Left Cover \(Simplex Model\)](#)” on page 244.


■ Procedure

1. Disconnect all the Flat Cables [1] and connectors [2] installed on the Main Controller PCB.




2. Remove the Main Controller PCB [1].

- 1 Screw [2]
- 5 Screws (black TP) [3]

**NOTE:**

The layout of the connectors on the Main Controller PCB is shown below.



| J No. | J No. | Symbol | Name | Remarks |
|-------|-------|-----------------|-----------------------|------------|
| J1 | J401 | UNIT15 / UNIT19 | Control Panel PCB | |
| J2 | J1601 | CIS | CIS Sensor | |
| J3 | J902 | UNIT1 | Engine Controller PCB | |
| J4 | J1 | UNIT14 | Wireless LAN PCB | Wifi Model |
| J6 | - | - | - | |
| J7 | J1406 | PS4 | Original Sensor | SADF Model |
| J7 | J1407 | PS5 | Original Edge Sensor | SADF Model |
| J11 | - | M3 | Flatbed Motor Unit | |
| J12 | J1401 | M5 | SADF Motor Unit | SADF Model |
| J14 | - | - | USB | |
| J15 | - | PS6 | Tray Sensor | |
| J22 | - | - | - | |
| J600 | - | - | LAN | |
| J901 | J1204 | UNIT17 | FAX NCU PCB | FAX Model |
| J903 | J1201 | UNIT17 | FAX NCU PCB | FAX Model |
| J904 | - | SP1 | Speaker | FAX Model |

■ After Replacing

1. After replacing the PCB, enter the serial number in "Location " of System Management Settings from remote UI or local UI, and confirm the serial number.
2. Check that OK is displayed in COPIER > OPTION > SERIAL > SN-MAIN.
 - For the detailed procedure, refer to the chapter on service mode.

3. COPIER > OPTION > BODY > LOCALE

To set country group.

- 1: Japan
- 2: North America
- 3: Korea
- 4: China
- 5: Taiwan
- 6: Europe
- 7: Asia

Setting range: 1 - 7 (Service part default value: 2)


4. Execute the following service mode to enable this setting.

COPIER > FUNCTION > CLEAR > ALL

5. If the user has printed the user data list and saved the address book before the replacement, ask the user to return the settings back to the original values.

- Ask the user to load the address book from remote UI.
 1. Start remote UI and log in in administrator mode.
 2. [Settings/Registration] > [Import/Export] > [Import]
 3. Select the address book file to be imported, and click [Start Importing].
 4. Click [OK].

Removing the FAX NCU PCB (Fax Model 120V/230V + Simplex Model)




■ Preparation

1. Remove the Left Cover (Simplex Model) [“Removing the Left Cover \(Simplex Model\)”](#) on page 244.


■ Procedure

1. Remove the FAX NCU PCB [1].

- 1 Flat Cable [2]
- 1 Connector [3]
- 3 Screws [4]



● Removing the Wireless LAN PCB (Wifi Model + Simplex Model)




■ Preparation


1. Remove the Left Cover (Simplex Model) [“Removing the Left Cover \(Simplex Model\)”](#) on page 244.

■ Procedure

1. Remove the Wireless LAN Unit [1].
 - 1 Flat Cable [2]
 - 1 Screw (black TP) [3]



● Removing the Paper Leading Edge Sensor (Simplex Model)



■ Preparation


1. Remove the Left Cover (Simplex Model) [“Removing the Left Cover \(Simplex Model\)”](#) on page 244.
2. Depending on the model, perform one of the following operation.
 1. Remove the SADF Unit + Reader Unit (SADF Model) [“Removing the SADF Unit + Reader Unit.”](#) on page 119.
 2. Remove the Copyboard Cover + Reader Unit (Copyboard Model) [“Removing the Copyboard Cover + Reader Unit”](#) on page 149.
3. Remove the Right Cover (Simplex Model) [“Removing the Upper Cover \(Simplex Model\)”](#) on page 249.
4. Remove the Front Cover Unit (Simplex Model) [“Removing the Front Cover Unit \(Simplex Model\)”](#) on page 248.
5. Remove the Upper Cover (Simplex Model) [“Removing the Upper Cover \(Simplex Model\)”](#) on page 249.
6. Remove the Rear Cover (Simplex Model) [“Removing the Rear Cover \(Simplex Model\)”](#) on page 251.

7. Remove the Main Controller PCB (Simplex Model) “Removing the Main Controller PCB (Simplex Model)” on page 263.
8. Remove the FAX NCU PCB (FAX Model 120/230V) (Simplex Model) “Removing the FAX NCU PCB (Fax Model 120V/230V + Simplex Model)” on page 266.

■ Procedure


1. Remove the Wireless LAN Unit [1] (Wifi Model).

- 1 Screw (black TP) [2]
- 2 Hooks [3]




2. Remove the Main Controller PCB Installation Plate [1].

- 1 Wire Saddle [2]
- 4 Screws (with washer) [3]
- 2 Screws (black TP) [4]




3. Free the harness [1] from the Harness Guide [A].

- 1 Terminal [2]




CAUTION:


Be sure that the terminal [2] is in contact with the Contact Spring [3].



4. Remove the Harness Retaining Spring [1] from the 2 hooks [2].




5. Disconnect the 4 connectors [1].



6. Free the harness [1] from the guide [A].


7. Remove the Paper Leading Edge Sensor PCB [2].

• 2 Claws [3]




NOTE:

The following shows how to route the harness.



Removing the Fixing Delivery/Paper Width Sensor PCB (Simplex Model)




■ Preparation

1. Remove the Left Cover (Simplex Model) [“Removing the Left Cover \(Simplex Model\)” on page 244.](#)
2. Depending on the model, perform one of the following operation.
 1. Remove the SADF Unit + Reader Unit (SADF Model) [“Removing the SADF Unit + Reader Unit.” on page 119.](#)
 2. Remove the Copyboard Cover + Reader Unit (Copyboard Model) [“Removing the Copyboard Cover + Reader Unit” on page 149.](#)
3. Remove the Right Cover (Simplex Model) [“Removing the Upper Cover \(Simplex Model\)” on page 249.](#)
4. Remove the Front Cover Unit (Simplex Model) [“Removing the Front Cover Unit \(Simplex Model\)” on page 248.](#)
5. Remove the Upper Cover (Simplex Model) [“Removing the Upper Cover \(Simplex Model\)” on page 249.](#)
6. Remove the Rear Cover (Simplex Model) [“Removing the Rear Cover \(Simplex Model\)” on page 251.](#)
7. Remove the Main Controller PCB (Simplex Model) [“Removing the Main Controller PCB \(Simplex Model\)” on page 263.](#)
8. Remove the FAX NCU PCB (FAX Model 120/230V) (Simplex Model) [“Removing the FAX NCU PCB \(Fax Model 120V/230V + Simplex Model\)” on page 266.](#)


■ Procedure

1. Remove the Wireless LAN Unit [1] (Wifi Model).
 - 1 Screw (black TP) [2]
 - 2 Hooks [3]




2. Remove the Main Controller PCB Installation Plate [1].

- 1 Wire Saddle [2]
- 4 Screws (with washer) [3]
- 2 Screws (black TP) [4]




3. Free the harness [1] from the Harness Guide [A].

- 1 Terminal [2]




CAUTION:


Be sure that the terminal [2] is in contact with the Contact Spring [3].



4. Remove the Harness Retaining Spring [1] from the 2 hooks [2].




5. Disconnect the 4 connectors [1].




6. Free the harness [1] from the guide [A].

7. Remove the Fixing Delivery/Paper Width Sensor PCB [2].


- 1 Connector [3]
- 2 Claws [4]

**NOTE:**

The following shows how to route the harness.



● Removing the Toner Sensor and Multi Pickup Sensor Unit (Fax Model + Simplex Model)



■ Preparation


1. Remove the Left Cover (Simplex Model) **“Removing the Left Cover (Simplex Model)”** on page 244.
2. Depending on the model, perform one of the following operation.
 1. Remove the SADF Unit + Reader Unit (SADF Model) **“Removing the SADF Unit + Reader Unit.”** on page 119.

2. Remove the Copyboard Cover + Reader Unit (Copyboard Model) “Removing the Copyboard Cover + Reader Unit” on page 149.
3. Remove the Right Cover (Simplex Model) “Removing the Upper Cover (Simplex Model)” on page 249.
4. Remove the Front Cover Unit (Simplex Model) “Removing the Front Cover Unit (Simplex Model)” on page 248.
5. Remove the Upper Cover (Simplex Model) “Removing the Upper Cover (Simplex Model)” on page 249.

■ Procedure


1. Remove the Wireless LAN Unit [1] (Wifi Model).

- 1 Flat Cable [2]
- 1 Screw (black TP) [3]
- 2 Hooks [4]




2. Remove the Scanner Cover [1].

- 2 Screws (black TP) [2]


**NOTE:**

How to assemble the Scanner Cover

1. Be sure to pass the Shutter Open/Close Lever [3] through the hole [A] of the Scanner Cover.




2. Be sure that the Shutter Open/Close Lever [3] can move vertically.




3. Pass the harness [1] through the hole [A] of the Left Side Plate to the inside.

- 1 Connector [2]
- 1 Connector [3] (Fax Model)




4. Remove the Multi Pickup Sensor Unit [1].

- 1 Wire Saddle [2]
- 1 Claw [3]
- 3 Hooks [4]



● Removing the Speaker (Fax Model + Simplex Model)




■ Preparation


1. Remove the Left Cover (Simplex Model) [“Removing the Left Cover \(Simplex Model\)”](#) on page 244.
2. Remove the Right Cover (Simplex Model) [“Removing the Upper Cover \(Simplex Model\)”](#) on page 249.
3. Remove the Front Cover Unit (Simplex Model) [“Removing the Front Cover Unit \(Simplex Model\)”](#) on page 248.

■ Procedure

1. Disconnect the Speaker Harness [1], and pass it through the hole [A] of the Left Side Plate to the inside.
 - 1 Connector [2]
 - 1 Wire Saddle [3]




2. Free the Speaker Harness [1] from the Harness Guide [A], and pass it through the hole [B] of the Right Plate to the outside.



3. Remove the speaker [1].


- 1 Screw [2]
- 2 Hook [3]

**NOTE:**

How to assemble the speaker


Be sure to assemble it with the harness [1] routed upwards.

Otherwise, the connector of the Speaker Harness cannot reach the Main Controller.



Laser Exposure System (Simplex Model)

Layout Drawing



| No. | Name | Reference | Remarks |
|-----|--------------------|---|---------|
| [1] | Laser Scanner Unit | "Removing the Laser Scanner Unit (Simplex Model)" on page 280 | |

Removing the Laser Scanner Unit (Simplex Model)



■ Preparation

1. Remove the Left Cover (Simplex Model) "[Removing the Left Cover \(Simplex Model\)](#)" on page 244.
2. Depending on the model, perform one of the following operation.
 1. Remove the SADF Unit + Reader Unit (SADF Model) "[Removing the SADF Unit + Reader Unit.](#)" on page 119.
 2. Remove the Copyboard Cover + Reader Unit (Copyboard Model) "[Removing the Copyboard Cover + Reader Unit](#)" on page 149.
3. Remove the Right Cover (Simplex Model) "[Removing the Upper Cover \(Simplex Model\)](#)" on page 249.
4. Remove the Front Cover Unit (Simplex Model) "[Removing the Front Cover Unit \(Simplex Model\)](#)" on page 248.
5. Remove the Upper Cover (Simplex Model) "[Removing the Upper Cover \(Simplex Model\)](#)" on page 249.


■ Procedure

CAUTION:

Do not disassemble the Laser Scanner Unit because it requires adjustment.

1. Remove the Scanner Cover [1].

- 2 Screws (black TP) [2]




2. Move the Laser Scanner Unit [1].

- 4 Screws [2]

3. Remove the Laser Scanner Unit [1].


- 1 Flat Cable [3]
- 1 Sponge [4]
- 1 Connector [5]



NOTE:

How to assemble the Scanner Cover

1. Be sure to pass the Shutter Open/Close Lever [3] through the hole [A] of the Scanner Cover.



2. Be sure that the Shutter Open/Close Lever [3] can move vertically.





Image Formation System (Simplex Model)

Layout Drawing



| No. | Name | Reference | Remarks |
|-----|-----------------|--|---------|
| [1] | Transfer Roller | "Removing the Transfer Roller (Simplex Model)" on page 283 | |

Removing the Transfer Roller (Simplex Model)



■ Procedure

CAUTION:


Do not touch the surface of the Transfer Roller.

1. Depending on the model, perform one of the following operation.


1. Open the SADF Unit + Reader Unit [1] and Delivery Tray [2] (SADF Model).
2. Open the Copyboard Cover + Reader Unit [1] and Delivery Tray [2] (Copyboard Model).

2. Remove the bushing [3] of the Transfer Roller.

- 2 Claws [4]




3. Hold both ends of the shaft [1] of the Transfer Roller, and remove the Transfer Roller [2].



CAUTION:


Be sure that the bushing [1] is facing the correct direction when assembling.



NOTE:


How to assemble the Transfer Roller

Be sure to assemble it by aligning the spring [1] with the boss [2].




Fixing System (Simplex Model)

Layout Drawing



| No. | Name | Reference | Remarks |
|-----|-------------|--|---------|
| [1] | Fixing Unit | "Removing the Fixing Assembly (Simplex Model)" on page 286 | |

Removing the Fixing Assembly (Simplex Model)



■ Preparation

1. Remove the Left Cover (Simplex Model) "[Removing the Left Cover \(Simplex Model\)](#)" on page 244.
2. Depending on the model, perform one of the following operation.
 1. Remove the SADF Unit + Reader Unit (SADF Model) "[Removing the SADF Unit + Reader Unit.](#)" on page 119.
 2. Remove the Copyboard Cover + Reader Unit (Copyboard Model) "[Removing the Copyboard Cover + Reader Unit](#)" on page 149.
3. Remove the Right Cover (Simplex Model) "[Removing the Upper Cover \(Simplex Model\)](#)" on page 249.
4. Remove the Front Cover Unit (Simplex Model) "[Removing the Front Cover Unit \(Simplex Model\)](#)" on page 248.
5. Remove the Upper Cover (Simplex Model) "[Removing the Upper Cover \(Simplex Model\)](#)" on page 249.
6. Remove the Rear Cover (Simplex Model) "[Removing the Rear Cover \(Simplex Model\)](#)" on page 251.
7. Remove the Main Controller PCB (Simplex Model) "[Removing the Main Controller PCB \(Simplex Model\)](#)" on page 263.
8. Remove the FAX NCU PCB (FAX Model 120/230V) (Simplex Model) "[Removing the FAX NCU PCB \(Fax Model 120V/230V + Simplex Model\)](#)" on page 266.


■ Procedure

CAUTION:

- Be sure to start work after the Fixing Assembly is cooled down enough.
- The Fixing Assembly right after printing may cause burn injury.
- Do not disassemble the Fixing Assembly because it requires adjustment.


1. Remove the Wireless LAN Unit [1] (Wifi Model).

- 1 Screw (black TP) [2]
- 2 Hooks [3]




2. Remove the Main Controller PCB Installation Plate [1].

- 1 Wire Saddle [2]
- 4 Screws (with washer) [3]
- 2 Screws (black TP) [4]




3. Free the harness [1] from the Harness Guide [A].

- 1 Terminal [2]




CAUTION:

Be sure that the terminal [2] is in contact with the Contact Spring [3].




4. Remove the Harness Retaining Spring [1] from the 2 hooks [2].




5. Remove the 2 Reinforcing Plates [1] (right and left).

- 4 Screws (black TP) [2]




6. Disconnect the 4 connectors [1].





7. Free the harness [1] from the Harness Guide [A].

8. Free the Fixing Harness [2] from the Harness Holder [3].




9. Remove the Harness Holder [1].

- 1 Claw [2]

**10. Remove the Shaft Support [1] of the Delivery Roller.**


11. Remove the Fixing Assembly [1].

- 3 Screws [2]


**NOTE:**

How to install the Fixing Harness

1. Wrap the Fixing Harness [2] around the protrusion [1] of the Harness Holder.
2. Pass it through the Harness Guide [A], and then connect the connector [3].


**NOTE:**

The following shows how to route the harness.




Pickup Feed System (Simplex Model)

Layout Drawing



| No. | Name | Reference | Remarks |
|-----|----------------------------|---|---------|
| [1] | Delivery Slave Roller Unit | "Removing the Delivery Slave Roller Unit (Simplex Model)" on page 303 | |
| [2] | Pickup Unit | "Removing the Pickup Unit (Simplex Model)" on page 292 | |
| [3] | Pickup Tray Unit | "Removing the Pickup Tray Unit (Simplex Model)" on page 298 | |
| [4] | Separation Pad | "Removing the Separation Pad (Simplex Model)" on page 302 | |
| [5] | Pickup Roller | "Removing the Pickup Roller (Simplex Model)" on page 300 | |
| [6] | Pickup Solenoid | "Removing the Pickup Solenoid (Simplex Model)" on page 304 | |

Removing the Pickup Unit (Simplex Model)



Preparation


1. Remove the Left Cover (Simplex Model) "[Removing the Left Cover \(Simplex Model\)](#)" on page 244.
2. Depending on the model, perform one of the following operation.
 1. Remove the SADF Unit + Reader Unit (SADF Model) "[Removing the SADF Unit + Reader Unit.](#)" on page 119.
 2. Remove the Copyboard Cover + Reader Unit (Copyboard Model) "[Removing the Copyboard Cover + Reader Unit](#)" on page 149.

3. Remove the Right Cover (Simplex Model) [“Removing the Upper Cover \(Simplex Model\)”](#) on page 249.
4. Remove the Front Cover Unit (Simplex Model) [“Removing the Front Cover Unit \(Simplex Model\)”](#) on page 248.
5. Remove the Upper Cover (Simplex Model) [“Removing the Upper Cover \(Simplex Model\)”](#) on page 249.
6. Remove the Rear Cover (Simplex Model) [“Removing the Rear Cover \(Simplex Model\)”](#) on page 251.
7. Remove the Main Controller PCB (Simplex Model) [“Removing the Main Controller PCB \(Simplex Model\)”](#) on page 263.
8. Remove the FAX NCU PCB (FAX Model 120/230V) (Simplex Model) [“Removing the FAX NCU PCB \(Fax Model 120V/230V + Simplex Model\)”](#) on page 266.
9. Remove the Separation Pad (Simplex Model) [“Removing the Separation Pad \(Simplex Model\)”](#) on page 302.

■ Procedure


1. Remove the Wireless LAN Unit [1] (Wifi Model).

- 1 Screw (black TP) [2]
- 2 Hooks [3]




2. Remove the Main Controller PCB Installation Plate [1].

- 1 Wire Saddle [2]
- 4 Screws (with washer) [3]
- 2 Screws (black TP) [4]




3. Free the harness [1] from the Harness Guide [A].

- 1 Terminal [2]




CAUTION:


Be sure that the terminal [2] is in contact with the Contact Spring [3].




4. Remove the Harness Retaining Spring [1] from the 2 hooks [2].




5. Disconnect the 4 connectors [1].




6. Free the harness [1] from the Harness Guide [A].




7. Remove the Shaft Retainer [1].




8. Turn the machine so that it is placed with its front side down.



9. Remove the 6 screws (TP) [1] and the screw (with toothed lock washer) [2].




10. Remove the Pickup Unit [2] while opening the Pickup Tray [1].




CAUTION:

- When installing the Pickup Unit [1], be sure that the Contact Spring [2] is in contact with the [A] part.
- Be sure to make the contact point [3] of the grounding come in contact with the [B] part.
- Be sure to install the Pickup Unit [1] while holding the Pickup Tray [4].
(This is because the tension of the spring is applied to the Pickup Tray.)




NOTE:

The following shows how to route the harness.



● Removing the Pickup Tray Unit (Simplex Model)




■ Preparation

1. Remove the Left Cover (Simplex Model) “Removing the Left Cover (Simplex Model)” on page 244.
2. Depending on the model, perform one of the following operation.
 1. Remove the SADF Unit + Reader Unit (SADF Model) “Removing the SADF Unit + Reader Unit.” on page 119.
 2. Remove the Copyboard Cover + Reader Unit (Copyboard Model) “Removing the Copyboard Cover + Reader Unit” on page 149.
3. Remove the Right Cover (Simplex Model) “Removing the Upper Cover (Simplex Model)” on page 249.
4. Remove the Front Cover Unit (Simplex Model) “Removing the Front Cover Unit (Simplex Model)” on page 248.
5. Remove the Upper Cover (Simplex Model) “Removing the Upper Cover (Simplex Model)” on page 249.
6. Remove the Rear Cover (Simplex Model) “Removing the Rear Cover (Simplex Model)” on page 251.
7. Remove the Separation Pad (Simplex Model) “Removing the Separation Pad (Simplex Model)” on page 302.


■ Procedure

1. Remove the 4 screws (black TP) [1] and the 6 screws [2].



2. Remove the Pickup Unit [2] while holding the Pickup Tray Unit [1] toward the front.


- 2 Boss Holes [3]
- 2 Hooks [4]
- 2 Bosses [5]




NOTE:

How to assemble the Pickup Tray Unit

1. While holding the pickup tray [1] together, assemble it by aligning the 2 hooks [4] with the 2 Boss Holes [3] and the 2 bosses [5] with the Pickup Unit [2].



2. Fix the 6 screws [6] in the following order.
3. Be sure to check the positioning of the 6 bosses [7] when installing the Pickup Tray Unit.




● Removing the Pickup Roller (Simplex Model)



■ Procedure

CAUTION:

- Do not touch the surface of the Pickup Roller.
- Do not touch the Transfer Roller [1].




1. Depending on the model, perform one of the following operation.

1. Open the SADF + Reader Unit [1] and the Delivery Tray [2] (SADF Model).
2. Open the Copyboard Cover + Reader Unit [1] and the Delivery Tray [2] (Copyboard Model).

2. Remove the Pickup Roller [3].

- 2 Claws [4]



● Removing the Separation Pad (Simplex Model)



■ Procedure



CAUTION:

Do not touch the surface of the Separation Pad.

1. Turn the machine so that it is placed with its left side down.
2. Depending on the model, perform one of the following operation.
 1. Hold and open the SADF Unit + Reader Unit [1] (SADF Model).
 2. Hold and open the Copyboard Unit + Reader Unit [1] (Copyboard Model).


CAUTION:

Turning the machine sideways may release the tension of the hinge of the SADF Unit [2] and cause the units to open suddenly.




3. Remove the Separation Pad [1].

- 2 Screws [2]
- 2 Hooks [3]




● Removing the Delivery Slave Roller Unit (Simplex Model)



■ Procedure

1. Depending on the model, perform one of the following operation.

1. Open the SADF + Reader Unit [1] and the Delivery Tray [2] (SADF Model).
2. Open the Copyboard Cover + Reader Unit [1] and the Delivery Tray [2] (Copyboard Model).





2. Remove the Delivery Slave Roller Unit [1].


- 2 Shafts [2]

CAUTION:

Do not damage the Delivery Slave Roller Unit [1] by bending it too much.



Removing the Pickup Solenoid (Simplex Model)



■ Preparation


1. Remove the Left Cover (Simplex Model) [“Removing the Left Cover \(Simplex Model\)”](#) on page 244.
2. Depending on the model, perform one of the following operation.
 1. Remove the SADF Unit + Reader Unit (SADF Model) [“Removing the SADF Unit + Reader Unit.”](#) on page 119.
 2. Remove the Copyboard Cover + Reader Unit (Copyboard Model) [“Removing the Copyboard Cover + Reader Unit”](#) on page 149.

3. Remove the Right Cover (Simplex Model) [“Removing the Upper Cover \(Simplex Model\)”](#) on page 249.
4. Remove the Front Cover Unit (Simplex Model) [“Removing the Front Cover Unit \(Simplex Model\)”](#) on page 248.
5. Remove the Upper Cover (Simplex Model) [“Removing the Upper Cover \(Simplex Model\)”](#) on page 249.
6. Remove the Rear Cover (Simplex Model) [“Removing the Rear Cover \(Simplex Model\)”](#) on page 251.
7. Remove the Main Controller PCB (Simplex Model) [“Removing the Main Controller PCB \(Simplex Model\)”](#) on page 263.
8. Remove the FAX NCU PCB (FAX Model 120/230V) (Simplex Model) [“Removing the FAX NCU PCB \(Fax Model 120V/230V + Simplex Model\)”](#) on page 266.

■ Procedure


1. Remove the Wireless LAN Unit [1] (Wifi Model).

- 1 Screw (black TP) [2]
- 2 Hooks [3]




2. Remove the Main Controller PCB Installation Plate [1].

- 1 Wire Saddle [2]
- 4 Screws (with washer) [3]
- 2 Screws (black TP) [4]




3. Free the harness [1] from the Harness Guide [A].

- 1 Terminal [2]




CAUTION:


Be sure that the terminal [2] is in contact with the Contact Spring [3].




4. Remove the Harness Retaining Spring [1] from the 2 hooks [2].



5. Disconnect the 4 connectors [1].




6. Free the Pickup Solenoid Harness [1] from the Harness Guide [A].




7. Move the Solenoid Arm [1] to remove the Pickup Solenoid [2].

- 1 Screw [3]

**NOTE:**

The following shows how to route the harness.





Adjustment

Mechanical Adjustment.....310

Mechanical Adjustment

Confirming Nip Width

CAUTION:


Be sure to follow the procedures below, otherwise the fixing film or the fixing sleeve may be damaged.

The nip width of the fixing unit is not adjustable in this printer, however, the incorrect nip width may cause the faulty fixing. Follow the procedures below to check the nip width.

1. Prepare an all-black print of A4 size made by the same type of EP Toner cartridge for this printer before visiting the customer site.
2. Load the printed sheet facing DOWN on the pickup tray.
3. Print a test-page.
4. Turn off the printer when the leading edge of the paper appears in the face-down delivery slot. Wait for 60 seconds and open the cartridge door to remove the paper from the printer.
5. Measure the width of the glossy band across the paper and check if it is meeting the requirements below.

Wasp/Horsethief/Blackrock

- Center (a): 5.5mm to 8.1mm
- Right and left (b, c): 5.5mm to 8.1mm





Troubleshooting

| | |
|----------------------------|-----|
| Test Print..... | 312 |
| Troubleshooting Items..... | 313 |
| Version Upgrade..... | 314 |
| Log Collect Tool..... | 315 |

Test Print

Test Print Function

This equipment has a test print function to check if the printer engine normally operates.

Test patterns (horizontal lines) are output when executing this test print.


The following is the operation procedure;

a. 1-sided print


1. Set A4/LTR papers on the pickup tray or the manual feed pickup tray.
2. Continuously open and close the Delivery Tray [1] at least 5 times for even number of times with the Power Switch ON.
3. A 1-sided engine test print is executed.

b. 2-sided print

1. Set A4/LTR papers on the pickup tray or the manual feed pickup tray.
2. Continuously open and close the Delivery Tray [1] at least 5 times for odd number of times with the Power Switch ON.
3. A 2-sided engine test print is executed.



Engine Test Print Pattern



Troubleshooting Items

Remedy for Image Failure

When an image failure occurs, perform the remedy by referring to the following material.

- Top > Troubleshooting > When You Cannot Print Properly

Intervals of Soiling, White Spots, Etc. That Occur on Images

| Cause of failure | | Intervals (mm) | Symptom | | | |
|------------------|-------------------------|----------------|---------|-------------|-------------|----------------|
| | | | Soiling | White spots | Soiled back | Fixing failure |
| Cartridge | Primary Charging Roller | Approx. 27 | - | Occurs | - | - |
| | Photosensitive Drum | Approx. 75 | Occurs | Occurs | - | - |
| | Developing Roller | Approx. 34 | - | Occurs | - | - |
| Transfer Roller | | Approx. 39 | - | Occurs | Occurs | - |
| Fixing Assembly | Fixing Film | Approx. 57 | Occurs | Occurs | - | Occurs |
| | Pressure Roller | Approx. 79 | Occurs | - | Occurs | Occurs |


Version Upgrade

Overview

This machine supports the following two methods for upgrading the firmware.

1. User Support Tool (UST)
2. Via Internet

Upgrading of Firmware



UST is included in the firmware for the machine that can be downloaded from the website of CINC. Firmware is downloaded as a zip file and a folder containing UST is extracted by decompressing the file.

When executing UST on the PC connected to the machine with a USB Cable, the firmware is upgraded by downloading it from the PC to the machine. For the detailed procedure, refer to "UST Operation Guide" stored in the decompressed folder. "UST Operation Guide" is also available from the website of CINC.

Upgrading via Internet

Overview

Select to automatically install the firmware update without using a computer.

Preparation

1. Check that there are no other jobs being executed.
2. In an environment where access is obtained via a proxy server, the proxy setting is made from the remote UI.
Settings/Registration > System Management Settings > Network Settings > TCP/IP Settings > Proxy Settings > Edit... > Use Proxy(select)Select the [Use Proxy] check box and specify the required settings.
3. Check that the serial number of the host machine is shown on the Main Controller PCB.

NOTE:

To upgrade the firmware of the host machine via Internet, the serial number of the machine need to be written on the Main Controller PCB.

Execute Options > Service Mode > Serial Number Settings, and check that the Serial Number is registered.

Procedure

1. Press the [Menu] key, and update the firmware via the Internet in user mode
options > Remote UI > System Management Settings > Update Firmware > Via Internet

NOTE:

- Re fer to the User's Manual of the device for how to connect the device to the external network.
- This is applicable either in a wired LAN environment or a wireless LAN environment.


Log Collect Tool

Outline

A tool to collect operational status log of the host machine (Log Collector) will be provided as a means to analyze failure occurred in a field.

Operation log is collected using this tool when a service technician is requested to obtain the log by the Support Dept. of the sales company.

This tool runs on a PC connected to the machine with a USB Cable and collects operational status log in the machine.



NOTE:

Since the log collected by this tool is a log to be used for analysis by R&D, it is not necessary for the service technician to check the detail of it in the field.

CAUTION:

This tool does not recognize multiple machines at a time. Therefore, if multiple machines are connected to a PC with multiple USB ports, the tool does not work.

Only one machine should be connected to a PC with a USB Cable to use the tool.

Log File

The specifications of the log file are shown below.

- Log file name: It is recorded as "usb_yyyymmdd_hhmmss.log". (yyyymmdd_hhmmss indicates year, month, date, and time (hour, minute, second) when the log is collected.)
- Log file capacity: 300 KB or less
- Time required for collection: Approx. 10 seconds

Supported Languages

Languages supported by this tool are shown below.

- English
- Korean
- Japanese

What to Prepare

- Machine where the problem has occurred
- USB Cable (Connector shape: A-B)
- PC that meets the following conditions:
 - USB port is usable
 - One of the following OS should be running.
 - Windows Vista
 - Windows 7
 - Windows 8
 - Windows 8.1
 - Windows 10
- Tool (CanonLogCollector_Verx.x.x.x.zip) ^{*1}

*1. Follow the instruction of the Support Dept. of the sales company to obtain the tool. "x.x.x.x" indicates the version.


Operation Procedure

1. Be sure to turn OFF and then ON the power only once.

CAUTION:

Be sure to turn OFF and then ON the power only once before collecting logs. This transfers log information from the storage area to the log collection area. If the power is turned OFF and then ON twice, the data will be overwritten and necessary log data will be

2. Decompress the tool (CanonLogCollector_Verx.x.x.x.zip) on a directory with write permission on the PC. CanonLogCollector.exe is extracted in the decompressed folder.




3. Double-click to start CanonLogCollector.exe.

NOTE:


It is not necessary to install this tool and it can be executed in any location.

The CanonLogCollector screen appears and "There is one connected device." is displayed.




4. Click the [Start] button.

"Receiving log is successfully finished" is displayed.



5. Press the [Exit Program] button to quit the tool.
6. The collected log file is saved in the folder where CanonLogCollector.exe exists. Send it to the Support Dept. of the sales company.



CAUTION:

While the machine is in operation, log information is continually added. However, capacity of the machine's log storage area is not large, log information may be overwritten when a long time has passed. Therefore, be sure to collect the log as soon as possible.

■ Troubleshooting

The [Start] button is not activated

Remedy differs according to the displayed contents on the status line.

- "There is no connected device." is displayed.
Check the following possible causes and take necessary steps.
 - The connected machine has not been started
 - The USB Cable is not connected properly
 - The setting of USB connection is not correct
- "There are more than one connected device." is displayed
Machine other than the target machine is connected to the PC with a USB Cable. Disconnect the machine other than the target machine.

"Receiving log is finished. (Receive timeout.)" is displayed

If "Receiving log is finished. (Receive timeout.)" is displayed by pressing the [Start] button on the CanonLogCollector screen, the log data has not been properly sent from the machine to the PC.

When the log data has been properly sent, the file size will be 300 KB or less. However, if not, the size will be approx. 1 KB. If the size of a log file is about 1K, reconnect the USB Cable, or reconfigure the setting of USB Cable and collect log again. If the log cannot be collected again, turn OFF and then ON the main power of the machine.





Error/Jam/Alarm

| | |
|------------------|-----|
| Overview..... | 319 |
| Error Codes..... | 320 |
| Jam Codes..... | 322 |

Overview

This section describes codes shown in case any problem is occurred.
Since this product does not collect logs for alarms, no alarm code is shown.

| Code type | Description | Reference |
|------------|--|---|
| Error code | This code is displayed when a failure which impacts printing has occurred. | “Error Codes” on page 320 |
| Jam code | This code is displayed when a jam has occurred in this machine. | “Jam Codes” on page 322 |
| Alarm code | N/A | - |

Error Codes

| Code | | Detection description | Remedy |
|------|------|---|---|
| E000 | 0000 | Fixing Assembly does not start up within specified time. | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Check that the heater resistance measured between 1PIN and 2PIN of the cable (J101) on the DC Controller Board is in the following range. Replace the Fixing Assembly when the resistance value is abnormal. [1] 120 V machine - Heater resistance: $16.0 \Omega \pm 7\%$ [2] 230 V machines - Heater resistance: $53.8 \Omega \pm 7\%$ 2. Check the connection of connector (J101) on the DC Controller Board. 3. Check the connection of connector (J552) on DC Controller Board. 4. Replace the Fixing Assembly. 5. Replace the DC Controller Board. |
| E001 | 0000 | Abnormal high-temperature detection | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Check that the heater resistance measured between 1PIN and 2PIN of the cable (J101) on the DC Controller Board is in the following range. Replace the Fixing Assembly when the resistance value is abnormal. [1] 120 V machine - Heater resistance: $16.0 \Omega \pm 7\%$ [2] 230 V machines - Heater resistance: $53.8 \Omega \pm 7\%$ 2. Check the connection of connector (J101) on the DC Controller Board. 3. Check the connection of connector (J552) on DC Controller Board. 4. Replace the Fixing Assembly. 5. Replace the DC Controller Board. |
| E003 | 0000 | Abnormal low-temperature detection | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Check that the heater resistance measured between 1PIN and 2PIN of the cable (J101) on the DC Controller Board is in the following range. Replace the Fixing Assembly when the resistance value is abnormal. [1] 120 V machine - Heater resistance: $16.0 \Omega \pm 7\%$ [2] 230 V machines - Heater resistance: $53.8 \Omega \pm 7\%$ 2. Check the connection of connector (J101) on the DC Controller Board. 3. Check the connection of connector (J552) on DC Controller Board. 4. Replace the Fixing Assembly. 5. Replace the DC Controller Board. |
| E004 | 0000 | Fixing power supply drive circuit error | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Replace the DC Controller Board. 2. Replace the Fixing Assembly. |
| E100 | 0001 | Error detection on any of scanner motor, laser unit, and BD detection at scanner area. | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Replace the Laser Scanner Unit. 2. Replace the DC Controller Board. |
| E196 | 2000 | ROM read/write error (Error in storing each setting values for user mode / service mode / factory mode) | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Update the set of the Controller Firmware 2. Replace the Main Controller Board. |
| E202 | 0002 | Contact Image Sensor HP error, Failure in return | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Check the connection of Flat Cable between Main Controller Board (J5) and Contact Image Sensor. 2. Replace the Flat Cable between Main Controller Board (J5) and Contact Image Sensor. 3. Replace the Contact Image Sensor. 4. Replace the Main Controller Board. |
| E225 | 0001 | Light intensity of a lamp is less or equal to the criteria | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Check the connection of Flat Cable between Main Controller Board (J5) and Contact Image Sensor. 2. Replace the Flat Cable between Main Controller Board (J5) and Contact Image Sensor. 3. Replace the Contact Image Sensor. 4. Replace the Main Controller Board. |

| Code | | Detection description | Remedy |
|------|------|---|--|
| E301 | 0001 | Insufficient light intensity in shading | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Check the connection of Flat Cable between Main Controller Board (J5) and Contact Image Sensor. 2. Replace the Flat Cable between Main Controller Board (J5) and Contact Image Sensor. 3. Replace the Contact Image Sensor. 4. Replace the Main Controller Board. |
| E736 | 0000 | Communication error with CCU/modem, or no FAX board installed on FAX model. | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Check the connection of connectors between the Main Controller Board (J601, J602) and the FAX-NCU Board (J1201, J1204). 2. Replace the connectors between the Main Controller Board (J601, J602) and the FAX-NCU Board (J1201, J1204). 3. Replace the FAX-NCU Board. 4. Replace the Main Controller Board. |
| E740 | 0002 | Error detection on either Network Board or Mac address | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Check the connection of the network cable. 2. Replace the Main Controller Board. |
| E744 | 0002 | Language file error | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. Update the set of the Controller Firmware |
| | 4000 | Engine ID error (Invalid engine connection is detected) | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Check the DC Controller Board. 2. Update the Engine Firmware. 3. Update the set of the Controller Firmware |
| | 6000 | Communication error with Wireless LAN board. | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Replace the Wireless LAN Board. 2. Replace the Main Controller Board. |
| E760 | 0001 | The internal reset processing is not completed when print process error occurs. | Turn OFF/ON the power to reset the invalid internal data. |
| E806 | 0000 | Fan Motor cannot rotate at specified revolution speed. | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Replace the Main Fan Unit. 2. Replace the DC Controller Board. |
| E808 | 0001 | Fixing Assembly_Edge Left Cooling Fan error | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Replace the Edge Left Cooling Fan. 2. Replace the DC Controller Board. |
| E808 | 0002 | Fixing Assembly_Edge Right Cooling Fan error | When the same error repeatedly occurs after several times of turning the power OFF/ON, execute the following remedies. <ol style="list-style-type: none"> 1. Replace the Edge Right Cooling Fan. 2. Replace the DC Controller Board. |

Jam Codes

| Jam Codes | Cause |
|-------------------|-------------------------------------|
| Scanner Jam Codes | |
| 0001H | DES Sensor Delay |
| 0002H | DES Sensor Stationary |
| 0094H | Initial Stationary |
| 0095H | Pickup NG |
| 0071H | Timing Error |
| Printer Jam Codes | |
| 0004H | Re-pickup Delay Jam |
| 0005H | Multi-purpose Tray Pickup Delay Jam |
| 0008H | Pickup Stationary Jam |
| 000CH | Fixing Delivery Delay Jam |
| 0010H | Fixing Delivery Stationary Jam |
| 0014H | Internal Paper Jam |
| 0018H | Door Open Jam |
| 001CH | Wrap Jam |
| 0020H | Reversal Delay Jam |
| 0021H | Reversal Stationary Jam |



Service Mode


| | |
|---------------|-----|
| Overview..... | 324 |
| COPIER..... | 326 |
| FEEDER..... | 335 |
| FAX..... | 336 |
| TESTMODE..... | 348 |

Overview

Entering Service Mode.

Contact the sales company for the method to enter service mode.







Service Mode Menu



Screen flow of Service mode



| | 5 Line LCD model | 6 Line LCD model |
|--|-----------------------------|------------------|
| Initial / Category / Sub category screen | | |
| LCD | | |
| Select the item | : Up-arrow / down-arrow key | : Display Touch |
| Go to Sub category screen | : OK key | : Display Touch |
| Go to Initial screen | : Return key | : Return key |
| Item selection screen | | |

| | 5 Line LCD model | 6 Line LCD model |
|--|---|---|
| LCD |  |  |
| Select the item | : Up-arrow / down-arrow key | : Display Touch |
| Go to Setting screen | : OK key | : Display Touch |
| Go to Sub category screen | : Return key | : Return key |
| Input value screen | | |
| LCD |  |  |
| Enter the setting value | : numeric keypad | : numeric keypad |
| Increment the setting value one by one | : Up-arrow key | : Up-arrow key |
| Decrease the setting value one by one | : Down-arrow key | : Down-arrow key |
| Nullify the setting value | : Clear key | : numeric keypad [0] |
| Change the setting | : OK key | : Display Touch |
| Maintain the setting | : Return key | : Return key |
| How to input the switch setting value | | |
| LCD |  |  |
| Select the bit | : Right/Left-arrow key | : Right/Left-arrow key |
| Increment the setting value one by one | : Up-arrow key | : Up-arrow key |
| Decrease the setting value one by one | : Down-arrow key | : Down-arrow key |
| Change the setting | : OK key | : Display Touch |

COPIER

DISPLAY

VERSION

| COPIER > DISPLAY > VERSION | | |
|----------------------------|---|----------------------|
| Sub item | Description | Common to all models |
| MAIN | Display version/checksum of Bootable (Product program area) | Yes |
| BOOT | Display version/checksum of BootROM (Boot program area) | Yes |
| LANG | Display version/checksum of Language (Resource area) | Yes |
| ECONT | Display ROM version of recording engine | Yes |

ERR

| COPIER > DISPLAY > ERR | | |
|------------------------|---|----------------------|
| Sub item | Description | Common to all models |
| ERR | Error code display (for PESP) To display the error code and detail code of the system error. Up to 20 items | Yes |

JAM

| COPIER > DISPLAY > JAM | | |
|------------------------|--|----------------------|
| Sub item | Description | Common to all models |
| ERR | Jam history display (for PESP) To display the jam history of the printer and scanner. Up to 20 items | Yes |

CCD

| COPIER > DISPLAY > CCD | | | |
|------------------------|---|-----------|-------|
| Sub item | Description | ADF model | Other |
| FB-TARGET-B | Shading target value for BLUE of Reader Copyboard | Yes | Yes |
| FB-TARGET-G | Shading target value for GREEN of Reader Copyboard | Yes | Yes |
| FB-TARGET-R | Shading target value for RED of Reader Copyboard | Yes | Yes |
| FB-TARGET-BW | Shading target value of Reader Copyboard in black and white | Yes | Yes |
| DF-TARGET-B | Shading target value for BLUE of DF | Yes | No |
| DF-TARGET-G | Shading target value for GREEN of DF | Yes | No |
| DF-TARGET-R | Shading target value for RED of DF | Yes | No |
| DF-TARGET-BW | Shading target value of DF in black and white | Yes | No |



■ R-CON

| COPIER > I/O > R-CON | | | | |
|----------------------|-----|----------------------------|-----------|-------|
| Address | BIT | Contents of display | ADF model | Other |
| P001 | 0 | Sensor state display (DES) | Yes | No |
| | 1 | Sensor state display (DS) | Yes | No |



■ ADJ-XY

| COPIER > ADJUST > ADJ-XY | | | |
|--------------------------|---|-----------|-------|
| Sub item | Description | ADF model | Other |
| ADJ-X | Adjustment value of image reading start position (Horizontal scanning direction) (X direction) [Applicable case] When the reading position of vertical scanning direction in fixed reading is incorrect [Adjustment] <ul style="list-style-type: none"> Reduce the setting value when non-image width is larger than criteria. Increase the setting value when the area out of original area is copied. When increment the setting value by 1, the image reading start position is moved toward trailing edge by 0.1mm. Setting range: - 30 ~ 30 [Value after RAM clear: 0] | Yes | Yes |
| STRD-POS | Adjusting reading position in DF stream reading [Applicable case] When the reading position of vertical scanning direction in DF stream reading is incorrect [Adjustment] <ul style="list-style-type: none"> When increment the setting value by 1, image reading start position is moved toward leading edge by 0.1mm. Setting range: - 30 ~ 30 [Value after RAM clear: 0] | Yes | No |
| ADJ-X-MG | Fine adjustment (0.1% precision) of magnification ratio in Horizontal scanning direction in copyboard reading $\pm 3\%$ [Applicable case] When copy output image is larger or smaller than original image [Adjustment] Adjust by comparing the copy output and original. <ul style="list-style-type: none"> Increase the value when output image is smaller. Decrease the value when output image is larger. Setting range: - 30 ~ 30 [Factory default settings/ Value after RAM clear] 0 [Caution] This adjustment is targeted to adjust the image position on copy output. This may affect to the image of SCAN. | Yes | Yes |

■ CCD

| COPIER > ADJUST > CCD | | | |
|-----------------------|---|-----------|-------|
| Sub item | Description | ADF model | Other |
| W-PLT-X | Standard White Plate X signal data Setting range: 7000 to 9999 (Default value: 8493) | Yes | Yes |
| W-PLT-Y | Standard White Plate Y signal data Setting range: 7000 to 9999 (Default value: 8988) | Yes | Yes |

| COPIER > ADJUST > CCD | | | |
|-----------------------|---|-----------|-------|
| Sub item | Description | ADF model | Other |
| W-PLT-Z | Standard White Plate Z signal data Setting range: 7000 to 9999 (Default value: 9176) | Yes | Yes |
| FBTAR-R | Shading target value for RED in copyboard reading Setting range: 128 ~ 384 [Value after RAM clear: 290] | Yes | Yes |
| FBTAR-G | Shading target value for GREEN in copyboard reading Setting range: 128 ~ 384 [Value after RAM clear: 284] | Yes | Yes |
| FBTAR-B | Shading target value for BLUE in copyboard reading Setting range: 128 ~ 384 [Value after RAM clear: 278] | Yes | Yes |
| FBTAR-BW | Shading target value in copyboard black and white reading Setting range: 128 ~ 384 [Value after RAM clear: 301] | Yes | Yes |
| DFTAR-R | Shading target value for RED in DF reading Setting range: 128 ~ 384 [Value after RAM clear: 334] | Yes | No |
| DFTAR-G | Shading target value for GREEN in DF reading Setting range: 128 ~ 384 [Value after RAM clear: 323] | Yes | No |
| DFTAR-B | Shading target value for BLUE in DF reading Setting range: 128 ~ 384 [Value after RAM clear: 318] | Yes | No |
| DFTAR-BW | Shading target value in black and white reading Setting range: 128 ~ 384 [Value after RAM clear: 341] | Yes | No |

■ PANEL

| COPIER > ADJUST > PANEL | | | |
|-------------------------|--|--------------------|-------|
| Sub item | Description | Touch Panel models | Other |
| TOUCHCHK | To adjust the coordinate on the Touch Panel. | Yes | No |

FUNCTION

■ CLEAR

| COPIER > FUNCTION > CLEAR | | | | |
|---------------------------|----------|--|-----------|-------|
| Sub item | Item | Description | FAX model | Other |
| TEL-USER | | Clear the user data and the registered address data. SSSW is not cleared. When this service mode is executed, a message "REBOOTING..." is displayed on the Control Panel, and the host machine is automatically restarted. | Yes | Yes |
| SRVC-DAT | | SERVICE DATA is cleared. User data is not cleared. | Yes | Yes |
| HIST | ACT-HIST | Communication log is cleared. | Yes | No |
| | ACC-HIST | Each print log is cleared. | Yes | Yes |
| | JAM-HIST | JAM log is cleared. | Yes | Yes |
| | ERR-HIST | Error(E code) log is cleared. | Yes | Yes |
| PWD-CLEAR | | Password of the system administrator is cleared. | Yes | Yes |

| COPIER > FUNCTION > CLEAR | | | | |
|---------------------------|------|--|-----------|-------|
| Sub item | Item | Description | FAX model | Other |
| ALL | | <p>The following data are cleared.</p> <ul style="list-style-type: none"> • USER DATA • SERVICE DATA • JOB ID • Each log • CLEAR DATE • KEY LOG DATA <p>USER DATA/ SERVICE DATA are reset to the default location value. Appropriate values for LOCAL / SIZE-LC needs to be preset before executing of CLEAR -> ALL When this service mode is executed without setting the appropriate values for LOCAL / SIZE-LC, factory default settings are continued to use.</p> <p>When this service mode is executed, a message "REBOOTING..." is displayed on the Control Panel, and the host machine is automatically restarted.</p> | Yes | Yes |

■ MISC-R

| COPIER > FUNCTION > MISC-R | | |
|----------------------------|--|----------------------|
| Sub item | Description | Common to all models |
| SCANLAMP | Execution of lighting function for Scanning Lamp. (CIS LED R -> G -> B -> W -> OFF) | Yes |

■ MISC-P

● OUTPUT

When outputting the report, place paper in the Pickup Cassette, and remove paper from the Multi-purpose Tray. If paper is placed in the Multi-purpose Tray, the report is not output even if paper is placed in the Pickup Cassette.

| COPIER > FUNCTION > MISC-P | | | |
|----------------------------|---|-----------|-------|
| Sub item | Description | FAX model | Other |
| SRVC-DAT | To output the system data list/ system dump list as follows; | Yes | No |
| SYS-DAT | To output the system data list. Service software switches and parameters used in FAX function are mainly outputted. | Yes | No |
| SYS-DMP | To output the system dump list. Service data such as the number of communications, the number of receiving pages and sending pages, and the number of error are outputted. | Yes | No |
| CNTR | To output the counter report. Counter values of use trend for reading, storage, communications, and copy are displayed. | Yes | Yes |
| SPEC | To output the spec report. Current device status is printed out. | Yes | Yes |
| KEY-HIST | Output of the key log report To output the key log up to the time the transmission task was input (the [START] key was pressed). | Yes | No |

■ SYSTEM

| COPIER > FUNCTION > SYSTEM | | |
|----------------------------|---------------------------------|----------------------|
| Sub item | Description | Common to all models |
| DOWNLOAD | To switch to the download mode. | Yes |

■ PARAM

| COPIER > FUNCTION > PARAM | | | |
|---------------------------|--|-----------|-------|
| Sub item | Description | FAX model | Other |
| EXC-NAVI | <p>To switch of installation navigation.</p> <p>Setting value</p> <ul style="list-style-type: none"> • 0: Enable (Default) • 1: Disable <p>Set this switch to 1 after the termination of installation navigation.</p> <p>Installation navigation is not executed when this switch is 1 at next start-up.</p> <p>When this service mode is executed, a message "REBOOTING..." is displayed on the Control Panel, and the host machine is automatically restarted.</p> | Yes | No |

■ SPLMAN

| COPIER > FUNCTION > SPLMAN | | | |
|----------------------------|---|---------------|--------------|
| Sub item | Description | Simplex Model | Duplex Model |
| TOP-MPT | <p>Adjustment of leading edge margin when feeding from MP tray.</p> <p>Adjustment in: 0.1mm</p> <p>Setting range: 50 ~ 150 (Default value: 100)</p> | Yes | Yes |
| TOP-DUP-MPT | <p>Adjustment of leading edge margin on both sides/ back side when feeding from MP tray.</p> <p>Adjustment in: 0.1mm</p> <p>Setting range: 50 ~ 150 (Default value: 100)</p> | No | Yes |
| LEFT-MPT | <p>Adjustment of left margin when feeding from MP tray.</p> <p>Adjustment in: 0.1mm</p> <p>Setting range: 50 ~ 150 (Default value: 91)</p> | Yes | Yes |
| LEFT-DUP-MPT | <p>Adjustment of left margin on both sides/ back side when feeding from MP tray.</p> <p>Adjustment in: 0.1mm</p> <p>Setting range: 50 ~ 150 (Default value: 92)</p> | No | Yes |
| TOP-CST | <p>Adjustment of leading edge margin when feeding from cassette.</p> <p>Adjustment in: 0.1mm</p> <p>Setting range: 50 ~ 150 (Default value: 100)</p> | Yes | Yes |
| TOP-DUP-CST | <p>Adjustment of leading edge margin on both sides/ back side when feeding from cassette.</p> <p>Adjustment in: 0.1mm</p> <p>Setting range: 50 ~ 150 (Default value: 100)</p> | No | Yes |
| LEFT-CST | <p>Adjustment of left margin when feeding from cassette.</p> <p>Adjustment in: 0.1mm</p> <p>Setting range: 50 ~ 150 (Default value: 91)</p> | Yes | Yes |
| LEFT-DUP-CST | <p>Adjustment of left margin on both sides/ back side when feeding from cassette.</p> <p>Adjustment in: 0.1mm</p> <p>Setting range: 50 ~ 150 (Default value: 92)</p> | No | Yes |
| SPL14159 | <p>Fixation of USB device ID as "000000000000"</p> <p>0: OFF (Default)</p> <p>1: ON</p> | Yes | Yes |
| SPL27354 | For R&D use | - | - |
| SPL32620 | <p>PC-less update</p> <p>0: Disabled</p> <p>1: Enabled (Default)</p> | Yes | Yes |







■ BODY

| COPIER > OPTION > BODY | | | |
|------------------------|---|-----------|-------|
| Sub item | Description | ADF model | Other |
| DFDST-L2 | DF dust detection level threshold value (detection after completion of job) Setting range: 0 to 255 (Default value: 100) | Yes | - |
| LOCALE | To set country group. 1 : Japan 2 : North America 3 : Korea 4 : China 5 : Taiwan 6 : Europe 7 : Asia Setting range: 1 - 7 (Default value: Factory default) Execute the following service mode to enable this setting. COPIER > FUNCTION > CLEAR > ALL | Yes | Yes |
| ASLPMAX | To change the maximum value of the auto sleep time. 0 : 30 minutes (Default value) 1 : 240 minutes | Yes | Yes |
| NS-CMD5 | Restriction of the use of CRAM-MD5 authentication method at SMTP authentication 0: Dependent on the SMTP server (Default) 1: Not used | Yes | Yes |
| NS-PLN | Restriction of the use of PLAIN/LOGIN authentication, which is plaintext authentication, at SMTP authentication 0: Dependent on the SMTP server (Default) 1: Not used | Yes | Yes |
| NS-LGN | Restriction of the use of LOGIN authentication at SMTP authentication 0: Dependent on the SMTP server (Default) 1: Not used | Yes | Yes |
| SDTM-DSP | Setting of automatic shutdown menu display 0: Hide the menu 1: Display the menu | Yes | Yes |
| WLANPORT | Setting of whether to block transmission to/reception from an unnecessary port with port filter while Wi-Fi Direct is connected 0: Allow transmission to/reception from only the port used by Direct 1: Make the port status same as that of the port at wired side (not blocked) | Yes | Yes |
| SSLSTRNG | RC4 encryption 0: Normal mode (supported) 1: Secured mode (not supported) (Default) | Yes | Yes |

■ ACC

| COPIER > OPTION > ACC | | |
|-----------------------|---|----------------------|
| Sub item | Description | Common to all models |
| WLAN | Shows whether the Wireless LAN function is ON/OFF. 0: Forcibly turned OFF (The function is disabled even if the wireless LAN is installed.) 1: ON (Default value) | Yes |
| WLANMODE | Shows whether the Wireless LAN IEEE 802.11n standard is enabled/disabled. 0: Disabled 1: Enabled (Default value) | Yes |
| WLANSERIAL | Not in use | - |

■ SERIAL

| COPIER > OPTION > SERIAL | | |
|--------------------------|---|----------------------|
| Sub item | Description | Common to all models |
| SN-MAIN | <p>Enter the device serial number written on the rating name plate of the host machine.</p> <p><Input procedure></p> <ol style="list-style-type: none"> Write down the value in the "Location" field (blank by default) of System Management Settings from remote UI or local UI. -> In the field, the Controller PCB is replaced with a service part. Enter the serial number in "Location" of the system management settings, and confirm the serial number. [Menu] > [System Management Settings] > [Device Information Settings] > [Location] <div style="display: flex; justify-content: space-around;">   </div> <ol style="list-style-type: none"> Temporarily enter the serial number in "Location" (8 alphanumeric characters). Execute this service mode. Check that OK is displayed in COPIER > OPTION > SERIAL > SN-MAIN. <div style="display: flex; justify-content: space-around;">   </div> <p>After execution, turn OFF and then ON the power. Perform output only when the entered serial number is 8 alphanumeric characters. After output, the serial number entered in "Location" will be deleted.</p> <ol style="list-style-type: none"> After turning ON the power, check the serial number on the system management data list. Change the setting of "Location" back to the original value. (Enter the value you wrote down in step 1.) | Yes |

■ FNC-SW

| COPIER > OPTION > FNC-SW | | |
|--------------------------|--|----------------------|
| Sub item | Description | Common to all models |
| CRG-PROC | To set the operation performed when a cartridge reaches the end of life. 0: Not stopped (Default) 1: Stopped once 2: Completely stopped | Yes |
| CRGLF-K | Reference value for judging "Out" of the component other than toner (Drum/Developing Assembly/waste toner) included in the cartridge life (for Bk) Setting range: 0 to 200 (Default value: 100) | Yes |



■ TOTAL

| COPIER > COUNTER > TOTAL | | | | |
|--|---|----------------------|-----------|--------------|
| Display/ Setting/ Adjustment rage: 0 ~ 999,999 Return to 0 when exceeding 999,999. | | | | |
| Sub item | Description | Common to all models | FAX model | Duplex Model |
| SERVICE1 | Total counter 1 for service Count up when a paper is ejected from the machine (regardless of sizes such as large size and small size.) | Yes | | |
| SERVICE2 | Total counter 2 for service Count up when a paper is ejected from the machine (regardless of sizes such as large size and small size.) | Yes | | |
| TTL | Total counter (Copier + Printer + FAX + Combination) | Yes | | |
| COPY | Total copy counter Count up when a paper is ejected from the machine after execution of copy operation. | Yes | | |
| PDL-PRT | PDL printing counter Count up when PDL printing, ejecting a paper from the machine, and duplex stacking. Blank paper is also counted. Count up by 1 regardless of large or small. | Yes | | |
| FAX-PRT | FAX reception printing counter Count up when FAX reception printing, ejecting a paper from the machine, and duplex stacking. Blank paper is also counted. Count up by 1 regardless of large or small. It can be cleared. | | Yes | |
| RPT-PRT | Report printing counter Count up when report printing, ejecting a paper from the machine, and duplex stacking. Blank paper is also counted. Count up by 1 regardless of large or small. It can be cleared. | Yes | | |
| 2-SIDE | 2 sided copy/ print counter Count up the number of passing through the duplex path in copying/ printing when ejecting a paper from the machine and duplex stacking. Blank paper is also counted. Count up by 1 regardless of large or small. It can be cleared. | | | Yes |
| SCAN | Scanning counter Count up the number of scanning when scanning is completed. Count up by 1 regardless of large or small. It can be cleared. | Yes | | |

■ PICK-UP

| COPIER > COUNTER > PICK-UP | | | |
|--|--|---------------|--------------|
| Display/ Setting/ Adjustment rage: 0 ~ 999,999 Return to 0 when exceeding 999,999. | | | |
| Sub item | Description | Simplex Model | Duplex Model |
| C1 | Total counter of cassette 1 pickup Display the number of pages picked up from cassette 1. | Yes | Yes |
| MF | Total counter of multi-purpose tray pickup Display the number of pages picked up from multi-purpose tray. | Yes | Yes |
| 2-SIDE | Total counter of 2-sided pickup Display the number of pages by 2-sided pickup. | No | Yes |

■ FEEDER

| COPIER > COUNTER > FEEDER | | | |
|--|---|-----------|-------|
| Display/ Setting/ Adjustment rage: 0 ~ 999,999 Return to 0 when exceeding 999,999. | | | |
| Sub item | Description | ADF model | Other |
| FEED | Total counter of document pickup by ADF | Yes | No |

■ JAM

| COPIER > COUNTER > JAM | | | | |
|--|------------------------------------|----------------------|-----------|--------------|
| Display/ Setting/ Adjustment rage: 0 ~ 999,999 Return to 0 when exceeding 999,999. | | | | |
| Sub item | Description | Common to all models | ADF model | Duplex Model |
| TOTAL | Total jam counter | Yes | | |
| FEEDER | Total jam counter for feeder | | Yes | |
| 2-SIDE | Jam counter for duplex unit | | | Yes |
| MF | Jam counter for multi-purpose tray | Yes | | |
| C1 | Jam counter for cassette 1 | Yes | | |

FEEDER

ADJUST

| FEEDER > ADJUST | | | |
|-----------------|--|-----------|-------|
| Sub item | Description | ADF model | Other |
| DOCST | Adjustment of the page front reading position when using ADF(common in SADF model and DADF model). Setting range: -30 ~ 30 | Yes | No |
| LA-SPD | Adjustment of magnification ratio in vertical scanning direction in stream feeding. 0.1% precision Setting range: -30 ~ 30 | Yes | No |

FUNCTION

| FEEDER > FUNCTION | | | | |
|-------------------|--|------------|------------|-------|
| Sub item | Description | SADF model | DADF model | Other |
| FEED-CHK | Paper feeding test for only ADF Setting value 1: SADF 2: DADF | Yes | Yes | No |
| SL-ON | Operation start-up for solenoid The solenoid is operated only for 100 ms because the solenoid will burn if it is kept ON for a long period of time. | No | Yes | No |
| MTR-ON | Operation start-up for motor | Yes | Yes | No |
| FEED-ON | Paper feeding test for only ADF | Yes | Yes | No |

FAX

List of SSSW

- FAX model only

| FAX > SSSW | | |
|------------|---------|---|
| SSSW No. | Bit No. | Function |
| SW 01 | | (Errors, COPY functions) |
| | Bit 0 | Output error codes for service technicians |
| | Bit 1 | Error in memory dump |
| | Bit 2 | Enter the password for transferring received confidential image |
| | Bit 3 | Prohibit COPY |
| | Bit 4 | Display No. 300s |
| | Bit 5 | |
| | Bit 6 | Prohibit users from setting date/time |
| | Bit 7 | Collectively clear user setting prohibition |
| SW 02 | | (Setting for network connection criteria) |
| | Bit 0 | Do not start when memory clear list is unable to output |
| | Bit 1 | |
| | Bit 2 | |
| | Bit 3 | |
| | Bit 4 | V34 CCRTN OFF |
| | Bit 5 | |
| | Bit 6 | |
| SW 03 | | (Echo measures) |
| | Bit 0 | Check EQM of TCF |
| | Bit 1 | Apply echo protect tone to V.29 |
| | Bit 2 | |
| | Bit 3 | |
| | Bit 4 | Heard DIS twice |
| | Bit 5 | First DIS interference |
| | Bit 6 | Interfered DIS frequency |
| SW 04 | | (Measures against communication troubles) |
| | Bit 0 | Monitor LC |
| | Bit 1 | Check CI signal frequency |
| | Bit 2 | V21 end flag |
| | Bit 3 | Prohibit T.30 node F kept by both parties |
| | Bit 4 | T.30 node F echo timer |
| | Bit 5 | Check CI signal frequency when setting PBX |
| | Bit 6 | Do not send CNG for manual outgoing transmission |
| SW 05 | | (Standard functions, DIS signal setting) |
| | Bit 0 | |
| | Bit 1 | mm/inch conversion (text mode) |
| | Bit 2 | mm/inch conversion (text and picture / picture mode) |
| | Bit 3 | Prohibit DIS from transmitting bit33 and the followings. |
| | Bit 4 | Declare cut sheets |
| | Bit 5 | Declare LRT/LGL in DIS |
| | Bit 6 | Prohibit ECM outgoing transmission |
| SW 06 | | (Setting of reading criteria) |

| FAX > SSSW | | |
|------------|----------------|---|
| SSSW No. | Bit No. | Function |
| SW 06 | Bit 0 | Move from DES to pre-scan position |
| | Bit 1 | Pre-scan at time other than power-ON |
| | Bit 2 | Restrict document length |
| | Bit 3 | Stamp option |
| | Bit 4 | Reading width 0:A4 1: LTR |
| | Bit 5 | Record memory copy time sharing |
| | Bit 6 | Variable resolution at COPY |
| | Bit 7 | Half tone + super fine |
| SW 07 | | Not in use |
| SW 08 | | Not in use |
| SW 09 | | Not in use |
| SW 10 | | Not in use |
| SW 11 | | Not in use |
| SW 12 | | (Page timer setting) |
| | Bit 0 | 1 page timeout (outgoing transmission) |
| | Bit 1 | |
| | Bit 2 | 1 page timeout (HT transmission) |
| | Bit 3 | |
| | Bit 4 | 1 page timeout (incoming transmission) |
| | Bit 5 | |
| | Bit 6 | |
| Bit 7 | 1 page timeout | |
| SW 13 | | |
| | Bit 0 | Prohibit relay broadcasting / transfer while receiving relay / transfer |
| | Bit 1 | Response to faulty image while receiving relay / transfer |
| | Bit 2 | Convert mm/inch when transmitting received image |
| | Bit 3 | |
| | Bit 4 | |
| | Bit 5 | |
| | Bit 6 | |
| SW 14 | | |
| | Bit 0 | |
| | Bit 1 | Standard paper size type <NADA>COPIER > OPTION > BODY > MODEL-SZ |
| | Bit 2 | Convert inch to mm in both main/vertical scanning directions or only in vertical scanning direction |
| | Bit 3 | Convert inch to mm only for OCR transmission |
| | Bit 4 | Declare resolution for Inch series |
| | Bit 5 | |
| | Bit 6 | |
| SW 15 | | |
| | Bit 0 | |
| | Bit 1 | Polarity memory timing at dial-in |
| | Bit 2 | Receive incoming calls to ND circuit: device circuit |
| | Bit 3 | |
| | Bit 4 | |
| | Bit 5 | |
| | Bit 6 | Detect continuous signals when switching F/T |
| Bit 7 | | |
| SW 16 | | Not in use |
| SW 17 | | Not in use |
| SW 18 | | |
| | Bit 0 | Detect carrier disconnection between DCS and TCF |

| FAX > SSSW | | |
|------------|---------|---|
| SSSW No. | Bit No. | Function |
| SW 18 | Bit 1 | Waiting time for carrier disconnection between DCS and TCF |
| | Bit 2 | Prohibit communication control for IP network |
| | Bit 3 | |
| | Bit 4 | |
| | Bit 5 | |
| | Bit 6 | |
| | Bit 7 | |
| SW 19 | | Not in use |
| SW 20 | | Not in use |
| SW 21 | | Not in use |
| SW 22 | Bit 0 | Prohibit NSX transmission |
| | Bit 1 | Prohibit separated A4 record |
| | Bit 2 | Prohibit broadcasting transmission |
| | Bit 3 | Prohibit manual polling actions |
| | Bit 4 | Prohibit manual transmission when transmitting archives |
| | Bit 5 | |
| | Bit 6 | With archive transmission function |
| | Bit 7 | |
| SW 23 | | Not in use |
| SW 24 | | Not in use |
| SW 25 | | (Setting for report display function) |
| | Bit 0 | Prioritize the received telephone number to the dialed number |
| | Bit 1 | Prioritize the received abbreviated name to the dialed abbreviated name |
| | Bit 2 | Regard a received blank CIS as an unreceived CIS |
| | Bit 3 | Message language selection for user SW |
| | Bit 4 | |
| | Bit 5 | |
| | Bit 6 | |
| Bit 7 | | |
| SW 26 | | Not in use |
| SW 27 | | Not in use |
| SW 28 | Bit 0 | Prohibit calling party for V8 procedure |
| | Bit 1 | Prohibit called party from V8 procedure |
| | Bit 2 | Prohibit calling party from V8 late-start |
| | Bit 3 | Prohibit called party from V8 late-start |
| | Bit 4 | Prohibit V.34 called party from starting fallback |
| | Bit 5 | Prohibit V.34 calling party from starting fallback |
| | Bit 6 | |
| | Bit 7 | |
| SW 29 | | Not in use |
| SW 30 | Bit 0 | Support for 1284 device ID |
| | Bit 1 | |
| | Bit 2 | |
| | Bit 3 | |
| | Bit 4 | |
| | Bit 5 | New dial tone detection method |
| | Bit 6 | |
| | Bit 7 | |
| SW 31 | | Not in use |
| SW 32 | | |

| FAX > SSSW | | |
|------------|---------|----------------------------|
| SSSW No. | Bit No. | Function |
| SW 32 | Bit 0 | Canon/NTT NSX switching SW |
| | Bit 1 | |
| | Bit 2 | |
| | Bit 3 | |
| | Bit 4 | |
| | Bit 5 | 0:NCU2004 1:NCU2002 |
| | Bit 6 | |
| | Bit 7 | |
| SW 33 | | Not in use |
| SW 34 | | Not in use |
| SW 35 | | Not in use |
| SW 36 | | Not in use |
| SW 37 | | Not in use |
| SW 38 | | Not in use |
| SW 39 | | Not in use |
| SW 40 | | Not in use |
| SW 41 | | Not in use |
| SW 42 | | Not in use |
| SW 43 | | Not in use |
| SW 44 | | Not in use |
| SW 45 | | Not in use |
| SW 46 | | Not in use |
| SW 47 | | Not in use |
| SW 48 | | Not in use |
| SW 49 | | Not in use |
| SW 50 | | Not in use |

List of MENU

- FAX model only

| Menu switch registration mode | | |
|-------------------------------|--------------------------------------|---|
| No. | Parameter | Selection |
| 001 | Not in use | |
| 002 | Not in use | |
| 003 | Not in use | |
| 004 | Not in use | |
| 005 | ON/OFF of NL equalizer | 0: OFF 1: ON |
| 006 | Telephone line monitor | 0-3 0: DIAL 1: SERVICEMAN 1 2: SERVICEMAN 2 3: OFF |
| 007 | Transmission level (ATT) | 0-15 |
| 008 | Upper limit of V.34 modulation speed | 0-5 0: 3429BAUD 1: 3200BAUD 2: 3000BAUD 3: 2800BAUD 4: 2743BAUD 5: 2400BAUD |

| Menu switch registration mode | | |
|-------------------------------|--------------------------------|--|
| No. | Parameter | Selection |
| 009 | Upper limit of V.34 data speed | 0-13 0: 33.6kbps 1: 31.2 2: 28.8 3: 26.4 4: 24.0 5: 21.6 6: 19.2 7: 16.8 8: 14.4 9: 12.0 10: 9.6 11: 7.2 12: 4.8 13: 2.4 |
| 010 | Pseudo-CI signal frequency | 0-2 0: 50Hz 1: 25Hz 2: 17Hz |
| 011 | Not in use | |
| 012 | Not in use | |
| 013 | Not in use | |
| 014 | Not in use | |
| 015 | Not in use | |
| 016 | Not in use | |
| 017 | Not in use | |
| 018 | Not in use | |
| 019 | Not in use | |
| 020 | Not in use | |

List of NUM

- FAX model only

| Numeric parameter setting mode | | |
|--------------------------------|--|--|
| No. | Parameter | Allowable setting range |
| 001 | Not in use | |
| 002 | RTN transmission criteria X | 1 to 99% |
| 003 | RTN transmission criteria n | 2 to 99 times |
| 004 | RTN transmission criteria m | 1 to 99 lines |
| 005 | NCC pause (before ID code) | 1 to 60s |
| 006 | NCC pause (after ID code) | 1 to 60s |
| 007 | Not in use | |
| 008 | Not in use | |
| 009 | Not in use | |
| 010 | T.30 T0 timer | 55s principally |
| 011 | T.30 T1 timer (for incoming transmission) | 0 to 9999 (France=3500, Others=3000) |
| 012 | Maximum incoming lines | 0 to 65535 (line) 0: without limitation |
| 013 | T.30 EOL timer | 500 to 3000 (set to 55s by default) |
| 014 | Not in use | |
| 015 | Threshold between hooking and on-hook | 0 to 999 |
| 016 | Lead time to the first response when switching between FAX and TEL | 0 to 9 |
| 017 | Duration to activate pseudo-RBT cadence | 0 to 999 |
| 018 | Duration to deactivate pseudo-RBT cadence (short) | 0 to 999 |

| Numeric parameter setting mode | | |
|--------------------------------|---|---|
| No. | Parameter | Allowable setting range |
| 019 | Duration to deactivate pseudo-RBT cadence (long) | 0 to 999 |
| 020 | Duration to activate pseudo-ring cadence | 0 to 999 |
| 021 | Duration to deactivate pseudo-CI cadence (short) | 0 to 999 |
| 022 | Duration to deactivate pseudo-CI cadence (long) | 0 to 999 |
| 023 | CNG detection level when switching between FAX and TEL | 0 to 7 |
| 024 | Pseudo-RBT outgoing level when switching between FAX and TEL | 10 to 20 (100v), 0 to 20 (120, 230v) |
| 025 | CNG monitor duration while the answering device is activated | 0 to 999 |
| 026 | No signal detection level while the answering device is activated | 0 to 7 |
| 027 | Duration to detect preamble of V21 low-speed flag | 20 (*10ms) |
| 028 | Not in use | |
| 029 | Not in use | |
| 030 | Not in use | |
| 031 | Not in use | |
| 032 | Not in use | |
| 033 | Not in use | |
| 034 | Not in use | |
| 035 | Not in use | |
| 036 | Not in use | |
| 037 | Not in use | |
| 038 | Not in use | |
| 039 | Not in use | |
| 040 | Not in use | |
| 041 | Not in use | |
| 042 | Not in use | |
| 043 | Not in use | |
| 044 | Not in use | |
| 045 | Not in use | |
| 046 | Not in use | |
| 047 | Not in use | |
| 048 | Not in use | |
| 049 | Not in use | |
| 050 | Not in use | |
| 051 | Threshold to detect hook | 10 to 9999 |
| 052 | Not in use | |
| 053 | Set DTMF calling counts when receiving FAX remotely | 0 to 9999(*25) |
| 054 | Set BusyTone outgoing duration when using handset | 0 to 9999 |
| 055 | Not in use | |
| 056 | Not in use | |
| 057 | Not in use | |
| 058 | Not in use | |
| 059 | Not in use | |
| 060 | Not in use | |
| 061 | Not in use | |
| 062 | Not in use | |
| 063 | Not in use | |
| 064 | Not in use | |
| 065 | Not in use | |
| 066 | Not in use | |
| 067 | Not in use | |
| 068 | Not in use | |
| 069 | Not in use | |
| 070 | Not in use | |

| Numeric parameter setting mode | | |
|--------------------------------|------------------------------|-------------------------|
| No. | Parameter | Allowable setting range |
| 071 | Not in use | |
| 072 | Not in use | |
| 073 | Not in use | |
| 078 | Exclusive use of a developer | |
| 079 | Exclusive use of a developer | |
| 080 | Exclusive use of a developer | |

List of NCU

- FAX model only

■ TONE

- Setting of Tone Parameters

While "#NCU" is displayed, press "OK" key -> Select "#TONE" and press "OK" key so that it becomes tone parameter setting mode.

| Item | Function | Setting range |
|------|---------------------------------|-----------------|
| 001 | Tone signal sending time (PSTN) | 10 to 9999 (ms) |
| 002 | Minimum pause time (PSTN) | 10 to 9999 (ms) |

TONE/PULSE

■ PULSE

- Setting of Pulse Parameters

While "#NCU" is displayed, press "OK" key -> Select "#PULSE" and press "OK" key so that it becomes pulse parameter setting mode.

| Item | Function | Setting range |
|------|--------------------------|--------------------|
| FORM | Pulse digit format | 0 -> DP (N) |
| | | 1 -> DP (N+1) |
| | | 2 -> DP (10-N) |
| 001 | Pulse dial speed (10pps) | 5 to 300 (x0.1pps) |
| 002 | Pulse dial speed (20pps) | 5 to 300 (x0.1pps) |
| 003 | Pulse dial make ratio | 10 to 90 (%) |
| 004 | Minimum pause time | 10 to 9999 (ms) |

■ DIAL TONE

1. Bit switch

| Bit No. | Function | 1 | 0 |
|---------|---------------------------------|----------------------------|---|
| Bit 0 | Frequency detection method | Modem | Tonal counter |
| Bit 1 | | | |
| Bit 2 | Signal frequency | Changed | Not changed |
| Bit 3 | | | |
| Bit 4 | Judgment of intermittent signal | Start from valid ON signal | Start from either valid ON signal or OFF signal |
| Bit 5 | | | |
| Bit 6 | Signal form | Continuous | Intermittent |
| Bit 7 | Signal detection | Detected | Not detected |

2. Numeric value parameter

| Parameter No. | Function | Setting range |
|---------------|--------------------------------|-------------------|
| 001 | T0 timer | 0 to 9999 (x10ms) |
| 002 | T1 timer | 0 to 9999 (x10ms) |
| 003 | T2 timer | 0 to 9999 (x10ms) |
| 004 | T3 timer | 0 to 9999 (x10ms) |
| 005 | T4 timer | 0 to 9999 (x10ms) |
| 006 | Signal detection table | 0 to 16 |
| 007 | Signal detection level | 0 to 7 |
| 008 | Number of valid tone detection | 0 to 9999 (times) |

■ 2nd DLTN

1. Bit switch

| Bit No. | Function | 1 | 0 |
|---------|---------------------------------|----------------------------|---|
| Bit 0 | Frequency detection method | Modem | Tonal counter |
| Bit 1 | | | |
| Bit 2 | Signal frequency | Changed | Not changed |
| Bit 3 | | | |
| Bit 4 | Judgment of intermittent signal | Start from valid ON signal | Start from either valid ON signal or OFF signal |
| Bit 5 | | | |
| Bit 6 | Signal form | Continuous | Intermittent |
| Bit 7 | Signal detection | Detected | Not detected |

2. Numeric value parameter

| Parameter No. | Function | Setting range |
|---------------|--------------------------------|-------------------|
| 001 | T0 timer | 0 to 9999 (x10ms) |
| 002 | T1 timer | 0 to 9999 (x10ms) |
| 003 | T2 timer | 0 to 9999 (x10ms) |
| 004 | T3 timer | 0 to 9999 (x10ms) |
| 005 | T4 timer | 0 to 9999 (x10ms) |
| 006 | Signal detection table | 0 to 16 |
| 007 | Signal detection level | 0 to 7 |
| 008 | Number of valid tone detection | 0 to 9999 (times) |

■ BUSTONE0

1. Bit switch

| Bit No. | Function | 1 | 0 |
|---------|---------------------------------|----------------------------|---|
| Bit 0 | | | |
| Bit 1 | | | |
| Bit 2 | Signal frequency | Changed | Not changed |
| Bit 3 | | | |
| Bit 4 | Judgment of intermittent signal | Start from valid ON signal | Start from either valid ON signal or OFF signal |
| Bit 5 | | | |
| Bit 6 | Signal form | Continuous | Intermittent |
| Bit 7 | Signal detection | Detected | Not detected |

2. Numeric value parameter

| Parameter No. | Function | Setting range |
|---------------|--------------------------------|-------------------|
| 001 | | |
| 002 | T1 timer | 0 to 9999 (x10ms) |
| 003 | T2 timer | 0 to 9999 (x10ms) |
| 004 | T3 timer | 0 to 9999 (x10ms) |
| 005 | T4 timer | 0 to 9999 (x10ms) |
| 006 | Signal detection table | 0 to 16 |
| 007 | Signal detection level | 0 to 7 |
| 008 | Number of valid tone detection | 0 to 9999 (times) |

■ BUSTONE1

1. Bit switch

| Bit No. | Function | 1 | 0 |
|---------|---------------------------------|----------------------------|---|
| Bit 0 | | | |
| Bit 1 | | | |
| Bit 2 | Signal frequency | Changed | Not changed |
| Bit 3 | RBT signal detection | Detected | Not detected |
| Bit 4 | Judgment of intermittent signal | Start from valid ON signal | Start from either valid ON signal or OFF signal |
| Bit 5 | RBT signal check cycle | 1 cycle | 1/2 cycle |
| Bit 6 | Signal form | Continuous | Intermittent |
| Bit 7 | Signal detection | Detected | Not detected |

2. Numeric value parameter

| Parameter No. | Function | Setting range |
|---------------|--------------------------------|-------------------|
| 001 | | |
| 002 | T1 timer | 0 to 9999 (x10ms) |
| 003 | T2 timer | 0 to 9999 (x10ms) |
| 004 | T3 timer | 0 to 9999 (x10ms) |
| 005 | T4 timer | 0 to 9999 (x10ms) |
| 006 | Signal detection table | 0 to 16 |
| 007 | Signal detection level | 0 to 7 |
| 008 | Number of valid tone detection | 0 to 9999 (times) |

■ REORDRTN

1. Bit switch

| Bit No. | Function | 1 | 0 |
|---------|---------------------------------|----------------------------|---|
| Bit 0 | | | |
| Bit 1 | Signal detection method | FED | FR3 |
| Bit 2 | Signal frequency | Changed | Not changed |
| Bit 3 | | | |
| Bit 4 | Judgment of intermittent signal | Start from valid ON signal | Start from either valid ON signal or OFF signal |
| Bit 5 | | | |
| Bit 6 | Signal form | Continuous | Intermittent |
| Bit 7 | Signal detection | Detected | Not detected |

2. Numeric value parameter

| Parameter No. | Function | Setting range |
|---------------|--------------------------------|-------------------|
| 001 | | |
| 002 | T1 timer | 0 to 9999 (x10ms) |
| 003 | T2 timer | 0 to 9999 (x10ms) |
| 004 | T3 timer | 0 to 9999 (x10ms) |
| 005 | T4 timer | 0 to 9999 (x10ms) |
| 006 | Signal detection table | 0 to 16 |
| 007 | Signal detection level | 0 to 7 |
| 008 | Number of valid tone detection | 0 to 9999 (times) |

■ MULTI

1. Numeric value parameter

| Parameter No. | Function | Setting range |
|---------------|----------|---------------|
| 001 | | 0 to 9999 |
| 002 | | 0 to 9999 |
| 003 | | 0 to 9999 |
| 004 | | 0 to 9999 |

■ AUTO RX

1. Numeric value parameter

| Parameter No. | Function | Setting range |
|---------------|--------------------------|-------------------|
| 001 | CI ON time | 0 to 9999 (x10ms) |
| 002 | CI long off time | 0 to 9999 (x10ms) |
| 003 | CI off time | 0 to 9999 (x10ms) |
| 004 | CL long off time | 0 to 9999 (x10ms) |
| 005 | CI MAX off time | 0 to 9999 (x10ms) |
| 006 | CI wait time | 0 to 9999 (x10ms) |
| 007 | CI frequency | 0 to 9999 (cycle) |
| 008 | CI frequency lower limit | 0 to 9999 (Hz) |
| 009 | CI frequency upper limit | 0 to 9999 (Hz) |

■ CNGDTCT

1. Numeric value parameter

| Parameter No. | Function | Setting range |
|---------------|---|--|
| 001 | At F/T switching | CNG MIN ON time |
| 002 | | CNG MAX ON time |
| 003 | | |
| 004 | | |
| 005 | | |
| 006 | | Hit ratio |
| 007 | At direct connecting to answering phone | CNG MIN ON time |
| 008 | | CNG MAX ON time |
| 009 | | Tolerable time of instantaneous interruption |
| 010 | | |
| 011 | | Number of detection |
| 012 | | Hit ratio |

■ SPECIALB

- Not in use

■ SPECIALN

- Not in use

■ RKEY

1. Numeric value parameter

| Parameter No. | Function | Setting range |
|---------------|-----------------------------------|-------------------|
| 001 | Connection time of flash | 0 to 9999 (x10ms) |
| 002 | Connection time of grounding wire | 0 to 9999 (x10ms) |
| 003 | | |

■ PBXDIALT

1. Bit switch

| Bit No. | Function | 1 | 0 |
|---------|---------------------------------|----------------------------|---|
| Bit 0 | Frequency detection method | Modem | Tonal counter |
| Bit 1 | | | |
| Bit 2 | Signal frequency | Changed | Not changed |
| Bit 3 | | | |
| Bit 4 | Judgment of intermittent signal | Start from valid ON signal | Start from either valid ON signal or OFF signal |
| Bit 5 | | | |
| Bit 6 | Signal form | Continuous | Intermittent |
| Bit 7 | Signal detection | Detected | Not detected |

2. Numeric value parameter

| Parameter No. | Function | Setting range |
|---------------|--------------------------------|-------------------|
| 001 | T0 timer | 0 to 9999 (x10ms) |
| 002 | T1 timer | 0 to 9999 (x10ms) |
| 003 | T2 timer | 0 to 9999 (x10ms) |
| 004 | T3 timer | 0 to 9999 (x10ms) |
| 005 | T4 timer | 0 to 9999 (x10ms) |
| 006 | Signal detection table | 0 to 16 |
| 007 | Signal detection level | 0 to 9 |
| 008 | Number of valid tone detection | 0 to 9999 (times) |

■ PBXBUSYT

1. Bit switch

| Bit No. | Function | 1 | 0 |
|---------|---------------------------------|----------------------------|---|
| Bit 0 | | | |
| Bit 1 | | | |
| Bit 2 | Signal frequency | Changed | Not changed |
| Bit 3 | | | |
| Bit 4 | Judgment of intermittent signal | Start from valid ON signal | Start from either valid ON signal or OFF signal |
| Bit 5 | | | |
| Bit 6 | Signal form | Continuous | Intermittent |
| Bit 7 | Signal detection | Detected | Not detected |

2. Numeric value parameter

| Parameter No. | Function | Setting range |
|---------------|--------------------------------|-------------------|
| 001 | - | - |
| 002 | T1 timer | 0 to 9999 (x10ms) |
| 003 | T2 timer | 0 to 9999 (x10ms) |
| 004 | T3 timer | 0 to 9999 (x10ms) |
| 005 | T4 timer | 0 to 9999 (x10ms) |
| 006 | Signal detection table | 0 to 16 |
| 007 | Signal detection level | 0 to 9 |
| 008 | Number of valid tone detection | 0 to 9999 (times) |

TESTMODE

SYSTEM

■ DRAM

| TESTMODE > SYSTEM > DRAM | | |
|--------------------------|--|----------------------|
| Sub item | Description | Common to all models |
| TEST1 | Data read/write check for DRAM (except system work area) | Yes |

■ SPEAKER

| TESTMODE > SYSTEM > SPEAKER | | | |
|-----------------------------|---|-----------|-------------|
| Sub item | Description | FAX model | Other model |
| ON | When "ON" is selected, entry tone is generated once. | Yes | No |
| MIN | When "MIN" is selected, entry tone is generated once. | Yes | No |
| MAX | When "MAX" is selected, entry tone is generated once. | Yes | No |

SCAN

■ ADJUST

● ADF-ADJ

| TESTMODE > SCAN > ADJUST > ADF-ADJ | | | |
|------------------------------------|--|-----------|-------------|
| Sub item | Description | ADF model | Other model |
| DF-SPEED | Enter the adjustment value for the magnification ratio in vertical scanning direction in stream feeding Setting value: -30 ~ 30(Default value: 0) | Yes | No |
| DF-OFFSET | Enter for the adjustment of DF original stop position Setting value: -30 ~ 30(Default value: 0) | Yes | No |

■ SENSOR

| TESTMODE > SCAN > ADJUST > SENSOR | | |
|-----------------------------------|--|----------------------|
| Sub item | Description | Common to all models |
| TRAY PAPER SENSOR | Display the status of Multi Pickup Sensor 1: Paper existing 0: No paper | Yes |
| REGI SENS | Display the status of Leading Edge Sensor 1: Paper existing 0: No paper | Yes |
| ESS DOOR SENS | Display the status of Delivery Tray Open/ Close Switch 1: OPEN 0: CLOSE | Yes |

■ ADFTEST

| TESTMODE > SCAN > ADFTEST | | | | |
|---------------------------|---|------------|------------|-------------|
| Sub item | Description | SADF model | DADF model | Other model |
| SPEED | For testing of ADF feeding speed. Execute feeding test of ADF motor at specified speed. [Setting value] STDFAX, FINEFAX, SFINEFAX, RGB300dpi, RGB150dpi, Gray300dpi, Gray150dpi, Mono300dpi, Mono150dpi | Yes | Yes | No |
| 2-SIDE | Specify ON/OFF for duplex mode | No | Yes | No |
| COUNT | Page counter for originals: Existing | Yes | Yes | No |
| START | Start feeding | Yes | Yes | No |

■ BOOKFEED

| TESTMODE > SCAN > BOOKFEED | | |
|----------------------------|---|----------------------|
| Sub item | Description | Common to all models |
| PAGE | Display the number of bookfeed pages | Yes |
| SPEED | For testing of feeding speed. Execute feeding test of the book motor at specified speed. [Setting value] STDFAX, FINEFAX, SFINEFAX, RGB600dpi, RGB300dpi, RGB150dpi, Gray600dpi, Gray300dpi, Gray150dpi, Mono600dpi, Mono300dpi, Mono150dpi | Yes |
| START | Start of bookfeed | Yes |
| STOP | End of bookfeed | Yes |

FAX

■ MODEM


| TESTMODE > FAX > MODEM | | | |
|------------------------|---|-----------|-------------|
| Sub item | Description | FAX model | Other model |
| RELAY-1 | Test ON/OFF of port SW and relay on NCU Setting value: ON, OFF | Yes | No |
| FREQ | Transmit selected frequency in closed DC circuit using tone generation function of modem. [Setting values] 462Hz, 1100Hz, 1300Hz, 1500Hz, 1650Hz, 1850Hz, 2100Hz | Yes | No |
| G3TX | Transmit selected signal pattern in closed DC circuit at selected frequency using G3 signal transmission function of modem. [Setting values] 300bps, 2400bps, 4800bps, 7200bps, 9600bps, TC7200, TC9600, 12000bp, 14400bp | Yes | No |
| DTMFTX | Transmit DTMF signal using DTMF transmission function of modem after DC circuit closure. | Yes | No |
| V34G3TX | Transmit selected frequency using G3 signal transmission function (V.34) after DC circuit closure. [Setting values] SPEED : 2400bps*, 3429baud, 3200baud, 3000baud, 2800baud, 2743baud, 2400baud *: 2400bps, 4800bps, 7200bps, 9600bps, 12000bps, 14400bps, 16800bps, 19200bps, 21600bps, 24000bps, 26400bps, 28800bps, 31200bps, 33600bps | Yes | No |

■ FACULTY

| TESTMODE > FAX > FACULTY | | | |
|--------------------------|---|-----------|-------------|
| Sub item | Description | FAX model | Other model |
| G34800TX | Transmit the frequency of 4800bps using G3 signal transmission function after DC circuit closure. | Yes | No |
| DETECT1 | Ring detection Check the status (ON, OFF) of hook and Ci, Fc from i line. | Yes | No |
| DETECT2 | CNG detection test 1 Execute CNG signal check and FED check. Detect CNG after CML relay is ON. | Yes | No |
| DETECT3 | CNG detection test 2 Execute CNG signal check and FED check. Detect CNG after CML relay is OFF. | Yes | No |

● PANEL

| TESTMODE > FAX > PANEL | | |
|------------------------|--|------------------------|
| Sub item | Description | Common to all models |
| KEY CHECK START | Key check [Applicable case] Check if all keys functions normally after replacement of Control Panel. | Yes |
| LED CHECK START | LED check [Applicable case] Check if all LEDs are lit normally after replacement of Control Panel. | Yes |
| LCD CHECK START | LCD check [Applicable case] Check if LCD can display without any missing dot after replacement of Control Panel. | Yes |
| TOUCH CHECK START | Touch Panel check [Use case] To check if the Touch Panel can be used when replacing the Control Panel | Touch panel model only |




APPENDICES

| | |
|------------------------------|-----|
| Solvent/Oil List..... | 352 |
| General Circuit Diagram..... | 353 |
| General Timing Chart..... | 354 |
| Backup Data..... | 355 |

Solvent/Oil List


| Name | Usage | Remarks |
|---------------|---|--|
| Ethyl alcohol | Cleaning e.g.) Metal parts Grease Toner contamination | <ul style="list-style-type: none">• Local procurement• Keep fire away |
| Lubricant | <ul style="list-style-type: none">• Apply it on gears etc.• Apply it on shafts and shaft supports etc. | <ul style="list-style-type: none">• tool number: HY9-0007 (Dow Corning made Molykote EM-50L) |

General Circuit Diagram



General Timing Chart

Timing chart two consecutive prints on A4 paper



Backup Data

| Data | | Replace-ment | CLEAR | | | | | | | | | | | | | | | | | Backup | |
|----------------------------------|-----------------------------|--------------|------------------------|--------------|-----------------|-----------------|----------------|---------------|----------------|-------------------|---------------------------|-----------------------------------|--|---------------------------|-------------------------------|----------|----------|----------|-----------|--------|---------|
| | | | Menu > Initialize Menu | | | | | | | | | Menu > System Management Settings | | | COPIER > FUNCTION > CLEAR | | | | | User | Service |
| | | | Controller PCB*1 | Preferen-ces | Timer Set-tings | Common Settings | Copy Set-tings | Fax Set-tings | Scan Set-tings | Printer Set-tings | Adjust-ment/ Mainte-nance | Initialize All | Initialize System Management Set-tings | Initializing Address Book | Initialize All Data/ Settings | TEL-USER | SRVC-DAT | HIST *2 | PWD-CLEAR | ALL | Yes/No |
| Menu | Network Settings | Clear | - | - | - | - | - | - | - | - | - | Clear | - | Clear | Clear | - | - | - | Clear | No | No |
| | Preferen-ces | Clear | Clear | - | - | - | - | - | - | - | Clear | - | - | Clear | Clear | - | - | - | Clear | No | No |
| | Timer Set-tings | Clear | - | Clear | - | - | - | - | - | - | Clear | - | - | Clear | Clear | - | - | - | Clear | No | No |
| | Common Settings | Clear | - | - | Clear | - | - | - | - | - | Clear | - | - | Clear | Clear | - | - | - | Clear | No | No |
| | Copy Set-tings | Clear | - | - | - | Clear | - | - | - | - | Clear | - | - | Clear | Clear | - | - | - | Clear | No | No |
| | Fax Set-tings | Clear | - | - | - | - | Clear | - | - | - | Clear | - | - | Clear | Clear | - | - | - | Clear | No | No |
| | Scan Set-tings | Clear | - | - | - | - | - | Clear | - | - | Clear | - | - | Clear | Clear | - | - | - | Clear | No | No |
| | Printer Set-tings | Clear | - | - | - | - | - | - | Clear | - | Clear | - | - | Clear | Clear | - | - | - | Clear | No | No |
| | Adjustment/ Maintenance | Clear | - | - | - | - | - | - | - | Clear | Clear | - | - | Clear | Clear | - | - | - | Clear | No | No |
| | System Management Set-tings | Clear | - | - | - | - | - | - | - | - | - | Clear | - | Clear | Clear | - | - | Clear *3 | Clear *3 | No | No |
| | Initialize Menu | Clear | - | - | - | - | - | - | - | - | Clear | - | - | Clear | Clear | - | - | - | Clear | No | No |
| | Output Rprt. | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | No | No |
| Logs | Clear | - | - | - | - | - | - | - | - | - | - | - | Clear | - | - | Clear | - | Clear | No | No | |
| Reader / ADF Adjustment Settings | Clear | - | - | - | - | - | - | - | - | - | - | - | - | Clear | - | - | - | - | No | No | |
| Service Mode Settings | Clear | - | - | - | - | - | - | - | - | - | - | - | - | Clear | - | - | - | Clear | No | No | |
| Serial Number | Clear | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | No | No | |
| Address Book | Clear | - | - | - | - | - | - | - | - | Clear | - | Clear | Clear | Clear | - | - | - | Clear | Yes *4 | No | |

*1. Log data such as Mac address, USB serial number, printer-related setting values, scanner-related setting values, user data, and logs are initialized.

*2. The logs (print, jam, error, and alarm) are cleared.

*3. The system administrator ID and the password are changed back to the default values. <Manager ID: 7654321 / PIN: 7654321>

*4. Method: Remote UI, Location: PC