

SERVICE MANUAL

FIELD SERVICE

bizhub 160/160f **bizhub** 161/161f

Confidential – for internal use only, do not distribute

2005.04 KONICA MINOLTA BUSINESS TECHNOLOGIES, INC. Ver. 1.0

SAFETY AND IMPORTANT WARNING ITEMS

Read carefully the Safety and Important Warning Items described below to understand them before doing service work.

IMPORTANT NOTICE

Because of possible hazards to an inexperienced person servicing this product as well as the risk of damage to the product, KONICA MINOLTA BUSINESS TECHNOLOGIES, INC. (hereafter called the KMBT) strongly recommends that all servicing be performed only by KMBT-trained service technicians.

Changes may have been made to this product to improve its performance after this Service Manual was printed. Accordingly, KMBT does not warrant, either explicitly or implicitly, that the information contained in this Service Manual is complete and accurate.

The user of this Service Manual must assume all risks of personal injury and/or damage to the product while servicing the product for which this Service Manual is intended.

Therefore, this Service Manual must be carefully read before doing service work both in the course of technical training and even after that, for performing maintenance and control of the product properly.

Keep this Service Manual also for future service.

DESCRIPTION ITEMS FOR DANGER, WARNING AND CAUTION

In this Service Manual, each of three expressions " \triangle DANGER", " \triangle WARNING", and " \triangle CAUTION" is defined as follows together with a symbol mark to be used in a limited meaning.

When servicing the product, the relevant works (disassembling, reassembling, adjustment, repair, maintenance, etc.) need to be conducted with utmost care.

- heth DANGER: Action having a high possibility of suffering death or serious injury
- WARNING: Action having a possibility of suffering death or serious injury

CAUTION: Action having a possibility of suffering a slight wound, medium trouble, and property damage

Symbols used for safety and important warning items are defined as follows:



SAFETY WARNINGS

[1] MODIFICATIONS NOT AUTHORIZED BY KONICA MINOLTA BUSINESS TECHNOLOGIES, INC.

KONICA MINOLTA brand products are renowned for their high reliability. This reliability is achieved through high-quality design and a solid service network.

Product design is a highly complicated and delicate process where numerous mechanical, physical, and electrical aspects have to be taken into consideration, with the aim of arriving at proper tolerances and safety factors. For this reason, unauthorized modifications involve a high risk of degradation in performance and safety. Such modifications are therefore strictly prohibited. the points listed below are not exhaustive, but they illustrate the reasoning behind this policy.

F	Prohibited Actions		
	<u>A</u> DANGER		
•	Using any cables or power cord not specified by KMBT.	\bigcirc	
•	Using any fuse or thermostat not specified by KMBT. Safety will not be assured, leading to a risk of fire and injury.	\bigcirc	
•	Disabling fuse functions or bridging fuse terminals with wire, metal clips, solder or similar object.	\bigcirc	
•	Disabling relay functions (such as wedging paper between relay contacts)	\bigcirc	
•	Disabling safety functions (interlocks, safety circuits, etc.) Safety will not be assured, leading to a risk of fire and injury.	\bigcirc	Sold and the second sec
•	Making any modification to the product unless instructed by KMBT	\bigcirc	
•	Using parts not specified by KMBT	\bigcirc	

[2] POWER PLUG SELECTION

In some countries or areas, the power plug provided with the product may not fit wall outlet used in the area. In that case, it is obligation of customer engineer (hereafter called the CE) to attach appropriate power plug or power cord set in order to connect the product to the supply.



[3] CHECKPOINTS WHEN PERFORMING ON-SITE SERVICE

KONICA MINOLTA brand products are extensively tested before shipping, to ensure that all applicable safety standards are met, in order to protect the customer and customer engineer (hereafter called the CE) from the risk of injury. However, in daily use, any electrical equipment may be subject to parts wear and eventual failure. In order to maintain safety and reliability, the CE must perform regular safety checks.

1. Power Supply





Wiring

Never use multi-plug adapters to plug multiple power cords

If used, the risk of fire exists,

in the same outlet.

 When an extension cord is required, use a specified one. Current that can flow in the extension cord is limited, so using a too long extension cord may result in fire.

Do not use an extension cable reel with the cable taken up. Fire may result.

2. Installation Requirements

Prohibited Installation Places

🕂 WARNING

· Do not place the product near flammable materials or vola-

tile materials that may catch fire.

A risk of fire exists.

- Do not place the product in a place exposed to water such as rain.
 - A risk of fire and electric shock exists.

When not Using the Product for a long time

🔿 WARNING

· When the product is not used over an extended period of time (holidays, etc.), switch it off and unplug the power cord.

Dust collected around the power plug and outlet may cause fire.





Ventilation

- The product generates ozone gas during operation, but it will not be harmful to the human body.
 - If a bad smell of ozone is present in the following cases, ventilate the room.
 - a. When the product is used in a poorly ventilated room
 - b. When taking a lot of copies
 - c. When using multiple products at the same time

Stability

 Be sure to lock the caster stoppers.
 In the case of an earthquake and so on, the product may slide, leading to a injury.

Inspection before Servicing

Before conducting an inspection, read all relevant documentation (service manual, technical notices, etc.) and proceed with the inspection following the prescribed procedure, using only the prescribed tools. Do not make any adjustment not described in the documentation.

If the prescribed procedure or tool is not used, the product may break and a risk of injury or fire exists.

- Before conducting an inspection, be sure to disconnect the power plugs from the product and options.
 When the power plug is inserted in the wall outlet, some units are still powered even if the POWER switch is turned OFF. A risk of electric shock exists.
- The area around the fixing unit is hot. You may get burnt.











Work Performed with the Product Powered On

Take every care when making adjustments or performing an operation check with the product powered. If you make adjustments or perform an operation check with the external cover detached, you may touch live or high-voltage parts or you may be caught in moving gears or the timing belt, leading to a risk of injury.
Take every care when servicing with the external cover detached. High-voltage exists around the drum unit. A risk of electric shock exists.



Safety Checkpoints	
 Check electrode units such as a charging corona unit for deterioration and sign of leakage. Current can leak, leading to a risk of trouble or fire. 	0
 Before disassembling or adjusting the write unit (P/H unit) incorporating a laser, make sure that the power cord has been disconnected. The laser light can enter your eye, leading to a risk of loss of eyesight. 	
 Do not remove the cover of the write unit. Do not supply power with the write unit shifted from the specified mount- ing position. The laser light can enter your eye, leading to a risk of loss of eyesight. 	\bigcirc
 When replacing a lithium battery, replace it with a new lithium battery specified in the Parts Guide Manual. Dispose of the used lithium battery using the method specified by local authority. Improper replacement can cause explosion. 	
 After replacing a part to which AC voltage is applied (e.g., optical lamp and fixing lamp), be sure to check the installation state. A risk of fire exists. 	
 Check the interlock switch and actuator for loosening and check whether the interlock functions properly. If the interlock does not function, you may receive an electric shock or be injured when you insert your hand in the product (e.g., for clearing paper jam). 	
 Make sure the wiring cannot come into contact with sharp edges, burrs, or other pointed parts. Current can leak, leading to a risk of electric shock or fire. 	

Safety Checkpoints

Make sure that all screws, components, wiring, connectors, etc. that were removed for safety check and maintenance have been reinstalled in the original location. (Pay special attention to forgotten connectors, pinched cables, forgotten screws, etc.)



A risk of product trouble, electric shock, and fire exists.

Handling of Consumables

 Toner and developer are not harmful substances, but care must be taken not to breathe excessive amounts or let the substances come into contact with eyes, etc. It may be stimulative.

If the substances get in the eye, rinse with plenty of water immediately. When symptoms are noticeable, consult a physician.

• Never throw the used cartridge and toner into fire. You may be burned due to dust explosion.

Handling of Service Materials

• Unplug the power cord from the wall outlet.

Drum cleaner (isopropyl alcohol) and roller cleaner (acetone-based) are highly flammable and must be handled with care. A risk of fire exists.

 Do not replace the cover or turn the product ON before any solvent remnants on the cleaned parts have fully evaporated.

A risk of fire exists.

Handling of Service Materials

 Use only a small amount of cleaner at a time and take care not to spill any liquid. If this happens, immediately wipe it off.

A risk of fire exists.

 When using any solvent, ventilate the room well. Breathing large quantities of organic solvents can lead to discomfort.



[4] Laser Safety

 This is a digital machine certified as a Class 1 laser product. There is no possibility of danger from a laser, provided the machine is serviced according to the instruction in this manual.

4.1 Internal Laser Radiation

semiconductor laser			
Maximum power of the laser diode	15 mW		
Maximum average radiation power (*)	36.903 μW		
Wavelength	770-800 nm		

*at laser aperture of the Print Head Unit

- This product employs a Class 3b laser diode that emits an invisible laser beam. The laser diode and the scanning polygon mirror are incorporated in the print head unit.
- The print head unit is NOT A FIELD SERVICEABLE ITEM. Therefore, the print head unit should not be opened under any circumstances.



[5] Used Batteries Precautions

ALL Areas

CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

Germany

VORSICHT!

Explosionsgefahr bei unsachgemäßem Austausch der Batterie.

Ersatz nur durch denselben oder einen vom Hersteller empfohlenen gleichwertigen Typ. Entsorgung gebrauchter Batterien nach Angaben des Herstellers.

France

ATTENTION

Il y a danger d'explosion s'il y a remplacement incorrect de la batterie.

Remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

Denmark

ADVARSEL!

Lithiumbatteri - Eksplosionsfare ved fejlagtig håndtering.

Udskiftning må kun ske med batteri af samme fabrikat og type. Levér det brugte batteri tilbage til leverandøren.

Finland, Sweden

VAROITUS

Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

VARNING

Explosionsfara vid felaktigt batteribyte.

Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens instruktion.

Norway

ADVARSEL

Eksplosjonsfare ved feilaktig skifte av batteri.

Benytt samme batteritype eller en tilsvarende type anbefalt av apparatfabrikanten. Brukte batterier kasseres i henhold til fabrikantens instruksjoner.

U.S.A., Canada (CDRH Regulation)

- This machine is certified as a Class 1 Laser product under Radiation Performance Standard according to the Food, Drug and Cosmetic Act of 1990. Compliance is mandatory for Laser products marketed in the United States and is reported to the Center for Devices and Radiological Health (CDRH) of the U.S. Food and Drug Administration of the U.S. Department of Health and Human Services (DHHS). This means that the device does not produce hazardous laser radiation.
- The label shown on page S-16 indicates compliance with the CDRH regulations and must be attached to laser products marketed in the United States.

CAUTION

• Use of controls, adjustments or performance of procedures other than those specified in this manual may result in hazardous radiation exposure.

semiconductor laser		
Maximum power of the laser diode	15 mW	
Wavelength	770-800 nm	

All Areas

CAUTION

• Use of controls, adjustments or performance of procedures other than those specified in this manual may result in hazardous radiation exposure.

semiconductor laser		
Maximum power of the laser diode	15 mW	
Wavelength	770-800 nm	

Denmark

ADVARSEL

 Usynlig laserstråling ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling. Klasse 1 laser produkt der opfylder IEC60825-1 sikkerheds kravene.

halvlederlaser		
Laserdiodens højeste styrke	15 mW	
bølgelængden	770-800 nm	

Finland, Sweden

LUOKAN 1 LASERLAITE KLASS 1 LASER APPARAT

VAROITUS!

 Laitteen käyttäminen muulla kuin tässä käyttöohjeessa mainitulla tavalla saattaa altistaa käyttäjän turvallisuusluokan 1 ylittävälle näkymättömälle lasersäteilylle.

puolijohdelaser		
Laserdiodin suurin teho 15 mW		
aallonpituus	770-800 nm	

VARNING!

 Om apparaten används på annat sätt än i denna bruksanvisning specificerats, kan användaren utsättas för osynlig laserstrålning, som överskrider gränsen för laserklass 1.

halvledarlaser		
Den maximala effekten för laserdioden	15 mW	
våglängden	770-800 nm	

VARO!

 Avattaessa ja suojalukitus ohitettaessa olet alttiina näkymättomälle lasersäteilylle. Älä katso säteeseen.

VARNING!

 Osynlig laserstråining när denna del är öppnad och spärren är urkopplad. Betrakta ej stråien.

Norway

ADVERSEL

 Dersom apparatet brukes på annen måte enn spesifisert i denne bruksanvisning, kan brukeren utsettes för unsynlig laserstrålning, som overskrider grensen for laser klass 1.

halvleder laser		
Maksimal effekt till laserdiode	15 mW	
bølgelengde	770-800 nm	

5.1 Laser Safety Label

• A laser safety label is attached to the inside of the machine as shown below.



5.2 Laser Caution Label

• A laser caution label is attached to the outside of the machine as shown below.



5.3 PRECAUTIONS FOR HANDLING THE LASER EQUIPMENT

- When laser protective goggles are to be used, select ones with a lens conforming to the above specifications.
- When a disassembly job needs to be performed in the laser beam path, such as when working around the printerhead and PC Drum, be sure first to turn the printer OFF.
- If the job requires that the printer be left ON, take off your watch and ring and wear laser protective goggles.
- A highly reflective tool can be dangerous if it is brought into the laser beam path. Use utmost care when handling tools on the user's premises.
- The Print Head is not to be disassembled or adjusted in the field. Replace the Unit or Assembly including the Control Board. Therefore, remove the Laser Diode, and do not perform Control Board trimmer adjustment.

WARNING INDICATIONS ON THE MACHINE

Caution labels shown are attached in some areas on/in the machine.

When accessing these areas for maintenance, repair, or adjustment, special care should be taken to avoid burns and electric shock.



$\underline{\land}$ CAUTION:

 You may be burned or injured if you touch any area that you are advised not to touch by any caution label. Do not remove caution labels. If any caution label has come off or become dirty and therefore the caution cannot be read, contact our Service Office.



SERVICE MANUAL

FIELD SERVICE

bizhub 160/160f **bizhub** 161/161f Main Unit

Confidential - for internal use only, do not distribute

2005.04 KONICA MINOLTA BUSINESS TECHNOLOGIES, INC. Ver. 1.0

Confidential - for internal use only, do not distribute

After publication of this service manual, the parts and mechanism may be subject to change for improvement of their performance.

Therefore, the descriptions given in this service manual may not coincide with the actual machine.

When any change has been made to the descriptions in the service manual, a revised version will be issued with a revision mark added as required.

Revision mark:

- To indicate clearly a section revised, show \triangle to the left of the revised section. A number within \triangle represents the number of times the revision has been made.
- To indicate clearly a section revised, show **A** in the lower outside section of the corresponding page.

A number within **A** represents the number of times the revision has been made.

NOTE

Revision marks shown in a page are restricted only to the latest ones with the old ones deleted.

- When a page revised in Ver. 2.0 has been changed in Ver. 3.0: The revision marks for Ver. 3.0 only are shown with those for Ver. 2.0 deleted.
- When a page revised in Ver. 2.0 has not been changed in Ver. 3.0: The revision marks for Ver. 2.0 are left as they are.

2005/04	1.0		Issue of the first edition
Date	Service manual Ver.	Revision mark	Descriptions of revision

Confidential - for internal use only, do not distribute

Confidential - for internal use only, do not distribute

CONTENTS

General

1.	Syster	m configuration	. 1
2.	Produ	ct specifications	. 2
2.1	bizh	ub 160 / bizhub 161	. 2
2.1	.1	Main Unit	. 2
2.1	.2	GDI Printer Function (bizhub 160 only)	. 4
2.1	.3	PCL Printer Function (bizhub 161 only)	. 5
2.2	bizh	ub 160f / bizhub 161f	. 6
2.2	2.1	Main Unit	. 6
2.2	2.2	GDI Printer Function (bizhub 160f only)	. 8
2.2	2.3	PCL Printer Function (bizhub 161f only)	. 9
2.2	2.4	FAX Function	10

Maintenance

3.	Period	dical check	13
3.1	Mair	ntenance Items	13
3.1	1.1	Parts to be Replaced by Users (CRU)	13
3.1	1.2	Periodical Parts Replacement (Every 50,000 Print)	13
3.2	Mair	ntenance Parts	14
3.3	Con	cept of parts life	14
3.4	Mair	ntenance procedure (Periodical check parts)	15
3.4	4.1	Remove the Imaging Cartridge	15
3.4	1.2	Feed Roller	15
3.4	1.3	Replacement of the Image Transfer Roller	16
3.5	Rep	lacing the Unit	17
3.5	5.1	Replacement of the Toner Cartridge	17
3.5	5.2	Replacement of the Drum Cartridge	18
3.5	5.3	Replacement of the Fusing Unit	19
4.	Servi	ce tool	21
4.1	CE.	Tool List	21
4.2	Сор	y materials	21
4.2	2.1	Maintenance Kit	21
5.	Firmw	vare upgrade	22
5.1	Prep	parations for Firmware rewriting	22
5.2	Firm	nware rewriting	
5.2.1 Installing the Printer Driver/ TWAIN Driver Using Plug and Play			

160/160f	161/161f
bizhub	bizhub

5.2	2.2	Procedure for Upgrading the Firmware (Engine firmware/ Copier firmware/ FAX firmware/ PCL firmware)	23
5.2	2.3	Procedure for Upgrading the FAX Firmware (Upgrading Procedure Using Telephone Line from FAX Machine to FAX Machine)	25
53	Ron	nedv for a Failed I Indeting of the Firmware	26
5.4	Ren	nedy for a Failed Updating of the Firmware for PCI	20
0	(bizl	hub 161, bizhub 161f only)	28
6.	Other	·	30
6.1	Disa	assembly/Adjustment prohibited items	30
6.2	Disa	assembly/Assembly list (Other parts)	31
6.3	Disa	assembly/Assembly procedure	32
6.3	3.1	Identification of Exterior Parts and Removal Procedures for Them	32
6.3	3.2	Removal of Circuit Boards and Other Electrical Components	33
6.3	3.3	NIC Board (Option for bizhub 161/160f/161f)	34
6.3	3.4	NCU Board (bizhub 160f/161f only)	34
6.3	3.5	PCL Board (bizhub 161/161f only)	35
6.3	3.6	Controller/Mechanical Control Board	35
6.3	3.7	Control Panel	36
6.3	3.8	Interface Board	37
6.3	3.9	Plate NIC Board (Option for bizhub 161/160f/161f)	38
6.3	3.10	Power Unit	39
6.3	3.11	High Voltage Unit	42
6.3	3.12	IR Unit	42
6.3	3.13	PH Unit	43
6.3	3.14	Original Cover Set Sensor	44
6.3	3.15	Upper Cover Assy. (Original Glass)	44
6.3	3.16	Scanner Motor	45
6.3	3.17	Scanner Assy	45
6.3	3.18	Belt	46
6.3	3.19	 Main Motor	
6.3	3.20	Paper Empty Sensors	47
6.3	3.21	Paper Take-Un Solenoid	48
6.0	3 22	Paper Take-I In Clutch Gear	49
6.0	3.22	Torque Limiter	50
64	0.20 Onti	ion Counter	50 52
6.4	Ծքն 1 1	Bemoval of the Mechanical Counter	52
0		(Option for bizhub 160/161/160f/161f)	52

Adjustment/Setting

7.	How t	o use the adjustment section	53
8.	Status	s Mode	54
8.1	State	us Mode function tree	54
8.2	State	us Mode setting procedure	55
8.2	2.1	Procedure	55
8.2	2.2	Exiting procedure	55
8.2	2.3	Changing the Status Mode functions	55
8.2	2.4	TOTAL PAGE	56
8.2	2.5	TX/ RX RESULT (bizhub 160f/161f only)	56
8.2	2.6	PRINT REPORT (bizhub 161/160f/161f only)	57
9.	Utility	Mode (bizhub 160/bizhub 161)	64
9.1	Utilit	y Mode function tree	64
9.2	Utilit	y Mode setting procedure	65
9.2	2.1	Procedure	65
9.2	2.2	Exiting procedure	65
9.2	2.3	Changing the settings for Utility Mode functions	65
9.2	2.4	MACHINE SETTING	66
9.2	2.5	PAPER SOURCE SETUP	67
9.2	2.6	USER MANAGEMENT	68
9.2	2.7	COPY SETTING	68
9.2	2.8	NETWORK SETTING	69
10.	Utility	Mode (bizhub 160f/bizhub 161f)	71
10.1	Utilit	y Mode function tree	71
10.2	2 Utilit	y Mode setting procedure	74
10	.2.1	Procedure	74
10	.2.2	Exiting procedure	74
10	.2.3	Changing the settings for Utility Mode Functions	74
10	.2.4	MACHINE SETTING	75
10	.2.5	PAPER SOURCE SETUP	77
10	.2.6	USER MANAGEMENT	77
10	.2.7	ADMIN. MANAGEMENT	78
10	.2.8	COPY SETTING	80
10	.2.9	FAX REGISTRATION	81
10	.2.10	TX OPERATION	83
10	.2.11	RX OPERATION	85
10	.2.12	COMM. SETTING	91
10	.2.13	REPORTING	92

	10.2.14	INITIAL USER DATA	93
	10.2.15	NETWORK SETTING	94
	10.2.16	E-MAIL SETTING 1	96
	10.2.17	E-MAIL SETTING 2	97
	10.2.18	SCAN SETTING	99
11.	. Adjus	tment item list	100
12.	. Servi	ce Mode (bizhub 160/bizhub 161)	101
1	2.1 Serv	vice Mode function tree	101
1	2.2 Serv	vice Mode setting procedure	103
	12.2.1	Procedure	103
	12.2.2	Exiting procedure	103
	12.2.3	Changing the settings for Service Mode functions	103
1	2.3 Serv	vice Mode functions	104
	12.3.1	SERVICE'S CHOICE	104
	12.3.2	ADJUST	107
	12.3.3	COUNTER	115
	12.3.4	DISPLAY	117
	12.3.5	FUNCTION	118
	12.3.6	FIXED ZOOM CHANGE	120
	12.3.7	FACTORY TEST	120
	12.3.8	CLEAR DATA	121
13.	. Servi	ce Mode (bizhub 160f/bizhub 161f)	122
1	3.1 Serv	vice Mode function tree	122
1	3.2 Serv	vice Mode setting procedure	125
	13.2.1	Procedure	125
	13.2.2	Exiting procedure	125
	13.2.3	Changing the settings for Service Mode functions	125
1	3.3 Serv	vice Mode functions	126
	13.3.1	SERVICE'S CHOICE	126
	13.3.2	ADJUST	134
	13.3.3	COUNTER	142
	13.3.4	DISPLAY	144
	13.3.5	FUNCTION	145
	13.3.6	Soft Switch Function	147
	13.3.7	REPORT	148
	13.3.8	T.30 PROTOCOL LIST	152
	13.3.9	ADMIN. REGISTRATION (Administrator number registration)	153
	13.3.10	FIXED ZOOM CHANGE	154

13.3.11	FACTORY TEST	154
13.3.12	CLEAR DATA	154
14. Boar	d Switch	160
14.1 Nai	nes of control panel parts and their functions	160
14.1.1	bizhub 160/ bizhub 161	160
14.1.2	bizhub 160f/ bizhub 161f	161
14.2 Circ	cuit Board Locations	163
14.2.1	bizhub 160	163
14.2.2	bizhub 161	164
14.2.3	bizhub 160f	
14.2.4	bizhub 161f	165
14.3 Fur	nctions of switches and parts on PWBs	
14.3.1	PWB-P (Controller/Mechanical Control Board)	165
14.3.2	PWB-IF (Interface Board)	166
14.3.3	NCU (Network Control Unit Board)	166
14.3.4	PCL (PCL Controller Board)	166
14.3.5	NC-501: PWB- NIC (Network Interface Card Board)	167
14.3.6	NC-501: NIC-IF (Plate NIC Board)	
14.4 Adi	ustment of jumper switches on NCU board	
15. Secu	rity Mode	
15.1 Sec	curity Mode function tree	169
15.2 Sec	curity Mode setting procedure	169
15.2.1	Procedure	169
15.2.2	Exiting Procedure	169
15.3 Sec	curity Mode functions	169
15.3.1	MACHINE COUNTER	
16. Soft	Switch Set (bizhub 160f/bizhub 161f only)	170
16.1 Des	scription	170
16.2 Def	ault setting	171
16.2.1	Country for each Marketing area	171
16.3 Def	ault soft switch setting for each market area 1	172
16.4 Def	ault soft switch setting for each market area 2	174
16.5 Def	ault soft switch setting for each market area 3	176
16.6 Def	ault soft switch setting for each market area 4	178
16.7 Sof	t switch list	179
16.8 Sof	t switch definition	183
16.8.1	SOFT SWITCH: #01	183
16.8.2	SOFT SWITCH: #02	
16.8.3	SOFT SWITCH: #03	185

101

bizhub 160/160f	bizhub 161/161f	

16.8.4

16.8.5

16.8.6

16.8.7

16.8.8

16.8.9

COFT CMUTCUL #10

Appendix

10.8.10	SOFT SWITCH: #10
16.8.11	SOFT SWITCH: #11 192
16.8.12	SOFT SWITCH: #12 192
16.8.13	SOFT SWITCH: #13 193
16.8.14	SOFT SWITCH: #14 194
16.8.15	SOFT SWITCH: #15 194
16.8.16	SOFT SWITCH: #16 195
16.8.17	SOFT SWITCH: #17 195
16.8.18	SOFT SWITCH: #18 196
16.8.19	SOFT SWITCH: #19 197
16.8.20	SOFT SWITCH: #20 198
16.8.21	SOFT SWITCH: #21 199
16.8.22	SOFT SWITCH: #22
16.8.23	SOFT SWITCH: #23
16.8.24	SOFT SWITCH: #24
16.8.25	SOFT SWITCH: #25
16.8.26	SOFT SWITCH: #26
16.8.27	SOFT SWITCH: #27
16.8.28	SOFT SWITCH: #28
16.8.29	SOFT SWITCH: #29
16.8.30	SOFT SWITCH: #30
16.8.31	SOFT SWITCH: #31
16.8.32	SOFT SWITCH: #32
16.8.33	SOFT SWITCH: #33
16.8.34	SOFT SWITCH: #34
16.8.35	SOFT SWITCH: #35
16.8.36	SOFT SWITCH: #36
16.8.37	SOFT SWITCH: #37
16.8.38	SOFT SWITCH: #38
16.8.39	SOFT SWITCH: #39
16.8.40	SOFT SWITCH: #40

16.	8.41	SOFT SWITCH: #41
16.	8.42	SOFT SWITCH: #42
16.	8.43	SOFT SWITCH: #43
16.	8.44	SOFT SWITCH: #44
16.	8.45	SOFT SWITCH: #45
16.	8.46	SOFT SWITCH: #46
16.	8.47	SOFT SWITCH: #47
16.	8.48	SOFT SWITCH: #48
16.	8.49	SOFT SWITCH: #49
16.	8.50	SOFT SWITCH: #50
16.	8.51	SOFT SWITCH: #51
16.	8.52	SOFT SWITCH: #52
16.	8.53	SOFT SWITCH: #53
16.	8.54	SOFT SWITCH: #54
16.	8.55	SOFT SWITCH: #55
16.	8.56	SOFT SWITCH: #56
16.	8.57	SOFT SWITCH: #57
16.	8.58	SOFT SWITCH: #58
16.	8.59	SOFT SWITCH: #59 Part 1 223
16.	8.60	SOFT SWITCH: #59 Part 2
16.	8.61	SOFT SWITCH: #59 Part 3 225
16.	8.62	SOFT SWITCH: #60
16.	8.63	SOFT SWITCH: #61
16.	8.64	SOFT SWITCH: #62
16.	8.65	SOFT SWITCH: #63
16.	8.66	SOFT SWITCH: #64
17.	Fax P	rotocols
17.1	G3 I	ECM (G3 Error Correction Mode) 229
17.2	Line	control
17.	2.1	Procedure of G3 mode communication
17.3	Tabl	e of reference code
17.4	How	to analyze the T30 protocol monitor232

Troubleshooting

18.	Introduction	239
18.1	Overall Control Configuration	239
19.	Jam display	240
19.1	Misfeed Displays	240

Troubleshooting

19.1.1	Misfeed Display Resetting Procedure	240
19.2 Sen	isor layout	
19.3 Solu	ution	
19.3.1	Initial Check Items	242
19.3.2	Paper Take-Up/Transport Misfeed	
19.3.3	Fusing/Exit Misfeed	
20. Malfu	Inction code	245
20.1 Trou	uble code	245
20.1.1	Trouble code list	245
20.2 Solu	ution	247
20.2.1	C0045: Fuser Fan Motor Error	247
20.2.2	C0210: H.V. Abnormal	
20.2.3	C0500: Fuser Warm Up Error	
20.2.4	C0510: Fuser Temperature Low	249
20.2.5	C0520: Fuser Overheat	250
20.2.6	C0650: Scanner Home Sensor Error	250
20.2.7	C1200: ASIC Memory Abnormal	251
20.2.8	C1300: Polygon Mirror Motor Error	251
20.2.9	C133B: Communication with Option Error	252
20.2.10	C133C: Modem Error	252
20.2.11	C133D: ROM Checksum Error	253
20.2.12	C13F0: Laser Error	253
20.2.13	C1468: Parameter Chip Error	
20.2.14	C14A3: IR Lamp Malfunction	254
21. Powe	r supply trouble	255
21.1 Pow	ver is not turned ON.	255
22. Image	e quality problem	256
22.1 Trou	ubleshooting Image Quality Problems	256
22.2 Hov	v to Identify Problematic Part	256
22.2.1	Initial Check Items	256
22.3 Trou	ubleshooting for Specific Image Quality Problems	257
22.4 Solu	ution	258
22.4.1	Image Reading System: Blank or Black Prints	258
22.4.2	Image Reading System: Low Image Density	258
22.4.3	Image Reading System: Foggy Background or Rough Image	259
22.4.4	Image Reading System: Black Streaks or Bands	260
22.4.5	Image Reading System: Black Spots	261
22.4.6	Image Reading System: Blank Streaks or Bands	

22.4.7	Image Reading System: Uneven Image	263
22.4.8	Printer System: Blank or Black Prints	264
22.4.9	Printer System: Blank Spots	265
22.4.10	Printer System: Smears on Back	265
22.4.11	Printer System: Low Image Density	266
22.4.12	Printer System: Foggy Background	267
22.4.13	Printer System: Blank Streaks or Bands	267
22.4.14	Printer System: Black Streaks or Bands	268
22.4.15	Printer System: Offset Image	268
22.4.16	Printer System: Uneven Image	269
23. FAX	error (bizhub 160f/bizhub 161f only)	270
23.1 Cor	mmunication Error	270
23.1.1	Outline	270
23.1.2	Error occurring during transmission	270
23.1.3	Error occurring during reception	270
23.2 Erro	or Code	271
23.2.1	Reception	271
23.2.2	Transmission	273

Appendix

24. Parts layout drawing	277
24.1 Main Unit	
24.2 DF-501 (Option)	
24.3 PF-501 (Option)	
25. Connector layout drawing	
25.1 Main Unit	

Blank page

General

1. System configuration



- [1] Automatic Document Feeder DF-501
- [2] Original Cover OC-503
- [3] Main Unit bizhub 160, bizhub 160f, bizhub 161, bizhub 161f
- [4] Paper Feed Cassette PF-501

- [5] Mechanical Counter MC-502
- [6] Expansion memory (32 MB) EM-101
- [7] NIC NC-501 - Plate NIC Board
- [8] Internet Fax & Network Scan kit SU-502

2. Product specifications

2.1 bizhub 160 / bizhub 161

2.1.1 Main Unit

Туре	Desktop
Original scanning system	Scanning in main scanning direction with a 3-line color CCD sensor, and scanning in sub-scanning direction with unit scanning and sheet feed- through system
Photo conductor type	OPC (Organic Photo conductor)
Copying system	Electrostatic dry Powdered image transfer to plain paper with laser
Resolution	Scan: 600 dpi × 600 dpi Write: 600 dpi × 600 dpi
Paper feed-in system	2-Way system (Tray1 and Bypass Tray) *3-Way system is possible if optional PF-501 (Tray2) is installed.
Exposure system	Unit scanning slit exposure
Developing system	FMT (Fine Micro Toning) single component developing
Drum-charging system	Rotating brush with pre-charge film
Image transfer system	Roller transfer
Paper separation system	Curvature separation + Charge Neutralizing needle
Fusing system	Heat roller
Max. Original size	Up to A4 or 8.5 \times 14 (Legal)
Memory Capacity	STD: 16 MB *48 MB Maximum with 32 MB Option Memory (EM-101)

Copy Medium

Paper source		Tray1	Bypass Tray	Tray2
Type Plain paper (60 to 90 g/m ² , 16 to 24 lb)		A4, A5, B5, 8.5 × 14 (Legal),		A4, 8.5 × 11 (Letter)
Recycled paper (60 to 90 g/m ² , 16 to 24 lb) Special paper (91 to 163 g/m ² , 24 to 43 lb Transparencies	Recycled paper (60 to 90 g/m ² , 16 to 24 lb)	8.5 × 11 (Letter), 5.5 × 8.5 (Half Letter), FLS, 16K		
	Special paper (91 to 163 g/m ² , 24 to 43 lb)	Custom size: Max. 216 × 350 Min. 105 × 149	6 μμ	-
	Transparencies	Will1. 105 × 140	μμ	-
	Label sheets			-
	Envelopes			_

NOTE

The dimension for Tray2 is fixed at A4 or Letter.

2

Continuous copy speed (copies/min.)	12 copies/minute (at full size and 600 dpi × 300 dpi, with ADF)
Continuous print speed (sheets/min.)	More than 16 sheets/minute (with plain A4R or Letter R paper)
Warm-up time	Less than 25 seconds (at a room temperature of 23 °C and at the rated voltage)
First print time	16 seconds or less (at full size and 600 dpi \times 300 dpi, with plain A4R or Letter R paper)
First copy time	13 seconds or less (at full size and 600 dpi × 300 dpi, with plain A4R or Letter R paper) *If the Start key is pressed more than 3 seconds after opening and clos- ing the Original Cover or Auto Document Feeder after the engine has warmed up.

Zoom Ratios

		Metric Size	Inch Size
Fixed	Full size	×1.00	×1.00
	Enlargement	×1.15	×1.29
		×1.41	×1.54
		×2.00	×2.00
		×4.00	×4.00
	Reduction	×0.81	×0.78
		×0.70	×0.64
		×0.50	×0.50
		×0.25	×0.25
Variable	×0.2	5 to ×4.00 (in ×0.01 inc	rements)

Lens	Through lens (F=5.0, f=27.195)
Exposure Lamp	Cold Cathode Florescent Lamp
Fusing temperature	200 °C

Power /Current Consumption (main unit only)

Voltage	Maximum power consumption
110 V, 120-127 V	720, 820-880 W
220-240 V	740-850 W

Power source	110 V, 120V-127 V, 220-240 V 50/60 Hz
Main unit dimensions (including Original Cover)	Width508 mm (20 inch) Depth608 mm (24 inch) Height408 mm (16 inch)
Main unit weight	14.9 kg (32.75 lb)
2.1.2 GDI Printer Function (bizhub 160 only)

RAM	Share with copier.
Interfaces	IEEE 1284 (Parallel),
	USB Revision 1.1 (except for Windows NT)
Printer Language	GDI
Fonts	Windows
Supported Operating Systems	Windows XP (SP2 or later), Windows server 2003, Windows 2000 (SP4 or later), Windows NT Workstation Version 4.0 (SP6a or later), Windows Me, Windows 98 (SP1), Windows 98 Second Edition
Web Browser	Internet Explorer 4.0 or later, Netscape navigator 4.0 or later

2.1.3 PCL Printer Function (bizhub 161 only)

Memory capacity	32MB (on board for image processing).	
	16MB (on board for file system, input buffer).	
	64MB/ 128MB (optional, standard DIMM for file system. PC133 is recommended)	
Interfaces	IEEE 1284 (Parallel), USB Revision 1.1 (except for Windows NT)	
Printer Language	PJL, PCL5e, PCL-XL 2.1 PCL6 printer controller switches the PDL by PJL command.	
Download Fonts	PCL6 printer controller supports two kinds of download font format. Bitmap font format/ True type font format	
Resident Font & Symbol Set	8 bitmap font (Standard), 45 scale font (Standard) Symbol Set List (Total 36) ISO 8859-1 Latin1/ ISO 8859-2 Latin2/ ISO 8559-9 Latin5/ISO 4/ ISO 6/ ISO 11/ ISO 15/ ISO 17/ ISO 21/ ISO 60/ ISO 69/ PC-8/ PC Turkish / PC- 8 Danish/ Norwegian/ PC-850 /PC-852 / PC-856 (PC-Cyrillic)/ Ventura International/ Ventura US/ Ventura Math/ Windows 3.0 Latin 1 80H/ Win- dows 3.1 Latin 1 80H/ Windows 3.1 Latin 2 80H/ Windows 3.1 Latin 5 80H/ Windows 3.1 Baltic 80H/ PS Text/ PS Math/ PI Font/ Roman-8/ Desktop/ Microsoft Publishing/ Math-8/ MC Text ODBH/ Legal/ Symbol/ Wingdings Typeface List (Total 53) Courier/ CG Times/ CG Times Bold/ CG Times Italic/ CG Omega Bold Italic/ CG Omega/ CG Omega Bold/ CG Omega Italic/ CG Omega Bold Italic/ Coronet/ Clarendon Condensed/ Univers Medium Univers Bold/ Univers Medium Italic/ Univers Bold Italic/ Univers Bold Condensed Italic/ Antique Olive Antique Olive Bold/ Antique Olive Italic/ Garamond Antiqua/ Garamond Halbfett/ Garamond Kursiv/ Gara- mond Kursiv Halbfelt/ Marigold/ Albertus Medium/ Abertus Extra Bold/ Arial/ Arial Bold/ Arial Italic/ Times New Bold Italic/ Symbol/ Wingdings/ Cou- rier Bold/ Courier Italic/ Courier Bold Italic/ Symbol/ Wingdings/ Cou- rier Bold/ Courier Italic/ Courier Bold Italic/ Letter Gothic/	
Resident Font & Symbol Set	Letter Gothic Bold/ Letter Gothic Italic/ Line Printer (ISO 8859-1 Latin1)/ Line Printer (Leagal)/ Line Printer (Roman-8)/ Line Printer (PC-8 Danish/ Norwegian)/ Line Printer (PC-850)/ Line Printer (ISO 8859-2 Latin 2)/ Line Printer (ISO 8859-9 Latin5)/ Line Printer (PC-8)	
Supported Operating Systems	Windows XP, Windows server 2003, Windows 2000, Windows NT4.0 (SP6a or later: USB not supported), Windows Me, Windows 98 Second Edition	

2.2 bizhub 160f / bizhub 161f

2.2.1 Main Unit

Туре	Desktop
Original scanning system	Scanning in main scanning direction with a 3-line color CCD sensor, and scanning in sub-scanning direction with unit scanning and sheet feed- through system
Photo conductor type	OPC (Organic Photo conductor)
Copying system	Electrostatic dry Powdered image transfer to plain paper with laser
Resolution	Scan: 600 dpi × 600 dpi Write: 600 dpi × 600 dpi
Paper feed-in system	2-Way system (Tray1 and Bypass Tray) *3-Way system is possible if optional PF-501 (Tray2) is installed.
Exposure system	Unit scanning slit exposure
Developing system	FMT (Fine Micro Toning) single component developing
Drum-charging system	Rotating brush with pre-charge film
Image transfer system	Roller transfer
Paper separation system	Curvature separation + Charge Neutralizing needle
Fusing system	Heat roller
Max. Original size	Up to A4 or 8.5×14 (Legal)
Memory Capacity	STD: 16 MB (48 MB Maximum with 32 MB Option Memory)

Copy Medium

Paper source		Tray1	Bypass Tray	Tray2
Туре	Plain paper (60 to 90 g/m ² , 16 to 24 lb)	A4, A5, B5, 8.5 × 14 (Legal),		A4, 8.5 × 11 (Letter)
Recycled paper (60 to 90 g/m ² , Special paper (91 to 163 g/m ² Transparencies Label sheets	Recycled paper (60 to 90 g/m ² , 16 to 24 lb)	8.5 × 11 (Letter), 5.5 × 8.5 (Half Letter), FLS, 16K		
	Special paper (91 to 163 g/m ² , 24 to 43 lb)	Custom size: Max. 216 × 356 μμ	μμ	-
	Transparencies	Wii11. 105 × 146	μμ	-
	Label sheets			_
	Envelopes			-

NOTE

The dimension for Tray2 is fixed at A4 or Letter.

Continuous copy speed (copies/min.)	12 copies/minute (at full size and 600 dpi × 300 dpi)
Continuous print speed (sheets/min.)	More than 16 sheets/minute (with plain A4R or Letter R paper)
Warm-up time	Less than 25 seconds (at a room temperature of 23 °C and at the rated voltage)
First print time	16 seconds or less (at full size and 600 dpi \times 300 dpi, with plain A4R or Letter R paper)
First copy time	13 seconds or less (at full size and 600 dpi × 300 dpi, with plain A4R or Letter R paper) *If the Start key is pressed more than 3 seconds after opening and clos- ing the Original Cover or Auto Document Feeder after the engine has warmed up.

Zoom Ratios

		Metric Size	Inch Size
Fixed	Full size	×1.00	×1.00
	Enlargement	×1.15	×1.29
		×1.41	×1.54
		×2.00	×2.00
		×4.00	×4.00
	Reduction	×0.81	×0.78
		×0.70	×0.64
		×0.50	×0.50
		×0.25	×0.25
Variable	×0.25 to ×4.00 (in ×0.01 increments)		

Lens	Through lens (F=5.0, f=27.195)
Exposure Lamp	Cold Cathode Florescent Lamp
Fusing temperature	200 °C

Power /Current Consumption (main unit only)

Voltage	Maximum power consumption
110 V, 120-127 V	700, 770-880 W
220-240 V	740-830 W

Power source	110 V, 120V-127 V, 220-240 V 50/60 Hz
Dimensions (including Automatic Document Feeder)	Width508 mm (20 inch) Depth608 mm (24 inch) Height468 mm (16 inch)
Weight (including Automatic Document Feeder)	17.3 kg (38.25 lb)

2.2.2 GDI Printer Function (bizhub 160f only)

RAM	Share with copier.
Interfaces	IEEE 1284 (Parallel),
	USB Revision 1.1 (except for Windows NT)
Printer Language	GDI
Fonts	Windows
Supported Operating Systems	Windows XP (SP2 or later), Windows server 2003, Windows 2000 (SP4 or later), Windows NT Workstation Version 4.0 (SP6a or later), Windows Me, Windows 98 (SP1), Windows 98 Second Edition
Web Browser	Internet Explorer 4.0 or later, Netscape navigator 4.0 or later

2.2.3	PCL Printer Function (bizhub 161f only)
-------	---

Memory capacity	32MB (on board for image processing).	
	16MB (on board for file system, input buffer).	
	64MB/ 128MB (optional, standard DIMM for file system. PC133 is recommended)	
Interfaces	IEEE 1284 (Parallel), USB Revision 1.1 (except for Windows NT)	
Printer Language	PJL, PCL5e, PCL-XL 2.1 PCL6 printer controller switches the PDL by PJL command.	
Download Fonts	PCL6 printer controller supports two kinds of download font format. Bitmap font format/ True type font format	
Resident Font & Symbol Set	Symbol Set List (Total 36) ISO 8859-1 Latin1/ ISO 8859-2 Latin2/ ISO 8559-9 Latin5/ISO 4/ ISO 6/ ISO 11/ ISO 15/ ISO 17/ ISO 21/ ISO 60/ ISO 69/ PC-8/ PC Turkish / PC- 8 Danish/ Norwegian/ PC-850 /PC-852 / PC-856 (PC-Cyrillic)/ Ventura International/ Ventura US/ Ventura Math/ Windows 3.0 Latin 1 80H/ Windows 3.1 Latin 1 80H/ Windows 3.1 Latin 2 80H/ Windows 3.1 Latin 5 80H/ Windows 3.1 Baltic 80H/ PS Text/ PS Math/ PI Font/ Roman-8/ Desktop/ Microsoft Publishing/ Math-8/ MC Text ODBH/ Legal/ Symbol/ Wingdings Typeface List (Total 53) Courier/ CG Times/ CG Times Bold/ CG Times Italic/ CG Omega Bold Italic/ CG Omega/ CG Omega Bold/ CG Omega Italic/ CG Omega Bold Italic/ Coronet/ Clarendon Condensed/ Univers Medium/ Univers Bold/ Univers Medium Italic/ Univers Bold Italic/ Univers Bold/ Univers Bold Condensed/ Univers Medium Condensed/ Univers Bold Condensed/ Univers Medium Condensed/ Univers Bold Condensed Italic/ Antique Olive Bold/ Antique Olive Italic/ Garamond Antiqua/ Garamond Halbfett/ Garamond Kursiv/ Gara- mond Kursiv Halbfelt/ Marigold/ Albertus Medium/ Abertus Extra Bold/ Arial/ Arial Bold/ Arial Italic/ Times New Bold Italic/ Symbol/ Wingdings/ Cou- rier Bold/ Courier Italic/ Courier Bold Italic/ Letter Gothic/	
Resident Font & Symbol Set	Letter Gothic Bold/ Letter Gothic Italic/ Line Printer (ISO 8859-1 Latin1)/ Line Printer (Leagal)/ Line Printer (Roman-8)/ Line Printer (PC-8 Danish/ Norwegian)/ Line Printer (PC-850)/ Line Printer (ISO 8859-2 Latin 2)/ Line Printer (ISO 8859-9 Latin5)/ Line Printer (PC-8)	
Supported Operating Systems	Windows XP, Windows server 2003, Windows 2000, Windows NT4.0 (SP6a or later: USB not supported), Windows Me, Windows 98 Second Edition	

2.2.4 FAX Function

General	
Compatibility	Super G3/ G3/ ECM (Error correction mode)
Scanning Resolution	STD: CD 8 lines/mm x FD 3.85 lines/mm Fine: CD 8 lines/mm x FD 7.7 lines/mm Super Fine: CD 8 lines/mm x FD 15.4 lines/mm
Line	PSTN/ PBX
Data Transmission Rate	33.6 kbps (V.34 JBIG)
Coding Method	MH/ MR/ MMR/ JBIG
Scanning Area	Scanning on the original glass - Metric: A5, A4 - Inch: 5.5 × 8.5 (Half Letter), 8.5 × 11 (Letter), 8.5 × 14 (Legal) Sheet through scanning - CD direction: Maximum 215 mm (8.5 inch) - FD direction: Maximum 1,000 mm (39 inch)
Internet fax	Enable when the optional Internet Fax & Network Scan Kit SU-502 is installed.
Dialing	
Direct dialing	Entering the fax number directly using the 10-Key Pad.
One touch dial	15 keys
Speed dial	200 fax numbers
Group dial	15 groups (50 destination/group)
Program dial	4 keys (No. 12, 13, 14, 15)
Other dialing	Pause insert, Phone Book dial, On-hook dial, Automatic redial, Redial, Chain dial, Combination dial
Transmission	
Transmission mode	ADF TX, Memory TX, Batch TX, Broadcast TX, Confidential Mailbox TX, F code TX (SubAddress TX, SID TX), Forward TX Manual TX, Polling TX, Quick Memory TX, Book TX, Relay initiate TX, Reservation TX, Timer TX,
TX resolution mode/ TX image mode	Standard (204 dpi x 98 dpi), Fine (204 dpi x 196 dpi), Super fine (204 dpi x 392 dpi), Standard + halftone (204 dpi x 98 dpi), Fine + halftone (204 dpi x 196 dpi), Super fine + halftone (204 dpi x 392 dpi)
Receiving	
Receiving mode	Auto RX, Closed network RX, Confidential Mailbox RX, Inward Polling RX, Manual RX, Memory RX, Substitute RX,
RX resolution	204 dpi x 98 dpi, 204 dpi x 196 dpi, 204 dpi x 392 dpi
Max. recording paper size	A4 or 8.5 × 14 (Legal)
Report	Activity report, Back up RAM error report, G3 protocol monitor report, Memory image print, Power failure report, Reservation report, RX result report, Service report, TX result report,
List	Key setting list, Machine status list, Memory data list, One-touch dial list, Service data list, Speed dial list,

Other Features	Automatic paper selection, Backup of memory,
	Confirmation of communication result, Daylight saving time,
	Date/Time setting, Display of destination station, Footer,
	Header, Package reception printing, Pause insert,
	Quick memory printing, Remote monitor, RX print cancel,
	RX printing mode (100 %reception/ Reception print mode/ Cut mode),
	Separate print, Smoothing, Speaker, Time zone,
	Tone signal transmission, TX cancel, RX cancel

Blank page

Maintenance

3. Periodical check

3.1 Maintenance Items

3.1.1 Parts to be Replaced by Users (CRU)

No.	Class	Parts to be replaced	Cycle	Clean	Replace	Descriptions
1	Processing	Toner cartridge	4,300		٠	*1
2	sections	Drum Cartridge	16,000		٠	*1

*1: Average number of print during intermittent printing (2 pages/job)

3.1.2 Periodical Parts Replacement (Every 50,000 Print)

No.	Class	Parts to be replaced	Number of personnel	Check	Clean	Replace	Lubri- cation	Descrip- tions
1	Overall Paper take-up and image conditions			•				
2		Appearance		•	•			
3	Paper feed section	Feed roller		•	•			
4	Transport section	Image Transfer Roller	1			•		
5	Fusing section	Fusing Unit	1			•		
6	DF-501 Paper Separator Pad		1			•		

3.2 Maintenance Parts

- To ensure that the machine produces good copies and to extend its service life, it is recommended that the maintenance jobs described in this schedule be carried out as instructed.
- Replace with reference to the numeric values displayed on the PM counter.

A. Main Unit

No.	Classifica- tion	Parts name	Qua ntity	Actual durable cycle	Pats No.	Descriptions	Ref.Page in this manual
1	Image Transfer section	Image Transfer Roller	1	50,000	4136-4103-XX		☞ 16
2	Fusing	Fusing Unit (100V)	1	50,000	4137-0751-XX		r⊛ 10.
2	section	Fusing Unit (200V)		50,000	4137-0752-XX		13
3	Processing	Toner Cartridge	1	4,300	(materials)		rs 17
4	section	Drum Cartridge	1	16,000	(materials)		疁 18

B. Option

No.	Classifica- tion	Parts name	Qua ntity	Actual durable cycle	Pats No.	Descriptions	Ref.Page in this manual
1	DF-501	Separation Pad	1	50,000	4980-1075-XX		DF-501 manual

NOTE

- As a rule, the Drum Cartridge and Toner Cartridge are to be replaced by the user.
- The contents of the Maintenance List are subject to change without notice.
- For the part numbers, see Parts Manual and Parts Modification Notice.

3.3 Concept of parts life

A. Conditions for Life Specifications Values

• The life specifications value represents the number of printed pages produced or figures equivalent to it when given conditions (see the Table given below) are met. It can be more or less depending on how each individual printer is used.

Print Conditions			
Job type	Making 2 copies per job		
Paper size	A4R / Letter R		
B/W ratio	B/W 6 %		

3.4 Maintenance procedure (Periodical check parts)

3.4.1 Remove the Imaging Cartridge





3.4.2 Feed Roller





- 1. Lift up the Exit Tray and remove it.
- 2. Open the Front Door.

- *3.* Remove the Imaging Cartridge. **NOTE**
- The Imaging Cartridge is the Drum Cartridge, to which the Toner Cartridge is mounted.

A. Cleaning

- 1. Remove the Imaging Cartridge.
- 2. Using a soft cloth, wipe the surface of the Feed Roller clean of dirt.

B. Replacement

- 1. Remove the Imaging Cartridge.
- 2. Remove the Feed Roller.

3.4.3 Replacement of the Image Transfer Roller







- 1. Remove the Imaging Cartridge.
- Place the levers of the Bearings (white) on the right and left ends of the Image Transfer Roller toward this side and remove the Image Transfer Roller from the Image Transfer Roller holder.
- 3. Pull out the Bearings on the right and left ends, and the gear, from the Image Transfer Roller removed from its holder. Install the Bearings and the gear to the new Image Transfer Roller.

NOTE

- Do not touch, or dirty with chemicals or toner, the surface of the Image Transfer Roller, as indentations in and dirt on the surface of the Image Transfer Roller adversely affect the quality of the printed image.
- When handling the Image Transfer Roller, hold onto the shaft and Bearings of the roller.
- Do not place a new Image Transfer Roller directly on the floor or other surface.
- Insert the new Image Transfer Roller into the Image Transfer Roller holder and place the levers of the Bearings into the original upward positions.

3.5 Replacing the Unit

3.5.1 Replacement of the Toner Cartridge









A. Removal Procedure

- 1. Remove the Imaging Cartridge.
- 2. Pull the lever of the Toner Cartridge in the direction shown in the illustration and disconnect the Toner Cartridge from the Drum Cartridge.

NOTE

• If the Drum Cartridge is to be placed on a floor or similar place, use care to prevent toner from scattering around.

B. Reinstallation Procedure

 Take out a new Toner Cartridge and shake it in the horizontal direction sufficiently so that toner is agitated.

NOTE

- Placing the Toner Cartridge in an upright position or shaking it vigorously will spill toner.
- 2. Remove the protective cover from the Toner Cartridge.

3. Install the new Toner Cartridge to the Drum Cartridge.

NOTE

 Insert the Toner Cartridge along the guide provided on the Drum Cartridge side and make sure that the Toner Cartridge is not tilted when inserted.



4. Install the Imaging Cartridge in the printer.

NOTE

- Insert the Imaging Cartridge along the guide provided on the printer side. Ensure that the Imaging Cartridge is not slid obliquely.
- 5. Close the Front Door.

Precautions for Replacing the Toner Cartridge

• Different types of Toner Cartridges are available for different regions. Therefore, check the Toner Cartridge type before replacing it.

<Toner Cartridge Types for Each Region>

USA & Canada : Toner Cartridge 605 C Europe : Toner Cartridge 601 A

Other regions : Toner Cartridge 602 B

3.5.2 Replacement of the Drum Cartridge







A. Removal Procedure

- 1. Remove the Imaging Cartridge.
- Pull the lever of the Toner Cartridge in the direction shown in the illustration and disconnect the Drum Cartridge.

B. Reinstallation Procedure

1. Mount the Toner Cartridge to a new Drum Cartridge.

NOTE

- Insert the Toner Cartridge along the guide provided on the new Drum Cartridge side and make sure that the Toner Cartridge is not tilted when inserted.
- 2. Install the Imaging Cartridge in the printer.

NOTE

 Insert the Imaging Cartridge along the guide provided on the printer side. Ensure that the Imaging Cartridge is not slid obliquely.

3. Close the Front Door.

NOTE

• After replacing the Drum Cartridge, be sure to reset the I/C counter in the Service Mode.

bizhub 160/160f bizhub 161/161f

3.5.3 Replacement of the Fusing Unit

NOTE

• Immediately after turning off the printer, the area around the Fusing Unit is extremely hot. Therefore, in order to reduce the risk of burns, wait until the unit has cooled down before performing any operation.

A. Removal Procedure

- 1. Remove the Rear Cover.
- ræ 32
- 2. Remove the NIC Board. (only when the option NC-501 is mounted)
- rs 34
- 3. Remove the NCU Board. (bizhub 160f/161f only)
- 🖙 34

4. Remove the PCL Board. (bizhub 161/161f only)

rs 35







5. Unplug all connector on the Controller/Mechanical Control Board.

NOTE

- The two connectors marked with "*" in the illustration are provided for bizhub 160f/161f only.
- *6.* Remove the two screws, and then remove the Left Rear Cover.

7. Remove the three screws, and then remove the Circuit Board and Metal Bracket.









- 8. Remove the Upper Left Cover.
- 9. Remove the two screws, and then remove the Upper Right Cover and Protective Metal Bracket.

NOTE

- The Protective Metal Bracket is tightened together with the Upper Right Cover.
- Remove two screws, unplug three connectors, and remove the Fusing Unit.

NOTE

- The surfaces around the Fusing Unit are very hot. Use utmost care not to touch any surfaces other than the Fusing Unit.
- 11. Remove the Fusing Unit.

- B. Reinstallation Procedure
- 1. Connect connector A.
- 2. Mount the Fusing Unit in the printer and secure it in position by tightening the two screws.
- 3. Connect connectors B and C. NOTE
- When installing the Fusing Unit, route the harness as shown in the illustration and make sure that no part of the harness is wedged between the Fusing Unit and printer.

4. Service tool

4.1 CE Tool List

• There is not use for the CE tool.

4.2 Copy materials

Parts name	Replacing period *1
Toner Cartridge	4,300 copies
Drum Cartridge	16,000 copies

^{*1:} Life value that can be achieved with a probability of 90% even with product-to-product variations and fluctuating operating environmental conditions taken into consideration, when the T/C is used under the conditions of B/W ratio 6%.

4.2.1 Maintenance Kit

There is no setting for the Maintenance Kit.

5. Firmware upgrade

5.1 Preparations for Firmware rewriting

NOTE

- The TWAIN driver must already be installed on the host computer to be used for updating the firmware.
- If the printer driver or TWAIN driver is not installed, follow the procedure described below to install the driver.
- If the driver is already installed, skip to "Procedure for Updating the Firmware" and update the firmware.

5.2 Firmware rewriting

5.2.1 Installing the Printer Driver/ TWAIN Driver Using Plug and Play

<For Windows XP>

- 1. Start up the host computer, and then insert the CD-ROM into the CD-ROM drive.
- 2. Turn on the printer.
- 3. Use a USB cable to connect the printer to the host computer.
- 4. In the "Found New Hardware Wizard" dialog box, select "Install from a list or specific location [Advanced]", and then click the [Next] button.
- 5. Below "Search for the best driver in these locations.", select "Include this location in the search", and then click the [Browse] button.
- Specify "\Corresponding_language\2K_XP" on the CD-ROM, and then click the [OK] button.
- 7. Click the [Next] button, and then click the [Finish] button.
- 8. When the "Found New Hardware Wizard" dialog box appears again, repeat steps 4 through 7 to install all drivers.

<For Windows 2000>

- 1. Start up the host computer, and then insert the CD-ROM into the CD-ROM drive.
- 2. Turn on the printer.
- 3. Use a USB cable to connect the printer to the host computer.
- 4. In the "Install Hardware Device Drivers" dialog box, select "Search for a suitable driver for my device (recommended)", and then click the [Next] button.
- 5. In the "Locate Driver Files" dialog box, select "Specify a location", and then click the [Next] button.
- Click the [Browse...] button, specify "\Corresponding_language\2K_XP" on the CD-ROM, and then click the [OK] button.
- Click the [OK] button, and then continue following the instructions in the dialog boxes that appear until the "Completing the Found New Hardware Wizard" dialog box appears.
- 8. Click the [Finish] button.
- 9. When the "Found New Hardware Wizard" dialog box appears again, repeat steps 4 through 8 to install all drivers.

<For Windows Me/98>

- 1. Start up the host computer, and then insert the CD-ROM into the CD-ROM drive.
- 2. Turn on the printer.
- 3. Use a USB cable to connect the printer to the host computer.
- 4. In the "Install Hardware Device Drivers" dialog box, click the [Next] button, select "Search for a suitable driver for my device (recommended)", and then click the [Next] button again.

Maintenance

Maintenance

- 5. Select "Specify a location", and then click the [Browse...] button.
- Specify "\Corresponding_language\Win9X" on the CD-ROM, and then click the [OK] button.
- Click the [OK] button, and then continue following the instructions in the dialog boxes that appear until the "Completing the Found New Hardware Wizard" dialog box appears.
- 8. Click the [Finish] button.
- 9. When the "Found New Hardware Wizard" dialog box appears again, repeat steps 4 through 8 to install all drivers.

5.2.2 Procedure for Upgrading the Firmware (Engine firmware/ Copier firmware/ FAX firmware/ PCL firmware)

NOTE

- The engine firmware, Copier firmware, FAX firmware and PCL firmware can be upgraded by using the following procedure.
- For the upgrading procedure of NIC firmware, see "NIC NC-501 Upgrading the Firmware."
- 1. Turn on the printer.
- 2. Start up the host computer (Windows 98 or later).
- 3. Copy the "Update Software" folder and "Update" file to drive C. (Copy them into the highest directory on drive C.)
- 4. Use a USB cable to connect the printer to the host computer. (Wait until the hardware is detected.)
- 5. Display the "System Properties" dialog box ("Properties" for "My Computer"), click the "Hardware" tab, click the [Device Manager] button, select "Imaging devices", and then check that "KONICA MINOLTA 160 scanner" has been added.

Hardware Woard Imaging devices Imaging devices<	General Network Identification Hardware User Profiles Ad	dvanced	
Hadware Wizard. Device Manager The Device Manager Device M	Hardware Wizard The Hardware wizard helps you install, uninstall, rep unplug, eject, and configure your hardware.	pair,	IEI ECI Computer Disk drives
Diverse Manager int all the hardware devices installed on your computer. Use the Device Manager to change the properties of any devices. The Popy disk controllers Divers Signing. Device Manager Hardware Profiles KONICA MINOLTA 160 Hardware profiles provide a way for you to set up and store different hardware contiguations. Monitory Hardware Profiles Hardware Profiles DK Cancel DK Cancel Apply Universal Serial Bus controllers 4980f2e0011	Hardware Wi	izard	Display adapters DVD/CD-BOM drives
The Device Manager sits all the hardware devices installed properties of any divice. Driver Signing Device Manager. Hardware Profiles Device Manager. Hardware Profiles Rey Hordward Movies. Hardware Profiles Bit Metword Machines Profiles Hardware Profiles Bit Metword Machines Bit Metword A way for you to set up and store different hardware configuration. Bit Metword Machines Hardware Profiles Bit Metword Machines Bit Metword A way for you to set up and store different hardware Profiles. Bit Metword Machines Bit Metword A way for you to set up and store different hardware profiles Bit Metword A dapters Bit Cancel Apply Diversal Serial Bus controllers Bit System devices Bit Cancel Apply	Device Manager		Eloppy disk controllers
Driver Signing Device Manager Hadwae Profiles Notice and other pointing devices Hadwae Profiles Monitors Hadwae Profiles Monitors Hadwae Profiles Ports (COM & LPT) By Ports (COM & LPT) System devices DK Cancel Apply	The Device Manager lists all the hardware devices on your computer. Use the Device Manager to cha properties of any device.	ange the	Total ATA/ATAPI Convollers
Hadware Profiles Mice and other pointing devices If the diverse profiles provide a way for you to set up and store different hadware configurations. If the diverse profiles provide a way for you to set up and store different hadware profiles. If the diverse profiles provide a way for you to set up and store different hadware profiles. If the diverse profiles provide a way for you to set up and store different hadware profiles. If the diverse profiles provide a way for you to set up and store different hadware profiles. If the diverse profiles provide a way for you to set up and store different hadware profiles. If the diverse profiles provide a way for you to set up and store different hadware profiles. If the diverse profiles provide a way for you to set up and store different hadware profiles. If the diverse profiles provide a way for you to set up and store different hadware profiles. If the diverse profiles provide a way for you to set up and store different hadware profiles. If the diverse profiles provide a way for you to set up and store different hadware profiles. If the diverse profiles provide a way for you to set up and store different hadware profiles. If the diverse profiles prof	Driver Signing Device Mana	ager	Keyboards
OK Cancel Apply	Hardware Profiles Hardware profiles provide a way for you to set up a	and store	Mice and other pointing devices
Hardware Proles Hardware Proles Har	different hardware configurations.		Ref Network adapters
OK Cancel Apply	Hardware Pro	ofiles	Ports (COM & LPT)
OK Cancel Apply 4980f2e001:			E-Second, video and game controllers
OK Cancel Apply			E System devices
	OK. Cancel	Apply	Universal Serial Bus controllers 4980f2e00

6. Double-click "Update" file in the "Update Software" folder. The "A3S/A4S Update F/W-VX.XX" dialog box appears.



7. Click the [Browse] button, and then select "Update" file, which was copied onto drive C in step 3.

NOTE

• The software identifies the type of firmware. Select the Update" file of the engine firmware, Copier firmware, FAX firmware, or PCL firmware and click the "Browse" button.

A3S/A4S Update F/	W - V3.01	×
File path : 🛛	C:\ShimantoV100CopyF01K	Browse
Update	Exit	

- 8. Click the [Update] button. The transfer of firmware data begins. (Wait until the transfer of data is finished.)
- 9. Check the firmware update status in the display.



NOTE

- Do not turn the printer off or on while the screen shown above is displayed.
- 10. Check that the following message appears in the display to indicate that the updating of the firmware is complete.



11. Click the [OK] button, and then quit the "A3S/A4S Update F/W-VX.XX" application.



12. Turn the printer off, then on again.

5.2.3 Procedure for Upgrading the FAX Firmware (Upgrading Procedure Using Telephone Line from FAX Machine to FAX Machine)

NOTE

- The firmware transmitter fax machine must be loaded with the latest version of the firmware. If the firmware is not upgraded, do that by following the "Procedure for Updating the Firmware" described in the previous section.
- 1. Set the REMOTE MONITOR to "FULL" in ADMIN.MANEGEMENT mode of Utility. (Firmware receiver fax machine)
- 2. Set the firmware transmitter fax machine into the Service mode. Utility, Stop, 0, 0, Stop, 0, 1
- 3. Select "5. FUNCTION" and then select "UPLOAD FIRMWARE".
- 4. Type the telephone number, to which the firmware receiver fax machine is connected. (The relevant one touch dial number may be used if the telephone number has been previously programmed in it.)
- Press the Start key. This starts transfer of the data. The Message Panel of the transmitter fax machine displays the same screen as that appearing during ordinary faxing. When the data transfer is completed, the ordinary standby screen reappears on the Message Panel.
- The firmware receiver fax machine receives the firmware data. The following message appears on the Message Panel, indicating that transfer of firmware data is started.

NOTE

• Do not use any of the printer and copier functions until upgrading of firmware is completed.



7. The following message appears on the Message Panel of the firmware receiver fax machine, indicating that upgrading of the firmware is completed.



8. Turn OFF and ON the Power Switch of the firmware receiver fax machine.

5.3 Remedy for a Failed Updating of the Firmware

- 1. Turn off the printer.
- 2. Remove the USB cable connecting the printer to the host computer.
- 3. Remove the Rear Cover.
- ræ 32

bizhub 160/160f bizhub 161/161f

- 4. Remove the NIC Board. (only when the option NC-501 is mounted)
- ræ 34
- 5. Change the settings for jumper switches CJ1 and CJ2 on the Controller/Mechanical Control Board from "1-2" to "2-3".



 Attach Service Download BIOS U19 and U26 to memory sockets U19 and U26 on the Controller/Mechanical Control Board.



- 7. Use a USB cable to connect the printer to the host computer.
- 8. Start up the host computer.
- 9. Turn on the printer. The following message appears in the display.



- 10. Perform steps 6 through 10 of "Procedure for Upgrading the Firmware" to update the firmware.
- 11. Check that the following message appears in the display to indicate that the updating of the firmware has been completed correctly.



4980D051AB

- 12. Turn off the printer.
- 13. Change the settings for jumper switches CJ1 and CJ2 on the Controller/Mechanical Control Board from "2-3" to "1-2". (Return them to their default settings.)
- 14. Remove Service Download BIOS U19 and U26 from memory sockets U19 and U26 on the Controller/Mechanical Control Board.
- 15. Install the NIC Board. (only when the optional NIC Board is mounted)
- 16. Install the Rear Cover.
- 17. Turn on the printer.

5.4 Remedy for a Failed Updating of the Firmware for PCL (bizhub 161, bizhub 161f only)

When Failed Updating of the PCL6 Firmware (such as updating the Firmware turned the power off, couldn't upgrade the Firmware during the correct method, or if any extraordinary condition happened during upgrading PCL6 firmware), you can use the method step by step as following:

- 1. Turn off the printer.
- 2. Remove the USB cable connecting the printer to the host computer.
- *3.* Remove the Rear Cover.
- rs 32
- Change the settings for jumper switches CJ1/ CJ2/CJ3/CJ4 on the PCL Controller Board from "1-2" to "2-3".



5. Attach Service Download BIOS U8 to memory sockets U8 on the PCL Controller Board.



- 6. Use a USB cable to connect the printer to the host computer.
- 7. Start up the host computer.
- 8. Turn on the printer. There are normally showed in the display.
- 9. Wait for 30 seconds. until the machine connect the PCL Controller Board finished.
- 10. Press the Utility key.

- 11. Press the following keys in this order to enter the Service mode. Stop $\rightarrow 0 \rightarrow 0 \rightarrow$ Stop $\rightarrow 0 \rightarrow 1$
- 12. Check the PCL firmware version that in the service mode. \rightarrow 4. DISPLAY \rightarrow PCL F/W Ver.
- 13. If the PCL firmware version can showed on the display mean connect with finished.
- 14. Perform steps 6 through 10 of "Procedure for Upgrading the Firmware" to update the firmware.
- 15. Waiting for 90 sec. Check that the following message appears in the display to indicate that the updating of the firmware has been completed correctly.



- 16. Turn off the printer.
- Change the settings for jumper switches CJ1/ CJ2/CJ3/CJ4 on the PCL Controller Board from "2-3" to "1-2".
- Remove Service Download BIOS U8 to memory sockets U8 on the PCL Controller Board.
- 19. Install the Rear Cover.
- 20. Turn on the printer.
- 21. Check the Version again. Following as step 10 to 12.

6. Other

6.1 Disassembly/Adjustment prohibited items

A. Paint-locked Screws

NOTE

- Paint-locked screws show that the assembly or unit secured can only be adjusted or set at the factory and should not be adjusted, set, or removed in the field.
- When the screws are removed, the red paint is coated on the points where readjustment is required.
- Once the red painted screw is removed or loosened, you should make adjustment. Accordingly check the adjustment items in operation manual and make necessary adjustment. Note that when two or more screws are used on the part in questions, only one representative screw may be marked with red paint.

(1) Other Screws not Marked with Red Paint



C. Variable Resistors on Board

NOTE

 Do not turn the variable resistors on boards for which no adjusting instructions are given in Adjustment/Setting.

D. Removal of PWBs

NOTE

- When removing a circuit board or other electrical component, refer to "Handling of PWBs" and follow the corresponding removal procedures.
- The removal procedures given in the following omit the removal of connectors and screws securing the circuit board support or circuit board.
- Where it is absolutely necessary to touch the ICs and other electrical components on the board, be sure to ground your body.



6.2 Disassembly/Assembly list (Other parts)

No.	Section	Part name			ef.Page
1	Exterior parts	Original Cove	er	13	32
2		Exit tray		3	32
3		Front Door		3	32
4		Tray1 (with B	Tray1 (with Bypass Tray)		32
5		Left Cover		13	32
6		Right Cover		6	32
7		Rear Cover		3	32
8	Board and etc.	PWB-NIC	Network Interface Card Board * NC-501 Option for bizhub 161/160f/161f	3	34
9		PWB-NCU	NCU Board * bizhub 160f/161f only	ß	34
10		PWB-PCL	PCL Board * bizhub 161/161f only	R.	35
11		PWB-P	Controller/Mechanical Control Board	13	35
12		PWB-O	Control Panel	13	36
13		PWB-IF	Interface Board	13	37
14		NIC-IF	Plate NIC Board * NC-501 Option for bizhub 161/160f/161f	8	38
15		PU1	Power Unit	13	39
16		HV1	High Voltage Unit	13	42
17	Unit	PH Unit		13	43
18	IR	IR Unit		3	42
19		Original cove	r set sensor	3	44
20		Upper Cover	Assy. (Original Glass)	13	44
21		Scanner Motor		1 37	45
22		Scanner Ass	у.	13	45
23		Belt		13	46
24	Others	Main Motor		1 37	46
25		Paper Empty	Sensors	1 37	47
26		Paper Take-U	Jp Solenoid	13	48
27		Paper Take-L	Jp Clutch Gear	13	49
28		Torque Limite	er	13	50
29		Mechanical 0 * Option for b	Counter izhub 160/161/160f/161f	13	52

6.3 Disassembly/Assembly procedure

6.3.1 Identification of Exterior Parts and Removal Procedures for Them



No.	Name	Removal Procedure
1	Original Cover	Open the Original Cover \rightarrow Pull it straight up.
2	Exit tray	While pressing out one side, remove the Exit tray.
3	Front Door	Open the Front Door. \rightarrow While pressing in one side, remove the Front Door.
4	Tray1 (with Bypass Tray)	Hold down the main unit with one hand and pull Tray1 off toward you.
5	Left Cover	Open the Front Door. \rightarrow Remove the screw, unhook the six tabs, and remove the Left Cover.
6	Right Cover	Open the Front Door. \rightarrow Remove the two screws, unhook the four tabs, and remove the Right Cover.
7	Rear Cover	Remove the five screws, and remove the Rear Cover.

6.3.2 Removal of Circuit Boards and Other Electrical Components

NOTE

- When removing a circuit board or other electric component, refer to the precautions for handling PWBs and follow the corresponding removal procedures.
- The removal procedures given in the following paragraphs omit the removal of the component in question from a connector or a PWB support.
- Where it is absolutely necessary to touch the ICs and other electric components on the board, be sure to ground your body.



6.3.3 NIC Board (Option for bizhub 161/160f/161f)

1. Remove the Rear Cover.





6.3.4 NCU Board (bizhub 160f/161f only)

1. Remove the Rear Cover.





2. Disconnect the connector from the NIC Board.

- 3. Remove three screws.
- 4. Remove the NIC Board.

2. Disconnect all connectors from the NCU Board.

- 3. Remove three screws.
- 4. Remove the NCU Board.

1. Remove the Rear Cover.





- 6.3.6 Controller/Mechanical Control Board
- 1. Remove the Rear Cover.
- rs 32
- 2. Remove the NIC Board. (only when the option NC-501 is mounted)
- 🖙 34
- 3. Remove the NCU Board. (bizhub 160f/161f only)
- 🖙 34
- 4. Remove the PCL Board. (bizhub 161/161f only)
- rs 35





 Disconnect all connectors and flat cables from the Controller/Mechanical Control Board.

2. Disconnect all connectors from the

PCL Board.

Remove four screws.
 Remove the PCL Board.

NOTE

- The two connectors marked with "*" in the illustration are provided for bizhub 160f/161f only.
- Use utmost care not to snap off the flat cable.
- 6. Remove six screws.
- 7. Remove the Controller/Mechanical Control Board.

A. Moving the Parameter Chip

NOTE

 After the Controller/Mechanical Control Board (PWB-P) is replaced, be sure to move the Parameter Chip form the old Controller/Mechanical Control Board to the new one.

Remove the Parameter Chip (U39) from the old Controller/Mechanical Control Board, and then attach it to the new Controller/Mechanical Control Board.





6.3.7 Control Panel

- 1. Remove the Exit tray.
- ræ 32



2. Remove the Rubber cap, then remove the three screws.

correct direction.

- 3. Unplug one connector and one flat cable.
- 4. Remove the Control Panel.

NOTE

• Use utmost care not to snap off the flat cable.

6.3.8 Interface Board

- 1. Remove the Rear Cover.
- rs 32
- 2. Remove the NCU Board. (bizhub 160f/161f only)
- 🖙 34
- 3. Remove the PCL Board. (bizhub 161/161f only)
- rs 35









- Unplug the three connectors on the Controller/Mechanical Control Board. (For bizhub 160/161)
- Unplug the five connectors on the Controller/Mechanical Control Board. (For bizhub 160f/161f)

NOTE

- The two connectors marked with "*" in the illustration are provided for bizhub 160f/161f only.
- 6. Remove the two screws.
- 7. Remove the Left Rear Cover.

- 8. Remove the three screws.
- 9. Remove the Circuit Board and Metal Bracket.

- 10. Remove the two screws.
- *11.* Remove the Protective Metal Bracket for the Interface Board.





- 12. Remove the seven screws.
- 13. Remove the Interface Board.

6.3.9 Plate NIC Board (Option for bizhub 161/160f/161f)

1. Remove the Rear Cover.

r⊛ 32

2. Remove the NIC Board. (only when the option NC-501 is mounted)

rs 34

- 3. Remove the NCU Board.
- rs 34
- 4. Remove the PCL Board. (bizhub 161/161f only)

rs 35







 Unplug the five connectors on the Controller/Mechanical Control Board.

6. Unplug the connector on the Plate NIC Board.

- 7. Remove the two screws.
- 8. Remove the Left Rear Cover.





6.3.10 Power Unit

- 1. Remove the Right Cover.
- rs 32
- 2. Remove the Left Cover.
- ræ 32
- 3. Remove the Rear Cover.
- 🖙 32
- 4. Remove the NIC Board. (only when the option NC-501 is mounted)
- rs 34
- 5. Remove the NCU Board. (bizhub 160f/161f only)
- ræ 34
- 6. Remove the PCL Board. (bizhub 161/161f only) S 35
- 7. Remove the IR Unit.
- rs 42



- 9. Remove the three screws.
- 10. Remove the Circuit Board and Metal Bracket.

- 11. Remove the two screws.
- 12. Remove the Plate NIC Board.

- 8. Remove the two screws.
- 9. Remove the Left Rear Cover.

Maintenance


10. Unplug all connector on the Controller/Mechanical Control Board.

NOTE

- The two connectors marked with "*" in the illustration are provided for bizhub 160f/161f only.
- 11. Remove the three screws.
- 12. Remove the Circuit Board and Metal Bracket.

- 13. Remove the three screws.
- 14. Unhook the tab, and then remove the Right Rear Frame.

15. Remove the three screws from the Left Rear Frame.

- 16. Remove the four screws.
- 17. Remove the Metal Bracket.











- 18. Remove the two screws.
- *19.* Unhook the tab, and then remove the Left Rear Frame.

- 20. Remove the Upper Left Cover.
- 21. Remove the two screws.
- 22. Remove the Upper Right Cover and Protective Metal Bracket.

NOTE

- The Protective Metal Bracket is tightened together with the Upper Right Cover.
- 23. Remove the two screws.
- 24. Unplug the three connectors.
- 25. Remove the Fusing Unit Assy.

- 26. Remove three screws.
- 27. Remove the Power Switch stay.
- 28. Remove the Power Switch.

- 29. Remove four screws.
- 30. Disconnect three connectors.
- 31. Remove the Power Unit Assy.



6.3.11 High Voltage Unit

- 1. Remove the Power Unit Assy.
- 🖙 39



6.3.12 IR Unit

- 1. Remove the Left Cover.
- r⊛ 32
- 2. Remove the Right Cover.
- r≊ 32
- 3. Remove the Rear Cover.
- i≌ 32
- 4. Remove the PCL Board. (bizhub 161/161f only).
- rs 35





- 32. Remove four screws.
- 33. Remove the Power Unit.

- 2. Remove one screw.
- 3. Remove the High Voltage Unit.

5. Unplug the connector.

 Unplug the two flat cables from the Controller/Mechanical Control Board.

NOTE

• Be extremely careful not to break the flat cables.



6.3.13 PH Unit

NOTE

- NEVER attempt to replace the PH Unit with power being supplied to the printer. Doing that could lead to exposure to the laser beam, resulting in blindness
- NEVER attempt to disassemble or adjust the PH Unit. Doing that could lead to exposure to the laser beam, resulting in blindness.
- 1. Remove the IR Unit.
- rs 42
- 2. Remove the Fusing Unit.
- 🖙 19
- 3. Remove the Exit tray.
- r⊛ 32
- 4. Remove the PCL Board. (bizhub 161/161f only).
- rs 35





- 5. Remove the four screws.
- 6. Unhook the two tabs, and then remove the Upper Cover.

 Disconnect one flat cable and one connector from the Controller/ Mechanical Control Board.

NOTE

• Use utmost care not to snap off the flat cable.

- 7. Remove the two screws.
- 8. Unhook the two tabs, and then remove the IR Unit.

Maintenance



- 8. Remove three screws.
- 9. Remove the PH Unit.

NOTE

• When reinstalling the PH Unit, tighten the screws in the numerical order shown in the illustration.

Precautions for Removal/Reinstallation of the PH Unit

• NEVER touch the window on the backside of the PH Unit. A dirty window can cause an image problem.



6.3.14 Original Cover Set Sensor

- 1. Remove the Original Cover.
- 2. Remove the Control Panel.
- r≊ 36



6.3.15 Upper Cover Assy. (Original Glass)

- 1. Remove the Original Cover.
- 2. Remove the Control Panel.
- r≊ 36



3. Remove the Original cover set sen-

sor.

- 3. Remove the six screws.
- 4. Remove the Upper Cover Assy. (Original Glass).

6.3.16 Scanner Motor

- 1. Remove the Original Cover.
- 2. Remove the Upper Cover Assy. (Original Glass).
- i≌ 32
- 3. Remove the Left Cover.
- rs 32







6.3.17 Scanner Assy.

- 1. Remove the Original Cover.
- 2. Remove the Upper Cover Assy. (Original Glass).
- rs 32



4. Unplug one connector from the Scanner Motor.

- 5. Remove the two screws.
- 6. Remove the Scanner Motor Mounting Bracket.

- 7. Remove the two screws.
- 8. Remove the Scanner Motor.

- 3. Remove the two screws.
- 4. Remove the Flat Cable Holding Plate.



5. Unplug the Flat Cable.

- 6. Remove the Belt and shaft.
- 7. Remove the Scanner Assy.

6.3.18 Belt

- 1. Remove the Original Cover.
- 2. Remove the Upper Cover Assy. (Original Glass).

4980D022AA

- ræ 32
- 3. Remove the Scanner Assy.
- ræ 45



6.3.19 Main Motor

- 1. Remove the Left Cover.

Remove the C-clip.
 Remove the washer.
 Remove the Belt.

- 2. Disconnect one connector.
- 3. Remove two screws.
- 4. Remove the Main Motor.

6.3.20 Paper Empty Sensors

- 1. Remove the Imaging Cartridge.
- 2. Remove the Front Door.

NOTE

- The Imaging Cartridge is the Drum Cartridge, to which the Toner Cartridge is mounted.
- 3. Remove the Left and Right Covers.
- rs 32









4. Remove the four connectors from the Paper Take-Up Upper Guide Assy.

5. Unhook the two tabs, and then remove the Paper Take-Up Upper Guide Assy.

6. Unhook two tabs and remove the tray.

7. Remove the Multi purpose Tray Paper Empty Sensor.





6.3.21 Paper Take-Up Solenoid

- 1. Remove the Left Cover.
- rs 32





- Field Service Ver. 1.0 Apr. 2005
- 8. Remove the Multiple Bypass Tray Paper Empty Sensor.

9. Remove the Toner Empty detection sensor.

2. Disconnect one connector of the Paper Take-Up Solenoid.

- 3. Remove one screw.
- 4. Remove the Paper Take-Up Solenoid.

Precautions for Installation of the Paper Take-Up Solenoid

- 1. Mount the Paper Take-Up Solenoid and tighten one screw.
- 2. Turn the gear in the direction of the arrow shown below so that the flapper of the Paper Take-Up Solenoid catches the stopper of the gear.



6.3.22 Paper Take-Up Clutch Gear

- 1. Remove the Fusing Unit.
- ræ 19
- 2. Remove the Power Unit.
- ræ 39
- 3. Remove the Paper Take-Up Upper Guide Assy.



4980D057AA



- 4. Disconnect one connector and remove the Cooling Fan Motor 2.
- 5. Disconnect one connector of the Main Motor.
- 6. Remove the Paper Lifting Plate Assy.
- 7. Remove two springs.

 Disconnect one connector and one flat cable from the Controller/ Mechanical Control Board.

NOTE

- Use utmost care not to snap off the flat cable.
- 9. Remove the Top Cover.
- 10. Remove four screws.
- 11. Remove the PH Base Plate Assy.



6.3.23 Torque Limiter

Remove the Paper take up Clutch Gear.
 49



- 12. Disconnect one connector of the Paper Take-Up Solenoid.
- 13. Remove two screws.
- 14. Remove the Left Frame.
- 15. Remove one screw.
- *16.* Remove the Paper Take-Up Solenoid.

17. Unhook two tabs and remove the Paper Take-Up Clutch Gear.

2. Unhook three tabs and take apart the Paper Take-Up Clutch Gear then, remove the Torque Limiter.

bizhub 160/160f bizhub 161/161f

50

Precautions for Installation of the Torque Limiter

Coupling Gear has five dent for adjustment the Take-Up Roller position. When Torque Limiter is replaced, adjust the set position of the Coupling Gear so that the Take-Up Roller becomes level. The procedure is as follow.





After setting replaced Paper Take-Up Clutch Gear (Torque Limiter) to the shaft, Rotate the Paper Take-Up Clutch Gear by hand (Need to be released Solenoid Flapper).

Look at the stop position of the Take-Up Roller from Clutch Gear side.





1. When the Roller is lent to clockwise, move the coupling Gear to A direction.

2. When the Roller is lent to counter clockwise, move the coupling Gear to B direction.

6.4 Option Counter

6.4.1 Removal of the Mechanical Counter (Option for bizhub 160/161/160f/161f)

- 1. Remove the Right Cover.
- i≊ 32

6. Other

- 2. Remove the Rear Cover.
- r⊛ 32
- 3. Remove the PCL Board. (bizhub 161/161f only)
- i≊ 35







4. Unplug one connector on the Controller/Mechanical Control Board.

5. Remove the Relay Harness.

6. Remove the screw, and then remove the Mechanical Counter.

Adjustment/Setting

7. How to use the adjustment section

- "Adjustment/Setting" contains detailed information on the adjustment items and procedures for this machine.
- Throughout this "Adjustment/Setting," the default settings are indicated by " ".

A. Advance Checks

- Before attempting to solve the customer problem, the following advance checks must be made. Check to see if:
- 1. The power supply voltage meets the specifications.
- 2. The power supply is properly grounded.
- 3. The machine shares the power supply with any other machine that draws large current intermittently (e.g., elevator and air conditioner that generate electric noise).
- 4. The installation site is environmentally appropriate: high temperature, high humidity, direct sunlight, ventilation, etc.; levelness of the installation site.
- 5. The original has a problem that may cause a defective image.
- 6. The density is properly selected.
- 7. The Original Glass, slit glass, or related part is dirty.
- 8. Correct paper is being used for printing.
- 9. The units, parts, and supplies used for printing (developer, PC Drum, etc.) are properly replenished and replaced when they reach the end of their useful service life.
- 10. Toner is not running out.

B. Precautions for Service Jobs

- 1. To unplug the power cord of the machine before starting the service job procedures.
- 2. If it is unavoidably necessary to service the machine with its power turned ON, use utmost care not to be caught in the Scanner Cables or gears of the Exposure Unit.
- 3. Special care should be used when handling the Fusing Unit which can be extremely hot.
- 4. The Developing Unit has a strong magnetic field. Keep watches and measuring instruments away from it.
- 5. Take care not to damage the PC Drum with a tool or similar device.
- 6. Do not touch IC pins with bare hands.

8. Status Mode

- The total number of pages printed and scanned since this machine was installed can be checked.
- Results of 60 past faxes sent and received and counter information are displayed on the LCD, and various reports are printed. (bizhub 160f/161f only)
- The reports and the lists are printed. (bizhub 160f/161f only)

8.1 Status Mode function tree



bizhub 160/160f bizhub 161/161f

> *: bizhub 160f/161f only **: bizhub 161/161f only ***: bizhub 161/160f/161f only

8.2 Status Mode setting procedure

8.2.1 Procedure

- 1. Press the Status key.
- 2. The first Status screen appears.

8.2.2 Exiting procedure

• Press the Panel Reset key.

8.2.3 Changing the Status Mode functions

- 1. Press the \blacktriangle / \blacktriangledown key or < / > key to select the desired function.
- 2. Press the Yes key to apply the setting.
- 3. To return to the previous screen, press the No/ C key.



8.2.4 TOTAL PAGE

Functions	 Total Count: Displays the total number of pages printed since this machine was installed. Total Scan : Displays the total number of pages scanned since this machine was installed. However, the scanned number of pages in copy are not included. TX Pages* : Displays the total number of pages faxed since this machine was installed. RX Pages* : Displays the total number of pages received since this machine was installed.
Use	 The total number of pages printed and scanned since this machine was installed can be checked.
Setting/Procedure	 Press the Status key. Press the Yes key. Press the ▼ and ▲ keys to check the "TOTAL COUNT", "TOTAL SCAN", "TX PAGES" or "RX PAGES" values.

* : Available only if the bizhub 160f/161f.

8.2.5 TX/ RX RESULT (bizhub 160f/161f only)

Functions	 TX Result Report : Displays the transmission result report. RX Result Report : Displays the reception result report.
Use	 Results of 60 past faxes sent and received and counter information are dis- played on the LCD, and various reports are printed.
Setting/Procedure	 Press the Status key twice. Press the Yes key. Press the t and s keys to display the desired transmission results to check them. In the transmission result screen, "TX" indicates sent faxes, and "RX" indicates received ones. To print the transmission result report, press the Start key. After the transmission result report is printed, the main screen appears. If the No key is pressed twice while the transmission results are displayed, the main screen appears.

8.2.6	PRINT REPORT (bizhub 161/160f/161f only)
-------	--

Functions	 TX Result Report* 	: Prints the transmission result report.		
	 RX Result Report* 	: Prints the reception result report.		
	 Activity Report* 	: Prints the transmission/reception result report.		
	 Memory Report* 	: Prints the list of documents stored in the memory.		
	Memory Image Report*	: Prints the reduced image of the first page of the document stored in the memory.		
	One Touch List*	: Prints the recipients programmed in the one-touch dial keys.		
	 Speed Dial List* 	: Prints the recipients programmed for the speed dial numbers.		
	 Key Setting List* 	: Prints the settings specified for one-touch dial keys.		
	 Machine Status List* 	: Prints the current machine status.		
	 Configuration Page** 	: Prints the current machine configuration.		
Use	The reports and the lists	are printed.		
Setting/Procedure	 Press the Status key 3 times. Press the Yes key. Press the Yes key. After the specified report/list that you wish to print, and then press the Yes key. After the specified report/list is printed, the main screen appears again. 			
	NOTE • The reception/transmi details on viewing the 157 56	ssion result reports can be checked on screen. For transmission result, refer to "TX/ RX Result."		

* : Available only if the bizhub 160f/161f.

** : Available only if the bizhub 161/160f/161f.

• TX result report (example)

NAME:ABC TEL:123456 DATE:Dec.0	123 7 1.2003 15:12		TX RESULT	REPORT					
SESSION	FUNCTION	No.	DESTINATION STATION	DATE	TIME	PAGE	DURATION	MODE	RESULT
0001	тх	001	AAA NEWYORK 012345678	JAN.23	17:43	010	00h00min00s	G3	ОК

• RX result report (example)

NAME:ABC TEL:123456 DATE:Dec.0	123 7 1.2003 15:12		RX RESULT	REPORT	г				
SESSION	FUNCTION	No.	DESTINATION STATION	DATE	TIME	PAGE	DURATION	MODE	RESULT
0069	RX	001	AAA NEWYORK 012345678	JAN.22	20:07	010	00h00min00s	G3	ОК

• Activity report (example)

NAME TEL:12 DATE:	:ABC 123 234567 Dec.01.2003	15:12			ACTIVITY REPORT				
NO.	SESSION	DATE	TIME	TX/RX	DESTINATION STATION	PAGE	DURATION	MODE	RESULT
01	0034	JAN.22	20:07	ТХ	AAA NEWYORK 012345678	010	00h00min00s	G3 -2.4	ОК
02	0048	JAN.23	14:20	RX	ZZZ LONDON 876543210	001	00h00min00s	G3 -2.4	ОК

• Memory data list (example)

-	NAME:ABC 123 TEL:1234567 DATE:Dec.01.20	003 15:12		MEM	ORY DATA LIST		
	SESSION	FUNCTION	TIME	NO.	DES	TINATION STATION	PAGE
	0077	ТΧ	16:03	001		DELLY OFFICE	001

• Memory image print (example)

			MEMORY IMAGE			
NAME:ABC 123 TEL:1234567 DATE:Dec.01.20	003 15:12		MEMORY IMAGE PRINT			
SESSION	FUNCTION	NO.	DESTINATION STATION	DATE	TIME	PAGE
0077	TX	001	DELLY OFFICE	JAN.26	16:03	001

• One-touch list (example)

NAME:AB TEL:12345 DATE:Dec	C 123 567 .01.2003 15:12	ONE TOUCH LIST			
OT-NO.	DESTINATION STATION	DESTINATION NUMBER	BATCH TIME	SPEED	SET DATE
OP-01	AMSTERDAM OFFICE	0P09876543		33.6	JAN.20.2001

• Speed dial list (example)

NAME:AB TEL:12345 DATE:Dec	C 123 567 .01.2003 15:12	SPEED DIAL LIST		
SP-NO.	DESTINATION STATION	DESTINATION NUMBER	SPEED	SET DATE
SP-001	SYDNEY OFFICE	0P111222333444	33.6	JAN.26.2004
	•			

• Key setting list (example)

KEY .	SETTING LIST					
NAME:ABC 123 TEL:1234567 DATE:Dec.01.2003 15:12						
KEY-NO. TIMER FUNCTION NO.	DESTINATION STATION					
OT-01 APORO OFFICE 01	OT-01 J.B SUB:1234 999888777666					

• Machine status list (Page1: example)

JAME:ABC 123 MACHINE STATUS LIST				
DATE:Dec.01.2004 15:12				
MACHINE SETTING				
AUTO RESET (min.)	OFF			
ENERGY SAVE MODE (min.)	15			
DENSITY (ADF)	MODE 1			
DENSITY (BOOK)	MODE 1			
PRINT DENSITY		K		
LCD CONTRAST	LIGHT DARK			
LANGUAGE	ENGLISH			
LAMP OFF TIME	MODE 1			
BUZZER VOLUME	LOW			
INITIALMODE	COPY			
PAPER SOURCE SETTING				
	TRAY PAPER	TRAY SETTING		
TRAY1	A4 L	CONTINUOUS		
TRAY2	A4 L	CONTINUOUS		
COPY SETTING		-		
PAPER PRIORITY	PAPER PRIORITY TRAY 1			
DENSITY PRIORITY	AUTO DENSITY			
DENSITY LEVEL (AUTO)	LIGHT DARK			
DENSITY LEVEL (MANUAL)	DENSITY LEVEL (MANUAL)			
OUTPUT PRIORITY	NON			
ADF RESOLUTION	600X300			
FAX REGISTRATION				
ONE TOUCH OR GROUP DIAL	10/15 RESERVED			
SPEED DIAL	004/210 RESERVED			
PROGRAM DIAL	(12) NONE (13) PROGRAM	(14) PROGRAM 15) PROGRAM		
BATCH TX	00/15			
	(01) ID= NONE	(02) ID= NONE		
MAIL BOX	(03) ID= NONE	(04) ID= NONE		
	(05) ID= NONE			
TX OPERATIONS		-		
SCAN CONTRAST	LIGHT DARK			
RESOLUTION	STANDARD			
DEFAULT TX	MEMORY TX			
HEADER	ON			
RX OPERATIONS	1			
MEMORY RX MODE	OFF			
NO. OF RINGS	2			
RIDUCTION RX	ON			
RX PRINT	MEMORY RX			
RX MODE	AUTO RX			
FORWARD	ON(PRINT)			
FOOTER	OFF			
ELECT TRAY TRAY1 :ENABLE				
CLOSED NETWORK	OFF			

Г

• Machine status list (Page2: example)

COMM SETTING TONEPULSE TONE LINE MONITOR LOW STNPX PSTNPX PSTNPX PSTNPX ACTIVITY REPORT O ACTIVITY REPORT O ACTIVITY REPORT O FF TX RESULT REPORT O F FX FX FX FX FX FX FX FX F	NAME:ABC 123 TEL:1234567 DATE:Dec.01.2004 15:12	MACHINE	STATUS LIST		
TONE/PULSE TONE LINE MONITOR LOW PSTN/PBX PSTN ACTIVITY REPORT ON ACTIVITY REPORT OFF TX RESULT REPORT OFF RX RESULT REPORT OFF INITIAL USER DATA. OFF DATE AND TIME JAN 27 2004 10:00 +00:00 USER FAX NUMBER OP1234567880 USER FAX NUMBER GATEWAY TX DISABLE OSCONFIG. DISABLE GATEWAY TX DISABLE SEMAR JE-MAIL ADDRESS aaa @bbb.com SMTP SERVER 333.444.555.666 SMTP PORT NO. 77 SMTP TIMEOUT (sec.) 60 DEFAULT SUBJECT <td>COMM SETTING</td> <td></td> <td></td> <td></td> <td></td>	COMM SETTING				
LINE MONITOR LOW PSTN/PEX PSTN ACTIVITY PEPORT ON ACTIVITY REPORT OFF TX RESULT REPORT OFF XR RESULT REPORT OFF JINITIAL USER DATA. DATE AND TIME DATE AND TIME JAN.27.2004 10:00 + 00:00 USER FAX NUMBER OPI234567890 USER FAX NUMBER OPI234567890 USER FAX NUMBER OPI234567890 USER NAME AAABBBCCC DDDEEE .NETWORK SETTING III .222.333.444 IP ADDRESS 111.222.333.444 SUBNET MASK 555.666.777.888 GATEWAY 999.000.111.222 DNS CONFIG. DISABLE E-MAIL SETTING 1 SENDEN NAME E-MAIL ADDRESS aaa@bbb.com SMTP SERVER 333.444.555.666 SMTP PORT NO. 77 SMTP SERVER 333.444.555.666 SMTP PORT NO. 77 SMTP SERVER 333.444.555.666 SMTP PORT NO. 77 SMTP TIMEOUT (sec.) 60	TONE/PULSE	TONE			
PSTN/PBX PSTN .REPORTING. ACTIVITY REPORT ON RESERVATION REPORT OFF TX RESULT REPORT OFF TX RESULT REPORT OFF	LINE MONITOR	LOW			
REPORTING ON ACTIVITY REPORT ON RESERVATION REPORT OFF TX RESULT REPORT OFF TX RESULT REPORT OFF INITIAL USER DATA DATE AND TIME DATE AND TIME JAN.27.2004 10:00 +00:00 USER FAX NUMBER OP1234567890 USER NAME AAABBBCCC DDDEEE NETWORK SETTING IP IP ADDRESS 111.222.333.444 SUBNET MASK S55.666.777.888 GATEWAY 999.000.111.222 DNS CONFIG. DISABLE GATEWAY X DISABLE E-MAIL SETTING 1 SENDER NAME E-MAIL SETTING 1 SENDER NAME E-MAIL SETTING 1 SENDER NAME E-MAIL SETTING 2 FOF DEFAULT SUBJECT from aaa E-MAIL SETTING 2 FOF DEFAULT SUBJECT from aaa E-MAIL SETTING 2 FOP DEFAULT SUBJECT from aaa E-MAIL SETTING 2 FOP3 TIMEOUT (sec.) FOP3 TIMEOUT (sec.) 60<	PSTN/PBX	PSTN			
ACTIVITY REPORT ON RESERVATION REPORT OFF TX RESULT REPORT OFF RX RESULT REPORT OFF INITIAL USER DATA.	REPORTING				
RESERVATION REPORT OFF TX RESULT REPORT OFF RX RESULT REPORT OFF INITIAL USER DATA DATE AND TIME DATE AND TIME JAN.27.2004 10:00 +00:00 USER RAX NUMBER 0P1234567890 USER NAME AAABBBCCC DDDEEE .NETWORK SETTING	ACTIVITY REPORT	ON			
TX RESULT REPORT OFF RX RESULT REPORT OFF INITIAL USER DATA DATE AND TIME DATE AND TIME JAN.27.2004 10:00 +00:00 USER FAX NUMBER 0P1234567890 USER NAME AAABBBCCC DDDEEE NETWORK SETTING IP IP ADDRESS 111.222.333.444 SUBNET MASK 555.666.777.888 GATEWAY 999.000.111.222 DNS CONFIG. DISABLE GATEWAY 999.000.111.222 DNS CONFIG. DISABLE GATEWAY TX DISABLE GATEWAY TX DISABLE SENDER NAME	RESERVATION REPORT	OFF			
RX RESULT REPORT OFF .INITIAL USER DATA JAN 27.2004 10:00 +00:00 DATE AND TIME JAN 27.2004 10:00 +00:00 USER FAX NUMBER OP1234567890 USER FAX NUMBER OP1234567890 USER FAX NUMBER OP1234567890 USER FAX NUMBER AAABBBCCC DDDEEE .NETWORK SETTING II1.222.333.444 SUBNET MASK 555.666.777.888 GATEWAY Y99.000.111.222 DNS CONFIG. DISABLE GATEWAY TX DISABLE E-MAIL SETTING 1 SENDER NAME E-MAIL ADDRESS aaa@ bbb.com SMTP SERVER 333.444.555.666 SMTP SERVER 333.444.555.666 SMTP TIMEOUT (sec.) 60 TEXT INSERT OFF DEFAULT SUBJECT from aaa E-MAIL SETTING 2 POP3 SERVER POP3 SERVER 888.999.000.111 POP3 SERVER 888.999.000.111 POP3 SERVER 888.999.000.111 POP3 SERVER 60 POP3 ACCOUNT aaa POP3 ACCOUNT <td>TX RESULT REPORT</td> <td>OFF</td> <td></td> <td></td> <td></td>	TX RESULT REPORT	OFF			
INTIAL USER DATA DATE AND TIME JAN.27.2004 10:00 +00:00 USER FAX NUMBER OP1234567890 USER NAME AAABBBCCC DDDEEE NETWORK SETTING IP ADDRESS IP ADDRESS 111.222.333.444 SUBNET MASK 555.666.777.888 GATEWAY 999.000.111.222 DNS CONFIG. DISABLE GATEWAY TX DISABLE SENDER NAME	RX RESULT REPORT	OFF			
DATE AND TIME JAN.27.2004 10:00 +00:00 USER NAME AAABBBCCC DDDEEE .NETWORK SETTING I IP ADDRESS 111.222.333.444 SUBNET MASK 555.666.777.888 GATEWAY 999.000.111.222 DNS CONFIG. DISABLE GATEWAY 999.000.111.222 DNS CONFIG. DISABLE GATEWAY TX DISABLE GATEWAY TX DISABLE SENDER NAME	INITIAL USER DATA				
USER FAX NUMBER OP1234567890 USER NAME AAABBBCCC DDDEEE NETWORK SETTING II1.222.33.444 IP ADDRESS 111.222.33.444 SUBNET MASK 555.666.777.888 GATEWAY 999.000.111.222 DNS CONFIG. DISABLE GATEWAY TX DISABLE E-MAIL SETTING 1 SENDER NAME E-MAIL ADDRESS aaa@bbb.com SMTP SERVER 333.444.555.666 SMTP PORT NO. 77 SMTP FORT NO. 77 SMTP PORT NO. 77 SMTP TIMEQUT (sec.) 60 DEFAULT SUBJECT from aaa E-MAIL SETTING 2 POP3 SERVER POP3 SERVER 888.999.000.111 POP3 ASSWORD **** AUTO RECEPTION (min.) OFF LEADER PRINT ON	DATE AND TIME	JAN.27.2004 10:00	0 +00:00		
USER NAME AAABBBCCC DDDEEE I.NETWORK SETTING II1.222.33.444 SUBNET MASK 555.666.777.888 GATEWAY 999.000.111.222 DNS CONFIG. DISABLE GATEWAY DISABLE GATEWAY TX DISABLE GATEWAY TX DISABLE SENDER NAME	USER FAX NUMBER	0P1234567890			
NETWORK SETTING IP ADDRESS 111.222.333.444 SUBNET MASK 555.666.777.888 GATEWAY 999.000.111.222 DNS CONFIG. DISABLE GATEWAY TX DISABLE E-MAIL SETTING 1 SENDER NAME E-MAIL ADDRESS aaa@bbb.com SMTP TIMEOUT (sec.) 60 TEXT INSERT OFF DEFAULT SUBJECT from aaa E-MAIL SETTING 2. 60 POP3 SERVER 888.999.000.111 POP3 SERVER 60 POP3 TIMEOUT (sec.) 60 POP3 TIMEOUT (sec.) 60 POP3 TACCOUNT aaa POP3 TASSWORD ***** AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON .SCANNER SETTING <	USER NAME	AAABBBCCC DDD	DEEE		
IP ADDRESS 111.222.333.444 SUBNET MASK 555.666.777.888 GATEWAY 999.000.111.222 DNS CONFIG. DISABLE GATEWAY TX DISABLE GATEWAY TX DISABLE SENDER NAME	NETWORK SETTING	1			
SUBNET MASK 555.666.777.888 GATEWAY 999.000.111.222 DNS CONFIG. DISABLE GATEWAY TX DISABLE E-MAIL SETTING 1.	IP ADDRESS	111.222.333.444			
GATEWAY 999.000.111.222 DNS CONFIG. DISABLE GATEWAY TX DISABLE GATEWAY TX DISABLE GATEWAY TX DISABLE SENDER NAME	SUBNET MASK	555.666.777.888			
DNS CONFIG. DISABLE GATEWAY TX DISABLE E-MAIL SETTING 1 SENDER NAME E-MAIL ADDRESS aaa@bbb.com SMTP SERVER 333.444.555.666 SMTP PORT NO. STP SMTP PORT NO. TX OFF DEFAULT SUBJECT from aaa E-MAIL SETTING 2 POP3 SERVER POP3 PORT NO. 888.999.000.111 POP3 PORT NO. 888.999.000.111 POP3 PORT NO. 888 POP3 TIMEOUT (sec.) 60 POP3 ACCCOUNT aaa POP3 ACCOUNT aaa POP3 ACCOUNT AUTO RECEPTION (min.) OFF	GATEWAY	999.000.111.222			
GATEWAY TX DISABLE E-MAIL SETTING 1 SENDER NAME E-MAIL ADDRESS aaa@bbb.com SMTP SERVER 333.444.555.666 SMTP PORT NO. 77 SMTP PORT NO. 77 SMTP TIMEOUT (sec.) 60 TEXT INSERT OFF DEFAULT SUBJECT from aaa E-MAIL SETTING 2 POP3 SERVER POP3 SERVER 888.999.000.111 POP3 SERVER 60 POP3 SERVER 888.999.000.111 POP3 SERVER 888.999.000.111 POP3 SERVER 888.999.000.111 POP3 SERVER 60 POP3 TIMEOUT (sec.) 60 POP3 ACCCOUNT aaa AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON SCANNER SETTING IFF CODING METHOD MH OTHER STATUS. TX/RX TOTAL PAGES TX/RX TOTAL PAGES TX 000000 SCAN COUNTER 000000 INAGE FORMAT </td <td>DNS CONFIG.</td> <td>DISABLE</td> <td></td> <td></td> <td></td>	DNS CONFIG.	DISABLE			
E-MAIL SETTING 1 SENDER NAME E-MAIL ADDRESS aaa@bbb.com SMTP SERVER 333.444.555.666 SMTP PORT NO. SMTP PORT NO. T7 SMTP TIMEOUT (sec.) 60 TEXT INSERT OFF DEFAULT SUBJECT from aaa E-MAIL SETTING 2 POP3 SERVER 888.999.000.111 POP3 SERVER 888 POP3 TIMEOUT (sec.) 60 POP3 PORT NO. 888 POP3 PORT NO. 888 POP3 ACCCOUNT aaa POP3 PASSWORD **** AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON SCANNER SETTING RESOLUTION 300X300 IMAGE FORMAT TIFF CODING METHOD MH	GATEWAY TX	DISABLE			
SENDER NAME	E-MAIL SETTING 1				
E-MAIL ADDRESS aaa@bbb.com SMTP SERVER 333.444.555.666 SMTP PORT NO. 77 SMTP TIMEOUT (sec.) 60 TEXT INSERT OFF DEFAULT SUBJECT from aaa E-MAIL SETTING 2 POP3 SERVER POP3 SERVER 888.999.000.111 POP3 YORT NO. 888 POP3 TIMEOUT (sec.) 60 POP3 TIMEOUT (sec.) 60 POP3 ACCCOUNT aaa AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON SCANNER SETTING RESOLUTION RESOLUTION 300X300 IMAGE FORMAT TIFF CODING METHOD MH OTHER STATUS TX TX/RX TOTAL PAGES TX VSER COUNTER TOTAL COUNTER	SENDER NAME				
SMTP SERVER 333.444.555.666 SMTP PORT NO. 77 SMTP TIMEOUT (sec.) 60 TEXT INSERT OFF DEFAULT SUBJECT from aaa E-MAIL SETTING 2 POP3 SERVER POP3 SERVER 888.999.000.111 POP3 YORT NO. 888 POP3 TIMEOUT (sec.) 60 POP3 ACCCOUNT aaa POP3 PASSWORD **** AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON SCANNER SETTING RESOLUTION RESOLUTION 300X300 IMAGE FORMAT TIFF CODING METHOD MH OTHER STATUS TX TX/RX TOTAL PAGES TX USER COUNTER TOTAL COUNTER	E-MAIL ADDRESS	aaa@bbb.com			
SMTP PORT NO. 77 SMTP TIMEOUT (sec.) 60 TEXT INSERT OFF DEFAULT SUBJECT from aaa E-MAIL SETTING 2 POP3 SERVER POP3 SERVER 888.999.000.111 POP3 PORT NO. 888 POP3 TIMEOUT (sec.) 60 POP3 ACCCOUNT aaa POP3 PASSWORD **** AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON SCANNER SETTING RESOLUTION RESOLUTION 300X300 IMAGE FORMAT TIFF CODING METHOD MH OTHER STATUS TX TX/RX TOTAL PAGES TX USER COUNTER TOTAL COUNTER	SMTP SERVER	333.444.555.666			
SMTP TIMEOUT (sec.) 60 TEXT INSERT OFF DEFAULT SUBJECT from aaa E-MAIL SETTING 2 POP3 SERVER POP3 SERVER 888.999.000.111 POP3 OPRT NO. 888 POP3 TIMEOUT (sec.) 60 POP3 ACCCOUNT aaa POP3 PASSWORD **** AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON SCANNER SETTING RESOLUTION RESOLUTION 300X300 IMAGE FORMAT TIFF CODING METHOD MH OTHER STATUS TX TX/RX TOTAL PAGES TX USER COUNTER TOTAL COUNTER	SMTP PORT NO.	77			
TEXT INSERT OFF DEFAULT SUBJECT from aaa E-MAIL SETTING 2 POP3 SERVER POP3 SERVER 888.999.000.111 POP3 PORT NO. 888 POP3 TIMEOUT (sec.) 60 POP3 ACCCOUNT aaa POP3 PASSWORD **** AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON SCANNER SETTING RESOLUTION RESOLUTION 300X300 IMAGE FORMAT TIFF CODING METHOD MH OTHER STATUS TX TX/RX TOTAL PAGES TX USER COUNTER TOTAL COUNTER	SMTP TIMEOUT (sec.)	60			
DEFAULT SUBJECT from aaa E-MAIL SETTING 2 POP3 SERVER 888.999.000.111 POP3 SERVER 888.999.000.111 POP3 TIMEOUT (sec.) 60 POP3 TIMEOUT (sec.) 60 POP3 ACCCOUNT aaa POP3 PASSWORD **** AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc @ bbb.com HEADER PRINT ON SCANNER SETTING RESOLUTION 300X300 IMAGE FORMAT TIFF CODING METHOD MH O00000 IUSER COUNTER TOTAL COUNTER 000000 IUSER COUNTER 000000 INTAL OOD	TEXT INSERT	OFF			
E-MAIL SETTING 2 POP3 SERVER 888.999.000.111 POP3 PORT NO. 888 POP3 TIMEOUT (sec.) 60 POP3 ACCCOUNT aaa POP3 PASSWORD **** AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON SCANNER SETTING RESOLUTION RESOLUTION 300X300 IMAGE FORMAT TIFF CODING METHOD MH OTHER STATUS TX TX/RX TOTAL PAGES TX 000000 USER COUNTER TOTAL COUNTER 000000	DEFAULT SUBJECT	from aaa			
POP3 SERVER 888.999.000.111 POP3 PORT NO. 888 POP3 TIMEOUT (sec.) 60 POP3 ACCCOUNT aaa POP3 PASSWORD **** AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON SCANNER SETTING RESOLUTION RESOLUTION 300X300 IMAGE FORMAT TIFF CODING METHOD MH OTHER STATUS TX TX/RX TOTAL PAGES TX USER COUNTER TOTAL COUNTER SCAN COUNTER 000000	E-MAIL SETTING 2	1			
POP3 PORT NO. 888 POP3 TIMEOUT (sec.) 60 POP3 ACCCOUNT aaa POP3 PASSWORD **** AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON SCANNER SETTING RESOLUTION RESOLUTION 300X300 IMAGE FORMAT TIFF CODING METHOD MH OTHER STATUS TX TX/RX TOTAL PAGES TX USER COUNTER TOTAL COUNTER SCAN COUNTER 000000	POP3 SERVER	888.999.000.111			
POP3 TIMEOUT (sec.) 60 POP3 ACCCOUNT aaa POP3 PASSWORD **** AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON SCANNER SETTING	POP3 PORT NO.	888			
POP3 ACCCOUNT aaa POP3 PASSWORD **** AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON SCANNER SETTING	POP3 TIMEOUT (sec.)	60			
POP3 PASSWORD **** AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON SCANNER SETTING	POP3 ACCCOUNT	aaa			
AUTO RECEPTION (min.) OFF REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON SCANNER SETTING	POP3 PASSWORD	POP3 PASSWORD ****			
REPLAY ADDRESS ccc@bbb.com HEADER PRINT ON SCANNER SETTING SCANNER SETTING RESOLUTION 300X300 IMAGE FORMAT TIFF CODING METHOD MH OTHER STATUS TX/RX TOTAL PAGES TX/RX TOTAL PAGES TX 000000 USER COUNTER TOTAL COUNTER 000000	AUTO RECEPTION (min.)	OFF			
HEADER PRINT ON SCANNER SETTING SCANNER SETTING RESOLUTION 300X300 IMAGE FORMAT TIFF CODING METHOD MH OTHER STATUS TX/RX TOTAL PAGES TX 000000 RX 000000 USER COUNTER TOTAL COUNTER 000000	REPLAY ADDRESS	ccc@bbb.com			
SCANNER SETTING RESOLUTION 300X300 IMAGE FORMAT TIFF CODING METHOD MH OTHER STATUS TX/RX TOTAL PAGES TX/RX TOTAL PAGES TX 000000 USER COUNTER TOTAL COUNTER 000000	HEADER PRINT ON				
RESOLUTION 300X300 IMAGE FORMAT TIFF CODING METHOD MH OTHER STATUS	SCANNER SETTING				
IMAGE FORMAT TIFF CODING METHOD MH OTHER STATUS	RESOLUTION	300X300			
CODING METHOD MH OTHER STATUS	IMAGE FORMAT	TIFF			
OTHER STATUS TX/RX TOTAL PAGES TX 000000 RX 000000 USER COUNTER TOTAL COUNTER 000000 SCAN COUNTER 000000	CODING METHOD	MH			
TX/RX TOTAL PAGES TX 000000 RX 000000 USER COUNTER TOTAL COUNTER 000000 SCAN COUNTER 000000	OTHER STATUS				
USER COUNTER TOTAL COUNTER 000000 SCAN COUNTER 000000	TX/RX TOTAL PAGES TX 000000 RX 000000			000000	
USER COUNTER SCAN COUNTER 000000		TOTAL COUNTER	000000		
	USER COUNTER	SCAN COUNTER	000000		

• Configuration page (example: bizhub 160f)

KONICA MINOLTA 160f

Printer Configuration Page

Printer Information Printer F/W : 100 Maser F/W : 100 Total Count : 000000 Size Count : 000000

Printer Configuration Printer Memory : 16Mbytes TRAY 1: A4 TRAY 2: A4 Bypass : Installed Output Tray : Installed Network : Ethernet

Network Setting Network Firmware : 100 Network Address : 00:00:00:00:00:00 Network Speed : AUTO

TCP/IP Network Information Protocol Address : 000.000.000.000 Subnetmask : 000.000.000.000 Default Gateway : 000.000.000.000 IPP http ://000.000.000.000/ipp.cgi

Novell Network Information : Printer Server Name : Password Defined : Preferred Server Name : Connection Mode : Directory Services Preferred NDS Tree : • Configuration page (example: bizhub 161f)

KONICA MINOLTA 161f Printer Configuration Page

Printer Information Maser F/W : 100 Printer F/W : 100 Language : English Total Count : 000000 Paper Size Count : 000000

Printer Configuration Printer Memory : 16Mbytes TRAY 1: A4 TRAY 2: A4 Bypass : Installed Output Tray : Standard NIC : Installed

PDL Information

Paper size : A4 Orientation : Portrait Copies : 1 Paper Source : Auto Font Name : Courier Size : 12.0 Pitch : 10.0 Symbol Set : PC-8 Form Length : 64

Network Information NIC F/W : 5.03 Hardware Address: 00:00:00:00:00:00 Network : Ethernet Network Speed : Auto

TCP/IP Configuration IP Address : 000.000.000.000 Subnetmask : 000.000.000.000 Gateway : 000.000.000.000 IPP: HTTP: //000.000.000.000/ipp.cgi DHCP Server : 000.000.000 IP Mode : DHCP

• PCL font list (example: bizhub 161f)

KONICA MINOLTA bizhub 161f PCL Font List 1 Pitch Print Sample & Font Symbol Fix/ Point Stroke Name or Style PS Weight ID Set (cpi) Size Typeface Escape Sequence PC-8 F 01 Scale Upright Medium Courier Р Scale 02 PC-8 Upright Medium CG Times CG Times 03 PC-8 Р Scale Upright Bold Bold --53 PC-850 F 16.67/8.5 Upright Medium Line Printer

9. Utility Mode (bizhub 160/bizhub 161)

• This mode is used to set various machine functions.

9.1 Utility Mode function tree



*: Available only if the NIC NC-501 is installed. (bizhub 161 only)

9.2 Utility Mode setting procedure

9.2.1 Procedure

- 1. Press the Utility key.
- 2. The first Utility Mode screen appears.

9.2.2 Exiting procedure

• Press the Panel Reset key.

9.2.3 Changing the settings for Utility Mode functions

- 1. Press the \blacktriangle / \bigtriangledown key, < / > key or the 10-Key Pad to select the desired function.
- 2. Press the ▲/ ▼ key, < / > key or the 10-Key Pad to select the desired setting.
- 3. Press the Yes key to apply the setting.
- 4. To return to the previous screen, press the No/ C key.



9.2.4 MACHINE SETTING

• Various settings for the machine's operating environment can be specified.

A. AUTO PANEL RESET

Functions / Use	• To specify the time until the auto panel reset operation is performed after a copy cycle has been completed or after the last key operation.		
Setting/Procedure	The default setting is "1" minute.		
	OFF ON:0.5 "1" 2 3 4 5(min)		

B. ENERGY SAVE MODE

Functions / Use	 To specify the time until the machine enters Energy Save mode after a copy cycle has been completed or after the last key operation. 		
Setting/Procedure	The default setting is "15" minutes.		
	"15" min (1 to 240)		

C. DENSITY (ADF)

Functions / Use	 To specify the scanning density when using the Automatic Document Feeder. NOTE In order to reduce the appearance of spots in copies, the Automatic Document Feeder density level is set for lighter copies as a default.
Setting/Procedure	 The default setting is "MODE1." "MODE 1" : For a lighter copy density in order to reduce the appearance of spots in copies MODE 2 : For printing copies with the same density as the document

D. DENSITY (BOOK)

Functions / Use	 To specify the scanning density when using the Original Glass. 		
Setting/Procedure	The default setting is "MODE1."		
	"MODE 1" : For printing copies with the same density as the document MODE 2 : For a lighter copy density in order to reduce the appearance of spots in copies		

E. PRINT DENSITY

Functions / Use	To specify the default print density.
Setting/Procedure	The default setting is "0."
	"0" (-3 to +3)

F. LCD CONTRAST

Functions / Use	To specify the brightness of the display.	
Setting/Procedure	The default setting is "0."	
	"0" (-1 to +2)	

G. LANGUAGE

Functions / Use	To specify the language of screens.		
Setting/Procedure	 The default setting is "ENGLISH." The language settings are divided into Type 1 and Type 2. The Type 1 languages are the standard. Available Languages 		
	Type1 "ENGLISH" GERMAN FRENCH ITALIAN DANISH DUTCH SPANISH NORWEGIAN SWEDISH FINNISH TURKISH PORTUGUESE		
	Type2 "ENGLISH" GERMAN FRENCH CZECH HUNGARIAN POLISH ROMANIAN LITHUANIAN SLOVAKIAN		

H. LAMP OFF TIME

Functions / Use	 To specify the time until the Exposure Lamp goes off. 	
Setting/Procedure	 The default setting is "MODE1." 	
	"MODE 1" : When four hours have passed since the last operation was performed	
	MODE 2 : When the machine enters Energy Save mode	

9.2.5 PAPER SOURCE SETUP

• Various settings for the paper tray can be specified.

A. TRAY1 PAPER

Functions / Use	 To specify the type and size of paper loaded into Tray1. 		
Setting/Procedure	Default setting of paper type is "PLAIN."		
	"PLAIN" OHP CARD ENVELOPE		
	Default setting of paper size depend on the marketing area setting. Metric area : "A4", Inch area : "LT"		
	A5 B5 A4 FLS 16K HL LT LG NOTE • If "OHP" is selected as the paper type, only "A4" and "LT" are available as paper sizes. • To specify a custom paper size, type in the size.		

B. TRAY SETTING

Functions / Use	To specify whether or not auto tray switching is enabled for each paper tray.		
Setting/Procedure	The default setting is "CONTINUOUS."		
	FIXED	"CONTINUOUS"	

Adjustment / Setting

9.2.6 USER MANAGEMENT

• Various functions for use of the machine can be set.

A. CHANGE DC?

Functions / Use	To clear the I/C COUNTER value.
Setting/Procedure	 NOTE If the Drum Cartridge has been replaced, never fail to use this function to clear the "I/C COUNTER" value. This function has the same effect as "SERVICE MODE/CLEAR DATA/I/C COUNTER." 121

9.2.7 COPY SETTING

• The default settings for each copy function can be specified.

A. PAPER PRIORITY

Functions / Use	 To specify the paper tray that is given pr 	iority.
Setting/Procedure	 The default setting is "TRAY1." 	
	"TRAY1"	TRAY2

B. DENSITY PRIORITY

Functions / Use	 To specify the image density setting that is selected when the machine is turned on or the Panel Reset key is pressed.
Setting/Procedure	The default setting is "AUTO."
	"AUTO" MANUAL PHOTO

C. DENSITY LEVEL (A)

Functions / Use	 To specify the default density level when the Auto setting is selected.
Setting/Procedure	The default setting is NORMAL "0."
	"0" (-1 to +1)

D. DENSITY LEVEL (M)

Functions / Use	 To specify the default density level when manually setting the image density.
Setting/Procedure	 The default setting is NORMAL "0."
	"0" (-4 to +4)

E. OUTPUT PRIORITY

Functions / Use	To specify the default finishing setting.	
Setting/Procedure	 The default setting is "NON." 	
	"NON"	SORT

F. RESOLUTION

Functions / Use	To specify the scanning resolution.	
Setting/Procedure	 The default setting is "600×300." 	
	"600×300"	600×600

9.2.8 NETWORK SETTING

 Depending on the network environment in which the machine is located, there may be some restrictions on the network functions that the machine can use. Make the network settings to suit the functions and environment required for customer's location. The network settings can be specified from the control panel or using the administrator mode of Page Scope Web Connection.

A. IP ADDRESS

Functions / Use	 This function is used to specify the IP address for the copier.
	 NOTE Available only if the NIC NC-501 is installed. Please consult customer's network administrator for information about the IP address to use.
Setting/Procedure	The default setting is "AUTO."
	"AUTO" SPECIFY
	 If AUTO is selected, the IP address is automatically acquired from the DHCP server.
	 NOTE AUTO is only enabled if there is a DHCP server available on the network. When IP address cannot be acquired from the DHCP server, IP address is acquired by the "Auto-IP function." When AUTO is selected, there is no need to set the subnet mask or gateway setting. When using a fixed IP address, IP Address in NVRAM must be selected for Page Scope Web Connection. Select this option from the "TCP/IP Configuration" menu on the "Network" tab.
	 If SPECIFY is selected, the screen for entering the IP address appears.

B. SUBNET MASK

Functions / Use	 This function is used to specify the subnet mask value for the network.
	 NOTE Available only if the NIC NC-501 is installed. Please consult customer's network administrator for information about the subnet mask to use.
Setting/Procedure	 Setting LAN connect to WAN the net mask address.
	 NOTE If Auto is selected for "1 IP Address/Auto," the items of "2 Subnet mask" and "3 Gateway" are automatically set. Key entry is therefore disabled for "2 Subnet mask" and "3 Gateway."

C. GATEWAY

Functions / Use	 This function is used to specify the default gateway (IP address) of a router on the network.
	 NOTE Available only if the NIC NC-501 is installed. Please consult customer's network administrator for information about the gateway to use.
Setting/Procedure	 Setting LAN address. NOTE If Auto is selected for "1 IP Address/Auto," the items of "2 Subnet mask" and "3 Gateway" are automatically set. Key entry is therefore disabled for "2 Subnet mask" and "3 Gateway."

10. Utility Mode (bizhub 160f/bizhub 161f)

• This mode is used to set various machine functions.

10.1 Utility Mode function tree



bizhub 160/160f bizhub 161/161f



*: Available only if the NIC NC-501 is installed.

**: Available only if the Internet Fax & Network Scan Kit SU-502 is installed.



*: Available only if the NIC NC-501 is installed.

**: Available only if the Internet Fax & Network Scan Kit SU-502 is installed.

10.2 Utility Mode setting procedure

10.2.1 Procedure

- 1. Press the Utility key.
- 2. The first Utility mode screen appears.

10.2.2 Exiting procedure

• Press the Panel Reset key.

10.2.3 Changing the settings for Utility Mode Functions

- 1. Press the \blacktriangle / \forall key, < / > key or the 10-Key Pad to select the desired function.
- 2. Press the \blacktriangle / \forall key, < / > key or the 10-Key Pad to select the desired setting.
- 3. Press the Yes key to apply the setting.
- 4. To return to the previous screen, press the No/ C key.



10.2.4 MACHINE SETTING

• Various settings for the machine's operating environment can be specified.

A. AUTO PANEL RESET

Functions / Use	• To specify the time until the auto panel reset operation is performed after a copy cycle has been completed or after the last key operation.
Setting/Procedure	The default setting is "1" minute.
	OFF ON:0.5 "1" 2 3 4 5 (min)

B. ENERGY SAVE MODE

Functions / Use	 To specify the time until the machine enters Energy Save mode after a copy cycle has been completed or after the last key operation.
Setting/Procedure	The default setting is "15" minutes.
	"15" min (1 to 240)

C. DENSITY (ADF)

Functions / Use	 To specify the scanning density when using the Automatic Document Feeder. NOTE In order to reduce the appearance of spots in copies, the Automatic Document Feeder density level is set for lighter copies as a default. 		
Setting/Procedure	The default setting is "MODE1."		
	"MODE 1" :For a lighter copy density in order to reduce the appearance of spots in copies		
	MODE 2 : For printing copies with the same density as the document		

D. DENSITY (BOOK)

Functions / Use	 To specify the scanning density when using the Original Glass. 		
Setting/Procedure	The default setting is "MODE1."		
	"MODE 1" : For printing copies with the same density as the document MODE 2 : For a lighter copy density in order to reduce the appearance of spots in copies		

E. PRINT DENSITY

Functions / Use	•	To specify the default print density.
Setting/Procedure	•	The default setting is "0."
		"0" (-3 to +3)

F. LCD CONTRAST

Functions / Use	To specify the brightness of the display.		
Setting/Procedure	The default setting is "0."		
	"0" (-1 to +2)		

Adjustment / Setting
G. LANGUAGE

Functions / Use	 To specify the language of screens. 	
Setting/Procedure	 The default setting is "ENGLISH." The language settings are divided into Type 1 and Type 2. The Type 1 languages are the standard. Available Languages 	
	Type1 "ENGLISH" GERMAN FRENCH ITALIAN DANISH DUTCH SPANISH NORWEGIAN SWEDISH FINNISH TURKISH PORTUGUESE	
	Type2 "ENGLISH" GERMAN FRENCH CZECH HUNGARIAN POLISH ROMANIAN LITHUANIAN SLOVAKIAN	

H. LAMP OFF TIME

Functions / Use	To specify the time until the Exposure Lamp goes off.		
Setting/Procedure	 The default setting is "MODE1." 		
	"MODE 1" : When four hours have passed since the last operation was performed MODE 2 : When the machine enters Energy Save mode		

I. BUZZER VOLUME

Functions / Use	To set the volume of alarms and the beep sounded when a key is pressed.		
Setting/Procedure	The default setting is "LOW."		
	HIGHT "LOW" OFF		

J. INITIAL MODE

Functions / Use	 To set the mode (Copy mode or Fax mode) that the machine starts up in or returns to after the Control Panel is reset. 	
Setting/Procedure	 The default setting is "COPY." 	
	"COPY"	FAX

10.2.5 PAPER SOURCE SETUP

• Various settings for the paper tray can be specified.

A. TRAY1 PAPER

Functions / Use	 To specify the type and size of paper loaded into Tray1. 	
Setting/Procedure	Default setting of paper type is "PLAIN."	
	"PLAIN" OHP CARD ENVELOPE	
	 Default setting of paper size depend on the marketing area setting. Metric area : "A4", Inch area : "LT" 	
	A5 B5 A4 FLS 16K HL LT LG NOTE • If "OHP" is selected as the paper type, only "A4" and "LT" are available as paper sizes.	
	 To specify a custom paper size, type in the size. 	

B. TRAY SETTING

Functions / Use	To specify whether or not auto tray switching is enabled for each paper tray.		
Setting/Procedure	 The default setting is "CONTINUOUS." 		
	FIXED	"CONTINUOUS"	

10.2.6 USER MANAGEMENT

• Various functions for use of the machine can be set.

A. CHANGE DC?

Functions / Use	To clear the I/C COUNTER value.
Setting/Procedure	 NOTE If the Drum Cartridge has been replaced, never fail to use this function to clear the "I/C COUNTER" value. This function has the same effect as "SERVICE MODE/CLEAR DATA/I/C COUNTER." 121

10.2.7 ADMIN. MANAGEMENT

- Various functions for controlling the use of the machine can be set.
- In order to set an "ADMIN. MANAGEMENT" function, the administrator number (ADMIN. NO.) must be entered.
- 🖙 153

ADMIN. NO=____

A. REMOTE MONITOR

Functions / Use	 To set the access right when monitoring a user machine from a remote location on the Service side. 	
	RSD is used for remote monitoring.	
Setting/Procedure	The default setting is "LIMITED."	
	"LIMITED" FULL OFF	
	LIMITED:	
	 Access right with limited functions. Detailed settings made in the user machine can be monitored. It is, however, not possible to change the user setting or upgrade firmware. 	
	FULL:	
	 Access right with no restrictions. In addition to being able to monitor the detailed settings made in the user machine, the Service can change user settings and upgrade firmware. When "FULL" is selected, the "Remote Monitoring Password" screen will appear. 	
	PASSWORD= OK=YES	
	The Administrator of the user machine sets a 4-digit (0000 to 9999) "Remote Monitoring Password."	
	 This password is necessary for Remote Monitoring and must be obtained in advance from the Administrator of the user machine. 	
	OFF:	
	Access is prohibited. Remote Monitoring is disabled.	

NOTE

Precautions for Changing the Setting of ADMIN. MANAGEMENT/REMOTE MONITOR If the user machine setting has been changed from "LIMITED" to "FULL" or vice versa while RSD (Remote Setup Diagnostic) communication is established, perform the following operations:

- Temporarily disconnect the communication and re-execute "Remote Connect."
- Press the "Disconnect" key to disconnect the communication.



- The specific changes made in the setting of REMOTE MONITOR are not validated unless the connection is made again.
- < Precautions for Using the RSD (Remote Setup Diagnostic)>
- When a connection is established with a local machine using the RSD, the following message appears on the Display and no operations can be made from the "Control Panel" of the local machine. Neither the PC print nor Scanner function can be accepted.



- No connection can be made with the RSD during operation from the "Control Panel" of the local machine. Make the connection while no operations are performed on the local machine.
- As is the case with the RSD, operations from the "Control Panel" of the local machine, PC print, and Scanner function are not accepted while a connection is being established with the local machine using the LSD (Local Setup Diagnostic) and Page Scope Web Connection/Admin. mode.
- As is the case with the RSD, no connection can be made with LSD and Page Scope Web Connection/Admin. mode during operation from the "Control Panel" of the local machine. Make the connection while no operations are performed on the local machine.

bizhub 160/160f bizhub 161/161f

10.2.8 COPY SETTING

• The default settings for each copy function can be specified.

A. PAPER PRIORITY

Functions / Use	To specify the paper tray that is given priority.		
Setting/Procedure	The default setting is "TRAY1."		
	"TRAY1"	TRAY2	

B. DENSITY PRIORITY

Functions / Use	•	• To specify the image density setting that is selected when the machine is turned on or the Panel Reset key is pressed.		
Setting/Procedure	•	The default setting is "AUTO."		
		"AUTO"	MANUAL	РНОТО

C. DENSITY LEVEL (A)

Functions / Use	To specify the default density level when the Auto setting is selected.	
Setting/Procedure	The default setting is NORMAL "0."	
	"0" (-1 to +1)	

D. DENSITY LEVEL (M)

Functions / Use	To specify the default density level when manually setting the image density.		
Setting/Procedure	 The default setting is NORMAL "0." 		
	"0" (-4 to +4)		

E. OUTPUT PRIORITY

Functions / Use	 To specify the default finishing setting. 	
Setting/Procedure	 The default setting is "NON." 	
	"NON"	SORT

F. RESOLUTION

Functions / Use	To specify the scanning resolution.		
Setting/Procedure	 The default setting is "600×300." 		
	"600×300"	600×600	

10.2.9 FAX REGISTRATION

• From the "FAX REGISTRATION" menu, various settings can be specified in order to take advantage of this machine's many fax functions.

A. ONE-TOUCH DIAL

Functions / Use	 This function can allowing the recip manually enter th nient for program 	be used to program one-touch dial keys with fax numbers, ient to be specified easily and accurately without the need to e number using the 10-Key Pad. This dialing method is conve- ming numbers where faxes are frequently sent to.
Setting/Procedure	A maximum of 15	fax numbers can be programmed.
	The contents of regi Destination name Dial No. Sub address SID Modem speed Registered data	istration. : 20 characters. : 30 digits. : 20 digits. : 20 digits. : 33.6 kbps/ 14.4 kbps/ 9.6 kbps : Automatically.

B. SPEED DIAL

Functions / Use	 This function can be used to program speed dial numbers with fax numbers, allowing the recipient to be specified easily and accurately without the need to manually enter the number using the 10-Key Pad.
Setting/Procedure	 A maximum of 200 fax numbers (001 to 200) can be programmed. The contents of registration. Destination name : 20 characters. Dial No. : 30 digits. Sub address : 20 digits. SID : 20 digits. Modem speed : 33.6 kbps/ 14.4 kbps/ 9.6 kbps Registered data : Automatically.

C. GROUP DIAL

Functions / Use	 This function can be used to program a single one-touch dial key with a maximum of 50 different fax numbers as one group. Programming a one-touch dial key with a group of fax numbers is convenient when documents are frequently sent to a set group of multiple recipients. 	
Setting/Procedure	The contents of registration.Group nameInformation of destination station	: 20 characters. : The contents of one-touch or speed dial.

D. PROGRAM DIAL

Functions / Use	 This function can be used to program one-touch dial keys (No. 12 to 15) with fax numbers and a transmission/reception function (such as timer transmission or polling reception), allowing that function to be carried out by pressing just the corresponding one-touch dial key. 				
Setting/Procedure	 If o sion res The 	 If one-touch dial keys have been programmed with fax numbers and a transmission/reception function, that function can be carried out by pressing just the corresponding one-touch dial key. The function of registration 			
		Function No. Function Description			
		1 BROADCAST Up to 50 detection			
		2 TIMER TX -			
		3 MAIBOX TX -			
		6	POLLING RX	Up to 50 detection	
		7	RELEY INITIATE	-	

E. BATCH TX

Functions / Use	 This function can be used to specify the batch transmission setting (transmission time) for a one-touch dial key programmed with recipient fax numbers, so multi- ple documents can be stored in the memory and sent out together at the speci- fied time.
Setting/Procedure	 If the batch transmission setting (transmission time) is specified for a one-touch dial key programmed with recipient fax numbers, multiple documents can be stored in the memory and sent out together at the specified time. A one-touch dial key must first be programmed with the fax number of the recipient for the batch transmission. Cannot set for e-mail address.

F. MAILBOX

Functions / Use	 This function can be used to specify mailbox IDs in order to receive faxes with mailbox reception only if the mailbox ID sent by the caller matches the mailbox ID set on this machine.
Setting/Procedure	 Mailbox IDs must first be specified in order to receive faxes with mailbox reception only if the mailbox ID sent by the caller matches the mailbox ID set on this machine. A mailbox ID cannot be the same as a relay box ID. Setting value : 0000 to 9999 Password : Setting range 0 to 9999, or none.

10.2.10 TX OPERATION

• From the "TX OPERATION" menu, various functions for sending faxes can be set.

A. SCAN CONTRAST

Functions / Use	 This function can be used to set the default scanning contrast level to one of five settings between "LIGHT" and "DARK." For dark-colored paper (media), select a setting towards "LIGHT." For faint or colored text, select a setting toward "DARK." 			
Setting/Procedure	 The defau 	It setting is "0."		
		Setting value	Description	
		-2		4980S506AA
		-1		4980S505AA
		"0"		4980S502AA
		+1		4980S503AA
		+2		4980S504AA

B. RESOLUTION

Functions / Use	 This function can be used to set the default scanning resolution (image quality) to one of the following: "Standard", "Fine", "Super Fine", "Half Tone + Standard", "Half Tone + Fine" or "Half Tone + Super Fine."
Setting/Procedure	 The default setting is "STD." The resolution when transmission image mode is Text. "STD": Standard FINE : Fine S/F : Super Fine H/T : Half Tone -> to the resolution when transmission image mode is half-tone.

C. DEFAULT TX

Functions / Use	 This function can be used to set the default setting (ON or OFF) for adding the header (date sent, sender's name and fax number, etc.) when sending faxes.
Setting/Procedure	The default setting is "MEM.TX."
	"MEM TX" : Memory Transmission ADF TX : Direct transmission

D. HEADER

Functions / Use	 This function can be used to specify mailbox IDs in order to receive faxes with mailbox reception only if the mailbox ID sent by the caller matches the mailbox ID set on this machine. 		
Setting/Procedure	The default setting is "ON."		
	"ON" : Add header OFF : No header		
	The contents of registration.		
	TX data and time.		
	Transmitter's own name.		
	Iransmitter's own tei number. Session number		
	Session number Page number		
	 Total page number. Total page number (only displayed by use the memory TX job). It is selectable by soft switch to transmit only pages which have failed to transmit if communication error occurs on the way transmitting document. In this case, page number on Header Print is continued from the page number of the document successfully transmitted. Whether user setting is allowed or not is selectable with Soft switch. 		
	 For North America, Header print is set ON, and setting change to OFF by the user is not allowed. 		
	 Attaching Header Print: Image within 4 mm (1/4 in.) top margin of transmitting document is not transmit- ted and Header print data is attached. 		

10.2.11 RX OPERATION

• From the RX OPERATION menu, various functions for receiving faxes can be set.

A. MEMORY RX MODE

Functions / Use	 This function can be used to set whether to allow ("ON") memory reception or not ("OFF"). In cases when confidential faxes are being received, the received document can be stored in the memory and printed at a specified time or when memory reception is set to "OFF." A password can be set to specify the starting time or ending time of memory reception, or to cancel the function. The set start- ing time and ending time are valid every day until memory reception is turned off.
Setting/Procedure	The default setting is "OFF."
	ON : Enable memory RX mode "OFF" : Disable memory RX mode

B. No. of RINGS

Functions / Use	 This function can be call is answered. 	e used to set the n	umber of rings be	tween 1 and 16 until the
Setting/Procedure	 The default setting is "2" (marketing area: standard). Depend on soft switch setting of marketing area. 			
	1 : Once 5 : 5 times 9 : 9 times 13 : 13 times NOTE • A fax to be receiv receive it if the se	"2" : Twice 6 : 6 times 10 : 10 times 14 : 14 times ed is cancelled at	3 : 3 times 7 : 7 times 11 : 11 times 15 : 15 times nd the machine b INGS" is made to	4 : 4 times 8 : 8 times 12 : 12 times 16 : 16 times
	of "CNG duration Be sure to make t "CNG duration aft 199 : SOFT SWI	after dialing." the "No. of RINGS ter dialing" settin TCH/ #21/ Bit No. (5" setting to a val g. 6-7: CNG duration	ue shorter than the after dialing

C. REDUCTION RX

Functions / Use	 This function can be used to set whether documents longer than the paper are printed reduced ("ON"), split ("OFF"), or discarded ("CUT"). However, when sending a document more than 24 mm (1 in.) longer than the paper, "CUT" is not available. (In this case, the document is split.) 	
Setting/Procedure	The default setting is "ON." "ON" : Reduction print mode OFF : 100 % RX mode CUT : Cut mode	

(1) Reduction print mode

Recording paper size	Footer	Length of received image	Printing
		Less than 289 mm	1 page with 100 %
		290 mm to 385 mm	1 page with (289 mm / image length)% reduction
	OFF	386 mm to 570 mm	Divide into 2 pages with 100 %
		571 mm to 851 mm	Divide into 3 pages with 100 %
A.4		851 mm or more	Divide into 3 pages (or more) with 100 %
A4		Less than 285 mm	1 page with 100 %
		286 mm to 381 mm	1 page with (285 mm / image length)% reduction
	ON	382 mm to 562 mm	Divide into 2 pages with 100 %
		563 mm to 839 mm	Divide into 3 pages with 100 %
		840 mm or more	Divide into 3 pages (or more) with 100 %
		Less than 271 mm	1 page with 100 %
		272 mm to 387 mm	1 page with (271 mm / image length)% reduction
	OFF	388 mm to 534 mm	Divide into 2 pages with 100 %
		535 mm to 797 mm	Divide into 3 pages with 100 %
Latter		798 mm or more	Divide into 3 pages (or more) with 100 %
Letter	ON	Less than 267 mm	1 page with 100 %
		268 mm to 381 mm	1 page with (267 mm / image length)% reduction
		382 mm to 526 mm	Divide into 2 pages with 100 %
		527 mm to 785 mm	Divide into 3 pages with 100 %
		786 mm or more	Divide into 3 pages (or more) with 100 %
		Less than 347 mm	1 page with 100 %
	OFF	348 mm to 385 mm	1 page with (347 mm / image length)% reduction
		386 mm to 686 mm	Divide into 2 pages with 100 %
		687 mm to 1025 mm	Divide into 3 pages with 100 %
Legal		1,026 mm or more	Divide into 3 pages (or more) with 100 %
	ON	Less than 343 mm	1 page with 100 %
		344 mm to 381 mm	1 page with (343 mm / image length)% reduction
		382 mm to 678 mm	Divide into 2 pages with 100 %
		679 mm to 1013 mm	Divide into 3 pages with 100 %
		1,014 mm or more	Divide into 3 pages (or more) with 100 %

(2) 100 % RX mode

• All receiving data is divided into 2 pages or more, and is printed.

Recording paper size	Footer	Length of received image	Printing
		Less than 289 mm	1 page
	OFF	290 mm to 570 mm	Divide into 2 pages
	011	571 mm to 851 mm	Divide into 3 pages
A.4		852 mm or more	Divide into 4 pages or more
~~		Less than 285 mm	1 page
		286 mm to 562 mm	Divide into 2 pages
	ON	563 mm to 839 mm	Divide into 3 pages
		840 mm or more	Divide into 4 pages or more
		Less than 271 mm	1 page
	OFF	272 mm to 534 mm	Divide into 2 pages
	011	535 mm to 797 mm	Divide into 3 pages
Lottor		798 mm or more	Divide into 4 pages or more
Leller	ON	Less than 267 mm	1 page
		268 mm to 526 mm	Divide into 2 pages
		527 mm to 785 mm	Divide into 3 pages
		786 mm or more	Divide into 4 pages or more
	OFF	Less than 348 mm	1 page
		349 mm to 688 mm	Divide into 2 pages
		689 mm to 1,028 mm	Divide into 3 pages
Legal		1,029 mm or more	Divide into 4 pages or more
		Less than 344 mm	1 page
		345 mm to 680 mm	Divide into 2 pages
		681 mm to 1,016 mm	Divide into 3 pages
		1,017 mm or more	Divide into 4 pages or more

(3) Cut mode

• The data that is larger than 1-page record area is cut and not recorded (to 18 mm).

Recording paper size	Footer	Length of received image	Printing	
		Less than 289 mm	1 page	
		290 mm to 313 mm	Print into 1 page. 1 mm to 24 mm of end is cut.	
	OFF	314 mm to 570 mm	Divide into 2 pages	
	OFF	571 mm to 594 mm	Divide into 2 pages. 1 mm to 24 mm of end is cut.	
		595 mm to 851 mm	Divide into 3 pages	
A.4		852 mm or more	Divide into 3 pages (or more). 1 mm to 24 mm of end is cut.	
A4		Less than 285 mm	1 page	
		286 mm to 309 mm	Print into 1 page. 1 mm to 24 mm of end is cut.	
		310 mm to 562 mm	Divide into 2 pages	
	ON	563 mm to 586 mm	Divide into 2 pages. 1 mm to 24 mm of end is cut.	
		587 mm to 839 mm	Divide into 3 pages	
		840 mm or more	Divide into 3 pages (or more). 1 mm to 24 mm of end is cut.	
		Less than 271 mm	1 page	
		272 mm to 295 mm	Print into 1 page. 1 mm to 24 mm of end is cut.	
	OFF	296 mm to 534 mm	Divide into 2 pages	
	OFF	535 mm to 558 mm	Divide into 2 pages. 1 mm to 24 mm of end is cut.	
		559 mm to 797 mm	Divide into 3 pages	
Lattor		798 mm or more	Divide into 3 pages (or more). 1 mm to 24 mm of end is cut.	
Letter	ON	Less than 267 mm	1 page	
		268 mm to 291 mm	Print into 1 page. 1 mm to 24 mm of end is cut.	
		292 mm to 526 mm	Divide into 2 pages	
		527 mm to 550 mm	Divide into 2 pages. 1 mm to 24 mm of end is cut.	
		510 mm to 785 mm	Divide into 3 pages	
		786 mm or more	Divide into 3 pages (or more). 1 mm to 24 mm of end is cut.	
		Less than 347 mm	1 page	
		348 mm to 371 mm	Print into 1 page. 1 mm to 24 mm of end is cut.	
	OFF	372 mm to 686 mm	Divide into 2 pages	
		687 mm to 710 mm	Divide into 2 pages. 1 mm to 24 mm of end is cut.	
		711 mm to 1,025 mm	Divide into 3 pages	
Legal		1,026 mm or more	Divide into 3 pages (or more). 1 mm to 24 mm of end is cut.	
	ON	Less than 343 mm	1 page	
		344 mm to 367 mm	Print into 1 page. 1 mm to 24 mm of end is cut.	
		368 mm to 678 mm	Divide into 2 pages	
		679 mm to 702 mm	Divide into 2 pages. 1 mm to 24 mm of end is cut.	
		703 mm to 1,13 mm	Divide into 3 pages	
		1,014 mm or more	Divide into 3 pages (or more). 1 mm to 24 mm of end is cut.	

D. RX PRINT

Functions / Use	 This function can be used to set whether the fax is only printed after all document pages have been received ("MEMORY RX") or printing begins as soon as the first page of the document is received ("PRINT RX"). 	
Setting/Procedure	The default setting is "MEMORY RX."	
	"MEMORY RX" : Printed after all document pages have been received. PRINT RX : Printing begins as soon as the first page of the document is received.	

E. RX MODE

Functions / Use	 This function can be used to set the reception mode to automatic reception ("AUTO RX") or manual reception ("MANUAL RX"). Automatic reception : Automatically begins receiving after the set number of rings.
	Manual reception : Does not automatically receive the fax. Reception begins after making a connection by picking up the telephone receiver or pressing the Speaker key, then pressing the Start key.
Setting/Procedure	The default setting is "AUTO RX." "AUTO RX" : Automatic reception MANUAL RX : Manual reception

F. FORWARD

Functions / Use	 This function can be used to set whether or not the received document is forwarded. Forward : The received document is forwarded to the specified fax ("ON") number or e-mail address. Forward and print : The received document is printed by this machine at the ("ON (PRINT)") same time that it is forwarded to the specified fax number or e-mail address. Do not forward : The document is not forwarded. ("OFF") 	
Setting/Procedure	The default setting is "OFF." ON : Add forward "OFF" : No forward	

G. FOOTER

Functions / Use	This function can be used to set whether or not the reception information (RX data and time, RX management number, RX page number, Transmitter's ID) is printed at the bottom of each received document.	
Setting/Procedure	The default setting is "OFF." ON : Add footer "OFF" : No footer	

• Attaching footer print:

When Footer is selected ON, it is printed at the end of printable area. 4mm line area from the end of printable area is kept for printing Footer. It should be attached on Footer area regardless of image length. If the received image is divided into 2 pages or more, Footer is printed in the specified location of all the recording sheets of paper printed.

Image data area:

The received image data is printed on the area except for 12mm from recording paper size. (No printable area: 8mm (1/3 in) + Footer area: 4mm (1/4 in)) The following table is the image printable area of each recording paper size due to setting of Footer Print.

Paper length		Footer off	Footer on	
		Image data area	Image data area	Footer area
A4	297 mm	289 mm	285 mm	+4 mm (1/4 in)
Letter	279 mm	271 mm	267 mm	+4 mm (1/4 in)
Legal	356 mm	348 mm	344 mm	+4 mm (1/4 in)

H. SELECT TRAY

Functions / Use	 This function can be used to select which paper tray can be used to supply paper when printing received documents or transmission reports. (A paper tray that cannot be used for supplying paper can also be specified.) This function is only available when an optional paper tray is installed. 	
Setting/Procedure	 The default setting is "Enable." Tray1 : "Enable" Disable Tray2 : "Enable" Disable A non-equipped cassette is not displayed. When setting value is determined, reception setting of utility menu is indicated. This setting has effect on RX print and Report print. 	

I. CLOSED NETWORK

Functions / Use	 This function can be used to set whether or not the fax is received if the sender's fax number does not match the fax number programmed in this machine's one- touch dial keys. 	
Setting/Procedure	The default setting is "OFF."	
	ON : Enable closed network reception "OFF" : Disable closed network reception	

10.2.12 COMM. SETTING

 From the "COMM.SETTING" menu, various functions are available for specifying communication settings.

A. TONE/ PULSE

Functions / Use	 This function can be used to specify the dialing system. If this function is not correctly set to the type of dialing system used, faxes cannot be sent. Select the correct setting after checking which type of dialing system is used by your telephone line. There are two types of telephone dialing systems: tone dialing (PB) and pulse dialing (DP10pps or DP20pps). Faxes cannot be sent if this machine is not set to the system used by your telephone line. Select the correct setting after checking which type of dialing system is used.
Setting/Procedure	The default setting is "TONE." "TONE" : Tone line PULSE 10pps : Pulse line of 10 pps PULSE 20pps : Pulse line of 20 pps

B. LINE MONITOR

Functions / Use	This function can be used to set the volume when monitoring communication to "HIGH", "LOW" or "OFF."	
	Usual TX/ RX (Start) : Pressing Start key following pressing ten-key. Pressing Start key following pressing Speed dial. Pressing One-touch key. Pressing Redial key.	
	Usual TX/ RX (End) : After receiving V21 signal.	
	 Using Speaker key (Start) : Just after pressing Speaker key. 	
	Using Speaker key (End) : Just after pressing Speaker key	
Setting/Procedure	The default setting is "LOW."	
	HIGE Usual TX/ RX : High, Usual SPEAKER key : High "LOW" Usual TX/ RX : Low, Usual SPEAKER key : Low OFF Usual TX/ RX : Off, Usual SPEAKER key : Low	

C. PSTN/ PBX

Functions / Use	 This function can be used to set whether the connected telephone wiring is a public switched telephone network (PSTN) or a private branch exchange (PBX). For a PBX system, the outside line access number (or extension number) must be specified. The connected wiring system can be set to either PSTN (Public Switched Telephone Network) or PBX (Private Branch Exchange). For a PBX system, the outside line access number (or extension number) must be specified. The outside line access number (or extension number) is programmed in the [#] key.
Setting/Procedure	The default setting is "PSTN."
	"PSTN" : Public Switched Telephone Network PBX : Private Branch Exchange

10.2.13 REPORTING

• From the "REPORTING" menu, various functions are available for specifying which reports are automatically printed.

A. ACTIVITY REPORT

Functions / Use	 Every 60 transmissions/receptions, the transmissions/receptions. This f report is printed automatically when 	a report can be printed to show the results of unction can be used to set whether the the 60th transmission/ reception is reached.
Setting/Procedure	 The default setting is "ON." 	
	"ON"	OFF

B. RESERV.REPORT

Functions / Use	 If multiple recipients are specified for mission and polling reception, a rep This function can be used to set wh 	or transmission, such as with broadcast trans- ort can be printed to show specified settings. Nether this report is printed automatically.
Setting/Procedure	 The default setting is "OFF." 	
	ON	"OFF"

C. TX RESULT REPORT

Functions / Use	This function can be used to set whether mission is printed automatically after the	er the report showing the result of a trans- e transmission is finished.
Setting/Procedure	 The default setting is "OFF." 	
	ON	"OFF"

D. RX RESULT REPORT

Functions / Use	 This function can be used to set reception is printed automaticall (If regular reception is not finisher regardless of the selected settin 	whether the report showing the result of a y after mailbox reception is finished. ed normally, a report will always be printed, g.)
Setting/Procedure	 The default setting is "OFF." 	
	ON	"OFF"

10.2.14 INITIAL USER DATA

• Various settings for the machine's user data can be specified.

A. DATE & TIME

Setting value	Description	
Hour	00 to 23	
Minute	00 to 59	
Year	00 to 99 (2000 to 2099 will be meant)	
Month	01 to 12	
Day	01 to 28, 29, 30, 31	
Time Zone	-12 hour to +12hour, interval: 30 minute.	

B. USER FAX No.

Functions / Use	 User fax number is set to TSI (Transmitting Station Identification), CSI (Called Subscriber Identification) during communication. A symbol is printed on header and Status list, but only figure is set to TSI, CSI signal. This is checked with the communication permission ID registered at destination station in case of Closed network.
Setting/Procedure	 Max. 20 digits. The characters which can be inputted are "numbers from 0 to 9", "Space", "+" and ""

C. USER NAME

Functions / Use	 The User Name is used for the indication of destination station at the time of the communication between same models.
Setting/Procedure	Maximum 32 digits character can be inputted.

10.2.15 NETWORK SETTING

• Depending on the network environment in which the machine is located, there may be some restrictions on the network functions that the machine can use. Make the network settings to suit the functions and environment required for customer's location. The network settings can be specified from the control panel or using the administrator mode of Page Scope Web Connection.

A. IP ADDRESS

Functions / Use	 This function is used to specify the IP address for the copier. 	
	 NOTE Available only if the NIC NC-501 is installed. Please consult customer's network administrator for information about the IP address to use. 	
Setting/Procedure	The default setting is "AUTO."	
	"AUTO" SPECIFY	
	 If "AUTO" is selected, the IP address is automatically acquired from the DHCP server. 	
	 NOTE AUTO is only enabled if there is a DHCP server available on the network. When IP address cannot be acquired from the DHCP server, IP address is acquired by the "Auto-IP function." When AUTO is selected, there is no need to set the subnet mask or gateway setting. When using a fixed IP address, IP Address in NVRAM must be selected for Page Scope Web Connection. Select this option from the "TCP/IP Configuration" menu on the "Network" tab. 	
	 If SPECIFY is selected, the screen for entering the IP address appears. 	

B. SUBNET MASK

Functions / Use	 This function is used to specify the subnet mask value for the network. NOTE Available only if the NIC NC-501 is installed. Please consult customer's network administrator for information about the subnet mask to use.
Setting/Procedure	 Setting LAN connect to WAN the net mask address. NOTE If Auto is selected for "1 IP Address/Auto," the items of "2 Subnet mask" and "3 Gateway" are automatically set. Key entry is therefore disabled for "2 Subnet mask" and "3 Gateway."

C. GATEWAY

Functions / Use	 This function is used to specify the default gateway (IP address) of a router on the network.
	 NOTE Available only if the NIC NC-501 is installed. Please consult customer's network administrator for information about the gateway to use.
Setting/Procedure	Setting LAN address.
	 NOTE If Auto is selected for "1 IP Address/Auto," the items of "2 Subnet mask" and "3 Gateway" are automatically set. Key entry is therefore disabled for "2 Subnet mask" and "3 Gateway."

D. DNS CONFIG.

Functions / Use	 This function is used to enable or disable the DNS (Domain Name System) setting. If there is a DNS server on your network, enter the IP address of the DNS server. *If the DNS server is located within your local network, select Enable. If you are using the DNS server of an Internet service provider (ISP) or some other DNS server located outside your local network, select Disable.
	NOTE Available only if the Internet Fax & Network Scan Kit SU-502 is installed. Please consult customer's network administrator for details.
Setting/Procedure	The default setting is "DISABLE."
	"DISABLE" ENABLE
	 If DISABLE is selected, the NETWORK SETTING screen appears. If ENABLE is selected, the screen for entering the IP address of the DNS server appears.

E. GATEWAY TX

Functions / Use	 This function is used to enable the Direct I 	Fax function.
	NOTE Available only if the Internet Fax & Network 	work Scan Kit SU-502 is installed.
Setting/Procedure	 The default setting is "DISABLE." 	
	"DISABLE"	ENABLE

10.2.16 E-MAIL SETTING 1

- Available only if the Internet Fax & Network Scan Kit SU-502 is installed.
- Depending on the network environment in which the machine is located, there may be some restrictions on the network functions that the machine can use. Make the network settings to suit the functions and environment required for customer's location. The network settings can be specified from the control panel or using the administrator mode of Page Scope Web Connection.

A. SENDER NAME

Functions / Use	This function is used to specify the sender's name.
Setting/Procedure	Up to 20 characters can be entered for the sender name.

B. E-MAIL ADDRESS

Functions / Use	 This function is used to specify the e-mail address of the sender.
	NOTE • Please consult customer's network administrator for information about the e-mail address to use.
Setting/Procedure	 Up to 64 characters can be entered for the sender address. If customer does not receive e-mail on the copier, enter the e-mail address of the customer's administrator.

C. SMTP SERVER

Functions / Use	This function is used to enter the IP address or host name of an SMTP server.
	NOTE • Please consult customer's network administrator for information about the IP address to use.
Setting/Procedure	 Up to 64 characters can be entered for the host name. The DNS settings must have been specified before specifying the host name for the SMTP server.

D. SMTP PORT NO.

Functions / Use	This function is used to enter the port number (1 to 65535) for the SMTP server.
	NOTE Please consult customer's network administrator for information about the port number to use.
Setting/Procedure	The port number can be set between 1 and 65535.Normally, port number 25 is used.

E. SMTP TIMEOUT

Functions / Use	 This function is used to specify the length of time (in seconds) before the con- nection to the SMTP server times out. (30 to 300 seconds)
Setting/Procedure	The default setting is "60" second.
	"60" sec (30 to 300)

F. TEXT INSERT

Functions / Use	 This function is used to specify whether or not to insert text explaining that an image has been attached to an e-mail message, when sending scan data as an E-mail attachment.
Setting/Procedure	The default setting is "OFF."
	 ON : If ON is selected, the following text is inserted in the e-mail message. "OFF" : If OFF is selected, a blank e-mail message will be sent.
	NOTE Image data (TIFF format) has been attached to the E-mail. We recommend you use a program like "Imaging for Windows" to view the file.

G. DEFAULT SUBJECT

Functions / Use	 This function is used to specify the default subject line, when sending scan data as an e-mail attachment.
Setting/Procedure	 Up to 20 characters can be entered for the default subject.

10.2.17 E-MAIL SETTING 2

- Available only if the Internet Fax & Network Scan Kit SU-502 is installed.
- Depending on the network environment in which the machine is located, there may be some restrictions on the network functions that the machine can use. Make the network settings to suit the functions and environment required for customer's location. The network settings can be specified from the control panel or using the administrator mode of Page Scope Web Connection.

A. POP3 SERVER

Functions / Use	This function is used to enter the IP address or host name of an POP3 server.
	NOTE Please consult customer's network administrator for information about the IP address to use.
Setting/Procedure	 Up to 64 characters can be entered for the host name. The DNS settings must have been specified before specifying the host name for the POP3 server.

B. POP3 PORT NO.

Functions / Use	This function is used to enter the port number (1 to 65535) for the POP3 server.					
	NOTE Please consult customer's network administrator for information about the port number to use. 					
Setting/Procedure	The port number can be set between 1 and 65535.Normally, port number 110 is used.					

C. POP3 TIMEOUT

Functions / Use	This function is used to specify the length of time (in seconds) before the con- nection to the POP3 server times out. (30 to 300 seconds)						
Setting/Procedure	The default setting is "60" second.						
	"60" sec (30 to 300)						

D. POP3 ACCOUNT

Functions / Use	 This function is used to enter the account name used to log on to the POP3 server.
	NOTE • Please consult customer's network administrator for information about the account name to use.
Setting/Procedure	 Up to 64 characters can be entered for the account name.

E. POP3 PASSWORD

Functions / Use	 This function is used to enter the password associated with the account name used to log in to the POP3 server.
	NOTE • Please consult customer's network administrator for information about the password to use.
Setting/Procedure	 Up to 32 characters can be entered for the password.

F. AUTO RECEPTION

Functions / Use	This function is used to specify the time interval (in minutes) for checking E-mail, when Auto Reception is enabled. (0 minutes: OFF, 1 to 60 minutes)							
Setting/Procedure	The default setting is "OFF."							
	ON "OFF"							
	 If ON is selected, the screen used to spec appears. The time interval for automatical between 1 minute and 60 minutes. The de If OFF is selected, the E-MAIL SETTING 	ON is selected, the screen used to specify the time interval for checking e-ma ppears. The time interval for automatically checking for new e-mail can be set etween 1 minute and 60 minutes. The default setting is "15 minutes." OFF is selected, the E-MAIL SETTING 2 screen appears again.						

G. REPLAY ADDRESS

Functions / Use	 This function is used to enter the e-mail address to be used when sending notifi- cation of an error, if an error occurs while receiving an Internet fax.
Setting/Procedure	 Up to 64 characters can be entered for the reply address. Normally, the reply address is set to the e-mail address of the customer's administrator.

H. HEADER PRINT

Functions / Use	This function is used to specify whether or not to print header information when printing E-mails that have been received.						
Setting/Procedure	The default setting is "OFF." ON : Printing cover page & attachment file. "OFF" : Only printing attachment file.						

10.2.18 SCAN SETTING

- Available only if the Internet Fax & Network Scan Kit SU-502 is installed.
- The scan settings can be specified from the control panel or using the administrator mode of Page Scope Web Connection.

A. RESOLUTION

Functions / Use	 The default settings for resolution used by the Scan to E-mail and Scan to Server (FTP) functions can be specified. 						
Setting/Procedure	 The default setting is "300 × 300" dpi. 						
	150 × 150 dpi : Normal resolution for text documents containing stan- dard sized text.						
	"300 × 300" dpi : Higher resolution for text documents containing small characters or fine print, such as a newspaper article.						
	600 × 600 dpi : Highest resolution for scanning photographs and other images						

B. IMAGE FORMAT

Functions / Use	 The default settings for data format used by the Scan to E-mail and Scan to Server (FTP) functions can be specified. 							
Setting/Procedure	 The default setting is "TIFF." 	The default setting is "TIFF."						
	"TIFF"	PDF						
	 TIFF : Tagged Image File Format, clearer than the image data PDF : Portable Document Format becomes small compared w 	Tagged Image File Format, The image is not compressed. Images are clearer than the image data of the PDF form. Portable Document Format, The image is compressed. The data size becomes small compared with the image data of the TIFF form.						

C. CODING METHOD

Functions / Use	 The default settings for coding method, used by the Scan to E-mail and Scan to Server (FTP) functions can be specified. 					
Setting/Procedure	 The default setting is "MH." "MH" : Modified Huffmann. MR : Modified Read, 50% faster than MH. MMR : Modified Modified Read, 50% faster than MR. 					

11. Adjustment item list

Replacement Part/Service Job Adjustment/Setting Items		No	Replace Image Transfer Roller	Replace Fusing Unity	Replace Drum Cartridge	Replace Paper Take-up parts	Replace Scanner Assy.	Removal Original Glass	Replace PWB-P	Replace PH Unit	Execute Memory Clear	Execute F/W update	Replace ADF Paper Separator Pad	
	Service	Re-entry of Service Choice set- tings	1			_	_	_	_	_	_	(1)	_	
	Choice	Edge Erase (Leading, Trailing, Vertical)	2								(1)			
		PRN Main Regist	3								(2)			
		PRN Sub Regist	4								(3)			
		CCD Main Zoom	5					(1)						
		CCD Sub Zoom	6					(2)						
Ð	Adjust	CCD Main Regist	7					(3)	(1)					
Mod		CCD Sub Regist	8					(4)	(2)					
ee ee		ADF Sub Zoom	9					(5)	(3)					
ervi		ADF Main Regist	10					(6)	(4)					
S		ADF Sub Regist	11					(7)	(5)					
	Counter	PM Counter check (return to 0)	12	(2)	(2)									
	Countor	I/C Counter check (return to 0)	13			(2)								
	Display	F/W Version Check	14										0	
	Function	Paper Feed Test	15				0							
		ADF Feed Test	16											0
	Soft Switch	Re-entry of Soft Switch	17									(4)		
	Clear Data	PM Counter	18	(1)	(1)									
		I/C Counter	19			(1)								
Re-entry of Utility settings		20									(3)			
Re-entry of Security settings		21									(2)			
F/W upgrading		22	<u> </u>						(2)					
Remounting of EEPROM (PWB-P)			23							(1)				

• This table shows the adjustment items that are required when a part of the machine has been replaced. Priority order, if applicable, during the adjustment procedures is indicated by the corresponding number in the parentheses.

12. Service Mode (bizhub 160/bizhub 161)

• This mode is used to check, specify, adjust and register service functions.

12.1 Service Mode function tree





12.2 Service Mode setting procedure

NOTE

 Be sure to keep the access procedure for the Service mode from any unauthorized persons not involved with service operations.

12.2.1 Procedure

- 1. Press the Utility key.
- 2. Press the following keys in this order to enter the Service Mode. Stop $\rightarrow 0 \rightarrow 0 \rightarrow S$ top $\rightarrow 0 \rightarrow 1$
- 3. The first Service mode screen appears.

12.2.2 Exiting procedure

• Press the Panel Reset key.

12.2.3 Changing the settings for Service Mode functions

- 1. Press the \blacktriangle / \checkmark key to select the desired function.
- 2. Press the ▲/ ▼ key, < / > key or the 10-Key Pad to select the desired setting.
- 3. Press the Yes key to apply the setting.
- 4. To return to the previous screen, press the No/ C key.

NOTE

• In order for the settings for the Service mode functions to be changed, the machine must be turned off, then on again.



12.3 Service Mode functions

12.3.1 SERVICE'S CHOICE

• Various machine service functions can be specified.

A. SHIPMENT DESTINATION

Functions / Use	To switch the fixed zoom ratios and paper sizes according to the selected mar- keting area.					
Setting/Procedure	• The default setting is either "METRIC" or "INCH."					
	METRIC	INCH				

B. LEADING EDGE ERASE

Functions	• To change the laser emission timing to adjust the width of the image area that is erased at the leading edge.		
Use	When the PH unit has been replaced When the user requests a smaller margin		
Adjustment Speci- fication	A •Specify the amount erased at the leading edge (width of A) of the paper. Specifications 0 ± 2.0 mm Setting Range 0 to 5 (1 increment = 1 mm) The default setting is "4" mm		
Adjustment Instruction	To reduce the margin Decrease the setting. To increase the margin Increase the setting.		
Adjustment Procedure	 Enter Service's Choice in the Service mode. Select "LEADING EDGE ERASE." Specify the setting. Specify settings for the "TRAILING EDGE ERASE" and the "VERTICAL EDGE ERASE" functions in the same way. 		

C. TRAILING EDGE ERASE

Functions	• To change the laser emission timing to adjust the width of the image area that is erased at the trailing edge.		
Use	 When the PH unit has been replaced When the user requests a smaller margin 		
Adjustment Speci- fication	 Specify the amount erased at the trailing edge (width of B) of the paper. Specifications 0 ± 2.0 mm Setting Range 0 to 5 (1 increment = 1 mm) The default setting is "4" mm 		
Adjustment Instruction	To reduce the margin Decrease the setting. To increase the margin Increase the setting.		
Adjustment Procedure	 Enter Service's Choice in the Service mode. Select "TRAILING EDGE ERASE". Specify the setting. Specify settings for the "LEADING EDGE ERASE" and the "VERTICAL EDGE ERASE" functions in the same way. 		

D. VERTICAL EDGE ERASE

Functions	• To change the laser emission timing to adjust the width of the image area that is erased on both sides (main scan direction).		
Use	 When the PH unit has been replaced When the user requests a smaller margin 		
Adjustment Speci- fication	 Specify the amount erased at the both sides (width of C) of the paper. Specifications 0 ± 2.0 mm Setting Range 0 to 5 (1 increment = 1 mm) The default setting is "4" mm 		
Adjustment Instruction	To reduce the margin Decrease the setting. To increase the margin Increase the setting.		
Adjustment Procedure	 Enter Service's Choice in the Service mode. Select "VERTICAL EDGE ERASE". Specify the setting. Specify settings for the "LEADING EDGE ERASE" and the "TRAILING EDGE ERASE" functions in the same way. 		

E. FLS PAPER SIZE

Functions	To specify the paper size for foolscap.			
Use	 When the FLS paper size has been changed Upon setup 			
Setting/Procedure	The default setting is "330*210."			
	330*203 "330*210" 330*216 337*206			

F. GDI TIMEOUT

Functions / Use	 To specify the time for GDI time out. bizhub 160 only. 				
Setting/Procedure	The default setting is "6" (60 seconds).				
	0 (5sec) 4 (40sec)	1 (10sec) 5 (50sec)	2 (20sec) "6" (60sec)	3 (30sec)	

G. TONER EMPTY STOP

Functions / Use	 To select if copy operations are stopped when the toner becomes empty. 		
Setting/Procedure	The default setting is "ON."		
	"ON"	OFF	
	If "OFF" is selected, operations are	not stopped when the toner becomes empty.	

H. PRE-ROTATION

Functions / Use	• To select if the pre-rotation operation for the Fusing Roller is performed when the Start key is pressed.		
Setting/Procedure	The default setting is "ON."		
	"ON" OF	F	
	 If "OFF" is selected, the length of time until the shorter. 	first copy can be printed is	

I. FUSER TEMP.Ad

Functions	• To specify the fusing temperature when using plain paper (more than 186 mm).		
Use	When a fusing failure has occurred		
Setting/Procedure	The default setting is "0."		
	"0" (Standard) 1 (Higher)		

12.3.2 ADJUST

Precautions for making test copies with functions from the "ADJUST" menu

- The test pattern should be positioned vertically.
- Use paper loaded into Tray1 to make the test copy.



A. Printing a Test Pattern

NOTE

Print a test pattern when making the following adjustments.

- · Printer's main scanning & sub-scanning registration adjustments
- · Scanner's main scanning & sub-scanning registration adjustments
- Scanner's zoom ratio adjustment
- 1. Enter the Service mode.
- 2. Press the Density Select key to select the function.
- 3. Select "PRINT TEST PATTERN" → "TEST PATTERN 1."
- 4. Press the Start key to begin printing the test pattern.

bizhub 160/160f bizhub 161/161f

B. PRN MAIN REGIST

Functions	 To vary and adjust the print start position in the main scanning direction. 		
Use	 If the image on the copy deviates in the main scan direction When the PH unit has been replaced 		
Adjustment Specification	 Adjust the amount that widths A and B in the printed test pattern are shifted so that the following specification is met. Specifications 0 ± 2.0 mm Setting Range 60 to 140 (1 increment = 0.1 mm) The default setting is "100" 		
Adjustment Instruction	If the width of A is less than the width of B Increase the setting. If the width of B is less than the width of A Decrease the setting.		
Adjustment Procedure	 Print the test pattern. Check the amount that widths A and B in the test pattern are shifted. If the shift is out of specification, adjust it according to the following procedure. Enter the "ADJUST" menu in the Service mode. Change the setting. If the shift cannot be adjusted to within the specification with a single adjustment, perform the adjustment again to change the setting. Press the Yes key to apply the setting. NOTE If the Stop key is pressed, instead of the Yes key, the main screen is displayed and the setting returns to that before it was changed. 		
	6. Print a test pattern again and check it.		

C. PRN SUB REGIST

Functions	 To vary and adjust the print start position in the sub-scanning direction. 		
Use	 After the PRN MAIN REGIST adjustment has been performed If the image on the copy deviates in the sub scan direction When the PH unit has been replaced 		
Adjustment Specification	Adjust the width of C in the printed test pattern so that the following specification is met. Specifications 20 ± 2.5 mm Setting Range 87 to 113 (1 increment = 0.46 mm) The default setting is "100"		
Adjustment Instruction	If the width of C in the test pattern is longer than the specified width Increase the setting. If the width of C in the test pattern is shorter than the specified width Decrease the setting.		
Adjustment Procedure	 Print the test pattern. Check that the width of C in the test pattern meets the specification. If the width of C is out of specification, adjust it according to the following procedure. Enter the "ADJUST" menu in the Service mode. Change the setting. If the shift cannot be adjusted to within the specification with a single adjustment, perform the adjustment again to change the setting. Press the Yes key to apply the setting. NOTE If the Stop key is pressed, instead of the Yes key, the main screen is displayed and the setting returns to that before it was changed. 		
	6. Print a test pattern again and check it.		

bizhub 160/160f bizhub 161/161f

D. CCD MAIN ZOOM

Functions	• To adjust for variations in the accuracy of IR parts and their mounting accuracy by varying the scanning zoom ratio in the main scanning direction.		
Use	 After the PRN MAIN REGIST and PRN SUB REGIST adjustments have been performed When the Scanner Assy. has been replaced 		
Adjustment Specification	 After finishing the PRN MAIN REGIST and PRN SUB REGIST adjustments. Place the printed test pattern on the Original Glass, and make a copy of it. Adjust the width of D in the copy of the test pattern so that the following specification is met. 		
	4007D052AA Specifications 100 ± 0.5 % (Zoom Ratio = Full Size :100%)		
	Setting Range 95 to 105 (1 increment = 0.4 %) The default setting is "100"		
Adjustment Instruction	If the width of D in the test pattern is longer than the specified width. Decrease the setting. If the width of D in the test pattern is shorter than the specified width. Increase the setting.		
Adjustment Procedure	 Print the test pattern. Enter the "ADJUST" menu in the Service mode. Place the test pattern on the Original Glass and make a test copy. 		
	NOTE The test pattern should be positioned vertically. Use A4 or Letter paper loaded into Tray1 to make the test copy. 		
	 Check that the width of D in the copy of the test pattern meets the specification. Calculation: (1 – Width of D in the document ÷ Width of D in the copy) × 100 If the width of D is out of specification, adjust it according to the following procedure. Change the setting. If the shift cannot be adjusted to within the specification with a single adjustment, perform the adjustment again to change the setting. Press the Yes key to apply the setting. 		
	 NOTE If the Stop key is pressed, instead of the Yes key, the main screen is displayed and the setting returns to that before it was changed. Place the test pattern on the Original Glass again, make another test copy, and check it. 		

E. CCD SUB ZOOM

Functions	 To adjust for variations in the accuracy of IR parts and their mounting accuracy by varying the scanning zoom ratio in the sub-scanning direction. 		
Use	 After the PRN MAIN REGIST and PRN SUB REGIST adjustments have been performed When the Scanner Assy. has been replaced 		
Adjustment Specification	 After finishing the PRN MAIN REGIST and PRN SUB REGIST adjustments. Place the printed test pattern on the Original Glass, and make a copy of it. Adjust the width of E in the copy of the test pattern so that the following specification is met. 4007D053AA Specifications 200 ± 0.5% (Zoom Batio = Full Size:100 %) 		
	Setting Range 95 to 105 (1 increment = 0.4 %) The default setting is "100"		
Adjustment Instruction	If the width of E in the test pattern is longer than the specified width. Decrease the setting. If the width of E in the test pattern is shorter than the specified width. Increase the setting.		
Adjustment Procedure	 Print the test pattern. Enter the "ADJUST" menu in the Service mode. Place the test pattern on the Original Glass and make a test copy. NOTE The test pattern should be positioned vertically. Use A4 or Letter paper loaded into Trav1 to make the test copy. 		
	 Check that the width of E in the copy of the test pattern meets the specification. Calculation: (1 – Width of E in the document ÷ Width of E in the copy) × 100 If the width of E is out of specification, adjust it according to the following procedure. Change the setting. If the shift cannot be adjusted to within the specification with a single adjustment, perform the adjustment again to change the setting. Press the Yes key to apply the setting. 		
	 NOTE If the Stop key is pressed, instead of the Yes key, the main screen is displayed and the setting returns to that before it was changed. Place the test pattern on the Original Glass again, make another test copy, and check it. 		
F. CCD MAIN REGIST

Functions	 To adjust for variations in the accuracy of IR parts and their mounting accuracy by varying the scanning start position in the main scanning direction. 	
Use	 After the PRN MAIN REGIST and PRN SUB REGIST and CCD MAIN ZOOM adjustments have been performed When the Upper Cover Assy. (Original Glass) has been replaced When the Scanner Assy. has been replaced 	
Adjustment Specification	After finishing the PRN MAIN REGIST & PRN SUB REGIST and CCD MAIN ZOOM adjust- ments. Place the printed test pattern on the Original Glass, and make a copy of it. Adjust the amount that widths A and B in the printed test pattern are shifted so that the fol- lowing specifications 0 ± 2.0 mm	
	Setting Range 90 to 110 (1 increment = 0.5 mm) The default setting is "100"	
Adjustment Instruction	If the width of A is less than the width of B Increase the setting. If the width of B is less than the width of A Decrease the setting.	
Adjustment Procedure	 Print the test pattern. Enter the "ADJUST" menu in the Service mode. Place the test pattern on the Original Glass and make a test copy. NOTE The test pattern should be positioned vertically. Use A4 or Letter paper loaded into Tray1 to make the test copy. Check the amount that widths A and B in the copy of the test pattern are shifted. If the shift is out of specification, adjust it according to the following procedure. Change the setting. If the shift cannot be adjusted to within the specification with a single adjustment, pe form the adjustment again to change the setting. 	
	 6. Press the Yes key to apply the setting. NOTE If the Stop key is pressed, instead of the Yes key, the main screen is displayed and the setting returns to that before it was changed. Place the test pattern on the Original Glass again, make another test copy, and check it. 	

G. CCD SUB REGIST

 After the PRN MAIN REGIST and PRN SUB REGIST and CCD SUB ZOOM adjustments have been performed When the Upper Cover Assy. (Original Glass) has been replaced When the Scanner Assy. has been replaced
 After finishing the PRN MAIN REGIST & PRN SUB REGIST and CCD SUB ZOOM adjustments. Place the printed test pattern on the Original Glass, and make a copy of it. Adjust the width of C in the printed test pattern so that the following specification is met. Specifications 20 ± 3.0 mm Setting Range 90 to 110 (1 increment = 0.5 mm) The default setting is "100"
If the width of C in the test pattern is longer than the specified width Increase the setting. If the width of C in the test pattern is shorter than the specified width Decrease the setting.
 Print the test pattern. Enter the "ADJUST" menu in the Service mode. Place the test pattern on the Original Glass and make a test copy. NOTE The test pattern should be positioned vertically. Use A4 or Letter paper loaded into Tray1 to make the test copy. Check that the width of C in copy of the test pattern meets the specification. If the width of C is out of specification, adjust it according to the following procedure. Change the setting.
 If the shift cannot be adjusted to within the specification with a single adjustment, perform the adjustment again to change the setting. 6. Press the Yes key to apply the setting. NOTE If the Stop key is pressed, instead of the Yes key, the main screen is displayed and the setting returns to that before it was changed. Place the test nattern on the Original Glass again make another test conv and

bizhub 160/160f bizhub 161/161f

H. ADF SUB ZOOM

For details, see DF-501 Service Manual.

Functions	 To adjust for variations in the accuracy of all parts and their mounting accuracy by varying the scanning zoom ratio in the sub-scanning direction when using the Auto- matic Document Feeder.
Use	 After the PRN MAIN REGIST and PRN SUB REGIST and CCD SUB ZOOM adjustments have been performed When the Upper Cover Assy. (Original Glass) has been replaced When the ADF has been replaced

I. ADF MAIN REGIST

For details, see DF-501 Service Manual.

Functions	 To adjust for variations in the accuracy of all parts and their mounting accuracy by varying the scanning start position in the main scanning direction when using the Automatic Document Feeder.
Use	 After the PRN MAIN REGIST and PRN SUB REGIST and CCD MAIN ZOOM adjustments have been performed After the ADF SUB ZOOM adjustments have been performed When the Upper Cover Assy. (Original Glass) has been replaced When the ADF has been replaced

J. ADF SUB REGIST

For details, see DF-501 Service Manual.

Functions	 To adjust for variations in the accuracy of all parts and their mounting accuracy by varying the scanning start position in the sub-scanning direction when using the Auto- matic Document Feeder.
Use	 After the PRN MAIN REGIST and PRN SUB REGIST and CCD SUB ZOOM adjustments have been performed After the ADF SUB ZOOM adjustments have been performed When the Upper Cover Assy. (Original Glass) has been replaced When the ADF has been replaced

12.3.3 COUNTER

• The counter values can be displayed.

NOTE

The following counters continue counting even while operations are performed in Service Mode.

- PM COUNTER
- IC COUNTER
- PRINTER JAM COUNTER
- ADF JAM COUNTER
- TROUBLE COUNTER

A. TOTAL COUNTER

Functions / Use	To display the total number of pages used.
Setting/Procedure	 COPY: Number of copies printed PRINT: Number of computer printouts printed
	 Test prints made in Service mode to check the operation are not counted.

B. PM COUNTER

Functions / Use	 To display the number of times that PM parts are used.
Setting/Procedure	To clear the counter data, use the functions on the "CLEAR DATA" menu of Service mode.

C. I/C COUNTER

Functions / Use	To display the total number of times that the Drum Cartridge has been used.
Setting/Procedure	To clear the counter data, use the functions on the "CLEAR DATA" menu of Service mode.

D. APPLICATION COUNTER

Functions / Use	 To display the number of pages used with each application.
Setting/Procedure	COPY PRINT : Number of copies printed FAX RX PRINT : (Not Used)
	REPORT PRINT : (Not Used) PC PRINT : Number of computer printouts printed FAX TX PAGE : (Not Used) MAIL TX PAGE : (Not Used) • To clear the counter data, use the functions on the "CLEAR DATA" menu of Service mode.

E. SCAN COUNTER

Functions / Use	 To display the number of scans made.
Setting/Procedure	MONOCHROME : Number of monochrome scans COLOR : Number of color scans • Scans made while making copies are not counted. • To clear the counter data, use the functions on the "CLEAR DATA" menu of Service mode.

F. PRINTER JAM COUNTER

Functions / Use	 To display the number of misfeeds that occurred while printing.
Setting/Procedure	 To clear the counter data, use the functions on the "CLEAR DATA" menu of Service mode.

G. ADF JAM COUNTER

Functions / Use	 To display the number of misfeeds that occurred while using the Automatic Document Feeder. When DF-501 (option) is set, this counter is displayed.
Setting/Procedure	• To clear the counter data, use the functions on the "CLEAR DATA" menu of Service mode.

H. TROUBLE COUNTER

Functions / Use	 To display the number of times each error was detected.
Setting/Procedure	C0045 :Fuser fan error
	C0210 :Transfer voltage error
	C0500 :Fuser Warm up error
	C0510 :Fuser temperature low
	C0520 :Fuser overheat
	C0650 :Home sensor error / Scanner motor error
	C1200 :ASIC memory abnormal
	C1300 :Polygon mirror motor error
	C133B :Communication with option error
	C133C :Modem error
	C133D :ROM checksum error
	C13F0 :Laser error
	C1468 :Parameter Chip error
	C14A3 :IR lamp malfunction
	 To clear the counter data, use the functions on the "CLEAR DATA" menu of Service mode.

12.3.4 DISPLAY

• Various information can be displayed.

Function	Purpose	Setting Details/Preca	autions
MAIN F/W VER.	To display the version of the Copier firmware.		
ENGINE F/W VER.	To display the version of the engine firmware.		
PCL F/W VER.	To display the version of the PCL firmwar	e.	
NIC F/W VER.	To display the version of the NIC firmware.		
MAIN RAM SIZE	To display the size of the main memory.		
PCL RAM SIZE	To display the size of the PCL memory.		
SERIAL NO.	To display the serial number of the main unit. • Once the serial number is specified, "SERIALNO." on the "ADJUST" menu cannot be set again.		
CUSTOMER ID	To display the customer ID for the main unit.		
TC TYPE	To specify the type of Toner Cartridge that should be installed in the main unit.	 The default setting differing on the marketing and 	ers depend- rea.
	Once the type of Toner Cartridge is	Toner Cartridge Type	Setting
	specified, "TC TYPE" on the	(No Toner Cartridge)	0
	ADJOST menu cannot be set again.	(Not Used)	1
	< Types of Toner Cartridges>	Α	2
	Toner Cartridge 906 A	В	3
	• Others:	(Not Used)	4
Toner Cartri • North/ South Toner Cartri	North/ South America:	С	5
	Toner Cartridge 908 C	(Not Used)	6
		(Not Used)	7
		(Not Used)	8
		(Not Used)	9
		(Not Used)	10
		(Not Used)	11

12.3.5 FUNCTION

• The service functions (paper feed test and image printing) can be checked and adjusted.

A. PAPER FEED TEST

Functions	• To check the paper feeding in the paper take-up/transport sections without print- ing on the paper.
Use	When a paper misfeed occurs
Setting/Procedure	 Select the paper tray. Press the Start key to begin testing paper feeding. Press the Stop key to stop testing paper feeding.

B. PRINT TEST PATTERN 1

Functions	 To print the test pattern for adjusting the image. 		
	4980S530AA		
Use	If there is tilt or when registration or zoom ratio adjustments are performed		
Setting/Procedure	 Select the paper tray. Select the test pattern type. Press the Start key to print the test pattern. 		

C. PRINT TEST PATTERN 2

Functions	To print the test pattern for halftones and gradations.		
	4980S531AA		
Use	 When checking density and pitch irregularities When checking reproducibility of gradations 		
Setting/Procedure	 Select the paper tray. Select the test pattern type. Press the Start key to print the test pattern. 		

D. ADF FEED TEST

Functions	 To check the paper feeding in the paper take-up/transport sections in the Auto- matic Document Feeder. 	
Use	When a document misfeed occurs	
Setting/Procedure	1. Load paper into the Automatic Document Feeder.	
	2. Press the Start key to begin testing paper feeding.	
	3. Press the Stop key to stop testing paper feeding.	

E. COPY ADF GLASS AREA

Functions	• To check for dirt in the scanning section of the Automatic Document Feeder.
Use	If spots appear in the copies
Setting/Procedure	 Load A4 or Letter paper into Tray1. Press the Start key to start the "COPY ADF GLASS AREA" function. Two copy samples are fed out. Check that no spots appear in the copy samples. Press the Stop key to stop the "COPY ADF GLASS AREA" function.

F. CCD MOVE TO HOME

Functions	To move the scanner to its home position in order to secure the scanner.
Use	When transporting the machine
Setting/Procedure	 NOTE When transporting the machine, be sure to move the scanner to its home position and secure it with the stopper at the bottom left of the IR.

G. SCAN TEST

Functions	To check the lighting of the Exposure Lamp and the movement of the scanner.
Use	If the scanner malfunctions
Setting/Procedure	 Press the Start key to begin the scanner test. Press the Stop key to stop the scanner test.

12.3.6 FIXED ZOOM CHANGE

Functions/Use	The fixed zoom ratios can be changed.
Setting/Procedure	1. Select the fixed zoom ratio that you wish to change.
	Use the 10-Key Pad to type in the desired fixed zoom ratio.

A. Default fixed zoom ratios and setting ranges according to marketing area

Metric

Setting Name	Initial fixed zoom ratio	Setting Range
Reduction 2	70%	51% to 70%
Reduction 1	81%	71% to 99%
Expansion 1	115%	101% to 140%
Expansion 2	141%	141% to 199%

Inch

Setting Name	Initial fixed zoom ratio	Setting Range
Reduction 2	64%	51% to 64%
Reduction 1	78%	65% to 99%
Expansion 1	129%	101% to 153%
Expansion 2	154%	154% to 199%

12.3.7 FACTORY TEST

• Operation tests can be performed during manufacturing.

	Functions/Use
PANEL BUZZER TEST	To check the operation of the display and all indicators and buttons.
RAM TEST	To test reading and writing of the memory.

12.3.8 CLEAR DATA

• Each type of data can be cleared.

A. MEMORY CLEAR

Functions/Use	• To clear the settings for the functions listed at the right and return the functions to their default settings.
Setting/Procedure	 All functions of the Utility mode All functions in the "Services Choice" menu of the Service mode All functions in the "ADJUST" menu of the Service mode (except "SERIAL NO.", "CUSTOMER ID" and "TC TYPE") All "FIXED ZOOM" settings in the Service mode All Security mode settings in the Service mode NOTE After the "MEMORY CLEAR" function is performed, turn the machine off, then on again.

B. TOTAL CLEAR

Functions/Use	The following counter are cleared (initialization).
Setting/Procedure	 PM counter I/C counter Application counter Scan counter Printer jam counter ADF jam counter Trouble counter NOTE After the "TOTAL CLEAR" function is performed, turn the machine off, then on again. The clearance of "TOTAL COUNTER" can not be performed.

C. Other Counter Clear

Functions	Use
PM COUNTER	To clear the PM COUNTER value.
I/C COUNTER	To clear the I/C COUNTER value.
APPLICATION COUNTER	To clear the APPLICATION COUNTER value.
SCAN COUNTER	To clear the SCAN COUNTER value.
PRINTER JAM COUNTER	To clear the PRINTER JAM COUNTER value.
ADF JAM COUNTER	To clear the ADF JAM COUNTER value.
TROUBLE COUNTER	To clear the TROUBLE COUNTER value.

13. Service Mode (bizhub 160f/bizhub 161f)

• This mode is used to check, specify, adjust and register service functions.

13.1 Service Mode function tree



*: bizhub 160f only **: bizhub 161f only



*: bizhub 160f only **: bizhub 161f only bizhub 160/160f bizhub 161/161f



13.2 Service Mode setting procedure

NOTE

• Be sure to keep the access procedure for the Service mode from any unauthorized persons not involved with service operations.

13.2.1 Procedure

- 1. Press the Utility key.
- 2. Press the following keys in this order to enter the Service mode. Stop $\rightarrow 0 \rightarrow 0 \rightarrow S$ top $\rightarrow 0 \rightarrow 1$
- 3. The first Service mode screen appears.

13.2.2 Exiting procedure

• Press the Panel Reset key.

13.2.3 Changing the settings for Service Mode functions

- 1. Press the \blacktriangle / \checkmark key to select the desired function.
- 2. Press the ▲/ ▼ key, < / > key or the 10-Key Pad to select the desired setting.
- 3. Press the Yes key to apply the setting.
- 4. To return to the previous screen, press the No/C key.

NOTE

• In order for the settings for the Service Mode functions to be changed, the machine must be turned off, then on again.



bizhub 160/160f bizhub 161/161f

13.3 Service Mode functions

13.3.1 SERVICE'S CHOICE

A. MARKETTING AREA

- Set the marketing area.
- If you change the marketing area, the soft switch (1-64) will change automatically.

NOTE

- If you change the marketing area, the following items are cleared (initialization). Before change the marketing area, be sure to record the setting values that are to be change the marketing area.
- After change the marketing area has been executed, make necessary entries of data again based on the setting values recorded.

Function		Default Setting
Utility mode/ Machine setting/ Buzzer volume	r≊ 76	Low
Utility mode/ Admin. management/ Remote monitor	r≊ 78	Limited

• According to the following table, the machines that are installed in the West Europe Area select "West Europe" in the "Marketing Area" function. Do not select each country.

Marketing area	Country
Standard	Baltic, Bahrain, Indonesia, Israel, Kuwait, Oman, Philippine, Poland, Qatar, Romania, Russia, Saudiarabia, Slovakia, Slovenia, Thailand, U.A.E., Ukraine
U.S.A	U.S.A., Canada.
West Europe	Austria, Belgium, Czech, Denmark, Finland, France, Greece, Hungary, Ireland, Italy, Netherlands, Norway, Portugal, Spain, Sweden, Switzerland, United Kingdom, West Europe.
Asia	Hong Kong, Malaysia
Setting in accordance with each country	Australia, China, Germany, Japan, Korea, New Zealand, South Africa, Taiwan.
Singapore	Singapore (remark: with DTS default setting).

(1) MARKETING AREA Setting Procedure

• Use the one touch key or using [▲ / ▼] key to select any number from 1 to 15.

One Touch	Marketing area	One Touch	Marketing area
1	STANDARD	9	NETHERLANDS
2	U.S.A.	10	FINLAND
3	TAIWAN	11	DENMARK
4	SPAIN	12	SWITZERLAND
5	ITALY	13	IRELAND
6	BELGIUM	14	PORTUGAL
7	NORWAY	15	SOUTH AFRICA
8	SWEDEN	-	-

• Using [▲ / ▼] key to select any number from 16 to 48.

No.	Marketing area	No.	Marketing area
16	GREECE	33	POLAND
17	ISRAEL	34	ROMANIA
18	AUSTRIA	35	RUSSIA
19	GERMANY	36	SINGAPORE
20	FRANCE	37	MALAYSIA
21	UNITED KINGDOM	38	HONG KONG
22	AUSTRALIA	39	PHILIPPINES
23	CHINA	40	THAILAND
24	NEW ZEALAND	41	INDONESIA
25	KOREA	42	OMAN
26	CZECH	43	UAE
27	SLOVAK	44	QATAR
28	HUNGARY	45	BAHRAIN
29	UKRAINE	46	KUWAIT
30	BALTIC	47	SAUDI ARABIA
31	WEST EUROPE	48	JAPAN
32	SLOVENIJA	-	-

B. SHIPMENT DESTINATION

Functions / Use	To switch the fixed zoom reketing area.	atios and paper sizes according to the selected mar-	
Setting/Procedure	The default setting is eithe	er "METRIC" or "INCH."	
	METRIC	INCH	

bizhub 160/160f bizhub 161/161f

C. LEADING EDGE ERASE

Functions	 To change the laser emission timing to adjust the width of the image area that is erased at the leading edge. 	
Use	When the PH unit has been replacedWhen the user requests a smaller margin	
Adjustment Speci- fication	A 	
Adjustment Instruction	To reduce the margin Decrease the setting. To increase the margin Increase the setting.	
Adjustment Procedure	 Enter Service's Choice in the Service mode. Select "LEADING EDGE ERASE." Specify the setting. Specify settings for the "TRAILING EDGE ERASE" and the "VERTICAL EDGE ERASE" functions in the same way. 	

D. TRAILING EDGE ERASE

Functions	 To change the laser emission timing to adjust the width of the image area that is erased at the trailing edge. 	
Use	When the PH unit has been replacedWhen the user requests a smaller margin	
Adjustment Speci- fication	 B Specify the amount erased at the trailing edge (width of B) of the paper. Specifications 0 ± 2.0 mm Setting Range 0 to 5 (1 increment = 1 mm) The default setting is "4" mm 	
Adjustment Instruction	To reduce the margin Decrease the setting. To increase the margin Increase the setting.	
Adjustment Procedure	 Enter Service's Choice in the Service mode. Select "TRAILING EDGE ERASE." Specify the setting. Specify settings for the "LEADING EDGE ERASE" and the "VERTICAL EDGE ERASE" functions in the same way. 	

E. VERTICAL EDGE ERASE

Functions	 To change the laser emission timing to adjust the width of the image area that is erased on both sides (main scan direction). 	
Use	 When the PH unit has been replaced When the user requests a smaller margin 	
Adjustment Speci- fication	 Specify the amount erased at the both sides (width of C) of the paper. Specifications 0 ± 2.0 mm Setting Range 0 to 5 (1 increment = 1 mm) The default setting is "4" mm 	
Adjustment Instruction	To reduce the margin Decrease the setting. To increase the margin Increase the setting.	
Adjustment Procedure	 Enter Service's Choice in the Service mode. Select "VERTICAL EDGE ERASE." Specify the setting. Specify settings for the "LEADING EDGE ERASE" and the "TRAILING EDGE ERASE" functions in the same way. 	

F. FLS PAPER SIZE

Functions	To specify the paper size for foolscap.
Use	When the FLS paper size has been changedUpon setup
Setting/Procedure	 The default setting is "330*210" mm.
	330*203 "330*210" 330*216 337*206 (mm)

G. TX SPEED

Functions/Use	Transmit start speed setting. Choose the mode from among the following.	
Setting/Procedure	The default setting is "V.34."	
	"V.34" : 33600, 31200, 28800, 26400, 24000, 21600, 19200, 16800 V.17 : 14400, 12000, 9600, 7200 V.29 : 9600, 7200 V.27 : 4800, 2400	

H. RX SPEED

Functions/Use	Reception start speed setting. Choose the mode from among the following.
Setting/Procedure	The default setting is "V.34."
	"V.34" : 33600, 31200, 28800, 26400, 24000, 21600, 19200, 16800 V.17 : 14400, 12000, 9600, 7200 V.29 : 9600, 7200 V.27 : 4800, 2400

I. TX LEVEL

Functions/Use	 PSK/FSK signa 	l output level.				
Setting/Procedure	 The default sett 	The default setting is "-9 dBm."				
	-2 dBm	-3 to -8 dBm	"-9 dBm"	-10 to -16 dBm	-17 dBm	

J. RX LEVEL

Functions/Use	Reception ser	sitivity level.			
Setting/Procedure	The default set	tting is "-43 dBm."			
	-36 dBm	-37 to -42 dBm	"-43 dBm"	-44 to -48 dBm	-49 dBm

K. DTMF LEVEL

Functions/Use	Dual tone output	ut level.			
Setting/Procedure	 The default set 	ting is "-9 dBm."			
	-2 dBm	-3 to -8 dBm	"-9 dBm"	-10 to -16 dBm	-17 dBm

L. CNG LEVEL

Functions/Use	Callin	g tone ou	utput level.			
Setting/Procedure	 The d 	 The default setting is "-11 dBm." 				
	-	2 dBm	-3 to -10 dBm	"-11 dBm"	-12 to -16 dBm	-17 dBm

M. CED LEVEL

Functions/Use	Answer tone of	output level.			
Setting/Procedure	The default set	etting is "-11 dBm	"		
	-2 dBm	-3 to -10 dBm	"-11 dBm"	-12 to -16 dBm	-17 dBm

N. ECM MODE

Functions/Use	Select error correction mode.		
Setting/Procedure	The default setting is "ON."		
	"ON" : When an error occurs during communication, re-send the frame where the error occurs.		
	OFF : Any error is ignored during communication.		

O. CODING SCHEME

Functions/Use	 Select compression method in TX/ RX mode. 	
Setting/Procedure	The default setting is "JBIG."	
	 "JBIG": The most complex compression method that generates the smallest code than any of following ones. MMR : A compression method. MR : A compression method. MH : The simplest compression method. 	

Select compression method in TX/ RX mode.

P. Toner Empty Report

Functions/Use	 Select to generate a report to a specific destination when toner empty status occurs in the engine.
Setting/Procedure	The default setting is "OFF."
	"OFF" : Not to generate report. ON : Generate a report to report destination.
	 If "ON" is selected, select generate report and send to remote side when toner runs out. Enter the telephone number for which the report is to be produced. Fax number specifications: An up-to-20-digit number that may consist of "0-9", "*", "#", "pause", and "space." (0-9, #, *, pause, _) The report will generate after 20 minutes, 24 hours, 48 hours, or 72 hours after the event has occurred or until the condition is gone.

• Toner empty report (example)

	SERVICE REPORT
NAME:ABC 123 TEL:1234567 DATE:Dec.01.2003 15:12	
The Fax's following conditions we report to your dealer automatical	re appears, the machine may be can not work correctly, the Fax already send a y. They will contact with you soon.
Toner status	: Empty

bizhub 160/160f bizhub 161/161f

Q. PROTOCOL REPORT

Functions/Use	Print communication report.Choose one from among the following.	
Setting/Procedure	The default setting is "OFF." "OFF" : Disable T.30 communication report. ON : Print T.30 communication report. ON(ERROR) : Print T.30 communication report when an error occurs.	

T.30 communication report (example: V.17 communication)

				PROTOCOL MO	NITOR RE	PORT	7			
NAME: ABC TEL:886 3 4 DATE: APR.	; 733507 10'97 12:20						J			
SESSION	FUNCTION	NO	DEST	INATION STATION	DATE	TIME	PAGE	DURATION	MODE	RESULT
0001	тх	01	ABC 22345678	901234567890	DEC.02	15:00	008	00h00min00s	ECM-12	ОК
ТХ	RX					DA	TA			
NSF			FF 03	3 20 00 00 00 00 00 00 00	00 00 00 00	00 00 00	00 00 0	0 00 00 00 00 0	0	
CSI			FF 03	3 40 00 00 00 00 00 00 00	00 00 00 00	00 00 00	00 00 0	0 00 00 00 00 0	0 00	
DIS			FF 13	FF 13 40 00 00 00 00 00						
	NSS		FF 03	FF 03 00 00 00 00 00 00 00 00 00 00 00						
	DCS		FF 03	FF 03 00 00 00 00 00 00 00 00 00						
	TCF		00 00	00 00 00 00 00 00 00 00 00 00 00						
CFR			FF 13	3 84						
	PIX									
	EOP		FF 13	3 BF 2F 00 00 41						
MCF			FF 13	3 8C						
	DCN		FF 13	3 FB						

R. GDI TIMEOUT

Functions / Use	To specify the tbizhub 160 on	ime for GDI tir ly.	ne out.	
Setting/Procedure	 The default set 	ting is "6" (60	seconds).	
	0 (5sec) 4 (40sec)	1 (10sec) 5 (50sec)	2 (20sec) "6" (60sec)	3 (30sec)

S. TONER EMPTY STOP

Functions / Use	 To select if copy operations are stopped when the toner becomes empty. 		
Setting/Procedure	The default setting is "ON."		
	"ON" OFF		
	• If "OFF" is selected, operations are not stopped when the toner becomes empty.		

T. PRE-ROTATION

Functions / Use	 To select if the pre-rotation operation for the Fusing Roller is performed when the Start key is pressed. 		
Setting/Procedure	The default setting is "ON."		
	"ON"	OFF	
	 If "OFF" is selected, the length of time until the first copy can be printed is shorter. 		

U. FUSER TEMP Ad

Functions	• To specify the fusing temperature when using plain paper (more than 186 mm).		
Use	When a fusing failure has occurred		
Setting/Procedure	 The default setting is "0." 		
	"0" (Standard)	1 (Higher)	

13.3.2 ADJUST

Precautions for making test copies with functions from the "ADJUST" menu

- The test pattern should be positioned vertically.
- Use paper loaded into Tray1 to make the test copy.



A. Printing a Test Pattern

NOTE

Print a test pattern when making the following adjustments.

- Printer's main scanning & sub-scanning registration adjustments
- · Scanner's main scanning & sub-scanning registration adjustments
- Scanner's zoom ratio adjustment
- 1. Enter the Service mode.
- 2. Press the Density Select key to select the function.
- 3. Select "PRINT TEST PATTERN" → "TEST PATTERN 1."
- 4. Press the Start key to begin printing the test pattern.

B. PRN MAIN REGIST

Functions	 To vary and adjust the print start position in the main scanning direction. 	
Use	 If the image on the copy deviates in the main scan direction When the PH unit has been replaced	
Adjustment Specification	Adjust the amount that widths A and B in the printed test pattern are shifted so that the following specification is met. Specifications 0 ± 2.0 mm Setting Range 60 to 140 (1 increment = 0.1 mm) The default setting is "100"	
Adjustment Instruction	If the width of A is less than the width of B Increase the setting. If the width of B is less than the width of A Decrease the setting.	
Adjustment Procedure	 Print the test pattern. Check the amount that widths A and B in the test pattern are shifted. If the shift is out of specification, adjust it according to the following procedure. Enter the "ADJUST" menu in the Service mode. Change the setting. If the shift cannot be adjusted to within the specification with a single adjustment, perform the adjustment again to change the setting. Press the Yes key to apply the setting. NOTE If the Stop key is pressed, instead of the Yes key, the main screen is displayed and the setting returns to that before it was changed. 	
	6. Print a test pattern again and check it.	

C. PRN SUB REGIST

Functions	 To vary and adjust the print start position in the sub-scanning direction. 	
Use	 After the PRN MAIN REGIST adjustment has been performed If the image on the copy deviates in the sub scan direction When the PH unit has been replaced 	
Adjustment Specification	 Adjust the width of C in the printed test pattern so that the following specification is met. Specifications 20 ± 2.5 mm Setting Range 87 to 113 (1 increment = 0.46 mm) The default setting is "100" 	
Adjustment Instruction	If the width of C in the test pattern is longer than the specified width Increase the setting. If the width of C in the test pattern is shorter than the specified width Decrease the setting.	
Adjustment Procedure	 Print the test pattern. Check that the width of C in the test pattern meets the specification. If the width of C is out of specification, adjust it according to the following procedure Enter the "ADJUST" menu in the Service mode. Change the setting. If the shift cannot be adjusted to within the specification with a single adjustment, perform the adjustment again to change the setting. Press the Yes key to apply the setting. NOTE If the Stop key is pressed, instead of the Yes key, the main screen is displayed and the setting returns to that before it was changed. 	
	6. Print a test pattern again and check it.	

D. CCD MAIN ZOOM

Functions	 To adjust for variations in the accuracy of IR parts and their mounting accuracy by varying the scanning zoom ratio in the main scanning direction.
Use	 After the PRN MAIN REGIST and PRN SUB REGIST adjustments have been performed When the Scanner Assy. has been replaced
Adjustment Specification	 After finishing the PRN MAIN REGIST and PRN SUB REGIST adjustments. Place the printed test pattern on the Original Glass, and make a copy of it. Adjust the width of D in the copy of the test pattern so that the following specification is met.
	4007D052AA Specifications 100 ± 0.5 % (Zoom Ratio = Full Size :100%)
	Setting Range 95 to 105 (1 increment = 0.4 %) The default setting is "100"
Adjustment Instruction	If the width of D in the test pattern is longer than the specified width. Decrease the setting. If the width of D in the test pattern is shorter than the specified width. Increase the setting.
Adjustment Procedure	 Print the test pattern. Enter the "ADJUST" menu in the Service mode. Place the test pattern on the Original Glass and make a test copy. NOTE The test pattern should be positioned vertically. Use A4 or Letter paper loaded into Tray1 to make the test copy.
	 Check that the width of D in the copy of the test pattern meets the specification. Calculation: (1 – Width of D in the document ÷ Width of D in the copy) × 100 If the width of D is out of specification, adjust it according to the following procedure. Change the setting. If the shift cannot be adjusted to within the specification with a single adjustment, perform the adjustment again to change the setting. Press the Yes key to apply the setting.
	 NOTE If the Stop key is pressed, instead of the Yes key, the main screen is displayed and the setting returns to that before it was changed. Place the test pattern on the Original Glass again, make another test copy, and check it.

E. CCD SUB ZOOM

Functions	 To adjust for variations in the accurac varying the scanning zoom ratio in th 	cy of IR parts and their mounting accuracy by e sub-scanning direction.		
Use	 After the PRN MAIN REGIST and PF formed When the Scanner Assy. has been re 	RN SUB REGIST adjustments have been per-		
Adjustment Specification		 After finishing the PRN MAIN REGIST and PRN SUB REGIST adjustments. Place the printed test pattern on the Original Glass, and make a copy of it. Adjust the width of E in the copy of the test pattern so that the following specification is met. Specifications 		
		200 ± 0.5 % (Zoom Ratio = Full Size :100%) Setting Range 95 to 105 (1 increment = 0.4 %) The default setting is "100"		
Adjustment Instruction	If the width of E in the test pattern is lon If the width of E in the test pattern is sh	nger than the specified width. Decrease the setting. orter than the specified width. Increase the setting.		
Adjustment Procedure	 Print the test pattern. Enter the "ADJUST" menu in the Se Place the test pattern on the Origina NOTE The test pattern should be positio Use A4 or Letter paper loaded into 	rvice mode. I Glass and make a test copy. ned vertically. o Tray1 to make the test copy.		
	 Check that the width of E in the copy of the test pattern meets the specification. Calculation: (1 – Width of E in the document ÷ Width of E in the copy) × 100 If the width of E is out of specification, adjust it according to the following procedure. Change the setting. If the shift cannot be adjusted to within the specification with a single adjustment, perform the adjustment again to change the setting. Press the Yes key to apply the setting. 			
	 NOTE If the Stop key is pressed, instead and the setting returns to that before Place the test pattern on the Origin check it. 	of the Yes key, the main screen is displayed ore it was changed. nal Glass again, make another test copy, and		

F. CCD MAIN REGIST

Functions	 To adjust for variations in the accuracy of IR parts and their mounting accuracy by varying the scanning start position in the main scanning direction.
Use	 After the PRN MAIN REGIST and PRN SUB REGIST and CCD MAIN ZOOM adjustments have been performed When the Upper Cover Assy. (Original Glass) has been replaced When the Scanner Assy. has been replaced
Adjustment Specification	After finishing the PRN MAIN REGIST & PRN SUB REGIST and CCD MAIN ZOOM adjust- ments. Place the printed test pattern on the Original Glass, and make a copy of it. Adjust the amount that widths A and B in the printed test pattern are shifted so that the fol- lowing specifications 0 ± 2.0 mm Setting Range 90 to 110 (1 increment = 0.5 mm)
Adjustment	The default setting is "100"
Instruction	If the width of B is less than the width of B Increase the setting. If the width of B is less than the width of A Decrease the setting.
Adjustment Procedure	 Print the test pattern. Enter the "ADJUST" menu in the Service mode. Place the test pattern on the Original Glass and make a test copy. NOTE The test pattern should be positioned vertically. Use A4 or Letter paper loaded into Tray1 to make the test copy.
	 Check the amount that widths A and B in the copy of the test pattern are shifted. If the shift is out of specification, adjust it according to the following procedure. Change the setting. If the shift cannot be adjusted to within the specification with a single adjustment, perform the adjustment again to change the setting. Press the Yes key to apply the setting.
	 NOTE If the Stop key is pressed, instead of the Yes key, the main screen is displayed and the setting returns to that before it was changed. Place the test pattern on the Original Glass again, make another test copy, and check it.

bizhub 160/160f bizhub 161/161f

G. CCD SUB REGIST

Functions	• To adjust for variations in the accuracy of IR parts and their mounting accuracy by varying the scanning start position in the sub-scanning direction.
Use	 After the PRN MAIN REGIST and PRN SUB REGIST and CCD SUB ZOOM adjustments have been performed When the Upper Cover Assy. (Original Glass) has been replaced When the Scanner Assy. has been replaced
Adjustment Specification	 After finishing the PRN MAIN REGIST & PRN SUB REGIST and CCD SUB ZOOM adjustments. Place the printed test pattern on the Original Glass, and make a copy of it. Adjust the width of C in the printed test pattern so that the following specification is met. Specifications 20 ± 3.0 mm Setting Range 90 to 110 (1 increment = 0.5 mm) The default setting is "100"
Adjustment Instruction	If the width of C in the test pattern is longer than the specified width Increase the setting. If the width of C in the test pattern is shorter than the specified width Decrease the setting.
Adjustment Procedure	 Print the test pattern. Enter the "ADJUST" menu in the Service mode. Place the test pattern on the Original Glass and make a test copy. NOTE The test pattern should be positioned vertically. Use A4 or Letter paper loaded into Tray1 to make the test copy.
	 Check that the width of C in copy of the test pattern meets the specification. If the width of C is out of specification, adjust it according to the following procedure. Change the setting. If the shift cannot be adjusted to within the specification with a single adjustment, perform the adjustment again to change the setting. Press the Yes key to apply the setting.
	 NOTE If the Stop key is pressed, instead of the Yes key, the main screen is displayed and the setting returns to that before it was changed. Place the test pattern on the Original Glass again, make another test copy, and check it.

H. ADF SUB ZOOM

For details, see DF-501 Service Manual.

Functions	 To adjust for variations in the accuracy of all parts and their mounting accuracy by varying the scanning zoom ratio in the sub-scanning direction when using the Auto- matic Document Feeder.
Use	 After the PRN MAIN REGIST and PRN SUB REGIST and CCD SUB ZOOM adjustments have been performed When the Upper Cover Assy. (Original Glass) has been replaced When the ADF has been replaced

I. ADF MAIN REGIST

For details, see DF-501 Service Manual.

Functions	 To adjust for variations in the accuracy of all parts and their mounting accuracy by varying the scanning start position in the main scanning direction when using the Automatic Document Feeder.
Use	 After the PRN MAIN REGIST and PRN SUB REGIST and CCD MAIN ZOOM adjustments have been performed After the ADF SUB ZOOM adjustments have been performed When the Upper Cover Assy. (Original Glass) has been replaced When the ADF has been replaced

J. ADF SUB REGIST

For details, see DF-501 Service Manual.

Functions	 To adjust for variations in the accuracy of all parts and their mounting accuracy by varying the scanning start position in the sub-scanning direction when using the Auto- matic Document Feeder.
Use	 After the PRN MAIN REGIST and PRN SUB REGIST and CCD SUB ZOOM adjustments have been performed After the ADF SUB ZOOM adjustments have been performed When the Upper Cover Assy. (Original Glass) has been replaced When the ADF has been replaced

13.3.3 COUNTER

• The counter values can be displayed.

A. TOTAL COUNTER

Functions / Use	To display the total number of pages used.		
Setting/Procedure	COPY : Number of copies printed PRINT : Number of computer printouts printed		
	 Test prints made in Service mode to check the operation are not counted. 		

B. PM COUNTER

Functions / Use	 To display the number of times that PM parts are used. 		
Setting/Procedure	To clear the counter data, use the functions on the "CLEAR DATA" menu of Ser- vice mode.		

C. I/C COUNTER

Functions / Use	To display the total number of times that the Drum Cartridge has been used.
Setting/Procedure	To clear the counter data, use the functions on the "CLEAR DATA" menu of Ser- vice mode.

D. APPLICATION COUNTER

Functions / Use	 To display the number of pages used with each application. 		
Setting/Procedure	COPY PRINT : Number of copies printed FAX RX PRINT : Number of Fax reception printed. REPORT PRINT : Number of Report printed. PC PRINT : Number of computer printouts printed FAX TX PAGE : Number of Fax transmitting pages. MAIL TX PAGE : Number of Mail transmitting pages. • To clear the counter data, use the functions on the "CLEAR DATA" menu of Service mode.		

E. SCAN COUNTER

Functions / Use	 To display the number of scans made. 			
Setting/Procedure	MONOCHROME : Number of monochrome scans COLOR : Number of color scans			
	 Scans made while making copies are not counted. To clear the counter data, use the functions on the "CLEAR DATA" menu of Service mode. 			

F. PRINTER JAM COUNTER

Functions / Use	To display the number of misfeeds that occurred while printing.		
Setting/Procedure	To clear the counter data, use the functions on the "CLEAR DATA" menu of Service mode.		

G. ADF JAM COUNTER

Functions / Use	 To display the number of misfeeds that occurred while using the Automatic Doc- ument Feeder.
Setting/Procedure	 To clear the counter data, use the functions on the "CLEAR DATA" menu of Service mode.

H. TROUBLE COUNTER

Functions / Use	 To display the number of times each error was detected.
Setting/Procedure	C0045 :Fuser fan error
	C0210 :Transfer voltage error
	C0500 :Fuser Warm up error
	C0510 :Fuser temperature low
	C0520 :Fuser overheat
	C0650 :Home sensor error / Scanner motor error
	C1200 :ASIC memory abnormal
	C1300 :Polygon mirror motor error
	C133B :Communication with option error
	C133C :Modem error
	C133D :ROM checksum error
	C13F0 :Laser error
	C1468 :Parameter Chip error
	C14A3 :IR lamp malfunction
	 To clear the counter data, use the functions on the "CLEAR DATA" menu of Service mode.

13.3.4 DISPLAY

• Various information can be displayed.

Function	Purpose	Setting Details/Preca	utions	
MAIN F/W VER.	To display the version of the Copier firmware.			
ENGINE F/W VER.	To display the version of the engine firmware.			
PCL F/W VER.	To display the version of the PCL firmware.			
NIC F/W VER.	To display the version of the NIC firmware.			
MAIN RAM SIZE	To display the size of the main memory.			
PCL RAM SIZE	To display the size of the PCL memory.			
SERIAL NO.	 To display the serial number of the main unit. Once the serial number is specified, "SERIALNO." on the "ADJUST" menu cannot be set again. 			
CUSTOMER ID	To display the customer ID for the main unit.			
TC TYPE	To specify the type of Toner Cartridge that should be installed in the main unit.	 The default setting differing on the marketing ar 	ers depend- rea.	
	 Once the type of Toner Cartridge is specified, "TC TYPE" on the "ADJUST" menu cannot be set again. <types cartridges="" of="" toner=""></types> Europe: Toner Cartridge 906 A Others: Toner Cartridge 907 B North/ South America: Toner Cartridge 908 C 	Toner Cartridge Type	Setting	
		(No Toner Cartridge)	0	
		(Not Used)	1	
		A	2	
		В	3	
		(Not Used)	4	
		С	5	
		(Not Used)	6	
		(Not Used)	7	
		(Not Used)	8	
		(Not Used)	9	
		(Not Used)	10	
		(Not Used)	11	

*: bizhub 161f only

13.3.5 FUNCTION

• The service functions (paper feed test and image printing) can be checked and adjusted.

A. PAPER FEED TEST

Functions	 To check the paper feeding in the paper take-up/transport sections without print- ing on the paper.
Use	When a paper misfeed occurs
Setting/Procedure	 Select the paper tray. Press the Start key to begin testing paper feeding. Press the Stop key to stop testing paper feeding.

B. PRINT TEST PATTERN 1

Functions	To print the test pattern for adjusting the image.
	4980S530AA
Use	 If there is tilt or when registration or zoom ratio adjustments are performed
Setting/Procedure	 Select the paper tray. Select the test pattern 1. Press the Start key to print the test pattern.

C. PRINT TEST PATTERN 2

Functions	To print the test pattern for halftones and gradations.
	4980S531AA
Use	 When checking density and pitch irregularities When checking reproducibility of gradations
Setting/Procedure	 Select the paper tray. Select the test pattern 2. Press the Start key to print the test pattern.

D. ADF FEED TEST

Functions	 To check the paper feeding in the paper take-up/transport sections in the Auto- matic Document Feeder.
Use	When a document misfeed occurs
Setting/Procedure	 Load paper into the Automatic Document Feeder. Press the Start key to begin testing paper feeding. Press the Stop key to stop testing paper feeding.

E. COPY ADF GLASS AREA

Functions	To check for dirt in the scanning section of the Automatic Document Feeder.
Use	 If spots appear in the copies
Setting/Procedure	 Load A4 or Letter paper into Tray1. Press the Start key to start the "COPY ADF GLASS AREA" function. Two copy samples are fed out. Check that no spots appear in the copy samples. Press the Stop key to stop the "COPY ADF GLASS AREA" function.

F. CCD MOVE TO HOME

Functions	To move the scanner to its home position in order to secure the scanner.
Use	When transporting the machine
Setting/Procedure	NOTE When transporting the machine, be sure to move the scanner to its home position and secure it with the stopper at the bottom left of the IR.

G. UPLOAD FIRMWARE

Functions/Use	Download firmware from this machine to remote side, after setup of remote side location.
Setting/Procedure	 Machine will dial automatically and copy the EPROM data to remote side machine. For details, refer to ADJUSTMENT.

H. FAX RES. COPY TEST

Functions	Fax resolution copy test
Use	 To check whether the encoding/ decoding process is correct
Setting/Procedure	 The paper source is fixed to Tray1(MP).(Tray cannot be changed.) When A4 or Letter is not loaded in Tray1, operation of printing is not performed.
	NOTE If an error is displayed during the test, execute "SERVICE MODE/CLEAR DATA/DRAM CLEAR."

I. SCAN TEST

Functions	To check the lighting of the Exposure Lamp and the movement of the scanner.
Use	If the scanner malfunctions
Setting/Procedure	 Press the Start key to begin the scanner test. Press the Stop key to stop the scanner test.

13.3.6 Soft Switch Function

• Refer to the chapter of soft switch for the explanation of soft switch.

🖙 170



A. KEY DEFINITION FOR SOFT SWITCH

Key	Definition
•	Soft Switch Number Forward.
A	Soft Switch Number Backward.
YES	Update Soft Switch by current setting.
NO/STOP	Exit Soft Switch setting
ONE TOUCH	 1 - 15 of the soft switch numbers uses and selects an one-touch key. 16 - 64 of the soft switch numbers uses and selects ↓ key.
13.3.7 REPORT

- The following list is selected, and press YES key.
- After service mode ends, the list is automatically printed.

No.	Indication on LCD
1	SERVICE DATA LIST
2	ERROR CODE LIST
3	T.30 PROTOCOL LIST

A. SERVICE DATA LIST

- Print service data list report and Error log history list.
- Service Data list includes the following items:
- 1. Report title
- 2. Soft switch list: Soft switch is displayed by HEX No.
 - example)

When the setting of SOFT SWITCH #01 is 0000 0001 (Bit No. 8765 4321)", it is written as 20.

Hex-	-binary								Н	EX							
conve	rsion list	0	1	2	3	4	5	6	7	8	9	А	В	С	D	Е	F
	4 (8)	0	0	0	0	0	0	0	0	1	1	1	1	1	1	1	1
Bit no	3 (7)	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1
Dit 110.	2 (6)	0	0	1	1	0	0	1	1	0	0	1	1	0	0	1	1
	1 (5)	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1

- 3. Communication history and counter
- 4. Mailbox ID & Password
- 5. RX in memory password
- 6. Admin. password
- 7. Section number password
- 8. ROM ID

• Error log history list includes the following items:

No.	Item	Description
1	Index	Index number from 0 - 9999
2	Error	Error code number
3	Maker	NSF frame maker code
4	Tell.	Remote side or TX side telephone number for that transaction

(1) Service Data List (example)

			SI	ERVI	CE D	ata l	.IST									-
									(0	exam	ple) = He	x 01	= 000	0 00	01	
									P	Rit no	- 87	65	13	2 1	01	
NAME ABC 123										Dit No.	- 07	Di+	404			
TEL 1234567											.8 = 0	DIL	NO.4	=0		
DATE:Dec.01.200	3 15:12						_	/			.7 = 0	DIL	NO.3	=0		
MARKETING ARE	EA=STAN	DARE	C						E		.6 = 0	BIT	NO.2	=0		
SHIPMENT DEST	INATION	= ME	TRI	<u>c</u>					E	Bit No	.5 = 0	Bit	No.1	=1		
SOFT SWITCH																
SW01-SW16	01 20	80	0C	00	00	07	61	00	81	00	80	10	00	01	03	
SW17-SW32	00 00	68	00	80	06	00	00	00	28	00	A7	14	68	00	00	
SW33-SW48	C0 82	10	8A	00	C1	00	08	00	00	00	04	00	06	00	89	
SW49-SW64	01 00	00	00	00	B0	00	00	00	00	00	21	0F	00	80	10	
COMMUNICATIO	ON HISTO	ORY 8	S CC	DUN	TER											
000000: ECM RX	TIME					00	0000): E(СМ 1	ГХ Т	IME					
000001: G3 RX T	IME					00	0000): G3	3 RX	(PAC	GΕ					
000000: V.17 14.4	ιK					00	0000): V.	17 1	2K						
000000: V.17 9.6k	<					00	0000): V.	177	.2K						
000000: V.29 9.6K	(00	0000): V.2	29 7	.2K						
000000: V.27 4.8K						00	000	1: V.2	272	.4K						
000000: G3 IX II						00	0000	J: Ga	3 I X		٦E					
000000. V.17 14.4	Hr.					00		J. V. h. V.	22 1	2N วห						
000000. V.33 14.4	нх. (00		יעי ר. אייעיר	177	21						
000000: V.17 9.01	(00	0000). v.	297	2K						
000000 [.] V 27 4 8k	(00	0000	י v	272	4K						
000007: V.34 RX	TIME					00	0007	7: V.:	34 R	X P/	٩GE					
000002: 33.6K						00	0005	5: 31	.2K							
000000: 28.8K						00	0000): 26	6.4K							
000000: 24.0K						00	0000): 21	.6K							
000000: 19.2K						00	0000	D: 16	6.8K							
000000: 9.6K						00	0000): 7.2	2K							
000000: 4.8K						00	0000): 2.4	4K							
000001: V.34 TX 1	TIME					00	0015	5: V.(34 T	X PA	GE					
000001: 33.6K						00	0006	5:31	.2K							
000000: 28.8K						00	0000	J: 26	0.4K							
000000: 24.0K						00		J: ZI								
000000. 19.2K						00		ט	0.0N							
000000. 9.0K						00		J. 7.4 ハウノ	2 IX 4 K							
000000. 4.0K	TIME					00	0000	7. JP		зх т	IME					
000000: TOTAL C	OUNTER					00	2001			5.1						
000000: COPY PI	RINT					00	0000): FA	XP	RIN ⁻	Г					
000000: REPORT	PRINT					00	0000): PC	C PF	RINT						
MAILBOX ID &	PW															
NO.1 ID=	PW=	NO	.2	D=		F	PW=		NO.	.3 IC)=		P١	N=		
NO.4 ID=	PW=	NO	.5 I	D=		F	PW=									

SERVICE DATA LIST

NAME:ABC 123 TEL:1234567 DATE:Dec.01.2003 15:12

-- ADJUST --PRINT MAIN REGIST: 77 CCD MAIN ZOOM: 100 CCD MAIN REGIST: 100 ADF SUB ZOOM: 100 ADF MAIN REGIST: 100 SERIAL NUMBER: 12345678 TC TYPE: 1

RX IN MEMORY: ADMIN.PASSWORD: 000000 MAIN RAM SIZE: 16MB PCL RAM SIZE: 0MB

-- ROM ID --01/01/2004 v1.00-0 PRN: SUB REGIST: 100 CCD: SUB ZOOM: 100 CCD SUB REGIST: 100

ADF SUB REGIST: 100 CUSTOMER ID: 1 000000: G3 TX PAGE

(2) Error Log History List (example)

The following table is the error log history. The table keeps the last 40 records only.

Index Error Maker Tell 0001: 0070 49EE 88634733507 0002: 00A0 49EE 88634733507 0003: 0070 0000 0000 0004: 0070 0000 0000 0005: 0070 0000 0000 0008: 0070 0000 0000 0008: 0070 0000 0000 0010: 0070 0000 0000 0011: 0070 0000 0011: 0070 0010: 0070 0000 0013: 0070 0000 0014: 0070 0000 0015: 0070 0000 0016: 0070 0000 0018: 0070 0000 0018: 0070 00000 0019: 0020 49EE 123 0020: 0070 00000 0000 0000 0000 0000 0019: 0020 49EE 123 0020: </th <th></th> <th></th> <th>ERROR LOG H</th> <th>IISTORY LIST</th>			ERROR LOG H	IISTORY LIST
0001: 0070 49EE 88634733507 0002: 00A0 49EE 0000 0004: 0070 0000 0005: 0070 0000 0008: 0070 0000 0009: 0070 0000 0008: 0070 0000 0011: 0070 0000 0012: 0070 0000 0011: 0070 0000 0011: 0070 0000 0011: 0070 0000 0011: 0070 0000 0011: 0070 0000 0011: 0070 0000 0013: 0070 0000 0014: 0070 0000 0015: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000 Image: the set of the	Index	Error	Maker	Tell
0002: 00A0 49EE 0003: 0070 0000 0004: 0070 0000 0006: 0070 0000 0007: 0070 0000 0008: 0070 0000 0010: 0070 0000 0010: 0070 0000 0011: 0070 0000 0012: 0070 0000 0013: 0070 0000 0014: 0070 0000 0015: 0070 0000 0016: 0070 0000 0017: 0070 0000 0016: 0070 0000 0018: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000	0001:	0070	49EE	88634733507
0003: 0070 0000 0004: 0070 0000 0005: 0070 0000 0008: 0070 0000 0009: 0070 0000 0011: 0070 0000 0012: 0070 0000 0013: 0070 0000 0014: 0070 0000 0013: 0070 0000 0014: 0070 0000 0015: 0070 0000 0016: 0070 0000 0017: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000 Image: the second se	0002:	00A0	49EE	
0004: 0070 0000 0005: 0070 0000 0006: 0070 0000 0007: 0070 0000 0008: 0070 0000 0010: 0070 0000 0011: 0070 0000 0012: 0070 0000 0013: 0070 0000 0015: 0070 0000 0016: 0070 0000 0015: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000	0003:	0070	0000	
0005: 0070 0000 0006: 0070 0000 0007: 0070 0000 0008: 0070 0000 0009: 0070 0000 0010: 0070 0000 0011: 0070 0000 0012: 0070 0000 0013: 0070 0000 0014: 0070 0000 0015: 0070 0000 0016: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000 Image: Colored Colo	0004:	0070	0000	
0006: 0070 0000 0007: 0070 0000 0008: 0070 0000 0010: 0070 0000 0011: 0070 0000 0012: 0070 0000 0014: 0070 0000 0015: 0070 0000 0016: 0070 0000 0018: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000 Image: Colored State	0005:	0070	0000	
0007: 0070 0000 0008: 0070 0000 0010: 0070 0000 0011: 0070 0000 0012: 0070 0000 0013: 0070 0000 0016: 0070 0000 0015: 0070 0000 0016: 0070 0000 0017: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000 Image: Control of the state of t	0006:	0070	0000	
0008: 0070 0000 0009: 0070 0000 0010: 0070 0000 0011: 0070 0000 0012: 0070 0000 0013: 0070 0000 0014: 0070 0000 0015: 0070 0000 0016: 0070 0000 0017: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000 Image: Colored State	0007:	0070	0000	
0009: 0070 0000 0010: 0070 0000 0011: 0070 0000 0012: 0070 0000 0013: 0070 0000 0014: 0070 0000 0015: 0070 0000 0016: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000 Image: Constant of the state of the	0008:	0070	0000	
0010: 0070 0000 0011: 0070 0000 0012: 0070 0000 0013: 0070 0000 0014: 0070 0000 0015: 0070 0000 0016: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000	0009:	0070	0000	
0011: 0070 0000 0012: 0070 0000 0013: 0070 0000 0014: 0070 0000 0016: 0070 0000 0017: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000 V V V V NSF signal 3rd. and 4th byte Keep 20 digits of TSI or CS	0010:	0070	0000	
0012: 0070 0000 0013: 0070 0000 0014: 0070 0000 0015: 0070 0000 0016: 0070 0000 0017: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000 Image: Constant of the state of th	0011:	0070	0000	
0013: 0070 0000 0014: 0070 0000 0015: 0070 0000 0016: 0070 0000 0017: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000 V V V V NSF signal 3rd. and 4th byte Keep 20 digits of TSI or CS	0012:	0070	0000	
0014: 0070 0000 0015: 0070 0000 0016: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000 NSF signal 3rd. and 4th byte Keep 20 digits of TSI or CS	0013:	0070	0000	
0015: 0070 0000 0016: 0070 0000 0017: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000	0014:	0070	0000	
0016: 0070 0000 0017: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000 Image: Constant of the second	0015:	0070	0000	
0017: 0070 0000 0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000 NSF signal 3rd. and 4th byte Keep 20 digits of TSI or CS	0016:	0070	0000	
0018: 0070 0000 0019: 0020 49EE 123 0020: 0070 0000 NSF signal 3rd. and 4th byte Keep 20 digits of TSI or CS	0017:	0070	0000	
0019: 0020 49EE 123 0020: 0070 0000 NSF signal 3rd. and 4th byte Keep 20 digits of TSI or CS	0018:	0070	0000	
0020: 0070 0000 NSF signal 3rd. and 4th byte Keep 20 digits of TSI or CS	0019:	0020	49EE	123
NSF signal 3rd. and 4th byte Keep 20 digits of TSI or CS	0020:	0070	0000	\
NSF signal 3rd. and 4th byte Keep 20 digits of TSI or CS				
		NSF signal 3	rd. and 4th byte	Keep 20 digits of TSI or CSI

B. ERROR CODE LIST

Г

- Print out error code as following table. (example)
- See Troubleshooting Error Code.

		ERROF	R CODE LIST		
CODE	ERROR TIMES	CODE	ERROR TIMES	CODE	ERROR TIMES
0001 0007 0007 0010 0013 0016 00122 00258 00258 00259 00259 00259 00250 00347 00034 00040 00403 00404 00404 00404 00404 00404 004052 00555 00558 005561 00647 00552 00558 005561 00647 00652 00558 005561 00647 00652 00558 005561 00647 00652 00558 005561 00677 00677 00677 00077 00077 000775 00075	00000000 00000000 <t< td=""><td>0002 0005 0008 00014 0017 0014 0017 0023 0029 0029 0029 0029 0029 0029 0029</td><td>00000000 <t< td=""><td>0003 0006 0007 00012 0015 0012 00214 00226 00226 00226 00226 00257 00258 00268 00267 00275 0000000000</td><td>00000000 <t< td=""></t<></td></t<></td></t<>	0002 0005 0008 00014 0017 0014 0017 0023 0029 0029 0029 0029 0029 0029 0029	00000000 00000000 <t< td=""><td>0003 0006 0007 00012 0015 0012 00214 00226 00226 00226 00226 00257 00258 00268 00267 00275 0000000000</td><td>00000000 <t< td=""></t<></td></t<>	0003 0006 0007 00012 0015 0012 00214 00226 00226 00226 00226 00257 00258 00268 00267 00275 0000000000	00000000 00000000 <t< td=""></t<>

13.3.8 T.30 PROTOCOL LIST

- Print out T.30 or V8 protocol after communication.
- 1. SESSION NUMBER
- 2. FUNCTION NAME
- 3. DESTINATION NAME/TELEPHONE NUMBER
- 4. COMMUNICATION DATE & TIME
- 5. TOTAL PAGE NUMBER FOR THIS SESSION
- 6. COMMUNICATION SPEED AND ECM MODE
- 7. COMMUNICATION RESULT
- 8. T.30 COMMAND SENT BY LOCAL FAX
- 9. T.30 COMMAND RECEIVED FROM REMOTE FAX
- 10. T.30 FRAME THAT INCLUDES ADDRESS & CONTROL & DATA

A. V.17 Communication (example)

rs 132

			PROTOCOL MO	NITOR RE	EPORT				
TEL:886 3 4 DATE: APR.	, 733507 10'97 12:20								
SESSION	FUNCTION	NO	DESTINATION STATION	DATE	TIME	PAGE	DURATION	MODE	RESULT
0001	ТХ	01	ABC 22345678901234567890	DEC.02	15:00	008	00h00min00s	ECM-12	ОК
T)/	DY	_	r						
17	нх				DA	IA			
NSF			FF 03 20 00 00 00 00 00 00 00	00 00 00 00	00 00 00	00 00 0	0 00 00 00 00 0	0	
CSI			FF 03 40 00 00 00 00 00 00 00	00 00 00 00	00 00 00	00 00 0	0 00 00 00 00 0	0 00	
DIS			FF 13 40 00 00 00 00 00						
	NSS		FF 03 00 00 00 00 00 00 00 00	00 00 00 00					
	DCS		FF 03 00 00 00 00 00 00 00 00	00 00					
	TCF		00 00 00 00 00 00 00 00 00 00	00 00					
CFR			FF 13 84						
	PIX								
	EOP		FF 13 BF 2F 00 00 41						
MCF		\mathbf{i}	FF 13 8C						
	DCN		FF 13 FB						
	ï		Ň						
DATA	DATA PHASE TRAINING PHASE								

B. V.34 Communication (example)



13.3.9 ADMIN. REGISTRATION (Administrator number registration)

• The administrator number (0 to 999999) required for the Administrator mode of Utility is programmed or changed.

A. Remote monitor

Setting value	Description	Default
LIMITED	Enable remote monitor function limitedly	0
FULL	Enable remote monitor function fully	
OFF	Disable remote monitor function	

13.3.10 FIXED ZOOM CHANGE

Functions/Use	The fixed zoom ratios can be changed.
Setting/Procedure	1. Select the fixed zoom ratio that you wish to change.
	Use the 10-Key Pad to type in the desired fixed zoom ratio.

Default fixed zoom ratios and setting ranges according to marketing area

• Metric

Setting Name	Initial fixed zoom ratio	Setting Range
Reduction 2	70%	51% to 70%
Reduction 1	81%	71% to 99%
Expansion 1	115%	101% to 140%
Expansion 2	141%	141% to 199%

• Inch

Setting Name	Initial fixed zoom ratio	Setting Range
Reduction 2	64%	51% to 64%
Reduction 1	78%	65% to 99%
Expansion 1	129%	101% to 153%
Expansion 2	154%	154% to 199%

13.3.11 FACTORY TEST

• This test is for factory adjustment only and should NOT be used.

	Functions/Use
SIGNAL TEST	This test is for factory adjustment only and should NOT be used.
RELAY TEST	This test is for factory adjustment only and should NOT be used.
DIAL TEST	This test is for factory adjustment only and should NOT be used.
VOLUME TEST	To check the volume of the speaker.
PANEL BUZZER TEST	 To check the operation of the display and all indicators and buttons. When the panel buzzer test are finish, press the panel reset key twice.
RAM TEST	To test reading and writing of the memory.

13.3.12 CLEAR DATA

• Each type of data can be cleared.

A. DRAM CLEAR

Functions/Use	 To clear the settings for the functions listed at the right and return the functions to their default settings. Clear all data in the memory file and free all memory to 100%, the user data are not affected. But only clear DRAM data on PWB-P.
Setting/Procedure	NOTE • Not include DRAM data on NIC.

B. SRAM CLEAR

Functions	 To clear the settings for the functions listed at the right and return the functions to their default settings.
Use	 The following items are cleared (initialization).
Setting/Procedure	 NOTE Before executing "SRAM CLEAR," be sure to record the setting values that are to be initialized through "SRAM CLEAR." For the record of the setting values, it is a good idea to have reports and lists printed. Some setting values are not included any of these reports or lists. Be sure to make a note of them separately. After "SRAM CLEAR" has been executed, make necessary entries of data again based on the setting values recorded.

MODE	Initialized Items		Default	Report/ List		
UTILITY	MACHINE SETTING	BUZZAR VOLUM	LOW	MACHINE STATUS LIST	13	57
MODE	ADMIN. MANEGEMENT	REMOTE MONITOR	LIMITED	None	Non	е
	FAX REGISTRATION	ONE TOUCH DIAL SPEED DIAL GROUP DIAL PROGRAM DIAL BATCH TX MAIL BOX	None None None None None	ONE TOUCH LIST SPEED DIAL LIST KEY SETTING LIST MACHINE STATUS LIST	8	57
	TX OPERATION	SCAN CONTRAST RESOLUTION DEFAULT TX HEADER	0 STD MEM. TX ON	MACHINE STATUS LIST	8	57
	RX OPERATION	MEMORY RX MODE NO. of RINGS REDUCTION RX RX PRINT RX MODE FORWARD FOOTER SELECT TRAY CLOSED NETWORK\	OFF 2 ON MEMORY RX AUTO RX OFF ENABLE OFF OFF	MACHINE STATUS LIST	8	57
	COMM. SETTING	TONE/ PULSE LINE MONITOR PSTN/ PBX	TONE LOW PSTN	MACHINE STATUS LIST	2	57
	REPORT	ACTIVITY REPORT RESERV. REPORT TX RESULT REPORT RX RESULT REPORT	ON OFF OFF OFF	MACHINE STATUS LIST	8	57
	INIRTIAL USER DATA	DATE & TIME USER FAX NO. USER NAME	None None None	MACHINE STATUS LIST	2	57
	NETWORK SETTING	IP ADDRESS SUBNET MASK GATE WAY DNS CONFIG GATE WAY TX	AUTO None DISABLE DISABLE	MACHINE STATUS LIST	8	57

MODE	Initialized Items		Default	Report/ List		
UTILITY MODE	E-MAIL SETTING 1	SENDER NAME E-MAIL ADDRESS SMTP SERVER SMTP TIMEOUT TEXT INSERT DEFAULT SUBJECT	None None 60 OFF None	MACHINE STATUS LIST	1 37	57
	E-MAIL SETTING 2	POP3 SERVER POP3 PORT NO. POP3 TIMEOUT POP3 ACCOUNT POP3 PASSWORD AUTO RECEPTION REPLAY ADDRESS HEADER PRINT	None None None None OFF None OFF	MACHINE STATUS LIST	8	57
	SCAN SETTING	RESOLUTION IMAGE FROMAT CODING METHOD	300 X 300 TIFF MH	MACHINE STATUS LIST	2	57
TX/RX Result (Activity Data)			None	TX RESULT REPORT RX RESULT REPORT ACTIVITY REPORT	2	57
Image Data	of DRAM memory file		None	MEMORY DATA LIST MEMORY IMAGE PRINT	8	57
SERVICE	SERVICE'S CHOICE	MARKETTING AREA	STANDARD	SERVICE DATA LIST	3	148
MODE		TX SPEED RX SPEED TX LEVEL RX LEVEL CNG LEVEL CCD LEVEL ECM MODE CODING SCHEME PROTOCOL REPORT	V.34 V.34 -3 dBm to -8 dBm -3 dBm to -42 dBm -9 dBm -11 dBm -11 dBm ON JBIG OFF	None	Nor	le

C. MEMORY CLEAR

Functions	• To clear the settings for the functions listed at the right and return the functions to their default settings.
Use	The following items are cleared (initialization).
Setting/Procedure	 NOTE Before executing "MEMORY CLEAR," be sure to record the setting values that are to be initialized through "MEMORY CLEAR." For the record of the setting values, it is a good idea to have reports and lists printed. Some setting values are not included any of these reports or lists. Be sure to make a note of them separately. After "MEMORY CLEAR" has been executed, make necessary entries of data again based on the setting values recorded.

MODE	Initialized Items		De	fault	Report/ List		
UTILITY MODE	TILITY MODE MACHINE SETTING ENERGY SAVE MODE 1 MODE ENERGY SAVE MODE DENSITY(ADF) MODE1 DENSITY(BOOK) MODE1 BUZZAR VOLUM LOW INITIAL MODE COPY		MACHINE STATUS LIST	13	57		
	PAPER SOURCE SETUP	TRAY1 PAPER	METRIC A4/ PLAIN	INCH LETTER/ PLAIN	MACHINE STATUS LIST	8	57
		TRAYSETTING	CONTINU	JOUS			
	ADMIN. MANEGEMENT	REMOTE MONITOR	LIMITED		None	Non	e
	COPY SETTING	PAPER PRIORITY DENSITY PRIORITY DENSITY LEVEL(A) DENSITY LEVEL(M) OUTPUT PRIORITY RESOLUTION	TRAY1 AUTO 0 0 NON 600X300		MACHINE STATUS LIST	3	57
	FAX REGISTRATION	ONE TOUCH DIAL SPEED DIAL GROUP DIAL PROGRAM DIAL BATCH TX MAIL BOX	None None None None None		ONE TOUCH LIST SPEED DIAL LIST KEY SETTING LIST MACHINE STATUS LIST	2	57
	TX OPERATION	SCAN CONTRAST RESOLUTION DEFAULT TX HEADER	0 STD MEM. TX ON		MACHINE STATUS LIST	13	57
	RX OPERATION	MEMORY RX MODE NO. of RINGS REDUCTION RX RX PRINT RX MODE FORWARD FOOTER SELECT TRAY CLOSED NETWORK\	OFF 2 ON MEMORY RX AUTO RX OFF OFF ENABLE OFF		MACHINE STATUS LIST	83	57
COMM. SETTING TONE/ PULSE LINE MONITOR PSTN/ PBX		TONE LOW PSTN		MACHINE STATUS LIST	1 37	57	

MODE	Initialized Items		De	fault	Report/ List		
UTILITY MODE	REPORT	ACTIVITY REPORT RESERV. REPORT TX RESULT REPORT RX RESULT REPORT	ON OFF OFF OFF		MACHINE STATUS LIST	B	57
	INIRTIAL USER DATA	DATE & TIME USER FAX NO. USER NAME	None None None		MACHINE STATUS LIST	8	57
	NETWORK SETTING	IP ADDRESS SUBNET MASK GATE WAY DNS CONFIG GATE WAY TX	AUTO None None DISABLE DISABLE		MACHINE STATUS LIST	637	57
	E-MAIL SETTING 1	SENDER NAME E-MAIL ADDRESS SMTP SERVER SMTP TIMEOUT TEXT INSERT DEFAULT SUBJECT	None None 60 OFF None		MACHINE STATUS LIST	1 37	57
	E-MAIL SETTING 2	POP3 SERVER POP3 PORT NO. POP3 TIMEOUT POP3 ACCOUNT POP3 PASSWORD AUTO RECEPTION REPLAY ADDRESS HEADER PRINT	None None None None OFF None OFF		MACHINE STATUS LIST	13	57
	SCAN SETTING	RESOLUTION IMAGE FROMAT CODING METHOD	300 X 300 TIFF MH)	MACHINE STATUS LIST	13	57
SERVICE	SERVICE'S CHOICE	MARKETTING AREA	STANDAR	RD	SERVICE DATA LIST	13	148
MODE		TX SPEED RX SPEED TX LEVEL RX LEVEL DTMF LEVEL CNG LEVEL CED LEVEL ECM MODE CODING SCHEME PROTOCOL REPORT	V.34 V.34 -3 dBm to -37dBm to -9 dBm -11 dBm -11 dBm ON JBIG OFF	9 -8 dBm 9 -42 dBm	None	Non	e
	ADJUST	PRN MAINREGIST PRN SUB REGIST CCD MAIN ZOOM CCD SUB ZOOM CCD MAIN REGIST CCD SUB REGIST ADF SUB ZOOM ADF MAIN REGIST ADF SUB REGIST	100 100 100 100 100 100 100 100 100		SERVICE DATA LIST	83	148
	ADMIN. REGISTRATION		000000		SERVICE DATA LIST	1 32	148
	FIXED ZOOM CHANGE	REDUCTIN 2 REDUCTION1 EXPANTION1 EXPANTION2	METRIC 70% 81% 115% 141%	INCH 64% 78% 129% 154%	None	Non	e
	SECURITY	MACHINE COUNTER	ENABLE	·	None	Non	е
							_

D. TOTAL CLEAR

Functions/Use	 The following counter are cleared (initialization).
Setting/Procedure	 PM counter I/C counter Application counter Scan counter Printer jam counter ADF jam counter Trouble counter NOTE After the "TOTAL CLEAR" function is performed, turn the machine off, then on again. The clearance of "TOTAL COUNTER" can not be performed.

E. Other counter clear

Functions	Use
PM COUNTER	To clear the PM COUNTER value.
I/C COUNTER	To clear the I/C COUNTER value.
APPLICATION COUNTER	To clear the APPLICATION COUNTER value.
SCAN COUNTER	To clear the SCAN COUNTER value.
PRINTER JAM COUNTER	To clear the PRINTER JAM COUNTER value.
ADF JAM COUNTER	To clear the ADF JAM COUNTER value.
TROUBLE COUNTER	To clear the TROUBLE COUNTER value.

bizhub 160/160f bizhub 161/161f

14. Board Switch

14.1 Names of control panel parts and their functions

14.1.1 bizhub 160/ bizhub 161



No.	Key Name	Function			
1	Printer key	Press to enter Printer mode.			
2	Utility key	Press to enter Utility mode.			
3	Error lamp	The indicator lights up if an error or malfunction occurs.			
4	Display	Shows the number of copies to be made, the zoom ratio, and other settings.			
5	No/C key	 Press to reset the number of copies to "1". Press to clear various settings. Press to return to the previous screen. Press to specify various settings. 			
6	Yes key	Press to apply the specified setting.Press to specify various settings.			
7	10-Key Pad	Use to type in the number of copies to be made and any other numeric data.			
8	Stop key	 Press to stop the print operation. Press to stop the scan operation. The indicator lights up in orange when the machine is brought to a pause or in a print cycle. 			
9	Panel Reset key	Press to reset all copy functions to their default settings.			
10	Start key	 Press to start a scanning operation. Press to start a print operation. Press to specify various settings. 			
11	▲ / ▼ key	 Press to change the zoom ratio between ×0.25 and ×4.00 in ×0.01 increments. Press to show the various settings and information. Press to specify various settings. 			
12	Zoom key	Press to select a zoom ratio from the preset fixed ratios.			

No.	Key Name	Function
13	Paper key	Press to select the paper in the desired paper tray.
14	< / > key	Press to adjust the image density.Press to specify various settings.
15	Auto/Photo key	Press to change the image density mode.
16	Status key	Press to display each counter value.
17	Sort key	Press to select the "Sort" function.
18	2in1 key	Press to select the "2in1" copy function.

14.1.2 bizhub 160f/ bizhub 161f



No.	Key Name	Function
1	Utility key	Press to enter Utility mode.
2	Printer key	Press to enter Printer mode.
3	Error lamp	The indicator lights up in orange if an error or malfunction occurs.
4	Display	Shows the number of copies to be made, the zoom ratio, and other settings.
5	No/ C key	 Press to reset the number of copies to "1". Press to clear the various settings. Press to return to the previous screen. Press to specify the various settings.
6	Yes key	Press to validate the setting just made.Press to specify the various settings.

bizhub 160/160f bizhub 161/161f

No.	Key Name	Function									
7	10-Key Pad	Use to enter the number of copies to be made and any other numeric data. Use to enter text such as a name.									
8	Scan key	Press to enter Scan mode. The indicator lights up in green to indicate that the machine is in Scan mode. (Available only when the Internet Fax & Network Scan Kit is installed.)									
9	Fax key	Press to enter Fax mode. The indicator lights up in green to indicate that the machine is in Fax mode.									
10	Copy key	Press to enter Copy mode. The indicator lights up in green to indicate that the machine is in Copy mode.									
11	Stop key	 Press to stop a print cycle. Press to stop a scanning sequence. The indicator flashes in orange when the machine is brought to a pause or in a print cycle. 									
12	Panel Reset key	Press to reset all print functions and settings to their defaults.									
13	123/ ABC key	Press to switch the function of the10-Key Pad between typ- ing in numbers and typing in letters.									
14	Start key	 Press to start a scanning or print cycle. Press to specify the various settings. The indicator lights up in green when the machine can accept print jobs. 									
15	▲/ ▼ key	 Press to change the zoom ratio in the range between a 0.25 and × 4.00 in × 0.01 increments. Press to scan through the various settings and information, in order. 									
16	Zoom key	Press to specify the validus settings. Press to select a zoom ratio from among those fixed ratios available as standard.									
17	Paper key	Press to select the paper tray that contains the desired paper.									
18	< / > key	Press to adjust the image density.Press to specify the various settings.									
19	Auto/ Photo key	Press to change the image density mode.									
20	Sort key	Press to select the sort function.									
21	2in1 key	Press to select the 2in1 function.									
22	Status key	Press to view the counters and transmission results. In addition, the list of settings specified for each function and the reports can be printed.									
23	Memory TX lamp	Lights up when the memory transmission function is selected.									
24	Auto RX lamp	Lights up when the automatic reception function is selected.									
25	Resolution key	Use to select the image quality (transmission resolution).									
26	Speaker key	Press to answer the call.Press again to hang up.									
27	Phone Book key	Use to display the information programmed for one-touch dialing, group dialing and speed dialing.									

No.	Key Name	Function
28	Redial/Pause key	Re-dials the last number called. During dialing, use to generate a pause when transferring from an internal to an external line or receiving information services.
29	Speed Dial key	Use to dial previously programmed fax numbers repre- sented by 3-digit numbers.
30	Function key	 Used to select a function. BROADCAST (broadcast transmission), TIMER TX (timer transmission), MAILBOX TX (mailbox transmission), PRINT MAILBOX RX (retrieve mailbox faxes), POLLING TX (polling transmission), POLLING RX (polling reception), RELAY INITIATE (relay initiation transmission), CANCEL RESERV. (cancel queued job), TX MODE (transmission mode), Internet fax reception (with the Internet Fax & Network Scan Kit installed)
31	One-touch Dial key	Used to dial previously programmed fax numbers.

14.2 Circuit Board Locations

14.2.1 bizhub 160



14.2.2 bizhub 161



14.2.3 bizhub 160f



14.2.4 bizhub 161f



14.3 Functions of switches and parts on PWBs

14.3.1 PWB-P (Controller/Mechanical Control Board)



Adjustment / Setting

14.3.2 PWB-IF (Interface Board)



14.3.3 NCU (Network Control Unit Board)

• bizhub 160f, bizhub 161f only

14.3.4 PCL (PCL Controller Board)

• bizhub 161, bizhub 161f only

14.3.5 NC-501: PWB- NIC (Network Interface Card Board)

• Option for bizhub 161, bizhub 160f, bizhub 161f

14.3.6 NC-501: NIC-IF (Plate NIC Board)

• Option for bizhub 161, bizhub 160f, bizhub 161f

14.4 Adjustment of jumper switches on NCU board

- Make the correct settings of the jumper switches at six places on the NCU Board according to the applicable marketing area.
- When the NCU Board has been replaced, check that the jumper switches are set as shown below.

* Country Classification Jumper Switch Setting

Туре	Jumper Switch	Setting	Country
STD (UL)/	JP1	2 - 3	STD (UL): Canada, South America, Taiwan, U.S A.
(Others)	JP2	1 - 2	STD (Others) [,] Bahrain Baltic Croatia Hong Kong Iran
	JP3	1 - 2	Kuwait, Malaysia, New Zealand, Poland, Qatar, Romania,
	JP4	1 - 2	Russia, Singapore, Slovakia, Slovenia, Ukraine, Others.
	JP5	2 - 3	
	JP6	2 - 3	
TBR-21	JP1	2 - 3	Austria, Belgium, Cyprus, Czech, Denmark, Finland,
	JP2	2 - 3	France, Germany, Greece, Hungary, Iceland,
	JP3	2 - 3	Ireland, Italy, Liechtenstein, Luxembourg, Netherlands, Norway, Sweden, Switzerland, I.I.K
	JP4	2 - 3	Nethenands, Norway, Sweden, Switzenand, C.N.
	JP5	1 - 2	
	JP6	1 - 2	
Australia/	JP1	2 - 3	Australia/ South Africa
South	JP2	2 - 3	
Africa	JP3	1 - 2	
	JP4	1 - 2	
	JP5	2 - 3	
	JP6	2 - 3	
China	JP1	2 - 3	China
	JP2	1 - 2	
	JP3	1 - 2	
	JP4	1 - 2	
	JP5	2 - 3	
	JP6	1 - 2	

15. Security Mode

• This mode is used to set various security functions.

15.1 Security Mode function tree

SECURITY	MACHINE COUNTER
02001111	

15.2 Security Mode setting procedure

NOTE

 Be sure to keep the access procedure for the Security mode from any unauthorized persons not involved with service operations.

15.2.1 Procedure

- 1. Display the Service mode screen.
- 2. Press the Stop key, then the 9 key.
- 3. The Security mode screen appears.

15.2.2 Exiting Procedure

• Press the Panel Reset key.

15.3 Security Mode functions

15.3.1 MACHINE COUNTER

Functions / Use	To enable or disable copying depending on whether or not the Mechanical Counter is installed.											
Setting/Procedure	The default setting is "ENABLE."											
	"ENABLE"	DISABLE										
	NOTE If "ENABLE" is selected, copying is possible even if the Mechanical Counter is not installed. 											

16. Soft Switch Set (bizhub 160f/bizhub 161f only)

16.1 Description

- This machine is provided with a soft switches used for making various adjustments. The initial values can be changed, defined to comply with the requirements unique to each individual country.
- The initial settings of the soft switches can be changed according to the marketing area. The settings can be changed when: The marketing area code is set in the Service mode. The marketing area code is set using the RSD utility software. SRAM is cleared using the Service mode. In this case, the initial settings are determined according to the current marketing area code.
- The bit status can be changed by the following methods:
- 1. Use Soft Switch available as a Service Mode function.

ræ 147

Hex								Н	EX								
conve	rsion list	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	Е	F
	4 (8)	0	0	0	0	0	0	0	0	1	1	1	1	1	1	1	1
Rit no	3 (7)	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1
Dit 110.	2 (6)	0	0	1	1	0	0	1	1	0	0	1	1	0	0	1	1
	1 (5)	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1

2. Use the RSD software function.

16.2 Default setting

16.2.1 Country for each Marketing area

NOTE

- A different country may be applicable depending on the communications standard.
- The marketing area settings can be set using the Service's choice of Service Mode.

🖙 126

• According to the following table, the machines that are installed in the West Europe Area select "West Europe" in the "Marketing Area" function. Do not select each country.

Marketing area	Country							
Standard	Baltic, Bahrain, Indonesia, Israel, Kuwait, Oman, Philippine, Poland, Qatar, Romania, Russia, Saudiarabia, Slovakia, Slovenia, Thailand, U.A.E., Ukraine							
U.S.A	U.S.A., Canada.							
West Europe	Austria, Belgium, Czech, Denmark, Finland, France, Greece, Hungary, Ireland, Italy, Netherlands, Norway, Portugal, Spain, Sweden, Switzerland, United Kingdom, West Europe.							
Asia	Hong Kong, Malaysia							
Setting in accordance with each country	Australia, China, Germany, Japan, Korea, New Zealand, South Africa, Taiwan.							
Singapore	Singapore (remark: with DTS default setting).							

16.3 Default soft switch setting for each market area 1

		Marketi	ng area							
Soft	Standard (Initial setting)	U.S.A.	West europe	Asia						
switch No.	Bit No.	Bit No.	Bit No.	Bit No.						
	1 2 3 4 5 6 7 8	1 2 3 4 5 6 7 8	1 2 3 4 5 6 7 8	1 2 3 4 5 6 7 8						
# 01	10000000	10000000	10000000	10000000						
# 02	00000100	0 0 0 0 0 0 0 0	0 0 0 0 0 1 0 0	0 0 0 0 0 1 0 0						
# 03	01100001	0 1 1 0 0 0 0 1	01100011	0 1 1 0 0 0 0 1						
# 04	00110000	00110000	0 0 1 1 0 0 0 0	0 0 1 1 0 0 0 0						
# 05	0 1 0 1 0 0 0 0	00010000	0 1 0 1 0 0 1 1	0 0 0 1 0 0 0 0						
# 06	1 1 1 1 0 0 1 0	1 1 1 1 0 0 1 0	1 1 1 1 0 0 1 0	1 1 1 1 0 0 1 0						
# 07	0 0 0 1 0 0 0 0	0 0 0 1 0 0 0 0	0 0 0 1 0 0 0 1	1 1 1 0 0 0 0 0						
# 08	10000110	10000110	0 0 0 0 1 1 1 1	1 0 0 0 0 1 1 0						
# 09	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	00101010	0 0 0 0 0 0 0 0						
# 10	1 0 0 0 0 1 0 1	10000101	1 1 1 1 0 1 1 1	1 0 0 0 0 1 0 1						
# 11	0 0 0 0 0 0 0 0	0 0 0 0 0 1 0 0	1 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0						
# 12	0 0 0 0 0 0 0 1	0 0 0 0 0 0 0 1	0 0 0 0 0 0 0 1	0 0 0 0 0 0 0 1						
# 13	0 0 0 0 1 0 0 0	0 0 0 0 1 0 0 0	0 0 1 0 1 0 0 1	0 0 0 0 1 0 0 0						
# 14	0 1 0 0 0 0 0 0	0 1 0 0 0 0 0 0	0 1 0 0 0 0 0 0	0 1 0 0 0 0 0 0						
# 15	1 0 0 0 0 0 0 0	1 0 0 0 0 0 0 0	1 0 0 0 0 0 0 0	1 0 0 0 0 0 0 0						
# 16	1 1 0 0 0 0 0 0	1 1 0 0 0 0 0 0	1 1 0 0 0 0 0 0	1 1 0 0 0 0 0 0						
# 17	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0						
# 18	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0						
# 19	00010110	0 0 0 1 0 1 1 0	1 1 0 1 0 1 1 0	0 1 1 0 0 1 1 0						
# 20	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0						
# 21	00000011	0 0 0 0 0 0 0 1	0 0 0 0 0 0 1 1	0 0 0 0 0 0 1 1						
# 22	0 1 1 0 0 0 0 0	0 1 1 0 0 0 0 0	0 1 1 0 0 0 0 0	0 1 1 0 0 0 0 0						
# 23	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0						
# 24	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0						
# 25	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0						
# 26	0 0 0 1 0 1 0 0	0 0 0 1 0 1 0 0	0 0 0 1 0 1 0 0	0 0 0 1 0 1 0 0						
# 27	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0						
# 28	1 1 1 0 0 1 0 1	1 1 1 0 0 1 0 1	1 1 1 0 1 0 1 0	1 1 1 0 0 1 0 1						
# 29	00101000	00101000	0 0 1 0 1 0 0 0	0 0 1 0 1 0 0 0						
# 30	0 0 0 1 0 1 1 0	0 0 0 1 0 1 1 0	0 0 0 1 0 1 1 0	0 0 0 1 0 1 1 0						
# 31	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0						
# 32	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0						
# 33	00000010	00000010	0 0 0 0 0 0 1 0	0 0 0 0 0 0 1 0						
# 34	0100000	0 1 0 0 0 0 0 0	0100000	0 1 0 0 0 0 0 0						
# 35	00001001	00000101	00000101	00001001						
# 36	01010001	01010001	01010001	0 1 0 1 0 0 0 1						
# 37	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0						

														Μ	arł	eti	ng	ar	ea													
Soft	Standard (Initial setting)								U.S	S.A					٧	Ve	st e	eur	ор	e		Asia										
SWITCH NO.			I	Bit	No					Bit No.								Bit No.							Bit No.							
	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8
# 38	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1
# 39	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
# 40	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 41	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 42	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 43	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 44	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 45	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 46	0	1	0	1	0	0	0	0	0	1	0	1	0	0	0	1	0	1	0	1	0	0	0	0	0	1	0	1	0	0	0	0
# 47	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 48	1	0	0	1	0	0	0	1	1	0	0	1	0	0	0	1	1	0	0	1	0	0	0	1	1	0	0	1	0	0	0	1
# 49	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
# 50	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 51	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 52	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 53	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 54	0	0	0	1	0	1	0	1	0	0	0	1	0	1	0	1	0	0	0	1	0	1	0	1	0	0	0	1	0	1	0	1
# 55	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 56	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 57	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 58	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 59	0	0	0	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 60	1	0	0	0	0	1	0	0	1	0	0	0	0	1	0	0	1	0	0	0	0	1	0	0	1	0	0	0	0	1	0	0
# 61	1	1	1	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	0	0
# 62	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 63	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1
# 64	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0

16.4 Default soft switch setting for each market area 2

	Marketing area											
Soft	Austria	China	Germany	Japan								
switch No.	Bit No.	Bit No.	Bit No.	Bit No.								
	1 2 3 4 5 6 7 8	1 2 3 4 5 6 7 8	1 2 3 4 5 6 7 8	1 2 3 4 5 6 7 8								
# 01	1 0 0 0 0 0 0 0	1 0 0 0 0 0 0 0	1 0 0 0 0 0 0 0	1 0 0 0 0 0 0 0								
# 02	0 0 0 0 0 1 0 0	00000100	0 0 0 0 0 1 0 0	00000100								
# 03	0 1 1 0 0 0 1 1	01100001	0 1 1 0 0 0 1 1	0 1 1 0 0 0 0 1								
# 04	00110000	00110000	00110000	00110000								
# 05	00010011	10010011	10010011	0 0 0 1 0 0 0 0								
# 06	1 1 1 1 0 0 1 0	1 1 1 1 0 0 1 0	1 1 1 1 0 0 1 0	1 1 1 1 0 0 1 0								
# 07	00010001	0 0 0 1 0 0 0 1	00010001	0 0 0 1 0 0 0 0								
# 08	00000111	0 0 0 0 1 1 1 1	00000111	10000110								
# 09	00101000	0 0 1 0 1 0 0 0	00101100	0 0 0 0 0 0 0 0								
# 10	1 1 1 1 0 1 0 1	1 1 1 1 0 1 0 1	1 1 1 1 0 1 1 1	10000101								
# 11	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	1 0 0 0 0 1 0 0	0 0 0 0 0 0 0 0								
# 12	0 0 0 0 0 0 0 1	0 0 0 0 1 0 0 1	0010001	00000001								
# 13	00001000	00010000	00101000	0 0 0 0 1 0 0 0								
# 14	0 1 0 0 0 0 0 0	0 1 0 0 0 0 0 0	0 1 0 0 0 1 0 0	0 1 0 0 0 0 0 0								
# 15	1 0 0 0 0 0 0 0	1 0 0 0 0 0 0 0	1 0 0 0 0 0 0 0	10000000								
# 16	1 1 0 0 0 0 0 0	1 1 0 0 0 0 0 0	1 1 0 0 0 0 0 0	1 1 0 0 0 0 0 0								
# 17	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0								
# 18	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0								
# 19	0 0 0 1 0 1 1 0	0 0 0 1 0 1 1 0	0 0 0 1 0 1 1 0	00010110								
# 20	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0								
# 21	00000011	00000001	00000011	00000011								
# 22	0 1 1 0 0 1 0 0	0 1 1 0 0 0 0 0	0 1 1 0 0 0 0 0	0 1 1 0 0 0 0 0								
# 23	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0								
# 24	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0								
# 25	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0								
# 26	0 0 0 1 0 1 0 0	0 0 0 1 0 1 0 0	0 0 0 1 0 1 0 0	00010100								
# 27	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0								
# 28	1 1 1 0 1 0 1 1	1 1 1 0 0 1 0 1	1 1 1 0 0 1 0 1	1 1 1 0 0 1 0 1								
# 29	00101000	0 0 1 0 1 0 0 0	00101000	00101000								
# 30	0 0 0 1 0 1 1 0	0 0 0 1 0 1 1 0	0 0 0 1 0 1 1 0	0 0 0 1 0 1 1 0								
# 31	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0								
# 32	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0								
# 33	0 0 0 1 1 0 1 0	00000010	00000010	00000010								
# 34	0 1 0 0 0 0 0 0	0 1 0 0 0 0 0 0	0 1 0 0 0 0 0 0	0 1 0 0 0 0 0 0								
# 35	00000101	00000101	00000101	00001001								
# 36	0 1 0 1 0 0 0 1	0 1 0 1 0 0 0 1	0 1 0 1 0 0 0 1	0 1 0 1 0 0 0 1								
# 37	0 0 0 0 0 0 0 0	000000000	000000000	0 0 0 0 0 0 0 0								

	Marketing area																															
Soft Austria										Ch	ina	l					G	err	nar	ny						Jap	ban	1				
switch No.				Bit	No						I	Bit	Nc						I	Зit	No				Bit No.							
	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8
# 38	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1
# 39	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
# 40	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 41	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 42	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 43	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 44	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 45	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 46	0	1	0	1	0	0	0	0	0	1	0	1	0	0	0	0	0	1	0	1	0	0	0	0	0	1	0	1	0	0	0	0
# 47	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 48	1	0	0	1	0	0	0	1	1	0	0	1	0	0	0	1	1	0	0	1	0	0	0	1	1	0	0	1	0	0	0	1
# 49	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
# 50	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 51	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 52	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 53	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 54	0	0	0	1	0	1	0	1	0	0	0	1	0	1	0	1	0	0	0	1	0	1	0	1	0	0	0	1	0	1	0	1
# 55	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 56	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 57	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 58	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 59	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 60	1	0	0	0	0	1	0	0	1	0	0	0	0	1	0	0	1	0	0	0	0	1	0	0	1	0	0	0	0	1	0	0
# 61	1	1	1	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	0	0
# 62	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 63	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1
# 64	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0

Adjustment / Setting

16.5	Default soft switch	setting for each	market area 3
------	---------------------	------------------	---------------

Soft switch No. Korea New Zealand South Africa Talwan Bit No. Bit No.			Marketing area	
Bit No. 1 2 3 4 5 6 7 8 1 0 0 0 0 0 0 0 1 0 0 0 0 0 0 0 0 0 0 0	Soft	Korea	New Zealand South Africa	Taiwan
$\begin{array}{ c c c c c c c c c c c c c c c c c c c$	switch No.	Bit No.	Bit No. Bit No.	Bit No.
#01 1 0		1 2 3 4 5 6 7 8	1 2 3 4 5 6 7 8 1 2 3 4 5 6 7 8	1 2 3 4 5 6 7 8
$\begin{array}{c c c c c c c c c c c c c c c c c c c $	# 01	1 0 0 0 0 0 0 0	1 0 0 0 0 0 0 0 1 0 0 0 0 0 0 0	1 0 0 0 0 0 0 0
$\begin{array}{c c c c c c c c c c c c c c c c c c c $	# 02	00000100	0 0 0 0 1 0 0 0 0 0 0 0 1 0 0	0 0 0 0 0 1 0 0
$\begin{array}{c c c c c c c c c c c c c c c c c c c $	# 03	0 1 1 0 0 0 0 1	0 1 1 0 0 0 1 1 0 1 1 0 0 0 0 1	0 1 1 0 0 0 0 1
$\begin{array}{c c c c c c c c c c c c c c c c c c c $	# 04	00110000	0 0 1 1 0 0 0 0 0 0 1 1 0 0 0 0	0 0 1 1 0 0 0 0
$\begin{array}{c c c c c c c c c c c c c c c c c c c $	# 05	1001000	0 0 0 1 0 1 1 1 0 0 0 1 0 0 0 0	0 1 0 1 0 0 0 0
	# 06	1 1 1 1 0 0 1 0	1 1 1 1 0 0 1 0 1 1 1 1 0 0 1 0	1 1 1 1 0 0 1 0
	# 07	0001000	0 0 0 1 0 0 0 1 0 1 0 1 0 0 0 0	0 0 0 1 0 0 0 0
	# 08	1 1 0 0 0 1 1 0	0 0 0 0 1 1 1 1 1 0 0 0 0 1 1 0	1 0 0 0 0 1 1 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 09	0 0 0 0 0 0 0 0	0 0 1 0 1 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0
# 11 0 <td># 10</td> <td>1 0 0 0 0 1 0 1</td> <td>1 1 1 1 0 1 1 1 1 0 0 0 0 1 0 1</td> <td>1 0 0 0 0 1 0 1</td>	# 10	1 0 0 0 0 1 0 1	1 1 1 1 0 1 1 1 1 0 0 0 0 1 0 1	1 0 0 0 0 1 0 1
# 12 0 0 0 0 1 0	# 11	0 0 0 0 0 0 0 0	0 0 0 0 0 1 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 12	00000001	0 0 0 0 1 0 0 1 0 0 0 0 0 0 1	0 0 0 0 0 0 0 1
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 13	0 0 0 0 1 0 0 0	0 0 0 0 1 0 0 0 0 0 0 0 1 0 0 0	0 0 0 0 1 0 0 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 14	0 1 0 0 0 0 0 0	0 1 0 0 0 0 0 0 0 1 0 0 0 0 0	0 1 0 0 0 0 0 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 15	1 0 0 0 0 0 0 0	1 0 0 0 0 0 0 0 1 0 0 0 0 0 0	1 0 0 0 0 0 0 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 16	1 1 0 0 0 0 0 0	1 1 0 0 0 0 0 0 1 1 0 0 0 0 0	1 1 0 0 0 0 0 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 17	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 18	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 19	0 0 0 1 0 1 1 0	0 0 0 1 0 1 1 0 0 1 0 1 0 1 1 0	1 1 0 1 0 1 1 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 20	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 21	0 0 0 0 0 0 0 1	0 0 0 0 0 0 1 1 0 0 0 0 0 0 1	0 0 0 0 0 0 1 1
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 22	0 1 1 0 0 0 0 0	0 1 1 0 0 0 0 0 0 1 1 0 0 0 0 0	0 1 1 0 0 0 0 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 23	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 24	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 25	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 26	00010100	0 0 0 1 0 1 0 0 0 0 0 1 0 1 0 0	0 0 0 1 0 1 0 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 27	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 28	1 1 1 0 0 1 0 1	1 1 1 0 0 1 0 1 1 1 1 0 0 1 0 1	1 1 1 0 0 1 0 1
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 29	00101000	0 0 1 0 1 0 0 0 0 0 1 0 1 0 0 0	0 0 1 0 1 0 0 0
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	# 30	0 0 0 1 0 1 1 0	0 0 0 1 0 1 1 0 0 0 0 1 0 1 1 1	0 0 0 1 0 1 1 0
# 32 0	# 31	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0
# 33 0 0 0 0 1 0 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 0 1 0	# 32	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0
# 34 0 1 0	# 33	00000010	0 0 0 0 0 0 1 0 0 0 0 0 0 1 0	0 0 0 0 0 0 1 0
# 35 0 0 0 1 0 0 0 1 0 1 0 0 0 1 0 1 0 0 0 1 0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0 1 0 0 1	# 34	0 1 0 0 0 0 0 0	0 1 0 0 0 0 0 0 0 1 0 0 0 0 0	0 1 0 0 0 0 0 0
# 36 0 1 0 0 1 1 0 0 1 0 1 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1 0 0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1 1 0 0 1 1 1 1	# 35	00001001	0 0 0 0 0 1 0 1 0 0 0 0 1 0 0 1	0 0 0 0 1 0 0 1
# 37 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	# 36	01010001	0 1 0 1 0 0 0 1 0 1 0 1 0 0 0 1	0 1 0 1 0 0 0 1
	# 37	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0

														Μ	ark	eti	ng	ar	ea													
Soft				Ko	rea	l				Ν	lev	٧Z	ea	lan	d			ę	δοι	uth	Af	rica	a					Taiv	var	٦		
switch No.			I	Bit	No						I	Bit	Nc).					I	Зit	No						I	Bit	No			
	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8
# 38	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1
# 39	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
# 40	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 41	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 42	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 43	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 44	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 45	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 46	0	1	0	1	0	0	0	0	0	1	0	1	0	0	0	0	0	1	0	1	0	0	0	0	0	1	0	1	0	0	0	0
# 47	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 48	1	0	0	1	0	0	0	1	1	0	0	1	0	0	0	1	1	0	0	1	0	0	0	1	1	0	0	1	0	0	0	1
# 49	1	0	0	0	0	0	0	0	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
# 50	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 51	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 52	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 53	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 54	0	0	0	1	0	1	0	1	0	0	0	1	0	1	0	1	0	0	0	1	0	1	0	1	0	0	0	1	0	1	0	1
# 55	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 56	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 57	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 58	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 59	1	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 60	1	0	0	0	0	1	0	0	1	0	0	0	0	1	0	0	1	0	0	0	0	1	0	0	1	0	0	0	0	1	0	0
# 61	1	1	1	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1	0	0	0	0
# 62	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
# 63	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1
# 64	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0	0

Adjustment / Setting

166	Dofault coft	ewitch	sotting	for	oach	markat	2102	л
10.0	Delault Solt	Switch	setting	101	each	market	area	4

		Μ	ark	eti	ng	ar	ea	
Soft			Si	nga	apo	ore		
switch No.			E	Bit	No			
	1	2	3	4	5	6	7	8
# 01	1	0	0	0	0	0	0	0
# 02	0	0	0	0	0	1	0	0
# 03	0	1	1	0	0	0	0	1
# 04	0	0	1	1	0	0	0	0
# 05	1	0	0	1	0	0	0	0
# 06	1	1	1	1	0	0	1	0
# 07	0	0	0	1	0	0	0	1
# 08	1	0	0	0	0	1	1	0
# 09	0	0	0	0	0	0	0	0
# 10	1	0	0	0	0	1	0	1
# 11	0	0	0	0	0	0	0	0
# 12	0	0	0	0	0	0	0	1
# 13	0	0	0	0	1	0	0	0
# 14	0	1	0	0	0	0	0	0
# 15	1	0	0	0	0	0	0	0
# 16	1	1	0	0	0	0	0	0
# 17	0	0	0	0	0	0	0	0
# 18	0	0	0	0	0	0	0	0
# 19	0	0	0	1	0	1	1	0
# 20	0	0	0	0	0	0	0	0
# 21	0	0	0	0	0	0	0	1
# 22	0	1	1	0	0	0	0	0
# 23	0	0	0	0	0	0	0	0
# 24	0	0	0	0	0	0	0	0
# 25	0	0	0	0	0	0	0	0
# 26	0	0	0	1	0	1	0	0
# 27	0	0	0	0	0	0	0	0
# 28	1	1	1	0	0	1	0	1
# 29	0	0	1	0	1	0	0	0
# 30	0	0	0	1	0	1	1	0
# 31	0	0	0	0	0	0	0	0
# 32	0	0	0	0	0	0	0	0

		М	ark	eti	ng	ar	ea	
Soft			Si	nga	арс	ore		
switch No.			E	Зit	No			
	1	2	3	4	5	6	7	8
# 33	0	0	0	0	0	0	1	0
# 34	0	1	0	0	0	0	0	0
# 35	0	0	0	0	0	1	0	1
# 36	0	1	0	1	0	0	0	1
# 37	0	0	0	0	0	0	0	0
# 38	1	0	0	0	0	1	1	1
# 39	1	0	0	0	0	0	0	0
# 40	0	0	0	0	0	0	0	0
# 41	0	0	0	0	0	0	0	0
# 42	0	0	0	0	0	0	0	0
# 43	0	0	0	0	0	0	0	0
# 44	0	0	0	0	0	0	0	0
# 45	0	0	0	0	0	0	0	0
# 46	0	1	0	1	0	0	0	0
# 47	0	0	0	0	0	0	0	0
# 48	1	0	0	1	0	0	0	1
# 49	1	0	0	0	0	0	0	0
# 50	0	0	0	0	0	0	0	0
# 51	0	0	0	0	0	0	0	0
# 52	0	0	0	0	0	0	0	0
# 53	0	0	0	0	0	0	0	0
# 54	0	0	0	1	0	1	0	1
# 55	0	0	0	0	0	0	0	0
# 56	0	0	0	0	0	0	0	0
# 57	0	0	0	0	0	0	0	0
# 58	0	0	0	0	0	0	0	0
# 59	0	0	0	0	0	0	0	0
# 60	1	0	0	0	0	1	0	0
# 61	1	1	1	1	0	0	0	0
	· · · ·	-	~	~	0	0	0	0
# 62	0	0	0	0	0	0	0	0
# 62 # 63	0 0	0 0	0	0	0	0	0	1

16.7 Soft switch list

Switch No.	Bit No.	Designation	Pa	ige No.
# 01	8	Detect CED or not after Dial	637	183
	2/1	V.34 CI signal byte number reserved		
# 02	8/7	Time between phase C to phase D signal in V.17	137	184
	6	Header TX selection open to user		
	3/2	Transmit RTN signal level criteria		
	1	Sent N.G page		
# 03	8	Send out NSF frame with station ID	137	185
	7	Number of pause within phone number		
	6	Re-dial prohibit for NO ANSWER		
	4/3/2/1	RX level setting		
# 04	4	Visible alarm for RTN signal	137	186
	3	Audible alarm or RTN signal		
	1	Polarity change detection		
# 05	8/7	Push Button on/off Timing (PB)	637	187
	6/5	Relation between dialed No. and No. of dial pulse		
	4/3/2/1	Dial pulse make ratio select (MR)		
# 06	8/7	Ring on time to ignore ring off time at 1st cycle	137	188
	4/3	Ring off time at 1 st. cycle to approve incoming ring		
# 07	8	Dial tone or busy tone detection	137	188
	7	PSTN/ PBX setting		
	6	PBX dial tone detect		
	5	Dial mode select		
	4/3/2/1	Tx level select for PSK/ FSK		
# 08	8	Sending RTN signal level	137	189
	7	Detect busy tone after dialing		
	6	Sending CED signal after connection		
	4/3/2/1	Redial interval		
# 09	8/7	Ringer frequency detection	137	190
	5	TSI/ CSI Append "+"		
	2/1	Time from RX DIS signal to send DCS signal		
# 10	8	Print out RTN page report	13	191
	7	Confirmation report result field		
	6/5	Get gap time between digit for pulse dial		
	4	RX PIP T.30 command after send out MPS command		
	3	Received DIS signal within reception		
	2	Transmission time limitation		
	1	Audio alarm after communication fail		
# 11	7	Detect dial tone after pre-fix number	637	192
	6	Pulse dial allowed to select		
	1	DTMF high frequency dB value		

16. Soft Switch Set (bizhub 160f/bizhub 161f only)

Switch No.	Bit No.	Designation	Pa	ge No.
# 12	8	ECM Mode capability	1 37	192
	7/6	V.34 fall back level for V.34 TX.		
	5	Send CTC after 4th PPR		
	3	Send EOR after lowest speed		
	2/1	TCF transmission timing after DCS		
# 13	8	MR capability for G3	13	193
	7/6	Delay time between transaction		
	5	Super fine printing capability for receiving		
	4	Disable ultra fine capability in RX mode		
	3	DTS mode (Der Telefax Standard)		
	2	Send DTC signal if RX DIS signal in polling RX mode		
# 14	6	Memory size level to RX	13	194
	3/2/1	Time between V.34 ANSam signal and FSK DIS signal		
# 15	1	Remote side no document to be polled	1 37	194
# 16	2/1	Fax communication coding method	1 37	195
# 17	6	CED frequency	1 37	195
	5/4/3	Pause between off hook and CED signal		
	2/1	Inactivity timer [T5]		
# 18	6/5	G3 mode training quality level	63	196
	4/3/2/1	Redefine re-dial attempts counter		
# 19	8/7/6/5	CNG signal level	1 37	197
	4/3/2/1	DTMF high frequency level		
# 20	5/4/3/2/1	Redefine redial interval	1 37	198
# 21	8	NSS signal before DCS	1 37	199
	7/6	CNG duration after dialing (T1)		
	5	T4 timer		
	3	DIS signal length		
	2/1	Increase default T1 timing during calling		
# 22	8	Detect busy tone before dial	1 37	200
	7	Regard dial tone as busy tone after dialing		
	6	Check busy tone method		
	4/3/2/1	CED signal output level		
# 23	-	Reserved	1 37	200
# 24	-	Reserved	1 37	201
# 25	4/3	Flash key time in ON hook key dial	1 37	201
# 26	8/7	Dial tone detection time before disconnected	1 37	202
	6/5/4/3/2/1	Dial tone insensitivity		
# 27	4/3/2/1	Immunity for dial tone receiver	r 37	203
# 28	8/7/6/5	Time to dial after dial tone on the line	13	204
# 29	5/4/3/2/1	Time to dial after size the line when dial tone detected	1 37	205

bizhub 160/160f bizhub 161/161f

Switch No.	Bit No.	Designation	Pa	ige No.
# 30	8/7	Pause delay time within digit	13	206
	6/5/4/3/2/1	Signal tone sensitivity after dial for busy tone		
# 31	-	Reserved	13	207
# 32	-	Reserved	13	207
# 33	7	V.17 echo protection tone	13	208
	6	V.29 echo protection tone		
	5	Compromise equalize enable (CEQ) in the transmit path (TCEQ)		
	4	Compromise equalize enable (CEQ) in the receiver path (RCEQ)		
# 34	-	Reserved	13	208
# 35	8/7	Dial tone table switch time	13	209
	6/5/4	Dial tone frequency upper range index		
	3/2/1	Dial tone frequency low range index		
# 36	8	Re-dial attempts continue fall counter	13	210
	4/3/2/1	Re-dial attempts fail limitation counter		
# 37	8	Polling TX type for V.34 modem	13	211
	7	Auto dial learning for V.34 modem		
	6/5/4	RX start symbol rate for V.34 modem		
	3/2/1	TX start symbol rate for V.34 modem		
# 38	8	Fine tone of 33.6 kbps/ 33.2 kbps receiving speed for V.34 modem	13	212
	7	Set/ reset V.34 transmit level deviation		
	6/5	V.34 flag number between ECM frame		
	4	Phase 2 guard tone power level (V.34)		
	2	Polling RX start speed		
	1	V.8/ V.34 capability		
# 39	8	Disable V.34 TX for V.34 modem	13	212
	7	Disable V.34 RX for V.34 modem		
	6/5	Flags number in ECM frame for V.34 modem		
	4	Manual TX mode for V.34 modem		
	3	Switch from V.17 to V.34 if DIS bit 6 set after received DIS		
	2/1	Delay time in primary channel for V.34 transmit after CFR or MCF signal		
# 40	8/7/6/5	V.17 RX start speed	13	213
	3/2/1	V.34 RX start speed		
# 41	8/7/6/5	V.17 TX start speed	13	214
	3/2/1	V.34 TX start speed		
# 42	-	Reserved	13	215
# 43	-	Reserved	13	215
# 44	-	Reserved	13	215
# 45	6	Closed network	13	216

16. Soft Switch Set (bizhub 160f/bizhub 161f only)

Switch No.	Bit No.	Designation	Pa	ge No.
# 46	8	Delight savings timer	13	216
	4	RX print		
	3	Default TX mode		
	2	Header for FAX TX		
	1	Print model name		
# 47	6	RX mode	D 37	217
	5	Footer		
# 48	8	Activity report	13	217
	7	Reservation report		
	6	TX result report		
	5	RX result report		
	4	TX/ RX error report		
	3	Error report for I-FAX and network scanner		
	2	Error mail (I-FAX)		
	1	Broadcast report		
# 49	6	Print RX mailbox report method	13	218
	5	Redial method if communication fail		
	4/3/2/1	No. of ring		
# 50	8	Transmit or cancel after time out in "Memory TX"	1 37	218
# 51	4/3	T30 monitor report selection	13	219
	2	Send "un-sent page mode" for memory transmission		
# 52	-	Reserved	13	219
# 53	-	Reserved	13	220
# 54	8	Report/ LCD date/ time type	13	220
	7/6	Report/ LCD date/ time format		
	5/4	Memory near full capacity for black/ white scanning		
	3/2	Memory near full capacity for color/gray scanning		
# 55	-	Reserved	13	221
# 56	-	Reserved	13	221
# 57	-	Reserved	13	221
# 58	8	Time out from OSK to FSK delay time	13	222
# 59	6/5/4/3/2/1	Time between GMT (Greenwich Mean Time)	13	223
# 60	6	Quick memory TX	13	226
	3	Print mailbox RX image even if password is not correct		
	2	Off hook alarm after communication		
	1	Display destination selection within TX phase C		
# 61	4/3/2/1	Max. No. of ring	13	226
# 62	-	Reserved	13	227
# 63	8	# key definition in PBX mode	13	227
	1	TX result report with image		

Switch	Bit No.	Designation	Page No.
No.			
# 64	6	Print RX error report on RX side if no FAX signal is detected	I® 228
	5	10 pps & 20 pps selectable by user	

16.8 Soft switch definition

16.8.1 SOFT SWITCH: #01

Bit No.	Designation		Function								
8	Detect CED or not after	0: Detect CED	: Detect CED after dial								
	Dial	1: Not detect (Not detect CED after dial								
7	Reserved	Reserved	leserved								
6	Reserved	Reserved	Reserved								
5	Reserved	Reserved	Reserved								
4	Reserved	Reserved					0	1			
3	Reserved	Reserved					0				
2	V.34 CI signal byte num-	Byte					0				
1	ber reserved	number	30 bytes	9 bytes	15 bytes	60 bytes	1				
		Bit 2 0 0 1 1									
		Bit 1	Bit 1 0 1 0 1								
16.8.2 SOFT SWITCH: #02

Bit No.	Designation			lr Se	iitial etting						
							Bit	HEX			
8	Time between phase C	BX Insensitivity	70 ms	120 ms	180 ms	60 ms	0	2			
7	to phase D signal in	Bit 8	0	0	1	1	0				
	V.17	Bit 7	0	1	0	1					
	Example: Image> EOP										
6	Header TX selection open to user	0: No 1: Yes	D: No 1: Yes								
5	Reserved	Reserved					0				
4	Reserved	Reserved					0	0			
3	Transmit RTN signal	Porcontago of					0				
2	level criteria	error line	10 %	15 %	20 %	25 %	0				
		Bit 3	0	0	1	1					
		Bit 2	0	1	0	1					
1	Sent N.G page	0: Send N.G page 1: Not re-send that	0								

- Bit 1 :If this bit is set to '0', N.G indicates our side detected RTN signal from other end. In this case machine can re-send the same page up to three or just one time, and this use for G3 mode only.
- Bit 2 to 3 :In G3 mode, if error line for each page meets the criteria setting, receiving machine will send RTN signal, in this case, some machine will re-send the same page again. The retry times depend on transmission side.
- Bit 6 :If this bit is set to '0', the header select function can not be changed by user, only changeable by serviceman in service mode.

16.8.3 SOFT SWITCH: #03

Bit No.	Designation		Function									
										Bit	HEX	
8	Send out NSF frame with station ID	1: Yes 0: No								1	8	
7	Number of pause within phone number	0: No limitation 1: Max. up to 2	on 2 "P" v	vithin i	nputte	d tele	ohone	numb	er	0		
6	Re-dial prohibit for NO ANSWER	0: Continue t 1: Not allowed busy tone a	: Continue to dial : Not allowed to re-dial if no any FAX signal or detecte busy tone after dialing									
5	Reserved	Reserved	leserved									
4	RX level setting	RX level (dB)	RX level -49 -48 -47 -46 -45 -44 -43 (dB)									
2		Bit 4	Bit 4 0 0 0 0 0 0 0 0									
1	•	Bit 3	Bit 3 0 0 0 0 1 1									
		Bit 2	0	0	1	1	0	0	1	Ŭ		
		Bit 1	0	1	0	1	0	1	0			
		RX level (dB)	-42	-41	-40	-39	-38	-37	-36			
		Bit 4	0	1	1	1	1	1	1			
		Bit 3	1	0	0	0	0	1	1			
		Bit 2	1	0	0	1	1	0	0			
		Bit 1	1	0	1	0	1	0	1			
		RX level (dB)	RX level (dB) Reserved									
		Bit 4	1	1								
		Bit 3	1	1								
		Bit 2	1	1								
		Bit 1	0	1								

- Bit 8 :If this bit is set to 1, the answer machine will send the machine name (which is that set in INITIAL USER DATA of Utility Mode) by NSF frame after connection.
- Bit7 :Can input Pause key to insert pause time between digits, this can put more than one "P" at the end of access telephone number during calling to other parties by using PBX system.

16.8.4 SOFT SWITCH: #04

Bit No.	Designation	Function	lr Se	nitial etting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Visible alarm for RTN signal	0: No 1: Yes - display message while sending / receiving RTN signal (RTN= Return To Negative).	1	С
3	Audible alarm for RTN signal	0: No 1: Yes - alarm for sending or receiving RTN signal.	1	
2	Reserved	Reserved	0	
1	Polarity change detection	0: Not to detect phase reverse during dialing & calling 1: Detect line phase reverse during dialing & calling	0	

• Bit 3: The alarm lasts for 3 seconds after a negative signal is detected in G3 mode.

• Bit 4: The display message will stay put on the LCD for 3 seconds or until next incoming T30 signal.

16.8.5 SOFT SWITCH: #05

Bit No.	Designation	Function									Initial Setting	
											Bit	HEX
8	Push button on/off	Timing		NI	10	o I -	70	70		00	0	0
7	timing (PB)	(ms)	0	FF	14		70	140)	90	0	
		B	it 8		0		0	1	,	1		
		В	it 7		0		1	0		1		
6	Relation between						-	_	1		0	
5	dialed No. and No. of		# 1	1		2	_	9			0	
J	dial pulse		# 2	3		4	-	0 7			Ŭ	
		-	# 4	4		5		6				
			# 5	5		6		5	Dee	o ru co d		
			# 6	6	i	7		4	Res	erved		
			# 7	7	'	8		3				
			# 8	8		9	_	2				
			# 9	9		10	_	1				
		Bit 6	# U)	0		1		1		
		Bit 5	5	0)	1		0		1		
4	Dial pulse make ratio	PPS	20	20	20	Reser	16	16	16	Reser	1	А
3	SEIECT (IMIR)	MR(%)	33	40	30	ved	33	40	30	ved	0	
2		Bit 4	0	0	0	0	0	0	0	0	1	
1		Bit 3	0	0	0	0	1	1	1	1	0	
		Bit 1	0	1	0	1	0	1	0	1		
		Dit i	U	•	U		U		0			
		PPS	10	10	10	10		Res	erved			
		MK(%)	33	40	30	32	1	1	1	1		
		Bit 3	0	0	0	0	1	1	1	1		
		Bit 2	0	0	1	1	0	0	1	1		
		Bit 1	0	1	0	1	0	1	0	1		
1											1	

16.8.6 SOFT SWITCH: #06

Bit No.	Designation		Function								
								Bit	HEX		
8	Ring on time to	Time (ms)		50	100	150	800	0	4		
7	ignore ring off time at	Bit 8		0	0	1	1	1			
]	TSt cycle	Bit 7		0	1	0	1				
6	Reserved	Reserved	Reserved								
5	Reserved	Reserved						0			
4	Ring off time at 1st.		100				1000	1	F		
	cycle to approve	Time (ms)	100	23	50 5	000	1000				
3	incoming ring	Bit 4	0	Τ (0	1	1	1			
	incoming mag	Bit 3	0		1	0	1				
		-									
2	Reserved	Reserved						1			
1	Reserved	Reserved	1								

16.8.7 SOFT SWITCH: #07

Bit No.	Designation	Function										nitial etting
											Bit	HEX
8	Dial tone or busy tone detection	0: Disable 1: Enable - Detect	dial t	one l	befor	e dia	l				0	0
7	PSTN/PBX setting	0: PSTN 1: PBX - Select PB	X lin	e typ	e						0	
6	PBX dial tone detect	0: Not to detect d 1: Detect dial tone mode	: Not to detect dial tone before pre-fix number : Detect dial tone before the pre-fix number in PBX mode									
5	Dial mode select	0: DTMF - PB 1: Pulse - DP	: DTMF - PB : Pulse - DP									
4	Tx level select for	Level (dBm)	-17	-16	-15	-14	-13	-12	-11	-10	1	8
3	PSK/FSK	Bit 4	0	0	0	0	0	0	0	0	0	
2		Bit 3	0	0	0	0	1	1	1	1	0	
1		Bit 2	0	0	1	1	0	0	1	1	0	
		Bit 1	0	1	0	1	0	1	0	1		
		Level (dBm)	-9	-8	-7	-6	-5	-4	-3	-2		
		Bit 4	Bit 4 1 <td></td>									
		Bit 3 0 0 0 0 1 1 1 1								1		
		Bit 2	0	0	1	1	0	0	1	1		
		Bit 1 0 1 0 1 0 1 0 1										

16.8.8 SOFT SWITCH: #08

Bit No.	Designation			l S	nitial etting								
											Bit	HEX	
8	Sending RTN signal level	0: (Normal, Fine)= 1: (Normal, Fine)=	:(12,) (6,12	24) c) cor	ontii ntinue	nue e erro	error or line	line ;			0	6	
7	Detect busy tone after dialing	0: Not to detect 1: Detect busy tor	ne af	ter d	lialin	g					1		
6	Sending CED signal After connection	0: Not to send 1: Send CED sign tion	ec-	1									
5	Reserved	Reserved	Reserved										
4	Redial Interval	Auto dial	1,	3,	1,	З,	1,	З,	1,	З,	0	1	
3		interval	1,	3,	1,	3.	1,	З,	1.	З,	0		
2			1,	15,	15.		1.	3.		3,	0		
1			1,	3.						5.	1		
			10,										
			1.										
		Bit 4	0	0	0	0	0	0	0	0			
		Bit 3	0	0	0	0	1	1	1	1			
		Bit 2	0	0	1	1	0	0	1	1			
		BIT 1	0	1	0	1	0	1	0	1			
		Auto dial	1,	2,	5,	1,	2,	2,	3,	10,			
		Interval	1, 1	2.	5, 5	2,	2,	2,	3,	10,			
			1.		5.	2,	2,	2.	3.	10,			
					-		2,	2,	З,	15,			
							2,	2.	З,	10.			
							2,		3.				
							2,						
							2,						
		Bit 4	1	1	1	1	1	1	1	1			
		Bit 3	0	0	0	0	1	1	1	1			
		Bit 2	0	0	1	1	0	0	1	1			
		Bit 1	0	1	0	1	0	1	0	1			

• Bit 8: If error line above definition, machine will send RTN signal instead of MCF signal. This will cause the other party to send the same page again.

16.8.9 SOFT SWITCH: #09

Bit No.	Designation			lı Se	nitial etting			
							Bit	HEX
8	Ringer frequency	Binger					0	0
7	detection	frequency range (Hz)	10 to 75 Hz	20 to 57.5	20 to 75 Hz	10 to 75 Hz	0	
		Bit 8	0	0	1	1		
		Bit 7	0	1	0	1		
6	Reserved	Reserved					0	
5	TSI/CSI append "+"	0: Not append ' 1: Automatically	"+" before insert "+"	send ou	t TSI/CSI		0	
4	Reserved	Reserved					0	0
3	Reserved	Reserved					0	
2	Time from RX DIS	Description (n	0					
1	signal to send DCS	Bit 2	0	0	1	1	0	
	Signai	Bit 1	0	1	0	1		
			-					

• Bit 5: When this bit is set to "1", the "+" character will be placed in the first position on CSI and TSI command.

16.8.10 SOFT SWITCH: #10

Bit No.	Designation		Function									
							Bit	HEX				
8	Print out RTN page report	0: Not to Print 1: Print Out RT RX RTN sigr	'N page re nal	port after	transacti	on for TX/	1	A				
7	Confirmation report result field	0: Print "OK" 1: Print "NG" in	: Print "OK" : Print "NG" in case of sending or receiving RTN signal									
6	Get gap time	Value (ms)	Value (ms) 550 650 750 850									
5	between digit for	Bit 6 0 0 1 1										
		Bit 5	0	1	0	1						
4	RX PIP T.30 com- mand after send out MPS command	0: Send DCS a 1: Return to Tx	t current s phase B w	peed aiting for D)IS signal		0	1				
3	Received DIS signal within reception	0: Repeat send 1: Disconnected	ling DIS/D	TC again ding DCN s	until time signal	out	0					
2	Transmission time limitation	0: No any limit 1: Limit to 8 mir		0								
1	Audio alarm after communication fail	0: Not to alarm 1: Alarm 3 sec		1								

- Bit 8: If this bit set to 1, machine will print out confirmation report after each transaction for TX/RX RTN signal.
- Bit 7: If this bit is set to1, the result field will show "NG" instead of "OK" in the confirmation report and activity report or checking the result on the LCD.
- Bit 2: For Manual Tx only.

16.8.11 SOFT SWITCH: #11

Bit No.	Designation	Function	li S⁄	nitial etting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Detect dial tone after pre-fix number	0: No 1: Yes	0	
6	Pulse dial allowed to select	0: Yes 1: Not allowed	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	DTMF high fre- quency dB value	0: Base on SW19 (1 to 4) 1: High 1dB	0	

- Bit 6: If this bit is set to 1, not allowed user to select Pulse dial, and this function open for serviceman to change.
- Bit 7: Bit set to 1, LCD will show the command between each party.

16.8.12 SOFT SWITCH: #12

Bit No.	Designation		Function								
								Bit	HEX		
8	ECM mode capabil- ity	1: Yes 0: No - also disat	I: Yes): No - also disable V.34 modem capability								
7	V.34 fall back level	Counter	0								
6	for V.34 TX.	Bit 7	Counter 1 2 3 4 Bit 7 0 0 1 1								
		Bit 6	0	1		0	1				
5	Send CTC after 4th PPR	0: Send CTC (Co 1: Send EOR (Er	D: Send CTC (Continue To Correct) 1: Send EOR (End Of Transmission)								
4	Reserved	Reserved						0	0		
3	Send EOR after low- est speed	0: Send DCN (Re 1: Send EOR_xx	edial) x (Germa	ny PT	T)			0			
2	TCF transmission	Description (m	s) 70		80	90	100	0			
1	timing after DCS	Bit 2	0								
		Bit 1									

- Bit 1 to 2: Delay time from FSK mode to PSK mode, this is used for G3 mode only, V.34 does not need this setting.
- Bit 6 to 7: If level reads "1", machine. Will go down to next lower speed for next data phase.

16.8.13 SOFT SWITCH: #13

Bit No.	Designation			li Se	nitial etting			
							Bit	HEX
8	MR capability for G3	0: Yes 1: No					0	1
7	Delay time between	Description (see)	0					
6	transaction		20	00	120	240	0	
-		Bil 7	0	0	1	1	-	
		Bit 6	0	1	0	1		
5	Super fine printing capability for receiv- ing	0: No. 1: Yes					1	
4	Disable ultra fine capability in RX mode	0: No. 1: Yes					0	0
3	DTS mode (Der Telefax Stan- dard)	0: No 1: Yes					0	
2	Send DTC signal if RX DIS signal in polling RX mode	1: No -send DIS ag 0: Yes	Jain				0	
1	Reserved	Reserved					0	

- Bit 7 to 6:If set to 1, the time between each transaction will become longer, in this case machine will wait more time before start to dial next transaction.
- Bit 4 :The resolution definition:
 - Standard R8 x 3.85 lines/mm
 - Fine R8 x 7.7 lines/mm
 - Super fine R8 x 15.4 line/mm,
 - Ultra fine R8 x 15.4 lines/mm.

16.8.14 SOFT SWITCH: #14

bizhub 160/160f bizhub 161/161f

Bit No.	Designation			lı Se	nitial etting								
											Bit	HEX	
8	Reserved	Reserved	leserved										
7	Reserved	Reserved									0		
6	Memory size level To RX	1: Up to 128 KE 0: Based on sy	Up to 128 KB Based on system configuration										
5	Reserved	Reserved									0		
4	Reserved	Reserved									0	2	
3	Time between V.34	Timer (ms)	50	60	70	80	100	120	140	160	0		
2	ANSam signal and	Bit 3	0	0	0	0	1	1	1	1	1		
1	I SK DIS Signal	Bit 2	0	0	1	1	0	0	1	1	0		
		Bit 1	0	1	0	1	0	1	0	1			

 Bit 6: If set to 1, machine will become manual RX mode if available memory size less than 128 K (manual RX mode: Press "Speaker" key and "Start" key, then machine can start receiving).

16.8.15 SOFT SWITCH: #15

Bit No.	Designation	Function	lı Se	nitial etting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	1
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Remote side no doc- ument to be polled	0: Not to generate error report document to be polled 1: Generate error report after communication end	1	

16.8.16 SOFT SWITCH: #16

Bit No.	Designation		Function											
							Bit	HEX						
8	Reserved	Reserved					0	0						
7	Reserved	Reserved					0	1						
6	Reserved	Reserved					0	1						
5	Reserved	Reserved					0	1						
4	Reserved	Reserved					0	3						
3	Reserved	Reserved					0	1						
2	Fax communication			1			1	1						
1	coding method	Coding method	MMR	MR	MH	JBIG	1							
		Bit 2	0	0	1	1								
		Bit 1	0	1	0	1								
			•	•										

16.8.17 SOFT SWITCH: #17

Bit No.	Designation				Fund	ctio	n		lı Se	nitial etting				
									Bit	HEX				
8	Reserved	Reserv	red						0	0				
7	Reserved	Reserv	eserved											
6	CED frequency	0: 210 1: 1100	: 2100 Hz : 1100 Hz											
5	Pause between off	Time	1.8 s	ес					0					
4	hook and CED sig-	(T=)	to 2.5	sec	T+ 100 r	ns	T+ 200 ms	s T+ 300 ms	0	0				
3	nai	Bit 5	0		0		0	0	0					
		Bit 4	0		0		1	1						
		Bit 3	0		1		0	1						
		Time (T=)	T+ 400	ms	T+ 500 r	ns	T+ 600 ms	s T+ 700 ms						
		Bit 5	1		1		1	1						
		Bit 4	0		0		1	1						
		Bit 3	0		1		0	1						
	1								_					
2	Inactivity timer [15]	Desc tior	n T5	Т5	+ 20 sec	T٤	5 + 40 sec	T5 + 60 sec	0					
		Bit	2 0		0		1 1							
		Bit	1 0		1 0 1									

• T5: 60 ± 5 sec in ITU-T standard

16.8.18 SOFT SWITCH: #18

Bit No.	Designation		Function												
														Bit	HEX
8	Reserved	Reserved	Reserved												
7	Reserved	Reserved												0	
6	G3 mode training	Definitio	n		Le	vel1	L	_eve	2	Leve	el3	Lev	/el4	0	
5	quality level	Bit 6				0		0		1			1	0	
		Bit 5				0		1		0			1		
4	Redefine re-dial	Counter	0	1	2	3	4	5	6	7	8	9	10	0	0
3	attempts counter	Bit 4	0	0	0	0	0	0	0	0	1	1	1	0	
2		Bit 3	0	0	0	0	1	1	1	1	0	0	0	0	
1		Bit 2	0	0	1	1	0	0	1	1	0	0	1	0	
		Bit 1	0	1	0	1	0	1	0	1	0	1	0		
		Counter		Re	serv	/ed		1							
		Bit 4	1	1	1	1	1								
		Bit 3	0	1	1	1	1								
		Bit 2	1	0	0	1	1								
		Bit 1	1	0	1	0	1	J							

- Bit 1 to 4:The redial attempt times will follow bit 1 to 4, if these bits are not all setting "0." Otherwise the redial attempt times will follow bit 1 to 4 on SW08.
- Bit 5 to 6:Level 4 training check phases is most severe than level 3, 2, 1. Level 4 can keep lowest RX speed communication than level 3, 2, 1 when poor line condition.

16.8.19 SOFT SWITCH: #19

Bit No.	Designation	Function	lı Se	nitial etting
			Bit	HEX
8	CNG signal level	Level (dBm) -17 -16 -15 -14 -13 -12 -11 -10	0	6
7		Bit 8 0 0 0 0 0 0 0 0 0	1	
6		Bit 7 0 0 0 0 1 1 1 1	1	
5		Bit 6 0 0 1 1 0 0 1 1	0	
-		Bit 5 0 1 0 1 0 1 0 1 0 1		
		Level (dBm) -9 -8 -7 -6 -5 -4 -3 -2		
		Bit 8 1 1 1 1 1 1 1 1 1		
		Bit 7 0 0 0 0 1 1 1 1		
		Bit 6 0 0 1 1 0 0 1 1		
		Bit 5 0 1 0 1 0 1 0 1		
4	DTME bigh fro		1	0
4	guency level	Level (dBm) -17 -16 -15 -14 -13 -12 -11 -10		0
3		Bit 4 0 0 0 0 0 0 0 0 0	0	
2		Bit 3 0 0 0 0 1 1 1 1	0	
1		Bit 2 0 0 1 1 0 0 1 1	0	
		Bit 1 0 1 0 1 0 1 0 1		
		Level (dBm) -9 -8 -7 -6 -5 -4 -3 -2		
		Bit 4 1 1 1 1 1 1 1 1		
		Bit 3 0 0 0 1 1 1 1		
		Bit 2 0 0 1 1 0 0 1 1		
		Bit 1 0 1 0 1 0 1 0 1		

Adjustment / Setting

16.8.20 SOFT SWITCH: #20

Bit No.	Designation		Function												l S	nitial etting
															Bit	HEX
8	Reserved	Reserved													0	0
7	Reserved	Reserved													0	
6	Reserved	Reserved	Reserved												0	
5	Redefine redial	Interval (min)	0	1	2	3	4	5	6	7	8	9	10	11	0	
4	interval	Bit 5	0	0	0	0	0	0	0	0	0	0	0	0	0	0
3	Redefine redial	Bit 4	0	0	0	0	0	0	0	0	1	1	1	1	0	
2	interval over default	Bit 3	0	0	0	0	1	1	1	1	0	0	0	0	0	
1	setting that is based	Bit 2	0	0	1	1	0	0	1	1	0	0	1	1	0	
•	on soft SW #08 bit 1	Bit 1	0	1	0	1	0	1	0	1	0	1	0	1	Ŭ	
	to 4	later (al (min)	10		10	14	14	c 1.	10	17	1.4	<u>.</u>	10	00		
		Interval (min)	12	-	13	14	1	5	10	17	10	5	19	20		
		Bit 5	0		0	0	U U	,	1	1			1	1		
		Bit 4	1		1	1	1		0	0	0)	0	0		
		Bit 3	1		1	1	1		0	0	0)	0	1		
		Bit 2	0		0	1	1		0	0	1		1	0		
		Bit 1	0		1	0	1		0	1	0)	1	0		
		Interval (min)					Re	ser	vec	ł						
		Bit 5	1	1	1	1	1	1	1	1	1	1	1			
		Bit 4	0	0	0	1	1	1	1	1	1	1	1			
		Bit 3	1	1	1	0	0	0	0	1	1	1	1			
		Bit 2	0	1	1	0	0	1	1	0	0	1	1			
		Bit 1	1	0	1	0	1	0	1	0	1	0	1			

16.8.21 SOFT SWITCH: #21

Bit No.	Designation			l S	nitial etting										
8	NSS signal before DCS	0: Not to send NSS 1: Send NSS signa	e model nodel	1	С										
7	CNG duration after	Duration (sec)	40	60	70	120	1								
6	dialing(T1)	Bit 7	0	0	1	1	0								
		Bit 6	0	1	0	1									
5	T4 timer	0: 3.0 sec – Norma 1: 4.5 sec	I case				0								
4	Reserved	Reserved					0	0							
3	DIS signal length	0: Normal length (1: 4 bytes DIS com	bit 1 to (mand – t	54) pit 1 to 32	only		0								
2	Increase default T1	Description (sec)	T1	T1+ 30	T1+ 40	T1+60	0								
1	timing during calling	Bit 7	0	0	1	1	0								
		Bit 6													

- Bit 1 to 2:T1 indicates the calling time after dialing, can adjust the T1 time longer by changing the default value. The default T1 timer depends on each country regulation.
- Bit 3 :Some old machines can not accept DIS command over 4 bytes, and every time will become fail. In this case you can set this bit to 1. If this bit is set to 1, JBIG and V8 capability will be disabled automatically.
- Bit 6 to 7:A fax to be received is cancelled and the machine becomes unable to receive it if the setting of "No. of RINGS" is made longer than the setting of "CNG duration after dialing." Be sure to make the "No. of RINGS" setting to a value shorter than the "CNG duration after dialing" setting.
 Image: Utility Mode/ RX operation/ No. of RINGS
- Bit 8 :Sender machine's name will show on the other party's LCD or print on the report if remote side is the same model.

16.8.22 SOFT SWITCH: #22

Bit No.	Designation			l S	nitial etting							
											Bit	HEX
8	Detect busy tone before dial	1: Check busy tone wit 0: Not to check		0	0							
7	Regard dial tone as busy tone after dialing	1: Yes - Check dial ton 0: No	e aft	er d	ialin	g					0	
6	Check busy tone method	0: Measure tone by in 1: By PTT regulation to	n put one f	ene requ	e rgy uenc	ovei y	r thr	esho	old		0	
5	Reserved	Reserved									0	
4	CED signal output	Level (dBm)	-17	-16	-15	-14	-13	-12	-11	-10	0	6
3	level	Bit 4	0	0	0	0	0	0	0	0	1	
2		Bit 3	0	0	0	0	1	1	1	1	1	
1		Bit 2	0	0	1	1	0	0	1	1	0	
		Bit 1	0	1	0	1	0	1	0	1		
		Level (dBm)	-9	-8	-7	-6	-5	-4	-3	-2		
		Bit 4	1	1	1	1	1	1	1	1		
		Bit 3	0	0	0	0	1	1	1	1		
		Bit 2	0	0	1	1	0	0	1	1		
		Bit 1	0	1	0	1	0	1	0	1		

16.8.23 SOFT SWITCH: #23

Bit No.	Designation	Function	l S	nitial etting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	

16.8.24 SOFT SWITCH: #24

Bit No.	Designation	Function	ו s	nitial etting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	

16.8.25 SOFT SWITCH: #25

Bit No.	Designation			l S	nitial etting			
							Bit	HEX
8	Reserved	Reserved					0	0
7	Reserved	Reserved					0	
6	Reserved	Reserved					0	
5	Reserved	Reserved					0	
4	Flash key time in ON	Flash time (ms)	100	80	60	50	0	0
3	hook key dial	Bit 4	0	0	1	1	0	
		Bit 3	0	1	0	1		
2	Reserved	Reserved					0	
1	Reserved	Reserved					0	

16.8.26 SOFT SWITCH: #26

bizhub 160/160f bizhub 161/161f

Adjustment / Setting

Bit No.	Designation	Function											In Se	itial tting	
														Bit	HEX
8	Dial tone detection time	Time (se	c)	1	10	T		15		20	T	21	5	0	2
7	before disconnected	Bit 8	0)		0			0		1	_	1	,	0	
		Bit 7			0			1	-	0		1			
					-										
6	Dial tone insensitivity	Level	0	4	2	0		6	6	7	0	0	10	1	
5	(0 dBm to -40 dBm)	(dBm)	0	-1	-2	-3	-4		-0	-7	-0	-9	-10	0	
4		Bit 6	0	0	0	0	0	0	0	0	0	0	0	1	8
3		Bit 5	0	0	0	0	0	0	0	0	0	0	0	0	
2		Bit 4	0	0	0	0	0	0	0	0	1	1	1	0	
1		Bit 3	0	0	0	0	1	1	1	1	0	0	0	0	
		Bit 1	0	1	0	1	0	1	0	1	0	1	0	-	
		Dit i	0		0		0		0		0		0		
		Level (dBm)	-11	-12	-1:	3 -	14	-15	-16	-17	-18	-19	-20		
		Bit 6	0	0	0	(0	0	0	0	0	0	0		
		Bit 5	0	0	0	(0	0	1	1	1	1	1		
		Bit 4	1	1	1		1	1	0	0	0	0	0		
		Bit 3	0	1	1	_	1	1	0	0	0	0	1		
		Bit 2	1	0	0		1	1	0	0	1	1	0		
		DILI	I	U			0	I	0	I	U	I	0		
		Level (dBm)	-21	-22	-23	3 -2	24	-25	-26	-27	-28	-29	-30		
		Bit 6	0	0	0	(0	0	0	0	0	0	0		
		Bit 5	1	1	1		1	1	1	1	1	1	1		
		Bit 4	0	0	0		1	1	1	1	1	1	1		
		Bit 3	1	1	1	(0	0	0	0	1	1	1		
		Bit 2	0	1	1	(0	0	1	1	0	0	1		
		BIT	I	0			0	I	0	I	0	I	0		
		Level (dBm)	-31	-32	-33	3 -3	34	-35	-36	-37	-38	-39	-40		
		Bit 6	0	1	1		1	1	1	1	1	1	1		
		Bit 5	1	0	0	(0	0	0	0	0	0	0		
		Bit 4	1	0	0	(0	0	0	0	0	0	1		
		Bit 3	1	0	0	(0	0	1	1	1	1	0		
		Bit 2	1	0	0		1	1	0	0	1	1	0		
			1	U	<u> </u>	1	U	I	U	I	U	I	U		
		Level					-4	41 ta	-50)					
		(dBm)													
		Bit 1 to 6 Setting disable													

16.8.27 SOFT SWITCH: #27

Bit No.	Designation	Function										itial tting
											Bit	HEX
8	Reserved	Reserved									0	0
7	Reserved	Reserved									0	
6	Reserved	Reserved									0	
5	Reserved	Reserved									0	
4	Immunity for dial	Level (dBm)	0	-1	-2	-3	-4	-5	-6	-7	0	0
3	tone receiver	Bit 4	0	0	0	0	0	0	0	0	0	
2		Bit 3	0	0	0	0	1	1	1	1	0	
1		Bit 2	0	0	1	1	0	0	1	1	0	
		Bit 1	0	1	0	1	0	1	0	1		
		Level (dBm)	-8	-9	-10	-11	-12	-13	-14	-15		
		Bit 4	1	1	1	1	1	1	1	1		
		Bit 3	0	0	0	0	1	1	1	1		
		Bit 2	0	0	1	1	0	0	1	1		
		Bit 1	0	1	0	1	0	1	0	1		

• Bit 1 to 4:Line input energy must be lower this level before dialing.

16.8.28 SOFT SWITCH: #28

Bit No.	Designation	Function										itial etting
											Bit	HEX
8	Time to dial after dial	Time (sec)	0	0.1	0.2	0.3	0.4	0.5	0.6	0.7	1	А
7	tone on the line	Bit 8	0	0	0	0	0	0	0	0	0	
6		Bit 7	0	0	0	0	1	1	1	1	1	
5		Bit 6	0	0	1	1	0	0	1	1	0	
		Bit 5	0	1	0	1	0	1	0	1		
		Time (sec)	0.8	0.9	1	1.	1 1	1.2	1.3	1		
		Bit 8	1	1	1	1		1	1			
		Bit 7	0	0	0	0		1	1			
		Bit 6	0	0	1	1		0	0			
		Bit 5	0	1	0	1		0	1			
		Time (sec)	1.4	1.	5							
		Bit 8	1	1								
		Bit 7	1	1								
		Bit 6	1	1								
		Bit 5	0	1								
4	Reserved	Reserved									0	7
3	Reserved	Reserved									1	
2	Reserved	Reserved									1	
1	Reserved	Reserved									1	

16.8.29 SOFT SWITCH: #29

Bit No.	Designation	Function										In Se	itial tting	
													Bit	HEX
8	Reserved	Reserved											0	1
7	Reserved	Reserved											0	
6	Reserved	Reserved											0	
5	Time to dial after size	Time	_	0.0	0.4	0.0	0.0	1.0	1.0	4.4	1.0	1 0	1	
4	the line when dial tone	(sec)	U	0.2	0.4	0.0	0.0	1.0	1.2	1.4	1.0	1.0	0	4
3	(Unit = 200 ms)	Bit 5	0	0	0	0	0	0	0	0	0	0	1	
2	(,	Bit 4	0	0	0	0	0	0	0	0	1	1	0	
1		Bit 2	0	0	1	1	0	0	1	1	0	0	0	
		Bit 1	0	1	0	1	0	1	0	1	0	1		
		Dit i	v		U	<u> </u>	v		Ŭ	<u> </u>	U	<u> </u>		
		Time	2.0	2.2	2.4	2.6	2.8	3.0	3.2	3.4	3.6	3.8		
		(SeC)	0	0	0	0	0	0	4	4	1	1		
		Bit 4	1	1	1	1	1	1	0	0	0	1		
		Bit 3	0	0	1	1	1	1	0	0	0	0		
		Bit 2	1	1	0	0	1	1	0	0	1	1		
		Bit 1	0	1	0	1	0	1	0	1	0	1		
		L												
		Time (sec)	4.0	4.2	4.4	4.6	4.8	5.0	5.2	5.4	5.6	5.8		
		Bit 5	1	1	1	1	1	1	1	1	1	1		
		Bit 4	0	0	0	0	1	1	1	1	1	1		
		Bit 3	1	1	1	1	0	0	0	0	1	1		
		Bit 2	0	0	1	1	0	0	1	1	0	0		
		Bit 1	0	1	0	1	0	1	0	1	0	1		
		Time (sec)	6.0	6.2										
		Bit 5	1	1	1									
		Bit 4	1	1										
		Bit 3	1	1										
		Bit 2	1	1										
		Bit 1	0	1										
1													Ì	1

16.8.30 SOFT SWITCH: #30

Bit No.	Designation	Function										In Se	itial tting		
														Bit	HEX
8	Pause delay time within	Time (se	c)	1	2.0		1	2.5		3.0)	3	.5	0	6
7	digits	Bit 8	,		0			0		1			1	1	
	Ex. 002Pxxxxxx	Bit 7			0			1		0			1		
									1.01						
6	Signal tone sensitivity	Level	0	-1	-2	-3	-4	-5	-6	-7	-8	-9	-10	1	
5	(UBIII) after dial for	(dBm)	Ŭ	•	-	Ŭ		Ŭ	Ŭ	Ĺ	Ŭ	Ŭ	10	0	
4	buby tono	Bit 6	Bit 6 0 0 0 0 0 0 0 0 0 0 0 0 0 0 1							1	8				
3		Bit 5	Bit 4 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0							0					
2		Bit 4	0	0	0	0	0	0	0	0	1	1	1	0	
1		BIt 3	0	0	1	1	1		1	1	0	0	1	0	
•		DIL Z	0	1	0	1	0	1	0	1	0	1	1	Ŭ	
		DILT	0		U		0	<u> </u>	0		U		0		
		Level (dBm)	-11	-1:	2 -1	3 -	14	-15	-16	-17	-18	-19	-20		
		Bit 6	0	0	C)	0	0	0	0	0	0	0		
		Bit 5	0	0	C)	0	0	1	1	1	1	1		
		Bit 4	1	1	1		1	1	0	0	0	0	0		
		Bit 3	0	1	1		1	1	0	0	0	0	1		
		Bit 2	1	0	C)	1	1	0	0	1	1	0		
		Bit 1	1	0	1		0	1	0	1	0	1	0		
		Level (dBm)	-21	-22	2 -2	3 -	24	-25	-26	-27	-28	-29	-30		
		Bit 6	0	0	0)	0	0	0	0	0	0	0		
		Bit 5	1	1	1		1	1	1	1	1	1	1		
		Bit 4	0	0	0)	1	1	1	1	1	1	1		
		Bit 3	1	1	1		0	0	0	0	1	1	1		
		Bit 2	0	1	1		0	0	1	1	0	0	1		
		Bit 1	1	0	1		0	1	0	1	0	1	0		
		Level (dBm)	-31	-32	2 -3	3 -	34	-35	-36	-37	-38	-39	-40		
		Bit 6	0	1	1		1	1	1	1	1	1	1		
		Bit 5	1	0	0)	0	0	0	0	0	0	0		
		Bit 4	1	0	0)	0	0	0	0	0	0	1		
		Bit 3 1 0 0 0 0 1 1 1 1 0													
		Bit 2	1	0	0)	1	1	0	0	1	1	0		
		Bit 1	1	0	1		0	1	0	1	0	1	0		
		Level (dBm)					-4	41 to	o -50)					
		Bit 1 to 6 Setting disable													

16.8.31 SOFT SWITCH: #31

Bit No.	Designation	Function	lr S€	itial etting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	

16.8.32 SOFT SWITCH: #32

Bit No.	Designation	Function	In Se	itial etting
			Bit	HEX
8	Reserved	Reserved	0	
7	Reserved	Reserved	0	0
6	Reserved	Reserved	0	0
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	
3	Reserved	Reserved	0	0
2	Reserved	Reserved	0	0
1	Reserved	Reserved	0	

16.8.33 SOFT SWITCH: #33

bizhub 160/160f bizhub 161/161f

Bit No.	Designation	Function	In Se	itial tting
			Bit	HEX
8	Reserved	Reserved	0	4
7	V.17 echo protection tone	0: Off 1: On	1	
6	V.29 echo protection tone	0: Off 1: On	0	
5	Compromise equalize enable (CEQ) in the transmit path (TCEQ)	0: No 1: Yes	0	
4	Compromise equalize enable (CEQ) in the receiver path (RCEQ)	0: No 1: Yes	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	

• Bit 4 to 5: V.17, V.29 and V.27 only

16.8.34 SOFT SWITCH: #34

Bit No.	Designation	Function	In Se	itial tting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	2
3	Reserved	Reserved	0	
2	Reserved	Reserved	1	
1	Reserved	Reserved	0	

16.8.35 SOFT SWITCH: #35

Bit No.	Designation	Function									nitial etting										
										Bit	HEX										
8	Dial tone table switch	Time (ms)	300	60	00	1000		20	00	1	9										
7	time	Bit 8	0	0)	1			1	0											
		Bit 7	0	1		0			1												
6	Dial tone frequency				1					0											
5	upper range index	Frequency range (Hz)	375 to	462	310 to	380	462	2 to	580	1	-										
4		Bit 6	0		0			0		0	0										
		Bit 5	0		0	1															
		Bit 4	0		1			0													
		Frequency range (Hz)	570 to	630	300 to	to 370		eser	ved												
		Bit 6	0		1		1	1	1												
		Bit 5	1		0	0		1	1												
		Bit 4	1		0		1	0	1												
		See Bit 1 to 3 (This upper ran value that defir	ige value r ied in bit 1	nust b to 3)	be highe	r than	low	ver r	ange												
3	Dial tone frequency	Frequency								0											
2	Low range index	range (Hz)	375 to	462	310 to 380		462	2 to	580	0											
1		Bit 3	0		0			0		0											
		Bit 2	0		0	0		0		0		1									
		Bit 1	0		1			0													
		Frequency range (Hz)	ency (Hz) 570 to 630		300to 370		300to 370		300to 370		300to 370		300to 370		300to 370		Re	serv	ed		
		Bit 3	0		1		1	1	1												
		Bit 2	1		0		0	1	1												
		Bit 1	1		0		1	0	1												
1										1	1										

16.8.36 SOFT SWITCH: #36

bizhub 160/160f bizhub 161/161f

Bit No.	Designation	Function									In Se	itial tting
											Bit	HEX
8	Re-dial attempts con- tinue fail counter	0: No any limita 1: limit up to b	No any limitation limit up to bit 1 to 4								1	8
7	Reserved	Reserved	eserved								0	
6	Reserved	Reserved									0	
5	Reserved	Reserved									0	
4	Re-dial attempts fail	Counter	0	1	2	3	4	5	6	7	1	6
3	limitation counter	Bit 4	0	0	0	0	0	0	0	0	0	
2		Bit 3	0	0	0	0	1	1	1	1	1	
1		Bit 2	0	0	1	1	0	0	1	1	0	
		Bit 1	0	1	0	1	0	1	0	1		
		Counter	8	9	10	11	12	13	14	15		
		Bit 4	1	1	1	1	1	1	1	1		
		Bit 3	0	0	0	0	1	1	1	1		
		Bit 2	0	0	1	1	0	0	1	1		
		Bit 1	0	1	0	1	0	1	0	1		
											1	

• Bit 8: The redial fail counter will plus 1 for each auto dialing, unless user interruption or after finish communication. If the counter is over the setting in bit 1 to 4 and Bit set to 1, then the machine will stop redial unless user interruption or enter the communication phase.

16.8.37 SOFT SWITCH: #37

Bit No.	Designation		lr Se	nitial etting									
								Bit	HEX				
8	Polling TX type for V.34 modem	0: V.34 1: V.17						0	0				
7	Auto dial learning for V.34 modem	0: Yes- skip V.3 1: No - retry from	4 hands n V.8 ha	shaking ndshake	with re	mote si	de	0					
6 5	RX start symbol rate for V.34 modem	Symbol rate (sym/s)	Symbol rate (sym/s) 3429 3200 3000 2800 2400 ()										
4		Max. speed (kbps)	33.6	31.2	26.4	24.0	21.6	0	0				
		Bit 6	0	0	0	0	1						
		Bit 5	0	0	1	1	0						
		Bit 4	0	1	0	1	0						
		Symbol rate Max. speed Bit 6	F 1	Reserve	d 1								
		Bit 5	0	1	1								
		Bit 4	1	0	1								
		-											
3 2	TX start symbol rate for V.34 modem	Symbol rate (sym/s)	3429	3200	3000	2800	2400	0	-				
1		Max. speed (kbps)	33.6	31.2	26.4	24.0	21.6	0					
		Bit 6	0	0	0	0	1						
		Bit 5	0	0	1	1	0						
		Bit 4	0	1	0	1	0						
		Symbol rate Max. speed											
		Bit 6	1	1	1								
		Bit 5	0	1	1								
		Bit 4	1	0	1								
1		1							1				

16.8.38 SOFT SWITCH: #38

Bit No.	Designation		Function					itial etting
							Bit	HEX
8	Fine tune of 33.6 kbps/ 31.2 kbps receiving speed for V.34 modem	0: No - modem default 1: Yes	setting				1	E
7	Set/Reset V.34 trans- mit level deviation	0: Reset 1: Set					1	
6	V.34 flag number	Flags number	2	4	8	10	1	
5	between ECM frame	Bit 6	0	0	1	1	0	
		Bit 5	0	1	0	1		
4	Phase 2 guard tone power level (V.34)	0: normal power leve 1: -7 db of normal pow	l er level				0	1
3	Reserved	Reserved					0	
2	Polling RX start speed	0: start from V.34 1: start from V.17					0	
1	V.8 /V.34 capability	0: No 1: Yes					1	

• Bit 8: This bit when set to 1 can get higher speed communication for V.34 under the same line condition.

16.8.39 SOFT SWITCH: #39

Bit No.	Designation		Function					itial tting
							Bit	HEX
8	Disable V.34 TX for V.34 modem	0: No 1: Yes					0	0
7	Disable V.34 RX for V.34 modem	0: No 1: Yes					0	
6	Flags number in ECM	Flags number	1	2	3	4	0	
5	frame for V.34 modem	Bit 6	0	0	1	1	0	
		Bit 5	0	1	0	1		
							-	
4	Manual TX mode for V.34 modem	0: V.8 - start handsh 1: V.17	ake fron	n V.8			0	1
3	Switch from V.17 to V.34 if DIS bit 6 set after received DIS	0: Yes - start V.8 han 1: No - Continue start	dshakir with V.1	n g.but o i 7	nly first f	time	0	
2	Delay time in primary	Symbol rate (ms)	100	200	300	500	0	
1	channel for V.34 trans-	Bit 2	0	0	1	1	1	
	signal	Bit 1	0	1	0	1		
							1	

16.8.40 SOFT SWITCH: #40

Bit No.	Designation	Function					In Se	itial etting
							Bit	HEX
8	V.17 RX start speed		V.17	V.17	V.17	V.17	0	0
7	Select receiving start	Speed (bps)	14400	12200	9600	7200	0	
6	speed for V.17	Bit 8	0	0	0	0	0	
5		Bit 7	0	0	0	0	0	
-		Bit 6	0	0	1	1		
		Bit 5	0	1	0	1		
					-			
		Speed (bps)	V.29	V.29	V.27	V.27 ter		
		opood (opo)	9600	7200	4800	2400		
		Bit 8	0	0	0	0		
		Bit 7	1	1	1	1		
		Bit 6	0	0	1	1		
		Bit 5	0	1	0	1		
		Speed		Reser	ved	-		
		Bit 8 1	1	1 1	1 1	1 1		
		Bit 7 0	0	0 0	1 1	1 1		
		Bit 6 0	0	1 1	0 0	1 1		
		Bit 5 0	1	0 1	0 1	0 1		
4	Reserved	Reserved					0	0
3	V.34 RX start speed		V.34	V.34	V.34	V.34	0	
2		Speed (bps)	33600	31200	28800	26400	0	
1		Bit 3	0	0	0	0	0	
		Bit 2	0	0	1	1		
		Bit 1	0	1	0	1		
			•	•		· · · · ·		
			V.34	V.34	V.34	V.34		
		Speed (bps)	24000	21600	19200	16800		
		Bit 3	1	1	1	1		
		Bit 2	0	0	1	1		
		Bit 1	0	1	0	1		
1							1	

16.8.41 SOFT SWITCH: #41

bizhub 160/160f bizhub 161/161f

Adjustment / Setting	

Bit No.	Designation		Function						lr Se	nitial etting		
									Bit	HEX		
8	V.17 TX start speed	One and the		V.17		V.17		V.17	V.	17	0	0
7	Select receiving start	Speed (bp	os)	1440	0	12200		9600	72	00	0	1
6	speed for V.17	Bit 8		0		0		0	(C	0	
5		Bit 7		0		0		0	(C	0	•
0		Bit 6		0		0		1		1	Ũ	
		Bit 5		0		1		0		1		
		Speed (br	ne)	V.29		V.29		V.27	V.27	7 ter		
		Opeca (b)	,3)	9600)	7200		4800	24	00		
		Bit 8		0		0		0	()		
		Bit 7		1		1		1		1		
		Bit 6		0		0		1		1		
		Bit 5		0		1		0		1		
											.	
		Speed				Rese	erve	bd		1		
		Bit 8	1	1	1	1	1	1	1	1		
		Bit 7	0	0	0	0	1	1	1	1		
		Bit 6	0	0	1	1	0	0	1	1		
		Bit 5	0	1	0	1	0) 1	0	1		
4	Reserved	Reserved									0	0
3	V.34 TX start speed			V.34		V.34		V.34	V.	34	0	
2		Speed (bp	os)	3360	0	31200		28800	264	400	0	
1		Bit 3		0		0		0	(C	0	
		Bit 2		0		0		1		1		
		Bit 1		0		1		0		1		
		Spood (br	20)	V.34		V.34		V.34	V.	34		
		Sheen (ph	,5)	2400	0	21600		19200	168	300		
		Bit 3		1		1		1		1		
		Bit 2		0		0		1		1	1	
		Bit 1		0		1	Τ	0		1	1	

16.8.42 SOFT SWITCH: #42

Bit No.	Designation	Function	In Se	itial tting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	

16.8.43 SOFT SWITCH: #43

Bit No.	Designation	Function	In Se	itial tting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	

16.8.44 SOFT SWITCH: #44

Bit No.	Designation	Function	In Se	itial tting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	

16.8.45 SOFT SWITCH: #45

Bit No.	Designation	Function	In Se	itial tting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Closed network	0: OFF 1: ON	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	

16.8.46 SOFT SWITCH: #46

Bit No.	Designation	Function	In Se	itial tting
			Bit	HEX
8	Daylight savings timer	0: No 1: Yes	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	RX print	0: RX one page then print one page. (PRINT RX) 1: Start to print after receiving all pages. (MEMORY RX)	1	A
3	Default TX mode	0: Memory TX 1: ADF TX	0	
2	Header for FAX TX	0: Off 1: On-Transmit header at top of each page.	1	
1	Print model name on top of TX page if machine name not reg- ister	0: No 1: Yes	0	

• Bit 1: If machine name not registered, the model name will print at the top of each receiving page. The default is not printed.

• Bit 2: Some country such as U.S.A. PTT regulation, must send header at top of each page.

16.8.47 SOFT SWITCH: #47

Bit No.	Designation	Function	In Se	itial etting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0]
6	RX mode	0: Auto RX mode 1: Manual RX mode	0	
5	Footer	0: Off 1: On – Print footer information at each of received page	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0]
2	Reserved	Reserved	0]
1	Reserved	Reserved	0]

• Bit 5: The footer shows machine number, receiving time, remote side TSI number, session and page number.

16.8.48 SOFT SWITCH: #48

Bit No.	Designation	Function	In Se	itial tting
			Bit	HEX
8	Activity report	0: No 1: Yes	1	8
7	Reservation report	0: No 1: Yes	0	
6	TX result report	0: No 1: Yes	0	
5	RX result report	0: No 1: Yes	0	
4	TX/ RX error report	0: No 1: Yes	1	9
3	Error report for I-FAX and network scanner	0: No 1: Yes	0	
2	Error mail (I-FAX)	If machine receives Error Mail (I-FAX), the mail is deleted or kept? 0: Delete 1: Keep	0	
1	Broadcast report	0: Not to print 1: Print	1	

- Bit 4: During communication have error in TX or RX and Bit 4 was set, the machine printed error report.
- Bit 2: If resetting (delete), the mail will be deleted on POP3 server. If setting (keep), the mail will be kept on POP3 server.

16.8.49 SOFT SWITCH: #49

Bit No.	Designation	Function								In Se	itial tting	
											Bit	HEX
8	Reserved	Reserved	Reserved								0	0
7	Reserved	Reserved	Reserved								0	
6	Print RX mailbox report method	0: Based on RX 1: Always printi	0: Based on RX RESULT REPORT setting 1: Always printing								0	
5	Redial method if com- munication fail	0: Redial again 1: Based on redial time interval							0			
4	No. of rings	No. of rings	1	2	3	4	5	6	7	8	0	1
3		Bit 4	0	0	0	0	0	0	0	0	0	
2		Bit 3	0	0	0	0	1	1	1	1	0	
1		Bit 2	0	0	1	1	0	0	1	1	1	
-		Bit 1	0	1	0	1	0	1	0	1		
		No. of rings	9	10	11	12	13	14	15	16		
		Bit 4	1	1	1	1	1	1	1	1		
		Bit 3	0	0	0	0	1	1	1	1		
		Bit 2	0	0	1	1	0	0	1	1		
		Bit 1	0	1	0	1	0	1	0	1		

16.8.50 SOFT SWITCH: #50

Bit No.	Designation	Function		itial tting
			Bit	HEX
8	Transmit or cancel after time out in "Memory TX"	0: Cancel and print out 1: Transmission	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	

• Bit 8: Can select cancel this job and print out report or start to send in case of time when memory full condition occurs

8	6
Ξ	Ξ
00	5
÷	÷
qr	q
Ę	Ę
-i2	<u>-1</u>

16.8.51 SOFT SWITCH: #51

Bit No.	Designation	Function						
							Bit	HEX
8	Reserved	Reserved					0	0
7	Reserved	Reserved					0	
6	Reserved	Reserved	Reserved					
5	Reserved	Reserved	0					
4	T30 monitor report	Descrip-	Not to	Print report	Print report	Not	0	0
3	selection	tion	print	for each transaction	while reporting error	used	0	
		Bit 4	0	0	1	1		
		Bit 3	0	1	0	1		
2	Send "un-sent page mode" for memory transmission	0: From er 1: From sta	ror page art page	9			0	
1	Reserved	Reserved					0	

16.8.52 SOFT SWITCH: #52

Bit No.	Designation	Function	In Se	itial etting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	
16.8.53 SOFT SWITCH: #53

Bit No.	Designation	Function	In Se	itial tting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	

16.8.54 SOFT SWITCH: #54

Bit No.	Designation			In Se	itial tting			
							Bit	HEX
8	Report/ LCD date/time type	0: Digits format (ex 1: Alpha numeric	ample: 2 format (2003. 1 examp	1. 19) le: 2003. N	IOV. 19)	0	2
7	Report/ LCD date/time	When bit No.8 is "1					0	
6	format	Date/ Time		003. DV. 19	19. NOV. 2003	NOV. 19. 2003	1	
		Bit 7		0	0	1		
		Bit 6		0	1	0		
		When bit No.8 is "0 Date/ Time Bit 7 Bit 6	". 200 19	3. 11. 0 0	19. 11. 2003 0 1	11. 19. 2003 1 0		
5	Memory near full	Description (KB)	48	96	176	256	0	
4	capacity for black/white	Bit 5	0	0	1	1	1	8
	scanning	Bit 4	0	1	0	1		
3	Memory near full		540	100		5004	0	
0	capacity for Color/Gray	Description (KB)	512	102	4 2512	5024	0	
2	scanning	DIT 3	0	1	1	1	0	
		Dil 2	U		0			
1	Reserved	Reserved					0	

16.8.55 SOFT SWITCH: #55

Bit No.	Designation	Function	In Se	iitial etting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	

16.8.56 SOFT SWITCH: #56

Bit No.	Designation	Function	In Se	itial etting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	

16.8.57 SOFT SWITCH: #57

Bit No.	Designation	Function	In Se	itial etting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	

16.8.58 SOFT SWITCH: #58

bizhub 160/160f bizhub 161/161f

Bit No.	Designation	Function	In Se	itial tting
			Bit	HEX
8	Time out from PSK to FSK delay time	0: 6 sec 1: 30 sec	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	

• Bit 8: This is the delay time for PSK signal after sending MCF or PPR command. The timer depends on regulations of each country.

16.8.59 SOFT SWITCH: #59 Part 1

Bit	Designation		Fun	ction			In	itial
No.							Se	etting
							Bit	HEX
8	Reserved	Reserved					0	0
7	Reserved	Reserved					0	
6	Time between GMT	Time between	Gre	0				
5	ONT: One service man	mean time	+00:00	+00:30	+01:00	+01:30	0	
4	GMT: Greenwich mean	Bit 6	0	0	0	0	0	0
3	ume	Bit 5	0	0	0	0	0	
2	-	Bit 4	0	0	0	0	0	
-	-	Bit 3	0	0	0	0	0	
1		Bit 2	0	0	1	1	0	
		Bit 1	0	1	0	1		
		Time between	Gre	enwich n	nean time	e + T		
		mean time	+02:00	+02:30	+03:00	+03:30		
		Bit 6	0	0	0	0		
		Bit 5	0	0	0	0		
		Bit 4	0	0	0	0		
		Bit 3	1	1	1	1		
		Bit 2	0	0	1	1		
		Bit 1	0	1	0	1		
		Time between	Gre	enwich n	nean time	+ T		
		mean time	+04:00 +04:30 +05:00 +05:30					
		Bit 6	0	0	0	0		
		Bit 5	0	0	0	0		
		Bit 4	1	1	1	1		
		Bit 3	0	0	0	0		
		Bit 2	0	0	1	1		
		Bit 1	0	1	0	1		
		Time between	Gre	enwich m	nean time	+ T		
		mean time	+06:00	+06:30	+07:00	+07:30		
		Bit 6	0	0	0	0		
		Bit 5	0	0	0	0		
		Bit 4	1	1	1	1		
		Bit 3	1	1	1	1		
		Bit 2	0	0	1	1		
		Bit 1	0	1	0	1		
		Time between	Gre	enwich m	nean time	+ T		
		mean time	+08:00	+08:30	+09:00	+09:30		
		Bit 6	0	0	0	0		
		Bit 5	1	1	1	1		
		Bit 4	0	0	0	0		
		Bit 3	0	0	0	0		
		Bit 2	0	0	1	1		
			U	I	U	I		

16.8.60 SOFT SWITCH: #59 Part 2

Bit No.	Designation		Function							
							Bit	HEX		
8	Reserved	Reserved					0	0		
7	Reserved	Reserved					0			
6	Time between GMT	Time between	Gra	onwich m	oon timo	. т	0			
5	OMT: Our annials man	mean time	±10.00	±10.30	±11.00	+ 1 ⊥11·30	0			
4	time	Bit 6	0	0	0	0	0	0		
3		Bit 5	1	1	1	1	0			
2		Bit 4	0	0	0	0	0			
1		Bit 3	1	1	1	1	0			
·		Bit 2	0	0	1	1	Ŭ			
		Bit 1	0	1	0	1				
		Time between	Gre	enwich m	nean time	+ T				
		mean time	+12:00	-00:30	-01:00	-01:30				
		Bit 6	0	1	1	1				
		Bit 5	1	0	0	0				
		Bit 4	1	0	0	0				
		Bit 3	0	0	0	0				
		Bit 2	0	0	1	1				
		Bit 1	0	1	0	1				
		Time between	Gre	enwich m	nean time	+ T				
		mean time	-02:00	-02:30	-03:00	-03:30				
		Bit 6	1	1	1	1				
		Bit 5	0	0	0	0				
		Bit 4	0	0	0	0				
		Bit 3	1	1	1	1				
		Bit 2	0	0	1	1				
		Bit 1	0	1	0	1				
		Time between	Gre	enwich m	nean time	+ T				
		mean time	-04:00	-04:30	-05:00	-05:30				
		Bit 6	1	1	1	1				
		Bit 5	0	0	0	0				
		Bit 4	1	1	1	1				
		Bit 3	0	0	0	0				
		Bit 2	0	0	1	1				
			U	1	U	1				

16.8.61 SOFT SWITCH: #59 Part 3

Bit No.	Designation		Function									
							Bit	HEX				
8	Reserved	Reserved					0	0				
7	Reserved	Reserved					0	1				
6	Time between GMT	-	0.10	anuiah	maan tim	a . T	0					
5		I ime between	-06:00			e + 1	0					
4	GMT: Greenwich mean	Bit 6	1	1	1	1	0	0				
3	time	Bit 5	0	0	0	0	0					
0	-	Bit 4	1	1	1	1	0	-				
2	-	Bit 3	1	1	1	1	0					
1		Bit 2	0	0	1	1	0					
		Bit 1	0	1	0	1						
		Time between	Gre	enwich	mean tim	e + T						
		mean time	-08:00	-08:30	-09:00	-09:30						
		Bit 6	1	1	1	1						
		Bit 5	1	1	1	1						
		Bit 4	0	0	0	0						
		Bit 3	0	0	0	0						
		Bit 2	0	0	1	1						
		Bit 1	0	1	0	1						
		Time between	Gre	enwich	mean tim	e + T						
		mean time	-10:00	-10:30	-11:00	-11:30						
		Bit 6	1	1	1	1						
		Bit 5	1	1	1	1						
		Bit 4	0	0	0	0						
		Bit 3	1	1	1	1						
		Bit 2	0	0	1	1						
		Bit 1	0	1	0	1						
		Time between	Gre	enwich	mean tim	e + T						
		mean time	-12:00		Reserve	d						
		Bit 6	1	1 1	1 1	1 1 1						
		Bit 5	1	1 1	1 1	1 1 1						
		Bit 4	1	1 1	1 1	1 1 1						
		Bit 3	0	0 0	0 1	1 1 1						
		Bit 2	0	0 1	1 0	0 1 1						
		Bit 1	0	1 0	1 0	1 0 1						
							1	1				

16.8.62 SOFT SWITCH: #60

Bit No.	Designation	Function	In Se	itial tting
			Bit	HEX
8	Reserved	Reserved	0	2
7	Reserved	Reserved	0	
6	Quick memory TX	0: Ineffective 1: Effective	1	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	1
3	Print mailbox RX image even if password is not correct	0: No 1: Yes	0	
2	Off hook alarm after communication	0: Alarm 1: No alarm after communication	0	
1	Display destination selection within TX Phase C	0: Local Name or telephone number 1: Display and report Remote telephone number	1	

• Bit 3: If bit 3 is set to "1", machine will print out the incoming page even if password is not correct.

16.8.63 SOFT SWITCH: #61

Bit No.	Designation		Function								In Se	itial tting
											Bit	HEX
8	Reserved	Reserved	leserved								0	0
7	Reserved	Reserved									0	
6	Reserved	Reserved	eserved							0		
5	Reserved	Reserved									0	
4	Max. No. of rings	No. of rings	1	2	3	4	5	6	7	8	1	F
3		Bit 4	0	0	0	0	0	0	0	0	1	
2		Bit 3	0	0	0	0	1	1	1	1	1	
1		Bit 2	0	0	1	1	0	0	1	1	1	
		Bit 1	0	1	0	1	0	1	0	1		
								-				
		No. of rings	9	10	11	12	13	14	15	16		
		Bit 4	1	1	1	1	1	1	1	1		
		Bit 3	0	0	0	0	1	1	1	1		
		Bit 2	0	0	1	1	0	0	1	1		
		Bit 1	0	1	0	1	0	1	0	1		

16.8.64 SOFT SWITCH: #62

Bit No.	Designation	Function	In Se	iitial etting
			Bit	HEX
8	Reserved	Reserved	0	0
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Reserved	Reserved	0	

16.8.65 SOFT SWITCH: #63

Bit No.	Designation	Function		itial tting
			Bit	HEX
8	# key definition in PBX mode	0: default is internal 1: default is external	1	8
7	Reserved	Reserved	0	
6	Reserved	Reserved	0	
5	Reserved	Reserved	0	
4	Reserved	Reserved	0	0
3	Reserved	Reserved	0	
2	Reserved	Reserved	0	
1	Tx Result report with image	0: Yes 1: No	0	

- Bit 8: if this bit set to "1", the # key is used to access PSTN line instead of the pre-fix number which is dialed in front of the TEL No. If this bit set to 0, the pre-fix number is used automatically to access PSTN line when the TEL No. is dialed.
- Bit 1: If this bit set to "1", the first page image will not append at the bottom of error report or OK report

16.8.66 SOFT SWITCH: #64

bizhub 160/160f bizhub 161/161f

Bit No.	Designation	Function	In Se	itial tting
			Bit	HEX
8	Reserved	Reserved	0	1
7	Reserved	Reserved	0	
6	Print RX error report on RX side if no FAX signal is detected	0: No 1: Yes	0	
5	10 PPS & 20 PPS selectable by user	0: No 1: Yes	1	
4	Reserved		0	0
3	Reserved		0	
2	Reserved		0	
1	Reserved		0	

- Bit 6: If this bit set to "1", Machine does not print a RX error report if no Fax signal from the other party is detected.
- Bit 5: Prevents user to change PPS if this bit set to "0."

bizhub 160/160f bizhub 161/161f

17. Fax Protocols

17.1 G3 ECM (G3 Error Correction Mode)

- G3 ECM is the error correction system newly recommended by Consultative Committee of International Telephone & Telegraph of 1988.
- By G3 ECM, documents are divided into blocks (called partial page) for transmission. If any error takes place in any frame (one partial page consists of 256 frames) on a partial page, the receiving party generates the retransmit request with erroneous frame numbers.

Transmission Receiving Frame 0 Frror Х Frame 1 Frame 2 Note: If one page end and Partial page consists of plural number of Frame 3 Х (High-speed Modem Sigpartial pages, PPS. NULL signal is transmitted nal) from the transmission side. Frame 255 Partial page end and End PPS.EOP procedure 300 dps Modem Signal PPR Re-transmit request (MCF is repeated if there is no error) Re-transmission for error Frame 1 **Re-transmission** (High-speed modem Sig-Frame 3 nal) PPS EOP Partial page end 300 dps Modem Signal MCF Message check (Received without error) 4507M501AA

Here is an example where frame 1 and frame 3 are subjected to error:

17.2 Line control

17.2.1 Procedure of G3 mode communication

• Basic communications diagram of G3 mode.



17.3 Table of reference code

Code	Function
CFR	Confirmation to Receive. 1850 Hz or 1650 Hz 3 sec.
CIG	Calling Station Identification.
CRP	Command Repeat.
CSI	Called Subscriber Identification.
DCN	Disconnect.
DCS	Digital Identification Signal.
DIS	Digital Transmit Command.
DTC	Digital Transmit Command.
EOM	End of Message. 1,100 Hz.
EOP	End of Procedure.
FTT	Failure to Train.
MCF	Message Confirmation. 1,650 Hz or 1,850 Hz.
MPS	Multi-Page Signal.
NCS	Non-Standard Facilities Command.
NCF	Non-Standard Facilities.
NSS	Non-Standard Facilities Set-up.
PIN	Procedural Interrupt Negative.
PIP	Procedural Interrupt Positive.
PRI-EOM	Procedure Interrupt-End of Message (COM).
PRI-MPS	Procedure Interrupt-Multi page Signal (MPS).
PRI-EOP	Procedure Interrupt-End of Procedure (EOP).
RTN	Retrain Negative.
RTP	Retrain Positive.
TSI	Transmitting Station Identification.

17.4 How to analyze the T30 protocol monitor

- DCS or DIS
- HEX Data as printed on page.
- 🖙 132, 152
- Example: V.17 Communication



• FIF (Facsimile Information Field)

HEX									1								2															
HEA	0		0		4		6			8		8			0			0														
Data Bit	0	0	0	0	0	0	0	0	0	1	0	0	0	1	1	0	1	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
Bit No.	8	7	6	5	4	3	2	1	16	15	14	13	12	11	10	9	24	23	22	21	20	19	18	19	32	31	30	29	28	27	26	25
Note	Bit Bit Bit	No No	5.1 5.1 5.1	1= 5= 9=	1, 1 0,	Bi R8 Bi	t N x	0.1 7.7 0.2	2= 1 Lii 20=	1 U	200 /mn nlin) bp n (F nite	↑ s Fine ed F	↑ ≥ M Pap	ode er l	e) Lei	ngt	h	-		1	1			-			-				

Hex-Binary Conversion List

Hex		Bin	ary																
0	0	0	0	0	4	0	1	0	0	8	1	0	0	0	С	1	1	0	0
1	0	0	0	1	5	0	1	0	1	9	1	0	0	1	D	1	1	0	1
2	0	0	1	0	6	0	1	1	0	Α	1	0	1	0	Е	1	1	1	0
3	0	0	1	1	7	0	1	1	1	В	1	0	1	1	F	1	1	1	1

DIS(DTC)/ DCS Bit Allocation Table of FIF (Facsimile Information Field)

Bit No.	Designation	DIS/DTC	DCS						
1	"0"= Invalid "1"= Store-and-forw	ard switching Internet fax simple mode							
2	Set to "0"								
3	"0"= Invalid "1"= Real-time Inter	net fax							
4	Set to "0"								
5	Set to "0"								
6	"0"= Invalid "1"= V.8 capabilities		Invalid						
7	Flame size	"0" = 256 octets preferred "1"= 64 octets preferred	Invalid						
8	Set to "0"								
9	"0"= Invalid "1"= Ready to transr	nit a facsimile document (polling)	Set to "0"						
10	"0"= Invalid "1"= Receiver fax op	eration							
11			Pit No.						
12			14 13 12 11 Data signalling rate						
13			2400 bit/s,						
14	Data signalling rate	Data signalling rate 14 13 12 11 Data signalling rate 0 0 0 V.27 ter fall-back mode 0 0 0 1 Rec. V.29 0 0 1 Rec. V.29 0 0 1 0 Rec. V.27 ter 14 14 14 14 15 0 0 1 1 Rec. V.27 ter 14 14 14 15 16	0 0 0 1 rec. V.27 ter 0 0 1 9600 bit/s, rec. V.29 0 0 1 0 4800 bit/s, rec. V.29 0 0 1 1 7200 bit/s, rec. V.27 ter 0 0 1 1 7200 bit/s, rec. V.29 0 1 0 0 Invalid 0 1 0 1 Reserved 0 1 1 Reserved 1 1 0 0 14,400 bit/s, rec. V.17 1 0 0 14,400 bit/s, rec. V.17 1 0 1 12,000 bit/s, rec. V.17 1 0 1 12,000 bit/s, rec. V.17 1 0 1 17,200 bit/s, rec. V.17 1 0 1 17,200 bit/s, rec. V.17 1 1 0 Reserved 1 1 0 Reserved 1 1 0 Reserved 1 1 0 Reserved 1 1 1 Res						
15	"0"= Invalid "1"= R8 × 7.7 lines/mm and/or 200 × 200 pels/25.4 mm								

bizhub 160/160f bizhub 161/161f

17. Fax Protocols

Bit No.	Designation	DIS/DTC	DCS
16	"0"= Invalid "1"= Two-dimension	al coding capability	"0"= Invalid "1"= Two-dimensional coding
17	Recording width capabilities	Bit No. Data signalling rate 18 17 0 0 Scan line length 215 mm ± 1% 1 1% 0 1 Scan line length 215 mm ± 1% and scan line length 255 mm ± 1% 1 0 1 0 mm ± 1% 1 0 mm ± 1% 1 1 1 1	$\begin{tabular}{ c c c c c c c c c c c c c c c c c c c$
19		Bit No.	Rit No. Recording length conshil
20	Recording length capability	20 19 0 0 A4 (297 mm) 0 1 A4 (297 mm) and B4 (364 mm) 1 0 Unlimited 1 1 Invalid	Bit No. Recording length capability 20 19 ity 0 0 A4 (297 mm) 0 1 B4 (364 mm) 1 0 Unlimited 1 1 Invalid
21	Bit No.	Minimum soon line time	
22	23 22 21	capability at the receive	
23	0 0 0 20 ms ms 0 0 1 5 ms ms 0 1 0 10 ms ms 0 1 1 20 ms ms 0 1 0 10 ms 1 0 0 40 ms 1 0 1 40 ms 1 1 0 10 ms 1 1 0 10 ms	at 3.85 1/mm: T 7.7 = T 3.85 20 at 3.85 1/mm: T 7.7 = T 3.85 at 3.85 1/mm: T 7.7 = T 3.85 10 at 3.85 1/mm: T 7.7 = T 3.85 10 at 3.85 1/mm: T 7.7 = $1/2$ T 3.85 at 3.85 1/mm: T 7.7 = T 3.85 40 at 3.85 1/mm: T 7.7 = $1/2$ T 3.85 at 3.85 1/mm: T 7.7 = $1/2$ T 3.85 at 3.85 1/mm: T 7.7 = $1/2$ T 3.85 at 3.85 1/mm: T 7.7 = T 3.85	Bit No. Minimum scan line time 23 22 21 0 0 20 ms 0 0 1 5 ms 0 1 0 10 ms 1 0 0 40 ms 1 1 0 ms
24	Extension field	"0"= Without "1"= With	
25	Reserved	J	
	"0"= Invalid		
26	"1"= Un-compresse	d mode	

Bit No.	Designation	DIS/DTC	DCS							
27	"0"= Invalid "1"= ECM									
28	Set to "0"		Frame size 0: 256 octets Frame size 1: 64 octets							
29	Set to "0"									
30	Set to "0"									
31	"0"= Invalid "1"= T.6 coding capa	bility	"0"= Invalid "1"= T.6 coding enabled							
32	Extend field	"0"= Without "1"= With								
33	"0"= Invalid "1"= Field not valid capability									
34	"0"= Invalid "1"= Multiple selectiv	e polling capability	Set to "0"							
35	"0"= Invalid "1"= Polling subaddr Address (DIS)/PSA	ess transmission (DTC) by Polled Sub-	- Set to "0"							
36	"0"= Invalid "1"= T.43 coding									
37	"0"= Invalid "1"= Plane interleave									
38	Set to "0"									
39	Set to "0"									
40	Extend field	"0"= Without "1"= With								
41	"0"= Invalid "1"= R8 x 15.4 lines/	mm								
42	"0"= Invalid "1"= 300 x 300 pels/	25.4 mm								
43	"0"= Invalid "1"= R16 x 15.4 lines	s/mm and/or 400 x 400 pels/25.4 mm								
44	"0"= Invalid "1"= Inch based reso	olution preferred	Resolution type selection "0"= metric based resolution "1"= inch based resolution							
45	"0"= Invalid "1"= Metric based re	solution preferred	Do not care							
46	Minimum scan line time capability for higher resolutions.	"0": T 15.4 = T 7.7 "1": T 15.4 = 1/2 T 7.7	Do not care							
47	"0"= Invalid "1"= Selective polling (DTC)	g (DIS)/ Selective polling transmission	Set to "0"							
48	Extend field 0: Without 1: With									
49	"0"= Invalid "1"= Sub Addressing	g capability	"0"= Invalid "1"= Sub Addressing transmission							

bizhub 160/160f bizhub 161/161f

17. Fax Protocols

Bit No.	Designation	DIS/DTC	DCS					
50	"0"= Invalid "1"= Password/ Sen Password transmiss	der Identification capability (DIS)/ ion (DTC)	"0"= Invalid "1"= Sender Identification transmis- sion					
51	"0"= Invalid "1"= Ready to transmit a data file (polling) Set to "0"							
52	Set to "0"		·					
53	"0"= Invalid "1"= Binary File Trar	nsfer (BFT)						
54	"0"= Invalid "1"= Document Tran	sfer Mode (DTM)						
55	"0"= Invalid "1"= EDIFACT Trans	fer (EDI)						
56	Extend field	0: Without 1: With						
57	"0"= Invalid "1"= Basic Transfer I	Mode (BTM)						
58	Set to "0"							
59	"0"= Invalid "1"= Ready to transment (polling)	nit a character or mixed mode docu-	Set to "0"					
60	"0"= Invalid "1"= Character mode	9						
61	Set to "0"							
62	"0"= Invalid "1"= Mixed mode							
63	Set to "0"							
64	Extend field	"0"= Without "1"= With						
65	"0"= Invalid "1"= Processable me	ode 26						
66	"0"= Invalid "1"= Digital network	capability						
67	Duplex and half duplex capabilities	"0"= Half duplex operation only "1"= Duplex and half duplex operation	"0"= Half duplex operation only "1"= Duplex operation					
68	"0"= Invalid "1"= JPEG coding							
69	"0"= Invalid "1"= Full color mode							
70	Set to "0"		"0"= Invalid "1"= Preferred Huffmann tables					
71	"0"= Invalid "1"= 12 bit/pixel/elen	nent	·					
72	Extend field	"0"= Without "1"= With						
73	"0"= Invalid "1"= No sampling (1	:1:1)						

Bit No.	Designation	DIS/DTC	DCS						
74	"0"= Invalid "1"= Nonstandard ra	diation light							
75	"0"= Invalid "1"= Nonstandard is	mute range							
76	"0"= Invalid "1"= North American ity	Letter (215.9 mm × 279.4 mm) capac-	"0"= Invalid "1"= North American Letter (215.9 mm × 279.4 mm)						
77	"0"= Invalid "1"= North American ity	Legal (215.9 mm × 355.6 mm) capac-	"0"= Invalid "1"= North American Legal (215.9 mm × 355.6 mm)						
78	"0"= Invalid "1"= Single layer seq	"0"= Invalid "1"= Single layer sequential encod- ing, basic							
79	"0"= Invalid "1"= Single layer sequential encoding, optional L0 capacity								
80	Extend field	"0"= Without "1"= With							
81	"0"= Invalid "1"= HKM key manag	gement capacity	"0"= Invalid "1"= HKM key management selec- tion						
82	"0"= Invalid "1"= RSA key manaç	gement capacity	"0"= Invalid "1"= RSA key management selection						
83	"0"= Invalid "1"= Override mode	capacity	"0"= Invalid "1"= Override mode function						
84	"0"= Invalid "1"= HFX40 code ca	pacity	"0"= Invalid "1"= HFX40 code selection						
85	"0"= Invalid "1"= Alternative code	e number 2 capacity	"0"= Invalid "1"= Alternative code number 2 selection						
86	"0"= Invalid "1"= Alternative code	e number 3 capacity	"0"= Invalid "1"= Alternative code number 3 selection						
87	"0"= Invalid "1"= HFX40-1 hashir	ng capacity	"0"= Invalid "1"= HFX40-1 hashing selection						
88	Extend field	"0"= Without "1"= With							
89	"0"= Invalid "1"= Alternative hash	ning system number 2 capacity	"0"= Invalid "1"= Alternative hashing system number 2 selection						
90	"0"= Invalid "1"= Alternative hashing system number 3 capacity "1"= Alternative hashing system number 3 selection								
91	Reserved								
92	"0"= Invalid "1"= T.44 (Mixed raster content) mode								
93	"0"= Invalid "1"= T.44 (Mixed raster content) mode								

17. Fax Protocols

Bit No.	Designation	DIS/DTC	DCS						
94	"0"= Invalid "1"= T.44 (Mixed raster content) mode								
95	"0"= Invalid "1"= Page length maximum strip size for T.44 (Mixed raster content)								
96	Extend field "0"= Without "1"= With								
97	"0"= Invalid "1"= Color/mono-color multi-value 300 pixels x 300 pixels or 400 pixels x 400 pixels / 25.4 mm								
98	"0"= Invalid "1"= R4 x 3.85 lines/mm and/or 100 pixels x 100 pixels / 25.4 mm for color/mono-color multi-value								
99	"0"= Invalid "1"= Single phase C	BFT negotiation capacity							
100	Set to "0"								
101	Set to "0"								
102	Set to "0"								
103	Set to "0"								
104	4 Extend field "0"= Without "1"= With								

bizhub 160/160f bizhub 161/161f

Troubleshooting

18. Introduction

• This chapter contains the items required or used when troubleshooting various printer problems.

18.1 Overall Control Configuration

• Understanding the overall control configuration will help perform the troubleshooting procedures for paper misfeeds, malfunctions, and image problems.



19. Jam display

19.1 Misfeed Displays

• The Error indicator lights up and a message appears in the display when a paper misfeed occurs.

Paper Take-Up Section Misfeed



Transport Section Misfeed



19.1.1 Misfeed Display Resetting Procedure

- 1. Open the appropriate covers, remove the misfed paper and any remaining paper, and then close the covers.
- 2. Open, then close the Front Door.

bizhub 160/160f bizhub 161/161f

19.2 Sensor layout



19.3 Solution

19.3.1 Initial Check Items

• When a paper misfeed occurs in the printer, first make the following initial checks.

Check	Action
Does the paper meet product specifications?	Replace paper.
Is the paper curled, wavy, or damp?	Replace paper.Instruct user in correct paper storage.
Is the paper transport path deformed, dirty, or obstructed with foreign matter?	 Clean the paper path and replace if neces- sary.
Are the Paper Separator Fingers dirty, deformed, or worn?	Replace Fusing Unit.
Is the roller dirty, deformed, or worn?	Clean the roller and replace if necessary.
Are Edge Guides at correct position to accommodate paper?	 Slide the Edge Guides up against the edges of the paper stack.
Does the actuator operate correctly when checked?	Correct or replace the actuator.

Precautions for Clearing Misfeed

• Reset the misfeed condition by opening and closing the Front Door after the misfeed has been cleared.

19.3.2 Paper Take-Up/Transport Misfeed

A. Detection Timing

Туре	Description
MP tray Pick-up Jam	The Paper Take-Up Switch does not turn on after the predetermined period of time has elapsed after paper take-up began.
2nd tray Pick-up Jam	
Bypass tray Pick-up Jam	
Separator Jam	The Exit Sensor is not blocked after the predetermined period of time has elapsed after the Paper Take-Up Switch is turned on. The Paper Take-Up Switch is not turned off after the predetermined period of time has elapsed after the Paper Take-Up Switch is turned on.

Relevant Electrical Parts		
Paper Take-Up Switch (S1) Exit Sensor (PS1) Paper Take-Up Solenoid (SL1)	Controller/Mechanical Control Board (PWB-P)	

Step		WIRING DIAGRAM	
	Action	Control Signal	Location (Electric Parts)
1	Initial checks	-	-
2	SL1 solenoid check	PWB-P MPJ3P-2	B-7
3	S1 switch check	PWB-P MPJ10P-2	F-7
4	PS1 sensor check	PWB-P MPJ8P-3	B-7
5	Replace PWB-P.	_	-

19.3.3 Fusing/Exit Misfeed

A. Detection Timing

Туре	Description
Fuser Jam	The Exit Sensor is not unblocked after the predetermined period of time has elapsed after the Paper Take-Up Switch is turned on.
Remains paper Jam 1 Remains paper Jam 2	 If all of the following conditions are met The Front Door or Exit Cover is opened, then closed. (Or the machine is turned on.) The Paper Take Lip Switch is turned on or the Exit Sapper is blocked.
Paper exit jam	The Exit Sensor is unblocked slower than the predetermined period of time after the Paper Take-Up Switch is turned on.

Relevant Electric Parts		
Paper Take-Up Switch (S1) Exit Sensor (PS1)	Controller/Mechanical Control Board (PWB-P)	

	Action	WIRING DIAGRAM	
Step		Control Signal	Location (Electric Parts)
1	Initial check items	-	-
2	S1 switch check	PWB-P MPJ10P-2	F-7
3	PS1 sensor check	PWB-P MPJ8P-3	B-7
4	Replace PWB-P.	-	-

20. Malfunction code

• The CPU performs a self-diagnosis on the condition of the unit, and if a malfunction is detected, the warning appears alternately with the error code in the display.



<Procedure for cancelling a malfunction display>

- In the C05XX trouble, turn the machine off, then on with the STOP key held down.
- Except above, cancel the malfunction display by turning the machine off, then on again.

20.1 Trouble code

20.1.1 Trouble code list

Malfunction Code	Malfunction Name	Description
C0045	Fuser fan motor error	 The LOCK signal remains HIGH or LOW continuously for a predetermined period of time while the Cooling Fan Motor remains energized.
C0210	H. V. abnormal	 The Drum Charge Monitor Voltage (HVC_MON) signal falls outside a predetermined range at any time after the lapse of a predetermined period of time after the Power Switch has been turned ON. The Image Transfer Voltage Monitor signal (T_MON_V) and Image Transfer Current Monitor signal (T_MON_I) fall outside a corresponding predetermined range.
C0500	Fuser warm up error	 The voltage of the Thermistor remains low for a predetermined period of time when a warm-up cycle is started. The temperature detected by the Thermistor remains lower than a reference value for a predetermined period of time for the period of time that begins 5 sec. after, and ends 9 sec. after, the start of the warm-up cycle (where the temperature detected by the Thermistor is 80 °C or less). The temperature detected by the Thermistor does not increase for a 3-sec. period or more for the period of time after the Fusing Roller Heater Lamp has been turned ON and ends when the lamp is turned OFF. The Fusing Roller Heater Lamp remains ON for a 30-sec. period or more (except during the period through which the Main Motor remains energized).

Malfunction Code	Malfunction Name	Description
C0510	Fuser temperature low	 The temperature detected by the Thermistor remains lower than the set temperature continuously for a predetermined period of time while the fusing temperature control is being provided. (The set temperatures are as follows: 140 °C during a print mode at 600 dpi; 70 °C during the standby mode.)
C0520	Fuser overheat	 The temperature detected by the Thermistor remains higher than 235 °C for a predetermined period of time while the fusing temperature control is being provided.
C0650	Scanner home sen- sor error	 The Scanner Home Position Sensor is not detected within the predetermined period of time after the Scanner Motor has started turning.
C1200	ASIC memory abnor- mal	 An error occurred while writing to or reading the SRAM on the Control Board (PWB-C).
C1300	Polygon mirror motor error	 The LOCK signal is not detected within a predetermined period of time that begins 1 sec. after the Polygon Motor has been energized. No new LOCK signal is detected for a 1-sec. period that begins 1.5 sec. after the first LOCK signal was detected. The LOCK signal is not detected for a continuous 0.5-sec. period in a state in which the Polygon Motor runs stably. The LOCK signal remains ON for a continuous 5-sec. period or more when the Polygon Motor remains deenergized.
C133B	Communication with option error	 Communication could not be established with the Controller Control Board within 5 seconds while printing.
C133C	Modem error	A malfunction occurred in the Modem.
C133D	ROM checksum error	A malfunction occurred in the ROM.
C13F0	Laser error	The laser output exceeds the upper limit value.The laser output remains lower than the lower limit value.
C1468	Parameter Chip error	An Parameter Chip not written with initial data was detected.
C14A3	IR lamp malfunction	 The luminosity level of the Exposure Lamp is not stabilized within the predetermined period of time.

20.2 Solution

20.2.1 C0045: Fuser Fan Motor Error

A. Detection Timing

Description

• The LOCK signal remains HIGH or LOW continuously for a predetermined period of time while the Cooling Fan Motor remains energized.

B. Troubleshooting Procedures

Relevant Electric Parts	
Cooling Fan Motor (M2)	Controller/Mechanical Control Board (PWB-P) Power Unit (PU1)

-			
		WIRING DIAGRAM	
Step	Action	Control Signal	Location (Electric Parts)
1	Check the Motor connectors for connec- tion and correct as necessary.	-	_
2	Check the fan for possible overload and correct as necessary.	-	_
3	M2 operation check	PWB-P MPJ13P-1 to 3 (pulse)	B-8
4	M3 operation check	PWB-P MPJ6P-1 to 3 (pulse)	B-9
5	Replace PWB-P.	-	-

20.2.2 C0210: H.V. Abnormal

A. Detection Timing

Г

	Description		
٠	The Drum Charge Monitor Voltage (HVC_MON) signal falls outside a predetermined range at any		
	time after the lapse of a predetermined period of time after the Power Switch has been turned ON.		
٠	The Image Transfer Voltage Monitor signal (T_MON_V) and Image Transfer Current Monitor signal		
	(T_MON_I) fall outside a corresponding predetermined range.		

Relevant Electric Parts	
Fusing Unit	Controller/Mechanical Control Board (PWB-P)

	Step Action	WIRING DIAGRAM	
Step		Control Signal	Location (Electric Parts)
1	Replace Fusing Unit.	-	-
2	Replace PWB-P.	-	-

20.2.3 C0500: Fuser Warm Up Error

A. Detection Timing

Description

- The voltage of the Thermistor remains low for a predetermined period of time when a warm-up cycle is started.
- The temperature detected by the Thermistor remains lower than a reference value for a predetermined period of time for the period of time that begins 5 sec. after, and ends 9 sec. after, the start of the warm-up cycle (where the temperature detected by the Thermistor is 80 °C or less).
- The temperature detected by the Thermistor does not increase for a 3-sec. period or more for the
 period of time that begins after the lapse of a predetermined period of time after the Fusing Roller
 Heater Lamp has been turned ON and ends when the lamp is turned OFF.
- The Fusing Roller Heater Lamp remains ON for a 30-sec. period or more (except during the period through which the Main Motor remains energized).

Relevant Electric Parts		
Fusing Unit	Controller/Mechanical Control Board (PWB-P)	
Thermistor (TH1)	Thermostat (TS1)	
Fusing Roller Heater Lamp (H1)	Power Unit (PU1)	

	Action	WIRING DIAGRAM	
Step		Control Signal	Location (Electric Parts)
1	Replace Thermistor (TH1).	-	-
2	Replace Fusing Unit.	-	-
3	Replace Controller/Mechanical Control Board (PWB-P).	_	_
4	Replace Power Unit (PU1).	-	-

C0510: Fuser Temperature Low 20.2.4

A. Detection Timing

Г

	Description	
•	The temperature detected by the Thermistor remains lower than the set temperature continuously for	
	a predetermined period of time while the fusing temperature control is being provided. (The set tem-	
	peratures are as follows: 140 °C during a print mode at 600 dpi; 70 °C during the standby mode.)	

B. Troubleshooting Procedures

Relevant Electric Parts		
Fusing Unit	Controller/Mechanical Control Board (PWB-P)	
Thermistor (TH1)	Thermostat (TS1)	
Fusing Roller Heater Lamp (H1)	Power Unit (PU1)	

		WIRING DIAGRAM	
Step A	Action	Control Signal	Location (Electric Parts)
1	Replace Thermistor (TH1).	-	-
2	Replace Fusing Unit.	-	-
3	Replace Controller/Mechanical Control Board (PWB-P).	-	-
4	Replace Power Unit (PU1).	-	-

٦

20.2.5 C0520: Fuser Overheat

A. Detection Timing

	Description
•	The temperature detected by the Thermistor remains higher than 235 °C for a predetermined period
	of time while the fusing temperature control is being provided.

B. Troubleshooting Procedures

Relevant Electric Parts		
Fusing Unit	Controller/Mechanical Control Board (PWB-P)	
Thermistor (TH1)	Thermostat (TS1)	
Fusing Roller Heater Lamp (H1)	Power Unit (PU1)	

	Action	WIRING DIAGRAM	
Step		Control Signal	Location (Electric Parts)
1	Replace Thermistor (TH1).	-	-
2	Replace Fusing Unit.	-	-
3	Replace Controller/Mechanical Control Board (PWB-P).	_	_
4	Replace Power Unit (PU1).	-	-

20.2.6 C0650: Scanner Home Sensor Error

A. Detection Timing

	Description
•	The Scanner Home Position Sensor is not detected within the predetermined period of time after the
	Scanner Motor has started turning.

Relevant Electrical Components		
Scanner Motor (M4)	Controller/Mechanical Control Board (PWB-P)	

Step		WIRING DIAGRAM	
	Action	Control Signal	Location (Electric Parts)
1	M4 operation check	-	-
2	Replace PWB-P.	_	_

20.2.7 C1200: ASIC Memory Abnormal

A. Detection Timing

Description

An error occurred while writing to or reading the SRAM on the Control Board (PWB-C).

B. Troubleshooting Procedures

Relevant Electri	cal Components
Controller/Mechanical Control Board (PWB-P)	

		WIRING DIAGRAM	
Step	Action	Control Signal	Location (Electric Parts)
1	Turn the copier off, then on again.	-	-
2	Check the connection of the memory on the PWB-P, and then correct it if neces- sary.	_	_
3	Replace PWB-P.	-	-

20.2.8 C1300: Polygon Mirror Motor Error

A. Detection Timing

	Description
ſ	• The LOCK signal is not detected within a predetermined period of time that begins 1 sec. after the
	Polygon Motor has been energized.

- No new LOCK signal is detected for a 1-sec. period that begins 1.5 sec. after the first LOCK signal was detected.
- The LOCK signal is not detected for a continuous 0.5-sec. period in a state in which the Polygon Motor runs stably.
- The LOCK signal remains ON for a continuous 5-sec. period or more when the Polygon Motor remains deenergized.

Relevant Electric Parts	
PH Unit Flat cable	Controller/Mechanical Control Board (PWB-P)

		WIRING DIAGRAM	
Step	Action	Control Signal	Location (Electric Parts)
1	Check cables for connection and correct	-	-
	as necessary.		
2	Replace PH Unit.	-	-
3	Replace PWB-P.	-	-

20.2.9 C133B: Communication with Option Error

A. Detection Timing

Description

Communication could not be established with the Controller Control Board within 5 seconds while printing.

B. Troubleshooting Procedures

Relevant Electric	cal Components
Controller/Mechanical Control Board (PWB-P)	

		WIRING DIAGRAM	
Step	Action	Control Signal	Location (Electric Parts)
1	Replace PWB-P.	-	-

20.2.10 C133C: Modem Error

A. Detection Timing

Description

A malfunction occurred in the Modem.

	Relevant Electri	cal Components
Network Control Unit Board (NCU)		

		WIRING DIAGRAM	
Step	Action	Control Signal	Location (Electric Parts)
1	Replace NCU.	-	-

20.2.11 C133D: ROM Checksum Error

A. Detection Timing

Description

A malfunction occurred in the ROM.

B. Troubleshooting Procedures

Relevant Electri	cal Components
Controller/Mechanical Control Board (PWB-P)	

Step	Action	WIRING DIAGRAM	
		Control Signal	Location (Electric Parts)
1	Replace PWB-P.	_	_

20.2.12 C13F0: Laser Error

A. Detection Timing

	Description
•	The laser output exceeds the upper limit value.
•	The laser output remains lower than the lower limit value.

B. Troubleshooting Procedures

Relevant Electric Parts		
PH Unit	Controller/Mechanical Control Board (PWB-P)	
Flat cable		

	Action	WIRING DIAGRAM		
Step		Control Signal	Location (Electric Parts)	
1	Check cables for connection and correct as necessary.	-	-	
2	Replace PH Unit.	-	-	
3	Replace PWB-P.	-	-	

bizhub 160/160f bizhub 161/161f

20.2.13 C1468: Parameter Chip Error

A. Detection Timing

	Description
٠	An Parameter Chip not written with initial data was detected.

B. Troubleshooting Procedures

Relevant Electric Parts			
Controller/Mechanical Control Board (PWB-P)			

	Action	WIRING DIAGRAM		
Step		Control Signal	Location (Electric Parts)	
1	Unplug, then plug in the power cord, and turn off the copier, then turn it on again.	_	_	
2	Check the connection of the Parameter Chip on the PWB-P, and then correct it if necessary.	_	_	
3	Replace PWB-P.	-	-	
4	Replace Parameter Chip.	_	-	

20.2.14 C14A3: IR Lamp Malfunction

A. Detection Timing

	Description
•	The luminosity level of the Exposure Lamp is not stabilized within the predetermined period of time.

Relevant Electric Parts		
IR Unit	Controller/Mechanical Control Board (PWB-P)	

	Action	WIRING DIAGRAM		
Step		Control Signal	Location (Electric Parts)	
1	Check the connection of the connectors, and then correct them if necessary.	_	_	
2	Replace PWB-P.	-	-	
3	Replace the Scanner Assy.	-	-	

21. Power supply trouble

21.1 Power is not turned ON.

Relevant Electric Parts			
Controller/Mechanical Control Board (PWB-P)	Power Unit (PU1)		

Step	Check	Wiring Diagram (Location)	Result	Action
1	Is the power cord plugged into the power outlet?	-	NO	Plug the power cord into the power outlet.
2	Is the power cord connected properly to the printer?	-	NO	Plug the power cord into the printer.
3	Is the Power Switch turned ON?	-	NO	Turn ON the Power Switch.
4	Are the fuses (F101 and F102)	-	NO	Replace Power Unit (PU1).
	on the Power Unit conducting?	_	YES	Replace Controller/Mechanical Control Board (PWB-P).
22. Image quality problem

22.1 Troubleshooting Image Quality Problems

- This chapter is divided into two parts: "Initial Checks" and "Troubleshooting for Specific Image Quality Problems".
- If an image quality problem occurs, first go through the "Initial Checks" and, if the cause is still not identified, continue to "Troubleshooting for Specific Image Quality Problems".

22.2 How to Identify Problematic Part

22.2.1 Initial Check Items

• Determine if the failure is attributable to a basic cause or causes.

Section	Step	Check	Result	Action
Installation site	1	The installation size complies with the requirements specified in "PRECAUTIONS FOR INSTALLATION" contained in the "GENERAL" section.	NO	Change the installation site.
Paper	2	The paper meets product specifications.	NO	Instruct the user to use recommended paper that meets product specifica-tions.
	3	The paper is damp.	YES	Change the paper. Instruct the user on the correct methods for stor- ing paper.
Original	4	The document is not flat.	YES	Correct the document.
document	5	Copies of a faint document (written in light pencil, etc.) are being made.	YES	Instruct the user to use a document with an appropriate image density.
	6	Copies of a highly transparent document (OHP film, etc.) are being made.	YES	Instruct the user on how to copy transparent doc- uments.
	7	The Original Glass is dirty or scratched.	YES	Clean or replace the Original Glass.
PM parts	8	PM parts relating to image formation have reached the end of cleaning/replacement cycles.	YES	Clean or replace the PM parts.
Adjustments	9	There are adjustments that can improve image quality problems by being performed again.	YES	Perform the adjustment again.

22.3 Troubleshooting for Specific Image Quality Problems

• Determine if the failure is attributable to the input system (Image Reading Section) or the output system (Engine section).

Check	Result	Cause
Copy made at a reduced zoom ratio	Full-size copy Reduced copy A A 1177T04YA	Input (image reading) system
A 1177T03YA	Full-size copy Reduced copy Image: Copy Image:	Output (printer) system

22.4 Solution

22.4.1 Image Reading System: Blank or Black Prints

<Sample of Image Quality Problem>



A. Troubleshooting Procedures

Step	Check	Result	Action
1	Are there no bent connector pins on the cables connecting the control boards, are all connec- tors correctly plugged in, and are no cables broken?	NO	Correctly plug in the connectors. Replace connection cables.
2	Does the Exposure Lamp light up?	NO	Replace the Scanner Assy.

22.4.2 Image Reading System: Low Image Density

<Sample of Image Quality Problem>

ABODE		ABCDE	
ABCDE ABCDE ABCDE		ABCDE ABCDE ABCDE ABCDE	

Step	Check	Result	Action
1	Is the surface of the Original Glass dirty?	YES	Clean it.
2	Are the Shading Sheet or back surface of the Original Glass dirty?	YES	Clean them.
3	Are the mirror or lens dirty?	YES	Clean them. Replace the Scanner Assy.
4	Is the Exposure Lamp dirty?	YES	Clean it. Replace the Scanner Assy.
5	Are there no bent connector pins on the cables connecting the control boards, are all connec- tors correctly plugged in, and are no cables broken?	NO	Correctly plug in the connectors. Replace connection cables.

22.4.3 Image Reading System: Foggy Background or Rough Image

<Sample of Image Quality Problem>



4011T004AA

Step	Check	Result	Action
1	Does sunlight or any other extraneous light enter the machine?	YES	Protect the copier from extraneous light.
2	Is the document damaged or dirty?	YES	Replace the document.
3	Is the Original Pad dirty?	YES	Clean it.
4	Does the Original Cover not lie flat?	YES	If the Original Cover is deformed or the hinges are damaged, replace the Original Cover.
5	Is the surface of the Original Glass dirty?	YES	Clean it.
6	Are the Shading Sheet or back surface of the Original Glass dirty?	YES	Clean them.
7	Are the mirror or lens dirty?	YES	Clean them. Replace the Scanner Assy.
8	Is the Exposure Lamp dirty?	YES	Clean it. Replace the Scanner.
9	Are there no bent connector pins on the cables connecting the control boards, are all connec- tors correctly plugged in, and are no cables broken?	NO	Correctly plug in the connectors. Replace connection cables.

22.4.4 Image Reading System: Black Streaks or Bands

<Sample of Image Quality Problem>



Step	Check	Result	Action
1	Is the document damaged or dirty?	YES	Replace the document.
2	Is the Original Pad dirty?	YES	Clean it.
3	Does the Original Cover not lie flat?	YES	If the Original Cover is deformed or the hinges are damaged, replace the Original Cover.
4	Is the surface of the Original Glass dirty?	YES	Clean it.
5	Are the Shading Sheet or back surface of the Original Glass dirty?	YES	Clean them.
6	Are the mirror or lens dirty?	YES	Clean them. Replace the Scanner Assy.
7	Is the Exposure Lamp dirty?	YES	Clean it. Replace the Scanner Assy.
8	Are there no bent connector pins on the cables connecting the control boards, are all connec- tors correctly plugged in, and are no cables broken?	NO	Correctly plug in the connectors. Replace connection cables.

22.4.5 Image Reading System: Black Spots

<Sample of Image Quality Problem>



Step	Check	Result	Action
1	Is the document damaged or dirty?	YES	Replace the document.
2	Is the Original Pad dirty?	YES	Clean it.
3	Is the Original Glass dirty?	YES	Clean it.
4	The problem has been eliminated after per- forming step 3.	NO	Replace the Scanner Assy.

22.4.6 Image Reading System: Blank Streaks or Bands

<Sample of Image Quality Problem>



Step	Check	Result	Action
1	Is the document damaged or dirty?	YES	Replace the document.
2	Is the Original Pad dirty?	YES	Clean it.
3	Does the Original Cover not lie flat?	YES	If the Original Cover is deformed or the hinges are damaged, replace the Original Cover.
4	Is the surface of the Original Glass dirty?	YES	Clean it.
5	Are the Shading Sheet or back surface of the Original Glass dirty?	YES	Clean them.
6	Are the mirror or lens dirty?	YES	Clean them. Replace the Scanner Assy.
7	Is the Exposure Lamp dirty?	YES	Clean it. Replace the Scanner Assy.
8	Are there no bent connector pins on the cables connecting the control boards, are all connec- tors correctly plugged in, and are no cables broken?	NO	Correctly plug in the connectors. Replace connection cables.

22.4.7 Image Reading System: Uneven Image

<Sample of Image Quality Problem>



A. Troubleshooting Procedures

Step	Check	Result	Action
1	Is the Scanner Motor drive being transmitted?	NO	Correct drive coupling mechanisms. Replace it.
2	Is the harness of the Exposure Lamp catch- ing?	YES	Correct it.
3	Is there enough slack in the Belt?	NO	Correct it. Replace the Belt.
4	Are the Scanner Rails scratched or dirty?	YES	Clean them.
5	Are there no bent connector pins on the cables connecting the control boards, are all connec- tors correctly plugged in, and are no cables broken?	NO	Correctly plug in the connectors. Replace connection cables.
6	The problem has been eliminated after per- forming step 5.	NO	Replace the Scanner Assy. Replace the IR Unit.

bizhub 160/160f bizhub 161/161f

22.4.8 Printer System: Blank or Black Prints

<Typical Faulty Images>



Step	Check	Result	Action
1	Is a printed page blank?	YES	Check PH Unit connectors for proper connection.
2	Is the coupling of the drive mechanism of the Imaging Cartridge properly connected?	NO	Check coupling of drive mechanism for connection and correct as neces- sary, or replace Imaging Cartridge (Drum Cartridge, Toner Cartridge).
3	Is the drum charge voltage contact point or PC Drum ground contact point of the Imaging Car- tridge properly connected?	NO	Check, clean, or correct contact point.
4	Is the High Voltage Unit (HV1) connector con- nected properly?	NO	Connect it properly.
5	Is the problem eliminated when step 4 was	NO	Replace High Voltage Unit (HV1).
	checked?		Replace Controller/Mechanical Con- trol Board (PWB-P).
			Replace PH Unit.

22.4.9 Printer System: Blank Spots

<Typical Faulty Image>

APCDE ABCDE ABCDE ABCDE	
A3CDE	4011T008AA

A. Troubleshooting Procedures

Step	Check	Result	Action	
1	Is paper damp?	YES	Replace paper for one just unwrapped.	
2	Is the PC Drum scratchy?	YES	Replace Drum Cartridge.	
3	Is there foreign matter on paper path?	YES	Remove foreign matter.	
4	Is Image Transfer Roller dirty or scratchy?	YES	Replace Image Transfer Roller.	
			Replace High Voltage Unit (HV1).	
			Replace Controller/Mechanical Con- trol Board (PWB-P).	

22.4.10 Printer System: Smears on Back

<Typical Faulty Image>



Step	Check	Result	Action
1	Is there foreign matter on paper path?	YES	Remove foreign matter.
2	Is Fusing Roller dirty or scratchy?	YES	Replace Fusing Unit (Fusing Roller).
3	Is Image Transfer Roller dirty or scratchy?	YES	Replace Image Transfer Roller.

22.4.11 Printer System: Low Image Density

<Typical Faulty Image>



Step	Check	Result	Action
1	Is paper damp?	YES	Replace paper for one just unwrapped.
2	Is there toner left in Toner Cartridge?	NO	Replace Toner Cartridge.
3	Is PC Drum faulty (life)?	YES	Replace Drum Cartridge.
4	Is developing bias faulty?	YES	Replace High Voltage Unit (HV1). Replace Controller/Mechanical Con- trol Board (PWB-P).
5	Is image transfer faulty?	YES	Replace Image Transfer Roller.
			Replace High Voltage Unit (HV1).
			Replace Controller/Mechanical Con- trol Board (PWB-P).

22.4.12 Printer System: Foggy Background

<Typical Faulty Image>

ABCDE ABCDE ABCDE ABCDE	
ABCDE	
	4011T004AA

A. Troubleshooting Procedures

Step	Check	Result	Action
1	Is PC Drum scratchy?	YES	Replace Drum Cartridge.
2	Is developing bias contact terminal in good contact with the mating part?	NO	Clean contact terminal or check termi- nal position.
3	Is PH window dirty?	YES	Clean.
4	Is the problem eliminated after checks have	NO	Replace High Voltage Unit (HV1).
	been made up to step 3?		Replace Controller/Mechanical Con- trol Board (PWB-P).

22.4.13 Printer System: Blank Streaks or Bands

<Typical Faulty Images>



Step	Check	Result	Action
1	Is Image Transfer Roller dented, scratchy, or dirty?	YES	Replace Image Transfer Roller.
2	Is PC Drum scratchy or dirty?	YES	Replace Drum Cartridge.
3	Is Fusing Roller scratchy or dirty?	YES	Replace Fusing Unit (Fusing Roller).
4	Is PH window dirty?	YES	Clean.
5	Is the problem eliminated after checks have been made up to step 4?	NO	Replace Controller/Mechanical Con- trol Board (PWB-P).

22.4.14 Printer System: Black Streaks or Bands

<Typical Faulty Images>



A. Troubleshooting Procedures

Step	Check	Result	Action
1	Is paper path dirty with toner?	YES	Clean.
2	Is PC Drum scratchy or dirty?	YES	Replace Drum Cartridge.
3	Is Fusing Roller scratchy or dirty?	YES	Replace Fusing Unit (Fusing Roller).
4	Is the problem eliminated after checks have been made up to step 3?	NO	Replace Controller/Mechanical Con- trol Board (PWB-P).

22.4.15 Printer System: Offset Image

<Typical Faulty Image>



Step	Check	Result	Action
1	Is Fusing Roller faulty?	YES	Replace Fusing Unit (Fusing Roller).
2	Is Image Transfer Roller faulty?	YES	Replace Image Transfer Roller.

22.4.16 Printer System: Uneven Image



<Typical Faulty Images>

Step	Check	Cause	Result	Action
1	Is uneven image at a pitch of 50.6 mm?	Image Transfer Roller is scratchy or dirty.	YES	Replace Image Transfer Roller.
2	Is uneven image at a pitch of 51.8 mm?	Flexible Sleeve is scratchy or dirty.	YES	Replace Toner Cartridge.
3	Is uneven image at a pitch of 75.3 mm?	Fusing Roller/rt is scratchy or dirty.	YES	Replace Fusing Unit.
4	Is uneven image at a pitch of 94.2 mm?	PC Drum is scratchy or dirty.	YES	Replace Drum Cartridge.
		Fusing Roller is scratchy or dirty.	YES	Replace Fusing Unit.

23. FAX error (bizhub 160f/bizhub 161f only)

23.1 Communication Error



23.1.1 Outline

- Error caused by a problem of communication functioning. Five possible causes of errors are:
- 1. Communication is discontinued by a machine error.
- 2. Communication is discontinued by a machine trouble.
- 3. Communication is discontinued by an error occurring at the destination station.
- 4. Communication is discontinued by a protocol error.
- 5. ADF Error on trouble.
- When communication is discontinued due to item 3 or 4, transmission is retried. In other case, transmission is canceled without retry.

23.1.2 Error occurring during transmission

• The transmission error before "Phase-B" performs redial according to the redial interval of each country and the number of times.

The transmission error after "Phase-C" performs redial only one time. Transmission is canceled when an error occurs again. (can change in Soft SW)

When an error occurs by ADF TX, transmission is canceled without redial.



23.1.3 Error occurring during reception

• Reception is canceled.

23.2 Error Code

23.2.1 Reception

Code	Possible Causes of Error.
0001	No G3 signal received within 35 sec. in manual receive mode.
0003	Received DIS after sending DIS signal.
0004	Received DCN after sending DTC signal.
0006	Detect busy tone within receiving phase B.
0009	Can not receive any signal within 35 sec. in manual polling mode.
0010	Received DCN signal after sending DTC signal in polling RX.
0011	Can not receive any correct response after sending three DTC signals.
0012	Remote side Password does not match in polling RX/our side no file to be polled.
0013	Can not receive carrier signal within 6 sec. after sending CFR in data phase C.
0014	Can not receive T.30 signal after sending FTT signal.
0015	Line polarity change within receiving phase B~D.
0016	Receive DCN signal after sending FTT signal.
0017	Can not receive any response from remote side after sending type of xxx_EOM signal.
0018	Can not detect energy within 6 sec. after sending FTT command.
0019	Received DCN signal after sending CFR signal.
001A	No energy on line over 6 sec. within phase C before any corrected ECM frame.
001D	Detect FSK signal, but did not receive any command within 6 sec.
001E	In phase C, have detected FSK signal, but did not receive any command within 6 sec.
0020	Can not correct frame within 6 sec., or in non-ECM mode, one decoding line over 6 sec.
0021	Remote-side disconnect at phase C (V.17).
0022	Owing to noise interference on the line, receiving side can't receive correct data within spec- ified time (no ECM).
0023	 Received "Remote monitoring password" error in RSD. "Utility mode/ Admin.management/ Remote monitor". "Service mode/ Admin. registration." The Customer machine has updated the firmware now. The Service Tech. Rep. updated remote machine firmware by RSD.
0024	 TX and RX machines both have different "machine ID (FAX model ID)" code in RSD. The Customer machine has updated the firmware now. The Service Tech. Ben updated remote machine firmware by RSD.
0025	 TX and BX machines have different "company ID (FAX machine maker ID)"
0023	 TX and TX machines have different company to (TXX machine maker iD) code in RSD. The Customer machine has updated the firmware now. The Service Tech. Rep. updated remote machine firmware by RSD
0026	 Remote monitor level error. Remote side can't access in RSD. The Customer machine has updated the firmware now. The Service Tech. Rep. updated remote machine firmware by RSD
0027	RSD connect failure due to user incorrect operation or machine error.
0029	Mailbox password not programmed or matched for mailbox receiving.
002A	Line Problem
0030	Did not receive any signal within 6 sec.at phase D.

Code	Possible Causes of Error.
0031	Received incorrect signal at phase D (not EOP, MPS, EOM, DCS PPS_Q, PPS_Q, etc.).
0032	Did not receive carrier signal within 6 sec.after sending MCF. or RTP, RTN signal.
0033	Received DCN signal at phase D within pages (not last page).
0039	In non-ECM mode, when machine already received the data but next line data doesn't receive within 13.1 seconds.
003F	Remote side TSI not programmed in machine one touch or speed dial directory.
0040	Did not receive carrier signal within 6 sec. after sending CTR.
0041	Did not receive carrier signal within 6 sec. after sending PPR.
0042	Did not receive correct signal after sending RNR signal.
0043	Received incorrect signal at phase D in ECM mode.
0044	Did not receive carrier signal /FSK signal within 6 sec. after sending MCF in ECM mode.
0045	Did not receive any correct signal after sending RNR response with ERR signal.
0046	Receive incorrect signal when sending RNR response with ERR signal.
0047	Did not receive correct signal after sending ERR signal.
0048	Did not receive correct signal after receiving PPS_PRI_Q or PRI_Q, EOR_PRI_Q.
0049	Did not receive correct signal after sending PIP/PIN signal within 13 sec.
004A	Line energy over threshold lasts for 60 seconds after MCF and can not detect FSK or carrier signal in ECM mode.
004B	Can not detect correct FSK signal even though detected FSK tone within 6 sec.
004C	Command hand shake fail when V.34 RX.
004E	Receive DCN signal after sending DIS in V.34.
004F	Remote side disconnected after sending ANSam in V.8 phase.
0050	Did not receive any correct signal after sending CJ signal in V.8 phase.
0051	Did not receive phase C signal after phase B within 20 seconds in V.34.
0052	Did not receive phase D signal after phase C within 20 seconds in V.34.
0053	Modem disconnect after phase D in V.34.
0054	Remote side disconnected after phase D in V.8.
0055	Receive incorrect signal after sending DIS signal in V.34.
0056	Modem disconnect after sending CFR in V.34.
0057	Did not detect image signal within 6 seconds after sending CFR.
0058	Did not detect image signal within 6 seconds after modem enter to phase A in V.34.
0059	Relay box is not registered even when Relay job has been received.
005A	Modem can not detect any correct ECM frame within 3 minutes in phase C.
005B	Did not detect phase E signal after primary channel within 6 seconds.
005C	Detect busy tone within control channel after phase C.
005D	Remote-side disconnect at phase C (V.34).
005E	Did not detect control channel signal after received RCP frame within 6 seconds.
005F	Did not detect silence after sending JM signal for polling TX function.
0060	There are no bulletin files to be polled in V.34.
0061	Machine can not detect V.21 or V.8 signal within 35 seconds.
0062	Modem disconnect in phase D after our side sending out flag sequence in control channel.
0063	Did not receive any flag sequence in control channel within 6 seconds in phase D.

Code	Possible Causes of Error.
0064	Did not detect any control channel signal in phase D within 60 seconds even though energy still on the line.
0065	Did not detect any control channel signal within 60 seconds after detect silence in phase D.
0066	Did not receive T.30 signal or carrier signal after sending CFR in V.34.
0070	User presses stop key during receiving.
0071	Memory full during receiving.

23.2.2 Transmission

Code	Possible Causes of Error.			
0080	Did not detect any G3 signal within 35 sec. specified by ITU-T in phase B.			
0081	Received DTC signal in transmission phase.			
0082	Transmitting unit receives a signal other than DIS or DTC. and DCN in phase B.			
0083	Detected FSK signal, but did not receive any signal within 35 seconds.			
0084	Detect DCN signal in phase B.			
0085	Transmitting unit sending DCS 3 times consecutively, but each time receiver responds with DIS/DTC.			
0086	Detected response signal other than DTC, DIS, FTT, DCN or CFR after sending DCS.			
0087	Training attempt has failed because speed unit cannot adjust to low lower speed.			
0088	Received DCN signal after sending out DCS signal.			
0089	Remote side no mailbox function or not compatible.			
008A	Remote side not enough memory for relay initiate.			
008B	Receiver's protocol of DIS is received, but it is not compatible with our machine.			
008C	Remote side not enough memory for relay initiate.			
008D	Receiver's protocol of DIS is received, but remote side can't receive document temporary, may be run out of paper or other reason.			
008E	Remote side CSI number not defined in machine one touch or speed dial directory.			
008F	Modem not ready to receive V.34 data during 6 seconds after receiving CFR signal.			
0090	Called side document not ready for our polling.			
0091	Sending out DCS+TCF signal 3 times consecutively but no signal in response from receiver.			
0092	Remote side disconnected during transmitting phase.			
0093	Received DCN signal after sending out DCS signal for V.34.			
0094	It is over 4 minutes to TX a ECM block (64K).			
0095	Wrong ID number when Polling RX or Mail Box TX.			
0099	Remote side disconnect after primary channel.			
009A	Did not detect any signal after sending CI signal.			
009C	Received DCN after sending DTC in V.34 polling RX.			
009D	Remote side hang up before V.34 modem enters phase B state in V.34 polling RX.			
009F	Did not receive any response from other side after sending PPS_EOM signal.			
00A0	User stops or cancels transmission job.			
00A1	Document JAM during transmission.			
00AE	Did not finish V.8 procedure or detect V.21 signal after CM signal within 30 seconds.			
00AF	Modem can not enter into control channel after TX side sends out RCP signal for V.34.			
00B0	Did not receive any command after our side retry three DCS signal in V.34 TX.			

Code	Possible Causes of Error.
00B1	Did not finish V.8 procedure or detect V.21 signal after ANSam signal within 35 seconds.
00B2	Did not detect phase B signal after our side sending CJ signal within 30 seconds.
00B3	Did not detect correct V.21 or JM signal after sending CM signal.
00B4	Did not detect correct phase B signal within 25 second after CM/JM signal exchange.
00B5	Did not detect phase C signal after phase B within 25 seconds.
00B6	Did not detect phase D signal within 25 seconds after CM/JM exchange.
00B7	Did not detect phase E signal after phase D within 30 seconds.
00B8	Remote side disconnect after our side sent DCS signal in V.34.
00B9	Receive T.30 signal other than DIS, DCS, CFR after sending DCS signal in V.34.
00BA	Did not receive correct signal after our side sent DTC signal in V.34.
00BB	Every time our side received DIS signal after sending DTC in V.34.
00BC	Modem not ready within 10 second after entering primary channel in V.34.
00BD	Can not detect correct V.21 or JM signal after detected FSK frequency.
00BE	Remote side no document to be polled after V8 handshaking.
00BF	Capability not match after V8 handshaking.
00C0	Remote side disconnect before entering primary channel in V.34.
00C1	At phase-D, transmitting unit sends out EOP 3 times consecutively, but receives no answer from receiving unit.
00C2	Remote side disconnect after sending out V.8 CM signal.
00C4	After sending MPS signal, the received signal is not one of MCF, RTN, PIP, PIN, RTP, DCN.
00C5	Received DCN signal after sending MPS signal.
00C9	At phase-D, sending MPS 3 times consecutively, but no answer from receiving unit.
00CA	After sending EOP signal, the received signal is not one of MCF, RTN, PIP, PIN, PRI-EOP, DCN.
00CB	After sending EOP signal, the received signal is DCN signal.
00CC	After sending EOM signal, the received signal is not one of MCF, RTN, PIP, PIN, RTP, DCN.
00CD	At phase-D, transmitting unit sends out EOM 3 times consecutively, but receives no answer.
00CE	At phase-D, transmitting unit sends out EOM, but receives DCN.
00CF	Received incorrect signal after sending DTC signal for V.34 polling.
00D0	Received ERR signal after sending EOR_NULL.
00D1	ECM TX received wrong command in phase D after PPS-EOP. (not PPR, MCF, PIP, PIN,).
00D2	Receive DCN after send command PPS-EOP signal.
00D3	Received DCN after sending PPS_NULL signal.
00D4	Received DCN after sending PPS_EOM signal.
00D8	Did not detect correct phase C signal for polling within 25 seconds.
00D9	Did not detect correct phase C signal after detecting silence after phase B.
00DA	Did not detect phase D signal within 30 seconds or remote side hang up over 6 seconds.
00DB	Did not receive any T.30 signal within 15 seconds in phase D.
00DC	Received T.30 signal in phase D other than DCS,DIS or DTC.
00DD	Remote side not the same model or no mailbox ID defined for mailbox TX.
00DE	Remote side no SUB capability in V.34.

Code	Possible Causes of Error.
00E0	At phase-D, transmitting unit sends out PPS_NULL 3 times consecutively but receives no answer.
00E1	Received incorrect response after sending PPS_NULL.
00E2	Did not receive any response in RR response procedure after sending PPS_NULL.
00E4	At phase-D, transmitting unit sends out PPS_MPS 3 times consecutively but no answer.
00E5	Received incorrect response after sending PPS_MPS.
00E6	Did not receive any response in RR response procedure after sending PPS_MPS.
00E7	Received DCN after sending PPS_MPS.
00E8	At phase-D, transmitting unit sends out PPS_EOP 3 times consecutively but no answer.
00E9	Receive PIN signal after sent last page three times.
00EA	Did not receive any response in RR response procedure after sending PPS_EOP.
00EB	At phase-D, transmitting unit sends out PPS_EOM 3 times consecutively but no answer.
00EC	Received incorrect response after sending PPS_EOM.
00ED	Did not receive any response in RR response procedure after sent out PPS_EOM.
00EE	At phase-D, transmitting unit sends out EOR_NULL 3 times consecutively but no answer.
00EF	Received incorrect response after sending EOR_NULL.
00F0	Did not receive any response procedure after sending EOR_NULL.
00F1	At phase-D, transmitting unit sends out EOR_MPS 3 times consecutively but no answer.
00F2	Received incorrect response after sending EOR_MPS.
00F3	Received ERR signal after sending EOR_MPS.
00F4	Did not receive any response in RR response procedure after sending EOR_MPS.
00F5	At phase-D, transmitting unit sends out EOR_EOP 3 times consecutively but no answer.
00F6	Received incorrect response after sending EOR_EOP.
00F7	After Received ERR, our side can not receive response after sending EOR_EOP command.
00F8	At phase-D, transmitting unit sends out EOR_EOM 3 times consecutively but no answer.
00F9	Received incorrect response after sending EOR_EOM.
00FA	Received ERR signal after sending EOR_EOM.
00FB	Did not receive any response in RR response procedure after sending EOR_EOM.
00FC	Did not receive any response after sending CTC.
00FD	Can't speed down to lower speed in ECM mode.
00FE	Memory full for transmission.
00FF	Redial all fail.

Blank page

Appendix

24. Parts layout drawing

24.1 Main Unit



- [1] Controller/Mechanical control Board (PWB-P)
- [2] High Voltage Unit (HV1)
- [3] Thermistor (TH1)
- [4] Cooling Fan Motor 2 (M3)
- [5] Control Panel (PWB-O)
- [6] Front Door Switch (S2)
- [7] Paper Take-Up Switch (S1)
- [8] Multi purpose Tray Paper Empty Sensor (PE1)
- [9] Multiple Bypass Tray Paper Empty Sensor (PE2)
- [10] Toner Empty detection sensor (TE1)
- [11] Paper Take-Up Solenoid (SL1)
- [12] Main Motor (M1)
- [13] Cooling Fan Motor 1 (M2)

- [14] Plat NIC Board (NIC-IF)
- [15] Battery (BATT1)
- [16] Speaker (SP1)
- [17] NCU Board (PWB-NCU)
- [18] Interface Board (PWB-IF)
- [19] Scanner Motor (M4)
- [20] Power Unit (PU1)
- [21] Fusing Roller Heater Lamp (H1)
- [22] Network Interface Card Board (PWB-NIC)
- [23] Original Cover set sensor (PS2)
- [24] Thermostat (TS1)
- [25] PCL Board (PWB-PCL)
- [26] Exit Sensor (PS1)

24.2 DF-501 (Option)



- Control Board (PWB-A DF) [1]
- Paper take-Up Sensor (PC2-DF) [2]
- Paper take-Up clutch (CL1-DF) [3]
- Leading Edge Detection Sensor (PC3-DF) [4]
- Main Motor (M5-DF) [5]
- DF door set switch (S3-DF) [6]
- Original detection Sensor (PC1-DF) [7]

bizhub 160/160f bizhub 161/161f

24.3 PF-501 (Option)



- 2nd Drawer Control Board (PWB-A PF) [1]
- [3] 2nd Drawer Take-up solenoid (SL2-PF)
- [2] Cassette type Detecting Switch (SW1-PF)

bizhub 160/160f bizhub 161/161f

25. Connector layout drawing



25.1 Main Unit



No.	CN	No.	Location	No.	CN	No.	Location
[1]	CN3	2P	C-7	[4]	CN2	2P	C-7
[2]	CN7	2P	C-9	[5]	CN6	3P	C-8
[3]	CN8	3P	C-9	[6]	CN5	4P	C-6



SERVICE MANUAL



DF-501

Confidential - for internal use only, do not distribute

2005.04 KONICA MINOLTA BUSINESS TECHNOLOGIES, INC. Ver. 1.0

Confidential - for internal use only, do not distribute

After publication of this service manual, the parts and mechanism may be subject to change for improvement of their performance.

Therefore, the descriptions given in this service manual may not coincide with the actual machine.

When any change has been made to the descriptions in the service manual, a revised version will be issued with a revision mark added as required.

Revision mark:

- To indicate clearly a section revised, show \triangle to the left of the revised section. A number within \triangle represents the number of times the revision has been made.
- To indicate clearly a section revised, show **A** in the lower outside section of the corresponding page.

A number within **A** represents the number of times the revision has been made.

NOTE

Revision marks shown in a page are restricted only to the latest ones with the old ones deleted.

- When a page revised in Ver. 2.0 has been changed in Ver. 3.0: The revision marks for Ver. 3.0 only are shown with those for Ver. 2.0 deleted.
- When a page revised in Ver. 2.0 has not been changed in Ver. 3.0: The revision marks for Ver. 2.0 are left as they are.

2005/04	1.0		Issue of the first edition
Date	Service manual Ver.	Revision mark	Descriptions of revision

Confidential - for internal use only, do not distribute

Confidential - for internal use only, do not distribute

CONTENTS

General Product specification1

Maintenance

1.

2. P	Periodical check	3
2.1	Maintenance procedure	3
2.1.1	1 Feed Roller	3
2.1.2	2 Pick-Up Roller	5
2.1.3	3 Removal of the Pick-Up Roller	5
2.1.4	4 Registration Rollers	5
2.1.5	5 Exit Roller	6
2.1.6	6 Paper Separation Pad	6
3. C	Other	7
3.1	Disassembly/Assembly list (Other Parts)	7
3.2	Disassembly/Assembly procedure	7
3.2.1	1 External Parts	7
3.2.2	2 Control Board	8
3.2.3	3 Main Motor	9

Adjustment/Setting

4	How to	use the adjustment section	11
5	Servic	e Mode	12
J.	A	coince the Corrige Mode	10
5.1	Acce	ssing the Service Mode	12
5.1	1.1	Accessing the "ADJUST" Menu	12
5.1	1.2	Printing a Test Page	12
5.2	ADJU	JST	13
5.2	2.1	ADF SUB ZOOM	13
5.2	2.2	ADF MAIN REGIST	14
5.2	2.3	ADF SUB REGIST	15
5.3	FUN	CTION	16
5.3	3.1	ADF FEED TEST	16
6.	Mecha	nical adjustment	17
6.1	Heigl	ht Adjustment	17
6.2	Lead	ing Edge Tilt Adjustment	18

Troubleshooting

7.	Paper Misfeed	19
7.1	Initial Check Items	19
7.2	Paper Misfeed Displays	19
7.3	Locations of Misfeed Detection Sensors	20
7.4	Misfeed Detection Timing and Troubleshooting Procedures	21
7.4	4.1 The Original misfeeds	21
8.	Timing Chart	22

General

1. Product specification

Name	Automatic Document Feeder		
Installation method	Inserted at upper-rear side of main unit		
Original type	Plain paper: 35 to 128 g/m ² (9 to 34 lb.)		
Detectable Original sizes	A5, B5, A4, 8.5 \times 14 (Legal), 8.5 \times 11 (Letter), 5.5 \times 8.5 (Invoice), Custom size width: 138 to 216 mm; length: 130 to 356 mm		
Paper capacity	Maximum 50 sheets (80 g/m ²) (21 lb)		
Registration	Center		
Original loading orientation	Face up		
Productivity	12 sheets/minute (with plain A4 or Letter paper)		
Original feeding Mode	Standard mode		
Power source	DC 24 V, DC 5 V (supplied by main unit)		
Power consumption	Less than 30 W		
Dimension	W: 497 mm × D: 355 mm × H: 80 mm (W: 19.5 inch × D: 14 inch × H: 3.25 inch)		
Weight	3.2 kg (7 lb)		
Operating environment	Same as the copier		

Original types	Possible problems
Originals bound with staples or paper clips	Incorrect paper take-up, damaged originals or drive malfunctions due to jammed paper clips
Originals bound with glue	Incorrect paper take-up or damaged originals
Folded, torn or extremely wrinkled originals	Incorrect paper take-up or damaged originals
Curled originals (more than 10 mm from front edge)	Paper misfeeds due to folded or skewed originals

Blank page

Periodical check

Feed Roller A. Cleaning of the Feed Roller 1. Open the Document Feeder Cover.

Maintenance

2.

2.1

2.1.1

DF-501

Maintenance procedure

1382E002AA

B. Replacement of the Feed Roller







2. Using a soft cloth, wipe clean the surface of the Feed Roller.

- 1. Open the Document Feeder Cover.
- 2. Remove the two screws, and then remove the Document Feeder Cover.

3. Remove the screw, and then remove the mounting plate and spring.

NOTE

- · Be extremely careful not to lose the spring.
- 4. Remove the two Document Stoppers.



5. Remove the Pick-Up Roller/Feed Roller Assy.

NOTE

- When installing the Pick-Up Roller/ Feed Roller Assy., make sure that the notch in the shaft of the Feed Roller is positioned on the top.
- 6. Remove the Feed Roller.

DF-501

A. Cleaning of the Pick-Up Roller

1. Open the Document Feeder Cover.



2.1.3 Removal of the Pick-Up Roller



2.1.4 Registration Rollers

A. Cleaning of the Registration Rollers

1. Open the Document Feeder Cover.



B. Cleaning of the Transport Roller

1. Open the Document Feeder Cover.



2. Using a soft cloth, wipe clean the surface of the Pick-Up Roller.

- 1. Remove the Pick-Up Roller/Feed Roller Assy.
- 2. Remove the Pick-Up Roller.

2. While turning the Document Feed Knob in the direction shown in the illustration, use a soft cloth to wipe clean the Registration Rollers.

2. Using a soft cloth, wipe clean the surface of the Transport Roller.

DF-501
2.1.5 Exit Roller

A. Cleaning of the Exit Roller

1. Open the Document Feeder Cover.



2.1.6 Paper Separation Pad

A. Cleaning of the Paper Separation Pad

1. Open the Document Feeder Cover.



B. Removal of the Paper Separation Pad

1. Open the Document Feeder Cover.





2. While turning the Document Feed Knob in the direction shown in the illustration, use a soft cloth to wipe clean the Exit Roller.

2. Using a soft cloth, wipe clean the surface of the Paper Separation Pad.

2. Remove the Paper Separator Cover.

- Loosen the two screws, and then remove the Paper Separation Pad.
 NOTE
- Be extremely careful not to lose the spring on the Paper Separation Pad.

6

3. Other

3.1 Disassembly/Assembly list (Other Parts)

No	Section	Part name	Ref. page
1	External Parts	Document Feeder Cover	r⊛ 7
2		Document Feeder Tray	r⊛ 7
3		Rear Cover	r⊛ 7
4	Board	Control Board	r⊛ 8
5	Other	Main Motor	r⊛ 9

3.2 Disassembly/Assembly procedure

3.2.1 External Parts



No.	Name	Removal Procedure
1	Document Feeder Cover	 Open the Document Feeder Cover. Remove the two screws. Remove the Document Feeder Cover.
2	Document Feeder Tray	 Open the Document Feeder Cover. Remove the Rear Cover. Remove the screw. Remove the Document Feed Knob. Remove the two screws. Remove the Document Feeder Tray.
3	Rear Cover	 Remove the screw. Remove the Rear Cover.

DF-501

3. Other

3.2.2 Control Board

NOTE

- When removing a circuit board, refer to the precautions for handling printed circuit boards and follow the corresponding removal procedures.
- The following removal procedures omit the removal of the applicable component from connectors and circuit board supports.
- When it is necessary to touch ICs and other electrical components on the circuit board, be sure to first ground yourself.



A. Removal of the Control Board







 Remove the screw, unhook the six tabs, and then remove the Rear Cover.

2. Unplug all connectors connected to the circuit board.

3. Remove the two screws, and then remove the Automatic Document Feeder Control Board.

DF-501

3.2.3 Main Motor

- A. Removal of the Main Motor
- 1. Remove the Rear Cover.



- 2. Unplug the connector on the Control Board.
- *3.* Remove the two screws, and then remove the Main Motor.

Blank page

Adjustment/Setting

4. How to use the adjustment section

- "Adjustment/Setting" contains detailed information on the adjustment items and procedures for this machine.
- Throughout this "Adjustment/Setting," the default settings are indicated by " ".

A. Advance Checks

- Before attempting to solve the customer problem, the following advance checks must be made. Check to see if:
- 1. The power supply voltage meets the specifications.
- 2. The power supply is properly grounded.
- 3. The machine shares the power supply with any other machine that draws large current intermittently (e.g., elevator and air conditioner that generate electric noise).
- 4. The installation site is environmentally appropriate: high temperature, high humidity, direct sunlight, ventilation, etc.; levelness of the installation site.
- 5. The original has a problem that may cause a defective image.
- 6. The density is properly selected.
- 7. The Original Glass, slit glass, or related part is dirty.
- 8. Correct paper is being used for printing.
- 9. The units, parts, and supplies used for printing (developer, PC Drum, etc.) are properly replenished and replaced when they reach the end of their useful service life.
- 10. Toner is not running out.

B. Precautions for Service Jobs

- 1. To unplug the power cord of the machine before starting the service job procedures.
- 2. If it is unavoidably necessary to service the machine with its power turned ON, use utmost care not to be caught in the Scanner Cables or gears of the Exposure Unit.
- 3. Special care should be used when handling the Fusing Unit which can be extremely hot.
- 4. The Developing Unit has a strong magnetic field. Keep watches and measuring instruments away from it.
- 5. Take care not to damage the PC Drum with a tool or similar device.
- 6. Do not touch IC pins with bare hands.

5. Service Mode

5.1 Accessing the Service Mode

- 1. Press the Utility key.
- 2. Press the following keys in order to enter the Service mode. Stop $\rightarrow 0 \rightarrow 0 \rightarrow Stop \rightarrow 0 \rightarrow 1$

NOTE

• Be sure to keep the access procedure for the Service mode from any unauthorized persons not involved with service operations.

5.1.1 Accessing the "ADJUST" Menu

- 1. Enter the Service mode.
- 2. Press the \blacktriangle or \blacktriangledown key to select the "ADJUST" menu.

5.1.2 Printing a Test Page

NOTE

- Print a test page when making the following adjustments.
- · Leading edge tilt adjustment
- Automatic Document Feeder sub-scanning zoom ratio adjustment
- Automatic Document Feeder main scanning & sub-scanning registration adjustments
- 1. Enter the Service mode.
- 2. Press the \blacktriangle or \blacktriangledown key to select the function.
- 3. Select "PRINT TEST PATTERN" \rightarrow "TEST PATTERN 1".
- 4. Press the Start key to begin printing the test page.

5.2 ADJUST

5.2.1 ADF SUB ZOOM

Functions	 To adjust for variations in the accuracy of all parts and their mounting accuracy by varying the scanning zoom ratio in the sub-scanning direction when using the Auto- matic Document Feeder. 		
Use	 When the Upper Cover Assy. (Original Glass) has been replaced When the ADF has been replaced 		
Adjustment Specification	 Adjust the length of E in the copy of the test pattern so that the following specification is met. Specifications 200 ± 0.5 % (Zoom Ratio = Full Size: 100 %) Setting Range 95 to 105 (1 increment = 0.4 %) The default setting is "100" 		
Adjustment Instruction	If the width of E in the test pattern is longer than the specified width. Decrease the setting. If the width of E in the test pattern is shorter than the specified width. Increase the setting.		
Adjustment Procedure	 Print the test pattern. Enter the "ADJUST" menu in the Service mode. Load the test pattern into the Automatic Document Feeder and make a test copy. 		
	NOTE The test pattern should be positioned vertically. Use A4 or Letter paper loaded into Tray 1 to make the test copy. 		
	 4. If the length of E in the copy of the test pattern is not the same as the length of E in the test pattern, adjust it according to the following procedure. 5. Change the setting. If the shift cannot be adjusted to within the specification with a single adjustment, perform the adjustment again to change the setting. 6. Press the Yes key to apply the setting. 		
 NOTE If the Stop key is pressed, instead of the Yes key, the main screen is and the setting returns to that before it was changed. Load the test pattern into the Automatic Document Feeder again, matest copy, and check it. 			

DF-501

5.2.2 ADF MAIN REGIST

Functions	 To adjust for variations in the accuracy of all parts and their mounting accuracy by varying the scanning start position in the main scanning direction when using the Automatic Document Feeder. 		
Use	 After the ADF SUB ZOOM adjustments have been performed When the Upper Cover Assy. (Original Glass) has been replaced When the ADF has been replaced 		
Adjustment Specification	B A 1382D011AA	 After finishing the ADF SUB ZOOM adjustments. Adjust the amount that widths A and B in the printed test pattern are shifted so that the following specification is met. Specifications 0 ± 2.0 mm Setting Range 	
		90 to 110 (1 increment = 0.5 mm) The default setting is "100"	
Adjustment Instruction	If the width of A is less than the width of B Increase the setting. If the width of B is less than the width of A Decrease the setting.		
Adjustment Procedure	ant 1. Print the test pattern. re 2. Enter the "ADJUST" menu in the Service mode. 3. Load the test pattern into the Automatic Document Feeder and make a test copy NOTE • The test pattern should be positioned vertically.		
	 4. Fold the copy of the test pattern in half, and then check if the fold aligns with the centerline. If they are not aligned, adjust it according to the following procedure. 5. Change the setting. If the shift cannot be adjusted to within the specification with a single adjustment, perform the adjustment again to change the setting. 6. Press the Yes key to apply the setting. 		
	 NOTE If the Stop key is pressed, instead of the Yes key, the main screen is displayed and the setting returns to that before it was changed. Load the test pattern into the Automatic Document Feeder again, make another test copy, and check it. 		

5.2.3 ADF SUB REGIST

Functions	 To adjust for variations in the accuracy of all parts and their mounting accuracy by varying the scanning start position in the sub-scanning direction when using the Auto- matic Document Feeder. 		
Use	 After the PRN MAIN REGIST and PRN SUB REGIST and CCD SUB ZOOM adjustments have been performed After the ADF SUB ZOOM adjustments have been performed When the Upper Cover Assy. (Original Glass) has been replaced When the ADF has been replaced 		
Adjustment Specification	 After finishing the ADF SUB ZOOM adjustments. Adjust the width of C in the printed test pattern so that the following specification is met. Specifications 20 ± 3.0 mm Setting Range 90 to 110 (1 increment = 0.5 mm) 		
	The default setting is "100"		
Adjustment Instruction	If the width of C in the test pattern is longer than the specified width Increase the setting. If the width of C in the test pattern is shorter than the specified width Decrease the setting.		
Adjustment Procedure	 Print the test pattern. Enter the "ADJUST" menu in the Service mode. Load the test pattern into the Automatic Document Feeder and make a test copy. NOTE The test pattern should be positioned vertically. Use A4 or Letter paper loaded into Tray 1 to make the test copy. 		
	 Check that the width of F in copy of the test pattern meets the specification. If the width of F is out of specification, adjust it according to the following procedure. Change the setting. If the shift cannot be adjusted to within the specification with a single adjustment, perform the adjustment again to change the setting. Press the Yes key to apply the setting. 		
	 NOTE If the Stop key is pressed, instead of the Yes key, the main screen is displayed and the setting returns to that before it was changed. Load the test pattern into the Automatic Document Feeder again, make another test copy, and check it. 		

DF-501

5.3 FUNCTION

5.3.1 ADF FEED TEST

Functions	To check the paper feeding in the paper take-up/transport sections in the Auto- matic Document Feeder.
Use	When a document misfeed occurs
Setting/Procedure	 Load paper into the Automatic Document Feeder. Press the Start key to begin testing paper feeding. Press the Stop key to stop testing paper feeding.

DF-501

6. Mechanical adjustment

6.1 Height Adjustment





 Check the gap between the Original Glass and the spacer on the Automatic Document Feeder.

NOTE

- Be sure to open, then close the Automatic Document Feeder, and then check during pre-lighting of the scanner.
- 2. If there is a gap, perform the adjustment described in step 3.

3. Turn the adjusting screw in the hinge of the Automatic Document Feeder until the spacer contacts the Original Glass.

Screw rotation direction

Clockwise: Raises the Automatic Document Feeder.

Counterclockwise: Lowers the Automatic Document Feeder.

6.2 Leading Edge Tilt Adjustment

1. Print the test pattern.











2. Draw lines 100 mm (A and B) from the center of the test pattern, as shown in the illustration.

 Load the test pattern into the Automatic Document Feeder, and then print five single-sided copies.

NOTE

- The test pattern should be positioned vertically.
- 4. Measure the lengths a and b on the copies of the test pattern and, if there is a large shift, adjust it according to the following procedure. Standard values of a and b = ? 1.0 mm

<If A is longer than B>

Using a con, loosen the shoulder screw shown in the illustration, and then slide the scale on the Automatic Document Feeder toward you. NOTE

 After finishing the adjustment, be sure to tighten the loosened shoulder screw.

<If A is shorter than B>

Using a coin, loosen the shoulder screw shown in the illustration, and then slide the scale on the Automatic Document Feeder away from you. NOTE

 After finishing the adjustment, be sure to tighten the loosened shoulder screw.

DF-501

Troubleshooting

7. Paper Misfeed

7.1 Initial Check Items

• When a paper misfeed occurs in the printer, first make the following initial checks.

Check	Action
Does the paper meet product specifications?	Replace paper.
Is the paper curled, wavy, or damp?	Replace paper. Instruct user in correct paper storage.
Is the paper transport path deformed, dirty, or obstructed with foreign matter?	Clean the paper path and replace if necessary.
Is the roller dirty, deformed, or worn?	Clean the roller and replace if necessary.
Are Edge Guides at correct position to accommodate paper?	Slide the Edge Guides up against the edges of the paper stack.
Does the actuator operate correctly when checked?	Correct or replace the actuator.

Precautions for Clearing Misfeed

 Reset the misfeed condition by opening and closing the Front Door after the misfeed has been cleared.

7.2 Paper Misfeed Displays

• The Error indicator lights up and a message appears in the display when a paper misfeed occurs.

A. Automatic Document Feeder Misfeed



B. Procedure for canceling the misfeed display

- 1. Open the appropriate covers, remove the misfed paper and any remaining paper, and then close the covers.
- 2. Open, then close the Front Door.

7.3 Locations of Misfeed Detection Sensors



DF-501

7.4 Misfeed Detection Timing and Troubleshooting Procedures

7.4.1 The Original misfeeds

A. Detection Timing

Туре	Description
ADF Jam	 The Paper Take-Up Sensor is not unblocked after the predetermined period of time has elapsed after document feeding began. The Paper Take-Up Sensor is not blocked after the predetermined period of time has elapsed after the Paper Take-Up Sensor is unblocked. The Exit Sensor is not unblocked after the predetermined period of time has elapsed after the Paper Take-Up Sensor is unblocked. The Exit Sensor is not blocked after the predetermined period of time has elapsed after the Paper Take-Up Sensor is unblocked. The Exit Sensor is not blocked after the predetermined period of time has elapsed after the Paper Take-Up Sensor is unblocked.
ADF remains paper jam	 If all of the following conditions are met The Automatic Document Feeder is in standby. The Document Feeder Cover is closed. The Original Detection Sensor is blocked. Either the Paper Take-Up Sensor or the Leading Edge Detection Sensor or both sensors are blocked.

B. Troubleshooting Procedures

Relevant Electrical Parts		
Original Detection Sensor (PC1) Paper Take-Up Sensor (PC2) Leading Edge Detection Sensor (PC3)	Control Board (PWB-A DF)	

Step	Action	WIRING DIAGRAM		
		Control Signal	Location (Electrical Component)	
1	Initial checks	-	-	
2	PC1-DF sensor check	PWB-A DF PA02A DF-1	F-5	
3	PC2-DF sensor check	PWB-A DF PA06A DF-1	F-4	
4	PC3-DF sensor check	PWB-A DF PA03A DF-1	F-4	
5	Replace PWB-A DF.	-	_	



DF-501



SERVICE MANUAL



PF-501

Confidential - for internal use only, do not distribute

2005.04 KONICA MINOLTA BUSINESS TECHNOLOGIES, INC. Ver. 1.0

After publication of this service manual, the parts and mechanism may be subject to change for improvement of their performance.

Therefore, the descriptions given in this service manual may not coincide with the actual machine.

When any change has been made to the descriptions in the service manual, a revised version will be issued with a revision mark added as required.

Revision mark:

- To indicate clearly a section revised, show \triangle to the left of the revised section. A number within \triangle represents the number of times the revision has been made.
- To indicate clearly a section revised, show **A** in the lower outside section of the corresponding page.

A number within **A** represents the number of times the revision has been made.

NOTE

Revision marks shown in a page are restricted only to the latest ones with the old ones deleted.

- When a page revised in Ver. 2.0 has been changed in Ver. 3.0: The revision marks for Ver. 3.0 only are shown with those for Ver. 2.0 deleted.
- When a page revised in Ver. 2.0 has not been changed in Ver. 3.0: The revision marks for Ver. 2.0 are left as they are.

2005/04	1.0		Issue of the first edition
Date	Service manual Ver.	Revision mark	Descriptions of revision

CONTENTS

General

1.	Product specification	Í.
	•	

Maintenance

2.	Period	dical check	3
2.1	Mair	ntenance procedure	3
2.1	1.1	Feed Roller	3
3.	Other		.4
3.1	Disa	assembly/Assembly list (Other parts)	.4
3.2	Disa	assembly/Assembly procedure	4
3.2	2.1	External Parts	4
3.2	2.2	2nd Drawer Control Board	.5
3.2	2.3	2nd Drawer Paper Take-Up Unit	5
3.2	2.4	Cassette Type Detecting Switch	6
3.2	2.5	2nd Drawer Take-up Solenoid	6

Blank page

General

1. Product specification

Name	2nd Paper Feed Cassette
Type of paper	Plain and recycled paper: 60 to 90 g/m ² (16 to 24 lb)
Media sizes	A4 and Letter
Paper capacity	Maximum 500 sheets (80 g/m ²) (21 lb)
Registration	Center
Power source	DC 24 V, DC 5 V (supplied by main unit)
Power consumption	Less than 7 W
Dimension	W: 401 mm × D: 615 mm × H: 138 mm (W: 15.75 inch × D: 24.25 inch × H: 5.5 inch)
Weight	4.3 kg (9.5 lb)
Environment	Same as the copier

Blank page

PF-501

Maintenance

2. Periodical check

2.1 Maintenance procedure

2.1.1 Feed Roller

A. Cleaning of the Feed Roller

1. Raise the main unit to separate it from the Paper Feed Cassette.



2. Using a soft cloth, wipe clean the surface of the Feed Roller.

B. Replacement of the Feed Roller

1. Raise the main unit to separate it from the Paper Feed Cassette.



2. Remove the Feed Roller at the two points indicated.

3. Other

3. Other

3.1 Disassembly/Assembly list (Other parts)

No	Section	Part name	Ref. page
1	External Parts	Rear Cover	r⊛ 4
2		Right Cover	r≊ 4
3		Left Cover	ræ 4
4	Board	2nd Drawer Control Board	r≊ 5
5	Other	2nd Drawer Paper Take-Up Unit	r≊ 5
6		Cassette Type Detecting Switch	r⊛ 6
7		2nd Drawer Take-up Solenoid	r∞ 6

3.2 Disassembly/Assembly procedure

3.2.1 External Parts



No.	Name	Removal Procedure
1	Rear Cover	1. Remove the four screws. 2. Remove the Rear Cover.
2	Right Cover	 Remove the Rear Cover. Remove the two screws. Remove the Right Cover.
3	Left Cover	 Remove the Rear Cover. Remove the two screws. Remove the Left Cover.

3.2.2 2nd Drawer Control Board

NOTE

- When removing a circuit board, refer to the precautions for handling printed circuit boards and follow the corresponding removal procedures.
- The following removal procedures omit the removal of the applicable component from connectors and circuit board supports.
- When it is necessary to touch ICs and other electrical components on the circuit board, be sure to first ground yourself.



A. Removal of the 2nd Drawer Control Board

1. Remove the 2nd Paper Take-Up Unit.



- 2. Remove the screw, and then remove the cover.
- 3. Remove the two screws, unplug the connector, and then remove the 2nd Drawer Control Board.
- 3.2.3 2nd Drawer Paper Take-Up Unit

A. Removal of the 2nd Drawer Paper Take-Up Unit

1. Raise the main unit to separate it from the Paper Feed Cassette.



2. Unhook the two tabs, and then remove the cover.

PF-501





3. Remove the actuator.

 Remove the six screws, unplug the two connectors, and then remove the 2nd Drawer Paper Take-Up Unit.

Field Service Ver. 1.0 Apr. 2005

3.2.4 Cassette Type Detecting Switch

A. Removal of the Cassette Type Detecting Switch

1. Remove the 2nd Drawer Paper Take-Up Unit.



2. Unplug the connector, and then remove the Cassette Type Detecting Switch.

3.2.5 2nd Drawer Take-up Solenoid

A. Removal of the 2nd Drawer Take-up Solenoid

1. Remove the 2nd Drawer Paper Take-Up Unit.



- 2. Remove the screw, and then remove the cover.
- *3.* Remove the screw, and then unplug the connector.
- 4. Remove the 2nd Drawer Take-up Solenoid.

PF-50'



SERVICE MANUAL

FIELD SERVICE

NC-501/SU-502

Confidential - for internal use only, do not distribute

2005.04 KONICA MINOLTA BUSINESS TECHNOLOGIES, INC. Ver. 1.0

After publication of this service manual, the parts and mechanism may be subject to change for improvement of their performance.

Therefore, the descriptions given in this service manual may not coincide with the actual machine.

When any change has been made to the descriptions in the service manual, a revised version will be issued with a revision mark added as required.

Revision mark:

- To indicate clearly a section revised, show \triangle to the left of the revised section. A number within \triangle represents the number of times the revision has been made.
- To indicate clearly a section revised, show **A** in the lower outside section of the corresponding page.

A number within **A** represents the number of times the revision has been made.

NOTE

Revision marks shown in a page are restricted only to the latest ones with the old ones deleted.

- When a page revised in Ver. 2.0 has been changed in Ver. 3.0: The revision marks for Ver. 3.0 only are shown with those for Ver. 2.0 deleted.
- When a page revised in Ver. 2.0 has not been changed in Ver. 3.0: The revision marks for Ver. 2.0 are left as they are.

2005/04	1.0		Issue of the first edition
Date	Service manual Ver.	Revision mark	Descriptions of revision

CONTENTS

General

1.	Product specifications1

Maintenance

2.	Other		3
2.1	Disa	assembly/Assembly list (Other parts)	3
2.2	Disa	assembly/Assembly procedure	3
2.	2.1	Network Interface Card (NC-501)	3
2.	2.2	Plate NIC Board (NC-501)	4
2.	2.3	Internet Fax & Network Scan Kit (SU-502)	5
3.	Firmw	vare upgrade	6

Troubleshooting

4.	Malfu	nctions/Warning9	
4.1	Trou	bleshooting Procedure Overview9	
4.2	Trou	bleshooting Procedure Chart9	
4.3	Mair	n Error Messages and Their Remedies 10	
4.4	Trou	bleshooting Functions11	
4.4	4.1	Scan to E-Mail Transmission 11	
4.4	1.2	Internet Fax Transmission11	
4.4	1.3	Internet Fax Reception12	
4.4	1.4	Direct Fax Sending (Gateway TX) 13	
4.4	1.5	PageScope Web Connection	
4.5 List of Communication Error Codes15			

Blank page

General

1. Product specifications

Name	Network Interface Card (NC-501)
Interface	Ethernet 10/100Base T /TX (RJ-45)
TCP/IP Service	ARP, BootP, DHCP, IPP, Ipr/lpd, Raw Socket, HTTPd1.1, SLP, AutoIP
Netware Services	Bindery, NDS, PServer mode, NPrinter mode, NDPS Frame Type (802.3, 802.2, 802.3 SNAP, Ethernet-II, Auto Detect)
Name	Internet Fax & Network Scan Kit (SU-502)
Interface	Ethernet 10/100Base T /TX (RJ-45)
Data format	MIME, Base64
Content Type	Multi-part/Mixed (text/plain, image/tiff)
I-FAX Communication Protocol	TX: SMTP RX: POP3
I-FAX Data Format	E-Mail Format: MIME Attached File format: Transmission: TIFF-S Reception: TIFF-F
I-FAX Cording method	Transmission: MH Reception: MH, MR, MMR, JBIG
I-FAX TX resolution	204 dpi × 98 dpi (STD) 204 dpi × 196 dpi (FINE)
I-FAX RX resolution	204 dpi × 98 dpi 204 dpi × 196 dpi 204 dpi × 391 dpi 200 dpi × 100 dpi 200 dpi × 200 dpi
Scan to E-Mail / Scan to FTP Communication Protocol	E-Mail TX: SMTP FTP TX: FTP
Scan to E-Mail / Scan to FTP Data Format	E-Mail Format: MIME Attached File format: TIFF, PDF
Scan to E-Mail / Scan to FTP Cording method	MH, MR, MMR, JPEG (For Color and Gray mode, fixed at JPEG)
Scan to E-Mail / Scan to FTP resolution	150 dpi × 150 dpi 300 dpi × 300 dpi 600 dpi × 600 dpi
Blank page

Maintenance

2. Other

2.1 Disassembly/Assembly list (Other parts)

No	Section	Option	Part name	Ref. page	
1	Board	NC-501	Network Interface Card (PWB-NIC)	r⊛ 3	
2			Plate NIC Board (NIC-IF)	rs 4	
3		SU-502	Internet Fax & Network Scan Kit	rs 5	

2.2 Disassembly/Assembly procedure

NOTE

- When removing a circuit board, refer to the precautions for handling printed circuit boards and follow the corresponding removal procedures.
- The following removal procedures omit the removal of the applicable component from connectors and circuit board supports.
- When it is necessary to touch ICs and other electrical components on the circuit board, be sure to first ground yourself.

2.2.1 Network Interface Card (NC-501)

A. Removal of the Network Interface Card





- 1. Turn OFF the Power Switch and unplug the power cord from the power outlet.
- 2. Remove the Rear Cover. (5 screws) **NOTE**

Use the following precautions when installing the Rear Cover.

- Make sure that the cover is positively placed inside the guide (Top and bottom).
- Make sure that the cover is properly doweled into the frame.
- Disconnect hookup connector P303 of the PCL Board.
- 4. Disconnect hookup connector P401 of the Net work Interface Card.

NOTE

Applicable to the Copier (PCL) and Fax (PCL) machine only.





2.2.2 Plate NIC Board (NC-501)

A. Removal of the Plate NIC Board





- 5. Disconnect hookup connector P402 of the Network Interface Card.
- 6. Disconnect hookup connector P502 of the Plate NIC Board.
- Remove the four screw, and the Network Interface Card (unplug the hookup connector provided on the backside of the Network I/F Card).

1. Remove the Rear Right Cover. (2 screws)

- Loosen one screw at the lower left corner of the PWB mounting bracket and remove the two fixing screws on the right.
- 3. Slide out the PWB mounting bracket in the direction of the arrow.

NOTE

Use the following precautions when installing the PWB mounting bracket.

- Fit the upper left corner of the PWB mounting bracket into the cutout in the copier.
- When installing the PWB mounting bracket in position, use care not to allow the harness to be wedged in mechanisms (shown inside a circle).

NC-501/SU-502



2.2.3 Internet Fax & Network Scan Kit (SU-502)

A. Removal of the Internet Fax & Network Scan Kit



1. Remove the Internet Fax & Network Scan Kit from IC socket BC31 of the Network Interface Card.

4. Remove the one screw, and the

Plate NIC Board.

NOTE

Use the following precautions when installing the Internet Fax & Network Scan Kit.

- Before installing the Internet Fax & Network Scan Kit, first remove the Network Interface Card from the copier.
- During installation, align the round portion on the IC socket with the cutoff corner of the Internet Fax & Network Scan Kit.

3. Firmware upgrade

- 1. Connect the Network Interface Card and PC with the network by using the RJ45 network cables.
- 2. Start up the [MS-DOS prompt] or [Command prompt] of PC.
- Input "ftp", and then input the [IP address].
 C:\>ftp XXX.XXX.XXX.XXX

NOTE

Confirm with the user's system administrator or network administrator on the IP address.

- 4. Press the "Enter" key.
- 5. Check that the following message is displayed, and that the PC has been connected with the NIC (Network Interface Card Board).

Connected_to_XXX.XXX.XXX.XXX 220_NET+ARM_FTP_SERVER_1.0_ready USER(XXX.XXX.XXX.XXX:(none)):

6. Press the "Enter" key.

NOTE

In case of using the Windows XP or Windows 2003 Server, type "(none)" and press the Enter key.

USER(XXX.XXX.XXX.XXX:(none)): (none)

Check that the following message is displayed, and that you could log on to the NIC through the PC.

230_User_none_logged_in.

- 8. Input "bin". (Data transfer is switched to the binary mode.)
- Press the "Enter" key. ftp>bin
- 10. The following messages is displayed. 200_Type_set_to_l.
- 11. Type "put" and then the location and name of the update file. ftp>put X:\XXX.bin
- 12. Press the "Enter" key. (Wait to a while until data transfer is completed.)
- 13. Check that the following message is displayed, and data has been properly transferred to the NIC from the PC.
 - 200_PORT_command_OK
 - 150_About_to_open_data_connection.
 - 226_Transfer_complete.

ftp: xxxbytes_sent_in_xxxSeconds_xxKbytes/sec.

14. Type "get flash" and press the Enter key. (Wait to a while until data transfer is completed.)

ftp>get flash

- 15. The following messages will appear.
- 200_PORT_command_OK 150_About_to_open_data_connection. 226_Transfer_complete ftp: xxxbytes_received_in_xxxSeconds_xxKbytes/sec.
- 16. Input "quit", and then press the "Enter" key.
- ftp>quit 221 Goodbye.

NC-501/SU-502

- 17. Input "type flash". C:\>type flash
- 18. Check that the firmware has been updated properly using the following messages that should appear.
 - step 1: Command format is correct
 - step 2: Program's header is right
 - step 4: Flash ROM erase OK
 - step 5: Flash ROM write OK
 - step 6: Program complete
- 19. Input "exit", and then press the "Enter" key.C:\>exit
- 20. Check that you exit the [MS-DOS prompt] or [Command prompt] of PC.
- 21. Delete the "flash" file created in drive C of the PC.
- 22. Press the main power switch for the copier OFF/ON to restart the copier.

C:\>ftp XXX.XXX.XXX.XXX

Connected to XXX.XXX.XXX.XXX 220 NET+ARM FTP SERVER X.X ready USER(XXX.XXX.XXX.XXX:(none)): 230 User none logged in. ftp>bin 200 Type set to I. ftp>put X:\XXX.bin 200 PORT command OK. 150 About to open data connection. 226 Transfer complete ftp: xxxbytes sent in xxxSeconds xxxKbytes/sec. ftp>get flash 200 PORT command OK. 150 About to open data connection. 226 Transfer complete. ftp: xxxbytes received in xxxSeconds xxxKbytes/sec. ftp>quit 221 Goodbye

C:\>type flash step 1 : Command format is correct step 2 : Program's header is right step 4 : Flash ROM erase OK step 5 : Flash ROM write OK step 6 : Program complete C:\>exit Blank page

NC-501/SU-502

Troubleshooting

4. Malfunctions/Warning

4.1 Troubleshooting Procedure Overview

- If the following symptoms occur when the machine is restarted after the Network Interface Card or the Internet Fax & Network Scan Kit has been mounted, check the board and connectors for proper connection. If the symptom persists, replace the defective part or parts.
- If it is not possible to transfer data correctly with the various settings made on [NET-WORK SETTING], the network or telephone line is probably defective.

NOTE

Network setting and line checks should be made by the network administrator (system administrator).

4.2 Troubleshooting Procedure Chart

1. If network settings are not correct, check them by following the flowchart below.



4.3 Main Error Messages and Their Remedies

Message	Cause	Remedy
COMM.ERROR XXXX SERVER	Communication is not possible because of some problem in the machine or the condition of the net- work or server.	Check the transmission results. Consult with the network admin- istrator.
CANNOT CONNECT XXXX SERVER	A connection to the server cannot be established.	Check that the Ethernet cable is correctly connected. Check the "E-MAIL SETTING 1", "E-MAIL SETTING 2" and "NET- WORK SETTING" settings. Consult with the network admin- istrator.
CANNOT GET IP XXXX SERVER	The IP address could not be assigned by the DNS or DHCP server.	Consult with the network admin- istrator.
DISCONNECT XXXX SERVER	The connection to the server was cut.	Consult with the network admin- istrator.
WRONG PASSWORD XXXX SERVER	The password is incorrect, so the machine could not log onto the server.	For a POP3 server, check the "E- MAIL SETTING 2" setting. Consult with the network admin- istrator.
RECEIVE WRONG DATA	An e-mail that cannot be printed by this machine was received. (For a file attachment in a format other than TIFF-F)	Ask the sender to send a TIFF-F file or text in the correct format.
MEM.FULL/TX CANCEL	While sending an e-mail, the size of the data for the scanned image has exceeded the capacity of the mem- ory.	Retrieve all received e-mail stored in the memory.
MEM.FULL/RX CANCEL XXXX SERVER	While receiving an e-mail, the size of the data for the scanned image has exceeded the capacity of the memory.	Retrieve all received e-mail stored in the memory.
FILE.FULL/TX CANCEL	While sending an e-mail, the maxi- mum of number of managed mem- ory file is used.	Retrieve all received e-mail stored in the memory.
FILE.FULL/RX CANCEL XXXX SERVER	While receiving an e-mail, the max- imum of number of managed mem- ory file is used.	Retrieve all received e-mail stored in the memory.
SERVER MEMORY FULL SMTP SERVER	The memory of the SMTP server has become full while sending an e-mail.	Consult with the network admin- istrator.
FTP SERVER ERROR	While uploading scan data, the data could not be correctly uploaded to the FTP server.	Please consult your network administrator for details.

4.4 Troubleshooting Functions

4.4.1 Scan to E-Mail Transmission

No.	Condition	Cause	Action
	Transmission is not possible.	The connections are incor- rect.	Check the LED indicator on the hub, and check the connections.
1		The settings necessary for the device are not registered.	Specify the necessary network settings.
		The LAN cable is damaged.	Replace the LAN cable.
	Transmission is possi- ble, but the image cannot be outputted at the recipient's terminal	The recipient's terminal is not able to handle the sent image.	Change the size, resolution and coding method so that they are supported by the recipient's terminal, and then try sending the data again.
2	or computer.	The document text was not inserted when the data was sent.	With some e-mail applications, if an e- mail is received containing no text and only an attached file, it may not be pos- sible to open the attached file. There- fore, text should be inserted into the document that is sent.

4.4.2 Internet Fax Transmission

No.	Condition	Cause	Action
	Transmission is not possible.	The connections are incor- rect.	Check the LED indicator on the hub, and check the connections.
1		The settings necessary for the device are not registered.	Specify the necessary network settings.
		The LAN cable is damaged.	Replace the LAN cable.
2	An interruption in the transmission was specified, but the transmission was not interrupted.	It takes some time to inter- rupt an Internet fax transmis- sion.	Wait until the transmission is inter- rupted.

4.4.3 Internet Fax Reception

No.	Condition	Cause	Action
	Reception is not pos- sible.	The connections are incor- rect.	Check the LED indicator on the hub, and check the connections.
		The setting to not automati- cally check for new e-mail messages has been speci- fied.	Specify a time interval for automatically checking for new e-mail messages. Receive manually.
1		The settings necessary for the device are not registered.	Specify the necessary network settings.
		The same POP3 user name is being used by a different e- mail application or another user.	Do not use the same POP3 user name that is used by a different e-mail application.
		The LAN cable is damaged.	Replace the LAN cable.
0	The data is received, but not printed.	An e-mail message with data of an incompatible format attached or with no data was received.	Ask the sender to send a TIFF-F file or text.
2		The memory is full.	Print saved documents and reduce the amount of memory that is used, and then ask the sender to send the data again.
3	The same document is received many times.	Since the size of the mail is too large, the connection with the server times out while the data is being received.	Specify that the data be kept on the computer, and delete the corresponding e-mail messages from the server. Ask the sender to try sending e-mail messages of smaller sizes.
4	An interruption in the reception was speci- fied, but the reception was not interrupted.	It takes some time to interrupt an Internet fax reception.	Wait until the transmission is inter- rupted.

4.4.4 Direct Fax Sending (Gateway TX)

No.	Condition	Cause	Action
	Data does not arrive at the copier.	The Unimessage Pro I-Net Portal settings are incorrect.	Check the Unimessage Pro I-Net Portal settings.
1		Since the size of the received data is large, it cannot be received due to the server's limitations.	Reduce the size of the data, for example, by decreasing the number of pages, and then try sending again.
2	A fax cannot be sent from this copier.	The communication mode for gateway transmissions is incorrectly specified.	The "GATEWAY TX" parameter must be set to "ENABLE", and the communica- tion mode must be set correctly.

4.4.5 PageScope Web Connection

No.	Condition	Cause	Action
	A connection with PageScope Web Con-	The IP address for the device is not specified correctly.	Specify the IP address.
	nection cannot be established.	The URL setting in the Web browser is incorrect.	In the "Address" box, type the IP address of the specified device.
1		The settings in the Web browser are incorrect.	Even though the device can be accessed, certain settings must be specified according to the network con- figuration in order to establish a connec- tion. For details, contact your network administrator.
		If a proxy is specified with the browser and the IP address of this copier cannot be recog- nized by the proxy server, the PageScope Web Connection window cannot be displayed.	Use the proxy settings in the browser to add the IP address of this copier to the list of exceptions that will not use the proxy server.
		The LAN cable is damaged.	Replace the LAN cable.
2	Could not login using Administrator mode.	Before this login, a different user name and password had been entered.	Once login is successful, that user name and password is saved in the browser until the browser is closed. Close the browser, and then start it up again.
	The text in the window	The browser is too small.	Increase the size of the browser.
3	is disorganized.	An appropriate font size is not selected.	Specify an appropriate font size for the computer and browser.
4	Some deleted charac- ters remain in the win- dow.	Operations differ depending on the browser used.	Reload the browser window or rescan.
5	The number of digits in an input or display area and the number of characters that can be registered are dif- ferent.	Depending on the browser, scroll within the input area. If this is not possible, this should not affect the actual setting operation, although it may be a problem for display- ing.	

No.	Condition	Cause	Action
6	Some characters can- not be specified or dis- played.	Depending on the operating system, some characters cannot be specified or dis- played.	_
7	Space characters can- not be specified or dis- played.	Spaces entered at the end of words may be removed.	_
8	Entered data was erased when an error occurred while speci- fying settings.	Depending on the browser, settings that appear as "*", such as passwords, may be erased.	

NC-501/SU-502

4.5 List of Communication Error Codes

• The following error codes appear in TX Result Report, RX Result Report.

Error code	Description
0072	A connection to the SMTP server cannot be established.
0073	Communication is not possible because of some problem in the machine or the condition of the network or SMTP Server.
0074	The connection to the SMTP server was cut.
0075	The memory of the SMTP server has become full while sending an e-mail.
007B	The connection is disconnected during gateway transmission.
007C	A Direct fax that cannot be forward transmit by this machine was received. (For a file attachment in a format other than TIFF-F)
007D	While receiving a Direct fax, the size of the data for the scanned image has exceeded the capacity of the memory.
007E	While receiving a Direct fax, the maximum of number of managed memory file is used.
0096	The IP address could not be assigned by the DNS server.
0097	The IP address could not be assigned by the DNS server.
0098	The IP address could not be assigned by the DNS server.
009B	A connection to the DNS server cannot be established.
00a2	While receiving an e-mail, the maximum of number of managed memory file is used.
00a3	A connection to the POP3 server cannot be established.
00a4	The password is incorrect, so the machine could not log onto the POP3 server.
00a5	Communication is not possible because of some problem in the machine or the condition of the network or POP Server.
00a6	The connection to the POP3 server was cut.
00a7	An e-mail that cannot be printed by this machine was received. (For a file attach- ment in a format other than TIFF-F)
00a8	While receiving an e-mail, the size of the data for the scanned image has exceeded the capacity of the memory.
00A9	A connection to the FTP server cannot be established.
00AA	The password is incorrect, so the machine could not log onto the FTP server.
00AB	Communication is not possible because of some problem in the machine or the condition of the network or FTP Server.
00AC	The connection to the FTP server was cut.
00AD	The FTP server cannot store the data that is sent from the machine.

Blank page

bizhub 160/161/160f/161f Overall Wiring Diagram



Confidential – for internal use only, do not distribute

⁴⁹⁸⁰⁻B001-2A Apr.2005

DF-501 Overall Wiring Diagram



Confidential - for internal use only, do not distribute

1382-B001-1A Apr.2005

PF-501 Overall Wiring Diagram



Confidential - for internal use only, do not distribute

4516-B001-1A Apr.2005



© 2005 KONICA MINOLTA BUSINESS TECHNOLOGIES, INC.

Use of this manual should be strictly supervised to avoid disclosure of confidential information.

Printed in Japan DD4980PE1-1000