



ECOSYS M4132idn
ECOSYS M4125idn
PF-470/PF-471
AK-470/DF-470
FAX System 13

SERVICE MANUAL

Published in March 2018
Rev.3

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

It may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for proper disposal.

ATTENTION

IL Y A UN RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UN MODÈLE DE TYPE INCORRECT. METTRE AU REBUT LES BATTERIES UTILISÉES SELON LES INSTRUCTIONS DONNÉES.

Il peut être illégal de jeter les batteries dans des eaux d'égout municipales. Vérifiez avec les fonctionnaires municipaux de votre région pour les détails concernant des déchets solides et une mise au rebut appropriée.

Notation of products in the manual

For the purpose of this service manual, products are identified by print speed at A4.

Product name	Print speed	Display size	Scanning method	100 V	120 V	220-240 V	Australia
TASKalfa 2510i	25 sheets/ min	4.3 inch	CIS	○	-	-	-
TASKalfa 2520i		7 inch	CCD	○	-	-	-
ECOSYS M4125idn		4.3 inch	CIS	-	○	○	○
ECOSYS M4132idn	32 sheets/ min	7 inch	CCD	-	○	○	○

Revision history

Revision	Date	Pages	Revised contents
1	2017/09/04	3-10Page 3-11Page 9-15Page	Added: Zener PWB
		6-103Page	Correction: U332 Setting range/Initial setting
		3-5Page	Correction: Position number of DP motors
		2-3Page	Deleted: No,25 Warranty card
2	2018/01/05	1-1Page	Correction: (1) Common function/Paper specification
		1-3Page	Correction: Numbers of continuous copying
		2-35Page	Change: Contents of country code list
		4-84Page	Added: Precaution when detach the PWB
		5-1Page 2-34Page	Added: OCR Dictionary, Comments when instal the OCR Dictionary
		6-5Page 6-181Page	Added: U930
		6-5Page 6-184Page	Change: U964 HDD → nonvolatile memory
		6-135Page 6-193Page	Change: Contents of country code list
		7-1Page	Change: The test sample to MIP-PG pattern
		7-19Page	Deleted: Border Erase function
		7-4Page to 7-6Page 7-7Page 7-8Page 7-9Page to 7-11Page	Correction: The description of (2-2 to 6) of the 7-1 Image formation problems Correction: The description of (2-8) of the 7-1 Image formation problems Correction: The description of (2-11) of the 7-1 Image formation problems Correction: The description of (2-13 to 17) of the 7-1 Image formation problems
		7-14Page 7-15Page to 7-17Page 7-18Page to 7-20Page	Correction: The description of (3-2) of the 7-1 Image formation problems Correction: The description of (3-4 to 9) of the 7-1 Image formation problems Correction: The description of (3-11 to 16) of the 7-1 Image formation problems
		7-24Page 7-25Page 7-27Page 7-28Page	Correction: The description of (4-3) of the 7-1 Image formation problems Correction: The description of (4-6) of the 7-1 Image formation problems Correction: The description of (4-13) of the 7-1 Image formation problems Correction: The description of (4-15) of the 7-1 Image formation problems
		7-32Page 7-32Page 7-33Page to 7-36Page	Correction: The description of (5-2) of the 7-1 Image formation problems Correction: The description of (5-4) of the 7-1 Image formation problems Correction: The description of (5-8 to 15) of the 7-1 Image formation problems

Revision	Date	Pages	Revised contents
2	2018/01/05	7-38Page 7-39Page 7-41Page	Correction: The description of (1-2) of the 7-2 Feeding/Conveying Failures Correction: The description of (1-5) of the 7-2 Feeding/Conveying Failures Correction: The description of (1-11) of the 7-2 Feeding/Conveying Failures
		7-46Page 7-48Page 7-60Page to 7-63Page	Correction: The description of (J0000) of the 7-2 Feeding/Conveying Failures Correction: The description of (J0501/J0502/J0503) of the 7-2 Feeding/Conveying Failures Correction: The description of (J9000 to J9410) of the 7-2 Feeding/Conveying Failures
		7-155Page to 7-156Page 7-159Page	Correction: The description of (2 to4) of the 7-8 Abnormal Noise Correction: The description of (14) of the 7-8 Abnormal Noise
		7-75Page to 7-76Page 7-78Page to 7-78Page 7-81Page to 7-82Page 7-84Page	Correction: The description of (C0980 to C1030) of the 7-3 Self Diagnostic Correction: The description of (C2010 to C2101) of the 7-3 Self Diagnostic Correction: The description of (C3200 to C3300) of the 7-3 Self Diagnostic Correction: The description of (C5101) of the 7-3 Self Diagnostic
3	2018.03.22	1-6Page	Paper weight of PF-470/471 (52 to 163 g/m2 → 60 to 163 g/m2)
		2-24Page	Deleted: The fixing screw of SD card cover
		5-4Page	Correction: USB folder structure
		6-4Page 6-114Page	Correction: Delete the word "Duplex"
		6-45Page	Correction: Setting Range (0 → -75)
		6-107Page	Correction: Description of setting of Auto sleep
		6-116Page	Correction: Test pattarn (2 → 1)



Safety precautions

This booklet provides safety warnings and precautions for our service personnel to ensure the safety of their customers, their machines as well as themselves during maintenance activities. Service personnel are advised to read this booklet carefully to familiarize themselves with the warnings and precautions described here before engaging in maintenance activities.

Safety warnings and precautions

Various symbols are used to protect our service personnel and customers from physical danger and to prevent damage to their property. These symbols are described below:

⚠ DANGER: High risk of serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

⚠ WARNING: Serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

⚠ CAUTION: Bodily injury or damage to property may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

Symbols

The triangle (△) symbol indicates a warning including danger and caution. The specific point of attention is shown inside the symbol.



General warning.



Warning of risk of electric shock.



Warning of high temperature.

⊘ indicates a prohibited action. The specific prohibition is shown inside the symbol.



General prohibited action.



Disassembly prohibited.

● indicates that action is required. The specific action required is shown inside the symbol.



General action required.





Remove the power plug from the wall outlet.











Always ground the copier.

1. Installation Precautions

WARNING











- Do not use a power supply with a voltage other than that specified. Avoid multiple connections to one outlet: they may cause fire or electric shock. When using an extension cable, always check that it is adequate for the rated current. 
- Connect the ground wire to a suitable grounding point. Not grounding the copier may cause fire or electric shock. Connecting the earth wire to an object not approved for the purpose may cause explosion or electric shock. Never connect the ground cable to any of the following: gas pipes, lightning rods, ground cables for telephone lines and water pipes or faucets not approved by the proper authorities. 

CAUTION:





- Do not place the copier on an infirm or angled surface: the copier may tip over, causing injury. 
- Do not install the copier in a humid or dusty place. This may cause fire or electric shock. 
- Do not install the copier near a radiator, heater, other heat source or near flammable material. This may cause fire. 
- Allow sufficient space around the copier to allow the ventilation grills to keep the machine as cool as possible. Insufficient ventilation may cause heat buildup and poor copying performance. 
- Always handle the machine by the correct locations when moving it. 
- Always use anti-toppling and locking devices on copiers so equipped. Failure to do this may cause the copier to move unexpectedly or topple, leading to injury. 
- Avoid inhaling toner or developer excessively. Protect the eyes. If toner or developer is accidentally ingested, drink a lot of water to dilute it in the stomach and obtain medical attention immediately. If it gets into the eyes, rinse immediately with copious amounts of water and obtain medical attention. 
- Advise customers that they must always follow the safety warnings and precautions in the copier's instruction handbook. 












2. Precautions for Maintenance

WARNING

- Always remove the power plug from the wall outlet before starting machine disassembly. 
- Always follow the procedures for maintenance described in the service manual and other related brochures. 
- Under no circumstances attempt to bypass or disable safety features including safety mechanisms and protective circuits. 
- Always use parts having the correct specifications. 
- Always use the thermostat or thermal fuse specified in the service manual or other related brochure when replacing them. Using a piece of wire, for example, could lead to fire or other serious accident. 
- When the service manual or other serious brochure specifies a distance or gap for installation of a part, always use the correct scale and measure carefully. 
- Always check that the copier is correctly connected to an outlet with a ground connection. 
- Check that the power cable covering is free of damage. Check that the power plug is dust-free. If it is dirty, clean it to remove the risk of fire or electric shock. 
- Never attempt to disassemble the optical unit in machines using lasers. Leaking laser light may damage eyesight. 
- Handle the charger sections with care. They are charged to high potentials and may cause electric shock if handled improperly. 



CAUTION

- Wear safe clothing. If wearing loose clothing or accessories such as ties, make sure they are safely secured so they will not be caught in rotating sections. 
- Use utmost caution when working on a powered machine. Keep away from chains and belts. 
- Handle the fixing section with care to avoid burns as it can be extremely hot. 
- Check that the fixing unit thermistor, heat and press rollers are clean. Dirt on them can cause abnormally high temperatures. 

- Do not remove the ozone filter, if any, from the copier except for routine replacement. 
- Do not pull on the AC power cord or connector wires on high-voltage components when removing them; always hold the plug itself. 
- Do not route the power cable where it may be stood on or trapped. If necessary, protect it with a cable cover or other appropriate item. 
- Treat the ends of the wire carefully when installing a new charger wire to avoid electric leaks. 
- Remove toner completely from electronic components. 
- Run wire harnesses carefully so that wires will not be trapped or damaged. 
- After maintenance, always check that all the parts, screws, connectors and wires that were removed, have been refitted correctly. Special attention should be paid to any forgotten connector, trapped wire and missing screws. 
- Check that all the caution labels that should be present on the machine according to the instruction handbook are clean and not peeling. Replace with new ones if necessary. 
- Handle greases and solvents with care by following the instructions below: 
 - Use only a small amount of solvent at a time, being careful not to spill. Wipe spills off completely.
 - Ventilate the room well while using grease or solvents.
 - Allow applied solvents to evaporate completely before refitting the covers or turning the power switch on.
 - Always wash hands afterwards.
- Never dispose of toner or toner bottles in fire. Toner may cause sparks when exposed directly to fire in a furnace, etc. 
- Should smoke be seen coming from the copier, remove the power plug from the wall outlet immediately. 

3. Miscellaneous

 **WARNING**

- Never attempt to heat the drum or expose it to any organic solvents such as alcohol, other than the specified refiner; it may generate toxic gas. 
- Keep the machine away from flammable liquids, gases, and aerosols. A fire or an electric shock might occur. 

This page is intentionally left blank.

CONTENTS

1	Specification	1-1
1 - 1	Specifications.....	1-1
(1)	Common function.....	1-1
(2)	Copy Functions.....	1-3
(3)	Printer Functions.....	1-4
(4)	Scanner Functions.....	1-4
(5)	Document Processor	1-5
(6)	Option	1-6
	(6-1)500 sheets × 1 Paper Feeder (PF-470)	1-6
	(6-2)500 sheets × 2 Paper Feeder (PF-471)	1-6
	(6-3)500 sheets Finisher (DF-470) (32ppm model only)	1-7
	(6-4)FAX System (FAX System 13)	1-8
1 - 2	Part Names.....	1-9
(1)	Exterior	1-9
(2)	Connectors/Interior	1-11
(3)	With Optional Equipments Attached	1-12
(4)	FAX System.....	1-13
(5)	Operation Panel Keys.....	1-14
1 - 3	Optional Equipment	1-16
(1)	PF-470 <500 sheets × 1 Paper Feeder>	1-17
(2)	PF-471 <500 sheets X 2 Paper Feeder>	1-17
(3)	AK-470 <Attachment Kit> (32ppm model only)	1-17
(4)	DF-470 <500 sheets Finisher> (32ppm model only)	1-17
(5)	Expansion memory	1-17
(6)	SD/SDHC memory card.....	1-17
(7)	Card Authentication Kit(B) "Card Authentication Kit"	1-17
(8)	HD-6/HD-7 <SSD>	1-17
(9)	IB-50 <Network Interface Kit>.....	1-17
(10)	IB-51 <Wireless Network Interface Kit>	1-17
(11)	IB-36 <Wireless Network Interface Kit> (220 to 240 V only (100/120V: standard)).....	1-17
(12)	FAX System 12 <FAX Kit>	1-18
(13)	Data Security Kit(E) <Data Security Kit>	1-18
(14)	UG-33 <Thin Print Option>	1-18
2	Installation	2-1
2 - 1	Environment.....	2-1
2 - 2	Installing the main unit.....	2-2
(1)	Unpacking and checking bundled items	2-3
	(1-1)Main unit	2-3
(2)	Notes on main unit transportation.....	2-4
(3)	Attaching the job separator tray.....	2-5
(4)	Unlocking the scanner mirror frame (CCD model only).....	2-5
(5)	Loading Paper	2-6
	(5-1)Precaution for Loading Paper	2-6
	(5-2)Set paper in the cassette	2-7
(6)	Switching the cassette heater switch.....	2-10
(7)	Connecting the Power Cord.....	2-10
(8)	Setting up the Toner Container.....	2-11
(9)	Default Setting	2-13
	(9-1)Setting Date and Time	2-13
	(9-2)Network Setup (LAN Cable Connection)	2-14
	(9-3)Paper size and media type setting	2-14
(10)	Installing Software	2-15

(11) Output Maintenance Report (Execute maintenance mode U000).....	2-15
(12) Clearing the counts (Maintenance mode U927)	2-15
(13) Setting the delivery date (Maintenance mode U278).....	2-15
(14) Exiting from the maintenance mode	2-15
(15) Completion of installing the main unit	2-16
2 - 3 Installing the optional devices	2-17
(1) Unpacking and checking bundled items	2-17
(1-1)Paper Feeder (PF-470) (Option)	2-17
(1-2)Paper Feeder (PF-471) (Option)	2-18
(1-3)Attachment Kit (AK-470) (Option)	2-19
(1-4)500-sheet Finisher (DF-470) (Option)	2-20
(2) Optional unit installation.....	2-21
2 - 4 Installing the optional parts	2-22
(1) Expansion memory	2-22
(2) SD/SDHC memory card.....	2-24
(3) SSD (HD-6/HD-7)	2-26
(4) Card reader.....	2-28
(5) Handset (100V model only)	2-30
2 - 5 About Optional Applications.....	2-34
2 - 6 Initializing procedures after installing the FAX system	2-35

3 Machine Design 3-1

3 - 1 Mechanical Configuration	3-1
(1) Cross-section view (CCD model).....	3-1
(2) Cross-section view (CIS model)	3-2
3 - 2 Extension device construction (option)	3-3
(1) 500-sheet x1 Paper Feeder cross-section view (PF-470)	3-3
(2) 500-sheet x2 Paper Feeder cross-section view (PF-471)	3-3
(3) Attachment kit cross-section view (AK-470)	3-4
(4) 5000-sheet Finisher cross-section view (DF-470)	3-4
3 - 3 Electric parts	3-5
(1) Wire connection	3-5
(1-1)(Machine rear side)	3-5
(1-2)Machine inside	3-6
(2) Descriptions about the major PWBs	3-7
(2-1)Main PWB	3-7
(2-2)Enginee PWB	3-7
(2-3)High voltage PWB	3-7
(2-4)Low voltage PWB	3-8
(2-5)Operation panel main PWB	3-8
(2-6)DP PWB	3-8
(3) PWBs.....	3-9
(3-1)Layout	3-9
(3-2)Part name table	3-10
(4) Sensors and Switches	3-12
(4-1)Layout	3-12
(4-2)Part name table	3-14
(5) Motors.....	3-16
(5-1)Layout	3-16
(5-2)Part name table	3-17
(6) Other parts.....	3-19
(6-1)Layout	3-19
(6-2)Part name table	3-20
3 - 4 Electric parts (Optional unit)	3-22
(1) Paper feeder (PF-470).....	3-22
(1-1)Layout	3-22
(1-2)Part name table	3-22
(2) Paper feeder (PF-471).....	3-24
(2-1)Layout	3-24

(2-2)Part name table	3-25
(3) Attachment Kit (AK-470)	3-26
(3-1)Layout	3-26
(3-2)Part name table	3-26
(4) 500-sheet Finisher (DF-470).....	3-27
(4-1)Layout	3-27
(4-2)Part name table	3-28
3 - 5 Drive system	3-30
(1) Drive configuration	3-30
(2) Drive location	3-35
(3) Drive unit.....	3-36
3 - 6 Mechanical construction	3-37
(1) Paper feed section	3-37
(1-1)Cassette paper feed section	3-37
(1-2)MP paper feed section	3-39
(2) Optical section	3-41
(2-1)Image scanner section (CIS model)	3-41
(2-2)Image scanner section (CCD model)	3-43
(2-3)Laser scanner unit	3-45
(3) Developer section	3-47
(3-1)Developer unit	3-47
(4) Drum section.....	3-49
(4-1)Drum unit	3-49
(5) Conveying/transfer section	3-51
(6) Fuser section	3-53
(7) Exit and feed-shift section.....	3-55
(8) Duplex conveying section	3-57
(9) Document Processor	3-59
(9-1)Original paper feed section	3-59
(9-2)Original conveying section, original reversing and exit section	3-61
(9-3) Reversing duplex scanning	3-63
3 - 7 Mechanical construction (option)	3-64
(1) Paper feeder (PF-470).....	3-64
(2) Paper feeder (PF-471).....	3-65
(3) Attachment Kit (AK-470)	3-67
(4) 500-sheet Finisher (DF-470).....	3-68
(4-1)Finishing section	3-68
(4-2)Exit tray section	3-70
(4-3)Bundle exit operation	3-72

4 Maintenance 4-1

4 - 1 Precautions for the maintenance	4-1
(1) Precautions	4-1
(2) Storage and handling of the drum	4-1
(3) Storage of the toner container	4-1
(4) Screening of the toner container.....	4-2
4 - 2 Maintenance parts	4-3
(1) Maintenance kits.....	4-3
(2) Executing the maintenance mode after replacing the maintenance kit	4-4
(2-1)Execute the following maintenance modes after replacing the maintenance kit.	4-4
(2-2)Maintenance mode to execute after replacing the unit	4-4
4 - 3 Maintenance parts replacement procedures	4-5
(1) Cassette feed section	4-5
(1-1)Detaching and reattaching the feed unit	4-5
(1-2)Detaching and reattaching the regist cleaner	4-6
(2) MP feed section	4-8
(2-1)Detaching and reattaching the MP feed roller	4-8
(2-2)Detaching and reattaching MP separation pad	4-9
(3) Transfer section	4-10

	(3-1)Detaching and reattaching the transfer unit	4-10
(4)	Drum section.....	4-11
	(4-1)Detaching and reattaching the drum unit	4-11
	(4-2)Detaching and reattaching the main charge roller unit	4-13
(5)	Developer section	4-14
	(5-1)Detaching and reattaching the developer unit	4-14
(6)	Fuser section	4-16
	(6-1)Detaching and reattaching the fuser unit	4-16
(7)	Document Processor	4-17
	(7-1)Detaching and reattaching the DP pickup pulley and DP feed roller	4-17
	(7-2)Detaching and reattaching the DP retard roller	4-18
4 - 4	Maintenance parts replacement procedures (option)	4-19
(1)	Paper feeder (PF-470/PF-471)	4-19
	(1-1)Detaching and reattaching the feed unit	4-19
4 - 5	Disassembly and Reassembly procedures.....	4-20
(1)	OUTER COVERS	4-20
	(1-1)Detaching and reattaching the front cover	4-20
	(1-2)Detaching and reattaching the controller box cover	4-22
	(1-3)Detaching and reattaching the rear cover	4-22
	(1-4)Detaching and reattaching the main tray	4-23
	(1-5)Detaching and reattaching the tray rear cover	4-26
	(1-6)Detaching and reattaching the MP tray	4-30
	(1-7)Detaching and reattaching the right cover 1	4-31
	(1-8)Detaching and reattaching the DP front cover	4-33
	(1-9)Detaching and reattaching the DP rear cover	4-34
	(1-10)Detaching and reattaching the DP original tray	4-35
(2)	Optical section	4-37
	(2-1)Detaching and reattaching the LSU	4-37
	(2-2)Detaching and reattaching the document processor	4-42
	(2-3)Detaching and reattaching the image scanner unit (CCD model)	4-43
	(2-4)Detaching and reattaching the image scanner unit (CIS model)	4-63
(3)	Drive section	4-72
	(3-1)Detaching and reattaching the drive unit	4-72
	(3-2)Detaching and reattaching the main motor	4-74
(4)	Detaching and attaching the other parts.....	4-75
	(4-1)Detaching and attaching the language sheet.	4-75
	(4-2)Detaching and reattaching the exit fan motor	4-76
	(4-3)Detaching and reattaching the controller fan motor	4-77
	(4-4)Detaching and reattaching the conveying fan motor.	4-80
	(4-5)Detaching and reattaching the temperature/humidity fan motor.	4-82
	(4-6)Fan motor attachment direction	4-83
(5)	PWBs.....	4-84
	(5-1)Detaching and reattaching the main PWB	4-84
	(5-2)Detaching and reattaching the Enginee PWB	4-88
	(5-3)Detaching and reattaching the low voltage PWB	4-90
	(5-4)Detaching and reattaching the high voltage PWB	4-94
	(5-5)Detaching and reattaching the operation panel PWB	4-99
	(5-6)Detaching and reattaching the DP PWB	4-102
4 - 6	Disassembly & Reassembly (option)	4-104
(1)	Paper feeder (PF-470/PF-471)	4-104
	(1-1)Detaching and reattaching the PF drive unit	4-104
	(1-2)Detaching and reattaching the PF PWB	4-105
(2)	Finisher (DF-470).....	4-106
	(2-1)Detaching and reattaching the DF front cover	4-106
	(2-2)Detaching and reattaching the DF rear cover	4-106
	(2-3)Aligning the phase of the upper and lower drive gears of the DF bundle eject belt	4-106
4 - 7	Periodical maintenance procedure (CH:Check CL:Clean AD:Adjust LU:Lubrication RE:Replace)	4-107
(1)	Main unit	4-107
(2)	Document Processor	4-109
(3)	Paper Feeder (PF-470/471) (Option).....	4-111

(4) Attachment Kit (AK-470) (Option)	4-112
(5) Finisher (DF-470) (Option)	4-112
5 Firmware	5-1
5 - 1 Firmware update	5-1
6 Maintenance mode	6-1
6 - 1 Maintenance mode	6-1
(1) Executing the maintenance mode	6-1
(2) Maintenance modes list	6-2
6 - 2 Service mode	6-190
(1) Service mode execution method	6-190
(2) Service mode table	6-190
7 Troubleshooting	7-1
7 - 1 Image formation problems	7-1
(1) Isolate the place of image failure	7-1
(2) Scanner Factors (when scanning from DP)	7-2
(2-1) Abnormal image	7-4
(2-2) Colored background	7-4
(2-3) Black dots	7-5
(2-4) Blurred characters	7-5
(2-5) Mismatch between the center of the original and the center of the copy image (Front side)	7-6
(2-6) Mismatch between the center of the original and the center of the copy image (Back side)	7-6
(2-7) Horizontal black streaks	7-6
(2-8) Vertical streaks, band (black or color)	7-7
(2-9) Regular difference of the leading edge on the original image and copy image (Front side)	7-7
(2-10) Regular difference of the leading edge on the original image and copy image (Back side)	7-8
(2-11) Vertical streaks, band (white)	7-8
(2-12) Moiré	7-8
(2-13) Missing entire image (White / Black)	7-9
(2-14) Image is dark partly or light	7-9
(2-15) Blurred image	7-10
(2-16) Image is missing partly	7-10
(2-17) Skewed image	7-11
(2-18) Entire image is light	7-11
(3) Scanner Factors (when scanning on the contact glass)	7-12
(3-1) Abnormal image	7-14
(3-2) Colored background	7-14
(3-3) Black dots	7-14
(3-4) Blurred characters	7-15
(3-5) Mismatch between the center of the original and the center of the output image	7-15
(3-6) Horizontal black streaks	7-15
(3-7) Vertical streaks or bands	7-16
(3-8) Regular difference of the leading edge on the original and output image	7-17
(3-9) Vertical streaks, band (white)	7-17
(3-10) Moiré	7-18
(3-11) No image comes out (White or Black)	7-18
(3-12) Image is dark partly or light	7-18
(3-13) Blurred image	7-19
(3-14) Image is missing partly	7-19
(3-15) Skewed image	7-20
(3-16) Entire image is light	7-20
(4) Engine Factors (Paper conveying cause: Transfer, Fuser and Separation)	7-22
(4-1) Black dots (toner dirt)	7-23
(4-2) Image is missing partly (blank image, white spots)	7-24
(4-3) Blank image	7-24

(4-4)Mismatch between the center of the original and the center of the copy image	7-24
(4-5)Dirty reverse side	7-25
(4-6)Entire image is light	7-25
(4-7)Horizontal streaks, band (White, black)	7-25
(4-8)Irregular errors at the leading edge of the original image and the copy image (variation of paper leading edge timing) 7-26	
(4-9)Blurred characters	7-26
(4-10)Offset	7-26
(4-11)Fusing failure	7-27
(4-12)Paper skew at the trailing edge	7-27
(4-13)Uneven transfer	7-27
(4-14)Blurred image	7-28
(4-15)Vertical streaks or bands	7-28
(5) Engine Factors (Image forming cause).....	7-29
(5-1)Background image is foggy.	7-31
(5-2)Background image is foggy.	7-32
(5-3)Background image is foggy.	7-32
(5-4)Entire image is light	7-32
(5-5)Entire image is light	7-33
(5-6)Entire image is light	7-33
(5-7)Image is missing partly	7-33
(5-8)Blank image	7-33
(5-9)No image comes out (Black)	7-34
(5-10)Periodic toner dirt	7-34
(5-11)Horizontal streaks, band (White, black)	7-35
(5-12)Vertical streaks or bands	7-35
(5-13)Vertical streaks, band (white)	7-36
(5-14)Horizontal uneven density	7-36
(5-15)Vertical uneven density	7-36
(5-16)Offset	7-37
(5-17)Gradation reproducibility is low	7-37
(5-18)Blurred image	7-37
(5-19)Trailing image	7-37
7 - 2 Feeding/Conveying Failures	7-38
(1) Prior standard check items	7-38
(1-1)Paper jam due to the cover-open detection	7-38
(1-2)Paper jam from paper factor	7-38
(1-3)Paper jam due to the dog-ear, paper skew, paper creases, fusing failure or the paper curl	7-39
(1-4)Paper jam due to the guide	7-39
(1-5)Paper jam caused by improperly loaded paper in the cassette	7-39
(1-6)Paper jam due to the inferior paper	7-39
(1-7)Paper jam from the factor of conveying roller, motor or clutch	7-39
(1-8)Paper jam due to the sensor	7-40
(1-9)Paper jam due to the setting / detection failure	7-40
(1-10)Paper jam due to the static electricity	7-41
(1-11)Paper jam caused by the installation environment (Papers inside the cassette are always damp.) 7-41	
(2) Paper misfeed detection	7-42
(2-1)Paper misfeed indication	7-42
(2-2)Paper misfeed detection condition	7-43
(3) Jam Codes.....	7-45
(4) Other Feeding/Conveying Failures	7-65
(4-1)Paper creases (Fuser factor)	7-65
(4-2)Paper creases (Registration or Transfer factor)	7-65
7 - 3 Self Diagnostic.....	7-67
(1) Self diagnostic error codes	7-67
(1-1)Error codes list	7-67
(2) System Error (Fxxxx) Outline.....	7-96
(2-1)System Error code list	7-96
(2-2)Content of System Error (Fxxxx) Outline	7-96

	(2-3)System Error (Fxxxx) Outline	7-99
7 - 4	FAX Related Errors.....	7-108
	(1) FAX Related Errors.....	7-108
	(1-1)C0030: FAX PWB system error	7-108
	(1-2)C0070: FAX PWB incompatible detection error	7-108
	(1-3)C0830: FAX PWB flash program area checksum error	7-108
	(1-4)C0870: PC FAX Image data transmission error	7-109
	(1-5)C0920: FAX file system error	7-109
	(1-6)The FAX cannot be sent	7-109
	(1-7)The beep sounds when the copying or printing is finished	7-110
	(1-8)When the data of the A3 or B4 size originals is transmitted, all of it is transmitted as the A4 size data . 7-110	
	(2) Communication Errors.....	7-111
7 - 5	Send Related Errors	7-132
	(1) Send Related Errors	7-132
	(1-1)The sending error 2101 does not disappear even if changing the host name or the security software settings 7-132	
	(1-2)Sending error 2203 does not disappear	7-132
	(1-3)The scanning data from the contact glass is automatically sent	7-132
	(2) Sending Errors (Error Codes).....	7-133
	(2-1)Scan to E-mail Error Codes	7-133
	(2-2)Scan to FTP Error Codes	7-136
	(2-3)Scan to SMB Error Codes	7-140
7 - 6	Print Errors.....	7-142
	(1) The paper loading message appears	7-143
	(2) The paper direction is incorrect	7-143
	(3) Paper is fed from the MP tray.....	7-144
	(4) Garbled characters	7-144
	(5) Paper is not fed from the MP tray.....	7-144
	(6) The same data is repeatedly printed out	7-144
	(7) PC window shows [Print job error], [Standby] or [Printer unavailable] is indicated on the printer properties... 7-145	
	(8) Attention lamp is lit while the printer standby message is indicated.	7-145
	(9) Print is not available in sleep mode due to the main unit startup error. Attention lamp is turned on. ...	7-145
	(10) Print stops after printing several pages and locks up. Attention lamp on operation panel lights.	7-145
	(11) Print output is unavailable due to the network factor (1).....	7-146
	(12) Print output is unavailable due to the network factor (2).....	7-146
	(13) Print output is unavailable due to the network factor (3).....	7-146
	(14) Print output is unavailable due to the network factor (4).....	7-147
	(15) Print output is unavailable due to the network factor (5).....	7-147
	(16) Print output is unavailable due to the network factor (6).....	7-148
	(17) Print output is unavailable due to the network factor (7).....	7-148
	(18) Data is not printed out due to the printer driver setting (1)	7-149
	(19) Data is not printed out due to the printer driver setting (2)	7-149
	(20) Data is not printed out due to the printer driver setting (3)	7-149
	(21) Data is not printed out due to the printer driver setting (4)	7-149
	(22) Data is not printed out due to the printer driver setting (5)	7-150
	(23) Data is not printed out due to the printer driver setting (6)	7-150
	(24) Data is not printed out due to the printer driver setting (7)	7-150
	(25) The printed image is partly missing	7-150
	(26) "Paper Mismatch Error" appears	7-151
7 - 7	Error Messages	7-152
	(1) "Check the document processor" appears.....	7-152
	(2) [Error occurred in cassette X] is displayed (Cassette 1) even after removing/inserting the cassette and checking/removing paper remaining in the main unit 7-152	
	(3) [Error occurred in cassette X] is displayed (Cassette 2, 3) even after removing/inserting the cassette and checking/removing paper remaining in the main unit 7-153	
	(4) The cover open message appears after closing the front cover.....	7-153
	(5) The cover open message remains after closing the front cover	7-153
	(6) The add paper message appears while the paper is loaded on the MP tray.....	7-154

(7) When DP is used, [Remove the original from document processor] is wrongly displayed	7-154
7 - 8 Abnormal Noise	7-155
(1) Abnormal noise (Basic support).....	7-155
(2) Abnormal sounds from the paper conveying section	7-155
(3) Abnormal sound from the developer section	7-156
(4) Abnormal sound from the document processor	7-156
(5) Abnormal sound from the exit section	7-156
(6) Fan rotating sounds are noisy	7-157
(7) Abnormal sound from the paper feed section	7-157
(8) Abnormal sound from the MP feed section.....	7-157
(9) Abnormal sound from the fuser exit section	7-157
(10) Abnormal sound from the fuser section	7-157
(11) Abnormal sound from inside the machine	7-158
(12) Abnormal sound from inside the machine	7-158
(13) Abnormal sound from inside the machine	7-158
(14) Abnormal sound from rear side of the main unit.....	7-159
7 - 9 Malfunction	7-160
(1) The size of paper set in the cassette is misdetected or not displayed.....	7-160
(2) The main unit malfunctions even if turning on the power switch	7-160
(3) No display in the operation panel	7-161
(4) The operation panel remains displaying "WELCOME" and does not change	7-161
(5) The login fails with other than the ID card	7-162

8 PWBs 8-1

8 - 1 Description for PWB	8-1
(1) Main PWB	8-1
(1-1)PWB photograph	8-1
(1-2)Connector position	8-1
(1-3)Connector lists	8-2
(2) Enginee PWB	8-9
(2-1)PWB photograph	8-9
(2-2)Connector position	8-9
(2-3)Connector lists	8-10
(3) High voltage PWB.....	8-17
(3-1)PWB photograph	8-17
(3-2)Connector position	8-17
(3-3)Connector lists	8-18
(4) Low voltage PWB	8-19
(4-1)PWB photograph	8-19
(4-2)Connector position	8-19
(4-3)Connector lists	8-20
(5) Operation PWB.....	8-22
(5-1)PWB photograph	8-22
(5-2)Connector position	8-23
(5-3)Connector lists	8-24
(6) DP PWB.....	8-28
(6-1)PWB photograph	8-28
(6-2)Connector position	8-28
(6-3)Connector lists	8-29
8 - 2 Description for PWB (OPTION)	8-31
(1) PF PWB (PF-410/PF-471).....	8-31
(1-1)Connector position	8-31
(1-2)Connector lists	8-31
(2) BR PWB (AK-470)	8-34
(2-1)Connector position	8-34
(2-2)Connector lists	8-34
(3) DF PWB (DF-470)	8-36
(3-1)Connector position	8-36
(3-2)Connector lists	8-36

9	Appendixes	9-1
9 - 1	Repetitive defects gauge	9-1
9 - 2	Firmware environment commands	9-2
9 - 3	Chart of image adjustment procedures	9-10
9 - 4	Wiring diagram.....	9-14
(1)	Engine.....	9-14
(2)	Engine / ISU/ EH/ LVU/ Fuser	9-15
(3)	Operation Panel / LCD.....	9-16
(4)	Main/ Engine/ Operation Panel/ ISU/ LSU	9-17
(5)	Document Processor	9-18
9 - 5	Wiring diagram (Options).....	9-19
(1)	Paper feeder (PF-470/PF-471).....	9-19
(2)	Attachment Kit (AK-470): 32ppm model only.....	9-20
(3)	500 sheets Finisher (DF-470): 32ppm model only.....	9-21
9 - 6	Installation guide	9-22
(1)	IB-50	9-22
(2)	IB-51	9-24
(3)	IB-36	9-26
(4)	PF-470/PF-471	9-28
(5)	AK-470/DF-470	9-31
(6)	Fax System 13.....	9-34

1 Specification

1 - 1 Specifications

(1) Common function

Item		Description	
		32 ppm model	25 ppm model
		7 inch LCD	
Type		Desktop	
Printing Method		Electro-photography by semiconductor laser	
Paper Weight	Cassette	60 to 163 g/m ²	
	Multi Purpose Tray	60 to 256 g/m ²	
Media type	Cassette	Plain, Preprinted, Bond, Recycled, Vellum, Rough, Letterhead, Color, Prepunched, Thick, High Quality, Custom 1 to 8 (Duplex: Same as Simplex, exclude Vellum)	
	Multi Purpose Tray	Plain, Transparency, Preprinted, Labels, Bond, Recycled, Vellum, Rough, Letterhead, Color, Prepunched, Envelope, Cardstock, Thick, High Quality, Custom 1 to 8	
Paper Size	Cassette 1	A3, A4, A5, B4, B5, Ledger, Letter, Legal, Statement, Oficio II, 216×340 mm, Folio, 8K, 16K	
	Multi Purpose Tray	A3, A4, A5, A6, B4, B5, B6, 216×340 mm, Ledger, Letter, Legal, Statement, Executive, Oficio II, Folio, 8K, 16K, ISO B5, Envelope #10, Envelope #9, Envelope #6 3/4, Envelope Monarch, Envelope DL, Envelope C5, Envelope C4, Hagaki (Cardstock), Oufuku Hagaki (Return postcard), Youkei 4, Youkei 2, Custom(98 x 148 to 297 x 432 mm)	
Printable Area		Print margin for top and bottom is 4 mm, both sides is 3 ± 2.5 mm	
Warm-up Time (23°C/73.4°F, 60%)	Power on	21 seconds or less (Wi-Fi available model) 20 seconds or less (Wi-Fi unavailable model)	
	Low Power	8 seconds or less	
	Sleep	16.4 seconds or less	13.9 seconds or less
Paper Capacity	Cassette	550 sheets (64 g/m ²)* ¹ 500 sheets (80 g/m ²)* ¹	
	Multi Purpose Tray	100 sheets (A4/Letter or smaller)(64 g/m ²) 25 sheets (larger than A4/Letter)(64 g/m ²)	
Output Tray Capacity	Main tray	250 sheets (80 g/m ²)	
	Job separator	50 sheets (80 g/m ²)	
Image Write System		Semiconductor laser and electro-photography	
Light source		Tri-color LED	White LED
Scanning method		Flat surface scanning by the CCD image sensor	Flat surface scanning by the CIS image sensor
Photoconductor		a-Si drum (diameter 30 mm)	
Charging system		Contact main charger roller system	

Item		Description	
		32 ppm model	25 ppm model
		7 inch LCD	
Developer system		Mono component jumping developer system Toner replenishing: Automatic from the toner container	
Transfer system		Transfer roller method	
Separation system		Small diameter separation and separation needle (Impressing DC voltage)	
Cleaning system		Counter blade	
Charge erasing system		Exposure by cleaning lamp (LED)	
Fusing system		Heat/pressure fusing with fuser heat roller + Fuser pressure roller Heat source: Halogen heater Abnormally high temperature protection devices: thermal-cutout	
Memory		Standard: 1024 MB (On-Board) Maximum: 3072 MB (On-Board +2048MB DIMM)	
Large capacity storage		SSD 32 GB / 128 GB	
Interface	Standard	Hi-Speed USB: 1 Hi-Speed USB Host: 2 Network interface: 1 (1000Base-T/100Base-Tx/10BASE-T) USB-Host: 2 (USB Flash memory slot)	
	Option	eKUIO: 2 (FAX can be installed in the Slot1 only)	
Operating Environment	Temperature	10 to 32.5°C/50 to 90.5°F	
	Humidity	10 to 80%	
	Altitude	3500 m/11482 ft maximum	
	Brightness	1500 lux maximum	
Dimension (W x D x H)		590 x 590 x 688 mm / 23.23" x 23.23" x 27.09"	
Weight (without toner container)		Approx. 52 kg / Approx. 114.6 lbs	Approx. 49 kg / Approx. 108.0 lbs
Space Required (W x D)		873 x 590 mm / 34.37" x 23.23" (Using multi purpose tray)	
Power source		100V AC, 50/60Hz, 14.0A 120V AC, 60Hz, 11.8A 220-240V AC, 50Hz, 6A	

*1: Up to upper limit height line in the cassette.

(2) Copy Functions

Item		Description	
		32 ppm model	25 ppm model
Copy Speed (Cassette paper feed section)	A4/Letter	32 sheets/min	25 sheets/min
	A4-R/Letter-R	23 sheets/min	18 sheets/min
	A3/Ledger	17 sheets/min	12 sheets/min
	B4/Legal	17 sheets/min	12 sheets/min
	B5	32 sheets/min	25 sheets/min
	B5-R	20 sheets/min	16 sheets/min
	A5-R	15 sheets/min	12 sheets/min
First Copy Time (A4, place on the platen, feed from Cassette)		5.2 seconds or less	5.8 seconds or less
Zoom Level		Manual mode: 25 to 400%, 1% increments Fixed zoom rate: 400%, 200%, 141%, 122%, 115%, 100%, 86%, 81%, 70%, 50%, 25%	
Continuous Copying		1 to 999 sheets	
Resolution		600 × 600dpi	
Supported Original Types		Sheet, Book, 3-dimensional objects (maximum original size: A3/Ledger)	
Original Feed System		Fixed	

(3) Printer Functions

Item		Description	
		32 ppm model	25 ppm model
Printing Speed (Cassette paper feed section)	A4/Letter	32 sheets/min	25 sheets/min
	A4-R/Letter-R	23 sheets/min	18 sheets/min
	A3/Ledger	17 sheets/min	12 sheets/min
	B4/Legal	17 sheets/min	12 sheets/min
	B5	32 sheets/min	25 sheets/min
	B5-R	20 sheets/min	16 sheets/min
	A5-R	15 sheets/min	12 sheets/min
First Print Time (A4, place on the platen, feed from Cassette)		5.2 seconds or less	5.8 seconds or less
Resolution		Fine 1200, 600 × 600 dpi	
Operating System		Windows Vista, Windows 7, Windows 8, Windows 8.1, Windows 10, Windows Server 2008/R2, Windows Server 2012/R2, Windows Server 2016, Mac OS X v10.5 or later	
Interface		USB Interface Connector: 1 (Hi-Speed USB) Network interface: 1 (1000 BASE-T/100 BASE-TX/10 BASE-T (IPv6, IPv4, IPSec), 802.3az supported)	
Page Description Language		PRESCRIBE	
Emulations		PCL6 (PCL-XL/PCL-5e), KPDL3 (PostScript3 compatible), PDF, XPS, Open XPS	

(4) Scanner Functions

Item		Description	
		32 ppm model	25 ppm model
		CCD	
Resolution		300dpi x 300dpi (Default), 200dpi x 200dpi, 200dpi x 100dpi, 600dpi x 600dpi, 400dpi x 400dpi, 200dpi x 400dpi	
File Format		TIFF, PDF, XPS, OpenXPS, PDF (high compression), JPEG	
Scanning Speed ^{*1} (A4, 300 dpi, Image quality: Text/Photo original)	Single sided monochrome	300 × 300 dpi: 50ipm 600 × 600 dpi: 36ipm	300 × 300 dpi: 50ipm 600 × 600 dpi: 36ipm
	Single sided color	300 × 300 dpi: 50ipm 600 × 600 dpi: 36ipm	300 × 300 dpi: 50ipm 600 × 600 dpi: 30ipm
Interface		Ethernet (10 BASE-T/100 BASE-TX/1000 BASE-T)	
Transmission System		SMB, SMTP, SMTPoverSSL, FTP, FTPoverSSL, TWAIN ^{*2} , WIA ^{*2} , WSD	

*1 When using the document processor (except TWAIN and WIA scanning)

*2 Supported Operating Systems: Windows Vista, Windows Server 2008, Windows Server 2008 R2, Windows 7, Windows 8, Windows 8.1, Windows 10, Windows Server 2012, Windows Server 2012 R2, Windows Server 2016

(5) Document Processor

Item	Description
Document Processor system	Automatic feed system (pickup pulley system + torque limiter system)
Original type	Sheet originals
Paper Size	Maximum: A3/Ledger (297 × 432 mm) Minimum: A5-R/Statement-R (140 × 182 mm)
Paper Weight	1-sided: 45 to 160 g/m ² 2-sided: 50 to 120 g/m ²
Loading Capacity	50 sheets (50 to 80 g/m ²)* ¹

*1 Up to upper limit height line in the document processor.

(6) Option

(6-1)500 sheets × 1 Paper Feeder (PF-470)

Item	Description
Paper Supply Method	Friction roller feeder
	60 to 163 g/m ²
Media type	Plain, Recycled, Color
Paper Size	A3,A4R,A4,A5R,B4,B5R,B5,Folio,Ledger,Legal,LetterR,Letter,Statement,Executive,Oficio II,8K,16KR,16K
Paper Capacity	(No. Sheets: 550(64 g/m ²)×1 cassette / 500(80g/m ²)× 1 cassette)
Dimension (W × D × H)	590× 589× 352mm
Weight	Approx. 21 kg / Approx. 46.3 lbs
Power source	Supply from the main unit

(6-2)500 sheets × 2 Paper Feeder (PF-471)

Item	Description
Paper Supply Method	Friction roller feeder
Paper weight	60 to 163 g/m ²
Media type	Plain, Recycled, Color
Paper Size	A3,A4R,A4,A5R,B4,B5R,B5,Folio,Ledger,Legal,LetterR,Letter,Statement,Executive,Oficio II,8K,16KR,16K
Paper Capacity	No. Sheets: 550(64 g/m ²)×2 cassettes / 500(80g/m ²)× 2 cassettes
Dimension (W × D × H)	590× 589× 352mm
Weight	Approx. 21 kg / Approx. 46.3 lbs
Power source	Supply from the main unit

(6-3)500 sheets Finisher (DF-470) (32ppm model only)

Item		Description
Type		Hunger type
Number of Trays		1 tray
Paper weight		52 to 256 g/m ²
Number of sheets and size storage limit	no stapling	A3, B4, Ledger, Legal, Oficioll, 216×340mm, 8K: 250 sheets A4, A4R, B5, B5R, Letter, LetterR, ExcutiveR, 16K: 500 sheets
	Stapling When stapling 2 to 10 sheets	A3, B4, Ledger, Legal, 8K: 22 sets A4R, LetterR: 40 sets A4, B5, Letter, 16K: 45 sets
	Stapling When stapling 11 to 20 sheets	A3, B4, Ledger, Legal, 8K: 11 sets A4R, LetterR: 20 sets A4, B5, Letter, 16K: 22 sets
	Stapling When stapling 21 to 30 sheets	A3, B4, Ledger, Legal, 8K: 9 sets A4, A4R, B5, Letter, LetterR, 16K: 15 sets
	Stapling When stapling 31 to 50 sheets	A4, A4R, B5, Letter, LetterR, 16K: 9 sets
Number of sheets staple limit Paper Weight 90 g/m² or less		A3, B4, Ledger, Legal, 216×340mm, 8K: 25 sheets
Dimension (W × D × H)		416 × 521 × 275.5 mm / 16.38 " × 20.51 " × 10.85 "
Weight		Approx. 12 kg / Approx. 26.4lb or less

(6-4)FAX System (FAX System 13)


Item	Description
Compatibility	G3
Communication Line	Subscriber telephone line
Transmission Time	Less than 3 seconds (33600 bps, JBIG, ITU-T A4-R #1 chart)
Transmission Speed	33600/31200/28800/26400/24000/21600/19200/16800/14400/12000/9600/ 7200/4800/2400 bps
Coding Scheme	JBIG/MMR/MR/MH
Error Correction	ECM
Original Size	Max. width: 297 mm/11", Max. length: 1,600 mm/63"
Number of originals to auto feed	Max. 50 sheets (When using the document processor)
Resolution	Scan: 200 × 100 dpi Normal (8 dot/mm × 3.85 line/mm) 200 × 200 dpi Fine (8 dot/mm × 7.7 line/mm) 200 × 400 dpi Super (Super Fine) (8 dot/mm × 15.4 line/mm) 400 × 400 dpi Ultra (Ultra Fine) (16 dot/mm × 15.4 line/mm) Print: 600 × 600 dpi
Gradations	256 shades (Error diffusion)
One Touch Key	100 keys
Multi-Station Transmission	Max. 100 destinations
Substitute Memory Reception	700 sheets or more (when using ITU-T A4 #1)
Image Memory Capacity	Standard memory (12MB) (for FAX transmission/reception)
Report Output	Send result report, FAX RX result report, Activity report, Status page
Option	Handset

**Note**


Specification subject to change for improvement of performance without notice

1 - 2 Part Names

(1) Exterior




- | | | | |
|---|---|----|---|
| 1 | Cassette | 9 | DP top cover. |
| 2 | Paper width guides | 10 | DP feed roller |
| 3 | Paper length guide | 11 | DP pickup roller |
| 4 | MP tray | 12 | DP separation pulley |
| 5 | MP sub tray | 13 | DP original width guide |
| 6 | MP paper width guides | 14 | DP original tray |
| 7 | Main tray | 15 | USB Memory Slot |
| 8 | Operation panel PWB
(7-inch panel model) | 16 | Operation panel PWB
(4.3-inch panel model) |



- | | | | |
|----|---------------------------|----|-----------------------|
| 17 | Front Cover | 24 | feed-shift guide |
| 18 | Power switch | 25 | Drum unit |
| 19 | Waste punch box | 26 | Developer unit |
| 20 | Right cover 1 | 27 | Toner container lever |
| 21 | MP feed roller | 28 | Fuser unit |
| 22 | Registration roller right | 29 | Toner container |
| 23 | Transfer roller | | |


(2) Connectors/Interior



- 1 DP angle regulating plate
- 2 DP Connector cover
- 3 Control box cover
- 4 DF Interface connector (32ppm model only)
- 5 Cassette heater switch
- 6 Outlet connector (32ppm model only)
- 7 Inlet connector


- 8 USB Interface Connector
- 9 Network Interface Connector
- 10 Option interface (Slot 2)
- 11 Option interface (Slot 1)

(3) With Optional Equipments Attached



- 1 Finisher exit tray (32ppm model only)
- 2 Finisher (32ppm model only)
- 3 BR conveying section (32 ppm model only)
- 4 Cassette 2
- 5 Cassette 3

(4) FAX System




- 1 LINE Connector (L1)
Connect the modular cords for telephone line.
- 2 TEL Connector (T1)
When using an optional handset or available telephone, connect it here.

 **Note**


Press the power key at the front side of the main unit to turn the power off.

(5) Operation Panel Keys

7-inch panel model



4.3-inch panel model




*1: Except 100V model

No.	Product name	Description
1	[Home] key	Shift the function setting value to the default and move to the home screen
2	Function Key (1)	These keys enable various functions and applications to be registered.
3	Function Key (2)	These keys enable various functions and applications to be registered.
4	Function Key (3)	These keys enable various functions and applications to be registered.
5	[Numeric Keypad] key	Key to input the value in the panel
6	Job separator, LED	Blinking when operating the job separator
7	[Status / Job Cancel] key / LED	Transitions to the screens of copy and print job processing, each transmission processing status check, stop, and job priority processing (interruption).
8	[System Menu / Counter] key / LED	Displays on the LCD screen the transition to the system menu screen and total counter values (scan, print, etc.) inside the system.
9	[Reset] key	Transitions the function setting value to the default and displays the basic screen in each of the functions.
10	[Stop] key	Cancels or pauses the job in progress.
11	[Start] key / LED	Starts copying and scanning operations and processing for setting operations.
12	[Interrupt] key / LED	Displays the Interrupt Copy screen.
13	[Logout] key / LED	Authenticates user switching, and exits the operation for the current user
14	[Energy Saver] key / LED	Recovers from Sleep if in Sleep Mode.
15	Attention, LED	Lights or blinks when an error occurs.
16	Memory, LED	Blinks while the machine is accessing the SSD or USB memory (general purpose item).
17	Processing, LED	Blinks during print processing, Fax transmission, i-Fax transmission, scan transmission, Fax reception, i-Fax reception and print data reception.
18	Touch panel	Full color 7 inch LCD, Full color 4.3 inch LCD
19	[Enter] key	Confirm the numeric key input or on-going function setting. Links to [OK] on the touch panel.
20	[Quick No. Search] key	Direct the registration contents by number such as the address number, user ID, etc.
21	[Clear] key	Erases number or character input.

1 - 3 Optional Equipment

The following options are available for this machine.



(1) PF-470 <500 sheets × 1 Paper Feeder>

One additional cassette identical to the machine's cassette can be installed in the machine. Paper capacity and loading method are the same as the standard cassettes.

(2) PF-471 <500 sheets X 2 Paper Feeder>

Two additional cassettes identical to the machine's cassette can be installed in the machine. Paper capacity and loading method are the same as the standard cassettes.

(3) AK-470 <Attachment Kit> (32ppm model only)

Paper conveying unit from main unit exit to the finisher entry guide

(4) DF-470 <500 sheets Finisher> (32ppm model only)

This equipment can stack high capacity paper and can offset each copy to sort. Sorted output documents can be stapled.

(5) Expansion memory

Expanding memory enables more complex printing and speeds up print job processing. The optional Expansion Memory provides an additional 2048 MB of memory, allowing expansion up to 3072 MB.

(6) SD/SDHC memory card

The SD/SDHC memory card is a micro chip card that can be written optional fonts, macros, forms, etc.

(7) Card Authentication Kit(B) "Card Authentication Kit"

User login administration can be performed using ID cards. To do so, it is necessary to register ID card information on the previously registered local user list.

(8) HD-6/HD-7 <SSD>

With SSD installed in the machine, received data can be rasterized and stored on this SSD. This enables high-speed printing of multiple copies using an electric sort function. Also, the document box function can be used.

(9) IB-50 <Network Interface Kit>

The Network Interface Kit provides a high-speed connection for the Gigabit-per-second interface. IB-50 supports traditional protocols such as AppleTalk, Netware and so on.

Only supports minimum function of standard utilities.

(10) IB-51 <Wireless Network Interface Kit>

This is a wireless LAN interface card which supports the wireless LAN specifications IEEE802.11n (Max 300 Mbps) and 11 g/b. IB-51 supports traditional protocols such as AppleTalk, Netware and so on.

Only supports minimum function of standard utilities.

The IB-51 setup utility is compatible with a Windows OS and Mac OSX.

(11) IB-36 <Wireless Network Interface Kit> (220 to 240 V only (100/120V: standard))

This is a wireless LAN interface card which supports the wireless LAN specifications IEEE802.11n (max. 65 Mbps) and 11 g/b. In addition, network printing is possible without using the wireless LAN router because Wi-Fi Direct is supported.

(12) FAX System 12 <FAX Kit>

By installing the FAX kit, fax send/receive is enabled. Also, it is possible to use it as a network fax, by using it with a computer. Refer to the Fax operation guide for details.

(13) Data Security Kit(E) <Data Security Kit>

The Data Security Kit overwrites all unnecessary data in the storage area of the SSD so that it cannot be retrieved. The Data Security Kit encrypts data before storing it in the SSD. It guarantees higher security because no data cannot be decoded by ordinary output or operations.

(14) UG-33 <Thin Print Option>

This application allows print data to be printed directly without a print driver.

2 Installation

2 - 1 Environment

Installation environment

1. Temperature: 50 to 90.5°F (10 to 32.5°C) (But humidity should be 70% or less when the temperature is 90.5°F (32.5°C).)
2. Humidity: 10 to 80% (But the temperature should be 86°F (30°C) or less when humidity is 80%.)
3. Power requirements:

AC100V	50/60Hz	15A or more
AC110V	60Hz	13A or more
AC120V	60Hz	12A or more
AC220 to 240V	50Hz	7.2A or more
4. Frequency fluctuation: 50Hz+/-2% or 60Hz+/-2%

Installation location

The operative environmental conditions are as follows:

Adverse environmental conditions may affect the image quality. It is recommended to use the machine as follows:
Humidity: 36 to 65% Temperature: 60.8 to 80.6°F or less (16 to 27°C).


Avoid the following locations when selecting a site for the machine.

- Avoid locations near a window or with exposure to direct sunlight
- Avoid locations with vibrations
- Avoid locations with rapid temperature fluctuations
- Avoid locations with direct exposure to hot or cold air
- Avoid poorly ventilated locations

If the floor is delicate, when this machine is moved after installation, the floor material may be damaged by the casters. During operation, some ozone is released, but the amount does not cause any ill effect to one's health.


If, however, the machine is used over a long period of time in a poorly ventilated room or when making an extremely large number of copies, the smell may become unpleasant. To maintain the appropriate environment for copy work, it is suggested that the room be properly ventilated.

Installation space



2 - 2 Installing the main unit


Installation procedures



(1) Unpacking and checking bundled items

Take out the main unit and accessories from the packing case.
Remove the tape and cushioning materials for packing from the main unit.

(1-1) Main unit



- | | | |
|----------------------------|------------------------------|---------------------------|
| 1. Bottom case | 10. Spacer B | 19. Plastic bag |
| 2. Bottom pad R | 11. Outer case | 20. Job Separator Tray |
| 3. Bottom pad L | 12. Upper pad R | 21. Plastic bag (400x600) |
| 4. Machine cover (740x700) | 13. Upper pad L | 22. Hinge |
| 5. Main unit | 14. Power cord | 23. Inner case F |
| 6. Inner case R | 15. Toner container | 24. Inner case B |
| 7. Inner case L | 16. Plastic bag (400x600) | 26. Setup guide |
| 8. Spacer A | 17. DVD | |
| 9. Plastic bag (630x730) | 18. Installation guide, etc. | |




Caution

Make sure to install the main unit on a level surface.

(2) Notes on main unit transportation


When transporting the main unit, lift the front and rear handle of the lower part of the main unit with two persons as shown in the figure.

Do not hold the operation unit because it will cause damage.



(3) Attaching the job separator tray


- 1 Attach the job separator tray (a) by inserting it while aligning to the right guide (b) and the left guide (c).



(4) Unlocking the scanner mirror frame (CCD model only)

- 1 **Unlock the lock of the scanner mirror frame.**


- 1 Push the front side of the scanner lock cover (a) and slide it in the direction of the arrow (1) and (2) to remove the scanner lock cover (a).
 - 2 Rotate the scanner lock cover (a) (3), then insert the hook (b) of the scanner lock cover (a) into the opening, and attach it in the direction of the arrow (4).
- In case of omitting to unlock, C3100 occurs.



(5) Loading Paper

(5-1) Precaution for Loading Paper

Before loading paper in the cassette, fan the paper taken from a new package to separate it in the procedures below.



Fan the paper and align the edges at the flat place.
In addition, note the following points.

- If the paper is curled or folded, straighten it before loading. Such paper may cause a jam.
- If paper is left under high temperature and high humidity after taking it out of the package, it may cause trouble with paper absorbing moisture. After setting paper in the cassette, seal the rest of the paper in the paper storage bag. Also, seal the paper remaining on the MP tray in the paper storage bag.
- If paper is left in the cassette for a long period, heat from the cassette heater may discolor it.
- If the machine will not be used for a prolonged period, protect all paper from humidity by removing it from the cassettes and sealing it in the paper storage bag.

Important


If you reuse paper already used for printing, remove staples or clips. Do not use paper with a staple or clip. This may cause poor image quality or malfunctions.

(5-2) Set paper in the cassette

The cassettes can hold plain paper, recycled paper, color paper, etc.

The cassette can hold 550 sheets of plain paper (64g/m²) or 500 sheets of plain paper (80g/m²).

1 Pull the cassette completely out of the main unit.




Note

Do not pull out multiple cassettes simultaneously.


2 Adjust the position of the paper length guide.

- 1 Press the tab and slide the guides to the paper size to use.




3 Adjust the position of the paper width guides.

- 1 Press the tab and slide the guides to the paper size to use.



4 Load paper.

- 1 Fan the paper, then tap it on a level surface to align the edges.
- 2 Load the paper in the cassette after aligning its edges.






✔ Important

- Load the paper with the print side facing up.
- Before loading paper in the cassette, fan the paper taken from a new package to separate it. (See page [P. 2-6](#))
- Before loading the paper, be sure that it is not curled or folded. Such paper may cause paper jams.
- Make sure that the loaded paper does not exceed the level indicator (see the illustration above).
- If paper is loaded without adjusting the paper length guide and paper width guides to the paper size to use, the paper may skew or become jammed.

5 Check the paper length guide and paper width guide are securely aligned to the paper.

Re-align the paper length guide or paper width guide if gaps are observed.




6 Insert the paper size sheet.**7** Gently insert the cassette all the way into the main unit.

(6) Switching the cassette heater switch

1 Switch the cassette heater switch.

- 1 Release the hook (a) and remove the cassette heater switch cover (b).
- 2 Switch the cassette heater switch (C).
- 3 Reattach the cassette heater switch cover (b) in the original position.




Note

Turn on, only when using the cassette heater.

(7) Connecting the Power Cord


1 Connect one end of the supplied power cord to the main unit and the other end to a power outlet.

- Power is supplied when connecting the power cord.
- Only use the power cord that comes with the main unit.




(8) Setting up the Toner Container


- 1 Open the front cover.




- 2 Take out the new toner container.




- 3 Slightly tap the toner container.




4 Shake the toner container.



5 Install the toner container.




6 Close the front cover.



(9) Default Setting

The Machine Setup Wizard is launched when the equipment is turned on for the first time after being installed. Available of setting the necessary items. Also, it can be set from System Menu as below.



(9-1) Setting Date and Time

- 1 Display the screen.
[System Menu/Counter] key > [Date/Timer/Energy Saver]
- 2 Configure the settings.
[Time Zone] > [Date/Time] > [Date Format]

Item	Description
Time Zone	Set the time difference from GMT. Choose the nearest listed location from the list. If you select a region that utilizes summer time, configure settings for summer time.
Date/Time	Set the date and time for the location where you use the machine. If you perform Send as E-mail, the date and time set here will be displayed on the header. Value: Year (2000 to 2037), Month (1 to 12), Day (1 to 31), Hour (00 to 23), Minute (00 to 59), Second (00 to 59)
Date Format	Select the display format of year, month, and date. The year is displayed in Western notation. Value:

(9-2) Network Setup (LAN Cable Connection)

TCP/IP (IPv4) Settings

Set up TCP/IP (IPv4) to connect to the Windows network.
The default settings are as follows.

- TCP/IP: On
- DHCP: On
- Auto-IP: On
- IP Address: 0.0.0.0
- Subnet Mask: 0.0.0.0
- Default Gateway: 0.0.0.0

- 1 Select [System Menu/Counter] key > [System/Network] > Enter the Login User Name and the Login Password > [Wired Network Settings] > [TCP/IP Setting].

Note

The factory default login user name and login password are set as shown below.

- Login User Name/Login Password (25ppm model): 2500 / 2500
- Login User Name/Login Password (32ppm model): 3200 / 3200 (except 100V model)

- 2 Select [IPv4] for setting.

Important

Restart the network from System Menu, or turn the power off and then on waiting 5 seconds or more.

When using DHCP server

[DHCP]: Set to [On].

When setting the static IP address

[DHCP]: Set to [Off].

[IP Address]: Enter the address.

[Subnet mask]: Enter the subnet mask in decimal (0 to 255) separated by four dots.

[Default Gateway]: Enter the address.

[Auto-IP]: Set to [Off].

When setting Auto IP, set the IP address to 0.0.0.0.

(9-3) Paper size and media type setting

- 1 Select [System Menu/Counter] key > [Cassette/MP tray Settings].
- 2 Select [Cassette 1 (to 3)] or [MP Tray Setting].
- 3 Select [Paper Size] and [Media Type] to set them.

(10) Installing Software

Install appropriate software in your PC from the bundled DVD (Product Library) if you want to use the printer function of this machine or perform TWAIN / WIA transmission or Network FAX transmission from your PC. (See the Operation Guide supplied with the main unit)

(11) Output Maintenance Report (Execute maintenance mode U000)

- 1 Input "000" using the numeric keys and press the [Start] key.
- 2 Select [Maintenance] and press the [Start] key to output the maintenance report.
- 3 Press the [Stop] key.

(12) Clearing the counts (Maintenance mode U927)

- 1 Input "927" using the numeric keys and press the [Start] key.
- 2 Select [Execute].
- 3 Press the [Start] key to clear the counter value.
- 4 Press the [Stop] key.

(13) Setting the delivery date (Maintenance mode U278)


- 1 Input "278" using the numeric keys and press the [Start] key.
- 2 Select [Today].
- 3 Press the [Start] key to set the delivery date.
- 4 Press the [Stop] key.

(14) Exiting from the maintenance mode


- 1 Input "001" using the numeric keys and press the [Start] key.
 - The maintenance mode is exited.

(15) Completion of installing the main unit

- 1 Make sure that each indicator is not flashing, and then push the power switch (a). (OFF)



- 2 Select [Yes] in the confirmation screen.
 - It takes a few minutes for power off.
- 3 Push the power switch (a). (ON)



Important

After turning off the power switch, do not turn on the power switch again immediately. Wait 5 seconds or more, and then turn on the power switch.


2 - 3 Installing the optional devices

(1) Unpacking and checking bundled items

Take out the optional unit and accessories from the packing case.


Remove the tape and cushioning materials for packing from the optional unit.

(1-1) Paper Feeder (PF-470) (Option)




- | | | |
|---|--|--------------------------|
| 1. Paper Feeder | 7. Upper left rear cushioning material | 13. Plastic bag (70x110) |
| 2. Outer case | 8. Upper right front cushioning material | 14. Installation guide |
| 3. Inner case | 9. Upper right rear cushioning material | 15. Cursor pin |
| 4. Bottom left cushioning material | 10. Top spacer | 16. Paper size plate |
| 5. Bottom right cushioning material | 11. Poly sheet | |
| 6. Upper left front cushioning material | 12. Plastic bag (240x350) | |

(1-2) Paper Feeder (PF-471) (Option)




- | | | |
|---|--|--------------------------|
| 1. Paper Feeder | 7. Upper left rear cushioning material | 13. Plastic bag (70x110) |
| 2. Outer case | 8. Upper right front cushioning material | 14. Installation guide |
| 3. Inner case | 9. Upper right rear cushioning material | 15. Cursor pins |
| 4. Bottom left cushioning material | 10. Top spacer | 16. Paper size plate |
| 5. Bottom right cushioning material | 11. Poly sheet | |
| 6. Upper left front cushioning material | 12. Plastic bag (240x350) | |

(1-3) Attachment Kit (AK-470) (Option)



- | | | |
|-------------------------|-------------------------|--------------|
| 1. BR power supply unit | 5. BR lower right guide | 9. Upper pad |
| 2. Outer case | 6. Top spacer | 10. Pins |
| 3. Main pad | 7. BR conveying unit | |
| 4. Bottom spacer | 8. Tray bridge | |

(1-4) 500-sheet Finisher (DF-470) (Option)



- | | | |
|-----------------------|-----------------|------------------------|
| 1. Finisher main body | 5. Bottom pad L | 9. Upper pad R |
| 2. Outer case | 6. Bottom pad R | 10. DF exit tray |
| 3. Protect sheet | 7. Spacer | 11. Installation guide |
| 4. Poly sheet | 8. Upper pad L | 12. Stop rings |

(2) Optional unit installation

Install necessary optional units in the main unit by referring to the installation procedures.


Category	Product name	32 ppm model	25 ppm model	Page
Network	IB-50 (Network Interface Kit)	○	○	P. 9-22
	IB-51 (Wireless Network Interface Kit)	○	○	P. 9-24
	IB-36 (Wireless Network Interface Kit)	○	○	P. 9-26
PF	PF-470 (500-sheet x1 Paper Feeder)	○	○	P. 9-28
	PF-471 (500-sheet x2 Paper Feeder)	○	○	
DF	AK-470 (Attachment Kit)	○	×	P. 9-31
	DF-470 (500-sheet Hanger Finisher)	○	×	
FAX kit	FAX System 13	○	○	P. 9-34

2 - 4 Installing the optional parts

(1) Expansion memory

The machine can perform more multiple jobs simultaneously by adding more memory. The memory can increase up to maximum 3072MB by attaching the optional expansion memory (2048MB).

Precautions for Handling the Memory



Important

Static electricity that accumulates in your body through clothing or carpets may damage a memory. To protect a memory, discharge static electricity from your body by touching a water pipe (faucet) or other large metal object. Wear the anti-static wrist band on the wrist.


1 Remove the control box cover.

- 1 Turn off the main unit and disconnect the power cord and all interface cables.


Note

The shutdown confirmation screen is displayed. It might take about three minutes to shut down.

- 2 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).




- 2 Remove the screw (a) (M3 x 8) and open the memory slot cover (b) in the direction of the arrow.**



- 3 Attach the expansion memory.**

- 1 Align the terminal section of the expansion memory (a) to the socket (b) side and align the cut-out section with the protruding section of the socket, and insert it diagonally and straight.
- 2 Carefully press the inserted memory module toward the main unit.
- 3 Reattach the covers.



 **Note**

Detaching the expansion memory

To detach the expansion memory, remove the rear left cover from the main unit. Then, carefully push the two stoppers so that the expansion memory pops up from the socket.

Checking the expansion memory

In order to verify if the expansion memory is installed properly, print out a status page and check its content.

(2) SD/SDHC memory card

Reading the SD/SDHC memory Card

- The contents of the SD/SDHC memory card are read into the main unit after turning the power on.


1 Remove the control box cover.

- 1 Turn off the main unit and disconnect the power cord and all interface cables.


Note

The shutdown confirmation screen is displayed. It might take about three minutes to shut down.


- 2 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).



2 Release the hook (a) in the direction of the arrow, and then remove the SD card cover (b).



3 Install an SD/SDHC memory card (a) in the memory card slot (b).



4 Reattach the covers.

Formatting the SD/SDHC Memory Card

To use an unused SD/SDHC card, you must first format it with the main unit.

Formatting will delete all existing data on the SD card.

If you have installed an application, do not format the SD card to avoid the removal of the application in the SD card.

Format it with a PC or Prescribe command in advance.

Format procedure in the system menu

- 1 Press [System Menu/Counter] key.
- 2 By pressing [Λ] [V] key, select [Adjustment/Maintenance] > [Service Settings] > Enter the Login User Name and the Login Password > [Format SD Card].



Note

The factory default login user name and login password are set as shown below.

- Login User Name/Login Password (25ppm model): 2500 / 2500
- Login User Name/Login Password (32ppm model): 3200 / 3200 (except 100V model)

- 3 Select [Yes] to execute the initialization.
- 4 Press the [Stop] key.

(3) SSD (HD-6/HD-7)



1 Remove the control box cover.

- 1 Turn off the main unit and disconnect the power cord and all interface cables.


Note

The shutdown confirmation screen is displayed. It might take about three minutes to shut down.

- 2 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).

**2 Remove two screws (a)(M3x8) and then remove the option slot cover (b).****3 Attach the SSD to the main unit.**

- 1 Insert the PWB unit (a) straight into the option slot (c).
- 2 Attach the PWB unit (a) to the upper slot (Slot 2) with two screws (b) (M3x8) removed.



4 Reattach the covers.

- When installing a new SSD, the guidance to format will be displayed at the first startup.
- The memory LED blinks when forming a preview image in an SSD after restart if data exists in the FAX box.

Formatting the SSD

When an optional SSD is inserted into the main unit for the first time, it must be formatted before use. Formatting will delete all existing data on the SSD.

Format procedure in the system menu

- 1 Press [System Menu/Counter] key.
- 2 By pressing [^] [V] key, select [Adjustment/Maintenance] > [Service Settings] > Enter the Login User Name and the Login Password > [Format SSD].




Note

The factory default login user name and login password are set as shown below.

- Login User Name/Login Password (25ppm model): 2500 / 2500
- Login User Name/Login Password (32ppm model): 3200 / 3200 (except 100V model)

- 3 Select [Yes] to execute the initialization.
- 4 Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

(4) Card reader



Card reader installation requires the following parts (bundled in the main unit).


- Sponge *1 2 pcs
- Hook-and-loop fastener 2 pairs

1 Turn the power switch off and disconnect the power plug.


Note

The shutdown confirmation screen is displayed. It might take about three minutes to shut down.

2 Open the document processor (a).




3 Release two hooks (c) downwards and remove the card reader cover (b) in the direction of the arrow.




4 Affix the hook-and-loop fastener to the back side of the card reader.

- 1 Affix the sponge (b) * 1 and a pair of hook-and-loop fasteners (c) to each of the protrusions (a) of the ISU front cover.
- 2 Affix the card reader (d) aligning to the position of the affixed hook-and-loop fasteners (c).




5 Attach the card reader.

- 1 Connect the USB connector (b) to the main body connector.
- 2 Bundle the surplus length of the cable (c) and attach the card reader (a).




6 Reattach the card reader cover (a) in the original position and close the document processor.



*1: 100V specification only


(5) Handset (100V model only)




Handset installation requires the following parts:

Handset (1909AG9JP0)	1 pc
(Bundled parts)	
• Handset	1 pc
• Handset holder	1 pc
• Handset mounting plate	1 pc
• Protection cover	1 pc
• Pins	2 pcs
• Telephone wire	1 pc
• Modular cord	1 pc
• Nuts	2 pcs


- 1** Turn the power switch off and disconnect the power plug.
- 2** Attach the handset mounting plate (a) to the upper left portion of the main unit (c) with two pins (b).
 - Use the screw at the lower hole of the handset mounting plate.




- 3** Connect the connector (c) of the telephone cable (b) to the handset holder (a) and insert it into the cable guide (d) while extending the telephone cable (b).



- 4** Put the pins (b) into the two catches at the back side of the handset holder (a) and slide it toward you to fix it.




- 5** Attach the protection cover (a) to the handset mounting plate (b).




6 Connect the telephone cable (a) to the handset (b).


- Insert the telephone cable (a) into between the handset holder (c) and the main body (d).




7 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).



8 Connect the connector (b) of the modular cord (a) to the TEL terminal (c) of the FAX PWB and reattach the removed controller box cover.



9 Connect the other end of the modular cord (a) to the handset holder (b).



2 - 5 About Optional Applications

application	
Data Security Kit	ThinPrint Option* ¹
Card Authentication Kit* ¹	

*1: This can be used on a trial basis for a limited time.

*Restrictions such as the number of times the application can be used during the trial period differ depending on the application.

*If you change the date/time while using the trial version of an application, you will no longer be able to use the application.

Starting Use of an Application

Use the procedure below to start using an application.

- 1 Select [System Menu/Counter] key > [System/Network] > Enter the Login User Name and the Login Password > [Optional Function].



Note

The factory default login user name and login password are set as shown below.

- Login User Name/Login Password (25ppm model): 2500 / 2500
- Login User Name/Login Password (32ppm model): 3200 / 3200 (except 100V model)

- 2 Select the desired application to start use and select [Activate].
 - You can view detailed information on the selected application by selecting [] or [Details].

Item
Function
License
Trial Counts
Date of Trial
Status

- 3 Select [Official] and enter a license key.

Some applications do not require you to enter a license key. If the license key entry screen does not appear, go to Step 4. To use the application as a trial, select [Trial] without entering the license key.
- 4 Select [Yes] in the confirmation screen.

Icons of activated application are displayed in the Home screen.

Installing OCR dictionary

[System Menu/Counter] key > [System/Network] > [OCR dictionary installation]

- When installing the OCR dictionary firmware, it is necessary that the SSD or the SD card has to be installed.
- It is necessary to format the SSD / SD card at the system menu in the main unit.



Note

If you started the Security Kit or Thin Print option and entered the license key, turn the power OFF/ON. Icons of activated application are displayed in the Home screen.

2 - 6 Initializing procedures after installing the FAX system

- 1 Connect the power plug of the main unit to the outlet and turn the power on.
- 2 Input "10871087" using the numeric keys to enter the maintenance mode.
- 3 Input "600" using the numeric keys and press the [Start] key.
- 4 Select [Country Code] and enter a country code using the numeric keys.
 - Refer to the following country code list.
- 5 Select [Execute].
- 6 Press the [Start] key to start data initialization.
 - Press the [Stop] key to cancel the data initialization.

Country code list

Country code	Destination	Country code	Destination
000	Japan	181	North America *2
156	Asian nations *1	181	South America *3
254	Taiwan	253	European nations *4
097	Korea	009	Australia
038	China	126	New Zealand *5

*1 Applied for Sales company competent Singapore, India, Thailand, Hong Kong.

*2 Applied for Sales company competent USA, Canada, Mexico.

*3 Applied for Sales company competent Bolivia, Chile, Peru, Argentina, Brazil.

*4 Applied for Sales company competent Italy, Germany, Spain, U.K., Netherlands, Sweden, France, Austria, Switzerland, Belgium, Denmark, Finland, Portugal, Ireland, Norway, Turkey, Russia, Saudi Arabia.

*5 Change the country code when selling in New Zealand. The country code to input is 126.

- 7 After completing installation, execute communication test to check if FAX normally operates.

Important

Note the following points when installing the FAX system in the line via ISDN or PBX.

Check if the line to connect supports the V.34 (Super G3) FAX communication.

Especially, when communicating between extensions in PBX (private line via TDM), only 14400bps or 9600bps of FAX communication speed is guaranteed and communication errors or TX/RX image failure may occur at V.34 communication in such a line.

Corrective Measures

Set the following maintenance mode if the communication speed guaranteed on the line is 14400bps.



U633 [Enables or disables the V.34 communication]: Off (See page [P. 6-154](#))

U630 [Setting TX speed and RX speed] (See page [P. 6-149](#))

3Machine Design



3 - 1 Mechanical Configuration

(1) Cross-section view (CCD model)



- | | |
|------------------------------------|---------------------------------|
| 1. Cassette | 9. Toner container |
| 2. Cassette paper feed section | 10. Fuser section |
| 3. MP paper feed section | 11. feed-shift and exit section |
| 4. registration roller | 12. Duplex conveying section |
| 5. Transfer and separation section | 13. Image scanner unit |
| 6. Main charger section | 14. Laser scanner unit |
| 7. Drum and cleaning section | 15. Document Processor |
| 8. Developer section | |


(2) Cross-section view (CIS model)



- | | |
|------------------------------------|---------------------------------|
| 1. Cassette | 9. Toner container |
| 2. Cassette paper feed section | 10. Fuser section |
| 3. MP paper feed section | 11. feed-shift and exit section |
| 4. registration roller | 12. Duplex conveying section |
| 5. Transfer and separation section | 13. Image scanner unit |
| 6. Main charger section | 14. Laser scanner unit |
| 7. Drum and cleaning section | 15. Document Processor |
| 8. Developer section | |


3 - 2 Extension device construction (option)

(1) 500-sheet x1 Paper Feeder cross-section view (PF-470)



1. Cassette paper feed section (Cassette 2)


(2) 500-sheet x2 Paper Feeder cross-section view (PF-471)



1. Upper paper feed section (Cassette 2)


2. Lower paper feed section (Cassette 3)

(3) Attachment kit cross-section view (AK-470)



- 1. BR paper conveying section

(4) 5000-sheet Finisher cross-section view (DF-470)




- 1. Finisher process section
- 2. Exit tray section
- 3. Power supply unit section

3 - 3 Electric parts


(1) Wire connection

(1-1)(Machine rear side)



- | | |
|------------------------|------------------------------------|
| 1. Main PWB | 10. Lift motor |
| 2. Engine PWB | 11. Fuser pressure release motor |
| 3. eKUIO PWB | 12. Exit fan motor |
| 4. Fuser motor | 13. DF PWB |
| 5. Developer motor | 14. DP feed-shift motor |
| 6. Main motor | 15. DP conveying motor |
| 7. Registration clutch | 16. DP feed motor |
| 8. Duplex clutch | 17. Temperature/humidity fan motor |
| 9. Feed clutch | |

(1-2)Machine inside



1. Low voltage PWB
2. High voltage PWB
3. Thermopile

4. Zener PWB
5. Laser scanner unit
6. Power source fan motor

(2) Descriptions about the major PWBs

(2-1)Main PWB

High Model



Low Model




Control the entire software for the interface to the PC and network and image data processing, etc.

(2-2)Engine PWB



Control the entire hardware to generate the high-voltage and the bias and for the paper conveying system and the tuser temperature, etc.


(2-3)High voltage PWB



Output the main high-voltage, the developer bias and the transfer bias.

(2-4)Low voltage PWB

100-120V



220-240V



Rectify the AC power input to the full-wave, convert it to DC24V by switched mode and output it. Also, control the tuser heater.

(2-5)Operation panel main PWB

High Model




Low Model



Control the LCD, the LED indicators and the key switches.


(2-6)DP PWB



Control the driver circuit of the motors and clutches, and the electric parts.

(3) PWBs

(3-1)Layout



Front side: / Inside: / Back side:

- | | |
|---|---|
| <ul style="list-style-type: none"> 1. DP PWB 2. CIS PWB *1 3. Wi-Fi PWB 4. LED drive PWB *2 | <ul style="list-style-type: none"> Controlling the driver circuit of the motors and clutches, and the electric parts. Front side original scanning Sending and receiving the wireless data. Controlling the LED |
|---|---|

5. Main PWB	Controlling the entire software for the interface to the PC and network and image data processing, etc.
6. CCD PWB *2	Original image scanning
7. Enginee PWB	Controlling of the entire hardware to generate the high-voltage and the bias, and for the paper conveying system and the fuser temperature, etc.
8. High voltage PWB	Generating the main charger high-voltage, the developer bias and the transfer bias
9. Developer relay PWB	Configuring the Enginee PWB and the developer unit wiring relay circuit.
10. Toner container relay PWB	Configuring the Enginee PWB and the toner container wiring relay circuit.
11. Drum relay PWB	Configuring the Enginee PWB and the drum unit wiring relay circuit.
12. Operation panel PWB *3	Controlling the LCD, the LED indicator and the key switches.
13. Operation panel PWB *4	Controlling the LCD, the LED indicator and the key switches.
14. Panel key PWB L *4	Configuring the LED indicator and the key switches.
15. Panel key PWB L *3	Configuring the LED indicator and the key switches.
16. NFC PWB *4	Antenna circuit for wireless communication.
17. NFC PWB *3	Antenna circuit for wireless communication.
18. Panel key PWB R	Configuring the LED indicator and the key switches.
19. Low voltage PWB	Rectifying the AC power input to the full-wave, convert it to DC24V by switched mode and output it. Controlling the fuser heater.
20. Drum PWB	Wiring relay to the electric parts inside drum unit Individual drum information storage by EEPROM
21. Developer PWB	Wiring relay to the electric parts inside developer unit
22. APC PWB	Emitting and controlling the laser beam
23. LED PWB F *2	Emitting the LED
24. LED PWB R *2	Emitting the LED
25. Zener PWB	Voltage potential control of fixing heat roller (countermeasure for offset)

*1: CIS model only, *2: CCD model only, *3: 4.3-inch panel model only, *4: 7-inch panel model

(3-2)Part name table

No.	Name used in service manual	Name used in parts list	Part. No.
1	DP PWB	PARTS PWB DP MAIN ASSY SP (PARTS DP UNIT SP)	302P194180 (302P193100)
2	CIS PWB *1	- (PARTS CIS ASSY SP)	- (302P293010)
3	Wi-Fi PWB	PARTS WIFI UNIT SP	302P194130
4	LED drive PWB *2	- (PARTS MOUNT LED ASSY)	- (302P193110)
5	Main PWB	PARTS PWB MAIN ASSY SP PARTS PWB MAIN ASSY SP EU PARTS PWB MAIN ASSY SP PARTS PWB MAIN ASSY SP EU	302P294030 *5 302P294040 *5 302P194140 *6 302P194150 *6


No.	Name used in service manual	Name used in parts list	Part. No.
6	CCD PWB *2	PARTS ISU SP	302P193120
7	Enginee PWB	PARTS PWB EngineE ASSY SP	302P194170
8	High voltage PWB	PARTS UNIT HIGH VOLTAGE SP	302P194260
9	Developer relay PWB	PARTS PWB DEVE CONNECT ASSY SP	302P194210
10	Toner container relay PWB	PARTS PWB CONTAINER CONNECT ASSY SP	302P194190
11	Drum relay PWB	PARTS PWB DRUM CONNECT ASSY SP	302K394080
12	Operation panel PWB *3	PARTS PWB PANEL MAIN ASSY SP (PARTS OPERATION UNIT SP)	302P294050 (302P294010)
13	Operation panel PWB *4	PARTS PWB PANEL MAIN ASSY SP (PARTS OPERATION UNIT SP) (PARTS OPERATION UNIT J SP)	302P194160 (302P194070) *6 (302P294020) *5
14	Panel key PWB L *4	- (PARTS OPERATION UNIT SP) (PARTS OPERATION UNIT J SP)	- (302P194070) *6 (302P294020) *5
15	Panel key PWB L *3	- (PARTS OPERATION UNIT SP)	- (302P294010)
16	NFC PWB *4	- (PARTS OPERATION UNIT SP) (PARTS OPERATION UNIT J SP)	- (302P194070) *6 (302P294020) *5
17	NFC PWB *3	- (PARTS OPERATION UNIT SP)	- (302P294010)
18	Panel key PWB R	- (PARTS OPERATION UNIT SP) (PARTS OPERATION UNIT SP) (PARTS OPERATION UNIT J SP)	- (302P294010) *3 (302P194070) *4, *6 (302P294020) *4, *5
19	Low voltage PWB	PARTS UNIT LOW VOLTAGE 100V SP PARTS UNIT LOW VOLTAGE 200V SP	302P194250 302P194240
20	Drum PWB	- (DK-6115)	- (302P193010)
21	Developer PWB	- (DV-6115)	- (302P193020)
22	APC PWB	- (LK-6115)	- (302P193080)
23	LED PWB F*2	- (PARTS MOUNT LED ASSY)	- (302P193110)
24	LED PWB R*2	- (PARTS MOUNT LED ASSY)	- (302P193110)
25	Zener PWB	PARTS PWB ZENER ASSY SP	302P194220

*1: CIS model only, *2: CCD model only, *3: 4.3-inch panel model only, *4: 7-inch panel model only

*5: 25 ppm model only, *6: 32 ppm model only

(4) Sensors and Switches

(4-1)Layout



Front side: / Inside: / Back side:

1. DP top cover switch

Configuring the safety circuit when the top cover open/close, and resetting the original jam.

2. DP feed sensor

Original jam detection at the primary feed.

3. DP feed-shift sensor

Reversing guide position detection

4. DP original sensor

Original set detection

5. DP original width sensor

Original width detection

6. DP original length sensor	Original length detection
7. DP registration sensor	Secondary paper feed timing detection
8. DP timing sensor	Original scan timing detection
9. DP open/close switch	DP open/close detection
10. Home position sensor *1	ISU home position detection
11. Home position sensor *2	ISU home position detection
12. Original size timing sensor *1	Original size sensor operation
13. Original size timing sensor *2	Original size sensor operation
14. Original size sensor *1	Original size detection
15. Original size sensor *2	Original size detection
16. JS paper full sensor	Job separator tray paper full detection
17. Paper full sensor	Main tray paper full detection
18. BR switch	Bridge detection
19. Right cover switch	24V power supply line shutoff when the right cover is open
20. JS paper sensor	Paper detection in the job separator section
21. Toner container lock sensor	Toner container lock detection
22. Toner container sensor	Toner container detection
23. Cassette heater switch	Cassette heater power supply on/off
24. Paper length switch	Cassette paper size (length) detection
25. Upper paper sensor	Cassette paper level detection
26. Lower paper sensor	Cassette paper level detection
27. Paper width switch	Cassette paper size (width) detection
28. DU sensor	Duplex conveying timing control and paper jam detection
29. Registration sensor	Secondary paper feed timing control
30. Conveying sensor	Paper jam detection at the vertical conveying section
31. Lift sensor	Cassette lift plate upper limit detection
32. MP paper sensor	Paper detection in the MP tray
33. PF connection switch	PF connection detection
34. Exit sensor	Paper jam detection at the fuser section
35. Temperature/humidity sensor	Machine inside temperature and absolute humidity detection
36. Thermopile	Fuser roller surface temperature detection
37. Front cover switch	24V power supply line shutoff when the front cover is open
38. Power switch	Power supply on/off to the main PWB, Enginee PWB, operation panel PWB, etc.
39. Toner sensor	Toner level detection in the toner container
40. Fuser thermistor	Fuser heat roller temperature detection
41. Fuser pressure release sensor	Fuser pressure mode detection
42. Waste toner sensor	Waste toner detection in the waste toner box

*1: CIS model only, *2: CCD model only

(4-2)Part name table


No.	Name used in service manual	Name used in parts list	Part. No.
1	DF top cover switch	INTER LOCK SWITCH (PARTS DP UNIT SP)	2FB27160 (302P193100)
2	DP feed sensor	PARTS SENSOR OPT SP (PARTS DP UNIT SP)	303M894260 (302P193100)
3	DP feed-shift sensor	PARTS SENSOR OPT SP (PARTS DP UNIT SP)	303M894260 (302P193100)
4	DP original sensor	PARTS SENSOR OPT SP (PARTS DP UNIT SP)	303M894260 (302P193100)
5	DP original width sensor	PARTS PWB PAPER SIZE SENSOR ASSY SP (PARTS TABLE ASSY SP) (PARTS DP UNIT SP)	303R394050 (302P194020) (302P193100)
6	DP original length sensor	PARTS SENSOR OPT SP (PARTS TABLE ASSY SP) (PARTS DP UNIT SP)	303M894260 (302P194020) (302P193100)
7	DP registration sensor	PARTS SENSOR OPT SP (PARTS DP UNIT SP)	303M894260 (302P193100)
8	DP timing sensor	PARTS SENSOR OPT SP (PARTS DP UNIT SP)	303M894260 (302P193100)
9	DP open/close switch	PARTS SENSOR OPT SP (PARTS DP UNIT SP)	303M894260 (302P193100)
10	Home position sensor *1	PARTS SENSOR OPT SP	303M894260
11	Home position sensor *2	SENSOR OPT.	7NXGP1S173LCH01
12	Original size timing sensor *1	PARTS SENSOR OPT SP	303M894260
13	Original size timing sensor *2	SENSOR OPT.	7NXGP1S173LCH01
14	Original size sensor *1	- (PARTS SENSOR OPT SP)	- (302ND94800)
15	Original size sensor *2	- (PARTS SENSOR OPT SP)	- (302ND94800)
16	JS full sensor	SENSOR OPT. (PARTS EXIT UNIT SP) (PARTS EXIT UNIT B SP)	7NXGP1S173LCH01 (302P194030) (302P194290) *3
17	Paper full sensor	SENSOR OPT. (PARTS EXIT UNIT SP) (PARTS EXIT UNIT B SP)	7NXGP1S173LCH01 (302P194030) (302P194290) *3
18	BR switch	SW.PUSH	7SP01000001+H01
19	Right cover switch	SW.MICRO	7SM010205+++H01
20	JS paper sensor	SENSOR OPT. (PARTS EXIT UNIT SP) (PARTS EXIT UNIT B SP)	7NXGP1S173LCH01 (302P194030) (302P194290) *3
21	Toner container lock sensor	SENSOR OPT.	7NXGP1S173LCH01
22	Toner container sensor	SW.PUSH	7SP01000001+H01

No.	Name used in service manual	Name used in parts list	Part. No.
23	Cassette heater switch	SW.SEESAW	7SC010105+++H01
24	Paper length switch	SW.PUSH	7SP03090001+H01
25	Upper paper sensor	SENSOR OPT.	7NXGP1S173LCH01
26	Lower paper sensor	SENSOR OPT.	7NXGP1S173LCH01
27	Paper width switch	SW.PUSH	7SP01000001+H01
28	DU sensor	SENSOR OPT. (PARTS CONVEYING UNIT)	7NXGP1S173LCH01 (302P194010)
29	Registration sensor	- (SENSOR FEED B)	- (303H327500)
30	Conveying sensor	SENSOR OPT.	7NXGP1S173LCH01
31	Lift sensor	SENSOR OPT.	7NXGP1S173LCH01
32	MP paper sensor	SENSOR OPT. (PARTS MPF ASSY SP)	7NXGP1S173LCH01 (302P194040)
33	PF connection switch	INTER LOCK SWITCH	2FB27160
34	Exit sensor	SENSOR OPT.	7NXGP1S173LCH01
35	Temperature/humidity sensor	PARTS PWB THERMISTOR ASSY SP	302R694190
36	Thermopile	PARTS THERMOPILE ASSY SP	302RH94110
37	Front cover switch	SWITCH INTERLOCK	303J945030
38	Power switch	PARTS PWB SWITCH ASSY SP	302NG94300
39	Toner sensor	PARTS CONT SENSOR ASSY SP	302KK94070
40	Fuser thermistor	- (FK-6115) (FK-6116) (FK-6117)	- (302P193040) *5 (302P193050) *4 (302P193060) *3
41	Fuser pressure release sensor	- (FK-6115) (FK-6116) (FK-6117)	- (302P193040) *5 (302P193050) *4 (302P193060) *3
42	Waste toner sensor	- (DK-6115)	- (302P193010)

*1: CIS model only, *2: CCD model only, *3: 120V model only, *4: 100V model only, *5: 220 to 240V model only

(5) Motors

(5-1) Layout



Front side: / Inside: / Back side:

- | | |
|---------------------------------|--------------------------------|
| 1. Scanner motor *2 | ISU wire drive |
| 2. Scanner motor *1 | ISU belt drive |
| 3. Exit fan motor | Fuser and exit section cooling |
| 4. Fuser pressure release motor | Fuser pressure release drive |
| 5. Fuser motor | Fuser and duplex system drive |

6. Main motor	Paper feed and drum system drive
7. Developer motor	Developer system drive
8. Exit motor	Exit system drive
9. Lift motor	Cassette lift plate operation
10. Conveying fan motor	Stabilize the paper conveying after transferring.
11. Power source fan motor	LLow voltage PWB cooling
12. LSU fan motor	Laser scanner unit cooling
13. Polygon motor	Polygon mirror drive
14. DP conveying motor	DP registration roller and DP conveying roller drive
15. DP feed motor	Original feed section drive
16. DP feed-shift motor	Original reversing and exit section drive
17. Temperature/humidity fan motor	Machine inside cooling

*1: CIS model only, *2: CCD model only

(5-2)Part name table


No.	Name used in service manual	Name used in parts list	Part. No.
1	Scanner motor *2	PARTS MOTOR ISU SP	302NG94211
2	Scanner motor *1	MOTOR REVERSE	302HN44100
3	Exit fan motor	PARTS FAN MOTOR SP	302NG94220
4	Fuser pressure release motor	PARTS DC MOTOR ASSY SP	302RV94180
5	Fuser motor	PARTS MOTOR-BL W10 SP (DR-6115)	302LC94292 (302P193090)
6	Main motor	PARTS MOTOR-BL W20 DRUM Z11 SP (DR-6115)	302LC94463 (302P193090)
7	Developer motor	PARTS MOTOR-BL W10 SP (DR-6115)	302LC94292 (302P193090)
8	Exit motor	MOTOR REVERSE (PARTS EXIT UNIT SP)	302HN44100 (302P194030)
9	Lift motor	PARTS MOTOR LIFT ASSY SP	302K394190
10	Conveying fan motor	FAN MOTOR PS40 (PARTS CONVEYING UNIT SP)	302HG44120 (302P194010)
11	Power source fan motor	PARTS FAN MOTOR SP	302NG94220
12	LSU fan motor	PARTS FAN MOTOR SP	302NG94220
13	Polygon motor	- (LK-6115)	- (302P193080)
14	DP conveying motor	PARTS MOTOR PAPER FEED SP (PARTS DP UNIT SP)	303R494040 (302P193100)
15	DP feed motor	PARTS MOTOR PAPER FEED SP (PARTS DP UNIT SP)	303R494040 (302P193100)

No.	Name used in service manual	Name used in parts list	Part. No.
16	DP feed-shift motor	MOTOR ROTARY (PARTS DP UNIT SP)	302KY44090 (302P193100)
17	Temperature/humidity fan motor	FAN MOTOR PS40	302HG44120

*1: CIS model only, *2: CCD model only

(6) Other parts

(6-1)Layout



Front side: / Inside: / Back side:

- 1. feed-shift solenoid
- 2. Developer clutch
- 3. Registration clutch
- 4. Duplex clutch
- 5. MP solenoid

- Paper output destination switching by operation of the feed-shift guide.
- Developer section drive control
- Secondary paper feed drive control
- Duplex conveying control
- MP lift plate control

6. Feed clutch	Primary paper feed control from the cassette
7. LCD *2	Operation panel display
8. LCD *1	Operation panel display
9. Cassette heater	Cassette section dehumidification
10. Fuser heater	Heating the fuser heat roller
11. DP registration clutch	DP secondary paper feed control
12. Thermal cutout	Fuser heater power supply shutoff when the fuser heat roller temperature is abnormally high.
13. Eraser	Removing the remaining electric charge on the drum.

*1: 4.3-inch panel model only, *2: 7-inch panel model only

(6-2)Part name table

No.	Name used in service manual	Name used in parts list	Part. No.
1	feed-shift solenoid	SOLENOID ASSY (PARTS EXIT UNIT SP) (PARTS EXIT UNIT B SP)	302F944090 (302P194030) (302P194290)
2	Developer clutch	PARTS CLUTCH 50 Z35R SP (DR-6115)	302NG94200 (302P193090)
3	Registration clutch	CLUTCH 50 Z35R (DR-6115)	302KV44041 (302P193090)
4	Duplex clutch	- (DR-6115)	- (302P193090)
5	MP solenoid	- (DR-6115)	- (302P193090)
6	Feed clutch	- (DR-6115)	- (302P193090)
7	LCD *2	PARTS TABLET OPERATION SP (PARTS OPERATION UNIT SP) (PARTS OPERATION UNIT J SP)	302NM94121 (302P194070) *4 (302P294020) *3
8	LCD *1	PARTS TABLET OPERATION SP (PARTS OPERATION UNIT SP)	302R494310 (302P294010)
9	Cassette heater	HEATER DEHUMIDIFIER 100 HEATER DEHUMIDIFIER 120 HEATER DEHUMIDIFIER 240	302RH44030 302RH44040 302RH44050
10	Fuser heater	- (FK-6115) (FK-6116) (FK-6117)	- (302P193040) *7 (302P193050) *6 (302P193060) *5
11	DP registration clutch	CLUTCH 50 Z35R (PARTS DP UNIT SP)	302KV44041 (302P193100)

No.	Name used in service manual	Name used in parts list	Part. No.
12	Thermal cutout	- (FK-6115) (FK-6116) (FK-6117)	- (302P193040) *7 (302P193050) *6 (302P193060) *5
13	Eraser	- (DK-6115)	- (302P193010)


*1: 4.3-inch panel model only, *2: 7-inch panel model only, *3: 25 ppm model only, *4: 32 ppm model only, *5: 120V model only,

*6: 100V model only, *7: 220 to 240V model only

3 - 4 Electric parts (Optional unit)

(1) Paper feeder (PF-470)

(1-1)Layout



1. PF PWB	Each electrical parts control in the paper feeder and serial communication with the main body
2. PF paper length switch	Paper length detection in the cassette 2
3. PF lift sensor 1	Upper limit detection when lifting the lift plate in the cassette 2
4. PF paper conveying sensor 1	Paper jam detection
5. PF paper width switch 1	Paper width detection in the cassette 2
6. PF upper paper sensor 1	Detecting the remaining paper level in the cassette2.
7. PF lower paper sensor 1	Detecting the remaining paper level in the cassette2.
8. PF lift motor 1	Cassette 2 lift plate operation
9. PF motor	Paper feed system drive
10. PF feed clutch 1	Feed roller and pickup roller drive
11. PF right cover switch	Configuring the safety circuit at the right cover open/close.
12. PF conveying clutch	Conveying roller drive
13. PF cassette heater	Paper dehumidification


(1-2)Part name table

No.	Name used in service manual	Name used in parts list	Part. No.
1	PF PWB	PARTS PWB PF MAIN ASSY SP	303NN94010
2	PF paper length switch 1	PUSH SWITCH 03 SN /SW-192 N	5ESP03090001+01

No.	Name used in service manual	Name used in parts list	Part. No.
3	PF lift sensor 1	SENSOR OPT.	7NXGP1S173LCH01
4	PF conveying sensor 1	SENSOR OPT.	7NXGP1S173LCH01
5	PF paper width switch 1	SW.PUSH	7SP01000001+H01
6	PF upper paper sensor 1	SENSOR OPT.	7NXGP1S173LCH01
7	PF lower paper sensor 1	SENSOR OPT.	7NXGP1S173LCH01
8	PF lift motor 1	PARTS MOTOR LIFT ASSY SP	302K394190
9	PF motor	PARTS MOTOR-BL W10 SP (PARTS DRIVE ASSY SP)	303NN94020 (303NP94010)
10	PF feed clutch 1	- (PARTS DRIVE ASSY SP)	- (303NP94010)
11	PF right cover switch	SW.PUSH	7SP01000001+H01
12	PF conveying clutch	- (PARTS DRIVE ASSY SP)	- (303NP94010)
13	PF cassette heater	HEATER DEHUMIDIFIER 100	302K302420

(2) Paper feeder (PF-471)

(2-1)Layout




- | | |
|--------------------------------|---|
| 1. PF paper length switch 1 | Paper length detection in the cassette 2 |
| 2. PF PWB | Each electrical parts control in the paper feeder and serial communication with the main body |
| 3. PF lift sensor 1 | Upper limit detection when lifting the lift plate in the cassette 2 |
| 4. PF paper conveying sensor 1 | Paper jam detection |
| 5. PF paper width switch 1 | Paper width detection in the cassette 2 |
| 6. PF upper paper sensor 1 | Detecting the remaining paper level in the cassette2. |
| 7. PF lower paper sensor 1 | Detecting the remaining paper level in the cassette2. |
| 8. PF lift motor 1 | Cassette 2 lift plate operation |
| 9. PF motor | Paper feed system drive |
| 10. PF feed clutch 1 | Feed roller and pickup roller drive in the cassette 2 |
| 11. PF right cover switch | Configuring the safety circuit at the right cover open/close. |
| 12. PF conveying clutch | Conveying roller drive |
| 13. PF feed clutch 2 | Feed roller and pickup roller drive in the cassette 3 |
| 14. PF lift motor 2 | Cassette 3 lift plate operation |
| 15. PF paper length switch 2 | Paper length detection in the cassette 3 |
| 16. PF cassette heater | Paper dehumidification |
| 17. PF lift sensor 2 | Upper limit detection when lifting the lift plate in the cassette 3 |
| 18. PF conveying sensor 2 | Paper jam detection |
| 19. PF paper width switch 2 | Paper width detection in the cassette 3 |
| 20. PF lower paper sensor 3 | Detecting the remaining paper level in the cassette 3. |
| 21. PF upper paper sensor 3 | Detecting the remaining paper level in the cassette 3. |

(2-2)Part name table

No.	Name used in service manual	Name used in parts list	Part. No.
1	PF paper length switch 1	PUSH SWITCH 03 SN /SW-192 N	5ESP03090001+01
2	PF PWB	PARTS PWB PF MAIN ASSY SP	303NN94010
3	PF lift sensor 1	SENSOR OPT.	7NXGP1S173LCH01
4	PF conveying sensor 1	SENSOR OPT.	7NXGP1S173LCH01
5	PF paper width switch 1	SW.PUSH	7SP01000001+H01
6	PF upper paper sensor 1	SENSOR OPT.	7NXGP1S173LCH01
7	PF lower paper sensor 1	SENSOR OPT.	7NXGP1S173LCH01
8	PF lift motor 1	PARTS MOTOR LIFT ASSY SP	302K394190
9	PF motor	PARTS MOTOR-BL W10 SP (PARTS DRIVE ASSY SP)	303NN94020 (303NP94010)
10	PF feed clutch 1	- (PARTS DRIVE ASSY SP)	- (303NP94010)
11	PF right cover switch	SW.PUSH	7SP01000001+H01
12	PF conveying clutch	- (PARTS DRIVE ASSY SP)	- (303NP94010)
13	PF feed clutch 2	- (PARTS DRIVE ASSY SP)	- (303NP94010)
14	PF lift motor 2	PARTS MOTOR LIFT ASSY SP	302K394190
15	PF paper length switch 2	PUSH SWITCH 03 SN /SW-192 N	5ESP03090001+01
16	PF cassette heater	HEATER DEHUMIDIFIER 100	302K302420
17	PF lift sensor 2	PARTS MOTOR LIFT ASSY SP	302K394190
18	PF conveying sensor 2	SENSOR OPT.	7NXGP1S173LCH01
19	PF paper width switch 2	SW.PUSH	7SP01000001+H01
20	PF lower paper sensor 2	SENSOR OPT.	7NXGP1S173LCH01
21	PF upper paper sensor 2	SENSOR OPT.	7NXGP1S173LCH01

(3) Attachment Kit (AK-470)

(3-1)Layout



Front side: / Inside: / Back side:

- | | |
|--------------------------|--|
| 1. BR cover switch | Configuring the safety circuit at the bridge cover open/close. |
| 2. BR conveying sensor 3 | Conveying paper detection in the bridge. (left side) |
| 3. BR PWB | Paper conveying system control in the bridge. |
| 4. BR conveying sensor 2 | Conveying paper detection in the bridge. (center) |
| 5. BR conveying sensor 1 | Conveying paper detection in the bridge. (right side) |
| 6. BR motor | Paper conveying drive control in the bridge. |
| 7. BR fan motor | Cooling inside the bridge. |

(3-2)Part name table

No.	Name used in service manual	Name used in parts list	Part. No.
1	BR cover switch	INTER LOCK SWITCH	2FB27160
2	BR conveying sensor 3	SENSOR OPT.	7NXGP1S173LCH01
3	BR PWB	PARTS PWB BRIDGE MAIN ASSY SP	303NS94010
4	BR conveying sensor 2	SENSOR OPT.	7NXGP1S173LCH01
5	BR conveying sensor 1	SENSOR OPT.	7NXGP1S173LCH01
6	BR motor	MOTOR REVERSE	302HN44100
7	BR fan motor	PARTS,FAN IMAGE SP	302FZ94660

(4) 500-sheet Finisher (DF-470)

(4-1)Layout



Front side: / Inside: / Back side:

1. DF PWB	Each electrical parts operation control
2. DF relay PWB	Configuring the Enginee PWB, DF PWB, BR PWB, and DF power source PWB wiring relay circuit.
3. DF power source PWB	Rectifying the AC power input to the full-wave, convert it to DC24V by switched mode and output it.
4. DF conveying sensor	Paper jam detection at the process section
5. DF adjusting sensor 1	Adjusting plate F home position detection
6. DF adjusting sensor 2	Adjusting plate R home position detection
7. DF exit sensor	Paper detection in the exit section
8. DF belt sensor	Bundle exit belt position detection
9. DF roller sensor	Bundle exit unit position detection
10. DF paper sensor 1	Paper holding lever position detection
11. DF paper sensor 2	Paper holding lever position detection
12. DF tray upper limit sensor	Exit tray upper limit detection
13. DF tray lower limit sensor	Exit tray lower limit detection
14. DF slide sensor	Staple unit slide position detection
15. DF staple cover switch	Staple cover open/close detection
16. DF staple position sensor	Staple unit position detection at the process section
17. DF top cover sensor	DF top cover open/close detection
18. DF belt solenoid	Bundle exit belt operation
19. DF paddle solenoid	Paddle rotation

20. DF paper solenoid	Paper holding lever operation
21. DF conveying motor	Conveying roller drive
22. DF bundle exit motor	Bundle exit unit drive
23. DF adjusting motor 1	Adjusting plate F drive
24. DF adjusting motor 2	Adjusting plate R drive
25. DF tray motor	Exit tray ascending and descending drive
26. DF roller motor	Exit roller drive
27. DF slide motor	Staple unit drive
28. DF staple motor	Staple operation

(4-2)Part name table


No.	Name used in service manual	Name used in parts list	Part. No.
1	DF PWB	PWB:PBA-CONTROL	305JS70260
2	DF relay PWB	PARTS PWB BRIDGE CONNECT ASSY SP (PARTS LVU BOX ASSY SP)	303NS94020 (303NS94130)
3	DF power source PWB	- (PARTS LVU BOX ASSY SP)	- (303NS94130)
4	DF conveying sensor	LVR-FE-SEN-ENT	305JA70880
5	DF adjusting sensor 1	GP1S73P2J00F	305JA70070
6	DF adjusting sensor 2	GP1S73P2J00F	305JA70070
7	DF exit sensor	GP1S73P2J00F	305JA70070
8	DF belt sensor	GP1S73P2J00F	305JA70070
9	DF roller sensor	GP1S73P2J00F	305JA70070
10	DF paper sensor 1	GP1S73P2J00F	305JA70070
11	DF paper sensor 2	GP1S73P2J00F	305JA70070
12	DF tray upper limit sensor	GP1S73P2J00F	305JA70070
13	DF tray lower limit sensor	GP1S73P2J00F	305JA70070
14	DF slide sensor	GP1S73P2J00F	305JA70070
15	DF staple cover switch	DE2L-FJ15	305JA70060
16	DF staple position sensor	GP1S73P2J00F	305JA70070
17	DF top cover sensor	GP1S73P2J00F	305JA70070
18	DF belt solenoid	SOL-TDS-F12G-68	305JA71490
19	DF paddle solenoid	SOLENOID:SOL-TDS-F12G-67A	305JS70270
20	DF paper solenoid	- (SOLENOID:ASY-YO-SOL)	- (305JS70270)
21	DF conveying motor	MOT-17PM-J343-P3VS	305JA70490
22	DF bundle exit motor	MOT-17PM-J052-G1VS	305JA70500
23	DF adjusting motor1	MOT-PM42M-048-NSE3	305JA71510

No.	Name used in service manual	Name used in parts list	Part. No.
24	DF adjusting motor 2	MOT-PM42M-048-NSF0	305JA71520
25	DF tray motor	MOTOR:MOTOR,DC GEARED (TRAY:ASY-S/P-TRY-S)	305JS70240 (305JS70290)
26	DF roller motor	MOT-17PM-J343-P3VS	305JA70490
27	DF slide motor	MOT-PM42L-048-NSE4	305JA71500
28	DF staple motor	- (STAPLER EH590)	- (303JY44010)

3 - 5 Drive system


(1) Drive configuration

Entire drive




A	MP paper feed section	E	Fuser section	15	Fuser motor
1	MP feed roller	9	Fuser pressure roller	16	Main motor
		10	Fuser heat roller	17	Developer motor
B	Cassette paper feed section	11	Fuser exit roller	18	Feed clutch
2	Retard roller			19	Duplex clutch
3	Feed roller	F	Exit section	20	Registration clutch
4	Pickup roller	12	Exit roller	21	Developer clutch
		13	JS exit roller		
C	Developer section	14	Exit motor		
5	Developer roller				
6	Agitation roller				
D	Drum section				
7	Drum				
8	Sweep roller				

Cassette drive




- | | | | |
|---|-------------|---|---------------|
| A | Main motor | 1 | Feed roller |
| B | Feed clutch | 2 | Retard roller |
| C | Lift motor | 3 | Pickup roller |

MP drive



- | | | | |
|---|--------------|---|----------------|
| A | Main motor | 1 | MP feed roller |
| B | MP solenoid: | | |


Drum drive



A Main motor

1 Drum

Developer drive



A Developer motor


B Developer clutch

1 Developer sleeve roller

2 Developer spiral roller A


3 Developer spiral roller B

Fuser drive




- | | | | |
|---|------------------------------|---|----------------------------------|
| A | Fuser motor | 1 | Fuser heat roller |
| B | Fuser pressure release motor | 2 | Fuser exit roller |
| | | 3 | Fuser pressure release cam shaft |

Exit/duplex drive




- | | | | |
|---|-------------|---|-------------------|
| A | Fuser motor | 1 | Lower exit roller |
| B | Exit motor | 2 | Upper exit roller |

(2) Drive location



- | | | | |
|---|-----------------|---|---------------------|
| 1 | Fuser motor | 4 | Registration clutch |
| 2 | Developer motor | 5 | Duplex clutch |
| 3 | Main motor | 6 | Feed clutch |

(3) Drive unit





3 - 6 Mechanical construction

(1) Paper feed section

The paper feed section consists of the cassette paper feed section and the MP tray paper feed section.


(1-1)Cassette paper feed section

The cassette can load 550 sheets paper (64g/m²) or 500 sheets paper (80g/m²). The cassette forwards paper by rotating the pickup roller and conveys it to the paper conveying section by rotating the paper feed roller. Multi-feeding is also prevented by the effect of the retard roller.




- | | | |
|------------------|-----------------------------|-----------------------------|
| 1. Pickup roller | 6. Paper length guide | 11. Paper width guides |
| 2. Feed roller | 7. Lift plate | 12. Width guide release tab |
| 3. Feed holder | 8. Lift operation plate | 13. Friction pad |
| 4. Retard roller | 9. Cassette base | 14. Unit release lever |
| 5. Retard holder | 10. Actuator (Paper sensor) | 15. Registration sensor |

Block diagram




(1-2)MP paper feed section

The MP tray can load 100 sheets paper (80g/m²). The paper on the MP tray is fed by rotating the MP feed roller while lifting up the MP lift plate by the MP solenoid. Multi-feeding is also prevented by the effect of the MP retard roller.



- | | | |
|----------------------|-----------------------------------|--------------------------|
| 1. MP feed roller | 4. Actuator
(MP paper sensor) | 7. MP paper width guides |
| 2. MP separation pad | 5. MP tray | 8. MP base |
| 3. MP lift plate | 6. MP sub tray | |

Block diagram




(2) Optical section

The optical section consists of the image scanner section for scanning the original and the laser scanner section to write the image.

(2-1) Image scanner section (CIS model)


The image on the original is exposed by the exposure lamp (LED) and the reflection light is scanned by the CIS to change the electric signal.

When using the document processor, the image scanner unit (ISU) stops at the original scanning position (slit glass) and scans the image from the original conveyed in the document processor.



- | | | |
|------------------|----------------------------|--------------------------------|
| 1. CIS | 5. Original size indicator | 9. ISU drive belt |
| 2. CIS carriage | 6. Slit glass | 10. Original size sensor |
| 3. ISU frame | 7. ISU upper frame | 11. Actuator (Original sensor) |
| 4. Contact glass | 8. Scanner shaft | 12. Scanner motor |



Block diagram



(2-2)Image scanner section (CCD model)


The image on the original is exposed by the exposure lamp and that reflection light is scanned by the CCD image sensor on the CCD PWB via three mirrors and the ISU lens to change the electric signal.

When using the document processor, the mirror frame A stops at the original scanning position (slit glass) and scans the image from the original conveyed in the document processor.




- | | | |
|----------------------------|--------------------|---------------------|
| 1. Contact glass | 7. Mirror frame A | 13. Mirror C |
| 2. Original size indicator | 8. Light guide | 14. ISU lens |
| 3. Slit glass | 9. LED drive PWB | 15. CCD PWB |
| 4. ISU frame | 10. Mirror A | 16. Lens unit cover |
| 5. Scanner motor | 11. Mirror frame B | |
| 6. ISU wire | 12. Mirror B | |

Block diagram




(2-3) Laser scanner unit

The charged drum surface is scanned by the laser emitted from the laser scanner units. The laser reflects to the polygon mirrors by rotating the polygon motor so that the laser scans horizontally to the image. The laser scanner unit has some lenses and mirrors, that adjust the diameter of the laser to focus the laser to the drum surface. Also, the LSU cleaning motor operates to automatically clean the LSU glass.



- | | | |
|--------------------------|------------------------|---------------|
| 1. Polygon motor | 6. APC PWB | 11. PD mirror |
| 2. $f\theta$ lens (sub) | 7. Collimator lens | 12. LSU base |
| 3. $f\theta$ lens (main) | 8. LD slit glass plate | 13. Drum |
| 4. LSU dust-proof glass | 9. LD mirror | |
| 5. LSU top cover | 10. PD lens | |



Block diagram



(3) Developer section


(3-1) Developer unit

The developer section consists of the magnet roller forming the magnetic brush, the sleeve roller forming the thin layer by replacing the toner, the developer blade, and the developer screw mixing up the toner. The toner density is adjusted by impressing the bias to the magnet roller and the sleeve roller. The toner amount inside the developer unit is detected by the toner sensor.



- | | | |
|----------------------|--------------------------|---------------------------------|
| 1. Developer roller | 5. Blade magnet | 9. Supply shutter |
| 2. Developer screw A | 6. Developer case | 10. DS pulley |
| 3. Developer screw B | 7. Upper developer cover | 11. Toner container drive shaft |
| 4. Developer blade | 8. Toner container | |

Block diagram




(4) Drum section

(4-1) Drum unit


In the main charger section, the main charger roller with the electric charge contacts the drum surface and rotates to charge the drum evenly.

In the cleaning section, toner remaining on the drum surface after transferring is removed by the cleaning blade, and collected to the waste toner box by the drum screw. The eraser consists of the LED lamp, and it removes the electric charge remaining on the drum before the main charge.



- | | | |
|-----------------------|--------------------|------------------------|
| 1. Drum | 6. Cleaning roller | 11. Separation claw |
| 2. MC roller | 7. Scraper | 12. Unit release lever |
| 3. MC cleaning roller | 8. Sweep roller | 13. Unit lock hook |
| 4. Main charger case | 9. Drum frame | |
| 5. Cleaning blade | 10. Eraser | |



Block diagram



(5) Conveying/transfer section


In the paper conveying section, fed paper is conveyed to the transfer and separation section.

The transfer section consists of the transfer roller, separation brush, drum separation claws, etc. The high-voltage output from the high-voltage PWB is impressed to the transfer roller, and transfer charge is applied. Paper after transferring is separated from the drum by impressing the separator high-voltage output from the high-voltage PWB to the separation brush.



- | | | |
|--------------------------|---------------------------------|-----------------------------|
| 1. drum separation claws | 5. Paper dust collecting sponge | 9. Separation needle holder |
| 2. Separation needle | 6. Registration roller L | 10. Conveying guide |
| 3. Transfer roller | 7. Pre-transfer pulley | 11. Conveying base |
| 4. Registration roller R | 8. Drum | 12. Fuser front guide |



Block diagram



(6) Fuser section


Paper from the transfer and separation section is pinched between the fuser heat roller and the Fuser pressure roller. The fuser heat roller is heated by the fuser heater, and is pressed by the Fuser pressure roller with the pressure added by the fuser pressure spring. So, toner is fused on the paper by that heat and pressure.

The surface temperature of the fuser heat roller is detected by the fuser thermistor and controlled by the Engine PWB. If the temperature at the fuser section is extremely high, the power line is shut off by the thermostat operation and the fuser heater is forced to turn off.





- | | | |
|--------------------------|-----------------------|----------------------------|
| 1. Fuser heat roller | 6. Fuser paper guide | 11. Fuser exit pulley |
| 2. Fuser main heater | 7. Fuser thermistor | 12. Actuator (Exit sensor) |
| 3. Fuser sub heater | 8. Fuser thermostat | 13. Discharger brush |
| 4. Fuser pressure roller | 9. Separator | 14. Handles |
| 5. Fuser upper frame | 10. Fuser exit roller | |

Block diagram




(7) Exit and feed-shift section

The exit and feed-shift section consists of the paper path from the fuser section to the Main tray, the job separator or the duplex conveying section.





- | | | |
|-------------------|---------------------------------------|--------------------------|
| 1. Exit pulley | 5. feed-shift guide | 9. Exit conveying base |
| 2. Exit roller | 6. Actuator
(Paper full sensor) | 10. Upper JS paper guide |
| 3. JS exit pulley | 7. Actuator
(JS paper full sensor) | 11. JS exit tray |
| 4. JS exit roller | 8. Actuator
(JS paper sensor) | 12. Exit pressure guide |

Block diagram




(8) Duplex conveying section

The duplex conveying section consists of the paper conveying path to forward the paper from the exit and feed-shift section to the paper conveying section in the duplex print.



- | | | |
|------------------------|-------------------------|---------------------|
| 1. Right cover | 3 DU conveying roller | 5. DU frame |
| 2. DU conveying pulley | 4. Actuator (DU sensor) | 6. Right exit guide |


Block diagram



(9) Document Processor


(9-1)Original paper feed section

The original feed section consists of the parts in the figure, and conveys the original on the DP original tray to the original conveying section. The original is fed by rotating the DP pickup and the DP feed roller.




- | | | |
|---------------------|----------------------------------|---------------------|
| 1. DP pickup roller | 4. DP retard roller | 7. DP stopper |
| 2. DP feed roller | 5. DP separation pad assy | 8. DP original tray |
| 3. DP feed holder | 6. Actuator (DP original sensor) | |

Block diagram




(9-2)Original conveying section, original reversing and exit section

The original conveying section consists of the parts in the figure. The conveyed original is scanned at the optical section (CCD) in the main unit when passing the DP slit glass.




- | | | |
|---------------------------|--|-----------------------------|
| 1. DP top cover | 7. DP conveying pulley B | 13. DP exit roller |
| 2. DP registration roller | 8. Actuator
(DP feed sensor) | 14. DP exit pulley |
| 3. DP registration pulley | 9. Actuator
(DP registration sensor) | 15. DP reversing roller |
| 4. DP conveying roller A | 10. Actuator
(DP timing sensor) | 16. DP reversing pulley |
| 5. DP conveying pulley A | 11. DP scanner guide | 17. DP original eject table |
| 6. DP conveying roller B | 12. DP feed-shift guide | 18. DP switchback tray |

Block diagram




(9-3) Reversing duplex scanning


The first side of original is scanned at the slit glass (main unit).




Conveyed to the DP reversing section by the DP reversing feed-shift guide / DP reversing roller.




The original is reversed by the reverse rotation of the DP reversing roller.



The second side of original is scanned at the slit glass (main unit) and the original is conveyed to the DP reversing section.



Ejected to the DP exit tray by the DP reversing, DP feed-shift and DP exit rollers.




3 - 7 Mechanical construction (option)

(1) Paper feeder (PF-470)

The paper feeder can load 550 sheets paper (64g/m²) or 500 sheets paper (80g/m²) and consists of one cassette. The cassette picks up paper by rotating the PF pickup roller and conveys it by rotating the PF feed roller. Multi-feed of paper is also prevented by the effect of the PF retard roller.

Fed paper is conveyed to the main unit by the PF conveying roller.




- | | | |
|--------------------------|-----------------------------|---|
| 1. PF pickup roller | 6. PF cassette base | 11. PF lower paper sensor 1 |
| 2. PF feed roller | 7. PF lift plate | 12. Actuator
(PF lift sensor) |
| 3. PF retard roller | 8. PF friction pad | 13. PF conveying sensor 1 |
| 4. PF conveying roller 1 | 9. PF lift operating plate | 14. Actuator
(PF conveying sensor 1) |
| 5. PF lift sensor 1 | 10. PF upper paper sensor 1 | |

(2) Paper feeder (PF-471)


The paper feeder can load 550 sheets paper (64g/m²) or 500 sheets paper (80g/m²) and consists of two cassette. The cassette picks up paper by rotating the PF pickup roller and conveys it by rotating the PF feed roller. Multi-feed of paper is also prevented by the effect of the PF retard roller.

Fed paper is conveyed to the main unit by the PF conveying roller.



- | | | |
|--------------------------|-------------------------------|---|
| 1. PF pickup roller | 9. PF cassette base | 17. Actuator
(PF lift sensor 1) |
| 2. PF feed roller | 10. PF lift plate | 18. Actuator
(PF lift sensor 2) |
| 3. PF retard roller | 11. PF friction pad | 19. PF conveying sensor 1 |
| 4. PF conveying roller 1 | 12. PF lift operating plate | 20. PF conveying sensor 2 |
| 5. PF conveying roller 2 | 13. PF upper paper sensor 1 | 21. Actuator
(PF conveying sensor 1) |
| 6. PF feed pulley | 14. PF lower paper sensor 1 | 22. Actuator
(PF conveying sensor 2) |
| 7. PF lift sensor 1 | 15. (PF upper paper sensor 2) | |
| 8. PF lift sensor 2 | 16. PF lower paper sensor 2 | |


Block diagram



*: Paper feeder (double cassette) only.


(3) Attachment Kit (AK-470)

The bridge unit section consists of the parts shown in the figure below. Paper exiting from the main unit is conveyed to the finishing section by the BR conveying roller.



- | | | |
|------------------------|--|--|
| 1. BR conveying roller | 3. Actuator
(BR conveying sensor 1) | 5. Actuator
(BR conveying sensor 3) |
| 2. BR conveying pulley | 4. Actuator
(BR conveying sensor 2) | |


Block diagram



(4) 500-sheet Finisher (DF-470)


(4-1) Finishing section

The finishing section consists of the parts below and the paper conveyed from the bridge unit is output to the DF tray. Also this section performs processing in the bundle exit mode and the staple mode.



- | | | |
|------------------------|-------------------------------|---------------------------|
| 1. DF conveying roller | 8. DF exit roller | 15. DF adjusting sensor 2 |
| 2. DF conveying pulley | 9. DF adjusting tray | 16. DF slide sensor |
| 3. DF conveying sensor | 10. DF exit pulley | 17. DF staple unit |
| 4. DF actuator | 11. DF paddle | 18. DF belt solenoid |
| 5. DF bundle exit belt | 12. DF exit sensor | 19. DF paddle solenoid |
| 6. DF conveying pulley | 13. Actuator (DF exit sensor) | |
| 7. DF bundle exit unit | 14. DF adjusting sensor 1 | |


Block diagram



(4-2)Exit tray section


The DF tray section consists of the parts shown in figure below and stocks the paper exit from the processing section. The upper limit position and the lower limit position of the DF tray are detected with the DF tray upper limit sensor and the DF tray lower limit sensor.

Also, the paper stock quantity is detected with the DF paper sensor 1, 2.




- | | | |
|---------------------------|----------------------|-------------------------------|
| 1. DF paper sensor 1 | 4. DF paper solenoid | 7. DF tray upper limit sensor |
| 2. DF paper sensor 2 | 5. DF tray | 8. DF tray lower limit sensor |
| 3. DF paper holding lever | 6. DF sub tray | 9. DF tray motor |

Block diagram




(4-3) Bundle exit operation


Paper is fed to the processing section by rotation of the DF conveying roller and the DF bundle exit belt. When the paper is conveyed into the processing section, the DF roller motor is driven to lift up the DF bundle exit unit.



When the trailing edge of paper passes through the DF bundle exit belt, the DF bundle exit unit is lifted down and the paper is fed to the DF adjusting tray by the DF eject roller and the DF bundle exit belt. The DF adjusting motor 1,2 drive the DF adjusting guides to adjust paper.



When adjustment of the last sheet of the bundle is completed, the DF exit roller and the DF paddle rotates to exit the bundle of paper to the DF tray.



4Maintenance

4 - 1 Precautions for the maintenance

(1) Precautions

Before disassembling the main unit, press the main power switch to turn the power off. Make sure that the power lamp on the operation panel is off and unplug the power cord from the wall outlet. Then, start the disassembly.

When handling the PWBs (printed wiring boards), do not touch parts with bare hands. Make sure not to damage the PWB.

If ICs are mounted on the PWB, do not touch them by hand or something charged with electrostatic.

Make sure to release the hook before disconnecting the connector with the hook.

Take care not to pinch up the wire and cable.

Use the original screws when reassembling the parts once disassembled.

If the types and the sizes of screws are not sure, refer to the parts list.

(2) Storage and handling of the drum

Note the following when handling and storing the drum.

When detaching the drum unit, never expose the drum surface to strong direct light.

Store in the range of ambient temperature of -20 to 40 degree C(-4°F to 104°F) and ambient humidity of 85% RH or less. Wait more than 5 seconds between the power off and on. Avoid storing the drum unit in the place where the temperature and humidity may suddenly change even if these changes are within the tolerable range.

Avoid exposure to any substance which is harmful or may affect the quality of the drum.

Do not touch the drum surface with any object.

Make sure not to touch the drum surface with bare hands or gloves.

If the drum is touched by hands or stained with oil, clean it.

(3) Storage of the toner container

Store the toner container in a cool, dark place.


Do not place the toner container under direct sunshine or in a damp environment.

(4) Screening of the toner container

Look at the screening film on the brand protection seal affixed to the toner container through the windows of the validation viewer.


Look at the screening film through two windows to check the genuineness.

- A black-colored band when seen through the the anti-counterfeit film portion left side window (mark ●).
 - A shiny or gold-colored band when seen through the anti-counterfeit film portion right side window (mark ☀).
- When seen as the above, it is genuine. Otherwise (e.g. both seen in gold), it is a counterfeit.



The brand protection seal has an incision as shown below to prohibit reuse.

Three cut parts at the red circle section



4 - 2 Maintenance parts

(1) Maintenance kits

For main unit

Service manual	Name used in parts list	Quantity	Part No.
MK-6115 *1	MK-6115/MAINTENANCE KIT		1702P18NL0
MK-6116 *2	MK-6116/MAINTENANCE KIT		1702P19JP0
MK-6117 *3	MK-6117/MAINTENANCE KIT		1702P17US0
MK-6119 *4	MK-6119/MAINTENANCE KIT		1702P18AS0
(300,000 images)	<ul style="list-style-type: none"> • DRUM UNIT • DLP UNIT • FUSER UNIT • TRANSFER UNIT • FEED UNIT • MP PULLEY FEED • M120V model IP PAD SEPERATION • REGISTRATION ROLLER CLEANER 	1 1 1 1 1 1 1 1	

*1: 220-240V model, *2: 100V model, *3: 120V model, *4: 240V model 120V model

For document processor

Service manual	Name used in parts list	Quantity	Part No.
MK-6110	MK-6110/MAINTENANCE KIT		1702P10UN0
(300,000 images)	<ul style="list-style-type: none"> • PULLEY FEED • GUIDE RETARD • ROLLER RETARD 	1 1 1	

(2) Executing the maintenance mode after replacing the maintenance kit

(2-1) Execute the following maintenance modes after replacing the maintenance kit.

Section	Mode No.	Maintenance item
Replacing settings	U251	Maintenance counter clear (Clear)
Image adjustment	U410	Adjusting the halftone automatically

(2-2) Maintenance mode to execute after replacing the unit

Drum unit

Section	Mode No.	Maintenance item
Image adjustment	U410	Adjusting the halftone automatically

Developer unit

Section	Mode No.	Maintenance item
Image adjustment	U410	Adjusting the halftone automatically

Transfer unit

Section	Mode No.	Maintenance item
Replacing settings	U127	Clearing the transfer count (Clear)
Image adjustment	U410	Adjusting the halftone automatically

MC roller

Section	Mode No.	Maintenance item
Replacing settings	U930	Clear the main charger roller counts (Clear)
Image adjustment	U410	Adjusting the halftone automatically

Feed roller / MP feed roller

Section	Mode No.	Maintenance item
Replacing settings	U901	Clearing the counters by paper source (Clear)

4 - 3 Maintenance parts replacement procedures


Replacement of the maintenance kit is required after about 300,000 images. The message [Replace MK.] appears at the replacement timing.

Execute maintenance mode U251 to reset the count after replacing the maintenance kit in the following procedures.

(1) Cassette feed section


(1-1) Detaching and reattaching the feed unit

- 1 Pull out the cassette (a) from the main unit (b) and remove it in the direction of the arrow.**



- 2 Detach the feed unit (a).**

- 1 Release the feed unit lock lever (a) and detach the feed unit (b).
- 2 Check or replace the feed unit (b), and then reattach the parts in the original position.




Execute the following setting after replacing the feed roller.


- Clearing the maintenance counts (Maintenance mode U251): Clear

(1-2) Detaching and reattaching the regist cleaner


- 1 Open the front cover (a).




- 2 Release the lock lever (a) and detach the waste toner box (b).



- 3 Release the lock lever (a) and open the developer cover (b).




4 Open the right cover 1 (a).



5 Detach the regist cleaner.


- 1 Pull out the regist cleaner (a) by holding the lever (b) of it.
- 2 Check the sponge of the regist cleaner (a) and clean or replace it.
- 3 Reattach the parts in the original position.



(2) MP feed section


(2-1) Detaching and reattaching the MP feed roller

1 Open the right cover 1 (a).



2 Detach the new MP feed roller.


- 1 Push the holder (a) inside and remove the MP feed roller (b).
- 2 Check or replace the MP feed roller and then reattach the parts in the original position.



(2-2) Detaching and reattaching MP separation pad

1 Detach the MP separation pad.

- 1 Tilt the MP separation pad (a) toward you and detach it in the direction of the arrow.
- 2 Check or replace the MP separation pad, and then reattach the parts in the original position.

**Caution**

When replacing the new MP separation pad or MP feed roller, take care not to touch the roller surface.


Execute the following setting after replacing the MP feed roller.

- Clearing the maintenance counts (Maintenance mode U251): Clear

(3) Transfer section


(3-1) Detaching and reattaching the transfer unit

1 Open the right cover 1 (a).



2 Detach the transfer unit.

- 1 Release two lock lever (a), Detach the transfer unit (b).
- 2 Check or replace the transfer unit (b), and then reattach the parts in the original position.



✔ Important




When reattaching the transfer unit, insert it until it clicks.

Execute the following setting after replacing the transfer unit.


- Checking/clearing the transfer counts (Maintenance mode U127): Clear

(4) Drum section

(4-1) Detaching and reattaching the drum unit


1 Open the front cover (a).**2** Release the lock lever (a) and remove the waste toner box (b).**3** Release the lock lever (a) and open the developer cover (b).

4 Open the right cover 1 (a).



5 Detach the drum unit.

- 1 Release the lock lever (a), Detach the drum unit (b).
- 2 Check or replace the drum unit (b), and then reattach the parts in the original position.




Execute the following setting after replacing the drum unit.

- Adjusting the halftone automatically (Maintenance mode U410)


(4-2) Detaching and reattaching the main charge roller unit

1 Detach the drum unit.

- 1 Release the lock lever (a), Detach the drum unit (b).

**2 Detach the MC roller unit.**




- 1 Release the lock lever (b), detach the MC roller unit (b) from the drum unit (c).
- 2 Check or replace the MC roller unit (a), and then reattach the parts in the original position.

**Execute the following setting after replacing the MC roller.**


- Clearing the main charger roller counts (Maintenance mode U930): Clear
- Adjusting the halftone automatically (Maintenance mode U410)

(5) Developer section


(5-1) Detaching and reattaching the developer unit

1 Open the front cover (a).**2** Release the lock lever (a) and detach the waste toner box (b).**3** Release the lever (a) and detach the toner container (b).

4 Release the lock lever (a).




5 Release the lock lever (a) and open the developer cover (b).



6 Detach the developer unit.

- 1 Release the lock lever (a) and detach the developer unit (b).
- 2 Check or replace the developer unit (b), and then reattach the parts in the original position.




Execute the following setting after replacing the developer unit.


- Adjusting the halftone automatically (Maintenance mode U410)

(6) Fuser section

(6-1) Detaching and reattaching the fuser unit

1 Open the right cover 1 (a).**2** Detach the fuser unit.

- 1 Pull up two handles (a).
- 2 Release the lock lever (b) and detach the fuser unit (c).
- 3 Check or replace the fuser unit (c), and then reattach the parts in the original position.



 **Important**


Insufficient lock will cause the phenomenon below when installing the fuser unit.

- Rear side lock failure (This will cause the fuser roller rotation failure without drive at the rear side.)
- Front side lock failure (This will cause the image squareness failure due to skew feed.)

(7) Document Processor


(7-1) Detaching and reattaching the DP pickup pulley and DP feed roller

1 Open the DP top cover (a).



2 Detach the DP feed roller.


- 1 Push up and open the DP feed lever (a).
- 2 Pull down the DP feed roller (b) toward you and detach it in the direction of the arrow.
- 3 Check or replace the DP feed roller (b), and then reattach the parts in the original position.




(7-2) Detaching and reattaching the DP retard roller

1 Detach the cover of DP retard roller cover.


- 1 Release the hook (a) and raise the DP retard roller cover (b) in the direction of the arrow .
- 2 Detach the DP retard roller cover (b) in the direction of the arrow.

**2 Detach the DP retard roller.**

- 1 Tilt up the tab of the DP retard roller holder.
- 2 Detach the DP retard roller (b) in the direction of the arrow.
- 3 Check or replace the DP retard roller (b), and then reattach the parts in the original position.

**Notes when attaching**

- 1 When attaching the DP retard roller holder (a) and pulling it down, make sure to check the protrusion (b) in inserted into the spring (c).




4 - 4 Maintenance parts replacement procedures (option)

(1) Paper feeder (PF-470/PF-471)


(1-1) Detaching and reattaching the feed unit

- 1 Pull out the cassette (a) from the paper feeder (b) and pull it out on an angle.



- 2 Detach the feed unit (a).

- 1 Release the lock lever (a) of feed unit, Detach the feed unit (b).
- 2 Check or replace the feed unit (b), and then reattach the parts in the original position.



Caution


When replacing the new pickup holder or retard holder, take care not to touch the roller surface.

4 - 5 Disassembly and Reassembly procedures


(1) OUTER COVERS

(1-1) Detaching and reattaching the front cover


- 1 Pull out the cassette (a) from the main unit (b) and remove it in the direction of the arrow.




- 2 Open the front cover (a).



- 3 Detach two hooks (b) of the straps (a).




4 Release the left and right fulcrums and detach the front cover (a).



(1-2) Detaching and reattaching the controller box cover


- 1 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).



(1-3) Detaching and reattaching the rear cover


- 1 Detach the rear cover.

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the rear cover, align it upward and release three hooks (c).




(1-4) Detaching and reattaching the main tray


- 1** Release the lock lever (b) and JS tray (a) in the direction of the arrow.




- 2** Pull out the cassette (a) from the main unit (b) and remove it in the direction of the arrow.



- 3** Open the front cover (a).




- 4 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).**




- 5 Detach the rear cover.**

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the rear cover, align it upward and release three hooks (c).




- 6 Remove the left lower cover.**

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the left lower cover (b), align it upward and release four hooks (c).




7 Detach the front top cover.

- 1 Release two hooks (b) of front top cover (a) and detach it.
- 2 Tilt the upper front cover (a) toward you.




8 Detach the main tray.




(1-5) Detaching and reattaching the tray rear cover


- 1** Release the lock lever (b) and JS tray (a) in the direction of the arrow.




- 2** Pull out the cassette (a) from the main unit (b) and remove it in the direction of the arrow.



- 3** Open the front cover (a).




- 4 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).**




- 5 Detach the rear cover.**

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the rear cover, align it upward and release three hooks (c).




- 6 Remove the left lower cover.**

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the left lower cover (b), align it upward and release four hooks (c).




7 Detach the front top cover.

- 1 Release two hooks (b) of front top cover (a) and detach it.
- 2 Tilt the upper front cover (a) toward you.




8 Detach the left top cover.




- 1 Remove two screws (b)(M3×8TP).
- 2 Release the two hooks (c) in the direction of the arrow and detach the left top cover (a).



9 Detach the tray left cover.

- 1 Release the hook (b) from the frame in the direction of the arrow.
- 2 Detach the tray left cover (a) while avoiding the tray rear cover (c).




10 Detach the main tray.**11 Detach the upper exit cover (a) while holding the tray rear cover (b).****12 Detach the tray rear cover (b).**



(1-6) Detaching and reattaching the MP tray

1 Detach the MP tray

- 1 Open the MP tray (a).
- 2 Release two fulcrums (b) of front and rear with a flat-blade screwdriver(c).
- 3 Detach two straps (d) while aligning them upward.
- 4 Detach the MP tray (a).




(1-7) Detaching and reattaching the right cover 1

1 Open the right cover 1 (a).**2** Remove two screws (b)(M3×8TP) and detach two strap (b) from main unit.**3** Detach the link of the conveying unit.


1 Detach the stop ring (b) from the back side of the conveying unit (a) and detach the link F (c).

2 Also, detach the stop ring (d) and then detach the link R (e).



4 Detach the right cover 1.


- 1 Rotate the wire cover (b).
- 2 Disconnect the connector (c).
- 3 Rotate the shaft (d), and slide it in the direction of the arrow.
- 4 Detach right cover 1 (a) while aligning it in the direction of the arrow.




(1-8) Detaching and reattaching the DP front cover

1 Remove the screw of the front cover.

- 1 Open the document processor (c).
- 2 Remove two screws (b)(M3×8TP) of the DP front cover (a).


**2 Detach the DP front cover.**

- 1 Open the DP top cover (b).
- 2 Detach the DP front cover (a) from the document processor (c).




(1-9) Detaching and reattaching the DP rear cover

- 1 Remove four screws (b) from the document processor (a).



- 2 Detach the DP rear cover.


- 1 Open the DP top cover (b).
- 2 Detach the DP original tray (a) while twisting it.





(1-10) Detaching and reattaching the DP original tray

1 Remove the screw of the front cover.


- 1 Open the document processor (c).
- 2 Remove two screws (b)(M3×8TP) of the DP front cover (a).

**2 Detach the DP front cover.**

- 1 Open the DP top cover (b).
- 2 Detach the DP front cover (a) from the document processor (c).


**3 Remove four screws (b) (M3×8TP) from the document processor (a).**

4 Detach the DP original tray (a) while twisting it.



5 Detach the DP original tray.


- 1 Remove the connector (b) from the DP PWB (c) and remove the cables (a) from five wire guides (d) .
- 2 Raise the DP original tray (e) and detach it in the direction of the arrow.




(2) Optical section

(2-1) Detaching and reattaching the LSU


- 1 Release the lock lever (b) and JS tray (a) in the direction of the arrow.




- 2 Pull out the cassette (a) from the main unit (b) and remove it in the direction of the arrow.



- 3 Open the front cover (a).




- 4 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).**




- 5 Detach the rear cover.**

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the rear cover, align it upward and release three hooks (c).




- 6 Remove the left lower cover.**

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the left lower cover (b), align it upward and release four hooks (c).




7 Detach the front top cover.

- 1 Release two hooks (b) of front top cover (a) and detach it.
- 2 Tilt the upper front cover (a) toward you.




8 Detach the main tray.




9 Detach the power source fan motor.

- 1 Disconnect the connector of the fan motor (b).
- 2 Remove one screw (c)(M3×8TP).
- 3 Release two hooks (c) and detach the power source fan motor assy.



10 Detach the laser scanner unit.

- 1 Disconnect two LSU connectors (b).
- 2 Remove four screws (c) and detach the laser scanner unit (a) in the direction of the arrow.
- 3 Check or replace the laser scanner unit (a), and then reattach the parts in the original position.




Notes when replacing the laser scanner unit

Execute the following adjustment after replacing the laser scanner unit.

Adjusting the halftone automatically (Maintenance mode U410)

- 1 Input "410" using the numeric keys.
- 2 Press the [Start] key.
 - Displays the execution information screen.
 - Test pattern 1 and Test pattern 2 are output on the A4 paper.
- 3 Set the output test pattern 1 as original, in the back side which the direction of the arrow is, looking down the side which is printing to the original glass.
 - Load about 20 sheets of the blank paper on Test Pattern 1.



- 4 Press the [Start] key.
 - The first auto adjustment is executed.
- 5 Set the output Test Pattern 2 as the original.
 - Set test pattern 2 and place approximately 20 sheets of white paper on it.
- 6 Press the [Start] key.

- The second auto adjustment is executed.
- 7 [Finish] appears after normal completion.



Exiting from the maintenance mode

- 1 Input "001" using the numeric keys and press the [Start] key.
- The maintenance mode is exited.

(2-2) Detaching and reattaching the document processor

1 Detach the DP connector of the document processor from the main unit.

- 1 Release the hook with a flat-blade screwdriver from the document processor (a) and detach the angle regulating plate (b).
- 2 Release two hooks (c) with a flat-blade screwdriver, detach the DP Connector cover (d).
- 3 Remove the wire saddles (e) and the DP connector cover (f).



**2 Open the document processor (a) to upright and detach the hinge (b) in the direction of the arrow.**

(2-3) Detaching and reattaching the image scanner unit (CCD model)

Detaching and reattaching the lens unit




1 Detach the DP connector of the document processor from the main unit.

- 1 Release the hook with a flat-blade screwdriver from the document processor (a) and detach the angle regulating plate (b).
- 2 Release two hooks (c) with a flat-blade screwdriver, detach the DP Connector cover (d).
- 3 Remove the wire saddles (e) and the DP connector cover (f).

**2 Open the document processor (a) to upright and detach the hinge (b) in the direction of the arrow.**


3 Remove two screws (b) and then remove the ISU right cover (a).

- Reattach it while aligning it to the contact glass side.


**4 Detach the contact glass (a).****5 Remove four screws (b) and then detach the lens unit cover (a).**

6 Detach the lens unit.

- 1 Remove the FFC (b) from the connector (c).
- 2 Remove four screws (d) and then detach the lens unit (a).



Note on disconnecting and connecting the FFC




Caution

To avoid the damage to the CCD PWB, do not touch the CCD PWB (c) but hold it at the directed part (d) when disconnecting and connecting the FFC (a) from/to the connector (b).

Notes when attaching the lens unit


- 1 When reattaching it, fix it to the original position by aligning it to the scale.
- 2 When replacing it, decide the fixing position of the ISU as follows.
 - The right and left of machine: Confirm the number (a) marked and align the ISU line (c) to the positioning line (b) at the frame with the same number. (Line (c) is at the applicable number marking side from two lines)
 - The rear and front of machine: Align the edge (e) of the ISU to the positioning line (d) of the frame.
- 3 Fix the ISU as originally with four screws.
- 4 Check or replace the lens unit, and then reattach the parts in the original position.




Detaching and reattaching the lamp unit

1 Detach the DP connector of the document processor from the main unit.

- 1 Release the hook with a flat-blade screwdriver from the document processor (a) and detach the angle regulating plate (b).
- 2 Release two hooks (c) with a flat-blade screwdriver, detach the DP Connector cover (d).
- 3 Remove the wire saddles (e) and the DP connector cover (f).







2 Open the document processor (a) to upright and detach the hinge (b) in the direction of the arrow.




3 Remove two screws (b)(M3×8TP) and then detach the ISU right cover (a).

- Reattach it while aligning it to the contact glass side.




4 Detach the contact glass (a).**5 Remove two screws (b)(M3×8TP) and then detach the ISU front top cover (a).****6 Remove two screws (b)(M3×8TP) and then detach the ISU rear cover (a).**

7 Detach the two transparent sheets (a) from the ISU frame (b).




8 Move the scanner carriage (a) to the cut-out.



9 Detach the lamp unit.

- 1 Remove the FFC (b) from the connector of the lamp unit (a).
- 2 Remove three screws (c) and detach the lamp unit (a).
- 3 Check or replace the lamp unit (a), and then reattach the parts in the original position.




✔ Important

Use an air blower brush when cleaning the light guide of the lamp unit. Clean not to leave a hair dust.


Detach the scanner wire

Execute it when the scanner wire is broken or is replaced.


- 1 Pull out the cassette (a) from the main unit (b) and remove it in the direction of the arrow.**



- 2 Open the front cover (a).**




- 3 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).**




4 Detach the rear cover.

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the rear cover, align it upward and release three hooks (c).




5 Remove the left lower cover.

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the left lower cover (b), align it upward and release four hooks (c).




6 Detach the DP connector of the document processor from the main unit.

- 1 Release the hook with a flat-blade screwdriver from the document processor (a) and detach the angle regulating plate (b).
- 2 Release two hooks (c) with a flat-blade screwdriver, detach the DP Connector cover (d).
- 3 Remove the wire saddles (e) and the DP connector cover (f).




7 Open the document processor (a) to upright and detach the hinge (b) in the direction of the arrow.






8 Detach the left top cover.

- 1 Remove two screws (b)(M3×8TP).
- 2 Release the two hooks (c) upward and detach the upper left cover (a).




9 Remove two screws (b) and then remove the ISU right cover (a).

- Reattach it while aligning it to the contact glass side.


**10 Detach the contact glass (a).****11 Remove two screws (b)(M3x8TP) and then detach the ISU front top cover (a).**

12 Remove two screws (b)(M3×8TP) and then detach the ISU rear cover (a).




13 Detach the IC card reader cover.

- 1 Release two hooks (b) downwards.
- 2 Detach the IC card reader cover (a) in the direction of the arrow.




14 Detach the language sheet.

- 1 Lift up two points of the leading edge of the operation panel cover (b), slide them in the direction of the arrow and then detach the operation panel cover from the operation panel (a).
- 2 Detach two clear panels (b) from the operation panel (a) and detach the language sheet (c).




15 Detach the operation top unit.

- 1 Remove two screws (b)(M3x8B).
- 2 Disconnect two connectors (d) of the operation panel PWB (c).
- 3 Detach the operation top unit (a).




16 Remove the wire of the power switch.


- 1 Release two hooks (b) of front top cover (a) and tilt it toward you.
- 2 Remove the connector (c) and remove the wire from two wire saddles (e).




17 Remove five screws (b)(M3x8TP) and then detach the operation lower cover (a).



18 Open the right cover 1 (a).




19 Detach the right top cover.




20 Detach the ISU front cover.

- 1 Remove two screws (b)(M3×8TP).
- 2 Release the hook(c) and three protrusions (d).
- 3 Detach the ISU front cover (a) in the direction of the arrow.




21 Remove the controller shield plate.

- 1 Remove four screws (b) (M3×8B) of the controller shield plate.
- 2 Slide the triangle mark (c) on the controller shield plate (a) in the direction of the arrow and detach it.




22 Disconnect the connector.


- 1 Disconnect two FFCs (b) from the main PWB (a).
- 2 Disconnect the connector (d) from the Engine PWB (b).




23 Remove two screws (b) (M3x8TP) and two header pins (c), and detach the scanner unit (a) upward.




24 Remove two screws (b) and then remove the ISU left cover (a).



25 Detach the two transparent sheets (a) from the ISU frame (b).




26 Move the scanner carriage (a) to the cut-out.




27 Detach the lamp unit.

- 1 Remove the FFC (b) from the connector of the lamp unit (a).
- 2 Remove two screws (c) and detach the lamp unit (a).




28 Detach the mirror unit A.

- 1 Remove one each screw (d) that secures the front wire keep plate (b) and rear wire keep plate (c).
- 2 Detach the mirror unit A(a) from scanner unit(e).



29 Detach the scanner wire.

- 1 Detach the scanner wire spring from hook(c).
- 2 Detach the scanner wire (a) and detach the scanner wire springs (b) from the round terminals (black marking) (d).



Reattach the scanner wire.

✔ Important

<Precautions>

When fitting the scanner wires, be sure to use those specified below.

Machine front side (P/N: 302K317150(gray))

Machine rear side(P/N: 302K317140(black))


<Fitting requires the following tools>

Two frame securing tools (P/N: 302FZ1710_)

Two scanner wire stoppers (P/N: 302RH9401_)


1 Detach the scanner wire drum assy.

- 1 Remove the screw (b) and detach the scanner wire drum gear (c).
- 2 Detach two screws (d) of scanner wire drum (a).
- 3 Detach the stop ring (f) and bushing (g) from the front side of the scanner wire drum shaft (e).
- 4 Detach the scanner wire drum (a) and the bushing (e) from scanner unit (h).




2 Fix the scanner wire.

- 1 Pass the ball (a) of the scanner wire through the hole of the scanner wire drum and wind the wire three times inside, and four times outside.
 - Shorter from small ball of the scanner wire is wound to come outside.
- 2 Secure the scanner wires (c) using the scanner wire stoppers (d).




3 Fix the position of the mirror frame B.

- 1 Reattach the scanner wire drum and the shaft to the scanner unit as originally.
- 2 Pass the mirror frame fixing parts (b) through the front and rear positioning holes for the scanner unit and fix the mirror frame B (a).




4 Reattach the scanner wire.

- 1 Hook the scanner wire at the out side of the main unit on the out side groove of the pulley of the mirror frame B.(1)
- 2 Hook the round terminals to the catches inside the scanner unit.(2)
- 3 Wind the inner scanner wires around the grooves in the pulleys at the left of the scanner unit from below to above.....(3)
- 4 Wind the scanner wires around the inside grooves in the pulleys of the mirror frame B from below to above.(4)
- 5 Wind the inner scanner wires around the grooves in the pulleys (f) at the left of the scanner unit(5)
- 6 Hook the round terminal on the scanner wire spring.(6)



5 Adjust the mirror frame position.

- 1 Detach the scanner wire stoppers and the frame securing tools.
- 2 Focusing on the locating ball of the wire drum, align the scanner wires to the inside.
- 3 Move the mirror frame B from side to side to correctly locate the wires in position.
- 4 Refit the mirror frame A in the main unit.
- 5 Move the mirror frames A (a) and the mirror frames B (b) to the machine left, and insert two frame securing tools (c) into the positioning holes at the front and rear of the scanner unit to secure the mirror frame A (a) and the mirror frame B (b) in position.
- 6 Attach the front wire holder plate and rear wire holder plate to the mirror frame A with each screw while holding the wire with the plates.
- 7 Detach the frame securing tools (c).
- 8 Reattach the parts in the original position.






(2-4) Detaching and reattaching the image scanner unit (CIS model)

Detaching and reattaching the CIS unit


1 Detach the DP connector of the document processor from the main unit.

- 1 Release the hook with a flat-blade screwdriver from the document processor (a) and detach the angle regulating plate (b).
- 2 Release two hooks (c) with a flat-blade screwdriver, detach the DP Connector cover (d).
- 3 Remove the wire saddles (e) and the DP connector cover (f).

**2 Open the document processor (a) to upright and detach the hinge (b) in the direction of the arrow.****3 Remove nine screws (b)(M3x8) and detach the contact glass (a).**


4 Detach the scanner carriage.

- 1 Remove the FFC (b) from the connector (c) of scanner carriage (a).
- 2 Detach the drive belt (d) from the fixing part (e) of the scanner carriage.
- 3 Detach the scanner carriage (a) from ISU lower frame (f).
- 4 Check the scanner carriage (a) and clean or replace it.
- 5 Reattach the parts in the original position.




Detaching and reattaching the image scanner unit


- 1 Pull out the cassette (a) from the main unit (b) and remove it in the direction of the arrow.



- 2 Open the front cover (a).




- 3 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).




4 Detach the rear cover.

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the rear cover, align it upward and release three hooks (c).




5 Remove the left lower cover.

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the left lower cover (b), align it upward and release four hooks (c).




6 Detach the DP connector of the document processor from the main unit.

- 1 Release the hook with a flat-blade screwdriver from the document processor (a) and detach the angle regulating plate (b).
- 2 Release two hooks (c) with a flat-blade screwdriver, detach the DP Connector cover (d).
- 3 Remove the wire saddles (e) and the DP connector cover (f).




7 Open the document processor (a) to upright and detach the hinge (b) in the direction of the arrow.




8 Detach the left top cover.

- 1 Remove two screws (b)(M3×8TP).
- 2 Release the two hooks (c) upward and detach the upper left cover (a).




9 Detach the IC card reader cover.

- 1 Release two hooks (b) downwards.
- 2 Detach the IC card reader cover (a) in the direction of the arrow.




10 Detach the language sheet.

- 1 Lift up two points of the leading edge of the operation panel cover (b), slide them in the direction of the arrow and then detach the operation panel cover from the operation panel (a).
- 2 Detach two clear panels (b) from the operation panel (a) and detach the language sheet (c).




11 Detach the operation top unit.

- 1 Remove two screws (b)(M3x8B).
- 2 Disconnect two connectors (d) of the operation panel PWB (c).
- 3 Detach the operation top unit (a).




12 Remove the wire of the power switch.


- 1 Release two hooks (b) of front top cover (a) and tilt it toward you.
- 2 Remove the connector (c) and remove the wire from two wire saddles (e).




13 Remove five screws (b)(M3x8TP) and then detach the operation lower cover (a).



14 Open the right cover 1 (a).




15 Release the three hooks (b) in the direction of the arrow and detach the right top cover (a).




16 Release three protrusions (b) upward and detach the ISU front cover.

- 1 Remove three screws (b)(M3x8TP).
- 2 Release the four hooks (c) in the direction of the arrow.
- 3 Detach the ISU front cover (a).




17 Remove the controller shield plate.

- 1 Remove four screws (b) (M3×8B) of the controller shield plate.
- 2 Slide the triangle mark (c) on the controller shield plate (a) in the direction of the arrow and detach it.




18 Disconnect the connector.

- 1 Disconnect the FFC (b) from the main PWB (a).
- 2 Disconnect the connector (d) from the Engine PWB (b).




19 Remove two screws (b) (M3x8TP) and two header pins (c), and detach the scanner unit (a) upward.



(3) Drive section


(3-1) Detaching and reattaching the drive unit

- 1 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).




- 2 Detach the rear cover.

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the rear cover, align it upward and release three hooks (c).




3 Detach the drive unit.

- 1 Remove four connectors (b) from Engine PWB (c) and lift motor (d).
- 2 Remove five screws (e)(M3×12B) and detach the drive unit (a).
- 3 Check or replace the drive unit (a), and then reattach in the original position the parts which are removed.



Notes when attaching the drive unit.



Check the position of the elevation cam (b) of the MP bottom plate at the backside of the drive unit (a). If it is at the B side than the reference line (c), rotate the main motor (d) manually to move the position of the elevation cam (b).



(3-2) Detaching and reattaching the main motor

1 Remove the motor assy.

- 1 Disconnect each connector (d) from three motors.
- 2 Remove five screws (b)(M3×8B) and detach the drive assy (a).


**2 Remove six screws (b)(M3x8) and detach three motors from the motor assy (e).****✔ Important**

When attaching the motor assembly, rotate the motor manually and align the phase of the motor shaft and drive unit gear.

(4) Detaching and attaching the other parts.


(4-1) Detaching and attaching the language sheet.

- 1 Lift up two points of the leading edge of the operation panel cover (b), slide them in the direction of the arrow and then detach the operation panel cover from the operation panel (a).




2 Detach the language sheet.

- 1 Detach two clear panels (b) from the operation panel (a).
- 2 Detach two language sheets.
- 3 Check or replace the language sheet, and then reattach the parts in the original position.




(4-2) Detaching and reattaching the exit fan motor

- 1 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).




- 2 Detach the rear cover.

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the rear cover, align it upward and release three hooks (c).




- 3 Detach the exit fan motor assy.

- 1 Remove the connector (c) and remove the wire (d) from hook (e).
- 2 Remove two screws (b)(M3×8TP) and then detach the exit fan motor assy(a).




(4-3) Detaching and reattaching the controller fan motor


- 1 Release the lock lever (b) and JS tray (a) in the direction of the arrow.




- 2 Pull out the cassette (a) from the main unit (b) and remove it in the direction of the arrow.



- 3 Open the front cover (a).




- 4 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).**




- 5 Detach the rear cover.**

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the rear cover, align it upward and release three hooks (c).




- 6 Remove the left lower cover.**

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the left lower cover (b), align it upward and release four hooks (c).




7 Detach the front top cover.

- 1 Release two hooks (b) of front top cover (a) and detach it.
- 2 Tilt the upper front cover (a) toward you.




8 Detach the main tray.




9 Detach the controller fan motor.

- 1 Remove the connector (c).
- 2 Remove two screws (b)(M3×8B) and then detach the controller fan motor (a).




(4-4) Detaching and reattaching the conveying fan motor.


- 1 Open the right cover 1 (a).



- 2 Release the front and rear lock levers (b) and close the conveying assembly (a).




- 3 Release five hooks (b) and detach the duplex conveying guide (a).




4 Detach the conveying fan motor assy.

- 1 Disconnect the connector (b) of the conveying fan motor.
- 2 Remove two screws (b)(M3×8B) and then detach the conveying fan motor assy (a).




(4-5) Detaching and reattaching the temperature/humidity fan motor.

- 1 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).




- 2 Detach the rear cover.

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the rear cover, align it upward and release three hooks (c).



- 3 Detach the temperature/humidity fan motor.


- 1 Remove two screws (c)(M3×8TP) and release the hook (d) in the direction of the arrow.
- 2 Remove the two connectors (b) and detach the temperature/humidity fan motor assy.



(4-6) Fan motor attachment direction

When reattaching the fan motor, be aware of the attachment direction (intake/exhaust).

- LSU fan motor (a) : intake(rating label side: the inside)
- Power source fan motor (b) : intake(rating label side: the inside)
- Exit fan motor (c) : exhaust(rating label side: the outside)
- Conveying fan motor (d) : exhaust(rating label side: the outside)
- Temperature/humidity fan motor (e) : intake(rating label side: the inside)



(5) PWBs

**Caution**


Before replacing the PWB, be sure to take the following procedures.

Otherwise, The PWB may be damaged.

- Disconnect the power cord.
- Press the power switch one second or more to discharge the electric charge inside the main unit.


(5-1) Detaching and reattaching the main PWB

- 1 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).




- 2 Remove the SD/SDHC memory card if installed.

- 1 Remove one screw (a) (M3x8) and release the hook (b) in the direction of the arrow, and then remove the SD card cover (c).
- 2 Detach an SD/SDHC memory card (e) in the memory card slot (d).




3 Detach the rear cover.

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the rear cover, align it upward and release three hooks (c).



4 Remove the controller shield plate.

- 1 Remove four screws (b)(M3×8B) of the controller shield plate.
- 2 Slide the triangle mark (c) on the controller shield plate (a) in the direction of the arrow and detach it.




5 Detach the main PWB.

- 1 Disconnect all the connectors and the FFCs from the main PWB (a).
- 2 Remove six screws (b)(M3x8B) and detach the main PWB (a).

✔ Important

When replacing the main PWB, make sure to remove the USB ground plate (d) from the USB connector (c) from the old board and install it in the new board.



- 3 Check or replace the main PWB, and then reattach the parts in the original position.


Resetting the maintenance mode when replacing the main PWB.

- 1 To clear C0180 [Machine number mismatch], execute maintenance mode U004 to set the machine number.
- 2 Execute the scan image adjustment.
 - Input the scanner automatic adjustment original data in maintenance mode U425.
 - Execute maintenance mode U411 by using the scanner automatic adjustment original.
 - Execute [Grayscale adjustment] from [System Menu].
- 3 If the optional item license was activated, reactivate it.
 - If the card authentication kit (B) was activated, reactivate it.
 - If the card type was set up, use maintenance mode U222 to set it up.
- 4 Import the data if it was exported in maintenance mode U917 from the main unit to replace the main PWB. (Also, available at KM-Net Viewer)
- 5 Reset the user default setting and FAX default setting from the System Menu or Command Center.
- 6 Reset the following maintenance mode if necessary.

No.	Maintenance mode relating to the main unit	No.	Maintenance mode relating to the FAX unit
U250	Maintenance counter preset	U603	User data 1
U251	Maintenance counter clear	U604	User data 2
U253	Switching the double/single counts	U610	System 1
U260	Switching the timing for copy counting	U611	System 2
U326	Black line cleaning indication	U612	System 3
U341	Printer cassette setting	U615	System 6
U343	Duplex priority mode	U625	Communication Setting
U345	Maintenance timing pre-caution setting	U695	FAX function customization
U402	Print margin adjustment		
U403	Scanning margin adjustment (table)		
U404	Scanning margin adjustment (DP)		
U407	Adjusting the writing timing (Duplex/Reversal)		
U425	Set Target		
U470	Setting the JPEG compression rate		


(5-2) Detaching and reattaching the Engine PWB

- 1 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).




- 2 Detach the rear cover.

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the rear cover, align it upward and release three hooks (c).



3 Detach the Enginee PWB.

- 1 Disconnect all the connectors and the FFCs from the Enginee PWB (a).
- 2 Remove four screws (b)(M3x8B) and detach the Enginee PWB (a).
- 3 Check or replace the Enginee PWB (a), and then reattach the parts in the original position.




✔ Important


When replacing the Enginee PWB (a), make sure to remove the EEPROM (U15) (c) from the old board and install it in the new board.

(5-3) Detaching and reattaching the low voltage PWB


- 1 Release the lock lever (b) and JS tray (a) in the direction of the arrow.




- 2 Pull out the cassette (a) from the main unit (b) and remove it in the direction of the arrow.



- 3 Open the front cover (a).




- 4 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).**




- 5 Detach the rear cover.**

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the rear cover, align it upward and release three hooks (c).




- 6 Remove the left lower cover.**

- 1 Remove five screws (b).
- 2 To detach the left lower cover (b), align it upward and release four hooks (c).




7 Detach the front top cover.

- 1 Release two hooks (b) of front top cover (a) and detach it.
- 2 Tilt the upper front cover (a) toward you.




8 Detach the main tray.




9 Detach the power source fan motor.

- 1 Disconnect the connector of the fan motor (b).
- 2 Remove one screw (c).
- 3 Release two hooks (c) and detach the power source fan motor assy.



10 Detach the low voltage PWB.

- 1 Disconnect all the connectors from the low voltage PWB (a).
- 2 Remove five screws (b)(M3x8B) and remove the low voltage PWB (a).
- 3 Check or replace the low voltage PWB (a), and then reattach the parts in the original position.




Caution


Electric charge may reside on the low-voltage PWB after turning the power off and disconnecting the power cord, and do not touch mounted parts.

(5-4) Detaching and reattaching the high voltage PWB


- 1 Release the lock lever (b) and JS tray (a) in the direction of the arrow.




- 2 Pull out the cassette (a) from the main unit (b) and remove it in the direction of the arrow.



- 3 Open the front cover (a).




- 4 Release the three hooks (b) in the direction of the arrow and remove the controller box cover (a).**




- 5 Detach the rear cover.**

- 1 Remove five screws (b)(M3×8TP).
- 2 To detach the rear cover, align it upward and release three hooks (c).




- 6 Remove the left lower cover.**

- 1 Remove five screws (b).
- 2 To detach the left lower cover (b), align it upward and release four hooks (c).




7 Detach the front top cover.

- 1 Release two hooks (b) of front top cover (a) and detach it.
- 2 Tilt the upper front cover (a) toward you.




8 Detach the left top cover.




- 1 Remove two screws (b)(M3×8TP).
- 2 Release the two hooks (c) upward and detach the upper left cover (a).



9 Detach the tray left cover.


- 1 Release the hook (b) from the frame in the direction of the arrow.
- 2 Detach the tray left cover (a) while avoiding the tray rear cover (c).



10 Detach the main tray.**11 Detach the upper exit cover (a) while holding the tray rear cover (b).****12 Detach the tray rear cover (b).**


13 Detach the high voltage PWB.

- 1 Disconnect the FFC (c) from the connector (b) at the back side of the high-voltage PWB (a).
- 2 Remove two screws (d)(M3×8TP) and two screws (e)(M3×8B) and detach the high voltage PWB (a).
- 3 Check or replace the high voltage PWB (a), and then reattach the parts in the original position.




(5-5) Detaching and reattaching the operation panel PWB

- 1 Lift up two points of the leading edge of the operation panel cover (b), slide them in the direction of the arrow and then detach the operation panel cover from the operation panel (a).




- 2 Detach the language sheet.

- 1 Detach two clear panels (b) from the operation panel (a).
- 2 Detach two language sheets.
- 3 Check or replace the language sheet, and then reattach the parts in the original position.



3 Detach the operation top unit.


- 1 Remove two screws (b)(M3x8B).
- 2 Disconnect two connectors (d) of the operation panel PWB (c).
- 3 Detach the operation top unit (a).




4 Disconnect the wire from the operation panel PWB.

- 1 Disconnect five FFCs (b) from the operation panel PWB (a).
 - The connector (d) has a lock.
- 2 Disconnect two connectors (c) from the operation panel PWB (a).

7-inch panel model




4.3-inch panel model




5 Distach the operation panel PWB.


- 1 Remove four screws (a) and detach the operation panel PWB (c) from the operation top unit (b).
- 2 Check or replace the operation panel PWB (c), and then reattach the parts in the original position.




(5-6) Detaching and reattaching the DP PWB

1 Remove four screws (b) from the document processor (a).**2 Detach the DP rear cover.**

- 1 Open the DP top cover (b).
- 2 Detach the DP original tray (a) while twisting it.

**3 Detach the DP PWB.**

- 1 Disconnect all the connectors from the DP PWB (a).
- 2 Remove four screws (b).
- 3 Release the hook A (c), release three hooks (d) in the direction of the arrow and detach the DP PWB (a).



 **Important**

When replacing the DP PWB (a), make sure to remove the EEPROM (YS1) (e) from the old board and install it in the new board.


4 - 6 Disassembly & Reassembly (option)

(1) Paper feeder (PF-470/PF-471)

(1-1) Detaching and reattaching the PF drive unit


1 Detach the PF rear cover.

- 1 Remove two screws (b).
- 2 Release three hooks (b) and detach PF rear cover (a) in the direction of the arrow.



2 Detach the PF drive unit.


- 1 Disconnect the connector (d) of the PF motor (c).
- 2 Release the wire (e) from the hook (f).
- 3 Remove three screws (b) and detach the drive unit (a).




(1-2) Detaching and reattaching the PF PWB

1 Detach the PF rear cover.

- 1 Remove two screws (b).
- 2 Release three hooks (b) and detach PF rear cover (a) in the direction of the arrow.

**2 Detach the PF PWB.**


- 1 Disconnect all the connectors from the PF PWB (a).
- 2 Remove two screws (b).
- 3 Release two hooks (c) and remove the PF PWB (a).



(2) Finisher (DF-470)


(2-1) Detaching and reattaching the DF front cover

- 1 Remove two screws (b) and detach the DF front cover (a).




(2-2) Detaching and reattaching the DF rear cover

- 1 Remove two screws (b) and detach the DF rear cover (a).



(2-3) Aligning the phase of the upper and lower drive gears of the DF bundle eject belt

- When attaching the upper and lower drive gear of the DF bundle exit belt, align the phase of the ribs (a) so that they lie on the same line.



4 - 7 Periodical maintenance procedure (CH:Check CL:Clean AD:Adjust LU:Lubrication RE:Replace)

(1) Main unit

Set Up

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
Test copy Test Print (Max. copy size)	CH AD	CH AD	CH AD	CH AD			-
Entire inside the main unit		CL	CL	CL			VACUUM : Remove toner and paper dust especially from imaging section and paper conveying path.
MK-6115 MK-6116 MK-6117 MK-6119			RE	RE			Drum unit, Developer unit, Fuser unit Transfer unit, Feed unit, Regist cleaner, MP feed rolle, MP separation pad

Exterior and Cover

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
OUTER COVERS	CH		CL	CL			Alcohol or dry cloth

Feed and Conveying section

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
Regist cleaner (302K394450)		CL	CL	CL			VACUUM : Paper dust removal
Feed unit (302K394480)		CL					Alcohol or dry cloth
MP feed roller (302K394460)		CL	CH RE	CH RE			Alcohol or dry cloth if no replacement. Check feed count by U901: Replace at 100K
MP separation pad (302P194090)		CL	CH RE	CH RE			Alcohol or dry cloth if no replacement. Check feed count by U901: Replace at 100K
Rollers/pulleys		CL	CL	CL			Alcohol or dry cloth
Conveying guides		CL	CL	CL			Alcohol or dry cloth

Exit and Duplex section

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
Rollers/pulleys		CL	CL	CL			Alcohol or dry cloth
Conveying guides			CL	CL			Alcohol or dry cloth

Image scanner section

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
Contact glass (302P194050) (302P194060)	CL	CL	CL	CL			Use dry cloth after cleaning by the alcohol (Normally surface only) Clean the back side (dry wipe after alcohol wipe) only when the abnormal image (streaks and dirt) appears. Clean by the dry cloth when installing DP
Slit glass (302P194050) (302P194060)	CL	CL	CL	CL			Alcohol or dry cloth or water wipe

Drive and Other section

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
CLUTCHS		CH RE	CH	CH			Check the copy registration and paper feed condition on registration and paper feed section.
SENSORS		CH	CH	CH			Use dry cloth or air blower to the light reception surface of the photo sensor.



Caution

Please do not use flammable spray for air blower in the list.

(2) Document Processor

Set Up

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
Test copy, Test print (Max. copy size)	CH AD	CH AD	CH AD	CH AD			-
MK-6110			RE	RE			DP feed roller assy, DP retard roller cover, DP retard roller

Exterior and Cover

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
Entire inside the main unit		CL	CL	CL			Alcohol or dry cloth

DP feed motor section

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
DP feed roller (302P194100)		CL					Alcohol (Replace MK-6110 if necessary)
DP retard roller cover (302P194110)		CL					Alcohol (Replace MK-6110 if necessary)
DP retard roller (302P194120)		CL					Alcohol (Replace MK-6110 if necessary)

DP conveying and reversing section

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
DP registration roller (302P194270)		CL	CL	CL			Alcohol or dry cloth
DP registration pulley (303P724170)		CL	CL	CL			Alcohol or dry cloth
DP conveying pulley A (303M824210)		CL	CL	CL			Alcohol or dry cloth
DP conveying pulley B (303LL24190)		CL	CL	CL			Alcohol or dry cloth
DP scanner guide (302P118260)		CL	CL	CL			Alcohol or dry cloth

DP other section

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
Original Cover (303JC04201)		CL	CL	CL			Alcohol or dry cloth
Slit glass (302RH17210)		CL	CL	CL			Alcohol or dry cloth (CCD section)

DP slit glass (302P217110)		CL	CL	CL			Alcohol or dry cloth (CIS section)
Conveying guides			CL	CL			Alcohol or dry cloth
SENSORS		CH	CH	CH			Use dry cloth or air blower to the light reception surface of the photo sensor.



Caution

Please do not use flammable spray for air blower in the list.

(3) Paper Feeder (PF-470/471) (Option)

Set Up

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
Test copy, Test print (Max. copy size)	CH AD	CH AD	CH AD	CH AD			Check the center alignment gap. (check after center adjustment of the main unit)

Exterior and Cover

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
Entire inside the main unit		CL	CL	CL			Alcohol or dry cloth

PF feed section

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
Feed unit (302K394480)		CL	CH RE	CH RE			Alcohol or dry cloth

PF conveying section

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
PF upper conveying roller (302MV94310)		CL	CL	CL			Alcohol or dry cloth
PF lower conveying roller (302MV94320)		CL	CL	CL			Alcohol or dry cloth
Conveying guides			CL	CL			Alcohol or dry cloth
SENSORS		CH	CH	CH			Use dry cloth or air blower to the light reception surface of the photo sensor.



Caution

Please do not use flammable spray for air blower in the list.

(4) Attachment Kit (AK-470) (Option)

Exterior and Cover

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
Entire inside the main unit		CL	CL	CL			Alcohol or dry cloth

BR paper conveying section

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
Rollers/pulleys		CL	CL	CL			Alcohol or dry cloth
Conveying guides		CL	CL	CL			Alcohol or dry cloth
SENSORS		CH	CH	CH			Use dry cloth or air blower to the light reception surface of the photo sensor.



Caution

Please do not use flammable spray for air blower in the list.

(5) Finisher (DF-470) (Option)

Exterior and Cover

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
Entire inside the main unit		CL	CL	CL			Alcohol or dry cloth

DF conveying section

Maintenance Parts, Location	Set UP	Call	PM maintenance (x1000 counts)				Point, Note
			300	600			
Rollers/pulleys		CL	CL	CL			Alcohol or dry cloth
Conveying guides			CL	CL			Alcohol or dry cloth
SENSORS		CH	CH	CH			Use dry cloth or air blower to the light reception surface of the photo sensor.



Caution

Please do not use flammable spray for air blower / blower brush in the list.

5Firmware

5 - 1 Firmware update

Execute the following to update the firmware below.

* The processing time is reduced with simultaneous processing by group.

[GROUP1 UPDATE]

UPDATE step	Target	Master file name	Message
1	Controller	DL_PKG_CTRL.2P1 (32 ppm model) DL_PKG_CTRL.2P2 (25 ppm model)	CPKG
	Product Line Platform	DL_CTRL_PLP.2P1	PLP
	Common Basic App	DL_CTRL_STDAPP_CMN.2P1	CMN
	System Setting App	DL_CTRL_STDAPP_SST.2P1	SST
	Maintenance App	DL_CTRL_STDAPP_MNT.2P1	MNT
	Copy App	DL_CTRL_STDAPP_CPY.2P1	CPY
	Print App	DL_CTRL_STDAPP_PRT.2P1	PRT
	Send App	DL_CTRL_STDAPP_SND.2P1	SND
	BOX App	DL_CTRL_STDAPP_BOX.2P1	BOX
	Fax App	DL_CTRL_STDAPP_FAX.2P1	SFAX
	Web Page App	DL_CTRL_STDAPP_WPG.2P1	WPG
	Auth App	DL_CTRL_STDAPP_AUTH.2P1	AUTH
	Panel Control System App	DL_CTRL_STDAPP_PCS.2P1 (32 ppm model) DL_CTRL_STDAPP_PCS.2P2 (25 ppm model)	PCS:
	Service Cooperation App	DL_CTRL_STDAPP_SCO.2P1	SCO
	Extension Service Platform	DL_CTRL_EXSP.2P1	EXSP
Package Version Info	DL_CTRL_VINF.2P1 (32 ppm model) DL_CTRL_VINF.2P2 (25 ppm model)	VINF	
Panel	DL_PANL.2P1 (32 ppm model) DL_PANL.2P2 (25 ppm model)	PANL	
Browser	DL_BRWS.2P1	BRWS	
2	Option Language Data(1)	DL_OPT_xx.2P1 (*1)	OPT1
3	Option Language Data(2)		OPT2
4	Option Language Data(3)		OPT3
5	Option Language Data(4)		OPT4
6	Option Language Data(5)		OPT5
7	Option Language Data (Erase)	DL_OPT_ER.2P1	-
8	OCR Dictionary Data	DL_OCR.2P1	OCR

📌 Important

When installing the OCR dictionary firmware, it is necessary that the SSD or the SD card has to be installed. Also, it is necessary to format the SSD / SD card at the system menu in the main unit.

[\[GROUP1 UPDATE\]](#)

UPDATE step	Target	Master file name	Message
1	FAX Board	DL_FAX.3R2	FAX

[\[GROUP3 UPDATE\]](#)

UPDATE step	Target	Master file name	Message
1	Document Processor	DL_DPRC.2P1	DP
2	Paper Feeder	DL_03NN.2P1	PF
3	Attachment Kit	DL_03NS.2P1	AK
4	Document Finisher	DL_05JS.2P1	DF
5	Enginee Firmware	DL_ENGN.2P1	ENGN

[\[GROUP4 UPDATE\]](#)

UPDATE step	Target	Master file name	Message
1	Sub Panel Board	DL_SPNL.2P1	SPNL

[Verify the signature at firmware update](#)

Verify the signature of the update file to prevent the firmware update with illegally falsified data.

[File names of the signature and firmware certificate](#)

Target	Signature file name	Firmware certificate file name
Common Basic App	2P1_CTRL_STDAPP_CMN_sign.bin	2P1_CTRL_STDAPP_CMN_cert.pem
System Setting App	2P1_CTRL_STDAPP_SST_sign.bin	2P1_CTRL_STDAPP_SST_cert.pem
Maintenance App	2P1_CTRL_STDAPP_MNT_sign.bin	2P1_CTRL_STDAPP_MNT_cert.pem
Copy App	2P1_CTRL_STDAPP_CPY_sign.bin	2P1_CTRL_STDAPP_CPY_cert.pem
Print App	2P1_CTRL_STDAPP_PRT_sign.bin	2P1_CTRL_STDAPP_PRT_cert.pem
Send App	2P1_CTRL_STDAPP_SND_sign.bin	2P1_CTRL_STDAPP_SND_cert.pem
BOX App	2P1_CTRL_STDAPP_BOX_sign.bin	2P1_CTRL_STDAPP_BOX_cert.pem
Fax App	2P1_CTRL_STDAPP_FAX_sign.bin	2P1_CTRL_STDAPP_FAX_cert.pem
Web Page App	2P1_CTRL_STDAPP_WPG_sign.bin	2P1_CTRL_STDAPP_WPG_cert.pem
Auth App	2P1_CTRL_STDAPP_AUTH_sign.bin	2P1_CTRL_STDAPP_AUTH_cert.pem
Panel Control System App	2P1_CTRL_STDAPP_PCS_sign.bin (32 ppm model) 2P2_CTRL_STDAPP_PCS_sign.bin (25 ppm model)	2P1_CTRL_STDAPP_PCS_cert.pem (32 ppm model) 2P2_CTRL_STDAPP_PCS_cert.pem (25 ppm model)
Service Cooperation Ap	2P1_CTRL_STDAPP_CMN_sign.bin	2P1_CTRL_STDAPP_CMN_cert.pem
Product Line Platform	2P1_CTRL_PLP_sign.bin	2P1_CTRL_PLP_cert.pem
Extension Service Platform	2P1_CTRL_EXSP_sign.bin	2P1_CTRL_EXSP_cert.pem
Package Version Info	2P1_CTRL_VINF_sign.bin (32 ppm model) 2P2_CTRL_VINF_sign.bin (25 ppm model)	2P1_CTRL_VINF_cert.pem (32 ppm model) 2P2_CTRL_VINF_cert.pem (25 ppm model)
Panel	2P1_PANL_sign.bin (32 ppm model) 2P2_PANL_sign.bin (25 ppm model)	2P1_PANL_cert.pem (32 ppm model) 2P2_PANL_cert.pem (25 ppm model)
Browser	2P1_BRWS_sign.bin	2P1_BRWS_cert.pem

Target	Signature file name	Firmware certificate file name
Option Language Data(1)	2P1_OPT_xx_sign.bin	2P1_OPT_xx_cert.pem
Option Language Data(2)		
Option Language Data(3)		
Option Language Data(4)		
Option Language Data(5)		
Option Language Data (Erase)	2P1_OPT_ER_sign.bin	2P1_OPT_ER_cert.pem
Sub Panel Board	2P1_SPNL_sign.bin	2P1_SPNL_cert.pem
FAX Board	3R2_FAX_sign.bin	3R2_FAX_cert.pem
Enginee Firmware	2P1_ENGN_sign.bin	2P1_ENGN_cert.pem
Document Processor	2P1_DPRC_sign.bin	2P1_DPRC_cert.pem
Document Finisher	2P1_05JS_sign.bin	2P1_05JS_cert.pem
Attachment Kit	2P1_03NS_sign.bin	2P1_03NS_cert.pem
Paper Feeder	2P1_03NN_sign.bin	2P1_03NN_cert.pem

Note when upgrading the firmware

When using a USB memory requiring a long time to start up, the main unit starts up before executing the firmware upgrade and entering into the firmware upgrade fails.

Maintenance mode U025 firmware update (S): Execute the firmware upgrade at Firmware Update (Security)


Preparations

Unzip the file containing the downloaded firmware and then copy the firmware and high-speed master file (skip files: ES_SKIP.ON) in [FWUP_02P1] folder *1 or [FWUP_02P2] folder *2 of the root folder of the USB memory.

*1: for 7 inch LCD model, *2: for 4.3 inch LCD model

* If the high-speed master file exists, the same version firmware update is skipped.

- 1 After turning the power switch (a) on and the screen is properly displayed, turn the power switch (a) off.
- 2 Insert the USB memory (b) with the firmware into the USB memory slot and turn the power switch (a) on.




- [FW-UPDATE] is parallelly processed and the progress is displayed.

[7 Inch display]




[4.3 Inch display]



- "Completed" is displayed when the firmware update is completed.
- Check if the new firmware versions are displayed.

[7 Inch display]



[4.3 Inch display]



- When there is no corresponding master file, "No Change" is displayed.
* is displayed after the firmware version update that has been skipped.
- [-----] is displayed when the FAX PWB, the option equipment, etc. is not installed.

For the case of an error

[7 Inch display]



[4.3 Inch display]



- When an error occurs during the firmware upgrade, the process is immediately interrupted and the error code and error message are indicated.

Codes	Description	Codes	Description
0000	Others	S000	Other signature verification error *1
0100	No Master file	S001	Signature verification file is inadequate
0200	Version mismatch of the master file	N001	Network connection failed. *2 (There is no upgrade target interrupted)
03xx	No Download File (No.xx)		
04xx	File (No.xx) Checksum mismatch		
05xx	File (No.xx) Preparation failure		
06xx	File (No.xx) Oversize	N002	Network connection failed. *3 (There is an upgrade target interrupted)
08xx	File (No.xx) Writing failure		

*1: Including the expired FW certificate

*2: Automatically restarted for the normal start-up since the normal start-up is available next time.

*3: Transferred to the USB upgrade mode instead of the automatic restart since the normal start-up may not be available next time.

Indication of the signature verification result

Official signature verification file	Indicate the result
Both certificate and signature files exist and verification is successful.	Version number
Both certificate and signature files exist but verification is unsuccessful.	S000
Neither certificate nor signature files exist. Or either of them does not exist.	S001

- 3 **Unplug the power cord and disconnect the USB memory.**
- 4 **Plug in the power cord and turn the power switch (a) on.**
- 5 **Check that the "Home" screen is displayed and then turn the power switch (a) off.**



Caution

Never turn the power switch (a) off or disconnect the USB memory (b) during the firmware update.

Safe-Update

When the firmware update was interrupted by power shut-off or disconnecting the USB memory during the firmware update, the firmware update is retried at the next power-on.

Turn the main power on again while the USB memory is installed.


* The firmware update that was already completed before power shut-down is skipped.

6 Maintenance mode

6 - 1 Maintenance mode

This model is equipped with the service mode for the main unit maintenance and correction.

(1) Executing the maintenance mode



(2) Maintenance modes list

Section	Maintenance item	Outline
General	U000 Printing Maintenance Report	Printing the reports and exporting them to a USB memory
	U001 Exiting the maintenance mode	Exiting from the maintenance mode
	U002 Set Factory Default	Initializing to the factory-default setting
	U004 Machine Number	Display of the machine serial number and setting
	U010 Setting the maintenance mode ID	Setting the maintenance mode ID
	U019 Firmware Version	Displays the firmware version of the PWB
Initialization	U021 Initializes Memory	Initializing the backup RAM
	U025 Firmware update (S)	Updates the firmware
Drive Paper feed Conveying Cooling	U030 Motor operation check	Drive the drive motor
	U031 Check the conveying switch	Check the conveying switch On/Off
	U032 Clutch operation check	Check the paper conveying clutch operation
	U033 Solenoid operation check	Drive the paper conveying and toner supply solenoids
	U034 Paper timing data adjustment	Adjusting the leading edge timing and the center line
	U035 Folio size setting	Sets the Folio paper length and width.
	U037 Fan motor operation check	Drive each fan motor.
	U051 Registration paper loop amount adjustment	Adjusts the paper loop amount between the rollers
	U053 Adjusting the motor speed	Sets each motor's speed correction
Optical	U063 Shading position adjustment	Changes the scanner shading position
	U065 Adjusting the magnification for table scanning	Adjusting the magnification for table scanning
	U066 Adjusting the table scanning timing	Adjusting the leading edge timing for table scanning
	U067 Adjusting the table scanning center line	Adjusting the center line for table scanning
	U068 DP scanning position adjustment	Adjusting the starting position for DP scanning
	U070 DP magnification adjustment	Adjusting the magnification for DP scanning
	U071 Adjusting the DP leading edge Timing	Adjusting the DP scanning timing
	U072 Adjusting the DP original center	Adjusting the center line for DP scanning
	U089 MIP-PG pattern output	Output MIP-PG pattern
	U099 Original size detection setting	Sets the original size detection check and detection threshold
High voltage system	U100 Main high voltage adjustment	Adjust the drum surface potential
	U101 Primary transfer voltage adjustment	Sets high voltage except the main high voltage and outputs
	U108 Separation Shift bias adjustment	Sets the transfer belt unit cleaning control voltage.
	U110 Drum counter	Displays/sets the drum counter
	U110 Drum drive time	Display the drum drive time that is used for the high-voltage time correction.
	U117 Drum unit number	Displays the drum number

Section	Maintenance item	Outline
High voltage system	U118 Drum unit history	Displays the drum history
	U120 Drum drive distance counter	Displays the drive distance counter
	U127 Clearing the transfer count	Displaying the counts
Developer system	U136 Toner level detection setting	Sets the number of pages printable at toner near end
	U139 Temperature, humidity	Displays the machine inside and outside humidity
	U140 Developer bias adjustment	Adjust the developer bias values
	U147 Setting the toner applying mode	Sets the overcharge toner removal mode
	U148 Drum refresh mode setting	Setting auto drum refresh
	U150 Toner sensor operation check	Displays the on/off status of each switch and sensor for toner
	U157 Developer drive time	Displays/sets the developer drive time
	U158 Developer counter	Displays/sets the developer counter
Fuser	U161 Fuser temperature adjustment	Sets the fuser control temperature
	U167 Clearing the fuser count	Display/set/clear the count.
	U198 Fuser phase control setting	Switch the stationary phase control
	U199 Fuser temperature	Monitor the fuser temperature
Operation section / Support equipment	U201 Initializing the touch panel	Correct the X and Y axis position of the touch panel
	U203 Check DP operation	Checking the DP paper conveying operation with the DP alone
	U207 Operation key check	Check the operation panel key operation
	U222 Setting the IC card type	Sets the ID card type
	U230 Optional device serial number	Displays the optional device serial number
	U243 Checking the DP motor	Drive the PF motor and solenoid
	U244 DP switch check	Drive the DP sensor
Mode Setting	U250 Maintenance counter preset	Changes the preset value
	U251 Maintenance counter clear	Displaying/clearing/changing the counter value
	U252 Destination	Sets the machine operation and indication depending on the specification of the destination
	U253 Double/single count switch	Sets the counter by color mode
	U260 Feed/eject counter switch	Setting the count-up timing
	U265 Setting by destination	Sets the OEM code
	U278 Delivery date setting	Register Delivery Date
	U285 Set Service Status Page	Setting the print coverage report output
	U287 Automatic recovery function	Sets whether to automatically recover after error
	U290 Application storage drive setting	Set the HyPAS application storage drive.
	U326 Black line cleaning display setting	Switch the black line cleaning guidance indication
	U332 Adjusting the black coverage coefficient	Setting the coefficient of the custom size
	U341 Printer cassette setting	Sets the cassette to printer output only

Section	Maintenance item	Outline
Mode Setting	U343 Duplex priority mode setting	Switches the duplex printing priority mode
	U345 Maintenance timing pre-caution setting	Setting the maintenance timing display
	U346 Selecting Sleep Mode	Setting the BAM related sleep mode
Image processing	U402 Print margin adjustment	Adjusts the scan image margins
	U403 Scanning margin adjustment (table)	Adjusts the margin for scanning originals
	U404 Scanning margin adjustment (DP)	Adjusts the margin for scanning originals
	U407 Adjusting the writing timing (Reversal)	Adjusting the writing timing in rotated 180 degrees
	U410 Adjusting the halftone automatically	Acquiring the data for the automatic halftone adjustment and the ID correction
	U411 Scanner auto adjustment	Adjusting the scanner and DP automatically
	U425 Target adjustment	Inputs the Lab value printed on an adjustment original
	U470 Setting the JPEG compression rate	Sets the JPEG compression rate
	U520 TDRS setting	Checking/setting the TDRS
FAX	U600 Initialize: All Data	Initializes all data and image memory.
	U601 Initialize: Keep data	Initializing the software switches of other than the machine data
	U603 User data 1	Makes user settings to enable the use as a FAX
	U604 User Data 2	Makes user settings to enable the use as a FAX
	U605 Data clear	Initializing the FAX communication data
	U610 System setting 1	Set the number of lines to be ignored when receiving a FAX at 100% magnification and in the auto reduction mode.
	U611 System setting 2	Number of adjustment lines for automatic reduction.
	U612 System setting 3	Setting regarding the FAX communication operation
	U615 System Setting 6	Sets the size to print at FAX reception and received image size
	U620 FAX system	Sets the signal detection method for remote switching
	U625 Communication Setting	Sets the auto redialing interval and the number of times of auto redialing
	U630 Communication control procedures 1	Setting the FAX communication
	U631 Communication control procedures 2	Sets the FAX communication
	U632 Communication control procedures 3	Setting the FAX communication
	U633 Communication control procedures 4	Setting the FAX communication
	U634 Communication control procedures 5	Set the acceptable error when judging the received TCF signal
	U640 Communication time setting 1	Setting the detection time by remote switching mode
	U641 Communication time setting 2	Sets the time-out time for the fax communication
	U650 Modem 1	Sets the G3 transmission cable equalizer
	U651 Modem 2	Sets the modem output level
U660 Ring setting	Setting the NCU (network control unit)	

Section	Maintenance item	Outline
Others	U670 List output	Outputting the list of the fax communication data
	U695 FAX function customization	FAX batch transmission is set up.
	U699 Software switch: Set	Sets the software switches individually
	U901 Clearing the counters by paper source	Displays/clears the counters by paper source
	U903 Clearing the jam counter	Displays/clears number of occurrence by jam trigger code
	U904 Clearing the service call error counter	Displays/clears the service call error and system error counts
	U905 Optional counter	Displaying the optional count
	U908 Total counter	Displays the total count
	U910 Black rate data	Clearing the print coverage data and its period
	U911 Counter by media type	Displays/clears the counts by media type
	U917 Read/Write Backup Data	Reading/writing the backup data to a USB memory
	U920 Billing counter	Displays the billing count
	U927 Clearing all the billing/life counters	Clearing the billing count and machine life count
	U930 Clear the main charger roller counts	Displaying/setting the counts
	U928 Machine life counter	Displays the machine life count
	U935 Relay PWB Maintenance	Sets the mode when an error occurs
	U942 DP loop amount setting	Adjust the paper loop amount when using the document processor
	U964	Transfer the log files save in the nonvolatile memory to a USB memory.
	U977 Setting the data capture mode	Stores the data sent to the main unit into a USB memory
	U984 Developer unit number	Displays the developer unit number
U985 Developer unit history	Displays the developer unit number history	
U991 Scanner counter	Displays the scanner count	

U000 Printing Maintenance Report

(Message: Mainte Report)

Contents

Prints the list of the current settings of the maintenance items, paper jam and service call error occurrences. Output the event log and service status page.

Also, sends output data to a USB memory.

Purpose

Checks the current settings of the maintenance items, paper jam and service call error occurrences.

Before initializing or replacing the backup memory, print the list of the current settings of the maintenance items to reenter the settings after initialization or replacement.

Method

- 1 Press the [Start] key.
- 2 Select the item to output.

Items	Output list
Maintenance	Maintenance mode setting list
User Status	Output User Status Page
Svc Status	Output Service Status Page
Event	Output the event log report
NW Status	Output Network Status Page
LLU Report	Output LLU report
Fax Sys Conf *1	Prints the list of local telephone number, confidential boxes and firmware versions.
Fax Act List *1	Prints the list of the error logs and communication lines.
Fax Self Sts *1	Maintenance mode setting, Fax communication setting output
Fax Pcl List *1	Outputs a list of communication procedures.
Fax Err List *1	Output the error list.
All	All reports output

*1: FAX installation only

- 3 Press the [Start] key to output the list.

If A4 paper is available, it is output with this size. If A4 paper is unavailable, select the paper source. Output status is displayed.

Method: when sending output data to a USB memory

- 1 Press the [Start] key.
- 2 Insert a USB memory into the USB memory slot.
- 3 Select the item to send.
- 4 Select [USB(Text)] or [USB(HTML)].

Items	Output list
Print	A report is printed.
USB(Text)	Destination: send to USB memory (text format)
USB(HTML)	Destination: send to USB memory (HTML format)

- Reinstall the USB memory for continuous USB out whenever completing output. (For unmounting the USB memory after output)
- 5 Press the [Start] key.
The output data is sent to the USB memory.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

Detail of event log

Event Log



MFP
ECOSYS M4132idn

XXXXXXXXXXXXXXXXXXXX

(2) 2017/03/19 15:15

(1) Firmware version 2P1_2000.001.133 2017.02.02

[XXXXXXXX] [XXXXXXXX] [XXXXXXXX]

(3) (4) (5)

(6) Machine No.:Z2C5Y00100

(7) Life Count:100000

(8) Paper Jam Log

#	Count.	Event Descriptions	Date and Time
12	5555555	0501.01.08.01.00	2014/02/12 17:30
11	4444444	4002.01.08.01.00	2014/02/12 17:30
10	3333333	0501.01.08.01.00	2014/02/12 17:30
9	2222222	4002.01.08.01.00	2014/02/12 17:30
8	1111111	0501.01.08.01.00	2014/02/12 17:30
7	9999999	4002.01.08.01.00	2014/02/12 17:30
6	8888888	0501.01.08.01.00	2014/02/12 17:30
5	7777777	4002.01.08.01.00	2014/02/12 17:30
4	6666666	0501.01.08.01.00	2014/02/12 17:30
3	5555555	4002.01.08.01.00	2014/02/12 17:30
2	4444444	0501.01.08.01.00	2014/02/12 17:30
1	1	4002.01.08.01.00	2014/02/12 17:30

0501.01.08.01.00
(a) (b) (c) (d) (e)

(10) Maintenance Log

#	Count.	Item.	Data and Time
2	444444	02.01	2014/02/12 17:30
1	222222	02.02	2014/02/12 17:30

(9) Service Call Log

#	Count.	Service Code	Data and Time
8	1111111	01.00.6000	2014/02/12 17:30
7	9999999	01.01.2100	2014/02/12 17:30
6	8888888	01.01.0000	2014/02/12 17:30
5	7777777	01.00.6000	2014/02/12 17:30
4	6666666	01.00.2100	2014/02/12 17:30
3	5555555	01.01.4000	2014/02/12 17:30
2	4444444	01.00.6000	2014/02/12 17:30
1	1	01.00.2100	2014/02/12 17:30

(11) Unknown toner Log

#	Count.	Serial Number	Item.	Data and Time
5	1111111	0123456789ABCDEF	01.00	2014/02/12 17:30
4	9999999	0123456789ABCDEF	01.00	2014/02/12 17:30
3	8888888	0123456789ABCDEF	01.00	2014/02/12 17:30
2	7777777	0123456789ABCDEF	01.00	2014/02/12 17:30
1	6666666	0123456789ABCDEF	01.00	2014/02/12 17:30

Event Log

MFP

ECOSYS M4132idn

Firmware version 2P1_2000.001.133 2017.02.02



XXXXXXXXXXXXXXXXXXXX

2017/03/19 15:15

[XXXXXXXX] [XXXXXXXX] [XXXXXXXX]

Machine No.:Z2C5Y00100

Life Count:100000

(12) Counter Log

(f) J0000:	0	J4302:	0
J0100:	1	J4303:	1
J0101:	11	J4304:	11
J0104:	222	J4309:	2
J0105:	1	J9000:	1
J0106:	1	J9004:	0
J0107:	1	J9010:	1
J0110:	1	J9060:	1
J0111:	1	J9061:	2
J0211:	1	J9062:	1
J0212:	1	J9110:	1
J0213:	999	J9120:	0
J0501:	1	J9200:	1
J0502:	1	J9210:	1
J0503:	1	J9220:	2
J0504:	1		
J0508:	1	(g) C0000:	0
J0509:	1	C0001:	1
J0511:	1	C0002:	2
J0512:	1	C0003:	3
J0513:	1	C0004:	4
J0514:	1	C0005:	5
J0518:	1	C0006:	6
J0519:	1	C0007:	7
J1403:	1	C0008:	8
J1404:	1	C0009:	9
J1413:	1	C0010:	10
J1414:	1	CF245:	11(0)
J1604:	1	CF248:	12(0)
J1614:	1	CF345:	13(0)
J4002:	1	(h) T00:	10
J4003:	1	M00:	20
J4004:	1	M01:	30
J4009:	1		
J4012:	1		
J4013:	1		
J4014:	1		
J4019:	1		
J4201:	1		
J4202:	0		
J4203:	1		
J4204:	1		
J4208:	0		
J4209:	1		
J4211:	11		
J4212:	222		
J4213:	1		
J4214:	2		
J4218:	1		

Description of event log

No.	Contents
(1)	System version
(2)	System date
(3)	Enginee firmware version
(4)	Enginee boot version
(5)	Operation panel firmware version
(6)	Machine serial number
(7)	Life counter

No.	Contents			
(8)	Paper Jam Log			
#	Count.	Event Descriptions	Date and Time	
Remembers 1 to 16 of occurrence. If the past paper jam occurrence is less than 16, all of them are indicated. The oldest log is deleted when exceeding 16 events.	The total page count at the time of a paper jam.	Log code (5 types in hexadecimal) (a) Cause of paper jam (b) Paper source (c) Paper size (d) Paper type (e) Paper eject	Date and time of occurrence	
(a)Detail of Cause of paper jam (Hexadecimal)				
• Refer to "2-2 Paper Misfeed Detection",for the detail of Cause of paper jam. (See page P. 7-43)				
(b) Detail of paper source (Hexadecimal)				
00: MP tray 01: Cassette 1 02: Cassette 2 (paper feeder) 03: Cassette 3 (paper feeder) 04 to 09: Reserved				
(c) Detail of paper size (Hexadecimal)				
00: Not specified 01: Monarch 02: Business 03: International DL 04: International C5 05: Executive 06: Letter-R 08: Letter-E 07: Legal 08: A4R 88: A4E 09: B5R 89: B5E 0A: A3	0B: B4 0C: Ledger 0D: A5R 0E: A6 0F: B6 10: Commercial #9 11: Commercial #6 12: ISO B5 13: Custom size 1E: C4 1F: Hagaki 20: Oufuku Hagaki 21: Oficio II	22: Special 1 24: Special 2 24: A3 Wide 25: Ledger Wide 26: Full bleed paper(12 x 8) 27: 8K 28: 16K-R A8: 16K-E 32: Statement-R B2: Statement-E 33: Folio 34: Youkei type 2 35: Youkei type 4		

No.	Contents			
(8) cont	Paper Jam Log			
	(d) Detail of paper type (Hexadecimal)			
	01: Plain 02: Transparency 03: Preprinted 04: Labels 05: Bond 06: Recycled 07: Vellum 08: Rough 09: Letterhead	0A: Color 0B: Prepunched 0C: Envelope 0D: Cardstock 0E: Coated 0F: 2nd side 10: Media 16 11: High quality	15: Custom 1 16: Custom 2 14: Custom 3 18: Custom 4 19: Custom 5 1A: Custom 6 1B: Custom 7 1C: Custom 8	
(b) Detail of paper source (Hexadecimal)				
	01: Main unit face down (FD) 02: Main unit face up (FU)/500 sheets finisher(FU) 03: 5000-sheets finisher(FD) 05: Job Separator Tray(FD)			
(9)	Service Call Log			
	# Remembers 1 to 8 th of occurrence of self diagnostics error. If the occurrence of the previous self-diagnostic error is 8 or less, all of the diagnostics errors are logged.	Count. The total page count at the time of the self diagnostic error.	Service Code The first two digits (identification) 01: Service call / System error 02: Unit replacement Next two digits (Auto reboot information) 00: Without auto reboot 01: Auto reboot execution Last four digits Self diagnostic error code (See page P. 7-67) (Example) 01.00.6000 01 indicates Self diagnostic error, 00 without auto beboot and 6000 Self diagnostic error code. U287 sets the auto reboot function	Date and Time Date and time of occurrence

No.	Contents			
(10)	Maintenance Log			
#	Count.	item	Date and Time	
Remembers 1 to 8 of occurrence of unknown toner detection. If the occurrence of the previous unknown toner detection is less than 8, all of the unknown toner detection are logged.	Total page count at the time of the replacement of the maintenance item. The toner replacement log is triggered by toner empty. This record may contain such a reference as the toner container is inserted twice or a used toner container is inserted.	Maintenance item code (1-byte value to indicate 2 items) First byte (Replacing item) 02: Maintenance kit Second 1 byte (replacement item type) 01: MK-6115/6116/6117/6119 02: MK-6110	Date and time of occurrence	
(11)	Toner Log			
#	Count.	Item. Serial Number	Date and Time	
Remembers 1 to 32 of occurrence of unknown toner detection. If the occurrence of the previous unknown toner detection is less than 32, all of the unknown toner detection are logged.	The total page count at the time of the request of toner container replacement.	log code First 1byte(Replacing item) 01: Genuine product 02: Non-genuine product Next 1byte (type of replacement item) 00: Black Last 16 digits Displays the serial number of the toner container.	Date and time of occurrence	

No.	Contents			
(12)	Counter Log			
	(f) Paper jam	(g) Self diagnostic error	(h) Maintenance replacement item	
	<p>Indicates the log counter of paper jams depending on location.</p> <p>Refer to Paper Jam Log.</p> <ul style="list-style-type: none"> All instances including those not having occurred are displayed. 	<p>Indicates the log counter of self diagnostics errors depending on cause.</p> <p>The number of auto reboot is also displayed at the service call/system error.</p> <p>(Example) CF245: 4(2) System Error 245 occurred last four times and then executed the auto reboot twice.</p>	<p>Indicates the log counter depending on the maintenance replacing item.</p> <p>T: Toner container 00: Black M: Maintenance kit</p> <p>01: MK-6115/6116/6117/6119 02: MK-6110</p> <p>Example: T00: 1 The toner container (Black) has been replaced once.</p> <p>The toner replacement log is triggered by toner empty. This record may contain such a reference as the toner container is inserted twice or a used toner container is inserted.</p>	<p>Consist of three log counters of paper jams, self diagnostics errors, and maintenance replacement items.</p>

Detail of service status page

Service Status Page

MFP
ECOSYS M4132idn

(2) ZKG6400006

(3) 01/08/2016 14:30

(4)(5) [2.1.6] [2P1_F000.001.008]

(1) Firmware Version 2P1_Q000.001.146 2016.08.01

(6)(7)(8) [2P1_1000.001.020] [2P1_1100.001.001] [2P1_7000.001.216]

Controller Information

Memory Status

Standard Size 1.0 GB

Option Slot 0 MB

(9) Total Size 1.0 GB

Time

(10) Local Time Zone

GMT Greenwich Mean Time: Dublin, Edinburgh, Lisbon, London

(11) Date and Time 04/08/2016 01:46

(12) Time Server

Installed Options

(13) Paper Feeder Cassette (500 x 2)
 (14) SD Card Not Installed
 (15) SSD Not Installed
 (16) Finisher Not Installed
 (17) Card Authentication Kit (B) Not Installed
 (18) Data Security Kit (E) Not Installed
 (19) UG-33 Not Installed
 (20) USB Keyboard Not Connected
 (21) USB Keyboard Type US-English

(22) Print Coverage

Average (%) / Usage Page(A4/Letter Conversion)

(23) Total / 0.00
 K: 0.00 / 0.00
 (24) Copy / 0.00
 K: 0.00 / 0.00
 (25) Printer / 0.00
 K: 0.00 / 0.00
 (26) FAX / 0.00
 K: 0.00 / 0.00
 (27) Period (- 04/08/2016 01:46)
 (28) Last Page (%) 0.00
 (29) Last Job (%) 0.00

(30) FRPO Status

Reserved B0 00
 Default Pattern Switch B8 00
 Page Orientation C1 00
 Default Font Number C5*10000+C2*100+C3 00000
 Reserved C6 00
 PCL Font Switch C8 00
 Print density D4 03
 Reserved D6 03
 Host Buffer Size H8 05
 FF Time Out H9 06
 Reserved I5 01
 Reserved I6 00
 Zoom J0 00
 Text wrap mode J7 00
 Horizontal user offset K0+K1/100 0.00
 Vertical user offset K2+K3/100 0.00
 Default KANJI number K4 00
 KANJI code switch K6 00
 Reserved K9 00
 KIR Mode N0 02
 Duplex mode N4 00
 Sleep Timer N5 120
 EcoPrint Mode N6 00
 Reserved N7 00
 Print Resolution N8 01

Default Emulation P1 06
 CR/LF Action P2/P3 1/1
 AES Mode P4 00
 AES Option 1/2 P7 10
 Command Recognition P9 82
 Default Paper Output R0 01
 Default Paper Size R2 00
 Reserved R3 00
 Default Paper Source R4 01
 Override A4/LT S4 01
 Host Buffer Size Rate S5 01
 RAM Disk Size S6 128
 RAM Disk Mode S7 01
 Wide A4 T6 00
 Default Line Spacing U0+U1/100 6.00
 Default Character Spacing U2+U3/100 10.00
 Reserved U4 01
 Country Code/Symbol Set U6/U7 41/53
 Default Pitch U8+U9/100 10.00
 Default Font Height V0*100+V1+V2/100 12.00
 Default Font Name V3 Courier
 Default KANJI Font Size V4*100+V5+V6/100 10.00
 Default KANJI Font Name V7 MTHSMINCHO-W3
 Courier/LetterGothic V9 05
 MP Tray Paper Type X0 01
 Cassette 1 Paper Type X1 01
 Cassette 2 Paper Type X2 01
 Cassette 3 Paper Type X3 01
 PCL Paper Source X9 00
 Auto Error Clear Y0 00
 Error Clear Timer Y1 06
 Finishing error Y3 127
 Special Type Act Mode Y4 00
 PDF mode Y5 00
 e-MPS error control Y6 03

RP Code

(31) 0008 01E2 3177
 (32) 0008 027A C873
 (33) FFFF FFFF FFFF
 (34) 0008 01E2 31F5

Service Status Page

MFP
ECOSYS M4132idn



ZKG6400006

01/08/2016 14:30

[2.1.6] [2P1_F000.001.008]

Firmware Version 2P1_Q000.001.146 2016.08.01

[2P1_1000.001.020] [2P1_1100.001.001] [2P1_7000.001.216]

Controller Information

Print Settings

(35) MP Tray Priority Off

(36) Altitude Adjustment

Status Normal

(37) System Firmware(Details)

2P1_Q000.001.146
2P1_QA00.001.146
2P1_R000.001.146
2P1_R100.001.146
2P1_R200.001.146
2P1_R300.001.146
2P1_R400.001.146
2P1_R500.001.146
2P1_R600.001.146
2P1_R700.001.146
2P1_R800.001.146
2P1_R900.001.146
2P1_RB00.001.146
2P1_RD00.001.146
2P1_S100.001.146

Engine Information

(38) NVRAM Version _Cb26630_Cb26630

(39) FAX Slot1

FAX BOOT Version 2GR_5000.001.001

FAX APL Version 2GR_5100.001.001

FAX IPL Version 2GR_5200.001.001

(40) MAC Address 00:17:C8:16:84:04

(41) DP Counters
Total 0

Service Status Page



MFP
ECOSYS M4132idn

ZKG6400006

01/08/2016 14:30

(1) Firmware Version 2P1_Q000.001.146 2016.08.01

[2.1.6] [2P1_F000.001.008]
[2P1_1000.001.020] [2P1_1100.001.001] [2P1_7000.001.216]

```

(42)(43) 1/1
(44) 600/600
(45) 0/0/0/0/
(46) 0/0/0/0/
(47) 0/50/0/50/
(48) 0000000/0000000/0000000/0000000/0000000/0000000/
(49) 0000000//0000000/0000000//0000000/
(50) 0000000/
F00/U00/0/1/1/1/25/50/0/0/0/0/00//5/2/0/1/ (51)(52)(53)(54)(55)(56)(57)(58)(59)(60)(61)(62)(63)(64)(65)(66)(67)(68)(69)
(70) 2010/9000/4010/5000/3010/2010/4000/4010/3010/2010/5000/6000/
5010/2010/2010/2010/2010/2010/2010/2010/2010/2010/2010/
(71) 00000000/00000000/0000000000000000000000000000000000000000000000000000/0000/00/00
(72)(73) /0/
(74) [3NN_9000.002.001][][]
(75) [2P1_81DK.001.003][2P1_81SE.001.003][2P1_81NO.001.003][2P1_81BR.001.003][2P1_81TR.001.003]
(76) 0258000000/0258000000/0000-----/-----/-----00/000000002E/C3694B6-----/-----/-----0000000/
0-----/-----/-----/-----0/00000000-----/-----/-----00A00A8/
C003600000-/-----/-----/-----0000000/0-----/-----00000/000-----/
---96AF961/43C14---/---000493E/0-----0/0000000000/249F000024/9F0000249F/0000000000-/-----000/0000000000/
0000000000/0000000000-/0202-----/-----/-----/-----/-----/-----/
-----/-----/-----/-----/-----000/000000

(77) 0/
(78)(79) -/-/
(80)(81) 0/5/
(82) 1/
1/0/1/ (83)(84)(85)
(86) EZJ00Z400033/
(87) EZK00Z400016/
    
```


No.	Items	Contents
(1)	Firmware Version	-
(2)	Machine serial number	-
(3)	System date	-
(4)	API version of the HyPAS application	-
(5)	Browser version	-
(6)	Enginee firmware version	-
(7)	Enginee boot version	-
(8)	Operation panel firmware version	-
(9)	Total memory size	-
(10)	Local time zone	-
(11)	Report output date	Day/Month/Year hour : minute
(12)	NTP server name	-
(13)	Whether the paper feeder is installed or not	Cassette(500 sheets×1) / Cassette(1500 sheets×2) / Not Installed
(14)	Availability of the SD memory card	Installed/Not Installed
(15)	Whether the SSD	Installed/Not Installed
(16)	Availability of the finisher	500 sheets finisher/not installed
(17)	Availability of the ID Card Authentication Kit	Introduced/ before introduction/trial
(18)	Availability of the Security Kit(E)	Installed/Not Installed
(19)	Availability of UG-33	Introduced/ before introduction/trial
(20)	USB keyboard connection status	Connected/Not connected
(21)	Type of the USB keyboard	US-English/US-English with Euro symbol/German/French
(22)	Page count converted to the A4/Letter size	Print Coverage provides a close-matching reference of toner consumption and will not match the actual toner consumption.
(23)	Entire average coverage	Black
(24)	Average coverage for copy	Black
(25)	Average printer coverage	Black/
(26)	Average coverage for FAX	Black
(27)	Cleared date and output date	-
(28)	Coverage on the last output page	-
(29)	Last job coverage information	-
(30)	FRPO setting	-
(31)	RP code	Coding the Enginee firmware version and the date of the previous update.
(32)	RP code	Code the main software version and the date of the latest update.
(33)	RP code	Coding the Enginee firmware version and the date of the previous update.

No.	Items	Contents
(34)	RP code	Code the main software version and the date of the previous update.
(35)	MP tray priority setting	Off : No setting Auto : Auto paper feed Always : All times
(36)	High altitude adjustment set data	Normal/1001-2000m/2001-3000m/3001-3500m
(37)	System Firmware (detail)	-
(38)	NVRAM version	_ 1F3 1225 _ 1F3 1225 (a)(b)(c)(d)(e)(f) (a) Consistency of the current firmware version and the database _ (underscore): OK * (Asterisk): NG (b) Database version (c) The oldest time stamp of database version (d) Consistency of the present software version and the ME firmware version _ (underscore): OK * (Asterisk): NG (e) ME firmware version (f) The oldest time stamp of the ME firmware version Normal if (a) and (d) are underscored, and (b) and (e) are identical with (c) and (f).
(39)	FAX firmware version	-
(40)	Mac address	-
(41)	DP counter	The number of times of DP feeding
(42)	Destination information	-
(43)	Area information	-
(44)	Margin setting	Top margin/Left margin
(45)	Top offset	-
(46)	Left offset	-
(47)	L parameters	Top margin integer part/Top margin decimal part/Left margin integer part /Left margin decimal part
(48)	Life counter (cassette 1)	Machine life/MP tray/Cassette/Paper feeder 1/Paper feeder 2/ Duplex
(49)	Life counter (cassette 2)	Drum unit/Transfer unit/MC roller/Fuser unit
(50)	Life counter (cassette 3)	Maintenance kits
(51)	Panel lock information	F00: OFF F01: Partial lock1 F02: Partial lock2 F03: Partial lock3 F04: Full lock
(52)	USB information	U00: Not Connected U01: Full speed U02: Hi speed

No.	Items	Contents
(53)	Paper handling information	0: Paper source select 1: Paper source fixed
(54)	Auto cassette change	0: OFF 1: ON (Default)
(55)	Black and white printing double count mode	0: All single counts 1: A3 (Less than 420 mm length), Single counts 2: Legal(Less than 356mm length), Single counts 3: Folio (Less than 330 mm length), Single counts
(56)	Billing counts timing	0: When secondary paper feed starts 1: When completing output
(57)	Temperature (machine inside)	-
(58)	Temperature (machine outside)	-
(59)	Relative humidity (machine outside)	-
(60)	Absolute humidity (machine outside)	-
(61)	Machine inside humidity	-
(62)	LSU1 humidity information	-
(63)	LSU2 humidity information	-
(64)	DRT information	-
(65)	Asset Number	-
(66)	Job end judgment time-out time	-
(67)	Job end detection mode	0: Detects as one job, even if contained multiple jobs 1: Detects as individual job, dividing multiple jobs at a break in job
(68)	Prescribe environment reset	0: Off 1: On
(69)	Scan to SMB mode setting	0: Off 1: On
(70)	Media type attributes 1 to 28 (Not used: 18, 19, 20) For details on settings, refer to MDAT command in "Prescribe Commands Reference Manual".	Weight settings Fuser settings 0: Light 0: High 1: Normal 1 1: Middle 2: Normal 2 2: Low 3: Normal 3 3: Vellum 4: Heavy 1 5: Heavy 2 Duplex settings 6: Heavy 3 0: Disable 7: Heavy 4 1: Enable 8: Heavy 5 9: Extra Heavy
(71)	RFID information	-
(72)	RFID reader/writer version	-
(73)	Toner install mode information	0: Off 1: On
(74)	Cassette2 software version	-

No.	Items	Contents
(75)	Option message version	-
(76)	Maintenance information	-
(77)	MC correction	1 to 7
(78)	Low coverage setting	0.1 to 100.0
(79)	Middle coverage setting	0.1 to 100.0
(80)	Toner low setting	0: Disabled 1: Enabled
(81)	Toner low detection level	0 to 100 (%)
(82)	Shift regulation for a single original	0: disable (shift regulation off) 1: enable (shift regulation on)
(83)	ErP applied mode setting	0: ErP non-applied mode 1: ErP applied mode
(84)	Full-page print mode	0: Normal mode (Factory setting) 1: Full-page mode
(85)	Wake-up mode	0: Off (Don't wake up) 1: On (Do wake up)
(86)	Drum serial number	-
(87)	Developer serial number	-

U001 Exiting the maintenance mode

(Message: Exit Mainte)

Contents

Exits the maintenance mode and returns to the normal copy mode.

Purpose

Exit the maintenance mode.

Method

- 1 Press the [Start] key.
The normal copy mode is entered.

U002 Set Factory Default

(Message: Set Factory Def)

Contents

Sets the machine initial setting values to the factory default.

Purpose

Executes the machine initial settings when shipping from factory.

Method

- 1 Press the [Start] key.
- 2 Select [Mode1(All)].

Items	Contents
Mode1(All)	Sets the machine initial setting values to the factory default.

- 3 Press the [Start] key.

- 4 Turn the power switch off.

An error code is displayed in case of the initialization error.

When errors occur, turn the power switch off then on, and execute initialization using maintenance mode U002.

Wait more than 5 seconds between the power off and on.

Error codes

Codes	Contents
0002	Setting information initialization failure
0003	Address book information initialization failure
0004	Job accounting information initialization failure
0005	Event log/Fax log/Job log information initialization failure
0006	Fax memory forward/panel program information initialization failure
0007	Short-cut key information initialization failure
0008	Fax reserve information initialization failure
0009	Account information initialization failure
0010	RP code backup execution failure
0011	Event log counter information/Accounting/Maintenance category initialization failure
0012	Coverage counter information initialization failure
0013	Life counter information initialization failure
0014	Enginee information initialization failure
0015	Scanner information initialization failure
0016	Log audit (inspection log) initialization failure
0017	Device information initialization failure
0018	Device information initialization failure

- The operation is terminated abnormally and it is necessary to execute it once more after turning the power off.

U004 Machine Number

(Message: Machine No.)

Contents

Sets or displays the machine serial number.

Purpose

Checks the machine serial number

After the main/Enginee PWB replacement, execute if the "C0180 machine number mismatch" occurs.



Caution

Do not execute U004, select [Execute] and press [Start] key if the machine serial number in the Enginee PWB is different from the main unit serial number. A different machine serial number is overwritten in the main PWB.

Method

- 1 Press the [Start] key.

When the machine serial number in the Enginee PWB matches the one in the main PWB,

Items	Contents
Machine No.	Displays the machine serial number.

When the machine serial number in the Enginee PWB does not match the one in the main PWB,

Items	Contents
Machine No.(Main)	Displays the machine serial number in the main PWB.
Machine No.(Eng)	Displays the machine serial number in the Enginee PWB.

Setting

Execute if the serial numbers do not match.

- 1 Select [Execute].
- 2 Press the [Start] key.
The serial number writing starts.
- 3 Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U010 Setting the maintenance mode ID

(Message: Set Mainte ID)

Contents

Change the maintenance mode ID for service.

Purpose

Modify maintenance mode ID for service for more security.

Method

- 1 Press the [Start] key.
- 2 Select the item to set.
The screen for setting is displayed.

Items	Contents
Change	Change the maintenance mode ID for the field.
Initialize	Initializes the maintenance mode ID for the field.

Method: Check

- 1 Select [New ID].

Items	Contents
New ID	Enter a new 8-digit maintenance ID
New ID(Reconfirm)	Enter a new 8-digit maintenance ID (to confirm)
Execute	Change the maintenance mode ID for the field.

- 2 Press ten keys (0–9, *, #) to enter a new 8-digit ID.
Either [*] or [#] must be included.
- 3 Press the [Start] key to set the setting value.
- 4 Select [New ID(Reconfirm)].
- 5 Press ten keys (0–9, *, #) to re-enter the new 8-digit ID.
- 6 Select [Execute].
- 7 Press the [Start] key to set the setting value.

Method: Initialize

- 1 Select [Execute].

Items	Contents
Execute	Initializes the maintenance mode ID for service.

- 2 Press the [Start] key to initialize the maintenance mode ID.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

Error codes

Codes	Contents
0001	Do not include "#" or "*" in the ID.
0002	ID does not match.
0003	8-digit ID is not input

U019 Firmware Version

(Message: Firm Version)

Contents

Displays the firmware version installed in each PWB.

Purpose

Check the firmware version installed in each PWB

Method

- 1 Press the [Start] key.
The firmware version is displayed.
- 2 Change the screen using the [^] [V] key.

Items	Contents
Controller	Main firmware
CMN App	CMN App firmware
SST App	SST App firmware
MNT App	MNT App firmware
CPY App	CPY App firmware
PRT App	PRT App firmware
SND App	SND App firmware
BOX App	BOX App firmware
FAX App *1	FAX App firmware
WPG App	WPG App firmware
AUTH App	AUTH App firmware
PCS App	PCS App firmware
SCO App	SCO App firmware
PLP	PLP firmware
EXSP	EXSP firmware
Version Info	Version Info firmware
MMI	Operation firmware
Browser	Browser firmware
Option Language1	Optional language1 firmware
Option Language2	Optional language2 firmware
Option Language3	Optional language3 firmware
Option Language4	Optional language4 firmware
Option Language5	Optional language5 firmware
Sub MMI	Panel firmware
Sub MMI Boot	Panel Boot
Fax APL *1	Fax APL firmware

Items	Contents
Fax Boot *1	Fax Boot
Fax IPL *1	Fax IPL firmware
Enginee	Enginee firmware
Enginee Boot	Enginee boot
DP	DP firmware
DP Boot	DP Boot
DF *2	finisher firmware
DF Boot *2	finisher boot
AK *3	Attachment kit firmware
AK Boot *3	Attachment kit boot
PF	Paper feeder firmware
PF Boot	Paper Feeder boot
HyPAS EMB API	HyPAS EMB API firmware
Application Name 01	Application 1 firmware
Application Name 02	Application 2 firmware
Application Name 03	Application 3 firmware
Application Name 04	Application 4 firmware
Application Name 05	Application 5 firmware
Application Name 06	Application 6 firmware
Application Name 07	Application 7 firmware
Application Name 08	Application 8 firmware
Application Name 09	Application 9 firmware
Application Name 10	Application 10 firmware
Application Name 11	Application 11 firmware
Application Name 12	Application 12 firmware
Application Name 13	Application 13 firmware
Application Name 14	Application 14 firmware
Application Name 15	Application 15 firmware
Application Name 16	Application 16 firmware

*1: FAX installed machine only/ *2: DP installed machine only/ *3: AK installed machine only

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U021 Initializes Memory

(Message: Init Memory)

Contents

Initializes all settings, except those pertinent to the type of machine, namely each counter, service call error history and mode setting. Also, initializes the backup RAM according to the area specification selected in the maintenance mode U252 (Setting the destination).

Purpose

Initialize the backup data except machine settings to the factory default in the field

Method

- 1 Press the [Start] key.
- 2 Select [Execute].

Items	Contents
Execute	Initialize data according to the destination information.

- 3 Press the [Start] key.
All data other than for adjustments is initialized by the destination setting.
- 4 Turn the power switch off then on. Wait more than 5 seconds between the power off and on.
An error code is displayed in case of the initialization error.
When errors occur, turn the power switch off then on, and execute initialization using maintenance mode U021.

Error codes

Items	Contents
0002	Setting information initialization failure
0003	Address book information initialization failure
0004	Job accounting information initialization failure
0005	Event log/Fax log/Job log information initialization failure
0006	Fax memory forward/panel program information initialization failure
0007	Short-cut key information initialization failure
0008	Fax reserve information initialization failure
0009	Account information initialization failure
0010	RP code backup execution failure
0011	Event log counter information/Accounting/Maintenance category initialization failure
0012	Coverage counter information initialization failure
0013	Life counter information initialization failure
0014	Enginee information initialization failure
0015	Scanner information initialization failure
0016	Log audit (inspection log) initialization failure
0017	Device information initialization failure
0018	Device information initialization failure

- The operation is terminated abnormally and it is necessary to execute it once more after turning the power off.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U025 Firmware update (S)

(Message: Firm Update(S))

Contents

Executes Firmware-Update from the USB memory while "Very High" is selected in the Security Level settings under the System Menu.

Supplement

Initiate the firmware upgrade by a service person by executing U025 while a USB memory is inserted

Method

- 1 Press the [Start] key.
- 2 Select [Execute].

Items	Contents
Execute	Updates the firmware

- 3 Press the [Start] key.
This is not executable when a USB memory is not installed.
- 4 After normal completion, turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U030 Motor operation check

(Message: Chk Motor)

Contents

Drive each motor.

Purpose

Execute to check each motor's operation.

Method

- 1 Press the [Start] key.
- 2 Select the motor to operate.
- 3 Press the [Start] key.
Each operation starts.

Items	Contents
Main	Operate the main motor
Exit(CW)	Operate the exit motor(CW)
Exit(CCW)	Operate the exit motor(CCW)
Fuser	Operate the fuser motor
DLP	Operate the the developer motor

To stop the operation, press the [Stop] key.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U031 Check the conveying switch

(Message: Chk Switch)

Contents

Displays the on/off status of each switch and sensor to detect paper on the paper conveying path.

Purpose

Execute to check the conveying switches and sensors are operating correctly.

Method

- 1 Press the [Start] key.
- 2 Check the switches and sensors by manually turning them on/off.
- 3 The switch indication is inverted when the switch is detected.

Items	Contents
Regist	Displays the switching status of the registration sensor
Fuser	Displays the switching status of the exit sensor
Dup	Displays the switching status of the DU sensor
Feed	Displays the switching status of the paper feed sensor
Tray Full	Displays the switching status of the exit full sensor
JobSepa Full	Displays the switching status of the job separator full sensor
Bridge	Displays the switching status of the bridge switch
Contain	Displays the switching status of the container sensor

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U032 Clutch operation check

(Message: Chk Clutch)

Contents

Supply power to each clutch.

Purpose

Execute to check each clutch's operation.

Method

- 1 Press the [Start] key.
- 2 Select the clutch to operate.
- 3 Press the [Start] key.
Each operation starts.

Items	Contents
Feed1	Operates the paper feed clutch 1
Regist	Operate the registration clutch
Dup	Operate the duplex clutch
DLP	Operate the developer clutch
Motor	Operate the motor

The clutch operation is available while the motor is operated.

- 4 To stop the clutch operation, press the [Stop] key.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U033 Solenoid operation check

(Message: Chk Solenoid)

Contents

Supply power to each solenoid.

Purpose

Execute to check each solenoid's operation.

Method

- 1 Press the [Start] key.
- 2 Select the solenoid to operate.
- 3 Press the [Start] key.
Each operation starts.
Select the motor before checking the motor rotation.

Items	Contents
MPT	Operate the MP solenoid
Eject	Operate the exit solenoid
Motor	Operate the motor

The solenoid operation is available while the motor is operated.

- 4 To stop the operation of the solenoid, press the [Stop] key.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U034 Paper timing data adjustment

(Message: Adj Paper Timing)

Contents

Adjust the leading edge registration or center line.

Purpose

Executed if there is a regular error between the leading edges of the copy image and original.

Adjusted if there is a regular error between the center lines of the copy image and original.

Method

- 1 Press the [Start] key.
- 2 Select the item to adjust.
The screen for adjusting is displayed.

Items	Contents
LSU Out Top Full	Adjust the leading edge timing
LSU Out Left	Adjusts the center line

Adjustment: LSU Out Top Full

- 1 Select the item to adjust.
- 2 Press the [System Menu/Counter] key .

Note

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Source/Conveying speed/Duplex/Color/Copies)

- 3 Press the [Start] key to output a test pattern.
- 4 Press the [System Menu/Counter] key .


Items	Contents	Setting range	Initial setting	Data variation
Cass	Adjust the leading edge timing for the cassette paper feed	-70 to 70	0	1 dot
MPT	Adjust the leading edge timing for the MP tray	-70 to 70	0	1 dot
Dup	Adjust the leading edge timing for the duplex print	-70 to 70	0	1 dot

- 5 By using the [<] [>] keys or the numeric keys, change the setting value.

For the test pattern 1, increase the value.

For the test pattern 2, decrease the value.

When the setting value is increased, the image moves backward, and it moves forward when the setting value is decreased.



- 6 Press the [Start] key to set the setting value.

 **Important**

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034 > U066([P. 6-47](#)) > U071([P. 6-53](#))

Adjustment: LSU Out Left

- 1 Select the item to adjust.
- 2 Press the [System Menu/Counter] key .

 **Note**


Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Source/Conveying speed/Duplex/Color/Copies)

- 3 Press the [Start] key to output a test pattern.
- 4 Press the [System Menu/Counter] key .


Items	Contents	Setting range	Initial setting	Data variation
MPT	Adjust the center line for the MP tray	-70 to 70	0	0.1mm
Cass1	Adjust the center line for cassette 1 feed	-70 to 70	0	0.1mm
Cass2	Adjust the center line for cassette 2 feed	-70 to 70	0	0.1mm
Cass3	Adjust the center line for cassette 3 feed	-70 to 70	0	0.1mm
Dup	Adjusting the center line when duplex copying (Back page)	-70 to 70	0	0.1mm

- 5 By using the [<] [>] keys or the numeric keys, change the setting value.
For the test pattern 1, increase the value.
For the test pattern 2, decrease the value.
When the setting value is increased, the image moves to right, and it moves to left when the setting value is decreased.


Center line of printing
(within ± 0.5 mm)



Correct image



Output example 1



Output example 2

- 6 Press the [Start] key to set the setting value.

 **Important**

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034 < U067([P. 6-49](#)) < U072([P. 6-55](#))

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U035 Folio size setting

(Message: Adj Folio Sz)

Contents

Changes the printable area when copying with Folio paper.

Purpose

Setting the actual size of Folio to use prevents the image dropout at the trailing edge or right/left edges.

Method

- 1 Press the [Start] key.
- 2 Select the item to set.
- 3 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Contents	Setting range	Initial setting	Data variation
Length	Sets the Folio paper length.	318 to 356 (mm)	330	1(mm)
Width	Sets the Folio paper width.	200 to 220(mm)	210	1(mm)

- 4 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U037 Fan motor operation check

(Message: Chk Fan Motor)

Contents

Drive each fan motor.

Purpose

Execute to check each fan motor's operation.

Method

- 1 Press the [Start] key.
- 2 Select the fan motor to operate.
- 3 Press the [Start] key.
Each operation starts.

Items	Contents
All	Operate all the fan motors
Eject	Operate the exit fan motor
Low Power	Operate the power source fan motor
LSU Cooling	Operate the LSU fan motor
Conveying	Operate the Conveying fan motor
Temp/Hmd	Operate the temperature/humidity fan motor

- To stop the operation, press the [Stop] key.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U051 Registration paper loop amount adjustment

(Message: Adj Paper Loop)

Contents

Adjusts the paper loop amount.

Purpose

The leading edge of the image may drop, image position may shift irregularly or paper is folded in a Z-shape.

Use to check/adjust skew feed.

Method

1 Press the [Start] key.

2 Select the item to adjust.

The screen for adjusting is displayed.

Items	Contents
Full	Paper loop amount adjustment at full speed
Half	Paper loop amount adjustment at half speed

Adjustment: Full/Half

1 Select the item to adjust.

2 Press the [System Menu/Counter] key .

Note

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Source/Conveying speed/Duplex/Color/Copies)

3 Place an original and press the [Start] key to make a test copy.

4 Press the [System Menu/Counter] key .

The screen for adjusting is displayed.


Items	Contents	Setting range	Initial setting	Data variation
MPT	Paper loop amount adjustment for the MP tray feed	-30 to 20	0	1mm
Cass1	Paper loop amount adjustment for the cassette 1 feed	-30 to 20	0	1mm
PF	Paper loop amount adjustment for the PF feed	-30 to 20	0	1mm
Dup	Paper loop amount adjustment for the duplex	-30 to 20	0	1mm

5 By using the [<] [>] keys or the numeric keys, change the setting value.


For the copy example 1, increase the value.

For the copy example 2, decrease the value.

When the setting value is increased, the paper loop amount increase, and it decreases when the setting value is decreased.



Original

Copy
example 1Copy
example 2

- 6 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U053 Adjusting the motor speed

(Message: Adj Motor Speed)

Contents

Execute the motor speed fine tuning.

Purpose

No need to change the basic settings. Change the set value when an image failure occurs.

Method

- 1 Press the [Start] key.
- 2 Select the item to adjust.
The screen for adjusting is displayed.

Items	Contents
Full	Adjusting the motor speed at full speed
Half	Adjusting the motor speed at half speed

Setting: Full/Half

- 1 Select the item to adjust.
The screen for adjusting is displayed.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Contents	Setting range	Initial setting	Data variation
Main	Sets the main motor	-100 to 100	0	0.1%
Main(MPT)	Sets the main motor (MP)	-100 to 100	0	0.1%
Main(Dup)	Sets the main motor (DU)	-100 to 100	0	0.1%
Main(PF)	Sets the main motor (PF)	-100 to 100	0	0.1%
Fuser	Sets the fuser motor	-100 to 100	0	0.1%
Polygon	Sets the polygon motor	-100 to 100	0	0.1%
Exit	Sets the exit motor	-100 to 100	0	0.1%
DLP	Sets the developer motor	-100 to 100	0	0.1%

- 3 Press the [Start] key to set the setting value.

Note

Test copy of the original is available by pressing the [System Menu/Counter] key as interruption copy mode when executing this maintenance mode.

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Source/Conveying speed/Duplex/Color/Copies)

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U063 Shading position adjustment

(Message: Adj Shading)

Contents

Changes the scanner shading position.

Purpose

Execute if the vertical white lines appears on the image and they are not improved after cleaning the shading plate, namely there are scratches or dirt inside the shading plate.

By changing the shading position, shading is available where there is no influence of dirt or scratch of the shading plate.

Setting

- 1 Press the [Start] key.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Contents	Setting range	Initial setting	Data variation
Position	Changes the scanner shading position	-3 to 18 (32 sheets) -6 to 34 (25 sheets)	0 0	- -

If the set value is increased, the shading position moves toward the machine left side and toward the right side if the value is reduced.

- 3 Press the [Start] key to set the setting value.



Note

Test copy of the original is available by pressing the [System Menu/Counter] key as interruption copy mode when executing this maintenance mode.

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings. (Source/Conveying speed/Duplex/Orientation/Color/Copies)

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U065 Adjusting the magnification for table scanning

(Message: Adj Scn)

Contents

Adjust the magnification in the main and sub scanning direction of the table scanning.

Purpose

Adjusts the magnification in the main and sub scanning direction of the table scanning if the above incorrect

Important

The magnification adjustment in the main scanning direction could cause black streaks depending on the content of the original document.

Adjust the magnification of the scanner in the following order.

U065(main scanning direction)([P. 6-45](#))>U065((sub scanning direction)([P. 6-45](#))

Method

- 1 Press the [Start] key.
- 2 Press the [System Menu/Counter] key .

Note

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Source/Conveying speed/Duplex/Orientation/Color/Copies)


- 3 Place an original and press the [Start] key to make a test copy.
- 4 Press the [System Menu/Counter] key .
- 5 Select the item to adjust.

Items	Contents	Setting range	Initial setting	Data variation
Main Scan	Scanner magnification in the main scanning direction	-75 to 75	0	0.02%
Sub Scan	Adjusts scanner magnification in the sub-scanning direction	-125 to 125	0	0.02%


Adjustment: Main Scan

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.
 - For the copy example 1, increase the value.
 - For the copy example 2, decrease the value.

When the setting value is increased, the image widens, and it narrows when the setting value is decreased.



Original

Copy
example 1Copy
example 2


- 2 Press the [Start] key to set the setting value.

Adjustment: Sub Scan


- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

- For the copy example 1, increase the value.
- For the copy example 2, decrease the value.

When the setting value is increased, the image get longer, and it shortens when the setting value is decreased.



Original

Copy
example 1Copy
example 2

- 2 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U066 Adjusting the table scanning timing

(Message: Table Timing)

Contents

Adjusts the leading edge timing for the table scanning.

Purpose

Executed if there is a regular error between the leading edges of the copy image and original.

Adjustment

- 1 Press the [Start] key.
- 2 Press the [System Menu/Counter] key .

Note

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Source/Conveying speed/Duplex/Orientation/Color/Copies)

- 3 Place an original and press the [Start] key to make a test copy.
- 4 Press the [System Menu/Counter] key .


Items	Contents	Setting range	Initial setting	Data variation
Front	Adjusts the scanner leading edge margin.	-30 to 30 *2 -57 to 57 *1	0 0	0.158 (mm) 0.158 (mm)

*1: 25 ppm model *2: 32 ppm model

- 5 By using the [<] [>] keys or the numeric keys, change the setting value.
 - For the copy example 1, increase the value.
 - For the copy example 2, decrease the value.

When the setting value is increased, the image moves forward, and it moves backward when the setting value is decreased.

Leading edge registration of the copy image (+1.0/-1.5 mm)



- 6 Press the [Start] key to set the setting value.

Important

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034([P. 6-36](#)) > U065([P. 6-45](#)) > U066

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U067 Adjusting the table scanning center line

(Message: Table Center)

Contents

Adjusts the center line for the table scanning.

Purpose

Adjusted if there is a regular error between the center lines of the copy image and original.

Adjustment

- 1 Press the [Start] key.
- 2 Press the [System Menu/Counter] key .

Note

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Source/Conveying speed/Duplex/Orientation/Color/Copies)


- 3 Place an original and press the [Start] key to make a test copy.
- 4 Press the [System Menu/Counter] key .

Items	Contents	Setting range	Initial setting	Data variation
Front	Adjusts the scanner center line	-60 to 60	0	0.085 (mm)

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.
 - For the copy example 1, decrease the value.
 - For the copy example 2, increase the value.

When the setting value is increased, the image moves to left, and it moves to right when the setting value is decreased.

Center line of the copy image (within ± 2.0 mm)



- 2 Press the [Start] key to set the setting value.

Important

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034([P. 6-36](#)) > U065([P. 6-45](#)) > U067

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U068 DP scanning position adjustment

(Message: DP Scn Start Pos)

Contents

Adjusts the starting position for scanning originals from the DP.

Execute test copy at the four scanning positions after adjustment.

Purpose

Adjust if the image fogging occurs because the scanning position is not proper when the DP is used

Execute U071 to adjust the timing of the DP leading edge when the scanning position is changed.

Method

- 1 Press the [Start] key.
- 2 Select the item to adjust.

Items	Description	Setting range	Initial setting	Data variation
DP Read	Adjusts the starting position for scanning originals.	-38 to 38 *2 -72 to 72 *1	0 0	0.158 (mm) 0.158 (mm)
Black Line	Adjusts the scanning position for the test copy originals.	0 to 3	0	-

*1: 25 ppm model *2: 32 ppm model

Adjustment: DP Read

- 1 Select [DP Read].
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.
When the setting value is increased, the image moves backward, and it moves forward when the setting value is decreased.
- 3 Press the [Start] key to set the setting value.

Adjustment: Black Line

- 1 Select [Black Line].
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.
- 3 Press the [Start] key to set the setting value.
- 4 Set the original (the one of which density is known) in the DP and press the [System Menu/Counter] key .



Note

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Source/Conveying speed/Duplex/Orientation/Color/Copies)

- 5 Press the [Start] key to execute the test copy.
- 6 Perform the test copy at each scanning position with the setting value from 0 to 3 and check that no black line appears and the image is normally scanned.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U070 DP magnification adjustment

(Message: Adj DP Motor)

Contents

Adjusting the magnification for DP scanning.

Purpose

Adjusted if the magnification is incorrect in the auxiliary scanning direction when the DP is used

Adjustment

- 1 Press the [Start] key.
- 2 Press the [System Menu/Counter] key .

Note


Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Source/Conveying speed/Duplex/Orientation/Color/Copies)

- 3 Place an original on the DP and press the [Start] key to make a test copy.
Check the duplex scanning by setting [Duplex] when test copying.
- 4 Press the [System Menu/Counter] key .
- 5 Select the item to adjust.


Items	Description	Setting range	Initial setting	Data variation
Sub Scan (F)	Adjusting the magnification for table scanning	-125 to 125	0	0.02%
Sub Scan (B)	Adjusts the 2nd side magnification in the sub scanning direction when duplex scanning	-125 to 125	0	0.02%

- 6 By using the [<] [>] keys or the numeric keys, change the setting value.
 - For the copy example 1, increase the value.
 - For the copy example 2, decrease the value.


When the setting value is increased, the image get longer, and it shortens when the setting value is decreased.



Original



Copy example 1



Copy example 2

- 7 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U071 Adjusting the DP leading edge Timing

(Message: DP Timing)

Contents

Adjusts the DP original scanning timing.

Purpose

Adjusted if there is a regular error between the leading or trailing edges of the original and the copy image when the DP is used

Method

- 1 Press the [Start] key.
- 2 Press the [System Menu/Counter] key .

Note

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Source/Conveying speed/Duplex/Orientation/Color/Copies)

- 3 Place an original on the DP and press the [Start] key to make a test copy.
 - Check the duplex scanning by setting [Duplex] when test copying.
- 4 Press the [System Menu/Counter] key .
- 5 Select the item to adjust.


Items	Description	Setting range	Initial setting	Data variation
Front Head	Leading edge registration. (Front page)	-36 to 36	0	-
Front Tail	Trailing edge registration. (Front page)	-36 to 36	0	-
Back Head	Leading edge registration. (Back page)	-36 to 36	0	-
Back Tail	Trailing edge registration. (Back page)	-36 to 36	0	-

Adjustment: Front Head/Back Head

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.
For the copy example 1, increase the value.
For the copy example 2, decrease the value.

When the setting value is increased, the image moves forward, and it moves backward when the setting value is decreased.

Leading edge registration of the copy image (+1.0/-1.5 mm)



- 2 Press the [Start] key to set the setting value.

 **Important**


Check the 2nd side after adjusting the 1st side. Adjust if necessary. Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034([P.6-36](#)) > U071


Adjustment: Front Tail/Back Tail

- 1 By using the [<] [>] keys or the numeric keys, change the setting value. For the copy example 1, increase the value. For the copy example 2, decrease the value.


When the setting value is increased, the image get longer, and it shortens when the setting value is decreased.



Original



Copy
example 1



Copy
example 2

- 2 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U072 Adjusting the DP original center

(Message: DP Center)

Contents

Adjusts the DP original center line.

Purpose

Adjusted if there is a regular error between the center lines of the original and the copy image when the DP is used

Adjustment

- 1 Press the [Start] key.
- 2 Press the [System Menu/Counter] key .

Note

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Source/Conveying speed/Duplex/Orientation/Color/Copies)


- 3 Place an original on the DP and press the [Start] key to make a test copy.
Check the duplex scanning by setting [Duplex] when test copying.
- 4 Press the [System Menu/Counter] key .
- 5 Select the item to adjust.

Items	Description	Setting range	Initial setting	Data variation
Front	DP center line. (Front page)	-60 to 60	0	0.085 (mm)
Back	DP center line. (Back page)	-60 to 60	0	0.085 (mm)

- 6 By using the [<] [>] keys or the numeric keys, change the setting value. For the copy example 1, decrease the value. For the copy example 2, increase the value.

When the setting value is increased, the image moves to left, and it moves to right when the setting value is decreased.

Center line of the copy image (within ± 2.0 mm)



- 7 Press the [Start] key to set the setting value.

Important

Check the 2nd side after adjusting the 1st side. Adjust if necessary.

Check the copy image after the adjustment.

If the image is still incorrect, adjust the following in the maintenance mode.

U034([P. 6-36](#)) > U065([P. 6-45](#)) > U067([P. 6-49](#)) > U072

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U089 MIP-PG pattern output

(Message: Output MIP-PG)

Contents

Select and output the MIP-PG pattern generated by the main unit.




Purpose


When adjusting the image scanning items, execute to check the machine status except the scanner section using the MIP-PG pattern output without image scanning process.

Test pages printed from the maintenance mode are not counted for the print coverage and page count displayed on the service status page.

Method

- 1 Press the [Start] key.
- 2 Select the MIP-PG pattern to output

Items	Contents
Gray scale	Gray scale pattern PG 
Mono1	Gray check PG (density: 0) 
Mono4	Gray check PG (density: 70) 

Items	Contents
256Gradation	PG for the grayscale level check (256 grayscale PG1) 
Sample Set	Outputs the following output patterns for the long life unit warranty application PG for the developer status and Engine ID check, for drum quality check (Gray scale, Mono4)

- 3 Press the [System Menu/Counter] key .



Caution



Note

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Copies)

- 4 Press the [Start] key to output a MIP-PG pattern.
- 5 Press the [System Menu/Counter] key .

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U099 Original size detection setting

(Message: Detect Org Sz)

Contents

Sets the original size detection check and detection threshold

Purpose

Changes the detection threshold if the original size is often mis-detected with entirely dark originals (high density) or originals dark at edges only

Setting

- 1 Press the [Start] key.
- 2 Select the item to set.
The screen for setting is displayed.

Items	Contents
Data1	Display of the original width of OriginalArea color
B/W Level1	Original size detection threshold setting
Data2	Display of the original copies width of OriginalArea color (when the document processor is installed)

Execution: Data1/Data2

- 1 Place an original copy on the table and close the document processor.
- 2 The light source is turned on and the CCD sensor detects the original width. The original size sensor detects the original lengthwise. (Detected twice)

Items	Contents
Original Area(dot)	Detected number of pixels (dot) in the original width
Original Area(mm)	Detected number of pixels (mm) in the original width
Size SW L	Indicating ON/OFF of the original length sensor (0: Off/1: On)


Setting: B/W Level1

- 1 Select the item to set.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Original1	Sets the threshold to judge the original	0 to 255	50	-
Original2	Sets the threshold to judge the original	0 to 255	50	-
Original3	Sets the threshold to judge the original	0 to 255	50	-
Light Source	Sets the threshold to judge the light source	0 to 255	49	-

Lowering the setting value improves the sensor's sensitivity and high density originals can be detected but the original mat may be detected as an original.

If differentiating each setting value, mis-detection may appear depending on the condition of placing the original.



In the figure	Original R/G/B	Original width size range	
①	1	A4R to A3	8.5" to 11"
②	2	B6R to A4R	5.5" to 8.5"
③	3	to B6R	to 5.5"

- 3 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U100 Main high voltage adjustment

(Message: Main HV Output)

Contents

Adjust the surface potential by changing the voltage impressed to the main charge roller.

Purpose

Change the set value to adjust the image when an image failure (background image) occurs.

Method

1 Press the [Start] key.

2 Select the item to set.

The screen for setting is displayed.

Items	Description
Adj AC Bias	Adjust the main charge AC bias
Set AC Auto Adj	Sets the automatic AC bias adjustment
Set DC Bias	Displays the main charge DC bias correction value
Adj DC Bias	Adjust the surface potential additional value
Set Charger Freq	Sets the frequency of the main charger
Chk Current	Displays the electric current flows

Setting: Adj AC Bias

1 Displays the current setting. (Enginee firmware displays the environmental correction result)

2 By using the [<] [>] keys or the numeric keys, change the setting value.

When the setting value is increased, the image get thinner, and it gets thicker when the setting value is decreased.
Set value is variable depending on the environment.

Items	Description	Setting range	Initial setting	Data variation
AC(K)	Black main charge AC bias value	400 to 2300	950	1V

3 Press the [Start] key to set the setting value.

Setting: Set AC Auto Adj

1 Select the item to set.

Items	Contents
On	Adjust automatically
Off	Not adjusted automatically

Initial setting: On

2 Press the [Start] key to set the setting value.

Setting: Set DC Bias

- 1 Displays the current setting. (Enginee firmware displays the environmental correction result)

Items	Description	Setting range	Initial setting	Data variation
DC1(K)	Black main charge DC bias value (Full speed)	225 to 675	450	1V

Setting: Adj DC Bias

- 1 Select the item to set.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.
When the setting value is increased, the image get thinner, and it gets thicker when the setting value is decreased.

Items	Description	Setting range	Initial setting	Data variation
DC2(K)	Black main charge DC bias additional value (Full speed)	-128 to 127	0	1V

- 3 Press the [Start] key to set the setting value.

Setting: Set Charger Freq

- 1 Select the item to set.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.
When the setting value is increased, the image get thicker, and it gets thinner when the setting value is decreased.

Items	Description	Setting range	Initial setting	Data variation
Generally	Setting the frequency of the main charger (Normal speed)	500 to 3000	1800	1Hz

- 3 Press the [Start] key to set the setting value.

Setting: Chk Current

- 1 Displays the current setting.

Items	Contents
K	Black inflow current

 **Note**

Test copy of the original is available by pressing the [System Menu/Counter] key as interruption copy mode when executing this maintenance mode.

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings. (Source/Conveying speed/Duplex/Orientation/Color/Copies)

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U101 Primary transfer voltage adjustment

(Message: 1st TC Output)

Contents

Set the primary transfer control voltage

Purpose

Change setting if a failure such as faint image, etc. occurs.

Setting

- 1 Press the [Start] key.
- 2 Select the item to set.
- 3 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
On Timing	On timing setting	-1000 to 1000	0	1ms
Off Timing	Off timing setting	-1000 to 1000	0	1ms
Bias(L)	Bias (L) setting	300 to 2400	748 *2	0.1μA
			586 *1	0.1μA
Bias(M)	Bias (M) setting	300 to 2400	970 *2	0.1μA
			759 *1	0.1μA
Bias(S)	Bias (S) setting	300 to 2400	1410 *2	0.1μA
			1104 *1	0.1μA
Bias Half(L)	Half-speed bias setting (L)	300 to 2400	423	0.1μA
Bias Half(M)	Half-speed bias setting (M)	300 to 2400	483	0.1μA
Bias Half(S)	Half-speed bias setting (S)	300 to 2400	643	0.1μA

*1: 25 ppm model *2: 32 ppm model

- 4 Press the [Start] key to set the setting value.

Note

Test copy of the original is available by pressing the [System Menu/Counter] key as interruption copy mode when executing this maintenance mode.

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings. (Source/Conveying speed/Duplex/Orientation/Color/Copies)

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U108 Separation Shift bias adjustment

(Message: Adj Sepa Sbias)

Contents

Adjust On/Off timing of the separation shift bias.

Purpose

Execute when paper separation failure occurs. (Paper rolled up by the drum is held down)

Method

- 1 Press the [Start] key.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Mode	Mode setting	1 to 8	1	-

- 3 Press the [Start] key to set the setting value.

Note

Test copy of the original is available by pressing the [System Menu/Counter] key as interruption copy mode when executing this maintenance mode.

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings. (Source/Conveying speed/Duplex/Orientation/Color/Copies)

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U110 Drum counter

(Message: Drum Cnt)

Contents

Displays the drum counter values.

Purpose

Execute to check the drum usage status.

Method

- 1 Press the [Start] key.

The drum counter is displayed.

Items	Contents
K	Displays the drum counter

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U110 Drum drive time

(Message: Drum Time)

Contents

Display the drum drive time that is used for the high-voltage time correction.

Purpose

Execute to check the drum usage status.

Method

- 1 Press the [Start] key.

Displays the drum drive time.

Items	Contents
K	Displays the drum drive time.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U117 Drum unit number

(Message: Drum No.)

Contents

Displays the drum number.

Purpose

Execute to check the drum number.

Method

- 1 Press the [Start] key.

Displays the drum number.

Items	Contents
K	Displays the black drum number

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U118 Drum unit history

(Message: Drum History)

Contents

Displays the machine serial number and drum counter history.

Purpose

Execute to check the machine serial number and drum counter values.

Method

- 1 Press the [Start] key.

Select the item to refer to.

Items	Contents
K	Displays the black drum history

Displays the machine serial number and 3 items of the drum counter history.

Items	Contents
Machine History1 to 3	Machine serial number history
Cnt History1 to 3	The drum counter history

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U120 Drum drive distance counter

(Message: Drum Drv Dist Cnt)

Contents

Displays the drum drive distance counter.

Purpose

Drum control counter that is used instead of the conventional drum drive counter.

Method

- 1 Press the [Start] key.

Displays the drum drive distance counter

Items	Contents
K	Displays the black drum drive distance counter

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U127 Clearing the transfer count

(Message: Clr Trans Cnt)

Contents

Display and clear the transfer counts for the transfer high-voltage output correction etc.

Purpose

Verify the transfer unit count after replacement. Also, clear the transfer counts after replacement.

Method

- 1 Press the [Start] key.

The transfer counter value appears.

Items	Contents
Cnt	Displays the transfer counts
Clear	Clearing the transfer counts

Method: Clear

- 1 Select [Clear].
- 2 Press the [Start] key to clear the transfer counter value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U136 Toner level detection setting

(Message: Set Toner Near End)

Contents

Execute the level setting of printable pages between toner near end and toner empty.

Purpose

Change the timing of detecting toner near end earlier than the current setting if the interval between toner near end and toner empty is too short.

Setting

- 1 Press the [Start] key.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
K	Setting the black toner level	0 to 9	3	-

If the set value is increased, the time interval from the toner near end to the toner empty becomes longer.

If the set value is reduced, the time interval from toner near end to toner empty becomes shorter.

0: no toner near end detection

- 3 Press the [Start] key to set the setting value.



Note

The setting change done during the toner low indication is not reflected.

Turn the main switch off and on to execute the setting change during the toner low indication.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U139 Temperature, humidity

(Message: Temp/Humidity)

Contents

Displays the machine inside and outside temperature and machine outside humidity.

Purpose

Check the machine inside and outside temperature and machine outside humidity.

Method

- 1 Press the [Start] key.
- 2 Select the item to check.
Displays the current temperature and humidity

Items	Contents
Ext Temp	Machine outside temperature (°C)
Ext Humidity	Machine outside humidity (%)
Int Temp	Machine inside temperature (°C)

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U140 Developer bias adjustment

(Message: Adj Dev Bias)

Contents

Displays/changes the developer bias set values.

Purpose

Execute to check/change the developer bias set values.

Method

- 1 Press the [Start] key.
- 2 Select the item to set.
- 3 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Bias	Bias setting	120 to 220	170	10
Duty	Duty setting	40 to 70	59 *2 63 *1	1
Clock	Clock setting	2600 to 3000	2700	50
Bias(Half)	Bias setting (Half speed)	120 to 220	170	10
Duty(Half)	Duty setting (Half speed)	40 to 70	65	1
Clock(Half)	Clock setting (Half speed)	2600 to 3000	2700	50

*1: 25 ppm model *2: 32 ppm model

- 4 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U147 Setting the toner applying mode

(Message: Set Toner Apply)

Contents

Mode selection for the operation to remove overcharged toner in the developer unit (Toner applying mode).

Purpose

Change the setting to reduce the toner applying amount.

Density is lowered if overcharged toner stays in the developer unit.

Method

- 1 Press the [Start] key.
- 2 Select the item to set.

Items	Contents
Mode0	Execute the toner applying operation
Mode1	Not to execute the toner applying operation

Initial setting: Mode1

- 3 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U148 Drum refresh mode setting

(Message: Set Drum Refresh)

Contents

Sets the mode to use the drum refresh in the user adjustment.

Purpose

Change the setting if the drum refresh is frequently operated.

Setting

- 1 Press the [Start] key.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Mode	Sets Auto drum refresh	0: Off 1: Short 2: Standard 3: Long	0	-

- 3 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U150 Toner sensor operation check

(Message: Chk Toner Sensor)

Contents

Displays the on/off status of each switch and sensor for toner.

Purpose

Execute to check each switch and sensor are operating correctly.

Method

- 1 Press the [Start] key.
- 2 Check the on/off status of the switch and sensor.
If "On" is detected, indication of corresponding switch and sensor is "1".

Items	Contents
Container Set	Toner container switch
Container Sensor	Toner sensor
Waste Box Sensor	Waste toner sensor
Motor	Main motor drive

To stop the operation of the motor, press the [Stop] key.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U157 Developer drive time

(Message: Dev Time)

Contents

Displays the developer drive time to be a reference for the toner density control correction.

Purpose

Execute to check the developer drive time since replacing the developer unit.

Method

- 1 Press the [Start] key.

Displays the developer drive time.

Items	Contents
K	Displays the Black developer unit drive time.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U158 Developer counter

(Message: Dev Cnt)

Contents

Displays the developer counter

Purpose

Execute to check the developer unit usage status.

Method

- 1 Press the [Start] key.

The developer count is displayed.

Items	Contents
K	Displays the black developer counter.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U161 Fuser temperature adjustment

(Message: Adj Fuser Temp)

Contents

Sets the fuser temperature.

Purpose

Normally no need to change. However, change the setting as corrective measures for paper curl, creases and fusing failure on thick paper.

Method

1 Press the [Start] key.

2 Select the item to set.

The screen for setting is displayed.

Items	Contents
Warm Up	Control temperature setting except at printing
Grain Mode	Setting the granular image control mode
Belt Mode	Fuser belt tension mode setting

Setting: Warm Up

1 Select the item to set.

2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
1st Feed(C)	Print start temperature (center): T23	50 to 185	150 *2 140 *1	1°C 1°C
Print(C)	Printing temperature (center): T25	100 to 210	165 *2 155 *1	1°C 1°C
Standby(C)	Standby temperature (center): T26	120 to 185	150 *2 140 *1	1°C 1°C
1st Feed(D)	Print start duty	0 to 100	20	1%
2nd Feed(D)	Secondary feed start duty	0 to 100	40 *2 35 *1	1% 1%

*1: 25 ppm model *2: 32 ppm model

3 Press the [Start] key to set the setting value.

Setting: Grain Mode

- 1 Select the item to set.

Items	Contents
Mode0	Present state
Mode1	Granular image reduction mode (Low) (Standby temperature: -10°C, Control temperature: -5°C)
Mode2	Granular image reduction mode (High) (Standby temperature: -20°C, Control temperature: -5°C)

Initial setting: Mode0

- 2 Press the [Start] key to set the setting value.

Setting: Belt Mode

- 1 Select the item to set.

Items	Contents
Mode0	No drive at Standby (Ready, Low Power) (Default)
Mode1	Full-speed drive for 500ms at every 10 minutes at Standby (Ready, Low Power)
Mode2	Full-speed drive for 500ms at every 3 minutes at Standby (Ready, Low Power)

Initial setting: Mode0

- 2 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U167 Clearing the fuser count

(Message: Clr Fuser Cnt)

Contents

Display/set/clear the fuser count.

Purpose

Execute to check or change the counter value after replacing the fuser unit.

Method

- 1 Press the [Start] key.

The fuser count is displayed.

Items	Contents
Cnt	Displays the fuser count
Release	Displays the fuser unit drive time (release)
Press	Displays the fuser unit drive time (press)
Clear	Clears the fuser count

Setting: Cnt / Release / Press

- 1 Select the item to set.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.
- 3 Press the [Start] key to set the setting value.

Method: Clear

- 1 Select [Clear].
- 2 Press the [Start] key.
Clears the fuser unit count

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U198 Fuser phase control setting

(Message: Set Phase Ctrl)

Contents

Switch to fixed phase control.

Purpose

Used to switch to fixed phase control.

Method

- 1 Press the [Start] key.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Mode	Fuser phase control type setting	0 to 2	0	-

- 3 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U199 Fuser temperature

(Message: Fuser Temp)

Contents

Fuser temperature is displayed.

Purpose

Execute to check the fuser temperature.

Method

- 1 Press the [Start] key.

Fuser temperature is displayed.

Items	Contents
Heat Edge1	Displays the fuser heat roller edge temperature (°C)
Heat Center	Displays the fuser heat roller center temperature (°C)

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U201 Initializing the touch panel

(Message: Init Touch Panel)

Contents

Adjusts touch panel detecting positions.

Purpose


Correct and confirm the touch panel detecting positions, when the panel PWB or the operation panel is replaced or if the detecting positions are not aligned.

When unable to press the software numeric keys due to the touch screen press position error and unable to enter the maintenance mode, press and old [Home], [Stop] and [Reset] keys 3 seconds to start up U201.

Method

- 1 Press the [Start] key.
- 2 Select the item to execute.
- 3 Press the [Start] key.

The screen for executing is displayed.



Items	Contents
Initialize	Automatically corrects the touch panel display position
Check	Checks the touch panel display position

Method: Initialize


- 1 Press the center of indicated "+".
- 2 Repeat three times.



- 3 After finishing setting, the [Check] screen is automatically displayed.

Method: Check

- 1 Press the center of indicated three "+", and then check the display position.



If out of the specified value, select [Initialize] and press the [Start] key to return to Step.1.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U203 Check DP operation

(Message: Chk DP Ope)

Contents

Simulate the original conveying operation separately in the DP.

Purpose

Check the DP operation

Method

- 1 Press the [Start] key.
- 2 Place an original in the DP if running this simulation with paper.
- 3 Select the scan speed
The screen for setting is displayed.

Items	Contents
Normal Speed	Normal scanning (600dpi)
High Speed	High speed scanning

Method: Normal Speed/High Speed

- 1 Select the item to operate.

Items	Contents
CCD ADP	With paper, a single-sided original is fed to the CCD
CCD RADP	With paper, a double-sided original is fed to the CCD

- 2 Press the [Start] key.
The operation starts.
- 3 To stop the operation, press the [Stop] key.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U207 Operation key check

(Message: Chk Panel Key)

Contents

Check the operation panel keys.

Purpose

Check the operation of all the keys and LEDs on the operation panel.

Method

- 1 Press the [Start] key to display execution window.
- 2 [Count 0] appears and the LED at the most left column in the operation panel is turned on.
- 3 Pressing the keys in order from the top at the row where the LED is lit, count increases one by one. When pressing all the keys at the row and there is an LED at the next right side row, the LED is lit.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U222 Setting the IC card type

(Message: Set IC Card Type)

Contents

Sets the ID card type

Purpose

Change the type of ID card

Setting

- 1 Press the [Start] key.
- 2 Select the item to set.

Items	Contents
Other	Select when the ID card type is other than SSFC.
SSFC	Select when the ID card type is SSFC.

Initial setting: Other

- 3 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U230 Optional device serial number

(Message: Device Serial No)

Contents

Displays the optional device serial number

Purpose

Specify the production lot from the serial number to make it help of investigation at problem occurrence.

Method

- 1 Press the [Start] key.

Displays the serial number.

Items	Contents
PF1	Displays the paper feeder 1 serial number.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U243 Checking the DP motor

(Message: Chk DP Motor)

Contents

Drive the motor or solenoid of the document processor.

Purpose

Check the operation of the motor or solenoid of the document processor.

Method

- 1 Press the [Start] key.
- 2 Select the item to operate.

Items	Contents
Feed Motor	Drive the DP feed motor
Conv Motor	Drive DP conveying motor.
Rev Motor	Drive DP feed-shift motor.
Regist clutch	Drive DP registration clutch.

- 3 Press the [Start] key. Each operation starts.
To stop the operation, press the [Stop] key.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U244 DP switch check

(Message: Chk DP Switch)

Contents

Displays each switch and sensor status of the document processor.

Purpose

Execute to check the operation of switches and sensors of the document processor.

Method

- 1 Press the [Start] key.
- 2 Check the switches and sensors by manually turning them on/off.

The switch indication is inverted when the switch is detected.

Items	Contents
Feed	Check DP feed sensor.
Regist	Check DP registration sensor.
Timing	Check DP timing sensor.
Set	Check DP original sensor.
Longitudinal	Check DP original length sensor.
Cover Open	Check DP top cover switch.
Open	Check the DP open/close switch

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U250 Maintenance counter preset

(Message: Mnt Cnt Pre-set)

Contents

Changes the pre-set values for the maintenance cycle and automatic grayscale adjustment.

Purpose

Change the timing to display the message for maintenance and automatic grayscale adjustment

Setting

- 1 Press the [Start] key.
- 2 Select the item to set.
- 3 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
M.Cnt A	Changes the maintenance counter (Kit A)	0 to 9999999	300000	-
M.Cnt HT	Change the maintenance counter preset value (HT adjustment)	0 to 9999999	0	-
Cass1	Change the maintenance counter preset value (Cassette 1)	0 to 9999999	300000	-
Cass2	Change the maintenance counter preset value (Cassette 2)	0 to 9999999	300000	-
Cass3	Change the maintenance counter preset value (Cassette 3)	0 to 9999999	300000	-

- 4 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U251 Maintenance counter clear

(Message: Clr Mnt Cnt)

Contents

Displays, clears or changes the maintenance count.

Purpose

Execute to check the maintenance count

Also, clear the count at the maintenance.

Setting

- 1 Press the [Start] key.
- 2 Select the item to set.
- 3 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
M.Cnt A	Maintenance cycle counter (Kit A)	0 to 9999999	0	-
M.Cnt HT	Maintenance cycle counter (HT adjustment)	0 to 9999999	0	-
Cass1	Maintenance cycle counter value (cassette 1)	0 to 9999999	0	-
Cass2	Maintenance cycle counter value (cassette 2)	0 to 9999999	0	-
Cass3	Maintenance cycle counter value (cassette 3)	0 to 9999999	0	-
Clear	Clears all the maintenance counts	0	0	-

Clearing

- 1 Select [Clear].
- 2 Press the [Start] key to clear the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U252 Destination

(Message: Set Dest)

Contents

Switch the operations and screens of the main unit according to the destination.

Purpose

Execute after initializing the backup RAM, in order to return the setting to the value before replacement or initialization

Method

- 1 Press the [Start] key.
- 2 Select the item to set.

Items	Contents
Japan Metric *1	Japan metric
Inch *2	Inch
Europe Metric *2	Europe Metric
Asia Pacific *2	Asia Pacific
Australia *2	Australia
China *2	China
Korea *2	Korea

*1: 100 V model only, *2: Except 100 V model

Initial setting: Destination

- 3 Press the [Start] key.
Initializes according to the destination
- 4 Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

U253 Double/single count switch

(Message: Set D/S Count)

Contents

Switches the count timing for the total counter and other counters by color mode.

Purpose

Select, according to user's request (copy service provider), if the maximum size paper is to be counted as one sheet (single count) or two sheets (double count)

Setting

- 1 Press the [Start] key.
- 2 Select [B/W].

Items	Contents
B/W	Switch the counter for B/W mode (Single/Double Count)

- 3 Select [SGL] or [DBL].

Items	Contents
SGL(All)	Set single count for all the paper sizes
DBL(A3/Ledger)	Set single count for A3(420mm) size or smaller
DBL(B4)	Set single count for Legal(356mm) size or smaller
DBL(Folio)	Set double count for Folio size or larger *2

Initial setting: SGL(All) (100V model), DBL(A3/Ledger) (120V/220-240V model)

*2: The Folio length can be set to between 330 and 356 mm using maintenance mode U035. However, the double count will be applied when the set value is 330mm (Initial value) or longer.

- 4 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U260 Feed/eject counter switch

(Message: Set Count Mode)

Contents

Switches the count timing for the total counter and other counters between paper feed and eject.

Purpose

Change the count timing according to the user's request

Setting

- 1 Press the [Start] key.
- 2 Selects the copy count timing.

Items	Contents
Feed	When secondary feed starts.
Eject	Selects the paper eject timing

Initial setting: Eject

- 3 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U265 Setting by destination

(Message: Set Model Dest)

Contents

Sets the OEM code.

Purpose

Execute when replacing the main PWB, etc.

Setting

- 1 Press the [Start] key.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Contents
No.	Displays the OEM code

- 3 Press the [Start] key to set the setting value.
- 4 Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U278 Delivery date setting

(Message: Set Delivery Date)

Contents

Registers the date of delivery of the machine.

Purpose

Execute when installing the machine. Execute to check the delivery date of the machine.

Method

- 1 Press the [Start] key.
- 2 Select [Today].
- 3 Press the [Start] key.
Sets the delivery date of the machine.

Clearing

- 1 Select [Clear].
- 2 Press the [Start] key.
Clears the delivery date of the machine.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U285 Set Service Status Page

(Message: Set Svc Sts Page)

Contents

Determines whether to display the digital dot coverage report on the report print.

Purpose

Change the setting according to the user's request

Setting

- 1 Press the [Start] key.
- 2 Select the item to set.

Items	Contents
On	Displays the digital dot coverage.
Off	Not to display the digital dot coverage.

Initial setting: On

- 3 Press the [Start] key. Set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U287 Automatic recovery function

(Message: Set Reset Func)

Contents

Sets whether to enable the automatic recovery function after the service call error

Purpose

Sets whether to enable the automatic recovery function after the service call error or system error

Setting

- 1 Press the [Start] key.
- 2 Select the item to set.
- 3 By using the[<] [>] keys change the setting value.

Items	Contents	Setting range	Initial setting
C0XXX	Sets whether to enable the automatic recovery function after the service call error	On/Off	Off
C1XXX	Sets whether to enable the automatic recovery function after the C1xxx code service call error	On/Off	Off
C2XXX	Sets whether to enable the automatic recovery function after the C2xxx code service call error	On/Off	Off
C3XXX	Sets whether to enable the automatic recovery function after the C3xxx code service call error	On/Off	Off
C4XXX	Sets whether to enable the automatic recovery function after the C4xxx code service call error	On/Off	Off
C5XXX	Sets whether to enable the automatic recovery function after the C5xxx code service call error	On/Off	Off
C6XXX	Sets whether to enable the automatic recovery function after the C6xxx code service call error	On/Off	Off
C7XXX	Sets whether to enable the automatic recovery function after the C7xxx code service call error	On/Off	Off
C8XXX	Sets whether to enable the automatic recovery function after the C8xxx code service call error	On/Off	Off
C9XXX	Sets whether to enable the automatic recovery function after the C9xxx code service call error	On/Off	Off
CFXXX	Sets whether to enable the automatic recovery function after the CF code service call error	On/Off	On

- 4 Press the [Start] key. Set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U290 Application storage drive setting

(Message: Set Drive App)

Contents

Set the HyPAS application storage drive.

Purpose

Set to save in the SD card or optional SSD.

Setting

- 1 Press the [Start] key.
- 2 Select the item to set.

Items	Contents
SD Card	Set to the SD card.
SSD	Set to the SSD card.

- 3 Press the [Start] key. Set the setting value.
- 4 Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U326 Black line cleaning display setting

(Message: Set Clean Bk Line)

Contents

Sets whether to indicate the black lines cleaning guidance when detecting black lines.

Purpose

Displays the cleaning guidance to reduce the service call with the black lines by dust on the contact glass when scanning from the document processor.

Method

1 Press the [Start] key.

2 Select the item to set.

The screen for setting is displayed.

Items	Contents
Black Line Mode	Sets On/Off of the black line cleaning guidance indication

Settin: Black Line Mode

1 Select the item to set.

Items	Contents
On	Indicate the black lines cleaning guidance
Off	Black line cleaning guidance is not indicated

Initial setting: On

2 Press the [Start] key. Set the setting value.

Completion

1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U332 Adjusting the black coverage coefficient

(Message: Adj Calc Rate)

Contents

Sets the coefficient of custom size with A4/Letter size. The coefficient set here is used to convert the black ratio in relation to the A4/Letter size and to display the result in the service status page.

Purpose

Set the coefficient for converting the black ratio for custom sizes in relation to the A4/Letter size

Setting

- 1 Press the [Start] key.
- 2 Select the item to set.
- 3 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Rate	Set the coefficient for converting the black ratio for custom sizes in relation to the A4/Letter size.	0.1 to 3.0	1.0	- -

- 4 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U341 Printer cassette setting

(Message: Set Prn Cass)

Contents

Sets the cassette to printer output only.

Purpose

Execute it when securing a cassette for printer. The cassette set to on is for printer only and it cannot be used for copy.

Setting

1 Press the [Start] key.

2 Select the item to set.

Multiple cassettes are selectable.

Items	Contents
Cass1	Setting cassette 1 to the printer paper source
Cass2	Setting cassette 2 to the printer paper source (paper feeder)
Cass3	Setting cassette 3 to the printer paper source (paper feeder)

Initial setting: Off (Cassette1 to 3)

3 Press the [Start] key to set the setting value.

Completion

1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U343 Duplex priority mode setting

(Message: Set Dup Pri Mode)

Contents

Switches between duplex or simplex copy for the initial copy mode.

Purpose

Set the frequently used settings depending on the user's usage.

Setting

- 1 Press the [Start] key.

Select the item to set.

Items	Contents
On	Duplex print priority is enabled
Off	Duplex print priority is disabled

Initial setting: Off

- 2 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U345 Maintenance timing pre-caution setting

(Message: Set Mnt Time Disp)

Contents

Sets when to display a message notifying that the time for maintenance is about to reach, by setting the number of prints that can be made before the current maintenance cycle reaches.

Displays the maintenance precaution message when the page count reaches the set value before the maintenance count.

Purpose

Change the time for maintenance precaution display.

Setting

- 1 Press the [Start] key.
- 2 Select the item to set.
- 3 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Cnt	Setting the maintenance time precaution display (Remaining number of prints that can be made before the current maintenance cycle reaches)	0 to 9999	0	-

- 4 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U346 Selecting Sleep Mode

(Message: Slct Sleep Mode)

Contents

Changes the sleep mode settings.

Purpose

Changes the sleep mode settings.

Method

- 1 Press the [Start] key.
- 2 Select the item to set.
The screen for setting is displayed.

Items	Contents
Timer/Sleep Level	BAM conformity country setting
Auto sleep	Switches AutoSleep function setting

Setting: Timer/Sleep Level

- 1 Select the item to set.

Items	Contents
More Energy Save	1: BAM conformity setting On Sleep mode is disabled (Quick Recovery setting is disabled)
Less Energy Save	0: BAM conformity setting Off Sets Sleep Level (Quick Recovery or Energy Saver)

Initial setting: More Energy Save (0)

- 2 Press the [Start] key. Set the setting value.
- 3 Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Setting: Auto sleep

- 1 Select the item to set.

Items	Contents
On	Enable auto sleep function.
Off	Disable auto sleep function.

Initial setting: On

If it is set to Off, sleep shift operation will not be performed even if sleep mode is set in the system menu.

Peel off the energy saver label when setting it to off

- 2 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U402 Print margin adjustment

(Message: Print Margin)

Contents

Adjusts the scan image margins.

Purpose

Make the adjustment if margins are incorrect

If the leading edge margin is less than the specified value, it may cause jam at the fuser.

If there is no bottom margin, when continuously printing, it may cause an image smudge on the second page.

Adjustment

- 1 Press the [Start] key.
- 2 Press the [System Menu/Counter] key .

Note


Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Source/Conveying speed/Duplex/Color/Copies)

- 3 Press the [Start] key to output a test pattern.
- 4 Press the [System Menu/Counter] key .
- 5 Select the item to set.

Items	Description	Setting range	Initial setting	Data variation
Lead	Adjusts the printer leading edge margin	0.0 to 10.0	4.0	0.1 (mm)
A Margin	Printer left margin	0.0 to 10.0	3.0	0.1 (mm)
C Margin	Printer right margin	0.0 to 10.0	3.0	0.1 (mm)
Trail	Printer trailing edge margin	0.0 to 10.0	3.9	0.1 (mm)

- 6 By using the [<] [>] keys or the numeric keys, change the setting value.

When the setting value is increased, the margin widens, and it narrows when the setting value is decreased.



- 7 Press the [Start] key to set the setting value.

Important

Appropriate margins are not obtained after this adjustment, execute the following maintenance mode.

U034([P.6-36](#)) > U402

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U403 Scanning margin adjustment (table)

(Message: Scan Margin Tbl)

Contents

Adjusts the margins for the table scanning.

Purpose

Make the adjustment if margins are incorrect

Adjustment

- 1 Press the [Start] key.
- 2 Press the [System Menu/Counter] key .


Note

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Source/Conveying speed/Duplex/Orientation/Color/Copies)

- 3 Place an original and press the [Start] key to make a test copy.
- 4 Press the [System Menu/Counter] key .
- 5 Select the item to adjust.

Items	Description	Setting range	Initial setting	Data variation
A Margin	Adjusts the scanner left margin	0.0 to 10.0	2.0	0.5(mm)
B Margin	Adjusts the scanner leading edge margin.	0.0 to 10.0	2.0	0.5(mm)
C Margin	Adjusts the scanner right margin	0.0 to 10.0	2.0	0.5(mm)
D Margin	Adjusts the scanner trailing edge margin	0.0 to 10.0	2.0	0.5(mm)

- 6 By using the [<] [>] keys or the numeric keys, change the setting value.
When the setting value is increased, the margin widens, and it narrows when the setting value is decreased.



- 7 Press the [Start] key to set the setting value.

Important

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034([P. 6-36](#)) > U402([P. 6-108](#)) > U403

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U404 Scanning margin adjustment (DP)

(Message: Scan Margin DP)

Contents

Adjusts the margins for DP scanning.

Purpose

Make the adjustment if margins are incorrect

Adjustment

- 1 Press the [Start] key.
- 2 Press the [System Menu/Counter] key .


Note

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Source/Conveying speed/Duplex/Orientation/Color/Copies)

- 3 Place an original on the DP and press the [Start] key to make a test copy.
- 4 Press the [System Menu/Counter] key .
- 5 Select the item to adjust.

Items	Description	Setting range	Initial setting	Data variation
A Margin	Adjusts the DP left margin	0.0 to 10.0	3.0	0.5(mm)
B Margin	Adjusts the DP leading edge margin	0.0 to 10.0	2.5	0.5(mm)
C Margin	Sets the DP right margin	0.0 to 10.0	3.0	0.5(mm)
D Margin	Adjusts the DP trailing edge margin	0.0 to 10.0	4.0	0.5(mm)

- 6 By using the [<] [>] keys or the numeric keys, change the setting value.
When the setting value is increased, the margin widens, and it narrows when the setting value is decreased.



- 7 Press the [Start] key to set the setting value.

Important

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034([P. 6-36](#)) > U402([P. 6-108](#)) > U403([P. 6-110](#)) > U404

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U407 Adjusting the writing timing (Reversal)

(Message: WR DR Timing)

Contents

Adjusts the writing timing in rotated 180 degrees.

Purpose

Adjusted when the page image of copying is printed in rotated 180 degrees from the scanner reading image (image on the memory)

Important

Adjust this after finishing the following maintenance modes.

U034(P. 6-36)> U402(P. 6-108)> U066(P. 6-47)> U403(P. 6-110)> U071(P. 6-53)> U404(P. 6-112)> U407

Adjustment

- 1 Press the [Start] key.
- 2 Press the [System Menu/Counter] key .

Note

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings.
(Source/Conveying speed/Duplex/Orientation/Color/Copies)


- 3 Place an original on the DP and press the [Start] key to make a test copy.
- 4 Press the [System Menu/Counter] key .
- 5 Select [Adj Data].

Items	Description	Setting range	Initial setting	Data variation
Adj Data	Adjusts the leading edge timing when writing the image in the memory	-47 to 47	0	1dot

- 6 By using the [<] [>] keys or the numeric keys, change the setting value.
 - For the copy example 1, increase the value.
 - For the copy example 2, decrease the value.

When the setting value is increased, the image moves forward, and it moves backward when the setting value is decreased.

Leading edge registration of the copy image (+1.0/-1.5 mm)



- 7 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U410 Adjusting the halftone automatically

(Message: Adj Half Tone)

Contents


Acquires the data for the automatic halftone adjustment and ID correction.

Purpose

Execute when the quality of reproduced halftones has dropped

Adjustment

- 1 Press the [Start] key.
Displays the execution information screen.
A test pattern is output on A4 paper.
- 2 Set the output test pattern as original, in the back side which the direction of the arrow is, looking down the side which is printing to the original glass.
Load about 20 sheets of the blank paper on Test Pattern 1.



- 3 Press the [Start] key.
The auto adjustment is executed.
- 4 [Finish] appears after normal completion.
- 5 An error code appears when an error occurs.

Error codes

Codes	Occurrence position	Contents	Re-adjustment
S001	Scanner	Original type error	Enable
S002		Original reference patch is not detected	Enable
S003		Original deviation is in excess in the main scanning direction	Enable
S004		Original deviation is in excess in the sub-scanning direction	Enable
S005		Original skew is in excess	Enable
S006		Other scanner error	Enable

Codes	Occurrence position	Contents	Re-adjustment
E001	Enginee	Enginee status error	Disable
E002		Enginee sensor error	Disable
E003		The Enginee is driving.	Enable
C101	Controller	Pause status	Disable
C102		Adjustment result error	Disable
C1FF		Other controller error	Disable
C200		Table adjustment value error	Disable
C300		Simple increment adjustment value error	Disable

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U411 Scanner auto adjustment

(Message: Auto Adj Scn)

Contents



Uses the specified originals and automatically adjusts the following items in the scanner and the DP scanning sections.

Scanner section: Original size magnification, leading edge timing, center line, chromatic aberration in main/sub scanning direction, MTF correction, color/monochrome input gamma, color correction matrix automatic adjustment

DP scanning section: Original size magnification, leading edge timing and center line, MTF correction, Input gamma, automatic adjustment of color correction matrix

Purpose

Automatically adjusts the scanner and the DP scanning sections.

Items	Use	Contents	Original for adjustment (P/N)
Table (Chart A)	In case of losing adjustment data, differing from the color tone extremely (not improve in case of executing U410) When replacing ISU(CCD unit), Optical LED lamp and Engine EEPROM. Use when setting up DP or executing U021 initialization	Execute automatic adjusts the table scanning. LED light intensity Scan timing White reference correction factor Chromatic aberration correction filter in the main scanning direction *3 Input gamma correction coefficient Color correction matrix factor	7505000005 
DP FU(ChartA)	Use when setting up DP or executing U021 initialization	Execute the 1st side automatic adjustment in the DP scanning section. White reference correction factor	
DP FU(ChartB)		Execute the 1st side automatic adjustment in the DP scanning section. Magnification in the sub-scanning direction Leading edge timing Center line Trailing edge timing	302AC68243 
Target		Set-up for obtaining the target value	7505000005
Debug *1		Adjusting the document processor scanning section with the chart output by the local machine Magnification in the sub-scanning direction Leading edge timing Center line Trailing edge timing	Without Chart B, executed in a simplified manner.

*1: Only when USB is installed

Method: Table (Chart A)

Automatic input of the target value

Usually, it adjusts here.

- 1 Set the specified original (P/N: 7505000005) on the table.
- 2 Enter maintenance item U411.
- 3 Select [Target].
- 4 Select [Auto].
- 5 Press the [Start] key.
- 6 Select [Table(ChartA)].
- 7 Press the [Start] key to read the barcode of the original chart and to start the automatic adjustment.
- 8 When automatic adjustment has normally completed, [OK] is displayed.
When the error code "1e" or "1f" is displayed during the automatic adjustment in the table scanning and the barcode is not read, adjust the following after manually inputting the target value.

Manual input of the target value

- 1 Enter the target values which are shown on the lower part of the front page of the adjustment original (P/N: 7505000005) by executing the maintenance mode U425.
- 2 Set the specified original (P/N: 7505000005) on the table.
- 3 Enter maintenance item U411.
- 4 Select [Target].
- 5 Select [U425].
- 6 Press the [Start] key.
- 7 Select [Table(ChartA)].
- 8 Press the [Start] key to start Auto adjustment.
- 9 When automatic adjustment has normally completed, [OK] is displayed.
If the image position is shifted largely at the DP adjustment below, an error might occur when adjusting it with ChartA. First, use ChartB (image position) to adjust it and then use ChartA (color).

Method: DP FU (Chart A)**Automatic input of the target value**

- 1 Set the specified original (P/N: 7505000005) face-up on the DP.
- 2 Enter maintenance item U411.
- 3 Select [Target].
- 4 Select [Auto].
- 5 Press the [Start] key.
- 6 Select [DP FU(ChartA)].
- 7 Press the [Start] key to read the barcode of the original chart and to start the automatic adjustment.
- 8 When automatic adjustment has normally completed, [OK] is displayed.
When the error code "1e" or "1f" is displayed during the automatic adjustment in the DP scanning and the barcode is not read, adjust the following after manually inputting the target value.

Manual input of the target value

- 1 Enter the target values which are shown on the lower part of the front page of the adjustment original (P/N: 7505000005) by executing the maintenance mode U425.
- 2 Set the specified original (P/N: 7505000005) face-up on the DP.
- 3 Enter maintenance item U411.
- 4 Select [Target].
- 5 Select [U425].
- 6 Press the [Start] key.
- 7 Select [DP FU(ChartA)].
- 8 Press the [Start] key to start Auto adjustment.
- 9 When automatic adjustment has normally completed, [OK] is displayed.

Method: DP FU (Chart B)

Adjusting the first side of the DP duplex scanning

- 1 Set the specified original (P/N: 302AC68243) face-up on the DP.
- 2 Enter maintenance item U411.
- 3 Select [DP FU(ChartB)].
- 4 Press the [Start] key to start Auto adjustment.
- 5 When automatic adjustment has normally completed, [OK] is displayed.
If an error occurs during auto adjustment, error code "NGXX" is displayed and operation stops. In this case, check the error and execute the automatic adjustment again.

Error codes

Codes	Contents	Corrective action
00	Automatic adjustment success	-
01	Black band detection error (Table scanning leading edge skew in the sub-scanning direction)	Set the original correctly and execute the adjustment again. Check lighting of the lamp or replace it.
04	Black band is not detected (Table leading edge in the sub-scanning direction)	
05	Black band is not detected (Table far end in the main scanning direction)	
06	Black band is not detected (Table near end in the main scanning direction)	
07	Black band is not detected (Table trailing edge in the sub-scanning direction)	
08	Black band is not detected (DP far end in the main scanning direction)	Check the attachment position of DP. Check lighting of the lamp or replace it.
09	Black band is not detected (DP near end in the main scanning direction)	Check the back and front of the adjustment original.
0a	Black band is not detected (DP leading edge in the sub-scanning direction)	
0b	Black band is not detected (Original check of DP leading edge in the sub-scanning direction)	
0c	Black band is not detected (DP trailing edge in the sub-scanning direction)	
0d	White band is not detected (DP trailing edge in the sub-scanning direction)	
0e	DMA time out	Turn the power switch off then on, and execute again.
0f	Magnification error in the sub-scanning direction	Turn the power switch off then on, and execute again.
10	Leading edge error in the sub-scanning direction	Adjust manually.
11	Trailing edge error in the sub-scanning direction	(U065 to U067, U070 to U072)
12	DP skew error in the sub-scanning direction	
13	Maintenance request error	Turn the power switch off then on, and execute again.
14	Center line error in the main scanning direction	Turn the power off and on, and execute again.
15	DP skew error in the main scanning direction	Adjust manually.
16	Magnification error in the main scanning direction	(U065 to U067, U070 to U072)
17	Service call error	Turn the power off and on, and execute again.
18	DP paper jam error	Set the original correctly and execute again.
19	PWB replacement error	-
1a	Original error	Clean the contact glass and slit glass. Exchange the adjustment original.

Codes	Contents	Corrective action
1b	Input gamma adjustment original error	Set the original correctly and execute again.
1c	Matrix adjustment original error	
1d	Original for the white reference correction coefficient error	
1e	Lab value detection error	Check the following and execute again. Is the bar code dirty? Is the original position correct? Is the bar code position correct?
1f	Lab value comparison error	Check the following and execute again. Is the acquired bar code the same? Is the original position correct? Is the bar code position correct?
20	Input gamma correction coefficient error	Set the original correctly and execute again.
21	Color correction matrix coefficient error	
30	Chromatic aberration adjustment original error	
40	Black dot detection error at the linearity correction (Point A)	Set the original correctly and execute again. Check if the lamp lights. If the lamp does not light, it is a defect.
41	Black dot detection error at the linearity correction (Point B)	
42	Black dot detection error at the linearity correction (Point C)	
43	Black dot detection error at the linearity correction (Point D)	
44	Black dot detection error at the linearity correction (Point E)	
45	Black dot detection error at the linearity correction (Point F)	
46	Black dot detection error at the linearity correction (Point G)	
47	Black dot detection error at the linearity correction (Point H)	
48	Black dot detection error at the linearity correction (Point I)	
49	Black dot detection error at the linearity correction (Point J)	
4a	Black dot detection error at the linearity correction (Point K)	
4b	Black dot detection error at the linearity correction (Point L)	
4c	Black dot detection error at the linearity correction (Point M)	
4d	Black dot detection error at the linearity correction (Point N)	
4e	Black dot detection error at the linearity correction (Point O)	
4f	Black dot detection error at the linearity correction (Point P)	

Codes	Contents	Corrective action
50	White reference plate correction ratio error.	Set the original correctly and execute again. If not cleared, it is the failure with an input data error.
99	Completed to obtain the test RAW	-

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U425 Target adjustment

(Message: Set Target)

Contents

Enter the Lab values which are shown on the back page of the adjustment original (P/N: 7505000005).

Purpose

Enter data in order to correct for differences in originals during the automatic adjustment

Method

- 1 Press the [Start] key.
- 2 Select the item to set.

Items	Contents
ChartA	Setting the adjustment value of the table scanning
ChartB	Sets the adjustment value of the DP scanning

Method: ChartA

- 1 Press the [Start] key.
- 2 Select the item to set.

Items	Contents
White	Setting the white patch for the adjustment original
Black	Setting the black patch for the adjustment original
Gray1	Setting the Gray1 patch for the adjustment original
Gray2	Setting the Gray2 patch for the adjustment original
Gray3	Setting the Gray3 patch for the adjustment original
C	Setting the cyan patch for the adjustment original
M	Setting the magenta patch for the adjustment original
Y	Setting the yellow patch for the adjustment original
R	Setting the red patch for the adjustment original
G	Setting the green patch for the adjustment original
B	Setting the blue patch for the adjustment original
Adjust Original	Setting the main scanning and sub-scanning directions

Setting: White

- 1 Select the item to set.
- 2 By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

Items	Description	Setting range	Initial setting	Data variation
L	L parameter setting	0.0 to 100	93.6	-
a	A value setting	-200 to 200	0.9	-
b	B value setting	-200 to 200	-0.4	-

- 3 Press the [Start] key to set the setting value.

Setting: Black

- 1 Select the item to set.
- 2 By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

Items	Description	Setting range	Initial setting	Data variation
L	L parameter setting	0.0 to 100	10.6	-
a	A value setting	-200 to 200	-0.2	-
b	B value setting	-200 to 200	-0.7	-

- 3 Press the [Start] key to set the setting value.

Setting: Gray1

- 1 Select the item to set.
- 2 By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

Items	Description	Setting range	Initial setting	Data variation
L	L parameter setting	0.0 to 100	76.2	-
a	A value setting	-200 to 200	-0.2	-
b	B value setting	-200 to 200	1.2	-

- 3 Press the [Start] key to set the setting value.

Setting: Gray2

- 1 Select the item to set.
- 2 By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

Items	Description	Setting range	Initial setting	Data variation
L	L parameter setting	0.0 to 100	25.2	-
a	A value setting	-200 to 200	-0.2	-
b	B value setting	-200 to 200	-0.2	-

- 3 Press the [Start] key to set the setting value.

Setting: Gray3

- 1 Select the item to set.
- 2 By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

Items	Description	Setting range	Initial setting	Data variation
L	L parameter setting	0.0 to 100	51.3	-

Items	Description	Setting range	Initial setting	Data variation
a	A value setting	-200 to 200	-0.3	-
b	B value setting	-200 to 200	-0.3	-

3 Press the [Start] key to set the setting value.

Setting: C

1 Select the item to set.

2 By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

Items	Description	Setting range	Initial setting	Data variation
L	L parameter setting	0.0 to 100	72.6	-
a	A value setting	-200 to 200	-32.8	-
b	B value setting	-200 to 200	-11.5	-

3 Press the [Start] key to set the setting value.

Setting: M

1 Select the item to set.

2 By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

Items	Description	Setting range	Initial setting	Data variation
L	L parameter setting	0.0 to 100	48.1	-
a	A value setting	-200 to 200	69.9	-
b	B value setting	-200 to 200	-6.1	-

3 Press the [Start] key to set the setting value.

Setting: Y

1 Select the item to set.

2 By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

Items	Description	Setting range	Initial setting	Data variation
L	L parameter setting	0.0 to 100	86.2	-
a	A value setting	-200 to 200	-18.6	-
b	B value setting	-200 to 200	81.7	-

3 Press the [Start] key to set the setting value.

Setting: R

- 1 Select the item to set.
- 2 By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

Items	Description	Setting range	Initial setting	Data variation
L	L parameter setting	0.0 to 100	46.7	-
a	A value setting	-200 to 200	54.2	-
b	B value setting	-200 to 200	38.6	-

- 3 Press the [Start] key to set the setting value.

Setting: G

- 1 Select the item to set.
- 2 By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

Items	Description	Setting range	Initial setting	Data variation
L	L parameter setting	0.0 to 100	67.8	-
a	A value setting	-200 to 200	-51.3	-
b	B value setting	-200 to 200	48.9	-

- 3 Press the [Start] key to set the setting value.

Setting: B

- 1 Select the item to set.
- 2 By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

Items	Description	Setting range	Initial setting	Data variation
L	L parameter setting	0.0 to 100	38.8	-
a	A value setting	-200 to 200	25.3	-
b	B value setting	-200 to 200	-22.8	-

- 3 Press the [Start] key to set the setting value.

Setting: Adjust Original

This setting is usually unnecessary.

Items	Description	Setting range	Initial setting	Data variation
Lead	Set the adjustment value of the leading edge.	4.0 to 6.0	5.0	0.1mm
Main Scan	Sets the adjustment value of the left edge.	9.0 to 11.0	10.0	0.1mm
Sub Scan	Set the adjustment value of the trailing edge.	189.0 to 191.0	190.0	0.1mm

- 1 Measure the distances "A", "B" and "C" from the upper edge of black belt 1 to the lower edge of black belt 3 of the adjustment original.

Measurement procedure


- Measure the distance "A", "B" and "C" between two points as follows. (A: 30mm from the left edge, B: 105mm from the left edge, C: 180mm from the left edge) Measure the distance from the leading edge to the top edge of black belt 1.
 - Apply the following formula for the values obtained: $((A+B+C)/3)$
- 2 Enter the value solved in "Lead" using the the [+] [-] keys keys.
 - 3 Press the [Start] key to set the setting value.
 - 4 Measure the distance "F" from the left edge to the right edge of black belt 2 on the adjustment original.

Measurement procedure

- Measure the distance "F" from the left edge at 21mm from the top edge of black belt 1 to the right edge of black belt 2.
- 5 Enter the values measured in "Main Scan" using the the [+] [-] keys keys.
 - 6 Press the [Start] key to set the setting value.
 - 7 Measure the distance "D" and "E" from the top edge of black belt 1 to the bottom edge of black belt 3 on the adjustment original at two positions.

Measurement procedure

- Measure the distance "D" and "E" between two points as follows. (D: Measure the distance from the leading edge to the trailing edge of black belt 3 on the adjustment original at 30mm of the left edge and deduct A. E: Measure the distance from the leading edge to the trailing edge of black belt 3 on the adjustment original at 180mm of the left edge and deduct C.)
 - Apply the following formula for the values obtained: $(D/2+E/2)$
- 8 Enter the value solved in "Sub Scan" using the the [+] [-] keys keys.
 - 9 Press the [Start] key to set the setting value.




Setting: DP(ChartB)

This setting is usually unnecessary.

Items	Description	Setting range	Initial setting	Data variation
Lead	Set the adjustment value of the leading edge.	14.0 to 16.0	15.0	0.1mm
Main Scan	Sets the adjustment value of the left edge.	14.0 to 16.0	15.0	0.1mm
Sub Scan	Set the adjustment value of the trailing edge.	388.0 to 392.0	390.0	0.1mm

- 1 Measure the distance "A" from the leading edge to the black belt (inside) on the adjustment original.
- 2 Enter the value measured in "Lead" using the the [+] [-] keys keys.
- 3 Measure the distance "B" from the left edge to the black belt (inside) on the adjustment original.
- 4 Enter the values measured in "Main Scan" using the the [+] [-] keys keys.
- 5 Measure the distance "C" from the leading black belt (inside) to the trailing black belt (inside) on the adjustment original.
- 6 Enter the values measured in "Sub Scan" using the the [+] [-] keys keys.
- 7 Press the [Start] key to set the setting value.

**Completion**

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U470 Setting the JPEG compression rate

(Message: Adj JPEG Rate)

Contents

Sets the JPEG compression rate by image mode.

Purpose

Change the setting depending on the image desired by the user. Lower the set value to reduce the image roughness by changing the compression rate in case of 200% or more of the enlarged copy . If the set value is reduced, compression is high and image quality is lowered. If the set value is increased, image quality is improved but processing speed is slower.

Method

1 Press the [Start] key.

2 Select the item to set.

The screen for setting is displayed.

Items	Contents
Copy	Compression rate of the copy
Send	Compression rate of the Send
System	Compression rate of the temporary saving in the system

Method: Copy

1 Select the item to set.

The screen for setting is displayed.

Items	Contents
Photo	Compression rate of the photo mode
Text	Compression rate of the text mode

Setting: Photo

1 Select the item to set.

2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Luminance	Compression rate of the brightness	4 to 10	10	1%
Chrominance	Compression rate of the color difference	4 to 10	10	1%

3 Press the [Start] key to set the setting value.

Setting: Text

1 Select the item to set.

2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Luminance	Compression rate of the brightness	4 to 10	10	1%
Chrominance	Compression rate of the color difference	4 to 10	10	1%

- 3 Press the [Start] key to set the setting value.

Method: Send

- 1 Select the item to set.

The screen for setting is displayed.

Items	Contents
Photo	Compression rate of the photo mode
Text	Compression rate of the text mode
HC-PDF(BG)	Sets the compression rate for high compression PDF
HC-PDF(Char)	Set the compression rate for High compression PDF (text color).
HC-PDF(File Size)	Set the compression rate for High compression PDF (compression priority).

Setting: Photo

- 1 Select the item to set.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Y1	Compression rate of the brightness	1 to 100	30	1%
Y2	Compression rate of the brightness	1 to 100	40	1%
Y3	Compression rate of the brightness	1 to 100	51	1%
Y4	Compression rate of the brightness	1 to 100	70	1%
Y5	Compression rate of the brightness	1 to 100	90	1%
CbCr1	Compression rate of the color difference	1 to 100	30	1%
CbCr2	Compression rate of the color difference	1 to 100	40	1%
CbCr3	Compression rate of the color difference	1 to 100	51	1%
CbCr4	Compression rate of the color difference	1 to 100	70	1%
CbCr5	Compression rate of the color difference	1 to 100	90	1%

- 3 Press the [Start] key to set the setting value.

Setting: Text

- 1 Select the item to set.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Y1	Compression rate of the brightness	1 to 100	30	1%
Y2	Compression rate of the brightness	1 to 100	40	1%
Y3	Compression rate of the brightness	1 to 100	51	1%
Y4	Compression rate of the brightness	1 to 100	70	1%
Y5	Compression rate of the brightness	1 to 100	90	1%
CbCr1	Compression rate of the color difference	1 to 100	30	1%

Items	Description	Setting range	Initial setting	Data variation
CbCr2	Compression rate of the color difference	1 to 100	40	1%
CbCr3	Compression rate of the color difference	1 to 100	51	1%
CbCr4	Compression rate of the color difference	1 to 100	70	1%
CbCr5	Compression rate of the color difference	1 to 100	90	1%

3 Press the [Start] key to set the setting value.

Setting: HC-PDF(BG)

1 Select the item to set.

2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Y1	Compression rate of the brightness	1 to 100	15	1%
Y2	Compression rate of the brightness	1 to 100	25	1%
Y3	Compression rate of the brightness	1 to 100	90	1%
CbCr1	Compression rate of the color difference	1 to 100	15	1%
CbCr2	Compression rate of the color difference	1 to 100	25	1%
CbCr3	Compression rate of the color difference	1 to 100	90	1%

3 Press the [Start] key to set the setting value.

Setting: HC-PDF(Char)

1 Select the item to set.

2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Y1	Compression rate of the brightness	1 to 100	15	1%
Y2	Compression rate of the brightness	1 to 100	75	1%
Y3	Compression rate of the brightness	1 to 100	90	1%
CbCr1	Compression rate of the color difference	1 to 100	15	1%
CbCr2	Compression rate of the color difference	1 to 100	75	1%
CbCr3	Compression rate of the color difference	1 to 100	90	1%

- 3 Press the [Start] key to set the setting value.

Setting: HC-PDF(File Size)

- 1 Select the item to set.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Y1	Compression rate of the brightness	1 to 100	15	1%
Y2	Compression rate of the brightness	1 to 100	25	1%
Y3	Compression rate of the brightness	1 to 100	75	1%
CbCr1	Compression rate of the color difference	1 to 100	15	1%
CbCr2	Compression rate of the color difference	1 to 100	25	1%
CbCr3	Compression rate of the color difference	1 to 100	75	1%

- 3 Press the [Start] key to set the setting value.

Setting: System

- 1 Select the item to set.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Y	Compression rate of the brightness	4 to 10	10	1%
CbCr	Compression rate of the color difference	4 to 10	10	1%

- 3 Press the [Start] key to set the setting value.



Note

Test copy of the original is available by pressing the [System Menu/Counter] key as interruption copy mode when executing this maintenance mode.

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings. (Source/Conveying speed/Duplex/Orientation/Color/Copies)

Completion

- 1 Press the [Stop] key.
- The screen for selecting a maintenance item No. is displayed.

U520 TDRS setting

(Message: Set TDRS)

Contents

Checks/sets the TDRS

Purpose

Execute to check/set the TDRS

Method

- 1 Press the [Start] key.
- 2 Select [New ID(Reconfirm)].

Items	Contents
On/Off Config	Changes to the TDRS features setting dialog

- 3 Select the item to set.

Items	Contents
On	Enables TDRS
Off	Disables TDRS

Initial setting: Off

- 4 Press the [Start] key to set the setting value.
- 5 Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U600 Initialize: All Data

(Message: Initialize: All Data)

Contents

Initializes software switches, and all data and image memory in the backup data on the FAX PWB according to the destination and OEM setting.

Initializes the file system and then initializes the communication record and the registered contents if the file system is checked and an error is detected there.

Purpose

Initialize the FAX PWB

Method

- 1 Press the [Start] key.
The screen for entering the country code and OEM code is displayed.
- 2 Select [Country Code].
- 3 By using the [<] [>] keys or the numeric keys, change the setting value.
Refer to the following country code list.
No need to change the default value of [OEM Code].

Items	Contents
Country Code	Setting Country code
OEM Code	Sets the OEM code
Execute	Executing data initialization

- 4 Select [Execute].
- 5 Press the [Start] key to set the setting value.
Data initialization starts.
Press the [Stop] key to cancel the data initialization.
- 6 The firmware version is displayed after the data initialization.
The firmware version of 3 types of application, boot and IPL is displayed.
When initialization is successful, "Completed" is displayed for one second.
Where an irregular value is input, when it initializes, the following errors are displayed.

Kind of error
Unknown Country (When Country Code is unknown)
Unknown OEM (When OEM Code is unknown)
Unknown Country (When both are unknown)

Country code list

Country code	Destination	Country code	Destination
000	Japan	181	North America *2
156	Asian nations *1	181	South America *3
254	Taiwan	253	European nations *4

Country code	Destination	Country code	Destination
097	Korea	009	Australia
038	China	126	New Zealand *5

*1 Applied for Sales company competent Singapore, India, Thailand, Hong Kong.

*2 Applied for Sales company competent USA, Canada, Mexico.

*3 Applied for Sales company competent Bolivia, Chile, Peru, Argentina, Brazil.

*4 Applied for Sales company competent Italy, Germany, Spain, U.K., Netherlands, Sweden, France, Austria, Switzerland, Belgium, Denmark, Finland, Portugal, Ireland, Norway, Turkey, Russia, Saudi Arabia.

*5 Change the country code when selling in New Zealand. The country code to input is 126.

Completion

1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U601 Initialize: Keep data

(Message: Init Keep Data)

Contents

Initializes software switches other than the machine data on the FAX PWB according to the destination and OEM setting.

Purpose

Initialize the FAX PWB without changing the user registration data and the factory defaults

Method

- 1 Press the [Start] key.
The screen for entering the country code and OEM code is displayed.
- 2 Select [Country Code].
- 3 By using the [<] [>] keys or the numeric keys, change the setting value.
Refer to the country code list. (See page [6-135](#))
No need to change the default value of [OEM Code].

Items	Contents
Country Code	Setting Country code
OEM Code	Sets the OEM code
Execute	Executing data initialization

- 4 Select [Execute].
- 5 Press the [Start] key to set the setting value.
Data initialization starts. Press the [Stop] key to cancel the data initialization.
- 6 The firmware version is displayed after the data initialization. The firmware version of 3 types of application, boot and IPL is displayed.
When initialization is successful, "Completed" is displayed for one second.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U603 User data 1

(Message: User Data 1)

Contents

Sets the line type for FAX use

Purpose

Execute as required

Method

- 1 Press the [Start] key.
- 2 Select [Line Type].

Items	Contents
Line Type	Line Type

- 3 Select the item to set.

Items	Contents
DTMF	DTMF
10PPS	10PPS
20PPS	20PPS

- 4 Press the [Start] key to set the setting value.
[Completed] is displayed.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U604 User Data 2

(Message: User Data 2)

Contents

Sets the number of rings for the automatic FAX/telephone switching for FAX use

Purpose

Adjust the number of rings to longer or shorter at the automatic FAX/telephone switching

Method

- 1 Press the [Start] key.
- 2 Select [Rings(F/T)].
- 3 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Rings (F/T)	Number of fax/telephone rings	0 to 15	-	-

If the default is set to "0", the main unit will start FAX reception without any ringing.

- 4 Press the [Start] key to set the setting value.
[Completed] is displayed.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U605 Data clear

(Message: Clr Data)

Contents

Initializes data related to the fax transmission such as transmission history or various ID.

Purpose

Clear the communication history

Method

- 1 Press the [Start] key.
- 2 Select [Clear Com.Rec.].

Items	Contents
Clear Com.Rec.	Delete data of communication history and protocol list of displayed port

- 3 Press the [Start] key.
When initialization is successful, "Completed" is displayed for one second.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U610 System setting 1

(Message: System Setting 1)

Contents

Set the number of lines to be ignored when receiving a fax at 100% magnification and in the auto reduction mode.

Method

- 1 Press the [Start] key.
- 2 Select the item to set.

Items	Contents
Cut Line: A4	Set the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode.
Cut Line: 100%	Set the number of lines to be ignored when receiving a fax at 100% magnification.
Cut Line: Auto	Number of lines to be ignored when receiving in the auto reduction mode.

Setting: Cut Line: A4

Set the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when the data is recorded in the auto reduction mode onto A4R or Letter R paper.

If the number of excess lines is below the setting, those lines are ignored. If over the setting, the entire data on a page is further reduced so that it can be recorded on the same page.

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting	Data variation
Number of lines to be ignored when receiving in the A4R auto reduction mode.	0 to 22	0	-

Increase the setting value if a page received in the reduction mode is reduced too much with the trailing edge margin. Decrease the value if there is dropout in received image.

- 2 Press the [Start] key to set the setting value.

Setting: Cut Line(100%)

Sets the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when recording the data at 100% magnification.

If the number of excess lines is below the setting, those lines are ignored. If it is over the setting, they are recorded on the next page.

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting	Data variation
Set the number of lines to be ignored when receiving a fax at 100% magnification.	0 to 22	3	-

Increase the setting value if a blank second page is output in the full magnification reception. Decrease the value if there is dropout in received image.

- 2 Press the [Start] key to set the setting value.

Setting: Cut Line: Auto

Set the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when the data is recorded in the auto reduction mode.

If the number of excess lines is below the setting, those lines are ignored. If over the setting, the entire data on a page is further reduced so that it can be recorded on the same page.

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting	Data variation
Number of lines to be ignored when receiving in the auto reduction mode.	0 to 22	0	-

Increase the setting value if a page received in the reduction mode is reduced too much with the trailing edge margin.
Decrease the value if there is dropout in received image.

- 2 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U611 System setting 2

(Message: System Setting 2)

Contents

Sets the number of adjustment lines for automatic reduction.

Purpose

Sets the number of adjustment lines for automatic reduction.

Method

- 1 Press the [Start] key.
- 2 Select the item to set.

Items	Contents
ADJ LINES	Sets the number of adjustment lines for automatic reduction.
ADJ LINES(A4)	Number of adjustment lines for automatic reduction when A4 paper is set.
ADJ LINES(LT)	Number of adjustment lines for automatic reduction when letter size paper is set.

Setting: ADJ LINES

Sets the number of adjustment lines for automatic reduction.

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting	Data variation
Number of adjustment lines for automatic reduction.	0 to 22	7	-

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Setting: ADJ LINES(A4)

Sets the number of adjustment lines for automatic reduction.

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting	Data variation
Number of adjustment lines for automatic reduction when A4 paper is set.	0 to 22	22	-

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Setting: ADJ LINES(LT)

Sets the number of adjustment lines for automatic reduction when letter size paper is set.

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting	Data variation
Number of adjustment lines for automatic reduction when letter size paper is set.	0 to 22	26	-

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U612 System setting 3

(Message: System Setting 3)

Contents

Sets the FAX operation and automatic printing of the protocol list.

Method

1 Press the [Start] key.

2 Select the item to set.

The screen for setting is displayed.

Items	Contents
Auto reduct	Selects auto reduction in the sub-scanning direction
Protocol List	Sets the automatic protocol list printing.

Setting: Auto Reduct

Sets whether to receive a long document by automatically reducing it in the sub-scanning direction or at 100% magnification.

1 Select the item to set.

Items	Contents
On	Auto reduction is executed if the received document is longer than the FAX paper.
Off	Auto reduction is not performed.

Initial setting: On

2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Setting: Protocol List

Sets the automatic protocol list printing.

1 Select the item to set.

Items	Contents
Off	The protocol list is not printed out automatically.
Err	Automatically printed if a communication error occurs.
On	Automatically printed out after communication.

Initial setting: Off

2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Completion

1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U615 System Setting 6

(Message: System Setting 6)

Contents

Sets the record width capacity and process if 11 inch width paper is set for the inch specification machine

Method

1 Press the [Start] key.

2 Select the item to set.

The screen for setting is displayed.

Items	Contents
RX WIDTH FOR 11"	

Setting: RX WIDTH FOR 11"

1 Select the item to set.

Items	Contents
LEDGER	Transmits the A3 width to the destination machine
B4	Transmits the B4 width to the destination machine

Initial setting: LEDGER

2 Press the [Start] key to set the setting value.

Completion

1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U620 FAX system

(Message: FAX System)

Contents

Sets the signal detection method for remote switching.

Change the setting according to the type of telephone connected to the main unit.

Purpose

Sets the remote switching conditions according to the user's telephone type, preference, etc.

Setting

- 1 Press the [Start] key.
- 2 Select [Remote Mode] and press the [Start] key.

Items	Contents
Remote Mode	Setting the remote switching mode

- 3 Select the item to set.

Items	Contents
One	Sets the one-shot type detection
Cont	Sets the continuous type detection

Initial setting: One

- 4 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U625 Communication Setting

(Message: Set Comm)

Contents

Sets the auto redialing interval and the number of times of auto redialing.

Purpose

FAX transmission may not be available if redialing interval is short. If long, it takes much time to complete transmission. Changes the setting to prevent the following problems.

Method

- 1 Press the [Start] key.
- 2 Select the item to set.

Items	Contents
Interval	Sets the auto redialing interval
Times	Sets the number of times of auto redialing

Setting: Interval

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting	Data variation
Sets the redialing interval	1 to 9 minutes	3 minutes	-

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Setting: Times

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting	Data variation
Sets the number of times of redialing	0 to 15 times	3 times	-

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U630 Communication control procedures 1

(Message: Communication Control 1)

Contents

Sets the FAX communication.

Purpose

Sets the following to correspond to field claims

Reducing the transmission time to improve the accuracy of reception when using a low quality line

Improving the accuracy of communication during the international communication

Method

1 Press the [Start] key.

2 Select the item to set.

The screen for setting is displayed.

Items	Contents
TX Speed	Sets the communication starting speed.
RX Speed	Sets the reception speed.
TX Echo	Sets the waiting period to prevent echo problems at the sender.
RX Echo	Sets the reception speed.

Setting: TX Speed

Sets the transmission speed of the sender. When the destination unit has the V.34 capability, V.34 is selected for transmission regardless of this setting.

1 Select the communication speed.

Items	Contents
14400bps/V17	V.17 14400bps
9600bps/V29	Set to V.17 14400bps.
4800bps/V27ter	Set to V.27ter 4800bps
2400bps/V27ter	Set to V.27ter 2400bps

Initial setting: 14400bps/V17

2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Setting: RX Speed

Sets the reception capacity to advise the transmitter by the DIS/NSF signal. When the destination unit has the V.34 capability, V.34 is selected for transmission regardless of this setting.

- 1 Select the reception speed.

Items	Contents
14400bps	V.17, V.33, V.29, V.27ter
9600bps	V.29, V.27ter
4800bps	V.27ter
2400bps	V.27ter (fallback only)

Initial setting: 14400bps

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Setting: TX Echo

Sets the time to send the DCS signal after the DIS signal is received. Execute when an error occurs with echo at the transmitter side.

- 1 Select the item to set.

Items	Contents
500	Sends the DCS 500 ms after receiving a DIS.
300	Sends the DCS 300 ms after receiving a DIS.

Initial setting: 300

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Setting: RX Echo

Sets the time to send the NSF, CSI or DIS signal after the CED signal is received. Execute when an error occurs with echo at the receiver side.

- 1 Select the item to set.

Items	Contents
500	Sends the NSF, CSI or DIS 500ms after receiving the CED.
75	Sends the NSF, CSI or DIS 75ms after receiving the CED.

Initial setting: 75

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U631 Communication control procedures 2

(Message: Comm Cnt 2)

Contents

Sets the FAX communication.

Purpose

Sets the transmission and reception of ECM

Sets the CED frequency

Method

- 1 Press the [Start] key.
- 2 Select the item to set.
The screen for setting is displayed.

Items	Contents
ECM TX	Sets ECM transmission.
ECM RX	Sets ECM reception.
CED Freq	The frequency of CED is set up.

Setting: ECM TX

Set to OFF when the reduction of transmission costs is of higher priority than image quality.

Do not set it to Off when connecting to the IP telephone line.

- 1 Select the item to set.

Items	Contents
On	ECM transmission is enabled.
Off	ECM transmission is disabled.

Initial setting: On

- 2 Press the [Start] key. Set the setting value.
[Completed] is displayed.

Setting: ECM RX

Set to OFF when the reduction of transmission costs is of higher priority than image quality.

Do not set it to OFF when connecting to the IP (Internet Protocol) telephone line.

- 1 Select the item to set.

Items	Contents
On	ECM reception is enabled.
Off	ECM reception is disabled.

Initial setting: On

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Setting: CED Freq

Sets the CED frequency. Execute it as one of the communication accuracy improvement measures for the international communication.

- 1 Select the item to set.

Items	Contents
2100	2100Hz
1100	1100Hz

Initial setting: 2100

- 2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U632 Communication control procedures 3

(Message: Comm Cnt 3)

Contents

Sets the FAX communication.

Purpose

Reducing the error communication when using a low quality line

Corresponds to field claims when automatic FAX/telephone switching

Method

1 Press the [Start] key.

2 Select the item to set.

The screen for setting is displayed.

Items	Contents
DIS 4Byte	Sets the DIS signal to 4 bytes.
Num OF CNG(F/T)	Sets the number of the CNG detection in the automatic FAX/telephone switching mode.

Setting: DIS 4Byte

Sets whether to send bit 33 and later bits of the DIS/DTC signal.

1 Select the item to set.

Items	Contents
On	Bit 33 and later bits of the DIS/DTC signal are not sent.
Off	Bit 33 and later bits of the DIS/DTC signal are sent.

Initial setting: Off

2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Setting: Num OF CNG(F/T)

Sets the CNG detection times in the automatic FAX/telephone switching mode.

1 Select the item to set.

Items	Contents
1Time	Detects CNG once.
2Time	Detects CNG twice.

Initial setting: 1Time (100V model)/2Time (Others)

2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Completion

1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U633 Communication control procedures 4

(Message: Comm Cnt 4)

Contents

Sets the FAX communication.

Purpose

Reducing the error communication when using a low quality line

Method

1 Press the [Start] key.

2 Select the item to set.

The screen for setting is displayed.

Items	Contents
V.34	Enables or disables the V.34 communication.
V.34-3429Hz	Sets the V.34 symbol speed (3429 Hz).
DIS 2Res	Sets the number of times of DIS signal reception.
RTN Check	Sets the reference for the RTN signal output.

Setting: V.34

Sets whether to enable/disable the V.34 communication individually for transmission and reception.

1 Select the item to set.

Items	Contents
On	V.34 communication is enabled for both transmission and reception.
TX	V.34 communication is enabled for transmission only.
RX	V.34 communication is enabled for reception only.
Off	V.34 communication is disabled for both transmission and reception.

Initial setting: On

2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Setting: V.34-3429Hz

Sets if the V.34 symbol speed 3429 Hz is used.

1 Select the item to set.

Items	Contents
On	V.34 symbol speed 3429 Hz is used.
Off	V.34 symbol speed 3429 Hz is not used.

Initial setting: On

2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Setting: DIS 2Res

Sets the number of times to receive the DIS signal to once or twice. Execute it as one of the corrective measures for transmission errors and other problems.

- 1 Select the item to set.

Items	Contents
Once	Responds to the first signal.
Twice	Responds to the second signal.

Initial setting: Once

- 2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Setting: RTN Check

Sets the error line rate to be a reference to the RTN signal transmission. If transmission errors occur frequently due to the line quality, lower this setting to reduce them.

- 1 Select the item to set.

Items	Contents
5%	Error line rate of 5%
10%	Error line rate of 10%
15%	Error line rate of 15%
20%	Error line rate of 20%

Initial setting: 15%

- 2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U634 Communication control procedures 5

(Message: Comm Cnt 5)

Contents

Sets the maximum number of error bytes judged acceptable when receiving a TCF signal. Execute it as one of measures to ease transmission conditions if transmission errors occur.

Purpose

Relax the communication conditions

Setting

- 1 Press the [Start] key.
- 2 Select [TCF Check].
- 3 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Contents	Setting range	Initial setting
TCF Check	Sets the allowed error bytes when detecting the TCF signal	1 to 255	0

- 4 Press the [Start] key to set the setting value.
[Completed] is displayed.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U640 Communication time setting 1

(Message: Comm Time 1)

Contents

Sets the detection time when one-shot detection is selected for remote switching.

Sets the detection time when continuous detection is selected for remote switching.

Purpose

Sets the remote switching conditions according to the user's telephone type, preference, etc.

Method

- 1 Press the [Start] key.
- 2 Select the item to set.
- 3 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Contents	Setting range	Initial setting
Time(One)	Sets the one-shot detection time for remote switching.	0 to 255	7 1 (New Zealand)
Time (Cont)	Sets the continuous detection time for remote switching.	0 to 255	80

- 4 Press the [Start] key to set the setting value.
[Completed] is displayed.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U641 Communication time setting 2

(Message: Comm Time 2)

Contents

Sets the time-out time for the fax communication.

Purpose

Mainly, executed to improve the accuracy of communication for international communication

Method

- 1 Press the [Start] key.
- 2 Select the item to set.

Items	Contents
T0 TIME OUT	Sets the T0 time-out time.
T1 TIME OUT	Sets the T1 time-out time.
T2 TIME OUT	Sets the T2 time-out time.
Ta TIME OUT	Sets the Ta time-out time.
Tb1 TIME OUT	Sets the Tb1 time-out time.
Tb2 TIME OUT	Sets the Tb2 time-out time.
Tc TIME OUT	Sets the Tc time-out time.
Td TIME OUT	Sets the Td time-out time.

Setting: T0 Time Out

Sets the time before detecting a CED or DIS signal after a dialing signal is sent.

Sets to prevent disconnection of a line that occurs depending on the quality of the exchange, or when the destination unit sets the auto switching function.

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting
Sets the T0 time-out time.	30 to 90 (s)	56 58 (100V model)

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Setting: Td Time Out

Sets the time before receiving the correct signal after call reception.

This setting is usually unnecessary.

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting
Sets the T1 time-out time.	30 to 90 (s)	36 38 (100V model)

- 2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Setting: T2 Time Out

The T2 time-out time is specified as follows.

From CFR signal output to image data reception

From image data reception to the next signal reception

In ECM, from RNR signal detection to the next signal reception

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting
Sets the T2 time-out time.	1 to 255	69

- 2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Setting: Ta Time Out


Sets the time to start ringing for an operator through the external telephone after receiving a call in the FAX/telephone automatic switching mode. If either receiving a FAX signal within this time or passing this time, the mode automatically switches to the FAX reception mode. Execute when a reception error occurs when in the automatic FAX/telephone switching.

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting
Sets the Ta time-out time.	1 to 255 s	30

- 2 Press the [Start] key to set the setting value.

[Completed] is displayed.



Setting: Tb1 Time Out

Sets the time to start sending the ring back tone after receiving a call as a fax machine in the FAX/telephone automatic switching mode. Execute when a reception error occurs when in the automatic FAX/telephone switching.

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting
Sets the Tb1 time-out time.	1 to 255	20

- 2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Setting: Tb2 Time Out

Sets the time to start ringing for an operator through the external telephone after receiving a call in the FAX/telephone automatic switching mode. (See figure 1-3-27). Execute when a reception error occurs when in the automatic FAX/telephone switching.

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting
Sets the Tb2 time-out time.	1 to 255	80

- 2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Setting: Tc Time Out

In the TAD mode, set the time to check if there are any triggers for shifting to FAX reception after a connected handset receives a call. Unless switched to FAX reception during this period, operated as a normal phone after this.

In the TAD mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting
Sets the Tc time-out time.	1 to 255 s	60

- 2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Setting: Td Time Out

Sets the length of time to determine silent status, one of the triggers for Tc time check.

In the TAD mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call. Be sure not to set too short, otherwise the mode may be switched to fax while the unit is being used as a telephone.

- 1 By using the [<] [>] keys or the numeric keys, change the setting value.

Contents	Setting range	Initial setting
Sets the Td time-out time.	1 to 255	6 30 (100V model) 9 (120V model)

- 2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U650 Modem 1

(Message: Modem 1)

Contents

Sets the G3 cable equalizer. Sets the modem detection level.

Purpose

Adjusts the equalizer to be compatible with the line characteristics

Set to Improve the accuracy of communication when using a low quality line

Method

- 1 Press the [Start] key.
- 2 Select the item to set.

Items	Contents
Reg G3 TX Eqr	Sets the G3 transmission cable equalizer.
Reg G3 RX Eqr	Sets the G3 reception cable equalizer.
RX Mdm Level	Sets the modem detection level.

Setting: Reg G3 TX Eqr

- 1 Select [0dB], [4dB], [8dB] or [12dB].

Initial setting: 0dB

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Setting: Reg G3 RX Eqr

- 1 Select [0dB], [4dB], [8dB] or [12dB].

Initial setting: 0dB

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Setting: RX Mdm Level

- 1 Select [-33dBm], [-38dBm], [-43dBm] or [-48dBm].

Initial setting: -43dBm

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U651 Modem 2

(Message: Modem 2)

Contents

Sets the modem output level.

Purpose

Adjust to make the equalizer compatible with the line characteristics when installing the main unit

Setting

- 1 Press the [Start] key.
- 2 Select the item to set.
- 3 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Contents	Setting range	Initial setting
Sgl LVL Modem	Sets the modem output level	-15 to 0	11 10 (100V model) 12 (Australia)
DTMF LEV (Cent)	DTMF output level (center value)	-15.0 to 0.0	-8 -9 (100V model) -7 (Australia) -6 (120V model)
DTMF LEV (Diff)	Sets the DTMF output level (level difference)	0 to 5.5	2 1.5 (Australia) 1 (New Zealand)

- 4 Press the [Start] key to set the setting value.
[Completed] is displayed.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U660 Ring setting

(Message: Set Calls)

Contents

Sets the NCU (network control unit).

Purpose

Execute as required

Method

- 1 Press the [Start] key.
- 2 Select the item to set.
The screen for setting is displayed.

Items	Contents
Exchange	Setting the PBX/PSTN connection
Dial Tone	Sets the PSTN dial tone detection.
Busy Tone	Sets the busy tone detection.
PBX Setting	Setting the PBX connection
DC Loop	Sets the loop current detection before dialing.

Setting: Exchange

Selects if the FAX is connected to either a PBX or public switched telephone network.

- 1 Select the item to set.

Items	Contents
PSTN	Connected to the public switched telephone network.
PBX	Connecting to the PBX

Initial setting: PSTN

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Setting: Dial Tone

Selects whether or not to check for a dial tone to check if the telephone is off the hook when a fax is connected to a public switched telephone network.

- 1 Select the item to set.

Items	Contents
On	The dial tone is detected.
Off	The dial tone is not detected.

Initial setting: On

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Setting: Busy Tone

Sets whether the line is disconnected immediately after a busy tone is detected, or the busy tone is not detected and the line remains connected until T0 time-out time, when a FAX signal is sent

FAX transmission may fail due to incorrect busy tone detection. When setting it to OFF, this problem may be improved. However, the line is not disconnected within the T0 time-out time even if the destination line is busy.

- 1 Select the item to set.

Items	Contents
On	Detects the busy tone.
Off	Does not detect the busy tone.

Initial setting: On/Off (Australia)

- 2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Setting: PBX Setting

Selects the mode to connect an outside call when connected to a PBX.

According to the type of the PBX connected, select the mode to connect an outside call.

- 1 Select the item to set.

Items	Contents
Flash	Flashing mode
Loop	Code number mode

Initial setting: Loop

- 2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Setting: DC Loop

Sets if the loop current is detected before dialing.

- 1 Select the item to set.

Items	Contents
On	Detects the loop current before dialing.
Off	Detects the loop current before dialing.

Initial setting: On

- 2 Press the [Start] key to set the setting value.

[Completed] is displayed.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U670 List output

(Message: Output List)

Contents

Outputs the list of fax communication data.

Printing a list is disabled either when a job is remaining in the buffer or when [Pause All Print Jobs] is pressed to halt printing.

Purpose

Check conditions of use, settings and transmission procedures of the FAX.

Method

- 1 Press the [Start] key.
- 2 Select the item to execute.
- 3 Press the [Start] key.
- 4 Output selected list.

Items	Contents
Sys Conf Report	Prints the list of software switches, local telephone number, confidential boxes, firmware versions and other information.
Action List	Prints the list of the error logs and communication lines.
Self Sts Report	Prints the list of FAX communication settings only in the maintenance mode (self-status report).
Protocol List	Outputs a list of communication procedures.
Error List	Output the error list.
Addr List(No.)	Outputs address book in the IDs order
Addr List(Idx)	Outputs address book in the order of names.
One-touch List	Outputs a list of one-touch.
Group List	Outputs the group list.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U695 FAX function customization

(Message: Custom FAX Func)

Contents

FAX package transmission is set up. Changes print size priority when receiving small size.

Purpose

Execute as required

Method

- 1 Select the item to set.

Items	Contents
FAX Bulk TX	FAX batch transmission is set up.
A5 Pt Pri Chg	Change of print size priority at the time of small size reception.

Setting: FAX Bulk TX

- 1 By using the [+] [-] keys, select [On] or [Off].

Items	Contents
On	FAX batch transmission is enabled.
Off	FAX batch transmission is disabled.

Initial setting: On

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Setting: A5 Pt Pri Chg

- 1 By using the [+] [-] keys, select [On] or [Off].

Items	Contents
On	At the time of A5 size reception: A5 >B5 >A4 >B4 >A3
Off	At the time of A5 size reception: A5 >A4 >B5 >A3 >B4

Initial setting: Off

- 2 Press the [Start] key to set the setting value.
[Completed] is displayed.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U699 Software switch: Set

(Message: Set: Soft SW)

Contents

Sets the software switches on the FAX PWB individually.

Purpose

Change the setting when a problem such as split output of received originals occurs

Since the communication performance is largely affected, normally this setting need not be changed.

Method

- 1 Press the [Start] key.
- 2 Select [SW No.].
- 3 Enter the desired software switch number (3 digits) using the numeric keys and press the [Start] key.

Items	Contents
SW No.	Specifies the software switch number (2 to 3 digits)

- 4 Press the keys of bit 0 to 7 to switch each bit between 0 and 1.

Items	Contents
Bit	Set the software switch bit (8bit).

- 5 Press the [Start] key to set the setting value.
[Completed] is displayed.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

List of software switches which can be configured

Communication control procedures

No.	bit	Contents
36	7654	Coding format in transmission
	3210	Coding format in reception
37	5	33600bps/V34
	4	31200bps/V34
	3	28800bps/V34
	2	26400bps/V34
	1	24000bps/V34
	0	21600bps/V34
38	7	19200bps/V34
	6	16800bps/V34
	5	14400bps/V34
	4	12000bps/V34
	3	9600bps/V34
	2	7200bps/V34
	1	4800bps/V34
	0	2400bps/V34
41	3	FSK detection in V.8
42	4	4800 bps transmission when low-speed setting is active
	2	FIF length when transmitting DIS/DTC signal 4 times or more

Communication time setting

No.	bit	Contents
53	76543210	T3 timeout setting
54	76543210	T4 timeout setting (auto transmission)
55	76543210	T5 timeout setting
60	76543210	Time before transmission of CNG (1100 Hz) signal
63	76543210	T0 timeout setting (manual transmission)
64	7	Phase C timeout in ECM reception
66	76543210	Timeout 1 in countermeasures against echo
68	76543210	Timeout for FSK detection start in V.8

Modem setting

No.	bit	Contents
89	76543	RX gain adjust

NCU setting

No.	bit	Contents
121	7654	Dial tone/busy tone detection pattern
122	7654	Busy tone detection pattern
	1	Busy tone detection in FAX/TEL automatic switching
125	76543210	Registering the access code for connection to PSTN
126	7654	Ringback tone ON/OFF cycle for the automatic FAX/telephone switching

Calling time setting

No.	bit	Contents
133	76543210	DTMF signal transmission time
134	76543210	DTMF signal pause time
141	76543210	Ringer detection cycle (minimum)
142	76543210	Ringer detection cycle (maximum)
143	76543210	Ringer ON time detection
144	76543210	Ringer OFF time detection
145	76543210	Ringer OFF time undetected
147	76543210	Dial tone detection time (continuous tone)
148	76543210	Allowable dial tone interruption time
149	76543210	Time for transmitting selection signal after closing the DC circuit
151	76543210	Ringer frequency detection invalid time

U901 Clearing the counters by paper source

(Message: Clr Paper FD Cnt)

Contents

Displays and clears the counts by paper source.

Purpose

Check the maintenance parts replacement timing. Executes to clear counters when replacing the maintenance parts.

Method

- 1 Press the [Start] key.

Displays the counts by paper source.

Items	Contents
MPT	Displays/clears the MP tray feed counter
Cass1	Displays/clears Cassette 1 count
Cass2	Displays Cassette 2 count
Cass3	Displays Cassette 3 count
Duplex	Displays/clears the duplex unit count

- 2 Select the counter to clear.
Unable to clear [Cassette 2] and [Cassette 3]
- 3 Press the [Start] key to clear the counter value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U903 Clearing the jam counter

(Message: Clr Paper JAM Cnt)

Contents

Displays/clears the jam counter by paper jam type.

Purpose

Execute to check the paper jam status. Executes to clear counters when replacing the maintenance parts.

Method

- 1 Press the [Start] key.
- 2 Select the item to execute.

Items	Contents
Cnt	Displaying/clearing the jam counts
Total Cnt	Displaying the accumulate jam counts

Method: Cnt

- 1 Select [Cnt].
Number of occurrence is displayed by jam code.
Code of no occurrence is not indicated.
- 2 Select [Clear] to clear the jam counts.
Individual counters cannot be cleared.
- 3 Press the [Start] key to clear the counter value.

Method: Total Cnt

- 1 Select [Total Cnt].
Accumulate number of occurrence is displayed by jam code.
- 2 Change the screen using the [^] [V] key.
Unable to clear the accumulated jam counter values.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U904 Clearing the service call error counter

(Message: Clr Svc Call Cnt)

Contents

Displays/clears the number of times of service call errors by service call error type.

Purpose

Executes to check the service call error. Executes to clear counters when replacing the maintenance parts.

Method

- 1 Press the [Start] key.
- 2 Select the item to execute.

Items	Contents
Cnt	Displays/clears the service call counter.
Total Cnt	Displays accumulate service call error counts.

Method: Cnt

- 1 Select [Cnt].
Number of occurrence is displayed by service call error.
Code of no occurrence is not indicated.
- 2 Select [Clear] to clear the service call error counter.
Individual counters cannot be cleared.
- 3 Press the [Start] key to clear the counter value.

Method: Total Cnt

- 1 Select [Total Cnt].
Accumulate number of occurrence is displayed by service call error.
Unable to clear the accumulated service call error counter values.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U905 Optional counter

(Message: Option Cnt)

Contents

Displays the counter values of the document processor and finisher.

Purpose

Execute to check the usage status of the document processor and finisher.

Method

- 1 Press the [Start] key.
- 2 Select the device to check.
Switched to the counter screen.

Items	Contents
DP	Displays the document processor count.
DF *1	Displays the document finisher count.

*1: DF installed machine

Method: DP

Each counter is displayed.

Items	Contents
ADP	Simplex original count is displayed.
RADP	Duplex original count is displayed.

Method: DF

Each counter is displayed.

Items	Contents
Sorter	The document finisher counter is displayed.
Staple	Displays the staple counter.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U908 Total counter

(Message: Total Cnt)

Contents

Displays the total counter.

Purpose

Execute to check the usage status of the main unit.

Method

- 1 Press the [Start] key.
Counter is displayed.

Items	Contents
Total Cnt	Displays the total count

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U910 Black rate data

(Message: Clr Coverage Dat)

Contents

Clears the accumulated data for the print coverage per A4 size paper and its period of time (as shown on the service status page).

Purpose

Clears data as required at the time such as maintenance

Method

- 1 Press the [Start] key.
- 2 Select [Execute].

Items	Contents
Execute	Clears the print coverage data.

- 3 Press the [Start] key to clear the print coverage data.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U911 Counter by media type

(Message: Paper SZ Cnt)

Contents

Display the counts to confirm when replacing the maintenance parts.

Purpose

Displays the counts to confirm when replacing the maintenance parts .

Method

- 1 Press the [Start] key.

Displays the paper feed counts by paper size.

Items	Contents
A3 *1	Displays A3 feed counts
B4 *1	Displays B4 feed counts
A4 *1	Displays A4 feed counts
B5 *1	Displays B5 feed counts
A5 *1	Displays A5 feed counts
Folio *1	Displays Folio feed counts
Ledger *2	Displays Ledger feed counts
Legal *2	Displays Legal feed counts
Letter *2	Displays Letter feed counts
Statement *2	Displays Statement feed counts
ETC	Displays Other paper feed counts.

*1: *1: metric specification, *2: inch specification

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U917 Read/Write Backup Data

(Message: R/W Bkup Data)

Contents

Retrieves the backup data to a USB memory from the main unit, or writes the data from the USB memory to the main unit.

Purpose

Makes a back up of the main unit information, and import or export to restore the main unit information

Method

- 1 Turn the power switch off.
- 2 Insert a USB memory into the USB memory slot.
- 3 Turn the power switch on.
Wait for about 10 seconds until the main unit recognizes a USB memory.
- 4 Press the [Start] key.
- 5 Select [Export] or [Import].
The screen for setting is displayed.

Items	Contents
Import	Imports data from the USB memory to the main unit.
Export	Retrieving data from the main unit to the USB memory.

6 Select the object item.

Items	Contents	Depending data*
Address Book	Address book information	-
Job Account	Job accounting information	-
One Touch	One-touch key information	Address book information
User	User management information	Job accounting information
Document Box	Document box information	Job accounting, User information
Shortcut	Short-cut information	Job accounting, User, Document Box information
Fax Forward	FAX forward information	Job accounting, User, Document Box information
System	System setting information	-
Network	Network setting information	-
Job Setting	Job setting information	-
Printer	Printer setting information	-
Fax Setting	FAX setting information	-
Program	Program information	Information of Address book, Job accounting, User management, Document box, FAX transfer and FAX setting
Panel Setting	Panel setting information	Information of Address book, Job accounting, User management, Document box, FAX transfer, FAX setting and Program

Since data are dependent with each other, data other than selected are also retrieved or written.

7 Press the [Start] key. Starts reading or writing.

The progress of selected item is displayed in %.

When an error occurs, the operation is canceled and an error code appears.

8 [Finish] appears after normal completion.

9 When selecting [Import], turn the power switch off then on, after completing writing. Wait more than 5 seconds between the power off and on.

Error codes

Codes	Contents
e0001	Internal processing error
e0002	File access error (Inability to access the USB memory, etc.)
e0003	The file necessary for Import does not exist.
e0004	The file incompatible with Import is directed.
e0005	The file is broken (Unzipping the file to import failed).
e0100 to eFFFF	Data processing error when executing Import/Export.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U920 Billing counter

(Message: Chg Cnt)

Contents

Displays the billing count.

Purpose

Execute to check the current billing counts

Method

- 1 Press the [Start] key.
- 2 Select the item to display.
The charge counts are displayed.

Items	Contents
B/W Copy	B/W copy count is displayed.
B/W Prn	B/W print count is displayed
B/W FAX	FAX count
Simplex	Simplex print count is displayed
Duplex	Duplex print count is displayed
Comb(Off)	Combine print counts (Off) is displayed
Comb(2in1)	Combine print counts (2in1) is displayed
Comb(4in1)	Combine print counts (4in1) is displayed

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U927 Clearing all the billing/life counters

(Message: Clr Chg/Life Cnt)

Contents

Clears all charge counts and machine life counts.

Supplement

The total charge counts and the machine life counts can be cleared only once if all count values are 1000 or less.

Method

- 1 Press the [Start] key.
- 2 Select [Execute].

Items	Contents
Execute	Initializes the billing count and machine life count.

- 3 Press the [Start] key.
Clears all charge counts and machine life counts.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U928 Machine life counter

(Message: Life Cnt)

Contents

The current machine life counts is displayed.

Purpose

Executed to check the machine life count

Method

- 1 Press the [Start] key.

The current machine life counts is displayed.

Items	Contents
Cnt	Displays the machine life count

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U930 Clear the main charger roller counts

(Message: Clear Charger Roller Counter)

Contents

Displays and clears the current main charger roller counts.

Purpose

To verify the main charger roller counts after replacing. Also, clear the counts after replacement

Method

- 1 Press the [Start] key.

The main charge roller counter for each color is displayed.

Items	Contents
K	The main charger roller counts are displayed.

Method: Clear

- 1 Select the item to set.
- 2 Select [Clear].
- 3 Press the [Start] key to clear the counter value.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U935 Relay PWB Maintenance

(Message: Mnt Relay Board)

Contents

Set the mode when a failure occurs.

Purpose

Set when the relay board is faulty.

Method

- 1 Press the [Start] key.
- 2 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Mode	Malfunction setting mode	0 (Disabled) 1 (Enabled)	0	

- 3 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U942 DP loop amount setting

(Message: Adj DP Loop Amt)

Contents

Adjust the paper loop amount when using the document processor.

Purpose

Execute when original no-feed jam, skew or creases on the original appears.

Method

- 1 Press the [Start] key.
- 2 Press the [System Menu/Counter] key .
- 3 Place an original on the DP and press the [Start] key to make a test copy.
- 4 Press the [System Menu/Counter] key .
- 5 Select the item to adjust.
- 6 By using the [<] [>] keys or the numeric keys, change the setting value.

Items	Description	Setting range	Initial setting	Data variation
Front	Single-side original loop amount	-31 to 31	0	0.176mm
Back	Double-side original loop amount	-31 to 31	0	0.176mm

When the setting value is increased, the paper loop amount increase, and it decreases when the setting value is decreased.

Increase the set value if no feed jam or skew feed occurs and reduce the set value if creases appear on the original.

- 7 Press the [Start] key to set the setting value.



Note

Test copy of the original is available by pressing the [System Menu/Counter] key as interruption copy mode when executing this maintenance mode.

Press the [System Menu/Counter] key and the setting screen below is displayed for necessary settings. (Source/Conveying speed/Duplex/Orientation/Color/Copies)

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U964

(Message:)

Contents

Transfer the log files save in the nonvolatile memory to a USB memory.

Transfer the log and screenshot at the log retrieval.

Purpose

Transfer the log file saved in the nonvolatile memory to a USB memory for investigation when a failure occurs.

Method

- 1 Check the LED display is off and turn the power switch off.
- 2 Insert a USB memory into the USB memory slot.
- 3 Turn the power switch on.
- 4 Enter maintenance item U964.
- 5 Select [Execute].

Items	Contents
Execute	Transfer the log file.

- 6 Press the [Start] key.
 - Starts transferring the log files saved in the nonvolatile memory to a USB memory.
 - [Processing] is displayed. (About 3 to 5 minutes)
- 7 [Completed] appears after normal completion.
- 8 Turn the power switch off then on. Wait more than 5 seconds between the power off and on.
 - An error code appears when there is an error.

Supplement**How to retrieve the log when the operation panel freezes**

Start retrieving the log when pressing and holding three keys on the operation panel (Status/Job Cancel + System Menu/Counter + Stop) for 3 to 6 seconds.

The memory lamp is blinking during retrieving and turns on when completed.

The log retrieved this way can be saved in a USB memory.

Error codes

Codes	Contents
No USB Storage	The USB memory is not installed
No File	No file
Mount Error	USB memory mount error
File Delete Error	Failed to delete existing files in the USB memory
Copy Error	SSD to USB memory copy failure
Unmount Error	USB memory unmount error
Other Error	Other error

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U977 Setting the data capture mode

(Message: Set Data Capture)

Contents

Stores the data sent to the main unit into a USB memory.

Purpose

Store the data sent to the main unit into a USB memory to check it.

Method

- 1 Press the [Start] key.
- 2 Select [Execute].

Items	Contents
Execute	Stores data in a USB memory.

- 3 Press the [Start] key.
When the operation is completed abnormally, an error code is displayed.

Error codes

Items	Contents
1	USB memory is broken. USB memory was disconnected during data processing or is write-protected.
4	USB memory is full.
50	Other error occurs

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U984 Developer unit number

(Message:Dev No.)

Contents

Displays the developer unit number.

Purpose

Execute to check the developer unit number.

Method

- 1 Press the [Start] key.

Displays the developer unit number.

Items	Contents
K	Displays the Black developer unit number.

Completion

- 1 Press the [Stop] key.

The screen for selecting a maintenance item No. is displayed.

U985 Developer unit history

(Message: Dev History)

Contents

Displays the machine serial number and developer counter history.

Purpose

Displays the machine serial number and developer count to check.

Method

- 1 Press the [Start] key.
- 2 Select [K].

Items	Contents
K	Displays the Black developer unit history.

Displays the machine serial number and 3 items of the developer counter history.

Items	Contents
Machine History 1 to 3	Machine serial number history
Cnt History1 to 3	Developer counter history

Completion

- 1 Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

U991 Scanner counter

(Message: Scn Cnt)

Contents

Displays the scanner operation counts.

Purpose

Display the number of scanner operation to check the usage status.

Method

- 1 Press the [Start] key.

Current number of operation is displayed.

Items	Contents
Copy Scan	Displays times of copy and scan operations.
Fax Scan	Displays times of FAX scan operations.
Other Scan	Displays times of other scan operations.

Completion

- 1 Press the [Stop] key.


The screen for selecting a maintenance item No. is displayed.

6 - 2 Service mode

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Service mode execution method

[Message Display]



*1: Displays only when the FAX kit is installed

*2: Displays only when the SSD is installed

*3: Displays only when the SD card is installed

(2) Service mode table

Items	Contents	Page
Clearing the partial operation	Retrieve the control of the defect unit.	P. 6-191
Developer unit	Set Toner Install mode when replacing the developer unit.	P. 6-192
FAX country code	Initializes all data and image memory.	P. 6-193
FAX calling setting	Set up for connection	P. 6-194
Altitude Adjustment	Sets the altitude adjustment mode	P. 6-195
Formatting the SSD	Format the SSD	P. 6-196
Formatting the SD card	Format the SD card	P. 6-197
Memory diagnostics	Memory diagnostics is executed at start-up to check if read/write is executed properly.	P. 6-198

Resetting the partial operation

Contents

When replacing the defect unit, the system control turns to normal and use of the unit is enabled.

Appears on the menu only at the partial operation status.

Purpose

Execute when replacing the defect unit.

Method

- 1 Enter [Service Settings] menu.
- 2 Press [^] or [V] key and select [Clear partial operation].
- 3 Press [Execute] key.

Completion

Power is restarted after execution.

Developer unit

Contents

Set Toner Install mode when replacing the developer unit.

Purpose

Execute when replacing the developer unit.

Method

- 1 Enter [Service Settings] menu.
- 2 Press [^] or [V] key and select [Developer unit].
- 3 Press [Execute] key.

Completion

- 1 After execution, power is automatically restarted and Toner Install operation is executed.

FAX country code

Contents

Initializes software switches, and all data and image memory in the backup data on the FAX PWB according to the destination and OEM setting.

Purpose

Initialize the FAX PWB

Method

- 1 Enter [Service Settings] menu.
- 2 By pressing [Λ] [V] key, select [FAX country code]
- 3 Press the [Start] key.
- 4 Enter the country code using the numeric keys.
- 5 Press the [Start] key to set the setting value.
Data initialization starts.

Country code list

Country code	Destination	Country code	Destination
000	Japan	181	North America *2
156	Asian nations *1	181	South America *3
254	Taiwan	253	European nations *4
097	Korea	009	Australia
038	China	126	New Zealand *5

*1 Applied for Sales company competent Singapore, India, Thailand, Hong Kong.

*2 Applied for Sales company competent USA, Canada, Mexico.

*3 Applied for Sales company competent Bolivia, Chile, Peru, Argentina, Brazil.

*4 Applied for Sales company competent Italy, Germany, Spain, U.K., Netherlands, Sweden, France, Austria, Switzerland, Belgium, Denmark, Finland, Portugal, Ireland, Norway, Turkey, Russia, Saudi Arabia.

*5 Change the country code when selling in New Zealand. The country code to input is 126.

Completion

- 1 Press the [Stop] key.

FAX calling setting

Contents

Selects if the FAX is connected to either a PBX or public switched telephone network.

Selects the mode to connect an outside call when connected to a PBX.

Registering the access code for connection to PSTN

Purpose

Execute as required

Method

- 1 Enter [Service Settings] menu.
- 2 Press [^] [V] key and select [FAX calling setting].
- 3 Press the [Start] key.

Items	Contents
PBX selection	Setting the PBX/PSTN connection
PBX setting	Setting the PBX connection
PSTN connection number setting	PSTN access code setting

Setting: PBX selection

- 1 By pressing [^] [V] key, select [PBX selection]
- 2 Press the [Start] key.
- 3 Press [^] [V] key and select [PBX] or [PSTN].
- 4 Press the [Start] key to set the setting value.

Setting: PBX Setting

- 1 Press [^] [V] key and select [PBX settings].
- 2 Press the [Start] key.
- 3 By pressing [^] [V] key, select [Loop] or [Flash].
- 4 Press the [Start] key to set the setting value.

Setting: Access code Setting

- 1 Press [^] or [V] key and select [PSTN connection number setting].
- 2 Press the [Start] key.
- 3 Press [^] or [V] key and input the access code. (0 to 9, 00 to 99)
- 4 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.

Altitude Adjustment

Contents

Set Altitude Adjustment mode.

Purpose

Execute if the print quality is low at the usage environment of 1001 meter or more altitude.

Method

- 1 Enter [Service Settings] menu.
- 2 By pressing [^] [V] key, select [Altitude Adjustment]
- 3 Press the [Start] key.
- 4 By pressing [^] [V] key, select the altitude range of [1001 to 2000m], [2001 to 3000m] or [3001 to 3500m].
- 5 Press the [Start] key to set the setting value.

Completion

- 1 Press the [Stop] key.

Formatting the SSD

Contents

Initialize the SSD.

Purpose

Initialize the SSD when replacing the SSD in the field.

Important

The following settings are initialized if the SSD is initialized.

System Menu (User Management, Job Accounting, Address Book, One Touch Key, Document Box, etc.), Shortcut key, Panel program.

If executing full-format, the following installed software is deleted.

Optional language, HyPAS application (FMU, etc.), OCR dictionary software, color table.

Method

- 1 Enter [Service Settings] menu.
- 2 By pressing [^] [V] key, select [Format SSD]
- 3 Press the [Yes] key to execute the initialization.
- 4 Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

- 1 Press the [Stop] key.

Formatting the SD card

Contents

Initialize the SD card.

Purpose

Executed when starting use of the SD card or when necessary.

Method

- 1 Enter [Service Settings] menu.
- 2 By pressing [Λ] [V] key, select [Format SD Card]
- 3 Press the [Yes] key to execute the initialization.

Completion

- 1 Press the [Stop] key.

Memory diagnostics

Contents

Memory diagnostics is executed at start-up to check if read/write is executed properly.

Purpose

A memory device defect is considered as one of factors of the case where the F-code error, lock-up or abnormal image occurs and is not cleared.

Check the memory failure

Method

- 1 Enter [Service Settings] menu.
- 2 By pressing [Λ] [V] key, select [Memory diagnostics]
- 3 Press [Execute] key.
- 4 Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

- 1 Press the [Stop] key.

7 Troubleshooting

7 - 1 Image formation problems

(1) Isolate the place of image failure

How to isolate the cause

Print MIP-PG pattern at U089 to check an image failure.

Yes: Engine factor

No: Scanner factor

Check if image failure is enlarged or reduced in the zoom mode.

Yes: Scanner factor


- 1 Scanner factor: Refer to [Image failure at Copy or Send](See page 7-2 or 7-12).
(LED lamp for originals on the contact glass→CCD)*2 or [CIS]*1 failure at scanning factor)

Isolate with the original scanning position.









- a. DP simplex (Scan by the main unit [CCD]*2 or [CIS]*1)
 - b. On the contact glass (Scan by the main unit [CCD]*2 or [CIS]*1)
- 2 Refer to image failure with Engine factor (See page 7-22 or 7-29).
(Main charge --> Drum --> LSU --> Developer --> Transfer image formation process failure)









*1:CIS model, *2:CCD model



Image data flow



(2) Scanner Factors (when scanning from DP)

No.	Contents	Image sample
(2-1)	Abnormal image	
(2-2)	Abnormal image	
(2-3)	Black dots	
(2-4)	Blurred characters	
(2-5)	Mismatch between the center of the original and the center of the copy image (Front side)	
(2-6)	Mismatch between the center of the original and the center of the copy image (Back side)	
(2-7)	Horizontal black streaks	
(2-8)	Vertical streaks, band (black or color)	

No.	Contents	Image sample
(2-9)	Regular difference of the leading edge on the original image and copy image (Front side)	
(2-10)	Regular difference of the leading edge on the original image and copy image (Back side)	
(2-11)	Vertical streaks, band (white)	
(2-12)	Moiré	
(2-13)	Missing entire image (White / Black)	
(2-14)	Image is dark partly or light	
(2-15)	Blurred image	
(2-16)	Image is missing partly	

No.	Contents	Image sample
(2-17)	Skewed image	
(2-18)	Entire image is light	

Content of Scanner Factors (when scanning from DP)

(2-1) Abnormal image

(When scanning from the DP)

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB	
2	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
3	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
4	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(2-2) Colored background.

(When scanning from the DP)

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The density adjustment is not set	Set [Background Density] to [Auto] at [System Menu/Counter] > [Common Settings] > [Function Defaults]	
2	Reloading the original	The original is raised at scanning.	Correct the wavy original and set it	
3	Cleaning the shading plate	The shading plate is dirty.	Clean the shading plate at the backside of the contact glass.	
4	Executing U411	The image is not adjusted.	When the same phenomenon occurs at the table scanning too, execute U411 [Table(chartA)].	
5	Reattaching the home position sensor	The home position sensor is not properly attached.	Reattach the home position sensor.	
6	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB	

Step	Check description	Assumed cause	Measures	Reference
7	Reattaching the lamp unit	The lamp unit is not attached properly.	Reattach the lamp unit.	
8	Checking the DP slit glass	The DP slit glass is dirty or not properly attached.	Clean the DP slit glass or reattach it.	
9	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
10	Replacing the lamp unit	The LED drive PWB (CCD model) or CIS PWB (CIS model) is faulty.	Replace the lamp unit.	
11	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(2-3) Black dots

(When scanning from the DP)

Step	Check description	Assumed cause	Measures	Reference
1	Replacing the original	The original is dirty.	Check the black dots on the original and replace it if necessary.	
2	Cleaning the DP slit glass	The DP slit glass is dirty.	Clean the DP slit glass.	
3	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB	
4	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
5	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
6	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(2-4) Blurred characters

(When scanning from the DP)

Step	Check description	Assumed cause	Measures	Reference
1	Checking the original	The originals out of specification are used. (They are thick, thin, or smooth.)	Ask a user to use the specified paper.	
2	Checking the original	The leading edge of the original is bent.	Stretch the bending or the paper creases of the original.	
3	Cleaning the DP conveying roller and the bushings	The DP conveying roller or the bushing is dirty.	Clean the DP conveying roller and the bushing.	
4	Reattaching the DP conveying pulley and the pressure spring	The original conveying pulley does not rotate smoothly.	Reattach the DP conveying pulley and the pressure spring.	
5	Reattaching the DP drive parts	The DP drive parts are not properly attached.	Reattach the DP drive parts.	
6	Reattaching the original pick-up guide	The original pick-up guide does not operate properly.	Reattach the original pick-up guide.	
7	Replacing the DP scanning guide	The DP scanning guide is deformed.	Replace the DP scanning guide.	
8	Reinstalling the document processor	The document processor is not properly installed in the main unit.	Reinstall the document processor.	

Step	Check description	Assumed cause	Measures	Reference
9	Checking the DP hinge	The DP hinge is faulty.	Open and close the document processor. Then, check if there is no space between the document processor and the main unit at the machine front and rear sides when closing the document processor. If there are any space, replace the DP hinge.	

(2-5) Mismatch between the center of the original and the center of the copy image (Front side)

(When scanning the front side through DP)

Step	Check description	Assumed cause	Measures	Reference
1	Reloading the original	The originals are not properly set on the original tray.	Reset the originals.	
2	Executing U072	The center line when scanning the front page of the originals at the document processor is not adjusted.	Adjust U072 [Front].	
3	Executing U411	The auto scanner adjustment when DP scanning is not executed.	Execute U411 [DP FU(Char B)].	

(2-6) Mismatch between the center of the original and the center of the copy image (Back side)

(When scanning the back side through DP)

Step	Check description	Assumed cause	Measures	Reference
1	Reloading the original	The originals are not properly set on the original tray.	Reset the originals.	
2	Executing U072	The center line when scanning the back page of the originals at the document processor is not adjusted.	Adjust U072 [Back].	

(2-7) Horizontal black streaks

(When scanning from the DP)

Step	Check description	Assumed cause	Measures	Reference
1	Replacing the original	The original is dirty.	Replace the original.	
2	Cleaning the DP slit glass	The DP slit glass is dirty.	Clean the DP slit glass.	
3	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB	
4	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
5	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
6	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(2-8) Vertical streaks, band (black or color)

(When scanning from the DP)

Step	Check description	Assumed cause	Measures	Reference
1	Cleaning the DP slit glass and the DP original conveying guide	The DP slit glass is dirty.	Clean the DP slit glass and the DP conveying guide.	
2	Cleaning the shading plate	The shading plate is dirty.	Clean the shading plate at the backside of the contact glass.	
3	Cleaning the mirror	The mirror is dirty.	Clean the optical mirror	
4	Removing dust	The dust is adhered on the lamp unit.	Remove dust inside the laser path of the lamp unit.	
5	(CCD model) Cleaning the CCD PWB	Dust is on the CCD PWB.	Clean the CCD PWB using an air-blower.	
6	Executing U063	The image scanning position is incorrect.	Execute U063 to change the scanner shading position.	
7	Replacing the original	The original is dirty.	Replace the original.	
8	Executing U068	The starting position for scanning an original on the DP is incorrect.	Adjust U068 [DP Read].	
9	Executing U072	The center line settings are incorrect. (The streaks or bands appear out of the original image.)	Adjust U072 [Front].	
10	Executing U411	The auto scanner adjustment when DP scanning is not executed.	Execute U411 [DP FU(Chart B)].	
11	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB	
12	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
13	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
14	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(2-9) Regular difference of the leading edge on the original image and copy image (Front side)

(When scanning from the DP)

Step	Check description	Assumed cause	Measures	Reference
1	Executing U071	The timing of scanning the original leading edge at the document processor is not properly set.	Adjust [Front Head] at U071.	
2	Executing U411	The starting position for scanning an original on the DP is incorrect.	Execute U411 [DP FU(Chart B)].	
3	Cleaning the DP conveying roller and the bushings	The DP conveying roller or the bushing is dirty.	Clean the DP conveying roller and the bushing.	
4	Replacing the DP conveying roller	The DP conveying roller is worn down.	Replace the DP conveying roller.	

Step	Check description	Assumed cause	Measures	Reference
5	Applying the grease	The DP drive motor rotates irregularly and the excessive load is applied to the DP drive gear.	Apply the grease to the drive gear of the DP drive motor. (EM-50LP: Part number (7BG010009H))	
6	Replacing the DP drive motor	The DP drive motor rotates irregularly due to the fault.	Reattach the DP drive motor and reconnect the connector. If not repaired, replace it.	

(2-10) Regular difference of the leading edge on the original image and copy image (Back side)

(When scanning from the DP)

Step	Check description	Assumed cause	Measures	Reference
1	Executing U071	The timing of scanning the leading edge on the back page of the originals at the document processor is not properly set.	Adjust [Back Head] at U071.	

(2-11) Vertical streaks, band (white)

(When scanning from the DP)

Step	Check description	Assumed cause	Measures	Reference
1	Replacing the original	The original is dirty.	Replace the original.	
2	Cleaning the mirror	The mirror is dirty.	Clean the optical mirror	
3	Cleaning the shading plate	The shading plate is dirty.	Clean the shading plate at the backside of the contact glass.	
4	Removing dust	The dust is adhered on the lamp unit.	Remove dust inside the laser path of the lamp unit.	
5	Executing U063	The image scanning position is incorrect.	Execute U063 to change the scanner shading position.	
6	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB	
7	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
8	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
9	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(2-12) Moiré

(When scanning from the DP)

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The original image quality is not set properly. (moiré changes depending on the image quality.)	Set [Original Image] at [System Menu/Counter] > [Common Settings] > [Function Defaults]	
2	Reloading the original	The original is not set properly. (moiré appears in the original scanning direction.)	Rotate the originals in 180 degrees and reload them.	

(2-13) Missing entire image (White / Black)

(When scanning from the DP)

Step	Check description	Assumed cause	Measures	Reference
1	Reloading the original	The originals were set upside down.	Reset the original to correct the front and back direction.	
2	Executing U068	The starting position for scanning an original on the DP is incorrect.	Adjust U068 [DP Read].	
3	Reattaching the home position sensor	The home position sensor is not properly attached.	Reattach the home position sensor.	
4	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. <ul style="list-style-type: none"> • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB 	
5	Reattaching the scanner drive belt	The scanner drive belt comes off.	Reattach the scanner drive belt.	
6	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
7	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
8	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(2-14) Image is dark partly or light

(When scanning from the DP)

Step	Check description	Assumed cause	Measures	Reference
1	Replacing the original	The original is dirty.	Replace the original.	
2	Checking the original	The originals are bent or creased.	Stretch the bending or the paper creases of the original.	
2	Cleaning the DP slit glass	The DP slit glass is dirty.	Clean the DP slit glass.	
3	Reattaching the DP slit glass	The DP slit glass is bent.	Reattach the DP slit glass.	
4	Reattaching the DP scanning guide	DP scanning guide is not installed properly.	Reattach the DP scanning guide.	
5	Cleaning the mirror	The mirror is dirty.	Clean the optical mirror	
6	Removing dust	The dust is adhered on the lamp unit.	Remove dust inside the laser path of the lamp unit.	
7	Replacing the lamp unit	The LED drive PWB (CCD model) or CIS PWB (CIS model) is faulty.	Replace the lamp unit.	
8	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. <ul style="list-style-type: none"> • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB 	
9	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(2-15) Blurred image

(When scanning from the DP)

Step	Check description	Assumed cause	Measures	Reference
1	Replacing the original	The original is wavy.	Make the originals flat, or replace it if possible.	
2	Removing condensation (DP slit glass)	The DP slit glass has condensation.	Remove the condensation on the DP slit glass.	
3	Checking the mirror	The mirror has condensation.	Remove condensation from the optical mirror	
4	Removing condensation	The lens unit (CCD model) or lamp unit (CIS model) is condensed	Remove condensation from the lens unit (CCD model) or lamp unit (CIS model)	
5	Executing U411	Each auto adjustment of the scanner is incorrect.	Execute U411 [DP FU(ChartA)].	
6	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. <ul style="list-style-type: none"> • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB 	
7	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
8	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
9	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(2-16) Image is missing partly

(When scanning from the DP)

Step	Check description	Assumed cause	Measures	Reference
1	Reloading the original	The original is not set properly.	Reset the originals.	
2	Changing the setting	The original size and the paper side do not match on the operation panel. (The setting is incorrect.)	Set the original size manually.	
3	Changing the setting	The copy position is rotated automatically.	Set [Auto Image Rotation] to [Off] from the System Menu.	
4	Cleaning the DP slit glass	The DP slit glass is dirty.	Clean the DP slit glass.	
5	Reattaching the DP slit glass	The DP slit glass is not properly attached.	Reattach the DP slit glass.	
6	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. <ul style="list-style-type: none"> • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB 	
7	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
8	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
9	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(2-17) Skewed image

(When scanning from the DP)









Step	Check description	Assumed cause	Measures	Reference
1	Checking the original	The original is bent, curled or creased.	Stretch the bend or the paper creases of the original.	
2	Resetting the original width guides	The original skews.	Relocate the original width guides.	
3	Cleaning the DP feed roller	The DP feed roller is dirty	Clean the DP feed roller.	
4	Replacing the DP feed roller	The DP feed roller is worn down	Replace the DP feed roller.	
5	Cleaning the DP registration roller	The DP registration roller is dirty.	Clean the DP registration roller.	
6	Reattaching the DP registration pulley	The operation of the DP registration pulley is faulty.	Reattach the DP registration pulley.	
7	Executing U942	The original loop amount before registration is improper.	Adjust the original loop amount at U942.	









(2-18) Entire image is light

(When scanning from the DP)

Step	Check description	Assumed cause	Measures	Reference
1	Executing U068	The starting position for scanning an original on the DP is incorrect.	Adjust U068 [DP Read].	
2	Changing the setting	The density is not properly adjusted. (The original type and image quality differs.)	Set the image quality according to the originals.	
3	Changing the setting	The density is not properly adjusted. ([EcoPrint] is set to "On".)	Change to [Off] at [System Menu/Counter] > [Common Setting] > [Function Defaults] > [EcoPrint]	
4	Changing the setting	The density is not properly adjusted. (The density setting is too light.)	Set the density setting to be dark.	
5	Changing the setting	The density is not properly adjusted. ([Background density] is set to "Off".)	Set [Manual] in the Background Density Adjustment to make dark.	
6	Changing the setting	[Prevent Bleed-thru] setting is [On]	Change to [Off] at [System Menu/Counter] > [Common Setting] > [Function Defaults] > [Prevent Bleed-thru]	
7	Cleaning the shading plate	The shading plate is dirty.	Clean the shading plate at the backside of the contact glass.	
8	Executing U411	The scanner image is not adjusted.	Execute U411 [DP FU(ChartA)].	
9	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. <ul style="list-style-type: none"> • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB 	
10	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
11	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
12	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(3) Scanner Factors (when scanning on the contact glass)

No.	Contents	Image sample
(3-1)	Abnormal image	
(3-2)	Colored background	
(3-3)	Black dots	
(3-4)	Blurred characters	
(3-5)	Mismatch between the center of the original and the center of the output image	
(3-6)	Horizontal black streaks	
(3-7)	Vertical streaks or bands	
(3-8)	Regular difference of the leading edge on the original and output image	

No.	Contents	Image sample
(3-9)	Vertical streaks, band (white)	
(3-10)	Moiré	
(3-11)	No image comes out (White or Black)	
(3-12)	Image is dark partly or light	
(3-13)	Blurred image	
(3-14)	Image is missing partly	
(3-15)	Skewed image	
(3-16)	Entire image is light	

Content of Scanner Factors (when scanning on the contact glass)

(3-1) Abnormal image

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB	
2	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
3	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
4	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(3-2) Colored background

Step	Check description	Assumed cause	Measures	Reference
1	Reloading the original	The original is raised at scanning.	Set the original during pressing.	
2	Cleaning the shading plate	The shading plate is dirty.	Clean the shading plate at the backside of the contact glass.	
3	Executing U411	The image is not adjusted.	Execute U411 [Table(ChartA)].	
4	Reattaching the home position sensor	The home position sensor is not properly attached.	Reattach the home position sensor.	
5	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB	
6	Reattaching the lamp unit	The lamp unit is not attached properly.	Reattach the lamp unit.	
7	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
8	Replacing the lamp unit	The LED drive PWB (CCD model) or CIS PWB (CIS model) is faulty.	Replace the lamp unit.	
9	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(3-3) Black dots

Step	Check description	Assumed cause	Measures	Reference
1	Replacing the original	The original is dirty.	Check the black dots or color dots on the original and replace it if necessary.	
2	Cleaning the contact glass	The contact glass is dirty.	Clean the contact glass.	
3	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB	

Step	Check description	Assumed cause	Measures	Reference
4	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
5	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
6	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(3-4) Blurred characters

Step	Check description	Assumed cause	Measures	Reference
1	Removing foreign material	There is a load on the scanner movement since the foreign objects adhere on the scanner rails (CCD model) or scanner rod (CIS model)	Remove foreign objects adhering to the scanner rail (CCD model) or scanner rod (CIS model)	
2	Reattaching the lamp unit	The lamp unit is not attached properly.	Reattach the lamp unit.	
3	Checking the belt tension	A load is applied to the scanner movement since the belt tension is improper.	Adjust the scanner motor belt tension properly.	
4	Removing foreign material	Foreign objects adhere to the scanner wire drum and pulley (CCD model) or scanner drive belt (CIS model)	Remove foreign objects adhering to the scanner wire drum and pulley (CCD model) or scanner drive belt (CIS model)	
5	(CCD model) Replacing the scanner wire	There are scratches on the scanner wire.	Replace the scanner wires.	
6	(CIS model) Replacing the scanner belt	The scanner belt is scratched	Replace the scanner belt	

(3-5) Mismatch between the center of the original and the center of the output image

Step	Check description	Assumed cause	Measures	Reference
1	Replacing the original	The original is not properly set on the contact glass.	Reset the originals.	
2	Reattaching the contact glass	The contact glass is not properly attached.	Reattach the contact glass.	
3	Executing U067	The scanner center line is not adjusted.	Adjust U067 [Front].	
4	Executing U411	The automatic table scanning adjustment is not executed.	Execute U411 [Table(ChartA)].	

(3-6) Horizontal black streaks

Step	Check description	Assumed cause	Measures	Reference
1	Replacing the original	The original is dirty.	Replace the original.	
2	Cleaning the contact glass	The contact glass is dirty.	Clean the contact glass.	
3	Executing U066	Scan the image at back side of the size indication plate. (Adjustment value at U066 [Front] is not appropriate.	Adjust U066 [Front].	

Step	Check description	Assumed cause	Measures	Reference
4	Executing U411	The image at the backside of the size indication plate is scanned. (The adjustment value of [Table(ChartA)] at U411 is incorrect.)	Execute U411 [Table(ChartA)].	
5	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB	
6	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
7	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
8	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(3-7) Vertical streaks or bands

Step	Check description	Assumed cause	Measures	Reference
1	Replacing the original	The original is dirty.	Replace the original.	
2	Changing the setting	Actual original size and detected original size are mismatched.	Set the original paper size.	
3	(CCD model) Checking the wire of the original size sensor	The wire of the original size sensor is faulty.	Check if 3 wires of the original size sensor are pinched up between the rear side plate and the hinge of the scanner unit. If pinched up, replace the wire.	
4	Cleaning the platen cover	The original cover is dirty.	Clean the original cover.	
5	Executing U067	The center line settings are incorrect. (The streaks or bands appear out of the original image.)	Adjust U067 [Front].	
6	Executing U411	The leading edge timing is incorrect. (Streaks or bands appear out of the original.)	Execute U411 [Table(ChartA)].	
7	Cleaning the contact glass	The contact glass or the shading plate at the backside of the contact glass is dirty.	Clean the contact glass and the shading plate at the backside of the contact glass.	
8	Cleaning the mirror	The mirror is dirty.	Clean the optical mirror	
9	Removing dust	The dust is adhered on the lamp unit.	Remove dust inside the laser path of the lamp unit.	
10	(CCD model) Cleaning the CCD PWB	Dust is on the CCD PWB.	Clean the CCD PWB using an air-blower.	
11	Executing U063	The image scanning position is incorrect.	Execute U063 to change the scanner shading position.	
12	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB	
13	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	

Step	Check description	Assumed cause	Measures	Reference
14	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
15	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(3-8) Regular difference of the leading edge on the original and output image

Step	Check description	Assumed cause	Measures	Reference
1	Reloading the original	The original is not set properly. (The leading edge of the original is not set on the contact glass properly)	Reset the originals.	
2	Executing U066	The scanner leading edge timing is incorrect	Adjust U066 [Front].	
3	Executing U411	The scanner leading edge timing is incorrect	Execute U411 [Table(ChartA)].	
4	Checking the home position sensor	The home position sensor is not properly attached.	Reattach the home position sensor.	
5	Checking the scanner drive belt	The scanner drive belt is loose.	Reattach the scanner drive belt.	
6	Checking the scanner motor	The scanner motor is faulty, and so the rotation is irregular.	Reattach the scanner motor and reconnect the connector. If not repaired, replace it.	

(3-9) Vertical streaks, band (white)

Step	Check description	Assumed cause	Measures	Reference
1	Reloading the original	The original is dirty.	Replace the original.	
2	Cleaning the mirror	The mirror is dirty.	Clean the mirror in the lamp unit.	
3	Cleaning the shading plate	The shading plate is dirty.	Clean the shading plate at the backside of the contact glass.	
4	Removing dust	The dust is adhered on the lamp unit.	Remove dust inside the laser path of the lamp unit.	
5	Executing U063	The image scanning position is incorrect.	Execute U063 to change the scanner shading position.	
6	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB	
7	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
8	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
9	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(3-10) Moiré

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The original image quality is not set properly. (moiré changes depending on the image quality.)	Set [Original Image] in [System Menu/Counter] key > [Common Settings] > [Function Defaults].	
2	Checking the original	The original is not set properly. (moiré appears in the original scanning direction.)	Rotate the originals in 90 degrees and reset them.	
3	Executing U065	The ratio in the main scanning direction is large. (This problem occurs when the print ratio is set as 100%.)	Change the value at U065 [Main Scan] to reduce the scanner magnification in the main scanning direction.	
4	Executing U411	Each adjustment of the scanner section is incorrect	Execute U411 [Table(ChartA)].	

(3-11) No image comes out (White or Black)

Step	Check description	Assumed cause	Measures	Reference
1	Reloading the original	The originals were set upside down.	Reset the original to correct the front and back direction.	
2	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB	
3	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
4	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
5	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(3-12) Image is dark partly or light

Step	Check description	Assumed cause	Measures	Reference
1	Replacing the original	The original is dirty.	Replace the original.	
2	Checking the original	The originals are bent or creased.	Stretch the bending or the paper creases of the original.	
3	Reattaching the original mat	The original mat shifts.	Reattach the original mat.	
4	Cleaning the contact glass	The contact glass is dirty.	Clean the contact glass.	
5	Reattaching the contact glass	The contact glass is not properly attached.	Reattach the contact glass.	
6	Cleaning the mirror	The mirror is dirty.	Clean the mirror in the lamp unit.	
7	Removing dust	The dust is adhered on the lamp unit.	Remove dust inside the laser path of the lamp unit.	
8	Replacing the lamp unit	The LED drive PWB (CCD model) or CIS PWB (CIS model) is faulty.	Replace the lamp unit.	

Step	Check description	Assumed cause	Measures	Reference
9	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. <ul style="list-style-type: none"> • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB 	
10	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(3-13) Blurred image

Step	Check description	Assumed cause	Measures	Reference
1	Checking the original	The original is wavy.	Make the originals flat, or replace it if possible.	
2	Removing condensation (contact glass)	The contact glass has condensation.	Remove the condensation on the contact glass.	
3	Removing condensation	The lens unit (CCD model) or lamp unit (CIS model) is condensed	Remove condensation from the lens unit (CCD model) or lamp unit (CIS model)	
4	Executing U411	Each auto adjustment of the scanner is incorrect.	Execute U411 [Table(ChartA)].	
5	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. <ul style="list-style-type: none"> • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB 	
6	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
7	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
8	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(3-14) Image is missing partly

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	Marked part by highlighter pen on the original cannot be scanned.	Set [Copy] > [Functions] > [Original image] > [Others] > [Highlighter] > [On]	
2	Checking the original	The original is not set properly.	Reset the originals.	
3	Changing the setting	The original size and the paper side do not match on the operation panel. (The setting is incorrect.)	Set the original size manually.	
4	Changing the setting	The copy position is rotated automatically.	Set [Auto Image Rotation] to [Off] from the System Menu.	
5	Cleaning the contact glass	The original scanning side of the contact glass is dirty.	Clean the original scanning side of the contact glass.	
6	Cleaning the shading plate	The shading plate is dirty.	Clean the shading plate at the backside of the contact glass.	
7	Reattaching the contact glass	The contact glass is not properly attached.	Reattach the contact glass.	

Step	Check description	Assumed cause	Measures	Reference
8	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB	
9	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Original size sensor - Engine PWB (YC15)	
10	(CCD model) Checking the wire of the original size sensor	The wire of the original size sensor is faulty.	Check if 3 wires of the original size sensor are pinched up between the rear side plate and the hinge of the scanner unit. If pinched up, replace the wire.	
10	Replacing the original size sensor	Original size and paper size are not matched on the operation panel display. (Original size sensor is misdetected.)	Replace the original size sensor.	
9	Replacing the lens unit	The lens unit is not attached properly.	Reattach the lens unit.	
11	Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
12	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	
13	Replacing the main PWB	The main PWB is faulty.	Replacing the main PWB.	

(3-15) Skewed image









Step	Check description	Assumed cause	Measures	Reference
1	Reloading the original	The original is not properly set. (The original is skewed.)	Reset the originals.	
2	Reattaching the lamp unit	The lamp unit is not attached properly.	Reattach the lamp unit.	








(3-16) Entire image is light

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The density is not properly adjusted. (The original type and image quality differs.)	Set the image quality according to the originals.	
2	Changing the setting	The density is not properly adjusted. ([EcoPrint] is set to "On".)	Change to [Off] at [System Menu/Counter] > [Common Setting] > [Function Defaults] > [EcoPrint]	
3	Changing the setting	The density is not properly adjusted. (The density setting is too light.)	Set the density setting to be dark.	
4	Changing the setting	[Prevent Bleed-thru] setting is [On]	Change to [Off] at [System Menu/Counter] > [Common Setting] > [Function Defaults] > [Prevent Bleed-thru]	
5	Cleaning the shading plate	The shading plate is dirty.	Clean the shading plate at the backside of the contact glass.	
6	Executing U411	The image is not adjusted.	Execute U411 [Table(ChartA)].	

Step	Check description	Assumed cause	Measures	Reference
7	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CCD model: CCD PWB - Main PWB • CIS model: CIS PWB - Main PWB	
8	(CCD model) Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit.	
9	(CIS model) Replacing the lamp unit	The CIS PWB is faulty	Replace the lamp unit.	
10	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(4) Engine Factors (Paper conveying cause: Transfer, Fuser and Separation)

No.	Contents	Image sample
(4-1)	Black dots (toner dirt)	
(4-2)	Image is missing partly (blank image, white spots)	
(4-3)	Blank image	
(4-4)	Mismatch between the center of the original and the center of the copy image	
(4-5)	Dirty reverse side	
(4-6)	Entire image is light	
(4-7)	Horizontal streaks, band (White, black)	
(4-8)	Irregular errors at the leading edge of the original image and the copy image (variation of paper leading edge timing)	

No.	Contents	Image sample
(4-9)	Blurred characters	
(4-10)	Offset	
(4-11)	Fusing failure	
(4-12)	Paper skew at the trailing edge	
(4-13)	Uneven transfer	
(4-14)	Blurred image	
(4-15)	Vertical streaks or bands	

Content of Engine Factors (Paper conveying cause: Transfer, Fuser and Separation)

(4-1) Black dots (toner dirt)

Step	Check description	Assumed cause	Measures	Reference
1	Checking the transfer roller	The transfer roller is dirty or scratched.	When the black dots appears in the transfer roller circumference interval (52mm), clean it. If not repaired, replace it.	

Step	Check description	Assumed cause	Measures	Reference
2	Checking the fuser separation claws	The fuser separation nails are dirty	Clean the fuser separation claws if dirty	
3	Checking the fuser unit	The fuser roller is dirty, scratched or foreign objects adheres	If black dots appears in the interval of fuser roller circumference (94mm), clean it. Remove foreign objects on the fuser roller by printing solid images. If it is not improved, replace the fuser unit.	

(4-2) Image is missing partly (blank image, white spots)

Step	Check description	Assumed cause	Measures	Reference
1	Replacing paper	The paper is damp.	Replace with the dry paper.	
2	Checking the paper storage place	The paper is stored in the high humidity environment.	Install the cassette heater if necessary. Also, ask users to store paper in a dry place.	
3	Checking the transfer roller	The transfer roller is dirty or scratched.	Clean the transfer roller if the image failure appears in the transfer roller circumference interval (52mm). If not repaired, replace the transfer roller.	
4	Setting the media type	The media type is not properly set.	Set the proper media type via the System Menu.	

(4-3) Blank image

Step	Check description	Assumed cause	Measures	Reference
1	Checking the right cover	The right conveying unit is not closed.	Check the lock of the right cover Assy, and open and close the right cover (conveying unit).	
2	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • High-voltage PWB - Engine PWB	
3	Checking the high-voltage PWB	The transfer bias output from the high-voltage PWB is faulty.	Replace the high-voltage PWB.	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

(4-4) Mismatch between the center of the original and the center of the copy image

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper width guides or the MP paper width guides	The locations of the paper width guides or the MP paper width guides do not fit with the paper size.	Relocate the paper width guides or the MP paper width guides to fit them with the paper size.	
2	Executing U034	The center line when image writing the data is incorrect.	Adjust the center line at U034 [LSU Out Left].	

(4-5) Dirty reverse side

Step	Check description	Assumed cause	Measures	Reference
1	Checking the transfer roller	The transfer roller is dirty or scratched.	Clean the transfer roller if the image failure appears in the transfer roller circumference interval (52mm). If not repaired, replace the transfer roller.	
2	Changing the setting	The transfer bias is improperly set.	Retrieve the transfer bias to the default at U101	
3	Checking the fuser pressure roller	The fuser pressure roller is dirty caused by the paper type setting.	Perform the duplex printing with the solid image and clean the fuser pressure roller. And set proper paper thickness in System Menu.	
4	Cleaning the conveying guide	The conveying guide is dirty	Clean the conveying guide.	

(4-6) Entire image is light

Step	Check description	Assumed cause	Measures	Reference
1	Replacing paper	The paper is damp.	Replace with the dry paper..	
2	Checking the paper storage place	Paper is stored in the high humidity environment.	Install the cassette heater if necessary. Also, ask users to store paper in a dry place.	
3	Changing the setting	The secondary transfer voltage is improperly set.	Retrieve the transfer voltage to the default at U106	
4	Checking the transfer bias contact	The transfer bias contact is dirty or deformed, so, the impression is unavailable.	Clean the transfer bias contact or correct it so that it grounds securely.	
5	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • High-voltage PWB - Engine PWB	
6	Checking the high-voltage PWB	The transfer bias output from the high-voltage PWB is faulty.	Replace the high-voltage PWB.	
7	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

(4-7) Horizontal streaks, band (White, black)

Step	Check description	Assumed cause	Measures	Reference
1	Cleaning the fuser roller	The fuser roller is dirty	When the image failure appears in the fuser roller circumference interval (94mm), clean it.	
2	Checking the right cover	Only one side of the right cover (conveying unit) is closed, or the pressure spring is deformed.	Close the right cover (conveying unit).	
3	Checking the transfer unit	The pressure spring is not properly attached or deformed.	Reattach the pressure spring. If not repaired, replace the transfer unit.	

(4-8) Irregular errors at the leading edge of the original image and the copy image (variation of paper leading edge timing)

Step	Check description	Assumed cause	Measures	Reference
1	Executing U034	The leading edge timing is not properly adjusted.	Adjust the leading edge timing at U034 [LSU Out Top].	
2	Executing U051	The paper loop amount before registration is improper.	Execute U051 to adjust the paper loop amount before registration.	
3	Checking the clutch	The feed conveying related clutch does not operate correctly.	Execute U032. If the paper feed / conveying clutches (feed clutch, middle clutch or registration clutch) do not operate properly, reattach them and reconnect the connectors. If not repaired, replace the drive unit.	

(4-9) Blurred characters

Step	Check description	Assumed cause	Measures	Reference
1	Replacing paper	Unspecified papers are used.	Replace with the paper within the specification.	
2	Changing the setting	The media type is not properly set.	Set the proper media type via the System Menu.	
3	Applying the grease	The drives from the conveying motors are not smoothly transmitted.	Apply the grease to the drive gear of the conveying related motor. (EM-50LP: Part number (7BG010009H))	
4	Replacing the conveying guide	The conveying guide is deformed.	Replace the conveying guide.	
5	Replacing the fuser unit	The fuser forwarding guide is deformed or the fuser pressure is uneven.	Replace the fuser unit.	

(4-10) Offset

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper	Unspecified papers are used.	Replace with the paper within the specification, or change to the media type setting closest to the specified paper.	
2	Changing the setting	The media type is not properly set.	Change the settings according to the media type (paper weight).	
3	Cleaning the transfer roller	The transfer roller is dirty.	Clean the transfer roller if the image failure appears in the circumference interval (52mm)	
4	Checking U101	The secondary transfer voltage is improperly set.	Retrieve the transfer voltage to the default at U101	
5	Checking U161	The higher fuser temperature is set.	Execute U161 [Print] and reset the fuser temperature to the default value.	
6	Cleaning the fuser roller	The fuser roller is dirty	When the image failure appears in the fuser roller circumference interval (94mm), clean it.	
7	Replacing the fuser unit	The fuser roller surface is scratched	Replace the fuser unit.	

(4-11) Fusing failure

Step	Check description	Assumed cause	Measures	Reference
1	Replacing paper	Unspecified papers are used.	Replace with the proper paper.	
2	Setting the media type	The media type is not properly set.	Set the proper media type via the System Menu.	
3	Checking U161	The lower fuser temperature is set.	Change the fuser temperature to the default value.	
4	Replacing the fuser unit	The nipping pressure (width) is small and fuser pressure setting is weak.	Replace the fuser unit.	

(4-12) Paper skew at the trailing edge

Step	Check description	Assumed cause	Measures	Reference
1	Cleaning the transfer unit	The neighboring parts of the secondary transfer roller are dirty with paper dust.	Clean the transfer roller, separation needle and paper conveying path	
2	Removing foreign material	Paper is caught by foreign material such as a piece of paper.	Replace the toner sucking fan motor if it does not operate properly when executing U037 [Toner].	
3	Relocating the paper width guides or the MP paper width guides	The set position of the paper width guides / MP paper width guides is mismatched with the paper size, and so, the paper is skewed.	Relocate the paper width guides or the MP paper width guides to fit them with the paper size.	
4	Checking the conveying section	The registration rollers or the middle pulleys are not properly attached, or they are dirty.	Check if the registration rollers and the middle pulleys are properly attached. If necessary, reattach them. Also, they are dirty with toner or paper dust, clean them.	
5	Opening and reclosing the right cover	The right cover is not firmly closed.	Open the right cover (conveying unit) once, and close it firmly.	
6	Reinstalling the fuser unit	The fuser unit is not properly installed.	Insert the fuser unit straight into the main unit, and lock both sides of the fuser unit firmly.	

(4-13) Uneven transfer

Step	Check description	Assumed cause	Measures	Reference
1	Opening and closing the conveying section	The conveying section is not closed completely.	Open the right cover (conveying unit) once, and close it firmly.	
2	Cleaning the transfer roller	The transfer roller is dirty.	Clean the transfer roller if the image failure appears in the circumference interval (52mm)	
3	Checking the transfer unit	The transfer roller is faulty or the pressure spring is deformed.	Correct the pressure spring deformed. If not repaired, replace the transfer unit.	
4	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • High-voltage PWB - Engine PWB	
5	Checking the high-voltage PWB	The transfer bias output from the high-voltage PWB is faulty.	Replace the high-voltage PWB.	
6	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

Step	Check description	Assumed cause	Measures	Reference
7	Replacing the fuser unit	The roller, or the parts in the drive section or the fuser press-release section are deformed or worn down.	Replace the fuser unit.	








(4-14) Blurred image









Step	Check description	Assumed cause	Measures	Reference
1	Replacing paper	The paper is damp.	Replace with the new dry paper.	
2	Checking the paper storage place	Paper is stored in the high humidity environment.	Install the cassette heater if necessary. Also, ask users to store paper in a dry place.	





(4-15) Vertical streaks or bands

Step	Check description	Assumed cause	Measures	Reference
1	Cleaning the fuser unit	The fuser heat roller and fuser separation claws are dirty with paper dust and toner	Execute the solid image printing to clean the fuser heat roller. And also clean the separation nails. If the parts in the fuser unit is broken, replace the fuser unit.	
2	Changing the setting	The media type is not properly set.	Set the proper media type via the System Menu.	
3	Cleaning the exit feed-shift guide	The exit feed-shift guide has toner dirt or welding.	Clean the exit feed-shift guide.	
4	Cleaning the separation needle	The separation needles are dirty with paper dust or toner.	Clean the separation needle above the transfer roller with a cleaning brush, etc.	
5	Checking the transfer roller	The transfer roller is dirty, deformed or worn down.	Clean the transfer roller if the image failure appears in the transfer roller circumference interval (52mm). If not repaired, replace the transfer roller.	
6	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • High-voltage PWB - Engine PWB	
7	Checking the high-voltage PWB	The transfer bias output from the high-voltage PWB is faulty.	Replace the high-voltage PWB.	
8	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

(5) Engine Factors (Image forming cause)

No.	Contents	Image sample
(5-1)	Background image is foggy.	
(5-2)	Background image is foggy.	
(5-3)	Background image is foggy.	
(5-4)	Entire image is light	
(5-5)	Entire image is light	
(5-6)	Entire image is light	
(5-7)	Background image is foggy.	

No.	Contents	Image sample
(5-8)	Blank image	
(5-9)	No image comes out (Black)	
(5-10)	Periodic toner dirt	
(5-11)	Horizontal streaks, band (White, black)	
(5-12)	Vertical streaks or bands	
(5-13)	Vertical streaks, band (white)	
(5-14)	Horizontal uneven density	
(5-15)	Vertical uneven density	

No.	Contents	Image sample
(5-16)	Offset	
(5-17)	Gradation reproducibility is low	
(5-18)	Blurred image	
(5-19)	Trailing image	

Content of Engine Factors (Image forming cause)

(5-1) Background image is foggy.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the print coverage	The charge amount of the toner is low.	Check the print coverage on the service status page and if printed in high coverage, execute the drum refresh.	
2	Checking the developer bias contact	The developer bias contact is dirty or deformed.	Clean the developer bias contact, or correct its shape so that it grounds securely.	
3	Checking the developer high-voltage contact	The developer high-voltage contact of the high-voltage PWB is dirty or deformed.	Clean the developer high-voltage contact and correct it so that it grounds securely. Or reattach the high-voltage PWB.	
4	Executing U140	The setting values at U140 are different from the default.	Retrieve the U140 setting values to the default	
5	Checking the developer unit	The charge amount of the toner is low.	Replace the developer unit.	
6	Replacing the high-voltage PWB	The developer bias output from the high-voltage PWB is high	Replace the high-voltage PWB.	
7	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

(5-2) Background image is foggy.

Step	Check description	Assumed cause	Measures	Reference
1	Reinstalling the main charger unit	The main charger unit is not installed properly.	Reinstall the main charger unit to the drum unit, and Reinstall the drum unit to the main body to ensure that the connector is connected.	
2	Checking the main charger unit	The MC roller surface is dirty.	Clean the MC roller surface. If not resolved, replace the main charger unit and clear the MC roller counter at U930.	
3	Main charger unit replacement	The MC roller reaches its life.	If the main charger roller counter exceeds 300,000 at U930, the drum surface potential is lowered under the low temperature environment. Therefore, replace the main charger unit and clear the main charger roller counter at U930.	
4	Changing the setting	The setting value of the main high-voltage is incorrect.	If the setting values at U100 are not the default values, reset them to the default values.	
5	Checking the drum unit and the developer unit	The drum is faulty.	Replace the drum unit.	
6	Checking the main charger high-voltage contact	The main charger high-voltage contact of the high-voltage PWB is dirty or deformed.	Clean the charger high voltage contact and correct it to ensure that it is grounded. Or, reinstall the high voltage PWB.	
7	Replacing the high-voltage PWB	The main charger bias output from the high-voltage PWB is high	Replace the high-voltage PWB.	
8	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	
9	Checking the temperature inside the main unit	Temperature is low in the installation environment.	If the machine inside temperature is below 10°C / 50°F at U139, instruct user to change the installation environment of the room temperature 16°C / 60.8°F or higher. (This phenomenon tends to occur immediately after being left in a low temperature environment for few days if turning on the power).	

(5-3) Background image is foggy.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • LSU(APC PWB) - Main PWB	
2	LSU replacement	The LSU is faulty.	Replace the LSU.	

(5-4) Entire image is light

Step	Check description	Assumed cause	Measures	Reference
1	Reinstalling the toner container	Toner is collected on one side.	Sufficiently shake the toner container and reinstall it to the main unit.	
2	Cleaning the DS pulleys	The DS pulleys are dirty.	Clean the DS pulleys at both ends of the developer unit.	
3	Checking the developer bias contact	The developer bias contact is deformed.	Correct the developer bias contact so that it grounds securely.	

Step	Check description	Assumed cause	Measures	Reference
4	Executing U140	The setting values at U140 are different from the default.	Retrieve the U140 setting values to the default	
5	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • High-voltage PWB - Engine PWB	
6	Replacing the high-voltage PWB	The developer, main charger and transfer bias output from the high-voltage PWB is low.	Replace the high-voltage PWB.	
7	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

(5-5) Entire image is light

Step	Check description	Assumed cause	Measures	Reference
1	Executing Drum refresh	Condensation on the drum surface	Execute Drum refresh.	
2	Cleaning the eraser	Eraser is dirty	Clean the eraser.	
3	Checking the eraser	Eraser is faulty	Reinsert the drum unit into the main unit all the way. If not repaired, replace the drum unit.	
4	Drum unit replacement	The drum surface is worn down and photoconductor layer is thickened. The drum surface potential after exposure is high.	Replace the drum unit.	

(5-6) Entire image is light

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • LSU(APC PWB) - Main PWB	
2	LSU replacement	The LSU is faulty.	Replace the LSU.	

(5-7) Image is missing partly

Step	Check description	Assumed cause	Measures	Reference
1	Executing Drum refresh	The drum surface is dirty.	Execute Drum refresh.	
2	Drum unit replacement	There are adhered objects on the drum surface.	Replace the drum unit.	

(5-8) Blank image

Step	Check description	Assumed cause	Measures	Reference
1	Checking the developer bias contact	The developer bias contact is dirty or deformed.	Clean the developer bias contact, or correct its shape so that it grounds securely.	
2	Developer unit replacement	The developer drive gear is faulty.	Replace the developer unit.	

Step	Check description	Assumed cause	Measures	Reference
3	Checking U140	The setting value of the developer bias is improper.	Execute U140 and reset the developer bias to the default value.	
4	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Developer motor - Engine PWB • LSU (APC PWB) - Main PWB 	
5	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. <ul style="list-style-type: none"> • High voltage PWB - Engine PWB 	
6	Checking the developer motor	The developing motor does not operate properly.	Execute U030 to check the developer motor operation. If the developer motor does not operate properly, reattach it and reconnect the connector. If not repaired, replace it.	
7	Replacing the high-voltage PWB	The developer, main charger and transfer bias output from the high-voltage PWB is low.	Replace the high-voltage PWB.	
8	LSU replacement	APC PWB of LSU is faulty.	Replace the LSU.	
9	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

(5-9) No image comes out (Black)

Step	Check description	Assumed cause	Measures	Reference
1	reinstalling the main charger unit and drum unit	The drum unit or the main charger unit is not properly installed.	Reattach the main charger unit to the drum unit and reinstall the drum unit into the main unit to ensure secure contact .	
2	Checking the MC roller contact	The contact of the MC roller is dirty or deformed. (Charge bias can't be applied)	Clean the main charger roller contact and correct it so that it is grounded securely.	
3	Checking the high-voltage contact	The high-voltage contact of the high-voltage PWB is dirty or deformed.	Clean the high-voltage contact and correct it so that it grounds securely. Or reattach the high-voltage PWB.	
4	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. <ul style="list-style-type: none"> • High-voltage PWB - Engine PWB 	
5	Replacing the high-voltage PWB	The main charger bias voltage output is not even from the main high-voltage PWB.	Replace the high-voltage PWB.	
6	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

(5-10) Periodic toner dirt

Step	Check description	Assumed cause	Measures	Reference
1	(In case of 94mm cycle) Executing drum refresh	The drum surface is dirty.	Execute Drum refresh.	
2	(In case of 94mm interval) Checking the drum unit	There are some scratches on the drum surface.	Replace the drum unit.	
3	(In case of 37.5mm interval) Checking the main charger unit	There is dirt or foreign object on the MC roller surface	Clean the MC roller surface. If not resolved, replace the main charger unit and clear the MC roller counter at U930.	

Step	Check description	Assumed cause	Measures	Reference
4	(In case of 40mm interval) Checking the developer unit	There is dirt, foreign object or scratch on the developing roller.	Wipe the developer roller dry. If it does not improve, replace the developer unit.	
5	(In case of 63mm interval) Checking the DS pulley	Foreign objects adhere to the DS pulley.	Clean the DS pulley.	

(5-11) Horizontal streaks, band (White, black)

Step	Check description	Assumed cause	Measures	Reference
1	Checking the developer unit	Both ends of the developer roller are dirty and it causes the developer bias leakage.	Clean both ends of the developer roller and the developer bias contact.	
2	Developer unit replacement	Both ends of the developer roller and the developer bias contact are deteriorated and it causes the developer bias leakage.	Replace the developer unit.	
3	Executing Drum refresh	The drum surface is dirty.	Execute Drum refresh.	
4	Drum unit replacement	The drum surface is scratched and there is leak.	Replace the drum unit.	
5	Main charger unit replacement	The MC roller surface is dirty or scratch.	Replace the main charger unit if the image failure appears in the MC roller circumference interval, and then clear the main charger roller counter at U930.	
6	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • High-voltage PWB - Engine PWB	
7	Replacing the high-voltage PWB	The main charger bias voltage output is not even from the main high-voltage PWB.	Replace the high-voltage PWB.	
8	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

(5-12) Vertical streaks or bands

Step	Check description	Assumed cause	Measures	Reference
1	Executing Drum refresh	The drum surface is dirty.	Execute Drum refresh.	
2	Drum unit replacement	The cleaning blade or drum surface is worn out.	Replace the drum unit.	
3	Cleaning the MC roller	Streaky dirt adheres to the surface of the MC roller, and no electric potential is applied.	Clean the MC roller surface with water.	
4	Main charger unit replacement	MC roller surface is streaky altered.	Replace the main charger unit and clear the MC roller counter at U930.	
5	Checking the developer unit	Foreign materials are pinched between the blade and magnet roller	Remove foreign objects between the blade and magnet roller. If not improved, replace the developer unit.	

(5-13) Vertical streaks, band (white)

Step	Check description	Assumed cause	Measures	Reference
1	Developer unit replacement	Foreign objects or aggregated toner adhere on the developing roller.	Clean the developer roller. Or, replace the developer unit if not repaired after cleaning.	
2	Removing foreign material	There are foreign objects on the laser path of the LSU.	Remove foreign objects on the frame or sealing material between the developer unit and the drum unit.	
3	Executing Drum refresh	The drum surface is dirty.	Execute Drum refresh.	
4	Drum unit replacement	There are some scratches on the drum surface.	Replace the drum unit.	
5	Checking the main charger unit	There is dirt, foreign object or scratch on the MC roller.	Clean the MC roller surface. If not resolved, replace the main charger unit and clear the MC roller counter at U930.	
6	Cleaning the eraser	Eraser is dirty	Clean the eraser.	

(5-14) Horizontal uneven density

Step	Check description	Assumed cause	Measures	Reference
1	Checking the main charger unit	MC roller rotation is uneven.	Reattach the main charger unit.	
2	Main charger unit replacement	The MC cleaning roller is deformed.	Replace the main charger unit and clear the MC roller counter at U930.	
3	Cleaning the DS pulleys	The DS pulleys are dirty.	Clean the DS pulleys at both ends of the developer unit.	
4	Developer unit replacement	The DS pulleys are faulty.	Replace the developer unit.	
5	Cleaning the developing bias contact	The conduction is not stabilized due to the dirty developer bias contact.	Clean the developer bias contact.	
6	Executing Drum refresh	Toner smudges in the shape of a streak are on both ends of the drum surface.	Execute Drum refresh.	
7	Drum unit replacement	The drum surface is worn down.	Replace the drum unit.	
8	LSU replacement	The laser emission is uneven.	Replace the LSU.	

(5-15) Vertical uneven density

Step	Check description	Assumed cause	Measures	Reference
1	Executing Drum refresh	The drum surface has condensation.	Execute Drum refresh.	
2	Checking the main charger unit	Streaky dirt adheres to the surface of the MC roller.	Clean the MC roller surface. If not resolved, replace the main charger unit and clear the MC roller counter at U930.	
3	Drum unit replacement	The drum surface is worn down.	Replace the drum unit.	

(5-16) Offset

Step	Check description	Assumed cause	Measures	Reference
1	Executing Drum refresh	The drum surface is dirty.	Execute Drum refresh.	
3	Drum unit replacement	The drum surface is worn down or has some scratches.	Replace the drum unit.	
3	Cleaning the developing roller	The developer roller is dirty	Clean the developer roller.	
4	Developer unit replacement	The developer roller surface is worn down or has scratches.	Replace the developer unit.	

(5-17) Gradation reproducibility is low

Step	Check description	Assumed cause	Measures	Reference
1	Adjusting the image	Grayscale adjustment is not executed	Execute System Menu [Adjustment/Maintenance] > [Grayscale]	

(5-18) Blurred image

Step	Check description	Assumed cause	Measures	Reference
1	Executing Drum refresh	The drum surface has condensation.	Execute Drum refresh.	
2	Checking the LSU	The LSU dust-proof glass is dirty or altered	Clean or replace the LSU	

(5-19) Trailing image

Step	Check description	Assumed cause	Measures	Reference
1	Changing the media type setting	The transfer current setting mismatches the paper used	Change the media type setting of the cassette with the target paper. Select the cassette at Cassette/MP tray setting in System Menu and set the media type to Custom 8. (Transfer current setting value is increased)	

7 - 2 Feeding/Conveying Failures

(1) Prior standard check items

Wear, dirt or foreign matter adhesion of conveyance system rollers, pulleys and gears

No.	Contents
(1-1)	Paper jam due to the cover-open detection
(1-2)	Paper jam from paper factor
(1-3)	Paper jam due to the dog-ear, paper skew, paper creases, fusing failure or the paper curl
(1-4)	Paper jam due to the guide
(1-5)	Paper jam caused by improperly loaded paper in the cassette
(1-6)	Paper jam due to the inferior paper
(1-7)	Paper jam from the factor of conveying roller, motor or clutch
(1-8)	Paper jam due to the sensor
(1-9)	Paper jam due to the setting / detection failure
(1-10)	Paper jam due to the static electricity
(1-11)	Paper jam caused by the installation environment (Papers inside the cassette are always damp.)

Content of Feeding/Conveying Failures

(1-1) Paper jam due to the cover-open detection

Step	Check description	Assumed cause	Measures	Reference
1	Opening / closing the front cover	The front cover is not engaged.	Open the right cover and close it securely.	
2	Checking the toner container and waste toner box	The toner container and waste toner box are not attached properly	Check how the toner container and waste toner box are attached. Reattach them if necessary.	
3	Opening and reclosing the right cover	The right cover is not aligned to the other exterior covers.	Open the right cover and close it again securely.	
4	Checking the conveying unit	Parts on the conveying unit are not attached properly	Check the attachment of the transfer roller unit and drum cover on the conveying unit, and reattach them if necessary.	

(1-2) Paper jam from paper factor

Step	Check description	Assumed cause	Measures	Reference
1	Reloading paper	The paper curls.	Reload paper upside down.	
2	Replacing paper	The paper is damp.	Replace with the dry paper.	
3	Checking the paper	The paper fanning is not enough or the cutting edge of loaded paper is damaged.	Fan the paper well and load it by reversing the paper direction. Correct or replace paper if a dog-ear is found.	
4	Checking the paper	The paper is wavy.	Correct or replace paper. If you cannot get user agreement about the paper replacement, relocate the leading end of paper and the trailing end or reload paper upside down.	
5	Checking the paper	Unspecified paper is used or foreign objects are on the paper.	Ask a user to use the specified paper type. Or, remove the paper with foreign objects.	

(1-3) Paper jam due to the dog-ear, paper skew, paper creases, fusing failure or the paper curl

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper path and the paper	The paper is caught with a piece of paper, etc. Or the leading edge of the sheet is bent.	When the dog-ear occurs, check if a piece of torn paper, foreign objects or the burrs on the part do not exist on the paper path, and remove them.	
2	Fuser temperature setting	The paper curls since the fuser temperature is improper.	Reset the fuser temperature to the default value at U161 when the paper curls.	

(1-4) Paper jam due to the guide

Step	Check description	Assumed cause	Measures	Reference
1	Checking the guide	The guide is dirty or foreign objects adhere	The guide is dirty with toner, paper dust, etc. Or if foreign objects adhere, clean it with cloth, etc.	
2	Checking the guide	The guide does not properly operate due to the incorrect attachment or a fault.	Check the guide, and remove any burrs. Also, if the guide does not operate smoothly manually, reattach the guide. Then, replace the guide if it is not fixed or if there is deformation or frictional wear.	
3	Checking the solenoid	The solenoid does not operate properly.	Execute U033 and check if the guide can move smoothly by the operation sounds. If the guide does not operate thoroughly or smoothly, reattach the guide. And, replace the solenoid if the issue is not resolved.	

(1-5) Paper jam caused by improperly loaded paper in the cassette

Step	Check description	Assumed cause	Measures	Reference
1	Relocating the paper width guides	The locations of the paper width guides do not fit with the paper size.	Relocate the paper width guides or the MP paper width guides along the paper size when the paper skew or the paper creases occur.	
2	Checking the paper	The paper fanning is not enough.	Fan paper and reload it in the paper source. If a part of the paper is bent, remove it.	

(1-6) Paper jam due to the inferior paper

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper	Unspecified papers are used.	Explain to the user to use the paper within the specifications.	

(1-7) Paper jam from the factor of conveying roller, motor or clutch

Step	Check description	Assumed cause	Measures	Reference
1	Checking the roller or the pulley	The roller or surface of the pulley is dirty, or faulty.	Check if the rollers or the pulleys have no paper dust, toner, foreign objects, diameter change or frictional wear, and clean their surface. If not repaired, replace the parts.	

Step	Check description	Assumed cause	Measures	Reference
2	Cleaning the roller shaft and the bearings	The roller shaft or the bearings are dirty.	If a load is given to the roller rotation caused by the dirt of the roller shaft or the bearings, clean.	
3	Checking the spring	The spring does not press the conveying roller or pulley properly.	Check if the spring is dropping off or the roller and the pulley are pressed properly, then reattach them if necessary.	
4	Checking the clutch	The clutch does not operate properly.	Execute U032 (main unit), U243 (dual scan DP) to check the clutch operation. If the clutch does not operate properly, reattach it and reconnect the connector. If not repaired, replace the individual clutch or the unit containing the clutch.	
5	Checking the motor	The motor does not operate properly.	Execute U030 [Main unit] and U243 [DP] and check the related motor operation. If not operating normally, replace the motor.	

(1-8) Paper jam due to the sensor

Step	Check description	Assumed cause	Measures	Reference
1	Checking the actuator and the recovery spring	The actuator or the return spring does not operate correctly.	If the actuator is caught or came off, reattach the actuator or recovery spring.	
2	Cleaning the sensor	The sensor is dirty.	If the sensor surface is dirty with paper dust, etc., clean it.	
3	Checking the sensor	The sensor does not operate correctly.	Check the sensor operation by executing U031 (main unit) or U244 (document processor). If the sensor does not operate properly, clean and reattach it, then reinsert the connector. If not repaired, replace it.	

(1-9) Paper jam due to the setting / detection failure

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper leading edge margin	The leading edge margin is not enough.	If there is no image margin at the paper leading edge, execute U034 to adjust the leading edge timing and then U403 to adjust the leading edge margin	
2	Relocating the paper width guides	The paper size is misdetected.	Relocate the paper width guides or the MP paper width guides along with the paper size to properly detect the paper size.	
3	Checking the settings	The media type is not properly set.	If the media type setting does not match the actual paper thickness, set the paper weight at [System Menu] > [Common Settings] > [Paper Settings] > [Media Type Settings].	

(1-10) Paper jam due to the static electricity

Step	Check description	Assumed cause	Measures	Reference
1	Checking the ground	The static electricity accumulates.	When the main unit is installed in the low humidity environment where the static electricity easily accumulates on the conveying guide during the continuous printing, check if the discharge sheet in the exit section and the metal guide in the transfer section are grounded securely. Reattach them if necessary.	

(1-11) Paper jam caused by the installation environment (Papers inside the cassette are always damp.)

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper storage place	Papers have been stored in the improper place.	Ask users to store paper in a dry place.	
2	Setting the cassette heater	The paper is damp.	Turn the cassette heater switch on at the machine rear side.	


(2) Paper misfeed detection

(2-1) Paper misfeed indication

When a paper misfeed occurs, the machine immediately stops printing and displays the paper misfeed message on the operation panel. To remove paper misfeed in the machine, pull out the cassette, open the front cover or paper conveying cover.

The locations are displayed on the operation panel when a paper jam has occurred.

Jam location indication




- 1 Shows the location of a paper jam.
- 2 Shows the previous step.
- 3 Shows the next step.
- 4 Shows the removal procedure.

Display	Jam location	Display	Jam location
1	Misfeed in MP tray	6	Misfeed in the cassette 3
2	Misfeed inside the right cover 1	7	Misfeed in the document finisher
3	Misfeed in the cassette 1	8	Misfeed in the conveying unit
4	Misfeed inside the right cover 3	9	Misfeed in the document processor
5	Misfeed in the cassette 2		

(2-2) Paper misfeed detection condition

Main unit + Optional unit



Item	Sensor name	Item	Sensor name
A	Paper sensor	L	DU sensor
B	PF paper sensor 1	M	BR conveying sensor 1
C	PF paper sensor 2	N	BR conveying sensor 2
D	Conveying sensor	O	BR conveying sensor 3
E	PF conveying sensor 1	P	DF conveying sensor
F	PF conveying sensor 2	Q	DF exit sensor
G	MP paper sensor	R	DP originsl sensor
H	Registration sensor	S	DP paper feed sensor
I	Exit sensor	T	DP registration sensor
J	Paper full sensor	U	DP timing sensor
K	JS full sensor		

Error code and JAM location

Error code	JAM location	Error code	JAM location	Error code	JAM location	Error code	JAM location
J0000	-	J4002	3	J4901	8	J6023	-
J0100	-	J4003	3	J4902	8	J6043	-
J0101	-	J4012	2	J4903	8	J6103	8
J0104	-	J4013	2	J4908	8	J6113	7
J0105	-	J4201	2	J4909	8	J6123	7
J0106	-	J4202	2	J4911	8	J6413	7
J0107	-	J4203	2	J4912	8	J6423	7
J0110	-	J4208	2	J4913	8	J6803	7
J0111	-	J4209	2	J4918	8	J6813	7
J0114	-	J4211	2	J4919	8	J6903	7
J0120	2	J4212	2	J5001	8	J6913	7
J0121	2	J4213	2	J5002	8	J7013	7
J0210	-	J4218	2	J5003	8	J7023	7
J0501	3	J4219	2	J5008	8	J7913	-
J0502	3	J4301	2	J5009	8	J7923	-
J0503	3	J4302	2	J5011	8	J7933	-
J0508	2	J4303	2	J5012	8	J7943	-
J0509	1	J4309	2	J5013	8	J7953	-
J0511	3	J4311	2	J5018	8	J7963	-
J0512	3	J4312	2	J5019	8	J9000	9
J0513	3	J4313	2			J9001	9
J0518	3	J4319	2			J9002	9
J0519	3					J9004	9
J1403	5					J9010	-
J1413	4					J9011	-
						J9110	9
						J9200	9
						J9400	9
						J9410	9

(3) Jam Codes

Error code	Contents	note
J0000	Power ON jam	
J0100/J0101/J0104/ J0105/J0106/J0107	Jam from firmware factor	
J0110/J0111/J0114	Cover open detection	J0110: Right cover open detection, J0111: Front cover open detection, J0114: Bridge cover open detection
J0120/J0121	Firmware triggered jam at duplex	
J0210	PF right cover open detection	Object: 500-sheet paper feeder, 500-sheetx2 paper feeder
J0501/J0502/J0503	Cassette no feed	
J0501/J0502/J0503	Cassette no feed	J0501: Registration sensor does not turn on J0502: PF conveying sensor 1 does not turn on J0503: PF conveying sensor 2 does not turn on
J0508	Duplex no feed	
J0509	No paper feed from the MP tray	
J0511	Multi-feeding from cassette	
J0512/J0513	Multi feed jam	Object: Paper feeder
J0518	Multi-feeding from the duplex section	
J0519	Multi-feeding from the MP tray	
J1403	PF conveying sensor 1 non-arrival jam	
J1413	PF conveying sensor 1 stay jam	
J4002/J4003	Registration sensor non-arrival jam	
J4012/J4013	Registration sensor stay jam	
J4201/J4202/J4203/ J4208/J4209	Eject sensor non-arrival jam	
J4211/J4212/J4213/J4218/ J4219	Eject sensor stay jam	
J4301/J4302/J4303/J4309	DU sensor non-arrival jam	
J4311/4312/4313/4319	DU sensor stay jam	
J4901/4902/4903/4908/ 4909	BR conveying sensor 2 non-arrival jam	
J4911/4912/4913/4918/ 4919	BR conveying sensor 2 stay jam	
J5001/5002/5003/5008/ 5009	BR conveying sensor 3 non-arrival jam	
J5011/5012/5013/5018/ 5019	BR conveying sensor 3 stay jam	
J6023	DF staple cover open jam	
J6043	DF top cover open jam	
J6103	DF conveying sensor jam	
J6113	DF conveying stay jam	
J6123	DF conveying sensor stay jam	
J6413	DF exit sensor stay jam	
J6423	DF exit sensor stay jam	
J6803	Front adjustor plate operation on error	
J6813	Front adjustor plate operation off error	

Error code	Contents	note
J6903	Rear adjustor plate operation on error	
J6913	Rear adjustor plate operation off error	
J7013	Staple operation error	
J7023	Staple initial operation error	
J7913	Sequence error 1	
J7923	Sequence error 2	
J7933	Sequence error 3	
J7943	Sequence error 4	
J7953	Sequence error 5	
J7963	Sequence error 6	
J9000	No original feed	
J9001	DP conveying jam	
J9002	Paper jam detected when starting the paper conveying	
J9004	DP switchback jam	
J9010	DP cover open jam	
J9011	DP top cover open jam	
J9110	DP feed sensor multi-feeding jam	
J9200	DP registration sensor non-arrival jam	
J9400	DP timing sensor non-arrival jam	
J9410	DP timing sensor stay jam	

Content of Jam Code

J0000: Power ON jam

The power is turned on while a conveying sensor turns on.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper path	There is a piece of paper remaining on paper conveying route to turn on the sensor.	If a piece of paper or the foreign objects adhere on the conveying path, or a burr in the parts such as the guide or the actuator, remove them.	
2	Specifying the sensor	If the faulty sensor can be specified at U031, the connector is not properly connected or the wire is faulty.	Specify the sensor turning on at U031, clean and reattach the sensor. Then, reconnect the connector. If the sensor turning on is displayed at U031 again, replace the wire or the sensor.	
3	(CCD model) Checking the wire of the original size sensor	The wire of the original size sensor is faulty. (This failure cannot be specified at U031.)	Check if 3 wires of the original size sensor are pinched up between the rear side plate and the hinge of the scanner unit. If pinched up, replace the wire and the main PWB.	

J0100/J0101/J0104/J0105/J0106/J0107: Jam from firmware factor

The firmware does not properly activate.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The controller does not activate properly.	Remove the paper on the conveying section. Turn off the power switch off and unplug the power cord. After 5s passes, reconnect the power cord and turn the power switch on.	
2	Firmware upgrade	The firmware does not properly activate.	Upgrade the firmware to the latest version.	

J0110/J0111/J0114: Cover open detection

J0110: Right cover open detection, J0111: Front cover open detection, J0114: Bridge cover open detection

Cover opened during printing

Step	Check description	Assumed cause	Measures	Reference
1	Checking the cover	The covers are not fitted.	Check if the cover is closed firmly, and reattach it if necessary. If the cover is deformed, repair or replace it.	
2	Checking the cover switch	The cover switch does not operate properly.	Reattach the cover switch and reconnect the connector. If the cover switch is faulty, replace it.	

J0120/J0121: Firmware triggered jam at duplex

The firmware does not properly activate.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The controller does not activate properly.	Remove the paper on the conveying section. Turn off the power switch off and unplug the power cord. After 5s passes, reconnect the power cord and turn the power switch on.	
2	Firmware upgrade	The firmware does not properly activate.	Upgrade the firmware to the latest version.	

J0210: PF right cover open detection

Object: 500-sheet paper feeder, 500-sheetx2 paper feeder

PF right cover opened during printing

Step	Check description	Assumed cause	Measures	Reference
1	Checking the PF right cover	The PF right cover is not aligned to the other exterior covers.	Check if the cover is securely closed, and reattach it if necessary. Correct or replace it if deformed.	
2	Checking the PF right cover switch	The PF right cover switch does not operate properly.	Reattach the PF right cover switch and reconnect the connector. If it is faulty, replace it.	

J0501/J0502/J0503: Cassette no feed

Prior checkpoints at no paper feed from the cassette

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper	The cut-end of the paper is crushed.	Fan the paper well and load it by reversing the paper direction	
2	Checking the paper	The paper leading edge is bent.	Remove the bent paper.	
3	Checking the paper	The paper curls or is wavy.	Correct the paper. Switch the leading edge and the trailing edge of paper, or flip paper upside down and reload the paper	
4	Checking the paper	foreign objects are on the paper.	Remove the paper with foreign objects.	
5	Checking the paper	Unspecified papers are used.	Use the paper matching the specification	

J0501/J0502/J0503: Cassette no feed

J0501: Registration sensor does not turn on

J0502: PF conveying sensor 1 does not turn on

J0503: PF conveying sensor 2 does not turn on

The next sensor does not turn on after the feed clutch turns on when feeding from cassette 1-3

Step	Check description	Assumed cause	Measures	Reference
1	Relocating the paper width guides and paper length guide	The paper width guide and length guide set position does not match the paper	Relocate the paper width guides and paper length guide to match the paper size.	
2	Checking the actuator for the upper paper sensor/lower paper sensor.	The actuator does not operate properly.	If the actuator is deformed or does not properly operate, replace it.	
3	Checking the paper path	The paper is caught with a piece of paper, etc.	If there is a piece of paper, foreign objects, etc. on the conveying path, remove them.	
4	Checking the pickup pulley	The conveying function of the pickup pulley is not enough.	Check the pickup spring. In case of installation failure, reattach the spring. Clean the pickup roller surface. If the surface is worn down, replace the pickup roller.	
5	Checking the paper feed roller	The conveying function of the paper feed roller is not enough.	Clean the feed roller surface. If worn down, replace it.	
6	Checking the paper feed clutch	The paper feed clutch is not connected, so the paper feed roller does not rotate.	Reattach the feed clutch and reconnect the connector. If not repaired, replace it.	
7	Checking the sensor	The sensor does not operate correctly.	Reattach the sensor and reconnect the connector. If not repaired, replace it.	
8	Checking the wire connection	The connector is not properly connected.	Reconnect the connectors on the Engine PWB and PF PWB.	

J0508: Duplex no feed

The registration sensor does not turn on when feed from the duplex section.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper path	The paper is caught with a piece of paper, etc.	If there is a piece of paper, foreign objects, etc. on the conveying path, remove them.	

Step	Check description	Assumed cause	Measures	Reference
2	Checking the conveying roller and the pulley	The paper conveying force is lowered.	Clean the surface of the DU conveying roller and conveying pulley. Check the pressure to the roller and pulley. If the spring or bushing comes off, reattach it. Check the drive gear and replace it if damaged.	
3	Checking the registration sensor	The registration sensor does not operate properly.	Execute U031 [Regist]. If the registration sensor does not operate properly, clean and reattach it then reconnect the connector. If not repaired, replace it.	
4	Checking the DU clutch	DU clutch does not operate correctly.	Execute U032 [DU1]. If DU clutch does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J0509: No paper feed from the MP tray

When feeding from MP tray, registration sensor does not turn on.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper path	The paper is caught with a piece of paper, etc.	If there is a piece of paper, foreign objects, etc. on the conveying path, remove them.	
2	Checking the MP feed roller and drive gears	The paper conveying force is lowered or slippage occurs	Clean the surface of the MP feed roller. If it is worn down, replace it. If the foreign objects adhere on the drive gear, remove them. If damaged, replace it.	
3	Checking the registration sensor	The registration sensor does not operate properly.	Execute U031 [Regist]. If the registration sensor does not operate properly, clean and reattach it then reconnect the connector. If not repaired, replace it.	
4	Checking the MP lift plate	The MP lift plate does not operate properly.	Execute U030 [MPT]. If the MP lift plate does not operate normally, reattach the MP lift plate. If not repaired, replace the drive unit.	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J0511: Multi-feeding from cassette

The registration sensor does not turn on when feeding from cassette 1.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper	The cut-end of the paper is crushed.	Fan the paper well and load it by reversing the paper direction	
2	Checking the retard roller	The paper separation force of the retard pulley is not enough.	Clean the retard pulley surface. If worn down, replace it.	
3	Checking the retard roller operation	The retard roller does not contact the feed roller	Rotate the retard roller to check if it contacts the feed roller. If the load is heavy in excess, check the drive belt and clean the ISU shaft	
4	Checking the paper length switch	Paper size is misdetected by paper length switch.	If the paper size loaded in the cassette differs from the paper size indicated on the operation panel, reattach the paper length switch and reconnect the connector. If not repaired, replace the paper length switch.	
5	Checking the registration sensor	The registration sensor does not operate properly.	Execute U031 [Regist]. If the registration sensor does not operate properly, clean and reattach it then reconnect the connector. If not repaired, replace it.	

Step	Check description	Assumed cause	Measures	Reference
6	Checking the paper feed clutch	The paper feed clutch does not operate properly.	Execute U032 [Feed]. If the feed clutch does not operate normally, replace the drive unit.	
7	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J0512/J0513: Multi feed jam

Object: Paper feeder

The PF conveying sensor does not turn off when feeding from cassette2, 3

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper	The cut-end of the paper is crushed.	Fan the paper well and load it by reversing the paper direction	
2	Checking the retard roller	The paper separation force of the retard pulley is not enough.	Clean the retard pulley surface. If worn down, replace it.	
3	Checking the retard roller operation	The retard roller does not contact the feed roller	Rotate the retard roller to check if it contacts the feed roller. If the load is heavy in excess, check the drive belt and clean the ISU shaft	
4	Checking the paper length switch	Paper size is misdetected by paper length switch.	If the paper size loaded in the cassette differs from the paper size indicated on the operation panel, reattach the paper length switch and reconnect the connector. If not repaired, replace the paper length switch.	
5	Checking the PF conveying sensor	PF conveying sensor does not operate correctly.	Check the operation of the actuator. Clean and reattach the sensor, then reconnect the connector. If not repaired, replace it.	
6	Checking the PF paper feed clutch	The PF paper feed clutch does not operate properly.	If the PF feed clutch does not operate normally, replace the PF drive unit.	
7	Replacing the PF PWB	The PF PWB is faulty.	Replace the PF PWB.	
8	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J0518: Multi-feeding from the duplex section

The registration sensor does not turn off during paper feed from the duplex section.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the registration sensor	The registration sensor does not operate properly.	Execute U031 [Regist]. If the registration sensor does not operate properly, clean and reattach it then reconnect the connector. If not repaired, replace it.	
2	Checking the DU clutch	DU clutch does not operate correctly.	Execute U032 [Dup]. If the DU clutch does not operate normally, replace the drive unit.	
3	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J0519: Multi-feeding from the MP tray

When feeding from MP tray, registration sensor does not turn off.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper size	Paper size on display and actual one mismatch (actual is longer)	Adjust the paper setting to match the actual paper size	

Step	Check description	Assumed cause	Measures	Reference
2	Checking the MP feed roller and the MP separation pad	The paper separation force of the MP separation pad is insufficient.	Clean the MP feed roller and MP separation pad, or replace them	
3	Checking the registration sensor	The registration sensor does not operate properly.	Execute U031 [Regist]. If the registration sensor does not operate properly, clean and reattach it then reconnect the connector. If not repaired, replace it.	
4	Checking the MP solenoid	The MP feed roller rotation does not stop due to the MP solenoid operation failure	Execute U033 [MPT]. If the MP solenoid does not operate normally, replace the drive unit.	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J1403: PF conveying sensor 1 non-arrival jam

The PF conveying sensor 1 does not turn on when feeding from cassette 3

Step	Check description	Assumed cause	Measures	Reference
1	Checking the PF cover	The PF cover is deformed.	Check if the PF cover is closed securely. Replace it if it cannot be closed due to deformation.	
2	Checking PF conveying sensor 1	PF conveying sensor 1 does not operate normally	Check the operation of the actuator. Clean and reattach the sensor, then reconnect the connector. If not repaired, replace it.	
3	Checking the PF conveying clutch	PF conveying clutch does not operate correctly.	If the PF conveying clutch does not operate normally, replace the PF drive unit.	
4	Replacing the PF PWB	The PF PWB is faulty.	Replace the PF PWB.	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J1413: PF conveying sensor 1 stay jam

The PF conveying sensor 1 does not turn off when feeding from cassette 3

Step	Check description	Assumed cause	Measures	Reference
1	Checking the PF cover	The PF cover is deformed.	Check if the PF cover is closed securely. Replace it if it cannot be closed due to deformation.	
2	Checking PF conveying sensor 1	PF conveying sensor 1 does not operate normally	Check the operation of the actuator. Clean and reattach the sensor, then reconnect the connector. If not repaired, replace it.	
3	Checking the PF conveying clutch	PF conveying clutch does not operate correctly.	If the PF conveying clutch does not operate normally, replace the PF drive unit.	
4	Replacing the PF PWB	The PF PWB is faulty.	Replace the PF PWB.	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J4002/J4003: Registration sensor non-arrival jam

The registration sensor does not turn on when feeding from cassette 3.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the registration sensor	The registration sensor does not operate properly.	Execute U031 [Regist]. If the registration sensor does not operate properly, clean and reattach it then reconnect the connector. If not repaired, replace it.	

Step	Check description	Assumed cause	Measures	Reference
2	Checking the PF conveying clutch	PF conveying clutch does not operate correctly.	If the PF conveying clutch does not operate normally, replace the PF drive unit.	
3	Replacing the PF PWB	The PF PWB is faulty.	Replace the PF PWB.	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J4012/J4013: Registration sensor stay jam

The registration sensor does not turn on when feeding from cassette 2-3

Step	Check description	Assumed cause	Measures	Reference
1	Checking the registration sensor	The registration sensor does not operate properly.	Execute U031 [Regist]. If the registration sensor does not operate properly, clean and reattach it then reconnect the connector. If not repaired, replace it.	
2	Checking the PF conveying clutch	PF conveying clutch does not operate correctly.	If the PF conveying clutch does not operate normally, replace the PF drive unit.	
3	Replacing the PF PWB	The PF PWB is faulty.	Replace the PF PWB.	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J4201/J4202/J4203/J4208/J4209: Eject sensor non-arrival jam

The exit sensor does not turn on during paper feed from cassette 1-3, duplex section or MP tray.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the actuator	The actuator or exit sensor connecting section does not operate properly.	Move the actuator for the exit sensor in the fuser unit and check the joint section operates normally and the exit sensor turns on. If not, correct the actuator or replace the fuser unit.	
2	Checking the paper setting	The actual paper and the paper settings (paper weight, media type, etc.) do not match.	Change to the proper paper setting from System Menu	
3	Checking the fuser heat roller/ Fuser pressure roller/front fuser guide	Foreign objects adhere to the fuser heat roller, Fuser pressure roller or fuser front guide	Clean the fuser heat roller, Fuser pressure roller and fuser front guide. If not repaired, replace the fuser unit.	
4	Checking the fuser separation claws	Foreign materials such as toner adhere on the fuser separation nails. Or the fuser separation nails are deformed or improperly attached.	If toner, etc. adhere on the fuser separation nails, remove them. If it is deformed, replace the fuser unit.	
5	Checking the leading edge margin	The leading edge margin is insufficient	Execute U034 [Adj Paper Timing] and adjust the leading edge timing.	
6	Checking the exit sensor	The exit sensor does not operate properly.	Execute U031 [Fuser]. If the exit sensor does not operate properly, clean and reattach it then reconnect the connector. If not repaired, replace it.	
7	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J4211/J4212/J4213/J4218/J4219: Eject sensor stay jam

The exit sensor does not turn off during paper feed from cassette 1-3, duplex section or MP tray.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the fuser exit guide	Paper is caught up at the fuser exit guide.	If welding of toner, burrs are on the conveying surface of the fuser exit guide, remove them or replace the fuser exit guide.	
2	Checking the exit guide	Paper is caught up at the exit guide	If welding of toner, burrs are on the fuser exit guide, remove or replace them.	
3	Checking the exit roller and the drive parts	The exit roller or drive parts do not operate correctly.	Check if the exit motor drive is transmitted to the upper/lower exit roller. if the drive gears is damaged or the bushing is worn down, replace it.	
4	Checking the actuator	The actuator or exit sensor connecting section does not operate properly.	Move the actuator for the exit sensor in the fuser unit and check the joint section operates normally and the exit sensor turns on. If not, correct the actuator or replace the fuser unit.	
5	Checking the exit sensor	The exit sensor does not operate properly.	Execute U031 [Fuser]. If the exit sensor does not operate properly, clean and reattach it then reconnect the connector. If not repaired, replace it.	
6	Checking the exit motor	The exit motor does not operate correctly.	Execute U030 [Exit]. If the exit motor does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
7	Checking the feed-shift solenoid	The feed-shift solenoid does not operate normally.	Execute U033 [Eject] to check the exit feed-shift guide operation. If it does not operate correctly, reattach the solenoid and reconnect the connector. If not repaired, replace it.	
8	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J4301/J4302/J4303/J4309: DU sensor non-arrival jam

The DU sensor does not turn on when feeding from cassette 1-3 or MP tray

Step	Check description	Assumed cause	Measures	Reference
1	Checking the exit guide	Paper is caught up at the exit guide	If welding of toner, burrs are on the fuser exit guide, remove or replace them.	
2	Checking the exit roller and the drive parts	The exit roller or drive parts do not operate correctly.	Check if the exit motor drive is transmitted to the upper/lower exit roller. if the drive gears is damaged or the bushing is worn down, replace it.	
3	Checking the feed-shift solenoid	The feed-shift solenoid does not operate normally.	Execute U033 [Eject] to check the exit feed-shift guide operation. If it does not operate correctly, reattach the solenoid and reconnect the connector. If not repaired, replace it.	
4	Checking the exit motor	The exit motor does not operate correctly.	Execute U030 [Exit]. If the exit motor does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
5	Checking the DU conveying roller	Conveying capability of the DU conveying roller is not enough.	Clean the DU conveying roller. If the surface is worn down, replace it.	
6	Checking the DU conveying pulley	Pressure of the DU conveying pulley is not enough.	Check the DP conveying pulley. If the pressing parts are deformed or damaged, replace them.	

Step	Check description	Assumed cause	Measures	Reference
7	Checking the DU sensor	DU sensor does not operate correctly.	Execute U031 [DU1]. If DU sensor does not operate properly, clean and reattach it then reconnect the connector. If not repaired, replace it.	
8	Checking the DU clutch	DU clutch does not operate correctly.	Execute U032 [Dup]. If the DU clutch does not operate normally, replace the drive unit.	
9	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J4311/J4312/J4313/J4319: DU sensor stay jam

The DU sensor does not turn off when feeding from cassette 1-3 or MP tray

Step	Check description	Assumed cause	Measures	Reference
1	Checking the DU conveying roller	Conveying capability of the DU conveying roller is not enough.	Clean the DU conveying roller. If the surface is worn down, replace it.	
2	Checking the DU conveying pulley	Pressure of the DU conveying pulley is not enough.	Check the DP conveying pulley. If the pressing parts are deformed or damaged, replace them.	
3	Checking the DU sensor	DU sensor does not operate correctly.	Execute U031 [DU1]. If DU sensor does not operate properly, clean and reattach it then reconnect the connector. If not repaired, replace it.	
4	Checking the DU clutch	DU clutch does not operate correctly.	Execute U032 [Dup]. If the DU clutch does not operate normally, replace the drive unit.	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J4901/J4902/J4903/J4908/J4909: BR conveying sensor 2 non-arrival jam

BR conveying sensor 2 does not turn on during paper feed from cassette 1-3, duplex section or MP tray.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the BR conveying belt	The BR conveying belt comes off.	Check the BR conveying belt and reattach it	
2	Checking the conveying guide	The foreign objects such as toner are on the conveying guide.	Clean or replace the conveying guide.	
3	Checking the paper conveying roller	Conveying capability of the conveying roller is not enough.	Clean the conveying roller. If the surface is worn out, replace it.	
4	Checking BR conveying sensor 2	BR conveying sensor 2 does not operate correctly.	Reattach and reconnect BR conveying sensor 2. If not repaired, replace it.	
5	Checking the BR conveying motor	The BR conveying motor does not operate correctly.	Reconnect the connector of the DP conveying motor. If it is not fixed, replace it.	
6	Replacing the BR PWB	The BR PWB is faulty.	Replace the BR PWB.	
7	Replacing the DF relay PWB	The DF relay PWB is faulty	Replace the DF relay PWB.	
8	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J4911/J4912/J4913/J4918/J4919: BR conveying sensor 2 stay jam

BR conveying sensor 2 does not turn off during paper feed from cassette 1-3, duplex section or MP tray.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the conveying guide	The foreign objects such as toner are on the conveying guide.	Clean or replace the conveying guide.	
2	Checking the paper conveying roller	Conveying capability of the conveying roller is not enough.	Clean the conveying roller. If the surface is worn out, replace it.	
3	Checking BR conveying sensor 2	BR conveying sensor 2 does not operate correctly.	Reattach and reconnect BR conveying sensor 2. If not repaired, replace it.	
4	Replacing the BR PWB	The BR PWB is faulty.	Replace the BR PWB.	
5	Replacing the DF relay PWB	The DF relay PWB is faulty	Replace the DF relay PWB.	
6	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J5001/J5002/J5003/J5008/J5009: BR conveying sensor 3 non-arrival jam

BR conveying sensor 3 does not turn on during paper feed from cassette 1-3, duplex section or MP tray.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the conveying guide	The foreign objects such as toner are on the conveying guide.	Clean or replace the conveying guide.	
2	Checking the paper conveying roller	Conveying capability of the conveying roller is not enough.	Clean the conveying roller. If the surface is worn out, replace it.	
3	Checking BR conveying sensor 3	BR conveying sensor 3 does not operate correctly.	Reattach and reconnect BR conveying sensor 3. If not repaired, replace it.	
4	Replacing the BR PWB	The BR PWB is faulty.	Replace the BR PWB.	
5	Replacing the DF relay PWB	The DF relay PWB is faulty	Replace the DF relay PWB.	
6	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J5011/J5012/J5013/J5018/J5019: BR conveying sensor 3 stay jam

BR conveying sensor 3 does not turn off during paper feed from cassette 1-3, duplex section or MP tray.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the conveying guide	The foreign objects such as toner are on the conveying guide.	Clean or replace the conveying guide.	
2	Checking the paper conveying roller	Conveying capability of the conveying roller is not enough.	Clean the conveying roller. If the surface is worn out, replace it.	
3	Checking BR conveying sensor 3	BR conveying sensor 3 does not operate correctly.	Reattach and reconnect BR conveying sensor 3. If not repaired, replace it.	
4	Replacing the BR PWB	The BR PWB is faulty.	Replace the BR PWB.	
5	Replacing the DF relay PWB	The DF relay PWB is faulty	Replace the DF relay PWB.	
6	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

J6023: DF staple cover open jam

The DF staple cover open is detected during the DF operation

Step	Check description	Assumed cause	Measures	Reference
1	Checking the DF staple cover	The DF front cover is not aligned to the other exterior covers.	Check if the DF staple cover is closed firmly and reattach it if necessary. If the DF staple cover is deformed, repair or replace it.	

Step	Check description	Assumed cause	Measures	Reference
2	Checking the DF staple cover switch	The DF staple cover switch does not operate normally	Check the DF staple cover switch. If not operating normally, reattach it and reconnect the connector. If not repaired, replace it.	
3	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J6043: DF top cover open jam

The DF top cover open is detected during the DF operation

Step	Check description	Assumed cause	Measures	Reference
1	Checking the DF top cover	The DF top cover is not aligned to the other exterior covers.	Check if the DF top cover is closed firmly and reattach the DF top cover if necessary. If the DF top cover is deformed, repair or replace it.	
2	Checking the DF top cover sensor	The DF top cover sensor does not operate correctly.	Check the DF top cover sensor. If it does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
3	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J6103: DF conveying sensor jam

The DF conveying sensor does not turn on after passing the specific time since the paper output signal from the main unit was received.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the conveying guide	The foreign objects such as toner are on the conveying guide.	Clean or replace the conveying guide.	
2	Checking the paper conveying roller	Conveying capability of the conveying roller is not enough.	Clean the conveying roller. If the surface is worn out, replace it.	
3	Checking the DF conveying sensor	The DF entry sensor does not operate correctly.	Check the DF entry sensor. If it does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
4	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J6113: DF conveying stay jam

The DF conveying sensor does not turn off when passing the specific time after it turns on

Step	Check description	Assumed cause	Measures	Reference
1	Checking the conveying guide	The foreign objects such as toner are on the conveying guide.	Clean or replace the conveying guide.	
2	Checking the paper conveying roller	Conveying capability of the conveying roller is not enough.	Clean the conveying roller. If the surface is worn out, replace it.	
3	Checking the DF conveying sensor	The DF entry sensor does not operate correctly.	Check the DF entry sensor. If it does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
4	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J6123: DF conveying sensor stay jam

The conveying sensor detects paper at power-up or cover close

Step	Check description	Assumed cause	Measures	Reference
1	Checking the conveying guide	The foreign objects such as toner are on the conveying guide.	Clean or replace the conveying guide.	
2	Checking the paper conveying roller	Conveying capability of the conveying roller is not enough.	Clean the conveying roller. If the surface is worn out, replace it.	
3	Checking the DF conveying sensor	The DF conveying sensor does not operate normally.	Check the DF conveying sensor. If not operating normally, reattach it and reconnect the connector. If not repaired, replace it.	
4	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J6413: DF exit sensor stay jam

During the bundle eject operation, the DF exit sensor does not detect no paper when passing the specified time.

Step	Check description	Assumed cause	Measures	Reference
1	Checking DF adjustor tray	Foreign objects such as toner, etc. adhere to the DF adjustor tray	Clean the DF adjustor tray or replace it	
2	Checking the exit roller	The paper conveying force of the exit roller is insufficient.	Clean the exit roller. If the surface is worn out, replace it.	
3	Checking the DF exit sensor	The DF exit sensor does not operate correctly.	Check the DF exit sensor. If it does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
4	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J6423: DF exit sensor stay jam

The DF exit sensor detects paper at power-up or cover close

Step	Check description	Assumed cause	Measures	Reference
1	Checking DF adjustor tray	Foreign objects such as toner, etc. adhere to the DF adjustor tray	Clean the DF adjustor tray or replace it	
2	Checking the exit roller	The paper conveying force of the exit roller is insufficient.	Clean the exit roller. If the surface is worn out, replace it.	
3	Checking the DF exit sensor	The DF exit sensor does not operate correctly.	Check the DF exit sensor. If it does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
4	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J6803: Front adjustor plate operation on error

The DF adjusting sensor 1 does not turn on after passing the specified time when executing jobs

Step	Check description	Assumed cause	Measures	Reference
1	Checking DF adjusting sensor 1	DF adjusting sensor 1 does not operate normally	Check the DF adjusting sensor 1. If not operating normally, reattach it and reconnect the connector. If not repaired, replace it.	
2	Checking the DF adjusting motor 1	DF adjusting motor 1 does not operate normally	Check the DF adjusting motor 1. If not operating normally, reattach it and reconnect the connector. If not repaired, replace it.	
3	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J6813: Front adjustor plate operation off error

The DF adjusting sensor 1 does not turn off after passing the specified time when executing jobs

Step	Check description	Assumed cause	Measures	Reference
1	Checking DF adjusting sensor 1	DF adjusting sensor 1 does not operate normally	Check the DF adjusting sensor 1. If not operating normally, reattach it and reconnect the connector. If not repaired, replace it.	
2	Checking the DF adjusting motor 1	DF adjusting motor 1 does not operate normally	Check the DF adjusting motor 1. If not operating normally, reattach it and reconnect the connector. If not repaired, replace it.	
3	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J6903: Rear adjustor plate operation on error

The DF adjusting sensor 2 does not turn on after passing the specified time when executing jobs

Step	Check description	Assumed cause	Measures	Reference
1	Checking DF adjusting sensor 2	DF adjusting sensor 2 does not operate normally	Check the DF adjusting sensor 2. If not operating normally, reattach it and reconnect the connector. If not repaired, replace it.	
2	Checking the DF adjusting motor 2	DF adjusting motor 2 does not operate normally	Check the DF adjusting motor 2. If not operating normally, reattach it and reconnect the connector. If not repaired, replace it.	
3	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J6913: Rear adjustor plate operation off error

The DF adjusting sensor 2 does not turn off after passing the specified time when executing jobs

Step	Check description	Assumed cause	Measures	Reference
1	Checking DF adjusting sensor 2	DF adjusting sensor 2 does not operate normally	Check the DF adjusting sensor 2. If not operating normally, reattach it and reconnect the connector. If not repaired, replace it.	
2	Checking the DF adjusting motor 2	DF adjusting motor 2 does not operate normally	Check the DF adjusting motor 2. If not operating normally, reattach it and reconnect the connector. If not repaired, replace it.	
3	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J7013: Staple operation error

When starting the clinch operation, the initial setting of the staple for the next bundle is not ready after passing the specified time.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the staple	Check if the upper BF registration guide shifts manually, and reattach it if it does not smoothly shift.	Check if the lower BF registration guide shifts manually, and reattach it if it does not smoothly shift.	
2	Replacing the DF staple unit	The DF staple unit is faulty.	Replace the DF staple unit.	
3	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J7023: Staple initial operation error

During the initial operation at power-up or cover close, when the staple supply operation is performed 10 time, the initial setting of the staple is not available.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the staple	Check if the upper BF registration guide shifts manually, and reattach it if it does not smoothly shift.	Check if the lower BF registration guide shifts manually, and reattach it if it does not smoothly shift.	
2	Replacing the DF staple unit	The DF staple unit is faulty.	Replace the DF staple unit.	
3	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J7913: Sequence error 1

Operation start=1 during Finisher operation permission=0

Step	Check description	Assumed cause	Measures	Reference
1	Firmware upgrade	Firmware mismatches	Upgrade the firmware to the latest version.	
2	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J7923: Sequence error 2

Maintenance mode request has occurred during Finisher operation permission = 0 or Operation start = 1

Step	Check description	Assumed cause	Measures	Reference
1	Firmware upgrade	Firmware mismatches	Upgrade the firmware to the latest version.	
2	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J7933: Sequence error 3

Backup data command 1 is received at operation start=1

Step	Check description	Assumed cause	Measures	Reference
1	Firmware upgrade	Firmware mismatches	Upgrade the firmware to the latest version.	
2	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J7943: Sequence error 4

Operation start=1 is received during standby=0

Step	Check description	Assumed cause	Measures	Reference
1	Firmware upgrade	Firmware mismatches	Upgrade the firmware to the latest version.	
2	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J7953: Sequence error 5

Paper interval and bundle interval are not normal.

Step	Check description	Assumed cause	Measures	Reference
1	Firmware upgrade	Firmware mismatches	Upgrade the firmware to the latest version.	
2	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J7963: Sequence error 6

The exit finish command is not sent from the finisher when passing 15s after the BR exit sensor turns off

Step	Check description	Assumed cause	Measures	Reference
1	Firmware upgrade	Firmware mismatches	Upgrade the firmware to the latest version.	
2	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

J9000: No original feed

The DP feed sensor does not turn on after the paper feed was retried.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the original	The original leading edge has a dog-ear, is curled, wavy or others.	Correct or replace the original	
2	Checking the original	The original out of specification is used.	Explain users to use the original within the specifications.	
3	Checking the original	Foreign objects adhere on the original.	If foreign objects adhere, remove them	
4	Checking the original	The originals are stapled	Remove the staple	
5	Checking the original	Too many originals are loaded	Reduce the original stack volume to the specified	
6	Checking the original width guides	The location of the original width guides and the original size are mismatched.	Align the original width guides to the original size.	
7	Checking the paper path	The original is caught up by a piece of paper.	If there is a piece of paper, foreign objects on the conveying path, remove them.	
8	Checking the pickup pulley	The conveying function of the pickup pulley is not enough.	Clean the pickup pulley surface. If worn down, replace it.	
9	Checking the DP feed roller	The paper conveying force of the DP feed roller is insufficient.	Clean the DP feed roller surface. If worn down, replace it.	
10	Checking the DP feed sensor	The DP feed sensor does not operate correctly.	Execute U244 [Feed]. If the DP feed sensor does not operate normally, check the actuator, spring and sensor connector. If not repaired, replace the sensor.	
11	Checking the DP feed clutch	The DP feed clutch does not operate correctly.	Check the DP feed clutch. If it does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
12	Checking the DP feed motor	The DP feed motor does not operate correctly.	Execute U243 [Feed Motor]. If the DP feed motor does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
13	Replacing the DP PWB	The DP PWB is faulty.	Replace the DP PWB.	

J9001: DP conveying jam

The DP timing sensor off is detected before the specified time after it turns on

Step	Check description	Assumed cause	Measures	Reference
1	Checking the original	The original out of specification is fed.	Explain users to use the original within the specifications.	

Step	Check description	Assumed cause	Measures	Reference
2	Checking the DP timing sensor	DP timing sensor does not operate correctly.	Execute U244 [Timing]. If the DP timing sensor does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
3	Replacing the DP PWB	The DP PWB is faulty.	Replace the DP PWB.	

J9002: Paper jam detected when starting the paper conveying

An unspecified conveying sensor turns on when starting paper conveying.

Step	Check description	Assumed cause	Measures	Reference
1	Specifying the sensor	Specify the sensor which is turned on	Specified the sensor turning on at U244 and go to the next step	
2	Checking the paper path	There is a piece of paper remaining on the paper conveying path to turn on the sensor.	If there is a piece of paper, foreign objects, etc. the conveying path, remove them.	
3	Checking the sensor	The sensor does not operate correctly.	Clean and reattach the sensor specified at U244 and reconnect the connector. If not repaired, replace it.	
4	Replacing the DP PWB	The DP PWB is faulty.	Replace the DP PWB.	

J9004: DP switchback jam

During the reversing duplex scanning, the DP registration sensor does not turn on when passing the specified time after the DP timing sensor turns off.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper path	The original is caught up by a piece of paper.	If there is a piece of paper, foreign objects on the conveying path, remove them.	
2	Checking the DP conveying roller	The paper conveying performance of the DP conveying roller is insufficient.	Clean the DP conveying roller surface. If worn down, replace it.	
3	Checking the DP feed-shift guide	The original is hooked with the DP feed-shift guide.	Check the DP feed-shift guide. If deformed, replace it.	
4	Checking the DP feed-shift motor	The DP feed-shift motor does not operate correctly.	Execute U243 [Rev Motor]. If the DP feed-shift motor does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
5	Checking the DP feed-shift sensor	The DP feed-shift sensor does not operate correctly.	Reattach the DP feed-shift sensor and reconnect the connector. If not repaired, replace it.	
6	Checking the DP registration sensor	The DP registration sensor does not operate correctly.	Execute U244 [Regist]. If the DP registration sensor does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
7	Replacing the DP PWB	The DP PWB is faulty.	Replace the DP PWB.	

J9010: DP cover open jam

The DP is opened during the original conveying

Step	Check description	Assumed cause	Measures	Reference
1	Checking the DP	The DP is not connected properly	Check if the DP is closed securely. Reattach it if necessary.	
2	Checking the DP opening/closing switch	The DP opening/closing switch does not operate properly.	Execute U244 [Option]. If the DP open/close switch does not operate normally, reattach it and reconnect the connector.	
3	Replacing the DP PWB	The DP PWB is faulty.	Replace the DP PWB.	

J9011: DP top cover open jam

The DP top cover opens during the original conveying.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the DP top cover	The DP top cover is faulty.	Check if the DP top cover closes securely and reattach it if necessary. If the DP top cover is deformed, repair or replace it.	
2	Checking the DP top cover switch	The DP top cover switch does not operate properly.	Execute U244 [Cover Open]. If the DP top cover switch does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
3	Replacing the DP PWB	The DP PWB is faulty.	Replace the DP PWB.	

J9110: DP feed sensor multi-feeding jam

The DP feed sensor or DP registration sensor does not turn off after passing the specific time after the DP timing sensor turned on.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the original	The original leading edge has a dog-ear, is curled, wavy or others.	Correct or replace the original	
2	Checking the original	The original out of specification is used.	Explain users to use the original within the specifications.	
3	Checking the front DP separation pad and DP separation pulley	The paper separation force of the DP front separation pad and DP separation pulley is not enough	Clean the DP front separation pad and DP separation pulley. If worn down, replace them.	
4	Checking the DP feed sensor and DP registration sensor	The DP feed sensor or DP registration sensor does not operate normally	Clean and reattach the DP feed sensor and DP registration sensor and then reconnect the connector. If not repaired, replace it.	
5	Checking the DP feed clutch	The rotation of the DP feed roller does not stop while the DP feed clutch remains engaged.	Check the DP feed clutch. If it does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
6	Replacing the DP PWB	The DP PWB is faulty.	Replace the DP PWB.	

J9200: DP registration sensor non-arrival jam

The DP registration sensor does not turn on when passing the specified time after the DP timing sensor turns on

Step	Check description	Assumed cause	Measures	Reference
1	Checking the original	The original leading edge has a dog-ear, is curled, wavy or others.	Correct or replace the original	

Step	Check description	Assumed cause	Measures	Reference
2	Checking the original	The original out of specification is used.	Explain users to use the original within the specifications.	
3	Checking the original width guides	The location of the original width guides and the original size are mismatched.	Align the original width guides to the original size.	
4	Checking the paper path	The original is caught up by a piece of paper.	If there is a piece of paper, foreign objects on the conveying path, remove them.	
5	Checking the DP registration sensor	The DP registration sensor does not operate correctly.	Execute U244 [Regist]. If the DP registration sensor does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
6	Replacing the DP PWB	The DP PWB is faulty.	Replace the DP PWB.	

J9400: DP timing sensor non-arrival jam

The DP timing sensor does not turn on when passing the specified time after the DP registration sensor turns

Step	Check description	Assumed cause	Measures	Reference
1	Checking the original	The original leading edge has a dog-ear, is curled, wavy or others.	Correct or replace the original	
2	Checking the original	The original out of specification is used.	Explain users to use the original within the specifications.	
3	Checking the original width guides	The location of the original width guides and the original size are mismatched.	Align the original width guides to the original size.	
4	Checking the paper path	The original is caught up by a piece of paper.	If there is a piece of paper, foreign objects on the conveying path, remove them.	
5	Checking the DP timing sensor	DP timing sensor does not operate correctly.	Execute U244 [Timing]. If the DP timing sensor does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
6	Replacing the DP PWB	The DP PWB is faulty.	Replace the DP PWB.	

J9410: DP timing sensor stay jam

The DP timing sensor does not turn off when passing the specified time after it turns on

Step	Check description	Assumed cause	Measures	Reference
1	Checking the original	The original leading edge has a dog-ear, is curled, wavy or others.	Correct or replace the original	
2	Checking the original	The original out of specification is used.	Explain users to use the original within the specifications.	
3	Checking the original width guides	The location of the original width guides and the original size are mismatched.	Align the original width guides to the original size.	
4	Checking the paper path	The original is caught up by a piece of paper.	If there is a piece of paper, foreign objects on the conveying path, remove them.	
5	Checking the DP conveying roller	The paper conveying performance of the DP conveying roller is insufficient.	Clean the DP conveying roller surface. If worn down, replace it.	

Step	Check description	Assumed cause	Measures	Reference
6	Checking the DP timing sensor	DP timing sensor does not operate correctly.	Execute U244 [Timing]. If the DP timing sensor does not operate correctly, reattach it and reconnect the connector. If not repaired, replace it.	
7	Replacing the DP PWB	The DP PWB is faulty.	Replace the DP PWB.	

(4) Other Feeding/Conveying Failures

No.	Contents	Condition
(1)	Paper creases (Fuser factor)	
(2)	Paper creases (Registration or Transfer factor)	

Content of Feeding/Conveying Failures

(4-1) Paper creases (Fuser factor)

Condition: The image is printed on the crease section. (Fuser factor)

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper	Paper is curled caused by the moisture absorption. Or, paper leading edge is waving.	Flip paper upside down and reset. Or, replace with new paper which is unopened paper.	
2	(When the paper is skewed) Checking the rear transfer guide and the discharge needle.	Paper is caught in the rear transfer guide, discharge needle, a piece of paper, etc..	If a piece of paper or foreign objects are on the conveying path, or foreign objects or burrs are on the rear transfer guide or the discharge needle, remove them or replace them.	
3	(If occurring under a specific condition) Changing the setting	The actual paper and the paper settings (media type, paper size) do not match.	Set the proper media type via the System Menu.	
4	Checking the paper storage place	Paper is stored in a damp place.	Install the cassette heater if necessary. Also, ask users to store paper in a dry place.	
5	Checking the transfer roller	The transfer roller is dirty with the toner, paper dust or others, or it is worn down.	Clean the transfer roller. If the surface is worn down, replace it.	
6	Replacing the fuser unit	The center of the fuser pressure roller is worn out. The front and rear pressure spring are not attached properly.	Check the pressure balance of both ends of the fuser unit by checking the nipped pressure on the solid image. If the balance is uneven, replace the fuser unit.	

(4-2) Paper creases (Registration or Transfer factor)

Condition: The image is not printed on the crease section. (Registration, transfer factor)

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper	The paper is curled downward or wavy.	Correct or replace paper. If you cannot get user agreement about the paper replacement, relocate the leading end of paper and the trailing end or reload paper upside down.	
2	Checking the paper	foreign objects are on the paper.	Remove paper that the foreign objects adhere from the cassette.	
3	Opening and reclosing the right cover	The right cover is not firmly closed.	Open the right cover (conveying unit) once, and close it firmly.	
4	(When the paper is being conveyed obliquely) Resetting the paper width guide or MP paper width guide	The set position of the paper width guides / MP paper width guides is mismatched with the paper size, and so, the paper is skewed.	Reset the paper width guide or the MP paper width guide matches to paper size. Or, check set position of the support guide. (Excluding the cassette1)	

Step	Check description	Assumed cause	Measures	Reference
5	Checking the paper feed roller	The conveying function of the paper feed roller is not enough.	Clean the paper feed roller surface. If worn down, replace it.	
6	Checking the conveying rollers	Conveying related rollers are not attached properly. Or, the conveying capability is not enough due to dirty.	Clean the surface of the conveying related rollers and the pulleys (vertical conveying, middle, registration) and reattach.	
7	(When paper is skewed) Checking the pressure spring	Pressure balance is not good because the pressure spring of front and back of the roller are not attached properly.	Check the pressure of the conveying related rollers and the pulleys, and if the spring or the bearings are dropped off, reattach them. If they are deformed or worn out, replace them.	
8	(When the paper skew occurs) Checking the paper path	Paper is caught at the conveying guide, piece of paper, etc..	If a piece of paper, the foreign objects are on the conveying path, or the foreign objects, a burr are on the conveying surface of the conveying guide, remove or replace them. If the sheet guide material has a damage, deformation, floating, repair or replace them.	

7 - 3 Self Diagnostic

If the part causing the problem was not supplied, use the unit including the part for replacement.



Caution

Before attempting to check the fuser unit and the low voltage power supply PWB, be sure to turn the power switch off and unplug the machine from power.

Even if the power switch of the main unit is turned off and the power cord is unplugged, the electric charge may remain in the capacitors on the low voltage PWB, so that please be careful not to touch the mounted parts to protect you from electric shock.

(1) Self diagnostic error codes

(1-1) Error codes list

Error code	Contents
C0030	FAX PWB system error
C0060	Engine PWB communication error
C0070	FAX PWB incompatible detection error
C0100	Backup memory device error
C0120	MAC address data error
C0130	Backup memory reading/writing error
C0140	Backup memory data error
C0150	Engine EEPROM reading / writing error
C0160	EEPROM data error
C0170	Charger count error
C0180	Machine serial number mismatch
C0190	Backup memory device error (Engine)
C0500	Drive lock detected by the Engine firmware
C0510	High-voltage remote control error
C0520	Developer control error
C0530	Backup task error
C0540	Engine firmware unexpected control detection
C0800	Image processing error
C0830	FAX PWB flash program area checksum error
C0840	RTC error
C0870	PC FAX Image data transmission error
C0920	FAX file system error
C0980	24V power interruption detection
C1010	Lift motor 1 error
C1020	PF lift motor 1 error
C1030	PF lift motor 2 error
C1800	Paper Feeder communication error
C1900	Paper Feeder EEPROM error
C2000	Main motor steady state error
C2010	Main motor startup error
C2101	Developer motor steady state error
C2111	Developer motor start-up error
C2300	Fuser motor steady state error

Error code	Contents
C2310	Fuser motor start-up error
C2600	PF motor error
C3100	Carriage error
C3100	Carriage error
C3200	LED error
C3200	CISerror
C3300	CCD AGC error
C3300	CIS AGC error
C3500	Scanner AISC communication error
C3600	Scanner sequence error
C4001	Polygon motor synchronization error
C4011	Polygon motor steady-state error
C4101	BD initialization error
C5101	Main high-voltage error
C6000	Fuser main heater broken wire
C6020	Fuser thermopile error
C6030	Fuser thermopile wire break detection
C6050	Fuser thermopile low temperature error
C6200	Broken fuser sub heater
C6220	Fuser thermistor high temperature error
C6230	Broken fuser thermistor detection
C6250	Fuser thermistor low temperature error
C6400	Zero-cross signal error
C6610	Pressure release error
C6650	Fuser thermopile EEPROM error
C7200	Inner thermistor broken (developer)
C7210	Inner thermistor short-circuited (developer)
C7800	Outer thermistor broken
C7810	Outer thermistor short-circuited
C8030	DF tray upper limit detection error
C8040	DF belt error
C8140	Dr tray motor error
C8210	DF staple error
C8320	DF adjuster motor 2 error
C8330	DF adjuster motor 1error
C8350	DF roller motor error
C8360	DF slide motor error
C8460	EEPROM error
C8800	Document finisher communication error
C8830	Relay conveying unit communication error
C8990	Finisher setup error
C9000	DP communication error
C9060	DP EEPROM error

Content of Self Diagnostic

C0030: FAX PWB system error

The FAX processing cannot be continued due to the FAX firmware error.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The FAX PWB does not operate properly.	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Firmware upgrade	The firmware is faulty.	Reinstall the FAX firmware.	
3	Replacing the FAX PWB	The FAX PWB is faulty.	Replace the FAX PWB.	

C0060: Engine PWB communication error

Error was detected at the initial communication of the Engine PWB

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The Engine PWB does not operate properly.	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Checking the connection	The connector is not properly connected.	Clean the connector (YC12) terminal on the Engine PWB and re-insert the connector	
3	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C0070: FAX PWB incompatible detection error

Abnormal detection of FAX control PWB incompatibility in the initial communication with the FAX control PWB, any normal communication command is not transmitted.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the FAX PWB	The incompatible FAX PWB is installed.	Install the FAX PWB for the applicable model.	
2	Firmware upgrade	The FAX firmware is faulty.	Reinstall the FAX firmware.	
3	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

C0100: Backup memory device error

An abnormal status is output from the flash memory.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The flash memory does not operate properly.	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Checking the main PWB	The connector or the FFC is not connected properly. Or, the wire, FFC, the PWB is faulty.	Clean the terminal of the connectors on the main PWB, reconnect the connector of the wire, and reconnect the FFC terminal. If the wire or the FFC is faulty, repair or replace them. If not resolved, replace the main PWB.	

C0120: MAC address data error

The MAC address data is incorrect.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The flash memory does not operate properly.	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Checking the MAC address	The MAC address is incorrect.	Replace the main PWB when the MAC address is not indicated on the network status page.	

C0130: Backup memory reading/writing error

The reading or writing into the flash memory is unavailable.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The flash memory does not operate properly.	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Checking the main PWB	The connector or the FFC is not connected properly. Or, the wire, FFC, the PWB is faulty.	Clean the terminal of the connectors on the main PWB, reconnect the connector of the wire, and reconnect the FFC terminal. If the wire or the FFC is faulty, repair or replace them. If not resolved, replace the main PWB.	

C0140: Backup memory data error

The flash memory data read at the initial start-up is faulty

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The flash memory does not operate properly.	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Checking the main PWB	The connector or the FFC is not connected properly. Or, the wire, FFC, the PWB is faulty.	Clean the terminal of the connectors on the main PWB, reconnect the connector of the wire, and reconnect the FFC terminal. If the wire or the FFC is faulty, repair or replace them. If not resolved, replace the main PWB.	

C0150: Engine EEPROM reading / writing error

1. Continuous five times detection of no response from the device for 5ms or more on reading / writing.
2. Data read twice do not match continuous 8 times.
3. Writing data and reading data do not match continuous 8 times.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The EEPROM on the Engine PWB does not operate properly.	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Checking the EEPROM on the Engine PWB	The EEPROM is not properly attached.	Reattach the EEPROM on the Engine PWB.	

Step	Check description	Assumed cause	Measures	Reference
3	Replacing the EEPROM	The EEPROM is faulty.	1. Print Maintenance Report at U000 beforehand. 2. Replace the EEPROM on the Engine PWB. C0180 appears when turning the power on. Execute U004 at that state. 3. Then, print Maintenance Report at U000. Compare the setting values with Maintenance Report printed before and change the different values. (Target maintenance mode: U051, U065, U067, U100, U101, U161, etc.) 4. Check the output image and adjust the image at U410, etc. if necessary.	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C0160: EEPROM data error

The data read from the EEPROM is judged as abnormal.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The EEPROM on the Engine PWB does not operate properly.	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Executing U021	The storage data in the EEPROM on the Engine PWB is faulty.	Execute U021.	
3	Replacing the EEPROM	The EEPROM is faulty.	1. Print Maintenance Report at U000 beforehand. 2. Replace the EEPROM on the Engine PWB. C0180 appears when turning the power on. Execute U004 at that state. 3. Then, print Maintenance Report at U000. Compare the setting values with Maintenance Report printed before and change the different values. (Target maintenance mode: U051, U065, U067, U100, U101, U161, etc.) 4. Check the output image and adjust the image at U410, etc. if necessary.	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C0170: Charger count error

1. Errors are detected in both backup memory of the Engine PWB charge counter and main PWB charge counter.
2. Main PWB counter data and Engine PWB counter date are faulty

Step	Check description	Assumed cause	Measures	Reference
1	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB and execute U004	

Step	Check description	Assumed cause	Measures	Reference
2	Replacing the EEPROM on the Engine PWB	The EEPROM is faulty.	<ol style="list-style-type: none"> 1. Print Maintenance Report at U000 beforehand. 2. Replace the EEPROM on the Engine PWB. C0180 appears when turning the power on. Execute U004 at that state. 3. Then, print Maintenance Report at U000. Compare the setting values with Maintenance Report printed before and change the different values. (Target maintenance mode: U051, U065, U067, U100, U101, U161, etc.) 4. Check the output image and adjust the image at U410, etc. if necessary. 	
3	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C0180: Machine serial number mismatch

The machine serial Nos. in the main PWB and the EEPROM on the Engine PWB mismatch when turning the power on.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the machine serial No. of the main PWB	The main PWB for the different main unit is installed.	Check the machine serial Nos of MAIN and Engine at U004, and install the correct main PWB if the MAIN No. differs.	
2	Checking the machine serial No. in the EEPROM on the Engine PWB	The EEPROM for the different main unit is installed.	Check the machine serial Nos of MAIN and Engine at U004, and install the correct EEPROM on the Engine PWB if the Engine machine serial No. differs.	
3	Replacing the main PWB	The main PWB is faulty.	When the MAIN machine serial No. differs at U004, replace the main PWB and execute U004.	
4	Checking the EEPROM on the Engine PWB	The EEPROM is faulty.	<p>If the machine serial number on the Engine PWB is different at U004, reattach the EEPROM. If not repaired, replace the EEPROM on the Engine PWB.</p> <ol style="list-style-type: none"> 1. Print Maintenance Report at U000 beforehand. 2. Replace the EEPROM on the Engine PWB. C0180 appears when turning the power on. Execute U004 at that state. 3. Then, print Maintenance Report at U000. Compare the setting values with Maintenance Report printed before and change the different values. (Target maintenance mode: U051, U065, U067, U100, U101, U161, etc.) 4. Check the output image and adjust the image at U410, etc. if necessary. 	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C0190: Backup memory device error (Engine)

Data from the main unit IC cannot be read out at power-up

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The IC in the Engine PWB does not operate normally	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C0500: Drive lock detected by the Engine firmware

During the Engine steady state control, the main motor drive continued 60 minutes or more (except during the maintenance mode)

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The firmware in the Engine PWB does not operate normally	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C0510: High-voltage remote control error

Only the high-voltage remote signal turns on while the drum is stopped

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The firmware in the Engine PWB does not operate normally	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C0520: Developer control error

The developer bias off is detected during the main charge bias off

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The firmware in the Engine PWB does not operate normally	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C0530: Backup task error

No operation 30s or more when monitoring the backup task operation

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The firmware in the Engine PWB does not operate normally	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C0540: Engine firmware unexpected control detection

Eject switching solenoid turned on over the specified time

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The firmware in the Engine PWB does not operate normally	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C0800: Image processing error

The print sequence jam (J010x) is detected 2 times continuously.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the image data	The image data is faulty.	When this issue occurs only when handling the certain image data, check if the image data is faulty.	
2	Checking the situation	The printing operation of the certain file is faulty.	Acquire the job's log if the phenomenon can be reproduced by specifying the job when the error was detected.	
3	Checking the main PWB	The connector or the FFC is not connected properly. Or, the wire, FFC, the PWB is faulty.	Clean the terminal of the connectors on the main PWB, reconnect the connector of the wire, and reconnect the FFC terminal. If the wire or the FFC is faulty, repair or replace them. If not resolved, replace the main PWB.	

C0830: FAX PWB flash program area checksum error

The program stored in the flash memory on the FAX PWB is broken so it cannot perform.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The FAX PWB is not connected properly.	Turn off the power switch and pull out the power plug. After passing 5s, reattach the FAX PWB and reinsert the power plug. Then, turn on the power switch.	
2	Firmware upgrade	The firmware is faulty.	Reinstall the FAX firmware.	
3	Initializing the fax	The data in the FAX PWB is faulty.	Execute U600 to initialize the FAX.	
4	Replacing the FAX PWB	The FAX PWB is faulty.	Replace the FAX PWB.	

C0840: RTC error

- Not communicated with RTC correctly.
- RTC data is inconsistent with empty battery.

Step	Check description	Assumed cause	Measures	Reference
1	Setting time and date (RTC)	Time and date (RTC) are erased	Set Date and Time (RTC) from System Menu	
2	Replacing the main PWB	The main PWB is faulty, or the backup battery runs out.	Replacing the main PWB	

C0870: PC FAX Image data transmission error

Data was not properly transmitted even if the specified times of retry were made when the large volume data is transmitted between the FAX PWB and the main PWB.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The FAX PWB does not operate properly.	Turn off the power switch and pull out the power plug. After passing 5s, reattach the FAX PWB and reinsert the power plug. Then, turn on the power switch.	
2	Initializing the fax	The data in the FAX PWB is faulty.	Execute U600 to initialize the FAX.	
3	Firmware upgrade	The FAX firmware is faulty.	Upgrade the fax firmware to the latest version.	
4	Replacing the FAX PWB	The FAX PWB is faulty.	Replace the FAX PWB.	
5	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

C0920: FAX file system error

The backup data could not be stored since the file system of the flash memory is faulty.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The FAX PWB does not operate properly.	Turn off the power switch and pull out the power plug. After passing 5s, reattach the FAX PWB and reinsert the power plug. Then, turn on the power switch.	
2	Initializing the fax	FAX control values are incorrect	Execute U600 to initialize the FAX.	
3	Reconnecting the FAX PWB	The FAX PWB is not connected properly.	Reinstall FAX PWB to Main PWB.	
4	Firmware upgrade	The firmware is faulty.	Reinstall the FAX firmware.	
5	Replacing the FAX PWB	The FAX PWB is faulty.	Replace the FAX PWB.	

C0980: 24V power interruption detection

- 24V power shutoff signal is detected 1s continuously.
- Other service call error occurs after 24V power shutoff signal is lowered, and then 24V power is recovered.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The firmware in the Engine PWB does not operate normally	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Low voltage PWB - Engine PWB	
3	Replacing the low voltage PWB	The low voltage PWB is faulty.	When the +24V generation from the low voltage PWB is not stable, and it lowers, replace the low voltage PWB.	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C1010: Lift motor 1 error

- Cassette 1 lift motor over-current is detected 5 times continuously.
- Lift sensor on is not detected 5 times continuously when passing 15s after cassette 1 is loaded.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the lift plate	The lift plate does not operate properly.	Repair or replace the lift plate when it does not move vertically.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Lift motor - Engine PWB (YC18) • Lift sensor - Engine PWB (YC19) 	
3	Checking the lift motor	The lift motor is faulty.	Check the lift motor operation, and replace it if necessary.	
4	Checking the lift sensor	The lift sensor is not properly attached, or it is faulty.	Reattach PF lift upper limit sensor. If not repaired, replace it.	
5	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
6	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C1020: PF lift motor 1 error

Object: 500-sheet paper feeder, 500-sheetx2 paper feeder

The PF lift sensor 1 on is not detected 5 times continuously when passing 15s after loading cassette 2.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the lift plate	The lift plate does not operate properly.	Repair or replace the lift plate when it does not move vertically.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • PF lift motor 1 - PF PWB (YC4) • PF upper limit sensor 1 - PF PWB (YC3) 	
3	Checking PF lift motor 1	PF lift motor 1 is faulty.	Check the operation of lift motor 1, and replace it if necessary.	
4	Checking PF lift sensor 1	PF lift sensor 1 is not properly attached, or it is faulty.	Reattach PF lift sensor 1. If not repaired, replace it.	
5	PF firmware upgrade	The PF firmware is not the latest version.	Upgrade the PF firmware to the latest version.	
6	Replacing the PF PWB	The PF PWB is faulty.	Replace the PF PWB.	

C1030: PF lift motor 2 error

Object: 500-sheetx2 paper feeder

The PF lift sensor 2 on is not detected 5 times continuously when passing 15s after loading cassette 3.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the lift plate	The lift plate does not operate properly.	Repair or replace the lift plate when it does not move vertically.	

Step	Check description	Assumed cause	Measures	Reference
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • PF lift motor 2 - PF PWB (YC6) • PF upper limit sensor 2 - PF PWB (YC5) 	
3	Checking PF lift motor 2	PF lift motor 2 is faulty.	Check the operation of lift motor 2, and replace it if necessary.	
4	Checking PF lift sensor 2	PF lift sensor 2 is not properly attached, or it is faulty.	Reattach PF lift sensor 2. If not repaired, replace it.	
5	PF firmware upgrade	The PF firmware is not the latest version.	Upgrade the PF firmware to the latest version.	
6	Replacing the PF PWB	The PF PWB is faulty.	Replace the PF PWB.	

C1800: Paper Feeder communication error

Object: 500-sheet paper feeder, 500-sheetx2 paper feeder

The communication error was detected 10 times continuously.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Engine PWB (YC6) - PF PWB (YC1) 	
2	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware and PF firmware to the latest version	
3	Replacing the PF PWB	The PF PWB is faulty.	Replace the PF PWB.	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C1900: Paper Feeder EEPROM error

Object: 500-sheet paper feeder, 500-sheetx2 paper feeder

For internal count

The writing data and the reading data mismatch 4 times continuously when writing.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Engine PWB (YC6) - PF PWB (YC1) 	
2	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware and PF firmware to the latest version	
3	Replacing the PF PWB	The PF PWB is faulty.	Replace the PF PWB.	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C2000: Main motor steady state error

The main motor steady state off is detected 1s continuously after becoming the steady state

Step	Check description	Assumed cause	Measures	Reference
1	Checking the main motor	The main motor drive is faulty	Execute U030 [Main] and check the main motor operation. Check if the gear rotates or load is heavy in excess	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Main motor - Engine PWB (YC24)	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
4	Replacing the main motor	The main motor is faulty.	Replace the main motor.	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C2010: Main motor startup error

The main motor is not in the steady state within 3s after start-up

Step	Check description	Assumed cause	Measures	Reference
1	Checking the main motor	The main motor drive is faulty	Execute U030 [Main] and check the main motor operation. Check if the gear rotates or load is heavy in excess	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Main motor - Engine PWB (YC24)	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
4	Replacing the main motor	The main motor is faulty.	Replace the main motor.	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C2101: Developer motor steady state error

Developer motor steady state off is detected 1s continuously after the steady state

Step	Check description	Assumed cause	Measures	Reference
1	Checking the developer motor	The developer motor drive is faulty.	Execute U030 [DLP] and check the developer motor operation. Check if the gears in the drive unit rotate and there is heavy load in excess.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Developer motor - Engine PWB (YC25)	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
4	Replacing the developer motor	The developer motor is faulty.	Replace the developer motor.	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C2111: Developer motor start-up error

Developer motor is not in the steady state within 3s after start-up

Step	Check description	Assumed cause	Measures	Reference
1	Checking the developer motor	The developer motor drive is faulty.	Execute U030 [DLP] and check the developer motor operation. Check if the gears in the drive unit rotate and there is heavy load in excess.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Developer motor - Engine PWB (YC25)	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
4	Replacing the developer motor	The developer motor is faulty.	Replace the developer motor.	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C2300: Fuser motor steady state error

The fuser motor steady state off is detected 1s continuously after becoming steady state

Step	Check description	Assumed cause	Measures	Reference
1	Checking the fuser motor	The fuser motor drive is faulty	Execute U030 [Fuser] and check the fuser motor operation. Check if the gears in the drive unit rotate and there is heavy load in excess.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Fuser motor - Engine PWB(YC24)	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
4	Replacing the fuser motor	The fuser motor is faulty.	Replace the fuser motor.	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C2310: Fuser motor start-up error

The fuser motor is not in the steady state within 3s after start-up

Step	Check description	Assumed cause	Measures	Reference
1	Checking the fuser motor	The fuser motor drive is faulty	Execute U030 [Fuser] and check the fuser motor operation. Check if the gears in the drive unit rotate and there is heavy load in excess.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Fuser motor - Engine PWB(YC24)	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
4	Replacing the fuser motor	The fuser motor is faulty.	Replace the fuser motor.	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C2600: PF motor error

Object: 500-sheet paper feeder, 500-sheetx2 paper feeder

An error signal was detected 2s continuously during the PF motor drive

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • PF motor - PFPWB (YC2)	
2	Firmware upgrade	The firmware is not the latest version.	Upgrade the PF firmware to the latest version.	
3	Checking the PF motor	The PF motor is faulty	Replace the PF motor	
4	Replacing the PF PWB	The PF PWB is faulty.	Replace the PF PWB.	

C3100: Carriage error

Object: CCD model

The home position sensor is off and does not turn on when passing the specified time at initialization and it does not turn on at retry once.

Step	Check description	Assumed cause	Measures	Reference
1	Unlocking the primary mirror unit	The primary mirror unit is not unlocked.	Unlock the primary mirror unit.	
2	Checking the scanner and scanner wire	A load is applied to the scanner movement.	Move the mirror unit manually. If there is heavy load in excess, clean the scanner wire, wire drum, scanner rail, etc.	
3	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Scanner motor - Engine PWB	
4	Checking the scanner motor and the belt tension.	The scanner motor or belt tension is faulty	Reattach the scanner motor and adjust the belt tension. If not repaired, replace the scanner motor.	
5	Checking the home position sensor	The home position sensor is faulty.	Reattach the home position sensor. If not repaired, replace it.	
6	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
7	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C3100: Carriage error

Object: CIS model

The home position sensor is off and does not turn on when passing the specified time at initialization and it does not turn on at retry once.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the scanner and ISU shaft	A load is applied to the scanner movement.	Move the mirror unit manually. If there is heavy load in excess, check the drive belt and clean the ISU shaft.	

Step	Check description	Assumed cause	Measures	Reference
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Scanner motor - Engine PWB	
3	Checking the scanner motor	The scanner motor is faulty.	Reattach the scanner motor. If not repaired, replace it.	
4	Checking the home position sensor	The home position sensor is faulty.	Reattach the home position sensor. If not repaired, replace it.	
5	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
6	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C3200: LED error

Object: CCD model

The white reference data retrieved by lighting the lamp at the initial operation is at the specified value or less.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the LED lamp	The LED lamp does not light.	Check if the LED lamp lights. If it does not light, replace the lamp unit and execute U411 [Table].	
2	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • LED drive PWB - Main PWB (YC3003)	
3	Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit and execute U411.	
4	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C3200: CISerror

Object: CIS model

- The white reference data retrieved by lighting the lamp at the initial operation is lower than the specified value.
- The white reference data retrieved by lighting the lamp at the auto table adjustment is lower than the specified value.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the CIS lamp	The CIS lamp does not light	Check if the CIS lamp turns on. If not, replace the lamp unit and execute U411 [Table]	
2	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CIS PWB - Main PWB (YC3001)	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C3300: CCD AGC error

Object: CCD model

For internal count

The white reference data after adjustment is not within the target range

Step	Check description	Assumed cause	Measures	Reference
1	Cleaning the backside of the contact glass	The white reference sheet is dirty.	Clean the white reference sheet at the backside of the contact glass.	
2	Checking the LED lamp	The LED lamp is broken.	Check if the LED lamp lights. If it does not light, replace the lamp unit and execute U411 [Table].	
3	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • LED drive PWB - Main PWB (YC3003)	
4	Replacing the lens unit	The CCD PWB is faulty.	Replace the lens unit and execute U411.	
5	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
6	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C3300: CIS AGC error

Object: CIS model

For internal count

The white reference data after adjustment is not within the target range

Step	Check description	Assumed cause	Measures	Reference
1	Cleaning the backside of the contact glass	The white reference sheet is dirty.	Clean the white reference sheet at the backside of the contact glass.	
2	Checking the CIS lamp	The CIS lamp does not light	Check if the CIS lamp turns on. If not, replace the lamp unit and execute U411 [Table]	
3	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • CIS PWB - Main PWB (YC3001)	
4	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C3500: Scanner AISC communication error

Readback values are different 4 times continuously during communication between the scanner and ASIC

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • Main PWB (YC26) - Engine PWB (YC3)	
2	Firmware upgrade	The firmware is not the latest version.	Upgrade the main firmware and the Engine firmware to the latest version.	

Step	Check description	Assumed cause	Measures	Reference
3	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	
4	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

C3600: Scanner sequence error

- Mail box buffer overflow is detected.
- Software sequence error is detected.

Step	Check description	Assumed cause	Measures	Reference
1	Executing U021	The memory operation is faulty.	Execute U021 and initialize the backup data	
2	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. • Main PWB (YC26) - Engine PWB (YC3)	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the main firmware and the Engine firmware to the latest version.	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	
5	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

C4001: Polygon motor synchronization error

The polygon motor does not become steady state when passing 10s after starting the drive

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Polygon motor - Engine PWB(YC23)	
2	Checking the polygon motor	The polygon motor does not rotate properly.	Check the rotation sound of the polygon motor, and reattach or replace the LSU if it does not rotate properly.	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C4011: Polygon motor steady-state error

Steady state off is detected 1s continuously after the polygon motor is in the steady state

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Polygon motor - Engine PWB(YC23)	
2	Checking the polygon motor	The polygon motor does not rotate properly.	Check the rotation sound of the polygon motor, and reattach or replace the LSU if it does not rotate properly.	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C4101: BD initialization error

BD is not detected within 1s after the polygon motor is in the steady state

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • APC PWB(YC1) - Main PWB(YC24) • Main PWB(YC26) - Engine PWB(YC3) 	
2	Checking the LSU	The APC PWB does not operate normally	Reattach or replace the LSU	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the main firmware and the Engine firmware to the latest version.	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	
5	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

C5101: Main high-voltage error

When measuring the rush-in current by changing the Vpp in 3 steps at the Vpp adjustment, the difference between zero current value and the third step current value is 5 or less.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the drum unit and the developer unit	The drum or the drum screw does not rotate properly due to the excessive load.	Check if the drum or drum screw rotates by manually and if not, replace the drum unit.	
2	Checking the main motor	The main motor is faulty.	Replace the main motor.	
3	Checking the main charger unit	Since foreign objects adhere to the main charger high-voltage contact, it is deformed or damaged, proper current does not flow.	Check the main charger unit high voltage contact. Clean it if foreign objects adhere. Replace the main charger unit if deformed or damaged and clear the main charger roller counter at U930.	
4	Checking the connection	FFC is not connected properly. Or it is faulty.	Clean the FFC terminals of the following FFC and reconnect them. If the FFC terminal is deformed or broken, replace the FFC. <ul style="list-style-type: none"> • high voltage PWB - Engine PWB (YC10) 	
5	Checking the high-voltage PWB	The high-voltage PWB is faulty.	Replace the high-voltage PWB.	
6	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
7	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C6000: Fuser main heater broken wire

1. The fuser thermopile does not detect 100°C/212°F within 20s after starting warm-up.
2. During warm-up, the temperature detected by the fuser thermistor does not reach the edge ready temperature within 60s after detecting 100°C/212°F.

Step	Check description	Assumed cause	Measures	Reference
1	Reinstalling the fuser unit	There are foreign objects in the drawer contact terminal of the fuser unit	Clean the drawer connector terminal of the fuser unit. Check if the pin of the drawer connector is not bent, and replace the fuser unit if it is bent. If it is normal, reinstall the fuser unit so that the drawer connector is securely connected.	

Step	Check description	Assumed cause	Measures	Reference
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the wire connector terminal and reconnect it. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Fuser heater - Low-voltage PWB (YC4) • Thermal cutout - Low-voltage PWB (TB3) • Fuser thermopile - Engine PWB (YC13) 	
3	Replacing the fuser thermopile	The fuser thermopile does not detect temperature correctly	Replace the fuser thermopile.	
4	Replacing the fuser unit	The fuser heater, thermal cutout or others is faulty	Replace the fuser unit.	
5	Replacing the low voltage PWB	The low voltage PWB is faulty.	Replace the low voltage PWB.	
6	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
7	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C6020: Fuser thermopile error

The fuser thermopile detects high temperature 1s continuously

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Fuser thermopile - Engine PWB (YC13) 	
2	Replacing the fuser thermopile	The fuser thermopile does not detect temperature correctly	Replace the fuser thermopile.	
3	Replacing the low voltage PWB	The low voltage PWB is faulty.	Replace the low voltage PWB.	
4	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C6030: Fuser thermopile wire break detection

1. During warm-up, the fuser thermopile detected the abnormal outer temperature output value for 1s.
2. During warm-up, the fuser thermopile detected the abnormal target output value for 1s.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Fuser thermopile - Engine PWB (YC13) 	
2	Replacing the fuser thermopile	The fuser thermopile is faulty	Replace the fuser thermopile.	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C6050: Fuser thermopile low temperature error

The fuser thermopile detected 100°C/212°F or less 1s continuously during printing

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Fuser thermopile - Engine PWB (YC13)	
2	Replacing the fuser thermopile	The fuser thermopile does not detect temperature correctly	Replace the fuser thermopile.	
3	Replacing the low voltage PWB	The low voltage PWB is faulty.	Replace the low voltage PWB.	
4	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C6200: Broken fuser sub heater

1. During warm-up, the temperature detected by the fuser thermistor does not reach 100°C/212°F within 60s after starting warm-up.
2. During warm-up, the temperature detected by the fuser thermistor does not reach the edge ready temperature within 60s after detecting 100°C/212°F.

Step	Check description	Assumed cause	Measures	Reference
1	Reinstalling the fuser unit	There are foreign objects in the drawer contact terminal of the fuser unit	Clean the drawer connector terminal of the fuser unit. Check if the pin of the drawer connector is not bent, and replace the fuser unit if it is bent. If it is normal, reinstall the fuser unit so that the drawer connector is securely connected.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the wire connector terminal and reconnect it. If there is no continuity, replace the wire. • Fuser heater - Low-voltage PWB (YC4) • Thermal cutout - Low-voltage PWB (TB3) • Fuser thermistor - Engine PWB (YC13)	
3	Replacing the fuser unit	The fuser sub heater, fuser thermistor, or others is faulty	Replace the fuser unit.	
4	Replacing the low voltage PWB	The low voltage PWB is faulty.	Replace the low voltage PWB.	
5	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
6	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C6220: Fuser thermistor high temperature error

The fuser thermistor detected high temperature 1s continuously

Step	Check description	Assumed cause	Measures	Reference
1	Reinstalling the fuser unit	There are foreign objects in the drawer contact terminal of the fuser unit	Clean the drawer connector terminal of the fuser unit. Check if the pin of the drawer connector is not bent, and replace the fuser unit if it is bent. If it is normal, reinstall the fuser unit so that the drawer connector is securely connected.	

Step	Check description	Assumed cause	Measures	Reference
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the wire connector terminal and reconnect it. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Fuser heater - Low-voltage PWB (YC4) • Thermal cutout - Low-voltage PWB (TB3) • Fuser thermistor - Engine PWB (YC13) 	
3	Replacing the fuser unit	The fuser thermistor does not detect temperature correctly	Replace the fuser unit.	
4	Replacing the low voltage PWB	The low voltage PWB is faulty.	Replace the low voltage PWB.	
5	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
6	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C6230: Broken fuser thermistor detection

The fuser thermistor detects 42°C/108°F or less while the fuser thermopile detects 100°C/212°F or more during warm-up

Step	Check description	Assumed cause	Measures	Reference
1	Reinstalling the fuser unit	There are foreign objects in the drawer contact terminal of the fuser unit	Clean the drawer connector terminal of the fuser unit. Check if the pin of the drawer connector is not bent, and replace the fuser unit if it is bent. If it is normal, reinstall the fuser unit so that the drawer connector is securely connected.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the wire connector terminal and reconnect it. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Fuser heater - Low-voltage PWB (YC4) • Thermal cutout - Low-voltage PWB (TB3) • Fuser thermistor - Engine PWB (YC13) 	
3	Replacing the fuser unit	The fuser thermistor is faulty	Replace the fuser unit.	
4	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C6250: Fuser thermistor low temperature error

The fuser thermistor detected 60 degree C or less 1s continuously during printing

Step	Check description	Assumed cause	Measures	Reference
1	Reinstalling the fuser unit	There are foreign objects in the drawer contact terminal of the fuser unit	Clean the drawer connector terminal of the fuser unit. Check if the pin of the drawer connector is not bent, and replace the fuser unit if it is bent. If it is normal, reinstall the fuser unit so that the drawer connector is securely connected.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the wire connector terminal and reconnect it. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Fuser heater - Low-voltage PWB (YC4) • Thermal cutout - Low-voltage PWB (TB3) • Fuser thermistor - Engine PWB (YC13) 	

Step	Check description	Assumed cause	Measures	Reference
3	Replacing the fuser unit	The fuser thermistor is faulty	Replace the fuser unit.	
4	Replacing the low voltage PWB	The low voltage PWB is faulty.	Replace the low voltage PWB.	
5	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
6	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C6400: Zero-cross signal error

No zero-cross signal continued 3s during the heater control

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Engine PWB (YC14) - Low-voltage PWB (YC8)	
2	Replacing the low voltage PWB	The low voltage PWB is faulty.	Replace the low voltage PWB.	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C6610: Pressure release error

1. The fuser pressure release sensor changing from on to off is not detected when passing 10s after starting the fuser pressure decrease.
2. The fuser pressure release sensor changing from off to on is not detected when passing 10s after starting the fuser pressure increase.

Step	Check description	Assumed cause	Measures	Reference
1	Reinstalling the fuser unit	There are foreign objects in the drawer contact terminal of the fuser unit	Clean the drawer connector terminal of the fuser unit. Check if the pin of the drawer connector is not bent, and replace the fuser unit if it is bent. If it is normal, reinstall the fuser unit so that the drawer connector is securely connected.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the wire connector terminal and reconnect it. If there is no continuity, replace the wire. • Engine PWB (YC21) - Fuser pressure release motor • Engine PWB (YC13) - Fuser pressure release sensor	
3	Replacing the fuser unit	The fuser unit is faulty at the fuser pressure release mechanism or the fuser pressure release sensor .	Replace the fuser unit.	

C6650: Fuser thermopile EEPROM error

1. Access to the thermopile EEPROM is not available.
2. During scanning, no response from the device is detected 5ms or more 5 times continuously.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Fuser thermopile - Engine PWB(YC13)	
2	Replacing the fuser thermopile	The fuser thermopile does not detect temperature correctly	Replace the fuser thermopile.	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C7200: Inner thermistor broken (developer)

The input sampling value of the sensor is at the reference value or more.

Step	Check description	Assumed cause	Measures	Reference
1	Reinstalling the developer unit	The developer unit is not properly installed.	Reinstall developer unit so that the connector connects securely.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Developer relay PWB - Engine PWB (YC8)	
3	Developer unit replacement	The sensor on the developer PWB is faulty	Replace the developer unit.	
4	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C7210: Inner thermistor short-circuited (developer)

The sensor input sampling value is at the reference value or less

Step	Check description	Assumed cause	Measures	Reference
1	Reinstalling the developer unit	The developer unit is not properly installed.	Reinstall developer unit so that the connector connects securely.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Developer relay PWB - Engine PWB (YC8)	
3	Developer unit replacement	The sensor on the developer PWB is faulty	Replace the developer unit.	
4	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C7800: Outer thermistor broken

The input sampling value of the sensor is at the reference value or more.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Temperature/humidity sensor - Engine PWB (YC9)	
2	Replacing the temperature/humidity sensor	The temperature/humidity sensor is faulty.	Replace the temperature/humidity sensor.	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C7810: Outer thermistor short-circuited

The sensor input sampling value is at the reference value or less

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Temperature/humidity sensor - Engine PWB (YC9)	
2	Replacing the temperature/humidity sensor	The temperature/humidity sensor is faulty.	Replace the temperature/humidity sensor.	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C8030: DF tray upper limit detection error

Object: 500-sheet document finisher

The DF tray upper limit sensor on is detected when the DF tray motor is in ascending operation

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • DF tray upper limit sensor - DFPWB (CN5) • Paper level sensor 1, 2 - DFPWB (CN6)	
2	Replacing the sensor	The Dr tray upper limit sensor, paper level sensor 1 or 2 is faulty	Replace the DF tray upper limit sensor or paper level sensor.	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the DP firmware to the latest version.	
4	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

C8040: DF belt error

Object: 500-sheet document finisher

The DF belt sensor on or off cannot be detected when passing the specified time after the DF belt solenoid turns on

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the wire connector terminal and reconnect it. If there is no continuity, replace the wire. • DF belt sensor - DF PWB (CN10) • DF belt solenoid - DF PWB (CN21)	
2	Replacing the DF belt sensor	DF belt sensor is faulty	Replace DF belt sensor	
3	Replacing the DF belt solenoid	DF belt solenoid is faulty	Replace DF belt solenoid	
4	Firmware upgrade	The firmware is not the latest version.	Upgrade the DP firmware to the latest version.	
5	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

C8140: Dr tray motor error

Object: 500-sheet document finisher

During the DF tray motor drive, the DF tray lower limit sensor, paper level sensor 1 and 2 on is not detected within 10s.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • DF tray motor - DF PWB (CN15) • DF tray lower limit sensor - DF PWB (CN5) • Paper level sensor1, 2 - DF PWB (CN6)	
2	Replacing the DF tray motor	The DF tray motor is faulty.	Replace the DF tray motor.	
3	Replacing the sensor	The DF tray lower limit sensor, paper level sensor 1 or 2 is faulty	Replace the DF tray lower limit sensor or paper level sensor.	
4	Firmware upgrade	The firmware is not the latest version.	Upgrade the DP firmware to the latest version.	
5	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

C8210: DF staple error

Object: 500-sheet document finisher

JAM7013 and 7023 was detected twice

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • DF staple unit - DF PWB	
2	Checking the staple	Check if the upper BF registration guide shifts manually, and reattach it if it does not smoothly shift.	Check if the lower BF registration guide shifts manually, and reattach it if it does not smoothly shift.	
3	Replacing the DF staple unit	The DF staple unit is faulty.	Replace the DF staple unit.	
4	Firmware upgrade	The firmware is not the latest version.	Upgrade the DP firmware to the latest version.	
5	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

C8320: DF adjuster motor 2 error

Object: 500-sheet document finisher

The DF adjusting sensor 2 on or off cannot be detected when passing the specified time after the DF adjusting motor 2 turns on

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • DF adjusting motor 2 - DFPWB (CN18) • DF adjusting sensor 2 - DFPWB (CN7)	
2	Replacing DF adjusting motor 2	DF adjusting motor 2 is faulty	Replace DF adjusting motor 2	
3	Replacing the DF adjusting sensor 2	DF adjusting sensor 2 is faulty	Replace DF adjusting sensor 2	
4	Firmware upgrade	The firmware is not the latest version.	Upgrade the DP firmware to the latest version.	
5	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

C8330: DF adjuster motor 1 error

Object: 500-sheet document finisher

The DF adjusting sensor 1 on or off cannot be detected when passing the specified time after the DF adjusting motor 1 turns on

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • DF adjusting motor 1 - DFPWB(CN18) • DF adjusting sensor 1 - DFPWB(CN7)	
2	Replacing DF adjusting motor 1	DF adjusting motor 1 is faulty	Replace DF adjusting motor 1	
3	Replacing the DF adjusting sensor 1	DF adjusting sensor 1 is faulty	Replace DF adjusting sensor 1	
4	Firmware upgrade	The firmware is not the latest version.	Upgrade the DP firmware to the latest version.	
5	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

C8350: DF roller motor error

Object: 500-sheet document finisher

The DF roller sensor on or off cannot be detected when passing the specified time after the DF roller motor turns on

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • DF roller motor - DF PWB (CN20) • DF roller sensor - DF PWB (CN11)	
2	Replacing the DF roller sensor	DF roller sensor is faulty	Replace DF roller sensor	

Step	Check description	Assumed cause	Measures	Reference
3	Replacing the DF roller motor	The DF roller motor is faulty	Replace DF roller motor	
4	Firmware upgrade	The firmware is not the latest version.	Upgrade the DP firmware to the latest version.	
5	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

C8360: DF slide motor error

Object: 500-sheet document finisher

The DF slide sensor on or off cannot be detected when passing the specified time after the DF slide motor turns on

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • DF slide motor - DF PWB(CN14) • DF slide sensor - DF PWB(CN22) 	
2	Replacing the DF slide sensor	The DF slide sensor is faulty.	Replace the DF slide sensor	
3	Replacing the DF slide motor	The DF slide motor is faulty.	Replace the DF slide motor	
4	Firmware upgrade	The firmware is not the latest version.	Upgrade the DP firmware to the latest version.	
5	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

C8460: EEPROM error

Object: 500-sheet document finisher

EEPROM read/write is not available

Step	Check description	Assumed cause	Measures	Reference
1	Firmware upgrade	The firmware is not the latest version.	Upgrade the DP firmware to the latest version.	
2	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	

C8800: Document finisher communication error

Object: 500-sheet document finisher

The communication error was detected 10 times continuously.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the wire connector terminal and reconnect it. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Engine PWB (YC5) - DF relay PWB (YC2) • DF relay PWB (YC3) - DF PWB (CN1) 	
2	Firmware upgrade	The firmware is not the latest version.	Upgrade the DP firmware to the latest version.	
3	Replacing the DF relay PWB	The DF relay PWB is faulty	Replace the DF relay PWB.	
4	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	
5	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	

Step	Check description	Assumed cause	Measures	Reference
6	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C8830: Relay conveying unit communication error

Object: 500-sheet document finisher + relay conveying unit

The communication error was detected 10 times continuously.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Engine PWB (YC5) - DF relay PWB (YC2) • DF relay PWB (YC4) - BR PWB (YC5) 	
2	Firmware upgrade	The firmware is not the latest version.	Upgrade the BR firmware to the latest version.	
3	Replacing the BR PWB	The BR PWB is faulty.	Replace the BR PWB.	
4	Replacing the DF relay PWB	The DF relay PWB is faulty	Replace the DF relay PWB.	
5	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
6	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C8990: Finisher setup error

Object: 500-sheet document finisher + relay conveying unit

1. Communication error occurs with either the finisher or relay conveying unit.
2. Communication error occurs while installation of the relay conveying unit is detected

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the wire connector terminal and reconnect it. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • DF PWB (CN1) - DF relay PWB (YC3) • DF relay PWB (YC4) - BR PWB (YC5) 	
2	Firmware upgrade	The firmware is not the latest version.	Upgrade the DP firmware to the latest version.	
3	Replacing the DF PWB	The DF PWB is faulty.	Replace the DF PWB.	
4	Replacing the BR PWB	The BR PWB is faulty.	Replace the BR PWB.	

C9000: DP communication error

Object: Document processor

The communication error was detected 10 times continuously.

Step	Check description	Assumed cause	Measures	Reference
1	Firmware upgrade	The main unit firmware and the document processor firmware mismatch	Upgrade the main unit firmware and the document processor firmware to the latest version.	

Step	Check description	Assumed cause	Measures	Reference
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • DP PWB (YC2) - Engine PWB (YC4)	
3	Replacing the DP PWB	The DP PWB is faulty.	Replace the DP PWB.	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

C9060: DP EEPROM error

Object: Document processor

The writing data and the reading data into the EEPROM mismatch.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the EEPROM	The EEPROM is not properly installed.	Reattach the EEPROM on the DP PWB.	
2	Replacing the DP PWB	The DP PWB is faulty.	Replace the DP PWB.	
3	Replacing the EEPROM	The EEPROM is faulty.	Replace the EEPROM on the DP PWB, then execute U411.	

C9180: DP feed-shift motor error

Object: Document processor

1. The DP feed-shift motor home position cannot be detected even driving it for one round.
2. The DP feed-shift motor home position cannot be detected even after retrying the detection for 3 times.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • DP feed-shift motor - DP PWB (YC7) • DP feed-shift sensor - DP PWB (YC4) • DP PWB (YC2) - Engine PWB (YC18)	
2	Replacing the DP feed-shift sensor	The DP feed-shift sensor is faulty.	Replace the DP feed-shift sensor.	
3	Replacing the DP feed-shift motor	The DP feed-shift motor is faulty.	Replace the DP feed-shift motor.	
4	Replacing the DP PWB	The DP PWB is faulty.	Replace the DP PWB.	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

(2) System Error (Fxxxx) Outline

(2-1) System Error code list

Error code	Contents
F000	Main unit CPU communication error (Controller - Panel)
F010	Program read error
F020	System memory error (RAM reading/writing error or CPU memory error)
F040	Communication error between the main unit CPU (Communication error between the controller and Engine)
F050	Engine program error
F052	Panel Engine program error

(2-2) Content of System Error (Fxxxx) Outline

F000: Main unit CPU communication error (Controller - Panel)

The panel cannot be detected since the CPU communication between the main PWB and the operation panel main PWB is unavailable.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The communication between the main PWB and the operation panel main PWB is faulty.	Turn off the power switch and pull out the power plug. After passing 5s, reinsert the power plug and turn on the power switch.	
2	Checking the connection	The connector is not connected properly. Or, the wire or the SATA cable is faulty.	Clean the wire, the terminal of SATA cable connector and reconnect them. If there is no continuity, replace the wire. • Main PWB - Operation panel PWB	
3	Executing U021	The backup RAM data is faulty.	Execute U021 to initialize the backup RAM data.	
4	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	
5	Replacing the operation panel main PWB	The operation panel main PWB is faulty.	Replace the panel main PWB.	

F010: Program read error

Data corruption is detected at the program read

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The communication between the main PWB and the operation panel main PWB is faulty.	Turn off the power switch and pull out the power plug. After passing 5s, reinsert the power plug and turn on the power switch.	
2	Executing U021	The backup RAM data is faulty.	Execute U021 to initialize the backup RAM data.	
3	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

F020: System memory error (RAM reading/writing error or CPU memory error)

The error appears during the reading/writing check of the RAM for the CPU when the main unit starts up.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The communication between the main PWB and the operation panel main PWB is faulty.	Turn off the power switch and pull out the power plug. After passing 5s, reinsert the power plug and turn on the power switch.	
2	Executing U021	The backup RAM data is faulty.	Execute U021 to initialize the backup RAM data.	
3	Checking the main PWB	The connector or the FFC is not connected properly. Or, the wire, FFC, the PWB is faulty.	Clean the terminal of the connectors on the main PWB, reconnect the connector of the wire, and reconnect the FFC terminal. If the wire or the FFC is faulty, repair or replace them. If not resolved, replace the main PWB.	

F040: Communication error between the main unit CPU (Communication error between the controller and Engine)

There is an error in the communication between the main PWB and the Engine PWB.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	There is an error in the communication between the main PWB and the Engine PWB.	Turn off the power switch and pull out the power plug. After passing 5s, reinsert the power plug and turn on the power switch.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Engine PWB (YC3) - Main PWB (YC26)	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the main firmware and the Engine firmware to the latest version.	
4	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

F050: Engine program error

The Engine program cannot start up.

Step	Check description	Assumed cause	Measures	Reference
1	Firmware upgrade	The firmware is not the latest version.	Upgrade the Engine firmware to the latest version	
2	Resetting the main power	The Engine firmware checksum is faulty.	Turn off the power switch and pull out the power plug. After passing 5s, reinsert the power plug and turn on the power switch.	
3	Checking the EEPROM	The EEPROM is not properly attached.	Reattach the EEPROM.	
4	Checking the Engine PWB	The connector or the FFC is not connected properly. Or, the wire, FFC, the PWB is faulty.	Clean the terminal of the connectors on the Engine PWB, reconnect the connector of the wire, and reconnect the FFC terminal. If the wire or the FFC is faulty, repair or replace it. If not resolved, replace the Engine PWB.	

F052: Panel Engine program error


The panel program cannot start up.

Step	Check description	Assumed cause	Measures	Reference
1	Firmware upgrade	The firmware is not the latest version.	Upgrade the panel firmware to the latest version.	
2	Resetting the main power	The panel RAM checksum is faulty.	Turn off the power switch and pull out the power plug. After passing 5s, reinsert the power plug and turn on the power switch.	
3	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the connectors on the operation panel PWB, reconnect the connector of the wire. If there is no continuity, replace the wire.	
4	Replacing the operation panel main PWB	The operation panel main PWB is faulty.	Replace the panel main PWB.	

(2-3) System Error (Fxxxx) Outline

The document is described for the outline of the factors of the Fxxx errors that are not described in the self-diagnosis error code list.

Please utilize it as the measures when the system is not recovered after power off/on or it frequently occurs.

 **Important**

- Please initially check the following when the error (Fxxx) is indicated.
 - Check the DIMM (DDR memory) and neighboring parts: Check the contact on the control PWB by releasing and reinserting the DIMM.
If the error repeats after that, replace the DIMM.
- Power is partially supplied to this machine when the power is turned off.
Unplug the power plug and check if the F-code error is not released when passing one minute or more after turning the power off and then on.

Num ber	Contents	Verification procedure & check point	Remarks
-	It locks on a Welcome screen.It locks on a starting logo (Taskalfa/Ecosys) screen.(Even if time passes for a definite period of time in more than * notes, a screen does not change)	(1) Check the harness of * (between Main board <=>SSD), and the connection state of a connector between Panel<=>Main boards, and perform an operation check. (2) Check contact of a DDR memory (extracting) and perform an operation check. If exchangeable, it will exchange and will perform an operation check. (3) Initialize SSD and perform an operation check. * (4) U021 Controller backup initialization is carried out and an operation check is performed. (5) Exchange a PanelMain board and perform an operation check. (6) Exchange a Main board and perform an operation check. (7) It will get, if USBLOG is obtainable, and contact service headquarters. * : only SSD standard model	* Execution of U024 will vanish user data and the software installed. Reinstallation is required.
F000	CF000 will be displayed if * notes progress is carried out for a definite period of time with a Welcome screen.The communication fault between Panel-Main boards.Communication fault between Panel Core-Main Core Notes 2	(1) Check the harness of * (between Main board <=>SSD), and the connection state of a connector between Panel<=>Main boards, and perform an operation check. (2) Check contact of a DDR memory (extracting) and perform an operation check. If exchangeable, it will exchange and will perform an operation check. (3) Initialize SSD and perform an operation check. * (4) U021 Controller backup initialization is carried out and an operation check is performed. (5) Exchange a Main board and perform an operation check. (6) Exchange a PanelMain board and perform an operation check. (7) It will get, if USBLOG is obtainable, and contact service headquarters. * : only SSD standard model * Note 2 : Only Dual Core CPU model	

Num ber	Contents	Verification procedure & check point	Remarks
F12X	Abnormality detecting in a Scan control section	(1) Check the harness between Scan/DP<=>Main boards, and the connection state of a connector, and perform an operation check. (2) Initialize SSD and perform an operation check. * (3) U021 Controller backup initialization is carried out and an operation check is performed. (4) Exchange a Scan/DP board and perform an operation check. (5) Exchange a Main board and perform an operation check. (6) Get USBLOG and contact service headquarters. * Only SSD standard model	
F14X	Abnormality detecting in a FAX control part	(1) Check the harness between FAX<=>Main boards, and the connection state of a connector, and perform an operation check. (2) Initialize SSD and perform an operation check. * (3) U021 Controller backup initialization is carried out and an operation check is performed. (4) Perform a deed operation check for DIMM Clear by U671. * Notes(Since it disappears when received data remain, cautions are required.) (5) Exchange FAX_DIMM and perform an operation check. * Notes (6) Exchange a FAX board and perform an operation check. (7) Exchange a Main board and perform an operation check. (8) Get USBLOG and contact service headquarters. * Only SSD standard model * Note Only model which has Flash for FAX data in a Main board	[Confirmation of KUJO connector connection] Is fax board in the lower slot? Is the orientation of the fax board correct?
F15X	Abnormality detecting in an authentication device control section	(1) Check the harness between authentication device <=>Main boards, and the connection situation of a connector, and perform an operation check. (2) Initialize SSD and perform an operation check. * (3) Carry out U021 Main backup initialization and perform an operation check. (4) Exchange a Main board and perform an operation check. (5) Exchange SSD and perform an operation check. * (6) Get USBLOG and contact service headquarters. * Only SSD standard model	Authentication device: Card reader etc.
F17X	Abnormality detecting in a printer data control part	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	

Num ber	Contents	Verification procedure & check point	Remarks
F18X	Abnormality detecting in a Video control section	(1) Check the harness between Engine<=>Main boards, and the connection state of a connector, and perform an operation check. (2) Initialize SSD and perform an operation check. * (3) U021 Controller backup initialization is carried out and an operation check is performed. (4) Exchange an Engine board and perform an operation check. (5) Exchange a Main board and perform an operation check. (6) Get USBLOG and contact service headquarters. * Only SSD standard model	
F1DX	Abnormality detecting of the image memory Management Department	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	* Poor arrangement of F1D4:Random Access Memory(1) Confirmation of U340(2) Initialization of a set point (U021)
F21X F22X F23X	Abnormality detecting in an image-processing part	(1) Check contact of a DDR memory and perform an operation check. (2) Initialize SSD and perform an operation check. * (3) Carry out U021 Main backup initialization and perform an operation check. (4) Exchange a Main board and perform an operation check. (5) Exchange SSD and perform an operation check. * (6) Get USBLOG and contact service headquarters. * Only SSD standard model	
F24X	Abnormality detecting in the system Management Department	(1) Check contact of a DDR memory and perform an operation check. (2) Initialize SSD and perform an operation check. * (3) Carry out U021 Main backup initialization and perform an operation check. (4) Exchange a Main board and perform an operation check. (5) Exchange SSD and perform an operation check.* (6) Get USBLOG and contact service headquarters. * Only SSD standard model	* F248 is the abnormalities of a printer process.In recurring by specific printer data, please give me cooperation at acquisition of capture data and USBLOG.
F25X	Abnormality detecting in a network management department	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Get USBLOG and packet capture and contact service headquarters. * Only SSD standard model	[Main body to External network] Ethernet connector * It may occur according to a visitor's networkenvironment.
F26X F27X F28X F29X F2AX	Abnormality detecting in the system Management Department	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	

Num ber	Contents	Verification procedure & check point	Remarks
F2BX F2CX F2DX F2EX F2FX F30X F31X F32X	Abnormality detecting in a network control part	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Get USBLOG and contact service headquarters. (Depending on an analysis result, it is packet capture acquisition) * Only SSD standard model	[Main body to External network] Ethernet connector
F33X	Abnormality detecting in the Scan Management Department	(1) Check the harness between Scan/DP<=>Main boards, and the connection state of a connector, and perform an operation check. (2) Initialize SSD and perform an operation check. * (3) U021 Controller backup initialization is carried out and an operation check is performed. (4) Exchange a Scan/DP board and perform an operation check. (5) Exchange a Main board and perform an operation check. (6) Get USBLOG and contact service headquarters. * Only SSD standard model	
F34X	Abnormality detecting in the Panel Management Department	(1) Check the harness between Panel<=>Main boards, and the connection state of a connector, and perform an operation check. * Notes (2) Initialize SSD and perform an operation check. * (3) U021 Controller backup initialization is carried out and an operation check is performed. (4) Exchange a Panel board and perform an operation check. * Notes (5) Exchange a Main board and perform an operation check. (6) Get USBLOG and contact service headquarters. * Only SSD standard model * Note : A Dual Core CPU model and HyPAS model	
F35X	Abnormality detecting in the printing controlling Management Department	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	

Num ber	Contents	Verification procedure & check point	Remarks
F37X	Abnormality detecting in the FAX Management Department	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Perform a deed operation check for DIMM Clear by U671.(Since it disappears when received data remain, cautions are required.) * notes (4) Exchange FAX_DIMM and perform an operation check. * Notes (5) Exchange a Main board and perform an operation check. (6) Exchange SSD and perform an operation check. * (7) Get USBLOG and contact service headquarters. * Only SSD standard model * Note Only model which has Flash for FAX data in a Main board	
F38X	Abnormality detecting in the authentication authorized Management Department	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	
F3AX F3BX F3CX F3DX F3EX F3FX F40X F41X F42X F43X F44X F45X	Abnormality detecting in the Entity Management Department	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	
F46X	Abnormality detecting of a printer rendering part	(1) Exchange boards and perform an operation check. (2) the acquisition wish of USBLOG -- carry out(Depending on the (2) case, it is print capture data acquisition) * Only SSD standard model	* F46F is the abnormalities of a printer process.In recurring by specific printer data, please give me cooperation at acquisition of capture data and USBLOG.
F47X	Abnormality detecting of an image editing processing part	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	

Num ber	Contents	Verification procedure & check point	Remarks
F4DX	Abnormality detecting in the Entity Management Department	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	
F50X	Abnormality detecting in the FAX Management Department	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition.
F52X	Abnormality detecting in a JOB execution part	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition.
F53X			
F55X			
F56X			
F57X			
F63X	Abnormality detecting in a device control section	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	
F68X	Abnormality detecting in a storage device control section	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	* F684 is the overwrite error at the time of an SSD security kit.
F90X	Abnormality detecting in the extension application service part	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition.

Number	Contents	Verification procedure & check point	Remarks
F93X	Abnormality detecting in the extension application management part	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition.
F9FX	Abnormality detecting in the extension application various service part	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition.
FC0X	Abnormality detecting in system application	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition.
FC5X	Abnormality detecting in Copy application	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition.
FCAX	Abnormality detecting in Print application	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition.
FCFX	Abnormality detecting in Send application	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition.

Num ber	Contents	Verification procedure & check point	Remarks
FD4X	Abnormality detecting in Box application	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition.
FD9X	Abnormality detecting in FAX application	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition.
FDEX	Abnormality detecting in maintenance application	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition.
FF7X	Abnormality detecting in a report creation part	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition. [Controller problem] Resolution is only power off / On.
F80X	Abnormality detecting in the Data Access Platform Service	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition.

Number	Contents	Verification procedure & check point	Remarks
FE3X	Abnormality detecting in a authentication/ authorization part	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition.
FF5X	Abnormality detecting in the Application Entity Management Department	(1) Initialize SSD and perform an operation check. * (2) Carry out U021 Main backup initialization and perform an operation check. (3) Exchange a Main board and perform an operation check. (4) Exchange SSD and perform an operation check. * (5) Get USBLOG and contact service headquarters. * Only SSD standard model	Since the USB log immediately after occurrence is needed for analysis, please give me cooperation of acquisition.

7 - 4 FAX Related Errors

(1) FAX Related Errors

No.	Contents
(1)	C0030: FAX PWB system error
(2)	C0070: FAX PWB incompatible detection error
(3)	C0830: FAX PWB flash program area checksum error
(4)	C0870: PC FAX Image data transmission error
(5)	C0920: FAX file system error
(6)	The FAX cannot be sent
(7)	The beep sounds when the copying or printing is finished
(8)	When the data of the A3 or B4 size originals is transmitted, all of it is transmitted as the A4 size data

Content of FAX Related Errors

(1-1) C0030: FAX PWB system error

The FAX processing cannot be continued due to the FAX firmware error.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The FAX PWB does not operate properly.	Turn off the power switch and unplug the power plug. After 5s passes, reconnect the power plug and turn on the power switch.	
2	Firmware upgrade	The firmware is faulty.	Reinstall the FAX firmware.	
3	Replacing the FAX PWB	The FAX PWB is faulty.	Replace the FAX PWB.	

(1-2) C0070: FAX PWB incompatible detection error

Abnormal detection of FAX control PWB incompatibility in the initial communication with the FAX control PWB, any normal communication command is not transmitted.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the FAX PWB	The incompatible FAX PWB is installed.	Install the FAX PWB for the applicable model.	
2	Firmware upgrade	The firmware is faulty.	Reinstall the FAX firmware.	
3	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	

(1-3) C0830: FAX PWB flash program area checksum error

The program stored in the flash memory on the FAX PWB is broken so it cannot perform.

Step	Check description	Assumed cause	Measures	Reference
1	Firmware upgrade	The firmware is faulty.	Reinstall the FAX firmware.	
2	Resetting the main power	The FAX PWB is not connected properly.	Turn off the power switch and pull out the power plug. After passing 5s, reattach the FAX PWB and reinsert the power plug. Then, turn on the power switch.	
3	Initializing the fax	The data in the FAX PWB is faulty.	Execute U600 to initialize the FAX.	
4	Replacing the FAX PWB	The FAX PWB is faulty.	Replace the FAX PWB.	

(1-4) C0870: PC FAX Image data transmission error

Data was not properly transmitted even if the specified times of retry were made when the large volume data is transmitted between the FAX PWB and the main PWB.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The FAX PWB does not operate properly.	Turn off the power switch and pull out the power plug. After passing 5s, reattach the FAX PWB and reinsert the power plug. Then, turn on the power switch.	
2	Initializing the fax	The data in the FAX PWB is faulty.	Execute U600 to initialize the FAX.	
3	Firmware upgrade	The firmware is faulty.	Upgrade the fax firmware to the latest version.	
4	Replacing the FAX PWB	The FAX PWB is faulty.	Replace the FAX PWB.	
5	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	
6	Executing U024	The data stored in the SSD is faulty.	Execute U024 [SSD Format].	

(1-5) C0920: FAX file system error

The backup data could not be stored since the file system of the flash memory is faulty.

Step	Check description	Assumed cause	Measures	Reference
1	Initializing the fax	FAX control values are incorrect	Execute U600 to initialize the FAX.	
2	Resetting the main power	The FAX PWB does not operate properly.	Turn off the power switch and pull out the power plug. After passing 5s, reattach the FAX PWB and reinsert the power plug. Then, turn on the power switch.	
3	Reconnecting the FAX PWB	The FAX PWB is not connected properly.	Reinstall FAX PWB to Main PWB.	
4	Firmware upgrade	The firmware is faulty.	Reinstall the FAX firmware.	
5	Replacing the FAX PWB	The FAX PWB is faulty.	Replace the FAX PWB.	

(1-6) The FAX cannot be sent

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection of the modular cable	The modular cable disconnects.	Reconnect the modular cable.	
2	Changing the connection	If the adapter and the switching device or the like is connected to the telephone line, it is affected.	Directly connect the main unit to the telephone line.	
3	Changing the setting	The line settings are incorrect.	Correct the line settings. (Reduce the transmission speed, etc.)	
4	Checking the status at the destination unit.	The destination unit is busy.	Wait a while and then redial the number if busy tones are heard.	
5	Checking the status at the destination unit.	The modular cable is disconnected in the destination unit if the destination unit does not receive the calling.	Request the destination unit to reconnect the modular cable.	

Step	Check description	Assumed cause	Measures	Reference
6	Checking the setting at the destination unit	The manual reception is set in the destination unit if the destination unit does not receive the calling.	Ask the destination unit to change the reception settings.	
7	Changing the sending content	When transmitting the data to the other country, the communication line is automatically cut.	Input a pause at the last of the destination FAX number.	

(1-7) The beep sounds when the copying or printing is finished

Step	Check description	Assumed cause	Measures	Reference
1	Firmware upgrade	The firmware is not the latest version.	Upgrade the fax firmware to the latest version.	


(1-8) When the data of the A3 or B4 size originals is transmitted, all of it is transmitted as the A4 size data

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The receivable size in the destination unit is A4 / Letter.	Select [B4] or [A3/Ledger] according to the receivable size at the Address book registration display > [i-FAX] > [Paper size].	
2	Changing the setting	The receivable size in the destination unit is A4 / Letter.	Select the condition of the destination unit when transmitting the data, choose [B4] or [A3/Ledger] according to the receivable sizes.	

(2) Communication Errors

Error codes are listed on the communication reports, activity report, etc. The codes consist of an error code indication U followed by a 5-digit number. (The V.34 error is indicated with E of the error code and 5-digit number)

Regarding the 5-digit number, upper 3 digits indicate error and large classification of cause, lower 2 digits small classification of cause. The lower 2 digits are 00 for the item not requiring the category.



Error code

Error code	Contents
U00000/E00000	No response or busy after the set number of redials.
U00100/E00100	Transmission was interrupted by a press of the stop/clear key.
U00200/E00200	Reception was interrupted by a press of the [Stop] key.
U00300/E00300	Recording paper on the destination unit has run out during transmission.
U00430/E00430	Polling request was received but interrupted because of a mismatch in permitted number. Or, sub address-based bulletin board transmission request was received but interrupted because of a mismatch in permitted ID in the transmitting unit.
U00431/E00431	An sub address bulletin board transmission was interrupted because the specified sub address password was not registered.
U00432/E00432	A sub address bulletin board transmission was interrupted because the sub address password did not match.
U00433/E00433	A sub address bulletin board transmission request was received but data was not present in the sub address box.
U00440/E00440	Sub address confidential reception was interrupted because the specified sub address password was not registered.
U00450/E00450	The reception was interrupted because the permitted ID and FAX number did not match in the restricted transmission (password check transmission) in the destination unit.
U00460/E00460	The encryption reception was interrupted because the specified encryption box number was not registered.
U00462/E00462	Encrypted reception was interrupted because the encryption key for the specified encryption box was not registered.
U00601/E00601	Document jam or the document length exceeds the maximum.
U00613/E00613	The optical section is faulty
U00656/E00656	The data was not transmitted due to an error in the modem.
U00690/E00690	System error
U00800/E00800	A page transmission error occurred because of the reception of an RTN or PIN signal.
U00811/E00811	A page reception error remained after retry of transmission in the ECM mode.
U00900/E00900	An RTN or PIN signal was transmitted because of a page reception error.
U00910/E00910	Some pages cannot be received after retry of transmission in the ECM mode

Error code	Contents
U01000/E01000	An FTT signal was received for a set number of times after TCF signal transmission at 2400 bps. Or, an RTN signal was received in response to a Q signal (excluding EOP) after transmission at 2400 bps.
U01001/E01001	Function as indicated by DIS signal is not consistent with the one of own machine.
U01016/E01016	T1 timeout occurs since MBF signal is received but DIS signal is not after sending EOM signal.
U01019/E01019	Command send retrial times exceeds since significant signal is not received after sending CNC signal. (between own machines)
U01020/E01020	Command send retrial times exceeds since significant signal is not received after sending CTC signal. (ECM)
U01021/E01021	Command send retrial times exceeds since significant signal is not received after sending EOR•Q signal. (ECM)
U01022/E01022	Command send retrial times exceeds since significant signal is not received after sending RR signal. (ECM)
U01028/E01028	T5 timeout is detected when sending in ECM (ECM)
U01052/E01052	DCN signal is received after sending RR signal (ECM)
U01080/E01080	PIP signal is received after sending PPS and NULL signals.
U01092/E01092	Communication is stopped since there are impossible combination of symbol speed and communication speed at V.34 sending.
U01093/E01093	A DCN or other inappropriate signal was received during phase B of transmission.
U01094/E01094	DCS/NSS signal send retrial time is exceeded at phase B during transmission.
U01095/E01095	Command send retry time is exceeded since the significant signal is not received after sending (PPS) Q signal at phase D during transmission.
U01096/E01096	DCN signal or invalid command is received at phase D during transmission.
U01097/E01097	The preset number of command retransfers was exceeded after transmission of an RR signal or no response.
U01100/E01100	Function indicated by DCS signal is not consistent with the one of own machine.
U01101/E01101	Function indicated by NSS signal except communication type is not consistent with the one of own machine.
U01102/E01102	DTC (NSC) signal is received while own machine has no transmission data.
U01110/E01110	No response is received after sending DIS signal.
U01111/E01111	No response is received after sending DTC (NSC) signal.
U01113/E01113	No response after transmitting an FTT signal.
U01125/E01125	No response after transmitting a CNS signal. (Between the units of our make)
U01129/E01129	No response after transmitting an SPA signal. (Short protocol)
U01141/E01141	DCN signal is received after sending DTC signal.
U01143/E01143	DCN signal is received after sending FTT signal.
U01155/E01155	DCN signal is received after sending SPA signal. (simplified protocol)
U01160/E01160	Maximum transmission time per line is exceeded while receiving message.
U01162/E01162	Reception was aborted due to a modem malfunction during message reception.
U01191/E01191	Communication is stopped with error during image data receipt sequence at V.34.
U01193/E01193	No response, DCN signal or invalid command is received at phase C/D during reception.
U01194/E01194	DCN signal is received at phase B during reception.
U01195/E01195	No message is received at phase C during reception.
U01196/E01196	Error line control overflow and decoding error occurred in messages during reception.
U01400/E01400	An invalid one-touch key was specified during communication.
U01500/E01500	A communication error occurred when calling in V.8 mode.
U01600/E01600	A communication error occurred when called in V.8 mode.
U01700/E01700	A communication error occurred in phase 2 (line probing).
U01720/E01720	The communication error appears at phase 4 (replacing the modem parameter).
U01721/E01721	The communication was interrupted because there is no communication speed commonly used with the destination unit.
U01800/E01800	A communication error occurred in phase 2 (line probing).
U01810/E01810	A communication error occurred in phase 3 (primary channel equivalent device training).
U01820/E01820	The communication error appears at phase 4 (replacing the modem parameter).

Error code	Contents
U01821/E01821	The communication was interrupted because there is no communication speed commonly used with the destination unit.
U03000/E03000	No document was present in the destination unit when polling reception started.
U03200/E03200	In interoffice sub address bulletin board reception, the data was not stored in the box specified by the destination unit.
U03300/E03300	In polling reception from a unit of our own model, operation was interrupted due to a mismatch in permitted ID or telephone number. Or, in interoffice sub address-based bulletin board reception, operation was interrupted due to a mismatch in permitted ID or telephone number.
U03400/E03400	Polling reception was interrupted because of a mismatch in individual numbers (destination unit is either of our make or by another manufacturer).
U03500/E03500	In interoffice sub address bulletin board reception, the specified sub address password was not registered in the destination unit.
U03600/E03600	An interoffice sub address bulletin board reception was interrupted because of a mismatch in the specified sub address password.
U03700/E03700	Interoffice sub address bulletin board reception failed because the destination unit had no sub address bulletin board transmission capability, or data was not stored in any sub address box in the destination unit.
U04000/E04000	In interoffice sub address transmission mode, the specified sub address password was not registered in the destination unit.
U04100/E04100	The destination unit had no sub address reception capability while the sub address transmission was executed.
U04200/E04200	In encrypted transmission, the specified encryption box was not registered in the destination unit.
U04300/E04300	The encryption transmission was carried out, but there is no encryption function at the other machine.
U04400/E04400	Encrypted transmission was interrupted because encryption keys did not agree.
U04500/E04500	Encrypted reception was interrupted because of a mismatch in encryption keys.
U05100/E05100	The transmission was interrupted because the permitted ID and FAX number did not match in the restricted transmission (password check transmission).
U05200/E05200	Restricted reception (Password check reception) was interrupted because the permitted FAX number / ID did not match, the rejected FAX number matched, or the destination unit did not return its phone number.
U05300/E05300	The destination unit set the restricted reception (Password check reception). Consequently, the transmission was interrupted because the permitted FAX number / ID did not match, the rejected FAX number matched, or the own unit did not return its phone number.
U14000/E14000	Memory overflowed during the sub address confidential reception.
U14100/E14100	In interoffice sub address transmission, memory overflowed in the destination unit.
U19000/E19000	Memory overflowed during memory reception.
U19100/E19100	Memory overflowed in the destination unit while transmitting the data.
U19300/E19300	Transmission failed because an error appeared during JBIG encoding.

Content of Communication Errors

U00000/E00000

Step	Check description	Assumed cause	Measures	Reference
1	Resending	The status is Busy.	Check if the destination unit can receive the data and resend the data if there is no particular problem.	

U00100/E00100

Step	Check description	Assumed cause	Measures	Reference
1	Resending	Transmission was interrupted by a press of the stop/clear key.	Resend.	

U00200/E00200

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	Reception was interrupted by a press of the [Stop] key.	Suspend resending from the destination unit or request the destination unit to resend the data.	

U00300/E00300

Step	Check description	Assumed cause	Measures	Reference
1	Request to the destination unit	Recording paper on the destination unit has run out during transmission.	Request the destination unit to set the recording papers.	

U00430/E00430

Step	Check description	Assumed cause	Measures	Reference
1	Checking the permitted number	Polling or sub address bulletin board transmission were requested, but the communication was interrupted because the permitted ID did not match. (It occurs in the transmitting unit.)	Register a valid permitted number	

U00431/E00431

Step	Check description	Assumed cause	Measures	Reference
1	Request to the destination unit	An sub address bulletin board transmission was interrupted because the specified sub address password was not registered.	Register the sub address password in the destination unit.	

U00432/E00432

Step	Check description	Assumed cause	Measures	Reference
1	Checking the sub address password	A sub address bulletin board transmission was interrupted because the sub address password did not match.	Send by using correct the sub address password.	

U00433/E00433

Step	Check description	Assumed cause	Measures	Reference
1	Checking the sub address box	A sub address bulletin board transmission request was received but data was not present in the sub address box.	Set data in the sub address box.	

U00440/E00440

Step	Check description	Assumed cause	Measures	Reference
1	Checking the sub address password	Sub address confidential reception was interrupted because the specified sub address password was not registered.	Register the sub address password.	

U00450/E00450

Step	Check description	Assumed cause	Measures	Reference
1	Checking the permitted number	The reception was interrupted because the permitted ID and FAX number did not match in the restricted transmission (password check transmission) in the destination unit.	Register the permitted number to be consistent at own machine side.	

U00460/E00460

Step	Check description	Assumed cause	Measures	Reference
1	Checking the encryption key	The encryption reception was interrupted because the specified encryption box number was not registered.	Register an encrypted box number.	

U00462/E00462

Step	Check description	Assumed cause	Measures	Reference
1	Checking the encryption key	Encrypted reception was interrupted because the encryption key for the specified encryption box was not registered.	Register an encryption key.	

U00601/E00601

Step	Check description	Assumed cause	Measures	Reference
1	Checking the original	Original jam	Clear original feed jam and resend.	

Step	Check description	Assumed cause	Measures	Reference
2	Checking the original	The original length exceeds the maximum allowed.	Check if the original length does not exceed 1.6 meter and resend.	

U00613/E00613

Step	Check description	Assumed cause	Measures	Reference
1	Checking the service call error record	The optical section is faulty	Check the service call error record and perform the corrective actions.	

U00656/E00656

Step	Check description	Assumed cause	Measures	Reference
1	Resending	Transmission was interrupted because there was an error in the modem.	Resend.	
2	Resetting the main power	Transmission was interrupted because there was an error in the modem.	Turn off the power switch and pull out the power plug. After passing 5s, reattach the FAX PWB and reinsert the power plug. Then, turn on the power switch.	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the fax firmware to the latest version.	
4	Initializing the fax	The FAX initial value was changed.	Execute U600 to initialize the FAX.	
5	Replacing the FAX PWB	The FAX PWB is faulty.	Replace the FAX PWB.	

U00690/E00690

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	System error	Turn off the power switch and pull out the power plug. After passing 5s, reinsert the power plug and turn on the power switch.	
2	Measures for the system error	System error in the main unit	Perform the corrective actions for the system error in the main unit.	

U00800/E00800

Step	Check description	Assumed cause	Measures	Reference
1	Checking the transmit start speed	A page transmission error occurred because of reception of a RTN or PIN signal.	In case pages are not properly sent and resending does not solve it, reduce transmit start speed and resend the data.	

U00811/E00811

Step	Check description	Assumed cause	Measures	Reference
1	Resending	A page reception error remained after retry of transmission in the ECM mode.	In case pages are not properly sent and resending does not solve it, reduce transmit start speed and resend the data.	

U00900/E00900

Step	Check description	Assumed cause	Measures	Reference
1	Re-reception	An RTN or PIN signal was transmitted because of a page reception error.	Resend the page if there is a page not transmitted properly.	

U00910/E00910

Step	Check description	Assumed cause	Measures	Reference
1	Re-reception	Some pages cannot be received after retry of transmission in the ECM mode	Resend the page if there is a page not transmitted properly.	

U01000/E01000

Step	Check description	Assumed cause	Measures	Reference
1	Resending	An FTT signal was received for a set number of times after TCF signal transmission at 2400 bps. Or, an RTN signal was received in response to a Q signal (excluding EOP) after transmission at 2400 bps.	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01001/E01001

Step	Check description	Assumed cause	Measures	Reference
1	Resending	Function as indicated by DIS signal is not consistent with the one of own machine.	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01016/E01016

Step	Check description	Assumed cause	Measures	Reference
1	Resending	T1 timeout occurs since MBF signal is received but DIS signal is not after sending EOM signal.	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	

Step	Check description	Assumed cause	Measures	Reference
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01019/E01019

Step	Check description	Assumed cause	Measures	Reference
1	Resending	Command send retrial times exceeds since significant signal is not received after sending CNC signal. (between own machines)	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01020/E01020

Step	Check description	Assumed cause	Measures	Reference
1	Resending	Command send retrial times exceeds since significant signal is not received after sending CTC signal. (ECM)	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01021/E01021

Step	Check description	Assumed cause	Measures	Reference
1	Resending	Command send retrial times exceeds since significant signal is not received after sending EOR•Q signal. (ECM)	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01022/E01022

Step	Check description	Assumed cause	Measures	Reference
1	Resending	Command send retrial times exceeds since significant signal is not received after sending RR signal. (ECM)	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	

Step	Check description	Assumed cause	Measures	Reference
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01028/E01028

Step	Check description	Assumed cause	Measures	Reference
1	Resending	T5 timeout is detected when sending in ECM (ECM)	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01052/E01052

Step	Check description	Assumed cause	Measures	Reference
1	Resending	DCN signal is received after sending RR signal (ECM)	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01080/E01080

Step	Check description	Assumed cause	Measures	Reference
1	Resending	PIP signal is received after sending PPS and NULL signals.	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01092/E01092

Step	Check description	Assumed cause	Measures	Reference
1	Resending	Communication is stopped since there are impossible combination of symbol speed and communication speed at V.34 sending.	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01093/E01093

Step	Check description	Assumed cause	Measures	Reference
1	Checking the settings	The modem is not detected since the received signal is attenuated with its frequency response.	Set the modem detection level at U650 [RX Mm Level]. (Initial setting: -43dBm)	
2	Checking the settings	The modem is not detected since the received signal is attenuated with its frequency response.	Set the G3 reception cable equalizer in U650 [Rag G3 RX Ear]. (Initial setting: 0dBm)	

U01094/E01094

Step	Check description	Assumed cause	Measures	Reference
1	Resending	DCS/NSS signal send retrial time is exceeded at phase B during transmission.	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01095/E01095

Step	Check description	Assumed cause	Measures	Reference
1	Resending	Command send retry time is exceeded since the significant signal is not received after sending (PPS) Q signal at phase D during transmission.	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01096/E01096

Step	Check description	Assumed cause	Measures	Reference
1	Resending	DCN signal or invalid command is received at phase D during transmission.	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01097/E01097

Step	Check description	Assumed cause	Measures	Reference
1	Resending	The preset number of command retransfers was exceeded after transmission of an RR signal or no response.	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01100/E01100

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	Function indicated by DCS signal is not consistent with the one of own machine.	Request the destination unit to resend the data.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01101/E01101

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	Function indicated by NSS signal except communication type is not consistent with the one of own machine.	Request the destination unit to resend the data.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01102/E01102

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	DTC (NSC) signal is received while own machine has no transmission data.	Request the destination unit to resend the data.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01110/E01110

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	No response is received after sending DIS signal.	Request the destination unit to resend the data.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01111/E01111

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	No response is received after sending DTC (NSC) signal.	Request the destination unit to resend the data.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01113/E01113

Step	Check description	Assumed cause	Measures	Reference
1	Checking the settings	The modem is not detected since the received signal is attenuated with its frequency response.	Set the modem detection level at U650 [RX Mm Level]. (Initial setting: -43dBm)	
2	Checking the settings	The modem is not detected since the received signal is attenuated with its frequency response.	Set the G3 reception cable equalizer in U650 [Rag G3 RX Ear]. (Initial setting: 0dBm)	

U01125/E01125

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	No response after transmitting a CNS signal. (Between the units of our make)	Request the destination unit to resend the data.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01129/E01129

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	No response after transmitting an SPA signal. (Short protocol)	Request the destination unit to resend the data.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01141/E01141

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	DCN signal is received after sending DTC signal.	Request the destination unit to resend the data.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01143/E01143

Step	Check description	Assumed cause	Measures	Reference
1	Checking the settings	DCN signal is received after sending FTT signal.	Set the G3 reception cable equalizer in U650 [Rag G3 RX Ear]. (Initial setting: 0dBm)	

U01155/E01155

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	DCN signal is received after sending SPA signal. (simplified protocol)	Request the destination unit to resend the data.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01160/E01160

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	Maximum transmission time per line is exceeded while receiving message.	Request the destination unit to resend the data.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01162/E01162

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	Maximum transmission time per line is exceeded while receiving message.	Request the destination unit to resend the data.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01191/E01191

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	Communication is stopped with error during image data receipt sequence at V.34.	Request the destination unit to resend the data.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01193/E01193

Step	Check description	Assumed cause	Measures	Reference
1	Checking the settings	No response, DCN signal or invalid command is received at phase C/D during reception.	Extend T2 time-out time in U641 [T2 TIME OUT]. (Change from the initial setting 69 to 150.)	

Step	Check description	Assumed cause	Measures	Reference
2	Checking the settings	Line condition is poor.	Set the corrective measures for echoes at the reception in U630 [RX Echo]. (Initial setting: 75)	
3	Changing the transmit start timing	Line condition is poor.	Change the reception starting speed to "9600bps" or less.	

U01194/E01194

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	DCN signal is received at phase B during reception.	Request the destination unit to resend the data.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01195/E01195

Step	Check description	Assumed cause	Measures	Reference
1	Checking the settings	No message is received at phase C during reception.	Extend T2 time-out time in U641 [T2 TIME OUT]. (Change from the initial setting 69 to 150.)	
2	Checking the settings	Line condition is poor.	Set the corrective measures for echoes at the reception in U630 [RX Echo]. (Initial setting: 75)	
3	Changing the transmit start timing	Line condition is poor.	Change the reception starting speed to "9600bps" or less.	

U01196/E01196

Step	Check description	Assumed cause	Measures	Reference
1	Resending	Error line control overflow and decoding error occurred in messages during reception.	Resend.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01400/E01400

Step	Check description	Assumed cause	Measures	Reference
1	Checking the telephone number	"#" exists in advance of "x" on the phone numbers of the destination unit, so it is processed as the invalid dial line.	Delete "#" from the registered numbers if "#" exists in advance of "x" on the phone numbers of the destination unit.	

U01500/E01500

Step	Check description	Assumed cause	Measures	Reference
1	Checking the transmit start speed	The communication line is the poor condition.	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
2	Checking the transmit start speed	The communication line condition is poor and an error frequently occurs.	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01600/E01600

Step	Check description	Assumed cause	Measures	Reference
1	Request to the destination unit	The communication line is the poor condition.	Request the destination unit to resend the data after reducing the transmit start speed.	
2	Changing the transmit start timing	The communication line condition is poor and an error frequently occurs.	Request the destination unit to resend the data after lowering the reception start speed.	

U01700/E01700

Step	Check description	Assumed cause	Measures	Reference
1	Resending	A communication error occurred in phase 2 (line probing).	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01720/E01720

Step	Check description	Assumed cause	Measures	Reference
1	Resending	The communication error appears at phase 4 (replacing the modem parameter).	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01721/E01721

Step	Check description	Assumed cause	Measures	Reference
1	Resending	The communication was interrupted because there is no communication speed commonly used with the destination unit.	Resend.	
2	Checking the transmit start speed	Line condition is poor. (Destination unit)	Execute U630 [TX Speed] to reduce the transmit start speed. Then, resend the data.	

Step	Check description	Assumed cause	Measures	Reference
3	Changing the initial value	Line condition is poor. (Own machine)	Change the default value of the transmit start speed by executing U630 [TX Speed].	

U01800/E01800

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	A communication error occurred in phase 2 (line probing).	Request the destination unit to resend the data after reducing the transmit start speed.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01810/E01810

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	A communication error occurred in phase 3 (primary channel equivalent device training).	Request the destination unit to resend the data after reducing the transmit start speed.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01820/E01820

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	A communication error occurred in phase 3 (primary channel equivalent device training).	Request the destination unit to resend the data after reducing the transmit start speed.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U01821/E01821

Step	Check description	Assumed cause	Measures	Reference
1	Request for resending	The communication was interrupted because there is no communication speed commonly used with the destination unit.	Request the destination unit to resend the data after reducing the transmit start speed.	
2	Changing the initial value	Line condition is poor. (Own machine)	Change the reception speed by executing U630 [RX Speed].	

U03000/E03000

Step	Check description	Assumed cause	Measures	Reference
1	Request to the destination unit	No document was present in the destination unit when polling reception started.	Request the destination unit to set the originals.	

U03200/E03200

Step	Check description	Assumed cause	Measures	Reference
1	Request to the destination unit	There is no data in the sub address box in the main unit that are specified from the destination unit.	Request the destination unit to store the original data in the sub address box.	

U03300/E03300

Step	Check description	Assumed cause	Measures	Reference
1	Request to the destination unit	The permitted ID and FAX number registered in the destination unit are incorrect.	Request the destination unit to register the own ID and the own FAX number as the permitted ID and the permitted FAX number.	

U03400/E03400

Step	Check description	Assumed cause	Measures	Reference
1	Checking the destination unit	In polling reception, the operation was interrupted because the password input in the destination unit and the own FAX number in the receiver did not match.	Revise it so that the password input at the destination machine is consistent with the receiversownFAXIDtoreceiveagain.'	

U03500/E03500

Step	Check description	Assumed cause	Measures	Reference
1	Checking the destination unit	In polling reception, the operation was interrupted because the password input in the destination unit and the own FAX number in the receiver did not match.	Revise it so that the password input at the destination machine is consistent with the receiversownFAXIDtoreceiveagain.'	

U03600/E03600

Step	Check description	Assumed cause	Measures	Reference
1	Resending	Sub address bulletin board reception was interrupted because the specified sub address password did not match.	Resend the data after inputting the sub address password registered in the destination unit.	

U03700/E03700

Step	Check description	Assumed cause	Measures	Reference
1	Checking the destination unit	Destination machine has no sub address bulletin board communication function or no originals are stored in any original delivery box (sub address box).	Check if the destination unit has a sub address bulletin board communication function. If available, request the destination unit to save the original data in the sub address box.	

U04000/E04000

Step	Check description	Assumed cause	Measures	Reference
1	Request to the destination unit	The original was transmitted to the sub address box, but the specified box was not registered in the destination unit that is our own model.	Register the sub address password in the destination unit.	
2	Checking the sub address of the FAX transmission condition	The original was transmitted to the sub address box in the destination unit that is our own model, but the sub address of the transmission condition did not match.	Match the sub address in the FAX forward condition	

U04100/E04100

Step	Check description	Assumed cause	Measures	Reference
1	Resending	The destination unit had no sub address reception capability while the sub address transmission was executed.	Transmit the data according to the reception function in the destination unit.	

U04200/E04200

Step	Check description	Assumed cause	Measures	Reference
1	Request to the destination unit	In encrypted transmission, the specified encryption box was not registered in the destination unit.	Request the destination unit to register the encrypted box.	

U04300/E04300

Step	Check description	Assumed cause	Measures	Reference
1	Resending	The encryption transmission was carried out, but there is no encryption function at the other machine.	Transmit the data according to the reception function in the destination unit.	

U04400/E04400

Step	Check description	Assumed cause	Measures	Reference
1	Checking the encryption key	Encrypted transmission was interrupted because encryption keys did not agree.	Request resending after checking the encryption key registered in the receiving and sending machines.	

U04500/E04500

Step	Check description	Assumed cause	Measures	Reference
1	Checking the encryption key	Encrypted transmission was interrupted because encryption keys did not agree.	Request resending after checking the encryption key registered in the receiving and sending machines.	

U05100/E05100

Step	Check description	Assumed cause	Measures	Reference
1	Checking the permitted number	The transmission was interrupted because the permitted ID and FAX number did not match in the restricted transmission (password check transmission).	Resend after confirming the authorization number that has been registered.	

U05200/E05200

Step	Check description	Assumed cause	Measures	Reference
1	Checking the settings	The number does not match a permitted FAX number / ID, or it matches a rejected FAX number.	Change the restricted reception settings.	
2	Request to the destination unit	The own telephone number is not informed from the destination unit.	Request the destination unit to register the own telephone number.	

U05300/E05300

Step	Check description	Assumed cause	Measures	Reference
1	Request to the destination unit	The number does not match a permitted FAX number / ID, or it matches a rejected FAX number.	Ask the destination unit to change the restricted reception settings.	
2	Request to the destination unit	The main unit did not acknowledge its phone number in question .	Request the destination unit to register the own telephone number.	

U14000/E14000

Step	Check description	Assumed cause	Measures	Reference
1	Checking the memory	The reception to the FAX box was interrupted due to memory overflow in its unit.	Print documents stored in memory and make room in memory. Or stop receiving in the FAX box.	

U14100/E14100

Step	Check description	Assumed cause	Measures	Reference
1	Request to the destination unit	Transmission was interrupted due to the memory overflow in the destination unit when transmitting into the sub address box.	Request the destination unit to release memory.	

U19000/E19000

Step	Check description	Assumed cause	Measures	Reference
1	Checking the memory	The reception was interrupted due to the memory overflow in the main unit during memory reception.	Release memory by printing originals stored in memory.	

U19100/E19100

Step	Check description	Assumed cause	Measures	Reference
1	Resending	The transmission was interrupted because there is an error in the data during transmission.	Resend.	
2	Resetting the main power	The transmission was interrupted because there is an error in the data during transmission.	Turn off the power switch and pull out the power plug. After passing 5s, reattach the FAX PWB and reinsert the power plug. Then, turn on the power switch.	

U19300/E19300

Step	Check description	Assumed cause	Measures	Reference
1	Resending	The transmission was interrupted because there is an error in the data during transmission.	Resend.	
2	Resetting the main power	The transmission was interrupted because there is an error in the data during transmission.	Turn off the power switch and pull out the power plug. After passing 5s, reattach the FAX PWB and reinsert the power plug. Then, turn on the power switch.	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the fax firmware to the latest version.	
4	Initializing the fax	The FAX initial value was changed.	Execute U600 to initialize the FAX.	

Step	Check description	Assumed cause	Measures	Reference
5	Replacing the FAX PWB	The FAX PWB is faulty.	Replace the FAX PWB.	

7 - 5 Send Related Errors

(1) Send Related Errors

No.	Contents
(1)	The sending error 2101 does not disappear even if changing the host name or the security software settings
(2)	Sending error 2203 does not disappear
(3)	The scanning data from the contact glass is automatically sent

Content of Send Related Errors

(1-1) The sending error 2101 does not disappear even if changing the host name or the security software settings

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The incorrect port number has been set.	Change the SMB port number from "139" to "445".	

(1-2) Sending error 2203 does not disappear

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The Windows Fire Wall is not properly set. (Windows Vista / 7 / 8)	Open [Control panel] > [System and Security] > Windows firewall] and select [Permit the program or function through Windows firewall]. Check [Share files and printers] and the check box on the right as well.	

(1-3) The scanning data from the contact glass is automatically sent

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	[Continuous Scan] is not set to [On].	Press [Send] key or [FAX] key, and select [On] in [Advanced setup] > [Continuous scan].	
2	Changing the setting	[Continuous Scan] is not set to [On].	Select [On] at [Functions] > [Continuous scan]	

(2) Sending Errors (Error Codes)

(2-1) Scan to E-mail Error Codes

Error code	Contents
1101	SMTP/POP3 server does not exist on the network.
1102	Login to the SMTP/POP3 server has failed.
1104	Destination address domain is restricted and transmission is denied.
1105	SMTP protocol is invalid.
1106	The sender address is not set.
2101	Connection to the SMTP/POP3 server has failed.
2102	Connection to the SMTP/POP3 server has failed. (Connection timeout)
2103	The server cannot establish communication.
2201	Communication to the SMTP/POP3 server has failed.
2202	Communication to the SMTP/POP3 server has failed. (Connection timeout)
2204	The size of scanning exceeded its limit.
3101	SMTP/POP3 server responded with an error.
3201	No SMTP authentication is found.
4803	Failed to establish the SSL session.

Content of Scan to E-mail Error Codes

Scan to E-mail error code : 1101

SMTP/POP3 server does not exist on the network.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	SMTP / POP3 server name is incorrect.	Correct the SMTP / POP3 server name at [Function Settings] > [E-mail] via the command center.	
2	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
3	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	

Scan to E-mail error code : 1102

Login to the SMTP/POP3 server has failed.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The user name or the password is incorrect.	Correct the SMTP / POP3 user name or password at [Function Settings] > [E-mail] via the command center.	
2	Changing the setting	The SMTP/POP3 server settings are incorrect.	Correct the protocol in the Network Settings via the Command Center.	

Scan to E-mail error code : 1104

Destination address domain is restricted and transmission is denied.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	Destination address domain is restricted and transmission is denied.	Correct the settings in the Network Settings via the Command Center.	

Scan to E-mail error code : 1105

SMTP protocol is invalid.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the settings	SMTP protocol is invalid.	Correct the protocol in the Network Settings via the Command Center.	

Scan to E-mail error code : 1106

The sender address is not set.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The sender address is not set.	Correct the protocol in the Network Settings via the Command Center.	

Scan to E-mail error code : 2101

Connection to the SMTP/POP3 server has failed.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	SMTP / POP3 server name is incorrect.	Correct the SMTP / POP3 server name at [Function Settings] > [E-mail] via the command center.	
2	Connecting the LAN cable	The LAN cable is not connected to the main unit.	Connect the LAN cable to the main unit.	
3	Changing the setting	The port number is incorrect.	Correct the SMTP/POP3 port number.	
4	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
5	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	
6	Changing the setting	The SMTP/POP3 server settings are incorrect.	Correct the protocol in the Network Settings via the Command Center.	

Scan to E-mail error code : 2102

Connection to the SMTP/POP3 server has failed. (Connection timeout)

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	SMTP / POP3 server name is incorrect.	Correct the SMTP / POP3 server name at [Function Settings] > [E-mail] via the command center.	
2	Changing the setting	The port number is incorrect.	Correct the SMTP/POP3 port number.	
3	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	

Step	Check description	Assumed cause	Measures	Reference
4	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	
5	Changing the setting	The SMTP/POP3 server settings are incorrect.	Correct the protocol in the Network Settings via the Command Center.	

Scan to E-mail error code : 2103

The server cannot establish communication.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the SMTP/POP3 server name	SMTP / POP3 server name is incorrect.	Correct the SMTP / POP3 server name at [Function Settings] > [E-mail] via the command center.	
2	Checking the SMTP/POP3 port No.	The port number is incorrect.	Correct the SMTP/POP3 port number.	
3	Checking the settings	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
4	Checking the settings	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	
5	Checking the settings	The SMTP/POP3 server settings are incorrect.	Correct the protocol in the Network Settings via the Command Center.	

Scan to E-mail error code : 2201

Communication to the SMTP/POP3 server has failed.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
2	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	

Scan to E-mail error code : 2202

Communication to the SMTP/POP3 server has failed. (Connection timeout)

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
2	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	

Scan to E-mail error code : 2204

The size of scanning exceeded its limit.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	

Scan to E-mail error code : 3101

SMTP/POP3 server responded with an error.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
2	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	
3	Changing the setting	The SMTP/POP3 server settings are incorrect.	Correct the protocol in the Network Settings via the Command Center.	

Scan to E-mail error code : 3201

No SMTP authentication is found.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The SMTP server settings are incorrect.	Set the correct SMTP Authentication Protocol at [Function Settings] > [E-mail] via the command center.	

Scan to E-mail error code : 4803

Failed to establish the SSL session.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The self-signed certificate of the device is incorrect.	Correct the certificates in the Security Settings via the Command Center.	
2	Changing the setting	The service certificate settings are incorrect.	Correct the certificates in the Security Settings via the Command Center.	
3	Changing the setting	The SMTP/POP3 settings are incorrect.	Correct the protocol in the Network Settings via the Command Center.	

(2-2) Scan to FTP Error Codes

Error code	Contents
1101	FTP server does not exist on the network.
1102	Login to the FTP server has failed.
1105	FTP protocol is not enabled.
1131	Initializing TLS has failed.
1132	TLS negotiation has failed.
2101	Connection to the FTP server has failed.
2102	Connection to the FTP server has failed. (Timeout)
2103	The server cannot establish communication.
2201	Communication with the FTP server has failed.
2202	Communication with the FTP server has failed. (Timeout)
2203	No response from the server during a specific period of time.
2231	Communication with the FTP server has failed. (FTPS communication)
3101	FTP server responded with an error.

Content of Scan to FTP Error Codes

Scan to FTP error code : 1101

FTP server does not exist on the network.

Step	Check description	Assumed cause	Measures	Reference
1	Correcting the FTP host name	The FTP host name is incorrect.	Correct the FTP host name via the Command Center.	
2	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
3	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	

Scan to FTP error code : 1102

Login to the FTP server has failed.

Step	Check description	Assumed cause	Measures	Reference
1	Correcting the user name or the password	The user name or the password is incorrect.	Correct the user name and the password.	
2	Changing the setting	FTP server is improper.	Correct the protocol in the Network Settings via the Command Center.	

Scan to FTP error code : 1105

FTP protocol is not enabled.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	FTP protocol is not enabled.	Correct the protocol in the Network Settings via the Command Center.	

Scan to FTP error code : 1131

Initializing TLS has failed.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The security settings of the device are incorrect.	Correct the settings in the Security Settings via the Command Center.	

Scan to FTP error code : 1132

TLS negotiation has failed.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The security settings of the device are incorrect.	Correct the settings in the Security Settings via the Command Center.	
2	Changing the setting	The FTP server settings are incorrect.	Correct the protocol in the Network Settings via the Command Center.	

Scan to FTP error code : 2101

Connection to the FTP server has failed.

Step	Check description	Assumed cause	Measures	Reference
1	Correcting the FTP host name	The FTP host name is incorrect.	Correct the FTP host name via the Command Center.	
2	Checking the LAN cable	The LAN cable is not connected to the main unit.	Connect the LAN cable to the main unit.	
3	Correcting the FTP port no.	The port number is incorrect.	Correct the FTP port number.	
4	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
5	Changing the setting	The FTP server settings are incorrect.	Correct the protocol in the Network Settings via the Command Center.	

Scan to FTP error code : 2102

Connection to the FTP server has failed. (Timeout)

Step	Check description	Assumed cause	Measures	Reference
1	Correcting the FTP host name	The FTP host name is incorrect.	Correct the FTP host name via the Command Center.	
2	Correcting the FTP port no.	The port number is incorrect.	Correct the FTP port number.	
3	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
4	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	
5	Changing the setting	The FTP server settings are incorrect.	Correct the protocol in the Network Settings via the Command Center.	

Scan to FTP error code : 2103

The server cannot establish communication.

Step	Check description	Assumed cause	Measures	Reference
1	Correcting the FTP host name	The FTP host name is incorrect.	Correct the FTP host name via the Command Center.	
2	Correcting the FTP port no.	The port number is incorrect.	Correct the FTP port number.	
3	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
4	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	
5	Changing the setting	The FTP server settings are incorrect.	Correct the protocol in the Network Settings via the Command Center.	

Scan to FTP error code : 2201

Communication with the FTP server has failed.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	

Step	Check description	Assumed cause	Measures	Reference
2	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	
3	Correcting the destination folder name	The destination folder name is incorrect.	Set the correct destination folder.	
4	Changing the setting	The FTP server settings are incorrect.	Correct the protocol in the Network Settings via the Command Center.	

Scan to FTP error code : 2202

Communication with the FTP server has failed. (Timeout)

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
2	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	

Scan to FTP error code : 2203

No response from the server during a specific period of time.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
2	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	

Scan to FTP error code : 2231

Communication with the FTP server has failed. (FTPS communication)

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
2	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	

Scan to FTP error code : 3101

FTP server responded with an error.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
2	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	
3	Changing the setting	The FTP server settings are incorrect.	Correct the protocol in the Network Settings via the Command Center.	

(2-3) Scan to SMB Error Codes

Error code	Contents
1101	Destination host does not exist on the network.
1102	Login to the host has failed.
1103	Destination host, folder, and/or file names are invalid.
1105	SMB protocol is not enabled.
2101	Login to the host has failed.
2201	Writing scanned data has failed.
2203	No response from the host during a specific period of time.

Content of Scan to SMB Error Codes

Scan to SMB error code : 1101

Destination host does not exist on the network.

Step	Check description	Assumed cause	Measures	Reference
1	Correcting the destination host name	The destination host name is incorrect.	Correct the destination host name.	
2	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
3	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	

Scan to SMB error code : 1102

Login to the host has failed.

Step	Check description	Assumed cause	Measures	Reference
1	Correcting the user name and the password	The user name or the password is incorrect.	Correct the user name and the password.	
2	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
3	Changing the setting	The sharing settings of the destination host / folder are incorrect.	Correct the sharing settings of the destination host / folder.	

Scan to SMB error code : 1103

Destination host, folder, and/or file names are invalid.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the destination host name, destination folder name and the file name	The invalid character is included.	Correct the destination host name, folder name or the file name if the invalid characters are included.	
2	Correcting the destination folder name and the file name	The destination folder name or the file name is incorrect.	Revise the destination folder and file name according to the naming rules.	
3	Changing the setting of the destination host and folder.	The destination host or the destination folder is not set properly.	Revise the destination host and destination folder properly.	

Scan to SMB error code : 1105

SMB protocol is not enabled.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The settings of the SMP protocol are incorrect.	Correct the protocol in the Network Settings via the Command Center.	

Scan to SMB error code : 2101

Login to the host has failed.

Step	Check description	Assumed cause	Measures	Reference
1	Correcting the destination host name	The destination host name is incorrect.	Correct the destination host name.	
2	Checking the LAN cable	The LAN cable is not connected to the main unit in the transmission (Scan to SMB).	Connect the LAN cable to the main unit.	
3	Correcting the SMB port no.	The port number is incorrect.	Correct the SMB port number.	
4	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
5	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	

Scan to SMB error code : 2201

Writing scanned data has failed.

Step	Check description	Assumed cause	Measures	Reference
1	Correcting the sending file name	The sending file name is incorrect.	Correct the scanning file name.	
2	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
3	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	

Scan to SMB error code : 2203

No response from the host during a specific period of time.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The network settings are incorrect.	Correct the settings in the Network Settings via the Command Center.	
2	Changing the setting	The network settings that the main unit is connected to are incorrect.	Correct the network settings that the main unit is connected to.	
3	Checking the LAN cable	The LAN cable is not connected to the main unit in the transmission (Scan to SMB).	Connect the LAN cable to the main unit.	

7 - 6 Print Errors

No.	Contents	Condition
(1)	The paper loading message appears	
(2)	The paper direction is incorrect	
(3)	Paper is fed from the MP tray	The main unit MP tray setting is wrong
(4)	Garbled characters	The printer driver was not properly installed.
(5)	Paper is not fed from the MP tray	The media types of each paper source defined in the printer driver and the main unit are mismatched.
(6)	The same data is repeatedly printed out	A PC (spooler) does not properly operate.
(7)	PC window shows [Print job error], [Standby] or [Printer unavailable] is indicated on the printer properties	The main unit is not ready to print.
(8)	Attention lamp is lit while the printer standby message is indicated.	The main unit locks up.
(9)	Print is not available in sleep mode due to the main unit startup error. Attention lamp is turned on.	The main unit locks up.
(10)	Print stops after printing several pages and locks up. Attention lamp on operation panel lights.	The image processing fails due to the insufficient memory, so the main unit locks up.
(11)	Print output is unavailable due to the network factor (1)	The network has some troubles or the network setting is incorrect.
(12)	Print output is unavailable due to the network factor (2)	The cable between the main unit and the PC is not properly connected.
(13)	Print output is unavailable due to the network factor (3)	The access point (router or HUB) in the network does not operate properly.
(14)	Print output is unavailable due to the network factor (4)	The router is faulty, or the router settings are incorrect.
(15)	Print output is unavailable due to the network factor (5)	"Offline" appears and the print function is unavailable.
(16)	Print output is unavailable due to the network factor (6)	Only 1 PC can't print out of all PCs installed. There is no error indication and print job will be held if print instruction is requested.
(17)	Print output is unavailable due to the network factor (7)	The main unit IP address is changed.
(18)	Data is not printed out due to the printer driver setting (1)	[Not connected] is displayed on PC and print job can't be performed due to the error. (Can't print)
(19)	Data is not printed out due to the printer driver setting (2)	[Preparing the printer] is displayed on the operation panel. The printing document is not output and the job is held.
(20)	Data is not printed out due to the printer driver setting (3)	A PC does not recognize the main unit.
(21)	Data is not printed out due to the printer driver setting (4)	PC operation does not stabilize.
(22)	Data is not printed out due to the printer driver setting (5)	Check if the issue occurs when printing the data from all PCs in the network or from a certain PC. Then, print out the data from another PC if it occurs at a certain PC.
(23)	Data is not printed out due to the printer driver setting (6)	The incorrect printer driver was selected.
(24)	Data is not printed out due to the printer driver setting (7)	Installed printer driver shows "Deleting" and it remains when reinstalling it
(25)	The printed image is partly missing	The image data processing with a certain application (Excel, PDF) is faulty.
(26)	"Paper Mismatch Error" appears	The paper size is not detected properly.

Content of Print Errors

(1) The paper loading message appears

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper	The size of the loaded paper did not match the paper size set in the printer properties.	Load the paper of the paper size defined at "Paper size" in the [Basic] tab in the print settings at the PC to the cassette.	
2	Checking the paper size	The paper size on the operation panel and the one set for the paper source do not match.	Check if the paper size on the operation panel and the one set for the paper source do not match	
3	Relocating the paper width guides	The locations of the paper width guides do not fit with the paper size.	Relocate the paper width guides to fit them with the paper size.	
4	Checking the actuator and the spring	The actuator or the spring does not operate properly.	Reattach the actuator and the spring for the upper / lower paper sensors. If not repaired, replace them.	
5	Checking the situation	The print data generated by a certain application (Word) is faulty.	Check if the print data not generated by a certain application (Word) is output properly. And then, change the application setting if necessary.	
6	Changing the setting	Paper orientation is not properly set in the print page setting on a certain application (Word).	Check the page orientation with preview before printing and reset the page orientation at the print setting on a certain application (Word).	
7	Checking the settings	The paper size and the media type detected at the main unit did not match with the paper size and the media type set in the printer driver.	Check if the paper size detected on the MP tray and the media type of the MP tray set via the System Menu (for the main unit) matched to the paper size and the media type at [Imaging] > [Basic] in the printer properties at the PC.	
8	Changing the setting	The MP tray setting does not match between the main unit and printer driver	Select "MP tray" at [Source] in the [Basic] tab in the print settings at the PC.	

(2) The paper direction is incorrect

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	There is a communication error.	Turn the power switch off after confirming there is no job in process at PC and main unit. When passing 5s, turn the power switch on.	
2	Checking the font list	Font for special data is not resident.	After checking output from Excel and Word is normal, print the font list to check if a font supported to special data is built in.	
3	Selecting the bitmap font	The bitmap font (default setting) is unselected.	Select the bitmap font (default setting) and print the data.	
4	Checking the printer driver	The printer driver is faulty.	Uninstall and reinstall the printer driver.	

(3) Paper is fed from the MP tray

The main unit MP tray setting is wrong

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The Auto Cassette Change is [On].	Change the Auto cassette change setting to [OFF] if paper is not available in the selected cassette, paper will not be fed. ([System Menu/Counter] > [Printer] > [Auto Cassette Change] > [OFF])	
2	Changing the setting	"Media type" in the [Basic] tab in the print settings at the PC differs from the media type of the cassette that is set in the main unit.	Check the media type set on the main unit cassette and MP tray and set the media type for the main unit in the [Basic] tab in the print settings at the PC.	
3	Changing the setting	The same media type is set between the main unit cassette and MP tray	Set different media types between the main unit cassette and MP tray	

(4) Garbled characters

The printer driver was not properly installed.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	There is a communication error.	Turn the power switch off after confirming there is no job in process at PC and main unit. When passing 5s, turn the power switch on.	
2	Checking the font list	Font for special data is not resident.	After checking output from Excel and Word is normal, print the font list to check if a font supported to special data is built in.	
3	Selecting the bitmap font	The bitmap font (default setting) is unselected.	Select the bitmap font (default setting) and print the data.	
4	Checking the printer driver	The printer driver is faulty.	Uninstall and reinstall the printer driver.	

(5) Paper is not fed from the MP tray

The media types of each paper source defined in the printer driver and the main unit are mismatched.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the settings	The paper size and the media type detected at the main unit did not match with the paper size and the media type set in the printer driver.	Check if the paper size detected on the MP tray and the media type of the MP tray set via the System Menu (for the main unit) matched to the paper size and the media type at [Imaging] > [Basic] in the printer properties at the PC.	
2	Changing the setting	The MP tray setting does not match between the main unit and printer driver	Select "MP tray" at [Source] in the [Basic] tab in the print settings at the PC.	

(6) The same data is repeatedly printed out

A PC (spooler) does not properly operate.

Step	Check description	Assumed cause	Measures	Reference
1	Deleting the job	The generated data is faulty.	Delete the print job spooled in the PC and print it out again.	

(7) PC window shows [Print job error], [Standby] or [Printer unavailable] is indicated on the printer properties

The main unit is not ready to print.

Step	Check description	Assumed cause	Measures	Reference
1	Clearing the error	The main unit is not ready to print.	Check if an error is displayed on the operation panel or [Attention] lamp blinks. Then, clear the error.	
2	Checking the main unit	The main unit is not ready to print.	Resolve the problem at the main unit if any	

(8) Attention lamp is lit while the printer standby message is indicated.

The main unit locks up.

Step	Check description	Assumed cause	Measures	Reference
1	Clearing the error	The main unit is not ready to print.	Cancel the print jobs of all the PCs after confirming no error appears on the operation panel. Then, turn the power switch off. When passing 5s, turn the power switch on.	

(9) Print is not available in sleep mode due to the main unit startup error. Attention lamp is turned on.

The main unit locks up.

Step	Check description	Assumed cause	Measures	Reference
1	Firmware upgrade	The firmware is not the latest version.	Upgrade the firmware to the latest version.	
2	Changing the setting	The sleep level is not set to Quick Recovery mode.	Turn the power switch off. When passing 5s, turn the power switch on. Then, set Sleep Level to Quick Recovery	

(10) Print stops after printing several pages and locks up. Attention lamp on operation panel lights.

The image processing fails due to the insufficient memory, so the main unit locks up.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the situation	The data processing in a certain PC is faulty.	Check if the issue occurs when printing the data from all PCs in the network or from a certain PC. Then, print out the data from another PC if it occurs at a certain PC.	
2	Checking the situation	The application is not properly set.	Check if a problem occurring from a certain application and file (big data like CAD data) and change application setting and refer to application's help.	
3	Firmware upgrade	The firmware is not the latest version.	Upgrade the main firmware to the latest version.	
4	Deleting the job	Processing fails.	Cancel the job in process and reprint in the main unit job status	
5	Resetting the main power	The main unit locks up.	If the operation panel or the buttons are not active, turn the power switch off and unplug the power plug. After 5s passes, reconnect the power plug and turn the power switch on.	

(11) Print output is unavailable due to the network factor (1)

The network has some troubles or the network setting is incorrect.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the network	There is trouble in the network.	Check if the memory LED on the operation panel of the main unit is blinking after printing out from the PC. If not blinking, cancel the processing job and reprint out.	
2	Checking the network	There is trouble in the network.	When the printing error appears on the operation panel or the PC screen, clear the error caused by the toner or paper jam, etc.	
3	Checking the network	There is trouble in the network.	Check the main unit IP Address in the status page, etc. and then check if Command Center can be opened using that IP Address. If not, reconfigure the network again.	
4	Checking the network	There is trouble in the network.	Check the internet connection and restore the network connection if necessary	
5	Checking the network	There is trouble in the network.	Check the cable and reset the router or HUB.	
6	Restarting up	The PC or the main unit locks up.	Restart the PC or the main unit, and print out again.	

(12) Print output is unavailable due to the network factor (2)

The cable between the main unit and the PC is not properly connected.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the cable	The cable between the main unit and the PC is not properly connected.	Check the cable connection between the main unit and the PC.	
2	Restarting up	The main unit or the PC does not properly start up.	Restart the main unit and then restart the PC.	
3	Checking the Ethernet cable	The Ethernet cable is faulty.	Replace the Ethernet cable.	
4	Changing the connection	Another network is faulty.	Directly connect the main unit to the PC with the cross cable and then check if the same data can be printed out.	

(13) Print output is unavailable due to the network factor (3)

The access point (router or HUB) in the network does not operate properly.

Step	Check description	Assumed cause	Measures	Reference
1	Restarting up	The router or the HUB does not properly activate.	Check if the link lamp of the router or hub is lit and restart it.	
2	Checking the Ethernet cable	The Ethernet cable is not properly connected.	In case the link lamp is off, once disconnect the Ethernet cable from the router and reconnect it to check the link lamp is lit.	
3	Checking the Ethernet cable	The Ethernet cable is faulty.	Replace the Ethernet cable.	
4	Restarting up	The router, HUB, PC or the main unit do not start up properly.	In case of no connection while the link lamp is lit, restart the router or hub and then restart up the PC and the main unit.	

(14) Print output is unavailable due to the network factor (4)

The router is faulty, or the router settings are incorrect.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The IP address is not properly set.	Check if the main unit IP Address indicated in the status page is the same as the IP Address in the [Port] tab of [Printer Properties] at the PC. If not, correct the IP address at the PC	
2	Changing the setting	The printer host name is not properly set.	Check the printer host name by printing out the status report when there is a server environment. Then, check the printer host name at the [Port] tab in the printer properties at a PC. If they differ, correct the printer host name.	

(15) Print output is unavailable due to the network factor (5)

"Offline" appears and the print function is unavailable.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the network	There is trouble in the network.	Check the internet connection and restore the network connection if necessary	
2	Restarting up	The PC malfunctions.	When "Offline" appears on the printer driver, check if it is used in the pause or offline. Then, restart up the PC.	
3	Changing the setting	The application is not properly set.	Check if the other Excel / Word data can be output and change the setting of the application.	
4	Changing the setting	The IP address is not properly set.	Check if the main unit IP Address indicated in the status page is the same as the IP Address in the [Port] tab of [Printer Properties] at the PC. If not, correct the IP address at the PC	
5	Restarting up	The IP address is not properly set.	Check if communication via command center or PING is available with IP address set up. Set up IP address again and restart the main unit if necessary.	
6	Restarting up	The port settings in the printer properties at the PC are incorrect.	Remove the checks at the dual-directional support and the SNMP status in the [Port] tab of the printer properties in a PC. Then, restart up the main unit and the PC.	
7	Restarting up	The main unit does not start up properly.	After the printer is ready, check if the test sheet can be output and restart the main unit.	

(16) Print output is unavailable due to the network factor (6)

Condition:

PC OS: Windows 7

Print file: Test page

Connecting method: Wireless LAN

Only 1 PC can't print out of all PCs installed. There is no error indication and print job will be held if print instruction is requested.

Step	Check description	Assumed cause	Measures	Reference
1	Restarting up	The main unit or the PC does not properly start up.	Restart up the main unit or the PC.	
2	Checking the cable	The cable is not properly connected.	Check the cable connection (Check if the network connection is available.)	
3	Checking the IP address	The IP address is not properly set.	Check if the ID address is properly set, and correct it if incorrect.	
4	Checking the network	There is trouble in the network.	Check if access via command center or PING is available and then check the hub or router.	
5	Changing the setting	The printer port IP address, the SNMP of the printer driver, or the bi-directional support is not properly set.	Correct the IP address and remove the checks at the SNMP status and the dual-directional support in the [Port] tab of the printer properties at a PC. Then, restart up the main unit and the PC.	
6	Uninstalling the security software or setting the exception	The restriction of the security software causes the phenomenon.	Check if the printer is available by uninstalling the security software. Or, set the exception setting.	

(17) Print output is unavailable due to the network factor (7)

The main unit IP address is changed.

Step	Check description	Assumed cause	Measures	Reference
1	Restarting up	There is trouble in the network.	Check if a problem occurs with output from all PCs on the network and restart up hub or router.	
2	Checking the cable	The cable is not properly connected.	Check if there is problem with the cable connection on the network.	
3	Restarting up	The main unit does not start up properly.	If the operation panel or the buttons are not active, turn the power switch off and unplug the power plug. After 5s passes, reconnect the power plug and turn the power switch on.	
4	Changing the setting	IP address was changed.	Check if the main unit IP Address indicated in the status page is the same as the IP Address in the [Port] tab of [Printer Properties] at the PC. If not, correct the IP address at the PC	
5	Changing the setting	The static IP Address is not set in the System Menu	Set the static IP Address in the System Menu	

(18) Data is not printed out due to the printer driver setting (1)

Condition:

PC OS: Windows 7

Print file: Test page

Connecting method: Wireless LAN

[Not connected] is displayed on PC and print job can't be performed due to the error. (Can't print)

Step	Check description	Assumed cause	Measures	Reference
1	Deleting the job	The faulty print job is remaining.	Check if the print job remains in the printer driver and delete the remaining.	

(19) Data is not printed out due to the printer driver setting (2)

Condition:

PC OS: Windows 7

Print file: Test page

Connecting method: Wireless LAN

[Preparing the printer] is displayed on the operation panel. The printing document is not output and the job is held.

Step	Check description	Assumed cause	Measures	Reference
1	Deleting the job	The faulty print job is remaining.	Check if the print job remains in the printer driver and delete the remaining.	

(20) Data is not printed out due to the printer driver setting (3)

A PC does not recognize the main unit.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the settings	The printer driver is not properly set.	Check if the printer icon of PC is [Ready]. (Right click the printer icon and execute the trouble shooting)	
2	Installing the printer driver	The printer driver is faulty.	Uninstall and reinstall the printer driver.	
3	Restarting up	The PC does not start up properly.	Restart up the PC.	
4	Checking the printer driver	The printer driver is not the latest version.	Update the printer driver.	

(21) Data is not printed out due to the printer driver setting (4)

PC operation does not stabilize.

Step	Check description	Assumed cause	Measures	Reference
1	Restarting up	The printer driver is not properly set.	Restart PC. (In case if many application software are running or the free space of the PC memory /SSD is low)	

(22) Data is not printed out due to the printer driver setting (5)

Check if the issue occurs when printing the data from all PCs in the network or from a certain PC. Then, print out the data from another PC if it occurs at a certain PC.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the IP address	The IP address is not properly set.	Check if the IP Address indicated in the main unit status report and system menu is same as the IP address in the port setting of [Printer Properties] at the PC. If not, correct the IP address at the port setting	

(23) Data is not printed out due to the printer driver setting (6)

The incorrect printer driver was selected.

Step	Check description	Assumed cause	Measures	Reference
1	Installing the printer driver	The incorrect printer driver is selected.	Select the correct printer driver. If it is not in the PC, install the printer driver for the destination unit in the PC.	

(24) Data is not printed out due to the printer driver setting (7)

Installed printer driver shows "Deleting" and it remains when reinstalling it

Step	Check description	Assumed cause	Measures	Reference
1	Deleting the job	The print jobs remain in the spool inside the printer driver.	Delete all print jobs spooling inside the printer driver.	
2	Uninstalling the printer driver	There is the unused printer driver.	Delete the unused printer driver.	
3	Restarting the print	The system is pausing.	Right click the pausing printer icon and select [Print resuming]. Then, check the ready port.	
4	Checking the settings	The host name or the IP address is not properly set.	When the main unit connects to a local network, check the host name and the IP address on the status report of the main unit.	
5	Adding the Standard TCP/IP port	There is no main unit IP Address in the Standard TCP/IP Port	Add the main unit IP address in Standard TCP/IP port and print Test Page	

(25) The printed image is partly missing

The image data processing with a certain application (Excel, PDF) is faulty.

Step	Check description	Assumed cause	Measures	Reference
1	Checking the situation	The image data processing with a certain application (Excel, PDF) is faulty.	When the phenomenon occurs with a certain file only, check if there is an abnormality in the image data.	
2	Checking the situation	The data processing with a certain application (Excel, PDF) is faulty.	Check if the image does not drop out on the print preview, and refer to the Help in the application if necessary.	
3	Changing the setting	The PDL settings is incorrect.	Select "GDI compatible mode" at [PDL settings] in the print settings at the PC.	
4	Firmware upgrade	The firmware is not the latest version.	Upgrade the main firmware to the latest version.	

(26) "Paper Mismatch Error" appears

The paper size is not detected properly.

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	The paper size for the MP tray is not properly set.	Adjust the MP tray paper size	
2	Resetting the MP paper width guides	The locations of the MP paper width guides do not match the paper size.	Reset the MP paper width guides to match the paper size.	
3	Checking the MP tray	The MP tray is not pulled out.	Pull out the MP tray to extend it if the A3 size paper is not detected.	
4	Changing the setting	The paper size is not set properly in the System Menu.	Register the custom size in [MP Tray Setting] in the System Menu > [Paper Size] > [Size Entry].	
5	Changing the setting	Paper Mismatch Error is set to [Ignore].	Set [Ignore] at [Common Settings] > [Error Handlings] > [Paper Mismatch Error] via the System Menu.	

7 - 7 Error Messages

No.	Contents
(1)	"Check the document processor" appears
(2)	[Error occurred in cassette X] is displayed (Cassette 1) even after removing/inserting the cassette and checking/removing paper remaining in the main unit
(3)	[Error occurred in cassette X] is displayed (Cassette 2, 3) even after removing/inserting the cassette and checking/removing paper remaining in the main unit
(4)	The cover open message appears after closing the front cover
(5)	The cover open message remains after closing the front cover
(6)	The add paper message appears while the paper is loaded on the MP tray
(7)	When DP is used, [Remove the original from document processor] is wrongly displayed

Content of Error Messages

(1) "Check the document processor" appears

Closing of the document processor cannot be detected.

Step	Check description	Assumed cause	Measures	Reference
1	Executing U244	The DP opening/closing switch does not operate properly.	Execute U244 [Open]. If the DP opening/closing switch does not operate properly, reattach it and reconnect the connector. If not repaired, replace it.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • DP opening/closing switch - DP PWB • DP PWB - Low-voltage PWB	
3	Checking the DP opening/closing switch signal	The DP opening/closing switch signal output is faulty.	Check the output of the DP opening/closing switch signal on the DP PWB.	
4	Replacing the DP PWB	The DP PWB is faulty.	Replace the DP PWB.	
5	Firmware upgrade	The firmware is faulty.	Upgrade the firmware to the latest version.	
6	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

(2) [Error occurred in cassette X] is displayed (Cassette 1) even after removing/inserting the cassette and checking/removing paper remaining in the main unit

Step	Check description	Assumed cause	Measures	Reference
1	Reinstalling the paper feed unit	The paper feed unit is not inserted completely.	Pull the paper feed unit out, then reinsert it completely.	
2	Checking the lift plate	The lift plate does not rise up.	Reattach the lift plate. If it is deformed, replace it.	
3	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Lift motor - Engine PWB	
4	Replacing the lift motor	The lift motor is faulty.	Replace the lift motor.	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

(3) [Error occurred in cassette X] is displayed (Cassette 2, 3) even after removing/inserting the cassette and checking/removing paper remaining in the main unit

Object: Paper feeder

Step	Check description	Assumed cause	Measures	Reference
1	Reinstall the PF feed unit	The PF paper feed unit is not inserted completely.	Pull the PF paper feed unit out, and then reinsert it completely.	
2	Checking the lift plate	The PF lift plate does not rise up.	Reattach the PF lift plate. If it is deformed, replace it.	
3	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • PF lift motor 2 - PF PWB (YC6) • PF upper limit sensor 2 - PF PWB (YC5) 	
4	Replacing the PF lift motor	The PF lift motor is faulty.	In case if it does not improve even U906 (Reset disable function) is executed, replace the PF lift motor 1 and 2.	
5	Replacing the PF PWB	The PF PWB is faulty.	Replace the PF PWB.	
6	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

(4) The cover open message appears after closing the front cover

Step	Check description	Assumed cause	Measures	Reference
1	Reattaching the front cover	The front cover does not turn the front cover sensor on due to the fitting failure.	Reattach the front cover.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Front cover switch - Low-voltage PWB 	
3	Replacing the front cover switch	The front cover switch is faulty.	Replace the front cover switch.	

(5) The cover open message remains after closing the front cover

Step	Check description	Assumed cause	Measures	Reference
1	Checking the right cover switch	The covers are not fitted.	The right cover switch does not turn on when closing the right cover. If turning on when directly pressing it, check the cover. If the cover does not match, reattach it.	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Right cover switch - Engine PWB 	
3	Replacing the right cover switch	The right cover switch is faulty.	Replace the right cover switch.	

(6) The add paper message appears while the paper is loaded on the MP tray

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • MP paper sensor - Relay connector • Relay connector - Engine PWB 	
2	Replacing the actuator	The actuator is deformed.	Replace the actuator for the MP paper sensor.	
3	Checking the MP paper sensor	The MP paper sensor is not properly attached or it is faulty.	Reattach the MP paper sensor, and replace it if it is not fixed.	
4	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

(7) When DP is used, [Remove the original from document processor] is wrongly displayed

Step	Check description	Assumed cause	Measures	Reference
1	Checking the connection	The DP original sensor wire is faulty	Check the DP original sensor wire. If it is constantly on due to short-circuit, replace the wire. <ul style="list-style-type: none"> • DP original sensor - DP PWB 	
2	Checking the actuator	The actuator is deformed.	Replace the actuator for the DP original sensor	
3	Checking the DP original sensor	The DP original sensor is not attached properly or faulty.	Reattach the DP original sensor. If not repaired, replace it.	
4	Replacing the DP PWB	The DP PWB is faulty.	Replace the DP PWB.	

7 - 8 Abnormal Noise

No.	Contents	Condition
(1)	Abnormal noise (Basic support)	
(2)	Abnormal sounds from the paper conveying section	Frictional wear, smudges / foreign objects adhesion on the conveying rollers, pulleys and the gears
(3)	Abnormal sound from the developer section	Caused by the developer unit.
(4)	Abnormal sound from the document processor	The frictional wear, affixing the smudges or the foreign objects, improperly attaching of the part
(5)	Abnormal sound from the exit section	Smudges / foreign objects adhesion in the exit section
(6)	Fan rotating sounds are noisy	Fan motor is dirty or faulty.
(7)	Abnormal sound from the paper feed section	Wear, dirtiness, foreign material adhesion or attachment failure at the paper feed section
(8)	Abnormal sound from the MP feed section	Wear, dirtiness, foreign objects adhesion or attachment failure at the MP feed section
(9)	Abnormal sound from the fuser exit section	The fuser exit roller bushing and pulley are dirty and foreign objects adhere to them
(10)	Abnormal sound from the fuser section	Smudges / foreign objects adhesion or the interference between the parts in the fuser section
(11)	Abnormal sound from inside the machine	Toner container drive failure, toner supply shutter opening/closing failure or toner aggregation
(12)	Abnormal sound from inside the machine	Smudges / foreign objects adhesion or the toner condensation in the developer section
(13)	Abnormal sound from inside the machine	Frictional wear, smudges / foreign objects adhesion, or the waste toner clogging in the drum section
(14)	Abnormal sound from rear side of the main unit	

Content of Abnormal Noise

(1) Abnormal noise (Basic support)

Step	Check description	Assumed cause	Measures	Reference
1	Applying the grease	The grease on each gear or bushing is not enough.	Check the rotation of the roller, the pulley or the gear, if they do not rotate smoothly, apply the grease on the gears or the bearings. (EM-50LP, Part number: 7BG010009H)	
2	Reattaching the gears or the bearings	The parts such as each gear or bushing are not properly attached.	Reattach the gear or the bearings.	

(2) Abnormal sounds from the paper conveying section

Frictional wear, smudges / foreign objects adhesion on the conveying rollers, pulleys and the gears

Step	Check description	Assumed cause	Measures	Reference
1	Cleaning and applying the grease	The bushing or the gear is dirty or foreign objects are on them.	Clean the bearings and the gears of the conveying related rollers, and apply the grease (EM-50LP, Part number: 7BG010009H).	
2	Cleaning and applying the grease	The inside of the pulley is worn down.	Clean the drive shaft of the conveying related pulley and apply the Hanarl. (302LV94550)	

Step	Check description	Assumed cause	Measures	Reference
3	Checking the pressure spring	Pressure of the conveying related roller and pulley are weak, and the bearing vibrates as the roller and pulley rotate.	Reattach the pressure springs of the conveying related rollers or the pulleys, or replace them.	
4	Replacing the drive unit	The parts in the drive unit are faulty.	Replace the drive unit	

(3) Abnormal sound from the developer section

Caused by the developer unit.

Step	Check description	Assumed cause	Measures	Reference
1	Executing U030	(Specify that the abnormal noise arises from the developer unit.)	Execute U030 [DLP] to check if the abnormal noise arises from the developer unit. Then, go to the next step.	
2	Checking the developer unit	The developer unit drive is faulty.	Check if the developer is not leaking from the developer unit, there is no damaged location, and whether the roller rotates manually. Repair if necessary.	
3	Developer unit replacement	The developer unit is faulty.	Replace the developer unit.	

(4) Abnormal sound from the document processor

The frictional wear, affixing the smudges or the foreign objects, improperly attaching of the part

Step	Check description	Assumed cause	Measures	Reference
1	Cleaning and applying the grease	The bushing or the gear is dirty or foreign objects are on them.	Clean the bearings and the shafts of the DP conveying roller, and apply the grease (EM-50LP, Part number: 7BG010009H).	
2	Replacing the bushing	The bushing is worn down.	Replace the bearing of the DP conveying roller.	
3	Cleaning and applying the grease	The drive gear is dirty or foreign objects are on it.	Clean the gears which transmit the drive to the DP conveying roller, and apply the grease (EM-50LP, Part number: 7BG010009H).	
4	Reattaching the motor	The motor does not engage with the drive gear.	Reattach the DP conveying related motors.	

(5) Abnormal sound from the exit section

Smudges / foreign objects adhesion in the exit section

Step	Check description	Assumed cause	Measures	Reference
1	Cleaning and applying the grease	The bushing or the gear is dirty or foreign objects are on them.	Clean the bushings and gears of the conveying rollers and apply the Hanarl (EM-50LP, Part number: 7BG010009H).	
2	Cleaning and applying the grease	The inside of the pulley is worn down.	Clean the drive shaft of the conveying pulleys and apply the Hanarl. (302LV94550)	
3	Cleaning and applying the grease	The bearings are dirty or the foreign objects adhere.	Clean the reverse guide and the shaft of the exit feed-shift guide. If it is not possible to remove the dirt or the foreign objects, replace them.	
4	Checking the exit motor	The exit motor is faulty.	Execute U030 [Exit]. If the abnormal sound occurs, replace the exit reverse motor.	

(6) Fan rotating sounds are noisy

Fan motor is dirty or faulty.

Step	Check description	Assumed cause	Measures	Reference
1	Cleaning the fan motor	The fan of the fan motor is dirty.	Execute U037 and specify the fan motor which has a high rotation sound, and clean the fan.	
2	Replacing the fan motor	The fan motor is faulty.	Reattach the fan motor and reconnect the connector. If not repaired, replace it.	

(7) Abnormal sound from the paper feed section

Wear, dirtiness, foreign material adhesion or attachment failure at the paper feed section

Step	Check description	Assumed cause	Measures	Reference
1	Checking the gear and the clutch	The parts such as the gear or the clutch are not properly attached.	Reattach the gear or the clutch at the paper feed drive section if they are not properly attached.	
2	Cleaning and applying the grease	The gear or the bushing is dirty or foreign objects are on them.	Clean the gears and the bearings of the feed drive section, and apply the grease. (EM-50LP, Part number: 7BG010009H)	
3	Cleaning and applying the grease	The shaft or the bushing is dirty or foreign objects are on them.	Clean the shaft and the bearings of the feed roller, and apply the grease. (EM-50LP, Part number: 7BG010009H)	
4	Checking the paper feed roller	The paper feed roller surface is dirty or worn down.	Clean the paper feed roller, or replace it if necessary.	

(8) Abnormal sound from the MP feed section

Wear, dirtiness, foreign objects adhesion or attachment failure at the MP feed section

Step	Check description	Assumed cause	Measures	Reference
1	Checking the gear and the clutch	The parts such as the gear or the clutch are not properly attached.	When the gears or the clutch in the MP paper feed drive section are not properly attached, reattach them.	
2	Cleaning and applying the grease	The shaft or the bushing is dirty or foreign objects are on them.	Clean the shaft and the bearings of the MP feed roller, and apply the grease. (EM-50LP, Part number: 7BG010009H)	
3	Checking the MP friction pad	The surface of the MP friction pad is dirty or worn out.	Clean the MP friction pad and replace it if necessary.	
4	Checking the MP lift plate	The MP lift plate is not attached properly.	Reattach the MP lift plate.	

(9) Abnormal sound from the fuser exit section

The fuser exit roller bushing and pulley are dirty and foreign objects adhere to them

Step	Check description	Assumed cause	Measures	Reference
1	Cleaning and applying the grease	The fuser exit roller, bushing or stop ring is dirty, or foreign objects adhere to it.	Clean the fuser exit roller, the bushing, stop ring, etc., and apply heat-resistant grease.	

(10) Abnormal sound from the fuser section

Smudges / foreign objects adhesion or the interference between the parts in the fuser section

Step	Check description	Assumed cause	Measures	Reference
1	Cleaning and applying the grease	The fuser exit roller, bushing or stop ring is dirty, or foreign objects adhere to it.	Clean the fuser exit roller, bushing, stop ring, pulley, etc. and apply grease (EM-50LP, Part number: 7BG010009H)	
2	Cleaning and applying the grease	The gear is dirty or foreign objects are on it.	Clean the fuser drive gear and apply the grease. (EM-50LP, Part number: 7BG010009H)	
3	Replacing the fuser unit	The fuser unit is faulty.	Replace the fuser unit.	

(11) Abnormal sound from inside the machine

Toner container drive failure, toner supply shutter opening/closing failure or toner aggregation

Step	Check description	Assumed cause	Measures	Reference
1	Checking the toner container	The torque increases due to the toner condensation.	Shake the toner container enough and reinstall it. Or, replace it.	
2	Cleaning the drive parts of the container motor	The drive gear shaft or the bearings of the container motor is dirty. Or, the foreign objects are adhered.	If the drive gear of the container motor does not rotate smoothly, clean the shaft or the bearings.	

(12) Abnormal sound from inside the machine

Smudges / foreign objects adhesion or the toner condensation in the developer section

Step	Check description	Assumed cause	Measures	Reference
1	Checking the developer unit	The shaft or the bushing of the developer roller is dirty or foreign objects are on them.	Check if the developer roller rotates. If not rotating smoothly, clean the shaft or the bushing of the developer roller.	
2	Checking the developer unit	The torque inside the developer unit increased due to the toner condensation, etc.	Clean the developer unit. Then, replace it if the issue is not resolved.	

(13) Abnormal sound from inside the machine

Frictional wear, smudges / foreign objects adhesion, or the waste toner clogging in the drum section

Step	Check description	Assumed cause	Measures	Reference
1	Executing Drum refresh	Toner is not enough on the drum.	Execute the drum refresh to supply the toner to the cleaning unit.	
2	Checking the drum screw	The drum screw does not properly rotate.	Check the drum screw rotation and if it does not rotates smoothly, clean it. If it locks, replace the IH unit.	
3	Cleaning and applying the grease	Foreign objects are on the tooth of the drum drive gear, or the grease is not enough.	Clean the tooth surface of the drum drive gear and apply the grease. (EM-50LP, Part number: 7BG010009H)	
4	Drum unit replacement	The torque inside the drum unit increased due to the waste toner clogging, etc.	Replace the drum unit.	

(14) Abnormal sound from rear side of the main unit

Step	Check description	Assumed cause	Measures	Reference
1	Reattaching the motor in the drive unit	The motor in the drive unit is faulty	Reattach the motor in the drive unit.	
2	Reattaching the drive unit	The gears in the drive unit and the neighboring gears are not engaged properly.	Reattach the drive unit	

7 - 9 Malfunction

No.	Contents	Condition
(1)	The size of paper set in the cassette is misdetected or not displayed	
(2)	The main unit malfunctions even if turning on the power switch	
(3)	No display in the operation panel	(Image on the operation panel is faulty or becomes pure white)
(4)	The operation panel remains displaying "WELCOME" and does not change	Communicate between the main PWB and the operation panel main PWB can't be done.
(5)	The login fails with other than the ID card	

Content of Malfunction

(1) The size of paper set in the cassette is misdetected or not displayed

Object: Main unit, Paper feeder

Step	Check description	Assumed cause	Measures	Reference
1	Checking the paper length switch and fan-shape arm	The paper length switch or fan-shape arm does not operate properly	Reattach the paper length switch or fan-shape arm	
2	Checking the connection	The connector is not connected properly, or the wire is faulty.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. • Paper length switch - Engine PWB • Paper width switch - Engine PWB	
3	Replacing the paper length switch	The paper length switch is faulty	Replace the paper length switch	
4	Replacing the paper width switch	The paper width switch is faulty	Replace the paper width switch	
5	Replacing the Engine PWB	The Engine PWB is faulty.	Replace the Engine PWB.	

(2) The main unit malfunctions even if turning on the power switch

Step	Check description	Assumed cause	Measures	Reference
1	Measuring the input voltage	The power cord has no continuity.	Plug the power cord into another wall outlet.	
2	Checking the power cord	The power plug of the power cord is faulty.	If the power plug is deformed or faulty, replace the power cord.	
3	Checking the power cord	The power cord is faulty.	If there is no continuity of the power cord, replace the power cord.	
4	Checking the power switch	The power switch is faulty.	Check the continuity between the contacts of the power switch. Replace the power switch if there is no continuity.	
5	Checking the low voltage PWB	The connector is not connected properly. The wire or the PWB is faulty.	Clean the terminal of the connectors on the low voltage PWB, then reconnect the wire connector. If the wire is faulty, repair or replace it. If not repaired, replace the low voltage PWB.	

Step	Check description	Assumed cause	Measures	Reference
6	Checking the main PWB	The connector or FFC terminal is not connected properly. Or, the wire, FFC, PWB is faulty.	Clean the terminal of the connectors on the main PWB, reconnect the connector of the wire, and reconnect the FFC terminal. If the wire or the FFC is faulty, repair or replace them. If not resolved, replace the main PWB.	
7	Checking the Engine PWB	The connector or FFC terminal is not connected properly. Or, the wire, FFC, PWB is faulty.	Clean the terminal of the connectors on the Engine PWB, reconnect the connector of the wire, and reconnect the FFC terminal. If the wire or the FFC is faulty, repair or replace it. If not resolved, replace the Engine PWB.	

(3) No display in the operation panel

(Image on the operation panel is faulty or becomes pure white)

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The main firmware does not start correctly.	Turn off the power switch and pull out the power plug. After passing 5s, reinsert the power plug and turn on the power switch.	
2	Checking the connection	The connector is not connected properly. Or, the wire is faulty so that the power for display is not supplied.	Clean the terminal of the following wire connectors and reconnect the connectors. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Main PWB - Operation panel main PWB • Main PWB - Low-voltage PWB 	
3	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	
4	Checking the operation panel PWB	The operation panel main PWB is faulty.	Replace the panel main PWB.	
5	Replacing the low voltage PWB	Low voltage power PWB is faulty and the power is not supplied to the main PWB.	Replace the low voltage PWB.	

(4) The operation panel remains displaying "WELCOME" and does not change

Communicate between the main PWB and the operation panel main PWB can't be done.

Step	Check description	Assumed cause	Measures	Reference
1	Resetting the main power	The communication between the main PWB and the operation panel main PWB is faulty.	Turn off the power switch and pull out the power plug. After passing 5s, reinsert the power plug and turn on the power switch.	
2	Checking the connection	The connector is not connected properly. Or, the wire or the SATA cable is faulty.	Clean the following wire, the terminal of SATA cable connector and reconnect them. If there is no continuity, replace the wire. <ul style="list-style-type: none"> • Main PWB - Operation panel main PWB 	
3	Executing U021	The backup RAM data is faulty.	Execute U021 to initialize the backup RAM data.	
4	Replacing the main PWB	The main PWB is faulty.	Replace the main PWB.	
5	Replacing the operation panel main PWB	The operation panel main PWB is faulty.	Replace the panel main PWB.	

(5) The login fails with other than the ID card

Step	Check description	Assumed cause	Measures	Reference
1	Changing the setting	[User/Job Account] is valid while the card authentication kit is not installed.	Set [Permit] at [User/Job Account] > [ID Card Settings] > [Key Login] via the System Menu.	

8PWBs

8 - 1 Description for PWB

(1) Main PWB

(1-1) PWB photograph


CCD model



CIS model



(1-2) Connector position



(1-3) Connector lists

Destination

- YC2: SD card
- YC3: Wi-Fi PWB
- YC4: USB device
- YC5: USB host (Front)
- YC6: USB host (Side)
- YC9: Ethernet
- YC12: Operation panel PWB, Power switch
- YC13: Operation panel PWB
- YC24: APC PWB
- YC25: Low voltage PWB
- YC26: Enginee PWB
- YC27: eKUIO PWB
- YC3001: CIS *1
- YC3002: CCD PWB *2
- YC3003: LED drive PWB *2

*1: CCD model, *2: CIS model

Connector	Pins	Signal	I/O	Voltage	Description
YC2	1	CD/DAT3	IO	3.3 V DC (pulse)	Data[3]
	2	CMD	IO	3.3 V DC (pulse)	Command
	3	VSS	O	-	Ground
	4	VDD	O	3.3 V DC	Power supply output
	5	CLK	O	3.3 V DC (pulse)	Transfer clock
	6	VSS	O	-	Ground
	7	DAT0	IO	3.3 V DC (pulse)	Data[0]
	8	DAT1	IO	3.3 V DC (pulse)	Data[1]
	9	DAT2	IO	3.3 V DC (pulse)	Data[2]
	10	CD	I	3.3 V DC	Detecting switch
	11	COMMON	I	-	Common Connection (Ground)
	12	WP	I	3.3 V DC	Write-Protect
YC3	1	SD_D3	IO	3.3 V DC (pulse)	Data[3]
	2	SD_D2	IO	3.3 V DC (pulse)	Data[2]
	3	SD_CMD	IO	3.3 V DC (pulse)	Command
	4	GND	O	-	Ground
	5	SD_CLK	O	3.3 V DC (pulse)	Transfer clock
	6	GND	O	-	Ground
	7	SD_D1	IO	3.3 V DC (pulse)	Data[1]
	8	SD_D0	IO	3.3 V DC (pulse)	Data[0]
	9	GND	O	-	Ground
	10	VIO	O	3.3 V DC	Power supply output
	11	VBAT	O	3.3 V DC	Power supply output
	12	GND	O	-	Ground

Connector	Pins	Signal	I/O	Voltage	Description
YC3	13	PAVDD	O	3.3 V DC	Power supply output
	14	GND	O	-	Ground
	15	HOSTWAKE	O	-	Not use (Ground)
	16	GND	O	-	Ground
	17	RESET	O	-	Not use (Ground)
	18	GND	O	-	Ground
	19	USB_+	O	-	Not use (Ground)
	20	USB_-	O	-	Not use (Ground)
YC4	1	VBUS	O	5 V DC	VBUS
	2	D-	IO	0.4 V DC (pulse)	Data(-)
	3	D+	IO	0.4 V DC (pulse)	Data(+)
	4	GND	O	-	Ground
	5	STDB_SSTX-	IO	-	Not use
	6	STDB_SSTX+	IO	-	Not use
	7	GND	O	-	Ground
	8	STDB_SSRX-	IO	-	Not use
	9	STDB_SSRX+	IO	-	Not use
YC5	1	VBUS	O	5 V DC	VBUS
	2	DATA-	IO	0.4 V DC (pulse)	Data(-)
	3	DATA+	IO	0.4 V DC (pulse)	Data(+)
	4	ID	-	-	Not use
	5	SHEELD-G	O	-	Ground
YC6	1	VBUS	O	5 V DC	VBUS
	2	DATA-	IO	0.4 V DC (pulse)	Data(-)
	3	DATA+	IO	0.4 V DC (pulse)	Data(+)
	4	ID	-	-	Not use
	5	SHEELD-G	O	-	Ground
YC9	R1	TD1+	IO	-1.0 to +1.0(pulse)	Data
	R2	TD1-	IO	-1.0 to +1.0(pulse)	Data
	R3	TD2+	IO	-1.0 to +1.0(pulse)	Data
	R4	TD2-	IO	-1.0 to +1.0(pulse)	Data
	R5	CT1	-	-	Center tap
	R6	CT2	-	-	Center tap
	R7	TD3+	IO	-1.0 to +1.0(pulse)	Data
	R8	TD3-	IO	-1.0 to +1.0(pulse)	Data
	R9	TD4+	IO	-1.0 to +1.0(pulse)	Data
	R10	TD4-	IO	-1.0 to +1.0(pulse)	Data
	L1	YWLED_A	O	3.3 V DC	LED anode (Power supply output)
	L2	YWLED_K	I	-	LED cathode (Ground)
	L3	GRLED_K	I	-	LED cathode (Ground)
	L4	GRLED_A	O	3.3 V DC	LED anode (Power supply output)
YC12	1	I2C_SCL_NFC	O	3.3 V DC (pulse)	NFC communication clock
	2	I2C_SDA_NFC	IO	3.3 V DC (pulse)	NFC communication data
	3	3.3 V DC 2_NFC	O	3.3 V DC	NFC Power supply output
	4	NIRQ	I	0V	NFC interrupt
	5	FPRST	O	0V	Panel reset
	6	INT_ENERGYSAVERKEY	I	3.3 V DC	Energy Saver key input

Connector	Pins	Signal	I/O	Voltage	Description	
YC12	7	P2C_SDAT	I	3.3 V DC (pulse)	Panel communication data	
	8	PNL_WKUP_REQ	I	0V	Operation panel recovery request	
	9	C2P_SDAT	O	3.3 V DC (pulse)	Panel communication data	
	10	AUDIO	O	Analog	FAX Audio	
	11	P2C_SDIR	I	3.3 V DC	Panel communication direction	
	12	NC	-	-	Not use	
	13	P2C_SBSY	I	3.3 V DC	Panel communication permission	
	14	LED_ATTENTION	O	0V	LED control	
	15	C2P_SCK	O	3.3 V DC (pulse)	Panel communication clock	
	16	LED_MEMORY	O	0V	LED control	
	17	DISPLAY_POWERON	-	-	Not use	
	18	BEEP_POWERON	O	0V	Alert sound drive	
	19	INT_ANYKEY	I	0V	Energy saver recovery	
	20	GND	O	-	Ground	
	21	GND	O	-	Ground	
	22	GND	O	-	Ground	
	23	5 V DC 1	O	5 V DC	Power supply output	
	24	GND	O	-	Ground	
	25	5 V DC 1	O	5 V DC	Power supply output	
	26	JOB_LED	O	-	Job separator LED	
	27	5 V DC 1	O	5 V DC	Power supply output	
	28	GND	O	-	Ground	
	29	5 V DC 1	O	5 V DC	Power supply output	
	30	POWER_SW	I	3.3 V DC	Power source switch	
	YC13	1	GND	O	-	Ground
		2	LCD_OFF	O	3.3 V DC	Conducting LCD
		3	LOCKN	I	3.3 V DC	Communication sync
		4	GND	O	-	Ground
		5	TX0N	O	-100 to +100mV(pulse)	LCD data (N)
		6	TX0P	O	-100 to +100mV(pulse)	LCD data (P)
7		GND	O	-	Ground	
YC24	1	5 V DC 4_IL	O	5 V DC	Power supply output	
	2	GND	O	-	Ground	
	3					
	4					
	5	VDATA1N	O	-100 to +100mV(pulse)	Image data	
	6	VDATA1P	O	-100 to +100mV(pulse)	Image data	
	7					
	8	SAMPLE1	O	3.3 V DC (pulse)	Sample / hold	
	9	OUTPEN	O	3.3 V DC (pulse)	Output permission	
	10	VCONT	O		Reference voltage	
	11	PDN	I	3.3 V DC (pulse)	Horizontal sync signal	
	12	3.3 V DC 4	O	3.3 V DC	Power supply output	
YC25	1	GND	-		Ground	
	2	24 V DC 2	I	24 V DC	Power supply input	
	3	5 V DC 0	I	5 V DC	Power supply input	
	4	5 V DC 0	I	5 V DC	Power supply input	

Connector	Pins	Signal	I/O	Voltage	Description
YC25	5	5 V DC 0	I	5 V DC	Power supply input
	6	SLEEP	O	5 V DC	Sleep signal
	7	GND	I	-	Ground
	8	GND	I	-	Ground
	9	GND	I	-	Ground
	10	AC_DOWN	-	-	Not use
YC26	1	OVSYNCMON	I	3.3 V DC (pulse)	VSYNC monitor
	2	PAGEST	I	3.3 V DC (pulse)	Page valid range
	3	SCAN_E2C_SCK	I	3.3 V DC (pulse)	Scan communication clock
	4	SCAN_G2E_SDAT	O	3.3 V DC (pulse)	Scan communication data
	5	SCAN_E2C_SDAT	I	3.3 V DC (pulse)	Scan communication data
	6	SCAN_E2C_SEL	I	3.3 V DC	Scan communication start request
	7	SCAN_G2E_RDY	O	3.3 V DC	Scan communication permission
	8	C2E_SCK	I	3.3 V DC (pulse)	Enginee communication clock
	9	C2E_SDAT	O	3.3 V DC (pulse)	Enginee communication data
	10	E2C_SDAT	I	3.3 V DC (pulse)	Enginee communication data
	11	E2C_SDIR	I	3.3 V DC	Enginee communication direction
	12	E2C_IR	I	0V	Enginee communication interrupt
	13	E2C_SBSY	I	3.3 V DC	Enginee communication permission
	14	GND	-	-	Ground
	15	EG_SCL	I	3.3 V DC (pulse)	Video register communication clock
	16	GND	-	-	Ground
	17	EG_SDA	IO	3.3 V DC (pulse)	Video register communication data
	18	GND	-	-	Ground
	19	PVSYNC	I	3.3 V DC (pulse)	Sub scanning start signal
	20	5 V DC 4_IL	I	5 V DC	Power supply input
	21	C2E_QUICK_START	O	0V	Recovery from sleep mode or other status notification
	22	E2C_WKUP_BGD_N	I	3.3 V DC	Background recovery request
	23	ENGHLD	O	0V	Enginee hold
	24	SCANHLD	O	0V	Scan hold
	25	DUTY_COTROL	O	3.3 V DC (pulse)	Duty control
	26	E2C_WKUP_RDY_N	I	3.3 V DC	Ready recovery request
	27	5 V DC 2_E	O	5 V DC	Power supply output
	28	C2E_STBY_ASIC	O	3.3 V DC	ASIC access permission
	29	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	30	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	31	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	32	3.3 V DC 1	O	3.3 V DC	Power supply output
	33	NC	-	-	Not use
	34	NC	-	-	Not use
	35	GND	O	-	Ground
	36	GND	O	-	Ground
	37	GND	O	-	Ground
	38	JOB_LED	I		Job separator LED
YC27	1	VBUS1	O	5 V DC	VBUS
	2	USB_DN1	IO	-400 to +400mV(pulse)	Data(-)

Connector	Pins	Signal	I/O	Voltage	Description	
YC27	3	USB_DP1	IO	-400 to +400mV(pulse)	Data(+)	
	4	AUDIO1	-	-	Not use	
	5	WAKEUP1	I	3.3 V DC	Recovery request	
	6	RESET1	O	5 V DC	Reset	
	7	GND	O	-	Ground	
	8	GND	O	-	Ground	
	9	GND	O	-	Ground	
	10	GND	O	-	Ground	
	11	GND	O	-	Ground	
	12	NC	-	-	Not use	
	13	5 V DC 2_C2	O	5 V DC	Power supply output	
	14	5 V DC 2_C2	O	5 V DC	Power supply output	
	15	5 V DC 2_C2	O	5 V DC	Power supply output	
	16	5 V DC 2_C2	O	5 V DC	Power supply output	
	17	5 V DC 2_C2	O	5 V DC	Power supply output	
	18	5 V DC 2_C2	O	5 V DC	Power supply output	
	19	5 V DC 2_C2	O	5 V DC	Power supply output	
	20	5 V DC 1_C	O	5 V DC	Power supply output	
	21	5 V DC 1_C	O	5 V DC	Power supply output	
	22	5 V DC 1_C	O	5 V DC	Power supply output	
	23	NC	-	-	Not use	
	24	GND	O	-	Ground	
	25	GND	O	-	Ground	
	26	GND	O	-	Ground	
	27	GND	O	-	Ground	
	28	VBUS0	O	5 V DC	VBUS	
	29	USB_DN0	IO	-400 to +400mV(pulse)	Data(-)	
	30	USB_DP0	IO	-400 to +400mV(pulse)	Data(+)	
	31	AUDIO0	I	Analog	FAX Audio	
	32	WAKEUP0	I	3.3 V DC	Recovery request	
	33	RESET0	O	5 V DC	Reset	
	YC3001 *1	1	OS6_RE	I	Analog	Image signal
		2	GND	O	-	Ground
3		OS5_RO	I	Analog	Image signal	
4		GND	O	-	Ground	
5		OS3_GO	I	Analog	Image signal	
6		GND	O	-	Ground	
7		OS4_GE	I	Analog	Image signal	
8		GND	O	-	Ground	
9		OS2_BE	I	Analog	Image signal	
10		GND	O	-	Ground	
11		OS1_BO	I	Analog	Image signal	
12		GND	O	-	Ground	
13		CCD_SH	O	3.3 V DC (pulse)	Shift gate	
14		GND	O	-	Ground	
15		CCDCLK2	O	3.3 V DC (pulse)	Transfer clock	
16		GND	O	-	Ground	


Connector	Pins	Signal	I/O	Voltage	Description
YC3001 *1	17	CCD_RS	O	3.3 V DC (pulse)	Reset gate
	18	GND	O	-	Ground
	19	CCDCLK1	O	3.3 V DC (pulse)	Transfer clock
	20	NC	-	-	Not use
	21	5 V DC 5	O	5 V DC	Power supply output
	22	5 V DC 5	O	5 V DC	Power supply output
	23	NC	-	-	Not use
	24	+12V3_C	O	12V	Power supply output
	25	+12V3_C	O	12V	Power supply output
YC3002 *2	1	+12V3_C	O	12V	Power supply output
	2	+12V3_C	O	12V	Power supply output
	3	LED_PWM	O	3.3 V DC (pulse)	Lamp lighting control
	4	LED_ENA	O	3.3 V DC (pulse)	Lamp lighting control
	5	GND	O	-	Ground
	6	GND	O	-	Ground
YC3003 *2	1	3.3 V DC 5	O	3.3 V DC	Power supply output
	2	3.3 V DC 5	O	3.3 V DC	Power supply output
	3	3.3 V DC 5	O	3.3 V DC	Power supply output
	4	Pull-down	-	-	Pull-down
	5	LED_COM2	O	-	LED anode
	6	LED2_B	I	-	LED cathode
	7	LED2_G	I	-	LED cathode
	8	LED2_R	I	-	LED cathode
	9	MODE	O	3.3 V DC (pulse)	CIS control signal
	10	SP	O	3.3 V DC (pulse)	CIS control signal
	11	VREF	O	1.1V	Reference Power supply output
	12	GND	O	-	Ground
	13	CLK	O	3.3 V DC (pulse)	CIS control clock
	14	GND	O	-	Ground
	15	OS1	I	Analog	Image signal
	16	GND	O	-	Ground
	17	OS2	I	Analog	Image signal
	18	GND	O	-	Ground
	19	OS3	I	Analog	Image signal
	20	GND	O	-	Ground
	21	OS4	I	Analog	Image signal
	22	GND	O	-	Ground
	23	OS5	I	Analog	Image signal
	24	GND	O	-	Ground
	25	OS6	I	Analog	Image signal
	26	GND	O	-	Ground
	27	OS7	I	Analog	Image signal
	28	GND	O	-	Ground
	29	OS8	I	Analog	Image signal
	30	GND	O	-	Ground
	31	OS9	I	Analog	Image signal
	32	GND	O	-	Ground

Connector	Pins	Signal	I/O	Voltage	Description
YC3003 *2	33	LED_COM1	O		LED anode
	34	LED1_B	I		LED cathode
	35	LED1_G	I		LED cathode
	36	LED1_R	I		LED cathode


*1: CCD model, *2: CIS model

(2) Engine PWB

(2-1) PWB photograph



(2-2) Connector position



(2-3) Connector lists

Destination

- YC3: Main PWB
- YC4: Document Processor
- YC5: Finisher (option)
- YC6: Paper feeder (option)
- YC7: Bridge detection switch
- YC8: Developer relay PWB, Drum relay PWB, Container relay PWB
- YC9: Toner sensor, Toner container lock sensor, Toner container switch, Temperature sensor, LSU fan motor
- YC10: High voltage PWB
- YC12: Power source fan motor
- YC13: Thermopile, Fuser thermistor, Fuser pressure release sensor
- YC14: Low voltage PWB
- YC15: Scanner motor, Home position sensor, Original sensor, Original size sensor
- YC16: Exit motor, Exit sensor, Exit full sensor, Exit sensor, JS exit sensor, Exit fan motor
- YC17: feed-shift solenoid
- YC18: Paper feed clutch, Registration clutch, Duplex clutch, MP solenoid, Lift motor, Developer clutch
- YC19: Lift sensor, Registration sensor
- YC20: Paper sensor 1, Paper sensor 2, Paper length switch, Paper width switch
- YC21: Conveying fan motor, DU sensor, Conveying sensor, MP paper sensor
- YC23: Polygon motor
- YC24: Main motor, Fuser motor
- YC25: Developer motor
- YC26: Low voltage PWB
- YC27: Right cover switch
- YC28: Paper fan motor

Connector	Pins	Signal	I/O	Voltage	Description
YC3	1	JOB_LED	O	3.3 V DC /0V	Job Separator paper detection
	2	GND	I	-	Ground
	3	GND	I	-	Ground
	4	GND	I	-	Ground
	5	NC	-	-	Not use
	6	NC	-	-	Not use
	7	3.3 V DC 1	I	3.3 V DC	Power supply input
	8	3.3 V DC 2_E	I	3.3 V DC	Power supply input
	9	3.3 V DC 2_E	I	3.3 V DC	Power supply input
	10	3.3 V DC 2_E	I	3.3 V DC	Power supply input
	11	C2E_STBY_ASIC	I	3.3 V DC	ASIC access permission
	12	5 V DC 2_E	I	5 V DC	Power supply output
	13	E2C_WKUP_RDY_N	O	3.3 V DC /0V	Ready recovery request
	14	DUTY_COTROL	I	3.3 V DC (pulse)	Duty control

Connector	Pins	Signal	I/O	Voltage	Description
YC3	15	SCANHLD	I	3.3 V DC /0V	Scan hold
	16	ENGHLD	I	3.3 V DC /0V	Enginee hold
	17	E2C_WKUP_BGD_N	O	3.3 V DC	Background recovery request
	18	C2E_QUICK_START	I	3.3 V DC /0V	Recovery from sleep mode or other status notification
	19	5 V DC 4_IL	O	5 V DC	Power supply output
	20	PVSYNC	O	3.3 V DC /0V	Sub scanning start signal
	21	GND	I	-	Ground
	22	EG_SDA	IO	3.3 V DC (pulse)	Video register communication data
	23	GND	I	-	Ground
	24	EG_SCL	O	3.3 V DC (pulse)	Video register communication clock
	25	GND	I	-	Ground
	26	E2C_SBSY	O	3.3 V DC /0V	Main-Enginee communication permission
	27	E2C_IR	O	3.3 V DC /0V	Main-Enginee communication interrupt
	28	E2C_SDIR	O	3.3 V DC /0V	Main-Enginee communication direction
	29	E2C_SDAT	O	3.3 V DC (pulse)	Main-Enginee communication data
	30	C2E_SDAT	I	3.3 V DC (pulse)	Main-Enginee communication data
	31	C2E_SCK	I	3.3 V DC (pulse)	Main-Enginee communication clock
	32	SCAN_C2E_RDY	I	3.3 V DC /0V	Enginee-Scan communication permission
	33	SCAN_E2C_SEL	O	3.3 V DC /0V	Enginee-Scan communication start request
	34	SCAN_E2C_SDAT	O	3.3 V DC (pulse)	Enginee-Scan communication data
	35	SCAN_C2E_SDAT	I	3.3 V DC (pulse)	Enginee-Scan communication data
	36	SCAN_E2C_SCK	O	3.3 V DC (pulse)	Enginee-Scan communication clock
	37	PAGEST	O	3.3 V DC /0V	Page valid range
	38	OVSYNCMON	I	3.3 V DC /0V	VSYNC monitor
YC4	1	GND	O	-	Ground
	2	GND	O	-	Ground
	3	GND	O	-	Ground
	4	GND	O	-	Ground
	5	24 V DC 2	O	24 V DC	Power supply output
	6	24 V DC 2	O	24 V DC	Power supply output
	7	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	8	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	9	DP_CLK	O	3.3 V DC (pulse)	Enginee-DP communication clock
	10	DP_SO	O	3.3 V DC (pulse)	Enginee-DP communication data
	11	DP_SEL	O	3.3 V DC /0V	Enginee-DP communication select
	12	DP_SI	I	3.3 V DC (pulse)	Enginee-DP communication data
	13	DP_RDY	I	3.3 V DC /0V	Enginee-DP communication status
	14	DP_TMG	I	3.3 V DC /0V	VSYNC output to Enginee
	15	DP_OPEN	I	3.3 V DC /0V	DP open/close detection
	16	DP_ORG_SET	I	3.3 V DC /0V	DP original set detection
	17	3.3 V DC 3	O	3.3 V DC	Power supply output
	18	GND	O	-	Ground
YC5	1	EH_CLK	O	3.3 V DC (pulse)	Enginee-EH communication clock
	2	EH_SI	I	3.3 V DC (pulse)	Enginee-EH communication data
	3	EH_SO	O	3.3 V DC (pulse)	Enginee-EH communication data
	4	BR_SEL	O	3.3 V DC /0V	Enginee-AK communication select

Connector	Pins	Signal	I/O	Voltage	Description
YC5	5	DF_SEL	O	3.3 V DC /0V	Enginee-DF communication select
	6	DF_RDY	I	3.3 V DC /0V	Enginee-DF communication ready
	7	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	8	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	9	GND	O	-	Ground
	10	GND	O	-	Ground
YC6	1	EH_CLK	O	3.3 V DC (pulse)	Enginee-EH communication clock
	2	EH_SI	I	3.3 V DC (pulse)	Enginee-EH communication data
	3	EH_SO	O	3.3 V DC (pulse)	Enginee-EH communication data
	4	PF_SEL	O	3.3 V DC /0V	Enginee-PF communication select
	5	PF_RDY	I	3.3 V DC /0V	Enginee-PF communication ready
	6	PF_SET	I	3.3 V DC /0V	PF paper set detection
	7	PF_PAUSE	O	3.3 V DC /0V	PF timing adjustment
	8	24 V DC 2	O	24 V DC	Power supply output
	9	3.3 V DC 3	O	3.3 V DC	Power supply output
	10	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	11	GND	O	-	Ground
	12	GND	O	-	Ground
YC7	1	BR_SET	I	3.3 V /2.26 V/1.65 V / 1.34 V DC	AK set detection
	2	GND	O	-	Ground
	3	LVU_SEL	I	3.3 V/2.26 V/1.65 V/ 1.34 V DC	Low-voltage power supply determination
	4	GND	O	-	Ground
YC8	1	GND	O	-	Ground
	2	1WIRE	IO	3.3 V DC (pulse)	Toner container communication
	3	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	4	DRUM_SDA	IO	3.3 V DC (pulse)	Drum communication data
	5	DRUM_SCL	O	3.3 V DC (pulse)	Drum communication clock
	6	GND	O	-	Ground
	7	WT_LED	O	3.3 V DC /0V	Waste toner box level detection LED
	8	WT_SENS	I	Analog	Waste toner box level detection
	9	3.3 V DC 2_LED	O	3.3 V DC	Power supply output
	10	ERASE	O	3.3 V DC /0V	Eraser control
	11	24 V DC 2	O	24 V DC	Power supply output
	12	GND	O	-	Ground
	13	DLP_SDA	IO	3.3 V DC (pulse)	Developer communication data
	14	DLP_SCL	O	3.3 V DC (pulse)	Developer communication clock
	15	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	16	DLP_TH	I	Analog	Developer thermistor
YC9	1	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	2	TNR_EMP	I	3.3 V DC /0V	Toner level detection
	3	GND	O	-	Ground
	4	CON_LOCK	I	3.3 V DC /0V	Toner container lock detection
	5	GND	O	-	Ground
	6	3.3 V DC 2_LED	O	3.3 V DC	Power supply output
	7	GND	O	-	Ground
	8	TCONSET	I	3.3 V DC /0V	Toner container set detection

Connector	Pins	Signal	I/O	Voltage	Description
YC9	9	THERM	I	Analog	Machine outside temperature
	10	GND	O	-	Ground
	11	HUM_OUT	O	3.3 V DC (pulse)	Machine outside humidity
	12	HUM_CLK	I	3.3 V DC (pulse)	Machine outside humidity clock
	13	24 V DC	O	24 V DC	Power supply output
	14	LSU_FAN_REM	O	24 V DC /0V	LSU cooling fan control
YC10	1	24 V DC 2_IL	O	24 V DC	Power supply output
	2	24 V DC 2_IL	O	24 V DC	Power supply output
	3	MC_CLK	O	10 V DC (pulse)	Main charger high-voltage clock
	4	MC_ACCNT	O	10 V DC (pulse)	Main charger high-voltage AC control
	5	MC_DCCNT	O	10 V DC (pulse)	Main charger high-voltage DC control
	6	MC_ISENS	O	Analog	Main charger current monitor
	7	DC_REM	O	H(24 V DC)/L(0V)	Main charger/transfer high-voltage DC remote
	8	TRA_CNT	O	10 V DC (pulse)	Transfer high-voltage DC control
	9	SEP_REM	O	H(24 V DC)/L(0V)	Separation high-voltage DC remote
	10	NC	-	-	Not use
	11	DLP_CLK	O	10 V DC (pulse)	Developer high-voltage clock
	12	DLP_CNT	O	10 V DC (pulse)	Developer high-voltage DC control
	13	GND	O	-	Ground
	14	GND	O	-	Ground
YC12	1	SEC_CLK	O	3.3 V DC (pulse)	Communication clock
	2	SEC_DATA	IO	3.3 V DC (pulse)	Communication data
	3	GND	O	-	Ground
	4	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	5	24 V DC 2	O	24 V DC	Power supply output
	6	LVU_FAN_REM	O	24 V DC /0V	Cooling fan control
YC13	1	FSR_TOBJ	I	Analog	Thermopile object temperature data
	2	GND	O	-	Ground
	3	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	4	FSR_TAMB	I	Analog	Thermopile surrounding temperature data
	5	THP_SDA	IO	3.3 V DC (pulse)	Thermopile communication data
	6	THP_SCL	O	3.3 V DC (pulse)	Thermopile communication clock
	7	GND	O	-	Ground
	8	FSR_EDGE	I	Analog	Fuser edge thermistor
	9	3.3 V DC 2_LED	O	3.3 V DC	Power supply output
	10	GND	O	-	Ground
	11	FSR_PRESS	I	3.3 V DC /0V	Fuser pressure release detection
YC14	1	ZCROSS	I	3.3 V DC (pulse)	Zero-cross signal
	2	RELAYREM	O	3.3 V DC /0V	Low-voltage relay remote
	3	MHREM	O	3.3 V DC /0V	Main heater remote
	4	SHREM	O	3.3 V DC /0V	Sub heater remote
	5	ILVCC	I	Analog	Power supply output for interlock
	6	GND	O	-	Ground
	7	24 V DC 2_IL	O	24 V DC	Power supply output
YC15	1	SCAN_/B	O	24 V DC /0V	Scanner motor drive
	2	SCAN_/A	O	24 V DC /0V	Scanner motor drive


Connector	Pins	Signal	I/O	Voltage	Description	
YC15	3	SCAN_B	O	24 V DC /0V	Scanner motor drive	
	4	SCAN_A	O	24 V DC /0V	Scanner motor drive	
	5	3.3 V DC 2_LED	O	3.3 V DC	Power supply output	
	6	GND	O	-	Ground	
	7	HP_SENS	I	3.3 V DC /0V	Scanner home position detection	
	8	3.3 V DC 2_LED	O	3.3 V DC	Power supply output	
	9	GND	O	-	Ground	
	10	TABLE_OPEN	I	3.3 V DC /0V	DP open/close detection	
	11	GND	O	-	Ground	
	12	ORG_SENS	I	3.3 V DC /0V	Scanner original size detection	
	13	5 V DC 2_E	O	5 V DC	Power supply output	
	YC16	1	EXIT_/B	O	24 V DC /0V	Exit motor drive
		2	EXIT_/A	O	24 V DC /0V	Exit motor drive
3		EXIT_B	O	24 V DC /0V	Exit motor drive	
4		EXIT_A	O	24 V DC /0V	Exit motor drive	
5		3.3 V DC 2_LED	O	3.3 V DC	Power supply output	
6		GND	O	-	Ground	
7		EXIT_FULL_UP	I	3.3 V DC /0V	Upper exit paper full detection	
8		3.3 V DC 2_LED	O	3.3 V DC	Power supply output	
9		GND	O	-	Ground	
10		EXIT_FULL_DOWN	I	3.3 V DC /0V	Lower exit paper full detection	
11		FUSER_SW	I	3.3 V DC /0V	Fuser conveying paper detection	
12		GND	O	-	Ground	
13		3.3 V DC 2_LED	O	3.3 V DC	Power supply output	
14		3.3 V DC 2_LED	O	3.3 V DC	Power supply output	
15		GND	O	-	Ground	
16		JOB_TRAY	I	3.3 V DC /0V	Job Separator paper detection	
17		EXIT_FAN_REM	O	24 V DC /0V	Exit cooling fan control	
18		24 V DC 2	O	24 V DC	Power supply output	
YC17	1	EJE_SOL_PULL	O	24 V DC /0V	Exit solenoid control	
	2	24 V DC 2	O	24 V DC	Power supply output	
	3	EJE_SOL_RETURN	O	24 V DC /0V	Exit solenoid control	
YC18	1	FEED_CL_REM	O	24 V DC /0V	Conveying clutch control	
	2	24 V DC 2	O	24 V DC	Power supply output	
	3	REG_CL_REM	O	24 V DC /0V	Registration clutch control	
	4	24 V DC 2	O	24 V DC	Power supply output	
	5	DU_CL_REM	O	24 V DC /0V	Duplex clutch control	
	6	24 V DC 2	O	24 V DC	Power supply output	
	7	24 V DC 2	O	24 V DC	Power supply output	
	8	MPF_SOL_REM	O	24 V DC /0V	MPF solenoid control	
	9	GND	O	-	Ground	
	10	LMOT_REM	O	24 V DC /0V	Lift motor control	
	11	DLP_CL_REM	O	24 V DC /0V	Developer clutch control	
	12	24 V DC 2	O	24 V DC	Power supply output	
YC19	1	3.3 V DC 2_LED	O	3.3 V DC	Power supply output	
	2	GND	O	-	Ground	
	3	LIFTFULL	I	3.3 V DC /0V	Lift motor upper limit detection	

Connector	Pins	Signal	I/O	Voltage	Description
YC19	4	5 V DC 2_E	O	5 V DC	Power supply output
	5	RESIST	I	3.3 V DC /0V	Registration paper detection
	6	GND	O	-	Ground
YC20	1	3.3 V DC 2_LED	O	3.3 V DC	Power supply output
	2	GND	O	-	Ground
	3	PAPEMP1	I	3.3 V DC /2V/1.65 V DC /1.26V	Cassette paper level detection
	4	3.3 V DC 2_LED	O	3.3 V DC	Power supply output
	5	GND	O	-	Ground
	6	PAPEMP2	I	3.3 V DC /2V/1.65 V DC /1.26V	Cassette paper level detection
	7	PAPLSIZE3	I	3.3 V DC /0V	Cassette paper size detection
	8	GND	O	-	Ground
	9	PAPLSIZE2	I	3.3 V DC /0V	Cassette paper size detection
	10	PAPLSIZE1	I	3.3 V DC /0V	Cassette paper size detection
	11	PAPWSIZE1	I	3.3 V DC /0V	Cassette paper size detection
	12	GND	O	-	Ground
YC21	1	FEED_FAN_REM	O	24 V DC /0V	Conveying cooling fan control
	2	24 V DC 2_IL	O	24 V DC	Power supply output
	3	3.3 V DC 2_LED	O	3.3 V DC	-
	4	GND	O	-	Ground
	5	DU_SW	I	3.3 V DC /0V	DU paper detection
	6	3.3 V DC 2_LED	O	3.3 V DC	Power supply output
	7	GND	O	-	Ground
	8	FEED_SW	I	3.3 V DC /0V	Conveying paper detection
	9	3.3 V DC 3_LED	O	3.3 V DC	Power supply output
	10	GND	O	-	Ground
	11	MPF_REMAIN	I	3.3 V DC /0V	MPF paper detection
	12	GND	O	-	Ground
	13	FSR_PRESS_MOT_REM	O	24 V DC /0V	Fuser pressure release motor drive
YC23	1	24 V DC 2	O	24 V DC	Power supply output
	2	GND	O	-	Ground
	3	POL_REM	O	3.3 V DC /0V	Polygon motor remote
	4	POL_READY	I	3.3 V DC /0V	Polygon motor ready
	5	POL_CLK	O	5 V DC (pulse)	Polygon motor clock
YC24	1	24 V DC 2_IL	O	24 V DC	Power supply output
	2	GND	O	-	Ground
	3	MAIN_MOT_REM	O	5 V DC /0V	Main motor remote
	4	MAIN_MOT_CLK	O	5 V DC (pulse)	Main motor clock
	5	MAIN_MOT_RDY	I	3.3 V DC /0V	Main motor ready
	6	MAIN_MOT_DIR	O	5 V DC /0V	Main motor rotation direction
	7	24 V DC 2_IL	O	24 V DC	Power supply output
	8	GND	O	-	Ground
	9	FSR_MOT_REM	O	5 V DC /0V	Fuser motor remote
	10	FSR_MOT_CLK	O	5 V DC (pulse)	Fuser motor clock
	11	FSR_MOT_RDY	I	3.3 V DC /0V	Fuser motor ready
	12	FSR_MOT_DIR	O	5 V DC /0V	Fuser motor rotation direction
YC25	1	24 V DC 2_IL	O	24 V DC	Power supply output

Connector	Pins	Signal	I/O	Voltage	Description
YC25	2	GND	O	-	Ground
	3	DLP_MOT_REM	O	5 V DC /0V	Developer motor remote
	4	DLP_MOT_CLK	O	5 V DC (pulse)	Developer motor clock
	5	DLP_MOT_RDY	I	3.3 V DC /0V	Developer motor ready
	6	DLP_MOT_DIR	O	5 V DC /0V	Developer motor rotation direction
YC26	1	24 V DC 2_IL1	I	24 V DC	Power supply input
	2	GND	O	-	Ground
	3	GND	O	-	Ground
	4	24 V DC 2	I	24 V DC	Power supply input
	5	24 V DC 2	I	24 V DC	Power supply input
YC27	1	24 V DC 2_IL1	O	24 V DC	Power supply output
	2	24 V DC 2_IL2	I	24 V DC	Power supply input
YC28	1	HUM_FAN_REM	O	24 V DC /0V	Intake fan control for the machine outside temperature / humidity sensor
	2	24 V DC 2	O	24 V DC	Power supply output

(3) High voltage PWB

(3-1) PWB photograph



(3-3) Connector lists

Destination


- CN1: Enginee PWB

Connector	Pins	Signal	I/O	Voltage	Description
CN1	1	24 V DC 2_IL	I	24 V DC	Power supply input
	2	24 V DC 2_IL	I	24 V DC	Power supply input
	3	MC_CLK	I	10 V DC (pulse)	Main charger clock
	4	MC_ACCNT	I	10 V DC (pulse)	Main charger AC control
	5	MC_DCCNT	I	10 V DC (pulse)	Main charger DC control
	6	MC_ISENS	O	0 to 3V	Main charger output current detection
	7	DC_REM	I	H(24 V DC)/L(0 V)	High-voltage remote
	8	TRA_CNT	I	10 V DC (pulse)	Transfer control
	9	SEP_REM	I	H(24 V DC)/L(0 V)	Separation remote
	10	NC	-	-	Not use
	11	DLP_CLK	I	10 V DC (pulse)	Developer clock
	12	DLP_CNT	I	10 V DC (pulse)	Developer DC control
	13	GND	-	0V	Ground
	14	GND	-	0V	Ground

(4) Low voltage PWB

(4-1) PWB photograph

100-120V



220-240V



(4-2) Connector position



(4-3) Connector lists

Destination

- TB1/TB2: Inlet
- TB3: Thermal cutout
- YC1: Outlet *1
- YC2: Cassette heater switch
- YC3: Paper feeder (option), Cassette heater
- YC4: Fuser heater
- YC5: Front cover switch
- YC6: Enginee PWB
- YC7: Main PWB
- YC8: Enginee PWB

*1: 32 ppm model only

Connector	Pins	Signal	I/O	Voltage	Description
TB1	1	AC_LIVE	I	Commercial Power supply input voltage	AC_LIVE
TB2	1	AC_NEUTRAL	I	Commercial Power supply input voltage	AC_NEUTRAL
TB3	1	LIVE	O	Commercial Power supply output voltage	Fuser heater AC_LIVE output
YC1 *1	1	AC_LIVE	O	Commercial Power supply output voltage	DF LIVE
	3	AC_NEUTRAL	O	Commercial Power supply output voltage	DF NEUTRAL
YC2	1	CH_SW	O	Commercial Power supply output voltage	LIVE output to switch
	2	N.C	-	-	Not use
	3	CH_COM	I	Commercial Power supply input voltage	LIVE input from switch
YC3	1	Cassette_H_LIVE	O	Commercial Power supply output voltage	LIVE output to the dehumidifying heater
	2	Cassette_H_LIVE	O	Commercial Power supply output voltage	LIVE output to the dehumidifying heater
	3	N.C	-	-	Not use
	4	N.C	-	-	Not use
	5	Cassette_H_NEUTRAL	O	Commercial Power supply output voltage	NEUTRAL output to the dehumidifying heater
	6	Cassette_H_NEUTRAL	O	Commercial Power supply output voltage	NEUTRAL output to the dehumidifying heater
YC4	1	MH	O	Commercial Power supply output voltage	AC output to fuser unit main heater
	2	SH	O	Commercial Power supply output voltage	AC output to fuser unit sub heater
YC5	1	ILVCC	I	3.3 V DC	Power supply input at sleep mode
	2	24 V DC 2	O	24 V DC	24 V DC 2 output to the interlock switch
	3	N.C	-	-	Not use
	4	24 V DC IL1	I	24 V DC	24 V DC through the interlock switch

Connector	Pins	Signal	I/O	Voltage	Description
YC6	1	24 V DC 2_IL1	O	24 V DC	24 V DC through the interlock switch
	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	24 V DC 2	O	24 V DC	24 V DC output to Enginee PWB
	5	24 V DC 2	O	24 V DC	24 V DC output to Enginee PWB
YC7	1	24 V DC 2	O	24 V DC	24 V DC output to Main PWB
	2	GND	O	0V	GND to Main PWB
	3	5 V DC 0	O	5 V DC	5 V DC output to Main PWB
	4	5 V DC 0	O	5 V DC	5 V DC output to Main PWB
	5	5 V DC 0	O	5 V DC	5 V DC output to Main PWB
	6	GND	-	-	Ground
	7	GND	-	-	Ground
	8	GND	-	-	Ground
	9	SLEEP	I	H(3.3 V DC)/L(0 V)	Sleep control signal
YC8	1	24 V DC 2_IL	O	24 V DC	24 V DC through the interlock switch
	2	GND	-	-	Ground
	3	ILVCC	O	3.3 V DC	Power supply output at sleep mode
	4	SHREM	I	H(3.3 V DC)/L(0 V)	Sub heater control
	5	MHREM	I	H(3.3 V DC)/L(0 V)	Main heater control
	6	RELAYREM	I	H(3.3 V DC)/L(0 V)	Relay control for the fuser heater
	7	ZCROSS	O	H(3.3 V DC)/L(0 V)	Zero-cross signal

*1: 32 ppm model only


(5) Operation PWB

(5-1) PWB photograph

7-inch panel model




4.3-inch panel model




(5-2) Connector position

7-inch panel model



4.3-inch panel model



(5-3) Connector lists

Destination

- YC3: NFC PWB
- YC4: Panel key PWB R
- YC5: Panel key PWB L
- YC6: Speaker
- YC7: Main PWB
- YC8: Touch panel
- YC9: CCD PWB *2
- YC10: Main PWB
- YC20: CCD PWB *1

*1: 4.3-inch panel model, *2: 7-inch panel model

Connector	Pins	Signal	I/O	Voltage	Description
YC3	1	3.3 V DC 2_NFC	O	3.3 V DC	Power supply output
	2	GND	-	-	Ground
	3	NFC_SWCLK	O	0 V/3.3 V DC (pulse)	NFC data clock
	4	NFC_SWDA	I/O	0 V/3.3 V DC (pulse)	NFC input/output data
	5	NIRQ	I	0 V/3.3 V DC	NFC interrupt
YC4	1	ENERGYSAVER KEY	I	0 V/3.3 V DC	Key input
	2	ENERGYSAVER LED	O	0 V/3.3 V DC	LED output
	3	SCAN2	O	0 V/3 V DC	Key scan
	4	ATTENTION	O	0 V/5 V DC	LED output
	5	MEMORY	O	0 V/5 V DC	LED output
	6	5 V DC 1	O	5 V DC	Power supply output
	7	SCAN4	O	0 V/3 V DC	Key scan
	8	LED1	O	0 V/3.3 V DC	LED output
	9	KEY3	I	0 V/3.3 V DC	Key input
	10	LED2	O	0 V/3.3 V DC	LED output
	11	SCAN3	O	0 V/3 V DC	Key scan
	12	SCAN7	O	0 V/3 V DC	Key scan
	13	SCAN6	O	0 V/3 V DC	Key scan
	14	KEY2	I	0 V/3.3 V DC	Key input
	15	KEY1	I	0 V/3.3 V DC	Key input
	16	GND	-	-	Ground
	17	SCAN5	O	0 V/3 V DC	Key scan
	18	PROCESSING	O	0 V/5 V DC	LED output
	19	KEY0	I	0 V/3.3 V DC	Key input
YC5	1	GND	-	-	Ground
	2	SCAN0	O	0 V/3 V DC	Key scan
	3	KEY0	I	0 V/3.3 V DC	Key input
	4	NC	-	-	Not use
	5	KEY1	I	0 V/3.3 V DC	Key input
	6	NC	-	-	Not use
	7	SCAN1	O	0 V/3 V DC	Key scan

Connector	Pins	Signal	I/O	Voltage	Description
YC5	8	SCAN2	O	0 V/3 V DC	Key scan
	9	NC	-	-	Not use
	10	NC	-	-	Not use
	11	LED0	O	0 V/3.3 V DC	LED output
	12	JOB_LED	I	0 V/3.3 V DC	Job separator LED input
YC6	1	SPEAKER_P	O	Pulse	Speaker output
	2	SPEAKER_N	O	Pulse	Speaker output
YC7	A1	5 V DC 1	I	5 V DC	Power supply input
	A2	5 V DC 1	I	5 V DC	Power supply input
	A3	5 V DC 1	I	5 V DC	Power supply input
	A4	5 V DC 1	I	5 V DC	Power supply input
	A5	GND	-	-	Ground
	A6	INT_ANYKEY	O	0 V/3.3 V DC	Panel sleep recovery
	A7	DISPLAY_POWERON	I	0 V/3.3 V DC	Display lit
	A8	C2P_SCK	I	0 V/3.3 V DC (pulse)	Main-Panel communication clock
	A9	P2C_SBSY	O	0 V/3.3 V DC	Main-Panel communication busy
	A10	P2C_SDIR	O	0 V/3.3 V DC	Main-panel communication direction
	A11	C2P_SDAT	I	0 V/3.3 V DC (pulse)	Main-Panel communication data
	A12	P2C_SDAT	O	0 V/3.3 V DC (pulse)	Main-Panel communication data
	A13	FPRST	I	0 V/3.3 V DC	Panel reset
	A14	3.3 V DC 2_NFC	I	3.3 V DC	Power supply output
	A15	I2C_SCL_NFC	I	0 V/3.3 V DC (pulse)	NFC-Panel communication clock
	B1	I2C_SDA_NFC	I/O	0 V/3.3 V DC (pulse)	NFC-Panel communication data
	B2	NIRQ	I	0 V/3.3 V DC	NFC-Panel communication interrupt
	B3	INT_ENERGYSAVERKEY_N	O	0 V/3.3 V DC	Energy saver interrupt
	B4	PNL_WKUP_REQ	I	0 V/3.3 V DC	Operation panel recovery request
	B5	AUDIO	I	Analog	Audio signal
		NC	-	-	Not use
	B7	LED_ATTENTION	I	0 V/3.3 V DC	LED drive
	B8	LED_MEMORY	I	0 V/3.3 V DC	LED drive
	B9	BEEP_POWERON	I	0 V/3.3 V DC	Speaker input
	B10	GND	-	-	Ground
B11	GND	-	-	Ground	
B12	GND	-	-	Ground	
B13	JOB_LED	O	0 V/3.3 V DC	Job separator LED output	
B14	GND	-	-	Ground	
B15	NC	-	-	Not use	
YC8	1	XR	I	0 V to 3 V DC	Touch panel coordinate data
	2	YB	I	0 V to 3 V DC	Touch panel coordinate data
	3	XL	I	0 V to 3 V DC	Touch panel coordinate data
	4	YT	I	0 V to 3 V DC	Touch panel coordinate data
YC9 *2	1	NC	-	-	Not use
	2	NC	-	-	Not use
	3	GND	-	-	Ground
	4	DITH	O	3.3 V DC	Dithering function permission
	5	VCOM	O	0 V/3.3 V DC	Power supply output


Connector	Pins	Signal	I/O	Voltage	Description	
YC9 *2	6	NC	-	-	Not use	
	7	RSTB	O	0 V/3.3 V DC	Reset	
	8	AVDD	O	0V/10.5 V DC	Power supply output	
	9	VEEG	O	0 V/-8 V DC	Power supply output	
	10	VDDG	O	0 V/18 V DC	Power supply output	
	11	UPDN	O	0 V DC	Up and down display select	
	12	SHLR	O	3.3 V DC	Right and left display select	
	13	GND	-	-	Ground	
	14	DCLK	O	0 V/3.3 V DC (pulse)	Display data clock	
	15	GND	-	-	Ground	
	16	R0	O	0 V/3.3 V DC	LCD display data	
	17	R1	O	0 V/3.3 V DC	LCD display data	
	18	R2	O	0 V/3.3 V DC	LCD display data	
	19	R3	O	0 V/3.3 V DC	LCD display data	
	20	R4	O	0 V/3.3 V DC	LCD display data	
	21	R5	O	0 V/3.3 V DC	LCD display data	
	22	R6	O	0 V/3.3 V DC	LCD display data	
	23	R7	O	0 V/3.3 V DC	LCD display data	
	24	G0	O	0 V/3.3 V DC	LCD display data	
	25	G1	O	0 V/3.3 V DC	LCD display data	
	26	G2	O	0 V/3.3 V DC	LCD display data	
	27	G3	O	0 V/3.3 V DC	LCD display data	
	28	G4	O	0 V/3.3 V DC	LCD display data	
	29	G5	O	0 V/3.3 V DC	LCD display data	
	30	G6	O	0 V/3.3 V DC	LCD display data	
	31	G7	O	0 V/3.3 V DC	LCD display data	
	32	B0	O	0 V/3.3 V DC	LCD display data	
	33	B1	O	0 V/3.3 V DC	LCD display data	
	34	B2	O	0 V/3.3 V DC	LCD display data	
	35	B3	O	0 V/3.3 V DC	LCD display data	
	36	B4	O	0 V/3.3 V DC	LCD display data	
	37	B5	O	0 V/3.3 V DC	LCD display data	
	38	B6	O	0 V/3.3 V DC	LCD display data	
		B7	O	0 V/3.3 V DC	LCD display data	
	40	HSD	O	0 V/3.3 V DC	Horizontal display data sync	
	41	VSD	O	0 V/3.3 V DC	Vertical display data sync	
	42	DE	O	0 V/3.3 V DC	Data input permission	
	43	MODE	O	0 V/3.3 V DC	Display mode select	
	44	DVDD	O	3.3 V DC	Power supply output	
	45	VCOM	O	0 V/3.3 V DC	Power supply output	
	46	GND	-	-	Ground	
	47	VLED-	I	0 V/0.3 V DC	LED input	
	48	VLED-	I	0 V/0.3 V DC	LED input	
	49	VLED+	O	0 V/19 V DC	LED output	
	50	VLED+	O	0 V/19 V DC	LED output	
	YC10	1	GND	-	-	Ground
		2	LCD_OFF	I	0 V/3.3 V DC	LCD display off

Connector	Pins	Signal	I/O	Voltage	Description
YC10	3	LOCKN	I	0 V/3.3 V DC	LCD display permission
	4	GND	-	-	Ground
	5	RX0N	I/O	Pulse	LCD display data
	6	RX0P	I/O	Pulse	LCD display data
	7	GND	-	-	Ground
YC20 *1	1	NC	-	-	Not use
	2	NC	-	-	Not use
	3	NC	-	-	Not use
	4	NC	-	-	Not use
	5	GND	-	-	Ground
	6	NC	-	-	Not use
	7	DEN	O	0 V/3.3 V DC	Data input permission
	8	VSYNC	O	0 V/3.3 V DC	Vertical display data sync
	9	HSYNC	O	0 V/3.3 V DC	Horizontal display data sync
	10	RESET	O	0 V/3.3 V DC	LCD reset
	11	CLK	O	0 V/3.3 V DC (pulse)	Display data clock
	12	GND	-	-	Ground
	13	B7	O	0 V/3.3 V DC	LCD display data
	14	B6	O	0 V/3.3 V DC	LCD display data
	15	B5	O	0 V/3.3 V DC	LCD display data
	16	B4	O	0 V/3.3 V DC	LCD display data
	17	B3	O	0 V/3.3 V DC	LCD display data
	18	B2	O	0 V/3.3 V DC	LCD display data
	19	B1	O	0 V/3.3 V DC	LCD display data
	20	B0	O	0 V/3.3 V DC	LCD display data
	21	G7	O	0 V/3.3 V DC	LCD display data
	22	G6	O	0 V/3.3 V DC	LCD display data
	23	G5	O	0 V/3.3 V DC	LCD display data
	24	G4	O	0 V/3.3 V DC	LCD display data
	25	G3	O	0 V/3.3 V DC	LCD display data
	26	G2	O	0 V/3.3 V DC	LCD display data
	27	G1	O	0 V/3.3 V DC	LCD display data
	28	G0	O	0 V/3.3 V DC	LCD display data
	29	R7	O	0 V/3.3 V DC	LCD display data
	30	R6	O	0 V/3.3 V DC	LCD display data
	31	R5	O	0 V/3.3 V DC	LCD display data
	32	R4	O	0 V/3.3 V DC	LCD display data
	33	R3	O	0 V/3.3 V DC	LCD display data
	34	R2	O	0 V/3.3 V DC	LCD display data
	35	R1	O	0 V/3.3 V DC	LCD display data
	36	R0	O	0 V/3.3 V DC	LCD display data
	37	DVDD	O	3.3 V DC	Power supply output
	38	GND	-	-	Ground
	39	VLED+	O	0 V/12 V DC	LED output
	40	VLED-	I	0 V DC	LED input


*1: 4.3-inch panel model, *2: 7-inch panel model

(6) DP PWB

(6-1) PWB photograph



(6-2) Connector position



(6-3) Connector lists

Destination

- YC2: Enginee PWB
- YC3: DP cover open/close switch
- YC4: DP original sensor, DP feed sensor, DP registration sensor, DP open/close switch, DP feed-shift sensor, DP timing sensor
- YC6: Original length sensor, Original width sensor
- YC7: DP feed motor, DP conveying motor, DP feed-shift motor, DP registration clutch


Connector	Pins	Signal	I/O	Voltage	Description
YC2	1	FG	-	-	Ground
	2	GND	-	-	Ground
	3	3.3 V DC 3	I	3.3 V DC	Power supply input
	4	DP_ORG_SET	I	0 V/3.3 V DC	DP original set detection
	5	DP_OPEN	I	0 V/3.3 V DC	DP open/close detection
	6	DP_TMG	O	0 V/3.3 V DC	VSYNC output to Enginee
	7	DP_RDY	O	0 V/3.3 V DC (pulse)	Enginee-DP communication status
	8	DP_SI	O	0 V/3.3 V DC (pulse)	Enginee-DP communication data
	9	DP_SEL	I	0 V/3.3 V DC	Enginee-DP communication select
	10	DP_SO	I	0 V/3.3 V DC (pulse)	Enginee-DP communication data
	11	DP_CLK	I	0 V/3.3 V DC (pulse)	Enginee-DP communication clock
	12	3.3 V DC 2_E	I	3.3 V DC	Power supply input
	13	3.3 V DC 2_E	I	3.3 V DC	Power supply input
	14	24 V DC 2	I	24 V DC	Power supply input
	15	24 V DC 2	I	24 V DC	Power supply input
	16	GND	-	-	Ground
	17	GND	-	-	Ground
	18	GND	-	-	Ground
	19	GND	-	-	Ground
YC3	1	24 V DC 2	O	24 V DC	Power supply output
	2	NC	-	-	Not use
	3	24 V DC IL_DP	O	24 V DC	Power supply output
YC4	1	3.3 V DC 3	O	3.3 V DC	Power supply output
	2	GND	-	-	Ground
	3	SET_SW	I	0 V/3.3 V DC	DP original set detection
	4	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	5	GND	-	-	Ground
	6	FEED_SW	I	0 V/3.3 V DC	Original conveying detection
	7	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	8	GND	-	-	Ground
	9	REGIST_SW	I	0 V/3.3 V DC	Original conveying registration detection
	10	3.3 V DC 3	O	3.3 V DC	Power supply output
	11	GND	-	-	Ground
	12	DP_OPEN_SW	I	0 V/3.3 V DC	DP open/close detection
	13	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	14	GND	-	-	Ground

Connector	Pins	Signal	I/O	Voltage	Description
YC4	15	HP_SW	I	0 V/3.3 V DC	Home position detection for the feed-shift guide and conveying pressure
	16	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	17	GND	-	-	Ground
	18	TIMING_SW	I	0 V/3.3 V DC	Original conveying timing detection
YC6	1	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	2	GND	-	-	Ground
	3	LS_SW	I	0 V/3.3 V DC	Original length detection
	4	3.3 V DC 2_E	O	3.3 V DC	Power supply output
	5	WSIZE	I	0 V to 3 V DC	Original width detection
	6	GND	-	-	Ground
YC7	1	FEED_MOT_A	O	0 V to 24 V DC (analog)	Feed motor output
	2	FEED_MOT_B	O	0 V to 24 V DC (analog)	Feed motor output
	3	FEED_MOT_/A	O	0 V to 24 V DC (analog)	Feed motor output
	4	FEED_MOT_/B	O	0 V to 24 V DC (analog)	Feed motor output
	5	CONV_MOT_A	O	0 V to 24 V DC (analog)	Conveying motor output
	6	CONV_MOT_/A	O	0 V to 24 V DC (analog)	Conveying motor output
	7	CONV_MOT_B	O	0 V to 24 V DC (analog)	Conveying motor output
	8	CONV_MOT_/B	O	0 V to 24 V DC (analog)	Conveying motor output
	9	JNC_MOT_A	O	0 V to 24 V DC (analog)	feed-shift motor output
	10	JNC_MOT_B	O	0 V to 24 V DC (analog)	feed-shift motor output
	11	JNC_MOT_/A	O	0 V to 24 V DC (analog)	feed-shift motor output
	12	JNC_MOT_/B	O	0 V to 24 V DC (analog)	feed-shift motor output
	13	CL_REM	O	0 V/24 V DC	Registration clutch remote
	14	24 V DC IL_DP	O	24 V DC	Power supply output

8 - 2 Description for PWB (OPTION)

(1) PF PWB (PF-410/PF-471)

(1-1) Connector position



(1-2) Connector lists

Destination

- YC1: Enginee PWB
- YC2: PF drive motor
- YC3: PF lift sensor 1, PF paper sensor 1(U), PF paper sensor 1(L), PF conveying sensor 1
- YC4: PF lift motor 1, PF feed clutch 1, PF conveying clutch
- YC5: PF lift sensor 2, PF paper sensor 2(U), PF paper sensor 2(L), PF conveying sensor 2
- YC6: PF lift motor 2, PF feed clutch 2
- YC7: PF paper length switch 1, PF paper width switch 1, Right cover switch 3
- YC8: PF paper length switch 2, PF paper width switch 2


Connector	Pins	Signal	I/O	Voltage	Description
YC1	1	GND	-	-	Ground
	2	GND	-	-	Ground
	3	3.3V4	I	3.3 V DC	Power supply input
	4	3.3V0	I	3.3 V DC	Power supply input
	5	24V4	I	24 V DC	Power supply input
	6	PF_PAUSE	O	0 V/3.3 V DC	Pause signal
	7	PF_SET	O	0 V/3.3 V DC	Set signal
	8	PF_RDY	O	0 V/3.3 V DC	Ready signal
	9	PF_SEL	I	0 V/3.3 V DC	Paper Feeder select signal

Connector	Pins	Signal	I/O	Voltage	Description
YC1	10	EH_SI	I	0 V/3.3 V DC (pulse)	Serial communication data signal input
	11	EH_SO	O	0 V/3.3 V DC (pulse)	Serial communication data signal output
	12	EH_CLK	I	0 V/3.3 V DC (pulse)	Serial communication clock signal
YC2	1	MAIN_DIR	O	0 V/3.3 V DC	PF motor drive change signal
	2	MAIN_READY	I	0 V/3.3 V DC	PF motor ready signal
	3	MAIN_CLK	O	0 V/3.3 V DC (pulse)	PF motor clock signal
	4	MAIN_REM	O	0 V/3.3 V DC	PF motor
	5	GND	-	-	Ground
	6	24V4	O	24 V DC	Power supply output
YC3	1	3.3V4	O	3.3 V DC	Power supply output
	2	GND	-	-	Ground
	3	PFLS1	I	0 V/3.3 V DC	PF lift sensor 1
	4	3.3V4	O	3.3 V DC	Power supply output
	5	GND	-	-	Ground
	6	PFPS1(U)	I	0 V/3.3 V DC	PF upper feed sensor 1
	7	3.3V4	O	3.3 V DC	Power supply output
	8	GND	-	-	Ground
	9	PFPS1(L)	I	0 V/3.3 V DC	PF lower feed sensor 1
	10	3.3V4	O	3.3 V DC	Power supply output
	11	GND	-	-	Ground
	12	PFFS1	I	0 V/3.3 V DC	PF conveying sensor 1
YC4	1	LIFT_REM1	O	0 V/3.3 V DC	PF lift motor 1
	2	24V4	O	24 V DC	Power supply output
	3	REG_CL_REM1	O	0 V/3.3 V DC	PF feed clutch 1
	4	NC	-	-	Not use
	5	24V4	O	24 V DC	Power supply output
	6	REG_CL_REM	O	0 V/3.3 V DC	PF conveying clutch
	7	NC	-	-	Not use
	8	24V4	O	24 V DC	Power supply output
YC5	1	3.3V4	O	3.3 V DC	Power supply output
	2	GND	-	-	Ground
	3	PFLS2	I	0 V/3.3 V DC	PF lift sensor 2
	4	3.3V4	O	3.3 V DC	Power supply output
	5	GND	-	-	Ground
	6	PFPS2(U)	I	0 V/3.3 V DC	PF upper paper sensor 2
	7	3.3V4	O	3.3 V DC	Power supply output
	8	GND	-	-	Ground
	9	PFPS2(L)	I	0 V/3.3 V DC	PF lower paper sensor 2
	10	3.3V4	O	3.3 V DC	Power supply output
	11	GND	-	-	Ground
	12	PFFS2	I	0 V/3.3 V DC	PF conveying sensor 2
	13	NC	-	-	Not use
	14	GND	-	-	Ground
YC6	1	LIFT_REM2	O	0 V/24 V DC	PF lift motor 2
	2	24V4	O	24 V DC	Power supply output
	3	REG_CL_REM2	O	0 V/24 V DC	PF feed clutch 2
	4	NC	-	-	Not use

Connector	Pins	Signal	I/O	Voltage	Description
	5	24V4	O	24 V DC	Power supply output
YC7	1	PAPLSIZE1(3)	I	0 V/3.3 V DC	PF paper length switch 1
	2	PAPLSIZE1(2)	I	0 V/3.3 V DC	PF paper length switch 1
	3	GND	-	-	Ground
	4	PAPLSIZE1(1)	I	0 V/3.3 V DC	PF paper length switch 1
	5	PAPWSIZE1	I	0 V/3.3 V DC	PF paper width switch 1
	6	GND	-	-	Ground
	7	COVEROPEN	I	0 V/3.3 V DC	DF right cover switch
	8	GND	-	-	Ground
YC8	1	PAPLSIZE2(3)	I	0 V/3.3 V DC	PF paper length switch 2
	2	PAPLSIZE1(2)	I	0 V/3.3 V DC	PF paper length switch 2
	3	GND	-	-	Ground
	4	PAPLSIZE2(1)	I	0 V/3.3 V DC	PF paper length switch 2
	5	PAWLSIZE2	I	0 V/3.3 V DC	PF paper width switch 2
	6	GND	-	-	Ground

(2) BR PWB (AK-470)

(2-1) Connector position



(2-2) Connector lists

Destination


- YC2: BR conveying sensor 1, 2 and 3
- YC3: BR motor
- YC4: BR cover switch
- YC5: DP relay PWB
- YC6: BR fan motor

Connector	Pins	Signal	I/O	Voltage	Description
YC2	1	3.3V2	O	3.3 V DC	Power supply output
	2	GND	-	-	Ground
	3	JAM_SENCE3	I	0 V/3.3 V DC	BR conveying sensor 3
	4	3.3V2	O	3.3 V DC	Power supply output
	5	GND	-	-	Ground
	6	JAM_SENCE2	I	0 V/3.3 V DC	BR conveying sensor 2
	7	3.3V2	O	3.3 V DC	Power supply output
	8	GND	-	-	Ground
	9	JAM_SENCE1	I	0 V/3.3 V DC	BR conveying sensor 1
YC3	1	SMOTB_	O	0 V/24 V DC (pulse)	BR motor control signal
	2	SMOTA_	O	0 V/24 V DC (pulse)	BR motor control signal
	3	SMOTB	O	0 V/24 V DC (pulse)	BR motor control signal
	4	SMOTA	O	0 V/24 V DC (pulse)	BR motor control signal
YC4	1	24V	O	24 V DC	Power supply output

Connector	Pins	Signal	I/O	Voltage	Description
YC4	2	NC	-	-	Not use
	3	24VIL	I	0 V/24 V DC	BR cover switch
YC5	1	BR_CLK	I	0 V/3.3 V DC (pulse)	Serial clock signal
	2	BR_SI	O	0 V/3.3 V DC (pulse)	Serial communication data signal output
	3	BR_SO	I	0 V/3.3 V DC (pulse)	Serial communication data signal input
	4	BR_SEL	I	0 V/3.3 V DC	Select signal
	5	BR_RDY	O	0 V/3.3 V DC	Ready signal
	6	3.3V4	I	3.3 V DC	Power supply input
	7	FAN_CONT	I	0 V/24 V DC	BR fan motor
	8	GND	-	-	Ground
	9	GND	-	-	Ground
	10	GND	-	-	Ground
	11	24V_DF	I	24 V DC	Power supply input
	12	24V_DF	I	24 V DC	Power supply input
YC6	1	FAN_CONT	O	0 V/24 V DC	BR fan motor
	2	+24V_DFD	O	24 V DC	Power supply output

(3) DF PWB (DF-470)

(3-1) Connector position



(3-2) Connector lists

Destination

- CN1: DF relay PWB
- CN5: Tray upper limit sensor, Tray lower limit sensor
- CN6: Paper detection sensor 1, Paper detection sensor 2
- CN7: Exit paper sensor, Adjustment sensor 1, 2
- CN8: Staple position sensor
- CN9: Conveying sensor
- CN10: Belt sensor
- CN11: Roller sensor, DF top cover sensor
- CN12: Drive motor in the staple unit, Home position sensor, Self-priming sensor, Staple sensor
- CN13: Staple cover switch
- CN14: Slide motor
- CN15: Tray motor
- CN16: Paddle solenoid
- CN17: Paper detection solenoid
- CN18: Adjustment motor 1, 2
- CN19: Conveying motor, Bundle exit motor
- CN20: Roller motor
- CN21: Belt solenoid
- CN22: Slide sensor


Connector	Pins	Signal	I/O	Voltage	Description
CN1	1	DF_CLK	I	0 V/5 V DC (pulse)	Serial clock signal
	2	DF_SI	O	0 V/5 V DC (pulse)	Serial communication data signal output
	3	DF_SO	I	0 V/5 V DC (pulse)	Serial communication data signal input
	4	DF_SEL	I	0 V/5 V DC	Select signal
	5	DF_RDY	O	0 V/5 V DC	Ready signal
	6	DF_SET	O	0 V/5 V DC	Finisher connect signal
	7	+24V	I	24 V DC	Power supply input
	8	+24V	I	24 V DC	Power supply input
	9	+24V	I	24 V DC	Power supply input
	10	GND	-	-	Ground
	11	GND	-	-	Ground
	12	GND	-	-	Ground
CN5	1	T_LL_SEN	I	0 V/5 V DC	DF tray lower sensor
	2	SGND	-	-	Ground
	3	+5V	O	5 V DC	Power supply output
	4	T_UL_SEN	I	0 V/5 V DC	DF tray upper sensor
	5	SGND	-	-	Ground
	6	+5V	O	5 V DC	Power supply output
	7	NC	-	-	Not connected
CN6	1	+5V	O	5 V DC	Power supply output
	2	SGND	-	-	Ground
	3	RHDS1	I	0 V/5 V DC	DF paper sensor 1
	4	+5V	O	5 V DC	Power supply output
	5	SGND	-	-	Ground
	6	RHDS2	I	0 V/5 V DC	DF paper sensor 2
CN7	1	+5V	O	5 V DC	Power supply output
	2	SGND	-	-	Ground
	3	EMPS	I	0 V/5 V DC	DF exit sensor
	4	+5V	O	5 V DC	Power supply output
	5	SGND	-	-	Ground
	6	FJ_HPS	I	0 V/5 V DC	DF adjustment sensor1
	7	+5V	O	5 V DC	Power supply output
	8	SGND	-	-	Ground
	9	RJ_HPS	I	0 V/5 V DC	DF adjustment sensor 2
CN8	1	+5V	O	5 V DC	Power supply output
	2	SGND	-	-	Ground
	3	JIS	I	0 V/5 V DC	DF staple position sensor
	4	NC	-	-	Not use
	5	NC	-	-	Not use
CN9	1	+5V	O	5 V DC	Power supply output
	2	SGND	-	-	Ground
	3	PINS	I	0 V/5 V DC	DF conveying sensor
CN10	1	+5V	O	5 V DC	Power supply output
	2	SGND	-	-	Ground
	3	BRS	I	0 V/5 V DC	DF belt sensor
	4	NC	-	-	Not use

Connector	Pins	Signal	I/O	Voltage	Description
CN11	1	+5V	O	5 V DC	Power supply output
	2	SGND	-	-	Ground
	3	RUDS	I	0 V/5 V DC	DF roller sensor
	4	+5V	O	5 V DC	Power supply output
	5	SGND	-	-	Ground
	6	JAMCVR_S	I	0 V/5 V DC	DF top cover sensor
CN12	1	STPM+	O	0 V/24 V DC (pulse)	DF staple motor control signal
	2	STPM+	O	0 V/24 V DC (pulse)	DF staple motor control signal
	3	STPM-	O	0 V/24 V DC (pulse)	DF staple motorcontrol signal
	4	STPM-	O	0 V/24 V DC (pulse)	DF staple motor control signal
	5	+5V	O	5 V DC	Power supply output
	6	STP_HPS	O	0 V/5 V DC	STHPS: On/Off
	7	SELF_P	I	0 V/5 V DC	STSPS: On/Off
	8	LS	I	0 V/5 V DC	STES: On/Off
	9	SGND	-	-	Ground
CN13	1	+24V	O	24 V DC	Power supply output
	2	H_SW	I	0 V/24 V DC	DF staple cover switch
CN14	1	SLD_*A	O	0 V/24 V DC (pulse)	DF slide motor control signal
	2	SLD_A	O	0 V/24 V DC (pulse)	DF slide motor control signal
	3	SLD_B	O	0 V/24 V DC (pulse)	DF slide motor control signal
	4	SLD_*B	O	0 V/24 V DC (pulse)	DF slide motor control signal
CN15	1	TM_+	O	0 V/24 V DC (pulse)	DF tray motor control signal
	2	TM_-	O	0 V/24 V DC (pulse)	DF tray motor control signal
	3	NC	-	-	Not use
CN16	1	+24V	O	24 V DC	Power supply output
	2	P_SOL	O	0 V/24 V DC	DF paddle solenoid
	3	NC	-	-	Not use
	4	NC	-	-	Not use
CN17	1	+24V	O	24 V DC	Power supply output
	2	S_SOL	O	0 V/24 V DC	DF paper solenid
	3	NC	-	-	Not use
CN18	1	FJMOT_*A	O	0 V/24 V DC (pulse)	DF adjustment motor 1 control signal
	2	FJMOT_A	O	0 V/24 V DC (pulse)	DF adjustment motor 1 control signal
	3	FJMOT_B	O	0 V/24 V DC (pulse)	DF adjustment motor 1 control signal
	4	FJMOT_*B	O	0 V/24 V DC (pulse)	DF adjustment motor 1 control signal
	5	RJMOT_*A	O	0 V/24 V DC (pulse)	DF adjustment motor 2 control signal
	6	RJMOT_A	O	0 V/24 V DC (pulse)	DF adjustment motor 2 control signal
	7	RJMOT_B	O	0 V/24 V DC (pulse)	DF adjustment motor 2 control signal
	8	RJMOT_*B	O	0 V/24 V DC (pulse)	DF adjustment motor 2 control signal
CN19	1	FMOT_*B	O	0 V/24 V DC (pulse)	DF conveying motor control signal
	2	+24V	O	24 V DC	Power supply output
	3	FMOT_B	O	0 V/24 V DC (pulse)	DF conveying motor control signal
	4	FMOT_A	O	0 V/24 V DC (pulse)	DF conveying motor control signal
	5	+24V	O	24 V DC	Power supply output
	6	FMOT_*A	O	0 V/24 V DC (pulse)	DF conveying motor control signal
	7	TMOT_*B	O	0 V/24 V DC (pulse)	DF bundle discharge motor control signal
	8	+24V	O	24 V DC	Power supply output

Connector	Pins	Signal	I/O	Voltage	Description
CN19	9	TMOT_B	O	0 V/24 V DC (pulse)	DF bundle discharge motor control signal
	10	TMOT_A	O	0 V/24 V DC (pulse)	DF bundle discharge motor control signal
	11	+24V	O	24 V DC	Power supply output
	12	TMOT_*A	O	0 V/24 V DC (pulse)	DF bundle discharge motor control signal
CN20	1	ROMOT_*B	O	0 V/24 V DC (pulse)	DF roller motor control signal
	2	+24V	O	24 V DC	Power supply output
	3	ROMOT_B	O	0 V/24 V DC (pulse)	DF roller motor control signal
	4	ROMOT_A	O	0 V/24 V DC (pulse)	DF roller motor control signal
	5	+24V	O	24 V DC	Power supply output
	6	ROMOT_*A	O	0 V/24 V DC (pulse)	DF roller motor control signal
CN21	1	+24V	O	24 V DC	Power supply output
	2	BR_SOL	O	0 V/24 V DC	DF belt solenoid
CN22	1	+5V	O	5 V DC	Power supply output
	2	SGND	-	-	Ground
	3	SLP_HP	I	0 V/5 V DC	DF slide sensor

9Appendixes

9 - 1 Repetitive defects gauge



* The repetitive marks interval may vary depending on operating conditions.

9 - 2 Firmware environment commands

The printer maintains a number of printing parameters in its memory. These parameters may be changed permanently with the FRPO (Firmware Reprogram) commands.

This section provides information on how to use the FRPO command and its parameters using examples.

Using FRPO commands for reprogramming the firmware

The current settings of the FRPO parameters are listed as the optional values on the service status page.

Note: Before changing any FRPO parameters, print out a service status page, so you will know the parameter values before the changes are made. FRPO INIT command can reset all the FRPO parameters to the default settings of the printer. (!R! FRPO INIT; EXIT;)

The FRPO command is sent to the printer in the following sequence:

!R! FRPO parameter, value; EXIT;

Example: Changing emulation mode to PC-PR201/65A

!R! FRPO P1, 6; EXIT;

FRPO parameters

Items	FRPO	Setting value	Factory setting
Default pattern resolution	B8	0: 300 dpi 1: 600 dpi	0
Default copy number	C0	1 to 999	1
Page orientation	C1	0: Portrait 1: Landscape	0
Default font	C2	Middle two digits of power-up font	0
	C3	Last two digits of power-up font	0
	C5	First two digits of power-up font	0
PCL font switch	C8	0: HP compatibility mode (Characters higher than 127 are not printed.) 32: Conventional mode (Characters higher than 127 are printed.) Supported symbol sets: ISO-60 Norway [00D], ISO-15 Italian [00I], ISO-11 Sweden [00S], ISO-6 ASCII [00U], ISO-4 U.K. [01E], ISO-69 France [01F], ISO-21 Germany [01G], ISO-17 Spain [02S], Symbol [19M]* *: 128 or more of the high code section can be printed with any C8 value. But, when setting C8 value to 0, character code 160 is not printed.	0
Print density control	D4	1: Light 2: Slightly light 3: Standard 4: Slightly dark 5: Dark	3
Total host buffer size	H8	0 to 99 in units of the size defined by FRPO S5	5
Form feed time-out value	H9	Value in units of 5 seconds (0 to 99).	6 1(100V model)

Items	FRPO	Setting value	Factory setting
Reduction rate	J0	0: 100% 5: 70 % 6: 81 % 7: 86 % 8: 94 % 9: 98 %	0
Auto linefeed (LF) mode *1	J7	0: Auto linefeed 1: No auto linefeed	0
Integer section of User horizontal offset *1	K0	-7 to +7 (cm)	0
Decimal section of User horizontal offset *1	K1	-99 to +99 (1/100 cm)	0
Integer section of User vertical offset *1	K2	-7 to +7 (cm)	0
Decimal section of User vertical offset *1	K3	-99 to +99 (1/100 cm)	0
Kanji font number *1	K4	0: Same as V7 1: Mincho 40 dots 2: Gothic 40 dots 5: Mincho 48 dots 6: Gothic 48 dots	0
New/old JIS code switching *1	K6	0: New JIS mode 1: Old JIS mode	0
KIR	N0	0: OFF 2: ON	2
Duplex printing mode selection	N4	0: OFF 1: Long-edge mode (long-edge bind) 2: Short-edge mode (Short-edge bind)	0
Sleep timer time-out time	N5	1 to 240 minutes [0: OFF]	1
Eco Print mode	N6	0: OFF 2: ON	0
Resolution	N8	0: 300dpi 1: 600dpi 3: 1200dpi	1
Default emulation mode	P1	6: PCL6 (except PCL XL) 9: KPDL	6 9(KDA)
Carriage-return action *	P2	0: Ignores 1: CR 2: CR+LF	1
Linefeed action *	P3	0: Ignores 1: LF 2: CR+LF	1

Items	FRPO	Setting value	Factory setting
KPDL auto switching (When the optional KPDL3 upgrade kit is installed)	P4	0: None 1: Auto switching	0 1(120V model)
AES option 1-After AES is started, the data neither applicable to KPDL nor auto switching (alternate) emulation is processed in KPDL (When the optional KPDL3 upgrade kit is installed).	P7	After AES is started, the data neither applicable to KPDL nor auto switching (alternate) emulation is processed in KPDL. 0: AES activated by all the page exit commands. 1: None 2: AES activated by all the page exit commands and Prescribe EXIT command. 3: AES activated by Prescribe EXIT command only. 4: AES activated by ^L command only. 6: AES activated by Prescribe EXIT command and ^L command. After AES is started, the data neither applicable to KPDL nor auto switching (alternate) emulation is processed in KPDL. 10: AES activated by all the page exit commands and Prescribe EXIT command.	10 11(120V model)
Command recognition character	P9	ASCII code of 33 to 126	82(R)
Stacker setting at start-up	R0	1(Main tray) 3 5	1 3 (When DF-470 is installed)

Items	FRPO	Setting value	Factory setting
Paper Size	R2	0: Size of the default paper cassette (See R4.) 1: Envelope Monarch 2: Envelope #10 3: Envelope DL 4: Envelope C5 5: Executive 6: Letter 7: Legal 8: ISO A4 9: JIS B5 10: ISO A3 11: JIS B4 12: Ledger 13: ISO A5 14: ISO A6 15: JIS B6 16: Envelope #9 17: Envelope #6-3/4 18: ISO B5 19 Custom 30: C4 31: Cardstock 32: 20: Oufuku Hagaki 33: Oficio II 39: 8K 40: 16K 42: 8.5x13.5 50: Statement 51: Folio 52: Youkei type 2 (Envelope) 53: Youkei type 4 (Envelope)	0
Default paper source	R4	0: Multi Purpose Tray 1: Cassette 1 2: Cassette 2 3: Cassette 3	1
MP tray paper size	R7	Same as the R2 values except: 0	8 6(120V model)
A4/Letter override	S4	0: OFF 1: ON	1 0(100V model)
Host buffer size rate (H8 value and integration)	S5	0: 10 KB 1: 100 KB 2: 1 MB	1
RAM disk size	S6	1 to 1024 MB	128
RAM disk mode	S7	0: OFF 1: ON	1
Wide A4	T6	0: OFF 1: ON	0

Items	FRPO	Setting value	Factory setting
Line spacing *	U0	Lines per inch (integer value)	6
Line spacing	U1	Lines per inch (fraction value)	0
Character spacing	U2	Characters per inch (integer value)	10
Character spacing	U3	Characters per inch (fraction value)	0
Country code of the resident fonts	U6	0: US 1: France 2: Germany 3: U.K. 4: Denmark 5: Sweden 6: Italy 7: Spain 8: Japan 9: US legal 10: IBM PC-850 (Multi-lingual) 11: IBM PC-860 (Portuguese) 12: IBM PC-863 (Canadian French) 13: IBM PC-865 (Norwegian) 14: Norway 15: Denmark 2 16: Spain 2 17: Latin America 21: US ASCII (U7 = 50 SET) 77: HP Roman-8 (U4 = 52 SET)	41 0(100V model)
Supported symbol sets	U7	0: Same as the default emulation mode (P1) 1: IBM 6: IBM PC-8 50: US ASCII (U6 = 21 SET) 52: HP Roman-8 (U6 = 77 SET)	53 0(100V model)
Default font pitch	U8	0 to 99	10
	U9	0 to 99	0
ANK outline font size at start-up*	V0	Integer value of ANK outline font size at power-up Upper 2-digit/valid value: 00 to 09	0
	V1	Integer value of ANK outline font size at power-up Lower 2-digit/valid value: 00 to 99	12
	V2	Decimal value of ANK outline font size at power-up Valid value: 00, 25, 50, 75	0

Items	FRPO	Setting value	Factory setting
ANK outline font name at start-up*	V3	ANK outline font name at power-up	Courier
Initial Kanji outline font size (100 V model only)*, *1	V4	Upper 2-digit integer value of Kanji outline font size at start-up Valid value range: 00 to 09	0
	V5	2-digit integer value of the Kanji outline font size at start-up Valid value range: 00 to 99	10
	V6	2-digit decimal value of the Kanji outline font size at start-up Valid value: 00, 25, 50, 75	0
	V7	Kanji outline font name at start-up	MTHSMINCHO -W3
Default weight (courier and letter Gothic)	V9	0: Courier = darkness Letter Gothic = darkness 1: Courier = regular Letter Gothic = darkness 4: Courier = darkness Letter Gothic = regular 5: Courier = regular Letter Gothic = regular	5
Media type (MP tray)	X0	1: Plain 2: Transparency 3: Preprinted 4: Labels 5: Bond 6: Recycled 7: Vellum 9: Letterhead 10: Color 11: Prepunched 12: Envelope 13: Cardstock 16: Thick 17: High quality 21 to 28: Custom 1 to Custom 8	1





Items	FRPO	Setting value	Factory setting
Media type (Paper cassettes 1)	X1	1: Plain 3: Preprinted 5: Bond 6: Recycled 7: Vellum 9: Letterhead 10: Color 11: Prepunched 16: Thick 17: High quality 21 to 28: Custom 1 to Custom 8	1
Media type (Cassette 2, 3)	X2 X3	1: Plain 3: Preprinted 5: Bond 6: Recycled 7: Vellum 9: Letterhead 10: Color 11: Prepunched 16: Thick 17: High quality 21 to 28: Custom 1 to Custom 8	1
Cassette selection mode (PCL)	X9	0: Paper selection depending on an escape sequence compatible with HP-LJ5Si 2: Paper selection depending on an escape sequence compatible with HP-LJ8000	0
Auto error clear at an error (For errors to clear by pressing [Go] key only)	Y0	0: OFF 1: ON	0
Auto error clear timeout time	Y1	Value in units of 5 seconds (0 to 99).	6 (30 sec)
Paper error detection at duplex printing	Y3	0 to 255	127

Items	FRPO	Setting value	Factory setting
Forced duplex printing setting (Media type is Preprinted, Prepunched and Letterhead only)	Y4	0: OFF 1: ON	0
PDF direct printing	Y5	0: Zoom depending on paper size 1: Loads paper which is the same size as the image 2: Loads Letter, A4 size paper depending on the image size Enlarges or reduces the image to fit in the current paper size 3: Loads Letter, A4 size paper depending on the image size 8: Printed in full magnification 9: Loads Letter, A4 size paper depending on the image size 10: Loads Letter, A4 size paper depending on the image size Enlarges or reduces the image to fit in the current paper size	0
e-MPS error	Y6	0: No error control 1: Output the error list 2: Displays the error 3: Displays the error and prints the error report	3





*1: 100V model only

*: Ignored depending on emulation




9 - 3 Chart of image adjustment procedures

Adjusting order	Item	Image	Maintenance mode		Page	Setting procedure		Remarks
			No.	Mode		Method	Adjustment	
1	Adjusting the center line of the MP tray (Adjustment of writing) Changes the LSU writing start timing.		U034	LSU Out Left	P.6-36	<ol style="list-style-type: none"> 1 Press the Start key. 2 Select the adjustment content. [LSU Out Left] - [MPT] 3 Press the System Menu key. 4 Press the Start key. (Pattern output) 5 Press the System Menu key. 6 Execute the adjustment. 	<ol style="list-style-type: none"> 1 By using the [<] [>] keys or the numeric keys, change the setting value. 2 Press the Start key to set the setting value. 3 Press the [Stop] key. 	<p>*When the setting value is increased, the image moves rightward.</p> <p>*When adjusting for the duplex copy, select [Dup].</p>
2	Adjusting the center line of the cassettes (Adjustment of writing) Changes the LSU writing start timing.		U034	LSU Out Left	P.6-36	<ol style="list-style-type: none"> 1 Press the Start key. 2 Select the adjustment content. [LSU Out Left] - [Cass1] to [Cass3] 3 Press the System Menu key. 4 Press the Start key. (Pattern output) 5 Press the System Menu key. 6 Execute the adjustment. 	<ol style="list-style-type: none"> 1 By using the [<] [>] keys or the numeric keys, change the setting value. 2 Press the Start key to set the setting value. 3 Press the [Stop] key. 	<p>*When the setting value is increased, the image moves rightward.</p> <p>*When adjusting for the duplex copy, select [Dup].</p>
3	Adjusting the leading edge registration of the MP tray (Adjustment of writing) Changes the secondary paper feed timing.		U034	LSU Out Top Full	P.6-36	<ol style="list-style-type: none"> 1 Press the Start key. 2 Select the adjustment content. [Lsu Out Top Full] - [MPT] 3 Press the System Menu key. 4 Press the Start key. (Pattern output) 5 Press the System Menu key. 6 Execute the adjustment. 	<ol style="list-style-type: none"> 1 By using the [<] [>] keys or the numeric keys, change the setting value. 2 Press the Start key to set the setting value. 3 Press the [Stop] key. 	<p>*When the setting value is increased, the image moves downward.</p> <p>*When adjusting for the duplex copy, select [Duplex].</p>
4	Adjusting the leading edge registration of the cassette (Adjustment of writing) Changes the secondary paper feed timing.		U034	LSU Out Top Full	P.6-36	<ol style="list-style-type: none"> 1 Press the Start key. 2 Select the adjustment content. [Lsu Out Top Full] - [Cass] 3 Press the System Menu key. 4 Press the Start key. (Pattern output) 5 Press the System Menu key. 6 Execute the adjustment. 	<ol style="list-style-type: none"> 1 By using the [<] [>] keys or the numeric keys, change the setting value. 2 Press the Start key to set the setting value. 3 Press the [Stop] key. 	<p>*When the setting value is increased, the image moves downward.</p> <p>*When adjusting for the duplex copy, select [Duplex].</p>

> Chart of image adjustment procedures

Adjusting order	Item	Image	Maintenance mode		Page	Setting procedure		Remarks
			No.	Mode		Method	Adjustment	
5	Adjusting the leading edge margin (Adjustment of writing) Changes the LSU illumination start timing.		U402	Lead	P.6-108	<ol style="list-style-type: none"> 1 Press the Start key. 2 Select the adjustment content. [Lead] 3 Press the System Menu key. 4 Press the Start key. (Pattern output) 5 Press the System Menu key. 6 Execute the adjustment. 	<ol style="list-style-type: none"> 1 By using the [<] [>] keys or the numeric keys, change the setting value. 2 Press the Start key to set the setting value. 3 Press the [Stop] key. 	*When the setting value is increased, the margin get larger.
6	Adjusting the trailing edge margin (Adjustment of writing) Changes the LSU illumination end timing.		U402	Trail	P.6-108	<ol style="list-style-type: none"> 1 Press the Start key. 2 Select the adjustment content. [Trail] 3 Press the System Menu key. 4 Press the Start key. (Pattern output) 5 Press the System Menu key. 6 Execute the adjustment. 	<ol style="list-style-type: none"> 1 By using the [<] [>] keys or the numeric keys, change the setting value. 2 Press the Start key to set the setting value. 3 Press the [Stop] key. 	*When the setting value is increased, the margin get larger.
7	Adjusting the left and right margins (Adjustment of writing) Changes the LSU illumination start/end timing.		U402	A Margin C Margin	P.6-108	<ol style="list-style-type: none"> 1 Press the Start key. 2 Select the adjustment content. Select [A Margin] or [C Margin]. 3 Press the System Menu key. 4 Press the Start key. (Pattern output) 5 Press the System Menu key. 6 Execute the adjustment. 	<ol style="list-style-type: none"> 1 By using the [<] [>] keys or the numeric keys, change the setting value. 2 Press the Start key to set the setting value. 3 Press the [Stop] key. 	*When the setting value is increased, the margin get larger.
8	Adjusting magnification of the scanner in the main scanning direction Processes data.		U065	Main Scan	P.6-45	<ol style="list-style-type: none"> 1 Press the Start key. 2 Select the adjustment content. [Main Scan] 3 Press the System Menu key. 4 Place an original and press the Start key. (Test copy output) 5 Press the System Menu key. 6 Execute the adjustment. 	<ol style="list-style-type: none"> 1 By using the [<] [>] keys or the numeric keys, change the setting value. 2 Press the Start key to set the setting value. 3 Press the [Stop] key. 	U065: When using on the contact glass *When the setting value is increased, the image get larger.

> Chart of image adjustment procedures

Adjusting order	Item	Image	Maintenance mode		Page	Setting procedure		Remarks
			No.	Mode		Method	Adjustment	
9	Adjusting magnification of the scanner in the sub scanning direction (scanning adjustment) Changes the original scanning speed.		U065 U070 (original: Test copy)	Sub Scan Sub Scan(F) Sub Scan(B)	P.6-45 P.6-52	1 Press the Start key. 2 Select the adjustment content. U065: [Sub Scan] U070: [Sub Scan(F)] or [Sub Scan(B)] 3 Press the System Menu key. 4 Place an original and press the Start key. (Test copy output) 5 Press the System Menu key. 6 Execute the adjustment.	1 By using the [<] [>] keys or the numeric keys, change the setting value. 2 Press the Start key to set the setting value. 3 Press the [Stop] key.	U065: When using on the contact glass *When the setting value is increased, the image get larger. U070: When using document processor *When the setting value is increased, the image get longer.
10	Adjusting the center line (Adjustment of reading) Scan data is processed.		U067 U072 (original: Test copy)	Front Front Back	P.6-49 P.6-55	1 Press the Start key. 2 Select the adjustment content. U067: [Front] U072: [Front] or [Back] 3 Press the System Menu key. 4 Place an original and press the Start key. (Test copy output) 5 Press the System Menu key. 6 Execute the adjustment.	1 By using the [<] [>] keys or the numeric keys, change the setting value. 2 Press the Start key to set the setting value. 3 Press the [Stop] key.	U067: When using on the contact glass *When the setting value is increased, the image moves leftward. U072: When using document processor *Back adjustment selects [Back] at the time of duplex mode. *When the setting value is increased, the image moves rightward.
11	Adjusting the leading edge registration (Adjustment of reading) Changes the original scan start timing.		U066 U071 (original: Test copy)	Front Front Head Back Head	P.6-47 P.6-53	1 Press the Start key. 2 Press the System Menu key. 3 Place an original and press the Start key. (Test copy output) 4 Press the System Menu key. 5 Select the adjustment content. U066: [Front] U071: [Front Head]	1 By using the [<] [>] keys or the numeric keys, change the setting value. 2 Press the Start key to set the setting value. 3 Press the [Stop] key.	U066: When using on the contact glass *When the setting value is increased, the image moves forward. U071: When using document processor *Back adjustment selects [Back Head] at the time of duplex mode. *When the setting value is increased, the image moves forward.

When maintenance item U411 (Automatic adjustment in the scanner) is run using the specified original (P/N 7505000005), the following adjustments are automatically made:

- LED light intensity
- Scan timing
- White reference correction factor
- Chromatic aberration correction filter in the main scanning direction *1
- Color gamma input correction factor
- Color correction matrix factor

*1: CCD model only

When maintenance item U411 (Automatic adjustment in the scanner) is run using the specified original (P/N 302AC68243), the following adjustments are automatically made:

When running this test chart, you first must clean the feed rollers with alcohol and ensure the DP width guides are correctly positioned against the original.

- Adjusting the DP sub scanning magnification (U070)
- Adjusting the DP leading edge registration (U071)
- Adjusting the DP center line (U072)
- Adjusting the DP trailing edge registration (U071)

When maintenance item U411 (Automatic adjustment in the scanner) is run using the specified original, the following adjustments are automatically made:


- Adjusting the DP sub scanning magnification (U070)
- Adjusting the DP leading edge registration (U071)
- Adjusting the DP center line (U072)
- Adjusting the DP trailing edge registration (U071)

Image quality


Items	Specifications
100% magnification	Printer: ±0.8% Copy: ±1.5% Using DP: ±2.0%
Magnification	Copy: ±2.0% Using DP: ±2.5%
Lateral squareness	Copy: ±2.0mm/200mm Using DP: ±2.5mm/200mm
Leading edge timing	Print: 2.0 mm or less Copy: 2.0mm or less Using DP: 2.5mm or less
Skewed paper feed (left-right difference)	Print: 1.0mm /100mm or less Copy: 1.0mm /100mm or less (table) 1.5mm/100 mm or less (DP)
Lateral image shifting	Print: ±2.0mm or less (cassette) ±3.0mm or less (MP tray) Copy: ±2.0mm or less (cassette) ±3.0mm or less (MP tray) Using DP: ±2.0mm or less (cassette) ±3.0mm or less (MP tray)

9 - 4 Wiring diagram


(1) Engine




(2) Engine / ISU/ EH/ LVU/ Fuser




(3) Operation Panel / LCD



(4) Main/ Engine/ Operation Panel/ ISU/ LSU




(5) Document Processor




9 - 5 Wiring diagram (Options)


(1) Paper feeder (PF-470/PF-471)



(2) Attachment Kit (AK-470): 32ppm model only



(3) 500 sheets Finisher (DF-470): 32ppm model only



9 - 6 Installation guide


(1) IB-50

IB-50



(Network interface)

INSTALLATION GUIDE












IB-50



**Black & White
MFP 25/32**



**Black & White
MFP 25/30**




(2) IB-51

IB-51






(Wireless Interface)

INSTALLATION GUIDE

IB-51



**Black & White
MFP 25/32**




(3) IB-36

IB-36








(Wireless Interface)

INSTALLATION GUIDE

IB-36



**Black & White
MFP 25/32**



(4) PF-470/PF-471

PF-470/471

(500 sheetx1 Paper feeder)



(500 sheetx2 Paper feeder)

INSTALLATION GUIDE



PF-470/471 PAPER FEEDER






PF-470




PF-471




1




2




PF-470




PF-471




3




4




5-1




5-2




6



7





(ENG)

Fix Paper Width Guide

You can fix the paper width guide using the supplied retaining pins. Follow the steps below as necessary.

(FR)

Fixation du guide de largeur du papier

Vous pouvez fixer le guide de largeur du papier en utilisant les goupilles de fixation fournies.

Suivez les étapes ci-dessous en fonction des besoins.

(ES)

Fijar la guía de anchura del papel

Puede fijar la guía de anchura del papel con los pernos de retén proporcionados. Siga los pasos siguientes según sea necesario.

(DE)

Papierbreitenführung befestigen

Sie können die Papierbreitenführung mit den gelieferten Haltebolzen befestigen. Folgen Sie den Schritten unten falls notwendig.

(IT)

Fissare la guida di larghezza carta

Per fissare la guida di larghezza carta, utilizzare i perni di fissaggio forniti. Eseguire i seguenti punti come necessario.

(CN)

固定纸张宽度导板

您可以使用附带的定位卡榫固定纸张宽度导板。

必要时执行如下步骤。

(TW)

固定紙張寬度導板

您可以使用隨附的定位卡榫固定紙張寬度導板。

如有必要，請執行以下步驟。

(KO)

용지폭 가이드 고정

기기와 함께 제공된 핀으로 용지폭 가이드를 고정시킬 수 있습니다.



필요하면 아래의 작업을 하십시오.

(JP)

用紙幅ガイドの固定

用紙幅ガイドは同梱のピンで固定することが可能です。

必要に応じて、以下の作業を行って下さい。



(5) AK-470/DF-470

AK-470/DF-470







**(Conveying Unit)
(500 sheet Finisher)**





INSTALLATION GUIDE

DF-470 DOCUMENT FINISHER , AK-470 ATTACHMENT KIT



for
Black & White MFP 32
Black & White MFP 25/30
Color MFP 30
Color MFP 20/25






(6) Fax System 13










Fax System 13

INSTALLATION GUIDE


FAX System 13



Black & White MFP 25/32



1	LINE connector	Connect the modular cord for the telephone line to this connector.
2	TEL connector	When using a commercially available telephone set, connect the modular cord to this connector.
1	Connecteur LINE	Brancher le cordon pour la ligne téléphonique sur cette prise.
2	Connecteur TEL	Lors de l'utilisation d'un téléphone standard, brancher le cordon téléphonique à cette prise.
1	Conector de LINEA	Conecte el cable modular de la línea telefónica a este conector.
2	Conector TEL	Si utiliza un aparato telefónico de los disponibles en el mercado, conecte el cable modular a este conector.
1	Leitungs-anschluss-buchse	Verbinden Sie diesen Anschluss mit der Telefonsdose.
2	Telefonanschlussbuchse	Hier kann ein Telefon angeschlossen werden.
1	Connettore LINEA	Collegare a questo connettore il cavo modulare della linea telefonica.
2	Connettore TEL	Se si desidera collegare al sistema un normale telefono, collegarlo a questo connettore.
1	LINHA conector	Conecte o cabo modular para a linha telefónica a este conector.
2	TEL conector	Ao usar um aparelho telefónico disponível comercialmente, conecte o cabo modular a este conector.
1	LINE接続コネクタ	電話回線のモジュラーコードを接続してください。
2	TEL接続コネクタ	市販の電話機を併用する場合は、ここに接続してください。



10

FAX Setup Wizard

(ENG)

The machine provides Quick Setup Wizard in System Menu to set the FAX. Follow the instructions on the operation panel.



(BR)

A máquina fornece o Assistente de Configuração Rápida no Menu do Sistema para configurar o FAX. Siga as instruções no painel de operação.




(CZ)

V systémové nabídce zařizeni najdete Průvodce rychlým nastavením, pomocí něhož můžete nastavit FAX. Postupujte podle pokynů na provozním panelu.




(DE)

Die Maschine bietet den Schnelleinstieg Wizard im Systemmenü an, um das Fax einzustellen. Folgen Sie den Anweisungen auf dem Bedienfeld.



(DK)

Maskinen indeholder en Guide til hurtig opsætning i System menuen til indstilling af faxen. Følg anvisningerne på betjeningspanelet.




(ES)

La máquina dispone del Asistente de configuración rápida en el Menu Sistema para configurar el fax. Siga las instrucciones del panel de controles.




(FI)

Laitteen Järjestelmä-valikossa on ohjattu pika-asennustoiminto faksin asetusta varten. Noudata käyttöpaneelin ohjeita.




(FR)

L'appareil prévoit un Assistant de configuration rapide dans le menu système pour régler les paramètres du fax. Suivez les instructions sur le panneau de commande.



(GR)

Το μηχάνημα διαθέτει έναν Οδηγό Γρήγορης Εγκατάστασης στο Μενού Συστήματος για τη ρύθμιση του ΦΑΞ. Ακολουθήστε τις οδηγίες που εμφανίζονται στον πίνακα λειτουργίας.




(HEB)

המכשיר מספק אשף הגדרה מהירה במסך המערכת, להגדרת הפקס. פנה לפי ההוראות המופיעות בלוח המפעיל.



(HU)

A rendszermenüben a gyorsleleptető varázsló lehetővé teszi a FAX beállítását. Kövesse a kezelőpultton megjelenő utasításokat.



(IT)

È possibile utilizzare la procedura guidata di installazione rapida reperibile nel Menu Sistema per la configurazione del modulo FAX. Attenersi alle istruzioni visualizzate sul pannello comandi.



(NL)

In het Systemmenu van het apparaat bevindt zich de wizard Snel installeren om de fax in te stellen. Volg de instructies op het bedieningspaneel van de fax.



(NO)

Maskinen har en Hurtigoppsettveiviser i Systemmenyen til innstilling av faxen. Følg veiledningen på betjeningspanelet.



(PL)

W menu systemowym urządzenia dostępny jest Przewodnik szybkiej instalacji, który pozwoli ustawić funkcję FAKSU. Wykonuj instrukcje z panelu operacyjnego.




(PT)

A máquina proporciona o Assistente de Configuração Rápida no Menu do Sistema para definir o FAX. Siga as instruções no painel de funcionamento.



(RO)

Echipamentul are un expert de configurare rapidă în meniul Sistem pentru configurarea faxului. Urmați instrucțiunile din panoul de utilizare.




(RU)

Аппарат позволяет запустить мастер быстрой установки из системного меню для настройки факса. Выполните инструкции на панели управления.



(SV)

Maskinen har en snabbstartguide i systemmenyn för att ställa in faxen. Följ instruktionerna som anges på kontrollpanelen.



(TR)

Cihaz FAXS ayarlamak için Sistem Menüünde Hızlı Kurulum Sihirbazı sunar. İlgili panosundaki talimatları izleyin.



(ARA)

يوفر الجهاز معالج الإعداد السريع في قائمة النظام لإعداد الفاكس. اتبع التعليمات الموجودة على لوحة التشغيل.



(CN)

可通过机器系统菜单中的快速设置向导设置传真。请遵循操作面板上的指导说明。



(TW)

可透過系統選單中的快速設定精靈進行傳真設定。請依照操作面板上的指示說明。



(KO)

기기의 시스템 메뉴에서 팩스를 설정할 수 있도록 빠른 설정 마법사를 제공합니다. 조작 패널에 표시된 지침을 따르십시오.



(JP)

本機は、システムメニューに簡単セットアップウィザードを搭載しております。画面にしたがってファクスを設定してください。



KYOCERA Document Solutions America, Inc.

Headquarters

225 Sand Road,
Fairfield, New Jersey 07004-0008, USA
Phone: +1-973-808-8444
Fax: +1-973-882-6000

Latin America

8240 NW 52nd Terrace Dawson Building, Suite 301
Miami, Florida 33166, USA
Phone: +1-305-421-6640
Fax: +1-305-421-6666

KYOCERA Document Solutions Canada, Ltd.

6120 Kestrel Rd., Mississauga, ON L5T 1S8,
Canada
Phone: +1-905-670-4425
Fax: +1-905-670-8116

KYOCERA Document Solutions

Mexico, S.A. de C.V.

Calle Arquimedes No. 130, 4 Piso, Colonia Polanco
Chapultepec, Delegacion Miguel Hidalgo,
Distrito Federal, C.P. 11560, México
Phone: +52-555-383-2741
Fax: +52-555-383-7804

KYOCERA Document Solutions Brazil, Ltda.

Alameda África, 545, Pólo Empresarial Consbrás,
Tamboré, Santana de Parnaíba, State of São Paulo, CEP
06543-306, Brazil
Phone: +55-11-2424-5353
Fax: +55-11-2424-5304

KYOCERA Document Solutions Chile SpA

Jose Ananias 505, Macul. Santiago, Chile
Phone: +562-2350-7000
Fax: +562-2350-7150

KYOCERA Document Solutions

Australia Pty. Ltd.

Level 3, 6-10 Talavera Road North Ryde N.S.W, 2113,
Australia
Phone: +61-2-9888-9999
Fax: +61-2-9888-9588

KYOCERA Document Solutions

New Zealand Ltd.

Ground Floor, 19 Byron Avenue, Takapuna, Auckland,
New Zealand
Phone: +64-9-415-4517
Fax: +64-9-415-4597

KYOCERA Document Solutions Asia Limited

13/F., Mita Centre, 552-566, Castle Peak Road Tsuen Wan,
New Territories, Hong Kong
Phone: +852-2496-5678
Fax: +852-2610-2063

KYOCERA Document Solutions

(China) Corporation

8F, No. 288 Nanjing Road West, Huangpu District,
Shanghai, 200003, China
Phone: +86-21-5301-1777
Fax: +86-21-5302-8300

KYOCERA Document Solutions

(Thailand) Corp., Ltd.

335 Ratchadapisek Road, Wongsawang, Bangsue,
Bangkok 10800,
Thailand
Phone: +66-2-586-0333
Fax: +66-2-586-0278

KYOCERA Document Solutions

Singapore Pte. Ltd.

12 Tai Seng Street #04-01A,
Luxasia Building, Singapore 534118
Phone: +65-6741-8733
Fax: +65-6748-3788

KYOCERA Document Solutions

Hong Kong Limited

16/F., Mita Centre, 552-566, Castle Peak Road Tsuen Wan,
New Territories, Hong Kong
Phone: +852-3582-4000
Fax: +852-3185-1399

KYOCERA Document Solutions

Taiwan Corporation

6F., No.37, Sec. 3, Minquan E. Rd.,
Zhongshan Dist., Taipei 104, Taiwan R.O.C.
Phone: +886-2-2507-6709
Fax: +886-2-2507-8432

KYOCERA Document Solutions Korea Co., Ltd.

#10F Daewoo Foundation Bldg 18, Toegyero, Jung-gu,
Seoul, Korea
Phone: +822-6933-4050
Fax: +822-747-0084

KYOCERA Document Solutions

India Private Limited

Second Floor, Centrum Plaza, Golf Course Road,
Sector-53, Gurgaon, Haryana 122002, India
Phone: +91-0124-4671000
Fax: +91-0124-4671001

KYOCERA Document Solutions Europe B.V.

Bloemlaan 4, 2132 NP Hoofddorp,
The Netherlands
Phone: +31-20-654-0000
Fax: +31-20-653-1256

KYOCERA Document Solutions Nederland B.V.

Beechavenue 25, 1119 RA Schiphol-Rijk,
The Netherlands
Phone: +31-20-5877200
Fax: +31-20-5877260

KYOCERA Document Solutions (U.K.) Limited

Eldon Court, 75-77 London Road,
Reading, Berkshire RG1 5BS,
United Kingdom
Phone: +44-118-931-1500
Fax: +44-118-931-1108

KYOCERA Document Solutions Italia S.p.A.

Via Monfalcone 15, 20132, Milano, Italy,
Phone: +39-02-921791
Fax: +39-02-92179-600

KYOCERA Document Solutions Belgium N.V.

Sint-Martinusweg 199-201 1930 Zaventem,
Belgium
Phone: +32-2-7209270
Fax: +32-2-7208748

KYOCERA Document Solutions France S.A.S.

Espace Technologique de St Aubin
Route de l'Orme 91195 Gif-sur-Yvette CEDEX,
France
Phone: +33-1-69852600
Fax: +33-1-69853409

KYOCERA Document Solutions Espana, S.A.

Edificio Kyocera, Avda. de Manacor No.2,
28290 Las Matas (Madrid), Spain
Phone: +34-91-6318392
Fax: +34-91-6318219

KYOCERA Document Solutions Finland Oy

Atomitie 5C, 00370 Helsinki,
Finland
Phone: +358-9-47805200
Fax: +358-9-47805212

KYOCERA Document Solutions Europe B.V., Amsterdam (NL) Zürich Branch

Hohlstrasse 614, 8048 Zürich,
Switzerland
Phone: +41-44-9084949
Fax: +41-44-9084950

KYOCERA Bilgitas Document Solutions Turkey A.S.

Altunizade Mah. Prof. Fahrettin Kerim Gökay Cad. No:45
34662 ÜSKÜDAR ISTANBUL, TURKEY
Phone: +90-216-339-0020
Fax: +90-216-339-0070

KYOCERA Document Solutions Deutschland GmbH

Otto-Hahn-Strasse 12, 40670 Meerbusch,
Germany
Phone: +49-2159-9180
Fax: +49-2159-918100

KYOCERA Document Solutions Austria GmbH

Wienerbergstraße 11, Turm A, 18. OG, 1100 Wien,
Austria
Phone: +43-1-863380
Fax: +43-1-86338-400

KYOCERA Document Solutions Nordic AB

Esbogatan 16B 164 75 Kista, Sweden
Phone: +46-8-546-550-00
Fax: +46-8-546-550-10

KYOCERA Document Solutions Norge Nuf

Olaf Helsetsv. 6, 0619 Oslo, Norway
Phone: +47-22-62-73-00
Fax: +47-22-62-72-00

KYOCERA Document Solutions Danmark A/S

Ejby Industrivej 60, DK-2600 Glostrup,
Denmark
Phone: +45-70223880
Fax: +45-45765850

KYOCERA Document Solutions Portugal Lda.

Rua do Centro Cultural, 41 (Alvalade) 1700-106 Lisboa,
Portugal
Phone: +351-21-843-6780
Fax: +351-21-849-3312

KYOCERA Document Solutions South Africa (Pty) Ltd.

KYOCERA House, Hertford Office Park,
90 Bekker Road (Cnr. Allandale), Midrand, South Africa
Phone: +27-11-540-2600
Fax: +27-11-466-3050

KYOCERA Document Solutions Russia LLC.

Building 2, 51/4, Schepkina St., 129110, Moscow,
Russia
Phone: +7(495)741-0004
Fax: +7(495)741-0018

KYOCERA Document Solutions Middle East

Dubai Internet City, Bldg. 17,
Office 157 P.O. Box 500817, Dubai,
United Arab Emirates
Phone: +971-04-433-0412

KYOCERA Document Solutions Inc.

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: +81-6-6764-3555
<http://www.kyoceradocumentsolutions.com>