



TASKalfa 3050ci
TASKalfa 3550ci
TASKalfa 4550ci
TASKalfa 5550ci

**SERVICE
MANUAL**

Published in December 2013
842LC116
2LCSM066
Rev. 6

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

It may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for proper disposal.

ATTENTION

IL Y A UN RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UN MODÈLE DE TYPE INCORRECT. METTRE AU REBUT LES BATTERIES UTILISÉES SELON LES INSTRUCTIONS DONNÉES.

Il peut être illégal de jeter les batteries dans des eaux d'égout municipales. Vérifiez avec les fonctionnaires municipaux de votre région pour les détails concernant des déchets solides et une mise au rebut appropriée.

Notation of products in the manual

For the purpose of this service manual, products are identified by print speed at A4 and black and white modes.

TASKalfa 3050ci: 30 ppm model

TASKalfa 3550ci: 35 ppm model

TASKalfa 4550ci: 45 ppm model

TASKalfa 5550ci: 55 ppm model

Revision history

Revision	Date	Replaced pages	Remarks
1	March 14, 2011	Safety precautions, 1-2-12	-
2	March 31, 2011	Contents, 1-1-1 to 1-1-4, 1-1-7, 1-2-2, 1-2-4 to 1-2-6, 1-2-12 to 1-2-15, 1-2-17 to 1-2-70, 1-3-2 to 1-3-10, 1-3-14, 1-3-18 to 1-3-25, 1-3-27, 1-3-28, 1-3-31, 1-3-32, 1-3-34 to 1-3-37, 1-3-39 to 1-3-55, 1-3-57 to 1-3-89, 1-3-93 to 1-3-100, 1-3-103, 1-3-105, 1-3-113 to 1-3-118, 1-3-121, 1-3-124, 1-3-125, 1-3-130 to 1-3-135, 1-3-140, 1-3-143, 1-3-146, 1-3-148, 1-3-150 to 1-3-153, 1-3-155 to 1-3-157, 1-3-162, 1-3-163, 1-3-166, 1-3-169 to 1-3-171, 1-3-173, 1-3-174, 1-3-176 to 1-3-178, 1-3-181, 1-3-185, 1-3-187, 1-3-190, 1-3-191, 1-3-193, 1-3-198, 1-4-3 to 1-4-25, 1-4-28 to 1-4-49, 1-4-53, 1-4-59, 1-4-61, 1-4-62, 1-4-65 to 1-4-68, 1-4-73, 1-4-81, 1-4-82, 1-4-84, 1-4-89 to 1-4-92, 1-4-94, 1-4-100, 1-4-103 to 1-4-108, 1-5-3, 1-5-4, 1-5-10, 1-5-11, 1-5-15, 1-5-19, 1-5-20, 1-5-25, 1-5-30, 1-5-33 to 1-5-35, 1-5-39, 1-5-40, 1-5-41, 1-5-43, 1-5-45, 1-5-47, 1-5-49, 1-5-52, 1-5-54, 1-5-61, 1-5-62, 1-5-66, 1-5-68, 1-5-69, 1-5-72, 1-5-74, 1-5-77, 1-5-81, 1-5-82, 1-5-86, 1-5-89, 1-5-90, 2-1-12, 2-1-13, 2-1-20, 2-1-21, 2-1-23, 2-2-1 to 2-2-6, 2-2-8 to 2-2-10, 2-3-6, 2-3-7, 2-3-12, 2-3-15, 2-3-17, 2-3-18, 2-3-20, 2-3-30, 2-3-33, 2-3-34, 2-3-40, 2-3-41, 2-3-44, 2-3-47, 2-3-58 to 2-3-60, 2-3-67, 2-3-71 to 2-3-74, 2-3-77, 2-3-85, 2-4-11 to 2-4-13, 2-4-16 to 2-4-21, 2-4-28 to 2-4-30	-
3	July 28, 2011	Contents, 1-1-1 to 1-1-4, 1-2-2, 1-2-5, 1-2-7, 1-2-9, 1-2-10, 1-2-12, 1-2-13, 1-2-16, 1-2-17, 1-2-19, 1-2-23, 1-2-28, 1-2-29, 1-2-37, 1-2-40, 1-2-45, 1-2-69 to 1-2-104, 1-3-2 to 1-3-10, 1-3-17 to 1-3-20, 1-3-22, 1-3-23, 1-3-27, 1-3-31, 1-3-32, 1-3-36, 1-3-37, 1-3-40 to 1-3-42, 1-3-44 to 1-3-49, 1-3-52 to 1-3-55, 1-3-57 to 1-3-61, 1-3-70, 1-3-72 to 1-3-75, 1-3-81 to 1-3-83, 1-3-86, 1-3-88, 1-3-93, 1-3-95, 1-3-98, 1-3-101, 1-3-103 to 1-3-105, 1-3-109 to 1-3-110, 1-3-116 to 1-3-118, 1-3-120, 1-3-143, 1-3-147, 1-3-150, 1-3-152, 1-3-157 to 1-3-160, 1-3-164, 1-3-166, 1-3-167, 1-3-174, 1-3-175, 1-3-177, 1-3-182, 1-3-184 to 1-3-187, 1-3-189, 1-3-190, 1-3-203, 1-3-204, 1-4-3 to 1-4-7, 1-4-10 to 1-4-21, 1-4-25, 1-4-28, 1-4-31 to 1-4-78, 1-4-81, 1-4-82, 1-4-85 to 1-4-92, 1-4-95, 1-4-96, 1-4-98 to 1-4-100, 1-4-102 to 1-4-105, 1-4-112, 1-4-116 to 1-4-119, 1-4-127 to 1-4-130, 1-5-3, 1-5-6, 1-5-7, 1-5-22, 1-5-24, 1-5-30, 1-5-33, 1-5-37, 1-5-43, 1-5-44, 1-5-52, 1-5-53, 1-5-55 to 1-5-60, 1-5-76, 1-5-77, 1-5-80, 1-5-92, 1-6-1, 1-6-2, 2-1-3, 2-1-16, 2-1-17, 2-1-19 to 2-1-21, 2-2-1 to 2-2-3, 2-3-39, 2-3-41, 2-3-43 to 2-3-45, 2-3-52, 2-3-57, 2-3-64, 2-3-76, 2-3-90, 2-3-97 to 2-3-99, 2-4-1 to 2-4-9, 2-4-11, 2-4-18, 2-4-24	-

Revision	Date	Replaced pages	Remarks
4	September 30, 2011	Contents, 1-2-19, 1-2-28, 1-2-29, 1-2-37, 1-2-60, 1-2-77, 1-2-94, 1-3-50, 1-3-70, 1-3-103, 1-3-104, 1-3-167, 1-3-178, 1-4-48, 1-4-52 to 1-4-55, 1-4-59, 1-4-60, 1-4-64 to 1-4-67, 1-4-74, 1-4-91, 1-4-92, 1-5-24, 1-5-89, 1-6-1 to 1-6-4, 2-1-22, 2-4-1 to 2-4-9,	-
5	May 11, 2012	Contents, 1-2-10, 1-2-16, 1-2-19, 1-2-20, 1-2-66, 1-2-68, 1-2-71, 1-3-5 to 1-3-7, 1-3-9, 1-3-31 to 1-3-34, 1-3-67, 1-3-82, 1-3-83, 1-3-96, 1-3-103, 1-3-104, 1-3-147, 1-3-176, 1-3-179, 1-3-188 to 1-3-191, 1-3-193 to 1-3-196, 1-4-3, 1-4-57 to 1-4-62, 1-4-66, 1-4-126, 1-4-127, 1-5-2, 1-5-22 to 1-5-25, 1-5-28 to 1-5-32	-
6	December 5, 2013	Contents, 1-2-17, 1-2-22, 1-2-24, 1-2-39, 1-2-41, 1-2-65, 1-2-68, 1-2-69, 1-3-2, 1-3-4, 1-3-6, 1-3-7, 1-3-15 to 1-3-17, 1-3-20, 1-3-32, to 1-3-34, 1-3-42, 1-3-43, 1-3-72 to 1-3-75, 1-3-79, 1-3-80, 1-3-94, 1-3-96, 1-3-98, 1-3-100, 1-3-105, 1-3-106, 1-3-112 to 1-3-114, 1-3-124, 1-3-125, 1-3-138 to 1-3-140, 1-3-148, 1-3-176, 1-3-181, 1-3-183, 1-3-186, 1-3-189, 1-3-190, 1-3-193, 1-3-194, 1-3-197, 1-3-199, 1-3-211, 1-3-212, 1-4-2, 1-4-3, 1-4-5, 1-4-27 to 1-4-283, 1-4-297, 1-5-4, 1-5-59 to 1-5-61, 1-5-64, 1-5-81, 1-5-82, 1-5-85, 1-5-105, 1-5-106, 1-6-2, 2-1-3, 2-1-5, 2-1-6, 2-1-20, 2-2-2, 2-2-4, 2-2-5, 2-3-39, 2-3-79, 2-4-1 to 2-4-3, 2-4-7, 2-4-8, 2-4-11, 2-4-13, 2-4-16 to 2-4-32, 2-4-39, 2-4-44, 2-4-45, 2-4-48	-



Safety precautions

This booklet provides safety warnings and precautions for our service personnel to ensure the safety of their customers, their machines as well as themselves during maintenance activities. Service personnel are advised to read this booklet carefully to familiarize themselves with the warnings and precautions described here before engaging in maintenance activities.

Safety warnings and precautions

Various symbols are used to protect our service personnel and customers from physical danger and to prevent damage to their property. These symbols are described below:

⚠ DANGER: High risk of serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

⚠ WARNING: Serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

⚠ CAUTION: Bodily injury or damage to property may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

Symbols

The triangle (\triangle) symbol indicates a warning including danger and caution. The specific point of attention is shown inside the symbol.



General warning.



Warning of risk of electric shock.



Warning of high temperature.

⊘ indicates a prohibited action. The specific prohibition is shown inside the symbol.



General prohibited action.



Disassembly prohibited.

● indicates that action is required. The specific action required is shown inside the symbol.



General action required.





Remove the power plug from the wall outlet.











Always ground the copier.

1. Installation Precautions

WARNING











- Do not use a power supply with a voltage other than that specified. Avoid multiple connections to one outlet: they may cause fire or electric shock. When using an extension cable, always check that it is adequate for the rated current. 
- Connect the ground wire to a suitable grounding point. Not grounding the copier may cause fire or electric shock. Connecting the earth wire to an object not approved for the purpose may cause explosion or electric shock. Never connect the ground cable to any of the following: gas pipes, lightning rods, ground cables for telephone lines and water pipes or faucets not approved by the proper authorities. 

CAUTION:





- Do not place the copier on an infirm or angled surface: the copier may tip over, causing injury. 
- Do not install the copier in a humid or dusty place. This may cause fire or electric shock. 
- Do not install the copier near a radiator, heater, other heat source or near flammable material. This may cause fire. 
- Allow sufficient space around the copier to allow the ventilation grills to keep the machine as cool as possible. Insufficient ventilation may cause heat buildup and poor copying performance. 
- Always handle the machine by the correct locations when moving it. 
- Always use anti-toppling and locking devices on copiers so equipped. Failure to do this may cause the copier to move unexpectedly or topple, leading to injury. 
- Avoid inhaling toner or developer excessively. Protect the eyes. If toner or developer is accidentally ingested, drink a lot of water to dilute it in the stomach and obtain medical attention immediately. If it gets into the eyes, rinse immediately with copious amounts of water and obtain medical attention. 
- Advise customers that they must always follow the safety warnings and precautions in the copier's instruction handbook. 












2. Precautions for Maintenance

WARNING

- Always remove the power plug from the wall outlet before starting machine disassembly. 
- Always follow the procedures for maintenance described in the service manual and other related brochures. 
- Under no circumstances attempt to bypass or disable safety features including safety mechanisms and protective circuits. 
- Always use parts having the correct specifications. 
- Always use the thermostat or thermal fuse specified in the service manual or other related brochure when replacing them. Using a piece of wire, for example, could lead to fire or other serious accident. 
- When the service manual or other serious brochure specifies a distance or gap for installation of a part, always use the correct scale and measure carefully. 
- Always check that the copier is correctly connected to an outlet with a ground connection. 
- Check that the power cable covering is free of damage. Check that the power plug is dust-free. If it is dirty, clean it to remove the risk of fire or electric shock. 
- Never attempt to disassemble the optical unit in machines using lasers. Leaking laser light may damage eyesight. 
- Handle the charger sections with care. They are charged to high potentials and may cause electric shock if handled improperly. 



CAUTION

- Wear safe clothing. If wearing loose clothing or accessories such as ties, make sure they are safely secured so they will not be caught in rotating sections. 
- Use utmost caution when working on a powered machine. Keep away from chains and belts. 
- Handle the fixing section with care to avoid burns as it can be extremely hot. 
- Check that the fixing unit thermistor, heat and press rollers are clean. Dirt on them can cause abnormally high temperatures. 

- Do not remove the ozone filter, if any, from the copier except for routine replacement. 
- Do not pull on the AC power cord or connector wires on high-voltage components when removing them; always hold the plug itself. 
- Do not route the power cable where it may be stood on or trapped. If necessary, protect it with a cable cover or other appropriate item. 
- Treat the ends of the wire carefully when installing a new charger wire to avoid electric leaks. 
- Remove toner completely from electronic components. 
- Run wire harnesses carefully so that wires will not be trapped or damaged. 
- After maintenance, always check that all the parts, screws, connectors and wires that were removed, have been refitted correctly. Special attention should be paid to any forgotten connector, trapped wire and missing screws. 
- Check that all the caution labels that should be present on the machine according to the instruction handbook are clean and not peeling. Replace with new ones if necessary. 
- Handle greases and solvents with care by following the instructions below: 
 - Use only a small amount of solvent at a time, being careful not to spill. Wipe spills off completely.
 - Ventilate the room well while using grease or solvents.
 - Allow applied solvents to evaporate completely before refitting the covers or turning the power switch on.
 - Always wash hands afterwards.
- Never dispose of toner or toner bottles in fire. Toner may cause sparks when exposed directly to fire in a furnace, etc. 
- Should smoke be seen coming from the copier, remove the power plug from the wall outlet immediately. 

3. Miscellaneous

WARNING

- Never attempt to heat the drum or expose it to any organic solvents such as alcohol, other than the specified refiner; it may generate toxic gas. 
- Keep the machine away from flammable liquids, gases, and aerosols. A fire or an electric shock might occur. 

This page is intentionally left blank.

CONTENTS

1-1 Specifications

1-1-1 Specifications	1-1-1
1-1-2 Parts names	1-1-5
(1) Machine	1-1-5
(2) Option	1-1-7
(3) Operation panel	1-1-8
1-1-3 Machine cross section	1-1-9

1-2 Installation

1-2-1 Installation environment	1-2-1
1-2-2 Unpacking and installation	1-2-2
(1) Installation procedure	1-2-2
(2) Setting initial copy modes	1-2-18
1-2-3 Installing the key counter (option)	1-2-19
(1) Installing directly on the device	1-2-19
(2) Mounting on the document table	1-2-28
1-2-4 Installing the key card MK-2 (option for japan only)	1-2-37
1-2-5 Installing the KMAS (option for japan only)	1-2-51
1-2-6 Installing the coin vender (option for japan only)	1-2-60
1-2-7 Installing the cassette heater (option)	1-2-65
1-2-8 Installing the gigabit ethernet board (option)	1-2-70
1-2-9 Installing the IC card reader holder (option)	1-2-72
1-2-10 Installing the keyboard holder (option)	1-2-78
1-2-11 Installing the duct unit (option)	1-2-85
1-2-12 Installing the handset (option for japan only)	1-2-88
(1) Installing directly on the device	1-2-88
(2) Mounting on the document table	1-2-95

1-3 Maintenance Mode

1-3-1 Maintenance mode	1-3-1
(1) Executing a maintenance item	1-3-1
(2) Maintenance modes item list	1-3-2
(3) Contents of the maintenance mode items	1-3-11

1-4 Troubleshooting

1-4-1 Paper misfeed detection	1-4-1
(1) Paper misfeed indication	1-4-1
(2) Paper misfeed detection condition	1-4-2
1-4-2 Troubleshooting	1-4-27
(1) First check items	1-4-27
(2) Items and corrective actions relating to the device that will cause paper jam	1-4-31
(3) Paper jam at feeding from cassette	
Electrical parts that could cause paper jam during paper travelling	
at the primary feeding (regist roller)	1-4-45
(4) Paper jam at feeding from cassette 2	
Electrical parts that could cause paper jam during paper travelling	
at the primary feeding (regist roller)	1-4-47
(5) Paper jam during manual feeding	
Electrical parts that could cause paper jam during paper travelling	
at the primary feeding (regist roller)	1-4-49

(6) Paper jam at the duplex re-feeding unit	
Electrical parts that could cause paper jam during paper travelling	
at the primary feeding (regist roller).....	1-4-51
(7) Electrical parts that could cause paper jam at the Secondary transfer unit.....	1-4-52
(8) Electrical parts that could cause paper jam at the fuser and eject parts	1-4-53
(9) Electrical parts that could cause paper jam at the duplex unit	1-4-55
(10) Electrical parts that lead to a paper jam in the BR (bridge) part.....	1-4-57
(11) Electrical parts that could cause paper jam at the DF paper feeding part.....	1-4-59
(12) Electrical parts that could cause paper jam at the DF process part	1-4-61
(13) Electrical parts that lead to a paper jam in the DF eject tray	1-4-62
(14) Electrical parts that lead to a paper jam in the CF conveying part	1-4-63
1-4-3 Self-diagnostic function	1-4-64
(1) Self-diagnostic function	1-4-64
(2) Self diagnostic codes.....	1-4-65
1-4-4 Image formation problems	1-4-200
1-4-5 Poor image (due to DP and scanner reading)	1-4-202
(1) No image appears (entirely white).....	1-4-203
(2) No image appears (entirely black).....	1-4-206
(3) Image is too light.	1-4-208
(4) The background is colored.	1-4-212
(5) White streaks are printed vertically.....	1-4-215
(6) Black or color streaks appear longitudinally.	1-4-218
(7) Streaks are printed horizontally.	1-4-222
(8) One side of the print image is darker than the other.	1-4-225
(9) Black or color dots appear on the image.	1-4-228
(10) Image is blurred.	1-4-230
(11) The leading edge of the image is consistently misaligned with the original.	1-4-233
(12) Part of image is missing.	1-4-235
(13) Image is out of focus.	1-4-238
(14) Image center does not align with the original center.	1-4-240
(15) Shifted colors.....	1-4-241
(16) Moire.....	1-4-244
(17) Skewed image	1-4-245
(18) Abnormal image	1-4-247
1-4-6 Poor image (Image rendering problems: Mono-color printer engine	1-4-250
(1) No image appears (entirely white).....	1-4-251
(2) No image appears (entirely black).....	1-4-253
(3) Image is too light.	1-4-254
(4) The background is colored.	1-4-256
(5) White streaks are printed vertically.....	1-4-258
(6) Black or color streaks appear longitudinally.	1-4-259
(7) Black, white or color lines appear widthwise.	1-4-260
(8) Uneven density longitudinally.	1-4-261
(9) Uneven density widthwise.	1-4-262
(10) Black or color dots appear on the image.	1-4-262
(11) Offset occurs.	1-4-263
(12) Image is partly missing. (Outlines objects and white dots.).....	1-4-264
(13) Image is out of focus.	1-4-264
(14) Poor grayscale reproducibility.	1-4-265
(15) Unevenly repeating horizontal streaks in the printed objects.	
Colored spots in the printed objects.	1-4-265
1-4-7 Poor image	
(Transferring toner and Image rendering problems: Four-color printer engine.....	1-4-266
(1) No image appears (entirely white).....	1-4-268

(2) Image is too light.	1-4-269
(3) The background is colored.	1-4-270
(4) White streaks are printed vertically.	1-4-270
(5) Black or color streaks appear longitudinally.	1-4-271
(6) Black, white or color lines appear widthwise.	1-4-272
(7) Uneven transferring toner.	1-4-272
(8) Black or color dots appear on the image.	1-4-274
(9) Image is blurred (Shifted transferring).	1-4-274
(10) The leading edge of the image is consistently misaligned with the original.	1-4-275
(11) The leading edge of the image is sporadically misaligned with the original.	1-4-276
(12) Paper is wrinkled.	1-4-276
(13) Offset occurs.	1-4-278
(14) Image is partly missing (Outlines objects and white dots).	1-4-278
(15) Fusing is loose.	1-4-279
(16) Image is out of focus.	1-4-280
(17) Image center does not align with the original center.	1-4-280
(18) Dirty paper edges with toner.	1-4-281
(19) Inferior color reproducibility.	1-4-281
(20) Shifted colors.	1-4-282
(21) Dirty reverse side of paper.	1-4-283
1-4-8 Electric problems.	1-4-284
1-4-9 Mechanical problems.	1-4-292
1-4-10 Send error code.	1-4-294
(1) Scan to SMB error codes.	1-4-294
(2) Scan to FTP error codes.	1-4-295
(3) Scan to E-mail error codes.	1-4-296
1-4-11 Error codes.	1-4-298
(1) Error code.	1-4-298
(2) Table of general classification.	1-4-299
(2-1) U004XX error code table: Interrupted phase B.	1-4-301
(2-2) U006XX error code table: Problems with the unit.	1-4-301
(2-3) U008XX error code table: Page transmission error.	1-4-301
(2-4) U009XX error code table: Page reception error.	1-4-301
(2-5) U010XX error code table: G3 transmission.	1-4-302
(2-6) U011XX error code table: G3 reception.	1-4-303
(2-7) U017XX error code table: V.34 transmission.	1-4-304
(2-8) U018XX error code table: V.34 reception.	1-4-304
1-4-12 Printing System Troubleshooting.	1-4-305

1-5 Assembly and disassembly

1-5-1 Precautions for assembly and disassembly.	1-5-1
(1) Precautions.	1-5-1
(2) Drum.	1-5-1
(3) Toner.	1-5-1
(4) How to tell a genuine Kyocera toner container.	1-5-2
1-5-2 Paper feed section.	1-5-3
(1) Detaching and refitting the primary paper feed unit.	1-5-3
(2) Detaching and refitting the forwarding pulley, paper feed pulley and separation pulley. [30 ppm model / 35 ppm model]	1-5-7
(3) Detaching and refitting the forwarding pulley, paper feed pulley and separation pulley. [45 ppm model / 55 ppm model]	1-5-10
(4) Detaching and refitting the MP tray paper feed unit.	1-5-11

(5) Detaching and refitting the MP forwarding pulley, MP paper feed pulley and MP separation pulley	1-5-14
1-5-3 Optical section	1-5-19
(1) Detaching and refitting the exposure lamp	1-5-19
(2) Detaching and refitting the scanner wires	1-5-22
(3) Detaching and refitting the ISU.....	1-5-26
(4) Detaching and refitting the LSU.....	1-5-33
(5) Color registration adjustment.....	1-5-39
1-5-4 Image formation section	1-5-42
(1) Detaching and refitting the inner unit.....	1-5-42
(2) Detaching and refitting the developer unit and drum unit	1-5-44
(3) Detaching and refitting the charger roller unit.....	1-5-46
1-5-5 Transfer section	1-5-47
(1) Detaching and refitting the paper conveying unit	1-5-47
(2) Detaching and refitting the transfer belt unit.....	1-5-49
(3) Detaching and refitting the cleaning pre brush	1-5-51
(4) Detaching and refitting the transfer roller	1-5-53
1-5-6 Fuser section	1-5-55
(1) Detaching and refitting the fuser unit.....	1-5-55
(2) Detaching and refitting fuser IH unit	1-5-57
1-5-7 PWBs.....	1-5-59
(1) Detaching and refitting the main PWB.....	1-5-59
(2) Detaching and refitting the engine PWB.....	1-5-64
(3) Detaching and refitting the power source PWB.....	1-5-66
(4) Detaching and refitting the high voltage PWB 1	1-5-69
(5) Detaching and refitting the high voltage PWB 2	1-5-70
(6) Detaching and refitting the operation PWB	1-5-71
(7) Detaching and refitting the fuser IH PWB.....	1-5-75
1-5-8 Drive section	1-5-80
(1) Detaching and refitting the drum drive unit K and the drum drive unit MCY.....	1-5-80
(2) Detaching and refitting the main drive unit	1-5-86
(3) Detaching and refitting the fuser drive unit, transfer drive unit and feed drive unit.....	1-5-87
(4) Detaching and refitting the lift motor 1 and 2.....	1-5-93
1-5-9 Others.....	1-5-94
(1) Detaching the eject filter.....	1-5-94
(2) Detaching and refitting the toner filter.....	1-5-95
(3) Detaching and refitting the fan filter.....	1-5-96
(4) Detaching and refitting the transfer belt filter.....	1-5-97
(5) Detaching and refitting the DU filter.....	1-5-98
(6) Detaching and refitting the left filter	1-5-99
(7) Detaching and refitting the developer filter	1-5-100
(8) Detaching and refitting the hard disk unit	1-5-101
(9) Detaching and refitting the eject unit	1-5-103
(10) Direction of installing the principal fan motors	1-5-104
(11) Skewed paper feeding check/adjustment.....	1-5-105

1-6 Requirements on PWB Replacement

1-6-1 Upgrading the firmware	1-6-1
1-6-2 Remarks on main PWB replacement.....	1-6-4
1-6-3 Remarks on engine PWB replacement	1-6-6

2-1 Mechanical Construction

2-1-1 Paper feed/conveying section	2-1-1
(1) Cassette paper feed section	2-1-1
(2) MP tray paper feed section	2-1-3
(3) Paper conveying section	2-1-5
2-1-2 Drum section	2-1-8
2-1-3 Developer section	2-1-10
2-1-4 Optical section	2-1-12
(1) Image scanner section	2-1-12
(2) Laser scanner section	2-1-14
2-1-5 Transfer/Separation section	2-1-16
(1) Intermediate transfer unit section	2-1-16
(2) Secondary transfer roller section	2-1-18
2-1-6 Fuser section	2-1-20
2-1-7 Eject/Feedshift section	2-1-22
2-1-8 Duplex conveying section	2-1-24

2-2 Electrical Parts Layout

2-2-1 Electrical parts layout	2-2-1
(1) PWBs	2-2-1
(2) Switches and sensors	2-2-4
(3) Motors	2-2-6
(4) Fan motors	2-2-8
(5) Others	2-2-10

2-3 Operation of the PWBs

2-3-1 Main PWB	2-3-1
2-3-2 Engine PWB	2-3-12
2-3-3 Power source PWB	2-3-38
2-3-4 ISC PWB	2-3-46
2-3-5 Operation PWB 1	2-3-51
2-3-6 Front PWB	2-3-56
2-3-7 Feed PWB 1	2-3-65
2-3-8 Feed PWB 2	2-3-75
2-3-9 Relay PWB	2-3-81
2-3-10 Motor control PWB	2-3-87
2-3-11 LSU relay PWB	2-3-91

2-4 Appendixes

2-4-1 Appendixes	2-4-1
(1) List of maintenance parts	2-4-1
(2) Maintenance kits	2-4-4
(3) Periodic maintenance procedures	2-4-6
(4) Repetitive defects gauge	2-4-10
(5) Firmware environment commands	2-4-11
(6) System Error (Fxxxx) Outline	2-4-18
(7) Timing chart	2-4-23
(8) Chart of image adjustment procedures	2-4-33
(9) Wiring diagram	2-4-35

INSTALLATION GUIDE

DOCUMENT PROCESSOR
PAPER FEEDER
LARGE CAPACITY FEEDER
SIDE DECK
SIDE MULTI TRAY
1000-SHEETS FINISHER
4000-SHEETS FINISHER
FINISHER ATTACHMENT KIT
CENTER-FOLDING UNIT
MAILBOX
PUNCH UNIT
INNER JOB SEPARATOR
100-SHEETS INNER JOB SEPARATOR
RIGHT JOB SEPARATOR
BANNER GUIDE
FAX SYSTEM
DOCUMENT TABLE
PRINTING SYSTEM

1-1-1 Specifications

Machine

Item	Specifications				
	30 ppm	35 ppm	45 ppm	55 ppm	
Type	Desktop				
Printing method	Electrophotography by semiconductor laser, tandem drum system				
Originals	Sheet, Book, 3-dimensional objects (maximum original size: A3/12 × 18")				
Original feed system	Fixed				
Paper weight	Cassette	60 to 220 g/m ²		60 to 256 g/m ²	
	MP tray	60 to 300 g/m ²			
Paper type	Cassette	Plain, Rough, Vellum, Recycled, Preprinted, Bond, Color (Colour), Prepunched, Letterhead, Thick, High Quality, Custom 1 to 8 (Duplex: Same as simplex)			
	MP tray	Plain, Transparency (OHP film), Rough, Vellum, Labels, Recycled, Preprinted, Bond, Cardstock, Color (Colour), Prepunched, Letterhead, Thick, Coated, Envelope, High Quality, Custom 1 to 8			
Paper size	Cassette	A3, B4, A4, A4R, B5, B5R, A5R, Ledger, Legal, Letter, LetterR, StatementR, Oficio II, 12 × 18", Folio, 8K, 16K, 16KR			
	MP tray	A3, B4, A4, A4R, B5, ISO B5, B5R, A5R, B6R, A6R, Return postcard, Postcards, Envelope DL, Envelope C5, Envelope C4, Envelope #10 (Commercial #10), Envelope #9 (Commercial #9), Envelope #6 (Commercial #6 3/4), Envelope Monarch, Youkei 2, Youkei 4, Ledger, Legal, Letter, LetterR, Executive, StatementR, Oficio II, 12 × 18", Folio, 8K, 16K, 16KR, Custom			
Zoom level	Manual mode : 25 to 400%, 1% increments Auto mode : Preset zoom				
Printing speed	B/W	A4 : 30 ppm Letter : 30 ppm A4R : 21 ppm LetterR : 21 ppm A3 : 15 ppm Ledger : 15 ppm B4 : 18 ppm Legal : 18 ppm B5 : 30 ppm	A4 : 35 ppm Letter : 35 ppm A4R : 24 ppm LetterR : 24 ppm A3 : 17 ppm Ledger : 17 ppm B4 : 21 ppm Legal : 21 ppm B5 : 35 ppm	A4 : 45 ppm Letter : 45 ppm A4R : 31 ppm LetterR : 31 ppm A3 : 22 ppm Ledger : 22 ppm B4 : 27 ppm Legal : 21 ppm B5 : 45 ppm	A4 : 55 ppm Letter : 55 ppm A4R : 24 ppm LetterR : 24 ppm A3 : 27 ppm Ledger : 27 ppm B4 : 33 ppm Legal : 21 ppm B5 : 55 ppm
	Color	A4 : 30 ppm Letter : 30 ppm A4R : 21 ppm LetterR : 21 ppm A3 : 15 ppm Ledger : 15 ppm B4 : 18 ppm Legal : 18 ppm B5 : 30 ppm	A4 : 35 ppm Letter : 35 ppm A4R : 24 ppm LetterR : 24 ppm A3 : 17 ppm Ledger : 17 ppm B4 : 21 ppm Legal : 21 ppm B5 : 35 ppm	A4 : 45 ppm Letter : 45 ppm A4R : 24 ppm LetterR : 24 ppm A3 : 22 ppm Ledger : 22 ppm B4 : 27 ppm Legal : 21 ppm B5 : 45 ppm	A4 : 50 ppm Letter : 50 ppm A4R : 24 ppm LetterR : 24 ppm A3 : 25 ppm Ledger : 25 ppm B4 : 30 ppm Legal : 21 ppm B5 : 50 ppm

Item		Specifications			
		30 ppm	35 ppm	45 ppm	55 ppm
First print time (A4, feed from cassette)	B/W	6.2 s or less	5.8 s or less	4.7 s or less	4.4 s or less
	Color	8.1 s or less	7.4 s or less	6.0 s or less	5.7 s or less
Warm-up time (22 °C/71.6 °F, 60% RH)	Power on	25 s or less	25 s or less	30 s or less	30 s or less
	Low Power	15 s or less	15 s or less	20 s or less	20 s or less
	Sleep	20 s or less	20 s or less	30 s or less	30 s or less
Paper capacity	Cassette	550 sheets (64 g/m ²) 500 sheets (80 g/m ²)			
	MP tray	A4/Letter or less 165 sheets (64 g/m ²) 150 sheets (80 g/m ²) More than A4/Letter 55 sheets (64 g/m ²) 50 sheets (80 g/m ²)			
Output tray capacity	Inner tray	250 sheets (80 g/m ²)			
	with inner job separator	30 sheets (80 g/m ²)			
	with right job separator	70 sheets (80 g/m ²)			
Continuous copying		1 to 999 sheets			
Light source		LED			
Scanning system		Flat bed scanning by CCD image sensor			
Photoconductor		a-Si (drum diameter 30 mm)			
Image write system		Semiconductor laser			
Charging system		Charger roller			
Developing system		Touch down developing system Developer: 2-component Toner replenishing: Automatic from the toner container			
Transfer system		Primary: Transfer belt Secondary: Transfer roller			
Separation system		Small diameter separation, Separation electrode			
Cleaning system		Drum: Counter blade, Cleaning roller Transfer belt: Fur brush			
Charge erasing system		Exposure by cleaning lamp (LED)			
Fusing system		Belt fusing Heat source: IH Abnormally high temperature protection devices: thermostat			
CPU		PowerPC 750CL/600 MHz		PowerPC 750GL/750 MHz	
Main memory	Standard	2048 MB			
	Maximum	2048 MB			
Hard Disk		160 GB (standard)		320 GB (160 GB x 2) (standard)	

Item		Specifications			
		30 ppm	35 ppm	45 ppm	55 ppm
Interface	Standard	USB Interface Connector: 1 (Hi-Speed USB) USB Port: 2 (Hi-Speed USB) Network interface: 1 (10 BASE-T/100 BASE-TX/1000 BASE-T)			
	Option	Fax slot: 2 Network interface: 1 (10 BASE-T/100 BASE-TX/1000 BASE-T)			
Resolution		600 × 600 dpi			
Operating environment	Temperature	10 to 32.5 °C/50 to 90.5 °F			
	Humidity	15 to 80% RH			
	Altitude	2,500 m/8,202 ft or less			
	Brightness	1,500 lux or less			
Dimensions (W × D × H)	machine only	668 × 767 × 747 mm 26 5/16 × 30 3/16 × 29 3/8"			
	with paper feeder	668 × 767 × 1053 mm 26 5/16 × 30 3/16 × 41 7/16"			
Space required (W × D)		977 × 767 mm (using MP tray) 38 7/16 × 30 3/16" (using MP tray)			
Weight		114 kg / 251.3 lb			
Power source		120 V AC, 60 Hz, more than 12.0 A 220 - 240 V AC, 50/60 Hz, more than 7.2 A			
Options		Document processor, Original cover, Paper feeder, Large capacity feeder, Side deck, Side multi tray*, Side paper feeder*, Side large capacity feeder*, 1000-sheet finisher, 4000-sheet finisher, Center-folding unit, Mailbox, Punch unit, Inner job separator, Right job separator, Key counter, Fax kit, Expansion memory, Internet fax kit (A), Data security kit, Printed document guard kit, Emulation option kit, Gigabit ethernet board, Printing system, Document table, IC card reader holder, Keyboard holder and Duct unit *: 45 ppm/55 ppm model only			

Printer

Item	Specifications
Printing speed	Same as copying speed.
Resolution	600 x 600 dpi
Operating system	Windows XP, Windows Server 2003, Windows Vista, Windows 7, Windows Server 2008, Apple Macintosh OS 10.x
Interface	USB interface connector: 1 (USB Hi-speed) Network interface: 1 (10BASE-T/100BASE-TX/1000BASE-T)
Page description language	PRESCRIBE

Scanner

Item	Specifications			
	30 ppm	35 ppm	45 ppm	55 ppm
System requirements	CPU: 600 MHz or higher RAM: 128 MB or more			
Resolution	600 dpi, 400 dpi, 300 dpi, 200 dpi, 200 ×100 dpi, 200 × 400 dpi			
File format	TIFF, JPEG, XPS, PDF (MMR/JPEG compression), PDF (high compression)			
Scanning speed (A4 landscape, 300 dpi, Image quality: Text/Photo original)*1	Simplex	B/W : 70 images/min Color: 70 images/min		B/W : 80 images/min Color: 80 images/min
	Duplex	B/W : 100 images/min Color: 80 images/min		B/W : 140 images/min Color: 110 images/min
Interface	Ethernet (10 BASE-T/100 BASE-TX/1000 BASE-T)			
Network protocol	TCP/IP			
Transmission system	PC transmission SMB Scan to SMB FTP Scan to FTP, FTP over SSL E-mail transmission SNTP Scan to E-mail TWAIN scan*2 WIA scan*3			

*1 When using the dual scan document processor (except TWAIN and WIA scanning)

*2 Available operating system: Windows XP, Windows Server 2003, Windows Vista, Windows Server 2008, Windows 7

*3 Available operating system: Windows Vista, Windows 7, Windows Server 2008

NOTE: These specifications are subject to change without notice.

1-1-2 Parts names

(1) Machine




Figure 1-1-1

- | | |
|----------------------------------|-----------------------------------|
| 1. Original size indicator plate | 11. Handles |
| 2. Slit glass | 12. Release button |
| 3. Toner container K | 13. Waste toner box |
| 4. Toner container M | 14. Waste toner tray |
| 5. Toner container C | 15. Front cover |
| 6. Toner container Y | 16. Toner container release lever |
| 7. Platen (Contact glass) | 17. Network interface connector |
| 8. Clip holder | 18. USB port |
| 9. Operation panel | 19. USB interface connector |
| 10. Indicators | 20. Option interface |






Figure 1-1-2

- | | |
|---------------------------------|---------------------------------|
| 21. Inner tray | 31. Paper conveying unit lever |
| 22. Document processor (option) | 32. Duplex cover lever |
| 23. Original cover | 33. Duplex cover |
| 24. USB port | 34. MP paper width guide |
| 25. Cassettes | 35. MP support Tray |
| 26. Paper length guide | 36. MP (Multi-Purpose) tray |
| 27. Guide lock lever | 37. Paper conveying cover lever |
| 28. Paper width guide | 38. Paper conveying cover |
| 29. Paper width adjusting tab | 39. Handle |
| 30. Paper conveying unit | 40. Main power switch |

(2) Option**Figure 1-1-3**

- | | |
|--------------------------------------|-------------------------------|
| 1. Machine | 8. Side paper feeder |
| 2. Document processor (dual scan DP) | 9. Side large capacity feeder |
| 3. Document processor (reversed DP) | 10. 1000-sheet finisher |
| 4. Paper feeder | 11. 4000-sheet finisher |
| 5. Large capacity feeder | 12. Center-folding unit |
| 6. Side deck | 13. Mailbox |
| 7. Side multi tray | |

(3) Operation panel**Figure 1-1-4**

- | | | |
|------------------------------|--------------------------|-------------------------------|
| 1. Program key | 11. Power key | 21. Memory indicator |
| 2. Status/Job cancel key | 12. Counter key | 22. Numeric keys |
| 3. Copy key | 13. Main power indicator | 23. Enter key |
| 4. Accessibility display key | 14. Application key | 24. Attention indicator |
| 5. Help key | 15. Document box key | 25. Start key |
| 6. Auto color key | 16. Send key | 26. Stop key |
| 7. Quick no. search key | 17. FAX key* | 27. Interrupt key |
| 8. Clear key | 18. Full color key | 28. Authentication/Logout key |
| 9. Reset key | 19. Processing indicator | 29. Energy saver key |
| 10. System menu key | 20. Black and White key | |

*: Option

1-1-3 Machine cross section




Figure 1-1-5

- | | | |
|--------------------------------|-----------------------------|--|
| 1. Cassette paper feed section | 8. Drum unit C | 15. Primary transfer section |
| 2. MP tray paper feed section | 9. Drum unit Y | 16. Secondary transfer/Separation sections |
| 3. Paper conveying section | 10. Developer unit K | 17. Fuser section |
| 4. Optical section | 11. Developer unit M | 18. Eject/Feed shift sections |
| 5. Laser scanner unit | 12. Developer unit C | 19. Duplex section |
| 6. Drum unit K | 13. Developer unit Y | |
| 7. Drum unit M | 14. Toner container section | |

This page is intentionally left blank.

1-2-1 Installation environment

1. Temperature: 10 to 32.5°C/50 to 90.5°F
2. Humidity: 15 to 80% RH
3. Power supply: 120 V AC, 12.0 A
220 - 240 V AC, 7.2 A
4. Power source frequency: 50 Hz \pm 2%/60 Hz \pm 2%
5. Installation location

Avoid direct sunlight or bright lighting. Ensure that the photoconductor will not be exposed to direct sunlight or other strong light when removing paper jams.

Avoid locations subject to high temperature and high humidity or low temperature and low humidity; an abrupt change in the environmental temperature; and cool or hot, direct air.

Avoid places subject to dust and vibrations.

Choose a surface capable of supporting the weight of the machine.

Place the machine on a level surface (maximum allowance inclination: 1°).

Avoid air-borne substances that may adversely affect the machine or degrade the photoconductor, such as mercury, acidic or alkaline vapors, inorganic gasses, NOx, SOx gases and chlorine-based organic solvents.

Select a well-ventilated location.

6. Allow sufficient access for proper operation and maintenance of the machine.

Machine front : 100 cm/39 3/8"

Machine rear : 10 cm/ 3 15/16"

Machine right : 35 cm/13 3/4"

Machine left : 30 cm/11 13/16"

Machine top : 40 cm/15 3/4"





Figure 1-2-1

1-2-2 Unpacking and installation

(1) Installation procedure



Moving the machine

When moving the machine, pull out three carrying handles, and move with carrying handles and the handhold.




Figure 1-2-2

Unpacking




Figure 1-2-3

- | | |
|---------------------------|----------------------------|
| 1. Machine | 13. Machine cover |
| 2. Outer case | 14. Document tray |
| 3. Inner case | 15. Power cord |
| 4. Top pad | 16. Plastic bag |
| 5. Skid | 17. Paper size plates |
| 6. Bottom sheet | 18. Paper media plates |
| 7. Bottom pad | 19. Operation panel sheets |
| 8. Bottom front left pad | 20. Operation guide etc. |
| 9. Bottom front right pad | 21. Eject spacer |
| 10. Bottom rear left pad | 22. Waste toner box |
| 11. Bottom rear right pad | 23. Barcode label |
| 12. Rear pad | 24. Hinge joints |

Place the machine on a level surface.

Removing the eject spacer

1. Remove the eject spacer and silica gel from the eject section.




Figure 1-2-4

Removing the tapes

1. Remove the tape and then remove the ISU lock leaflet.
2. Remove three tapes and then remove two A3 papers.
3. Remove seven tapes and then remove three protect sheets.




Figure 1-2-5

4. Remove eight tapes.




Figure 1-2-6

Installing the paper feeder (option)

1. Install the optional paper feeder or large capacity feeder as necessary.
2. Verify levelness at the four corners of the contact glass using a level gauge, and adjust the level bolts at the bottom of the machine to optimize levelness.

Release the lock of the scanner mirror frame

1. Remove the scanner lock cover.
2. Mount the scanner lock cover in the reverse manner to restore in the original location.

*: Unless unlocking is performed, C3100 is caused.





Figure 1-2-7

Release of lift plate stopper

1. Pull cassette 1 and 2 out.
 2. Remove the lift plate stopper from each cassette and attach it to the storage location.
- When moving the machine, attach the lift plate in original position.




Figure 1-2-8

Loading paper

1. Squeeze the ends of the bottom of the paper length guide and move the guide to fit the length of the paper.




Figure 1-2-9

2. Press the guide lock lever to release the lock.
3. Grasp the paper width adjusting tab and move the paper width guides to fit the paper.




Figure 1-2-10

4. Align the paper flush against the right side of the cassette.
 - *: Before loading the paper, be sure that it is not curled or folded.
 - *: Ensure that the loaded paper does not exceed the level indicated.
 - *: Make sure that the paper length guide and the paper width guides are correctly abut with the paper. Be sure to remove spaces between the guides and the paper.




Figure 1-2-11

5. Press the guide lock lever to lock.




Figure 1-2-12

- 6. Insert the paper size plate and the paper media plate.
- 7. Gently push the cassette back in.




Figure 1-2-13

Installing the toner containers

1. Open the front cover.
2. Hold the toner container vertically and hit the upper part about 3 times. Invert the toner container so that the other end is up, and hit in the same way.
3. Hold the toner container horizontally and shake from side to side about 3 times.




Figure 1-2-14

4. Install four color toner containers.
5. Turn down the toner container release levers to lock the four color toner containers.




Figure 1-2-15

Unlocking the developer waste exit

Caution

To ease setup, the device was shipped with the developer unit already replenished with developer. Therefore, to prevent developer from spilling during shipping, a developer shutter is equipped with the developer unit.

To disengage the shutter, use the following procedure: Note that if the shutter is not completely disengaged and retained in place, the developer in the developer unit may clog at the outlet causing a damage to the developer unit.

1. Remove the tape and then remove the set up leaflet.
- *: The setup leaflet must be affixed in position before dispatching the machine.
2. Press the fixing pin in four positions and rotate.
- *: Fully insert the fixing pin keeping the line vertical and rotate by 90 degrees clockwise. Make sure that the central line is horizontal.




Figure 1-2-16

3. Remove a screw and slide the lever right wards.
 4. Fix the lever using the screw previously removed at the right screw hole and unlock the developer waste exit.
- *: When the device is shipped again or removed, use the reverse procedure to lock in the developer waste exit. Failure to observe this caution could result in deteriorated print quality and/or C calls.





Figure 1-2-17

Installing the waste toner box

Caution

Before installing the waste toner box, unlock the developer waste exit (see page 1-2-12).

1. Push the release button and pull out the waste toner tray.
2. Open the lid and install the waste toner box.
3. Push the waste toner tray back in.
4. Close the front cover.







Figure 1-2-18

Replacing operation panel sheet

1. Insert a flat-head screwdriver and slide the operation panel covers A and B to remove them.

**Figure 1-2-19**

2. Remove the clear panel.

**Figure 1-2-20**

3. Remove the operation panel sheet.
4. Replace the operation panel sheet of the corresponding language.
5. Refit the clear panel.
6. Refit the operation panel covers A and B.




Figure 1-2-21

Installing the original platen or DP (option)

1. Install optional original platen or DP.

Installing other optional devices

1. Install the optional devices (job separator, document finisher and/or fax kit etc.) as necessary.

Installing the cassette heater (option)

1. Install the optional cassette heater as necessary (see page 1-2-65).

Connect the power cord

1. Connect the power cord to the power cord connector on rear lower of the machine.
2. Connect the power plug to the wall outlet.

Adjusting the image

1. Turn the main power switch on.
2. **Check the messages on the operation panel**
 After completion of warming up, in case to display "Warning for high temperature. Adjust the room temperature." on the operation panel, follow the step 3. (Performing Drum Refresh)
 In case to display "Warning for low temperature. Adjust the room temperature." on the operation panel, install the machine in the other location this message won't be shown.
 Installing the machine in a low temperature environment could cause image quality problems.
 In case to have no display, follow the step 4 (Performing LSU cleaning).
 *: Perform the high altitude settings when a leakage is developed on images in a high altitude installation, such as in Mexico City.
 U140 - AC Calb - High Altitude - Mode 2
3. **Performing drum refresh (see the operation guide)**
 Press the System menu key.
 Press [Adjustment/Maintenance] and then [Next] of [Drum Refresh].
 Press [Execute] to perform drum refresh. When completed, press [OK].
4. **Performing LSU cleaning (see the operation guide)**
 Press [Adjustment/Maintenance] and then [Next] of [Laser Scanner Cleaning].
 Press [Execute] to perform LSU cleaning. When completed, press [OK].
5. **Performing calibration**
(see the operation guide,U464 Setting the ID correction operation - performing calibration)
 Press [Adjustment/Maintenance] and then [Next] of [Calibration].
 Press [Execute] to perform Color calibration. When completed, press [OK].
6. **Performing color registration (see the operation guide,U469 Adjusting the color registration)**
 Press [Adjustment/Maintenance] and then [Next] of [Color Registration].
 Perform adjustments automatically or manually.
Auto correction
 Press [Next] in [Auto]. Press [Start]. A chart is printed.
 Set the output chart for adjustment as the original.
 Press [Start] to perform Color registration. When completed, press [OK].
Manual correction
 Press [Next] in [Manual]. Press [Print] of [Chart]. A chart is printed.
 Find the location on each chart where 2 lines most closely match.
 Press [Next] of [Registration] and [Change].
 Enter the registration values for each chart.
 Press [Start] to perform Color registration. When completed, press [OK].
7. **Adjusting the halftone automatically (see page 1-3-158)**
 Load the cassette with multiple sheets of A4 or Letter paper.
 Enter the maintenance mode by entering 10871087 using the numeric keys.
 Enter 410 using the numeric keys and press the start key.
 Press [Normal Mode] and then press the start key. A test patterns 1, 2 and 3 are outputted.
 Place the output test pattern 1 as the original.
 Place approximately 20 sheets of white paper on the test pattern 1 and set them.
 Press the start key. Adjustment is made.
 Place the output test pattern 2 as the original.

Place approximately 20 sheets of white paper on the test pattern 2 and set them.
 Press the start key. Adjustment is made.
 Place the output test pattern 3 as the original.
 Place approximately 20 sheets of white paper on the test pattern 2 and set them.
 Press the start key. Adjustment is made.
 [Finish] is displayed in [Phase] when normally completed.
 Press the stop key twice to exit.

8. Make test copies.

If image quality is unsatisfactory after test copying, execute calibration, then retry U410-Adjusting the halftone automatically.
 If paper is fed skewed, perform the adjustment of skewed paper in the cassette (see page 1-5-105).

Setting the delivery date (maintenance item U278)

1. Enter the maintenance mode by entering 10871087 using the numeric keys.
2. Enter 278 using the numeric keys and press the start key.
3. Select [Today].
4. Press the start key. The delivery date is set.
5. Press the stop key to exit.

Output an own-status report (maintenance item U000)

1. Enter 000 using the numeric keys and press the start key.
 2. Select [Maintenance] and press the start key. A status report is output.
 3. Press the stop key to exit.
- *: If paper is fed skewed, perform the adjustment of skewed paper in the cassette (see page 1-5-122).

Exit maintenance mode

1. Enter 001 using the numeric keys and press the start key. The machine exits the maintenance mode.

Print out the user setting list

1. Select [Report Print] to output the user various setting reports.

Completion of the machine installation


(2) Setting initial copy modes

Factory settings are as follows:

Maintenance item No.	Contents	Factory setting
U253	Switching between double and single counts	DBL(A3/Ledger)
U260	Selecting the timing for copy counting	Eject
U276	Setting the copy count mode	Mode0
U284	Setting 2 color copy mode	Off
U285	Setting service status page	On
U323	Setting abnormal temperature and humidity warning	On
U325	Setting the paper interval	Off/1
U326	Setting the black line cleaning indication	On/8
U327	Setting the cassette heater control	Off
U343	Switching between duplex/simplex copy mode	Off

1-2-3 Installing the key counter (option)

(1) Installing directly on the device



Key counter installation requires the following parts:

Parts	Quantity	Part.No.
Key counter	1	3025418011
Key counter set	1	302A369709
Key counter wire	1	302K946AJ0
M4 nut	2	3CY06030

*: Not used in 120V model.


Supplied parts of key counter set (302A369709):

Parts	Quantity	Part.No.
Key counter socket assembly	1	3029236241
Key counter cover retainer	1	302GR03010
Key counter retainer	1	302GR03020
Key counter cover	1	3066060011
Key counter mount	1	3066060041
Edging	2*	7YZM210006++H01
Band	1*	M21AH010
M3 x 8 tap-tight P screw	1*	5MBTPB3008PW++R
M4 x 10 tap-tight P screw	2*	5MBTPB4010PW++R
M4 x 10 tap-tight S screw	2*	5MBTPB4010TW++R
M3 x 6 bronze flat-head screw	2	7BB003306H
M4 x 20 tap-tight S screw	2	7BB100420H
M3 nut	1	7BC1003055++H01
M3 x 8 bronze binding screw	1*	B1B03080
M4 x 30 tap-tight S screw	1*	B1B54300
M4 x 6 chrome TP screw	5	B4A04060
M4 x 10 chrome TP screw	2*	B4A04100


*: Not used in this model.

Procedure

1. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Fit the key counter socket assembly to the key counter retainer using two screws and nut.
3. Fit the key counter mount to the key counter cover using two screws.
4. Fit the key counter retainer to the key counter mount using two screws.

**Figure 1-2-22**

- *: For the 120V model, proceed to step 26.
5. Pull the paper conveying unit out.
 6. Remove two screws and then remove the ISU right cover.
 7. Remove the screw and five hooks and then remove the right upper cover.

**Figure 1-2-23**

- Cut out the aperture plate on the right upper cover using nippers.




Figure 1-2-24

- Remove seven screws and then remove the rear upper cover.





Figure 1-2-25

10. Release six wire saddles on the controller box.
11. Remove the wire holder.

**Figure 1-2-26**

12. Remove the following connectors that connected to the main PWB from the outside of the control box.

- YC25
- YC11
- YC30
- YC24
- YC3 (FFC connector with a lock)
- YC17 (BK)
- YC21 (WH)
- YC12

*: When removing the FFC from the FFC connector with a lock, remove the FFC after released by lifting down the lock lever (see figure a).

*: When connecting an FFC furnished with the protrusions at both ends, address the side with a blue-colored tape towards the locking lever, insert the FFC into the connector until the protrusions are recessed, and raise the lock lever to lock the FFC (see figure b).






Figure 1-2-27

13. Remove five screws.
14. Unhook two hooks and then remove the controller box.




Figure 1-2-28

15. Connect the connector of the key counter wire to the connector YC24 on the engine PWB.




Figure 1-2-29

16. Remove two wire holders.
17. Route the key counter wire through the wire guide and fix it at the wire holders.




Figure 1-2-30

18. Release three wire saddles.
19. Remove the wire holder.
20. Route the key counter wire through the three wire saddles and wire guide and fix it at the wire holder.
21. Refit the controller box.
22. Refit the left upper cover and the rear upper cover.




Figure 1-2-31

23. Mount two M4 nuts at the back of the right upper cover.




Figure 1-2-32

24. Insert the projection of the key counter cover retainer in the aperture of the right upper cover.
25. Fit the key counter cover retainer using the two M4 x 20 screws.




Figure 1-2-33

26. Pass the connector of the key counter wire through the aperture in the right upper cover.
27. Refit the right upper cover.
28. Refit the ISU right cover.
29. Close the paper conveying unit.




Figure 1-2-34

30. Connect the key counter signal cable to the key counter wire.
31. Fit the key counter cover to the machine using the M4 x 6 screw.

32. Insert the key counter into the key counter socket assembly.
33. Turn the main power switch on and enter the maintenance mode.
34. Run maintenance item U204 and select [Key-Counter] (see page 1-3-111).
35. Exit the maintenance mode.
36. Check that the message requesting the key counter to be inserted is displayed on the touch panel when the key counter is pulled out.
37. Check that the counter counts up as copies are made.





Figure 1-2-35

(2) Mounting on the document table

Key counter installation requires the following parts:

Parts	Quantity	Part.No.
Key counter	1	3025418011
Key counter set	1	302A369709
Key counter wire	1	302K946AJ0
Document table	1	1902H70UN1 (option)

Supplied parts of key counter set (302A369709):

Parts	Quantity	Part.No.
Key counter socket assembly	1	3029236241
Key counter cover retainer	1	302GR03010
Key counter retainer	1	302GR03020
Key counter cover	1	3066060011
Key counter mount	1	3066060041
Edging	2*	7YZM210006++H01
Band	1*	M21AH010
M3 x 8 tap-tight P screw	1*	5MBTPB3008PW++R
M4 x 10 tap-tight P screw	2*	5MBTPB4010PW++R
M4 x 10 tap-tight S screw	2*	5MBTPB4010TW++R
M3 x 6 bronze flat-head screw	2	7BB003306H
M4 x 20 tap-tight S screw	2	7BB100420H
M3 nut	1	7BC1003055++H01
M3 x 8 bronze binding screw	1*	B1B03080
M4 x 30 tap-tight S screw	1*	B1B54300
M4 x 6 chrome TP screw	5	B4A04060
M4 x 10 chrome TP screw	2*	B4A04100

*: Not used in this model.


Supplied parts of document table (1902H70UN1):

Parts	Quantity	Part.No.
Tray stay	1	-
Tray mount	1	-
Tray cover	1	302LC04600
Tray lower cover	1	302LC04710
Tray retainer	1	-
Sheet	2*	302LC04660
Pin	2	303NS24410
M4 nut	2	3CY06030
M4 x 8 screw	7	7BB180408H
M4 x 14 screw	2	7BB607414H

*: Sheet x1 is not used.

Procedure

1. Perform steps 1 through 25 as explained in (1) Installing directly on the device.
2. Mount two M4 nuts at the back of the right upper cover.
3. Fit the tray stay to the right upper cover using two M4 x 14 screws.



*: Secure the screws making sure that the nuts do not fall.




Figure 1-2-36

4. Fit the tray retainer to the machine using the M4 x 8 screw.
- *: The procedure described above is not required if an optional right job separator has been installed.




Figure 1-2-37

5. Pass the connector of the key counter wire through the aperture in the right upper cover.
6. Refit the right upper cover.
7. Refit the ISU right cover.
8. Close the paper conveying unit.




Figure 1-2-38

9. Snap in the tray mount to the tray stay and fix using two M4 x 8 screws.





Figure 1-2-39

10. Cut out the aperture plate on the tray cover using nippers.
11. Fit the tray cover to the tray stay using four M4 x 8 screws.




Figure 1-2-40

12. Fit the key counter cover retainer using two M4 x 20 tap-tight S screws.





Figure 1-2-41

13. Pass the key counter signal cable through the aperture in the document table.
14. Fit the key counter cover to the document table using the M4 x 6 screw.
15. Connect the key counter signal cable to the key counter wire.

**Figure 1-2-42**

16. Fit the tray lower cover.
Install the key counter signal cable and key counter wire so that they are held behind the tray lower cover.




Figure 1-2-43

17. Secure the tray lower cover with two pins.




Figure 1-2-44

18. Adhere the sheet onto right side of the document table.
19. Insert the key counter into the key counter socket assembly.
20. Turn the main power switch on and enter the maintenance mode.
21. Run maintenance item U204 and select [Key-Counter] (see page 1-3-111).
22. Exit the maintenance mode.
23. Check that the message requesting the key counter to be inserted is displayed on the touch panel when the key counter is pulled out.
24. Check that the counter counts up as copies are made.




Figure 1-2-45

1-2-4 Installing the key card MK-2 (option for japan only)

Key card installation requires the following parts:

Parts	Quantity	Part.No.
Key card MK-2	1	8J272002 (option)
MK-2 mount	1	Supplied with MK-2
M4 x 16 screw	2*	
Document table	1	1902H70UN1 (option)
M4 x 20 tap-tight S screw	2	7BB100420H

*:Not used in this model.

Supplied parts of document table (1902H70UN1):


Parts	Quantity	Part.No.
Tray stay	1	-
Tray mount	1	-
Tray cover	1	302LC04600
Tray lower cover	1	302LC04710
Tray retainer	1*1	-
Sheet	2*2	302LC04660
Pin	2	303NS24410
M4 nut	2	3CY06030
M4 x 8 screw	7	7BB180408H
M4 x 14 screw	2	7BB607414H

*1: Not used in this model.


*2: Sheet x1 is not used.

Procedure


1. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Pull the paper conveying unit out.
3. Remove two screws and then remove the ISU right cover.
4. Remove the screw and five hooks and then remove the right upper cover.

**Figure 1-2-46**

5. Remove seven screws and then remove the rear upper cover.

**Figure 1-2-47**

6. Release six wire saddles on the controller box.
7. Remove the wire holder.



**Figure 1-2-48**

8. Remove the following connectors that connected to the main PWB from the outside of the control box.

- YC25
- YC11
- YC30
- YC24
- YC3 (FFC connector with a lock)
- YC17 (BK)
- YC21 (WH)
- YC12

*: When removing the FFC from the FFC connector with a lock, remove the FFC after released by lifting down the lock lever (see figure a).

*: When connecting an FFC furnished with the protrusions at both ends, address the side with a blue-colored tape towards the locking lever, insert the FFC into the connector until the protrusions are recessed, and raise the lock lever to lock the FFC (see figure b).



Main PWB

▨ FFC connector with a lock






Figure 1-2-49


9. Remove five screws.
10. Unhook two hooks and then remove the controller box.

**Figure 1-2-50**

11. Cut out the aperture plate on the right upper cover using nippers.

**Figure 1-2-51**

12. Mount two M4 nuts at the back of the right upper cover.
13. Fit the tray stay to the right upper cover using two M4 x 14 screws.



*: Secure the screws making sure that the nuts do not fall.




Figure 1-2-52

14. Snap in the tray mount to the tray stay and fix using two M4 x 8 screws.





Figure 1-2-53

15. Cut out the aperture plate on the tray cover using nippers.




Figure 1-2-54

16. Pass the MK-2 signal cable through the aperture in the tray cover, tray stay and right upper cover.





Figure 1-2-55

17. Connect the connector of the MK-2 signal cable to the connector YC25 on the engine PWB.
18. Remove the screw from the machine.
19. Fix the MK-2 signal cable to the ground terminal with the screw that was removed.

**Figure 1-2-56**

20. Remove three wire holders.
21. Route the MK-2 signal cable through the wire guide and fix it at three wire holders.
- *: Dress the MK-2 signal wire away from the scanner motor and fix.
22. Refit the controller box.
23. Refit the left upper cover and the rear upper cover.






Figure 1-2-57

24. Fit the tray retainer to the machine using the M4 x 8 screw.
- *: The procedure described above is not required if an optional right job separator has been installed.




Figure 1-2-58

25. Refit the right upper cover.
26. Refit the ISU right cover.
27. Close the paper conveying unit.
28. Fit the tray cover to the tray stay using four M4 x 8 screws.




Figure 1-2-59

29. Remove the four screws securing the MK-2 cover; attach the MK-2 mount to the MK-2, and secure using the four screws.




Figure 1-2-60

30. Fit the MK-2 to the document table using two M4 x 20 tap-tight S screws.






Figure 1-2-61

31. Fit the tray lower cover.
32. Secure the tray lower cover with two pins.

**Figure 1-2-62**

33. Adhere the sheet onto right side of the document table.
34. Turn the main power switch on and enter the maintenance mode.
35. Run maintenance item U204 and select [Key-Card] (see page 1-3-111).
36. Exit the maintenance mode.

**Figure 1-2-63**

1-2-5 Installing the KMAS (option for japan only)

KMAS installation requires the following parts:

Using the PHS module

Parts	Quantity	Part.No.
PHS module	1	HM000080 (option)
PHS signal cable	1	023CK200 (option)
KMAS interface PWB	1	023CK000 (option)
M3 x 16 bronze binding screw	2	B3323160
Ferrite core	1	2A027770
Clamp	1	M2105910
KMAS wire set	1	302K994610

Supplied parts of KMAS wire set (302K994610):


Parts	Quantity	Part.No.
KMAS wire	1	302K946AG0
Spacer A	1	7YZM510009++H01
Spacer B	3	7YZM510011++H01

Using a modem

Parts	Quantity	Part.No.
RS-232C signal cable	1	303CK60011
RS-232C relay cable	1	303CK60041
KMAS interface PWB	1	023CK000 (option)


Procedure

To fix KMAS, perform the following procedure:



Setting the DIP switch


1. Configure DIP switches 1 to 4 on the KMAS interface board as follows:

**Figure 1-2-64**


DIP SW No.	Description	Remarks
1	PHS module/modem switching ON: Use modem OFF: Use PHS module	
2	Modem outgoing switching ON: Pulse OFF: Tone	This is required when modem is used.
3	Communication speed switching with the device ON: 9600bps OFF: 19200bps	Set to OFF.
4	Communication log when automatically notifying service calls Switching messages ON: Message is fixed OFF: Normal message is used	When ON, the message is "Call a service representative." When OFF, the message will vary depending on communication status. To setup the system with automatic accounting only, ON may be set.

Fitting the KMAS interface PWB

2. Remove seven screws and then remove the rear upper cover.

**Figure 1-2-65**

3. Attach one spacer A and three spacers B to the side of the controller box.

**Figure 1-2-66**

4. Insert the KMAS interface PWB to three spacers B.




Figure 1-2-67

5. Remove YC7 and YC23 on the main PWB and connector of the controller fan motor. Remove the relay wire.






Figure 1-2-68

6. Connect the connector of the KMAS wire to the connector YC1 on the KMAS PWB.
7. Connect the connector of the KMAS wire to controller fan motor, YC7 and YC23 on the main PWB.

**Figure 1-2-69**

8. Pass the KMAS wire through the edging of the controller box and wire saddle and then fasten the KMAS wire.




Figure 1-2-70

Fitting the PHS signal cable and PHS module

9. Remove two screws and then remove the lid from the rear upper cover.
10. Pass the PHS signal cable through the aperture in the rear upper cover.
11. Secure the PHS signal cable to rear upper cover with two screws.




Figure 1-2-71

12. Connect the connector of the PHS signal cable to the connector YC2 on the KMAS interface PWB.
13. Refit the rear upper cover.




Figure 1-2-72

14. Fit the PHS module to rear upper cover using two M3 x 16 screws.




Figure 1-2-73

15. Wrap the PHS signal cable around the ferrite core a turn.
16. Connect the connector of the PHS signal cable to PHS module.
17. Fit the clamp to PHS signal cable.
18. After using alcohol to clean the rear upper cover, adhere the clamp to rear upper cover.




Figure 1-2-74

Fitting the RS-232C signal cable

1. By referring to the instructions given to fix the PHS signal wire, insert the connector at the end of the RS-232C relay cable to the YC3 connector on the KMAS interface PWB.
If the wire length is short, use a RS-232C extension cable.
2. Connect the RS-232C signal cable to the modem.

Initializing the KMAS

1. Turn the main power switch on and enter the maintenance mode.
2. Run maintenance item U202 and Performs [Init/Set TEL No.] (see page 1-3-109).
3. Exit the maintenance mode.

1-2-6 Installing the coin vender (option for japan only)

Coin vender installation requires the following parts:

Parts	Quantity	Part.No.
Coin vender	1	1905H99JP0 (option)
Vender wire	1	Supplied with coin vender
Vender base	1	
M4 x 6 screw	4	
Ferrite core	1	
Clamp	1	
Vender signal cable	1	302K946AE0

Procedure

1. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Fit the vender base to coin vender using four M4 x 6 screws.




Figure 1-2-75

3. Remove seven screws and then remove the rear upper cover.




Figure 1-2-76

4. Remove eight screws.
5. Release two hanging parts and then remove the rear lower cover.




Figure 1-2-77

- Remove two screws and then remove the lid.




Figure 1-2-78

- Connect the connector of the vender signal cable to the connector YC23 on the engine PWB.
- Pass the vender signal cable through the wire guide and ten wire saddles and then fasten the cable.




Figure 1-2-79

9. Pass the vender wire through the aperture in the IF mount.
10. Secure the vender wire with two screws removed in step 6.
11. Secure the ground terminal of the vender wire to rear frame with the screw.
12. Connect the connector of the vender wire to connector of the vender signal cable.




Figure 1-2-80

13. Refit the rear lower and upper covers.
14. Connect the signal cable of coin vender to connector of the vender wire.




Figure 1-2-81

15. Fit the ferrite core to signal cable of coin vender.
16. Fit the clamp to signal cable of coin vender.
17. Remove a screw from the coin vender and fix the coin vender with a clamp.




Figure 1-2-82

18. Affix the price size decal at the right side of the coin vender operation panel.




Figure 1-2-83

19. Turn the main power switch on and enter the maintenance mode.
20. Run maintenance mode U206 and activate 'Coin vender is installed.' Continue configuring the coin vender required (see page 1-3-112).
21. Exit the maintenance mode.

1-2-7 Installing the cassette heater (option)

Cassette heater installation requires the following parts:

Parts	Quantity	Part.No.
Cassette heater set (120V)	1	302K994931
Cassette heater set (240V)	1	302K994941

Supplied parts of cassette heater set (302K994931):


Parts	Quantity	Part.No.
Cassette heater (120V)	1	302H794620
Wire saddle	3	7YZM610001++H01
Connector cover	1	303NF04140
Label/ caution	1	302KP34220
M3 x 8 tap-tight S screw	2	7BB700308H
M4 x 8 tap-tight S screw	1	7BB700408H

Supplied parts of cassette heater set (302K994941):


Parts	Quantity	Part.No.
Cassette heater (240V)	1	302H794610
Wire saddle	3	7YZM610001++H01
Connector cover	1	303NF04140
Label/ caution	1	302KP34220
M3 x 8 tap-tight S screw	2	7BB700308H
M4 x 8 tap-tight S screw	1	7BB700408H

Procedure

1. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Pull the cassette 1 forward.
3. Draw out Cassette 1 by releasing the release lever.

**Figure 1-2-84**

4. Pull the cassette 2 forward.
5. Draw out Cassette 2 by releasing the release lever.

**Figure 1-2-85**

6. Fit three wire saddles on the bottom frame of the machine.
7. Fit the cassette heater using two M3 x 8 screws.




Figure 1-2-86

8. Pass the wire of the cassette heater through three wire saddles and then fasten the wire.
- *: Route the wire so that it do not disturb opening and closing the cassettes.
9. Connect the connector of the cassette heater to the connector in the rear frame of the machine.




Figure 1-2-87

10. Insert two hooks of the connector cover to the holes of base of the machine each.
11. Install the connector cover by using a M4 x 8 screw.




Figure 1-2-88

12. Adhere the caution label after wiping the bottom frame of this side of cassette heater with alcohol.




Figure 1-2-89

13. To install Cassette 1 and Cassette 2, align the cassette slider 2 and cassette slider 1 with each other.
14. Push the cassette in fully.




Figure 1-2-90

1-2-8 Installing the gigabit ethernet board (option)

Gigabit ethernet board installation requires the following parts:

Parts	Quantity	Part.No.
Gigabit ethernet board	1	1505JV0UN0 (option)

Procedure

1. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Open the controller lid.
3. Remove two pins and then remove the slot cover of the OPT2.




Figure 1-2-91

4. Insert the gigabit ethernet board along the groove in OPT2 and secure the board with two pins that have been removed in step 3.
- *: Do not directly touch the gigabit ethernet board terminal.
Hold the top and bottom of the gigabit ethernet board, or the projection of the board to insert the gigabit ethernet board.




Figure 1-2-92

5. Plug the network cable into the line terminal,
6. Close the controller lid.




Figure 1-2-93

1-2-9 Installing the IC card reader holder (option)

IC card reader holder installation requires the following parts:

Parts	Quantity	Part.No.
IC card reader holder	1	1709AD0UN0 (option)

Supplied parts of IC card reader holder (1709AD0UN0):

Parts	Quantity	Part.No.
Card reader case	1	-
Card reader base	1	-
Card reader mount	1	-
Card reader tray	1	-
USB Wire (For extension)	1	-
Pin	3	303NS24410
Clamp	6	7YZM690002++H01

The card reader base, card reader mount, and the pin are packaged as an assembled kit.

Procedure

1. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Remove the pin of the card reader base and then remove the card reader mount.






Figure 1-2-94

3. Remove the cover next to the operation panel using a flat-blade screwdriver.
4. Fit the card reader mount to the machine using two pins.

**Figure 1-2-95**

5. Refit the card reader base to card reader mount using the pin removed in step 2.

**Figure 1-2-96**

6. Fit the card reader tray to the card reader base.
 Choose the direction of mounting the IC card reader according to the depth of the reader.
 10mm to 22mm: Face the mark A upwards.
 Less than 10mm: Face the mark B upwards.





Figure 1-2-97

7. Route the USB wire of the IC card reader through the aperture of the card reader base and mount the IC card reader on the card reader base.




Figure 1-2-98

8. Hook the two hooks of the card reader case to fit the card reader case to the card reader base.
Press its top until it clicks in.





Figure 1-2-99

9. Fit six clamps.
Right side: three
Rear side: three




Figure 1-2-100

10. Cut out the breakaway cover on the controller lid using nippers.




Figure 1-2-101

11. Pass the USB wire of the IC card reader through six clamps and then fasten the wire.
12. Connect the USB wire to the machine. If the length does not suffice, use the USB wire supplied.




Figure 1-2-102

Enabling IC Card Authentication

Precautions

To install the optional function, you need the License Key. Please access the designated website of your dealer or service representative, and register "Machine No." indicated on your machine and "Product ID" indicated on the License Certificate supplied with the product to issue the License Key.

1. Turn the main power switch on.
2. Press the System Menu key and then press [System].
If user login administration is disabled, the user authentication screen appears.
Enter your login user name and password and then press [Login]. For this, you need to log in with administrator privileges.
3. Press [Next] of Optional Function.
4. Select CARD AUTHENTICATION KIT(B) and press [Activate].
5. The License Key entry screen is displayed.
Enter the License Key using the numeric keys and press [Official].
6. Confirm the product name CARD AUTHENTICATION KIT(B) and press [Yes].
7. To use a SSFC card, run maintenance mode U222 and set SSFC.

1-2-10 Installing the keyboard holder (option)

Keyboard holder installation requires the following parts:

Parts	Quantity	Part.No.
Keyboard holder	1	1709AF0UN0 (option)

Supplied parts of keyboard holder (1709AF0UN0):

Parts	Quantity	Part.No.
Upper keyboard holder	1	-
Lower keyboard holder	1	-
Keyboard cover	1	-
Velcro A	2	-
Velcro B	2	-
Film	1*1	-
M4 x 8 tap-tight S screw	2	-
M4 x 8 tap-tight P screw	3	-
M3 x 8 tap-tight S screw	2*1	-
Clamp	6*2	7YZM690002++H01

*1: Not used in this model.

*2: Clamp x1 is not used.

Procedure

1. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Remove the staple holder and then remove two screws.






Figure 1-2-103

3. Fit the lower keyboard mount to the machine using two screws removed in step 2.

**Figure 1-2-104**

4. Fit the upper keyboard mount to the lower keyboard mount using two M4 x 8 tap-tight S screws.

**Figure 1-2-105**

5. Latch the keyboard cover with the upper keyboard mount by the five hooks.
6. Fit the keyboard cover to the upper keyboard mount using three M4 x 8 tap-tight P screws.




Figure 1-2-106

7. Adhere two Velcro tapes onto the upper keyboard mount.




Figure 1-2-107

8. Adhere two Velcro tapes onto back side of the keyboard.






Figure 1-2-108

- Align the Velcro tapes with each other, mount the keyboard onto the upper keyboard mount.

**Figure 1-2-109**

- Fit the staple cover.

**Figure 1-2-110**

11. Cut out the breakaway cover on the controller lid using nippers.




Figure 1-2-111

12. Fit five clamps.
Left side: three
Rear side: two




Figure 1-2-112

13. Pass the USB wire of the keyboard through five clamps and then fasten the wire.
14. Connect the USB wire to the machine.




Figure 1-2-113

1-2-11 Installing the duct unit (option)

Duct unit installation requires the following parts:

Parts	Quantity	Part.No.
Duct unit	1	302LC94530

Supplied parts of duct unit (302LC94530):

Parts	Quantity	Part.No.
Duct A	1	-
Duct B	1	-
Filter	2	-
M3 x 8 tap-tight P screw	2	7BB200308H
M3 x 8 tap-tight P screw (black)	1	7BB282308H
M3 x 8 tap-tight S screw (black)	2	7BB782308H

Procedure

1. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Fit duct B to duct A using two M3 x 8 tap-tight P screws.




Figure 1-2-114

3. Fit two filters to duct A.




Figure 1-2-115

4. Remove the screw A from the rear lower cover.




Figure 1-2-116

5. Fit the duct unit to the machine using the removed screw A, M3 x 8 tap-tight P screw (black) and two M3 x 8 tap-tight S screws (black).





Figure 1-2-117

1-2-12 Installing the handset (option for japan only)

(1) Installing directly on the device



Handset installation requires the following parts:


Parts	Quantity	Part.No.
Handset	1	1909AG9JP0 (option)

Supplied parts of handset (1909AG9JP0):



Parts	Quantity	Part.No.
Handset	1	-
Handset base	1	-
Handset mount	1	-
Protection cover	1	-
Pin	2	-
Telephone wire	1	-
Modular cable	1	-
M4 nut	2	3CY06030

Procedure

1. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Pull the paper conveying unit out.
3. Remove two screws and then remove the ISU right cover.
4. Remove the screw and five hooks and then remove the right upper cover.

**Figure 1-2-118**

5. Mount two M4 nuts at the back of the right upper cover.
6. Fit the handset mount to the right upper cover using two pins. Use the lower screw holes.



*: Secure the screws making sure that the nuts do not fall.




Figure 1-2-119

7. Refit the right upper cover.
8. Refit the ISU right cover.
9. Close the paper conveying unit.
10. Remove two nuts and two pins from the handset mount and remount it at mark B.




Figure 1-2-120

11. Insert the pins at the insert parts on the back of the handset base, and slide it towards you.




Figure 1-2-121

- 12. Fit the protection cover to the handset mount.




Figure 1-2-122

- 13. Connect the telephone wire to the handset and the handset base.




Figure 1-2-123

14. Connect the modular cable to the handset base and the machine.






Figure 1-2-124

(2) Mounting on the document table

Handset installation requires the following parts:

Parts	Quantity	Part.No.
Handset	1	1909AG9JP0 (option)
Document table	1	1902H70UN2 (option)

Supplied parts of handset (1909AG9JP0):

Parts	Quantity	Part.No.
Handset	1	-
Handset base	1	-
Handset mount	1*	-
Protection cover	1	-
Pin	2	-
Telephone wire	1	-
Modular cable	1	-
M4 nut	2*	3CY06030

*: Not used in this model.


Supplied parts of document table (1902H70UN1):

Parts	Quantity	Part.No.
Tray stay	1	-
Tray mount	1	-
Tray cover	1	302LC04601
Tray lower cover	1	302LC04710
Tray retainer	1	-
Sheet	2*	302LC04660
Pin	2	303NS24410
M4 nut	2	3CY06030
M4 x 8 screw	7	7BB180408H
M4 x 14 screw	2	7BB607414H


*: Sheet x1 is not used.

Procedure

1. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Pull the paper conveying unit out.
3. Remove two screws and then remove the ISU right cover.
4. Remove the screw and five hooks and then remove the right upper cover.

**Figure 1-2-125**

5. Mount two M4 nuts at the back of the right upper cover.
6. Fit the tray stay to the right upper cover using two M4 x 14 screws.



*: Secure the screws making sure that the nuts do not fall.





Figure 1-2-126

7. Fit the tray retainer to the machine using the M4 x 8 screw.
- *: The procedure described above is not required if an optional right job separator has been installed.
8. Refit the right upper cover.
 9. Refit the ISU right cover.
 10. Close the paper conveying unit.

**Figure 1-2-127**

11. Snap in the tray mount to the tray stay and fix using two M4 x 8 screws.





Figure 1-2-128

12. Fit the tray cover to the tray stay using four M4 x 8 screws.




Figure 1-2-129

13. Remove two nuts and two pins from the handset mount.
14. Replace the two nuts and two pins which were removed at mark A on the tray mount.




Figure 1-2-130

15. Insert the pins at the insert parts on the back of the handset base, and slide it towards you.




Figure 1-2-131

16. Cut out the breakaway cover on the tray lower cover using nippers.




Figure 1-2-132

- 17. Fit the tray lower cover.
- 18. Secure the tray lower cover with two pins.




Figure 1-2-133

19. Adhere the sheet onto left side of the document table.




Figure 1-2-134

20. Connect the telephone wire to the handset and the handset base.




Figure 1-2-135

21. Connect the modular cable to the handset base and the machine.






Figure 1-2-136

1-3-1 Maintenance mode

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a maintenance item



(2) Maintenance modes item list

Section	Item No.	Content of maintenance item	Initial setting			
			30ppm	35ppm	45ppm	55ppm
General	U000	Outputting an own-status report	-			
	U001	Exiting the maintenance mode	-			
	U002	Setting the factory default data	-			
	U003	Setting the service telephone number	-			
	U004	Setting the machine number	-			
	U010	Setting the maintenance mode ID	-			
	U019	Displaying the ROM version	-			
Initializa- tion	U021	Memory initializing	-			
	U024	HDD formatting	-			
Drive, paper feed and paper convey- ing sys- tem	U030	Checking the operation of the motors	-			
	U031	Checking switches and sensors for paper conveying	-			
	U032	Checking the operation of the clutches	-			
	U033	Checking the operation of the solenoids	-			
	U034	Adjusting the print start timing				
		LSU Out Top	0/0/0/0/0/0/0/0/0/0/0			
		LSU Out Left	0/0/0/0/0/0/0	0/0/0/0/0/0/0/0		
		LSU Out Top B/W	-			0/0/0/0/0/0
		LSU Out Top 3/4	0/0/0/0/0/0			
	U035	Setting the printing area for folio paper	330/210			
	U037	Checking the operation of the fan motors	-			
	U039	Adjusting the magnification	0			
	U051	Adjusting the deflection in the paper				
		Paper Loop Amount	1/1/1/1/1/1	-5/0/-5/0/ -5/0/-5/0/ -6/-1/-5/0	-7/-1/-7/-1/ -7/-1/-7/-1/ -8/-2/-7/-1	
		Paper Loop Amount B/W	-			-8/-8/-8/ -8/-9/-8
		Paper Loop Amount 3/4	1/1/1/1/1/1	-2/-2/-2/-2/-3/-2		
		U052	Setting the fuser motor control			
	U052	Set Loop Sensor	-			
		Loop Sensor Control	On/On/On/On			
		Set Loop Sensor Valid	On			
U053	Setting the adjustment of the motor speed					
	Motor1	19	16	12	11	
	Motor2	0/0/0/-/0		0/0/0/17/0	0/0/0/15/0	

Section	Item No.	Content of maintenance item	Initial setting			
			30ppm	35ppm	45ppm	55ppm
Drive, paper feed and paper convey- ing sys- tem	U053	Motor3	-31/0/-46/ -46/39/0/ -/-/ 0/0/0/0	-26/0/-39/ -39/33/0/ -/-/ 0/0/0/0	-20/0/-30/ -30/82/0/ 18/-30/-30/ 0/0/0/0	-18/0/-27/ -27/73/0/ 16/-27/-27/ 0/0/0/0
		Motor4	-/42	-/36	-/28	25/22
		Motor5	-			0/0/14/0
		Motor6	-			-16/0/-25/ -25/66/0/ 15/-24/-24
		Motor1 Half	0			
		Motor2 Half	0/0/0/-/0		0/0/0/34/0	0/0/0/30/0
		Motor3 Half	-61/0/-65/ -65/77/0/ -/-/	-52/0/-55/ -55/66/0/ -/-/	-41/0/-43/ -43/164/0/ 36/-60/-60	-36/0/-38/ -38/147/0/ 32/-54/-54
		Motor1 3/4	0			
		Motor2 3/4	0/0/0/-/0		0/0/0/22/0	
		Motor3 3/4	-40/0/-61/ -61/50/0/ -/-/	-36/0/-54/ -54/45/0/ -/-/	-26/0/-39/-39/106/0/ 23/ -39/-39	
	U059	Setting fan mode				
		Fan Mode	Mode1			
		Cooling Mode	0			
Optical	U061	Checking the operation of the exposure lamp	-			
	U063	Adjusting the shading position	0			
	U065	Adjusting the scanner magnification	0/0			
	U066	Adjusting the scanner leading edge registration	0/0			
	U067	Adjusting the scanner center line	0/0			
	U068	Adjusting the scanning position for originals from the DP	0/0			
	U070	Adjusting the DP magnification	0/0/0			
	U071	Adjusting the DP scanning timing	0/0/0/0			
	U072	Adjusting the DP center line	0/0/0			
	U073	Checking the scanner operation	-			
	U074	DP input response adjustment	1			
	U087	Setting DP reading position modification operation	125/125/125			
	U089	Outputting a MIP-PG pattern	-			

Section	Item No.	Content of maintenance item	Initial setting			
			30ppm	35ppm	45ppm	55ppm
Optical	U091	Setting the white line correction	112/112/112/75/0			
	U099		DP is not installed 20/30/40/20/30/40/20/30/40 DP is installed 50/50/50/50/50/50/50/50/50			
High voltage	U100	Adjusting main high voltage				
		Adj AC Bias	-			
		Set AC Auto Adj	On			
		Set DC Bias	-			
		Adj DC Bias	0/0/0/0/0/0/0/0			
		Set Low Temp	1			
		Set Charger Freq	10442/ -/ 10690/ 10690	8857/ -/ 10690/ 10690	8807/ -/ 10690/ 8857	11022/ 10690/ 10690 8857
		Chk Current	-			
	U101	Setting the voltage for the primary transfer				
		Normal Full	114	118	126	131
		Normal Half	101	103	108	110
		Normal 3/4	110	110	118	118
		Normal B/W	-			135
		Add Color Normal	2/2/15			
		Add Color Heavy4/5	-4/-4/-2/-17		-5/-5/-3/- 18	-6/-6/-4/- 19
		Add Color 2nd Normal	-3/-3/-2/-14			
		Add Color 2nd Heavy4/5	-4/-4/-2/-17		-5/-5/-3/- 18	-6/-6/-4/- 19
		Surround Correct	Off			
	U106	Setting the voltage for the secondary transfer				
		Light/Normal 1st Normal2/3 1st	125/118/ 110	131/123/ 115	143/134/ 120	150/139/ 128
		Light/Normal 2nd Normal2/3 2nd	167/133/ 112	180/140/ 116	207/155/ 124	220/163/ 128
		Light/Normal 1st 3/4(Gloss) Normal2/3 1st 3/4(Gloss)	120/114/111		131/123/120	
		Light/Normal 2nd 3/4(Gloss) Normal2/3 2nd 3/4(Gloss)	155/126/111		180/140/120	
		Light/Normal 1st B/W Normal2/3 1st B/W	-			150/144/ 128/

Section	Item No.	Content of maintenance item	Initial setting			
			30ppm	35ppm	45ppm	55ppm
High voltage	U106	Light/Normal 2nd B/W Normal2/3 2nd B/W	-			183/171/ 128
		Heavy1 1st 3/4	121/118/115		133/129/124	
		Heavy1 2nd 3/4	137/133/115		155/150/124	
		Heavy2-5 1st Half	114/111/ 109	118/115/ 112	126/123/ 119	130/127/ 122
		Heavy2-5 2nd Half	126/123/ 109	132/128/ 112	144/140/ 119	151/146/ 122
		OHP	118/115/ 112	123/120/ 116	134/129/ 124	139/133/ 128
		Bias	163/163/ 1/-/122/ 114/121	1/1/1/-/ 127/118/ 121	1/1/1/-/ 138/126/ 133	1/1/1/1/ 143/130/ 133
	U107	Setting the transfer cleaning voltage				
		Belt(A)	187/172/ 182/-	192/175/ 182/-	202/180/ 192/-	207/182/ 192/212
		Belt(B)	120/100/ 110/-	130/100/ 110/-	150/110/ 130/-	160/110/ 130/160
	U108	Setting separation shift bias				
		Output	55/55/55/55/0/0			
		Output 3/4	55/55/55/55			
		Output B/W	-		20/20/20/20	
		Timing	-			
		Subtraction Value	-35			
	U110	Checking the drum count	-			
	U111	Checking the drum drive time	-			
	U117	Checking the drum number	-			
	U118	Displaying the drum history	-			
U119	Setting the drum	-				
U122	Checking the transfer belt unit number	-				
U123	Displaying the transfer belt unit history	-				
U127	Checking/clearing the transfer count	-				
U128	Setting transfer high-voltage timing	-5/0/20	-5/0/16	-5/0/13	-5/0/10	
Developer	U130	Initial setting for the developer	-			
	U131	Adjusting the toner sensor control voltage	-			
		Manual	150/150/150/150			
		Mode	Auto			
U132	Replenishing toner forcibly					

Section	Item No.	Content of maintenance item	Initial setting			
			30ppm	35ppm	45ppm	55ppm
Developer	U135	Checking toner motor operation	-			
	U136	Setting toner near end detection	3/3			
	U139	Displaying the temperature and humidity outside the machine	-			
	U140	Displaying developer bias				
		Sleeve DC	72/72/72/62/-	84/84/84/70/-	84/84/84/70/70	
		Sleeve AC	175/175/175/175/-	155/155/155/155/-	155/155/155/155/155	
		Mag DC	130/130/130/130/-	155/155/155/155/-	155/155/155/155/155	
		Mag AC	101/101/101/101/-	200/200/200/160/-	200/200/200/160/160	
		Sleeve Freq	5221/ -/ 5345/ 5345	5345/ -/ 5345/ 5345	5345/ -/ 5345/ 5345	5511/ 5345/ 5345/ 5345
		Sleeve Duty	63/-	43/-	43/43	
		Mag Duty	37/-	68/-	68/68	
		AC Calib				
		Magnification	-	15/15/15/12		
		High Altitude	0	Mode1		
		U147	Setting for toner applying operation			
	Mode		Mode1			
	Upper Limit		2.0			
	Minimum		10			
	Interval Number		250/100/50			
	U148	Setting drum refresh mode	2			
	U155	Checking sensors for toner	-			
U156	Setting the toner replenishment level					
	Supply	512/512/512/512/-	512/512/512/512/512			
	Empty	100/100/100/100/-	100/100/100/100/100			
U157	Checking the developer drive time	-				

Section	Item No.	Content of maintenance item	Initial setting			
			30ppm	35ppm	45ppm	55ppm
Developer	U158	Checking the developer count	-			
Fuser	U161	Setting the fuser control temperature	-			
		Warm Up	155/110/ 40/165/ 155/150/ 50/120	160/110/ 40/170/ 165/150/ 50/120	165/140/ 80/170/ 165/150/ 50/155	170/145/ 80/175/ 175/150/ 50/160
		Print	165/0	170/0	170/0	175/0
		Low Powe Mode	-		Mode1	
		Grain Mode	Mode0			
	U163	Resetting the fuser problem data	-			
	U167	Checking/clearing the fuser count	-			
	U169	Checking/setting the fuser power source	-			
	U199	Displaying fuser heater temperature	-			
Operation panel and support equipment	U200	Turning all LEDs on	-			
	U201	Initializing the touch panel	-			
	U202	Setting the KMAS host monitoring system	-			
	U203	Checking DP operation	-			
	U204	Setting the presence or absence of a key card or key counter	Off/Coin Vender			
	U206	Setting the presence or absence of a coin vender				
		On/Off Config	Off			
		No Coin Action	Off			
		Price	10/10/10/10/100/50/30/50/ 100/50/30/50/100/50/30/50			
	U207	Checking the operation panel keys	-			
	U208	Setting the paper size for the side deck	Letter (Inch)/A4 (Metric)			
	U211	Setting the presence or absence of the job separator	Off			
	U221	Setting the USB host lock function	Off			
	U222	Setting the IC card type	Other			
	U223	Operation panel lock	Unlock			
	U224	Panel sheet extension	-			
	U234	Setting punch destination	Inch (Inch)/Europe Metric (Metric)			
U237	Setting finisher stack quantity	0/0				
U240	Checking the operation of the finisher	-				
U241	Checking the operation of the switches of the finisher	-				

Section	Item No.	Content of maintenance item	Initial setting			
			30ppm	35ppm	45ppm	55ppm
Operation panel and support equipment	U243	Checking the operation of the DP motors	-			
	U244	Checking the DP switches	-			
	U245	Checking messages	-			
	U246	Setting the finisher				
		Finisher	0/0/0/0/0/0/0/0			
		Booklet	0/0/0/0/0/0/0/0			
	U247	Setting the paper feed device	-			
U249	Finisher operation test	-				
Mode setting	U250	Checking/clearing the maintenance cycle	-			
	U251	Checking/clearing the maintenance counter	-			
	U252	Setting the destination	-			
	U253	Switching between double and single counts	DBL(A3/Ledger)			
	U260	Selecting the timing for copy counting	Eject			
	U265	Setting OEM purchaser code	-			
	U271	Setting the page count	2/3			
	U276	Setting the copy count mode	Mode0			
	U278	Setting the delivery date	-			
	U284	Setting 2 color copy mode	Off			
	U285	Setting service status page	On			
	U323	Setting abnormal temperature and humidity warning	On			
	U325	Setting the paper interval	Off/1			
	U326	Setting the black line cleaning indication	On/8			
	U327	Setting the cassette heater control	Off			
	U332	Setting the size conversion factor				
		Rate	1.0			
		Mode	0			
		Level 1	1.0			
		Level 2	2.5			
U340	Setting the applied mode	190/1				
U341	Specific paper feed location setting for printing function	-				
U343	Switching between duplex/simplex copy mode	Off				
U345	Setting the value for maintenance due indication	0				

Section	Item No.	Content of maintenance item	Initial setting			
			30ppm	35ppm	45ppm	55ppm
Image processing	U402	Adjusting margins of image printing	4.5/2.2/2.2/2.2			
	U403	Adjusting margins for scanning an original on the contact glass	2.0/2.0/2.0/2.0			
	U404	Adjusting margins for scanning an original from the DP	2.0/2.0/2.0/2.0/2.0/2.0/2.0/2.0			
	U407	Adjusting the leading edge registration for memory image printing	0			
	U410	Adjusting the halftone automatically	Table1			
	U411	Adjusting the scanner automatically	-			
	U412	Adjusting the uneven density	-			
	U415	Adjusting the print position automatically	-			
	U425	Setting the target	-			
	U429	Setting the offset for the color balance	0/0/0/0			
	U460	Adjusting the conveying sensor				
		Conveying Sensor	0/0			
		On/Off Config	Off			
	U464	Setting the ID correction operation				
		Permission	On			
		Time Interval	480			
		Mode	Normal			
		On/Sleep Out	On			
		AP/NE	On			
		Leaving Time	480			
		Driving Time	300			
		Timing	3600			
		Target Value	890/910/ 910/760/ 320/320/ 300/350	890/910/ 910/790/ 320/320/ 300/350	890/910/910/760/ 320/320/300/350	
		Print Rate(B/W)	50			
		Calib	-			
		Edge Reduction	Off			
		U465	Data reference for ID correction	-		
	U467	Setting the color registration adjustment				
		Color Regist	On			
		Timing	10			
U468	Checking the color registration data	-				
U469	Adjusting the color registration	-				

Section	Item No.	Content of maintenance item	Initial setting			
			30ppm	35ppm	45ppm	55ppm
Image processing	U470	Setting the JPEG compression ratio				
		Copy	90/90/90/90			
		Send	30/40/51/70/90/30/40/51/70/90 30/40/51/70/90/30/40/51/70/90 15/25/90/15/25/90/ 15/25/90/15/25/90			
		System	90/90			
	U474	Checking LSU cleaning operation	1000			
	U485	Setting the image processing mode	1/0			
	U486	Setting color/black and white operation mode	Mode2			
Others	U901	Checking copy counts by paper feed locations	-			
	U903	Checking/clearing the paper jam counts	-			
	U904	Checking/clearing the call for service counts	-			
	U905	Checking counts by optional devices	-			
	U906	Resetting partial operation control	-			
	U908	Checking the total counter value	-			
	U910	Clearing the print coverage data	-			
	U911	Checking copy counts by paper sizes	-			
	U917	Setting backup data reading/writing	-			
	U920	Checking the copy counts	-			
	U927	Clearing the all copy counts and machine life counts (one time only)	-			
	U928	Checking machine life counts	-			
	U930	Checking/clearing the charger roller count	-			
	U942	Setting of deflection for feeding from DP	0/0/0			
	U952	Maintenance mode workflow	-			
	U964	Checking of log	-			
	U969	Checking of toner area code	-			
	U977	Data capture mode	-			
	U984	Checking the developer unit number	-			
	U985	Displaying the developer unit history	-			
U989	HDD Scan disk	-				
Others	U990	Checking the time for the exposure lamp to light	-			
	U991	Checking the scanner operation count	-			

(3) Contents of the maintenance mode items

Item No.	Description																								
U000	<p data-bbox="288 293 703 322">Outputting an own-status report</p> <p data-bbox="288 360 440 389">Description Outputs lists of the current settings of the maintenance items, and paper jam and service call occurrences. Outputs the event log or service status page. Also sends output data to the USB memory.</p> <p data-bbox="288 501 400 530">Purpose To check the current setting of the maintenance items, or paper jam or service call occurrences. Before initializing or replacing the backup RAM, output a list of the current settings of the maintenance items to reenter the settings after initialization or replacement.</p> <p data-bbox="288 642 389 672">Method</p> <ol data-bbox="304 674 1038 741" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be output using the cursor up/down keys. <table border="1" data-bbox="336 748 1401 1084"> <thead> <tr> <th data-bbox="336 748 639 792">Display</th> <th data-bbox="639 748 1401 792">Output list</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 792 639 837">Maintenance</td> <td data-bbox="639 792 1401 837">List of the current settings of the maintenance modes</td> </tr> <tr> <td data-bbox="336 837 639 882">User Status</td> <td data-bbox="639 837 1401 882">Outputs the user status page</td> </tr> <tr> <td data-bbox="336 882 639 927">Service Status</td> <td data-bbox="639 882 1401 927">Outputs the service status page</td> </tr> <tr> <td data-bbox="336 927 639 972">Event</td> <td data-bbox="639 927 1401 972">Outputs the event log</td> </tr> <tr> <td data-bbox="336 972 639 1016">Network Status</td> <td data-bbox="639 972 1401 1016">Outputs the network status page</td> </tr> <tr> <td data-bbox="336 1016 639 1084">All</td> <td data-bbox="639 1016 1401 1084">Outputs the all reports</td> </tr> </tbody> </table> <ol data-bbox="304 1099 1430 1267" style="list-style-type: none"> 3. Press the start key. A list is output. 4. Press the start key. The interrupt print mode is entered and a list is output. When A4/Letter paper is available, a report of this size is output. If not, specify the paper feed location. 5. The output status is displayed. <table border="1" data-bbox="336 1279 1401 1518"> <thead> <tr> <th data-bbox="336 1279 639 1323">Display</th> <th data-bbox="639 1279 1401 1323">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1323 639 1368">Ready</td> <td data-bbox="639 1323 1401 1368">List of the current settings of the maintenance modes</td> </tr> <tr> <td data-bbox="336 1368 639 1413">Active</td> <td data-bbox="639 1368 1401 1413">Outputs the user status page</td> </tr> <tr> <td data-bbox="336 1413 639 1458">Complete</td> <td data-bbox="639 1413 1401 1458">Outputs the service status page</td> </tr> <tr> <td data-bbox="336 1458 639 1518">Error</td> <td data-bbox="639 1458 1401 1518">Outputs the event log</td> </tr> </tbody> </table>	Display	Output list	Maintenance	List of the current settings of the maintenance modes	User Status	Outputs the user status page	Service Status	Outputs the service status page	Event	Outputs the event log	Network Status	Outputs the network status page	All	Outputs the all reports	Display	Description	Ready	List of the current settings of the maintenance modes	Active	Outputs the user status page	Complete	Outputs the service status page	Error	Outputs the event log
Display	Output list																								
Maintenance	List of the current settings of the maintenance modes																								
User Status	Outputs the user status page																								
Service Status	Outputs the service status page																								
Event	Outputs the event log																								
Network Status	Outputs the network status page																								
All	Outputs the all reports																								
Display	Description																								
Ready	List of the current settings of the maintenance modes																								
Active	Outputs the user status page																								
Complete	Outputs the service status page																								
Error	Outputs the event log																								

Item No.	Description								
U000	<p>Method: Send to the USB memory</p> <ol style="list-style-type: none"> 1. Press the power key on the operation panel, and after verifying the main power indicator has gone off, switch off the main power switch. 2. Insert USB memory in USB memory slot. 3. Turn the main power switch on. 4. Enter the maintenance item. 5. Press the start key. 6. Select the item to be send. 7. Select [Text] or [HTML]. <table border="1" data-bbox="336 562 1401 754"> <thead> <tr> <th data-bbox="336 562 639 611">Display</th> <th data-bbox="639 562 1401 611">Output list</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 611 639 660">Print</td> <td data-bbox="639 611 1401 660">Outputs the report</td> </tr> <tr> <td data-bbox="336 660 639 710">USB (Text)</td> <td data-bbox="639 660 1401 710">Sends output data to the USB memory (text type)</td> </tr> <tr> <td data-bbox="336 710 639 754">USB (HTML)</td> <td data-bbox="639 710 1401 754">Sends output data to the USB memory (HTML type)</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 8. Press the start key. Output will be sent to the USB memory. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Output list	Print	Outputs the report	USB (Text)	Sends output data to the USB memory (text type)	USB (HTML)	Sends output data to the USB memory (HTML type)
Display	Output list								
Print	Outputs the report								
USB (Text)	Sends output data to the USB memory (text type)								
USB (HTML)	Sends output data to the USB memory (HTML type)								

Item No.	Description																																																																																																																																																																																																																																																																																																																																																																																																		
U000	<p data-bbox="288 241 411 273">Event log</p> <div data-bbox="316 297 1398 1637" style="border: 1px solid black; padding: 10px;"> <h3 data-bbox="355 324 576 369">Event Log</h3> <p data-bbox="355 376 416 403">MFP</p> <p data-bbox="1155 376 1362 403">(2) 27/Oct/2010 08:40</p> <p data-bbox="347 432 1362 459">(1) Firmware version 2LC_2000.000.000 2010.10.27 [XXXXXXXX] [XXXXXXXX] [XXXXXXXX] [XXXXXXXX]</p> <table border="0" data-bbox="347 495 1362 929"> <tr> <td colspan="3" data-bbox="347 495 790 521">(8) Paper Jam Log</td> <td colspan="4" data-bbox="790 495 1362 521">(12) Counter Log</td> </tr> <tr> <td data-bbox="389 528 405 551">#</td> <td data-bbox="437 528 517 551">Count.</td> <td data-bbox="564 528 756 551">Event Descriptions</td> <td data-bbox="804 528 820 551">(f)</td> <td data-bbox="868 528 948 551">J0000: 0</td> <td data-bbox="995 528 1075 551">J0041: 1</td> <td data-bbox="1123 528 1203 551">(g) C0000: 0</td> <td data-bbox="1251 528 1331 551">(h) T00: 10</td> </tr> <tr> <td>16</td> <td>9999999</td> <td>0501.01.08.01.01</td> <td></td> <td>J0001: 1</td> <td>J0042: 1</td> <td>C0001: 1</td> <td>T01: 20</td> </tr> <tr> <td>15</td> <td>8888888</td> <td>4002.01.08.01.01</td> <td></td> <td>J0002: 11</td> <td>J0043: 1</td> <td>C0002: 2</td> <td>T02: 30</td> </tr> <tr> <td>14</td> <td>7777777</td> <td>0501.01.08.01.01</td> <td></td> <td>J0003: 222</td> <td>J0044: 1</td> <td>C0003: 3</td> <td>T03: 40</td> </tr> <tr> <td>13</td> <td>6666666</td> <td>4002.01.08.01.01</td> <td></td> <td>J0004: 1</td> <td>J0045: 1</td> <td>C0004: 4</td> <td>T04: 50</td> </tr> <tr> <td>12</td> <td>5555555</td> <td>0501.01.08.01.01</td> <td></td> <td>J0005: 1</td> <td>J0046: 1</td> <td>C0005: 5</td> <td>T05: 999</td> </tr> <tr> <td>11</td> <td>4444444</td> <td>4002.01.08.01.01</td> <td></td> <td>J0006: 1</td> <td>J0047: 1</td> <td>C0006: 6</td> <td></td> </tr> <tr> <td>10</td> <td>3333333</td> <td>0501.01.08.01.01</td> <td></td> <td>J0007: 1</td> <td>J0048: 1</td> <td>C0007: 7</td> <td></td> </tr> <tr> <td>9</td> <td>2222222</td> <td>4002.01.08.01.01</td> <td></td> <td>J0008: 1</td> <td>J0049: 1</td> <td>C0008: 8</td> <td></td> </tr> <tr> <td>8</td> <td>1111111</td> <td>0501.01.08.01.01</td> <td></td> <td>J0009: 1</td> <td>J0050: 1</td> <td>C0009: 9</td> <td></td> </tr> <tr> <td>7</td> <td>9999999</td> <td>4002.01.08.01.01</td> <td></td> <td>J0010: 1</td> <td></td> <td>C0010: 10</td> <td></td> </tr> <tr> <td>6</td> <td>8888888</td> <td>0501.01.08.01.01</td> <td></td> <td>J0011: 1</td> <td></td> <td>C0011: 11</td> <td></td> </tr> <tr> <td>5</td> <td>7777777</td> <td>4002.01.08.01.01</td> <td></td> <td>J0012: 999</td> <td></td> <td>C0012: 12</td> <td></td> </tr> <tr> <td>4</td> <td>6666666</td> <td>0501.01.08.01.01</td> <td></td> <td>J0013: 1</td> <td></td> <td>C0013: 13</td> <td></td> </tr> <tr> <td>3</td> <td>5555555</td> <td>4002.01.08.01.01</td> <td></td> <td>J0014: 1</td> <td></td> <td>C0014: 14</td> <td></td> </tr> <tr> <td>2</td> <td>4444444</td> <td>0501.01.08.01.01</td> <td></td> <td>J0015: 1</td> <td></td> <td>C0015: 15</td> <td></td> </tr> <tr> <td>1</td> <td>3333333</td> <td>4002.01.08.01.01</td> <td></td> <td>J0016: 1</td> <td></td> <td>C0016: 16</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0017: 1</td> <td></td> <td>C0017: 17</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0018: 1</td> <td></td> <td>C0018: 18</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0019: 1</td> <td></td> <td>C0019: 19</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0020: 1</td> <td></td> <td>C0020: 20</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0021: 1</td> <td></td> <td>C0021: 21</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0022: 1</td> <td></td> <td>C0022: 22</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0023: 1</td> <td></td> <td>C0023: 23</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0024: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0025: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0026: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0027: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0028: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0029: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0030: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0031: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0032: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0033: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0034: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0035: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0036: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0037: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0038: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0039: 1</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>J0040: 1</td> <td></td> <td></td> <td></td> </tr> </table> <p data-bbox="347 958 564 985">(9) Service Call Log</p> <table border="0" data-bbox="389 992 708 1200"> <tr> <td>#</td> <td>Count.</td> <td>Service Code</td> </tr> <tr> <td>8</td> <td>1111111</td> <td>01.6000</td> </tr> <tr> <td>7</td> <td>9999999</td> <td>01.2100</td> </tr> <tr> <td>6</td> <td>8888888</td> <td>01.4000</td> </tr> <tr> <td>5</td> <td>7777777</td> <td>01.6000</td> </tr> <tr> <td>4</td> <td>6666666</td> <td>01.2100</td> </tr> <tr> <td>3</td> <td>5555555</td> <td>01.4000</td> </tr> <tr> <td>2</td> <td>4444444</td> <td>01.6000</td> </tr> <tr> <td>1</td> <td>1</td> <td>01.2100</td> </tr> </table> <p data-bbox="347 1229 564 1256">(10) Maintenance Log</p> <table border="0" data-bbox="389 1263 644 1326"> <tr> <td>#</td> <td>Count.</td> <td>Item.</td> </tr> <tr> <td></td> <td></td> <td>Log Data Nothing...</td> </tr> </table> <p data-bbox="347 1361 596 1388">(11) Unknown toner Log</p> <table border="0" data-bbox="389 1395 628 1532"> <tr> <td>#</td> <td>Count.</td> <td>Item.</td> </tr> <tr> <td>5</td> <td>1111111</td> <td>01.00</td> </tr> <tr> <td>4</td> <td>9999999</td> <td>01.00</td> </tr> <tr> <td>3</td> <td>8888888</td> <td>01.00</td> </tr> <tr> <td>2</td> <td>7777777</td> <td>01.00</td> </tr> <tr> <td>1</td> <td>6666666</td> <td>01.00</td> </tr> </table> <p data-bbox="1086 1576 1347 1603">(7) [XXXXXXXXXXXXXXXXXXXXX]</p> </div>	(8) Paper Jam Log			(12) Counter Log				#	Count.	Event Descriptions	(f)	J0000: 0	J0041: 1	(g) C0000: 0	(h) T00: 10	16	9999999	0501.01.08.01.01		J0001: 1	J0042: 1	C0001: 1	T01: 20	15	8888888	4002.01.08.01.01		J0002: 11	J0043: 1	C0002: 2	T02: 30	14	7777777	0501.01.08.01.01		J0003: 222	J0044: 1	C0003: 3	T03: 40	13	6666666	4002.01.08.01.01		J0004: 1	J0045: 1	C0004: 4	T04: 50	12	5555555	0501.01.08.01.01		J0005: 1	J0046: 1	C0005: 5	T05: 999	11	4444444	4002.01.08.01.01		J0006: 1	J0047: 1	C0006: 6		10	3333333	0501.01.08.01.01		J0007: 1	J0048: 1	C0007: 7		9	2222222	4002.01.08.01.01		J0008: 1	J0049: 1	C0008: 8		8	1111111	0501.01.08.01.01		J0009: 1	J0050: 1	C0009: 9		7	9999999	4002.01.08.01.01		J0010: 1		C0010: 10		6	8888888	0501.01.08.01.01		J0011: 1		C0011: 11		5	7777777	4002.01.08.01.01		J0012: 999		C0012: 12		4	6666666	0501.01.08.01.01		J0013: 1		C0013: 13		3	5555555	4002.01.08.01.01		J0014: 1		C0014: 14		2	4444444	0501.01.08.01.01		J0015: 1		C0015: 15		1	3333333	4002.01.08.01.01		J0016: 1		C0016: 16						J0017: 1		C0017: 17						J0018: 1		C0018: 18						J0019: 1		C0019: 19						J0020: 1		C0020: 20						J0021: 1		C0021: 21						J0022: 1		C0022: 22						J0023: 1		C0023: 23						J0024: 1								J0025: 1								J0026: 1								J0027: 1								J0028: 1								J0029: 1								J0030: 1								J0031: 1								J0032: 1								J0033: 1								J0034: 1								J0035: 1								J0036: 1								J0037: 1								J0038: 1								J0039: 1								J0040: 1				#	Count.	Service Code	8	1111111	01.6000	7	9999999	01.2100	6	8888888	01.4000	5	7777777	01.6000	4	6666666	01.2100	3	5555555	01.4000	2	4444444	01.6000	1	1	01.2100	#	Count.	Item.			Log Data Nothing...	#	Count.	Item.	5	1111111	01.00	4	9999999	01.00	3	8888888	01.00	2	7777777	01.00	1	6666666	01.00
(8) Paper Jam Log			(12) Counter Log																																																																																																																																																																																																																																																																																																																																																																																																
#	Count.	Event Descriptions	(f)	J0000: 0	J0041: 1	(g) C0000: 0	(h) T00: 10																																																																																																																																																																																																																																																																																																																																																																																												
16	9999999	0501.01.08.01.01		J0001: 1	J0042: 1	C0001: 1	T01: 20																																																																																																																																																																																																																																																																																																																																																																																												
15	8888888	4002.01.08.01.01		J0002: 11	J0043: 1	C0002: 2	T02: 30																																																																																																																																																																																																																																																																																																																																																																																												
14	7777777	0501.01.08.01.01		J0003: 222	J0044: 1	C0003: 3	T03: 40																																																																																																																																																																																																																																																																																																																																																																																												
13	6666666	4002.01.08.01.01		J0004: 1	J0045: 1	C0004: 4	T04: 50																																																																																																																																																																																																																																																																																																																																																																																												
12	5555555	0501.01.08.01.01		J0005: 1	J0046: 1	C0005: 5	T05: 999																																																																																																																																																																																																																																																																																																																																																																																												
11	4444444	4002.01.08.01.01		J0006: 1	J0047: 1	C0006: 6																																																																																																																																																																																																																																																																																																																																																																																													
10	3333333	0501.01.08.01.01		J0007: 1	J0048: 1	C0007: 7																																																																																																																																																																																																																																																																																																																																																																																													
9	2222222	4002.01.08.01.01		J0008: 1	J0049: 1	C0008: 8																																																																																																																																																																																																																																																																																																																																																																																													
8	1111111	0501.01.08.01.01		J0009: 1	J0050: 1	C0009: 9																																																																																																																																																																																																																																																																																																																																																																																													
7	9999999	4002.01.08.01.01		J0010: 1		C0010: 10																																																																																																																																																																																																																																																																																																																																																																																													
6	8888888	0501.01.08.01.01		J0011: 1		C0011: 11																																																																																																																																																																																																																																																																																																																																																																																													
5	7777777	4002.01.08.01.01		J0012: 999		C0012: 12																																																																																																																																																																																																																																																																																																																																																																																													
4	6666666	0501.01.08.01.01		J0013: 1		C0013: 13																																																																																																																																																																																																																																																																																																																																																																																													
3	5555555	4002.01.08.01.01		J0014: 1		C0014: 14																																																																																																																																																																																																																																																																																																																																																																																													
2	4444444	0501.01.08.01.01		J0015: 1		C0015: 15																																																																																																																																																																																																																																																																																																																																																																																													
1	3333333	4002.01.08.01.01		J0016: 1		C0016: 16																																																																																																																																																																																																																																																																																																																																																																																													
				J0017: 1		C0017: 17																																																																																																																																																																																																																																																																																																																																																																																													
				J0018: 1		C0018: 18																																																																																																																																																																																																																																																																																																																																																																																													
				J0019: 1		C0019: 19																																																																																																																																																																																																																																																																																																																																																																																													
				J0020: 1		C0020: 20																																																																																																																																																																																																																																																																																																																																																																																													
				J0021: 1		C0021: 21																																																																																																																																																																																																																																																																																																																																																																																													
				J0022: 1		C0022: 22																																																																																																																																																																																																																																																																																																																																																																																													
				J0023: 1		C0023: 23																																																																																																																																																																																																																																																																																																																																																																																													
				J0024: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0025: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0026: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0027: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0028: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0029: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0030: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0031: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0032: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0033: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0034: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0035: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0036: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0037: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0038: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0039: 1																																																																																																																																																																																																																																																																																																																																																																																															
				J0040: 1																																																																																																																																																																																																																																																																																																																																																																																															
#	Count.	Service Code																																																																																																																																																																																																																																																																																																																																																																																																	
8	1111111	01.6000																																																																																																																																																																																																																																																																																																																																																																																																	
7	9999999	01.2100																																																																																																																																																																																																																																																																																																																																																																																																	
6	8888888	01.4000																																																																																																																																																																																																																																																																																																																																																																																																	
5	7777777	01.6000																																																																																																																																																																																																																																																																																																																																																																																																	
4	6666666	01.2100																																																																																																																																																																																																																																																																																																																																																																																																	
3	5555555	01.4000																																																																																																																																																																																																																																																																																																																																																																																																	
2	4444444	01.6000																																																																																																																																																																																																																																																																																																																																																																																																	
1	1	01.2100																																																																																																																																																																																																																																																																																																																																																																																																	
#	Count.	Item.																																																																																																																																																																																																																																																																																																																																																																																																	
		Log Data Nothing...																																																																																																																																																																																																																																																																																																																																																																																																	
#	Count.	Item.																																																																																																																																																																																																																																																																																																																																																																																																	
5	1111111	01.00																																																																																																																																																																																																																																																																																																																																																																																																	
4	9999999	01.00																																																																																																																																																																																																																																																																																																																																																																																																	
3	8888888	01.00																																																																																																																																																																																																																																																																																																																																																																																																	
2	7777777	01.00																																																																																																																																																																																																																																																																																																																																																																																																	
1	6666666	01.00																																																																																																																																																																																																																																																																																																																																																																																																	

Figure 1-3-1

Detail of event log

No.	Items	Description
(1)	System version	
(2)	System date	
(3)	Engine soft version	
(4)	Engine boot version	

Item No.	Description				
U000	Detail of event log				
	No.	Items	Description		
	(5)	Controller BROM version			
	(6)	Operation panel mask version			
	(7)	Machine serial number			
	(8)	Paper Jam Log	#	Count.	Event
			Remembers 1 to 16 of occurrence. If the occurrence of the previous paper jam is less than 16, all of the paper jams are logged. When the occurrence exceeds 16, the oldest occurrence is removed.	The total page count at the time of the paper jam.	Log code (hexadecimal, 5 categories) (a) Cause of a paper jam (b) Paper source (c) Paper size (d) Paper type (e) Paper eject
			(a) Cause of paper jam (Hexadecimal)		
			For details on the case of paper jam, refer to Paper Misfeed Detection. (P.1-4-1)		
			(b) Detail of paper source (Hexadecimal)		
		00: MP tray 01: Cassette 1 02: Cassette 2 03: Cassette 3 (paper feeder/large capacity feeder) 04: Cassette 4 (paper feeder/large capacity feeder) 05: Cassette 5 (side multi tray/side deck) 06: Cassette 6 (side paper feeder/side large capacity feeder) 07: Cassette 7 (side paper feeder/side large capacity feeder) 08 to 09: Reserved			
		(c) Detail of paper size (Hexadecimal)			
		00: (Not specified) 01: Monarch 02: Business 03: International DL 04: International C5 05: Executive 06: Letter-R 08: Letter-E 07: Legal 08: A4R 88: A4E 09: B5R 89: B5E 0A: A3	0B: B4 0C: Ledger 0D: A5R 0E: A6 0F: B6 10: Commercial #9 11: Commercial #6 12: ISO B5 13: Custom size 1E: C4 1F: Postcard 20: Reply-paid post-card 21: Oficio II	22: Special 1 23: Special 2 24: A3 wide 25: Ledger wide 26: Full bleed paper (12 x 8) 27: 8K 28: 16K-R A8: 16K-E 32: Statement-R B2: Statement-E 33: Folio 34: Western type 2 35: Western type 4	

Item No.	Description																													
U000	No.	Items	Description																											
	(8) cont.	Paper Jam Log	<p>(d) Detail of paper type (Hexadecimal)</p> <table border="1" data-bbox="584 376 1414 701"> <tr> <td>01: Plain</td> <td>0A: Color</td> <td>15: Custom 1</td> </tr> <tr> <td>02: Transparency</td> <td>0B: Prepunched</td> <td>16: Custom 2</td> </tr> <tr> <td>03: Preprinted</td> <td>0C: Envelope</td> <td>17: Custom 3</td> </tr> <tr> <td>04: Labels</td> <td>0D: Cardstock</td> <td>18: Custom 4</td> </tr> <tr> <td>05: Bond</td> <td>0E: Coated</td> <td>19: Custom 5</td> </tr> <tr> <td>06: Recycled</td> <td>0F: 2nd side</td> <td>1A: Custom 6</td> </tr> <tr> <td>07: Vellum</td> <td>10: Media 16</td> <td>1B: Custom 7</td> </tr> <tr> <td>08: Rough</td> <td>11: High quality</td> <td>1C: Custom 8</td> </tr> <tr> <td>09: Letterhead</td> <td></td> <td></td> </tr> </table> <p>(e) Detail of paper eject location (Hexadecimal)</p> <p>01: Face down (FD) 02: Face up (FU)/1000-sheet finisher face up (FU)/ 4000-sheet finisher left sub tray (FU) 03: 1000-sheet finisher face down (FD) 4000-sheet finisher main tray (FD) 05: Job separator tray 06: 4000-sheet finisher right sub tray (FU) 07: 4000-sheet finisher left sub tray (FD) 09: 4000-sheet finisher right sub tray (FD) 0A: Center-folding unit tray 0B: Mailbox tray 1 (FD) 0C: Mailbox tray 1 (FU) 0F: 100-sheets Inner Job separator tray (FD) 15: Mailbox tray 2 (FD) 16: Mailbox tray 2 (FU) 1F: Mailbox tray 3 (FD) 20: Mailbox tray 3 (FU) 29: Mailbox tray 4 (FD) 2A: Mailbox tray 4 (FU) 33: Mailbox tray 5 (FD) 34: Mailbox tray 5 (FU) 3D: Mailbox tray 6 (FD) 3E: Mailbox tray 6 (FU) 47: Mailbox tray 7 (FD) 48: Mailbox tray 7 (FU) 04/0D/0E: Reserved</p>	01: Plain	0A: Color	15: Custom 1	02: Transparency	0B: Prepunched	16: Custom 2	03: Preprinted	0C: Envelope	17: Custom 3	04: Labels	0D: Cardstock	18: Custom 4	05: Bond	0E: Coated	19: Custom 5	06: Recycled	0F: 2nd side	1A: Custom 6	07: Vellum	10: Media 16	1B: Custom 7	08: Rough	11: High quality	1C: Custom 8	09: Letterhead		
	01: Plain	0A: Color	15: Custom 1																											
	02: Transparency	0B: Prepunched	16: Custom 2																											
03: Preprinted	0C: Envelope	17: Custom 3																												
04: Labels	0D: Cardstock	18: Custom 4																												
05: Bond	0E: Coated	19: Custom 5																												
06: Recycled	0F: 2nd side	1A: Custom 6																												
07: Vellum	10: Media 16	1B: Custom 7																												
08: Rough	11: High quality	1C: Custom 8																												
09: Letterhead																														

Item No.	Description								
U000	<table border="1"> <thead> <tr> <th data-bbox="293 282 379 322">No.</th> <th data-bbox="379 282 560 322">Items</th> <th colspan="3" data-bbox="560 282 1422 322">Description</th> </tr> </thead> </table>				No.	Items	Description		
	No.	Items	Description						
	(9)	Service Call Log	<table border="1"> <thead> <tr> <th data-bbox="560 322 826 376">#</th> <th data-bbox="826 322 1077 376">Count.</th> <th data-bbox="1077 322 1422 376">Service Code</th> </tr> </thead> <tbody> <tr> <td data-bbox="560 376 826 734">Remembers 1 to 8 of occurrence of self diagnostics error. If the occurrence of the previous diagnostics error is less than 8, all of the diagnostics errors are logged.</td> <td data-bbox="826 376 1077 734">The total page count at the time of the self diagnostics error.</td> <td data-bbox="1077 376 1422 734">Self diagnostic error code (See page 1-4-65) Example: 01.6000 01: Self diagnostic error 6000: Self diagnostic error code number</td> </tr> </tbody> </table>	#	Count.	Service Code	Remembers 1 to 8 of occurrence of self diagnostics error. If the occurrence of the previous diagnostics error is less than 8, all of the diagnostics errors are logged.	The total page count at the time of the self diagnostics error.	Self diagnostic error code (See page 1-4-65) Example: 01.6000 01: Self diagnostic error 6000: Self diagnostic error code number
	#	Count.	Service Code						
	Remembers 1 to 8 of occurrence of self diagnostics error. If the occurrence of the previous diagnostics error is less than 8, all of the diagnostics errors are logged.	The total page count at the time of the self diagnostics error.	Self diagnostic error code (See page 1-4-65) Example: 01.6000 01: Self diagnostic error 6000: Self diagnostic error code number						
	(10)	Maintenance Log	<table border="1"> <thead> <tr> <th data-bbox="560 734 826 788">#</th> <th data-bbox="826 734 1077 788">Count.</th> <th data-bbox="1077 734 1422 788">Item</th> </tr> </thead> <tbody> <tr> <td data-bbox="560 788 826 1525">Remembers 1 to 8 of occurrence of replacement. If the occurrence of the previous replacement of toner container is less than 8, all of the occurrences of replacement are logged.</td> <td data-bbox="826 788 1077 1525">The total page count at the time of the replacement of the toner container. * :The toner replacement log is triggered by toner empty. This record may contain such a reference as the toner container is inserted twice or a used toner container is inserted.</td> <td data-bbox="1077 788 1422 1525">Code of maintenance replacing item (1 byte, 2 categories) First byte (Replacing item) 01: Toner container Second byte (Type of replacing item) 00: Black 01: Cyan 02: Magenta 03: Yellow First byte (Replacing item) 02: Maintenance kit Second byte (Type of replacing item) 01: MK-8305A/8505A 02: MK-8305B/8505B 03: MK-8305C/8505C</td> </tr> </tbody> </table>	#	Count.	Item	Remembers 1 to 8 of occurrence of replacement. If the occurrence of the previous replacement of toner container is less than 8, all of the occurrences of replacement are logged.	The total page count at the time of the replacement of the toner container. * :The toner replacement log is triggered by toner empty. This record may contain such a reference as the toner container is inserted twice or a used toner container is inserted.	Code of maintenance replacing item (1 byte, 2 categories) First byte (Replacing item) 01: Toner container Second byte (Type of replacing item) 00: Black 01: Cyan 02: Magenta 03: Yellow First byte (Replacing item) 02: Maintenance kit Second byte (Type of replacing item) 01: MK-8305A/8505A 02: MK-8305B/8505B 03: MK-8305C/8505C
#	Count.	Item							
Remembers 1 to 8 of occurrence of replacement. If the occurrence of the previous replacement of toner container is less than 8, all of the occurrences of replacement are logged.	The total page count at the time of the replacement of the toner container. * :The toner replacement log is triggered by toner empty. This record may contain such a reference as the toner container is inserted twice or a used toner container is inserted.	Code of maintenance replacing item (1 byte, 2 categories) First byte (Replacing item) 01: Toner container Second byte (Type of replacing item) 00: Black 01: Cyan 02: Magenta 03: Yellow First byte (Replacing item) 02: Maintenance kit Second byte (Type of replacing item) 01: MK-8305A/8505A 02: MK-8305B/8505B 03: MK-8305C/8505C							
(11)	Unknown Toner Log	<table border="1"> <thead> <tr> <th data-bbox="560 1525 826 1579">#</th> <th data-bbox="826 1525 1077 1579">Count.</th> <th data-bbox="1077 1525 1422 1579">Item</th> </tr> </thead> <tbody> <tr> <td data-bbox="560 1579 826 2002">Remembers 1 to 5 of occurrence of unknown toner detection. If the occurrence of the previous unknown toner detection is less than 5, all of the unknown toner detection are logged.</td> <td data-bbox="826 1579 1077 2002">The total page count at the time of the toner empty error with using an unknown toner container.</td> <td data-bbox="1077 1579 1422 2002">Unknown toner log code (1 byte, 2 categories) First byte 01: Toner container (Fixed) Second byte 00: Black 01: Cyan 02: Magenta 03: Yellow</td> </tr> </tbody> </table>	#	Count.	Item	Remembers 1 to 5 of occurrence of unknown toner detection. If the occurrence of the previous unknown toner detection is less than 5, all of the unknown toner detection are logged.	The total page count at the time of the toner empty error with using an unknown toner container.	Unknown toner log code (1 byte, 2 categories) First byte 01: Toner container (Fixed) Second byte 00: Black 01: Cyan 02: Magenta 03: Yellow	
#	Count.	Item							
Remembers 1 to 5 of occurrence of unknown toner detection. If the occurrence of the previous unknown toner detection is less than 5, all of the unknown toner detection are logged.	The total page count at the time of the toner empty error with using an unknown toner container.	Unknown toner log code (1 byte, 2 categories) First byte 01: Toner container (Fixed) Second byte 00: Black 01: Cyan 02: Magenta 03: Yellow							

Item No.	Description			
<p>U000</p>	No.	Items	Description	
	(12)	<p>Counter Log</p> <p>Comprised of three log counters including paper jams, self diagnostics errors, and replacement of the toner container.</p>	<p>(f) Paper jam</p> <p>Indicates the log counter of paper jams depending on location.</p> <p>Refer to Paper Jam Log.</p> <p>All instances including those are not occurred are displayed.</p>	<p>(g) Self diagnostic error</p> <p>Indicates the log counter of self diagnostics errors depending on cause.</p> <p>Example: C6000: 4</p> <p>Self diagnostics error 6000 has happened four times.</p>

Item No.	Description
U000	<p data-bbox="287 241 582 275">Service status page (1)</p> <div data-bbox="295 302 1420 1803" style="border: 1px solid black; padding: 10px;"> <h2 data-bbox="327 324 766 369">Service Status Page</h2> <p data-bbox="327 376 391 403">MFP</p> <p data-bbox="1173 369 1372 398">(2) 27/10/2010 12:00</p> <p data-bbox="319 425 798 454">(1) Firmware version 2LC_2000.000.000 2010.10.27</p> <p data-bbox="1005 403 1380 454">(3) [XXXXXXXX] (4) [XXXXXXXX] (5) [XXXXXXXX]</p> <hr/> <p data-bbox="343 504 630 533">Controller Information</p> <p data-bbox="343 548 494 571">Memory status</p> <p data-bbox="319 571 662 600">(7) Total Size 2.0 GB</p> <p data-bbox="343 622 399 645">Time</p> <p data-bbox="319 645 766 674">(8) Local Time Zone +01:00 Amsterdam</p> <p data-bbox="319 674 758 703">(9) Date and Time 27/10/2010 12:00</p> <p data-bbox="319 703 718 732">(10) Time Server 10.183.53.13</p> <p data-bbox="343 750 518 772">Installed Options</p> <p data-bbox="303 772 766 1086"> (11) Document Processor Installed (12) Paper feeder Cassette (500 x 2) (13) Side Feeder Cassette (3000) (14) Finisher 1000-Finisher (15) Job Separator Installed (16) Document Gued (A) Installed (17) Card Authentication Kit (B) Installed (18) Internet FAX Kit (A) Installed Security Kit (E) Installed (19) Data Security Kit (E) Software Type I (20) UG-34 Installed (21) USB Keyboard Connected (22) USB Keyboard Type US-English </p> <p data-bbox="343 1108 494 1131">Print Coverage</p> <p data-bbox="303 1131 837 1164">(23) Average(%) / Usage Page(A4/Letter Conversion)</p> <p data-bbox="303 1164 638 1288"> (24) Total K: 1.10 / 1111111.11 C: 2.20 / 2222222.22 M: 3.30 / 3333333.33 Y: 4.40 / 4444444.44 </p> <p data-bbox="303 1288 638 1400"> (25) Copy K: 1.10 / 1111111.11 C: 2.20 / 2222222.22 M: 3.30 / 3333333.33 Y: 4.40 / 4444444.44 </p> <p data-bbox="303 1400 638 1523"> (26) Printer K: 1.10 / 1111111.11 C: 2.20 / 2222222.22 M: 3.30 / 3333333.33 Y: 4.40 / 4444444.44 </p> <p data-bbox="303 1523 638 1568"> (27) FAX K: 1.10 / 1111111.11 </p> <p data-bbox="303 1568 813 1597">(28) Period (27/10/2010 - 03/11/2010 08:40)</p> <p data-bbox="303 1597 774 1626">(29) Last Page K/C/M/Y(%) 1.00 / 2.22 / 3.33 / 4.44</p> <p data-bbox="853 504 1173 533">(30) FAX Information Slot1/Slot2</p> <p data-bbox="853 533 1133 562">(31) Rings (Normal) 3</p> <p data-bbox="853 562 1133 591">(32) Rings (FAX/TEL) 3</p> <p data-bbox="853 591 1133 620">(33) Rings (TAD) 3</p> <p data-bbox="853 620 1173 649">(34) Option DIMM Size 16 MB</p> <p data-bbox="853 672 1029 701">(35) FRPO Status</p> <p data-bbox="901 701 1340 730">Default Pattern Switch B8 0</p> <p data-bbox="901 730 1388 759">Default Font Number C5*1000+C2*100+C3 00000</p> <p data-bbox="901 1299 1340 1328">e-MPS error control Y6 0</p> <p data-bbox="901 1366 989 1395">RP Code</p> <p data-bbox="853 1395 1053 1424">(36) 1234 5678 9012</p> <p data-bbox="853 1424 1053 1453">(37) 5678 9012 3456</p> <p data-bbox="853 1453 1053 1482">(38) 9012 3456 7890</p> <p data-bbox="853 1482 1053 1512">(39) 3456 7890 1234</p> <p data-bbox="829 1736 845 1765">1</p> <p data-bbox="1117 1736 1380 1765">(6) [XXXXXXXXXXXXXXXXXXXX]</p> </div>

Figure 1-3-2

Item No.	Description		
U000	Detail of service status page		
	No.	Description	Supplement
	(1)	Firmware version	-
	(2)	System date	-
	(3)	Engine soft version	-
	(4)	Engine boot version	-
	(5)	Operation panel mask version	-
	(6)	Machine serial number	-
	(7)	Total memory size	-
	(8)	Local time zone	-
	(9)	Report output date	Day/Month/Year hour:minute
	(10)	NTP server name	-
	(11)	Presence or absence of the document processor	Installed/Not installed
	(12)	Presence or absence of the paper feeder	Paper feeder/Large capacity feeder/Not Installed
	(13)	Presence or absence of the side feeder	Side deck/Side multi tray/Side paper feeder/ Side large capacity feeder/Not Installed
	(14)	Presence or absence of the finisher	1000-sheet finisher/4000-sheet finisher/ Not Installed
	(15)	Presence or absence of the job separator	Installed/Not Installed
	(16)	Presence or absence of the printed document guard kit	Installed/Not Installed
	(17)	Presence or absence of the IC card authentication kit	Installed/Not Installed/Trial
	(18)	Presence or absence of the internet fax kit	Installed/Not Installed
	(19)	Presence or absence of the data security kit	Installed/Not Installed
	(20)	Presence or absence of the UG-34	Installed/Not Installed
	(21)	Presence or absence of the USB keyboard	Connected/Not connected
	(22)	USB keyboard setting display	US-English/US-English with Euro/German/French
	(23)	Page of relation to the A4/Letter	* :Print Coverage provides a close-matching reference of toner consumption and will not match with the actual toner consumption.
	(24)	Average coverage for total	Black/Cyan/Magenta/Yellow
(25)	Average coverage for copy	Black/Cyan/Magenta/Yellow	

Item No.	Description		
U000	No.	Description	Supplement
	(26)	Average coverage for printer	Black/Cyan/Magenta/Yellow
	(27)	Average coverage for fax	Black/Cyan/Magenta/Yellow
	(28)	Cleared date and output date	-
	(29)	Coverage on the final output page	-
	(30)	Fax kit information	This item is printed only when the fax kit is installed.
	(31)	Number of rings	0 to 15
	(32)	Number of rings before automatic switching	0 to 15
	(33)	Number of rings before connecting to answering machine	0 to 15
	(34)	Optional DIMM size	-
	(35)	FRPO setting	-
	(36)	RP code	Code the engine software version and the date of update.
	(37)	RP code	Code the main software version and the date of update.
	(38)	RP code	Code the engine software version and the date of the previous update.
	(39)	RP code	Code the main software version and the date of the previous update.
	(40)	NV RAM version	<p>_ 1F3 1225 _ 1F3 1225 (a) (b) (c) (d) (e) (f)</p> <p>(a) Consistency of the present software version and the database _ (underscore): OK * (Asterisk): NG</p> <p>(b) Database version (c) The oldest time stamp of database version (d) Consistency of the present software version and the ME firmware version _ (underscore): OK * (Asterisk): NG</p> <p>(e) ME firmware version (f) The oldest time stamp of the ME database version</p> <p>Normal if (a) and (d) are underscored, and (b) and (e) are identical with (c) and (f).</p>
(41)	Scanner firmware version	-	

Item No.	Description		
U000	No.	Description	Supplement
	(42)	Fax firmware version	This item is printed only when the fax kit is installed.
	(43)	Mac address	-
	(44)	The last sent date and time	-
	(45)	Transmission address	-
	(46)	Destination information	-
	(47)	Area information	-
	(48)	Margin settings	Top margin/Left margin
	(49)	Margin/Page length/Page width settings	Top margin integer part/Top margin decimal part/ Left margin integer part/Left margin decimal part/ Page length integer part/Page length decimal part/ Page width integer part/Page width decimal part
		Life counter (The first line)	Machine life/MP tray/Cassette 1/Cassette 2/ Cassette 3/Cassette 4/Cassette 5/Cassette 6/ Cassette 7/Duplex
	(50)	Life counter (The second line)	Drum unit K/Drum unit C/Drum unit M/Drum unit Y/ Transfer belt unit/Developer unit K/ Developer unit C/Developer unit M/ Developer unit Y/Maintenance kit A/ Maintenance kit B/Maintenance kit C
	(51)	Panel lock information	0: Off/1: Partial lock/2: Full lock
	(52)	USB information	U00: Not installed/U01: Full speed/U02: Hi speed
	(53)	Paper handling information	0: Paper source unit select/1: Paper source unit
	(54)	Color printing double count mode	0: All single counts 1: A3, Single count, Less than 420 mm (length) 2: Legal, Single count, 356 mm or less (length) 3: Folio, Single count, Less than 330 mm (length)
	(55)	Black and white printing double count mode	0: All single counts 1: A3, Single count, Less than 420 mm (length) 2: Legal, Single count, 356 mm or less (length) 3: Folio, Single count, Less than 330 mm (length)
	(56)	Billing counting timing	-
	(57)	Temperature (machine inside)	-
	(58)	Temperature (machine outside)	-
	(59)	Relative humidity (machine outside)	-
	(60)	Humidity (machine inside)	-
(61)	Fixed assets number	-	
(62)	Job end judgment time-out time	-	
(63)	Job end detection mode	-	

Item No.	Description																				
U000	No.	Description	Supplement																		
	(64)	Prescribe environment reset	0: Off 1: On																		
	(65)	Media type attributes 1 to 28 (Not used: 18, 19, 20)	<table border="0"> <tr> <td>Weight settings</td> <td>Fuser settings</td> </tr> <tr> <td>0: Light</td> <td>0: High</td> </tr> <tr> <td>1: Normal 1</td> <td>1: Middle</td> </tr> <tr> <td>2: Normal 2</td> <td>2: Low</td> </tr> <tr> <td>3: Normal 3</td> <td>3: Vellum</td> </tr> <tr> <td>4: Heavy 1</td> <td>Duplex settings</td> </tr> <tr> <td>5: Heavy 2</td> <td>0: Disable</td> </tr> <tr> <td>6: Heavy 3</td> <td>1: Enable</td> </tr> <tr> <td>7: Extra Heavy</td> <td></td> </tr> </table>	Weight settings	Fuser settings	0: Light	0: High	1: Normal 1	1: Middle	2: Normal 2	2: Low	3: Normal 3	3: Vellum	4: Heavy 1	Duplex settings	5: Heavy 2	0: Disable	6: Heavy 3	1: Enable	7: Extra Heavy	
	Weight settings	Fuser settings																			
	0: Light	0: High																			
	1: Normal 1	1: Middle																			
	2: Normal 2	2: Low																			
	3: Normal 3	3: Vellum																			
	4: Heavy 1	Duplex settings																			
	5: Heavy 2	0: Disable																			
	6: Heavy 3	1: Enable																			
	7: Extra Heavy																				
	(66)	Calibration information	Black/Cyan/Magenta/Yellow																		
	(67)	Calibration information	-																		
	(68)	Calibration information	-																		
	(69)	Calibration information	-																		
	(70)	Calibration information	-																		
	(71)	Calibration information	-																		
	(72)	Calibration information	-																		
	(73)	Calibration information	-																		
	(74)	Calibration information	-																		
	(75)	Calibration information	-																		
	(76)	RFID information	-																		
	(77)	RFID reader/writer version information	-																		
	(78)	Color table version for printer	-																		
	(79)	Color table 2 version for printer	-																		
	(80)	Color table version for copy	-																		
	(81)	Color table 2 version for copy	-																		
(82)	Maintenance information	-																			
(83)	Altitude	0: Standard 1: High altitude 1 2: High altitude 2																			
(84)	Charger roller correction	1 to 5																			
(85)	Configuring toner coverage counters	0: Full-color count display 1: Color coverage count display																			
(86)	Low coverage setting	0.1 to 100.0																			
(87)	Middle coverage setting	0.1 to 100.0																			
(88)	Data Sanitization information	-																			

Item No.	Description																																			
U000	<table border="1" data-bbox="296 286 1422 734"> <thead> <tr> <th data-bbox="296 286 387 331">No.</th> <th data-bbox="387 286 798 331">Description</th> <th data-bbox="798 286 1422 331">Supplement</th> </tr> </thead> <tbody> <tr> <td data-bbox="296 331 387 421">(89)</td> <td data-bbox="387 331 798 421">Toner low setting</td> <td data-bbox="798 331 1422 421">0: Enabled 1: Disabled</td> </tr> <tr> <td data-bbox="296 421 387 465">(90)</td> <td data-bbox="387 421 798 465">Toner low detection level</td> <td data-bbox="798 421 1422 465">0 to 100 (%)</td> </tr> <tr> <td data-bbox="296 465 387 510">(91)</td> <td data-bbox="387 465 798 510">Drum serial number</td> <td data-bbox="798 465 1422 510">Black/Cyan/Magenta/Yellow</td> </tr> <tr> <td colspan="3" data-bbox="296 510 1422 734"> <p data-bbox="539 555 740 582">Code conversion</p> <table border="1" data-bbox="539 600 1222 694"> <thead> <tr> <th data-bbox="539 600 608 645">A</th> <th data-bbox="608 600 676 645">B</th> <th data-bbox="676 600 745 645">C</th> <th data-bbox="745 600 813 645">D</th> <th data-bbox="813 600 882 645">E</th> <th data-bbox="882 600 951 645">F</th> <th data-bbox="951 600 1019 645">G</th> <th data-bbox="1019 600 1088 645">H</th> <th data-bbox="1088 600 1157 645">I</th> <th data-bbox="1157 600 1222 645">J</th> </tr> </thead> <tbody> <tr> <td data-bbox="539 645 608 694">0</td> <td data-bbox="608 645 676 694">1</td> <td data-bbox="676 645 745 694">2</td> <td data-bbox="745 645 813 694">3</td> <td data-bbox="813 645 882 694">4</td> <td data-bbox="882 645 951 694">5</td> <td data-bbox="951 645 1019 694">6</td> <td data-bbox="1019 645 1088 694">7</td> <td data-bbox="1088 645 1157 694">8</td> <td data-bbox="1157 645 1222 694">9</td> </tr> </tbody> </table> </td> </tr> </tbody> </table>	No.	Description	Supplement	(89)	Toner low setting	0: Enabled 1: Disabled	(90)	Toner low detection level	0 to 100 (%)	(91)	Drum serial number	Black/Cyan/Magenta/Yellow	<p data-bbox="539 555 740 582">Code conversion</p> <table border="1" data-bbox="539 600 1222 694"> <thead> <tr> <th data-bbox="539 600 608 645">A</th> <th data-bbox="608 600 676 645">B</th> <th data-bbox="676 600 745 645">C</th> <th data-bbox="745 600 813 645">D</th> <th data-bbox="813 600 882 645">E</th> <th data-bbox="882 600 951 645">F</th> <th data-bbox="951 600 1019 645">G</th> <th data-bbox="1019 600 1088 645">H</th> <th data-bbox="1088 600 1157 645">I</th> <th data-bbox="1157 600 1222 645">J</th> </tr> </thead> <tbody> <tr> <td data-bbox="539 645 608 694">0</td> <td data-bbox="608 645 676 694">1</td> <td data-bbox="676 645 745 694">2</td> <td data-bbox="745 645 813 694">3</td> <td data-bbox="813 645 882 694">4</td> <td data-bbox="882 645 951 694">5</td> <td data-bbox="951 645 1019 694">6</td> <td data-bbox="1019 645 1088 694">7</td> <td data-bbox="1088 645 1157 694">8</td> <td data-bbox="1157 645 1222 694">9</td> </tr> </tbody> </table>			A	B	C	D	E	F	G	H	I	J	0	1	2	3	4	5	6	7	8	9
No.	Description	Supplement																																		
(89)	Toner low setting	0: Enabled 1: Disabled																																		
(90)	Toner low detection level	0 to 100 (%)																																		
(91)	Drum serial number	Black/Cyan/Magenta/Yellow																																		
<p data-bbox="539 555 740 582">Code conversion</p> <table border="1" data-bbox="539 600 1222 694"> <thead> <tr> <th data-bbox="539 600 608 645">A</th> <th data-bbox="608 600 676 645">B</th> <th data-bbox="676 600 745 645">C</th> <th data-bbox="745 600 813 645">D</th> <th data-bbox="813 600 882 645">E</th> <th data-bbox="882 600 951 645">F</th> <th data-bbox="951 600 1019 645">G</th> <th data-bbox="1019 600 1088 645">H</th> <th data-bbox="1088 600 1157 645">I</th> <th data-bbox="1157 600 1222 645">J</th> </tr> </thead> <tbody> <tr> <td data-bbox="539 645 608 694">0</td> <td data-bbox="608 645 676 694">1</td> <td data-bbox="676 645 745 694">2</td> <td data-bbox="745 645 813 694">3</td> <td data-bbox="813 645 882 694">4</td> <td data-bbox="882 645 951 694">5</td> <td data-bbox="951 645 1019 694">6</td> <td data-bbox="1019 645 1088 694">7</td> <td data-bbox="1088 645 1157 694">8</td> <td data-bbox="1157 645 1222 694">9</td> </tr> </tbody> </table>			A	B	C	D	E	F	G	H	I	J	0	1	2	3	4	5	6	7	8	9														
A	B	C	D	E	F	G	H	I	J																											
0	1	2	3	4	5	6	7	8	9																											
U001	<p data-bbox="288 763 679 790">Exiting the maintenance mode</p> <p data-bbox="288 835 440 862">Description Exits the maintenance mode and returns to the normal copy mode.</p> <p data-bbox="288 907 400 934">Purpose To exit the maintenance mode.</p> <p data-bbox="288 1010 387 1037">Method 1. Press the start key. The normal copy mode is entered.</p>																																			
U002	<p data-bbox="288 1090 687 1120">Setting the factory default data</p> <p data-bbox="288 1164 440 1191">Description Restores the machine conditions to the factory default settings.</p> <p data-bbox="288 1236 400 1263">Purpose To move the mirror frame of the scanner to the position for transport.</p> <p data-bbox="288 1339 387 1366">Method 1. Press the start key. 2. Select [Mode1(All)]. 3. Press the start key. The mirror frame of the scanner returns to the home position. 4. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. * : An error code is displayed in case of an initialization error. When errors occurred, turn main power switch off then on, and execute initialization using maintenance item U002.</p> <p data-bbox="336 1682 488 1709">Error codes</p> <table border="1" data-bbox="336 1727 1401 2011"> <thead> <tr> <th data-bbox="336 1727 643 1771">Codes</th> <th data-bbox="643 1727 1401 1771">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1771 643 1816">0001</td> <td data-bbox="643 1771 1401 1816">Entity error</td> </tr> <tr> <td data-bbox="336 1816 643 1861">0002</td> <td data-bbox="643 1816 1401 1861">Controller error</td> </tr> <tr> <td data-bbox="336 1861 643 1906">0003</td> <td data-bbox="643 1861 1401 1906">OS error</td> </tr> <tr> <td data-bbox="336 1906 643 1951">0020</td> <td data-bbox="643 1906 1401 1951">Engine error</td> </tr> <tr> <td data-bbox="336 1951 643 1995">0040</td> <td data-bbox="643 1951 1401 1995">Scanner error</td> </tr> </tbody> </table>	Codes	Description	0001	Entity error	0002	Controller error	0003	OS error	0020	Engine error	0040	Scanner error																							
Codes	Description																																			
0001	Entity error																																			
0002	Controller error																																			
0003	OS error																																			
0020	Engine error																																			
0040	Scanner error																																			

Item No.	Description										
U003	<p>Setting the service telephone number</p> <p>Description Sets the telephone number to be displayed when a service call code is detected.</p> <p>Purpose To set the telephone number to call service when installing the machine.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. The keys to enter the number are displayed on the touch panel. 2. Enter a telephone number (up to 15 digits). 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>										
U004	<p>Setting the machine number</p> <p>Description Sets or displays the machine number.</p> <p>Purpose To check or set the machine number.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. If the machine serial number of engine PWB matches with that of main PWB <table border="1" data-bbox="336 1131 1401 1227"> <thead> <tr> <th data-bbox="336 1131 641 1176">Display</th> <th data-bbox="641 1131 1401 1176">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1176 641 1227">Machine No.</td> <td data-bbox="641 1176 1401 1227">Displays the machine serial number</td> </tr> </tbody> </table> <p>If the machine serial number of engine PWB does not match with that of main PWB</p> <table border="1" data-bbox="336 1283 1401 1429"> <thead> <tr> <th data-bbox="336 1283 641 1328">Display</th> <th data-bbox="641 1283 1401 1328">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1328 641 1373">Machine No.(Main)</td> <td data-bbox="641 1328 1401 1373">Displays the machine serial number of main</td> </tr> <tr> <td data-bbox="336 1373 641 1429">Machine No.(Eng)</td> <td data-bbox="641 1373 1401 1429">Displays the machine serial number of engine</td> </tr> </tbody> </table> <p>Setting Carry out if the machine serial number does not match.</p> <ol style="list-style-type: none"> 1. Select [Execute]. 2. Press the start key. Writing of serial No. starts. 3. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Machine No.	Displays the machine serial number	Display	Description	Machine No.(Main)	Displays the machine serial number of main	Machine No.(Eng)	Displays the machine serial number of engine
Display	Description										
Machine No.	Displays the machine serial number										
Display	Description										
Machine No.(Main)	Displays the machine serial number of main										
Machine No.(Eng)	Displays the machine serial number of engine										

Item No.	Description								
U010	<p data-bbox="290 241 715 275">Setting the maintenance mode ID</p> <p data-bbox="290 309 440 342">Description Sets the maintenance mode ID.</p> <p data-bbox="290 376 400 409">Purpose Modify maintenance mode ID for more security.</p> <p data-bbox="290 488 387 521">Method</p> <p data-bbox="306 521 564 555">1. Press the start key.</p> <table border="1" data-bbox="336 566 1401 757"> <thead> <tr> <th data-bbox="336 566 639 611">Display</th> <th data-bbox="639 566 1401 611">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 611 639 656">New ID</td> <td data-bbox="639 611 1401 656">Enter a new 8-digit ID</td> </tr> <tr> <td data-bbox="336 656 639 701">New ID(Reconfirm)</td> <td data-bbox="639 656 1401 701">Enter a new 8-digit ID (to confirm)</td> </tr> <tr> <td data-bbox="336 701 639 757">Initialize</td> <td data-bbox="639 701 1401 757">Initialize the ID</td> </tr> </tbody> </table> <p data-bbox="290 801 384 835">Setting</p> <p data-bbox="306 835 1289 1003">1. Select [New ID]. 2. Enter a new 8-digit ID on ten keys (0 – 9, *, #). * and # are mandatory to contain. 3. Select [New ID(Reconfirm)]. 4. Enter a new 8-digit ID on ten keys (0 – 9, *, #). 5. Press the start key. The setting is set.</p> <p data-bbox="290 1048 528 1081">Method: [Initialize]</p> <p data-bbox="306 1081 751 1149">1. Select [Initialize]. 2. Press the start key. ID is initialized.</p> <p data-bbox="290 1182 440 1216">Completion</p> <p data-bbox="290 1216 1257 1249">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	New ID	Enter a new 8-digit ID	New ID(Reconfirm)	Enter a new 8-digit ID (to confirm)	Initialize	Initialize the ID
Display	Description								
New ID	Enter a new 8-digit ID								
New ID(Reconfirm)	Enter a new 8-digit ID (to confirm)								
Initialize	Initialize the ID								

Item No.	Description																																																								
U019	<p data-bbox="288 241 647 275">Displaying the ROM version</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 970 374">Displays the part number of the ROM fitted to each PWB.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1238 443">To check the part number or to decide, if the newest version of ROM is installed.</p> <p data-bbox="288 486 387 515">Method</p> <ol data-bbox="304 519 954 584" style="list-style-type: none"> 1. Press the start key. The ROM version are displayed. 2. Change the screen using the cursor up/down keys. <table border="1" data-bbox="336 595 1399 1937"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1399 640">Description</th> </tr> </thead> <tbody> <tr><td>Main</td><td>Main ROM</td></tr> <tr><td>MMI</td><td>Operation ROM</td></tr> <tr><td>Browser</td><td>Browser ROM</td></tr> <tr><td>Engine</td><td>Engine ROM</td></tr> <tr><td>Engine Boot</td><td>Engine booting</td></tr> <tr><td>Scanner</td><td>Scanner ROM</td></tr> <tr><td>Scanner Boot</td><td>Scanner booting</td></tr> <tr><td>RFID</td><td>RFID ROM</td></tr> <tr><td>IH CPU</td><td>IH CPU ROM</td></tr> <tr><td>IH CPU Boot</td><td>IH CPU booting</td></tr> <tr><td>Motor CPU</td><td>Motor CPU ROM</td></tr> <tr><td>Motor CPU Boot</td><td>Motor CPU booting</td></tr> <tr><td>Dictionary</td><td>-</td></tr> <tr><td>Option Language</td><td>Optional language ROM</td></tr> <tr><td>PDF1.7 Resource</td><td>PDF1.7 resource ROM</td></tr> <tr><td>Solution Framework</td><td>Framework ROM</td></tr> <tr><td>FMU</td><td>FMU ROM</td></tr> <tr><td>Weekly Timer</td><td>Weekly Timer ROM</td></tr> <tr><td>Color Table1(Copy)</td><td>Color table 1 (copy) ROM</td></tr> <tr><td>Color Table2(Copy)</td><td>Color table 2 (copy) ROM</td></tr> <tr><td>Color Table1(Prn)</td><td>Color table 1 (printer) ROM</td></tr> <tr><td>Color Table2(Prn)</td><td>Color table 2 (printer) ROM</td></tr> <tr><td>DP</td><td>Document processor ROM</td></tr> <tr><td>DP Boot</td><td>Document processor booting</td></tr> <tr><td>PF1</td><td>Paper feeder / Large capacity feeder ROM</td></tr> <tr><td>PF1 Boot</td><td>Paper feeder / Large capacity feeder booting</td></tr> <tr><td>Side PF</td><td>Side multi tray /Side deck ROM</td></tr> </tbody> </table>	Display	Description	Main	Main ROM	MMI	Operation ROM	Browser	Browser ROM	Engine	Engine ROM	Engine Boot	Engine booting	Scanner	Scanner ROM	Scanner Boot	Scanner booting	RFID	RFID ROM	IH CPU	IH CPU ROM	IH CPU Boot	IH CPU booting	Motor CPU	Motor CPU ROM	Motor CPU Boot	Motor CPU booting	Dictionary	-	Option Language	Optional language ROM	PDF1.7 Resource	PDF1.7 resource ROM	Solution Framework	Framework ROM	FMU	FMU ROM	Weekly Timer	Weekly Timer ROM	Color Table1(Copy)	Color table 1 (copy) ROM	Color Table2(Copy)	Color table 2 (copy) ROM	Color Table1(Prn)	Color table 1 (printer) ROM	Color Table2(Prn)	Color table 2 (printer) ROM	DP	Document processor ROM	DP Boot	Document processor booting	PF1	Paper feeder / Large capacity feeder ROM	PF1 Boot	Paper feeder / Large capacity feeder booting	Side PF	Side multi tray /Side deck ROM
Display	Description																																																								
Main	Main ROM																																																								
MMI	Operation ROM																																																								
Browser	Browser ROM																																																								
Engine	Engine ROM																																																								
Engine Boot	Engine booting																																																								
Scanner	Scanner ROM																																																								
Scanner Boot	Scanner booting																																																								
RFID	RFID ROM																																																								
IH CPU	IH CPU ROM																																																								
IH CPU Boot	IH CPU booting																																																								
Motor CPU	Motor CPU ROM																																																								
Motor CPU Boot	Motor CPU booting																																																								
Dictionary	-																																																								
Option Language	Optional language ROM																																																								
PDF1.7 Resource	PDF1.7 resource ROM																																																								
Solution Framework	Framework ROM																																																								
FMU	FMU ROM																																																								
Weekly Timer	Weekly Timer ROM																																																								
Color Table1(Copy)	Color table 1 (copy) ROM																																																								
Color Table2(Copy)	Color table 2 (copy) ROM																																																								
Color Table1(Prn)	Color table 1 (printer) ROM																																																								
Color Table2(Prn)	Color table 2 (printer) ROM																																																								
DP	Document processor ROM																																																								
DP Boot	Document processor booting																																																								
PF1	Paper feeder / Large capacity feeder ROM																																																								
PF1 Boot	Paper feeder / Large capacity feeder booting																																																								
Side PF	Side multi tray /Side deck ROM																																																								

Item No.	Description			
U019	<table border="1"> <thead> <tr> <th data-bbox="336 286 639 331">Display</th> <th data-bbox="639 286 1401 331">Description</th> </tr> </thead> </table>		Display	Description
	Display	Description		
	Side PF Boot	Side multi tray /Side deck booting		
	SMT SSW	Side multi tray multi feed sensor		
	PF2	Side paper feeder / Side large capacity feeder ROM		
	PF2 Boot	Side paper feeder / Side large capacity feeder booting		
	DF	1000-sheet finisher / 4000-sheet finisher ROM		
	DF Boot	1000-sheet finisher / 4000-sheet finisher booting		
	PH	Punch unit ROM		
	PH Boot	Punch unit booting		
	MT	Mailbox ROM		
	MT Boot	Mailbox booting		
	BF	Center-folding unit ROM		
	BF Boot	Center-folding unit booting		
	Fax APL1	Fax APL 1		
	Fax Boot1	Fax booting 1		
	Fax IPL1	Fax IPL 1		
	Fax APL2	Fax APL 2 (dual Fax)		
	Fax Boot2	Fax booting 2 (dual Fax)		
	Fax IPL2	Fax IPL 2 (dual Fax)		
<p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>				

Item No.	Description										
U021	<p data-bbox="290 241 533 275">Memory initializing</p> <p data-bbox="290 311 440 340">Description</p> <p data-bbox="290 344 1422 445">Initializes all settings, except those pertinent to the type of machine, namely each counter, service call history and mode setting. Also initializes backup RAM according to region specification selected in maintenance item U252 Setting the destination.</p> <p data-bbox="290 450 400 479">Purpose</p> <p data-bbox="290 483 922 515">To return the machine settings to their factory default.</p> <p data-bbox="290 551 387 580">Method</p> <ol data-bbox="306 584 1382 757" style="list-style-type: none"> <li data-bbox="306 584 564 616">1. Press the start key. <li data-bbox="306 620 539 651">2. Select [Execute]. <li data-bbox="306 656 1345 723">3. Press the start key. All data other than that for adjustments due to variations between machines is initialized based on the destination setting. <li data-bbox="306 728 1382 757">4. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. <p data-bbox="338 761 1059 792">* : An error code is displayed in case of an initialization error.</p> <p data-bbox="370 797 1426 864">When errors occurred, turn main power switch off then on, and execute initialization using maintenance item U021.</p> <p data-bbox="338 900 488 929">Error codes</p> <table border="1" data-bbox="338 943 1399 1182"> <thead> <tr> <th data-bbox="338 943 641 987">Codes</th> <th data-bbox="641 943 1399 987">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="338 992 641 1037">0001</td> <td data-bbox="641 992 1399 1037">Entity error</td> </tr> <tr> <td data-bbox="338 1041 641 1086">0002</td> <td data-bbox="641 1041 1399 1086">Controller error</td> </tr> <tr> <td data-bbox="338 1090 641 1135">0020</td> <td data-bbox="641 1090 1399 1135">Engine error</td> </tr> <tr> <td data-bbox="338 1140 641 1184">0040</td> <td data-bbox="641 1140 1399 1184">Scanner error</td> </tr> </tbody> </table>	Codes	Description	0001	Entity error	0002	Controller error	0020	Engine error	0040	Scanner error
Codes	Description										
0001	Entity error										
0002	Controller error										
0020	Engine error										
0040	Scanner error										

Item No.	Description						
U024	<p>HDD formatting</p> <p>Description Initializes the hard disk.</p> <p>Purpose To initialize the hard disk when replacing the hard disk after shipping.</p> <p>Caution In addition, the following settings are also initialized by initializing the hard disk. System menu (user login administration, job accounting, address book, one-touch keys and document box etc.), shortcuts and panel programs When fully formatted, the following pre-installed software are removed. Option language, PDF1.7 resource, FMU, weekly timer</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item. <table border="1" data-bbox="336 804 1401 949"><thead><tr><th data-bbox="336 804 641 853">Display</th><th data-bbox="641 804 1401 853">Description</th></tr></thead><tbody><tr><td data-bbox="336 853 641 902">Full</td><td data-bbox="641 853 1401 902">Full format</td></tr><tr><td data-bbox="336 902 641 949">Data</td><td data-bbox="641 902 1401 949">Data format (the application software are retained)</td></tr></tbody></table> <ol style="list-style-type: none">3. Press [Execute].4. Press the start key to initialize the hard disk.5. Turn the main power switch off and on. Allow more than 5 seconds between Off and On.	Display	Description	Full	Full format	Data	Data format (the application software are retained)
Display	Description						
Full	Full format						
Data	Data format (the application software are retained)						



Item No.	Description																																								
U030	<p data-bbox="288 241 767 271">Checking the operation of the motors</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 515 374">Drives each motor.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 738 443">To check the operation of each motor.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="304 517 815 618" style="list-style-type: none"> 1. Press the start key. 2. Select the motor to be operated. 3. Press the start key. The operation starts. <table border="1" data-bbox="336 629 1385 1619"> <thead> <tr> <th data-bbox="336 629 687 680">Display</th> <th data-bbox="687 629 1385 680">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 680 687 719">Feed</td> <td data-bbox="687 680 1385 719">Paper feed motor (PFM) is turned on</td> </tr> <tr> <td data-bbox="336 719 687 757">DLP(K)</td> <td data-bbox="687 719 1385 757">Developer motor K (DEVM-K) is turned on</td> </tr> <tr> <td data-bbox="336 757 687 795">DLP(CMY)</td> <td data-bbox="687 757 1385 795">Developer motor MCY (DEVM-MCY) is turned on</td> </tr> <tr> <td data-bbox="336 795 687 833">Fuser</td> <td data-bbox="687 795 1385 833">Fuser motor (FUM) is turned on</td> </tr> <tr> <td data-bbox="336 833 687 871">SB(CW)</td> <td data-bbox="687 833 1385 871">Eject motor (EM) is turned on clockwise</td> </tr> <tr> <td data-bbox="336 871 687 909">SB(CCW)</td> <td data-bbox="687 871 1385 909">Eject motor (EM) is turned on counterclockwise</td> </tr> <tr> <td data-bbox="336 909 687 947">CMY Release</td> <td data-bbox="687 909 1385 947">Color release motor (CRM) is turned on</td> </tr> <tr> <td data-bbox="336 947 687 985">Job Separator</td> <td data-bbox="687 947 1385 985">JS eject motor (JSEM) is turned on</td> </tr> <tr> <td data-bbox="336 985 687 1023">Inner Job Separator(CW)</td> <td data-bbox="687 985 1385 1023">JS conveying motor (JSCM) is turned on clockwise</td> </tr> <tr> <td data-bbox="336 1023 687 1061">Inner Job Separator(CCW)</td> <td data-bbox="687 1023 1385 1061">JS conveying motor (JSCM) is turned on counterclockwise</td> </tr> <tr> <td data-bbox="336 1061 687 1099">Regist*</td> <td data-bbox="687 1061 1385 1099">Registration motor (RM) is turned on</td> </tr> <tr> <td data-bbox="336 1099 687 1137">Bridge1</td> <td data-bbox="687 1099 1385 1137">BR conveying motor 1 (BRCM1) is turned on</td> </tr> <tr> <td data-bbox="336 1137 687 1176">Bridge2</td> <td data-bbox="687 1137 1385 1176">BR conveying motor 2 (BRCM2) is turned on</td> </tr> <tr> <td data-bbox="336 1176 687 1214">Belt Meand</td> <td data-bbox="687 1176 1385 1214">Transfer motor (TRM) is turned on</td> </tr> <tr> <td data-bbox="336 1214 687 1252">Press Release</td> <td data-bbox="687 1214 1385 1252">Transfer release motor (TRRM) is turned on</td> </tr> <tr> <td data-bbox="336 1252 687 1290">Fuser Release</td> <td data-bbox="687 1252 1385 1290">Fuser release motor (FURM) is turned on</td> </tr> <tr> <td data-bbox="336 1290 687 1328">DU1*</td> <td data-bbox="687 1290 1385 1328">Duplex motor 1 (DUM1) is turned on</td> </tr> <tr> <td data-bbox="336 1328 687 1366">DU2*</td> <td data-bbox="687 1328 1385 1366">Duplex motor 2 (DUM2) is turned on</td> </tr> <tr> <td data-bbox="336 1366 687 1404">Mid Roller*</td> <td data-bbox="687 1366 1385 1404">Middle motor (RM) is turned on</td> </tr> </tbody> </table> <p data-bbox="331 1648 692 1677">*: 45 ppm/55 ppm model only.</p> <ol data-bbox="304 1682 780 1711" style="list-style-type: none"> 4. To stop operation, press the stop key. <p data-bbox="288 1751 440 1780">Completion</p> <p data-bbox="288 1785 1254 1814">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Feed	Paper feed motor (PFM) is turned on	DLP(K)	Developer motor K (DEVM-K) is turned on	DLP(CMY)	Developer motor MCY (DEVM-MCY) is turned on	Fuser	Fuser motor (FUM) is turned on	SB(CW)	Eject motor (EM) is turned on clockwise	SB(CCW)	Eject motor (EM) is turned on counterclockwise	CMY Release	Color release motor (CRM) is turned on	Job Separator	JS eject motor (JSEM) is turned on	Inner Job Separator(CW)	JS conveying motor (JSCM) is turned on clockwise	Inner Job Separator(CCW)	JS conveying motor (JSCM) is turned on counterclockwise	Regist*	Registration motor (RM) is turned on	Bridge1	BR conveying motor 1 (BRCM1) is turned on	Bridge2	BR conveying motor 2 (BRCM2) is turned on	Belt Meand	Transfer motor (TRM) is turned on	Press Release	Transfer release motor (TRRM) is turned on	Fuser Release	Fuser release motor (FURM) is turned on	DU1*	Duplex motor 1 (DUM1) is turned on	DU2*	Duplex motor 2 (DUM2) is turned on	Mid Roller*	Middle motor (RM) is turned on
Display	Description																																								
Feed	Paper feed motor (PFM) is turned on																																								
DLP(K)	Developer motor K (DEVM-K) is turned on																																								
DLP(CMY)	Developer motor MCY (DEVM-MCY) is turned on																																								
Fuser	Fuser motor (FUM) is turned on																																								
SB(CW)	Eject motor (EM) is turned on clockwise																																								
SB(CCW)	Eject motor (EM) is turned on counterclockwise																																								
CMY Release	Color release motor (CRM) is turned on																																								
Job Separator	JS eject motor (JSEM) is turned on																																								
Inner Job Separator(CW)	JS conveying motor (JSCM) is turned on clockwise																																								
Inner Job Separator(CCW)	JS conveying motor (JSCM) is turned on counterclockwise																																								
Regist*	Registration motor (RM) is turned on																																								
Bridge1	BR conveying motor 1 (BRCM1) is turned on																																								
Bridge2	BR conveying motor 2 (BRCM2) is turned on																																								
Belt Meand	Transfer motor (TRM) is turned on																																								
Press Release	Transfer release motor (TRRM) is turned on																																								
Fuser Release	Fuser release motor (FURM) is turned on																																								
DU1*	Duplex motor 1 (DUM1) is turned on																																								
DU2*	Duplex motor 2 (DUM2) is turned on																																								
Mid Roller*	Middle motor (RM) is turned on																																								



Item No.	Description																																				
U031	<p data-bbox="290 241 960 275">Checking switches and sensors for paper conveying</p> <p data-bbox="290 309 440 342">Description</p> <p data-bbox="290 344 1302 378">Displays the on-off status of each paper detection switch or sensor on the paper path.</p> <p data-bbox="290 380 400 414">Purpose</p> <p data-bbox="290 416 1179 450">To check if the switches and sensors for paper conveying operate correctly.</p> <p data-bbox="290 483 387 517">Method</p> <ol data-bbox="306 519 1398 651" style="list-style-type: none"> 1. Press the start key. 2. Turn each switch or sensor on and off manually to check the status. When the on-status of a switch or sensor is detected, that switch or sensor is displayed in reverse. <table border="1" data-bbox="336 667 1398 1529"> <thead> <tr> <th data-bbox="336 667 639 712">Display</th> <th data-bbox="639 667 1398 712">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 712 639 757">MPT Jam</td> <td data-bbox="639 712 1398 757">MP feed sensor (MPFS)</td> </tr> <tr> <td data-bbox="336 757 639 801">Cassette1 Feed</td> <td data-bbox="639 757 1398 801">Feed sensor 1 (FS1)</td> </tr> <tr> <td data-bbox="336 801 639 846">Cassette2 Feed</td> <td data-bbox="639 801 1398 846">Feed sensor 2 (FS2)</td> </tr> <tr> <td data-bbox="336 846 639 891">Feed2(Feed B)</td> <td data-bbox="639 846 1398 891">Paper conveying sensor (PCS)</td> </tr> <tr> <td data-bbox="336 891 639 936">Regist</td> <td data-bbox="639 891 1398 936">Registration sensor (RS)</td> </tr> <tr> <td data-bbox="336 936 639 981">Belt Jam</td> <td data-bbox="639 936 1398 981">Loop sensor (LPS)</td> </tr> <tr> <td data-bbox="336 981 639 1025">Exit Feed</td> <td data-bbox="639 981 1398 1025">Switchback sensor (SBS)</td> </tr> <tr> <td data-bbox="336 1025 639 1070">DU1</td> <td data-bbox="639 1025 1398 1070">Duplex sensor 1 (DUS1)</td> </tr> <tr> <td data-bbox="336 1070 639 1115">DU2</td> <td data-bbox="639 1070 1398 1115">Duplex sensor 2 (DUS2)</td> </tr> <tr> <td data-bbox="336 1115 639 1160">Bridge1 Feed</td> <td data-bbox="639 1115 1398 1160">BR conveying sensor 1 (BRCS1)</td> </tr> <tr> <td data-bbox="336 1160 639 1205">Bridge2 Feed</td> <td data-bbox="639 1160 1398 1205">BR conveying sensor 2 (BRCS2)</td> </tr> <tr> <td data-bbox="336 1205 639 1249">Bridge Exit</td> <td data-bbox="639 1205 1398 1249">BR eject sensor (BRES)</td> </tr> <tr> <td data-bbox="336 1249 639 1294">Exit Paper</td> <td data-bbox="639 1249 1398 1294">Eject full sensor (EFS)</td> </tr> <tr> <td data-bbox="336 1294 639 1339">Fuser Feed</td> <td data-bbox="639 1294 1398 1339">Fuser eject sensor (FUES)</td> </tr> <tr> <td data-bbox="336 1339 639 1384">Feed1(Mid)</td> <td data-bbox="639 1339 1398 1384">Middle sensor (MS)</td> </tr> <tr> <td data-bbox="336 1384 639 1429">Exit Job Separator</td> <td data-bbox="639 1384 1398 1429">JS eject sensor (JSES)</td> </tr> <tr> <td data-bbox="336 1429 639 1473">Inner Job Separator</td> <td data-bbox="639 1429 1398 1473">Tray full sensor(JSTFS)</td> </tr> </tbody> </table> <p data-bbox="290 1585 440 1619">Completion</p> <p data-bbox="290 1621 1254 1655">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MPT Jam	MP feed sensor (MPFS)	Cassette1 Feed	Feed sensor 1 (FS1)	Cassette2 Feed	Feed sensor 2 (FS2)	Feed2(Feed B)	Paper conveying sensor (PCS)	Regist	Registration sensor (RS)	Belt Jam	Loop sensor (LPS)	Exit Feed	Switchback sensor (SBS)	DU1	Duplex sensor 1 (DUS1)	DU2	Duplex sensor 2 (DUS2)	Bridge1 Feed	BR conveying sensor 1 (BRCS1)	Bridge2 Feed	BR conveying sensor 2 (BRCS2)	Bridge Exit	BR eject sensor (BRES)	Exit Paper	Eject full sensor (EFS)	Fuser Feed	Fuser eject sensor (FUES)	Feed1(Mid)	Middle sensor (MS)	Exit Job Separator	JS eject sensor (JSES)	Inner Job Separator	Tray full sensor(JSTFS)
Display	Description																																				
MPT Jam	MP feed sensor (MPFS)																																				
Cassette1 Feed	Feed sensor 1 (FS1)																																				
Cassette2 Feed	Feed sensor 2 (FS2)																																				
Feed2(Feed B)	Paper conveying sensor (PCS)																																				
Regist	Registration sensor (RS)																																				
Belt Jam	Loop sensor (LPS)																																				
Exit Feed	Switchback sensor (SBS)																																				
DU1	Duplex sensor 1 (DUS1)																																				
DU2	Duplex sensor 2 (DUS2)																																				
Bridge1 Feed	BR conveying sensor 1 (BRCS1)																																				
Bridge2 Feed	BR conveying sensor 2 (BRCS2)																																				
Bridge Exit	BR eject sensor (BRES)																																				
Exit Paper	Eject full sensor (EFS)																																				
Fuser Feed	Fuser eject sensor (FUES)																																				
Feed1(Mid)	Middle sensor (MS)																																				
Exit Job Separator	JS eject sensor (JSES)																																				
Inner Job Separator	Tray full sensor(JSTFS)																																				

Item No.	Description																								
U032	<p data-bbox="288 241 786 275">Checking the operation of the clutches</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 547 374">Turns each clutch on.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 740 443">To check the operation of each clutch.</p> <p data-bbox="288 486 387 515">Method</p> <ol data-bbox="308 519 815 618" style="list-style-type: none"> 1. Press the start key. 2. Select the clutch to be operated. 3. Press the start key. The operation starts. <table border="1" data-bbox="336 631 1401 1207"> <thead> <tr> <th data-bbox="336 631 639 680">Display</th> <th data-bbox="639 631 1401 680">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 680 639 723">Feed1</td> <td data-bbox="639 680 1401 723">Paper feed clutch 1 (PFCL1) is turned on</td> </tr> <tr> <td data-bbox="336 723 639 766">Feed2</td> <td data-bbox="639 723 1401 766">Paper feed clutch 2 (PFCL2) is turned on</td> </tr> <tr> <td data-bbox="336 766 639 808">Mid Roller*1</td> <td data-bbox="639 766 1401 808">Middle clutch (MCL) is turned on</td> </tr> <tr> <td data-bbox="336 808 639 851">MPT Feed</td> <td data-bbox="639 808 1401 851">MP paper feed clutch (MPPFCL) is turned on</td> </tr> <tr> <td data-bbox="336 851 639 893">Regist*1</td> <td data-bbox="639 851 1401 893">Registration clutch (RCL) is turned on</td> </tr> <tr> <td data-bbox="336 893 639 936">Feed</td> <td data-bbox="639 893 1401 936">Paper conveying clutch (PCCL) is turned on</td> </tr> <tr> <td data-bbox="336 936 639 978">DU1*1</td> <td data-bbox="639 936 1401 978">Duplex clutch 1 (DUCL1) is turned on</td> </tr> <tr> <td data-bbox="336 978 639 1021">DU2*1</td> <td data-bbox="639 978 1401 1021">Duplex clutch 2 (DUCL2) is turned on</td> </tr> <tr> <td data-bbox="336 1021 639 1064">Assist1*2</td> <td data-bbox="639 1021 1401 1064">Assist clutch 1 (ASCL1) is turned on</td> </tr> <tr> <td data-bbox="336 1064 639 1106">Assist2*2</td> <td data-bbox="639 1064 1401 1106">Assist clutch 2 (ASCL2) is turned on</td> </tr> <tr> <td data-bbox="336 1106 639 1149">Motor</td> <td data-bbox="639 1106 1401 1149">Motor is turned on</td> </tr> </tbody> </table> <p data-bbox="331 1243 1090 1272">*1: 30 ppm/35 ppm model only. *2: 45 ppm/55 ppm model only.</p> <ol data-bbox="308 1276 780 1305" style="list-style-type: none"> 4. To stop operation, press the stop key. <p data-bbox="288 1348 440 1377">Completion</p> <p data-bbox="288 1382 1254 1411">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Feed1	Paper feed clutch 1 (PFCL1) is turned on	Feed2	Paper feed clutch 2 (PFCL2) is turned on	Mid Roller*1	Middle clutch (MCL) is turned on	MPT Feed	MP paper feed clutch (MPPFCL) is turned on	Regist*1	Registration clutch (RCL) is turned on	Feed	Paper conveying clutch (PCCL) is turned on	DU1*1	Duplex clutch 1 (DUCL1) is turned on	DU2*1	Duplex clutch 2 (DUCL2) is turned on	Assist1*2	Assist clutch 1 (ASCL1) is turned on	Assist2*2	Assist clutch 2 (ASCL2) is turned on	Motor	Motor is turned on
Display	Description																								
Feed1	Paper feed clutch 1 (PFCL1) is turned on																								
Feed2	Paper feed clutch 2 (PFCL2) is turned on																								
Mid Roller*1	Middle clutch (MCL) is turned on																								
MPT Feed	MP paper feed clutch (MPPFCL) is turned on																								
Regist*1	Registration clutch (RCL) is turned on																								
Feed	Paper conveying clutch (PCCL) is turned on																								
DU1*1	Duplex clutch 1 (DUCL1) is turned on																								
DU2*1	Duplex clutch 2 (DUCL2) is turned on																								
Assist1*2	Assist clutch 1 (ASCL1) is turned on																								
Assist2*2	Assist clutch 2 (ASCL2) is turned on																								
Motor	Motor is turned on																								

Item No.	Description												
U033	<p>Checking the operation of the solenoids</p> <p>Description Turns each solenoid on.</p> <p>Purpose To check the operation of each solenoid.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the solenoid to be operated.z 3. Press the start key. The operation starts. <table border="1" data-bbox="336 631 1401 920"> <thead> <tr> <th data-bbox="336 631 639 676">Display</th> <th data-bbox="639 631 1401 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 676 639 721">Branch Left</td> <td data-bbox="639 676 1401 721">BR Feedshift solenoid (BRFSSOL) is turned on</td> </tr> <tr> <td data-bbox="336 721 639 766">Branch Exit</td> <td data-bbox="639 721 1401 766">Feedshift solenoid (FSSOL) is turned on</td> </tr> <tr> <td data-bbox="336 766 639 810">Job Separator</td> <td data-bbox="639 766 1401 810">JS feedshift solenoid (JSFSSOL) is turned on</td> </tr> <tr> <td data-bbox="336 810 639 855">ID Clean</td> <td data-bbox="639 810 1401 855">Cleaning solenoid (CLSOL) is turned on</td> </tr> <tr> <td data-bbox="336 855 639 920">Motor</td> <td data-bbox="639 855 1401 920">Motor is turned on</td> </tr> </tbody> </table> <p>*: 45 ppm/55 ppm model only.</p> <ol style="list-style-type: none"> 4. To stop operation, press the stop key. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Branch Left	BR Feedshift solenoid (BRFSSOL) is turned on	Branch Exit	Feedshift solenoid (FSSOL) is turned on	Job Separator	JS feedshift solenoid (JSFSSOL) is turned on	ID Clean	Cleaning solenoid (CLSOL) is turned on	Motor	Motor is turned on
Display	Description												
Branch Left	BR Feedshift solenoid (BRFSSOL) is turned on												
Branch Exit	Feedshift solenoid (FSSOL) is turned on												
Job Separator	JS feedshift solenoid (JSFSSOL) is turned on												
ID Clean	Cleaning solenoid (CLSOL) is turned on												
Motor	Motor is turned on												
U034	<p>Adjusting the print start timing</p> <p>Description Adjusts the leading edge registration or center line.</p> <p>Purpose Make the adjustment if there is a regular error between the leading edges of the copy image and original. Make the adjustment if there is a regular error between the center lines of the copy image and original.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be adjusted. <table border="1" data-bbox="336 1615 1401 1859"> <thead> <tr> <th data-bbox="336 1615 603 1659">Display</th> <th data-bbox="603 1615 1401 1659">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1659 603 1704">LSU Out Top</td> <td data-bbox="603 1659 1401 1704">Leading edge registration adjustment</td> </tr> <tr> <td data-bbox="336 1704 603 1749">LSU Out Left</td> <td data-bbox="603 1704 1401 1749">Center line adjustment</td> </tr> <tr> <td data-bbox="336 1749 603 1794">LSU Out Top B/W*</td> <td data-bbox="603 1749 1401 1794">Leading edge registration adjustment in black/white mode</td> </tr> <tr> <td data-bbox="336 1794 603 1859">LSU Out Top 3/4</td> <td data-bbox="603 1794 1401 1859">Leading edge registration adjustment at 3/4 times of line speed</td> </tr> </tbody> </table> <p>*: 55 ppm model only.</p>	Display	Description	LSU Out Top	Leading edge registration adjustment	LSU Out Left	Center line adjustment	LSU Out Top B/W*	Leading edge registration adjustment in black/white mode	LSU Out Top 3/4	Leading edge registration adjustment at 3/4 times of line speed		
Display	Description												
LSU Out Top	Leading edge registration adjustment												
LSU Out Left	Center line adjustment												
LSU Out Top B/W*	Leading edge registration adjustment in black/white mode												
LSU Out Top 3/4	Leading edge registration adjustment at 3/4 times of line speed												



Item No.	Description																																																																					
U034	Adjustment: Leading edge registration adjustment																																																																					
	1. Press the system menu key. 2. Press the start key to output a test pattern. 3. Press the system menu key. 4. Select the item to be adjusted.																																																																					
	[LSU Out Top]																																																																					
	<table border="1"> <thead> <tr> <th data-bbox="336 456 504 539">Display</th> <th data-bbox="504 456 959 539">Description</th> <th data-bbox="959 456 1110 539">Setting range</th> <th data-bbox="1110 456 1225 539">Initial setting</th> <th data-bbox="1225 456 1394 539">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 539 504 584">MPT(L)</td> <td data-bbox="504 539 959 584">Paper feed from MP tray</td> <td data-bbox="959 539 1110 584">-3.0 to 3.0</td> <td data-bbox="1110 539 1225 584">0</td> <td data-bbox="1225 539 1394 584">0.1 mm</td> </tr> <tr> <td data-bbox="336 584 504 629">MPT Half(L)</td> <td data-bbox="504 584 959 629">Paper feed from MP tray</td> <td data-bbox="959 584 1110 629">-3.0 to 3.0</td> <td data-bbox="1110 584 1225 629">0</td> <td data-bbox="1225 584 1394 629">0.1 mm</td> </tr> <tr> <td data-bbox="336 629 504 674">Cassette(L)</td> <td data-bbox="504 629 959 674">Paper feed from cassette</td> <td data-bbox="959 629 1110 674">-3.0 to 3.0</td> <td data-bbox="1110 629 1225 674">0</td> <td data-bbox="1225 629 1394 674">0.1 mm</td> </tr> <tr> <td data-bbox="336 674 504 763">Cassette Half(L)</td> <td data-bbox="504 674 959 763">Paper feed from cassette</td> <td data-bbox="959 674 1110 763">-3.0 to 3.0</td> <td data-bbox="1110 674 1225 763">0</td> <td data-bbox="1225 674 1394 763">0.1 mm</td> </tr> <tr> <td data-bbox="336 763 504 808">Duplex(L)</td> <td data-bbox="504 763 959 808">Duplex mode (second)</td> <td data-bbox="959 763 1110 808">-3.0 to 3.0</td> <td data-bbox="1110 763 1225 808">0</td> <td data-bbox="1225 763 1394 808">0.1 mm</td> </tr> <tr> <td data-bbox="336 808 504 898">Duplex Half(L)</td> <td data-bbox="504 808 959 898">Duplex mode (second)</td> <td data-bbox="959 808 1110 898">-3.0 to 3.0</td> <td data-bbox="1110 808 1225 898">0</td> <td data-bbox="1225 808 1394 898">0.1 mm</td> </tr> <tr> <td data-bbox="336 898 504 943">MPT(S)</td> <td data-bbox="504 898 959 943">Paper feed from MP tray</td> <td data-bbox="959 898 1110 943">-3.0 to 3.0</td> <td data-bbox="1110 898 1225 943">0</td> <td data-bbox="1225 898 1394 943">0.1 mm</td> </tr> <tr> <td data-bbox="336 943 504 1032">MPT Half(S)</td> <td data-bbox="504 943 959 1032">Paper feed from MP tray</td> <td data-bbox="959 943 1110 1032">-3.0 to 3.0</td> <td data-bbox="1110 943 1225 1032">0</td> <td data-bbox="1225 943 1394 1032">0.1 mm</td> </tr> <tr> <td data-bbox="336 1032 504 1077">Cassette(S)</td> <td data-bbox="504 1032 959 1077">Paper feed from cassette</td> <td data-bbox="959 1032 1110 1077">-3.0 to 3.0</td> <td data-bbox="1110 1032 1225 1077">0</td> <td data-bbox="1225 1032 1394 1077">0.1 mm</td> </tr> <tr> <td data-bbox="336 1077 504 1167">Cassette Half(S)</td> <td data-bbox="504 1077 959 1167">Paper feed from cassette</td> <td data-bbox="959 1077 1110 1167">-3.0 to 3.0</td> <td data-bbox="1110 1077 1225 1167">0</td> <td data-bbox="1225 1077 1394 1167">0.1 mm</td> </tr> <tr> <td data-bbox="336 1167 504 1211">Duplex(S)</td> <td data-bbox="504 1167 959 1211">Duplex mode (second)</td> <td data-bbox="959 1167 1110 1211">-3.0 to 3.0</td> <td data-bbox="1110 1167 1225 1211">0</td> <td data-bbox="1225 1167 1394 1211">0.1 mm</td> </tr> <tr> <td data-bbox="336 1211 504 1285">Duplex Half(S)</td> <td data-bbox="504 1211 959 1285">Duplex mode (second)</td> <td data-bbox="959 1211 1110 1285">-3.0 to 3.0</td> <td data-bbox="1110 1211 1225 1285">0</td> <td data-bbox="1225 1211 1394 1285">0.1 mm</td> </tr> </tbody> </table>					Display	Description	Setting range	Initial setting	Change in value per step	MPT(L)	Paper feed from MP tray	-3.0 to 3.0	0	0.1 mm	MPT Half(L)	Paper feed from MP tray	-3.0 to 3.0	0	0.1 mm	Cassette(L)	Paper feed from cassette	-3.0 to 3.0	0	0.1 mm	Cassette Half(L)	Paper feed from cassette	-3.0 to 3.0	0	0.1 mm	Duplex(L)	Duplex mode (second)	-3.0 to 3.0	0	0.1 mm	Duplex Half(L)	Duplex mode (second)	-3.0 to 3.0	0	0.1 mm	MPT(S)	Paper feed from MP tray	-3.0 to 3.0	0	0.1 mm	MPT Half(S)	Paper feed from MP tray	-3.0 to 3.0	0	0.1 mm	Cassette(S)	Paper feed from cassette	-3.0 to 3.0	0	0.1 mm	Cassette Half(S)	Paper feed from cassette	-3.0 to 3.0	0	0.1 mm	Duplex(S)	Duplex mode (second)	-3.0 to 3.0	0	0.1 mm	Duplex Half(S)	Duplex mode (second)	-3.0 to 3.0	0	0.1 mm
	Display	Description	Setting range	Initial setting	Change in value per step																																																																	
	MPT(L)	Paper feed from MP tray	-3.0 to 3.0	0	0.1 mm																																																																	
	MPT Half(L)	Paper feed from MP tray	-3.0 to 3.0	0	0.1 mm																																																																	
	Cassette(L)	Paper feed from cassette	-3.0 to 3.0	0	0.1 mm																																																																	
	Cassette Half(L)	Paper feed from cassette	-3.0 to 3.0	0	0.1 mm																																																																	
	Duplex(L)	Duplex mode (second)	-3.0 to 3.0	0	0.1 mm																																																																	
	Duplex Half(L)	Duplex mode (second)	-3.0 to 3.0	0	0.1 mm																																																																	
	MPT(S)	Paper feed from MP tray	-3.0 to 3.0	0	0.1 mm																																																																	
	MPT Half(S)	Paper feed from MP tray	-3.0 to 3.0	0	0.1 mm																																																																	
	Cassette(S)	Paper feed from cassette	-3.0 to 3.0	0	0.1 mm																																																																	
	Cassette Half(S)	Paper feed from cassette	-3.0 to 3.0	0	0.1 mm																																																																	
	Duplex(S)	Duplex mode (second)	-3.0 to 3.0	0	0.1 mm																																																																	
	Duplex Half(S)	Duplex mode (second)	-3.0 to 3.0	0	0.1 mm																																																																	
	(L): When large size paper is used (218 mm or more in width of paper).																																																																					
	(S): When small size paper is used.																																																																					
	[LSU Out Top B/W] [LSU Out Top 3/4]																																																																					
	<table border="1"> <thead> <tr> <th data-bbox="336 1420 504 1532">Display</th> <th data-bbox="504 1420 959 1532">Description</th> <th data-bbox="959 1420 1110 1532">Setting range</th> <th data-bbox="1110 1420 1225 1532">Initial setting</th> <th data-bbox="1225 1420 1394 1532">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1532 504 1576">MPT(L)</td> <td data-bbox="504 1532 959 1576">Paper feed from MP tray</td> <td data-bbox="959 1532 1110 1576">-3.0 to 3.0</td> <td data-bbox="1110 1532 1225 1576">0</td> <td data-bbox="1225 1532 1394 1576">0.1 mm</td> </tr> <tr> <td data-bbox="336 1576 504 1621">Cassette(L)</td> <td data-bbox="504 1576 959 1621">Paper feed from cassette</td> <td data-bbox="959 1576 1110 1621">-3.0 to 3.0</td> <td data-bbox="1110 1576 1225 1621">0</td> <td data-bbox="1225 1576 1394 1621">0.1 mm</td> </tr> <tr> <td data-bbox="336 1621 504 1666">Duplex(L)</td> <td data-bbox="504 1621 959 1666">Duplex mode (second)</td> <td data-bbox="959 1621 1110 1666">-3.0 to 3.0</td> <td data-bbox="1110 1621 1225 1666">0</td> <td data-bbox="1225 1621 1394 1666">0.1 mm</td> </tr> <tr> <td data-bbox="336 1666 504 1711">MPT(S)</td> <td data-bbox="504 1666 959 1711">Paper feed from MP tray</td> <td data-bbox="959 1666 1110 1711">-3.0 to 3.0</td> <td data-bbox="1110 1666 1225 1711">0</td> <td data-bbox="1225 1666 1394 1711">0.1 mm</td> </tr> <tr> <td data-bbox="336 1711 504 1756">Cassette(S)</td> <td data-bbox="504 1711 959 1756">Paper feed from cassette</td> <td data-bbox="959 1711 1110 1756">-3.0 to 3.0</td> <td data-bbox="1110 1711 1225 1756">0</td> <td data-bbox="1225 1711 1394 1756">0.1 mm</td> </tr> <tr> <td data-bbox="336 1756 504 1823">Duplex(S)</td> <td data-bbox="504 1756 959 1823">Duplex mode (second)</td> <td data-bbox="959 1756 1110 1823">-3.0 to 3.0</td> <td data-bbox="1110 1756 1225 1823">0</td> <td data-bbox="1225 1756 1394 1823">0.1 mm</td> </tr> </tbody> </table>					Display	Description	Setting range	Initial setting	Change in value per step	MPT(L)	Paper feed from MP tray	-3.0 to 3.0	0	0.1 mm	Cassette(L)	Paper feed from cassette	-3.0 to 3.0	0	0.1 mm	Duplex(L)	Duplex mode (second)	-3.0 to 3.0	0	0.1 mm	MPT(S)	Paper feed from MP tray	-3.0 to 3.0	0	0.1 mm	Cassette(S)	Paper feed from cassette	-3.0 to 3.0	0	0.1 mm	Duplex(S)	Duplex mode (second)	-3.0 to 3.0	0	0.1 mm																														
	Display	Description	Setting range	Initial setting	Change in value per step																																																																	
	MPT(L)	Paper feed from MP tray	-3.0 to 3.0	0	0.1 mm																																																																	
Cassette(L)	Paper feed from cassette	-3.0 to 3.0	0	0.1 mm																																																																		
Duplex(L)	Duplex mode (second)	-3.0 to 3.0	0	0.1 mm																																																																		
MPT(S)	Paper feed from MP tray	-3.0 to 3.0	0	0.1 mm																																																																		
Cassette(S)	Paper feed from cassette	-3.0 to 3.0	0	0.1 mm																																																																		
Duplex(S)	Duplex mode (second)	-3.0 to 3.0	0	0.1 mm																																																																		
(L): When large size paper is used (218 mm or more in width of paper).																																																																						
(S): When small size paper is used.																																																																						

Item No.	Description																																																		
U034	<p data-bbox="304 241 1340 309">5. Change the setting value using the cursor +/- or numeric keys. For output example 1, increase the value. For output example 2, decrease the value.</p> <div data-bbox="367 336 1197 660" style="text-align: center;">  <p data-bbox="367 353 526 443">Leading edge registration (20 ± 1.0 mm)</p> <p data-bbox="558 604 718 638">Correct image</p> <p data-bbox="813 604 941 660">Output example 1</p> <p data-bbox="1053 604 1181 660">Output example 2</p> </div> <p data-bbox="782 683 941 716">Figure 1-3-4</p> <p data-bbox="304 757 766 790">6. Press the start key. The value is set.</p> <p data-bbox="288 824 391 857">Remark</p> <p data-bbox="288 862 1412 929">When changing the setting value of [Large] each item is modified, equal to amount of the value which is changed adds also the value of [Small] each item and is pulled.</p> <p data-bbox="288 963 391 996">Caution</p> <p data-bbox="288 1001 1396 1068">Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="295 1086 901 1176" style="text-align: center;">  <pre> graph LR U034[U034] --> U066[U066 (P.1-3-54)] U066 --> U071[U071 (P.1-3-59)] </pre> </div> <p data-bbox="288 1261 742 1294">Adjustment: Center line adjustment</p> <ol data-bbox="304 1299 837 1433" style="list-style-type: none"> 1. Press the system menu key. 2. Press the start key to output a test pattern. 3. Press the system menu key. 4. Select the item to be adjusted. <table border="1" data-bbox="335 1444 1396 1960"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>MPT</td> <td>Paper feed from MP tray</td> <td>-3.0 to 3.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>Cassette1</td> <td>Paper feed from cassette 1</td> <td>-3.0 to 3.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>Cassette2</td> <td>Paper feed from cassette 2</td> <td>-3.0 to 3.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>Cassette3</td> <td>Paper feed from optional cassette 3</td> <td>-3.0 to 3.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>Cassette4</td> <td>Paper feed from optional cassette 4</td> <td>-3.0 to 3.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>Cassette5</td> <td>Paper feed from optional cassette 5</td> <td>-3.0 to 3.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>Cassette6</td> <td>Paper feed from optional cassette 6*</td> <td>-3.0 to 3.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>Cassette7</td> <td>Paper feed from optional cassette 7*</td> <td>-3.0 to 3.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>Duplex</td> <td>Duplex mode (second)</td> <td>-3.0 to 3.0</td> <td>0</td> <td>0.1 mm</td> </tr> </tbody> </table> <p data-bbox="335 1971 694 2004">*: 45 ppm/55 ppm model only.</p>	Display	Description	Setting range	Initial setting	Change in value per step	MPT	Paper feed from MP tray	-3.0 to 3.0	0	0.1 mm	Cassette1	Paper feed from cassette 1	-3.0 to 3.0	0	0.1 mm	Cassette2	Paper feed from cassette 2	-3.0 to 3.0	0	0.1 mm	Cassette3	Paper feed from optional cassette 3	-3.0 to 3.0	0	0.1 mm	Cassette4	Paper feed from optional cassette 4	-3.0 to 3.0	0	0.1 mm	Cassette5	Paper feed from optional cassette 5	-3.0 to 3.0	0	0.1 mm	Cassette6	Paper feed from optional cassette 6*	-3.0 to 3.0	0	0.1 mm	Cassette7	Paper feed from optional cassette 7*	-3.0 to 3.0	0	0.1 mm	Duplex	Duplex mode (second)	-3.0 to 3.0	0	0.1 mm
Display	Description	Setting range	Initial setting	Change in value per step																																															
MPT	Paper feed from MP tray	-3.0 to 3.0	0	0.1 mm																																															
Cassette1	Paper feed from cassette 1	-3.0 to 3.0	0	0.1 mm																																															
Cassette2	Paper feed from cassette 2	-3.0 to 3.0	0	0.1 mm																																															
Cassette3	Paper feed from optional cassette 3	-3.0 to 3.0	0	0.1 mm																																															
Cassette4	Paper feed from optional cassette 4	-3.0 to 3.0	0	0.1 mm																																															
Cassette5	Paper feed from optional cassette 5	-3.0 to 3.0	0	0.1 mm																																															
Cassette6	Paper feed from optional cassette 6*	-3.0 to 3.0	0	0.1 mm																																															
Cassette7	Paper feed from optional cassette 7*	-3.0 to 3.0	0	0.1 mm																																															
Duplex	Duplex mode (second)	-3.0 to 3.0	0	0.1 mm																																															




Item No.	Description
U034	<p data-bbox="304 241 1342 309">5. Change the setting value using the +/- keys or numeric keys. For output example 1, increase the value. For output example 2, decrease the value.</p> <div data-bbox="533 331 1187 725" style="text-align: center;"> <p data-bbox="533 331 767 394">Center line of printing (within ± 2.0 mm)</p>  <p data-bbox="549 667 708 696">Correct image</p> <p data-bbox="815 667 927 725">Output example 1</p> <p data-bbox="1050 667 1166 725">Output example 2</p> </div> <p data-bbox="783 752 938 786">Figure 1-3-5</p> <p data-bbox="304 824 767 857">6. Press the start key. The value is set.</p> <p data-bbox="288 891 395 920">Caution</p> <p data-bbox="288 927 1406 994">Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="293 1010 903 1106" style="text-align: center;">  <pre> graph LR U034[U034] --> U067[U067 (P.1-3-55)] U067 --> U072[U072 (P.1-3-61)] </pre> </div> <p data-bbox="288 1155 443 1189">Completion</p> <p data-bbox="288 1196 1257 1229">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>


Item No.	Description												
U035	<p data-bbox="290 241 788 273">Setting the printing area for folio paper</p> <p data-bbox="290 311 440 342">Description</p> <p data-bbox="290 344 911 376">Changes the printing area for copying on folio paper.</p> <p data-bbox="290 380 400 412">Purpose</p> <p data-bbox="290 414 1374 479">To prevent cropped images on the trailing edge or left/right side of copy paper by setting the actual printing area for folio paper.</p> <p data-bbox="290 517 384 548">Setting</p> <ol data-bbox="308 553 858 651" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. 3. Change the setting value using the +/- keys. <table border="1" data-bbox="336 665 1399 808"> <thead> <tr> <th data-bbox="336 665 564 712">Display</th> <th data-bbox="564 665 943 712">Description</th> <th data-bbox="943 665 1171 712">Setting range</th> <th data-bbox="1171 665 1399 712">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 712 564 759">Length</td> <td data-bbox="564 712 943 759">Length</td> <td data-bbox="943 712 1171 759">330 to 356 mm</td> <td data-bbox="1171 712 1399 759">330</td> </tr> <tr> <td data-bbox="336 759 564 808">Width</td> <td data-bbox="564 759 943 808">Width</td> <td data-bbox="943 759 1171 808">200 to 220 mm</td> <td data-bbox="1171 759 1399 808">210</td> </tr> </tbody> </table> <ol data-bbox="308 822 766 853" style="list-style-type: none"> 4. Press the start key. The value is set. <p data-bbox="290 891 440 922">Completion</p> <p data-bbox="290 925 1254 956">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Length	Length	330 to 356 mm	330	Width	Width	200 to 220 mm	210
Display	Description	Setting range	Initial setting										
Length	Length	330 to 356 mm	330										
Width	Width	200 to 220 mm	210										

Item No.	Description																																																
U037	<p data-bbox="288 241 815 271">Checking the operation of the fan motors</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 560 374">Drives each fan motor.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 783 443">To check the operation of each fan motor.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="304 517 815 618" style="list-style-type: none"> 1. Press the start key. 2. Select the fan motor to be operated. 3. Press the start key. The operation starts. <table border="1" data-bbox="336 633 1399 1400"> <thead> <tr> <th data-bbox="336 633 571 678">Display</th> <th data-bbox="571 633 1294 678">Description</th> <th data-bbox="1294 633 1399 678">Group</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 678 571 723">Fuser Cooling</td> <td data-bbox="571 678 1294 723">Fuser rear fan motor (FURFM) is turned on</td> <td data-bbox="1294 678 1399 723">B</td> </tr> <tr> <td data-bbox="336 723 571 768">DLP Rear</td> <td data-bbox="571 723 1294 768">Exhaust motor 1and 2 (EXFM1, 2) is turned on</td> <td data-bbox="1294 723 1399 768">A</td> </tr> <tr> <td data-bbox="336 768 571 813">LSU Cooling</td> <td data-bbox="571 768 1294 813">LSU fan motor (LSUFM) is turned on</td> <td data-bbox="1294 768 1399 813">B</td> </tr> <tr> <td data-bbox="336 813 571 857">Belt Cooling</td> <td data-bbox="571 813 1294 857">Belt fan motor 1and 2 (BLFM1, 2) is turned on</td> <td data-bbox="1294 813 1399 857">A</td> </tr> <tr> <td data-bbox="336 857 571 902">Exit Cooling</td> <td data-bbox="571 857 1294 902">Eject front fan motor (EFFM) is turned on</td> <td data-bbox="1294 857 1399 902">B</td> </tr> <tr> <td data-bbox="336 902 571 947">Toner</td> <td data-bbox="571 902 1294 947">Toner fan motor 1and 2 (TFM1, 2) is turned on</td> <td data-bbox="1294 902 1399 947">A</td> </tr> <tr> <td data-bbox="336 947 571 992">Low Volt</td> <td data-bbox="571 947 1294 992">Power source fan motor (PSFM) is turned on</td> <td data-bbox="1294 947 1399 992">A</td> </tr> <tr> <td data-bbox="336 992 571 1037">Exit Rear Cooling</td> <td data-bbox="571 992 1294 1037">Eject rear fan motor (EFRM) is turned on</td> <td data-bbox="1294 992 1399 1037">B</td> </tr> <tr> <td data-bbox="336 1037 571 1081">IH PWB</td> <td data-bbox="571 1037 1294 1081">IH fan motor (IHFM) is turned on</td> <td data-bbox="1294 1037 1399 1081">A</td> </tr> <tr> <td data-bbox="336 1081 571 1126">IH Coil</td> <td data-bbox="571 1081 1294 1126">Fuser front fan motor (FUFFM) is turned on</td> <td data-bbox="1294 1081 1399 1126">A</td> </tr> <tr> <td data-bbox="336 1126 571 1171">DLP Front</td> <td data-bbox="571 1126 1294 1171">Developer fan motor 1and 2 (DEVFM1, 2) is turned on</td> <td data-bbox="1294 1126 1399 1171">A</td> </tr> <tr> <td data-bbox="336 1171 571 1216">Conv Edge</td> <td data-bbox="571 1171 1294 1216">Fuser fan motor 1and 2 (FUFM1, 2) is turned on</td> <td data-bbox="1294 1171 1399 1216">A</td> </tr> <tr> <td data-bbox="336 1216 571 1261">Fuser Edge</td> <td data-bbox="571 1216 1294 1261">Fuser edge fan motor 1and 2 (FUEFM1, 2) is turned on</td> <td data-bbox="1294 1216 1399 1261">-</td> </tr> <tr> <td data-bbox="336 1261 571 1305">GroupA</td> <td data-bbox="571 1261 1294 1305">Fan motors of group A are turned on</td> <td data-bbox="1294 1261 1399 1305"></td> </tr> <tr> <td data-bbox="336 1305 571 1350">GroupB</td> <td data-bbox="571 1305 1294 1350">Fan motors of group B are turned on</td> <td data-bbox="1294 1305 1399 1350"></td> </tr> </tbody> </table> <ol data-bbox="304 1406 783 1435" style="list-style-type: none"> 4. To stop operation, press the stop key. <p data-bbox="288 1476 440 1505">Completion</p> <p data-bbox="288 1509 1254 1538">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Group	Fuser Cooling	Fuser rear fan motor (FURFM) is turned on	B	DLP Rear	Exhaust motor 1and 2 (EXFM1, 2) is turned on	A	LSU Cooling	LSU fan motor (LSUFM) is turned on	B	Belt Cooling	Belt fan motor 1and 2 (BLFM1, 2) is turned on	A	Exit Cooling	Eject front fan motor (EFFM) is turned on	B	Toner	Toner fan motor 1and 2 (TFM1, 2) is turned on	A	Low Volt	Power source fan motor (PSFM) is turned on	A	Exit Rear Cooling	Eject rear fan motor (EFRM) is turned on	B	IH PWB	IH fan motor (IHFM) is turned on	A	IH Coil	Fuser front fan motor (FUFFM) is turned on	A	DLP Front	Developer fan motor 1and 2 (DEVFM1, 2) is turned on	A	Conv Edge	Fuser fan motor 1and 2 (FUFM1, 2) is turned on	A	Fuser Edge	Fuser edge fan motor 1and 2 (FUEFM1, 2) is turned on	-	GroupA	Fan motors of group A are turned on		GroupB	Fan motors of group B are turned on	
Display	Description	Group																																															
Fuser Cooling	Fuser rear fan motor (FURFM) is turned on	B																																															
DLP Rear	Exhaust motor 1and 2 (EXFM1, 2) is turned on	A																																															
LSU Cooling	LSU fan motor (LSUFM) is turned on	B																																															
Belt Cooling	Belt fan motor 1and 2 (BLFM1, 2) is turned on	A																																															
Exit Cooling	Eject front fan motor (EFFM) is turned on	B																																															
Toner	Toner fan motor 1and 2 (TFM1, 2) is turned on	A																																															
Low Volt	Power source fan motor (PSFM) is turned on	A																																															
Exit Rear Cooling	Eject rear fan motor (EFRM) is turned on	B																																															
IH PWB	IH fan motor (IHFM) is turned on	A																																															
IH Coil	Fuser front fan motor (FUFFM) is turned on	A																																															
DLP Front	Developer fan motor 1and 2 (DEVFM1, 2) is turned on	A																																															
Conv Edge	Fuser fan motor 1and 2 (FUFM1, 2) is turned on	A																																															
Fuser Edge	Fuser edge fan motor 1and 2 (FUEFM1, 2) is turned on	-																																															
GroupA	Fan motors of group A are turned on																																																
GroupB	Fan motors of group B are turned on																																																

Item No.	Description										
<p>U039</p>	<p>Adjusting the magnification</p> <p>Description Adjusts the magnification of the printing.</p> <p>Purpose Make the adjustment if the magnification in the auxiliary scanning direction is incorrect.</p> <p>Caution Adjust the magnification in the following order.</p> <div style="text-align: center;">  <pre> graph LR U039[U039] --> U065[U065 (P.1-3-52)] U065 --> U070[U070 (P.1-3-57)] </pre> </div> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Press the start key to output a test pattern. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="338 929 1401 1093"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Sub Scan</td> <td>Magnification in the auxiliary scanning direction</td> <td>-1 to 1</td> <td>0</td> <td>0.1 %</td> </tr> </tbody> </table> <p>Adjustment: [Sub Scan]</p> <ol style="list-style-type: none"> 1. Change the setting value using the +/- keys or numeric keys. Increasing the value makes the image longer, while decreasing the value makes the image shorter. <div style="text-align: center;">  </div> <p>Figure 1-3-6</p> <ol style="list-style-type: none"> 2. Press the start key. The value is set. <p>Completion Press the stop key. The indication for selecting a maintenance item No. appears.</p>	Display	Description	Setting range	Initial setting	Change in value per step	Sub Scan	Magnification in the auxiliary scanning direction	-1 to 1	0	0.1 %
Display	Description	Setting range	Initial setting	Change in value per step							
Sub Scan	Magnification in the auxiliary scanning direction	-1 to 1	0	0.1 %							

Item No.	Description																																																																																																							
U051	<p data-bbox="288 241 756 273">Adjusting the deflection in the paper</p> <p data-bbox="288 311 440 338">Description</p> <p data-bbox="288 344 979 376">Adjusts the deflection in the paper at the registration roller.</p> <p data-bbox="288 383 400 409">Purpose</p> <p data-bbox="288 416 1426 479">Make the adjustment if the leading edge of the copy image is missing or varies randomly, or if the copy paper is Z-folded.</p> <p data-bbox="288 517 387 544">Method</p> <ol data-bbox="304 553 695 616" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be adjusted. <table border="1" data-bbox="336 631 1401 824"> <thead> <tr> <th data-bbox="336 631 679 676">Display</th> <th data-bbox="679 631 1401 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 676 679 721">Paper Loop Amount</td> <td data-bbox="679 676 1401 721">Deflection adjustment</td> </tr> <tr> <td data-bbox="336 721 679 766">Paper Loop Amount B/W*</td> <td data-bbox="679 721 1401 766">Deflection adjustment in black and white mode</td> </tr> <tr> <td data-bbox="336 766 679 810">Paper Loop Amount 3/4</td> <td data-bbox="679 766 1401 810">Deflection adjustment at 3/4 times of line speed</td> </tr> </tbody> </table> <p data-bbox="336 835 592 866">*: 55 ppm model only.</p> <p data-bbox="288 904 440 931">Adjustment</p> <ol data-bbox="304 940 1054 1070" style="list-style-type: none"> 1. Press the system menu key. 2. Place an original and press the start key to make a test copy. 3. Press the system menu key. 4. Select the item to be adjusted. <p data-bbox="336 1077 592 1108">[Paper Loop Amount]</p> <table border="1" data-bbox="336 1122 1401 1928"> <thead> <tr> <th data-bbox="336 1122 520 1211" rowspan="2">Display</th> <th data-bbox="520 1122 855 1211" rowspan="2">Description</th> <th data-bbox="855 1122 999 1211" rowspan="2">Setting range</th> <th colspan="4" data-bbox="999 1122 1401 1167">Initial setting</th> </tr> <tr> <th data-bbox="999 1167 1102 1211">30ppm</th> <th data-bbox="1102 1167 1206 1211">35ppm</th> <th data-bbox="1206 1167 1302 1211">45ppm</th> <th data-bbox="1302 1167 1401 1211">55ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1211 520 1256">MPT(L)</td> <td data-bbox="520 1211 855 1256">Paper feed from MP tray</td> <td data-bbox="855 1211 999 1256">-30 to 20</td> <td data-bbox="999 1211 1102 1256">1</td> <td data-bbox="1102 1211 1206 1256">1</td> <td data-bbox="1206 1211 1302 1256">-5</td> <td data-bbox="1302 1211 1401 1256">-7</td> </tr> <tr> <td data-bbox="336 1256 520 1301">MPT Half(L)</td> <td data-bbox="520 1256 855 1301">Paper feed from MP tray</td> <td data-bbox="855 1256 999 1301">-30 to 20</td> <td data-bbox="999 1256 1102 1301">1</td> <td data-bbox="1102 1256 1206 1301">1</td> <td data-bbox="1206 1256 1302 1301">0</td> <td data-bbox="1302 1256 1401 1301">-1</td> </tr> <tr> <td data-bbox="336 1301 520 1346">Cassette(L)</td> <td data-bbox="520 1301 855 1346">Paper feed from cassette</td> <td data-bbox="855 1301 999 1346">-30 to 20</td> <td data-bbox="999 1301 1102 1346">1</td> <td data-bbox="1102 1301 1206 1346">1</td> <td data-bbox="1206 1301 1302 1346">-5</td> <td data-bbox="1302 1301 1401 1346">-7</td> </tr> <tr> <td data-bbox="336 1346 520 1435">Cassette Half(L)</td> <td data-bbox="520 1346 855 1435">Paper feed from cassette</td> <td data-bbox="855 1346 999 1435">-30 to 20</td> <td data-bbox="999 1346 1102 1435">1</td> <td data-bbox="1102 1346 1206 1435">1</td> <td data-bbox="1206 1346 1302 1435">0</td> <td data-bbox="1302 1346 1401 1435">-1</td> </tr> <tr> <td data-bbox="336 1435 520 1480">Duplex(L)</td> <td data-bbox="520 1435 855 1480">Duplex mode (second)</td> <td data-bbox="855 1435 999 1480">-30 to 20</td> <td data-bbox="999 1435 1102 1480">1</td> <td data-bbox="1102 1435 1206 1480">1</td> <td data-bbox="1206 1435 1302 1480">-5</td> <td data-bbox="1302 1435 1401 1480">-7</td> </tr> <tr> <td data-bbox="336 1480 520 1570">Duplex Half(L)</td> <td data-bbox="520 1480 855 1570">Duplex mode (second)</td> <td data-bbox="855 1480 999 1570">-30 to 20</td> <td data-bbox="999 1480 1102 1570">1</td> <td data-bbox="1102 1480 1206 1570">1</td> <td data-bbox="1206 1480 1302 1570">0</td> <td data-bbox="1302 1480 1401 1570">-1</td> </tr> <tr> <td data-bbox="336 1570 520 1615">MPT(S)</td> <td data-bbox="520 1570 855 1615">Paper feed from MP tray</td> <td data-bbox="855 1570 999 1615">-30 to 20</td> <td data-bbox="999 1570 1102 1615">1</td> <td data-bbox="1102 1570 1206 1615">1</td> <td data-bbox="1206 1570 1302 1615">-5</td> <td data-bbox="1302 1570 1401 1615">-7</td> </tr> <tr> <td data-bbox="336 1615 520 1659">MPT Half(S)</td> <td data-bbox="520 1615 855 1659">Paper feed from MP tray</td> <td data-bbox="855 1615 999 1659">-30 to 20</td> <td data-bbox="999 1615 1102 1659">1</td> <td data-bbox="1102 1615 1206 1659">1</td> <td data-bbox="1206 1615 1302 1659">0</td> <td data-bbox="1302 1615 1401 1659">-1</td> </tr> <tr> <td data-bbox="336 1659 520 1704">Cassette(S)</td> <td data-bbox="520 1659 855 1704">Paper feed from cassette</td> <td data-bbox="855 1659 999 1704">-30 to 20</td> <td data-bbox="999 1659 1102 1704">1</td> <td data-bbox="1102 1659 1206 1704">1</td> <td data-bbox="1206 1659 1302 1704">-6</td> <td data-bbox="1302 1659 1401 1704">-8</td> </tr> <tr> <td data-bbox="336 1704 520 1794">Cassette Half(S)</td> <td data-bbox="520 1704 855 1794">Paper feed from cassette</td> <td data-bbox="855 1704 999 1794">-30 to 20</td> <td data-bbox="999 1704 1102 1794">1</td> <td data-bbox="1102 1704 1206 1794">1</td> <td data-bbox="1206 1704 1302 1794">-1</td> <td data-bbox="1302 1704 1401 1794">-2</td> </tr> <tr> <td data-bbox="336 1794 520 1839">Duplex(S)</td> <td data-bbox="520 1794 855 1839">Duplex mode (second)</td> <td data-bbox="855 1794 999 1839">-30 to 20</td> <td data-bbox="999 1794 1102 1839">1</td> <td data-bbox="1102 1794 1206 1839">1</td> <td data-bbox="1206 1794 1302 1839">-5</td> <td data-bbox="1302 1794 1401 1839">-7</td> </tr> <tr> <td data-bbox="336 1839 520 1928">Duplex Half(S)</td> <td data-bbox="520 1839 855 1928">Duplex mode (second)</td> <td data-bbox="855 1839 999 1928">-30 to 20</td> <td data-bbox="999 1839 1102 1928">1</td> <td data-bbox="1102 1839 1206 1928">1</td> <td data-bbox="1206 1839 1302 1928">0</td> <td data-bbox="1302 1839 1401 1928">-1</td> </tr> </tbody> </table> <p data-bbox="336 1939 740 1971">Change in value per step: 1.0 mm</p> <p data-bbox="336 1977 1174 2009">(L): When large size paper is used (218 mm or more in width of paper).</p> <p data-bbox="336 2013 756 2045">(S): When small size paper is used.</p>	Display	Description	Paper Loop Amount	Deflection adjustment	Paper Loop Amount B/W*	Deflection adjustment in black and white mode	Paper Loop Amount 3/4	Deflection adjustment at 3/4 times of line speed	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	MPT(L)	Paper feed from MP tray	-30 to 20	1	1	-5	-7	MPT Half(L)	Paper feed from MP tray	-30 to 20	1	1	0	-1	Cassette(L)	Paper feed from cassette	-30 to 20	1	1	-5	-7	Cassette Half(L)	Paper feed from cassette	-30 to 20	1	1	0	-1	Duplex(L)	Duplex mode (second)	-30 to 20	1	1	-5	-7	Duplex Half(L)	Duplex mode (second)	-30 to 20	1	1	0	-1	MPT(S)	Paper feed from MP tray	-30 to 20	1	1	-5	-7	MPT Half(S)	Paper feed from MP tray	-30 to 20	1	1	0	-1	Cassette(S)	Paper feed from cassette	-30 to 20	1	1	-6	-8	Cassette Half(S)	Paper feed from cassette	-30 to 20	1	1	-1	-2	Duplex(S)	Duplex mode (second)	-30 to 20	1	1	-5	-7	Duplex Half(S)	Duplex mode (second)	-30 to 20	1	1	0	-1
Display	Description																																																																																																							
Paper Loop Amount	Deflection adjustment																																																																																																							
Paper Loop Amount B/W*	Deflection adjustment in black and white mode																																																																																																							
Paper Loop Amount 3/4	Deflection adjustment at 3/4 times of line speed																																																																																																							
Display	Description	Setting range	Initial setting																																																																																																					
			30ppm	35ppm	45ppm	55ppm																																																																																																		
MPT(L)	Paper feed from MP tray	-30 to 20	1	1	-5	-7																																																																																																		
MPT Half(L)	Paper feed from MP tray	-30 to 20	1	1	0	-1																																																																																																		
Cassette(L)	Paper feed from cassette	-30 to 20	1	1	-5	-7																																																																																																		
Cassette Half(L)	Paper feed from cassette	-30 to 20	1	1	0	-1																																																																																																		
Duplex(L)	Duplex mode (second)	-30 to 20	1	1	-5	-7																																																																																																		
Duplex Half(L)	Duplex mode (second)	-30 to 20	1	1	0	-1																																																																																																		
MPT(S)	Paper feed from MP tray	-30 to 20	1	1	-5	-7																																																																																																		
MPT Half(S)	Paper feed from MP tray	-30 to 20	1	1	0	-1																																																																																																		
Cassette(S)	Paper feed from cassette	-30 to 20	1	1	-6	-8																																																																																																		
Cassette Half(S)	Paper feed from cassette	-30 to 20	1	1	-1	-2																																																																																																		
Duplex(S)	Duplex mode (second)	-30 to 20	1	1	-5	-7																																																																																																		
Duplex Half(S)	Duplex mode (second)	-30 to 20	1	1	0	-1																																																																																																		

Item No.	Description						
U051	[Paper Loop Amount B/W]						
	Display	Description	Setting range	Initial setting			
				30ppm	35ppm	45ppm	55ppm
	MPT(L)	Paper feed from MP tray	-30 to 20	-	-	-	-8
	Cassette(L)	Paper feed from cassette	-30 to 20	-	-	-	-8
	Duplex(L)	Duplex mode (second)	-30 to 20	-	-	-	-8
	MPT(S)	Paper feed from MP tray	-30 to 20	-	-	-	-8
	Cassette(S)	Paper feed from cassette	-30 to 20	-	-	-	-9
	Duplex(S)	Duplex mode (second)	-30 to 20	-	-	-	-8
	Change in value per step: 1.0 mm						
	(L): When large size paper is used (218 mm or more in width of paper).						
	(S): When small size paper is used.						
	[Paper Loop Amount 3/4]						
	Display	Description	Setting range	Initial setting			
				30ppm	35ppm	45ppm	55ppm
	MPT(L)	Paper feed from MP tray	-30 to 20	1	1	-2	-2
	Cassette(L)	Paper feed from cassette	-30 to 20	1	1	-2	-2
	Duplex(L)	Duplex mode (second)	-30 to 20	1	1	-2	-2
	MPT(S)	Paper feed from MP tray	-30 to 20	1	1	-2	-2
	Cassette(S)	Paper feed from cassette	-30 to 20	1	1	-3	-3
	Duplex(S)	Duplex mode (second)	-30 to 20	1	1	-2	-2
	Change in value per step: 1.0 mm						
	(L): When large size paper is used (218 mm or more in width of paper).						
	(S): When small size paper is used.						
	5. Change the setting value using the +/- keys or numeric keys.						
For output example 1, increase the value. For output example 2, decrease the value.							
The greater the value, the larger the deflection; the smaller the value, the smaller the deflection.							
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Original</p> </div> <div style="text-align: center;">  <p>Copy example 1</p> </div> <div style="text-align: center;">  <p>Copy example 2</p> </div> </div>							
Figure 1-3-7							
6. Press the start key. The value is set.							
Completion							
Press the stop key. The indication for selecting a maintenance item No. appears.							

Item No.	Description																							
U052	<p>Setting the fuser motor control</p> <p>Description Enters the sensor data values described on the supplied sheet provided when the loop sensor is replaced and performs correction processing for the fuser motor.</p> <p>Purpose To perform when replacing the loop sensor or paper conveying unit.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 631 1401 824"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Set Loop Sensor</td> <td>Enter the data value for loop sensor</td> </tr> <tr> <td>Loop Sensor Control</td> <td>Set the loop sensor detection control</td> </tr> <tr> <td>Set Loop Sensor Valid</td> <td>Sets the presence or absence of the loop sensor</td> </tr> </tbody> </table> <p>Method: [Set Loop Sensor]</p> <ol style="list-style-type: none"> 1. Select [Scanning Board1]. 2. Enter the sensor data value of supplied sheet DATA1 using the +/- keys. 3. Select [Scanning Board2]. 4. Enter the sensor data value of supplied sheet DATA2 using the +/- keys. 5. Press the start key. The value is set. <p style="text-align: right;">How to read the sensor data value</p> <p>(e.g.)</p>  <p>Setting: [Loop Sensor Control]</p> <ol style="list-style-type: none"> 1. Select the item. 2. Select On or Off. <table border="1" data-bbox="336 1339 1401 1715"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>No.1</td> <td>Sensor detection On/Off setting at 125 to 250 mm from the top of paper</td> <td>On</td> </tr> <tr> <td>No.2</td> <td>Sensor detection On/Off setting at 250 to 290 mm from the top of paper</td> <td>On</td> </tr> <tr> <td>No.3</td> <td>Sensor detection On/Off setting at 300 to 330 mm from the top of paper</td> <td>On</td> </tr> <tr> <td>No.4</td> <td>Sensor detection On/Off setting at 350 to 370 mm from the top of paper</td> <td>On</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Setting: [Set Loop Sensor Valid]</p> <ol style="list-style-type: none"> 1. Select On or Off. Initial setting: On 2. Press the start key. The setting is set. <p>Completion Press the stop key. The indication for selecting a maintenance item No. appears.</p>	Display	Description	Set Loop Sensor	Enter the data value for loop sensor	Loop Sensor Control	Set the loop sensor detection control	Set Loop Sensor Valid	Sets the presence or absence of the loop sensor	Display	Description	Initial setting	No.1	Sensor detection On/Off setting at 125 to 250 mm from the top of paper	On	No.2	Sensor detection On/Off setting at 250 to 290 mm from the top of paper	On	No.3	Sensor detection On/Off setting at 300 to 330 mm from the top of paper	On	No.4	Sensor detection On/Off setting at 350 to 370 mm from the top of paper	On
Display	Description																							
Set Loop Sensor	Enter the data value for loop sensor																							
Loop Sensor Control	Set the loop sensor detection control																							
Set Loop Sensor Valid	Sets the presence or absence of the loop sensor																							
Display	Description	Initial setting																						
No.1	Sensor detection On/Off setting at 125 to 250 mm from the top of paper	On																						
No.2	Sensor detection On/Off setting at 250 to 290 mm from the top of paper	On																						
No.3	Sensor detection On/Off setting at 300 to 330 mm from the top of paper	On																						
No.4	Sensor detection On/Off setting at 350 to 370 mm from the top of paper	On																						

Item No.	Description																																												
U053	<p data-bbox="288 241 829 275">Setting the adjustment of the motor speed</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 927 374">Performs fine adjustment of the speeds of the motors.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1362 479">Basically, the setting need not be changed. Modify settings by interlock setting only if faulty images occur.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 553 691 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be adjusted <table border="1" data-bbox="336 631 1399 1668"> <thead> <tr> <th data-bbox="336 631 528 676">Display</th> <th data-bbox="528 631 1399 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 676 528 721">Motor1</td> <td data-bbox="528 676 1399 721">Adjustment of drum motor K speeds</td> </tr> <tr> <td data-bbox="336 721 528 810">Motor2</td> <td data-bbox="528 721 1399 810">Adjustment of developer motor K, developer motor MCY, transfer motor, registration motor and transfer cleaning motor speeds</td> </tr> <tr> <td data-bbox="336 810 528 900">Motor3</td> <td data-bbox="528 810 1399 900">Adjustment of eject motor, fuser motor, BR conveying motor 1/2, paper feed motor, JS eject motor, middle motor and duplex motor 1/2 speeds</td> </tr> <tr> <td data-bbox="336 900 528 945">Motor4</td> <td data-bbox="528 900 1399 945">Drum motor K speed adjustment in black/white mode</td> </tr> <tr> <td data-bbox="336 945 528 1034">Motor5*</td> <td data-bbox="528 945 1399 1034">Adjustment of developer motor K, transfer motor, registration motor and transfer cleaning motor speeds in black/white mode</td> </tr> <tr> <td data-bbox="336 1034 528 1124">Motor6*</td> <td data-bbox="528 1034 1399 1124">Adjustment of eject motor, fuser motor, BR conveying motor 1/2, paper feed motor, JS eject motor, middle motor and duplex motor 1/2 speeds in black/white mode</td> </tr> <tr> <td data-bbox="336 1124 528 1169">Motor1 Half</td> <td data-bbox="528 1124 1399 1169">Adjustment of drum motor K speeds in half speed</td> </tr> <tr> <td data-bbox="336 1169 528 1258">Motor2 Half</td> <td data-bbox="528 1169 1399 1258">Adjustment of developer motor K, developer motor MCY, transfer motor, registration motor and transfer cleaning motor speeds in half speed</td> </tr> <tr> <td data-bbox="336 1258 528 1348">Motor3 Half</td> <td data-bbox="528 1258 1399 1348">Adjustment of eject motor, fuser motor, BR conveying motor 1/2, paper feed motor, JS eject motor, middle motor and duplex motor 1/2 speeds in half speed</td> </tr> <tr> <td data-bbox="336 1348 528 1393">Motor1 3/4</td> <td data-bbox="528 1348 1399 1393">Adjustment of drum motor K speeds at 3/4 times of line speed</td> </tr> <tr> <td data-bbox="336 1393 528 1482">Motor2 3/4</td> <td data-bbox="528 1393 1399 1482">Adjustment of developer motor K, developer motor MCY, transfer motor, registration motor and transfer cleaning motor speeds at 3/4 times of line speed</td> </tr> <tr> <td data-bbox="336 1482 528 1572">Motor3 3/4</td> <td data-bbox="528 1482 1399 1572">Adjustment of eject motor, fuser motor, BR conveying motor 1/2, paper feed motor, JS eject motor, middle motor and duplex motor 1/2 speeds at 3/4 times of line speed</td> </tr> </tbody> </table> <p data-bbox="336 1682 595 1711">*: 55 ppm model only.</p> <p data-bbox="288 1749 507 1778">Setting: [Motor1]</p> <ol data-bbox="304 1785 697 1814" style="list-style-type: none"> 1. Select the item to be adjusted. <table border="1" data-bbox="336 1827 1399 1973"> <thead> <tr> <th data-bbox="336 1827 491 1872" rowspan="2">Display</th> <th data-bbox="491 1827 815 1872" rowspan="2">Description</th> <th data-bbox="815 1827 1007 1872" rowspan="2">Setting range</th> <th colspan="4" data-bbox="1007 1827 1399 1872">Initial setting</th> </tr> <tr> <th data-bbox="1007 1872 1102 1917">30ppm</th> <th data-bbox="1102 1872 1198 1917">35ppm</th> <th data-bbox="1198 1872 1294 1917">45ppm</th> <th data-bbox="1294 1872 1399 1917">55ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1917 491 1973">Drum(K)</td> <td data-bbox="491 1917 815 1973">Drum motor K (DRM-K)</td> <td data-bbox="815 1917 1007 1973">-5000 to 5000</td> <td data-bbox="1007 1917 1102 1973">19</td> <td data-bbox="1102 1917 1198 1973">16</td> <td data-bbox="1198 1917 1294 1973">12</td> <td data-bbox="1294 1917 1399 1973">11</td> </tr> </tbody> </table>	Display	Description	Motor1	Adjustment of drum motor K speeds	Motor2	Adjustment of developer motor K, developer motor MCY, transfer motor, registration motor and transfer cleaning motor speeds	Motor3	Adjustment of eject motor, fuser motor, BR conveying motor 1/2, paper feed motor, JS eject motor, middle motor and duplex motor 1/2 speeds	Motor4	Drum motor K speed adjustment in black/white mode	Motor5*	Adjustment of developer motor K, transfer motor, registration motor and transfer cleaning motor speeds in black/white mode	Motor6*	Adjustment of eject motor, fuser motor, BR conveying motor 1/2, paper feed motor, JS eject motor, middle motor and duplex motor 1/2 speeds in black/white mode	Motor1 Half	Adjustment of drum motor K speeds in half speed	Motor2 Half	Adjustment of developer motor K, developer motor MCY, transfer motor, registration motor and transfer cleaning motor speeds in half speed	Motor3 Half	Adjustment of eject motor, fuser motor, BR conveying motor 1/2, paper feed motor, JS eject motor, middle motor and duplex motor 1/2 speeds in half speed	Motor1 3/4	Adjustment of drum motor K speeds at 3/4 times of line speed	Motor2 3/4	Adjustment of developer motor K, developer motor MCY, transfer motor, registration motor and transfer cleaning motor speeds at 3/4 times of line speed	Motor3 3/4	Adjustment of eject motor, fuser motor, BR conveying motor 1/2, paper feed motor, JS eject motor, middle motor and duplex motor 1/2 speeds at 3/4 times of line speed	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Drum(K)	Drum motor K (DRM-K)	-5000 to 5000	19	16	12	11
Display	Description																																												
Motor1	Adjustment of drum motor K speeds																																												
Motor2	Adjustment of developer motor K, developer motor MCY, transfer motor, registration motor and transfer cleaning motor speeds																																												
Motor3	Adjustment of eject motor, fuser motor, BR conveying motor 1/2, paper feed motor, JS eject motor, middle motor and duplex motor 1/2 speeds																																												
Motor4	Drum motor K speed adjustment in black/white mode																																												
Motor5*	Adjustment of developer motor K, transfer motor, registration motor and transfer cleaning motor speeds in black/white mode																																												
Motor6*	Adjustment of eject motor, fuser motor, BR conveying motor 1/2, paper feed motor, JS eject motor, middle motor and duplex motor 1/2 speeds in black/white mode																																												
Motor1 Half	Adjustment of drum motor K speeds in half speed																																												
Motor2 Half	Adjustment of developer motor K, developer motor MCY, transfer motor, registration motor and transfer cleaning motor speeds in half speed																																												
Motor3 Half	Adjustment of eject motor, fuser motor, BR conveying motor 1/2, paper feed motor, JS eject motor, middle motor and duplex motor 1/2 speeds in half speed																																												
Motor1 3/4	Adjustment of drum motor K speeds at 3/4 times of line speed																																												
Motor2 3/4	Adjustment of developer motor K, developer motor MCY, transfer motor, registration motor and transfer cleaning motor speeds at 3/4 times of line speed																																												
Motor3 3/4	Adjustment of eject motor, fuser motor, BR conveying motor 1/2, paper feed motor, JS eject motor, middle motor and duplex motor 1/2 speeds at 3/4 times of line speed																																												
Display	Description	Setting range	Initial setting																																										
			30ppm	35ppm	45ppm	55ppm																																							
Drum(K)	Drum motor K (DRM-K)	-5000 to 5000	19	16	12	11																																							

Item No.	Description						
U053	Setting: [Motor2]						
	1. Select the item to be adjusted.						
	Display	Description	Setting range	Initial setting			
				30ppm	35ppm	45ppm	55ppm
	Dev(K)	Developer motor K (DEVM-K)	-5000 to 5000	0	0	0	0
	Dev(CMY)	Developer motor MCY (DEVM-MCY)	-5000 to 5000	0	0	0	0
	Trans Belt	Transfer motor (TRM)	-5000 to 5000	0	0	0	0
	Regist*	Registration motor (RM)	-5000 to 5000	-	-	17	15
	Belt Clean	Transfer cleaning motor (TRCM)	-5000 to 5000	0	0	0	0
	*: 45 ppm/55 ppm model only						
	Setting: [Motor3]						
	1. Select the item to be adjusted.						
	Display	Description	Setting range	Initial setting			
				30ppm	35ppm	45ppm	55ppm
	SB	Eject motor (EM)	-5000 to 5000	-31	-26	-20	-18
	Fixing	Fuser motor (FUM)	-5000 to 5000	0	0	0	0
	Bridge1	BR conveying motor 1 (BRCM1)	-5000 to 5000	-46	-39	-30	-27
	Bridge2	BR conveying motor 2 (BRCM2)	-5000 to 5000	-46	-39	-30	-27
	Feed	Paper feed motor (PFM)	-5000 to 5000	39	33	82	73
	Job Separator	JS eject motor (JSEM)	-5000 to 5000	0	0	0	0
	Mid Roller*	Middle motor (MM)	-5000 to 5000	-	-	18	16
	DU1*	Duplex motor 1 (DUM1)	-5000 to 5000	-	-	-30	-27
	DU2*	Duplex motor 2 (DUM2)	-5000 to 5000	-	-	-30	-27
	Bridge1 DF High	BR conveying motor 1 (BRCM1)	-5000 to 5000	0	0	0	0
	Bridge1 DF Low	BR conveying motor 1 (BRCM1)	-5000 to 5000	0	0	0	0
Bridge2 DF High	BR conveying motor 2 (BRCM2)	-5000 to 5000	0	0	0	0	
Bridge2 DF Low	BR conveying motor 2 (BRCM2)	-5000 to 5000	0	0	0	0	
*: 45 ppm/55 ppm model only.							

Item No.	Description																																													
U053	Setting: [Motor4]																																													
	1. Select the item to be adjusted.																																													
	<table border="1"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="4">Initial setting</th> </tr> <tr> <th>30ppm</th> <th>35ppm</th> <th>45ppm</th> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>Drum B/W(K)*</td> <td>Drum motor K (DRM-K) in black/white mode</td> <td>-5000 to 5000</td> <td>-</td> <td>-</td> <td>-</td> <td>25</td> </tr> <tr> <td>Drum Mono(K)</td> <td>Drum motor K (DRM-K) in monochrome mode</td> <td>-5000 to 5000</td> <td>42</td> <td>36</td> <td>28</td> <td>22</td> </tr> </tbody> </table>							Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Drum B/W(K)*	Drum motor K (DRM-K) in black/white mode	-5000 to 5000	-	-	-	25	Drum Mono(K)	Drum motor K (DRM-K) in monochrome mode	-5000 to 5000	42	36	28	22														
	Display	Description	Setting range	Initial setting																																										
				30ppm	35ppm	45ppm	55ppm																																							
	Drum B/W(K)*	Drum motor K (DRM-K) in black/white mode	-5000 to 5000	-	-	-	25																																							
	Drum Mono(K)	Drum motor K (DRM-K) in monochrome mode	-5000 to 5000	42	36	28	22																																							
	*: 55 ppm model only.																																													
	Setting: [Motor5]																																													
	1. Select the item to be adjusted.																																													
<table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Dev B/W(K)</td> <td>Developer motor K (DEVK-K) in black/white mode</td> <td>-5000 to 5000</td> <td>0</td> </tr> <tr> <td>Trans Belt B/W</td> <td>Transfer motor (TRM) in black/white mode</td> <td>-5000 to 5000</td> <td>0</td> </tr> <tr> <td>Regist B/W</td> <td>Registration motor (RM) in black/white mode</td> <td>-5000 to 5000</td> <td>14</td> </tr> <tr> <td>Belt Clean B/W</td> <td>Transfer cleaning motor (TRCM) in black/white mode</td> <td>-5000 to 5000</td> <td>0</td> </tr> </tbody> </table>							Display	Description	Setting range	Initial setting	Dev B/W(K)	Developer motor K (DEVK-K) in black/white mode	-5000 to 5000	0	Trans Belt B/W	Transfer motor (TRM) in black/white mode	-5000 to 5000	0	Regist B/W	Registration motor (RM) in black/white mode	-5000 to 5000	14	Belt Clean B/W	Transfer cleaning motor (TRCM) in black/white mode	-5000 to 5000	0																				
Display	Description	Setting range	Initial setting																																											
Dev B/W(K)	Developer motor K (DEVK-K) in black/white mode	-5000 to 5000	0																																											
Trans Belt B/W	Transfer motor (TRM) in black/white mode	-5000 to 5000	0																																											
Regist B/W	Registration motor (RM) in black/white mode	-5000 to 5000	14																																											
Belt Clean B/W	Transfer cleaning motor (TRCM) in black/white mode	-5000 to 5000	0																																											
Setting: [Motor6]																																														
1. Select the item to be adjusted.																																														
<table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>SB B/W</td> <td>Eject motor (EM) in black/white mode</td> <td>-5000 to 5000</td> <td>-16</td> </tr> <tr> <td>Fixing B/W</td> <td>Fuser motor (FUM) in black/white mode</td> <td>-5000 to 5000</td> <td>0</td> </tr> <tr> <td>Bridge1 B/W</td> <td>BR conveying motor 1 (BRCM1) in black/white mode</td> <td>-5000 to 5000</td> <td>-25</td> </tr> <tr> <td>Bridge2 B/W</td> <td>BR conveying motor 2 (BRCM2) in black/white mode</td> <td>-5000 to 5000</td> <td>-25</td> </tr> <tr> <td>Feed B/W</td> <td>Paper feed motor (PFM) in black/white mode</td> <td>-5000 to 5000</td> <td>66</td> </tr> <tr> <td>Job Separator B/W</td> <td>JS eject motor (JSEM) in black/white mode</td> <td>-5000 to 5000</td> <td>0</td> </tr> <tr> <td>Mid Roller B/W</td> <td>Middle motor (MM) in black/white mode</td> <td>-5000 to 5000</td> <td>15</td> </tr> <tr> <td>DU1 B/W</td> <td>Duplex motor 1 (DUM1) in black/white mode</td> <td>-5000 to 5000</td> <td>-24</td> </tr> <tr> <td>DU2 B/W</td> <td>Duplex motor 2 (DUM2) in black/white mode</td> <td>-5000 to 5000</td> <td>-24</td> </tr> </tbody> </table>							Display	Description	Setting range	Initial setting	SB B/W	Eject motor (EM) in black/white mode	-5000 to 5000	-16	Fixing B/W	Fuser motor (FUM) in black/white mode	-5000 to 5000	0	Bridge1 B/W	BR conveying motor 1 (BRCM1) in black/white mode	-5000 to 5000	-25	Bridge2 B/W	BR conveying motor 2 (BRCM2) in black/white mode	-5000 to 5000	-25	Feed B/W	Paper feed motor (PFM) in black/white mode	-5000 to 5000	66	Job Separator B/W	JS eject motor (JSEM) in black/white mode	-5000 to 5000	0	Mid Roller B/W	Middle motor (MM) in black/white mode	-5000 to 5000	15	DU1 B/W	Duplex motor 1 (DUM1) in black/white mode	-5000 to 5000	-24	DU2 B/W	Duplex motor 2 (DUM2) in black/white mode	-5000 to 5000	-24
Display	Description	Setting range	Initial setting																																											
SB B/W	Eject motor (EM) in black/white mode	-5000 to 5000	-16																																											
Fixing B/W	Fuser motor (FUM) in black/white mode	-5000 to 5000	0																																											
Bridge1 B/W	BR conveying motor 1 (BRCM1) in black/white mode	-5000 to 5000	-25																																											
Bridge2 B/W	BR conveying motor 2 (BRCM2) in black/white mode	-5000 to 5000	-25																																											
Feed B/W	Paper feed motor (PFM) in black/white mode	-5000 to 5000	66																																											
Job Separator B/W	JS eject motor (JSEM) in black/white mode	-5000 to 5000	0																																											
Mid Roller B/W	Middle motor (MM) in black/white mode	-5000 to 5000	15																																											
DU1 B/W	Duplex motor 1 (DUM1) in black/white mode	-5000 to 5000	-24																																											
DU2 B/W	Duplex motor 2 (DUM2) in black/white mode	-5000 to 5000	-24																																											


Item No.	Description																																																											
U053	Setting: [Motor1 Half] 1. Select the item to be adjusted.																																																											
	<table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Drum(K)</td> <td>Drum motor K (DRM-K) in half speed</td> <td>-5000 to 5000</td> <td>0</td> </tr> </tbody> </table>	Display	Description	Setting range	Initial setting	Drum(K)	Drum motor K (DRM-K) in half speed	-5000 to 5000	0																																																			
	Display	Description	Setting range	Initial setting																																																								
	Drum(K)	Drum motor K (DRM-K) in half speed	-5000 to 5000	0																																																								
	Setting: [Motor2 Half] 1. Select the item to be adjusted.																																																											
	<table border="1"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="4">Initial setting</th> </tr> <tr> <th>30ppm</th> <th>35ppm</th> <th>45ppm</th> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>Dev(K)</td> <td>Developer motor K (DEVM-K) in half speed</td> <td>-5000 to 5000</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>Dev(CMY)</td> <td>Developer motor MCY (DEVM-MCY) in half speed</td> <td>-5000 to 5000</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>Trans Belt</td> <td>Transfer motor (TRM) in half speed</td> <td>-5000 to 5000</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>Regist*</td> <td>Registration motor (RM) in half speed</td> <td>-5000 to 5000</td> <td>-</td> <td>-</td> <td>34</td> <td>30</td> </tr> <tr> <td>Belt Clean</td> <td>Transfer cleaning motor (TRCM) in half speed</td> <td>-5000 to 5000</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> </tbody> </table>	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Dev(K)	Developer motor K (DEVM-K) in half speed	-5000 to 5000	0	0	0	0	Dev(CMY)	Developer motor MCY (DEVM-MCY) in half speed	-5000 to 5000	0	0	0	0	Trans Belt	Transfer motor (TRM) in half speed	-5000 to 5000	0	0	0	0	Regist*	Registration motor (RM) in half speed	-5000 to 5000	-	-	34	30	Belt Clean	Transfer cleaning motor (TRCM) in half speed	-5000 to 5000	0	0	0	0													
	Display				Description	Setting range	Initial setting																																																					
		30ppm	35ppm	45ppm			55ppm																																																					
	Dev(K)	Developer motor K (DEVM-K) in half speed	-5000 to 5000	0	0	0	0																																																					
	Dev(CMY)	Developer motor MCY (DEVM-MCY) in half speed	-5000 to 5000	0	0	0	0																																																					
Trans Belt	Transfer motor (TRM) in half speed	-5000 to 5000	0	0	0	0																																																						
Regist*	Registration motor (RM) in half speed	-5000 to 5000	-	-	34	30																																																						
Belt Clean	Transfer cleaning motor (TRCM) in half speed	-5000 to 5000	0	0	0	0																																																						
*: 45 ppm/55 ppm model only.																																																												
Setting: [Motor3 Half] Select the item to be adjusted.																																																												
<table border="1"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="4">Initial setting</th> </tr> <tr> <th>30ppm</th> <th>35ppm</th> <th>45ppm</th> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>SB</td> <td>Eject motor (EM) in half speed</td> <td>-5000 to 5000</td> <td>-61</td> <td>-52</td> <td>-41</td> <td>-36</td> </tr> <tr> <td>Fixing</td> <td>Fuser motor (FUM) in half speed</td> <td>-5000 to 5000</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>Bridge1</td> <td>BR conveying motor 1 (BRCM1) in half speed</td> <td>-5000 to 5000</td> <td>-65</td> <td>-55</td> <td>-43</td> <td>-38</td> </tr> <tr> <td>Bridge2</td> <td>BR conveying motor 2 (BRCM2) in half speed</td> <td>-5000 to 5000</td> <td>-65</td> <td>-55</td> <td>-43</td> <td>-38</td> </tr> <tr> <td>Feed</td> <td>Paper feed motor (PFM) in half speed</td> <td>-5000 to 5000</td> <td>77</td> <td>66</td> <td>164</td> <td>147</td> </tr> <tr> <td>Job Separator</td> <td>JS eject motor (JSEM) in half speed</td> <td>-5000 to 5000</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>Mid Roller*</td> <td>Middle motor (MM) in half speed</td> <td>-5000 to 5000</td> <td>-</td> <td>-</td> <td>36</td> <td>32</td> </tr> </tbody> </table>	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	SB	Eject motor (EM) in half speed	-5000 to 5000	-61	-52	-41	-36	Fixing	Fuser motor (FUM) in half speed	-5000 to 5000	0	0	0	0	Bridge1	BR conveying motor 1 (BRCM1) in half speed	-5000 to 5000	-65	-55	-43	-38	Bridge2	BR conveying motor 2 (BRCM2) in half speed	-5000 to 5000	-65	-55	-43	-38	Feed	Paper feed motor (PFM) in half speed	-5000 to 5000	77	66	164	147	Job Separator	JS eject motor (JSEM) in half speed	-5000 to 5000	0	0	0	0	Mid Roller*	Middle motor (MM) in half speed	-5000 to 5000	-	-	36	32
Display				Description	Setting range	Initial setting																																																						
	30ppm	35ppm	45ppm			55ppm																																																						
SB	Eject motor (EM) in half speed	-5000 to 5000	-61	-52	-41	-36																																																						
Fixing	Fuser motor (FUM) in half speed	-5000 to 5000	0	0	0	0																																																						
Bridge1	BR conveying motor 1 (BRCM1) in half speed	-5000 to 5000	-65	-55	-43	-38																																																						
Bridge2	BR conveying motor 2 (BRCM2) in half speed	-5000 to 5000	-65	-55	-43	-38																																																						
Feed	Paper feed motor (PFM) in half speed	-5000 to 5000	77	66	164	147																																																						
Job Separator	JS eject motor (JSEM) in half speed	-5000 to 5000	0	0	0	0																																																						
Mid Roller*	Middle motor (MM) in half speed	-5000 to 5000	-	-	36	32																																																						


Item No.	Description						
U053							
	Display	Description	Setting range	Initial setting			
				30ppm	35ppm	45ppm	55ppm
	DU1*	Duplex motor 1 (DUM1) in half speed	-5000 to 5000	-	-	-60	-54
	DU2*	Duplex motor 2 (DUM2) in half speed	-5000 to 5000	-	-	-60	-54
	1. *: 45 ppm/55 ppm model only.						
	Setting: [Motor1 3/4]						
	1. Select the item to be adjusted.						
	Display	Description	Setting range	Initial setting			
				0			
Drum(K)	Drum motor K (DRM-K) at 3/4 times of line speed	-5000 to 5000	0				
Setting: [Motor2 3/4]							
1. Select the item to be adjusted.							
Display	Description	Setting range	Initial setting				
			0				
Dev(K)	Developer motor K (DEVM-K) at 3/4 times of line speed	-5000 to 5000	0				
Dev(CMY)	Developer motor MCY (DEVM-MCY) at 3/4 times of line speed	-5000 to 5000	0				
Trans Belt	Transfer motor (TRM) at 3/4 times of line speed	-5000 to 5000	0				
Regist*	Registration motor (RM) at 3/4 times of line speed	-5000 to 5000	22				
Belt Clean	Transfer cleaning motor (TRCM) at 3/4 times of line speed	-5000 to 5000	0				
*: 45 ppm/55 ppm model only.							

Item No.	Description						
U053	Setting: [Motor3 3/4]						
	1. Select the item to be adjusted.						
				Initial setting			
				30ppm	35ppm	45ppm	55ppm
	SB	Eject motor (EM) at 3/4 times of line speed	-5000 to 5000	-40	-36	-26	-26
	Fixing	Fuser motor (FUM) at 3/4 times of line speed	-5000 to 5000	0	0	0	0
	Bridge1	BR conveying motor 1 (BRCM1) at 3/4 times of line speed	-5000 to 5000	-61	-54	-39	-39
	Bridge2	BR conveying motor 2 (BRCM2) at 3/4 times of line speed	-5000 to 5000	-61	-54	-39	-39
	Feed	Paper feed motor (PFM) at 3/4 times of line speed	-5000 to 5000	50	45	106	106
	Job Separator	JS eject motor (JSEM) at 3/4 times of line speed	-5000 to 5000	0	0	0	0
Mid Roller*	Middle motor (MM) at 3/4 times of line speed	-5000 to 5000	-	-	23	23	
DU1*	Duplex motor 1 (DUM1) at 3/4 times of line speed	-5000 to 5000	-	-	-39	-39	
DU2*	Duplex motor 2 (DUM2) at 3/4 times of line speed	-5000 to 5000	-	-	-39	-39	
*: 45 ppm/55 ppm model only.							
Completion							
Press the stop key. The indication for selecting a maintenance item No. appears.							

Item No.	Description																								
U059	<p data-bbox="288 241 512 275">Setting fan mode</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 778 374">Specifies mode for developer fan motors.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1318 443">Handling the lowering density [to suppress thermal stresses owing to the heated toner]</p> <p data-bbox="288 555 387 584">Method</p> <ol data-bbox="304 589 564 651" style="list-style-type: none"> 1. Press the start key. 2. Select the mode. <table border="1" data-bbox="336 665 1399 873"> <thead> <tr> <th data-bbox="336 665 603 714">Display</th> <th data-bbox="603 665 1399 714">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 714 603 788">Fan Mode</td> <td data-bbox="603 714 1399 788">Sets threshold temperature at which developer fan motors operate.</td> </tr> <tr> <td data-bbox="336 788 603 873">Cooling Mode</td> <td data-bbox="603 788 1399 873">Sets temperature at which the developer fan motors are switched for controlling.</td> </tr> </tbody> </table> <p data-bbox="288 920 544 949">Setting: [Fan Mode]</p> <ol data-bbox="304 954 539 983" style="list-style-type: none"> 1. Select the mode. <table border="1" data-bbox="336 999 1399 1480"> <thead> <tr> <th data-bbox="336 999 564 1048">Display</th> <th data-bbox="564 999 1399 1048">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1048 564 1095">Mode1</td> <td data-bbox="564 1048 1399 1095">Setting temperature:Normal</td> </tr> <tr> <td data-bbox="336 1095 564 1211">Mode2</td> <td data-bbox="564 1095 1399 1211">Setting temperature:Temperature threshold is raised from mode1 (WUP, temperature at READY : mode1 temperature -7(°C), Temperature at PRINT : mode1 temperature -3(°C).)</td> </tr> <tr> <td data-bbox="336 1211 564 1328">Mode3</td> <td data-bbox="564 1211 1399 1328">Setting temperature:Temperature threshold is raised from mode2 (WUP, temperature at READY : mode1 temperature -22(°C), Temperature at PRINT : mode1 temperature -8(°C).)</td> </tr> <tr> <td data-bbox="336 1328 564 1480">Auto</td> <td data-bbox="564 1328 1399 1480">Starting with Mode 2 at power up or recovery from sleep mode, and switches to Mode 3 when the termistor detects a developer temperature BK is equal to or higher than 38°C. The device never reverts from mode 2 from mode 3 while power is on.</td> </tr> </tbody> </table> <p data-bbox="336 1500 584 1529">Initial setting: Mode1</p> <ol data-bbox="304 1534 783 1563" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1606 595 1635">Setting: [Cooling Mode]</p> <ol data-bbox="304 1639 858 1668" style="list-style-type: none"> 1. Change the setting value using the +/- keys. <table border="1" data-bbox="336 1682 1383 1848"> <thead> <tr> <th data-bbox="336 1682 564 1765">Display</th> <th data-bbox="564 1682 1050 1765">Description</th> <th data-bbox="1050 1682 1219 1765">Setting range</th> <th data-bbox="1219 1682 1383 1765">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1765 564 1848">Cooling Mode</td> <td data-bbox="564 1765 1050 1848">Amount of shift from the initial standard temperature</td> <td data-bbox="1050 1765 1219 1848">-3 to 3 (°C)</td> <td data-bbox="1219 1765 1383 1848">0</td> </tr> </tbody> </table> <p data-bbox="336 1859 1217 1888">A larger value advances the operating timing, and a smaller value slows it.</p> <ol data-bbox="304 1892 767 1921" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1964 440 1993">Completion</p> <p data-bbox="288 1998 1246 2027">Press the stop key. The indication for selecting a maintenance item No. appears.</p>	Display	Description	Fan Mode	Sets threshold temperature at which developer fan motors operate.	Cooling Mode	Sets temperature at which the developer fan motors are switched for controlling.	Display	Description	Mode1	Setting temperature:Normal	Mode2	Setting temperature:Temperature threshold is raised from mode1 (WUP, temperature at READY : mode1 temperature -7(°C), Temperature at PRINT : mode1 temperature -3(°C).)	Mode3	Setting temperature:Temperature threshold is raised from mode2 (WUP, temperature at READY : mode1 temperature -22(°C), Temperature at PRINT : mode1 temperature -8(°C).)	Auto	Starting with Mode 2 at power up or recovery from sleep mode, and switches to Mode 3 when the termistor detects a developer temperature BK is equal to or higher than 38°C. The device never reverts from mode 2 from mode 3 while power is on.	Display	Description	Setting range	Initial setting	Cooling Mode	Amount of shift from the initial standard temperature	-3 to 3 (°C)	0
Display	Description																								
Fan Mode	Sets threshold temperature at which developer fan motors operate.																								
Cooling Mode	Sets temperature at which the developer fan motors are switched for controlling.																								
Display	Description																								
Mode1	Setting temperature:Normal																								
Mode2	Setting temperature:Temperature threshold is raised from mode1 (WUP, temperature at READY : mode1 temperature -7(°C), Temperature at PRINT : mode1 temperature -3(°C).)																								
Mode3	Setting temperature:Temperature threshold is raised from mode2 (WUP, temperature at READY : mode1 temperature -22(°C), Temperature at PRINT : mode1 temperature -8(°C).)																								
Auto	Starting with Mode 2 at power up or recovery from sleep mode, and switches to Mode 3 when the termistor detects a developer temperature BK is equal to or higher than 38°C. The device never reverts from mode 2 from mode 3 while power is on.																								
Display	Description	Setting range	Initial setting																						
Cooling Mode	Amount of shift from the initial standard temperature	-3 to 3 (°C)	0																						

Item No.	Description										
U061	<p>Checking the operation of the exposure lamp</p> <p>Description Lights the exposure lamp.</p> <p>Purpose To check whether the exposure lamp are turned on.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 598 1401 741"> <thead> <tr> <th data-bbox="336 598 603 642">Display</th> <th data-bbox="603 598 1401 642">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 642 603 687">CCD</td> <td data-bbox="603 642 1401 687">The exposure lamp lights</td> </tr> <tr> <td data-bbox="336 687 603 741">CIS</td> <td data-bbox="603 687 1401 741">The CIS lights (when dual scan DP is installed)</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The lamp lights. 4. To turn the lamp off, press the stop key. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	CCD	The exposure lamp lights	CIS	The CIS lights (when dual scan DP is installed)				
Display	Description										
CCD	The exposure lamp lights										
CIS	The CIS lights (when dual scan DP is installed)										
U063	<p>Adjusting the shading position</p> <p>Description Changes the shading position of the scanner.</p> <p>Purpose Used when the white line continue to appear longitudinally on the image after the shading plate is cleaned. This is due to flaws or stains inside the shading plate. To prevent this problem, the shading position should be changed so that shading is possible without being affected by the flaws or stains.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 1393 1401 1523"> <thead> <tr> <th data-bbox="336 1393 528 1473">Display</th> <th data-bbox="528 1393 922 1473">Description</th> <th data-bbox="922 1393 1082 1473">Setting range</th> <th data-bbox="1082 1393 1193 1473">Initial setting</th> <th data-bbox="1193 1393 1401 1473">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1473 528 1523">Position</td> <td data-bbox="528 1473 922 1523">Shading position</td> <td data-bbox="922 1473 1082 1523">0 to 18</td> <td data-bbox="1082 1473 1193 1523">0</td> <td data-bbox="1193 1473 1401 1523">0.158 mm</td> </tr> </tbody> </table> <p>Increasing the value moves the shading position toward the machine left, and decreasing it moves the position toward the machine right.</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Supplement While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	Position	Shading position	0 to 18	0	0.158 mm
Display	Description	Setting range	Initial setting	Change in value per step							
Position	Shading position	0 to 18	0	0.158 mm							


Item No.	Description															
U065	<p data-bbox="288 241 754 271">Adjusting the scanner magnification</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 877 374">Adjusts the magnification of the original scanning.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1276 443">Make the adjustment if the magnification in the main scanning direction is incorrect.</p> <p data-bbox="288 448 1316 477">Make the adjustment if the magnification in the auxiliary scanning direction is incorrect.</p> <p data-bbox="288 517 392 546">Caution</p> <p data-bbox="288 551 1362 618">The magnification adjustment along the main scanning direction could cause black streaks depending on the content of the original document.</p> <p data-bbox="288 622 1013 651">Adjust the magnification of the scanner in the following order.</p> <div data-bbox="293 669 1054 763" style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; padding: 5px; text-align: center;"> U039 (P.1-3-40) </div> → <div style="border: 1px solid black; padding: 5px; text-align: center;"> U065 main scanning direction </div> → <div style="border: 1px solid black; padding: 5px; text-align: center;"> U065 auxiliary scanning direction </div> </div> </div> <p data-bbox="288 815 387 844">Method</p> <ol data-bbox="304 851 1058 1016" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 1032 1401 1279" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Main Scan</td> <td>Scanner magnification in the main scanning direction</td> <td>-75 to 75</td> <td>0</td> <td>0.02 %</td> </tr> <tr> <td>Sub Scan</td> <td>Scanner magnification in the auxiliary scanning direction</td> <td>-125 to 125</td> <td>0</td> <td>0.02 %</td> </tr> </tbody> </table> <p data-bbox="288 1326 606 1355">Adjustment: [Main Scan]</p> <ol data-bbox="304 1361 1302 1458" style="list-style-type: none"> 1. Change the setting value using the +/- keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. Increasing the setting enlarges the image and decreasing it narrows the image. <div data-bbox="667 1485 1054 1709" style="text-align: center; margin: 10px 0;">  <div style="display: flex; justify-content: space-around; width: 100%;"> <div style="text-align: center;">Original</div> <div style="text-align: center;">Copy example 1</div> <div style="text-align: center;">Copy example 2</div> </div> </div> <p data-bbox="783 1733 938 1762">Figure 1-3-8</p> <ol data-bbox="304 1803 766 1832" style="list-style-type: none"> 2. Press the start key. The value is set. 	Display	Description	Setting range	Initial setting	Change in value per step	Main Scan	Scanner magnification in the main scanning direction	-75 to 75	0	0.02 %	Sub Scan	Scanner magnification in the auxiliary scanning direction	-125 to 125	0	0.02 %
Display	Description	Setting range	Initial setting	Change in value per step												
Main Scan	Scanner magnification in the main scanning direction	-75 to 75	0	0.02 %												
Sub Scan	Scanner magnification in the auxiliary scanning direction	-125 to 125	0	0.02 %												



Item No.	Description
U065	<p data-bbox="288 244 596 275">Adjustment: [Sub Scan]</p> <p data-bbox="308 280 1414 412">1. Change the setting value using the +/- keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. Increasing the value makes the image longer, while decreasing the value makes the image shorter.</p> <div data-bbox="667 439 1054 658" style="text-align: center;"><p data-bbox="676 600 1054 658">Original Copy example 1 Copy example 2</p></div> <p data-bbox="783 689 938 721" style="text-align: center;">Figure 1-3-9</p> <p data-bbox="308 759 767 790">2. Press the start key. The value is set.</p> <p data-bbox="288 826 440 857">Completion</p> <p data-bbox="288 862 1254 893">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Item No.	Description																						
U066	<p data-bbox="288 241 900 273">Adjusting the scanner leading edge registration</p> <p data-bbox="288 311 440 338">Description</p> <p data-bbox="288 344 1117 376">Adjusts the scanner leading edge registration of the original scanning.</p> <p data-bbox="288 383 400 409">Purpose</p> <p data-bbox="288 416 1426 479">Make the adjustment if there is a regular error between the leading edges of the copy image and original.</p> <p data-bbox="288 517 440 544">Adjustment</p> <ol data-bbox="304 553 1058 719" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 734 1401 981"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Front</td> <td>Scanner leading edge registration</td> <td>-30 to 30</td> <td>0</td> <td>0.158 mm</td> </tr> <tr> <td>Rotate</td> <td>Scanner leading edge registration (rotate copying)</td> <td>-30 to 30</td> <td>0</td> <td>0.158 mm</td> </tr> </tbody> </table> <ol data-bbox="304 994 1406 1124" style="list-style-type: none"> 6. Change the setting value using the +/- keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. Increasing the value moves the image forward and decreasing the value moves the image backward. <div data-bbox="576 1153 1299 1458" style="text-align: center;"> <p>Leading edge registration of the copy image (+1.0/-1.5 mm or less)</p> <p>Original Copy example 1 Copy example 2</p> </div> <p data-bbox="775 1491 946 1518">Figure 1-3-10</p> <ol data-bbox="304 1561 767 1592" style="list-style-type: none"> 7. Press the start key. The value is set. <p data-bbox="288 1630 392 1657">Caution</p> <p data-bbox="288 1664 1430 1727">If the above adjustment does not optimize the leading edge registration, proceed with the following maintenance modes.</p> <div data-bbox="293 1742 1129 1839" style="text-align: center;"> <table border="1"> <tr> <td style="padding: 5px;">U039 (P.1-3-40)</td> <td style="padding: 5px; text-align: center;">→</td> <td style="padding: 5px;">U034 (P.1-3-34)</td> <td style="padding: 5px; text-align: center;">→</td> <td style="padding: 5px;">U065 (P.1-3-52)</td> <td style="padding: 5px; text-align: center;">→</td> <td style="padding: 5px;">U066</td> </tr> </table> </div> <p data-bbox="288 1888 440 1915">Completion</p> <p data-bbox="288 1921 1254 1953">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	Front	Scanner leading edge registration	-30 to 30	0	0.158 mm	Rotate	Scanner leading edge registration (rotate copying)	-30 to 30	0	0.158 mm	U039 (P.1-3-40)	→	U034 (P.1-3-34)	→	U065 (P.1-3-52)	→	U066
Display	Description	Setting range	Initial setting	Change in value per step																			
Front	Scanner leading edge registration	-30 to 30	0	0.158 mm																			
Rotate	Scanner leading edge registration (rotate copying)	-30 to 30	0	0.158 mm																			
U039 (P.1-3-40)	→	U034 (P.1-3-34)	→	U065 (P.1-3-52)	→	U066																	




Item No.	Description																				
U067	<p>Adjusting the scanner center line</p> <p>Description Adjusts the scanner center line of the original scanning.</p> <p>Purpose Make the adjustment if there is a regular error between the center lines of the copy image and original.</p> <p>Adjustment</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 734 1401 949"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Front</td> <td>Scanner center line</td> <td>-60 to 60</td> <td>0</td> <td>0.085 mm</td> </tr> <tr> <td>Rotate</td> <td>Scanner center line (rotate copying)</td> <td>-40 to 40</td> <td>0</td> <td>0.085 mm</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 6. Change the setting value using the +/- keys or numeric keys. For copy example 1, decrease the value. For copy example 2, increase the value. Increasing the value moves the image leftward and decreasing it moves the image rightward. <div data-bbox="646 1084 1158 1384" style="text-align: center;"> <p>Center line of the copy image (within ± 2.0 mm)</p> <p>Original Copy example 1 Copy example 2</p> </div> <p>Figure 1-3-11</p> <ol style="list-style-type: none"> 7. Press the start key. The value is set. <p>Caution If the above adjustment does not optimize the center line, proceed with the following maintenance modes.</p> <div data-bbox="293 1666 903 1760" style="text-align: center;"> <table border="1"> <tr> <td style="padding: 5px;">U034 (P.1-3-36)</td> <td style="padding: 5px; text-align: center;">→</td> <td style="padding: 5px;">U065 (P.1-3-52)</td> <td style="padding: 5px; text-align: center;">→</td> <td style="padding: 5px;">U067</td> </tr> </table> </div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	Front	Scanner center line	-60 to 60	0	0.085 mm	Rotate	Scanner center line (rotate copying)	-40 to 40	0	0.085 mm	U034 (P.1-3-36)	→	U065 (P.1-3-52)	→	U067
Display	Description	Setting range	Initial setting	Change in value per step																	
Front	Scanner center line	-60 to 60	0	0.085 mm																	
Rotate	Scanner center line (rotate copying)	-40 to 40	0	0.085 mm																	
U034 (P.1-3-36)	→	U065 (P.1-3-52)	→	U067																	

Item No.	Description															
U068	<p data-bbox="288 241 1021 275">Adjusting the scanning position for originals from the DP</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1414 412">Adjusts the position for scanning originals from the DP. Performs the test copy at the four scanning positions after adjusting.</p> <p data-bbox="288 416 400 445">Purpose</p> <p data-bbox="288 450 1426 517">Used when the image fogging occurs because the scanning position is not proper when the DP is used. Run U071 to adjust the timing of DP leading edge when the scanning position is changed.</p> <p data-bbox="288 553 384 582">Setting</p> <p data-bbox="304 586 571 616">1. Press the start key.</p> <table border="1" data-bbox="336 631 1399 880"> <thead> <tr> <th data-bbox="336 631 528 712">Display</th> <th data-bbox="528 631 922 712">Description</th> <th data-bbox="922 631 1082 712">Setting range</th> <th data-bbox="1082 631 1195 712">Initial setting</th> <th data-bbox="1195 631 1399 712">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 712 528 792">DP Read</td> <td data-bbox="528 712 922 792">Starting position adjustment for scanning originals</td> <td data-bbox="922 712 1082 792">-38 to 38</td> <td data-bbox="1082 712 1195 792">0</td> <td data-bbox="1195 712 1399 792">0.158 mm</td> </tr> <tr> <td data-bbox="336 792 528 880">Black Line</td> <td data-bbox="528 792 922 880">Scanning position for the test copy originals</td> <td data-bbox="922 792 1082 880">0 to 3</td> <td data-bbox="1082 792 1195 880">0</td> <td data-bbox="1195 792 1399 880">-</td> </tr> </tbody> </table> <p data-bbox="304 891 550 920">2. Select [DP Read].</p> <p data-bbox="304 925 983 954">3. Change the setting using the +/- keys or numeric keys.</p> <p data-bbox="333 958 1426 1025">When the setting value is increased, the scanning position moves to the right and it moves to the left when the setting value is decreased.</p> <p data-bbox="304 1030 766 1059">4. Press the start key. The value is set.</p> <p data-bbox="304 1064 564 1093">5. Select [Black Line].</p> <p data-bbox="304 1097 983 1126">6. Change the setting using the +/- keys or numeric keys.</p> <p data-bbox="304 1131 766 1160">7. Press the start key. The value is set.</p> <p data-bbox="304 1164 1417 1193">8. Set the original (the one which density is known) in the DP and press the system menu key.</p> <p data-bbox="304 1198 834 1227">9. Press the start key. Test copy is executed.</p> <p data-bbox="288 1232 1426 1299">10. Perform the test copy at each scanning position with the setting value from 0 to 3 and check that no black line appears and the image is normally scanned.</p> <p data-bbox="288 1335 440 1364">Completion</p> <p data-bbox="288 1368 1254 1397">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	DP Read	Starting position adjustment for scanning originals	-38 to 38	0	0.158 mm	Black Line	Scanning position for the test copy originals	0 to 3	0	-
Display	Description	Setting range	Initial setting	Change in value per step												
DP Read	Starting position adjustment for scanning originals	-38 to 38	0	0.158 mm												
Black Line	Scanning position for the test copy originals	0 to 3	0	-												

Item No.	Description																									
U070	<p data-bbox="288 241 687 275">Adjusting the DP magnification</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 762 376">Adjusts the DP original scanning speed.</p> <p data-bbox="288 383 400 412">Purpose</p> <p data-bbox="288 416 1426 479">Make the adjustment if the magnification is incorrect in the auxiliary scanning direction when the DP is used.</p> <p data-bbox="288 486 1426 548">Make the adjustment if the magnification is incorrect in the main scanning direction when the CIS is used.</p> <p data-bbox="288 589 440 618">Adjustment</p> <ol data-bbox="304 622 1182 790" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original on the DP and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 801 1401 1285"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Sub Scan(F)</td> <td>Magnification in the auxiliary scanning direction of CCD (first side)</td> <td>-125 to 125</td> <td>0</td> <td>0.02 %</td> </tr> <tr> <td>Sub Scan(B)^{*1}</td> <td>Magnification in the auxiliary scanning direction of CCD (second side)</td> <td>-125 to 125</td> <td>0</td> <td>0.02 %</td> </tr> <tr> <td>Main Scan(CIS)^{*2}</td> <td>Magnification in the main scanning direction of CIS</td> <td>-100 to 100</td> <td>0</td> <td>0.02 %</td> </tr> <tr> <td>Sub Scan(CIS)^{*2}</td> <td>Magnification in the auxiliary scanning direction of CIS</td> <td>-125 to 125</td> <td>0</td> <td>0.02 %</td> </tr> </tbody> </table> <p data-bbox="336 1294 879 1326">*1: Reversed DP only. *2: Dual scan DP only.</p> <p data-bbox="288 1361 595 1393">Adjustment: [Sub Scan]</p> <ol data-bbox="304 1397 1410 1532" style="list-style-type: none"> 1. Change the setting value using the +/- keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. Increasing the value makes the image longer, while decreasing the value makes the image shorter. <div data-bbox="667 1559 1054 1783" style="text-align: center;">  <p data-bbox="676 1720 762 1749">Original</p> <p data-bbox="804 1720 916 1783">Copy example 1</p> <p data-bbox="943 1720 1054 1783">Copy example 2</p> </div> <p data-bbox="775 1805 946 1836">Figure 1-3-12</p> <ol data-bbox="304 1877 767 1908" style="list-style-type: none"> 2. Press the start key. The value is set. 	Display	Description	Setting range	Initial setting	Change in value per step	Sub Scan(F)	Magnification in the auxiliary scanning direction of CCD (first side)	-125 to 125	0	0.02 %	Sub Scan(B) ^{*1}	Magnification in the auxiliary scanning direction of CCD (second side)	-125 to 125	0	0.02 %	Main Scan(CIS) ^{*2}	Magnification in the main scanning direction of CIS	-100 to 100	0	0.02 %	Sub Scan(CIS) ^{*2}	Magnification in the auxiliary scanning direction of CIS	-125 to 125	0	0.02 %
Display	Description	Setting range	Initial setting	Change in value per step																						
Sub Scan(F)	Magnification in the auxiliary scanning direction of CCD (first side)	-125 to 125	0	0.02 %																						
Sub Scan(B) ^{*1}	Magnification in the auxiliary scanning direction of CCD (second side)	-125 to 125	0	0.02 %																						
Main Scan(CIS) ^{*2}	Magnification in the main scanning direction of CIS	-100 to 100	0	0.02 %																						
Sub Scan(CIS) ^{*2}	Magnification in the auxiliary scanning direction of CIS	-125 to 125	0	0.02 %																						

Item No.	Description
U070	<p>Adjustment: [Main Scan]</p> <p>1. Change the setting value using the +/- keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. Increasing the setting enlarges the image and decreasing it narrows the image.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Original Copy example 1 Copy example 2</p> </div> <p style="text-align: center;">Figure 1-3-13</p> <p>2. Press the start key. The value is set.</p> <p>Caution If the above adjustment does not optimize the magnification, perform the following maintenance modes.</p> <div style="text-align: center;">  </div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Item No.	Description																																																		
U071	<p data-bbox="287 241 721 275">Adjusting the DP scanning timing</p> <p data-bbox="287 311 440 340">Description</p> <p data-bbox="287 344 762 376">Adjusts the DP original scanning timing.</p> <p data-bbox="287 380 400 409">Purpose</p> <p data-bbox="287 414 1422 479">Make the adjustment if there is a regular error between the leading or trailing edges of the original and the copy image when the DP is used.</p> <p data-bbox="287 517 387 546">Method</p> <ol data-bbox="304 553 1182 723" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original on the DP and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <p data-bbox="335 725 496 754">Reversed DP</p> <table border="1" data-bbox="336 768 1401 1182"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Front Head</td> <td>Leading edge registration of CCD (first side)</td> <td>-32 to 32</td> <td>0</td> <td>0.085 mm</td> </tr> <tr> <td>Front Tail</td> <td>Trailing edge registration of CCD (first side)</td> <td>-32 to 32</td> <td>0</td> <td>0.085 mm</td> </tr> <tr> <td>Back Head</td> <td>Leading edge registration of CCD (second side)</td> <td>-32 to 32</td> <td>0</td> <td>0.085 mm</td> </tr> <tr> <td>Back Tail</td> <td>Trailing edge registration of CCD (second side)</td> <td>-32 to 32</td> <td>0</td> <td>0.085 mm</td> </tr> </tbody> </table> <p data-bbox="335 1225 501 1254">Dual scan DP</p> <table border="1" data-bbox="336 1267 1401 1648"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Front Head</td> <td>Leading edge registration of CCD (first side)</td> <td>-27 to 27</td> <td>0</td> <td>0.207 mm</td> </tr> <tr> <td>Front Tail</td> <td>Trailing edge registration of CCD (first side)</td> <td>-27 to 27</td> <td>0</td> <td>0.207 mm</td> </tr> <tr> <td>CIS Head</td> <td>Leading edge registration of CIS</td> <td>-27 to 27</td> <td>0</td> <td>0.207 mm</td> </tr> <tr> <td>CIS Tail</td> <td>Trailing edge registration of CIS</td> <td>-27 to 27</td> <td>0</td> <td>0.207 mm</td> </tr> </tbody> </table>	Display	Description	Setting range	Initial setting	Change in value per step	Front Head	Leading edge registration of CCD (first side)	-32 to 32	0	0.085 mm	Front Tail	Trailing edge registration of CCD (first side)	-32 to 32	0	0.085 mm	Back Head	Leading edge registration of CCD (second side)	-32 to 32	0	0.085 mm	Back Tail	Trailing edge registration of CCD (second side)	-32 to 32	0	0.085 mm	Display	Description	Setting range	Initial setting	Change in value per step	Front Head	Leading edge registration of CCD (first side)	-27 to 27	0	0.207 mm	Front Tail	Trailing edge registration of CCD (first side)	-27 to 27	0	0.207 mm	CIS Head	Leading edge registration of CIS	-27 to 27	0	0.207 mm	CIS Tail	Trailing edge registration of CIS	-27 to 27	0	0.207 mm
Display	Description	Setting range	Initial setting	Change in value per step																																															
Front Head	Leading edge registration of CCD (first side)	-32 to 32	0	0.085 mm																																															
Front Tail	Trailing edge registration of CCD (first side)	-32 to 32	0	0.085 mm																																															
Back Head	Leading edge registration of CCD (second side)	-32 to 32	0	0.085 mm																																															
Back Tail	Trailing edge registration of CCD (second side)	-32 to 32	0	0.085 mm																																															
Display	Description	Setting range	Initial setting	Change in value per step																																															
Front Head	Leading edge registration of CCD (first side)	-27 to 27	0	0.207 mm																																															
Front Tail	Trailing edge registration of CCD (first side)	-27 to 27	0	0.207 mm																																															
CIS Head	Leading edge registration of CIS	-27 to 27	0	0.207 mm																																															
CIS Tail	Trailing edge registration of CIS	-27 to 27	0	0.207 mm																																															

Item No.	Description
U071	<p>Adjustment: Leading edge registration</p> <p>1. Change the setting value using the +/- keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. Increasing the value moves the image forward and decreasing the value moves the image backward.</p> <div data-bbox="655 434 1066 674" style="text-align: center;">  <p>Original Copy example 1 Copy example 2</p> </div> <p style="text-align: center;">Figure 1-3-14</p> <p>2. Press the start key. The value is set.</p> <p>Caution If the first side is adjusted, check the second side and if adjustment is required, carry out the adjustment. If the above adjustment does not optimize the leading edge registration, proceed with the following maintenance modes.</p> <div data-bbox="295 1030 903 1122" style="text-align: center;">  <pre> graph LR A["U039 (P.1-3-40)"] --> B["U034 (P.1-3-34)"] B --> C["U071"] </pre> </div> <p>Adjustment: Trailing edge registration</p> <p>1. Change the setting value using the +/- keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value.</p> <div data-bbox="679 1296 1043 1536" style="text-align: center;">  <p>Original Copy example 1 Copy example 2</p> </div> <p style="text-align: center;">Figure 1-3-15</p> <p>2. Press the start key. The value is set.</p> <p>Caution If the first side is adjusted, check the second side and if adjustment is required, carry out the adjustment.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Item No.	Description																				
U072	<p>Adjusting the DP center line</p> <p>Description Adjusts the scanning start position for the DP original.</p> <p>Purpose Make the adjustment if there is a regular error between the centers of the original and the copy image when the DP is used.</p> <p>Adjustment</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original on the DP and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 734 1401 960"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Front</td> <td>DP center line (first side)</td> <td>-60 to 60</td> <td>0</td> <td>0.085 mm</td> </tr> <tr> <td>Back</td> <td>DP center line (second side)</td> <td>-60 to 60</td> <td>0</td> <td>0.085 mm</td> </tr> <tr> <td>CIS*</td> <td>CIS center line</td> <td>-39 to 39</td> <td>0</td> <td>0.085 mm</td> </tr> </tbody> </table> <p>*: Dual scan DP only</p> <ol style="list-style-type: none"> 6. Change the setting value using the +/- keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. Increasing the value moves the image rightward and decreasing it moves the image leftward. <div data-bbox="646 1126 1074 1368" style="text-align: center;"> <p>Original Copy example 1 Copy example 2</p> </div> <p>Figure 1-3-16</p> <ol style="list-style-type: none"> 7. Press the start key. The value is set. <p>Caution If the first side is adjusted, check the second side and if adjustment is required, carry out the adjustment. If the above adjustment does not optimize the center line, proceed with the following maintenance modes.</p> <pre> graph LR U034["U034 (P.1-3-36)"] --> U065["U065 (P.1-3-52)"] U065 --> U067["U067 (P.1-3-55)"] U067 --> U072["U072"] </pre> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	Front	DP center line (first side)	-60 to 60	0	0.085 mm	Back	DP center line (second side)	-60 to 60	0	0.085 mm	CIS*	CIS center line	-39 to 39	0	0.085 mm
Display	Description	Setting range	Initial setting	Change in value per step																	
Front	DP center line (first side)	-60 to 60	0	0.085 mm																	
Back	DP center line (second side)	-60 to 60	0	0.085 mm																	
CIS*	CIS center line	-39 to 39	0	0.085 mm																	

Item No.	Description																																																						
U073	<p data-bbox="290 241 702 275">Checking the scanner operation</p> <p data-bbox="290 311 440 340">Description</p> <p data-bbox="290 344 1037 374">Simulates the scanner operation under the arbitrary conditions.</p> <p data-bbox="290 380 400 409">Purpose</p> <p data-bbox="290 414 1409 479">To check the scanner operation. This is also done to check the accumulation of dust on the slit glass.</p> <p data-bbox="290 517 387 546">Method</p> <ol data-bbox="306 553 702 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be operated. <table border="1" data-bbox="336 631 1401 871"> <thead> <tr> <th data-bbox="336 631 641 678">Display</th> <th data-bbox="641 631 1401 678">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 678 641 725">Scanner Motor</td> <td data-bbox="641 678 1401 725">Scanner operation</td> </tr> <tr> <td data-bbox="336 725 641 772">Home Position</td> <td data-bbox="641 725 1401 772">Home position operation</td> </tr> <tr> <td data-bbox="336 772 641 819">Dust Check</td> <td data-bbox="641 772 1401 819">Dust adhesion check operation with lamp on</td> </tr> <tr> <td data-bbox="336 819 641 871">DP Reading</td> <td data-bbox="641 819 1401 871">DP scanning position operation</td> </tr> </tbody> </table> <p data-bbox="290 913 606 943">Setting: [Scanner Motor]</p> <ol data-bbox="306 947 786 1048" style="list-style-type: none"> 1. Select [Scanner Motor]. 2. Select the item. 3. Change the setting using the +/- keys. <table border="1" data-bbox="336 1061 1401 1254"> <thead> <tr> <th data-bbox="336 1061 564 1108">Display</th> <th data-bbox="564 1061 1096 1108">Operating conditions</th> <th data-bbox="1096 1061 1401 1108">Setting range</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1108 564 1155">Zoom</td> <td data-bbox="564 1108 1096 1155">Magnification</td> <td data-bbox="1096 1108 1401 1155">25 to 400 %</td> </tr> <tr> <td data-bbox="336 1155 564 1202">Size</td> <td data-bbox="564 1155 1096 1202">Original size</td> <td data-bbox="1096 1155 1401 1202">See below.</td> </tr> <tr> <td data-bbox="336 1202 564 1254">Lamp</td> <td data-bbox="564 1202 1096 1254">On and off of the exposure lamp</td> <td data-bbox="1096 1202 1401 1254">0 (off) or 1 (on)</td> </tr> </tbody> </table> <p data-bbox="336 1294 785 1323">Original sizes for each setting in SIZE</p> <table border="1" data-bbox="336 1339 1401 1722"> <thead> <tr> <th data-bbox="336 1339 603 1386">Setting</th> <th data-bbox="603 1339 869 1386">Paper size</th> <th data-bbox="869 1339 1136 1386">Setting</th> <th data-bbox="1136 1339 1401 1386">Paper size</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1386 603 1433">5000</td> <td data-bbox="603 1386 869 1433">A4</td> <td data-bbox="869 1386 1136 1433">5000</td> <td data-bbox="1136 1386 1401 1433">A5R</td> </tr> <tr> <td data-bbox="336 1433 603 1480">4300</td> <td data-bbox="603 1433 869 1480">B5</td> <td data-bbox="869 1433 1136 1480">7800</td> <td data-bbox="1136 1433 1401 1480">Folio</td> </tr> <tr> <td data-bbox="336 1480 603 1527">5100</td> <td data-bbox="603 1480 869 1527">11" x 8 1/2"</td> <td data-bbox="869 1480 1136 1527">10200</td> <td data-bbox="1136 1480 1401 1527">11" x 17"</td> </tr> <tr> <td data-bbox="336 1527 603 1574">10000</td> <td data-bbox="603 1527 869 1574">A3</td> <td data-bbox="869 1527 1136 1574">9000</td> <td data-bbox="1136 1527 1401 1574">11" x 15"</td> </tr> <tr> <td data-bbox="336 1574 603 1621">8600</td> <td data-bbox="603 1574 869 1621">B4</td> <td data-bbox="869 1574 1136 1621">8400</td> <td data-bbox="1136 1574 1401 1621">8 1/2" x 14"</td> </tr> <tr> <td data-bbox="336 1621 603 1668">7100</td> <td data-bbox="603 1621 869 1668">A4R</td> <td data-bbox="869 1621 1136 1668">6600</td> <td data-bbox="1136 1621 1401 1668">8 1/2" x 11"</td> </tr> <tr> <td data-bbox="336 1668 603 1722">6100</td> <td data-bbox="603 1668 869 1722">B5R</td> <td data-bbox="869 1668 1136 1722">5100</td> <td data-bbox="1136 1668 1401 1722">5 1/2" x 8 1/2"</td> </tr> </tbody> </table> <ol data-bbox="306 1733 1117 1865" style="list-style-type: none"> 4. Press the start key. The setting is set. 5. Select [Execute]. 6. Press the start key. Scanning starts under the selected conditions. 7. To stop operation, press the stop key. 	Display	Description	Scanner Motor	Scanner operation	Home Position	Home position operation	Dust Check	Dust adhesion check operation with lamp on	DP Reading	DP scanning position operation	Display	Operating conditions	Setting range	Zoom	Magnification	25 to 400 %	Size	Original size	See below.	Lamp	On and off of the exposure lamp	0 (off) or 1 (on)	Setting	Paper size	Setting	Paper size	5000	A4	5000	A5R	4300	B5	7800	Folio	5100	11" x 8 1/2"	10200	11" x 17"	10000	A3	9000	11" x 15"	8600	B4	8400	8 1/2" x 14"	7100	A4R	6600	8 1/2" x 11"	6100	B5R	5100	5 1/2" x 8 1/2"
Display	Description																																																						
Scanner Motor	Scanner operation																																																						
Home Position	Home position operation																																																						
Dust Check	Dust adhesion check operation with lamp on																																																						
DP Reading	DP scanning position operation																																																						
Display	Operating conditions	Setting range																																																					
Zoom	Magnification	25 to 400 %																																																					
Size	Original size	See below.																																																					
Lamp	On and off of the exposure lamp	0 (off) or 1 (on)																																																					
Setting	Paper size	Setting	Paper size																																																				
5000	A4	5000	A5R																																																				
4300	B5	7800	Folio																																																				
5100	11" x 8 1/2"	10200	11" x 17"																																																				
10000	A3	9000	11" x 15"																																																				
8600	B4	8400	8 1/2" x 14"																																																				
7100	A4R	6600	8 1/2" x 11"																																																				
6100	B5R	5100	5 1/2" x 8 1/2"																																																				

Item No.	Description
U073	<p>Method: [Home Position]</p> <ol style="list-style-type: none">1. Select [Home Position].2. Press the start key. <p>The mirror frame of the scanner moves to the home position.</p> <p>Method: [Dust Check]</p> <ol style="list-style-type: none">1. Select [Dust Check].2. Press the start key. The exposure lamp lights.3. To turn the exposure lamp off, press the stop key. <p>Method: [DP Reading]</p> <ol style="list-style-type: none">1. Select [DP Reading].2. Press the start key. <p>The mirror frame of the scanner moves to the reading position.</p> <p>Completion</p> <p>Press the stop key when scanning stops. The screen for selecting a maintenance item No. is displayed.</p>


Item No.	Description								
U074	<p data-bbox="288 241 683 275">DP input response adjustment</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1023 376">Sets the density correction for scanning originals from the DP.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1394 479">Modify the setting only if a spotted background appears when a bluish original or a document with a background that is slightly colored is scanned from the DP.</p> <p data-bbox="288 483 1420 548">Perform adjustment if the page scanned using the table and the page scanned using DP do not match.</p> <p data-bbox="288 589 384 618">Setting</p> <ol data-bbox="304 622 922 687" style="list-style-type: none"> 1. Press the start key. 2. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="336 698 1385 866"> <thead> <tr> <th data-bbox="336 698 564 781">Display</th> <th data-bbox="564 698 1050 781">Description</th> <th data-bbox="1050 698 1219 781">Setting range</th> <th data-bbox="1219 698 1385 781">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 781 564 866">Coefficient</td> <td data-bbox="564 781 1050 866">Compensating original document scanning density</td> <td data-bbox="1050 781 1219 866">0 to 3</td> <td data-bbox="1219 781 1385 866">1</td> </tr> </tbody> </table> <p data-bbox="336 875 1402 907">Settings 0: No correction / 1: Slight correction / 2: Medium correction / 3: Strong correction</p> <ol data-bbox="304 911 767 943" style="list-style-type: none"> 3. Press the start key. The value is set. <p data-bbox="288 978 448 1008">Supplement</p> <p data-bbox="288 1012 1418 1077">While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p data-bbox="288 1117 440 1146">Completion</p> <p data-bbox="288 1151 1256 1182">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Coefficient	Compensating original document scanning density	0 to 3	1
Display	Description	Setting range	Initial setting						
Coefficient	Compensating original document scanning density	0 to 3	1						

Item No.	Description																						
U087	<p data-bbox="288 241 938 275">Setting DP reading position modification operation</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 347 1426 479">The presence or absence of dust is determined by comparing the scan data of the original trailing edge and that taken after the original is conveyed past the DP original scanning position. If dust is identified, the DP original scanning position is adjusted for the following originals. Using image correction to reduce black streaks.</p> <p data-bbox="288 486 400 515">Purpose</p> <p data-bbox="288 521 1385 584">When using DP, to solve the problem when black lines occurs due to the dust with respect to original reading position.</p> <p data-bbox="288 622 392 651">Caution</p> <p data-bbox="288 658 1398 721">The coordinates of position where documents are scanned are modified when [System Menu] [Adjustment/Maintenance] [Correcting Black Line] is set to [Off].</p> <p data-bbox="288 759 387 788">Method</p> <ol data-bbox="304 795 632 857" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 875 1401 1016"> <thead> <tr> <th data-bbox="336 875 639 920">Display</th> <th data-bbox="639 875 1401 920">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 920 639 965">CCD</td> <td data-bbox="639 920 1401 965">Setting of standard data when dust is detected.</td> </tr> <tr> <td data-bbox="336 965 639 1016">Black Line</td> <td data-bbox="639 965 1401 1016">Initialization of original reading position.</td> </tr> </tbody> </table> <p data-bbox="288 1061 475 1090">Setting: [CCD]</p> <ol data-bbox="304 1097 906 1160" style="list-style-type: none"> 1. Select the item to be set. 2. Change the value using the +/- or numeric keys. <table border="1" data-bbox="336 1176 1385 1402"> <thead> <tr> <th data-bbox="336 1176 488 1256">Display</th> <th data-bbox="488 1176 1050 1256">Description</th> <th data-bbox="1050 1176 1219 1256">Setting range</th> <th data-bbox="1219 1176 1385 1256">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1256 488 1301">R</td> <td data-bbox="488 1256 1050 1301">Lowest density of the R regard as the dust</td> <td data-bbox="1050 1256 1219 1301">0 to 255</td> <td data-bbox="1219 1256 1385 1301">125</td> </tr> <tr> <td data-bbox="336 1301 488 1346">G</td> <td data-bbox="488 1301 1050 1346">Lowest density of the G regard as the dust</td> <td data-bbox="1050 1301 1219 1346">0 to 255</td> <td data-bbox="1219 1301 1385 1346">125</td> </tr> <tr> <td data-bbox="336 1346 488 1402">B</td> <td data-bbox="488 1346 1050 1402">Lowest density of the B regard as the dust</td> <td data-bbox="1050 1346 1219 1402">0 to 255</td> <td data-bbox="1219 1346 1385 1402">125</td> </tr> </tbody> </table> <ol data-bbox="304 1413 767 1442" style="list-style-type: none"> 3. Press the start key. The value is set. <p data-bbox="288 1480 555 1509">Method: [Black Line]</p> <ol data-bbox="304 1516 831 1579" style="list-style-type: none"> 1. Select [Clear]. 2. Press the start key. The setting is cleared. <p data-bbox="288 1617 440 1646">Completion</p> <p data-bbox="288 1653 1254 1682">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	CCD	Setting of standard data when dust is detected.	Black Line	Initialization of original reading position.	Display	Description	Setting range	Initial setting	R	Lowest density of the R regard as the dust	0 to 255	125	G	Lowest density of the G regard as the dust	0 to 255	125	B	Lowest density of the B regard as the dust	0 to 255	125
Display	Description																						
CCD	Setting of standard data when dust is detected.																						
Black Line	Initialization of original reading position.																						
Display	Description	Setting range	Initial setting																				
R	Lowest density of the R regard as the dust	0 to 255	125																				
G	Lowest density of the G regard as the dust	0 to 255	125																				
B	Lowest density of the B regard as the dust	0 to 255	125																				

Item No.	Description																														
U089	<p data-bbox="288 241 651 271">Outputting a MIP-PG pattern</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1050 374">Selects and outputs the MIP-PG pattern created in the machine.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1422 479">To check copier status other than scanner when adjusting image printing, using MIP-PG pattern output (with-out scanning).</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 553 1082 618" style="list-style-type: none"> 1. Press the start key. 2. Select the MIP-PG pattern to be output and press the start key. <table border="1" data-bbox="336 631 1399 1247"> <thead> <tr> <th data-bbox="336 631 564 676">Display</th> <th data-bbox="564 631 908 676">Description</th> <th data-bbox="908 631 1399 676">Purpose</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 676 564 721">256Gradation</td> <td data-bbox="564 676 908 721">256-gradation PG</td> <td data-bbox="908 676 1399 721">To check the gradation reproducibility</td> </tr> <tr> <td data-bbox="336 721 564 808">Color Belt</td> <td data-bbox="564 721 908 808">Four color belts PG</td> <td data-bbox="908 721 1399 808">To check the developer state and the engine section ID</td> </tr> <tr> <td data-bbox="336 808 564 853">Gray(C)</td> <td data-bbox="564 808 908 853">Cyan PG</td> <td data-bbox="908 808 1399 853">To check the drum quality</td> </tr> <tr> <td data-bbox="336 853 564 898">Gray(M)</td> <td data-bbox="564 853 908 898">Magenta PG</td> <td data-bbox="908 853 1399 898">To check the drum quality</td> </tr> <tr> <td data-bbox="336 898 564 943">Gray(Y)</td> <td data-bbox="564 898 908 943">Yellow PG</td> <td data-bbox="908 898 1399 943">To check the drum quality</td> </tr> <tr> <td data-bbox="336 943 564 987">Gray(K)</td> <td data-bbox="564 943 908 987">Black PG</td> <td data-bbox="908 943 1399 987">To check the drum quality</td> </tr> <tr> <td data-bbox="336 987 564 1032">White</td> <td data-bbox="564 987 908 1032">Blank paper PG</td> <td data-bbox="908 987 1399 1032">To check the drum quality</td> </tr> <tr> <td data-bbox="336 1032 564 1120">Gradation Gray</td> <td data-bbox="564 1032 908 1120">5-gradation gray PG</td> <td data-bbox="908 1032 1399 1120">To check for vertical lines on the laser scanner unit</td> </tr> <tr> <td data-bbox="336 1120 564 1247">Sample Set</td> <td data-bbox="564 1120 908 1247">Four color belts PG, Cyan PG, Magenta PG, Yellow PG and Black PG</td> <td data-bbox="908 1120 1399 1247">Pattern output for LLU assurance application</td> </tr> </tbody> </table> <ol data-bbox="304 1261 898 1326" style="list-style-type: none"> 3. Press the system menu key. 4. Press the start key. A MIP-PG pattern is output. <p data-bbox="288 1361 440 1391">Completion</p> <p data-bbox="288 1395 1254 1424">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Purpose	256Gradation	256-gradation PG	To check the gradation reproducibility	Color Belt	Four color belts PG	To check the developer state and the engine section ID	Gray(C)	Cyan PG	To check the drum quality	Gray(M)	Magenta PG	To check the drum quality	Gray(Y)	Yellow PG	To check the drum quality	Gray(K)	Black PG	To check the drum quality	White	Blank paper PG	To check the drum quality	Gradation Gray	5-gradation gray PG	To check for vertical lines on the laser scanner unit	Sample Set	Four color belts PG, Cyan PG, Magenta PG, Yellow PG and Black PG	Pattern output for LLU assurance application
Display	Description	Purpose																													
256Gradation	256-gradation PG	To check the gradation reproducibility																													
Color Belt	Four color belts PG	To check the developer state and the engine section ID																													
Gray(C)	Cyan PG	To check the drum quality																													
Gray(M)	Magenta PG	To check the drum quality																													
Gray(Y)	Yellow PG	To check the drum quality																													
Gray(K)	Black PG	To check the drum quality																													
White	Blank paper PG	To check the drum quality																													
Gradation Gray	5-gradation gray PG	To check for vertical lines on the laser scanner unit																													
Sample Set	Four color belts PG, Cyan PG, Magenta PG, Yellow PG and Black PG	Pattern output for LLU assurance application																													

Item No.	Description																				
U091	<p data-bbox="288 241 699 275">Setting the white line correction</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1422 409">Sets the error detection threshold value for white line correction and displays the count result of abnormal pixels.</p> <p data-bbox="288 414 400 443">Purpose</p> <p data-bbox="288 448 1046 479">To perform when replacing the CIS, DP main PWB or CIS roller.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 553 564 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 631 1401 1146"> <thead> <tr> <th data-bbox="336 631 564 680">Display</th> <th data-bbox="564 631 1401 680">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 680 564 730">Calculation(R)</td> <td data-bbox="564 680 1401 730">Abnormal pixel count result for color R</td> </tr> <tr> <td data-bbox="336 730 564 779">Calculation(G)</td> <td data-bbox="564 730 1401 779">Abnormal pixel count result for color G</td> </tr> <tr> <td data-bbox="336 779 564 828">Calculation(B)</td> <td data-bbox="564 779 1401 828">Abnormal pixel count result for color B</td> </tr> <tr> <td data-bbox="336 828 564 878">Threshold(R)</td> <td data-bbox="564 828 1401 878">Displaying of abnormal pixel detection threshold value for color R</td> </tr> <tr> <td data-bbox="336 878 564 927">Threshold(G)</td> <td data-bbox="564 878 1401 927">Displaying of abnormal pixel detection threshold value for color G</td> </tr> <tr> <td data-bbox="336 927 564 976">Threshold(B)</td> <td data-bbox="564 927 1401 976">Displaying of abnormal pixel detection threshold value for color B</td> </tr> <tr> <td data-bbox="336 976 564 1050">Threshold (Abnormal)</td> <td data-bbox="564 976 1401 1050">Abnormal pixel threshold value setting</td> </tr> <tr> <td data-bbox="336 1050 564 1099">Mode</td> <td data-bbox="564 1050 1401 1099">Switching between white line correction mode ON/OFF</td> </tr> <tr> <td data-bbox="336 1099 564 1146">Execute</td> <td data-bbox="564 1099 1401 1146">Holding of white reference data</td> </tr> </tbody> </table> <p data-bbox="288 1189 663 1218">Method: white line correction</p> <ol data-bbox="304 1225 1430 1805" style="list-style-type: none"> 1. Press [Execute]. 2. Press the start key. Holding of white reference data is started. 3. The count result of abnormal pixels is displayed. 4. Press the system menu key. 5. Place a gray original on the DP with the gray side down. Load paper in the cassette. The paper should be the same size as the original. 6. Press the start key. Two test pattern sheets will be printed.(1 st sheet: Approx. 60 mm black band, 2nd sheet: Blank or approx. 60 mm gray band) 7. If vertical black lines appear on the blank (or gray band) page and vertical white lines appear on the black band in the same position, clean the CIS roller and the CIS glass and then repeat white line correction. If vertical black lines or vertical white lines appear on both sheets, white line correction has been completed normally. However, the cause of the vertical lines lies in the engine, and thus the engine must be checked. 8. Press the system menu key. Mode is set to 1. 	Display	Description	Calculation(R)	Abnormal pixel count result for color R	Calculation(G)	Abnormal pixel count result for color G	Calculation(B)	Abnormal pixel count result for color B	Threshold(R)	Displaying of abnormal pixel detection threshold value for color R	Threshold(G)	Displaying of abnormal pixel detection threshold value for color G	Threshold(B)	Displaying of abnormal pixel detection threshold value for color B	Threshold (Abnormal)	Abnormal pixel threshold value setting	Mode	Switching between white line correction mode ON/OFF	Execute	Holding of white reference data
Display	Description																				
Calculation(R)	Abnormal pixel count result for color R																				
Calculation(G)	Abnormal pixel count result for color G																				
Calculation(B)	Abnormal pixel count result for color B																				
Threshold(R)	Displaying of abnormal pixel detection threshold value for color R																				
Threshold(G)	Displaying of abnormal pixel detection threshold value for color G																				
Threshold(B)	Displaying of abnormal pixel detection threshold value for color B																				
Threshold (Abnormal)	Abnormal pixel threshold value setting																				
Mode	Switching between white line correction mode ON/OFF																				
Execute	Holding of white reference data																				

Item No.	Description																																				
U091	<p data-bbox="336 241 639 271">How to view test copies</p> <table border="1" data-bbox="336 284 1401 560"> <thead> <tr> <th data-bbox="336 284 528 329">blank sheet</th> <th data-bbox="528 284 716 329">black band</th> <th data-bbox="716 284 1021 329">Causes</th> <th data-bbox="1021 284 1401 329">Corrective measures</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 329 528 374">No lines</td> <td data-bbox="528 329 716 374">No lines</td> <td data-bbox="716 329 1021 374">-</td> <td data-bbox="1021 329 1401 374">Complete</td> </tr> <tr> <td data-bbox="336 374 528 463">Black lines</td> <td data-bbox="528 374 716 463">White lines</td> <td data-bbox="716 374 1021 463">Dirty CIS roller or CIS glass</td> <td data-bbox="1021 374 1401 463">Clean CIS roller or CIS glass and then perform U091 again</td> </tr> <tr> <td data-bbox="336 463 528 508">Black lines</td> <td data-bbox="528 463 716 508">No lines</td> <td data-bbox="716 463 1021 508">Engine side</td> <td data-bbox="1021 463 1401 508">U091 ends, check engine</td> </tr> <tr> <td data-bbox="336 508 528 560">No lines</td> <td data-bbox="528 508 716 560">White lines</td> <td data-bbox="716 508 1021 560">Engine side</td> <td data-bbox="1021 508 1401 560">U091 ends, check engine</td> </tr> </tbody> </table> <p data-bbox="290 607 699 636">Setting: Threshold value setting</p> <ol data-bbox="308 640 906 703" style="list-style-type: none"> 1. Select the item to be set. 2. Change the value using the +/- or numeric keys. <table border="1" data-bbox="336 719 1385 1084"> <thead> <tr> <th data-bbox="336 719 564 801">Display</th> <th data-bbox="564 719 1050 801">Description</th> <th data-bbox="1050 719 1233 801">Setting range</th> <th data-bbox="1233 719 1385 801">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 801 564 884">Threshold(B)</td> <td data-bbox="564 801 1050 884">Displaying of abnormal pixel detection threshold value for color B</td> <td data-bbox="1050 801 1233 884">0 to 1023</td> <td data-bbox="1233 801 1385 884">112</td> </tr> <tr> <td data-bbox="336 884 564 967">Threshold (Abnormal)</td> <td data-bbox="564 884 1050 967">Abnormal pixel threshold value setting</td> <td data-bbox="1050 884 1233 967">0 to 8191</td> <td data-bbox="1233 884 1385 967">75</td> </tr> <tr> <td data-bbox="336 967 564 1084">Mode</td> <td data-bbox="564 967 1050 1084">Switching between white line correction mode ON/OFF</td> <td data-bbox="1050 967 1233 1084">0: OFF/ 1: ON/ 2: Test mode</td> <td data-bbox="1233 967 1385 1084">0</td> </tr> </tbody> </table> <p data-bbox="336 1099 1433 1227">* : Normally the Threshold (Com) value should not be changed from 112, the initial setting. If white lines appear even though the CIS roller and glass are not dirty, raise the set value. If fine lines in some originals disappear, lower the set value. Set within the range 50 to 200. (If set outside this range, the image may be affected.)</p> <ol data-bbox="308 1267 767 1296" style="list-style-type: none"> 3. Press the start key. The value is set. <p data-bbox="290 1337 440 1366">Completion</p> <p data-bbox="290 1370 1254 1400">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	blank sheet	black band	Causes	Corrective measures	No lines	No lines	-	Complete	Black lines	White lines	Dirty CIS roller or CIS glass	Clean CIS roller or CIS glass and then perform U091 again	Black lines	No lines	Engine side	U091 ends, check engine	No lines	White lines	Engine side	U091 ends, check engine	Display	Description	Setting range	Initial setting	Threshold(B)	Displaying of abnormal pixel detection threshold value for color B	0 to 1023	112	Threshold (Abnormal)	Abnormal pixel threshold value setting	0 to 8191	75	Mode	Switching between white line correction mode ON/OFF	0: OFF/ 1: ON/ 2: Test mode	0
blank sheet	black band	Causes	Corrective measures																																		
No lines	No lines	-	Complete																																		
Black lines	White lines	Dirty CIS roller or CIS glass	Clean CIS roller or CIS glass and then perform U091 again																																		
Black lines	No lines	Engine side	U091 ends, check engine																																		
No lines	White lines	Engine side	U091 ends, check engine																																		
Display	Description	Setting range	Initial setting																																		
Threshold(B)	Displaying of abnormal pixel detection threshold value for color B	0 to 1023	112																																		
Threshold (Abnormal)	Abnormal pixel threshold value setting	0 to 8191	75																																		
Mode	Switching between white line correction mode ON/OFF	0: OFF/ 1: ON/ 2: Test mode	0																																		
U099	<p data-bbox="290 1420 703 1449">Adjusting original size detection</p> <p data-bbox="290 1489 440 1518">Description</p> <p data-bbox="290 1523 1334 1552">Checks the operation of the original size detection and sets the sensing threshold value.</p> <p data-bbox="290 1556 400 1585">Purpose</p> <p data-bbox="290 1590 1425 1655">Modify the threshold of detection if documents are frequently mal-detected in size after scanning a wholly dark document or a document enclosed with dark objects on edges.</p> <p data-bbox="290 1695 387 1724">Method</p> <ol data-bbox="308 1729 564 1792" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 1807 1401 2000"> <thead> <tr> <th data-bbox="336 1807 504 1852">Display</th> <th data-bbox="504 1807 1401 1852">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1852 504 1897">Data1</td> <td data-bbox="504 1852 1401 1897">Displaying original size detection transmission data</td> </tr> <tr> <td data-bbox="336 1897 504 1942">B/W Level1</td> <td data-bbox="504 1897 1401 1942">Setting original size detection threshold value</td> </tr> <tr> <td data-bbox="336 1942 504 2000">Data2</td> <td data-bbox="504 1942 1401 2000">Displaying original size detection transmission data (when DP is installed)</td> </tr> </tbody> </table>	Display	Description	Data1	Displaying original size detection transmission data	B/W Level1	Setting original size detection threshold value	Data2	Displaying original size detection transmission data (when DP is installed)																												
Display	Description																																				
Data1	Displaying original size detection transmission data																																				
B/W Level1	Setting original size detection threshold value																																				
Data2	Displaying original size detection transmission data (when DP is installed)																																				

Item No.	Description																																																																				
U099	<p>Method: [Data1/Data2]</p> <ol style="list-style-type: none"> Place the original and close the original cover or DP The light source illuminates and the CCD sensor determines the width of the document. The original size sensor determines the document is vertical or horizontal. (The document is detected two times when the DP is installed.) <table border="1" data-bbox="336 421 1401 712"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Original Area R</td> <td>Detected original width size for color R</td> </tr> <tr> <td>Original Area G</td> <td>Detected original width size for color G</td> </tr> <tr> <td>Original Area B</td> <td>Detected original width size for color B</td> </tr> <tr> <td>Original Area</td> <td>Detected original width size</td> </tr> <tr> <td>Size SW L</td> <td>Displays the original size sensor (OSS) ON/OFF</td> </tr> </tbody> </table> <p>Setting: [B/W Level1]</p> <ol style="list-style-type: none"> Select an item to be set. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 862 1401 1377"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting*</th> </tr> </thead> <tbody> <tr> <td>Original R1</td> <td>Original threshold value for color R (near side)</td> <td>0 to 255</td> <td>20/50</td> </tr> <tr> <td>Original R2</td> <td>Original threshold value for color R (center)</td> <td>0 to 255</td> <td>30/50</td> </tr> <tr> <td>Original R3</td> <td>Original threshold value for color R (far side)</td> <td>0 to 255</td> <td>40/50</td> </tr> <tr> <td>Original G1</td> <td>Original threshold value for color G (near side)</td> <td>0 to 255</td> <td>20/50</td> </tr> <tr> <td>Original G2</td> <td>Original threshold value for color G (center)</td> <td>0 to 255</td> <td>30/50</td> </tr> <tr> <td>Original G3</td> <td>Original threshold value for color G (far side)</td> <td>0 to 255</td> <td>40/50</td> </tr> <tr> <td>Original B1</td> <td>Original threshold value for color B (near side)</td> <td>0 to 255</td> <td>20/50</td> </tr> <tr> <td>Original B2</td> <td>Original threshold value for color B (center)</td> <td>0 to 255</td> <td>30/50</td> </tr> <tr> <td>Original B3</td> <td>Original threshold value for color B (far side)</td> <td>0 to 255</td> <td>40/50</td> </tr> </tbody> </table> <p>*:DP is not installed/DP is installed</p> <p>Reducing the value increases the sensitivity of the sensor allowing a document with more density to be detected, however, the document mat could be detected as an original document.</p> <p>If the values vary excessively, mal-detection could occur depending on how a document is placed.</p> <div data-bbox="347 1615 805 1917" style="display: flex; align-items: center;">  </div> <table border="1" data-bbox="874 1715 1374 1917" style="margin-left: 20px;"> <thead> <tr> <th>Fig.</th> <th>Original R/G/B</th> <th colspan="2">Original width size range</th> </tr> </thead> <tbody> <tr> <td>①</td> <td>1</td> <td>A4R to A3</td> <td>8.5" to 11"</td> </tr> <tr> <td>②</td> <td>2</td> <td>B6R to A4R</td> <td>5.5" to 8.5"</td> </tr> <tr> <td>③</td> <td>3</td> <td>to B6R</td> <td>to 5.5"</td> </tr> </tbody> </table> <p style="text-align: center;">Figure 1-3-17</p> <ol style="list-style-type: none"> Press the start key. The value is set. 	Display	Description	Original Area R	Detected original width size for color R	Original Area G	Detected original width size for color G	Original Area B	Detected original width size for color B	Original Area	Detected original width size	Size SW L	Displays the original size sensor (OSS) ON/OFF	Display	Description	Setting range	Initial setting*	Original R1	Original threshold value for color R (near side)	0 to 255	20/50	Original R2	Original threshold value for color R (center)	0 to 255	30/50	Original R3	Original threshold value for color R (far side)	0 to 255	40/50	Original G1	Original threshold value for color G (near side)	0 to 255	20/50	Original G2	Original threshold value for color G (center)	0 to 255	30/50	Original G3	Original threshold value for color G (far side)	0 to 255	40/50	Original B1	Original threshold value for color B (near side)	0 to 255	20/50	Original B2	Original threshold value for color B (center)	0 to 255	30/50	Original B3	Original threshold value for color B (far side)	0 to 255	40/50	Fig.	Original R/G/B	Original width size range		①	1	A4R to A3	8.5" to 11"	②	2	B6R to A4R	5.5" to 8.5"	③	3	to B6R	to 5.5"
Display	Description																																																																				
Original Area R	Detected original width size for color R																																																																				
Original Area G	Detected original width size for color G																																																																				
Original Area B	Detected original width size for color B																																																																				
Original Area	Detected original width size																																																																				
Size SW L	Displays the original size sensor (OSS) ON/OFF																																																																				
Display	Description	Setting range	Initial setting*																																																																		
Original R1	Original threshold value for color R (near side)	0 to 255	20/50																																																																		
Original R2	Original threshold value for color R (center)	0 to 255	30/50																																																																		
Original R3	Original threshold value for color R (far side)	0 to 255	40/50																																																																		
Original G1	Original threshold value for color G (near side)	0 to 255	20/50																																																																		
Original G2	Original threshold value for color G (center)	0 to 255	30/50																																																																		
Original G3	Original threshold value for color G (far side)	0 to 255	40/50																																																																		
Original B1	Original threshold value for color B (near side)	0 to 255	20/50																																																																		
Original B2	Original threshold value for color B (center)	0 to 255	30/50																																																																		
Original B3	Original threshold value for color B (far side)	0 to 255	40/50																																																																		
Fig.	Original R/G/B	Original width size range																																																																			
①	1	A4R to A3	8.5" to 11"																																																																		
②	2	B6R to A4R	5.5" to 8.5"																																																																		
③	3	to B6R	to 5.5"																																																																		

Item No.	Description																																										
U099	<p>Completion Press the stop key. The screen for maintenance item No. is displayed.</p>																																										
U100	<p>Adjusting main high voltage</p> <p>Description Controls the charger roller voltage to optimize the surface potential.</p> <p>Purpose To change the setting value to adjust the image if an image failure (background blur, etc.) occurs.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 1. Select an item and press the start key. <table border="1" data-bbox="336 645 1401 1077"> <thead> <tr> <th data-bbox="336 645 639 689">Display</th> <th data-bbox="639 645 1401 689">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 689 639 734">Adj AC Bias</td> <td data-bbox="639 689 1401 734">Main charger AC bias for each color</td> </tr> <tr> <td data-bbox="336 734 639 779">Set AC Auto Adj</td> <td data-bbox="639 734 1401 779">Setting the AC bias auto adjustment</td> </tr> <tr> <td data-bbox="336 779 639 824">Set DC Bias</td> <td data-bbox="639 779 1401 824">Main charger DC bias for each color</td> </tr> <tr> <td data-bbox="336 824 639 869">Adj DC Bias</td> <td data-bbox="639 824 1401 869">Additional surface potential</td> </tr> <tr> <td data-bbox="336 869 639 913">Set Low Temp</td> <td data-bbox="639 869 1401 913">Pre-charge time at power supply ON</td> </tr> <tr> <td data-bbox="336 913 639 958">Set Charger Freq</td> <td data-bbox="639 913 1401 958">Setting the main charger frequency</td> </tr> <tr> <td data-bbox="336 958 639 1003">Chk Current</td> <td data-bbox="639 958 1401 1003">Rush current display</td> </tr> <tr> <td data-bbox="336 1003 639 1077">Set AC Gain*</td> <td data-bbox="639 1003 1401 1077">Setting the AC Gain</td> </tr> </tbody> </table> <p data-bbox="336 1077 691 1111">*: 30 ppm/35 ppm model only.</p> <p>Setting: [Adj AC Bias]</p> <ol style="list-style-type: none"> 1. Change the value using the +/- or numeric keys. Increasing the setting makes the image lighter; decreasing it makes the image darker. The values set vary depending on environments. <table border="1" data-bbox="336 1294 1401 1621"> <thead> <tr> <th data-bbox="336 1294 603 1339">Display</th> <th data-bbox="603 1294 1171 1339">Description</th> <th data-bbox="1171 1294 1401 1339">Setting range</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1339 603 1384">AC Bias(C)</td> <td data-bbox="603 1339 1171 1384">Main charger AC bias for cyan</td> <td data-bbox="1171 1339 1401 1384">0 to 255</td> </tr> <tr> <td data-bbox="336 1384 603 1429">AC Bias(M)</td> <td data-bbox="603 1384 1171 1429">Main charger AC bias for magenta</td> <td data-bbox="1171 1384 1401 1429">0 to 255</td> </tr> <tr> <td data-bbox="336 1429 603 1473">AC Bias(Y)</td> <td data-bbox="603 1429 1171 1473">Main charger AC bias for yellow</td> <td data-bbox="1171 1429 1401 1473">0 to 255</td> </tr> <tr> <td data-bbox="336 1473 603 1518">AC Bias(K)</td> <td data-bbox="603 1473 1171 1518">Main charger AC bias for black</td> <td data-bbox="1171 1473 1401 1518">0 to 255</td> </tr> <tr> <td data-bbox="336 1518 603 1621">AC Bias B/W(K)*</td> <td data-bbox="603 1518 1171 1621">Main charger AC bias for black in black/white mode</td> <td data-bbox="1171 1518 1401 1621">0 to 255</td> </tr> </tbody> </table> <p data-bbox="336 1621 595 1655">*: 55 ppm model only.</p> <ol style="list-style-type: none"> 2. Press the start key. The value is set. <p>Setting: [Set AC Auto Adj]</p> <ol style="list-style-type: none"> 1. Select On or Off. <table border="1" data-bbox="336 1809 1401 1955"> <thead> <tr> <th data-bbox="336 1809 639 1854">Display</th> <th data-bbox="639 1809 1401 1854">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1854 639 1899">On</td> <td data-bbox="639 1854 1401 1899">Turns auto adjustment ON</td> </tr> <tr> <td data-bbox="336 1899 639 1955">Off</td> <td data-bbox="639 1899 1401 1955">Turns auto adjustment OFF</td> </tr> </tbody> </table> <p data-bbox="336 1955 539 1989">Initial setting: On</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. 	Display	Description	Adj AC Bias	Main charger AC bias for each color	Set AC Auto Adj	Setting the AC bias auto adjustment	Set DC Bias	Main charger DC bias for each color	Adj DC Bias	Additional surface potential	Set Low Temp	Pre-charge time at power supply ON	Set Charger Freq	Setting the main charger frequency	Chk Current	Rush current display	Set AC Gain*	Setting the AC Gain	Display	Description	Setting range	AC Bias(C)	Main charger AC bias for cyan	0 to 255	AC Bias(M)	Main charger AC bias for magenta	0 to 255	AC Bias(Y)	Main charger AC bias for yellow	0 to 255	AC Bias(K)	Main charger AC bias for black	0 to 255	AC Bias B/W(K)*	Main charger AC bias for black in black/white mode	0 to 255	Display	Description	On	Turns auto adjustment ON	Off	Turns auto adjustment OFF
Display	Description																																										
Adj AC Bias	Main charger AC bias for each color																																										
Set AC Auto Adj	Setting the AC bias auto adjustment																																										
Set DC Bias	Main charger DC bias for each color																																										
Adj DC Bias	Additional surface potential																																										
Set Low Temp	Pre-charge time at power supply ON																																										
Set Charger Freq	Setting the main charger frequency																																										
Chk Current	Rush current display																																										
Set AC Gain*	Setting the AC Gain																																										
Display	Description	Setting range																																									
AC Bias(C)	Main charger AC bias for cyan	0 to 255																																									
AC Bias(M)	Main charger AC bias for magenta	0 to 255																																									
AC Bias(Y)	Main charger AC bias for yellow	0 to 255																																									
AC Bias(K)	Main charger AC bias for black	0 to 255																																									
AC Bias B/W(K)*	Main charger AC bias for black in black/white mode	0 to 255																																									
Display	Description																																										
On	Turns auto adjustment ON																																										
Off	Turns auto adjustment OFF																																										

Item No.	Description																																																																				
U100	<p data-bbox="288 241 614 273">Displaying: [Set DC Bias]</p> <p data-bbox="304 277 715 309">1. The current setting is displayed.</p> <table border="1" data-bbox="336 320 1401 797"> <thead> <tr> <th data-bbox="336 320 639 365">Display</th> <th data-bbox="639 320 1401 365">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 365 639 409">DC1 Bias(C)</td> <td data-bbox="639 365 1401 409">Main charger DC bias for cyan (full speed)</td> </tr> <tr> <td data-bbox="336 409 639 454">DC1 Bias Half(C)</td> <td data-bbox="639 409 1401 454">Main charger DC bias for cyan (half speed)</td> </tr> <tr> <td data-bbox="336 454 639 499">DC1 Bias(M)</td> <td data-bbox="639 454 1401 499">Main charger DC bias for magenta (full speed)</td> </tr> <tr> <td data-bbox="336 499 639 544">DC1 Bias Half(M)</td> <td data-bbox="639 499 1401 544">Main charger DC bias for magenta (half speed)</td> </tr> <tr> <td data-bbox="336 544 639 589">DC1 Bias(Y)</td> <td data-bbox="639 544 1401 589">Main charger DC bias for yellow (full speed)</td> </tr> <tr> <td data-bbox="336 589 639 633">DC1 Bias Half(Y)</td> <td data-bbox="639 589 1401 633">Main charger DC bias for yellow (half speed)</td> </tr> <tr> <td data-bbox="336 633 639 678">DC1 Bias(K)</td> <td data-bbox="639 633 1401 678">Main charger DC bias for black (full speed)</td> </tr> <tr> <td data-bbox="336 678 639 723">DC1 Bias Half(K)</td> <td data-bbox="639 678 1401 723">Main charger DC bias for black (half speed)</td> </tr> <tr> <td data-bbox="336 723 639 797">DC1 Bias B/W(K)*</td> <td data-bbox="639 723 1401 797">Main charger DC bias for black in black/white mode</td> </tr> </tbody> </table> <p data-bbox="336 808 593 840">*: 55 ppm model only.</p> <p data-bbox="288 880 571 911">Setting: [Adj DC Bias]</p> <p data-bbox="304 916 632 947">1. Select the item to be set.</p> <p data-bbox="304 952 906 983">2. Change the value using the +/- or numeric keys.</p> <p data-bbox="336 987 1358 1019">Increasing the setting makes the image lighter; decreasing it makes the image darker.</p> <table border="1" data-bbox="336 1025 1385 1641"> <thead> <tr> <th data-bbox="336 1025 571 1104">Display</th> <th data-bbox="571 1025 1118 1104">Description</th> <th data-bbox="1118 1025 1270 1104">Setting range</th> <th data-bbox="1270 1025 1385 1104">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1104 571 1149">DC2 Bias(C)</td> <td data-bbox="571 1104 1118 1149">Main charger DC bias for cyan (full speed)</td> <td data-bbox="1118 1104 1270 1149">128 to 127</td> <td data-bbox="1270 1104 1385 1149">0</td> </tr> <tr> <td data-bbox="336 1149 571 1193">DC2 Bias Half(C)</td> <td data-bbox="571 1149 1118 1193">Main charger DC bias for cyan (half speed)</td> <td data-bbox="1118 1149 1270 1193">128 to 127</td> <td data-bbox="1270 1149 1385 1193">0</td> </tr> <tr> <td data-bbox="336 1193 571 1283">DC2 Bias(M)</td> <td data-bbox="571 1193 1118 1283">Main charger DC bias for magenta (full speed)</td> <td data-bbox="1118 1193 1270 1283">128 to 127</td> <td data-bbox="1270 1193 1385 1283">0</td> </tr> <tr> <td data-bbox="336 1283 571 1373">DC2 Bias Half(M)</td> <td data-bbox="571 1283 1118 1373">Main charger DC bias for magenta (half speed)</td> <td data-bbox="1118 1283 1270 1373">128 to 127</td> <td data-bbox="1270 1283 1385 1373">0</td> </tr> <tr> <td data-bbox="336 1373 571 1417">DC2 Bias(Y)</td> <td data-bbox="571 1373 1118 1417">Main charger DC bias for yellow (full speed)</td> <td data-bbox="1118 1373 1270 1417">128 to 127</td> <td data-bbox="1270 1373 1385 1417">0</td> </tr> <tr> <td data-bbox="336 1417 571 1462">DC2 Bias Half(Y)</td> <td data-bbox="571 1417 1118 1462">Main charger DC bias for yellow (half speed)</td> <td data-bbox="1118 1417 1270 1462">128 to 127</td> <td data-bbox="1270 1417 1385 1462">0</td> </tr> <tr> <td data-bbox="336 1462 571 1507">DC2 Bias(K)</td> <td data-bbox="571 1462 1118 1507">Main charger DC bias for black (full speed)</td> <td data-bbox="1118 1462 1270 1507">128 to 127</td> <td data-bbox="1270 1462 1385 1507">0</td> </tr> <tr> <td data-bbox="336 1507 571 1552">DC2 Bias Half(K)</td> <td data-bbox="571 1507 1118 1552">Main charger DC bias for black (half speed)</td> <td data-bbox="1118 1507 1270 1552">128 to 127</td> <td data-bbox="1270 1507 1385 1552">0</td> </tr> <tr> <td data-bbox="336 1552 571 1641">DC2 Bias B/W(K)*</td> <td data-bbox="571 1552 1118 1641">Main charger DC bias for black in black/white mode</td> <td data-bbox="1118 1552 1270 1641"></td> <td data-bbox="1270 1552 1385 1641"></td> </tr> </tbody> </table> <p data-bbox="336 1653 593 1684">*: 55 ppm model only.</p> <p data-bbox="304 1688 767 1720">3. Press the start key. The value is set.</p> <p data-bbox="288 1760 596 1792">Setting: [Set Low Temp]</p> <p data-bbox="304 1796 914 1827">1. Change the value using the +/- or numeric keys.</p> <table border="1" data-bbox="336 1834 1385 1962"> <thead> <tr> <th data-bbox="336 1834 564 1912">Display</th> <th data-bbox="564 1834 1050 1912">Description</th> <th data-bbox="1050 1834 1219 1912">Setting range</th> <th data-bbox="1219 1834 1385 1912">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1912 564 1962">Set Low Temp</td> <td data-bbox="564 1912 1050 1962">Pre-charge time at power supply ON</td> <td data-bbox="1050 1912 1219 1962">0 to 6</td> <td data-bbox="1219 1912 1385 1962">1</td> </tr> </tbody> </table> <p data-bbox="304 1973 767 2004">2. Press the start key. The value is set.</p>	Display	Description	DC1 Bias(C)	Main charger DC bias for cyan (full speed)	DC1 Bias Half(C)	Main charger DC bias for cyan (half speed)	DC1 Bias(M)	Main charger DC bias for magenta (full speed)	DC1 Bias Half(M)	Main charger DC bias for magenta (half speed)	DC1 Bias(Y)	Main charger DC bias for yellow (full speed)	DC1 Bias Half(Y)	Main charger DC bias for yellow (half speed)	DC1 Bias(K)	Main charger DC bias for black (full speed)	DC1 Bias Half(K)	Main charger DC bias for black (half speed)	DC1 Bias B/W(K)*	Main charger DC bias for black in black/white mode	Display	Description	Setting range	Initial setting	DC2 Bias(C)	Main charger DC bias for cyan (full speed)	128 to 127	0	DC2 Bias Half(C)	Main charger DC bias for cyan (half speed)	128 to 127	0	DC2 Bias(M)	Main charger DC bias for magenta (full speed)	128 to 127	0	DC2 Bias Half(M)	Main charger DC bias for magenta (half speed)	128 to 127	0	DC2 Bias(Y)	Main charger DC bias for yellow (full speed)	128 to 127	0	DC2 Bias Half(Y)	Main charger DC bias for yellow (half speed)	128 to 127	0	DC2 Bias(K)	Main charger DC bias for black (full speed)	128 to 127	0	DC2 Bias Half(K)	Main charger DC bias for black (half speed)	128 to 127	0	DC2 Bias B/W(K)*	Main charger DC bias for black in black/white mode			Display	Description	Setting range	Initial setting	Set Low Temp	Pre-charge time at power supply ON	0 to 6	1
Display	Description																																																																				
DC1 Bias(C)	Main charger DC bias for cyan (full speed)																																																																				
DC1 Bias Half(C)	Main charger DC bias for cyan (half speed)																																																																				
DC1 Bias(M)	Main charger DC bias for magenta (full speed)																																																																				
DC1 Bias Half(M)	Main charger DC bias for magenta (half speed)																																																																				
DC1 Bias(Y)	Main charger DC bias for yellow (full speed)																																																																				
DC1 Bias Half(Y)	Main charger DC bias for yellow (half speed)																																																																				
DC1 Bias(K)	Main charger DC bias for black (full speed)																																																																				
DC1 Bias Half(K)	Main charger DC bias for black (half speed)																																																																				
DC1 Bias B/W(K)*	Main charger DC bias for black in black/white mode																																																																				
Display	Description	Setting range	Initial setting																																																																		
DC2 Bias(C)	Main charger DC bias for cyan (full speed)	128 to 127	0																																																																		
DC2 Bias Half(C)	Main charger DC bias for cyan (half speed)	128 to 127	0																																																																		
DC2 Bias(M)	Main charger DC bias for magenta (full speed)	128 to 127	0																																																																		
DC2 Bias Half(M)	Main charger DC bias for magenta (half speed)	128 to 127	0																																																																		
DC2 Bias(Y)	Main charger DC bias for yellow (full speed)	128 to 127	0																																																																		
DC2 Bias Half(Y)	Main charger DC bias for yellow (half speed)	128 to 127	0																																																																		
DC2 Bias(K)	Main charger DC bias for black (full speed)	128 to 127	0																																																																		
DC2 Bias Half(K)	Main charger DC bias for black (half speed)	128 to 127	0																																																																		
DC2 Bias B/W(K)*	Main charger DC bias for black in black/white mode																																																																				
Display	Description	Setting range	Initial setting																																																																		
Set Low Temp	Pre-charge time at power supply ON	0 to 6	1																																																																		

Item No.	Description																																																											
U100	<p>Setting: [Set Charger Freq]</p> <ol style="list-style-type: none"> Select the item to be set. Change the value using the +/- or numeric keys. <table border="1" data-bbox="336 353 1401 781"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="4">Initial setting</th> </tr> <tr> <th>30ppm</th> <th>35ppm</th> <th>45ppm</th> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>Generally</td> <td>Main charger frequency</td> <td>7500 to 11280</td> <td>10442</td> <td>8857</td> <td>8807</td> <td>11022</td> </tr> <tr> <td>B/W*</td> <td>Main charger frequency in black/white mode</td> <td>7500 to 11280</td> <td>-</td> <td>-</td> <td>-</td> <td>10690</td> </tr> <tr> <td>Half</td> <td>Main charger frequency in half speed</td> <td>7500 to 11280</td> <td>10690</td> <td>10690</td> <td>10690</td> <td>10690</td> </tr> <tr> <td>3/4</td> <td>Main charger frequency at 3/4 times of line speed</td> <td>7500 to 11280</td> <td>10690</td> <td>10690</td> <td>8857</td> <td>8857</td> </tr> </tbody> </table> <p>*: 55 ppm model only.</p> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Displaying: [Chk Current]</p> <ol style="list-style-type: none"> The current setting is displayed. <table border="1" data-bbox="336 940 1401 1178"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>C</td> <td>Cyan rush current</td> </tr> <tr> <td>M</td> <td>Magenta rush current</td> </tr> <tr> <td>Y</td> <td>Yellow rush current</td> </tr> <tr> <td>K</td> <td>Black rush current</td> </tr> </tbody> </table> <p>Setting: [Set AC Gain]</p> <ol style="list-style-type: none"> Select the item to be set. <table border="1" data-bbox="296 1270 1418 1538"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Auto</td> <td>Automatically adjusted in accordance with the environment (Default)</td> </tr> <tr> <td>Mode1</td> <td>Use this setting when C2203 occurs (Multiplier = 0.95)</td> </tr> <tr> <td>Mode2</td> <td>Use this setting when charging pitch streaks (horizontal) occur (Multiplier = 1.05)</td> </tr> <tr> <td>Mode3</td> <td>Use this setting if C2203 occurred and the charging pitch streaks (horizontal) has been observed despite mode1 has been selected.</td> </tr> </tbody> </table> <p>Initial setting: Auto</p> <ol style="list-style-type: none"> Press the start key. The setting is set. <p>Completion</p> <p>Press the stop key. The screen for maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Generally	Main charger frequency	7500 to 11280	10442	8857	8807	11022	B/W*	Main charger frequency in black/white mode	7500 to 11280	-	-	-	10690	Half	Main charger frequency in half speed	7500 to 11280	10690	10690	10690	10690	3/4	Main charger frequency at 3/4 times of line speed	7500 to 11280	10690	10690	8857	8857	Display	Description	C	Cyan rush current	M	Magenta rush current	Y	Yellow rush current	K	Black rush current	Display	Description	Auto	Automatically adjusted in accordance with the environment (Default)	Mode1	Use this setting when C2203 occurs (Multiplier = 0.95)	Mode2	Use this setting when charging pitch streaks (horizontal) occur (Multiplier = 1.05)	Mode3	Use this setting if C2203 occurred and the charging pitch streaks (horizontal) has been observed despite mode1 has been selected.
Display	Description				Setting range	Initial setting																																																						
		30ppm	35ppm	45ppm		55ppm																																																						
Generally	Main charger frequency	7500 to 11280	10442	8857	8807	11022																																																						
B/W*	Main charger frequency in black/white mode	7500 to 11280	-	-	-	10690																																																						
Half	Main charger frequency in half speed	7500 to 11280	10690	10690	10690	10690																																																						
3/4	Main charger frequency at 3/4 times of line speed	7500 to 11280	10690	10690	8857	8857																																																						
Display	Description																																																											
C	Cyan rush current																																																											
M	Magenta rush current																																																											
Y	Yellow rush current																																																											
K	Black rush current																																																											
Display	Description																																																											
Auto	Automatically adjusted in accordance with the environment (Default)																																																											
Mode1	Use this setting when C2203 occurs (Multiplier = 0.95)																																																											
Mode2	Use this setting when charging pitch streaks (horizontal) occur (Multiplier = 1.05)																																																											
Mode3	Use this setting if C2203 occurred and the charging pitch streaks (horizontal) has been observed despite mode1 has been selected.																																																											
U101	<p>Setting the voltage for the primary transfer</p> <p>Description</p> <p>Sets the control voltage for the primary transfer.</p> <p>Purpose</p> <p>To change the setting when any density problems, such as too dark or light, occur.</p> <p>Setting</p> <ol style="list-style-type: none"> Press the start key. Select the item to be set. 																																																											

Item No.	Description																																								
U101	<table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Normal</td> <td>Setting the primary transfer positive voltage</td> </tr> <tr> <td>Add Color</td> <td>Setting the addition value (The addition value at the surface is referenced as standard)</td> </tr> <tr> <td>Add Color 2nd</td> <td>Setting the addition value for the second side</td> </tr> <tr> <td>Surround Correct</td> <td>Environmental correction ON/OFF setting</td> </tr> </tbody> </table>	Display	Description	Normal	Setting the primary transfer positive voltage	Add Color	Setting the addition value (The addition value at the surface is referenced as standard)	Add Color 2nd	Setting the addition value for the second side	Surround Correct	Environmental correction ON/OFF setting																														
	Display	Description																																							
	Normal	Setting the primary transfer positive voltage																																							
	Add Color	Setting the addition value (The addition value at the surface is referenced as standard)																																							
	Add Color 2nd	Setting the addition value for the second side																																							
	Surround Correct	Environmental correction ON/OFF setting																																							
	Setting: [Normal] 1. Select the item to be set. 1. Change the value using the +/- or numeric keys.																																								
	<table border="1"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="4">Initial setting</th> </tr> <tr> <th>30ppm</th> <th>35ppm</th> <th>45ppm</th> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>Full</td> <td>Primary transfer positive voltage for yellow (full speed)</td> <td>0 to 255</td> <td>114</td> <td>118</td> <td>126</td> <td>131</td> </tr> <tr> <td>Half</td> <td>Primary transfer positive voltage for yellow (half speed)</td> <td>0 to 255</td> <td>101</td> <td>103</td> <td>108</td> <td>110</td> </tr> <tr> <td>3/4</td> <td>Primary transfer positive voltage for yellow at 3/4 times of line speed</td> <td>0 to 255</td> <td>110</td> <td>110</td> <td>118</td> <td>118</td> </tr> <tr> <td>B/W*</td> <td>Primary transfer positive voltage for yellow in black/white mode</td> <td>0 to 255</td> <td>-</td> <td>-</td> <td>-</td> <td>135</td> </tr> </tbody> </table>		Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Full	Primary transfer positive voltage for yellow (full speed)	0 to 255	114	118	126	131	Half	Primary transfer positive voltage for yellow (half speed)	0 to 255	101	103	108	110	3/4	Primary transfer positive voltage for yellow at 3/4 times of line speed	0 to 255	110	110	118	118	B/W*	Primary transfer positive voltage for yellow in black/white mode	0 to 255	-	-	-	135
	Display	Description				Setting range	Initial setting																																		
			30ppm	35ppm	45ppm		55ppm																																		
Full	Primary transfer positive voltage for yellow (full speed)	0 to 255	114	118	126	131																																			
Half	Primary transfer positive voltage for yellow (half speed)	0 to 255	101	103	108	110																																			
3/4	Primary transfer positive voltage for yellow at 3/4 times of line speed	0 to 255	110	110	118	118																																			
B/W*	Primary transfer positive voltage for yellow in black/white mode	0 to 255	-	-	-	135																																			
*: 55 ppm model only.																																									
2. Press the start key. The value is set.																																									
Setting: [Add Color] 1. Select the item to be set.																																									
<table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Normal</td> <td>Setting the addition value (Full speed)</td> </tr> <tr> <td>Heavy 4/5</td> <td>Setting the addition value (Heavy 4/5)</td> </tr> </tbody> </table>		Display	Description	Normal	Setting the addition value (Full speed)	Heavy 4/5	Setting the addition value (Heavy 4/5)																																		
Display	Description																																								
Normal	Setting the addition value (Full speed)																																								
Heavy 4/5	Setting the addition value (Heavy 4/5)																																								
2. Change the value using the +/- or numeric keys.																																									
[Normal]																																									
<table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>C</td> <td>Addition value (cyan)</td> <td>-127 to 127</td> <td>2</td> </tr> <tr> <td>M</td> <td>Addition value (magenta)</td> <td>-127 to 127</td> <td>2</td> </tr> <tr> <td>Y</td> <td>Addition value (black)</td> <td>-127 to 127</td> <td>15</td> </tr> </tbody> </table>		Display	Description	Setting range	Initial setting	C	Addition value (cyan)	-127 to 127	2	M	Addition value (magenta)	-127 to 127	2	Y	Addition value (black)	-127 to 127	15																								
Display	Description	Setting range	Initial setting																																						
C	Addition value (cyan)	-127 to 127	2																																						
M	Addition value (magenta)	-127 to 127	2																																						
Y	Addition value (black)	-127 to 127	15																																						
[Heavy 4/5]																																									
<table border="1"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="4">Initial setting</th> </tr> <tr> <th>30ppm</th> <th>35ppm</th> <th>45ppm</th> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>C</td> <td>Addition value for the second side (cyan)</td> <td>-127 to 127</td> <td>-2</td> <td>-2</td> <td>-3</td> <td>-4</td> </tr> <tr> <td>M</td> <td>Addition value for the second side (magenta)</td> <td>-127 to 127</td> <td>-4</td> <td>-4</td> <td>-5</td> <td>-6</td> </tr> </tbody> </table>		Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	C	Addition value for the second side (cyan)	-127 to 127	-2	-2	-3	-4	M	Addition value for the second side (magenta)	-127 to 127	-4	-4	-5	-6															
Display	Description				Setting range	Initial setting																																			
		30ppm	35ppm	45ppm		55ppm																																			
C	Addition value for the second side (cyan)	-127 to 127	-2	-2	-3	-4																																			
M	Addition value for the second side (magenta)	-127 to 127	-4	-4	-5	-6																																			

Item No.	Description						
U101							
	Display	Description	Setting range	Initial setting			
				30ppm	35ppm	45ppm	55ppm
	Y	Addition value for the second side (yellow)	-127 to 127	-4	4	-5	-6
	K	Addition value for the second side (black)	-127 to 127	-17	-17	-18	-19
	3. Press the start key. The value is set.						
	Setting: [Add Color 2nd]						
	1. Select the item to be set.						
	Display	Description					
	Normal	Setting the addition value (Full speed)					
Heavy 4/5	Setting the addition value (Heavy 4/5)						
2. Change the value using the +/- or numeric keys.							
[Normal]							
Display	Description	Setting range	Initial setting				
			30 ppm	35 ppm	45 ppm	55 ppm	
C	Addition value for the second side (cyan)	-127 to 127	-4	-4	-5	-6	
M	Addition value for the second side (magenta)	-127 to 127	-4	-4	-5	-6	
Y	Addition value for the second side (yellow)	-127 to 127	-2	-2	-3	-4	
K	Addition value for the second side (black)	-127 to 127	-17	-17	-18	-19	
[Heavy 4/5]							
Display	Description	Setting range	Initial setting				
			30 ppm	35 ppm	45 ppm	55 ppm	
C	Addition value for the second side (cyan)	-127 to 127	-2	-2	-3	-4	
M	Addition value for the second side (magenta)	-127 to 127	-4	-4	-5	-6	
Y	Addition value for the second side (yellow)	-127 to 127	-4	4	-5	-6	
K	Addition value for the second side (black)	-127 to 127	-17	-17	-18	-19	
3. Press the start key. The value is set.							
Setting: [Surround Correct]							
1. Select On or Off.							
Display	Description						
On	Environmental correction is not performed						
Off	Environmental correction is performed						
Initial setting: Off							
2. Press the start key. The setting is set.							

Item No.	Description																														
U101	<p>Supplement While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>																														
U106	<p>Setting the voltage for the secondary transfer</p> <p>Description Sets the control voltage for the secondary transfer depending on each paper type.</p> <p>Purpose To change the setting when any density problems, such as too dark or light, occur.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="295 824 1433 1384"> <thead> <tr> <th data-bbox="295 824 523 875">Display</th> <th data-bbox="523 824 1433 875">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="295 875 523 958">Light/Normal1</td> <td data-bbox="523 875 1433 958">Control voltage for the transfer bias on paper with thickness 52 g/m² to 64 g/m² and 65 g/m² to 75 g/m²</td> </tr> <tr> <td data-bbox="295 958 523 1041">Normal2/3</td> <td data-bbox="523 958 1433 1041">Control voltage for the transfer bias on paper with thickness 76 g/m² to 105 g/m²</td> </tr> <tr> <td data-bbox="295 1041 523 1124">Heavy1</td> <td data-bbox="523 1041 1433 1124">Control voltage for the transfer bias on paper with thickness 106 g/m² to 135 g/m²</td> </tr> <tr> <td data-bbox="295 1124 523 1207">Heavy2/3</td> <td data-bbox="523 1124 1433 1207">Control voltage for the transfer bias on paper with thickness 136 g/m² to 220 g/m²</td> </tr> <tr> <td data-bbox="295 1207 523 1290">Heavy4/5</td> <td data-bbox="523 1207 1433 1290">Control voltage for the transfer bias on paper with thickness 221 g/m² to 300 g/m²</td> </tr> <tr> <td data-bbox="295 1290 523 1335">OHP</td> <td data-bbox="523 1290 1433 1335">Control voltage for the transfer bias for transparencies</td> </tr> <tr> <td data-bbox="295 1335 523 1384">Bias</td> <td data-bbox="523 1335 1433 1384">Transfer bias value</td> </tr> </tbody> </table> <p>Setting: [Light/Normal1]</p> <ol style="list-style-type: none"> 1. Select the item to be set. <table border="1" data-bbox="295 1480 1433 1883"> <thead> <tr> <th data-bbox="295 1480 523 1532">Display</th> <th data-bbox="523 1480 1433 1532">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="295 1532 523 1576">1st</td> <td data-bbox="523 1532 1433 1576">Control voltage for the transfer bias for the first side (full speed)</td> </tr> <tr> <td data-bbox="295 1576 523 1621">2nd</td> <td data-bbox="523 1576 1433 1621">Control voltage for the transfer bias for the second side (full speed)</td> </tr> <tr> <td data-bbox="295 1621 523 1704">1st 3/4(Gloss)</td> <td data-bbox="523 1621 1433 1704">Control voltage for the transfer bias for the first side at 3/4 times of line speed</td> </tr> <tr> <td data-bbox="295 1704 523 1787">2nd 3/4(Gloss)</td> <td data-bbox="523 1704 1433 1787">Control voltage for the transfer bias for the second side at 3/4 times of line speed</td> </tr> <tr> <td data-bbox="295 1787 523 1832">1st B/W*</td> <td data-bbox="523 1787 1433 1832">Control voltage for the transfer bias for the first side in black/white mode</td> </tr> <tr> <td data-bbox="295 1832 523 1883">2nd B/W*</td> <td data-bbox="523 1832 1433 1883">Control voltage for the transfer bias for the second side in black/white mode</td> </tr> </tbody> </table> <p>*: 55 ppm model only.</p> <ol style="list-style-type: none"> 2. Select the paper width to be set. 3. Change the value using the +/- or numeric keys. 	Display	Description	Light/Normal1	Control voltage for the transfer bias on paper with thickness 52 g/m ² to 64 g/m ² and 65 g/m ² to 75 g/m ²	Normal2/3	Control voltage for the transfer bias on paper with thickness 76 g/m ² to 105 g/m ²	Heavy1	Control voltage for the transfer bias on paper with thickness 106 g/m ² to 135 g/m ²	Heavy2/3	Control voltage for the transfer bias on paper with thickness 136 g/m ² to 220 g/m ²	Heavy4/5	Control voltage for the transfer bias on paper with thickness 221 g/m ² to 300 g/m ²	OHP	Control voltage for the transfer bias for transparencies	Bias	Transfer bias value	Display	Description	1st	Control voltage for the transfer bias for the first side (full speed)	2nd	Control voltage for the transfer bias for the second side (full speed)	1st 3/4(Gloss)	Control voltage for the transfer bias for the first side at 3/4 times of line speed	2nd 3/4(Gloss)	Control voltage for the transfer bias for the second side at 3/4 times of line speed	1st B/W*	Control voltage for the transfer bias for the first side in black/white mode	2nd B/W*	Control voltage for the transfer bias for the second side in black/white mode
Display	Description																														
Light/Normal1	Control voltage for the transfer bias on paper with thickness 52 g/m ² to 64 g/m ² and 65 g/m ² to 75 g/m ²																														
Normal2/3	Control voltage for the transfer bias on paper with thickness 76 g/m ² to 105 g/m ²																														
Heavy1	Control voltage for the transfer bias on paper with thickness 106 g/m ² to 135 g/m ²																														
Heavy2/3	Control voltage for the transfer bias on paper with thickness 136 g/m ² to 220 g/m ²																														
Heavy4/5	Control voltage for the transfer bias on paper with thickness 221 g/m ² to 300 g/m ²																														
OHP	Control voltage for the transfer bias for transparencies																														
Bias	Transfer bias value																														
Display	Description																														
1st	Control voltage for the transfer bias for the first side (full speed)																														
2nd	Control voltage for the transfer bias for the second side (full speed)																														
1st 3/4(Gloss)	Control voltage for the transfer bias for the first side at 3/4 times of line speed																														
2nd 3/4(Gloss)	Control voltage for the transfer bias for the second side at 3/4 times of line speed																														
1st B/W*	Control voltage for the transfer bias for the first side in black/white mode																														
2nd B/W*	Control voltage for the transfer bias for the second side in black/white mode																														

Item No.	Description						
U106	[1st]						
	Display	Description	Setting range	Initial setting			
				30ppm	35ppm	45ppm	55ppm
	Width=105	105 mm wide	0 to 255	125	131	143	150
	Width=210	210 mm wide	0 to 255	118	123	134	139
	Width=297	297 mm wide	0 to 255	110	115	120	128
	[2nd]						
	Display	Description	Setting range	Initial setting			
				30ppm	35ppm	45ppm	55ppm
	Width=105	105 mm wide	0 to 255	167	180	207	220
	Width=210	210 mm wide	0 to 255	133	140	155	163
	Width=297	297 mm wide	0 to 255	112	116	124	128
	[1st 3/4(Gloss)]						
	Display	Description	Setting range	Initial setting			
30ppm				35ppm	45ppm	55ppm	
Width=105	105 mm wide	0 to 255	120	120	131	131	
Width=210	210 mm wide	0 to 255	114	114	123	123	
Width=297	297 mm wide	0 to 255	111	111	120	120	
[2nd 3/4(Gloss)]							
Display	Description	Setting range	Initial setting				
			30ppm	35ppm	45ppm	55ppm	
Width=105	105 mm wide	0 to 255	155	155	180	180	
Width=210	210 mm wide	0 to 255	126	126	140	140	
Width=297	297 mm wide	0 to 255	111	111	120	120	
[1st B/W]							
Display	Description	Setting range	Initial setting				
			55ppm				
Width=105	105 mm wide	0 to 255	150				
Width=210	210 mm wide	0 to 255	144				
Width=297	297 mm wide	0 to 255	128				
[2nd B/W]							
Display	Description	Setting range	Initial setting				
			55ppm				
Width=105	105 mm wide	0 to 255	183				
Width=210	210 mm wide	0 to 255	171				
Width=297	297 mm wide	0 to 255	128				
4. Press the start key. The value is set.							

Item No.	Description																																																																																																														
U106	<p data-bbox="288 241 544 271">Setting: [Normal2/3]</p> <p data-bbox="288 277 632 306">1. Select the item to be set.</p> <table border="1" data-bbox="336 320 1401 792"> <thead> <tr> <th data-bbox="336 320 564 365">Display</th> <th data-bbox="564 320 1401 365">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 365 564 409">1st</td> <td data-bbox="564 365 1401 409">Control voltage for the transfer bias for the first side (full speed)</td> </tr> <tr> <td data-bbox="336 409 564 454">2nd</td> <td data-bbox="564 409 1401 454">Control voltage for the transfer bias for the second side (full speed)</td> </tr> <tr> <td data-bbox="336 454 564 544">1st 3/4(Gloss)</td> <td data-bbox="564 454 1401 544">Control voltage for the transfer bias for the first side at 3/4 times of line speed</td> </tr> <tr> <td data-bbox="336 544 564 633">2nd 3/4(Gloss)</td> <td data-bbox="564 544 1401 633">Control voltage for the transfer bias for the second side at 3/4 times of line speed</td> </tr> <tr> <td data-bbox="336 633 564 723">1st B/W*</td> <td data-bbox="564 633 1401 723">Control voltage for the transfer bias for the first side in black/white mode</td> </tr> <tr> <td data-bbox="336 723 564 792">2nd B/W*</td> <td data-bbox="564 723 1401 792">Control voltage for the transfer bias for the second side in black/white mode</td> </tr> </tbody> </table> <p data-bbox="336 804 592 833">*: 55 ppm model only.</p> <p data-bbox="288 840 719 869">2. Select the paper width to be set.</p> <p data-bbox="288 875 906 904">3. Change the value using the +/- or numeric keys.</p> <p data-bbox="336 911 389 940">[1st]</p> <table border="1" data-bbox="336 952 1401 1189"> <thead> <tr> <th data-bbox="336 952 520 1041" rowspan="2">Display</th> <th data-bbox="520 952 823 1041" rowspan="2">Description</th> <th data-bbox="823 952 975 1041" rowspan="2">Setting range</th> <th colspan="4" data-bbox="975 952 1401 996">Initial setting</th> </tr> <tr> <th data-bbox="975 996 1078 1041">30ppm</th> <th data-bbox="1078 996 1182 1041">35ppm</th> <th data-bbox="1182 996 1286 1041">45ppm</th> <th data-bbox="1286 996 1401 1041">55ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1041 520 1086">Width=105</td> <td data-bbox="520 1041 823 1086">105 mm wide</td> <td data-bbox="823 1041 975 1086">0 to 255</td> <td data-bbox="975 1041 1078 1086">125</td> <td data-bbox="1078 1041 1182 1086">131</td> <td data-bbox="1182 1041 1286 1086">143</td> <td data-bbox="1286 1041 1401 1086">150</td> </tr> <tr> <td data-bbox="336 1086 520 1131">Width=210</td> <td data-bbox="520 1086 823 1131">210 mm wide</td> <td data-bbox="823 1086 975 1131">0 to 255</td> <td data-bbox="975 1086 1078 1131">118</td> <td data-bbox="1078 1086 1182 1131">123</td> <td data-bbox="1182 1086 1286 1131">134</td> <td data-bbox="1286 1086 1401 1131">139</td> </tr> <tr> <td data-bbox="336 1131 520 1189">Width=297</td> <td data-bbox="520 1131 823 1189">297 mm wide</td> <td data-bbox="823 1131 975 1189">0 to 255</td> <td data-bbox="975 1131 1078 1189">110</td> <td data-bbox="1078 1131 1182 1189">115</td> <td data-bbox="1182 1131 1286 1189">120</td> <td data-bbox="1286 1131 1401 1189">128</td> </tr> </tbody> </table> <p data-bbox="336 1205 397 1234">[2nd]</p> <table border="1" data-bbox="336 1245 1401 1482"> <thead> <tr> <th data-bbox="336 1245 520 1335" rowspan="2">Display</th> <th data-bbox="520 1245 823 1335" rowspan="2">Description</th> <th data-bbox="823 1245 975 1335" rowspan="2">Setting range</th> <th colspan="4" data-bbox="975 1245 1401 1290">Initial setting</th> </tr> <tr> <th data-bbox="975 1290 1078 1335">30ppm</th> <th data-bbox="1078 1290 1182 1335">35ppm</th> <th data-bbox="1182 1290 1286 1335">45ppm</th> <th data-bbox="1286 1290 1401 1335">55ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1335 520 1379">Width=105</td> <td data-bbox="520 1335 823 1379">105 mm wide</td> <td data-bbox="823 1335 975 1379">0 to 255</td> <td data-bbox="975 1335 1078 1379">167</td> <td data-bbox="1078 1335 1182 1379">180</td> <td data-bbox="1182 1335 1286 1379">207</td> <td data-bbox="1286 1335 1401 1379">220</td> </tr> <tr> <td data-bbox="336 1379 520 1424">Width=210</td> <td data-bbox="520 1379 823 1424">210 mm wide</td> <td data-bbox="823 1379 975 1424">0 to 255</td> <td data-bbox="975 1379 1078 1424">133</td> <td data-bbox="1078 1379 1182 1424">140</td> <td data-bbox="1182 1379 1286 1424">155</td> <td data-bbox="1286 1379 1401 1424">163</td> </tr> <tr> <td data-bbox="336 1424 520 1482">Width=297</td> <td data-bbox="520 1424 823 1482">297 mm wide</td> <td data-bbox="823 1424 975 1482">0 to 255</td> <td data-bbox="975 1424 1078 1482">112</td> <td data-bbox="1078 1424 1182 1482">116</td> <td data-bbox="1182 1424 1286 1482">124</td> <td data-bbox="1286 1424 1401 1482">128</td> </tr> </tbody> </table> <p data-bbox="336 1500 520 1529">[1st 3/4(Gloss)]</p> <table border="1" data-bbox="336 1541 1401 1778"> <thead> <tr> <th data-bbox="336 1541 520 1630" rowspan="2">Display</th> <th data-bbox="520 1541 823 1630" rowspan="2">Description</th> <th data-bbox="823 1541 975 1630" rowspan="2">Setting range</th> <th colspan="4" data-bbox="975 1541 1401 1585">Initial setting</th> </tr> <tr> <th data-bbox="975 1585 1078 1630">30ppm</th> <th data-bbox="1078 1585 1182 1630">35ppm</th> <th data-bbox="1182 1585 1286 1630">45ppm</th> <th data-bbox="1286 1585 1401 1630">55ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1630 520 1675">Width=105</td> <td data-bbox="520 1630 823 1675">105 mm wide</td> <td data-bbox="823 1630 975 1675">0 to 255</td> <td data-bbox="975 1630 1078 1675">120</td> <td data-bbox="1078 1630 1182 1675">120</td> <td data-bbox="1182 1630 1286 1675">131</td> <td data-bbox="1286 1630 1401 1675">131</td> </tr> <tr> <td data-bbox="336 1675 520 1720">Width=210</td> <td data-bbox="520 1675 823 1720">210 mm wide</td> <td data-bbox="823 1675 975 1720">0 to 255</td> <td data-bbox="975 1675 1078 1720">114</td> <td data-bbox="1078 1675 1182 1720">114</td> <td data-bbox="1182 1675 1286 1720">123</td> <td data-bbox="1286 1675 1401 1720">123</td> </tr> <tr> <td data-bbox="336 1720 520 1778">Width=297</td> <td data-bbox="520 1720 823 1778">297 mm wide</td> <td data-bbox="823 1720 975 1778">0 to 255</td> <td data-bbox="975 1720 1078 1778">111</td> <td data-bbox="1078 1720 1182 1778">111</td> <td data-bbox="1182 1720 1286 1778">120</td> <td data-bbox="1286 1720 1401 1778">120</td> </tr> </tbody> </table>	Display	Description	1st	Control voltage for the transfer bias for the first side (full speed)	2nd	Control voltage for the transfer bias for the second side (full speed)	1st 3/4(Gloss)	Control voltage for the transfer bias for the first side at 3/4 times of line speed	2nd 3/4(Gloss)	Control voltage for the transfer bias for the second side at 3/4 times of line speed	1st B/W*	Control voltage for the transfer bias for the first side in black/white mode	2nd B/W*	Control voltage for the transfer bias for the second side in black/white mode	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Width=105	105 mm wide	0 to 255	125	131	143	150	Width=210	210 mm wide	0 to 255	118	123	134	139	Width=297	297 mm wide	0 to 255	110	115	120	128	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Width=105	105 mm wide	0 to 255	167	180	207	220	Width=210	210 mm wide	0 to 255	133	140	155	163	Width=297	297 mm wide	0 to 255	112	116	124	128	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Width=105	105 mm wide	0 to 255	120	120	131	131	Width=210	210 mm wide	0 to 255	114	114	123	123	Width=297	297 mm wide	0 to 255	111	111	120	120
Display	Description																																																																																																														
1st	Control voltage for the transfer bias for the first side (full speed)																																																																																																														
2nd	Control voltage for the transfer bias for the second side (full speed)																																																																																																														
1st 3/4(Gloss)	Control voltage for the transfer bias for the first side at 3/4 times of line speed																																																																																																														
2nd 3/4(Gloss)	Control voltage for the transfer bias for the second side at 3/4 times of line speed																																																																																																														
1st B/W*	Control voltage for the transfer bias for the first side in black/white mode																																																																																																														
2nd B/W*	Control voltage for the transfer bias for the second side in black/white mode																																																																																																														
Display	Description	Setting range	Initial setting																																																																																																												
			30ppm	35ppm	45ppm	55ppm																																																																																																									
Width=105	105 mm wide	0 to 255	125	131	143	150																																																																																																									
Width=210	210 mm wide	0 to 255	118	123	134	139																																																																																																									
Width=297	297 mm wide	0 to 255	110	115	120	128																																																																																																									
Display	Description	Setting range	Initial setting																																																																																																												
			30ppm	35ppm	45ppm	55ppm																																																																																																									
Width=105	105 mm wide	0 to 255	167	180	207	220																																																																																																									
Width=210	210 mm wide	0 to 255	133	140	155	163																																																																																																									
Width=297	297 mm wide	0 to 255	112	116	124	128																																																																																																									
Display	Description	Setting range	Initial setting																																																																																																												
			30ppm	35ppm	45ppm	55ppm																																																																																																									
Width=105	105 mm wide	0 to 255	120	120	131	131																																																																																																									
Width=210	210 mm wide	0 to 255	114	114	123	123																																																																																																									
Width=297	297 mm wide	0 to 255	111	111	120	120																																																																																																									

Item No.	Description																																
U106	[2nd 3/4(Gloss)]																																
	<table border="1"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="4">Initial setting</th> </tr> <tr> <th>30ppm</th> <th>35ppm</th> <th>45ppm</th> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>Width=105</td> <td>105 mm wide</td> <td>0 to 255</td> <td>155</td> <td>155</td> <td>180</td> <td>180</td> </tr> <tr> <td>Width=210</td> <td>210 mm wide</td> <td>0 to 255</td> <td>126</td> <td>126</td> <td>140</td> <td>140</td> </tr> <tr> <td>Width=297</td> <td>297 mm wide</td> <td>0 to 255</td> <td>111</td> <td>111</td> <td>120</td> <td>120</td> </tr> </tbody> </table>	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Width=105	105 mm wide	0 to 255	155	155	180	180	Width=210	210 mm wide	0 to 255	126	126	140	140	Width=297	297 mm wide	0 to 255	111	111	120	120
	Display				Description	Setting range	Initial setting																										
		30ppm	35ppm	45ppm			55ppm																										
	Width=105	105 mm wide	0 to 255	155	155	180	180																										
	Width=210	210 mm wide	0 to 255	126	126	140	140																										
	Width=297	297 mm wide	0 to 255	111	111	120	120																										
	[1st B/W]																																
	<table border="1"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th>Initial setting</th> </tr> <tr> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>Width=105</td> <td>105 mm wide</td> <td>0 to 255</td> <td>150</td> </tr> <tr> <td>Width=210</td> <td>210 mm wide</td> <td>0 to 255</td> <td>144</td> </tr> <tr> <td>Width=297</td> <td>297 mm wide</td> <td>0 to 255</td> <td>128</td> </tr> </tbody> </table>	Display	Description	Setting range	Initial setting	55ppm	Width=105	105 mm wide	0 to 255	150	Width=210	210 mm wide	0 to 255	144	Width=297	297 mm wide	0 to 255	128															
	Display				Description	Setting range	Initial setting																										
		55ppm																															
	Width=105	105 mm wide	0 to 255	150																													
Width=210	210 mm wide	0 to 255	144																														
Width=297	297 mm wide	0 to 255	128																														
[2nd B/W]																																	
<table border="1"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th>Initial setting</th> </tr> <tr> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>Width=105</td> <td>105 mm wide</td> <td>0 to 255</td> <td>183</td> </tr> <tr> <td>Width=210</td> <td>210 mm wide</td> <td>0 to 255</td> <td>171</td> </tr> <tr> <td>Width=297</td> <td>297 mm wide</td> <td>0 to 255</td> <td>128</td> </tr> </tbody> </table>	Display	Description	Setting range	Initial setting	55ppm	Width=105	105 mm wide	0 to 255	183	Width=210	210 mm wide	0 to 255	171	Width=297	297 mm wide	0 to 255	128																
Display				Description	Setting range	Initial setting																											
	55ppm																																
Width=105	105 mm wide	0 to 255	183																														
Width=210	210 mm wide	0 to 255	171																														
Width=297	297 mm wide	0 to 255	128																														
4. Press the start key. The value is set.																																	
Setting: [Heavy1]																																	
1. Select the item to be set.																																	
<table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1st 3/4</td> <td>Control voltage for the transfer bias for the first side at 3/4 times of line speed</td> </tr> <tr> <td>2nd 3/4</td> <td>Control voltage for the transfer bias for the second side at 3/4 times of line speed</td> </tr> </tbody> </table>	Display	Description	1st 3/4	Control voltage for the transfer bias for the first side at 3/4 times of line speed	2nd 3/4	Control voltage for the transfer bias for the second side at 3/4 times of line speed																											
Display	Description																																
1st 3/4	Control voltage for the transfer bias for the first side at 3/4 times of line speed																																
2nd 3/4	Control voltage for the transfer bias for the second side at 3/4 times of line speed																																
2. Select the paper width to be set.																																	
3. Change the value using the +/- or numeric keys.																																	
[1st 3/4]																																	
<table border="1"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="4">Initial setting</th> </tr> <tr> <th>30ppm</th> <th>35ppm</th> <th>45ppm</th> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>Width=105</td> <td>105 mm wide</td> <td>0 to 255</td> <td>121</td> <td>121</td> <td>133</td> <td>133</td> </tr> <tr> <td>Width=210</td> <td>210 mm wide</td> <td>0 to 255</td> <td>118</td> <td>118</td> <td>129</td> <td>129</td> </tr> <tr> <td>Width=297</td> <td>297 mm wide</td> <td>0 to 255</td> <td>115</td> <td>115</td> <td>124</td> <td>124</td> </tr> </tbody> </table>	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Width=105	105 mm wide	0 to 255	121	121	133	133	Width=210	210 mm wide	0 to 255	118	118	129	129	Width=297	297 mm wide	0 to 255	115	115	124	124	
Display				Description	Setting range	Initial setting																											
	30ppm	35ppm	45ppm			55ppm																											
Width=105	105 mm wide	0 to 255	121	121	133	133																											
Width=210	210 mm wide	0 to 255	118	118	129	129																											
Width=297	297 mm wide	0 to 255	115	115	124	124																											

Item No.	Description																																
U106	[2nd 3/4]																																
	<table border="1"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="4">Initial setting</th> </tr> <tr> <th>30ppm</th> <th>35ppm</th> <th>45ppm</th> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>Width=105</td> <td>105 mm wide</td> <td>0 to 255</td> <td>137</td> <td>137</td> <td>155</td> <td>155</td> </tr> <tr> <td>Width=210</td> <td>210 mm wide</td> <td>0 to 255</td> <td>133</td> <td>133</td> <td>150</td> <td>150</td> </tr> <tr> <td>Width=297</td> <td>297 mm wide</td> <td>0 to 255</td> <td>115</td> <td>115</td> <td>124</td> <td>124</td> </tr> </tbody> </table>	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Width=105	105 mm wide	0 to 255	137	137	155	155	Width=210	210 mm wide	0 to 255	133	133	150	150	Width=297	297 mm wide	0 to 255	115	115	124	124
	Display				Description	Setting range	Initial setting																										
		30ppm	35ppm	45ppm			55ppm																										
	Width=105	105 mm wide	0 to 255	137	137	155	155																										
	Width=210	210 mm wide	0 to 255	133	133	150	150																										
	Width=297	297 mm wide	0 to 255	115	115	124	124																										
	4. Press the start key. The value is set.																																
	Setting: [Heavy2/3]																																
	1. Select the item to be set.																																
<table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1st Half</td> <td>Control voltage for the transfer bias for the first side (half speed)</td> </tr> <tr> <td>2nd Half</td> <td>Control voltage for the transfer bias for the second side (half speed)</td> </tr> </tbody> </table>	Display	Description	1st Half	Control voltage for the transfer bias for the first side (half speed)	2nd Half	Control voltage for the transfer bias for the second side (half speed)																											
Display	Description																																
1st Half	Control voltage for the transfer bias for the first side (half speed)																																
2nd Half	Control voltage for the transfer bias for the second side (half speed)																																
2. Select the paper width to be set.																																	
3. Change the value using the +/- or numeric keys.																																	
[1st Half]																																	
<table border="1"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="4">Initial setting</th> </tr> <tr> <th>30ppm</th> <th>35ppm</th> <th>45ppm</th> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>Width=105</td> <td>105 mm wide</td> <td>0 to 255</td> <td>114</td> <td>118</td> <td>126</td> <td>130</td> </tr> <tr> <td>Width=210</td> <td>210 mm wide</td> <td>0 to 255</td> <td>111</td> <td>115</td> <td>123</td> <td>127</td> </tr> <tr> <td>Width=297</td> <td>297 mm wide</td> <td>0 to 255</td> <td>109</td> <td>112</td> <td>119</td> <td>122</td> </tr> </tbody> </table>	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Width=105	105 mm wide	0 to 255	114	118	126	130	Width=210	210 mm wide	0 to 255	111	115	123	127	Width=297	297 mm wide	0 to 255	109	112	119	122	
Display				Description	Setting range	Initial setting																											
	30ppm	35ppm	45ppm			55ppm																											
Width=105	105 mm wide	0 to 255	114	118	126	130																											
Width=210	210 mm wide	0 to 255	111	115	123	127																											
Width=297	297 mm wide	0 to 255	109	112	119	122																											
[2nd Half]																																	
<table border="1"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="4">Initial setting</th> </tr> <tr> <th>30ppm</th> <th>35ppm</th> <th>45ppm</th> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>Width=105</td> <td>105 mm wide</td> <td>0 to 255</td> <td>126</td> <td>132</td> <td>144</td> <td>151</td> </tr> <tr> <td>Width=210</td> <td>210 mm wide</td> <td>0 to 255</td> <td>123</td> <td>128</td> <td>140</td> <td>146</td> </tr> <tr> <td>Width=297</td> <td>297 mm wide</td> <td>0 to 255</td> <td>109</td> <td>112</td> <td>119</td> <td>122</td> </tr> </tbody> </table>	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Width=105	105 mm wide	0 to 255	126	132	144	151	Width=210	210 mm wide	0 to 255	123	128	140	146	Width=297	297 mm wide	0 to 255	109	112	119	122	
Display				Description	Setting range	Initial setting																											
	30ppm	35ppm	45ppm			55ppm																											
Width=105	105 mm wide	0 to 255	126	132	144	151																											
Width=210	210 mm wide	0 to 255	123	128	140	146																											
Width=297	297 mm wide	0 to 255	109	112	119	122																											
4. Press the start key. The value is set.																																	
Setting: [Heavy4/5]																																	
1. Select the item to be set.																																	
<table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1st Half</td> <td>Control voltage for the transfer bias for the first side (half speed)</td> </tr> <tr> <td>2nd Half</td> <td>Control voltage for the transfer bias for the second side (half speed)</td> </tr> </tbody> </table>	Display	Description	1st Half	Control voltage for the transfer bias for the first side (half speed)	2nd Half	Control voltage for the transfer bias for the second side (half speed)																											
Display	Description																																
1st Half	Control voltage for the transfer bias for the first side (half speed)																																
2nd Half	Control voltage for the transfer bias for the second side (half speed)																																
2. Select the paper width to be set.																																	
3. Change the value using the +/- or numeric keys.																																	

Item No.	Description						
U106	[1st Half]						
	Display	Description	Setting range	Initial setting			
				30ppm	35ppm	45ppm	55ppm
	Width=105	105 mm wide	0 to 255	114	118	126	130
	Width=210	210 mm wide	0 to 255	111	115	123	127
	Width=297	297 mm wide	0 to 255	104	107	113	116
	[2nd Half]						
	Display	Description	Setting range	Initial setting			
				30ppm	35ppm	45ppm	55ppm
	Width=105	105 mm wide	0 to 255	126	132	144	151
	Width=210	210 mm wide	0 to 255	123	128	140	146
	Width=297	297 mm wide	0 to 255	104	107	113	116
	4. Press the start key. The value is set.						
	Setting: [OHP]						
1. Select the item to be set.							
2. Change the value using the +/- or numeric keys.							
Display	Description	Setting range	Initial setting				
			30ppm	35ppm	45ppm	55ppm	
Width=105	105 mm wide	0 to 255	118	123	134	139	
Width=210	210 mm wide	0 to 255	115	120	129	133	
Width=297	297 mm wide	0 to 255	112	116	124	128	
3. Press the start key. The value is set.							
Setting: [Bias]							
1. Select the item to be set.							
2. Change the value using the +/- or numeric keys.							
Display	Description	Setting range	Initial setting				
			30ppm	35ppm	45ppm	55ppm	
Reverse	Transfer reverse bias (full speed)	0 to 255	163	1	1	1	
Reverse Half	Transfer reverse bias (half speed)	0 to 255	163	1	1	1	
Reverse 3/4	Transfer reverse bias at 3/4 times of line speed	0 to 255	1	1	1	1	
Reverse B/W*	Transfer reverse bias in black/white mode	0 to 255	-	-	-	1	
Cleaning	Cleaning control value (full speed)	0 to 255	122	127	138	143	
*: 55 ppm model only.							
3. Press the start key. The value is set.							

Item No.	Description						
U106							
	Display	Description	Setting range	Initial setting			
				30ppm	35ppm	45ppm	55ppm
	Cleaning Half	Cleaning control value (half speed)	0 to 255	114	118	126	130
Cleaning 3/4	Cleaning control value at 3/4 times of line speed	0 to 255	121	121	133	133	
<p>*: 55 ppm model only. 4. Press the start key. The value is set.</p>							
<p>Supplement While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p>							
<p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>							

Item No.	Description																																																																																				
U107	<p data-bbox="288 241 754 275">Setting the transfer cleaning voltage</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 924 374">Sets the cleaning control voltage for transfer belt unit.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1323 443">Change settings if an offset has occurred due to the failure of cleaning the transfer belt.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="304 517 632 582" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 595 1401 741"> <thead> <tr> <th data-bbox="336 595 564 640">Display</th> <th data-bbox="564 595 1401 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 564 685">Belt(A)</td> <td data-bbox="564 640 1401 685">Transfer belt cleaning voltage (printing)</td> </tr> <tr> <td data-bbox="336 685 564 741">Belt(B)</td> <td data-bbox="564 685 1401 741">Transfer belt cleaning voltage (paper interval)</td> </tr> </tbody> </table> <ol data-bbox="304 752 914 817" style="list-style-type: none"> 3. Select the item to be set. 4. Change the value using the +/- or numeric keys. <p data-bbox="336 822 435 851">[Belt(A)]</p> <table border="1" data-bbox="336 864 1401 1151"> <thead> <tr> <th data-bbox="336 864 504 958" rowspan="2">Display</th> <th data-bbox="504 864 852 958" rowspan="2">Description</th> <th data-bbox="852 864 1002 958" rowspan="2">Setting range</th> <th colspan="4" data-bbox="1002 864 1401 909">Initial setting</th> </tr> <tr> <th data-bbox="1002 909 1102 958">30ppm</th> <th data-bbox="1102 909 1203 958">35ppm</th> <th data-bbox="1203 909 1303 958">45ppm</th> <th data-bbox="1303 909 1401 958">55ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 958 504 1003">Full</td> <td data-bbox="504 958 852 1003">Full speed</td> <td data-bbox="852 958 1002 1003">0 to 255</td> <td data-bbox="1002 958 1102 1003">187</td> <td data-bbox="1102 958 1203 1003">192</td> <td data-bbox="1203 958 1303 1003">202</td> <td data-bbox="1303 958 1401 1003">207</td> </tr> <tr> <td data-bbox="336 1003 504 1048">Half</td> <td data-bbox="504 1003 852 1048">Half speed</td> <td data-bbox="852 1003 1002 1048">0 to 255</td> <td data-bbox="1002 1003 1102 1048">172</td> <td data-bbox="1102 1003 1203 1048">175</td> <td data-bbox="1203 1003 1303 1048">180</td> <td data-bbox="1303 1003 1401 1048">182</td> </tr> <tr> <td data-bbox="336 1048 504 1093">3/4</td> <td data-bbox="504 1048 852 1093">3/4 times of line speed</td> <td data-bbox="852 1048 1002 1093">0 to 255</td> <td data-bbox="1002 1048 1102 1093">182</td> <td data-bbox="1102 1048 1203 1093">182</td> <td data-bbox="1203 1048 1303 1093">192</td> <td data-bbox="1303 1048 1401 1093">192</td> </tr> <tr> <td data-bbox="336 1093 504 1151">B/W*</td> <td data-bbox="504 1093 852 1151">Black/white mode</td> <td data-bbox="852 1093 1002 1151">0 to 255</td> <td data-bbox="1002 1093 1102 1151">-</td> <td data-bbox="1102 1093 1203 1151">-</td> <td data-bbox="1203 1093 1303 1151">-</td> <td data-bbox="1303 1093 1401 1151">212</td> </tr> </tbody> </table> <p data-bbox="336 1162 435 1191">[Belt(B)]</p> <table border="1" data-bbox="336 1205 1401 1491"> <thead> <tr> <th data-bbox="336 1205 504 1299" rowspan="2">Display</th> <th data-bbox="504 1205 852 1299" rowspan="2">Description</th> <th data-bbox="852 1205 1002 1299" rowspan="2">Setting range</th> <th colspan="4" data-bbox="1002 1205 1401 1249">Initial setting</th> </tr> <tr> <th data-bbox="1002 1249 1102 1299">30ppm</th> <th data-bbox="1102 1249 1203 1299">35ppm</th> <th data-bbox="1203 1249 1303 1299">45ppm</th> <th data-bbox="1303 1249 1401 1299">55ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1299 504 1344">Full</td> <td data-bbox="504 1299 852 1344">Full speed</td> <td data-bbox="852 1299 1002 1344">0 to 255</td> <td data-bbox="1002 1299 1102 1344">120</td> <td data-bbox="1102 1299 1203 1344">130</td> <td data-bbox="1203 1299 1303 1344">150</td> <td data-bbox="1303 1299 1401 1344">160</td> </tr> <tr> <td data-bbox="336 1344 504 1388">Half</td> <td data-bbox="504 1344 852 1388">Half speed</td> <td data-bbox="852 1344 1002 1388">0 to 255</td> <td data-bbox="1002 1344 1102 1388">100</td> <td data-bbox="1102 1344 1203 1388">100</td> <td data-bbox="1203 1344 1303 1388">110</td> <td data-bbox="1303 1344 1401 1388">110</td> </tr> <tr> <td data-bbox="336 1388 504 1433">3/4</td> <td data-bbox="504 1388 852 1433">3/4 times of line speed</td> <td data-bbox="852 1388 1002 1433">0 to 255</td> <td data-bbox="1002 1388 1102 1433">110</td> <td data-bbox="1102 1388 1203 1433">110</td> <td data-bbox="1203 1388 1303 1433">130</td> <td data-bbox="1303 1388 1401 1433">130</td> </tr> <tr> <td data-bbox="336 1433 504 1491">B/W*</td> <td data-bbox="504 1433 852 1491">Black/white mode</td> <td data-bbox="852 1433 1002 1491">0 to 255</td> <td data-bbox="1002 1433 1102 1491">-</td> <td data-bbox="1102 1433 1203 1491">-</td> <td data-bbox="1203 1433 1303 1491">-</td> <td data-bbox="1303 1433 1401 1491">160</td> </tr> </tbody> </table> <p data-bbox="336 1503 595 1532">*: 75 ppm model only.</p> <ol data-bbox="304 1536 767 1565" style="list-style-type: none"> 5. Press the start key. The value is set. <p data-bbox="288 1606 448 1635">Supplement</p> <p data-bbox="288 1639 1418 1704">While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p data-bbox="288 1744 440 1774">Completion</p> <p data-bbox="288 1778 1256 1807">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Belt(A)	Transfer belt cleaning voltage (printing)	Belt(B)	Transfer belt cleaning voltage (paper interval)	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Full	Full speed	0 to 255	187	192	202	207	Half	Half speed	0 to 255	172	175	180	182	3/4	3/4 times of line speed	0 to 255	182	182	192	192	B/W*	Black/white mode	0 to 255	-	-	-	212	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Full	Full speed	0 to 255	120	130	150	160	Half	Half speed	0 to 255	100	100	110	110	3/4	3/4 times of line speed	0 to 255	110	110	130	130	B/W*	Black/white mode	0 to 255	-	-	-	160
Display	Description																																																																																				
Belt(A)	Transfer belt cleaning voltage (printing)																																																																																				
Belt(B)	Transfer belt cleaning voltage (paper interval)																																																																																				
Display	Description	Setting range	Initial setting																																																																																		
			30ppm	35ppm	45ppm	55ppm																																																																															
Full	Full speed	0 to 255	187	192	202	207																																																																															
Half	Half speed	0 to 255	172	175	180	182																																																																															
3/4	3/4 times of line speed	0 to 255	182	182	192	192																																																																															
B/W*	Black/white mode	0 to 255	-	-	-	212																																																																															
Display	Description	Setting range	Initial setting																																																																																		
			30ppm	35ppm	45ppm	55ppm																																																																															
Full	Full speed	0 to 255	120	130	150	160																																																																															
Half	Half speed	0 to 255	100	100	110	110																																																																															
3/4	3/4 times of line speed	0 to 255	110	110	130	130																																																																															
B/W*	Black/white mode	0 to 255	-	-	-	160																																																																															

Item No.	Description																																								
U108	<p data-bbox="288 241 651 271">Setting separation shift bias</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 983 374">Adjusts output of separation shift bias and ON/OFF timing.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 994 443">To set when the separated malfunction of the paper occurs.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="304 517 633 582" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 595 1399 889"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1399 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">Output</td> <td data-bbox="639 640 1399 685">Adjusting the separation shift bias output</td> </tr> <tr> <td data-bbox="336 685 639 730">Output 3/4</td> <td data-bbox="639 685 1399 730">Adjusting the separation shift bias output</td> </tr> <tr> <td data-bbox="336 730 639 775">Output B/W*</td> <td data-bbox="639 730 1399 775">Adjusting the separation shift bias output in black/white mode</td> </tr> <tr> <td data-bbox="336 775 639 819">Timing</td> <td data-bbox="639 775 1399 819">Adjusting the ON/OFF timing with paper position</td> </tr> <tr> <td data-bbox="336 819 639 889">Subtraction Value</td> <td data-bbox="639 819 1399 889"></td> </tr> </tbody> </table> <p data-bbox="336 896 612 925">*: 55 ppm model only.</p> <p data-bbox="288 965 504 994">Setting: [Output]</p> <ol data-bbox="304 999 978 1064" style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the +/- or numeric key. <table border="1" data-bbox="336 1077 1399 1655"> <thead> <tr> <th data-bbox="336 1077 564 1155">Display</th> <th data-bbox="564 1077 1066 1155">Description</th> <th data-bbox="1066 1077 1233 1155">Setting range</th> <th data-bbox="1233 1077 1399 1155">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1155 564 1234">Light 1st</td> <td data-bbox="564 1155 1066 1234">Separation shift bias for the first side on paper with thickness 52 to 64 g/m²</td> <td data-bbox="1066 1155 1233 1234">0 to 255</td> <td data-bbox="1233 1155 1399 1234">55</td> </tr> <tr> <td data-bbox="336 1234 564 1312">Light 2nd</td> <td data-bbox="564 1234 1066 1312">Separation shift bias for the second side on paper with thickness 52 to 64 g/m²</td> <td data-bbox="1066 1234 1233 1312">0 to 255</td> <td data-bbox="1233 1234 1399 1312">55</td> </tr> <tr> <td data-bbox="336 1312 564 1391">Normal 1st</td> <td data-bbox="564 1312 1066 1391">Separation shift bias for the first side on paper with thickness 65 to 75 g/m²</td> <td data-bbox="1066 1312 1233 1391">0 to 255</td> <td data-bbox="1233 1312 1399 1391">55</td> </tr> <tr> <td data-bbox="336 1391 564 1469">Normal 2nd</td> <td data-bbox="564 1391 1066 1469">Separation shift bias for the second side on paper with thickness 65 to 75 g/m²</td> <td data-bbox="1066 1391 1233 1469">0 to 255</td> <td data-bbox="1233 1391 1399 1469">55</td> </tr> <tr> <td data-bbox="336 1469 564 1547">Add Normal Lead</td> <td data-bbox="564 1469 1066 1547">Addition value for leading edge on paper with thickness 76 to 105 g/m²</td> <td data-bbox="1066 1469 1233 1547">-127 to 127</td> <td data-bbox="1233 1469 1399 1547">0</td> </tr> <tr> <td data-bbox="336 1547 564 1655">Heavy/OHP</td> <td data-bbox="564 1547 1066 1655">Separation shift bias for transparencies or paper with thickness 106 to 300 g/m²</td> <td data-bbox="1066 1547 1233 1655">0 to 255</td> <td data-bbox="1233 1547 1399 1655">0</td> </tr> </tbody> </table> <ol data-bbox="304 1664 767 1693" style="list-style-type: none"> 3. Press the start key. The value is set. 	Display	Description	Output	Adjusting the separation shift bias output	Output 3/4	Adjusting the separation shift bias output	Output B/W*	Adjusting the separation shift bias output in black/white mode	Timing	Adjusting the ON/OFF timing with paper position	Subtraction Value		Display	Description	Setting range	Initial setting	Light 1st	Separation shift bias for the first side on paper with thickness 52 to 64 g/m ²	0 to 255	55	Light 2nd	Separation shift bias for the second side on paper with thickness 52 to 64 g/m ²	0 to 255	55	Normal 1st	Separation shift bias for the first side on paper with thickness 65 to 75 g/m ²	0 to 255	55	Normal 2nd	Separation shift bias for the second side on paper with thickness 65 to 75 g/m ²	0 to 255	55	Add Normal Lead	Addition value for leading edge on paper with thickness 76 to 105 g/m ²	-127 to 127	0	Heavy/OHP	Separation shift bias for transparencies or paper with thickness 106 to 300 g/m ²	0 to 255	0
Display	Description																																								
Output	Adjusting the separation shift bias output																																								
Output 3/4	Adjusting the separation shift bias output																																								
Output B/W*	Adjusting the separation shift bias output in black/white mode																																								
Timing	Adjusting the ON/OFF timing with paper position																																								
Subtraction Value																																									
Display	Description	Setting range	Initial setting																																						
Light 1st	Separation shift bias for the first side on paper with thickness 52 to 64 g/m ²	0 to 255	55																																						
Light 2nd	Separation shift bias for the second side on paper with thickness 52 to 64 g/m ²	0 to 255	55																																						
Normal 1st	Separation shift bias for the first side on paper with thickness 65 to 75 g/m ²	0 to 255	55																																						
Normal 2nd	Separation shift bias for the second side on paper with thickness 65 to 75 g/m ²	0 to 255	55																																						
Add Normal Lead	Addition value for leading edge on paper with thickness 76 to 105 g/m ²	-127 to 127	0																																						
Heavy/OHP	Separation shift bias for transparencies or paper with thickness 106 to 300 g/m ²	0 to 255	0																																						

Item No.	Description								
U108	Setting: [Output 3/4 / Output B/W]								
	1. Select the item to be set. 2. Change the setting value using the +/- or numeric key.								
	Display		Description		Setting range	Initial setting			
	Output 3/4		Output B/W*						
	Light 1st	Separation shift bias for the first side on paper with thickness 52 to 64 g/m ²		0 to 255	55	20			
	Light 2nd	Separation shift bias for the second side on paper with thickness 52 to 64 g/m ²		0 to 255	55	20			
	Normal 1st	Separation shift bias for the first side on paper with thickness 65 to 75 g/m ²		0 to 255	55	20			
	Normal 2nd	Separation shift bias for the second side on paper with thickness 65 to 75 g/m ²		0 to 255	55	20			
	* : 55 ppm model only.								
	3. Press the start key. The value is set.								
	Setting: [Timing]								
	1. Select the item to be set. 2. Change the setting value using the +/- or numeric key.								
	Display		Description		Setting range	Initial setting			
	On Timing Lead		Separation shift bias ON timing at leading edge of paper		-200 to 200	0			
	On Timing Center		Separation shift bias ON timing at center of paper		-200 to 200	0			
Off Timing		Separation shift bias OFF timing		-200 to 200	0				
3. Press the start key. The value is set.									
Supplement									
While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).									
Setting: [Subtraction Value]									
1. Change the setting value using the +/- keys.									
Display		Description		Setting range	Initial setting				
Value				-127 to 127	-35				
2. Press the start key. The value is set.									
Completion									
Press the stop key. The screen for selecting a maintenance item No. is displayed.									

Item No.	Description										
U110	<p>Checking the drum count</p> <p>Description Displays the drum counts for checking.</p> <p>Purpose To check the drum status.</p> <p>Method 1. Press the start key. The current drum counts is displayed.</p> <table border="1" data-bbox="336 562 1401 801"> <thead> <tr> <th data-bbox="336 562 639 607">Display</th> <th data-bbox="639 562 1401 607">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 607 639 651">C</td> <td data-bbox="639 607 1401 651">Drum count value for cyan</td> </tr> <tr> <td data-bbox="336 651 639 696">M</td> <td data-bbox="639 651 1401 696">Drum count value for magenta</td> </tr> <tr> <td data-bbox="336 696 639 741">Y</td> <td data-bbox="639 696 1401 741">Drum count value for yellow</td> </tr> <tr> <td data-bbox="336 741 639 786">K</td> <td data-bbox="639 741 1401 786">Drum count value for black</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	C	Drum count value for cyan	M	Drum count value for magenta	Y	Drum count value for yellow	K	Drum count value for black
Display	Description										
C	Drum count value for cyan										
M	Drum count value for magenta										
Y	Drum count value for yellow										
K	Drum count value for black										
U111	<p>Checking the drum drive time</p> <p>Description Displays the drum drive time for checking a figure, which is used as a reference when correcting the high voltage based on time.</p> <p>Purpose To check the drum status.</p> <p>Method 1. Press the start key. The drum drive time is displayed.</p> <table border="1" data-bbox="336 1285 1401 1525"> <thead> <tr> <th data-bbox="336 1285 639 1330">Display</th> <th data-bbox="639 1285 1401 1330">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1330 639 1375">C</td> <td data-bbox="639 1330 1401 1375">Drum drive time for cyan</td> </tr> <tr> <td data-bbox="336 1375 639 1420">M</td> <td data-bbox="639 1375 1401 1420">Drum drive time for magenta</td> </tr> <tr> <td data-bbox="336 1420 639 1464">Y</td> <td data-bbox="639 1420 1401 1464">Drum drive time for yellow</td> </tr> <tr> <td data-bbox="336 1464 639 1509">K</td> <td data-bbox="639 1464 1401 1509">Drum drive time for black</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	C	Drum drive time for cyan	M	Drum drive time for magenta	Y	Drum drive time for yellow	K	Drum drive time for black
Display	Description										
C	Drum drive time for cyan										
M	Drum drive time for magenta										
Y	Drum drive time for yellow										
K	Drum drive time for black										

Item No.	Description																
U117	<p>Checking the drum number</p> <p>Description Displays the drum number.</p> <p>Purpose To check the drum number.</p> <p>Method 1. Press the start key. The drum number is displayed.</p> <table border="1" data-bbox="336 562 1401 801"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>C</td> <td>Cyan drum number</td> </tr> <tr> <td>M</td> <td>Magenta drum number</td> </tr> <tr> <td>Y</td> <td>Yellow drum number</td> </tr> <tr> <td>K</td> <td>Black drum number</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	C	Cyan drum number	M	Magenta drum number	Y	Yellow drum number	K	Black drum number						
Display	Description																
C	Cyan drum number																
M	Magenta drum number																
Y	Yellow drum number																
K	Black drum number																
U118	<p>Displaying the drum history</p> <p>Description Displays the past record of machine number and the drum counter.</p> <p>Purpose To check the count value of machine number and the drum counter.</p> <p>Method 1. Press the start key. 2. Select the color to check.</p> <table border="1" data-bbox="336 1288 1401 1527"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>C</td> <td>Cyan drum past record</td> </tr> <tr> <td>M</td> <td>Magenta drum past record</td> </tr> <tr> <td>Y</td> <td>Yellow drum past record</td> </tr> <tr> <td>K</td> <td>Black drum past record</td> </tr> </tbody> </table> <p>The history of a machine number and a drum counter for each color is displayed by three cases.</p> <table border="1" data-bbox="336 1619 1401 1765"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Machine History1 - 3</td> <td>Historical records of the machine number</td> </tr> <tr> <td>Cnt History1 - 3</td> <td>Historical records of drum counter</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	C	Cyan drum past record	M	Magenta drum past record	Y	Yellow drum past record	K	Black drum past record	Display	Description	Machine History1 - 3	Historical records of the machine number	Cnt History1 - 3	Historical records of drum counter
Display	Description																
C	Cyan drum past record																
M	Magenta drum past record																
Y	Yellow drum past record																
K	Black drum past record																
Display	Description																
Machine History1 - 3	Historical records of the machine number																
Cnt History1 - 3	Historical records of drum counter																

Item No.	Description
U119	<p>Setting the drum</p> <p>Description Sets drum sensitivity.</p> <p>Purpose To set the drum after replacing the drum unit or laser scanner unit. When completed, perform maintenance mode U464, Calibration.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Execute]. 3. Press the start key. Drum setup is commenced. 4. Turn the main power switch off and on. Allow more than 5 seconds between Off and On.
U122	<p>Checking the transfer belt unit number</p> <p>Description Displays the number of the transfer belt unit for checking.</p> <p>Purpose To check the number of the transfer belt.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The current number of the transfer belt is displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Item No.	Description										
U123	<p>Displaying the transfer belt unit history</p> <p>Description Displays the past record of machine number and the transfer belt unit counter.</p> <p>Purpose To check the count value of machine number and the transfer counter.</p> <p>Method</p> <ol style="list-style-type: none"> Press the start key. The history of a machine number and a transfer belt unit counter for each color is displayed by three cases. <table border="1" data-bbox="336 631 1401 777"> <thead> <tr> <th data-bbox="336 631 641 678">Display</th> <th data-bbox="641 631 1401 678">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 678 641 725">Machine History1 - 3</td> <td data-bbox="641 678 1401 725">Historical records of the machine number</td> </tr> <tr> <td data-bbox="336 725 641 772">Cnt History1 - 3</td> <td data-bbox="641 725 1401 772">Historical records of transfer belt unit counter</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Machine History1 - 3	Historical records of the machine number	Cnt History1 - 3	Historical records of transfer belt unit counter				
Display	Description										
Machine History1 - 3	Historical records of the machine number										
Cnt History1 - 3	Historical records of transfer belt unit counter										
U127	<p>Checking/clearing the transfer count</p> <p>Description Displays and clears the counts of the transfer counter.</p> <p>Purpose To check the count or drive time after replacement of the transfer belt unit or transfer roller. Also to clear the counts after replacing transfer roller.</p> <p>Method</p> <ol style="list-style-type: none"> Press the start key. The current counts of the transfer counter is displayed. <table border="1" data-bbox="336 1258 1401 1498"> <thead> <tr> <th data-bbox="336 1258 641 1305">Display</th> <th data-bbox="641 1258 1401 1305">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1305 641 1352">Mid Trans(Cnt)</td> <td data-bbox="641 1305 1401 1352">Transfer belt unit count value</td> </tr> <tr> <td data-bbox="336 1352 641 1400">2nd Trans(Cnt)</td> <td data-bbox="641 1352 1401 1400">Transfer roller count value</td> </tr> <tr> <td data-bbox="336 1400 641 1447">Mid Trans(Time)</td> <td data-bbox="641 1400 1401 1447">Transfer belt unit drive time</td> </tr> <tr> <td data-bbox="336 1447 641 1494">2nd Trans(Time)</td> <td data-bbox="641 1447 1401 1494">Transfer roller drive time</td> </tr> </tbody> </table> <p>Clearing</p> <ol style="list-style-type: none"> Select [Clear]. Press the start key. The counter value is cleared. Clears only the transfer roller. The transfer belt unit is not cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Mid Trans(Cnt)	Transfer belt unit count value	2nd Trans(Cnt)	Transfer roller count value	Mid Trans(Time)	Transfer belt unit drive time	2nd Trans(Time)	Transfer roller drive time
Display	Description										
Mid Trans(Cnt)	Transfer belt unit count value										
2nd Trans(Cnt)	Transfer roller count value										
Mid Trans(Time)	Transfer belt unit drive time										
2nd Trans(Time)	Transfer roller drive time										

Item No.	Description																																
U128	<p>Setting transfer high-voltage timing</p> <p>Description Adjusts the ON/OFF timing of transfer high-voltage output.</p> <p>Purpose Basically, the setting need not be changed. If any problem such as faulty images or dirt on the back surface occurs, change the setting.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to set. 3. Change the value using the +/- keys or numeric keys. <table border="1" data-bbox="336 667 1401 1010"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="4">Initial setting</th> </tr> <tr> <th>30ppm</th> <th>35ppm</th> <th>45ppm</th> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>On Timing 1st</td> <td>Transfer ON timing adjustment value (first side)</td> <td>-200 to 200</td> <td>-5</td> <td>-5</td> <td>-5</td> <td>-5</td> </tr> <tr> <td>On Timing 2nd</td> <td>Transfer ON timing adjustment value (second side)</td> <td>-200 to 200</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>Off Timing</td> <td>Transfer OFF timing adjustment value</td> <td>-200 to 200</td> <td>20</td> <td>16</td> <td>13</td> <td>10</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	On Timing 1st	Transfer ON timing adjustment value (first side)	-200 to 200	-5	-5	-5	-5	On Timing 2nd	Transfer ON timing adjustment value (second side)	-200 to 200	0	0	0	0	Off Timing	Transfer OFF timing adjustment value	-200 to 200	20	16	13	10
Display	Description				Setting range	Initial setting																											
		30ppm	35ppm	45ppm		55ppm																											
On Timing 1st	Transfer ON timing adjustment value (first side)	-200 to 200	-5	-5	-5	-5																											
On Timing 2nd	Transfer ON timing adjustment value (second side)	-200 to 200	0	0	0	0																											
Off Timing	Transfer OFF timing adjustment value	-200 to 200	20	16	13	10																											
U130	<p>Initial setting for the developer</p> <p>Description The toner sensor control bias is adjusted so that the sensor output is set as the target value with the initial developer.</p> <p>Purpose Automatically executed when the developer unit loaded with the initial developer is replaced.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Execute]. 3. Press the start key. <p>Toner installation is started and the control value of the toner sensor is displayed.</p> <table border="1" data-bbox="336 1630 1401 1870"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>C</td> <td>Toner sensor C control voltage</td> </tr> <tr> <td>M</td> <td>Toner sensor M control voltage</td> </tr> <tr> <td>Y</td> <td>Toner sensor Y control voltage</td> </tr> <tr> <td>K</td> <td>Toner sensor K control voltage</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	C	Toner sensor C control voltage	M	Toner sensor M control voltage	Y	Toner sensor Y control voltage	K	Toner sensor K control voltage																						
Display	Description																																
C	Toner sensor C control voltage																																
M	Toner sensor M control voltage																																
Y	Toner sensor Y control voltage																																
K	Toner sensor K control voltage																																

Item No.	Description																																														
U131	<p data-bbox="288 241 831 275">Adjusting the toner sensor control voltage</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 767 376">Adjusts the toner sensor control voltage.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1398 479">If control values are not correctly retrievable due to the EEPROM of the developer unit failure, etc., use manual adjustment and obtain a temporary control value.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 553 783 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set or displayed. <table border="1" data-bbox="336 631 1401 824"> <thead> <tr> <th data-bbox="336 631 639 676">Display</th> <th data-bbox="639 631 1401 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 676 639 721">Manual</td> <td data-bbox="639 676 1401 721">Toner sensor control voltage manual adjustment</td> </tr> <tr> <td data-bbox="336 721 639 766">Auto</td> <td data-bbox="639 721 1401 766">Toner sensor control voltage auto adjustment</td> </tr> <tr> <td data-bbox="336 766 639 810">Mode</td> <td data-bbox="639 766 1401 810">Switching the manual adjustment and auto adjustment</td> </tr> </tbody> </table> <p data-bbox="288 869 509 898">Setting: [Manual]</p> <ol data-bbox="304 902 906 967" style="list-style-type: none"> 1. Select the item to be set. 2. Change the value using the +/- or numeric keys. <table border="1" data-bbox="336 981 1401 1256"> <thead> <tr> <th data-bbox="336 981 564 1061">Display</th> <th data-bbox="564 981 1066 1061">Description</th> <th data-bbox="1066 981 1233 1061">Setting range</th> <th data-bbox="1233 981 1401 1061">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1061 564 1106">Control(C)</td> <td data-bbox="564 1061 1066 1106">Toner sensor C control voltage</td> <td data-bbox="1066 1061 1233 1106">0 to 255</td> <td data-bbox="1233 1061 1401 1106">150</td> </tr> <tr> <td data-bbox="336 1106 564 1151">Control(M)</td> <td data-bbox="564 1106 1066 1151">Toner sensor M control voltage</td> <td data-bbox="1066 1106 1233 1151">0 to 255</td> <td data-bbox="1233 1106 1401 1151">150</td> </tr> <tr> <td data-bbox="336 1151 564 1196">Control(Y)</td> <td data-bbox="564 1151 1066 1196">Toner sensor Y control voltage</td> <td data-bbox="1066 1151 1233 1196">0 to 255</td> <td data-bbox="1233 1151 1401 1196">150</td> </tr> <tr> <td data-bbox="336 1196 564 1256">Control(K)</td> <td data-bbox="564 1196 1066 1256">Toner sensor K control voltage</td> <td data-bbox="1066 1196 1233 1256">0 to 255</td> <td data-bbox="1233 1196 1401 1256">150</td> </tr> </tbody> </table> <ol data-bbox="304 1263 767 1294" style="list-style-type: none"> 3. Press the start key. The value is set. <p data-bbox="288 1332 523 1361">Displaying: [Auto]</p> <ol data-bbox="304 1366 715 1397" style="list-style-type: none"> 1. The current setting is displayed. <table border="1" data-bbox="336 1411 1401 1843"> <thead> <tr> <th data-bbox="336 1411 639 1456">Display</th> <th data-bbox="639 1411 1401 1456">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1456 639 1500">Default(C)</td> <td data-bbox="639 1456 1401 1500">Reference value for toner sensor C control voltage</td> </tr> <tr> <td data-bbox="336 1500 639 1545">Default(M)</td> <td data-bbox="639 1500 1401 1545">Reference value for toner sensor M control voltage</td> </tr> <tr> <td data-bbox="336 1545 639 1590">Default(Y)</td> <td data-bbox="639 1545 1401 1590">Reference value for toner sensor Y control voltage</td> </tr> <tr> <td data-bbox="336 1590 639 1635">Default(K)</td> <td data-bbox="639 1590 1401 1635">Reference value for toner sensor K control voltage</td> </tr> <tr> <td data-bbox="336 1635 639 1680">Control(C)</td> <td data-bbox="639 1635 1401 1680">Toner sensor C control voltage after correction</td> </tr> <tr> <td data-bbox="336 1680 639 1724">Control(M)</td> <td data-bbox="639 1680 1401 1724">Toner sensor M control voltage after correction</td> </tr> <tr> <td data-bbox="336 1724 639 1769">Control(Y)</td> <td data-bbox="639 1724 1401 1769">Toner sensor Y control voltage after correction</td> </tr> <tr> <td data-bbox="336 1769 639 1843">Control(K)</td> <td data-bbox="639 1769 1401 1843">Toner sensor K control voltage after correction</td> </tr> </tbody> </table>	Display	Description	Manual	Toner sensor control voltage manual adjustment	Auto	Toner sensor control voltage auto adjustment	Mode	Switching the manual adjustment and auto adjustment	Display	Description	Setting range	Initial setting	Control(C)	Toner sensor C control voltage	0 to 255	150	Control(M)	Toner sensor M control voltage	0 to 255	150	Control(Y)	Toner sensor Y control voltage	0 to 255	150	Control(K)	Toner sensor K control voltage	0 to 255	150	Display	Description	Default(C)	Reference value for toner sensor C control voltage	Default(M)	Reference value for toner sensor M control voltage	Default(Y)	Reference value for toner sensor Y control voltage	Default(K)	Reference value for toner sensor K control voltage	Control(C)	Toner sensor C control voltage after correction	Control(M)	Toner sensor M control voltage after correction	Control(Y)	Toner sensor Y control voltage after correction	Control(K)	Toner sensor K control voltage after correction
Display	Description																																														
Manual	Toner sensor control voltage manual adjustment																																														
Auto	Toner sensor control voltage auto adjustment																																														
Mode	Switching the manual adjustment and auto adjustment																																														
Display	Description	Setting range	Initial setting																																												
Control(C)	Toner sensor C control voltage	0 to 255	150																																												
Control(M)	Toner sensor M control voltage	0 to 255	150																																												
Control(Y)	Toner sensor Y control voltage	0 to 255	150																																												
Control(K)	Toner sensor K control voltage	0 to 255	150																																												
Display	Description																																														
Default(C)	Reference value for toner sensor C control voltage																																														
Default(M)	Reference value for toner sensor M control voltage																																														
Default(Y)	Reference value for toner sensor Y control voltage																																														
Default(K)	Reference value for toner sensor K control voltage																																														
Control(C)	Toner sensor C control voltage after correction																																														
Control(M)	Toner sensor M control voltage after correction																																														
Control(Y)	Toner sensor Y control voltage after correction																																														
Control(K)	Toner sensor K control voltage after correction																																														

Item No.	Description																		
U131	<p>Setting: [Mode]</p> <p>1. Select the item to be set.</p> <table border="1" data-bbox="336 320 1401 465"> <thead> <tr> <th data-bbox="336 320 639 365">Display</th> <th data-bbox="639 320 1401 365">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 365 639 409">Manual</td> <td data-bbox="639 365 1401 409">Toner sensor control voltage manual adjustment</td> </tr> <tr> <td data-bbox="336 409 639 465">Auto</td> <td data-bbox="639 409 1401 465">Toner sensor control voltage auto adjustment</td> </tr> </tbody> </table> <p>Initial setting: Auto</p> <p>2. Press the start key. The value is set.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Manual	Toner sensor control voltage manual adjustment	Auto	Toner sensor control voltage auto adjustment												
Display	Description																		
Manual	Toner sensor control voltage manual adjustment																		
Auto	Toner sensor control voltage auto adjustment																		
U132	<p>Replenishing toner forcibly</p> <p>Description Replenishes toner forcibly until the toner sensor output value reaches the toner feed start level.</p> <p>Purpose Used when the toner empty is detected frequently.</p> <p>Method</p> <p>1. Press the start key. 2. Select [Execute]. 3. Press the start key. Toner is replenished until the toner sensor output value reaches the toner feed start level.</p> <table border="1" data-bbox="336 1086 1401 1518"> <thead> <tr> <th data-bbox="336 1086 639 1131">Display</th> <th data-bbox="639 1086 1401 1131">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1131 639 1176">Supply(C)</td> <td data-bbox="639 1131 1401 1176">Toner feed start level (cyan)</td> </tr> <tr> <td data-bbox="336 1176 639 1220">Supply(M)</td> <td data-bbox="639 1176 1401 1220">Toner feed start level (magenta)</td> </tr> <tr> <td data-bbox="336 1220 639 1265">Supply(Y)</td> <td data-bbox="639 1220 1401 1265">Toner feed start level (yellow)</td> </tr> <tr> <td data-bbox="336 1265 639 1310">Supply(K)</td> <td data-bbox="639 1265 1401 1310">Toner feed start level (black)</td> </tr> <tr> <td data-bbox="336 1310 639 1355">Sensor(C)</td> <td data-bbox="639 1310 1401 1355">Toner sensor output value (cyan)</td> </tr> <tr> <td data-bbox="336 1355 639 1400">Sensor(M)</td> <td data-bbox="639 1355 1401 1400">Toner sensor output value (magenta)</td> </tr> <tr> <td data-bbox="336 1400 639 1444">Sensor(Y)</td> <td data-bbox="639 1400 1401 1444">Toner sensor output value (yellow)</td> </tr> <tr> <td data-bbox="336 1444 639 1518">Sensor(K)</td> <td data-bbox="639 1444 1401 1518">Toner sensor output value (black)</td> </tr> </tbody> </table> <p>4. To stop operation, press the stop key.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Supply(C)	Toner feed start level (cyan)	Supply(M)	Toner feed start level (magenta)	Supply(Y)	Toner feed start level (yellow)	Supply(K)	Toner feed start level (black)	Sensor(C)	Toner sensor output value (cyan)	Sensor(M)	Toner sensor output value (magenta)	Sensor(Y)	Toner sensor output value (yellow)	Sensor(K)	Toner sensor output value (black)
Display	Description																		
Supply(C)	Toner feed start level (cyan)																		
Supply(M)	Toner feed start level (magenta)																		
Supply(Y)	Toner feed start level (yellow)																		
Supply(K)	Toner feed start level (black)																		
Sensor(C)	Toner sensor output value (cyan)																		
Sensor(M)	Toner sensor output value (magenta)																		
Sensor(Y)	Toner sensor output value (yellow)																		
Sensor(K)	Toner sensor output value (black)																		

Item No.	Description												
U135	<p>Checking toner motor operation</p> <p>Description Drives toner motors.</p> <p>Purpose To check the operation of toner motors.</p> <p>Remarks When driving the toner motors long time or several times, developer section becomes the toner full and is locked.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Toner]. 3. Press the start key. The operation starts. <table border="1" data-bbox="336 770 1401 866"> <thead> <tr> <th data-bbox="336 770 639 815">Display</th> <th data-bbox="639 770 1401 815">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 815 639 866">Toner</td> <td data-bbox="639 815 1401 866">Toner motor (TM) is turned on</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. To stop the operation, press the stop key. <p>Completion Press the stop key after operation stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Toner	Toner motor (TM) is turned on								
Display	Description												
Toner	Toner motor (TM) is turned on												
U136	<p>Setting toner near end detection</p> <p>Description Sets the level that indicates the number of sheets that can be printed from occurrence of toner near end to toner empty.</p> <p>Purpose To change the setting to advance detection of near end if the interval from toner near end to toner empty seems too short.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. 3. Change the value using the +/- or numeric keys. <table border="1" data-bbox="336 1520 1401 1700"> <thead> <tr> <th data-bbox="336 1520 528 1603">Display</th> <th data-bbox="528 1520 1094 1603">Description</th> <th data-bbox="1094 1520 1249 1603">Setting range</th> <th data-bbox="1249 1520 1401 1603">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1603 528 1648">CMY</td> <td data-bbox="528 1603 1094 1648">Setting the level of cyan/magenta/yellow toner</td> <td data-bbox="1094 1603 1249 1648">0 to 9</td> <td data-bbox="1249 1603 1401 1648">3</td> </tr> <tr> <td data-bbox="336 1648 528 1700">K</td> <td data-bbox="528 1648 1094 1700">Setting the level of black toner</td> <td data-bbox="1094 1648 1249 1700">0 to 9</td> <td data-bbox="1249 1648 1401 1700">3</td> </tr> </tbody> </table> <p>Increasing the setting makes the interval from toner near end to toner empty longer. Decreasing the setting makes the interval from toner near end to toner empty shorter. If 0 is set, toner near end will not be detected.</p> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	CMY	Setting the level of cyan/magenta/yellow toner	0 to 9	3	K	Setting the level of black toner	0 to 9	3
Display	Description	Setting range	Initial setting										
CMY	Setting the level of cyan/magenta/yellow toner	0 to 9	3										
K	Setting the level of black toner	0 to 9	3										

Item No.	Description																																				
U139	<p data-bbox="288 241 1077 275">Displaying the temperature and humidity outside the machine</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1110 374">Displays the detected temperature and humidity outside the machine.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1007 443">To check the temperature and humidity outside the machine.</p> <p data-bbox="288 486 387 515">Method</p> <ol data-bbox="304 519 564 582" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 595 1401 788"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1401 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">Ext/Int</td> <td data-bbox="639 640 1401 685">Internal/External temperature (°C), External humidity (%)</td> </tr> <tr> <td data-bbox="336 685 639 730">LSU</td> <td data-bbox="639 685 1401 730">Internal temperature around the laser scanner unit (°C)</td> </tr> <tr> <td data-bbox="336 730 639 788">Developing</td> <td data-bbox="639 730 1401 788">Internal temperature around the developer section (°C)</td> </tr> </tbody> </table> <p data-bbox="288 835 504 864">Method: [Ext/Int]</p> <ol data-bbox="304 869 959 898" style="list-style-type: none"> 1. The current temperature and humidity are displayed. <table border="1" data-bbox="336 911 1401 1104"> <thead> <tr> <th data-bbox="336 911 639 956">Display</th> <th data-bbox="639 911 1401 956">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 956 639 1001">External Temp</td> <td data-bbox="639 956 1401 1001">External temperature (°C)</td> </tr> <tr> <td data-bbox="336 1001 639 1046">External Humidity</td> <td data-bbox="639 1001 1401 1046">External humidity (%)</td> </tr> <tr> <td data-bbox="336 1046 639 1104">Internal Temp</td> <td data-bbox="639 1046 1401 1104">Internal temperature (°C)</td> </tr> </tbody> </table> <p data-bbox="288 1151 475 1180">Method: [LSU]</p> <ol data-bbox="304 1184 778 1214" style="list-style-type: none"> 1. The current temperature is displayed. <table border="1" data-bbox="336 1227 1401 1469"> <thead> <tr> <th data-bbox="336 1227 639 1272">Display</th> <th data-bbox="639 1227 1401 1272">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1272 639 1317">C</td> <td data-bbox="639 1272 1401 1317">Internal temperature around the laser scanner unit C (°C)</td> </tr> <tr> <td data-bbox="336 1317 639 1361">M</td> <td data-bbox="639 1317 1401 1361">Internal temperature around the laser scanner unit M (°C)</td> </tr> <tr> <td data-bbox="336 1361 639 1406">Y</td> <td data-bbox="639 1361 1401 1406">Internal temperature around the laser scanner unit Y (°C)</td> </tr> <tr> <td data-bbox="336 1406 639 1469">K</td> <td data-bbox="639 1406 1401 1469">Internal temperature around the laser scanner unit K (°C)</td> </tr> </tbody> </table> <p data-bbox="288 1516 564 1545">Method: [Developing]</p> <ol data-bbox="304 1550 778 1579" style="list-style-type: none"> 1. The current temperature is displayed. <table border="1" data-bbox="336 1592 1401 1834"> <thead> <tr> <th data-bbox="336 1592 639 1637">Display</th> <th data-bbox="639 1592 1401 1637">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1637 639 1682">C</td> <td data-bbox="639 1637 1401 1682">Internal temperature around the developer unit C (°C)</td> </tr> <tr> <td data-bbox="336 1682 639 1727">M</td> <td data-bbox="639 1682 1401 1727">Internal temperature around the developer unit M (°C)</td> </tr> <tr> <td data-bbox="336 1727 639 1771">Y</td> <td data-bbox="639 1727 1401 1771">Internal temperature around the developer unit Y (°C)</td> </tr> <tr> <td data-bbox="336 1771 639 1834">K</td> <td data-bbox="639 1771 1401 1834">Internal temperature around the developer unit K (°C)</td> </tr> </tbody> </table> <p data-bbox="288 1881 440 1910">Completion</p> <p data-bbox="288 1915 1254 1944">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Ext/Int	Internal/External temperature (°C), External humidity (%)	LSU	Internal temperature around the laser scanner unit (°C)	Developing	Internal temperature around the developer section (°C)	Display	Description	External Temp	External temperature (°C)	External Humidity	External humidity (%)	Internal Temp	Internal temperature (°C)	Display	Description	C	Internal temperature around the laser scanner unit C (°C)	M	Internal temperature around the laser scanner unit M (°C)	Y	Internal temperature around the laser scanner unit Y (°C)	K	Internal temperature around the laser scanner unit K (°C)	Display	Description	C	Internal temperature around the developer unit C (°C)	M	Internal temperature around the developer unit M (°C)	Y	Internal temperature around the developer unit Y (°C)	K	Internal temperature around the developer unit K (°C)
Display	Description																																				
Ext/Int	Internal/External temperature (°C), External humidity (%)																																				
LSU	Internal temperature around the laser scanner unit (°C)																																				
Developing	Internal temperature around the developer section (°C)																																				
Display	Description																																				
External Temp	External temperature (°C)																																				
External Humidity	External humidity (%)																																				
Internal Temp	Internal temperature (°C)																																				
Display	Description																																				
C	Internal temperature around the laser scanner unit C (°C)																																				
M	Internal temperature around the laser scanner unit M (°C)																																				
Y	Internal temperature around the laser scanner unit Y (°C)																																				
K	Internal temperature around the laser scanner unit K (°C)																																				
Display	Description																																				
C	Internal temperature around the developer unit C (°C)																																				
M	Internal temperature around the developer unit M (°C)																																				
Y	Internal temperature around the developer unit Y (°C)																																				
K	Internal temperature around the developer unit K (°C)																																				

Item No.	Description																																																																		
U140	<p data-bbox="287 241 622 273">Displaying developer bias</p> <p data-bbox="287 309 438 340">Description</p> <p data-bbox="287 344 906 376">Displays and changes various developer bias value.</p> <p data-bbox="287 380 399 412">Purpose</p> <p data-bbox="287 416 842 448">To check or changes the developer bias value.</p> <p data-bbox="287 483 391 515">Method</p> <ol data-bbox="303 519 630 582" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="335 593 1401 1075"> <thead> <tr> <th data-bbox="343 600 638 645">Display</th> <th data-bbox="638 600 1393 645">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 649 638 683">Sleeve DC</td> <td data-bbox="638 649 1393 683">Developer sleeve roller DC bias</td> </tr> <tr> <td data-bbox="343 687 638 721">Sleeve AC</td> <td data-bbox="638 687 1393 721">Developer sleeve roller AC bias</td> </tr> <tr> <td data-bbox="343 725 638 759">Mag DC</td> <td data-bbox="638 725 1393 759">Developer magnet roller DC bias</td> </tr> <tr> <td data-bbox="343 763 638 797">Mag AC</td> <td data-bbox="638 763 1393 797">Developer magnet roller AC bias</td> </tr> <tr> <td data-bbox="343 801 638 835">Sleeve Freq</td> <td data-bbox="638 801 1393 835">Developer sleeve roller frequency</td> </tr> <tr> <td data-bbox="343 840 638 873">Sleeve Duty</td> <td data-bbox="638 840 1393 873">Developer sleeve roller duty</td> </tr> <tr> <td data-bbox="343 878 638 911">Mag Duty</td> <td data-bbox="638 878 1393 911">Developer magnet roller duty</td> </tr> <tr> <td data-bbox="343 916 638 949">AC Calib</td> <td data-bbox="638 916 1393 949">Executing or setting the AC calibration</td> </tr> <tr> <td data-bbox="343 954 638 987">Image Preference</td> <td data-bbox="638 954 1393 987">Toner density setting</td> </tr> </tbody> </table> <p data-bbox="287 1120 550 1151">Setting: [Sleeve DC]</p> <ol data-bbox="303 1155 1053 1218" style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="335 1232 1401 1742"> <thead> <tr> <th data-bbox="343 1238 454 1328" rowspan="2">Display</th> <th data-bbox="454 1238 869 1328" rowspan="2">Description</th> <th data-bbox="869 1238 1005 1328" rowspan="2">Setting range</th> <th colspan="4" data-bbox="1005 1238 1393 1276">Initial setting</th> </tr> <tr> <th data-bbox="1005 1276 1101 1328">30ppm</th> <th data-bbox="1101 1276 1197 1328">35ppm</th> <th data-bbox="1197 1276 1292 1328">45ppm</th> <th data-bbox="1292 1276 1393 1328">55ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 1332 454 1411">C</td> <td data-bbox="454 1332 869 1411">Developer sleeve roller DC bias for cyan</td> <td data-bbox="869 1332 1005 1411">0 to 255</td> <td data-bbox="1005 1332 1101 1411">72</td> <td data-bbox="1101 1332 1197 1411">72</td> <td data-bbox="1197 1332 1292 1411">84</td> <td data-bbox="1292 1332 1393 1411">84</td> </tr> <tr> <td data-bbox="343 1415 454 1494">M</td> <td data-bbox="454 1415 869 1494">Developer sleeve roller DC bias for magenta</td> <td data-bbox="869 1415 1005 1494">0 to 255</td> <td data-bbox="1005 1415 1101 1494">72</td> <td data-bbox="1101 1415 1197 1494">72</td> <td data-bbox="1197 1415 1292 1494">84</td> <td data-bbox="1292 1415 1393 1494">84</td> </tr> <tr> <td data-bbox="343 1498 454 1576">Y</td> <td data-bbox="454 1498 869 1576">Developer sleeve roller DC bias for yellow</td> <td data-bbox="869 1498 1005 1576">0 to 255</td> <td data-bbox="1005 1498 1101 1576">72</td> <td data-bbox="1101 1498 1197 1576">72</td> <td data-bbox="1197 1498 1292 1576">84</td> <td data-bbox="1292 1498 1393 1576">84</td> </tr> <tr> <td data-bbox="343 1581 454 1659">K</td> <td data-bbox="454 1581 869 1659">Developer sleeve roller DC bias for black</td> <td data-bbox="869 1581 1005 1659">0 to 255</td> <td data-bbox="1005 1581 1101 1659">62</td> <td data-bbox="1101 1581 1197 1659">62</td> <td data-bbox="1197 1581 1292 1659">70</td> <td data-bbox="1292 1581 1393 1659">70</td> </tr> <tr> <td data-bbox="343 1664 454 1742">B/W*</td> <td data-bbox="454 1664 869 1742">Developer sleeve roller DC bias in black/white mode</td> <td data-bbox="869 1664 1005 1742">0 to 255</td> <td data-bbox="1005 1664 1101 1742">-</td> <td data-bbox="1101 1664 1197 1742">-</td> <td data-bbox="1197 1664 1292 1742">-</td> <td data-bbox="1292 1664 1393 1742">70</td> </tr> </tbody> </table> <p data-bbox="335 1751 598 1783">*: 55 ppm model only.</p> <ol data-bbox="303 1787 766 1818" style="list-style-type: none"> 3. Press the start key. The value is set. 	Display	Description	Sleeve DC	Developer sleeve roller DC bias	Sleeve AC	Developer sleeve roller AC bias	Mag DC	Developer magnet roller DC bias	Mag AC	Developer magnet roller AC bias	Sleeve Freq	Developer sleeve roller frequency	Sleeve Duty	Developer sleeve roller duty	Mag Duty	Developer magnet roller duty	AC Calib	Executing or setting the AC calibration	Image Preference	Toner density setting	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	C	Developer sleeve roller DC bias for cyan	0 to 255	72	72	84	84	M	Developer sleeve roller DC bias for magenta	0 to 255	72	72	84	84	Y	Developer sleeve roller DC bias for yellow	0 to 255	72	72	84	84	K	Developer sleeve roller DC bias for black	0 to 255	62	62	70	70	B/W*	Developer sleeve roller DC bias in black/white mode	0 to 255	-	-	-	70
Display	Description																																																																		
Sleeve DC	Developer sleeve roller DC bias																																																																		
Sleeve AC	Developer sleeve roller AC bias																																																																		
Mag DC	Developer magnet roller DC bias																																																																		
Mag AC	Developer magnet roller AC bias																																																																		
Sleeve Freq	Developer sleeve roller frequency																																																																		
Sleeve Duty	Developer sleeve roller duty																																																																		
Mag Duty	Developer magnet roller duty																																																																		
AC Calib	Executing or setting the AC calibration																																																																		
Image Preference	Toner density setting																																																																		
Display	Description	Setting range	Initial setting																																																																
			30ppm	35ppm	45ppm	55ppm																																																													
C	Developer sleeve roller DC bias for cyan	0 to 255	72	72	84	84																																																													
M	Developer sleeve roller DC bias for magenta	0 to 255	72	72	84	84																																																													
Y	Developer sleeve roller DC bias for yellow	0 to 255	72	72	84	84																																																													
K	Developer sleeve roller DC bias for black	0 to 255	62	62	70	70																																																													
B/W*	Developer sleeve roller DC bias in black/white mode	0 to 255	-	-	-	70																																																													

Item No.	Description						
U140	Setting: [Sleeve AC]						
	1. Select the item to be set. 2. Change the setting value using the +/- keys or numeric keys.						
	Display	Description	Setting range	Initial setting			
				30ppm	35ppm	45ppm	55ppm
	C	Developer sleeve roller AC bias for cyan	0 to 255	175	175	155	155
	M	Developer sleeve roller AC bias for magenta	0 to 255	175	175	155	155
	Y	Developer sleeve roller AC bias for yellow	0 to 255	175	175	155	155
	K	Developer sleeve roller AC bias for black	0 to 255	175	175	155	155
	B/W*	Developer sleeve roller AC bias in black/white mode	0 to 255	-	-	-	155
	*: 55 ppm model only.						
	3. Press the start key. The value is set.						
	Setting: [Mag DC]						
	1. Select the item to be set. 2. Change the setting value using the +/- keys or numeric keys.						
	Display	Description	Setting range	Initial setting			
				30ppm	35ppm	45ppm	55ppm
C	Developer magnet roller DC bias for cyan	0 to 255	130	130	155	155	
M	Developer magnet roller DC bias for magenta	0 to 255	130	130	155	155	
Y	Developer magnet roller DC bias for yellow	0 to 255	130	130	155	155	
K	Developer magnet roller DC bias for black	0 to 255	130	130	155	155	
B/W*	Developer magnet roller DC bias in black/white mode	0 to 255	-	-	-	155	
*: 55 ppm model only.							
3. Press the start key. The value is set.							

Item No.	Description						
U140	Setting: [Mag AC]						
	1. Select the item to be set.						
	2. Change the setting value using the +/- keys or numeric keys.						
				Initial setting			
	Display	Description	Setting range	30ppm	35ppm	45ppm	55ppm
	C	Developer magnet roller AC bias for cyan	0 to 255	101	101	200	200
	M	Developer magnet roller AC bias for magenta	0 to 255	101	101	200	200
	Y	Developer magnet roller AC bias for yellow	0 to 255	101	101	200	200
	K	Developer magnet roller AC bias for black	0 to 255	101	101	160	160
	B/W*	Developer magnet roller AC bias in black/white mode	0 to 255	-	-	-	160
	*: 55 ppm model only.						
	3. Press the start key. The value is set.						
	Setting: [Sleeve Freq]						
	1. Select the item to be set.						
	2. Change the setting value using the +/- keys or numeric keys.						
			Initial setting				
Display	Description	Setting range	30ppm	35ppm	45ppm	55ppm	
Normal	Developer sleeve roller frequency	0 to 6200	5221	5345	5345	5511	
B/W*	Developer sleeve roller frequency in black/white mode	0 to 6200	-	-	-	5345	
Half	Developer sleeve roller frequency (half speed)	0 to 6200	5345	5345	5345	5345	
3/4*	Developer sleeve roller frequency at 3/4 times of line speed	0 to 6200	5345	5345	5345	5345	
*: 55 ppm model only.							
3. Press the start key. The value is set.							
Setting: [Sleeve Duty]							
1. Select the item to be set.							
2. Change the setting value using the +/- keys or numeric keys.							
			Initial setting				
Display	Description	Setting range	30ppm	35ppm	45ppm	55ppm	
Normal	Developer sleeve roller duty	0 to 99	63	63	43	43	
B/W*	Developer sleeve roller duty in black/white mode	0 to 99	-	-	-	43	
*: 55 ppm model only.							
3. Press the start key. The value is set.							

Item No.	Description																															
U140	Setting: [Mag Duty]																															
	1. Select the item to be set. 2. Change the setting value using the +/- keys or numeric keys.																															
	<table border="1"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="4">Initial setting</th> </tr> <tr> <th>30ppm</th> <th>35ppm</th> <th>45ppm</th> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>Normal</td> <td>Developer magnet roller duty</td> <td>0 to 99</td> <td>37</td> <td>37</td> <td>68</td> <td>68</td> </tr> <tr> <td>B/W*</td> <td>Developer magnet roller duty in black/white mode</td> <td>0 to 99</td> <td>-</td> <td>-</td> <td>-</td> <td>68</td> </tr> </tbody> </table>							Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Normal	Developer magnet roller duty	0 to 99	37	37	68	68	B/W*	Developer magnet roller duty in black/white mode	0 to 99	-	-	-	68
	Display	Description	Setting range	Initial setting																												
				30ppm	35ppm	45ppm	55ppm																									
	Normal	Developer magnet roller duty	0 to 99	37	37	68	68																									
	B/W*	Developer magnet roller duty in black/white mode	0 to 99	-	-	-	68																									
	*: 55 ppm model only.																															
	3. Press the start key. The value is set.																															
	Method: [AC Calib](45 ppm model/55 ppm model)																															
1. Select the item.																																
<table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Calibration</td> <td>Executing the AC calibration</td> </tr> <tr> <td>Magnification</td> <td>AC calibration target bias value setting</td> </tr> <tr> <td>High Altitude</td> <td>Mode setting for AC calibration bias control</td> </tr> </tbody> </table>							Display	Description	Calibration	Executing the AC calibration	Magnification	AC calibration target bias value setting	High Altitude	Mode setting for AC calibration bias control																		
Display	Description																															
Calibration	Executing the AC calibration																															
Magnification	AC calibration target bias value setting																															
High Altitude	Mode setting for AC calibration bias control																															
Method: [Calibration]																																
1. Turns the items to implement to on. 2. If the machine is installed at high altitudes, turn all of CMYK to On. Changing Type to 1 sets all of CMYK to On.																																
<table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>C</td> <td>When replacing the developer unit C or drum unit C</td> </tr> <tr> <td>M</td> <td>When replacing the developer unit M or drum unit M</td> </tr> <tr> <td>Y</td> <td>When replacing the developer unit Y or drum unit Y</td> </tr> <tr> <td>K</td> <td>When replacing the developer unit K or drum unit K</td> </tr> <tr> <td>Type</td> <td>Setting the mode</td> </tr> </tbody> </table>							Display	Description	C	When replacing the developer unit C or drum unit C	M	When replacing the developer unit M or drum unit M	Y	When replacing the developer unit Y or drum unit Y	K	When replacing the developer unit K or drum unit K	Type	Setting the mode														
Display	Description																															
C	When replacing the developer unit C or drum unit C																															
M	When replacing the developer unit M or drum unit M																															
Y	When replacing the developer unit Y or drum unit Y																															
K	When replacing the developer unit K or drum unit K																															
Type	Setting the mode																															
3. Select [Execute]. 4. Press the start key. AC calibration is executed. 5. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. * : When an error occurs, an error code is displayed.																																
Setting: [Magnification]																																
1. Select the item to be set. 2. Change the setting value using the +/- keys or numeric keys.																																
<table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>C</td> <td>When replacing the developer unit C or drum unit C</td> <td>-10 to 15</td> <td>15</td> </tr> <tr> <td>M</td> <td>When replacing the developer unit M or drum unit M</td> <td>-10 to 15</td> <td>15</td> </tr> <tr> <td>Y</td> <td>When replacing the developer unit Y or drum unit Y</td> <td>-10 to 15</td> <td>15</td> </tr> <tr> <td>K</td> <td>When replacing the developer unit K or drum unit K</td> <td>-10 to 1 5</td> <td>12</td> </tr> </tbody> </table>							Display	Description	Setting range	Initial setting	C	When replacing the developer unit C or drum unit C	-10 to 15	15	M	When replacing the developer unit M or drum unit M	-10 to 15	15	Y	When replacing the developer unit Y or drum unit Y	-10 to 15	15	K	When replacing the developer unit K or drum unit K	-10 to 1 5	12						
Display	Description	Setting range	Initial setting																													
C	When replacing the developer unit C or drum unit C	-10 to 15	15																													
M	When replacing the developer unit M or drum unit M	-10 to 15	15																													
Y	When replacing the developer unit Y or drum unit Y	-10 to 15	15																													
K	When replacing the developer unit K or drum unit K	-10 to 1 5	12																													
3. Press the start key. The value is set.																																

Item No.	Description																																		
U140	<p>Method: [High Altitude]</p> <p>1. Select Mode1 or Mode2. * : 45 ppm model/55 ppm model</p> <table border="1" data-bbox="336 353 1401 533"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Mode1</td> <td>Execute AC calibration by normal bias control</td> </tr> <tr> <td>Mode2</td> <td>If print density is low in an installation at high altitude, execute calibration by fixing the bias potential.</td> </tr> </tbody> </table> <p>Initial setting: Mode1</p> <p>2. Press the start key. The value is set. 3. Turn the main power switch off and on. Allow more than 5 seconds between Off and On.</p> <p>Method: [AC Calib] (30 ppm model/35 ppm model)</p> <p>1. Select the item.</p> <table border="1" data-bbox="336 757 1401 855"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>High Altitude</td> <td>Mode setting for AC calibration bias control</td> </tr> </tbody> </table> <p>Method: [High Altitude]</p> <p>1. Select mode.</p> <table border="1" data-bbox="336 976 1401 1267"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Default</td> <td>Initial setting</td> <td>3000m</td> <td>Settings equivalent to the altitude of 3000 m.</td> </tr> <tr> <td>1000m</td> <td>Settings equivalent to the altitude of 1000 m.</td> <td>4000m</td> <td>Settings equivalent to the altitude of 4000 m.</td> </tr> <tr> <td>2000m</td> <td>Settings equivalent to the altitude of 2000 m.</td> <td></td> <td></td> </tr> </tbody> </table> <p>2. Press the start key. The value is set.</p> <p>Method: [Image Preference]</p> <p>1. Select the Copy. 2. Change the value using the +/- or numeric keys.</p> <table border="1" data-bbox="336 1491 1401 1626"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Copy</td> <td>Setting toner density at copying</td> <td>-1 to +1</td> <td>0</td> </tr> </tbody> </table> <p>1: Low 0: Normal +1: Deep</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Mode1	Execute AC calibration by normal bias control	Mode2	If print density is low in an installation at high altitude, execute calibration by fixing the bias potential.	Display	Description	High Altitude	Mode setting for AC calibration bias control	Display	Description	Display	Description	Default	Initial setting	3000m	Settings equivalent to the altitude of 3000 m.	1000m	Settings equivalent to the altitude of 1000 m.	4000m	Settings equivalent to the altitude of 4000 m.	2000m	Settings equivalent to the altitude of 2000 m.			Display	Description	Setting range	Initial setting	Copy	Setting toner density at copying	-1 to +1	0
Display	Description																																		
Mode1	Execute AC calibration by normal bias control																																		
Mode2	If print density is low in an installation at high altitude, execute calibration by fixing the bias potential.																																		
Display	Description																																		
High Altitude	Mode setting for AC calibration bias control																																		
Display	Description	Display	Description																																
Default	Initial setting	3000m	Settings equivalent to the altitude of 3000 m.																																
1000m	Settings equivalent to the altitude of 1000 m.	4000m	Settings equivalent to the altitude of 4000 m.																																
2000m	Settings equivalent to the altitude of 2000 m.																																		
Display	Description	Setting range	Initial setting																																
Copy	Setting toner density at copying	-1 to +1	0																																

Item No.	Description																																
U147	<p data-bbox="288 241 746 275">Setting for toner applying operation</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1425 445">Sets the mode for removing charged toner in the developing unit (T7 control: Toner applying operation). Defines the action that the toner accumulated on the developer blade is sent back in the developer unit (done by the vibration motor).</p> <p data-bbox="288 450 400 479">Purpose</p> <p data-bbox="288 483 1370 546">The setting can be changed to reduce the toner applying quantity. Performed to change the occurrence of the control of the vibration motor.</p> <p data-bbox="288 551 1142 584">If the charged toner stays inside the developing unit, density decreases.</p> <p data-bbox="288 620 387 649">Method</p> <ol data-bbox="304 654 632 719" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 732 1401 974"> <thead> <tr> <th data-bbox="336 732 564 781">Display</th> <th data-bbox="564 732 1401 781">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 781 564 826">Mode</td> <td data-bbox="564 781 1401 826">Settings for toner applying operation</td> </tr> <tr> <td data-bbox="336 826 564 871">Upper Limit</td> <td data-bbox="564 826 1401 871">Upper limit printing ratio of toner applying quantity with each mode</td> </tr> <tr> <td data-bbox="336 871 564 916">Minimum</td> <td data-bbox="564 871 1401 916">Toner layer width when cleaning mode is selected</td> </tr> <tr> <td data-bbox="336 916 564 974">Interval Number</td> <td data-bbox="564 916 1401 974">Setting the vibration motor On timing</td> </tr> </tbody> </table> <p data-bbox="288 1016 488 1048">Setting: [Mode]</p> <ol data-bbox="304 1052 539 1081" style="list-style-type: none"> 1. Select the mode. <table border="1" data-bbox="336 1095 1401 1240"> <thead> <tr> <th data-bbox="336 1095 564 1144">Display</th> <th data-bbox="564 1095 1401 1144">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1144 564 1189">Mode0</td> <td data-bbox="564 1144 1401 1189">Less consumption of toner than a regular toner applying operation</td> </tr> <tr> <td data-bbox="336 1189 564 1240">Mode1</td> <td data-bbox="564 1189 1401 1240">Executes toner applying with the regular amount of toner</td> </tr> </tbody> </table> <p data-bbox="336 1252 580 1281">Initial setting; Mode1</p> <ol data-bbox="304 1285 782 1317" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1355 564 1386">Setting: [Upper Limit]</p> <ol data-bbox="304 1391 1054 1422" style="list-style-type: none"> 1. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 1435 1401 1599"> <thead> <tr> <th data-bbox="336 1435 520 1514">Display</th> <th data-bbox="520 1435 1066 1514">Description</th> <th data-bbox="1066 1435 1233 1514">Setting range</th> <th data-bbox="1233 1435 1401 1514">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1514 520 1599">Value</td> <td data-bbox="520 1514 1066 1599">Upper limit printing ratio of toner applying quantity with each mode (%)</td> <td data-bbox="1066 1514 1233 1599">0 to 2.0</td> <td data-bbox="1233 1514 1401 1599">2.0</td> </tr> </tbody> </table> <ol data-bbox="304 1608 767 1639" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1677 533 1709">Setting: [Minimum]</p> <ol data-bbox="304 1713 1054 1744" style="list-style-type: none"> 1. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 1758 1401 1921"> <thead> <tr> <th data-bbox="336 1758 520 1836">Display</th> <th data-bbox="520 1758 1066 1836">Description</th> <th data-bbox="1066 1758 1233 1836">Setting range</th> <th data-bbox="1233 1758 1401 1836">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1836 520 1921">Value</td> <td data-bbox="520 1836 1066 1921">Toner layer width when cleaning mode is selected (mm)</td> <td data-bbox="1066 1836 1233 1921">0 to 30</td> <td data-bbox="1233 1836 1401 1921">10</td> </tr> </tbody> </table> <ol data-bbox="304 1930 767 1962" style="list-style-type: none"> 2. Press the start key. The value is set. 	Display	Description	Mode	Settings for toner applying operation	Upper Limit	Upper limit printing ratio of toner applying quantity with each mode	Minimum	Toner layer width when cleaning mode is selected	Interval Number	Setting the vibration motor On timing	Display	Description	Mode0	Less consumption of toner than a regular toner applying operation	Mode1	Executes toner applying with the regular amount of toner	Display	Description	Setting range	Initial setting	Value	Upper limit printing ratio of toner applying quantity with each mode (%)	0 to 2.0	2.0	Display	Description	Setting range	Initial setting	Value	Toner layer width when cleaning mode is selected (mm)	0 to 30	10
Display	Description																																
Mode	Settings for toner applying operation																																
Upper Limit	Upper limit printing ratio of toner applying quantity with each mode																																
Minimum	Toner layer width when cleaning mode is selected																																
Interval Number	Setting the vibration motor On timing																																
Display	Description																																
Mode0	Less consumption of toner than a regular toner applying operation																																
Mode1	Executes toner applying with the regular amount of toner																																
Display	Description	Setting range	Initial setting																														
Value	Upper limit printing ratio of toner applying quantity with each mode (%)	0 to 2.0	2.0																														
Display	Description	Setting range	Initial setting																														
Value	Toner layer width when cleaning mode is selected (mm)	0 to 30	10																														

Item No.	Description																
U147	<p>Setting: [Interval Number]</p> <ol style="list-style-type: none"> Select the item to be set. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 353 1401 651"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Print(Normal)</td> <td>During continuous printing (Normal environment)</td> <td>10 to 500</td> <td>250</td> </tr> <tr> <td>Print(H/H)</td> <td>During continuous printing (High humidity environment)</td> <td>10 to 200</td> <td>100</td> </tr> <tr> <td>Print End</td> <td>Print completed</td> <td>10 to 100</td> <td>50</td> </tr> </tbody> </table> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Print(Normal)	During continuous printing (Normal environment)	10 to 500	250	Print(H/H)	During continuous printing (High humidity environment)	10 to 200	100	Print End	Print completed	10 to 100	50
Display	Description	Setting range	Initial setting														
Print(Normal)	During continuous printing (Normal environment)	10 to 500	250														
Print(H/H)	During continuous printing (High humidity environment)	10 to 200	100														
Print End	Print completed	10 to 100	50														
U148	<p>Setting drum refresh mode</p> <p>Description Selects the mode used in drum refreshing</p> <p>Purpose Change settings when drum refreshing is too frequently executed.</p> <p>Setting</p> <ol style="list-style-type: none"> Press the start key. Select the mode. <table border="1" data-bbox="336 1167 1401 1346"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Normal^{*1}</td> <td>Automatic drum refreshing setting</td> <td>0 to 3</td> <td>2</td> </tr> <tr> <td>Dew Condensation^{*2}</td> <td>Dew condensation drum refreshing setting</td> <td>0 to 3</td> <td>0</td> </tr> </tbody> </table> <p>* 1: 0: Off / 1: Short / 2: Standard / 3: Long * 2: 0:Mode0/ 1:Mode1/ 2:Mode2/ 3:Mode3 Larger the number, more the times of the refresh.</p> <ol style="list-style-type: none"> Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Normal ^{*1}	Automatic drum refreshing setting	0 to 3	2	Dew Condensation ^{*2}	Dew condensation drum refreshing setting	0 to 3	0				
Display	Description	Setting range	Initial setting														
Normal ^{*1}	Automatic drum refreshing setting	0 to 3	2														
Dew Condensation ^{*2}	Dew condensation drum refreshing setting	0 to 3	0														

Item No.	Description																														
U155	<p data-bbox="290 241 643 275">Checking sensors for toner</p> <p data-bbox="290 311 440 340">Description</p> <p data-bbox="290 344 754 374">Displays the toner sensor output value.</p> <p data-bbox="290 380 400 409">Purpose</p> <p data-bbox="290 414 1163 443">To check the output value for each color when any image problems occur.</p> <p data-bbox="290 486 387 515">Method</p> <ol data-bbox="308 519 678 584" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be display. <table border="1" data-bbox="336 598 1401 777"> <thead> <tr> <th data-bbox="336 598 639 642">Display</th> <th data-bbox="639 598 1401 642">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 642 639 687">Waste Toner</td> <td data-bbox="639 642 1401 687">Control voltage value of the waste toner sensor</td> </tr> <tr> <td data-bbox="336 687 639 777">Toner</td> <td data-bbox="639 687 1401 777">Control voltage value and replenishment level of toner sensor each color</td> </tr> </tbody> </table> <p data-bbox="290 817 579 846">Method: [Waste Toner]</p> <ol data-bbox="308 851 1029 880" style="list-style-type: none"> 1. Check the status of sensor. The current value is displayed. <table border="1" data-bbox="336 896 1401 1041"> <thead> <tr> <th data-bbox="336 896 639 940">Display</th> <th data-bbox="639 896 1401 940">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 940 639 985">Full</td> <td data-bbox="639 940 1401 985">Waste toner sensor 1 (WTS1)</td> </tr> <tr> <td data-bbox="336 985 639 1041">Near Full</td> <td data-bbox="639 985 1401 1041">Waste toner sensor 2 (WTS2)</td> </tr> </tbody> </table> <p data-bbox="290 1084 494 1113">Method: [Toner]</p> <ol data-bbox="308 1120 1029 1149" style="list-style-type: none"> 1. Check the status of sensor. The current value is displayed. <table border="1" data-bbox="336 1164 1401 1597"> <thead> <tr> <th data-bbox="336 1164 639 1209">Display</th> <th data-bbox="639 1164 1401 1209">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1209 639 1254">Sensor(C)</td> <td data-bbox="639 1209 1401 1254">Toner sensor C output value</td> </tr> <tr> <td data-bbox="336 1254 639 1299">Sensor(M)</td> <td data-bbox="639 1254 1401 1299">Toner sensor M output value</td> </tr> <tr> <td data-bbox="336 1299 639 1344">Sensor(Y)</td> <td data-bbox="639 1299 1401 1344">Toner sensor Y output value</td> </tr> <tr> <td data-bbox="336 1344 639 1388">Sensor(K)</td> <td data-bbox="639 1344 1401 1388">Toner sensor K output value</td> </tr> <tr> <td data-bbox="336 1388 639 1433">Supply(C)</td> <td data-bbox="639 1388 1401 1433">Toner replenishment level for cyan</td> </tr> <tr> <td data-bbox="336 1433 639 1478">Supply(M)</td> <td data-bbox="639 1433 1401 1478">Toner replenishment level for magenta</td> </tr> <tr> <td data-bbox="336 1478 639 1523">Supply(Y)</td> <td data-bbox="639 1478 1401 1523">Toner replenishment level for yellow</td> </tr> <tr> <td data-bbox="336 1523 639 1597">Supply(K)</td> <td data-bbox="639 1523 1401 1597">Toner replenishment level for black</td> </tr> </tbody> </table> <p data-bbox="290 1639 440 1668">Completion</p> <p data-bbox="290 1673 1256 1702">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Waste Toner	Control voltage value of the waste toner sensor	Toner	Control voltage value and replenishment level of toner sensor each color	Display	Description	Full	Waste toner sensor 1 (WTS1)	Near Full	Waste toner sensor 2 (WTS2)	Display	Description	Sensor(C)	Toner sensor C output value	Sensor(M)	Toner sensor M output value	Sensor(Y)	Toner sensor Y output value	Sensor(K)	Toner sensor K output value	Supply(C)	Toner replenishment level for cyan	Supply(M)	Toner replenishment level for magenta	Supply(Y)	Toner replenishment level for yellow	Supply(K)	Toner replenishment level for black
Display	Description																														
Waste Toner	Control voltage value of the waste toner sensor																														
Toner	Control voltage value and replenishment level of toner sensor each color																														
Display	Description																														
Full	Waste toner sensor 1 (WTS1)																														
Near Full	Waste toner sensor 2 (WTS2)																														
Display	Description																														
Sensor(C)	Toner sensor C output value																														
Sensor(M)	Toner sensor M output value																														
Sensor(Y)	Toner sensor Y output value																														
Sensor(K)	Toner sensor K output value																														
Supply(C)	Toner replenishment level for cyan																														
Supply(M)	Toner replenishment level for magenta																														
Supply(Y)	Toner replenishment level for yellow																														
Supply(K)	Toner replenishment level for black																														

Item No.	Description																																																						
U156	<p data-bbox="288 241 762 271">Setting the toner replenishment level</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 871 374">Sets the toner replenishment level for each color.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 895 443">To change settings according to the original image.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="304 517 632 582" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 595 1401 741"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1401 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">Supply</td> <td data-bbox="639 640 1401 685">Setting the toner replenishment level</td> </tr> <tr> <td data-bbox="336 685 639 741">Empty</td> <td data-bbox="639 685 1401 741">Setting the toner empty level</td> </tr> </tbody> </table> <p data-bbox="288 786 512 815">Method: [Supply]</p> <ol data-bbox="304 819 1350 920" style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the +/- or numeric keys. Increasing the setting makes the image lighter; decreasing it makes the image darker. <table border="1" data-bbox="336 934 1401 1249"> <thead> <tr> <th data-bbox="336 934 528 1001">Display</th> <th data-bbox="528 934 1094 1001">Description</th> <th data-bbox="1094 934 1246 1001">Setting range</th> <th data-bbox="1246 934 1401 1001">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1001 528 1046">C</td> <td data-bbox="528 1001 1094 1046">Toner replenishment level for cyan</td> <td data-bbox="1094 1001 1246 1046">0 to 900</td> <td data-bbox="1246 1001 1401 1046">512</td> </tr> <tr> <td data-bbox="336 1046 528 1090">M</td> <td data-bbox="528 1046 1094 1090">Toner replenishment level for magenta</td> <td data-bbox="1094 1046 1246 1090">0 to 900</td> <td data-bbox="1246 1046 1401 1090">512</td> </tr> <tr> <td data-bbox="336 1090 528 1135">Y</td> <td data-bbox="528 1090 1094 1135">Toner replenishment level for yellow</td> <td data-bbox="1094 1090 1246 1135">0 to 900</td> <td data-bbox="1246 1090 1401 1135">512</td> </tr> <tr> <td data-bbox="336 1135 528 1180">K</td> <td data-bbox="528 1135 1094 1180">Toner replenishment level for black</td> <td data-bbox="1094 1135 1246 1180">0 to 900</td> <td data-bbox="1246 1135 1401 1180">512</td> </tr> <tr> <td data-bbox="336 1180 528 1249">B/W*</td> <td data-bbox="528 1180 1094 1249">Toner replenishment level in black/white mode</td> <td data-bbox="1094 1180 1246 1249">0 to 900</td> <td data-bbox="1246 1180 1401 1249">512</td> </tr> </tbody> </table> <p data-bbox="336 1261 592 1290">*: 55 ppm model only.</p> <ol data-bbox="304 1294 767 1323" style="list-style-type: none"> 3. Press the start key. The value is set. <p data-bbox="288 1364 504 1393">Method: [Empty]</p> <ol data-bbox="304 1397 1366 1532" style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the +/- or numeric keys. Increasing the setting makes 'toner empty' appear later and decreasing it makes 'toner empty' appear earlier. <table border="1" data-bbox="336 1545 1401 1861"> <thead> <tr> <th data-bbox="336 1545 528 1612">Display</th> <th data-bbox="528 1545 1094 1612">Description</th> <th data-bbox="1094 1545 1246 1612">Setting range</th> <th data-bbox="1246 1545 1401 1612">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1612 528 1657">C</td> <td data-bbox="528 1612 1094 1657">Toner empty level for cyan</td> <td data-bbox="1094 1612 1246 1657">0 to 1023</td> <td data-bbox="1246 1612 1401 1657">100</td> </tr> <tr> <td data-bbox="336 1657 528 1702">M</td> <td data-bbox="528 1657 1094 1702">Toner empty level for magenta</td> <td data-bbox="1094 1657 1246 1702">0 to 1023</td> <td data-bbox="1246 1657 1401 1702">100</td> </tr> <tr> <td data-bbox="336 1702 528 1747">Y</td> <td data-bbox="528 1702 1094 1747">Toner empty level for yellow</td> <td data-bbox="1094 1702 1246 1747">0 to 1023</td> <td data-bbox="1246 1702 1401 1747">100</td> </tr> <tr> <td data-bbox="336 1747 528 1792">K</td> <td data-bbox="528 1747 1094 1792">Toner empty level for black</td> <td data-bbox="1094 1747 1246 1792">0 to 1023</td> <td data-bbox="1246 1747 1401 1792">100</td> </tr> <tr> <td data-bbox="336 1792 528 1861">B/W*</td> <td data-bbox="528 1792 1094 1861">Toner empty level in black/white mode</td> <td data-bbox="1094 1792 1246 1861">0 to 1023</td> <td data-bbox="1246 1792 1401 1861">100</td> </tr> </tbody> </table> <p data-bbox="336 1872 592 1901">*: 55 ppm model only.</p> <ol data-bbox="304 1906 767 1935" style="list-style-type: none"> 3. Press the start key. The value is set. <p data-bbox="288 1975 440 2004">Completion</p> <p data-bbox="288 2009 1254 2038">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Supply	Setting the toner replenishment level	Empty	Setting the toner empty level	Display	Description	Setting range	Initial setting	C	Toner replenishment level for cyan	0 to 900	512	M	Toner replenishment level for magenta	0 to 900	512	Y	Toner replenishment level for yellow	0 to 900	512	K	Toner replenishment level for black	0 to 900	512	B/W*	Toner replenishment level in black/white mode	0 to 900	512	Display	Description	Setting range	Initial setting	C	Toner empty level for cyan	0 to 1023	100	M	Toner empty level for magenta	0 to 1023	100	Y	Toner empty level for yellow	0 to 1023	100	K	Toner empty level for black	0 to 1023	100	B/W*	Toner empty level in black/white mode	0 to 1023	100
Display	Description																																																						
Supply	Setting the toner replenishment level																																																						
Empty	Setting the toner empty level																																																						
Display	Description	Setting range	Initial setting																																																				
C	Toner replenishment level for cyan	0 to 900	512																																																				
M	Toner replenishment level for magenta	0 to 900	512																																																				
Y	Toner replenishment level for yellow	0 to 900	512																																																				
K	Toner replenishment level for black	0 to 900	512																																																				
B/W*	Toner replenishment level in black/white mode	0 to 900	512																																																				
Display	Description	Setting range	Initial setting																																																				
C	Toner empty level for cyan	0 to 1023	100																																																				
M	Toner empty level for magenta	0 to 1023	100																																																				
Y	Toner empty level for yellow	0 to 1023	100																																																				
K	Toner empty level for black	0 to 1023	100																																																				
B/W*	Toner empty level in black/white mode	0 to 1023	100																																																				

Item No.	Description										
U157	<p>Checking the developer drive time</p> <p>Description Displays the developer drive time for checking a figure, which is used as a reference when correcting the toner control.</p> <p>Purpose To check the developer drive time after replacing the developer unit.</p> <p>Method 1. Press the start key. The developer drive time is displayed.</p> <table border="1" data-bbox="336 595 1401 837"> <thead> <tr> <th data-bbox="336 595 639 645">Display</th> <th data-bbox="639 595 1401 645">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 645 639 689">C</td> <td data-bbox="639 645 1401 689">Developer drive time for cyan</td> </tr> <tr> <td data-bbox="336 689 639 734">M</td> <td data-bbox="639 689 1401 734">Developer drive time for magenta</td> </tr> <tr> <td data-bbox="336 734 639 779">Y</td> <td data-bbox="639 734 1401 779">Developer drive time for yellow</td> </tr> <tr> <td data-bbox="336 779 639 837">K</td> <td data-bbox="639 779 1401 837">Developer drive time for black</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	C	Developer drive time for cyan	M	Developer drive time for magenta	Y	Developer drive time for yellow	K	Developer drive time for black
Display	Description										
C	Developer drive time for cyan										
M	Developer drive time for magenta										
Y	Developer drive time for yellow										
K	Developer drive time for black										
U158	<p>Checking the developer count</p> <p>Description Displays the developer count for checking.</p> <p>Purpose To check the developer unit status.</p> <p>Method 1. Press the start key. The current developer counts is displayed.</p> <table border="1" data-bbox="336 1285 1401 1527"> <thead> <tr> <th data-bbox="336 1285 639 1335">Display</th> <th data-bbox="639 1285 1401 1335">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1335 639 1379">C</td> <td data-bbox="639 1335 1401 1379">Developer count value for cyan</td> </tr> <tr> <td data-bbox="336 1379 639 1424">M</td> <td data-bbox="639 1379 1401 1424">Developer count value for magenta</td> </tr> <tr> <td data-bbox="336 1424 639 1469">Y</td> <td data-bbox="639 1424 1401 1469">Developer count value for yellow</td> </tr> <tr> <td data-bbox="336 1469 639 1527">K</td> <td data-bbox="639 1469 1401 1527">Developer count value for black</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	C	Developer count value for cyan	M	Developer count value for magenta	Y	Developer count value for yellow	K	Developer count value for black
Display	Description										
C	Developer count value for cyan										
M	Developer count value for magenta										
Y	Developer count value for yellow										
K	Developer count value for black										

Item No.	Description																																																																													
U161	<p data-bbox="290 241 766 273">Setting the fuser control temperature</p> <p data-bbox="290 311 440 342">Description</p> <p data-bbox="290 344 758 376">Changes the fuser control temperature.</p> <p data-bbox="290 380 400 412">Purpose</p> <p data-bbox="290 414 1425 479">Normally no change is necessary. However, can be used to prevent curling or creasing of paper, or solve a fuser problem on thick paper.</p> <p data-bbox="290 517 387 548">Method</p> <ol data-bbox="306 553 632 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 631 1399 871"> <thead> <tr> <th data-bbox="336 631 641 676">Display</th> <th data-bbox="641 631 1399 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 676 641 721">Warm Up</td> <td data-bbox="641 676 1399 721">Control temperature except at printing</td> </tr> <tr> <td data-bbox="336 721 641 766">Print</td> <td data-bbox="641 721 1399 766">Control temperature during printing</td> </tr> <tr> <td data-bbox="336 766 641 810">Low Power Mode*</td> <td data-bbox="641 766 1399 810">Heating power reduction control</td> </tr> <tr> <td data-bbox="336 810 641 855">Grain Mode</td> <td data-bbox="641 810 1399 855">Control for the impalpable unevenness in glossiness</td> </tr> </tbody> </table> <p data-bbox="336 891 632 922">*: 45/55 ppm model only.</p> <p data-bbox="290 960 533 992">Setting: [Warm Up]</p> <ol data-bbox="306 996 858 1061" style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the +/- keys. <table border="1" data-bbox="336 1075 1399 1865"> <thead> <tr> <th data-bbox="336 1075 512 1164" rowspan="2">Display</th> <th data-bbox="512 1075 852 1164" rowspan="2">Description</th> <th data-bbox="852 1075 1002 1164" rowspan="2">Setting range</th> <th colspan="4" data-bbox="1002 1075 1399 1115">Initial setting</th> </tr> <tr> <th data-bbox="1002 1115 1102 1164">30ppm</th> <th data-bbox="1102 1115 1203 1164">35ppm</th> <th data-bbox="1203 1115 1303 1164">45ppm</th> <th data-bbox="1303 1115 1399 1164">55ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1164 512 1252">Ready (Center)</td> <td data-bbox="512 1164 852 1252">Control temperature at displaying Ready (Center)</td> <td data-bbox="852 1164 1002 1252">130 to 200 (°C)</td> <td data-bbox="1002 1164 1102 1252">155</td> <td data-bbox="1102 1164 1203 1252">160</td> <td data-bbox="1203 1164 1303 1252">165</td> <td data-bbox="1303 1164 1399 1252">170</td> </tr> <tr> <td data-bbox="336 1252 512 1339">Ready (Edge)</td> <td data-bbox="512 1252 852 1339">Control temperature at displaying Ready (Edge)</td> <td data-bbox="852 1252 1002 1339">100 to 200 (°C)</td> <td data-bbox="1002 1252 1102 1339">110</td> <td data-bbox="1102 1252 1203 1339">110</td> <td data-bbox="1203 1252 1303 1339">140</td> <td data-bbox="1303 1252 1399 1339">145</td> </tr> <tr> <td data-bbox="336 1339 512 1426">Ready (Press)</td> <td data-bbox="512 1339 852 1426">Control temperature at displaying Ready (Press)</td> <td data-bbox="852 1339 1002 1426">0 to 200 (°C)</td> <td data-bbox="1002 1339 1102 1426">40</td> <td data-bbox="1102 1339 1203 1426">40</td> <td data-bbox="1203 1339 1303 1426">80</td> <td data-bbox="1303 1339 1399 1426">80</td> </tr> <tr> <td data-bbox="336 1426 512 1514">Drive (Center)</td> <td data-bbox="512 1426 852 1514">Stable temperature during driving (Center)</td> <td data-bbox="852 1426 1002 1514">130 to 200 (°C)</td> <td data-bbox="1002 1426 1102 1514">165</td> <td data-bbox="1102 1426 1203 1514">170</td> <td data-bbox="1203 1426 1303 1514">170</td> <td data-bbox="1303 1426 1399 1514">175</td> </tr> <tr> <td data-bbox="336 1514 512 1601">Wait (Center)</td> <td data-bbox="512 1514 852 1601">Stable temperature during halt (Center)</td> <td data-bbox="852 1514 1002 1601">130 to 200 (°C)</td> <td data-bbox="1002 1514 1102 1601">155</td> <td data-bbox="1102 1514 1203 1601">165</td> <td data-bbox="1203 1514 1303 1601">165</td> <td data-bbox="1303 1514 1399 1601">175</td> </tr> <tr> <td data-bbox="336 1601 512 1688">Low Power (Press)</td> <td data-bbox="512 1601 852 1688">Control temperature at low power consumption (Press)</td> <td data-bbox="852 1601 1002 1688">0 to 200 (°C)</td> <td data-bbox="1002 1601 1102 1688">150</td> <td data-bbox="1102 1601 1203 1688">150</td> <td data-bbox="1203 1601 1303 1688">150</td> <td data-bbox="1303 1601 1399 1688">150</td> </tr> <tr> <td data-bbox="336 1688 512 1776">Full Speed Shift(Center)</td> <td data-bbox="512 1688 852 1776">Full speed shift temperature (Center)</td> <td data-bbox="852 1688 1002 1776">0 to 200 (°C)</td> <td data-bbox="1002 1688 1102 1776">50</td> <td data-bbox="1102 1688 1203 1776">50</td> <td data-bbox="1203 1688 1303 1776">50</td> <td data-bbox="1303 1688 1399 1776">50</td> </tr> <tr> <td data-bbox="336 1776 512 1865">Pressure (Press)</td> <td data-bbox="512 1776 852 1865">Pressurizing beginning temperature (Press)</td> <td data-bbox="852 1776 1002 1865">0 to 200 (°C)</td> <td data-bbox="1002 1776 1102 1865">120</td> <td data-bbox="1102 1776 1203 1865">120</td> <td data-bbox="1203 1776 1303 1865">155</td> <td data-bbox="1303 1776 1399 1865">160</td> </tr> </tbody> </table> <ol data-bbox="306 1874 766 1906" style="list-style-type: none"> 3. Press the start key. The value is set. 	Display	Description	Warm Up	Control temperature except at printing	Print	Control temperature during printing	Low Power Mode*	Heating power reduction control	Grain Mode	Control for the impalpable unevenness in glossiness	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Ready (Center)	Control temperature at displaying Ready (Center)	130 to 200 (°C)	155	160	165	170	Ready (Edge)	Control temperature at displaying Ready (Edge)	100 to 200 (°C)	110	110	140	145	Ready (Press)	Control temperature at displaying Ready (Press)	0 to 200 (°C)	40	40	80	80	Drive (Center)	Stable temperature during driving (Center)	130 to 200 (°C)	165	170	170	175	Wait (Center)	Stable temperature during halt (Center)	130 to 200 (°C)	155	165	165	175	Low Power (Press)	Control temperature at low power consumption (Press)	0 to 200 (°C)	150	150	150	150	Full Speed Shift(Center)	Full speed shift temperature (Center)	0 to 200 (°C)	50	50	50	50	Pressure (Press)	Pressurizing beginning temperature (Press)	0 to 200 (°C)	120	120	155	160
Display	Description																																																																													
Warm Up	Control temperature except at printing																																																																													
Print	Control temperature during printing																																																																													
Low Power Mode*	Heating power reduction control																																																																													
Grain Mode	Control for the impalpable unevenness in glossiness																																																																													
Display	Description	Setting range	Initial setting																																																																											
			30ppm	35ppm	45ppm	55ppm																																																																								
Ready (Center)	Control temperature at displaying Ready (Center)	130 to 200 (°C)	155	160	165	170																																																																								
Ready (Edge)	Control temperature at displaying Ready (Edge)	100 to 200 (°C)	110	110	140	145																																																																								
Ready (Press)	Control temperature at displaying Ready (Press)	0 to 200 (°C)	40	40	80	80																																																																								
Drive (Center)	Stable temperature during driving (Center)	130 to 200 (°C)	165	170	170	175																																																																								
Wait (Center)	Stable temperature during halt (Center)	130 to 200 (°C)	155	165	165	175																																																																								
Low Power (Press)	Control temperature at low power consumption (Press)	0 to 200 (°C)	150	150	150	150																																																																								
Full Speed Shift(Center)	Full speed shift temperature (Center)	0 to 200 (°C)	50	50	50	50																																																																								
Pressure (Press)	Pressurizing beginning temperature (Press)	0 to 200 (°C)	120	120	155	160																																																																								

Item No.	Description																																									
U161	<p>Setting: [Print]</p> <ol style="list-style-type: none"> Select the item to be set. Change the setting value using the +/- keys. <table border="1" data-bbox="336 353 1401 616"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="4">Initial setting</th> </tr> <tr> <th>30ppm</th> <th>35ppm</th> <th>45ppm</th> <th>55ppm</th> </tr> </thead> <tbody> <tr> <td>Full Speed Print(Center)</td> <td>Temperature at maximum print speed (Center)</td> <td>130 to 200 (°C)</td> <td>165</td> <td>170</td> <td>170</td> <td>175</td> </tr> <tr> <td>Duplex Shift (Center)</td> <td>Temperature at duplex printing (Center)</td> <td>-20 to 20 (°C)</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Setting: [Low Power Mode]</p> <ol style="list-style-type: none"> Select the item to be set. <table border="1" data-bbox="336 772 1401 992"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Mode0</td> <td>Present state control mode (Usually not used)</td> </tr> <tr> <td>Mode1</td> <td>Fuser control temperature reduction mode (For normal users)</td> </tr> <tr> <td>Mode2</td> <td>Large volume output mode (For users who repeatedly print approximately 1500 sheets at a time)</td> </tr> </tbody> </table> <p>Initial setting: Mode1</p> <ol style="list-style-type: none"> Press the start key. The setting is set. <p>Setting: [Grain Mode]</p> <ol style="list-style-type: none"> Select the item to be set. <table border="1" data-bbox="336 1193 1401 1413"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Mode0</td> <td>Current level. Special control is not performed</td> </tr> <tr> <td>Mode1</td> <td>Improvement mode for the impalpable unevenness in glossiness</td> </tr> <tr> <td>Mode2</td> <td>More improvement</td> </tr> </tbody> </table> <p>Initial setting: Mode0</p> <ol style="list-style-type: none"> Press the start key. The setting is set. <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Full Speed Print(Center)	Temperature at maximum print speed (Center)	130 to 200 (°C)	165	170	170	175	Duplex Shift (Center)	Temperature at duplex printing (Center)	-20 to 20 (°C)	0	0	0	0	Display	Description	Mode0	Present state control mode (Usually not used)	Mode1	Fuser control temperature reduction mode (For normal users)	Mode2	Large volume output mode (For users who repeatedly print approximately 1500 sheets at a time)	Display	Description	Mode0	Current level. Special control is not performed	Mode1	Improvement mode for the impalpable unevenness in glossiness	Mode2	More improvement
Display	Description				Setting range	Initial setting																																				
		30ppm	35ppm	45ppm		55ppm																																				
Full Speed Print(Center)	Temperature at maximum print speed (Center)	130 to 200 (°C)	165	170	170	175																																				
Duplex Shift (Center)	Temperature at duplex printing (Center)	-20 to 20 (°C)	0	0	0	0																																				
Display	Description																																									
Mode0	Present state control mode (Usually not used)																																									
Mode1	Fuser control temperature reduction mode (For normal users)																																									
Mode2	Large volume output mode (For users who repeatedly print approximately 1500 sheets at a time)																																									
Display	Description																																									
Mode0	Current level. Special control is not performed																																									
Mode1	Improvement mode for the impalpable unevenness in glossiness																																									
Mode2	More improvement																																									
U163	<p>Resetting the fuser problem data</p> <p>Description Resets the detection of a service call code indicating a problem in the fuser section.</p> <p>Purpose To prevent accidents due to an abnormally high fuser temperature.</p>																																									

Item No.	Description								
U163	<p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press [Execute]. 3. Press the start key. The fuser problem data is initialized. 4. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. 								
U167	<p>Checking/clearing the fuser count</p> <p>Description Displays and clears the fuser count for checking.</p> <p>Purpose To check the fuser count or drive time after replacement of the fuser unit. Also to clear the counts after replacing unit.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The fuser count is displayed. <table border="1" data-bbox="336 786 1401 976"> <thead> <tr> <th data-bbox="336 786 639 831">Display</th> <th data-bbox="639 786 1401 831">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 831 639 875">Cnt</td> <td data-bbox="639 831 1401 875">Fuser unit count value</td> </tr> <tr> <td data-bbox="336 875 639 920">Release(Time)</td> <td data-bbox="639 875 1401 920">Fuser unit drive time (release)</td> </tr> <tr> <td data-bbox="336 920 639 965">Press(Time)</td> <td data-bbox="639 920 1401 965">Fuser unit drive time (press)</td> </tr> </tbody> </table> <p>Clearing</p> <ol style="list-style-type: none"> 1. Press [Clear]. 2. Press the start key. The count is cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Cnt	Fuser unit count value	Release(Time)	Fuser unit drive time (release)	Press(Time)	Fuser unit drive time (press)
Display	Description								
Cnt	Fuser unit count value								
Release(Time)	Fuser unit drive time (release)								
Press(Time)	Fuser unit drive time (press)								
U169	<p>Checking/setting the fuser power source</p> <p>Description Displays and settings the reference voltage of the fuser IH PWB.</p> <p>Purpose To check the reference voltage. * : When U021 is being executed, set the same voltage with the voltage of the IH control PWB.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the mode. <table border="1" data-bbox="336 1666 1401 1762"> <thead> <tr> <th data-bbox="336 1666 564 1711">Display</th> <th data-bbox="564 1666 1171 1711">Description</th> <th data-bbox="1171 1666 1401 1711">Setting range</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1711 564 1762">Mode</td> <td data-bbox="564 1711 1171 1762">Reference voltage</td> <td data-bbox="1171 1711 1401 1762">1 to 4</td> </tr> </tbody> </table> <p>1: 100 V specifications 2: 200 V specifications 3: 120 V specifications 4: 110 V specifications</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Mode	Reference voltage	1 to 4		
Display	Description	Setting range							
Mode	Reference voltage	1 to 4							

Item No.	Description										
U199	<p>Displaying fuser heater temperature</p> <p>Description Displays the detected fuser temperature.</p> <p>Purpose To check the fuser temperature.</p> <p>Method 1. Press the start key. The fuser temperature is displayed.</p> <table border="1" data-bbox="336 562 1401 801"> <thead> <tr> <th data-bbox="336 562 641 607">Display</th> <th data-bbox="641 562 1401 607">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 607 641 651">Heat Roller Edge1</td> <td data-bbox="641 607 1401 651">Heat roller edge temperature (°C)</td> </tr> <tr> <td data-bbox="336 651 641 696">Heat Roller Edge2</td> <td data-bbox="641 651 1401 696">Heat roller edge temperature (°C)</td> </tr> <tr> <td data-bbox="336 696 641 741">Heat Roller Center</td> <td data-bbox="641 696 1401 741">Heat roller center temperature (°C)</td> </tr> <tr> <td data-bbox="336 741 641 786">Press Roller Center</td> <td data-bbox="641 741 1401 786">Press roller center temperature (°C)</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance mode No. is displayed.</p>	Display	Description	Heat Roller Edge1	Heat roller edge temperature (°C)	Heat Roller Edge2	Heat roller edge temperature (°C)	Heat Roller Center	Heat roller center temperature (°C)	Press Roller Center	Press roller center temperature (°C)
Display	Description										
Heat Roller Edge1	Heat roller edge temperature (°C)										
Heat Roller Edge2	Heat roller edge temperature (°C)										
Heat Roller Center	Heat roller center temperature (°C)										
Press Roller Center	Press roller center temperature (°C)										
U200	<p>Turning all LEDs on</p> <p>Description Turns all the LEDs on the operation panel on.</p> <p>Purpose To check if all the LEDs on the operation panel light.</p> <p>Method 1. Press the start key. 2. Select [Execute]. 3. Press the start key. All the LEDs on the operation panel light. 4. Press the stop key. The LEDs turns off.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>										

Item No.	Description						
U201	<p data-bbox="288 241 628 271">Initializing the touch panel</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1174 374">Automatically correct the positions of the X- and Y-axes of the touch panel.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1273 443">To automatically correct the display positions on the touch panel after it is replaced.</p> <p data-bbox="288 486 387 515">Method</p> <ol data-bbox="308 519 711 584" style="list-style-type: none"> <li data-bbox="308 519 564 548">1. Press the start key. <li data-bbox="308 553 711 584">2. Select the [Initialize] or [Check]. <table border="1" data-bbox="336 598 1399 741"> <thead> <tr> <th data-bbox="336 598 641 642">Display</th> <th data-bbox="641 598 1399 642">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 642 641 687">Initialize</td> <td data-bbox="641 642 1399 687">Adjusts the display on the panel automatically</td> </tr> <tr> <td data-bbox="336 687 641 741">Check</td> <td data-bbox="641 687 1399 741">Checks the display on the touch panel</td> </tr> </tbody> </table> <p data-bbox="288 786 528 815">Method: [Initialize]</p> <ol data-bbox="308 819 1278 987" style="list-style-type: none"> <li data-bbox="308 819 564 848">1. Press the start key. <li data-bbox="308 853 1278 918">2. Press the center of the + keys. Be sure to press three + keys displayed in order. The touch panel is adjusted automatically. <li data-bbox="308 922 1054 952">3. Press the indicated three + keys, and then check the display. <li data-bbox="308 956 564 987">4. Press the stop key. <p data-bbox="288 1028 501 1057">Method: [Check]</p> <ol data-bbox="308 1061 1337 1196" style="list-style-type: none"> <li data-bbox="308 1061 564 1090">1. Press the start key. <li data-bbox="308 1095 1337 1160">2. Press the indicated three + keys, and then check the display. When adjusting the display, press [Initialize] to execute the adjustment automatically. <li data-bbox="308 1164 564 1196">3. Press the stop key. <p data-bbox="288 1236 440 1265">Completion</p> <p data-bbox="288 1270 1254 1299">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Initialize	Adjusts the display on the panel automatically	Check	Checks the display on the touch panel
Display	Description						
Initialize	Adjusts the display on the panel automatically						
Check	Checks the display on the touch panel						

Item No.	Description																					
U202	<p data-bbox="288 241 826 275">Setting the KMAS host monitoring system</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 962 374">Initializes or operates the KMAS host monitoring system.</p> <p data-bbox="288 378 1425 445">This is an optional device which is currently supported only by Japanese specification machines, so no setting is necessary.</p> <p data-bbox="288 450 400 479">Purpose</p> <p data-bbox="288 483 1019 512">Performed at installation, periodic maintenance, and/or repair.</p> <p data-bbox="288 553 387 582">Method</p> <ol data-bbox="304 586 564 651" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 665 1399 808"> <thead> <tr> <th data-bbox="336 665 639 710">Display</th> <th data-bbox="639 665 1399 710">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 710 639 754">Init/Set TEL No.</td> <td data-bbox="639 710 1399 754">Initialization/Phone Nbr. se</td> </tr> <tr> <td data-bbox="336 754 639 808">Call Service End</td> <td data-bbox="639 754 1399 808">Outgoing at the end of service activities</td> </tr> </tbody> </table> <p data-bbox="288 853 619 882">Method: [Init/Set TEL No.]</p> <ol data-bbox="304 887 654 916" style="list-style-type: none"> 1. Select the item to be input. <table border="1" data-bbox="336 929 1399 1072"> <thead> <tr> <th data-bbox="336 929 639 974">Display</th> <th data-bbox="639 929 1399 974">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 974 639 1019">TEL No. 1</td> <td data-bbox="639 974 1399 1019">Sales companies</td> </tr> <tr> <td data-bbox="336 1019 639 1072">TEL No. 2</td> <td data-bbox="639 1019 1399 1072">Call center</td> </tr> </tbody> </table> <ol data-bbox="304 1086 1129 1290" style="list-style-type: none"> 2. Input the telephone number using the numeric keys. 3. Press the start key. The setting is set. 4. Select [Initialize]. 5. Select [Execute]. 6. Press the start key. Communication with the host initiated. 7. The result of communication will be displayed. (Refer to the result.) <p data-bbox="288 1328 632 1357">Method: [Call Service End]</p> <ol data-bbox="304 1361 1129 1462" style="list-style-type: none"> 1. Select [Execute]. 2. Press the start key. Communication with the host initiated. 3. The result of communication will be displayed. (Refer to the result.) <p data-bbox="336 1500 488 1529">Result table</p> <table border="1" data-bbox="336 1543 1399 1879"> <thead> <tr> <th data-bbox="336 1543 639 1588">Display</th> <th data-bbox="639 1543 1399 1588">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1588 639 1641">OK</td> <td data-bbox="639 1588 1399 1641">Communication properly terminated.</td> </tr> <tr> <td data-bbox="336 1641 639 1879" rowspan="4">NG</td> <td data-bbox="639 1641 1399 1686">Communication error (Nbr. of calls exceeded)</td> </tr> <tr> <td data-bbox="639 1686 1399 1731">Communication error (Communication timeout)</td> </tr> <tr> <td data-bbox="639 1731 1399 1776">Communication error (Communication trial timeout)</td> </tr> <tr> <td data-bbox="639 1776 1399 1879">Communication error (Other) KMAS unreachable</td> </tr> </tbody> </table> <p data-bbox="288 1926 440 1955">Completion</p> <p data-bbox="288 1960 1254 1989">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Init/Set TEL No.	Initialization/Phone Nbr. se	Call Service End	Outgoing at the end of service activities	Display	Description	TEL No. 1	Sales companies	TEL No. 2	Call center	Display	Description	OK	Communication properly terminated.	NG	Communication error (Nbr. of calls exceeded)	Communication error (Communication timeout)	Communication error (Communication trial timeout)	Communication error (Other) KMAS unreachable
Display	Description																					
Init/Set TEL No.	Initialization/Phone Nbr. se																					
Call Service End	Outgoing at the end of service activities																					
Display	Description																					
TEL No. 1	Sales companies																					
TEL No. 2	Call center																					
Display	Description																					
OK	Communication properly terminated.																					
NG	Communication error (Nbr. of calls exceeded)																					
	Communication error (Communication timeout)																					
	Communication error (Communication trial timeout)																					
	Communication error (Other) KMAS unreachable																					

Item No.	Description																				
U203	<p data-bbox="288 241 587 271">Checking DP operation</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1046 374">Simulates the original conveying operation separately in the DP.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 612 443">To check the DP operation.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="304 517 1083 618" style="list-style-type: none"> 1. Press the start key. 2. Place an original in the DP if running this simulation with paper. 3. Select the speed to be operated. <table border="1" data-bbox="336 629 1399 775"> <thead> <tr> <th data-bbox="336 629 639 674">Display</th> <th data-bbox="639 629 1399 674">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 674 639 719">Normal Speed</td> <td data-bbox="639 674 1399 719">Normal reading (600 dpi)</td> </tr> <tr> <td data-bbox="336 719 639 775">High Speed</td> <td data-bbox="639 719 1399 775">High-speed reading</td> </tr> </tbody> </table> <ol data-bbox="304 786 702 815" style="list-style-type: none"> 4. Select the item to be operated. <table border="1" data-bbox="336 826 1399 1267"> <thead> <tr> <th data-bbox="336 826 639 871">Display</th> <th data-bbox="639 826 1399 871">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 871 639 916">CCD ADP</td> <td data-bbox="639 871 1399 916">With paper, single-sided original of CCD</td> </tr> <tr> <td data-bbox="336 916 639 960">CCD RADP</td> <td data-bbox="639 916 1399 960">With paper, double-sided original of CCD</td> </tr> <tr> <td data-bbox="336 960 639 1005">CIS</td> <td data-bbox="639 960 1399 1005">With paper, double-sided original of CIS</td> </tr> <tr> <td data-bbox="336 1005 639 1095">CCD ADP (Non-P)</td> <td data-bbox="639 1005 1399 1095">Without paper, single-sided original of CCD (continuous operation)</td> </tr> <tr> <td data-bbox="336 1095 639 1184">CCD RADP (Non-P)</td> <td data-bbox="639 1095 1399 1184">Without paper, double-sided original of CCD (continuous operation)</td> </tr> <tr> <td data-bbox="336 1184 639 1267">CIS (Non-P)</td> <td data-bbox="639 1184 1399 1267">Without paper, double-sided original of CIS (continuous operation)</td> </tr> </tbody> </table> <ol data-bbox="304 1279 917 1346" style="list-style-type: none"> 5. Press the start key. The operation starts. 6. To stop continuous operation, press the stop key. <p data-bbox="288 1379 440 1408">Completion</p> <p data-bbox="288 1413 1254 1442">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Normal Speed	Normal reading (600 dpi)	High Speed	High-speed reading	Display	Description	CCD ADP	With paper, single-sided original of CCD	CCD RADP	With paper, double-sided original of CCD	CIS	With paper, double-sided original of CIS	CCD ADP (Non-P)	Without paper, single-sided original of CCD (continuous operation)	CCD RADP (Non-P)	Without paper, double-sided original of CCD (continuous operation)	CIS (Non-P)	Without paper, double-sided original of CIS (continuous operation)
Display	Description																				
Normal Speed	Normal reading (600 dpi)																				
High Speed	High-speed reading																				
Display	Description																				
CCD ADP	With paper, single-sided original of CCD																				
CCD RADP	With paper, double-sided original of CCD																				
CIS	With paper, double-sided original of CIS																				
CCD ADP (Non-P)	Without paper, single-sided original of CCD (continuous operation)																				
CCD RADP (Non-P)	Without paper, double-sided original of CCD (continuous operation)																				
CIS (Non-P)	Without paper, double-sided original of CIS (continuous operation)																				

Item No.	Description														
U204	<p data-bbox="287 241 1069 275">Setting the presence or absence of a key card or key counter</p> <p data-bbox="287 309 438 342">Description</p> <p data-bbox="287 344 1114 378">Sets the presence or absence of the optional key card or key counter.</p> <p data-bbox="287 380 399 414">Purpose</p> <p data-bbox="287 416 1101 450">To run this maintenance item if a key card or key counter is installed.</p> <p data-bbox="287 483 391 517">Method</p> <ol data-bbox="303 519 630 586" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="335 598 1401 741"> <thead> <tr> <th data-bbox="343 609 641 642">Display</th> <th data-bbox="641 609 1393 642">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 645 641 678">Device</td> <td data-bbox="641 645 1393 678">Sets the presence or absence of the key card or key counter</td> </tr> <tr> <td data-bbox="343 680 641 714">Message</td> <td data-bbox="641 680 1393 714">Sets the message when optional equipment is not installed</td> </tr> </tbody> </table> <p data-bbox="287 786 502 819">Setting: [Device]</p> <ol data-bbox="303 822 837 855" style="list-style-type: none"> 1. Select the optional counter to be installed. <table border="1" data-bbox="335 866 1401 1055"> <thead> <tr> <th data-bbox="343 878 641 911">Display</th> <th data-bbox="641 878 1393 911">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 913 641 947">Key-Card</td> <td data-bbox="641 913 1393 947">The key card is installed</td> </tr> <tr> <td data-bbox="343 949 641 983">Key-Counter</td> <td data-bbox="641 949 1393 983">The key counter is installed</td> </tr> <tr> <td data-bbox="343 985 641 1019">Off</td> <td data-bbox="641 985 1393 1019">Not installed</td> </tr> </tbody> </table> <p data-bbox="335 1111 539 1144">Initial setting: Off</p> <ol data-bbox="303 1146 1380 1214" style="list-style-type: none"> 2. Press the start key. The setting is set. 3. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. <p data-bbox="287 1247 550 1281">Setting: [MESSAGE]</p> <ol data-bbox="303 1283 1380 1384" style="list-style-type: none"> 1. Select the [Key Device] or [Coin Vender]. 2. Press the start key. The setting is set. 3. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. 	Display	Description	Device	Sets the presence or absence of the key card or key counter	Message	Sets the message when optional equipment is not installed	Display	Description	Key-Card	The key card is installed	Key-Counter	The key counter is installed	Off	Not installed
Display	Description														
Device	Sets the presence or absence of the key card or key counter														
Message	Sets the message when optional equipment is not installed														
Display	Description														
Key-Card	The key card is installed														
Key-Counter	The key counter is installed														
Off	Not installed														

Item No.	Description																								
U206	<p data-bbox="288 241 919 275">Setting the presence or absence of a coin vender</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 975 374">Sets the presence or absence of the optional coin vender.</p> <p data-bbox="288 378 1433 407">This is an optional device which is currently supported only by Japanese specification machines.</p> <p data-bbox="288 412 400 441">Purpose</p> <p data-bbox="288 445 962 474">To run this maintenance item if a coin vender is installed.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 551 632 613" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 629 1401 871"> <thead> <tr> <th data-bbox="336 629 639 674">Display</th> <th data-bbox="639 629 1401 674">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 674 639 719">On/Off Config</td> <td data-bbox="639 674 1401 719">Sets the presence or absence of the coin vender</td> </tr> <tr> <td data-bbox="336 719 639 763">No Coin Action</td> <td data-bbox="639 719 1401 763">Behavior when change runs out during copying</td> </tr> <tr> <td data-bbox="336 763 639 808">Price</td> <td data-bbox="639 763 1401 808">Charge per copy by size and color</td> </tr> <tr> <td data-bbox="336 808 639 853">Boot Mode</td> <td data-bbox="639 808 1401 853">Setting activation mode</td> </tr> </tbody> </table> <p data-bbox="288 916 592 945">Setting: [On/Off Config]</p> <ol data-bbox="304 949 536 978" style="list-style-type: none"> 1. Select On or Off. <table border="1" data-bbox="336 994 1401 1140"> <thead> <tr> <th data-bbox="336 994 639 1039">Display</th> <th data-bbox="639 994 1401 1039">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1039 639 1084">On</td> <td data-bbox="639 1039 1401 1084">The coin vender is installed</td> </tr> <tr> <td data-bbox="336 1084 639 1128">Off</td> <td data-bbox="639 1084 1401 1128">The coin vender is not installed</td> </tr> </tbody> </table> <p data-bbox="336 1144 539 1173">Initial setting: Off</p> <ol data-bbox="304 1178 1378 1240" style="list-style-type: none"> 2. Press the start key. The setting is set. 3. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. <p data-bbox="288 1285 611 1314">Setting: [No Coin Action]</p> <ol data-bbox="304 1319 520 1348" style="list-style-type: none"> 1. Select the item. <table border="1" data-bbox="336 1364 1401 1554"> <thead> <tr> <th data-bbox="336 1364 639 1408">Display</th> <th data-bbox="639 1364 1401 1408">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1408 639 1453">All Clear</td> <td data-bbox="639 1408 1401 1453">All clear is performed</td> </tr> <tr> <td data-bbox="336 1453 639 1498">Auto Clear</td> <td data-bbox="639 1453 1401 1498">Auto clear is performed</td> </tr> <tr> <td data-bbox="336 1498 639 1543">Off</td> <td data-bbox="639 1498 1401 1543">Clear is not performed</td> </tr> </tbody> </table> <p data-bbox="336 1559 539 1588">Initial setting: Off</p> <ol data-bbox="304 1592 1378 1655" style="list-style-type: none"> 2. Press the start key. The setting is set. 3. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. 	Display	Description	On/Off Config	Sets the presence or absence of the coin vender	No Coin Action	Behavior when change runs out during copying	Price	Charge per copy by size and color	Boot Mode	Setting activation mode	Display	Description	On	The coin vender is installed	Off	The coin vender is not installed	Display	Description	All Clear	All clear is performed	Auto Clear	Auto clear is performed	Off	Clear is not performed
Display	Description																								
On/Off Config	Sets the presence or absence of the coin vender																								
No Coin Action	Behavior when change runs out during copying																								
Price	Charge per copy by size and color																								
Boot Mode	Setting activation mode																								
Display	Description																								
On	The coin vender is installed																								
Off	The coin vender is not installed																								
Display	Description																								
All Clear	All clear is performed																								
Auto Clear	Auto clear is performed																								
Off	Clear is not performed																								

Item No.	Description																																																			
U206	<p data-bbox="288 241 483 271">Setting: [Price]</p> <p data-bbox="304 277 632 306">1. Select the item to be set.</p> <table border="1" data-bbox="336 320 1401 512"> <thead> <tr> <th data-bbox="336 320 639 365">Display</th> <th data-bbox="639 320 1401 365">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 365 639 409">Normal</td> <td data-bbox="639 365 1401 409">Charge setting: Normal</td> </tr> <tr> <td data-bbox="336 409 639 454">AD</td> <td data-bbox="639 409 1401 454">Charge setting: Commercial</td> </tr> <tr> <td data-bbox="336 454 639 512">Print</td> <td data-bbox="639 454 1401 512">Charge setting: Print</td> </tr> </tbody> </table> <p data-bbox="288 566 571 595">Setting: [Normal / AD]</p> <p data-bbox="304 602 632 631">1. Select the item to be set.</p> <table border="1" data-bbox="336 645 1401 884"> <thead> <tr> <th data-bbox="336 645 639 689">Display</th> <th data-bbox="639 645 1401 689">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 689 639 734">B/W</td> <td data-bbox="639 689 1401 734">Black & White</td> </tr> <tr> <td data-bbox="336 734 639 779">CMY</td> <td data-bbox="639 734 1401 779">Single color C, M, Y</td> </tr> <tr> <td data-bbox="336 779 639 824">RGB</td> <td data-bbox="639 779 1401 824">Single color R, G, B</td> </tr> <tr> <td data-bbox="336 824 639 884">Full Color</td> <td data-bbox="639 824 1401 884">Full color</td> </tr> </tbody> </table> <p data-bbox="336 896 539 925">Initial setting: Off</p> <p data-bbox="304 931 703 960">2. Select the paper size to be set.</p> <p data-bbox="304 967 858 996">3. Change the setting value using the +/- keys.</p> <table border="1" data-bbox="336 1010 1401 1361"> <thead> <tr> <th data-bbox="336 1010 563 1171" rowspan="2">Display</th> <th data-bbox="563 1010 943 1171" rowspan="2">Description</th> <th data-bbox="943 1010 1094 1171" rowspan="2">Setting range</th> <th colspan="2" data-bbox="1094 1010 1401 1088">Initial setting</th> </tr> <tr> <th data-bbox="1094 1088 1233 1171">B/W</th> <th data-bbox="1233 1088 1401 1171">CMY/RGB Full Color</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1171 563 1216">A3-Ledger</td> <td data-bbox="563 1171 943 1216">A3/Ledger size</td> <td data-bbox="943 1171 1094 1216">0 to 300</td> <td data-bbox="1094 1171 1233 1216">10</td> <td data-bbox="1233 1171 1401 1216">100</td> </tr> <tr> <td data-bbox="336 1216 563 1261">B4</td> <td data-bbox="563 1216 943 1261">B4 size</td> <td data-bbox="943 1216 1094 1261">0 to 300</td> <td data-bbox="1094 1216 1233 1261">10</td> <td data-bbox="1233 1216 1401 1261">50</td> </tr> <tr> <td data-bbox="336 1261 563 1305">Card</td> <td data-bbox="563 1261 943 1305">Post card</td> <td data-bbox="943 1261 1094 1305">0 to 300</td> <td data-bbox="1094 1261 1233 1305">10</td> <td data-bbox="1233 1261 1401 1305">30</td> </tr> <tr> <td data-bbox="336 1305 563 1361">Other</td> <td data-bbox="563 1305 943 1361">Other</td> <td data-bbox="943 1305 1094 1361">0 to 300</td> <td data-bbox="1094 1305 1233 1361">10</td> <td data-bbox="1233 1305 1401 1361">50</td> </tr> </tbody> </table> <p data-bbox="336 1373 587 1402">In 10-yen increments</p> <p data-bbox="336 1408 1209 1438">Value of 0 allows non-restricted copying. (At a periodic maintenance, etc.)</p> <p data-bbox="304 1444 767 1473">4. Press the start key. The value is set.</p> <p data-bbox="304 1480 1378 1509">5. Turn the main power switch off and on. Allow more than 5 seconds between Off and On.</p> <p data-bbox="288 1585 480 1615">Setting: [Print]</p> <p data-bbox="304 1621 523 1650">1. Select the item.</p> <table border="1" data-bbox="336 1664 1401 1805"> <thead> <tr> <th data-bbox="336 1664 639 1709">Display</th> <th data-bbox="639 1664 1401 1709">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1709 639 1753">B/W</td> <td data-bbox="639 1709 1401 1753">Black & White</td> </tr> <tr> <td data-bbox="336 1753 639 1805">Full Color</td> <td data-bbox="639 1753 1401 1805">Full color</td> </tr> </tbody> </table> <p data-bbox="304 1816 703 1845">2. Select the paper size to be set.</p>	Display	Description	Normal	Charge setting: Normal	AD	Charge setting: Commercial	Print	Charge setting: Print	Display	Description	B/W	Black & White	CMY	Single color C, M, Y	RGB	Single color R, G, B	Full Color	Full color	Display	Description	Setting range	Initial setting		B/W	CMY/RGB Full Color	A3-Ledger	A3/Ledger size	0 to 300	10	100	B4	B4 size	0 to 300	10	50	Card	Post card	0 to 300	10	30	Other	Other	0 to 300	10	50	Display	Description	B/W	Black & White	Full Color	Full color
Display	Description																																																			
Normal	Charge setting: Normal																																																			
AD	Charge setting: Commercial																																																			
Print	Charge setting: Print																																																			
Display	Description																																																			
B/W	Black & White																																																			
CMY	Single color C, M, Y																																																			
RGB	Single color R, G, B																																																			
Full Color	Full color																																																			
Display	Description	Setting range	Initial setting																																																	
			B/W	CMY/RGB Full Color																																																
A3-Ledger	A3/Ledger size	0 to 300	10	100																																																
B4	B4 size	0 to 300	10	50																																																
Card	Post card	0 to 300	10	30																																																
Other	Other	0 to 300	10	50																																																
Display	Description																																																			
B/W	Black & White																																																			
Full Color	Full color																																																			

Item No.	Description					
U206	3. Change the setting value using the +/- keys.					
	Display		Description	Setting range	Initial setting	
					B/W	CMY/RGB Full Color
	A3-Ledger		A3/Ledger size	0 to 300	10	100
	B4		B4 size	0 to 300	10	50
	Card		Post card	0 to 300	10	30
	Other		Other	0 to 300	10	50
	In 10-yen increments Value of 0 allows non-restricted copying. (At a periodic maintenance, etc.)					
	Setting: [Apl]					
	1. Select the item to be set. 2. Change the setting value using the +/- keys.					
Display		Description	Setting range	Initial setting		
Apl1		Expanded charging unit 1	0 to 300	10		
Apl2		Expanded charging unit 2	0 to 300	10		
Apl3		Expanded charging unit 3	0 to 300	10		
Apl4		Expanded charging unit 4	0 to 300	10		
Apl5		Expanded charging unit 5	0 to 300	10		
3. Press the start key. The value is set. 4. Turn the main power switch off and on. Allow more than 5 seconds between Off and On.						
Setting: [Boot Mode]						
1. Select the item.						
Display		Description				
Normal		Assign activation to normal mode.				
Copy Service		Assign activation to copy service display.				
Initial setting: Copy Service						
2. Press the start key. The setting is set.						
Completion						
Press the stop key. The screen for selecting a maintenance item No. is displayed.						

Item No.	Description
U207	<p>Checking the operation panel keys</p> <p>Description Checks operation of the operation panel keys.</p> <p>Purpose To check operation of all the keys and LEDs on the operation panel.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. [Count0] is displayed and the left most LED on the operation panel lights. 3. As the keys lined up in the same line as the lit indicator are pressed in the order from the top to the bottom, the figure shown on the touch panel increases in increments of 1. When all the keys in that line are pressed and if there are any LEDs corresponding to the keys in the line on the immediate right, the top LED in that line will light. 4. When all the keys on the operation panel have been pressed, all the LEDs light for up to 10 seconds. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>
U208	<p>Setting the paper size for the side deck</p> <p>Description Sets the size of paper used in side deck.</p> <p>Purpose To change the setting when installing the side deck or the size of paper used in the side deck is changed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the paper size (A4, B5 or Letter). Initial setting: Letter (Inch specifications) A4 (Metric specifications) 3. Press the start key. The setting is set. 4. Turn the main power switch off and on. Allow more than 5 seconds between Off and On.

Item No.	Description						
U211	<p data-bbox="288 244 962 275">Setting the presence or absence of the job separator</p> <p data-bbox="288 315 440 342">Description</p> <p data-bbox="288 349 957 376">Sets the presence or absence of the inner job separator.</p> <p data-bbox="288 383 400 409">Purpose</p> <p data-bbox="288 416 1067 443">To run this maintenance item if the inner job separator is installed.</p> <p data-bbox="288 483 387 510">Method</p> <ol data-bbox="308 517 678 618" style="list-style-type: none"> 1. Press the start key. 2. Select [Inner Job Separator]. 3. Select On or Off. <table border="1" data-bbox="336 633 1401 777"> <thead> <tr> <th data-bbox="336 633 641 680">Display</th> <th data-bbox="641 633 1401 680">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 680 641 728">On</td> <td data-bbox="641 680 1401 728">The inner job separator is installed</td> </tr> <tr> <td data-bbox="336 728 641 777">Off</td> <td data-bbox="641 728 1401 777">The inner job separator is not installed</td> </tr> </tbody> </table> <p data-bbox="336 786 539 813">Initial setting: Off</p> <ol data-bbox="308 819 1378 884" style="list-style-type: none"> 4. Press the start key. The setting is set. 5. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. 	Display	Description	On	The inner job separator is installed	Off	The inner job separator is not installed
Display	Description						
On	The inner job separator is installed						
Off	The inner job separator is not installed						

Item No.	Description						
U221	<p>Setting the USB host lock function</p> <p>Description Specifies ON/OFF the USB host lock function. Setting this to ON causes the machine to be unable to recognize the device connected to the USB host.</p> <p>Purpose Set according to the preference of the user.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Host Lock]. 3. Select On or Off. <table border="1" data-bbox="336 667 1401 808"> <thead> <tr> <th data-bbox="336 667 639 712">Display</th> <th data-bbox="639 667 1401 712">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 712 639 757">On</td> <td data-bbox="639 712 1401 757">USB host lock function ON</td> </tr> <tr> <td data-bbox="336 757 639 808">Off</td> <td data-bbox="639 757 1401 808">USB host lock function OFF</td> </tr> </tbody> </table> <p>Initial setting: Off</p> <ol style="list-style-type: none"> 4. Press the start key. The setting is set. 5. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. 	Display	Description	On	USB host lock function ON	Off	USB host lock function OFF
Display	Description						
On	USB host lock function ON						
Off	USB host lock function OFF						
U222	<p>Setting the IC card type</p> <p>Description Sets the type of IC card.</p> <p>Purpose To change the type of IC card.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 1323 1401 1464"> <thead> <tr> <th data-bbox="336 1323 639 1368">Display</th> <th data-bbox="639 1323 1401 1368">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1368 639 1413">Other</td> <td data-bbox="639 1368 1401 1413">The type of IC card is SSFC.</td> </tr> <tr> <td data-bbox="336 1413 639 1464">SSFC</td> <td data-bbox="639 1413 1401 1464">The type of IC card is not SSFC.</td> </tr> </tbody> </table> <p>Initial setting: Other</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Other	The type of IC card is SSFC.	SSFC	The type of IC card is not SSFC.
Display	Description						
Other	The type of IC card is SSFC.						
SSFC	The type of IC card is not SSFC.						

Item No.	Description																																			
U223	<p data-bbox="288 241 558 275">Operation panel lock</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 745 374">Sets the operation panel lock function.</p> <p data-bbox="288 383 400 412">Purpose</p> <p data-bbox="288 416 1382 479">This is performed to inhibit operating and canceling the system menu on the operation panel which may be done by others then an administrator.</p> <p data-bbox="288 517 384 546">Setting</p> <ol data-bbox="304 553 564 616" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 631 1399 824"> <thead> <tr> <th data-bbox="336 631 639 676">Display</th> <th data-bbox="639 631 1399 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 676 639 721">Unlock</td> <td data-bbox="639 676 1399 721">Release the lock of the operation from the system menu</td> </tr> <tr> <td data-bbox="336 721 639 766">Partial Lock</td> <td data-bbox="639 721 1399 766">Lock the operation from the system menu</td> </tr> <tr> <td data-bbox="336 766 639 810">Lock</td> <td data-bbox="639 766 1399 810">Lock the operation from the system menu and job cancel</td> </tr> </tbody> </table> <p data-bbox="336 835 584 864">Initial setting: Unlock</p> <ol data-bbox="304 869 782 898" style="list-style-type: none"> 3. Press the start key. The setting is set. <table border="1" data-bbox="336 945 1248 1413"> <thead> <tr> <th data-bbox="336 945 791 990">Item</th> <th data-bbox="791 945 1019 990">Partial Lock</th> <th data-bbox="1019 945 1248 990">Lock</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 990 791 1034">Entering maintenance mode</td> <td data-bbox="791 990 1019 1034">Prohibited</td> <td data-bbox="1019 990 1248 1034">Prohibited</td> </tr> <tr> <td data-bbox="336 1034 791 1079">Entering system menu</td> <td data-bbox="791 1034 1019 1079">Prohibited</td> <td data-bbox="1019 1034 1248 1079">Prohibited</td> </tr> <tr> <td data-bbox="336 1079 791 1169">Transmission/transmission from document boxes</td> <td data-bbox="791 1079 1019 1169">Prohibited</td> <td data-bbox="1019 1079 1248 1169">Prohibited</td> </tr> <tr> <td data-bbox="336 1169 791 1214">Entering addressbook add/edit</td> <td data-bbox="791 1169 1019 1214">Prohibited</td> <td data-bbox="1019 1169 1248 1214">Prohibited</td> </tr> <tr> <td data-bbox="336 1214 791 1258">Entering document box add/edit</td> <td data-bbox="791 1214 1019 1258">Prohibited</td> <td data-bbox="1019 1214 1248 1258">Prohibited</td> </tr> <tr> <td data-bbox="336 1258 791 1303">Pressing stop key</td> <td data-bbox="791 1258 1019 1303">Permitted</td> <td data-bbox="1019 1258 1248 1303">Prohibited</td> </tr> <tr> <td data-bbox="336 1303 791 1348">Pressing status/job cancel</td> <td data-bbox="791 1303 1019 1348">Permitted</td> <td data-bbox="1019 1303 1248 1348">Prohibited</td> </tr> <tr> <td data-bbox="336 1348 791 1413">Disconnecting FAX lines</td> <td data-bbox="791 1348 1019 1413">Permitted</td> <td data-bbox="1019 1348 1248 1413">Prohibited</td> </tr> </tbody> </table> <p data-bbox="288 1456 440 1485">Completion</p> <p data-bbox="288 1489 1254 1518">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Unlock	Release the lock of the operation from the system menu	Partial Lock	Lock the operation from the system menu	Lock	Lock the operation from the system menu and job cancel	Item	Partial Lock	Lock	Entering maintenance mode	Prohibited	Prohibited	Entering system menu	Prohibited	Prohibited	Transmission/transmission from document boxes	Prohibited	Prohibited	Entering addressbook add/edit	Prohibited	Prohibited	Entering document box add/edit	Prohibited	Prohibited	Pressing stop key	Permitted	Prohibited	Pressing status/job cancel	Permitted	Prohibited	Disconnecting FAX lines	Permitted	Prohibited
Display	Description																																			
Unlock	Release the lock of the operation from the system menu																																			
Partial Lock	Lock the operation from the system menu																																			
Lock	Lock the operation from the system menu and job cancel																																			
Item	Partial Lock	Lock																																		
Entering maintenance mode	Prohibited	Prohibited																																		
Entering system menu	Prohibited	Prohibited																																		
Transmission/transmission from document boxes	Prohibited	Prohibited																																		
Entering addressbook add/edit	Prohibited	Prohibited																																		
Entering document box add/edit	Prohibited	Prohibited																																		
Pressing stop key	Permitted	Prohibited																																		
Pressing status/job cancel	Permitted	Prohibited																																		
Disconnecting FAX lines	Permitted	Prohibited																																		

Item No.	Description																																									
U224	<p data-bbox="288 241 574 271">Panel sheet extension</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1426 409">Changes the image data and the message of the opening screen at the machine startup and the image data and the message of the service call screen to user specified data.</p> <p data-bbox="288 414 400 443">Purpose</p> <p data-bbox="288 448 805 477">Set according to the preference of the user.</p> <p data-bbox="288 517 383 546">Setting</p> <ol data-bbox="304 553 1082 757" style="list-style-type: none"> 1. Write the image data or the message data to the USB memory. 2. Insert USB memory in USB memory slot of the machine. 3. Turn the main power switch on. 4. Enter the maintenance item. 5. Press the start key. 6. Select the [Install] or [UnInstall]. <table border="1" data-bbox="336 768 1401 913"> <thead> <tr> <th data-bbox="336 768 639 813">Display</th> <th data-bbox="639 768 1401 813">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 813 639 857">Install</td> <td data-bbox="639 813 1401 857">Installs the image data or the message data</td> </tr> <tr> <td data-bbox="336 857 639 913">UnInstall</td> <td data-bbox="639 857 1401 913">Restores the original image data or message data</td> </tr> </tbody> </table> <ol data-bbox="304 925 520 954" style="list-style-type: none"> 7. Select the item. <table border="1" data-bbox="336 965 1401 1207"> <thead> <tr> <th data-bbox="336 965 564 1010">Display</th> <th data-bbox="564 965 908 1010">Description</th> <th data-bbox="908 965 1401 1010">Display area</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1010 564 1055">Opening Img</td> <td data-bbox="564 1010 908 1055">Startup screen</td> <td data-bbox="908 1010 1401 1055">Entire start display</td> </tr> <tr> <td data-bbox="336 1055 564 1099">Call Img</td> <td data-bbox="564 1055 908 1099">Service call screen</td> <td data-bbox="908 1055 1401 1099">Graphic display area</td> </tr> <tr> <td data-bbox="336 1099 564 1144">Call Msg Top</td> <td data-bbox="564 1099 908 1144">Service call message 1</td> <td data-bbox="908 1099 1401 1144">Message display area (top)</td> </tr> <tr> <td data-bbox="336 1144 564 1207">Call Msg Detail</td> <td data-bbox="564 1144 908 1207">Service call message 2</td> <td data-bbox="908 1144 1401 1207">Message display area (descriptive area)</td> </tr> </tbody> </table> <ol data-bbox="304 1218 1016 1283" style="list-style-type: none"> 8. Press the start key. Installation or uninstallation is started. 9. When normally completed, [OK] is displayed. <p data-bbox="288 1323 464 1352">Supplement 1</p> <p data-bbox="336 1357 539 1386">File information</p> <table border="1" data-bbox="336 1397 1401 1778"> <thead> <tr> <th data-bbox="336 1397 564 1442">Description</th> <th data-bbox="564 1397 927 1442">File name</th> <th data-bbox="927 1397 1233 1442">Image size (in pixels)</th> <th data-bbox="1233 1397 1401 1442">File format</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1442 564 1532">Startup screen</td> <td data-bbox="564 1442 927 1532">opening_ext_image.png</td> <td data-bbox="927 1442 1233 1532">Length: 480 Width : 800</td> <td data-bbox="1233 1442 1401 1532">PNG</td> </tr> <tr> <td data-bbox="336 1532 564 1621">Service call screen</td> <td data-bbox="564 1532 927 1621">callwin_ext_image.png</td> <td data-bbox="927 1532 1233 1621">Length: 200 Width : 180</td> <td data-bbox="1233 1532 1401 1621">PNG</td> </tr> <tr> <td data-bbox="336 1621 564 1700">Service call message 1</td> <td data-bbox="564 1621 927 1700">callwin_ext_mes_top.txt</td> <td data-bbox="927 1621 1233 1700">-</td> <td data-bbox="1233 1621 1401 1700">TEXT (Unicode)</td> </tr> <tr> <td data-bbox="336 1700 564 1778">Service call message 2</td> <td data-bbox="564 1700 927 1778">callwin_ext_mes_detail.txt</td> <td data-bbox="927 1700 1233 1778">-</td> <td data-bbox="1233 1700 1401 1778">TEXT (Unicode)</td> </tr> </tbody> </table>	Display	Description	Install	Installs the image data or the message data	UnInstall	Restores the original image data or message data	Display	Description	Display area	Opening Img	Startup screen	Entire start display	Call Img	Service call screen	Graphic display area	Call Msg Top	Service call message 1	Message display area (top)	Call Msg Detail	Service call message 2	Message display area (descriptive area)	Description	File name	Image size (in pixels)	File format	Startup screen	opening_ext_image.png	Length: 480 Width : 800	PNG	Service call screen	callwin_ext_image.png	Length: 200 Width : 180	PNG	Service call message 1	callwin_ext_mes_top.txt	-	TEXT (Unicode)	Service call message 2	callwin_ext_mes_detail.txt	-	TEXT (Unicode)
Display	Description																																									
Install	Installs the image data or the message data																																									
UnInstall	Restores the original image data or message data																																									
Display	Description	Display area																																								
Opening Img	Startup screen	Entire start display																																								
Call Img	Service call screen	Graphic display area																																								
Call Msg Top	Service call message 1	Message display area (top)																																								
Call Msg Detail	Service call message 2	Message display area (descriptive area)																																								
Description	File name	Image size (in pixels)	File format																																							
Startup screen	opening_ext_image.png	Length: 480 Width : 800	PNG																																							
Service call screen	callwin_ext_image.png	Length: 200 Width : 180	PNG																																							
Service call message 1	callwin_ext_mes_top.txt	-	TEXT (Unicode)																																							
Service call message 2	callwin_ext_mes_detail.txt	-	TEXT (Unicode)																																							

Item No.	Description										
U224	<p>Supplement 2</p> <p>Displaying start display The pre-installed graphics file is displayed at power on or recovering from sleeping.</p> <p>Graphics display on service call display The pre-installed graphics file is displayed at a service call.</p> <p>How to change the message Entering #562 (4 letters) using the numeric keypad during a service call display will let service call messages 1 and 2.</p> <p>How to reset the message display Reverting the maintenance mode will automatically reset the message to the previous.</p> <p>Caution The graphics file for start display must be opaque. (To avoid the background from overlapping at recovering from sleeping.) The total size of the files installable is approximately 1.8 MB.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>										
U234	<p>Setting punch destination</p> <p>Description Sets the destination of punch unit of 1000-sheet finisher or 4000-sheet finisher.</p> <p>Purpose To be set when installing a different punch unit from the destination of the machine.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the destination. <table border="1" data-bbox="336 1234 1401 1473"> <thead> <tr> <th data-bbox="336 1234 639 1279">Display</th> <th data-bbox="639 1234 1401 1279">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1279 639 1323">Auto</td> <td data-bbox="639 1279 1401 1323">Conforms to destination settings.</td> </tr> <tr> <td data-bbox="336 1323 639 1368">Japan Metric</td> <td data-bbox="639 1323 1401 1368">Metric (Japan) specifications</td> </tr> <tr> <td data-bbox="336 1368 639 1413">Inch</td> <td data-bbox="639 1368 1401 1413">Inch (North America) specifications</td> </tr> <tr> <td data-bbox="336 1413 639 1458">Europe Metric</td> <td data-bbox="639 1413 1401 1458">Metric (Europe) specifications</td> </tr> </tbody> </table> <p>Initial setting: Inch (Inch specifications)/Europe Metric (Metric specifications)</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. 4. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. 	Display	Description	Auto	Conforms to destination settings.	Japan Metric	Metric (Japan) specifications	Inch	Inch (North America) specifications	Europe Metric	Metric (Europe) specifications
Display	Description										
Auto	Conforms to destination settings.										
Japan Metric	Metric (Japan) specifications										
Inch	Inch (North America) specifications										
Europe Metric	Metric (Europe) specifications										

Item No.	Description																		
U237	<p data-bbox="288 241 675 275">Setting finisher stack quantity</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1412 409">Sets the number of sheets of each stack on the main tray and on the middle tray in 4000-sheet finisher.</p> <p data-bbox="288 414 400 443">Purpose</p> <p data-bbox="288 448 1023 479">To change the setting when a stack malfunction has occurred.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 553 632 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 631 1401 777"> <thead> <tr> <th data-bbox="336 631 641 678">Display</th> <th data-bbox="641 631 1401 678">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 678 641 725">Main Tray</td> <td data-bbox="641 678 1401 725">Number of sheets of stack on the main tray</td> </tr> <tr> <td data-bbox="336 725 641 777">Middle Tray</td> <td data-bbox="641 725 1401 777">Number of sheets of stack on the middle tray for staple mode</td> </tr> </tbody> </table> <p data-bbox="288 819 541 851">Setting: [Main Tray]</p> <ol data-bbox="304 855 983 887" style="list-style-type: none"> 1. Change the setting using the +/- keys or numeric keys. <table border="1" data-bbox="336 898 1401 1043"> <thead> <tr> <th data-bbox="336 898 641 945">Display</th> <th data-bbox="641 898 1401 945">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 945 641 992">0</td> <td data-bbox="641 945 1401 992">Number of sheets of stack on the main tray: 4000 sheets</td> </tr> <tr> <td data-bbox="336 992 641 1043">1</td> <td data-bbox="641 992 1401 1043">Number of sheets of stack on the main tray: 1500 sheets</td> </tr> </tbody> </table> <p data-bbox="336 1055 517 1086">Initial setting: 0</p> <ol data-bbox="304 1090 1378 1155" style="list-style-type: none"> 2. Press the start key. The setting is set. 3. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. <p data-bbox="288 1193 564 1225">Setting: [Middle Tray]</p> <ol data-bbox="304 1229 983 1261" style="list-style-type: none"> 1. Change the setting using the +/- keys or numeric keys. <table border="1" data-bbox="336 1272 1401 1485"> <thead> <tr> <th data-bbox="336 1272 641 1319">Display</th> <th data-bbox="641 1272 1401 1319">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1319 641 1404">0</td> <td data-bbox="641 1319 1401 1404">Number of sheets of stack on the middle tray for staple mode: 65 sheets</td> </tr> <tr> <td data-bbox="336 1404 641 1485">1</td> <td data-bbox="641 1404 1401 1485">Number of sheets of stack on the middle tray for staple mode: 30 sheets</td> </tr> </tbody> </table> <p data-bbox="336 1496 517 1527">Initial setting: 0</p> <p data-bbox="336 1532 1278 1563">Number of sheets of stack on the internal tray for non-staple copying: 10 sheets</p> <ol data-bbox="304 1568 1378 1632" style="list-style-type: none"> 2. Press the start key. The setting is set. 3. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. 	Display	Description	Main Tray	Number of sheets of stack on the main tray	Middle Tray	Number of sheets of stack on the middle tray for staple mode	Display	Description	0	Number of sheets of stack on the main tray: 4000 sheets	1	Number of sheets of stack on the main tray: 1500 sheets	Display	Description	0	Number of sheets of stack on the middle tray for staple mode: 65 sheets	1	Number of sheets of stack on the middle tray for staple mode: 30 sheets
Display	Description																		
Main Tray	Number of sheets of stack on the main tray																		
Middle Tray	Number of sheets of stack on the middle tray for staple mode																		
Display	Description																		
0	Number of sheets of stack on the main tray: 4000 sheets																		
1	Number of sheets of stack on the main tray: 1500 sheets																		
Display	Description																		
0	Number of sheets of stack on the middle tray for staple mode: 65 sheets																		
1	Number of sheets of stack on the middle tray for staple mode: 30 sheets																		

Item No.	Description																																																		
U240	<p data-bbox="287 241 774 275">Checking the operation of the finisher</p> <p data-bbox="287 309 438 342">Description</p> <p data-bbox="287 344 1244 378">Turns each motor and solenoid of 1000-sheet finisher or 4000-sheet finisher ON.</p> <p data-bbox="287 380 399 414">Purpose</p> <p data-bbox="287 416 1420 483">To check the operation of each motor and solenoid of the 1000-sheet finisher or 4000-sheet finisher.</p> <p data-bbox="287 517 391 551">Method</p> <ol data-bbox="303 553 694 620" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be checked. <table border="1" data-bbox="335 631 1401 873"> <thead> <tr> <th data-bbox="343 642 641 676">Display</th> <th data-bbox="641 642 1393 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 687 641 721">Motor</td> <td data-bbox="641 687 1393 721">Checking the motor of the document finisher</td> </tr> <tr> <td data-bbox="343 732 641 766">Solenoid</td> <td data-bbox="641 732 1393 766">Checking the solenoid of the document finisher</td> </tr> <tr> <td data-bbox="343 777 641 810">Mail Box</td> <td data-bbox="641 777 1393 810">Checking the motor of the mailbox</td> </tr> <tr> <td data-bbox="343 822 641 855">Booklet</td> <td data-bbox="641 822 1393 855">Checking the motor of the center-folding unit</td> </tr> </tbody> </table> <p data-bbox="287 920 494 954">Method: [Motor]</p> <ol data-bbox="303 956 813 1023" style="list-style-type: none"> 1. Select the item to be operated. 2. Press the start key. The operation starts. <table border="1" data-bbox="335 1034 1401 1989"> <thead> <tr> <th data-bbox="343 1046 641 1079">Display</th> <th data-bbox="641 1046 1393 1079">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 1090 641 1124">Feed In(H)</td> <td data-bbox="641 1090 1393 1124">DF paper entry motor (DFPEM) is turned on at high speed</td> </tr> <tr> <td data-bbox="343 1135 641 1169">Feed In(L)</td> <td data-bbox="641 1135 1393 1169">DF paper entry motor (DFPEM) is turned on at low speed</td> </tr> <tr> <td data-bbox="343 1180 641 1214">Middle(H)</td> <td data-bbox="641 1180 1393 1214">DF middle motor (DFMM) is turned on at high speed</td> </tr> <tr> <td data-bbox="343 1225 641 1258">Middle(L)</td> <td data-bbox="641 1225 1393 1258">DF middle motor (DFMM) is turned on at low speed</td> </tr> <tr> <td data-bbox="343 1270 641 1303">Eject(H)</td> <td data-bbox="641 1270 1393 1303">DF eject motor (DFEM) is turned on at high speed</td> </tr> <tr> <td data-bbox="343 1314 641 1348">Eject(L)</td> <td data-bbox="641 1314 1393 1348">DF eject motor (DFEM) is turned on at low speed</td> </tr> <tr> <td data-bbox="343 1359 641 1393">Save(H)</td> <td data-bbox="641 1359 1393 1393">DF drum motor (DFDRM) is turned on at high speed</td> </tr> <tr> <td data-bbox="343 1404 641 1438">Save(L)</td> <td data-bbox="641 1404 1393 1438">DF drum motor (DFDRM) is turned on at low speed</td> </tr> <tr> <td data-bbox="343 1449 641 1482">Tray</td> <td data-bbox="641 1449 1393 1482">DF tray motor (DFTM) is turned on</td> </tr> <tr> <td data-bbox="343 1494 641 1527">Staple Move</td> <td data-bbox="641 1494 1393 1527">DF slide motor (DFSLM) is turned on</td> </tr> <tr> <td data-bbox="343 1538 641 1572">Staple</td> <td data-bbox="641 1538 1393 1572">DF staple motor (DFSTM) is turned on</td> </tr> <tr> <td data-bbox="343 1583 641 1617">Width Test(A3)</td> <td data-bbox="641 1583 1393 1617">DF side registration motor 1, 2 (DFSRM1, 2) is turned on</td> </tr> <tr> <td data-bbox="343 1628 641 1662">Width Test(LD)</td> <td data-bbox="641 1628 1393 1662">DF side registration motor 1, 2 (DFSRM1, 2) is turned on</td> </tr> <tr> <td data-bbox="343 1673 641 1706">Beat</td> <td data-bbox="641 1673 1393 1706">DF paddle motor (DFPDM) is turned on</td> </tr> <tr> <td data-bbox="343 1718 641 1751">Eject Unlock(HP)</td> <td data-bbox="641 1718 1393 1751">DF eject release motor (DFERM) is turned on to home position</td> </tr> <tr> <td data-bbox="343 1762 641 1796">Sort Test</td> <td data-bbox="641 1762 1393 1796">DF shift motor 1, 2 (DFFSM1, 2) is turned on</td> </tr> <tr> <td data-bbox="343 1807 641 1841">Eject Unlock(30)</td> <td data-bbox="641 1807 1393 1841">DF eject release motor (DFERM) drive position 30-sheet stack</td> </tr> <tr> <td data-bbox="343 1852 641 1886">Eject Unlock(50)</td> <td data-bbox="641 1852 1393 1886">DF eject release motor (DFERM) drive position 50-sheet stack</td> </tr> <tr> <td data-bbox="343 1897 641 1930">Eject Unlock(Fix)</td> <td data-bbox="641 1897 1393 1930">DF eject release motor (DFERM) fixed drive position</td> </tr> </tbody> </table>	Display	Description	Motor	Checking the motor of the document finisher	Solenoid	Checking the solenoid of the document finisher	Mail Box	Checking the motor of the mailbox	Booklet	Checking the motor of the center-folding unit	Display	Description	Feed In(H)	DF paper entry motor (DFPEM) is turned on at high speed	Feed In(L)	DF paper entry motor (DFPEM) is turned on at low speed	Middle(H)	DF middle motor (DFMM) is turned on at high speed	Middle(L)	DF middle motor (DFMM) is turned on at low speed	Eject(H)	DF eject motor (DFEM) is turned on at high speed	Eject(L)	DF eject motor (DFEM) is turned on at low speed	Save(H)	DF drum motor (DFDRM) is turned on at high speed	Save(L)	DF drum motor (DFDRM) is turned on at low speed	Tray	DF tray motor (DFTM) is turned on	Staple Move	DF slide motor (DFSLM) is turned on	Staple	DF staple motor (DFSTM) is turned on	Width Test(A3)	DF side registration motor 1, 2 (DFSRM1, 2) is turned on	Width Test(LD)	DF side registration motor 1, 2 (DFSRM1, 2) is turned on	Beat	DF paddle motor (DFPDM) is turned on	Eject Unlock(HP)	DF eject release motor (DFERM) is turned on to home position	Sort Test	DF shift motor 1, 2 (DFFSM1, 2) is turned on	Eject Unlock(30)	DF eject release motor (DFERM) drive position 30-sheet stack	Eject Unlock(50)	DF eject release motor (DFERM) drive position 50-sheet stack	Eject Unlock(Fix)	DF eject release motor (DFERM) fixed drive position
Display	Description																																																		
Motor	Checking the motor of the document finisher																																																		
Solenoid	Checking the solenoid of the document finisher																																																		
Mail Box	Checking the motor of the mailbox																																																		
Booklet	Checking the motor of the center-folding unit																																																		
Display	Description																																																		
Feed In(H)	DF paper entry motor (DFPEM) is turned on at high speed																																																		
Feed In(L)	DF paper entry motor (DFPEM) is turned on at low speed																																																		
Middle(H)	DF middle motor (DFMM) is turned on at high speed																																																		
Middle(L)	DF middle motor (DFMM) is turned on at low speed																																																		
Eject(H)	DF eject motor (DFEM) is turned on at high speed																																																		
Eject(L)	DF eject motor (DFEM) is turned on at low speed																																																		
Save(H)	DF drum motor (DFDRM) is turned on at high speed																																																		
Save(L)	DF drum motor (DFDRM) is turned on at low speed																																																		
Tray	DF tray motor (DFTM) is turned on																																																		
Staple Move	DF slide motor (DFSLM) is turned on																																																		
Staple	DF staple motor (DFSTM) is turned on																																																		
Width Test(A3)	DF side registration motor 1, 2 (DFSRM1, 2) is turned on																																																		
Width Test(LD)	DF side registration motor 1, 2 (DFSRM1, 2) is turned on																																																		
Beat	DF paddle motor (DFPDM) is turned on																																																		
Eject Unlock(HP)	DF eject release motor (DFERM) is turned on to home position																																																		
Sort Test	DF shift motor 1, 2 (DFFSM1, 2) is turned on																																																		
Eject Unlock(30)	DF eject release motor (DFERM) drive position 30-sheet stack																																																		
Eject Unlock(50)	DF eject release motor (DFERM) drive position 50-sheet stack																																																		
Eject Unlock(Fix)	DF eject release motor (DFERM) fixed drive position																																																		

Item No.	Description																																												
U240	<table border="1" data-bbox="336 286 1401 479"> <thead> <tr> <th data-bbox="336 286 641 331">Display</th> <th data-bbox="641 286 1401 331">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 331 641 376">Eject Unlock(Full)</td> <td data-bbox="641 331 1401 376">DF eject release motor (DFERM) full-open drive position</td> </tr> <tr> <td data-bbox="336 376 641 421">Punch</td> <td data-bbox="641 376 1401 421">Punch motor (PUM) is turned on</td> </tr> <tr> <td data-bbox="336 421 641 479">Punch Move</td> <td data-bbox="641 421 1401 479">Punch slide motor (PUSLM) is turned on</td> </tr> </tbody> </table> <p data-bbox="288 521 534 555">Method: [Solenoid]</p> <ol data-bbox="304 557 815 622" style="list-style-type: none"> <li data-bbox="304 557 699 591">1. Select the item to be operated. <li data-bbox="304 591 815 622">2. Press the start key. The operation starts. <table border="1" data-bbox="336 633 1401 922"> <thead> <tr> <th data-bbox="336 633 641 678">Display</th> <th data-bbox="641 633 1401 678">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 678 641 723">Sub Tray</td> <td data-bbox="641 678 1401 723">DF feedshift solenoid (DFFSSOL) is turned on</td> </tr> <tr> <td data-bbox="336 723 641 768">Save Drum</td> <td data-bbox="641 723 1401 768">DF drum solenoid (DFDRSOL) is turned on</td> </tr> <tr> <td data-bbox="336 768 641 813">Booklet</td> <td data-bbox="641 768 1401 813">DF center fold solenoid (DFCFSOL) is turned on</td> </tr> <tr> <td data-bbox="336 813 641 857">Punch</td> <td data-bbox="641 813 1401 857">Punch solenoid (PUSOL) is turned on</td> </tr> <tr> <td data-bbox="336 857 641 922">Three Fold</td> <td data-bbox="641 857 1401 922">CF feedshift solenoid (CFFSSOL) is turned on</td> </tr> </tbody> </table> <p data-bbox="288 965 531 999">Method: [Mail Box]</p> <ol data-bbox="304 1001 815 1066" style="list-style-type: none"> <li data-bbox="304 1001 699 1034">1. Select the item to be operated. <li data-bbox="304 1034 815 1066">2. Press the start key. The operation starts. <table border="1" data-bbox="336 1077 1401 1225"> <thead> <tr> <th data-bbox="336 1077 564 1122">Display</th> <th data-bbox="564 1077 1401 1122">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1122 564 1167">Conv</td> <td data-bbox="564 1122 1401 1167">MB drive motor (MBDM) is turned on at paper conveying</td> </tr> <tr> <td data-bbox="336 1167 564 1225">Branch</td> <td data-bbox="564 1167 1401 1225">MB drive motor (MBDM) is turned on at feedshift operation</td> </tr> </tbody> </table> <p data-bbox="288 1267 520 1301">Method: [Booklet]</p> <ol data-bbox="304 1303 815 1368" style="list-style-type: none"> <li data-bbox="304 1303 699 1337">1. Select the item to be operated. <li data-bbox="304 1337 815 1368">2. Press the start key. The operation starts. <table border="1" data-bbox="336 1379 1401 1814"> <thead> <tr> <th data-bbox="336 1379 641 1424">Display</th> <th data-bbox="641 1379 1401 1424">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1424 641 1469">Folding</td> <td data-bbox="641 1424 1401 1469">CF main motor (CFMM) is turned on</td> </tr> <tr> <td data-bbox="336 1469 641 1514">Blade</td> <td data-bbox="641 1469 1401 1514">CF blade motor (CFBM) is turned on</td> </tr> <tr> <td data-bbox="336 1514 641 1559">Bundle Up</td> <td data-bbox="641 1514 1401 1559">CF adjustment motor 2 (CFADM2) is turned on</td> </tr> <tr> <td data-bbox="336 1559 641 1603">Bundle Down</td> <td data-bbox="641 1559 1401 1603">CF adjustment motor 1 (CFADM1) is turned on</td> </tr> <tr> <td data-bbox="336 1603 641 1648">Staple</td> <td data-bbox="641 1603 1401 1648">CF staple motor (CFSTM) is turned on</td> </tr> <tr> <td data-bbox="336 1648 641 1693">Width Test(A3)</td> <td data-bbox="641 1648 1401 1693">CF side registration motor 1, 2 (CFSRM1, 2) is turned on</td> </tr> <tr> <td data-bbox="336 1693 641 1738">Width Test(LD)</td> <td data-bbox="641 1693 1401 1738">CF side registration motor 1, 2 (CFSRM1, 2) is turned on</td> </tr> <tr> <td data-bbox="336 1738 641 1814">Feed In</td> <td data-bbox="641 1738 1401 1814">CF paper entry motor (CFPEM) is turned on</td> </tr> </tbody> </table> <p data-bbox="288 1856 440 1890">Completion</p> <p data-bbox="288 1892 1254 1926">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Eject Unlock(Full)	DF eject release motor (DFERM) full-open drive position	Punch	Punch motor (PUM) is turned on	Punch Move	Punch slide motor (PUSLM) is turned on	Display	Description	Sub Tray	DF feedshift solenoid (DFFSSOL) is turned on	Save Drum	DF drum solenoid (DFDRSOL) is turned on	Booklet	DF center fold solenoid (DFCFSOL) is turned on	Punch	Punch solenoid (PUSOL) is turned on	Three Fold	CF feedshift solenoid (CFFSSOL) is turned on	Display	Description	Conv	MB drive motor (MBDM) is turned on at paper conveying	Branch	MB drive motor (MBDM) is turned on at feedshift operation	Display	Description	Folding	CF main motor (CFMM) is turned on	Blade	CF blade motor (CFBM) is turned on	Bundle Up	CF adjustment motor 2 (CFADM2) is turned on	Bundle Down	CF adjustment motor 1 (CFADM1) is turned on	Staple	CF staple motor (CFSTM) is turned on	Width Test(A3)	CF side registration motor 1, 2 (CFSRM1, 2) is turned on	Width Test(LD)	CF side registration motor 1, 2 (CFSRM1, 2) is turned on	Feed In	CF paper entry motor (CFPEM) is turned on
Display	Description																																												
Eject Unlock(Full)	DF eject release motor (DFERM) full-open drive position																																												
Punch	Punch motor (PUM) is turned on																																												
Punch Move	Punch slide motor (PUSLM) is turned on																																												
Display	Description																																												
Sub Tray	DF feedshift solenoid (DFFSSOL) is turned on																																												
Save Drum	DF drum solenoid (DFDRSOL) is turned on																																												
Booklet	DF center fold solenoid (DFCFSOL) is turned on																																												
Punch	Punch solenoid (PUSOL) is turned on																																												
Three Fold	CF feedshift solenoid (CFFSSOL) is turned on																																												
Display	Description																																												
Conv	MB drive motor (MBDM) is turned on at paper conveying																																												
Branch	MB drive motor (MBDM) is turned on at feedshift operation																																												
Display	Description																																												
Folding	CF main motor (CFMM) is turned on																																												
Blade	CF blade motor (CFBM) is turned on																																												
Bundle Up	CF adjustment motor 2 (CFADM2) is turned on																																												
Bundle Down	CF adjustment motor 1 (CFADM1) is turned on																																												
Staple	CF staple motor (CFSTM) is turned on																																												
Width Test(A3)	CF side registration motor 1, 2 (CFSRM1, 2) is turned on																																												
Width Test(LD)	CF side registration motor 1, 2 (CFSRM1, 2) is turned on																																												
Feed In	CF paper entry motor (CFPEM) is turned on																																												

Item No.	Description																																																
U241	<p data-bbox="287 241 976 275">Checking the operation of the switches of the finisher</p> <p data-bbox="287 309 440 342">Description</p> <p data-bbox="287 344 1414 378">Displays the status of each switches and sensors of 1000-sheet finisher or 4000-sheet finisher.</p> <p data-bbox="287 380 400 414">Purpose</p> <p data-bbox="287 416 1406 483">To check the operation of each switches and sensors of the 1000-sheet finisher or 4000-sheet finisher.</p> <p data-bbox="287 517 387 551">Method</p> <ol data-bbox="304 553 695 620" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be checked. <table border="1" data-bbox="336 631 1401 873"> <thead> <tr> <th data-bbox="336 631 639 676">Display</th> <th data-bbox="639 631 1401 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 676 639 721">Finisher</td> <td data-bbox="639 676 1401 721">Checking the switch and sensor of the document finisher</td> </tr> <tr> <td data-bbox="336 721 639 766">Mail Box</td> <td data-bbox="639 721 1401 766">Checking the switch and sensor of the mailbox</td> </tr> <tr> <td data-bbox="336 766 639 810">Booklet</td> <td data-bbox="639 766 1401 810">Checking the switch and sensor of the center-folding unit</td> </tr> <tr> <td data-bbox="336 810 639 873">Punch</td> <td data-bbox="639 810 1401 873">Checking the switch and sensor of the punch unit</td> </tr> </tbody> </table> <p data-bbox="287 913 526 947">Method: [Finisher]</p> <ol data-bbox="304 949 1398 1050" style="list-style-type: none"> 1. Turn each switch or sensor on and off manually to check the status. When the on-status of a switch or sensor is detected, that switch or sensor is displayed in reverse. <table border="1" data-bbox="336 1061 1401 1973"> <thead> <tr> <th data-bbox="336 1061 639 1106">Display</th> <th data-bbox="639 1061 1401 1106">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1106 639 1151">Front Cover</td> <td data-bbox="639 1106 1401 1151">DF front cover switch (DFFCSW)</td> </tr> <tr> <td data-bbox="336 1151 639 1196">MPT*1</td> <td data-bbox="639 1151 1401 1196">DF eject cover switch (DFECSW)</td> </tr> <tr> <td data-bbox="336 1196 639 1240">Top Cover*2</td> <td data-bbox="639 1196 1401 1240">DF top cover switch (DFTCSW)</td> </tr> <tr> <td data-bbox="336 1240 639 1285">Tray U-Limit*1</td> <td data-bbox="639 1240 1401 1285">DF tray sensor 1 (DFTS1)</td> </tr> <tr> <td data-bbox="336 1285 639 1330">Tray HP2</td> <td data-bbox="639 1285 1401 1330">DF tray sensor 2 (DFTS2)</td> </tr> <tr> <td data-bbox="336 1330 639 1375">Tray Middle</td> <td data-bbox="639 1330 1401 1375">DF tray sensor 3 (DFTS3)</td> </tr> <tr> <td data-bbox="336 1375 639 1420">Tray L-Limit</td> <td data-bbox="639 1375 1401 1420">DF tray sensor 4 (DFTS4)</td> </tr> <tr> <td data-bbox="336 1420 639 1464">Tray L-Limit(BL)</td> <td data-bbox="639 1420 1401 1464">DF tray sensor 5 (DFTS5)</td> </tr> <tr> <td data-bbox="336 1464 639 1509">Tray Top</td> <td data-bbox="639 1464 1401 1509">DF tray upper surface sensor (DFTUSS)</td> </tr> <tr> <td data-bbox="336 1509 639 1554">HP</td> <td data-bbox="639 1509 1401 1554">DF paper entry sensor (DFPES)</td> </tr> <tr> <td data-bbox="336 1554 639 1599">Sub Tray Eject*1</td> <td data-bbox="639 1554 1401 1599">DF sub eject sensor (DFSES)</td> </tr> <tr> <td data-bbox="336 1599 639 1644">Middle Tray Eject</td> <td data-bbox="639 1599 1401 1644">DF middle eject sensor (DFMES)</td> </tr> <tr> <td data-bbox="336 1644 639 1688">Drum*1</td> <td data-bbox="639 1644 1401 1688">DF drum sensor (DFDRS)</td> </tr> <tr> <td data-bbox="336 1688 639 1733">Staple HP</td> <td data-bbox="639 1688 1401 1733">DF slide sensor (DFSLS)</td> </tr> <tr> <td data-bbox="336 1733 639 1778">Middle Tray</td> <td data-bbox="639 1733 1401 1778">DF middle tray sensor (DFMTS)</td> </tr> <tr> <td data-bbox="336 1778 639 1823">Width Front HP</td> <td data-bbox="639 1778 1401 1823">DF side registration sensor 1 (DFSRS1)</td> </tr> <tr> <td data-bbox="336 1823 639 1868">Width Tail HP</td> <td data-bbox="639 1823 1401 1868">DF side registration sensor 2 (DFSRS2)</td> </tr> <tr> <td data-bbox="336 1868 639 1912">Bundle Eject HP</td> <td data-bbox="639 1868 1401 1912">DF bundle discharge sensor (DFBDS)</td> </tr> </tbody> </table>	Display	Description	Finisher	Checking the switch and sensor of the document finisher	Mail Box	Checking the switch and sensor of the mailbox	Booklet	Checking the switch and sensor of the center-folding unit	Punch	Checking the switch and sensor of the punch unit	Display	Description	Front Cover	DF front cover switch (DFFCSW)	MPT*1	DF eject cover switch (DFECSW)	Top Cover*2	DF top cover switch (DFTCSW)	Tray U-Limit*1	DF tray sensor 1 (DFTS1)	Tray HP2	DF tray sensor 2 (DFTS2)	Tray Middle	DF tray sensor 3 (DFTS3)	Tray L-Limit	DF tray sensor 4 (DFTS4)	Tray L-Limit(BL)	DF tray sensor 5 (DFTS5)	Tray Top	DF tray upper surface sensor (DFTUSS)	HP	DF paper entry sensor (DFPES)	Sub Tray Eject*1	DF sub eject sensor (DFSES)	Middle Tray Eject	DF middle eject sensor (DFMES)	Drum*1	DF drum sensor (DFDRS)	Staple HP	DF slide sensor (DFSLS)	Middle Tray	DF middle tray sensor (DFMTS)	Width Front HP	DF side registration sensor 1 (DFSRS1)	Width Tail HP	DF side registration sensor 2 (DFSRS2)	Bundle Eject HP	DF bundle discharge sensor (DFBDS)
Display	Description																																																
Finisher	Checking the switch and sensor of the document finisher																																																
Mail Box	Checking the switch and sensor of the mailbox																																																
Booklet	Checking the switch and sensor of the center-folding unit																																																
Punch	Checking the switch and sensor of the punch unit																																																
Display	Description																																																
Front Cover	DF front cover switch (DFFCSW)																																																
MPT*1	DF eject cover switch (DFECSW)																																																
Top Cover*2	DF top cover switch (DFTCSW)																																																
Tray U-Limit*1	DF tray sensor 1 (DFTS1)																																																
Tray HP2	DF tray sensor 2 (DFTS2)																																																
Tray Middle	DF tray sensor 3 (DFTS3)																																																
Tray L-Limit	DF tray sensor 4 (DFTS4)																																																
Tray L-Limit(BL)	DF tray sensor 5 (DFTS5)																																																
Tray Top	DF tray upper surface sensor (DFTUSS)																																																
HP	DF paper entry sensor (DFPES)																																																
Sub Tray Eject*1	DF sub eject sensor (DFSES)																																																
Middle Tray Eject	DF middle eject sensor (DFMES)																																																
Drum*1	DF drum sensor (DFDRS)																																																
Staple HP	DF slide sensor (DFSLS)																																																
Middle Tray	DF middle tray sensor (DFMTS)																																																
Width Front HP	DF side registration sensor 1 (DFSRS1)																																																
Width Tail HP	DF side registration sensor 2 (DFSRS2)																																																
Bundle Eject HP	DF bundle discharge sensor (DFBDS)																																																

Item No.	Description																																						
U241	<table border="1" data-bbox="336 286 1401 669"> <thead> <tr> <th data-bbox="336 286 639 331">Display</th> <th data-bbox="639 286 1401 331">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 331 639 376">Match Paddle*1</td> <td data-bbox="639 331 1401 376">DF adjustment sensor (DFADS)</td> </tr> <tr> <td data-bbox="336 376 639 421">Lead Paddle</td> <td data-bbox="639 376 1401 421">DF paddle sensor (DFPDS)</td> </tr> <tr> <td data-bbox="336 421 639 465">Shift Front HP*1</td> <td data-bbox="639 421 1401 465">DF shift sensor 1 (DFSFS1)</td> </tr> <tr> <td data-bbox="336 465 639 510">Shift Tail HP</td> <td data-bbox="639 465 1401 510">DF shift sensor 2 (DFSFS2)</td> </tr> <tr> <td data-bbox="336 510 639 555">Shift Unlock HP</td> <td data-bbox="639 510 1401 555">DF shift release sensor (DFSFRS)</td> </tr> <tr> <td data-bbox="336 555 639 600">Sub Tray Full</td> <td data-bbox="639 555 1401 600">DF sub tray full sensor (DFSTFS)</td> </tr> <tr> <td data-bbox="336 600 639 669">Shift Set</td> <td data-bbox="639 600 1401 669">DF shift set sensor (DFSFS)</td> </tr> </tbody> </table> <p data-bbox="288 678 967 707">*1: 4000-sheet finisher only. *2: 1000-sheet finisher only.</p> <p data-bbox="288 745 531 775">Method: [Mail Box]</p> <p data-bbox="304 781 1398 878">1. Turn each switch or sensor on and off manually to check the status. When the on-status of a switch or sensor is detected, that switch or sensor is displayed in reverse.</p> <table border="1" data-bbox="336 893 1401 1422"> <thead> <tr> <th data-bbox="336 893 639 938">Display</th> <th data-bbox="639 893 1401 938">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 938 639 983">Eject</td> <td data-bbox="639 938 1401 983">MB eject sensor (MBES)</td> </tr> <tr> <td data-bbox="336 983 639 1028">Cover</td> <td data-bbox="639 983 1401 1028">MB cover open/close switch (MBCOCSW)</td> </tr> <tr> <td data-bbox="336 1028 639 1072">Over Flow1</td> <td data-bbox="639 1028 1401 1072">MB overflow sensor 1 (MBOFS1)</td> </tr> <tr> <td data-bbox="336 1072 639 1117">Over Flow2</td> <td data-bbox="639 1072 1401 1117">MB overflow sensor 2 (MBOFS2)</td> </tr> <tr> <td data-bbox="336 1117 639 1162">Over Flow3</td> <td data-bbox="639 1117 1401 1162">MB overflow sensor 3 (MBOFS3)</td> </tr> <tr> <td data-bbox="336 1162 639 1207">Over Flow4</td> <td data-bbox="639 1162 1401 1207">MB overflow sensor 4 (MBOFS4)</td> </tr> <tr> <td data-bbox="336 1207 639 1252">Over Flow5</td> <td data-bbox="639 1207 1401 1252">MB overflow sensor 5 (MBOFS5)</td> </tr> <tr> <td data-bbox="336 1252 639 1296">Over Flow6</td> <td data-bbox="639 1252 1401 1296">MB overflow sensor 6 (MBOFS6)</td> </tr> <tr> <td data-bbox="336 1296 639 1341">Over Flow7</td> <td data-bbox="639 1296 1401 1341">MB overflow sensor 7 (MBOFS7)</td> </tr> <tr> <td data-bbox="336 1341 639 1422">Motor HP</td> <td data-bbox="639 1341 1401 1422">MB paper entry sensor (MBPES)</td> </tr> </tbody> </table>	Display	Description	Match Paddle*1	DF adjustment sensor (DFADS)	Lead Paddle	DF paddle sensor (DFPDS)	Shift Front HP*1	DF shift sensor 1 (DFSFS1)	Shift Tail HP	DF shift sensor 2 (DFSFS2)	Shift Unlock HP	DF shift release sensor (DFSFRS)	Sub Tray Full	DF sub tray full sensor (DFSTFS)	Shift Set	DF shift set sensor (DFSFS)	Display	Description	Eject	MB eject sensor (MBES)	Cover	MB cover open/close switch (MBCOCSW)	Over Flow1	MB overflow sensor 1 (MBOFS1)	Over Flow2	MB overflow sensor 2 (MBOFS2)	Over Flow3	MB overflow sensor 3 (MBOFS3)	Over Flow4	MB overflow sensor 4 (MBOFS4)	Over Flow5	MB overflow sensor 5 (MBOFS5)	Over Flow6	MB overflow sensor 6 (MBOFS6)	Over Flow7	MB overflow sensor 7 (MBOFS7)	Motor HP	MB paper entry sensor (MBPES)
Display	Description																																						
Match Paddle*1	DF adjustment sensor (DFADS)																																						
Lead Paddle	DF paddle sensor (DFPDS)																																						
Shift Front HP*1	DF shift sensor 1 (DFSFS1)																																						
Shift Tail HP	DF shift sensor 2 (DFSFS2)																																						
Shift Unlock HP	DF shift release sensor (DFSFRS)																																						
Sub Tray Full	DF sub tray full sensor (DFSTFS)																																						
Shift Set	DF shift set sensor (DFSFS)																																						
Display	Description																																						
Eject	MB eject sensor (MBES)																																						
Cover	MB cover open/close switch (MBCOCSW)																																						
Over Flow1	MB overflow sensor 1 (MBOFS1)																																						
Over Flow2	MB overflow sensor 2 (MBOFS2)																																						
Over Flow3	MB overflow sensor 3 (MBOFS3)																																						
Over Flow4	MB overflow sensor 4 (MBOFS4)																																						
Over Flow5	MB overflow sensor 5 (MBOFS5)																																						
Over Flow6	MB overflow sensor 6 (MBOFS6)																																						
Over Flow7	MB overflow sensor 7 (MBOFS7)																																						
Motor HP	MB paper entry sensor (MBPES)																																						



Item No.	Description																																												
U241	<p data-bbox="287 241 518 275">Method: [Booklet]</p> <p data-bbox="287 275 1396 376">1. Turn each switch or sensor on and off manually to check the status. When the on-status of a switch or sensor is detected, that switch or sensor is displayed in reverse.</p> <table border="1" data-bbox="335 387 1401 1059"> <thead> <tr> <th data-bbox="343 398 641 443">Display</th> <th data-bbox="641 398 1393 443">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 443 641 488">HP</td> <td data-bbox="641 443 1393 488">CF paper entry sensor (CFPES)</td> </tr> <tr> <td data-bbox="343 488 641 533">Eject</td> <td data-bbox="641 488 1393 533">CF eject sensor (CFES)</td> </tr> <tr> <td data-bbox="343 533 641 577">Paper</td> <td data-bbox="641 533 1393 577">CF paper sensor (CFPS)</td> </tr> <tr> <td data-bbox="343 577 641 622">Tray Full</td> <td data-bbox="641 577 1393 622">CF tray full sensor (CFTFS)</td> </tr> <tr> <td data-bbox="343 622 641 667">Bundle Up HP</td> <td data-bbox="641 622 1393 667">CF adjustment sensor 1 (CFADS1)</td> </tr> <tr> <td data-bbox="343 667 641 712">Bundle Down HP</td> <td data-bbox="641 667 1393 712">CF adjustment sensor 2 (CFADS2)</td> </tr> <tr> <td data-bbox="343 712 641 757">Width Up HP</td> <td data-bbox="641 712 1393 757">CF side registration sensor 1 (CFSRS1)</td> </tr> <tr> <td data-bbox="343 757 641 801">Width Down HP</td> <td data-bbox="641 757 1393 801">CF side registration sensor 2 (CFSRS2)</td> </tr> <tr> <td data-bbox="343 801 641 846">Blade HP</td> <td data-bbox="641 801 1393 846">CF blade sensor (CFBLS)</td> </tr> <tr> <td data-bbox="343 846 641 891">Tray</td> <td data-bbox="641 846 1393 891">CF tray switch (CFTSW)</td> </tr> <tr> <td data-bbox="343 891 641 936">Set</td> <td data-bbox="641 891 1393 936">CF set switch (CFSSW)</td> </tr> <tr> <td data-bbox="343 936 641 981">Left Guide</td> <td data-bbox="641 936 1393 981">CF left guide switch (CFLGSW)</td> </tr> <tr> <td data-bbox="343 981 641 1025">Vertical Feed</td> <td data-bbox="641 981 1393 1025">CF paper conveying sensor (CFPCS)</td> </tr> </tbody> </table> <p data-bbox="287 1104 502 1137">Method: [Punch]</p> <p data-bbox="287 1137 1396 1238">1. Turn each switch or sensor on and off manually to check the status. When the on-status of a switch or sensor is detected, that switch or sensor is displayed in reverse.</p> <table border="1" data-bbox="335 1249 1401 1630"> <thead> <tr> <th data-bbox="343 1261 641 1305">Display</th> <th data-bbox="641 1261 1393 1305">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 1305 641 1350">Punch HP</td> <td data-bbox="641 1305 1393 1350">Punch home position sensor (PUHPS)</td> </tr> <tr> <td data-bbox="343 1350 641 1395">Edge Face1</td> <td data-bbox="641 1350 1393 1395">Punch paper edge sensor (PUPES)</td> </tr> <tr> <td data-bbox="343 1395 641 1440">Edge Face2</td> <td data-bbox="641 1395 1393 1440">Punch paper edge sensor (PUPES)</td> </tr> <tr> <td data-bbox="343 1440 641 1485">Edge Face3</td> <td data-bbox="641 1440 1393 1485">Punch paper edge sensor (PUPES)</td> </tr> <tr> <td data-bbox="343 1485 641 1529">Edge Face4</td> <td data-bbox="641 1485 1393 1529">Punch paper edge sensor (PUPES)</td> </tr> <tr> <td data-bbox="343 1529 641 1574">Tank</td> <td data-bbox="641 1529 1393 1574">Punch tank set switch (PUTSSW)</td> </tr> <tr> <td data-bbox="343 1574 641 1619">Tank Full</td> <td data-bbox="641 1574 1393 1619">Punch tank full sensor (PUTFS)</td> </tr> </tbody> </table> <p data-bbox="287 1675 438 1709">Completion</p> <p data-bbox="287 1709 1252 1742">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	HP	CF paper entry sensor (CFPES)	Eject	CF eject sensor (CFES)	Paper	CF paper sensor (CFPS)	Tray Full	CF tray full sensor (CFTFS)	Bundle Up HP	CF adjustment sensor 1 (CFADS1)	Bundle Down HP	CF adjustment sensor 2 (CFADS2)	Width Up HP	CF side registration sensor 1 (CFSRS1)	Width Down HP	CF side registration sensor 2 (CFSRS2)	Blade HP	CF blade sensor (CFBLS)	Tray	CF tray switch (CFTSW)	Set	CF set switch (CFSSW)	Left Guide	CF left guide switch (CFLGSW)	Vertical Feed	CF paper conveying sensor (CFPCS)	Display	Description	Punch HP	Punch home position sensor (PUHPS)	Edge Face1	Punch paper edge sensor (PUPES)	Edge Face2	Punch paper edge sensor (PUPES)	Edge Face3	Punch paper edge sensor (PUPES)	Edge Face4	Punch paper edge sensor (PUPES)	Tank	Punch tank set switch (PUTSSW)	Tank Full	Punch tank full sensor (PUTFS)
Display	Description																																												
HP	CF paper entry sensor (CFPES)																																												
Eject	CF eject sensor (CFES)																																												
Paper	CF paper sensor (CFPS)																																												
Tray Full	CF tray full sensor (CFTFS)																																												
Bundle Up HP	CF adjustment sensor 1 (CFADS1)																																												
Bundle Down HP	CF adjustment sensor 2 (CFADS2)																																												
Width Up HP	CF side registration sensor 1 (CFSRS1)																																												
Width Down HP	CF side registration sensor 2 (CFSRS2)																																												
Blade HP	CF blade sensor (CFBLS)																																												
Tray	CF tray switch (CFTSW)																																												
Set	CF set switch (CFSSW)																																												
Left Guide	CF left guide switch (CFLGSW)																																												
Vertical Feed	CF paper conveying sensor (CFPCS)																																												
Display	Description																																												
Punch HP	Punch home position sensor (PUHPS)																																												
Edge Face1	Punch paper edge sensor (PUPES)																																												
Edge Face2	Punch paper edge sensor (PUPES)																																												
Edge Face3	Punch paper edge sensor (PUPES)																																												
Edge Face4	Punch paper edge sensor (PUPES)																																												
Tank	Punch tank set switch (PUTSSW)																																												
Tank Full	Punch tank full sensor (PUTFS)																																												


Item No.	Description																						
U243	<p data-bbox="287 241 813 275">Checking the operation of the DP motors</p> <p data-bbox="287 309 438 342">Description</p> <p data-bbox="287 344 805 378">Turns the motors or solenoids in the DP on.</p> <p data-bbox="287 380 399 414">Purpose</p> <p data-bbox="287 416 949 450">To check the operation of the DP motors and solenoids.</p> <p data-bbox="287 483 391 517">Method</p> <ol data-bbox="303 519 813 620" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be operated. 3. Press the start key. The operation starts. <table border="1" data-bbox="335 631 1401 1158"> <thead> <tr> <th data-bbox="343 642 641 676">Display</th> <th data-bbox="641 642 1393 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 687 641 721">Feed Motor</td> <td data-bbox="641 687 1393 721">DP original feed motor (DPOFM) is turned on</td> </tr> <tr> <td data-bbox="343 732 641 766">Conv Motor</td> <td data-bbox="641 732 1393 766">DP original conveying motor (DPOCM) is turned on</td> </tr> <tr> <td data-bbox="343 777 641 810">Rev Motor*1</td> <td data-bbox="641 777 1393 810">DP switchback motor (DPSBM) is turned on</td> </tr> <tr> <td data-bbox="343 822 641 855">Lift Motor</td> <td data-bbox="641 822 1393 855">DP lift motor (DPLM) is turned on</td> </tr> <tr> <td data-bbox="343 866 641 900">Rev Press Sol*1</td> <td data-bbox="641 866 1393 900">DP pressure solenoid (DPPSOL) is turned on</td> </tr> <tr> <td data-bbox="343 911 641 945">Rev Branch Sol*1</td> <td data-bbox="641 911 1393 945">DP feedshift solenoid (DPFSSOL) is turned on</td> </tr> <tr> <td data-bbox="343 956 641 990">Eject Motor*2</td> <td data-bbox="641 956 1393 990">DP eject motor (DPEM) is turned on</td> </tr> <tr> <td data-bbox="343 1001 641 1034">Regist Motor*2</td> <td data-bbox="641 1001 1393 1034">DP registration motor (DPRM) is turned on</td> </tr> <tr> <td data-bbox="343 1046 641 1079">DP Fan*2</td> <td data-bbox="641 1046 1393 1079">DP fan motor 1 (DPFM1) is turned on</td> </tr> <tr> <td data-bbox="343 1090 641 1124">CIS Fan*2</td> <td data-bbox="641 1090 1393 1124">DP fan motor 2 (DPFM2) is turned on</td> </tr> </tbody> </table> <p data-bbox="335 1169 877 1202">*1: Reversed DP only. *2: Dual scan DP only.</p> <ol data-bbox="303 1205 829 1238" style="list-style-type: none"> 4. To turn each motor off, press the stop key. <p data-bbox="287 1272 438 1305">Completion</p> <p data-bbox="287 1308 1433 1375">Press the stop key when operation stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Feed Motor	DP original feed motor (DPOFM) is turned on	Conv Motor	DP original conveying motor (DPOCM) is turned on	Rev Motor*1	DP switchback motor (DPSBM) is turned on	Lift Motor	DP lift motor (DPLM) is turned on	Rev Press Sol*1	DP pressure solenoid (DPPSOL) is turned on	Rev Branch Sol*1	DP feedshift solenoid (DPFSSOL) is turned on	Eject Motor*2	DP eject motor (DPEM) is turned on	Regist Motor*2	DP registration motor (DPRM) is turned on	DP Fan*2	DP fan motor 1 (DPFM1) is turned on	CIS Fan*2	DP fan motor 2 (DPFM2) is turned on
Display	Description																						
Feed Motor	DP original feed motor (DPOFM) is turned on																						
Conv Motor	DP original conveying motor (DPOCM) is turned on																						
Rev Motor*1	DP switchback motor (DPSBM) is turned on																						
Lift Motor	DP lift motor (DPLM) is turned on																						
Rev Press Sol*1	DP pressure solenoid (DPPSOL) is turned on																						
Rev Branch Sol*1	DP feedshift solenoid (DPFSSOL) is turned on																						
Eject Motor*2	DP eject motor (DPEM) is turned on																						
Regist Motor*2	DP registration motor (DPRM) is turned on																						
DP Fan*2	DP fan motor 1 (DPFM1) is turned on																						
CIS Fan*2	DP fan motor 2 (DPFM2) is turned on																						



Item No.	Description																												
U244	<p data-bbox="288 241 625 271">Checking the DP switches</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1102 374">Displays the status of the respective switches and sensors in the DP.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1139 443">To check if respective switches and sensors in the DP operate correctly.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="304 517 1398 649" style="list-style-type: none"> 1. Press the start key. 2. Turn each switch or sensor on and off manually to check the status. When the on-status of a switch or sensor is detected, that switch or sensor is displayed in reverse. <table border="1" data-bbox="336 665 1398 1337"> <thead> <tr> <th data-bbox="336 665 639 710">Display</th> <th data-bbox="639 665 1398 710">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 710 639 754">Feed</td> <td data-bbox="639 710 1398 754">DP feed sensor (DPFS)</td> </tr> <tr> <td data-bbox="336 754 639 799">Regist^{*1}</td> <td data-bbox="639 754 1398 799">DP registration sensor (DPRS)</td> </tr> <tr> <td data-bbox="336 799 639 844">Timing</td> <td data-bbox="639 799 1398 844">DP timing sensor (DPTS)</td> </tr> <tr> <td data-bbox="336 844 639 889">CIS Head^{*2}</td> <td data-bbox="639 844 1398 889">DP CIS sensor (DPCS)</td> </tr> <tr> <td data-bbox="336 889 639 934">Tray^{*1}</td> <td data-bbox="639 889 1398 934">DP switchback sensor (DPSBS)</td> </tr> <tr> <td data-bbox="336 934 639 978">Set</td> <td data-bbox="639 934 1398 978">DP original sensor (DPOS)</td> </tr> <tr> <td data-bbox="336 978 639 1023">Longitudinal</td> <td data-bbox="639 978 1398 1023">DP original length switch (DPOLSW)</td> </tr> <tr> <td data-bbox="336 1023 639 1068">Lift U-Limit</td> <td data-bbox="639 1023 1398 1068">DP lift sensor 1 (DPLS1)</td> </tr> <tr> <td data-bbox="336 1068 639 1113">Lift L-Limit</td> <td data-bbox="639 1068 1398 1113">DP lift sensor 2 (DPLS2)</td> </tr> <tr> <td data-bbox="336 1113 639 1158">Cover Open</td> <td data-bbox="639 1113 1398 1158">DP interlock switch (DPILSW)</td> </tr> <tr> <td data-bbox="336 1158 639 1202">Open</td> <td data-bbox="639 1158 1398 1202">DP open/close switch (DPOCSW)</td> </tr> <tr> <td data-bbox="336 1202 639 1247">Eject</td> <td data-bbox="639 1202 1398 1247">DP eject sensor (DPES)</td> </tr> <tr> <td data-bbox="336 1247 639 1292">Slant^{*2}</td> <td data-bbox="639 1247 1398 1292">DP slant sensor (DPSS)</td> </tr> </tbody> </table> <p data-bbox="336 1346 879 1375">*1: Reversed DP only. *2: Dual scan DP only.</p> <p data-bbox="288 1415 440 1444">Completion</p> <p data-bbox="288 1449 1254 1478">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Feed	DP feed sensor (DPFS)	Regist ^{*1}	DP registration sensor (DPRS)	Timing	DP timing sensor (DPTS)	CIS Head ^{*2}	DP CIS sensor (DPCS)	Tray ^{*1}	DP switchback sensor (DPSBS)	Set	DP original sensor (DPOS)	Longitudinal	DP original length switch (DPOLSW)	Lift U-Limit	DP lift sensor 1 (DPLS1)	Lift L-Limit	DP lift sensor 2 (DPLS2)	Cover Open	DP interlock switch (DPILSW)	Open	DP open/close switch (DPOCSW)	Eject	DP eject sensor (DPES)	Slant ^{*2}	DP slant sensor (DPSS)
Display	Description																												
Feed	DP feed sensor (DPFS)																												
Regist ^{*1}	DP registration sensor (DPRS)																												
Timing	DP timing sensor (DPTS)																												
CIS Head ^{*2}	DP CIS sensor (DPCS)																												
Tray ^{*1}	DP switchback sensor (DPSBS)																												
Set	DP original sensor (DPOS)																												
Longitudinal	DP original length switch (DPOLSW)																												
Lift U-Limit	DP lift sensor 1 (DPLS1)																												
Lift L-Limit	DP lift sensor 2 (DPLS2)																												
Cover Open	DP interlock switch (DPILSW)																												
Open	DP open/close switch (DPOCSW)																												
Eject	DP eject sensor (DPES)																												
Slant ^{*2}	DP slant sensor (DPSS)																												

Item No.	Description
U245	<p data-bbox="287 241 550 275">Checking messages</p> <p data-bbox="287 309 438 342">Description</p> <p data-bbox="287 344 1114 378">Displays a list of messages on the touch panel of the operation panel.</p> <p data-bbox="287 380 399 414">Purpose</p> <p data-bbox="287 416 766 450">To check the messages to be displayed.</p> <p data-bbox="287 483 391 517">Method</p> <ol data-bbox="303 519 1428 689" style="list-style-type: none"><li data-bbox="303 519 566 553">1. Press the start key.<li data-bbox="303 555 1428 656">2. Change the message using the cursor up/down keys. When a message number is entered with the numeric keys and then the start key is pressed, the message corresponding the specified number is displayed.<li data-bbox="303 658 821 689">3. Change the language using the +/- keys. <p data-bbox="287 723 438 757">Completion</p> <p data-bbox="287 759 1252 792">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>



Item No.	Description																								
U246	<p>Setting the finisher</p> <p>Description Provides various settings for the 1000-sheet finisher or 4000-sheet finisher, if furnished.</p> <p>Purpose</p> <p>Adjustment of registration stop timing in punch mode Adjust if skewed paper conveying occurs or if the copy paper is Z-folded in punch mode.</p> <p>Adjustment of paper stop timing in the punch mode To adjust this item when the position of a punch hole is different from the specified one.</p> <p>Adjustment of center position timing in the punch mode Adjusts the center position of a punch hole in punch mode if the position is not proper.</p> <p>Adjustment of front/rear side registration home position Provides optimization when paper jam occurs due to an inferior fitting of the side registration guides to paper.</p> <p>Adjustment of front/rear shift home position Performed when adjustment is lost with the ejected paper</p> <p>Adjusting of front/back stapling home position Adjusts the stapling position in the staple mode if the position is not proper.</p> <p>Adjustment of upper/lower side registration home position Provides optimization when paper jam occurs due to an inferior fitting of the side registration guides to paper.</p> <p>Adjustment of booklet stapling position Adjusts the booklet stapling position in the stitching mode if the position is not proper.</p> <p>Adjustment of center folding position Adjusts the center folding position in the stitching mode if the position is not proper.</p> <p>Adjustment of tri- folding position Adjusts the tri-folding position in the stitching mode if the position is not proper.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to set. <table border="1" data-bbox="336 1323 1401 1467"> <thead> <tr> <th data-bbox="336 1323 643 1368">Display</th> <th data-bbox="643 1323 1401 1368">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1368 643 1413">Finisher</td> <td data-bbox="643 1368 1401 1413">Adjustment of 1000-sheet finisher and 4000-sheet finisher</td> </tr> <tr> <td data-bbox="336 1413 643 1467">Booklet</td> <td data-bbox="643 1413 1401 1467">Adjustment of center-folding unit</td> </tr> </tbody> </table> <p>Method: [Finisher]</p> <ol style="list-style-type: none"> 1. Select the item to set. <table border="1" data-bbox="336 1590 1401 2022"> <thead> <tr> <th data-bbox="336 1590 643 1635">Display</th> <th data-bbox="643 1590 1401 1635">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1635 643 1680">Punch Regist</td> <td data-bbox="643 1635 1401 1680">Adjustment of registration stop timing in punch mode</td> </tr> <tr> <td data-bbox="336 1680 643 1724">Punch Feed</td> <td data-bbox="643 1680 1401 1724">Adjustment of the paper stop timing in punch mode</td> </tr> <tr> <td data-bbox="336 1724 643 1769">Punch Width</td> <td data-bbox="643 1724 1401 1769">Adjustment of the center position timing in punch mode</td> </tr> <tr> <td data-bbox="336 1769 643 1814">Width Front HP</td> <td data-bbox="643 1769 1401 1814">Adjustment of front side registration home position</td> </tr> <tr> <td data-bbox="336 1814 643 1859">Width Tail HP</td> <td data-bbox="643 1814 1401 1859">Adjustment of rear side registration home position</td> </tr> <tr> <td data-bbox="336 1859 643 1904">Shift Front HP</td> <td data-bbox="643 1859 1401 1904">Adjustment of front shift home position</td> </tr> <tr> <td data-bbox="336 1904 643 1948">Shift Tail HP</td> <td data-bbox="643 1904 1401 1948">Adjustment of rear shift home position</td> </tr> <tr> <td data-bbox="336 1948 643 2022">Staple HP</td> <td data-bbox="643 1948 1401 2022">Adjustment of front and back stapling home position</td> </tr> </tbody> </table>	Display	Description	Finisher	Adjustment of 1000-sheet finisher and 4000-sheet finisher	Booklet	Adjustment of center-folding unit	Display	Description	Punch Regist	Adjustment of registration stop timing in punch mode	Punch Feed	Adjustment of the paper stop timing in punch mode	Punch Width	Adjustment of the center position timing in punch mode	Width Front HP	Adjustment of front side registration home position	Width Tail HP	Adjustment of rear side registration home position	Shift Front HP	Adjustment of front shift home position	Shift Tail HP	Adjustment of rear shift home position	Staple HP	Adjustment of front and back stapling home position
Display	Description																								
Finisher	Adjustment of 1000-sheet finisher and 4000-sheet finisher																								
Booklet	Adjustment of center-folding unit																								
Display	Description																								
Punch Regist	Adjustment of registration stop timing in punch mode																								
Punch Feed	Adjustment of the paper stop timing in punch mode																								
Punch Width	Adjustment of the center position timing in punch mode																								
Width Front HP	Adjustment of front side registration home position																								
Width Tail HP	Adjustment of rear side registration home position																								
Shift Front HP	Adjustment of front shift home position																								
Shift Tail HP	Adjustment of rear shift home position																								
Staple HP	Adjustment of front and back stapling home position																								

Item No.	Description																
U246	<p data-bbox="288 241 587 271">Setting: [Punch Regist]</p> <ol data-bbox="288 277 1054 342" style="list-style-type: none"> <li data-bbox="288 277 600 306">1. Select [Punch Regist]. <li data-bbox="288 311 1054 342">2. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 353 1401 483"> <thead> <tr> <th data-bbox="336 353 906 439">Description</th> <th data-bbox="906 353 1059 439">Setting range</th> <th data-bbox="1059 353 1195 439">Initial setting</th> <th data-bbox="1195 353 1401 439">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 439 906 483">Adjustment of registration stop timing</td> <td data-bbox="906 439 1059 483">-20 to 20</td> <td data-bbox="1059 439 1195 483">0</td> <td data-bbox="1195 439 1401 483">0.25 mm</td> </tr> </tbody> </table> <p data-bbox="336 495 1426 555">If skewed paper conveying occurs (sample 1), increase the setting value. If the copy paper is Z-folded (sample 2), decrease the setting value.</p> <div data-bbox="671 577 1059 813" style="text-align: center;">  <p data-bbox="687 786 791 813">Sample 1</p> <p data-bbox="948 786 1054 813">Sample 2</p> </div> <p data-bbox="775 842 946 871" style="text-align: center;">Figure 1-3-18</p> <ol data-bbox="288 913 767 943" style="list-style-type: none"> <li data-bbox="288 913 767 943">3. Press the start key. The value is set. <p data-bbox="288 981 568 1010">Setting: [Punch Feed]</p> <ol data-bbox="288 1016 1054 1081" style="list-style-type: none"> <li data-bbox="288 1016 584 1046">1. Select [Punch Feed]. <li data-bbox="288 1050 1054 1081">2. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 1093 1401 1223"> <thead> <tr> <th data-bbox="336 1093 906 1178">Description</th> <th data-bbox="906 1093 1059 1178">Setting range</th> <th data-bbox="1059 1093 1195 1178">Initial setting</th> <th data-bbox="1195 1093 1401 1178">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1178 906 1223">Adjustment of the paper stop timing</td> <td data-bbox="906 1178 1059 1223">-10 to 10</td> <td data-bbox="1059 1178 1195 1223">0</td> <td data-bbox="1195 1178 1401 1223">0.52 mm</td> </tr> </tbody> </table> <p data-bbox="336 1234 1426 1294">If the distance of the position of a punch hole is smaller than the specified value A, increase the setting value. If the distance is larger than the value A, decrease the setting value.</p> <div data-bbox="448 1317 1270 1552" style="text-align: center;">  <p data-bbox="938 1480 1270 1541">Preset value A: 13 mm (metric) 9.5 mm (inch)</p> </div> <p data-bbox="775 1581 946 1610" style="text-align: center;">Figure 1-3-19</p> <ol data-bbox="288 1653 767 1682" style="list-style-type: none"> <li data-bbox="288 1653 767 1682">3. Press the start key. The value is set. 	Description	Setting range	Initial setting	Change in value per step	Adjustment of registration stop timing	-20 to 20	0	0.25 mm	Description	Setting range	Initial setting	Change in value per step	Adjustment of the paper stop timing	-10 to 10	0	0.52 mm
Description	Setting range	Initial setting	Change in value per step														
Adjustment of registration stop timing	-20 to 20	0	0.25 mm														
Description	Setting range	Initial setting	Change in value per step														
Adjustment of the paper stop timing	-10 to 10	0	0.52 mm														

Item No.	Description																																
U246	<p>Setting: [Punch Width]</p> <ol style="list-style-type: none"> 1. Select [Punch Width]. 2. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 353 1401 483"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of the punch center position timing</td> <td>-4 to 4</td> <td>0</td> <td>0.52 mm</td> </tr> </tbody> </table> <p>If the punch hole is too close to the front of the machine, increase the setting value. If the punch hole is too close to the rear of the machine, decrease the setting value.</p>  <p style="text-align: center;">Figure 1-3-20</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Setting: [Width Front HP/Width Tail HP]</p> <ol style="list-style-type: none"> 1. Select [Width Front HP] or [Width Tail HP]. 2. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 1108 1401 1285"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of front side registration home position</td> <td>-15 to 15</td> <td>0</td> <td>0.19 mm</td> </tr> <tr> <td>Adjustment of rear side registration home position</td> <td>-15 to 15</td> <td>0</td> <td>0.19 mm</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The value is set. 4. Press the stop key. The screen for selecting a maintenance item No. is displayed. 5. Enter maintenance mode U240 and select [Motor], then [Width Test(A3)]. The width guides of the middle tray will move to A3-size position. 6. Pull the middle tray, insert paper between the guides and check that paper is about the guides. 7. Repeat the above adjustment until paper is properly in position. <p>Setting: [Shift Front HP/Shift Tail HP]</p> <ol style="list-style-type: none"> 1. Select [Shift Front HP] or [Shift Tail HP]. 2. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 1648 1401 1825"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of front shift home position</td> <td>-15 to 15</td> <td>0</td> <td>0.19 mm</td> </tr> <tr> <td>Adjustment of rear shift home position</td> <td>-15 to 15</td> <td>0</td> <td>0.19 mm</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The value is set. 4. Press the stop key. The screen for selecting a maintenance item No. is displayed. 5. Enter maintenance mode U240 and select [Motor], then [Sort Test]. 6. Repeat the above adjustment until eject paper is properly in position. 	Description	Setting range	Initial setting	Change in value per step	Adjustment of the punch center position timing	-4 to 4	0	0.52 mm	Description	Setting range	Initial setting	Change in value per step	Adjustment of front side registration home position	-15 to 15	0	0.19 mm	Adjustment of rear side registration home position	-15 to 15	0	0.19 mm	Description	Setting range	Initial setting	Change in value per step	Adjustment of front shift home position	-15 to 15	0	0.19 mm	Adjustment of rear shift home position	-15 to 15	0	0.19 mm
Description	Setting range	Initial setting	Change in value per step																														
Adjustment of the punch center position timing	-4 to 4	0	0.52 mm																														
Description	Setting range	Initial setting	Change in value per step																														
Adjustment of front side registration home position	-15 to 15	0	0.19 mm																														
Adjustment of rear side registration home position	-15 to 15	0	0.19 mm																														
Description	Setting range	Initial setting	Change in value per step																														
Adjustment of front shift home position	-15 to 15	0	0.19 mm																														
Adjustment of rear shift home position	-15 to 15	0	0.19 mm																														

Item No.	Description																												
<p>U246</p>	<p>Setting: [Staple HP]</p> <ol style="list-style-type: none"> 1. Select [Staple HP]. 2. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 353 1401 488"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of front and back stapling home position</td> <td>-15 to 15</td> <td>0</td> <td>0.19 mm</td> </tr> </tbody> </table> <p>When staple positions are off toward the front side of the machine (sample 1), increase the setting value. When staple positions are off toward the rear side of the machine (sample 2), decrease the setting value.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Sample 1</p> </div> <div style="text-align: center;">  <p>Sample 2</p> </div> </div> <p style="text-align: center;">Figure 1-3-21</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Method: [Booklet]</p> <ol style="list-style-type: none"> 1. Select the item to set. <table border="1" data-bbox="336 1115 1401 1597"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Width Up HP</td> <td>Adjustment of upper side registration home position</td> </tr> <tr> <td>Width Down HP</td> <td>Adjustment of lower side registration home position</td> </tr> <tr> <td>Staple Pos1</td> <td>Adjustment of booklet stapling position for A4/Letter size</td> </tr> <tr> <td>Staple Pos2</td> <td>Adjustment of booklet stapling position for B4/Legal size</td> </tr> <tr> <td>Staple Pos3</td> <td>Adjustment of booklet stapling position for A3/Ledger/8K size</td> </tr> <tr> <td>Booklet Pos1</td> <td>Adjustment of center folding position for A4/Letter size</td> </tr> <tr> <td>Booklet Pos2</td> <td>Adjustment of center folding position for B4/Legal size</td> </tr> <tr> <td>Booklet Pos3</td> <td>Adjustment of center folding position for A3/Ledger/8K size</td> </tr> <tr> <td>Three Fold</td> <td>Adjustment of tri-folding position</td> </tr> </tbody> </table>	Description	Setting range	Initial setting	Change in value per step	Adjustment of front and back stapling home position	-15 to 15	0	0.19 mm	Display	Description	Width Up HP	Adjustment of upper side registration home position	Width Down HP	Adjustment of lower side registration home position	Staple Pos1	Adjustment of booklet stapling position for A4/Letter size	Staple Pos2	Adjustment of booklet stapling position for B4/Legal size	Staple Pos3	Adjustment of booklet stapling position for A3/Ledger/8K size	Booklet Pos1	Adjustment of center folding position for A4/Letter size	Booklet Pos2	Adjustment of center folding position for B4/Legal size	Booklet Pos3	Adjustment of center folding position for A3/Ledger/8K size	Three Fold	Adjustment of tri-folding position
Description	Setting range	Initial setting	Change in value per step																										
Adjustment of front and back stapling home position	-15 to 15	0	0.19 mm																										
Display	Description																												
Width Up HP	Adjustment of upper side registration home position																												
Width Down HP	Adjustment of lower side registration home position																												
Staple Pos1	Adjustment of booklet stapling position for A4/Letter size																												
Staple Pos2	Adjustment of booklet stapling position for B4/Legal size																												
Staple Pos3	Adjustment of booklet stapling position for A3/Ledger/8K size																												
Booklet Pos1	Adjustment of center folding position for A4/Letter size																												
Booklet Pos2	Adjustment of center folding position for B4/Legal size																												
Booklet Pos3	Adjustment of center folding position for A3/Ledger/8K size																												
Three Fold	Adjustment of tri-folding position																												

Item No.	Description																												
U246	<p data-bbox="288 241 783 275">Setting: [Width Up HP/Width Down HP]</p> <ol data-bbox="288 277 1054 342" style="list-style-type: none"> 1. Select [Width Up HP] or [Width Down HP]. 2. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 353 1401 533"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of upper side registration home position</td> <td>-15 to 15</td> <td>0</td> <td>0.34 mm</td> </tr> <tr> <td>Adjustment of lower side registration home position</td> <td>-15 to 15</td> <td>0</td> <td>0.34 mm</td> </tr> </tbody> </table> <ol data-bbox="288 544 1426 779" style="list-style-type: none"> 3. Press the start key. The value is set. 4. Press the stop key. The screen for selecting a maintenance item No. is displayed. 5. Enter maintenance mode U240 and select [Booklet], then [Width Test(A3)]. The width guides of the center-folding unit will move to A3-size position. 6. Pull the center-folding unit, insert paper between the guides and check that paper is about the guides. 7. Repeat the above adjustment until paper is properly in position. <p data-bbox="288 817 552 851">Setting: [Staple Pos]</p> <ol data-bbox="288 853 1054 918" style="list-style-type: none"> 1. Select [Staple Pos1], [Staple Pos2] or [Staple Pos3]. 2. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 929 1401 1261"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of booklet stapling position for A4/Letter size</td> <td>-15 to 15</td> <td>0</td> <td>0.32 mm</td> </tr> <tr> <td>Adjustment of booklet stapling position for B4/Legal size</td> <td>-15 to 15</td> <td>0</td> <td>0.32 mm</td> </tr> <tr> <td>Adjustment of booklet stapling position for A3/Ledger/8K size</td> <td>-15 to 15</td> <td>0</td> <td>0.32 mm</td> </tr> </tbody> </table> <p data-bbox="333 1272 1409 1337">When staples are placed too far right (sample 1), decrease the preset value. When staples are placed too far left (sample 2), increase the preset value.</p> <p data-bbox="333 1339 713 1373">Reference value: within ± 2 mm</p> <div data-bbox="403 1397 1315 1671" style="text-align: center;"> </div> <p data-bbox="775 1700 946 1733">Figure 1-3-22</p> <ol data-bbox="288 1771 767 1805" style="list-style-type: none"> 3. Press the start key. The value is set. 	Description	Setting range	Initial setting	Change in value per step	Adjustment of upper side registration home position	-15 to 15	0	0.34 mm	Adjustment of lower side registration home position	-15 to 15	0	0.34 mm	Description	Setting range	Initial setting	Change in value per step	Adjustment of booklet stapling position for A4/Letter size	-15 to 15	0	0.32 mm	Adjustment of booklet stapling position for B4/Legal size	-15 to 15	0	0.32 mm	Adjustment of booklet stapling position for A3/Ledger/8K size	-15 to 15	0	0.32 mm
Description	Setting range	Initial setting	Change in value per step																										
Adjustment of upper side registration home position	-15 to 15	0	0.34 mm																										
Adjustment of lower side registration home position	-15 to 15	0	0.34 mm																										
Description	Setting range	Initial setting	Change in value per step																										
Adjustment of booklet stapling position for A4/Letter size	-15 to 15	0	0.32 mm																										
Adjustment of booklet stapling position for B4/Legal size	-15 to 15	0	0.32 mm																										
Adjustment of booklet stapling position for A3/Ledger/8K size	-15 to 15	0	0.32 mm																										

Item No.	Description																								
<p>U246</p>	<p>Setting: [Booklet Pos]</p> <ol style="list-style-type: none"> 1. Select [Booklet Pos1], [Booklet Pos2] or [Booklet Pos3]. 2. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 353 1401 616"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of center folding position for A4/Letter size</td> <td>-15 to 15</td> <td>0</td> <td>0.32 mm</td> </tr> <tr> <td>Adjustment of center folding position for B4/Legal size</td> <td>-15 to 15</td> <td>0</td> <td>0.32 mm</td> </tr> <tr> <td>Adjustment of center folding position for A3/Ledger/8K size</td> <td>-15 to 15</td> <td>0</td> <td>0.32 mm</td> </tr> </tbody> </table> <p>When the centerfold position too far right (sample 1), increase the preset value. When the centerfold position too far left (sample 2), decrease the setting value.</p> <p>Reference value A: A4, Letter: Length of paper × 1/2 ± 2 mm A3, Ledger, B4: Length of paper × 1/2 ± 3 mm</p>  <p style="text-align: center;">Figure 1-3-23</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Setting: [Three Fold]</p> <ol style="list-style-type: none"> 1. Select [Three Fold]. 2. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 1279 1401 1413"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of tri-folding position</td> <td>-15 to 15</td> <td>0</td> <td>0.32 mm</td> </tr> </tbody> </table> <p>When the tri-fold position too far right (sample 1), increase the preset value. When the tri-fold position too far left (sample 2), decrease the setting value.</p> <p>Reference value A: 7.0 ± 2 mm</p>  <p style="text-align: center;">Figure 1-3-24</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Change in value per step	Adjustment of center folding position for A4/Letter size	-15 to 15	0	0.32 mm	Adjustment of center folding position for B4/Legal size	-15 to 15	0	0.32 mm	Adjustment of center folding position for A3/Ledger/8K size	-15 to 15	0	0.32 mm	Description	Setting range	Initial setting	Change in value per step	Adjustment of tri-folding position	-15 to 15	0	0.32 mm
Description	Setting range	Initial setting	Change in value per step																						
Adjustment of center folding position for A4/Letter size	-15 to 15	0	0.32 mm																						
Adjustment of center folding position for B4/Legal size	-15 to 15	0	0.32 mm																						
Adjustment of center folding position for A3/Ledger/8K size	-15 to 15	0	0.32 mm																						
Description	Setting range	Initial setting	Change in value per step																						
Adjustment of tri-folding position	-15 to 15	0	0.32 mm																						

Item No.	Description																																			
U247	<p data-bbox="288 241 663 273">Setting the paper feed device</p> <p data-bbox="288 311 440 342">Description</p> <p data-bbox="288 344 911 376">Turns on motor and clutches of paper feeder device.</p> <p data-bbox="288 383 400 414">Purpose</p> <p data-bbox="288 416 1078 448">To check the operation of motor and clutches of paper feed device.</p> <p data-bbox="288 486 387 517">Method</p> <ol data-bbox="304 519 683 584" style="list-style-type: none"> 1. Press the start key. 2. Select the paper feed device. <table border="1" data-bbox="336 598 1401 934"> <thead> <tr> <th data-bbox="336 598 639 645">Display</th> <th data-bbox="639 598 1401 645">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 645 639 692">2PF</td> <td data-bbox="639 645 1401 692">Paper feeder</td> </tr> <tr> <td data-bbox="336 692 639 739">LCF</td> <td data-bbox="639 692 1401 739">Large capacity feeder</td> </tr> <tr> <td data-bbox="336 739 639 786">Side Deck</td> <td data-bbox="639 739 1401 786">Side deck</td> </tr> <tr> <td data-bbox="336 786 639 833">SMT</td> <td data-bbox="639 786 1401 833">Side multi tray</td> </tr> <tr> <td data-bbox="336 833 639 880">Side 2PF</td> <td data-bbox="639 833 1401 880">Side paper feeder</td> </tr> <tr> <td data-bbox="336 880 639 934">Side LCF</td> <td data-bbox="639 880 1401 934">Side large capacity feeder</td> </tr> </tbody> </table> <p data-bbox="288 978 592 1010">Method: [2PF/Side 2PF]</p> <ol data-bbox="304 1012 871 1043" style="list-style-type: none"> 1. Press [Motor] or [Device] and select the item. <table border="1" data-bbox="336 1057 1401 1487"> <thead> <tr> <th colspan="2" data-bbox="336 1057 715 1104">Display</th> <th data-bbox="715 1057 1401 1104">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1104 448 1200" rowspan="2">Motor</td> <td data-bbox="448 1104 715 1151">Off</td> <td data-bbox="715 1104 1401 1151">PF paper feed motor (PFPFM) is turned off</td> </tr> <tr> <td data-bbox="448 1151 715 1200">On</td> <td data-bbox="715 1151 1401 1200">PF paper feed motor (PFPFM) is turned on</td> </tr> <tr> <td data-bbox="336 1200 448 1487" rowspan="6">Device</td> <td data-bbox="448 1200 715 1247">C1 Clutch</td> <td data-bbox="715 1200 1401 1247">PF paper conveying clutch 1 (PFPCCL1) is turned on</td> </tr> <tr> <td data-bbox="448 1247 715 1294">C2 Clutch</td> <td data-bbox="715 1247 1401 1294">PF paper conveying clutch 2 (PFPCCL2) is turned on</td> </tr> <tr> <td data-bbox="448 1294 715 1341">V Feed(H) Clutch</td> <td data-bbox="715 1294 1401 1341">PF paper feed clutch 1 (PFPFCL1) is turned on</td> </tr> <tr> <td data-bbox="448 1341 715 1388">V Feed(L) Clutch</td> <td data-bbox="715 1341 1401 1388">PF paper feed clutch 2 (PFPFCL2) is turned on</td> </tr> <tr> <td data-bbox="448 1388 715 1435">Cassette1 Solenoid</td> <td data-bbox="715 1388 1401 1435">PF pickup solenoid 1 (PFUSOL1) is turned on</td> </tr> <tr> <td data-bbox="448 1435 715 1487">Cassette2 Solenoid</td> <td data-bbox="715 1435 1401 1487">PF pickup solenoid 2 (PFUSOL2) is turned on</td> </tr> </tbody> </table> <ol data-bbox="304 1498 815 1599" style="list-style-type: none"> 2. Select [Execute]. 3. Press the start key. The operation starts. 4. To stop operation, press the stop key. 	Display	Description	2PF	Paper feeder	LCF	Large capacity feeder	Side Deck	Side deck	SMT	Side multi tray	Side 2PF	Side paper feeder	Side LCF	Side large capacity feeder	Display		Description	Motor	Off	PF paper feed motor (PFPFM) is turned off	On	PF paper feed motor (PFPFM) is turned on	Device	C1 Clutch	PF paper conveying clutch 1 (PFPCCL1) is turned on	C2 Clutch	PF paper conveying clutch 2 (PFPCCL2) is turned on	V Feed(H) Clutch	PF paper feed clutch 1 (PFPFCL1) is turned on	V Feed(L) Clutch	PF paper feed clutch 2 (PFPFCL2) is turned on	Cassette1 Solenoid	PF pickup solenoid 1 (PFUSOL1) is turned on	Cassette2 Solenoid	PF pickup solenoid 2 (PFUSOL2) is turned on
Display	Description																																			
2PF	Paper feeder																																			
LCF	Large capacity feeder																																			
Side Deck	Side deck																																			
SMT	Side multi tray																																			
Side 2PF	Side paper feeder																																			
Side LCF	Side large capacity feeder																																			
Display		Description																																		
Motor	Off	PF paper feed motor (PFPFM) is turned off																																		
	On	PF paper feed motor (PFPFM) is turned on																																		
Device	C1 Clutch	PF paper conveying clutch 1 (PFPCCL1) is turned on																																		
	C2 Clutch	PF paper conveying clutch 2 (PFPCCL2) is turned on																																		
	V Feed(H) Clutch	PF paper feed clutch 1 (PFPFCL1) is turned on																																		
	V Feed(L) Clutch	PF paper feed clutch 2 (PFPFCL2) is turned on																																		
	Cassette1 Solenoid	PF pickup solenoid 1 (PFUSOL1) is turned on																																		
	Cassette2 Solenoid	PF pickup solenoid 2 (PFUSOL2) is turned on																																		

Item No.	Description																																																									
U247	<p data-bbox="287 241 598 275">Method: [LCF/Side LCF]</p> <p data-bbox="287 275 869 309">1. Press [Motor] or [Device] and select the item.</p> <table border="1" data-bbox="335 320 1399 797"> <thead> <tr> <th colspan="2" data-bbox="335 320 718 365">Display</th> <th data-bbox="718 320 1399 365">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="335 365 446 465" rowspan="2">Motor</td> <td data-bbox="446 365 718 409">Off</td> <td data-bbox="718 365 1399 409">PF paper feed motor (PFPFM) is turned off</td> </tr> <tr> <td data-bbox="446 409 718 465">On</td> <td data-bbox="718 409 1399 465">PF paper feed motor (PFPFM) is turned on</td> </tr> <tr> <td data-bbox="335 465 446 797" rowspan="7">Device</td> <td data-bbox="446 465 718 510">C1 Clutch</td> <td data-bbox="718 465 1399 510">PF paper conveying clutch 1 (PFPCCL1) is turned on</td> </tr> <tr> <td data-bbox="446 510 718 555">C2 Clutch</td> <td data-bbox="718 510 1399 555">PF paper conveying clutch 2 (PFPCCL2) is turned on</td> </tr> <tr> <td data-bbox="446 555 718 600">V Feed Clutch</td> <td data-bbox="718 555 1399 600">PF paper conveying clutch 3 (PFPCCL3) is turned on</td> </tr> <tr> <td data-bbox="446 600 718 645">H Feed1 Clutch</td> <td data-bbox="718 600 1399 645">PF paper feed clutch 1 (PFPFCL1) is turned on</td> </tr> <tr> <td data-bbox="446 645 718 689">H Feed2 Clutch</td> <td data-bbox="718 645 1399 689">PF paper feed clutch 2 (PFPFCL2) is turned on</td> </tr> <tr> <td data-bbox="446 689 718 734">Cassette1 Solenoid</td> <td data-bbox="718 689 1399 734">PF pickup solenoid 1 (PFUSOL1) is turned on</td> </tr> <tr> <td data-bbox="446 734 718 797">Cassette2 Solenoid</td> <td data-bbox="718 734 1399 797">PF pickup solenoid 2 (PFUSOL2) is turned on</td> </tr> </tbody> </table> <p data-bbox="287 808 534 842">2. Select [Execute].</p> <p data-bbox="287 842 813 875">3. Press the start key. The operation starts.</p> <p data-bbox="287 875 782 909">4. To stop operation, press the stop key.</p> <p data-bbox="287 943 550 976">Method: [Side Deck]</p> <p data-bbox="287 976 869 1010">1. Press [Motor] or [Device] and select the item.</p> <table border="1" data-bbox="335 1021 1399 1265"> <thead> <tr> <th colspan="2" data-bbox="335 1021 718 1066">Display</th> <th data-bbox="718 1021 1399 1066">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="335 1066 446 1167" rowspan="2">Motor</td> <td data-bbox="446 1066 718 1111">Off</td> <td data-bbox="718 1066 1399 1111">SF paper feed motor (SFPFM) is turned off</td> </tr> <tr> <td data-bbox="446 1111 718 1167">On</td> <td data-bbox="718 1111 1399 1167">SF paper feed motor (SFPFM) is turned on</td> </tr> <tr> <td data-bbox="335 1167 446 1265" rowspan="2">Device</td> <td data-bbox="446 1167 718 1211">C1 Clutch</td> <td data-bbox="718 1167 1399 1211">SF paper conveying clutch (SFPCCL) is turned on</td> </tr> <tr> <td data-bbox="446 1211 718 1265">Cassette1 Solenoid</td> <td data-bbox="718 1211 1399 1265">SF pickup solenoid (PFUSOL) is turned on</td> </tr> </tbody> </table> <p data-bbox="287 1276 534 1310">2. Select [Execute].</p> <p data-bbox="287 1310 813 1344">3. Press the start key. The operation starts.</p> <p data-bbox="287 1344 782 1377">4. To stop operation, press the stop key.</p> <p data-bbox="287 1411 478 1444">Method: [SMT]</p> <p data-bbox="287 1444 869 1478">1. Press [Motor] or [Device] and select the item.</p> <table border="1" data-bbox="335 1489 1399 1921"> <thead> <tr> <th colspan="2" data-bbox="335 1489 718 1534">Display</th> <th data-bbox="718 1489 1399 1534">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="335 1534 446 1635" rowspan="2">Motor</td> <td data-bbox="446 1534 718 1579">Off</td> <td data-bbox="718 1534 1399 1579">SM paper feed motor (SMPFM) is turned off</td> </tr> <tr> <td data-bbox="446 1579 718 1635">On</td> <td data-bbox="718 1579 1399 1635">SM paper feed motor (SMPFM) is turned on</td> </tr> <tr> <td data-bbox="335 1635 446 1921" rowspan="6">Device</td> <td data-bbox="446 1635 718 1680">C1 Clutch</td> <td data-bbox="718 1635 1399 1680">SM paper conveying clutch 1 (SMPCCL1) is turned on</td> </tr> <tr> <td data-bbox="446 1680 718 1724">Feed1 Clutch</td> <td data-bbox="718 1680 1399 1724">SM paper conveying clutch 2 (SMPCCL2) is turned on</td> </tr> <tr> <td data-bbox="446 1724 718 1769">Feed2 Clutch</td> <td data-bbox="718 1724 1399 1769">SM paper conveying clutch 3 (SMPCCL3) is turned on</td> </tr> <tr> <td data-bbox="446 1769 718 1814">Feed3 Clutch</td> <td data-bbox="718 1769 1399 1814">SM paper conveying clutch 4 (SMPCCL4) is turned on</td> </tr> <tr> <td data-bbox="446 1814 718 1859">Cassette1 Solenoid</td> <td data-bbox="718 1814 1399 1859">SM pickup solenoid (SMPUSOL) is turned on</td> </tr> <tr> <td data-bbox="446 1859 718 1921">Separator Solenoid</td> <td data-bbox="718 1859 1399 1921">SM feedshift solenoid (SMFSSOL) is turned on</td> </tr> </tbody> </table> <p data-bbox="287 1933 534 1966">2. Select [Execute].</p> <p data-bbox="287 1966 813 2000">3. Press the start key. The operation starts.</p> <p data-bbox="287 2000 782 2033">4. To stop operation, press the stop key.</p>	Display		Description	Motor	Off	PF paper feed motor (PFPFM) is turned off	On	PF paper feed motor (PFPFM) is turned on	Device	C1 Clutch	PF paper conveying clutch 1 (PFPCCL1) is turned on	C2 Clutch	PF paper conveying clutch 2 (PFPCCL2) is turned on	V Feed Clutch	PF paper conveying clutch 3 (PFPCCL3) is turned on	H Feed1 Clutch	PF paper feed clutch 1 (PFPFCL1) is turned on	H Feed2 Clutch	PF paper feed clutch 2 (PFPFCL2) is turned on	Cassette1 Solenoid	PF pickup solenoid 1 (PFUSOL1) is turned on	Cassette2 Solenoid	PF pickup solenoid 2 (PFUSOL2) is turned on	Display		Description	Motor	Off	SF paper feed motor (SFPFM) is turned off	On	SF paper feed motor (SFPFM) is turned on	Device	C1 Clutch	SF paper conveying clutch (SFPCCL) is turned on	Cassette1 Solenoid	SF pickup solenoid (PFUSOL) is turned on	Display		Description	Motor	Off	SM paper feed motor (SMPFM) is turned off	On	SM paper feed motor (SMPFM) is turned on	Device	C1 Clutch	SM paper conveying clutch 1 (SMPCCL1) is turned on	Feed1 Clutch	SM paper conveying clutch 2 (SMPCCL2) is turned on	Feed2 Clutch	SM paper conveying clutch 3 (SMPCCL3) is turned on	Feed3 Clutch	SM paper conveying clutch 4 (SMPCCL4) is turned on	Cassette1 Solenoid	SM pickup solenoid (SMPUSOL) is turned on	Separator Solenoid	SM feedshift solenoid (SMFSSOL) is turned on
Display		Description																																																								
Motor	Off	PF paper feed motor (PFPFM) is turned off																																																								
	On	PF paper feed motor (PFPFM) is turned on																																																								
Device	C1 Clutch	PF paper conveying clutch 1 (PFPCCL1) is turned on																																																								
	C2 Clutch	PF paper conveying clutch 2 (PFPCCL2) is turned on																																																								
	V Feed Clutch	PF paper conveying clutch 3 (PFPCCL3) is turned on																																																								
	H Feed1 Clutch	PF paper feed clutch 1 (PFPFCL1) is turned on																																																								
	H Feed2 Clutch	PF paper feed clutch 2 (PFPFCL2) is turned on																																																								
	Cassette1 Solenoid	PF pickup solenoid 1 (PFUSOL1) is turned on																																																								
	Cassette2 Solenoid	PF pickup solenoid 2 (PFUSOL2) is turned on																																																								
Display		Description																																																								
Motor	Off	SF paper feed motor (SFPFM) is turned off																																																								
	On	SF paper feed motor (SFPFM) is turned on																																																								
Device	C1 Clutch	SF paper conveying clutch (SFPCCL) is turned on																																																								
	Cassette1 Solenoid	SF pickup solenoid (PFUSOL) is turned on																																																								
Display		Description																																																								
Motor	Off	SM paper feed motor (SMPFM) is turned off																																																								
	On	SM paper feed motor (SMPFM) is turned on																																																								
Device	C1 Clutch	SM paper conveying clutch 1 (SMPCCL1) is turned on																																																								
	Feed1 Clutch	SM paper conveying clutch 2 (SMPCCL2) is turned on																																																								
	Feed2 Clutch	SM paper conveying clutch 3 (SMPCCL3) is turned on																																																								
	Feed3 Clutch	SM paper conveying clutch 4 (SMPCCL4) is turned on																																																								
	Cassette1 Solenoid	SM pickup solenoid (SMPUSOL) is turned on																																																								
	Separator Solenoid	SM feedshift solenoid (SMFSSOL) is turned on																																																								

Item No.	Description																																	
U247	<p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>																																	
U249	<p>Finisher operation test</p> <p>Description Performs operating tests on the 4000-sheet finisher.</p> <p>Purpose To check the operation of the 4000-sheet finisher.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 712 1401 857"> <thead> <tr> <th data-bbox="336 712 639 763">Display</th> <th data-bbox="639 712 1401 763">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 763 639 808">Punch Position</td> <td data-bbox="639 763 1401 808">Check the stop position of punching</td> </tr> <tr> <td data-bbox="336 808 639 857">Booklet Pass</td> <td data-bbox="639 808 1401 857">Check the paper paths to the center-folding unit</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. 4. Press the system menu key to make a test copy. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Punch Position	Check the stop position of punching	Booklet Pass	Check the paper paths to the center-folding unit																											
Display	Description																																	
Punch Position	Check the stop position of punching																																	
Booklet Pass	Check the paper paths to the center-folding unit																																	
U250	<p>Checking/clearing the maintenance cycle</p> <p>Description Changes preset values for maintenance cycle and automatic grayscale adjustment.</p> <p>Purpose Provides changing the time when the message to acknowledge to conduct maintenance and automatic grayscale adjustment is periodically displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. 3. Change the setting using the +- keys or numeric keys. <table border="1" data-bbox="336 1473 1401 2033"> <thead> <tr> <th data-bbox="336 1473 564 1525">Display</th> <th data-bbox="564 1473 1134 1525">Description</th> <th data-bbox="1134 1473 1401 1525">Setting range</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1525 564 1570">M.Cnt A</td> <td data-bbox="564 1525 1134 1570">Preset values for maintenance cycle (kit A)</td> <td data-bbox="1134 1525 1401 1570">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1570 564 1615">M.Cnt B</td> <td data-bbox="564 1570 1134 1615">Preset values for maintenance cycle (kit B)</td> <td data-bbox="1134 1570 1401 1615">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1615 564 1659">M.Cnt C</td> <td data-bbox="564 1615 1134 1659">Preset values for maintenance cycle (kit C)</td> <td data-bbox="1134 1615 1401 1659">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1659 564 1749">M.Cnt HT</td> <td data-bbox="564 1659 1134 1749">Preset values for automatic grayscale adjustment</td> <td data-bbox="1134 1659 1401 1749">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1749 564 1794">Cassette 1</td> <td data-bbox="564 1749 1134 1794">Maintenance counter cassette1</td> <td data-bbox="1134 1749 1401 1794">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1794 564 1839">Cassette 2</td> <td data-bbox="564 1794 1134 1839">Maintenance counter cassette1</td> <td data-bbox="1134 1794 1401 1839">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1839 564 1883">Cassette 3</td> <td data-bbox="564 1839 1134 1883">Maintenance counter cassette1</td> <td data-bbox="1134 1839 1401 1883">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1883 564 1928">Cassette 4</td> <td data-bbox="564 1883 1134 1928">Maintenance counter cassette1</td> <td data-bbox="1134 1883 1401 1928">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1928 564 1973">Cassette 5</td> <td data-bbox="564 1928 1134 1973">Maintenance counter cassette5</td> <td data-bbox="1134 1928 1401 1973">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1973 564 2033">Cassette 6</td> <td data-bbox="564 1973 1134 2033">Maintenance counter cassette6</td> <td data-bbox="1134 1973 1401 2033">0 to 9999999</td> </tr> </tbody> </table>	Display	Description	Setting range	M.Cnt A	Preset values for maintenance cycle (kit A)	0 to 9999999	M.Cnt B	Preset values for maintenance cycle (kit B)	0 to 9999999	M.Cnt C	Preset values for maintenance cycle (kit C)	0 to 9999999	M.Cnt HT	Preset values for automatic grayscale adjustment	0 to 9999999	Cassette 1	Maintenance counter cassette1	0 to 9999999	Cassette 2	Maintenance counter cassette1	0 to 9999999	Cassette 3	Maintenance counter cassette1	0 to 9999999	Cassette 4	Maintenance counter cassette1	0 to 9999999	Cassette 5	Maintenance counter cassette5	0 to 9999999	Cassette 6	Maintenance counter cassette6	0 to 9999999
Display	Description	Setting range																																
M.Cnt A	Preset values for maintenance cycle (kit A)	0 to 9999999																																
M.Cnt B	Preset values for maintenance cycle (kit B)	0 to 9999999																																
M.Cnt C	Preset values for maintenance cycle (kit C)	0 to 9999999																																
M.Cnt HT	Preset values for automatic grayscale adjustment	0 to 9999999																																
Cassette 1	Maintenance counter cassette1	0 to 9999999																																
Cassette 2	Maintenance counter cassette1	0 to 9999999																																
Cassette 3	Maintenance counter cassette1	0 to 9999999																																
Cassette 4	Maintenance counter cassette1	0 to 9999999																																
Cassette 5	Maintenance counter cassette5	0 to 9999999																																
Cassette 6	Maintenance counter cassette6	0 to 9999999																																

Item No.	Description																																							
U250	<table border="1" data-bbox="336 286 1401 430"> <thead> <tr> <th data-bbox="336 286 564 331">Display</th> <th data-bbox="564 286 1134 331">Description</th> <th data-bbox="1134 286 1401 331">Setting range</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 331 564 376">Cassette 7</td> <td data-bbox="564 331 1134 376">Maintenance counter cassette7</td> <td data-bbox="1134 331 1401 376">0 to 9999999</td> </tr> <tr> <td data-bbox="336 376 564 430">Clear</td> <td data-bbox="564 376 1134 430">Maintenance counter all clear</td> <td data-bbox="1134 376 1401 430">0 to 9999999</td> </tr> </tbody> </table> <p data-bbox="304 443 767 472">4. Press the start key. The value is set.</p> <p data-bbox="288 510 440 539">Completion</p> <p data-bbox="288 546 1254 575">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p> <p data-bbox="336 613 1366 678">* : When the firmware is upgraded in the field, the standard counter value newly added should be set to 150000.</p>	Display	Description	Setting range	Cassette 7	Maintenance counter cassette7	0 to 9999999	Clear	Maintenance counter all clear	0 to 9999999																														
Display	Description	Setting range																																						
Cassette 7	Maintenance counter cassette7	0 to 9999999																																						
Clear	Maintenance counter all clear	0 to 9999999																																						
U251	<p data-bbox="288 696 847 725">Checking/clearing the maintenance counter</p> <p data-bbox="288 763 440 792">Description</p> <p data-bbox="288 799 1382 864">Displays and clears or changes the maintenance count and automatic grayscale adjustment count.</p> <p data-bbox="288 871 400 900">Purpose</p> <p data-bbox="288 907 1418 972">To verify the maintenance counter count and automatic grayscale count. Also to clear the count during maintenance service.</p> <p data-bbox="288 1010 384 1039">Setting</p> <ol data-bbox="304 1046 983 1144" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be changed. 3. Change the setting using the +/- keys or numeric keys. <table border="1" data-bbox="336 1155 1401 1778"> <thead> <tr> <th data-bbox="336 1155 564 1200">Display</th> <th data-bbox="564 1155 1134 1200">Description</th> <th data-bbox="1134 1155 1401 1200">Setting range</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1200 564 1245">M.Cnt A</td> <td data-bbox="564 1200 1134 1245">Count value for maintenance cycle (kit A)</td> <td data-bbox="1134 1200 1401 1245">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1245 564 1290">M.Cnt B</td> <td data-bbox="564 1245 1134 1290">Count value for maintenance cycle (kit B)</td> <td data-bbox="1134 1245 1401 1290">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1290 564 1335">M.Cnt C</td> <td data-bbox="564 1290 1134 1335">Count value for maintenance cycle (kit C)</td> <td data-bbox="1134 1290 1401 1335">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1335 564 1379">M.Cnt HT</td> <td data-bbox="564 1335 1134 1379">Automatic grayscale adjustment count</td> <td data-bbox="1134 1335 1401 1379">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1379 564 1424">Cassette 1</td> <td data-bbox="564 1379 1134 1424">Maintenance counter cassette1</td> <td data-bbox="1134 1379 1401 1424">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1424 564 1469">Cassette 2</td> <td data-bbox="564 1424 1134 1469">Maintenance counter cassette2</td> <td data-bbox="1134 1424 1401 1469">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1469 564 1514">Cassette 3</td> <td data-bbox="564 1469 1134 1514">Maintenance counter cassette3</td> <td data-bbox="1134 1469 1401 1514">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1514 564 1559">Cassette 4</td> <td data-bbox="564 1514 1134 1559">Maintenance counter cassette4</td> <td data-bbox="1134 1514 1401 1559">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1559 564 1603">Cassette 5</td> <td data-bbox="564 1559 1134 1603">Maintenance counter cassette5</td> <td data-bbox="1134 1559 1401 1603">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1603 564 1648">Cassette 6</td> <td data-bbox="564 1603 1134 1648">Maintenance counter cassette6</td> <td data-bbox="1134 1603 1401 1648">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1648 564 1693">Cassette 7</td> <td data-bbox="564 1648 1134 1693">Maintenance counter cassette7</td> <td data-bbox="1134 1648 1401 1693">0 to 9999999</td> </tr> <tr> <td data-bbox="336 1693 564 1778">Clear</td> <td data-bbox="564 1693 1134 1778">Maintenance counter all clear</td> <td data-bbox="1134 1693 1401 1778">0 to 9999999</td> </tr> </tbody> </table> <p data-bbox="304 1794 767 1823">4. Press the start key. The value is set.</p> <p data-bbox="288 1861 400 1890">Clearing</p> <ol data-bbox="304 1897 903 1962" style="list-style-type: none"> 1. Select [Clear]. 2. Press the start key. The setting value is cleared. 	Display	Description	Setting range	M.Cnt A	Count value for maintenance cycle (kit A)	0 to 9999999	M.Cnt B	Count value for maintenance cycle (kit B)	0 to 9999999	M.Cnt C	Count value for maintenance cycle (kit C)	0 to 9999999	M.Cnt HT	Automatic grayscale adjustment count	0 to 9999999	Cassette 1	Maintenance counter cassette1	0 to 9999999	Cassette 2	Maintenance counter cassette2	0 to 9999999	Cassette 3	Maintenance counter cassette3	0 to 9999999	Cassette 4	Maintenance counter cassette4	0 to 9999999	Cassette 5	Maintenance counter cassette5	0 to 9999999	Cassette 6	Maintenance counter cassette6	0 to 9999999	Cassette 7	Maintenance counter cassette7	0 to 9999999	Clear	Maintenance counter all clear	0 to 9999999
Display	Description	Setting range																																						
M.Cnt A	Count value for maintenance cycle (kit A)	0 to 9999999																																						
M.Cnt B	Count value for maintenance cycle (kit B)	0 to 9999999																																						
M.Cnt C	Count value for maintenance cycle (kit C)	0 to 9999999																																						
M.Cnt HT	Automatic grayscale adjustment count	0 to 9999999																																						
Cassette 1	Maintenance counter cassette1	0 to 9999999																																						
Cassette 2	Maintenance counter cassette2	0 to 9999999																																						
Cassette 3	Maintenance counter cassette3	0 to 9999999																																						
Cassette 4	Maintenance counter cassette4	0 to 9999999																																						
Cassette 5	Maintenance counter cassette5	0 to 9999999																																						
Cassette 6	Maintenance counter cassette6	0 to 9999999																																						
Cassette 7	Maintenance counter cassette7	0 to 9999999																																						
Clear	Maintenance counter all clear	0 to 9999999																																						

Item No.	Description																										
U251	<p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p> <p>* : When the firmware is upgraded in the field, input the counter value of U901 into the primary feed counter. If the counter value is larger than 150000, replace the primary feed roller and input "0".</p>																										
U252	<p>Setting the destination</p> <p>Description Switches the operations and screens of the machine according to the destination.</p> <p>Purpose To be executed after initializing the backup RAM, in order to return the setting to the value before replacement or initialization.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the destination. <table border="1" data-bbox="336 853 1401 1236"> <thead> <tr> <th data-bbox="336 853 639 898">Display</th> <th data-bbox="639 853 1401 898">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 898 639 943">Japan Metric</td> <td data-bbox="639 898 1401 943">Metric (Japan) specifications</td> </tr> <tr> <td data-bbox="336 943 639 987">Inch</td> <td data-bbox="639 943 1401 987">Inch (North America) specifications</td> </tr> <tr> <td data-bbox="336 987 639 1032">Europe Metric</td> <td data-bbox="639 987 1401 1032">Metric (Europe) specifications</td> </tr> <tr> <td data-bbox="336 1032 639 1077">Asia Pacific</td> <td data-bbox="639 1032 1401 1077">Metric (Asia Pacific) specifications</td> </tr> <tr> <td data-bbox="336 1077 639 1122">Australia</td> <td data-bbox="639 1077 1401 1122">Australia specifications</td> </tr> <tr> <td data-bbox="336 1122 639 1167">China</td> <td data-bbox="639 1122 1401 1167">China specifications</td> </tr> <tr> <td data-bbox="336 1167 639 1211">Korea</td> <td data-bbox="639 1167 1401 1211">Korea specifications</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. 4. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. * : An error code is displayed in case of an initialization error. When errors occurred, turn main power switch off then on, and execute initialization using maintenance item U252. <p>Error codes</p> <table border="1" data-bbox="336 1496 1401 1738"> <thead> <tr> <th data-bbox="336 1496 639 1541">Codes</th> <th data-bbox="639 1496 1401 1541">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1541 639 1585">0001</td> <td data-bbox="639 1541 1401 1585">Entity error</td> </tr> <tr> <td data-bbox="336 1585 639 1630">0002</td> <td data-bbox="639 1585 1401 1630">Controller error</td> </tr> <tr> <td data-bbox="336 1630 639 1675">0020</td> <td data-bbox="639 1630 1401 1675">Engine error</td> </tr> <tr> <td data-bbox="336 1675 639 1720">0040</td> <td data-bbox="639 1675 1401 1720">Scanner error</td> </tr> </tbody> </table>	Display	Description	Japan Metric	Metric (Japan) specifications	Inch	Inch (North America) specifications	Europe Metric	Metric (Europe) specifications	Asia Pacific	Metric (Asia Pacific) specifications	Australia	Australia specifications	China	China specifications	Korea	Korea specifications	Codes	Description	0001	Entity error	0002	Controller error	0020	Engine error	0040	Scanner error
Display	Description																										
Japan Metric	Metric (Japan) specifications																										
Inch	Inch (North America) specifications																										
Europe Metric	Metric (Europe) specifications																										
Asia Pacific	Metric (Asia Pacific) specifications																										
Australia	Australia specifications																										
China	China specifications																										
Korea	Korea specifications																										
Codes	Description																										
0001	Entity error																										
0002	Controller error																										
0020	Engine error																										
0040	Scanner error																										

Item No.	Description																		
U253	<p data-bbox="288 244 863 275">Switching between double and single counts</p> <p data-bbox="288 315 440 342">Description</p> <p data-bbox="288 349 1337 376">Switches the count system for the total counter and other counters for every color mode.</p> <p data-bbox="288 383 400 409">Purpose</p> <p data-bbox="288 416 1374 481">Used to select, according to the preference of the user (copy service provider), if A3/Ledger paper is to be counted as one sheet (single count) or two sheets (double count).</p> <p data-bbox="288 521 384 548">Setting</p> <ol data-bbox="304 555 595 620" style="list-style-type: none"> 1. Press the start key. 2. Select the item to set. <table border="1" data-bbox="336 633 1401 824"> <thead> <tr> <th data-bbox="336 633 639 678">Display</th> <th data-bbox="639 633 1401 678">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 678 639 723">Full Color</td> <td data-bbox="639 678 1401 723">Count system of full color mode</td> </tr> <tr> <td data-bbox="336 723 639 768">Mono Color*</td> <td data-bbox="639 723 1401 768">Count system of single color mode</td> </tr> <tr> <td data-bbox="336 768 639 824">B/W</td> <td data-bbox="639 768 1401 824">Count system of black/white mode</td> </tr> </tbody> </table> <p data-bbox="336 837 1254 864">Displayed only if the setting of U276 (Setting the copy count mode) is Mode1.</p> <ol data-bbox="304 871 630 898" style="list-style-type: none"> 3. Select the count system. <table border="1" data-bbox="336 911 1401 1151"> <thead> <tr> <th data-bbox="336 911 639 956">Display</th> <th data-bbox="639 911 1401 956">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 956 639 1001">SGL(All)</td> <td data-bbox="639 956 1401 1001">Single count for all size paper</td> </tr> <tr> <td data-bbox="336 1001 639 1046">DBL(A3/Ledger)</td> <td data-bbox="639 1001 1401 1046">Double count for A3/Ledger size or larger</td> </tr> <tr> <td data-bbox="336 1046 639 1090">DBL(B4)</td> <td data-bbox="639 1046 1401 1090">Double count for B4 size or larger</td> </tr> <tr> <td data-bbox="336 1090 639 1151">DBL(Folio)</td> <td data-bbox="639 1090 1401 1151">Double count for Folio size or larger</td> </tr> </tbody> </table> <p data-bbox="336 1164 695 1191">Initial setting: DBL(A3/Ledger)</p> <ol data-bbox="304 1198 782 1225" style="list-style-type: none"> 4. Press the start key. The setting is set. <p data-bbox="288 1265 440 1292">Completion</p> <p data-bbox="288 1299 1254 1326">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Full Color	Count system of full color mode	Mono Color*	Count system of single color mode	B/W	Count system of black/white mode	Display	Description	SGL(All)	Single count for all size paper	DBL(A3/Ledger)	Double count for A3/Ledger size or larger	DBL(B4)	Double count for B4 size or larger	DBL(Folio)	Double count for Folio size or larger
Display	Description																		
Full Color	Count system of full color mode																		
Mono Color*	Count system of single color mode																		
B/W	Count system of black/white mode																		
Display	Description																		
SGL(All)	Single count for all size paper																		
DBL(A3/Ledger)	Double count for A3/Ledger size or larger																		
DBL(B4)	Double count for B4 size or larger																		
DBL(Folio)	Double count for Folio size or larger																		

Item No.	Description						
U260	<p>Selecting the timing for copy counting</p> <p>Description Changes the copy count timing for the total counter and other counters.</p> <p>Purpose To be set according to user request.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the copy count timing. <table border="1" data-bbox="336 598 1401 741"> <thead> <tr> <th data-bbox="336 598 641 642">Display</th> <th data-bbox="641 598 1401 642">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 642 641 687">Feed</td> <td data-bbox="641 642 1401 687">When secondary paper feed starts</td> </tr> <tr> <td data-bbox="336 687 641 741">Eject</td> <td data-bbox="641 687 1401 741">When the paper is ejected</td> </tr> </tbody> </table> <p>Initial setting: Eject</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Feed	When secondary paper feed starts	Eject	When the paper is ejected
Display	Description						
Feed	When secondary paper feed starts						
Eject	When the paper is ejected						
U265	<p>Setting OEM purchaser code</p> <p>Description Sets the OEM purchaser code.</p> <p>Purpose Sets the code when replacing the main PWB and the like.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the setting value using the numeric keys. 3. Press the start key. The setting is set. 4. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. 						

Item No.	Description												
U271	<p>Setting the page count</p> <p>Description Banner counting</p> <p>Purpose To change when modifying counting Banner</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. 3. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 633 1401 882"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Banner A</td> <td>Counting for Banner A (470.1mm to 915mm/18.51" to 36")</td> <td>2 to 30</td> <td>2</td> </tr> <tr> <td>Banner B</td> <td>Counting for Banner B (915.1mm to 1,220mm/36.01" to 48")</td> <td>2 to 30</td> <td>3</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Banner A	Counting for Banner A (470.1mm to 915mm/18.51" to 36")	2 to 30	2	Banner B	Counting for Banner B (915.1mm to 1,220mm/36.01" to 48")	2 to 30	3
Display	Description	Setting range	Initial setting										
Banner A	Counting for Banner A (470.1mm to 915mm/18.51" to 36")	2 to 30	2										
Banner B	Counting for Banner B (915.1mm to 1,220mm/36.01" to 48")	2 to 30	3										
U276	<p>Setting the copy count mode</p> <p>Description Sets the count mode of single color mode.</p> <p>Purpose To change the charging counter which counts up in single color printing.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the mode. <table border="1" data-bbox="336 1397 1401 1543"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Mode0</td> <td>This lets the full color counter count up in single color</td> </tr> <tr> <td>Mode1</td> <td>This lets the single color counter count up in single color</td> </tr> </tbody> </table> <p>Initial setting: Mode 0</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Mode0	This lets the full color counter count up in single color	Mode1	This lets the single color counter count up in single color						
Display	Description												
Mode0	This lets the full color counter count up in single color												
Mode1	This lets the single color counter count up in single color												

Item No.	Description						
U278	<p>Setting the delivery date</p> <p>Description Enter delivery date in month, day, and year.</p> <p>Purpose To operate when installing the machine. Perform this to confirm the delivery date.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Today]. 3. Press the start key. The delivery date is set. <p>Clearing</p> <ol style="list-style-type: none"> 1. Select [Clear]. 2. Press the start key. The delivery date is cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>						
U284	<p>Setting 2 color copy mode</p> <p>Description Sets whether to use 2 color copy mode.</p> <p>Purpose According to user request, changes the setting.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select On or Off. <table border="1" data-bbox="336 1234 1401 1377"> <thead> <tr> <th data-bbox="336 1234 639 1281">Display</th> <th data-bbox="639 1234 1401 1281">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1281 639 1328">On</td> <td data-bbox="639 1281 1401 1328">2 color copy mode is enabled</td> </tr> <tr> <td data-bbox="336 1328 639 1377">Off</td> <td data-bbox="639 1328 1401 1377">2 color copy mode is disabled</td> </tr> </tbody> </table> <p>Initial setting: Off If On is selected, 2-color copy will be displayed on the color function screen.</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	On	2 color copy mode is enabled	Off	2 color copy mode is disabled
Display	Description						
On	2 color copy mode is enabled						
Off	2 color copy mode is disabled						

Item No.	Description						
U285	<p>Setting service status page</p> <p>Description Determines displaying the print coverage report on reporting.</p> <p>Purpose According to user request, changes the setting.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select On or Off. <table border="1" data-bbox="336 598 1401 741"> <thead> <tr> <th data-bbox="336 598 641 642">Display</th> <th data-bbox="641 598 1401 642">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 642 641 687">On</td> <td data-bbox="641 642 1401 687">Displays the print coverage</td> </tr> <tr> <td data-bbox="336 687 641 741">Off</td> <td data-bbox="641 687 1401 741">Not to display the print coverage</td> </tr> </tbody> </table> <p>Initial setting: On</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	On	Displays the print coverage	Off	Not to display the print coverage
Display	Description						
On	Displays the print coverage						
Off	Not to display the print coverage						
U323	<p>Setting abnormal temperature and humidity warning</p> <p>Description Specify whether or not a notice is displayed on the operation panel when abnormal temperature and humidity is detected.</p> <p>Purpose According to user request, changes the setting.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select On or Off. <table border="1" data-bbox="336 1328 1401 1471"> <thead> <tr> <th data-bbox="336 1328 641 1373">Display</th> <th data-bbox="641 1328 1401 1373">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1373 641 1417">On</td> <td data-bbox="641 1373 1401 1417">Displays the abnormal temperature and humidity warning</td> </tr> <tr> <td data-bbox="336 1417 641 1471">Off</td> <td data-bbox="641 1417 1401 1471">Not to display the abnormal temperature and humidity warning</td> </tr> </tbody> </table> <p>Initial setting: On</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	On	Displays the abnormal temperature and humidity warning	Off	Not to display the abnormal temperature and humidity warning
Display	Description						
On	Displays the abnormal temperature and humidity warning						
Off	Not to display the abnormal temperature and humidity warning						

Item No.	Description																				
U325	<p data-bbox="288 241 612 271">Setting the paper interval</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1428 409">Determines the interval between pages and the toner replenishment amount when printing pages with high print coverage.</p> <p data-bbox="288 414 400 443">Purpose</p> <p data-bbox="288 448 1428 512">Modify the settings only if a spotted background or uneven density appears when printing pages with high print coverage.</p> <p data-bbox="288 553 387 582">Method</p> <ol data-bbox="304 586 593 651" style="list-style-type: none"> 1. Press the start key. 2. Select the item to set. <table border="1" data-bbox="336 665 1401 808"> <thead> <tr> <th data-bbox="336 665 639 710">Display</th> <th data-bbox="639 665 1401 710">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 710 639 754">Interval</td> <td data-bbox="639 710 1401 754">Paper interval control ON/OFF setting</td> </tr> <tr> <td data-bbox="336 754 639 808">Mode</td> <td data-bbox="639 754 1401 808">Setting mode of the paper interval control</td> </tr> </tbody> </table> <p data-bbox="288 853 512 882">Setting: [Interval]</p> <ol data-bbox="304 887 536 916" style="list-style-type: none"> 1. Select On or Off. <table border="1" data-bbox="336 929 1401 1075"> <thead> <tr> <th data-bbox="336 929 639 974">Display</th> <th data-bbox="639 929 1401 974">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 974 639 1019">On</td> <td data-bbox="639 974 1401 1019">Paper interval control is performed</td> </tr> <tr> <td data-bbox="336 1019 639 1075">Off</td> <td data-bbox="639 1019 1401 1075">Paper interval control is not performed</td> </tr> </tbody> </table> <p data-bbox="336 1086 539 1115">Initial setting: Off</p> <ol data-bbox="304 1120 780 1149" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1189 488 1218">Setting: [Mode]</p> <ol data-bbox="304 1223 1054 1252" style="list-style-type: none"> 1. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 1265 1401 1400"> <thead> <tr> <th data-bbox="336 1265 528 1350">Display</th> <th data-bbox="528 1265 1094 1350">Description</th> <th data-bbox="1094 1265 1251 1350">Setting range</th> <th data-bbox="1251 1265 1401 1350">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1350 528 1400">Mode</td> <td data-bbox="528 1350 1094 1400">Paper interval control mode</td> <td data-bbox="1094 1350 1251 1400">1 to 10</td> <td data-bbox="1251 1350 1401 1400">1</td> </tr> </tbody> </table> <p data-bbox="288 1512 440 1541">Completion</p> <p data-bbox="288 1545 1254 1574">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Interval	Paper interval control ON/OFF setting	Mode	Setting mode of the paper interval control	Display	Description	On	Paper interval control is performed	Off	Paper interval control is not performed	Display	Description	Setting range	Initial setting	Mode	Paper interval control mode	1 to 10	1
Display	Description																				
Interval	Paper interval control ON/OFF setting																				
Mode	Setting mode of the paper interval control																				
Display	Description																				
On	Paper interval control is performed																				
Off	Paper interval control is not performed																				
Display	Description	Setting range	Initial setting																		
Mode	Paper interval control mode	1 to 10	1																		

Item No.	Description																				
U326	<p data-bbox="288 241 810 275">Setting the black line cleaning indication</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1193 376">Sets whether to display the cleaning guidance when detecting the black line.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1422 481">Displays the cleaning guidance in order to make the call for service with the black line decrease by the rubbish on the contact glass when scanning from the DP.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 553 595 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item to set. <table border="1" data-bbox="336 631 1401 777"> <thead> <tr> <th data-bbox="336 631 639 678">Display</th> <th data-bbox="639 631 1401 678">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 678 639 725">Black Line Mode</td> <td data-bbox="639 678 1401 725">Black line cleaning guidance ON/OFF setting</td> </tr> <tr> <td data-bbox="336 725 639 777">Black Line Cnt</td> <td data-bbox="639 725 1401 777">Setting counts of the cleaning guidance indication</td> </tr> </tbody> </table> <p data-bbox="288 819 628 851">Setting: [Black Line Mode]</p> <ol data-bbox="304 855 536 884" style="list-style-type: none"> 1. Select On or Off. <table border="1" data-bbox="336 898 1401 1043"> <thead> <tr> <th data-bbox="336 898 639 945">Display</th> <th data-bbox="639 898 1401 945">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 945 639 992">On</td> <td data-bbox="639 945 1401 992">Displays the cleaning guidance</td> </tr> <tr> <td data-bbox="336 992 639 1043">Off</td> <td data-bbox="639 992 1401 1043">Not to display the cleaning guidance</td> </tr> </tbody> </table> <p data-bbox="336 1055 536 1084">Initial setting: On</p> <ol data-bbox="304 1088 783 1120" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1158 603 1189">Setting: [Black Line Cnt]</p> <ol data-bbox="304 1193 1054 1225" style="list-style-type: none"> 1. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 1236 1401 1402"> <thead> <tr> <th data-bbox="336 1236 528 1317">Display</th> <th data-bbox="528 1236 1098 1317">Description</th> <th data-bbox="1098 1236 1249 1317">Setting range</th> <th data-bbox="1249 1236 1401 1317">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1317 528 1402">Cnt</td> <td data-bbox="528 1317 1098 1402">Setting counts of the cleaning guidance indication (x 1000 sheets)</td> <td data-bbox="1098 1317 1249 1402">0 to 255</td> <td data-bbox="1249 1317 1401 1402">8</td> </tr> </tbody> </table> <p data-bbox="336 1413 1358 1480">When setting is 0, the black line cleaning indication is displayed only if the black line is detected.</p> <ol data-bbox="304 1485 767 1516" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1552 440 1583">Completion</p> <p data-bbox="288 1588 1254 1619">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Black Line Mode	Black line cleaning guidance ON/OFF setting	Black Line Cnt	Setting counts of the cleaning guidance indication	Display	Description	On	Displays the cleaning guidance	Off	Not to display the cleaning guidance	Display	Description	Setting range	Initial setting	Cnt	Setting counts of the cleaning guidance indication (x 1000 sheets)	0 to 255	8
Display	Description																				
Black Line Mode	Black line cleaning guidance ON/OFF setting																				
Black Line Cnt	Setting counts of the cleaning guidance indication																				
Display	Description																				
On	Displays the cleaning guidance																				
Off	Not to display the cleaning guidance																				
Display	Description	Setting range	Initial setting																		
Cnt	Setting counts of the cleaning guidance indication (x 1000 sheets)	0 to 255	8																		

Item No.	Description								
U327	<p data-bbox="290 241 730 271">Setting the cassette heater control</p> <p data-bbox="290 311 440 340">Description</p> <p data-bbox="290 344 675 374">Sets the cassette heater control.</p> <p data-bbox="290 380 400 409">Purpose</p> <p data-bbox="290 414 1149 443">To change the setting according to the machine installation environment.</p> <p data-bbox="290 483 384 512">Setting</p> <ol data-bbox="306 517 603 582" style="list-style-type: none"> 1. Press the start key. 2. Select the item to set.. <table border="1" data-bbox="336 595 1401 824"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1401 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 730">Mode1</td> <td data-bbox="639 640 1401 730">Setting On when the humidity is 65%. (when sleep mode and waiting mode)</td> </tr> <tr> <td data-bbox="336 730 639 775">Mode2</td> <td data-bbox="639 730 1401 775">Setting On in full-time. (when sleep mode and waiting mode)</td> </tr> <tr> <td data-bbox="336 775 639 824">Off</td> <td data-bbox="639 775 1401 824">Cassette heater OFF</td> </tr> </tbody> </table> <p data-bbox="336 844 539 873">Initial setting: Off</p> <ol data-bbox="306 878 782 907" style="list-style-type: none"> 3. Press the start key. The setting is set. <p data-bbox="336 947 1401 1012">* : To reflect the setting, exit the maintenance mode once, and shut down the operation of the normal screen, then turn the main power switch OFF / ON.</p> <p data-bbox="290 1052 440 1081">Completion</p> <p data-bbox="290 1086 1256 1115">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Mode1	Setting On when the humidity is 65%. (when sleep mode and waiting mode)	Mode2	Setting On in full-time. (when sleep mode and waiting mode)	Off	Cassette heater OFF
Display	Description								
Mode1	Setting On when the humidity is 65%. (when sleep mode and waiting mode)								
Mode2	Setting On in full-time. (when sleep mode and waiting mode)								
Off	Cassette heater OFF								

Item No.	Description																																				
U332	<p>Setting the size conversion factor</p> <p>Description Sets the coefficient of nonstandard sizes in relation to the A4/Letter size. The coefficient set here is used to convert the black ratio in relation to the A4/Letter size and to display the result in user simulation. Make settings on the color copy and color print coverage counter displays, as well as the coverage threshold.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to set. <table border="1" data-bbox="336 595 1401 837"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Rate</td> <td>Size coefficient</td> </tr> <tr> <td>Mode</td> <td>Toggling full-color count and color coverage count display</td> </tr> <tr> <td>Level 1</td> <td>Low coverage threshold value</td> </tr> <tr> <td>Level 2</td> <td>Middle coverage threshold value</td> </tr> </tbody> </table> <p>Setting: [Rate]</p> <p>Purpose: To set the coefficient for converting the black ratio for nonstandard sizes in relation to the A4/Letter size.</p> <ol style="list-style-type: none"> 1. Change the setting using the +/-keys or numeric keys. <table border="1" data-bbox="336 990 1401 1086"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Rate</td> <td>Size coefficient</td> <td>0.1 to 3.0</td> <td>1.0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 2. Press the start key. The value is set. <p>Setting: [Mode]</p> <p>Purpose: Make settings on the color copy and color print color/coverage counter displays.</p> <ol style="list-style-type: none"> 1. Select the mode. <table border="1" data-bbox="336 1279 1401 1422"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Full-color count display</td> </tr> <tr> <td>1</td> <td>Color coverage count display</td> </tr> </tbody> </table> <p>Initial setting: 0 * : If '0' has been changed to '1', revert the U260 feed/eject counter switch to its initial state (Eject).</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. <p>Setting: [Level 1/2]</p> <p>Purpose: Make settings on the color copy and color print coverage threshold.</p> <ol style="list-style-type: none"> 1. Select the item. 2. Change the setting using the +/-keys or numeric keys. <table border="1" data-bbox="336 1749 1401 1892"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Level 1</td> <td>Low coverage threshold value</td> <td>0.1 to 99.8</td> <td>1.0</td> </tr> <tr> <td>Level 2</td> <td>Middle coverage threshold value</td> <td>0.1 to 99.9</td> <td>2.5</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Rate	Size coefficient	Mode	Toggling full-color count and color coverage count display	Level 1	Low coverage threshold value	Level 2	Middle coverage threshold value	Display	Description	Setting range	Initial setting	Rate	Size coefficient	0.1 to 3.0	1.0	Display	Description	0	Full-color count display	1	Color coverage count display	Display	Description	Setting range	Initial setting	Level 1	Low coverage threshold value	0.1 to 99.8	1.0	Level 2	Middle coverage threshold value	0.1 to 99.9	2.5
Display	Description																																				
Rate	Size coefficient																																				
Mode	Toggling full-color count and color coverage count display																																				
Level 1	Low coverage threshold value																																				
Level 2	Middle coverage threshold value																																				
Display	Description	Setting range	Initial setting																																		
Rate	Size coefficient	0.1 to 3.0	1.0																																		
Display	Description																																				
0	Full-color count display																																				
1	Color coverage count display																																				
Display	Description	Setting range	Initial setting																																		
Level 1	Low coverage threshold value	0.1 to 99.8	1.0																																		
Level 2	Middle coverage threshold value	0.1 to 99.9	2.5																																		

Item No.	Description																														
U340	<p data-bbox="288 241 611 275">Setting the applied mode</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1406 409">Allocates memory to ensure that there is sufficient memory available for the printer to use as a working area.</p> <p data-bbox="288 414 400 443">Purpose</p> <p data-bbox="288 448 1430 512">Modify the memory allocation if insufficient memory for transparency support or XPS direct printing occurs.</p> <p data-bbox="288 551 387 580">Method</p> <ol data-bbox="304 584 595 649" style="list-style-type: none"> 1. Press the start key. 2. Select the item to set. <table border="1" data-bbox="336 665 1399 808"> <thead> <tr> <th data-bbox="336 665 639 710">Display</th> <th data-bbox="639 665 1399 710">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 710 639 754">Adj Memory</td> <td data-bbox="639 710 1399 754">Setting the memory allocation</td> </tr> <tr> <td data-bbox="336 754 639 808">Adj Max Job</td> <td data-bbox="639 754 1399 808">Setting the maximum of multiple jobs</td> </tr> </tbody> </table> <p data-bbox="288 853 571 882">Setting: [Adj Memory]</p> <ol data-bbox="304 887 983 916" style="list-style-type: none"> 1. Change the setting using the +/- keys or numeric keys. <table border="1" data-bbox="336 929 1399 1178"> <thead> <tr> <th data-bbox="336 929 564 1010">Display</th> <th data-bbox="564 929 1066 1010">Description</th> <th data-bbox="1066 929 1249 1010">Setting range</th> <th data-bbox="1249 929 1399 1010">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1010 564 1093">Image</td> <td data-bbox="564 1010 1066 1093">Area temporarily used to create output image.</td> <td data-bbox="1066 1010 1249 1093">0 to 400 (MB)</td> <td data-bbox="1249 1010 1399 1093">190</td> </tr> <tr> <td data-bbox="336 1093 564 1178">Image(Detail)</td> <td data-bbox="564 1093 1066 1178">Area temporarily used to hold downloaded font and other data.</td> <td data-bbox="1066 1093 1249 1178">0 to 400 (MB)</td> <td data-bbox="1249 1093 1399 1178">1</td> </tr> </tbody> </table> <p data-bbox="336 1189 1225 1254">Set the values below in case print failure occurs with the memory shortage. (recommended value)</p> <p data-bbox="336 1258 496 1288">Image : +190</p> <p data-bbox="336 1292 564 1321">Image(Detail) : +1</p> <ol data-bbox="304 1326 1378 1391" style="list-style-type: none"> 2. Press the start key. The value is set. 3. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. <p data-bbox="288 1429 448 1458">Supplement</p> <p data-bbox="288 1462 1305 1491">The work area for copy is small and it may cause output failure if the values are large.</p> <p data-bbox="288 1532 576 1561">Setting: [Adj Max Job]</p> <ol data-bbox="304 1565 975 1594" style="list-style-type: none"> 1. Change the setting using the +/-keys or numeric keys. <table border="1" data-bbox="336 1610 1399 1792"> <thead> <tr> <th data-bbox="336 1610 564 1691">Display</th> <th data-bbox="564 1610 1096 1691">Description</th> <th data-bbox="1096 1610 1249 1691">Setting range</th> <th data-bbox="1249 1610 1399 1691">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1691 564 1736">Copy</td> <td data-bbox="564 1691 1096 1736">Maximum copy (Scan To Print) Jobs</td> <td data-bbox="1096 1691 1249 1736">10 to 50</td> <td data-bbox="1249 1691 1399 1736">10</td> </tr> <tr> <td data-bbox="336 1736 564 1792">Printer</td> <td data-bbox="564 1736 1096 1792">Maximum printer (Host To Print) Jobs</td> <td data-bbox="1096 1736 1249 1792">10 to 50</td> <td data-bbox="1249 1736 1399 1792">-</td> </tr> </tbody> </table> <p data-bbox="336 1800 1262 1830">The maximum Printer jobs should be (maximum jobs) – (maximum copy jobs).</p> <ol data-bbox="304 1834 767 1863" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1901 440 1930">Completion</p> <p data-bbox="288 1935 1254 1964">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Adj Memory	Setting the memory allocation	Adj Max Job	Setting the maximum of multiple jobs	Display	Description	Setting range	Initial setting	Image	Area temporarily used to create output image.	0 to 400 (MB)	190	Image(Detail)	Area temporarily used to hold downloaded font and other data.	0 to 400 (MB)	1	Display	Description	Setting range	Initial setting	Copy	Maximum copy (Scan To Print) Jobs	10 to 50	10	Printer	Maximum printer (Host To Print) Jobs	10 to 50	-
Display	Description																														
Adj Memory	Setting the memory allocation																														
Adj Max Job	Setting the maximum of multiple jobs																														
Display	Description	Setting range	Initial setting																												
Image	Area temporarily used to create output image.	0 to 400 (MB)	190																												
Image(Detail)	Area temporarily used to hold downloaded font and other data.	0 to 400 (MB)	1																												
Display	Description	Setting range	Initial setting																												
Copy	Maximum copy (Scan To Print) Jobs	10 to 50	10																												
Printer	Maximum printer (Host To Print) Jobs	10 to 50	-																												

Item No.	Description																
U341	<p data-bbox="288 241 1005 275">Specific paper feed location setting for printing function</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1294 376">Sets a paper feed location specified for printer output (only if a printer kit is installed).</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 895 445">To use a paper feed location only for printer output.</p> <p data-bbox="288 450 1243 481">A paper feed location specified for printer output cannot be used for copy output.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 553 863 651" style="list-style-type: none"> 1. Press the start key. 2. Select the paper feed location for the printer. Two or more cassette can be selected. <table border="1" data-bbox="336 665 1399 1048"> <thead> <tr> <th data-bbox="336 665 639 710">Display</th> <th data-bbox="639 665 1399 710">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 710 639 754">Cassette1</td> <td data-bbox="639 710 1399 754">Cassette 1</td> </tr> <tr> <td data-bbox="336 754 639 799">Cassette2</td> <td data-bbox="639 754 1399 799">Cassette 2</td> </tr> <tr> <td data-bbox="336 799 639 844">Cassette3</td> <td data-bbox="639 799 1399 844">Cassette 3 (paper feeder/large capacity feeder)</td> </tr> <tr> <td data-bbox="336 844 639 889">Cassette4</td> <td data-bbox="639 844 1399 889">Cassette 4 (paper feeder/large capacity feeder)</td> </tr> <tr> <td data-bbox="336 889 639 934">Cassette5</td> <td data-bbox="639 889 1399 934">Cassette 5 (side multi tray/side deck)</td> </tr> <tr> <td data-bbox="336 934 639 978">Cassette6</td> <td data-bbox="639 934 1399 978">Cassette 6 (side paper feeder/side large capacity feeder)</td> </tr> <tr> <td data-bbox="336 978 639 1048">Cassette7</td> <td data-bbox="639 978 1399 1048">Cassette 7 (side paper feeder/side large capacity feeder)</td> </tr> </tbody> </table> <p data-bbox="333 1061 1366 1126">When an optional paper feed device is not installed, the corresponding count is not displayed.</p> <ol data-bbox="304 1131 782 1162" style="list-style-type: none"> 3. Press the start key. The setting is set. <p data-bbox="288 1198 440 1227">Completion</p> <p data-bbox="288 1232 1254 1263">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Cassette1	Cassette 1	Cassette2	Cassette 2	Cassette3	Cassette 3 (paper feeder/large capacity feeder)	Cassette4	Cassette 4 (paper feeder/large capacity feeder)	Cassette5	Cassette 5 (side multi tray/side deck)	Cassette6	Cassette 6 (side paper feeder/side large capacity feeder)	Cassette7	Cassette 7 (side paper feeder/side large capacity feeder)
Display	Description																
Cassette1	Cassette 1																
Cassette2	Cassette 2																
Cassette3	Cassette 3 (paper feeder/large capacity feeder)																
Cassette4	Cassette 4 (paper feeder/large capacity feeder)																
Cassette5	Cassette 5 (side multi tray/side deck)																
Cassette6	Cassette 6 (side paper feeder/side large capacity feeder)																
Cassette7	Cassette 7 (side paper feeder/side large capacity feeder)																




Item No.	Description								
U343	<p>Switching between duplex/simplex copy mode</p> <p>Description Switches the initial setting between duplex and simplex copy.</p> <p>Purpose To be set according to frequency of use: set to the more frequently used mode.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select On or Off. <table border="1" data-bbox="336 595 1401 741"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1401 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">On</td> <td data-bbox="639 640 1401 685">Duplex copy</td> </tr> <tr> <td data-bbox="336 685 639 741">Off</td> <td data-bbox="639 685 1401 741">Simplex copy</td> </tr> </tbody> </table> <p>Initial setting: Off</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	On	Duplex copy	Off	Simplex copy		
Display	Description								
On	Duplex copy								
Off	Simplex copy								
U345	<p>Setting the value for maintenance due indication</p> <p>Description Sets when to display a message notifying that the time for maintenance is about to be reached, by setting the number of copies that can be made before the current maintenance cycle ends. When the difference between the number of copies of the maintenance cycle and that of the maintenance count reaches the set value, the message is displayed.</p> <p>Purpose To change the time for maintenance due indication.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the setting using the +/- keys or numeric keys. <table border="1" data-bbox="336 1368 1401 1570"> <thead> <tr> <th data-bbox="336 1368 488 1447">Display</th> <th data-bbox="488 1368 1094 1447">Description</th> <th data-bbox="1094 1368 1246 1447">Setting range</th> <th data-bbox="1246 1368 1401 1447">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1447 488 1570">Cnt</td> <td data-bbox="488 1447 1094 1570">Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)</td> <td data-bbox="1094 1447 1246 1570">0 to 9999</td> <td data-bbox="1246 1447 1401 1570">0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Cnt	Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)	0 to 9999	0
Display	Description	Setting range	Initial setting						
Cnt	Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)	0 to 9999	0						

Item No.	Description																														
U402	<p data-bbox="288 241 751 275">Adjusting margins of image printing</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 703 376">Adjusts margins for image printing.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 826 445">Make the adjustment if margins are incorrect.</p> <p data-bbox="288 483 440 512">Adjustment</p> <ol data-bbox="304 517 839 685" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Press the start key to output a test pattern. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 698 1399 974"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Lead</td> <td>Printer leading edge margin</td> <td>0.0 to 10.0</td> <td>4.0</td> <td>0.1 mm</td> </tr> <tr> <td>A Margin</td> <td>Printer left margin</td> <td>0.0 to 10.0</td> <td>3.0</td> <td>0.1 mm</td> </tr> <tr> <td>C Margin</td> <td>Printer right margin</td> <td>0.0 to 10.0</td> <td>3.0</td> <td>0.1 mm</td> </tr> <tr> <td>Trail</td> <td>Printer trailing edge margin</td> <td>0.0 to 10.0</td> <td>3.9</td> <td>0.1 mm</td> </tr> </tbody> </table> <ol data-bbox="304 987 1426 1055" style="list-style-type: none"> 6. Change the setting value using the +/- keys or numeric keys. Increasing the value makes the margin wider, and decreasing it makes the margin narrower. <div data-bbox="528 1077 1193 1496" style="text-align: center;"> </div> <p data-bbox="775 1525 946 1554">Figure 1-3-25</p> <ol data-bbox="304 1592 767 1624" style="list-style-type: none"> 7. Press the start key. The value is set. <p data-bbox="288 1662 392 1691">Caution</p> <p data-bbox="288 1695 1358 1762">If the above adjustment does not optimize the margins, perform the following maintenance modes.</p> <div data-bbox="293 1778 903 1872" style="text-align: center;"> <table border="1"> <tr> <td style="padding: 5px;">U039 (P.1-3-40)</td> <td style="text-align: center;">→</td> <td style="padding: 5px;">U034 (P.1-3-36)</td> <td style="text-align: center;">→</td> <td style="padding: 5px;">U402</td> </tr> </table> </div> <p data-bbox="288 1921 440 1951">Completion</p> <p data-bbox="288 1955 1254 1986">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	Lead	Printer leading edge margin	0.0 to 10.0	4.0	0.1 mm	A Margin	Printer left margin	0.0 to 10.0	3.0	0.1 mm	C Margin	Printer right margin	0.0 to 10.0	3.0	0.1 mm	Trail	Printer trailing edge margin	0.0 to 10.0	3.9	0.1 mm	U039 (P.1-3-40)	→	U034 (P.1-3-36)	→	U402
Display	Description	Setting range	Initial setting	Change in value per step																											
Lead	Printer leading edge margin	0.0 to 10.0	4.0	0.1 mm																											
A Margin	Printer left margin	0.0 to 10.0	3.0	0.1 mm																											
C Margin	Printer right margin	0.0 to 10.0	3.0	0.1 mm																											
Trail	Printer trailing edge margin	0.0 to 10.0	3.9	0.1 mm																											
U039 (P.1-3-40)	→	U034 (P.1-3-36)	→	U402																											

Item No.	Description																																
U403	<p data-bbox="288 241 1102 275">Adjusting margins for scanning an original on the contact glass</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1023 376">Adjusts margins for scanning the original on the contact glass.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 826 445">Make the adjustment if margins are incorrect.</p> <p data-bbox="288 483 440 512">Adjustment</p> <ol data-bbox="304 517 1058 685" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 698 1401 974"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>A Margin</td> <td>Scanner left margin</td> <td>0.0 to 10.0</td> <td>2.0</td> <td>0.5 mm</td> </tr> <tr> <td>B Margin</td> <td>Scanner leading edge margin</td> <td>0.0 to 10.0</td> <td>2.0</td> <td>0.5 mm</td> </tr> <tr> <td>C Margin</td> <td>Scanner right margin</td> <td>0.0 to 10.0</td> <td>2.0</td> <td>0.5 mm</td> </tr> <tr> <td>D Margin</td> <td>Scanner trailing edge margin</td> <td>0.0 to 10.0</td> <td>2.0</td> <td>0.5 mm</td> </tr> </tbody> </table> <ol data-bbox="304 987 1425 1055" style="list-style-type: none"> 6. Change the setting value using the +/- keys or numeric keys. Increasing the value makes the margin wider, and decreasing it makes the margin narrower. <div data-bbox="528 1077 1193 1496" style="text-align: center;"> <p data-bbox="708 1081 1134 1137">Leading edge margin of the copy image (4.0 +1.5/-1.0 mm)</p> <p data-bbox="528 1234 735 1317">Left margin of the copy image (2.5 +1.5/-2.0 mm)</p> <p data-bbox="991 1234 1193 1317">Right margin of the copy image (2.5 +1.5/-2.0 mm)</p> <p data-bbox="708 1440 1126 1496">Trailing edge margin of the copy image (4.0 mm or less)</p> </div> <p data-bbox="775 1525 946 1554">Figure 1-3-26</p> <ol data-bbox="304 1592 767 1624" style="list-style-type: none"> 7. Press the start key. The value is set. <p data-bbox="288 1662 392 1691">Caution</p> <p data-bbox="288 1695 1358 1762">If the above adjustment does not optimize the margins, perform the following maintenance modes.</p> <div data-bbox="293 1780 1129 1877" style="text-align: center;"> <table border="1"> <tr> <td style="padding: 5px;">U039 (P.1-3-40)</td> <td style="padding: 5px; text-align: center;">→</td> <td style="padding: 5px;">U034 (P.1-3-36)</td> <td style="padding: 5px; text-align: center;">→</td> <td style="padding: 5px;">U402 (P.1-3-153)</td> <td style="padding: 5px; text-align: center;">→</td> <td style="padding: 5px;">U403</td> </tr> </table> </div> <p data-bbox="288 1924 440 1953">Completion</p> <p data-bbox="288 1957 1246 1989">Press the stop key. The indication for selecting a maintenance item No. appears.</p>	Display	Description	Setting range	Initial setting	Change in value per step	A Margin	Scanner left margin	0.0 to 10.0	2.0	0.5 mm	B Margin	Scanner leading edge margin	0.0 to 10.0	2.0	0.5 mm	C Margin	Scanner right margin	0.0 to 10.0	2.0	0.5 mm	D Margin	Scanner trailing edge margin	0.0 to 10.0	2.0	0.5 mm	U039 (P.1-3-40)	→	U034 (P.1-3-36)	→	U402 (P.1-3-153)	→	U403
Display	Description	Setting range	Initial setting	Change in value per step																													
A Margin	Scanner left margin	0.0 to 10.0	2.0	0.5 mm																													
B Margin	Scanner leading edge margin	0.0 to 10.0	2.0	0.5 mm																													
C Margin	Scanner right margin	0.0 to 10.0	2.0	0.5 mm																													
D Margin	Scanner trailing edge margin	0.0 to 10.0	2.0	0.5 mm																													
U039 (P.1-3-40)	→	U034 (P.1-3-36)	→	U402 (P.1-3-153)	→	U403																											

Item No.	Description																																													
U404	<p data-bbox="288 241 997 275">Adjusting margins for scanning an original from the DP</p> <p data-bbox="288 309 440 342">Description</p> <p data-bbox="288 344 927 378">Adjusts margins for scanning the original from the DP.</p> <p data-bbox="288 380 400 414">Purpose</p> <p data-bbox="288 416 826 450">Make the adjustment if margins are incorrect.</p> <p data-bbox="288 483 440 517">Adjustment</p> <ol data-bbox="304 519 1182 685" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original on the DP and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 696 1401 1305"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>A Margin</td> <td>DP left margin</td> <td>0.0 to 10.0</td> <td>3.0</td> <td>0.5 mm</td> </tr> <tr> <td>B Margin</td> <td>DP leading edge margin</td> <td>0.0 to 10.0</td> <td>2.5</td> <td>0.5 mm</td> </tr> <tr> <td>C Margin</td> <td>DP right margin</td> <td>0.0 to 10.0</td> <td>3.0</td> <td>0.5 mm</td> </tr> <tr> <td>D Margin</td> <td>DP trailing edge margin</td> <td>0.0 to 10.0</td> <td>4.0</td> <td>0.5 mm</td> </tr> <tr> <td>A Margin (Back)*</td> <td>DP left margin (second side)</td> <td>0.0 to 10.0</td> <td>3.0</td> <td>0.5 mm</td> </tr> <tr> <td>B Margin (Back)*</td> <td>DP leading edge margin (second side)</td> <td>0.0 to 10.0</td> <td>2.5</td> <td>0.5 mm</td> </tr> <tr> <td>C Margin (Back)*</td> <td>DP right margin (second side)</td> <td>0.0 to 10.0</td> <td>3.0</td> <td>0.5 mm</td> </tr> <tr> <td>D Margin (Back)*</td> <td>DP trailing edge margin (second side)</td> <td>0.0 to 10.0</td> <td>4.0</td> <td>0.5 mm</td> </tr> </tbody> </table> <p data-bbox="336 1317 596 1350">* : Dual scan DP only</p> <ol data-bbox="304 1384 1423 1451" style="list-style-type: none"> 6. Change the setting value using the cursor left/right keys or numeric keys. Increasing the value makes the margin wider, and decreasing it makes the margin narrower. <div data-bbox="564 1473 1230 1895" style="text-align: center;"> <p data-bbox="778 1473 1043 1536">DP leading edge margin (4.0 +1.5/-1.0 mm)</p> <p data-bbox="564 1626 767 1688">DP left margin (2.5 +1.5/-2.0 mm)</p> <p data-bbox="1023 1626 1230 1688">DP right margin (2.5 +1.5/-2.0 mm)</p> <p data-bbox="778 1832 1043 1895">DP trailing edge margin (4.0 mm or less)</p> </div> <p data-bbox="778 1917 943 1951">Figure 1-3-27</p> <ol data-bbox="304 1984 767 2018" style="list-style-type: none"> 7. Press the start key. The value is set. 	Display	Description	Setting range	Initial setting	Change in value per step	A Margin	DP left margin	0.0 to 10.0	3.0	0.5 mm	B Margin	DP leading edge margin	0.0 to 10.0	2.5	0.5 mm	C Margin	DP right margin	0.0 to 10.0	3.0	0.5 mm	D Margin	DP trailing edge margin	0.0 to 10.0	4.0	0.5 mm	A Margin (Back)*	DP left margin (second side)	0.0 to 10.0	3.0	0.5 mm	B Margin (Back)*	DP leading edge margin (second side)	0.0 to 10.0	2.5	0.5 mm	C Margin (Back)*	DP right margin (second side)	0.0 to 10.0	3.0	0.5 mm	D Margin (Back)*	DP trailing edge margin (second side)	0.0 to 10.0	4.0	0.5 mm
Display	Description	Setting range	Initial setting	Change in value per step																																										
A Margin	DP left margin	0.0 to 10.0	3.0	0.5 mm																																										
B Margin	DP leading edge margin	0.0 to 10.0	2.5	0.5 mm																																										
C Margin	DP right margin	0.0 to 10.0	3.0	0.5 mm																																										
D Margin	DP trailing edge margin	0.0 to 10.0	4.0	0.5 mm																																										
A Margin (Back)*	DP left margin (second side)	0.0 to 10.0	3.0	0.5 mm																																										
B Margin (Back)*	DP leading edge margin (second side)	0.0 to 10.0	2.5	0.5 mm																																										
C Margin (Back)*	DP right margin (second side)	0.0 to 10.0	3.0	0.5 mm																																										
D Margin (Back)*	DP trailing edge margin (second side)	0.0 to 10.0	4.0	0.5 mm																																										

Item No.	Description
U404	<p data-bbox="290 241 395 271">Caution</p> <p data-bbox="290 277 1358 344">If the above adjustment does not optimize the margins, perform the following maintenance modes.</p> <div data-bbox="295 360 1358 456"><pre data-bbox="295 360 1358 456">graph LR; U039["U039 (P.1-3-40)"] --> U034["U034 (P.1-3-36)"]; U034 --> U402["U402 (P.1-3-153)"]; U402 --> U403["U403 (P.1-3-154)"]; U403 --> U404["U404"];</pre></div> <p data-bbox="290 506 440 535">Completion</p> <p data-bbox="290 542 1254 571">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Item No.	Description										
U407	<p data-bbox="290 241 1136 273">Adjusting the leading edge registration for memory image printing</p> <p data-bbox="290 311 440 338">Description</p> <p data-bbox="290 344 1018 376">Adjusts the leading edge registration during memory copying.</p> <p data-bbox="290 383 400 409">Purpose</p> <p data-bbox="290 416 1398 479">Make the following adjustment if there is a regular error between the leading edge of the copy image on the front face and that on the reverse face during duplex switchback copying.</p> <p data-bbox="290 517 392 544">Caution</p> <p data-bbox="290 551 1433 613">Before making this adjustment, ensure that the following adjustments have been made in maintenance mode</p> <div data-bbox="290 636 1433 842" style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <pre> graph LR U034["U034 (P.1-3-34)"] --> U402["U402 (P.1-3-153)"] U402 --> U066["U066 (P.1-3-54)"] U066 --> U403["U403 (P.1-3-154)"] U403 --> U071["U071 (P.1-3-59)"] U071 --> Arrow1[] U404["U404 (P.1-3-155)"] --> U407["U407"] style Arrow1 width:0px,height:0px </pre> </div> <p data-bbox="290 893 440 920">Adjustment</p> <ol data-bbox="304 927 1058 1061" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original and press the start key to make a test copy. 4. Press the system menu key. <table border="1" data-bbox="336 1077 1401 1240" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adj Data</td> <td>Leading edge registration for memory image printing</td> <td>-47 to 47</td> <td>0</td> <td>0.1 mm</td> </tr> </tbody> </table> <ol data-bbox="304 1256 1302 1319" style="list-style-type: none"> 5. Change the setting value using the +/- keys or numeric keys. For copy example 1, decrease the value. For copy example 2, increase the value. <div data-bbox="655 1346 1066 1585" style="text-align: center; margin: 10px 0;"> <div style="display: flex; justify-content: space-around; width: 100%;"> <div style="text-align: center;">  Original </div> <div style="text-align: center;">  Copy example 1 </div> <div style="text-align: center;">  Copy example 2 </div> </div> </div> <p data-bbox="775 1615 946 1641">Figure 1-3-28</p> <ol data-bbox="304 1686 766 1713" style="list-style-type: none"> 6. Press the start key. The value is set. <p data-bbox="290 1753 440 1780">Completion</p> <p data-bbox="290 1787 1254 1818">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	Adj Data	Leading edge registration for memory image printing	-47 to 47	0	0.1 mm
Display	Description	Setting range	Initial setting	Change in value per step							
Adj Data	Leading edge registration for memory image printing	-47 to 47	0	0.1 mm							


Item No.	Description																																						
U410	<p data-bbox="287 241 758 275">Adjusting the halftone automatically</p> <p data-bbox="287 309 438 342">Description</p> <p data-bbox="287 344 1412 412">Carries out processing for the data acquisition that is required in order to perform either automatic adjustment of the halftone or the ID correction operation. Also the color table is changed.</p> <p data-bbox="287 414 399 448">Purpose</p> <p data-bbox="287 450 1428 517">Performed when the quality of reproduced halftones has dropped. Modify the color table settings if the fidelity of characters is to be improved.</p> <p data-bbox="287 551 391 584">Method</p> <ol data-bbox="303 586 566 654" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="335 665 1401 846"> <thead> <tr> <th data-bbox="343 665 641 714">Display</th> <th data-bbox="641 665 1401 714">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 714 641 795">Normal Mode</td> <td data-bbox="641 714 1401 795">Executing the automatic adjustment of the halftone (continuous adjustment)</td> </tr> <tr> <td data-bbox="343 795 641 846">Setting Table</td> <td data-bbox="641 795 1401 846">Switching the color table</td> </tr> </tbody> </table> <p data-bbox="287 889 590 922">Method: [Normal Mode]</p> <ol data-bbox="303 925 1292 1473" style="list-style-type: none"> 1. Select [Normal Mode]. 2. Press the start key. A test patterns 1, 2 and 3 are outputted. 3. Place the output test pattern 1 as the original. Place approximately 20 sheets of white paper on the test pattern 1 and set them. 4. Press the start key. Adjustment is made (first time). 5. Place the output test pattern 2 as the original. Place approximately 20 sheets of white paper on the test pattern 2 and set them. 6. Press the start key. Adjustment is made (second time). 7. Place the output test pattern 3 as the original. Place approximately 20 sheets of white paper on the test pattern 3 and set them. 8. Press the start key. Adjustment is made (third time). 9. When normally completed, [Finish] is displayed. If a problem occurs during auto adjustment, error code is displayed. <p data-bbox="335 1512 486 1545">Error codes</p> <table border="1" data-bbox="335 1556 1401 1989"> <thead> <tr> <th data-bbox="343 1556 486 1606">Codes</th> <th data-bbox="486 1556 869 1606">Description</th> <th data-bbox="869 1556 1013 1606">Codes</th> <th data-bbox="1013 1556 1401 1606">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 1606 486 1655">S001</td> <td data-bbox="486 1606 869 1655">Patch not detected</td> <td data-bbox="869 1606 1013 1655">E001</td> <td data-bbox="1013 1606 1401 1655">Engine status error</td> </tr> <tr> <td data-bbox="343 1655 486 1749">S002</td> <td data-bbox="486 1655 869 1749">Original deviation in the main scanning direction</td> <td data-bbox="869 1655 1013 1749">E002</td> <td data-bbox="1013 1655 1401 1749">Engine sensor error</td> </tr> <tr> <td data-bbox="343 1749 486 1843">S003</td> <td data-bbox="486 1749 869 1843">Original deviation in the auxiliary scanning direction</td> <td data-bbox="869 1749 1013 1843">EFFF</td> <td data-bbox="1013 1749 1401 1843">Engine other error</td> </tr> <tr> <td data-bbox="343 1843 486 1892">S004</td> <td data-bbox="486 1843 869 1892">Original inclination error</td> <td data-bbox="869 1843 1013 1892">C001</td> <td data-bbox="1013 1843 1401 1892">Controller error</td> </tr> <tr> <td data-bbox="343 1892 486 1942">S005</td> <td data-bbox="486 1892 869 1942">Original type error</td> <td data-bbox="869 1892 1013 1942">C100</td> <td data-bbox="1013 1892 1401 1942">Adjustment value error</td> </tr> <tr> <td data-bbox="343 1942 486 1989">SFFF</td> <td data-bbox="486 1942 869 1989">Scanner other error</td> <td data-bbox="869 1942 1013 1989">C200</td> <td data-bbox="1013 1942 1401 1989">Adjustment value error</td> </tr> <tr> <td data-bbox="343 1989 486 2016"></td> <td data-bbox="486 1989 869 2016"></td> <td data-bbox="869 1989 1013 2016">CFFF</td> <td data-bbox="1013 1989 1401 2016">Controller other error</td> </tr> </tbody> </table>	Display	Description	Normal Mode	Executing the automatic adjustment of the halftone (continuous adjustment)	Setting Table	Switching the color table	Codes	Description	Codes	Description	S001	Patch not detected	E001	Engine status error	S002	Original deviation in the main scanning direction	E002	Engine sensor error	S003	Original deviation in the auxiliary scanning direction	EFFF	Engine other error	S004	Original inclination error	C001	Controller error	S005	Original type error	C100	Adjustment value error	SFFF	Scanner other error	C200	Adjustment value error			CFFF	Controller other error
Display	Description																																						
Normal Mode	Executing the automatic adjustment of the halftone (continuous adjustment)																																						
Setting Table	Switching the color table																																						
Codes	Description	Codes	Description																																				
S001	Patch not detected	E001	Engine status error																																				
S002	Original deviation in the main scanning direction	E002	Engine sensor error																																				
S003	Original deviation in the auxiliary scanning direction	EFFF	Engine other error																																				
S004	Original inclination error	C001	Controller error																																				
S005	Original type error	C100	Adjustment value error																																				
SFFF	Scanner other error	C200	Adjustment value error																																				
		CFFF	Controller other error																																				

Item No.	Description								
U410	<p data-bbox="288 244 587 275">Method: [Setting Table]</p> <p data-bbox="288 280 523 311">1. Select the item.</p> <table border="1" data-bbox="336 322 1401 546"> <thead> <tr> <th data-bbox="336 322 639 367">Display</th> <th data-bbox="639 322 1401 367">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 367 639 412">Table1</td> <td data-bbox="639 367 1401 412">Normal color table</td> </tr> <tr> <td data-bbox="336 412 639 501">Table2</td> <td data-bbox="639 412 1401 501">Color tables for improving reproduction of characters at black and white printing</td> </tr> <tr> <td data-bbox="336 501 639 546">Table3</td> <td data-bbox="639 501 1401 546">More fidelity than Table2</td> </tr> </tbody> </table> <p data-bbox="336 562 579 593">Initial setting: Table1</p> <p data-bbox="288 598 783 629">2. Press the start key. The setting is set.</p> <p data-bbox="288 667 440 698">Completion</p> <p data-bbox="288 703 1257 734">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Table1	Normal color table	Table2	Color tables for improving reproduction of characters at black and white printing	Table3	More fidelity than Table2
Display	Description								
Table1	Normal color table								
Table2	Color tables for improving reproduction of characters at black and white printing								
Table3	More fidelity than Table2								

Item No.	Description																											
U411	<p data-bbox="287 241 751 275">Adjusting the scanner automatically</p> <p data-bbox="287 311 440 340">Description</p> <p data-bbox="287 344 1425 409">Uses a specified original and automatically adjusts the following items in the scanner and the DP scanning sections.</p> <p data-bbox="287 414 400 443">Purpose</p> <p data-bbox="287 448 1425 546">To perform automatic adjustment of various items in the scanner and the DP scanning sections. Perform adjustments using a new test chart (chart 1) when replacing ISC PWB, LED lamp PWB, ISU, CIS and/or DP main PWB.</p> <p data-bbox="287 589 387 618">Method</p> <ol data-bbox="304 622 564 685" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 701 1401 1512"> <thead> <tr> <th data-bbox="336 701 564 779">Display</th> <th data-bbox="564 701 1098 779">Description</th> <th data-bbox="1098 701 1401 779">Original to be used for adjustment (P/N)</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 779 564 864">Table (Chart1)</td> <td data-bbox="564 779 1098 864">Automatic adjustment in the scanner section (chart 1)</td> <td data-bbox="1098 779 1401 864">7505000005</td> </tr> <tr> <td data-bbox="336 864 564 983">DP FaceUp (Chart1)</td> <td data-bbox="564 864 1098 983">Do not use. Automatic adjustment in the DP scanning section (first side) (chart 1)</td> <td data-bbox="1098 864 1401 983">7505000005</td> </tr> <tr> <td data-bbox="336 983 564 1068">DP FaceDown (Chart1)</td> <td data-bbox="564 983 1098 1068">Automatic adjustment in the DP scanning section (second side) (chart 1)</td> <td data-bbox="1098 983 1401 1068">7505000005</td> </tr> <tr> <td data-bbox="336 1068 564 1153">Table (Chart2)</td> <td data-bbox="564 1068 1098 1153">Automatic adjustment in the scanner section (chart 2)</td> <td data-bbox="1098 1068 1401 1153">302FZ56990</td> </tr> <tr> <td data-bbox="336 1153 564 1238">DP FaceUp (Chart2)</td> <td data-bbox="564 1153 1098 1238">Automatic adjustment in the DP scanning section (first side) (chart 2)</td> <td data-bbox="1098 1153 1401 1238">302AC68243</td> </tr> <tr> <td data-bbox="336 1238 564 1357">DP FaceDown (Chart2)</td> <td data-bbox="564 1238 1098 1357">Automatic adjustment in the DP scanning section (second side) (chart 2)</td> <td data-bbox="1098 1238 1401 1357">302AC68243/ 303JX57010/ 303JX57020</td> </tr> <tr> <td data-bbox="336 1357 564 1400">Target</td> <td data-bbox="564 1357 1098 1400">Set-up for obtaining the target value</td> <td data-bbox="1098 1357 1401 1400">-</td> </tr> <tr> <td data-bbox="336 1400 564 1512">DP Auto Adj</td> <td data-bbox="564 1400 1098 1512">Automatic adjustment of automatic document processor using the chart printed from the machine</td> <td data-bbox="1098 1400 1401 1512">-</td> </tr> </tbody> </table> <p data-bbox="287 1554 600 1585">Method: [Table (Chart1)]</p> <p data-bbox="287 1590 695 1619">To manually enter the target value</p> <ol data-bbox="304 1624 1259 1895" style="list-style-type: none"> 1. Enter the target values which are shown at the bottom of the specified original (P/N: 7505000005) executing maintenance item U425. 2. Set a specified original on the platen. 3. Enter maintenance item U411. 4. Select [Target]. 5. Select [U425] and press the start key. 6. Select [Table (Chart1)]. 7. Select the item. 	Display	Description	Original to be used for adjustment (P/N)	Table (Chart1)	Automatic adjustment in the scanner section (chart 1)	7505000005	DP FaceUp (Chart1)	Do not use. Automatic adjustment in the DP scanning section (first side) (chart 1)	7505000005	DP FaceDown (Chart1)	Automatic adjustment in the DP scanning section (second side) (chart 1)	7505000005	Table (Chart2)	Automatic adjustment in the scanner section (chart 2)	302FZ56990	DP FaceUp (Chart2)	Automatic adjustment in the DP scanning section (first side) (chart 2)	302AC68243	DP FaceDown (Chart2)	Automatic adjustment in the DP scanning section (second side) (chart 2)	302AC68243/ 303JX57010/ 303JX57020	Target	Set-up for obtaining the target value	-	DP Auto Adj	Automatic adjustment of automatic document processor using the chart printed from the machine	-
Display	Description	Original to be used for adjustment (P/N)																										
Table (Chart1)	Automatic adjustment in the scanner section (chart 1)	7505000005																										
DP FaceUp (Chart1)	Do not use. Automatic adjustment in the DP scanning section (first side) (chart 1)	7505000005																										
DP FaceDown (Chart1)	Automatic adjustment in the DP scanning section (second side) (chart 1)	7505000005																										
Table (Chart2)	Automatic adjustment in the scanner section (chart 2)	302FZ56990																										
DP FaceUp (Chart2)	Automatic adjustment in the DP scanning section (first side) (chart 2)	302AC68243																										
DP FaceDown (Chart2)	Automatic adjustment in the DP scanning section (second side) (chart 2)	302AC68243/ 303JX57010/ 303JX57020																										
Target	Set-up for obtaining the target value	-																										
DP Auto Adj	Automatic adjustment of automatic document processor using the chart printed from the machine	-																										

Item No.	Description																		
U411	<p>To automatically enter the target value</p> <ol style="list-style-type: none"> 1. Enter the value for [Adjust Original] using maintenance item U425. 2. Set a specified original (P/N: 7505000005) on the platen. 3. Enter maintenance item U411. 4. Select [Target]. 5. Select [Auto] and press the start key. 6. Select [Table (Chart1)]. 7. Select the item. <table border="1" data-bbox="336 562 1401 1028"> <thead> <tr> <th data-bbox="336 562 639 607">Display</th> <th data-bbox="639 562 1401 607">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 607 639 651">All</td> <td data-bbox="639 607 1401 651">Executing the all scanner adjustment</td> </tr> <tr> <td data-bbox="336 651 639 696">LED/AGC</td> <td data-bbox="639 651 1401 696">Executing the adjustment for LED light quantity/AGC</td> </tr> <tr> <td data-bbox="336 696 639 741">White</td> <td data-bbox="639 696 1401 741">Executing the white reference compensation coefficient</td> </tr> <tr> <td data-bbox="336 741 639 831">Input</td> <td data-bbox="639 741 1401 831">Executing the adjustment for magnification, leading edge timing and center line</td> </tr> <tr> <td data-bbox="336 831 639 875">C.A.</td> <td data-bbox="639 831 1401 875">Executing the adjustment for chromatic aberration filter</td> </tr> <tr> <td data-bbox="336 875 639 920">MTF</td> <td data-bbox="639 875 1401 920">Executing the adjustment for MTF filter</td> </tr> <tr> <td data-bbox="336 920 639 965">Gamma</td> <td data-bbox="639 920 1401 965">Executing the adjustment for input gamma</td> </tr> <tr> <td data-bbox="336 965 639 1010">Matrix</td> <td data-bbox="639 965 1401 1010">Executing the adjustment for matrix</td> </tr> </tbody> </table> <p>8. Press the start key. Auto adjustment starts.</p> <p>* : When automatic adjustment has normally completed, [OK] is displayed. If a problem occurs during auto adjustment, error code is displayed and operation stops. Should this happen, determine the details of the problem and repeat the procedure from the beginning.</p> <p>Method: [DP FaceUp (Chart1)]</p> <p>To manually enter the target value</p> <ol style="list-style-type: none"> 1. Enter the target values which are shown at the bottom of the specified original (P/N: 7505000005) executing maintenance item U425. 2. Set a specified original on the DP face up. 3. Enter maintenance item U411. 4. Select [Target]. 5. Select [U425] and press the start key. 6. Select [DP FaceUp (Chart1)]. 7. Select [Input]. <p>To automatically enter the target value</p> <ol style="list-style-type: none"> 1. Enter the value for [Adjust Original] using maintenance item U425. 2. Set a specified original (P/N: 7505000005) on the DP face up. 3. Enter maintenance item U411. 4. Select [Target]. 5. Select [Auto] and press the start key. 6. Select [DP FaceUp (Chart1)]. 7. Select [Input]. 	Display	Description	All	Executing the all scanner adjustment	LED/AGC	Executing the adjustment for LED light quantity/AGC	White	Executing the white reference compensation coefficient	Input	Executing the adjustment for magnification, leading edge timing and center line	C.A.	Executing the adjustment for chromatic aberration filter	MTF	Executing the adjustment for MTF filter	Gamma	Executing the adjustment for input gamma	Matrix	Executing the adjustment for matrix
Display	Description																		
All	Executing the all scanner adjustment																		
LED/AGC	Executing the adjustment for LED light quantity/AGC																		
White	Executing the white reference compensation coefficient																		
Input	Executing the adjustment for magnification, leading edge timing and center line																		
C.A.	Executing the adjustment for chromatic aberration filter																		
MTF	Executing the adjustment for MTF filter																		
Gamma	Executing the adjustment for input gamma																		
Matrix	Executing the adjustment for matrix																		

Item No.	Description								
U411	<table border="1" data-bbox="336 286 1401 383"> <thead> <tr> <th data-bbox="336 286 641 331">Display</th> <th data-bbox="641 286 1401 331">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 331 641 383">Input</td> <td data-bbox="641 331 1401 383">Executing the adjustment for input gamma and matrix</td> </tr> </tbody> </table> <p data-bbox="304 392 845 421">8. Press the start key. Auto adjustment starts.</p> <p data-bbox="336 427 1409 562">* : When automatic adjustment has normally completed, [OK] is displayed. If a problem occurs during auto adjustment, error code is displayed and operation stops. Should this happen, determine the details of the problem and repeat the procedure from the beginning.</p> <p data-bbox="288 600 710 629">Method: [DP FaceDown (Chart1)]</p> <p data-bbox="288 636 695 665">To manually enter the target value</p> <ol data-bbox="304 672 1259 943" style="list-style-type: none"> 1. Enter the target values which are shown at the bottom of the specified original (P/N: 7505000005) executing maintenance item U425. 2. Set a specified original on the DP face down. 3. Enter maintenance item U411. 4. Select [Target]. 5. Select [U425] and press the start key. 6. Select [DP FaceDown (Chart1)]. 7. Select [All]. <p data-bbox="288 981 743 1010">To automatically enter the target value</p> <ol data-bbox="304 1016 1120 1256" style="list-style-type: none"> 1. Enter the value for [Adjust Original] using maintenance item U425. 2. Set a specified original (P/N: 7505000005) on the DP face down. 3. Enter maintenance item U411. 4. Select [Target]. 5. Select [Auto] and press the start key. 6. Select [DP FaceDown (Chart1)]. 7. Select [All]. <table border="1" data-bbox="336 1301 1401 1464"> <thead> <tr> <th data-bbox="336 1301 641 1346">Display</th> <th data-bbox="641 1301 1401 1346">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1346 641 1464">All</td> <td data-bbox="641 1346 1401 1464">Executing the adjustment in the DP scanning section (second side) for magnification, leading edge timing, center line, MTF filter, input gamma and matrix</td> </tr> </tbody> </table> <p data-bbox="304 1473 845 1503">8. Press the start key. Auto adjustment starts.</p> <p data-bbox="336 1509 1409 1644">* : When automatic adjustment has normally completed, [OK] is displayed. If a problem occurs during auto adjustment, error code is displayed and operation stops. Should this happen, determine the details of the problem and repeat the procedure from the beginning.</p>	Display	Description	Input	Executing the adjustment for input gamma and matrix	Display	Description	All	Executing the adjustment in the DP scanning section (second side) for magnification, leading edge timing, center line, MTF filter, input gamma and matrix
Display	Description								
Input	Executing the adjustment for input gamma and matrix								
Display	Description								
All	Executing the adjustment in the DP scanning section (second side) for magnification, leading edge timing, center line, MTF filter, input gamma and matrix								

Item No.	Description																		
<p>U411</p>	<p>Method: [Table (Chart2)]</p> <ol style="list-style-type: none"> 1. Enter the target values which are shown on the back of the specified original (P/N: 302FZ56990) executing maintenance item U425. 2. Set a specified original on the platen. 3. Enter maintenance item U411. 4. Select [Target]. 5. Select [U425] and press the start key. 6. Select [Table (Chart2)]. 7. Select the item. <table border="1" data-bbox="336 562 1401 931"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>All</td> <td>Executing the all scanner adjustment</td> </tr> <tr> <td>Input</td> <td>Executing the adjustment for magnification, leading edge timing and center line</td> </tr> <tr> <td>C.A.</td> <td>Executing the adjustment for chromatic aberration filter</td> </tr> <tr> <td>MTF</td> <td>Executing the adjustment for MTF filter</td> </tr> <tr> <td>Gamma</td> <td>Executing the adjustment for input gamma</td> </tr> <tr> <td>Matrix</td> <td>Executing the adjustment for matrix</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 8. Press the start key. Auto adjustment starts. <p>* : When automatic adjustment has normally completed, [OK] is displayed. If a problem occurs during auto adjustment, error code is displayed and operation stops. Should this happen, determine the details of the problem and repeat the procedure from the beginning.</p> <p>Method: [DP FaceUp (Chart2)]</p> <ol style="list-style-type: none"> 1. Measure the leading edge, main scanning, and auxiliary scanning of the specified original (P/N: 302AC68243) and enter the values by executing maintenance item U425. 2. Set a specified original (P/N: 302AC68243) on the DP. Cut the trailing edge of the original.  <p style="text-align: center;">Figure 1-3-29</p> <ol style="list-style-type: none"> 3. Enter maintenance item U411. 4. Select [Target]. 5. Select [U425] and press the start key. 6. Select [DP FaceUp (Chart2)]. 7. Select [INPUT]. <table border="1" data-bbox="336 1816 1401 1944"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Input</td> <td>Executing the adjustment in the DP scanning section (first side) for magnification, leading edge timing and center line</td> </tr> </tbody> </table>	Display	Description	All	Executing the all scanner adjustment	Input	Executing the adjustment for magnification, leading edge timing and center line	C.A.	Executing the adjustment for chromatic aberration filter	MTF	Executing the adjustment for MTF filter	Gamma	Executing the adjustment for input gamma	Matrix	Executing the adjustment for matrix	Display	Description	Input	Executing the adjustment in the DP scanning section (first side) for magnification, leading edge timing and center line
Display	Description																		
All	Executing the all scanner adjustment																		
Input	Executing the adjustment for magnification, leading edge timing and center line																		
C.A.	Executing the adjustment for chromatic aberration filter																		
MTF	Executing the adjustment for MTF filter																		
Gamma	Executing the adjustment for input gamma																		
Matrix	Executing the adjustment for matrix																		
Display	Description																		
Input	Executing the adjustment in the DP scanning section (first side) for magnification, leading edge timing and center line																		

Item No.	Description															
U411	<p data-bbox="304 241 845 271">8. Press the start key. Auto adjustment starts.</p> <p data-bbox="336 277 1406 409">* : When automatic adjustment has normally completed, [OK] is displayed. If a problem occurs during auto adjustment, error code is displayed and operation stops. Should this happen, determine the details of the problem and repeat the procedure from the beginning.</p> <p data-bbox="288 450 708 479">Method: [DP FaceDown (Chart2)]</p> <ol data-bbox="304 486 1425 685" style="list-style-type: none"> 1. Place the specified original for acquiring gamma target data (P/N: 303JX57010) on the platen, and press the start key. 2. Place the specified original for acquiring matrix target data (P/N: 303JX57020) on the platen, and press the start key. When normally completed, [OK] is displayed. 3. Select the item. <table border="1" data-bbox="336 701 1401 1249"> <thead> <tr> <th data-bbox="336 701 564 779">Display</th> <th data-bbox="564 701 1098 779">Description</th> <th data-bbox="1098 701 1401 779">Original to be used for adjustment (P/N)</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 779 564 936">All</td> <td data-bbox="564 779 1098 936">Executing the adjustment in the DP scanning section (second side) for magnification, leading edge timing, center line, MTF filter, input gamma and matrix</td> <td data-bbox="1098 779 1401 936">302AC68243/ 303JX57010/ 303JX57020</td> </tr> <tr> <td data-bbox="336 936 564 1048">Input</td> <td data-bbox="564 936 1098 1048">Executing the adjustment in the DP scanning section (second side) for magnification, leading edge timing and center line</td> <td data-bbox="1098 936 1401 1048">302AC68243</td> </tr> <tr> <td data-bbox="336 1048 564 1171">MTF/Gamma</td> <td data-bbox="564 1048 1098 1171">Executing the adjustment in the DP scanning section (second side) for MTF filter and input gamma</td> <td data-bbox="1098 1048 1401 1171">303JX57010</td> </tr> <tr> <td data-bbox="336 1171 564 1249">Matrix</td> <td data-bbox="564 1171 1098 1249">Executing the adjustment in the DP scanning section (second side) for matrix</td> <td data-bbox="1098 1171 1401 1249">303JX57020</td> </tr> </tbody> </table> <p data-bbox="288 1294 373 1323">[Input]</p> <ol data-bbox="304 1330 1094 1426" style="list-style-type: none"> 1. Select [Input]. 2. Set a specified original (P/N: 302AC6824) on the DP face down. 3. Press the start key. Auto adjustment starts. <p data-bbox="288 1467 469 1496">[MTF/Gamma]</p> <ol data-bbox="304 1503 1102 1599" style="list-style-type: none"> 1. Select [MTF/Gamma]. 2. Set a specified original (P/N: 303JX57010) on the DP face down. 3. Press the start key. Auto adjustment starts. <p data-bbox="288 1639 389 1668">[Matrix]</p> <ol data-bbox="304 1675 1102 1771" style="list-style-type: none"> 1. Select [Matrix]. 2. Set a specified original (P/N: 303JX57020) on the DP face down. 3. Press the start key. Auto adjustment starts. <p data-bbox="288 1812 1430 1908">When [ALL] is selected, the adjustment of [Input], [MTF/Gamma] and [Matrix] can be executed at once. When adjusting, place the three specified originals on the DP face down, and then press the start key.</p> <p data-bbox="288 1915 1417 1980">Set the original 303JX57020, and then place 303JX57010 and 302AC68243 in order on the top of the original.</p>	Display	Description	Original to be used for adjustment (P/N)	All	Executing the adjustment in the DP scanning section (second side) for magnification, leading edge timing, center line, MTF filter, input gamma and matrix	302AC68243/ 303JX57010/ 303JX57020	Input	Executing the adjustment in the DP scanning section (second side) for magnification, leading edge timing and center line	302AC68243	MTF/Gamma	Executing the adjustment in the DP scanning section (second side) for MTF filter and input gamma	303JX57010	Matrix	Executing the adjustment in the DP scanning section (second side) for matrix	303JX57020
Display	Description	Original to be used for adjustment (P/N)														
All	Executing the adjustment in the DP scanning section (second side) for magnification, leading edge timing, center line, MTF filter, input gamma and matrix	302AC68243/ 303JX57010/ 303JX57020														
Input	Executing the adjustment in the DP scanning section (second side) for magnification, leading edge timing and center line	302AC68243														
MTF/Gamma	Executing the adjustment in the DP scanning section (second side) for MTF filter and input gamma	303JX57010														
Matrix	Executing the adjustment in the DP scanning section (second side) for matrix	303JX57020														

Item No.	Description																																						
U411	<p>* : When automatic adjustment has normally completed, [OK] is displayed. If a problem occurs during auto adjustment, error code is displayed and operation stops. Should this happen, determine the details of the problem and repeat the procedure from the beginning.</p> <p>Method: [DP Auto Adj]</p> <ol style="list-style-type: none"> 1. Load A4/letter paper. 2. Press the start key to output the original for adjustment. 3. Set the output the original for adjustment and press the start key. 4. Set the output the original for adjustment on the DP face up. 5. Press the start key to scan documents. 6. Press the start key. Auto adjustment of first side starts. 7. Set the output the original for adjustment on the DP face down. 8. Press the start key to scan documents. 9. Press the start key. Auto adjustment of second side starts. <p>* : When automatic adjustment has normally completed, [OK] is displayed. If a problem occurs during auto adjustment, error code is displayed and operation stops. Should this happen, determine the details of the problem and repeat the procedure from the beginning.</p> <p>Error Codes</p> <table border="1" data-bbox="336 976 1401 1991"> <thead> <tr> <th data-bbox="336 976 451 1021">Codes</th> <th data-bbox="451 976 1401 1021">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1021 451 1111">01</td> <td data-bbox="451 1021 1401 1111">Black band detection error (scanner auxiliary scanning direction leading edge skew)</td> </tr> <tr> <td data-bbox="336 1111 451 1155">02</td> <td data-bbox="451 1111 1401 1155">Black band detection error (scanner main scanning direction far end skew)</td> </tr> <tr> <td data-bbox="336 1155 451 1200">03</td> <td data-bbox="451 1155 1401 1200">Black band detection error (scanner main scanning direction near end skew)</td> </tr> <tr> <td data-bbox="336 1200 451 1290">03</td> <td data-bbox="451 1200 1401 1290">Black band detection error (scanner auxiliary scanning direction trailing edge skew)</td> </tr> <tr> <td data-bbox="336 1290 451 1335">04</td> <td data-bbox="451 1290 1401 1335">Black band is not detected (scanner auxiliary scanning direction leading edge)</td> </tr> <tr> <td data-bbox="336 1335 451 1379">05</td> <td data-bbox="451 1335 1401 1379">Black band is not detected (scanner main scanning direction far end)</td> </tr> <tr> <td data-bbox="336 1379 451 1424">06</td> <td data-bbox="451 1379 1401 1424">Black band is not detected (scanner main scanning direction near end)</td> </tr> <tr> <td data-bbox="336 1424 451 1469">07</td> <td data-bbox="451 1424 1401 1469">Black band is not detected (scanner auxiliary scanning direction trailing edge)</td> </tr> <tr> <td data-bbox="336 1469 451 1514">08</td> <td data-bbox="451 1469 1401 1514">Black band is not detected (DP main scanning direction far end)</td> </tr> <tr> <td data-bbox="336 1514 451 1559">09</td> <td data-bbox="451 1514 1401 1559">Black band is not detected (DP main scanning direction near end)</td> </tr> <tr> <td data-bbox="336 1559 451 1626">0a</td> <td data-bbox="451 1559 1401 1626">Black band is not detected (DP auxiliary scanning direction leading edge)</td> </tr> <tr> <td data-bbox="336 1626 451 1715">0b</td> <td data-bbox="451 1626 1401 1715">Black band is not detected (DP auxiliary scanning direction leading edge original check)</td> </tr> <tr> <td data-bbox="336 1715 451 1760">0c</td> <td data-bbox="451 1715 1401 1760">Black band is not detected (DP auxiliary scanning direction trailing edge)</td> </tr> <tr> <td data-bbox="336 1760 451 1805">0d</td> <td data-bbox="451 1760 1401 1805">White band is not detected (DP auxiliary scanning direction trailing edge)</td> </tr> <tr> <td data-bbox="336 1805 451 1850">0e</td> <td data-bbox="451 1805 1401 1850">DMA time out</td> </tr> <tr> <td data-bbox="336 1850 451 1895">0f</td> <td data-bbox="451 1850 1401 1895">Auxiliary scanning direction magnification error</td> </tr> <tr> <td data-bbox="336 1895 451 1939">10</td> <td data-bbox="451 1895 1401 1939">Auxiliary scanning direction leading edge error</td> </tr> <tr> <td data-bbox="336 1939 451 1984">11</td> <td data-bbox="451 1939 1401 1984">Auxiliary scanning direction trailing edge error</td> </tr> </tbody> </table>	Codes	Description	01	Black band detection error (scanner auxiliary scanning direction leading edge skew)	02	Black band detection error (scanner main scanning direction far end skew)	03	Black band detection error (scanner main scanning direction near end skew)	03	Black band detection error (scanner auxiliary scanning direction trailing edge skew)	04	Black band is not detected (scanner auxiliary scanning direction leading edge)	05	Black band is not detected (scanner main scanning direction far end)	06	Black band is not detected (scanner main scanning direction near end)	07	Black band is not detected (scanner auxiliary scanning direction trailing edge)	08	Black band is not detected (DP main scanning direction far end)	09	Black band is not detected (DP main scanning direction near end)	0a	Black band is not detected (DP auxiliary scanning direction leading edge)	0b	Black band is not detected (DP auxiliary scanning direction leading edge original check)	0c	Black band is not detected (DP auxiliary scanning direction trailing edge)	0d	White band is not detected (DP auxiliary scanning direction trailing edge)	0e	DMA time out	0f	Auxiliary scanning direction magnification error	10	Auxiliary scanning direction leading edge error	11	Auxiliary scanning direction trailing edge error
Codes	Description																																						
01	Black band detection error (scanner auxiliary scanning direction leading edge skew)																																						
02	Black band detection error (scanner main scanning direction far end skew)																																						
03	Black band detection error (scanner main scanning direction near end skew)																																						
03	Black band detection error (scanner auxiliary scanning direction trailing edge skew)																																						
04	Black band is not detected (scanner auxiliary scanning direction leading edge)																																						
05	Black band is not detected (scanner main scanning direction far end)																																						
06	Black band is not detected (scanner main scanning direction near end)																																						
07	Black band is not detected (scanner auxiliary scanning direction trailing edge)																																						
08	Black band is not detected (DP main scanning direction far end)																																						
09	Black band is not detected (DP main scanning direction near end)																																						
0a	Black band is not detected (DP auxiliary scanning direction leading edge)																																						
0b	Black band is not detected (DP auxiliary scanning direction leading edge original check)																																						
0c	Black band is not detected (DP auxiliary scanning direction trailing edge)																																						
0d	White band is not detected (DP auxiliary scanning direction trailing edge)																																						
0e	DMA time out																																						
0f	Auxiliary scanning direction magnification error																																						
10	Auxiliary scanning direction leading edge error																																						
11	Auxiliary scanning direction trailing edge error																																						

Item No.	Description																																
U411	<p data-bbox="335 241 494 273">Error Codes</p> <table border="1" data-bbox="335 286 1401 1052"> <thead> <tr> <th data-bbox="343 297 446 331">Codes</th> <th data-bbox="446 297 1393 331">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 342 446 376">12</td> <td data-bbox="446 342 1393 376">DP uxiliary scanning direction skew error</td> </tr> <tr> <td data-bbox="343 387 446 421">13</td> <td data-bbox="446 387 1393 421">Maintenance request error</td> </tr> <tr> <td data-bbox="343 432 446 465">14</td> <td data-bbox="446 432 1393 465">Main scanning direction center line error</td> </tr> <tr> <td data-bbox="343 477 446 510">15</td> <td data-bbox="446 477 1393 510">DP main scanning direction skew error</td> </tr> <tr> <td data-bbox="343 521 446 555">16</td> <td data-bbox="446 521 1393 555">Main scanning direction magnification error</td> </tr> <tr> <td data-bbox="343 566 446 600">17</td> <td data-bbox="446 566 1393 600">Service call error</td> </tr> <tr> <td data-bbox="343 611 446 645">18</td> <td data-bbox="446 611 1393 645">DP paper misfeed error</td> </tr> <tr> <td data-bbox="343 656 446 689">19</td> <td data-bbox="446 656 1393 689">PWB replacement error</td> </tr> <tr> <td data-bbox="343 701 446 734">1a</td> <td data-bbox="446 701 1393 734">Original error</td> </tr> <tr> <td data-bbox="343 745 446 779">1b</td> <td data-bbox="446 745 1393 779">Input gamma adjustment original error</td> </tr> <tr> <td data-bbox="343 790 446 824">1c</td> <td data-bbox="446 790 1393 824">Matrix adjustment original error</td> </tr> <tr> <td data-bbox="343 835 446 869">1d</td> <td data-bbox="446 835 1393 869">Original for the white reference compensation coefficient error</td> </tr> <tr> <td data-bbox="343 880 446 913">1e</td> <td data-bbox="446 880 1393 913">Lab value searching error</td> </tr> <tr> <td data-bbox="343 925 446 958">1f</td> <td data-bbox="446 925 1393 958">Lab value comparing error</td> </tr> <tr> <td data-bbox="343 969 446 1003">63</td> <td data-bbox="446 969 1393 1003">Completed to obtain a test RAW</td> </tr> </tbody> </table> <p data-bbox="287 1104 438 1135">Completion</p> <p data-bbox="287 1137 1252 1169">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Codes	Description	12	DP uxiliary scanning direction skew error	13	Maintenance request error	14	Main scanning direction center line error	15	DP main scanning direction skew error	16	Main scanning direction magnification error	17	Service call error	18	DP paper misfeed error	19	PWB replacement error	1a	Original error	1b	Input gamma adjustment original error	1c	Matrix adjustment original error	1d	Original for the white reference compensation coefficient error	1e	Lab value searching error	1f	Lab value comparing error	63	Completed to obtain a test RAW
Codes	Description																																
12	DP uxiliary scanning direction skew error																																
13	Maintenance request error																																
14	Main scanning direction center line error																																
15	DP main scanning direction skew error																																
16	Main scanning direction magnification error																																
17	Service call error																																
18	DP paper misfeed error																																
19	PWB replacement error																																
1a	Original error																																
1b	Input gamma adjustment original error																																
1c	Matrix adjustment original error																																
1d	Original for the white reference compensation coefficient error																																
1e	Lab value searching error																																
1f	Lab value comparing error																																
63	Completed to obtain a test RAW																																

Item No.	Description						
U412	<p data-bbox="288 241 667 275">Adjusting the uneven density</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1426 412">Adjusts the uneven developer/transfer density in the drum axis direction by scanning directly the density distribution of test pattern with the scanner and adjusting LSU light quantity.</p> <p data-bbox="288 416 400 445">Purpose</p> <p data-bbox="288 450 1027 479">To perform when replacing the drum unit or laser scanner unit.</p> <p data-bbox="288 483 1054 512">When completed, perform maintenance mode U464, Calibration.</p> <p data-bbox="288 553 387 582">Method</p> <ol data-bbox="304 589 564 651" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 665 1399 808"> <thead> <tr> <th data-bbox="336 665 639 712">Display</th> <th data-bbox="639 665 1399 712">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 712 639 759">Normal Mode</td> <td data-bbox="639 712 1399 759">Executing the uneven density correction</td> </tr> <tr> <td data-bbox="336 759 639 808">On/Off Config</td> <td data-bbox="639 759 1399 808">Uneven density correction ON/OFF setting</td> </tr> </tbody> </table> <p data-bbox="288 851 592 880">Method: [Normal Mode]</p> <ol data-bbox="304 884 1406 1469" style="list-style-type: none"> 1. Select [Default Value]. A test pattern is outputted with the initial light quantity setting. (1st sheet) 2. Place approximately 20 sheets of white paper on the output test pattern and place as the original. 3. Press the start key. the correction starts. 4. After the correction is completed, and press the start key. A test pattern is outputted. (2nd sheet) A test pattern is outputted with light quantity setting lower than the 1st test pattern by 20%. 5. Place approximately 20 sheets of white paper on the output test pattern and place as the original. 6. Press the start key. the correction starts. 7. After the correction is completed, and press the start key. A test pattern is outputted. (3rd sheet) 8. Place approximately 20 sheets of white paper on the output test pattern and place as the original. 9. Press the start key. The correction result is checked. When normally completed, [OK] is displayed. <p data-bbox="288 1509 488 1538">Retry (1st time)</p> <ol data-bbox="304 1543 1078 1608" style="list-style-type: none"> 10. If the correction is not completed normally, [Retry] is displayed. 11. Repeat steps 4 and 9. <p data-bbox="288 1648 496 1677">Retry (2nd time)</p> <ol data-bbox="304 1682 1123 1780" style="list-style-type: none"> 12. If the correction is not completed normally, [Retry] is displayed. 13. Repeat steps 4 and 9. If a problem occurs during auto correction, error code is displayed. 	Display	Description	Normal Mode	Executing the uneven density correction	On/Off Config	Uneven density correction ON/OFF setting
Display	Description						
Normal Mode	Executing the uneven density correction						
On/Off Config	Uneven density correction ON/OFF setting						

Item No.	Description																																	
U412	Error codes																																	
	<table border="1"> <thead> <tr> <th data-bbox="336 286 488 331">Codes</th> <th data-bbox="488 286 869 331">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 331 488 376">S001</td> <td data-bbox="488 331 869 376">Patch not detected</td> </tr> <tr> <td data-bbox="336 376 488 421">S002</td> <td data-bbox="488 376 869 421">Original deviation in the main scanning direction</td> </tr> <tr> <td data-bbox="336 421 488 465">S003</td> <td data-bbox="488 421 869 465">Original deviation in the auxiliary scanning direction</td> </tr> <tr> <td data-bbox="336 465 488 510">S004</td> <td data-bbox="488 465 869 510">Original inclination error</td> </tr> <tr> <td data-bbox="336 510 488 555">S005</td> <td data-bbox="488 510 869 555">Original type error</td> </tr> <tr> <td data-bbox="336 555 488 600">SFFF</td> <td data-bbox="488 555 869 600">Scanner other error</td> </tr> </tbody> </table>		Codes	Description	S001	Patch not detected	S002	Original deviation in the main scanning direction	S003	Original deviation in the auxiliary scanning direction	S004	Original inclination error	S005	Original type error	SFFF	Scanner other error	<table border="1"> <thead> <tr> <th data-bbox="869 286 1021 331">Codes</th> <th data-bbox="1021 286 1402 331">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="869 331 1021 376">E001</td> <td data-bbox="1021 331 1402 376">Engine status error</td> </tr> <tr> <td data-bbox="869 376 1021 421">E002</td> <td data-bbox="1021 376 1402 421">Spotted background error</td> </tr> <tr> <td data-bbox="869 421 1021 465">E003</td> <td data-bbox="1021 421 1402 465">Density error</td> </tr> <tr> <td data-bbox="869 465 1021 510">E004</td> <td data-bbox="1021 465 1402 510">Uneven density error</td> </tr> <tr> <td data-bbox="869 510 1021 555">EFFF</td> <td data-bbox="1021 510 1402 555">Engine other error</td> </tr> <tr> <td data-bbox="869 555 1021 600">C001</td> <td data-bbox="1021 555 1402 600">Controller error</td> </tr> <tr> <td data-bbox="869 600 1021 645">CFFF</td> <td data-bbox="1021 600 1402 645">Controller other error</td> </tr> </tbody> </table>		Codes	Description	E001	Engine status error	E002	Spotted background error	E003	Density error	E004	Uneven density error	EFFF	Engine other error	C001	Controller error	CFFF	Controller other error
	Codes	Description																																
	S001	Patch not detected																																
	S002	Original deviation in the main scanning direction																																
	S003	Original deviation in the auxiliary scanning direction																																
	S004	Original inclination error																																
	S005	Original type error																																
	SFFF	Scanner other error																																
	Codes	Description																																
E001	Engine status error																																	
E002	Spotted background error																																	
E003	Density error																																	
E004	Uneven density error																																	
EFFF	Engine other error																																	
C001	Controller error																																	
CFFF	Controller other error																																	
Setting: [On/Off Config]																																		
1. Select On or Off.																																		
<table border="1"> <thead> <tr> <th data-bbox="336 846 639 891">Display</th> <th data-bbox="639 846 1402 891">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 891 639 936">On</td> <td data-bbox="639 891 1402 936">Uneven density correction is enabled</td> </tr> <tr> <td data-bbox="336 936 639 987">Off</td> <td data-bbox="639 936 1402 987">Uneven density correction is disabled</td> </tr> </tbody> </table>				Display	Description	On	Uneven density correction is enabled	Off	Uneven density correction is disabled																									
Display	Description																																	
On	Uneven density correction is enabled																																	
Off	Uneven density correction is disabled																																	
ON is automatically set after the correction is complete.																																		
2. Press the start key. The setting is set.																																		
Completion																																		
Press the stop key. The screen for selecting a maintenance item No. is displayed.																																		

Item No.	Description																																						
U415	<p data-bbox="287 241 821 275">Adjusting the print position automatically</p> <p data-bbox="287 309 438 342">Description Automatically adjusts timings at the print engine. Adjustment for leading edge timing, center line and margin.</p> <p data-bbox="287 414 399 448">Purpose Used to make respective auto adjustments for the print engine.</p> <p data-bbox="287 519 391 553">Method</p> <ol data-bbox="303 555 1141 896" style="list-style-type: none"> 1. Load A3/ledger paper. Load A4/Letter when the large capacity feeder is used. 2. Press the start key. 3. Select [Execute]. 4. Press the start key. A test pattern is outputted 5. Set the output test pattern as the original. 6. Press the start key. Automatically performs adjustment from the top to bottom cassettes. 7. When normally completed, [OK] is displayed. If a problem occurs during auto adjustment, error code is displayed. <p data-bbox="335 929 494 963">Error Codes</p> <table border="1" data-bbox="335 974 1396 1892"> <thead> <tr> <th data-bbox="343 981 550 1025">Codes</th> <th data-bbox="550 981 1388 1025">Description</th> </tr> </thead> <tbody> <tr><td>S001</td><td>Black band is not detected (main scanning direction far end)</td></tr> <tr><td>S002</td><td>Black band is not detected (main scanning direction near end)</td></tr> <tr><td>S003</td><td>Black band is not detected (auxiliary scanning direction leading edge)</td></tr> <tr><td>S004</td><td>Black band is not detected (auxiliary scanning direction trailing edge)</td></tr> <tr><td>S005</td><td>Auxiliary scanning direction skew error (1.5 mm or more)</td></tr> <tr><td>S006</td><td>Main scanning direction skew error (1.5 mm or more)</td></tr> <tr><td>S007</td><td>Original error (detection of reverse original paper)</td></tr> <tr><td>S008</td><td>Original error (page mismatch)</td></tr> <tr><td>SFFF</td><td>Scanner other error</td></tr> <tr><td>C101</td><td>Adjustment value error (main scanning direction magnification)</td></tr> <tr><td>C102</td><td>Adjustment value error (auxiliary scanning direction magnification)</td></tr> <tr><td>C103</td><td>Adjustment value error (leading edge timing)</td></tr> <tr><td>C104</td><td>Adjustment value error (center line)</td></tr> <tr><td>C105</td><td>Adjustment value error (B margin)</td></tr> <tr><td>C106</td><td>Adjustment value error (A margin)</td></tr> <tr><td>C107</td><td>Adjustment value error (C margin)</td></tr> <tr><td>C108</td><td>Adjustment value error (D margin)</td></tr> <tr><td>CFFF</td><td>Controller other error</td></tr> </tbody> </table> <p data-bbox="287 1926 438 1960">Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Codes	Description	S001	Black band is not detected (main scanning direction far end)	S002	Black band is not detected (main scanning direction near end)	S003	Black band is not detected (auxiliary scanning direction leading edge)	S004	Black band is not detected (auxiliary scanning direction trailing edge)	S005	Auxiliary scanning direction skew error (1.5 mm or more)	S006	Main scanning direction skew error (1.5 mm or more)	S007	Original error (detection of reverse original paper)	S008	Original error (page mismatch)	SFFF	Scanner other error	C101	Adjustment value error (main scanning direction magnification)	C102	Adjustment value error (auxiliary scanning direction magnification)	C103	Adjustment value error (leading edge timing)	C104	Adjustment value error (center line)	C105	Adjustment value error (B margin)	C106	Adjustment value error (A margin)	C107	Adjustment value error (C margin)	C108	Adjustment value error (D margin)	CFFF	Controller other error
Codes	Description																																						
S001	Black band is not detected (main scanning direction far end)																																						
S002	Black band is not detected (main scanning direction near end)																																						
S003	Black band is not detected (auxiliary scanning direction leading edge)																																						
S004	Black band is not detected (auxiliary scanning direction trailing edge)																																						
S005	Auxiliary scanning direction skew error (1.5 mm or more)																																						
S006	Main scanning direction skew error (1.5 mm or more)																																						
S007	Original error (detection of reverse original paper)																																						
S008	Original error (page mismatch)																																						
SFFF	Scanner other error																																						
C101	Adjustment value error (main scanning direction magnification)																																						
C102	Adjustment value error (auxiliary scanning direction magnification)																																						
C103	Adjustment value error (leading edge timing)																																						
C104	Adjustment value error (center line)																																						
C105	Adjustment value error (B margin)																																						
C106	Adjustment value error (A margin)																																						
C107	Adjustment value error (C margin)																																						
C108	Adjustment value error (D margin)																																						
CFFF	Controller other error																																						

Item No.	Description																																												
U425	<p data-bbox="287 241 518 275">Setting the target</p> <p data-bbox="287 309 438 342">Description Enters the lab values that is indicated of the chart 1 (P/N: 7505000005) or chart 2 (P/N: 302FZ56990) used for adjustment.</p> <p data-bbox="287 414 399 448">Purpose Performs data input in order to correct for differences in originals during automatic adjustment.</p> <p data-bbox="287 519 391 553">Method 1. Press the start key. Select the chart to be used.</p> <table border="1" data-bbox="335 631 1401 777"> <thead> <tr> <th data-bbox="343 638 641 683">Display</th> <th data-bbox="641 638 1393 683">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 683 641 728">Chart1</td> <td data-bbox="641 683 1393 728">Chart 1 (P/N: 7505000005)</td> </tr> <tr> <td data-bbox="343 728 641 772">Chart2</td> <td data-bbox="641 728 1393 772">Chart 2 (P/N: 302FZ56990)</td> </tr> </tbody> </table> <p data-bbox="287 817 502 851">Method: [Chart1] 1. Press the start key. 2. Select the item to be set.</p> <table border="1" data-bbox="335 929 1401 1556"> <thead> <tr> <th data-bbox="343 936 641 981">Display</th> <th data-bbox="641 936 1393 981">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 981 641 1025">White</td> <td data-bbox="641 981 1393 1025">Setting the white patch for the original for adjustment</td> </tr> <tr> <td data-bbox="343 1025 641 1070">Black</td> <td data-bbox="641 1025 1393 1070">Setting the black patch for the original for adjustment</td> </tr> <tr> <td data-bbox="343 1070 641 1115">Gray1</td> <td data-bbox="641 1070 1393 1115">Setting the Gray1 patch for the original for adjustment</td> </tr> <tr> <td data-bbox="343 1115 641 1160">Gray2</td> <td data-bbox="641 1115 1393 1160">Setting the Gray2 patch for the original for adjustment</td> </tr> <tr> <td data-bbox="343 1160 641 1205">Gray3</td> <td data-bbox="641 1160 1393 1205">Setting the Gray3 patch for the original for adjustment</td> </tr> <tr> <td data-bbox="343 1205 641 1249">C</td> <td data-bbox="641 1205 1393 1249">Setting the cyan patch for the original for adjustment</td> </tr> <tr> <td data-bbox="343 1249 641 1294">M</td> <td data-bbox="641 1249 1393 1294">Setting the magenta patch for the original for adjustment</td> </tr> <tr> <td data-bbox="343 1294 641 1339">Y</td> <td data-bbox="641 1294 1393 1339">Setting the yellow patch for the original for adjustment</td> </tr> <tr> <td data-bbox="343 1339 641 1384">R</td> <td data-bbox="641 1339 1393 1384">Setting the red patch for the original for adjustment</td> </tr> <tr> <td data-bbox="343 1384 641 1429">G</td> <td data-bbox="641 1384 1393 1429">Setting the green patch for the original for adjustment</td> </tr> <tr> <td data-bbox="343 1429 641 1473">B</td> <td data-bbox="641 1429 1393 1473">Setting the blue patch for the original for adjustment</td> </tr> <tr> <td data-bbox="343 1473 641 1550">Adjust Original</td> <td data-bbox="641 1473 1393 1550">Setting the main and auxiliary scanning directions</td> </tr> </tbody> </table> <p data-bbox="287 1563 630 1597">3. Select the item to be set.</p> <table border="1" data-bbox="335 1608 1401 1798"> <thead> <tr> <th data-bbox="343 1615 641 1659">Display</th> <th data-bbox="641 1615 1021 1659">Description</th> <th data-bbox="1021 1615 1393 1659">Setting range</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 1659 641 1704">L</td> <td data-bbox="641 1659 1021 1704">Setting the L value</td> <td data-bbox="1021 1659 1393 1704">0.0 to 100.0</td> </tr> <tr> <td data-bbox="343 1704 641 1749">a</td> <td data-bbox="641 1704 1021 1749">Setting the a value</td> <td data-bbox="1021 1704 1393 1749">-200.0 to 200.0</td> </tr> <tr> <td data-bbox="343 1749 641 1794">b</td> <td data-bbox="641 1749 1021 1794">Setting the b value</td> <td data-bbox="1021 1749 1393 1794">-200.0 to 200.0</td> </tr> </tbody> </table> <p data-bbox="287 1809 1428 1877">4. Enters the value that is indicated on the face of the chart using the +/- keys or numeric keys. 5. Press the start key. The value is set.</p>	Display	Description	Chart1	Chart 1 (P/N: 7505000005)	Chart2	Chart 2 (P/N: 302FZ56990)	Display	Description	White	Setting the white patch for the original for adjustment	Black	Setting the black patch for the original for adjustment	Gray1	Setting the Gray1 patch for the original for adjustment	Gray2	Setting the Gray2 patch for the original for adjustment	Gray3	Setting the Gray3 patch for the original for adjustment	C	Setting the cyan patch for the original for adjustment	M	Setting the magenta patch for the original for adjustment	Y	Setting the yellow patch for the original for adjustment	R	Setting the red patch for the original for adjustment	G	Setting the green patch for the original for adjustment	B	Setting the blue patch for the original for adjustment	Adjust Original	Setting the main and auxiliary scanning directions	Display	Description	Setting range	L	Setting the L value	0.0 to 100.0	a	Setting the a value	-200.0 to 200.0	b	Setting the b value	-200.0 to 200.0
Display	Description																																												
Chart1	Chart 1 (P/N: 7505000005)																																												
Chart2	Chart 2 (P/N: 302FZ56990)																																												
Display	Description																																												
White	Setting the white patch for the original for adjustment																																												
Black	Setting the black patch for the original for adjustment																																												
Gray1	Setting the Gray1 patch for the original for adjustment																																												
Gray2	Setting the Gray2 patch for the original for adjustment																																												
Gray3	Setting the Gray3 patch for the original for adjustment																																												
C	Setting the cyan patch for the original for adjustment																																												
M	Setting the magenta patch for the original for adjustment																																												
Y	Setting the yellow patch for the original for adjustment																																												
R	Setting the red patch for the original for adjustment																																												
G	Setting the green patch for the original for adjustment																																												
B	Setting the blue patch for the original for adjustment																																												
Adjust Original	Setting the main and auxiliary scanning directions																																												
Display	Description	Setting range																																											
L	Setting the L value	0.0 to 100.0																																											
a	Setting the a value	-200.0 to 200.0																																											
b	Setting the b value	-200.0 to 200.0																																											



Item No.	Description
U425	<p>Setting: [Adjust Original]</p> <ol style="list-style-type: none"> 1. Measure the distance from the leading edge to the top of black belt 1 of the original at A, B and C. Measurement procedure <ol style="list-style-type: none"> 1) Measure the distance from the leading edge to the top of black belt 1 of the original at A (30 mm from the left edge), B (148.5 mm from the left edge) and C (267 mm from the left edge), respectively. 2) Apply the following formula for the values obtained: $((A + B + C) / 3)$ 2. Enter the values solved using the cursor left/right keys or numeric keys in [Dist1]. 3. Press the start key. The value is set. 4. Measure the distance from the left edge to the right edge black belt 2 of the original at F. Measurement procedure <ol style="list-style-type: none"> 1) Measure the distance from the left edge to the right edge black belt 2 of the original at F (15 mm from the top edge of black belt 1). 5. Enter the values using the cursor left/right keys or numeric keys in [Dist2]. 6. Press the start key. The value is set. 7. Measure the distance from the top edge of black belt 1 to the bottom of black belt 3 of the original at D and E. Measurement procedure <ol style="list-style-type: none"> 1) Measure the distance from the top edge of black belt 1 to the bottom of black belt 3 of the original at D (30 mm from the left edge) and E (267 mm from the left edge), respectively. 2) Apply the following formula for the values obtained: $(D/2 + E/2)$ 8. Enter the measured value using the cursor left/right keys or numeric keys in [Dist3]. 9. Press the start key. The value is set.  <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-left: auto; margin-right: auto;"> <p>[Dist1] = $(A+B+C)/3$ [Dist2] = F [Dist3] = $D/2+E/2$</p> </div> <p style="text-align: center;">Original for adjustment (P/N: 7505000005)</p>

Figure 1-3-30

Item No.	Description																																										
U425	<p data-bbox="287 241 507 273">Method: [Chart2]</p> <p data-bbox="287 277 564 340">1. Press the start key. 2. Select the item.</p> <table border="1" data-bbox="336 353 1401 616"> <thead> <tr> <th data-bbox="336 353 639 398">Display</th> <th data-bbox="639 353 1401 398">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 398 639 483">CCD</td> <td data-bbox="639 398 1401 483">Entering the target values of the chart (P/N: 302FZ56990) used for adjustment</td> </tr> <tr> <td data-bbox="336 483 639 568">DP</td> <td data-bbox="639 483 1401 568">Entering the measurement value of the chart (P/N: 302AC68243) used for adjustment</td> </tr> <tr> <td data-bbox="336 568 639 616">CIS</td> <td data-bbox="639 568 1401 616">Execution is not required</td> </tr> </tbody> </table> <p data-bbox="287 656 480 687">Method: [CCD]</p> <p data-bbox="287 692 632 723">1. Select the item to be set.</p> <table border="1" data-bbox="336 734 1401 1261"> <thead> <tr> <th data-bbox="336 734 639 779">Display</th> <th data-bbox="639 734 1401 779">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 779 639 824">N875</td> <td data-bbox="639 779 1401 824">Setting the N875 patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 824 639 869">N475</td> <td data-bbox="639 824 1401 869">Setting the N475 patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 869 639 913">N125</td> <td data-bbox="639 869 1401 913">Setting the N125 patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 913 639 958">C</td> <td data-bbox="639 913 1401 958">Setting the cyan patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 958 639 1003">M</td> <td data-bbox="639 958 1401 1003">Setting the magenta patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 1003 639 1048">Y</td> <td data-bbox="639 1003 1401 1048">Setting the yellow patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 1048 639 1093">R</td> <td data-bbox="639 1048 1401 1093">Setting the red patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 1093 639 1137">G</td> <td data-bbox="639 1093 1401 1137">Setting the green patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 1137 639 1182">B</td> <td data-bbox="639 1137 1401 1182">Setting the blue patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 1182 639 1261">Adjust Original</td> <td data-bbox="639 1182 1401 1261">Setting the main and auxiliary scanning directions</td> </tr> </tbody> </table> <p data-bbox="287 1272 632 1303">2. Select the item to be set.</p> <table border="1" data-bbox="336 1314 1401 1507"> <thead> <tr> <th data-bbox="336 1314 639 1359">Display</th> <th data-bbox="639 1314 1018 1359">Description</th> <th data-bbox="1018 1314 1401 1359">Setting range</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1359 639 1404">L</td> <td data-bbox="639 1359 1018 1404">Setting the L value</td> <td data-bbox="1018 1359 1401 1404">0.0 to 100.0</td> </tr> <tr> <td data-bbox="336 1404 639 1449">a</td> <td data-bbox="639 1404 1018 1449">Setting the a value</td> <td data-bbox="1018 1404 1401 1449">-200.0 to 200.0</td> </tr> <tr> <td data-bbox="336 1449 639 1507">b</td> <td data-bbox="639 1449 1018 1507">Setting the b value</td> <td data-bbox="1018 1449 1401 1507">-200.0 to 200.0</td> </tr> </tbody> </table> <p data-bbox="287 1518 1430 1581">3. Enters the value that is indicated on the back of the chart using the +/- keys or numeric keys. 4. Press the start key. The value is set.</p>	Display	Description	CCD	Entering the target values of the chart (P/N: 302FZ56990) used for adjustment	DP	Entering the measurement value of the chart (P/N: 302AC68243) used for adjustment	CIS	Execution is not required	Display	Description	N875	Setting the N875 patch for the original for adjustment	N475	Setting the N475 patch for the original for adjustment	N125	Setting the N125 patch for the original for adjustment	C	Setting the cyan patch for the original for adjustment	M	Setting the magenta patch for the original for adjustment	Y	Setting the yellow patch for the original for adjustment	R	Setting the red patch for the original for adjustment	G	Setting the green patch for the original for adjustment	B	Setting the blue patch for the original for adjustment	Adjust Original	Setting the main and auxiliary scanning directions	Display	Description	Setting range	L	Setting the L value	0.0 to 100.0	a	Setting the a value	-200.0 to 200.0	b	Setting the b value	-200.0 to 200.0
Display	Description																																										
CCD	Entering the target values of the chart (P/N: 302FZ56990) used for adjustment																																										
DP	Entering the measurement value of the chart (P/N: 302AC68243) used for adjustment																																										
CIS	Execution is not required																																										
Display	Description																																										
N875	Setting the N875 patch for the original for adjustment																																										
N475	Setting the N475 patch for the original for adjustment																																										
N125	Setting the N125 patch for the original for adjustment																																										
C	Setting the cyan patch for the original for adjustment																																										
M	Setting the magenta patch for the original for adjustment																																										
Y	Setting the yellow patch for the original for adjustment																																										
R	Setting the red patch for the original for adjustment																																										
G	Setting the green patch for the original for adjustment																																										
B	Setting the blue patch for the original for adjustment																																										
Adjust Original	Setting the main and auxiliary scanning directions																																										
Display	Description	Setting range																																									
L	Setting the L value	0.0 to 100.0																																									
a	Setting the a value	-200.0 to 200.0																																									
b	Setting the b value	-200.0 to 200.0																																									

Item No.	Description
U425	<p>Setting: [Adjust Original]</p> <ol style="list-style-type: none"> 1. Measure the distance from the left edge to the black belt (a) of the original at A, B and C. Measurement procedure <ol style="list-style-type: none"> 1) Measure the distance from the edge to the black belt (a) of the original at A (30 mm from the leading edge), B (148.5 mm from the leading edge) and C (267 mm from the leading edge), respectively. 2) Apply the following formula for the values obtained: $((A + C) / 2 + B) / 2$ 2. Enter the values solved using the cursor left/right keys or numeric keys in [Lead]. 3. Press the start key. The value is set. 4. Measure the distance from the leading edge to the black belt (b) of the original at D, E and F. Measurement procedure <ol style="list-style-type: none"> 1) Measure the distance from the edge to the black belt (b) of the original at D (35 mm from the left edge), E (110 mm from the left edge) and F (185 mm from the left edge), respectively. 2) Apply the following formula for the values obtained: $((D + F) / 2 + E) / 2$ 5. Enter the values solved using the cursor left/right keys or numeric keys in [Main Scan]. 6. Press the start key. The value is set. 7. Measure the length (G) from the edge of the black belt (a) to edge of N475 of the original. 8. Enter the measured value using the cursor left/right keys or numeric keys in [Sub Scan]. 9. Press the start key. The value is set.
	<p style="text-align: center;">Original for adjustment (P/N: 302FZ56990)</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-left: auto; margin-right: auto;"> <p>[Lead] = $((A + C) / 2 + B) / 2$</p> <p>[Main Scan] = $((D + F) / 2 + E) / 2$</p> <p>[Sub Scan] = G</p> </div>
	Figure 1-3-31

Item No.	Description
U425	<p>Setting: [DP]</p> <ol style="list-style-type: none"> 1. Measure the distance from the leading edge to the black belt (inside) of the original at A. 2. Enter the measured value using the +/- keys in [Lead]. 3. Measure the distance from the left edge to the black belt (inside) of the original at B. 4. Enter the measured value using the +/- keys in [Main Scan]. 5. Measure the distance from the black belt of leading edge (inside) to the black belt of trailing edge (inside) of the original at C. 6. Enter the measured value using the +/- keys in [Sub Scan]. 7. Press the start key. The value is set. <div style="text-align: center;">  <p>The diagram shows a rectangular object with a thick black border. Three measurement points are indicated: 'A' is a vertical double-headed arrow on the right side, measuring the distance from the top edge to the inner edge of the black belt; 'B' is a horizontal double-headed arrow at the top, measuring the distance from the left edge to the inner edge of the black belt; 'C' is a vertical double-headed arrow in the center, measuring the distance between the inner edges of the black belts on the top and bottom sides.</p> </div> <p>Original for adjustment (P/N: 302AC68243)</p> <p>Figure 1-3-32</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Item No.	Description																																		
U429	<p data-bbox="288 241 783 275">Setting the offset for the color balance</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1374 409">Displays and changes the density for each color during copying in the various image quality modes.</p> <p data-bbox="288 414 400 443">Purpose</p> <p data-bbox="288 448 735 477">To change the balance for each color.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 551 703 616" style="list-style-type: none"> 1. Press the start key. 2. Select the image quality mode. <table border="1" data-bbox="336 629 1401 965"> <thead> <tr> <th data-bbox="336 629 639 674">Display</th> <th data-bbox="639 629 1401 674">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 674 639 719">Text+Photo</td> <td data-bbox="639 674 1401 719">Density of each color in the text & photo mode</td> </tr> <tr> <td data-bbox="336 719 639 763">Photo</td> <td data-bbox="639 719 1401 763">Density of each color in the photo mode</td> </tr> <tr> <td data-bbox="336 763 639 808">Photo/Printout</td> <td data-bbox="639 763 1401 808">Density of each color in the printed photo mode</td> </tr> <tr> <td data-bbox="336 808 639 853">Text</td> <td data-bbox="639 808 1401 853">Density of each color in the text mode</td> </tr> <tr> <td data-bbox="336 853 639 898">Graphics/Map</td> <td data-bbox="639 853 1401 898">Density of each color in the map mode</td> </tr> <tr> <td data-bbox="336 898 639 965">Copy/Printout</td> <td data-bbox="639 898 1401 965">Density of each color in the printed document mode</td> </tr> </tbody> </table> <p data-bbox="288 1010 384 1039">Setting</p> <ol data-bbox="304 1043 1054 1108" style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 1122 1401 1397"> <thead> <tr> <th data-bbox="336 1122 528 1205">Display</th> <th data-bbox="528 1122 983 1205">Description</th> <th data-bbox="983 1122 1246 1205">Setting range</th> <th data-bbox="1246 1122 1401 1205">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1205 528 1249">C</td> <td data-bbox="528 1205 983 1249">Value of the cyan setting</td> <td data-bbox="983 1205 1246 1249">-5 to 5 (0 to 10*)</td> <td data-bbox="1246 1205 1401 1249">0</td> </tr> <tr> <td data-bbox="336 1249 528 1294">M</td> <td data-bbox="528 1249 983 1294">Value of the magenta setting</td> <td data-bbox="983 1249 1246 1294">-5 to 5 (0 to 10*)</td> <td data-bbox="1246 1249 1401 1294">0</td> </tr> <tr> <td data-bbox="336 1294 528 1339">Y</td> <td data-bbox="528 1294 983 1339">Value of the yellow setting</td> <td data-bbox="983 1294 1246 1339">-5 to 5 (0 to 10*)</td> <td data-bbox="1246 1294 1401 1339">0</td> </tr> <tr> <td data-bbox="336 1339 528 1397">K</td> <td data-bbox="528 1339 983 1397">Value of the black setting</td> <td data-bbox="983 1339 1246 1397">-5 to 5 (0 to 10*)</td> <td data-bbox="1246 1339 1401 1397">0</td> </tr> </tbody> </table> <p data-bbox="336 1408 730 1438">*: When selecting [Copy/Printout]</p> <p data-bbox="336 1442 1270 1471">Increasing the value darkens the density and decreasing it lightens the density.</p> <ol data-bbox="304 1476 767 1505" style="list-style-type: none"> 3. Press the start key. The value is set. <p data-bbox="288 1547 448 1576">Supplement</p> <p data-bbox="288 1581 1417 1646">While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p data-bbox="288 1686 440 1715">Completion</p> <p data-bbox="288 1720 1254 1749">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Text+Photo	Density of each color in the text & photo mode	Photo	Density of each color in the photo mode	Photo/Printout	Density of each color in the printed photo mode	Text	Density of each color in the text mode	Graphics/Map	Density of each color in the map mode	Copy/Printout	Density of each color in the printed document mode	Display	Description	Setting range	Initial setting	C	Value of the cyan setting	-5 to 5 (0 to 10*)	0	M	Value of the magenta setting	-5 to 5 (0 to 10*)	0	Y	Value of the yellow setting	-5 to 5 (0 to 10*)	0	K	Value of the black setting	-5 to 5 (0 to 10*)	0
Display	Description																																		
Text+Photo	Density of each color in the text & photo mode																																		
Photo	Density of each color in the photo mode																																		
Photo/Printout	Density of each color in the printed photo mode																																		
Text	Density of each color in the text mode																																		
Graphics/Map	Density of each color in the map mode																																		
Copy/Printout	Density of each color in the printed document mode																																		
Display	Description	Setting range	Initial setting																																
C	Value of the cyan setting	-5 to 5 (0 to 10*)	0																																
M	Value of the magenta setting	-5 to 5 (0 to 10*)	0																																
Y	Value of the yellow setting	-5 to 5 (0 to 10*)	0																																
K	Value of the black setting	-5 to 5 (0 to 10*)	0																																

Item No.	Description																																		
U460	<p data-bbox="288 241 699 275">Adjusting the conveying sensor</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1174 376">Compensates the threshold value of the side multi tray's multi feed sensor.</p> <p data-bbox="288 383 400 412">Purpose</p> <p data-bbox="288 416 1374 448">If more than one sheet is fed at a time, modify the threshold depending on the environment.</p> <p data-bbox="288 486 387 515">Method</p> <ol data-bbox="304 519 564 584" style="list-style-type: none"> 1. Press the start key. 2. Select [SMT]. <table border="1" data-bbox="336 598 1401 741"> <thead> <tr> <th data-bbox="336 598 639 642">Display</th> <th data-bbox="639 598 1401 642">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 642 639 687">DP</td> <td data-bbox="639 642 1401 687">Settings of paper conveying sensor on the DP</td> </tr> <tr> <td data-bbox="336 687 639 741">SMT*</td> <td data-bbox="639 687 1401 741">Settings of multiple feed sensor on the side multi tray</td> </tr> </tbody> </table> <p data-bbox="336 750 691 781">*: 45 ppm/55 ppm model only.</p> <p data-bbox="288 819 459 848">Method: [DP]</p> <ol data-bbox="304 853 521 884" style="list-style-type: none"> 1. Select the item. <table border="1" data-bbox="336 898 1401 994"> <thead> <tr> <th data-bbox="336 898 639 943">Display</th> <th data-bbox="639 898 1401 943">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 943 639 994">On/Off Config</td> <td data-bbox="639 943 1401 994">Paper conveying sensor On/Off settings</td> </tr> </tbody> </table> <p data-bbox="288 1046 592 1075">Setting: [On/Off Config]</p> <ol data-bbox="304 1079 537 1111" style="list-style-type: none"> 1. Select On or Off. <table border="1" data-bbox="336 1124 1401 1267"> <thead> <tr> <th data-bbox="336 1124 639 1169">Display</th> <th data-bbox="639 1124 1401 1169">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1169 639 1214">On</td> <td data-bbox="639 1169 1401 1214">Paper conveying sensor is enabled</td> </tr> <tr> <td data-bbox="336 1214 639 1267">Off</td> <td data-bbox="639 1214 1401 1267">Paper conveying sensor is disabled</td> </tr> </tbody> </table> <p data-bbox="336 1274 539 1305">Initial setting: Off</p> <ol data-bbox="304 1310 782 1341" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1379 387 1408">Method</p> <ol data-bbox="304 1413 521 1444" style="list-style-type: none"> 1. Select the item. <table border="1" data-bbox="336 1458 1401 1601"> <thead> <tr> <th data-bbox="336 1458 639 1503">Display</th> <th data-bbox="639 1458 1401 1503">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1503 639 1547">Conveying Sensor</td> <td data-bbox="639 1503 1401 1547">Multi feed sensor settings/Calibration</td> </tr> <tr> <td data-bbox="336 1547 639 1601">On/Off Config</td> <td data-bbox="639 1547 1401 1601">Multi feed sensor On/Off settings</td> </tr> </tbody> </table> <p data-bbox="288 1644 652 1673">Setting: [Conveying Sensor]</p> <ol data-bbox="304 1677 521 1709" style="list-style-type: none"> 1. Select the item. <table border="1" data-bbox="336 1722 1401 2011"> <thead> <tr> <th data-bbox="336 1722 639 1767">Display</th> <th data-bbox="639 1722 1401 1767">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1767 639 1812">Sensor(Non-P)</td> <td data-bbox="639 1767 1401 1812">Empty paper sensor display</td> </tr> <tr> <td data-bbox="336 1812 639 1856">Sensor</td> <td data-bbox="639 1812 1401 1856">Displaying sensor value when paper is present</td> </tr> <tr> <td data-bbox="336 1856 639 1901">Threshold(Single)</td> <td data-bbox="639 1856 1401 1901">Paper feeding threshold settings</td> </tr> <tr> <td data-bbox="336 1901 639 1946">Threshold(Multi)</td> <td data-bbox="639 1901 1401 1946">Multi feed threshold settings</td> </tr> <tr> <td data-bbox="336 1946 639 2011">Execute</td> <td data-bbox="639 1946 1401 2011">Executing the calibration</td> </tr> </tbody> </table>	Display	Description	DP	Settings of paper conveying sensor on the DP	SMT*	Settings of multiple feed sensor on the side multi tray	Display	Description	On/Off Config	Paper conveying sensor On/Off settings	Display	Description	On	Paper conveying sensor is enabled	Off	Paper conveying sensor is disabled	Display	Description	Conveying Sensor	Multi feed sensor settings/Calibration	On/Off Config	Multi feed sensor On/Off settings	Display	Description	Sensor(Non-P)	Empty paper sensor display	Sensor	Displaying sensor value when paper is present	Threshold(Single)	Paper feeding threshold settings	Threshold(Multi)	Multi feed threshold settings	Execute	Executing the calibration
Display	Description																																		
DP	Settings of paper conveying sensor on the DP																																		
SMT*	Settings of multiple feed sensor on the side multi tray																																		
Display	Description																																		
On/Off Config	Paper conveying sensor On/Off settings																																		
Display	Description																																		
On	Paper conveying sensor is enabled																																		
Off	Paper conveying sensor is disabled																																		
Display	Description																																		
Conveying Sensor	Multi feed sensor settings/Calibration																																		
On/Off Config	Multi feed sensor On/Off settings																																		
Display	Description																																		
Sensor(Non-P)	Empty paper sensor display																																		
Sensor	Displaying sensor value when paper is present																																		
Threshold(Single)	Paper feeding threshold settings																																		
Threshold(Multi)	Multi feed threshold settings																																		
Execute	Executing the calibration																																		

Item No.	Description																		
U460	<p data-bbox="288 241 734 275">Setting: [Threshold(Single)/(Multi)]</p> <ol data-bbox="304 277 1053 342" style="list-style-type: none"> <li data-bbox="304 277 518 306">1. Select the item. <li data-bbox="304 309 1053 342">2. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 353 1401 533"> <thead> <tr> <th data-bbox="336 353 603 436">Display</th> <th data-bbox="603 353 1070 436">Description</th> <th data-bbox="1070 353 1235 436">Setting range</th> <th data-bbox="1235 353 1401 436">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 436 603 481">Threshold(Single)</td> <td data-bbox="603 436 1070 481">Paper feeding threshold settings</td> <td data-bbox="1070 436 1235 481">0 to 254</td> <td data-bbox="1235 436 1401 481">0</td> </tr> <tr> <td data-bbox="336 481 603 533">Threshold(Multi)</td> <td data-bbox="603 481 1070 533">Multi feed threshold settings</td> <td data-bbox="1070 481 1235 533">0 to 254</td> <td data-bbox="1235 481 1401 533">0</td> </tr> </tbody> </table> <ol data-bbox="304 544 766 577" style="list-style-type: none"> <li data-bbox="304 544 766 577">3. Press the start key. The value is set. <p data-bbox="288 611 523 645">Method: [Execute]</p> <ol data-bbox="304 647 849 712" style="list-style-type: none"> <li data-bbox="304 647 534 676">1. Select [Execute]. <li data-bbox="304 678 849 712">2. Press the start key. Calibration is executed. <p data-bbox="288 745 592 779">Setting: [On/Off Config]</p> <ol data-bbox="304 781 534 815" style="list-style-type: none"> <li data-bbox="304 781 534 815">1. Select On or Off. <table border="1" data-bbox="336 826 1401 972"> <thead> <tr> <th data-bbox="336 826 643 878">Display</th> <th data-bbox="643 826 1401 878">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 878 643 922">On</td> <td data-bbox="643 878 1401 922">Multi feed sensor is enabled</td> </tr> <tr> <td data-bbox="336 922 643 972">Off</td> <td data-bbox="643 922 1401 972">Multi feed sensor is disabled</td> </tr> </tbody> </table> <p data-bbox="336 983 539 1016">Initial setting: Off</p> <ol data-bbox="304 1019 782 1052" style="list-style-type: none"> <li data-bbox="304 1019 782 1052">2. Press the start key. The setting is set. <p data-bbox="288 1086 440 1120">Completion</p> <p data-bbox="288 1122 1254 1155">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Threshold(Single)	Paper feeding threshold settings	0 to 254	0	Threshold(Multi)	Multi feed threshold settings	0 to 254	0	Display	Description	On	Multi feed sensor is enabled	Off	Multi feed sensor is disabled
Display	Description	Setting range	Initial setting																
Threshold(Single)	Paper feeding threshold settings	0 to 254	0																
Threshold(Multi)	Multi feed threshold settings	0 to 254	0																
Display	Description																		
On	Multi feed sensor is enabled																		
Off	Multi feed sensor is disabled																		

Item No.	Description																																
U464	<p data-bbox="287 241 734 275">Setting the ID correction operation</p> <p data-bbox="287 309 438 342">Description</p> <p data-bbox="287 344 1433 409">Turns ID correction (calibration) on or off. Also, this allows individual settings for calibration operation.</p> <p data-bbox="287 412 399 445">Purpose</p> <p data-bbox="287 448 1425 515">Implements various settings of calibration when poor image quality is caused or to allow various settings of calibration depending on the user preference.</p> <p data-bbox="287 517 1029 551">To perform the calibration when replacing the maintenance kit.</p> <p data-bbox="287 584 391 618">Method</p> <ol data-bbox="303 620 630 685" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="335 696 1401 1697"> <thead> <tr> <th data-bbox="343 707 639 741">Display</th> <th data-bbox="639 707 1393 741">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 752 639 786">Permission</td> <td data-bbox="639 752 1393 786">Setting to turn calibration on/off</td> </tr> <tr> <td data-bbox="343 797 639 831">Time Interval</td> <td data-bbox="639 797 1393 831">Setting the interval time of calibration after printing</td> </tr> <tr> <td data-bbox="343 842 639 875">Mode</td> <td data-bbox="639 842 1393 875">Setting the color print execution mode</td> </tr> <tr> <td data-bbox="343 887 639 920">On/Sleep Out*</td> <td data-bbox="639 887 1393 952">Setting execution parameters for calibration when powered up or reverted from auto-sleep</td> </tr> <tr> <td data-bbox="343 963 639 996">AP/NE*</td> <td data-bbox="639 963 1393 1028">Paper interval calibration ON/OFF setting at the time of calibration/near end after toner feed</td> </tr> <tr> <td data-bbox="343 1039 639 1072">Leaving Time*</td> <td data-bbox="639 1039 1393 1149">Setting the standard time for judging whether or not to carry out calibration based on the sleep time when the machine recovers from the sleep mode</td> </tr> <tr> <td data-bbox="343 1160 639 1193">Driving Time*</td> <td data-bbox="639 1160 1393 1270">Setting the standard time for judging whether or not to carry out paper interval calibration based on the driving time during printing</td> </tr> <tr> <td data-bbox="343 1281 639 1314">Timing*</td> <td data-bbox="639 1281 1393 1391">Setting the standard time for judging whether or not to carry out calibration based on the continuous print driving time during printing</td> </tr> <tr> <td data-bbox="343 1402 639 1435">Target Value</td> <td data-bbox="639 1402 1393 1467">Setting the sensor target values for toner thick layer calibration and light amount calibration</td> </tr> <tr> <td data-bbox="343 1478 639 1512">Print Rate(B/W)*</td> <td data-bbox="639 1478 1393 1543">Setting the proportion of black/white printing at which black/white calibration is executed during color printing.</td> </tr> <tr> <td data-bbox="343 1554 639 1588">Calib</td> <td data-bbox="639 1554 1393 1588">Executing the calibration</td> </tr> <tr> <td data-bbox="343 1599 639 1632">Edge Reduction</td> <td data-bbox="639 1599 1393 1664">Smoothing edge settings (automatic calibration is implemented after settings are completed)</td> </tr> </tbody> </table> <p data-bbox="335 1709 821 1742">*: Enabled when Mode is set to Custom.</p> <p data-bbox="287 1744 566 1778">Setting: [Permission]</p> <ol data-bbox="303 1780 534 1814" style="list-style-type: none"> 1. Select On or Off. <table border="1" data-bbox="335 1825 1401 1966"> <thead> <tr> <th data-bbox="343 1836 639 1870">Display</th> <th data-bbox="639 1836 1393 1870">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 1881 639 1915">On</td> <td data-bbox="639 1881 1393 1915">Turns calibration ON</td> </tr> <tr> <td data-bbox="343 1926 639 1960">Off</td> <td data-bbox="639 1926 1393 1960">Turns calibration OFF</td> </tr> </tbody> </table> <p data-bbox="335 1977 534 2011">Initial setting: On</p> <ol data-bbox="303 2013 782 2047" style="list-style-type: none"> 2. Press the start key. The setting is set. 	Display	Description	Permission	Setting to turn calibration on/off	Time Interval	Setting the interval time of calibration after printing	Mode	Setting the color print execution mode	On/Sleep Out*	Setting execution parameters for calibration when powered up or reverted from auto-sleep	AP/NE*	Paper interval calibration ON/OFF setting at the time of calibration/near end after toner feed	Leaving Time*	Setting the standard time for judging whether or not to carry out calibration based on the sleep time when the machine recovers from the sleep mode	Driving Time*	Setting the standard time for judging whether or not to carry out paper interval calibration based on the driving time during printing	Timing*	Setting the standard time for judging whether or not to carry out calibration based on the continuous print driving time during printing	Target Value	Setting the sensor target values for toner thick layer calibration and light amount calibration	Print Rate(B/W)*	Setting the proportion of black/white printing at which black/white calibration is executed during color printing.	Calib	Executing the calibration	Edge Reduction	Smoothing edge settings (automatic calibration is implemented after settings are completed)	Display	Description	On	Turns calibration ON	Off	Turns calibration OFF
Display	Description																																
Permission	Setting to turn calibration on/off																																
Time Interval	Setting the interval time of calibration after printing																																
Mode	Setting the color print execution mode																																
On/Sleep Out*	Setting execution parameters for calibration when powered up or reverted from auto-sleep																																
AP/NE*	Paper interval calibration ON/OFF setting at the time of calibration/near end after toner feed																																
Leaving Time*	Setting the standard time for judging whether or not to carry out calibration based on the sleep time when the machine recovers from the sleep mode																																
Driving Time*	Setting the standard time for judging whether or not to carry out paper interval calibration based on the driving time during printing																																
Timing*	Setting the standard time for judging whether or not to carry out calibration based on the continuous print driving time during printing																																
Target Value	Setting the sensor target values for toner thick layer calibration and light amount calibration																																
Print Rate(B/W)*	Setting the proportion of black/white printing at which black/white calibration is executed during color printing.																																
Calib	Executing the calibration																																
Edge Reduction	Smoothing edge settings (automatic calibration is implemented after settings are completed)																																
Display	Description																																
On	Turns calibration ON																																
Off	Turns calibration OFF																																

Item No.	Description																																
U464	<p data-bbox="288 241 582 273">Setting: [Time Interval]</p> <p data-bbox="304 277 1054 309">1. Change the setting value using the +/- keys or numeric keys.</p> <table border="1" data-bbox="336 320 1401 450"> <thead> <tr> <th data-bbox="336 320 564 398">Display</th> <th data-bbox="564 320 1066 398">Description</th> <th data-bbox="1066 320 1249 398">Setting range</th> <th data-bbox="1249 320 1401 398">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 398 564 450">Time(sec)</td> <td data-bbox="564 398 1066 450">Setting the interval time of calibration</td> <td data-bbox="1066 398 1249 450">0 to 9999 (s)</td> <td data-bbox="1249 398 1401 450">480</td> </tr> </tbody> </table> <p data-bbox="304 461 767 492">2. Press the start key. The value is set.</p> <p data-bbox="288 528 486 560">Setting: [Mode]</p> <p data-bbox="304 564 520 595">1. Select the item.</p> <table border="1" data-bbox="336 607 1401 896"> <thead> <tr> <th data-bbox="336 607 639 656">Display</th> <th data-bbox="639 607 1401 656">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 656 639 705">Short</td> <td data-bbox="639 656 1401 705">Setting the color print execution mode: short</td> </tr> <tr> <td data-bbox="336 705 639 754">Normal</td> <td data-bbox="639 705 1401 754">Setting the color print execution mode: normal</td> </tr> <tr> <td data-bbox="336 754 639 804">Long</td> <td data-bbox="639 754 1401 804">Setting the color print execution mode: long</td> </tr> <tr> <td data-bbox="336 804 639 853">Custom</td> <td data-bbox="639 804 1401 853">Setting the color print execution mode: custom</td> </tr> <tr> <td data-bbox="336 853 639 896">Auto</td> <td data-bbox="639 853 1401 896">Setting the color print execution mode: auto</td> </tr> </tbody> </table> <p data-bbox="336 907 587 938">Initial setting: Normal</p> <p data-bbox="304 943 783 974">2. Press the start key. The setting is set.</p> <p data-bbox="288 1010 587 1041">Setting: [On/Sleep Out]</p> <p data-bbox="304 1046 536 1077">1. Select On or Off.</p> <table border="1" data-bbox="336 1088 1401 1301"> <thead> <tr> <th data-bbox="336 1088 639 1137">Display</th> <th data-bbox="639 1088 1401 1137">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1137 639 1216">On</td> <td data-bbox="639 1137 1401 1216">Executes calibration if fuser temperature is less than 50°C/ 122°F at power-up or recovery from auto sleep mode</td> </tr> <tr> <td data-bbox="336 1216 639 1301">Off</td> <td data-bbox="639 1216 1401 1301">Not to execute calibration regardless of fuser temperature at power-up or recovery from auto sleep mode</td> </tr> </tbody> </table> <p data-bbox="336 1312 536 1344">Initial setting: On</p> <p data-bbox="304 1348 783 1379">2. Press the start key. The setting is set.</p> <p data-bbox="288 1415 497 1447">Setting: [AP/NE]</p> <p data-bbox="304 1451 536 1482">1. Select On or Off.</p> <table border="1" data-bbox="336 1494 1401 1706"> <thead> <tr> <th data-bbox="336 1494 639 1543">Display</th> <th data-bbox="639 1494 1401 1543">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1543 639 1621">On</td> <td data-bbox="639 1543 1401 1621">Paper interval calibration at the time of calibration/near end after toner feed is carried out</td> </tr> <tr> <td data-bbox="336 1621 639 1706">Off</td> <td data-bbox="639 1621 1401 1706">Paper interval calibration at the time of calibration/near end after toner feed is not carried out</td> </tr> </tbody> </table> <p data-bbox="336 1718 536 1749">Initial setting: On</p> <p data-bbox="304 1753 783 1785">2. Press the start key. The setting is set.</p>	Display	Description	Setting range	Initial setting	Time(sec)	Setting the interval time of calibration	0 to 9999 (s)	480	Display	Description	Short	Setting the color print execution mode: short	Normal	Setting the color print execution mode: normal	Long	Setting the color print execution mode: long	Custom	Setting the color print execution mode: custom	Auto	Setting the color print execution mode: auto	Display	Description	On	Executes calibration if fuser temperature is less than 50°C/ 122°F at power-up or recovery from auto sleep mode	Off	Not to execute calibration regardless of fuser temperature at power-up or recovery from auto sleep mode	Display	Description	On	Paper interval calibration at the time of calibration/near end after toner feed is carried out	Off	Paper interval calibration at the time of calibration/near end after toner feed is not carried out
Display	Description	Setting range	Initial setting																														
Time(sec)	Setting the interval time of calibration	0 to 9999 (s)	480																														
Display	Description																																
Short	Setting the color print execution mode: short																																
Normal	Setting the color print execution mode: normal																																
Long	Setting the color print execution mode: long																																
Custom	Setting the color print execution mode: custom																																
Auto	Setting the color print execution mode: auto																																
Display	Description																																
On	Executes calibration if fuser temperature is less than 50°C/ 122°F at power-up or recovery from auto sleep mode																																
Off	Not to execute calibration regardless of fuser temperature at power-up or recovery from auto sleep mode																																
Display	Description																																
On	Paper interval calibration at the time of calibration/near end after toner feed is carried out																																
Off	Paper interval calibration at the time of calibration/near end after toner feed is not carried out																																

Item No.	Description																																																																									
U464	Setting: [Leaving Time]																																																																									
	1. Change the setting value using the +/- keys or numeric keys.																																																																									
	<table border="1"> <thead> <tr> <th data-bbox="336 322 564 405">Display</th> <th data-bbox="564 322 1066 405">Description</th> <th data-bbox="1066 322 1262 405">Setting range</th> <th colspan="4" data-bbox="1262 322 1401 405">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 405 564 450">Time(min)</td> <td data-bbox="564 405 1066 450">Setting the standard time of sleep mode</td> <td data-bbox="1066 405 1262 450">0 to 480 (min)</td> <td colspan="4" data-bbox="1262 405 1401 450">480</td> </tr> </tbody> </table>		Display	Description	Setting range	Initial setting				Time(min)	Setting the standard time of sleep mode	0 to 480 (min)	480																																																													
	Display	Description	Setting range	Initial setting																																																																						
	Time(min)	Setting the standard time of sleep mode	0 to 480 (min)	480																																																																						
	2. Press the start key. The value is set.																																																																									
	Setting: [Driving Time]																																																																									
	1. Change the setting value using the +/- keys.																																																																									
	<table border="1"> <thead> <tr> <th data-bbox="336 584 564 689">Display</th> <th data-bbox="564 584 1066 689">Description</th> <th data-bbox="1066 584 1262 689">Setting range</th> <th colspan="4" data-bbox="1262 584 1401 689">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 689 564 734">Time(sec)</td> <td data-bbox="564 689 1066 734">Setting the drive standard time</td> <td data-bbox="1066 689 1262 734">300 to 3000 (s)</td> <td colspan="4" data-bbox="1262 689 1401 734">300</td> </tr> </tbody> </table>		Display	Description	Setting range	Initial setting				Time(sec)	Setting the drive standard time	300 to 3000 (s)	300																																																													
	Display	Description	Setting range	Initial setting																																																																						
	Time(sec)	Setting the drive standard time	300 to 3000 (s)	300																																																																						
	2. Press the start key. The value is set.																																																																									
	Setting: [Timing]																																																																									
	1. Change the setting value using the +/- keys.																																																																									
	<table border="1"> <thead> <tr> <th data-bbox="336 869 564 974">Display</th> <th data-bbox="564 869 1066 974">Description</th> <th data-bbox="1066 869 1262 974">Setting range</th> <th colspan="4" data-bbox="1262 869 1401 974">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 974 564 1019">Time(sec)</td> <td data-bbox="564 974 1066 1019">Setting the drive standard time of continuous print</td> <td data-bbox="1066 974 1262 1019">0 to 3600 (s)</td> <td colspan="4" data-bbox="1262 974 1401 1019">3600</td> </tr> </tbody> </table>		Display	Description	Setting range	Initial setting				Time(sec)	Setting the drive standard time of continuous print	0 to 3600 (s)	3600																																																													
Display	Description	Setting range	Initial setting																																																																							
Time(sec)	Setting the drive standard time of continuous print	0 to 3600 (s)	3600																																																																							
2. Press the start key. The value is set.																																																																										
Setting: [Target Value]																																																																										
1. Select the item.																																																																										
2. Change the setting value using the +/- keys or numeric keys.																																																																										
<table border="1"> <thead> <tr> <th data-bbox="336 1198 564 1339" rowspan="2">Display</th> <th data-bbox="564 1198 1066 1339" rowspan="2">Description</th> <th data-bbox="1066 1198 1262 1339" rowspan="2">Setting range</th> <th colspan="4" data-bbox="1262 1198 1401 1339">Initial setting</th> </tr> <tr> <th data-bbox="1262 1198 1401 1339">30ppm</th> <th data-bbox="1401 1198 1439 1339">35ppm</th> <th data-bbox="1439 1198 1477 1339">45ppm</th> <th data-bbox="1477 1198 1516 1339">55ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1339 564 1422">Thick-ness(C)</td> <td data-bbox="564 1339 1066 1422">Toner thick layer calibration (cyan)</td> <td data-bbox="1066 1339 1262 1422">0 to 1000</td> <td data-bbox="1262 1339 1401 1422">890</td> <td data-bbox="1401 1339 1439 1422">890</td> <td data-bbox="1439 1339 1477 1422">890</td> <td data-bbox="1477 1339 1516 1422">890</td> </tr> <tr> <td data-bbox="336 1422 564 1505">Thick-ness(M)</td> <td data-bbox="564 1422 1066 1505">Toner thick layer calibration (magenta)</td> <td data-bbox="1066 1422 1262 1505">0 to 1000</td> <td data-bbox="1262 1422 1401 1505">910</td> <td data-bbox="1401 1422 1439 1505">910</td> <td data-bbox="1439 1422 1477 1505">910</td> <td data-bbox="1477 1422 1516 1505">910</td> </tr> <tr> <td data-bbox="336 1505 564 1588">Thick-ness(Y)</td> <td data-bbox="564 1505 1066 1588">Toner thick layer calibration (yellow)</td> <td data-bbox="1066 1505 1262 1588">0 to 1000</td> <td data-bbox="1262 1505 1401 1588">910</td> <td data-bbox="1401 1505 1439 1588">910</td> <td data-bbox="1439 1505 1477 1588">910</td> <td data-bbox="1477 1505 1516 1588">910</td> </tr> <tr> <td data-bbox="336 1588 564 1671">Thick-ness(K)</td> <td data-bbox="564 1588 1066 1671">Toner thick layer calibration (black)</td> <td data-bbox="1066 1588 1262 1671">0 to 1000</td> <td data-bbox="1262 1588 1401 1671">760</td> <td data-bbox="1401 1588 1439 1671">790</td> <td data-bbox="1439 1588 1477 1671">760</td> <td data-bbox="1477 1588 1516 1671">760</td> </tr> <tr> <td data-bbox="336 1671 564 1753">Gamma(C)</td> <td data-bbox="564 1671 1066 1753">Light amount calibration (cyan)</td> <td data-bbox="1066 1671 1262 1753">0 to 500</td> <td data-bbox="1262 1671 1401 1753">320</td> <td data-bbox="1401 1671 1439 1753">320</td> <td data-bbox="1439 1671 1477 1753">320</td> <td data-bbox="1477 1671 1516 1753">320</td> </tr> <tr> <td data-bbox="336 1753 564 1836">Gamma(M)</td> <td data-bbox="564 1753 1066 1836">Light amount calibration (magenta)</td> <td data-bbox="1066 1753 1262 1836">0 to 500</td> <td data-bbox="1262 1753 1401 1836">320</td> <td data-bbox="1401 1753 1439 1836">320</td> <td data-bbox="1439 1753 1477 1836">320</td> <td data-bbox="1477 1753 1516 1836">320</td> </tr> <tr> <td data-bbox="336 1836 564 1919">Gamma(Y)</td> <td data-bbox="564 1836 1066 1919">Light amount calibration (yellow)</td> <td data-bbox="1066 1836 1262 1919">0 to 500</td> <td data-bbox="1262 1836 1401 1919">300</td> <td data-bbox="1401 1836 1439 1919">300</td> <td data-bbox="1439 1836 1477 1919">300</td> <td data-bbox="1477 1836 1516 1919">300</td> </tr> <tr> <td data-bbox="336 1919 564 1998">Gamma(K)</td> <td data-bbox="564 1919 1066 1998">Light amount calibration (black)</td> <td data-bbox="1066 1919 1262 1998">0 to 500</td> <td data-bbox="1262 1919 1401 1998">350</td> <td data-bbox="1401 1919 1439 1998">350</td> <td data-bbox="1439 1919 1477 1998">350</td> <td data-bbox="1477 1919 1516 1998">350</td> </tr> </tbody> </table>		Display	Description	Setting range	Initial setting				30ppm	35ppm	45ppm	55ppm	Thick-ness(C)	Toner thick layer calibration (cyan)	0 to 1000	890	890	890	890	Thick-ness(M)	Toner thick layer calibration (magenta)	0 to 1000	910	910	910	910	Thick-ness(Y)	Toner thick layer calibration (yellow)	0 to 1000	910	910	910	910	Thick-ness(K)	Toner thick layer calibration (black)	0 to 1000	760	790	760	760	Gamma(C)	Light amount calibration (cyan)	0 to 500	320	320	320	320	Gamma(M)	Light amount calibration (magenta)	0 to 500	320	320	320	320	Gamma(Y)	Light amount calibration (yellow)	0 to 500	300	300	300	300	Gamma(K)	Light amount calibration (black)	0 to 500	350	350	350	350						
Display	Description				Setting range	Initial setting																																																																				
		30ppm	35ppm	45ppm		55ppm																																																																				
Thick-ness(C)	Toner thick layer calibration (cyan)	0 to 1000	890	890	890	890																																																																				
Thick-ness(M)	Toner thick layer calibration (magenta)	0 to 1000	910	910	910	910																																																																				
Thick-ness(Y)	Toner thick layer calibration (yellow)	0 to 1000	910	910	910	910																																																																				
Thick-ness(K)	Toner thick layer calibration (black)	0 to 1000	760	790	760	760																																																																				
Gamma(C)	Light amount calibration (cyan)	0 to 500	320	320	320	320																																																																				
Gamma(M)	Light amount calibration (magenta)	0 to 500	320	320	320	320																																																																				
Gamma(Y)	Light amount calibration (yellow)	0 to 500	300	300	300	300																																																																				
Gamma(K)	Light amount calibration (black)	0 to 500	350	350	350	350																																																																				
3. Press the start key. The value is set.																																																																										



Item No.	Description														
U464	<p>Setting: [Print Rate(B/W)]</p> <p>1. Change the setting value using the +/- keys or numeric keys.</p> <table border="1" data-bbox="336 320 1401 450"> <thead> <tr> <th data-bbox="336 320 564 398">Display</th> <th data-bbox="564 320 1066 398">Description</th> <th data-bbox="1066 320 1249 398">Setting range</th> <th data-bbox="1249 320 1401 398">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 398 564 450">Threshold</td> <td data-bbox="564 398 1066 450">Proportion of black/white printing</td> <td data-bbox="1066 398 1249 450">0 to 100 (%)</td> <td data-bbox="1249 398 1401 450">50</td> </tr> </tbody> </table> <p>2. Press the start key. The value is set.</p> <p>Method: [Calib]</p> <p>1. Select [Execute].</p> <p>2. Press the start key. Calibration is executed.</p> <p>* : Duplicates selecting [System Menu] - [Adjustment/Maintenance] - [Calibration]. The same operation as System menu.</p> <p>Setting: [Edge Reduction]</p> <p>1. Select On or Off.</p> <table border="1" data-bbox="336 813 1401 956"> <thead> <tr> <th data-bbox="336 813 641 857">Display</th> <th data-bbox="641 813 1401 857">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 857 641 902">On</td> <td data-bbox="641 857 1401 902">Enable smoothing edges</td> </tr> <tr> <td data-bbox="336 902 641 956">Off</td> <td data-bbox="641 902 1401 956">Disable smoothing edges</td> </tr> </tbody> </table> <p>Initial setting: On</p> <p>Press the start key. The setting is set.</p> <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Threshold	Proportion of black/white printing	0 to 100 (%)	50	Display	Description	On	Enable smoothing edges	Off	Disable smoothing edges
Display	Description	Setting range	Initial setting												
Threshold	Proportion of black/white printing	0 to 100 (%)	50												
Display	Description														
On	Enable smoothing edges														
Off	Disable smoothing edges														
U465	<p>Data reference for ID correction</p> <p>Description</p> <p>References the data related to ID correction.</p> <p>Purpose</p> <p>To check the corresponding data.</p> <p>Method</p> <p>1. Press the start key.</p> <p>2. Select the item to be reference.</p> <table border="1" data-bbox="336 1518 1401 1807"> <thead> <tr> <th data-bbox="336 1518 603 1570">Display</th> <th data-bbox="603 1518 1401 1570">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1570 603 1615">TCONT</td> <td data-bbox="603 1570 1401 1615">Developer bias control value after ID correction</td> </tr> <tr> <td data-bbox="336 1615 603 1659">Laser Power</td> <td data-bbox="603 1615 1401 1659">Scaling factor to the value determined in light amount calibration</td> </tr> <tr> <td data-bbox="336 1659 603 1704">Bias Calib</td> <td data-bbox="603 1659 1401 1704">Sensor value for toner thick layer calibration</td> </tr> <tr> <td data-bbox="336 1704 603 1749">T7 CTD</td> <td data-bbox="603 1704 1401 1749">T7 control value</td> </tr> <tr> <td data-bbox="336 1749 603 1807">Stress</td> <td data-bbox="603 1749 1401 1807">Intermediate transfer belt durability</td> </tr> </tbody> </table>	Display	Description	TCONT	Developer bias control value after ID correction	Laser Power	Scaling factor to the value determined in light amount calibration	Bias Calib	Sensor value for toner thick layer calibration	T7 CTD	T7 control value	Stress	Intermediate transfer belt durability		
Display	Description														
TCONT	Developer bias control value after ID correction														
Laser Power	Scaling factor to the value determined in light amount calibration														
Bias Calib	Sensor value for toner thick layer calibration														
T7 CTD	T7 control value														
Stress	Intermediate transfer belt durability														

Item No.	Description																																																
U465	<p data-bbox="288 241 574 275">Displaying: [TCOUNT]</p> <p data-bbox="288 277 877 311">Select [TCOUNT]. The current value is displayed.</p> <table border="1" data-bbox="336 353 1401 786"> <thead> <tr> <th data-bbox="336 353 603 398">Display</th> <th data-bbox="603 353 1401 398">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 398 603 443">Before(C)</td> <td data-bbox="603 398 1401 443">Developer bias control value for cyan before ID correction</td> </tr> <tr> <td data-bbox="336 443 603 488">Before(M)</td> <td data-bbox="603 443 1401 488">Developer bias control value for magenta before ID correction</td> </tr> <tr> <td data-bbox="336 488 603 533">Before(Y)</td> <td data-bbox="603 488 1401 533">Developer bias control value for yellow before ID correction</td> </tr> <tr> <td data-bbox="336 533 603 577">Before(K)</td> <td data-bbox="603 533 1401 577">Developer bias control value for black before ID correction</td> </tr> <tr> <td data-bbox="336 577 603 622">After(C)</td> <td data-bbox="603 577 1401 622">Developer bias control value for cyan after ID correction</td> </tr> <tr> <td data-bbox="336 622 603 667">After(M)</td> <td data-bbox="603 622 1401 667">Developer bias control value for magenta after ID correction</td> </tr> <tr> <td data-bbox="336 667 603 712">After(Y)</td> <td data-bbox="603 667 1401 712">Developer bias control value for yellow after ID correction</td> </tr> <tr> <td data-bbox="336 712 603 757">After(K)</td> <td data-bbox="603 712 1401 757">Developer bias control value for black after ID correction</td> </tr> </tbody> </table> <p data-bbox="288 831 622 864">Displaying: [Laser Power]</p> <p data-bbox="304 866 962 900">1. Select [Laser Power]. The current value is displayed.</p> <table border="1" data-bbox="336 909 1401 1149"> <thead> <tr> <th data-bbox="336 909 491 954">Display</th> <th data-bbox="491 909 1401 954">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 954 491 999">C</td> <td data-bbox="491 954 1401 999">Scaling factor to the value determined in light amount calibration (cyan)</td> </tr> <tr> <td data-bbox="336 999 491 1043">M</td> <td data-bbox="491 999 1401 1043">Scaling factor to the value determined in light amount calibration (magenta)</td> </tr> <tr> <td data-bbox="336 1043 491 1088">Y</td> <td data-bbox="491 1043 1401 1088">Scaling factor to the value determined in light amount calibration (yellow)</td> </tr> <tr> <td data-bbox="336 1088 491 1133">K</td> <td data-bbox="491 1088 1401 1133">Scaling factor to the value determined in light amount calibration (black)</td> </tr> </tbody> </table> <p data-bbox="288 1196 592 1229">Displaying: [Bias Calib]</p> <p data-bbox="304 1232 932 1265">1. Select [Bias Calib]. The current value is displayed.</p> <table border="1" data-bbox="336 1274 1401 1514"> <thead> <tr> <th data-bbox="336 1274 564 1319">Display</th> <th data-bbox="564 1274 1401 1319">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1319 564 1364">C</td> <td data-bbox="564 1319 1401 1364">Sensor value for toner thick layer calibration (cyan)</td> </tr> <tr> <td data-bbox="336 1364 564 1408">M</td> <td data-bbox="564 1364 1401 1408">Sensor value for toner thick layer calibration (magenta)</td> </tr> <tr> <td data-bbox="336 1408 564 1453">Y</td> <td data-bbox="564 1408 1401 1453">Sensor value for toner thick layer calibration (yellow)</td> </tr> <tr> <td data-bbox="336 1453 564 1498">K</td> <td data-bbox="564 1453 1401 1498">Sensor value for toner thick layer calibration (black)</td> </tr> </tbody> </table> <p data-bbox="288 1559 555 1592">Displaying: [T7 CTD]</p> <p data-bbox="304 1594 904 1628">1. Select [T7 CTD]. The current value is displayed.</p> <table border="1" data-bbox="336 1637 1401 1877"> <thead> <tr> <th data-bbox="336 1637 564 1682">Display</th> <th data-bbox="564 1637 1401 1682">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1682 564 1727">C</td> <td data-bbox="564 1682 1401 1727">T7 control value (cyan)</td> </tr> <tr> <td data-bbox="336 1727 564 1771">M</td> <td data-bbox="564 1727 1401 1771">T7 control value (magenta)</td> </tr> <tr> <td data-bbox="336 1771 564 1816">Y</td> <td data-bbox="564 1771 1401 1816">T7 control value (yellow)</td> </tr> <tr> <td data-bbox="336 1816 564 1861">K</td> <td data-bbox="564 1816 1401 1861">T7 control value (black)</td> </tr> </tbody> </table>	Display	Description	Before(C)	Developer bias control value for cyan before ID correction	Before(M)	Developer bias control value for magenta before ID correction	Before(Y)	Developer bias control value for yellow before ID correction	Before(K)	Developer bias control value for black before ID correction	After(C)	Developer bias control value for cyan after ID correction	After(M)	Developer bias control value for magenta after ID correction	After(Y)	Developer bias control value for yellow after ID correction	After(K)	Developer bias control value for black after ID correction	Display	Description	C	Scaling factor to the value determined in light amount calibration (cyan)	M	Scaling factor to the value determined in light amount calibration (magenta)	Y	Scaling factor to the value determined in light amount calibration (yellow)	K	Scaling factor to the value determined in light amount calibration (black)	Display	Description	C	Sensor value for toner thick layer calibration (cyan)	M	Sensor value for toner thick layer calibration (magenta)	Y	Sensor value for toner thick layer calibration (yellow)	K	Sensor value for toner thick layer calibration (black)	Display	Description	C	T7 control value (cyan)	M	T7 control value (magenta)	Y	T7 control value (yellow)	K	T7 control value (black)
Display	Description																																																
Before(C)	Developer bias control value for cyan before ID correction																																																
Before(M)	Developer bias control value for magenta before ID correction																																																
Before(Y)	Developer bias control value for yellow before ID correction																																																
Before(K)	Developer bias control value for black before ID correction																																																
After(C)	Developer bias control value for cyan after ID correction																																																
After(M)	Developer bias control value for magenta after ID correction																																																
After(Y)	Developer bias control value for yellow after ID correction																																																
After(K)	Developer bias control value for black after ID correction																																																
Display	Description																																																
C	Scaling factor to the value determined in light amount calibration (cyan)																																																
M	Scaling factor to the value determined in light amount calibration (magenta)																																																
Y	Scaling factor to the value determined in light amount calibration (yellow)																																																
K	Scaling factor to the value determined in light amount calibration (black)																																																
Display	Description																																																
C	Sensor value for toner thick layer calibration (cyan)																																																
M	Sensor value for toner thick layer calibration (magenta)																																																
Y	Sensor value for toner thick layer calibration (yellow)																																																
K	Sensor value for toner thick layer calibration (black)																																																
Display	Description																																																
C	T7 control value (cyan)																																																
M	T7 control value (magenta)																																																
Y	T7 control value (yellow)																																																
K	T7 control value (black)																																																

Item No.	Description																				
U465	<p>Displaying: [Stress]</p> <p>1. Select [Stress]. The current value is displayed.</p> <table border="1" data-bbox="336 320 1401 465"> <thead> <tr> <th data-bbox="336 320 491 365">Display</th> <th data-bbox="491 320 1401 365">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 365 491 409">Front</td> <td data-bbox="491 365 1401 409">Intermediate transfer belt durability (Front)</td> </tr> <tr> <td data-bbox="336 409 491 465">Rear</td> <td data-bbox="491 409 1401 465">Intermediate transfer belt durability (Rear)</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Front	Intermediate transfer belt durability (Front)	Rear	Intermediate transfer belt durability (Rear)														
Display	Description																				
Front	Intermediate transfer belt durability (Front)																				
Rear	Intermediate transfer belt durability (Rear)																				
U467	<p>Setting the color registration adjustment</p> <p>Description Sets the color registration adjustment and transfer belt speed correction. Also, determines the conditions by which color registration correction is executed depending on the LSU temperature.</p> <p>Purpose If color variance is uneven due to a sensor failure, etc., turn this off and temporarily make a manual adjustment.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 1016 1401 1229"> <thead> <tr> <th data-bbox="336 1016 641 1061">Display</th> <th data-bbox="641 1016 1401 1061">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1061 641 1106">Color Regist</td> <td data-bbox="641 1061 1401 1106">Setting the color registration correction operation</td> </tr> <tr> <td data-bbox="336 1106 641 1229">Timing</td> <td data-bbox="641 1106 1401 1229">After the previous correction is executed, color registration is compensated as the LSU temperature varies by the value determined.</td> </tr> </tbody> </table> <p>Setting: [Color Regist]</p> <ol style="list-style-type: none"> 1. Select On or Off. <table border="1" data-bbox="336 1352 1401 1498"> <thead> <tr> <th data-bbox="336 1352 641 1397">Display</th> <th data-bbox="641 1352 1401 1397">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1397 641 1442">On</td> <td data-bbox="641 1397 1401 1442">Enables the color registration correction operation.</td> </tr> <tr> <td data-bbox="336 1442 641 1498">Off</td> <td data-bbox="641 1442 1401 1498">Disables the color registration correction operation.</td> </tr> </tbody> </table> <p>Initial setting: On</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. <p>Setting: [Timing]</p> <ol style="list-style-type: none"> 1. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 1688 1401 1856"> <thead> <tr> <th data-bbox="336 1688 564 1778">Display</th> <th data-bbox="564 1688 1067 1778">Description</th> <th data-bbox="1067 1688 1235 1778">Setting range</th> <th data-bbox="1235 1688 1401 1778">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1778 564 1856">Timing</td> <td data-bbox="564 1778 1067 1856">Conditions for execution depending on the LSU temperature variation</td> <td data-bbox="1067 1778 1235 1856">2 to 10</td> <td data-bbox="1235 1778 1401 1856">10</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 2. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Color Regist	Setting the color registration correction operation	Timing	After the previous correction is executed, color registration is compensated as the LSU temperature varies by the value determined.	Display	Description	On	Enables the color registration correction operation.	Off	Disables the color registration correction operation.	Display	Description	Setting range	Initial setting	Timing	Conditions for execution depending on the LSU temperature variation	2 to 10	10
Display	Description																				
Color Regist	Setting the color registration correction operation																				
Timing	After the previous correction is executed, color registration is compensated as the LSU temperature varies by the value determined.																				
Display	Description																				
On	Enables the color registration correction operation.																				
Off	Disables the color registration correction operation.																				
Display	Description	Setting range	Initial setting																		
Timing	Conditions for execution depending on the LSU temperature variation	2 to 10	10																		

Item No.	Description																																				
U468	<p data-bbox="288 241 751 271">Checking the color registration data</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1299 374">Displays the color registration correction data and transfer belt speed correction data.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 686 443">To check the corresponding data.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="304 517 708 582" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be reference. <table border="1" data-bbox="336 595 1399 981"> <thead> <tr> <th data-bbox="336 595 564 640">Display</th> <th data-bbox="564 595 1399 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 564 685">V Correction</td> <td data-bbox="564 640 1399 685">Display the transfer speed adjustment value</td> </tr> <tr> <td data-bbox="336 685 564 730">Auto(C)</td> <td data-bbox="564 685 1399 730">Display the auto color registration adjustment value for cyan</td> </tr> <tr> <td data-bbox="336 730 564 775">Auto(M)</td> <td data-bbox="564 730 1399 775">Display the auto color registration adjustment value for magenta</td> </tr> <tr> <td data-bbox="336 775 564 819">Auto(Y)</td> <td data-bbox="564 775 1399 819">Display the auto color registration adjustment value for yellow</td> </tr> <tr> <td data-bbox="336 819 564 864">Manual(C)</td> <td data-bbox="564 819 1399 864">Display the manual color registration adjustment value for cyan</td> </tr> <tr> <td data-bbox="336 864 564 909">Manual(M)</td> <td data-bbox="564 864 1399 909">Display the manual color registration adjustment value for magenta</td> </tr> <tr> <td data-bbox="336 909 564 981">Manual(Y)</td> <td data-bbox="564 909 1399 981">Display the manual color registration adjustment value for yellow</td> </tr> </tbody> </table> <p data-bbox="288 1021 624 1050">Displaying: [V Correction]</p> <ol data-bbox="304 1055 959 1084" style="list-style-type: none"> 1. Select [V Correction]. The current value is displayed. <table border="1" data-bbox="336 1097 1399 1196"> <thead> <tr> <th data-bbox="336 1097 641 1142">Display</th> <th data-bbox="641 1097 1399 1142">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1142 641 1196">Status</td> <td data-bbox="641 1142 1399 1196">transfer speed adjustment value</td> </tr> </tbody> </table> <p data-bbox="288 1236 738 1265">Displaying: [Auto(C)/Auto(M)/Auto(Y)]</p> <ol data-bbox="304 1270 1171 1299" style="list-style-type: none"> 1. Select [Auto(C)], [Auto(M)] or [Auto(Y)]. The current value is displayed. <table border="1" data-bbox="336 1312 1399 1581"> <thead> <tr> <th data-bbox="336 1312 641 1357">Display</th> <th data-bbox="641 1312 1399 1357">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1357 641 1447">Main Scan</td> <td data-bbox="641 1357 1399 1447">Auto color registration adjustment value of the main scanning direction</td> </tr> <tr> <td data-bbox="336 1447 641 1536">Sub Scan</td> <td data-bbox="641 1447 1399 1536">Auto color registration adjustment value of the auxiliary scanning direction</td> </tr> <tr> <td data-bbox="336 1536 641 1581">Magnification</td> <td data-bbox="641 1536 1399 1581">Auto color registration adjustment value of the magnification</td> </tr> </tbody> </table> <p data-bbox="288 1621 866 1650">Displaying: [Manual(C)/Manual(M)/Manual(Y)]</p> <ol data-bbox="304 1655 1289 1684" style="list-style-type: none"> 1. Select [Manual(C)], [Manual(M)] or [Manual(Y)]. The current value is displayed. <table border="1" data-bbox="336 1697 1399 1966"> <thead> <tr> <th data-bbox="336 1697 641 1742">Display</th> <th data-bbox="641 1697 1399 1742">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1742 641 1832">Main Scan</td> <td data-bbox="641 1742 1399 1832">Manual color registration adjustment value of the main scanning direction</td> </tr> <tr> <td data-bbox="336 1832 641 1921">Sub Scan</td> <td data-bbox="641 1832 1399 1921">Manual color registration adjustment value of the auxiliary scanning direction</td> </tr> <tr> <td data-bbox="336 1921 641 1966">Magnification</td> <td data-bbox="641 1921 1399 1966">Manual color registration adjustment value of the magnification</td> </tr> </tbody> </table>	Display	Description	V Correction	Display the transfer speed adjustment value	Auto(C)	Display the auto color registration adjustment value for cyan	Auto(M)	Display the auto color registration adjustment value for magenta	Auto(Y)	Display the auto color registration adjustment value for yellow	Manual(C)	Display the manual color registration adjustment value for cyan	Manual(M)	Display the manual color registration adjustment value for magenta	Manual(Y)	Display the manual color registration adjustment value for yellow	Display	Description	Status	transfer speed adjustment value	Display	Description	Main Scan	Auto color registration adjustment value of the main scanning direction	Sub Scan	Auto color registration adjustment value of the auxiliary scanning direction	Magnification	Auto color registration adjustment value of the magnification	Display	Description	Main Scan	Manual color registration adjustment value of the main scanning direction	Sub Scan	Manual color registration adjustment value of the auxiliary scanning direction	Magnification	Manual color registration adjustment value of the magnification
Display	Description																																				
V Correction	Display the transfer speed adjustment value																																				
Auto(C)	Display the auto color registration adjustment value for cyan																																				
Auto(M)	Display the auto color registration adjustment value for magenta																																				
Auto(Y)	Display the auto color registration adjustment value for yellow																																				
Manual(C)	Display the manual color registration adjustment value for cyan																																				
Manual(M)	Display the manual color registration adjustment value for magenta																																				
Manual(Y)	Display the manual color registration adjustment value for yellow																																				
Display	Description																																				
Status	transfer speed adjustment value																																				
Display	Description																																				
Main Scan	Auto color registration adjustment value of the main scanning direction																																				
Sub Scan	Auto color registration adjustment value of the auxiliary scanning direction																																				
Magnification	Auto color registration adjustment value of the magnification																																				
Display	Description																																				
Main Scan	Manual color registration adjustment value of the main scanning direction																																				
Sub Scan	Manual color registration adjustment value of the auxiliary scanning direction																																				
Magnification	Manual color registration adjustment value of the magnification																																				

Item No.	Description										
U468	<p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>										
U469	<p>Adjusting the color registration</p> <p>Description Performs the color registration correction and transfer belt speed correction.</p> <p>Purpose To perform when replacing the maintenance kit or laser scanner unit.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 712 1401 954"> <thead> <tr> <th data-bbox="336 712 564 763">Display</th> <th data-bbox="564 712 1401 763">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 763 564 808">Auto</td> <td data-bbox="564 763 1401 808">Executing the auto color registration correction</td> </tr> <tr> <td data-bbox="336 808 564 853">Manual</td> <td data-bbox="564 808 1401 853">Executing the manual color registration correction</td> </tr> <tr> <td data-bbox="336 853 564 898">Belt Initialize</td> <td data-bbox="564 853 1401 898">Executing the transfer belt speed correction</td> </tr> <tr> <td data-bbox="336 898 564 954">Belt Check</td> <td data-bbox="564 898 1401 954">Confirmation of transfer belt position</td> </tr> </tbody> </table> <p>Method: [Auto]</p> <ol style="list-style-type: none"> 1. Select [Print]. 2. Press the start key. A chart for adjustment is outputted. 3. Set the output chart for adjustment as the original. 4. Select [Execute]. 5. Press the start key. Color registration correction starts. 6. When normally completed, [OK] is displayed. If a problem occurs during auto adjustment, error code is displayed. <div data-bbox="539 1294 1174 1742"> </div> <p style="text-align: center;">Chart for adjustment</p> <p style="text-align: center;">Figure 1-3-33</p>	Display	Description	Auto	Executing the auto color registration correction	Manual	Executing the manual color registration correction	Belt Initialize	Executing the transfer belt speed correction	Belt Check	Confirmation of transfer belt position
Display	Description										
Auto	Executing the auto color registration correction										
Manual	Executing the manual color registration correction										
Belt Initialize	Executing the transfer belt speed correction										
Belt Check	Confirmation of transfer belt position										

Item No.	Description																								
U469	<p data-bbox="336 241 488 271">Error codes</p> <table border="1" data-bbox="336 286 1401 573"> <thead> <tr> <th>Codes</th> <th>Description</th> <th>Codes</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>S001</td> <td>Patch not detected</td> <td>S004</td> <td>Original inclination error</td> </tr> <tr> <td>S002</td> <td>Original deviation in the main scanning direction</td> <td>S005</td> <td>Original type error</td> </tr> <tr> <td>S003</td> <td>Original deviation in the auxiliary scanning direction</td> <td>SFFF</td> <td>Scanner other error</td> </tr> <tr> <td></td> <td></td> <td>E001</td> <td>Engine state error</td> </tr> <tr> <td></td> <td></td> <td>CFFF</td> <td>Controller other error</td> </tr> </tbody> </table> <p data-bbox="292 618 512 647">Method: [Manual]</p> <ol data-bbox="308 654 1406 853" style="list-style-type: none"> 1. Select [Print]. 2. Press the start key. A chart for adjustment is outputted. 3. Select [Regist]. 4. Read figures at MH-1 to 7/CH-1 to 7/YH-1 to 7 and MV-3/CV-3/YV-3 of the reference chart and enter the figure marked at the scale which the BK fine line is in line with the M/C/Y fine lines, using the # key or * key. <div data-bbox="296 887 1422 1312" style="border: 1px solid black; padding: 10px;">  <p data-bbox="472 1272 719 1301" style="text-align: center;">Chart for adjustment</p> <p data-bbox="962 1200 1358 1294" style="text-align: center;">(example) When a red bar exactly coincides with B, enter B as a value.</p> </div> <p data-bbox="775 1346 943 1375" style="text-align: center;">Figure 1-3-34</p> <ol data-bbox="308 1417 1390 1547" style="list-style-type: none"> 5. Press the start key. The value is set. 6. Press the start key after all values have been entered. Color registration correction starts. 7. Print a chart for adjustment. 8. Verify that each scale is within the range of 1 to A. <div data-bbox="632 1570 1086 1827" style="border: 1px solid black; padding: 10px;">  <p data-bbox="659 1895 1054 1955" style="text-align: center;">The scale must be corresponding within the range of "A" from "1".</p> </div> <p data-bbox="775 1984 943 2016" style="text-align: center;">Figure 1-3-35</p>	Codes	Description	Codes	Description	S001	Patch not detected	S004	Original inclination error	S002	Original deviation in the main scanning direction	S005	Original type error	S003	Original deviation in the auxiliary scanning direction	SFFF	Scanner other error			E001	Engine state error			CFFF	Controller other error
Codes	Description	Codes	Description																						
S001	Patch not detected	S004	Original inclination error																						
S002	Original deviation in the main scanning direction	S005	Original type error																						
S003	Original deviation in the auxiliary scanning direction	SFFF	Scanner other error																						
		E001	Engine state error																						
		CFFF	Controller other error																						

Item No.	Description										
U469	<p>Method: [Belt Initialize]</p> <ol style="list-style-type: none"> 1. Select [Execute]. 2. Press the start key. Transfer belt speed correction starts. <p>Method:[Belt Check]</p> <ol style="list-style-type: none"> 1. Select [Mode]. 2. Change the setting value using the +/- keys. <table border="1" data-bbox="336 495 1401 734"> <thead> <tr> <th data-bbox="336 495 639 539">Display</th> <th data-bbox="639 495 1401 539">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 539 639 584">Angle</td> <td data-bbox="639 539 1401 584">Display of cam position</td> </tr> <tr> <td data-bbox="336 584 639 629">Belt Position</td> <td data-bbox="639 584 1401 629">Display of belt position</td> </tr> <tr> <td data-bbox="336 629 639 674">Mode</td> <td data-bbox="639 629 1401 674">Operational mode</td> </tr> <tr> <td data-bbox="336 674 639 734">Excute</td> <td data-bbox="639 674 1401 734">Execution of belt position confirmation</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Select [Execute]. 4. Press the start key. Transfer belt position confirmation starts, and the value is displayed. <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Angle	Display of cam position	Belt Position	Display of belt position	Mode	Operational mode	Excute	Execution of belt position confirmation
Display	Description										
Angle	Display of cam position										
Belt Position	Display of belt position										
Mode	Operational mode										
Excute	Execution of belt position confirmation										

Item No.	Description																										
U470	<p data-bbox="290 241 750 273">Setting the JPEG compression ratio</p> <p data-bbox="290 311 440 342">Description</p> <p data-bbox="290 344 1158 376">Sets the compression ratio for JPEG images in each image quality mode.</p> <p data-bbox="290 380 400 412">Purpose</p> <p data-bbox="290 414 1418 584">To change the setting in accordance with the image that the user is copying. For example, in order to soften the coarseness of the image when making copies at over 200% magnification, change the level of compression by raising the value. Lowering the value will increase the compression and thereby lower the image quality; Raising the value will increase image quality but lower the image processing speed.</p> <p data-bbox="290 622 387 654">Method</p> <ol data-bbox="308 656 632 719" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 734 1399 927"> <thead> <tr> <th data-bbox="336 734 641 781">Display</th> <th data-bbox="641 734 1399 781">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 781 641 828">Copy</td> <td data-bbox="641 781 1399 828">Compression ratio for copying</td> </tr> <tr> <td data-bbox="336 828 641 875">Send</td> <td data-bbox="641 828 1399 875">Compression ratio for sending</td> </tr> <tr> <td data-bbox="336 875 641 927">System</td> <td data-bbox="641 875 1399 927">Compression ratio for temporary storage in system</td> </tr> </tbody> </table> <p data-bbox="290 974 485 1005">Setting: [Copy]</p> <ol data-bbox="308 1008 632 1039" style="list-style-type: none"> 1. Select the item to be set. <table border="1" data-bbox="336 1055 1399 1196"> <thead> <tr> <th data-bbox="336 1055 641 1102">Display</th> <th data-bbox="641 1055 1399 1102">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1102 641 1149">Photo</td> <td data-bbox="641 1102 1399 1149">Compression ratio in the photo mode</td> </tr> <tr> <td data-bbox="336 1149 641 1196">Text</td> <td data-bbox="641 1149 1399 1196">Compression ratio in the text mode</td> </tr> </tbody> </table> <ol data-bbox="308 1207 1054 1270" style="list-style-type: none"> 2. Select the item to be set. 3. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 1285 1399 1464"> <thead> <tr> <th data-bbox="336 1285 564 1368">Display</th> <th data-bbox="564 1285 1066 1368">Description</th> <th data-bbox="1066 1285 1233 1368">Setting range</th> <th data-bbox="1233 1285 1399 1368">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1368 564 1415">Y</td> <td data-bbox="564 1368 1066 1415">Compression ratio of brightness</td> <td data-bbox="1066 1368 1233 1415">1 to 100</td> <td data-bbox="1233 1368 1399 1415">90</td> </tr> <tr> <td data-bbox="336 1415 564 1464">CbCr</td> <td data-bbox="564 1415 1066 1464">Compression ratio of color differential</td> <td data-bbox="1066 1415 1233 1464">1 to 100</td> <td data-bbox="1233 1415 1399 1464">90</td> </tr> </tbody> </table> <ol data-bbox="308 1476 767 1507" style="list-style-type: none"> 4. Press the start key. The value is set. 	Display	Description	Copy	Compression ratio for copying	Send	Compression ratio for sending	System	Compression ratio for temporary storage in system	Display	Description	Photo	Compression ratio in the photo mode	Text	Compression ratio in the text mode	Display	Description	Setting range	Initial setting	Y	Compression ratio of brightness	1 to 100	90	CbCr	Compression ratio of color differential	1 to 100	90
Display	Description																										
Copy	Compression ratio for copying																										
Send	Compression ratio for sending																										
System	Compression ratio for temporary storage in system																										
Display	Description																										
Photo	Compression ratio in the photo mode																										
Text	Compression ratio in the text mode																										
Display	Description	Setting range	Initial setting																								
Y	Compression ratio of brightness	1 to 100	90																								
CbCr	Compression ratio of color differential	1 to 100	90																								




Item No.	Description																																																										
U470	<p data-bbox="288 241 480 271">Setting: [Send]</p> <p data-bbox="288 277 632 306">1. Select the item to be set.</p> <table border="1" data-bbox="336 320 1401 595"> <thead> <tr> <th data-bbox="336 320 639 365">Display</th> <th data-bbox="639 320 1401 365">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 365 639 409">Photo</td> <td data-bbox="639 365 1401 409">Compression ratio in the photo mode</td> </tr> <tr> <td data-bbox="336 409 639 454">Text</td> <td data-bbox="639 409 1401 454">Compression ratio in the text mode</td> </tr> <tr> <td data-bbox="336 454 639 499">HC-PDF(BG)</td> <td data-bbox="639 454 1401 499">Compression ratio of high compression PDF</td> </tr> <tr> <td data-bbox="336 499 639 595">HC-PDF(Char)</td> <td data-bbox="639 499 1401 595">Setting the compression rate of the high-compression PDF (text color)</td> </tr> </tbody> </table> <p data-bbox="288 651 632 680">2. Select the item to be set.</p> <p data-bbox="288 687 1054 716">3. Change the setting value using the +/- keys or numeric keys.</p> <p data-bbox="336 723 528 752">[Photo] or [Text]</p> <table border="1" data-bbox="336 766 1401 943"> <thead> <tr> <th data-bbox="336 766 549 842">Display</th> <th data-bbox="549 766 1019 842">Description</th> <th data-bbox="1019 766 1187 842">Setting range</th> <th data-bbox="1187 766 1401 842">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 842 549 887">Y1 to Y5</td> <td data-bbox="549 842 1019 887">Compression ratio of brightness</td> <td data-bbox="1019 842 1187 887">1 to 100</td> <td data-bbox="1187 842 1401 887">30/40/51/70/90</td> </tr> <tr> <td data-bbox="336 887 549 943">CbCr1 to CbCr5</td> <td data-bbox="549 887 1019 943">Compression ratio of color differential</td> <td data-bbox="1019 887 1187 943">1 to 100</td> <td data-bbox="1187 887 1401 943">30/40/51/70/90</td> </tr> </tbody> </table> <p data-bbox="336 956 512 985">[HC-PDF(BG)]</p> <table border="1" data-bbox="336 999 1401 1176"> <thead> <tr> <th data-bbox="336 999 549 1075">Display</th> <th data-bbox="549 999 1019 1075">Description</th> <th data-bbox="1019 999 1187 1075">Setting range</th> <th data-bbox="1187 999 1401 1075">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1075 549 1120">Y3 to Y3</td> <td data-bbox="549 1075 1019 1120">Compression ratio of brightness</td> <td data-bbox="1019 1075 1187 1120">1 to 100</td> <td data-bbox="1187 1075 1401 1120">15/25/90</td> </tr> <tr> <td data-bbox="336 1120 549 1176">CbCr3 to CbCr3</td> <td data-bbox="549 1120 1019 1176">Compression ratio of color differential</td> <td data-bbox="1019 1120 1187 1176">1 to 100</td> <td data-bbox="1187 1120 1401 1176">15/25/90</td> </tr> </tbody> </table> <p data-bbox="336 1189 528 1218">[HC-PDF(Char)]</p> <table border="1" data-bbox="336 1232 1401 1408"> <thead> <tr> <th data-bbox="336 1232 549 1308">Display</th> <th data-bbox="549 1232 1019 1308">Description</th> <th data-bbox="1019 1232 1187 1308">Setting range</th> <th data-bbox="1187 1232 1401 1308">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1308 549 1352">Y3 to Y3</td> <td data-bbox="549 1308 1019 1352">Compression ratio of brightness</td> <td data-bbox="1019 1308 1187 1352">1 to 100</td> <td data-bbox="1187 1308 1401 1352">15/25/90</td> </tr> <tr> <td data-bbox="336 1352 549 1408">CbCr3 to CbCr3</td> <td data-bbox="549 1352 1019 1408">Compression ratio of color differential</td> <td data-bbox="1019 1352 1187 1408">1 to 100</td> <td data-bbox="1187 1352 1401 1408">15/25/90</td> </tr> </tbody> </table> <p data-bbox="288 1422 767 1451">4. Press the start key. The value is set.</p> <p data-bbox="288 1487 512 1516">Setting: [System]</p> <p data-bbox="288 1523 632 1552">1. Select the item to be set.</p> <p data-bbox="288 1559 1054 1588">2. Change the setting value using the +/- keys or numeric keys.</p> <table border="1" data-bbox="336 1601 1401 1778"> <thead> <tr> <th data-bbox="336 1601 564 1677">Display</th> <th data-bbox="564 1601 1066 1677">Description</th> <th data-bbox="1066 1601 1233 1677">Setting range</th> <th data-bbox="1233 1601 1401 1677">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1677 564 1722">Y</td> <td data-bbox="564 1677 1066 1722">Compression ratio of brightness</td> <td data-bbox="1066 1677 1233 1722">1 to 100</td> <td data-bbox="1233 1677 1401 1722">90</td> </tr> <tr> <td data-bbox="336 1722 564 1778">CbCr</td> <td data-bbox="564 1722 1066 1778">Compression ratio of color differential</td> <td data-bbox="1066 1722 1233 1778">1 to 100</td> <td data-bbox="1233 1722 1401 1778">90</td> </tr> </tbody> </table> <p data-bbox="288 1792 767 1821">3. Press the start key. The value is set.</p> <p data-bbox="288 1827 448 1856">Supplement</p> <p data-bbox="288 1863 1417 1928">While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p data-bbox="288 1964 440 1993">Completion</p> <p data-bbox="288 2000 1254 2029">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Photo	Compression ratio in the photo mode	Text	Compression ratio in the text mode	HC-PDF(BG)	Compression ratio of high compression PDF	HC-PDF(Char)	Setting the compression rate of the high-compression PDF (text color)	Display	Description	Setting range	Initial setting	Y1 to Y5	Compression ratio of brightness	1 to 100	30/40/51/70/90	CbCr1 to CbCr5	Compression ratio of color differential	1 to 100	30/40/51/70/90	Display	Description	Setting range	Initial setting	Y3 to Y3	Compression ratio of brightness	1 to 100	15/25/90	CbCr3 to CbCr3	Compression ratio of color differential	1 to 100	15/25/90	Display	Description	Setting range	Initial setting	Y3 to Y3	Compression ratio of brightness	1 to 100	15/25/90	CbCr3 to CbCr3	Compression ratio of color differential	1 to 100	15/25/90	Display	Description	Setting range	Initial setting	Y	Compression ratio of brightness	1 to 100	90	CbCr	Compression ratio of color differential	1 to 100	90
Display	Description																																																										
Photo	Compression ratio in the photo mode																																																										
Text	Compression ratio in the text mode																																																										
HC-PDF(BG)	Compression ratio of high compression PDF																																																										
HC-PDF(Char)	Setting the compression rate of the high-compression PDF (text color)																																																										
Display	Description	Setting range	Initial setting																																																								
Y1 to Y5	Compression ratio of brightness	1 to 100	30/40/51/70/90																																																								
CbCr1 to CbCr5	Compression ratio of color differential	1 to 100	30/40/51/70/90																																																								
Display	Description	Setting range	Initial setting																																																								
Y3 to Y3	Compression ratio of brightness	1 to 100	15/25/90																																																								
CbCr3 to CbCr3	Compression ratio of color differential	1 to 100	15/25/90																																																								
Display	Description	Setting range	Initial setting																																																								
Y3 to Y3	Compression ratio of brightness	1 to 100	15/25/90																																																								
CbCr3 to CbCr3	Compression ratio of color differential	1 to 100	15/25/90																																																								
Display	Description	Setting range	Initial setting																																																								
Y	Compression ratio of brightness	1 to 100	90																																																								
CbCr	Compression ratio of color differential	1 to 100	90																																																								

Item No.	Description																								
U474	<p data-bbox="288 241 719 275">Checking LSU cleaning operation</p> <p data-bbox="288 309 440 342">Description</p> <p data-bbox="288 344 1385 412">Provides cleaning LSU by means of the LSU cleaning motor. Also, the cleaning cycle can be adjusted.</p> <p data-bbox="288 450 387 483">Method</p> <ol data-bbox="304 486 564 553" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 562 1401 707"> <thead> <tr> <th data-bbox="336 562 639 607">Display</th> <th data-bbox="639 562 1401 607">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 607 639 651">Execute</td> <td data-bbox="639 607 1401 651">Executing the cleaning operation</td> </tr> <tr> <td data-bbox="336 651 639 707">Cycle</td> <td data-bbox="639 651 1401 707">Setting the cleaning cycle</td> </tr> </tbody> </table> <p data-bbox="288 752 523 786">Method: [Execute]</p> <ol data-bbox="304 788 898 822" style="list-style-type: none"> 1. Press the start key. Cleaning the LSU slit glass. <p data-bbox="288 855 488 889">Setting: [Cycle]</p> <ol data-bbox="304 891 815 925" style="list-style-type: none"> 1. Change the setting value using +/- keys. <table border="1" data-bbox="336 934 1401 1113"> <thead> <tr> <th data-bbox="336 934 564 1012">Display</th> <th data-bbox="564 934 1066 1012">Description</th> <th data-bbox="1066 934 1233 1012">Setting range</th> <th data-bbox="1233 934 1401 1012">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1012 564 1068">Cycle</td> <td data-bbox="564 1012 1066 1068">Cleaning cycle</td> <td data-bbox="1066 1012 1233 1068">0 to 5000</td> <td data-bbox="1233 1012 1401 1068">1000</td> </tr> <tr> <td data-bbox="336 1068 564 1113">Timing</td> <td data-bbox="564 1068 1066 1113">Cleaning timing</td> <td data-bbox="1066 1068 1233 1113">-</td> <td data-bbox="1233 1068 1401 1113">Print End</td> </tr> </tbody> </table> <p data-bbox="336 1128 882 1162">The setting can be changed by 1000 per step.</p> <ol data-bbox="304 1164 767 1198" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1232 504 1265">Setting: [Timing]</p> <ol data-bbox="304 1267 520 1301" style="list-style-type: none"> 1. Select the item. <table border="1" data-bbox="336 1310 1401 1456"> <thead> <tr> <th data-bbox="336 1310 639 1355">Display</th> <th data-bbox="639 1310 1401 1355">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1355 639 1400">Print</td> <td data-bbox="639 1355 1401 1400">Execute during a Job</td> </tr> <tr> <td data-bbox="336 1400 639 1456">Print End</td> <td data-bbox="639 1400 1401 1456">Execute after a Job has been completed</td> </tr> </tbody> </table> <p data-bbox="336 1464 612 1498">Initial setting: Print End</p> <ol data-bbox="304 1500 767 1534" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1568 440 1601">Completion</p> <p data-bbox="288 1603 1254 1637">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Execute	Executing the cleaning operation	Cycle	Setting the cleaning cycle	Display	Description	Setting range	Initial setting	Cycle	Cleaning cycle	0 to 5000	1000	Timing	Cleaning timing	-	Print End	Display	Description	Print	Execute during a Job	Print End	Execute after a Job has been completed
Display	Description																								
Execute	Executing the cleaning operation																								
Cycle	Setting the cleaning cycle																								
Display	Description	Setting range	Initial setting																						
Cycle	Cleaning cycle	0 to 5000	1000																						
Timing	Cleaning timing	-	Print End																						
Display	Description																								
Print	Execute during a Job																								
Print End	Execute after a Job has been completed																								

Item No.	Description																												
U485	<p data-bbox="288 241 746 275">Setting the image processing mode</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1382 412">Sets the detection level for scanning printed matter outputted with the confidential document guard function. Also, sets the process PDF images are rotated.</p> <p data-bbox="288 416 400 445">Purpose</p> <p data-bbox="288 450 1433 517">To change the detection level when the confidential document guard is not printed well for detection in scanning. Also, changes the process of how PDF images are rotated.</p> <p data-bbox="288 553 387 582">Method</p> <ol data-bbox="304 586 564 654" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 665 1401 808"> <thead> <tr> <th data-bbox="336 665 639 710">Display</th> <th data-bbox="639 665 1401 710">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 710 639 754">Mode</td> <td data-bbox="639 710 1401 754">Setting the image processing mode</td> </tr> <tr> <td data-bbox="336 754 639 808">Color Table</td> <td data-bbox="639 754 1401 808">Setting the Color Table</td> </tr> </tbody> </table> <p data-bbox="288 853 488 882">Setting: [Mode]</p> <ol data-bbox="304 887 520 916" style="list-style-type: none"> 1. Select the item. <table border="1" data-bbox="336 929 1401 1077"> <thead> <tr> <th data-bbox="336 929 639 974">Display</th> <th data-bbox="639 929 1401 974">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 974 639 1019">Conf. Doc. Detection</td> <td data-bbox="639 974 1401 1019">Confidential document guard detection level</td> </tr> <tr> <td data-bbox="336 1019 639 1077">PDF Rotation</td> <td data-bbox="639 1019 1401 1077">Processing the rotation of PDF images</td> </tr> </tbody> </table> <p data-bbox="288 1122 679 1151">Setting: [Conf. Doc. Detection]</p> <ol data-bbox="304 1155 1010 1184" style="list-style-type: none"> 1. Change the setting value using +/- keys or numeric keys. <table border="1" data-bbox="336 1198 1401 1364"> <thead> <tr> <th data-bbox="336 1198 564 1279">Display</th> <th data-bbox="564 1198 1066 1279">Description</th> <th data-bbox="1066 1198 1233 1279">Setting range</th> <th data-bbox="1233 1198 1401 1279">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1279 564 1364">Conf. Doc. Detection</td> <td data-bbox="564 1279 1066 1364">Confidential document guard detection level</td> <td data-bbox="1066 1279 1233 1364">1 to 5</td> <td data-bbox="1233 1279 1401 1364">1</td> </tr> </tbody> </table> <p data-bbox="333 1375 1433 1442">A smaller value raises the detection sensitivity but increases the possibility of false detection. A larger value lowers the detection sensitivity but decreases the possibility of false detection.</p> <ol data-bbox="304 1447 767 1476" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1512 587 1541">Setting: [PDF Rotation]</p> <ol data-bbox="304 1545 1010 1574" style="list-style-type: none"> 1. Change the setting value using +/- keys or numeric keys. <table border="1" data-bbox="336 1588 1401 1821"> <thead> <tr> <th data-bbox="336 1588 639 1632">Display</th> <th data-bbox="639 1588 1401 1632">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1632 639 1677">0</td> <td data-bbox="639 1632 1401 1677">Assigns the image rotation with the internal parameter</td> </tr> <tr> <td data-bbox="336 1677 639 1722">1</td> <td data-bbox="639 1677 1401 1722">Assigns the image rotation with the actual image</td> </tr> <tr> <td data-bbox="336 1722 639 1821">2</td> <td data-bbox="639 1722 1401 1821">Assigns the image rotation with the internal parameter (CTM rotation)</td> </tr> </tbody> </table> <p data-bbox="333 1832 517 1861">Initial setting: 0</p> <ol data-bbox="304 1865 767 1895" style="list-style-type: none"> 2. Press the start key. The value is set. 	Display	Description	Mode	Setting the image processing mode	Color Table	Setting the Color Table	Display	Description	Conf. Doc. Detection	Confidential document guard detection level	PDF Rotation	Processing the rotation of PDF images	Display	Description	Setting range	Initial setting	Conf. Doc. Detection	Confidential document guard detection level	1 to 5	1	Display	Description	0	Assigns the image rotation with the internal parameter	1	Assigns the image rotation with the actual image	2	Assigns the image rotation with the internal parameter (CTM rotation)
Display	Description																												
Mode	Setting the image processing mode																												
Color Table	Setting the Color Table																												
Display	Description																												
Conf. Doc. Detection	Confidential document guard detection level																												
PDF Rotation	Processing the rotation of PDF images																												
Display	Description	Setting range	Initial setting																										
Conf. Doc. Detection	Confidential document guard detection level	1 to 5	1																										
Display	Description																												
0	Assigns the image rotation with the internal parameter																												
1	Assigns the image rotation with the actual image																												
2	Assigns the image rotation with the internal parameter (CTM rotation)																												

Item No.	Description										
U485	<p data-bbox="288 241 488 275">Setting: [Mode]</p> <p data-bbox="304 311 520 338">1. Select the item.</p> <table border="1" data-bbox="336 353 1401 595"> <thead> <tr> <th data-bbox="336 353 639 398">Display</th> <th data-bbox="639 353 1401 398">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 398 639 443">Color Table 1(Prn)</td> <td data-bbox="639 398 1401 443">Setting the printer color table (Default)</td> </tr> <tr> <td data-bbox="336 443 639 488">Color Table 2(Prn)</td> <td data-bbox="639 443 1401 488">Setting the printer color table (Custom)</td> </tr> <tr> <td data-bbox="336 488 639 533">Install</td> <td data-bbox="639 488 1401 533">Install the printer color table</td> </tr> <tr> <td data-bbox="336 533 639 595">Uninstall</td> <td data-bbox="639 533 1401 595">Uninstall the printer color table</td> </tr> </tbody> </table> <p data-bbox="288 640 903 674">Setting: [Color Table 1(Prn)],[Color Table 2(Prn)]</p> <p data-bbox="304 678 1131 880"> 1. Default/Custom printer color tables are shown. 2. Press the appropriate button. 3. Press the target button for switching 4. Press the Start key and [Complete] is displayed. 5. Press the reset key. 6. Once the screen changes to blue, turn the power switch off and on. </p> <p data-bbox="288 920 496 954">Setting: [Install]</p> <p data-bbox="336 954 1425 1016">* : Before proceeding, make sure that the USB flash device that contains the color table files is inserted.</p> <p data-bbox="368 1021 1214 1055">The color table files must be placed in the root of the USB flash device.</p> <p data-bbox="304 1059 911 1160"> 1. Press the Excute button once it is activated. 2. Press the [Start] key. 3. Installation is completed when [OK] is displayed. </p> <p data-bbox="288 1200 528 1234">Setting: [Uninstall]</p> <p data-bbox="304 1234 1163 1335"> 1. The color table currently being installed is displayed. 2. Select the color table you want to uninstall, then press the Start key. * : You can select more than one file to simultaneously uninstall them. </p> <p data-bbox="288 1440 440 1473">Completion</p> <p data-bbox="288 1473 1254 1507">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Color Table 1(Prn)	Setting the printer color table (Default)	Color Table 2(Prn)	Setting the printer color table (Custom)	Install	Install the printer color table	Uninstall	Uninstall the printer color table
Display	Description										
Color Table 1(Prn)	Setting the printer color table (Default)										
Color Table 2(Prn)	Setting the printer color table (Custom)										
Install	Install the printer color table										
Uninstall	Uninstall the printer color table										

Item No.	Description																
U486	<p data-bbox="288 241 871 271">Setting color/black and white operation mode</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1358 409">When color and B/W documents are mixed, sets operation mode after a color document is detected.</p> <p data-bbox="288 414 400 443">Purpose</p> <p data-bbox="288 448 1401 546">To ensure productivity when copying color and B/W documents in ACS mode, select Mode3. However, selecting Mode3 will increase the maintenance count for cyan, magenta, and yellow color developer units even when there is a B/W original after a color original.</p> <ol data-bbox="304 589 564 651" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 665 1401 808"> <thead> <tr> <th data-bbox="336 665 639 710">Display</th> <th data-bbox="639 665 1401 710">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 710 639 754">Mode</td> <td data-bbox="639 710 1401 754">Setting color/black and white operation</td> </tr> <tr> <td data-bbox="336 754 639 808">Permission</td> <td data-bbox="639 754 1401 808">Permission for Half-speed monochrome printing</td> </tr> </tbody> </table> <p data-bbox="288 853 480 882">[Setting:Mode]</p> <ol data-bbox="304 887 564 949" style="list-style-type: none"> 1. Press the start key. 2. Select the mode. <table border="1" data-bbox="336 965 1401 1798"> <thead> <tr> <th data-bbox="336 965 475 1010">Display</th> <th data-bbox="475 965 1401 1010">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1010 475 1216">Mode1</td> <td data-bbox="475 1010 1401 1216"> <p data-bbox="485 1021 1337 1086">A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is minimum.</p> <p data-bbox="485 1104 1378 1202">Once diverted to color printing mode, the subsequent black and white printing is executed in the same linear velocity as in color printing with other processings switched on the fly.</p> </td> </tr> <tr> <td data-bbox="336 1216 475 1449">Mode2</td> <td data-bbox="475 1216 1401 1449"> <p data-bbox="485 1227 1337 1292">A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is maximum.</p> <p data-bbox="485 1310 1385 1438">Printing in color mode resumes up to 9 pages in a row even an interrupt is made to switch to black and white mode, until printing is diverted to black and white mode from color mode at the 10th page (color processing is terminated).</p> </td> </tr> <tr> <td data-bbox="336 1449 475 1646">Mode3</td> <td data-bbox="475 1449 1401 1646"> <p data-bbox="485 1460 1337 1525">A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is maximum.</p> <p data-bbox="485 1543 1366 1641">Mode suited for high color printing volume Once diverted to color mode, the black and white printings are executed in color processing mode (including the linear velocity).</p> </td> </tr> <tr> <td data-bbox="336 1646 475 1798">Auto</td> <td data-bbox="475 1646 1401 1798"> <p data-bbox="485 1657 1385 1785">Mode that allows to select from modes 1 through 3 depending on the usage. Mode is selected from three modes depending on the percentage of color and black and white printings in the total number of print pages during a pre-determined period.</p> </td> </tr> </tbody> </table> <p data-bbox="336 1821 584 1850">Initial setting: Mode2</p> <ol data-bbox="304 1854 780 1883" style="list-style-type: none"> 3. Press the start key. The setting is set. 	Display	Description	Mode	Setting color/black and white operation	Permission	Permission for Half-speed monochrome printing	Display	Description	Mode1	<p data-bbox="485 1021 1337 1086">A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is minimum.</p> <p data-bbox="485 1104 1378 1202">Once diverted to color printing mode, the subsequent black and white printing is executed in the same linear velocity as in color printing with other processings switched on the fly.</p>	Mode2	<p data-bbox="485 1227 1337 1292">A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is maximum.</p> <p data-bbox="485 1310 1385 1438">Printing in color mode resumes up to 9 pages in a row even an interrupt is made to switch to black and white mode, until printing is diverted to black and white mode from color mode at the 10th page (color processing is terminated).</p>	Mode3	<p data-bbox="485 1460 1337 1525">A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is maximum.</p> <p data-bbox="485 1543 1366 1641">Mode suited for high color printing volume Once diverted to color mode, the black and white printings are executed in color processing mode (including the linear velocity).</p>	Auto	<p data-bbox="485 1657 1385 1785">Mode that allows to select from modes 1 through 3 depending on the usage. Mode is selected from three modes depending on the percentage of color and black and white printings in the total number of print pages during a pre-determined period.</p>
Display	Description																
Mode	Setting color/black and white operation																
Permission	Permission for Half-speed monochrome printing																
Display	Description																
Mode1	<p data-bbox="485 1021 1337 1086">A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is minimum.</p> <p data-bbox="485 1104 1378 1202">Once diverted to color printing mode, the subsequent black and white printing is executed in the same linear velocity as in color printing with other processings switched on the fly.</p>																
Mode2	<p data-bbox="485 1227 1337 1292">A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is maximum.</p> <p data-bbox="485 1310 1385 1438">Printing in color mode resumes up to 9 pages in a row even an interrupt is made to switch to black and white mode, until printing is diverted to black and white mode from color mode at the 10th page (color processing is terminated).</p>																
Mode3	<p data-bbox="485 1460 1337 1525">A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is maximum.</p> <p data-bbox="485 1543 1366 1641">Mode suited for high color printing volume Once diverted to color mode, the black and white printings are executed in color processing mode (including the linear velocity).</p>																
Auto	<p data-bbox="485 1657 1385 1785">Mode that allows to select from modes 1 through 3 depending on the usage. Mode is selected from three modes depending on the percentage of color and black and white printings in the total number of print pages during a pre-determined period.</p>																

Item No.	Description						
<p>U486</p>	<p>[Setting:Permission]</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select On or Off <table border="1" data-bbox="336 353 1401 499"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>On</td> <td>Permission : monochrome printing * 1 (3 colors release)</td> </tr> <tr> <td>Off</td> <td>Prohibition : color printing (4-color press)</td> </tr> </tbody> </table> <p>Initial setting: Off</p> <p>When the background of printing on envelope is colored , set On. If perform it , there is a possibility that the jitter occurs.</p> <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p> <p>Details on the modes</p> <div data-bbox="288 786 1434 1133"> <p>Mode 1</p>  </div> <div data-bbox="288 1182 1434 1541"> <p>Mode 2</p>  </div> <div data-bbox="288 1590 1434 1962"> <p>Mode 3</p>  </div> <p style="text-align: center;">Figure 1-3-36</p>	Display	Description	On	Permission : monochrome printing * 1 (3 colors release)	Off	Prohibition : color printing (4-color press)
Display	Description						
On	Permission : monochrome printing * 1 (3 colors release)						
Off	Prohibition : color printing (4-color press)						

Item No.	Description																				
U901	<p data-bbox="290 241 884 275">Checking copy counts by paper feed locations</p> <p data-bbox="290 311 440 340">Description</p> <p data-bbox="290 344 1015 374">Displays or clears paper feed counts by paper feed locations.</p> <p data-bbox="290 378 1356 407">Performs backup when the counters on the engine PWB and PF main PWB do not match.</p> <p data-bbox="290 412 400 441">Purpose</p> <p data-bbox="290 445 1418 512">To check the time to replace consumable parts. Also to clear the counts after replacing the consumable parts.</p> <p data-bbox="290 517 1433 546">Backup the counter values after completing changing the PF main PWB and the paper feed unit.</p> <p data-bbox="290 582 387 611">Method</p> <p data-bbox="304 616 1161 645">1. Press the start key. The counts by paper feed locations are displayed.</p> <table border="1" data-bbox="336 663 1399 1144"> <thead> <tr> <th data-bbox="336 663 639 712">Display</th> <th data-bbox="639 663 1399 712">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 712 639 757">MPT</td> <td data-bbox="639 712 1399 757">MP tray</td> </tr> <tr> <td data-bbox="336 757 639 801">Cassette1</td> <td data-bbox="639 757 1399 801">Cassette 1</td> </tr> <tr> <td data-bbox="336 801 639 846">Cassette2</td> <td data-bbox="639 801 1399 846">Cassette 2</td> </tr> <tr> <td data-bbox="336 846 639 891">Cassette3</td> <td data-bbox="639 846 1399 891">Cassette 3 (paper feeder/large capacity feeder)</td> </tr> <tr> <td data-bbox="336 891 639 936">Cassette4</td> <td data-bbox="639 891 1399 936">Cassette 4 (paper feeder/large capacity feeder)</td> </tr> <tr> <td data-bbox="336 936 639 981">Cassette5</td> <td data-bbox="639 936 1399 981">Cassette 5 (side multi tray/side deck)</td> </tr> <tr> <td data-bbox="336 981 639 1025">Cassette6</td> <td data-bbox="639 981 1399 1025">Cassette 6 (side paper feeder/side large capacity feeder)</td> </tr> <tr> <td data-bbox="336 1025 639 1070">Cassette7</td> <td data-bbox="639 1025 1399 1070">Cassette 7 (side paper feeder/side large capacity feeder)</td> </tr> <tr> <td data-bbox="336 1070 639 1115">Duplex</td> <td data-bbox="639 1070 1399 1115">Duplex unit</td> </tr> </tbody> </table> <p data-bbox="336 1153 1370 1220">* : When an optional paper feed unit is not installed, the corresponding count is not displayed.</p> <p data-bbox="290 1256 400 1285">Clearing</p> <p data-bbox="304 1290 1347 1424">1. Select the counts to be cleared. [Cassette3], [Cassette4], [Cassette5], [Cassette6] and [Cassette7] cannot be cleared. 2. Select the counts for all and press [Clear]. 3. Press the start key. The counts is cleared.</p> <p data-bbox="290 1460 397 1489">Back up</p> <p data-bbox="304 1494 1380 1771">1. Select the paper feed location. 2. Select [Engine] when changing the PF main PWB. Backup the [Engine] counter values to [Enhancement]. Select [Enhancement] when changing the paper feed unit. Backup the [Enhancement] counter values to [Engine]. 3. Select [Execute]. 4. Press the start key. Back up the counter values. 5. Turn the main power switch off and on. Allow more than 5 seconds between Off and On.</p> <p data-bbox="336 1807 1329 1910">* : The values of cassette 4 counter vary in accordance with the cassette 3 counter. The values of cassette 7 counter vary in accordance with the cassette 6 counter. Select [None] if the counter values are not backed up.</p> <p data-bbox="290 1946 440 1975">Completion</p> <p data-bbox="290 1980 1256 2009">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MPT	MP tray	Cassette1	Cassette 1	Cassette2	Cassette 2	Cassette3	Cassette 3 (paper feeder/large capacity feeder)	Cassette4	Cassette 4 (paper feeder/large capacity feeder)	Cassette5	Cassette 5 (side multi tray/side deck)	Cassette6	Cassette 6 (side paper feeder/side large capacity feeder)	Cassette7	Cassette 7 (side paper feeder/side large capacity feeder)	Duplex	Duplex unit
Display	Description																				
MPT	MP tray																				
Cassette1	Cassette 1																				
Cassette2	Cassette 2																				
Cassette3	Cassette 3 (paper feeder/large capacity feeder)																				
Cassette4	Cassette 4 (paper feeder/large capacity feeder)																				
Cassette5	Cassette 5 (side multi tray/side deck)																				
Cassette6	Cassette 6 (side paper feeder/side large capacity feeder)																				
Cassette7	Cassette 7 (side paper feeder/side large capacity feeder)																				
Duplex	Duplex unit																				

Item No.	Description						
U903	<p data-bbox="290 241 798 275">Checking/clearing the paper jam counts</p> <p data-bbox="290 311 440 340">Description</p> <p data-bbox="290 344 890 376">Displays or clears the jam counts by jam locations.</p> <p data-bbox="290 380 400 409">Purpose</p> <p data-bbox="290 414 1390 445">To check the paper jam status. Also to clear the jam counts after replacing consumable parts.</p> <p data-bbox="290 483 387 512">Method</p> <ol data-bbox="304 517 564 582" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 595 1401 741"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1401 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">Cnt</td> <td data-bbox="639 640 1401 685">Displays/clears the jam counts</td> </tr> <tr> <td data-bbox="336 685 639 741">Total Cnt</td> <td data-bbox="639 685 1401 741">Displays the total jam counts</td> </tr> </tbody> </table> <p data-bbox="290 786 466 815">Method: [Cnt]</p> <ol data-bbox="304 819 1002 1025" style="list-style-type: none"> 1. Select [Cnt]. The count of jam code by type is displayed. Codes for which the count value is 0 are not displayed. 2. Change the screen using the cursor up/down keys. 3. Select the count value for jam code and press [Clear]. The individual counter cannot be cleared. 4. Press the start key. The counter value is cleared. <p data-bbox="290 1064 536 1093">Method: [Total Cnt]</p> <ol data-bbox="304 1097 1150 1198" style="list-style-type: none"> 1. Select [Total Cnt]. The total number of jam code by type is displayed. 2. Change the screen using the cursor up/down keys. The total number of jam count cannot be cleared. <p data-bbox="290 1270 805 1299">How to display the history of paper jams</p> <p data-bbox="290 1303 432 1332">[Function]</p> <p data-bbox="290 1337 1422 1368">To check the variation in the occurrences of paper jams as a consequence of firmware upgrade.</p> <p data-bbox="290 1406 448 1435">[Procedure]</p> <ol data-bbox="304 1440 1414 1541" style="list-style-type: none"> 1. Retrieves versions of system and engine software at the timing of clearing. 2. Displays comparison of the occurrences of paper jams before and after firmware upgrades. 3. Displays the date of clearing. <p data-bbox="290 1579 405 1608">[Method]</p> <p data-bbox="290 1612 553 1641">At firmware upgrade</p> <ol data-bbox="304 1646 1406 1747" style="list-style-type: none"> 1. Perform clearance of the counter following the above before performing firmware upgrade. 2. Clearing the counter records the date of clearing. 3. Perform firmware upgrade. <p data-bbox="290 1785 569 1814">At performing service</p> <ol data-bbox="304 1818 1426 1883" style="list-style-type: none"> 1. Print a maintenance report using mode U000 and check the variance of occurrence of paper jams after firmware upgrade was done. 	Display	Description	Cnt	Displays/clears the jam counts	Total Cnt	Displays the total jam counts
Display	Description						
Cnt	Displays/clears the jam counts						
Total Cnt	Displays the total jam counts						

Item No.	Description																																										
<p>U903</p>	<p>Detail of history of paper jams</p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p>Maintenance Report MFP 17/Apr/2011 08:40</p> <p>Firmware version 2LC_2000.000.000 2011.04.17 [XXXXXXXX] [XXXXXXXX] [XXXXXXXX]</p> <hr/> <p>Machine No.: SPXXX00001 Life Count : 001234</p> <hr/> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 40%;">(a) Paper Jam Log</td> <td style="width: 20%;">(b) 2011.12.12</td> <td style="width: 20%;"></td> <td style="width: 20%;"></td> </tr> <tr> <td>JAM0000</td> <td style="text-align: center;">1</td> <td style="text-align: center;">10</td> <td></td> </tr> <tr> <td>JAM0100</td> <td style="text-align: center;">0</td> <td style="text-align: center;">2</td> <td></td> </tr> <tr> <td>JAM0101</td> <td style="text-align: center;">0</td> <td style="text-align: center;">2</td> <td></td> </tr> <tr> <td>JAM0110</td> <td style="text-align: center;">0</td> <td style="text-align: center;">2</td> <td rowspan="7" style="vertical-align: middle; text-align: center;">(c) [] (d)</td> </tr> <tr> <td>JAM0111</td> <td style="text-align: center;">1</td> <td style="text-align: center;">2</td> </tr> <tr> <td>JAM0112</td> <td style="text-align: center;">0</td> <td style="text-align: center;">1</td> </tr> <tr> <td>JAM0131</td> <td style="text-align: center;">5</td> <td style="text-align: center;">89</td> </tr> <tr> <td>JAM0210</td> <td style="text-align: center;">2</td> <td style="text-align: center;">7</td> </tr> </table> </div> <p style="text-align: center;">Figure 1-3-37</p> <table border="1" style="width: 100%; border-collapse: collapse; margin: 10px 0;"> <thead> <tr> <th style="width: 10%;">No.</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>a</td> <td>Paper jam numbers</td> </tr> <tr> <td>b</td> <td>Date of clearing counter records</td> </tr> <tr> <td>c</td> <td>Occurrences of paper jams after clearing the paper jam counts</td> </tr> <tr> <td>d</td> <td>Total number of paper jams</td> </tr> </tbody> </table> <p>Method: [Total Cnt]</p> <ol style="list-style-type: none"> 1. Select [Total Cnt]. The total number of jam code by type is displayed. 2. Change the screen using the cursor up/down keys. The total number of jam count cannot be cleared. <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	(a) Paper Jam Log	(b) 2011.12.12			JAM0000	1	10		JAM0100	0	2		JAM0101	0	2		JAM0110	0	2	(c) [] (d)	JAM0111	1	2	JAM0112	0	1	JAM0131	5	89	JAM0210	2	7	No.	Description	a	Paper jam numbers	b	Date of clearing counter records	c	Occurrences of paper jams after clearing the paper jam counts	d	Total number of paper jams
(a) Paper Jam Log	(b) 2011.12.12																																										
JAM0000	1	10																																									
JAM0100	0	2																																									
JAM0101	0	2																																									
JAM0110	0	2	(c) [] (d)																																								
JAM0111	1	2																																									
JAM0112	0	1																																									
JAM0131	5	89																																									
JAM0210	2	7																																									
No.	Description																																										
a	Paper jam numbers																																										
b	Date of clearing counter records																																										
c	Occurrences of paper jams after clearing the paper jam counts																																										
d	Total number of paper jams																																										

Item No.	Description						
U904	<p data-bbox="288 241 861 275">Checking/clearing the call for service counts</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 954 376">Displays or clears the service call code counts by types.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 839 445">To check the service call code status by types.</p> <p data-bbox="288 450 1177 481">Also to clear the service call code counts after replacing consumable parts.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 553 564 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 631 1401 777"> <thead> <tr> <th data-bbox="336 631 639 680">Display</th> <th data-bbox="639 631 1401 680">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 680 639 730">Cnt</td> <td data-bbox="639 680 1401 730">Displays/clears the call for service counts</td> </tr> <tr> <td data-bbox="336 730 639 777">Total Cnt</td> <td data-bbox="639 730 1401 777">Displays the total call for service counts</td> </tr> </tbody> </table> <p data-bbox="288 822 467 851">Method: [Cnt]</p> <ol data-bbox="304 857 1152 1061" style="list-style-type: none"> 1. Select [Cnt]. The count for service call detection by type is displayed. Codes for which the count value is 0 are not displayed. 2. Change the screen using the cursor up/down keys. 3. Select the count value for service call code and press [Clear]. The individual counter cannot be cleared. 4. Press the start key. The counter value is cleared. <p data-bbox="288 1099 536 1128">Method: [Total Cnt]</p> <ol data-bbox="304 1135 1260 1232" style="list-style-type: none"> 1. Select [Total Cnt]. The total number of service call counts by type is displayed. 2. Change the screen using the cursor up/down keys. The total number of service call count cannot be cleared. <p data-bbox="288 1308 852 1337">How to display the history of service counts</p> <p data-bbox="288 1344 432 1373">[Function]</p> <p data-bbox="288 1377 1433 1408">To check the variation in the occurrences of service calls as a consequence of firmware upgrade.</p> <p data-bbox="288 1447 448 1476">[Procedure]</p> <ol data-bbox="304 1482 1428 1579" style="list-style-type: none"> 1. Retrieves versions of system and engine software at the timing of clearing. 2. Displays comparison of the occurrences of service calls before and after firmware upgrades. 3. Displays the date of clearing. <p data-bbox="288 1617 405 1646">[Method]</p> <p data-bbox="288 1653 553 1682">At firmware upgrade</p> <ol data-bbox="304 1688 1406 1785" style="list-style-type: none"> 1. Perform clearance of the counter following the above before performing firmware upgrade. 2. Clearing the counter records the date of clearing. 3. Perform firmware upgrade. <p data-bbox="288 1823 569 1852">At performing service</p> <ol data-bbox="304 1859 1406 1924" style="list-style-type: none"> 1. Print a maintenance report using mode U000 and check the variance of occurrence of service calls after firmware upgrade was done. 	Display	Description	Cnt	Displays/clears the call for service counts	Total Cnt	Displays the total call for service counts
Display	Description						
Cnt	Displays/clears the call for service counts						
Total Cnt	Displays the total call for service counts						

Item No.	Description																																																						
<p>U904</p>	<p>Detail of history of service counts</p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p style="text-align: center;">Maintenance Report</p> <p>MFP 17/Apr/2011 08:40</p> <p>Firmware version 2LC_2000.000.000 2011.04.17 [XXXXXXXX] [XXXXXXXX] [XXXXXXXX]</p> <hr/> <p>Machine No.: SPXXX00001 Life Count : 001234</p> <hr/> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 40%;">Paper Jam Log</td> <td style="width: 20%;">2011.12.12</td> <td style="width: 20%;"></td> <td style="width: 20%;"></td> </tr> <tr> <td style="padding-left: 20px;">JAM0000</td> <td style="padding-left: 20px;">10</td> <td style="padding-left: 20px;">1</td> <td></td> </tr> <tr> <td>(a) Service Call Log</td> <td>(b) 2011.12.12</td> <td></td> <td></td> </tr> <tr> <td style="padding-left: 20px;">C0630</td> <td style="padding-left: 20px;">1</td> <td style="padding-left: 20px;">1</td> <td></td> </tr> <tr> <td style="padding-left: 20px;">C1000</td> <td style="padding-left: 20px;">0</td> <td style="padding-left: 20px;">50</td> <td></td> </tr> <tr> <td style="padding-left: 20px;">C1950</td> <td style="padding-left: 20px;">0</td> <td style="padding-left: 20px;">1</td> <td></td> </tr> <tr> <td style="padding-left: 20px;">C2840</td> <td style="padding-left: 20px;">3</td> <td style="padding-left: 20px;">17</td> <td></td> </tr> <tr> <td style="padding-left: 20px;">C4300</td> <td style="padding-left: 20px;">1</td> <td style="padding-left: 20px;">2</td> <td></td> </tr> <tr> <td style="padding-left: 20px;">C9000</td> <td style="padding-left: 20px;">0</td> <td style="padding-left: 20px;">1</td> <td></td> </tr> <tr> <td style="padding-left: 20px;">C9060</td> <td style="padding-left: 20px;">5</td> <td style="padding-left: 20px;">20</td> <td></td> </tr> <tr> <td style="padding-left: 20px;">C9080</td> <td style="padding-left: 20px;">2</td> <td style="padding-left: 20px;">1</td> <td></td> </tr> </table> </div> <p style="text-align: center;">Figure 1-3-38</p> <table border="1" style="width: 100%; border-collapse: collapse; margin: 10px 0;"> <thead> <tr> <th data-bbox="336 1149 413 1193">No</th> <th data-bbox="413 1149 1398 1193">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1193 413 1238">a</td> <td data-bbox="413 1193 1398 1238">Service call numbers</td> </tr> <tr> <td data-bbox="336 1238 413 1283">b</td> <td data-bbox="413 1238 1398 1283">Date of clearing counter records</td> </tr> <tr> <td data-bbox="336 1283 413 1328">c</td> <td data-bbox="413 1283 1398 1328">Occurrences of service calls after clearing the service call counts</td> </tr> <tr> <td data-bbox="336 1328 413 1373">d</td> <td data-bbox="413 1328 1398 1373">Total number of service calls</td> </tr> </tbody> </table> <p>Method: [Total Cnt]</p> <ol style="list-style-type: none"> 1. Select [Total Cnt]. The total number of service call counts by type is displayed. 2. Change the screen using the cursor up/down keys. The total number of service call count cannot be cleared. <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Paper Jam Log	2011.12.12			JAM0000	10	1		(a) Service Call Log	(b) 2011.12.12			C0630	1	1		C1000	0	50		C1950	0	1		C2840	3	17		C4300	1	2		C9000	0	1		C9060	5	20		C9080	2	1		No	Description	a	Service call numbers	b	Date of clearing counter records	c	Occurrences of service calls after clearing the service call counts	d	Total number of service calls
Paper Jam Log	2011.12.12																																																						
JAM0000	10	1																																																					
(a) Service Call Log	(b) 2011.12.12																																																						
C0630	1	1																																																					
C1000	0	50																																																					
C1950	0	1																																																					
C2840	3	17																																																					
C4300	1	2																																																					
C9000	0	1																																																					
C9060	5	20																																																					
C9080	2	1																																																					
No	Description																																																						
a	Service call numbers																																																						
b	Date of clearing counter records																																																						
c	Occurrences of service calls after clearing the service call counts																																																						
d	Total number of service calls																																																						

Item No.	Description																														
U905	<p data-bbox="288 241 762 275">Checking counts by optional devices</p> <p data-bbox="288 309 440 342">Description</p> <p data-bbox="288 344 1015 378">Displays the counts of DP, 1000-sheet or 4000-sheet finisher.</p> <p data-bbox="288 380 400 414">Purpose</p> <p data-bbox="288 416 983 450">To check the use of DP, 1000-sheet or 4000-sheet finisher.</p> <p data-bbox="288 483 387 517">Method</p> <ol data-bbox="304 519 979 622" style="list-style-type: none"> 1. Press the start key. 2. Select the device, the count of which is to be checked. The count of the selected device is displayed. <table border="1" data-bbox="336 633 1401 779"> <thead> <tr> <th data-bbox="336 633 639 678">Display</th> <th data-bbox="639 633 1401 678">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 678 639 723">DP</td> <td data-bbox="639 678 1401 723">Counts of DP</td> </tr> <tr> <td data-bbox="336 723 639 779">DF</td> <td data-bbox="639 723 1401 779">Counts of 1000-sheet or 4000-sheet finisher</td> </tr> </tbody> </table> <p data-bbox="288 824 459 857">Method: [DP]</p> <table border="1" data-bbox="336 869 1401 1059"> <thead> <tr> <th data-bbox="336 869 639 913">Display</th> <th data-bbox="639 869 1401 913">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 913 639 958">ADP</td> <td data-bbox="639 913 1401 958">No. of single-sided originals that has passed through the DP</td> </tr> <tr> <td data-bbox="336 958 639 1003">RADP</td> <td data-bbox="639 958 1401 1003">No. of double-sided originals that has passed through the DP</td> </tr> <tr> <td data-bbox="336 1003 639 1059">CIS</td> <td data-bbox="639 1003 1401 1059">No. of dual scan originals that has passed through the DP</td> </tr> </tbody> </table> <p data-bbox="288 1104 459 1137">Method: [DF]</p> <table border="1" data-bbox="336 1149 1401 1529"> <thead> <tr> <th data-bbox="336 1149 639 1193">Display</th> <th data-bbox="639 1149 1401 1193">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1193 639 1238">Sorter</td> <td data-bbox="639 1193 1401 1238">No. of copies that has passed</td> </tr> <tr> <td data-bbox="336 1238 639 1283">Staple</td> <td data-bbox="639 1238 1401 1283">Frequency the stapler has been activated</td> </tr> <tr> <td data-bbox="336 1283 639 1328">Punch</td> <td data-bbox="639 1283 1401 1328">Frequency the punch has been activated</td> </tr> <tr> <td data-bbox="336 1328 639 1373">Stack*</td> <td data-bbox="639 1328 1401 1373">Frequency the main tray eject has been activated</td> </tr> <tr> <td data-bbox="336 1373 639 1417">Saddle*</td> <td data-bbox="639 1373 1401 1417">Frequency the saddle eject has been activated</td> </tr> <tr> <td data-bbox="336 1417 639 1462">Fold*</td> <td data-bbox="639 1417 1401 1462">Frequency the center folding has been activated</td> </tr> <tr> <td data-bbox="336 1462 639 1529">Three Fold*</td> <td data-bbox="639 1462 1401 1529">Frequency the tri-folding has been activated</td> </tr> </tbody> </table> <p data-bbox="336 1541 660 1574">* : 4000-sheet finisher only</p> <p data-bbox="288 1608 440 1641">Completion</p> <p data-bbox="288 1644 1254 1677">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	DP	Counts of DP	DF	Counts of 1000-sheet or 4000-sheet finisher	Display	Description	ADP	No. of single-sided originals that has passed through the DP	RADP	No. of double-sided originals that has passed through the DP	CIS	No. of dual scan originals that has passed through the DP	Display	Description	Sorter	No. of copies that has passed	Staple	Frequency the stapler has been activated	Punch	Frequency the punch has been activated	Stack*	Frequency the main tray eject has been activated	Saddle*	Frequency the saddle eject has been activated	Fold*	Frequency the center folding has been activated	Three Fold*	Frequency the tri-folding has been activated
Display	Description																														
DP	Counts of DP																														
DF	Counts of 1000-sheet or 4000-sheet finisher																														
Display	Description																														
ADP	No. of single-sided originals that has passed through the DP																														
RADP	No. of double-sided originals that has passed through the DP																														
CIS	No. of dual scan originals that has passed through the DP																														
Display	Description																														
Sorter	No. of copies that has passed																														
Staple	Frequency the stapler has been activated																														
Punch	Frequency the punch has been activated																														
Stack*	Frequency the main tray eject has been activated																														
Saddle*	Frequency the saddle eject has been activated																														
Fold*	Frequency the center folding has been activated																														
Three Fold*	Frequency the tri-folding has been activated																														

Item No.	Description
U906	<p>Resetting partial operation control</p> <p>Description Resets the service call code for partial operation control.</p> <p>Purpose To be reset after partial operation is performed due to problems in the cassettes or other sections, and the related parts are serviced.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press [Execute]. 3. Press the start key to reset partial operation control. 4. Turn the main power switch off and on. Allow more than 5 seconds between Off and On.
U908	<p>Checking the total counter value</p> <p>Description Displays the total counter value.</p> <p>Purpose To check the total counter value.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The total count value is displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>
U910	<p>Clearing the print coverage data</p> <p>Description Clears the accumulated data for the print coverage per A4 size paper and its period of time (as shown on the service status report).</p> <p>Purpose To clear data as required at times such as during maintenance service.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Execute]. 3. Press the start key. The print coverage data is cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Item No.	Description																																
U911	<p data-bbox="288 241 767 275">Checking copy counts by paper sizes</p> <p data-bbox="288 309 440 342">Description</p> <p data-bbox="288 344 844 378">Displays the paper feed counts by paper sizes.</p> <p data-bbox="288 380 400 414">Purpose</p> <p data-bbox="288 416 927 450">To check the counts after replacing consumable parts.</p> <p data-bbox="288 483 387 517">Method</p> <p data-bbox="308 519 1331 553">1. Press the start key. The screen for the paper feed counts by paper size is displayed.</p> <table border="1" data-bbox="336 562 1401 1016"> <thead> <tr> <th data-bbox="336 562 491 645">Display (metric)</th> <th data-bbox="491 562 868 645">Description</th> <th data-bbox="868 562 1019 645">Display (inch)</th> <th data-bbox="1019 562 1401 645">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 645 491 689">A3</td> <td data-bbox="491 645 868 689">Paper feed counts for A3</td> <td data-bbox="868 645 1019 689">Ledger</td> <td data-bbox="1019 645 1401 689">Paper feed counts for Ledger</td> </tr> <tr> <td data-bbox="336 689 491 734">B4</td> <td data-bbox="491 689 868 734">Paper feed counts for B4</td> <td data-bbox="868 689 1019 734">Legal</td> <td data-bbox="1019 689 1401 734">Paper feed counts for Legal</td> </tr> <tr> <td data-bbox="336 734 491 779">A4</td> <td data-bbox="491 734 868 779">Paper feed counts for A4</td> <td data-bbox="868 734 1019 779">Letter</td> <td data-bbox="1019 734 1401 779">Paper feed counts for Letter</td> </tr> <tr> <td data-bbox="336 779 491 824">B5</td> <td data-bbox="491 779 868 824">Paper feed counts for B5</td> <td data-bbox="868 779 1019 824">Statement</td> <td data-bbox="1019 779 1401 824">Paper feed counts for State-</td> </tr> <tr> <td data-bbox="336 824 491 869">A5</td> <td data-bbox="491 824 868 869">Paper feed counts for A5</td> <td data-bbox="868 824 1019 869"></td> <td data-bbox="1019 824 1401 869">ment</td> </tr> <tr> <td data-bbox="336 869 491 913">Folio</td> <td data-bbox="491 869 868 913">Paper feed counts for Folio</td> <td data-bbox="868 869 1019 913">ETC</td> <td data-bbox="1019 869 1401 913">Paper feed counts for other</td> </tr> <tr> <td data-bbox="336 913 491 1016">ETC</td> <td data-bbox="491 913 868 1016">Paper feed counts for other size</td> <td data-bbox="868 913 1019 1016"></td> <td data-bbox="1019 913 1401 1016">size</td> </tr> </tbody> </table> <p data-bbox="288 1061 400 1095">Clearing</p> <p data-bbox="308 1097 871 1131">1. Select the paper size of counts to be cleared.</p> <p data-bbox="308 1133 831 1167">2. Press the start key. The counts is cleared.</p> <p data-bbox="288 1200 440 1234">Completion</p> <p data-bbox="288 1236 1254 1270">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display (metric)	Description	Display (inch)	Description	A3	Paper feed counts for A3	Ledger	Paper feed counts for Ledger	B4	Paper feed counts for B4	Legal	Paper feed counts for Legal	A4	Paper feed counts for A4	Letter	Paper feed counts for Letter	B5	Paper feed counts for B5	Statement	Paper feed counts for State-	A5	Paper feed counts for A5		ment	Folio	Paper feed counts for Folio	ETC	Paper feed counts for other	ETC	Paper feed counts for other size		size
Display (metric)	Description	Display (inch)	Description																														
A3	Paper feed counts for A3	Ledger	Paper feed counts for Ledger																														
B4	Paper feed counts for B4	Legal	Paper feed counts for Legal																														
A4	Paper feed counts for A4	Letter	Paper feed counts for Letter																														
B5	Paper feed counts for B5	Statement	Paper feed counts for State-																														
A5	Paper feed counts for A5		ment																														
Folio	Paper feed counts for Folio	ETC	Paper feed counts for other																														
ETC	Paper feed counts for other size		size																														

Item No.	Description																																				
U917	<p data-bbox="288 241 746 275">Setting backup data reading/writing</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1425 409">Retrieves the backup data to a USB memory from the machine; or writes the data from the USB memory to the machine.</p> <p data-bbox="288 414 400 443">Purpose</p> <p data-bbox="288 448 866 477">To store and write data when replacing the HDD.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 553 1425 790" style="list-style-type: none"> 1. Press the power key on the operation panel, and after verifying the power indicator has gone off, switch off the main power switch. 2. Insert USB memory in USB memory slot. 3. Turn the main power switch on. Wait for 10 seconds to allow the machine to recognize the USB memory. 4. Enter maintenance item U917. 5. Select [Import] or [Export]. <table border="1" data-bbox="336 801 1401 949"> <thead> <tr> <th data-bbox="336 801 639 853">Display</th> <th data-bbox="639 801 1401 853">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 853 639 898">Import</td> <td data-bbox="639 853 1401 898">Writing data from the USB memory to the machine</td> </tr> <tr> <td data-bbox="336 898 639 949">Export</td> <td data-bbox="639 898 1401 949">Retrieving from the machine to a USB memory</td> </tr> </tbody> </table> <ol data-bbox="304 958 520 987" style="list-style-type: none"> 6. Select the item. <table border="1" data-bbox="336 999 1401 1621"> <thead> <tr> <th data-bbox="336 999 549 1050">Display</th> <th data-bbox="549 999 927 1050">Description</th> <th data-bbox="927 999 1401 1050">Depending data</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1050 549 1095">Address Book</td> <td data-bbox="549 1050 927 1095">Address book</td> <td data-bbox="927 1050 1401 1095">-</td> </tr> <tr> <td data-bbox="336 1095 549 1140">Job Account</td> <td data-bbox="549 1095 927 1140">Job accounting</td> <td data-bbox="927 1095 1401 1140">-</td> </tr> <tr> <td data-bbox="336 1140 549 1184">One Touch</td> <td data-bbox="549 1140 927 1184">Information on one-touch key</td> <td data-bbox="927 1140 1401 1184">Address book</td> </tr> <tr> <td data-bbox="336 1184 549 1229">User</td> <td data-bbox="549 1184 927 1229">User managements</td> <td data-bbox="927 1184 1401 1229">Job accounting</td> </tr> <tr> <td data-bbox="336 1229 549 1319">Program</td> <td data-bbox="549 1229 927 1319">Program information</td> <td data-bbox="927 1229 1401 1319">Job accountings and user managements</td> </tr> <tr> <td data-bbox="336 1319 549 1408">Shortcut</td> <td data-bbox="549 1319 927 1408">Shortcut information</td> <td data-bbox="927 1319 1401 1408">Job accountings, user managements and document box information</td> </tr> <tr> <td data-bbox="336 1408 549 1498">Fax Forward</td> <td data-bbox="549 1408 927 1498">FAX transfer information</td> <td data-bbox="927 1408 1401 1498">Job accountings, user managements and document box information</td> </tr> <tr> <td data-bbox="336 1498 549 1588">Document Box</td> <td data-bbox="549 1498 927 1588">Document box information</td> <td data-bbox="927 1498 1401 1588">Job accountings and user managements</td> </tr> <tr> <td data-bbox="336 1588 549 1621">IC Card</td> <td data-bbox="549 1588 927 1621">IC card information</td> <td data-bbox="927 1588 1401 1621">-</td> </tr> </tbody> </table> <p data-bbox="336 1630 1353 1695">* : Since data are dependent with each other, data other than those assigned are also retrieved or written in.</p> <ol data-bbox="304 1704 1361 1868" style="list-style-type: none"> 7. Press the start key. Starts reading or writing. The progress of selected item is displayed in %. When an error occurs, the operation is canceled and an error code is displayed. 8. When normally completed, [Finish] is displayed. 9. Turn the main power switch off and on after completing writing when selecting [Import]. 	Display	Description	Import	Writing data from the USB memory to the machine	Export	Retrieving from the machine to a USB memory	Display	Description	Depending data	Address Book	Address book	-	Job Account	Job accounting	-	One Touch	Information on one-touch key	Address book	User	User managements	Job accounting	Program	Program information	Job accountings and user managements	Shortcut	Shortcut information	Job accountings, user managements and document box information	Fax Forward	FAX transfer information	Job accountings, user managements and document box information	Document Box	Document box information	Job accountings and user managements	IC Card	IC card information	-
Display	Description																																				
Import	Writing data from the USB memory to the machine																																				
Export	Retrieving from the machine to a USB memory																																				
Display	Description	Depending data																																			
Address Book	Address book	-																																			
Job Account	Job accounting	-																																			
One Touch	Information on one-touch key	Address book																																			
User	User managements	Job accounting																																			
Program	Program information	Job accountings and user managements																																			
Shortcut	Shortcut information	Job accountings, user managements and document box information																																			
Fax Forward	FAX transfer information	Job accountings, user managements and document box information																																			
Document Box	Document box information	Job accountings and user managements																																			
IC Card	IC card information	-																																			

Item No.	Description			
U917	Error Codes			
	Codes	Description	Codes	Description
	e002	Parameter error	e31e	User managements error
	e003	File write error	e31f	User managements open error
	e004	File initialization error	e320	User managements error
	e005	File error	e321	User managements open error
	e006	Processing error	e322	User managements list error
	e010	Address book clear error (contact)	e324	Shortcut open error
	e011	Address book open error (contact)	e325	Shortcut list error
	e012	Address book list error (contact)	e410	Box file open error
	e013	Address book list error (contact)	e411	Box error in writing
	e014	Address book clear error (group)	e412	Box error in reading
	e015	Address book open error (group)	e413	Box list error
	e016	Address book list error (group)	e414	Box list error
	e017	Address book list error (group)	e415	Box error
	e110	Job accounting clear error	e416	Box error
	e111	Job accounting open error	e417	Box open error
	e112	Job accounting open error	e418	Box close error
	e113	Job accounting error in writing	e419	Box creation error
	e114	Job accounting list error	e41a	Box creation error
	e115	Job accounting list error	e41b	Box deletion error
	e210	One-touch open error	e41c	Box movement error
	e211	One-touch list error	e510	Program error in writing
	e212	One-touch list error	e511	Program error in reading
	e310	User managements backup error	e610	Shortcut error in writing
	e311	User managements clear error	e611	Shortcut error in reading
	e312	User managements open error	e710	Fax memory open error
	e313	User managements open error	e711	Fax memory initialization error
	e314	User managements open error	e712	Fax memory list error
	e315	User managements error in writing	e713	Fax memory error
	e316	User managements list error	e714	Fax memory error
	e317	User managements list error	e715	Fax memory mode error
	e318	User managements list error	e716	Fax memory error
	e319	User managements list error	e717	Fax memory error
	e31a	User managements open error	e718	Fax memory mode error
	e31b	User managements error	e910	File reading error
	e31c	User managements error	e911	File writing error
	e31d	User managements open error	e912	Data mismatch

Item No.	Description			
U917	Error Codes			
	Codes	Description	Codes	Description
	e913	Log file open error	d008	File rename error
	e914	Log file error in writing	d009	File open error
	e915	Directory open error	d00a	File close error
	e916	Directory error in reading	d00b	File reading error
	e917	Synchronization error	d00c	File writing error
	e918	Synchronization error	d00d	File copy error
	d000	Unspecified error	d00e	File compressed error
	d001	HDD unavailable	d00f	File decompressed error
	d002	USB memory is not inserted	d010	Directory open error
	d003	File for writing is not found in the USB	d011	Directory creation error
	d004	File for reading is not found in the HDD	d012	File writing error
	d005	USB error in writing	d013	File reading error
	d006	USB error in reading	d014	File deletion error
	d007	USB unmount error	d015	File copy error to the USB
	Completion			
	Press the stop key. The screen for selecting a maintenance item No. is displayed.			

Item No.	Description																						
U920	<p>Checking the copy counts</p> <p>Description Checks the copy counts.</p> <p>Purpose To check the copy counts.</p> <p>Method 1. Press the start key. The current counts are displayed.</p> <table border="1" data-bbox="336 562 1401 1088"> <thead> <tr> <th data-bbox="336 562 641 607">Display</th> <th data-bbox="641 562 1401 607">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 607 641 651">Color Copy(H)</td> <td data-bbox="641 607 1401 651">Count value of full color copy (coverage: high)</td> </tr> <tr> <td data-bbox="336 651 641 696">Color Copy(M)</td> <td data-bbox="641 651 1401 696">Count value of full color copy (coverage: middle)</td> </tr> <tr> <td data-bbox="336 696 641 741">Color Copy(L)</td> <td data-bbox="641 696 1401 741">Count value of full color copy (coverage: low)</td> </tr> <tr> <td data-bbox="336 741 641 786">Mono Color Copy</td> <td data-bbox="641 741 1401 786">Count value of single color copy</td> </tr> <tr> <td data-bbox="336 786 641 831">B/W Copy</td> <td data-bbox="641 786 1401 831">Count value of black/white copy</td> </tr> <tr> <td data-bbox="336 831 641 875">Color Prn(H)</td> <td data-bbox="641 831 1401 875">Count value of full color print (coverage: high)</td> </tr> <tr> <td data-bbox="336 875 641 920">Color Prn(M)</td> <td data-bbox="641 875 1401 920">Count value of full color print (coverage: middle)</td> </tr> <tr> <td data-bbox="336 920 641 965">Color Prn(L)</td> <td data-bbox="641 920 1401 965">Count value of full color print (coverage: low)</td> </tr> <tr> <td data-bbox="336 965 641 1010">B/W Prn</td> <td data-bbox="641 965 1401 1010">Count value of black/white print</td> </tr> <tr> <td data-bbox="336 1010 641 1088">B/W Fax</td> <td data-bbox="641 1010 1401 1088">Count value of black/white FAX</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Color Copy(H)	Count value of full color copy (coverage: high)	Color Copy(M)	Count value of full color copy (coverage: middle)	Color Copy(L)	Count value of full color copy (coverage: low)	Mono Color Copy	Count value of single color copy	B/W Copy	Count value of black/white copy	Color Prn(H)	Count value of full color print (coverage: high)	Color Prn(M)	Count value of full color print (coverage: middle)	Color Prn(L)	Count value of full color print (coverage: low)	B/W Prn	Count value of black/white print	B/W Fax	Count value of black/white FAX
Display	Description																						
Color Copy(H)	Count value of full color copy (coverage: high)																						
Color Copy(M)	Count value of full color copy (coverage: middle)																						
Color Copy(L)	Count value of full color copy (coverage: low)																						
Mono Color Copy	Count value of single color copy																						
B/W Copy	Count value of black/white copy																						
Color Prn(H)	Count value of full color print (coverage: high)																						
Color Prn(M)	Count value of full color print (coverage: middle)																						
Color Prn(L)	Count value of full color print (coverage: low)																						
B/W Prn	Count value of black/white print																						
B/W Fax	Count value of black/white FAX																						
U927	<p>Clearing the all copy counts and machine life counts (one time only)</p> <p>Description Resets all of the counts back to zero.</p> <p>Supplement The total account counter and the machine life counter can be cleared only once if all count values are 1000 or less.</p> <p>Method 1. Press the start key. 2. Select [Execute]. 3. Press the start key. All copy counts and machine life counts are cleared.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>																						

Item No.	Description										
U928	<p>Checking machine life counts</p> <p>Description Displays the machine life counts.</p> <p>Purpose To check the machine life counts.</p> <p>Method 1. Press the start key. The current machine life counts is displayed.</p> <table border="1" data-bbox="336 562 1401 658"> <thead> <tr> <th data-bbox="336 562 639 607">Display</th> <th data-bbox="639 562 1401 607">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 607 639 658">Cnt</td> <td data-bbox="639 607 1401 658">Machine life counts</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Cnt	Machine life counts						
Display	Description										
Cnt	Machine life counts										
U930	<p>Checking/clearing the charger roller count</p> <p>Description Displays the counts of the charger roller counter for checking or clearing.</p> <p>Purpose To check the count after replacement of the charger roller unit. To clear the counter value when replacing the charger roller unit.</p> <p>Method 1. Press the start key. The current counts of the charger roller count for each color is displayed.</p> <table border="1" data-bbox="336 1140 1401 1379"> <thead> <tr> <th data-bbox="336 1140 639 1184">Display</th> <th data-bbox="639 1140 1401 1184">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1184 639 1232">C</td> <td data-bbox="639 1184 1401 1232">Count value of cyan charger roller</td> </tr> <tr> <td data-bbox="336 1232 639 1279">M</td> <td data-bbox="639 1232 1401 1279">Count value of magenta charger roller</td> </tr> <tr> <td data-bbox="336 1279 639 1326">Y</td> <td data-bbox="639 1279 1401 1326">Count value of yellow charger roller</td> </tr> <tr> <td data-bbox="336 1326 639 1379">K</td> <td data-bbox="639 1326 1401 1379">Count value of black charger roller</td> </tr> </tbody> </table> <p>Clearing 1. Select the counts to be cleared. 2. Select the counts for all and press [Clear]. 3. Press the start key. The counts is cleared.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	C	Count value of cyan charger roller	M	Count value of magenta charger roller	Y	Count value of yellow charger roller	K	Count value of black charger roller
Display	Description										
C	Count value of cyan charger roller										
M	Count value of magenta charger roller										
Y	Count value of yellow charger roller										
K	Count value of black charger roller										

Item No.	Description																				
U942	<p data-bbox="288 241 807 275">Setting of deflection for feeding from DP</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1139 374">Adjusts the deflection generated when the document processor is used.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1409 479">Use this mode if an original non-feed jam, oblique feed or wrinkling of original occurs when the document processor is used.</p> <p data-bbox="288 517 384 546">Setting</p> <ol data-bbox="304 553 1182 757" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original on the DP and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. 6. Change the setting value using the +/- keys or numeric keys. <table border="1" data-bbox="336 768 1401 994"> <thead> <tr> <th data-bbox="344 779 504 846">Display</th> <th data-bbox="504 779 943 846">Description</th> <th data-bbox="943 779 1078 846">Setting range</th> <th data-bbox="1078 779 1193 846">Initial setting</th> <th data-bbox="1193 779 1393 846">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="344 853 504 882">Front</td> <td data-bbox="504 853 943 882">Deflection of single-sided original</td> <td data-bbox="943 853 1078 882">-31 to 31</td> <td data-bbox="1078 853 1193 882">0</td> <td data-bbox="1193 853 1393 882">0.17 mm</td> </tr> <tr> <td data-bbox="344 904 504 934">Back*</td> <td data-bbox="504 904 943 934">Deflection of double-sided original</td> <td data-bbox="943 904 1078 934">-31 to 31</td> <td data-bbox="1078 904 1193 934">0</td> <td data-bbox="1193 904 1393 934">0.17 mm</td> </tr> <tr> <td data-bbox="344 956 504 985">Mix</td> <td data-bbox="504 956 943 985">Deflection of mixed original</td> <td data-bbox="943 956 1078 985">-31 to 31</td> <td data-bbox="1078 956 1193 985">0</td> <td data-bbox="1193 956 1393 985">0.17 mm</td> </tr> </tbody> </table> <p data-bbox="336 1010 600 1039">*1: Reversed DP only.</p> <p data-bbox="336 1043 1377 1108">* : The greater the value, the larger the deflection; the smaller the value, the smaller the deflection.</p> <p data-bbox="373 1113 1417 1178">If an original non-feed jam or oblique feed occurs, increase the setting value. If wrinkling of original occurs, decrease the value.</p> <ol data-bbox="304 1182 767 1211" style="list-style-type: none"> 7. Press the start key. The value is set. <p data-bbox="288 1249 440 1279">Completion</p> <p data-bbox="288 1283 1254 1312">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	Front	Deflection of single-sided original	-31 to 31	0	0.17 mm	Back*	Deflection of double-sided original	-31 to 31	0	0.17 mm	Mix	Deflection of mixed original	-31 to 31	0	0.17 mm
Display	Description	Setting range	Initial setting	Change in value per step																	
Front	Deflection of single-sided original	-31 to 31	0	0.17 mm																	
Back*	Deflection of double-sided original	-31 to 31	0	0.17 mm																	
Mix	Deflection of mixed original	-31 to 31	0	0.17 mm																	

Item No.	Description																										
U952	<p data-bbox="288 241 657 271">Maintenance mode workflow</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1426 409">The maintenance modes configured in the machine or a USB flash device as a workflow must be executed in succession.</p> <p data-bbox="288 414 400 443">Purpose</p> <p data-bbox="288 448 983 477">This allows maintenance mode to be preset as a template.</p> <p data-bbox="288 517 384 546">Setting</p> <ol data-bbox="304 551 564 616" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 629 1399 967"> <thead> <tr> <th data-bbox="336 629 603 680">Display</th> <th data-bbox="603 629 1399 680">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 680 603 725">Continue</td> <td data-bbox="603 680 1399 725">Restarting an abandoned workflow</td> </tr> <tr> <td data-bbox="336 725 603 770">Execute(USB)</td> <td data-bbox="603 725 1399 770">Executes a workflow housed in a USB flash device</td> </tr> <tr> <td data-bbox="336 770 603 815">Execute</td> <td data-bbox="603 770 1399 815">Executes a workflow stored in the machine</td> </tr> <tr> <td data-bbox="336 815 603 860">Entry(USB)</td> <td data-bbox="603 815 1399 860">Exports a workflow housed in a USB flash device to the machine</td> </tr> <tr> <td data-bbox="336 860 603 904">Entry</td> <td data-bbox="603 860 1399 904">Assigns a workflow in the machine manually</td> </tr> <tr> <td data-bbox="336 904 603 967">Log</td> <td data-bbox="603 904 1399 967">Displays a list of workflows recently executed</td> </tr> </tbody> </table> <p data-bbox="288 1010 523 1039">Method: [Execute]</p> <ol data-bbox="304 1043 572 1108" style="list-style-type: none"> 1. Select [Execute]. 2. Select the workflow. <table border="1" data-bbox="336 1122 1399 1218"> <thead> <tr> <th data-bbox="336 1122 641 1173">Display</th> <th data-bbox="641 1122 1399 1173">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1173 641 1218">Data1 - 6</td> <td data-bbox="641 1173 1399 1218">The area to store workflows in the machine</td> </tr> </tbody> </table> <ol data-bbox="304 1229 1126 1294" style="list-style-type: none"> 3. Press the start key. Executes maintenance modes defined in a workflow in succession. <p data-bbox="288 1332 489 1361">Method: [Entry]</p> <ol data-bbox="304 1366 730 1431" style="list-style-type: none"> 1. Select [Entry]. 2. Select the area to store workflow. <table border="1" data-bbox="336 1444 1399 1541"> <thead> <tr> <th data-bbox="336 1444 641 1496">Display</th> <th data-bbox="641 1444 1399 1496">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1496 641 1541">Data1 - 6</td> <td data-bbox="641 1496 1399 1541">The area to store workflows in the machine</td> </tr> </tbody> </table> <ol data-bbox="304 1552 1292 1581" style="list-style-type: none"> 3. Press the +/- keys or numeric keys to assign a maintenance Nbr. into a workflow. <table border="1" data-bbox="336 1594 1399 1691"> <thead> <tr> <th data-bbox="336 1594 641 1646">Display</th> <th data-bbox="641 1594 1399 1646">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1646 641 1691">Flow1 - 14</td> <td data-bbox="641 1646 1399 1691">Assign a maintenance Nbr.</td> </tr> </tbody> </table> <ol data-bbox="304 1702 1126 1798" style="list-style-type: none"> 4. Press the start key. The setting is set. 5. Press the start key. Executes maintenance modes defined in a workflow in succession. 	Display	Description	Continue	Restarting an abandoned workflow	Execute(USB)	Executes a workflow housed in a USB flash device	Execute	Executes a workflow stored in the machine	Entry(USB)	Exports a workflow housed in a USB flash device to the machine	Entry	Assigns a workflow in the machine manually	Log	Displays a list of workflows recently executed	Display	Description	Data1 - 6	The area to store workflows in the machine	Display	Description	Data1 - 6	The area to store workflows in the machine	Display	Description	Flow1 - 14	Assign a maintenance Nbr.
Display	Description																										
Continue	Restarting an abandoned workflow																										
Execute(USB)	Executes a workflow housed in a USB flash device																										
Execute	Executes a workflow stored in the machine																										
Entry(USB)	Exports a workflow housed in a USB flash device to the machine																										
Entry	Assigns a workflow in the machine manually																										
Log	Displays a list of workflows recently executed																										
Display	Description																										
Data1 - 6	The area to store workflows in the machine																										
Display	Description																										
Data1 - 6	The area to store workflows in the machine																										
Display	Description																										
Flow1 - 14	Assign a maintenance Nbr.																										

Item No.	Description												
U952	<p>Method: [Execute(USB)]</p> <ol style="list-style-type: none"> 1. Press the power key on the operation panel, and after verifying the main power indicator has gone off, switch off the main power switch. 2. Insert USB memory in USB memory slot. 3. Turn the main power switch on. 4. Enter maintenance item U952. 5. Select [Execute(USB)]. 6. Select the workflow. <table border="1" data-bbox="336 526 1401 622"> <thead> <tr> <th data-bbox="336 526 641 571">Display</th> <th data-bbox="641 526 1401 571">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 571 641 622">WorkFlowData01 - 07</td> <td data-bbox="641 571 1401 622">Workflow data in the USB flash device</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 7. Press the start key. Executes maintenance modes defined in a workflow in succession. <p>Method: [Entry(USB)]</p> <ol style="list-style-type: none"> 1. Press the power key on the operation panel, and after verifying the main power indicator has gone off, switch off the main power switch. 2. Insert USB memory in USB memory slot. 3. Turn the main power switch on. 4. Enter maintenance item U952. 5. Select [Entry(USB)]. 6. Select the workflow. <table border="1" data-bbox="336 1023 1401 1120"> <thead> <tr> <th data-bbox="336 1023 641 1068">Display</th> <th data-bbox="641 1023 1401 1068">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1068 641 1120">WorkFlowData01 - 07</td> <td data-bbox="641 1068 1401 1120">Workflow data in the USB flash device</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 7. Select the work flow save area. <table border="1" data-bbox="336 1171 1401 1267"> <thead> <tr> <th data-bbox="336 1171 641 1216">Display</th> <th data-bbox="641 1171 1401 1216">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1216 641 1267">Data1 - 6</td> <td data-bbox="641 1216 1401 1267">The area to store workflows in the machine</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 8. Select [Execute]. Exports a workflow housed in a USB flash device to the machine. <p>Example</p> <p>Registration is feasible when a USB flash device that stores the commands and text/maintenance ID (editable) is inserted. File Format: xxx.mwf</p> <pre>!R! MNFC "WFPS"; 1, SET UP, 464, 469, 410, 000, 927, 278 2, WARRANTY, 089, 000 3, MK-A, 119, 930, 140, 469, 127, 464, 469, 412, 464, 410, 251 4, MK-B, 119, 930, 140, 464, 469, 412, 464, 410, 251 5, MK-C, 167, 464, 469, 410, 251 WRED;EXIT;</pre> <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	WorkFlowData01 - 07	Workflow data in the USB flash device	Display	Description	WorkFlowData01 - 07	Workflow data in the USB flash device	Display	Description	Data1 - 6	The area to store workflows in the machine
Display	Description												
WorkFlowData01 - 07	Workflow data in the USB flash device												
Display	Description												
WorkFlowData01 - 07	Workflow data in the USB flash device												
Display	Description												
Data1 - 6	The area to store workflows in the machine												

Item No.	Description																								
U964	<p>Checking of log</p> <p>Description Sends a log file saved on the HDD to a USB memory.</p> <p>Purpose To transfer a log file saved on the HDD to a USB memory as a means of investigating malfunctions.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the power key on the operation panel, and after verifying the main power indicator has gone off, switch off the main power switch. 2. Insert USB memory in USB memory slot. 3. Turn the main power switch on. 4. Enter maintenance item U964. <table border="1" data-bbox="336 734 1401 907"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Execute</td> <td>Transfer the Log file which is stored into HDD into the USB memory</td> </tr> <tr> <td>Jam Log</td> <td>Exchange the Log acquisition function when JAM occurs</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 5. Select [Execute]. 6. Press the start key. Starts sending the log file saved on the HDD to the USB memory. Processing is displayed for approximately 3 to 5 minutes. 7. When normally completed, [Completed] is displayed. 8. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. If a problem occurs during auto correction, error code is displayed. <p>Setting: [Jam Log]</p> <ol style="list-style-type: none"> 1. Select Jam Log. 2. Select On or Off. <table border="1" data-bbox="336 1312 1401 1458"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>On</td> <td>Acquire the Log when JAM occurs</td> </tr> <tr> <td>Off</td> <td>Do not acquire the Log when JAM occurs</td> </tr> </tbody> </table> <p>Initial setting: Off</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>* : When U964 JAM setting turns ON, please explain the user make sure to turn OFF/ON the main power switch when the Log has been acquired completely after clearing jammed paper when JAM occurs.</p> <div data-bbox="300 1675 646 1832"> </div> <table border="1" data-bbox="671 1682 1431 1910"> <thead> <tr> <th>Display</th> <th>During Log Retrieval</th> <th>After Log Retrieval</th> </tr> </thead> <tbody> <tr> <td>Attention indicator</td> <td>Blinking</td> <td>Lighting</td> </tr> <tr> <td>Processing indicator</td> <td>Blinking</td> <td>Blinking</td> </tr> <tr> <td>Memory indicator</td> <td>Blinking</td> <td>Lighting</td> </tr> </tbody> </table> <p>* : When U964 JAM setting turns ON, the service call may appear wrongly due to malfunction if the main power switch is not turned OFF/ON after clearing jammed paper.</p>	Display	Description	Execute	Transfer the Log file which is stored into HDD into the USB memory	Jam Log	Exchange the Log acquisition function when JAM occurs	Display	Description	On	Acquire the Log when JAM occurs	Off	Do not acquire the Log when JAM occurs	Display	During Log Retrieval	After Log Retrieval	Attention indicator	Blinking	Lighting	Processing indicator	Blinking	Blinking	Memory indicator	Blinking	Lighting
Display	Description																								
Execute	Transfer the Log file which is stored into HDD into the USB memory																								
Jam Log	Exchange the Log acquisition function when JAM occurs																								
Display	Description																								
On	Acquire the Log when JAM occurs																								
Off	Do not acquire the Log when JAM occurs																								
Display	During Log Retrieval	After Log Retrieval																							
Attention indicator	Blinking	Lighting																							
Processing indicator	Blinking	Blinking																							
Memory indicator	Blinking	Lighting																							

Item No.	Description																
U964	<p>Supplement Instructions on how to obtain a log when the operation panel has frozen Simultaneously press and hold the *, 8, 6, and Clear keys for 3 to 6 seconds to start logging. The memory indicator keeps lighting during a log is generated and goes off when completed.</p> <p>Error codes</p> <table border="1" data-bbox="336 459 1401 842"> <thead> <tr> <th data-bbox="336 459 639 504">Display</th> <th data-bbox="639 459 1401 504">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 504 639 548">No Usb Storage</td> <td data-bbox="639 504 1401 548">USB memory is not inserted</td> </tr> <tr> <td data-bbox="336 548 639 593">No File</td> <td data-bbox="639 548 1401 593">File is not found</td> </tr> <tr> <td data-bbox="336 593 639 638">Mount Error</td> <td data-bbox="639 593 1401 638">USB memory mount error</td> </tr> <tr> <td data-bbox="336 638 639 683">File Delete Error</td> <td data-bbox="639 638 1401 683">File deletion error</td> </tr> <tr> <td data-bbox="336 683 639 728">Copy Error</td> <td data-bbox="639 683 1401 728">File copy error</td> </tr> <tr> <td data-bbox="336 728 639 772">Unmount Error</td> <td data-bbox="639 728 1401 772">USB memory unmount error</td> </tr> <tr> <td data-bbox="336 772 639 842">Other Error</td> <td data-bbox="639 772 1401 842">Other error</td> </tr> </tbody> </table>	Display	Description	No Usb Storage	USB memory is not inserted	No File	File is not found	Mount Error	USB memory mount error	File Delete Error	File deletion error	Copy Error	File copy error	Unmount Error	USB memory unmount error	Other Error	Other error
Display	Description																
No Usb Storage	USB memory is not inserted																
No File	File is not found																
Mount Error	USB memory mount error																
File Delete Error	File deletion error																
Copy Error	File copy error																
Unmount Error	USB memory unmount error																
Other Error	Other error																
U969	<p>Checking of toner area code</p> <p>Description Displays the toner area code.</p> <p>Purpose To check the toner area code.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The toner area code is displayed. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>																
U977	<p>Data capture mode</p> <p>Description Store the print data sent to the machine into USB memory.</p> <p>Purpose In case to occur the error at printing, check the print data sent to the machine.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the power key on the operation panel, and after verifying the main power indicator has gone off, switch off the main power switch. 2. Insert USB memory in USB memory slot. 3. Turn the main power switch on. 4. Enter maintenance item U977. 5. Select [Execute]. 6. Press the start key. 7. Send the print data to the machine. Once the print data is stored into USB memory, [Finish] will be displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>																

Item No.	Description										
U977	<p data-bbox="287 241 443 271">Error codes</p> <table border="1" data-bbox="336 286 1401 510"> <thead> <tr> <th data-bbox="336 286 639 331">Error codes</th> <th data-bbox="639 286 1401 331">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 331 639 421">1</td> <td data-bbox="639 331 1401 421">A removable memory has been crushed. A removable memory was removed during processing or is write-protected.</td> </tr> <tr> <td data-bbox="336 421 639 465">2</td> <td data-bbox="639 421 1401 465">The removable memory is full.</td> </tr> <tr> <td data-bbox="336 465 639 510">50</td> <td data-bbox="639 465 1401 510">Other error</td> </tr> </tbody> </table>	Error codes	Description	1	A removable memory has been crushed. A removable memory was removed during processing or is write-protected.	2	The removable memory is full.	50	Other error		
Error codes	Description										
1	A removable memory has been crushed. A removable memory was removed during processing or is write-protected.										
2	The removable memory is full.										
50	Other error										
U984	<p data-bbox="287 551 758 580">Checking the developer unit number</p> <p data-bbox="287 618 440 647">Description Displays the developer unit number.</p> <p data-bbox="287 685 400 714">Purpose To check the developer unit number.</p> <p data-bbox="287 790 387 819">Method</p> <ol data-bbox="308 826 1214 855" style="list-style-type: none"> 1. Press the start key. The developer unit number for each color is displayed. <table border="1" data-bbox="336 871 1401 1111"> <thead> <tr> <th data-bbox="336 871 639 916">Display</th> <th data-bbox="639 871 1401 916">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 916 639 960">C</td> <td data-bbox="639 916 1401 960">Cyan developer unit number</td> </tr> <tr> <td data-bbox="336 960 639 1005">M</td> <td data-bbox="639 960 1401 1005">Magenta developer unit number</td> </tr> <tr> <td data-bbox="336 1005 639 1050">Y</td> <td data-bbox="639 1005 1401 1050">Yellow developer unit number</td> </tr> <tr> <td data-bbox="336 1050 639 1111">K</td> <td data-bbox="639 1050 1401 1111">Black developer unit number</td> </tr> </tbody> </table> <p data-bbox="287 1151 440 1180">Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	C	Cyan developer unit number	M	Magenta developer unit number	Y	Yellow developer unit number	K	Black developer unit number
Display	Description										
C	Cyan developer unit number										
M	Magenta developer unit number										
Y	Yellow developer unit number										
K	Black developer unit number										

Item No.	Description																
U985	<p>Displaying the developer unit history</p> <p>Description Displays the past record of machine number and the developer counter.</p> <p>Purpose To check the count value of machine number and the developer counter.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the color to check. <table border="1" data-bbox="336 598 1401 837"> <thead> <tr> <th data-bbox="336 598 639 642">Display</th> <th data-bbox="639 598 1401 642">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 642 639 687">C</td> <td data-bbox="639 642 1401 687">Cyan developer unit past record</td> </tr> <tr> <td data-bbox="336 687 639 732">M</td> <td data-bbox="639 687 1401 732">Magenta developer unit past record</td> </tr> <tr> <td data-bbox="336 732 639 777">Y</td> <td data-bbox="639 732 1401 777">Yellow developer unit past record</td> </tr> <tr> <td data-bbox="336 777 639 837">K</td> <td data-bbox="639 777 1401 837">Black developer unit past record</td> </tr> </tbody> </table> <p>The history of a machine number and a developer counter for each color is displayed by three cases.</p> <table border="1" data-bbox="336 925 1401 1068"> <thead> <tr> <th data-bbox="336 925 639 969">Display</th> <th data-bbox="639 925 1401 969">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 969 639 1014">Machine History1 - 3</td> <td data-bbox="639 969 1401 1014">Historical records of the machine number</td> </tr> <tr> <td data-bbox="336 1014 639 1068">Cnt History1 - 3</td> <td data-bbox="639 1014 1401 1068">Historical records of developer counter</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	C	Cyan developer unit past record	M	Magenta developer unit past record	Y	Yellow developer unit past record	K	Black developer unit past record	Display	Description	Machine History1 - 3	Historical records of the machine number	Cnt History1 - 3	Historical records of developer counter
Display	Description																
C	Cyan developer unit past record																
M	Magenta developer unit past record																
Y	Yellow developer unit past record																
K	Black developer unit past record																
Display	Description																
Machine History1 - 3	Historical records of the machine number																
Cnt History1 - 3	Historical records of developer counter																
U989	<p>HDD Scan disk</p> <p>Description Restores data in the hard disk by scanning the disk.</p> <p>Purpose If power is turned off while accessing to the hard disk is performed, the control information in the hard disk drive may be damaged. Use this mode to restore the data.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Execute]. 3. Press the start key. When scanning of the disk is complete, the execution result is displayed. 4. Turn the main power switch off and on. Allow more than 5 seconds between Off and On. 																

Item No.	Description								
U990	<p>Checking the time for the exposure lamp to light</p> <p>Description Displays the accumulated time for the CIS to light.</p> <p>Purpose To check duration of use of the CIS.</p> <p>Method 1. Press the start key. The accumulated time for the CIS to light is displayed in minutes.</p> <table border="1" data-bbox="336 598 1401 694"> <thead> <tr> <th data-bbox="336 598 641 642">Display</th> <th data-bbox="641 598 1401 642">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 642 641 694">CIS</td> <td data-bbox="641 642 1401 694">The accumulated time for the CIS to light</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	CIS	The accumulated time for the CIS to light				
Display	Description								
CIS	The accumulated time for the CIS to light								
U991	<p>Checking the scanner operation count</p> <p>Description Displays the scanner operation count.</p> <p>Purpose To check the status of use of the scanner.</p> <p>Method 1. Press the start key. The current operation counts is displayed.</p> <table border="1" data-bbox="336 1140 1401 1332"> <thead> <tr> <th data-bbox="336 1140 641 1184">Display</th> <th data-bbox="641 1140 1401 1184">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1184 641 1232">Copy Scan</td> <td data-bbox="641 1184 1401 1232">Scanner operation counts for copying</td> </tr> <tr> <td data-bbox="336 1232 641 1279">Fax Scan</td> <td data-bbox="641 1232 1401 1279">Scanner operation counts for fax</td> </tr> <tr> <td data-bbox="336 1279 641 1332">Other Scan</td> <td data-bbox="641 1279 1401 1332">Scanner operation counts except for copying</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance No. item is displayed.</p>	Display	Description	Copy Scan	Scanner operation counts for copying	Fax Scan	Scanner operation counts for fax	Other Scan	Scanner operation counts except for copying
Display	Description								
Copy Scan	Scanner operation counts for copying								
Fax Scan	Scanner operation counts for fax								
Other Scan	Scanner operation counts except for copying								

This page is intentionally left blank.

1-4-1 Paper misfeed detection

(1) Paper misfeed indication

When a paper misfeed occurs, the machine immediately stops printing and displays the paper misfeed message on the operation panel. To remove paper misfed in the machine, pull out the cassette, open the paper conveying unit or paper conveying cover.




Figure 1-4-1 Paper misfeed indication

- A. Misfeed in cassette 1
- B. Misfeed in cassette 2
- C. Misfeed in cassette 3 or 4 (option)
- D. Misfeed in the MP tray
- E. Misfeed in paper conveying unit, paper conveying cover or PF paper conveying cover
- F. Misfeed in the duplex section
- G. Misfeed in the fuser section
- H. Misfeed in document processor (option)
- I. Misfeed in job separator (option)
- J. Misfeed in bridge unit (option)
- K. Misfeed in document finisher (option)
- L. Misfeed in cassette 5 (option)
- M. Misfeed in cassette 6 or 7 (option)

Machine + Option2




Figure 1-4-3 Paper jam location (Matchline + Option2)

* : This model does not support the following codes: 0132 /0505 /0515 /9030

Code	Contents	Conditions	Jam location*
0000	Initial jam	The power is turned on when a sensor in the conveying system is on.	-
0100	Secondary paper feed request time out	Secondary paper feed request given by the controller is unreachable.	-
0101	Waiting for toner package to become ready	Process package won't become ready.	-
0102	Waiting for toner package to become ready	Toner package won't become ready.	-
0103	Waiting for the image-sustaining package to become ready	The image-sustaining package won't become ready.	-
0104	Waiting for conveying package to become ready	Conveying package won't become ready.	-
0106	Paper feeding request for duplex printing time out	Paper feeding request for duplex printing given by the controller is unreachable.	-
0107	Waiting for fuser package to become ready	Fuser package won't become ready.	-
0108	Waiting for option package to become ready	Option package won't become ready.	-
0110	Paper conveying unit open	The paper conveying unit is opened during printing.	E
0111	Front cover open	The front cover is opened during printing.	-
0112	Duplex cover open	The duplex cover is opened during printing.	F
0113	Paper conveying cover open	The paper conveying cover is opened during printing.	E
0114	BR conveying unit open	The BR conveying unit is opened during printing.	J
0115	BR eject cover open	The BR eject cover is opened during printing.	J
0131	MP lift sensor upper limit detection	MP lift sensor 1 (MPLS1) does not turn on within specified time of the MP lift plate rising.	D
0200	Machine sequence error	A sequence error has caused.	-
0210	PF paper conveying cover open	The PF paper conveying cover is opened during printing.	E
0211	SM paper conveying cover open	The SM paper conveying cover is opened during printing.	L
0212	SM top cover open	The SM top cover is opened during printing.	L
0213	SD cover open	The SD cover is opened during printing.	L
0214	PF paper conveying cover (side) open	The PF paper conveying cover (side) is opened during printing.	M

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
0215	Side multi tray release	The side multi tray is released during printing.	L
0300	Ejection uncompleted	An ejection-completed error has occurred.	-
0501	No paper feed from cassette 1	Feed sensor 1 (FS1) does not turn on during paper feed from cassette 1.	A
0502	No paper feed from cassette 2	Feed sensor 2 (FS2) does not turn on during paper feed from cassette 2.	B
0503	No paper feed from cassette 3	PF feed sensor 1 (PFFS1) does not turn on during paper feed from cassette 3 (paper feeder).	C
0504	No paper feed from cassette 4	PF feed sensor 2 (PFFS2) does not turn on during paper feed from cassette 4 (paper feeder).	C
0506	No paper feed from cassette 6	PF feed sensor 1 (PFFS1) does not turn on during paper feed from cassette 6 (side paper feeder).	M
0507	No paper feed from cassette 7	PF feed sensor 2 (PFFS2) does not turn on during paper feed from cassette 7 (side paper feeder).	M
0508	No paper feed from duplex section	Registration sensor (RS) does not turn on during paper feed from duplex section.	F
0509	No paper feed from MP tray	MP feed sensor (MPFS) does not turn on during paper feed from MP tray.	D
0511	Multiple sheets in cassette 1	Feed sensor 1 (FS1) does not turn off during paper feed from cassette 1.	A
0512	Multiple sheets in cassette 2	Feed sensor 2 (FS2) does not turn off during paper feed from cassette 2.	B
0513	Multiple sheets in cassette 3	PF feed sensor 1 (PFFS1) does not turn off during paper feed from cassette 3 (paper feeder).	C
0514	Multiple sheets in cassette 4	PF feed sensor 2 (PFFS2) does not turn off during paper feed from cassette 4 (paper feeder).	C
0515	Multiple sheets in cassette 5	SM feed sensor (SMFS) does not turn off during paper feed from cassette 5 (side multi tray).	L
0516	Multiple sheets in cassette 6	PF feed sensor 1 (PFFS1) does not turn off during paper feed from cassette 6 (side paper feeder).	M
0517	Multiple sheets in cassette 7	PF feed sensor 2 (PFFS2) does not turn off during paper feed from cassette 7 (side paper feeder).	M
0518	Multiple sheets in duplex section	Registration sensor (RS) does not turn off during paper feed from duplex section.	F
0519	Multiple sheets in MP tray	MP feed sensor (MPFS) does not turn off during paper feed from MP tray.	D
0523	No paper feed from cassette 3	PF feed sensor 1 (PFFS1) does not turn on during paper feed from cassette 3 (large capacity feeder).	C
0524	No paper feed from cassette 4	PF feed sensor 2 (PFFS2) does not turn on during paper feed from cassette 4 (large capacity feeder).	C

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
0525	No paper feed from cassette 5	SM feed sensor (SMFS) does not turn on during paper feed from cassette 5 (side multi tray).	L
0526	No paper feed from cassette 6	PF feed sensor 1 (PFFS1) does not turn on during paper feed from cassette 6 (side large capacity feeder).	M
0527	No paper feed from cassette 7	PF feed sensor 2 (PFFS2) does not turn on during paper feed from cassette 7 (side large capacity feeder).	M
0533	Multiple sheets in cassette 3	PF feed sensor 1 (PFFS1) does not turn off during paper feed from cassette 3 (large capacity feeder).	C
0534	Multiple sheets in cassette 4	PF feed sensor 2 (PFFS2) does not turn off during paper feed from cassette 4 (large capacity feeder).	C
0535	Multiple sheets in cassette 5	SM feed sensor (SMFS) does not turn off during paper feed from cassette 5 (side multi tray).	L
0536	Multiple sheets in cassette 6	PF feed sensor 1 (PFFS1) does not turn off during paper feed from cassette 6 (side large capacity feeder).	M
0537	Multiple sheets in cassette 7	PF feed sensor 2 (PFFS2) does not turn off during paper feed from cassette 7 (side large capacity feeder).	M
0545	No paper feed from side deck	SD feed sensor (SDFS) does not turn on during paper feed from side deck.	L
0555	Multiple sheets in side deck	SD feed sensor (SDFS) does not turn off during paper feed from side deck.	L
1301	Middle sensor non arrival jam	Middle sensor (MS) does not turn on during paper feed from cassette 1.	A
1302		Middle sensor (MS) does not turn on during paper feed from cassette 2.	B
1303		Middle sensor (MS) does not turn on during paper feed from cassette 3 (paper feeder/large capacity feeder).	C
1304		Middle sensor (MS) does not turn on during paper feed from cassette 4 (paper feeder/large capacity feeder).	C
1305		Middle sensor (MS) does not turn on during paper feed from cassette 5 (side multi tray/side deck).	L
1306		Middle sensor (MS) does not turn on during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	M
1307		Middle sensor (MS) does not turn on during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	M

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
1311	Middle sensor stay jam	Middle sensor (MS) does not turn off during paper feed from cassette 1.	E
1312		Middle sensor (MS) does not turn off during paper feed from cassette 2.	E
1313		Middle sensor (MS) does not turn off during paper feed from cassette 3 (paper feeder/large capacity feeder).	E
1314		Middle sensor (MS) does not turn off during paper feed from cassette 4 (paper feeder/large capacity feeder).	E
1315		Middle sensor (MS) does not turn off during paper feed from cassette 5 (side multi tray/side deck).	E
1316		Middle sensor (MS) does not turn off during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	E
1317		Middle sensor (MS) does not turn off during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	E
1502	Paper conveying sensor non arrival jam	Paper conveying sensor (PCS) does not turn on during paper feed from cassette 2.	B
1503		Paper conveying sensor (PCS) does not turn on during paper feed from cassette 3 (paper feeder/large capacity feeder).	C
1504		Paper conveying sensor (PCS) does not turn on during paper feed from cassette 4 (paper feeder/large capacity feeder).	C
1512	Paper conveying sensor stay jam	Paper conveying sensor (PCS) does not turn off during paper feed from cassette 2.	E
1513		Paper conveying sensor (PCS) does not turn off during paper feed from cassette 3 (paper feeder/large capacity feeder).	E
1514		Paper conveying sensor (PCS) does not turn off during paper feed from cassette 4 (paper feeder/large capacity feeder).	E
1703	PF paper conveying sensor 1 non arrival jam	PF paper conveying sensor 1 (PFPCS1) does not turn on during paper feed from cassette 3 (paper feeder).	C
1704		PF paper conveying sensor 1 (PFPCS1) does not turn on during paper feed from cassette 4 (paper feeder).	C
1713	PF paper conveying sensor 1 stay jam	PF paper conveying sensor 1 (PFPCS1) does not turn off during paper feed from cassette 3 (paper feeder).	E
1714		PF paper conveying sensor 1 (PFPCS1) does not turn off during paper feed from cassette 4 (paper feeder).	E
1904	PF paper conveying sensor 2 non arrival jam	PF paper conveying sensor 2 (PFPCS2) does not turn on during paper feed from cassette 4 (paper feeder).	C

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
1914	PF paper conveying sensor 2 stay jam	PF paper conveying sensor 2 (PFPCS2) does not turn off during paper feed from cassette 4 (paper feeder).	E
2106	PF paper conveying sensor 1 non arrival jam	PF paper conveying sensor 1 (PFPCS1) does not turn on during paper feed from cassette 6 (side paper feeder).	M
2107		PF paper conveying sensor 1 (PFPCS1) does not turn on during paper feed from cassette 7 (side paper feeder).	M
2116	PF paper conveying sensor 1 stay jam	PF paper conveying sensor 1 (PFPCS1) does not turn off during paper feed from cassette 6 (side paper feeder).	L
2117		PF paper conveying sensor 1 (PFPCS1) does not turn off during paper feed from cassette 7 (side paper feeder).	L
2307	PF paper conveying sensor 2 non arrival jam	PF paper conveying sensor 2 (PFPCS2) does not turn on during paper feed from cassette 7 (side paper feeder).	M
2317	PF paper conveying sensor 2 stay jam	PF paper conveying sensor 2 (PFPCS2) does not turn off during paper feed from cassette 7 (side paper feeder).	M
2603	PF paper conveying sensor 1 non arrival jam	PF paper conveying sensor 1 (PFPCS1) does not turn on during paper feed from cassette 3 (large capacity feeder).	C
2604		PF paper conveying sensor 1 (PFPCS1) does not turn on during paper feed from cassette 4 (large capacity feeder).	C
2606		PF paper conveying sensor 1 (PFPCS1) does not turn on during paper feed from cassette 6 (side large capacity feeder).	M
2607		PF paper conveying sensor 1 (PFPCS1) does not turn on during paper feed from cassette 7 (side large capacity feeder).	M
2613	PF paper conveying sensor 1 stay jam	PF paper conveying sensor 1 (PFPCS1) does not turn off during paper feed from cassette 3 (large capacity feeder).	E
2614		PF paper conveying sensor 1 (PFPCS1) does not turn off during paper feed from cassette 4 (large capacity feeder).	E
2616		PF paper conveying sensor 1 (PFPCS1) does not turn off during paper feed from cassette 6 (side large capacity feeder).	L
2617		PF paper conveying sensor 1 (PFPCS1) does not turn off during paper feed from cassette 7 (side large capacity feeder).	L

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
2704	PF paper conveying sensor 2 non arrival jam	PF paper conveying sensor 2 (PFPCS2) does not turn on during paper feed from cassette 4 (large capacity feeder).	C
2707		PF paper conveying sensor 2 (PFPCS2) does not turn on during paper feed from cassette 7 (side large capacity feeder).	M
2714	PF paper conveying sensor 2 stay jam	PF paper conveying sensor 2 (PFPCS2) does not turn off during paper feed from cassette 4 (large capacity feeder).	E
2717		PF paper conveying sensor 2 (PFPCS2) does not turn off during paper feed from cassette 7 (side large capacity feeder).	L
3106	PF paper conveying sensor 1 non arrival jam	PF paper conveying sensor 1 (PFPCS1) does not turn on during paper feed from cassette 6 (side large capacity feeder).	M
3107		PF paper conveying sensor 1 (PFPCS1) does not turn on during paper feed from cassette 7 (side large capacity feeder).	M
3116	PF paper conveying sensor 1 stay jam	PF paper conveying sensor 1 (PFPCS1) does not turn off during paper feed from cassette 6 (side large capacity feeder).	L
3117		PF paper conveying sensor 1 (PFPCS1) does not turn off during paper feed from cassette 7 (side large capacity feeder).	L
3307	PF paper conveying sensor 2 non arrival jam	PF paper conveying sensor 2 (PFPCS2) does not turn on during paper feed from cassette 7 (side large capacity feeder).	M
3317	PF paper conveying sensor 2 stay jam	PF paper conveying sensor 2 (PFPCS2) does not turn off during paper feed from cassette 7 (side large capacity feeder).	L
3405	SM paper conveying sensor 1 non arrival jam	SM paper conveying sensor 1 (SMPCS1) does not turn on during paper feed from cassette 5 (side multi tray).	L
3406		SM paper conveying sensor 1 (SMPCS1) does not turn on during paper feed from cassette 6 (side multi tray).	M
3407		SM paper conveying sensor 1 (SMPCS1) does not turn on during paper feed from cassette 7 (side multi tray).	M

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
3415	SM paper conveying sensor 1 stay jam	SM paper conveying sensor 1 (SMPCS1) does not turn off during paper feed from cassette 5 (side multi tray).	L
3416		SM paper conveying sensor 1 (SMPCS1) does not turn off during paper feed from cassette 6 (side multi tray).	L
3417		SM paper conveying sensor 1 (SMPCS1) does not turn off during paper feed from cassette 7 (side multi tray).	L
3505	SM paper conveying sensor 2 non arrival jam	SM paper conveying sensor 2 (SMPCS2) does not turn on during paper feed from cassette 5 (side multi tray).	L
3506		SM paper conveying sensor 2 (SMPCS2) does not turn on during paper feed from cassette 6 (side multi tray).	M
3507		SM paper conveying sensor 2 (SMPCS2) does not turn on during paper feed from cassette 7 (side multi tray).	M
3515	SM paper conveying sensor 2 stay jam	SM paper conveying sensor 2 (SMPCS2) does not turn off during paper feed from cassette 5 (side multi tray).	L
3516		SM paper conveying sensor 2 (SMPCS2) does not turn off during paper feed from cassette 6 (side multi tray).	L
3517		SM paper conveying sensor 2 (SMPCS2) does not turn off during paper feed from cassette 7 (side multi tray).	L
3605	SM paper conveying sensor 3 non arrival jam	SM paper conveying sensor 3 (SMPCS3) does not turn on during paper feed from cassette 5 (side multi tray).	L
3606		SM paper conveying sensor 3 (SMPCS3) does not turn on during paper feed from cassette 6 (side multi tray).	M
3607		SM paper conveying sensor 3 (SMPCS3) does not turn on during paper feed from cassette 7 (side multi tray).	M

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
3615	SM paper conveying sensor 3 stay jam	SM paper conveying sensor 3 (SMPCS3) does not turn off during paper feed from cassette 5 (side multi tray).	L
3616		SM paper conveying sensor 3 (SMPCS3) does not turn off during paper feed from cassette 6 (side multi tray).	L
3617		SM paper conveying sensor 3 (SMPCS3) does not turn off during paper feed from cassette 7 (side multi tray).	M
3705	SM eject sensor non arrival jam	SM eject sensor (SMES) does not turn on during paper feed from cassette 5 (side multi tray).	L
3706		SM eject sensor (SMES) does not turn on during paper feed from cassette 6 (side multi tray).	M
3707		SM eject sensor (SMES) does not turn on during paper feed from cassette 7 (side multi tray).	M
3715	SM eject sensor stay jam	SM eject sensor (SMES) does not turn off during paper feed from cassette 5 (side multi tray).	L
3716		SM eject sensor (SMES) does not turn off during paper feed from cassette 6 (side multi tray).	L
3717		SM eject sensor (SMES) does not turn off during paper feed from cassette 7 (side multi tray).	L
4001	Registration sensor non arrival jam	Registration sensor (RS) does not turn on during paper feed from cassette 1.	E
4002		Registration sensor (RS) does not turn on during paper feed from cassette 2.	E
4003		Registration sensor (RS) does not turn on during paper feed from cassette 3 (paper feeder/large capacity feeder).	E
4004		Registration sensor (RS) does not turn on during paper feed from cassette 4 (paper feeder/large capacity feeder).	E
4005		Registration sensor (RS) does not turn on during paper feed from cassette 5 (side multi tray/side deck).	E
4006		Registration sensor (RS) does not turn on during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	E
4007		Registration sensor (RS) does not turn on during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	E
4009		Registration sensor (RS) does not turn on during paper feed from MP tray.	E

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
4011	Registration sensor stay jam	Registration sensor (RS) does not turn off during paper feed from cassette 1.	E
4012		Registration sensor (RS) does not turn off during paper feed from cassette 2.	E
4013		Registration sensor (RS) does not turn off during paper feed from cassette 3 (paper feeder/large capacity feeder).	E
4014		Registration sensor (RS) does not turn off during paper feed from cassette 4 (paper feeder/large capacity feeder).	E
4015		Registration sensor (RS) does not turn off during paper feed from cassette 5 (side multi tray/side deck).	E
4016		Registration sensor (RS) does not turn off during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	E
4017		Registration sensor (RS) does not turn off during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	E
4019		Registration sensor (RS) does not turn off during paper feed from MP tray.	E
4101		Loop sensor non arrival jam	Loop sensor (LPS) does not turn on during paper feed from cassette 1.
4102	Loop sensor (LPS) does not turn on during paper feed from cassette 2.		E
4103	Loop sensor (LPS) does not turn on during paper feed from cassette 3 (paper feeder/large capacity feeder).		E
4104	Loop sensor (LPS) does not turn on during paper feed from cassette 4 (paper feeder/large capacity feeder).		E
4105	Loop sensor (LPS) does not turn on during paper feed from cassette 5 (side multi tray/side deck).		E
4106	Loop sensor (LPS) does not turn on during paper feed from cassette 6 (side paper feeder/side large capacity feeder).		E
4107	Loop sensor (LPS) does not turn on during paper feed from cassette 7 (side paper feeder/side large capacity feeder).		E
4108	Loop sensor (LPS) does not turn on during paper feed from duplex section.		E
4109	Loop sensor (LPS) does not turn on during paper feed from MP tray.		E

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
4111	Loop sensor stay jam	Loop sensor (LPS) does not turn off during paper feed from cassette 1.	E
4112		Loop sensor (LPS) does not turn off during paper feed from cassette 2.	E
4113		Loop sensor (LPS) does not turn off during paper feed from cassette 3 (paper feeder/large capacity feeder).	E
4114		Loop sensor (LPS) does not turn off during paper feed from cassette 4 (paper feeder/large capacity feeder).	E
4115		Loop sensor (LPS) does not turn off during paper feed from cassette 5 (side multi tray/side deck).	E
4116		Loop sensor (LPS) does not turn off during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	E
4117		Loop sensor (LPS) does not turn off during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	E
4118		Loop sensor (LPS) does not turn off during paper feed from duplex section.	E
4119		Loop sensor (LPS) does not turn off during paper feed from MP tray.	E
4201		Fuser eject sensor non arrival jam	Fuser eject sensor (FUES) does not turn on during paper feed from cassette 1.
4202	Fuser eject sensor (FUES) does not turn on during paper feed from cassette 2.		E
4203	Fuser eject sensor (FUES) does not turn on during paper feed from cassette 3 (paper feeder/large capacity feeder).		E
4204	Fuser eject sensor (FUES) does not turn on during paper feed from cassette 4 (paper feeder/large capacity feeder).		E
4205	Fuser eject sensor (FUES) does not turn on during paper feed from cassette 5 (side multi tray/side deck).		E
4206	Fuser eject sensor (FUES) does not turn on during paper feed from cassette 6 (side paper feeder/side large capacity feeder).		E
4207	Fuser eject sensor (FUES) does not turn on during paper feed from cassette 7 (side paper feeder/side large capacity feeder).		E
4208	Fuser eject sensor (FUES) does not turn on during paper feed from duplex section.		E
4209	Fuser eject sensor (FUES) does not turn on during paper feed from MP tray.		E

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
4211	Fuser eject sensor stay jam	Fuser eject sensor (FUES) does not turn off during paper feed from cassette 1.	G
4212		Fuser eject sensor (FUES) does not turn off during paper feed from cassette 2.	G
4213		Fuser eject sensor (FUES) does not turn off during paper feed from cassette 3 (paper feeder/large capacity feeder).	G
4214		Fuser eject sensor (FUES) does not turn off during paper feed from cassette 4 (paper feeder/large capacity feeder).	G
4215		Fuser eject sensor (FUES) does not turn off during paper feed from cassette 5 (side multi tray/side deck).	G
4216		Fuser eject sensor (FUES) does not turn off during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	G
4217		Fuser eject sensor (FUES) does not turn off during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	G
4218		Fuser eject sensor (FUES) does not turn off during paper feed from duplex section.	G
4219		Fuser eject sensor (FUES) does not turn off during paper feed from MP tray.	G
4301	Duplex sensor 1 non arrival jam	Duplex sensor 1 (DUS1) does not turn on during paper feed from cassette 1.	G
4302		Duplex sensor 1 (DUS1) does not turn on during paper feed from cassette 2.	G
4303		Duplex sensor 1 (DUS1) does not turn on during paper feed from cassette 3 (paper feeder/large capacity feeder).	G
4304		Duplex sensor 1 (DUS1) does not turn on during paper feed from cassette 4 (paper feeder/large capacity feeder).	G
4305		Duplex sensor 1 (DUS1) does not turn on during paper feed from cassette 5 (side multi tray/side deck).	G
4306		Duplex sensor 1 (DUS1) does not turn on during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	G
4307		Duplex sensor 1 (DUS1) does not turn on during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	G
4309		Duplex sensor 1 (DUS1) does not turn on during paper feed from MP tray.	G

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
4311	Duplex sensor 1 stay jam	Duplex sensor 1 (DUS1) does not turn off during paper feed from cassette 1.	F
4312		Duplex sensor 1 (DUS1) does not turn off during paper feed from cassette 2.	F
4313		Duplex sensor 1 (DUS1) does not turn off during paper feed from cassette 3 (paper feeder/large capacity feeder).	F
4314		Duplex sensor 1 (DUS1) does not turn off during paper feed from cassette 4 (paper feeder/large capacity feeder).	F
4315		Duplex sensor 1 (DUS1) does not turn off during paper feed from cassette 5 (side multi tray/side deck).	F
4316		Duplex sensor 1 (DUS1) does not turn off during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	F
4317		Duplex sensor 1 (DUS1) does not turn off during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	F
4319		Duplex sensor 1 (DUS1) does not turn off during paper feed from MP tray.	F
4401	Duplex sensor 2 non arrival jam	Duplex sensor 2 (DUS2) does not turn on during paper feed from cassette 1.	F
4402		Duplex sensor 2 (DUS2) does not turn on during paper feed from cassette 2.	F
4403		Duplex sensor 2 (DUS2) does not turn on during paper feed from cassette 3 (paper feeder/large capacity feeder).	F
4404		Duplex sensor 2 (DUS2) does not turn on during paper feed from cassette 4 (paper feeder/large capacity feeder).	F
4405		Duplex sensor 2 (DUS2) does not turn on during paper feed from cassette 5 (side multi tray/side deck).	F
4406		Duplex sensor 2 (DUS2) does not turn on during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	F
4407		Duplex sensor 2 (DUS2) does not turn on during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	F
4409		Duplex sensor 2 (DUS2) does not turn on during paper feed from MP tray.	F

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
4411	Duplex sensor 2 stay jam	Duplex sensor 2 (DUS2) does not turn off during paper feed from cassette 1.	F
4412		Duplex sensor 2 (DUS2) does not turn off during paper feed from cassette 2.	F
4413		Duplex sensor 2 (DUS2) does not turn off during paper feed from cassette 3 (paper feeder/large capacity feeder).	F
4414		Duplex sensor 2 (DUS2) does not turn off during paper feed from cassette 4 (paper feeder/large capacity feeder).	F
4415		Duplex sensor 2 (DUS2) does not turn off during paper feed from cassette 5 (side multi tray/side deck).	F
4416		Duplex sensor 2 (DUS2) does not turn off during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	F
4417		Duplex sensor 2 (DUS2) does not turn off during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	F
4418		Duplex sensor 2 (DUS2) does not turn off during paper feed from duplex section.	F
4419		Duplex sensor 2 (DUS2) does not turn off during paper feed from MP tray.	F

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
4601	Eject full sensor non arrival jam	Eject full sensor (EFS) does not turn on during paper feed from cassette 1.	G
4602		Eject full sensor (EFS) does not turn on during paper feed from cassette 2.	G
4603		Eject full sensor (EFS) does not turn on during paper feed from cassette 3 (paper feeder/large capacity feeder).	G
4604		Eject full sensor (EFS) does not turn on during paper feed from cassette 4 (paper feeder/large capacity feeder).	G
4605		Eject full sensor (EFS) does not turn on during paper feed from cassette 5 (side multi tray/side deck).	G
4606		Eject full sensor (EFS) does not turn on during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	G
4607		Eject full sensor (EFS) does not turn on during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	G
4608		Eject full sensor (EFS) does not turn on during paper feed from duplex section.	G
4609		Eject full sensor (EFS) does not turn on during paper feed from MP tray.	G
4611	Eject full sensor stay jam	Eject full sensor (EFS) does not turn off during paper feed from cassette 1.	G
4612		Eject full sensor (EFS) does not turn off during paper feed from cassette 2.	G
4613		Eject full sensor (EFS) does not turn off during paper feed from cassette 3 (paper feeder/large capacity feeder).	G
4614		Eject full sensor (EFS) does not turn off during paper feed from cassette 4 (paper feeder/large capacity feeder).	G
4615		Eject full sensor (EFS) does not turn off during paper feed from cassette 5 (side multi tray/side deck).	G
4616		Eject full sensor (EFS) does not turn off during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	G
4617		Eject full sensor (EFS) does not turn off during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	G
4618		Eject full sensor (EFS) does not turn off during paper feed from duplex section.	G
4619		Eject full sensor (EFS) does not turn off during paper feed from MP tray.	G

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
4701	Switchback sensor non arrival jam	Switchback sensor (SBS) does not turn on during paper feed from cassette 1.	G
4702		Switchback sensor (SBS) does not turn on during paper feed from cassette 2.	G
4703		Switchback sensor (SBS) does not turn on during paper feed from cassette 3 (paper feeder/large capacity feeder).	G
4704		Switchback sensor (SBS) does not turn on during paper feed from cassette 4 (paper feeder/large capacity feeder).	G
4705		Switchback sensor (SBS) does not turn on during paper feed from cassette 5 (side multi tray/side deck).	G
4706		Switchback sensor (SBS) does not turn on during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	G
4707		Switchback sensor (SBS) does not turn on during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	G
4708		Switchback sensor (SBS) does not turn on during paper feed from duplex section.	G
4709		Switchback sensor (SBS) does not turn on during paper feed from MP tray.	G
4711	Switchback sensor stay jam	Switchback sensor (SBS) does not turn off during paper feed from cassette 1.	I
4712		Switchback sensor (SBS) does not turn off during paper feed from cassette 2.	I
4713		Switchback sensor (SBS) does not turn off during paper feed from cassette 3 (paper feeder/large capacity feeder).	I
4714		Switchback sensor (SBS) does not turn off during paper feed from cassette 4 (paper feeder/large capacity feeder).	I
4715		Switchback sensor (SBS) does not turn off during paper feed from cassette 5 (side multi tray/side deck).	I
4716		Switchback sensor (SBS) does not turn off during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	I
4717		Switchback sensor (SBS) does not turn off during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	I
4718		Switchback sensor (SBS) does not turn off during paper feed from duplex section.	I
4719		Switchback sensor (SBS) does not turn off during paper feed from MP tray.	I

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
4901	BR conveying sensor 1 non arrival jam	BR conveying sensor 1 (BRCS1) does not turn on during paper feed from cassette 1.	G
4902		BR conveying sensor 1 (BRCS1) does not turn on during paper feed from cassette 2.	G
4903		BR conveying sensor 1 (BRCS1) does not turn on during paper feed from cassette 3 (paper feeder/large capacity feeder).	G
4904		BR conveying sensor 1 (BRCS1) does not turn on during paper feed from cassette 4 (paper feeder/large capacity feeder).	G
4905		BR conveying sensor 1 (BRCS1) does not turn on during paper feed from cassette 5 (side multi tray/side deck).	G
4906		BR conveying sensor 1 (BRCS1) does not turn on during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	G
4907		BR conveying sensor 1 (BRCS1) does not turn on during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	G
4908		BR conveying sensor 1 (BRCS1) does not turn on during paper feed from duplex section.	G
4909		BR conveying sensor 1 (BRCS1) does not turn on during paper feed from MP tray.	G
4911	BR conveying sensor 1 stay jam	BR conveying sensor 1 (BRCS1) does not turn off during paper feed from cassette 1.	J
4912		BR conveying sensor 1 (BRCS1) does not turn off during paper feed from cassette 2.	J
4913		BR conveying sensor 1 (BRCS1) does not turn off during paper feed from cassette 3 (paper feeder/large capacity feeder).	J
4914		BR conveying sensor 1 (BRCS1) does not turn off during paper feed from cassette 4 (paper feeder/large capacity feeder).	J
4915		BR conveying sensor 1 (BRCS1) does not turn off during paper feed from cassette 5 (side multi tray/side deck).	J
4916		BR conveying sensor 1 (BRCS1) does not turn off during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	J
4917		BR conveying sensor 1 (BRCS1) does not turn off during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	J

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
4918	BR conveying sensor 1 stay jam	BR conveying sensor 1 (BRCS1) does not turn off during paper feed from duplex section.	J
4919		BR conveying sensor 1 (BRCS1) does not turn off during paper feed from MP tray.	J
5001	BR conveying sensor 2 non arrival jam	BR conveying sensor 2 (BRCS2) does not turn on during paper feed from cassette 1.	J
5002		BR conveying sensor 2 (BRCS2) does not turn on during paper feed from cassette 2.	J
5003		BR conveying sensor 2 (BRCS2) does not turn on during paper feed from cassette 3 (paper feeder/large capacity feeder).	J
5004		BR conveying sensor 2 (BRCS2) does not turn on during paper feed from cassette 4 (paper feeder/large capacity feeder).	J
5005		BR conveying sensor 2 (BRCS2) does not turn on during paper feed from cassette 5 (side multi tray/side deck).	J
5006		BR conveying sensor 2 (BRCS2) does not turn on during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	J
5007		BR conveying sensor 2 (BRCS2) does not turn on during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	J
5008		BR conveying sensor 2 (BRCS2) does not turn on during paper feed from duplex section.	J
5009		BR conveying sensor 2 (BRCS2) does not turn on during paper feed from MP tray.	J
5011		BR conveying sensor 2 stay jam	BR conveying sensor 2 (BRCS2) does not turn off during paper feed from cassette 1.
5012	BR conveying sensor 2 (BRCS2) does not turn off during paper feed from cassette 2.		J
5013	BR conveying sensor 2 (BRCS2) does not turn off during paper feed from cassette 3 (paper feeder/large capacity feeder).		J
5014	BR conveying sensor 2 (BRCS2) does not turn off during paper feed from cassette 4 (paper feeder/large capacity feeder).		J
5015	BR conveying sensor 2 (BRCS2) does not turn off during paper feed from cassette 5 (side multi tray/side deck).		J

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
5016	BR conveying sensor 2 stay jam	BR conveying sensor 2 (BRCS2) does not turn off during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	J
5017		BR conveying sensor 2 (BRCS2) does not turn off during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	J
5018		BR conveying sensor 2 (BRCS2) does not turn off during paper feed from duplex section.	J
5019		BR conveying sensor 2 (BRCS2) does not turn off during paper feed from MP tray.	J
5101	BR eject sensor non arrival jam	BR eject sensor (BRES) does not turn on during paper feed from cassette 1.	J
5102		BR eject sensor (BRES) does not turn on during paper feed from cassette 2.	J
5103		BR eject sensor (BRES) does not turn on during paper feed from cassette 3 (paper feeder/large capacity feeder).	J
5104		BR eject sensor (BRES) does not turn on during paper feed from cassette 4 (paper feeder/large capacity feeder).	J
5105		BR eject sensor (BRES) does not turn on during paper feed from cassette 5 (side multi tray/side deck).	J
5106		BR eject sensor (BRES) does not turn on during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	J
5107		BR eject sensor (BRES) does not turn on during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	J
5108		BR eject sensor (BRES) does not turn on during paper feed from duplex section.	J
5109		BR eject sensor (BRES) does not turn on during paper feed from MP tray.	J

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
5111	BR eject sensor stay jam	BR eject sensor (BRES) does not turn off during paper feed from cassette 1.	J
5112		BR eject sensor (BRES) does not turn off during paper feed from cassette 2.	J
5113		BR eject sensor (BRES) does not turn off during paper feed from cassette 3 (paper feeder/large capacity feeder).	J
5114		BR eject sensor (BRES) does not turn off during paper feed from cassette 4 (paper feeder/large capacity feeder).	J
5115		BR eject sensor (BRES) does not turn off during paper feed from cassette 5 (side multi tray/side deck).	J
5116		BR eject sensor (BRES) does not turn off during paper feed from cassette 6 (side paper feeder/side large capacity feeder).	J
5117		BR eject sensor (BRES) does not turn off during paper feed from cassette 7 (side paper feeder/side large capacity feeder).	J
5118		BR eject sensor (BRES) does not turn off during paper feed from duplex section.	J
5119		BR eject sensor (BRES) does not turn off during paper feed from MP tray.	J
6000		DF paper entry error	DF paper entry sensor (DFPES) turns on before the eject signal is output from the machine (4000-sheet finisher).
6001	DF paper entry sensor (DFPES) turns on before the eject signal is output from the machine (1000-sheet finisher).		K
6020	DF front cover open	DF front upper cover is opened during operation (4000-sheet finisher).	K
6021		DF front cover is opened during operation (1000-sheet finisher).	K
6041	DF top cover open	DF top cover is opened during operation (1000-sheet finisher).	K
6050	CF eject cover open	CF eject cover is opened during operation (4000-sheet finisher).	K
6060	MB cover open	MB cover is opened during operation (4000-sheet finisher).	K
6070	Center folding unit open	Center folding unit is opened during operation (4000-sheet finisher).	K
6080	CF left guide open	CF left guide is opened during operation (4000-sheet finisher).	K

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
6100	DF paper entry sensor non arrival jam	DF paper entry sensor (DFPES) is not turned on even if a specified time has elapsed after the machine eject signal was received (4000-sheet finisher).	K
6101		DF paper entry sensor (DFPES) is not turned on even if a specified time has elapsed after the machine eject signal was received (1000-sheet finisher).	K
6110	DF paper entry sensor stay jam	DF paper entry sensor (DFPES) is not turned off within specified time of its turning on (4000-sheet finisher).	K
6111		DF paper entry sensor (DFPES) is not turned off within specified time of its turning on (1000-sheet finisher).	K
6200	DF sub eject sensor non arrival jam	DF sub eject sensor (DFSES) does not turn on within specified time of DF paper entry sensor (DFPES) turning on.	K
6210	DF sub eject sensor stay jam	DF sub eject sensor (DFSES) is not turned off within specified time of its turning on.	K
6300	DF middle eject sensor non arrival jam	DF middle eject sensor (DFMES) does not turn on within specified time of DF paper entry sensor (DFPES) turning on (4000-sheet finisher).	K
6301		DF middle eject sensor (DFMES) does not turn on within specified time of DF paper entry sensor (DFPES) turning on (1000-sheet finisher).	K
6310	DF middle eject sensor stay jam	DF middle eject sensor (DFMES) is not turned off within specified time of its turning on (4000-sheet finisher).	K
6311		DF middle eject sensor (DFMES) is not turned off within specified time of its turning on (1000-sheet finisher).	K
6400	DF tray upper surface sensor non arrival jam	DF tray upper surface sensor (DFTUSS) does not turn on within specified time of DF middle eject sensor (DFMES) turning on (4000-sheet finisher).	K
6401		DF tray upper surface sensor (DFTUSS) does not turn on within specified time of DF middle eject sensor (DFMES) turning on (1000-sheet finisher).	K
6410	DF tray upper surface sensor stay jam	DF tray upper surface sensor (DFTUSS) is not turned off within specified time of its turning on (4000-sheet finisher).	K
6411		DF tray upper surface sensor (DFTUSS) is not turned off within specified time of its turning on (1000-sheet finisher).	K

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
6500	DF eject paper sensor non arrival jam	DF eject paper sensor (DFMETS) does not turn on within specified time of DF middle eject sensor (DFMES) turning on.	K
6510	DF eject paper sensor stay jam	DF eject paper sensor (DFMETS) is not turned off since the bundle discharge starts (4000-sheet finisher).	K
6511		DF eject paper sensor (DFMETS) is not turned off since the bundle discharge starts (1000-sheet finisher).	K
6600	DF drum sensor non arrival jam	DF drum sensor (DFDRS) does not turn on within specified time of DF paper entry sensor (DFPES) turning on.	K
6610	DF drum sensor stay jam	DF drum sensor (DFDRS) is not turned off within specified time of its turning on.	K
6710	Center folding unit stay jam	During paper conveying to center folding unit, DF drum sensor (DFDRS) is not turned off within specified time of its turning on.	K
6810	DF side registration sensor 1 stay jam	DF side registration sensor 1 (DFSRS1) is not turned off within specified time after driving the DF side registration motor 1 (DFSRM1) (4000-sheet finisher).	K
6811		DF side registration sensor 1 (DFSRS1) is not turned off within specified time after driving the DF side registration motor 1 (DFSRM1) (1000-sheet finisher).	K
6910	DF side registration sensor 2 stay jam	DF side registration sensor 2 (DFSRS2) is not turned off within specified time after driving the DF side registration motor 2 (DFSRM2) (4000-sheet finisher).	K
6811		DF side registration sensor 2 (DFSRS2) is not turned off within specified time after driving the DF side registration motor 2 (DFSRM2) (1000-sheet finisher).	K
7000	DF staple operation error	DF staple sensor (DFSTS) is not turned on within specified time after driving the DF staple motor (DFSTM) (4000-sheet finisher).	K
7001		DF staple sensor (DFSTS) is not turned on within specified time after driving the DF staple motor (DFSTM) (1000-sheet finisher).	K
7100	CF paper entry sensor non arrival jam	CF paper entry sensor (CFPES) is not turned on even if a specified time has elapsed after the machine eject signal was received.	K
7110	CF paper entry sensor stay jam	CF paper entry sensor (CFPES) is not turned off within specified time of its turning on.	K
7200	CF eject sensor non arrival jam	CF eject sensor (CFES) is not turned on within specified time since centerfold operation starts.	K
7210	CF eject sensor stay jam	During centerfold operation, CF eject sensor (CFES) is not turned off within specified time of its turning on.	K

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
7300	CF eject sensor non arrival jam	CF eject sensor (CFES) is not turned on within specified time since three fold operation starts.	K
7310	CF eject sensor stay jam	During three fold operation, CF eject sensor (CFES) is not turned off within specified time of its turning on.	K
7400	CF side registration sensor 2 non arrival jam	CF side registration sensor 2 (CFSRS2) is not turned on within specified time after driving the CF side registration motor 2 (CFSRM2).	K
7500	CF side registration sensor 1 non arrival jam	CF side registration sensor 1 (CFSRS1) is not turned on within specified time after driving the CF side registration motor 1 (CFSRM1).	K
7600	CF staple operation error	CF staple sensor (CFSTS) is not turned on within specified time after driving the CF staple motor (CFSTM).	K
7700	CF paper conveying sensor non arrival jam	CF paper conveying sensor (CFPCS) is not turned on even if a specified time has elapsed after the machine eject signal was received.	K
7710	CF paper conveying sensor stay jam	CF paper conveying sensor (CFPCS) is not turned off within specified time of its turning on.	K
7800	MB eject sensor non arrival jam	MB eject sensor (MBES) is not turned on even if a specified time has elapsed after the machine eject signal was received.	K
7810	MB eject sensor stay jam	MB eject sensor (MBES) is not turned off within specified time of its turning on.	K
7950	Paper interval error jam	An illegal inter-page or inter-copy interval has occurred (4000-sheet finisher).	K
7951		An illegal inter-page or inter-copy interval has occurred (1000-sheet finisher).	K
9000	No original feed	DP feed sensor (DPFS) does not turn on within specified time during the first sheet feeding (Retry 5 times).	H
9001	DP original conveying jam	DP timing sensor (DPTS) turns off within the specified time since the sensor turns on.	H
9002	DP sensor stay jam	Sensor in the conveying system is on since original feeding starts.	H
9004	DP switchback jam 2	DP registration sensor (DPRS) is not turned on within specified time since original switchback operation starts.	H
9005	No original feed 2	DP lift sensor 1 (DPLS1) does not turn on within specified time of the lift plate rising.	H
9006	DP switchback jam 3	DP eject sensor (DPES) is not turned on within specified time since original switchback operation starts.	H
9007	DP switchback jam 4	DP eject sensor (DPES) is not turned off within specified time since original switchback operation starts.	H

*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

Code	Contents	Conditions	Jam location*
9008	No original feed 3	DP CIS sensor (DPCS) does not turn on within specified time of the paper feed starting.	H
9009	DP original conveying jam 2	Next feed original became the stand-by states of paper feed while reading the image.	H
9010	Document processor open	Document processor is opened during original feeding.	H
9011	DP top cover open	The DP top cover is opened during original feeding.	H
9020	Original skew feed jam	DP skew sensor (DPSS) does not turn on within specified time of DP registration sensor (DPRS) turning on.	H
9110	DP feed sensor stay jam	DP feed sensor (DPFS) does not turn off within specified time of DP timing sensor (DPTS) turning on.	H
9200	DP registration sensor non arrival jam	DP registration sensor (DPRS) does not turn on within specified time of DP feed sensor (DPFS) turning on.	H
9210	DP registration sensor stay jam	DP registration sensor (DPRS) does not turn off within specified time of DP timing sensor (DPTS) turning on.	H
9300	DP CIS sensor non arrival jam	DP CIS sensor (DPCS) does not turn on within specified time of DP registration sensor (DPRS) turning on.	H
9310	DP CIS sensor stay jam	DP CIS sensor (DPCS) does not turn off within specified time of DP registration sensor (DPRS) turning off.	H
9400	DP timing sensor non arrival jam	DP timing sensor (DPTS) does not turn on within specified time of DP feed sensor (DPFS) turning on.	H
9410	DP timing sensor stay jam	DP timing sensor (DPTS) does not turn off within specified time of DP feed sensor (DPFS) turning off.	H
9500	DP switchback sensor non arrival jam	DP switchback sensor (DPSBS) does not turn on within specified time of DP timing sensor (DPTS) turning on.	H
9600	DP eject sensor non arrival jam	DP eject sensor (DPES) does not turn on within specified time of DP timing sensor (DPTS) turning on.	H
9610	DP eject sensor stay jam	DP eject sensor (DPES) does not turn off within specified time of DP timing sensor (DPTS) turning off.	H


*: Refer to figure 1-4-1 for paper misfeed indication (see page 1-4-1).

1-4-2 Troubleshooting

(1) First check items

If the paper is fed askew, jammed, curled, or leading-edge dog-eared, first perform to check the following items.

Check items	Check description	Corrective measures
Paper	1. Check the paper delivered is dog-eared, skewed, ruffled, loosely fused, or curled.	If a dog-ear has happened, check there are no objects existing in the conveying paths and, if any, fix. If the paper is fed askew or crumpled, perform the following two items. If an inferior fusing or curling is observed and the fuser temperature is set to an abnormal value, when measured by performing maintenance mode U161, reset to the default. (see page 1-3-104)
	2. Check how paper is loaded in the cassette (deck). Check that the paper has been properly aligned with width adjuster cursor and the rear guide; it has been loaded without skewing; or it is not damaged. (Crumpled paper, main unit/DF jam)	Adjust the cursors to the size of the paper. (If paper is fed askew, perform a skew cancellation adjustment of the width adjuster cursor.) (see page 1-5-105)
	3. Check how paper is loaded. Check if the cutting edge of the paper bundle inside is crumpled or bent.	If the cutting edge of the paper bundle is crumpled, fan the paper before loading. If the paper is folded, stretch before loading in the cassette
	4. If a large-capacity deck is being used, check how paper is loaded in the deck. Check if the paper inside the deck is placed above the guide.	Reload the paper so that its edges won't be situated above the platform.
	5. Check the paper is damp, wavy, or curled.	1. Load the paper bundle in the cassette upside down. 2. Load the paper bundle after rotating it 180° and reload. 3. Change the paper.
	6. Check if the paper loaded was stored in a continuously humid place.	Instruct the user to store paper in a dry, less humid place. Install a cassette heater and configure using U327. (see page 1-3-148)
	7. Check if the paper conforms to the requirements.	Isolate the cause of the problem by replacing the paper with the recommended paper. (see page 1-1-1)



Check items	Check description	Corrective measures
	8. Check the paper ejected is dog-eared, skewed, ruffled, loosely fused, or curled.	If the maintenance mode U161 shows that the fuser temperature is set to an abnormal value, reset it to the default. (see page 1-3-104)
Settings/ Detection	1. Perform U034 to check the reference mark is situated at 20mm±1mm from the edge. (Fuser jam) (see page 1-3-34)	If the check line is not situated at 20mm±1mm from the leading edge, adjust the leading margin by U402. (see page 1-3-153)
	2. Check the panel if the paper size is correctly detected and the cassette size is not fixed. (Paper jam caused by continuously fed paper, DF Jam J611X) Perform U000 to obtain a Event Log to check if the paper size and the size of the paper loaded are met when jam has occurred and if the size of the original document and the paper size are met. see page 1-3-11)	If the paper size is incorrectly displayed, adjust the positions of the paper set guide cursors in accordance with the paper size, making sure that the paper is not askew to activate the size detector switch.
	3. Check that paper settings are made in accordance with the paper being used. (Jam caused by faulty separation)	If the existing paper settings are incorrect, configure using a common settings in the system menu, original document/ paper settings properly.
Conveying unit	Check the main unit vertical conveying unit or the front and back parts and right and left parts of the deck's horizontal conveying unit are slightly strained and closed.	To open, first open the right-side conveying unit and close firmly. (Check the position of the safety switch)

Check items	Check description	Corrective measures
Conveying guide, approaching guide, paddle guide	1. Check that the foreign objects including scrips, paper clips, etc., do not exist in the paper conveying paths.	If foreign objects such as scrips, etc., remain in the paper conveying path, remove.
	2. Check that the paper conveying guide and the separation needles are not contaminated with toner, paper dusts, etc.	If dirty, clean the guide, ribs (by a cloth), and the separation needles (by a cleaning brush). If the ribs of the conveying guides were broken or deposited with toner, replace.
	3. Check that the paper conveying guide has no bars, deformations, or abrasions; and it is properly mounted without being floated.	1. Clean the conveying guide or the paper approaching guide. Remove any protrusions including bars. If floated, fix it properly. If deformation or abrasion is observed, replace. 2. If a curled light-weight paper is interrupted by the eject guide causing dog-ears, affix a sheet of film for prevention.
	4. Check that the guide. Check that the guide is smoothly operative when manipulated.	If the guide is inoperative or won't operate smoothly, replace the guide or the unit.
	5. Check that the guide. Perform U033 to check the operation of the solenoid to sight-check or audio-check its action. (see page 1-3-34)	If the guide is inoperative or won't operate smoothly, re-assemble the guide or replace the solenoid or the unit.

Check items	Check description	Corrective measures
Conveying roller, feed roller	1. Check the conveying rollers have no paper dusts, toner, or foreign objects stucked. Check a variation of the outer diameter of the roller or abrasion is not observed with the conveying roller.	Clean the conveying rollers or the pulleys. If variation in the external diameter or abrasion is observed, replace. * : Identify the roller being new or old , and replace.
	2. Turn the cover safety switch on and perform U030 - Motor, U032 - Clutch, and U240 - Finished, check they operate normally. * : At checking the clutch by U032, confirm that the roller won't turn when the motor is turned on. (see page 1-3-33)	If the conveying motor or the clutch is inoperative, replace. If stained, replace the clutch. If the clutch is kept turned on due to a tensioned wire, reroute wires.
	3. Check the conveying roller rotates without overloading. Check the axle holder or the roller shaft are not contaminated. Check that the spring has not fallen off and is mounted so that it is properly applying pressure against the rollers or pulleys.	Clean the roller axle or the axle holder. Re-assemble it while checking the pressure of the spring.
Sensor	1. Check if it does not operate with smoothness due to an abnormal move or dropping off of the actuator of the conveying switch.	Re-assemble the actuator or the return spring.
	2. Check that the surface of the sensor and the receptor black felt pieces are not contaminated with toner, paper dusts, etc.	If dirty, clean the sensor or the black felt piece.
	3. Perform U031 - Conveying switch and U241 - Finisher switch to check the sensors are normal without flickering, etc. (see page 1-3-32, 1-3-124)	If U031 has revealed that the sensor is inoperative, replace the switch.

Check items	Check description	Corrective measures
Static	Check if the location is susceptible to build static discharge at the conveying guide during printing.	Re-assemble and re-wire the static discharge sheet at the ejection unit or the metal guide at the transfer unit so that they are properly grounded.

(2) Items and corrective actions relating to the device that will cause paper jam





Jam types	Check description	Corrective measures
No-paper-feed jam or the leading edge of paper is curled back at the position of the roller (J0501, J0502, J0503, J0504, J0505, J0506, J0507, J0509, J0523, J0524, J0525, J0526, J0527, J0545)	1. Check if the jammed paper or the printed paper has a tear caused by the roller at its leading edge.	Replace the primary feed roller. (Service life of rubber roller is 150k.) Increase the spring pressure to pinch the separation rollers if the component is undue to its expected life. Replace the spring.
	2. Check abrasion and paper dusts on the feed roller and forward rollers.	Clean the feed roller and the forward roller. Or, if not amended, replace.
	3. Perform U032 to check the forward roller and feed roller are rotating.	If disconnected or or stained, replace the primary feed clutch.
	4. Check if a primary feed roller of a wrong material of rubber (gray) is installed.	Replace the feed rollers with a genuine set of a feed roller (1), retard rollers (2), and pickup rollers (3, black-colored).
	5. Check that the conveying force of the pickup roller is sufficient.	Increase the conveying force during paper pickup by increasing the spring load of the pickup roller.
	6. Check the luminal is sufficiently protruded in front of approaching the feed roller and the nip. (Too wide a gap against the feed roller.)	Amount of protrusion of luminal in approaching (Gap: 0.2 - 0.5 mm) must be maintained after adjustment.





Jam types	Check description	Corrective measures
	7. Check the separation roller is not disturbed as a driving component is in contact with the frame during the separation roller is in motion.	If it gets in contact, replace the primary feed unit.
	8. Depress the release lever to release the pressure of the primary feed rollers to check that the retard holder falls.(The pressure by the retard roller to the feed roller is decreased.)	Modify mounting the retard holder fixing plate.



Jam types	Check description	Corrective measures
Multiple-feed Jam J0511, J0512, J0513, J0514, J0516, J0517, J0519?	1. Check if the cutting edge of the paper bundle is crumpled or the cassette is loaded with multiple times of replenishing paper.	If the cutting edge of the paper bundle is crumpled or the cassette is loaded with multiple times of replenishing paper, load new paper.
	2. Checking paper size. Check that the size of the loaded paper and the paper size chosen on the operator panel are met.	<p>If the paper size does not agree.</p> <ol style="list-style-type: none"> 1. If the cassette cursors are open against the paper, set it properly. 2. Insert the cassette until the paper size detector switch is turned on. <p>If the size is not detectable while automatic sizing is enabled, replace the size detection switch.</p> <p>If the paper size agrees</p> <ol style="list-style-type: none"> 1. If paper other than complying the requirements such as coated paper, inkjet paper, etc., is used, replace the paper. 2. RE-assemble the pulley retard in the primary feed unit if it is mounted to the opposite direction. 3. Check if the spring retard has not been fallen off of the mounting position. SDecrease the spring pressure to pinch the separation rollers if the component is at the mounting position. 4. Replace the primary feed unit.
	3. Check if paper dusts and abrasion are observed on the paper fanning roller and retard roller.	<p>If the paper fanning roller is dirty, clean.</p> <p>If abrasion is observed, replace.</p>
	4. Select the motor by U032 and check the clutch rotates following the other component when the motor is turned on. (see page 1-3-33)	If the clutch rotates following the other component and its stain is observed, replace the clutch.
Duplex No-original-feed Jam (J0508)/ Duplex Multiple-feed Jam (J0518)	Perform U031 to check if the duplex sensor 2 is detected. (see page 1-3-32)	If the duplex sensor 2 is not working, replace the duplex sensor 2.





Jam types	Check description	Corrective measures
Intermediate/ conveying sensor retention jam (J1313, J1314, J1513, J1514)	1. Check to see if the driving mechanism for paper conveyance is operative without a hinderance.	If it won't operate without hinderance, re-assemble or replace the actuator's return spring.
	2. Perform U031 to check the operation of the sensor.	If the sensor is inoperative, replace.
	3. Select the motor by U032 and check if the conveying motor rotates following the other component. (see page 1-3-33)	If stained, replace the clutch.Re-assmeble the clutch so that it is not continuously energized. (Change of wirings, etc.)
	4. Check if the conveying guide is twisted to be mounted.(If the mounting parts of the guide is floated, the actuator won't protrude sufficiently.)	If the bracket is twisted to be mounted, remove the screw fixing the conveying guide and properly mount the bracket in the right position and fix again.
	5. Check no wrinkles are observed at the sluck of paper during paper feeding.	Adjust the cursors to the size of the paper. (If paper is fed askew, perform a skew cancellation adjustment of the width adjuster cursor.) (see page 1-5-105)
Conveying sensor unreachable jam (J1503/J1504) SM conveying sensor 2 retention jam (J3415, J3416, J3417)	1. Check to see if the actuator is operative without hinderance.	Re-assemble or replace the actuator's return spring.
	2. Check the transmission of the gear drive using U032. * : Check the conveying roller rotates and is movable in the direction of thrust without hinderance. (see page 1-3-33)	If the roller won't rotate without hinderance, loosen the screws for adjusting the position (at the gear train bracket) to mount the driving gears, and tighten so that a gap between the gears and frame is eliminated.




Jam types	Check description	Corrective measures
Loop sensor non arrival jam (J4101, J4102, J4103, J4104, J4105, J4106, J4107)	1. Check no wrinkles are observed at the sluck of paper during paper feeding.	Exercise a countermeasure against wrinkles. (Check for the existence of the regist guide.)
	2. Check that the paper is entirely loaded inside the cassette without being skewed.	Reload paper.
Fuser ejection sensor retention jam (J421X) Ejection-full sensor unreachable jam (J460X) Inversion sensor unreachable jam (J470X)	1. If paper jam occurs at the paddle guide in the ejection unit, check if the guide is operative without hinderance.	If the distance between the housing and the paddle guide is too small for the guide to move without hinderance, replace the eject unit.
	2. Perform U031 to check if the eject sensor does not show a false detection. (see page 1-3-32)	Replace the defective eject sensor or the eject unit.
Duplex sensors 1 and 2, stuck/ Unreachable Jam (J43XX, J44XX)	1. Check that the duplex rollers cause slipage in feeding paper.	Clean or replace the duplex roller in the coveying unit.
	2. Perform U031 to check if the duplex sensors 1 and 2 do not show false detections.	Replace the defective duplex sensors 1 and 2 or the coveying unit.
	3. Check if the second side of plain paper is curled at its tail and slacked in the middle making the switch disguised as no existance of paper.	Replace the paper with new paper.Try feeding paper lengthwise.





Jam types	Check description	Corrective measures
BR conveying sensor 1/2 unreachable/stay jam (J49XX) Eject sensor non arrival jam (J50XX) Eject sensor stay jam (J51XX) DF paper entry error JAM (J600X)	1. Check the location the bridge relay conveying unit is mounted.	Re-mount.  <p>▲ Location of mounting the relaying conveyance unit</p>
	2. Check if the positionings of the bridge drive unit is broken.	 <p>Damaged</p> <p>Normal</p>
	3. Check the bridge conveying unit has been properly installed.	Re-mount.  <p>[Fixing Paper conveying unit]</p> <p>Sliding rails for the AK conveyance unit</p> <p>AK conveyance unit</p> <p>Front side of the machine</p>
	4. Check if the upper conveying guide on the bridge conveying unit has fallen off.	Re-mount.  <p>A view of the AK (Bridge) Conveyance Unit Tray being opened</p> <p>Upper guide</p> <p>Lower guide</p> <p>Affix fixing films (No. 1) at the two axles.</p> <p>No.1</p> <p>Flix fixing films (No. 1)</p> <p>Adhesive tape</p> <p>PET FILM t=0.1mm</p>





Jam types	Check description	Corrective measures
BR conveying sensor 1/2 unreachable/stay jam (J49XX) Eject sensor non arrival jam (J50XX) Eject sensor stay jam (J51XX) DF paper entry error JAM (J600X)	5. Check contamination of the rollers of the bridge eject unit.	Clean or replace the rollers. 
	6. Check if the fixed hook part of the bridge eject unit is broken.	Replace the eject unit if damaged. 
	7. Check if the rail moutings of the bridge eject unit is broken.	Replace the eject unit if damaged. 
	8. Check contamination or abrasion of the axle holders of the bridge eject unit.	Clean the axle holder or replace with a new axle holder. 




Jam types	Check description	Corrective measures
BR conveying sensor 1/2 unreachable/stay jam (J49XX) Eject sensor non arrival jam (J50XX) Eject sensor stay jam (J51XX) DF paper entry error JAM (J600X)	9. Check if the pivot of the paper conveying guide of the bridge eject unit has fallen off.	Re-mount. 
	10. Check if the ribs of the conveying unit of the bridge eject unit have fallen off.	If a rig is broken, replace the conveying guide. 

Jam types	Check description	Corrective measures
<p>DF conveying sensor unreachable jam (J610X) DF conveying sensor retention jam (J611X)</p>	<p>1. Check the main unit and the DF are vertically flush with each other.</p>	<p>Perform the height adjustment by referring to the installation instructions.</p>  
	<p>2. Check if the upper conveying guide on the BR conveying unit has fallen off. (Fixing an anti-falling part)</p>	<p>Re-mount. (Fixing an anti-falling part)</p>  <p>A view of the AK (Bridge) Conveyance Unit Tray being opened</p> <p>Upper guide</p> <p>Lower guide</p>  <p>Affix fixing films (No. 1) at the two axles.</p> <p>No1</p> <p>Flixes (No. 1)</p> <p>Adhesive tape</p> <p>PET FILM t=0.1mm</p>

Jam types	Check description	Corrective measures
DF conveying sensor unreachable jam (J610X) DF conveying sensor retention jam (J611X)	3. Check if the jammed paper has a dog-ear.	<p>1.If the paper is caught at the hole of the bridge conveying unit and dog-eared and jammed, affix a sheet of film over the hole.</p>  <p>2.If a down-curved sheet is jammed at the DF conveying guide ribs by being dog-eared, replace the DF conveying lower guide.</p> 
	4. Check if dog-ears are caused within the punch unit.	<p>If the edge of paper is caught at the holes of the punch unit, check the punch unit and the firmware version of the DF using U019, and upgrade the firmware of both units altogether.3NK_9A00.003.004 or later, 3NB_9200.004.007or later, 3NC_9200.004.001 or later</p>
	5. Check if paper is caught at its leading edge to crumple.	<p>If a welding protrusion on the conveying side causes paper to be trapped, try replacing the punch unit.</p> 

Jam types	Check description	Corrective measures
DF conveying sensor unreachable jam (J610X) DF conveying sensor retention jam (J611X)	<p>6. If the paper is stuck in front of the conveying roller and it is not damaged, check if it is jammed because it was trapped at the stay punch.</p> 	<p>Affix sheets of PET film at the Stay Punch in two parts.</p>  
DF intermediate sensor retention jam (J631X) DF main tray ejection retention JAM (J641X) DF eject sensor non arrival jam (J6500) DF eject sensor retention jam (J651X)	<p>1. If there is not the jammed paper which is causing J631, at the paper processing area, check to see if the actuator (DF middle sensor) is operative.</p> 	<p>Re-mount the actuator.</p>

Jam types	Check description	Corrective measures
<p>DF intermediate sensor retention jam (J631X) DF main tray ejection retention JAM (J641X) DF eject sensor non arrival jam (J6500) DF eject sensor retention jam (J651X)</p>	<p>2. Check the range of the up and down movement of the ejection rollers. Check if the operating position after feeding in the first sheet is normal. (1)If it moves askew (due to the forward and backward shift of phase on the eject guide) (2)If the range of motion is too small Check if the gap between the ejection roller and the ejection pulleys is approximately 3.5 - 5.5 mm. (Check gaps while making paper still in the intermediate process tray.)</p>	<p>If the gap is not correct, fix balance of the bundle eject unit. If (1): Correct the phase shifting with meshing of the front and back gears. (Turn on U240 - Motor-EjectUnlock (30) to check the balance of the front and back rollers with the bundle eject unit opened.see page 1-3-122)</p>  <p>If (2): Adjust the positioning of or replace the Mount PI upper guide.</p> 
	<p>3. Execute maintenance mode U240 Motor - Width Test A3/LD to adjust the position of the width adjuster cursor of the process tray. Check if the cursor is located at 0 - +0.5 from the edge of is abnormally shifted. (The DF and the main unit paper sources) (see page 1-3-122)</p>	<p>If the width adjuster cursor is wrongly positioned, perform U246 Finisher - Width Front HP/Width Tail HP. (see page 1-3-130)</p>  

Jam types	Check description	Corrective measures
DF intermediate sensor retention jam (J631X) DF main tray ejection retention JAM (J641X) DF eject sensor non arrival jam (J6500) DF eject sensor retention jam (J651X)	4. Check if the dog-eared paper, under-curved paper, or the paper fed in a wrong timing is disturbed at the cursor and causing a sluck jam.	Replace the cursor with a new type. 
	5. Check if a slack jam and stapling problem has occurred while the paper entered the DF process tray due to the down-curl of the paper at duplex printing since the paper approaches the process tray.	If correcting dog-ears or curlings is not possible, apply two seats of film onto the plastic guides to support the paper ends during feeding. 
	6. With stapling at one point with about 65 sheets, check for the failure on the bundle when it is delivered in the shape of an arc. 	1. If a wire from the ejection motor is pinched by other component or a connector is loosely connected, correct. If a loss of synchronism is observed with the ejection motor due to lack of torque, replace the motor. 2. If paper slippage occurs due to the lack of pressure by the ejection rollers, check the pressure rollers (3, at the center) to see if the pressure is insufficient and replace or re-assemble. If a malfunction to encumber the ejection rollers to generate pressure is observed, correct.
	7. With stapling set at 2 points and about 50 sheets, run a test print and check the print bundle delivered for the failure on the direction of ejection and the front and back side, abrupt alignment, and overall alignment.	If the paper is curled, change the direction of loading paper or replace the paper.

Jam types	Check description	Corrective measures
DF intermediate sensor retention jam (J631X) DF main tray ejection retention JAM (J641X) DF eject sensor non arrival jam (J6500) DF eject sensor retention jam (J651X)	8. Check if a floated staple, buckling, or stapling at a wrong position is occurred. 9. Check stapling has been properly done if the paper bundle cannot be ejected causing J-6510. * : 4000-sheets finisher	Configure each of the cassettes for the weight of the paper loaded. Replace the paper. Adjust the stapling home position by U246 - Staple HP. (see page 1-3-130) Provide instructions with the following points emphasized. 1. Tap the paper to align its ends and load all the way into the cassette. 2. After settings, let go off of the paper. (Allows automatic ejection after stapling.) 3. Do not remove paper before the paper bundle is ejected once it is stapled.
DF drum sensor non arrival jam (J6600)	Paper is jammed with its leading edge caught by the diversion solenoid 1 in the middle of conveying paths.	Check the axle of the diverting solenoid is inserted all the way into the lever of the DF diverting solenoid 1, and insert the lever firmly if it is not.
DF drum sensor retention jam (J6610)	1. Check if the size and orientation of the original document and the paper used match.	If not agreed, load the paper bundle in the size and orientation configured for the cassette or the manual feed tray.
	2. Check to see if the actuator (DF drum sensor) is operative without hinderance.	If the return spring has been fallen off of the fixing position, fix it properly. If the actuator won't operate smoothly, replace.
Center-folding unit conveying retention JAM (J6710) Center-folding unit conveying retention JAM (J7710)	If paper is jammed before reaching the center-folding unit, check that the drive train gears are in mesh.	If the drive transmission gears are not in mesh, replace the pivot pin of the CF lock lever and the DF fixing pin.

(3) Paper jam at feeding from cassette**Electrical parts that could cause paper jam during paper travelling at the primary feeding (regist roller)**

Timing of detection

Jam code
J0501,J0511,J1301,J1311,J4001,J4011

Measures

Related parts	
Paper feed motor(PFM)	Registration sensor (RS)
Paper feed clutch 1(PFCL1)	Engine PWB (EPWB)
Assist clutch 1 (ACSL1)*2	Feed PWB 2 (FPWB2)
Middle clutch (MCL)*1 Middle motor (MM) *2	Feed PWB 1 (FPWB1)
Registration clutch (RCL)*1 Registration motor (RM)*2	
Feed sensor 1 (FS1)	
Middle sensor (MS)	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only.

J0501Checking procedure at the occurrence of	J0501Corrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Feed sensor 1 (FS1): Conduct connectivity check, mounting location, operation (U031)	Feed PWB 2 YC8-11
3	Paper feed clutch (PFCL1): Operation check (U032)	Feed PWB 2 YC4-1
4	Paper feed motor : Operation check (U030)	Feed PWB 2 YC2-3(RDY),1(REM)
5	Feed PWB 2: Replace	
6	Engine PWB : Replace	

J13X1Checking procedure at the occurrence of	J13X1Corrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Middle sensor (MS) : Conduct connectivity check, mounting location, operation (U031)	Feed PWB 2 YC8-9
3	Assist clutch 1 (ACSL1)* ² :Operation check (U032)	Feed PWB 2 YC10-1
4	Middle clutch (MCL)* ¹ : Middle motor (MM)* ² :Operation check (U032/30)	Feed PWB 2 YC7-14 / YC7-1 to 4
5	Feed PWB 2: Replace	
6	Engine PWB : Replace	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only.

J40X1Checking procedure at the occurrence of	J40X1Corrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Registration sensor (RS): Conduct connectivity check, mounting location, operation (U031) and U051 - Slack Margin Settings.	Feed PWB 2 YC7-12
3	Registration clutch (RCL)* ¹ Registration motor (RM)* ² : Operation check (U032/30)	Feed PWB 1 YC22-2 / YC25-1 to 4
4	Feed PWB 1 : Replace	
5	Engine PWB : Replace	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only.

(4) Paper jam at feeding from cassette 2**Electrical parts that could cause paper jam during paper travelling at the primary feeding (regist roller)**

Timing of detection

Jam code
J0502,J0512,J1302,J1312,J1502,J1512,J4001,J4011

Corrective Action

Related parts	
Paper feed motor(PFM)	Engine PWB (EPWB)
Paper feed clutch 2 (PFCL2)	Feed PWB 2 (FPWB2)
Assist clutch 1 (ACSL1)?ACSL2)*2	Feed PWB 1 (FPWB1)
Middle clutch (MCL)*1 Middle motor (MM)*2	
Registration clutch (RCL)*1 Registration motor (RM)*2	
Vertical conveying clutch (PCCL)	
Feed sensor 2 (FS2)	
Paper conveying sensor (PCS)	
Middle sensor (MS)	
Registration sensor (RS)	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only.

J05X2Checking procedure at the occurrence of	J05X2Corrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Feed sensor 1 (FS1): Conduct connectivity check, mounting location, operation (U031)	Feed PWB 2 YC8-23
3	Paper feed clutch (PFCL1): Operation check (U032)	Feed PWB 2 YC4-1
4	Paper feed motor : Operation check (U030)	Feed PWB 2 YC2-3(RDY), 5(REM)
5	Feed PWB 2: Replace	
6	Engine PWB : Replace	

J13X2Checking procedure at the occurrence of	J13X2Corrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Middle sensor (MS) : Conduct connectivity check, mounting location, operation (U031)	Feed PWB 2 YC8-9
3	Vertical conveying clutch (PCCL): Operation check (U032)	Feed PWB 2 YC5-3
4	Middle clutch (MCL) ^{*1} Middle motor (MM) ^{*2} ?Operation check (U032/30)	Feed PWB 2 YC7-14 / YC7-1 and 4
5	Feed PWB 2: Replace	
6	Engine PWB : Replace	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only

J15X2Checking procedure at the occurrence of	J15X2Corrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Conveying sensor (PCS) I/O check and sensor (U031) check	Feed PWB 2 YC6-3
3	Vertical conveying clutch (PCCL): Operation check (U032)	Feed PWB 2 YC5-3
4	Assist clutch 1 (ACSL1) ^{*2} ?Operation check (U032)	Feed PWB 2 YC12-1
5	Feed PWB 2: Replace	
6	Engine PWB : Replace	

*2: 45 ppm model /55 ppm model only.

J40X2Checking procedure at the occurrence of	J40X2Corrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Registration sensor (RS): Conduct connectivity check, mounting location, operation (U031) and U051 - Slack Margin Settings.	Feed PWB 2 YC7-12
3	Registration clutch (RCL) ^{*1} Registration motor (RM) ^{*2} : Operation check (U032/30)	Feed PWB 1 YC22-2 / YC25-1 to 4
4	Feed PWB 1 : Replace	

J40X2Checking procedure at the occurrence of	J40X2Corrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
5	Engine PWB : Replace	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only.

(5) Paper jam during manual feeding

Electrical parts that could cause paper jam during paper travelling at the primary feeding (regist roller)

Timing of detection

Jam code
J0131,J0509,J0519,J4009,J4019

Corrective Action

Related parts	
Paper feed motor(PFM)	Engine PWB (EPWB)
Manual feed clutch (MPPFCL)	Feed PWB 1 (FPWB1)
Middle clutch (MCL)* ¹ Middle motor (MM)* ²	Relay PWB (RYPWB) * : In paper conveying unit
Registration clutch (RCL)* ¹ Registration motor (RM)* ²	
MP feed sensor (MPFS)	
Registration sensor (RS)	
Manual feed lift motor (MPLM)	
MP lift sensor 1 (MPLS1)	
MP lift sensor 2 (MPLS2)	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only.

J05X9Checking procedure at the occurrence of	J05X9Corrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	MP feed sensor (MPFS): Conduct connectivity check, mounting location, operation (U031)	Feed PWB 1 YC17-9
3	Manual feed conveying clutch (CL): Operation check (U032)	Feed PWB 2 YC4-1

J05X9Checking procedure at the occurrence of	J05X9Corrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
4	Middle clutch (MCL) ^{*1} Middle motor (MM) ^{*2} ?Operation check (U032/30)	Feed PWB 2 YC7-14 / YC7-1 to 4
5	Feed PWB 2: Replace	
6	Engine PWB : Replace	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only.

J40X9Checking procedure at the occurrence of	J40X9Corrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Registration sensor (RS): Conduct connectivity check, mounting location, operation (U031)	Feed PWB 2 YC7-12
3	Registration clutch (RCL) ^{*1} Registration motor (RM) ^{*2} : Operation check (U032/30)	Feed PWB 1 YC22-2 / YC25-1 to 4
4	Feed PWB 1 : Replace	
5	Engine PWB : Replace	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only.

J0131Checking procedure at the occurrence of	J0131Corrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Manual feed lift base elevation check: 1. Up-and-down movability of the paper lift base of the manual feed tray. 2. Check if the lift lever is in contact with the lift motor cam (re-mount the manual feed table).	-
3	MP lift sensors 1 and 2: Check for connection and the position of the sensor to be mounted.	Relay PWB (YC3-5, YC3-8) (YC12)
4	MP lift motor: Check if the paper lift base is raised as the motor rotates.	Relay PWB(YC3-11), (YC12)
5	Feed PWB 1 : Replace	Feed PWB 1(YC17),(YC1)
6	Engine PWB : Replace	Engine PWB (YC6)

(6) Paper jam at the duplex re-feeding unit
Electrical parts that could cause paper jam during paper travelling at the primary feeding (regist roller)

Timing of detection

Jam code
J0508,J0518

Corrective Action

Related parts	
Paper feed motor(PFM) * : 30 ppm model /35 ppm model only.	Engine PWB (EPWB)
Duplex clutch 2 (DUCL2) ^{*1} Duplex motor 2 (DUM2) ^{*2}	Feed PWB 1 (FPWB1)
Duplex sensor 2 (DUS2)	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only.

Checking procedure at the occurrence of J05X8	J05X8 Corrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Duplex sensor 2 (DUS2): Conduct connectivity check, mounting location, operation (U031)	Feed PWB 1 YC 14-5
3	Duplex clutch 2 (DUCL2) ^{*1} Duplex motor 2 (DUM2) ^{*2} : Operation check (U032/30)	Feed PWB 1 YC 14-12 / YC14-14 to 17
4	Is the drive from the paper feed motor chanced to the lower duplex rollers? * : 30 ppm model /35 ppm model only.	
5	Feed PWB 1 : Replace	
6	Engine PWB : Replace	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only.

(7) Electrical parts that could cause paper jam at the Secondary transfer unit

Timing of detection

Jam code
J410x,J411x

Corrective Action

Related parts	
Paper feed motor(PFM) * : 30 ppm model /35 ppm model	Engine PWB (EPWB)
Secondary transfer roller - transfers the drive from the transfer belt	Feed PWB 1 (FPWB1)
Registration clutch (RCL) ^{*1} Registration motor (RM) ^{*2}	Relay PWB (RYPWB) * : In paper conveying unit
Loop sensor (LPS)	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only.

Checking procedure at the occurrence of J41XX	Corrective action at the occurrence of J41XX	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Loop sensor (LPS) : Conduct connectivity check, mounting location, operation (U031)	Feed PWB 1 YC23-11
3	Registration clutch (RCL) ^{*1} Registration motor (RM) ^{*2} : Operation check (U032/30)	Feed PWB 1 YC22-2 / YC25-1 to 4
4	Check that the drive from the transfer belt unit is transferred to the second transfer roller.	
5	Check that the drive from the paper feed motor is transferred to the regist roller. * : 30 ppm model /35 ppm model only	
6	Check how the conveying unit and the main unit drawer are connected (such as a fallen pin) and, if they are normal, replace the relay PWB.	
7	Feed PWB 1 : Replace	
8	Engine PWB : Replace	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only.

(8) Electrical parts that could cause paper jam at the fuser and eject parts

Timing of detection

Jam code
J420x,J421x,J460x,J461x,J470x,J471x

Corrective Action

Related parts	
Fuser motor (FUM)	Engine PWB (EPWB)
Eject motor (EM)	Front PWB (FRPWB)
Paddle solenoid C (FSSOLC)	
Fuser eject sensor (FUES)	
Eject full sensor (EFS)	
Switchback sensor (SBS)	
JS eject motor (JSEM) * : The job separator is installed.	

J42XXChecking procedure at the occurrence of	J42XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Fuser eject sensor (FUES) : Conduct connectivity check, mounting location, operation (U031)	Engine PWB YC26-A13
3	Paddle solenoid (FSSOL): Paddle guide check (U033)	Front PWB YC5-19
4	Fuser motor (FUM) : Operation check (U030)	Feed PWB 1 YC18-3(RDY), 5(REM)
5	Engine PWB : Replace	

J46XXChecking procedure at the occurrence of	J46XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Eject full sensor (EFS) : Conduct connectivity check, mounting location, operation (U031)	Front PWB YC5-16
3	Paddle solenoid (FSSOL): Paddle guide check (U033)	Front PWB YC5-19
4	Eject motor (EM) : Operation check (U030)	Front PWB YC5-8 to 11
5	Front PWB (FRPWB): Replace	
	Engine PWB : Replace	

J47XXChecking procedure at the occurrence of	J47XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Switchback sensor (SBS) : Conduct connectivity check, mounting location, operation (U031)	Front PWB YC5-13
3	Paddle solenoid (FSSOL): Paddle guide check (U033)	Front PWB YC5-19
4	Job separator eject motor (JSEM): Operational check (U030)	JJS main circuit PWB: YC2-4, 5, 6, 7, YC-1 Feed PWB 1: YC20
5	Engine PWB : Replace	Engine PWB : YC7 Front PWB : YC3

(9) Electrical parts that could cause paper jam at the duplex unit

Timing of detection

Jam code
J430x,J431x,J440x,J441x

Corrective Action

Related parts	
Paper feed motor(PFM) * : 30 ppm model /35 ppm model	Engine PWB (EPWB)
Duplex clutch 1 (DUCL1)* ¹ Duplex motor 1 (DUM1)* ²	Relay PWB (RYPWB) * : In paper conveying unit
Duplex clutch 2 (DUCL2)* ¹ Duplex motor 2 (DUM2)* ²	* : Feed PWB 1 (FPWB1)
Duplex sensor 1 (DUS1)	Feed PWB 1 (FPWB1) J440X
Duplex sensor 2 (DUS2)	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only.

J43XXChecking procedure at the occurrence of	J43XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Duplex sensor 1 (DUS1) : Conduct connectivity check, mounting location, operation (U031)	Feed PWB 1 YC23-1
3	Duplex clutch 1 (DUCL1)* ¹ Duplex motor 1 (DUM1)* ² : Operation check (U032/30)	Feed PWB 1 YC23-4 /YC23-6 to 9
4	Is the drive from the paper feed motor chanded to the upper and lower duplex rollers? * : 30 ppm model /35 ppm model only	
5	Check how the conveying unit and the main unit drawer are connected and, if they are normal, replace the feed circuit PWB1.	
6	Feed PWB 1(FPWB1) : relpace	
7	Engine PWB : Replace	
8	Relay PWB (RYPWB) : Replace	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only.

J44XXChecking procedure at the occurrence of	J44XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	Duplex sensor 2 (DUS2) : Conduct connectivity check, mounting location, operation (U031)	Feed PWB 1 YC14-5
3	Duplex clutch 2 (DUCL2) ^{*1} Duplex motor 2 (DUM2) ^{*2} : Operation check (U032/30)	Feed PWB 1 YC14-12 / YC14-14 to 17
4	Is the drive from the paper feed motor chanded to the upper and lower duplex rollers? * : 30 ppm model /35 ppm model only	
5	Check how the conveying unit and the main unit drawer are connected and, if they are normal, replace the feed circuit PWB1.	
6	Feed PWB 1(FPWB1) : relpace	
7	Engine PWB : Replace	
8	Relay PWB (RYPWB) : Replace	

*1: 30 ppm model /35 ppm model only. *2: 45 ppm model /55 ppm model only.

(10) Electrical parts that lead to a paper jam in the BR (bridge) part

Timing of detection

Jam code
J490x,J491x,J500x,J501x,J510x,J511x

Corrective Action

Related parts	
BR conveying motor 1 (BRCM1)	Engine PWB (EPWB)
BR conveying motor 2 (BRCM2)	BR PWB (BRPWB)
BR conveying sensor 1 (BRCS1)	
BR conveying sensor 2 (BRCS2)	
BR eject sensor 2 (BRES)	
BR paddle solenoid (BRSOL)	

J49XXChecking procedure at the occurrence of	J49XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	BR conveying sensor 1 (BRCS1) : Conduct connectivity check, mounting location, operation (U031)	BR PWB YC6-2
3	BR conveying motor 1 (BRCM1) : Operation check (U030)	BR PWB YC7-1 to 4
4	BR PWB (BRPWB) : Replace	
5	Engine PWB : Replace	

J50XXChecking procedure at the occurrence of	J50XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	BR conveying sensor 2 (BRCS2) : Conduct connectivity check, mounting location, operation (U031)	BR PWB YC4-2
3	BR conveying motor 2 (BRCM2) : Operation check (U030)	BR PWB YC7-5 to 8
4	BR PWB (BRPWB) : Replace	
5	Engine PWB : Replace	

J51XXChecking procedure at the occurrence of	J51XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	BR eject sensor 2 (BRES) : Conduct connectivity check, mounting location, operation (U031)	Engine PWB YC20-17
3	BR paddle solenoid (BRSOL): Check for switching paddle guide (U033)	Engine PWB YC20-17
4	BR PWB (BRPWB) : Replace	
5	Engine PWB : Replace	

(11) Electrical parts that could cause paper jam at the DF paper feeding part

Timing of detection

Jam code
J610x,J611x,J620x,J621x,J630x,J631x

Corrective Action

Related parts	
DF paper entry motor (DFPEM)	DF feedshift solenoid 3 (DFSSOL)
DF middle motor (DFMM)	DP main PWB (DFMPWB)
DF eject motor (DFEM)	
BR conveying motor 1 (BRCM1)	
BR conveying motor 2 (BRCM2)	
DF paper entry sensor (DFPES)	
DF middle sensor (DFMES)	
DF sub eject sensor (DFSES)	

J61XXChecking procedure at the occurrence of	J61XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	DF paper entry sensor (DFPES) : Conduct connectivity check, mounting location, operation (U241:Finisher HP)	DF main PWB YC21-9
3	DF paddle solenoid 3 (DFSSOL): Check to see the paddle guide 3 is switchable (U240 Solenoid - Subtray)	DF main PWB YC18-12,13
4	DF paper entry sensor (DFPES) : Operation check (U240 :Motor →Feed In(H),Feed In(L))	DF main PWB YC12-13 to 16
5	BR conveying motor 1 (BRCM1) , BR conveying motor 2 (BRCM2) : Operation check (U030 Bridge1 , Bridge2)	
6	DF main PWB(DFMPWB) : Replace	

J62XXChecking procedure at the occurrence of	J62XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27

J62XXChecking procedure at the occurrence of	J62XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
2	DF sub eject sensor (DFSES) : Conduct connectivity check, mounting location, operation (U241)	DF main PWB YC21-3
3	DF paddle solenoid 3 (DFSSOL): Check to see the paddle guide 3 is switchable (U240)	DF main PWB YC18-12,13
4	DF paper entry sensor (DFPES) : Operation check (U240)	DF main PWB YC12-13 to 16
5	DF eject motor (DFEM) : Operation check (U240)	DF main PWB YC12-5 to 8
6	DF main PWB(DFMPWB) : Replace	

J63XXChecking procedure at the occurrence of	J63XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	DF middle sensor (DFMES):Conduct connectivity check, mounting location, operation (U241)	DF main PWB YC20-6
3	DF paddle solenoid 3 (DFSSOL): Check to see the paddle guide 3 is switchable (U240)	DF main PWB YC18-12,13
4	DF paper entry sensor (DFPES) : Operation check (U240)	DF main PWB YC12-13 to 16
5	DF middle motor (DFMM) : Operation check (U240)	DF main PWB YC10-5 to 8
6	DF main PWB(DFMPWB) : Replace	

(12) Electrical parts that could cause paper jam at the DF process part

Timing of detection

Jam code
J6500,J651x,J6600,J6610,J630x,J631x

Corrective Action

Related parts	
DF middle motor (DFMM)	DF main PWB(DFMPWB)
DF drum motor (DFDRM)	
DF bundle eject sensor (DFBDS)	
DF drum sensor (DFDRS)	
DF paddle solenoid 1 (BRSOL)	

J65XXChecking procedure at the occurrence of	J65XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	DF middle sensor (DFMES):Conduct connectivity check, mounting location, operation (U241)	DF main PWB YC20-6
3	DF bundle eject sensor (DFBDS) : Conduct connectivity check, mounting location, operation (U241)	DF main PWB YC22-27
4	DF middle motor (DFMM) : Operation check (U240)	DF main PWB YC12-9 to 12
5	DF main PWB(DFMPWB) : Replace	

J66XXChecking procedure at the occurrence of	J66XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	DF drum sensor (DFDRS) : Conduct connectivity check, mounting location, operation (U241)	DF main PWB YC20-3
3	DF paddle solenoid 3 (DFPSSOL): Check to see the paddle guide 3 is switchable (U240)	DF main PWB YC18-12,13
4	DF drum motor (DFDRM) : Operation check (U240)	DF main PWB YC18-1 to 4

J66XXChecking procedure at the occurrence of	J66XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
5	DF main PWB(DFMPWB) : Replace	

(13) Electrical parts that lead to a paper jam in the DF eject tray

Timing of detection

Jam code
J640x,J641x

Corrective Action

Related parts	
DF eject motor (DFEM)	DF main PWB(DFMPWB)
DF tray motor (DFTM)	
DF middle sensor (DFMES)	
DF tray upper sensor 1 and 2	

J64XXChecking procedure at the occurrence of	J64XXCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	DF middle sensor (DFMES):Conduct connectivity check, mounting location, operation (U241)	DF main PWB YC20-6
3	DF tray upper sensor 1 and 2 (DFTUSS1, 2) : Conduct connectivity check, mounting location, operation (U241)	DF main PWB YC21-19(DFTUSS1),YC13-3(DFTUSS2)
4	DF eject motor (DFEM): Operational check (U240)	DF main PWB YC12-5 to 8
5	DF tray motor (DFTM) : Operation check (U240)	DF main PWB YC19-4
6	DF main PWB(DFMPWB) : Replace	

(14) Electrical parts that lead to a paper jam in the CF conveying part

Timing of detection

Jam code
J6710,J7700,J7710

Corrective Action

Related parts	
DF drum motor (DFDRM)	DF main PWB(DFMPWB)
CF paper entry motor (CFPEM)	CF PWB (CFPWB)
DF drum sensor (DFDRS)	
CF conveying sensor (CFPCS)	

J671XChecking procedure at the occurrence of	J671XCorrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	DF drum sensor (DFDRS) : Conduct connectivity check, mounting location, operation (U241)	DF main PWB YC20-3
3	DF drum motor (DFDRM) : Operation check (U240)	DF main PWB YC18-1 to 4
4	Check if the drive from the CF paper entry motor (CFPEM): Check if the gears can chain the drive.	CF PWB YC18-1 to 4
5	DF main PWB(DFMPWB) : Replace	
6	CF PWB (CFPWB): Replace	

Checking procedure at the occurrence of J77X0	J77X0Corrective action at the occurrence of	On/Off control signal output connector (terminal), point of checking connection
1	Items for Initial Checks	see page 1-4-27
2	CF conveying sensor (CFPCS) : Conduct connectivity check, mounting location check, operation check (U241)	CF PWB YC20-15
3	CF paper entry motor (CFPEM): Check if the gears can chain the drive.	CF PWB YC18-1 to 4
4	DF main PWB(DFMPWB) : Replace	
5	CF PWB (CFPWB): Replace	

1-4-3 Self-diagnostic function

(1) Self-diagnostic function

This machine is equipped with self-diagnostic function. When a problem is detected, the machine stops printing and display an error message on the operation panel. An error message consists of a message prompting a contact to service personnel and a four-digit error code indicating the type of the error.

(2) Self diagnostic codes

If the part causing the problem was not supplied, use the unit including the part for replacement

Caution:

Before attempting to check the power supply, fuser unit, and the IH controller PWB, be sure to turn the power switch off and unplug the machine from power. Allow at least 5 seconds before starting to conduct service until the capacitors on the circuit boards have been completely discharged.

To reset a service call for fuser, performing U163 Fuser Defects is required. (See page 1-3-105)

To reset a service call regarding the Maintenance T display and the DP, performing U906 Disconnection at Defect is required. (See page 1-3-201)

Code	Contents	Causes	Check procedures/ corrective measures
0030	FAX control PWB system error Processing with the fax software was disabled due to a hardware problem.	FAX control PWB	<ol style="list-style-type: none"> 1. Turn the main power switch off and after 5 seconds, re-mount the FAX controller PWB, then turn power on. 2. Reinstall the fax software. 3. Replace the FAX control PWB.
0070	FAX control PWB incompatible detection error Abnormal detection of FAX control PWB incompatibility In the initial communication with the FAX control PWB, any normal communication command is not transmitted.	FAX control PWB	<ol style="list-style-type: none"> 1. Install the FAX system designed for the model. 2. Reinstall the fax software.
0080	Option printing system device error. The version of the FPGA for Fiery control is not readable. (Defective FPGA)	Defective FPGA for printing system control.	<ol style="list-style-type: none"> 1. Turn the main power switch off and after 5 seconds, re-mount the FAX controller PWB, then turn power on. 2. Replace the main PWB (see page 1-5-59).
0100	Backup memory device error	EEPROM(main PWB)	<ol style="list-style-type: none"> 1. Turn the main power switch off and after 5 seconds, re-mount the FAX controller PWB, then turn power on. 2. Check that the EEPROM on the main circuit PWB is properly installed on the main circuit PWB and, if not, re-install it. 3. Replace the main PWB (see page 1-5-59).
0120	MAC address data error For data in which the MAC address is invalid.	Defective flash memory.	<ol style="list-style-type: none"> 1. Turn the main power switch off and after 5 seconds, re-mount the FAX controller PWB, then turn power on. 2. Check the MAC address on the network status page. 3. If it is blank, obtain an EEPROM with its MAC address written and install. 4. Replace the main PWB (see page 1-5-59).

Code	Contents	Causes	Check procedures/ corrective measures
0150	<p>Backup memory read/write error (engine PWB) No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated 5 times successively. Mismatch of reading data from 2 locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively.</p>	EEPROM	<ol style="list-style-type: none"> 1. Turn the main power switch off and after 5 seconds, re-mount the FAX controller PWB, then turn power on. 2. Check that the EEPROM is properly installed on the engine PWB and re-install it. 3. Replace the engine PWB (see page 1-5-64). 4. Check the EEPROM and if the data are corrupted, contact the service support.
0160	<p>Backup memory data error (engine PWB) Reading data from EEPROM is abnormal.</p>	EEPROM	<ol style="list-style-type: none"> 1. Turn the main power switch off and after 5 seconds, re-mount the FAX controller PWB, then turn power on. 2. Execute U021 - memory initializing.(see page 1-3-29) 3. If the EEPROM data are corrupted, contact the service support.
0170	<p>Billing counting error A checksum error is detected in the main and engine backup memories for the billing counters.</p>	EEPROM	<ol style="list-style-type: none"> 1. Check that the EEPROMs installed in the main PWB and the engine PWB are correct and, if not, use the correct EEPROM for the model. 2. If the EEPROM data are corrupted, contact the service support.
		Main PWB	Replace the main PWB (see page 1-5-59).
		Engine PWB	Replace the engine PWB (see page 1-5-64).
0180	<p>Machine number mismatch Machine number of main and engine does not match.</p>	Data damage of EEPROM.	<ol style="list-style-type: none"> 1. Confirm the machine data for the main and engine units by using U004 (see page 1-3-25). 2. If the serial number data of different models is alternately displayed, install the correct EEPROM in the PWB of the wrong serial number data. 3. Contact the Service Support.
0620	<p>FAX image DIMM error 1. The Fax image DIMM has not been installed. 2. Fax image DIMM access error.</p>	DIMM installed incorrectly.	<ol style="list-style-type: none"> 1. Install the FAX image DIMM supplied in the FAX system onto the main PWB. 2. Firmly install the FAX image DIMM again onto the main board. 3. Check the FAX image DIMM and remove any foreign objects that may be adhered to it. 4. Replace with a new FAX image DIMM.
		Main PWB.	Replace the main PWB (see page 1-5-59).

Code	Contents	Causes	Check procedures/ corrective measures
0630	DMA error DMA transmission of image data does not complete within the specified period of time.	DP CIS	<ol style="list-style-type: none"> 1. Reconnect the CIS signal line. 2. Confirm that the CIS connector terminals are firmly connected and connect the connector all the way in. Insert the connector all the way in. 3. If the wiring is disconnected, shorted or grounded, replace the wiring.
		DP main PWB Main PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. 2. If the wiring is disconnected, shorted or grounded, replace the wiring. Wiring that connects the CIS and the DP controller PWB. Wiring that connects the DP main PWB and the main PWB. 3. Replace the DP main PWB. 4. Replace the main PWB (see page 1-5-59).
0640	Hard disk error The hard disk cannot be accessed.	HDD	<ol style="list-style-type: none"> 1. If an abnormal noise is heard from the HDD, replace the HDD. 2. Check the SATA wiring between the HDD and the main circuit PWB for loose connection, disconnection and damages, and that it is connected into the correct terminal. Main PWB: YC1, YC27 3. Replace the SATA cable. 4. Execute U024 to initialize (FULL) the HDD (see page 1-3-30). 5. If an error is detected after executing U024, replace the HDD.
		Main PWB	Replace the main PWB (see page 1-5-59).
0650	FAX image DIMM check error A fax image DIMM which was used with another machine is installed.	FAX DIMM.	<ol style="list-style-type: none"> 1. Confirm that a used FAX image DIMM was used instead of the FAX image DIMM contained in the FAX system. 2. If a DIMM that was used with other unit has been installed, execute maintenance mode U671 - Recovery FAX DIMM. 3. Check whether the Fax DIMM is properly inserted into the socket on the main PWB. 4. Replace with a new FAX image DIMM.
		Main PWB	Replace the main PWB (see page 1-5-59).

Code	Contents	Causes	Check procedures/ corrective measures
0800	Image processing error JAM010X is detected twice.	Main PWB	Replace the main PWB (see page 1-5-59).
0830	FAX control PWB flash program area checksum error A checksum error occurred with the program of the FAX control PWB.	FAX software	1. Reinstall the fax software.
		FAX control PWB	1. Execute initializing by U600.(Refer to the FAX service manual) 2. Replace the FAX control PWB.
0840	Faults of RTC (Maintenance T is displayed) The time is judged to go back based on the comparison of the RTC time and the current time or five years or more have passed. After C840 is detected, the machine enters in disconnection mode after the main power switch has been switched on and off and indicates 'Maintenance T.'	Battery (main PWB)	1. Make sure that the back-up batteries on the main PWB are not short-circuited. 2. Reset Maintenance T by executing U906 (see page 1-3-201). 3. If the same C call is displayed when power is switched on and off, replace the back up battery. 4. If communication error (due to a noise, etc.) is present with the RTC on the main circuit PWB, check the PWB is properly grounded.
		Main PWB	Replace the main PWB (see page 1-5-59).
0870	FAX control PWB to main PWB high capacity data transfer error High-capacity data transfer between the FAX control PWB and the main PWB of the machine was not normally performed even if the data transfer was retried the specified times.	FAX control PWB	1. Turn the main power switch off and after 5 seconds, re-mount the FAX controller PWB, then turn power on. 2. Replace the FAX control PWB.
		HDD	Execute U024 to initialize the HDD (see page 1-3-30).
		Main PWB	Replace the main PWB (see page 1-5-59).
0920	Fax file system error The backup data is not retained for file system abnormality of flash memory of the FAX control PWB.	FAX control PWB	1. Execute initializing by U600 (Refer to the FAX service manual). 2. Replace the FAX control PWB.
0970	12 V power down detect Detection of the temporary blackout during sleeping (24V is off, 23V is on, only the controller software is running)	Power source PWB	1. Check the +12V output is given at YC14 of the power source PWB. 2. Replace the power source PWB (see page 1-5-66).
0980	24 V power down detect 24V disconnection signal is detected for 1 s and 12V disconnection signal is not detected.	Power source PWB	1. Check the +24V output is given at YC9 (30/35 ppm) or YC12 (45/55 ppm) of the power circuit PWB. 2. Replace the power source PWB (see page 1-5-66)

Code	Contents	Causes	Check procedures/ corrective measures
1000	MP lift motor error If the MP lift sensor 1 (upper limit detect) or 2 (bottom detect) is not detectable to be turned on while the MP lift motor is ascending or descending.	Manual feed lift base elevating mechanism	<ol style="list-style-type: none"> 1. Check that the paper lift base of the manual feed tray can smoothly ascend and descent, if not, repair or replace. 2. Check that the lift lever is located so that it can ascend or descend by the lift motor cam and that it not damaged and, if necessary, re-install or replace the manual feed table.
		MP lift motor	<ol style="list-style-type: none"> 1. Check that the paper elevator has been ascended. 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. MP lift motor and Relay PWB (YC3) Relay PWB (YC12) and Feed PWB1 (YC17) Feed PWB1 (YC1) and Engine PWB (YC6) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the MP lift motor.
		MP lift sensor1 MP lift sensor2	<ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. MP lift sensor1,2 and Relay PWB (YC3) Relay PWB (YC12) and Feed PWB1(YC17) Feed PWB1 (YC1) and Engine PWB (YC6) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the MP lift sensor1 or MP lift sensor2.
		Feed PWB 2	Replace the Feed PWB 2.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
1010	Lift motor 1 error After cassette 1 is inserted, lift sensor 1 does not turn on within 12 s. This error is detected 5 times successively. The lock signal of the motor is detected continuously for 1 s. This error is detected 5 times successively.	Cassette lift base elevating mechanism	Check that the cassette base can be manipulated smoothly, if not, repair or replace.
		Lift motor 1	<ol style="list-style-type: none"> 1. Check that the cassette base has been ascended. 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Lift motor 1 and Feed PWB 2 (YC3) Feed PWB 2 (YC1) and Engine PWB (YC4) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the lift motor 1.
		Lift sensor 1	<ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Lift sensor 1 and Feed PWB 2 (YC8) Feed PWB 2 (YC1) and Engine PWB (YC4) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the lift sensor1.
		Feed PWB 2	Replace the Feed PWB 2.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
1020	Lift motor 2 error After cassette 2 is inserted, lift sensor 2 does not turn on within 12 s. This error is detected 5 times successively. The lock signal of the motor is detected continuously for 1 s. This error is detected 5 times successively.	Cassette lift base elevating mechanism	Check that the cassette base can be manipulated smoothly, if not, repair or replace.
		Lift motor 2	<ol style="list-style-type: none"> 1. Check that the cassette base has been ascended. 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Lift motor 2 and Feed PWB 2 (YC3) Feed PWB 2 (YC1) and Engine PWB (YC4) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the lift motor 2.
		Lift sensor 2	<ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Lift sensor 2 and Feed PWB 2 (YC8) Feed PWB 2 (YC1) and Engine PWB (YC4) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the lift sensor2.
		Feed PWB 2	Replace the Feed PWB 2.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
1030	PF lift motor 1 error (paper feeder) After cassette 3 is inserted, PF lift sensor 1 does not turn on within 12 s. This error is detected 5 times successively. During driving the motor, the lift overcurrent protective monitor signal is detected for 1 s or more 5 times successively. However, the first 1 s after motor is turned on is excluded from detection.	Cassette lift base elevating mechanism	Check that the cassette base can be manipulated smoothly, if not, repair or replace.
		PF Lift motor 1	<ol style="list-style-type: none"> 1. Check that the cassette base has been ascended. 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF Lift motor 1 and main PWB (YC7) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. PFReplace the lift motor 1.
		PF Lift sensor 1	<ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF Lift sensor 1 and PF main PWB (YC7) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the lift sensor 1.
		PF main PWB	Replace the PF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
1040	PF lift motor 2 error (paper feeder) After cassette 4 is inserted, PF lift sensor 2 does not turn on within 12 s. This error is detected 5 times successively. During driving the motor, the lift overcurrent protective monitor signal is detected for 1 s or more 5 times successively. However, the first 1 s after motor is turned on is excluded from detection.	Cassette lift base elevating mechanism	Check that the cassette base can be manipulated smoothly, if not, repair or replace.
		PF Lift motor 2	1. Check that the cassette base has been ascended. 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF Lift motor 2 and PF main PWB (YC7) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the PF Lift motor2.
		PF Lift sensor 2	1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF Lift sensor 2 and PF main PWB (YC7) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the PF Lift sensor 2.
		PF main PWB	Replace the PF main PWB (Refer to the service manual for the paper feeder).

Code	Contents	Causes	Check procedures/ corrective measures
1050	SM lift motor error (side multi tray) [45 ppm/55 ppm model] After cassette 5 is inserted, SM lift sensor does not turn on within 12 s. This error is detected 5 times successively. (Time to detect is 2 seconds at the second time and later.) During driving the motor, the lift overcurrent protective monitor signal is detected for 1 s or more 5 times successively. However, the first 1 s after motor is turned on is excluded from detection.	Cassette lift base elevating mechanism	Check that the cassette base can be manipulated smoothly, if not, repair or replace.
		SM Lift motor	1. Check that the cassette base has been ascended. 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. SM Lift motor and SM main PWB (YC5) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the SM Lift motor.
		SM Lift sensor	1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. SM Lift sensor and SM main PWB (YC7) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the SM Lift sensor.
		SM main PWB	Replace the SM main PWB (Refer to the service manual for the paper feeder).

Code	Contents	Causes	Check procedures/ corrective measures
1060	PF lift motor 1 error (side paper feeder) [45 ppm/55 ppm model] After cassette 6 is inserted, PF lift sensor 1 does not turn on within 12 s. This error is detected 5 times successively. (Time to detect is 2 seconds at the second time and later.) During driving the motor, the lift overcurrent protective monitor signal is detected for 1 s or more 5 times successively. However, the first 1 s after motor is turned on is excluded from detection. *:The software over-current protection monitor signal has been detected for 200ms or longer where LFC is installed.	Cassette lift base elevating mechanism	Check that the cassette base can be manipulated smoothly, if not, repair or replace.
		PF Lift motor 1	1. Check that the cassette base has been ascended. 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF Lift motor 1 and PF main PWB (YC7) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the lift motor 1.
		PF Lift sensor 1	1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF Lift sensor1 and PF main PWB (YC5) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the lift sensor 1.
		PF main PWB	Replace the PF main PWB (Refer to the service manual for the paper feeder).

Code	Contents	Causes	Check procedures/ corrective measures
1070	<p>PF lift motor 2 error (side paper feeder) [45 ppm/55 ppm model]</p> <p>After cassette 7 is inserted, PF lift sensor 2 does not turn on within 12 s. This error is detected 5 times successively. (Time to detect is 2 seconds at the second time and later.)</p> <p>During driving the motor, the lift overcurrent protective monitor signal is detected for 1 s or more 5 times successively. However, the first 1 s after motor is turned on is excluded from detection.</p> <p>*:The software over-current protection monitor signal has been detected for 200ms or longer where LFC is installed.</p>	Cassette lift base elevating mechanism	Check that the cassette base can be manipulated smoothly, if not, repair or replace.
		PF Lift motor2	<ol style="list-style-type: none"> 1. Check that the cassette base has been ascended. 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF Lift motor 2 and PF main PWB (YC7) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the PF Lift motor2.
		PF Lift sensor2	<ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF Lift sensor 2 and PF main PWB (YC4) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. PFReplace the lift sensor2.
		PF main PWB	Replace the PF main PWB (Refer to the service manual for the paper feeder).

Code	Contents	Causes	Check procedures/ corrective measures
1100	<p>PF lift motor 1 error (large capacity feeder) After cassette 3 is inserted, PF lift sensor 1 does not turn on within 23 s. This error is detected 5 times successively. (Time to detect is 2 seconds at the second time and later.) During driving the motor, the lift overcurrent protective monitor signal is detected for 200 ms or more 5 times successively. However, the first 1 s after PF lift motor 1 is turned on is excluded from detection.</p>	Paper feeder lift base elevating mechanism	Check that the cassette base can be manipulated smoothly, if not, repair or replace.
		PF Lift motor1	<ol style="list-style-type: none"> 1. Check that the cassette base has been ascended. 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF Lift motor 1 and PF main PWB (YC7) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the PF lift motor1.
		PF Lift sensor1	<ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF Lift sensor 1 and PF main PWB (YC5) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the PF lift sensor1.
		PF main PWB	Replace the PF main PWB (Refer to the service manual for the paper feeder).

Code	Contents	Causes	Check procedures/ corrective measures
1110	PF lift motor 2 error (large capacity feeder) After cassette 4 is inserted, PF lift sensor 2 does not turn on within 23 s. This error is detected 5 times successively. (Time to detect is 2 seconds at the second time and later.) During driving the motor, the lift overcurrent protective monitor signal is detected for 200 ms or more 5 times successively. However, the first 1 s after PF lift motor 2 is turned on is excluded from detection.	Paper feeder lift base elevating mechanism	Check that the cassette base can be manipulated smoothly, if not, repair or replace.
		PF Lift motor 2	<ol style="list-style-type: none"> 1. Check that the cassette base has been ascended. 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF Lift motor 2 and PF main PWB (YC7) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the PF Lift motor2.
		PF Lift sensor2	<ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF Lift sensor2 and PF main PWB (YC4) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the PF Lift sensor 2.
		PF main PWB	Replace the PF main PWB (Refer to the service manual for the paper feeder).
1140	SD lift motor error (side deck) After cassette 5 is inserted, SD lift sensor does not turn on within 30 s. The lock signal of the motor is detected continuously for 200 ms.	Paper feeder lift base elevating mechanism	Check that the cassette base can be manipulated smoothly, if not, repair or replace.
		SD Lift motor	<ol style="list-style-type: none"> 1. Check that the cassette base has been ascended. 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. SD Lift motor and SD main PWB (YC8) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the SD Lift motor.

Code	Contents	Causes	Check procedures/ corrective measures
1140		SD Lift sensor	<ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. SD Lift sensor and SD main PWB (YC5) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the SD Lift sensor.
		SD main PWB	Replace the SD main PWB (Refer to the service manual for the paper feeder).
1250	SM multi feed sensor communication error (side multi tray) [45 ppm/55 ppm model] A communication error is detected 3 times in succession.	Side multi tray	Check the wiring connection status with the main unit and, if necessary, try connecting it again.
		SM main PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. SM main PWB (YC1) and Engine PWB (YC19) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the PF main PWB (Refer to the service manual for the paper feeder).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
1350	SM multi feed sensor error (side multi tray) [45 ppm/55 ppm model] The SM multi feed sensor has detected multi feeding 5 times successively.	SM multi feed sensor	<ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. SM multi feed sensor and SM main PWB (YC11) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the SM multi feed sensor.
		SM main PWB	Replace the PF main PWB (Refer to the service manual for the paper feeder).

Code	Contents	Causes	Check procedures/ corrective measures
1400	Rotary guide motor error The guide sensor is not detected to be on at the home position detection with the rotary guide for three times in a row.	Rotary guide motor	<ol style="list-style-type: none"> 1. Check the rotary guide and drive gear can rotate or they are not unusually loaded and, if necessary, replace. 2. Confirm that the wiring connector is firmly connected and, if necessary, connect the connector all the way in. Rotary guide motor and BR PWB (YC5) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the rotary guide motor.
		BR PWB	Replace the BR PWB.
1450	SM multi feed sensor backup error (side multi tray) [45 ppm/55 ppm model] When writing the data, read and write data does not match 3 times in succession. Deleting a block has failed three times in a row. Writing won't complete in 200 ms after writing has commenced.	SM multi feed sensor	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. SM multi feed sensor and SM main PWB (YC11) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the SM multi feed sensor.
		SM main PWB	Replace the PF main PWB (Refer to the service manual for the paper feeder).
1710	Side multi tray incompatible detection error [30 ppm/35 ppm model] The side multi tray has been installed with a device to which it is incompatible.	The side multi tray is installed with a device to which it is incompatible.	Install the side multi-tray with the target model.
1800	Paper feeder communication error A communication error from paper feeder is detected 10 times in succession.	Paper feeder	Check the wiring connection status with the main unit and, if necessary, try connecting it again.
		PF main PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF main PWB (YC13) and Engine PWB (YC19) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the PF main PWB (Refer to the service manual for the paper feeder).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
1810 Side multi tray communication error [45 ppm/55 ppm model] A communication error from paper feeder is detected 10 times in succession.		Side multi tray	Check the wiring connection status with the main unit and, if necessary, try connecting it again.
		SM main PWB	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. SM main PWB (YC1) and Engine PWB (YC19) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the PF main PWB (Refer to the service manual for the paper feeder).
		Engine PWB	Check the engine software and upgrade to the latest, if necessary. Replace the engine PWB (see page 1-5-64).
		SM main PWB	Replace the PF main PWB (Refer to the service manual for the paper feeder).
1820 Side paper feeder communication error [45 ppm/55 ppm model] A communication error from paper feeder is detected 10 times in succession.		Side paper feeder	Check the wiring connection status with the main unit and, if necessary, try connecting it again.
		SM main PWB	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. SM main PWB (YC1) and Engine PWB (YC19) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the PF main PWB (Refer to the service manual for the paper feeder).
		PF main PWB	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF main PWB (YC13) and SM main PWB (YC4) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the PF main PWB (Refer to the service manual for the paper feeder).
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
1900	Paper feeder EEPROM error When writing the data, read and write data does not match 3 times in succession.	PF main PWB (EEPROM)	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. 2. Replace the PF main PWB (Refer to the service manual for the paper feeder).
1910	Side multi tray EEPROM error [45 ppm/55 ppm model] When writing the data, read and write data does not match 3 times in succession.	SM main PWB (EEPROM)	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. 2. Replace the PF main PWB (Refer to the service manual for the paper feeder).
1920	Side paper feeder EEPROM error [45 ppm/55 ppm model] When writing the data, read and write data does not match 3 times in succession.	PF main PWB (EEPROM)	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. 2. Replace the PF main PWB (Refer to the service manual for the paper feeder).
1950	Transfer belt unit EEPROM error No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated 5 times successively. Mismatch of reading data from 2 locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively.	Transfer belt sensor (EEPROM)	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Engine PWB (YC27) and RFID PWB (4P connector) (Check wirings on the RFID side since the signal line for the intermediate transfer belt sensor EEPROM on the engine PWB and the signal line for the toner container RFID are the same.) Transfer belt unit and Engine PWB (YC3) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the transfer belt unit (see page 1-5-53).

Code	Contents	Causes	Check procedures/ corrective measures
2101	Developer motor K error After developer motor K is driven, the ready signal does not turn to L within 5 s. After developer motor K is stabilized, the ready signal is at the H level for 5 s continuously.	Developer unit K	<ol style="list-style-type: none"> 1. Check that the developer waste lock has been released and, if not, release the lock (see page 1-2-12). 2. Check that the gears and spiral screw of the developer unit are not damaged. 3. Confirm that the developer roller can rotate. 4. If it won't rotate, replace the developer unit (see page 1-5-44).
		Developer motor K	<ol style="list-style-type: none"> 1. To check the motor operation, execute DLP(K) by U030 motor operation check (see page 1-3-31). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer motor K and Motor control PWB (YC7) Motor control PWB (YC3) and Engine PWB (YC9) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the Developer motor K.
		Motor control PWB	Replace the Motor control PWB
		Engine PWB.	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2103	Developer motor MCY error After developer motor MCY is driven, the ready signal does not turn to L within 5 s. After developer motor MCY is stabilized, the ready signal is at the H level for 5 s continuously.	Developer unit MCY	<ol style="list-style-type: none"> 1. Check that the developer waste lock has been released and, if not, release the lock (see page 1-2-12). 2. Check that the gears and spiral screw of the developer unit are not damaged. 3. Confirm that the developer roller can rotate. 4. If it won't rotate, replace the developer unit (see page 1-5-44).
		Developer motor MCY	<ol style="list-style-type: none"> 1. To check the motor operation, execute DLP(MCY) by U030 motor operation check (see page 1-3-31). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer motor MCY and Motor control PWB (YC7) Motor control PWB (YC3) and Engine PWB (YC9) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the Developer motor MCY.
		Motor control PWB	Replace the Motor control PWB
		Engine PWB.	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2201	Drum motor K steady-state error After drum motor K is stabilized, the ready signal is at the H level for 5 s continuously.	Drum unit	<ol style="list-style-type: none"> To check the motor operation, execute Belt Mean (transfer motor) by U030 motor operation check. (see page 1-3-31) Confirm that the drum or the drum screw can rotate. If it won't rotate, replace the drum unit. (see page 1-5-44)
		Drum motor K	<ol style="list-style-type: none"> Execute U030 Belt Mean Drum Motor and check that the drum motor can rotate (see page 1-3-31). Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Drum motor K and Motor control PWB (YC5) Motor control PWB (YC3) and Engine PWB (YC9) If the wiring is disconnected, shorted or grounded, replace the wiring. Replace the drum motor K (see page 1-5-80).
		Motor control PWB	Replace the Motor control PWB
		Engine PWB	<ol style="list-style-type: none"> Check the engine software and upgrade to the latest, if necessary. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2202	Drum motor C steady-state error [45 ppm/55 ppm model] After drum motor C is stabilized, the ready signal is at the H level for 5 s continuously.	Drum unit	1. To check the motor operation, execute Belt Mean (transfer motor) by U030 motor operation check (see page 1-3-31). 2. Confirm that the drum or the drum screw can rotate. 3. If it won't rotate, replace the drum unit. (see page 1-5-44)
		Drum motor C	1. Execute U030 Belt Mean Drum Motor and check that the drum motor can rotate (see page 1-3-31). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Drum motor C and Motor control PWB (YC4) Motor control PWB (YC3) and Engine PWB (YC9) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the Drum motor C (see page 1-5-80).
		Motor control PWB	Replace the Motor control PWB
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2203	Drum motor MCY steady-state error [30 ppm/35 ppm model] After drum motor MCY is stabilized, the ready signal is at the H level for 5 s continuously.	Drum unit	<ol style="list-style-type: none"> 1. To check the motor operation, execute Belt Mean (transfer motor) by U030 motor operation check (see page 1-3-31). 2. Confirm that the drum or the drum screw can rotate. 3. If it won't rotate, replace the drum unit (see page 1-5-44).
		Drum motor MCY	<ol style="list-style-type: none"> 1. Execute U030 Belt Mean Drum Motor and check that the drum motor can rotate (see page 1-3-31). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Drum motor MCY and Motor control PWB (YC5) Motor control PWB (YC3) and Engine PWB (YC9) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the Drum motor MCY (see page 1-5-80).
		Motor control PWB	Replace the Motor control PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2203	Drum motor M steady-state error [45 ppm/55 ppm model] After drum motor M is stabilized, the ready signal is at the H level for 5 s continuously.	Drum unit	<ol style="list-style-type: none"> 1. To check the motor operation, execute Belt Mean (transfer motor) by U030 motor operation check (see page 1-3-31). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Decrease Vpp using U100. Change set ac gain of U100 from Auto to mode1. (see page 1-3-70) 4. Confirm that the drum or the drum screw can rotate. 5. If it won't rotate, replace the drum unit (see page 1-5-44).
		Drum motor M	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Drum motor M and Motor control PWB (YC5) Motor control PWB (YC3) and Engine PWB (YC9) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Drum motor MCY (see page 1-5-80).
		Motor control PWB	Replace the Motor control PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2204	Drum motor Y steady-state error [45 ppm/55 ppm model] After drum motor Y is stabilized, the ready signal is at the H level for 5 s continuously.	Drum unit	<ol style="list-style-type: none"> 1. To check the motor operation, execute Belt Mean (transfer motor) by U030 motor operation check (see page 1-3-31). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Decrease Vpp using U100. Change set ac gain of U100 from Auto to mode1. (see page 1-3-70) 4. Confirm that the drum or the drum screw can rotate. 5. If it won't rotate, replace the drum unit (see page 1-5-44).
		Drum motor Y	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Drum motor Y and Motor control PWB (YC4) Motor control PWB (YC3) and Engine PWB (YC9) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Drum motor Y (see page 1-5-80).
		Motor control PWB	Replace the Motor control PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2211	Drum motor K startup error Drum motor K is not stabilized within 5 s since the motor is activated.	Drum unit	<ol style="list-style-type: none"> 1. To check the motor operation, execute Belt Mean (transfer motor) by U030 motor operation check (see page 1-3-31). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Decrease Vpp using U100. Change set ac gain of U100 from Auto to mode1. (see page 1-3-70) 4. Confirm that the drum or the drum screw can rotate. 5. If it won't rotate, replace the drum unit (see page 1-5-44).
		Drum motor K	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Drum motor K and Motor control PWB (YC5) Motor control PWB (YC3) and Engine PWB (YC9) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Drum motor K (see page 1-5-80).
		Motor control PWB	Replace the Motor control PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2212	Drum motor C startup error [45 ppm/55 ppm model] Drum motor C is not stabilized within 5 s since the motor is activated.	Drum unit	<ol style="list-style-type: none"> 1. To check the motor operation, execute Belt Mean (transfer motor) by U030 motor operation check (see page 1-3-31). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Decrease Vpp using U100. Change set ac gain of U100 from Auto to mode1. (see page 1-3-70) 4. Confirm that the drum or the drum screw can rotate. 5. If it won't rotate, replace the drum unit (see page 1-5-44).
		Drum motor C	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Drum motor C and Motor control PWB (YC4) Motor control PWB (YC3) and Engine PWB (YC9) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Drum motor C (see page 1-5-80).
		Motor control PWB	Replace the Motor control PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2213	Drum motor MCY startup error [30 ppm/35 ppm model] Drum motor MCY is not stabilized within 5 s since the motor is activated.	Drum unit	<ol style="list-style-type: none"> 1. To check the motor operation, execute Belt Mean (transfer motor) by U030 motor operation check (see page 1-3-31). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Decrease Vpp using U100. Change set ac gain of U100 from Auto to mode1. (see page 1-3-70) 4. Confirm that the drum or the drum screw can rotate. 5. If it won't rotate, replace the drum unit (see page 1-5-44).
		Drum motor MCY	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Drum motor MCY and Motor control PWB (YC5) Motor control PWB (YC3) and Engine PWB (YC9) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Drum motor MCY (see page 1-5-80).
		Motor control PWB	Replace the Motor control PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2213	Drum motor M startup error [45 ppm/55 ppm model] Drum motor M is not stabilized within 5 s since the motor is activated.	Drum unit	<ol style="list-style-type: none"> 1. To check the motor operation, execute Belt Mean (transfer motor) by U030 motor operation check (see page 1-3-31). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Decrease Vpp using U100. Change set ac gain of U100 from Auto to mode1. (see page 1-3-70) 4. Confirm that the drum or the drum screw can rotate. 5. If it won't rotate, replace the drum unit (see page 1-5-44).
		Drum motor M	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Drum motor M and Motor control PWB (YC5) Motor control PWB (YC3) and Engine PWB (YC9) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Drum motor MCY (see page 1-5-80).
		Motor control PWB	Replace the Motor control PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2214	Drum motor Y startup error [45 ppm/55 ppm model] Drum motor Y is not stabilized within 5 s since the motor is activated.	Drum unit	<ol style="list-style-type: none"> 1. To check the motor operation, execute Belt Mean (transfer motor) by U030 motor operation check (see page 1-3-31). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Decrease Vpp using U100. Change set ac gain of U100 from Auto to mode1. (see page 1-3-70) 4. Confirm that the drum or the drum screw can rotate. 5. If it won't rotate, replace the drum unit (see page 1-5-80).
		Drum motor Y	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Drum motor Y and Motor control PWB (YC4) Motor control PWB (YC3) and Engine PWB (YC9) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Drum motor Y (see page 1-5-80).
		Motor control PWB	Replace the Motor control PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2300	Fuser motor error After fuser motor is driven, the ready signal does not turn to L within 2 s. After fuser motor is stabilized, the ready signal is at the H level for 1 s continuously.	Fuser motor	<ol style="list-style-type: none"> 1. Execute Fuser (Fuser motor) by U030 motor operation check (see page 1-3-31). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. fuser motor and Feed PWB 1(YC18) Feed PWB 1(YC1) and Engine PWB (YC6) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the fuser motor (see page 1-5-87).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
		Feed PWB 1	Replace the Feed PWB 1.
		Fuser unit	Replace the fuser unit (see page 1-5-55).
2500	Paper feed motor error After paper feed motor is driven, the ready signal does not turn to L within 2 s. After paper feed motor is stabilized, the ready signal is at the H level for 1 s continuously.	Paper feed motor	<ol style="list-style-type: none"> 1. Execute Feed (paper feed motor) by U030 motor operation check (see page 1-3-31). 2. Check the paper feed roller and drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Paper feed motor and Feed PWB 2(YC2) Feed PWB 2(YC1) and Engine PWB (YC4) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the paper feed motor.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2600	PF paper feed motor error (large capacity feeder) After PF paper feed motor is driven, the ready signal does not turn to L within 2 s.	PF paper feed motor	<ol style="list-style-type: none"> 1. Execute LCF - Motor ON of U247 feed unit operation check (see page 1-3-136). 2. Check the paper feed roller and drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF paper feed motor and PF main PWB (YC16) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the paper feed motor.
		PF main PWB	Replace the PF main PWB (Refer to the service manual for the paper feeder).
2610	PF paper feed motor error (paper feeder) [45 ppm/55 ppm model] After PF paper feed motor is driven, the ready signal does not turn to L within 2 s.	PF paper feed motor	<ol style="list-style-type: none"> 1. Execute 2PF - Motor ON of U247 feed unit operation check (see page 1-3-136). 2. Check the paper feed roller and drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF paper feed motor and PF main PWB (YC16) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the paper feed motor.
		PF main PWB	Replace the PF main PWB (Refer to the service manual for the paper feeder).

Code	Contents	Causes	Check procedures/ corrective measures
2640	SD paper feed motor error (side deck) [45 ppm/55 ppm model] After SD paper feed motor is driven, the ready signal does not turn to L within 2 s.	SD paper feed motor	<ol style="list-style-type: none"> 1. Execute Side deck - Motor ON of U247 feed unit operation check (see page 1-3-136). 2. Check the paper feed roller and drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. SD paper feed motor and SD main PWB (YC16) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the SD paper feed motor.
		SD main PWB	Replace the SD main PWB (Refer to the service manual for the paper feeder).
2650	SM paper feed motor error (side multi tray) [45 ppm/55 ppm model] After SM paper feed motor is driven, the ready signal does not turn to L within 2 s.	SM paper feed motor	<ol style="list-style-type: none"> 1. Execute SMT - Motor ON of U247 feed unit operation check (see page 1-3-136). 2. Check the paper feed roller and drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. SM paper feed motor and SM main PWB (YC5) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the SD paper feed motor.
		SM main PWB	Replace the PF main PWB (Refer to the service manual for the paper feeder).

Code	Contents	Causes	Check procedures/ corrective measures
2660	PF paper feed motor error (side large capacity feeder) [45 ppm/55 ppm model] After PF paper feed motor is driven, the ready signal does not turn to L within 2 s.	PF paper feed motor	<ol style="list-style-type: none"> 1. Execute Side LCF - Motor ON of U247 feed unit operation check (see page 1-3-136). 2. Check the paper feed roller and drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF paper feed motor and PF main PWB (YC16) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the PF paper feed motor.
		PF main PWB	Replace the PF main PWB (Refer to the service manual for the paper feeder).
2670	PF paper feed motor error (side paper feeder) [45 ppm/55 ppm model] After PF paper feed motor is driven, the ready signal does not turn to L within 2 s.	PF paper feed motor	<ol style="list-style-type: none"> 1. Execute Side 2PF - Motor ON of U247 feed unit operation check (see page 1-3-136). 2. Check the paper feed roller and drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. PF paper feed motor and PF main PWB (YC16) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the PF paper feed motor.
		PF main PWB	Replace the PF main PWB (Refer to the service manual for the paper feeder).

Code	Contents	Causes	Check procedures/ corrective measures
2700	3-color release motor error When the color release motor is driven, the color release sensor does not turn on/off for 5 s.	Color release motor Color release sensor (transfer belt unit)	<ol style="list-style-type: none"> 1. Execute CMY Release by U030 motor operation check (see page 1-3-31). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Transfer belt unit and Engine PWB (YC3) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the transfer belt unit (see page 1-5-53).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
2730	Secondary transfer release motor error When the transfer release motor is driven, the transfer release sensor does not turn on/off for 5 s.	Color release motor	<ol style="list-style-type: none"> 1. Execute Press Release by U030 motor operation check (see page 1-3-31). 2. Check for broken drive gears and replace if any. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Transfer release motor and relay PWB (YC14) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the Transfer release motor.
		Color release sensor	<ol style="list-style-type: none"> 1. When abnormal noise is observed at the execution of Press Release of U030 motor operation check. 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. 4. Replace the Transfer release motor.

Code	Contents	Causes	Check procedures/ corrective measures
2730		Paper conveying unit	<ol style="list-style-type: none"> 1. The main-unit access drawer of the paper conveying unit has no foreign objects adhered or no distorted pins and, if necessary, repair. 2. Check the paper conveying unit is firmly closed. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Relay PWB (YC1) and Feed PWB 1(YC14) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the paper conveying unit and execute U052 (see page 1-3-43).
		Feed PWB 1	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Feed PWB 1 (YC1) and Engine PWB (YC6) 2. Check that the IC on the feed circuit PWB1 is not damaged (by an overcurrent or foreign object) and, if necessary, replace.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2760	Transfer motor startup error Transfer motor is not stabilized within 5 s since the motor is activated.	Transfer motor	<ol style="list-style-type: none"> 1. Execute Belt Meand By U030 Motor Operation Check (see page 1-3-31). 2. Rotate the drive gear, the belt and the roller by the hand and check that they are not unusually loaded. 3. Clean the transfer belt unit. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Transfer motor and Feed PWB 1 (YC13) Feed PWB 1(YC2) and Engine PWB (YC5) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the Transfer motor.
		Feed PWB 1	Replace the Feed PWB 1.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
2770	Intermediate transfer belt meandering correction error If the intermediate transfer belt position detecting sensor has derived an incorrect value.	Transfer belt unit	<ol style="list-style-type: none"> 1. Check that the transfer belt unit has been properly installed so that the intermediate belt unit waste toner shutter won't be derailed when the belt unit is strongly inserted. 2. Reinstall the intermediate transfer belt unit.(Insert slowly all the way in.?) 3. Run U469 Belt Position with B/W and confirm the angle (position of belt) is within the range (6 to 26) (see page 1-3-185). 4. Check that the main unit is placed perfectly horizontal. 5. Replace the transfer belt unit (see page 1-5-49).
		Transfer belt sensor (Transfer belt unit)	<ol style="list-style-type: none"> 1. Clean the toner off of the sensor and its proximity using a blower. 2. Check the sensor actuator are correctly positioned.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2780	Intermediate transfer belt meandering correction sensor error An abnormal value is detected to transfer skew sensor.	Transfer belt sensor (Transfer belt unit)	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Transfer belt unit and Engine PWB (YC3) 1. Replace the transfer belt unit (see page 1-5-53).
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
2790	Intermediate transfer skew motor error When the transfer skew motor is driven, timeouts (300 ms) were detected twice in a row.	Transfer skew motor	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Transfer belt unit and Engine PWB (YC3) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the transfer belt unit (see page 1-5-53).
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2810	Waste toner motor error Initialized when an error is constantly observed for 2 s after the waste toner motor is activated. An error is constantly observed for 2.5 s after rebooting. The lock detect signal won't be H level three times in a row within 200 ms at 1.25 ms cycles after the waste toner motor has been driven.	Waste toner box	<ol style="list-style-type: none"> 1. Rotate the waste toner spiral by the hand and check that they are not unusually loaded. 2. If the spiral won't turn, replace the waste toner tank.
		Waste toner motor	<ol style="list-style-type: none"> 1. Rotate the drive gear by the hand and check that they are not unusually loaded. 2. Clean the drive gears and the axle holder. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. ?Waste toner motor and Front PWB (YC16) Front PWB (YC3) and Engine PWB (YC7) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the waste toner motor.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
2820	Transfer motor steady-state error After transfer motor is stabilized, the ready signal is at the H level for 5 s continuously. The counter value obtained by timer capture is lower than 2200 for 10 times in a row.	Transfer motor	<ol style="list-style-type: none"> 1. Execute Belt Meand by U030 motor operation check (see page 1-3-31). 2. Rotate the Waste toner spiral by the hand and check that they are not unusually loaded. 3. Clean the transfer belt unit. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Transfer motor and Feed PWB 1(YC13) Feed PWB 1(YC2) and Engine PWB (YC5) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the Transfer motor (see page 1-5-49).
		Feed PWB 1	Replace the Feed PWB 1.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2840	Transfer cleaning motor error After transfer cleaning motor is driven, the ready signal does not turn to L within 2 s. After transfer cleaning motor is stabilized, the ready signal is at the H level for 1 s continuously.	Transfer cleaning motor	<ol style="list-style-type: none"> 1. Rotate the roller and the drive gear by the hand and check that they are not unusually loaded. 2. Check if the waste toner is remaining inside the cleaning unit without being disposed of. 3. Clean inside the cleaning unit. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Transfer cleaning motor and Engine PWB (YC3) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the transfer cleaning motor.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
2850	Transfer belt sensor error The signal is not received for 100 ms in succession.	Transfer motor	<ol style="list-style-type: none"> 1. Execute Belt Meand by U030 motor operation check (see page 1-3-31). 2. Rotate the Waste toner spiral by the hand and check that they are not unusually loaded. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Transfer motor and Feed PWB 1(YC13) Feed PWB 1(YC1) and Engine PWB (YC6) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the Transfer motor.
		Feed PWB 1	Replace the Feed PWB 1.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
2860	Transfer belt sensor error The signal is not received for 100 ms in succession.	Transfer belt sensor	<ol style="list-style-type: none"> 1. Execute Belt Meand by U030 motor operation check (see page 1-3-31). 2. Check that the drive roller for the sensor pulse can be rotated. 3. Check that the sensor is correctly positioned. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Transfer belt sensor and Transfer belt unit and Engine PWB (YC3) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the transfer belt unit.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
2950	Motor control PWB communication error A communication error from the motor control PWB is detected 10 times in succession.	Motor control PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Motor control PWB (YC3) and Engine PWB (YC9) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Motor control PWB.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
3100	Scanner carriage error The home position is not correct when the power is turned on, at the end of a reading process of the table and document processor.	The scanner mirror frame is being locked after setup.	Check whether the scanner mirror frame has been unlocked and unlock if necessary (see page 1-2-7).
		Scanner motor	<ol style="list-style-type: none"> 1. Execute U073 scanner motor check (see page 1-3-62). 2. Move the scanner by the hand to check whether it is unusually difficult to move. 3. Check that the optical wire rope is not disengaged and engage the wire. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Scanner motor and ISC PWB (YC5) ISC PWB (YC3) and Main PWB (YC11) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the scanner motor.
		Home position sensor	<ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Home position sensor and ISC PWB (YC8) 3. Replace the home position sensor.
		ISC PWB	Replace the ISC PWB and execute U411 (see page 1-3-160).
		Main PWB	Replace the main PWB (see page 1-5-59).

Code	Contents	Causes	Check procedures/ corrective measures
3200	Exposure lamp error When input value at the time of LED lamp PWB illumination does not exceed the threshold value between 5 s.	LED lamp PWB	1. Execute CCD of U061 lamp check (see page 1-3-51). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. LED lamp PWB and ISC PWB (YC6) CCD PWB (YC2) and ISC PWB (YC9) ISC PWB (YC3) and Main PWB (YC11) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the LED lamp PWB and execute U411 (see page 1-3-160).
		ISC PWB	Replace the ISC PWB and execute U411 (see page 1-3-160).
		CCD PWB	Replace the ISU and execute U411 (see page 1-3-160).
		Main PWB	Replace the main PWB (see page 1-5-59).
3210	CIS lamp error When input value at the time of CIS illumination does not exceed the threshold value between 5 s.	CIS	1. Execute U906 Separating Operation Release (see page 1-3-201). 2. Execute CCD of U061 lamp check (see page 1-3-51). 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. CIS and DPSHD PWB (YC2) DPSHD PWB (YC3) and DP relay PWB (YC2) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the CIS and execute U091 and U411 (see page 1-3-67,1-3-160).
		DPSHD PWB	Replace the DPSHD PWB.
		DP relay PWB	Replace the DP relay PWB.

Code	Contents	Causes	Check procedures/ corrective measures
3300	Optical system (AGC) error After AGC, correct input is not obtained at CCD.	LED lamp PWB	<ol style="list-style-type: none"> Execute CCD of U061 lamp check (see page 1-3-51). Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. LED lamp PWB and ISC PWB (YC6) CCD PWB (YC2) and ISC PWB (YC9) ISC PWB (YC3) and Main PWB (YC11) If the wiring is disconnected, shorted or grounded, replace the wiring. If the LED lamp won't light, replace the LED PWB and execute U411 (see page 1-3-160).
		CCD PWB	Replace the ISU and execute U411 (see page 1-3-160).
		ISC PWB	Replace the ISC PWB and execute U411 (see page 1-3-160).
		Main PWB	Replace the main PWB (see page 1-5-59).
3310	CIS AGC error After AGC, correct input is not obtained at CIS.	CIS	<ol style="list-style-type: none"> Execute U906 Separating Operation Release (see page 1-3-201). Execute CCD of U061 lamp check (see page 1-3-51). Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DP CIS and DPSHD PWB (YC2) DPSHD PWB (YC3) and DP relay PWB (YC2) If the wiring is disconnected, shorted or grounded, replace the wiring. Replace the CIS and execute U091 and U411 (see page 1-3-67, 1-3-160).
		DPSHD PWB	Replace the DPSHD PWB.
3500	Communication error between scanner and ASIC An error code is detected.	ISC PWB	<ol style="list-style-type: none"> Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. ISC PWB (YC3) and Main PWB (YC11) If the wiring is disconnected, shorted or grounded, replace the wiring. Replace the ISC PWB and execute U411 (see page 1-3-160).
		Main PWB	Replace the main PWB (see page 1-5-59).

Code	Contents	Causes	Check procedures/ corrective measures
3600	Scanner sequence error	ISC PWB	<ol style="list-style-type: none"> 1. U021 Execute memory initializing (see page 1-3-29). 2. Replace the ISC PWB and execute U411 (see page 1-3-160).
3700	Scanner device error	CCD?ISU)	Since the ISU is mounted with a CCD of different type, install the ISU that matches with the model.
3800	AFE error When writing the data, read and write data does not match 3 times in succession. No response is received in 100 ms from AEF.	ISC PWB	<ol style="list-style-type: none"> 1. Confirm that the FFC wiring connector is not distorted and connect the FFC wiring all the way in. CCD PWB (YC2) and ISC PWB (YC9) 2. If the FFC wiring is disconnected, replace the FFC wiring. 3. Replace the ISC PWB and execute U411 (see page 1-5-64).
		CCD PWB	Replace the ISU and execute U411 (see page 1-3-160).
3900	Backup memory read/write error (ISC PWB) Read and write data does not match.	Backup memory (ISC PWB)	<ol style="list-style-type: none"> 1. Turn the main power switch off and after 5 seconds, turn it on. 2. Replace the ISC PWB and execute U411 (see page 1-3-160).
4001	Polygon motor K synchronization error After polygon motor K is driven, the ready signal does not turn to L within 30 s. The polygon motor speed won't stabilize within 10 s.	Polygon motor K (LSU)	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Polygon motor K and LSU relay PWB (YC4) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
4002	Polygon motor C synchronization error After polygon motor C is driven, the ready signal does not turn to L within 30 s. The polygon motor speed won't stabilize within 10 s.	Polygon motor C (LSU)	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Polygon motor C and LSU relay PWB (YC9) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
4003	Polygon motor M synchronization error After polygon motor M is driven, the ready signal does not turn to L within 30 s. The polygon motor speed won't stabilize within 10 s.	Polygon motor M (LSU)	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Polygon motor M and LSU relay PWB (YC7) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
4004	Polygon motor Y synchronization error After polygon motor Y is driven, the ready signal does not turn to L within 30 s. The polygon motor speed won't stabilize within 10 s.	Polygon motor Y (LSU)	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Polygon motor Y and LSU relay PWB (YC11) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
4011	Polygon motor K steady-state error After polygon motor K is stabilized, the ready signal is at the H level for 15 s continuously.	Polygon motor K (LSU)	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Polygon motor K and LSU relay PWB (YC4) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
4012	Polygon motor C steady-state error After polygon motor C is stabilized, the ready signal is at the H level for 15 s continuously.	Polygon motor C (LSU)	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Polygon motor C and LSU relay PWB (YC9) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	Check the engine software and upgrade to the latest, if necessary. Replace the engine PWB (see page 1-5-64).
4013	Polygon motor M steady-state error After polygon motor M is stabilized, the ready signal is at the H level for 15 s continuously.	Polygon motor M (LSU)	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Polygon motor M and LSU relay PWB (YC7) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	Check the engine software and upgrade to the latest, if necessary. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
4014	Polygon motor Y steady-state error After polygon motor Y is stabilized, the ready signal is at the H level for 15 s continuously.	Polygon motor Y (LSU)	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Polygon motor Y and LSU relay PWB (YC11) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
4101	BD initialization error K After polygon motor K is driven, the BD signal is not detected for 1 s.	PD PWB K (LSU)	<ol style="list-style-type: none"> 1. Confirm that the FFC wiring connector is not distorted and connect the FFC wiring all the way in. Laser scanner unit and LSU relay PWB (YC5) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the FFC wiring is disconnected, replace the FFC wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
4102	BD initialization error C After polygon motor C is driven, the BD signal is not detected for 1 s.	PD PWB C (LSU)	<ol style="list-style-type: none"> 1. Confirm that the FFC wiring connector is not distorted and connect the FFC wiring all the way in. Laser scanner unit and LSU relay PWB (YC10) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the FFC wiring is disconnected, replace the FFC wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
4103	BD initialization error M After polygon motor M is driven, the BD signal is not detected for 1 s.	PD PWB M (LSU)	1. Confirm that the FFC wiring connector is not distorted and connect the FFC wiring all the way in. Laser scanner unit and LSU relay PWB (YC8) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the FFC wiring is disconnected, replace the FFC wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
4104	BD initialization error Y After polygon motor Y is driven, the BD signal is not detected for 1 s.	PD PWB Y (LSU)	1. Confirm that the FFC wiring connector is not distorted and connect the FFC wiring all the way in. Laser scanner unit and LSU relay PWB (YC12) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the FFC wiring is disconnected, replace the FFC wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
4201	BD steady-state error K The BD signal is not detected.	PD PWB K (LSU)	1. Confirm that the FFC wiring connector is not distorted and connect the FFC wiring all the way in. Laser scanner unit and LSU relay PWB (YC5) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the FFC wiring is disconnected, shorted or grounded, replace the FFC wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
4202	BD steady-state error C The BD signal is not detected.	PD PWB C (LSU)	1. Confirm that the FFC wiring connector is not distorted and connect the FFC wiring all the way in. Laser scanner unit and LSU relay PWB (YC10) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the FFC wiring is disconnected, replace the FFC wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
4203	BD steady-state error M The BD signal is not detected.	PD PWB M (LSU)	1. Confirm that the FFC wiring connector is not distorted and connect the FFC wiring all the way in. Laser scanner unit and LSU relay PWB (YC8) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the FFC wiring is disconnected, replace the FFC wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
4204	BD steady-state error Y The BD signal is not detected.	PD PWB Y (LSU)	1. Confirm that the FFC wiring connector is not distorted and connect the FFC wiring all the way in. Laser scanner unit and LSU relay PWB (YC12) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the FFC wiring is disconnected, replace the FFC wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
4300	Polygon motor phase error ASIC won't settle in completion of phase adjustment for 2 s after a BD signal is detected.	Laser scanner unit	Replace the laser scanner unit (see page 1-5-33).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
4600	LSU cleaning motor error After LSU cleaning motor is driven, the ready signal does not turn to L within 2 s. After LSU cleaning motor is stabilized, the ready signal is at the H level for 1 s continuously.	LSU cleaning motor	<ol style="list-style-type: none"> 1. Execute LSU cleaning using Adjustment/Maintenance of the system menu. 2. Rotate the drive gear and the cleaning spiral by the hand and check that they are not unusually loaded. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. LSU cleaning motor and Engine PWB (YC21) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the LSU cleaning motor.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
5101	Main high-voltage error K Measure the inflowing current when Vpp is varied in 3 steps and verify if the difference of the currents of 0 and step 2 is less than 42 (51 if lower high-voltage board).	Drum unit	<ol style="list-style-type: none"> 1. Execute U030 Belt Mean Drum Motor and check that the drum motor can rotate (see page 1-3-31). 2. Confirm that the drum or the drum screw can rotate. 3. Check that the discharger lamp is properly connected and lit up. 4. If it won't rotate, replace the drum unit.
		Charger roller unit	<ol style="list-style-type: none"> 1. Check that the high-voltage contacts are not distorted or adhered with foreign objects. 2. Reinstall the charger roller unit. Or, replace the charger roller unit (see page 1-5-46).
		High voltage PWB 1	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. High voltage PWB 1(YC4)^{*1},(YC3)^{*2} and Engine PWB (YC17) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the High voltage PWB 1 (see page 1-5-69). <p>*1:45 ppm model/ 55ppm model *2:30ppm model/ 35ppm model</p>
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
5102	Main high-voltage error C Measure the inflowing current when Vpp is varied in 3 steps and verify if the difference of the currents of 0 and step 2 is less than 42 (51 if lower high-voltage board).	Drum unit	<ol style="list-style-type: none"> 1. Execute U030 Belt Mean Drum Motor and check that the drum motor can rotate (see page 1-3-31). 2. Confirm that the drum or the drum screw can rotate. 3. Check that the discharger lamp is properly connected and lit up. 4. If it won't rotate, replace the drum unit.
		Charger roller unit	<ol style="list-style-type: none"> 1. Check that the high-voltage contacts are not distorted or adhered with foreign objects. 2. Reinstall the charger roller unit. Or, replace the charger roller unit (see page 1-5-46).
		High voltage PWB 1	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. High voltage PWB 1(YC2) and Engine PWB (YC16) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the High voltage PWB 1 (see page 1-5-69).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
5103	Main high-voltage error M Measure the inflowing current when Vpp is varied in 3 steps and verify if the difference of the currents of 0 and step 2 is less than 42 (51 if lower high-voltage board).	Drum unit	<ol style="list-style-type: none"> 1. Execute U030 Belt Mean Drum Motor and check that the drum motor can rotate (see page 1-3-31). 2. Confirm that the drum or the drum screw can rotate. 3. Check that the discharger lamp is properly connected and lit up. 4. If it won't rotate, replace the drum unit.
		Charger roller unit	<ol style="list-style-type: none"> 1. Check that the high-voltage contacts are not distorted or adhered with foreign objects. 2. Reinstall the charger roller unit. Or, replace the charger roller unit (see page 1-5-46).
		High voltage PWB 1	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. High voltage PWB 1(YC3) and Engine PWB (YC17) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the High voltage PWB 1 (see page 1-5-69).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
5104	Main high-voltage error Y Measure the inflowing current when Vpp is varied in 3 steps and verify if the difference of the currents of 0 and step 2 is less than 42 (51 if lower high-voltage board).	Drum unit	<ol style="list-style-type: none"> 1. Execute U030 Belt Mean Drum Motor and check that the drum motor can rotate (see page 1-3-31). 2. Confirm that the drum or the drum screw can rotate. 3. Check that the discharger lamp is properly connected and lit up. 4. If it won't rotate, replace the drum unit.
		Charger roller unit	<ol style="list-style-type: none"> 1. Check that the high-voltage contacts are not distorted or adhered with foreign objects. 2. Reinstall the charger roller unit. Or, replace the charger roller unit (see page 1-5-46).
		High voltage PWB 1	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. High voltage PWB 1(YC1) and Engine PWB (YC16) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the High voltage PWB 1 (see page 1-5-69).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
6000	Broken fuser heater wire Fuser thermistor 1 does not reach 100° C/212 °F even after 60 s during warming up. The detected temperature of fuser thermistor 1 does not reach the specified temperature (ready indication temperature) for 420 s in warming up after reached to 100° C/212 °F.	Fuser unit	<ol style="list-style-type: none"> 1. Check that no paper jam is present. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the Fuser unit and execute U167 counter clear (see page 1-3-106). (Deteriorated sensitivity due to the toner adhered to the center thermistor.)
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
		Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. Replace the fuser IH PWB (see page 1-5-75).
		Fuser IH unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH unit and Fuser IH PWB (YC9 and 10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH unit (see page 1-5-57).
6020	Abnormally high fuser Center thermistor 1 temperature Fuser center thermistor 1 detects a temperature higher than 240°C/464°F for 1 s.	Fuser unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Fuser unit (see page 1-5-55).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
6030	Broken fuser center thermistor 1 wire Input from fuser center thermistor 1 is 984 or more (A/D value) continuously for 1 s. Verify if A/D read in the differential output won't change by 4 or more when it was turned on for 10 seconds in a low-temperature environment.	Fuser unit	<ol style="list-style-type: none"> 1. Check that no paper jam is present. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the Fuser unit and execute U167 counter clear (see page 1-3-106). (Deteriorated sensitivity due to the toner adhered to the center thermistor.)
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
		Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. Replace the Fuser IH PWB (see page 1-5-75).
		Fuser IH unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH unit and Fuser IH PWB (YC9 and 10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH unit (see page 1-5-57).

Code	Contents	Causes	Check procedures/ corrective measures
6040	Fuser heater error Input from fuser thermistor 1 is abnormal value continuously for 1 s.	Fuser unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Fuser unit and execute U167 counter clear (see page 1-3-106).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
		Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB (YC4) and Engine PWB (YC26) 2. Replace the fuser IH PWB (see page 1-5-75).

Code	Contents	Causes	Check procedures/ corrective measures
6050	<p>Abnormally low fuser center thermistor 1 temperature Fuser center thermistor 1 detects a temperature lower than 100°C/212°F for 1 s after warming up, during ready or during print.</p> <p>Fuser center thermistor 1 detects a temperature lower than 70°C/158°F for 1 s during low power mode.</p>	Power source	<ol style="list-style-type: none"> 1. Check that the operating voltage falls within +/-10%. 2. Check no voltage drop is caused. The heater is deactivated at 70V or lower. 3. Relocate the AC outlet that supplies power.
		Fuser unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Fuser unit and execute U167 counter clear (see page 1-3-106).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
		Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. Replace the Fuser IH PWB (see page 1-5-75).
		Fuser IH unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH unit and Fuser IH PWB (YC9 and 10) Fuser IH PWB(YC4) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH unit (see page 1-5-57).

Code	Contents	Causes	Check procedures/ corrective measures
6120	Abnormally high fuser press thermistor 4 temperature Fuser press thermistor 4 detects a temperature higher than 190°C/374°F for 1 s.	Fuser unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Fuser unit and execute U167 counter clear (see page 1-3-106).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
6130	Broken fuser press thermistor 4 wire Input from fuser press thermistor 4 is 992 or more (A/D value) continuously for 60 s.	Fuser unit	<ol style="list-style-type: none"> 1. Check that no paper jam is present. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) Fuser IH PWB(YC4) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the Fuser unit and execute U167 counter clear (see page 1-3-106). (Deteriorated sensitivity due to the toner adhered to the center thermistor.)
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
		Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. Replace the fuser IH PWB (see page 1-5-75).
		Fuser IH unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH unit and Fuser IH PWB (YC9 and 10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH unit (see page 1-5-57).

Code	Contents	Causes	Check procedures/ corrective measures
6150	Abnormally low fuser press thermistor 4 temperature Fuser press thermistor 4 detects a temperature lower than 30°C/86°F for 1 s after warming up.	Fuser unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) Fuser IH PWB(YC4) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Fuser unit and execute U167 counter clear (see page 1-3-106).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
		Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. Replace the fuser IH PWB (see page 1-5-75).
		Fuser IH unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH unit and Fuser IH PWB (YC9 and 10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH unit (see page 1-5-57).

Code	Contents	Causes	Check procedures/ corrective measures
6200	Broken fuser edge heater wire Fuser thermistor 2 does not reach 100° C/212 °F even after 60 s during warming up. The detected temperature of fuser thermistor 2 does not reach the specified temperature (ready indication temperature) for 420 s in warming up after reached to 100° C/212 °F.	Fuser unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) If the wiring is disconnected, shorted or grounded, replace the wiring. 2. Replace the Fuser unit and execute U167 counter clear (see page 1-3-106).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
		Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. Replace the fuser IH PWB (see page 1-5-75).
		Fuser IH unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH unit and Fuser IH PWB (YC9 and 10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH unit (see page 1-5-57).

Code	Contents	Causes	Check procedures/ corrective measures
6220	Abnormally high fuser edge thermistor 2 temperature Fuser edge thermistor 2 detects a temperature higher than 245°C/473°F for 1 s.	Fuser unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) Fuser IH PWB(YC4) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Fuser unit and execute U167 counter clear (see page 1-3-106).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
		Fuser IH unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH unit and Fuser IH PWB (YC9 and 10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH unit (see page 1-5-57).

Code	Contents	Causes	Check procedures/ corrective measures
6230	Broken fuser edge thermistor 2 wire The Input signal from the fuser edge thermistor 2 is 992 or more (A/D value) continuously for 1 s when the temperature at the fuser edge thermistor 1 is greater than 100°C/212°F during warming up.	Fuser unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) Fuser IH PWB(YC4) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Fuser unit and execute U167 counter clear (see page 1-3-106).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
		Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. Replace the fuser IH PWB (see page 1-5-75).
		Fuser IH unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH unit and Fuser IH PWB (YC9 and 10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH unit (see page 1-5-57).

Code	Contents	Causes	Check procedures/ corrective measures
6250	<p>Abnormally low fuser edge thermistor 2 temperature</p> <p>Fuser edge thermistor 2 detects a temperature lower than 100°C/212°F for 1 s during ready or print.</p> <p>Fuser edge thermistor 2 detects a temperature lower than 50°C/122°F for 1 s during warming up.</p>	Fuser unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) Fuser IH PWB(YC4) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Fuser unit and execute U167 counter clear (see page 1-3-106).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
		Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. Replace the fuser IH PWB (see page 1-5-75).
		Fuser IH unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH unit and Fuser IH PWB (YC9 and 10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH unit (see page 1-5-57).

Code	Contents	Causes	Check procedures/ corrective measures
6320	Abnormally high fuser middle thermistor 3 temperature Fuser middle thermistor 3 detects a temperature higher than 205°C/401°F for 1 s.	Fuser unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Fuser unit and execute U167 counter clear (see page 1-3-106).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
6330	Broken fuser middle thermistor 3 wire Fuser middle thermistor 3 detects a temperature lower than 20°C/68°F continuously for 1 s	Fuser unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) Fuser IH PWB(YC4) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Fuser unit and execute U167 counter clear (see page 1-3-106).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
		Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. Replace the fuser IH PWB (see page 1-5-75).

Code	Contents	Causes	Check procedures/ corrective measures
6600	Fuser belt rotation error A belt rotating pulse is not received for 1 s. (Engine CPU)	Fuser motor	<ol style="list-style-type: none"> 1. Execute Fuser by U030 motor operation check (see page 1-3-31). 2. Check that the drive gear can rotate and not heavily loaded and, if necessary, apply grease to the axle holder and gears. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser motor and Feed PWB (YC18) and Engine PWB (YC6) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the fuser motor (see page 1-5-87).
		Fuser belt sensor	<ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the fuser unit and execute U167 counter clear (see page 1-3-106).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
6610	Fuser release motor error When the fuser release motor is driven, the fuser release sensor does not turn on/off for 5 s.	Fuser release motor	<ol style="list-style-type: none"> 1. Execute Fuser Release by U030 motor operation check (see page 1-3-31). 2. Check that the drive gear can be rotated by the hand and the separation is possible. 3. If the motor won't rotate, confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the fuser unit and execute U167 counter clear (see page 1-3-106).
		Fuser release sensor	<ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Check that the sensor is not contaminated or damaged.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
6710	Fuser IH PWB CPU reset error Watch doc timer has been overflowed.	Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH PWB (see page 1-5-75).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
6720	Fuser IH belt rotation error A belt rotating pulse is not received for 2 s.	Fuser motor	<ol style="list-style-type: none"> 1. Execute Fuser by U030 motor operation check (see page 1-3-31). 2. Check that the drive gear can rotate and not heavily loaded and, if necessary, apply grease to the axle holder and gears. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser motor and Feed PWB(YC18) and Engine PWB (YC6) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the fuser motor (see page 1-5-87).
		Fuser belt sensor	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Engine PWB (YC26) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser unit and execute U167 counter clear (see page 1-3-106).
		Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. Replace the fuser IH PWB (see page 1-5-75).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
6730	Abnormally high fuser IH PWB temperature 1 The input detect temperature is greater than 105°C/221 °F.	Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH PWB (see page 1-5-75).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
6740	Abnormally high fuser IH PWB temperature 2 The input detect temperature is greater than 105°C/221 °F.	Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH PWB (see page 1-5-75).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
6750	Fuser IH output over-current error The output current is greater than 90A for 10 ms in succession.	Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH PWB (see page 1-5-75).
		Fuser IH unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH unit and Fuser IH PWB (YC9 and 10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH unit (see page 1-5-57).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
6760	Fuser IH input over-current error The input current is greater than 20A(100V/120V), 10A(200V) for 100 ms in succession.	Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH PWB (see page 1-5-75).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
6770	Fuser IH low electric power error The preset power is less than 0.6 times of it for 120 ms in succession.	Fuser unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser unit and Fuser IH PWB (YC6) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Fuser IH unit (see page 1-5-57).
		Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Fuser IH PWB (see page 1-5-75).
		Fuser IH unit	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH unit and Fuser IH PWB (YC9 and 10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the fuser IH unit (see page 1-5-57).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
6900	Fuser belt cooling fan error When the fuser edge fan motor 1, 2 is driven, alarm signal is detected for 5 s continuously.	Fuser edge fan motor 1, 2	<ol style="list-style-type: none"> 1. Execute Fuser Edge by U037 fan motor operation check (see page 1-3-39). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser edge fan motor 1 and Engine PWB (YC26) Fuser edge fan motor 2 and Fuser PWB (YC2) Fuser PWB (YC1) and Engine PWB (YC26) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the fuser unit and execute U167 counter clear (see page 1-3-106).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
6910	Engine software ready error The device won't engage in ready state in 60 minutes after warming-up has began. (A previous timeout process has not been cancelled.)	Engine PWB	<ol style="list-style-type: none"> 1. Turn the main power switch off and after 5 seconds, turn it on. 2. Reinstall the engine software. 3. Replace the engine PWB (see page 1-5-64).
6920	Fuser front fan motor error When the fuser front fan motor is driven, alarm signal is detected for 5 s continuously.	Fuser front fan motor	<ol style="list-style-type: none"> 1. Execute fuser front fan motor by U037 fan motor operation check (see page 1-3-39). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser front fan motor and Front PWB (YC4) Front PWB (YC3) and Engine PWB (YC7) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the fuser front fan motor.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
6930	Fuser rear fan motor error When the fuser rear fan motor is driven, alarm signal is detected for 5 s continuously.	Fuser rear fan motor	<ol style="list-style-type: none"> 1. Execute fuser rear fan motor by U037 fan motor operation check (see page 1-3-39). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser rear fan motor and Engine PWB (YC26) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the fuser rear fan motor.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
6940	IH fan motor error When the IH fan motor is driven, the alarm signal is detected for 5 s continuously.	IH fan motor	<ol style="list-style-type: none"> 1. Execute IH PWB by U037 fan motor operation check (see page 1-3-39). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. IH fan motor and Feed PWB 1(YC11) Feed PWB 1(YC2) and Engine PWB (YC5) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the IH fan motor.
		Feed PWB 1	Replace the Feed PWB1.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
6950	Fuser IH PWB communication error No response is received in 30 ms since a command is sent to IHCPU. A checksum error is detected 10 times in succession.	Power source PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Power source PWB (YC9) and Feed PWB 1(YC4) Power source PWB (YC3) and Fuser IH PWB (YC1) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. If the +24V output is not given by the power circuit PWB (YC9), replace the power source PWB.
		Feed PWB 1	<ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected and, if necessary, connect the connector all the way in. Power source PWB (YC3) and Fuser IH PWB (YC1) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. If the +24V output is not given by the feed PWB1 (YC27), replace the feed PWB1.
		Fuser IH PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Fuser IH PWB(YC4) and Engine PWB (YC26) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Fuser IH PWB (see page 1-5-75).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
6960	Current PWB error Less than 1A is continuously observed for 5 s.	Current PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Current PWB(YC17) and Feed PWB? (YC13) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Current PWB.

Code	Contents	Causes	Check procedures/ corrective measures
6990	Fuser power supply incompatibility Information won't match between the engine backup and the fuser IH PWB.	Differences in settings after initialization	When this has happened after initialization using U021, make settings identical with the voltages on the IH PWB using U169 (see page 1-3-29,1-3-106).
		Fuser IH PWB	Replace with a fuser IH PWB specifically designed with the standard voltage (see page 1-5-75).
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7001	Toner motor K error When the toner motor K is driven, the pulse sensor is not detected for 15 times in 200 ms intervals has occurred in 15 times. During the toner motor is driven, an event in which TMOT_LOCK turns to H (locked) 5 times has occurred in 15 sets.	Toner container K	1. Check that the spiral screw of the toner container can be rotated by the hand. 2. Check for broken gears and replace if any.
		Toner motor K	1. Draw out the toner container and check execute U135 - toner motor check (see page 1-3-92). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Toner motor K and Engine PWB (YC27) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the Toner motor K.
		Screw sensor K	1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Screw sensorK and Engine PWB (YC27) 3. Replace the screw sensor K.
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7002	<p>Toner motor C error When the toner motor K is driven, the pulse sensor is not detected for 15 times in 200 ms intervals has occurred in 15 times.</p> <p>During the toner motor is driven, an event in which TMOT_LOCK turns to H (locked) 5 times has occurred in 15 sets.</p>	Toner container C	<ol style="list-style-type: none"> 1. Check that the spiral screw of the toner container can be rotated by the hand. 2. Check for broken gears and replace if any.
		Toner motor C	<ol style="list-style-type: none"> 1. Draw out the toner container and check execute U135 - toner motor check (see page 1-3-92). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Toner motor C and Engine PWB (YC27) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the Toner motor C.
		Screw sensor C	<ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Screw sensorC and Engine PWB (YC27) 3. Replace the screw sensor C.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7003	<p>Toner motor M error</p> <p>When the toner motor K is driven, the pulse sensor is not detected for 15 times in 200 ms intervals has occurred in 15 times.</p> <p>During the toner motor is driven, an event in which TMOT_LOCK turns to H (locked) 5 times has occurred in 15 sets.</p>	Toner container M	<ol style="list-style-type: none"> 1. Check that the spiral screw of the toner container can be rotated by the hand. 2. Check for broken gears and replace if any.
		Toner motor M	<ol style="list-style-type: none"> 1. Draw out the toner container and check execute U135 - toner motor check (see page 1-3-92). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Toner motor M and Engine PWB (YC27) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the Toner motor M.
		Screw sensor M	<ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Screw sensorM and Engine PWB (YC27) 3. Replace the screw sensor M.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7004	<p>Toner motor Y error When the toner motor K is driven, the pulse sensor is not detected for 15 times in 200 ms intervals has occurred in 15 times.</p> <p>During the toner motor is driven, an event in which TMOT_LOCK turns to H (locked) 5 times has occurred in 15 sets.</p>	Toner containerY	<ol style="list-style-type: none"> 1. Check that the spiral screw of the toner container can be rotated by the hand. 1. Check for broken gears and replace if any.
		Toner motor Y	<ol style="list-style-type: none"> 1. Draw out the toner container and check execute U135 - toner motor check (see page 1-3-92). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Toner motor Y and Engine PWB (YC27) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the Toner motor Y.
		Screw sensor Y	<ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Screw sensor Y and Engine PWB (YC27) 3. Replace the screw sensor Y.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7101	Toner sensor K error Sensor output value of 60 or less or 944 or more continued for 3 s.	Failure of locking the developer waste slot at setup.	If an abnormal noise is heard, check that the developer ejection outlet is released and, if not, release the outlet (see page 1-2-12).
		Toner sensor K	<ol style="list-style-type: none"> 1. Check the toner sensor output by U155 (see page 1-3-101). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Toner sensor K and Front PWB (YC9) Front PWB (YC2) and Engine PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Check that the gears of the developer unit K are not damaged and the spiral can rotate. 5. Replace the Developer unit K (see page 1-5-44).
		Toner motor K	<ol style="list-style-type: none"> 1. Draw out the toner container and check execute U135 - toner motor check (see page 1-3-92). 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Toner motor K and Engine PWB (YC27) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the Toner motor K.
Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64). 		

Code	Contents	Causes	Check procedures/ corrective measures
7102	Toner sensor C error Sensor output value of 60 or less or 944 or more continued for 3 s.	Failure of locking the developer waste slot at setup.	If an abnormal noise is heard, check that the developer ejection outlet is released and, if not, release the outlet (see page 1-2-12).
		Toner sensor C	1. Check the toner sensor output by U155 (see page 1-3-101). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Toner sensor C and Front PWB (YC13) Front PWB (YC2) and Engine PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Check that the gears of the developer unit C are not damaged and the spiral can rotate. 5. Replace the Developer unit C (see page 1-5-44).
		Toner motor C	1. Draw out the toner container and check execute U135 - toner motor check. 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Toner motor C and Engine PWB (YC27) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the Toner motor C.
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7103	Toner sensor M error Sensor output value of 60 or less or 944 or more continued for 3 s.	Failure of locking the developer waste slot at setup.	If an abnormal noise is heard, check that the developer ejection outlet is released and, if not, release the outlet (see page 1-2-12).
		Toner sensor M	1. Check the toner sensor output by U155 (see page 1-3-101). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Toner sensor M and Front PWB (YC11) Front PWB (YC2) and Engine PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Check that the gears of the developer unit M are not damaged and the spiral can rotate. 5. Replace the Developer unit M (see page 1-5-44).
		Toner motor M	1. Draw out the toner container and check execute U135 - toner motor check. 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Toner motor M and Engine PWB (YC27) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the Toner motor M.
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7104	Toner sensor Y error Sensor output value of 60 or less or 944 or more continued for 3 s.	Failure of locking the developer waste slot at setup.	If an abnormal noise is heard, check that the developer ejection outlet is released and, if not, release the outlet (see page 1-2-12).
		Toner sensor Y	<ol style="list-style-type: none"> 1. Check the toner sensor output by U155 (see page 1-3-101). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Toner sensor Y and Front PWB (YC15) Front PWB (YC2) and Engine PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Check that the gears of the developer unit Y are not damaged and the spiral can rotate. 5. Replace the Developer unit Y (see page 1-5-44).
		Toner motor Y	<ol style="list-style-type: none"> 1. Draw out the toner container and check execute U135 - toner motor check. 2. Check the drive gear can rotate or they are not unusually loaded and, if necessary, replace. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Toner motor Y and Engine PWB (YC27) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the Toner motor Y.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7200	Broken outer temperature sensor 2 wire The sensor input sampling is greater than 230.	Outer temperature sensor 2	<ol style="list-style-type: none"> 1. Confirm Ext/Int is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Outer temperature sensor 2 and Front PWB (YC19) Front PWB (YC2) and Engine PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the outer temperature sensor 2.
		Front PWB	Replace the front PWB.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7210	Short-circuited outer temperature sensor 2 The sensor input sampling is less than 69.	Outer temperature sensor 2	<ol style="list-style-type: none"> 1. Confirm Ext/Int is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Outer temperature sensor 2 and Front PWB (YC19) Front PWB (YC2) and Engine PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the outer temperature sensor 2.
		Front PWB	Replace the front PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7221	Broken LSU thermistor K wire The sensor input sampling is greater than 230.	LSU thermistor K	<ol style="list-style-type: none"> 1. Confirm LSU is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Laser scanner unit and LSU relay PWB (YC5) LSU relay PWB (YC3) and Engine PWB (YC12) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the laser scanner unit (see page 1-5-33).
		LSU relay PWB	REPLACE the LSU relay PWB.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7222	Broken LSU thermistor C wire The sensor input sampling is greater than 230.	LSU thermistor C	<ol style="list-style-type: none"> 1. Confirm LSU is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Laser scanner unit and LSU relay PWB (YC10) LSU relay PWB (YC3) and Engine PWB (YC12) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the laser scanner unit (see page 1-5-33).
		LSU relay PWB	REPLACE the LSU relay PWB.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7223	Broken LSU thermistor M wire The sensor input sampling is greater than 230.	LSU thermistor M	<ol style="list-style-type: none"> 1. Confirm LSU is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Laser scanner unit and LSU relay PWB (YC8) LSU relay PWB (YC3) and Engine PWB (YC12) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the laser scanner unit (see page 1-5-33).
		LSU relay PWB	REPLACE the LSU relay PWB.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7224	Broken LSU thermistor Y wire The sensor input sampling is greater than 230.	LSU thermistor Y	<ol style="list-style-type: none"> 1. Confirm LSU is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Laser scanner unit and LSU relay PWB (YC12) LSU relay PWB (YC3) and Engine PWB (YC12) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the laser scanner unit (see page 1-5-33).
		LSU relay PWB	REPLACE the LSU relay PWB.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7231	Short-circuited LSU thermistor K The sensor input sampling is less than 69.	LSU thermistor K	<ol style="list-style-type: none"> 1. Confirm LSU is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Laser scanner unit and LSU relay PWB (YC5) LSU relay PWB (YC3) and Engine PWB (YC12) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the laser scanner unit (see page 1-5-33).
		LSU relay PWB	Replace the LSU relay PWB.
		Engine PWB	Check the engine software and upgrade to the latest, if necessary. Replace the engine PWB (see page 1-5-64).
7232	Short-circuited LSU thermistor C The sensor input sampling is less than 69.	LSU thermistor C	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Laser scanner unit and LSU relay PWB (YC10) LSU relay PWB (YC3) and Engine PWB (YC12) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		LSU relay PWB	REPLACE the LSU relay PWB.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7233	Short-circuited LSU thermistor M The sensor input sampling is less than 69.	LSU thermistor M	<ol style="list-style-type: none"> 1. Confirm LSU is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Laser scanner unit and LSU relay PWB (YC8) LSU relay PWB (YC3) and Engine PWB (YC12) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the laser scanner unit (see page 1-5-33).
		LSU relay PWB	REPLACE the LSU relay PWB.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7234	Short-circuited LSU thermistor Y The sensor input sampling is less than 69.	LSU thermistor Y	<ol style="list-style-type: none"> 1. Confirm LSU is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Laser scanner unit and LSU relay PWB (YC12) LSU relay PWB (YC3) and Engine PWB (YC12) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the laser scanner unit (see page 1-5-33).
		LSU relay PWB	REPLACE the LSU relay PWB.
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7241	Broken developer thermistor K wire The sensor input sampling is greater than 230.	Developer thermistor K	<ol style="list-style-type: none"> 1. Confirm Developing is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer unitK and Front PWB (YC9) Front PWB (YC2) and Engine PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the Developer unit K (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7242	Broken developer thermistor C wire The sensor input sampling is greater than 230.	Developer thermistor C	<ol style="list-style-type: none"> 1. Confirm Developing is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer unitC and Front PWB (YC13) Front PWB (YC2) and Engine PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the Developer unit C (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7243	Broken developer thermistor M wire The sensor input sampling is greater than 230.	Developer thermistor M	<ol style="list-style-type: none"> 1. Confirm Developing is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer unitM and Front PWB (YC11) Front PWB (YC2) and Engine PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the Developer unit M (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7244	Broken developer thermistor Y wire The sensor input sampling is greater than 230.	Developer thermistor Y	<ol style="list-style-type: none"> 1. Confirm Developing is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer unitY and Front PWB (YC15) Front PWB (YC2) and Engine PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the Developer unit Y (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7251	Short-circuited developer thermistor K The sensor input sampling is less than 69.	Developer thermistor K	<ol style="list-style-type: none"> 1. Confirm Developing is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer unitK and Front PWB (YC9) Front PWB (YC2) and Engine PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the Developer unit K (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7252	Short-circuited developer thermistor C The sensor input sampling is less than 69.	Developer thermistor C	<ol style="list-style-type: none"> 1. Confirm Developing is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer unitC and Front PWB (YC13) Front PWB (YC2) and Engine PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the Developer unit C (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7253	Short-circuited developer thermistor M The sensor input sampling is less than 69.	Developer thermistor M	<ol style="list-style-type: none"> 1. Confirm Developing is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the terminal pins of the wiring connector are not missing or distorted and connect the connector all the way in. Developer unitM and Front PWB (YC11) Front PWB (YC2) and Engine PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the Developer unit M (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7254	Short-circuited developer thermistor Y wire The sensor input sampling is less than 69.	Developer thermistor Y	<ol style="list-style-type: none"> 1. Confirm Developing is displayed by U139 temperature and humidity (see page 1-3-93). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer unitY and Front PWB (YC15) Front PWB (YC2) and Engine PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the Developer unit Y (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7401	Developer unit K type mismatch error Absence of the developer unit K is detected.	Different type of the developer unit is installed.	Install the developer unit of the correct type.
		Developer unit K	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer unit K and Front PWB (YC9) Front PWB (YC2) and Engine PWB (YC10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring.
7402	Developer unit C type mismatch error Absence of the developer unit C is detected.	Different type of the developer unit is installed.	Install the developer unit of the correct type.
		Developer unit C	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer unit C and Front PWB (YC13) Front PWB (YC2) and Engine PWB (YC10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring.
7403	Developer unit M type mismatch error Absence of the developer unit M is detected.	Different type of the developer unit is installed.	Install the developer unit of the correct type.
		Developer unit M	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer unit M and Front PWB (YC11) Front PWB (YC2) and Engine PWB (YC10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring.
7404	Developer unit Y type mismatch error Absence of the developer unit Y is detected.	Different type of the developer unit is installed.	Install the developer unit of the correct type.
		Developer unit Y	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer unit Y and Front PWB (YC15) Front PWB (YC2) and Engine PWB (YC10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring.

Code	Contents	Causes	Check procedures/ corrective measures
7601	ID sensor 1 error An abnormal value is detected in the input data to ID sensor 1. Dark potential error FrontDarkP and FrontDarkS are greater than 0.80V. Light potential error FrontBrightS is smaller than FrontDarkS. FrontBrightP is smaller than FrontDarkP + 0.5V.	ID sensor1 (front)	1. Execute calibration of U464 ID compensation settings and check the Boas Calib values by U465 ID compensation data display (see page 1-3-181). 2. Detach the intermediate transfer belt unit and clean the ID sensor on its surface. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. ID sensor 1 (front) and Feed PWB 1(YC10) Feed PWB 1(YC1) and Engine PWB (YC6) 4. If the wiring is disconnected, shorted or grounded, replace the wiring.
		Feed PWB 1	Replace the Feed PWB 1.
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7602	ID sensor 2 error Dark potential error RearDarkP and RearDarkS are greater than 0.80V. Light potential error RearBrightS is smaller than RearDarkS. RearBrightP is smaller than RearDarkP + 0.5V.	ID sensor 2 (back)	1. Execute calibration of U464 ID compensation settings and check the Boas Calib values by U465 ID compensation data display (see page 1-3-181). 2. Detach the intermediate transfer belt unit and clean the ID sensor on its surface. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. ID sensor2 (back) and Feed PWB 1(YC10) Feed PWB 1(YC1) and Engine PWB (YC6) 4. If the wiring is disconnected, shorted or grounded, replace the wiring.
		Feed PWB 1	Replace the Feed PWB 1.
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7800	Broken outer temperature sensor 1 wire The device did not respond for more than 5 ms during reading, in 5 times.	Outer temperature sensor 1	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Outer temperature sensor 1 and Front PWB (YC16) Front PWB (YC2) and Engine PWB (YC10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Outer temperature sensor 1.
		Front PWB	Replace the front PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7901	Drum K EEPROM error No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively. Mismatch of reading data from two locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively.	DRPWB K	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DRPWB K and Front PWB (YC7) Front PWB (YC2) and Engine PWB (YC10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Drum unit K (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7902	Drum C EEPROM error No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively. Mismatch of reading data from two locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively.	DRPWB C	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DRPWB C and Front PWB (YC12) Front PWB (YC2) and Engine PWB (YC10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Drum unit C (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7903	Drum M EEPROM error No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively. Mismatch of reading data from two locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively.	DRPWB M	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DRPWB M and Front PWB (YC10) Front PWB (YC2) and Engine PWB (YC10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Drum unit M (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7904	Drum Y EEPROM error No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively. Mismatch of reading data from two locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively.	DRPWB Y	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DRPWB Y and Front PWB (YC14) Front PWB (YC2) and Engine PWB (YC10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Drum unit Y (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7911	Developer unit K EEPROM error No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively. Mismatch of reading data from two locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively.	Developer unit K	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer unit K and Front PWB (YC9) Front PWB (YC2) and Engine PWB (YC10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Developer unit K (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7912	Developer unit C EEPROM error No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively. Mismatch of reading data from two locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively.	Developer unit C	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer unit C and Front PWB (YC13) Front PWB (YC2) and Engine PWB (YC10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Developer unit C (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7913	Developer unit M EEPROM error No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively. Mismatch of reading data from two locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively.	Developer unit M	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer unit M and Front PWB (YC11) Front PWB (YC2) and Engine PWB (YC10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Developer unit M (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7914	Developer unit Y EEPROM error No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively. Mismatch of reading data from two locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively.	Developer unit Y	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Developer unit Y and Front PWB (YC15) Front PWB (YC2) and Engine PWB (YC10) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Developer unit Y (see page 1-5-44).
		Front PWB	Replace the front PWB
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7941	Laser scanner unit K EEPROM error [35 ppm/ 45 ppm/ 55 ppm model] Mismatch of reading data from two locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively.	APC PWB K	1. Confirm that the FFC wiring connector is not distorted and connect the FFC wiring all the way in. APC PWB K and LSU relay PWB (YC5) LSU relay PWB (YC2) and Engine PWB (YC11) 2. If the FFC wiring is disconnected, shorted or grounded, replace the FFC wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		LSU relay PWB	REPLACE the LSU relay PWB.
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7942	Laser scanner unit C EEPROM error [35 ppm/ 45 ppm/ 55 ppm model] Mismatch of reading data from two locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively.	APC PWB C	1. Confirm that the FFC wiring connector is not distorted and connect the FFC wiring all the way in. APC PWB C and LSU relay PWB (YC10) LSU relay PWB (YC2) and Engine PWB (YC11) 2. If the FFC wiring is disconnected, shorted or grounded, replace the FFC wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		LSU relay PWB	REPLACE the LSU relay PWB.
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
7943	Laser scanner unit M EEPROM error [35 ppm/ 45 ppm/ 55 ppm model] Mismatch of reading data from two locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively.	APC PWB M	1. Confirm that the FFC wiring connector is not distorted and connect the FFC wiring all the way in. APC PWB M and LSU relay PWB (YC8) LSU relay PWB (YC2) and Engine PWB (YC11) 2. If the FFC wiring is disconnected, shorted or grounded, replace the FFC wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		LSU relay PWB	REPLACE the LSU relay PWB.
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
7944	Laser scanner unit Y EEPROM error [35 ppm/ 45 ppm/ 55 ppm model] Mismatch of reading data from two locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively.	APC PWB Y	1. Confirm that the FFC wiring connector is not distorted and connect the FFC wiring all the way in. APC PWB Y and LSU relay PWB (YC12) LSU relay PWB (YC2) and Engine PWB (YC11) 2. If the FFC wiring is disconnected, shorted or grounded, replace the FFC wiring. 3. Replace the laser scanner unit (see page 1-5-33).
		LSU relay PWB	REPLACE the LSU relay PWB.
		Engine PWB	1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
8010	Punch motor error 1 When the punch motor is driven, punch home position sensor does not turn on within 200 ms.	Punch motor	<ol style="list-style-type: none"> 1. Execute Motor - Punch of U240 finisher operation check (see page 1-3-122). 2. Manipulate the punch unit up and down to check it can smoothly move up and down. 3. Check that the drive from the motor reaches the punch cam. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Punch motor and Punch PWB (YC4) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the punch motor.
		Punch home position sensor	<ol style="list-style-type: none"> 1. Execute Punch - Punch HP of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Punch home position sensor and Punch PWB (YC8) 4. Replace the Punch home position sensor.
		Punch PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Punch PWB (YC1) and DF main PWB (YC7) (4000-sheet finisher) Punch PWB (YC1) and DF main PWB (YC8) (1000-sheet finisher) 2. Replace the punch PWB.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8020	Punch motor error 2 Home position is not obtained in 3 s after home position is initialized or in standby.	Punch motor	<ol style="list-style-type: none"> 1. Execute Motor - Punch of U240 finisher operation check (see page 1-3-122). 2. Manipulate the punch unit up and down to check it can smoothly move up and down. 3. Check that the drive from the motor reaches the punch cam. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Replace the punch PWB.Punch motor and Punch PWB (YC4) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the punch motor.
		Punch PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Punch PWB (YC1) and DF main PWB (YC7)(4000-sheet finisher) Punch PWB (YC1) and DF main PWB (YC8)(1000-sheet finisher) 2. Replace the punch PWB.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8030	Punch motor error 3 Home position does not turn from On to Off in 50 ms after home position has been initialized.	Punch motor	<ol style="list-style-type: none"> 1. Execute Motor - Punch of U240 finisher operation check (see page 1-3-122). 2. Manipulate the punch unit up and down to check it can smoothly move up and down. 3. Check that the drive from the motor reaches the punch cam. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Punch motor and Punch PWB (YC4) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the punch motor.
		Punch PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Punch PWB (YC1) and DF main PWB (YC7) (4000-sheet finisher) Punch PWB (YC1) and DF main PWB (YC8) (1000-sheet finisher) 2. Replace the punch PWB.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8090	DF paddle motor error When the DF paddle motor is driven, DF paddle sensor does not turn on within 1 s.	DF paddle motor	<ol style="list-style-type: none"> 1. Execute Motor - Beat of U240 finisher operation check (see page 1-3-122). 2. Check that the paddle can rotate. 3. Check that the drive from the motor reaches the paddle. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF paddle motor and DF main PWB (YC15) (4000-sheet finisher) DF paddle motor and DF main PWB (YC11) (1000-sheet finisher) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the DF paddle motor.
		DF paddle sensor	<ol style="list-style-type: none"> 1. Execute Finisher - Bundle Eject HP of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF paddle sensor and DF main PWB (YC22) (4000-sheet finisher) DF paddle sensor and DF main PWB (YC20) (1000-sheet finisher) 4. Replace the DF paddle sensor.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8100	DF eject release motor error When the DF eject release motor is driven, DF bundle discharge sensor does not turn on within 1 s.	DF eject release motor	<ol style="list-style-type: none"> 1. Execute Motor - Eject Unlock (Full) of U240 finisher operation check (see page 1-3-122). 2. Check that the ejection guide of the process tray is opened and, if not, repair the guide. 3. Check that the drive from the motor reaches the eject guide. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF bundle discharge unit sensor and DF main PWB (YC22)(4000-sheet finisher) DF bundle discharge unit sensor and DF main PWB (YC20)(1000-sheet finisher) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the DF eject release motor.
		DF bundle discharge unit sensor	<ol style="list-style-type: none"> 1. Execute Finisher - Bundle Eject HP of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF bundle discharge unit sensor and DF main PWB (YC22)(4000-sheet finisher) DF bundle discharge unit sensor and DF main PWB (YC20)(1000-sheet finisher) 4. Replace the DF bundle discharge unit sensor.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8110	DF shift motor 1 error (4000-sheet finisher) When the DF shift motor 1 is driven, DF shift sensor 1 does not turn on within 160 ms.	DF shift motor 1 (front)	<ol style="list-style-type: none"> 1. Execute Motor - Sort Test of U240 finisher operation check (see page 1-3-122). 2. Manipulate the front shift guide back and forth so that it is smoothly operable. 3. Check that the drive from the motor reaches the front shift guide. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF shift motor 1 and DF main PWB (YC14) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the DF shift motor 1
		DF shift set sensor 1 (front)	<ol style="list-style-type: none"> 1. Execute Finisher - Shift Front HP of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF shift set sensor 1 and DF main PWB (YC23) 4. Replace the DF shift set sensor 1.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8120	DF shift motor 2 error (4000-sheet finisher) When the DF shift motor 2 is driven, DF shift sensor 2 does not turn on within 160 ms.	DF shift motor 2 (rear)	<ol style="list-style-type: none"> 1. Execute Motor - Sort Test of U240 finisher operation check (see page 1-3-122). 2. Manipulate the rear shift guide back and forth so that it is smoothly operable. 3. Check that the drive from the motor reaches the rear shift guide. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF shift motor 2 and DF main PWB (YC14) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the DF shift motor 2.
		DF shift set sensor 2 (rear)	<ol style="list-style-type: none"> 1. Execute Finisher - Shift Trail HP of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF shift set sensor 2 and DF main PWB (YC23) 4. Replace the DF shift set sensor2.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8130	DF shift release motor error (4000-sheet finisher) When the DF shift release motor is driven, DF shift release sensor does not turn on within 1 s.	DF shift release motor	<ol style="list-style-type: none"> 1. Check that cancelling the maintenance mode after executing the Motor-Sort Test by U240 finisher operation check lets the back and forth cursors returns to the home position (see page 1-3-122). 2. Manipulate the front and rear shift guide back and forth so that it is smoothly operable. 3. Check that the drive from the motor reaches the shift guide front and rear. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF shift release motor and DF main PWB (YC23) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the DF shift release motor.
		DF shift release sensor	<ol style="list-style-type: none"> 1. Execute Finisher - Shift Unlock HP of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF shift release sensor and DF main PWB (YC23) 4. Replace the DF shift release sensor.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8140	DF tray motor error 1 When the main tray has started ascending, DF tray sensor 1 or DF tray upper surface sensor does not turn on within 20 s.	DF tray motor	<ol style="list-style-type: none"> 1. Execute Motor - Tray of U240 finisher operation check (see page 1-3-122). 2. Manipulate the main tray up and down to check it is smoothly operable. 3. Check that the drive from the motor reaches the main tray. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF tray motor and DF Main PWB(YC16) (4000-sheet finisher) DF tray motor and DF Main PWB(YC14) (1000-sheet finisher) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the DF tray motor.
		DF tray sensor 1 DF tray upper surface sensor	<ol style="list-style-type: none"> 1. Execute Finisher - Tray U-Limit, Tray Top of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF tray sensor 1 and DF Main PWB(YC22) (4000-sheet finisher) DF tray upper surface sensor and DF Main PWB(YC21,YC13) (4000-sheet finisher) DF tray sensor 1 and DF main PWB (YC20) (1000-sheet finisher) DF tray upper surface sensor and DF main PWB (YC18) (1000-sheet finisher) 4. Replace the DF tray sensor 1 or DF tray upper surface sensor.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8150	DF tray motor error 2 When the main tray has descended, DF tray sensor 1 or DF tray upper surface sensor does not turn off within 5 s.	DF tray motor	<ol style="list-style-type: none"> 1. Execute Motor - Tray of U240 finisher operation check (see page 1-3-122). 2. Manipulate the main tray up and down to check it is smoothly operable. 3. Check that the drive from the motor reaches the main tray. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF tray motor and DF main PWB (YC16) (4000-sheet finisher) DF tray motor and DF main PWB (YC14) (1000-sheet finisher) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the DF tray motor.
		DF tray sensor 1 DF tray upper surface sensor	<ol style="list-style-type: none"> 1. Execute Finisher - Tray U-Limit, Tray Top of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF tray sensor 1 and DF main PWB (YC22) (4000-sheet finisher) DF tray upper surface sensor and DF main PWB (YC21, YC13) (4000-sheet finisher) DF tray sensor 1 and DF main PWB (YC20) (1000-sheet finisher) DF tray upper surface sensor and DF main PWB (YC18) (1000-sheet finisher) 4. Replace the DF tray sensor 1 or DF tray upper surface sensor.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8160	DF tray motor error 3 When the main tray has descended, DF tray sensor 3 does not turn on within 20 s.	DF tray motor	<ol style="list-style-type: none"> 1. Execute Motor - Tray of U240 finisher operation check (see page 1-3-122). 2. Manipulate the main tray up and down to check it is smoothly operable. 3. Check that the drive from the motor reaches the main tray. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF tray motor and DF main PWB (YC16) (4000-sheet finisher) DF tray motor and DF main PWB (YC14) (1000-sheet finisher) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the DF tray motor.
		DF tray sensor 4	<ol style="list-style-type: none"> 1. Execute Finisher - Tray Middle of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF tray sensor 4 and DF main PWB (YC23) (4000-sheet finisher) DF tray sensor 4 and DF main PWB (YC20) (1000-sheet finisher) 4. Replace the DF tray sensor 4.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8170	DF side registration motor 1 error 1 When initial operation, DF side registration sensor 1 does not turn on within 3 s.	DF side registration motor 1	<ol style="list-style-type: none"> 1. Execute Motor - Width Test of U240 finisher operation check (see page 1-3-122). 2. Manipulate the front side registration guide back and forth so that it is smoothly operable. 3. Check that the drive from the motor reaches the front side registration guide. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF side registration motor 1 and DF main PWB (YC15) (4000-sheet finisher) DF side registration motor 1 and DF main PWB (YC11) (1000-sheet finisher) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the DF side registration motor 1.
		DF side registration sensor 1	<ol style="list-style-type: none"> 1. Execute Finisher - Width Front of U241 finisher switch check(see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF side registration sensor 1. and DF main PWB (YC22) (4000-sheet finisher) DF side registration sensor 1. and DF main PWB (YC20) (1000-sheet finisher) 4. Replace the DF side registration sensor 1.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8180	DF side registration motor 1 error 2 JAM6810 (jam in front of width alignment) is detected twice.	DF side registration motor 1	<ol style="list-style-type: none"> 1. Execute Motor - Width Test of U240 finisher operation check (see page 1-3-122). 2. Manipulate the front side registration guide back and forth so that it is smoothly operable. 3. Check that the drive from the motor reaches the front side registration guide. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF side registration motor 1 and DF main PWB (YC15) (4000-sheet finisher) DF side registration motor 1 and DF main PWB (YC11) (1000-sheet finisher) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the DF side registration motor 1.
		DF side registration sensor 1.	<ol style="list-style-type: none"> 1. Execute Finisher - Width Front of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF side registration sensor 1. and DF main PWB (YC22) (4000-sheet finisher) DF side registration sensor 1. and DF main PWB (YC20) (1000-sheet finisher) ??If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the DF side registration sensor 1.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8190	DF side registration motor 2 error 1 When initial operation, DF side registration sensor 2 does not turn on within 3 s.	DF side registration motor 2	<ol style="list-style-type: none"> 1. Execute Motor - Width Test of U240 finisher operation check (see page 1-3-122). 2. Manipulate the rear side registration guide back and forth so that it is smoothly operable. 3. Check that the drive from the motor reaches the rear side registration guide. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF side registration motor 2 and DF main PWB (YC15) (4000-sheet finisher) DF side registration motor 2 and DF main PWB (YC11) (1000-sheet finisher) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the DF side registration motor 2.
		DF side registration sensor 2	<ol style="list-style-type: none"> 1. Execute Finisher - Width tail HP of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF side registration sensor 2 and DF main PWB (YC22) (4000-sheet finisher) DF side registration sensor 2 and DF main PWB (YC20) (1000-sheet finisher) 4. Replace the DF side registration sensor 2.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8200	DF side registration motor 2 error 2 JAM6910 (jam in front of width alignment) is detected twice.	DF side registration motor 2	<ol style="list-style-type: none"> 1. Execute Motor - Width Test of U240 finisher operation check (see page 1-3-122). 2. Manipulate the rear side registration guide back and forth so that it is smoothly operable. 3. Check that the drive from the motor reaches the rear side registration guide. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF side registration motor 2 and DF main PWB (YC15) (4000-sheet finisher) DF side registration motor 2 and DF main PWB (YC11) (1000-sheet finisher) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the DF side registration motor 2.
		DF side registration sensor 2	<ol style="list-style-type: none"> 1. Execute Finisher - Width Tail HP of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF side registration sensor 2 and DF main PWB (YC22) (4000-sheet finisher) DF side registration sensor 2 and DF main PWB (YC20) (1000-sheet finisher) 4. Replace the DF side registration sensor 2.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8210	DF slide motor error When initial operation, DF staple sensor does not turn on within 3 s.	DF slide motor	<ol style="list-style-type: none"> 1. Execute Motor - Staple Move of U240 finisher operation check (see page 1-3-122). 2. Manipulate the staple unit back and forth so that it is smoothly operable. 3. Check that the drive from the motor reaches the staple unit. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF slide motor and DF main PWB (YC12) (4000-sheet finisher) DF slide motor and DF main PWB (YC10) (1000-sheet finisher) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the DF slide motor.
		DF staple sensor	<ol style="list-style-type: none"> 1. Execute Finisher - Staple HP of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF staple sensor and DF main PWB (YC22) (4000-sheet finisher) DF staple sensor and DF main PWB (YC20) (1000-sheet finisher) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the DF staple sensor.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8230	DF staple motor error 1 Staple JAM (DF) has been detected twice in a row. (The home position could not be detected in 600 ms since the motor was driven after jam was detected twice.)	DF staple motor	1. Remove the staple unit and check that stapling is possible without a jam. 2. Confirm that the FFC wiring connector is not distorted and connect the FFC wiring all the way in. Staple unit and DF main PWB (YC17) (4000-sheet finisher) Staple unit and DF main PWB (YC11) (1000-sheet finisher) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the staple unit. (Refer to the service manual for the document finisher).
		DF staple sensor	Replace the staple unit.
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).
8240	DF staple motor error 2 Staple JAM (DF) has been detected twice in a row. (The second JAM detection condition fulfilled with a lock detection signal maintained 1 V for 500 ms continuously, while the stapler motor was driven.)	DF staple motor	1. Remove the staple unit and check that stapling is possible without a jam. 2. Confirm that the FFC wiring connector is not distorted and connect the FFC wiring all the way in. Staple unit and DF main PWB (YC17) (4000-sheet finisher) Staple unit and DF main PWB (YC11) (1000-sheet finisher) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the staple unit. (Refer to the service manual for the document finisher).
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).

Code	Contents	Causes	Check procedures/ corrective measures
8300	Center-folding unit communication error (4000-sheet finisher) Communication with the center-folding unit is not possible.	CF set sensor	<ol style="list-style-type: none"> 1. Execute Booklet - Set of U241 finisher switch check (see page 1-3-124). 2. Check that the SW and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. CF main PWB (YC7) and DF main PWB (YC9) 4. If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the CF set sensor.
		CF main PWB	Replace the CF main PWB
		DF main PWB	Replace the DF main PWB (Refer to the service manual for the document finisher).
8310	CF side registration motor 2 error (4000-sheet finisher) When initial operation, CF side registration sensor 2 does not turn on within 1 s.	CF side registration motor 2	<ol style="list-style-type: none"> 1. Execute Motor - Width Test of U240 finisher operation check (see page 1-3-122). 2. Manipulate the width adjuster upper guide back and forth so that it can smoothly move back and forth. 3. Check that the drive from the motor reaches the width adjuster upper guide. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. CF side registration motor 2 and CF main PWB (YC10) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the CF side registration motor.
		CF side registration sensor 2	<ol style="list-style-type: none"> 1. Execute Booklet - Width U HP of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. CF side registration sensor 2 and CF main PWB (YC20) 4. Replace the CF side registration sensor 2.
		CF main PWB	Replace the CF main PWB

Code	Contents	Causes	Check procedures/ corrective measures
8320	CF adjustment motor error (4000-sheet finisher) When initial operation, CF adjustment sensor does not turn on within 2.5 s.	CF adjustment motor1,2	<ol style="list-style-type: none"> 1. Execute Motor - Bundle U / Down of U240 finisher operation check (see page 1-3-122). 2. Manipulate the fold moving belt up and down to check it is smoothly operable. 3. Check that the drive from the motor reaches the fold moving belt. (Check if the belt is bent.) 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. CF adjustment motor 1,2 and CF main PWB (YC10) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the CF adjustment motor1,2.
		CF adjustment sensor1,2	<ol style="list-style-type: none"> 1. Execute Booklet - bundle Up / Down HP of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. CF adjustment sensor 1,2 and CF main PWB (YC20) 4. Replace the CF adjustment sensor1,2.
		CF main PWB	Replace the CF main PWB.

Code	Contents	Causes	Check procedures/ corrective measures
8330	CF blade motor error (4000-sheet finisher) When initial operation, CF blade sensor does not turn on within 3 s.	CF blade motor	<ol style="list-style-type: none"> 1. Execute Booklet - Blade of U240 finisher operation check (see page 1-3-122). 2. Manipulate the fold blade up and down to check it is smoothly operable. 3. Check that the drive from the motor reaches the fold blade. Check if the belt is bent. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. CF blade motor and CF main PWB (YC15) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the CF blade motor.
		CF blade sensor	<ol style="list-style-type: none"> 1. Execute Booklet - Blade HP of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. CF blade sensor and CF main PWB (YC20) 4. Replace the CF blade sensor.
		CF main PWB	Replace the CF main PWB
8340	CF staple motor error 1 (4000-sheet finisher) Staple JAM (center-folding unit) has been detected twice in a row. (The home position could not be detected in 600 ms since the motor was driven after jam was detected twice.)	CF staple motor	<ol style="list-style-type: none"> 1. Execute Booklet - Staple of U240 finisher operation check (see page 1-3-122). 2. Manipulate The Staple Up And Down To Check It Is Smoothly Operable. 3. Check that the drive from the motor reaches the staple. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. CF staple unit and CF main PWB (YC13) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the CF staple motor.
		CF staple sensor	Replace the CF staple unit.
		CF main PWB	Replace the CF main PWB.

Code	Contents	Causes	Check procedures/ corrective measures
8350	CF side registration motor 1 error (4000-sheet finisher) When initial operation, CF side registration sensor 1 does not turn on within 1 s.	CF side registration motor 1	<ol style="list-style-type: none"> 1. Execute Booklet - Width Test of U240 finisher operation check (see page 1-3-122). 2. Manipulate the width adjuster upper guide back and forth so that it can smoothly move back and forth. 3. Check that the drive from the motor reaches the width adjuster lower guide. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. CF side registration motor 1 and CF main PWB (YC10) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the CF side registration motor 1.
		CF side registration sensor 1	<ol style="list-style-type: none"> 1. Execute Booklet - Width Down HP of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. CF side registration sensor 1 and CF main PWB (YC20) 4. Replace the CF side registration sensor 1.
		CF main PWB	Replace the CF main PWB

Code	Contents	Causes	Check procedures/ corrective measures
8360	CF main motor error (4000-sheet finisher) During driving the motor, lock signal is detected for 1 s continuously.	CF main motor	<ol style="list-style-type: none"> 1. Execute Booklet - Folding of U240 finisher operation check (see page 1-3-122). 2. Manipulate the conveying roller so that it can smoothly rotate. 3. Check that the drive from the motor reaches the conveying roller. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. CF main motor and CF main PWB (YC16) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the CF main motor.
		CF main PWB	Replace the CF main PWB

Code	Contents	Causes	Check procedures/ corrective measures
8410	Punch slide motor error 1 The punch slide sensor won't turn On when home position has been moved by 30 mm.	Punch slide motor	<ol style="list-style-type: none"> 1. Execute Booklet - Punch Move of U240 finisher operation check (see page 1-3-122). 2. Manipulate the punch unit back and forth so that it can smoothly move back and forth. 3. Check that the drive from the motor reaches punch area. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Punch slide motor and Punch PWB (YC3) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the punch slide motor.
		Punch slide sensor	<ol style="list-style-type: none"> 1. Execute Booklet - Punch HP of U240 finisher operation check (see page 1-3-122). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Punch slide sensor and Punch PWB (YC6) 4. Replace the punch slide sensor.
		Punch PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Punch PWB (YC1) and DF main PWB (YC7) (4000-sheet finisher) Punch PWB (YC1) and DF main PWB (YC8) (1000-sheet finisher) 2. Replace the punch PWB.
		DF main PWB	Replace the DF main PWB

Code	Contents	Causes	Check procedures/ corrective measures
8420	Punch slide motor error 2 In detection of paper edges, the paper edge cannot be detected in 30 mm move.	Punch slide motor	<ol style="list-style-type: none"> 1. Execute Booklet - Punch Move of U240 finisher operation check (see page 1-3-122). 2. Manipulate the punch unit back and forth so that it can smoothly move back and forth. 3. Check that the drive from the motor reaches punch area. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Punch slide motor and Punch PWB (YC3) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the punch slide motor.
		Punch paper edge sensor 1,2	<ol style="list-style-type: none"> 1. Execute Booklet - Edge Face 1,2,3,4 of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Punch paper edge sensor 1,2 and Punch PWB (YC5,YC7) 4. Replace the punch paper edge sensor 1,2.
		Punch PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Punch PWB (YC1) and DF main PWB (YC7) (4000-sheet finisher) Punch PWB (YC1) and DF main PWB (YC8) (1000-sheet finisher) 2. Replace the Punch PWB.
		DF main PWB	Replace the DF main PWB

Code	Contents	Causes	Check procedures/ corrective measures
8430	Punch unit communication error Communication failed to be established after the punch unit was hooked up.	Punch PWB	<ol style="list-style-type: none"> 1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Punch PWB (YC1) and DF main PWB (YC7) (4000-sheet finisher) Punch PWB (YC1) and DF main PWB (YC8) (1000-sheet finisher) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Punch PWB.
		DF main PWB	Replace the DF main PWB
8500	Mailbox communication error (4000-sheet finisher) Communication failed to be established after the mailbox was hooked up.	MB Main PWB	<ol style="list-style-type: none"> 1. Turn the main power switch off and after 5 seconds, turn it on. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. MB main PWB (YC3) and DF main PWB (YC6) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the MB main PWB
		DF main PWB	Replace the DF main PWB
8510	MB conveying motor error 1 (4000-sheet finisher) When initial operation, MB home position sensor does not turn on within 5 s.	MB drive motor	<ol style="list-style-type: none"> 1. If the transfer roller won't rotate smoothly, repair its mechanism. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. MB drive motor and MB main PWB (YC5) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the MB drive motor.
		MB home position sensor	<ol style="list-style-type: none"> 1. Execute Mail Box - Motor HP of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. MB home position sensor and MB main PWB (YC2) 4. Replace the MB home position sensor.
		MB main PWB	Replace the MB main PWB

Code	Contents	Causes	Check procedures/ corrective measures
8520	MB conveying motor error 2 (4000-sheet finisher) When standby operation, MB home position sensor does not turn off within 1 s.	MB drive motor	<ol style="list-style-type: none"> 1. Execute Mail Box - Conv of U240 finisher operation check (see page 1-3-122). 2. Manipulate the conveying roller of the mailbox so that it can smoothly rotate. 3. Check that the drive from the motor reaches the conveying roller. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. MB drive motor and MBMain PWB (YC5) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the MB drive motor.
		MB home position sensor	<ol style="list-style-type: none"> 1. Execute Mail Box - Motor HP of U241 finisher switch check (see page 1-3-124). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. MB home position sensor and MB main PWB (YC2) 4. Replace the MB home position sensor.
		MB main PWB	Replace the MB main PWB

Code	Contents	Causes	Check procedures/ corrective measures
8800	Document finisher main program error Document finisher main program error at power up.	DF main PWB	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF main PWB (YC4) and Engine PWB (YC18) (4000-sheet finisher) DF main PWB (YC7) and Engine PWB (YC18) (1000-sheet finisher) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the DF main PWB
		Engine PWB	Check the engine software and upgrade to the latest, if necessary. Replace the engine PWB (see page 1-5-64).
8900	Document finisher backup error Read and write data does not match 3 times in succession.	DF main PWB	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DF main PWB (YC4) and Engine PWB (YC18) (4000-sheet finisher) DF main PWB (YC7) and Engine PWB (YC18) (1000-sheet finisher) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the DF main PWB
8930	Center-folding unit backup error (4000-sheet finisher) Read and write data does not match 3 times in succession.	CF main PWB	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. CF main PWB (YC7) and DF main PWB (YC9) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. INSTALL the EEPROM properly. 4. Replace the CF main PWB

Code	Contents	Causes	Check procedures/ corrective measures
9000	Document processor communication error Communication with the document processor is not possible.	DP main PWB	1. Check that the versions of the main unit firmware and the DP firmware are identical. 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DP main PWB(YC1) and ISC PWB(YC12) ISC PWB (YC3) and Main PWB (YC11) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. DPReplace the main PWB
		ISC PWB	Replace the ISC PWB.
9010	Coin vender communication error A communication error from coin vender is detected 10 times in succession.	U206 setting	Set maintenance mode U206 to off when a coin vender is not installed (see page 1-3-112).
		Coin vender control PWB	1. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. Coin vender control PWB and Engine PWB (YC23) 2. If the wiring is disconnected, shorted or grounded, replace the wiring. 3. Replace the Coin vender control PWB.
		Engine PWB	Check the engine software and upgrade to the latest, if necessary. Replace the engine PWB (see page 1-5-64).

Code	Contents	Causes	Check procedures/ corrective measures
9040	DP lift motor going up error When the DP lift motor is driven, DP lift sensor 1 does not turn on within 1500 pulse. (Three recovery times.) The above has been detected 5 times.	DP lift motor	<ol style="list-style-type: none"> 1. Execute U906 Separating Operation Release (see page 1-3-201). 2. Execute Lift Motor of U243 DP motor operation check (see page 1-3-127). 3. Check that the original document lift guide can move upwards. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DP lift motor and DP MAIN PWB (YC5) 5. If the wiring is disconnected, shorted or grounded, replace the wiring. 6. Replace the DP lift motor.
		DP lift sensor 1	<ol style="list-style-type: none"> 1. Execute LIFT L-Limit of U244 DP switch check (see page 1-3-128). 2. Check that the sensor and its mounting board are correctly positioned. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DP lift sensor 1 and DP MAIN PWB (YC4) 4. Replace the DP lift sensor 1.
		DP MAIN PWB	Replace the DP main PWB

Code	Contents	Causes	Check procedures/ corrective measures
9050 DP lift motor going down error When the DP lift motor is driven, DP lift sensor 2 does not turn on within 1500 pulse. (Three recovery times.) The above has been detected 5 times.		DP lift motor	<ol style="list-style-type: none"> 1. Execute U906 Separating Operation Release (see page 1-3-201). 2. Execute Lift Motor of U243 DP motor operation check (see page 1-3-127). 3. Check that the original document lift guide can move downwards. 4. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DP lift motor and DP MAIN PWB (YC5) If the wiring is disconnected, shorted or grounded, replace the wiring. 5. Replace the DP lift motor.
		DP lift sensor 2	<ol style="list-style-type: none"> 1. Execute Lift L-Limit of U244 DP switch check (see page 1-3-128). 2. Confirm that the DP lift sensor 2 has been firmly fitted. 3. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DP lift sensor 2 and DP MAIN PWB (YC2) 4. Replace the DP lift sensor2.
		DP main PWB	Replace the DP main PWB
9060 DP EEPROM error Mismatch of reading data from two locations occurs 3 times successively. Mismatch between writing data and reading data occurs 3 times successively.		DP main PWB	<ol style="list-style-type: none"> 1. Execute U906 Separating Operation Release (see page 1-3-201). 2. Confirm that the EEPROM has been properly installed. 3. DPReplace the main PWB
		Device damage of EEPROM	Contact the Service Support.
9070 Communication error between DP and SHD A communication error is detected.		DP SHD PWB	<ol style="list-style-type: none"> 1. Execute U906 Separating Operation Release (see page 1-3-201). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. DP SHD PWB (YC1) and DP main PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the DP SHD PWB.

Code	Contents	Causes	Check procedures/ corrective measures
9080	LED fault detection A block is existent below a peak which was obtained by activating the LEDs in the four CIS blocks at power on, which is less than 80hex.	DP CIS	<ol style="list-style-type: none"> 1. Execute CIS automatic original document alignment by U411 (see page 1-3-160). 2. Confirm that the power connector is firmly connected and, if necessary, connect the connector all the way in. CIS and DP SHD PWB (YC2) DP SHD PWB (YC1) and DP MAIN PWB (YC10) 3. If the wiring is disconnected, shorted or grounded, replace the wiring. 4. Replace the CIS and execute U411.
		DPSHD PWB	Replace the DP SHD PWB.
9100	Coin vender control PWB error Communication error has been detected at the coin mec of the coin vender control PWB.	Coin vender control PWB	Replace the coin mec.
9110	Coin vender error Communication error has been detected in connection with the coin mec and the rejector.	Rejector	<ol style="list-style-type: none"> 1. Check that the rejector is firmly installed and, if not, install firmly. 2. Replace the Rejector.
9120	Sensor error in coin vender change (Yen 10) Change is empty despite change is enough.	Coin jam in the change tube	Check visually and remedy.
		Contact in the connector	Check the connection of the empty change sensor.
		Change empty sensor	Replace the coin mec.
		Coin vender control PWB	Replace the coin mec.
9130	Sensor error in coin vender change (Yen 50) Change is empty despite change is enough.	Coin jam in the change tube	Check visually and remedy.
		Contact in the connector	Check the connection of the empty change sensor.
		Change empty sensor	Replace the coin mec.
		Coin vender control PWB	Replace the coin mec.

Code	Contents	Causes	Check procedures/ corrective measures
9140	Sensor error in coin vender change (Yen 100) Change is empty despite change is enough.	Coin jam in the change tube	Check visually and remedy.
		Contact in the connector	Check the connection of the empty change sensor.
		Change empty sensor	Replace the coin mec.
		Coin vender Control PWB	Replace the coin mec.
9150	Sensor error in coin vender change (Yen 500) Change is empty despite change is enough.	Change tube	Check no exchange jam is observed at the outlet and, if necessary, repair it.
		Change empty sensor	1. Reinsert the connector if it its connection is loose. 2. Replace the coin mec.
		Coin vender control PWB	Replace the coin mec.
9160	Coin vender pay-out error Coin is paid out despite the pay-out motor is determined not active.	Pay-out motor	Replace the coin mec.
9170	Coin vender pay-out sensor error Coin is paid out despite the pay-out motor is determined not active.	Pay-out area	Check no exchange jam is observed at the outlet and, if necessary, repair it.
		Pay-out motor	Replace the coin mec.
		Pay-out sensor	Replace the coin mec.
9500	ISC PWB error A	Main PWB ISC PWB	1. Reinsert the connector if it its connection is loose. Main PWB (YC25) and ISC PWB (YC4) 2. Replace the main PWB (see page 1-5-59). 3. Replace the ISC main PWB 4. Contact the Service Support.
9510	ISC PWB error B	Main PWB DPSHD PWB	1. Reinsert the connector if it its connection is loose. DP relay PWB (YC2) and DPSHD PWB (YC3) 2. Replace the main PWB (see page 1-5-59). 3. Replace the DPSHD PWB. 4. Contact the Service Support.

Code	Contents	Causes	Check procedures/ corrective measures
9520	ISC PWB error C	Main PWB ISC PWB	<ol style="list-style-type: none"> 1. Reinsert the connector if its connection is loose. Main PWB (YC25) and ISC PWB (YC4) 2. Replace the main PWB (see page 1-5-59). 3. Replace the ISC main PWB 4. Contact the Service Support.
F000	Communication error between main PWB and operation PWB	Main PWB	<ol style="list-style-type: none"> 1. Turn the main power switch off and after 5 seconds, then turn power on. 2. Check that the wirings and connectors between the main circuit PWB and the operation circuit PWB and between the main circuit PWB and the HDD are normal. Main PWB (YC12,YC17,YC30) and Operation PWB (YC1,YC2,YC3) 3. Check that the DDR memories in the main circuit PWB are well conducted and, if not, replace. 4. Execute U024 to initialize (FULL) the HDD (see page 1-3-32). 5. Execute U021 to initialize memory. (see page 1-3-29) 6. Replace the Main PWB. 7. Copy the log File saved in the HDD by U964 in USB memory and contact the service support (see page 1-3-211).
		Operation PWB	Replace the operation PWB (see page 1-5-71).
F010	Main PWB checksum error	Main PWB	<ol style="list-style-type: none"> 1. Turn the main power switch off and after 5 seconds, then turn power on. 2. If not corrected, replace the main PWB (see page 1-5-59).

Code	Contents	Causes	Check procedures/ corrective measures
F040	Communication error between main PWB and print engine	Main PWB	<ol style="list-style-type: none"> 1. Turn the main power switch off and after 5 seconds, then turn power on. 2. Repair or replace the wire from the engine PWB, that may be grounded. (Check short-circuit between 5V and 3.3V.) 3. Check that the FFC wire connecting between the main PWB (YC3) and the engine PWB (YC46) is normal and, if necessary, re-insert. Or, replace the FFC wire. 4. If not corrected, replace the main PWB (see page 1-5-59).
		Engine PWB	<ol style="list-style-type: none"> 1. Check the engine software and upgrade to the latest, if necessary. 2. Replace the engine PWB (see page 1-5-64).
		HDD	Replace the HDD (see page 1-5-101).
F041	Communication error between main PWB and scanner engine	Main PWB	<ol style="list-style-type: none"> 1. Turn the main power switch off and after 5 seconds, then turn power on. 2. Check that the wires between the main PWB and the ISC PWB are normal. 3. If not corrected, replace the main PWB (see page 1-5-59).
		ISC PWB	Replace the ISC PWB.
F050	Print engine ROM checksum error	Engine software	Install the latest engine software.
		Engine PWB	<ol style="list-style-type: none"> 1. Turn the main power switch off and after 5 seconds, then turn power on. 2. Confirm that the EEPROM has been properly installed. 3. If not corrected, Replace the engine PWB (see page 1-5-64).
F051	Scanner engine ROM checksum error	Scanner software	Install the latest scanner software.
		ISC PWB	<ol style="list-style-type: none"> 1. Turn the main power switch off and after 5 seconds, then turn power on. 2. Confirm that the EEPROM has been properly installed. 3. If not corrected, Replace the ISC PWB.

Code	Contents	Causes	Check procedures/ corrective measures
F278	Power supply in drive system error	The main power switch was turned off before the power switch is pressed. Shutdown due to a power failure	Turn the main power switch off and after 5 seconds, then turn power on. (Before turning power off, verify that the power key has been pressed and the power indicator has gone off, then switch the main power switch.)

1-4-4 Image formation problems

Isolate the component an image defect has occurred from.

<A guide to isolate the component of the cause.>

Run U089 to print a test page and check whether an image defect happens.

YES: Main unit as the cause of defect

NO: Scanner as the cause of defect

Perform enlarged or reduced copying and verify if the defective images are enlarged or reduced, accordingly.

YES: Scanner as the cause of defect

1. Scanner as the cause of defect:

If the defect occurs with copying or sending, refer to P.1-4-202.

(Defects caused by a reading error that occurs at the original (glass) LED lamp to CCD (DP: CIS).)

Isolate the problem at the location that the originals are scanned.

a. Single DP side (read by Main CCD)

b. On the contact glass (read by Main CCD)

c. Back side DP (For DPs mounted with CIS)

2. Main unit as the cause of defect:

Verify whether the problem is caused with mono or full color development (defects seen over the entire image).

(1)Main unit as the cause of defect (Mono color) If the defect of image occurs with mono color development of a particular color, refer to p. 1-4-184.


(A defect occurs from the rendering process that involves charging, drum, LSU, developer, and primary transferring.)

(2)Main unit as the cause of defect (Image entirety) If the defect of image occurs with full color development, refer to p. 4-4-198.


(A defect of transferring and paper conveyance occurs from the rendering process that involves the intermediate belt, secondary transfer roller, fuser, ejection.)

<Flow of image data>


Copying :




Sending :




Printing data from PC :



FAX (send) :



FAX receive :



<Flow of rendering image>

Charging > Drum > LSU > Development > Primary transfer (Intermediate transfer belt)
>Secondary transfer > Fusing

1-4-5 Poor image (due to DP and scanner reading)

(1) No image appears (entirely white).



1-4-203

(2) No image appears (entirely black).



1-4-206

(3) Image is too light.



1-4-208

(4) The background is colored.




1-4-212

(5) White streaks are printed vertically.



1-4-215

(6) Black or color streaks appear longitudinally.



1-4-218

(7) Streaks are printed horizontally.



1-4-222

(8) One side of the print image is darker than the other.



1-4-225

(9) Black or color dots appear on the image.




1-4-228

(10) Image is blurred.



1-4-230

(11) The leading edge of the image is consistently misaligned with the original.



1-4-233

(12) Part of image is missing.



1-4-235

(13) Image is out of focus.




1-4-238

(14) Image center does not align with the original center.




1-4-240

(15) Shifted colors




1-4-241

(16) Moire



1-4-244

(17) Skewed image




1-4-245

(18) Abnormal image



1-4-247

(1) No image appears (entirely white).

1. Table scanning

	Defective part	Check description	Corrective Action
1	Contact glass assy	Check the location the contact glass is mounted.	Re-mount the contact glass if it is hanged off.
2	FFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
3	Home position sensor	Check the location the Home position sensor is mounted.	Re-mount the Home position sensor if it is hanged off.
4	Scanner wire drum	Check that the scanner drive gear is loosely mounted.	If the optical wire drum is loosely mounted, secure the screws.
5	Scanner drive gear	Check that the scanner drive gear is loosely mounted.	If the scanner drive gear loosely mounted, secure the screw.
6	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
7	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
8	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

2. DP-scanning first (front) page


	Defective part	Check description	Corrective Action
1	Original document	Verify the sides of the original document.	If the sides of the original document are reversed, place the original document properly.
2	Contact glass assy	Check the location the contact glass is mounted.	Re-mount the contact glass if it is hanged off.
3	FFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
4	Home position sensor	Check the location the Home position sensor is mounted.	Re-mount the Home position sensor if it is hanged off.
5	Scanner wire drum	Check that the scanner drive gear is loosely mounted.	If the optical wire drum is loosely mounted, secure the screws.
6	Scanner drive gear	Check that the scanner drive gear is loosely mounted.	If the scanner drive gear loosely mounted, secure the screw.
7	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
8	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
9	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

3. DP-scanning second (back) page (with a dual scan DP installed)

	Defective part	Check description	Corrective Action
1	Original document	Verify the sides of the original document.	If the sides of the original document are reversed, place the original document properly.
2	White-reference roller(Counter the CIS)	Check that the white-reference roller is smoothly operative.	If the white-reference roller does not rotate smoothly, re-install.
3	White-reference roller(Counter the CIS)	Check if the white reference roller is contaminated on its surface or damaged.	If the white-reference roller is dirty, clean. Or, if the roller is damaged, replace.
43	DP_CIS unit	Check the location the CIS unit is mounted.	Re-mount the CIS unit if it is hanged off.
5	DP_SHD PWB	Check the CIS and the SHD PWB is properly connected.	Reinsert the connector if the PWB was loosely inserted.If not cured, replace the PWB.
6	DP_CIS	CIS is defective.	Replace the CIS and perform U091 and U411. (see page 1-3-67,1-3-160)
7	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	Original document	Verify the sides of the original document.	If the sides of the original document are reversed, place the original document properly.
2	Contact glass assy	Check the location the contact glass is mounted.	Re-mount the contact glass if it is hanged off.
3	FFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
4	Home position sensor	Check the location the Home position sensor is mounted.	Re-mount the Home position sensor if it is hanged off.
5	Scanner wire drum	Check that the scanner drive gear is loosely mounted.	If the optical wire drum is loosely mounted, secure the screws.
6	Scanner drive gear	Check that the scanner drive gear is loosely mounted.	If the scanner drive gear loosely mounted, secure the screw.
7	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
8	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
9	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

(2) No image appears (entirely black).

1. Table scanning

	Defective part	Check description	Corrective Action
1	FFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
2	SATA cable ISC	Check the SATA cable between the ISC PWB and main PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
3	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
4	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
5	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

2. DP-scanning first (front) page

	Defective part	Check description	Corrective Action
1	Scanning position of the DP	Confirm the value using maintenance mode U068, DP Read.	If a large value is observed in maintenance mode U068, DP Read, perform adjustment.(see page 1-3-56)
2	FFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
3	SATA cable ISC	Check the SATA cable between the ISC PWB and main PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
4	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
5	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)


	Defective part	Check description	Corrective Action
6	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

3. DP-scanning second (back) page (with a dual scan DP installed)

	Defective part	Check description	Corrective Action
1	DP_CIS unit	Check the location the CIS unit is mounted.	Re-mount the CIS unit if it is hanged off.
2	DP_SHD PWB	Check the CIS and the SHD PWB is properly connected.	Reinsert the connector if the PWB was loosely inserted.If not cured, replace the PWB.
3	DP_CIS	CIS is defective.	replace the CIS and perform U091 and U411. (see page 1-3-67,1-3-160)
4	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	Scanning position of the DP	Confirm the value using maintenance mode U068, DP Read.	If a large value is observed in maintenance mode U068, DP Read, perform adjustment.(see page 1-3-56)
2	FFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
3	SATA cable ISC	Check the SATA cable between the ISC PWB and main PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
4	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
5	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
6	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

(3) Image is too light.

1. Table scanning

	Defective part	Check description	Corrective Action
1	The settings of the adjustment of density	Check the settings of the adjustment of density.	1. Deactivate EcoPrint if it is activated. Or, if the density is too low, choose an image quality that suits the original document in type. 2. Increase density. 3. Perform the background color adjustment using the system menu.
2	Settings of anti-offset	Check the settings of anti-offset.	If anti-offset is set to on, set it to off.
3	Adjustment of the scanner	Check the automatic adjustment of the scanner.	Perform maintenance mode U411, table(Chart1)_All. (see page 1-3-160)
4	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
5	Home position sensor	Check the location the Home position sensor is mounted.	Re-mount the Home position sensor if it is hanged off.
6	FFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
7	FFC cable LED	Check the FFC cable between the LED PWB and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
8	Lamp unit	Check the location the lamp unit is mounted.	Re-mount the lamp unit if it is hanged off.
9	LED PWB	Check that the LED is lit.	If the LED is not lit, replace the LED PWB and perform U411.
10	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
11	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)

	Defective part	Check description	Corrective Action
12	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

2. DP-scanning first (front) page

	Defective part	Check description	Corrective Action
1	The settings of the adjustment of density	Check the settings of the adjustment of density.	1. Deactivate EcoPrint if it is activated. Or, if the density is too low, choose an image quality that suits the original document in type. 2. Increase density. 3. Perform the background color adjustment using the system menu.
2	Settings of anti-offset	Check the settings of anti-offset.	If anti-offset is set to on, set it to off.
3	Adjustment of the scanner	Check the automatic adjustment of the scanner.	Perform maintenance mode U411, DP FaceUp(Chart1)_Input(see page 1-3-160)
4	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
5	Home position sensor	Check the location the Home position sensor is mounted.	Re-mount the Home position sensor if it is hanged off.
6	Scanning position of the DP	Check whether the scanning position of the DP is wrong.	If the scanning position of the DP is shifted, perform maintenance mode U068, DP Read.(see page 1-3-56)
7	FFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
8	FFC cable LED	Check the FFC cable between the LED PWB and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
9	Lamp unit	Check the location the lamp unit is mounted.	Re-mount the lamp unit if it is hanged off.
10	LED PWB	Check that the LED is lit.	If the LED is not lit, replace the LED PWB and perform U411.
11	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
12	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
13	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)


3. DP-scanning second (back) page (with a dual scan DP installed)

	Defective part	Check description	Corrective Action
1	The settings of the adjustment of density	Check the settings of the adjustment of density.	1. Deactivate EcoPrint if it is activated. Or, if the density is too low, choose an image quality that suits the original document in type. 2. Increase density. 3. Perform the background color adjustment using the system menu.
2	Settings of anti-offset	Check the settings of anti-offset.	If anti-offset is set to on, set it to off.
3	Adjustment of the scanner	Check the automatic adjustment of the scanner.	Perform maintenance mode U411, DP FaceDown(Char1)_All (see page 1-3-160)
4	White-reference roller(Counter the CIS)	Check that the white-reference roller is smoothly operative.	If the white-reference roller does not rotate smoothly, re-install.
5	White-reference roller(Counter the CIS)	Check if the white reference roller is contaminated on its surface or damaged.	If the white-reference roller is dirty, clean. Or, if the roller is damaged, replace.
6	DP_CIS unit	Check the location the CIS unit is mounted.	Re-mount the CIS unit if it is hanged off.
7	DP_SHD PWB	Check the CIS and the SHD PWB is properly connected.	Reinsert the connector if the PWB was loosely inserted.If not cured, replace the PWB.
8	DP_CIS	CIS is defective.	Replace the CIS and perform U091 and U411. (see page 1-3-67,1-3-160)
9	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	The settings of the adjustment of density	Check the settings of the adjustment of density.	1. Deactivate EcoPrint if it is activated. Or, if the density is too low, choose an image quality that suits the original document in type. 2. Increase density. 3. Perform the background color adjustment using the system menu.
2	Settings of anti-offset	Check the settings of anti-offset.	If anti-offset is set to on, set it to off.
3	Adjustment of the scanner	Check the automatic adjustment of the scanner.	Perform maintenance mode U411, DP FaceUp(Char1)_Input. (see page 1-3-160)

	Defective part	Check description	Corrective Action
4	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
5	Home position sensor	Check the location the Home position sensor is mounted.	Re-mount the Home position sensor if it is hanged off.
6	Scanning position of the DP	Check whether the scanning position of the DP is wrong.	If the scanning position of the DP is shifted, perform maintenance mode U068, DP Read.(see page 1-3-56)
7	FFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
8	FFC cable LED	Check the FFC cable between the LED PWB and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
9	Lamp unit	Check the location the lamp unit is mounted.	Re-mount the lamp unit if it is hanged off.
10	LED PWB	Check that the LED is lit.	If the LED is not lit, replace the LED PWB and perform U411.
11	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
12	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
13	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

(4) The background is colored.

1. Table scanning

	Defective part	Check description	Corrective Action
1	Original document	1. Check if the background density of the original document is too dense. 2. Check if the original document is floated during scanning.	1. If the background density of the original document is too dense, perform automatic background adjustment. Or, adjust density with background adjustment. 2. If the original document is floated during scanning, press down the original document.
2	Adjustment of the scanner	Check the automatic adjustment of the scanner.	Perform maintenance mode U411, table(Chart1)_All. (see page 1-3-160)
3	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
4	Contact glass assy	Check the location the contact glass is mounted.	Re-mount the contact glass if it is hanged off.
5	Home position sensor	Check the location the Home position sensor is mounted.	Re-mount the Home position sensor if it is hanged off.
6	FFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
7	FFC cable LED	Check the FFC cable between the LED PWB and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
8	Lamp unit	Check the location the lamp unit is mounted.	Re-mount the lamp unit if it is hanged off.
9	LED PWB	Check that the LED is lit.	If the LED is not lit, replace the LED PWB and perform U411.
10	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
11	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)

	Defective part	Check description	Corrective Action
12	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

2. DP-scanning first (front) page

	Defective part	Check description	Corrective Action
1	Original document	1. Check if the background density of the original document is too dense. 2. Check if the original document is floated during scanning.	1. If the background density of the original document is too dense, perform automatic background adjustment.Or, adjust density with background adjustment. 2. Adjust the location the DP is mounted.
2	Adjustment of the scanner	Check the automatic adjustment of the scanner.	Perform maintenance mode U411, DP FaceDown(Char1)_All. (see page 1-3-160)
3	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
4	Contact glass assy	Check the location the contact glass is mounted.	Re-mount the contact glass if it is hanged off.
5	Home position sensor	Check the location the Home position sensor is mounted.	Re-mount the Home position sensor if it is hanged off.
6	Installing DP	Check whether the DP frame is distorted or the hinges are damaged.	Replace the DP.
7	FFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
8	FFC cable LED	Check the FFC cable between the LED PWB and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
9	Lamp unit	Check the location the lamp unit is mounted.	Re-mount the lamp unit if it is hanged off.
10	LED PWB	Check that the LED is lit.	If the LED is not lit, replace the LED PWB and perform U411.
11	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
12	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
13	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

3. DP-scanning second (back) page (with a dual scan DP installed)


	Defective part	Check description	Corrective Action
1	Original document	1. Check if the background density of the original document is too dense. 2. Check if the original document is floated during scanning.	1. If the background density of the original document is too dense, perform automatic background adjustment.Or, adjust density with background adjustment. 2. Adjust the location the CIS unit is mounted.
2	Adjustment of the scanner	Check the automatic adjustment of the scanner.	Perform maintenance mode U411, DP FaceDown(Char1)_All. (see page 1-3-160)
3	White-reference roller(Counter the CIS)	Check that the white-reference roller is smoothly operative.	If the white-reference roller does not rotate smoothly, re-install.
4	White-reference roller(Counter the CIS)	Check if the white reference roller is contaminated on its surface or damaged.	If the white-reference roller is dirty, clean. Or, if the roller is damaged, replace.
5	DP_CIS unit	Check the location the CIS unit is mounted.	Re-mount the CIS unit if it is hanged off.
6	DP_SHD PWB	Check the CIS and the SHD PWB is properly connected.	Reinsert the connector if the PWB was loosely inserted.If not cured, replace the PWB.
7	DP_CIS	CIS is defective.	Replace the CIS and perform U091 and U411. (see page 1-3-67,1-3-160)
8	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	Original document	1. Check if the background density of the original document is too dense. 2. Check if the original document is floated during scanning.	1. If the background density of the original document is too dense, perform automatic background adjustment.Or, adjust density with background adjustment. 2. Adjust the location the DP is mounted.
2	Adjustment of the scanner	Check the automatic adjustment of the scanner.	Perform maintenance mode U411, DP FaceUp(Char1)_Input. (see page 1-3-160)
3	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
4	Contact glass assy	Check the location the contact glass is mounted.	Re-mount the contact glass if it is hanged off.
5	Home position sensor	Check the location the Home position sensor is mounted.	Re-mount the Home position sensor if it is hanged off.

	Defective part	Check description	Corrective Action
6	Installing DP	Check whether the DP frame is distorted or the hinges are damaged.	Replace the DP.
7	FFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
8	Lamp unit	Check the location the lamp unit is mounted.	Re-mount the lamp unit if it is hanged off.
9	LED PWB	Check that the LED is lit.	If the LED is not lit, replace the LED PWB and perform U411.
10	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
11	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
12	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

(5) White streaks are printed vertically.



1. Table scanning

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
3	Mirror	Check whether the mirrors are dirty.	If the mirrors are dirty, clean the three mirrors.
4	Lamp unit	Check that the lamp unit is contaminated with dusts.	If dusts are observed on the lamp unit, remove the dusts in the light paths.
5	Lamp unit	Check whether the LED cover is hanged off.	Re-mount the LED cover if it is hanged off.

	Defective part	Check description	Corrective Action
6	ISU	Check whether the lens cover is hanged off.	Re-mount the lens cover if it is hanged off.
7	Shading plate	Check whether the shading plate is dirty.	If the shading plate is dirty, perform maintenance mode U063 to modify the shading position. If it does not cure, replace the contact glass assembly. (see page 1-3-160)
8	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
9	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
10	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

2. DP-scanning first (front) page

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
3	Mirror	Check whether the mirrors are dirty.	If the mirrors are dirty, clean the three mirrors.
4	Lamp unit	Check that the lamp unit is contaminated with dusts.	If dusts are observed on the lamp unit, remove the dusts in the light paths.
5	Lamp unit	Check whether the LED cover is hanged off.	Re-mount the LED cover if it is hanged off.
6	ISU	Check whether the lens cover is hanged off.	Re-mount the lens cover if it is hanged off.
7	Shading plate	Check whether the shading plate is dirty.	If the shading plate is dirty, perform maintenance mode U063 to modify the shading position. If it does not cure, replace the contact glass assembly. (see page 1-3-51)
8	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
9	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
10	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

3. DP-scanning second (back) page (with a dual scan DP installed)


	Defective part	Check description	Corrective Action
1	White-reference roller (Counter the CIS)	Check if the white reference roller is contaminated on its surface or damaged.	If the white-reference roller is dirty, clean. Or, if the roller is damaged, replace.
2	DP_CIS glass	Check whether the CIS glass is contaminated.	If the CIS glass is contaminated, clean the CIS glass and conveying guide. If it has a scuff, replace.
3	White streaks compensation settings	Check the white streaks compensation settings.	Check the white streaks compensation settings.
4	DP_CIS unit	Check the location the CIS unit is mounted.	Re-mount the CIS unit if it is hanged off.
5	DP_SHD PWB	Check the CIS and the SHD PWB is properly connected.	Reinsert the connector if the PWB was loosely inserted. If not cured, replace the PWB.
6	DP_CIS	CIS is defective.	Replace the CIS and perform U091 and U411. (see page 1-3-67, 1-3-160)
7	Main PWB	The main PWB is defective.	Replace the main PWB. (see page 1-5-59)

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
3	Mirror	Check whether the mirrors are dirty.	If the mirrors are dirty, clean the three mirrors.
4	Lamp unit	Check that the lamp unit is contaminated with dusts.	If dusts are observed on the lamp unit, remove the dusts in the light paths.
5	Lamp unit	Check whether the LED cover is hanged off.	Re-mount the LED cover if it is hanged off.
6	ISU	Check whether the lens cover is hanged off.	Re-mount the lens cover if it is hanged off.
7	Shading plate	Check whether the shading plate is dirty.	If the shading plate is dirty, perform maintenance mode U063 to modify the shading position. If it does not cure, replace the contact glass assembly. (see page 1-3-51)
8	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)

	Defective part	Check description	Corrective Action
9	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
10	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

(6) Black or color streaks appear longitudinally.



1. Table scanning

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	Original document	Check if the size of the original document and its reference size match.	If the size of the original document and its reference size do not match, set the correct document size or activate border erasure.
3	Contact glass assy	Check the location the contact glass is mounted.	Re-mount the contact glass if it is hanged off.
4	Adjustment of the scanner	Check the scanning adjustment of the scanner.	1. Perform maintenance mode U067, Front.(see page 1-3-55) 2. Perform maintenance mode U411, table (Chart1)_Input. (see page 1-3-160)
5	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean.
6	mirror	Check whether the mirrors are dirty.	If the mirrors are dirty, clean the three mirrors.
7	Lamp unit	Check that the lamp unit is contaminated with dusts.	If dusts are observed on the lamp unit, remove the dusts in the light paths.
8	CCD sensor	Check the dust on the CCD sensor glass.	Check whether the CCD sensor glass is stuck with dusts, and if necessary, remove the dusts by an air blower.

	Defective part	Check description	Corrective Action
9	Shading plate	Check whether the shading plate is dirty.	If the shading plate is dirty, perform maintenance mode U063 to modify the shading position. If it does not cure, replace the contact glass assembly. (see page 1-3-51)
10	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
11	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
12	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

2. DP-scanning first (front) page

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	Original document	Check if the size of the original document and its reference size match.	If the size of the original document and its reference size do not match, set the correct document size or activate border erasure.
3	Scanning position of the DP	Check whether the scanning position of the DP is wrong.	If the scanning position of the DP is shifted, perform maintenance mode U068, DP Read. (see page 1-3-56)
4	Adjustment of the scanner	Check if the outer areas of the original document have streaks or lines.	1. Perform maintenance mode U072, Front. (see page 1-3-61) 2. Perform maintenance mode U411, DP Auto Adj. 3. Perform maintenance mode U411, DP FaceUp(Char2)_Input. (see page 1-3-160)
5	Slit glass, Contact glass	Check whether the slit glass and contact glass are dirty.	If the slit glass and contact glass are dirty, clean the contact glass, the slit glass, the bottom part of the shading plate, and the conveying guide.
6	Mirror	Check whether the mirrors are dirty.	If the mirrors are dirty, clean the three mirrors.
7	Lamp unit	Check that the lamp unit is contaminated with dusts.	If dusts are observed on the lamp unit, remove the dusts in the light paths.
8	CCD sensor	Check the dust on the CCD sensor glass.	Check whether the CCD sensor glass is stuck with dusts, and if necessary, remove the dusts by an air blower.


	Defective part	Check description	Corrective Action
9	Shading plate	Check whether the shading plate is dirty.	If the shading plate is dirty, perform maintenance mode U063 to modify the shading position. If it does not cure, replace the contact glass assembly. (see page 1-3-51)
10	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
11	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
12	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

3. DP-scanning second (back) page (with a dual scan DP installed)

	Defective part	Check description	Corrective Action
1	Adjustment of the scanner	Check if the outer areas of the original document have streaks or lines.	1. Perform maintenance mode U072, Front. (see page 1-3-61) 2. Perform maintenance mode U411, DP Auto Adj. 3. Perform maintenance mode U411, DP FaceDown(Char1)_All. (see page 1-3-160)
2	DP_CIS glass	Check whether the CIS glass of the DP is contaminated.	If the CIS glass of the DP is contaminated, clean. Or, if it has scuffs, replace.
3	DP guide plate	Check whether the DP guide plate roller is dirty.	Clean the guide plate and the conveying guide.
4	DP regist pulley	The DP regist pulley is contaminated.	Clean the DP regist pulley.
5	White-reference roller(Counter the CIS)	Check if the white reference roller is contaminated on its surface or damaged.	If the white-reference roller is dirty, clean. Or, if the roller is damaged, replace.
6	White streaks compensation settings	Check the white streaks compensation settings.	If the white streaks compensation is insufficient, perform maintenance mode U091.(see page 1-3-67)
7	DP_CIS unit	Check the location the CIS unit is mounted.	Re-mount the CIS unit if it is hanged off.
8	DP_SHD PWB	Check the CIS and the SHD PWB is properly connected.	Reinsert the connector if the PWB was loosely inserted.If not cured, replace the PWB.
9	DP_CIS	CIS is defective.	Replace the CIS and perform U091 and U411. (see page 1-3-67,1-3-160)
10	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	Original document	Check if the size of the original document and its reference size match.	If the size of the original document and its reference size do not match, set the correct document size or activate border erasure.
3	Adjustment of the scanner	Check if the outer areas of the original document have streaks or lines.	Perform maintenance mode U072, Front. (see page 1-3-61)
4	Scanning position of the DP	Check whether the scanning position of the DP is wrong.	If the scanning position of the DP is shifted, perform maintenance mode U068, DP Read. (see page 1-3-56)
5	Slit glass, contact glass	Check whether the slit glass and contact glass are dirty.	If the slit glass and contact glass are dirty, clean the contact glass, the slit glass, the bottom part of the shading plate, and the conveying guide.
6	Mirror	Check whether the mirrors are dirty.	If the mirrors are dirty, clean the three mirrors.
7	Lamp unit	Check that the lamp unit is contaminated with dusts.	If dusts are observed on the lamp unit, remove the dusts in the light paths.
8	CCD sensor	Check the dust on the CCD sensor glass.	Check whether the CCD sensor glass is stuck with dusts, and if necessary, remove the dusts by an air blower.
9	Shading plate	Check whether the shading plate is dirty.	If the shading plate is dirty, perform maintenance mode U063 to modify the shading position. If it does not cure, replace the contact glass assembly. (see page 1-3-51)
10	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
11	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
12	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

(7) Streaks are printed horizontally.

1. Table scanning

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
4	Ajusting scanner	Check that the image at the back of the size indicator has been rendered.	1. If the image at the back of the size indicator, perform maintenance mode U066, Front. (see page 1-3-54) 2. Perform maintenance mode U411, table(Chart1)_Input.(see page 1-3-160)
5	FFFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
6	FFC cable LED	Check the FFC cable between the LED PWB and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
7	SATA cable ISC	Check the SATA cable between the ISC PWB and main circuit PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
10	LED PWB	Check that the LED is lit.	If the LED is not lit, replace the LED PWB and perform U411.
11	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
12	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

2. DP-scanning first (front) page

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.


	Defective part	Check description	Corrective Action
2	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
3	FFFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
4	FFC cable LED	Check the FFC cable between the LED PWB and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
5	SATA cable ISC	Check the SATA cable between the ISC PWB and main circuit PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
6	LED PWB	Check that the LED is lit.	If the LED is not lit, replace the LED PWB and perform U411.
7	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
8	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

3. DP-scanning second (back) page (with a dual scan DP installed)

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	DP_CIS glass	Check whether the CIS glass of the DP is contaminated.	If the CIS glass of the DP is contaminated, clean. Or, if it has scuffs, replace.
3	DP_CIS unit	Check the location the CIS unit is mounted.	Re-mount the CIS unit if it is hanged off.
4	DP_SHD PWB	Check the CIS and the SHD PWB is properly connected.	Reinsert the connector if the PWB was loosely inserted.If not cured, replace the PWB.
5	DP_SATA cable	Check the FFC cable between the SHD PWB and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
6	DP_CIS	CIS is defective.	Replace the CIS and perform U091 and U411. (see page 1-3-67,1-3-160)
7	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
3	FFFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
4	FFC cable LED	Check the FFC cable between the LED PWB and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
5	SATA cable ISC	Check the SATA cable between the ISC PWB and main circuit PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
6	LED PWB	Check that the LED is lit.	If the LED is not lit, replace the LED PWB and perform U411.
7	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
8	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

(8) One side of the print image is darker than the other.

1. Table scanning

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	Original document	Check if the original document has creases or foldings or wrinkles.	If the original document has foldings or creases, remove them.
3	Position of the mat of the platen	Check whether the position of the mat of the DP or the platen is wrong.	If the position of the mat of the DP or the platen is shifted, re-mount.
4	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
5	Contact glass assy	Check the location the contact glass is mounted.	Re-mount the contact glass if it is hanged off.
6	Lamp unit	Check that the contact part of the lamp unit and the rail is distorted.	If the contact part of the lamp unit and the rail is distorted, replace the lamp unit.
7	Mirror	Check whether the mirrors are dirty.	If the mirrors are dirty, clean the three mirrors.
8	ISU	Check the location the ISU unit is mounted.	Insert a spacer between the scanner unit and the ISU to change the height. (Refer to the service bulletin #B314 (2LC-0026).) .(see page 1-5-26)
9	LED PWB	Check that the LED is lit.	If the LED is not lit, replace the LED PWB and perform U411.(see page 1-3-160)
10	LED Assy	Check the mounting position of the refelector board or if it is distorted.	If the LED assy is hanged off of the mounting position of the reflector or it is deformed, replace the LED assy.
11	Lamp unit	Check that the contact part of the lamp unit and the rail is distorted.	If the contact part of the lamp unit and the rail is distorted, replace the lamp unit.
12	Mirror unit	Check the location the mirror is mounted.	Re-mount the mirror if it is hanged off. Or, if the mirror is damaged, replace.

	Defective part	Check description	Corrective Action
13	Mirror unit	Check that the contact part of the mirror unit and the rail is distorted.	If the contact part of the mirror unit and the rail is distorted, replace the mirror unit.
14	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
15	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
16	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

2. DP-scanning first (front) page

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	Original document	Check if the original document has creases or foldings or wrinkles.	If the original document has foldings or creases, remove them.
3	DP scanning guide	Check that the scanning guide is smoothly operative.	If the scanning guide does not rotate smoothly, re-install.
4	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
5	Contact glass assy	Check the location the contact glass is mounted.	Re-mount the contact glass if it is hanged off.
6	LED PWB	Check that the LED is lit.	If the LED is not lit, replace the LED PWB and perform U411.
7	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
8	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
9	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

3. DP-scanning second (back) page (with a dual scan DP installed)


	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	Original document	Check if the original document has creases or foldings or wrinkles.	If the original document has foldings or creases, remove them.

	Defective part	Check description	Corrective Action
3	White-reference roller(Counter the CIS)	Check that the white-reference roller is smoothly operative.	If the white-reference roller does not rotate smoothly, re-install.
4	DP_CIS	CIS is defective.	Replace the CIS and perform U091 and U411. (see page 1-3-67,1-3-160)
5	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	Original document	Check if the original document has creases or foldings or wrinkles.	If the original document has foldings or creases, remove them.
3	DP scanning guide	Check that the scanning guide is smoothly operative.	If the scanning guide does not rotate smoothly, re-install.
4	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
5	Contact glass assy	Check the location the contact glass is mounted.	Re-mount the contact glass if it is hanged off.
6	LED PWB	Check that the LED is lit.	If the LED is not lit, replace the LED PWB and perform U411. (see page 1-3-160)
7	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
8	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
9	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

(9) Black or color dots appear on the image.



1. Table scanning

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
3	FFFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
4	SATA cable ISC	Check the SATA cable between the ISC PWB and main circuit PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
5	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

2. DP-scanning first (front) page


	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
3	FFFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
4	SATA cable ISC	Check the SATA cable between the ISC PWB and main circuit PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
5	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

3. DP-scanning second (back) page (with a dual scan DP installed)

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	DP_SHD PWB	Check the CIS and the SHD PWB is properly connected.	Reinsert the connector if the PWB was loosely inserted.If not cured, replace the PWB.
3	DP_SATA cable	Check the FFC cable between the SHD PWB and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
4	DP_CIS	CIS is defective.	Replace the CIS and perform U091 and U411. (see page 1-3-67,1-3-160)
5	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is dirty.	If the original document is dirty, replace.
2	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
3	FFFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
4	SATA cable ISC	Check the SATA cable between the ISC PWB and main circuit PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
5	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

(10) Image is blurred.

1. Table scanning

	Defective part	Check description	Corrective Action
1	Rail	Check that the carriage is smoothly operative.	If the carriage does not travel smoothly, remove foreign objects on the front and back optical rails.
2	Lamp unit	Check that the carriage is smoothly operative.	If the carriage does not travel smoothly because the lamp unit contacts with the frame, rectify.
3	Optical wire drum	Confirm that a foreign object exists between the wire rope and the optical wire drum.	If a foreign object exists, remove.
4	Mirror unit	Check that a foreign object exists in the grooves of the pulley.	If a foreign object exists in the grooves of the pulleys, remove.
5	Pulley	Check that a foreign object exists in the grooves of the pulleys other than above.	If a foreign object exists in the grooves of the pulleys, remove.
6	Wire rope	Confirm that the wire rope has a foreign object stuck or has a scuff.	If a foreign object exists on the wire rope, remove the foreign object. Or, if it is damaged, replace.

2. DP-scanning first (front) page

	Defective part	Check description	Corrective Action
1	DP conveying pulley	Check that the conveying pulley is smoothly operative.	If the conveying pulley does not rotate smoothly, re-assemble the conveying roller and springs.
2	Adjustment height of the hinge portions of the DP	Check the height of the front and back portions of the DP.	If the front and back side of the DP is not leveled, adjust the hinge on the left side.
3	Install DP	Check how it is mounted on the main unit.	If the front and back side of the DP is not leveled, adjust the hinge on the left side.
4	DP hinge	Check that the DP hinge is operative in both ascending and descending directions and kept open.	If the DP is not operative smoothly or is not held stably open, remove the hinges.


	Defective part	Check description	Corrective Action
5	DP document mat	Check the location the document mat of the DP is mounted.	Re-mount the document mat of the DP if it is hanged off.
6	Original document	Check that the leading edge of the original document is dog-eared.	If the leading edge of the original documet is dog-eared, straighten.
7	Scanning guide	Check if the scanning guide is distorted.	If the scanning guide deformed, replace.
8	Scopper guide	Check that the scopper guide is smoothly operative.	If the scopper guide does not rotate smoothly, re-install.
9	Conveying pulley(the front and back portions of scanning)	Check whether the feed roller is dirty.	If the feed roller is dirty, clean.
10	Drive belt	Check if the drive belt is jumping gear teeth.	If the drive belt is jumping gear teeth, re-mount the belt tensioner.

3. DP-scanning second (back) page (with a dual scan DP installed)

	Defective part	Check description	Corrective Action
1	DP conveying pulley	Check that the conveying pulley is smoothly operative.	If the conveying pulley does not rotate smoothly, re-asslemble the conveying roller and springs.
2	Install DP	Check how it is mounted on the main unit.	If mounting to the main unit is improper, check positioning and secure the screws.
3	DP hinge	Check that the DP hinge is operative in both ascending and descending directions and kept open.	If the DP is not operative smoothly or is not held stably open, remove the hinges.
4	DP document mat	Check the location the document mat of the DP is mounted.	Re-mount the document mat of the DP if it is hanged off.
5	Original document	Check that the leading edge of the original document is dog-eared.	If the leading edge of the original documet is dog-eared, straighten.
6	Scanning roller	Check if the scanning roller is floated.	If the scanning roller is floated, re-assemble.
7	Conveying pulley(the front and back portions of scanning)	Check whether the feed roller is dirty.	If the feed roller is dirty, clean.
8	Scanning roller	Check if the scanning glass is floated.	If the scanning glass is floated, re-assemble.
9	Drive belt	Check if the drive belt is jumping gear teeth.	If the drive belt is jumping gear teeth, re-mount the belt tensioner.

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	DP conveying pulley	Check that the conveying pulley is smoothly operative.	If the conveying pulley does not rotate smoothly, re-assemble the conveying roller and springs.
2	Adjustment height of the hinge portions of the DP	Check the height of the front and back portions of the DP.	If the front and back side of the DP is not leveled, adjust the hinge on the left side.
3	Install DP	Check how it is mounted on the main unit.	If mounting to the main unit is improper, check positioning and secure the screws.
4	DP hinge	Check that the DP hinge is operative in both ascending and descending directions and kept open.	If the DP is not operative smoothly or is not held stably open, remove the hinges.
5	DP document mat	Check the location the document mat of the DP is mounted.	Re-mount the document mat of the DP if it is hanged off.
6	Original document	Check that the leading edge of the original document is dog-eared.	If the leading edge of the original document is dog-eared, straighten.
7	Scanning guide	Check if the scanning guide is distorted.	If the scanning guide deformed, replace.
8	Scopper guide	Check that the scopper guide is smoothly operative.	If the scopper guide does not rotate smoothly, re-install.
9	Conveying pulley(the front and back portions of scanning)	Check whether the feed roller is dirty.	If the feed roller is dirty, clean.
10	Drive belt	Check if the drive belt is jumping gear teeth.	If the drive belt is jumping gear teeth, re-mount the belt tensioner.

(11) The leading edge of the image is consistently misaligned with the original.

1. Table scanning

	Defective part	Check description	Corrective Action
1	Original document	Check if the original document is loaded correctly in the contact glass.	If the original document is not properly placed on the contact glass, place it correctly.
2	Secures the lamp unit	Confirm the orientation of the bracket that secures the wire rope and the lamp unit.	If the bracket that fixes the wire rope and the lamp unit is misaligned, align the bracket properly.
3	Adjustment of the scanner	Check the scanning adjustment of the scanner.	1. Perform maintenance mode U066, Front. (see page 1-3-54) 2. Perform maintenance mode U411, table(Char1)_Input. (see page 1-3-160)
4	Home position sensor	Check the location the Home position sensor is mounted.	Re-mount the Home position sensor if it is hanged off.
5	Drive belt	Check that the scanner drive gear is loosely mounted.	If the scanner drive gear loosely mounted, secure the screw.
6	Scanner wire drum	Check that the scanner drive gear is loosely mounted.	If the optical wire drum is loosely mounted, secure the screws.
7	Scanner drive gear	Check that the scanner drive gear is loosely mounted.	If the scanner drive gear loosely mounted, secure the screw.

2. DP-scanning first (front) page


	Defective part	Check description	Corrective Action
1	Adjustment of the scanner	Check the scanning adjustment of DP scanning.	1. Perform maintenance mode U071, CIS Head. (see page 1-3-59) 2. Perform maintenance mode U411, DP Auto Adj. (only a dual scan DP installed) 3. Perform maintenance mode U411, FaceUp(Char2)_Input. (see page 1-3-160)
2	Original conveying roller	Check if the conveyer roller is contaminated or worn.	If the feed roller is dirty, clean the feed roller and its axles. If the roller is worn out, replace.
3	DP drive motor	Check whether the DP drive motor is fluctuated in rotation.	If the DP motor is fluctuated in rotation, apply grease with the drive gear. If no improvement is observed, replace the motor.

3. DP-scanning second (back) page (with a dual scan DP installed)

	Defective part	Check description	Corrective Action
1	Adjustment of the scanner	Check the scanning adjustment of DP scanning.	<ol style="list-style-type: none"> 1. Perform maintenance mode U071, CIS Head. (see page 1-3-59) 2. Perform maintenance mode U411, DP Auto Adj. (only a dual scan DP installed) 3. Perform maintenance mode U411, FaceUp(Char2)_Input. (see page 1-3-160)

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	Adjustment of the scanner	Check the scanning adjustment of DP scanning.	<ol style="list-style-type: none"> 1. Perform maintenance mode U071, Back Head. (see page 1-3-59)

(12) Part of image is missing.

1. Table scanning

	Defective part	Check description	Corrective Action
1	Original document	Check if the original document is loaded correctly in the contact glass.	If the original document is not properly placed on the contact glass, place it correctly.
2	Original document	<ol style="list-style-type: none"> 1. Check that the size of the original document and the paper size match on the panel. 2. Check that the copying position has been automatically rotated. 	<ol style="list-style-type: none"> 1. If the sizes of the original document and the paper do not match, manually set the proper paper size for the original document. 2. Check the paper size automatic detection switch and replace if faulty. 3. If the copying position is automatically rotated, deactivate automatic image
3	Settings of Border removal	Check the value of border removal.	If a large value is given to bordere erasure, change it to a smaller value.
4	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
5	Contact glass assy	Check the location the contact glass is mounted.	Re-mount the contact glass if it is hanged off.
6	FFFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
7	SATA cable ISC	Check the SATA cable between the ISC PWB and main circuit PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
8	Lamp unit	Check the location the lamp unit is mounted.	Re-mount the lamp unit if it is hanged off.
9	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
10	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
11	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

2. DP-scanning first (front) page

	Defective part	Check description	Corrective Action
1	Original document	Check if the original document is loaded correctly in the DP.	If the original document is not properly placed on the contact glass, place it correctly.
2	Original document	1. パネル上の表示で原稿サイズと用紙サイズが一致しているか確認する。 2. Check that the copying position has been automatically rotated.	1. If the sizes of the original document and the paper do not match, manually set the proper paper size for the original document. 2. Check the paper size automatic detection switch and replace if faulty. 3. If the copying position is automatically rotated, deactivate automatic image rotation by the system menu.
3	Settings of Border removal	Check the value of border removal.	If a large value is given to bordere erasure, change it to a smaller value.
4	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
5	FFFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
6	SATA cable ISC	Check the SATA cable between the ISC PWB and main circuit PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.
7	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
8	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
9	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)


3. DP-scanning second (back) page (with a dual scan DP installed)

	Defective part	Check description	Corrective Action
1	Original document	Check if the original document is loaded correctly in the DP.	If the original document is not properly placed on the contact glass, place it correctly.
2	Original document	Check the size of the original document and its reference size.	If the size of the original document and its reference size do not match, manually set the document size.
3	Settings of Border removal	Check the value of border removal.	If a large value is given to bordere erasure, change it to a smaller value.

	Defective part	Check description	Corrective Action
4	DP_SATA cable	Check the FFC cable between the SHD PWB and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
5	DP_SHD PWB	Check the CIS and the SHD PWB is properly connected.	Reinsert the connector if the PWB was loosely inserted.If not cured, replace the PWB.
6	DP_CIS	CIS is defective.	Replace the CIS and perform U091 and U411. (see page 1-3-67,1-3-160)
7	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	Original document	Check if the original document is loaded correctly in the DP.	If the original document is not properly placed on the contact glass, place it correctly.
2	Original document	Check the size of the original document and its reference size.	If the size of the original document and its reference size do not match, manually set the document size.
3	Settings of Border removal	Check the value of border removal.	If a large value is given to bordere erasure, change it to a smaller value.
4	Contact glass	Check whether the contact glass is dirty.	If the contact glass is dirty, clean the contact glass, and the bottom part of the shading plate.
5	FFFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
6	SATA cable ISC	Check the SATA cable between the ISC PWB and main circuit PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
7	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
8	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
9	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

(13) Image is out of focus.

1. Table scanning and DP-scanning first (front) page

	Defective part	Check description	Corrective Action
1	Original document	Check whether the original document is wavy.	If the original document is wavy, straighten.Or, replace the original document.
2	Contact glass	Check the dew on the contact glass.	Check whether the contact glass for dew condensation, and if necessary, remove the dew.
3	Mirror	Check the dew on the mirror.	If the mirrors are dew-condensed, remove the dew.
4	Lens	The lens has dew condensation.	Remove the dew on lens.
5	CCD sensor	Check the dew on the CCD sensor glass.	Check whether the CCD sensor glass for dew condensation, and if necessary, remove the dew.
6	Adjustment of the scanner	Check the automatic adjustment of the scanner.	Perform maintenance mode U411, table(Chart1)_All. (see page 1-3-160)
7	ISU	Confirm the position of the lens and the CCD sensor.	If the lenses and the CCD sensor are misaligned, replace the ISU and perform U411.
8	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
9	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)


2. DP-scanning second (back) page (with a dual scan DP installed)

	Defective part	Check description	Corrective Action
1	DP_CIS glass	Check the dew on the CIS glass.	Check whether the CIS glass for dew condensation, and if necessary, remove the dew.
2	DP_CIS glass	Check whether the CIS glass is contaminated.	If the CIS glass is contaminated, clean the CIS glass. If it has a scuff, replace.

	Defective part	Check description	Corrective Action
3	White-reference roller(Counter the CIS)	Check that the white-reference roller is smoothly operative.	If the white-reference roller does not rotate smoothly, re-install.
4	Adjustment of the scanner	Check the automatic adjustment of the scanner.	Perform maintenance mode U411, DP FaceDown(Char1)_All. (see page 1-3-160)
5	DP_CIS unit	Check the location the CIS unit is mounted.	Re-mount the CIS unit if it is hanged off.
6	DP_CIS	CIS is defective.	Replace the CIS and perform U091 and U411. (see page 1-3-67,1-3-160)

3. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	Contact glass	Check the dew on the contact glass.	Check whether the contact glass for dew condensation, and if necessary, remove the dew.
2	Mirror	Check the dew on the mirror.	If the mirrors are dew-condensed, remove the dew.
3	Lens	The lens has dew condensation.	Remove the dew on lens.
4	CCD sensor	Check the dew on the CCD sensor glass.	Check whether the CCD sensor glass for dew condensation, and if necessary, remove the dew.
5	Adjustment of the scanner	Check the automatic adjustment of the scanner.	Perform maintenance mode U411, table(Char1)_All. (see page 1-3-160)
6	ISU	Confirm the position of the lens and the CCD sensor.	If the lenses and the CCD sensor are misaligned, replace the ISU and perform U411. (see page 1-3-160)
7	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
8	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

(14) Image center does not align with the original center.

1. Table scanning

	Defective part	Check description	Corrective Action
1	Original document	Check if the original document is loaded correctly in the contact glass.	If the original document is not properly placed on the contact glass, place it correctly.
2	Contact glass assy	Check the location the contact glass is mounted.	Re-mount the contact glass if it is hanged off.
3	Adjustment of the scanner	Check the scanning adjustment of the scanner.	1. Perform maintenance mode U067, Front.(see page 1-3-55) 2. Perform maintenance mode U411, table(Char1)_Input. (see page 1-3-160)

2. DP-scanning first (front) page

	Defective part	Check description	Corrective Action
1	Original document	Check if the original document is loaded correctly in the DP.	If the original document is not properly placed on the contact glass, place it correctly.
2	Adjustment of the scanner	Check the scanning adjustment of DP scanning.	1. Perform maintenance mode U072, Front. 2. Perform maintenance mode U411, DP Auto Adj. (If a duplex scanning DP is installed.) 3. Perform maintenance mode U411, DP FaceUp(Char2)_Input. (see page 1-3-160)


3. DP-scanning second (back) page (with a dual scan DP installed)

	Defective part	Check description	Corrective Action
1	Original document	Check if the original document is loaded correctly in the DP.	If the original document is not properly placed on the contact glass, place it correctly.
2	Adjustment of the scanner	Check the scanning adjustment of DP scanning.	1. Perform maintenance mode U071, CIS Head. (see page 1-3-59) 2. Perform maintenance mode U411, DP Auto Adj. (only a dual scan DP installed) 3. Perform maintenance mode U411, FaceUp(Char2)_Input. (see page 1-3-160)

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	Original document	Check if the original document is loaded correctly in the DP.	If the original document is not properly placed on the contact glass, place it correctly.
2	Adjustment of the scanner	Check the scanning adjustment of DP scanning.	1. Perform maintenance mode U072, Rear. (see page 1-3-61)

(15) Shifted colors



1. Table scanning

	Defective part	Check description	Corrective Action
1	Rail	Check that the carriage is smoothly operative.	If the carriage does not travel smoothly, remove foreign objects on the front and back optical rails.
2	Lamp unit	Check that the carriage is smoothly operative.	If the carriage does not travel smoothly because the lamp unit contacts with the frame, rectify.
3	Optical wire drum	Confirm that a foreign object exists between the wire rope and the optical wire drum.	If a foreign object exists, remove.
4	Mirror unit	Check that a foreign object exists in the grooves of the pulley.	If a foreign object exists in the grooves of the pulleys, remove.
5	Pulley	Check that a foreign object exists in the grooves of the pulleys other than above.	If a foreign object exists in the grooves of the pulleys, remove.
6	Wire rope	Confirm that the wire rope has a foreign object stuck or has a scuff.	If a foreign object exists on the wire rope, remove the foreign object. Or, if it is damaged, replace.

2. DP-scanning first (front) page

	Defective part	Check description	Corrective Action
1	DP conveying pulley	Check that the conveying pulley is smoothly operative.	If the conveying pulley does not rotate smoothly, re-assemble the conveying roller and springs.

	Defective part	Check description	Corrective Action
2	Adjustment height of the hinge portions of the DP.	Check the height of the front and back portions of the DP.	If the front and back side of the DP is not leveled, adjust the hinge on the left side.
3	Install DP	Check how it is mounted on the main unit.	If mounting to the main unit is improper, check positioning and secure the screws.
4	DP hinge	Check that the DP hinge is operative in both ascending and descending directions and kept open.	If the DP is not operative smoothly or is not held stably open, remove the hinges.
5	DP document mat	Check the location the document mat of the DP is mounted.	Re-mount the document mat of the DP if it is hanged off.
6	Original document	Check that the leading edge of the original document is dog-eared.	If the leading edge of the original document is dog-eared, straighten.
7	Scanning guide	Check if the scanning guide is distorted.	If the scanning guide deformed, replace.
8	Scoper guide	Check that the scoper guide is smoothly operative.	If the scoper guide does not rotate smoothly, re-install.
9	Conveying pulley(the front and back portions of scanning)	Check whether the feed roller is dirty.	If the feed roller is dirty, clean.
10	Drive belt	Check if the drive belt is jumping gear teeth.	If the drive belt is jumping gear teeth, re-mount the belt tensioner.

3. DP-scanning second (back) page (with a dual scan DP installed)


	Defective part	Check description	Corrective Action
1	DP conveying pulley	Check that the conveying pulley is smoothly operative.	If the conveying pulley does not rotate smoothly, re-assemble the conveying roller and springs.
2	Install DP	Check how it is mounted on the main unit.	If mounting to the main unit is improper, check positioning and secure the screws.
3	DP hinge	Check that the DP hinge is operative in both ascending and descending directions and kept open.	If the DP is not operative smoothly or is not held stably open, remove the hinges.
4	DP document mat	Check the location the document mat of the DP is mounted.	Re-mount the document mat of the DP if it is hanged off.
5	Original document	Check that the leading edge of the original document is dog-eared.	If the leading edge of the original document is dog-eared, straighten.

	Defective part	Check description	Corrective Action
6	Scanning roller	Check if the scanning roller is floated.	If the scanning roller is floated, re-assemble.
7	Conveying pulley(the front and back portions of scanning)	Check whether the feed roller is dirty.	If the feed roller is dirty, clean.
8	Scanning guide	Check if the scanning guide is floated.	If the scanning glass is floated, re-assemble.
9	Drive belt	Check if the drive belt is jumping gear teeth.	If the drive belt is jumping gear teeth, re-mount the belt tensioner.

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	DP conveying pulley	Check that the conveying pulley is smoothly operative.	If the conveying pulley does not rotate smoothly, re-assemble the conveying roller and springs.
2	Adjustment height of the hinge portions of the DP	Check the height of the front and back portions of the DP.	If the front and back side of the DP is not leveled, adjust the hinge on the left side.
3	Install DP	Check how it is mounted on the main unit.	If mounting to the main unit is improper, check positioning and secure the screws.
4	DP hinge	Check that the DP hinge is operative in both ascending and descending directions and kept open.	If the DP is not operative smoothly or is not held stably open, remove the hinges.
5	DP document mat	Check the location the document mat of the DP is mounted.	Re-mount the document mat of the DP if it is hanged off.
6	Original document	Check that the leading edge of the original document is dog-eared.	If the leading edge of the original document is dog-eared, straighten.
7	Scanning guide	Check if the scanning guide is distorted.	If the scanning guide deformed, replace.
8	Scopper guide	Check that the scopper guide is smoothly operative.	If the scopper guide does not rotate smoothly, re-install.
9	Conveying pulley(the front and back portions of scanning)	Check whether the feed roller is dirty.	If the feed roller is dirty, clean.
10	Drive belt	Check if the drive belt is jumping gear teeth.	If the drive belt is jumping gear teeth, re-mount the belt tensioner.

(16) Moire



1. Table scanning

	Defective part	Check description	Corrective Action
1	Settings of print quality mode	Confirm whether the moire varies depending on print quality mode.	Switch print quality mode if the moire varies depending on print quality mode. 1. Execute printing in text or print mode. 2. Reduce the sharpness (to minus).
2	Original document	Check if moire is observed along the direction of scanning of the original document.	If moire is observed, place the original document after rotating it 90-degree.
3	Scaling factor	Happens with the zoom ratio of 100%.	Reduce the real-size ratio of the main scan direction by U065.
4	Adjustment of the scanner	Check the automatic adjustment of the scanner.	Perform maintenance mode U411, table(Chart1)_All. (see page 1-3-61)

2. DP-scanning first (front) page

	Defective part	Check description	Corrective Action
1	Settings of print quality mode	Confirm whether the moire varies depending on print quality mode.	Switch print quality mode if the moire varies depending on print quality mode. 1. Execute printing in text or print mode. 2. Reduce the sharpness (to minus).
2	Adjustment of the scanner	Check the automatic adjustment of the scanner.	Perform maintenance mode U411, table(Chart1)_All. (see page 1-3-160)


3. DP-scanning second (back) page (with a dual scan DP installed)

	Defective part	Check description	Corrective Action
1	Settings of print quality mode	Confirm whether the moire varies depending on print quality mode.	Switch print quality mode if the moire varies depending on print quality mode. 1. Execute printing in text or print mode. 2. Reduce the sharpness (to minus).
2	Adjustment of the scanner	Check the automatic adjustment of the scanner.	Perform maintenance mode U411, DP FaceDown(Chart1)_All. (see page 1-3-160)

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	Settings of print quality mode	Confirm whether the moire varies depending on print quality mode.	Switch print quality mode if the moire varies depending on print quality mode. 1. Execute printing in text or print mode. 2. Reduce the sharpness (to minus).
2	Adjustment of the scanner	Check the automatic adjustment of the scanner.	Perform maintenance mode U411, table(Chart1)_All. (see page 1-3-160)

(17) Skewed image



1. Table scanning

	Defective part	Check description	Corrective Action
1	Original document	Check if the original document is fed askew.	If the original document is not placed askew on the contact glass, place it correctly.
2	本体_ スキャナー ユニット高さ調整	Check the scanner unit is quite level.	If the scanner unit is not quite level, perform the height adjustment of the entire scanner unit.
3	Lamp unit	Check the location the lamp unit is mounted.	Re-mount the lamp unit if it is hanged off.

2. DP-scanning first (front) page

	Defective part	Check description	Corrective Action
1	Original document	Check if the original document has creases or foldings or wrinkles.	If the original document has foldings or creases, remove them.
2	DP paper feed	Check if the original document has creases or foldings or wrinkles.	If the original document has foldings or creases, remove them.
3	Lamp unit	Check the location the lamp unit is mounted.	Re-mount the lamp unit if it is hanged off.

	Defective part	Check description	Corrective Action
4	Feed roller in the DP	Check whether the feed roller is dirty.	If the feed roller is dirty, clean.Or, if not cured, replace the feed roller.
5	DP regist roller	Check whether the DP regist roller is dirty.	If the DP regist roller is dirty, clean.
6	DP regist pulley	Check that the DP regist pulley is smoothly operative.	If the DP regist pulley does not rotate smoothly, re-install.
7	Adjustment amount of slack of the original documen	Check the amount of slack of the original document when it reaches at the regist.	If the amount of the slack of the original document right in front of the DP regist. is insufficient, perform maintenance mode U942, DP sluck settings.(see page 1-3-208)
8	The original docu-ment	Check that the cursor matches with the original document.	Align the cursor to match with the original document, if necessary.
9	Adjustment posi-tions of the hinge	Check the front and back adjust-ment positions of the right-hand side hinge.	If the front and back adjustment positions of the hinge are improper, perform adjustment.


3. DP-scanning second (back) page (with a dual scan DP installed)

	Defective part	Check description	Corrective Action
1	Original document	Check if the original document has creases or foldings or wrinkles.	If the original document has foldings or creases, remove them.
2	DP paper feed	Check if the original document has creases or foldings or wrinkles.	If the original document has foldings or creases, remove them.
3	DP regist roller	Check whether the DP regist roller is dirty.	If the DP regist roller is dirty, clean.
4	DP regist pulley	Check that the DP regist pulley is smoothly operative.	If the DP regist pulley does not rotate smoothly, re-install.
5	Adjustment amount of slack of the original documen	Check the amount of slack of the original document when it reaches at the regist.	If the amount of the slack of the original document right in front of the DP regist. is insufficient, perform maintenance mode U942, DP sluck settings. (see page 1-3-208)
6	The original docu-ment	Check that the cursor matches with the original document.	Align the cursor to match with the original document, if necessary.
7	Install the CIS	Check whether CIS is loosely mounted.	Re-mount the CIS unit if it is hanged off.

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	Original document	Check if the original document has creases or foldings or wrinkles.	If the original document has foldings or creases, remove them.
2	Lamp unit	Check the location the lamp unit is mounted.	Re-mount the lamp unit if it is hanged off.
3	Feed roller in the DP	Check whether the feed roller is dirty.	If the feed roller is dirty, clean.Or, if not cured, replace the feed roller.
4	DP regist roller	Check whether the DP regist roller is dirty.	If the DP regist roller is dirty, clean.
5	DP regist pulley	Check that the DP regist pulley is smoothly operative.	If the DP regist pulley does not rotate smoothly, re-install.
6	Adjustment amount of slack of the original documen	Check the amount of slack of the original document when it reaches at the regist.	If the amount of the slack of the original document right in front of the DP regist. is insufficient, perform maintenance mode U942, DP sluck settings. (see page 1-3-208)
7	The original docu-ment	Check that the cursor matches with the original document.	Align the cursor to match with the original document, if necessary.
8	Adjustment posi-tions of the hinge	Check the front and back adjust-ment positions of the right-hand side hinge.	If the front and back adjustment positions of the hinge are improper, perform adjustment. ?
12	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

(18) Abnormal image



1. Table scanning

	Defective part	Check description	Corrective Action
1	FFFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if it its connection is loose. Or, if conduction is lot, replace the wire.

	Defective part	Check description	Corrective Action
2	SATA cable ISC	Check the SATA cable between the ISC PWB and main circuit PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
3	HDD	Check the wires to the HDD in conduction. Check the connector for connection. Check the connector pins for distortion.	1. Reinsert the connector if its connection is loose. 2. Check the wires and connectors, and replace if faulty. 3. Replace the HDD or the SATA wire.
4	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
5	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
6	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

2. DP-scanning first (front) page

	Defective part	Check description	Corrective Action
1	FFFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
2	SATA cable ISC	Check the SATA cable between the ISC PWB and main circuit PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
3	HDD	Check the wires to the HDD in conduction. Check the connector for connection. Check the connector pins for distortion.	1. Reinsert the connector if its connection is loose. 2. Check the wires and connectors, and replace if faulty. 3. Replace the HDD or the SATA wire.
4	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
5	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
6	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

3. DP-scanning second (back) page (with a dual scan DP installed)

	Defective part	Check description	Corrective Action
1	DP_SHD PWB	Check the CIS and the SHD PWB is properly connected.	Reinsert the connector if the PWB was loosely inserted.If not cured, replace the PWB.

	Defective part	Check description	Corrective Action
2	DP_SATA cable	Check the FFC cable between the SHD PWB and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
3	DP_CIS	CIS is defective.	Replace the CIS and perform U091 and U411. (see page 1-3-67,1-3-160)
4	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

4. DP-scanning second (back) page (with a reversed DP installed)

	Defective part	Check description	Corrective Action
1	FFC cable CCD	Check the FFC cable between the CCD sensor and ISC PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
2	SATA cable ISC	Check the SATA cable between the ISC PWB and main circuit PWB is properly connected. Or, verify conduction of the wire.	Reinsert the connector if its connection is loose. Or, if conduction is lot, replace the wire.
3	HDD	Check the wires to the HDD in conduction. Check the connector for connection. Check the connector pins for distortion.	1. Reinsert the connector if its connection is loose. 2. Check the wires and connectors, and replace if faulty. 3. Replace the HDD or the SATA wire.
4	ISC PWB	The ISC PWB is defective.	replace the ISC PWB and perform U411. (see page 1-3-160)
5	CCD PWB	The CCD PWB is defective.	Replace the ISU PWB and perform U411. (see page 1-3-160)
6	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-59)

1-4-6 Poor image (Image rendering problems: Mono-color printer engine)

(1) No image appears (entirely white).



1-4-251

(2) No image appears (entirely black).



1-4-253

(3) Image is too light.



1-4-254

(4) The background is colored.




1-4-256

(5) White streaks are printed vertically.



1-4-258

(6) Black or color streaks appear longitudinally.



1-4-259

(7) Black, white or color lines appear widthwise.




1-4-260

(8) Uneven density longitudinally.



1-4-261

(9) Uneven density widthwise.



1-4-262

(10) Black or color dots appear on the image.



1-4-262

(11) Offset occurs.



1-4-263

(12) Image is partly missing. (Outlines objects and white dots.)




1-4-264

(13) Image is out of focus.



1-4-264

(14) Poor grayscale reproducibility.




1-4-265

(15) Unevenly repeating horizontal streaks in the printed objects. Colored spots in the printed objects.



1-4-265


(1) No image appears (entirely white).

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. No or defective developing bias output. 2. Failure of the rotation of the developing roller. 3. Defective primary transfer. 4. Laser is not dispersed from the laser scanner unit (LSU). 5. The drum does not rotate.

	Defective part	Check description	Corrective Action
1	Developing unit	Conducting U089 to generate four-color PGs and check the following with the color which is defective:	
		Check whether the developer drive gear is damaged.	If the developer unit is in fault, replace the developer unit.
		Check the developing roller by manually rotating the roller.	If the developer unit is in fault, replace the developer unit. (see page 1-5-44)
		Check contamination and deformation on the terminals of developer unit or the high-voltage PWB1.	If the connecting terminals are dirty, clean. If the connecting terminals are deformed, correct for a proper conduction.
2	High-voltage PWB1	Check the connection of the connector(s) and the high-voltage PWB1. Or, verify conduction of the wires.	Reinsert the connector if its connection is loose. Replace the cable if it has no conduction. High voltage PWB 1 (YC1, 2) and engine PWB (YC16) High voltage PWB 1 (YC3, 4) and engine PWB (YC17)
		Check the value of the U140.	<ol style="list-style-type: none"> 1. Conduct U140 to confirm whether the developing bias value is at its default. (see page 1-3-94) 2. Replace the high-voltage circuit PWB1.
3	High-voltage PWB2 (Transfer)	Check contamination and deformation on the terminals of the primary transfer roller and high-voltage circuit PWB2.	<ol style="list-style-type: none"> 1. If the connecting terminals are dirty, clean. 2. If the connecting terminals are deformed, correct for a proper conduction.
		The primary transfer current supplied by the high-voltage PWB2 (transfer) is faulty.	Replace the high-voltage PWB2.


	Defective part	Check description	Corrective Action
4	Laser scanner unit (LSU)	Check the connection of the connectors. Or, verify conduction of the wires.	1. Reinsert the FFC wire if its connection is loose. Replace the cable if it has no conduction. 2. Replace the LSU (see page 1-5-33)
5	Engine PWB	A control signal is not derived from the engine PWB.	Replace the enging PWB. (see page 1-5-64)

(2) No image appears (entirely black).

Print example	Cause of trouble
	1. No main charging. 2. The laser from the LSU is activated simultaneously for all colors.

	Defective part	Check description	Corrective Action
1	Charing roller	Confirm the charing roller is properly mounted. Check whether the connecting terminals of the charging roller and high-voltage PWB1 are deformed.	If the charging roller is not fixed properly, fix the roller properly. If the connecting terminals are deformed, correct for a proper conduction.
2	High-voltage PWB1	Check the connection of the connectors. Or, verify conduction of the wires. High voltage PWB 1 (YC1, 2) and engine PWB (YC16) High voltage PWB 1 (YC3, 4) and engine PWB (YC17) Main charging current supplied by the high-voltage PWB1 is faulty.	Reinsert the connector if its connection is loose. Replace the cable if it has no conduction. Replace the high-voltage PWB1. (see page 1-5-69)
3	Laser scanner unit (LSU)	Switching on and off the laser diode on the LSU PWB is out of control.	Replace the LSU. (see page 1-5-33)
4	Engine PWB	Defective the engine PWB.	Replace the engine PWB.(see page 1-5-64)
5	Main PWB	The main PWB is defective.	Replace the main PWB.(see page 1-5-64)


(3) Image is too light.

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. Variance in environments (dew formation). 2. Toner is under supplied, or deteriorated in quality. 3. The volatage of the developing bias is too low. 4. The volatage of the primary transfer current is too low. 5. The power of LSU laser is too low. 6. The surface potential of the drum is too high.

	Defective part	Check description	Corrective Action
1	Drum unit	Check that the drum has dew condensation.	If a dew condensation is observed, execute drum refreshing. (System Menu >Adjustment / Maintenance)
2	Developer unit	Conducting U089 to generate four-color PGs and check the following with the color which is defective: (see page 1-3-66)	
		Confirm the value from U155. (see page 1-3-101)	If the value is less than 542, perform U132 to forcibly replenish toner. (see page 1-3-91) Replace the developer unit if the output is kept too low.
		Determine if the device executed a low-density printing for a prolonged period.	<ol style="list-style-type: none"> 1. If the device was executing a low-density printing for a prolonged period, perform developing refreshing. (System Menu >Adjustment / Maintenance) 2. If developer refreshing does not correct the problem, perform the following Execute maintenance modes U464 Calibration and U410 Grayscale Adjustment. (see page 1-3-178,1-3-158)
		Check if the connecting terminals for developer bias are deformed.	If the connecting terminals are deformed, correct for a proper conduction.
		Confirm the value from U140 MagDC. (see page 1-3-94)	If the MagDC value is in excess of the upper limit, perform U464 to set the Thickness Target Value from 0 to +30. Execute calibration by U140. Execute maintenance modes U464 Calibration.(see page 1-3-178)

	Defective part	Check description	Corrective Action
3	Toner container	Shake the toner container up and down approx. 10 times, and check the following: 1. Check remaining toner by the indicator. 2. Check whether the toner supply inlet is open.	If the message prompting toner replenishing is shown, the toner inlet is not open, replace the toner container.
4	Toner supply motor	Conduct U135 to check the revolution of the toner supply motor. (see page 1-3-92)	Conduct U135 to check the revolution of the toner supply motor.
5	High-voltage PWB1	Check the value of the U140.	1. If the value obtained after U140 does not conform to the default value, reset it to the default. (see page 1-3-94) 2. Replace the high-voltage PWB1.
6	Primary transfer belt unit	1. Check whether the connecting terminals. 2. Check the value of the U106. (see page 1-3-78)	1. If the connecting terminals are deformed, correct for a proper conduction. 2. If the value obtained after U106 does not conform to the default value, reset it to the default. 3. Replace transfer belt unit.
7	High-voltage PWB2	The primary transfer current supplied by the high-voltage PWB2 is faulty.	Replace the high-voltage circuit PWB2.
8	LSU	1. Switching the laser diode on the LSU APC PWB is out of control. 2. Check whether the internal mirrors are contaminated.	Replace the LSU. (Performs U119) (see page 1-3-87)
9	Drum unit	1. Check if the discharging lamp is dirty. 2. Check whether it is lit.	1. If the discharging lamp is dirty, clean. 2. If cleaning does not help, or it does not light, replace the drum unit. (Performs U119)(see page 1-3-87)
10	Engine PWB	Defective the engine PWB	Replace the enging circuit PWB. (see page 1-5-64)


(4) The background is colored.

Print example	要因
	<ol style="list-style-type: none"> 1. Toner is deteriorated in quality (under-charged). 2. Toner is over-supplied. 3. Developing bias is too high. 4. The layer of toner is too thick on the developing roller (too much toner). 5. The surface potential of the drum is too low (under low temperature environment).

	Defective part	Check description	Corrective Action
1	Developer unit	Conducting U089 to generate four-color PGs and check the following with the color which is defective: (see page 1-3-66)	
		<ol style="list-style-type: none"> 1. Check whether the device was being continuously operated with high density, under a hot environment. 	If the device was being continuously operated with high density under a hot environment, perform developing refreshing. (System Menu >Adjustment / Maintenance)
		<ol style="list-style-type: none"> 2. Check the value of the U140 developer bios. (see page 1-3-94) 	If the density ID is too low at calibration, execute maintenance modes U464 Calibration and U410 Grayscale Adjustment. (see page 1-3-94,1-3-94)
		<ol style="list-style-type: none"> 3. Check contamination and deformation on the connecting terminals for developer bias. 	If the connecting terminals for developer bias are dirty, clean.If the connecting terminals are deformed, correct for a proper conduction.
		<ol style="list-style-type: none"> 4. Check the toner sensor output by U155. (see page 1-3-101) 	If the toner sensor output obtained by U155 is 100 or less, replace the developer unit. (see page 1-5-44)
2	Drum unit	<ol style="list-style-type: none"> 1. Conduct U139 to check the internal temperature. (see page 1-3-93) 	If the internal temperature is 16-degree C or less, continue printing until the temperature reaches 16-dgree C or higher.
		<ol style="list-style-type: none"> 2. Check the value of the U100 main high voltage. (see page 1-3-70) 	Fix the inner unit properly. (see page 1-5-42)
		<ol style="list-style-type: none"> 3. Check that the ground terminal is not contaminated or the conductive grease is not applied with the connecting terminals. 	If the connecting terminals are dirty, clean. If the amount of the grease applied is too small, apply conductive grease to the bearing on the receiver side of the drum drive axle. Replace the drum unit. (Performs U119)
		<ol style="list-style-type: none"> 4. Check if the charging roller is dirty. 	If the charging roller is dirty, clean.Or replace it. (Performs U930)(see page 1-5-42)


	Defective part	Check description	Corrective Action
3	High-voltage PWB1	The developing bias and charging current supplied by the high-voltage PWB1 is faulty.	Replace the high-voltage PWB1. (see page 1-5-42)
4	Engine PWB	Defective the engine PWB	Replace the enging PWB. (see page 1-5-64)
5	Toner supply motor	Check the toner supply motor is continuously rotating.Check wires for shortcircuiting.	If the harnesses are short-circuited and the toner motor is continuously rotating, replace the toner supply motor.

(5) White streaks are printed vertically.

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. Dirty LSU slit glass. 2. Foreign objects inside the developer unit. 3. Internal contamination 4. Dirty drum inside.


	Defective part	Check description	Corrective Action
1	LSU	Check if the LSU slit glass is dirty.	If the LSU slit glass is dirty, perform laser scanner cleaning.
2	Developer unit	Conducting U089 to generate four-color PGs. (see page 1-3-66)	Replace the developer unit in fault. (see page 1-5-44)
3	Light path between the LSU and the drum	Check if there are dusts, dirt, or toner obstructing the light paths.	If a foreign object exists on the frame or the sealings between the developer unit and the drum unit, remove.
4	Drum unit	Check if the charging roller is dirty.	If the charging roller is dirty, clean. Or replace it. (Performs U930) (see page 1-5-46)
		Check if the discharging lamp is dirty.	If the discharging lamp is dirty, clean.

(6) Black or color streaks appear longitudinally.

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. Dirty charging roller 2. Flawed or dirty drum unit 3. Damaged or paper dust bitten cleaning blade


	Defective part	Check description	Corrective Action
1	Charging roller unit	Confirm there is no toner streaks on the surface of the charging roller.	If the charging roller has streaks on its surface, clean the charging roller. Replace the charging roller, if necessary. (Performs U930) (see page 1-5-46)
2	Drum unit	<p>The drum is dirty on its surface.</p> <p>Check if the drum has scratches. Check whether the edge of the cleaning blade is damaged. Replace the drum unit. Check whether it is abraded or paper dusts are accumulated. Check whether toner is accumulated in the cleaning section.</p>	<p>Execute drum refreshing. (System Menu >Adjustment / Maintenance)</p> <p>Replace the drum unit. (Performs U119) (see page 1-5-44)</p>

(7) Black, white or color lines appear widthwise.

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. Dirty developer unit or terminals 2. Flawed or dirty drum unit Improper grounding 3. Dirty primary transfer roller terminals


	Defective part	Check description	Corrective Action
1	Developer unit	<ol style="list-style-type: none"> 1. Check the print image on paper has a problem at an interval equivalent to the circumference of the developing roller (39mm). 2. Check that the developing roller is dirty at its ends or at the developing bias tab. 	<ol style="list-style-type: none"> 1. If the ends of the developing roller and the connecting terminals for developer bias are dirty, clean. 2. Replace the developer unit. (see page 1-5-44)
2	Drum unit	<ol style="list-style-type: none"> 1. Check the print image on paper has a problem at an interval equivalent to the circumference of the drum (94mm). 	Execute drum refreshing. (System Menu >Adjustment / Maintenance)
		<ol style="list-style-type: none"> 2. Check if the drum has scratches. 	Replace the drum unit. (Performs U119) (see page 1-5-44)
		<ol style="list-style-type: none"> 3. Check the grounding tab of the drum or the drum drive shaft. 	<ol style="list-style-type: none"> 1. Check how the inner unit is mounted, and correct, if necessary. 2. Replace the drum unit. (Performs U119) (see page 1-5-44)
4	Primary transfer roller (transfer belt)	<p>Check if the connecting terminals between the transfer high-voltage circuit PWB and the primary transfer roller are contaminated by toner.</p> <p>Or, the connecting terminals are deformed losing contacts.</p>	<ol style="list-style-type: none"> 1. If the connecting terminals is dirty, clean it using a brush. 2. If the connecting terminals are deformed, correct for a proper conduction. 3. Replace the transfer belt unit. (see page 1-5-49)
5	High-voltage PWB1	The bias voltage output supplied by the high-voltage PWB1 is not even.	Replace the high-voltage PWB1. (see page 1-5-49)

(8) Uneven density longitudinally.

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. Dirty LSU inside 2. The transfer belt is not pressed against the drum properly. 3. Drum condensation.


	Defective part	Check description	Corrective Action
1	LSU	The emission of laser dispersed from the LSU is not even. (Mirror is dropped off inside.)	Replace the LSU.(Performs U119)
2	Primary transfer roller (transfer belt)	Check the position at which the primary transfer roller axles are mounted.	<ol style="list-style-type: none"> 1. If the axle holder is hanged off of the mounting position, <ol style="list-style-type: none"> 1. fix the axle holder properly. 2. Replace the transfer belt unit. (see page 1-5-49)
3	Drum unit	<ol style="list-style-type: none"> 1. Check toner is evenly layered on its surface. 2. Determine whether the device has been operated under a highly humid environment. 	<ol style="list-style-type: none"> 1. Execute drum refreshing. 2. Selects the Dew Mode by U148 Drum Referesh Mode. (see page 1-3-100) 3. Install a cassette heater. 4. Replace the drum unit. (Performs U119) (see page 1-5-44)
4	Developer unit	Check that toner is evenly layered on the developing roller.	Replace the developer unit. (see page 1-5-44)

(9) Uneven density widthwise.

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. Defective laser scanner unit. 2. Improper charging roller rotation 3. Improper contact on the developer unit terminals

	Defective part	Check description	Corrective Action
1	LSU	Check the emission of laser is even.	Replace the LSU. (see page 1-5-33)
2	Charging roller	Confirm the charging roller is improperly mounted.	<ol style="list-style-type: none"> 1. Fix the charging roller properly. 2. Replace the charging roller. (Performs U119) (see page 1-5-46)
3	Developer unit	Check If the connecting terminals of the developing bias is contaminated by toner.	<ol style="list-style-type: none"> 1. If the connecting terminals is dirty, clean it using a brush. 2. Replace the developer unit. (Performs U140) (see page 1-5-44)


(10) Black or color dots appear on the image.

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. Dirty charging roller 2. Flawed or dirty drum unit 3. Damaged or paper dust bitten cleaning blade

	Defective part	Check description	Corrective Action
1	Drum unit	Check the print image on paper has a problem at an interval equivalent to the circumference of the drum(94mm).	If the drum has scratches, replace the drum unit. (see page 1-5-44)
2	Charging roller	Check the print image on paper has a problem at an interval equivalent to the circumference of the charging roller(38mm).	A problem is observed at a constant interval of 38 mm, replace the charging roller.(U930) (see page 1-3-207)


	Defective part	Check description	Corrective Action
3	Developer unit	1. Check that the developing bias is leaked.	Execute AC calibration by U140. (see page 1-3-94)
		2. Check the print image on paper has a problem at an interval equivalent to the circumference of the developing roller(39mm).	1. Check the print image on paper has a problem at an interval equivalent to the circumference of the developer roller, the developer unit is cleasd. 2. Replace the developer unit. (see page 1-5-36)

(11) Offset occurs.

Print example	Cause of trouble
	1. Flawed or dirty drum unit 2. Developing bias leakage.


	Defective part	Check description	Corrective Action
1	Drum unit	Check the print image on paper has a problem at an interval equivalent to the circumference of the drum (94mm).	Check the print image on paper has a problem at an interval equivalent to the circumference of the drum, replace the drum unit. (see page 1-5-44)
2	Developer unit	1. Offsets are observed at an constant interval of 39 mm, which is equivalent to the circumference of the developing roller.	If offsets are observed at an constant interval of 39 mm, which is equivalent to the circumference of the developing roller, replace the developer unit. (Waste toner is not properly swept from the developing roller.) (see page 1-5-44)

(12) Image is partly missing. (Outlines objects and white dots.)

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. Flawed or dirty drum unit. 2. Deformed or dirty primary transfer roller on its surface.


	Defective part	Check description	Corrective Action
1	Drum unit	Check the print image on paper has a problem at an interval equivalent to the circumference of the drum (94mm)	Check the print image on paper has a problem at an interval equivalent to the circumference of the drum, execute drum refreshing (System Menu > Adjustment/Maintenance).
2	Primary transfer roller (transfer belt)	Check if the primary transfer roller is deformed or contaminated on its surface.	If the intermediate transfer belt unit is deformed or contaminated, replace the intermediate transfer belt unit. (see page 1-5-49)

(13) Image is out of focus.

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. Drum condensation. 2. Dirty LSU slit glass.


	Defective part	Check description	Corrective Action
1	Drum unit	Check that the surface of the drum has dew condensation.	Execute drum refreshing. System Menu > Adjustment/Maintenance
2	LSU	Check whether the CIS glass is contaminated in its entirety.	<ol style="list-style-type: none"> 1. If the LSU slit glass is dirty, perform laser scanner cleaning. 2. Replace the LSU. (Performs U119) (see page 1-5-33)

(14) Poor grayscale reproducibility.

Print example	Cause of trouble
	1. Poor image adjustment.

	Defective part	Check description	Corrective Action
1	画像調整	Check if color adjustment is insufficient.	Execute maintenance modes U464 Calibration and U410 Grayscale Adjustment. (see page 1-3-94, 1-3-94)

(15) Unevenly repeating horizontal streaks in the printed objects. Colored spots in the printed objects.

Print example	Cause of trouble
	1. Installation at a high altitude. 2. Using the paper with high surface resistance.

	Defective part	Check description	Corrective Action
1	Developer unit	The device is installed in an altitude greater than 1500 m sea level.	If the device is installed in an altitude greater than 1500 m sea level, perform the following. <ol style="list-style-type: none"> 1. 30 ppm / 35 ppm devices Run maintenance mode U140 and turn both AC Calib and High Altitude. 2. 45 ppm / 55 ppm devices Run maintenance mode U140 and turn both AC Calib and High Altitude to Mode1. If changing to Mode1 won't work, change to Mode2. (see page 1-3-94)
2	Paper	Check if paper is of high surface resistance.	Change the paper to another.

1-4-7 Poor image (Transferring toner and Image rendering problems: Four-color printer engine)

(1) No image appears (entirely white).



1-4-268

(2) Image is too light.



1-4-269

(3) The background is colored.




1-4-270

(4) White lines appear longitudinally.




1-4-270

(5) Black or color streaks appear longitudinally.



1-4-271

(6) Black, white or color lines appear widthwise.



1-4-272



(7) Uneven transferring toner.




1-4-272

(8) Black or color dots appear on the image.



1-4-274

(9) Image is blurred (Shifted transferring).



1-4-274

(10) The leading edge of the image is consistently misaligned with the original.



1-4-275

(11) The leading edge of the image is sporadically misaligned with the original.




1-4-276

(12) Paper is wrinkled.



1-4-276

(13) Offset occurs.



1-4-278

(14) Image is partly missing
(Outlines objects and white dots).



1-4-278

(15) Fusing is loose.



1-4-279

(16) Image is out of focus.



1-4-280

(17) Image center does not align with the original center.



1-4-280

(18) Dirty paper edges with toner.




1-4-281

(19) Inferior color reproducibility.



1-4-281

(20) Shifted colors.



1-4-282




(21) Dirty reverse side of paper.




1-4-283

(1) No image appears (entirely white).

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. Defective transfer bias output. 2. The second transfer roller is not pressurized.


	Defective part	Check description	Corrective Action
1	Secondary transfer roller	Check the right side conveying unit is closed.	If the conveying unit has not been closed, check how the conveying guide is locked and open the conveying guide once, then close.
2	Secondary transfer roller pressure motor	<ol style="list-style-type: none"> 1. Conduct U030 Press Release to confirm that the pressure motor for the secondary transfer roller is activated. 2. Check the connection of the connectors. 	<ol style="list-style-type: none"> 1. Reinsert the connector if its connection is loose. 2. Replace the motor.
3	High-voltage PWB2	<ol style="list-style-type: none"> 1. Check the connection of the connectors. High voltage PWB 2 (YC1) and engine PWB (YC8) 2. Verify conduction of the wires. 	<ol style="list-style-type: none"> 1. Reinsert the connector if its connection is loose. 2. Replace the cable if it has no conduction. 3. Replace the high-voltage PWB2. (see page 1-5-70)
4	Enging PWB	<ol style="list-style-type: none"> 1. Check the connection of the connectors. 2. Verify conduction of the wires. 3. Check whether the secondary transfer high voltage-on signal is derived from the engine circuit PWB. 	<ol style="list-style-type: none"> 1. Reinsert the connector if its connection is loose. 2. Replace the cable if it has no conduction. 3. If a signal is not obtained, replace the engine PWB. (see page 1-5-64)

(2) Image is too light.

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. The paper absorbs moisture. 2. The contact pressure at the second transfer roller and the intermediate transfer belt is too low. 3. The voltage applied to the second transfer current is incorrect.


	Defective part	Check description	Corrective Action
1	Paper	<ol style="list-style-type: none"> 1. Check that the paper has moisture absorbed. 2. Check the humidity at the place the paper has been stored. 	<ol style="list-style-type: none"> 1. If the paper is damp, replace. Choose a dry place to store paper. 2. If necessary, install a cassette heater.
2	Conveying unit	Check the right side conveying unit is closed.	If the conveying unit has not been closed, check how the conveying guide is locked and open the conveying guide once, then close.
3	Secondary transfer roller	Confirm the position of the secondary transfer roller during printing.	Position the pressure cam correctly if the secondary transfer roller is off-set.
4	High-voltage PWB2	Check the connecting terminals between the high-voltage PWB2 and the conveying unit are not dirty nor deformed.	<ol style="list-style-type: none"> 1. If the connecting terminals are dirty, clean. 2. If the connecting terminals are deformed, correct for a proper conduction.
5	U106 the secondary transfer voltage setting	Check the secondary transfer voltage with U106.	If the value of the second transfer voltage after U106 is not its default, reset it to the default. (see page 1-3-78)

(3) The background is colored.

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. Defective transfer belt grounding. 2. Dirty secondary transfer roller.


	Defective part	Check description	Corrective Action
1	Transfer belt unit	<ol style="list-style-type: none"> 1. Check if the drive belt is bleached on its surface. Confirm the value from U140 MagDC after conducting calibration. 	Increase the U140 MagDC value if the U140 MadDC value has not reached at its maximum even though the belt is bleached on its surface. If the MadDC increased to its maximum won't cure, replace the transfer belt unit. (see page 1-5-53)
		<ol style="list-style-type: none"> 2. Check if the ground tab of the intermediate transfer belt unit is deformed. 	If the grounding tab is deformed, correct it so that it is properly grounded.
2	Secondary transfer roller	Check that the roller is dirty in its entirety.	If the secondary transfer roller is dirty in its entirety, clean.

(4) White streaks are printed vertically.

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. Defective transfer belt grounding. 2. Dirty secondary transfer roller.


	Defective part	Check description	Corrective Action
1	Transfer belt unit	Check whether a white streak occurs at the same position as the smear on the transfer belt occurs.	<ol style="list-style-type: none"> 1. Clean the intermediate transfer belt if it is dirty. 2. Replace the intermediate transfer belt unit. (see page 1-5-49)
2	Secondary transfer roller	Check whether a white streak occurs at the same position as the smear on the roller transfer occurs.	Clean the second transfer roller if it is dirty. If not cured, replace the second transfer roller. (see page 1-5-53)

(5) Black or color streaks appear longitudinally.

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. Poor voltage applied for transfer belt cleaning. 2. Dirty secondary transfer roller. 3. Dirty separation brush. 4. Dirty fuser unit inside.

	Defective part	Check description	Corrective Action
1	Transfer belt unit	Check if paper dusts have accumulated at the proximity of the cleaning pre brush.	<ol style="list-style-type: none"> 1. If paper dusts are accumulated, clean the pre-brush by removing the cleaning cover. (see page 1-5-51) 2. If cleaning does not help improve the symptom, replace intermediate transfer belt unit. (see page 1-5-49)
		Check the cleaning bias connector or the connecting terminals of high voltage are not dirty or deformed.	<ol style="list-style-type: none"> 1. If the connector or terminals are dirty, clean. 2. If the connecting terminals are deformed, correct for a proper conduction. 3. Replace the high-voltage circuit PWB2. (see page 1-5-70)
		Check if the intermediate transfer belt roller is contaminated on its surface or damaged.	<ol style="list-style-type: none"> 1. If smears and scuff are observed on the transfer belt unit, replace the unit. (see page 1-5-49)
2	Secondary transfer roller	Check if the secondary transfer roller is contaminated, deformed or abraded.	Clean the secondary transfer roller if it is dirty. Replace the roller if it is deformed or abraded. (see page 1-5-53)
3	Separation brush	Check if the separation brush is dirty with paper dusts and waste toner.	If the separation brush is dirty, clean it using a brush.
4	Fuser unit	<ol style="list-style-type: none"> 1. The paper separation puddle is contaminated with toner. 2. Check the device is adjusted for a correct paper weight that matches the paper in use. 	<ol style="list-style-type: none"> 1. If the paper separation puddle is dirty, clean the paper separation puddle. 2. If the settings for paper weight and the paper being used do not match, make a proper configuration.
5	Eject guide	The Rib is contaminated with toner.	If it is dirty, clean.


(6) Black, white or color lines appear widthwise.

Print example	Cause of trouble
	1. Defective transfer belt grounding. 2. Dirty secondary transfer roller.

1. Table scanning


	Defective part	Check description	Corrective Action
1	Transfer belt unit	Check the print image that implies dirt, deformation, or scratches on the transfer belt, which will be appearing at an interval equal to its circumference (936mm).	1. If the print image has a problem, clean the transfer belt by a soft cloth. 2. If cleaning does not cure, replace transfer belt unit.
2	Fuser unit	Check the print image on paper has a problem at an interval equivalent to the circumference of the fuser roller.	If the print image has a problem, clean the fuser unit. If it does not cure, replace the fuser unit.

(7) Uneven transferring toner.

Print example	Cause of trouble
	1. Defective transfer belt grounding. 2. Dirty secondary transfer roller.


	Defective part	Check description	Corrective Action
1	Transfer belt unit	Check if paper dusts have accumulated at the proximity of the cleaning pre brush.	<ol style="list-style-type: none"> 1. If paper dusts are accumulated, clean the pre-brush by removing the cleaning cover. 2. If cleaning does not help improve the symptom, replace transfer belt unit. (see page 1-5-49)
		Check the cleaning bias connector or the connecting terminals of high voltage are not dirty or deformed.	<ol style="list-style-type: none"> 1. If the connector or terminals are dirty, clean. 2. If the connecting terminals are deformed, correct for a proper conduction. 3. Replace the high-voltage circuit PWB2. (see page 1-5-70)
		Check if the transfer belt roller is contaminated on its surface or damaged.	<ol style="list-style-type: none"> 1. Replace the transfer belt unit. (see page 1-5-49)
2	Secondary transfer roller	Check if the secondary transfer roller is contaminated, deformed or abraded.	<ol style="list-style-type: none"> 1. If the secondary transfer roller is dirty, clean. 2. If cleaning does not help improve the symptom, replace the secondary transfer roller. (see page 1-5-49)
3	Fuser unit	Check that the roller, its driving unit, or the fusing pressure release mechanism is deformed, abraded, or damaged.	If the roller, its driving unit, or the fusing pressure release mechanism is deformed, abraded, or damaged, replace the fuser unit. (see page 1-5-49)

(8) Black or color dots appear on the image.

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. Flawed or dirty transfer belt. 2. Dirty secondary transfer roller. 3. Dirty Fuser unit inside.


	Defective part	Check description	Corrective Action
1	Transfer belt unit	Check the transfer belt for cleaning.	<ol style="list-style-type: none"> 1. Clean the cleaning pre-brush. 2. If it does not cure, replace the cleaning pre-brush. (see page 1-5-51)
		Check the print image that implies dirt, deformation, or scratches on the transfer belt, which will be appearing at an interval equal to its circumference (936mm).	Replace the transfer belt unit. (see page 1-5-49)
2	Secondary transfer roller	Check the print image on paper has a problem at an interval equivalent to the circumference of the secondary transfer roller(75mm).	<ol style="list-style-type: none"> 1. If the print image has a problem, clean the secondary transfer roller. 2. If cleaning does not help improve the symptom, replace the roller. (see page 1-5-53)
3	Fuser unit	Check the print image on paper has a problem at an interval equivalent to the circumference of the fuser roller or the fuser transfer belt.	<ol style="list-style-type: none"> 1. If the print image has a problem, clean the fuser roller or the fuser transfer belt. 2. If cleaning does not help improve the symptom, replace the fuser unit. (see page 1-5-55)

(9) Image is blurred (Shifted transferring).

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. The paper used does not conform to the requirement. 2. Imbalanced fuser unit pressures.


	Defective part	Check description	Corrective Action
1	Paper	<ol style="list-style-type: none"> 1. Check that the type of the paper used falls within the range of specifications. 2. Check the settings of the type and weight of the paper. 	<ol style="list-style-type: none"> 1. If the type of the paper being used falls outside the requirements, replace and use a suitable type of paper. 2. If the settings made for the paper used is inadequate, configure the settings according to the paper being used.
2	Fuser unit	<ol style="list-style-type: none"> 1. Check the fuser pressure balance. 2. Check if the fuser paper-inserting guide is deformed. 	<ol style="list-style-type: none"> 1. Replace the fuser unit. (see page 1-5-55) 2. If the fuser unit is deformed, replace. (see page 1-5-55)
3	paper conveyance motor	Check to see if the driving mechanism for paper conveyance is operative without a hinderance.	If the drive does not operate normally, apply grease.
4	Paper conveying guide	The paper conveying guide is deformed.	Replace the paper conveying guide.

(10) The leading edge of the image is consistently misaligned with the original.

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. Improperly adjusted leading edge timing. 2. Improper amount of slack of the original document in front of the registration.


	Defective part	Check description	Corrective Action
1	Regist roller	1. Check whether the leading-edge timing is adequately adjusted.	If the intermediate transfer belt is not sufficient, perform U034 to adjust the leading edge timing. (see page 1-3-34)
		2. Check the amount of slack of the original document when it reaches at the DP regist is adequate.	If the amount of the slack in front of the regist roller is insufficient, perform maintenance mode U051 to optimize the sluck. (see page 1-3-41)

(11) The leading edge of the image is sporadically misaligned with the original.



	Defective part	Check description	Corrective Action
1	Paper feed clutch, Middle clutch, Registration clutch, Duplex clutch	Verify that the clutches are properly fit.If it is not fixed properly, fix it properly.Or, check they are operative without a hinderance. (30 ppm/35 ppm model)	1. If it is not fixed properly, fix it properly. 2. If it does not operate without a hinderance, replace the clutch.
2	Paper feed clutch, Middle motor, Registration motor, Duplex motor	Verify that the clutches and motors are properly fit.Or, check they are operative without a hinderance. (45 ppm/55 ppm model)	1. If it is not fixed properly, fix it properly. 2. If it does not operate without a hinderance, replace the clutch or motor.


(12) Paper is wrinkled.



	Defective part	Check description	Corrective Action
1	Paper-width guides	Check the paper-width guides are flush with the paper.	If the width adjuster cursors are not flush with paper, set them correctly.
2	Paper	1. Check paper is curled or wavy. 2. Check that peper is stored in a humid place.	1. If the paper is curled or wavy, replace. 2. Choose a dry place to store paper.
3	Registration roller	The pressures at the front and back springs are unbalanced.	Replace the spring with the one having a correct pressure.


	Defective part	Check description	Corrective Action
4	Fuser unit	The pressuring spring of the fuser unit is defective.	Replace the fuser unit. (see page 1-5-55)

(13) Offset occurs.



	Defective part	Check description	Corrective Action
1	Paper	<ol style="list-style-type: none"> 1. Check that the type of the paper used falls within the range of specifications. 2. Check the settings of the type and weight of the paper. 	<ol style="list-style-type: none"> 1. If the type of the paper being used falls outside the requirements, replace and use a suitable type of paper. 2. If the settings made for the paper used is inadequate, configure the settings according to the paper being used.
2	Transfer belt unit	Check the transfer cleaning voltage with U107. (see page 1-3-82)	<ol style="list-style-type: none"> 1. If the transfer cleaning voltage with U107 is not its default, reset it to the default. 2. Replace the transfer belt unit. (see page 1-5-49)
3	Fuser unit	Check if the fuser unit roller is dirty.	If the fuser unit roller is dirty, replace the unit.
4	Fusing temperature setting	Check the fusing temperature value after U161. (see page 1-3-104)	If the fusing temperature value after U161 is not its default, reset it to the default.


(14) Image is partly missing (Outlines objects and white dots).



	Defective part	Check description	Corrective Action
1	Paper	Check that the paper has moisture absorbed. Check that paper is stored in a humid place.	<ol style="list-style-type: none"> 1. If the paper is damp, replace. Choose a dry place to store paper. 2. If necessary, install a cassette heater. (see page 1-2-65)

	Defective part	Check description	Corrective Action
2	Transfer belt unit	Check the print image that implies dirt, deformation, or scratches on the intermediate transfer belt, which will be appearing at an interval equal to its circumference (936mm).	<ol style="list-style-type: none"> 1. Clean the intermediate transfer belt by a soft cloth. 2. Replace the intermediate transfer belt unit.
3	Secondary transfer roller	Check the print image on paper has a problem at an interval equivalent to the circumference of the secondary transfer roller(75mm).	<ol style="list-style-type: none"> 1. Clean the secondary transfer roller. 2. Replace the secondary transfer roller. (see page 1-5-53)
4	Fusing temperature setting	Conduct U161 to check the value and check whether the fuser temperature is set to low. (see page 1-3-104)	<ol style="list-style-type: none"> 1. Choose a paper weight appropriate for the weight of the paper actually being used, if the fusing temperature was set low using U161. 2. Perform U161 for an appropriate fusing temperature.


(15) Fusing is loose.



	Defective part	Check description	Corrective Action
1	Paper	<ol style="list-style-type: none"> 1. Check that the type of the paper used falls within the range of specifications. 2. Check the settings of the type and weight of the paper. 	<ol style="list-style-type: none"> 1. If the type of the paper being used falls outside the requirements, replace and use a suitable type of paper.
2	用紙紙厚設定	Check If the weight of the paper is correctly set.	If the weight of the paper is not correctly set, choose the correct weight that matches the paper being used.
3	Fuser unit	Check the fuser pressure setting.	Replace the fuser unit. (see page 1-5-55)


	Defective part	Check description	Corrective Action
4	Fusing temperature setting	Check the value of the U161. (see page 1-3-104)	Choose a paper weight appropriate for the weight of the paper actually being used, if the fusing temperature was set low using U161. Perform U161 for an appropriate fusing temperature.

(16) Image is out of focus.




	Defective part	Check description	Corrective Action
1	Paper	Check that the paper has moisture absorbed. Check that paper is stored in a humid place.	1. If the paper is damp, replace. Choose a dry place to store paper. 2. If necessary, install a cassette heater. (see page 1-2-65)

(17) Image center does not align with the original center.




	Defective part	Check description	Corrective Action
1	Paper setting	Check if paper is set correctly.	Reload paper if the paper was not loaded correctly.
2	画像位置調整	Conduct U034 to confirm the center alignment during writing images.	Perform adjustment if the value after U034 Center Line Adjustment is inadequate. (see page 1-3-34)

(18) Dirty paper edges with toner.

Print example	Cause of trouble
	1. Toner scattering due to an internal temperature increase

	Defective part	Check description	Corrective Action
1	Conveying guide	Check if the conveying guide is dirty with toner.	If the conveying guide is dirty with toner, clean the developer unit and the cooling ducts.
2	機内（現像器）の温度上昇	Check the device has been used for printing a large amount of data in duplex mode with a high density.	If the device has been used for printing a large amount of data in duplex mode with a high density, clean the developer unit.


(19) Inferior color reproducibility.



	Defective part	Check description	Corrective Action
1	Paper	Check that the paper has moisture absorbed. Check that paper is stored in a humid place.	1. If the paper is damp, replace. Choose a dry place to store paper. 2. If necessary, install a cassette heater. (see page 1-2-65)
2	Paper specifications	Inpalpable unevenness in glossiness is observed at the high density area on paper.	1. If the rough paper intended for monochrome printing is being used, change the paper to the type intended for color printing. 2. Select the Gain Mode by U161 and select a lower fusing temperature. 3. If the installation environment is at a high altitude, select and perform U140 High Altitude. (see page 1-3-94)


	Defective part	Check description	Corrective Action
3	Paper type	Check the settings of the type and weight of the paper.	If the paper and the paper type or weight do not match, choose the correct match.
4	Image adjustment	Check whether the above has been cured.	Execute maintenance modes U464 Calibration and U410 Grayscale Adjustment.
5	Enging PWB	Check if the color printing is florid in its entirety.	If the print image is florid, replace the enging PWB. (see page 1-5-64)
6	Printer driver setting	Check what color table is being selected for the printer.	<ol style="list-style-type: none"> 1. If a proper color table is not being selected for the printer, manipulate the printer driver for a mode that provides a proper color fidelity. 2. Select an adequate mode by U485.
		Check that the print data is of CMYK.	If the print data is of CMYK, select an adequate mode by the KPDL Color Conversion Process.

(20) Shifted colors.

Print example	Cause of trouble
	<ol style="list-style-type: none"> 1. False detection of the velocity of rotaton of the transfer belt.

	Defective part	Check description	Corrective Action
1	Color Regist Adjustment	Check if U469 Color Regist Adjustment is performed after power is turned on and warming-up completes.	If U469 Color Registration adjustment has not been done, perform U464 Calibration, then U469 Color Registration. (see page 1-3-185,1-3-178)
2	Motor control PWB	If the above remedy won't work, check whether an intensive color shift in the direction of sub scan is observed.	If it does not cure,replace the motor control PWB.
3	LSU	Check if adjusting the color shift can help compensation in the direction of main scan.	Replace the laser scanner unit if necessary. (see page 1-5-33)

(21) Dirty reverse side of paper.



	Defective part	Check description	Corrective Action
1	Secondary transfer roller	Check if the secondary transfer roller is dirty with toner.	<ol style="list-style-type: none"> 1. Clean the secondary transfer roller. 2. Reset U106 Bias settings to its default.
2	Fuser pressure roller	Check that a foreign object is stuck on the fuser pressure roller.	<ol style="list-style-type: none"> 1. If a foreign object exists, clean the fuser pressure roller. 2. If the paper and the paper weight do not match, choose the proper paper weight setting.
3	Upper conveying guide	Check if the conveying guide is dirty with toner.	If the conveying guide is dirty with toner, clean the conveying guide or the developer unit.

1-4-8 Electric problems

If the part causing the problem was not supplied, use the unit including the part for replacement.
Troubleshooting to each failure must be in the order of the numbered symptoms.

Problem	Causes	Check procedures/corrective measures
(1) The machine does not operate when the main power switch is turned on.	1. No electricity at the power outlet.	Measure the input voltage.
	2. The power cord is not plugged in properly.	Check the contact between the power plug and the outlet.
	3. Broken power cord.	Check for continuity. If none, replace the cord.
	4. Defective main power switch.	Check for continuity across the contacts. If none, replace the main power switch.
	5. Defective power source PWB.	Replace the power source PWB (see page 1-5-66).
(2) MP lift motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. MP lift motor and relay PWB (YC3) Relay PWB (YC12) and feed PWB 1 (YC17) Feed PWB 1 (YC1) and engine PWB (YC6)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the MP lift motor.
	4. Defective PWB.	Replace the relay PWB, feed PWB 1 or engine PWB and check for correct operation (see page 1-5-64).
(3) Scanner motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Scanner motor and ISC PWB (YC5) ISC PWB (YC3) and main PWB (YC11)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the scanner motor.
	4. Defective PWB.	Replace the ISC PWB or main PWB and check for correct operation (see page 1-5-59).
(4) Registration motor does not operate (45 ppm/55 ppm model only).	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Registration motor and feed PWB 1 (YC25) Feed PWB 1 (YC2) and engine PWB (YC5)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the registration motor.
	4. Defective PWB.	Replace the feed PWB 1 or engine PWB and check for correct operation (see page 1-5-64).

Problem	Causes	Check procedures/corrective measures
(5) Middle motor does not operate (45 ppm/55 ppm model only).	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Middle motor and feed PWB 2 (YC7) Feed PWB 2 (YC1) and engine PWB (YC4)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the middle motor.
	4. Defective PWB.	Replace the feed PWB 2 or engine PWB and check for correct operation (see page 1-5-64).
(6) Eject motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Eject motor and front PWB (YC5) Front PWB (YC3) and engine PWB (YC7)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the eject motor.
	4. Defective PWB.	Replace the front PWB or engine PWB and check for correct operation (see page 1-5-64).
(7) Duplex motor 1 does not operate (45 ppm/55 ppm model only).	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Duplex motor 1 and relay PWB (YC16) Relay PWB (YC13) and feed PWB 1 (YC23) Feed PWB 1 (YC2) and engine PWB (YC5)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the duplex motor 1.
	4. Defective PWB.	Replace the relay PWB, feed PWB 1 or engine PWB and check for correct operation (see page 1-5-64).
(8) Duplex motor 2 does not operate (45 ppm/55 ppm model only).	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Duplex motor 2 and relay PWB (YC7) Relay PWB (YC1) and feed PWB 1 (YC14) Feed PWB 1 (YC1) and engine PWB (YC6)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the duplex motor 2.
	4. Defective PWB.	Replace the relay PWB, feed PWB 1 or engine PWB and check for correct operation (see page 1-5-64).

Problem	Causes	Check procedures/corrective measures
(9) Toner fan motor 1, 2 does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Toner fan motor 1, 2 and engine PWB (YC19)
	2. Defective motor.	Replace the toner fan motor 1 or 2.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-64).
(10) Developer fan motor 1, 2 does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Developer fan motor 1, 2 and front PWB (YC6) Front PWB (YC3) and engine PWB (YC7)
	2. Defective motor.	Replace the developer fan motor 1 or 2.
	3. Defective PWB.	Replace the front PWB or engine PWB and check for correct operation (see page 1-5-64).
(11) Exhaust fan motor 1, 2 does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Exhaust fan motor 1, 2 and engine PWB (YC19)
	2. Defective motor.	Replace the exhaust fan motor 1 or 2.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-64).
(12) LSU fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. LSU fan motor and front PWB (YC16) Front PWB (YC2) and engine PWB (YC10)
	2. Defective motor.	Replace the LSU fan motor.
	3. Defective PWB.	Replace the front PWB or engine PWB and check for correct operation (see page 1-5-64).
(13) Belt fan motor 1, 2 does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Belt fan motor 1, 2 and engine PWB (YC19)
	2. Defective motor.	Replace the belt fan motor 1 or 2.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-64).
(14) Fuser fan motor 1, 2 does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Fuser fan motor 1, 2 and relay PWB (YC16) Relay PWB (YC13) and feed PWB 1 (YC23) Feed PWB 1 (YC2) and engine PWB (YC5)
	2. Defective motor.	Replace the fuser fan motor 1 or 2.
	3. Defective PWB.	Replace the relay PWB, feed PWB 1 or engine PWB and check for correct operation (see page 1-5-64).

Problem	Causes	Check procedures/corrective measures
(15) Eject fan motor 1, 2 does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Eject fan motor 1, 2 and relay PWB (YC11) Relay PWB (YC13) and feed PWB 1 (YC23) Feed PWB 1 (YC2) and engine PWB (YC5)
	2. Defective motor.	Replace the eject fan motor 1 or 2.
	3. Defective PWB.	Replace the relay PWB, feed PWB 1 or engine PWB and check for correct operation (see page 1-5-64).
(16) Eject front fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Eject front fan motor and front PWB (YC4) Front PWB (YC3) and engine PWB (YC7)
	2. Defective motor.	Replace the eject front fan motor.
	3. Defective PWB.	Replace the front PWB or engine PWB and check for correct operation (see page 1-5-64).
(17) Eject rear fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Eject rear fan motor and feed PWB 1 (YC19) Feed PWB 1 (YC1) and engine PWB (YC6)
	2. Defective motor.	Replace the eject rear fan motor.
	3. Defective PWB.	Replace the feed PWB 1 or engine PWB and check for correct operation (see page 1-5-64).
(18) Power source fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Power source fan motor and engine PWB (YC22)
	2. Defective motor.	Replace the power source fan motor.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-64).
(19) Controller fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Controller fan motor and main PWB (YC23)
	2. Defective motor.	Replace the controller fan motor.
	3. Defective PWB.	Replace the main PWB and check for correct operation (see page 1-5-59).
(20) Paper feed clutch 1, 2 does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Paper feed clutch 1, 2 and feed PWB 2 (YC4) Feed PWB 2 (YC1) and engine PWB (YC4)
	2. Defective clutch.	Replace the paper feed clutch 1 or 2.
	3. Defective PWB.	Replace the feed PWB 2 or engine PWB and check for correct operation (see page 1-5-64).

Problem	Causes	Check procedures/corrective measures
(21) Assist clutch 1, 2 does not operate (45 ppm/55 ppm model only).	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Assist clutch 1 and feed PWB 2 (YC10) Assist clutch 2 and feed PWB 2 (YC12) Feed PWB 2 (YC1) and engine PWB (YC4)
	2. Defective clutch.	Replace the assist clutch 1 or 2.
	3. Defective PWB.	Replace the feed PWB 2 or engine PWB and check for correct operation (see page 1-5-64).
(22) Paper conveying clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Paper conveying clutch and feed PWB 2 (YC5) Feed PWB 2 (YC1) and engine PWB (YC4)
	2. Defective clutch.	Replace the paper conveying clutch.
	3. Defective PWB.	Replace the feed PWB 2 or engine PWB and check for correct operation (see page 1-5-64).
(23) MP paper feed clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. MP paper feed clutch and relay PWB (YC3) Relay PWB (YC12) and feed PWB 1 (YC17) Feed PWB 1 (YC1) and engine PWB (YC6)
	2. Defective clutch.	Replace the MP paper feed clutch.
	3. Defective PWB.	Replace the relay PWB, feed PWB 1 or engine PWB and check for correct operation (see page 1-5-64).
(24) Registration clutch does not operate (30 ppm/35 ppm model only).	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Registration clutch and feed PWB 1 (YC22) Feed PWB 1 (YC2) and engine PWB (YC5)
	2. Defective clutch.	Replace the registration clutch.
	3. Defective PWB.	Replace the feed PWB 1 or engine PWB and check for correct operation (see page 1-5-64).
(25) Middle clutch does not operate (30 ppm/35 ppm model only).	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Middle clutch and feed PWB 2 (YC7) Feed PWB 2 (YC1) and engine PWB (YC4)
	2. Defective clutch.	Replace the middle clutch.
	3. Defective PWB.	Replace the feed PWB 2 or engine PWB and check for correct operation (see page 1-5-64).
(26) Duplex clutch 1 does not operate (30 ppm/35 ppm model only).	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Duplex clutch 1 and relay PWB (YC11) Relay PWB (YC13) and feed PWB 1 (YC23) Feed PWB 1 (YC2) and engine PWB (YC5)
	2. Defective clutch.	Replace the duplex clutch 1.
	3. Defective PWB.	Replace the relay PWB, feed PWB 1 or engine PWB and check for correct operation (see page 1-5-64).

Problem	Causes	Check procedures/corrective measures
(27) Duplex clutch 2 does not operate (30 ppm/35 ppm model only).	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Duplex clutch 2 and relay PWB (YC7) Relay PWB (YC1) and feed PWB 1 (YC14) Feed PWB 1 (YC1) and engine PWB (YC6)
	2. Defective clutch.	Replace the duplex clutch 2.
	3. Defective PWB.	Replace the relay PWB, feed PWB 1 or engine PWB and check for correct operation (see page 1-5-64).
(28) Pickup solenoid 1, 2 does not operate (45 ppm/55 ppm model only).	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Pickup solenoid 1, 2 and feed PWB 2 (YC8) Feed PWB 2 (YC1) and engine PWB (YC4)
	2. Defective solenoid.	Replace the pickup solenoid 1 or 2.
	3. Defective PWB.	Replace the feed PWB 2 or engine PWB and check for correct operation (see page 1-5-64).
(29) Feedshift solenoid does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Feedshift and front PWB (YC5) Front PWB (YC3) and engine PWB (YC7)
	2. Defective solenoid.	Replace the feedshift solenoid 1 or 2.
	3. Defective PWB.	Replace the front PWB or engine PWB and check for correct operation (see page 1-5-64).
(30) Cleaning solenoid does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Cleaning solenoid and feed PWB 1 (YC10) Feed PWB 1 (YC1) and engine PWB (YC4)
	2. Defective solenoid.	Replace the cleaning solenoid.
	3. Defective PWB.	Replace the feed PWB 1 or engine PWB and check for correct operation (see page 1-5-64).
(31) The message requesting paper to be loaded is shown when paper is present on the cassette.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Paper sensor 1, 2 and feed PWB 2 (YC8) Feed PWB 2 (YC1) and engine PWB (YC4)
	2. Deformed actuator.	Check visually and replace if necessary.
	3. Defective sensor.	Replace the paper sensor 1 or 2.
	4. Defective PWB.	Replace the feed PWB 2 or engine PWB and check for correct operation (see page 1-5-64).

Problem	Causes	Check procedures/corrective measures
(32) The message requesting paper to be loaded is shown when paper is present on the MP tray.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. MP paper sensor and relay PWB (YC3) Relay PWB (YC12) and feed PWB 1 (YC17) Feed PWB 1 (YC1) and engine PWB (YC6)
	2. Deformed actuator.	Check visually and replace if necessary.
	3. Defective sensor.	Replace the MP paper sensor.
	4. Defective PWB.	Replace the feed PWB 1 or engine PWB and check for correct operation (see page 1-5-64).
(33) The size of paper on the cassette is not displayed correctly.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Paper length switch 1, 2 and feed PWB 2 (YC3) Paper width switch 1, 2 and feed PWB 2 (YC3) Feed PWB 2 (YC1) and engine PWB (YC4)
	2. Defective switch.	Replace the paper length switch 1, 2 or paper width switch 1, 2.
	3. Defective PWB.	Replace the feed PWB 2 or engine PWB and check for correct operation (see page 1-5-64).
(34) The size of paper on the MP tray is not displayed correctly.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. MP paper length switch and relay PWB (YC2) MP paper width switch and relay PWB (YC2) Relay PWB (YC12) and feed PWB 1 (YC17) Feed PWB 1 (YC1) and engine PWB (YC6)
	2. Defective switch.	Replace the MP paper length switch or MP paper width switch.
	3. Defective PWB.	Replace the relay PWB, feed PWB 1 or engine PWB and check for correct operation (see page 1-5-64).
(35) A paper jam in the paper feed, paper conveying or eject section is indicated when the main power switch is turned on.	1. A piece of paper torn from paper is caught around feed sensor 1, 2, MP feed sensor, middle sensor, paper conveying sensor, registration sensor, loop sensor, fuser eject sensor, duplex sensor 1, 2, eject full sensor or switchback sensor.	Check visually and remove it, if any.
	2. Defective sensor.	Replace the feed sensor 1, 2, MP feed sensor, middle sensor, paper conveying sensor, registration sensor, loop sensor, fuser eject sensor, duplex sensor 1, 2, eject full sensor or switchback sensor.

Problem	Causes	Check procedures/corrective measures
(36) A message indicating cover open is displayed when the front cover is closed.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Front cover switch and front PWB (YC16) Front PWB (YC2) and engine PWB (YC10)
	2. Defective switch.	Replace the front cover switch.
(37) A message indicating unit open is displayed when the paper conveying unit is closed.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Paper conveying unit switch and feed PWB 1 (YC15) Feed PWB 1 (YC4) and power source PWB (YC12)
	2. Defective switch.	Replace the paper conveying unit switch.
(38) A message indicating cover open is displayed when the duplex cover is closed.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Duplex cover switch and relay PWB (YC7) Relay PWB (YC1) and feed PWB 1 (YC14) Feed PWB 1 (YC1) and engine PWB (YC6)
	2. Defective switch.	Replace the duplex cover switch.
(39) A message indicating cover open is displayed when the paper conveying cover is closed.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Paper conveying cover switch and feed PWB 2 (YC6) Feed PWB 2 (YC1) and power source PWB (YC4)
	2. Defective switch.	Replace the paper conveying cover switch.

1-4-9 Mechanical problems

If the part causing the problem was not supplied, use the unit including the part for replacement.

Problem	Causes/check procedures	Corrective measures
(1) No primary paper feed.	Check if the surfaces of the following rollers are dirty with paper powder. Forwarding pulley Paper feed pulley MP paper feed pulley	Clean with isopropyl alcohol.
	Check if the following rollers is deformed. Forwarding pulley Paper feed pulley MP paper feed pulley	Check visually and replace any deformed (see page 1-5-7, 1-5-10, 1-5-14).
	Defective paper feed clutch 1, 2 or MP paper feed clutch installation.	Check visually and remedy if necessary.
(2) No secondary paper feed.	Check if the surfaces of the following rollers are dirty with paper powder. Right registration roller Left registration roller	Clean with isopropyl alcohol.
	Defective registration motor installation. (45 ppm/55 ppm model) Defective registration clutch installation. (30 ppm/35 ppm model)	Check visually and remedy if necessary.
(3) Skewed paper feed.	Paper width guide in a cassette installed incorrectly.	Check the paper width guide visually and remedy or replace if necessary.
(4) Multiple sheets of paper are fed.	Check if the paper is excessively curled.	Change the paper.
	Paper is loaded incorrectly.	Load the paper correctly.
	Check if the separation pulley is worn.	Replace the separation pulley if it is worn (see page 1-5-7, 1-5-10).
(5) Paper jams.	Check if the paper is excessively curled.	Change the paper.
	Check if the contact between the right and left registration rollers is correct.	Check visually and remedy if necessary.
	Check if the heat roller or press roller is extremely dirty or deformed.	Check visually and replace the fuser unit (see page 1-5-55).
(6) Toner drops on the paper conveying path.	Check if the drum unit or developer unit is extremely dirty.	Clean the drum unit or developer unit.

Problem	Causes/check procedures	Corrective measures
(7) Abnormal noise is heard.	Check if the rollers, pulleys and gears operate smoothly.	Grease the bushes and gears.
	Check if the following clutches are installed correctly. Paper feed clutch 1, 2 Assist clutch 1, 2 ^{*1} Paper conveying clutch MP paper feed clutch Registration clutch ^{*2} Middle clutch ^{*2} Duplex clutch 1, 2 ^{*2} *1: 45 ppm/55 ppm model only *2: 30 ppm/35 ppm model only	Check visually and remedy if necessary.

1-4-10 Send error code

This section describes the scanning errors and descriptions, preventive actions, as well as corrective actions. Error codes not described here could fall within software errors.

If such an error is encountered, turn power off then on, and advise the service representative.

(1) Scan to SMB error codes

Code	Contents	Check procedures/corrective measures
1101	Host destined does not exist on the network.	<ol style="list-style-type: none"> 1. Confirm destined host. 2. Confirm device's network parameters. 3. Confirm the network parameters the device is connected.
1102	Login to the host has failed.	<ol style="list-style-type: none"> 1. Confirm user name and password. 2. Confirm the network parameters the device is connected. 3. Check the host if the folder is properly shared.
1103	Destined host, folder, and/or file names are invalid.	<ol style="list-style-type: none"> 1. Check illegal characters are not contained within these names. 2. Check the name of the folder and files conform with the naming syntax. 3. Confirm destined host and folder.
1105	SMB protocol is not enabled.	<ol style="list-style-type: none"> 1. Confirm device's SMB protocols.
2101	Login to the host has failed.	<ol style="list-style-type: none"> 1. Confirm destined host. 2. Confirm that the LAN cable is properly connected to the device. 3. Check the SMB port number. 4. Confirm device's network parameters. 5. Confirm the network parameters the device is connected.
2201	Writing scanned data has failed.	<ol style="list-style-type: none"> 1. Check the scanning file name. 2. Confirm device's network parameters. 3. Confirm the network parameters the device is connected.
2203	No response from the host during a certain period of time.	<ol style="list-style-type: none"> 1. Confirm the network parameters the device is connected. 2. Confirm that the LAN cable is properly connected to the device.

(2) Scan to FTP error codes

Code	Contents	Check procedures/corrective measures
1101	FTP server does not exist on the network.	<ol style="list-style-type: none"> 1. Check the FTP server name. 2. Confirm device's network parameters. 3. Confirm the network parameters the device is connected.
1102	Login to the FTP server has failed.	<ol style="list-style-type: none"> 1. Confirm user name and password. 2. Check the FTP server name.
1103	Destined folder is invalid.	<ol style="list-style-type: none"> 1. Check illegal characters are not contained within these names. 2. Check the FTP server name.
1105	FTP protocol is not enabled.	<ol style="list-style-type: none"> 1. Confirm device's FTP protocols.
1131	Initializing TLS has failed.	<ol style="list-style-type: none"> 1. Confirm device's security parameters.
1132	TLS negotiation has failed.	<ol style="list-style-type: none"> 1. Confirm device's security parameters. 2. Check the FTP server name.
2101	Access to the FTP server has failed.	<ol style="list-style-type: none"> 1. Check the FTP server name. 2. Confirm that the LAN cable is properly connected to the device. 3. Check the FTP port number. 4. Confirm device's network parameters. 5. Confirm the network parameters the device is connected. 6. Check the FTP server name.
2102	Access to the FTP server has failed. (Connection timeout)	<ol style="list-style-type: none"> 1. Check the FTP server name. 2. Check the FTP port number. 3. Confirm device's network parameters. 4. Confirm the network parameters the device is connected. 5. Check the FTP server name.
2103	The server cannot establish communication.	<ol style="list-style-type: none"> 1. Check the FTP server name. 2. Check the FTP port number. 3. Confirm device's network parameters. 4. Confirm the network parameters the device is connected. 5. Check the FTP server name.
2201	Connection with the FTP server has failed.	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected. 3. Confirm destined folder. 4. Check the FTP server name.
2202	Connection with the FTP server has failed. (Timeout)	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected.
2203	No response from the server during a certain period of time.	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected.

Code	Contents	Check procedures/corrective measures
2231	Connection with the FTP server has failed. (FTPS communication)	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected.
3101	FTP server responded with an error.	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected. 3. Check the FTP server.

(3) Scan to E-mail error codes

Code	Contents	Check procedures/corrective measures
1101	SMTP/POP3 server does not exist on the network.	<ol style="list-style-type: none"> 1. Check the SMTP/POP3 server name. 2. Confirm device's network parameters. 3. Confirm the network parameters the device is connected.
1102	Login to the SMTP/POP3 server has failed.	<ol style="list-style-type: none"> 1. Confirm user name and password. 2. Check the SMTP/POP3 server.
1104	The domain the destined address belongs is prohibited by scanning restriction.	<ol style="list-style-type: none"> 1. Confirm device's SMTP parameters.
1105	SMTP protocol is not enabled.	<ol style="list-style-type: none"> 1. Confirm device's SMTP protocols.
1106	Sender's address is not specified.	<ol style="list-style-type: none"> 1. Confirm device's SMTP protocols.
2101	Connection to the SMTP/POP3 server has failed.	<ol style="list-style-type: none"> 1. Check the SMTP/POP3 server name. 2. Confirm that the LAN cable is properly connected to the device. 3. Check the SMTP/POP3 port number. 4. Confirm device's network parameters. 5. Confirm the network parameters the device is connected. 6. Check the SMTP/POP3 server.
2102	Connection to the SMTP/POP3 server has failed. (Connection timeout)	<ol style="list-style-type: none"> 1. Check the SMTP/POP3 server name. 2. Check the SMTP/POP3 port number. 3. Confirm device's network parameters. 4. Confirm the network parameters the device is connected. 5. Check the SMTP/POP3 server.
2103	The server cannot establish communication.	<ol style="list-style-type: none"> 1. Check the SMTP/POP3 server name. 2. Check the SMTP/POP3 port number. 3. Confirm device's network parameters. 4. Confirm the network parameters the device is connected. 5. Check the SMTP/POP3 server.
2201	Connection to the SMTP/POP3 server has failed.	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected.

Code	Contents	Check procedures/corrective measures
2202	Connection to the SMTP/POP3 server has failed. (Timeout)	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected.
2204	The size of scanning exceeded its limit.	<ol style="list-style-type: none"> 1. Confirm device's network parameters.
3101	SMTP/POP3 server responded with an error.	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected. 3. Check the SMTP/POP3 server.
3102	Error: Server Response.	<ol style="list-style-type: none"> 1. Check the SMTP/POP3 server. 2. Wait a minute and trye again.
3201	No SMTP authentication is found.	<ol style="list-style-type: none"> 1. Check the SMTP server. The device supports SMTP authentication services including CRAM-MD5, DIGEST-MD5, PLAIN and LOGIN.
4803	Failed to establish the SSL session.	<ol style="list-style-type: none"> 1. Verify the self certificate of the device. 2. Check the server certificate of the SMTP/POP3 server. 3. Check the SMTP/POP3 configuration of the device and the SMTP/POP3 server.

1-4-11 Error codes

(1) Error code

Error codes are listed on the communication reports, activity report, etc. The codes consist of an error code indication U followed by a 5-digit number. (Error codes for V34 communication errors start with an E indication, followed by five digits.)

The upper three of the five digits indicate general classification of the error and its cause, while the lower two indicate the detailed classification. Items for which detailed classification is not necessary have 00 as the last two digits.




Figure 1-4-4

(2) Table of general classification

Error code	Description
U00000	No response or busy after the set number of redials.
U00100	Transmission was interrupted by a press of the stop/clear key.
U00200	Reception was interrupted by a press of the stop/clear key.
U00300	Recording paper on the destination unit has run out during transmission.
U004XX	A connection was made but interrupted during handshake with the receiver unit (refer to P.1-4-301 U004XX error code table).
U006XX	Communication was interrupted because of a machine problem (refer to P.1-4-301 U006XX error code table).
U00700	Communication was interrupted because of a problem in the destination unit.
U008XX	A page transmission error occurred in G3 mode (refer to P.1-4-301 U008XX error code table).
U009XX	A page reception error occurred in G3 mode (refer to P.1-4-301 U009XX error code table).
U010XX	Transmission in G3 mode was interrupted by a signal error (refer to P.1-4-302 U010XX error code table).
U011XX	Reception in G3 mode was interrupted by a signal error (refer to P.1-4-303 U011XX error code table).
U01400	An invalid one-touch key was specified during communication.
U01500	A communication error occurred when calling in V.8 mode.
U01600	A communication error occurred when called in V.8 mode.
U017XX	A communication error occurred before starting T.30 protocol during transmission in V.34 mode (refer to P.1-4-304 U017XX error code table).
U018XX	A communication error occurred before starting T.30 protocol during reception in V.34 mode (refer to P.1-4-304 U018XX error code table).
U03000	No document was present in the destination unit when polling reception started.
U03200	In interoffice subaddress-based bulletin board reception, data was not stored in the box specified by the destination unit.
U03300	In polling reception from a unit of our make, operation was interrupted due to a mismatch in permit ID or telephone number. Or, in interoffice subaddress-based bulletin board reception, operation was interrupted due to a mismatch in permit ID or telephone number.
U03400	Polling reception was interrupted because of a mismatch in individual numbers (destination unit is either of our make or by another manufacturer).
U03500	In interoffice subaddress-based bulletin board reception, the specified Subaddress confidential box number was not registered in the destination unit.
U03600	An interoffice subaddress-based bulletin board reception was interrupted because of a mismatch in the specified subaddress confidential box number.
U03700	Interoffice subaddress-based bulletin board reception failed because the destination unit had no subaddress-based bulletin board transmission capability, or data was not stored in any subaddress confidential box in the destination unit.

Error code	Description
U04000	In interoffice subaddress-based transmission mode, the specified subaddress box number was not registered in the destination unit.
U04100	Subaddress-based transmission failed because the destination unit had no subaddress-based reception capability.
U04200	In encrypted transmission, the specified encryption box was not registered in the destination unit.
U04300	Encrypted transmission failed because the destination unit had no encrypted communication capability.
U04400	Encrypted transmission was interrupted because encryption keys did not agree.
U04500	Encrypted reception was interrupted because of a mismatch in encryption keys.
U05100	Password check transmission or restricted transmission was interrupted because the permit ID's did not agree with.
U05200	Password check reception or restricted reception was interrupted because the permit ID's did not match, the rejected FAX number's did match, or the destination receiver did not return its phone number.
U05300	The password check reception or the restricted reception was interrupted because the permitted numbers did not match, the rejected numbers did match, or the machine in question did not acknowledge its phone number.
U14000	Memory overflowed during confidential reception. Or, in subaddress-based confidential reception, memory overflowed.
U14100	In interoffice subaddress-based transmission, memory overflowed in the destination unit.
U19000	Memory overflowed during memory reception.
U19100	Memory overflowed in the destination unit during transmission.
U19300	Transmission failed because an error occurred during JBIG encoding.

(2-1) U004XX error code table: Interrupted phase B

Error code	Description
U00430	Polling request was received but interrupted because of a mismatch in permit number. Or, subaddress-based bulletin board transmission request was received but interrupted because of a mismatch in permit ID in the transmitting unit.
U00431	An subaddress-based bulletin board transmission was interrupted because the specified subaddress confidential box was not registered.
U00432	An subaddress-based bulletin board transmission was interrupted because of a mismatch in Subaddress confidential box numbers.
U00433	Subaddress-based bulletin board transmission request was received but data was not present in the subaddress confidential box.
U00440	Subaddress-based confidential reception was interrupted because the specified subaddress box was not registered.
U00450	The destination transmitter disconnected because the permit ID's did not agree with while the destination transmitter is in password-check transmission or restricted transmission.
U00460	Encrypted reception was interrupted because the specified encryption box number was not registered.
U00462	Encrypted reception was interrupted because the encryption key for the specified encryption box was not registered.

(2-2) U006XX error code table: Problems with the unit

Error code	Description
U00601	Document jam or the document length exceeds the maximum.
U00613	Image writing section problem
U00656	Data was not transmitted to a modem error.
U00690	System error.

(2-3) U008XX error code table: Page transmission error

Error code	Description
U00800	A page transmission error occurred because of reception of a RTN or PIN signal.
U00811	A page transmission error reoccurred after retry of transmission in the ECM mode.

(2-4) U009XX error code table: Page reception error

Error code	Description
U00900	An RTN or PIN signal was transmitted because of a page reception error.
U00910	A page reception error remained after retry of transmission in the ECM mode.

(2-5) U010XX error code table: G3 transmission

Error code	Description
U01000	An FTT signal was received for a set number of times after TCF signal transmission at 2400 bps. Or, an RTN signal was received in response to a Q signal (excluding EOP) after transmission at 2400 bps.
U01001	Function of the unit differs from that indicated by a DIS signal.
U01016	An MCF signal was received but no DIS signal was received after transmission of an EOM signal, and T1 timeout was detected.
U01019	No relevant signal was received after transmission of a CNC signal, and the preset number of command retransfers was exceeded (between units of our make).
U01020	No relevant signal was received after transmission of a CTC signal, and the preset number of command retransfers was exceeded (ECM).
U01021	No relevant signal was received after transmission of an EOR.Q signal, and the preset number of command retransfers was exceeded (ECM).
U01022	No relevant signal was received after transmission of an RR signal, and the preset number of command retransfers was exceeded (ECM).
U01028	T5 time-out was detected during ECM transmission (ECM).
U01052	A DCN signal was received after transmission of an RR signal (ECM).
U01080	A PIP signal was received after transmission of a PPS.NULL signal.
U01092	During transmission in V.34 mode, communication was interrupted because of an impossible combination of the symbol speed and communication speed.
U01093	A DCN or other inappropriate signal was received during phase B of transmission.
U01094	The preset number of command retransfers for DCS/NSS signals was exceeded during phase B of transmission.
U01095	No relevant signal was received after transmission of a PPS (Q) signal during phase D of transmission, and the preset number of command transfers was exceeded.
U01096	A DCN signal or invalid command was received during phase D of transmission.
U01097	The preset number of command retransfers was exceeded after transmission of an RR signal or no response.

(2-6) U011XX error code table: G3 reception

Error code	Description
U01100	Function of the unit differs from that indicated by a DCS signal.
U01101	Function of the unit (excl. communication mode select) differs from that indicated by an NSS signal.
U01102	A DTC (NSC) signal was received when no transmission data was in the unit.
U01110	No response after transmission of a DIS signal.
U01111	No response after transmission of a DTC (NSC) signal.
U01113	No response after transmission of an FTT signal.
U01125	No response after transmission of a CNS signal (between units of our make).
U01129	No response after transmission of an SPA signal (short protocol).
U01141	A DCN signal was received after transmission of a DTC signal.
U01143	A DCN signal was received after transmission of an FTT signal.
U01155	A DCN signal was received after transmission of an SPA signal (short protocol).
U01160	During message reception, transmission time exceeded the maximum transmission time per line.
U01162	Reception was aborted due to a modem malfunction during message reception.
U01191	Communication was interrupted because an error occurred during an image data reception sequence in the V.34 mode.
U01193	There was no response, or a DCN signal or invalid command was received, during phase C/D of reception.
U01194	A DCN signal was received during phase B of reception.
U01195	No message was received during phase C of reception.
U01196	Error line control was exceeded and a decoding error occurred for the message being received.

(2-7) U017XX error code table: V.34 transmission

Error code	Description
U01700	A communication error occurred in phase 2 (line probing).
U01720	A communication error occurred in phase 4 (modem parameter exchange).
U01721	Operation was interrupted due to the absence of a common communication speed between units.

U01700: A communication error that occurs at the transmitting unit in the period after transmission of INFO0 before entering phase 3 (primary channel equivalent device training). For example, INFO0/A/Abar (B/Bbar, for polling transmission)/INFOh was not detected.

U01720: A communication error that occurs at the transmitting unit in the period after initiating the control channel before entering the T.30 process. For example, PPh/ALT/MPh/E was not detected.

U01721: In the absence of a common communication speed between units (including when an impossible combination of communication speed and symbol speed occurs) after MPh exchange; 1) a DCN signal was received from the destination unit, and the line was cut; or 2) a DIS (NSF, CSI) signal was received from the destination unit and, in response to the signal, the unit transmitted a DCN signal, and the line was cut.

(2-8) U018XX error code table: V.34 reception

Error code	Description
U01800	A communication error occurred in phase 2 (line probing).
U01810	A communication error occurred in phase 3 (primary channel equivalent device training).
U01820	A communication error occurred in phase 4 (modem parameter exchange).
U01821	Operation was interrupted due to the absence of a common communication speed between units.

U01800: A communication error that occurs at the receiver unit in the period after transmission of INFO0 before entering phase 3 (primary channel equivalent device training). For example, INFO0/B/Bbar (A/Abar, for polling reception)/probing tone was not detected.

U01810: A communication error that occurs at the receiver unit in phase 3 (primary channel equivalent device training). For example, S/Sbar/PP/TRN was not detected.

U01820: A communication error that occurs at the receiver unit in the period after initiating the control channel before entering the T.30 process. For example, PPh/ALT/MPh/E was not detected.

U01821: In the absence of a common communication speed between units (including when an impossible combination of communication speed and symbol speed occurs) after MPh exchange, a DCN signal was transmitted to the destination unit and the line was cut.

1-4-12 Printing System Troubleshooting

Problem	Contents	Causes	Check procedures/corrective measures
1.Error 1020 is displayed.	Bridge board memory check error.	Bridge board mounting error.	Replace the bridge board and check for correct operation.
2.Error 1030 is displayed.	Printing system won't become ready.	Printing system is not powered.	Check power cable connection or replace.
3.Error 1031 is displayed.	Connection error of the DVI cable (damaged or loose connected).	Defective DVI cable or poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable.
	Defective bridge board.	Bridge board mounting error.	Replace the bridge board and check for correct operation.
4.Error 1040 is displayed.	Connection error of the network cable (damaged or loose connected).	Local network cable failure or loose connection.	Reinsert the network cable. Also check for continuity within the connector cable. If none, replace the cable.
5.Error 2000 is displayed.	Model code error.	The model code do not match with the main unit and Printing system.	Install the correct Printing system.
	Connection error of the network.	Network settings are incorrect with the MFP.	See item 9 above.
6.Error 2010 is displayed.	FPGA version mismatch.	The version does not match with the MFP FPGA and the Bridge board FPGA.	Replace the bridge board and check for correct operation(Failure or wrong version).
7.Error 2020 is displayed.	FW version mismatch.	The version does not match with the MFP firmware and the Printing system firmware.	Upgrade to match the version. Supported by the following software versions only. MFP Main 002.031 and later MMI 002.031 and later Printing system : Versions do not matter with the supporting or unsupported capability. If the version of the software is older than the above, upgrade the software for a later version.

Problem	Contents	Causes	Check procedures/corrective measures
8.Error 3000 is displayed.	The initial parameters of Printing system error.	The initial parameters (IP addresses, ports, etc.) do not match with the MFP firmware and the Printing system firmware.	Switch Printing system power off then on again.
	Defective bridge board.	Bridge board mounting error.	Replace the bridge board and check for correct operation.
	Defective main board.	Main board mounting error.	Replace the main board and check for correct operation.
	Defective Printing system.	Board mounting failure in the Printing system.	Replace the Printing system and check for correct operation.
9.“Fiery” is not shown on the MFP application.	Connection error of the DVI cable (damaged or loose connected).	Defective DVI cable or poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable.
	Connection error of the network cable (damaged or loose connected).	Local network cable failure or loose connection.Failure or wrong version.	Reinsert the network cable. Also check for continuity within the connector cable. If none, replace the cable.
	Connection error of the network.	Network settings are incorrect with the MFP.	Check network cable connection or replace. [System Menu] →[System] →Enter LoginUserName and LoginPassword and login. →[NetWork] →[TCP/IP Setting] TCP/IP :ON IPv4 DHCP :ON AutoIP :ON IPv6* :ON *:Make sure IPv6 is set to ON.
		Network settings are incorrect with the PC.	Perform the following steps. [Network Connection] on the control panel →[Local Area Connection] (Properties) →[Internet Protocol] (TCP/IP) (Properties) →Check [Resolve the IP address automatically].
FW version mismatch.	The version does not match with the MFP firmware and the Printing system firmware.	See item 7 above.	

Problem	Contents	Causes	Check procedures/corrective measures
9. "Fiery" is not shown on the MFP application.	Connection error of the harness between the Main board and the bridge board (damaged or loose connected).	Wiring failure or loose connection.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable.
	Defective bridge board.	Bridge board mounting error.	Replace the bridge board and check for correct operation.
	Defective main board.	Main board mounting error.	Replace the main board and check for correct operation.
	Defective Printing system.	Board mounting failure in the Printing system.	Replace the Printing system board and check for correct operation.
10. Fiery is not detectable with Command Work Station.	Connection error of the DVI cable (damaged or loose connected).	Defective DVI cable or poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable.
	Connection error of the network cable (damaged or loose connected).	Local network cable failure or loose connection. Failure or wrong version.	Reinsert the network cable. Also check for continuity within the connector cable. If none, replace the cable.
	Connection error of the network.	Network settings are incorrect with the MFP.	See item 9 above.
		Network settings are incorrect with the PC.	See item 9 above.
	FW version mismatch.	The version does not match with the MFP firmware and the Printing system firmware.	See item 7 above.
	Connection error of the harness between the Main board and the Bridge board (damaged or loose connected).	Defective cable or poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable.
	Defective bridge board.	Bridge board mounting error.	Replace the bridge board.
	Defective main board.	Main board mounting error.	Replace the main board.
Defective Printing system.	Board mounting failure in the Printing system.	Replace the Printing system.	

Problem	Contents	Causes	Check procedures/corrective measures
11.Printing is not possible with Command Work Station.	Defective bridge board.	Bridge board mounting error.	Replace the bridge board.
	Defective main board.	Main board mounting error.	Replace the main board.
	Defective Printing system.	Board mounting failure in the Printing system.	Replace the Printing system.
12.An abnormal printing occurs when printing from Command Work Station.	Connection error of the harness between the Main board and the Bridge board (damaged or loose connected).	Defective cable or poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable.
	Defective bridge board.	Bridge board mounting error.	Replace the bridge board and check for correct operation.
	The image data is not entered.	Engine board mounting error.	Replace the engine board and check for correct operation.
	Defective main board.	Main board mounting error.	Replace the main board and check for correct operation.
	Defective Printing system.	Board mounting failure in the Printing system.	Replace the Printing system and check for correct operation.

1-5-1 Precautions for assembly and disassembly

(1) Precautions

Before starting disassembly, press the Power key on the operation panel to off. Make sure that the Power lamp is off before turning off the main power switch. And then unplug the power cable from the wall outlet.

When the fax kit is installed, be sure to disconnect the modular cable before starting disassembly.

When handling PWBs (printed wiring boards), do not touch parts with bare hands.

The PWBs are susceptible to static charge.

Do not touch any PWB containing ICs with bare hands or any object prone to static charge.

When removing the hook of the connector, be sure to release the hook.

Take care not to get the cables caught.

To reassemble the parts, use the original screws. If the types and the sizes of screws are not known, refer to the PARTS LIST.

(2) Drum

Note the following when handling or storing the drum.

When removing the drum unit, never expose the drum surface to strong direct light.

Keep the drum at an ambient temperature between -20°C/-4°F and 40°C/104°F and at a relative humidity not higher than 85% RH. Avoid abrupt changes in temperature and humidity.

Avoid exposure to any substance which is harmful to or may affect the quality of the drum.

Do not touch the drum surface with any object. Should it be touched by hands or stained with oil, clean it.

(3) Toner

Store the toner container in a cool, dark place.

Avoid direct light and high humidity.

(4) How to tell a genuine Kyocera toner container

As a means of brand protection, the Kyocera toner container utilizes an optical security technology to enable visual validation. A validation viewer is required to accomplish this.

Hold the validation viewer over the left side part of the brand protection seal on the toner container. Through each window of the validation viewer, the left side part of the seal should be seen as follows:

A black-colored band when seen through the left side window (●)

A shiny or gold-colored band when seen through the right side window (☀)

The above will reveal that the toner container is a genuine Kyocera branded toner container, otherwise, it is a counterfeit.




Figure 1-5-1

The brand protection seal has an incision as shown below to prohibit reuse.




Figure 1-5-2

1-5-2 Paper feed section

(1) Detaching and refitting the primary paper feed unit

Procedure

Detaching remove the primary paper feed unit

1. Pull the cassette 1 and cassette 2 out completely.
2. Pull the paper conveying unit out.
3. Open the right lower cover.
4. Remove the strap and then remove the right lower cover.




Figure 1-5-3

5. Remove the rear upper cover and the rear lower cover (see page 1-5-75).
6. Remove three screws and then remove the right lower rear cover.




Figure 1-5-4

7. Open the handle cover.
8. Remove three screws.
9. Unhook the hook and then remove the right lower front cover.




Figure 1-5-5

10. Remove two connectors.




Figure 1-5-6

11. Remove two screws each from primary paper feed unit.

12. Remove the primary paper feed unit.

*: Use the specific primary paper feed unit depending on model - 30 ppm/35 ppm or 45 ppm/55 ppm.





Figure 1-5-7

13. Check or replace the primary paper feed unit and refit all the removed parts.
- *: When refit the primary paper feed unit, you must confirm the inserted pin to the driving coupler.
 - *: For 45ppm/55ppm model, you must install the primary paper feed unit while pushing the retard release lever of the lower side, when the primary paper feed unit is refitted.






Figure 1-5-8

(2) Detaching and refitting the forwarding pulley, paper feed pulley and separation pulley. [30 ppm model / 35 ppm model]

Procedure

1. Remove the primary paper feed unit
(see page 1-5-3).

Detaching the forwarding pulley and paper feed pulley

2. Remove four stop rings.




Figure 1-5-9

3. Slide the paper feed pulley shaft.
4. Remove the joint and three bushes.
5. Remove the spring and forwarding pulley holder assembly.




Figure 1-5-10

6. Pull the primary paper feed shaft out from the forwarding pulley holder.
 7. Remove the feed gear Z30H OW and paper feed pulley.
- *: To refit the feed gear Z30H OW, be sure to correctly align it with the paper feed pulley, so that the on-way clutches meet each other.




Figure 1-5-11

8. Pull the forwarding pulley from the axis hole of forwarding pulley holder.






Figure 1-5-12

Detaching the separation pulley

9. Remove the spring.
10. Remove the retard holder from the primary lower plate.

**Figure 1-5-13**

11. Remove the separation pulley from the retard holder.
12. Clean or replace the forwarding pulley, paper feed pulley and separation pulley.
13. Refit the forwarding pulley, paper feed pulley and separation pulley to the primary paper feed unit.
14. When the forwarding pulley, paper feed pulley or separation pulley is replaced, perform maintenance mode U903 (clearing the jam counter) (see page 1-3-196).

**Figure 1-5-14**

(3) Detaching and refitting the forwarding pulley, paper feed pulley and separation pulley. [45 ppm model / 55 ppm model]

Procedure

1. Remove the primary paper feed unit (see page 1-5-3).
2. Remove the stop ring A and then remove the one way clutch and the paper feed pulley.
3. Remove the stop ring B and then remove the forwarding pulley.




Figure 1-5-15

4. Remove the stop ring.
5. Remove the separation pulley while pushing the retard release lever.
6. Clean or replace the forwarding pulley, paper feed pulley and separation pulley.
7. Refit the forwarding pulley, paper feed pulley and separation pulley to the primary paper feed unit.
8. When the forwarding pulley, paper feed pulley or separation pulley is replaced, perform maintenance mode U903 (clearing the jam counter) (see page 1-3-196).




Figure 1-5-16

(4) Detaching and refitting the MP tray paper feed unit

Procedure

1. Pull the paper conveying unit out.
2. Open the MP tray.
3. Remove four screws.




Figure 1-5-17

4. Unhook eight hooks and then remove the right cover and DU cover assembly.




Figure 1-5-18

5. Remove two connectors.
 6. Release the wire saddle.
 7. Remove the wire saddle.
- *: To refit the wire saddle, be sure to fit in the positioning hole that was previously used.




Figure 1-5-19

8. Remove the MP tray.
- *: When refitting the MP tray, insert it in the MP tray paper feed unit side by turning the lift arm.




Figure 1-5-20

- 9. Remove two screws.
- 10. Remove the MP tray paper feed unit.




Figure 1-5-21

(5) Detaching and refitting the MP forwarding pulley, MP paper feed pulley and MP separation pulley

Procedure

1. Remove the MP tray paper feed unit (see page 1-5-11).

Detaching forwarding pulley and paper feed pulley

2. Unhook three hooks and then remove the Du lower guide.
- *: Remove the DU lower guide easy by bending the top base that the hook is hooking because the hook of the DU lower guide lacks flexibility.




Figure 1-5-22

3. Remove the stop ring A and then slide the driving joint.
4. Slide the bush A.
5. Remove the stop ring B and then remove the bush B.




Figure 1-5-23

6. Unhook the hook of the feed holder assembly.
7. Remove the spring and the feed holder assembly from the top base.




Figure 1-5-24

8. Remove two stop rings.
 9. Pull the feed MPF shaft out.
 10. Remove two bushes, one way gear Z30R and MP paper feed pulley.
- *: To refit the one-way gear Z30R, mount the gear in the correct direction as shown.




Figure 1-5-25

11. Remove the pickup MFP shaft from the axis holes of feed MFP holder.
12. Pull the pickup gear Z30R and MP forwarding pulley out from the pickup MFP shaft.




Figure 1-5-26

Detaching the MP separation pulley

13. Unhook two hooks and then remove the middle guide.






Figure 1-5-27

14. Remove the spring.
15. Release the uniting of joint by sliding the retard holder assembly.

**Figure 1-5-28**

16. Remove the retard holder assembly by turning it as shown.

**Figure 1-5-29**

17. Remove two stop rings.
18. Remove two bushes.
19. Pull the retard MPF shaft out and then remove the torque limiter and the MP separation pulley.
20. Clean or replace the MP forwarding pulley, MP paper feed pulley and MP separation pulley.
21. Refit the MP forwarding pulley, MP paper feed pulley and MP separation pulley to the MP tray paper feed unit.
22. When the MP forwarding pulley, MP paper feed pulley or MP separation pulley is replaced, perform maintenance mode U903 (clearing the jam counter) (see page 1-3-196).




Figure 1-5-30

1-5-3 Optical section

(1) Detaching and refitting the exposure lamp

Notes on handling the LED mount assembly

Do not touch the diffusion seat and the light guiding plate.

Use air blow when you clean the diffusion seat, the light guiding plate, and reflector.

Do not clean it using a cleaning cloth that adheres the fiber easily.




Figure 1-5-31

Procedure

1. Remove the original cover or the document processor.
2. Remove two screws and then remove the ISU front cover.
3. Remove two screws and then remove the ISU right cover.




Figure 1-5-32

4. Remove two screws and then remove the ISU rear cover.




Figure 1-5-33

5. Remove the platen.
6. Peels two films off.




Figure 1-5-34

7. Move the LED mount assembly to the cutting lack part.
8. Unhook the hook and remove the FFC cover from LED mount assembly.
9. Remove the FFC from the FFC connector.
10. Unhook two hooks and remove the FFC guide from the LED mount assembly.




Figure 1-5-35

11. Remove two screws and then remove the LED mount assembly.
12. Check or replace the LED mount assembly and refit all the removed parts.

*: When cleaning the reflector, the light guiding plate and the diffusion sheet of the LED mount assembly, clean it by air blow. Not to leave the hair dust.

13. When the LED mount assembly is replaced, perform maintenance mode U411 (Adjusting the scanner automatically) (see page 1-3-160).




Figure 1-5-36

(2) Detaching and refitting the scanner wires

NOTE

When fitting the wires, be sure to use those specified below.

Machine front: (P/N: 302H717380), black

Machine rear: (P/N: 302H717390), gray

Fitting requires the following tools

Two frame securing tools (P/N 302FZ17100)

Two scanner wire stoppers (P/N 3596811)

Procedure

1. Remove the exposure lamp
(see page 1-5-19).
2. Remove each screw and then remove
front and rear wire holder plates from
mirror 1 frame.
3. Remove the mirror 1 frame.




Figure 1-5-37

4. Remove the round terminals from the scanner wire springs on scanner unit left side.
5. Remove the scanner wire.




Figure 1-5-38

Fitting the scanner wires

6. Move the mirror 2 frame as shown in the figure and insert two frame securing tools into the positioning holes at the front and rear of the machine center to fix the mirror 2 frame in position.




Figure 1-5-39

7. Hook the round terminals (Non-red-marked) onto the catches inside of the scanner unit. (1)
8. Loop the scanner wires around the outer grooves in the pulleys on the mirror 2 frame, winding from below to above. (2)
9. Loop the scanner wire around the groove in the scanner wire pulley at the scanner unit right, winding from above to below. (3)
10. Wind the scanner wires around the scanner wire drum five turns from the rear toward the hole in the drum. (4)
11. Insert the locating ball on the scanner wire into the hole in the scanner wire drum. (5)
12. Wind the scanner wires three turns from the inner toward the hole in the drum. (6)
13. Install the scanner wire stoppers to the scanner wire drum to fix the wires. (7)
14. Loop the scanner wire around the groove in the scanner wire pulley at the scanner unit left, winding from below to above. (8)
15. Loop the scanner wires around the inner grooves in the pulleys on the mirror 2 frame, winding from below to above. (9)
16. Hook the scanner wires around the pulleys at the machine left. (10)
17. Hook the round terminal (Red-marked) onto the scanner wire spring. (11)




Figure 1-5-40

18. Remove the two scanner wire stoppers and frame securing tools.
19. Focusing on the locating ball of the wire drum, move aside the wires to inside.
20. Move the mirror 2 frame from side to side to correctly locate the wires in position.
21. Refit the mirror 1 frame.
22. Move the mirror 1 and 2 frames to the machine left, and insert the two frame securing tools into the positioning holes at the front and rear of the scanner unit to secure the frames in position.
23. Hold the wires and fix each front and rear wire holder plate to mirror 1 frame with the screw.
24. Remove the two frame securing tools.
25. Refit the exposure lamp.




Figure 1-5-41

(3) Detaching and refitting the ISU

Procedure

Detaching the ISU

1. Worn the electrostatic prevention band for the destruction prevention of the CCD board by static electricity.
2. Remove the platen (see page 1-5-19).
3. Remove six screws and then remove the lens cover.




Figure 1-5-42

4. Remove the connector.
 5. Remove the FFC from the FFC connector with a lock.
- *: When removing the FFC from the FFC connector with a lock, remove it after release the lock by lifting the lock lever up (see page 1-5-60).




Figure 1-5-43

- 6. Remove four screws and then remove the ISU.
- *: The ISU's are different depending on 30ppm model/35ppm model and 45ppm model/55ppm model.





Figure 1-5-44

Refitting the ISU

1. Install the FFT.

*: The FFT should be inserted while holding the position (A) shown in the illustration (A).




Figure 1-5-45

2. Decide the fix position of ISU by the following.
 - The right and left of machine:
Verify the number prefixed by a (a) mark.
 - Match the line (c) of ISU to the positioning line (b) of same number on frame side.
 - The rear and front of machine:
Match the edge (e) of ISU to the positioning line (d) on frame side.
3. Fix the ISU as before with four screws.





Figure 1-5-46

Refitting the ISU

4. Check the image

After replacing the CCD unit, check the copy image. According to the condition, execute the procedures below.

1. In case of no problem on the image, go to "9. Image Adjustment"
2. In case a part of the image is whitish from the leading edge or the background image appears like the illustration "a", go to "5. The CCD unit Height Adjustment 1"
3. In case white vertical lines appear on the image like the illustration "b", go to "7. The CCD unit Height Adjustment 2".

*: The CCD unit height adjustment is necessary for above 2 and 3 because an optical axis shifts and the light path is not secured.




Figure 1-5-47

5. The CCD unit Height Adjustment 1

In case a part of the image is whitish from the leading edge or the background image appears like the illustration "a".

The replacement ISU comes complete with a large spacer (B) and a small spacer (C).





Figure 1-5-48

1. **For 45/45, 55/50 ppm model**
Set the spacer (large) (B) into the inside screw holes at the CCD sensor side.
For 30/30, 35/35 ppm model
Set the spacer (large) (B) into the outside screw holes at the CCD sensor side.
2. Check the image.
3. In case of no problem on the image, go to "9. Image Adjustment".
4. In case of the problem on the image, go to "6. Re-adjustment 1".

45/45,55/50 ppm model



30/30,35/35 ppm model




Figure 1-5-49

6. Re-adjustment 1
 1. In case the whitish or background image still appears.
 - c: Insert the additional spacer (small) (C)
 2. In case the white vertical lines appear.
 - d: Remove the spacer (large) (B) and insert the spacer (small) (C).

Check the image and go to "9. Image Adjustment".






Figure 1-5-50

7. The CCD unit Height Adjustment 2

In case of white vertical lines appear like the illustration "b" on page 1.

1. Set the spacer (large)(B) into the outside screw holes at the lens side.
2. Check the image.

45/45,55/50 ppm model



30/30,35/35 ppm model




Figure 1-5-51

8. Re-adjustment 2

1. In case the white vertical lines still appear.
c: Insert the additional spacer (small) (C)
In case the whitish or background image appears.
d: Remove the spacer (large) (B) and insert the spacer (small) (C).
2. Check the image and go to "9. Image Adjustment".





Figure 1-5-52

9. Image Adjustment

Execute the U411 Auto Adjustment (see page 1-3-160).

Set a new auto adjustment chart (part no. 7505000005) on the contact glass.

Execute the U411- Target – Auto –Table (chart1) - ALL.

10. Refit all the removed parts.

(4) Detaching and refitting the LSU

Procedure

1. Remove the paper conveying unit (see page 1-5-47).
2. Remove the left upper cover (see page 1-5-82).
3. Remove the toner filter.
4. Remove the left filter cover and the left filter.
5. Remove two transfer belt filters.
6. Remove the left cover lid.
7. Open the front cover and remove screw A.
8. Remove three screws B and then remove the left cover.




Figure 1-5-53

9. Remove four screws and then remove the LSU retainer.




Figure 1-5-54

- 10. Remove two screws and then remove the middle feed plate.
- 11. Remove two LSU retainer pins and two springs.





Figure 1-5-55

- 12. Pull the LSU out a little.
- 13. Remove the following connector from the LSU.
 30 ppm model/35 ppm model:
 FFC connector with a lock: 1pcs
 Connector: 2pcs

 45 ppm model/55 ppm model:
 FFC connector with a lock: 2pcs
 Connector: 2pcs



*: When remove the FFC from the FFC connector with a lock, removing it after release the lock by lifting the lock lever up.




Figure 1-5-56

14. Pull the LSU out from the body of the machine.




Figure 1-5-57

15. Remove seven screws and then remove the LSU mount lid.




Figure 1-5-58

- 16. Remove the screw.
- 17. Unhook four hooks and then remove the LSU relay PWB cover.




Figure 1-5-59

- 18. Remove all the connectors and the FFC connectors with a lock.
(30ppm model/35ppm model has the FFC connector without a lock.)
- *: When remove the FFC from the FFC connector with a lock, removing it after release the lock by lifting the lock lever up.
- 19. Remove the electric wire from the electric wire support portion.
- 20. Remove the FFC from the FFC support portion.




Figure 1-5-60

- 21. Remove the LSU retainer pins and the springs.
- 22. Remove two screws each and then remove the LSU front holder.




Figure 1-5-61

23. Wrap an antistatic discharging belt around your wrist to prevent damage to the LSU.

*: Do not touch terminals and FFC contacts in the APC PWB of the LSU.

24. Remove four LSUs, following the precautions and instructions below.

(1) Lift the far end of the LSU.

(2) Unhook the protrusions at the front of the LSU.

*: Be sure to handle the front and rear handholds when handling the LSU.

*: Do not get the LSU in direct contact with the holding frame subsequently applying shocks to the polygon motor inside.

25. Check or replace the LSU and refit all the removed parts.

*: When reconnecting FFCs, be sure to insert the FFC all the way in with the FFC connector. This is to avoid a lengthy servicing due to a possible error which could cause re-disassembly and -assembly.

26. When replacing the new LSU, proceed as follows:

1) Performs maintenance mode U469 (Auto color registration correction) (see page 1-3-185).

2) Performs maintenance mode U119 (Setting the drum) (see page 1-3-87).

3) Performs maintenance mode U464 (Calibration) (see page 1-3-178).

4) Performs maintenance mode U412 (Adjusting the uneven density) (see page 1-3-167).

5) Performs maintenance mode U464 (Calibration) (see page 1-3-178).

6) Performs maintenance mode U410 (Adjusting the halftone automatically) (see page 1-3-158).





Figure 1-5-62

(5) Color registration adjustment

Follow the procedure below to replace the laser scanner unit.

Procedure

1. Press the system menu key.
2. Press [Adjustment/Maintenance], [Calibration] and then [Start]. Calibration begins.

Auto correction

3. Press [Color Registration], [Auto] and then [Start]. A chart is printed.
4. Place the printed chart as the original and then [Start]. Color registration begins.



Chart for adjustment

Figure 1-5-63

Manual correction

5. Press [Color Registration], [Manual], [Chart] and then [Print]. A chart is printed.
6. Press [Registration].
Read figures at MH-1 to 7/CH-1 to 7/YH-1 to 7 and MV-3/CV-3/YV-3 of the reference chart and enter the figure marked at the scale which the BK fine line is in line with the M/C/Y fine lines, using the +/- keys.
7. Press [Start] after all values have been entered. Color registration begins.





Chart for adjustment

Figure 1-5-64

8. Press [Chart] and [Print] to print a chart.
9. Verify that each scale is within the range of 1 to A. If they are within the range, proceed to step 10. If scales are out of range, repeat steps 6 through 9.



The scale must be corresponding within the range of "A" from "1".

Figure 1-5-65

10. Verify that scales of MV-1,2,4,5/CV-1,2,4,5/YV-1,2,4,5 coincide within the range of 1 to A. If they are within the range, adjustment is complete. If they are out of range, proceed to step 11.




Chart for adjustment

Figure 1-5-66

If manual color registration has failed:

11. If the balance between V-1 and V-5 is more than 2 scales (sample 1) or less than -2 scales (sample 2), perform the following steps:




Figure 1-5-67

12. Open the front cover and then pull out the waste toner box tray (see page 1-5-42).
13. Rotate the adjustment knob using a 5 mm hex wrench.
 - Direction of rotation
 - (V-1 - V-5) \geq 2 scales (sample 1): rotate counterclockwise.
 - (V-1 - V-5) \leq -2 scales (sample 2): rotate clockwise.
 - Number of rotation
 - (V-1 - V-5) x 4 clicks
14. Refit the waste toner box tray as before and then close the front cover.
15. Turn the main power switch off and on. Correction automatically starts.
16. Print a reference chart and verify the result.

Caution

After the adjustment for the angle of the mirror has been made, run the maintenance mode U464 (Calibration). (see page 1-3-178)




Figure 1-5-68

1-5-4 Image formation section

(1) Detaching and refitting the inner unit

Procedure

1. Open the front cover.
2. Remove all toner container each.
3. Remove the waste toner box tray by lifting upwards and from the right side.




Figure 1-5-69

4. Remove the screw and then open the connector cover.
5. Remove the connector.
6. Remove four fixed screws of inner unit.




Figure 1-5-70

7. Release the lock by pushing the fixed levers at the right and left of inner unit.
8. Remove the inner unit.




Figure 1-5-71

(2) Detaching and refitting the developer unit and drum unit

Detaching example: Developer unit Y and Drum unit Y

Procedure

1. Remove the fuser unit (see page 1-5-55).
2. Pull the transfer belt unit out a little (see page 1-5-49).
3. Remove the inner unit (see page 1-5-42).
4. Close the toner supply shutter.
5. Remove two connectors.




Figure 1-5-72

6. Pull out as one body the developer unit and the drum unit.
(The developer unit becomes basic and the drum units are combined.)
7. Detach the developer unit while supporting bottom.




Figure 1-5-73

8. Remove the drum unit from the developer unit.
 9. Check or replace the drum unit and the developer unit and refit all the removed parts.
10. When replacing the new developer unit, proceed as follows:
 - 1) Performs maintenance mode U140 (AC calibration) for 45 ppm/55 ppm model only (see page 1-3-94).
 - 2) Performs maintenance mode U464 (Calibration) (see page 1-3-178).
 - 3) Performs maintenance mode U469 (Auto color registration correction) (see page 1-3-185).
 - 4) Performs maintenance mode U410 (Adjusting the halftone automatically) (see page 1-3-158).




Figure 1-5-74

11. When replacing the new drum unit, proceed as follows:
 - 1) Performs maintenance mode U119 (drum setup) (see page 1-3-87).
 - 2) Performs maintenance mode U930 (checking/clearing the charger roller count) and checking the counter value (see page 1-3-207).
 - 3) Performs maintenance mode U140 (AC calibration) for 45 ppm/55 ppm model only (see page 1-3-94).
 - 4) Performs maintenance mode U464 (Calibration) (see page 1-3-178).
 - 5) Performs maintenance mode U469 (Auto color registration correction) (see page 1-3-185).
 - 6) Performs maintenance mode U412 (Adjusting the uneven density) (see page 1-3-167).
 - 7) Performs maintenance mode U464 (Calibration) (see page 1-3-178).
 - 8) Performs maintenance mode U410 (Adjusting the halftone automatically) (see page 1-3-158).

(3) Detaching and refitting the charger roller unit

Detaching example: Charger roller unit Y

Procedure

1. Remove the inner unit (see page 1-5-42).
2. Pull out the charger roller unit by picking and releasing the MC lock lever.
3. Check or replace the charger roller unit and refit all the removed parts.

*: When refitting the charger roller unit, that must hook the hook certain by operating the MC lock lever after inserting the charger roller unit until bumping.

4. When replacing the new charger roller unit, proceed as follows:
Performs maintenance mode U930 (clearing the charger roller count) (see page 1-3-207).




Figure 1-5-75

1-5-5 Transfer section

(1) Detaching and refitting the paper conveying unit

Procedure

1. Pull the paper conveying unit out.
2. Remove three screws.
3. Unhook three hooks and then remove the right front cover.




Figure 1-5-76

4. Unhook two hooks and then remove the conveying inner cover from the paper conveying unit.




Figure 1-5-77

- 5. Remove four screws.
- 6. Remove the paper conveying unit by lifting upward.




Figure 1-5-78

(2) Detaching and refitting the transfer belt unit

Procedure

1. Remove the paper conveying unit (see page 1-5-47).
2. Remove the fuser unit (see page 1-5-55).
3. Remove the connector.




Figure 1-5-79

4. Pull out the transfer belt unit by lifting up both ends.




Figure 1-5-80

5. Remove the transfer belt unit.
6. Check or replace the transfer belt unit and refit all the removed parts.

*: When refitting the new transfer belt unit, set the projected part aligned with the rail entrance.

7. When replacing the new transfer belt unit, proceed as follows:
 - 1) Performs maintenance mode U469 (Transfer belt speed correction) (see page 1-3-185).
 - 2) Performs maintenance mode U464 (Calibration) (see page 1-3-178).
 - 3) Performs maintenance mode U469 (Auto color registration correction) (see page 1-3-185).
 - 4) Performs maintenance mode U410 (Adjusting the halftone automatically) (see page 1-3-158).




Figure 1-5-81

(3) Detaching and refitting the cleaning pre brush

Procedure

1. Remove the transfer belt unit (see page 1-5-49).
2. Unhook the front and back springs from the hooks.




Figure 1-5-82

3. Unhook two hooks and then remove the cleaning cover.




Figure 1-5-83

4. Remove the cleaning pre brush by turning it as shown.
5. Check or replace the cleaning pre brush and refit all the removed parts.




Figure 1-5-84

*: Hook the springs back in place onto the cleaning pre brush when installing.




Figure 1-5-85

(4) Detaching and refitting the transfer roller

Procedure

1. Pull out the paper conveying unit.




Figure 1-5-86

2. Loosen two fixed screws on the TC guide.
3. Remove the stop ring.
4. Unhook the hook and remove the TC gear Z29R.
5. Remove two bearings.
6. Remove the transfer roller.





Figure 1-5-87

7. Check or replace the transfer roller and refit all the removed parts.

*: When refitting the transfer roller, confirm that the terminal of the ground plate is in contact with the ground plate in the frame.

8. When replacing the new transfer roller, proceed as follows:

- 1) Performs maintenance mode U127 (clearing the transfer counter) (see page 1-3-88).
- 2) Performs maintenance mode U464 (Calibration) (see page 1-3-178).
- 3) Performs maintenance mode U469 (Auto color registration correction) (see page 1-3-185).
- 4) Performs maintenance mode U410 (Adjusting the halftone automatically) (see page 1-3-158).




Figure 1-5-88

1-5-6 Fuser section

(1) Detaching and refitting the fuser unit

Procedure

1. Pull out the paper conveying unit.
2. Remove the screw and then the fuser wire cover.
3. Remove two connectors





Figure 1-5-89

4. Remove four screws (M4 × 10) and then remove the fuser unit.
5. Check or replace the fuser unit and refit all the removed parts.
6. When replacing the new fuser unit, proceed as follows:
 - 1) Performs maintenance mode U167 (clearing the fuser count) (see page 1-3-106).
 - 2) Performs maintenance mode U464 (Calibration) (see page 1-3-178).
 - 3) Performs maintenance mode U469 (Auto color registration correction) (see page 1-3-185).
 - 4) Performs maintenance mode U410 (Adjusting the halftone automatically) (see page 1-3-158).

**Figure 1-5-90**

(2) Detaching and refitting fuser IH unit

Procedure

1. Remove the rear upper cover and the rear lower cover (see page 1-5-75).
2. Remove the fuser unit (see page 1-5-55).
3. Remove the right upper cover (see page 1-5-75).
4. Remove the right middle rear cover (see page 1-5-75).
5. Remove four screws and then remove the fuser IH PWB cover (see page 1-5-75).
6. Remove the IH electric wire cover (see page 1-5-75).
7. Remove the wire holder.
8. Release the wire saddle.
9. Remove two connectors from the fuser IH PWB according to the following notes.

*: Confirm the power plug is removed from the outlet without fail when you remove the connector because a high current is supplied to fuser IH unit by this connector.

*: Confirm the connected connector was surely locked when you connect this connector again.




Figure 1-5-91

10. Remove two screws.
11. Unhook the hook by lifting up the fuser IH unit a little and then remove it.





Figure 1-5-92

1-5-7 PWBs

(1) Detaching and refitting the main PWB

Procedure

1. Remove the rear upper cover (see page 1-5-75).
2. Release six wire saddles on the controller box.
3. Remove the wire holder.





Figure 1-5-93


4. Remove the following connectors that connected to the main PWB from the outside of the control box.

- YC25
- YC11
- YC30
- YC24
- YC3 (FFC connector with a lock)
- YC17 (BK)
- YC21 (WH)
- YC12



*: When removing the FFC from the FFC connector with a lock, remove the FFC after released by lifting down the lock lever (see figure a and b).

*: When connecting an FFC furnished with the protrusions at both ends, address the side with a blue-colored tape towards the locking lever, insert the FFC into the connector until the protrusions are recessed, and raise the lock lever to lock the FFC (see figure c).



Main PWB

▨ FFC connector with a lock




Figure 1-5-94

5. Remove five screws.
6. Unhook two hooks and then remove the controller box.




Figure 1-5-95

7. Remove the following connectors that connected to the main PWB.
 - YC23
 - YC27
 - YC32
 - YC8 (FFC connector with a lock)
 - YC9
 - YC1 [BLACK] (with a lock)
 - YC2 [BLUE] (with a lock)

*: When removing the FFC from the FFC connector with a lock, remove the FFC after released by lifting down the lock lever (see page 1-5-60)





Figure 1-5-96

8. Release the wire saddle.
9. Remove two wire holders.
10. Remove two screws.
11. Remove the fan motor holder.




Figure 1-5-97

12. Remove five screws from the main PWB.




Figure 1-5-98

13. Remove the main PWB by releasing the projection of ground plate in the network connector.
14. Check or replace the main PWB and refit all the removed parts.

*: When replacing the main PWB, remove the following devices from the main PWB and then reattach it to the new main PWB. (see page 1-6-4)

EEPROM (YC14)
Code DIMM (YS4)
Memory DDR (YS1)

*: Exchange EEPROM (YC14) and code DIMM (YC4) by the set.






Figure 1-5-99

(2) Detaching and refitting the engine PWB

Procedure

1. Remove the controller box (see page 1-5-59).

*: Remove twenty two connectors of following from the engine PWB.

YC1

YC2

YC3

YC4 (FFC connector with a lock)

YC5 (FFC connector with a lock)

YC6 (FFC connector with a lock)

YC7 (FFC connector with a lock)

YC10 (FFC connector with a lock)

YC26

YC9

YC8

YC46 (FFC connector with a lock)

YC11 (FFC connector with a lock)*

YC12 (FFC connector with a lock)

YC15

YC16

YC18

YC17

YC19

YC20

YC21

YC22



YC45

*: 35/ 45/ 55 ppm model

*: When removing the FFC from the FFC connector with a lock, remove the FFC after released by lifting down the lock lever (see page 1-5-60)

*: When removing the FFC from the YC-46 and YC-47, remove the FFC after released by lifting up the lock lever.

*: When connecting an FFC furnished with the protrusions at both ends, address the side with a blue-colored tape towards the locking lever, insert the FFC into the connector until the protrusions are recessed, and raise the lock lever to lock the FFC (see page 1-5-60)



Engine PWB

Figure 1-5-100

2. Remove six screws.
3. Unhook two hooks and then remove the engine PWB.
4. Check or replace the engine PWB and refit all the removed parts.

*: When replacing the engine PWB, remove the EEPROM (U100) from the engine PWB and then reattach it to the new engine PWB.




Figure 1-5-101

(3) Detaching and refitting the power source PWB

Procedure

1. Remove the rear lower cover (see page 1-5-75).
2. Release three wire saddles.
3. Remove four connectors.






Figure 1-5-102

4. Release six wire saddles.
5. Remove the following eleven connectors and three tabs from the power source PWB.

- YC3
- YC1
- TB1
- TB2
- TB5
- YC7
- YC8
- YC17
- YC14
- YC12
- YC16
- YC13
- YC10
- YC11



6. Remove 2-pin relay connector.



Power source PWB

Figure 1-5-103

7. Release the wire saddle.
8. Remove the connector from the coin vender plate.




Figure 1-5-104

9. Remove screw.
10. Remove cooling duct1.
11. Remove two screws.
12. Remove the power source assembly.




Figure 1-5-105

13. Release wire saddle.
14. Remove 2-pin relay connector.
15. Remove screw.
16. Remove cooling duct2.
17. Remove eight screws.
18. Remove the power source PWB.
19. Check or replace the power source PWB and refit all the removed parts.




Figure 1-5-106

(4) Detaching and refitting the high voltage PWB 1

Procedure

1. Remove the power source PWB (see page 1-5-66).
2. Remove the main drive unit (see page 1-5-86).
3. Remove five connectors from high voltage PWB.




Figure 1-5-107

4. Remove eight screws.
5. Unhook two hooks of PWB spacer and then remove the high voltage PWB 1.
6. Check or replace the high voltage PWB 1 and refit all the removed parts.




Figure 1-5-108

(5) Detaching and refitting the high voltage PWB 2

Procedure

1. Remove the main drive unit (see page 1-5-86).
2. Pull the transfer belt unit out a little (see page 1-5-49).
3. Remove two connectors from the high voltage PWB 2 assembly.




Figure 1-5-109

4. Remove two screws.
5. Unhook two hooks and then remove the high voltage PWB 2.
6. Check or replace the high voltage PWB 2 and refit all the removed parts.




Figure 1-5-110

(6) Detaching and refitting the operation PWB

Procedure

1. Pull the paper conveying unit out.
2. Remove the screw from the right upper cover.




Figure 1-5-111

3. Open the front cover.
4. Remove the screw and then remove the fan cover.
5. Unhook three hooks and then remove the front upper right cover.




Figure 1-5-112

6. Remove the screw and then remove the operation panel cover.




Figure 1-5-113

7. Remove two screws and then remove the USB wire (connector).




Figure 1-5-114

8. Remove four screws.




Figure 1-5-115

- 9. Pull the operation panel unit upward.
- 10. Release three wire saddles.
- 11. Remove four connectors from the operation PWB.
- 12. Remove the operation panel unit.




Figure 1-5-116

13. Remove four connectors and two FFC from the operation PWB.

*: When removing the FFC from the FFC connector with a lock, remove the FFC after released by lifting up the lock lever (see page 1-5-60).




Figure 1-5-117

14. Remove four screws and then remove the operation PWB.
15. Check or replace the operation PWB and refit all the removed parts.




Figure 1-5-118

(7) Detaching and refitting the fuser IH PWB

Procedure

1. Remove seven screws and then remove the rear upper cover.




Figure 1-5-119

2. Remove eight screws.
3. Release two hanging parts and then remove the rear lower cover.
4. Remove the fuser unit (see page 1-5-55).




Figure 1-5-120

5. Remove two screws and then remove the ISU right cover.
6. Remove the screw and five hooks and then remove the right upper cover.




Figure 1-5-121

7. Remove the screw.
8. Unhook two hooks and then remove the right middle rear cover.




Figure 1-5-122

9. Remove four screws and then remove the fuser IH PWB cover.
10. Remove the IH electric wire cover.




Figure 1-5-123

11. Release two wire saddles.
12. Remove four connectors from the fuser IH PWB.




Figure 1-5-124

13. Remove two wire holders.
14. Remove the connector (YC27) from feed PWB 1.




Figure 1-5-125

15. Remove three screws.
16. Unhook two hooks and then remove IH box assembly.




Figure 1-5-126

17. Remove two connectors.
18. Remove six screws.
19. Unhook the hook of the PWB spacer and then remove the fuser IH PWB.
20. Check or replace the fuser IH PWB and refit all the removed parts.




Figure 1-5-127

1-5-8 Drive section

(1) Detaching and refitting the drum drive unit K and the drum drive unit MCY

Procedure

Detaching the drum drive unit K

1. Remove the rear upper cover and the rear lower cover (see page 1-5-75).
2. Remove the connector.
3. Release the wire saddle.




Figure 1-5-128

4. Remove three screws.
 5. Remove the drum drive unit K.
- *: Do not have a shaft part alone when you carry drum drive unit K. (Have the housing.)
- *: Put support on the tip of the shaft so that the shaft may become the horizontal when you put drum drive unit K on the table etc.






Figure 1-5-129

Detaching the drum drive unit K


1. Remove the rear upper cover and the rear lower cover (see page 1-5-75).
2. Remove the connector.
3. Release the wire saddle.

**Figure 1-5-130**

4. Remove three screws.
5. Remove the drum drive unit K.

**Figure 1-5-131**

6. Remove two screws.
7. Remove the drive mounting bracket K.

**Figure 1-5-132**

Detaching the drum drive unit MCY

1. Remove the left upper cover .
2. Remove the left cover.




Figure 1-5-133

3. Remove the connector.
4. Remove the screw.




Figure 1-5-134

5. Remove as one body the toner unit duct, the toner fan motor 1 and the toner fan motor 2.




Figure 1-5-135

6. Release wire saddles.
30ppm model/35ppm model: 1
45ppm model/55ppm model: 2
7. Remove connectors.
30ppm model/35ppm model: 1
45ppm model/55ppm model: 3





Figure 1-5-136

8. Remove five screws and then remove the drum drive unit MCY.
- *: Do not have a shaft part alone when you carry drum drive unit MCY. (Have the housing.)
- *: Put support on the tip of the shaft so that the shaft may become the horizontal when you put drum drive unit MCY on the table etc.
9. Check or replace the drum drive unit K and the drum drive unit MCY and refit all the removed parts.




Figure 1-5-137

Detaching the drum motor C,M,Y and MCY

1. Perform steps 1 through 5 of removing the drum drive unit MCY.
2. Release the wire saddle of the motor to remove. (See page -1-5-104.)
- *: For the drum motor M, C, and MCY only.
3. Remove the connector from the motor to remove.




Figure 1-5-138

4. Remove three screws
5. Remove the drum drive unit.




Figure 1-5-139

6. Remove two screws
7. Remove the drive mounting bracket.

*: Remove the drum drive unit M,Y in the same way.




Figure 1-5-140

(2) Detaching and refitting the main drive unit

Procedure

1. Remove the drum drive unit K and the drum drive unit MCY (see page 1-5-80).
2. Release three wire saddles on the main drive unit.
3. Remove two connectors.




Figure 1-5-141

4. Remove five screws.
5. Remove the main drive unit.
6. Check or replace the main drive unit and refit all the removed parts.




Figure 1-5-142

(3) Detaching and refitting the fuser drive unit, transfer drive unit and feed drive unit

Procedure

Detaching the fuser drive unit

1. Remove the rear upper cover and the rear lower cover (see page 1-5-75).
2. Remove five wire holders of feed PWB 1 assembly.
3. Release the wire saddle.




Figure 1-5-143

4. Remove the following twenty connectors from the feed PWB 1.
 - YC18, YC19
 - YC20, YC27
 - YC26, YC3
 - YC17, YC14
 - YC10, YC16
 - YC13, YC12
 - YC23, YC25
 - YC15, YC11
 - YC5, YC4
 - YC1 (FFC connector with a lock)
 - YC2 (FFC connector with a lock)

*: When removing the FFC from the FFC connector with a lock, remove the FFC after released by lifting down the lock lever (see page 1-5-60).




Figure 1-5-144

5. Remove the FFC from the FFC connector with a lock (YC4) on the engine PWB.
Remove the FFC from the FFC connector with a lock (YC1) on the feed PWB 2.

*: When removing the FFC from the FFC connector with a lock, remove the FFC after released by lifting down the lock lever (see page 1-5-60).




Figure 1-5-145

6. Remove three screws.
7. Remove the feed PWB 1 assembly.




Figure 1-5-146

- 8. Remove the connector.
- 9. Remove three screws.
- 10. Remove the fuser drive unit.




Figure 1-5-147

Detaching the transfer drive unit

- 11. Pull out the transfer belt unit a little (see page 1-5-49).
- 12. Release the clamp.
- 13. Remove the connector.
- 14. Remove three screws.
- 15. Remove the transfer drive unit.






Figure 1-5-148

Detaching the feed drive unit

16. Remove three wire holders from the feed 2 FFC guide.

**Figure 1-5-149**

17. Remove two screws and then remove the feed 2 FFC guide.

**Figure 1-5-150**

18. Remove the following nine connectors from the feed PWB 2.

- YC10
- YC11
- YC7
- YC8
- YC3
- YC5
- YC6
- YC13
- YC12




Figure 1-5-151

19. Remove three screws.
20. Remove the feed drive unit.




Figure 1-5-152

21. Check or replace the feed drive unit and refit all the removed parts.

*: Connect the connector (yellow) to the connector of paper feed clutch 1 on stamp [YELLOW] side as before, when removing the connector of the paper feed clutch as the check of the feed drive unit etc.




Figure 1-5-153

(4) Detaching and refitting the lift motor 1 and 2

Procedure

1. Remove the rear lower cover (see page 1-5-75).
2. Remove the power source assembly (see page 1-5-66).
3. Remove the connector each.
4. Remove two screws each.
5. Remove the lift motor 1 and 2.
6. Check or replace the lift motor and refit all the removed parts.




Figure 1-5-154

1-5-9 Others

(1) Detaching the eject filter

Procedure

1. Unhook the hook each and remove two eject filter units.
2. Remove the eject filter from the eject cover.
3. Clean or replace the eject filter and refit the filter.





Figure 1-5-155

(2) Detaching and refitting the toner filter

Procedure

1. Remove the toner filter unit while gripping the levers.
2. Clean or replace the toner filter unit and refit the filter.




Figure 1-5-156

(3) Detaching and refitting the fan filter

Procedure

1. Open the front cover.
2. Remove the fan filter by releasing the lever.
3. Clean the fan filter.
4. Refit the fan filter.




Figure 1-5-157

(4) Detaching and refitting the transfer belt filter

Procedure

1. Remove two transfer belt filters by releasing the lever.
2. Clean the transfer belt filter.
3. Refit the transfer belt filter.




Figure 1-5-158

(5) Detaching and refitting the DU filter

Procedure

1. Open the MP tray.
2. Remove two DU filters by releasing the lever.
3. Clean the DU filter.
4. Refit the DU filter.




Figure 1-5-159

(6) Detaching and refitting the left filter

Procedure

1. Remove the left filter cover by releasing the lever.
2. Remove the left filter.
3. Clean or replace the left filter and refit the filter.




Figure 1-5-160

(7) Detaching and refitting the developer filter

Procedure

1. Remove the developer filter cover by releasing the lever.
2. Remove the developer filter.
3. Clean the developer filter and refit the filter.




Figure 1-5-161

(8) Detaching and refitting the hard disk unit

Procedure

1. Perform maintenance mode U917 (backup data reading) (see page 1-3-203).
2. Remove the rear upper cover (see page 1-5-75).
3. Release the wire saddle.
4. Remove two screws.




Figure 1-5-162

5. Unhook two hooks and pull out the HDD bracket a little.




Figure 1-5-163

6. Remove two connectors from the hard disk unit while pushing the lock lever.
Number of hard disk unit equipment
30ppm model/35ppm model: 1
45ppm model/55ppm model: 2




Figure 1-5-164

7. Remove four screws and then remove the hard disk unit from the HDD bracket.
8. Replace the hard disk unit and refit all the removed parts.
9. Perform maintenance mode U024 (HDD formatting) (see page 1-3-30).
10. Install the firmwares by the following procedure.
1) Connects to the machine the USB memory that preserved Software LANGUAGE BR, JP (Opt Font, Opt Msg), and the PDF1.7 resource. The firmware is installed by switching the main power switch to ON/OFF.
2) Connects to the machine the USB memory that preserved Weekly-Timer, FMU application. Installs the firmware from the application screen of the system menu. (Refer to operation guide.)
11. Perform maintenance mode U917 (backup data writing) (see page 1-3-203).




Figure 1-5-165

(9) Detaching and refitting the eject unit

Procedure

1. Remove the right upper cover (see page 1-5-76).
2. Remove the fuser unit (see page 1-5-55).
3. Remove the connector.
4. Remove two screws and then remove the eject unit.
5. Check or replace the eject unit and refit all the removed parts.




Figure 1-5-166

Cautions on installing the eject unit

When inserting the eject unit into the device, use care that the eject unit does not get in contact with the eject guide, by keeping its actuator lifted while inserting.




Figure 1-5-167

(10) Direction of installing the principal fan motors

When detaching or refitting the fan motors, be careful of the airflow direction (intake or exhaust).




Figure 1-5-168

(11) Skewed paper feeding check/adjustment

At the paper feed source which a sheet of wrinkled paper has caused, check how the paper is fed askew. Run U051 to reduce the curvature of paper at the regist roller and measure how the paper is fed askew.

1. Print a maintenance report and note the U051 value.
2. Reduce the value by 10 for the paper source in question.(See page -1-5-49.)

3. Press the system menu button to print a test chart.

Check the skew value (balance of left and right, B-A).

Less than 1mm: OK

1mm or more:

Correct the skew by using the paper angle adjusting mechanism (in cassette) that modifies the angle of the paper width guides.




Figure 1-5-169

Procedure

1. Unsecure the fixing screws (screw 1 to 4) and adjust the angle of the paper width guide by the skew feed adjustment screw.
If the B-A is negative, rotate clockwise.
If the B-A is positive, rotate counter-clockwise.
2. Tighten the four screw.
*: Secure the screws in the order of screws 1, 2, 3, then 4.
3. Run U051 and reset the curvature the regist roller.




Figure 1-5-170

1-6-1 Upgrading the firmware

Follow the procedure below to upgrade the firmware of main PWB, operation PWB, engine PWB, ISC PWB, fuser IH PWB, motor control PWB, optional language, color table and optional devices.

Preparation

Extract the file that has the download firmware and put them in the USB flash device.

Procedure

1. Perform maintenance item U000 (maintenance report output) and check U019 ROM version.
2. Press the power key on the operation panel, and after verifying the power indicator has gone off, switch off the main power switch.
3. Insert the USB flash device in which the firmware has been written into a notch hole of the machine.
4. Turn the main power switch on. Upgrading firmware starts (blinking the memory LED).

Caution:

Never turn off the power switch or remove the USB flash device during upgrading.

5. [ROM version] is displayed on the touch panel when upgrading is complete.
6. Switch off the main power switch.
7. Wait for several seconds and then remove the USB flash device from the machine.
8. Turn the main power switch on.
9. Perform maintenance item U000 (maintenance report output) and check that U019 ROM version has been upgraded.




Figure 1-6-1

Procedure for recovery of version upgrade using operation PWB

Perform the following if the panel will not be activated due to a power failure during upgrading the version:

Procedure

1. Turn the power switch on the machine off and unplug the power cable. Remove the USB flash device.
2. Set the slide switch from NORMAL to BOOT (This engages the panel to the update mode).
3. Plug the power cable to power and turn the power switch on.

When the memory indicator is lit up (in approx. 1 minute after the power switch is turned on - the recovery firmware for the operation panel PWB has been updated.), turn the power switch off and unplug the power cable.

* : Set the slide switch on the operation PWB from BOOT to NORMAL. For normal use, leave the switch in NORMAL (not BOOT). The panel display is deactivated if this switch is set to BOOT.

* : The minimum parameters of the firmware required for recovery are restored (update mode for rebooting). Perform the normal upgrade procedure.




Figure 1-6-2

Emergency-UPDATE

If the device is accidentally switched off and upgrading was incomplete, upgrade becomes impossible from a USB flash device.

In that case, retry upgrading after recovering the software by following the procedure below.

Preparation

The CF memory card must be formatted in FAT or FAT32 in advance.

Extract the main firmware to download from the file.

Rename the file which was extracted from the archive. [DL_CTRL.2LC] to [KM_EMRG.2LC]

Copy the all extracted files to the root of the CF memory.

Procedure

1. Turn the main power switch off.
2. Install the CF memory card which contains the firmware onto the main PWB.
3. Turn the main power switch on.
4. Rewriting of the PWB software will start for restoration.
The memory and attention LEDs will be blinking.
5. Only the Memory LED will be blinking when rewriting is successful.
* : Only the Attention LED will be blinking when rewriting is failed.
6. Turn the main power switch off.
7. Wait for several seconds and then remove the CF memory from the main PWB.
8. Extract the firmware to download from the archive and copy to the root of the USB flash device.
9. Insert the USB flash device in which the firmware was copied into the slot on the machine.
10. Perform steps 4 to 7 on the previous page.

11. Turn the main power switch on.
12. Perform maintenance item U000 (Print a maintenance report) to check that the version of ROM U109 has been upgraded.




Figure 1-6-3

1-6-2 Remarks on main PWB replacement

When replacing the main PWB, remove the EEPROM (YC14) and code DIMM (YS4) from the main PWB that has been removed and then reattach it to the new main PWB.




Figure 1-6-4

When refitting DIMM, check "CODE" and "FLS" marked on the PWB and refit them to the original positions.




Figure 1-6-5

If the code DIMM (YS4) was replaced with a service supplied part, perform the following.

1. Insert the USB flash device in which the latest firmware was copied, into the slot on the machine and turn power on.(see page P.1-6-1)
2. Referring to the U000 maintenance report printed previously, enter the following values.
 - U252 Setting the destination
 - U265 Setting OEM purchaser code
 - U278 Setting the delivery date
 - U402 Adjusting margins of image printing
 - U952 Maintenance mode workflow
3. Reset machine settings.(Resets system menu settings modified at setup to their defaults.)
 - Main items for settings
 - [Date/Timer] - Date/Time settings
 - [Date/Timer] - Timer settings (Sleep timer)
 - [Edit Destination] - One-touch presetting

[User/Job accounting] - Defaults for user authentication and job accounting only.

Resettings are not required as the data are stored in harddisk.

[FAX] - FAX transmission settings (tel. no. of itself)

[System] - Network settings (IP address)

[Adjustment/Maintenance] - Silent Mode setting

4. Run the maintenance mode for image adjustments which follows.

1. Performs maintenance mode U464 (Calibration) (see page P.1-3-178).
2. Performs maintenance mode U469 (Auto color registration correction) (see page P.1-3-185).
3. Performs maintenance mode U410 (Adjusting the halftone automatically) (see page P.1-3-102).

When connecting the hard disk cables (YC1, YC2) to the PWB, match "BLACK" and "BLUE" marked on the PWB with the connector colors.




Figure 1-6-6

When connecting the USB cables (YC17, YC21) to the PWB, match "BK" and "WH" marked on the PWB with the connector colors.




Figure 1-6-7

1-6-3 Remarks on engine PWB replacement

When replacing the engine PWB, remove the EEPROM (U100) from the engine PWB that has been removed and then reattach it to the new engine PWB.




Figure 1-6-8

2-1-1 Paper feed/conveying section

Paper feed/conveying section consists of the paper feed unit that feeds paper from the cassette and the MP tray paper feed unit that feeds paper from the MP tray, and the paper conveying section that conveys the fed paper to the transfer/separation section.

(1) Cassette paper feed section

Cassette paper feed section consists of the paper holder with the cassette operation plate activated by lift motor 1 and 2, and the pulleys, such as the forwarding pulley, the paper feed pulley and the separation pulley, for extracting and conveying the paper. Paper is fed out of the cassette by the rotation of the forwarding pulley, paper feed pulley and separation pulley.




Figure 2-1-1 Cassette paper feed section

- | | | |
|-----------------------------|--|--|
| 1. Cassette base | 12. Paper sensor 2 (PS2) | 19. Paper gauge sensor 2 (L) (PGS2(L)) |
| 2. Cassette operation plate | 13. Lift sensor 1 (LS1) | 20. Actuator (Paper gauge sensor 2) |
| 3. Cassette | 14. Lift sensor 2 (LS2) | 21. Feed sensor 1 (FS1) |
| 4. Forwarding pulleys | 15. Paper gauge sensor 1 (U) (PGS1(U)) | 22. Feed sensor 2 (FS2) |
| 5. Paper feed pulleys | 16. Paper gauge sensor 1 (L) (PGS1(L)) | 23. Paper conveying sensor (PCS) |
| 6. Separation pulleys | 17. Actuator (Paper gauge sensor 1) | 24. Actuator (Paper conveying sensor) |
| 7. Assist rollers* | 18. Paper gauge sensor 2 (U) (PGS2(U)) | |
| 8. Assist pulleys* | | |
| 9. Paper conveying roller | | |
| 10. Paper conveying pulley | | |
| 11. Paper sensor 1 (PS1) | | |

*: 45 ppm/55 ppm model only




Figure 2-1-2 Cassette paper feed section block diagram

(2) MP tray paper feed section

Paper is fed out of the MP tray by the rotation of the MP forwarding pulley, MP paper feed pulley and MP separation pulley. The MP separation pulley prevents multiple sheets from being fed at one time by the torque limiter.




Figure 2-1-3 MP tray paper feed section

- | | |
|-------------------------------|---------------------------------------|
| 1. MP forwarding pulley | 10. MP lift sensor 2 (MPLS2) |
| 2. MP paper feed pulley | 11. MP paper length switch (MPPLSW) |
| 3. MP separate pulley | 12. Actuator (MP paper length switch) |
| 4. MP table | 13. MP paper width switch (MPPWSW) |
| 5. MP support Tray | 14. MP tray switch (MPTSW) |
| 6. MP lift base | 15. MP feed sensor (MPFS) |
| 7. MP paper sensor (MPPS) | |
| 8. Actuator (MP paper sensor) | |
| 9. MP lift sensor 1 (MPLS1) | |




Figure 2-1-4 MP tray paper feed section block diagram

(3) Paper conveying section

The paper conveying section conveys paper to the transfer/separation section as paper feeding from the cassette or MP tray, or as paper refeeding for duplex printing. Paper by feeding is conveyed by the middle roller to the position where the registration sensor (RS) is turned on, and then sent to the transfer/separation section by the right registration roller and left registration roller.




Figure 2-1-5 Paper conveying section

- | | |
|------------------------------|-----------------------------|
| 1. Middle roller | 6. Middle sensor (MS) |
| 2. Middle pulley | 7. Registration sensor (RS) |
| 3. Left registration roller | |
| 4. Right registration roller | |
| 5. Paper conveying pulley | |




Figure 2-1-6 Paper conveying section block diagram (30 ppm/35 ppm model)




Figure 2-1-7 Paper conveying section block diagram (45 ppm/55 ppm model)

2-1-2 Drum section

The drum section consists of the charger roller unit, drum and cleaning section. The drum is electrically charged uniformly by means of a charger roller to form a latent image on the surface. The cleaning section consists of the cleaning blade and the cleaning roller which remove residual toner from the drum surface after transfer. The cleaning lamp (CL) consists of LEDs and removes residual charge on the drum before main charging.




Figure 2-1-8 Drum section

- | | |
|----------------------------|------------------------|
| 1. Drum | 6. Cleaning blade |
| 2. Charger roller | 7. Cleaning roller |
| 3. Charger cleaning roller | 8. Control roller |
| 4. Charger case | 9. Drum screw |
| 5. Drum frame | 10. Cleaning lamp (CL) |




Figure 2-1-9 Drum section block diagram

2-1-3 Developer section

The developer unit consists of the sleeve roller that forms the magnetic brush, the magnet roller, the developer blade and the developer screws that agitate the toner. Also, the toner sensor (TS) checks whether or not toner remains in the developer unit.




Figure 2-1-10 Developer section

- | | |
|----------------------|----------------------|
| 1. Sleeve roller | 6. Developer case |
| 2. Magnet roller | 7. Developer cover |
| 3. Developer screw A | 8. Magnet cover |
| 4. Developer screw B | 9. Toner sensor (TS) |
| 5. Developer blade | |




Figure 2-1-11 Developer section block diagram

2-1-4 Optical section

The optical section consists of the image scanner section for scanning and the laser scanner section for printing.

(1) Image scanner section

The original image is illuminated by the LED lamp and scanned by the CCD image sensor in the CCD PWB (CCDPWB) via the three mirrors and ISU lens, the reflected light being converted to an electrical signal. The mirror frame A and B travel to scan on the optical rails on the front and rear of the machine to scan from side to side. The speed of the mirror frame B is half the speed of the mirror frame A.




Figure 2-1-12 Image scanner section

- | | |
|----------------------|--------------------------------------|
| 1. Mirror frame A | 9. ISU cover |
| 2. Mirror frame B | 10. Scanner wire drum |
| 3. LED mount | 11. Contact glass |
| 4. Scanner reflector | 12. Slit glass |
| 5. Mirror A | 13. Original size indicator plate |
| 6. Mirror B | 14. Home position sensor (HPS) |
| 7. ISU lens | 15. Original detection switch (ODSW) |
| 8. CCD PWB (CCDPWB) | |




Figure 2-1-13 Image scanner section block diagram

(2) Laser scanner section

The charged surface of the drum is then scanned by the laser beam from the laser scanner unit. The laser beam is dispersed as the polygon motor (PM) revolves to reflect the laser beam over the drum. Various lenses and mirror are housed in the laser scanner unit, adjust the diameter of the laser beam, and focalize it at the drum surface. Also the LSU cleaning motor (LSUCM) is activated to conduct automatically cleaning of the LSU dust shield glass.




Figure 2-1-14 Laser scanner section

- | | |
|-----------------------|--------------------------|
| 1. Polygon motor (PM) | 5. f- θ lens B |
| 2. f- θ lens A | 6. Mirror C |
| 3. Mirror A | 7. LSU dust shield glass |
| 4. Mirror B | 8. LSU spiral |




Figure 2-1-15 Laser scanner unit block diagram

2-1-5 Transfer/Separation section

The transfer/separation section consists of the intermediate transfer unit section and the secondary transfer roller section.

(1) Intermediate transfer unit section

The intermediate transfer unit section consists of the transfer cleaning unit, the transfer belt, and the four primary transfer rollers for respective color drums, and forms a full-color toner image by superimposing and transferring single-color toner images formed on each drum onto the transfer belt. Also with the ID sensors (IDS) mounted on the machine frame, the toner density on the transfer belt is measured.

The transfer cleaning unit collects toner remaining on the transfer belt after secondary transfer and forwards it as waste toner to the waste toner box.




Figure 2-1-16 Intermediate transfer unit section

- | | |
|-------------------------------|----------------------------------|
| 1. Drive roller | 11. Color release sensor (CRS) |
| 2. Backup roller | 12. Transfer belt sensor (TRBLS) |
| 3. Primary transfer roller K | 13. Transfer skew sensor (TRSS) |
| 4. Primary transfer roller M | 14. Transfer edge sensor (TRES) |
| 5. Primary transfer roller C | 15. Transfer skew motor (TRSM) |
| 6. Primary transfer roller Y | 16. Cleaning pre brush |
| 7. Tension roller | 17. Cleaning fur brush |
| 8. Transfer belt | 18. Cleaning roller |
| 9. ID sensor (IDS) | 19. Cleaning blade |
| 10. Color release motor (CRM) | 20. Cleaning screw |




Figure 2-1-17 Intermediate transfer unit section block diagram

(2) Secondary transfer roller section

The secondary transfer roller section consists of the secondary transfer roller mounted to the paper conveying unit and the separation brush. To the secondary transfer roller, DC bias is applied from the high voltage PWB 2 (HVPWB2). The toner image formed on the transfer belt is transferred to the paper by the potential difference and the paper is separated by curvature separation.




Figure 2-1-18 Secondary transfer roller section

1. Secondary transfer roller
2. Separation brush
3. Secondary transfer frame
4. Transfer guide
5. Transfer release sensor (TRRS)
6. Transfer release motor (TRRM)




Figure 2-1-19 Secondary transfer roller section block diagram

2-1-6 Fuser section

The paper sent from the transfer/separation section is interleaved between the heat roller and the press roller. The heat roller (fuser belt) is heated by the fuser IH (FIH), and the toner is fused by heat and pressure and fixed onto the paper because the press roller is pressed by the fuser press spring. The surface temperature of heat roller and press roller are detected by the fuser thermistor (FTH) and controlled by the engine PWB (EPWB).




Figure 2-1-20 Fuser section

- | | |
|-----------------------------|-------------------------------|
| 1. Heat roller (Fuser belt) | 9. Fuser eject roller |
| 2. Press roller | 10. Loop sensor (LPS) |
| 3. IH coils | 11. Fuser belt sensor (FUBLS) |
| 4. Side core | 12. Fuser thermistor 1 (FTH1) |
| 5. Arch core | 13. Fuser thermistor 2 (FTH2) |
| 6. Separators | 14. Fuser thermistor 3 (FTH3) |
| 7. Right fuser cover | 15. Fuser thermistor 4 (FTH4) |
| 8. Fuser eject pulley | 16. Fuser eject sensor (FUES) |




Figure 2-1-21 Fuser section block diagram

2-1-7 Eject/Feedshift section

The paper eject/feedshift section consists of the conveying path which sends the paper that has passed the fuser section to the top tray, duplex conveying section or job separator.




Figure 2-1-22 Eject/Feed shift section

- | | |
|------------------------|----------------------------------|
| 1. Middle pulley | 8. Lower duplex roller |
| 2. Eject roller | 9. Lower change guide |
| 3. Eject pulley | 10. Upper change guide |
| 4. Eject roller B | 11. Eject full sensor (EFS) |
| 5. Eject pulley B | 12. Actuator (eject full sensor) |
| 6. Upper duplex roller | 13. Switchback sensor (SBS) |
| 7. Duplex pulley | 14. Actuator (switchback sensor) |




Figure 2-1-23 Eject/Feed shift section block diagram

2-1-8 Duplex conveying section

The duplex conveying section consists of conveying path which sends the paper sent from the eject/feedshift section to the paper feed/conveying section when duplex printing.




Figure 2-1-24 Duplex conveying section

- | | |
|-------------------------|-------------------------------|
| 1. Upper duplex roller | 6. Duplex sensor 1 (DUS1) |
| 2. Middle duplex roller | 7. Actuator (duplex sensor 1) |
| 3. Lower duplex roller | 8. Duplex sensor 2 (DUS2) |
| 4. Duplex pulleys A | 9. Actuator (duplex sensor 2) |
| 5. Duplex pulleys B | |




Figure 2-1-25 Duplex conveying section block diagram (30 ppm/35 ppm model)




Figure 2-1-26 Duplex conveying section block diagram (45 ppm/55 ppm model)

2-2-1 Electrical parts layout

(1) PWBs




Figure 2-2-1 PWBs


1. Main PWB (MPWB) Controls the software such as the print data processing and provides the interface with computers.
2. Engine PWB (EPWB)..... Controls printer hardware such as high voltage/bias output control, paper conveying system control, and fuser temperature control, etc.
3. Power source PWB (PSPWB) After full-wave rectification of AC power source input, switching for converting to 24 V DC and 12 V DC for output.
4. High voltage PWB 1 (HVPWB1) Generates main charging and developer bias.
5. High voltage PWB 2 (HVPWB2) Generates transfer bias and separation bias.
6. ISC PWB (ISCPWB) Controls the scanner section.
7. CCD PWB (CCDPWB)..... Reads the image of originals.
8. LED lamp PWB (LLPWB) Exposes originals.
9. Operation PWB 1 (OPWB1)..... Controls touch panel and LCD indication.
10. Operation PWB 2 (OPWB2)..... Consists of the LED indicators and key switches.
11. Operation PWB 3 (OPWB3)..... Consists of the LED indicators.

12. Front PWB (FRPWB) Consists of wiring relay circuit between engine PWB and drum units, developer units, eject unit.
13. Feed PWB 1 (FPWB1)..... Consists of wiring relay circuit between engine PWB and fuser drive unit, relay PWB.
14. Feed PWB 2 (FPWB2)..... Consists of wiring relay circuit between engine PWB and paper conveying section, drive section.
15. Relay PWB (RPWB) Consists of wiring relay circuit between feed PWB 1 and paper conveying unit.
16. Motor control PWB (MCPWB)..... Consists of wiring relay circuit between engine PWB and drum motors, developer motors.
17. LSU relay PWB (LSURPWB)..... Consists of wiring relay circuit between engine PWB and laser scanner unit.
18. APC PWB K (APCPWB-K) Generates and controls the laser beam (black).
19. APC PWB M (APCPWB-M) Generates and controls the laser beam (magenta).
20. APC PWB C (APCPWB-C) Generates and controls the laser beam (cyan).
21. APC PWB Y (APCPWB-Y) Generates and controls the laser beam (yellow).
22. PD PWB K (PDPWB-K) Controls horizontal synchronizing timing of laser beam (black).
23. PD PWB M (PDPWB-M) Controls horizontal synchronizing timing of laser beam (magenta).
24. PD PWB C (PDPWB-C)..... Controls horizontal synchronizing timing of laser beam (cyan).
25. PD PWB Y (PDPWB-Y) Controls horizontal synchronizing timing of laser beam (yellow).
26. Drum PWB K (DRPWB-K) Drum individual information in EEPROM storage.
27. Drum PWB M (DRPWB-M) Drum individual information in EEPROM storage.
28. Drum PWB C (DRPWB-C)..... Drum individual information in EEPROM storage.
29. Drum PWB Y (DRPWB-Y) Drum individual information in EEPROM storage.
30. Transfer PWB (TRPWB) Transfer belt individual information in EEPROM storage.
31. Fuser PWB (FUPWB) Relays wirings from electrical components on the fuser unit.
32. Fuser IH PWB (FIHPWB)..... Controls the fuser IH.
33. RFID PWB (RFPWB) Reads the container information.
34. Interface PWB (IFPWB) Consists of wiring relay circuits between main PWB and Fax control PWB.
35. Current PWB (CRPWB)* Changes and outputs the AC current input to an analog signal.

*: 45 ppm model /55 ppm model only.


List of correspondences of PWB names

No.	Name used in service manual	Name used in parts list
1	Main PWB (MPWB)	PARTS PWB MAIN ASSY SP
2	Engine PWB (EPWB)	PARTS PWB ENGINE ASSY SP
3	Power source PWB (PSPWB)	PARTS UNIT LOW VOLTAGE SP
4	High voltage PWB 1 (HVPWB1)	PARTS UNIT HIGH VOLTAGE MAIN SP
5	High voltage PWB 2 (HVPWB2)	PARTS UNIT HIGH VOLTAGE TRANSFER SP
6	ISC PWB (ISCPWB)	PARTS PWB ISC ASSY SP
7	CCD PWB (CCDPWB)	-
8	LED lamp PWB (LLPWB)	-
9	Operation PWB 1 (OPWB1)	PARTS PWB PANEL MAIN ASSY J SP
10	Operation PWB 2 (OPWB2)	PARTS PWB OPERATION ASSY SP
11	Operation PWB 3 (OPWB3)	PARTS PWB OPERATION LED ASSY SP
12	Front PWB (FRPWB)	PARTS PWB FRONT CLR ASSY SP
13	Feed PWB 1 (FPWB1)	PARTS PWB FEED 1 ASSY SP
14	Feed PWB 2 (FPWB2)	PARTS PWB FEED 2 ASSY SP
15	Relay PWB (RPWB)	PARTS PWB JUNCTION ASSY SP
16	Motor control PWB (MCPWB)	PARTS PWB MOTOR CONTROL ASSY SP
17	LSU relay PWB (LSURPWB)	PARTS PWB LSU JUNC CLR ASSY SP
18	APC PWB K (APCPWB-K)	-
19	APC PWB M (APCPWB-M)	-
20	APC PWB C (APCPWB-C)	-
21	APC PWB Y (APCPWB-Y)	-
22	PD PWB K (PDPWB-K)	-
23	PD PWB M (PDPWB-M)	-
24	PD PWB C (PDPWB-C)	-
25	PD PWB Y (PDPWB-Y)	-
26	Drum PWB K (DRPWB-K)	-
27	Drum PWB M (DRPWB-M)	-
28	Drum PWB C (DRPWB-C)	-
29	Drum PWB Y (DRPWB-Y)	-
30	Transfer PWB (TRPWB)	-
31	Fuser PWB (FUPWB)	-
32	Fuser IH PWB (FIHPWB)	-
33	RFID PWB (RFPWB)	PARTS PWB RFID ASSY SP
34	Interface PWB (IFPWB)	PARTS PWB KUIO ASSY SP
35	Current PWB (CRPWB)	PARTS PWB CURRENT AVE ASSY SP

(2) Switches and sensors**Figure 2-2-2 Switches and sensors**

1. Main power switch (MSW) Turns ON/OFF the AC power source.
2. Front cover switch (FRCSW) Detects the opening and closing of the front cover.
3. Paper sensor 1 (PS1) Detects the presence of paper (cassette 1).
4. Paper sensor 2 (PS2) Detects the presence of paper (cassette 2).
5. Lift sensor 1 (LS1)..... Detects activation of upper limit of the bottom plate (cassette 1).
6. Lift sensor 2 (LS2)..... Detects activation of upper limit of the bottom plate (cassette 2).
7. Paper gauge sensor 1 (U) (PGS1(U))... Detects the paper gauge (cassette 1).
8. Paper gauge sensor 1 (L) (PGS1(L)).... Detects the paper gauge (cassette 1).
9. Paper gauge sensor 2 (U) (PGS2(U))... Detects the paper gauge (cassette 2).
10. Paper gauge sensor 2 (L) (PGS2(L)).... Detects the paper gauge (cassette 2).
11. Paper length switch 1 (PLSW1) Detects the length of paper (cassette 1).
12. Paper length switch 2 (PLSW2) Detects the length of paper (cassette 2).
13. Paper width switch 1 (PWSW1) Detects the width of paper (cassette 1).
14. Paper width switch 2 (PWSW2) Detects the width of paper (cassette 2).
15. Feed sensor 1 (FS1) Detects a paper misfeed in the paper feed section (cassette 1).
16. Feed sensor 2 (FS2) Detects a paper misfeed in the paper feed section (cassette 2).
17. Paper conveying sensor (PCS)..... Detects a paper misfeed in the vertical conveying section.
18. MP paper sensor (MPPS) Detects the presence of paper (MP tray).

- 19. MP lift sensor 1 (MPLS1) Detects activation of upper limit of the MP plate.
- 20. MP lift sensor 2 (MPLS2) Detects activation of lower limit of the MP plate.
- 21. MP paper length switch (MPPLSW) Detects the length of paper (MP tray).
- 22. MP paper width switch (MPPWSW) Detects the width of paper (MP tray).
- 23. MP tray switch (MPTSW) Detects the MP tray extension is extend.
- 24. MP feed sensor (MPFS) Detects a paper misfeed in the MP paper feed section.
- 25. Middle sensor (MS) Detects a paper misfeed in the paper conveying section.
- 26. Registration sensor (RS) Controls the secondary paper feed start timing.
- 27. Original size sensor (OSS) Detects the size of the original.
- 28. Original detection switch (ODSW) Detects the opening/closing of the document processor.
- 29. Home position sensor (HPS) Detects the optical system in the home position.
- 30. Screw sensor K (SRS-K) Controls the toner replenishing for the toner container K.
- 31. Screw sensor M (SRS-M) Controls the toner replenishing for the toner container M.
- 32. Screw sensor C (SRS-C) Controls the toner replenishing for the toner container C.
- 33. Screw sensor Y (SRS-Y) Controls the toner replenishing for the toner container Y.
- 34. Toner sensor K (TS-K) Detects the toner density in the developer unit K.
- 35. Toner sensor M (TS-M) Detects the toner density in the developer unit M.
- 36. Toner sensor C (TS-C) Detects the toner density in the developer unit C.
- 37. Toner sensor Y (TS-Y) Detects the toner density in the developer unit Y.
- 38. ID sensor 1 (IDS1) Measures image density for color calibration.
- 39. ID sensor 2 (IDS2) Measures image density for color calibration.
- 40. Color release sensor (CRS) Detects separation of primary transfer rollers M, C, and Y.
- 41. Transfer belt sensor (TRBLS) Detects positioning of transfer belt rotation.
- 42. Transfer skew sensor (TRSS) Detects skew of transfer belt center position.
- 43. Transfer edge sensor (TRES) Detects edge position of the transfer belt.
- 44. Transfer release sensor (TRRS) Detects separation of secondary transfer roller.
- 45. Loop sensor (LPS) Detects a paper misfeed. Controls the fuser motor by detecting deflection in the paper.
- 46. Fuser belt sensor (FUBLS) Detects positioning of fuser belt rotation.
- 47. Fuser release sensor (FURS) Detects fuser pressure release setting (envelope mode).
- 48. Fuser thermistor 1 (FTH1) Detects the heat roller (fuser belt) temperature.
- 49. Fuser thermistor 2 (FTH2) Detects the heat roller (fuser belt) temperature.
- 50. Fuser thermistor 3 (FTH3) Detects the heat roller (fuser belt) temperature.
- 51. Fuser thermistor 4 (FTH4) Detects the press roller temperature.
- 52. Fuser eject sensor (FUES) Detects a paper misfeed in the fuser section.
- 53. Eject full sensor (EFS) Detects a paper misfeed in the eject section. Detects when the inner tray is full.
- 54. Switchback sensor (SBS) Detects a paper misfeed in the eject and switchback sections.
- 55. Duplex sensor 1 (DUS1) Detects a paper misfeed in the duplex section.
- 56. Duplex sensor 2 (DUS2) Detects a paper misfeed in the duplex section.
- 57. Duplex cover switch (DUCSW) Detects the opening and closing of the duplex cover.
- 58. Waste toner sensor 1 (WTS1) Detects when the waste toner box is full.
- 59. Waste toner sensor 2 (WTS2) Detects when the waste toner box is near end.
- 60. Paper conveying unit switch
(PCUSW) Detects the opening and closing of the paper conveying unit.
- 61. Paper conveying cover switch
(PCCSW) Detects the opening and closing of the paper conveying cover.
- 62. Outer temperature sensor 1
(OTEMS1) Detects the outside temperature and humidity.
- 63. Outer temperature sensor 2
(OTEMS2) Detects the outside temperature and humidity.

(3) Motors**Figure 2-2-3 Motors**

- | | |
|---|--|
| 1. Paper feed motor (PFM) | Drives the paper feed section. |
| 2. Lift motor 1 (LM1)..... | Operates the bottom plate (cassette 1). |
| 3. Lift motor 2 (LM2)..... | Operates the bottom plate (cassette 2). |
| 4. MP lift motor (MPLM) | Operates the MP plate. |
| 5. Scanner motor (SM)..... | Drives the optical system. |
| 6. Polygon motor K (PM-K) | Drives the polygon mirror K. |
| 7. Polygon motor M (PM-M)..... | Drives the polygon mirror M. |
| 8. Polygon motor C (PM-C)..... | Drives the polygon mirror C. |
| 9. Polygon motor Y (PM-Y) | Drives the polygon mirror Y. |
| 10. Registration motor (RM) ^{*2} | Drives the registration section. |
| 11. Middle motor (MM) ^{*2} | Drives the paper conveying section. |
| 12. Drum motor K (DRM-K) | Drives the drum unit K. |
| 13. Drum motor M (DRM-M) ^{*2} | Drives the drum unit M. |
| 14. Drum motor C (DRM-C) ^{*2} | Drives the drum unit C. |
| Drum motor MCY (DRM-MCY) ^{*1} | Drives the drum units M, C and Y. |
| 15. Drum motor Y (DRM-Y) ^{*2} | Drives the drum unit Y. |
| 16. Toner motor K (TM-K) | Replenishes toner to the developer unit K. |
| 17. Toner motor M (TM-M) | Replenishes toner to the developer unit M. |

18. Toner motor C (TM-C)..... Replenishes toner to the developer unit C.
19. Toner motor Y (TM-Y) Replenishes toner to the developer unit Y.
20. Developer motor K (DEVM-K)..... Drives the developer unit K.
21. Developer motor MCY (DEVM-MCY) ... Drives the developer units M, C and Y.
22. Vibration motor K (VM-K)..... Toner lump in the developer unit K vibrates.
23. Vibration motor M (VM-M)..... Toner lump in the developer unit M vibrates.
24. Vibration motor C (VM-C) Toner lump in the developer unit C vibrates.
25. Vibration motor Y (VM-Y)..... Toner lump in the developer unit Y vibrates.
26. LSU cleaning motor (LSUCM) Drives LSU dust shield glass cleaning system.
27. Waste toner motor (WTM)..... Drives waste toner system.
28. Transfer motor (TRM) Drives the transfer section.
29. Transfer cleaning motor (TRCM) Drives the transfer cleaning section.
30. Color release motor (CRM)..... Drives separation of primary transfer rollers M, C, and Y.
31. Transfer skew motor (TRSM)..... Drives skew of transfer tension roller.
32. Transfer release motor (TRRM)..... Drives separation of secondary transfer roller.
33. Fuser motor (FUM) Drives the fuser section.
34. Fuser release motor (FURM) Drives fuser pressure release.
35. Eject motor (EM)..... Drives the eject section.
36. Duplex motor 1 (DUM1)*²..... Drives the duplex section.
37. Duplex motor 2 (DUM2)*²..... Drives the duplex section.

*1: 30 ppm model /35 ppm model only.

*2: 45 ppm model /55 ppm model only.

(4) Fan motors





Figure 2-2-4 Motors

- 1. Toner fan motor 1 (TFM1)..... Cools the toner container section.
- 2. Toner fan motor 2 (TFM2)..... Cools the toner container section.
- 3. Developer fan motor 1 (DEVFM1) Cools the developer section.
- 4. Developer fan motor 2 (DEVFM2) Cools the developer section.
- 5. Exhaust fan motor 1 (EXFM1) Cools the machine inside.
- 6. Exhaust fan motor 2 (EXFM2) Cools the machine inside.
- 7. LSU fan motor (LSUFM) Cools the laser scanner unit section.
- 8. Belt fan motor 1 (BLFM1)..... Cools the transfer belt section.
- 9. Belt fan motor 2 (BLFM2)..... Cools the transfer belt section.
- 10. Fuser edge fan motor 1 (FUEFM1)..... Cools the fuser section (edge).
- 11. Fuser edge fan motor 2 (FUEFM2)..... Cools the fuser section (edge).
- 12. Fuser front fan motor (FUFFM)..... Cools the fuser section (front side).
- 13. Fuser rear fan motor (FURFM) Cools the fuser section (rear side).
- 14. Eject front fan motor (EFFM) Cools the eject section (front side).
- 15. Eject rear fan motor (ERFM)..... Cools the eject section (rear side).
- 16. Fuser fan motor 1 (FUFM1) Cools the fuser section.
- 17. Fuser fan motor 2 (FUFM2) Cools the fuser section.

- 18. Eject fan motor 1 (EFM1)..... Cools the eject section.
- 19. Eject fan motor 2 (EFM2)..... Cools the eject section.
- 20. IH fan motor (IHFM) Cools the fuser IH PWB.
- 21. Power source fan motor (PSFM) Cools the power source section.
- 22. Controller fan motor (CONFM)..... Cools the controller section.

(5) Others**Figure 2-2-5 Others**

- | | |
|--|---|
| 1. Paper feed clutch 1 (PFCL1) | Primary paper feed from cassette 1. |
| 2. Paper feed clutch 2 (PFCL2) | Primary paper feed from cassette 2. |
| 3. Assist clutch 1 (ASCL1)* ² | Controls the drive of the assist roller. |
| 4. Assist clutch 2 (ASCL2)* ² | Controls the drive of the assist roller. |
| 5. Paper conveying clutch (PCCL) | Controls the drive of vertical conveying section. |
| 6. MP paper feed clutch (MPPFCL) | Controls primary paper feed from the MP tray. |
| 7. Middle clutch (MCL)* ¹ | Controls the drive of paper conveying section. |
| 8. Registration clutch (RCL)* ¹ | Controls the secondary paper feed. |
| 9. Duplex clutch 1 (DUCL1)* ¹ | Controls the drive of duplex section. |
| 10. Duplex clutch 2 (DUCL2)* ¹ | Controls the drive of duplex section. |
| 11. Pickup solenoid 1 (PUSOL1)* ² | Controls the pickup roller (cassette 1). |
| 12. Pickup solenoid 2 (PUSOL2)* ² | Controls the pickup roller (cassette 2). |
| 13. Feedshift solenoid (FSSOL) | Controls the feedshift guide. |
| 14. Cleaning solenoid (CLSOL) | Controls the ID sensor cleaning. |
| 15. Cleaning lamp K (CL-K) | Eliminates the residual electrostatic charge on the drum (black). |
| 16. Cleaning lamp M (CL-M) | Eliminates the residual electrostatic charge on the drum (magenta). |
| 17. Cleaning lamp C (CL-C) | Eliminates the residual electrostatic charge on the drum (cyan). |

- 18. Cleaning lamp Y (CL-Y) Eliminates the residual electrostatic charge on the drum (yellow).
- 19. Fuser IH (FIH) Heats the heat roller (fuser belt).
- 20. Fuser thermostat (FTS) Prevents overheating of the heat roller (fuser belt).
- 21. Cassette heater (CH) Dehumidifies the cassette section (option).
- 22. Hard disk (HDD) Stores the image data and information of job accounting mode.

*1: 30 ppm model /35 ppm model only.

*2: 45 ppm model /55 ppm model only.

This page is intentionally left blank.

2-3-1 Main PWB




Figure 2-3-1 Main PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC1 Connected to hard disk 1	1	GND	-	-	Ground
	2	TXP	O	-	HDD1 data signal
	3	TXN	O	-	HDD1 data signal
	4	GND	-	-	Ground
	5	RXN	I	-	HDD1 data signal
	6	RXP	I	-	HDD1 data signal
	7	GND	-	-	Ground
YC2 Connected to hard disk 2	1	GND	-	-	Ground
	2	TXP	O	-	HDD2 data signal
	3	TXN	O	-	HDD2 data signal
	4	GND	-	-	Ground
	5	RXN	I	-	HDD2 data signal
	6	RXP	I	-	HDD2 data signal
	7	GND	-	-	Ground
YC3 Connected to engine PWB	1	HSYNC_AN	O	0/3.3 V DC (pulse)	Image control signal
	2	HSYNC_AP	O	0/3.3 V DC (pulse)	Image control signal
	3	HSYNC_BN	O	0/3.3 V DC (pulse)	Image control signal
	4	HSYNC_BP	O	0/3.3 V DC (pulse)	Image control signal
	5	HSYNC_CN	O	0/3.3 V DC (pulse)	Image control signal
	6	HSYNC_CP	O	0/3.3 V DC (pulse)	Image control signal
	7	HSYNC_DN	O	0/3.3 V DC (pulse)	Image control signal
	8	HSYNC_DP	O	0/3.3 V DC (pulse)	Image control signal
	9	VSYNC_AN	O	0/3.3 V DC (pulse)	Image control signal
	10	VSYNC_AP	O	0/3.3 V DC (pulse)	Image control signal
	11	VSYNC_BN	O	0/3.3 V DC (pulse)	Image control signal
	12	VSYNC_BP	O	0/3.3 V DC (pulse)	Image control signal
	13	VSYNC_CN	O	0/3.3 V DC (pulse)	Image control signal
	14	VSYNC_CP	O	0/3.3 V DC (pulse)	Image control signal
	15	VSYNC_DN	O	0/3.3 V DC (pulse)	Image control signal
	16	VSYNC_DP	O	0/3.3 V DC (pulse)	Image control signal
	17	SGND	-	-	Ground
	18	TCLKP	O	0/3.3 V DC (pulse)	Clock signal
	19	TCLKN	O	0/3.3 V DC (pulse)	Clock signal
	20	SGND	-	-	Ground
	21	TCP	O	0/3.3 V DC (pulse)	Image control signal
	22	TCN	O	0/3.3 V DC (pulse)	Image control signal

Connector	Pin	Signal	I/O	Voltage	Description
YC3	23	SGND	-	-	Ground
Connected to engine PWB	24	TBP	O	0/3.3 V DC (pulse)	Image control signal
	25	TBN	O	0/3.3 V DC (pulse)	Image control signal
	26	SGND	-	-	Ground
	27	TAP	O	0/3.3 V DC (pulse)	Image control signal
	28	TAN	O	0/3.3 V DC (pulse)	Image control signal
	29	SGND	-	-	Ground
	30	SLEEP	O	0/3.3 V DC	Sleep signal
	31	HLD_ENG	O	0/3.3 V DC	Engine hold signal
	32	NC	-	-	Not used
	33	SGND	-	-	Ground
	34	EG IRN	O	0/3.3 V DC	Engine interrupt signal
	35	EG SO	I	0/3.3 V DC (pulse)	Serial communication data signal
	36	EG SBSY	O	0/3.3 V DC	Engine busy signal
	37	EG SDIR	O	0/3.3 V DC	Engine communication direction signal
	38	EG_SI	O	0/3.3 V DC (pulse)	Serial communication data signal
	39	EG_SCLK	O	0/3.3 V DC (pulse)	Engine lock signal
	40	SGND	-	-	Ground
YC5	1	TD1+	O	0/3.3 V DC (pulse)	Transmission data
Connected to ethernet	2	TD1-	O	0/3.3 V DC (pulse)	Transmission data
	3	TD2+	O	0/3.3 V DC (pulse)	Transmission data
	4	TD2-	O	0/3.3 V DC (pulse)	Transmission data
	5	CT1	O	3.3 V DC	3.3 V DC power output
	6	CT2	O	3.3 V DC	3.3 V DC power output
	7	TD3+	O	0/3.3 V DC (pulse)	Transmission data
	8	TD3-	O	0/3.3 V DC (pulse)	Transmission data
	9	TD4+	O	0/3.3 V DC (pulse)	Transmission data
	10	TD4-	O	0/3.3 V DC (pulse)	Transmission data
	11	GRLED_A1	O	0/3.3 V DC	LED emitter signal
	12	GRLED_K1	O	0/3.3 V DC	LED emitter signal
	13	YWLED_A2	O	0/3.3 V DC	LED emitter signal
	14	YWLED_K2	O	0/3.3 V DC	LED emitter signal

Connector	Pin	Signal	I/O	Voltage	Description
YC7	1	KMDET	I	0/3.3 V DC	KMAS set signal
Connected to KMAS	2	NC	-	-	Not used
	3	KMDREQ	I	0/3.3 V DC	KMAS control signal
	4	KMACK	O	0/3.3 V DC	KMAS control signal
	5	KMRXD	O	0/3.3 V DC (pulse)	KMAS received data signal
	6	SGND	-	-	Ground
	7	KMTXD	I	0/3.3 V DC (pulse)	KMAS transmission data signal
	8	SGND	-	-	Ground
	9	SGND	-	-	Ground
	10	SGND	-	-	Ground
	11	+5V	O	5 V DC	5 V DC power to KMAS
	12	+5V	O	5 V DC	5 V DC power to KMAS
YC8	1	RESET0	I	0/3.3 V DC	Reset signal
Connected to interface PWB	2	WAKEUP0	O	0/3.3 V DC	Control signal
	3	AUDIO0	I	Analog	Audio signal
	4	GND	-	-	Ground
	5	USB_DP0	I/O	-	USB data signal
	6	USB_DN0	I/O	-	USB data signal
	7	VBUS0	O	3.3 V DC	3.3 V DC power to IFPWB
	8	GND	-	-	Ground
	9	RESET1	I	0/3.3 V DC	Reset signal
	10	WAKEUP1	O	0/3.3 V DC	Control signal
	11	AUDIO1	I	Analog	Audio signal
	12	GND	-	-	Ground
	13	USB_DP1	I/O	-	USB data signal
	14	USB_DN1	I/O	-	USB data signal
	15	VBUS1	O	3.3 V DC	3.3 V DC power to IFPWB
YC9	1	GND	-	-	Ground
Connected to interface PWB	2	5V_CUT0	I	0/3.3 V DC	5 V DC cut signal
	3	GND	-	-	Ground
	4	5V	O	5 V DC	5 V DC power to IFPWB
	5	GND	-	-	Ground
	6	5V_CUT1	I	0/3.3 V DC	5 V DC cut signal

Connector	Pin	Signal	I/O	Voltage	Description
YC10	1	GND	-	-	Ground
Connected to DP relay PWB	2	GND	-	-	Ground
	3	3.3V	O	3.3 V DC	3.3 V DC power to DPRPWB
	4	3.3V	O	3.3 V DC	3.3 V DC power to DPRPWB
	5	3.3V	O	3.3 V DC	3.3 V DC power to DPRPWB
	6	3.3V	O	3.3 V DC	3.3 V DC power to DPRPWB
	7	VCLKB	I	0/3.3 V DC (pulse)	DPRPWB clock signal
	8	VSYNCB	I	0/3.3 V DC (pulse)	DPRPWB VSYNCB signal
	9	HSYNCB	I	0/3.3 V DC (pulse)	DPRPWB HSYNCB signal
	10	MREB	I	0/3.3 V DC (pulse)	DPRPWB MREB signal
	11	GND	-	-	Ground
	12	DRB0	I	0/3.3 V DC (pulse)	Image data signal
	13	DRB1	I	0/3.3 V DC (pulse)	Image data signal
	14	DRB2	I	0/3.3 V DC (pulse)	Image data signal
	15	DRB3	I	0/3.3 V DC (pulse)	Image data signal
	16	DRB4	I	0/3.3 V DC (pulse)	Image data signal
	17	DRB5	I	0/3.3 V DC (pulse)	Image data signal
	18	DRB6	I	0/3.3 V DC (pulse)	Image data signal
	19	DRB7	I	0/3.3 V DC (pulse)	Image data signal
	20	GND	-	-	Ground
	21	DGB0	I	0/3.3 V DC (pulse)	Image data signal
	22	DGB1	I	0/3.3 V DC (pulse)	Image data signal
	23	DGB2	I	0/3.3 V DC (pulse)	Image data signal
	24	DGB3	I	0/3.3 V DC (pulse)	Image data signal
	25	DGB4	I	0/3.3 V DC (pulse)	Image data signal
	26	DGB5	I	0/3.3 V DC (pulse)	Image data signal
	27	DGB6	I	0/3.3 V DC (pulse)	Image data signal
	28	DGB7	I	0/3.3 V DC (pulse)	Image data signal
	29	GND	-	-	Ground
	30	DBB0	I	0/3.3 V DC (pulse)	Image data signal
	31	DBB1	I	0/3.3 V DC (pulse)	Image data signal
	32	DBB2	I	0/3.3 V DC (pulse)	Image data signal
	33	DBB3	I	0/3.3 V DC (pulse)	Image data signal
	34	DBB4	I	0/3.3 V DC (pulse)	Image data signal
	35	DBB5	I	0/3.3 V DC (pulse)	Image data signal
	36	DBB6	I	0/3.3 V DC (pulse)	Image data signal

Connector	Pin	Signal	I/O	Voltage	Description
YC10	37	DBB7	I	0/3.3 V DC (pulse)	Image data signal
Connected to DP relay PWB	38	HHALF	O	0/3.3 V DC	DPRPWB Control signal
	39	SLEEP	O	0/3.3 V DC	DPRPWB Control signal
	40	TWS_DET	I	0/3.3 V DC	DPRPWB Control signal
	41	GND	-	-	Ground
	42	LA2	O	0/3.3 V DC (pulse)	Address bus signal
	43	LA3	O	0/3.3 V DC (pulse)	Address bus signal
	44	LA4	O	0/3.3 V DC (pulse)	Address bus signal
	45	LA5	O	0/3.3 V DC (pulse)	Address bus signal
	46	LA6	O	0/3.3 V DC (pulse)	Address bus signal
	47	LA7	O	0/3.3 V DC (pulse)	Address bus signal
	48	LA8	O	0/3.3 V DC (pulse)	Address bus signal
	49	LA9	O	0/3.3 V DC (pulse)	Address bus signal
	50	LA10	O	0/3.3 V DC (pulse)	Address bus signal
	51	LA11	O	0/3.3 V DC (pulse)	Address bus signal
	52	LA12	O	0/3.3 V DC (pulse)	Address bus signal
	53	LA13	O	0/3.3 V DC (pulse)	Address bus signal
	54	LA14	O	0/3.3 V DC (pulse)	Address bus signal
	55	LA15	O	0/3.3 V DC (pulse)	Address bus signal
	56	LA16	O	0/3.3 V DC (pulse)	Address bus signal
	57	LA17	O	0/3.3 V DC (pulse)	Address bus signal
	58	GND	-	-	Ground
	59	LD0	I/O	0/3.3 V DC (pulse)	Data bus signal
	60	LD1	I/O	0/3.3 V DC (pulse)	Data bus signal
	61	LD2	I/O	0/3.3 V DC (pulse)	Data bus signal
	62	LD3	I/O	0/3.3 V DC (pulse)	Data bus signal
	63	LD4	I/O	0/3.3 V DC (pulse)	Data bus signal
	64	LD5	I/O	0/3.3 V DC (pulse)	Data bus signal
	65	LD6	I/O	0/3.3 V DC (pulse)	Data bus signal
	66	LD7	I/O	0/3.3 V DC (pulse)	Data bus signal
	67	GND	-	-	Ground
	68	INT	I	0/3.3 V DC	DPRPWB Control signal
	69	RESETZ	O	0/3.3 V DC	DPRPWB Control signal
70	GND	-	-	Ground	
71	CEZ	O	0/3.3 V DC (pulse)	DPRPWB Control signal	
72	WEZ	O	0/3.3 V DC (pulse)	DPRPWB Control signal	

Connector	Pin	Signal	I/O	Voltage	Description
YC10 Connected to DP relay PWB	73	OEZ	O	0/3.3 V DC (pulse)	DPRPWB Control signal
	74	SCLKIN	O	0/3.3 V DC (pulse)	DPRPWB clock signal
	75	3.3V	O	3.3 V DC	3.3 V DC power to DPRPWB
	76	3.3V	O	3.3 V DC	3.3 V DC power to DPRPWB
	77	3.3V	O	3.3 V DC	3.3 V DC power to DPRPWB
	78	3.3V	O	3.3 V DC	3.3 V DC power to DPRPWB
	79	GND	-	-	Ground
	80	GND	-	-	Ground
YC11 Connected to ISC PWB	1	GND	-	-	Ground
	2	SC_IRN	O	0/3.3 V DC	Scanner interrupt signal
	3	SC_DIR	O	0/3.3 V DC	Scanner communication direction signal
	4	SC_HLDN	O	0/3.3 V DC	Scanner hold signal
	5	SC_BSY	O	0/3.3 V DC	Scanner busy signal
	6	SC_SI	O	0/3.3 V DC (pulse)	Serial communication data signal
	7	SC_SO	I	0/3.3 V DC (pulse)	Serial communication data signal
	8	SC_CLK	O	0/3.3 V DC (pulse)	Scanner clock signal
YC12 Connected to operation PWB 1	1	DEEP_POWERON	O	0/3.3 V DC	Sleep return signal
	2	ENERGY_SAVE	O	0/3.3 V DC	Energy save signal
	3	SUPND_POWER	O	3.3 V DC	3.3 V DC power to OPWB1
	4	LED_MEMORY_N	O	0/3.3 V DC	Memory LED control signal
	5	LED_ATTENTION_N	O	0/3.3 V DC	Attention LED control signal
	6	LED_PROCESSING_N	O	0/3.3 V DC	Processing LED control signal
	7	SHUT_DOWN	O	0/3.3 V DC	24 V down signal
	8	LIGHTOFF_POWERON	O	0/3.3 V DC	Sleep return signal
	9	AUDIO	O	Analog	Audio output signal
	10	PANEL RESET	O	0/3.3 V DC	Reset signal
	11	INT_POWERKEY_N	I	0/3.3 V DC	Power key: On/Off
	12	PANEL_STATUS	I	0/3.3 V DC	Operation panel status signal
	13	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC16	1	GND	-	-	Ground
Connected to CF card	2	D3	I/O	0/3.3 V DC (pulse)	Data bus signal
	3	D4	I/O	0/3.3 V DC (pulse)	Data bus signal
	4	D5	I/O	0/3.3 V DC (pulse)	Data bus signal
	5	D6	I/O	0/3.3 V DC (pulse)	Data bus signal
	6	D7	I/O	0/3.3 V DC (pulse)	Data bus signal
	7	/CE1	O	0/3.3 V DC	Control signal
	8	A10	O	0/3.3 V DC (pulse)	Address bus signal
	9	/OE	O	0/3.3 V DC	Control signal
	10	A9	O	0/3.3 V DC (pulse)	Address bus signal
	11	A8	O	0/3.3 V DC (pulse)	Address bus signal
	12	A7	O	0/3.3 V DC (pulse)	Address bus signal
	13	VCC	O	0/3.3 V DC	Control signal
	14	A6	O	0/3.3 V DC (pulse)	Address bus signal
	15	A5	O	0/3.3 V DC (pulse)	Address bus signal
	16	A4	O	0/3.3 V DC (pulse)	Address bus signal
	17	A3	O	0/3.3 V DC (pulse)	Address bus signal
	18	A2	O	0/3.3 V DC (pulse)	Address bus signal
	19	A1	O	0/3.3 V DC (pulse)	Address bus signal
	20	A0	O	0/3.3 V DC (pulse)	Address bus signal
	21	D0	I/O	0/3.3 V DC (pulse)	Data bus signal
	22	D1	I/O	0/3.3 V DC (pulse)	Data bus signal
	23	D2	I/O	0/3.3 V DC (pulse)	Data bus signal
	24	WP	O	0/3.3 V DC	Control signal
	25	/CD2	O	0/3.3 V DC	Control signal
	26	/CD1	O	0/3.3 V DC	Control signal
	27	D11	I/O	0/3.3 V DC (pulse)	Data bus signal
	28	D12	I/O	0/3.3 V DC (pulse)	Data bus signal
	29	D13	I/O	0/3.3 V DC (pulse)	Data bus signal
	30	D14	I/O	0/3.3 V DC (pulse)	Data bus signal
	31	D15	I/O	0/3.3 V DC (pulse)	Data bus signal
	32	/CE2	O	0/3.3 V DC	Control signal
	33	/VS1	O	0/3.3 V DC	Control signal
	34	/IORD	O	0/3.3 V DC	Control signal
	35	/IOWD	O	0/3.3 V DC	Control signal
	36	/WE	O	0/3.3 V DC	Control signal

Connector	Pin	Signal	I/O	Voltage	Description
YC16 Connected to CF card	37	RDY/BSY	I	0/3.3 V DC	Control signal
	38	VCC	O	0/3.3 V DC	Control signal
	39	CSEL	O	0/3.3 V DC	Control signal
	40	VS2	O	0/3.3 V DC	Control signal
	41	RESET	I	0/3.3 V DC	Reset signal
	42	/WAIT	O	0/3.3 V DC	Control signal
	43	INPACK	O	0/3.3 V DC	Control signal
	44	/REG	I	0/3.3 V DC	REG signal
	45	BVD2	O	0/3.3 V DC	Control signal
	46	BVD1	O	0/3.3 V DC	Control signal
	47	D8	I/O	0/3.3 V DC (pulse)	Data bus signal
	48	D9	I/O	0/3.3 V DC (pulse)	Data bus signal
	49	D10	I/O	0/3.3 V DC (pulse)	Data bus signal
	50	GND	-	-	Ground
YC17 Connected to operation PWB 1	1	VBUS	O	5 V DC	5 V DC power output
	2	DATA -	I/O	-	USB data signal
	3	DATA +	I/O	-	USB data signal
	4	NC	-	-	Not used
	5	GND	-	-	Ground
YC20 Connected to USB	1	VBUS	O	5 V DC	5 V DC power output
	2	DATA-	I/O	-	USB data signal
	3	DATA+	I/O	-	USB data signal
	4	GND	-	-	Ground
YC21 Connected to USB host	1	VBUS	O	5 V DC	5 V DC power output
	2	DATA -	I/O	-	USB data signal
	3	DATA +	I/O	-	USB data signal
	4	NC	-	-	Not used
	5	GND	-	-	Ground
YC23 Connected to controller fan motor	1	+12V	O	12 V DC	CONFM: On/Off
	2	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC24 Connected to power source PWB	1	+12V	O	12 V DC	12 V DC power from PSPWB
	2	+12V	O	12 V DC	12 V DC power from PSPWB
	3	+12V	O	12 V DC	12 V DC power from PSPWB
	4	+12V	O	12 V DC	12 V DC power from PSPWB
	5	GND	-	-	Ground
	6	GND	-	-	Ground
	7	GND	-	-	Ground
	8	GND	-	-	Ground
YC25 Connected to ISC PWB	1	GND	-	-	Ground
	2	HTPDN	I	0/3.3 V DC	Control signal
	3	LOCKN	I	0/3.3 V DC	Lock signal
	4	GND	-	-	Ground
	5	RX0N	I	0/3.3 V DC (pulse)	Received data signal
	6	RX0P	I	0/3.3 V DC (pulse)	Received data signal
	7	GND	-	-	Ground
YC27 Connected to hard disk 1	1	GND	-	-	Ground
	2	+5V_HDD	O	5 V DC	5 V DC power to HDD1
	3	GND	-	-	Ground
YC30 Connected to operation PWB 1	1	+5V	O	5 V DC	5 V DC power from OPWB1
	2	+5V	O	5 V DC	5 V DC power from OPWB1
	3	+5V	O	5 V DC	5 V DC power from OPWB1
	4	GND	-	-	Ground
	5	GND	-	-	Ground
	6	GND	-	-	Ground
YC32 Connected to hard disk 2	1	GND	-	-	Ground
	2	+5V_HDD	O	5 V DC	5 V DC power to HDD2
	3	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC33	1	SGND	-	-	Ground
Connected to fiery relay PWB	2	SDOCLK	O	0/3.3 V DC (pulse)	Clock signal
	3	SDO	O	0/3.3 V DC (pulse)	Serial communication data signal
	4	SGND	-	-	Ground
	5	SDICLK	O	0/3.3 V DC (pulse)	Clock signal
	6	SDI	I	0/3.3 V DC (pulse)	Serial communication data signal
	7	SGND	-	-	Ground
	8	SGND	-	-	Ground
	9	12V	O	12 V DC	12 V DC power to FIRPWB
	10	12V	O	12 V DC	12 V DC power to FIRPWB

Connector	Pin	Signal	I/O	Voltage	Description
YC1	1	GND	-	-	Ground
Connected to feed PWB 1	2	+5V	I	5 V DC	5 V DC power from FPWB1
	3	GND	-	-	Ground
	4	+12V	I	12 V DC	12 V DC power from FPWB1
	5	GND	-	-	Ground
	6	GND	-	-	Ground
	7	+24V1	I	24 V DC	24 V DC power from FPWB1
	8	+24V1	I	24 V DC	24 V DC power from FPWB1
YC2	1	GND	-	-	Ground
Connected to front PWB	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	GND	-	-	Ground
	5	GND	-	-	Ground
	6	+24V	O	24 V DC	24 V DC power to FRPWB
	7	+24V	O	24 V DC	24 V DC power to FRPWB
	8	+5V	O	5 V DC	5 V DC power to FRPWB
	9	+3.3V2	O	3.3 V DC	3.3 V DC power to FRPWB
	10	+3.3V1	O	3.3 V DC	3.3 V DC power to FRPWB
	YC3	A1	+24V1	O	24 V DC
Connected to transfer belt unit	A2	GND	-	-	Ground
	A3	ICL_MOT_REM	I	0/3.3 V DC	TRCM: On/Off
	A4	ICL_MOT_CLK	O	0/3.3 V DC (pulse)	TRCM clock signal
	A5	ICL_MOT_RDY	I	0/3.3 V DC	TRCM ready signal
	A6	ICL_MOT_DIR	O	0/3.3 V DC	TRCM drive switch signal
	A7	RLS_MOT_DR	O	0/24 V DC	CRM: On/Off
	A8	+24V1	O	24 V DC	24 V DC power to CRM
	A9	GND	-	-	Ground
	A10	RLS_SENS	I	0/3.3 V DC	CRS: On/Off
	A11	+5V	O	5 V DC	5 V DC power to CRS
	A12	ZIG_MOT_DR_C CW	O	0/24 V DC	TRSM: On/Off (CCW)
	A13	ZIG_MOT_DR_C W	O	0/24 V DC	TRSM: On/Off (CW)
	A14	GND	-	-	Ground
	A15	BLT_INDEX	-	-	Not used
	A16	+5V	-	-	Ground
	B1	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC3	B2	ZIG_SENS	I	0/3.3 V DC	TRSS: On/Off
Connected to transfer belt unit	B3	+5V	O	5 V DC	5 V DC power to TRSS
	B4	GND	-	-	Ground
	B4	GND	-	-	Ground
	B5	BLT_SPEED	I	0/3.3 V DC	TRBLS: On/Off
	B6	+5V	O	5 V DC	5 V DC power to TRBLS
	B7	TEMP	I	Analog	TEMP signal
	B8	ZIG_REV_SENS	I	0/3.3 V DC	TRES: On/Off
	B9	GND	-	-	Ground
	B10	+5V	O	5 V DC	5 V DC power to TRES
	B11	+3.3V2	O	3.3 V DC	3.3 V DC power to TRPWB
	B12	EPP_SCL2	O	0/3.3 V DC (pulse)	EEPROM clock signal
	B13	EPP_SDA2	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	B14	GND	-	-	Ground
	B15	A0	-	-	Not used
	B16	A1	-	-	Not used
YC4	1	GND	-	-	Ground
Connected to feed PWB 2	2	FEED_MOT_REM	O	0/3.3 V DC	PFM: On/Off
	3	FEED_MOT_CLK	O	0/3.3 V DC (pulse)	PFM clock signal
	4	FEED_MOT_RDY	I	0/3.3 V DC	PFM ready signal
	5	FEED_MOT_DIR	O	0/3.3 V DC	PFM drive switch signal
	6	FEED_CL1_REM	O	0/24 V DC	PFCL1: On/Off
	7	FEED_CL2_REM	O	0/24 V DC	PFCL2: On/Off
	8	ASIST_CL2	O	0/24 V DC	ASCL2: On/Off
	9	LIFT_MOT2_REM	O	0/24 V DC	LM2: On/Off
	10	GND	-	-	Ground
	11	LIFT_MOT1_REM 1	O	0/24 V DC	LM1: On/Off
	12	CAS2_WID	I	0/3.3 V DC	PWSW2: On/Off
	13	CAS2_LNG3	I	0/3.3 V DC	PLSW2: On/Off
	14	CAS2_LNG2	I	0/3.3 V DC	PLSW2: On/Off
	15	CAS2_LNG1	I	0/3.3 V DC	PLSW2: On/Off
	16	CAS1_WID	I	0/3.3 V DC	PWSW1: On/Off
	17	CAS1_LNG3	I	0/3.3 V DC	PLSW1: On/Off
	18	CAS1_LNG2	I	0/3.3 V DC	PLSW1: On/Off
	19	CAS1_LNG1	I	0/3.3 V DC	PLSW1: On/Off
	20	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC4	21	CAS2_QUANT2	I	0/3.3 V DC	PGS2(L): On/Off
Connected to feed PWB 2	22	CAS2_QUANT1	I	0/3.3 V DC	PGS2(U): On/Off
	23	CAS1_QUANT2	I	0/3.3 V DC	PGS1(L): On/Off
	24	CAS1_QUANT1	I	0/3.3 V DC	PGS1(U): On/Off
	25	LIFT_MOT1_LOCK	I	0/3.3 V DC	LM1 lock signal
	26	LIFT_MOT2_LOCK	I	0/3.3 V DC	LM2 lock signal
	27	CURRENT_SIG	I	0/3.3 V DC	Current signal
	28	V-FEED_CL	O	0/24 V DC	PCCL: On/Off
	29	COVER_OPEN	I	0/3.3 V DC	PCCSW: On/Off
	30	FEED2_SENS	I	0/3.3 V DC	PFPCS1: On/Off
	31	CAS1_P0	I	0/3.3 V DC	FS1: On/Off
	32	CAS1_LIFT_UP	I	0/3.3 V DC	LS1: On/Off
	33	GND	-	-	Ground
	34	CAS1_EMPTY	I	0/3.3 V DC	PS1: On/Off
	35	PICK_SOL1_RET	O	0/24 V DC	PUSOL1: On/Off (RET)
	36	PICK_SOL1_REM	O	0/24 V DC	PUSOL1: On/Off (ACT)
	37	CAS2_P0	I	0/3.3 V DC	FS2: On/Off
	38	CAS2_LIFT_UP	I	0/3.3 V DC	LS2: On/Off
	39	CAS2_EMPTY	I	0/3.3 V DC	PS2: On/Off
	40	PICK_SOL2_RET	O	0/24 V DC	PUSOL2: On/Off (RET)
	41	PICK_SOL2_REM	O	0/24 V DC	PUSOL2: On/Off (ACT)
	42	GND	-	-	Ground
	43	REG_SENS	I	0/3.3 V DC	RS: On/Off
	44	FEED1_SENS	I	0/3.3 V DC	PCS: On/Off
	45	BEND_SENS	I	0/3.3 V DC	RDS: On/Off
	46	MID_MOT_PH	O	0/3.3 V DC	MM control signal
	47	MID_MOT_REM(ROL_CL)	O	0/3.3 V DC	MM/MCL: On/Off
	48	MID_MOT_CLK	O	0/3.3 V DC (pulse)	MM clock signal
	49	MID_MOT_PD	O	0/3.3 V DC	MM control signal
	50	ASIST_CL1	O	0/24 V DC	ASCL1: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC5	1	GND	-	-	Ground
Connected to feed PWB 1	2	M_TEMP	-	-	Not used
	3	LOOP_SENS	I	0/3.3 V DC	LPS: On/Off
	4	GND	-	-	Ground
	5	EDGE_FAN_H	O	0/24 V DC	FUFM: On/Off
	6	DU1_MOT_PD	O	0/3.3 V DC	DUM1 control signal
	7	DU1_MOT_CLK	O	0/3.3 V DC (pulse)	DUM1 clock signal
	8	DU1_MOT_REM(CL_H)	O	0/3.3 V DC	DUM1/DUCL1: On/Off
	9	GND	-	-	Ground
	10	EXIT_FAN	O	0/24 V DC	EFM: On/Off
	11	DU_ENTER_SENS	I	0/3.3 V DC	DUS1: On/Off
	12	TCON_SET	-	-	Not used
	13	GND	-	-	Ground
	14	TRANS_MOT_REM	O	0/3.3 V DC	TRCM: On/Off
	15	TRANS_MOT_CLK	O	0/3.3 V DC (pulse)	TRCM clock signal
	16	TRANS_MOT_READY	I	0/3.3 V DC	TRCM ready signal
	17	TRANS_MOT_DIR	O	0/3.3 V DC	TRCM drive switch signal
	18	TRANS_MOT_BREAK	O	0/3.3 V DC	TRCM break signal
	19	GND	-	-	Ground
	20	DRM_MOT_BK_REM	-	-	Not used
	21	DRM_MOT_BK_RDY	-	-	Not used
	22	DRM_MOT_BK_DIR	-	-	Not used
	23	DRM_MOT_BK_BREAK	-	-	Not used
	24	GND	-	-	Ground
	25	DLP_MOT_BK_REM	-	-	Not used
	26	DLP_MOT_BK_CLK	-	-	Not used
	27	DLP_MOT_BK_RDY	-	-	Not used

Connector	Pin	Signal	I/O	Voltage	Description
YC5	28	DLP_MOT_BK_DIR	-	-	Not used
Connected to feed PWB 1	29	GND	-	-	Ground
	30	DRM_MOT_CLR_REM	-	-	Not used
	31	DRM_MOT_BK_CLR_CLK	-	-	Not used
	32	DRM_MOT_CLR_RDY	-	-	Not used
	33	DRM_MOT_CLR_DIR	-	-	Not used
	34	GND	-	-	Ground
	35	DLP_MOT_CLR_REM	-	-	Not used
	36	DLP_MOT_CLR_CLK	-	-	Not used
	37	DLP_MOT_CLR_RDY	-	-	Not used
	38	DLP_MOT_CLR_DIR	-	-	Not used
	39	GND	-	-	Ground
	40	REG_MOT_PD	O	0/3.3 V DC	RM control signal
	41	REG_MOT_CLK	O	0/3.3 V DC (pulse)	RM clock signal
	42	REG_MOT_REM(CL)	O	0/3.3 V DC	RM/RCL: On/Off
	43	GND	-	-	Ground
	44	IH_PWB_FAN_L	O	0/24 V DC	IHFM: On/Off
	45	IH_PWB_FAN_H	O	0/24 V DC	IHFM: On/Off
	46	IH_PWB_FAN_ALARM	I	0/3.3 V DC	IHFM alarm signal
	47	POWER_OFF	O	0/3.3 V DC	Power off signal
	48	DRM_HEAT_REM	-	-	Not used
	49	IH_PWB_FAN(U)_ALM	-	-	Not used
	50	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC6	1	GND	-	-	Ground
Connected to feed PWB 1	2	JOB_SET	I	0/3.3 V DC	Job separator set signal
	3	JOB_MOT_REM	O	0/3.3 V DC	JSEM: On/Off
	4	JOB_MOT_CLK	O	0/3.3 V DC (pulse)	JSEM clock signal
	5	JOB_MOT_DIR	O	0/3.3 V DC	JSEM drive switch signal
	6	JOB_OPEN_SEN S	I	0/3.3 V DC	JSOCS: On/Off
	7	JOB_SOL_REM	O	0/24 V DC	JSFSSOL: On/Off
	8	GND	-	-	Ground
	9	MAIN_HEAT_RE M	-	-	Not used
	10	SUB_HEAT_REM	-	-	Not used
	11	ZEROC	-	-	Not used
	12	FSR_RELAY	O	0/3.3 V DC	Fuser relay signal
	13	PRESS_REM	-	-	Not used
	14	EXIT_REAR_FAN _L	O	0/24 V DC	ERFM: On/Off
	15	EXIT_REAR_FAN _H	O	0/24 V DC	ERFM: On/Off
	16	GND	-	-	Ground
	17	FSR_CL_REM	-	-	Not used
	18	FSR_MOT_REM	O	0/3.3 V DC	FUM: On/Off
	19	FSR_MOT_CLK		0/3.3 V DC (pulse)	FUM clock signal
	20	FSR_MOT_RDY	O	0/3.3 V DC	FUM ready signal
	21	FSR_MOT_DIR	O	0/3.3 V DC	FUM drive switch signal
	22	FSR_MOT_BRK	O	0/3.3 V DC	FUM break signal
	23	GND	-	-	Ground
	24	MPF_TABLE	I	0/3.3 V DC	MPTSW: On/Off
	25	MPF_WID1	I	0/3.3 V DC	MPPWSW: On/Off
	26	MPF_WID2	I	0/3.3 V DC	MPPWSW: On/Off
	27	MPF_WID3	I	0/3.3 V DC	MPPWSW: On/Off
	28	MPF_LNG	I	0/3.3 V DC	MPPLSW: On/Off
	29	GND	-	-	Ground
	30	MPF_PPR_SET	I	0/3.3 V DC	MPPS: On/Off
	31	MPF_LIFT_UP	I	0/3.3 V DC	MPLS1: On/Off
	32	MPF_LIFT_DOW N	I	0/3.3 V DC	MPLS2: On/Off
	33	MPF_JAM	I	0/3.3 V DC	MPFS: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC6	34	MPF_CL	O	0/24 V DC	MPPFCL: On/Off
Connected to feed PWB 1	35	MPF_LIF2	O	0/24 V DC	MPLM: On/Off
	36	MPF_LIFT1	O	0/24 V DC	MPLM: On/Off
	37	GND	-	-	Ground
	38	TC_MOT_LOCK	-	-	Not used
	39	TC_TONER_LED	-	-	Not used
	40	TC_TONER_FUL L	-	-	Not used
	41	TC_TONER_VCO NT	-	-	Not used
	42	INTER_LOCK	-	-	Not used
	43	DU2_PD	O	0/3.3 V DC	DUM2 control signal
	44	DU2_CLK	O	0/3.3 V DC (pulse)	DUM2 clock signal
	45	DU2_REM(CL_L OW)	O	0/3.3 V DC	DUM2/DUCL2: On/Off
	46	GND	-	-	Ground
	47	DU_OPEN	I	0/3.3 V DC	DUCSW: On/Off
	48	DU_FAN	-	-	Not used
	49	PRESS_MOT_RE M1	O	0/24 V DC	TRRM: On/Off
	50	PRESS_MOT_RE M2	O	0/24 V DC	TRRM: On/Off
	51	PRESS_RLS_SE NS	I	0/3.3 V DC	TRRS: On/Off
	52	DU_SENS	I	0/3.3 V DC	DUS2: On/Off
	53	BELT_JAM_SENS	-	-	Not used
	54	GND	-	-	Ground
	55	CLN_SOL_RET	O	0/24 V DC	CLSOL: On/Off (RET)
	56	CLN_SOL_REM	O	0/24 V DC	CLSOL: On/Off (ACT)
	57	REG_SENS_R_S	I	Analog	IDS2 detection signal
	58	REG_SENS_R_P	I	Analog	IDS2 detection signal
	59	REG_R_LED	O	Analog	IDS2 control signal
	60	GND	-	-	Ground
	61	REG_SENS_F_S	I	Analog	IDS1 detection signal
	62	REG_SENS_F_P	I	Analog	IDS1 detection signal
	63	REG_F_LED	O	Analog	IDS1 control signal
	64	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC7	1	GND	-	-	Ground
Connected to front PWB	2	WTNR_SET	-	-	Not used
	3	INTER_LOCK	-	-	Not used
	4	IH_CORE_SENS	-	-	Not used
	5	IH_CORE_MOT_REM	-	-	Not used
	6	IH_CORE_CLK	-	-	Not used
	7	WTNR_LED	O	0/3.3 V DC (pulse)	WTS1 LED emitter signal
	8	IH_COIL_FAN_ALARM	I	0/3.3 V DC	FUFFM alarm signal
	9	IH_COIL_FAN_H	O	0/24 V DC	FUFFM: On/Off
	10	IH_COIL_FAN_L	O	0/24 V DC	FUFFM: On/Off
	11	EXIT_FAN	O	0/24 V DC	EFFM: On/Off
	12	CONTAIN_FAN	-	-	Not used
	13	JUNC_SOL_REM	O	0/24 V DC	FSSOL: On/Off (ACT)
	14	JUNC_SOL_RET	O	0/24 V DC	FSSOL: On/Off (RET)
	15	GND	-	-	Ground
	16	EXIT_PAPER_SENS	I	0/3.3 V DC	EFS: On/Off
	17	EXIT_FEED_SENS	I	0/3.3 V DC	SBS: On/Off
	18	SB_MOT_REM	O	0/3.3 V DC	EM: On/Off
	19	SB_MOT_PH	O	0/3.3 V DC	EM control signal
	20	SB_MOT_CLK	O	0/3.3 V DC (pulse)	EM clock signal
	21	SB_MOT_PD	O	0/3.3 V DC	EM control signal
	22	SB_MOT_DIR	O	0/3.3 V DC	EM drive switch signal
	23	GND	-	-	Ground
	24	DLP_FAN_Bk_H	O	0/24 V DC	DEVFM2: On/Off
	25	DLP_FAN_Bk_L	O	0/24 V DC	DEVFM2: On/Off
	26	DLP_FAN_CLR_H	O	0/24 V DC	DEVFM1: On/Off
	27	DLP_FAN_CLR_L	O	0/24 V DC	DEVFM1: On/Off
	28	WTNR_SET	I	Analog	WTS2 detection signal
	29	WTNR_NEAR	I	Analog	WTS2 detection signal
	30	WTNR_VCONT	O	0/3.3 V DC	WTS2 control signal
	31	GND	-	-	Ground
	32	ROT_MOT_REM	-	-	Not used
	33	ROT_MOT_CLK	-	-	Not used

Connector	Pin	Signal	I/O	Voltage	Description
YC7	34	ROT_MOT_PD	-	-	Not used
Connected to front PWB	35	ROT_MOT_DIR	-	-	Not used
	36	ROT_HP_SENS	-	-	Not used
	37	THOP_MOT_Bk_REM	-	-	Not used
	38	THOP_MOT_M_REM	-	-	Not used
	39	THOP_MOT_C_REM	-	-	Not used
	40	THOP_MOT_Y_REM	-	-	Not used
	41	GND	-	-	Ground
	42	ENCODE_Bk	-	-	Not used
	43	ENCODE_M	-	-	Not used
	44	ENCODE_C	-	-	Not used
	45	ENCODE_Y	-	-	Not used
	46	THOP_Bk	-	-	Not used
	47	THOP_M	-	-	Not used
	48	THOP_C	-	-	Not used
	49	THOP_Y	-	-	Not used
	50	GND	-	-	Ground
	YC8	1	SGND	-	-
Connected to high voltage PWB 2	2	SGND	-	-	Ground
	3	SP_CNT	O	Analog	Separation bias control voltage
	4	T2_CNT	O	Analog	Secondary transfer bias control voltage
	5	SP_REM	O	0/3.3 V DC	Separation bias: On/Off
	6	T_REM	O	0/3.3 V DC	Secondary transfer bias: On/Off
	7	FB_CNT	O	0/3.3 V DC	Primary transfer cleaning bias: On/Off
	8	T1_CNT_Bk	O	Analog	Primary transfer bias K control voltage
	9	T1_CNT_M	O	Analog	Primary transfer bias M control voltage
	10	T1_CNT_C	O	Analog	Primary transfer bias C control voltage
	11	T1_CNT_Y	O	Analog	Primary transfer bias Y control voltage
	12	T1_CLR_OFF_REM	O	0/3.3 V DC	Primary transfer control signal

Connector	Pin	Signal	I/O	Voltage	Description
YC9 Connected to motor control PWB	1	MOT_CLK	O	0/3.3 V DC (pulse)	MCPWB clock signal
	2	MOT_SDO	O	0/3.3 V DC (pulse)	MCPWB serial communication data signal
	3	MOT_SEL	O	0/3.3 V DC	MCPWB select signal
	4	MOT_SDI	I	0/3.3 V DC (pulse)	MCPWB serial communication data signal
	5	MOT_RDY	I	0/3.3 V DC	MCPWB ready signal
	6	EMERGENCY	O	0/3.3 V DC	MCPWB control signal
	7	BLT_SPEED	O	0/3.3 V DC	TBLS: On/Off
	8	BLT_INDEX	-	-	Not used
	9	DRM_INDEX_BK	O	0/3.3 V DC	DRM-K control signal
	10	DRM_INDEX_M	O	0/3.3 V DC	DRM-M control signal
	11	DRM_INDEX_C	O	0/3.3 V DC	DRM-C control signal
	12	DRM_INDEX_Y	O	0/3.3 V DC	DRM-Y control signal
	13	GND	-	-	Ground
	14	GND	-	-	Ground
	15	+5V	O	5 V DC	5 V DC power to MCPWB
	16	+5V	O	5 V DC	5 V DC power to MCPWB
	17	BLT_BRAKE	-	-	Not used
	18	BLT_VM	-	-	Not used
	19	BLT_REM	-	-	Not used
	20	MOT_DATA_SET	O	0/3.3 V DC	MCPWB control signal
	21	DRM_ON	O	0/3.3 V DC	MCPWB control signal
	22	BLT_FG	-	-	Not used
YC10 Connected to front PWB	1	GND	-	-	Ground
	2	DRM_INDEX_Bk	I	0/3.3 V DC	DRM-K control signal
	3	ERS_Bk	O	0/24 V DC	CL-K: On/Off
	4	TPD_Bk_1	I	Analog	DEVPWB-K detection signal
	5	DLP_VCONT_Bk_1	O	0/3.3 V DC	DEVPWB-K control signal
	6	TPD_TEMP_Bk	I	Analog	Developer thermistor K detection signal
	7	GND	-	-	Ground
	8	DRM_INDEX_M	I	0/3.3 V DC	DRM-M control signal
	9	ERS_M	O	0/24 V DC	CL-M: On/Off
	10	TPD_M_1	I	Analog	DEVPWB-M detection signal
	11	DLP_VCONT_M_1	O	0/3.3 V DC	DEVPWB-M control signal

Connector	Pin	Signal	I/O	Voltage	Description
YC10	12	TPD_TEMP_M	I	Analog	Developer thermistor M detection signal
Connected to front PWB	13	GND	-	-	Ground
	14	DRM_INDEX_C	I	0/3.3 V DC	DRM-C control signal
	15	ERS_C	O	0/24 V DC	CL-C: On/Off
	16	TPD_C_1	I	Analog	DEVPWB-C detection signal
	17	DLP_VCONT_C_1	O	0/3.3 V DC	DEVPWB-C control signal
	18	TPD_TEMP_C	I	Analog	Developer thermistor C detection signal
	19	GND	-	-	Ground
	20	TN_CLK	O	0/3.3 V DC (pulse)	Clock signal
	21	GND	-	-	Ground
	22	EEP_SCL1	O	0/3.3 V DC (pulse)	EEPROM clock signal
	23	GND	-	-	Ground
	24	EEP_SDA1	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	25	GND	-	-	Ground
	26	TPD_Y_1	I	Analog	DEVPWB-Y detection signal
	27	DLP_VCONT_Y_1	O	0/3.3 V DC	DEVPWB-Y control signal
	28	TPD_TEMP_Y	I	Analog	Developer thermistor Y detection signal
	29	ERS_Y	O	0/24 V DC	CL-Y: On/Off
	30	DRM_INDEX_Y	I	0/3.3 V DC	DRM-Y control signal
	31	FRONT_OPEN	I	0/3.3 V DC	FRCSW: On/Off
	32	GND	-	-	Ground
	33	I2C_SCL	O	0/3.3 V DC (pulse)	EEPROM clock signal
	34	GND	-	-	Ground
	35	I2C_SDA	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	36	GND	-	-	Ground
	37	LSU_FAN_REM	O	0/24 V DC	LSUFM: On/Off
	38	CLEAN_MOT_LOCK	I	0/3.3 V DC	WTM lock signal
	39	CLEAN_MOT_REM	O	0/24 V DC	WTM: On/Off
	40	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC11	1	SGND	-	-	Ground
Connected to LSU relay PWB	2	DATA_2PBK(LVD S)	O	0/3.3 V DC (pulse)	Video data signal K (P)
	3	DATA_2NBK(LVD S)	O	0/3.3 V DC (pulse)	Video data signal K (N)
	4	SGND	-	-	Ground
	5	GAIN_FIX_BK	O	0/3.3 V DC	APCPWB-K control signal
	6	PARA_SIG_P2_B K	O	0/3.3 V DC	APCPWB-K control signal
	7	PARA_SIG_P1_B K	O	0/3.3 V DC	APCPWB-K control signal
	8	PARA_SIG_P0_B K	O	0/3.3 V DC	APCPWB-K control signal
	9	INT_ST_1_BK	O	0/3.3 V DC	APCPWB-K control signal
	10	INT_ST_2_BK	O	0/3.3 V DC	APCPWB-K control signal
	11	PARA_SIG_P3_2 BK	O	0/3.3 V DC	APCPWB-K control signal
	12	SGND	-	-	Ground
	13	DATA_4PBK(LVD S)	O	0/3.3 V DC (pulse)	Video data signal K (P)
	14	DATA_4NBK(LVD S)	O	0/3.3 V DC (pulse)	Video data signal K (N)
	15	SGND	-	-	Ground
	16	DATA_3PBK(LVD S)	O	0/3.3 V DC (pulse)	Video data signal K (P)
	17	DATA_3NBK(LVD S)	O	0/3.3 V DC (pulse)	Video data signal K (N)
	18	SGND	-	-	Ground
	19	DATA_2P_M(LVD S)	O	0/3.3 V DC (pulse)	Video data signal M (P)
	20	DATA_2N_M(LVD S)	O	0/3.3 V DC (pulse)	Video data signal M (N)
	21	SGND	-	-	Ground
	22	GAIN_FIX_M	O	0/3.3 V DC	APCPWB-M control signal
	23	PALA_STG_P2_M	O	0/3.3 V DC	APCPWB-M control signal
	24	PALA_STG_P1_M	O	0/3.3 V DC	APCPWB-M control signal
	25	PALA_STG_P0_M	O	0/3.3 V DC	APCPWB-M control signal
	26	INT_ST_M	O	0/3.3 V DC	APCPWB-M control signal
	27	SGND	-	-	Ground
	28	DATA_2P_C(LVD S)	O	0/3.3 V DC (pulse)	Video data signal C (P)

Connector	Pin	Signal	I/O	Voltage	Description
YC11	29	DATA_2N_C(LVDS)	O	0/3.3 V DC (pulse)	Video data signal C (N)
Connected to LSU relay PWB	30	SGND	-	-	Ground
	31	GAIN_FIX_C	O	0/3.3 V DC	APCPWB-C control signal
	32	PALA_STG_P2_C	O	0/3.3 V DC	APCPWB-C control signal
	33	PALA_STG_P1_C	O	0/3.3 V DC	APCPWB-C control signal
	34	PALA_STG_P0_C	O	0/3.3 V DC	APCPWB-C control signal
	35	INT_ST_C	O	0/3.3 V DC	APCPWB-C control signal
	36	SGND	-	-	Ground
	37	DATA_2P_Y(LVDS)	O	0/3.3 V DC (pulse)	Video data signal Y (P)
	38	DATA_2N_Y(LVDS)	O	0/3.3 V DC (pulse)	Video data signal Y (N)
	39	SGND	-	-	Ground
	40	GAIN_FIX_Y	O	0/3.3 V DC	APCPWB-Y control signal
	41	PALA_STG_P2_Y	O	0/3.3 V DC	APCPWB-Y control signal
	42	PALA_STG_P1_Y	O	0/3.3 V DC	APCPWB-Y control signal
	43	PALA_STG_P0_Y	O	0/3.3 V DC	APCPWB-Y control signal
	44	INT_ST_Y	O	0/3.3 V DC	APCPWB-Y control signal
	45	SGND	-	-	Ground
	46	EEPROM_CS_1_BK	I/O	0/3.3 V DC (pulse)	APCPWB-K EEPROM data signal
	47	IDD_CS_1_BK	O	0/3.3 V DC	APCPWB-K control signal
	48	EEPROM_CS_2_BK	I/O	0/3.3 V DC (pulse)	APCPWB-K EEPROM data signal
	49	IDD_CS_2_BK	O	0/3.3 V DC	APCPWB-K control signal
	50	EEPROM_CS_M	I/O	0/3.3 V DC (pulse)	APCPWB-M EEPROM data signal
	51	IDD_CS_M	O	0/3.3 V DC	APCPWB-M control signal
	52	EEPROM_CS_C	I/O	0/3.3 V DC (pulse)	APCPWB-C EEPROM data signal
	53	IDD_CS_C	O	0/3.3 V DC	APCPWB-C control signal
	54	EEPROM_CS_Y	I/O	0/3.3 V DC (pulse)	APCPWB-Y EEPROM data signal
	55	IDD_CS_Y	O	0/3.3 V DC	APCPWB-Y control signal
	56	SGND	-	-	Ground
	57	MSET_N	O	0/3.3 V DC	Control signal
	58	SGND	-	-	Ground
	59	SDO	O	0/3.3 V DC (pulse)	Serial communication data signal
60	SGND	-	-	Ground	

Connector	Pin	Signal	I/O	Voltage	Description	
YC11	61	SDI	I	0/3.3 V DC (pulse)	Serial communication data signal	
	Connected to LSU relay PWB	62	SGND	-	-	Ground
		63	CLK	O	0/3.3 V DC (pulse)	Clock signal
		64	SGND	-	-	Ground
YC12	1	CLK_BK	O	0/3.3 V DC (pulse)	PM-K clock signal	
	Connected to LSU relay PWB	2	LOCK_BK	I	0/3.3 V DC	PM-K lock signal
		3	REM_BK	O	0/24 V DC	PM-K: On/Off
		4	SGND	-	-	Ground
		5	DATA_1PBK(LVDS)	O	0/3.3 V DC (pulse)	Video data signal K (P)
		6	DATA_1NBK(LVDS)	O	0/3.3 V DC (pulse)	Video data signal K (N)
		7	SGND	-	-	Ground
		8	SDCLK_BK	O	0/3.3 V DC (pulse)	APCPWB-K clock signal
		9	SGND	-	-	Ground
		10	PARA_SIG_P4_BK	O	0/3.3 V DC	APCPWB-K control signal
		11	PARA_SIG_P3_BK	O	0/3.3 V DC	APCPWB-K control signal
		12	CUALM_BK	I	0/3.3 V DC	APCPWB-K alarm signal
		13	LSU_TH_BK	I	Analog	LSU thermistor K detection signal
		14	BD_BK	I	0/3.3 V DC (pulse)	Horizontal synchronization signal K
		15	SGND	-	-	Ground
		16	CLK_M	O	0/3.3 V DC (pulse)	PM-M clock signal
		17	LOCK_M	I	0/3.3 V DC	PM-M lock signal
		18	REM_M	O	0/24 V DC	PM-M: On/Off
		19	SGND	-	-	Ground
		20	DATA_1P_M(LVDS)	O	0/3.3 V DC (pulse)	Video data signal M (P)
		21	DATA_1N_M(LVDS)	O	0/3.3 V DC (pulse)	Video data signal M (N)
		22	SGND	-	-	Ground
		23	SDCLK_M	O	0/3.3 V DC (pulse)	APCPWB-M clock signal
		24	SGND	-	-	Ground
		25	PARA_SIG_P4_M	O	0/3.3 V DC	APCPWB-M control signal
		26	PARA_SIG_P3_M	O	0/3.3 V DC	APCPWB-M control signal
		27	CUALM_M	I	0/3.3 V DC	APCPWB-M alarm signal
		28	LSU_TH_M	I	Analog	LSU thermistor M detection signal

Connector	Pin	Signal	I/O	Voltage	Description
YC12	29	BD_M	I	0/3.3 V DC (pulse)	Horizontal synchronization signal M
Connected to LSU relay PWB	30	SGND	-	-	Ground
	31	CLK_C	O	0/3.3 V DC (pulse)	PM-C clock signal
	32	LOCK_C	I	0/3.3 V DC	PM-C lock signal
	33	REM_C	O	0/24 V DC	PM-C: On/Off
	34	SGND	-	-	Ground
	35	DATA_1P_C(LVDS)	O	0/3.3 V DC (pulse)	Video data signal C (P)
	36	DATA_1N_C(LVDS)	O	0/3.3 V DC (pulse)	Video data signal C (N)
	37	SGND	-	-	Ground
	38	SDCLK_C	O	0/3.3 V DC (pulse)	APCPWB-C clock signal
	39	SGND	-	-	Ground
	40	PARA_SIG_P4_C	O	0/3.3 V DC	APCPWB-C control signal
	41	PARA_SIG_P3_C	O	0/3.3 V DC	APCPWB-C control signal
	42	CUALM_C	I	0/3.3 V DC	APCPWB-C alarm signal
	43	LSU_TH_C	I	Analog	LSU thermistor C detection signal
	44	BD_C	I	0/3.3 V DC (pulse)	Horizontal synchronization signal C
	45	SGND	-	-	Ground
	46	CLK_Y	O	0/3.3 V DC (pulse)	PM-Y clock signal
	47	LOCK_Y	I	0/3.3 V DC	PM-Y lock signal
	48	REM_Y	O	0/24 V DC	PM-Y: On/Off
	49	SGND	-	-	Ground
	50	DATA_1P_Y(LVDS)	O	0/3.3 V DC (pulse)	Video data signal Y (P)
	51	DATA_1N_Y(LVDS)	O	0/3.3 V DC (pulse)	Video data signal Y (N)
	52	SGND	-	-	Ground
	53	SDCLK_Y	O	0/3.3 V DC (pulse)	APCPWB-Y clock signal
	54	SGND	-	-	Ground
	55	PARA_SIG_P4_Y	O	0/3.3 V DC	APCPWB-Y control signal
	56	PARA_SIG_P3_Y	O	0/3.3 V DC	APCPWB-Y control signal
	57	CUALM_Y	I	0/3.3 V DC	APCPWB-Y alarm signal
	58	LSU_TH_Y	I	Analog	LSU thermistor Y detection signal
	59	BD_Y	I	0/3.3 V DC (pulse)	Horizontal synchronization signal Y
	60	SGND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC13 Connected to feed PWB 1	1	GND	-	-	Ground
	2	GND	-	-	Ground
	3	3.3V3	I	3.3 V DC	3.3 V DC power from FPWB1
	4	3.3V2	I	3.3 V DC	3.3 V DC power from FPWB1
YC16 Connected to high voltage PWB 1	1	SGND	-	-	Ground
	2	AC_MAIN_CLK	O	0/3.3 V DC (pulse)	AC charger roller Y clock signal
	3	DC_MAIN_REM	O	0/3.3 V DC	DC main charger Y: On/Off
	4	DC_MAIN_CNT_Y	O	PWM	DC charger roller Y control signal
	5	MAIN_IDC_Y	O	PWM	DC charger roller Y control signal
	6	AC_SLV_CLK_Y	O	0/3.3 V DC (pulse)	AC sleeve bias Y clock signal
	7	DC_SLV_CNT_Y	O	PWM	DC sleeve bias Y control voltage
	8	DC_MAG_CNT_Y	O	PWM	DC magnet bias Y control voltage
	9	AC_SLV_CNT_Y	O	PWM	AC sleeve bias Y control voltage
	10	AC_MAIN_CNT_Y	O	PWM	AC charger roller Y control signal
	11	DISCHARGE_Y	I	PWM	Main charger Y control signal
	12	AC_MAG_CNT_Y	O	0/3.3 V DC (pulse)	AC magnet bias Y control voltage
	13	AC_MAG_CLK_Y	O	0/3.3 V DC (pulse)	AC magnet bias Y clock signal
	14	DC_REC_CNT	O	PWM	DC bias Y control voltage
	15	N.C	-	-	Not used
	16	DC_REC_REM	O	PWM	DC bias C control voltage
	17	AC_MAG_CLK_C	O	0/3.3 V DC (pulse)	AC magnet bias C clock signal
	18	AC_MAG_CNT_C	O	0/3.3 V DC (pulse)	AC magnet bias C control voltage
	19	DISCHARGE_C	I	PWM	Main charger C control signal
	20	AC_MAIN_CNT_C	O	PWM	AC charger roller C control signal
	21	AC_SLV_CNT_C	O	PWM	AC sleeve bias C control voltage
	22	DC_MAG_CNT_C	O	PWM	DC magnet bias C control voltage
	23	DC_SLV_CNT_C	O	PWM	DC sleeve bias C control voltage
	24	AC_SLV_CLK_C	O	0/3.3 V DC (pulse)	AC sleeve bias C clock signal
	25	DC_MAG_REM	O	0/3.3 V DC	DC main charger C: On/Off
	26	MAIN_IDC_C	O	PWM	DC charger roller C control signal
	27	DC_MAIN_CNT_C	O	PWM	DC charger roller C control signal
	28	SGND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC17	1	SGND	-	-	Ground
Connected to high voltage PWB 1	2	DC_MAIN_CNT_M	O	PWM	DC charger roller Y control signal
	3	MAIN_IDC_M	O	PWM	DC charger roller M control signal
	4	AC_SLV_CLK_M	O	0/3.3 V DC (pulse)	AC sleeve bias M clock signal
	5	DC_SLV_CNT_M	O	PWM	DC sleeve bias M control voltage
	6	DC_MAG_CNT_M	O	PWM	DC magnet bias M control voltage
	7	AC_SLV_CNT_M	O	PWM	AC sleeve bias M control voltage
	8	AC_MAIN_CNT_M	O	PWM	AC charger roller M control signal
	9	DISCHARGE_M	I	PWM	Main charger M control signal
	10	AC_MAG_CNT_M	O	0/3.3 V DC (pulse)	AC magnet bias M control voltage
	11	AC_MAG_CLK_M	O	0/3.3 V DC (pulse)	AC magnet bias M clock signal
	12	AC_MAG_CLK_Bk	O	PWM	DC charger roller K control signal
	13	AC_MAG_CNT_Bk	O	PWM	DC charger roller K control signal
	14	DISCHARGE_Bk	I	PWM	Main charger K control signal
	15	AC_SLV_CNT_Bk	O	0/3.3 V DC (pulse)	AC sleeve bias K clock signal
	16	DC_MAG_CNT_Bk	O	PWM	DC sleeve bias K control voltage
	17	DC_SLV_CNT_Bk	O	PWM	DC magnet bias K control voltage
	18	AC_SLV_CLK_Bk	O	PWM	AC sleeve bias K control voltage
	19	AC_MAIN_CNT_Bk	O	PWM	AC charger roller K control signal
	20	MAIN_IDC_Bk	O	PWM	DC charger roller K control signal
	21	DC_MAIN_CNT_Bk	O	PWM	DC charger roller K control signal
22	SGND	-	-	Ground	
YC18	1	DF_CLK	O	0/3.3 V DC (pulse)	DFMPWB clock signal
Connected to 1000-sheet/4000-sheet finisher	2	DF_SDO	O	0/3.3 V DC (pulse)	DFMPWB serial communication data signal
	3	DF_SEL	O	0/3.3 V DC	DFMPWB select signal
	4	DF_SDI	O	0/3.3 V DC (pulse)	DFMPWB serial communication data signal
	5	DF_RDY	I	0/3.3 V DC	DFMPWB ready signal
	6	DF_DET	O	0/3.3 V DC	DFMPWB detection signal
	7	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC19 Connected to paper feeder/ large capac- ity feeder, toner fan motor 1/2, belt fan motor 1/2 and exhaust fan motor 1/2	A1	PF_CLK	O	0/3.3 V DC (pulse)	PFMPWB clock signal
	A2	PF_SDO	O	0/3.3 V DC (pulse)	PFMPWB serial communication data signal
	A3	PF_SEL	O	0/3.3 V DC	PFMPWB select signal
	A4	PF_SDI	I	0/3.3 V DC (pulse)	PFMPWB serial communication data signal
	A5	PF_RDY	I	0/3.3 V DC	PFMPWB ready signal
	A6	PF_PAUSE	O	0/3.3 V DC	PFMPWB pause signal
	A7	PF_CAS1_OPEN	I	0/3.3 V DC	PFMPWB control signal
	A8	PF_CAS2_OPEN	I	0/3.3 V DC	PFMPWB control signal
	A9	+3.3V4	O	3.3 V DC	3.3 V DC power to PFMPWB
	A10	GND	-	-	Ground
	A11	GND	-	-	Ground
	A12	TN_FAN1	O	0/24 V DC	TFM1: On/Off
	A13	+24V1	O	24 V DC	24 V DC power to TFM1
	A14	TN_FAN2	O	0/24 V DC	TFM2: On/Off
	A15	+24V1	O	24 V DC	24 V DC power to TFM2
	A16	LVU_FAN1	-	-	Not used
	A17	+24V1	-	-	Not used
	A18	LVU_FAN2	-	-	Not used
	A19	+24V1	-	-	Not used
	B1	SIDE_CLK	O	0/3.3 V DC (pulse)	PFMPWB clock signal (side)
	B2	SIDE_SDO	O	0/3.3 V DC (pulse)	PFMPWB serial communication data signal (side)
	B3	SIDE_SEL	O	0/3.3 V DC	PFMPWB select signal (side)
	B4	SIDE_SDI	I	0/3.3 V DC (pulse)	PFMPWB serial communication data signal (side)
	B5	SIDE_RDY	I	0/3.3 V DC	PFMPWB ready signal (side)
B6	SIDE_PAUSE	O	0/3.3 V DC	PFMPWB pause signal (side)	
B7	TANDEM_CAS1O PEN	I	0/3.3 V DC	PFMPWB control signal (side)	
B8	TANDEM_CAS2O PEN	I	0/3.3 V DC	PFMPWB control signal (side)	
B9	SIDE_MULTI_OP EN	O	0/3.3 V DC	PFMPWB control signal (side)	
B10	+3.3V4	O	3.3 V DC	3.3 V DC power to PFMPWB (side)	
B11	GND	-	-	Ground	
B12	+24V1	O	24 V DC	24 V DC power to BLFM1	

Connector	Pin	Signal	I/O	Voltage	Description
YC19 Connected to paper feeder/ large capacity feeder, toner fan motor 1/2, belt fan motor 1/2 and exhaust fan motor 1/2	B13	BELT_FAN1	O	0/24 V DC	BLFM1: On/Off
	B14	+24V1	O	24 V DC	24 V DC power to BLFM2
	B15	BELT_FAN2	O	0/24 V DC	BLFM2: On/Off
	B16	DLP_FAN1	O	0/24 V DC	EXFM1: On/Off
	B17	+24V1	O	24 V DC	24 V DC power to EXFM1
	B18	DLP_FAN2	O	0/24 V DC	EXFM2: On/Off
	B19	+24V1	O	24 V DC	24 V DC power to EXFM2
YC20 Connected to bridge unit	1	DECAL_HP_SEN S	-	-	Not used
	2	GUIDE_REM	-	-	Not used
	3	GUIDE_CLK	-	-	Not used
	4	GUIDE_PD	-	-	Not used
	5	GUIDE_DIR	-	-	Not used
	6	DECAL_REM	-	-	Not used
	7	DECAL_PH	-	-	Not used
	8	DECAL_CLK	-	-	Not used
	9	DECAL_PD	-	-	Not used
	10	DECAL_DIR	-	-	Not used
	11	+24V1	O	24 V DC	24 V DC power to BRSOL
	12	EXIT_SOL_REM	O	0/24 V DC	BRSOL: On/Off (ACT)
	13	EXIT_SOL_RET	O	0/24 V DC	BRSOL: On/Off (RET)
	14	GND	-	-	Ground
	15	EXIT_COV_OPE N	I	0/3.3 V DC	BRECSW: On/Off
	16	GND	-	-	Ground
	17	EXIT_SENS	I	0/3.3 V DC	BRES: On/Off
	18	+5V	O	5 V DC	5 V DC power to BRES
	19	N.C	-	-	Not used
	20	BRIDGE2 REM	O	0/3.3 V DC	BRCM2: On/Off
	21	BRIDGE2 PH	O	0/3.3 V DC	BRCM2 control signal
	22	BRIDGE2 CLK	O	0/3.3 V DC (pulse)	BRCM2 clock signal
	23	BRIDGE2 PD	O	0/3.3 V DC	BRCM2 control signal
	24	BRIDGE2 DIR	O	0/3.3 V DC	BRCM2 drive switch signal
	25	BRIDGE1 REM	O	0/3.3 V DC	BRCM2: On/Off
	26	BRIDGE1 PH	O	0/3.3 V DC	BRCM1 control signal

Connector	Pin	Signal	I/O	Voltage	Description
YC20 Connected to bridge unit	27	BRIDGE1 CLK	O	0/3.3 V DC (pulse)	BRCM1 clock signal
	28	BRIDGE1 PD	O	0/3.3 V DC	BRCM1 control signal
	29	BRIDGE1 DIR	O	0/3.3 V DC	BRCM1 drive switch signal
	30	BRIDGE_SENS 2	I	0/3.3 V DC	BRCS2: On/Off
	31	BRIDGE_OPEN	I	0/3.3 V DC	BRCSW: On/Off
	32	BRIDGE_SENS 1	I	0/3.3 V DC	BRCS1: On/Off
	33	GND	-	-	Ground
	34	5V	O	5 V DC	5 V DC power to BRPWB
	35	GND	-	-	Ground
	36	GND	-	-	Ground
	37	+24V1	O	24 V DC	24 V DC power to BRPWB
	38	+24V1	O	24 V DC	24 V DC power to BRPWB
	YC22 Connected to power source fan motor	1	LVU_FAN	O	0/24 V DC
2		+24V1	O	24 V DC	24 V DC power to PSFM
YC23 Connected to coin vender	1	+24V	O	24 V DC	24 V DC power to coin vender
	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	COIN_EN	I	0/3.3 V DC	Coin vender enable signal
	5	FGND	-	-	Ground
	6	FEED_COUNT	O	0/3.3 V DC	Coin vender control signal
	7	EJECT_COUNT	O	0/3.3 V DC	Coin vender control signal
	8	COPYING_SIG	O	0/3.3 V DC	Coin vender control signal
	9	TXD_COIN	O	0/3.3 V DC (pulse)	Serial communication data signal
	10	GND	-	-	Serial communication data signal
	11	RXD_COIN	I	0/3.3 V DC (pulse)	MCL: On/Off
	12	GND	-	-	Ground
YC24 Connected to key counter	1	GND	-	-	Ground
	2	DC1_SET	I	0/3.3 V DC	Key counter set signal
	3	DC1_COUNT	O	0/3.3 V DC	Key counter count signal
	4	+24V 1	O	24 V DC	24 V DC power to key card

Connector	Pin	Signal	I/O	Voltage	Description
YC25 Connected to key card	A1	+5V	O	5 V DC	5 V DC power to key card
	A2	+5V	O	5 V DC	5 V DC power to key card
	A3	+5V	O	5 V DC	5 V DC power to key card
	A4	+5V	O	5 V DC	5 V DC power to key card
	A5	+5V	O	5 V DC	5 V DC power to key card
	A6	+5V	O	5 V DC	5 V DC power to key card
	A7	+5V	O	5 V DC	5 V DC power to key card
	A8	+5V	O	5 V DC	5 V DC power to key card
	A9	COPY_ENABLE	I	0/3.3 V DC	Key card enable signal
	A10	+24V	O	24 V DC	24 V DC power to key card
	B1	KEY7	O	0/3.3 V DC	Key card control signal
	B2	KEY6	O	0/3.3 V DC	Key card control signal
	B3	KEY5	O	0/3.3 V DC	Key card control signal
	B4	KEY4	O	0/3.3 V DC	Key card control signal
	B5	KEY3	O	0/3.3 V DC	Key card control signal
	B6	KEY2	O	0/3.3 V DC	Key card control signal
	B7	KEY1	O	0/3.3 V DC	Key card control signal
	B8	KEY0	O	0/3.3 V DC	Key card control signal
	B9	GND	-	-	Ground
	B10	COUNT	O	0/3.3 V DC	Key card count signal
YC26 Connected to fuser unit and fuser IH PWB	A1	EDGE_FAN_ALM	I	0/3.3 V DC	FUEFM2 alarm signal
	A2	EDGE_FAN	O	0/24 V DC	FUEFM2: On/Off
	A3	+24V1	O	24 V DC	24 V DC power to FUEFM2
	A4	EDGE_FAN_ALM	I	0/3.3 V DC	FUEFM1 alarm signal
	A5	EDGE_FAN	O	0/24 V DC	FUEFM1: On/Off
	A6	+24V1	O	24 V DC	24 V DC power to FUEFM1
	A7	FSR_FAN_ALM	I	0/3.3 V DC	FURFM alarm signal
	A8	FSR_FAN	O	0/24 V DC	FURFM: On/Off
	A9	+24V1	O	24 V DC	24 V DC power to FURFM
	A10	FSR_RLS_DR_C CW	O	0/24 V DC	FURM: On/Off (CCW)
	A11	FSR_RLS_DR_C W	O	0/24 V DC	FURM: On/Off (CW)
	A12	GND	-	-	Ground
	A13	FSR_SIZE_SENS	I	0/3.3 V DC	FUES: On/Off
	A14	+5V	O	5 V DC	5 V DC power to FUES
	A15	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC26 Connected to fuser unit and fuser IH PWB	A16	FSR_RLS_SENS	I	0/3.3 V DC	FURS: On/Off
	A17	+5V	O	5 V DC	5 V DC power to FURS
	A18	GND	-	-	Ground
	A19	FSR_BLT_PLS	I	0/3.3 V DC	FUBLS: On/Off
	A20	+5V	O	5 V DC	5 V DC power to FUBLS
	B1	PRESS_HEART_REM	-	-	Not used
	B2	IH_RXD	I	0/3.3 V DC (pulse)	Serial communication data signal
	B3	IH_TXD	O	0/3.3 V DC (pulse)	Serial communication data signal
	B4	ROTATION	O	0/3.3 V DC	FIH control signal
	B5	IH_HEAT_REM	O	0/3.3 V DC	FIH: On/Off
	B6	+3.3V2	O	3.3 V DC	5 V DC power to FIH
	B7	GND	-	-	Ground
	B8	GND	-	-	Ground
	B9	PRESS_TH	I	Analog	FTH4 detection signal
	B10	GND	-	-	Ground
	B11	EDGE_TH	I	Analog	FTH2 detection signal
	B12	GND	-	-	Ground
	B13	GUIDE_TH1	-	-	Not used
	B14	GND	-	-	Ground
	B15	GUIDE_TH2	I	Analog	FTH3 detection signal
B16	MAIN_TH2	I	Analog	FTH1 detection signal	
B17	MAIN_TH1	I	Analog	FTH1 detection signal	
B18	GND	-	-	Ground	
B19	+24V1	O	24 V DC	24 V DC power to BRFM	
B20	BRIDGE_FAN	O	0/24 V DC	BRFM: On/Off	
YC27 Connected to RFID PWB, toner motor K/M/C/Y and screw sen- sor K/M/C/Y	1	EEP_SDA2	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	2	GND	-	-	Ground
	3	EEP_SCL2	I	0/3.3 V DC (pulse)	EEPROM clock signal
	4	3.3V2	O	3.3 V DC	3.3 V DC power to RFPWB
	5	+24V1	O	24 V DC	24 V DC power to TM-Y
	6	TMOT_Y_DR	O	0/24 V DC	TM-Y: On/Off
	7	+24V1	O	24 V DC	24 V DC power to TM-C
	8	TMOT_C_DR	O	0/24 V DC	TM-C: On/Off
	9	+24V1	O	24 V DC	24 V DC power to TM-M
	10	TMOT_M_DR	O	0/24 V DC	TM-M: On/Off
	11	+24V1	I	24 V DC	24 V DC power to TM-K

Connector	Pin	Signal	I/O	Voltage	Description
YC27 Connected to RFID PWB, toner motor K/M/C/Y and screw sen- sor K/M/C/Y	12	TMOT_Bk_DR	O	0/24 V DC	TM-K: On/Off
	13	GND	-	-	Ground
	14	ENCODE_Y	I	0/3.3 V DC	SRS-Y: On/Off
	15	+5V	O	5 V DC	24 V DC power to SRS-Y
	16	GND	-	-	Ground
	17	ENCODE_C	I	0/3.3 V DC	SRS-C: On/Off
	18	+5V	O	5 V DC	24 V DC power to SRS-C
	19	GND	-	-	Ground
	20	ENCODE_M	I	0/3.3 V DC	SRS-M: On/Off
	21	+5V	O	5 V DC	24 V DC power to SRS-M
	22	GND	-	-	Ground
	23	ENCODE_K	I	0/3.3 V DC	SRS-K: On/Off
	24	+5V	O	5 V DC	24 V DC power to SRS-K
YC46 Connected to main PWB	1	HSYNC_AN	I	0/3.3 V DC (pulse)	Image control signal
	2	HSYNC_AP	I	0/3.3 V DC (pulse)	Image control signal
	3	HSYNC_BN	I	0/3.3 V DC (pulse)	Image control signal
	4	HSYNC_BP	I	0/3.3 V DC (pulse)	Image control signal
	5	HSYNC_CN	I	0/3.3 V DC (pulse)	Image control signal
	6	HSYNC_CP	I	0/3.3 V DC (pulse)	Image control signal
	7	HSYNC_DN	I	0/3.3 V DC (pulse)	Image control signal
	8	HSYNC_DP	I	0/3.3 V DC (pulse)	Image control signal
	9	VSYNC_AN	I	0/3.3 V DC (pulse)	Image control signal
	10	VSYNC_AP	I	0/3.3 V DC (pulse)	Image control signal
	11	VSYNC_BN	I	0/3.3 V DC (pulse)	Image control signal
	12	VSYNC_BP	I	0/3.3 V DC (pulse)	Image control signal
	13	VSYNC_CN	I	0/3.3 V DC (pulse)	Image control signal
	14	VSYNC_CP	I	0/3.3 V DC (pulse)	Image control signal
	15	VSYNC_DN	I	0/3.3 V DC (pulse)	Image control signal
	16	VSYNC_DP	I	0/3.3 V DC (pulse)	Image control signal
	17	SGND	-	-	Ground
	18	TCLKP	I	0/3.3 V DC (pulse)	Clock signal
	19	TCLKN	I	0/3.3 V DC (pulse)	Clock signal
	20	SGND	-	-	Ground
	21	TCP	I	0/3.3 V DC (pulse)	Image control signal
	22	TCN	I	0/3.3 V DC (pulse)	Image control signal
	23	SGND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC46	24	TBP	I	0/3.3 V DC (pulse)	Image control signal
Connected to main PWB	25	TBN	I	0/3.3 V DC (pulse)	Image control signal
	26	SGND	-	-	Ground
	27	TAP	I	0/3.3 V DC (pulse)	Image control signal
	28	TAN	I	0/3.3 V DC (pulse)	Image control signal
	29	SGND	-	-	Ground
	30	SLEEP	I	0/3.3 V DC	Sleep signal
	31	HLD_ENG	I	0/3.3 V DC	Engine hold signal
	32	NC	-	-	Not used
	33	SGND	-	-	Ground
	34	EG IRN	I	0/3.3 V DC	Engine interrupt signal
	35	EG SO	O	0/3.3 V DC (pulse)	Serial communication data signal
	36	EG SBSY	I	0/3.3 V DC	Engine busy signal
	37	EG SDIR	I	0/3.3 V DC	Engine communication direction signal
	38	EG_SI	I	0/3.3 V DC (pulse)	Serial communication data signal
	39	EG_SCLK	I	0/3.3 V DC (pulse)	Engine lock signal
	40	SGND	-	-	Ground
	YC47	1	NC	-	-
Connected to fiery relay PWB	2	NC	-	-	Not used
	3	NC	-	-	Not used
	4	NC	-	-	Not used
	5	NC	-	-	Not used
	6	NC	-	-	Not used
	7	NC	-	-	Not used
	8	NC	-	-	Not used
	9	NC	-	-	Not used
	10	NC	-	-	Not used
	11	NC	-	-	Not used
	12	SGND	-	-	Ground
	13	CH1_N	O	0/3.3 V DC (pulse)	Image control signal
	14	CH1_P	O	0/3.3 V DC (pulse)	Image control signal
	15	SGND	-	-	Ground
	16	CH2_N	O	0/3.3 V DC (pulse)	Image control signal
	17	CH2_P	O	0/3.3 V DC (pulse)	Image control signal
	18	SGND	-	-	Ground
	19	CH3_N	O	0/3.3 V DC (pulse)	Image control signal

Connector	Pin	Signal	I/O	Voltage	Description
YC47	20	CH3_P	O	0/3.3 V DC (pulse)	Image control signal
Connected to fiery relay PWB	21	SGND	-	-	Ground
	22	VCLK_N	O	0/3.3 V DC (pulse)	Clock signal
	23	VCLK_P	O	0/3.3 V DC (pulse)	Clock signal
	24	SGND	-	-	Ground
	25	VSYNC_DP	O	0/3.3 V DC (pulse)	Image control signal
	26	VSYNC_DN	O	0/3.3 V DC (pulse)	Image control signal
	27	VSYNC_CP	O	0/3.3 V DC (pulse)	Image control signal
	28	VSYNC_CN	O	0/3.3 V DC (pulse)	Image control signal
	29	VSYNC_BP	O	0/3.3 V DC (pulse)	Image control signal
	30	VSYNC_BN	O	0/3.3 V DC (pulse)	Image control signal
	31	VSYNC_AP	O	0/3.3 V DC (pulse)	Image control signal
	32	VSYNC_AN	O	0/3.3 V DC (pulse)	Image control signal
	33	HSYNC_DP	O	0/3.3 V DC (pulse)	Image control signal
	34	HSYNC_DN	O	0/3.3 V DC (pulse)	Image control signal
	35	HSYNC_CP	O	0/3.3 V DC (pulse)	Image control signal
	36	HSYNC_CN	O	0/3.3 V DC (pulse)	Image control signal
	37	HSYNC_BP	O	0/3.3 V DC (pulse)	Image control signal
	38	HSYNC_BN	O	0/3.3 V DC (pulse)	Image control signal
	39	HSYNC_AP	O	0/3.3 V DC (pulse)	Image control signal
	40	HSYNC_AN	O	0/3.3 V DC (pulse)	Image control signal

2-3-3 Power source PWB

30 ppm model/35 ppm model




Figure 2-3-3 Power source PWB silk-screen diagram (30 ppm model/35 ppm model)

Connector	Pin	Signal	I/O	Voltage	Description
TB Connected to AC inlet and main power switch	1	LIVE	I	120 V AC 220-240 V AC	AC power input
	2	NEUTRAL	I	120 V AC 220-240 V AC	AC power input
	3	DH_LIVE	I	120 V AC 220-240 V AC	AC power input
YC1 Connected to main power switch	1	MSW_OUT	O	120 V AC 220-240 V AC	AC power input to MSW
	2	MSW_IN	I	120 V AC 220-240 V AC	AC power output from MSW
YC3 Connected to fuser IH PWB	1	IH_NEUTRAL	O	120 V AC 220-240 V AC	AC power output to FIHPWB
	2	NC	-	-	Not used
	3	IH_LIVE	O	120 V AC 220-240 V AC	AC power output to IHPWB
YC5 Connected to cassette heater	1	DH_LIVE	O	120 V AC 220-240 V AC	AC power output to CH
	2	DH_LIVE	O	120 V AC 220-240 V AC	AC power output to CH
	3	NC	-	-	Not used
	4	NC	-	-	Not used
	5	DH_NEUTRAL	O	120 V AC 220-240 V AC	AC power output to CH
	6	DH_NEUTRAL	O	120 V AC 220-240 V AC	AC power output to CH
YC6 Connected to paper feeder /large capacity feeder	1	DH_LIVE	O	120 V AC 220-240 V AC	AC power output to PFCH
	2	DH_NEUTRAL	O	120 V AC 220-240 V AC	AC power output to PFCH
YC7 Connected to LSU relay PWB	1	+24V1	O	24 V DC	24 V DC power to LSURPWB
	2	+24V1	O	24 V DC	24 V DC power to LSURPWB
	3	GND	-	-	Ground
	4	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC8 Connected to motor control PWB	1	GND	-	-	Ground
	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	+24V1	O	24 V DC	24 V DC power to MCPWB
	5	+24V1	O	24 V DC	24 V DC power to MCPWB
	6	+24V1	O	24 V DC	24 V DC power to MCPWB
YC9 Connected to feed PWB 1	1	+24V1	O	24 V DC	24 V DC power to FPWB1
	2	+24V1	O	24 V DC	24 V DC power to FPWB1
	3	+24V1	O	24 V DC	24 V DC power to FPWB1
	4	+12V	O	12 V DC	12 V DC power to FPWB1
	5	GND	-	-	Ground
	6	GND	-	-	Ground
	7	GND	-	-	Ground
	8	GND	-	-	Ground
YC10 Connected to paper feeder/ large capacity feeder, 1000-sheet/ 4000-sheet finisher and ISCPWB	1	+24V1	O	24 V DC	24 V DC power to paper feeder/ large capacity feeder
	2	+24V1	O	24 V DC	24 V DC power to paper feeder/ large capacity feeder
	3	+24V1	O	24 V DC	24 V DC power to 1000-sheet/4000-sheet finisher
	4	+24V1	O	24 V DC	24 V DC power to 1000-sheet/4000-sheet finisher
	5	+24V1	O	24 V DC	24 V DC power to ISCPWB
	6	+24V1	O	24 V DC	24 V DC power to ISCPWB
	7	+24V1	-	-	Not used
	8	+24V1	-	-	Not used
	9	GND	-	-	Ground
	10	GND	-	-	Ground
	11	GND	-	-	Ground
	12	GND	-	-	Ground
	13	GND	-	-	Ground
	14	GND	-	-	Ground
	15	GND	-	-	Ground
	16	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC13	1	+24V1	O	24 V DC	24 V DC power to HVPWB1
Connected to high voltage PWB 1	2	+24V1	O	24 V DC	24 V DC power to HVPWB1
	3	+24V1	O	24 V DC	24 V DC power to HVPWB1
	4	PGND	-	-	Ground
	5	PGND	-	-	Ground
	6	PGND	-	-	Ground
YC14	1	POWER_OFF	I	0/3.3 V DC	Sleep mode signal: On/Off
Connected to feed PWB 1	2	DRUM_HEAT_RE M	I	0/3.3 V DC	FH: On/Off
	3	GND	-	-	Ground
	4	FSR_RELAY_RE M	I	0/3.3 V DC	Power relay signal: On/Off
YC11	1	GND	-	-	Ground
Connected to main PWB	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	GND	-	-	Ground
	5	+12V1	O	12 V DC	12 V DC power to MPWB
	6	+12V1	O	12 V DC	12 V DC power to MPWB
	7	+12V1	O	12 V DC	12 V DC power to MPWB
	8	+12V1	O	12 V DC	12 V DC power to MPWB

45 ppm model/55 ppm model




Figure 2-3-4 Power source PWB silk-screen diagram (45 ppm model/55 ppm model)

Connector	Pin	Signal	I/O	Voltage	Description	
TB	1	LIVE	I	120 V AC 220-240 V AC	AC power input	
	Connected to AC inlet and main power switch	2	NEUTRAL	I	120 V AC 220-240 V AC	AC power input
		3	LIVE	-	-	Not used
		4	NEUTRAL	-	-	Not used
		5	DH_LIVE	I	120 V AC 220-240 V AC	AC power input
YC1	1	MSW_IN	O	120 V AC 220-240 V AC	AC power input to MSW	
Connected to main power switch	2	MSW_OUT	I	120 V AC 220-240 V AC	AC power output from MSW	
	YC3	1	IH_NEUTRAL	O	120 V AC 220-240 V AC	AC power output to IHPWB
Connected to fuser IH PWB	2	NC	-	-	Not used	
	3	IH_LIVE	O	120 V AC 220-240 V AC	AC power output to IHPWB	
YC8	1	DH_LIVE	O	120 V AC 220-240 V AC	AC power output to CH	
Connected to cassette heater	2	DH_LIVE	O	120 V AC 220-240 V AC	AC power output to CH	
	3	NC	-	-	Not used	
	4	NC	-	-	Not used	
	5	DH_NEUTRAL	O	120 V AC 220-240 V AC	AC power output to CH	
	6	DH_NEUTRAL	O	120 V AC 220-240 V AC	AC power output to CH	
YC9	1	DH_LIVE	O	120 V AC 220-240 V AC	AC power output to PFCH	
Connected to paper feeder/ large capac- ity feeder	2	DH_NEUTRAL	O	120 V AC 220-240 V AC	AC power output to PFCH	
	YC10	1	+24V1	O	24 V DC	24 V DC power to LSURPWB
Connected to LSU relay PWB	2	+24V1	O	24 V DC	24 V DC power to LSURPWB	
	3	GND	-	-	Ground	
	4	GND	-	-	Ground	

Connector	Pin	Signal	I/O	Voltage	Description
YC11 Connected to motor control PWB	1	+24V1	O	24 V DC	24 V DC power to MCPWB
	2	+24V1	O	24 V DC	24 V DC power to MCPWB
	3	+24V1	O	24 V DC	24 V DC power to MCPWB
	4	GND	-	-	Ground
	5	GND	-	-	Ground
	6	GND	-	-	Ground
YC12 Connected to feed PWB 1	1	+24V1	O	24 V DC	24 V DC power to FPWB1
	2	+24V1	O	24 V DC	24 V DC power to FPWB1
	3	+24V1	O	24 V DC	24 V DC power to FPWB1
	4	+12V	O	12 V DC	12 V DC power to FPWB1
	5	GND	-	-	Ground
	6	GND	-	-	Ground
	7	GND	-	-	Ground
	8	GND	-	-	Ground
YC13 Connected to paper feeder/ large capacity feeder, 1000-sheet/ 4000-sheet finisher and ISCPWB	1	+24V1	O	24 V DC	24 V DC power to paper feeder/ large capacity feeder
	2	+24V1	O	24 V DC	24 V DC power to paper feeder/ large capacity feeder
	3	+24V1	O	24 V DC	24 V DC power to 1000-sheet/4000-sheet finisher
	4	+24V1	O	24 V DC	24 V DC power to 1000-sheet/4000-sheet finisher
	5	+24V1	O	24 V DC	24 V DC power to ISCPWB
	6	+24V1	O	24 V DC	24 V DC power to ISCPWB
	7	+24V1	-	-	Not used
	8	+24V1	-	-	Not used
	9	GND	-	-	Ground
	10	GND	-	-	Ground
	11	GND	-	-	Ground
	12	GND	-	-	Ground
	13	GND	-	-	Ground
	14	GND	-	-	Ground
	15	-	-	-	-
	16	-	-	-	-

Connector	Pin	Signal	I/O	Voltage	Description
YC11	1	GND	-	-	Ground
Connected to main PWB	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	GND	-	-	Ground
	5	+12V1	O	12 V DC	12 V DC power to MPWB
	6	+12V1	O	12 V DC	12 V DC power to MPWB
	7	+12V1	O	12 V DC	12 V DC power to MPWB
	8	+12V1	O	12 V DC	12 V DC power to MPWB
YC16	1	+24V1	O	24 V DC	24 V DC power to HVPWB1
Connected to high voltage PWB 1	2	+24V1	O	24 V DC	24 V DC power to HVPWB1
	3	+24V1	O	24 V DC	24 V DC power to HVPWB1
	4	PGND	-	-	Ground
	5	PGND	-	-	Ground
	6	PGND	-	-	Ground
YC17	1	POWER_OFF	I	0/3.3 V DC	Sleep mode signal: On/Off
Connected to feed PWB 1	2	DRUM_HEAT_RE M	I	0/3.3 V DC	FH: On/Off
	3	GND	-	-	Ground

2-3-4 ISC PWB




Figure 2-3-5 ISC PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC3 Connected to main PWB	1	SC_CLK	I	0/3.3 V DC (pulse)	Scanner clock signal
	2	SC_SO	O	0/3.3 V DC (pulse)	Serial communication data signal
	3	SC_SI	I	0/3.3 V DC (pulse)	Serial communication data signal
	4	SC_BSY	I	0/3.3 V DC	Scanner busy signal
	5	SC_HLDN	I	0/3.3 V DC	Scanner hold signal
	6	SC_DIR	I	0/3.3 V DC	Scanner communication direction signal
	7	SC_IRN	I	0/3.3 V DC	Scanner interrupt signal
	8	GND(SPARE)	-	-	Ground
YC4 Connected to main PWB	1	GND	-	-	Ground
	2	HTPDN	O	0/3.3 V DC	Control signal
	3	LOCKN	O	0/3.3 V DC	Lock signal
	4	GND	-	-	Ground
	5	TX0N	O	0/3.3 V DC (pulse)	Transmission data signal
	6	TX0P	O	0/3.3 V DC (pulse)	Transmission data signal
	7	GND	-	-	Ground
YC5 Connected to scanner motor	1	SMOT AP	O	0/24 V DC (pulse)	SM drive control signal
	2	SMOT BP	O	0/24 V DC (pulse)	SM drive control signal
	3	SMOT AN	O	0/24 V DC (pulse)	SM drive control signal
	4	SMOT BN	O	0/24 V DC (pulse)	SM drive control signal
YC6 Connected to LED lamp PWB	1	+5V	O	5 V DC	5 V DC power to LLPWB
	2	FAIL	I	0/3.3 V DC	Error signal
	3	SDA	I/O	0/3.3 V DC	Data signal
	4	SCL	O	0/3.3 V DC (pulse)	Clock signal
	5	VSET	O	Analog	Analog voltage
	6	SGND	-	-	Ground
	7	PGND	-	-	Ground
	8	PWM	O	0/3.3 V DC	PWM signal
	9	POW	O	0/3.3 V DC	LED driver: On/Off
	10	+24V1	O	24 V DC	24 V DC power to LLPWB
	11	+24V1	O	24 V DC	24 V DC power to LLPWB
YC7 Connected to power source PWB	1	+24V1	I	24 V DC	24 V DC power from PSPWB
	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	GND	-	-	Ground
	5	+24V2	I	24 V DC	24 V DC power from PSPWB
	6	+24V2	I	24 V DC	24 V DC power from PSPWB

Connector	Pin	Signal	I/O	Voltage	Description	
YC8	1	+3.3V	O	3.3 V DC	3.3 V DC power to HPS	
	Connected to home position sensor	2	GND	-	-	Ground
		3	HP_SW	I	0/3.3 V DC	HPS: On/Off
YC9	1	GND	-	-	Ground	
	Connected to CCD PWB	2	CCDCLK1	O	0/3.3 V DC (pulse)	Clock signal
		3	GND	-	-	Ground
		4	CCDCLK2	O	0/3.3 V DC (pulse)	Clock signal
		5	GND	-	-	Ground
		6	CP	O	0/3.3 V DC	Clamp signal
		7	GND	-	-	Ground
		8	RS	O	0/3.3 V DC	Reset signal
		9	VSG	O	0/3.3 V DC	Control signal
		10	TG	O	0/3.3 V DC	Control signal
		11	SH	O	0/3.3 V DC	Shift gate signal
		12	AFE_SI	I	0/3.3 V DC (pulse)	Serial communication data signal
		13	AFE_EN	O	0/3.3 V DC (pulse)	Enable signal
		14	AFE_SO	O	0/3.3 V DC (pulse)	Serial communication data signal
		15	AFECLK	O	0/3.3 V DC (pulse)	Clock signal
		16	GND	-	-	Ground
		17	DIS_CIS_1P	I	0/3.3 V DC (pulse)	Image data signal
		18	DIS_CIS_1N	I	0/3.3 V DC (pulse)	Image data signal
		19	GND	-	-	Ground
		20	DIS_CIS_2P	I	0/3.3 V DC (pulse)	Image data signal
		21	DIS_CIS_2N	I	0/3.3 V DC (pulse)	Image data signal
		22	GND	-	-	Ground
		23	DIS_CIS_3P	I	0/3.3 V DC (pulse)	Image data signal
		24	DIS_CIS_3N	I	0/3.3 V DC (pulse)	Image data signal
		25	GND	-	-	Ground
		26	DIS_CIS_4P	I	0/3.3 V DC (pulse)	Image data signal
		27	DIS_CIS_4N	I	0/3.3 V DC (pulse)	Image data signal
		28	GND	-	-	Ground
		29	DIS_CIS_5P	I	0/3.3 V DC (pulse)	Image data signal
		30	DIS_CIS_5N	I	0/3.3 V DC (pulse)	Image data signal
		31	GND	-	-	Ground
		32	DIS_CISCKP	O	0/3.3 V DC (pulse)	Clock signal
		33	DIS_CISCKN	O	0/3.3 V DC (pulse)	Clock signal

Connector	Pin	Signal	I/O	Voltage	Description
YC9 Connected to CCD PWB	34	GND	-	-	Ground
	35	CCDSEL	O	0/3.3 V DC	Select signal
	36	GND	-	-	Ground
	37	AFE_MCLK	O	0/3.3 V DC (pulse)	Clock signal
	38	GND(AFE_SHD)	-	-	Ground
	39	CLPIN	O	0/3.3 V DC	Clamp signal
	40	GND(AFE_SHP)	-	-	Ground
YC11 Connected to CCD PWB	1	+5.1V	O	5 V DC	5 V DC power to CCDPWB
	2	GND	-	-	Ground
	3	+10V	O	DC10V	10 V DC power to CCDPWB
	4	GND	-	-	Ground
	5	+3.3V	O	3.3 V DC	3.3 V DC power to CCDPWB
	6	GND	-	-	Ground
YC12 Connected to DP main PWB	1	GND(SPARE)	-	-	Ground
	2	DP_TMG	I	0/3.3 V DC	DPTS: On/Off
	3	DP_RDY	I	0/3.3 V DC	ready signal
	4	DP_SEL	O	0/3.3 V DC	Select signal
	5	DP_CLK	O	0/3.3 V DC (pulse)	Clock signal
	6	DP_SO	O	0/3.3 V DC (pulse)	Serial communication data signal
	7	DP_SI	I	0/3.3 V DC (pulse)	Serial communication data signal
	8	DP_OPEN	I	0/3.3 V DC	DPOCSW: On/Off
	9	Reserve	-	-	Not used
	10	GND	-	-	Ground
	11	GND	-	-	Ground
	12	GND	-	-	Ground
	13	Reserve	-	-	Not used
	14	24V2	O	24 V DC	24 V DC power to DPMPWB
	15	24V2	O	24 V DC	24 V DC power to DPMPWB
	16	24V2	O	24 V DC	24 V DC power to DPMPWB
YC13 Connected to original size sensor	1	GND	-	-	Ground
	2	ORG_SW	I	0/3.3 V DC	OSS: On/Off
	3	+5.1V	O	5 V DC	5 V DC power to OSS

Connector	Pin	Signal	I/O	Voltage	Description
YC14	1	+3.3V	O	3.3 V DC	3.3 V DC power to ODSW
Connected to original detection switch	2	GND	-	-	Ground
	3	CO_SW	I	0/3.3 V DC	ODSW: On/Off

2-3-5 Operation PWB 1




Figure 2-3-6 Operation PWB 1 silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC1 Connected to main PWB	1	+5V	I	5 V DC	5 V DC power from MPWB
	2	+5V	I	5 V DC	5 V DC power from MPWB
	3	+5V	I	5 V DC	5 V DC power from MPWB
	4	GND	-	-	Ground
	5	GND	-	-	Ground
	6	GND	-	-	Ground
YC2 Connected to main PWB	1	VBUS	I	5 V DC	5 V DC power input
	2	DN	I/O	-	USB data signal
	3	DP	I/O	-	USB data signal
	4	ID	-	-	Not used
	5	GND	-	-	Ground
YC3 Connected to main PWB	1	GND	-	-	Ground
	2	SECOND_TRAY_SW	-	-	Not used
	3	BEEP_POWERON	I	0/3.3 V DC	Sleep return signal
	4	ENERGY_SAVE	I	0/3.3 V DC	Energy save signal
	5	SUPND_POWER	I	3.3 V DC	3.3 V DC power from MPWB
	6	LED_MEMORY_N	I	0/3.3 V DC	Memory LED control signal
	7	LED_ATTENTION_N	I	0/3.3 V DC	Attention LED control signal
	8	LED_PROCESSING_N	I	0/3.3 V DC	Processing LED control signal
	9	SHUT_DOWN	I	0/3.3 V DC	24 V down signal
	10	LIGHTOFF_POWERON	I	0/3.3 V DC	Sleep return signal
	11	AUDIO	I	Analog	Audio output signal
	12	PANEL RESET	I	0/3.3 V DC	Reset signal
	13	INT_POWERKEY_N	O	0/3.3 V DC	Power key: On/Off
	14	PANEL_STATUS	O	0/3.3 V DC	Operation panel status signal
	15	SGND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC4	1	SGND	-	-	Ground
Connected to LCD	2	SGND	-	-	Ground
	3	CK	O	0/3.3 V DC (pulse)	LCD clock signal
	4	SGND	-	-	Ground
	5	SGND	-	-	Ground
	6	SC	O	0/3.3 V DC	LCD Control signal
	7	R0(LSB)	O	0/3.3 V DC	LCD Control signal
	8	R1	O	0/3.3 V DC	LCD Control signal
	9	R2	O	0/3.3 V DC	LCD Control signal
	10	SGND	-	-	Ground
	11	R3	O	0/3.3 V DC	LCD Control signal
	12	R4	O	0/3.3 V DC	LCD Control signal
	13	R5(MSB)	O	0/3.3 V DC	LCD Control signal
	14	SGND	-	-	Ground
	15	G0(LSB)	O	0/3.3 V DC	LCD Control signal
	16	G1	O	0/3.3 V DC	LCD Control signal
	17	G2	O	0/3.3 V DC	LCD Control signal
	18	SGND	-	-	Ground
	19	G3	O	0/3.3 V DC	LCD Control signal
	20	G4	O	0/3.3 V DC	LCD Control signal
	21	G5(MSB)	O	0/3.3 V DC	LCD Control signal
	22	SGND	-	-	Ground
	23	B0(LSB)	O	0/3.3 V DC	LCD Control signal
	24	B1	O	0/3.3 V DC	LCD Control signal
	25	B2	O	0/3.3 V DC	LCD Control signal
	26	SGND	-	-	Ground
	27	B3	O	0/3.3 V DC	LCD Control signal
	28	B4	O	0/3.3 V DC	LCD Control signal
	29	B5(MSB)	O	0/3.3 V DC	LCD Control signal
	30	SGND	-	-	Ground
	31	H_SYNC	O	0/3.3 V DC (pulse)	LCD horizontal synchronization signal
	32	SGND	-	-	Ground
	33	V_SYNC	O	0/3.3 V DC (pulse)	LCD vertical synchronization signal
	34	SGND	-	-	Ground
	35	ENB	O	0/3.3 V DC	LCD enable signal
	36	CM	O	0/3.3 V DC	LCD mode switch signal

Connector	Pin	Signal	I/O	Voltage	Description	
YC4	37	3.3V	O	3.3 V DC	3.3 V DC power to LCD	
	Connected to LCD	38	3.3V	O	3.3 V DC	3.3 V DC power to LCD
		39	3.3V	O	3.3 V DC	3.3 V DC power to LCD
		40	3.3V	O	3.3 V DC	3.3 V DC power to LCD
YC5	1	BOT Y-	I	Analog	Touch panel Y- position signal	
	Connected to touch panel	2	LEFT X+	I	Analog	Touch panel X+ position signal
		3	TOP Y+	I	Analog	Touch panel Y+ position signal
		4	RIGHT X-	I	Analog	Touch panel X- position signal
YC6	1	KEY4	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 4	
	Connected to operation PWB 2	2	SCAN2	O	0/3.3 V DC (pulse)	Scan signal 2
		3	INT_POWERKEY_N	I	0/3.3 V DC	Power key: On/Off
		4	SCAN1	O	0/3.3 V DC (pulse)	Scan signal 1
		5	LED1	O	0/3.3 V DC (pulse)	Operation panel LED display drive signal 1
		6	SUPND_POWER	O	3.3 V DC	3.3 V DC power to OPWB2
		7	KEY3	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 3
		8	KEY2	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 2
		9	KEY1	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 1
		10	LED0	O	0/3.3 V DC (pulse)	Operation panel LED display drive signal 0
		11	KEY0	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 0
		12	SCAN4	O	0/3.3 V DC (pulse)	Scan signal 4
		13	SCAN3	O	0/3.3 V DC (pulse)	Scan signal 3
		14	SCAN0	O	0/3.3 V DC (pulse)	Scan signal 0
		15	GND	-	-	Ground
		16	GND	-	-	Ground
		17	GND	-	-	Ground
		18	GND	-	-	Ground
		19	GND	-	-	Ground
		20	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC7	1	SCAN4	O	0/3.3 V DC (pulse)	Scan signal 4
Connected to operation PWB 2	2	KEY5	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 5
	3	KEY6	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 6
	4	KEY7	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 7
	5	SCAN0	O	0/3.3 V DC (pulse)	Scan signal 0
	6	SCAN1	O	0/3.3 V DC (pulse)	Scan signal 1
	7	SCAN2	O	0/3.3 V DC (pulse)	Scan signal 2
	8	SCAN3	O	0/3.3 V DC (pulse)	Scan signal 3
	9	LED2	O	0/3.3 V DC (pulse)	Operation panel LED display drive signal 2
	10	LED3	O	0/3.3 V DC (pulse)	Operation panel LED display drive signal 3
	11	LED4	O	0/3.3 V DC (pulse)	Operation panel LED display drive signal 4
	12	GND	-	-	Ground
YC8	1	PROCESSING_LED	O	0/3.3 V DC	Processing LED control signal
Connected to operation PWB 3	2	MEMORY_LED	O	0/3.3 V DC	Memory LED control signal
	3	ATTENTION_LED	O	0/3.3 V DC	Attention LED control signal
	4	GND	-	-	Ground
YC11	1	VO2	O	Analog	Speaker sound signal (+)
Connected to speaker	2	VO1	O	Analog	Speaker sound signal (-)
YC14	1	LED_A	O	0/3.3 V DC	LED control signal
Connected to LCD	2	NC	-	-	Not used
	3	LED_C	I	0/3.3 V DC	LED control signal
	4	NC	-	-	Not used

2-3-6 Front PWB




Figure 2-3-7 Front PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC1 Connected to engine PWB	1	+3.3V1	I	3.3 V DC	3.3 V DC power from EPWB
	2	+3.3V2	I	3.3 V DC	3.3 V DC power from EPWB
	3	+5V	I	5 V DC	5 V DC power from EPWB
	4	+24V	I	24 V DC	24 V DC power from EPWB
	5	+24V	I	24 V DC	24 V DC power from EPWB
	6	GND	-	-	Ground
	7	GND	-	-	Ground
	8	GND	-	-	Ground
	9	GND	-	-	Ground
	10	GND	-	-	Ground
YC2 Connected to engine PWB	1	GND	-	-	Ground
	2	DRM_INDEX_Bk	O	0/3.3 V DC	DRM-K control signal
	3	ERS_Bk_REM	I	0/24 V DC	CL-K: On/Off
	4	TPD_Bk_1	O	Analog	TS-K detection signal
	5	DLP_VCONT_Bk_1	I	0/3.3 V DC	TS-K control signal
	6	TPD_TEMP_Bk	O	Analog	Developer thermistor K detection signal
	7	GND	-	-	Ground
	8	DRM_INDEX_M	O	0/3.3 V DC	DRM-M control signal
	9	ERS_M_REM	I	0/24 V DC	CL-M: On/Off
	10	TPD_M_1	O	Analog	DEVPWB-M detection signal
	11	DLP_VCONT_M_1	I	0/3.3 V DC	DEVPWB-M control signal
	12	TPD_TEMP_M	O	Analog	Developer thermistor M detection signal
	13	GND	-	-	Ground
	14	DRM_INDEX_C	O	0/3.3 V DC	DRM-C control signal
	15	ERS_C_REM	I	0/24 V DC	CL-C: On/Off
	16	TPD_C_1	O	Analog	DEVPWB-C detection signal
	17	DLP_VCONT_C_1	I	0/3.3 V DC	DEVPWB-C control signal
	18	TPD_TEMP_C	O	Analog	Developer thermistor C detection signal
	19	GND	-	-	Ground
	20	TN_CLK	I	0/3.3 V DC (pulse)	Clock signal
	21	GND	-	-	Ground
	22	EED_SCL1	I	0/3.3 V DC (pulse)	EEPROM clock signal

Connector	Pin	Signal	I/O	Voltage	Description
YC2	23	GND	-	-	Ground
Connected to engine PWB	24	EEP_SDA1	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	25	GND	-	-	Ground
	26	TPD_Y_1	O	Analog	DEVPWB-Y detection signal
	27	DLP_VCONT_Y_1	I	0/3.3 V DC	DEVPWB-Y control signal
	28	TPD_TEMP_Y	O	Analog	Developer thermistor Y detection signal
	29	ERS_Y_REM	I	0/24 V DC	CL-Y: On/Off
	30	DRM_INDEX_Y	O	0/3.3 V DC	DRM-Y control signal
	31	FRONT_OPEN	O	0/3.3 V DC	FRCSW: On/Off
	32	GND	-	-	Ground
	33	I2C_SCL	I	0/3.3 V DC (pulse)	EEPROM clock signal
	34	GND	-	-	Ground
	35	I2C_SDA	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	36	GND	-	-	Ground
	37	LSU_FAN_REM	I	0/24 V DC	LSUFM: On/Off
	38	CLEAN_MOT_LOCK	O	0/3.3 V DC	WTM lock signal
	39	CLEAN_MOT_REM	I	0/24 V DC	WTM: On/Off
	40	GND	-	-	Ground
	YC3	1	GND	-	-
Connected to engine PWB	2	WTNR_SET	-	-	Not used
	3	INTER_LOCK	-	-	Not used
	4	IH_CORE_SENS	-	-	Not used
	5	IH_CORE_MOT_REM	-	-	Not used
	6	IH_CORE_CLK	-	-	Not used
	7	WTNR_LED	I	0/3.3 V DC (pulse)	WTS1 LED emitter signal
	8	IH_COIL_FAN_ALARM	O	0/3.3 V DC	FUFFM alarm signal
	9	IH_COIL_FAN_H	I	0/24 V DC	FUFFM: On/Off
	10	IH_COIL_FAN_L	I	0/24 V DC	FUFFM: On/Off
	11	EXIT_FAN	I	0/24 V DC	EFFM: On/Off
	12	CONTAIN_FAN	-	-	Not used
	13	JUNC_SOL_REM	I	0/24 V DC	FSSOL: On/Off (ACT)
	14	JUNC_SOL_RET	I	0/24 V DC	FSSOL: On/Off (RET)
	15	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC3	16	EXIT_PAPER_SENS	O	0/3.3 V DC	EFS: On/Off
Connected to engine PWB	17	EXIT_FEED_SENS	O	0/3.3 V DC	SBS: On/Off
	18	SB_MOT_REM	I	0/3.3 V DC	EM: On/Off
	19	SB_MOT_PH	I	0/3.3 V DC	EM control signal
	20	SB_MOT_CLK	I	0/3.3 V DC (pulse)	EM clock signal
	21	SB_MOT_PD	I	0/3.3 V DC	EM control signal
	22	SB_MOT_DIR	I	0/3.3 V DC	EM drive switch signal
	23	GND	-	-	Ground
	24	DLP_FAN_Bk_H	I	0/24 V DC	DEVFM2: On/Off
	25	DLP_FAN_Bk_L	I	0/24 V DC	DEVFM2: On/Off
	26	DLP_FAN_CLR_H	I	0/24 V DC	DEVFM1: On/Off
	27	DLP_FAN_CLR_L	I	0/24 V DC	DEVFM1: On/Off
	28	WTNR_FULL	O	Analog	WTS2 detection signal
	29	WTNR_NEAR	O	Analog	WTS2 detection signal
	30	WTNR_VCONT	I	0/3.3 V DC	WTS2 control signal
	31	GND	-	-	Ground
	32	ROT_MOT_REM	-	-	Not used
	33	ROT_MOT_CLK	-	-	Not used
	34	ROT_MOT_PD	-	-	Not used
	35	ROT_MOT_DIR	-	-	Not used
	36	ROT_HP_SENS	-	-	Not used
	37	THOP_MOT_Bk_REM	-	-	Not used
	38	THOP_MOT_M_REM	-	-	Not used
	39	THOP_MOT_C_REM	-	-	Not used
	40	THOP_MOT_Y_REM	-	-	Not used
	41	GND	-	-	Ground
	42	ENCODE_Bk	-	-	Not used
	43	ENCODE_M	-	-	Not used
	44	ENCODE_C	-	-	Not used
	45	ENCODE_Y	-	-	Not used
	46	THOP_Bk	-	-	Not used
	47	THOP_M	-	-	Not used

Connector	Pin	Signal	I/O	Voltage	Description
YC3 Connected to engine PWB	48	THOP_C	-	-	Not used
	49	THOP_Y	-	-	Not used
	50	GND	-	-	Ground
YC4 Connected to fuser front fan motor and eject front fan motor	1	5V	-	-	Not used
	2	LED1	-	-	Not used
	3	5V	-	-	Not used
	4	LED2	-	-	Not used
	5	IH_COIL_FAN_ALARM	I	0/3.3 V DC	FUFFM alarm signal
	6	IH_COIL_FAN	O	0/24 V DC	FUFFM: On/Off
	7	24V	O	24 V DC	24 V DC power to FUFFM
	8	24V	O	24 V DC	24 V DC power to EFFM
	9	EXIT FAN	O	0/24 V DC	EFFM: On/Off
YC5 Connected to eject unit	1	ROT_CORE A	-	-	Not used
	2	ROT_CORE B	-	-	Not used
	3	ROT_CORE A/	-	-	Not used
	4	ROT_CORE B/	-	-	Not used
	5	GND	-	-	Not used
	6	ROT_HP_SENS	-	-	Not used
	7	5V	-	-	Not used
	8	SB_CORE B/	O	0/24 V DC (pulse)	EM drive control signal
	9	SB_CORE A/	O	0/24 V DC (pulse)	EM drive control signal
	10	SB_CORE B	O	0/24 V DC (pulse)	EM drive control signal
	11	SB_CORE A	O	0/24 V DC (pulse)	EM drive control signal
	12	GND	-	-	Ground
	13	EXIT_FEED_SENS	I	0/3.3 V DC	SBS: On/Off
	14	5V	O	5 V DC	5 V DC power to SBS
	15	GND	-	-	Ground
	16	EXIT_PAPER_SENS	I	0/3.3 V DC	EFS: On/Off
	17	5V	O	5 V DC	5 V DC power to EFS
	18	+24V1	O	24 V DC	24 V DC power to FSSOL
	19	JUNC_SOL_KYU	O	0/24 V DC	FSSOL: On/Off (ACT)
	20	JUNC_SOL_FUK	O	0/24 V DC	FSSOL: On/Off (RET)

Connector	Pin	Signal	I/O	Voltage	Description
YC6 Connected to developer fan motor 1/2	1	24V	O	24 V DC	24 V DC power to DEVFM2
	2	DLP_FAN_Bk	O	0/24 V DC	DEVFM2: On/Off
	3	24V	O	24 V DC	24 V DC power to DEVFM1
	4	DLP_FAN_M	O	0/24 V DC	DEVFM1: On/Off
YC7 Connected to drum unit K	1	3.3V2	O	3.3 V DC	3.3 V DC power to DRPWB-K
	2	EED_SCL1	O	0/3.3 V DC (pulse)	EEPROM clock signal
	3	EED_SDA1	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	4	GND	-	-	Ground
	5	DRM_ADR0_Bk	-	-	Not used
	6	DRM_ADR1_Bk	-	-	Not used
	7	24V	O	24 V DC	24 V DC power to CL-K
	8	ERS_Bk_REM	O	0/24 V DC	CL-K: On/Off
YC8 Connected to waste toner sensor 1/2	1	5V	O	5 V DC	5 V DC power to WTS1
	2	WTNR_FULL	I	Analog	WTS1 detection signal
	3	WTNR_LED	O	0/3.3 V DC (pulse)	WTS1 LED emitter signal
	4	5V_LED	O	5 V DC	5 V DC power to WTS1
	5	GND	-	-	Ground
	6	WTNR_SET	I	Analog	WTS2 detection signal
	7	5V	O	5 V DC	5 V DC power to WTS2
	8	WTNR_NEAR	-	-	Not used
	9	WTNR_LED	-	-	Not used
	10	5V_LED	-	-	Not used
YC9 Connected to developer unit K	1	TPD_TEMP_BK	I	Analog	Developer thermistor K detection signal
	2	DLP_VCONT_BK_1	O	0/3.3 V DC	DEVPWB-K control signal
	3	TPD_BK_1	I	Analog	DEVPWB-K detection signal
	4	TN_CLK_BK	O	0/3.3 V DC (pulse)	Clock signal
	5	GND	-	-	Ground
	6	DLP_ADR1_BK	-	-	Not used
	7	DLP_ADR0_BK	-	-	Not used
	8	EED_SDA1	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	9	EED_SCL1	O	0/3.3 V DC (pulse)	EEPROM clock signal
	10	3.3V2	O	3.3 V DC	3.3 V DC power to DEVPWB-K
	11	3V	O	3.3 V DC	3.3 V DC power to VM-K
	12	VIB_MOT	O	0/24 V DC	VM-K: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC10 Connected to drum unit M	1	3.3V2	O	3.3 V DC	3.3 V DC power to DRPWB-M
	2	EEP_SCL1	O	0/3.3 V DC (pulse)	EEPROM clock signal
	3	EEP_SDA1	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	4	GND	-	-	Ground
	5	DRM_ADR0_M	-	-	Not used
	6	DRM_ADR1_M	-	-	Not used
	7	24V	O	24 V DC	24 V DC power to CL-M
	8	ERS_M_REM	O	0/24 V DC	CL-M: On/Off
YC11 Connected to developer unit M	1	TPD_TEMP_M	I	Analog	Developer thermistor M detection signal
	2	DLP_VCONT_M_1	O	0/3.3 V DC	DEVPWB-M control signal
	3	TPD_M_1	I	Analog	DEVPWB-M detection signal
	4	TN_CLK_M	O	0/3.3 V DC (pulse)	Clock signal
	5	GND	-	-	Ground
	6	DLP_ADR1_M	-	-	Not used
	7	DLP_ADR0_M	-	-	Not used
	8	EEP_SDA1	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	9	EEP_SCL1	O	0/3.3 V DC (pulse)	EEPROM clock signal
	10	3.3V2	O	3.3 V DC	3.3 V DC power to DEVPWB-M
	11	3V	O	3.3 V DC	3.3 V DC power to VM-M
	12	VIB_MOT	O	0/24 V DC	VM-M: On/Off
YC12 Connected to drum unit C	1	3.3V2	O	3.3 V DC	3.3 V DC power to DRPWB-C
	2	EEP_SCL1	O	0/3.3 V DC (pulse)	EEPROM clock signal
	3	EEP_SDA1	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	4	GND	-	-	Ground
	5	DRM_ADR0_C	-	-	Not used
	6	DRM_ADR1_C	-	-	Not used
	7	24V	O	24 V DC	24 V DC power to CL-C
	8	ERS_C_REM	O	0/24 V DC	CL-C: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC13	1	TPD_TEMP_C	I	Analog	Developer thermistor C detection signal
Connected to developer unit C	2	DLP_VCONT_C_1	O	0/3.3 V DC	DEVPWB-C control signal
	3	TPD_C_1	I	Analog	DEVPWB-C detection signal
	4	TN_CLK_C	O	0/3.3 V DC (pulse)	Clock signal
	5	GND	-	-	Ground
	6	DLP_ADR1_C	-	-	Not used
	7	DLP_ADR0_C	-	-	Not used
	8	EEP_SDA1	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	9	EEP_SCL1	O	0/3.3 V DC (pulse)	EEPROM clock signal
	10	3.3V2	O	3.3 V DC	3.3 V DC power to DEVPWB-C
	11	3V	O	3.3 V DC	3.3 V DC power to VM-C
	12	VIB_MOT	O	0/24 V DC	VM-C: On/Off
	YC14	1	3.3V2	O	3.3 V DC
Connected to drum unit Y	2	EEP_SCL1	O	0/3.3 V DC (pulse)	EEPROM clock signal
	3	EEP_SDA1	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	4	GND	-	-	Ground
	5	DRM_ADR0_Y	-	-	Not used
	6	DRM_ADR1_Y	-	-	Not used
	7	24V	O	24 V DC	24 V DC power to CL-Y
	8	ERS_Y_REM	O	0/24 V DC	CL-Y: On/Off
	YC15	1	TPD_TEMP_Y	I	Analog
Connected to developer unit Y	2	DLP_VCONT_Y_1	O	0/3.3 V DC	DEVPWB-Y control signal
	3	TPD_Y_1	I	Analog	DEVPWB-Y detection signal
	4	TN_CLK_Y	O	0/3.3 V DC (pulse)	Clock signal
	5	GND	-	-	Ground
	6	DLP_ADR1_Y	-	-	Not used
	7	DLP_ADR0_Y	-	-	Not used
	8	EEP_SDA1	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	9	EEP_SCL1	O	0/3.3 V DC (pulse)	EEPROM clock signal
	10	3.3V2	O	3.3 V DC	3.3 V DC power to DEVPWB-Y
	11	3V	O	3.3 V DC	3.3 V DC power to VM-Y
	12	VIB_MOT	O	0/24 V DC	VM-Y: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC16	1	3.3V1	O	3.3 V DC	3.3 V DC power to OTEMS1
Connected to outer temperature sensor 1, front cover switch, LSU fan motor and waste toner motor	2	I2C_SDA	I	0/3.3 V DC (pulse)	EEPROM data signal
	3	GND	-	-	Ground
	4	I2C_SCL	O	0/3.3 V DC (pulse)	EEPROM clock signal
	5	FRONT_OPEN	I	0/3.3 V DC	FRCSW: On/Off
	6	GND	-	-	Ground
	7	24V	O	24 V DC	24 V DC power to LSUFM
	8	LSU_FAN_OUT	O	DC0V/24V	LSUFM: On/Off
	9	CL_MOT	O	DC0V/24V	WTM: On/Off
	10	24V	O	24 V DC	24 V DC power to WTM
	11	GND	-	-	Ground
YC19	1	3.3V1	O	3.3 V DC	3.3 V DC power to OTEMS2
Connected to outer temperature sensor 2	2	I2C_SDA	I	0/3.3 V DC (pulse)	EEPROM data signal
	3	GND	-	-	Ground
	4	I2C_SCL	O	0/3.3 V DC (pulse)	EEPROM clock signal

2-3-7 Feed PWB 1




Figure 2-3-8 Feed PWB 1 silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC1	1	GND	-	-	Ground
Connected to engine PWB	2	REG_F_LED	I	Analog	IDS1 control signal
	3	REG_SENS_F_P	O	Analog	IDS1 detection signal
	4	REG_SENS_F_S	O	Analog	IDS1 detection signal
	5	GND	-	-	Ground
	6	REG_R_LED	I	Analog	IDS2 control signal
	7	REG_SENS_RP(BK)	O	Analog	IDS2 detection signal
	8	REG_SENS_RS(BK)	O	Analog	IDS2 detection signal
	9	CLN_SOL_REM	I	0/24 V DC	CLSOL: On/Off (ACT)
	10	CLN_SOL_RET	I	0/24 V DC	CLSOL: On/Off (RET)
	11	GND	-	-	Ground
	12	BELT_JAM_SENS	-	-	Not used
	13	DU_SENS	O	0/3.3 V DC	DUS2: On/Off
	14	PRESS_RLS_SENS	O	0/3.3 V DC	TRRS: On/Off
	15	PRESS_MOT_REM2	I	0/24 V DC	TRRM: On/Off
	16	PRESS_MOT_REM1	I	0/24 V DC	TRRM: On/Off
	17	DU_FAN	-	-	Not used
	18	DU_OPEN	O	0/3.3 V DC	DUCSW: On/Off
	19	GND	-	-	Ground
	20	DU2_REM(CLLOW)	I	0/3.3 V DC	DUM2/DUCL2: On/Off
	21	DU2_CLK	I	0/3.3 V DC (pulse)	DUM2 clock signal
	22	DU2_PD	I	0/3.3 V DC	DUM2 control signal
	23	INTER_LOCK	-	-	Not used
	24	TC_TONER_VCON	-	-	Not used
	25	TC_TONER_FULL	-	-	Not used
	26	TC_TONER_LED	-	-	Not used
	27	TC_MOT_LOCK	-	-	Not used
	28	GND	-	-	Ground
	29	MPF_LIFT1	I	0/24 V DC	MPLM: On/Off
	30	MPF_LIF2	I	0/24 V DC	MPLM: On/Off
	31	MPF_CL	I	0/24 V DC	MPPFCL: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC1	32	MPF_JAM	O	0/3.3 V DC	MPFS: On/Off
Connected to engine PWB	33	MPF_LIFT_DOW N	O	0/3.3 V DC	MPLS2: On/Off
	34	MPF_LIFT_UP	O	0/3.3 V DC	MPLS1: On/Off
	35	MPF_PPR_SET	O	0/3.3 V DC	MPPS: On/Off
	36	GND	-	-	Ground
	37	MPF_LNG	O	0/3.3 V DC	MPPLSW: On/Off
	38	MPF_WID3	O	0/3.3 V DC	MPPWSW: On/Off
	39	MPF_WID2	O	0/3.3 V DC	MPPWSW: On/Off
	40	MPF_WID1	O	0/3.3 V DC	MPPWSW: On/Off
	41	MPF_TABLE	O	0/3.3 V DC	MPTSW: On/Off
	42	GND	-	-	Ground
	43	FSR_MOT_BRK	I	0/3.3 V DC	FUM break signal
	44	FSR_MOT_DIR	I	0/3.3 V DC	FUM drive switch signal
	45	FSR_MOT_RDY	O	0/3.3 V DC	FUM ready signal
	46	FSR_MOT_CLK	I	0/3.3 V DC (pulse)	FUM clock signal
	47	FSR_MOT_REM	I	0/3.3 V DC	FUM: On/Off
	48	FSR_CL_REM	-	-	Not used
	49	GND	-	-	Ground
	50	EXIT_REAR_FAN _H	I	0/24 V DC	ERFM: On/Off
	51	EXIT_REAR_FAN _L	I	0/24 V DC	ERFM: On/Off
	52	PRESS_REM	-	-	Not used
	53	FSR_RELAY	I	0/3.3 V DC	Fuser relay signal
	54	ZEROC	-	-	Not used
	55	SUB_HEAT_REM	-	-	Not used
	56	MAIN_HEAT_RE M	-	-	Not used
	57	GND	-	-	Ground
	58	JOB_SOL_REM	I	0/24 V DC	JSFSSOL: On/Off
	59	JOB_OPEN_SEN S	O	0/3.3 V DC	JSOCS: On/Off
	60	JOB_MOT_DIR	I	0/3.3 V DC	JSEM drive switch signal
	61	JOB_MOT_CLK	I	0/3.3 V DC (pulse)	JSEM clock signal
	62	JOB_MOT_REM	I	0/3.3 V DC	JSEM: On/Off
	63	JOB_SET	O	0/3.3 V DC	Job separator set signal
	64	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC2	1	GND	-	-	Ground
Connected to engine PWB	2	IH_PWB_FAN(U)_ALM	-	-	Not used
	3	DRM_HEAT_REM	-	-	Not used
	4	POWER_OFF	I	0/3.3 V DC	Power off signal
	5	IH_PWB_FAN_ALM	O	0/3.3 V DC	IHFM alarm signal
	6	IH_PWB_FAN_H	I	0/24 V DC	IHFM: On/Off
	7	IH_PWB_FAN_L	-	-	Not used
	8	GND	-	-	Ground
	9	REG_MOT_REM(CL)	I	0/3.3 V DC	RM/RCL: On/Off
	10	REG_MOT_CLK	I	0/3.3 V DC (pulse)	RM clock signal
	11	REG_MOT_PD	I	0/3.3 V DC	RM control signal
	12	GND	-	-	Ground
	13	DLP_MOT_CLR_DIR	-	-	Not used
	14	DLP_MOT_CLR_RDY	-	-	Not used
	15	DLP_MOT_CLR_CLK	-	-	Not used
	16	DLP_MOT_CLR_REM	-	-	Not used
	17	GND	-	-	Ground
	18	DRM_MOT_CLR_DIR	-	-	Not used
	19	DRM_MOT_CLR_RDY	-	-	Not used
	20	DRM_MOT_BK_CLR_CLK	-	-	Not used
	21	DRM_MOT_CLR_REM	-	-	Not used
	22	GND	-	-	Ground
	23	DLP_MOT_BK_DIR	-	-	Not used
	24	DLP_MOT_BK_RDY	-	-	Not used
	25	DLP_MOT_BK_CLK	-	-	Not used
	26	DLP_MOT_BK_REM	-	-	Not used

Connector	Pin	Signal	I/O	Voltage	Description
YC2	27	GND	-	-	Ground
Connected to engine PWB	28	DRM_MOT_BK_B RK	-	-	Not used
	29	DRM_MOT_BK_D IR	-	-	Not used
	30	DRM_MOT_BK_R DY	-	-	Not used
	31	DRM_MOT_BK_R EM	-	-	Not used
	32	GND	-	-	Ground
	33	TRANS_MOT_BR K	I	0/3.3 V DC	TRCM break signal
	34	TRANS_MOT_DI R	I	0/3.3 V DC	TRCM drive switch signal
	35	TRANS_MOT_RD Y	O	0/3.3 V DC	TRCM ready signal
	36	TRANS_MOT_CL K	I	0/3.3 V DC (pulse)	TRCM clock signal
	37	TRANS_MOT_RE M	I	0/3.3 V DC	TRCM: On/Off
	38	GND	-	-	Ground
	39	TCON_SET	-	-	Not used
	40	DU_ENTER_SEN S	O	0/3.3 V DC	DUS1: On/Off
	41	EXIT_FAN	I	0/24 V DC	EFM: On/Off
	42	GND	-	-	Ground
	43	DU1_MOT_REM(CL_H)	I	0/3.3 V DC	DUM1/DUCL1: On/Off
	44	DU1_MOT_CLK	I	0/3.3 V DC (pulse)	DUM1 clock signal
	45	DU1_MOT_PD	I	0/3.3 V DC	DUM1 control signal
	46	EDGE_FAN_H	I	0/24 V DC	FUFM: On/Off
	47	GND	-	-	Ground
	48	LOOP_SENS	O	0/3.3 V DC	LPS: On/Off
	49	M_TEMP	-	-	Not used
	50	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC3 Connected to engine PWB	1	+24V1	O	24 V DC	24 V DC power to EPWB
	2	+24V1	O	24 V DC	24 V DC power to EPWB
	3	GND	-	-	Ground
	4	GND	-	-	Ground
	5	+12V	O	12 V DC	12 V DC power to EPWB
	6	GND	-	-	Ground
	7	+5V	O	5 V DC	5 V DC power to EPWB
	8	GND	-	-	Ground
YC4 Connected to power source PWB	1	+24V1	I	24 V DC	24 V DC power from PSPWB
	2	+24V1	I	24 V DC	24 V DC power from PSPWB
	3	+24V1	I	24 V DC	24 V DC power from PSPWB
	4	+12V	I	12 V DC	12 V DC power from PSPWB
	5	GND	-	-	Ground
	6	GND	-	-	Ground
	7	GND	-	-	Ground
	8	GND	-	-	Ground
YC5 Connected to power source PWB	1	GND	-	-	Ground
	2	DRM_HEAT_REM	O	0/3.3 V DC	FH: On/Off
	3	POWER_OFF	O	0/3.3 V DC	Sleep mode signal: On/Off
YC10 Connected to ID sensor1/2 and cleaning solenoid	1	GND	-	-	Ground
	2	M_TEMP	-	-	Not used
	3	3.3V	O	3.3 V DC	3.3 V DC power to IDS1
	4	REG_F_LED	O	Analog	IDS1 control signal
	5	GND	-	-	Ground
	6	REG_SENS_F_P	I	Analog	IDS1 detection signal
	7	REG_SENS_F_S	I	Analog	IDS1 detection signal
	8	3.3V	O	3.3 V DC	3.3 V DC power to IDS2
	9	REG_R_LED	O	Analog	IDS2 control signal
	10	GND	-	-	Ground
	11	REG_SENS_R_P	I	Analog	IDS2 detection signal
	12	REG_SENS_R_S	I	Analog	IDS2 detection signal
	13	24V	O	24 V DC	24 V DC power to CLSOL
	14	CLN_SOL_REM	O	0/24 V DC	CLSOL: On/Off (ACT)
	15	CLN_SOL_RET	O	0/24 V DC	CLSOL: On/Off (RET)

Connector	Pin	Signal	I/O	Voltage	Description
YC11 Connected to IH fan motor	1	+24V1	O	24 V DC	24 V DC power to IHFM
	2	IH_PWB_FAN	O	0/24 V DC	IHFM: On/Off
	3	IH_PWB_FAN_AL M	I	0/3.3 V DC	IHFM alarm signal
YC12 Connected to feed PWB 2	1	+24V2	O	24 V DC	24 V DC power to FPWB2
	2	+24V2	O	24 V DC	24 V DC power to FPWB2
	3	+5V	O	5 V DC	5 V DC power to FPWB2
	4	GND	-	-	Ground
	5	GND	-	-	Ground
	6	GND	-	-	Ground
YC13 Connected to transfer motor	1	TRANS_MOT_BR K	O	0/3.3 V DC	TRM break signal
	2	TRANS_MOT_DI R	O	0/3.3 V DC	TRM drive switch signal
	3	TRANS_MOT_RD Y	I	0/3.3 V DC	TRM ready signal
	4	TRANS_MOT_CL K	O	0/3.3 V DC (pulse)	TRM clock signal
	5	TRANS_MOT_RE M	O	0/24 V DC	TRM: On/Off
	6	GND	-	-	Ground
	7	24V2	O	24 V DC	24 V DC power to TRM
	8	GND	-	-	Not used
	9	24V2	-	-	Not used
	10	TANK_SET	-	-	Not used
YC14 Connected to relay PWB	1	REG_BK_LED	-	-	Not used
	2	REG_BK_SENS1 _P	-	-	Not used
	3	REG_BK_SENS1 _S	-	-	Not used
	4	BELT_JAM_SENS	-	-	Not used
	5	DU_SENS	I	0/3.3 V DC	DUS2: On/Off
	6	PRESS_RLS_SE NS	I	0/3.3 V DC	TRRS: On/Off
	7	5V	O	5 V DC	5 V DC power to RYPWB
	8	PRESS_RLSMOT 21	O	0/24 V DC	TRRM: On/Off
	9	PRESS_RLSMOT 2	O	0/24 V DC	TRRM: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC14 Connected to relay PWB	10	24V2	O	24 V DC	24 V DC power to RYPWB
	11	DU_FAN	-	-	Not used
	12	DU_CL_LOWER_REM	O	0/24 V DC	DUCL2: On/Off
	13	DU_OPEN_SW	I	0/3.3 V DC	DUCSW: On/Off
	14	DU2_B/	O	0/24 V DC (pulse)	DUM2 drive control signal
	15	DU2_A/	O	0/24 V DC (pulse)	DUM2 drive control signal
	16	DU2_B	O	0/24 V DC (pulse)	DUM2 drive control signal
	17	DU2_A	O	0/24 V DC (pulse)	DUM2 drive control signal
	18	5V_LED	-	-	Not used
YC15 Connected to paper con- veying unit switch	1	+24V1	O	24 V DC	24 V DC power to PCUSW
	2	N.C	-	-	Not used
	3	+24V2	I	24 V DC	24 V DC power from PCUSW
YC16 Connected to high voltage PWB 2	1	+24V2	O	24 V DC	24 V DC power to HVPWB2
	2	GND	-	-	Ground
YC17 Connected to relay PWB	1	TC_TONER_LED	-	-	Not used
	2	TC_TONER_FULL	-	-	Not used
	3	TC_TONER_MOT_B	-	-	Not used
	4	TC_TONER_MOT_A	-	-	Not used
	5	MPF_LIFT_MOT_B	O	0/24 V DC	MPLM: On/Off
	6	MPF_LIFT_MOT_A	O	0/24 V DC	MPLM: On/Off
	7	24V2	O	24 V DC	24 V dc power to RYPWB
	8	MPF_CL_REM	O	0/24 V DC	MPPFCL: On/Off
	9	MPF_JAM_SENS	I	0/3.3 V DC	MPFS: On/Off
	10	MPF_LIFT_DOWN_SENS	I	0/3.3 V DC	MPLS2: On/Off
	11	MPF_LIFT_UP_SENS	I	0/3.3 V DC	MPLS1: On/Off
	12	MPF_PPR_SET	I	0/3.3 V DC	MPPS: On/Off
	13	LED_3.3V3	O	3.3 V DC	3.3 V DC power to RYPWB
	14	MPF_LNG	I	0/3.3 V DC	MPPLSW: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC17 Connected to relay PWB	15	MPF_WID3	I	0/3.3 V DC	MPPWSW: On/Off
	16	MPF_WID2	I	0/3.3 V DC	MPPWSW: On/Off
	17	MPF_WID1	I	0/3.3 V DC	MPPWSW: On/Off
	18	MPF_TABLE	I	0/3.3 V DC	MPTSW: On/Off
	19	GND	-	-	Ground
	20	GND	-	-	Ground
YC18 Connected to fuser motor	1	FSR_MOT_BRK	O	0/3.3 V DC	FUM break signal
	2	FSR_MOT_DIR	O	0/3.3 V DC	FUM drive switch signal
	3	FSR_MOT_RDY	I	0/3.3 V DC	FUM ready signal
	4	FSR_MOT_CLK	O	0/3.3 V DC (pulse)	FUM clock signal
	5	FSR_MOT_REM	O	0/24 V DC	FUM: On/Off
	6	GND	-	-	Ground
	7	24V2	O	24 V DC	24 V DC power to FUM
YC19 Connected to eject rear fan motor	1	EXIT_REAR_FAN	O	0/24 V DC	ERFM: On/Off
	2	+24V1	O	24 V DC	24 V DC power to ERFM
YC20 Connected to job separator	1	JOB_SET	I	0/3.3 V DC	Job separator set signal
	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	JOB_MOT_REM	O	0/24 V DC	JSEM: On/Off
	5	24V1	O	24 V DC	24 V DC power to JSMPWB
	6	JOB_MOT_CLK	O	0/3.3 V DC (pulse)	JSEM clock signal
	7	5V	O	5 V DC	5 V DC power to JSMPWB
	8	JOB_MOT_DIR	O	0/3.3 V DC	JSEM drive switch signal
	9	JOB_OPEN_SEN S	I	0/3.3 V DC	JSOCS: On/Off
	10	JOB_SOL_REM	O	0/24 V DC	JSFSSOL: On/Off
	11	NC	-	-	Not used
YC22 Connected to registration clutch	1	24V2	O	24 V DC	24 V DC power to RCL
	2	REG_CL_REM	O	0/24 V DC	RCL: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC23	1	DU_ENTER_SEN S	I	0/3.3 V DC	DUS1: On/Off
Connected to relay PWB	2	EXIT_FAN	O	0/24 V DC	EFM: On/Off
	3	24V2	O	24 V DC	24 V DC power to RYPWB
	4	DU_CL_UPPER_ REM	O	0/24 V DC	DUCL1: On/Off
	5	GND	-	-	Ground
	6	DU1_B/	O	0/24 V DC (pulse)	DUM1 drive control signal
	7	DU1_A/	O	0/24 V DC (pulse)	DUM1 drive control signal
	8	DU1_B	O	0/24 V DC (pulse)	DUM1 drive control signal
	9	DU1_A	O	0/24 V DC (pulse)	DUM1 drive control signal
	10	EDGE_FAN_REM	O	0/24 V DC	FUFM: On/Off
	11	LOOP_SENS	I	0/3.3 V DC	LPS: On/Off
	12	3.3V	O	3.3 V DC	3.3 V DC power to RYPWB
YC25	1	REG_MOT_B/	O	0/24 V DC (pulse)	RM drive control signal
Connected to registration motor	2	REG_MOT_A/	O	0/24 V DC (pulse)	RM drive control signal
	3	REG_MOT_B	O	0/24 V DC (pulse)	RM drive control signal
	4	REG_MOT_A	O	0/24 V DC (pulse)	RM drive control signal
YC26	1	3.3V2	O	3.3 V DC	3.3 V DC power to EPWB
Connected to engine PWB	2	3.3V3	O	3.3 V DC	3.3 V DC power to EPWB
	3	GND	-	-	Ground
	4	GND	-	-	Ground
YC27	1	MAIN_HEAT_RE M	-	-	Not used
Connected to fuser IH PWB	2	SUB_HEAT_REM	-	-	Not used
	3	+24V2	-	-	Not used
	4	ZEROC	-	-	Not used
	5	GND	-	-	Ground
	6	GND	-	-	Ground
	7	FSR_RELAY	O	0/3.3 V DC	Fuser relay signal
	8	+24V1	O	24 V DC	24 V DC power to IHPWB
	9	PRESS_REM	-	-	Not used

2-3-8 Feed PWB 2




Figure 2-3-9 Feed PWB 2 silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC1	1	GND	-	-	Ground
Connected to engine PWB	2	FEED_MOT_REM	I	0/3.3 V DC	PFM: On/Off
	3	FEED_MOT_CLK	I	0/3.3 V DC (pulse)	PFM clock signal
	4	FEED_MOT_RDY	O	0/3.3 V DC	PFM ready signal
	5	FEED_MOT_DIR	I	0/3.3 V DC	PFM drive switch signal
	6	FEED_CL1_REM	I	0/24 V DC	PFCL1: On/Off
	7	FEED_CL2_REM	I	0/24 V DC	PFCL2: On/Off
	8	ASIST_CL2	I	0/24 V DC	ASCL2: On/Off
	9	LIFT_MOT2_REM	I	0/24 V DC	LM2: On/Off
	10	GND	-	-	Ground
	11	LIFT_MOT1_REM 1	I	0/24 V DC	LM1: On/Off
	12	CAS2_WID	O	0/3.3 V DC	PWSW2: On/Off
	13	CAS2_LNG3	O	0/3.3 V DC	PLSW2: On/Off
	14	CAS2_LNG2	O	0/3.3 V DC	PLSW2: On/Off
	15	CAS2_LNG1	O	0/3.3 V DC	PLSW2: On/Off
	16	CAS1_WID	O	0/3.3 V DC	PWSW1: On/Off
	17	CAS1_LNG3	O	0/3.3 V DC	PLSW1: On/Off
	18	CAS1_LNG2	O	0/3.3 V DC	PLSW1: On/Off
	19	CAS1_LNG1	O	0/3.3 V DC	PLSW1: On/Off
	20	GND	-	-	Ground
	21	CAS2_QUANT2	O	0/3.3 V DC	PGS2(L): On/Off
	22	CAS2_QUANT1	O	0/3.3 V DC	PGS2(U): On/Off
	23	CAS1_QUANT2	O	0/3.3 V DC	PGS1(L): On/Off
	24	CAS1_QUANT1	O	0/3.3 V DC	PGS1(U): On/Off
	25	LIFT_MOT1_LOCK	O	0/3.3 V DC	LM1 lock signal
	26	LIFT_MOT2_LOCK	O	0/3.3 V DC	LM2 lock signal
	27	CURRENT_SIG	O	0/3.3 V DC	Current signal
	28	V-FEED_CL	I	0/24 V DC	PCCL: On/Off
	29	COVER_OPEN	O	0/3.3 V DC	PCCSW: On/Off
	30	FEED2_SENS	O	0/3.3 V DC	PFPCS1: On/Off
	31	CAS1_P0	O	0/3.3 V DC	FS1: On/Off
	32	CAS1_LIFT_UP	O	0/3.3 V DC	LS1: On/Off
	33	GND	-	-	Ground
	34	CAS1_EMPTY	O	0/3.3 V DC	PS1: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC1 Connected to engine PWB	35	PICK_SOL1_RET	I	0/24 V DC	PUSOL1: On/Off (RET)
	36	PICK_SOL1_REM	I	0/24 V DC	PUSOL1: On/Off (ACT)
	37	CAS2_P0	O	0/3.3 V DC	FS2: On/Off
	38	CAS2_LIFT_UP	O	0/3.3 V DC	LS2: On/Off
	39	CAS2_EMPTY	O	0/3.3 V DC	PS2: On/Off
	40	PICK_SOL2_RET	I	0/24 V DC	PUSOL2: On/Off (RET)
	41	PICK_SOL2_REM	I	0/24 V DC	PUSOL2: On/Off (ACT)
	42	GND	-	-	Ground
	43	REG_SENS	O	0/3.3 V DC	RS: On/Off
	44	FEED1_SENS	O	0/3.3 V DC	PCS: On/Off
	45	BEND_SENS	O	0/3.3 V DC	RDS: On/Off
	46	MID_MOT_PH	I	0/3.3 V DC	MM control signal
	47	MID_MOT_REM(ROL_CL)	I	0/3.3 V DC	MM/MCL: On/Off
	48	MID_MOT_CLK	I	0/3.3 V DC (pulse)	MM clock signal
	49	MID_MOT_PD	I	0/3.3 V DC	MM control signal
50	ASIST_CL1	I	0/24 V DC	ASCL1: On/Off	
YC2 Connected to paper feed motor	1	FEED_MOT_GAIN	-	-	Not used
	2	FEED_MOT_DIR	O	0/3.3 V DC	PFM drive switch signal
	3	FEED_MOT_RDY	I	0/3.3 V DC	PFM ready signal
	4	FEED_MOT_CLK	O	0/3.3 V DC (pulse)	PFM clock signal
	5	FEED_MOT_REM	O	0/24 V DC	PFM: On/Off
	6	GND	-	-	Ground
	7	24V2	O	24 V DC	24 V DC power to PFM
YC3 Connected to paper length switch 1/2, paper width switch 1/2, lift motor 1/2, paper gauge sensor 1(U)/(L) and paper gauge sensor 2(U)/(L)	1	CAS1_LNG1	I	0/3.3 V DC	PLSW1: On/Off
	2	CAS1_LNG2	I	0/3.3 V DC	PLSW1: On/Off
	3	GND	-	-	Ground
	4	CAS1_LNG3	I	0/3.3 V DC	PLSW1: On/Off
	5	CAS1_WID	I	0/3.3 V DC	PWSW1: On/Off
	6	GND	-	-	Ground
	7	CAS2_LNG1	I	0/3.3 V DC	PLSW2: On/Off
	8	CAS2_LNG2	I	0/3.3 V DC	PLSW2: On/Off
	9	GND	-	-	Ground
	10	CAS2_LNG3	I	0/3.3 V DC	PLSW2: On/Off
	11	CAS2_WID	I	0/3.3 V DC	PWSW2: On/Off
	12	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC3	13	LIFT_MOT1_RET	O	0/24 V DC	LM1: On/Off
Connected to paper length switch 1/2, paper width switch 1/2, lift motor 1/2, paper gauge sensor 1(U)/(L) and paper gauge sensor 2(U)/(L)	14	LIFT_MOT1_DR	O	0/24 V DC	LM1: On/Off
	15	LIFT_MOT2_RET	O	0/24 V DC	LM2: On/Off
	16	LIFT_MOT2_DR	O	0/24 V DC	LM2: On/Off
	17	LED_5V	O	5 V DC	5 V DC power to PGS1(U)
	18	GND	-	-	Ground
	19	CAS1_QUANT1	I	0/3.3 V DC	PGS1(U): On/Off
	20	LED_5V	O	5 V DC	5 V DC power to PGS1(L)
	21	GND	-	-	Ground
	22	CAS1_QUANT2	I	0/3.3 V DC	PGS1(L): On/Off
	23	LED_5V	O	5 V DC	5 V DC power to PGS2(U)
	24	GND	-	-	Ground
	25	CAS2_QUANT1	I	0/3.3 V DC	PGS2(U): On/Off
	26	LED_5V	O	5 V DC	5 V DC power to PGS2(L)
	27	GND	-	-	Ground
	28	CAS2_QUANT2	I	0/3.3 V DC	PGS2(L): On/Off
YC4	1	FEED_CL1_REM	O	0/24 V DC	PFCL1: On/Off
Connected to paper feed clutch 1/2	2	24V2	O	24 V DC	PFCL124 V DC power to PFCL1
	3	FEED_CL2_REM	O	0/24 V DC	PFCL2: On/Off
	4	24V2	O	24 V DC	24 V DC power to PFCL2
YC5	1	NC	-	-	Not used
Connected to paper conveying clutch	2	24V2	O	24 V DC	24 V DC power to PCCL
	3	V-FEED_CL_REM	O	0/24 V DC	PCCL: On/Off
YC6	1	LED_5V	O	5 V DC	5 V DC power to PCS
Connected to paper conveying sensor and paper conveying cover switch	2	GND	-	-	Ground
	3	FEED2_SENS	I	0/3.3 V DC	PCS: On/Off
	4	COVER_OPEN	I	0/3.3 V DC	PCCSW: On/Off
	5	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC7 Connected to middle motor, middle sensor and registration sensor	1	MID_B/	O	0/24 V DC (pulse)	MM drive control signal
	2	MID_A/	O	0/24 V DC (pulse)	MM drive control signal
	3	MID_B	O	0/24 V DC (pulse)	MM drive control signal
	4	MID_A	O	0/24 V DC (pulse)	MM drive control signal
	5	-	-	-	-
	6	-	-	-	-
	7	-	-	-	-
	8	GND	-	-	Ground
	9	FEED1_SENS	I	0/3.3 V DC	MS: On/Off
	10	5V	O	5 V DC	5 V DC power to MS
	11	GND	-	-	Ground
	12	REG_SENS	I	0/3.3 V DC	RS: On/Off
	13	5V	O	5 V DC	5 V DC power to RS
	14	MID_CL_REM	O	0/24 V DC	MCL: On/Off
	15	24V2	O	24 V DC	24 V DC power to MCL
YC8 Connected to primary paper feed unit	1	24V2	O	24 V DC	24 V DC power to PUSOL1
	2	PICK_SOL1_REM	O	0/24 V DC	PUSOL1: On/Off (ACT)
	3	PICK_SOL1_RET	O	0/24 V DC	PUSOL1: On/Off (RET)
	4	LED_5V	O	5 V DC	5 V DC power to PS1
	5	GND	-	-	Ground
	6	CAS1_EMPTY_SENS	I	0/3.3 V DC	PS1: On/Off
	7	LED_5V	O	5 V DC	5 V DC power to LS1
	8	GND	-	-	Ground
	9	CAS1_LIFT_UP_SENS	I	0/3.3 V DC	LS1: On/Off
	10	5V	O	5 V DC	5 V DC power to FS1
	11	CAS1_P0_SENS	I	0/3.3 V DC	FS1: On/Off
	12	GND	-	-	Ground
	13	24V2	O	24 V DC	24 V DC power to PUSOL2
	14	PICK_SOL2_REM	O	0/24 V DC	PUSOL2: On/Off (ACT)
	15	PICK_SOL2_RET	O	0/24 V DC	PUSOL2: On/Off (RET)
	16	LED_5V	O	5 V DC	5 V DC power to PS2
	17	GND	-	-	Ground
	18	CAS2_EMPTY_SENS	I	0/3.3 V DC	PS2: On/Off
	19	LED_5V	O	5 V DC	5 V DC power to LS2

Connector	Pin	Signal	I/O	Voltage	Description
YC8	20	GND	-	-	Ground
Connected to primary paper feed unit	21	CAS2_LIFT_UP_SENS	I	0/3.3 V DC	LS2: On/Off
	22	5V	O	5 V DC	5 V DC power to FS2
	23	CAS2_P0_SENS	I	0/3.3 V DC	FS2: On/Off
	24	GND	-	-	Ground
YC10	1	ASIST_CL1	O	0/24 V DC	ASCL1: On/Off
Connected to assist clutch 1	2	24V2	O	24 V DC	24 V DC power to ASCL1
YC11	1	GND	-	-	Ground
Connected to feed PWB 1	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	+5V	O	5 V DC	5 V DC power to FPWB1
	5	+24V2	O	24 V DC	24 V DC power to FPWB1
	6	+24V2	O	24 V DC	24 V DC power to FPWB1
YC12	1	ASIST_CL2	O	0/24 V DC	ASCL2: On/Off
Connected to assist clutch 2	2	24V2	O	24 V DC	24 V DC power to ASCL2
YC13	1	CURRENT_SIG	I	0/3.3 V DC	Current signal
Connected to current PWB	2	GND	-	-	Ground
	3	5V1	I	5 V DC	5 V DC power from CRPWB

2-3-9 Relay PWB




Figure 2-3-10 Relay PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC1	1	5V_LED	-	-	Not used
Connected to feed PWB 1	2	DU2_A	I	0/24 V DC (pulse)	DUM2 drive control signal
	3	DU2_B	I	0/24 V DC (pulse)	DUM2 drive control signal
	4	DU2_A/	I	0/24 V DC (pulse)	DUM2 drive control signal
	5	DU2_B/	I	0/24 V DC (pulse)	DUM2 drive control signal
	6	DU_OPEN_SW	O	0/3.3 V DC	DUCSW: On/Off
	7	DU_CL_LOWER_REM	I	0/24 V DC	DUCL2: On/Off
	8	DU_FAN	-	-	Not used
	9	24V2	I	24 V DC	24 V DC power from FPWB1
	10	PRESS_RLS_REM2	I	0/24 V DC	TRRM: On/Off
	11	PRESS_RLS_REM1	I	0/24 V DC	TRRM: On/Off
	12	5V	I	5 V DC	5 V DC power from FPWB1
	13	PRESS_RLS_SENS	O	0/3.3 V DC	TRRS: On/Off
	14	DU_SENS	O	0/3.3 V DC	DUS2: On/Off
	15	BELT_JAM_SENS	-	-	Not used
	16	REG_BK_SENS1_S	-	-	Not used
	17	REG_BK_SENS1_P	-	-	Not used
	18	REG_BK_LED	-	-	Not used
YC2	1	GND	-	-	Ground
Connected to MP tray unit	2	MPF_LNG	I	0/3.3 V DC	MPPLSW: On/Off
	3	5V	O	5 V DC	5 V DC power to MPPLSW
	4	MPF_WID3	I	0/3.3 V DC	MPPWSW: On/Off
	5	MPF_WID2	I	0/3.3 V DC	MPPWSW: On/Off
	6	GND	-	-	Ground
	7	MPF_WID1	I	0/3.3 V DC	MPPWSW: On/Off
	8	GND	-	-	Ground
	9	MPF_TABLE	I	0/3.3 V DC	MPTSW: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC3	1	LED_3.3V3	O	3.3 V DC	3.3 V DC power to MPPLSW
Connected to MP tray unit	2	GND	-	-	Ground
	3	MPF_PPR_SET	I	0/3.3 V DC	MPPS: On/Off
	4	GND	-	-	Ground
	5	MPF_LIFT_UP_SENS	I	0/3.3 V DC	MPLS1: On/Off
	6	5V	O	5 V DC	5 V DC power to MPLS1
	7	GND	-	-	Ground
	8	MPF_LIFT_DOWN_SENS	I	0/3.3 V DC	MPLS2: On/Off
	9	5V	O	5 V DC	5 V DC power to MPLS1
	10	GND	-	-	Ground
	11	MPF_JAM_SENS	I	0/3.3 V DC	MPFS: On/Off
	12	5V	O	5 V DC	5 V DC power to MPFS
	13	MPF_CL_REM	O	0/24 V DC	MPPFCL: On/Off
	14	24V2	O	24 V DC	24 V DC power to MPPFCL
	15	MPF_LIFT_DR_A	O	0/24 V DC	MPLM: On/Off
	16	MPF_LIFT_DR_B	O	0/24 V DC	MPLM: On/Off
YC7	1	24V2	O	24 V DC	24 V DC power to DUCL2
Connected to duplex clutch 2, duplex cover switch and duplex motor 2	2	DU_CL2_REM	O	0/24 V DC	DUCL2: On/Off
	3	DU_OPEN	I	0/3.3 V DC	DUCSW: On/Off
	4	GND	-	-	Ground
	5	DU2_B/	O	0/24 V DC (pulse)	DUM2 drive control signal
	6	DU2_A/	O	0/24 V DC (pulse)	DUM2 drive control signal
	7	DU2_B	O	0/24 V DC (pulse)	DUM2 drive control signal
	8	DU2_A	O	0/24 V DC (pulse)	DUM2 drive control signal
YC9	1	GND	-	-	Ground
Connected to duplex sensor 2	2	DU_SENS	I	0/3.3 V DC	DUS2: On/Off
	3	5V	O	5 V DC	5 V DC power to DUS2

Connector	Pin	Signal	I/O	Voltage	Description
YC10 Connected to loop sensor	1	LOOP_SENS	I	0/3.3 V DC	LPS: On/Off
	2	GND	-	-	Ground
	3	5V	O	5 V DC	5 V DC power to LPS
	4	3.3V	-	-	Not used
	5	REG_BK_LED	-	-	Not used
	6	GND	-	-	Not used
	7	REG_BK_SENS1_P	-	-	Not used
	8	REG_BK_SENS1_S	-	-	Not used
	9	GND	-	-	Not used
	10	BELT_JAM_SENS	-	-	Not used
	11	5V	-	-	Not used
YC11 Connected to duplex sensor 1, eject fan motor and duplex clutch 1	1	GND	-	-	Ground
	2	DU_ENTER_SENS	I	0/3.3 V DC	DUS1: On/Off
	3	5V	O	5 V DC	5 V DC power to DUS1
	4	EXIT_FAN_REM	O	0/24 V DC	EFM1: On/Off
	5	24V2	O	24 V DC	24 V DC power to EFM1
	6	EXIT_FAN_REM	O	0/24 V DC	EFM2: On/Off
	7	24V2	O	24 V DC	24 V DC power to EFM2
	8	24V2	O	24 V DC	24 V DC power to DUCL1
	9	DU_CL_UPPER_REM	O	0/24 V DC	DUCL1: On/Off
YC12 Connected to feed PWB 1	1	GND	-	-	Ground
	2	GND	-	-	Ground
	3	MPF_TABLE	O	0/3.3 V DC	MPTSW: On/Off
	4	MPF_WID1	O	0/3.3 V DC	MPPWSW: On/Off
	5	MPF_WID2	O	0/3.3 V DC	MPPWSW: On/Off
	6	MPF_WID3	O	0/3.3 V DC	MPPWSW: On/Off
	7	MPF_LNG	O	0/3.3 V DC	MPPLSW: On/Off
	8	LED_3.3V3	I	3.3 V DC	3.3 V DC power from FPWB1
	9	MPF_PPR_SET	O	0/3.3 V DC	MPPS: On/Off
	10	MPF_LIFT_UP_SENS	O	0/3.3 V DC	MPLS1: On/Off
	11	MPF_LIFT_DOWN_SENS	O	0/3.3 V DC	MPLS2: On/Off
	12	MPF_JAM_SENS	O	0/3.3 V DC	MPFS: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC12 Connected to feed PWB 1	13	MPF_CL_REM	I	0/24 V DC	MPPFCL: On/Off
	14	24V2	I	24 V DC	24 V DC power from FPWB1
	15	MPF_LIFT_MOT_A	I	0/24 V DC	MPLM: On/Off
	16	MPF_LIFT_MOT_B	I	0/24 V DC	MPLM: On/Off
	17	TC_TONER_MOT_A	-	-	Not used
	18	TC_TONER_MOT_B	-	-	Not used
	19	TC_TONER_FUL L	-	-	Not used
	20	TC_TONER_LED	-	-	Not used
YC13 Connected to feed PWB 1	1	3.3V	I	3.3 V DC	3.3 V DC power from FPWB1
	2	LOOP_SENS	O	0/3.3 V DC	LPS: On/Off
	3	EDGE_FAN_REM	I	0/24 V DC	FUFM: On/Off
	4	DU1_A	I	0/24 V DC (pulse)	DUM1 drive control signal
	5	DU1_B	I	0/24 V DC (pulse)	DUM1 drive control signal
	6	DU1_A/	I	0/24 V DC (pulse)	DUM1 drive control signal
	7	DU1_B/	I	0/24 V DC (pulse)	DUM1 drive control signal
	8	GND	-	-	Ground
	9	DU_CL_UPPER_REM	I	0/24 V DC	DUCL1: On/Off
	10	24V2	I	24 V DC	24 V DC power from FPWB1
	11	EXIT_FAN	I	0/24 V DC	EFM: On/Off
	12	DU_ENTER_SENS	O	0/3.3 V DC	DUS1: On/Off
YC14 Connected to transfer release sensor and transfer release motor	1	GND	-	-	Ground
	2	PRESS_RLS_SENS	I	0/3.3 V DC	TRRS: On/Off
	3	5V	O	5 V DC	5 V DC power to TRRS
	4	PRESS_RLS_REM1	O	0/24 V DC	TRRM: On/Off
	5	PRESS_RLS_REM2	O	0/24 V DC	TRRM: On/Off
	6	NC	-	-	Not used

Connector	Pin	Signal	I/O	Voltage	Description
YC16	1	DU1_B/	O	0/24 V DC (pulse)	DUM1 drive control signal
Connected to duplex motor 1 and fuser fan motor 1/2	2	DU1_A/	O	0/24 V DC (pulse)	DUM1 drive control signal
	3	DU1_B	O	0/24 V DC (pulse)	DUM1 drive control signal
	4	DU1_A	O	0/24 V DC (pulse)	DUM1 drive control signal
	5	EDGE_FAN_REM	O	0/24 V DC	FUFM1: On/Off
	6	24V2	O	24 V DC	24 V DC power to FUFM1
	7	EDGE_FAN_REM	O	0/24 V DC	FUFM2: On/Off
	8	24V2	O	24 V DC	24 V DC power to FUFM2

2-3-10 Motor control PWB




Figure 2-3-11 Motor control PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC2 Connected to power source PWB	1	GND	-	-	Ground
	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	+24V1	I	24 V DC	24 V DC power from PSPWB
	5	+24V1	I	24 V DC	24 V DC power from PSPWB
	6	+24V1	I	24 V DC	24 V DC power from PSPWB
YC3 Connected to engine PWB	1	DRM_INDEX_C	I	0/3.3 V DC	DRM-C control signal
	2	DRM_INDEX_M	I	0/3.3 V DC	DRM-M control signal
	3	DRM_INDEX_BK	I	0/3.3 V DC	DRM-K control signal
	4	BLT_INDEX	-	-	Not used
	5	BLT_SPEED	I	0/3.3 V DC	TBLS: On/Off
	6	EMERGENCY	I	0/3.3 V DC	MCPWB control signal
	7	ENG_RDY	O	0/3.3 V DC	MCPWB ready signal
	8	ENG_SDO	O	0/3.3 V DC (pulse)	MCPWB serial communication data signal
	9	ENG_SEL	I	0/3.3 V DC	MCPWB select signal
	10	ENG_SDI	I	0/3.3 V DC (pulse)	MCPWB serial communication data signal
	11	ENG_CLK	I	0/3.3 V DC (pulse)	MCPWB clock signal
	12	BLT_FG	-	-	Not used
	13	MOT_ON	I	0/3.3 V DC	MCPWB control signal
	14	MOT_DATA_SET	I	0/3.3 V DC	MCPWB control signal
	15	BLT_REM	-	-	Not used
	16	BLT_VM	-	-	Not used
	17	BLT_BRAKE	-	-	Not used
	18	+5V	I	5 V DC	5 V DC power to MCPWB
	19	+5V	I	5 V DC	5 V DC power to MCPWB
	20	GND	-	-	Ground
	21	GND	-	-	Ground
	22	DRM_INDEX_Y	I	0/3.3 V DC	DRM-Y control signal

Connector	Pin	Signal	I/O	Voltage	Description
YC4	1	NC	-	-	Not used
Connected to drum motor C/Y	2	NC	-	-	Not used
	3	NC	-	-	Not used
	4	NC	-	-	Not used
	5	NC	-	-	Not used
	6	NC	-	-	Not used
	7	NC	-	-	Not used
	8	NC	-	-	Not used
	9	DRM_C_BRAKE	-	-	Not used
	10	DRM_Y_BRAKE	-	-	Not used
	11	DRM_C_GAIN	-	-	Not used
	12	DRM_Y_GAIN	-	-	Not used
	13	DRM_C_CW/ CCW	O	0/24 V DC	DRM-C: On/Off
	14	DRM_Y_CW/ CCW	O	0/24 V DC	DRM-Y: On/Off
	15	DRM_C_LD	O	0/3.3 V DC	DRM-C control signal
	16	DRM_Y_LD	O	0/3.3 V DC	DRM-Y control signal
	17	DRM_C_CLK	O	0/3.3 V DC (pulse)	DRM-C clock signal
	18	DRM_Y_CLK	O	0/3.3 V DC (pulse)	DRM-Y clock signal
	19	DRM_C_S/S	O	0/3.3 V DC	DRM-C control signal
	20	DRM_Y_S/S	O	0/3.3 V DC	DRM-Y control signal
	21	PGND	-	-	Ground
	22	PGND	-	-	Ground
	23	+24V1	O	24 V DC	24 V DC power to DRM-C
	24	+24V1	O	24 V DC	24 V DC power to DRM-Y
YC5	1	NC	-	-	Not used
Connected to drum motor K/M	2	NC	-	-	Not used
	3	NC	-	-	Not used
	4	NC	-	-	Not used
	5	NC	-	-	Not used
	6	NC	-	-	Not used
	7	NC	-	-	Not used
	8	NC	-	-	Not used
	9	DRM_BK_BRAKE	-	-	Not used
	10	DRM_M_BRAKE	-	-	Not used
	11	DRM_BK_GAIN	-	-	Not used

Connector	Pin	Signal	I/O	Voltage	Description
YC5	12	DRM_M_GAIN	-	-	Not used
Connected to drum motor K/M	13	DRM_BK_CW/CCW	O	0/24 V DC	DRM-K: On/Off
	14	DRM_M_CW/CCW	O	0/24 V DC	DRM-M: On/Off
	15	DRM_BK_LD	O	0/3.3 V DC	DRM-K control signal
	16	DRM_M_LD	O	0/3.3 V DC	DRM-M control signal
	17	DRM_BK_CLK	O	0/3.3 V DC (pulse)	DRM-K clock signal
	18	DRM_M_CLK	O	0/3.3 V DC (pulse)	DRM-M clock signal
	19	DRM_BK_S/S	O	0/3.3 V DC	DRM-K control signal
	20	DRM_M_S/S	O	0/3.3 V DC	DRM-M control signal
	21	PGND	-	-	Ground
	22	PGND	-	-	Ground
	23	+24V1	O	24 V DC	24 V DC power to DRM-K
	24	+24V1	O	24 V DC	24 V DC power to DRM-M
YC7	1	DLP_M_GAIN	-	-	Not used
Connected to developer motor MCY/K	2	DLP_M_CW/CCW	O	0/24 V DC	DEVM-MCY: On/Off
	3	DLP_M_LD	O	0/3.3 V DC	DEVM-MCY control signal
	4	DLP_M_CLK	O	0/3.3 V DC (pulse)	DEVM-MCY clock signal
	5	DLP_M_S/S	O	0/3.3 V DC	DEVM-MCY control signal
	6	PGND	-	-	Ground
	7	+24V1	O	24 V DC	24 V DC power to DEVM-MCY
	8	DLP_BK_GAIN	-	-	Not used
	9	DLP_BK_CW/CCW	O	0/24 V DC	DEVM-K: On/Off
	10	DLP_BK_LD	O	0/3.3 V DC	DEVM-K control signal
	11	DLP_BK_CLK	O	0/3.3 V DC (pulse)	DEVM-K clock signal
	12	DLP_BK_S/S	O	0/3.3 V DC	DEVM-K control signal
	13	PGND	-	-	Ground
	14	+24V1	O	24 V DC	24 V DC power to DEVM-K

2-3-11 LSU relay PWB




Figure 2-3-12 LSU relay PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC1 Connected to power source PWB and engine PWB	1	+24V1	O	24 V DC	24 V DC power from PSPWB
	2	+24V1	O	24 V DC	24 V DC power from PSPWB
	3	GND	-	-	Ground
	4	GND	-	-	Ground
	5	+5V1	O	5 V DC	5 V DC power from EPWB
	6	+5V1	O	5 V DC	5 V DC power from EPWB
	7	GND	-	-	Ground
	8	GND	-	-	Ground
	9	+3.3V2	O	3.3 V DC	3.3 V DC power from EPWB
	10	GND	-	-	Ground
YC2 Connected to engine PWB	1	SGND	-	-	Ground
	2	CLK	I	0/3.3 V DC (pulse)	Clock signal
	3	SGND	-	-	Ground
	4	SDI	O	0/3.3 V DC (pulse)	Serial communication data signal
	5	SGND	-	-	Ground
	6	SDO	I	0/3.3 V DC (pulse)	Serial communication data signal
	7	SGND	-	-	Ground
	8	MSET_N	I	0/3.3 V DC	Control signal
	9	SGND	-	-	Ground
	10	LDD_CS 1 Y	I	0/3.3 V DC	APCPWB-Y control signal
	11	EEPROM CS Y	I/O	0/3.3 V DC (pulse)	APCPWB-Y EEPROM data signal
	12	LDD_CS 1 C	I	0/3.3 V DC	APCPWB-C control signal
	13	EEPROM CS C	I/O	0/3.3 V DC (pulse)	APCPWB-C EEPROM data signal
	14	LDD_CS 1 M	I	0/3.3 V DC	APCPWB-M control signal
	15	EEPROM CS M	I/O	0/3.3 V DC (pulse)	APCPWB-M EEPROM data signal
	16	LDD_CS 2 Bk	I	0/3.3 V DC	APCPWB-K control signal
	17	EEPROM CS 2 Bk	I/O	0/3.3 V DC (pulse)	APCPWB-K EEPROM data signal
	18	LDD_CS 1 Bk	I	0/3.3 V DC	APCPWB-K control signal
	19	EEPROM CS 1 Bk	I/O	0/3.3 V DC (pulse)	APCPWB-K EEPROM data signal
	20	SGND	-	-	Ground
	21	INT_ST 1 Y	I	0/3.3 V DC	APCPWB-Y control signal
	22	PALA_SIG P0 Y	I	0/3.3 V DC	APCPWB-Y control signal
	23	PALA_SIG P1 Y	I	0/3.3 V DC	APCPWB-Y control signal
	24	PALA_SIG P2 Y	I	0/3.3 V DC	APCPWB-Y control signal
	25	GAIN FIX Y	I	0/3.3 V DC	APCPWB-Y control signal
	26	SGND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC2	27	DATA_2N_Y(LVDS)	I	0/3.3 V DC (pulse)	Video data signal Y (N)
Connected to engine PWB	28	DATA_2P_Y(LVDS)	I	0/3.3 V DC (pulse)	Video data signal Y (P)
	29	SGND	-	-	Ground
	30	INT_ST 1 C	I	0/3.3 V DC	APCPWB-C control signal
	31	PALA_SIG P0 C	I	0/3.3 V DC	APCPWB-C control signal
	32	PALA_SIG P1 C	I	0/3.3 V DC	APCPWB-C control signal
	33	PALA_SIG P2 C	I	0/3.3 V DC	APCPWB-C control signal
	34	GAIN FIX C	I	0/3.3 V DC	APCPWB-C control signal
	35	SGND	-	-	Ground
	36	DATA_2N_C(LVDS)	I	0/3.3 V DC (pulse)	Video data signal C (N)
	37	DATA_2P_C(LVDS)	I	0/3.3 V DC (pulse)	Video data signal C (P)
	38	SGND	-	-	Ground
	39	INT_ST 1 M	I	0/3.3 V DC	APCPWB-M control signal
	40	PALA_SIG P0 M	I	0/3.3 V DC	APCPWB-M control signal
	41	PALA_SIG P1 M	I	0/3.3 V DC	APCPWB-M control signal
	42	PALA_SIG P2 M	I	0/3.3 V DC	APCPWB-M control signal
	43	GAIN FIX M	I	0/3.3 V DC	APCPWB-M control signal
	44	SGND	-	-	Ground
	45	DATA_2N_M(LVDS)	I	0/3.3 V DC (pulse)	Video data signal M (N)
	46	DATA_2P_M(LVDS)	I	0/3.3 V DC (pulse)	Video data signal M (P)
	47	SGND	-	-	Ground
	48	DATA_3NBk(LVDS)	I	0/3.3 V DC (pulse)	Video data signal K (N)
	49	DATA_3PBk(LVDS)	I	0/3.3 V DC (pulse)	Video data signal K (P)
	50	SGND	-	-	Ground
	51	DATA_4NBk(LVDS)	I	0/3.3 V DC (pulse)	Video data signal K (N)
	52	DATA_4PBk(LVDS)	I	0/3.3 V DC (pulse)	Video data signal K (P)
	53	SGND	-	-	Ground
	54	PALA_SIG P3_2Bk	I	0/3.3 V DC	APCPWB-K control signal

Connector	Pin	Signal	I/O	Voltage	Description
YC2	55	INT_ST 2 Bk	I	0/3.3 V DC	APCPWB-K control signal
Connected to engine PWB	56	INT_ST 1 Bk	I	0/3.3 V DC	APCPWB-K control signal
	57	PALA_SIG P0 Bk	I	0/3.3 V DC	APCPWB-K control signal
	58	PALA_SIG P1 Bk	I	0/3.3 V DC	APCPWB-K control signal
	59	PALA_SIG P2 Bk	I	0/3.3 V DC	APCPWB-K control signal
	60	GAIN FIX Bk	I	0/3.3 V DC	APCPWB-K control signal
	61	SGND	-	-	Ground
	62	DATA_2NBk(LVD S)	I	0/3.3 V DC (pulse)	Video data signal K (N)
	63	DATA_2PBk(LVD S)	I	0/3.3 V DC (pulse)	Video data signal K (P)
	64	SGND	-	-	Ground
YC3	1	SGND	-	-	Ground
Connected to engine PWB	2	BD Y	O	0/3.3 V DC (pulse)	Horizontal synchronization signal Y
	3	LSU_TH Y	O	Analog	LSU thermistor Y detection signal
	4	CUALM Y	O	0/3.3 V DC	APCPWB-Y alarm signal
	5	PALA_SIG P3 Y	I	0/3.3 V DC	APCPWB-Y control signal
	6	PALA_SIG P4 Y	I	0/3.3 V DC	APCPWB-Y control signal
	7	SGND	-	-	Ground
	8	SDCLK Y	I	0/3.3 V DC (pulse)	APCPWB-Y clock signal
	9	SGND	-	-	Ground
	10	DATA_1N_Y(LVD S)	I	0/3.3 V DC (pulse)	Video data signal Y (N)
	11	DATA_1P_Y(LVD S)	I	0/3.3 V DC (pulse)	Video data signal Y (P)
	12	SGND	-	-	Ground
	13	REM Y	I	0/24 V DC	PM-Y: On/Off
	14	LOCK Y	O	0/3.3 V DC	PM-Y lock signal
	15	CLK Y	I	0/3.3 V DC (pulse)	PM-Y clock signal
	16	SGND	-	-	Ground
	17	BD C	O	0/3.3 V DC (pulse)	Horizontal synchronization signal C
	18	LSU_TH C	O	Analog	LSU thermistor C detection signal
	19	CUALM C	O	0/3.3 V DC	APCPWB-C alarm signal
	20	PALA_SIG P3 C	I	0/3.3 V DC	APCPWB-C control signal
	21	PALA_SIG P4 C	I	0/3.3 V DC	APCPWB-C control signal
	22	SGND	-	-	Ground
	23	SDCLK C	I	0/3.3 V DC (pulse)	APCPWB-C clock signal
	24	SGND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC3	25	DATA_1N_C(LVDS)	I	0/3.3 V DC (pulse)	Video data signal C (N)
Connected to engine PWB	26	DATA_1P_C(LVDS)	I	0/3.3 V DC (pulse)	Video data signal C (P)
	27	SGND	-	-	Ground
	28	REM C	I	0/24 V DC	PM-C: On/Off
	29	LOCK C	O	0/3.3 V DC	PM-C lock signal
	30	CLK C	I	0/3.3 V DC (pulse)	PM-C clock signal
	31	SGND	-	-	Ground
	32	BD M	O	0/3.3 V DC (pulse)	Horizontal synchronization signal M
	33	LSU_TH M	O	Analog	LSU thermistor M detection signal
	34	CUALM M	O	0/3.3 V DC	APCPWB-M alarm signal
	35	PALA_SIG P3 M	I	0/3.3 V DC	APCPWB-M control signal
	36	PALA_SIG P4 M	I	0/3.3 V DC	APCPWB-M control signal
	37	SGND	-	-	Ground
	38	SDCLK M	I	0/3.3 V DC (pulse)	APCPWB-M clock signal
	39	SGND	-	-	Ground
	40	DATA_1N_M(LVDS)	I	0/3.3 V DC (pulse)	Video data signal M (N)
	41	DATA_1P_M(LVDS)	I	0/3.3 V DC (pulse)	Video data signal M (P)
	42	SGND	-	-	Ground
	43	REM M	I	0/24 V DC	PM-M: On/Off
	44	LOCK M	O	0/3.3 V DC	PM-M lock signal
	45	CLK M	I	0/3.3 V DC (pulse)	PM-M clock signal
	46	SGND	-	-	Ground
	47	BD Bk	O	0/3.3 V DC (pulse)	Horizontal synchronization signal K
	48	LSU_TH Bk	O	Analog	LSU thermistor K detection signal
	49	CUALM Bk	O	0/3.3 V DC	APCPWB-K alarm signal
	50	PALA_SIG P3 Bk	I	0/3.3 V DC	APCPWB-K control signal
	51	PALA_SIG P4 Bk	I	0/3.3 V DC	APCPWB-K control signal
	52	SGND	-	-	Ground
	53	SDCLK Bk	I	0/3.3 V DC (pulse)	APCPWB-K clock signal
	54	SGND	-	-	Ground
	55	DATA_1NBk(LVDS)	I	0/3.3 V DC (pulse)	Video data signal K (N)
	56	DATA_1PBk(LVDS)	I	0/3.3 V DC (pulse)	Video data signal K (P)

Connector	Pin	Signal	I/O	Voltage	Description
YC3 Connected to engine PWB	57	SGND	-	-	Ground
	58	REM Bk	I	0/24 V DC	PM-K: On/Off
	59	LOCK Bk	O	0/3.3 V DC	PM-K lock signal
	60	CLK Bk	I	0/3.3 V DC (pulse)	PM-K clock signal
YC4 Connected to polygon motor K	1	24V	O	24 V DC	24 V DC power to PM-K
	2	PGND	-	-	Ground
	3	REM Bk	O	0/24 V DC	PM-K: On/Off
	4	LOCK Bk	I	0/3.3 V DC	PM-K lock signal
	5	CLK Bk	O	0/3.3 V DC (pulse)	PM-K clock signal
YC5 Connected to APC PWB K	1	SGND	-	-	Ground
	2	BD Bk	I	0/3.3 V DC (pulse)	Horizontal synchronization signal K
	3	LSU_TH Bk	I	Analog	LSU thermistor K detection signal
	4	PALA_SIG P3_2Bk	-	-	Not used
	5	LDD_CS 2 Bk	-	-	Not used
	6	5V	O	5 V DC	5 V DC power to APCPWB-K
	7	5V	O	5 V DC	5 V DC power to APCPWB-K
	8	5V	O	5 V DC	5 V DC power to APCPWB-K
	9	LDD_CS 1 Bk	O	0/3.3 V DC	APCPWB-K control signal
	10	SDI1	I	0/3.3 V DC (pulse)	Serial communication data signal
	11	SDO1	O	0/3.3 V DC (pulse)	Serial communication data signal
	12	CLK1	O	0/3.3 V DC (pulse)	APCPWB-K clock signal
	13	EEPROM CS 1 Bk	I/O	0/3.3 V DC (pulse)	APCPWB-K EEPROM data signal
	14	MSET_N	O	0/3.3 V DC	APCPWB-K control signal
	15	CUALM Bk	I	0/3.3 V DC	APCPWB-K alarm signal
	16	INT_ST 2 Bk	O	0/3.3 V DC	APCPWB-K control signal
	17	INT_ST 1 Bk	O	0/3.3 V DC	APCPWB-K control signal
	18	PALA_SIG P0 Bk	O	0/3.3 V DC	APCPWB-K control signal
	19	PALA_SIG P1 Bk	O	0/3.3 V DC	APCPWB-K control signal
	20	PALA_SIG P2 Bk	O	0/3.3 V DC	APCPWB-K control signal
	21	PALA_SIG P3 Bk	O	0/3.3 V DC	APCPWB-K control signal
	22	PALA_SIG P4 Bk	O	0/3.3 V DC	APCPWB-K control signal
	23	SDCLK Bk	O	0/3.3 V DC (pulse)	APCPWB-K clock signal
	24	GAIN FIX Bk	O	0/3.3 V DC	APCPWB-K control signal
	25	DATA_1NBk(LVD S)	O	0/3.3 V DC (pulse)	Video data signal K (N)
	26	DATA_1PBk(LVD S)	O	0/3.3 V DC (pulse)	Video data signal K (P)

Connector	Pin	Signal	I/O	Voltage	Description
YC5	27	SGND	-	-	Ground
Connected to APC PWB K	28	DATA_2NBk(LVD S)	O	0/3.3 V DC (pulse)	Video data signal K (N)
	29	DATA_2PBk(LVD S)	O	0/3.3 V DC (pulse)	Video data signal K (P)
	30	SGND	-	-	Ground
YC7	1	24V	O	24 V DC	24 V DC power to PM-M
Connected to polygon motor M	2	PGND	-	-	Ground
	3	REM M	O	0/24 V DC	PM-M: On/Off
	4	LOCK M	I	0/3.3 V DC	PM-M lock signal
	5	CLK M	O	0/3.3 V DC (pulse)	PM-M clock signal
YC8	1	SGND	-	-	Ground
Connected to APC PWB M	2	BD M	I	0/3.3 V DC (pulse)	Horizontal synchronization signal M
	3	LSU_TH M	I	Analog	LSU thermistor M detection signal
	4	-	-	-	Not used
	5	-	-	-	Not used
	6	5V	O	5 V DC	5 V DC power to APCPWB-M
	7	5V	O	5 V DC	5 V DC power to APCPWB-M
	8	5V	O	5 V DC	5 V DC power to APCPWB-M
	9	LDD_CS 1 M	O	0/3.3 V DC	APCPWB-M control signal
	10	SDI1	I	0/3.3 V DC (pulse)	Serial communication data signal
	11	SDO1	O	0/3.3 V DC (pulse)	Serial communication data signal
	12	CLK1	O	0/3.3 V DC (pulse)	APCPWB-M clock signal
	13	EEPROM CS M	I/O	0/3.3 V DC (pulse)	APCPWB-M EEPROM data signal
	14	MSET_N	O	0/3.3 V DC	APCPWB-M control signal
	15	CUALM M	I	0/3.3 V DC	APCPWB-M alarm signal
	16	-	-	-	-
	17	INT_ST 1 M	O	0/3.3 V DC	APCPWB-M control signal
	18	PALA_SIG P0 M	O	0/3.3 V DC	APCPWB-M control signal
	19	PALA_SIG P1 M	O	0/3.3 V DC	APCPWB-M control signal
	20	PALA_SIG P2 M	O	0/3.3 V DC	APCPWB-M control signal
	21	PALA_SIG P3 M	O	0/3.3 V DC	APCPWB-M control signal
	22	PALA_SIG P4 M	O	0/3.3 V DC	APCPWB-M control signal
	23	SDCLK M	O	0/3.3 V DC (pulse)	APCPWB-M clock signal
	24	GAIN FIX M	O	0/3.3 V DC	APCPWB-M control signal
	25	DATA_1N_M(LVD S)	O	0/3.3 V DC (pulse)	Video data signal M (N)

Connector	Pin	Signal	I/O	Voltage	Description
YC8	26	DATA_1P_M(LVDS)	O	0/3.3 V DC (pulse)	Video data signal M (P)
Connected to APC PWB M	27	SGND	-	-	Ground
	28	DATA_2N_M(LVDS)	O	0/3.3 V DC (pulse)	Video data signal M (N)
	29	DATA_2P_M(LVDS)	O	0/3.3 V DC (pulse)	Video data signal M (P)
	30	SGND	-	-	Ground
YC9	1	24V	O	24 V DC	24 V DC power to PM-C
Connected to polygon motor C	2	PGND	-	-	Ground
	3	REM C	O	0/24 V DC	PM-C: On/Off
	4	LOCK C	I	0/3.3 V DC	PM-C lock signal
	5	CLK C	O	0/3.3 V DC (pulse)	PM-C clock signal
YC10	1	SGND	-	-	Ground
Connected to APC PWB C	2	BD C	I	0/3.3 V DC (pulse)	Horizontal synchronization signal C
	3	LSU_TH C	I	Analog	LSU thermistor C detection signal
	4	-	-	-	Not used
	5	-	-	-	Not used
	6	5V	O	5 V DC	5 V DC power to APCPWB-C
	7	5V	O	5 V DC	5 V DC power to APCPWB-C
	8	5V	O	5 V DC	5 V DC power to APCPWB-C
	9	LDD_CS 1 C	O	0/3.3 V DC	APCPWB-C control signal
	10	SDI1	I	0/3.3 V DC (pulse)	Serial communication data signal
	11	SDO1	O	0/3.3 V DC (pulse)	Serial communication data signal
	12	CLK1	O	0/3.3 V DC (pulse)	APCPWB-C clock signal
	13	EEPROM CS C	I/O	0/3.3 V DC (pulse)	APCPWB-C EEPROM data signal
	14	MSET_N	O	0/3.3 V DC	APCPWB-C control signal
	15	CUALM C	I	0/3.3 V DC	APCPWB-C alarm signal
	16	-	-	-	-
	17	INT_ST 1 C	O	0/3.3 V DC	APCPWB-C control signal
	18	PALA_SIG P0 C	O	0/3.3 V DC	APCPWB-C control signal
	19	PALA_SIG P1 C	O	0/3.3 V DC	APCPWB-C control signal
	20	PALA_SIG P2 C	O	0/3.3 V DC	APCPWB-C control signal
	21	PALA_SIG P3 C	O	0/3.3 V DC	APCPWB-C control signal
	22	PALA_SIG P4 C	O	0/3.3 V DC	APCPWB-C control signal
	23	SDCLK C	O	0/3.3 V DC (pulse)	APCPWB-C clock signal
	24	GAIN FIX C	O	0/3.3 V DC	APCPWB-C control signal

Connector	Pin	Signal	I/O	Voltage	Description	
YC10	25	DATA_1N_C(LVDS)	O	0/3.3 V DC (pulse)	Video data signal C (N)	
	Connected to APC PWB C	26	DATA_1P_C(LVDS)	O	0/3.3 V DC (pulse)	Video data signal C (P)
		27	SGND	-	-	Ground
		28	DATA_2N_C(LVDS)	O	0/3.3 V DC (pulse)	Video data signal C (N)
		29	DATA_2P_C(LVDS)	O	0/3.3 V DC (pulse)	Video data signal C (P)
		30	SGND	-	-	Ground
YC11	1	24V	O	24 V DC	24 V DC power to PM-Y	
	Connected to polygon motor Y	2	PGND	-	-	Ground
		3	REM Y	O	0/24 V DC	PM-Y: On/Off
		4	LOCK Y	I	0/3.3 V DC	PM-Y lock signal
		5	CLK Y	O	0/3.3 V DC (pulse)	PM-Y clock signal
YC12	1	SGND	-	-	Ground	
	Connected to APC PWB Y	2	BD Y	I	0/3.3 V DC (pulse)	Horizontal synchronization signal Y
		3	LSU_TH Y	I	Analog	LSU thermistor Y detection signal
		4	-	-	-	Not used
		5	-	-	-	Not used
		6	5V	O	5 V DC	5 V DC power to APCPWB-Y
		7	5V	O	5 V DC	5 V DC power to APCPWB-Y
		8	5V	O	5 V DC	5 V DC power to APCPWB-Y
		9	LDD_CS 1 Y	O	0/3.3 V DC	APCPWB-Y control signal
		10	SDI1	I	0/3.3 V DC (pulse)	Serial communication data signal
		11	SDO1	O	0/3.3 V DC (pulse)	Serial communication data signal
		12	CLK1	O	0/3.3 V DC (pulse)	APCPWB-Y clock signal
		13	EEPROM CS Y	I/O	0/3.3 V DC (pulse)	APCPWB-Y EEPROM data signal
		14	MSET_N	O	0/3.3 V DC	APCPWB-Y control signal
		15	CUALM Y	I	0/3.3 V DC	APCPWB-Y alarm signal
		16	-	-	-	-
		17	INT_ST 1 Y	O	0/3.3 V DC	APCPWB-Y control signal
		18	PALA_SIG P0 Y	O	0/3.3 V DC	APCPWB-Y control signal
		19	PALA_SIG P1 Y	O	0/3.3 V DC	APCPWB-Y control signal
		20	PALA_SIG P2 Y	O	0/3.3 V DC	APCPWB-Y control signal
		21	PALA_SIG P3 Y	O	0/3.3 V DC	APCPWB-Y control signal
		22	PALA_SIG P4 Y	O	0/3.3 V DC	APCPWB-Y control signal
		23	SDCLK Y	O	0/3.3 V DC (pulse)	APCPWB-Y clock signal

Connector	Pin	Signal	I/O	Voltage	Description
YC12	24	GAIN FIX Y	O	0/3.3 V DC	APCPWB-Y control signal
Connected to APC PWB Y	25	DATA_1N_Y(LVDS)	O	0/3.3 V DC (pulse)	Video data signal Y (N)
	26	DATA_1P_Y(LVDS)	O	0/3.3 V DC (pulse)	Video data signal Y (P)
	27	SGND	-	-	Ground
	28	DATA_2N_Y(LVDS)	O	0/3.3 V DC (pulse)	Video data signal Y (N)
	29	DATA_2P_Y(LVDS)	O	0/3.3 V DC (pulse)	Video data signal Y (P)
	30	SGND	-	-	Ground

2-4-1 Appendixes

(1) List of maintenance parts

30 ppm model/35 ppm model

Maintenance part name		Part No.	Alternative part No.
Name used in service manual	Name used in parts list		
Paper feed pulley	PULLEY FEED ASSY	302F906230	2F906230
Separation pulley	RETARD ROLLER ASSY	302F909171	2F909171
Forwarding pulley	PULLEY PICKUP ASSY	302HN06080	2HN06080
Contact glass for Metric	PARTS CONTACT-GLASS ASSY(C) SP	302K994040	2K994040
	PARTS CONTACT-GLASS ASSY(I) SP	302K994030	2K994030
LED mount	PARTS MOUNT LED ASSY SP	302K993040	2K993040
Original size sensor	SENSOR ORIGINAL	302H044110	2H044110
ISU	PARTS IMAGE SCANNER L SP	302LK93083	2LK93083
Lower duplex roller	PARTS ROLLER DU LOW SP	302LK94060	2LK94060
Middle duplex roller	PARTS ROLLER DU MID SP	302K994480	2K994480
Upper duplex roller	PARTS ROLLER DU UP SP	302LK94070	2LK94070
Eject roller	PARTS ROLLER EXIT SP	302LC94350	2LC94350
Fan filter	PARTS FILTER FAN ASSY(V) SP	302LC94170	2LC94170
Developer filter	FILTER DLP COOLING	302LC33500	2LC33500
Transfer belt filter	PARTS FILTER BELT UNIT(V) SP	302LC94130	2LC94130

Maintenance part name		Part No.	Alternative part No.
Name used in service manual	Name used in parts list		
Toner filter	FILTER LEFT SIDE	302LC33370	2LC33370
Left filter	FILTER LEFT SIDE	302LC33370	2LC33370
Eject filter	PARTS FILTER EXIT UNIT SP	302K994101	2K994101

45 ppm model/55 ppm model

Maintenance part name		Part No.	Alternative part No.
Name used in service manual	Name used in parts list		
Paper feed pulley	PULLEY FEED	302K906350	2K906350
Separation pulley	PULLEY RETARD	302K906360	2K906360
Forwarding pulley	PULLEY PICKUP	302K906370	2K906370
Contact glass	PARTS CONTACT-GLASS ASSY(C) SP	302K994040	2K994040
for Metric			
	PARTS CONTACT-GLASS ASSY(I) SP	302K994030	2K994030
for Inch			
LED mount	PARTS MOUNT LED ASSY SP	302K993040	2K993040
Original size sensor	SENSOR ORIGINAL	302H044110	2H044110
ISU	PARTS IMAGE SCANNER H ASSY SP	302K993033	2K993033
Lower duplex roller	PARTS ROLLER DU LOW SP	302K994470	2K994470
Middle duplex roller	PARTS ROLLER DU MID SP	302K994480	2K994480
Upper duplex roller	PARTS ROLLER DU UP SP	302LK94070	2LK94070
Eject roller	PARTS ROLLER EXIT SP	302LC94350	2LC94350
Fan filter	PARTS FILTER FAN ASSY(V) SP	302LC94170	2LC94170
Developer filter	FILTER DLP COOLING	302LC33500	2LC33500
Transfer belt filter	PARTS FILTER BELT UNIT(V) SP	302LC94130	2LC94130
Toner filter	FILTER LEFT SIDE	302LC33370	2LC33370
Left filter	FILTER LEFT SIDE	302LC33370	2LC33370
Eject filter	PARTS FILTER EXIT UNIT SP	302K994101	2K994101

(2) Maintenance kits

30 ppm model/35 ppm model

Maintenance part name		Parts No.	Alternative part No.
Name used in service	Name used in parts list		
MK-8305A/Maintenance kit (600,000 pages)	MK-8305A/MAINTENANCE KIT	1702LK0UN0	072LK0UN
Drum unit K	DK-8505 (K)	-	-
Developer unit K	DV-8305K	-	-
Transfer belt unit	TR-8505	-	-
Transfer roller	PARTS ROLLER SECONDLY TRANSFER SP	-	-
MK-8305B/Maintenance kit (600,000 pages)	MK-8305B/MAINTENANCE KIT	1702LK0UN1	072LK0U1
Drum unit C	DK-8505 (C)	-	-
Drum unit M	DK-8505 (M)	-	-
Drum unit Y	DK-8505 (Y)	-	-
Developer unit C	DV-8305C	-	-
Developer unit M	DV-8305M	-	-
Developer unit Y	DV-8305Y	-	-
MK-8305C/Maintenance kit (300,000 pages)	MK-8305C/MAINTENANCE KIT	1702LK0UN2	072LK0U2
Fuser unit	FK-UNIT	-	-
Eject filter	FILTER TOP		
Toner filter / Left filter	FILTER LEFT SIDE		

45 ppm model/55 ppm model

Maintenance part name		Parts No.	Alternative part No.
Name used in service	Name used in parts list		
MK-8505A/Maintenance kit (600,000 pages)	MK-8505A/MAINTENANCE KIT	1702LC0UN0	072LC0UN
Drum unit K	DK-8505 (K)	-	-
Developer unit K	DV-8505K	-	-
Transfer belt unit	TR-8505	-	-
Transfer roller	PARTS ROLLER SECONDLY TRANSFER SP	-	-
MK-8505B/Maintenance kit (600,000 pages)	MK-8505B/MAINTENANCE KIT	1702LC0UN1	072LC0U1
Drum unit C	DK-8505 (C)	-	-
Drum unit M	DK-8505 (M)	-	-
Drum unit Y	DK-8505 (Y)	-	-
Developer unit C	DV-8505C	-	-
Developer unit M	DV-8505M	-	-
Developer unit Y	DV-8505Y	-	-
MK-8505C/Maintenance kit (300,000 pages)	MK-8505C/MAINTENANCE KIT	1702LC0UN2	072LC0U2
Fuser unit	FK-UNIT	-	-
Eject filter	FILTER TOP		
Toner filter / Left filter	FILTER LEFT SIDE		

(3) Periodic maintenance procedures

Section	Maintenance part/location	User call	300K/600K/900K/1200K	Points and cautions	Page
Test copy and test print	Perform at the maximum copy size	Test copy	Test copy		



Section	Maintenance part/location	User call	300K/600K/900K/1200K	Points and cautions	Page
Paper feed ,conveying-section	Paper feed pulley	Check Clean	Check Replace	Clean with alcohol or a dry cloth. CH:performing U901 and check feeding count: Target to replace at 150K.	P.1-5-7 P.1-5-10
	Separation pulley	Check Clean	Check Replace	Clean with alcohol or a dry cloth. CH:performing U901 and check feeding count: Target to replace at 150K.	P.1-5-7 P.1-5-10
	Forwarding pulley	Check Clean	Check Replace	Clean with alcohol or a dry cloth. CH:performing U901 and check feeding count: Target to replace at 150K.	P.1-5-7 P.1-5-10
	Guides	Clean	Clean	Clean with alcohol or a dry cloth.	



Section	Maintenance part/location	User call	300K/600K/900K/1200K	Points and cautions	Page
Scanner Optical section	Contact glass	-	Clean	DP slit glass: CL dry cloth or alcohol wet cloth is strictly prohibited. When installing DP, CL with dry cloth.Contact glass for original: CL alcohol or dry cloth .(FACE SIDE) Only when unusual image (line or stain) appear, wipe the back side with dry cloth after cleaning with alcohol only. (BACK SIDE)	
	Mirror A	Clean	-	Clean:airblow after dry cloth only when unusual image(line) arises.	
	Mirror B	Clean	-	Clean:airblow after dry cloth only when unusual image(line) arises. 2pcs	

Section	Maintenance part/location	User call	300K/600K/900K/1200K	Points and cautions	Page
Scanner Optical section	ISU lens	Clean	-	Clean:airblow after dry cloth only when unusual image(line) arises.	
	LED mount	Check Replace	-	Replace if there are image problems.	
	RAIL ISU R/F	Lubrication	-	Apply grease if abnormal sound and jitter image appears Optical rail grease PG-671(P/N:60170000)	
	Original size sensor	Check Clean	-	Alcohol or dry cloth if there is problem. (lighting part and light reception part.)	
	ISU	-	-	Replace if there are image problems.	P.1-5-26



Section	Maintenance part/location	User call	600K/1200K	Points and cautions	Page
Transfer section	Transfer belt unit	-	Replace	Every 600k Replace.	P.1-5-49
	Transfer roller	-	Replace	Every 600k Replace.	P.1-5-53



Section	Maintenance part/location	User call	600K/1200K	Points and cautions	Page
Developer section	Developer unit K	Clean	Replace	Vacuum. Every 600k Replace.	P.1-5-44
	Developer unit C	Clean	Replace	Vacuum. Every 600k Replace.	P.1-5-44
	Developer unit M	Clean	Replace	Vacuum. Every 600k Replace.	P.1-5-44
	Developer unit Y	Clean	Replace	Vacuum. Every 600k Replace.	P.1-5-44



Section	Maintenance part/location	User call	600K/1200K	Points and cautions	Page
Drum section	Drum unit K	Clean	Replace	Vacuum. Every 600k Replace.	P.1-5-44
	Drum unit C	Clean	Replace	Vacuum. Every 600k Replace.	P.1-5-44
	Drum unit M	Clean	Replace	Vacuum. Every 600k Replace.	P.1-5-44
	Drum unit Y	Clean	Replace	Vacuum. Every 600k Replace.	P.1-5-44



Section	Maintenance part/location	User call	300K/600K/900K/1200K	Points and cautions	Page
Fuser section	Fuser unit	-	Replace	Every 300k Replace.	P.1-5-55



Section	Maintenance part/location	User call	300K/600K/900K/1200K	Points and cautions	Page
Eject, Duplex section	Lower duplex roller	-	Clean	Clean with alcohol or a dry cloth.	
	Middle duplex roller	-	Clean	Clean with alcohol or a dry cloth.	
	Upper duplex roller	-	Clean	Clean with alcohol or a dry cloth.	
	Eject roller	-	Clean	Clean with alcohol or a dry cloth.	



Section	Maintenance part/location	User call	300K/600K/900K/1200K	Points and cautions	Page
Outer, Cover	Outer Covers, Tray	-	Clean	Clean with alcohol or a dry cloth.	



Section	Maintenance part/location	User call	300K/600K/900K/1200K	Points and cautions	Page
Driving, Other	Fan filter	Clean	Clean	Vacuum. 1pcs	P.1-5-96
	Developer filter	Clean	Clean	Vacuum. 1pcs	P.1-5-100
	Transfer belt filter	Clean	Clean	Vacuum. 2pcs	P.1-5-97
	Toner filter Left filter	Replace	Replace	Every 300k Replace. (MK KIT) 2pcs	P.1-5-95 P.1-5-99
	Eject filter	Replace	Replace	Every 300k Replace. (MK KIT) 2pcs	P.1-5-94
	Each Clutches	Check Replace	Check	Check the image registration and paper feed conveying condition on paper feed conveying (regis- tration) part.	
	Sensors	Check	Check	Clean with alcohol or a dry cloth. (lighting part and light reception part.)	
	Image quality	Check Adjust	Check Adjust		



Section	Maintenance part/location	User call	300K/600K/900K/1200K	Points and cautions	Page
Option	Duct unit	Clean	Clean	Vacuum.	

* : Please do not use spray containing flammable gas for air-blow or air-brush purposes.

(4) Repetitive defects gauge

← First occurrence of defect

← 37.5 mm/1 1/2" Charger roller
← 39 mm/1 9/16" Magnet roller
Sleeve roller

← 57 mm/2 1/4" Right registration roller
← 63 mm/2 1/2" Left registration roller

← 75 mm/2 15/16" Transfer roller

← 94 mm/3 11/16" Drum
← 94.2 mm/3 11/16" Press roller (30 ppm/35 ppm)

← 109.9 mm/4 5/16" Press roller (45 ppm/55 ppm)

← 127.5 mm/5" Heat roller



← 936 mm/36 7/8" Transfer belt

(5) Firmware environment commands

The printer maintains a number of printing parameters in its memory. These parameters may be changed permanently with the FRPO (Firmware RePrOgram) commands.

This section provides information on how to use the FRPO command and its parameters using examples.

Using FRPO commands for reprogramming firmware

The current settings of the FRPO parameters are listed as optional values on the service status page.

Note: Before changing any FRPO parameter, print out a service status page, so you will know the parameter values before the changes are made. To return FRPO parameters to their factory default values, send the FRPO INIT (FRPO-INITialize) command.(!R! FRPO INIT; EXIT;)

The FRPO command is sent to the printer in the following sequence:

!R! FRPO parameter, value; EXIT;

Example: Changing emulation mode to PCL6

!R! FRPO P1, 6; EXIT;

FRPO parameters

Item	FRPO	Setting values	Factory setting
Top margin	A1	Integer value in inches	0
	A2	Fraction value in 1/100 inches	0
Left margin	A3	Integer value in inches	0
	A4	Fraction value in 1/100 inches	0
Page length	A5	Integer value in inches	17
	A6	Fraction value in 1/100 inches	30
Page width	A7	Integer value in inches	17
	A8	Fraction value in 1/100 inches	30
Default pattern resolution	B8	0: 300 dpi 1: 600 dpi	0
Page orientation	C1	0: Portrait 1: Landscape	0
Default font No. *	C2	Middle two digits of power-up font	0
	C3	Last two digits of power-up font	0
	C5	First two digits of power-up font	0
PCL font switch	C8	0: HP compatibility mode 32: Conventional compatibility mode	0
Total host buffer size	H8	0 to 99 in units of the size defined by FRPO S5	5
Form feed time-out value	H9	Value in units of 5 seconds (1 to 99)	6(30s)
Duplex mode	N4	0: Off 1: Long edge binding 2: Short edge binding	0

Item	FRPO	Setting values	Factory setting
Sleep timer time-out time	N5	Value in units of 1 minute (1 to 240)	30 ppm:30 35 ppm:45 45 ppm/ 55 ppm:60
Ecoprint level	N6	0: Off 2: On	0
Default emulation mode	P1	6: PCL 6 9: KPDL	120V: 9 220-240V: 6
Carriage-return action	P2	0: Ignores 1: Carriage-return 2: Carriage-return + linefeed	1
Linefeed action	P3	0: Ignores 1: Linefeed 2: Linefeed + carriage-return	1
Automatic emulation switching	P4	0: AES disabled 1: AES enabled	120V: 1 220-240V: 0
Alternative emulation (For KPDL3)	P5	Same as the P1 values except that 9 is ignored.	6
Automatic emulation switching trigger	P7	0: Page eject commands 1: None 2: Page eject and prescribe EXIT commands 3: Prescribe EXIT commands 4: Formfeed (^L) commands 6: Prescribe EXIT and formfeed commands 10: Page eject commands; if AES fails, resolves to KPDL	120V: 11 220-240V: 10
Command recognition character	P9	ASCII code of 33 to 126	82 (R)
Default stacker	R0	1 (inner tray)	1

Item	FRPO	Setting values	Factory setting
Default paper size	R2	0: Size of the default paper cassette (See R4.) 1: Monarch (3-7/8 × 7-1/2 inches) 2: Business (4-1/8 × 9-1/2 inches) 3: International DL (11 × 22 cm) 4: International C5 (16.2 × 22.9 cm) 5: Executive (7-1/4 × 10-1/2 inches) 6: US Letter (8-1/2 × 11 inches) 7: US Legal (8-1/2 × 14 inches) 8: A4 (21.0 × 29.7 cm) 9: JIS B5 (18.2 × 25.7 cm) 10: A3 (29.7 × 42 cm) 11: B4 (25.7 × 36.4 cm) 12: US Ledger (11 × 17 inches) 13: ISO A5 14: A6 (10.5 × 14.8 cm) 15: JIS B6 (12.8 × 18.2 cm) 16: Commercial #9 (3-7/8 × 8-7/8 inches) 17: Commercial #6 (3-5/8 × 6-1/2 inches) 18: ISO B5 (17.6 × 25 cm) 19: Custom (11.7 × 17.7 inches) 20: 21: 22: 23: 24: 30: C4 (22.9 × 32.4 cm) 31: Hagaki (10 × 14.8 cm) 32: Ofuku-hagaki (14.8 × 20 cm) 33: Officio II 38: 39: 8K 40: 16K 42: 8.5 × 13.5 inches 50: Statement 51: Folio 52: Youkei 2 53: Youkei 4	0
Default cassette	R4	0: MP tray 1: Cassette 1 2: Cassette 2 3: Cassette 3 4: Cassette 4 5: Cassette 5 6: Cassette 6 7: Cassette 7	1
Sorter full action	S3	0: Stop operation with detecting tray-full 1: Switching to the eject-able destinations when bin becomes tray full	0

Item	FRPO	Setting values	Factory setting
A4/letter equation	S4	0: Off 1: On	1
Host buffer size	S5	0: 10 KB 1: 100 KB 2: 1024 KB	1
Wide A4	T6	0: Off 1: On	0
Line spacing *	U0	Lines per inch (integer value)	6
	U1	Lines per inch (decimal value)	0
Character spacing *	U2	Characters per inch (integer value)	10
	U3	Characters per inch (decimal value)	0
Country code	U6	0: US-ASCII 1: France 2: Germany 3: UK 4: Denmark 5: Sweden 6: Italy 7: Spain 8: Japan 9: US Legal 10: IBM PC-850 (Multilingual) 11: IBM PC-860 (Portuguese) 12: IBM PC-863 (Canadian French) 13: IBM PC-865 (Norwegian) 14: Norway 15: Denmark 2 16: Spain 2 17: Latin America 50 - 99: HP PCL symbol set coding	41
Code set at power up in daisywheel emulation	U7	0: Same as the default emulation mode (P1) 1: IBM 6: PCL 7 - 99: HP PCL symbol set coding	53
Font pitch for fixedpitch scalable font *	U8	Default font pitch (integer value)	10
	U9	Default font pitch (decimal value)	0
Font height for the default scalable font *	V0	Integer value in 100 points: 0 to 9	0
	V1	Integer value in points: 0 to 99	12
	V2	decimal value in 1/100 points: 0, 25, 50, 75	0

Item	FRPO	Setting values	Factory setting
Default scalable font *	V3	Name of typeface of up to 32 characters, enclosed with single or double quotation marks	Courier
Default weight (courier and letter Gothic)	V9	0: Courier = darkness Letter Gothic = darkness 1: Courier = regular Letter Gothic = darkness 4: Courier = darkness Letter Gothic = regular 5: Courier = regular Letter Gothic = regular	5
Color mode	W1	0: Black & white 1: Color	1
Gloss mode	W6	0: Low (normal) 1: High	0
Paper type for the MP tray	X0	1: Plain 2: Transparency 3: Preprinted 4: Label 5: Bond 6: Recycle 7: Vellum 9: Letterhead 10: Color 11: Prepunched 12: Envelope 13: Cardstock 14: Coated 16: Thick 17: High quality 21 to 28: Custom1 to 8	1

Item	FRPO	Setting values	Factory setting
Paper type for cassettes 1 and 2	X1 X2	1: Plain 3: Preprinted 5: Bond 6: Recycled 7: Vellum 9: Letterhead 10: Color 11: Prepunched 16: Thick 17: High quality 21 to 28: Custom1 to 8	1
Paper type for optional cassettes 3 to 7	X3 X4 X5 X6 X10	1: Plain 3: Preprinted 5: Bond 6: Recycled 9: Letterhead 10: Color 11: Prepunched 17: High quality 21 to 28: Custom1 to 8	1
PCL paper source	X9	0: Paper selection depending on an escape sequence compatible with HP-LJ5Si. 2: Paper selection depending on an escape sequence compatible with HP-LJ8000.	0
Automatic continue for 'Press GO'	Y0	0: Off 1: On	0
Automatic continue timer	Y1	Value in units of 5 seconds (1 to 99)	6 (30 s)
Error message for device error	Y3	0: Not detect 127: Detect	127
Duplex operation for specified paper type (Prepunched, Preprinted and Letterhead)	Y4	0: Off 1: On	0

Item	FRPO	Setting values	Factory setting
Default operation for PDF direct printing	Y5	0: Enlarges or reduces the image to fit in the current paper size. Loads paper from the current paper cassette. 1: Through the image. Loads paper which is the same size as the image. 2: Enlarges or reduces the image to fit in the current paper size. Loads Letter, A4 size paper depending on the image size. 3: Through the image. Loads Letter, A4 size paper depending on the image size. 8: Through the image. Loads paper from the current paper cassette. 9: Through the image. Loads Letter, A4 size paper depending on the image size. 10: Enlarges or reduces the image to fit in the current paper size. Loads Letter, A4 size paper depending on the image size. * : 13-99: The same operation as default value (0).	0
e-MPS error	Y6	0: Does not print the error report and display the error message. 1: Prints the error report. 2: Displays the error message. 3: Prints the error report and displays the error message.	3

*: Ignored in some emulation modes.

(6) System Error (Fxxxx) Outline

The document is subscribed to describe the outline of the factors of the Fxxx errors that are not described in the

service manual. Please utilize it to refer to checking the factors.

Please utilize it as the measures when the system is not recovered after power off/on or it frequently occurs.

It may be from the hardware factor while the error (Fxxx) is indicated.

Please initially check the following.

Check the DDR2 memory and neighboring parts:

Check the contact of YS1 or YS2 with the memory. Replace the memory if the error repeats.

Check the HDD if the error repeats after replacing the main board.

Take care, however, of handling the data when formatting or replacing the HDD.

Check the HDD : Replace the HDD if the error repeats after formatting the HDD.

No.	Content	Check procedure & check point	Remark 1	Remark 2
-	Lock-up at Welcome display (The display unchanges after 3 minutes 30 seconds or more)	<ol style="list-style-type: none"> 1) Check connection of the harness (Panel to Main board), (Main board to HDD) and connectors and check function. 2) Check contact of the DDR memory by detaching and reattaching, and check function. replace it if available and check function. 3) Format the HDD and check function. (U024 FULL formatting) 4) Execute the U021Memory initializing to initialize the controller backup memory and check function. 5) Replace the panel board and check function. 6) Replace the main board and check function. 7) Retrieve the USBLOG and contact the Service Administrative Division. 	*User data and installed software is deleted if executing the U024. Reinstallation is required.	<p>[Main - Panel Interface] Main bord:YC12, YC1,YC30 Panel board:YC1,YC2,YC3</p> <p>[Main - HDD] Main board:YC1,YC2</p>
F000	CF000 appears in 3minutes 30 seconds after the Welcome display continues Panel—Main board communication error	<ol style="list-style-type: none"> 1) Check connection of the harness (Panel to Main board), (Main board to HDD) and connectors and check function. 2) Check contact of the DDR memory by detaching and reattaching, and check function. replace it if available and check function. 3) Format the HDD and check function. (U024 FULL formatting) 4) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 5) Replace the main board and check function. 6) Replace the Panel board and check function. 7) Retrieve the USBLOG and contact the Service Administrative Division. 		<p>[Main-Panel Interface] Mainboard: YC12,YC17,YC30 Panel borad: YC1,YC2,YC3</p> <p>If the LEDs are in the state belwo when the F000 appears, the DDR2 memory failure may be the cause. Check contact of theYS1 or YS2 with the memory. Memory LED turned on</p>
F10X	An error is detected at OS or some of device drivers.	<ol style="list-style-type: none"> 1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division. 		
F11X				
F12X	An error is detected at the Scan control section	<ol style="list-style-type: none"> 1) Check connection of the harness (Scan/DP - Main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Replace the Scan/DP board and check function. 5) Replace the main board and check function. 6) Retrieve the USBLOG and contact the Service Administrative Division. 		<p>[Main-Scan Interface] Main board:YC11,YC25 ISC board:</p> <p>[Main-DP relay Interface] (Check if the boards are firmly connected via the board-to-board connector.) Main board:YC10 DP relay board:YC4</p>
F13X	An error is detected at the Panel control section	<ol style="list-style-type: none"> 1) Check connection of the harness (Panel - Main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Replace the panel board and check function. 5) Replace the main board and check function. 6) Retrieve the USBLOG and contact the Service Administrative Division. 		<p>[Main-Panel Interface] Main board:YC12,YC17,YC30 Panel board:YC1,YC2,YC3</p>
F14X	An error is detected at the FAX control section	<ol style="list-style-type: none"> 1) Check connection of the harness (FAX - Main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Execute the U671 Clear FAX back up data (FAX DIMM clear) and check function. (Take cae of the received data since it is cleared) 5) Replace the FAX_DIMM and check function. 6) Replace the FAX board and check function. 7) Replace the main board and check function. 8) Retrieve the USBLOG and contact the Service Administrative Division. 		<p>F14A,F14F: KUIO error Main board (USB hub)</p> <p>[Main-KUIO Interface] Main board:YC8,YC9 KUIO board:YC3,YC4</p>
F15X	An error is detected at the authentication device control section	<ol style="list-style-type: none"> 1) Check connection of the harness (Authentication device - Main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Replace the main board and check function. 5) Replace the HDD and check function. 6) Retrieve the USBLOG and contact the Service Administrative Division. 	Authentication device: Card Reader, etc.	
F17X	An error is detected at the print data control section	<ol style="list-style-type: none"> 1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division. 		
F18X	An error is detected at the Video control section	<ol style="list-style-type: none"> 1) Check connection of the harness (Engine - Main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Replace the engine board and check function. 5) Replace the main board and check function. 6) Retrieve the USBLOG and contact the Service Administrative Division. 		<p>[Main⇄ENGINE Interface] Main board:YC3 Engine board:YC46 or YC50</p>
F19X	An error is detected at the OS or some of device drivers	<ol style="list-style-type: none"> 1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division. 		
F1AX				
F1BX	An error is detected at the Security management section	<ol style="list-style-type: none"> 1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division. 		

No.	Content	Check procedure & check point	Remark 1	Remark 2
F1CX	An error is detected at the File System management section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.	*The F1C4 error appears with the HDD security kit at work.	
F1DX	An error is detected at the Image memory management section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.	*The F1D4 error is RAM allocation error. 1 Check it with the U340 2 Initialize the setting valued with the U021	
F1EX	An error is detected at the OS or some of device drivers	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F1FX				
F20X				
F21X	An error is detected at the Image processing section	1) Check contact of the DDR memory and check function. 2) Format the HDD and check function. (U024 FULL formatting) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Replace the main board and check function. 5) Replace the HDD and check function. 6) Retrieve the USBLOG and contact the Service Administrative Division.		[DDR2 memory contact check] Main board:YS1 or YS2 A certain part of the memory be faulty. The frequency of failure occurrence is dependent on the frequency of access to the faulty bit. The ASIC may be faulty if the memory is not
F22X				
F23X				
F24X	An error is detected at the System management section	1) Check contact of the DDR memory and check function. 2) Format the HDD and check function. (U024 FULL formatting) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Replace the main board and check function. 5) Replace the HDD and check function. 6) Retrieve the USBLOG and contact the Service Administrative Division.	*The F248 error is printer process error. if it repeats with a certain print data, retrieve the capture data and USBLOG.	[DDR2 memory contact check] Main board:YS1 or YS2 A certain part of the memory be faulty. The frequency of failure occurrence is dependent on the frequency of access to the faulty bit. The ASIC may be faulty if the memory is not sensitive.
F25X	An error is detected at the Network management section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Retrieve the USBLOG and contact the Service Administrative Division. (or retrieve the packet capture data depending on the result of analysis)	*This may be owing to the users network environment.	
F26X	An error is detected at the System management section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F27X				
F28X				
F29X				
F2AX				
F2BX	An error is detected at the Network control section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Retrieve the USBLOG and contact the Service Administrative Division. (or retrieve the packet capture data depending on the result of analysis)		
F2CX				
F2DX				
F2EX				
F2FX				
F30X				
F31X				
F32X				
F33X	An error is detected at the Scan management section	1) Check connection of the harness (Scan/DP board - main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Replace the Scan/DP board and check function. 5) Replace the main board and check function. 6) Retrieve the USBLOG and contact the Service Administrative Division.		
F34X	An error is detected at the Panel management section	1) Check connection of the harness (Panel board - main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Replace the panel board and check function 5) Replace the main board and check function. 6) Retrieve the USBLOG and contact the Service Administrative Division.		
F35X	An error is detected at the Print control section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F36X	An error is detected at the Print management section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F37X	An error is detected at the FAX management section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Execute the U671 Clear FAX back up data (FAX DIMM clear) and check function. (Take care of the received data since it is cleared) 4) Replace the FAX_DIMM and check function. 5) Replace the main board and check function. 6) Replace the HDD and check function. 7) Retrieve the USBLOG and contact the Service Administrative Division.		F14A,F14F:KUIO error Main board (USB hub) [Main-KUIO Interface] Main board: YC8,YC9 KUIO board: YC3,YC4


No.	Content	Check procedure & check point	Remark 1	Remark 2
F38X	An error is detected at the Authentication/permit management section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F3AX F3BX F3CX F3DX F3EX F3FX F40X F41X F42X F43X F44X F45X	An error is detected at the Entity management section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F46X	An error is detected at the Print image process section	1) Replace the main board and check function. 2) Retrieve the USBLOG (or retrieve the print capture data by case)	*The F46F is printer process error. if it repeats with a certain print data, retrieve the capture data and USBLOG.	
F47X F48X F49X	An error is detected at the Image edit process control section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F4AX F4CX	An error is detected at the Print image process section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F4DX F4EX	An error is detected at the Entity control section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F4FX	An error is detected at the Job control section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F50X F51X F52X F53X F55X F56X F57X	An error is detected at the FAX control section An error is detected at the Job execution section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F58X F59X F5AX F5BX F5CX F5DX F5EX	An error is detected at the Service management section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F5FX	An error is detected at the Service execution section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F60X	An error is detected at the Maintenance mode management section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F61X	An error is detected at the Report compiling section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F62X	An error is detected at the Service execution section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		

No.	Content	Check procedure & check point	Remark 1	Remark 2
F63X	An error is detected at the Device control section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F64X	An error is detected at the Print image process section	1) Format the HDD and check function. (U024 FULL formatting)		
F65X		2) Execute the U021 Memory initializing to initialize the controller backup memory and check function.		
F66X		3) Replace the main board and check function.		
F67X		4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.		
F68X	An error is detected at the Storage device control section	1) Format the HDD and check function. (U024 FULL formatting) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. 5) Retrieve the USBLOG and contact the Service Administrative Division.	*F684 is Overwrite error with the HDD security kit	
F69X	An error is detected at the HyPAS control section	1) Format the HDD and check function. (U024 FULL formatting)		
F6AX		2) Execute the U021 Memory initializing to initialize the controller backup memory and check function.		
F6BX		3) Replace the main board and check function.		
F6CX		4) Replace the HDD and check function.		
F6DX		5) Retrieve the USBLOG and contact the Service Administrative Division.		
F6EX	An error is detected at the External Server management section	1) Check the external server and check function.	*FieryOption related	
F6FX		2) Check the connection to the external server and check function.		
F70X		3) Check the network settings and check function.		
F71X		4) Replace the bridge board and check function.		
F72X		5) Replace the main board and check function.		
F73X		6) Retrieve the USBLOG and contact the Service Administrative Division.		
F74X				
F75X				


(7) Timing chart

1. Cassette1 paper feeding, Paper size A4, Simplex, Preset 1
2. Cassette1 paper feeding, Paper size A4, Simplex, Preset 3


30/35 ppm model



45/55 ppm model




(1) Simplex_Preset 1_cassette1_A4



*1 Middle clutch (MCL): 30 / 35 ppm model, Middle motor (MM): 45 / 55 ppm model

*2 Registration clutch (RCL): 30 / 35 ppm model, Registration motor (RM): 45 / 55 ppm model


(2) Simplex_Preset 3_cassette1_A4




- *1 Middle clutch (MCL): 30 / 35 ppm model, Middle motor (MM): 45 / 55 ppm model
- *2 Registration clutch (RCL): 30 / 35 ppm model, Registration motor (RM): 45 / 55 ppm model
- *3 Duplex clutch 1 (DUCL1): 30 / 35 ppm model, Duplex motor 1 (DUM1): 45 / 55 ppm model
- *4 Duplex clutch 2 (DUCL2): 30 / 35 ppm model, Duplex motor 2 (DUM2): 45 / 55 ppm model

3. Cassette2 paper feeding, Paper size A4, Simplex, Preset 3


30/35 ppm model



45/55 ppm model




(3) Simplex_Preset 3_cassette2_A4




*1 Middle clutch (MCL): 30 / 35 ppm model, Middle motor (MM): 45 / 55 ppm model
 *2 Registration clutch (RCL): 30 / 35 ppm model, Registration motor (RM): 45 / 55 ppm model

4. MPF paper feeding, Paper size A4, Simplex, Preset 1


30/35 ppm model



45/55 ppm model



(4) Simplex_Preset 3_MPF_A4




*1 Middle clutch (MCL): 30 / 35 ppm model, Middle motor (MM): 45 / 55 ppm model


*2 Registration clutch (RCL): 30 / 35 ppm model, Registration motor (RM): 45 / 55 ppm model

- 5. Cassette1 paper feeding, Paper size A4, Duplex, Preset 1
- 6. Cassette1 paper feeding, Paper size A4, Duplex, Preset 3


30/35 ppm model



45/55 ppm model




(5) Duplex_Preset 1_cassette1_A4



- *1 Middle clutch (MCL): 30 / 35 ppm model, Middle motor (MM): 45 / 55 ppm model
- *2 Registration clutch (RCL): 30 / 35 ppm model, Registration motor (RM): 45 / 55 ppm model
- *3 Duplex clutch 1 (DUCL1): 30 / 35 ppm model, Duplex motor 1 (DUM1): 45 / 55 ppm model
- *4 Duplex clutch 2 (DUCL2): 30 / 35 ppm model, Duplex motor 2 (DUM2): 45 / 55 ppm model






(6) Duplex_Preset 3_cassette1_A4



- *1 Middle clutch (MCL): 30 / 35 ppm model, Middle motor (MM): 45 / 55 ppm model
- *2 Registration clutch (RCL): 30 / 35 ppm model, Registration motor (RM): 45 / 55 ppm model
- *3 Duplex clutch 1 (DUCL1): 30 / 35 ppm model, Duplex motor 1 (DUM1): 45 / 55 ppm model
- *4 Duplex clutch 2 (DUCL2): 30 / 35 ppm model, Duplex motor 2 (DUM2): 45 / 55 ppm model

(8) Chart of image adjustment procedures

Adjusting order	Item	Image	Description	Maintenance mode		Original	Page	Remarks
				Item No.	Mode			
1	Adjusting the magnification in the auxiliary scanning direction (printing adjustment)		Data processing	U039	Sub Scan	U039 test pattern	P.1-3-40	
2	Adjusting the center line of the MP tray (printing adjustment)		Adjusting the LSU print start timing	U034	LSU Out Left	U034 test pattern	P.1-3-34	To make an adjustment for duplex copying, select Duplex.
3	Adjusting the center line of the cassettes (printing adjustment)		Adjusting the LSU print start timing	U034	LSU Out Left	U034 test pattern	P.1-3-34	
4	Adjusting the leading edge registration of the MP tray (printing adjustment)		Registration motor turning on timing (secondary paper feed start timing)	U034	LSU Out Top	U034 test pattern	P.1-3-34	To make an adjustment for duplex copying, select Duplex.
5	Adjusting the leading edge registration of the cassette (printing adjustment)		Registration motor turning on timing (secondary paper feed start timing)	U034	LSU Out Top	U034 test pattern	P.1-3-34	
6	Adjusting the leading edge margin (printing adjustment)		LSU illumination start timing	U402	Lead	U402 test pattern	P.1-3-153	
7	Adjusting the trailing edge margin (printing adjustment)		LSU illumination end timing	U402	Trail	U402 test pattern	P.1-3-153	
8	Adjusting the left and right margins (printing adjustment)		LSU illumination start/end timing	U402	A Margin C Margin	U402 test pattern	P.1-3-153	
9	Adjusting magnification of the scanner in the main scanning direction (scanning adjustment)		Data processing	U065 U070	Main Scan Main Scan	Test chart	P.1-3-52 P.1-3-57	U065: For copying an original placed on the platen. U070: For copying originals from the DP.
10	Adjusting magnification of the scanner in the auxiliary scanning direction (scanning adjustment)		Original scanning speed	U065 U070	Sub Scan Sub Scan	Test chart	P.1-3-52 P.1-3-57	U065: For copying an original placed on the platen. U070: For copying originals from the DP.

Adjusting order	Item	Image	Description	Maintenance mode		Original	Page	Remarks
				Item No.	Mode			
11	Adjusting the center line (scanning adjustment)		Adjusting the original scan data (image adjustment)	U067	Front Rotate	Test chart	P.1-3-55	U067: For copying an original placed on the platen. To make an adjustment for rotate copying, select Rotate. U072: For copying originals from the DP. To make an adjustment for duplex copying, select Back.
				U072	Front Back		P.1-3-61	
12	Adjusting the leading edge registration (scanning adjustment)		Original scan start timing	U066	Front Rotate	Test chart	P.1-3-54	U066: For copying an original placed on the platen. To make an adjustment for trailing edge registration, select Rotate. U071: For copying originals from the DP. To make an adjustment for duplex copying, select Back Head.
				U071	Front Head Back Head		P.1-3-59	
13	Adjusting the leading edge margin (scanning adjustment)		Adjusting the original scan data (image adjustment)	U403	B Margin	Test chart	P.1-3-154	U403: For copying an original placed on the contact glass U404: For copying originals from the DP.
				U404	B Margin		P.1-3-155	
14	Adjusting the trailing edge margin (scanning adjustment)		Adjusting the original scan data (image adjustment)	U403	D Margin	Test chart	P.1-3-154	U403: For copying an original placed on the contact glass U404: For copying originals from the DP.
				U404	D Margin		P.1-3-155	
15	Adjusting the left and right margins (scanning adjustment)		Adjusting the original scan data (image adjustment)	U403	A Margin C Margin	Test chart	P.1-3-154	U403: For copying an original placed on the contact glass U404: For copying originals from the DP.
				U404	A Margin C Margin		P.1-3-155	

When maintenance item U411 (Automatic adjustment in the scanner) is run using the specified original (P/N 7505000005), the following adjustments are automatically made:

Adjusting the scanner auxiliary scanning direction magnification (U065) Adjusting the DP magnification (U070)
Adjusting the scanner leading edge registration (U066) Adjusting the DP leading edge registration (U071)
Adjusting the scanner center line (U067) Adjusting the DP center line (U072)

When maintenance item U411 (Automatic adjustment in the scanner) is run using the specified original (P/N 302AC68243), the following adjustments are automatically made:

Adjusting the DP magnification (U070)
Adjusting the DP leading edge registration (U071)
Adjusting the DP center line (U072)

Adjusting the DP magnification (U070)
Adjusting the DP leading edge registration (U071)
Adjusting the DP center line (U072)

When maintenance item U411 (Automatic adjustment in the scanner) is run using the chart printed from the machine, the following adjustments are automatically made:

Adjusting the DP magnification (U070)
Adjusting the DP leading edge registration (U071)
Adjusting the DP center line (U072)

When maintenance item U415 (Adjusting the print position automatically) is run, the following adjustments are automatically made:


Adjusting the printer leading edge registration (U034)
Adjusting the printer center line (U034)
Adjusting the printer margin (U402)

Image quality


Item	Specifications	Item	Specifications
100% magnification	Machine: $\pm 0.8\%$	Leading edge registration	Cassette: $+1.0/-1.5$ mm
	Using DP: $\pm 1.5\%$		MP tray: $+1.0/-1.5$ mm
Enlargement/reduction	Machine: $\pm 1.0\%$		Duplex: $+1.0/-1.5$ mm
	Using DP: $\pm 1.5\%$	Skewed paper feed (left-right difference)	Cassette: 1.5 mm or less
Lateral squareness	Machine: ± 1.5 mm/375 mm		MP tray: 1.5 mm or less
	Using DP: ± 3.0 mm/375 mm		Duplex: 2.0 mm or less
		Lateral image shifting	Cassette: ± 2.0 mm
			MP tray: ± 2.0 mm
			Duplex: ± 3.0 mm

(9) Wiring diagram


No.1 (30 ppm model/35 ppm model/45 ppm model/55 ppm model)




No.2 (30 ppm model)




No.2 (35 ppm model/45 ppm model/55 ppm model)




No.3 (30 ppm model/35 ppm model/45 ppm model/55 ppm model)




No.4 (30 ppm model/35 ppm model/45 ppm model/55 ppm model)




No.5 (30 ppm model/35 ppm model)




No.5 (45 ppm model/55 ppm model)




No.6 (30 ppm model/35 ppm model)




No.6 (45 ppm model/55 ppm model)




No.7 (30 ppm model/35 ppm model)




No.7 (45 ppm model/55 ppm model)




No.8 (30 ppm model/35 ppm model)




No.8 (45 ppm model/55 ppm model)




No.9 (30 ppm model/35 ppm model)



No.9 (45 ppm model/55 ppm model)



INSTALLATION GUIDE FOR DOCUMENT PROCESSOR



English		C* . Fixing fitting (width: 45 mm) ^{*1} 1	J . M3 × 8 screw BLACK ^{*1} 1
Supplied parts		D . Angle control fitting..... 1	K . Label "Operation procedure"..... 1
A . DP..... 1	B . Original mat..... 1	E . DP cable cover..... 1	*: for metric specification
C . Fixing fitting (width: 38.5 mm)..... 2 (DP-770)		F . Pin..... 1	** : for inch specification
		G . M4 × 14TP screw..... 8	L . Caution label "Original face up!"..... 1
		H . Left hinge cover ^{*1} 1	M . DP relay PWB ^{*1} 1
		I . Right hinge cover ^{*1} 1	^{*1} : DP-771 only

Français		C* . Fixation (largeur: 45 mm) ^{*1} 1	K . Étiquette relative à la procédure d'utilisation..... 1
Pièces fournies		D . Fixation d'angle..... 1	* : pour des spécifications métriques
A . DP..... 1	B . Plaque d'original..... 1	E . Couverture du câble du DP..... 1	** : pour des spécifications anglo-saxonnes
C . Fixation (largeur: 38,5 mm)..... 2 (DP-770)		F . Goupille..... 1	L . Étiquette d'avertissement relative à l'orientation vers le haut de la face de l'original..... 1
		G . Vis TP M4 × 14..... 8	M . Carte de circuit imprimé relais du DP ^{*1} 1
		H . Couverture de charnière gauche ^{*1} 1	^{*1} : DP-771 uniquement
		I . Couverture de charnière droite ^{*1} 1	
		J . Vis M3 × 8 NOIRE ^{*1} 1	

Español		C* . Herraje de fijación (anchura: 45 mm) ^{*1} 1	J . Tornillo M3 × 8 NEGRO ^{*1} 1
Partes suministradas		D . Herraje de control de ángulo..... 1	K . Etiqueta "Procedimiento operativo"..... 1
A . DP..... 1	B . Alfombrilla para originales..... 1	E . Cubierta del cable del DP..... 1	*: para especificaciones en el sistema métrico
C . Herraje de fijación (anchura: 38,5 mm)..... 2 (DP-770)		F . Pasador..... 1	** : para especificaciones en el sistema de pulgadas
		G . Tornillo TP M4 × 14..... 8	L . Etiqueta de precaución "Original cara arriba"..... 1
		H . Cubierta de la bisagra izquierda ^{*1} 1	M . PWB del relé del DP ^{*1} 1
		I . Cubierta de la bisagra derecha ^{*1} 1	^{*1} : DP-771 solamente


Deutsch		C* . Befestigungshalterung (Breite: 45 mm) ^{*1} 1	J . M3 × 8 Schraube SCHWARZ ^{*1} 1
Gelieferte Teile		D . Winkeleinstellbefestigung..... 1	K . Schild "Funktionsanweisung"..... 1
A . DP..... 1	B . Originalmatte..... 1	E . DP-Kabelabdeckung..... 1	*: für metrische Angaben
C . Befestigungshalterung (Breite: 38,5 mm)..... 2 (DP-770)		F . Stift..... 1	** : für Angaben in Zoll
		G . M4 × 14TP Schraube..... 8	L . Warnschild "Originalschriftseite nach oben"..... 1
		H . Linke Scharnierabdeckung ^{*1} 1	M . DP-Relaisleiterplatte ^{*1} 1
		I . Rechte Scharnierabdeckung ^{*1} 1	^{*1} : nur DP-771

Italiano		C* . Accessorio di fissaggio (larghezza: 45 mm) ^{*1} 1	J . Vite M3 × 8 NERA ^{*1} 1
Parti di forniture		D . Accessorio di regolazione angolare..... 1	K . Etichetta "Procedura di funzionamento"..... 1
A . DP..... 1	B . Tappetino originale..... 1	E . Coperchio del cavo DP..... 1	*: per specifiche in unità del sistema metrico
C . Accessorio di fissaggio (larghezza: 38,5 mm)..... 2 (DP-770)		F . Perno..... 1	** : per specifiche in pollici
		G . Vite M4 × 14TP..... 8	L . Etichetta di avvertimento "Originale rivolto verso l'alto!"..... 1
		H . Coperchio cerniera sinistra ^{*1} 1	M . Scheda a circuiti stampati di comunicazione DP ^{*1} 1
		I . Coperchio cerniera destra ^{*1} 1	^{*1} : Solo DP-771

简体中文		C* . 固定附件 (宽 45mm) *1..... 1	I . 右部铰链盖板 *1..... 1
附属品		D . 角度控制附件..... 1	J . M3×8 螺丝 BLACK*1..... 1
A . DP..... 1	B . 原稿垫..... 1	E . DP 电缆盖板..... 1	M . DP 中继板 *1..... 1
C . 固定附件 (宽 38.5mm)..... 2 (DP-770)		F . 销..... 1	*1: 仅限 DP-771
		G . M4×14TP 螺钉..... 8	(K) 和 (L) 并非附属品。
		H . 左部铰链盖板 *1..... 1	

한국어		C* . 고정쇠 (45mm 폭) *1..... 1	I . 힌지커버 우 *1..... 1
동봉품		D . 각도규제쇠..... 1	J . 나사 M3×8BLACK*1..... 1
A . DP 본체..... 1	B . 원고매트..... 1	E . DP 케이블커버..... 1	M . DP 중계기판*1..... 1
C . 고정쇠 (38.5mm 폭)..... 2 (DP-770)		F . 핀..... 1	*1: DP-771 만
		G . 나사 M4×14TP..... 8	(K) (L) 는 동봉되어 있지 않습니다.
		H . 힌지커버 좌 *1..... 1	

日本語		C* . 固定金具 (45mm 幅) *1..... 1	J . ビス M3×8BLACK*1..... 1
同梱品		D . 角度規制金具..... 1	M . DP 中継基板*1..... 1
A . DP 本体..... 1	B . 原稿マット..... 1	E . DP ケーブルカバー..... 1	*1: DP-771 のみ
C . 固定金具 (38.5mm 幅)..... 2 (DP-770)		F . ピン..... 1	(K) (L) は、同梱されていない。
		G . ビス M4×14TP..... 8	
		H . ヒンジカバー左*1..... 1	
		I . ヒンジカバー右*1..... 1	



N. Memory DIMM (1GB) 1

The memory DIMM must be expanded separately before using the "Dual scan function" on the DP-771.

Order a memory DIMM in the service parts.

For details, see the instructions on page 12.

N. Mémoire DIMM (1GB) 1

La mémoire DIMM doit être expansée séparément avant utilisation de la "Fonction double balayage" du DP-771.

Commander une mémoire DIMM auprès du service des pièces de rechange.

Pour plus de précisions, se reporter aux instructions de la page 12.

N. Memoria DIMM (1GB) 1

La memoria DIMM debe ampliarse de forma separada antes de utilizar la "Función de escaneado doble" del DP-771.

Realice un pedido de una memoria DIMM de repuesto.

Consulte las instrucciones de la página 12 para obtener información más detallada.

N. Speicher-DIMM (1GB) 1

Die DIMM-Speichermodule müssen separat aufgerüstet werden, bevor man die "Dual Scan Funktion" des DP-771 benutzt.

Bestellen Sie ein DIMM-Speichermodul zusammen mit den Serviceteilen.

Einzelheiten hierzu finden Sie in den Anleitungen auf Seite 12.

N. Memoria DIMM (1GB) 1

La memoria DIMM deve essere espansa separatamente prima di usare la "Funzione di scansione dual" sull'unità DP-771.

Ordinare una memoria DIMM dalle parti di servizio.

per maggiori informazioni in merito si prega di leggere le istruzioni riportate a pagina 12.

N. 内存模组 DIMM (1GB) 1

在使用 DP-771 的「一次双面扫描功能」时，必需要增加内存卡。

请订购维修部件 DIMM 内存。

有关详情，请参阅第 12 页的说明。

N. 메모리 DIMM (1GB) 1

DP-771 의 「양면동시 스캔기능」을 사용하는 경우에는 별도 메모리 DIMM 의 증설이 필요합니다 .

서비스 부품으로 메모리 DIMM 을 발주해 주십시오 .


상세는 12 페이지를 참조해 주십시오 .

N. メモリーDIMM(1GB)..... 1

DP-771 の「両面同時読み込み機能」を使用する場合は、別途メモリーDIMM の増設が必要です。

サービスパーツでメモリーDIMM を発注してください。

詳細は 12 ページ参照のこと



Precautions

Be sure to remove any tape and/or cushioning material from supplied parts. The illustrations of the DP in the Installation Guide are for DP-771.

Procedure

When installing the DP, be sure to turn the MFP power off and disconnect the power plug from the wall outlet.

Attach the fixing fitting. (DP-770)

1. Align projections (1) of each fixing fitting (C) with holes (2) on the MFP and insert the fixing fittings (C) into the MFP.
2. Secure each fixing fitting (C) with two M4 x 14TP screws (G).

Précautions

Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies. Les schémas du DP dans le Guide d'installation concernent le DP-771.

Procédure

Lors de l'installation du DP, veillez à mettre l'interrupteur du MFP hors tension et à débrancher la fiche d'alimentation de la prise murale.

Mettre en place la fixation. (DP-770)

1. Aligner les saillies (1) de chacune des pièces de fixation (C) avec les trous (2) sur le MFP et insérer ces pièces (C) dans le MFP.
2. Fixer chacune des pièces de fixation (C) avec deux vis M4 x 14TP (G).

Precauciones

Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas. Las ilustraciones del DP en la Guía de instalación corresponden al DP-771.

Procedimiento

Cuando instale el DP, asegúrese de apagar el interruptor principal del MFP y desenchúfelo del tomacorriente de la pared.

Monte el herraje de fijación. (DP-770)

1. Alinee las salientes (1) de cada herraje de fijación (C) con los orificios (2) del MFP e inserte los herrajes de fijación (C) en el MFP.
2. Asegure cada uno de los herrajes de fijación (C) con dos tornillos M4 x 14TP (G).

Vorsichtsmaßnahmen

Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen. Die Abbildungen des DP in der Installationsanleitung gelten für Modell DP-771.

Verfahren

Schalten Sie vor Installation des DP unbedingt den MFP-Hauptschalter aus, und ziehen Sie den Netzstecker aus der Steckdose.

Anbringen der Befestigungshalterung. (DP-770)

1. Die Zapfen (1) jeder Befestigungshalterung (C) mit den Öffnungen (2) am MFP ausrichten und die Befestigungshalterungen (C) in den MFP einsetzen.
2. Jede Befestigungshalterung (C) mit zwei M4 x 14TP Schrauben (G) befestigen.

Precauzioni

Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite. Le illustrazioni del DP nella Guida all'installazione sono per il modello DP-771.

Procedura

Spegnere l'interruttore principale e sfilare la spina dell'MFP dalla presa prima di installare il DP.

Applicazione dell'accessorio di fissaggio. (DP-770)

1. Allineare le sporgenze (1) di ogni accessorio di fissaggio (C) con i fori (2) sull'MFP, ed inserire gli accessori di fissaggio (C) nell'MFP.
2. Bloccare ogni accessorio di fissaggio (C) con le due viti M4 x 14TP (G).

注意事項

如果附属品上带有固定胶带，缓冲材料时务必揭下。安装手册中关于 DP 的图示以 DP-771 为例。

安装步骤

安装 DP 时，请务必将 MFP 电源关闭，关拔下电源插头再进行安装作业。

安装固定附件。(DP-770)

1. 将各固定附件 (C) 上的突出部分 (1) 与 MFP 上的孔 (2) 对齐，然后将固定附件 (C) 插入 MFP 中。
2. 用两颗 M4×14TP 螺钉 (G) 固定各固定附件 (C)。

주의사항

동봉품에 고정 테이프, 완충재가 붙어 있는 경우에는 반드시 제거할 것. 설치순서에 기재되어 있는 DP 본체 일러스트는 DP-771 입니다.

설치순서

DP 본체를 설치할 때에는 반드시 MFP 본체의 주 전원 스위치를 OFF 로 하고 전원 플러그를 뺀 다음 작업을 할 것.

고정쇠의 부착 (DP-770)

1. 고정쇠 (C) 의 돌기 (1) 와 MFP 본체의 구멍 (2) 을 맞추고 MFP 본체에 고정쇠 (C) 를 끼웁니다.
2. 나사 M4×14TP(G) 각 2 개로 2 개의 고정쇠 (C) 를 고정합니다.

注意事項


同梱品に固定テープ、緩衝材が付いている場合は必ず取り外すこと。設置手順書に記載している DP 本体のイラストは、DP-771 です。

取付手順

DP 本体を設置するときは、必ず MFP 本体の主電源スイッチを OFF にし、電源プラグを抜いてから作業すること。

固定金具の取り付け (DP-770)

1. 固定金具 (C) の突起 (1) と MFP 本体の穴 (2) を合わせ、MFP 本体に固定金具 (C) を差し込む。
2. ビス M4×14TP(G) 各 2 本で 2 つの固定金具 (C) を固定する。



Attach the fixing fitting. (DP-771)

1. Align the projections (1) on the right fixing fitting (C) and on the wider left fixing fitting (C*) with the respective holes (2) in the MFP and then insert the fixing fittings into the MFP.
2. Secure each of the fixing fittings (C) (C*) with 2 M4 × 14TP screws (G).

Mettre en place la fixation. (DP-771)

1. Aligner les saillies (1) de la fixation droite (C) et de la fixation gauche plus large (C*) avec les trous correspondants (2) du MFP et insérer les fixations dans le MFP.
2. Fixer chaque des fixations (C) (C*) avec 2 vis TP M4 × 14 (G).

Monte el herraje de fijación. (DP-771)

1. Alinee los salientes (1) del herraje de fijación derecho (C) y del herraje de fijación izquierdo más ancho (C*) con los orificios correspondientes (2) del MFP y, después, inserte los herrajes de fijación en el MFP.
2. Asegure cada uno de los herrajes de fijación (C) (C*) con 2 tornillos TP M4 × 14 (G).

Anbringen der Befestigungshalterung. (DP-771)

1. Die Zapfen (1) an der rechten Befestigungshalterung (C) und an der breiteren Befestigungshalterung (C*) am MFP ausrichten und die Befestigungshalterungen in den MFP einsetzen.
2. Die Befestigungshalterungen (C) (C*) mit den 2 M4 × 14TP Schrauben (G) befestigen.

Applicazione dell'accessorio di fissaggio. (DP-771)

1. Allineare le sporgenze (1) sull'accessorio di fissaggio destro (C) e sull'accessorio di fissaggio sinistro più largo (C*) con i rispettivi fori (2) nell'MFP, e quindi inserire gli accessori di fissaggio nell'MFP.
2. Fissare ciascuno degli accessori di fissaggio (C) (C*) con 2 viti M4 × 14TP (G).

安装固定附件。(DP-771)


1. 将固定附件 (C) 从右侧、宽幅固定夹具 (C*) 从左侧将各自的突出部分 (1) 与 MFP 主机的孔 (2) 对齐并插入到 MFP 主机中。
2. 使用各 2 颗 M4×14 螺丝 TP (G) 来固定固定附件 (C) 与固定附件 (C*)

고정쇠의 부착 (DP-771)

1. 우측에 고정쇠 (C), 좌측에 광폭 고정쇠 (C*) 각각의 돌기 (1) 와 MFP 본체 구멍 (2) 을 맞추고 MFP 본체에 끼웁니다 .
2. 나사 M4×14TP(G) 각 2 개로 고정쇠 (C) 와 고정쇠 (C*) 를 고정합니다 .

固定金具の取り付け(DP-771)

1. 右側に固定金具 (C)、左側に幅広の固定金具 (C*) のそれぞれの突起 (1) と MFP 本体の穴 (2) を合わせ、MFP 本体に差し込む。
2. ビス M4×14TP(G) 各 2 本で固定金具 (C) と固定金具 (C*) を固定する。



Install the DP.

3. Align hinge hole (3) of DP (A) with pin (4) of fixing fitting (C), place DP (A) on the MFP.
4. Slide the DP (A) toward the front side and engage hinges into hooks (5) on fixing fittings (C).

Installer le DP.

3. Aligner le trou de la charnière (3) du DP (A) sur la goupille (4) de la fixation (C) et placer le DP (A) sur le MFP.
4. Faire glisser le DP (A) vers l'avant et engager les charnières dans les crochets (5) sur les pièces de fixation (C).

Instale el DP.

3. Alinee el orificio de bisagra (3) del DP (A) con el pasador (4) del herraje de fijación (C) y coloque el DP (A) en el MFP.
4. Deslice el DP (A) hacia el frente y enganche las bisagras en los ganchos (5) de los herrajes de fijación (C).

Installieren des DP.

3. Scharnierloch (3) des DP (A) mit Stift (4) der Befestigungshalterung (C) ausrichten, und DP (A) auf den MFP stellen.
4. Den DP (A) nach vorne hin verschieben und die Scharniere in die Haken (5) an den Befestigungshalterungen (C) einsetzen.

Montaggio del DP.

3. Allineare il foro della cerniera (3) del DP (A) con il perno (4) dell'accessorio di fissaggio (C), quindi posizionare il DP (A) sull'MFP.
4. Far scorrere il DP (A) verso il lato anteriore ed inserire le cerniere nei ganci (5) sugli accessori di fissaggio (C).

安装 DP


3. 将 DP (A) 的铰链孔 (3) 对准固定附件 (C) 的销 (4)，并将 DP (A) 放在 MFP 上。
4. 朝前侧滑动 DP (A)，然后将铰链与固定附件 (C) 上的卡扣 (5) 相啮合。

DP 본체 부착

3. DP 본체 (A) 의 힌지부 구멍 (3) 과 고정쇠 (C) 핀 (4) 을 맞추고 MFP 본체에 DP 본체 (A) 를 올립니다 .
4. DP 본체 (A) 를 미끄러트려 힌지부를 고정쇠 (C) 의 결쇠 (5) 에 끼웁니다 .

DP 本体の取り付け

3. DP 本体 (A) のヒンジ部の穴 (3) と固定金具 (C) のピン (4) を合わせ、MFP 本体に DP 本体 (A) を乗せる。
4. DP 本体 (A) を手前にスライドさせ、ヒンジ部を固定金具 (C) の引っ掛け部 (5) にはめ込む。



5. Install DP (A) onto the MFP securely with pin (F) and two M4 × 14TP screws (G).

5. Installer le DP (A) sur le MFP en le fixant à l'aide de la goupille (F) et des deux vis TP M4 × 14 (G).

5. Instale el DP (A) firmemente en el MFP con el pasador (F) y dos tornillos TP M4 × 14 (G)


5. DP (A) sicher mit einem Stift (F) und zwei M4 × 14TP Schrauben (G) am MFP befestigen.

5. Montare il DP (A) sull'MFP assicurandolo con il perno (F) e due viti M4 × 14TP (G).


5. 用销 (F) 和两颗 M4×14TP 螺钉 (G) 将 DP (A) 安装到 MFP 上。

5. 핀 (F) 1 개와 나사 M4×14TP(G) 2 개로 DP 본체 (A) 를 MFP 본체에 고정합니다 .


5. 핀 (F) 1 본과 비스 M4×14TP(G) 2 본으로 DP 本体 (A) 를 MFP 本体에 고정한다 .



Install the angle control fitting.
To adjust DP open-close angle 60 degrees
 6. Install angle control fitting (D) at the rear side of the right hinge with two M4 x 14TP screws (G).



To adjust DP open-close angle 30 degrees
 7. Open the upper cover (6) of the DP (A).
 8. Remove the 3 TP screws (7) and the screw (8), and remove the strap (9) from the rear cover (10). Then remove the DP (A) rear cover (10).



9. Remove stop ring (11) of angle control fitting (D) that has been installed in step 6 to remove shaft (12).

Installer la fixation d'angle.
Pour régler l'angle d'ouverture/de fermeture du DP de 60 degrés
 6. Placer la fixation d'angle (D) à l'arrière de la charnière droite à l'aide des deux vis TP M4 x 14 (G).

Pour régler l'angle d'ouverture/de fermeture du DP de 30 degrés
 7. Ouvrir le couvercle supérieur (6) du DP (A).
 8. Déposer les 3 vis TP (7) et la vis (8), puis déposer la courroie (9) du couvercle arrière (10). Déposer ensuite le couvercle arrière (10) du DP (A).

9. Retirer l'anneau de butée (11) de la fixation d'angle (D) installée à l'étape 6 pour enlever la tige (12).

Instale el herraje de control de ángulo.
Para ajustar el DP, abra o cierre el ángulo 60 grados
 6. Instale el herraje de control de ángulo (D) en el lado trasero de la bisagra derecha con dos tornillos TP M4 x 14 (G).

Para ajustar el DP, abra o cierre el ángulo 30 grados
 7. Abra la cubierta superior (6) del DP (A).
 8. Quite los 3 tornillos TP (7) y el tornillo (8) y quite la correa (9) de la cubierta trasera (10). Después, quite la cubierta trasera (10) del DP (A).

9. Retire el anillo de retención (11) del herraje de control de ángulo (D) que se instaló en el paso 6 para retirar el eje (12).

Installieren der Winkeleinstellbefestigung.
Einstellen des Öffnungs-/Schließungswinkels des DP um 60 Grad
 6. Winkeleinstellbefestigung (D) an der Rückseite des rechten Scharniers mit zwei M4 x 14TP Schrauben (G) befestigen.

Einstellen des Öffnungs-/Schließungswinkels des DP um 30 Grad
 7. Die obere Abdeckung (6) des DP (A) öffnen.
 8. Die 3 TP-Schrauben (7) und die Schraube (8) entfernen und dann den Riemen (9) von der hinteren Abdeckung (10) abnehmen. Dann die hintere Abdeckung (10) des DP (A) abnehmen.

9. Anschlagring (11) von der Winkeleinstellbefestigung (D) abnehmen, die in Schritt 6 montiert wurde, um die Welle (12) zu entfernen.

Montaggio dell'accessorio di regolazione angolare.
Per regolare l'angolo di chiusura / apertura del DP a 60 gradi
 6. Montare l'accessorio di regolazione angolare (D) sul lato posteriore della cerniera destra con due viti M4 x 14TP (G).

Per regolare l'angolo di chiusura / apertura del DP a 30 gradi
 7. Aprire il pannello superiore (6) del DP (A).
 8. Rimuovere le 3 viti TP (7) e la vite (8), e quindi rimuovere la cinghietta (9) dal coperchio posteriore (10). Quindi rimuovere il coperchio posteriore (10) del DP (A).

9. Rimuovere l'anello di bloccaggio (11) dell'accessorio di regolazione angolare (D) che era stato installato al Punto 6 per rimuovere l'albero (12).

安装角度控制附件。
 若要将DP的开关角度调整为60度
 6. 在右部铰链的后部使用两颗M4x14TP螺钉(G)安装角度控制附件(D)。

若要将DP的开关角度调整为30度
 7. 打开DP(A)的上盖板(6)。
 8. 拆除3颗TP螺丝(7)和1颗螺丝(8),将带子(9)从后盖板(10)上拆除,拆下DP主机(A)的后盖板(10)。

9. 拆下在第6步中安装的角度控制配件(D)的止动环(11),以将轴(12)拆下。

각도규제쇠의 부착
 DP 개폐각도를 60도로 설정하는 경우
 6. 우 힌지 뒷측에 나사 M4x14TP(G) 2개로 각도규제쇠(D)를 부착합니다.


DP 개폐 각도를 30도로 설정하는 경우
 7. DP 본체(A)의 DP 윗커버(6)를 엽니다.
 8. TP 나사(7) 3개와 나사(8) 1개를 빼고 스트랩(9)을 뒷커버(10)에서 제거해 DP 본체(A)의 뒷커버(10)를 제거합니다.

9. 순서 6에서 부착한 각도규제쇠(D)의 스톱링(11) 1개를 제거하고 시프트(12)를 제거합니다.

角度規制金具の取り付け
 DP 開閉角度を 60 度に設定する場合
 6. 右ヒンジ後側にビス M4x14TP(G) 2本で角度規制金具(D)を取り付ける。

DP 開閉角度を 30 度に設定する場合
 7. DP 本体(A)のDP 上カバー(6)を開く。
 8. TP ビス(7)3本とビス(8)1本を外し、ストラップ(9)を後カバー(10)から外して、DP 本体(A)の後カバー(10)を取り外す。

9. 手順6で取り付けした角度規制金具(D)のストップリング(11)1個を外し、シャフト(12)を取り外す。



10. Insert shaft (12) into the rear side of the right hinge.
11. Attach stop ring (11) to the notch of shaft (12) and secure shaft (12).
12. Use the 3 TP screws (7) and the screw (8) to replace the rear cover (10) removed in step 8.

10. Insérer la tige (12) à l'arrière de la charnière droite.
11. Fixer l'anneau de butée (11) sur l'encoche de la tige (12) et mettre en place la tige (12).
12. Reposer le couvercle arrière (10) déposé à l'étape 8 et le fixer à l'aide des 3 vis TP (7) et de la vis (8).

10. Inserte el eje (12) en el lado trasero de la bisagra derecha.
11. Fije el anillo de retención (11) a la muesca del eje (12) y asegure el eje (12).
12. Use los 3 tornillos TP (7) y el tornillo (8) para volver a colocar la cubierta trasera (10) quitada en el paso 8.


10. Welle (12) in die Rückseite des rechten Scharniers einsetzen.
11. Anschlagring (11) an der Wellenkerbe (12) anbringen und Welle befestigen (12).
12. Die in Schritt 8 ausgebaute hintere Abdeckung (10) mittels der 3 TP-Schrauben (7) und der Schraube (8) wieder anbringen.

10. Inserire l'albero (12) nella parte posteriore della cerniera destra.
11. Applicare l'anello di bloccaggio (11) nell'incavo dell'albero (12) e assicurare l'albero (12).
12. Utilizzare le 3 viti TP (7) e la vite (8) per ricollocare il coperchio posteriore (10) rimosso nel passo 8.

10. 将轴 (12) 插入到右部铰链的后部。
11. 将止动环 (11) 安装到轴 (12) 的切口并将轴 (12) 固定。
12. 使用 3 颗树脂固定螺丝 (7) 和 1 颗螺丝 (8) 按原样安装在步骤 8 中拆下的后盖板 (10)。

10. 우 힌지 뒷측에 시프트 (12) 를 삽입합니다 .
11. 스톱링 (11) 을 시프트 (12) 의 구에 부착하고 시프트 (12) 를 고정합니다 .
12. 순서 8 에서 떼어낸 뒷 커버 (10) 를 수지 고정 나사 (7) 3 개와 나사 (8) 1 개로 원래 자리에 부착합니다 .

10. 右ヒンジ後側にシャフト (12) を挿入する。
11. ストップリング (11) をシャフト (12) の溝に取り付け、シャフト (12) を固定する。
12. 手順 8 で外した後カバー (10) を TP ビス (7) 3 本とビス (8) 1 本で元通り取り付ける。



13. Remove the screw (13) and remove the DP cable connection cover (14).

13. Déposer la vis (13) et déposer le couvercle de la connexion du câble du DP (14).

13. Quite el tornillo (13) y quite la cubierta de conexión del cable del DP (14).


13. Die Schraube (13) entfernen und die Abdeckung (14) des DP-Kabelanschlusses abnehmen.

13. Rimuovere la vite (13) e quindi rimuovere il coperchio di la connessione del cavo DP (14).

13. 拆除 1 颗螺丝 (13)，拆下 DP 电缆连接盖板 (14)。

13. DP 신호선의 접속 (DP-770 만)
DP-771 은 P8 의 순서 13 으로 진행 .
13. 나사 (13) 1 개를 빼고 DP 케이블 접속커버 (14) 를 제거합니다 .

13. DP 信号線の接続 (DP-770 のみ)
DP-771 は P8 の手順 13 へ進む。
13. ビス (13) 1 本を外して、DP ケーブル接続カバー (14) を外す。



14. Remove the DP cable connection cap (15) from the DP cable connection cover (14).

14. Déposer le chapeau de la connexion du câble du DP (15) du couvercle de la connexion du câble du DP (14).

14. Quite la tapa de conexión del cable del DP (15) de la cubierta de conexión del cable del DP (14).


14. Die Kappe (15) des DP-Kabelanschlusses von der Abdeckung (14) des DP-Kabelanschlusses abnehmen.

14. Rimuovere il cappuccio (15) per la connessione del cavo DP dal coperchio di connessione del cavo DP (14).


14. 从 DP 电缆连接盖板 (14) 上拆下 DP 电缆连接用盖 (15)。

14. DP 케이블 접속용커버 (14) 에서 DP 케이블 접속용 덮개 (15) 를 제거합니다 .


14. DP 케이블接続용커버 (14) から DP 케이블接続용フタ (15) を取り外す。



15. Pass the DP signal line (16) through the right-hand hole in the DP cable cover (E) and then pass the DP signal line (16) through the DP cable connection cover (14).



16. Plug the DP signal line connector (17) into the connector (18) on the ISC PWB.



17. Attach the DP cable cover (E) to the DP cable connection cover (14) and install the DP cable connection cover (14) using the screw (13) removed in step 13. Proceed to step 24 on page 13

15. Faire passer le câble du circuit de transmission du DP (16) dans le trou se trouvant à droite sur le couvercle du câble du DP (E) puis faire passer le câble du circuit de transmission du DP (16) dans le couvercle de la connexion du câble du DP (14).

16. Enficher le connecteur du câble du circuit de transmission du DP (17) dans le connecteur (18) sur l'ISC PWB.

17. Fixer le couvercle du câble du DP (E) sur le couvercle de la connexion du câble du DP (14) et installer le couvercle de la connexion du câble du DP (14) à l'aide de la vis (13) déposée à l'étape 13. Passer à l'étape 24 de la page 13.

15. Pase la línea de señales del DP (16) a través del orificio derecho de la cubierta del cable del DP (E) y, después, pase la línea de señales del DP (16) a través de la cubierta de conexión del cable del DP (14).

16. Enchufe el conector de la línea de señales del DP (17) al conector (18) PWB del ISC.

17. Fije la cubierta del cable del DP (E) a la cubierta de conexión del cable del DP (14) e instale la cubierta de conexión del cable del DP (14) usando el tornillo (13) quitado en el paso 13. Vaya al paso 24 de la página 13.

15. Die DP-Signalleitung (16) durch die rechte Öffnung in der DP-Kabelabdeckung (E) führen und dann die DP-Signalleitung (16) durch die Abdeckung (14) des DP-Kabelanschlusses führen.

16. Den Stecker (17) der DP-Signalleitung an den Stecker (18) der ISC-Leiterplatte anschließen.

17. Die DP-Kabelabdeckung (E) an der Abdeckung (14) des DP-Kabelanschlusses anbringen und die Abdeckung (14) des DP-Kabelanschlusses mittels der in Schritt 13 entfernten Schraube (13) befestigen. Weitergehen zu Schritt 24 auf Seite 13.

15. Passare la linea del segnale DP (16) attraverso il foro al lato destro nel coperchio del cavo DP (E), e quindi passare la linea del segnale DP (16) attraverso il coperchio di connessione del cavo DP (14).

16. Inserire il connettore (17) della linea del segnale DP nel connettore (18) sull'ISC PWB.

17. Fissare il coperchio del cavo DP (E) al coperchio di connessione del cavo DP (14), e quindi installare il coperchio di connessione del cavo DP (14) utilizzando la vite (13) rimossa nel passo 13. Procedere al passo 24 a pagina 13.

15. 将 DP 信号线 (16) 穿过 DP 电缆盖板 (E) 的右侧的孔, 接着将 DP 信号线 (16) 穿过 DP 电缆连接盖板 (14)。

16. 将 DP 信号线连接器 (17) 与 ISC 电路板的连接器 (18) 相连接。

17. 将 DP 电缆盖板 (E) 安装到 DP 电缆连接盖板 (14) 上, 使用步骤 13 中拆下的 1 颗螺丝 (13) 来安装 DP 电缆连接盖板 (14)。跳至 P13 的步骤 24。

15. DP 케이블커버 (E) 의 우측 구멍에 DP 신호선 (16) 을 통과시키고 또한, DP 케이블 접속용 커버 (14) 에 DP 신호선 (16) 을 통과시킵니다.


16. DP 신호선 커넥터 (17) 를 ISC 기판의 커넥터 (18) 에 접속합니다.

17. DP 케이블 커버 (E) 를 DP 케이블 접속커버 (14) 에 부착하고 순서 13 에서 제거한 나사 (13) 1 개로 DP 케이블 접속커버 (14) 를 부착합니다. P13 의 순서 24 로 진행.

15. DP ケーブルカバー (E) の右側の穴に DP 信号線 (16) を通し、さらに DP ケーブル接続用カバー (14) に DP 信号線 (16) を通す。


16. DP 信号線コネクタ (17) を ISC 基板のコネクタ (18) に接続する。

17. DP ケーブルカバー (E) を DP ケーブル接続カバー (14) に取り付け、手順 13 で外したビス (13) 1 本で DP ケーブル接続カバー (14) を取り付ける。P13 の手順 24 へ進む。



Connect the DP signal line (DP-771 only)

13. Remove the 8 screws (19) and remove the upper rear cover (20) of the MFP.



14. Remove the DP cable connection cap (22) from the DP cable connection cover (21).

Raccorder le circuit de transmission (DP-771 uniquement)

13. Déposer les 8 vis (19) et déposer le couvercle arrière supérieur (20) du MFP.

14. Déposer le chapeau de la connexion du câble du DP (22) du couvercle de la connexion du câble du DP (21).

Conecte la línea de señales del DP (DP-771 solamente)

13. Quite los 8 tornillos (19) y quite la cubierta trasera superior (20) del MFP.

14. Quite la tapa de conexión del cable del DP (22) de la cubierta de conexión del cable del DP (21)

Anschließen der DP-Signalleitungen (nur DP-771)

13. Die 8 Schrauben (19) entfernen und die obere hintere Abdeckung (20) des MFP abnehmen.

14. Die Kappe (22) des DP-Kabelanschlusses von der Abdeckung (21) des DP-Kabelanschlusses abnehmen.

Collegare la linea del segnale DP (solo DP-771)

13. Rimuovere le 8 viti (19) e quindi rimuovere il coperchio superiore posteriore (20) dell'MFP.

14. Rimuovere il cappuccio (22) per la connessione del cavo DP dal coperchio di connessione del cavo DP (21).

连接 DP 信号线 (仅限 DP-771)

13. 拆除 8 颗螺丝 (19), 拆下 MFP 主机的后上方盖板 (20)。

14. 从 DP 电缆连接盖板 (21) 上拆下 DP 电缆连接用盖 (22)。

DP 신호선의 접속 (DP-771 만)


13. 나사 (19) 8 개를 제거하고 MFP 본체의 뒷면 상커버 (20) 를 떼어 냅니다 .

14. DP 케이블 접속용커버 (21) 에서 DP 케이블 접속용 덮개 (22) 를 제거합니다 .

DP 信号線の接続 (DP-771 のみ)

13. ビス (19) 8 本を外し、MFP 本体の後上カバー (20) を取り外す。


14. DP ケーブル接続用カバー (21) から DP ケーブル接続用フタ (22) を取り外す。



15. Pass the DP signal line (23) through the right-hand hole in the DP cable cover (E). Then pass the red CIS data line (24) through the left-hand hole.

NOTICE

Pass the DP signal line (23) and CIS data line (24) through the same hole could result in abnormal images. Be sure that they pass through separate holes as shown in the figure.



16. Install the DP cable cover (E) and DP cable connection cover (21).

15. Faire passer le câble du circuit de transmission du DP (23) dans le trou se trouvant à droite sur le couvercle du câble du DP (E). Faire ensuite passer le câble rouge de la ligne des données du CIS (24) par le trou se trouvant côté gauche.

AVIS

Faire passer le câble du circuit de transmission du DP (23) et le câble de la ligne des données du CIS (24) dans le même passage de câble risque de résulter en production d'images anormales. S'assurer que ces deux câbles sont tirés dans des passages de câble différents comme illustré ici.

16. Installer le couvercle du câble du DP (E) et le couvercle de la connexion du câble du DP (21).

15. Pase la línea de señales del DP (23) a través del orificio derecho de la cubierta del cable del DP (E). Después, pase la línea de datos CIS roja (24) a través del orificio izquierdo.

AVISO

Si pasa la línea de señales del DP (23) y la línea de datos CIS (24) a través del mismo orificio podría provocar imágenes anormales. Asegúrese de que pasen a través de orificios distintos como aparece en la ilustración.

16. Instale la cubierta del cable del DP (E) y la cubierta de conexión del cable del DP (21).

15. Die DP-Signalleitung (23) durch die rechte Öffnung in der DP-Kabelabdeckung (E) führen. Dann die rote CIS-Signalleitung (24) durch die linke Öffnung führen.

HINWEIS

Wenn Sie die DP-Signalleitung (23) und die CIS-Datenleitung (24) durch dieselbe Öffnung führen, könnte es zu Bildfehlern kommen. Achten Sie darauf, dass die Leitungen wie abgebildet durch verschiedene Öffnungen geführt werden.

16. Die DP-Kabelabdeckung (E) und die Abdeckung (21) des DP-Kabelanschlusses anbringen.

15. Passare la linea del segnale DP (23) attraverso il foro al lato destro nel coperchio del cavo DP (E). Quindi passare la linea dati rossa CIS (24) attraverso il foro al lato sinistro.

NOTIFICA

Facendo passare la linea del segnale DP (23) e la linea dati CIS (24) attraverso lo stesso foro, potrebbe causare immagini anormali. Assicurarsi che tali linee passino attraverso fori separati, come viene mostrato nella figura.

16. Installare il coperchio del cavo DP (E) e il coperchio di connessione del cavo DP (21).

15. 将 DP 信号线 (23) 穿过 DP 电缆盖板 (E) 的右侧的孔, 接着将红色的 CIS 数据线 (24) 穿过左侧的孔。

注意

DP 信号线 (23) 与 CIS 数据线 (24) 如果穿过同一个孔, 可能会发生图像异常, 因此必须如图所示分别穿过左右两侧的孔。

16. 将 DP 电缆盖板 (E) 安装到 DP 电缆连接盖板上。

15. DP 케이블커버 (E) 의 우측 구멍에 DP 신호선 (23) 을 통과시킵니다 . 거기에 좌측 구멍에 적색 CIS 데이터선 (24) 을 통과시킵니다 .

주의

DP 신호선 (23) 과 CIS 데이터선 (24) 을 같은 구멍에 통과시키면 이상화상이 발생할 가능성이 있기 때문에 그림과 같이 좌우의 구멍에 각각 넣을 것 .


16. DP 케이블 커버 (E) 를 DP 케이블 접속용 커버 (21) 에 부착합니다 .

15. DP 케이블커버 (E) 의 右側の穴に DP 信号線 (23) を通す。さらに左側の穴に赤色の CIS データ線 (24) を通す。


注意

DP 信号線 (23) と CIS データ線 (24) を同じ穴に通すと異常画像が発生する可能性があるため、図の様に左右の穴に別々に入れること。


16. DP 케이블커버 (E) を DP 케이블 接続용 커버 (21) に取り付け。



17. Plug the DP signal line connector (23) into the connector (25) on the ISC PWB.



18. Remove the 2 fixing screws (30) and remove the plate (31).



Installing the DP relay PWB

19. Connect connector (26) on the DP relay PWB (M) to connector (27) on the MFP.

17. Enfiler le connecteur du câble du circuit de transmission du DP (23) dans le connecteur (25) sur l'ISC PWB.

18. Déposer les 2 vis de fixation (30) et déposer la plaque (31).

Installation de la carte de circuit imprimé relais du DP

19. Raccorder le connecteur (26) sur la carte de circuit imprimé relais du DP (M) au connecteur (27) sur le MFP.

17. Enchufe el conector de la línea de señales del DP (23) al conector (25) PWB del ISC.

18. Quite los 2 tornillos de fijación (30) y quite la placa (31).

Instalación del PWB del relé del DP

19. Conecte el conector (26) del PWB del relé del DP (M) al conector (27) del MFP.

17. Den Stecker (23) der DP-Signalleitung an den Stecker (25) der ISC-Leiterplatte anschließen.

18. Entfernen Sie die 2 Befestigungsschrauben (30) und dann die Platte (31).

Installieren der DP-Relaisleiterplatte

19. Den Stecker (26) an der DP-Relaisleiterplatte (M) mit dem Stecker (27) am MFP verbinden

17. Inserire il connettore (23) della linea del segnale DP nel connettore (25) sull'ISC PWB.

18. Rimuovere le 2 viti di fissaggio (30) e quindi rimuovere la piastra (31).

Installazione della scheda a circuiti stampati di comunicazione DP

19. Collegare il connettore (26) sulla scheda a circuiti stampati di comunicazione DP (M) al connettore (27) sull'MFP.

17. 将DP信号线连接器(23)与ISC电路板的接插件(25)相连接。

18. 拆下2颗固定螺丝(30)后,再卸下金属板(31)。

安装 DP 中继板

19. 将 DP 中继板 (M) 上的接插件 (26) 连接至 MFP 上的接插件 (27)。

17. DP 신호선 커넥터 (23) 를 ISC 기판의 커넥터 (25) 에 접속합니다 .

18. 고정나사 (30) 2 개를 제거하고 판금 (31) 을 제거합니다 .

DP 중계기판의 부착


19. DP 중계기판 (M) 의 커넥터 (26) 를 MFP 본체의 커넥터 (27) 에 접속합니다 .

17. DP 信号線コネクタ (23) を ISC 基板のコネクタ (25) に接続する。


18. 固定ビス (30) 2 本を外し、板金 (31) を外す。

DP 中継基板の取り付け

19. DP 中継基板 (M) のコネクタ (26) を、MFP 本体のコネクタ (27) に接続する。



20. Fix the DP relay PWB (M) using the plate (31) and 2 screws (30).



21. Plug the CIS data line (24) into the connector (28) on the DP relay PWB (M).

20. Fixer la carte de CI relais du DP (M) à l'aide de la plaque (31) et de 2 vis (30).

21. Enfiler le câble de la ligne des données du CIS (24) dans le connecteur (28) de la carte de circuit imprimé relais du DP (M).

20. Fije el PWB del relé del DP (M) usando la placa (31) y los dos tornillos (30).

21. Enchufe la línea de datos CIS (24) al conector (28) PWB del relé del DP (M).

20. Befestigen Sie die DP-Relaisleiterplatte (M) mit Hilfe der Platte (31) und der 2 Schrauben (30).

21. Die CIS-Datenleitung (24) an den Stecker (28) auf der DP-Relaisleiterplatte (M) anschließen.

20. Fissare la scheda a circuiti stampati di comunicazione DP (M) usando la piastra (31) e 2 viti (30).

21. Inserire la linea dati CIS (24) nel connettore (28) sulla scheda a circuiti stampati di comunicazione DP (M).

20. 用金属板 (31) 和 2 颗螺丝 (30) 来固定 DP 中继板 (M)。


21. 将 CIS 数据线 (24) 连接到 DP 中继电路板 (M) 上的接插件 (28) 上。

20. DP 중계기판 (M) 을 판금 (31), 나사 (30) 2 개로 고정합니다 .

21. DP 중계기판 (M) 상의 커넥터 (28) 에 CIS 데이터선 (24) 을 접속합니다 .

20. DP 中继基板 (M) を板金 (31)、ビス (30) 2 本で固定する。

21. DP 中继基板 (M) 上のコネクタ (28) に CIS データ線 (24) を接続する。



Steps for expanding the memory DIMM (1GB)(35, 45 and 55 ppm monochrome machines only)

22. Insert the memory DIMM (N) into the memory slot (YS2) of the main PWB.
(Insert all the way until it clicks)

23. Replace the upper rear cover (20) of the MFP using the 8 screws (19).

Opérations pour l'expansion de la mémoire DIMM (1GB) (machines monochromes 35, 45 et 55 ppm uniquement)

22. Insérer la mémoire DIMM (N) dans la fente mémoire (YS2) de la carte de CI principale.
(Insérer à fond jusqu'au clic)

23. Reposer le couvercle arrière supérieur (20) sur le MFP à l'aide des 8 vis (19).

Pasos para ampliar la memoria DIMM (1GB) (máquinas monocromáticas de 35, 45 y 55 ppm solamente)

22. Inserte la memoria DIMM (N) en la ranura para memoria (YS2) en el PWB principal.
(Insértela hasta escuchar un clic)

23. Vuelva a colocar la cubierta trasera superior (20) del MFP usando los 8 tornillos (19).

Schritte zur Aufrüstung der DIMM-Speichermodule (1GB) (nur 35, 45 und 55 ppm Monochrommaschinen)

22. Setzen Sie das DIMM-Speichermodul (N) in die Speicherbank (YS2) der Hauptleiterplatte ein.
(Drücken Sie sie bis zum Einrasten ein.)

23. Die obere hintere Abdeckung (20) des MFP wieder mit den 8 Schrauben (19) anbringen.

Passi per l'espansione della memoria DIMM (1GB) (solo per le macchine monocromatiche 35, 45 e 55 ppm)

22. Inserire la memoria DIMM (N) nello slot della memoria (YS2) sulla scheda principale PWB.
(Inserire completamente finché non scatta in posizione con un clic)

23. Ricollocare il coperchio superiore posteriore (20) dell'MFP utilizzando le 8 viti (19).

内存卡 (1GB) 的增加步骤 (仅对于 35 张、45 张和 55 张的黑白机)

22. 把内存卡 (N) 插入主板的内存插槽 (YS2)。
(插到底部, 直到发出咔嚓声为止)

23. 使用 8 颗螺丝 (19) 按原样安装 MFP 主机的后上方盖板 (20)。

메모리 DIMM (1GB) 의 증설순서 (흑백기 35 매, 45 매, 55 매만)


22. 주 회로기판의 메모리 슬롯 (YS2) 에 메모리 DIMM(N) 을 삽입합니다.
(딸깍하고 소리가 날 때까지 삽입할 것.)

23. 나사 (19) 8 개로 MFP 본체 뒷면 상커버 (20) 를 원래대로 부착합니다.

メモリーDIMM(1GB) の増設手順 (モノクロ機の 35 枚機、45 枚機、55 枚機のみ)

22. 主回路基板のメモリースロット (YS2) にメモリーDIMM(N) を挿入する。
(カチッと音がするまで挿入すること)

23. ビス (19) 8 本で、MFP 本体の後上カバー (20) を元通り取り付け。



Fasten the original mat.

24. Place original mat (B) with its Velcro (29) upward over the contact glass.

Align original mat (B) corner that has 90 degrees of angle with the inner left corner of the original instruction panel.

25. Close DP (A) and attach original mat (B) onto it with Velcro.

Fixer la plaque d'original.

24. Placer la plaque d'original (B) sur la vitre d'exposition, en orientant les bandes Velcro (29) vers le haut.

Aligner le coin du plateau d'original (B) faisant un angle de 90 degrés avec le coin gauche interne du panneau d'instructions d'original.

25. Abaisser le DP (A) et y fixer la plaque d'original (B) à l'aide des bandes Velcro.

Fije la alfombrilla para originales.

24. Coloque la alfombrilla para originales (B) con el velcro (29) hacia arriba sobre el cristal de contacto.

Alinee la esquina que tiene un ángulo de 90 grados de la alfombrilla para originales (B) con la esquina interior izquierda del panel de instrucciones para el original.

25. Cierre el DP (A) y fije la alfombrilla para originales (B) con el velcro.

Befestigen der Originalmatte.

24. Die Originalmatte (B) mit dem Klettband (29) nach oben über das Kontaktglas legen.

Die Ecke der Originalmatte (B), die einen 90-Grad-Winkel aufweist, mit der linken, inneren Kante des Originalbedienfeldes ausrichten.

25. Den DP (A) schließen und die Originalmatte (B) mit dem Klettband auf ihm befestigen.

Fissaggio del tappetino originale.

24. Posizionare il tappetino originale (B) con il velcro (29) rivolto verso l'alto sul vetro di appoggio.

Allineare l'angolo di 90 gradi del coprioriginale (B) con l'angolo interno sinistro del pannello di controllo originale.

25. Chiudere il DP (A) e applicarvi il tappetino originale (B) con il velcro.

粘貼原稿墊。

24. 將原稿墊 (B) 放置在稿台玻璃上，并使魔术貼 (29) 向上。

將原稿墊 (B) 的 90 度角對準原稿指示板的內部左角。

25. 關閉 DP (A)，使原稿墊 (B) 粘貼到 DP 上。

원고매트 부착

24. 매직테이프 (29) 를 위로 향하게 하고 원고매트 (B) 를 원고대 유리판에 놓습니다 .

원고매트 (B) 는 90° 가 되어 있는 각을 원고 지시판의 좌측 안에 맞출 것 .


25. DP 본체 (A) 를 내리고 원고매트 (B) 를 DP 본체 (A) 에 부착합니다 .

原稿マットの貼り付け

24.マジックテープ (29) を上に向けて、原稿マット (B) をコンタクトガラス上に置く。

原稿マット (B) は 90° になっている角を原稿指示板の左奥に合わせること。


25. DP 本体 (A) を下ろし、原稿マット (B) を DP 本体 (A) に貼り付ける。



Installing the hinge cover (DP-771 only)

For the DP-770, proceed to step 28 on page 15.

26. Install the left hinge cover (H).



27. Install the right hinge cover (I) using the M3 × 8 screw BLACK (J).

Installation des couvercles de charnière (DP-771 uniquement)

Pour le DP-770, passer à l'étape 28 de la page 15.

26. Installer le couvercle de la charnière gauche (H).

27. Installer le couvercle de la charnière droite (I) à l'aide de la vis M3 × 8 NOIRE (J).

Instalación de la cubierta de las bisagras (DP-771 solamente)

Para el DP-770, vaya al paso 28 de la página 15.

26. Instale la cubierta de la bisagra izquierda (H).

27. Instale la cubierta de la bisagra derecha (I) usando el tornillo M3 × 8 NEGRO (J).

Installieren der Scharnierabdeckung (nur DP-771)

Beim DP-770 gehen Sie zum Schritt 28 auf Seite 15 weiter.

26. Die linke Scharnierabdeckung (H) anbringen.

27. Die rechte Scharnierabdeckung (I) mit der M3 × 8 Schraube SCHWARZ (J) anbringen.

Installazione del coperchio cerniera (solo DP-771)

Per DP-770, procedere con il punto 28 a pagina 15.

26. Installare il coperchio cerniera sinistra (H).

27. Installare il coperchio cerniera destra (I) utilizzando la vite M3 × 8 NERA (J).

安装铰链盖板 (仅限 DP-771)

DP-770 跳至 P15 的步骤 28。

26. 安装左部铰链盖板 (H)。

27. 使用 1 颗 M3×8 螺丝 BLACK (J) 来安装右部铰链盖板 (I)。

힌지커버 부착 (DP-771 만)

DP-770 은 P15 의 순서 28 으로 진행 .

26. 좌측 힌지커버 (H) 를 부착합니다 .


27. 나사 M3×8BLACK(J) 1 개로 우측 힌지커버 (I) 를 부착합니다 .

ヒンジカバーの取り付け (DP-771 のみ)

DP-770 は、P15 の手順 28 に進む。

26. 左ヒンジカバー (H) を取り付ける。

27. ビス M3×8BLACK (J) 1 本で右ヒンジカバー (I) を取り付ける。



Adhere the label

28. Clean the label on the original table with alcohol.

29. Adhere Label "Operation procedure" (K) of which the language corresponding to the destination of the MFP onto the existing label on the original table. Figure (a)

30. Adhere Caution label "Original face up!" (L) of which the language corresponding to the destination of the MFP onto the label on the original table. Figure (b)

Coller l'étiquette relative

28. Avec de l'alcool, nettoyer l'étiquette se trouvant sur le plateau d'original.

29. Coller l'étiquette "Processus opératoire" (K) dans la langue correspondant au destinataire du MFP sur l'étiquette existante sur le plateau d'original du DP. Figure (a)

30. Coller l'étiquette de mise en garde "Original en haut!" (L) dans la langue correspondant au destinataire du MFP sur l'étiquette du plateau d'original. Figure (b)

Pegue la etiqueta

28. Limpie con alcohol la etiqueta de la cubierta de originales.

29. Adhiera la etiqueta "Procedimiento operativo" (K) del idioma correspondiente al destino del MFP sobre la etiqueta que se encuentra sobre la cubierta de originales. Figura (a)

30. Pegue la etiqueta de precaución "¡La cara del original hacia arriba!" (L), del idioma que corresponde al destino del MFP, sobre la etiqueta en la cubierta de originales. Figura (b)

Anbringen des Schildes

28. Das Schild auf dem Originalbedienfeld mit Alkohol reinigen.

29. Das Schild „Funktionsanweisung“ (K) in der Sprache des jeweiligen Einsatzlandes des MFP auf das vorhandene Schild auf dem Originalbedienfeld aufkleben. Abbildung (a)

30. Das Warnschild „Originalschriftseite nach oben!“ (L) in der Sprache des jeweiligen Einsatzlandes des MFP auf das vorhandene Schild auf dem Originalbedienfeld aufkleben. Abbildung (b)

Applicazione dell'etichetta

28. Pulire con alcool l'etichetta sul piano originale.

29. Far aderire l'etichetta "Procedura di funzionamento" (K) corrispondente alla lingua di destinazione dell'MFP, sull'etichetta esistente sul piano originale. Figura (a)

30. Far aderire l'etichetta di avvertenza "Originale rivolto verso l'alto!" (L) corrispondente alla lingua di destinazione dell'MFP, sull'etichetta del piano originale. Figura (b)

粘貼标签 (220V 规格以外)

28. 使用酒精清洁原稿台上的标签。

29. 将“动作步骤”标签(K) (其语言与对应的MFP销往目的地语言一致)粘貼至原稿台的现有标签上。图(a)

30. 将小心标签原稿正面朝上! (L) (其语言与对应的MFP销往目的地语言一致)粘貼至原稿台的标签上。图(b)

라벨 부착 (220V 사양이외)

28. 원고 테이블의 라벨 위를 알코올청소 합니다.

29. MFP 본체에 사용하는 국가의 언어에 맞는 조작라벨(K)을 원고 테이블 라벨위에 붙입니다. 그림(a)


30. MFP 본체에 사용하는 국가의 언어에 맞는 원고표용 라벨(L)을 원고 테이블 위에 붙입니다. 그림(b)

ラベルの貼り付け (100V仕様以外)

28. 原稿テーブルのラベル上をアルコール清掃する。

29. MFP 本体を使用する国の言語に合った操作ラベル(K)を原稿テーブルのラベル上に貼り付ける。図(a)

30. MFP 本体を使用する国の言語に合った原稿表向きラベル(L)を原稿テーブルのラベル上に貼り付ける。図(b)



[Operation check]

1. To check the machine operation, prepare original (a) where 4 lines (b) are drawn 20 mm from the edges of the A3 sheet and 1 line (c) is drawn at its center.
2. Connect the power plug of the MFP into the wall outlet and turn the main power switch on.
3. Set the original (a) on the DP and perform a test copy to check the operation and the copy example.

[Vérification du fonctionnement]

1. Pour vérifier le bon fonctionnement de l'appareil, préparer un original (a) sur lequel sont tracées 4 lignes (b) à 20 mm des bords de la feuille A3 et 1 ligne (c) en son axe.
2. Brancher la fiche d'alimentation du MFP sur la prise murale et mettre l'appareil sous tension.
3. Placer l'original (a) sur le DP et effectuer une copie de test pour vérifier le fonctionnement et l'exemple de copie.

[Verifique el funcionamiento]

1. Para comprobar el funcionamiento del aparato, prepare un original (a) que contenga 4 líneas (b) dibujadas a 20 mm de los bordes de la hoja A3 y 1 línea (c) dibujada en el centro.
2. Conecte el enchufe eléctrico del MFP en el tomacorriente de la pared y encienda el interruptor principal.
3. Coloque el original (a) en el DP y haga una copia de prueba para verificar el funcionamiento y el ejemplo de copia.

[Funktionsprüfung]

1. Zum Prüfen der Gerätefunktion das Original (a) vorbereiten, auf das 4 Linien (b) 20 mm von den Kanten des A3-Blattes und 1 Linie (c) in der Mitte gezeichnet sind.
2. Den Netzstecker am MFP in die Steckdose stecken und den Strom einschalten.
3. Das Original (a) auf den DP legen und eine Testkopie erstellen, um die Funktion und das Kopierbeispiel zu prüfen.

[Verifica del funzionamento]

1. Per verificare il funzionamento della macchina, preparare l'originale (a) tirando 4 linee (b) a 20 mm dai bordi del foglio A3 e una linea (c) al centro.
2. Inserire la spina dell'alimentazione dell'MFP nella presa a muro, quindi posizionare l'interruttore principale su On.
3. Posizionare l'originale(a) sul DP ed eseguire una copia di prova per verificare il funzionamento e l'esempio di copia.

[動作確認]


1. 若要检查机器动作, 准备一张 A3 原稿 (a), 距纸张边缘 20mm 画出 4 条线 (b) 并且在原稿中心画出 1 条线 (c)。
2. 将 MFP 的电源插头插入墙壁插座并打开主电源。
3. 在 DP 上设定原稿 (a) 并进行测试复印, 确认机器动作和复印样本。

[동작확인]

1. A3 크기용지의 끝에서 20mm 의 위치에 선 (b) 4 개와 용지 중심에 선 (c) 1 개를 긋고 동작확인용 원고 (a) 를 준비합니다 .
2. MFP 본체의 전원 플러그를 콘센트에 꽂고 주 전원 스위치를 ON 으로 합니다 .
3. 원고 (a) 를 DP 본체에 장착하고 시험복사를 합니다 . 동작 및 복사샘플을 확인합니다 .

[動作確認]

1. A3 사이즈용紙の端から 20mm の位置に線 (b) 4 本と、用紙の中心に線 (c) 1 本を引いた、動作確認用の原稿 (a) を用意する。
2. MFP 本体の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。
3. 原稿 (a) を DP 本体にセットし、テストコピーを行い、動作およびコピーサンプルを確認する。



4. Compare original (a) with the copy example. If the gap exceeds the reference value, perform the following adjustments according to the type of the gap.

Check images of the DP after checking and adjusting images of the MFP. For details, see the service manual.

NOTICE: If there is any image fogging, adjust the U068 DP scanning position. If you change the scanning position with U068, adjust the U071 DP leading edge timing.

4. Comparer l'original (a) avec l'exemple de copie. Si l'écart excède la valeur de référence, effectuer les réglages suivants en fonction du type d'écart.

Vérifier les images du DP après avoir contrôlé et réglé les images du MFP. Pour plus de détails, se reporter au manuel d'entretien.

AVIS: Si l'image est floue, régler la position de balayage de U068 du DP. Si la position de balayage de U068 est modifiée, régler la synchronisation du bord d'attaque de U071.

4. Compare el original (a) con el ejemplo de copia. Si la separación supera el valor de referencia, realice los siguientes ajustes según el tipo de separación.

Compruebe las imágenes del DP después de comprobar y ajustar las imágenes del MFP. Para más detalles, lea el manual de servicio.

AVISO: Si la imagen estuviera borrosa, ajuste la posición de escaneo U068 del DP. Si cambia la posición de escaneo con U068, ajuste la sincronización de borde superior U071 del DP

4. Das Original (a) mit dem Kopierbeispiel vergleichen. Wenn der Abstand größer als der Bezugswert ist, die folgenden Einstellungen gemäß dem Abstandstyp durchführen.

Die Bilder des DP nach dem Prüfen und Einstellen der Bilder des MFP prüfen. Weitere Einzelheiten siehe Wartungsanleitung.

HINWEIS: Falls das Bild verschwommen wirkt, ist die U068 DP Scan-Position zu verstellen. Wenn Sie die Scan-Position mit U068 verstellen, müssen Sie das U071 DP-Vorderkanten-Timing entsprechend verstellen.

4. Confrontare l'originale (a) con l'esempio di copia. Se lo scostamento supera il valore di riferimento, eseguire le seguenti regolazioni in funzione del tipo di scostamento.

Controllare le immagini del DP dopo avere effettuato i controlli e le regolazioni delle immagini sull'MFP. Per ulteriori dettagli leggere il manuale d'istruzioni.

NOTIFICA: Se è presente una qualsiasi sfocatura dell'immagine, regolare la posizione di scansione DP U068. Se si cambia la posizione di scansione con U068, regolare la sincronizzazione del bordo principale DP U071.

4. 对比复印样本和原稿(a), 如果偏移值在标准值以上时, 对偏移原稿进行调整。

对 MFP 本体的图像确认和调整后再对 DP 的图像进行确认。详细内容请参见维修手册。

(注意) 如果图像出现底灰, 用 U068 来调整 DP 的扫描位置。如果用 U068 更改了扫描位置, 则再用 U071 对 DP 的前端定时进行调整

4. 원고 (a) 와 복사샘플을 비교해 기준치 이상의 차이가 있는 경우 차이에 대해 조정을 합니다 .

MFP 본체의 화상확인 및 조정을 하고나서 DP 본체의 화상확인을 할 것 . 상세는 서비스 매뉴얼을 참조할 것 .

(주의) 화상 카브리기가 발생하는 경우 , U068DP 스캔위치 조정을 합니다 . U068 에서 스캔위치를 변경한 경우 U071DP 선단 타이밍 조정을 합니다 .

4. 原稿 (a) とコピーサンプルを比較し、基準値以上のずれがある場合、ずれ方に応じて調整を行う。

MFP 本体の画像確認及び調整を行ってから DP 本体の画像確認を行うこと。詳細はサービスマニュアルを参照のこと。

(注意)画像カブリが発生する場合、U068 DP 読み取り位置の調整を行う。U068 で読み取り位置を変更した場合、U071 DP 先端タイミング調整を行う。

Be sure to adjust in the following order. If not, the adjustment cannot be performed correctly.

For checking the angle of leading edge, see page 20. <Reference value> Simplex copying: within ± 3.0 mm; Duplex copying: within ± 4.0 mm

For checking the angle of trailing edge, see page 23. <Reference value> Simplex copying: within ± 3.0 mm; Duplex copying: within ± 4.0 mm

When using the original for adjustment, automatic adjustment of magnification, leading edge timing and center line can be performed at a time.

For the automatic adjustment using the original for adjustment, see page 26.

Veillez à effectuer le réglage en procédant dans l'ordre suivant. Sinon, il sera impossible d'obtenir un réglage correct.

Pour vérifier l'angle du bord avant, reportez-vous à la page 20. <Valeur de référence> Copie recto seul: $\pm 3,0$ mm max.; copie recto verso: $\pm 4,0$ mm max.

Pour vérifier l'angle du bord arrière, reportez-vous à la page 23. <Valeur de référence> Copie recto seul: $\pm 3,0$ mm max.; copie recto verso: $\pm 4,0$ mm max.

Lorsque vous utilisez l'original pour effectuer le réglage, vous pouvez effectuer automatiquement le réglage de l'agrandissement, de la synchronisation du bord avant et de la ligne médiane en une seule fois.

Pour le réglage automatique en utilisant l'original pour effectuer le réglage, reportez-vous à la page 26.

Asegúrese de ajustar en el siguiente orden. De lo contrario, el ajuste no puede hacerse correctamente.

Para verificar el ángulo del borde superior, vea la página 20. <Valor de referencia> Copia simple: dentro de $\pm 3,0$ mm; Copia duplex: dentro de $\pm 4,0$ mm

Para verificar el ángulo del borde inferior, vea la página 23. <Valor de referencia> Copia simple: dentro de $\pm 3,0$ mm; Copia duplex: dentro de $\pm 4,0$ mm

Quando utilice el original para el ajuste, puede hacerse un ajuste automático del cambio de tamaño, sincronización del borde superior y línea central al mismo tiempo.

Para el ajuste automático utilizando el original para el ajuste, vea la página 26.

Die Einstellung in der folgenden Reihenfolge durchführen. Anderenfalls kann die Einstellung nicht korrekt durchgeführt werden.

Angaben zur Prüfung des Winkels der Vorderkante auf Seite 20. <Bezugswert> Simplexkopie: innerhalb $\pm 3,0$ mm; Duplexkopie: innerhalb $\pm 4,0$ mm

Angaben zur Prüfung des Winkels der Hinterkante auf Seite 23. <Bezugswert> Simplexkopie: innerhalb $\pm 3,0$ mm; Duplexkopie: innerhalb $\pm 4,0$ mm

Bei Verwendung des Originals für die Einstellung können die automatischen Einstellungen für Vergrößerung, Vorderkanten-Timing und Mittellinie gleichzeitig durchgeführt werden.

Angaben zur automatischen Einstellung mithilfe des Originals auf Seite 26.

Accertarsi di eseguire le regolazioni in questa sequenza: in caso contrario, la regolazione non può essere effettuata correttamente.

Per controllare l'angolo del bordo principale, vedere pagina 20. <Valore di riferimento> Copia simplex: entro $\pm 3,0$ mm; Copia duplex: entro $\pm 4,0$ mm

Per controllare l'angolo del bordo di uscita, vedere pagina 23. <Valore di riferimento> Copia simplex: entro $\pm 3,0$ mm; Copia duplex: entro $\pm 4,0$ mm

Quando si utilizza l'originale per la regolazione, la regolazione automatica dell'ingrandimento, della sincronizzazione del bordo principale e della linea centrale possono essere eseguiti contemporaneamente.

Per la regolazione automatica eseguita con l'originale, vedere pagina 26.

必须按照以下步骤进行调整, 否则不能达到准确调整的要求。

• 确认前端倾斜度 第 20 页 <标准值> 单面: ± 3.0 mm 以内, 双面: ± 4.0 mm 以内

• 确认后端倾斜度 第 23 页 <标准值> 单面: ± 3.0 mm 以内, 双面: ± 4.0 mm 以内

使用调整用的原稿时, 可以同时自动进行等倍值, 前端定时以及中心线的调整。

• 通过调整用原稿进行自动调整 第 26 页

반드시 하기의 순서로 조정을 할 것. 순서대로 조정을 하지 않는 경우 바른 조정을 할 수 없습니다.

• 선단경사확인 20 페이지 <기준치> 단면: ± 3.0 mm 이내, 양면: ± 4.0 mm 이내

• 후단경사확인 23 페이지 <기준치> 단면: ± 3.0 mm 이내, 양면: ± 4.0 mm 이내

조정용 원고를 사용하면 등배도 조정, 선단타이밍 조정, 센터 라인 조정의 자동조정이 한번에 수행됩니다.

• 조정용 원고에 의한 자동조정 26 페이지

必ず下記の順序で調整を行うこと。順序通りに調整を行わない場合、正しい調整ができない。

• 先端斜め確認 20 ページ <基準値> 片面: ± 3.0 mm 以内、両面: ± 4.0 mm 以内

• 後端斜め確認 23 ページ <基準値> 片面: ± 3.0 mm 以内、両面: ± 4.0 mm 以内

調整用原稿を使用すると、等倍度調整、先端タイミング調整、センターライン調整の自動調整が一度におこなえる。

• 調整用原稿による自動調整 26 ページ

For checking the magnification, see page 29. <Reference value> Within $\pm 1.5\%$
For checking the leading edge timing, see page 31. <Reference value> Within ± 2.5 mm
For checking the center line, see page 33. <Reference value> Simplex copying: within ± 2.0 mm; Duplex copying: within ± 3.0 mm

Pour vérifier l'agrandissement, reportez-vous à la page 29. <Valeur de référence> $\pm 1,5\%$ max.
Pour vérifier la synchronisation du bord avant, reportez-vous à la page 31. <Valeur de référence> $\pm 2,5$ mm max.
Pour vérifier la ligne médiane, reportez-vous à la page 33. <Valeur de référence> Copie recto seul: $\pm 2,0$ mm max.;
copie recto verso: $\pm 3,0$ mm max.

Para verificar el cambio de tamaño, vea la página 29. <Valor de referencia> Dentro de $\pm 1,5\%$
Para verificar la sincronización del borde inferior, vea la página 31. <Valor de referencia> Dentro de $\pm 2,5$ mm
Para verificar la línea central, vea la página 33. <Valor de referencia> Copia simple: dentro de $\pm 2,0$ mm;
Copia duplex: dentro de $\pm 3,0$ mm


Angaben zur Prüfung der Vergrößerung auf Seite 29. <Bezugswert> Innerhalb $\pm 1,5\%$
Angaben zur Prüfung des Vorderkanten-Timings auf Seite 31. <Bezugswert> Innerhalb $\pm 2,5$ mm
Angaben zur Prüfung der Mittellinie auf Seite 33. <Bezugswert> Simplexkopie: innerhalb $\pm 2,0$ mm; Duplexkopie: innerhalb $\pm 3,0$ mm

Per controllare l'ingrandimento, vedere pagina 29. <Valore di riferimento> Entro $\pm 1,5\%$
Per controllare la sincronizzazione del bordo principale, vedere pagina 31. <Valore di riferimento> Entro $\pm 2,5$ mm
Per controllare la linea centrale, vedere pagina 33. <Valore di riferimento> Copia simplex: entro $\pm 2,0$ mm;
Copia duplex: entro $\pm 3,0$ mm

• 确认等倍值 第 29 页 <标准值> $\pm 1.5\%$ 以内
• 确认前端定时调整 第 31 页 <标准值> ± 2.5 mm 以内
• 确认中心线 第 33 页 <标准值> 单面: ± 2.0 mm 以内, 双面: ± 3.0 mm 以内

• 등배도 확인 29 페이지 <기준치> $\pm 1.5\%$ 이내
• 선단 타이밍 확인 31 페이지 <기준치> ± 2.5 mm 이내
• 센터 라인 확인 33 페이지 <기준치> 단면: ± 2.0 mm 이내, 양면: ± 3.0 mm 이내

• 等倍度確認 29 ページ <基準値> $\pm 1.5\%$ 以内
• 先端タイミング確認 31 ページ <基準値> ± 2.5 mm 以内
• センターライン確認 33 ページ <基準値> 片面: ± 2.0 mm 以内、両面: ± 3.0 mm 以内



[Checking the angle of leading edge]

1. Check the horizontal gap between line (1) of original (a) and line (2) of copy example positions. If the gap exceeds the reference value, adjust the gap according to the following procedure.

<Reference value> For single copying: The horizontal gap of line (2) should be within ± 3.0 mm.

For duplex copying: The horizontal gap of line (2) should be within ± 4.0 mm.

[Vérification de l'angle du bord avant]

1. Vérifier l'écart horizontal entre la position de la ligne (1) de l'original (a) et celle de la ligne (2) de l'exemple de copie. Si l'écart excède la valeur de référence, le régler selon la procédure suivante.

<Valeur de référence> Pour la copie recto : l'écart horizontal de la ligne (2) doit être de ± 3.0 mm.

Pour la copie recto-verso : l'écart horizontal de la ligne (2) doit être de ± 4.0 mm.

[Verificación del ángulo del borde superior]

1. Compruebe la separación horizontal entre la línea (1) del original (a) y la línea (2) de las posiciones del ejemplo de copia. Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.

<Valor de referencia> Para el copiado por una cara: la separación horizontal de la línea (2) debe estar dentro de ± 3.0 mm.

Para el copiado dúplex: la separación horizontal de la línea (2) debe estar dentro de ± 4.0 mm.

[Überprüfen des Winkels der Vorderkante]

1. Den horizontalen Abstand zwischen der Linie (1) des Originals (a) und der Linie (2) der Kopierbeispielpositionen prüfen. Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.

<Bezugswert> Einzelkopie: Der horizontale Abstand der Linie (2) sollte innerhalb von ± 3.0 mm liegen.

Duplexkopie: Der horizontale Abstand der Linie (2) sollte innerhalb von ± 4.0 mm liegen.

[Controllo dell'angolo del bordo principale]

1. Verificare lo scostamento orizzontale fra la linea (1) dell'originale (a) e la linea (2) delle posizioni dell'esempio di copia. Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.

<Valore di riferimento> Per la copia singola: lo scostamento orizzontale della linea (2) deve limitarsi a ± 3.0 mm.

Per la copia duplex: lo scostamento orizzontale della linea (2) deve limitarsi a ± 4.0 mm.

[确认前端倾斜度]

1. 确认原稿 (a) 上的线 (1) 和复印样本上的线 (2) 的左右偏移值。如果偏移值超过标准值，则按照下列步骤进行调整

<标准值> 单面复印时，线 (2) 的左右偏移值： ± 3.0 mm 以内。

双面复印时，线 (2) 的左右偏移值： ± 4.0 mm 以内。

[선단 경사확인]

1. 원고 (a) 의 선 (1) 과 복사샘플의 선 (2) 의 좌우 차이를 확인합니다. 차이가 기준치 외의 경우 다음의 순서대로 조정을 합니다.

<기준치> 단면의 경우 선 (2) 의 좌우차이: ± 3.0 mm 이내




양면의 경우 선 (2) 의 좌우차이: ± 4.0 mm 이내

[先端斜め確認]

1. 原稿 (a) の線 (1) とコピーサンプルの線 (2) の左右のずれを確認する。ずれが基準値外の場合、次の手順で調整を行う。

<基準値> 片面の場合、線 (2) の左右ずれ: ± 3.0 mm 以内

両面の場合、線 (2) の左右ずれ: ± 4.0 mm 以内



2. DP-770: Remove the angle control fitting (D). Loosen the 2 M4 × 14TP screws (G) on the left and right fixing fittings (C).
DP-771: Remove the left hinge cover (H) and the angle control fitting (D). Loosen the 2 M4 × 14TP screws (G) on the left and right fixing fittings (C*) (C).
3. Turn adjusting screw (3) at the rear side of the right hinge to adjust the DP position.
For copy example (d): Turn the adjusting screw counterclockwise and move the DP to the inner side.
For copy example (e): Turn the adjusting screw clockwise and move the DP to the front side.
Amount of change per scale: Approx. 1.0 mm
4. Perform a test copy.

2. DP-770: Déposer la fixation d'angle (assurant le contrôle de l'ouverture) (D). Desserrer les 2 vis TP M4 × 14 (G) sur les fixations gauche et droite (C).
DP-771: Déposer le couvercle de la charnière gauche (H) et la fixation d'angle (assurant le contrôle de l'ouverture) (D). Desserrer les 2 vis TP M4 × 14 (G) sur les fixations gauche et droite (C*) (C).
3. Tourner la vis de réglage (3) à l'arrière de la charnière droite pour régler la position du DP.
Pour l'exemple de copie (d) : tourner la vis de réglage dans le sens inverse des aiguilles d'une montre et déplacer le DP vers l'intérieur.
Pour l'exemple de copie (e) : tourner la vis de réglage dans le sens des aiguilles d'une montre et déplacer le DP vers l'avant.
Changement par graduation d'échelle : environ 1.0 mm
4. Effectuer une copie de test.

2. DP-770: quite el herraje de control de ángulo (D). Afloje los 2 tornillos TP M4 × 14 (G) de los herrajes de fijación izquierdo y derecho (C).
DP-771: quite la cubierta de la bisagra izquierda (H) y el herraje de control de ángulo (D). Afloje los 2 tornillos TP M4 × 14 (G) de los herrajes de fijación izquierdo y derecho (C*) (C).
3. Gire el tornillo de ajuste (3) en el lado trasero de la bisagra derecha para ajustar la posición del DP.
Para el ejemplo de copia (d): gire el tornillo de ajuste en sentido antihorario y mueva el DP al lado interno.
Para el ejemplo de copia (e): gire el tornillo de ajuste en sentido horario y mueva el DP al lado frontal.
Magnitud del cambio por escala: aprox. 1.0 mm
4. Haga una copia de prueba.


2. DP-770: Die Winkeleinstellbefestigung (D) entfernen. Die 2 M4 × 14TP Schrauben (G) an den linken und rechten Befestigungshalterung (C) lösen.
DP-771: Die linke Scharnierabdeckung (H) und die Winkeleinstellbefestigung (D) entfernen. Die 2 M4 × 14TP Schrauben (G) an den linken und rechten Befestigungshalterungen (C*) (C) lösen.
3. Die Einstellschraube (3) an der Rückseite des rechten Scharniers einstellen, um die DP-Position einzustellen.
Kopierbeispiel (d): Die Einstellschraube nach links drehen und den DP nach innen schieben.
Kopierbeispiel (e): Die Einstellschraube nach rechts drehen und den DP nach vorne schieben.
Änderung pro Maßstab: Ungefähr 1.0 mm
4. Eine Testkopie erstellen.

2. DP-770: Rimuovere l'accessorio di regolazione angolare (D). Allentare le 2 viti M4 × 14TP (G) sugli accessori di fissaggio (C) destro e sinistro.
DP-771: Rimuovere il coperchio cerniera sinistra (H) e l'accessorio di regolazione angolare (D). Allentare le 2 viti M4 × 14TP (G) sui lati destro e sinistro degli accessori di fissaggio (C*) (C) destro e sinistro.
3. Ruotare la vite di regolazione (3) sul lato posteriore della cerniera destra per regolare la posizione del DP.
Per l'esempio di copia (d): ruotare la vite di regolazione in senso antiorario e spostare il DP verso l'interno.
Per l'esempio di copia (e): ruotare la vite di regolazione in senso orario e spostare il DP in avanti.
Entità modifica per scala: circa 1.0 mm
4. Eseguire una copia di prova.

2. DP-770 时: 拆下角度限制附件 (D)。拧松左右固定附件 (C) 的 2 颗 M4x14TP (G) 螺丝。
DP-771 时: 拆下左部铰链盖板 (H) 以及角度限制附件 (D)。拧松左右固定附件 (C*) (C) 的 2 颗 M4x14TP (G) 螺丝。
3. 旋转右部铰链的后部的调整螺钉 (3) 以调整 DP 位置。
对于复印样本 (d): 逆时针旋转调整螺钉并将 DP 移动到内侧。对于复印样本 (e): 顺时针旋转调整螺钉并将 DP 移动到正面。
按比例尺的更改量: 约 1.0mm
4. 进行测试复印。

2. DP-770 의 경우: 각도규제시 (D) 를 제거합니다. 좌우의 고정쇠 (C) 나사 M4x14TP (G) 2 개를 느슨하게 합니다.
DP-771 의 경우: 좌 힌지커버 (H) 및 각도규제시 (D) 를 제거합니다. 좌우의 고정쇠 (C*) (C) 의 나사 M4x14TP (G) 2 개를 느슨하게 합니다.
3. 우 힌지 뒷측 조정나사 (3) 를 돌려 DP 본체의 위치를 조정합니다.
복사샘플 (d) 의 경우: 조정나사를 좌로 돌려 DP 본체를 안으로 넣습니다. 복사샘플 (e) 의 경우: 조정나사를 오른쪽으로 돌려 DP 본체를 앞으로 뺍니다.
1 개 변화량: 약 1.0mm
4. 시험복사를 합니다.

2. DP-770 の場合: 角度規制金具 (D) を取り外す。左右の固定金具 (C) のビス M4x14TP (G) 2 本を緩める
DP-771 の場合: 左ヒンジカバー (H) および角度規制金具 (D) を取り外す。左右の固定金具 (C*) (C) のビス M4x14TP (G) 2 本を緩める。
3. 右ヒンジ後側の調整ビス (3) を回し、DP 本体の位置を調整する。
コピーサンプル (d) の場合: 調整ビスを左に回し、DP 本体を奥へ動かす。
コピーサンプル (e) の場合: 調整ビスを右に回し、DP 本体を手前へ動かす。
1 目盛り当たりの変化量: 約 1.0mm
4. テストコピーを行う。



5. Repeat the steps above until the gap of line (2) of copy example shows the following reference values.

<Reference value> For single copying: The horizontal gap of line (2) should be within ± 3.0 mm.

For duplex copying: The horizontal gap of line (2) should be within ± 4.0 mm.

6. After adjustment is completed, retighten two M4 \times 14TP screws (G) that have been loosened in step 2.

7. Remove the original mat (B) and refit it (see steps 24 and 25 on page 13).

5. Répéter les étapes ci-dessus jusqu'à ce que l'écart de la ligne (2) de l'exemple de copie indique les valeurs de référence suivantes.

<Valeur de référence> Pour la copie recto : l'écart horizontal de la ligne (2) doit être de ± 3.0 mm.

Pour la copie recto-verso : l'écart horizontal de la ligne (2) doit être de ± 4.0 mm.

6. Une fois le réglage effectué, resserrer les deux vis TP M4 \times 14 (G) desserrées à l'étape 2.

7. Retirez le tapis d'original (B) et remettez-le en place. (Reportez-vous aux étapes 24 et 25 à la page 13.)

5. Repita los pasos anteriores hasta que la separación de la línea (2) del ejemplo de copia presente los siguientes valores de referencia.

<Valor de referencia> Para el copiado por una cara: la separación horizontal de la línea (2) debe estar dentro de ± 3.0 mm.

Para el copiado dúplex: la separación horizontal de la línea (2) debe estar dentro de ± 4.0 mm.

6. Una vez hecho el ajuste, vuelva a apretar los dos tornillos TP M4 \times 14 (G) que ha aflojado en el paso 2.

7. Desmonte la plancha de original (B) y vuelva a colocar (vea los pasos 24 y 25 en la página 13).

5. Die obigen Schritte wiederholen, bis der Abstand der Linie (2) des Kopierbeispiels die folgenden Bezugswerte aufweist.

<Bezugswert> Einzelkopie: Der horizontale Abstand der Linie (2) sollte innerhalb von ± 3.0 mm liegen.

Duplexkopie: Der horizontale Abstand der Linie (2) sollte innerhalb von ± 4.0 mm liegen.

6. Nach der Einstellung die zwei M4 \times 14TP Schrauben (G), die in Schritt 2 gelöst wurden, wieder festziehen.

7. Die Originalmatte (B) abnehmen und wieder anbringen (siehe Schritte 24 und 25 auf Seite 13).

5. Ripetere le operazioni sopra descritte fino a quando lo scostamento della linea (2) dell'esempio di copia riporterà i valori di riferimento seguenti.

<Valore di riferimento> Per la copia singola: lo scostamento orizzontale della linea (2) deve limitarsi a ± 3.0 mm.

Per la copia duplex: lo scostamento orizzontale della linea (2) deve limitarsi a ± 4.0 mm.

6. Una volta conclusa la regolazione, serrare nuovamente le viti M4 \times 14TP (G) che erano state allentate al Punto 2.

7. Rimuovere il coprioriginale (B) e reinserirlo (vedere i passi 24 e 25 a pagina 13).

5. 重复上述步骤直至复印样本上的线(2)的偏移值达到标准值范围内。

<标准值> 单面时, 线(2)的左右偏移值: ± 3.0 mm 以内

双面时, 线(2)的左右偏移值: ± 4.0 mm 以内

6. 调整完成后, 重新拧紧在步骤2中松开两颗M4 \times 14TP螺钉(G)。

7. 拆下原稿垫(B), 参照第13页的步骤24和25再次装上。

5. 복사샘플 선 (2) 차이가 기준치내가 될 때까지 조정을 반복합니다 .

<기준치> 단면의 경우 선 (2) 의 좌우차이: ± 3.0 mm 이내

양면의 경우 선 (2) 의 좌우차이: ± 4.0 mm 이내

6. 조정종료 후 순서 2 에서 느슨하게 한 나사 M4 \times 14TP(G) 2 개를 조입니다 .

7. 원고매트 (B) 를 제거하고 13 페이지 순서 24, 25 을 참고로 다시 부착합니다 .


5. コピーサンプルの線 (2) のずれが基準値内になるまで、調整を繰り返す。

<基準値> 片面の場合、線 (2) の左右ずれ: ± 3.0 mm 以内

両面の場合、線 (2) の左右ずれ: ± 4.0 mm 以内

6. 調整終了後、手順2で緩めたビス M4 \times 14TP(G)2本を締め付ける。

7. 原稿マット (B) を取り外し、13 ページの手順24、25 を参考に再度取り付ける。



[Checking the angle of trailing edge]

1. Check the gap between line (1) of original (a) and line (2) of copy example. If the gap exceeds the reference value, perform the following adjustment.
 <Reference value> For simplex copying: Within ± 3.0 mm
 For duplex copying: Within ± 4.0 mm

[Vérification de l'angle du bord arrière]

1. Vérifiez l'écart entre la ligne (1) de l'original (a) et la ligne (2) de l'exemple de copie. Si l'écart est supérieur à la valeur de référence, effectuez le réglage suivant.
 <Valeur de référence> Copie recto seul: $\pm 3,0$ mm max.
 Copie recto verso: $\pm 4,0$ mm max.

[Verificación del ángulo del borde inferior]

1. Verifique la separación entre la línea (1) del original (a) y la línea (2) de la copia de muestra. Si la superación supera el valor de referencia, haga el siguiente ajuste.
 <Valor de referencia> Para copia simple: Dentro de $\pm 3,0$ mm
 Para copia duplex: Dentro de $\pm 4,0$ mm

[Überprüfen des Winkels der Hinterkante]

1. Die Abweichung der Linie (1) des Originals (a) und der Linie (2) des Kopienmusters prüfen. Überschreitet die Abweichung den Bezugswert, ist die folgende Einstellung durchzuführen.
 <Bezugswert> Für Simplexkopie: Innerhalb $\pm 3,0$ mm
 Für Duplexkopie: Innerhalb $\pm 4,0$ mm

[Controllo dell'angolo del bordo di uscita]

1. Controllare la differenza tra la linea (1) dell'originale (a) e la linea (2) della copia di esempio. Se la differenza supera il valore di riferimento, effettuare la seguente regolazione.
 <Valore di riferimento> Per copia simplex: Entro $\pm 3,0$ mm
 Per copia duplex: Entro $\pm 4,0$ mm

[确认后端倾斜度]


1. 确认原稿 (a) 上的线 (1) 和复印样本上的线 (2) 的偏移值。如果超过标准值时，必须进行调整。
 <标准值> 单面时: ± 3.0 mm 以内
 双面时: ± 4.0 mm 以内

[후단 경사확인]


1. 원고 (a) 의 선 (1) 과 복사샘플 선 (2) 의 차이를 확인합니다 . 차이가 기준치 외의 경우에는 조정을 합니다 .
 <기준치> 단면의 경우: ± 3.0 m 이내
 양면의 경우: ± 4.0 mm 이내

[後端斜め確認]

1. 原稿 (a) の線 (1) とコピーサンプルの線 (2) のずれを確認する。ずれが基準値外の場合は調整をおこなう。
 <基準値> 片面の場合: ± 3.0 mm 以内
 両面の場合: ± 4.0 mm 以内



2. Open the upper cover (3) of the DP (A).
3. Remove the 3 TP screws (4) and the screw (5), and remove the strap (6) from the rear cover (7). Then remove the DP (A) rear cover (7).



4. Adjust the height of DP.
Loosen the nut (8).
For copy example (f): Loosen the adjusting screw (9).
For copy example (g): Tighten the adjusting screw (9).

- Amount of change per scale: Approx. 0.5 mm (10)
Retighten the nut (8).
5. Refit the rear cover (7) removed in step 3.
 6. Remove the original mat (B) and refit it (see steps 24 and 25 on page 13).

2. Ouvrir le couvercle supérieur (3) du DP (A)
3. Déposer les 3 vis TP (4) et la vis (5) puis déposer la courroie (6) du couvercle arrière (7). Déposer ensuite le couvercle arrière (7) du DP (A).

4. Réglez la hauteur du DP.
Desserrez l'écrou (8).
Pour l'exemple de copie (f): Desserrez la vis de réglage (9).
Pour l'exemple de copie (g): Serrez la vis de réglage (9).

- Quantité de changement par pas: environ 0,5 mm (10)
Resserrez l'écrou (8).
5. Reposer le capot arrière (7) déposé à l'étape 3.
 6. Retirez le tapis d'original (B) et remettez-le en place. (Reportez-vous aux étapes 24 et 25 à la page 13.)

2. Abra la cubierta superior (3) del DP (A).
3. Quite los 3 tornillos TP (4) y el tornillo (5) y quite la correa (6) de la cubierta trasera (7). Después, quite la cubierta trasera (7) del DP (A).

4. Ajuste la altura del DP.
Afloje la tuerca (8).
Para la copia de muestra (f): Afloje el tornillo de ajuste (9).
Para la copia de muestra (g): Apriete el tornillo de ajuste (9).

- Cantidad de cambio de escala: Aprox. 0,5 mm (10)
Vuelva a apretar la tuerca (8).
5. Vuelva a colocar la cubierta (7) desmontada en el paso 3.
 6. Desmonte la plancha de original (B) y vuelva a colocar (vea los pasos 24 y 25 en la página 13).

2. Die obere Abdeckung (3) des DP (A) öffnen.
3. Die 3 TP-Schrauben (4) und die Schraube (5) entfernen und den Riemen (6) von der hinteren Abdeckung (7) abnehmen. Dann die hintere Abdeckung (7) des DP (A) abnehmen.

4. Die Höhe des DP einstellen.
Lösen Sie die Mutter (8).
Für Kopienmuster (f): Lösen Sie die Einstellschraube (9).
Für Kopienmuster (g): Die Einstellschraube (9) festziehen.

- Änderungsbetrag pro Skalenstrich: ca. 0,5 mm (10)
Ziehen Sie die Mutter (8) wieder fest.
5. Die in Schritt 3 entfernte hintere Abdeckung (7) wieder anbringen.
 6. Die Originalmatte (B) abnehmen und wieder anbringen (siehe Schritte 24 und 25 auf Seite 13).

2. Aprire il pannello superiore (3) del DP (A).
3. Rimuovere le 3 viti TP (4) e la vite (5), e quindi rimuovere la cinghietta (6) dal coperchio posteriore (7). Quindi rimuovere il coperchio posteriore (7) del DP (A).

4. Regolazione dell'altezza del DP
Allentare il dado (8).
Per un esempio di copia (f): Allentare la vite di regolazione (9).
Per un esempio di copia (g): Stringere la vite di regolazione (9).

- Variatione graduale: circa 0,5 mm (10)
Stringere di nuovo il dado (8).
5. Reinserire il coperchio posteriore (7) rimosso nel passo 3.
 6. Rimuovere il coprioriginale (B) e reinserirlo (vedere i passi 24 e 25 a pagina 13).

2. 打开 DP (A) 的上盖板 (3)。
3. 拆除 3 颗 TP 螺丝 (4) 和 1 颗螺丝 (5)，将带子 (6) 从后盖板 (7) 上拆除，拆下 DP 主机 (A) 的后盖板 (7)。

4. 调整 DP 的高度。
松弛螺母 (8)。
测印件 (f) 时: 松弛调整螺丝 (9)。
测印件 (g) 时: 紧固调整螺丝 (9)。

- 每 1 格的移动量: 约 0.5mm (10)
将螺母 (8) 按原样紧固好。
5. 重新安装在步骤 3 中拆下的后盖板 (7)。
 6. 拆下原稿垫 (B)，参照第 13 页的步骤 24 和 25 再次装上。

2. DP 본체 (A) 의 DP 윗 커버 (3) 를 엽니다 .
3. TP 나사 (4) 3 개와 나사 (5) 1 개를 제거하고 스트랩 (6) 을 뒷면 커버 (7) 에서 제거해 DP 본체 (A) 의 후면 커버 (7) 를 제거합니다 .


4. DP 의 높이를 조정합니다 .
너트 (8) 를 느슨하게 합니다 .
복사샘플 (f) 의 경우 : 조정나사 (9) 를 느슨하게 합니다 .
복사샘플 (g) 의 경우 : 조정나사 (9) 를 조입니다 .

- 1 개 변화량 : 약 0.5mm (10)
너트 (8) 를 원래대로 조입니다 .
5. 순서 3 에서 제거한 윗 커버 (7) 를 원래대로 장착합니다 .
 6. 원고너트 (B) 를 제거하고 13 페이지 순서 24, 25 을 참고로 다시 부착합니다 .

2. DP 本体 (A) の DP 上カバー (3) を開く。
3. TP ビス (4) 3 本とビス (5) 1 本を外し、ストラップ (6) を後カバー (7) から外して、DP 本体 (A) の後カバー (7) を取り外す。

4. DP の高さを調整する。
ナット (8) をゆるめる。
コピーサンプル (f) の場合 : 調整ビス (9) をゆるめる。
コピーサンプル (g) の場合 : 調整ビス (9) を締める。

- 1 目盛り当たりの変化量 : 約 0.5mm (10)
ナット (8) を元通り締める。
5. 手順 3 で取り外した後カバー (7) を元通り取り付ける。
 6. 原稿マット (B) を取り外し、13 ページの手順 24, 25 を参考に再度取り付ける。



7. Make a proof copy again.
 8. Repeat steps 1 to 6 until line (2) of copy example shows the following the reference values.
 <Reference value> For simplex copying: Within ± 3.0 mm
 For duplex copying: Within ± 4.0 mm

7. Effectuez à nouveau une copie de test.
 8. Répétez les étapes 1 à 6 jusqu'à ce que la ligne (2) de l'exemple de copie corresponde aux valeurs de référence suivantes.
 <Valeur de référence> Copie recto seul: $\pm 3,0$ mm max.
 Copie recto verso: $\pm 4,0$ mm max.

7. Haga otra copia de prueba.
 8. Repita los pasos 1 a 6 hasta que la línea (2) de la copia de muestra tenga los siguientes valores de referencia.
 <Valor de referencia> Para copia simple: Dentro de $\pm 3,0$ mm
 Para copia duplex: Dentro de $\pm 4,0$ mm


7. Eine erneute Probekopie anfertigen.
 8. Die Schritte 1 bis 6 wiederholen, bis die Linie (2) des Kopienmusters die folgenden Bezugswerte aufweist.
 <Bezugswert> Für Simplexkopie: Innerhalb $\pm 3,0$ mm
 Für Duplexkopie: Innerhalb $\pm 4,0$ mm

7. Eseguire di nuovo una prova di copia.
 8. Ripetere i passi da 1 a 6 fino a che la linea (2) dell'esempio di copia non mostra i seguenti valori di riferimento.
 <Valore di riferimento> Per copia simplex: Entro $\pm 3,0$ mm
 Per copia duplex: Entro $\pm 4,0$ mm

7. 再次进行测试复印。
 8. 反复操作步骤 1~6, 直至测印件的线 (2) 为标准值内。
 <标准值> 单面时: ± 3.0 mm 以内
 双面时: ± 4.0 mm 以内

7. 다시 시험복사를 합니다 .
 8. 복사샘플 선 (2) 이 기준치내로 될 때까지 순서 1 ~ 6 을 반복합니다 .
 <기준치> 단면의 경우: ± 3.0 mm 이내
 양면의 경우: ± 4.0 mm 이내

7. 再度テストコピーをおこなう。
 8. コピーサンプルの線 (2) が基準値内になるまで、手順 1 ~ 6 を繰り返す。
 <基準値> 片面の場合: ± 3.0 mm 以内
 両面の場合: ± 4.0 mm 以内



**[Automatic adjustment using the original for adjustment]
If there is no DP auto adjustment original**

1. Set the maintenance mode U411, select DP Auto Adj and press the Start key to print an original.
2. Set the printed original on the contact glass and press the Start key.
3. Set the original on the DP face up and press the Start key to carry out surface adjustment.

4. Set the original on the DP face down and press the Start key to carry out rear-side adjustment.
5. If OK appears on the display, the adjustment is completed. If ERROR XX appears, the adjustment failed. Check the original set position and repeat steps 2 and 4 until OK appears. For details, see the service manual.

**[Réglage automatique en utilisant l'original pour effectuer le réglage]
Si la machine n'est pas pourvue de la fonction réglage automatique d'original du DP**

1. Régler le mode maintenance U411, sélectionner DP Auto Adj et appuyer sur la touche Start pour imprimer un original.
2. Placer l'original qui vient d'être imprimé sur la vitre d'exposition et appuyer sur la touche Start.
3. Placer l'original sur le DP côté imprimé en haut et appuyer sur la touche Start pour procéder au réglage de la surface.

4. Placer l'original sur le DP côté imprimé en bas et appuyer sur la touche Start pour procéder au réglage du côté arrière.
5. Si le message OK apparaît sur l'affichage, le réglage est terminé. Si le message ERROR XX (erreur XX) s'affiche, le réglage a échoué. Vérifier la position de l'original et recommencer les opérations 2 et 4 jusqu'à ce que le message OK apparaisse. Pour plus de détails, se reporter au manuel d'entretien.

**[Ajuste automático utilizando el original para el ajuste]
Si no existe el original de ajuste automático del DP**

1. Entre al modo de mantenimiento U411, seleccione DP Auto Adj y pulse la tecla de Start para imprimir un original.
2. Coloque el original impreso sobre el cristal de contacto y pulse la tecla de Start.
3. Coloque el original en el DP cara arriba y pulse la tecla de Start para realizar un ajuste de anverso.

4. Coloque el original en el DP cara abajo y pulse la tecla de Start para realizar un ajuste de reverso.
5. Wenn am Display OK angezeigt wird, ist die Einstellung abgeschlossen. Wenn ERROR XX (FEHLER XX) angezeigt wird, ist die Einstellung fehlgeschlagen. Überprüfen Sie die Originalpositionierung und wiederholen Sie Schritte 2 und 4, bis OK angezeigt wird. Weitere Einzelheiten siehe Wartungsanleitung.

**[Automatische Einstellung mithilfe des Originals]
Falls keine automatische Einstellung des Originals des DP vorhanden ist**

1. Den Wartungsmodus U411 einschalten. DP Auto Adj wählen und die Start-Taste betätigen, um ein Original auszudrucken.
2. Das ausgedruckte Original auf das Kontaktglas legen und die Start-Taste betätigen.
3. Das Original mit der Druckseite nach oben einlegen und die Start-Taste betätigen, um die Oberflächeneinstellung ausführen zu lassen

4. Das Original mit der Druckseite nach unten einlegen und die Start-Taste betätigen, um die Rückseiteneinstellung ausführen zu lassen.
5. Wenn am Display OK angezeigt wird, ist die Einstellung abgeschlossen. Wenn ERROR XX (FEHLER XX) angezeigt wird, ist die Einstellung fehlgeschlagen. Überprüfen Sie die Originalpositionierung und wiederholen Sie Schritte 2 und 4, bis OK angezeigt wird. Weitere Einzelheiten siehe Wartungsanleitung.

**[Regolazione automatica eseguita con l'originale]
Se non è presente l'autoregolazione originale DP**

1. Impostare la modalità manutenzione U411, selezionare DP Auto Adj e premere il tasto di Start per stampare un originale.
2. Posizionare l'originale stampato sul vetro di appoggio e premere il tasto di Start.
3. Posizionare l'originale sul DP rivolto verso l'alto e premere il tasto di Start per eseguire la regolazione della superficie.

4. Posizionare l'originale sul DP rivolto verso il basso e premere il tasto di Start per eseguire la regolazione del lato posteriore.
5. Se OK appare sul display, la regolazione è completata. Se compare ERROR XX (ERRORE XX), la regolazione non è riuscita. Verificare la posizione di impostazione dell'originale e ripetere le operazioni 2 e 4 fino a quando appare OK. Per ulteriori dettagli leggere il manuale d'istruzioni.

[通过调整用原稿进行自动调整]

没有 DP 调整用原稿时

1. 设置维护模式 U411, 按 DP Auto Adj、Start 键以输出原稿。
2. 将输出的原稿放在稿台上, 按 Start 键。
3. 将原稿面朝上放在 DP 主机上, 按 Start 键以进行正面的调整。

4. 将原稿面朝下放在 DP 主机上, 按 Start 键以进行反面的调整。
5. 如果屏幕上出现 OK (完成), 则表示调整完成。如果出现 ERROR XX (错误 XX), 则表示调整失败。检查原稿设定位置并重复步骤 2 和 4, 直到 OK (完成) 出现。详细内容请参照维修手册。

[조정용 원고에 올라 자동조정]

DP 조정용 원고가 없는 경우

1. 메인テナンス 모드 U411 을 세트하고 DP Auto Adj, 시작키를 눌러 원고를 출력합니다.
2. 출력한 원고를 원고 유리에 장착하고 시작키를 누릅니다.
3. 원고를 FaceUp 으로 DP 본체로 세트하고 시작키를 눌러 표면조정을 합니다.


4. 원고를 FaceDown 으로 DP 본체에 장착하고 시작키를 눌러 뒷면조정을 합니다.
5. 디스플레이에 OK 가 표시되면 조정완료가 됩니다. ERROR XX 가 표시된 경우에는 조정실패입니다. 원고 장착위치를 확인하고 OK 가 표시될 때까지 순서 2 ~ 4 를 반복합니다. 상세는 서비스 매뉴얼을 참조

[調整用原稿による自動調整]

DP 調整用原稿が無い場合

1. メンテナンスモード U411 をセットし、DP Auto Adj、Start キーを押し原稿を出力する。
2. 出力した原稿をコンタクトガラス上にセットし、Start キーを押す。
3. 原稿を FaceUp で DP 本体へセットし、Start キーを押し、表面の調整を行う。

4. 原稿を FaceDown で DP 本体へセットし、Start キーを押し、裏面の調整を行う。
5. ディスプレイに OK が表示されれば調整完了となる。ERROR XX が表示された場合は調整失敗である。原稿のセット位置を確認し、OK が表示されるまで手順 2 ~ 4 を繰り返す。詳細はサービスマニュアルを参照のこと。



Using a DP auto adjustment original

1. Direct F and R of the DP auto adjustment original upward, and set the original from the place where F and R are marked
2. Set the maintenance mode U411. Press the DP FaceUp (Chart2), Input and the Start key in that order to carry out surface adjustment.

3. If OK appears on the display, the adjustment is completed. If ERROR XX appears, the adjustment failed. Check the original set position and repeat steps 1 and 2 until OK appears. For details, see the service manual.

Avec la fonction réglage automatique d'original du DP

1. Diriger F (avant) et R (arrière) de la fonction de réglage automatique d'original du DP vers le haut, puis placer l'original à partir de l'emplacement des repères F et R.
2. Passer au mode maintenance U411. Appuyer sur les touches DP FaceUp (Chart2), Input et Start dans cet ordre pour procéder au réglage de la surface.

3. Si le message OK apparaît sur l'affichage, le réglage est terminé. Si le message ERROR XX (erreur XX) s'affiche, le réglage a échoué. Vérifier la position de l'original et recommencer les opérations 1 et 2 jusqu'à ce que le message OK apparaisse. Pour plus de détails, se reporter au manuel d'entretien.

Uso del original de ajuste automático del DP

1. Dirija F y R del original de ajuste automático del DP hacia arriba, y coloque el original a partir del sitio en que están marcados F y R.
2. Entre en el modo de mantenimiento U411. Pulse las teclas DP FaceUp (Chart2), Input y la tecla de Start, en ese orden, para realizar el ajuste de anverso.

3. Si aparece OK en la pantalla significa que el ajuste ha sido realizado. Si aparece ERROR XX, el ajuste ha fallado. Compruebe la posición ajustada del original y repita los pasos 1 y 2 hasta que aparezca OK en la pantalla. Para más detalles, lea el manual de servicio.

Gebrauch der automatischen Einstellung des Originals des DP

1. F und R der automatischen Einstellung des Originals des DP nach oben zeigen und das Original an die mit F und R markierte Stelle setzen.
2. Den Wartungsmodus U411 einschalten. DP Faceup (Chart2), Input und die Start-Taste in dieser Reihenfolge betätigen, um die Oberflächeneinstellung ausführen zu lassen.

3. Wenn am Display OK angezeigt wird, ist die Einstellung abgeschlossen. Wenn ERROR XX (FEHLER XX) angezeigt wird, ist die Einstellung fehlgeschlagen. Überprüfen Sie die Originalpositionierung und wiederholen Sie Schritte 1 und 2, bis OK angezeigt wird. Weitere Einzelheiten siehe Wartungsanleitung.

Uso di un'autoregolazione originale DP

1. Orientare F e R dell'autoregolazione originale DP verso l'alto e disporre l'originale rispetto ai punti in cui sono contrassegnati F e R.
2. Impostare la modalità manutenzione U411. Premere nell'ordine DP FaceUp (Chart2), Input e il tasto di Start, per eseguire la regolazione della superficie.

3. Se OK appare sul display, la regolazione è completata. Se compare ERROR XX (ERRORE XX), la regolazione non è riuscita. Verificare la posizione di impostazione dell'originale e ripetere le operazioni 1 e 2 fino a quando appare OK. Per ulteriori dettagli leggere il manuale d'istruzioni.

使用 DP 自动调整原稿时

1. 将 DP 自动调整原稿的 F 和 R 向上, 并把标有 F 和 R 的一侧插入 DP 来设定原稿。
2. 设置维护模式 U411, 按顺序按 DP FaceUp (Chart2)、Input、Start 键以进行正面的调整。

3. 如果屏幕上出现 OK (完成), 则表示调整完成。如果出现 ERROR XX (错误 XX), 则表示调整失败。检查原稿设定位置并重复步骤 1 和 2, 直到 OK (完成) 出现。详细内容请参照维修手册。

DP 자동조정용 원고를 사용하는 경우


1. DP 자동조정원고 F, R 을 위로 향하게 하고 F, R 이 쓰여져 있는 쪽에서 DP 본체로 세트합니다.
2. 메인テナンス 모드 U411 을 세트하고 DP FaceUp (Chart2), Input, 시작 키의 순서로 눌러 표면 조정을 합니다.

3. 디스플레이에 OK 가 표시되면 조정완료가 됩니다. ERROR XX 가 표시된 경우에는 조정실패입니다. 원고 장착 위치를 확인하고 OK 가 표시될 때까지 순서 1 ~ 2 를 반복합니다. 상세는 서비스 매뉴얼을 참조

DP 自動調整原稿を使用する場合

1. DP 自動調整原稿の F、R を上に向け、F、R が書かれている方から DP 本体へセットする。
2. メンテナンスモード U411 をセットし、DP FaceUp (Chart2)、Input、Start キーの順に押し、表面の調整を行う。

3. ディスプレイに OK が表示されれば調整完了となる。ERROR XX が表示された場合は調整失敗である。原稿のセット位置を確認し、OK が表示されるまで手順 1 ~ 2 を繰り返す。詳細はサービスマニュアルを参照のこと。



4. After completing the surface adjustment, direct F and R of the DP auto adjustment original downward and set the original by inserting the side where the F and R are marked into the DP first.
5. Set the maintenance mode U411. Press the DP FaceDown (Chart2), Normal Target, Input and the Start key in that order to carry out rear-side adjustment.

6. If OK appears on the display, the adjustment is completed. If ERROR XX appears, the adjustment failed. Check the original set position and repeat steps 4 and 5 until OK appears. For details, see the service manual.

4. Une fois le réglage de la surface effectué, diriger F (avant) et R (arrière) de la fonction de réglage automatique d'original du DP vers le bas et placer l'original en introduisant en premier dans le DP le côté sur lequel F et R sont indiqués.
5. Passer au mode maintenance U411. Appuyer sur les touches DP FaceDown (Chart2), Normal Target, Input et Start dans cet ordre pour procéder au réglage du côté arrière.

6. Si le message OK apparaît sur l'affichage, le réglage est terminé. Si le message ERROR XX (erreur XX) s'affiche, le réglage a échoué. Vérifier la position de l'original et recommencer les opérations 4 et 5 jusqu'à ce que le message OK apparaisse. Pour plus de détails, se reporter au manuel d'entretien.

4. Una vez hecho el ajuste del anverso, dirija F y R del original de ajuste automático del DP hacia abajo y coloque el original insertando en el DP, en primer lugar, el lado en el que están marcados F y R.
5. Entre en el modo de mantenimiento U411. Pulse las teclas DP FaceDown (Chart2), Normal Target, Input y la tecla de Start, en ese orden, para realizar el ajuste de reverso.

6. Si aparece OK en la pantalla significa que el ajuste ha sido realizado. Si aparece ERROR XX, el ajuste ha fallado. Compruebe la posición ajustada del original y repita los pasos 4 y 5 hasta que aparezca OK en la pantalla. Para más detalles, lea el manual de servicio.

4. Nach dem Abschluss der Oberflächeneinstellung F und R der automatischen Einstellung des Originals des DP nach unten zeigen und das Original einstellen, indem die mit F und R markierte Seite zuerst in den DP eingeführt wird.
5. Den Wartungsmodus U411 einschalten. DP FaceDown (Chart2), Normal Target, Input und die Start-Taste in dieser Reihenfolge betätigen, um die Rückseiteneinstellung ausführen zu lassen.

6. Wenn am Display OK angezeigt wird, ist die Einstellung abgeschlossen. Wenn ERROR XX (FEHLER XX) angezeigt wird, ist die Einstellung fehlgeschlagen. Überprüfen Sie die Originalpositionierung und wiederholen Sie Schritte 4 und 5, bis OK angezeigt wird. Weitere Einzelheiten siehe Wartungsanleitung.

4. Una volta conclusa la regolazione della superficie, orientare F e R dell'autoregolazione originale DP verso il basso e disporre l'originale inserendo nel DP prima il lato su cui sono contrassegnati F e R.
5. Impostare la modalità manutenzione U411. Premere nell'ordine DP FaceDown (Chart2), Normal Target, Input e il tasto di Start, per eseguire la regolazione del lato posteriore.

6. Se OK appare sul display, la regolazione è completata. Se compare ERROR XX (ERRORE XX), la regolazione non è riuscita. Verificare la posizione di impostazione dell'originale e ripetere le operazioni 4 e 5 fino a quando appare OK. Per ulteriori dettagli leggere il manuale d'istruzioni.

4. 完成正面调整后, 将 DP 自动调整原稿的 F 和 R 向下, 并首先将标有 F 和 R 的一侧插入 DP 来设定原稿。
5. 设置维护模式 U411, 按顺序按 DP FaceDown (Chart2)、Normal Target、Input、Start 键以进行反面的调整。


6. 如果屏幕上出现 OK (完成), 则表示调整完成。如果出现 ERROR XX (错误 XX), 则表示调整失败。检查原稿设定位置并重复步骤 4 和 5, 直到 OK (完成) 出现。详细内容请参照维修手册。

4. 표면의 조정완료 후 DP 자동조정원고의 F, R 을 아래로 향하게 해 F, R 이 쓰여져 있는 쪽에서 DP 본체로 세트합니다 .
5. 메인テナンス 모드 U411 을 세트하고 DP FaceDown (Chart2), Normal Target, Input, 시작키 순서로 뒷면조정을 합니다 .

6. 디스플레이에 OK 가 표시되면 조정완료가 됩니다 . ERROR XX 가 표시된 경우에는 조정실패입니다 . 원고 장착위치를 확인하고 OK 가 표시될 때까지 순서 4 ~ 5 를 반복합니다 . 상세는 서비스 매뉴얼을 참조

4. 表面の調整完了後、DP 自動調整原稿の F、R を下に向け、F、R が書かれている方から DP 本体へセットする。
5. メンテナンスモード U411 をセットし、DP FaceDown (Chart2)、Normal Target、Input、Start キーの順に押し、裏面の調整を行う。

6. ディスプレイに OK が表示されれば調整完了となる。ERROR XX が表示された場合は調整失敗である。原稿のセット位置を確認し、OK が表示されるまで手順 4 ~ 5 を繰り返す。詳細はサービスマニュアルを参照のこと。



[Checking the magnification]

1. Check the gap between line (1) of original (a) and line (2) (3) of copy example. If the gap exceeds the reference value, adjust the gap according to the following procedure.
<Reference value>
For the sub-scan direction, vertical gap of line (2): within ±1.5%
For the main-scan direction, horizontal gap of line (3): within ±1.5%

2. Use the maintenance mode U070 to adjust the magnification.
Main Scan: Adjusts the scanner main-scan magnification
Sub Scan: Adjusts the scanner sub-scan magnification
Sub Scan (CIS): Adjusts the scanner CIS sub-scan magnification (DP-771)

[Vérification de l'agrandissement]

1. Vérifier l'écart entre la ligne (1) de l'original (a) et la ligne (2) (3) de l'exemple de copie. Si l'écart excède la valeur de référence, le régler selon la procédure suivante.
<Valeur de référence>
Pour la direction du balayage secondaire, l'écart vertical de la ligne (2) est de ±1,5%
Pour la direction du balayage principal, l'écart horizontal de la ligne (3) est de ±1,5%

2. Pour régler l'agrandissement, utilisez le mode entretien U070.
Main Scan: Permet de régler l'agrandissement du balayage principal du scanner
Sub Scan: Permet de régler l'agrandissement du balayage secondaire du scanner
Sub Scan (CIS): Permet de régler l'agrandissement du balayage secondaire du CIS du scanner (DP-771)

[Verificación del cambio de tamaño]

1. Compruebe la separación entre la línea (1) del original (a) y la línea (2) (3) del ejemplo de copia. Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.
<Valor de referencia>
Para la dirección de exploración secundaria, separación vertical de la línea (2): dentro de ±1,5%
Para la dirección de exploración principal, separación horizontal de la línea (3): dentro de ±1,5%

2. Para ajustar la ampliación utilice el modo de mantenimiento U070.
Main Scan: ajusta el cambio de tamaño de la dirección de exploración principal del escáner.
Sub Scan: ajusta el cambio de tamaño de la dirección de exploración secundaria del escáner.
Sub Scan (CIS): ajusta el cambio de tamaño de la dirección de exploración secundaria CIS del escáner (DP-771).

[Überprüfen der Vergrößerung]

1. Den Abstand zwischen der Linie (1) des Originals (a) und der Linie (2) (3) des Kopierbeispiels prüfen. Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.
<Bezugswert>
Subscanrichtung: Vertikaler Abstand der Linie (2): Innerhalb ±1,5%
Hauptscanrichtung: Horizontaler Abstand der Linie (3): Innerhalb ±1,5%

2. Zum Einstellen der Vergrößerung den Wartungsmodus U070 verwenden.
Main Scan: Zur Einstellung der Hauptscan-Vergrößerung
Sub Scan: Zur Einstellung der Subscan-Vergrößerung
Sub Scan (CIS): Zur Einstellung der Scanner-CIS-Subscan-Vergrößerung (DP-771)

[Controllo dell'ingrandimento]

1. Verificare lo scostamento fra la linea (1) dell'originale (a) e la linea (2) (3) dell'esempio di copia. Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.
<Valore di riferimento>
Per l'orientamento della scansione ausiliare, lo scostamento verticale della linea (2) deve essere compreso fra ±1,5%
Per l'orientamento della scansione principale, lo scostamento orizzontale della linea (3) deve essere compreso fra ±1,5%

2. Usare la modalità di manutenzione U070 per regolare l'ingrandimento.
Main Scan: Regola l'ingrandimento della scansione principale dello scanner
Sub Scan: Regola l'ingrandimento della scansione ausiliare dello scanner
Sub Scan (CIS): Regola l'ingrandimento della scansione ausiliare CIS dello scanner (DP-771)

[确认等倍值]

1. 确认原稿 (a) 上的线 (1) 和复印样本上的线 (2)、(3) 之间的偏移值。如果偏移值超过标准值, 则按照下列步骤进行调整。
<标准值>
对于副扫描方向, 线 (2) 的上下偏移值: ±1.5% 以内
对于主扫描方向, 线 (3) 的左右偏移值: ±1.5% 以内

2. 使用维修模式 U070 调整等倍值。
Main Scan: 读取主扫描等倍度的调整
Sub Scan: 读取副扫描等倍度的调整
Sub Scan (CIS): CIS 的读取副扫描等倍度的调整 (DP-771)

[등배도확인]


1. 원고 (a) 선 (1) 과 복사샘플의 선 (2)(3) 의 차이를 확인합니다 . 차이가 기준이외의 경우, 다음 순서로 조정을 합니다 .
<기준치>
부주사 방향의 경우 선 (2) 의 상하차이: ±1.5% 이내
주주사 방향의 경우 선 (3) 의 좌우차이: ±1.5% 이내

2. 메인터너스 모드 U070 을 세트하고 조정을 합니다 .
Main Scan: 스캔 주사등배도의 조정
Sub Scan: 스캔 부주사등배도의 조정
Sub Scan(CIS): CIS 의 스캔 부주사등배도의 조정 (DP-771)

[等倍度確認]

1. 原稿 (a) の線 (1) とコピーサンプルの線 (2) (3) のずれを確認する。ずれが基準値外の場合、次の手順で調整を行う。
<基準値>
副走査方向の場合、線 (2) の上下ずれ: ±1.5% 以内
主走査方向の場合、線 (3) の左右ずれ: ±1.5% 以内

2. メンテナンスモード U070 をセットし、調整を行う。
Main Scan: 読み取り主走査等倍度の調整
Sub Scan: 読み取り副走査等倍度の調整
Sub Scan (CIS): CIS の読み取り副走査等倍度の調整 (DP-771)



3. Adjust the values.

For the shorter length copy example (h)(j): Increases the value.
 For the longer length copy example (i)(k): Decreases the value.
 Amount of change per step: 0.10 %

4. Perform a test copy.

5. Repeat the steps 2 to 4 above until the gap of line (2) (3) of copy example shows the reference value.

<Reference value>

For the sub-scan direction, vertical gap of line (2): within ±1.5%

For the main-scan direction, horizontal gap of line (3): within ±1.5%

3. Régler les valeurs.

Pour l'exemple de copie dont la longueur est plus courte (h)(j) : augmenter la valeur.

Pour l'exemple de copie dont la longueur est plus longue (i)(k) : diminuer la valeur.

Changement par graduation d'échelle : 0.10 %

4. Effectuer une copie de test.

5. Répéter les étapes 2 à 4 jusqu'à ce que l'écart de la ligne (2) (3) de l'exemple de copie indique la valeur de référence.

<Valeur de référence>

Pour la direction du balayage secondaire, l'écart vertical de la ligne (2) est de ±1,5%

Pour la direction du balayage principal, l'écart horizontal de la ligne (3) est de ±1,5%

3. Ajuste los valores.

Para el ejemplo de copia más corto (h)(j): aumenta el valor.

Para el ejemplo de copia más largo (i)(k): disminuye el valor.

Magnitud del cambio por incremento: 0.10 %

4. Haga una copia de prueba.

5. Repita los pasos 2 a 4 anteriores hasta que la separación de la línea (2) (3) del ejemplo de copia presente el valor de referencia.

<Valor de referencia>

Para la dirección de exploración secundaria, separación vertical de la línea (2): dentro de ±1,5%

Para la dirección de exploración principal, separación horizontal de la línea (3): dentro de ±1,5%

3. Die Werte einstellen.

Für die kürzere Länge des Kopierbeispiels (h)(j): Den Wert erhöhen.

Für die längere Länge des Kopierbeispiels (i)(k): Den Wert verringern.

Änderung pro Schritt: 0.10 %

4. Eine Testkopie erstellen.

5. Die Schritte 2 bis 4 wiederholen, bis der Abstand der Linie (2) (3) des Kopierbeispiels den Bezugswert aufweist.

<Bezugswert>

Subscanrichtung: Vertikaler Abstand der Linie (2): Innerhalb ±1,5%

Hauptscanrichtung: Horizontaler Abstand der Linie (3): Innerhalb ±1,5%

3. Regolare i valori.

Per l'esempio di copia di lunghezza inferiore (h)(j): aumenta il valore.

Per l'esempio di copia di lunghezza superiore (i)(k): riduce il valore.

Entità modifica per passo: 0,10 %

4. Eseguire una copia di prova

5. Ripetere le operazioni sopra descritte da 2 a 4 fino a quando lo scostamento della linea (2) (3) dell'esempio di copia riporterà i valori di riferimento.

<Valore di riferimento>

Per l'orientamento della scansione ausiliare, lo scostamento verticale della linea (2) deve essere compreso fra ±1,5%

Per l'orientamento della scansione principale, lo scostamento orizzontale della linea (3) deve essere compreso fra ±1,5%

3. 調整設定値。

在长度偏短时 复印样本 (h) (j): 调高设定值

在长度偏长时 复印样本 (i) (k): 调低设定值

设定值的一个调整单位变化量: 0.10%

4. 进行测试复印。

5. 重复上述步骤 2 到 4, 直至复印样本上的线 (2)、(3) 之间的偏移值达到标准值范围内。

<标准值>

对于副扫描方向, 线 (2) 的上下偏移值: ±1.5% 以内

对于主扫描方向, 线 (3) 的左右偏移值: ±1.5% 以内

3. 설정치를 조정합니다 .

길이가 짧은 경우 복사샘플 (h)(j): 설정치를 높입니다 .

길이가 긴 경우 복사샘플 (i)(k): 설정치를 내립니다 .

1 스텝당 변화량: 0.10%

4. 시험복사를 합니다 .

5. 복사샘플 선 (2)(3) 의 차이가 기준치내가 될 때까지 2 ~ 4 를 반복합니다 .

< 기준치 >

부주사 방향의 경우 선 (2) 의 상하차이: ±1.5% 이내

주주사 방향의 경우 선 (3) 의 좌우차이: ±1.5% 이내

3. 設定値を調整する。

長さが短い場合コピーサンプル (h) (j): 設定値を上げる

長さが長い場合コピーサンプル (i) (k): 設定値を下げる

1 ステップ当たりの変化量: 0.10%


4. テストコピーを行う。

5. コピーサンプルの線 (2) (3) のずれが基準値内になるまで手順 2 ~ 4 を繰り返す。

< 基準値 >

副走査方向の場合、線 (2) の上下ずれ: ±1.5% 以内

主走査方向の場合、線 (3) の左右ずれ: ±1.5% 以内



[Checking the leading edge timing]

1. Check the gap between line (1) on original (a) and line (2) of copy example. If the gap exceeds the reference value, adjust the gap according to the following procedure.
<Reference value>
Vertical gap of line (2): within ± 2.5 mm

2. Use the maintenance mode U071 to adjust the timing.
Front Head: Adjusts the leading edge timing (surface)
Front Tail: Adjusts the trailing edge timing (surface)
CIS Head: Adjusts the leading edge timing for CIS scanning.
CIS Tail: Adjusts the trailing edge timing for CIS scanning.

[Vérification de la synchronisation du bord avant]

1. Vérifier l'écart entre la ligne (1) de l'original (a) et la ligne (2) de l'exemple de copie. Si l'écart excède la valeur de référence, le régler selon la procédure suivante.
<Valeur de référence>
Écart vertical de la ligne (2) : ± 2.5 mm

2. Pour régler la synchronisation, utilisez le mode entretien U071.
Front Head: Permet de régler la synchronisation du bord de tête (surface)
Front Tail: Permet de régler la synchronisation du bord arrière (surface)
CIS Head: Permet de régler la synchronisation du bord de tête pour le balayage par le CIS.
CIS Tail: Permet de régler la synchronisation du bord arrière pour le balayage par le CIS.

[Cambio de la sincronización de borde superior]

1. Compruebe la separación entre la línea (1) del original (a) y la línea (2) del ejemplo de copia. Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.
<Valor de referencia>
Separación vertical de la línea (2): dentro de $\pm 2,5$ mm

2. Para ajustar la sincronización utilice el modo de mantenimiento U071.
Front Head: ajusta la sincronización del borde superior (anverso).
Front Tail: ajusta la sincronización del borde inferior (anverso).
CIS Head: ajusta la sincronización del borde superior para exploración CIS.
CIS Tail: ajusta la sincronización del borde inferior para exploración CIS.

[Überprüfen des Vorderkanten-Timings]

1. Den Abstand zwischen der Linie (1) des Originals (a) und der Linie (2) des Kopierbeispiels prüfen. Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.
<Bezugswert>
Vertikaler Abstand der Linie (2): Innerhalb $\pm 2,5$ mm

2. Zum Einstellen des Timing den Wartungsmodus U071 verwenden.
Front Head: Zur Einstellung des Vorderkanten-Timing (Oberfläche)
Front Tail: Zur Einstellung des Hinterkanten-Timing (Oberfläche)
CIS Head: Zur Einstellung des Vorderkanten-Timing für CIS-Scannen.
CIS Tail: Zur Einstellung des Hinterkanten-Timing für CIS-Scannen.

[Controllo della sincronizzazione del bordo principale]

1. Verificare lo scostamento fra la linea (1) sull'originale (a) e la linea (2) dell'esempio di copia. Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.
<Valore di riferimento>
Scostamento verticale della linea (2) compreso fra $\pm 2,5$ mm

2. Usare la modalità di manutenzione U071 per regolare la sincronizzazione.
Front Head: Regola la sincronizzazione del bordo principale (superficie)
Front Tail: Regola la sincronizzazione del bordo di uscita (superficie)
CIS Head: Regola la sincronizzazione del bordo principale per scansione CIS.
CIS Tail: Regola la sincronizzazione del bordo di uscita per scansione CIS.

[确认前端定时调整]

1. 确认原稿 (a) 上的线 (1) 和复印样本上的线 (2) 之间的偏移值。如果偏移值超过标准值, 则按照下列步骤进行调整。
<标准值>
线 (2) 的上下偏移值: ± 2.5 mm 以内

2. 使用维修模式 U071 调整定时。
Front Head: 调整前端对位 (正面)
Front Tail: 调整后端对位 (正面)
CIS Head: 调整 CIS 读取时的前段对位
CIS Tail: 调整 CIS 读取时的后端对位

[선단 타이밍확인]


1. 원고 (a) 선 (1) 과 복사샘플 선 (2) 의 차이를 확인합니다 . 차이가 기준치 외의 경우 다음 순서로 조정을 합니다 .
<기준치>
선 (2) 의 상하차이: ± 2.5 mm 이내

2. 메인テナンス 모드 U071 을 세트하고 조정을 합니다 .
Front Head : 선단 타이밍 (표면) 을 조정합니다 .
Front Tail : 후단 타이밍 (표면) 을 조정합니다 .
CIS Head: CIS 스캔 시의 선단 타이밍을 조정합니다 .
CIS Tail: CIS 스캔 시의 후단 타이밍을 조정합니다 .

[先端タイミン確認]

1. 原稿 (a) の線 (1) とコピーサンプルの線 (2) のずれを確認する。ずれが基準値外の場合、次の手順で調整を行う。
<基準値>
線 (2) の上下ずれ: ± 2.5 mm 以内

2. メンテナンスモード U071 をセットし、調整を行う。
Front Head : 先端タイミン (表面) を調整する
Front Tail : 後端タイミン (表面) を調整する
CIS Head: CIS 読み込み時の先端タイミンを調整する
CIS Tail: CIS 読み込み時の後端タイミンを調整する



3. Adjust the values.

For the faster leading edge timing, copy examples (l): Decreases the value.

For the slower leading edge timing, copy examples (m): Increases the value.

Amount of change per step: 0.17 mm

4. Perform a test copy.

5. Repeat the steps 2 to 4 above until the gap of line (2) of copy example shows the reference value.

<Reference value>

Vertical gap of line (2): within ± 2.5 mm

3. Régler les valeurs.

Pour les exemples de copie dont la synchronisation du bord avant est plus rapide (l) : diminuer la valeur.

Pour les exemples de copie dont la synchronisation du bord avant est plus lente (m) : augmenter la valeur.

Changement par graduation d'échelle : 0,17 mm

4. Effectuer une copie de test.

5. Répéter les étapes 2 à 4 jusqu'à ce que l'écart de la ligne (2) de l'exemple de copie indique la valeur de référence.

<Valeur de référence>

Écart vertical de la ligne (2) : ± 2.5 mm

3. Ajuste los valores.

Para una sincronización más rápida de extremo guía, ejemplos de copia (l): disminuye el valor.

Para una sincronización más lenta de extremo guía, ejemplos de copia (m): aumenta el valor.

Magnitud del cambio por incremento: 0,17 mm

4. Haga una copia de prueba.

5. Repita los pasos 2 a 4 anteriores hasta que la separación de la línea (2) del ejemplo de copia presente el valor de referencia.

<Valor de referencia>

Separación vertical de la línea (2): dentro de $\pm 2,5$ mm

3. Die Werte einstellen.

Für den schnelleren Vorderkantentakt, Kopierbeispiel (l): Den Wert verringern.

Für den langsameren Vorderkantentakt, Kopierbeispiel (m): Den Wert erhöhen.

Änderung pro Schritt: 0,17 mm

4. Eine Testkopie erstellen.

5. Die Schritte 2 bis 4 wiederholen, bis der Abstand der Linie (2) des Kopierbeispiels den Bezugswert aufweist.

<Bezugswert>

Vertikaler Abstand der Linie (2): Innerhalb $\pm 2,5$ mm

3. Regolare i valori.

Per accelerare la fasatura del bordo di entrata, esempi di copia (l): riduce il valore.

Per rallentare la fasatura del bordo di entrata, esempi di copia (m): aumenta il valore.

Entità modifica per passo: 0,17 mm

4. Eseguire una copia di prova

5. Ripetere le operazioni sopra descritte da 2 a 4 fino a quando lo scostamento della linea (2) dell'esempio di copia riporterà i valori di riferimento.

<Valore di riferimento>

Scostamento verticale della linea (2) compreso fra $\pm 2,5$ mm

3. 調整設定値。

在前端定时偏快时 复印样本 (l): 调低设定值

在前端定时偏慢时 复印样本 (m): 调高设定值

设定值的一个调整单位变化量: 0.17mm

4. 进行测试复印。

5. 重复上述步骤 2 到 4, 直至复印样本上的线 (2) 的偏移值达到标准值范围内。

<标准值>

线 (2) 的上下偏移值: ± 2.5 mm 以内

3. 설정치를 조정합니다.

선단 타이밍이 빠른 경우 복사샘플 (l): 설정치를 내립니다.

선단 타이밍이 늦은 경우 복사샘플 (m): 설정치를 올립니다.

1 스텝당 변화량: 0.17mm

4. 시험복사를 합니다.

5. 복사샘플 선 (2) 의 차이가 기준치내가 될 때까지 2 ~ 4 를 반복합니다.

<기준치>

선 (2) 의 상하차이: ± 2.5 mm 이내

3. 設定値を調整する。

先端タイミングが早い場合コピーサンプル (l): 設定値を下げる。

先端タイミングが遅い場合コピーサンプル (m): 設定値を上げる。


1 ステップ当たりの変化量: 0.17mm

4. テストコピーを行う。

5. コピーサンプルの線 (2) のずれが基準値内になるまで手順 2 ~ 4 を繰り返す。

<基準値>

線 (2) の上下ずれ: ± 2.5 mm 以内



[Checking the center line]

1. Check the gap between center line (1) on original (a) and center line (2) of copy example. If the gap exceeds the reference value, adjust the gap according to the following procedure.

<Reference value>

Horizontal difference of center line (2) for the single copying: ± 2.0 mm
Horizontal difference of center line (2) for the duplex copying: ± 3.0 mm

2. Use the maintenance mode U072 to adjust the timing.

Front: Adjusts the center line (surface)
Back: Adjusts the center line (rear side)
CIS: Adjusts the CIS center line

[Vérification de la ligne médiane]

1. Vérifier l'écart entre l'axe (1) de l'original (a) et l'axe (2) de l'exemple de copie. Si l'écart excède la valeur de référence, le régler selon la procédure suivante.

<Valeur de référence>

Différence horizontale de l'axe (2) pour la copie recto : ± 2.0 mm
Différence horizontale de l'axe (2) pour la copie recto-verso : ± 3.0 mm

2. Pour régler la ligne médiane, utiliser le mode entretien U072.

Front: Permet de régler l'axe (surface)
Back: Permet de régler l'axe (arrière)
CIS: Permet de régler l'axe du CIS

[Verificación de la línea central]

1. Compruebe la separación entre la línea de centro (1) del original (a) y la línea de centro (2) del ejemplo de copia. Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.

<Valor de referencia>

Diferencia horizontal de la línea de centro (2) para el copiado por una cara: ± 2.0 mm

Diferencia horizontal de la línea de centro (2) para el copiado dúplex: ± 3.0 mm

2. Para ajustar la línea central utilice el modo de mantenimiento U072.

Front: ajusta la línea central (anverso).
Back: ajusta la línea central (reverso).
CIS: ajusta la línea central CIS.

[Überprüfen der Mittellinie]

1. Den Abstand zwischen der Mittellinie (1) des Originals (a) und der Mittellinie (2) des Kopierbeispiels prüfen. Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.

<Bezugswert>

Horizontaler Unterschied der Mittellinie (2) für die Einzelkopie: ± 2.0 mm
Horizontaler Unterschied der Mittellinie (2) für die Duplexkopie: ± 3.0 mm

2. Zum Einstellen der Mittellinie den Wartungsmodus U072 verwenden.

Front: Zur Einstellung der Mittellinie (Oberfläche)
Back: Zur Einstellung der Mittellinie (Rückseite)
CIS: Zur Einstellung der CIS-Mittellinie

[Controllo della linea centrale]

1. Verificare lo scostamento fra la linea centrale (1) sull'originale (a) e la linea centrale (2) dell'esempio di copia. Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.

<Valore di riferimento>

Differenza orizzontale della linea centrale (2) per la copia singola: ± 2.0 mm
Differenza orizzontale della linea centrale (2) per la copia duplex: ± 3.0 mm

2. Usare la modalità di manutenzione U072 per regolare la linea centrale.

Front: Regola la linea centrale (superficie)
Back: Regola la linea centrale (lato posteriore)
CIS: Regola la linea centrale CIS

[确认中心线]

1. 确认原稿 (a) 中心线 (1) 和复印样本中心线 (2) 之间的偏移值。如果偏移值超过标准值, 则按照下列步骤进行调整。

<标准值> 单面复印时, 中心线 (2) 的左右偏移值: ± 2.0 mm 以内
双面复印时, 中心线 (2) 的左右偏移值: ± 3.0 mm 以内

2. 使用维修模式 U072 调整中心线。

Front: 中心位置 (正面) 的调整
Back: 中心位置 (反面) 的调整
CIS: CIS 的中心位置的调整

[센터 라인 확인]

1. 원고 (a) 중심선 (1) 과 복사샘플 중심선 (2) 의 차이를 확인합니다 . 차이가 기준치 외의 경우 다음 순서로 조정합니다 .

<기준치> 단면의 경우 중심선 (2) 의 좌우차이: ± 2.0 mm 이내
양면의 경우 중심선 (2) 의 좌우차이: ± 3.0 mm 이내

2. 메인テナンス 모드 U072 을 세트하고 조정을 합니다 .

Front: 센터 위치 (표면) 의 조정
Back: 센터 위치 (뒷면) 의 조정
CIS: CIS 의 센터 위치조정


[センターライン確認]

1. 原稿 (a) の中心線 (1) とコピーサンプルの中心線 (2) のずれを確認する。ずれが基準値外の場合、次の手順で調整を行う。

<基準値> 片面の場合、中心線 (2) の左右ずれ: ± 2.0 mm 以内
両面の場合、中心線 (2) の左右ずれ: ± 3.0 mm 以内

2. メンテナンスモード U072 をセットし、調整を行う。

Front: センター位置 (表面) の調整
Back: センター位置 (裏面) の調整
CIS: CIS のセンター位置の調整



3. Adjust the values.

If the center moves more front, copy example (n): Increases the value.
 If the center moves inner, copy sample (o): Decreases the value.
 Amount of change per step: 0.085 mm

4. Perform a test copy.

5. Repeat the steps 2 to 4 above until the gap of line (2) of copy example shows the reference value.

<Reference value>

Horizontal difference of center line (2) for the single copying: ± 2.0 mm
 Horizontal difference of center line (2) for the duplex copying: ± 3.0 mm

3. Régler les valeurs.

Pour l'exemple de copie (n) dont l'axe se déplace davantage vers l'avant : augmenter la valeur.

Pour l'exemple de copie (o) dont l'axe se déplace vers l'intérieur : diminuer la valeur.

Changement par graduation d'échelle : 0,085 mm

4. Effectuer une copie de test.

5. Répéter les étapes 2 à 4 jusqu'à ce que l'écart de la ligne (2) de l'exemple de copie indique la valeur de référence.

<Valeur de référence>

Différence horizontale de l'axe (2) pour la copie recto : ± 2.0 mm

Différence horizontale de l'axe (2) pour la copie recto-verso : ± 3.0 mm

3. Ajuste los valores.

Si el centro se desplaza más hacia el frente, ejemplo de copia (n): aumenta el valor.

Si el centro se desplaza hacia dentro, ejemplo de copia (o): disminuye el valor.

Magnitud del cambio por incremento: 0,085 mm

4. Haga una copia de prueba.

5. Repita los pasos 2 a 4 anteriores hasta que la separación de la línea (2) del ejemplo de copia presente el valor de referencia.

<Valor de referencia>

Diferencia horizontal de la línea de centro (2) para el copiado por una cara: ± 2.0 mm

Diferencia horizontal de la línea de centro (2) para el copiado dúplex: ± 3.0 mm

3. Die Werte einstellen.

Wenn die Mitte nach vorne verlagert ist, Kopierbeispiel (n): Den Wert erhöhen.

Wenn die Mitte nach innen verlagert ist, Kopierbeispiel (o): Den Wert verringern.

Änderung pro Schritt: 0,085 mm

4. Eine Testkopie erstellen.

5. Die Schritte 2 bis 4 wiederholen, bis der Abstand der Linie (2) des Kopierbeispiels den Bezugswert aufweist.

<Bezugswert>

Horizontaler Unterschied der Mittellinie (2) für die Einzelkopie: ± 2.0 mm

Horizontaler Unterschied der Mittellinie (2) für die Duplexkopie: ± 3.0 mm

3. Regolare i valori.

Se il centro si sposta più avanti, esempio di copia (n): aumenta il valore.

Se il centro si sposta verso l'interno, esempio di copia (o): riduce il valore.

Entità modifica per passo: 0,085 mm

4. Eseguire una copia di prova

5. Ripetere le operazioni sopra descritte da 2 a 4 fino a quando lo scostamento della linea (2) dell'esempio di copia riporterà i valori di riferimento.

<Valore di riferimento>

Differenza orizzontale della linea centrale (2) per la copia singola: ± 2.0 mm

Differenza orizzontale della linea centrale (2) per la copia duplex: ± 3.0 mm

3. 調整設定値。

当中心向前偏移时 复印样本 (n): 调高设定值

当中心向内偏移时 复印样本 (o): 调低设定值

设定值的一个调整单位变化量: 0.085mm

4. 进行测试复印。

5. 重复上述步骤 2 到 4, 直至复印样本上的线 (2) 的偏移值达到标准值范围内。

<标准值>

单面复印时, 中心线 (2) 的左右偏移值: ± 2.0 mm 以内

双面复印时, 中心线 (2) 的左右偏移值: ± 3.0 mm 以内

3. 설정치를 조정합니다 .

센터가 바로 앞으로 틀려 있는 경우 복사샘플 (n): 설정치를 높입니다 .

센터가 안으로 틀려 있는 경우 복사샘플 (o) : 설정치를 내립니다 .

1 스텝당 변화량: 0.085mm

4. 시험복사를 합니다 .

5. 복사샘플 중심선 (2) 차이가 기준치 내가 될 때까지 순서 2 ~ 4 를 반복합니다 .

< 기준치 >

단면의 경우 중심선 (2) 의 좌우차이: ± 2.0 mm 이내

양면의 경우 중심선 (2) 의 좌우차이: ± 3.0 mm 이내

3. 設定値を調整する。

センターが手前にずれている場合コピーサンプル (n): 設定値を上げる。

センターが奥にずれている場合コピーサンプル (o) 設定値を下げる。

1 ステップ当たりの変化量: 0.085mm

4. テストコピーを行う。


5. コピーサンプルの中心線 (2) ずれが基準値内になるまで手順 2 ~ 4 を繰り返す。

<基準値>



片面の場合、中心線 (2) の左右ずれ: ± 2.0 mm 以内

両面の場合、中心線 (2) の左右ずれ: ± 3.0 mm 以内

INSTALLATION GUIDE FOR PAPER FEEDER



English		E. Clamp 1		I. Media type plate (except for above models).....12	
Supplied parts		F. Wire cover..... 1		J. Stopper 2	
A. Paper feeder..... 1		G. Paper size plate..... 4		K. S Tite screws M4 × 20 4	
B. Pin 2		H. S Tite screw M4 × 8..... 3		Be sure to remove any tape and/or cushioning material from supplied parts.	
C. Retainer..... 1		I. Media type plate(120V model only) 6			
D. Intermediate paper conveying unit..... 1		I. Media type plate(110V model only) 2			
Français		E. Collier..... 1		Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.	
Pièces fournies		F. Couvercle de câble..... 1			
A. Bureau papier..... 1		G. Plaquette du format de papier 4			
B. Broche 2		H. Vis S Tite M4 × 8 3			
C. Élément de retenue 1		I. Plaquette du type de support..... 12			
D. Unité de transport du papier intermédiaire 1		J. Butée 2			
Español		K. Vis S Tite M4 × 20 4		Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.	
Partes suministradas		E. Sujetador 1			
A. Alimentador de papel..... 1		F. Cubierta para el cable..... 1			
B. Clavija..... 2		G. Placa de tamaño de papel 4			
C. Retén..... 1		H. Tornillo S Tite M4 × 8 3			
D. Unidad de transporte de papel intermedia. 1		I. Placa de tipo de medio 12			
Deutsch		J. Tope 2		Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.	
Gelieferte Teile		K. Tornillos S Tite M4 × 20 4			
A. Papiereinzug..... 1		E. Klemme..... 1			
B. Stift..... 2		F. Kabelabdeckung..... 1			
C. Halterung..... 1		G. Papierformatkarte 4			
D. Eingesetzte Papierfördereinheit 1		H. S-Tite-Schraube M4 × 8..... 3			
Italiano		I. Medientypkarte 12		Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.	
Parti di forniture		J. Anschlag 2			
A. Unità di alimentazione della carta 1		K. S-Tite-Schrauben M4 × 20..... 4			
B. Perno 2		E. Morsetto..... 1			
C. Fermo 1		F. Coperchio cavi..... 1			
D. Unità intermediale di trasporto carta..... 1		G. Piastra formato carta 4			
简体中文		H. Vite S Tite M4 × 8 3			
附属品		I. Piastra tipo carta..... 12			
A. 供纸工作台..... 1		J. Fermo 2			
B. 固定插销..... 2		K. Vite S Tite M4 × 20 4			
C. 安装板..... 1		E. 夹钳 1			
D. 中间搬运单元..... 1		F. 电线盖板 1			
한국어		G. 纸张尺寸标示 6			
동봉품		H. 紧固型 S 螺丝 M4×8 3			
A. 급지대..... 1		I. 纸张种类标示 2			
B. 핀..... 2		J. 限位器 2			
C. 부착판..... 1		E. 크램프..... 1			
D. 중간반송유닛..... 1		F. 전선커버..... 1			
日本語		G. 용지크기 플레이트..... 4			
同梱品		H. 나사 M4×8S 타이트..... 3			
A. ペーパーフィーダー..... 1		I. 용지종류 플레이트..... 2			
B. 핀..... 2		J. 전도방지쇠..... 2			
C. 取付板..... 1		E. クランプ 1			
D. 中間搬送ユニット..... 1		F. 電線カバー 1			
		G. 用紙サイズプレート 4			
		H. ビス M4×8S タイト 3			
		I. 用紙種類プレート 2			
		J. 転倒防止金具 2			
		K. ビス M4×20 S タイト 4			
					同梱品に固定テープ、緩衝材が付いている場合は必ず取り外すこと。



Procedure

Be sure to turn the MFP main power switch off and disconnect the MFP power plug from the wall outlet before starting to install the paper feeder.

1. Pull each cassette out and then remove the lift plate stopper (1) from each cassette and attach it to the storage location (2).
2. Gently close each cassette.

3. Remove the lower paper cassette (3) from the MFP
4. Remove the pin (4) and remove the lower paper cassette (3) in the MFP.

Procédure

Veiller à bien mettre l'interrupteur principal du MFP hors tension et à débrancher la fiche d'alimentation du MFP de la prise murale avant de commencer l'installation du bureau papier.

1. Tirer chaque tiroir vers l'extérieur puis retirer la butée de plaque d'élévation (1) de chaque tiroir et la fixer à l'emplacement de rangement (2).
2. Refermer progressivement chaque tiroir.

3. Retirer le tiroir inférieur (3) du MFP.
4. Déposer la broche (4) et le tiroir à papier inférieur (3) du MFP.

Procedimiento

Asegúrese de apagar el interruptor principal del MFP y de desconectar el enchufe del MFP del receptáculo de pared antes de empezar a instalar el alimentador de papel.

1. Abra la bandeja y quite el tope de la placa de elevación (1) de cada bandeja y colóquela en su lugar de depósito (2).
2. Cierre suavemente cada bandeja.

3. Quite el cajón de papel inferior (3) del MFP.
4. Quite el clavija (4) y el cajón de papel inferior (3) del MFP.

Verfahren

Schalten Sie unbedingt den Hauptschalter des MFP aus, und ziehen Sie den Netzstecker des MFP von der Netzsteckdose ab, bevor Sie mit der Installation des Papiereinzugs beginnen.

1. Die einzelnen Kassetten herausziehen, dann den Hebeplattenanschlag (1) von jeder Kasette entfernen und an der Speicherposition (2) anbringen.
2. Alle Kassetten sanft schließen.

3. Nehmen Sie die untere Papierlade (3) vom MFP ab.
4. Die Stift (4) entfernen und die untere Papierlade (3) im MFP abnehmen.

Procedura

Prima di dare inizio alla procedura di installazione dell'unità di alimentazione della carta, non mancare di spegnere l'MFP usando l'interruttore principale di alimentazione e di disinserire la spina del cavo di alimentazione dalla presa a muro della rete elettrica.

1. Estrarre ciascun cassetto e poi rimuovere il fermo della piastra di sollevamento (1) da ciascun cassetto e fissarlo nella posizione di immagazzinaggio (2).
2. Chiudere delicatamente ciascun cassetto.

3. Rimuovere il cassetto inferiore della carta (3) dall'MFP.
4. Rimuovere la perno (4) e quindi rimuovere il cassetto inferiore della carta (3) nell'MFP.

安装步骤

安装供纸工作台时，必须先关闭 MFP 主机上的主电源开关，并拔出电源插头后方可进行工作。

1. 拉出各供纸盒，拆下各 1 个升降板挡块 (1)，并安装在保管场所 (2) 上。
2. 轻轻地推入各供纸盒。

3. 取出 MFP 主机的下部供纸盒 (3)。
4. 拆除 1 颗固定插销 (4)，取出 MFP 主机的下部供纸盒 (3)。

설치순서

급지대를 설치할 때에는 반드시 MFP 본체의 주 전원 스위치를 OFF 로 하고 MFP 본체 전원 플러그를 빼고 작업을 할 것 .

1. 각 카세트를 빼고 리프트판 스톱퍼 (1) 각 1 개를 빼내 보관장소 (2) 에 부착합니다 .
2. 각 카세트를 조용히 밀어 넣습니다 .


3. MFP 본체의 하단 카세트 (3) 를 꺼냅니다 .
4. 핀 (4) 1 개를 제거하고 MFP 본체 하단 카세트 (3) 를 꺼냅니다 .

取付手順


ペーパーフィーダーを取り付ける際は、必ず MFP 本体の主電源スイッチを OFF にし、MFP 本体の電源プラグを抜いてから作業をおこなうこと。

1. 各カセットを引き出し、リフト板ストッパー (1) 各 1 個を外して保管場所 (2) に取り付ける。
2. 各カセットを静かに押し込む。


3. MFP 本体の下段カセット (3) を引き出す。
4. ピン (4) 1 本を外し、MFP 本体の下段カセット (3) を取り外す。



5. Place the MFP (7) on the paper feeder (A) so that the pins (5) at the front left and front right of the paper feeder (A) are aligned with the holes (6) in the base of the MFP.



6. Secure the MFP (7) to the paper feeder (A) with the 2 pins (B).



7. Pull out the lower paper cassette rail (8) in the MFP.
8. Fit the hook (9) on the rail (8) into the hole (10) in the lower paper cassette (3) and replace the lower paper cassette (3).
9. Secure the lower paper cassette (3) using the pin (4) removed in step 4.

5. Monter le MFP (7) sur le bureau papier (A) de sorte que les ergots (5) à l'avant gauche et à l'avant droit du bureau papier (A) soient alignés avec les trous (6) dans la base du MFP.

6. Fixer le MFP (7) au bureau papier (A) avec les 2 broches filetées (B).

7. Extraire la glissière du tiroir à papier inférieur (8) dans le MFP.
8. Insérer le crochet (9) de la glissière (8) dans le trou (10) du tiroir à papier inférieur (3) et reposer le tiroir à papier inférieur (3).
9. Fixer le tiroir à papier inférieur (3) à l'aide de la broche (4) déposée à l'étape 4.

5. Coloque el MFP (7) sobre el alimentador de papel (A) de forma tal que los pasadores (5) en los lados frontales izquierdo y derecho del alimentador de papel (A) estén alineados con los orificios (6) de la base del MFP.

6. Asegure el MFP (7) al alimentador de papel (A) con los 2 pasadores (B).

7. Extraiga el carril del cajón de papel inferior (8) del MFP.
8. Encaje el gancho (9) del carril (8) en el orificio (10) del cajón de papel inferior (3) y vuelva a colocar el cajón de papel inferior (3).
9. Asegure el cajón de papel inferior (3) usando el clavija (4) quitado en el paso 4.

5. Den MFP (7) so auf den Papiereinzug (A) setzen, dass die Stifte (5) vorne links und vorne rechts am Papiereinzug (A) auf die Öffnungen (6) im Boden des MFP ausgerichtet sind.

6. Den MFP (7) mit den 2 Stiften (B) am Papiereinzug (A) sichern.

7. Die Schiene (8) der unteren Papierlade im MFP herausziehen.
8. Den Haken (9) auf der Schiene (8) in die Öffnung (10) der unteren Papierlade (3) einpassen und die untere Papierlade (3) wieder einsetzen.
9. Die untere Papierlade (3) mit der in Schritt 4 entfernten Stift (4) befestigen.

5. Posizionare l'MFP (7) sull'unità di alimentazione della carta (A), in modo che i perni (5) alla parte frontale destra e sinistra dell'unità di alimentazione della carta (A) siano allineati con i fori (6) nella base dell'MFP.

6. Fissare l'MFP (7) all'unità di alimentazione della carta (A) con i 2 perni (B).

7. Estrarre la rotaia (8) del cassetto inferiore della carta nell'MFP.
8. Inserire il gancio (9) sulla rotaia (8) nel foro (10) nel cassetto inferiore della carta (3) e ricollocare il cassetto inferiore della carta (3).
9. Fissare il cassetto inferiore della carta (3) utilizzando la perno (4) rimossa nel passo 4.

5. 供紙盒 (A) の左右前面的各挿銷 (5) 分別對准 MFP 主機底面的孔 (6) 后, 將 MFP 主機 (7) 放在供紙盒 (A) 上

6. 用 2 個固定插銷 (B) 將 MFP 主機 (7) 固定在供紙盒 (A) 上。

7. 拉出 MFP 主机的下部供紙盒 (8) 导轨。
8. 将导轨 (8) 的卡扣 (9) 嵌入下部供紙盒 (3) 的孔 (10) 中, 按原样安装下部供紙盒 (3)
9. 使用步骤 4 中取下的 1 顆固定插銷 (4) 來固定下部供紙盒 (3)

5. 급지대 (A) 의 좌우 전방의 각 핀 (5) 과 MFP 본체의 베이스 구멍 (6) 이 맞도록 급지대 (A) 에 MFP 본체 (7) 를 놓습니다 .


6. 핀 (B) 2 개로 MFP 본체 (7) 를 급지대 (A) 에 고정합니다 .

7. MFP 본체의 하단 카세트 레일 (8) 을 꺼냅니다 .
8. 레일 (8) 후크 (9) 를 하단 카세트 (3) 구멍 (10) 에 꽂습니다 . 하단 카세트 (3) 를 원래 대로 장착합니다 .
9. 순서 4 에서 제거한 핀 (4) 1 개로 하단 카세트 (3) 를 고정합니다 .


5. ペーパーフィーダー(A) の左右前方の各ピン (5) と MFP 本体のベースの穴 (6) が合うように、ペーパーフィーダー(A) に MFP 本体 (7) を載せる。

6. ピン (B) 2 本で MFP 本体 (7) をペーパーフィーダー(A) に固定する。


7. MFP 本体の下段カセットレール (8) を引き出す。
8. レール (8) のフック (9) を下段カセット (3) の穴 (10) にはめ込み、下段カセット (3) を元通り取り付け。
9. 手順 4 で外したピン (4) 1 本で下段カセット (3) を固定する。



10. Remove the screw (11) in the rear of the paper feeder and remove the cover (12).



11. Remove the screw (13) to remove the metal plate (14).



12. Fit the hook (15) on the mounting plate (C) into the opening (16) and then align the 2 positioning projections.

13. Secure the mounting plate (C) with the screw (H).

10. Déposer la vis (11) à l'arrière du bureau papier et déposer le couvercle (12).

11. Déposer la vis (13) pour enlever la plaque métallique (14).

12. Insérer le crochet (15) du plateau de montage (C) dans l'ouverture (16) et aligner les 2 saillies de positionnement.

13. Fixer le plateau de montage (C) avec la vis (H).

10. Quite el tornillo (11) del lado trasero del alimentador de papel y quite la cubierta (12).

11. Quite el tornillo (13) para desmontar la placa de metal (14).

12. Coloque el gancho (15) de la placa de montaje (C) en la abertura (16) y, después, alinee los 2 resaltes de posición.

13. Asegure la placa de montaje (C) con el tornillo (H).

10. Die Schraube (11) an der Rückseite des Papiereinzugs entfernen und die Abdeckung (12) abnehmen.

11. Die Schraube (13) herausdrehen, um die Metallplatte (14) abzunehmen.

12. Den Haken (15) auf der Montageplatte (C) in die Öffnung (16) einpassen und dann die 2 Positionierungsnasen ausrichten.

13. Die Montageplatte (C) mit der Schraube (H) befestigen.

10. Rimuovere la vite (11) nel retro dell'unità di alimentazione della carta e quindi rimuovere il coperchio (12).

11. Rimuovere la vite (13), per rimuovere la piastra di metallo (14).

12. Inserire il gancio (15) sulla piastra di montaggio (C) nell'apertura (16) e quindi allineare le 2 sporgenze di posizionamento.

13. Fissare la piastra di montaggio (C) con la vite (H).

10. 拆除供紙盒后部的 1 顆螺絲 (11)，拆下盖板 (12)。

11. 拆除 1 顆螺絲 (13)，拆下金屬件 (14)。

12. 將安裝板 (C) 的卡扣 (15) 挂在開口部 (16) 上，並與定位用的 2 處突出部對齊。

13. 使用 1 顆螺絲 (H) 來固定安裝板 (C)。

10. 금지대 후면의 뒤쪽 나사 (11) 1 개를 제거하고 커버 (12) 를 떼어 냅니다 .

11. 나사 (13) 1 개를 제거하고 쇠 (14) 를 제거합니다 .

12. 부착판 (C) 의 후크 (15) 를 개구부 (16) 에 걸고 위치조정 돌기 2 곳을 맞춥니다 .


13. 나사 (H) 1 개로 부착판 (C) 을 고정합니다 .

10. ペーパーフィーダー後側のビス (11) 1 本を外し、カバー (12) を取り外す。


11. ビス (13) 1 本を外し、金具 (14) を取り外す。

12. 取付板 (C) のフック (15) を開口部 (16) に引っ掛けてから、位置決め突起 2箇所を合わせる。

13. ビス (H) 1 本で取付板 (C) を固定する。




14. Pass the power cord (17) through the edging (small) (18) and the signal cable (19) through the edging (large) (20) and then close the edging



15. Connect the power cord (21) and the signal cable (22) to connectors (23) (24) respectively on the MFP.

16. Replace the cover (12) using the screw (11) removed in step 10.



17. Open the lower right cover (25) on the MFP. Remove the strap (26) from the shaft (27) and remove lower right cover (25).

14. Faire passer le cordon d'alimentation (17) dans le (petit) passage (18) et le câble du signal (19) dans le (grand) passage (20) puis fermer le passage.

15. Raccorder respectivement le cordon d'alimentation (21) et le câble à signal (22) aux connecteurs (23) (24) du MFP.

16. Reposer le couvercle (12) à l'aide de la vis (11) déposée à l'étape 10.

17. Ouvrir le couvercle inférieur droit (25) du MFP. Déposer la courroie (26) de l'arbre (27) et déposer le couvercle inférieur droit (25).

14. Pase el cable de alimentación (17) a través de la pestaña (pequeña) (18) y el cable de señales (19) a través de la pestaña (grande) (20) y, después, cierre la pestaña.

15. Conecte el cable de alimentación (21) y el cable de señales (22) a los conectores (23) (24) del MFP, respectivamente.

16. Vuelva a colocar la cubierta (12) usando el tornillo (11) quitado en el paso 10.

17. Abra la cubierta frontal inferior (25) del MFP. Quite la correa (26) del eje (27) y quite la cubierta frontal inferior (25).

14. Das Netzkabel (17) durch den Kantenschutz (klein) (18) und das Signalkabel (19) durch den Kantenschutz (groß) (20) führen und dann den Kantenschutz schließen.

15. Das Netzkabel (21) und das Signalkabel (22) an den entsprechenden Steckverbindern (23) (24) des MFP anschließen.

16. Die Abdeckung (12) mittels der in Schritt 10 entfernten Schraube (11) wieder anbringen.

17. Die untere rechte Abdeckung (25) am MFP öffnen. Den Riemen (26) von der Welle (27) abnehmen und dann die untere rechte Abdeckung (25) abnehmen.

14. Passare il cavo di alimentazione (17) attraverso il bordo (piccolo) (18) e il cavo del segnale (19) attraverso il bordo (grande) (20), e quindi chiudere il bordo.

15. Collegare il cavo di alimentazione (21) e il cavo del segnale (22) rispettivamente ai connettori (23) e (24) sull'MFP.

16. Ricollocare il coperchio (12) utilizzando la vite (11) rimossa nel passo 10.

17. Aprire il pannello destro inferiore (25) sull'MFP. Rimuovere la cinghietta (26) dall'asta (27) e quindi rimuovere il pannello destro inferiore (25).

14. 将 AC 电线 (17) 从包边孔 (小) (18), 信号线 (19) 从包边孔 (大) (20) 中分别穿过, 关闭包边孔。

15. 将 AC 电线 (21) 以及信号线 (22) 分别与主机的接插件 (23)、(24) 连接。

16. 使用在步骤 10 中拆除的 1 颗螺丝 (11) 按原样安装盖板 (12)。

17. 打开 MFP 主机的右下部盖板 (25)。将带子 (26) 从轴 (27) 上拆除, 拆下右下部盖板 (25)。

14. AC 전선 (17) 을 에징 (소) (18) 에, 신호선 (19) 을 에징 (대) (20) 에 각각 지나가게 하고 에징을 닫습니다.

15. AC 전선 (21) 및 신호선 (22) 을 본체 커넥터 (23), (24) 에 각각 접속합니다.

16. 순서 10 에서 제거한 나사 (11) 1 개로 커버 (12) 를 원래대로 부착합니다.


17. MFP 본체의 오른쪽 아래 커버 (25) 를 엽니다. 스트랩 (26) 를 축 (27) 에서 떼어내 오른쪽 아래 커버 (25) 를 제거합니다.

14. AC 電線 (17) をエッジング(小) (18) に、信号線 (19) をエッジング(大) (20) にそれぞれ通し、エッジングを閉じる。


15. AC 電線 (21) および信号線 (22) を本体のコネクター (23)、(24) にそれぞれ接続する。

16. 手順 10 で取り外したビス (11) 1 本でカバー (12) を元通りに取り付ける。

17. MFP 本体の右下カバー (25) を開く。ストラップ (26) を軸 (27) から外し、右下カバー (25) を取り外す。



18. Open the paper feeder right cover (28).



19. Fit the 3 hooks (29) on the intermediate paper conveying unit (D) into the 3 holes (30) in the guide.
20. Secure the intermediate paper conveying unit (D) with the 2 screws (H).

18. Ouvrir le couvercle droit du bureau papier (28).

19. Insérer les 3 crochets (29) de l'unité de transport du papier intermédiaire (D) dans les 3 trous (30) du guide.
20. Fixer l'unité de transport du papier intermédiaire (D) à l'aide des 2 vis (H).

18. Abra la cubierta derecha del alimentador de papel (28).

19. Coloque los 3 ganchos (29) de la unidad de transporte de papel intermedia (D) en los 3 orificios (30) de la guía.
20. Asegure la unidad de transporte de papel intermedia (D) con los 2 tornillos (H).

18. Die rechte Abdeckung (28) des Papiererzugs öffnen.

19. Die 3 Haken (29) an der eingesetzten Papierfördereinheit (D) in die 3 Öffnungen (30) in der Führung einpassen.
20. Die eingesetzte Papierfördereinheit (D) mit den 2 Schrauben (H) sichern.

18. Aprire il pannello destro (28) dell'unità di alimentazione della carta.

19. Inserire i 3 ganci (29) sull'unità intermediale di trasporto carta (D) nei 3 fori (30) nella guida.
20. Fissare l'unità intermediale di trasporto carta (D) con le 2 viti (H).

18. 打开供纸盒的右部盖板 (28)。


19. 将中间搬运单元 (D) 的 3 个卡扣 (29) 嵌入导向板的 3 个孔 (30) 中。
20. 使用 2 颗螺丝 (H) 来固定中间搬运单元 (D)。

18. 금지대 오른쪽 커버 (28) 를 엽니다 .


19. 중간반송유닛 (D) 의 후크 (29) 3 개를 가이드 구멍 (30) 3 곳에 꽂습니다 .
20. 나사 (H) 2 개로 중간반송유닛 (D) 를 고정합니다 .

18. ペーパーフィーダーの右カバー (28) を開く。


19. 中間搬送ユニット (D) のフック (29) 3 個をガイドの穴 (30) 3 カ所にはめ込む。
20. ビス (H) 2 本で中間搬送ユニット (D) を固定する。



21. Connect the intermediate paper conveying unit connector (31).
 22. Attach the clamp (E) and secure the connector wire.



23. Insert the projection (32) on the wire cover (F) into the hole (33) in the paper feeder and install the wire cover (F).
 24. Close the paper feeder right cover (28) and replace the lower right cover (25) on the MFP.



25. Turn the adjusters on each corner (34) until they reach the floor and then secure the paper feeder.

21. Raccorder le connecteur (31) de l'unité de transport du papier intermédiaire.
 22. Monter le collier (E) et fixer le câble du connecteur.

23. Insérer la saillie (32) du couvercle du câble (F) dans le trou (33) du bureau papier et reposer le couvercle du câble (F).
 24. Fermer le couvercle droit du bureau papier (28) et reposer le couvercle inférieur droit (25) sur le MFP.

25. Faire tourner les dispositifs de réglage de chacun des coins (34) jusqu'à ce qu'ils touchent le sol et fixer ensuite le bureau papier.

21. Conecte el conector de la unidad de transporte de papel intermedia (31).
 22. Fije el sujetador (E) y asegure el cable del conector.

23. Inserte el resalto (32) de la cubierta para el cable (F) en el orificio (33) del alimentador de papel e instale la cubierta para el cable (F).
 24. Cierre la cubierta derecha del alimentador de papel (28) y vuelva a colocar la cubierta derecha inferior (25) en el MFP.

25. Gire los reguladores en cada esquina (34) hasta que lleguen al piso y, a continuación, asegure el alimentador de papel.

21. Den Steckverbinder (31) der eingesetzten Papierfördereinheit anschließen.
 22. Die Klemme (E) anbringen und das Kabel des Steckverbinders sichern.

23. Die Nase (32) der Kabelabdeckung (F) in die Öffnung (33) des Papiereinzugs einsetzen und die Kabelabdeckung (F) anbringen.
 24. Die rechte Abdeckung (28) des Papiereinzugs schließen und die untere rechte Abdeckung (25) wieder am MFP einsetzen.

25. Die Einsteller an jeder Ecke (34) drehen, bis sie den Boden berühren, und dann den Papiereinzug sichern.

21. Collegare il connettore (31) dell'unità intermediale di trasporto carta.
 22. Applicare il morsetto (E) e fissare il cavo del connettore.

23. Inserire la sporgenza (32) del coperchio cavi (F) nel foro (33) nell'unità di alimentazione della carta ed installare il coperchio cavi (F).
 24. Chiudere il pannello destro (28) dell'unità di alimentazione della carta e ricollocare il pannello destro inferiore (25) sull'MFP.

25. Ruotare i regolatori (34) presenti su ciascun angolo finché vengano a contatto con il pavimento, e quindi fissare l'unità di alimentazione della carta.

21. 连接中间搬运单元的接插件 (31)。
 22. 安装夹钳 (E)，以固定接插件电线。

23. 将电线盖板 (F) 的突出部 (32) 插入供纸盒的孔 (33) 中，安装电线盖板 (F)。
 24. 关闭供纸盒的右部盖板 (28)，按原样安装 MFP 主机的右下盖板 (25)。

25. 转动四角上的调节器 (34) 直至与地面接触，然后再固定供纸盒。

21. 중간반송유닛의 커넥터 (31) 를 접속합니다.
 22. 클램프 (E) 를 부착, 커넥터 전선을 고정합니다.


23. 전선커버 (F) 의 돌기 (32) 를 급지대의 구멍 (33) 에 넣고 전선커버 (F) 를 부착합니다.
 24. 급지대 오른쪽 커버 (28) 를 닫고, MFP 본체의 오른쪽 아래 커버 (25) 를 원래대로 부착합니다.

25. 네 곳의 어저스터 (34) 를 맨 밑에 닿을 위치까지 돌려 급지대를 고정합니다.

21. 中間搬送ユニットのコネクター(31) を接続する。
 22. クランプ (E) を取り付け、コネクター電線を固定する。

23. 電線カバー (F) の突起 (32) をペーパーフィーダーの穴 (33) に入れて、電線カバー (F) を取り付ける。
 24. ペーパーフィーダーの右カバー (28) を閉じ、MFP 本体の右下カバー (25) を元通りに取り付ける。

25. 四隅のアジャスター(34) を床に接触する位置まで回し、ペーパーフィーダーを固定する。



26. Select holes (38) and install each stopper (J) with 2 S Tite screws M4 × 20 (K) so that the stoppers will be grounded on the floor.

26. Sélectionner les trous (38) et installer chaque butée (J) avec 2 vis S Tite M4 × 20 (K) de sorte que les butées reposent sur le sol.

26. Seleccione los orificios (38) e instale cada tope (J) con los 2 tornillos S Tite M4 × 20 (K) de manera que los topes se conecten a tierra en el suelo.


26. Wählen Sie die Öffnungen (38) und befestigen Sie jeden Anschlag (J) mit den 2 S-Tite-Schrauben M4 × 20 (K) so an, dass die Anschläge am Boden aufsitzen.

26. Selezionare i fori (38) ed installare ogni fermo (J) con le 2 viti S Tite M4 × 20 (K) in modo che i fermi siano posti a terra sul pavimento.

26. 在孔(38)处各用2颗M4×20紧固型S螺丝(K)安装限位器(J),使之和地板接触。

26. 전도방지쇠(J)가 바닥면에 접지될 수 있도록 구멍(38)을 선택해 나사 M4×20 S 타이트(K) 각 2개로 설치합니다.

26. 転倒防止金具(J)が床面に接地するように、穴(38)を選択してビス M4×20 S タイト(K)各2本で取り付けます。



Setting the paper size plate and media type plate

Insert the paper size plate (G) and media type plate (I) into the each slots respectively.

Skewed paper feed adjustment

1. Connect the MFP power plug to the wall outlet and turn the MFP main power switch on.
2. Load paper into the cassette and make a test copy to check the image.
3. If the image is skewed (skewed paper feed), make the adjustments described below.
<Reference value> Left-right difference of 1.5 mm or less

Disposition des plaquettes du format de papier et du type de support

Introduire la plaquette du format de papier (G) et la plaquette du type de support (I) dans leur logement respectif.

Réglage de l'entraînement du papier en biais

1. Insérer la fiche d'alimentation du MFP dans la prise murale et mettre l'interrupteur principal du MFP sous tension.
2. Mettre du papier dans le tiroir et effectuer une copie d'essai pour vérifier l'image.
3. Si l'image est en biais (entraînement du papier en biais), régler en procédant comme décrit ci-dessous.
<Valeur de référence> Différence de droite à gauche de 1,5 mm ou moins.

Ajuste de la placa de tamaño de papel y la placa de tipo de medio

Inserte la placa de tamaño de papel (G) y la placa de tipo de medio (I) en cada uno de las ranuras, respectivamente.

Ajuste de alimentación de papel torcida

1. Conecte el enchufe del MFP en el receptáculo de pared y encienda el interruptor principal del MFP.
2. Introduzca papel en el cajón y haga una copia de prueba para verificar la imagen.
3. Si la imagen está torcida (alimentación del papel torcida) haga los ajustes que se describen a continuación.
<Valor de referencia> diferencia izquierda-derecha de 1,5 mm o menor.

Einsetzen der Papierformatkarte und der Medientypkarte

Setzen Sie die Papierformatkarte (G) und die Medientypkarte (I) in die jeweiligen Führungen.

Einstellung bei verkantetem Papiereinzug

1. Stecken Sie den Netzstecker des MFP in die Wandsteckdose und schalten Sie den MFP am Hauptschalter ein.
2. Legen Sie Papier in die Papierlade ein und machen Sie eine Testkopie, um das Bild zu prüfen.
3. Nehmen Sie nachstehende Einstellungen vor, falls das Bild verkantet ist (verkanteter Papiereinzug).
<Bezugswert> Links-rechts-Differenz maximal 1,5 mm.

Impostazione della piastra di formato carta e della piastra del tipo di supporto

Inserire la piastra del formato carta (G) e la piastra del tipo di supporto (I) nei rispettivi alloggiamenti.

Regolazione alimentazione obliqua carta

1. Collegare la spina del cavo di alimentazione dell'MFP alla presa a muro della rete elettrica e accendere l'interruttore principale di alimentazione.
2. Caricare carta nel cassetto ed eseguire una copia di prova per controllare l'immagine.
3. Se l'immagine risulta obliqua (alimentazione obliqua della carta), eseguire le regolazioni descritte sotto.
<Valore di riferimento> Differenza tra destra e sinistra di 1,5 mm o inferiore

纸张尺寸标示和纸张种类标示的安装

将纸张尺寸标示 (G) 和纸张种类标示 (I) 分别插入到图示的插槽中。

歪斜进纸调节

1. 将 MFP 主机上的电源插头插入电源插座中，打开主电源开关。
2. 在纸盒中放入纸张。进行测试复印以确认图像。
3. 图像倾斜（歪斜进纸）时进行以下调节。
<基准值> 左右差 1.5mm 以下

용지크기 플레이트와 용지종류 플레이트의 세트

용지크기 플레이트 (G) 와 용지종류 플레이트 (I) 를 각 표시 슬롯에 각각 삽입한다.

경사급지 조정


1. MFP 본체 전원플러그를 콘센트에 꽂고 주 전원 스위치를 ON 으로 합니다.
2. 카세트에 용지를 장착합니다. 시험복사를 하고 화상을 확인합니다.
3. 화상이 기울어져 있는 (경사급지) 경우에는 다음 조정을 합니다.
<기준치> 좌우차 1.5mm 이하

用紙サイズプレートと用紙種類プレートのセット

用紙サイズプレート (G) と用紙種類プレート (I) を各表示スロットにそれぞれ挿入する。

斜め給紙調整

1. MFP 本体の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。
2. カセットに用紙をセットする。テストコピーをおこない、画像を確認する。
3. 画像が傾いている (斜め給紙) 場合は次の調整をおこなう。
<基準値> 左右差 1.5mm 以下



4. Pull out the cassette (35) in the paper feeder and loosen the 4 screws (36).
5. Turn the adjusting screw (37) to adjust the cursor skew.
6. Retighten the 4 screws (36).
7. Make another test copy to check the image.

-
4. Sortir le tiroir (35) du bureau papier et desserrer les 4 vis (36).
 5. Faire tourner la vis de réglage (37) pour régler la déviation du curseur.
 6. Resserrer les 4 vis (36).
 7. Faire une autre copie d'essai pour vérifier l'image.

-
4. Extraiga el cajón (35) del alimentador de papel y afloje los 4 tornillos (36).
 5. Gire el tornillo de ajuste (37) para ajustar la desviación del cursor.
 6. Vuelva a apretar los 4 tornillos (36).
 7. Haga otra copia de prueba para verificar la imagen.


-
4. Ziehen Sie die Papierlade (35) aus dem Papiereinzug und lösen Sie die 4 Schrauben (36).
 5. Drehen Sie die Einstellschraube (37), um die Cursor-Verkantung zu korrigieren.
 6. Ziehen Sie die 4 Schrauben (36) wieder an
 7. Erstellen Sie zur Überprüfung des Bilds noch einmal eine Testkopie.

-
4. Estrarre il cassetto (35) dell'unità di alimentazione della carta e quindi allentare le 4 viti (36).
 5. Ruotare la vite di regolazione (37) per regolare l'inclinazione del cursore.
 6. Ristringere le 4 viti (36).
 7. Eseguire un'altra copia di prova per controllare l'immagine.

-
4. 拉出供纸盒 (35)，拧松 4 颗螺丝 (36)。
 5. 旋转调节螺丝 (37)，以调节游标的倾斜。
 6. 拧紧 4 颗螺丝 (36)。
 7. 再次进行测试复印，确认图像。

-
4. 금지 카세트 (35) 를 빼 내어 나사 (36) 4 개를 느슨하게 합니다 .
 5. 조정나사 (37) 을 돌려 커서 경사조정을 합니다 .
 6. 나사 (36) 4 개를 조입니다 .
 7. 다시 시험복사를 하고 화상을 확인합니다 .

-
4. ペーパーフィーダーのカセット (35) を引き出し、ビス (36) 4 本を緩める。
 5. 調整ネジ (37) を回し、カーソルの傾き調整をおこなう。
 6. ビス (36) 4 本を締め付ける。
 7. 再度、テストコピーをおこない、画像を確認する。



Adjusting the leading edge timing

The reference value for the leading edge timing is 20 ± 1.5 mm at position (b) in the correct image (a). If the timing is outside this range, perform the following adjustment.

1. Set maintenance mode U034, select LSU Out Top and Cassette(L)
2. Adjust the values.
Test pattern (c): Increase the setting value. Test pattern (d): Decrease the setting value.
3. Press the Start key to confirm the setting value.

Réglage de la synchronisation du bord de tête

La valeur de référence de la synchronisation du bord de tête est de $20 \pm 1,5$ mm à la position (b) d'une image correcte (a). Si la synchronisation est hors de cette plage, procéder au réglage suivant.

1. Passer en mode maintenance U034, sélectionner LSU Out Top et Cassette(L).
2. Régler les valeurs.
Mire d'essai (c): Augmentez la valeur de réglage. Mire d'essai (d): Diminuez la valeur de réglage.
3. Appuyer sur la touche de Start pour confirmer la valeur de réglage.

Cómo ajustar la sincronización del borde superior

El valor de referencia de la sincronización del borde superior es de $20 \pm 1,5$ mm en la posición (b) de la imagen correcta (a). Si la sincronización estuviera fuera de este rango, haga el siguiente ajuste.

1. Entre al modo de mantenimiento U034, seleccione LSU Out Top y Cassette(L).
2. Ajuste los valores.
Patrón de prueba (c): Aumente el valor de configuración. Patrón de prueba (d): Reduzca el valor de configuración.
3. Pulse la tecla de Start para confirmar el valor de configuración.

Einstellen des Vorderkanten-Timing

Der Bezugswert des Vorderkanten-Timing ist $20 \pm 1,5$ mm an Position (b) des korrekten Bilds (a). Falls das Timing außerhalb dieses Bereichs liegt, ist folgende Einstellung vorzunehmen.

1. Schalten Sie in den Wartungsmodus U034, wählen Sie LSU Out Top und Cassette(L).
2. Die Werte einstellen.
Testmuster (c): Den Einstellwert erhöhen. Testmuster (d): Den Einstellwert verringern.
3. Den Einstellwert durch Drücken der Start-Taste bestätigen.

Regolazione della sincronizzazione del bordo principale

Il valore di riferimento per la sincronizzazione del bordo principale è $20 \pm 1,5$ mm alla posizione (b) nell'immagine corretta (a). Se la sincronizzazione è all'infuori di questa gamma, effettuare la regolazione seguente.

1. Impostare la modalità manutenzione U034, selezionare LSU Out Top e Cassette(L).
2. Regolare i valori.
Modello di prova (c): Aumentare il valore dell'impostazione. Modello di prova (d): Diminuire il valore dell'impostazione.
3. Premere il tasto di Start per confermare il valore dell'impostazione.

前端対位調整

前端対位の基準値は矯正画像 (a) の (b) 位置が 20 ± 1.5 mm。超出该范围时，须进行以下调节。

1. 设置维护模式 U034，选择 LSU Out Top、Cassette(L)。
2. 调整设定值。
测试图案 (c)：调高设定值。测试图案 (d)：调低设定值。
3. 按 Start 键，以确定设定值。

선단 타이밍 조정


선단 타이밍은 적정화상 (a) 의 (b) 위치에서 기준치는 20 ± 1.5 mm. 여기에서 벗어나는 것은 이하의 조정을 합니다.

1. 메인テナンス 모드 U034 를 세트하고 LSU Out Top, Cassette(L) 을 선택합니다.
2. 설정치를 조정합니다.
테스트 패턴 (c) : 설정치를 높입니다. 테스트 패턴 (d) : 설정치를 내립니다.
3. 시작키를 누르고 설정치를 확인합니다.

先端タイミング調整

先端タイミングは、適正画像 (a) の (b) の位置で基準値は 20 ± 1.5 mm。これから外れるときは以下の調整をおこなう。

1. メンテナンスモード U034 をセットし、LSU Out Top、Cassette(L) を選択する。
2. 設定値を調整する。
テストパターン (c) : 設定値を上げる。テストパターン (d) : 設定値を下げる。
3. スタートキーを押し、設定値を確定する。



Adjusting the center line

The reference value for the center line is ± 0.5 mm or less at position (f) in the correct image (e). If the center line position is outside this range, perform the following adjustment.

1. Set maintenance mode U034, select LSU Out Left and Cassette3 or Cassette4.
2. Adjust the values.
Test pattern (g): Increase the setting value. Test pattern (h): Decrease the setting value.
3. Press the Start key to confirm the setting value.

Réglage de l'axe

La valeur de référence pour l'axe est de $\pm 0,5$ mm ou moins à la position (f) d'une image correcte (e). Si la position de l'axe est hors de cette plage, effectuez le réglage suivant.

1. Passer en mode maintenance U034, sélectionner LSU Out Left et Cassette3 ou Cassette4.
2. Régler les valeurs.
Mire d'essai (g): Augmentez la valeur de réglage. Mire d'essai (h): Diminuez la valeur de réglage.
3. Appuyer sur la touche de Start pour confirmer la valeur de réglage.

Ajuste de la línea central

El valor de referencia de la línea central es de $\pm 0,5$ mm o menor, en la posición (f) de la imagen correcta (e). Si la posición de la línea central estuviera fuera de este rango, haga el siguiente ajuste.

1. Entre al modo de mantenimiento U034, seleccione LSU Out Left y Cassette3 o Cassette4.
2. Ajuste los valores.
Patrón de prueba (g): Aumente el valor de configuración. Patrón de prueba (h): Reduzca el valor de configuración.
3. Pulse la tecla de Start para confirmar el valor de configuración.

Einstellen der Mittelinie

Der Bezugswert für die Mittelinie ist $\pm 0,5$ mm oder weniger an Position (f) des korrekten Bilds (e). Falls die Mittelinie außerhalb dieses Bereichs liegt, ist folgende Einstellung vorzunehmen.

1. Schalten Sie in den Wartungsmodus U034, wählen Sie LSU Out Left und Cassette3 oder Cassette4.
2. Die Werte einstellen.
Testmuster (g): Den Einstellwert erhöhen. Testmuster (h): Den Einstellwert verringern.
3. Den Einstellwert durch Drücken der Start-Taste bestätigen.

Regolazione della linea centrale

Il valore di riferimento per la linea centrale è $\pm 0,5$ mm o inferiore alla posizione (f) nell'immagine corretta (e). Se la posizione della linea centrale è all'infuori di questa gamma, effettuare la regolazione seguente.

1. Impostare la modalità manutenzione U034, selezionare LSU Out Left e Cassette3 o Cassette4.
2. Regolare i valori.
Modello di prova (g): Aumentare il valore dell'impostazione. Modello di prova (h): Diminuire il valore dell'impostazione.
3. Premere il tasto di Start per confermare il valore dell'impostazione.

中心线调节

中心线的基准值在矫正图像 (e) 的 (f) 位置为 ± 0.5 mm 以内。超出该范围时, 须进行以下调节。

1. 设置维护模式 U034, 选择 LSU Out Left、Cassette3 或 Cassette4。
2. 调整设定值。
测试图案 (g): 调高设定值。测试图案 (h): 调低设定值。
3. 按 Start 键, 以确定设定值。

센터라인 조정

센터라인은 적정화상 (e) 의 (f) 위치에서 기준치는 ± 0.5 mm 이내 . 여기에서 벗어나는 것은 이하의 조정을 합니다 .


1. 메인터넌스 모드 U034 를 세트하고 LSU Out Left, Cassette3 또는 Cassette4 를 선택합니다 .
2. 설정치를 조정합니다 .
테스트 패턴 (g) : 설정치를 높입니다 . 테스트 패턴 (h) : 설정치를 내립니다 .
3. 시작키를 누르고 설정치를 확인합니다 .

センターライン調整



センターラインは、適正画像 (e) の (f) の位置で基準値は ± 0.5 mm 以内。これから外れるときは以下の調整をおこなう。

1. メンテナンスモード U034 をセットし、LSU Out Left、Cassette3 または Cassette4 を選択する。
2. 設定値を調整する。
テストパターン (g) : 設定値を上げる。 テストパターン (h) : 設定値を下げる。
3. スタートキーを押し、設定値を確定する。

INSTALLATION GUIDE FOR LARGE CAPACITY FEEDER



English		E. Clamp 1		K. S Tite screws M4 × 20 4	
Supplied parts					
A. Paper feeder 1	B. Pin 2	C. Retainer 1	D. Intermediate paper conveying unit 1	F. Wire cover 1	G. Paper size plate 4
H. S Tite screw M4 × 8 3	I. Media type plate(except for 120V model) 12	I. Media type plate(120V model only) 6	J. Stopper 2	Be sure to remove any tape and/or cushioning material from supplied parts.	
Français		E. Collier 1		Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.	
Pièces fournies					
A. Bureau papier 1	B. Broche 2	C. Élément de retenue 1	D. Unité de transport du papier intermédiaire 1	F. Couverture de câble 1	G. Plaquette du format de papier 4
H. Vis S Tite M4 × 8 3	I. Plaquette du type de support 12	J. Butée 2	K. Vis S Tite M4 × 20 4		
Español		E. Sujetador 1		Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.	
Partes suministradas					
A. Alimentador de papel 1	B. Clavija 2	C. Retén 1	D. Unidad de transporte de papel intermedia. 1	F. Cubierta para el cable 1	G. Placa de tamaño de papel 4
H. Tornillo S Tite M4 × 8 3	I. Placa de tipo de medio 12	J. Tope 2	K. Tornillos S Tite M4 × 20 4		
Deutsch		E. Klemme 1		Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.	
Gelieferte Teile					
A. Papiereinzug 1	B. Stift 2	C. Halterung 1	D. Eingesetzte Papierfördereinheit 1	F. Kabelabdeckung 1	G. Papierformatkarte 4
H. S-Tite-Schraube M4 × 8 3	I. Medientypkarte 12	J. Anschlag 2	K. S-Tite-Schrauben M4 × 20 4		
Italiano		E. Morsetto 1		Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.	
Parti di forniture					
A. Unità di alimentazione della carta 1	B. Perno 2	C. Fermo 1	D. Unità intermediale di trasporto carta 1	F. Coperchio cavi 1	G. Piastra formato carta 4
H. Vite S Tite M4 × 8 3	I. Piastra tipo carta 12	J. Fermo 2	K. Vite S Tite M4 × 20 4		
简体中文		E. 夹钳 1		K. 紧固型 S 螺丝 M4 × 20 4	
附属品					
A. 供纸工作台 1	B. 固定插销 2	C. 安装板 1	D. 中间搬运单元 1	F. 电线盖板 1	G. 纸张尺寸标示 4
H. 紧固型 S 螺丝 M4 × 8 3	I. 纸张种类标示 2	J. 限位器 2	如果附属品上带有固定胶带, 缓冲材料时务必揭下。		
한국어		E. 크램프 1		K. 나사 M4×20 S 타이트 4	
동봉품					
A. 급지대 1	B. 핀 2	C. 부착판 1	D. 중간반송유닛 1	F. 전선커버 1	G. 용지크기 플레이트 4
H. 나사 M4×8S 타이트 3	I. 용지종류 플레이트 2	J. 전도방지쇠 2	동봉품에 고정 테이프, 완충재가 붙어 있는 경우에는 반드시 제거할 것 .		
日本語		E. クランプ 1		同梱品に固定テープ、緩衝材が付いている場合は必ず取り外すこと。	
同梱品					
A. ペーパーフィーダー 1	B. ピン 2	C. 取付板 1	D. 中間搬送ユニット 1	F. 電線カバー 1	G. 用紙サイズプレート 4
H. ビス M4×8S タイト 3	I. 用紙種類プレート 2	J. 転倒防止金具 2	K. ビス M4×20 S タイト 4		



Procedure

Be sure to turn the MFP main power switch off and disconnect the MFP power plug from the wall outlet before starting to install the paper feeder.

1. Pull out the right cassette (1) and left cassette (2), remove each of the lift plate stoppers (3) and attach them in the storage location.
2. Gently close each cassette.

3. Remove the lower paper cassette (4) from the MFP
4. Remove the pin (5) and remove the lower paper cassette (4) in the MFP.

Procédure

Veiller à bien mettre l'interrupteur principal du MFP hors tension et à débrancher la fiche d'alimentation du MFP de la prise murale avant de commencer l'installation du bureau papier.

1. Sortir le tiroir droit (1) et le tiroir gauche (2), déposer toutes les butées du plateau de levage (3) et les ranger soigneusement.
2. Refermer progressivement chaque tiroir.

3. Retirer le tiroir inférieur (4) du MFP.
4. Déposer la broche (5) et le tiroir à papier inférieur (4) du MFP.

Procedimiento

Asegúrese de apagar el interruptor principal del MFP y de desconectar el enchufe del MFP del receptáculo de pared antes de empezar a instalar el alimentador de papel.

1. Extraiga el cajón derecho (1) y el cajón izquierdo (2), quite cada uno de los topes de placa de elevación (3) y fíjelos en el lugar de almacenamiento.
2. Cierre suavemente cada bandeja.

3. Quite el cajón de papel inferior (4) del MFP.
4. Quite el clavija (5) y el cajón de papel inferior (4) del MFP.

Verfahren

Schalten Sie unbedingt den Hauptschalter des MFP aus, und ziehen Sie den Netzstecker des MFP von der Netzsteckdose ab, bevor Sie mit der Installation des Papiereinzugs beginnen.

1. Die rechte Papierlade (1) und die linke Papierlade (2) herausziehen, jeden der Hebeplattenanschlätze (3) entfernen und in der vorgesehenen Position verstauen.
2. Alle Kassetten sanft schließen.

3. Nehmen Sie die untere Papierlade (4) vom MFP ab.
4. Die Stift (5) entfernen und die untere Papierlade (4) im MFP abnehmen.

Procedura

Prima di dare inizio alla procedura di installazione dell'unità di alimentazione della carta, non mancare di spegnere l'MFP usando l'interruttore principale di alimentazione e di disinserire la spina del cavo di alimentazione dalla presa a muro della rete elettrica.

1. Estrarre il cassetto destro (1) e il cassetto sinistro (2), rimuovere ciascuno dei fermi (3) della piastra di sollevamento ed applicarli nella posizione di conservazione.
2. Chiudere delicatamente ciascun cassetto.

3. Rimuovere il cassetto inferiore della carta (4) dall'MFP.
4. Rimuovere la perno (5) e quindi rimuovere il cassetto inferiore della carta (4) nell'MFP.

安装步骤

安装供纸工作台时，必须先关闭 MFP 主机上的主电源开关，并拔出电源插头后方可进行工作。

1. 拉出右侧供纸盒 (1) 以及左侧供纸盒 (2)，拆下各 1 个升降板挡块 (3)，并安装在保管场所上。
2. 轻轻地推入各供纸盒。

3. 取出 MFP 主机的下部供纸盒 (4)。
4. 拆除 1 颗固定插销 (5)，取出 MFP 主机的下部供纸盒 (4)。

설치순서

급지대를 설치할 때에는 반드시 MFP 본체의 주 전원 스위치를 OFF 로 하고 MFP 본체 전원 플러그를 빼고 작업을 할 것 .

1. 카세트 오른쪽 (1) 및 카세트 왼쪽 (2) 을 꺼내어 리프트판 스톱퍼 (3) 각 1 개를 제거하고 보관장소에 부착합니다 .
2. 각 카세트를 조용히 밀어 넣습니다 .


3. MFP 본체의 하단 카세트 (4) 를 꺼냅니다 .
4. 핀 (5) 1 개를 제거하고 MFP 본체 하단 카세트 (4) 를 꺼냅니다 .

取付手順


ペーパーフィーダーを取り付ける際は、必ず MFP 本体の主電源スイッチを OFF にし、MFP 本体の電源プラグを抜いてから作業をおこなうこと。

1. カセット右 (1) およびカセット左 (2) を引き出し、リフト板ストッパー (3) 各 1 個を取り外し、保管場所に取り付ける。
2. 各カセットを静かに押し込む。


3. MFP 本体の下段カセット (4) を引き出す。
4. ピン (5) 1 本を外し、MFP 本体の下段カセット (4) を取り外す。



5. Place the MFP (8) on the paper feeder (A) so that the pins (6) at the front left and front right of the paper feeder (A) are aligned with the holes (7) in the base of the MFP.



6. Secure the MFP (8) to the paper feeder (A) with the 2 pins (B).



7. Pull out the lower paper cassette rail (9) in the MFP.
8. Fit the hook (10) on the rail (9) into the hole (11) in the lower paper cassette (4) and replace the lower paper cassette (4).
9. Secure the lower paper cassette (4) using the pin (5) removed in step 4.

5. Monter le MFP (8) sur le bureau papier (A) de sorte que les ergots (6) à l'avant gauche et à l'avant droit du bureau papier (A) soient alignés avec les trous (7) dans la base du MFP.

6. Fixer le MFP (8) au bureau papier (A) avec les 2 broches filetées (B).

7. Extraire la glissière du tiroir à papier inférieur (9) dans le MFP.
8. Insérer le crochet (10) de la glissière (9) dans le trou (11) du tiroir à papier inférieur (4) et reposer le tiroir à papier inférieur (4).
9. Fixer le tiroir à papier inférieur (4) à l'aide de la broche (5) déposée à l'étape 4.

5. Coloque el MFP (8) sobre el alimentador de papel (A) de forma tal que los pasadores (6) en los lados frontales izquierdo y derecho del alimentador de papel (A) estén alineados con los orificios (7) de la base del MFP.

6. Asegure el MFP (8) al alimentador de papel (A) con los 2 pasadores (B).

7. Extraiga el carril del cajón de papel inferior (9) del MFP.
8. Encaje el gancho (10) del carril (9) en el orificio (11) del cajón de papel inferior (4) y vuelva a colocar el cajón de papel inferior (4).
9. Asegure el cajón de papel inferior (4) usando el clavija (5) quitado en el paso 4.

5. Den MFP (8) so auf den Papiereinzug (A) setzen, dass die Stifte (6) vorne links und vorne rechts am Papiereinzug (A) auf die Öffnungen (7) im Boden des MFP ausgerichtet sind.

6. Den MFP (8) mit den 2 Stiften (B) am Papiereinzug (A) sichern.

7. Die Schiene (9) der unteren Papierlade im MFP herausziehen.
8. Den Haken (10) auf der Schiene (9) in die Öffnung (11) der unteren Papierlade (4) einpassen und die untere Papierlade (4) wieder einsetzen.
9. Die untere Papierlade (4) mit der in Schritt 4 entfernten Stift (5) befestigen.

5. Posizionare l'MFP (8) sull'unità di alimentazione della carta (A), in modo che i perni (6) alla parte frontale destra e sinistra dell'unità di alimentazione della carta (A) siano allineati con i fori (7) nella base dell'MFP.

6. Fissare l'MFP (8) all'unità di alimentazione della carta (A) con i 2 perni (B).

7. Estrarre la rotaia (9) del cassetto inferiore della carta nell'MFP.
8. Inserire il gancio (10) sulla rotaia (9) nel foro (11) nel cassetto inferiore della carta (4) e ricollocare il cassetto inferiore della carta (4).
9. Fissare il cassetto inferiore della carta (4) utilizzando la perno (5) rimossa nel passo 4.

5. 供紙盒 (A) の左右前面的各挿銷 (6) 分別對準 MFP 主機底面的孔 (7) 后, 將 MFP 主機 (8) 放在供紙盒 (A) 上

6. 用 2 個固定插銷 (B) 將 MFP 主機 (8) 固定在供紙盒 (A) 上。

7. 拉出 MFP 主机的下部供紙盒 (9) 导轨。
8. 将导轨 (9) 的卡扣 (10) 嵌入下部供紙盒 (4) 的孔 (11) 中, 按原样安装下部供紙盒 (4)
9. 使用步骤 4 中取下的 1 顆固定插銷 (5) 來固定下部供紙盒 (4)

5. 금지대 (A) 의 좌우 전방의 각 핀 (6) 과 MFP 본체의 베이스 구멍 (7) 이 맞도록 금지대 (A) 에 MFP 본체 (8) 를 놓습니다 .


6. 핀 (B) 2 개로 MFP 본체 (8) 를 금지대 (A) 에 고정합니다 .

7. MFP 본체의 하단 카세트 레일 (9) 을 꺼냅니다 .
8. 레일 (9) 후크 (10) 를 하단 카세트 (4) 구멍 (11) 에 꽂습니다 . 하단 카세트 (4) 를 원래 대로 장착합니다 .
9. 순서 4 에서 제거한 핀 (5) 1 개로 하단 카세트 (4) 를 고정합니다 .


5. ペーパーフィーダー(A) の左右前方の各ピン (6) と MFP 本体のベースの穴 (7) が合うように、ペーパーフィーダー(A) に MFP 本体 (8) を載せる。

6. ピン (B) 2 本で MFP 本体 (8) をペーパーフィーダー(A) に固定する。


7. MFP 本体の下段カセットレール (9) を引き出す。
8. レール (9) のフック (10) を下段カセット (4) の穴 (11) にはめ込み、下段カセット (4) を元通り取り付ける。
9. 手順 4 で外したピン (5) 1 本で下段カセット (4) を固定する。



10. Remove the screw (12) in the rear of the paper feeder and remove the cover (13).



11. Remove the screw (14) to remove the metal plate (15).



12. Fit the hook (16) on the mounting plate (C) into the opening (17) and then align the 2 positioning projections.

13. Secure the mounting plate (C) with the screw (H).

10. Déposer la vis (12) à l'arrière du bureau papier et déposer le couvercle (13).

11. Déposer la vis (14) pour enlever la plaque métallique (15).

12. Insérer le crochet (16) du plateau de montage (C) dans l'ouverture (17) et aligner les 2 saillies de positionnement.

13. Fixer le plateau de montage (C) avec la vis (H).

10. Quite el tornillo (12) del lado trasero del alimentador de papel y quite la cubierta (13).

11. Quite el tornillo (14) para desmontar la placa de metal (15).

12. Coloque el gancho (16) de la placa de montaje (C) en la abertura (17) y, después, alinee los 2 resaltes de posición.

13. Asegure la placa de montaje (C) con el tornillo (H).

10. Die Schraube (12) an der Rückseite des Papiereinzugs entfernen und die Abdeckung (13) abnehmen.

11. Die Schraube (14) herausdrehen, um die Metallplatte (15) abzunehmen.

12. Den Haken (16) auf der Montageplatte (C) in die Öffnung (17) einpassen und dann die 2 Positionierungsnasen ausrichten.

13. Die Montageplatte (C) mit der Schraube (H) befestigen.

10. Rimuovere la vite (12) nel retro dell'unità di alimentazione della carta e quindi rimuovere il coperchio (13).

11. Rimuovere la vite (14), per rimuovere la piastra di metallo (15).

12. Inserire il gancio (16) sulla piastra di montaggio (C) nell'apertura (17) e quindi allineare le 2 sporgenze di posizionamento.

13. Fissare la piastra di montaggio (C) con la vite (H).

10. 拆除供紙盒后部的 1 顆螺絲 (12)，拆下盖板 (13)。

11. 拆除 1 顆螺絲 (14)，拆下金屬件 (15)。

12. 將安裝板 (C) 的卡扣 (16) 挂在開口部 (17) 上，並與定位用的 2 處突出部對齊。

13. 使用 1 顆螺絲 (H) 來固定安裝板 (C)。

10. 금지대 후면의 뒤쪽 나사 (12) 1 개를 제거하고 커버 (13) 를 떼어 냅니다 .

11. 나사 (14) 1 개를 제거하고 쇠 (15) 를 제거합니다 .

12. 부착판 (C) 의 후크 (16) 를 개구부 (17) 에 걸고 위치조정 돌기 2 곳을 맞춥니다 .


13. 나사 (H) 1 개로 부착판 (C) 을 고정합니다 .

10. ペーパーフィーダー後側のビス (12) 1 本を外し、カバー (13) を取り外す。


11. ビス (14) 1 本を外し、金具 (15) を取り外す。

12. 取付板 (C) のフック (16) を開口部 (17) に引っ掛けてから、位置決め突起 2箇所を合わせる。

13. ビス (H) 1 本で取付板 (C) を固定する。




14. Pass the power cord (18) through the edging (small) (19) and the signal cable (20) through the edging (large) (21) and then close the edging



15. Connect the power cord (22) and the signal cable (23) to connectors (24) (25) respectively on the MFP.

16. Replace the cover (13) using the screw (12) removed in step 10.



17. Open the lower right cover (26) on the MFP. Remove the strap (27) from the shaft (28) and remove lower right cover (26).

14. Faire passer le cordon d'alimentation (18) dans le (petit) passage (19) et le câble du signal (20) dans le (grand) passage (21) puis fermer le passage.

15. Raccorder respectivement le cordon d'alimentation (22) et le câble à signal (23) aux connecteurs (24) (25) du MFP.

16. Reposer le couvercle (13) à l'aide de la vis (12) déposée à l'étape 10.

17. Ouvrir le couvercle inférieur droit (26) du MFP. Déposer la courroie (27) de l'arbre (28) et déposer le couvercle inférieur droit (26).

14. Pase el cable de alimentación (18) a través de la pestaña (pequeña) (19) y el cable de señales (20) a través de la pestaña (grande) (21) y, después, cierre la pestaña.

15. Conecte el cable de alimentación (22) y el cable de señales (23) a los conectores (24) (25) del MFP, respectivamente.

16. Vuelva a colocar la cubierta (13) usando el tornillo (12) quitado en el paso 10.

17. Abra la cubierta frontal inferior (26) del MFP. Quite la correa (27) del eje (28) y quite la cubierta frontal inferior (26).

14. Das Netzkabel (18) durch den Kantenschutz (klein) (19) und das Signalkabel (20) durch den Kantenschutz (groß) (21) führen und dann den Kantenschutz schließen.

15. Das Netzkabel (22) und das Signalkabel (23) an den entsprechenden Steckverbindern (24) (25) des MFP anschließen.

16. Die Abdeckung (13) mittels der in Schritt 10 entfernten Schraube (12) wieder anbringen.

17. Die untere rechte Abdeckung (26) am MFP öffnen. Den Riemen (27) von der Welle (28) abnehmen und dann die untere rechte Abdeckung (26) abnehmen.

14. Passare il cavo di alimentazione (18) attraverso il bordo (piccolo) (19) e il cavo del segnale (20) attraverso il bordo (grande) (21), e quindi chiudere il bordo.

15. Collegare il cavo di alimentazione (22) e il cavo del segnale (23) rispettivamente ai connettori (24) e (25) sull'MFP.

16. Ricollocare il coperchio (13) utilizzando la vite (12) rimossa nel passo 10.

17. Aprire il pannello destro inferiore (26) sull'MFP. Rimuovere la cinghietta (27) dall'asta (28) e quindi rimuovere il pannello destro inferiore (26).

14. 将 AC 电线 (18) 从包边孔 (小) (19), 信号线 (20) 从包边孔 (大) (21) 中分别穿过, 关闭包边孔。

15. 将 AC 电线 (22) 以及信号线 (23) 分别与主机的接插件 (24)、(25) 连接。

16. 使用在步骤 10 中拆除的 1 颗螺丝 (12) 按原样安装盖板 (13)。

17. 打开 MFP 主机的右下部盖板 (26)。将带子 (27) 从轴 (28) 上拆除, 拆下右下部盖板 (26)。

14. AC 전선 (18) 을 에징 (소) (19) 에, 신호선 (20) 을 에징 (대) (21) 에 각각 지나가게 하고 에징을 닫습니다.

15. AC 전선 (22) 및 신호선 (23) 을 본체 커넥터 (24), (25) 에 각각 접속합니다.

16. 순서 10 에서 제거한 나사 (12) 1 개로 커버 (13) 를 원래대로 부착합니다.


17. MFP 본체의 오른쪽 아래 커버 (26) 를 엽니다. 스트랩 (27) 를 축 (28) 에서 떼어내 오른쪽 아래 커버 (26) 를 제거합니다.

14. AC 電線 (18) をエッジング(小) (19) に、信号線 (20) をエッジング(大) (21) にそれぞれ通し、エッジングを閉じる。


15. AC 電線 (22) および信号線 (23) を本体のコネクター(24)、(25) にそれぞれ接続する。

16. 手順 10 で取り外したビス (12) 1 本でカバー (13) を元通りに取り付ける。

17. MFP 本体の右下カバー (26) を開く。ストラップ (27) を軸 (28) から外し、右下カバー (26) を取り外す。



18. Open the paper feeder right cover (29).



19. Fit the 3 hooks (30) on the intermediate paper conveying unit (D) into the 3 holes (31) in the guide.
20. Secure the intermediate paper conveying unit (D) with the 2 screws (H).

18. Ouvrir le couvercle droit du bureau papier (29).

19. Insérer les 3 crochets (30) de l'unité de transport du papier intermédiaire (D) dans les 3 trous (31) du guide.
20. Fixer l'unité de transport du papier intermédiaire (D) à l'aide des 2 vis (H).

18. Abra la cubierta derecha del alimentador de papel (29).

19. Coloque los 3 ganchos (30) de la unidad de transporte de papel intermedia (D) en los 3 orificios (31) de la guía.
20. Asegure la unidad de transporte de papel intermedia (D) con los 2 tornillos (H).

18. Die rechte Abdeckung (29) des Papiereinzugs öffnen.

19. Die 3 Haken (30) an der eingesetzten Papierfördereinheit (D) in die 3 Öffnungen (31) in der Führung einpassen.
20. Die eingesetzte Papierfördereinheit (D) mit den 2 Schrauben (H) sichern.

18. Aprire il pannello destro (29) dell'unità di alimentazione della carta.

19. Inserire i 3 ganci (30) sull'unità intermediale di trasporto carta (D) nei 3 fori (31) nella guida.
20. Fissare l'unità intermediale di trasporto carta (D) con le 2 viti (H).

18. 打开供纸盒的右部盖板 (29)。


19. 将中间搬运单元 (D) 的 3 个卡扣 (30) 嵌入导向板的 3 个孔 (31) 中。
20. 使用 2 颗螺丝 (H) 来固定中间搬运单元 (D)。

18. 금지대 오른쪽 커버 (29) 를 엽니다 .


19. 중간반송유닛 (D) 의 후크 (30) 3 개를 가이드 구멍 (31) 3 곳에 꽂습니다 .
20. 나사 (H) 2 개로 중간반송유닛 (D) 를 고정합니다 .

18. ペーパーフィーダーの右カバー(29)を開く。


19. 中間搬送ユニット (D) のフック (30) 3 個をガイドの穴 (31) 3 カ所にはめ込む。
20. ビス (H) 2 本で中間搬送ユニット (D) を固定する。



21. Connect the intermediate paper conveying unit connector (32).
 22. Attach the clamp (E) and secure the connector wire.



23. Insert the projection (33) on the wire cover (F) into the hole (34) in the paper feeder and install the wire cover (F).
 24. Close the paper feeder right cover (29) and replace the lower right cover (26) on the MFP.



25. Turn the adjusters on each corner (35) until they reach the floor and then secure the paper feeder.

21. Raccorder le connecteur (32) de l'unité de transport du papier intermédiaire.
 22. Monter le collier (E) et fixer le câble du connecteur.

23. Insérer la saillie (33) du couvercle du câble (F) dans le trou (34) du bureau papier et reposer le couvercle du câble (F).
 24. Fermer le couvercle droit du bureau papier (29) et reposer le couvercle inférieur droit (26) sur le MFP.

25. Faire tourner les dispositifs de réglage de chacun des coins (35) jusqu'à ce qu'ils touchent le sol et fixer ensuite le bureau papier.

21. Conecte el conector de la unidad de transporte de papel intermedia (32).
 22. Fije el sujetador (E) y asegure el cable del conector.

23. Inserte el resalto (33) de la cubierta para el cable (F) en el orificio (34) del alimentador de papel e instale la cubierta para el cable (F).
 24. Cierre la cubierta derecha del alimentador de papel (29) y vuelva a colocar la cubierta derecha inferior (26) en el MFP.

25. Gire los reguladores en cada esquina (35) hasta que lleguen al piso y, a continuación, asegure el alimentador de papel.

21. Den Steckverbinder (32) der eingesetzten Papierfördereinheit anschließen.
 22. Die Klemme (E) anbringen und das Kabel des Steckverbinders sichern.

23. Die Nase (33) der Kabelabdeckung (F) in die Öffnung (34) des Papiereinzugs einsetzen und die Kabelabdeckung (F) anbringen.
 24. Die rechte Abdeckung (29) des Papiereinzugs schließen und die untere rechte Abdeckung (26) wieder am MFP einsetzen.

25. Die Einsteller an jeder Ecke (35) drehen, bis sie den Boden berühren, und dann den Papiereinzug sichern.

21. Collegare il connettore (32) dell'unità intermediale di trasporto carta.
 22. Applicare il morsetto (E) e fissare il cavo del connettore.

23. Inserire la sporgenza (33) del coperchio cavi (F) nel foro (34) nell'unità di alimentazione della carta ed installare il coperchio cavi (F).
 24. Chiudere il pannello destro (29) dell'unità di alimentazione della carta e ricollocare il pannello destro inferiore (26) sull'MFP.

25. Ruotare i regolatori (35) presenti su ciascun angolo finché vengano a contatto con il pavimento, e quindi fissare l'unità di alimentazione della carta.

21. 连接中间搬运单元的接插件 (32)。
 22. 安装夹钳 (E)，以固定接插件电线。

23. 将电线盖板 (F) 的突出部 (33) 插入供纸盒的孔 (34) 中，安装电线盖板 (F)。
 24. 关闭供纸盒的右部盖板 (29)，按原样安装 MFP 主机的右下盖板 (26)。

25. 转动四角上的调节器 (35) 直至与地面接触，然后再固定供纸盒。

21. 중간반송유닛의 커넥터 (32) 를 접속합니다.
 22. 클램프 (E) 를 부착, 커넥터 전선을 고정합니다.


23. 전선커버 (F) 의 돌기 (33) 를 급지대의 구멍 (34) 에 넣고 전선커버 (F) 를 부착합니다.
 24. 급지대 오른쪽 커버 (29) 를 닫고, MFP 본체의 오른쪽 아래 커버 (26) 를 원래대로 부착합니다.

25. 네 곳의 어저스터 (35) 를 맨 밑에 닿을 위치까지 돌려 급지대를 고정합니다.

21. 中間搬送ユニットのコネクター(32) を接続する。
 22. クランプ (E) を取り付け、コネクター電線を固定する。

23. 電線カバー (F) の突起 (33) をペーパーフィーダーの穴 (34) に入れて、電線カバー (F) を取り付ける。
 24. ペーパーフィーダーの右カバー (29) を閉じ、MFP 本体の右下カバー (26) を元通りに取り付け。

25. 四隅のアジャスター(35) を床に接触する位置まで回し、ペーパーフィーダーを固定する。



26. Select holes (49) and install each stopper (J) with 2 S Tite screws M4 × 20 (K) so that the stoppers will be grounded on the floor.

26. Sélectionner les trous (49) et installer chaque butée (J) avec 2 vis S Tite M4 × 20 (K) de sorte que les butées reposent sur le sol.

26. Seleccione los orificios (49) e instale cada tope (J) con los 2 tornillos S Tite M4 × 20 (K) de manera que los topes se conecten a tierra en el suelo.


26. Wählen Sie die Öffnungen (49) und befestigen Sie jeden Anschlag (J) mit den 2 S-Tite-Schrauben M4 × 20 (K) so an, dass die Anschläge am Boden aufsitzen.

26. Selezionare i fori (49) ed installare ogni fermo (J) con le 2 viti S Tite M4 × 20 (K) in modo che i fermi siano posti a terra sul pavimento.

26. 在孔(49)处各用2颗M4×20紧固型S螺丝(K)安装限位器(J),使之和地板接触。


26. 전도방지쇠(J)가 바닥면에 접지될 수 있도록 구멍(49)을 선택해 나사 M4×20 S 타이트(K) 각 2개로 설치합니다.

26. 転倒防止金具(J)が床面に接地するように、穴(49)を選択してビス M4×20 S タイト(K) 各2本で取り付けます。



Setting the paper size plate and media type plate

Insert the paper size plate (G) and media type plate (I) into the each slots respectively.



1. Pull out the cassette of the paper feeder.
2. Turn the front lock lever (36) 90° and remove the front deck cursor (37).

Disposition des plaquettes du format de papier et du type de support

Introduire la plaquette du format de papier (G) et la plaquette du type de support (I) dans leur logement respectif.

Modification du format du papier (pour spécifications métriques seulement)

À expédition, les modèles à mesure en pouces sont réglés sur le format Letter et les modèles à mesure métrique sur le format A4. Pour passer au format B5, procéder de la manière suivante.

1. Tirer le magasin du bureau papier vers soi.
2. Faire tourner le levier de verrouillage avant (36) de 90° et déposer le curseur de platine avant (37).

Ajuste de la placa de tamaño de papel y la placa de tipo de medio

Insere la placa de tamaño de papel (G) y la placa de tipo de medio (I) en cada uno de las ranuras, respectivamente.

Cómo cambiar el tamaño de papel (sólo para las especificaciones métricas)

En el momento de salida de fábrica, se configura Carta para los modelos en pulgadas y A4 para los modelos en sistema métrico. Siga este procedimiento para cambiar el tamaño a B5.

1. Abra el casete del alimentador de papel.
2. Gire la palanca de bloqueo frontal (36) 90° y quite el cursor frontal de la plataforma (37).

Einsetzen der Papierformatkarte und der Medientypkarte

Setzen Sie die Papierformatkarte (G) und die Medientypkarte (I) in die jeweiligen Führungen.

Ändern des Papierformats (nur metrische Spezifikationen)

Beim Werksversand ist bei Modellen mit Zollmaß das Format Letter voreingestellt und bei Modellen mit metrischem Maß das Format A4. Das Format kann wie folgend auf B5 umgeschaltet werden.

1. Ziehen Sie die Papierlade aus dem Papiereinzug.
2. Den vorderen Verriegelungshebel (36) um 90° drehen und den vorderen Konsole-Cursor (37) abnehmen.

Impostazione della piastra di formato carta e della piastra del tipo di supporto

Inserire la piastra del formato carta (G) e la piastra del tipo di supporto (I) nei rispettivi alloggiamenti.

Cambio del formato della carta (solo per le specifiche metriche)

Al momento della spedizione, Letter è impostato per le specifiche in pollici e A4 è impostato per le specifiche metriche. Usare la procedura riportata sotto per cambiare il formato a B5.

1. Estrarre il cassetto dell'unità di alimentatore della carta.
2. Ruotare la leva frontale di blocco (36) di 90° e rimuovere il cursore frontale del deck (37).

纸张尺寸标示和纸张种类标示的安装

将纸张尺寸标示 (G) 和纸张种类标示 (I) 分别插入到图示的插槽中。

纸张尺寸更改 (仅限公制规格)

产品出厂时, 英制规格设定为 Letter、公制规格设定为 A4。要将尺寸更改为 B5 时, 请按以下步骤进行操作。

1. 拉出供纸工作台的供纸盒。
2. 将前部锁定杆 (36) 旋转 90°, 拆下堆纸板前部游标 (37)。

용지크기 플레이트와 용지종류 플레이트의 세트
용지크기 플레이트 (G) 와 용지종류 플레이트 (I) 를 각 표시 슬롯에 각각 삽입한다.

용지크기 변경 (센치 사양만)

출하시, 인치사양은 Letter, 센치사양은 A4 로 설정되어 있습니다. 크기를 B5 로 변경하는 경우에는 다음 순서를 진행해 주십시오.


1. 금지대 카세트를 빼 냅니다.
2. 잠금레버 앞 (36) 을 90° 회전시켜 데스크커서 앞 (37) 을 제거합니다.

用紙サイズプレートと用紙種類プレートのセット
用紙サイズプレート (G) と用紙種類プレート (I) を各表示スロットにそれぞれ挿入する。


用紙サイズ変更(センチ仕様のみ)

出荷時、インチ仕様は Letter、センチ仕様は A4 に設定されています。サイズを B5 に変更する場合は次の手順をおこなってください。

1. ペーパーフィーダーのカセットを引き出す。
2. ロックレバー前 (36) を 90° 回転させ、デッキカーソル前 (37) を取り外す。



3. Move the front deck cursor (37) so that it is aligned with the size indicators on the top (39) and bottom (38) of the cassette.
4. Turn the front lock lever (36) 90° to lock it.
5. Move the rear deck cursor (40) in the same way.



6. Release the hook (41) and remove the deck trailing edge cursor (42).

3. Déplacer le curseur de platine avant (37) de sorte qu'il soit aligné avec les indicateurs de format en haut (39) et en bas (38) du tiroir.
4. Faire tourner le levier de verrouillage avant (36) de 90° pour le verrouiller.
5. Déplacer le curseur de platine arrière (40) en procédant de la même manière.

6. Libérer le crochet (41) et déposer le curseur du bord arrière de la platine (42).

3. Mueva el cursor frontal de la plataforma (37) para que quede alineado con las indicadores de tamaño de la parte superior (39) e inferior (38) del cajón.
4. Gire la palanca de bloqueo frontal (36) 90° para bloquearla.
5. Mueva el cursor trasero de la plataforma (40) de la misma forma.

6. Libere el gancho (41) y quite el cursor del borde inferior de la plataforma (42).

3. Den vorderen Konsole-Cursor (37) so verschieben, dass er mit den Formatanzeigen oben (39) und unten (38) an der Kassette fluchtet.
4. Den vorderen Verriegelungshebel (36) zum Verriegeln um 90° drehen.
5. Den hinteren Konsole-Cursor (40) auf gleiche Weise verschieben.

6. Den Haken (41) lösen und den Hinterkante-Cursor (42) der Konsole abnehmen.

3. Spostare il cursore frontale del deck (37) in modo che esso risulti allineato con gli indicatori di formato sulla parte superiore (39) e inferiore (38) del cassetto.
4. Ruotare la leva frontale di blocco (36) di 90°, per bloccarla.
5. Spostare il cursore posteriore del deck (40) allo stesso modo.

6. Rilasciare il gancio (41) e rimuovere il cursore del bordo di uscita del deck (42).

3. 移动堆纸板前部游标 (37), 使供纸盒下部的尺寸标记 (38) 与供纸盒上部的尺寸标记 (39) 对齐。
4. 将前部锁定杆 (36) 旋转 90° 以固定。
5. 按同样方式移动后部堆纸板后部游标 (40)。


6. 解除卡扣 (41), 拆下堆纸板后部游标 (42)。

3. 카세트 밑의 크기표시 (38) 와 카세트 위의 크기 표시 (39) 에 맞춰 데크커서 앞 (37) 을 이동시킵니다 .
4. 잠금레버 앞 (36) 을 90° 회전시켜 고정합니다 .
5. 똑같이 데크커서 뒤 (40) 를 이동시킵니다 .


6. 후크 (41) 를 해제하고 데크 뒷단커서 (42) 를 제거합니다 .

3. カセット下のサイズ表示 (38) とカセット上のサイズ表示 (39) に合わせてデッキカーソル前 (37) を移動させる。
4. ロックレバー前 (36) を 90° 回転させ固定する。
5. 同様にデッキカーソル後 (40) を移動させる。

6. フック (41) を解除し、デッキ後端カーソル (42) を取り外す。



7. Lift up the sub-cursor (43).
8. Align with the size indicator (44), engage the hook (45) and install the deck trailing edge cursor (42).



Adjusting the cursor width

1. Load paper in the cassettes.
2. If the gap between the front deck cursor (37) and the paper (46) is outside the 0.5 to 1.5 mm range when the paper (46) is touching up against the rear deck cursor (40), perform the following adjustment.
 - * A cursor width that is too small can hinder paper feeding, while a cursor width that is too large can lead to problems such as skewed paper feed.

7. Lever le curseur secondaire (43).
8. Aligner avec l'indicateur de format (44), engager le crochet (45) et reposer le curseur du bord arrière de la platine (42).

Réglage de la largeur du curseur

1. Charger les tiroirs en papier.
2. Si l'écartement entre le curseur de platine avant (37) et le papier (46) est hors des limites de 0,5 à 1,5 mm quand le papier (46) touche le curseur de platine arrière (40), procéder au réglage suivant.
 - * Une largeur trop faible du curseur risque d'empêcher l'entraînement du papier et une largeur trop grande risque d'entraîner des problèmes du type entraînement du papier de biais.

7. Levante el cursor secundario (43).
8. Alinee con el indicador de tamaño (44), enganche el gancho (45) e instale el cursor del borde inferior de la plataforma. (42).

Cómo ajustar la anchura del cursor

1. Cargue papel en los cajones.
2. Si la separación entre el cursor frontal de la plataforma (37) y el papel (46) está fuera del rango de 0,5 a 1,5 mm cuando el papel (46) toca el cursor trasero de la plataforma (40), haga el siguiente ajuste.
 - * Una anchura del cursor demasiado pequeña puede impedir la alimentación de papel; una anchura del cursor demasiado grande puede provocar problemas con la alimentación torcida de papel.

7. Den Unter-Cursor (43) anheben.
8. Auf die Formatanzeige (44) ausrichten, den Haken (45) einsetzen und den Hinterkante-Cursor (42) der Konsole anbringen.

Einstellen der Cursor-Breite

1. Papier in die Papierladen einlegen.
2. Falls der Abstand zwischen dem vorderen Konsole-Cursor (37) und dem Papier (46) außerhalb des Bereichs 0,5 bis 1,5 mm liegt, wenn das Papier (46) am hinteren Konsole-Cursor (40) anliegt, ist folgende Einstellung vorzunehmen.
 - * Eine zu kleine Cursor-Breite kann den Papiereinzug behindern, wogegen eine zu große Cursor-Breite verkanteten Papiereinzug und ähnliche Probleme verursachen kann.

7. Sollevare il cursore secondario (43).
8. Allineare con l'indicatore formato (44), fissare il gancio (45) e installare il cursore del bordo di uscita del deck (42).

Regolazione della larghezza del cursore

1. Caricare carta nei cassetti.
2. Se lo spazio tra il cursore frontale del deck (37) e la carta (46) è fuori della gamma da 0,5 a 1,5 mm quando la carta (46) tocca il cursore posteriore del deck (40), eseguire la regolazione seguente.
 - * Una larghezza dei cursori troppo piccola può ostacolare l'alimentazione della carta, mentre un'alarghezza dei cursori troppo grande può essere causa di problemi, come ad esempio l'alimentazione obliqua della carta.

7. 抬起副游标 (43)。
8. 对齐尺寸标记 (44)，将卡扣 (45) 嵌入以安装堆纸板后部游标 (42)。

游标宽度的调节

1. 在供纸盒中装入纸张。
2. 在堆纸板后部游标 (40) 与纸张 (46) 接触的状态下，如果堆纸板前部游标 (37) 与纸张 (46) 的间隙超出了 0.5 ~ 1.5mm 的范围，须进行以下调节。
 - ※ 如果游标宽度过小，可能造成不供纸，游标宽度过大，则可能发生歪斜进纸等情况。

7. 서브커서 (43) 를 세웁니다 .
8. 크기표시 (44) 에 맞춰 후크 (45) 를 판백데크 후단커서 (42) 를 부착합니다 .


커서 폭 조정

1. 카세트에 용지를 장착합니다 .
2. 데크커서 뒤 (40) 에 용지 (46) 가 접하고 있는 상태에서 데크커서 앞 (37) 과 용지 (46) 의 틈이 0.5 ~ 1.5mm 의 범위외의 경우에는 이하의 조정을 합니다 .
 - ※ 커서 폭이 작으면 무급지, 커서 폭이 크면 경사급지 등이 발생할 가능성이 있습니다 .

7. サブカーソル (43) を起こす。
8. サイズ表示 (44) に合わせて、フック (45) をはめデッキ後端カーソル (42) を取り付ける。

カーソル幅の調整

1. カセットに用紙をセットする。
2. デッキカーソル後 (40) に用紙 (46) が接している状態で、デッキカーソル前 (37) と用紙 (46) の隙間が 0.5 ~ 1.5mm の範囲外の場合は、以下の調整をおこなう。
 - ※ カーソル幅が小さいと無給紙、カーソル幅が大きいと斜め給紙などが発生する可能性がある。



3. Insert a Philips-head screwdriver into the 2 long slots (47) in the front deck cursor (37) and loosen the 2 adjusting screws (48). Then move the front deck cursor (37).

4. Retighten the 2 adjusting screws (48).
5. Check that the gap between the front deck cursor (37) and the paper is between 0.5 and 1.5 mm.

3. Insérer un tournevis cruciforme dans les 2 longues fentes (47) du curseur de platine avant (37) et desserrer les 2 vis de réglage (48). Déplacer ensuite le curseur de platine avant (37).

4. Resserrer les 2 vis de réglage (48).
5. Vérifier que l'écartement entre le curseur de platine avant (37) et le papier est entre 0,5 et 1,5 mm.

3. Inserte un destornillador de cabeza Philips en las dos ranuras largas (47) en el cursor frontal de la plataforma (37) y afloje los 2 tornillos de ajuste (48). Después, mueva el cursor frontal de la plataforma (37).

4. Vuelva a apretar los 2 tornillos de ajuste (48).
5. Verifique que la separación entre el cursor frontal de la plataforma (37) y el papel sea de entre 0,5 y 1,5 mm.

3. Einen Kreuzschlitzschraubendreher in die 2 langen Öffnungen (47) im vorderen Konsole-Cursor (37) stecken und die 2 Einstellschrauben (48) lösen. Danach den vorderen Konsole-Cursor (37) verschieben.

4. Die 2 Einstellschrauben (48) wieder anziehen.
5. Vergewissern Sie sich, dass der Abstand zwischen dem vorderen Konsole-Cursor (37) und dem Papier im Bereich 0,5 bis 1,5 mm liegt.

3. Inserire un cacciavite con testa a croce tipo Philips nelle 2 fessure lunghe (47) nel cursore frontale del deck (37) e allentare le 2 viti di regolazione (48). Quindi spostare il cursore frontale del deck (37).

4. Ristringere le 2 viti di regolazione (48).
5. Controllare che lo spazio tra il cursore frontale del deck (37) e la carta sia compreso nella gamma tra 0,5 e 1,5 mm.

3. 将十字螺丝刀从堆纸板前部游标 (37) 的 2 处长孔 (47) 处插入, 拧松 2 颗调节螺丝 (48), 移动堆纸板前部游标 (37)。


4. 拧紧 2 颗调节螺丝 (48)。
5. 确认堆纸板前部游标 (37) 与纸张的间隙在 0.5 ~ 1.5mm 的范围内。

3. 데크커서 앞 (37) 2 곳의 긴 구멍 (47) 에서 플러스 드라이버를 넣어 조정나사 (48) 2 개를 느슨하게 하고 데크커서 앞 (37) 을 이동시킵니다 .

4. 조정나사 (48) 2 개를 조입니다 .
5. 데크커서 앞 (37) 과 용지의 틈이 0.5 ~ 1.5 mm 범위내가 되어 있는 것을 확인합니다 .

3. デッキカーソル前 (37) の 2箇所 の長穴 (47) からプラスドライバー挿入し、調整ビス (48) 2本を緩め、デッキカーソル前 (37) を移動させる。

4. 調整ビス (48) 2本を締め付ける。
5. デッキカーソル前 (37) と用紙の隙間が 0.5 ~ 1.5mm の範囲内になっていることを確認する



Adjusting the leading edge timing

The reference value for the leading edge timing is 20 ± 1.5 mm at position (b) in the correct image (a). If the timing is outside this range, perform the following adjustment.

1. Set maintenance mode U034, select LSU Out Top and Cassette(L)
2. Adjust the values.
Test pattern (c): Increase the setting value. Test pattern (d): Decrease the setting value.
3. Press the Start key to confirm the setting value.

Réglage de la synchronisation du bord de tête

La valeur de référence de la synchronisation du bord de tête est de $20 \pm 1,5$ mm à la position (b) d'une image correcte (a). Si la synchronisation est hors de cette plage, procéder au réglage suivant.

1. Passer en mode maintenance U034, sélectionner LSU Out Top et Cassette(L).
2. Régler les valeurs.
Mire d'essai (c): Augmentez la valeur de réglage. Mire d'essai (d): Diminuez la valeur de réglage.
3. Appuyer sur la touche de Start pour confirmer la valeur de réglage.

Cómo ajustar la sincronización del borde superior

El valor de referencia de la sincronización del borde superior es de $20 \pm 1,5$ mm en la posición (b) de la imagen correcta (a). Si la sincronización estuviera fuera de este rango, haga el siguiente ajuste.

1. Entre al modo de mantenimiento U034, seleccione LSU Out Top y Cassette(L).
2. Ajuste los valores.
Patrón de prueba (c): Aumente el valor de configuración. Patrón de prueba (d): Reduzca el valor de configuración.
3. Pulse la tecla de Start para confirmar el valor de configuración.

Einstellen des Vorderkanten-Timing

Der Bezugswert des Vorderkanten-Timing ist $20 \pm 1,5$ mm an Position (b) des korrekten Bilds (a). Falls das Timing außerhalb dieses Bereichs liegt, ist folgende Einstellung vorzunehmen.

1. Schalten Sie in den Wartungsmodus U034, wählen Sie LSU Out Top und Cassette(L).
2. Die Werte einstellen.
Testmuster (c): Den Einstellwert erhöhen. Testmuster (d): Den Einstellwert verringern.
3. Den Einstellwert durch Drücken der Start-Taste bestätigen.

Regolazione della sincronizzazione del bordo principale

Il valore di riferimento per la sincronizzazione del bordo principale è $20 \pm 1,5$ mm alla posizione (b) nell'immagine corretta (a). Se la sincronizzazione è all'infuori di questa gamma, effettuare la regolazione seguente.

1. Impostare la modalità manutenzione U034, selezionare LSU Out Top e Cassette(L).
2. Regolare i valori.
Modello di prova (c): Aumentare il valore dell'impostazione. Modello di prova (d): Diminuire il valore dell'impostazione.
3. Premere il tasto di Start per confermare il valore dell'impostazione.

前端対位調整

前端対位の基準値は矯正画像 (a) の (b) 位置が 20 ± 1.5 mm。超出该范围时，须进行以下调节。

1. 设置维护模式 U034，选择 LSU Out Top、Cassette(L)。
2. 调整设定值。
测试图案 (c)：调高设定值。测试图案 (d)：调低设定值。
3. 按 Start 键，以确定设定值。

선단 타이밍 조정


선단 타이밍은 적정화상 (a) 의 (b) 위치에서 기준치는 20 ± 1.5 mm. 여기에서 벗어나는 것은 이하의 조정을 합니다.

1. 메인テナンス 모드 U034 를 세트하고 LSU Out Top, Cassette(L) 을 선택합니다.
2. 설정치를 조정합니다.
테스트 패턴 (c) : 설정치를 높입니다. 테스트 패턴 (d) : 설정치를 내립니다.
3. 시작키를 누르고 설정치를 확인합니다.

先端タイミング調整

先端タイミングは、適正画像 (a) の (b) の位置で基準値は 20 ± 1.5 mm。これから外れるときは以下の調整をおこなう。

1. メンテナンスモード U034 をセットし、LSU Out Top、Cassette(L) を選択する。
2. 設定値を調整する。
テストパターン (c) : 設定値を上げる。テストパターン (d) : 設定値を下げる。
3. スタートキーを押し、設定値を確定する。



Adjusting the center line

The reference value for the center line is ± 0.5 mm or less at position (f) in the correct image (e). If the center line position is outside this range, perform the following adjustment.

1. Set maintenance mode U034, select LSU Out Left and Cassette3 or Cassette4.
2. Adjust the values.
Test pattern (g): Increase the setting value. Test pattern (h): Decrease the setting value.
3. Press the Start key to confirm the setting value.

Réglage de l'axe

La valeur de référence pour l'axe est de $\pm 0,5$ mm ou moins à la position (f) d'une image correcte (e). Si la position de l'axe est hors de cette plage, effectuez le réglage suivant.

1. Passer en mode maintenance U034, sélectionner LSU Out Left et Cassette3 ou Cassette4.
2. Régler les valeurs.
Mire d'essai (g): Augmentez la valeur de réglage. Mire d'essai (h): Diminuez la valeur de réglage.
3. Appuyer sur la touche de Start pour confirmer la valeur de réglage.

Ajuste de la línea central

El valor de referencia de la línea central es de $\pm 0,5$ mm o menor, en la posición (f) de la imagen correcta (e). Si la posición de la línea central estuviera fuera de este rango, haga el siguiente ajuste.

1. Entre al modo de mantenimiento U034, seleccione LSU Out Left y Cassette3 o Cassette4.
2. Ajuste los valores.
Patrón de prueba (g): Aumente el valor de configuración. Patrón de prueba (h): Reduzca el valor de configuración.
3. Pulse la tecla de Start para confirmar el valor de configuración.

Einstellen der Mittelinie

Der Bezugswert für die Mittelinie ist $\pm 0,5$ mm oder weniger an Position (f) des korrekten Bilds (e). Falls die Mittelinie außerhalb dieses Bereichs liegt, ist folgende Einstellung vorzunehmen.

1. Schalten Sie in den Wartungsmodus U034, wählen Sie LSU Out Left und Cassette3 oder Cassette4.
2. Die Werte einstellen.
Testmuster (g): Den Einstellwert erhöhen. Testmuster (h): Den Einstellwert verringern.
3. Den Einstellwert durch Drücken der Start-Taste bestätigen.

Regolazione della linea centrale

Il valore di riferimento per la linea centrale è $\pm 0,5$ mm o inferiore alla posizione (f) nell'immagine corretta (e). Se la posizione della linea centrale è all'infuori di questa gamma, effettuare la regolazione seguente.

1. Impostare la modalità manutenzione U034, selezionare LSU Out Left e Cassette3 o Cassette4.
2. Regolare i valori.
Modello di prova (g): Aumentare il valore dell'impostazione. Modello di prova (h): Diminuire il valore dell'impostazione.
3. Premere il tasto di Start per confermare il valore dell'impostazione.

中心线调节

中心线的基准值在矫正图像 (e) 的 (f) 位置为 ± 0.5 mm 以内。超出该范围时, 须进行以下调节。

1. 设置维护模式 U034, 选择 LSU Out Left、Cassette3 或 Cassette4。
2. 调整设定值。
测试图案 (g): 调高设定值。测试图案 (h): 调低设定值。
3. 按 Start 键, 以确定设定值。

센터라인 조정

센터라인은 적정화상 (e) 의 (f) 위치에서 기준치는 ± 0.5 mm 이내 . 여기에서 벗어나는 것은 이하의 조정을 합니다 .

1. 메인터넌스 모드 U034 를 세트하고 LSU Out Left, Cassette3 또는 Cassette4 를 선택합니다 .
2. 설정치를 조정합니다 .
테스트 패턴 (g) : 설정치를 높입니다 . 테스트 패턴 (h) : 설정치를 내립니다 .
3. 시작키를 누르고 설정치를 확인합니다 .

センターライン調整

センターラインは、適正画像 (e) の (f) の位置で基準値は ± 0.5 mm 以内。これから外れるときは以下の調整をおこなう。

1. メンテナンスモード U034 をセットし、LSU Out Left、Cassette3 または Cassette4 を選択する。
2. 設定値を調整する。
テストパターン (g) : 設定値を上げる。 テストパターン (h) : 設定値を下げる。
3. スタートキーを押し、設定値を確定する。

INSTALLATION GUIDE FOR SIDE DECK

English

References to medium-speed MFPs in this document denote 30/30, 35/35, 45/45 and 55/50 ppm color machines, and 35, 45 and 55 ppm monochrome machines.

References to high-speed MFPs in this document denote 65/65 and 75/70 ppm color machines, and 65 and 80 ppm monochrome machines.

Français

Dans le présent document, les références aux MFP à vitesse moyenne renvoient aux machines couleurs 30/30, 35/35, 45/45 et 55/50 ppm et aux machines monochromes 35, 45 et 55 ppm.

Dans le présent document, les références aux MFP à grande vitesse renvoient aux machines couleurs 65/65 et 75/70 ppm et aux machines monochromes 65 et 80 ppm.

Español

Las referencias a las MFP de velocidad media de este documento corresponden a las máquinas a color de 30/30, 35/35, 45/45 y 55/50 ppm y a las máquinas monocromáticas de 35, 45 y 55 ppm.

Las referencias a las MFP de alta velocidad de este documento corresponden a las máquinas a color de 65/65 y 75/70 ppm y a las máquinas monocromáticas de 65 y 80 ppm.

Deutsch

Angaben für MFP der mittleren Leistungsklasse in dieser Anleitung gelten für die 30/30, 35/35, 45/45 und 55/50 ppm Vollfarbenkopierer sowie für die 35, 45 und 55 ppm Monochrommaschinen.

Angaben für MFP der Hochleistungsklasse in dieser Anleitung gelten für die 65/65 und 75/70 ppm Vollfarbenkopierer sowie für die 65 und 80 ppm Monochrommaschinen.

Italiano

I riferimenti per le MFP a velocità media riportati in questo documento indicano le macchine a colori 30/30, 35/35, 45/45 e 55/50 ppm, e le macchine monocromatiche 35, 45 e 55 ppm.

I riferimenti per le MFP a velocità alta riportati in questo documento indicano le macchine a colori 65/65 e 75/70 ppm, e le macchine monocromatiche 65 e 80 ppm.

简体中文

本文中的中速 MFP 代表彩色 30/30 页机型、35/35 页机型、45/45 页机型、55/50 页机型、黑白 35 页机型、45 页机型、55 页机型。

本文中的高速 MFP 代表彩色 65/65 页机型、75/70 页机型、黑白 65 页机型、80 页机型。

한국어


본문 중 중속 MFP 는 컬러 30/30 매기, 35/35 매기, 45/45 매기, 55/50 매기, 흑백 35 매기, 45 매기, 55 매기를 나타냅니다.

본문 중 고속 MFP 는 컬러 65/65 매기, 75/70 매기, 흑백 65 매기, 80 매기를 나타냅니다.

日本語

本文中の中速 MFP はカラー機の 30/30 枚機、35/35 枚機、45/45 枚機、55/50 枚機、モノクロ機の 35 枚機、45 枚機、55 枚機を表す。

本文中の高速 MFP はカラー機の 65/65 枚機、75/70 枚機、モノクロ機の 65 枚機、80 枚機を表す。



Supplied parts

A. Side feeder	1
B. Large base slider	1
C. Small base slider	1
D. Lock pin	2
E. Switch press plate	1
F. M4 × 8 screw	8

G. Paper size plate	2
H. Media type plate(except for 120V model) ..	6
H. Media type plate(120V model only)	3
I. Cover plate	1
J. M4 × 10 tapping screw.....	1
K. Film	1

Be sure to remove any tape and/or cushioning material from supplied parts.

Pièces fournies

A. Plateau d'alimentation latéral.....	1
B. Grande règle de base	1
C. Petite règle de base.....	1
D. Broche de verrouillage.....	2
E. Plaque de pression de l'interrupteur	1
F. Vis M4 × 8.....	8

G. Plaquette du format de papier	2
H. Plaquette du type de support.....	6
I. Capot	1
J. Vis de connexion M4 × 10	1
K. Film	1

Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.

Partes suministradas

A. Alimentador lateral.....	1
B. Deslizador de base grande.....	1
C. Deslizador de base pequeño	1
D. Clavija de bloqueo	2
E. Placa de presión del interruptor.....	1
F. Tornillo M4 × 8	8

G. Placa de tamaño de papel	2
H. Placa de tipo de medio	6
I. Tapa	1
J. Tornillo de roscado M4 × 10	1
K. Película	1

Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.

Gelieferte Teile

A. Seitlicher Einzug	1
B. Großer Basis-Schieber	1
C. Kleiner Basis-Schieber	1
D. Arretierstift	2
E. Schalterdruckplatte	1
F. M4 × 8 Schraube	8

G. Papierformatkarte	2
H. Medientypkarte	6
I. Abdeckplatte	1
J. M4 × 10 Schneidschraube	1
K. Film	1

Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.

Parti di forniture

A. Unità di alimentazione laterale.....	1
B. Scivolo di base grande	1
C. Scivolo di base piccolo	1
D. Perno di bloccaggio	2
E. Piastra spingi interruttore.....	1
F. Vite M4 × 8	8

G. Piastra formato carta	2
H. Piastra tipo carta.....	6
I. Coperchio	1
J. Vite autofilettante M4 × 10	1
K. Pellicola	1

Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.

附属品

A. 侧供纸盒	1
B. 底座滑板(大)	1
C. 底座滑板(小)	1
D. 锁定插销	2
E. 开关挡板	1

F. M4×8 螺丝	8
G. 纸张尺寸标示	2
H. 纸张种类标示	1
I. 盖板	1
J. M4×10 自攻螺丝	1
K. 胶片	1

如果附属品上带有固定胶带,缓冲材料时必须揭下。

동봉품

A. 사이드피더	1
B. 베이스 슬라이더 대	1
C. 베이스 슬라이더 소	1
D. 잠금 핀	2
E. 스위치 판	1

F. 나사 M4×8	8
G. 용지크기 플레이트	2
H. 용지종류 플레이트	1
I. 커버 플레이트	1
J. 탭핑 나사 M4×10	1
K. 필름	1


동봉품에 고정 테이프, 완충재가 붙어 있는 경우에는 반드시 제거할 것.

同梱品

A. サイドフィーダー	1
B. ベーススライダ-大	1
C. ベーススライダ-小	1
D. ロックピン	2
E. スイッチ当たり板	1
F. ビス M4×8	8

G. 用紙サイズプレート	2
H. 用紙種類プレート	1
I. カバープレート	1
J. タッピングビス M4×10	1
K. フィルム	1

同梱品に固定テープ、緩衝材がついている場合は、必ず取り外すこと。



Procedure

Be sure to turn the MFP main power switch off and disconnect the MFP power plug from the wall outlet before starting to install the side feeder.

Installation on medium-speed MFPs

If installing on a high-speed MFP, proceed to step 13.

1. Open the lower right cover (1) on the MFP.
Remove the strap (2) from the shaft (3) and remove lower right cover (1).

Procédure

Veiller à bien mettre l'interrupteur principal du MFP hors tension et à débrancher la fiche d'alimentation du MFP de la prise murale avant de commencer l'installation du plateau d'alimentation latéral.

Montage sur des MFP à vitesse moyenne

Si le montage est fait sur un MFP à grande vitesse, passer à l'étape 13.

1. Ouvrir le couvercle inférieur droit (1) du MFP.
Déposer la courroie (2) de l'arbre (3) et déposer le couvercle inférieur droit (1).

Procedimiento

Asegúrese de apagar el interruptor principal del MFP y de desconectar el enchufe del MFP del receptáculo de pared antes de empezar a instalar el alimentador lateral.

Instalación en las MFP de velocidad media

Si se instala en una MFP de alta velocidad, vaya al paso 13.

1. Abra la cubierta frontal inferior (1) del MFP.
Quite la correa (2) del eje (3) y quite la cubierta frontal inferior (1).

Verfahren

Schalten Sie unbedingt den Hauptschalter des MFP aus, und ziehen Sie den Netzstecker des MFP von der Netzsteckdose ab, bevor Sie mit der Installation des seitlichen Einzugs beginnen.

Installation an MFP der mittleren Leistungsklasse

Gehen Sie zur Installation an einem MFP der Hochleistungsklasse weiter zu Schritt 13.

1. Die untere rechte Abdeckung (1) am MFP öffnen.
Den Riemen (2) von der Welle (3) abnehmen und dann die untere rechte Abdeckung (1) abnehmen.

Procedura

Prima di iniziare la procedura di installazione dell'unità di alimentazione laterale, assicurarsi di spegnere l'interruttore principale di alimentazione dell'MFP, e di scollegare la spina del cavo di alimentazione dalla presa elettrica a muro.

Installazione sulle MFP a velocità media

Se si installa su una MFP a velocità alta, procedere al passo 13.

1. Aprire il coperchio destro inferiore (1) sull'MFP.
Rimuovere la cinghietta (2) dall'asta (3) e quindi rimuovere il coperchio destro inferiore (1).

安装步骤

安装侧供纸盒时，必须先关闭 MFP 主机上的主电源开关，并拔出电源插头后方可进行工作。

安装于中速 MFP 上时

安装于高速 MFP 上时，进至步骤 13。

1. 打开 MFP 主机的右下部盖板 (1)。
将带子 (2) 从轴 (3) 上拆除，拆下右下部盖板 (1)。

설치순서

사이드피더를 설치할 때에는 반드시 MFP 본체의 주전원 스위치를 OFF 로 하고 전원 플러그를 뽑아 후 작업을 할 것 .

중속 MFP 에 설치하는 경우

고속 MFP 에 설치하는 경우에는 순서 13 로 진행합니다 .

1. MFP 본체의 오른쪽 아래 커버 (1) 를 엽니다 .
스트랩 (2) 를 축 (3) 에서 떼어내 오른쪽 아래 커버 (1) 를 제거합니다 .


取付手順

サイドフィーダーを設置するときは、必ず MFP 本体の主電源スイッチを OFF にし、電源プラグを抜いてから作業すること。


中速 MFP に設置の場合

高速 MFP に設置の場合は手順 13 に進む。


1. MFP 本体の右下カバー (1) を開く。
ストラップ (2) を軸 (3) から外し、右下カバー (1) を取り外す。



2. Open the MFP paper conveying cover (4).
3. Open the panel (6) on the MFP front right cover (5).



4. Remove 3 screws (7) and remove the front right cover (5).



5. Remove a screw (9) from the middle right rear cover (8).

2. Ouvrir le capot du transport du papier du MFP (4).
3. Ouvrir le panneau (6) sur le capot avant droit du MFP (5).

4. Déposer les 3 vis (7) et déposer le capot avant droit (5).

5. Déposer la vis (9) du capot arrière droit médian (8).

2. Abra la cubierta de transporte del papel del MFP (4).
3. Abra el panel (6) en la cubierta delantera derecha (5).

4. Quite los 3 tornillos (7) y quite la cubierta delantera derecha (5).

5. Quite el tornillo (9) de la cubierta trasera central (8).

2. Öffnen Sie die Papierförderabdeckung (4) des MFP.
3. Öffnen Sie die Platte (6) der vorderen rechten Abdeckung (5) des MFP.

4. Entfernen Sie 3 Schrauben (7) und nehmen Sie die vordere rechte Abdeckung (5) ab.

5. Entfernen Sie eine Schraube (9) von der mittleren rechten hinteren Abdeckung (8).

2. Aprire il coperchio (4) dell'unità di trasporto carta dell'MFP.
3. Aprire il pannello (6) sul coperchio destro anteriore (5) dell'MFP.

4. Rimuovere le 3 viti (7), e quindi rimuovere il coperchio destro posteriore (5).

5. Rimuovere la vite (9) dal coperchio posteriore centrale destro (8).

2. 打开 MFP 主机的供纸盖板 (4)。
3. 打开 MFP 主机的右前部盖板 (5) 的盖子 (6)。

4. 拆除 3 颗螺丝 (7)，拆下右前部盖板 (5)。

5. 拆除右中后部盖板 (8) 的 1 颗螺丝 (9)。

2. MFP 本体的搬送カバー (4) を開く。
3. MFP 本体の右前カバー (5) の 뚜껑 (6) 을 엽니다.


4. 나사 (7) 3 개를 제거하고 우측 전면커버 (5) 를 떼어 냅니다.

5. 우측 중간 뒷커버 (8) 의 나사 (9) 1 개를 제거합니다.


2. MFP 本体の搬送カバー (4) を開く。
3. MFP 本体の右前カバー (5) のふた (6) を開く。

4. ビス (7) 3 本を外し、右前カバー (5) を取り外す。


5. 右中後カバー (8) のビス (9) 1 本を外す。



6. Remove 3 screws (10), then lift the bottom of the middle right rear cover (8) and remove the lower right rear cover (11).



7. Remove the panel (13) from the lower right cover (12) on the paper feeder using a flat blade screwdriver.



8. Open the paper feeder right cover (14). Remove the strap (15) from the right cover shaft (16) and remove the right cover (14).

6. Déposer les 3 vis (10) puis lever le bas du capot arrière droit médian (8) pour déposer le capot arrière droit inférieur (11).

7. Déposer le panneau (13) du capot inférieur droit (12) du bureau papier en procédant à l'aide d'un tournevis à lame.

8. Ouvrir le couvercle droit du bureau papier (14). Déposer la courroie (15) de l'axe du capot droit (16) et déposer le capot droit (14).

6. Quite los 3 tornillos (10), luego levante la parte inferior de la cubierta trasera central derecha (8) y quite la cubierta trasera inferior derecha (11).

7. Quite el panel (13) de la cubierta derecha inferior (12) del alimentador de papel con un destornillador de pala plana.

8. Abra la cubierta derecha del alimentador de papel (14). Quite la correa (15) del eje de la cubierta derecha (16) y quite la cubierta derecha (14).

6. Entfernen Sie 3 Schrauben (10), heben Sie die mittlere rechte hintere Abdeckung (8) von unten her an und nehmen Sie die untere rechte hintere Abdeckung (11) ab.

7. Nehmen Sie mit einem flachen Schraubendreher die Platte (13) von der unteren rechten Abdeckung (12) des Papiereinzugs ab.

8. Die rechte Abdeckung (14) des Papiereinzugs öffnen. Nehmen Sie den Riemen (15) von der Welle (16) der rechten Abdeckung und dann die rechte Abdeckung (14) ab.

6. Rimuovere le 3 viti (10), quindi sollevare la parte in basso del coperchio posteriore centrale destro (8) e rimuovere il coperchio posteriore inferiore destro (11).

7. Rimuovere il pannello (13) dal coperchio destro inferiore (12) sull'unità di alimentazione carta utilizzando un cacciavite a testa piana.

8. Aprire il coperchio destro (14) dell'unità di alimentazione della carta. Rimuovere la cinghietta (15) dall'asta (16) del coperchio destro e quindi rimuovere il coperchio destro (14).

6. 拆除 3 顆螺絲 (10)，抬起右中後部蓋板 (8) 的下部，拆下右下後部蓋板 (11)。

7. 使用一字螺絲刀等將供紙盒的右下部蓋板 (12) 的蓋子 (13) 拆下。

8. 打開供紙盒的右部蓋板 (14)。從右蓋板的軸 (16) 上拆除掛繩 (15)，拆下右蓋板 (14)。

6. 나사 (10) 3 개를 제거하고 우측 하단 뒷커버 (8) 의 하측을 올리고 우측 중간 뒷커버 (11) 를 제거합니다 .


7. 용지 급지대의 우측 하단커버 (12) 의 뚜껑 (13) 을 마이너스 드라이버 등으로 떼어 냅니다 .

8. 급지대 우측커버 (14) 를 엽니다 . 스트랩 (15) 을 우측커버의 축 (16) 에서 떼어 내고 우측커버 (14) 를 제거합니다 .

6. 비스 (10) 3 본を外し、右中後カバー(8) の下側を持ち上げて、右下後カバー(11) を取り外す。

7. ペーパーフィーダーの右下カバー(12) のふた (13) をマイナスドライバーなどで取る。

8. ペーパーフィーダーの右カバー(14) を開く。ストラップ (15) を右カバーの軸 (16) から外し、右カバー(14) を取り外す。




For PF-730

9. Remove 3 screws (17) and a screw (18) and remove the paper feeder lower right cover (19).

For PF-740

9. Remove 3 screws (17) and a screw (20) and remove the paper feeder lower right cover (19).



10. Remove the breakaway cover (21) from the front right cover (5) and the breakaway cover (22) from the lower right rear cover (11).

Pour PF-730

9. Déposer les 3 vis (17) et la vis (18) puis déposer le capot inférieur droit du bureau papier (19).

Pour PF-740

9. Déposer les 3 vis (17) et la vis (20) puis déposer le capot inférieur droit du bureau papier (19).

10. Déposer le couvercle amovible (21) du capot avant droit (5) et le couvercle amovible (22) du capot arrière inférieur droit (11).

Para PF-730

9. Quite los 3 tornillos (17) y el tornillo (18) y quite la cubierta derecha inferior del alimentador de papel (19).

Para PF-740

9. Quite los 3 tornillos (17) y el tornillo (20) y quite la cubierta derecha inferior del alimentador de papel (19).

10. Quite la cubierta divisoria (21) de la cubierta delantera derecha (5) y la cubierta divisoria (22) de la cubierta trasera inferior derecha (11).

Für PF-730

9. Entfernen Sie 3 Schrauben (17) und eine Schraube (18) und nehmen Sie die untere rechte Abdeckung (19) des Papiereinzugs ab.

Für PF-740

9. Entfernen Sie 3 Schrauben (17) und eine Schraube (20) und nehmen Sie die untere rechte Abdeckung (19) des Papiereinzugs ab.

10. Nehmen Sie die Ablösungsabdeckung (21) von der vorderen rechten Abdeckung (5) ab und die Ablösungsabdeckung (22) von der unteren rechten hinteren Abdeckung (11).

Per PF-730

9. Rimuovere le 3 viti (17) e una vite (18), e quindi rimuovere il coperchio destro inferiore (19) dell'unità di alimentazione carta.

Per PF-740

9. Rimuovere le 3 viti (17) e una vite (20), e quindi rimuovere il coperchio destro inferiore (19) dell'unità di alimentazione carta.

10. Rimuovere il coperchio di distacco (21) dal coperchio destro anteriore (5), e il coperchio di distacco (22) dal coperchio posteriore inferiore destro (11).

PF-730 时

9. 拆除 3 颗螺丝 (17) 和 1 颗螺丝 (18), 拆下供纸盒的右下部盖板 (19)。

PF-740 时

9. 拆除 3 颗螺丝 (17) 和 1 颗螺丝 (20), 拆下供纸盒的右下部盖板 (19)。

10. 切除右前部盖板 (5) 的切割盖板 (21) 和右下后部盖板 (11) 的切割盖板 (22)。

PF-730 의 경우

9. 나사 (17) 3 개와 나사 (18) 1 개를 제거하고, 용지 급지대의 우측 하단커버 (19) 를 제거합니다 .

PF-740 의 경우

9. 나사 (17) 3 개와 나사 (20) 1 개를 제거하고, 용지 급지대의 우측 하단커버 (19) 를 제거합니다 .

10. 우측 전면커버 (5) 의 분할커버 (21) 와 오른쪽 하단 뒷커버 (11) 의 분할커버 (22) 를 떼어 냅니다 .


PF-730 の場合

9. ビス (17) 3 本とビス (18) 1 本を外して、ペーパーフィーダーの右下カバー (19) を取り外す。


PF-740 の場合

9. ビス (17) 3 本とビス (20) 1 本を外して、ペーパーフィーダーの右下カバー (19) を取り外す。

10. 右前カバー (5) の割りカバー (21) と右下後カバー (11) の割りカバー (22) を切り取る。



11. Remove the panel (23) from the MFP lower right cover (1) with a flat blade screwdriver.



12. After using alcohol to clean place adhering the film, adhere the film (K) in the position (24) indicated in the illustration. Proceed to step 25

11. Déposer le panneau (23) du capot inférieur droit du MFP (1) en procédant à l'aide d'un tournevis à lame.

12. Coller le film (K) sur l'emplacement (24) indiqué dans l'illustration, après avoir soigneusement nettoyé cet emplacement à l'alcool. Passer à l'étape 25.

11. Extraiga el panel (23) de la cubierta derecha inferior del MFP (1) con un destornillador de pala plana.

12. Después de utilizar alcohol para limpiar la zona donde se va a pegar la película, pegue la película (K) en el lugar (24) que se indica en la ilustración. Vaya al paso 25.

11. Nehmen Sie mit einem flachen Schraubendreher die Platte (23) von der unteren rechten Abdeckung (1) des MFP ab.

12. Zum Anbringen des Films (K) die Stelle zuvor mit Alkohol reinigen und den Film (K) dann in der in der Abbildung angegebenen Position (24) anbringen. Gehen Sie weiter zu Schritt 25.

11. Rimuovere il pannello (23) dal coperchio destro inferiore (1) dell'MFP con un cacciavite a testa piana.

12. Dopo aver utilizzato alcol per pulire la piastra che aderisce alla pellicola, far aderire la pellicola (K) nella posizione (24) indicata nell'illustrazione. Procedere al passo 25.

11. 使用一字螺丝刀将 MFP 主机的右下部盖板 (1) 的盖子 (23) 拆下。


12. 使用酒精对薄膜粘贴位置进行清洁后, 按插图位置 (24) 粘贴薄膜 (K)。进至步骤 25。

11. MFP 본체의 우측 뒷커버 (1) 의 뚜껑 (23) 을 마이너스 드라이버로 제거합니다 .

12. 필름 부착위치를 알코올 청소 후, 일러스트의 위치 (24) 에 맞춰 필름 (K) 을 부착합니다 . 순서 25 로 진행합니다 .


11. MFP 本体の右下カバー(1) のふた (23) をマイナスドライバーで取り外す。

12. フィルム貼り付け位置をアルコール清掃後、イラストの位置 (24) にあわせて、フィルム(K)を貼り付ける。手順 25 に進む。



Installation on high-speed MFPs

- 13.** Open the right cover 1 (25) on the MFP.
Remove the strap (26) from the shaft (27) and remove right cover 1 (25).



- 14.** Open the right cover 2 (28) on the MFP.
Remove the strap (29) from the right cover shaft (30) and remove the right cover 2 (28).

Montage sur des MFP à grande vitesse

- 13.** Ouvrir le capot droit 1 (25) du MFP.
Déposer la courroie (26) de l'arbre (27) et déposer le capot droit 1 (25).

- 14.** Ouvrir le capot droit 2 (28) du MFP.
Déposer la courroie (29) de l'axe du capot droit (30) et déposer le capot droit 2 (28).

Instalación en las MFP de alta velocidad

- 13.** Abra la cubierta derecha 1 (25) del MFP.
Quite la correa (26) del eje (27) y quite la cubierta derecha 1 (25).

- 14.** Abra la cubierta derecha 2 (28) del MFP.
Quite la correa (29) del eje de la cubierta derecha (30) y quite la cubierta derecha 2 (28).

Installation an MFP der Hochleistungsklasse

- 13.** Die rechte Abdeckung 1 (25) am MFP öffnen.
Den Riemen (26) von der Welle (27) abnehmen und dann die rechte Abdeckung 1 (25) abnehmen.

- 14.** Die rechte Abdeckung 2 (28) am MFP öffnen.
Nehmen Sie den Riemen (29) von der Welle (30) der rechten Abdeckung und dann die rechte Abdeckung 2 (28) ab.

Installazione sulle MFP a velocità alta

- 13.** Aprire il coperchio destro 1 (25) sull'MFP.
Rimuovere la cinghietta (26) dall'asta (27) e quindi rimuovere il coperchio destro 1 (25).

- 14.** Aprire il coperchio destro 2 (28) sull'MFP.
Rimuovere la cinghietta (29) dall'asta (30) del coperchio destro e quindi rimuovere il coperchio destro 2 (28).

安装于高速 MFP 上时

- 13.** 打开 MFP 主机的右部盖板 1 (25)。
将带子 (26) 从轴 (27) 上拆除，拆下右部盖板 1 (25)。

- 14.** 打开 MFP 主机的右部盖板 2 (28)。
从右盖板的轴 (30) 上拆除挂绳 (29)，拆下右盖板 2 (28)。

고속 MFP 에 설치하는 경우


- 13.** MFP 본체의 우측커버 1 (25) 를 엽니다 .
스트랩 (26) 를 축 (27) 에서 떼어내 우측커버 1 (25) 를 제거합니다 .

- 14.** MFP 본체의 우측커버 2 (28) 를 엽니다 .
스트랩 (29) 을 우측커버의 축 (30) 에서 떼어내고 우측커버 2 (28) 를 제거합니다 .


高速 MFP に設置の場合

- 13.** MFP 本体の右カバー1 (25) を開く。
ストラップ (26) を軸 (27) から外し、右カバー1 (25) を取り外す。


- 14.** MFP 本体の右カバー2 (28) を開く。
ストラップ (29) を右カバーの軸 (30) から外し、右カバー2 (28) を取り外す。



15. Open the MFP paper conveying cover (31).
16. Open the panel (33) on the MFP front right cover (32).



17. Remove the 4 screws (34) and release the 4 hooks (59). Then remove the front right cover (32).



18. Remove a screw (36) from the middle right rear cover (35).

15. Ouvrir le capot du transport du papier du MFP (31).
16. Ouvrir le panneau (33) sur le capot avant droit du MFP (32).

17. Retirer les 4 vis (34) et libérer les 4 crochets (59). Retirer ensuite le capot avant droit (32).

18. Déposer la vis (36) du capot arrière droit médian (35).

15. Abra la cubierta de transporte del papel del MFP (31).
16. Abra el panel (33) en la cubierta delantera derecha (32).

17. Quite los 4 tornillos (34) y libere los 4 ganchos (59). Después, quite la cubierta frontal derecha (32).

18. Quite el tornillo (36) de la cubierta trasera central (35).

15. Öffnen Sie die Papierförderabdeckung (31) des MFP.
16. Öffnen Sie die Platte (33) der vorderen rechten Abdeckung (32) des MFP.

17. Entfernen Sie die 4 Schrauben (34) und lösen Sie die 4 Haken (59). Danach nehmen Sie die rechte vordere Abdeckung (32) ab.

18. Entfernen Sie eine Schraube (36) von der mittleren rechten hinteren Abdeckung (35).

15. Aprire il coperchio (31) dell'unità di trasporto carta dell'MFP.
16. Aprire il pannello (33) sul coperchio destro anteriore (32) dell'MFP.

17. Rimuovere le 4 viti (34) e rilasciare i 4 ganchi (59). Rimuovere quindi il coperchio anteriore destro (32).

18. Rimuovere la vite (36) dal coperchio posteriore centrale destro (35).

15. 打开 MFP 主机的供纸盖板 (31)。
16. 打开 MFP 主机的右前部盖板 (32) 的盖子 (33)。

17. 卸下 4 颗螺丝 (34) 并松开 4 个卡扣 (59)。然后卸下右前盖板 (32)。

18. 拆除右中后部盖板 (35) 的 1 颗螺丝 (36)。

15. MFP 본체의 반송커버 (31) 를 엽니다 .
16. MFP 본체의 우측 전면커버 (32) 의 뚜껑 (33) 을 엽니다 .


17. 나사 (34) 4 개를 제거하고 후크 (59) 4 개를 풀니다 . 그런 다음 우측 전면 커버 (32) 를 제거합니다 .

18. 우측 중간 뒷커버 (35) 의 나사 (36) 1 개를 제거합니다 .


15. MFP 本体の搬送カバー (31) を開く。
16. MFP 本体の右前カバー (32) のふた (33) を開く。

17. ビス (34) 4 本およびフック (59) 4 箇所を外し、右前カバー (32) を取り外す。


18. 右中後カバー (35) のビス (36) 1 本を外す。



19. Remove the panel (38) from the lower right rear cover (37) with a flat blade screwdriver.



20. Remove 5 screws (39), then lift the bottom of the middle right rear cover (35) and remove the lower right rear cover (37).



21. Remove 2 screws (40) and remove the lower right cover (41).

19. Déposer le panneau (38) du capot arrière inférieur droit (37) en procédant à l'aide d'un tournevis à lame.

20. Déposer les 5 vis (39) puis lever le bas du capot arrière droit médian (35) pour déposer le capot arrière droit inférieur (37).

21. Déposer les 2 vis (40) et déposer le capot inférieur droit (41).

19. Extraiga el panel (38) de la cubierta trasera inferior derecha (37) con un destornillador de pala plana.

20. Quite los 5 tornillos (39), luego levante la parte inferior de la cubierta trasera central derecha (35) y quite la cubierta trasera inferior derecha (37).

21. Quite los 2 tornillos (40) y quite la cubierta derecha inferior (41).

19. Nehmen Sie mit einem flachen Schraubendreher die Platte (38) von der unteren rechten hinteren Abdeckung (37) ab.

20. Entfernen Sie 5 Schrauben (39), heben Sie die mittlere rechte hintere Abdeckung (35) von unten her an und nehmen Sie die untere rechte hintere Abdeckung (37) ab.

21. Entfernen Sie 2 Schrauben (40) und nehmen Sie die untere rechte Abdeckung (41) ab.

19. Rimuovere il pannello (38) dal coperchio posteriore inferiore destro (37) con un cacciavite a testa piana.

20. Rimuovere le 5 viti (39), quindi sollevare la parte in basso del coperchio posteriore centrale destro (35) e rimuovere il coperchio posteriore inferiore destro (37).

21. Rimuovere le 2 viti (40), e quindi rimuovere il coperchio destro inferiore (41).

19. 用一字螺丝刀等取下右下盖板(37)的盖子(38)。

20. 拆除5颗螺丝(39),抬起右中后部盖板(35)的下部,拆下右下后部盖板(37)。

21. 拆除2颗螺丝(40),拆下右下部盖板(41)。

19. 우측 아래뒷면 커버(37)의 뚜껑(38)을 마이너스 드라이버 등으로 푼니다.


20. 나사(39) 5개를 제거하고 우측 하단 뒷커버(35)의 하측을 올리고 우측 중간 뒷커버(37)를 제거합니다.

21. 나사(40) 2개를 제거하고 우측 하단커버(41)를 떼어 냅니다.


19. 右下後カバー(37)のふた(38)をマイナスドライバーなどで取る。

20. ビス(39)5本を外し、右中後カバー(35)の下側を持ち上げて、右下後カバー(37)を取り外す。

21. ビス(40)2本を外して、右下カバー(41)を取り外す。



22. Remove the breakaway cover (42) from the front right cover (32) and the breakaway cover (43) from the lower right rear cover (37).



23. Remove the panel (44) from the MFP right cover 1 (25) with a flat blade screwdriver.

22. Déposer le couvercle amovible (42) du capot avant droit (32) et le couvercle amovible (43) du capot arrière inférieur droit (37).

23. Déposer le panneau (44) du capot droit 1 du MFP (25) en procédant à l'aide d'un tournevis à lame.

22. Quite la cubierta divisoria (42) de la cubierta delantera derecha (32) y la cubierta divisoria (43) de la cubierta trasera inferior derecha (37).

23. Extraiga el panel (44) de la cubierta derecha 1 del MFP (25) con un destornillador de pala plana.

22. Nehmen Sie die Ablösungsabdeckung (42) von der vorderen rechten Abdeckung (32) ab und die Ablösungsabdeckung (43) von der unteren rechten hinteren Abdeckung (37).

23. Nehmen Sie mit einem flachen Schraubendreher die Platte (44) von der rechten Abdeckung 1 (25) des MFP ab.

22. Rimuovere il coperchio di distacco (42) dal coperchio destro anteriore (32), e il coperchio di distacco (43) dal coperchio posteriore inferiore destro (37).

23. Rimuovere il pannello (44) dal coperchio destro 1 (25) dell'MFP con un cacciavite a testa piana.

22. 切除右前部盖板 (32) 的切割盖板 (42) 和右下后部盖板 (37) 的切割盖板 (43)。


23. 使用一字螺丝刀将 MFP 主机的右部盖板 1 (25) 的盖子 (44) 拆下。

22. 우측 전면커버 (32) 의 분할커버 (42) 와 오른쪽 하단 뒷커버 (37) 의 분할커버 (43) 를 떼어 냅니다 .


23. MFP 본체의 우측커버 1 (25) 의 뚜껑 (44) 을 마이너스 드라이버로 제거합니다 .

22. 右前カバー (32) の割りカバー (42) と右下後カバー (37) の割りカバー (43) を切り取る。

23. MFP 本体の右カバー1 (25) のふた (44) をマイナスドライバーで取り外す。



24. After using alcohol to clean place adhering the film, adhere the film (K) in the position (51) indicated in the illustration.



25. Install a lock pin (D) on the front right of the MFP using an M4 × 8 screw (F).

24. Coller le film (K) sur l'emplacement (51) indiqué dans l'illustration, après avoir soigneusement nettoyé cet emplacement à l'alcool.

25. Monter une broche de verrouillage (D) à droite et à l'avant du MFP en procédant à l'aide d'une vis M4 × 8 (F).

24. Después de utilizar alcohol para limpiar la zona donde se va a pegar la película, pegue la película (K) en el lugar (51) que se indica en la ilustración.

25. Instale una clavija de bloqueo (D) en la parte derecha frontal del MFP usando un tornillo M4 × 8 (F).

24. Zum Anbringen des Films (K) die Stelle zuvor mit Alkohol reinigen und den Film (K) dann in der in der Abbildung angegebenen Position (51) anbringen.

25. Bringen Sie mit einer M4 × 8 Schraube (F) den Arretierungsstift (D) vorne rechts am MFP an.

24. Dopo aver utilizzato alcol per pulire la piastra che aderisce alla pellicola, far aderire la pellicola (K) nella posizione (51) indicata nell'illustrazione.

25. Installare un perno di bloccaggio (D) sulla parte anteriore destra dell'MFP utilizzando una vite M4 × 8 (F).

24. 使用酒精对薄膜粘贴位置进行清洁后,按插图位置(51)粘贴薄膜(K)。


25. 使用1颗M4×8螺丝(F)将锁定插销(D)安装到MFP主机的前右侧。

24. 필름 부착위치를 알코올 청소 후, 일러스트의 위치 (51) 에 맞춰 필름 (K) 을 부착합니다 .


25. 나사 M4×8(F) 1 개로 잠금 핀 (D) 을 MFP 본체 우측 전면쪽에 설치합니다 .

24. フィルム貼り付け位置をアルコール清掃後、イラストの位置(51)にあわせて、フィルム(K)を貼り付ける。

25. ビス M4×8(F) 1 本で、ロックピン (D) を MFP 本体右前側に取り付ける。



26. Install a lock pin (D) on the rear right of the MFP using an M4 x 8 screw (F) in the same way.



27. Place the small base slider (C) on the large base slider (B). Place so that the bend (46) on the small base slider (C) abuts inside the rest (45) at the end of the large base slider (B).

26. Monter une broche de verrouillage (D) à droite et à l'arrière du MFP en procédant de la même manière à l'aide d'une vis M4 x 8 (F).

27. Placer la petite règle de base (C) sur la grande règle de base (B). Disposer la petite règle de base (C) de sorte que son extrémité repliée (46) s'encastre dans la butée (45) à l'extrémité de la grande règle de base (B).

26. Instale una clavija de bloqueo (D) en la parte derecha frontal del MFP usando un tornillo M4 x 8 (F).

27. Coloque el deslizador de base pequeño (C) sobre el deslizador de base grande (B). Haga que la dobladura (46) del deslizador de base pequeño (C) quede en el interior del apoyo (45) del extremo del deslizador de base grande (B).

26. Bringen Sie auf gleiche Weise mit einer M4 x 8 Schraube (F) den Arretierungsstift (D) hinten rechts am MFP an.

27. Setzen Sie den kleinen Basis-Schieber (C) auf den großen Basis-Schieber (B). Setzen Sie ihn so auf, dass die Biegung (46) am kleinen Basis-Schieber (C) innerhalb der Auflage (45) am Ende des großen Basis-Schiebers (B) anliegt.

26. Installare un perno di bloccaggio (D) sulla parte posteriore destra dell'MFP utilizzando una vite M4 x 8 (F) alla stessa maniera.

27. Posizionare lo scivolo di base piccolo (C) sullo scivolo di base grande (B). Posizionare in modo che la piegatura (46) sullo scivolo di base piccolo (C) si attesti all'interno del sostegno (45) all'estremità dello scivolo di base grande (B).

26. 按相同方法, 使用 1 顆 M4x8 螺絲 (F) 將鎖定插銷 (D) 安裝到 MFP 主機的右後側。


27. 將底座滑板(小)(C)放在底座滑板(大)(B)。此時底座滑板(小)(C)的彎曲部(46)應處於底座滑板(大)(B)的前端折彎部(45)的內側。

26. 같은 방식으로 나사 M4x8(F) 1 개로 잠금 핀 (D) 을 MFP 본체 우측 뒤쪽에 설치합니다 .

27. 베이스 슬라이더 대 (B) 의 위에 베이스 슬라이더 소 (C) 를 얹습니다 . 그 때 , 베이스 슬라이더 소 (C) 의 곡선부 (46) 가 베이스 슬라이더 대 (B) 의 맨 앞쪽의 꺾이고 구부러진 부분 (45) 의 안쪽으로 오도록 세웁니다 .

26. 同様にビス M4x8(F) 1 本で、ロックピン (D) を MFP 本体右後側に取り付ける。

27. ベーススライダ-大 (B) の上にベーススライダ-小 (C) を乗せる。その際、ベーススライダ-小 (C) の曲げ (46) がベーススライダ-大 (B) の先端折り曲げ部 (45) の内側にくるようにセットする。



28. Insert the small base slider (C) under the paper feeder. Install to the base (47) using 2 M4 × 8 screws (F) so that the gap between the small base slider (C) and the large base slider (B) is 6 ± 2 mm.

* For PF-730, install to the screw holes marked "R".

28. Insérer la petite règle de base (C) sous le bureau papier. Fixer à la base (47) à l'aide de 2 vis M4 × 8 (F) de sorte que le battement entre la petite règle de base (C) et la grande règle de base (B) soit de 6 ± 2 mm.

* Pour le PF-730, fixer aux trous de vis marqués "R".

28. Inserte el deslizador de base pequeño (C) debajo del alimentador de papel. Instálelo en la base (47) usando 2 tornillos M4 × 8 (F) de manera tal que el huelgo entre el deslizador de base pequeño (C) y el deslizador de base grande (B) sea de 6 ± 2 mm.

* En el caso de PF-730, instale en los orificios para tornillo "R".

28. Stecken Sie den kleinen Basis-Schieber (C) unter den Papiereinzug. Befestigen Sie ihn mit 2 M4 × 8 Schrauben (F) so an der Basis (47), dass der Abstand zwischen dem kleinen Basis-Schieber (C) und dem großen Basis-Schieber (B) 6 ± 2 mm beträgt.

* Bei Modell PF-730 an den mit "R" markierten Schraublöchern befestigen.

28. Inserire lo scivolo di base piccolo (C) sotto l'unità di alimentazione carta. Installare alla base (47) utilizzando 2 viti M4 × 8 (F) in modo che lo spazio tra lo scivolo di base piccolo (C) e lo scivolo di base grande (B) sia di 6 ± 2 mm.

* Per PF-730, installare ai fori per viti segnalati con "R".

28. 将底座滑板(小)(C)装入供纸盒的下方。使用2颗M4×8(F)螺丝将底座滑板(小)(C)安装到底板(47)上,确保底座滑板(小)(C)与底座滑板(大)(B)之间的间隙为 6 ± 2 mm。

※PF-730时,安装到带有R刻印的螺纹孔上。

28. 베이스 슬라이더 소 (C) 를 용지 급지대 밑에 넣습니다 . 베이스 슬라이더 소 (C) 와 베이스 슬라이더 대 (B) 의 틈이 6 ± 2 mm 가 되도록 나사 M4×8(F) 2 개로 바닥판 (47) 에 장착합니다 .

※PF-730 은 R 의 각인이 있는 나사구멍에 장착합니다 .

28. ベーススライダ小 (C) をペーパーフィーダーの下に入れる。ベーススライダ小 (C) とベーススライダ大 (B) の隙間が、 6 ± 2 mm になるようにビス M4×8(F) 2 本で底板 (47) に取り付ける。

※PF-730 は R の刻印のあるビス穴に取り付ける。

Installation on medium-speed MFPs

If installing on a high-speed MFP, proceed to step 35.

29. Reinstall the paper feeder lower right cover (19).
30. Reinstall the paper feeder right cover (14).

31. Reinstall the lower right rear cover (11).
32. Mount a screw (9) in the middle right rear cover (8).
33. Reinstall the front right cover (5).
34. Reinstall the lower right cover (1).
Proceed to step 41.

Montage sur des MFP à vitesse moyenne

Si le montage est fait sur un MFP à grande vitesse, passer à l'étape 35.

29. Reposer le capot inférieur droit du bureau papier (19).
30. Reposer le capot droit du bureau papier (14).

31. Reposer le capot arrière inférieur droit (11).
32. Fixer la vis (9) sur le capot arrière médian droit (8).
33. Reposer le capot avant droit (5).
34. Reposer le capot inférieur droit (1).
Passer à l'étape 41.

Instalación en las MFP de velocidad media

Si se instala en una MFP de alta velocidad, vaya al paso 35.

29. Reinstale la cubierta derecha inferior del alimentador de papel (19).
30. Reinstale la cubierta derecha del alimentador de papel (14).

31. Reinstale la cubierta trasera inferior derecha (11).
32. Instale el tornillo (9) en la cubierta trasera central derecha (8).
33. Reinstale la cubierta delantera derecha (5).
34. Reinstale la cubierta derecha inferior (1).
Vaya al paso 41.

Installation an MFP der mittleren Leistungsklasse

Gehen Sie zur Installation an einem MFP der Hochleistungsklasse weiter zu Schritt 35.

29. Bringen Sie die untere rechte Abdeckung (19) des Papiereinzugs wieder an.
30. Bringen Sie die rechte Abdeckung (14) des Papiereinzugs wieder an.

31. Bringen Sie die untere rechte hintere Abdeckung (11) wieder an.
32. Befestigen Sie eine Schraube (9) an der mittleren rechten hinteren Abdeckung (8).
33. Bringen Sie die vordere rechte Abdeckung (5) wieder an.
34. Bringen Sie die untere rechte Abdeckung (1) wieder an.
Gehen Sie weiter zu Schritt 41.

Installazione sulle MFP a velocità media

Se si installa su una MFP a velocità alta, procedere al passo 35.

29. Reinstallare il coperchio destro inferiore dell'unità di alimentazione carta (19).
30. Reinstallare il coperchio destro (14) dell'unità di alimentazione carta.

31. Reinstallare il coperchio posteriore inferiore destro (11).
32. Montare la vite (9) nel coperchio posteriore centrale destro (8).
33. Reinstallare il coperchio destro anteriore (5).
34. Reinstallare il coperchio destro inferiore (1).
Procedere al passo 41.

安装于中速 MFP 上时

安装于高速 MFP 上时, 进至步骤 35。

29. 按原样安装供纸盒的右下部盖板 (19)。
30. 按原样安装供纸盒的右盖板 (14)。

31. 按原样安装右下后部盖板 (11)。
32. 安装右中后部盖板 (8) 的 1 颗螺丝 (9)。
33. 按原样安装右前部盖板 (5)。
34. 按原样安装右下后部盖板 (1)。
进至步骤 41。

중속 MFP 에 설치하는 경우

고속 MFP 에 설치하는 경우에는 순서 35 로 진행합니다 .

29. 용지 급지대의 우측 하단커버 (19) 를 원래대로 장착합니다 .
30. 용지 급지대의 우측커버 (14) 를 원래대로 장착합니다 .


31. 우측하단 뒷커버 (11) 를 원래대로 장착합니다 .
32. 우측 중간 뒷커버 (8) 의 나사 (9) 1 개를 장착합니다 .
33. 우측 전면커버 (5) 를 원래대로 장착합니다 .
34. 우측 하단커버 (1) 를 원래대로 장착합니다 .
순서 41 로 진행합니다 .

中速 MFP に設置の場合

高速 MFP に設置の場合は手順 35 に進む。

29. ペーパーフィーダーの右下カバー (19) を元通り取り付ける。
30. ペーパーフィーダーの右カバー (14) を元通り取り付ける。

31. 右下後カバー (11) を元通り取り付ける。
32. 右中後カバー (8) のビス (9) 1 本を取り付ける。
33. 右前カバー (5) を元通り取り付ける。
34. 右下カバー (1) を元通り取り付ける。
手順 41 に進む。



Installation on high-speed MFPs

- 35. Reinstall the lower right cover (41).
- 36. Reinstall the lower right rear cover (37).
- 37. Mount a screw (36) in the middle right rear cover (35).

- 38. Reinstall the front right cover (32).
- 39. Reinstall the right cover 2 (28).
- 40. Reinstall the right cover 1 (25).

- 41. Install the switch press plate (E) using the M4 × 10 tapping screw (J).

Montage sur des MFP à grande vitesse

- 35. Reposer le capot inférieur droit (41).
- 36. Reposer le capot arrière inférieur droit (37).
- 37. Fixer la vis (36) sur le capot arrière médian droit (35).

- 38. Reposer le capot avant droit (32).
- 39. Reposer le capot droit 2 (28).
- 40. Reposer le capot droit 1 (25).

- 41. Fixer la plaque de pression du contacteur (E) à l'aide d'une vis de connexion M4 × 10 (J).

Instalación en las MFP de alta velocidad

- 35. Reinstale la cubierta derecha inferior (41).
- 36. Reinstale la cubierta trasera inferior derecha (37).
- 37. Instale el tornillo (36) en la cubierta trasera central derecha (35).

- 38. Reinstale la cubierta delantera derecha (32).
- 39. Reinstale la cubierta derecha 2 (28).
- 40. Reinstale la cubierta derecha 1 (25).

- 41. Instale la placa de presión del interruptor (E) usando el tornillo de roscado M4 × 10 (J).

Installation an MFP der Hochleistungsklasse

- 35. Bringen Sie die untere rechte Abdeckung (41) wieder an.
- 36. Bringen Sie die untere rechte hintere Abdeckung (37) wieder an.
- 37. Befestigen Sie eine Schraube (36) an der mittleren rechten hinteren Abdeckung (35).

- 38. Bringen Sie die vordere rechte Abdeckung (32) wieder an.
- 39. Bringen Sie die rechte Abdeckung 2 (28) wieder an.
- 40. Bringen Sie die rechte Abdeckung 1 (25) wieder an.

- 41. Befestigen Sie mit der M4 × 10 Schraubenschraube (J) die Schalterdruckplatte (E).

Installazione sulle MFP a velocità alta

- 35. Reinstallare il coperchio destro inferiore (41).
- 36. Reinstallare il coperchio posteriore inferiore destro (37).
- 37. Montare la vite (36) nel coperchio posteriore centrale destro (35).

- 38. Reinstallare il coperchio destro anteriore (32).
- 39. Reinstallare il coperchio destro 2 (28).
- 40. Reinstallare il coperchio destro 1 (25).

- 41. Installare la piastra spingi interruttore (E) utilizzando la vite autofilettante M4 × 10 (J).

安装于高速 MFP 上时

- 35. 按原样安装右下部盖板 (41)。
- 36. 按原样安装右下后部盖板 (37)。
- 37. 安装右中后部盖板 (35) 的 1 颗螺丝 (36)。

- 38. 按原样安装右前部盖板 (32)。
- 39. 按原样安装右部盖板 2 (28)。
- 40. 按原样安装右部盖板 1 (25)。

- 41. 使用 1 颗 M4×10 自攻螺丝 (J) 安装开关挡板 (E)。

고속 MFP 에 설치하는 경우

- 35. 우측 하단커버 (41) 를 원래대로 장착합니다 .
- 36. 우측하단 뒷커버 (37) 를 원래대로 장착합니다 .
- 37. 우측 중간 뒷커버 (35) 의 나사 (36) 1 개를 장착합니다 .

- 38. 우측 전면커버 (32) 를 원래대로 장착합니다 .
- 39. 우측커버 2 (28) 를 원래대로 장착합니다 .
- 40. 우측커버 1 (25) 를 원래대로 장착합니다 .


- 41. 탭핑나사 M4×10(J) 1 개로 스위치 판 (E) 을 장착합니다 .

高速 MFP に設置の場合


- 35. 右下カバー (41) を元通り取り付けます。
- 36. 右下後カバー (37) を元通り取り付けます。
- 37. 右中後カバー (35) のビス (36) 1 本を取り付けます。

- 38. 右前カバー (32) を元通り取り付けます。
- 39. 右カバー 2 (28) を元通り取り付けます。
- 40. 右カバー 1 (25) を元通り取り付けます。

- 41. タッピングビス M4×10(J) 1 本でスイッチ当たり板 (E) を取り付けます。



42. Install the side feeder (A) to the large base slider (B) using 2 M4 × 8 screws (F). Install so that the center of the M4 × 8 screws (F) comes over the horizontal line (48) of the mounting plate on the large base slider (B).



43. Install the cover plate (I) using 2 M4 × 8 screws (F).

42. Fixer le dispositif du plateau d'alimentation latéral (A) à la grande règle de base (B) à l'aide de 2 vis M4 × 8 (F). Procéder de sorte que l'axe des vis M4 × 8 (F) recouvre la ligne horizontale (48) du plateau de montage sur la grande règle de base (B).

43. Fixer le capot (I) à l'aide de 2 vis M4 × 8 (F).

42. Instale el alimentador lateral (A) en el deslizador de base grande (B) usando 2 tornillos M4 × 8 (F). Instale de manera que el centro de los tornillos M4 × 8 (F) queden sobre la línea horizontal (48) de la placa de montaje del deslizador de base (B) grande.

43. Instale la tapa (I) usando los 2 tornillos M4 × 8 (F).

42. Befestigen Sie den seitlichen Einzug (A) mit 2 M4 × 8 Schrauben (F) am großen Basis-Schieber (B). Befestigen Sie ihn so, dass die Mitte der M4 × 8 Schrauben (F) über der Waagrechtlinie (48) der Montageplatte am großen Basis-Schieber (B) liegt.

43. Bringen Sie die Abdeckungsplatte (I) mit 2 M4 × 8 Schrauben (F) an.

42. Installare l'unità di alimentazione laterale (A) allo scivolo di base grande (B) utilizzando 2 viti M4 × 8 (F). Installare in modo che il centro delle viti M4 × 8 (F) sia sulla linea orizzontale (48) della piastra di montaggio sullo scivolo di base grande (B).

43. Installare il coperchio (I) utilizzando 2 viti M4 × 8 (F).

42. 使用 2 顆 M4×8 螺絲 (F) 將側供紙盒 (A) 安裝到底座滑板 (大) (B) 上。此時，應確保 M4×8 螺絲 (F) 的中心處於底座滑板 (大) (B) 的安裝板的平行線 (48) 上。


43. 使用 2 顆 M4×8 螺絲 (F) 安裝盖板 (I)。

42. 나사 M4×8(F) 2 개로 베이스 슬라이더 대 (B) 에 사이드 피더 (A) 를 장착합니다 . 그 때 , 베이스 슬라이더 대 (B) 의 설치판의 평행선 (48) 에 나사 M4×8(F) 의 센터가 오도록 장착합니다 .

43. 나사 M4×8(F) 2 개로 커버 플레이트 (I) 를 장착합니다 .

42. ビス M4×8(F) 2 本でベーススライダ大 (B) にサイドフィーダー(A) を取り付ける。その際、ベーススライダ大 (B) の取付板の平行線 (48) にビス M4×8(F) のセンターがくるように取り付ける。

43. ビス M4×8(F) 2 本でカバープレート (I) を取り付ける。



44. Plug the signal cable (49) for the side feeder into the paper feeder connector (50).
45. Push the side feeder to connect it to the MFP.

44. Enficher le câble de signal (49) du dispositif du plateau d'alimentation latéral dans le connecteur (50) du bureau papier.
45. Pousser le dispositif du plateau d'alimentation latéral pour le raccorder au MFP.

44. Conecte el cable de señal (49) del alimentador lateral en el conector del alimentador de papel (50).
45. Empuje el alimentador lateral para conectarlo al MFP.


44. Schließen Sie das Signalkabel (49) für den seitlichen Einzug am Papiereinzug-Steckverbinder (50) an.
45. Drücken Sie auf den seitlichen Einzug, um ihn mit dem MFP zu verbinden.

44. Collegare il cavo del segnale (49) per l'unità di alimentazione laterale nel connettore dell'unità di alimentazione carta (50).
45. Spingere l'unità di alimentazione laterale per collegarla all'MFP.

44. 将侧供纸盒的信号线 (49) 连接到供纸盒的接口 (50) 上。
45. 按住侧供纸盒, 将其与 MFP 主机连接。

44. 사이드 피더의 신호선 (49) 을 용지 급지대의 커넥터 (50) 에 접속합니다 .
45. 사이드 피더를 밀어 MFP 본체에 접속합니다 .

44. サイドフィーダーの信号線 (49) をペーパーフィーダーのコネクター (50) に接続する。
45. サイドフィーダーを押し、MFP 本体に接続する。



Setting the paper size plate and media type plate
Insert the paper size plate (G) and media type plate (H) into the each slots respectively.

Disposition des plaquettes du format de papier et du type de support
Introduire la plaquette du format de papier (G) et la plaquette du type de support (H) dans leur logement respectif.

Ajuste de la placa de tamaño de papel y la placa de tipo de medio
Inserte la placa de tamaño de papel (G) y la placa de tipo de medio (H) en cada uno de las ranuras, respectivamente.


Einsetzen der Papierformatkarte und der Medientypkarte
Setzen Sie die Papierformatkarte (G) und die Medientypkarte (H) in die jeweiligen Führungen.

Impostazione della piastra di formato carta e della piastra del tipo di supporto
Inserire la piastra del formato carta (G) e la piastra del tipo di supporto (H) nei rispettivi alloggiamenti.

纸张尺寸标示和纸张种类标示的安装
将纸张尺寸标示 (G) 和纸张种类标示 (H) 分别插入到图示的插槽中。

용지크기 플레이트와 용지종류 플레이트의 세트
용지크기 플레이트 (G) 와 용지종류 플레이트 (H) 를 각표시 슬롯에 각각 삽입한다 .

用紙サイズプレートと用紙種類プレートのセット
用紙サイズプレート (G) と用紙種類プレート (H) を各表示スロットにそれぞれ挿入する。



Changing paper size (metric specifications only)

At shipment, Letter is set for inch models and A4 is set for metric models. Use the procedure below to change the size to B5.

1. Pull out the side feeder cassette.
2. Remove a screw (1) and remove the stopper (2).

Modification du format du papier (pour spécifications métriques seulement)

À expédition, les modèles à mesure en pouces sont réglés sur le format Letter et les modèles à mesure métrique sur le format A4. Pour passer au format B5, procéder de la manière suivante.

1. Sortir le tiroir du dispositif du plateau d'alimentation latéral.
2. Déposer la vis (1) et la butée (2).

Cómo cambiar el tamaño de papel (sólo para las especificaciones métricas)

En el momento de salida de fábrica, se configura Carta para los modelos en pulgadas y A4 para los modelos en sistema métrico. Siga este procedimiento para cambiar el tamaño a B5.

1. Extraiga el cajón del alimentador lateral.
2. Quite el tornillo (1) y quite el tope (2).

Ändern des Papierformats (nur metrische Spezifikationen)

Beim Werksversand ist bei Modellen mit Zollmaß das Format Letter voreingestellt und bei Modellen mit metrischem Maß das Format A4. Das Format kann wie folgend auf B5 umgeschaltet werden.

1. Ziehen Sie die Papierlade des seitlichen Einzugs heraus.
2. Entfernen Sie eine Schraube (1) und nehmen Sie den Anschlag (2) heraus.

Cambio del formato della carta (solo per le specifiche metriche)

Al momento della spedizione, Letter è impostato per le specifiche in pollici e A4 è impostato per le specifiche metriche. Usare la procedura riportata sotto per cambiare il formato a B5.

1. Estrarre il cassetto dell'unità di alimentazione laterale.
2. Rimuovere la vite (1) e quindi rimuovere il fermo (2).

纸张尺寸更改 (仅限公制规格)

产品出厂时, 英制规格设定为 Letter、公制规格设定为 A4。要将尺寸更改为 B5 时, 请按以下步骤进行操作。

1. 拉出侧供纸盒的纸盒。
2. 拆除 1 颗螺丝 (1), 拆下挡块 (2)。

용지크기 변경 (센치 사양만)


출하시, 인치사양은 Letter, 센치사양은 A4 로 설정되어 있습니다. 크기를 B5 로 변경하는 경우에는 다음 순서를 진행해 주십시오.

1. 사이드 피더의 카세트를 빼 냅니다.
2. 나사 (1) 1 개를 제거하고 스톱퍼 (2) 를 떼어 냅니다.


[用紙サイズ変更(センチ仕様のみ)]

出荷時、インチ仕様は Letter、センチ仕様は A4 に設定されています。サイズを B5 に変更する場合は次の手順をおこなってください。

1. サイドフィーダーのカセットを引き出す。
2. ビス (1) 1 本を外し、ストップ (2) を取り外す。



3. Remove a screw (3) and remove the front deck cursor (4).



4. Move the front deck cursor (4) to match the size marking (5) (the outermost is A4, the innermost is B5) at the bottom of the cassette.
5. Fix the front deck cursor (4) using the screw (3).
6. Move the rear deck cursor (6) in the same way.

3. Déposer la vis (3) et le curseur de platine avant (4).

4. Déplacer le curseur de platine avant (4) en fonction du repère de format papier (5) (le repère le plus à l'extérieur est celui du format A4, celui le plus à l'intérieur, celui du format B5) se trouvant au fond de le tiroir.
5. Fixer le curseur de platine avant (4) à l'aide de la vis (3).
6. Déplacer le curseur de platine arrière (6) en procédant de la même manière.

3. Quite el tornillo (3) y quite el cursor frontal de la plataforma (4).

4. Mueva el cursor frontal de la plataforma (4) para que corresponda con la marca de tamaño (5) (la más externa es A4, la más interna es B5) en la parte inferior del cajón.
5. Fije el cursor frontal de la plataforma (4) usando el tornillo (3).
6. Mueva el cursor trasero de la plataforma (6) de la misma forma.

3. Entfernen Sie eine Schraube (3) und nehmen Sie den vorderen Konsole-Cursor (4) heraus.

4. Versetzen Sie den vorderen Konsole-Cursor (4), um die Formatmarkierung (5) am Boden der Papierlade anzupassen (die äußerste ist A4, die innerste ist B5).
5. Befestigen Sie den vorderen Konsole-Cursor (4) mit der Schraube (3).
6. Versetzen Sie den hinteren Konsole-Cursor (6) auf gleiche Weise.

3. Rimuovere la vite (3) e quindi rimuovere il cursore frontale del deck (4).

4. Spostare il cursore frontale del deck (4) per farlo corrispondere al segno del formato (5) (il più esterno è A4, il più interno è B5) alla parte inferiore del cassetto.
5. Fissare il cursore frontale del deck (4) utilizzando la vite (3).
6. Spostare il cursore posteriore del deck (6) alla stessa maniera.

3. 拆除 1 顆螺絲 (3)，拆下前部紙張長度調節片 (4)。


4. 根據紙盒下部的刻印 (5) (最外側為 A4、最內側為 B5) 移動前部紙張長度調節片 (4)。
5. 使用 1 顆螺絲 (3) 固定前部紙張長度調節片 (4)。
6. 按相同方法移動後部紙張長度調節片 (6)。

3. 나사 (3) 1 개를 제거하고 데크커서앞 (4) 을 제거합니다 .


4. 카세트 아래의 사이즈각인 (5) (가장 바깥쪽이 A4, 가장 안쪽이 B5) 에 맞춰 데크커서앞 (4) 을 이동시킵니다 .
5. 나사 (3) 1 개로 데크커서앞 (4) 을 고정합니다 .
6. 같은 방식으로 데크커서뒤 (6) 를 이동시킵니다 .

3. ビス (3) 1 本を外し、デッキカーソル前 (4) を取り外す。


4. カセット下のサイズ刻印 (5) (一番外側が A4、一番内側が B5) に合わせてデッキカーソル前 (4) を移動させる。
5. ビス (3) 1 本で、デッキカーソル前 (4) を固定する。
6. 同様にデッキカーソル後 (6) を移動させる。



7. Remove a screw (7) and remove the deck trailing edge cursor (8).



8. Move the deck trailing edge cursor (8) to match the size marking (9) at the bottom of the cassette.
9. Fix the deck trailing edge cursor (8) with the screw (7).



10. Reinstall the stopper (2) using the screw (1).
11. Run maintenance mode U208 and set the paper size.

7. Déposer la vis (7) et déposer le curseur du bord arrière de la platine (8).

8. Déplacer le curseur du bord arrière de la platine (8) en fonction du repère de format papier (9) se trouvant au fond de le tiroir.
9. Fixer le curseur du bord arrière de la platine (8) à l'aide de la vis (7).

10. Reposer la butée (2) à l'aide de la vis (1).
11. Exécuter le mode maintenance U208 et définir le format du papier.

7. Quite el tornillo (7) y quite el cursor del borde inferior de la plataforma (8).

8. Mueva el cursor del borde inferior de la plataforma (8) para que corresponda con la marca de tamaño (9) en la parte inferior del cajón.
9. Fije el cursor del borde inferior de la plataforma (8) con el tornillo (7).

10. Reinstale el tope (2) usando el tornillo (1).
11. Active el modo de mantenimiento U208 y ajuste el tamaño de papel.

7. Entfernen Sie eine Schraube (7) und nehmen Sie den Hinterkante-Cursor (8) heraus.

8. Versetzen Sie den Hinterkante-Cursor (8), um die Formatmarkierung (9) am Boden der Papierlade anzupassen.
9. Befestigen Sie den Hinterkante-Cursor (8) mit der Schraube (7).

10. Bringen Sie den Anschlag (2) wieder mit der Schraube (1) an.
11. Führen Sie den Wartungsmodus U208 aus und stellen Sie das Papierformat ein.

7. Rimuovere la vite (7) e quindi rimuovere il cursore del bordo finale del deck (8).

8. Spostare il cursore del bordo finale del deck (8) per farlo corrispondere al segno di formato (9) alla parte inferiore del cassetto.
9. Fissare il cursore del bordo finale del deck (8) con la vite (7).

10. Reinstallare il fermo (2) utilizzando la vite (1).
11. Eseguire la modalità manutenzione U208 e impostare il formato carta.

7. 拆除 1 顆螺絲 (7)，拆下后端紙張長度調節片 (8)。

8. 根據紙盒下部的刻印 (9) 移動后端紙張長度調節片 (8)。
9. 使用 1 顆螺絲 (7) 固定后端紙張長度調節片 (8)。

10. 使用 1 顆螺絲 (1)，按原樣安裝擋塊 (2)。
11. 執行維修模式 U208，進行紙張尺寸的設定。

7. 나사 (7) 1 개를 제거하고 데크뒤커서 (8) 를 제거합니다 .


8. 카세트 아래의 사이즈각인 (9) 에 맞춰서 데크뒤커서 (8) 를 이동시킵니다 .
9. 나사 (7) 1 개로 데크뒤커서 (8) 를 고정합니다 .

10. 나사 (1) 1 개로 스톱퍼 (2) 를 원래대로 장착합니다 .
11. 메인テナンス 모드 U208 을 실행해 용지크기 설정을 합니다 .

7. ビス (7) 1 本を外し、デッキ後端カーソル (8) を取り外す。

8. カセット下のサイズ刻印 (9) に合わせて、デッキ後端カーソル (8) を移動させる。
9. ビス (7) 1 本で、デッキ後端カーソル (8) を固定する。

10. ビス (1) 1 本で、ストップ (2) を元通り取り付ける。
11. メンテナンスモード U208 を実行し、用紙サイズの設定をおこなう。



Adjusting the cursor width

1. Load paper in the cassettes.
2. If the gap between the front deck cursor (4) and the paper (10) is outside the 0.5 to 1.0 mm range when the paper (10) is touching up against the rear deck cursor (6), perform the following adjustment.
* A cursor width that is too small can hinder paper feeding, while a cursor width that is too large can lead to problems such as skewed paper feed.

Réglage de la largeur du curseur

1. Charger les tiroirs en papier.
2. Si l'écartement entre le curseur de platine avant (4) et le papier (10) est hors des limites de 0,5 à 1,0 mm quand le papier (10) touche le curseur de platine arrière (6), procéder au réglage suivant.
* Une largeur trop faible du curseur risque d'empêcher l'entraînement du papier et une largeur trop grande risque d'entraîner des problèmes du type entraînement du papier de biais.

Cómo ajustar la anchura del cursor

1. Cargue papel en los cajones.
2. Si la separación entre el cursor frontal de la plataforma (4) y el papel (10) está fuera del rango de 0,5 a 1,0 mm cuando el papel (10) toca el cursor trasero de la plataforma (6), haga el siguiente ajuste.
* Una anchura del cursor demasiado pequeña puede impedir la alimentación de papel; una anchura del cursor demasiado grande puede provocar problemas con la alimentación torcida de papel.

Einstellen der Cursor-Breite

1. Papier in die Papierladen einlegen.
2. Falls der Abstand zwischen dem vorderen Konsole-Cursor (4) und dem Papier (10) außerhalb des Bereichs 0,5 bis 1,0 mm liegt, wenn das Papier (10) am hinteren Konsole-Cursor (6) anliegt, ist folgende Einstellung vorzunehmen.
* Eine zu kleine Cursor-Breite kann den Papiereinzug behindern, wogegen eine zu große Cursor-Breite verkanteten Papiereinzug und ähnliche Probleme verursachen kann.

Regolazione della larghezza del cursore

1. Caricare carta nei cassetti.
2. Se lo spazio tra il cursore frontale del deck (4) e la carta (10) è fuori della gamma da 0,5 a 1,0 mm quando la carta (10) tocca il cursore posteriore del deck (6), eseguire la regolazione seguente.
* Una larghezza dei cursori troppo piccola può ostacolare l'alimentazione della carta, mentre una larghezza dei cursori troppo grande può essere causa di problemi, come ad esempio l'alimentazione obliqua della carta.

游标宽度的调节


1. 在供纸盒中装入纸张。
2. 在堆纸板后部游标 (6) 与纸张 (10) 接触的状态下, 如果堆纸板前部游标 (4) 与纸张 (10) 的间隙超出了 0.5 ~ 1.0mm 的范围, 须进行以下调节。
※ 如果游标宽度过小, 可能造成不供纸, 游标宽度过大, 则可能发生歪斜进纸等情况。

커서 폭 조정

1. 카세트에 용지를 장착합니다.
2. 데크커서 뒤 (6) 에 용지 (10) 가 접하고 있는 상태에서 데크커서 앞 (4) 과 용지 (10) 의 틈이 0.5 ~ 1.0mm 의 범위외의 경우에는 이하의 조정을 합니다.
※ 커서 폭이 작으면 무급지, 커서 폭이 크면 경사급지 등이 발생할 가능성이 있습니다.

[カーソル幅の調整]

1. カセットに用紙をセットする。
2. デッキカーソル後 (6) に用紙 (10) が接している状態で、デッキカーソル前 (4) と用紙 (10) の隙間が 0.5 ~ 1.0mm の範囲外の場合は、以下の調整をおこなう。
※ カーソル幅が小さいと無給紙、カーソル幅が大きくと斜め給紙などが発生する可能性がある。



3. Loosen 2 adjusting screws (11) on the front deck cursor (4) and move the cursor (4) while checking with the scale (12).
4. Retighten the 2 adjusting screws (11).
5. Check that the gap between the front deck cursor (4) and the paper is between 0.5 and 1.0 mm.

-
3. Desserrer les 2 vis de réglage (11) sur le curseur de platine avant (4) et déposer le curseur (4) tout en vérifiant à l'aide de l'échelle (12).
 4. Resserrer les 2 vis de réglage (11).
 5. Vérifier que l'écartement entre le curseur de platine avant (4) et le papier est entre 0,5 et 1,0 mm.

-
3. Afloje 2 tornillos de ajuste (11) en el cursor frontal de la plataforma (4) y mueva el cursor (4) mientras verifica con la escala (12).
 4. Vuelva a apretar los 2 tornillos de ajuste (11).
 5. Verifique que la separación entre el cursor frontal de la plataforma (4) y el papel sea de entre 0,5 y 1,0 mm.


-
3. Lösen Sie 2 Einstellschrauben (11) am vorderen Konsole-Cursor (4) und versetzen Sie den Cursor (4) unter Beobachtung der Skale (12).
 4. Die 2 Einstellschrauben (11) wieder anziehen.
 5. Vergewissern Sie sich, dass der Abstand zwischen dem vorderen Konsole-Cursor (4) und dem Papier im Bereich 0,5 bis 1,0 mm liegt.

-
3. Allentare le 2 viti di regolazione (11) sul cursore frontale del deck (4), e quindi rimuovere il cursore (4) controllando la scala (12).
 4. Ristringere le 2 viti di regolazione (11).
 5. Controllare che lo spazio tra il cursore frontale del deck (4) e la carta sia compreso nella gamma tra 0,5 e 1,0 mm.

-
3. 拧松前部纸张长度调节片 (4) 的 2 颗调节螺丝 (11), 边确认刻度 (12) 边移动前部纸张长度调节片 (4)。
 4. 拧紧 2 颗调节螺丝 (11)。
 5. 确认堆纸板前部游标 (4) 与纸张的间隙在 0.5 ~ 1.0mm 的范围内。

-
3. 데크커서앞 (4) 의 조정나사 (11) 2 개를 풀어 눈금 (12) 을 확인하면서 데크커서앞 (4) 을 이동시킵니다 .
 4. 조정나사 (11) 2 개를 조입니다 .
 5. 데크커서 앞 (4) 과 용지의 틈이 0.5 ~ 1.0 mm 범위내가 되어 있는 것을 확인합니다 .

-
3. 데스크커솔前 (4) の調整ビス (11) 2 本を緩め、目盛り (12) を確認しながらデスクカーソル前 (4) を移動させる。
 4. 調整ビス (11) 2 本を締め付ける。
 5. 데스크カーソル前 (4) と用紙の隙間が 0.5 ~ 1.0mm の範囲内になっていることを確認する。



Adjusting the center line

Check the deviation between the center (1) of a correct image (a) and the center (2) of a test pattern.

<Reference value> Within ± 2.0 mm

1. Set the maintenance mode U034. Select LSU Out Left and Cassette5.

2. Adjust the values.

Test pattern (b): Increase the setting value.

Test pattern (c): Decrease the setting value.

3. Press the Start key to confirm the setting value.

Réglage de l'axe

Vérifier la déviation entre l'axe (1) d'une image correcte (a) et l'axe (2) d'une forme d'essai.

<Valeur de référence> $\pm 2,0$ mm max.

1. Passer au mode maintenance U034. Sélectionner LSU Out Left et Cassette5.

2. Régler les valeurs.

Mire d'essai (b): Augmentez la valeur de réglage.

Mire d'essai (c): Diminuez la valeur de réglage.

3. Appuyer sur la touche de Start pour confirmer la valeur de réglage.

Ajuste de la línea central

Compruebe la desviación entre el centro (1) de una imagen correcta (a) y el centro (2) de un patrón de prueba.

<Valor de referencia> Dentro de $\pm 2,0$ mm

1. Entre en el modo de mantenimiento U034. Seleccione LSU Out Left y Cassette5.

2. Ajuste los valores.

Patrón de prueba (b): Aumente el valor de configuración.

Patrón de prueba (c): Reduzca el valor de configuración.

3. Pulse la tecla de Start para confirmar el valor de configuración.

Einstellen der Mittelinie

Überprüfen Sie die Abweichung zwischen der Mitte (1) eines korrekten Bilds (a) und der Mitte (2) eines Prüfmusters.

<Bezugswert> Innerhalb $\pm 2,0$ mm

1. Stellen Sie den Wartungsmodus U034 ein. Wählen Sie LSU Out Left und Cassette5.

2. Die Werte einstellen.

Testmuster (b): Den Einstellwert erhöhen.

Testmuster (c): Den Einstellwert verringern.

3. Den Einstellwert durch Drücken der Start-Taste bestätigen.

Regolazione della linea centrale

Controllare la deviazione tra il centro (1) di un'immagine corretta (a) e il centro (2) di un modello di prova.

<Valore di riferimento> Entro $\pm 2,0$ mm

1. Impostare la modalità manutenzione U034. Selezionare LSU Out Left e Cassette5.

2. Regolare i valori.

Modello di prova (b): Aumentare il valore dell'impostazione.

Modello di prova (c): Diminuire il valore dell'impostazione.

3. Premere il tasto di Start per confermare il valore dell'impostazione.

中心线调节

确认标准图像 (a) 的中心位置 (1) 与测试图案的中心位置 (2) 的偏移。

<标准值> ± 2.0 mm 以内

1. 设置维修模式 U034, 选择 LSU Out Left、Cassette5。

2. 调整设定值。

测试图案 (b) : 调高设定值。

测试图案 (c) : 调低设定值。

3. 按 Start 键, 以确定设定值。

센터라인 조정

적정화상 (a) 의 센터 (1) 와 테스트패턴의 센터 (2) 의 차이를 확인합니다.

<기준치> ± 2.0 mm 이내

1. 메인テナンス 모드 U034 을 세트하고 LSU Out Left, Cassette5 를 선택합니다.

2. 설정치를 조정합니다.

테스트 패턴 (b) : 설정치를 높입니다.

테스트 패턴 (c) : 설정치를 내립니다.

3. 시작키를 누르고 설정치를 확인합니다.

センターライン調整

適正画像 (a) のセンター(1) とテストパターン(2) のずれを確認する。ずれが基準値外の場合は調整をおこなう。

<基準値> ± 2.0 mm 以内。

1. メンテナンスモード U034 をセットし、LSU Out Left、Cassette5 を選択する。

2. 設定値を調整する。

テストパターン (b) : 設定値を上げる。

テストパターン (c) : 設定値を下げる。

3. スタートキーを押し、設定値を確定する。

INSTALLATION GUIDE FOR SIDE MULTI TRAY

English

References to medium-speed MFPs in this document denote 45/45 and 55/50 ppm color machines.

References to high-speed MFPs in this document denote 65/65 and 75/70 ppm color machines, and 65 and 80 ppm monochrome machines.

Français

Dans le présent document, les références aux MFP à vitesse moyenne renvoient aux machines couleurs 45/45 et 55/50 ppm.

Dans le présent document, les références aux MFP à grande vitesse renvoient aux machines couleurs 65/65 et 75/70 ppm et aux machines monochromes 65 et 80 ppm.

Español

Las referencias a las MFP de velocidad media de este documento corresponden a las máquinas a color de 45/45 y 55/50 ppm.

Las referencias a las MFP de alta velocidad de este documento corresponden a las máquinas a color de 65/65 y 75/70 ppm y a las máquinas monocromáticas de 65 y 80 ppm.

Deutsch

Angaben für MFP der mittleren Leistungsklasse in dieser Anleitung gelten für die 45/45 und 55/50 ppm Vollfarbentkopierer.

Angaben für MFP der Hochleistungsklasse in dieser Anleitung gelten für die 65/65 und 75/70 ppm Vollfarbentkopierer sowie für die 65 und 80 ppm Monochrommaschinen.

Italiano

I riferimenti per le MFP a velocità media riportati in questo documento indicano le macchine a colori 45/45 e 55/50 ppm.

I riferimenti per le MFP a velocità alta riportati in questo documento indicano le macchine a colori 65/65 e 75/70 ppm, e le macchine monocromatiche 65 e 80 ppm.

简体中文

本文中的中速 MFP 代表彩色 45/45 页机型、55/50 页机型。

本文中的高速 MFP 代表彩色 65/65 页机型、75/70 页机型、黑白 65 页机型、80 页机型。

한국어


본문 중 중속 MFP 는 컬러 45/45 매기 , 55/50 매기 .

본문 중 고속 MFP 는 컬러 65/65 매기 , 75/70 매기 , 흑백 65 매기 , 80 매기를 나타냅니다 .

日本語

本文中の中速 MFP はカラー機の 45/45 枚機、55/50 枚機を表す。

本文中の高速 MFP はカラー機の 65/65 枚機、75/70 枚機、モノクロ機の 65 枚機、80 枚機を表す。



Supplied parts

A. Side multi-tray 1
 B. Large base slider 1
 C. Small base slider 1
 D. Lock pin 2
 E. Switch press plate 2
 F. M4 × 8 screw 10

G. Paper size plate 2
 H. Media type plate(except for 120V model) .. 7
 H. Media type plate(120V model only) 4
 I. Cover plate 1
 J. M4 × 10 tapping screw..... 1
 K. Stopper 2
 L. Cassette Number Label 6 1

M. Cassette Number Label 7 1
 N. Clamp 2
 O. Film 1
 Be sure to remove any tape and/or cushioning material from supplied parts.

Pièces fournies

A. Bac multiples usages latéral 1
 B. Grande règle de base 1
 C. Petite règle de base 1
 D. Broche de verrouillage 2
 E. Plaque de pression de l'interrupteur 1
 F. Vis M4 × 8 10

G. Plaquette du format de papier 2
 H. Plaquette du type de support 7
 I. Capot 1
 J. Vis de connexion M4 × 10 1
 K. Butée 2
 L. Étiquette de numéro de cassette 6 1
 M. Étiquette de numéro de cassette 7 1

N. Collier 2
 O. Film 1
 Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.

Partes suministradas

A. Multi-bandeja lateral 1
 B. Deslizador de base grande 1
 C. Deslizador de base pequeño 1
 D. Clavija de bloqueo 2
 E. Placa de presión del interruptor 1
 F. Tornillo M4 × 8 10

G. Placa de tamaño de papel 2
 H. Placa de tipo de medio 7
 I. Tapa 1
 J. Tornillo de roscado M4 × 10 1
 K. Tope 2
 L. Etiqueta de casete con el número 6 1
 M. Etiqueta de casete con el número 7 1

N. Abrazadera 2
 O. Película 1
 Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.

Gelieferte Teile

A. Seitliches Mehrzweck-Papierfach 1
 B. Großer Basis-Schieber 1
 C. Kleiner Basis-Schieber 1
 D. Arretierstift 2
 E. Schalterdruckplatte 1
 F. M4 × 8 Schraube 10

G. Papierformatkarte 2
 H. Medientypkarte 7
 I. Abdeckplatte 1
 J. M4 × 10 Schneidschraube 1
 K. Anschlag 2
 L. Aufkleber Kassettensnummer 6 1
 M. Aufkleber Kassettensnummer 7 1

N. Schelle 2
 O. Film 1
 Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.

Parti di forniture

A. Vassoio multiplo laterale 1
 B. Scivolo di base grande 1
 C. Scivolo di base piccolo 1
 D. Perno di bloccaggio 2
 E. Piastra spingi interruttore 1
 F. Vite M4 × 8 10

G. Piastra formato carta 2
 H. Piastra tipo carta 7
 I. Coperchio 1
 J. Vite autofilettante M4 × 10 1
 K. Fermo 2
 L. Etichetta numero cassetta 6 1
 M. Etichetta numero cassetta 7 1

N. Fascetta 2
 O. Pellicola 1
 Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.

附属品

A. 側手送紙盤 1
 B. 底座滑板(大) 1
 C. 底座滑板(小) 1
 D. 鎖定插銷 2
 E. 開關擋板 1
 F. M4×8 螺絲 10

G. 紙張尺寸標示 3
 H. 紙張種類標示 2
 I. 蓋板 1
 J. M4×10 自攻螺絲 1
 K. 擋塊 2
 L. 紙盒編號標籤 6 1
 M. 紙盒編號標籤 7 1

N. 束線夾 2
 O. 膠片 1
 如果附属品上帶有固定膠帶, 緩衝材料時務必揭下。

동봉품

A. 사이드 멀티 트레이 1
 B. 베이스 슬라이더 대 1
 C. 베이스 슬라이더 소 1
 D. 잠금 핀 2
 E. 스위치 판 1
 F. 나사 M4×8 10

G. 용지크기 플레이트 2
 H. 용지종류 플레이트 2
 I. 커버 플레이트 1
 J. 탭핑 나사 M4×10 1
 K. 스톱퍼 2
 L. 카세트 넘버 라벨 6 1
 M. 카세트 넘버 라벨 7 1


N. 클램프 2
 O. 필름 1
 동봉품에 고정 테이프, 완충재가 붙어 있는 경우에는 반드시 제거할 것 .

PF-780 同梱品

A. サイドマルチトレイ 1
 B. ベーススライダ-大 1
 C. ベーススライダ-小 1
 D. ロックピン 2
 E. スイッチ当たり板 1
 F. ビス M4×8 10

G. 用紙サイズプレート 2
 H. 用紙種類プレート 2
 I. カバープレート 1
 J. タッピングビス M4×10 1
 K. ストッパー 2
 L. カセットナンバーラベル 6 1
 M. カセットナンバーラベル 7 1

N. クランプ 2
 O. フィルム 1
 同梱品に固定テープ, 緩衝材がついている場合は, 必ず取り外すこと。



PF-730/740 Supplied parts

P. Paper feeder	1
Q. Pin	2
R. Retainer	1
S. Intermediate paper conveying unit	1
T. Clamp	1
U. Wire cover	1

V. Paper size plate	4
W. S Tite screw M4 x 8	3
X. Media type plate (120V model only)	6
X. Media type plate (PF-730:110V model only)	2
X. Media type plate (except for above models)	12

Y. Stopper	2
Z. S Tite screws M4 x 20	4

Be sure to remove any tape and/or cushioning material from supplied parts.

Do not use the following parts when installing PF-780: (R), (Y), (Z) and one (W).

PF-730/740 Pièces fournies

P. Bureau papier	1
Q. Broche	2
R. Élément de retenue	1
S. Unité de transport du papier intermédiaire	1
T. Collier	1
U. Couvercle de câble	1

V. Plaquette du format de papier	4
W. Vis S Tite M4 x 8	3
X. Plaquette du type de support	12
Y. Butée	2
Z. Vis S Tite M4 x 20	4

Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies

Ne pas utiliser les pièces suivantes pour l'installation de la PF-780 : (R), (Y), (Z) et un (W).

PF-730/740 Partes suministradas

P. Alimentador de papel	1
Q. Clavija	2
R. Retén	1
S. Unidad de transporte de papel intermedia	1
T. Sujetador	1
U. Cubierta para el cable	1

V. Placa de tamaño de papel	4
W. Tornillo S Tite M4 x 8	3
X. Placa de tipo de medio	12
Y. Tope	2
Z. Tornillos S Tite M4 x 20	4

Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.

No utilice las piezas siguientes cuando instale la PF-780: (R), (Y), (Z) y una (W).

PF-730/740 Gelieferte Teile

P. Papiereinzug	1
Q. Stift	2
R. Halterung	1
S. Eingesetzte Papierfördereinheit	1
T. Klemme	1
U. Kabelabdeckung	1

V. Papierformatkarte	4
W. S-Tite-Schraube M4 x 8	3
X. Medientypkarte	12
Y. Anschlag	2
Z. S-Tite-Schrauben M4 x 20	4

Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.

Die folgenden Teile bei der Installation von PF-780 nicht verwenden: (R), (Y), (Z) und ein (W).

PF-730/740 Parti di forniture

P. Unità di alimentazione della carta	1
Q. Perno	2
R. Fermo	1
S. Unità intermediale di trasporto carta	1
T. Morsetto	1
U. Coperchio cavi	1

V. Piastra formato carta	4
W. Vite S Tite M4 x 8	3
X. Piastra tipo carta	12
Y. Fermo	2
Z. Vite S Tite M4 x 20	4

Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.

Non utilizzare le seguenti parti quando si installa PF-780: (R), (Y), (Z) e uno (W).

PF-730/740 附属品

P. 供纸工作台	1
Q. 固定插销	2
R. 安装板	1
S. 中间搬运单元	1
T. 夹钳	1

U. 电线盖板	1
V. 纸张尺寸标示 (PF-730)	6
V. 纸张尺寸标示 (PF-740)	4
W. 紧固型 S 螺丝 M4x8	3
X. 纸张种类标示	2
Y. 限位器	2

Z. 紧固型 S 螺丝 M4 x 20

如果附属品上带有固定胶带, 缓冲材料时务必揭下。

设置 PF-780 时, 不使用以下部件: (R) (Y) (Z) 和 1 颗 (W)

PF-730/740 동봉품

P. 급지대	1
Q. 핀	2
R. 부착판	1
S. 중간반송유닛	1
T. 크램프	1

U. 전선커버	1
V. 용지크기 플레이트	4
W. 나사 M4x8S 타이트	3
X. 용지종류 플레이트	2
Y. 전도방지쇠	2
Z. 나사 M4x20 S 타이트	4

동봉품에 고정 테이프, 완충재가 붙어 있는 경우에는 반드시 제거할 것.

PF-780 을 설치할 경우에는 하기 부품은 사용하지 않음 : (R) (Y) (Z) 과 (W) 1 개



PF-730/740 同梱品

P. 페ーパー피더	1
Q. 핀	2
R. 取付板	1
S. 中间搬送ユニット	1
T. 클램프	1
U. 電線カバー	1

V. 用紙サイズプレート	4
W. ビス M4x8S タイト	3
X. 用紙種類プレート	2
Y. 転倒防止金具	2
Z. ビス M4x20 S タイト	4

同梱品に固定テープ, 緩衝材が付いている場合は必ず取り外すこと。

PF-780 を設置する場合は, 下記のパーツは使用しない: (R) (Y) (Z) と (W) 1 本



Procedure

Be sure to turn the MFP main power switch off and disconnect the MFP power plug from the wall outlet before starting to install the side feeder.

[Side feeder assembly]

- 1.Remove the capot (1) of the paper feeder (P).
(Do not use cover (1).)

- 2.Cut the ribs with a nipper, and then remove the breakaway cover (2).

Procédure

Veiller à bien mettre l'interrupteur principal du MFP hors tension et à débrancher la fiche d'alimentation du MFP de la prise murale avant de commencer l'installation du plateau d'alimentation latéral.

[Ensemble plateau d'alimentation latéral]

- 1.Déposer le capot (1) du bureau papier (P).
(Ne pas utiliser le capot (1).)

- 2.Couper les nervures avec une pince, puis déposer le couvercle amovible (2)

Procedimiento

Asegúrese de apagar el interruptor principal del MFP y de desconectar el enchufe del MFP del receptáculo de pared antes de empezar a instalar el alimentador lateral.

[Ensamblaje del alimentador lateral]

- 1.Quite la cubierta (1) del alimentador de papel (P).
(No utilice la cubierta (1).)

- 2.Recorte las nervaduras con unos alicates de corte y, a continuación, retire la cubierta divisoria (2).

Verfahren

Schalten Sie unbedingt den Hauptschalter des MFP aus, und ziehen Sie den Netzstecker des MFP von der Netzsteckdose ab, bevor Sie mit der Installation des seitlichen Einzugs beginnen.

[Seitlicher Einzug]

- 1.Die Abdeckung (1) des Papiereinzugs (P) abnehmen.
(Die Abdeckung (1) nicht verwenden.)

- 2.Die Rippen mit einer Zange schneiden und dann die Ablösungsabdeckung (2) entfernen.

Procedura

Prima di iniziare la procedura di installazione dell'unità di alimentazione laterale, assicurarsi di spegnere l'interruttore principale di alimentazione dell'MFP, e di scollegare la spina del cavo di alimentazione dalla presa elettrica a muro.

[Assemblaggio unità di alimentazione laterale]

- 1.Rimuovere il coperchio (1) dall'unità di alimentazione della carta (P).
(Non usare il coperchio (1).)

- 2.Tagliare le pieghe con una pinzetta e poi rimuovere il coperchio di distacco (2).

安装步骤

安装侧供纸盒时，必须先关闭 MFP 主机上的主电源开关，并拔出电源插头后方可进行工作。

[侧供纸盒的装配]

1. 拆下供纸工作台 (P) 的盖板 (1)。
(不使用盖板 (1))

2. 使用剪钳切断肋板，切除切割盖板 (2)。

설치순서

사이드피더를 설치할 때에는 반드시 MFP 본체의 주전원 스위치를 OFF 로 하고 전원 플러그를 뽑아 후 작업을 할 것 .

[사이드 피더 조립]

1. 용지 급지대 (P) 의 커버 (1) 을 제거합니다 .
(커버 (1) 은 사용하지 않습니다 .)

2. 니퍼로 리브를 자르고 분할커버 (2) 를 떼어 냅니다 .


取付手順

サイドフィーダーを設置するときは、必ず MFP 本体の主電源スイッチを OFF にし、電源プラグを抜いてから作業すること。


[サイドフィーダーの組み立て]

1. ペーパーフィーダー(P)のカバー(1)を取り外す。
(カバー(1)は使用しません。)

2. ニッパーでリブを切り、割りカバー(2)を切り取る。



3. Remove the panel (3) from the lower right cover (4) on the paper feeder using a flat blade screwdriver.



4. Open the paper feeder right cover (5).
Remove the strap (6) from the right cover shaft (7) and remove the right cover (5).

3. Déposer le panneau (3) du capot inférieur droit (4) du bureau papier en procédant à l'aide d'un tournevis à lame.

4. Ouvrir le couvercle droit du bureau papier (5).
Déposer la courroie (6) de l'axe du capot droit (7) et déposer le capot droit (5).

3. Quite el panel (3) de la cubierta derecha inferior (4) del alimentador de papel con un destornillador de pala plana.

4. Abra la cubierta derecha del alimentador de papel (5).
Quite la correa (6) del eje de la cubierta derecha (7) y quite la cubierta derecha (5).

3. Nehmen Sie mit einem flachen Schraubendreher die Platte (3) von der unteren rechten Abdeckung (4) des Papiereinzugs ab.

4. Die rechte Abdeckung (5) des Papiereinzugs öffnen.
Nehmen Sie den Riemen (6) von der Welle (7) der rechten Abdeckung und dann die rechte Abdeckung (5) ab.

3. Rimuovere il pannello (3) dal coperchio destro inferiore (4) sull'unità di alimentazione carta utilizzando un cacciavite a testa piana.

4. Aprire il coperchio destro (5) dell'unità di alimentazione della carta.
Rimuovere la cinghietta (6) dall'asta (7) del coperchio destro e quindi rimuovere il coperchio destro (5).

3. 使用一字螺丝刀等将供纸盒的右下部盖板 (4) 的盖子 (3) 拆下。


4. 打开供纸盒的右部盖板 (5)。
从右盖板的轴 (7) 上拆除挂绳 (6), 拆下右盖板 (5)。

3. 용지 급지대의 우측 하단커버 (4) 의 뚜껑 (3) 을 마이너스 드라이버 등으로 떼어 냅니다 .

4. 급지대 우측커버 (5) 를 엽니다 .
스트랩 (6) 을 우측커버의 축 (7) 에서 떼어내고 우측커버 (5) 를 제거합니다 .

3. ペーパーフィーダーの右下カバー (4) のふた (3) をマイナスドライバーなどで取る。

4. ペーパーフィーダーの右カバー (5) を開く。
ストラップ (6) を右カバーの軸 (7) から外し、右カバー (5) を取り外す。



For PF-730

5. Remove 3 screws (8) and a screw (9) and remove the paper feeder lower right cover (4).

For PF-740

5. Remove 3 screws (8) and a screw (10) and remove the paper feeder lower right cover (4).

Pour PF-730

5. Déposer les 3 vis (8) et la vis (9) puis déposer le capot inférieur droit du bureau papier (4).

Pour PF-740

5. Déposer les 3 vis (8) et la vis (10) puis déposer le capot inférieur droit du bureau papier (4).

Para PF-730

5. Quite los 3 tornillos (8) y el tornillo (9) y quite la cubierta derecha inferior del alimentador de papel (4).

Para PF-740

5. Quite los 3 tornillos (8) y el tornillo (10) y quite la cubierta derecha inferior del alimentador de papel (4).

Für PF-730

5. Entfernen Sie 3 Schrauben (8) und eine Schraube (9) und nehmen Sie die untere rechte Abdeckung (4) des Papiereinzugs ab.

Für PF-740

5. Entfernen Sie 3 Schrauben (8) und eine Schraube (10) und nehmen Sie die untere rechte Abdeckung (4) des Papiereinzugs ab.

Per PF-730

5. Rimuovere le 3 viti (8) e una vite (9), e quindi rimuovere il coperchio destro inferiore (4) dell'unità di alimentazione carta.

Per PF-740

5. Rimuovere le 3 viti (8) e una vite (10), e quindi rimuovere il coperchio destro inferiore (4) dell'unità di alimentazione carta.

PF-730 时

5. 拆除 3 颗螺丝 (8) 和 1 颗螺丝 (9), 拆下供纸盒的右下部盖板 (4)。

PF-740 时

5. 拆除 3 颗螺丝 (8) 和 1 颗螺丝 (10), 拆下供纸盒的右下部盖板 (4)。

PF-730 의 경우

5. 나사 (8) 3 개와 나사 (9) 1 개를 제거하고, 용지 급지대의 우측 하단커버 (4) 를 제거합니다.

PF-740 의 경우


5. 나사 (8) 3 개와 나사 (10) 1 개를 제거하고, 용지 급지대의 우측 하단커버 (4) 를 제거합니다.

PF-730 の場合

ビス (8) 3 本とビス (9) 1 本を外して、ペーパーフィーダーの右下カバー (4) を取り外す。

PF-740 の場合

5. ビス (8) 3 本とビス (10) 1 本を外して、ペーパーフィーダーの右下カバー (4) を取り外す。



6. Align the 2 paper feeder casters (11) in the direction shown in the illustration, and fasten each of them to stopper (K) using a screw (F).

7. Reinstall the paper feeder lower right cover (4).

8. Reinstall the paper feeder right cover (5).

6. Aligner les 2 roulettes (11) du bureau papier selon la direction indiquée sur l'illustration, et les fixer sur la butée (K) à l'aide d'une vis (F).

7. Reposer le capot inférieur droit du bureau papier (4).

8. Reposer le capot droit du bureau papier (5).

6. Alinee las 2 ruedas del alimentador de papel (11) en el sentido que se indica en la ilustración, y apriételas hasta llegar al tope (K) con un tornillo (F).

7. Reinstale la cubierta derecha inferior del alimentador de papel (4).

8. Reinstale la cubierta derecha del alimentador de papel (5).

6. Die 2 Laufrollen des Papiereinzugs (11) in der in der Abbildung angezeigten Richtung ausrichten und jede von ihnen mithilfe einer Schraube (F) am Anschlag (K) befestigen.

7. Bringen Sie die untere rechte Abdeckung (4) des Papiereinzugs wieder an.

8. Bringen Sie die rechte Abdeckung (5) des Papiereinzugs wieder an.

6. Allineare le ruote orientabili dell'unità di alimentazione della carta (11) nella direzione mostrata nell'illustrazione e stringere ognuno al fermo (K) con una vite (F).

7. Reinstallare il coperchio destro inferiore dell'unità di alimentazione carta (4).

8. Reinstallare il coperchio destro (5) dell'unità di alimentazione carta.

6. 将供纸工作台的 2 个脚轮 (11) 与图示方向对齐, 各使用 1 颗螺丝 (F) 来安装挡块 (K)。

7. 按原样安装供纸盒的右下部盖板 (4)。

8. 按原样安装供纸盒的右盖板 (5)。

6. 용지 급지대의 캐스터 (11) 2 개를 일러스트의 방향에 맞춰 각각 스톱퍼 (K) 를 나사 (F) 1 개로 장착합니다.


7. 용지 급지대의 우측 하단커버 (4) 를 원래대로 장착합니다.

8. 용지 급지대의 우측커버 (5) 를 원래대로 장착합니다.


6. ペーパーフィーダーのキャスター(11)2 個をイラストの方向に合わせ、それぞれストッパー(K)をビス(F)1 本で取り付け。

7. ペーパーフィーダーの右下カバー(4) を元通り取り付け。


8. ペーパーフィーダーの右カバー(5) を元通り取り付け。



9. Pull out the cassette of the side multi-tray, remove a lift plate stopper (12) and attach it in the storage location (13).



10. Remove a pin (14) and remove the cassette (15) of the side multi-tray (A).



11. Place the side multi-tray on the paper feeder (P) so that each pin (16) on the right and left sides of the front of the paper feeder (P) matches with the holes (17) in the base of the side multi-tray (A).

9. Tirer la cassette du bac multiples usages latéral vers l'extérieur, retirer la butée de plaque d'élévation (12) et la fixer à l'emplacement de rangement (13).

10. Retirer la broche (14) et déposer la cassette (15) du bac multiples usages latéral (A).

11. Placer le bac multiples usages latéral sur le bureau papier (P) de sorte à aligner chacune des broches (16) situées sur les côtés droit et gauche du devant du bureau papier (P) avec les orifices (17) de la base du bac multiples usages latéral (A).

9. Saque el casete de la multi-bandeja lateral, quite el tope de placa de elevación (12) y póngalo en el espacio reservado para guardarlo (13).

10. Quite el pasador (14) y saque el casete (15) de la multi-bandeja lateral (A).

11. Coloque la multi-bandeja lateral sobre el alimentador de papel (P) de tal manera que los pasadores (16) que se encuentran a izquierda y derecha en la parte delantera del alimentador de papel (P) coincidan con los agujeros (17) que hay en la base de la multi-bandeja lateral (A).

9. Die Kasette aus dem seitlichen Mehrzweck-Papierfach herausziehen, den Hebelplattenanschlag (12) entfernen und an der Speicherposition (13) anbringen.

10. Den Stift (14) und die Kasette (15) des seitlichen Mehrzweck-Papierfachs (A) herausnehmen.

11. Das seitliche Mehrzweck-Papierfach auf dem Papiereinzug (P) so platzieren, dass jeder Stift (16) auf der linken und rechten Vorderseite des Papiereinzugs (P) mit den Öffnungen (17) am Boden des seitlichen Mehrzweck-Papierfachs (A) übereinstimmt.

9. Estrarre il cassetto del vassoio multiplo laterale, rimuovere il fermo della piastra di sollevamento (12) e collegarlo nella posizione di stoccaggio (13).

10. Rimuovere una puntina (14) e rimuovere la cassetta (15) del vassoio multiplo laterale (A).

11. Porre il vassoio multiplo laterale sull'unità di alimentazione della carta (P) in modo che ogni punta (16) a destra e sinistra davanti all'unità di alimentazione della carta (P) corrisponda i fori (17) nella base del vassoio multiplo laterale (A).

9. 拉出侧手送纸盘的纸盒, 拆除 1 个升降板挡块 (12) 并将其安装到保存场所 (13)。

10. 拆除 1 枚插销 (14), 拆下侧手送纸盘 (A) 的纸盒 (15)。

11. 将供纸工作台 (P) 左右前方的各插销 (16) 与侧手送纸盘 (A) 的底座孔 (17) 对齐, 将侧手送纸盘 (A) 放在供纸工作台 (P) 上。

9. 사이드 멀티 트레이 카세트를 빼 내고 리프트판 스톱퍼 (12) 1 개를 빼 내어 보관장소 (13) 에 장착합니다 .


10. 핀 (14) 1 개를 떼어내 사이드 멀티 트레이 (A) 의 카세트 (15) 를 떼어 냅니다 .

11. 용지 급지대 (P) 의 좌우전방의 각 핀 (16) 과 사이드 멀티 트레이 (A) 의 베이스 구멍 (17) 이 맞도록 용지 급지대 (P) 에 사이드 멀티 트레이 (A) 를 얹습니다 .


9. サイドマルチトレイのカセットを引き出し、リフト板ストッパー (12) 1 個を外して保管場所 (13) に取り付ける。

10. ピン (14) 1 本を外しサイドマルチトレイ (A) のカセット (15) を取り外す。

11. ペーパーフィーダー (P) の左右前方の各ピン (16) とサイドマルチトレイ (A) のベースの穴 (17) が合うように、ペーパーフィーダー (P) にサイドマルチトレイ (A) を載せる。




12. Attach side multi-tray (A) to paper feeder (P) using 2 pins (Q).



13. Pull out the cassette rail (18) of the side multi-tray (A).

14. Mount the hooks (19) of the rail (18) to the hole (20) of the cassette (15), and replace the cassette (15).

15. Fasten the cassette (15) using a pin (14) removed in step 10.



16. Open the right cover (21) of the side multi-tray (A).

17. Remove the strap (22) from the right cover shaft (23) and remove the right cover (21).

12. Fixer le bac multiples usages latéral (A) au bureau papier (P) à l'aide de 2 broches (Q).

13. Tirer la glissière (18) de la cassette du bac multiples usages latéral (A) vers l'extérieur.

14. Monter les crochets (19) de la glissière (18) dans les orifices (20) de la cassette (15), et remettre la cassette (15) en place.

15. Fixer la cassette (15) à l'aide de la broche (14) déposée à l'étape 10.

16. Ouvrir le capot de droite (21) du bac multiples usages latéral (A).

17. Déposer la courroie (22) de l'axe du capot droit (23) et déposer le capot droit (21).

12. Sujete la multi-bandeja lateral (A) al alimentador de papel (P) utilizando 2 pasadores (Q).

13. Saque el carril del casete (18) de la multi-bandeja lateral (A).

14. Pase los ganchos (19) del carril (18) por el agujero (20) del casete (15) y sustituya el casete (15).

15. Apriete el casete (15) con el pasador (14) que quitó en el paso 10.

16. Abra la cubierta derecha (21) de la multi-bandeja lateral (A).

17. Quite la correa (22) del eje de la cubierta derecha (23) y quite la cubierta derecha (21).

12. Das seitliche Mehrzweck-Papierfach (A) mithilfe der 2 Stifte (Q) am Papiereinzug (P) befestigen.

13. Die Kassettenschiene (18) des seitlichen Mehrzweck-Papierfachs (A) herausziehen.

14. Die Haken (19) der Schiene (18) an der Öffnung (20) der Kassette (15) montieren und die Kassette wieder anbringen (15).

15. Die Kassette (15) mit dem in Schritt 10 entfernten Stift (14) befestigen.

16. Die rechte Abdeckung (21) des seitlichen Mehrzweck-Papierfachs (A) öffnen.

17. Nehmen Sie den Riemen (22) von der Welle (23) der rechten Abdeckung und dann die rechte Abdeckung (21) ab.

12. Collegare il vassoio multiplo laterale (A) all'unità di alimentazione della carta (P) utilizzando 2 puntine (Q).

13. Estrarre la cassetta (18) dal vassoio multiplo laterale (A).

14. Montare i ganci (19) della pista (18) al foro (20) della cassetta (15) e sostituire la cassetta (15).

15. Stringere la cassetta (15) utilizzando una puntina (14) rimossa nel passo 10.

16. Aprire il pannello destro (21) del vassoio multiplo laterale (A).

17. Rimuovere la cinghietta (22) dall'asta (23) del coperchio destro e quindi rimuovere il coperchio destro (21).

12. 使用 2 枚插销 (Q) 将侧手送纸盘 (A) 固定在供纸工作台 (P) 上。

13. 拉出侧手送纸盘 (A) 的纸盒导轨 (18)。

14. 将导轨 (18) 的卡爪 (19) 插入纸盒 (15) 的孔 (20) 中, 按原样安装纸盒 (15)。

15. 使用在步骤 10 中拆除的 1 枚插销 (14) 来固定纸盒 (15)。

16. 打开侧手送纸盘 (A) 的右部盖板 (21)。

17. 从右盖板的轴 (23) 上拆除挂绳 (22), 拆下右盖板 (21)。

12. 핀 (Q) 2 개로 사이드 멀티 트레이 (A) 를 용지 급지대 (P) 에 고정합니다 .

13. 사이드 멀티 트레이 (A) 의 카세트 레일 (18) 을 빼 냅니다 .

14. 레일 (18) 의 후크 (19) 를 카세트 (15) 의 구멍 (20) 에 끼우고 카세트 (15) 를 원래대로 장착합니다 .

15. 순서 10 에서 떼어낸 핀 (14) 1 개로 카세트 (15) 를 고정합니다 .

16. 사이드 멀티 트레이 (A) 의 우측커버 (21) 를 엽니다 .

17. 스트랩 (22) 을 우측커버의 축 (23) 에서 떼어내고 우측커버 (21) 를 제거합니다 .

12. 핀 (Q) 2 本でサイドマルチトレイ (A) をペーパーフィーダー (P) に固定する。


13. サイドマルチトレイ (A) のカセットレール (18) を引き出す。

14. レール (18) のフック (19) をカセット (15) の穴 (20) にはめ込み、カセット (15) を元通り取り付け。


15. 手順 10 で外したピン (14) 1 本でカセット (15) を固定する。

16. サイドマルチトレイ (A) の右カバー (21) を開く。


17. ストラップ (22) を右カバーの軸 (23) から外し、右カバー (21) を取り外す。



18. Open the paper feeder right cover (24).



19. Insert the intermediate paper conveying unit (S) in order of 25 to 26 on the illustration.



20. Secure the intermediate paper conveying unit (S) with the 2 screws (W).

18. Ouvrir le couvercle droit du bureau papier (24).

19. Insérer l'unité de transport du papier intermédiaire (S) en suivant l'ordre 25 à 26 indiqué sur l'illustration.

20. Fixer l'unité de transport du papier intermédiaire (S) à l'aide des 2 vis (W).

18. Abra la cubierta derecha del alimentador de papel (24).

19. Inserte la unidad de transporte de papel intermedia (S) siguiendo el orden de 25 a 26 de la ilustración.

20. Asegure la unidad de transporte de papel intermedia (S) con los 2 tornillos (W).

18. Die rechte Abdeckung (24) des Papierinzugs öffnen.

19. Die eingesetzte Papierfördereinheit (S) in der in der Abbildung gezeigten Reihenfolge 25 bis 26 einbauen.

20. Die eingesetzte Papierfördereinheit (S) mit den 2 Schrauben (W) sichern.

18. Aprire il pannello destro (24) dell'unità di alimentazione della carta.

19. Inserire l'unità intermediale di trasporto carta (S) da 25 a 26 sull'illustrazione.

20. Fissare l'unità intermediale di trasporto carta (S) con le 2 viti (W).

18. 打开供纸盒的右部盖板 (24)。

19. 将中间搬运单元 (S) 按如图所示先插入 25, 再插到 26。

20. 使用 2 颗螺丝 (W) 来固定中间搬运单元 (S)。

18. 금지대 우측커버 (24) 를 엽니다 .


19. 중간반송 유닛 (S) 를 일러스트 와 같이 25, 26 의 순으로 삽입합니다 .

20. 나사 (W) 2 개로 중간반송유닛 (S) 를 고정합니다 .


18. ペーパーフィーダーの右カバー(24)を開く。

19. 中間搬送ユニット(S)をイラストのように 25 から 26 の順で挿入する。


20. ビス (W) 2 本で中間搬送ユニット (S) を固定する。



21. Connect the intermediate paper conveying unit connector (27).
22. Attach the clamp (T) and secure the connector wire.



23. Insert the projection (28) of the wire cover (U) into the hole (29) in the intermediate paper conveying unit, and attach the wire cover (U).
24. Replace the right cover (21) of the side multi-tray (A).
25. Close the right cover of the paper feeder (24).



26. Remove the screw (30) in the rear of the paper feeder and remove the cover (31).

21. Raccorder le connecteur (27) de l'unité de transport du papier intermédiaire.
22. Monter le collier (T) et fixer le câble du connecteur.

23. Insérer la saillie (28) du couvercle de câble (U) dans l'orifice (29) de l'unité de transport du papier intermédiaire, et fixer le couvercle de câble (U).
24. Remettre le capot de droite (21) du bac multiples usages latéral (A) en place.
25. Fermer le capot de droite du bureau papier (24).

26. Déposer la vis (30) à l'arrière du bureau papier et déposer le couvercle (31).

21. Conecte el conector de la unidad de transporte de papel intermedia (27).
22. Fije el sujetador (T) y asegure el cable del conector.

23. Introduzca el resalto (28) de la cubierta para el cable (U) por el agujero (29) de la unidad de transporte de papel intermedia y sujete la cubierta para el cable (U).
24. Sustituya la cubierta derecha (21) de la multi-bandeja lateral (A).
25. Cierre la cubierta derecha del alimentador de papel (24).

26. Quite el tornillo (30) del lado trasero del alimentador de papel y quite la cubierta (31).

21. Den Steckverbinder (27) der eingesetzten Papierfördereinheit anschließen.
22. Die Klemme (T) anbringen und das Kabel des Steckverbinders sichern.

23. Die Nase (28) der Kabelabdeckung (U) in die Öffnung (29) in der eingesetzten Papierfördereinheit einsetzen und die Kabelabdeckung (U) befestigen.
24. Die rechte Abdeckung (21) des seitlichen Mehrzweck-Papierfachs (A) wieder anbringen.
25. Die rechte Abdeckung des Papiereinzugs (24) schließen.

26. Die Schraube (30) an der Rückseite des Papiereinzugs entfernen und die Abdeckung (31) abnehmen.

21. Collegare il connettore (27) dell'unità intermediale di trasporto carta.
22. Applicare il morsetto (T) e fissare il cavo del connettore.

23. Inserire la proiezione (28) del coperchio cavi (U) nel foro (29) dell'unità intermediale di trasporto carta e collegare il coperchio cavi (U).
24. Sostituire il pannello destro (21) del vassoio multiplo laterale (A).
25. Chiudere il pannello destro dell'unità di alimentazione della carta (24).

26. Rimuovere la vite (30) nel retro dell'unità di alimentazione della carta e quindi rimuovere il coperchio (31).

21. 连接中间搬运单元的接插件 (27)。
22. 安装夹钳 (T)，以固定接插件电线。

23. 将电线盖板 (U) 的突起 (28) 插入中间搬运单元的孔 (29) 中，安装电线盖板 (U)。
24. 按原样安装侧手送纸盘 (A) 的右部盖板 (21)。
25. 关闭供纸工作台的右部盖板 (24)。

26. 拆除供纸盒后部的 1 颗螺丝 (30)，拆下盖板 (31)。

21. 중간반송유니트의 커넥터 (27) 를 접속합니다.
22. 클램프 (T) 를 부착, 커넥터 전선을 고정합니다.


23. 전선커버 (U) 의 돌기 (28) 를 중간반송유니트의 구멍 (29) 에 넣고 전선커버 (U) 를 장착합니다.
24. 사이드 멀티 트레이 (A) 의 우측커버 (21) 를 원래대로 장착합니다.
25. 용지 금지대의 우측커버 (24) 를 닫습니다.

26. 금지대 후면의 뒤쪽 나사 (30) 1 개를 제거하고 커버 (31) 를 떼어 냅니다.

21. 中間搬送ユニットのコネクター(27) を接続する。
22. クランプ (T) を取り付け、コネクター電線を固定する。


23. 電線カバー (U) の突起 (28) を中間搬送ユニットの穴 (29) に入れて、電線カバー (U) を取り付ける。
24. サイドマルチトレイ (A) の右カバー (21) を元通りに取り付ける。
25. ペーパーフィーダーの右カバー (24) を閉じる。

26. ペーパーフィーダー後側のビス (30) 1 本を外し、カバー (31) を取り外す。



27. Connect the power cord (32) and the signal cable (33) to connectors (34) (35) respectively on the Side multi-tray.

28. Replace the cover (31) using the screw (30) removed in step 26.



**[Connecting the side feeder to the MFP]
Installation on medium-speed MFPs**

If installing on a high-speed MFP, proceed to step 13.

1. Open the lower right cover (1) on the MFP. Remove the strap (2) from the shaft (3) and remove lower right cover (1).

27. Raccorder respectivement le cordon d'alimentation (32) et le câble à signal (33) aux connecteurs (34) (35) du Bac multiples usages latéral.

28. Reposer le couvercle (31) à l'aide de la vis (30) déposée à l'étape 26.

[Connexion du plateau d'alimentation latéral au MFP]

Montage sur des MFP à vitesse moyenne

Si le montage est fait sur un MFP à grande vitesse, passer à l'étape 13.

1. Ouvrir le couvercle inférieur droit (1) du MFP. Déposer la courroie (2) de l'arbre (3) et déposer le couvercle inférieur droit (1).

27. Conecte el cable de alimentación (32) y el cable de señales (33) a los conectores (34) (35) del Multi-bandeja lateral, respectivamente.

28. Vuelva a colocar la cubierta (31) usando el tornillo (30) quitado en el paso 26.

**[Conexión del alimentador lateral a la MFP]
Instalación en las MFP de velocidad media**

Si se instala en una MFP de alta velocidad, vaya al paso 13.

1. Abra la cubierta frontal inferior (1) del MFP. Quite la correa (2) del eje (3) y quite la cubierta frontal inferior (1).

27. Das Netzkabel (32) und das Signalkabel (33) an den entsprechenden Steckverbindern (34) (35) des Seitlichen Mehrzweck-Papierfach anschließen.

28. Die Abdeckung (31) mittels der in Schritt 26 entfernten Schraube (30) wieder anbringen.

[Anschluß des seitlichen Einzugs am MFP]

Installation an MFP der mittleren Leistungsklasse

Gehen Sie zur Installation an einem MFP der Hochleistungsklasse weiter zu Schritt 13.

1. Die untere rechte Abdeckung (1) am MFP öffnen. Den Riemen (2) von der Welle (3) abnehmen und dann die untere rechte Abdeckung (1) abnehmen.

27. Collegare il cavo di alimentazione (32) e il cavo del segnale (33) rispettivamente ai connettori (34) e (35) sull'vassoio multiplo laterale.

28. Ricollocare il coperchio (31) utilizzando la vite (30) rimossa nel passo 26.

[Collegare l'unità di alimentazione laterale all'MFP]

Installazione sulle MFP a velocità media

Se si installa su una MFP a velocità alta, procedere al passo 13.

1. Aprire il coperchio destro inferiore (1) sull'MFP. Rimuovere la cinghietta (2) dall'asta (3) e quindi rimuovere il coperchio destro inferiore (1).

27. 将 AC 电线 (32) 以及信号线 (33) 分别与侧手送纸盘的接插件 (34)、(35) 连接。

28. 使用在步骤 26 中拆除的 1 颗螺丝 (30) 按原样安装盖板 (31)。

[侧供纸盒与 MFP 主机的连接]

安装于中速 MFP 上时

安装于高速 MFP 上时, 进至步骤 13。

1. 打开 MFP 主机的右下部盖板 (1)。将带子 (2) 从轴 (3) 上拆除, 拆下右下部盖板 (1)。

27. AC 전선 (32) 및 신호선 (33) 을 사이드 멀티 트레이체 커넥터 (34), (35) 에 각각 접속합니다.

28. 순서 26 에서 제거한 나사 (30) 1 개로 커버 (31) 를 원래대로 부착합니다.

[사이드 피더와 MFP 본체의 접속]

중속 MFP 에 설치하는 경우

고속 MFP 에 설치하는 경우에는 순서 13 로 진행합니다.

1. MFP 본체의 오른쪽 아래 커버 (1) 를 엽니다. 스트랩 (2) 를 축 (3) 에서 떼어내 오른쪽 아래 커버 (1) 를 제거합니다.

27. AC 電線 (32) および信号線 (33) をサイドマルチトレイのコネクター (34)、(35) にそれぞれ接続する。


28. 手順 26 で取り外したビス (30) 1 本でカバー (31) を元通りに取り付ける。

[サイドフィーダーと MFP 本体の接続]


中速 MFP に設置の場合

高速 MFP に設置の場合は手順 13 に進む。


1. MFP 本体の右下カバー (1) を開く。ストラップ (2) を軸 (3) から外し、右下カバー (1) を取り外す。



2. Open the MFP paper conveying cover (4).
3. Open the panel (6) on the MFP front right cover (5).



4. Remove 3 screws (7) and remove the front right cover (5).



5. Remove a screw (9) from the middle right rear cover (8).

2. Ouvrir le capot du transport du papier du MFP (4).
3. Ouvrir le panneau (6) sur le capot avant droit du MFP (5).

4. Déposer les 3 vis (7) et déposer le capot avant droit (5).

5. Déposer la vis (9) du capot arrière droit médian (8).

2. Abra la cubierta de transporte del papel del MFP (4).
3. Abra el panel (6) en la cubierta delantera derecha (5).

4. Quite los 3 tornillos (7) y quite la cubierta delantera derecha (5).

5. Quite el tornillo (9) de la cubierta trasera central (8).

2. Öffnen Sie die Papierförderabdeckung (4) des MFP.
3. Öffnen Sie die Platte (6) der vorderen rechten Abdeckung (5) des MFP.

4. Entfernen Sie 3 Schrauben (7) und nehmen Sie die vordere rechte Abdeckung (5) ab.

5. Entfernen Sie eine Schraube (9) von der mittleren rechten hinteren Abdeckung (8).

2. Aprire il coperchio (4) dell'unità di trasporto carta dell'MFP.
3. Aprire il pannello (6) sul coperchio destro anteriore (5) dell'MFP.

4. Rimuovere le 3 viti (7), e quindi rimuovere il coperchio destro posteriore (5).

5. Rimuovere la vite (9) dal coperchio posteriore centrale destro (8).

2. 打开 MFP 主机的供纸盖板 (4)。
3. 打开 MFP 主机的右前部盖板 (5) 的盖子 (6)。

4. 拆除 3 颗螺丝 (7)，拆下右前部盖板 (5)。

5. 拆除右中后部盖板 (8) 的 1 颗螺丝 (9)。

2. MFP 本体の搬送カバー (4) を開く。
3. MFP 本体の右前カバー (5) のふた (6) を開く。


4. ナス (7) 3 本を 제거하고 우측 전면커버 (5) 를 떼어 냅니다.

5. 우측 중간 뒷커버 (8) 의 나사 (9) 1 개를 제거합니다.


2. MFP 本体の搬送カバー (4) を開く。
3. MFP 本体の右前カバー (5) のふた (6) を開く。

4. ビス (7) 3 本を外し、右前カバー (5) を取り外す。


5. 右中後カバー (8) のビス (9) 1 本を外す。



6. Remove 3 screws (10), then lift the bottom of the middle right rear cover (8) and remove the lower right rear cover (11).



7. Remove the panel (13) from the lower right cover (12) on the paper feeder using a flat blade screwdriver.



8. Open the paper feeder right cover (14). Remove the strap (15) from the right cover shaft (16) and remove the right cover (14).

6. Déposer les 3 vis (10) puis lever le bas du capot arrière droit médian (8) pour déposer le capot arrière droit inférieur (11).

7. Déposer le panneau (13) du capot inférieur droit (12) du bureau papier en procédant à l'aide d'un tournevis à lame.

8. Ouvrir le couvercle droit du bureau papier (14). Déposer la courroie (15) de l'axe du capot droit (16) et déposer le capot droit (14).

6. Quite los 3 tornillos (10), luego levante la parte inferior de la cubierta trasera central derecha (8) y quite la cubierta trasera inferior derecha (11).

7. Quite el panel (13) de la cubierta derecha inferior (12) del alimentador de papel con un destornillador de pala plana.

8. Abra la cubierta derecha del alimentador de papel (14). Quite la correa (15) del eje de la cubierta derecha (16) y quite la cubierta derecha (14).

6. Entfernen Sie 3 Schrauben (10), heben Sie die mittlere rechte hintere Abdeckung (8) von unten her an und nehmen Sie die untere rechte hintere Abdeckung (11) ab.

7. Nehmen Sie mit einem flachen Schraubendreher die Platte (13) von der unteren rechten Abdeckung (12) des Papiereinzugs ab.

8. Die rechte Abdeckung (14) des Papiereinzugs öffnen. Nehmen Sie den Riemen (15) von der Welle (16) der rechten Abdeckung und dann die rechte Abdeckung (14) ab.

6. Rimuovere le 3 viti (10), quindi sollevare la parte in basso del coperchio posteriore centrale destro (8) e rimuovere il coperchio posteriore inferiore destro (11).

7. Rimuovere il pannello (13) dal coperchio destro inferiore (12) sull'unità di alimentazione carta utilizzando un cacciavite a testa piana.

8. Aprire il coperchio destro (14) dell'unità di alimentazione della carta. Rimuovere la cinghietta (15) dall'asta (16) del coperchio destro e quindi rimuovere il coperchio destro (14).

6. 拆除 3 顆螺絲 (10)，抬起右中後部蓋板 (8) 的下部，拆下右下後部蓋板 (11)。

7. 使用一字螺絲刀等將供紙盒的右下部蓋板 (12) 的蓋子 (13) 拆下。

8. 打開供紙盒的右部蓋板 (14)。從右蓋板的軸 (16) 上拆除掛繩 (15)，拆下右蓋板 (14)。

6. 나사 (10) 3 개를 제거하고 우측 하단 뒷커버 (8) 의 하측을 올리고 우측 중간 뒷커버 (11) 를 제거합니다 .


7. 용지 급지대의 우측 하단커버 (12) 의 뚜껑 (13) 을 마이너스 드라이버 등으로 떼어 냅니다 .

8. 급지대 우측커버 (14) 를 엽니다 . 스트랩 (15) 을 우측커버의 축 (16) 에서 떼어 내고 우측커버 (14) 를 제거합니다 .

6. 비스 (10) 3 본を外し、右中後カバー(8) の下側を持ち上げて、右下後カバー(11) を取り外す。

7. ペーパーフィーダーの右下カバー(12) のふた (13) をマイナスドライバーなどで取る。

8. ペーパーフィーダーの右カバー(14) を開く。ストラップ (15) を右カバーの軸 (16) から外し、右カバー(14) を取り外す。




For PF-730

9. Remove 3 screws (17) and a screw (18) and remove the paper feeder lower right cover (19).

For PF-740

9. Remove 3 screws (17) and a screw (20) and remove the paper feeder lower right cover (19).



10. Remove the breakaway cover (21) from the front right cover (5) and the breakaway cover (22) from the lower right rear cover (11).

Pour PF-730

9. Déposer les 3 vis (17) et la vis (18) puis déposer le capot inférieur droit du bureau papier (19).

Pour PF-740

9. Déposer les 3 vis (17) et la vis (20) puis déposer le capot inférieur droit du bureau papier (19).

10. Déposer le couvercle amovible (21) du capot avant droit (5) et le couvercle amovible (22) du capot arrière inférieur droit (11).

Para PF-730

9. Quite los 3 tornillos (17) y el tornillo (18) y quite la cubierta derecha inferior del alimentador de papel (19).

Para PF-740

9. Quite los 3 tornillos (17) y el tornillo (20) y quite la cubierta derecha inferior del alimentador de papel (19).

10. Quite la cubierta divisoria (21) de la cubierta delantera derecha (5) y la cubierta divisoria (22) de la cubierta trasera inferior derecha (11).

Für PF-730

9. Entfernen Sie 3 Schrauben (17) und eine Schraube (18) und nehmen Sie die untere rechte Abdeckung (19) des Papiereinzugs ab.

Für PF-740

9. Entfernen Sie 3 Schrauben (17) und eine Schraube (20) und nehmen Sie die untere rechte Abdeckung (19) des Papiereinzugs ab.

10. Nehmen Sie die Ablösungsabdeckung (21) von der vorderen rechten Abdeckung (5) ab und die Ablösungsabdeckung (22) von der unteren rechten hinteren Abdeckung (11).

Per PF-730

9. Rimuovere le 3 viti (17) e una vite (18), e quindi rimuovere il coperchio destro inferiore (19) dell'unità di alimentazione carta.

Per PF-740

9. Rimuovere le 3 viti (17) e una vite (20), e quindi rimuovere il coperchio destro inferiore (19) dell'unità di alimentazione carta.

10. Rimuovere il coperchio di distacco (21) dal coperchio destro anteriore (5), e il coperchio di distacco (22) dal coperchio posteriore inferiore destro (11).

PF-730 时

9. 拆除 3 颗螺丝 (17) 和 1 颗螺丝 (18), 拆下供纸盒的右下部盖板 (19)。

PF-740 时

9. 拆除 3 颗螺丝 (17) 和 1 颗螺丝 (20), 拆下供纸盒的右下部盖板 (19)。

10. 切除右前部盖板 (5) 的切割盖板 (21) 和右下后部盖板 (11) 的切割盖板 (22)。

PF-730 의 경우

9. 나사 (17) 3 개와 나사 (18) 1 개를 제거하고, 용지 급지대의 우측 하단커버 (19) 를 제거합니다 .

PF-740 의 경우

9. 나사 (17) 3 개와 나사 (20) 1 개를 제거하고, 용지 급지대의 우측 하단커버 (19) 를 제거합니다 .

10. 우측 전면커버 (5) 의 분할커버 (21) 와 오른쪽 하단 뒷커버 (11) 의 분할커버 (22) 를 떼어 냅니다 .


PF-730 の場合

9. ビス (17) 3 本とビス (18) 1 本を外して、ペーパーフィーダーの右下カバー (19) を取り外す。


PF-740 の場合

9. ビス (17) 3 本とビス (20) 1 本を外して、ペーパーフィーダーの右下カバー (19) を取り外す。

10. 右前カバー (5) の割りカバー (21) と右下後部カバー (11) の割りカバー (22) を切り取る。



11. Remove the panel (23) from the MFP lower right cover (1) with a flat blade screwdriver.



12. After using alcohol to clean place adhering the film, adhere the film (O) in the position (24) indicated in the illustration. Proceed to step 25.

11. Déposer le panneau (23) du capot inférieur droit du MFP (1) en procédant à l'aide d'un tournevis à lame.

12. Coller le film (O) sur l'emplacement (24) indiqué dans l'illustration, après avoir soigneusement nettoyé cet emplacement à l'alcool. Passer à l'étape 25.

11. Extraiga el panel (23) de la cubierta derecha inferior del MFP (1) con un destornillador de pala plana.

12. Después de utilizar alcohol para limpiar la zona donde se va a pegar la película, pegue la película (O) en el lugar (24) que se indica en la ilustración. Vaya al paso 25.

11. Nehmen Sie mit einem flachen Schraubendreher die Platte (23) von der unteren rechten Abdeckung (1) des MFP ab.

12. Zum Anbringen des Films (O) die Stelle zuvor mit Alkohol reinigen und den Film (O) dann in der in der Abbildung angegebenen Position (24) anbringen. Gehen Sie weiter zu Schritt 25.

11. Rimuovere il pannello (23) dal coperchio destro inferiore (1) dell'MFP con un cacciavite a testa piana.

12. Dopo aver utilizzato alcol per pulire la piastra che aderisce alla pellicola, far aderire la pellicola (O) nella posizione (24) indicata nell'illustrazione. Procedere al passo 25.

11. 使用一字螺丝刀将 MFP 主机的右下部盖板 (1) 的盖子 (23) 拆下。


12. 使用酒精对薄膜粘贴位置进行清洁后, 按插图位置 (24) 粘贴薄膜 (O)。进至步骤 25。

11. MFP 본체의 우측 뒷커버 (1) 의 뚜껑 (23) 을 마이너스 드라이버로 제거합니다 .

12. 필름 부착위치를 알코올 청소 후, 일러스트의 위치 (24) 에 맞춰 필름 (O) 을 부착합니다 . 순서 25 로 진행합니다 .


11. MFP 本体の右下カバー(1) のふた (23) をマイナスドライバーで取り外す。

12. フィルム貼り付け位置をアルコール清掃後、イラストの位置 (24) にあわせて、フィルム (O) を貼り付ける。手順 25 に進む。



Installation on high-speed MFPs

13. Open the right cover 1 (25) on the MFP.
Remove the strap (26) from the shaft (27) and remove right cover 1 (25).



14. Open the right cover 2 (28) on the MFP.
Remove the strap (29) from the right cover shaft (30) and remove the right cover 2 (28).

Montage sur des MFP à grande vitesse

13. Ouvrir le capot droit 1 (25) du MFP.
Déposer la courroie (26) de l'arbre (27) et déposer le capot droit 1 (25).

14. Ouvrir le capot droit 2 (28) du MFP.
Déposer la courroie (29) de l'axe du capot droit (30) et déposer le capot droit 2 (28).

Instalación en las MFP de alta velocidad

13. Abra la cubierta derecha 1 (25) del MFP.
Quite la correa (26) del eje (27) y quite la cubierta derecha 1 (25).

14. Abra la cubierta derecha 2 (28) del MFP.
Quite la correa (29) del eje de la cubierta derecha (30) y quite la cubierta derecha 2 (28).

Installation an MFP der Hochleistungsklasse

13. Die rechte Abdeckung 1 (25) am MFP öffnen.
Den Riemen (26) von der Welle (27) abnehmen und dann die rechte Abdeckung 1 (25) abnehmen.

14. Die rechte Abdeckung 2 (28) am MFP öffnen.
Nehmen Sie den Riemen (29) von der Welle (30) der rechten Abdeckung und dann die rechte Abdeckung 2 (28) ab.

Installazione sulle MFP a velocità alta

13. Aprire il coperchio destro 1 (25) sull'MFP.
Rimuovere la cinghietta (26) dall'asta (27) e quindi rimuovere il coperchio destro 1 (25).

14. Aprire il coperchio destro 2 (28) sull'MFP.
Rimuovere la cinghietta (29) dall'asta (30) del coperchio destro e quindi rimuovere il coperchio destro 2 (28).

安装于高速 MFP 上时

13. 打开 MFP 主机的右部盖板 1 (25)。
将带子 (26) 从轴 (27) 上拆除，拆下右部盖板 1 (25)。

14. 打开 MFP 主机的右部盖板 2 (28)。
从右盖板的轴 (30) 上拆除挂绳 (29)，拆下右盖板 2 (28)。

고속 MFP 에 설치하는 경우


13. MFP 본체의 우측커버 1 (25) 를 엽니다 .
스트랩 (26) 를 축 (27) 에서 떼어내 우측커버 1 (25) 를 제거합니다 .

14. MFP 본체의 우측커버 2 (28) 를 엽니다 .
스트랩 (29) 을 우측커버의 축 (30) 에서 떼어내고 우측커버 2 (28) 를 제거합니다 .


高速 MFP に設置の場合

13. MFP 本体の右カバー1 (25) を開く。
ストラップ (26) を軸 (27) から外し、右カバー1 (25) を取り外す。


14. MFP 本体の右カバー2 (28) を開く。
ストラップ (29) を右カバーの軸 (30) から外し、右カバー2 (28) を取り外す。



15. Open the MFP paper conveying cover (31).
16. Open the panel (33) on the MFP front right cover (32).



17. Remove the 4 screws (34) and release the 4 hooks (59). Then remove the front right cover (32).



18. Remove a screw (36) from the middle right rear cover (35).

15. Ouvrir le capot du transport du papier du MFP (31).
16. Ouvrir le panneau (33) sur le capot avant droit du MFP (32).

17. Retirer les 4 vis (34) et libérer les 4 crochets (59). Retirer ensuite le capot avant droit (32).

18. Déposer la vis (36) du capot arrière droit médian (35).

15. Abra la cubierta de transporte del papel del MFP (31).
16. Abra el panel (33) en la cubierta delantera derecha (32).

17. Quite los 4 tornillos (34) y libere los 4 ganchos (59). Después, quite la cubierta frontal derecha (32).

18. Quite el tornillo (36) de la cubierta trasera central (35).

15. Öffnen Sie die Papierförderabdeckung (31) des MFP.
16. Öffnen Sie die Platte (33) der vorderen rechten Abdeckung (32) des MFP.

17. Entfernen Sie die 4 Schrauben (34) und lösen Sie die 4 Haken (59). Danach nehmen Sie die rechte vordere Abdeckung (32) ab.

18. Entfernen Sie eine Schraube (36) von der mittleren rechten hinteren Abdeckung (35).

15. Aprire il coperchio (31) dell'unità di trasporto carta dell'MFP.
16. Aprire il pannello (33) sul coperchio destro anteriore (32) dell'MFP.

17. Rimuovere le 4 viti (34) e rilasciare i 4 ganchi (59). Rimuovere quindi il coperchio anteriore destro (32).

18. Rimuovere la vite (36) dal coperchio posteriore centrale destro (35).

15. 打开 MFP 主机的供纸盖板 (31)。
16. 打开 MFP 主机的右前部盖板 (32) 的盖子 (33)。

17. 卸下 4 颗螺丝 (34) 并松开 4 个卡扣 (59)。然后卸下右前盖板 (32)。

18. 拆除右中后部盖板 (35) 的 1 颗螺丝 (36)。

15. MFP 본체의 반송커버 (31) 를 엽니다 .
16. MFP 본체의 우측 전면커버 (32) 의 뚜껑 (33) 을 엽니다 .


17. 나사 (34) 4 개를 제거하고 후크 (59) 4 개를 풀니다 . 그런 다음 우측 전면 커버 (32) 를 제거합니다 .

18. 우측 중간 뒷커버 (35) 의 나사 (36) 1 개를 제거합니다 .


15. MFP 本体の搬送カバー (31) を開く。
16. MFP 本体の右前カバー (32) のふた (33) を開く。

17. ビス (34) 4 本およびフック (59) 4 箇所を外し、右前カバー (32) を取り外す。


18. 右中後カバー (35) のビス (36) 1 本を外す。



19. Remove the panel (38) from the lower right rear cover (37) with a flat blade screwdriver.



20. Remove 5 screws (39), then lift the bottom of the middle right rear cover (35) and remove the lower right rear cover (37).



21. Remove 2 screws (40) and remove the lower right cover (41).

19. Déposer le panneau (38) du capot arrière inférieur droit (37) en procédant à l'aide d'un tournevis à lame.

20. Déposer les 5 vis (39) puis lever le bas du capot arrière droit médian (35) pour déposer le capot arrière droit inférieur (37).

21. Déposer les 2 vis (40) et déposer le capot inférieur droit (41).

19. Extraiga el panel (38) de la cubierta trasera inferior derecha (37) con un destornillador de pala plana.

20. Quite los 5 tornillos (39), luego levante la parte inferior de la cubierta trasera central derecha (35) y quite la cubierta trasera inferior derecha (37).

21. Quite los 2 tornillos (40) y quite la cubierta derecha inferior (41).

19. Nehmen Sie mit einem flachen Schraubendreher die Platte (38) von der unteren rechten hinteren Abdeckung (37) ab.

20. Entfernen Sie 5 Schrauben (39), heben Sie die mittlere rechte hintere Abdeckung (35) von unten her an und nehmen Sie die untere rechte hintere Abdeckung (37) ab.

21. Entfernen Sie 2 Schrauben (40) und nehmen Sie die untere rechte Abdeckung (41) ab.

19. Rimuovere il pannello (38) dal coperchio posteriore inferiore destro (37) con un cacciavite a testa piana.

20. Rimuovere le 5 viti (39), quindi sollevare la parte in basso del coperchio posteriore centrale destro (35) e rimuovere il coperchio posteriore inferiore destro (37).

21. Rimuovere le 2 viti (40), e quindi rimuovere il coperchio destro inferiore (41).

19. 用一字螺丝刀等取下右下盖板 (37) 的盖子 (38)。

20. 拆除 5 颗螺丝 (39)，抬起右中后部盖板 (35) 的下部，拆下右下后部盖板 (37)。

21. 拆除 2 颗螺丝 (40)，拆下右下后部盖板 (41)。

19. 우측 아래뒷면 커버 (37) 의 뚜껑 (38) 을 마이너스 드라이버 등으로 푼니다.


20. 나사 (39) 5 개를 제거하고 우측 하단 뒷커버 (35) 의 하측을 올리고 우측 중간 뒷커버 (37) 를 제거합니다.

21. 나사 (40) 2 개를 제거하고 우측 하단커버 (41) 를 떼어 냅니다.


19. 右下後カバー(37) のふた(38)をマイナスドライバーなどで取る。

20. ビス(39)5本を外し、右中後カバー(35)の下側を持ち上げて、右下後カバー(37)を取り外す。

21. ビス(40)2本を外して、右下カバー(41)を取り外す。



22. Remove the breakaway cover (42) from the front right cover (32) and the breakaway cover (43) from the lower right rear cover (37).



23. Remove the panel (44) from the MFP right cover 1 (25) with a flat blade screwdriver.

22. Déposer le couvercle amovible (42) du capot avant droit (32) et le couvercle amovible (43) du capot arrière inférieur droit (37).

23. Déposer le panneau (44) du capot droit 1 du MFP (25) en procédant à l'aide d'un tournevis à lame.

22. Quite la cubierta divisoria (42) de la cubierta delantera derecha (32) y la cubierta divisoria (43) de la cubierta trasera inferior derecha (37).

23. Extraiga el panel (44) de la cubierta derecha 1 del MFP (25) con un destornillador de pala plana.

22. Nehmen Sie die Ablösungsabdeckung (42) von der vorderen rechten Abdeckung (32) ab und die Ablösungsabdeckung (43) von der unteren rechten hinteren Abdeckung (37).

23. Nehmen Sie mit einem flachen Schraubendreher die Platte (44) von der rechten Abdeckung 1 (25) des MFP ab.

22. Rimuovere il coperchio di distacco (42) dal coperchio destro anteriore (32), e il coperchio di distacco (43) dal coperchio posteriore inferiore destro (37).

23. Rimuovere il pannello (44) dal coperchio destro 1 (25) dell'MFP con un cacciavite a testa piana.

22. 切除右前部盖板 (32) 的切割盖板 (42) 和右下后部盖板 (37) 的切割盖板 (43)。


23. 使用一字螺丝刀将 MFP 主机的右部盖板 1 (25) 的盖子 (44) 拆下。

22. 우측 전면커버 (32) 의 분할커버 (42) 와 오른쪽 하단 뒷커버 (37) 의 분할커버 (43) 를 떼어 냅니다 .

23. MFP 본체의 우측커버 1 (25) 의 뚜껑 (44) 을 마이너스 드라이버로 제거합니다 .

22. 右前カバー (32) の割りカバー (42) と右下後カバー (37) の割りカバー (43) を切り取る。

23. MFP 本体の右カバー1(25) のふた (44) をマイナスドライバーで取り外す。



24. After using alcohol to clean place adhering the film, adhere the film (O) in the position (45) indicated in the illustration.

24. Coller le film (O) sur l'emplacement (45) indiqué dans l'illustration, après avoir soigneusement nettoyé cet emplacement à l'alcool.

24. Después de utilizar alcohol para limpiar la zona donde se va a pegar la película, pegue la película (O) en el lugar (45) que se indica en la ilustración.


24. Zum Anbringen des Films (O) die Stelle zuvor mit Alkohol reinigen und den Film (O) dann in der in der Abbildung angegebenen Position (45) anbringen.

24. Dopo aver utilizzato alcol per pulire la piastra che aderisce alla pellicola, far aderire la pellicola (O) nella posizione (45) indicata nell'illustrazione.

24. 使用酒精对薄膜粘贴位置进行清洁后,按插图位置(45)粘贴薄膜(O)。

24. 필름 부착위치를 알코올 청소 후, 일러스트의 위치(45)에 맞춰 필름(O)을 부착합니다.

24. フィルム貼り付け位置をアルコール清掃後、イラストの位置(45)にあわせて、フィルム(O)を貼り付ける。



25. Install a lock pin (D) on the front right of the MFP using an M4 x 8 screw (F).

25. Monter une broche de verrouillage (D) à droite et à l'avant du MFP en procédant à l'aide d'une vis M4 x 8 (F).

25. Instale una clavija de bloqueo (D) en la parte derecha frontal del MFP usando un tornillo M4 x 8 (F).


25. Bringen Sie mit einer M4 x 8 Schraube (F) den Arretierungsstift (D) vorne rechts am MFP an.

25. Installare un perno di bloccaggio (D) sulla parte anteriore destra dell'MFP utilizzando una vite M4 x 8 (F).


25. 使用1顆M4×8螺丝(F)將鎖定插銷(D)安裝到MFP主機的右前側。

25. 나사 M4×8(F) 1 개로 잠금 핀(D)을 MFP 본체 우측 전면쪽에 설치합니다.

25. ビス M4×8(F) 1 本で、ロックピン(D)をMFP 本体右前側に取り付ける。



26. Install a lock pin (D) on the rear right of the MFP using an M4 x 8 screw (F) in the same way.



27. Place the small base slider (C) on the large base slider (B). Place so that the bend (47) on the small base slider (C) abuts inside the rest (46) at the end of the large base slider (B).

26. Monter une broche de verrouillage (D) à droite et à l'arrière du MFP en procédant de la même manière à l'aide d'une vis M4 x 8 (F).

27. Placer la petite règle de base (C) sur la grande règle de base (B). Disposer la petite règle de base (C) de sorte que son extrémité repliée (47) s'encastre dans la butée (46) à l'extrémité de la grande règle de base (B).

26. Instale una clavija de bloqueo (D) en la parte derecha frontal del MFP usando un tornillo M4 x 8 (F).

27. Coloque el deslizador de base pequeño (C) sobre el deslizador de base grande (B). Haga que la dobladura (47) del deslizador de base pequeño (C) quede en el interior del apoyo (46) del extremo del deslizador de base grande (B).

26. Bringen Sie auf gleiche Weise mit einer M4 x 8 Schraube (F) den Arretierungsstift (D) hinten rechts am MFP an.

27. Setzen Sie den kleinen Basis-Schieber (C) auf den großen Basis-Schieber (B). Setzen Sie ihn so auf, dass die Biegung (47) am kleinen Basis-Schieber (C) innerhalb der Auflage (46) am Ende des großen Basis-Schiebers (B) anliegt.

26. Installare un perno di bloccaggio (D) sulla parte posteriore destra dell'MFP utilizzando una vite M4 x 8 (F) alla stessa maniera.

27. Posizionare lo scivolo di base piccolo (C) sullo scivolo di base grande (B). Posizionare in modo che la piegatura (47) sullo scivolo di base piccolo (C) si attesti all'interno del sostegno (46) all'estremità dello scivolo di base grande (B).

26. 按相同方法, 使用 1 顆 M4x8 螺絲 (F) 將鎖定插銷 (D) 安裝到 MFP 主機的右後側。


27. 將底座滑板 (小) (C) 放在底座滑板 (大) (B)。此時底座滑板 (小) (C) 的彎曲部 (47) 應處於底座滑板 (大) (B) 的前端折彎部 (46) 的內側。

26. 같은 방식으로 나사 M4x8(F) 1 개로 잠금 핀 (D) 을 MFP 본체 우측 뒤쪽에 설치합니다 .

27. 베이스 슬라이더 대 (B) 의 위에 베이스 슬라이더 소 (C) 를 얹습니다 . 그 때 , 베이스 슬라이더 소 (C) 의 곡선부 (47) 가 베이스 슬라이더 대 (B) 의 맨 앞쪽의 꺾이고 구부러진 부분 (46) 의 안쪽으로 오도록 세웁니다 .

26. 同様にビス M4x8(F) 1 本で、ロックピン (D) を MFP 本体右後側に取り付ける。

27. ベーススライダ大 (B) の上にベーススライダ小 (C) を乗せる。その際、ベーススライダ小 (C) の曲げ (47) がベーススライダ大 (B) の先端折り曲げ部 (46) の内側にくるようにセットする。



28. Insert the small base slider (C) under the machine. Install to the base (48) using 2 M4 × 8 screws (F) so that the gap between the small base slider (C) and the large base slider (B) is 6 ± 2 mm.

* For PF-730, install to the screw holes marked "R".

28. Insérer la petite règle de base (C) sous l'appareil. Fixer à la base (48) à l'aide de 2 vis M4 × 8 (F) de sorte que le battement entre la petite règle de base (C) et la grande règle de base (B) soit de 6 ± 2 mm.

* Pour le PF-730, fixer aux trous de vis marqués "R".

28. Introduzca el deslizador de base pequeño (C) por debajo de la máquina. Instálelo en la base (48) usando 2 tornillos M4 × 8 (F) de manera tal que el huelgo entre el deslizador de base pequeño (C) y el deslizador de base grande (B) sea de 6 ± 2 mm.

* En el caso de PF-730, instale en los orificios para tornillo "R".

28. Den kleinen Basis-Schieber (C) unter der Maschine einsetzen. Befestigen Sie ihn mit 2 M4 × 8 Schrauben (F) so an der Basis (48), dass der Abstand zwischen dem kleinen Basis-Schieber (C) und dem großen Basis-Schieber (B) 6 ± 2 mm beträgt.

* Bei Modell PF-730 an den mit "R" markierten Schraublöchern befestigen.

28. Inserire lo scivolo di base piccolo (C) sotto la macchina. Installare alla base (48) utilizzando 2 viti M4 × 8 (F) in modo che lo spazio tra lo scivolo di base piccolo (C) e lo scivolo di base grande (B) sia di 6 ± 2 mm.

* Per PF-730, installare ai fori per viti segnalati con "R".

28. 将底座滑板(小)(C)插入MFP主机侧的供纸工作台的下方。使用2颗M4×8(F)螺丝将底座滑板(小)(C)安装到底板(48)上,确保底座滑板(小)(C)与底座滑板(大)(B)之间的间隙为 6 ± 2 mm。

※PF-730时,安装到带有R刻印的螺纹孔上。

28. 베이스 슬라이더 소 (C) 를 MFP 본체측의 용지 급지대 밑에 넣습니다 . 베이스 슬라이더 소 (C) 와 베이스 슬라이더 대 (B) 의 틈이 6 ± 2 mm 가 되도록 나사 M4×8(F) 2 개로 바닥판 (48) 에 장착합니다 .

※PF-730 은 R 의 각인이 있는 나사구멍에 장착합니다 .

28. ベーススライダ小 (C) をMFP本体側のペーパーフィーダーの下に入れる。ベーススライダ小 (C) とベーススライダ大 (B) の隙間が、 6 ± 2 mm になるようにビス M4×8(F) 2 本で底板 (48) に取り付ける。

※PF-730 は R の刻印のあるビス穴に取り付ける。

Installation on medium-speed MFPs

If installing on a high-speed MFP, proceed to step 35.

29. Reinstall the paper feeder lower right cover (19).
30. Reinstall the paper feeder right cover (14).

31. Reinstall the lower right rear cover (11).
32. Mount a screw (9) in the middle right rear cover (8).
33. Reinstall the front right cover (5).
34. Reinstall the lower right cover (1).
Proceed to step 41.

Montage sur des MFP à vitesse moyenne

Si le montage est fait sur un MFP à grande vitesse, passer à l'étape 35.

29. Reposer le capot inférieur droit du bureau papier (19).
30. Reposer le capot droit du bureau papier (14).

31. Reposer le capot arrière inférieur droit (11).
32. Fixer la vis (9) sur le capot arrière médian droit (8).
33. Reposer le capot avant droit (5).
34. Reposer le capot inférieur droit (1).
Passer à l'étape 41.

Instalación en las MFP de velocidad media

Si se instala en una MFP de alta velocidad, vaya al paso 35.

29. Reinstale la cubierta derecha inferior del alimentador de papel (19).
30. Reinstale la cubierta derecha del alimentador de papel (14).

31. Reinstale la cubierta trasera inferior derecha (11).
32. Instale el tornillo (9) en la cubierta trasera central derecha (8).
33. Reinstale la cubierta delantera derecha (5).
34. Reinstale la cubierta derecha inferior (1).
Vaya al paso 41.

Installation an MFP der mittleren Leistungsklasse

Gehen Sie zur Installation an einem MFP der Hochleistungsklasse weiter zu Schritt 35.

29. Bringen Sie die untere rechte Abdeckung (19) des Papiereinzugs wieder an.
30. Bringen Sie die rechte Abdeckung (14) des Papiereinzugs wieder an.

31. Bringen Sie die untere rechte hintere Abdeckung (11) wieder an.
32. Befestigen Sie eine Schraube (9) an der mittleren rechten hinteren Abdeckung (8).
33. Bringen Sie die vordere rechte Abdeckung (5) wieder an.
34. Bringen Sie die untere rechte Abdeckung (1) wieder an.
Gehen Sie weiter zu Schritt 41.

Installazione sulle MFP a velocità media

Se si installa su una MFP a velocità alta, procedere al passo 35.

29. Reinstallare il coperchio destro inferiore dell'unità di alimentazione carta (19).
30. Reinstallare il coperchio destro (14) dell'unità di alimentazione carta.

31. Reinstallare il coperchio posteriore inferiore destro (11).
32. Montare la vite (9) nel coperchio posteriore centrale destro (8).
33. Reinstallare il coperchio destro anteriore (5).
34. Reinstallare il coperchio destro inferiore (1).
Procedere al passo 41.

安装于中速 MFP 上时

安装于高速 MFP 上时, 进至步骤 35。

29. 按原样安装供纸盒的右下部盖板 (19)。
30. 按原样安装供纸盒的右盖板 (14)。

31. 按原样安装右下后部盖板 (11)。
32. 安装右中后部盖板 (8) 的 1 颗螺丝 (9)。
33. 按原样安装右前部盖板 (5)。
34. 按原样安装右下部盖板 (1)。
进至步骤 41。

중속 MFP 에 설치하는 경우

고속 MFP 에 설치하는 경우에는 순서 35 로 진행합니다 .

29. 용지 급지대의 우측 하단커버 (19) 를 원래대로 장착합니다 .
30. 용지 급지대의 우측커버 (14) 를 원래대로 장착합니다 .


31. 우측하단 뒷커버 (11) 를 원래대로 장착합니다 .
32. 우측 중간 뒷커버 (8) 의 나사 (9) 1 개를 장착합니다 .
33. 우측 전면커버 (5) 를 원래대로 장착합니다 .
34. 우측 하단커버 (1) 를 원래대로 장착합니다 .
순서 41 로 진행합니다 .

中速 MFP に設置の場合

高速 MFP に設置の場合は手順 35 に進む。

29. ペーパーフィーダーの右下カバー (19) を元通り取り付ける。
30. ペーパーフィーダーの右カバー (14) を元通り取り付ける。

31. 右下後カバー (11) を元通り取り付ける。
32. 右中後カバー (8) のビス (9) 1 本を取り付ける。
33. 右前カバー (5) を元通り取り付ける。
34. 右下カバー (1) を元通り取り付ける。
手順 41 に進む。



Installation on high-speed MFPs

- 35. Reinstall the lower right cover (41).
- 36. Reinstall the lower right rear cover (37).
- 37. Mount a screw (36) in the middle right rear cover (35).

- 38. Reinstall the front right cover (32).
- 39. Reinstall the right cover 2 (28).
- 40. Reinstall the right cover 1 (25).

- 41. Install the switch press plate (E) using the M4 × 10 tapping screw (J).

Montage sur des MFP à grande vitesse

- 35. Reposer le capot inférieur droit (41).
- 36. Reposer le capot arrière inférieur droit (37).
- 37. Fixer la vis (36) sur le capot arrière médian droit (35).

- 38. Reposer le capot avant droit (32).
- 39. Reposer le capot droit 2 (28).
- 40. Reposer le capot droit 1 (25).

- 41. Fixer la plaque de pression du contacteur (E) à l'aide d'une vis de connexion M4 × 10 (J).

Instalación en las MFP de alta velocidad

- 35. Reinstale la cubierta derecha inferior (41).
- 36. Reinstale la cubierta trasera inferior derecha (37).
- 37. Instale el tornillo (36) en la cubierta trasera central derecha (35).

- 38. Reinstale la cubierta delantera derecha (32).
- 39. Reinstale la cubierta derecha 2 (28).
- 40. Reinstale la cubierta derecha 1 (25).

- 41. Instale la placa de presión del interruptor (E) usando el tornillo de roscado M4 × 10 (J).

Installation an MFP der Hochleistungsklasse

- 35. Bringen Sie die untere rechte Abdeckung (41) wieder an.
- 36. Bringen Sie die untere rechte hintere Abdeckung (37) wieder an.
- 37. Befestigen Sie eine Schraube (36) an der mittleren rechten hinteren Abdeckung (35).

- 38. Bringen Sie die vordere rechte Abdeckung (32) wieder an.
- 39. Bringen Sie die rechte Abdeckung 2 (28) wieder an.
- 40. Bringen Sie die rechte Abdeckung 1 (25) wieder an.

- 41. Befestigen Sie mit der M4 × 10 Schraubenschraube (J) die Schalterdruckplatte (E).

Installazione sulle MFP a velocità alta

- 35. Reinstallare il coperchio destro inferiore (41).
- 36. Reinstallare il coperchio posteriore inferiore destro (37).
- 37. Montare la vite (36) nel coperchio posteriore centrale destro (35).

- 38. Reinstallare il coperchio destro anteriore (32).
- 39. Reinstallare il coperchio destro 2 (28).
- 40. Reinstallare il coperchio destro 1 (25).

- 41. Installare la piastra spingi interruttore (E) utilizzando la vite autofilettante M4 × 10 (J).

安装于高速 MFP 上时

- 35. 按原样安装右下部盖板 (41)。
- 36. 按原样安装右下后部盖板 (37)。
- 37. 安装右中后部盖板 (35) 的 1 颗螺丝 (36)。

- 38. 按原样安装右前部盖板 (32)。
- 39. 按原样安装右部盖板 2 (28)。
- 40. 按原样安装右部盖板 1 (25)。

- 41. 使用 1 颗 M4×10 自攻螺丝 (J) 安装开关挡板 (E)。

고속 MFP 에 설치하는 경우

- 35. 우측 하단커버 (41) 를 원래대로 장착합니다 .
- 36. 우측하단 뒷커버 (37) 를 원래대로 장착합니다 .
- 37. 우측 중간 뒷커버 (35) 의 나사 (36) 1 개를 장착합니다 .

- 38. 우측 전면커버 (32) 를 원래대로 장착합니다 .
- 39. 우측커버 2 (28) 를 원래대로 장착합니다 .
- 40. 우측커버 1 (25) 를 원래대로 장착합니다 .


- 41. 탭핑나사 M4×10(J) 1 개로 스위치 판 (E) 을 장착합니다 .

高速 MFP に設置の場合


- 35. 右下カバー (41) を元通り取り付けます。
- 36. 右下後カバー (37) を元通り取り付けます。
- 37. 右中後カバー (35) のビス (36) 1 本を取り付けます。

- 38. 右前カバー (32) を元通り取り付けます。
- 39. 右カバー 2 (28) を元通り取り付けます。
- 40. 右カバー 1 (25) を元通り取り付けます。

- 41. タッピングビス M4×10(J) 1 本でスイッチ当たり板 (E) を取り付けます。



42. Attach the side feeder to the large base slider (B) using 2 M4 × 8 screws (F). Install so that the center of the M4 × 8 screws (F) comes over the horizontal line (49) of the mounting plate on the large base slider (B).



43. Install the cover plate (I) using 2 M4 × 8 screws (F).

42. Fixer le plateau d'alimentation latéral à la grande règle de base (B) à l'aide de 2 vis M4 × 8 (F). Procéder de sorte que l'axe des vis M4 × 8 (F) recouvre la ligne horizontale (49) du plateau de montage sur la grande règle de base (B).

43. Fixer le capot (I) à l'aide de 2 vis M4 × 8 (F).

42. Sujete el alimentador lateral al deslizador de base grande (B) con 2 tornillos M4 × 8 (F). Instale de manera que el centro de los tornillos M4 × 8 (F) queden sobre la línea horizontal (49) de la placa de montaje del deslizador de base (B) grande.

43. Instale la tapa (I) usando los 2 tornillos M4 × 8 (F).

42. Den seitlichen Einzug am großen Basis-Schieber (B) mithilfe der 2 Schrauben 2 M4 × 8 (F) befestigen. Befestigen Sie ihn so, dass die Mitte der M4 × 8 Schrauben (F) über der Waagrechtlinie (49) der Montageplatte am großen Basis-Schieber (B) liegt.

43. Bringen Sie die Abdeckungsplatte (I) mit 2 M4 × 8 Schrauben (F) an.

42. Collegare l'unità di alimentazione laterale allo scivolo di base grande (B) usando 2 viti M4 × 8 (F). Installare in modo che il centro delle viti M4 × 8 (F) sia sulla linea orizzontale (49) della piastra di montaggio sullo scivolo di base grande (B).

43. Installare il coperchio (I) utilizzando 2 viti M4 × 8 (F).

42. 使用 2 顆 M4×8 螺絲 (F) 將側供紙盒安裝到底座滑板 (大) (B) 上。此時，應確保 M4×8 螺絲 (F) 的中心處於底座滑板 (大) (B) 的安裝板的平行線 (49) 上。


43. 使用 2 顆 M4×8 螺絲 (F) 安裝盖板 (I)。

42. 나사 M4×8(F) 2 개로 베이스 슬라이더 대 (B) 에 사이드 피더를 장착합니다. 그 때, 베이스 슬라이더 대 (B) 의 설치판의 평행선 (49) 에 나사 M4×8(F) 의 센터가 오도록 장착합니다.


43. 나사 M4×8(F) 2 개로 커버 플레이트 (I) 를 장착합니다.

42. ビス M4×8(F) 2 本でベーススライダ大 (B) にサイドフィーダーを取り付ける。その際、ベーススライダ大 (B) の取付板の平行線 (49) にビス M4×8(F) のセンターがくるように取り付ける。

43. ビス M4×8(F) 2 本でカバープレート (I) を取り付ける。



44. Connect the signal cable (51) of the side feeder to the connector (50) of the MFP.
45. Push the side feeder to connect it to the MFP.



46. After using alcohol to clean place adhering the cassette number label 6 (L) and the cassette number label 7 (M), adhere them in the positions indicated in the illustration.

44. Connecter le câble de signal (51) du plateau d'alimentation latéral au connecteur (50) du MFP.
45. Pousser le dispositif du plateau d'alimentation latéral pour le raccorder au MFP.

46. Coller l'étiquette de numéro de cassette 6 (L) et l'étiquette de numéro de cassette 7 (M) sur les emplacements indiqués dans l'illustration, après avoir soigneusement nettoyé ces derniers à l'alcool.

44. Conecte el cable de señal (51) del alimentador lateral al conector (50) de la MFP.
45. Empuje el alimentador lateral para conectarlo al MFP.

46. Después de utilizar alcohol para limpiar la zona donde se va a pegar la etiqueta de casete con el número 6 (L) y la etiqueta de casete con el número 7 (M), péguelas en los lugares que se indican en la ilustración.

44. Das Signalkabel (51) des seitlichen Einzugs an den Stecker (50) des MFP anschließen.
45. Drücken Sie auf den seitlichen Einzug, um ihn mit dem MFP zu verbinden.

46. Zum Anbringen der Aufkleber Kassettensnummer 6 (L) und Kassettensnummer 7 (M) die Stellen zuvor mit Alkohol reinigen und die Aufkleber dann an den in der Abbildung angegebenen Positionen anbringen.

44. Collegare il cavo del segnale (51) dell'unità di alimentazione laterale al connettore (50) dell'MFP.
45. Spingere l'unità di alimentazione laterale per collegarla all'MFP.

46. Dopo aver utilizzato alcol per pulire la piastra che aderisce all'etichetta numero cassetta 6 (L) e l'etichetta numero cassetta 7 (M), farli aderire nelle posizioni indicate nell'illustrazione.

44. 将侧供纸盒的信号线(51)与MFP主机的接插件(50)相连。
45. 按住侧供纸盒,将其与MFP主机连接。


46. 使用酒精清洁要粘贴纸盒编号标签6(L)、纸盒编号标签7(M)的位置后,按图示位置粘贴。

44. 사이드 피더의 신호선(51)을 MFP 본체의 커넥터(50)에 접속합니다.
45. 사이드 피더를 밀어 MFP 본체에 접속합니다

46. 카세트 넘버라벨 6(L), 카세트 넘버라벨 7(M)의 부착위치를 알코올 청소 후, 일러스트의 위치에 부착합니다.

44. サイドフィーダーの信号線(51)をMFP本体のコンネクター(50)に接続する。
45. サイドフィーダーを押し、MFP本体に接続する。

46. カセットナンバーラベル6(L)、カセットナンバーラベル7(M)をアルコール清掃後、イラストの位置に貼り付ける。



For PF-730

47. Pull each cassette out and then remove the lift plate stopper (52) from each cassette and attach it to the storage location (53).

For PF-740

47. Pull out the right cassette (54) and left cassette (55), remove each of the lift plate stoppers (56) and attach them in the storage location.

48. Gently close each cassette.

Pour PF-730

47. Tirer chaque tiroir vers l'extérieur puis retirer la butée de plaque d'élévation (52) de chaque tiroir et la fixer à l'emplacement de rangement (53).

Pour PF-740

47. Sortir le tiroir droit (54) et le tiroir gauche (55), déposer toutes les butées du plateau de levage (56) et les ranger soigneusement.

48. Refermer progressivement chaque tiroir.

Para PF-730

47. Abra la bandeja y quite el tope de la placa de elevación (52) de cada bandeja y colóquela en su lugar de depósito (53).

Para PF-740

47. Extraiga el cajón derecho (54) y el cajón izquierdo (55), quite cada uno de los topes de placa de elevación (56) y fíjelos en el lugar de almacenamiento.

48. Cierre suavemente cada bandeja.

Für PF-730

47. Die einzelnen Kassetten herausziehen, dann den Hebeplattenanschlag (52) von jeder Kassette entfernen und an der Speicherposition (53) anbringen.

Für PF-740

47. Die rechte Papierlade (54) und die linke Papierlade (55) herausziehen, jeden der Hebeplattenanschläge (56) entfernen und in der vorgesehenen Position verstauen.

48. Alle Kassetten sachte schließen.

Per PF-730

47. Estrarre ciascun cassetto e poi rimuovere il fermo della piastra di sollevamento (52) da ciascun cassetto e fissarlo nella posizione di immagazzinaggio (53).

Per PF-740

47. Estrarre il cassetto destro (54) e il cassetto sinistro (55), rimuovere ciascuno dei fermi (56) della piastra di sollevamento ed applicarli nella posizione di conservazione.

48. Chiudere delicatamente ciascun cassetto.

PF-730 时

47. 拉出各供纸盒，拆下各 1 个升降板挡块 (52)，并安装在保管场所 (53) 上。

PF-740 时

47. 拉出右侧供纸盒 (54) 以及左侧供纸盒 (55)，拆下各 1 个升降板挡块 (56)，并安装在保管场所上。

48. 轻轻地推入各供纸盒。

PF-730 의 경우

47. 각 카세트를 빼고 리프트판 스톱퍼 (52) 각 1 개를 빼내 보관장소 (53) 에 부착합니다 .

PF-740 의 경우

47. 카세트 오른쪽 (54) 및 카세트 왼쪽 (55) 을 꺼내어 리프트판 스톱퍼 (56) 각 1 개를 제거하고 보관장소에 부착합니다

48. 각 카세트를 조용히 밀어 넣습니다 .


PF-730 の場合

47. 各カセットを引き出し、リフト板ストッパー (52) 各 1 個を外して保管場所 (53) に取り付ける。

PF-740 の場合

47. カセット右 (54) およびカセット左 (55) を引き出し、リフト板ストッパー (56) 各 1 個を取り外し、保管場所に取り付ける。

48. 各カセットを静かに押し込む。



When there is 1 power cable

49. Remove a screw (58).

When there are 2 power cables

49. Remove 2 screws (57) and (58).

En cas d'utilisation de 1 seul cordon d'alimentation

49. Retirer la vis (58).

En cas d'utilisation de 2 cordons d'alimentation

49. Retirer les 2 vis (57) et (58).

Si hay 1 cable eléctrico

49. Quite un tornillo (58).

Si hay 2 cables eléctricos

49. Quite 2 tornillos (57) y (58).

Wenn 1 Netzkabel vorhanden ist

49. Die Schraube (58) entfernen.

Wenn 2 Netzkabel vorhanden sind

49. Die 2 Schrauben (57) und (58) entfernen.

Quando esiste 1 cavo di alimentazione

49. Rimuovere una vite (58).

Quando esistono 2 cavi di alimentazione

49. Rimuovere 2 viti (57) e (58).

1 根电源线时

49. 拆除 1 颗螺丝 (58)。

2 根电源线时

49. 拆除 2 颗螺丝 (57) (58)。

전선 코드가 1 개인 경우

49. 나사 (58) 1 개를 제거합니다 .

전선 코드가 2 개인 경우


49. 나사 (57) (58) 2 개를 제거합니다 .

電源コードが 1 本の場合

49. ビス (58) 1 本を外す。

電源コードが 2 本の場合

49. ビス (57) (58) 2 本を外す。



When there is 1 power cable

50. Pass the power cable through the clamp (N) and fasten it using a screw (58) removed in step 49.

When there are 2 power cables

50. Pass the power cable through clamp (N) and fasten it using 2 screws (57) (58) removed in step 49.

En cas d'utilisation de 1 seul cordon d'alimentation

50. Faire passer le cordon d'alimentation au travers de collier (N) et le fixer à l'aide de la vis (58) déposée à l'étape 49.

En cas d'utilisation de 2 cordons d'alimentation

50. Faire passer les cordons d'alimentation au travers des colliers (N) et les fixer à l'aide des 2 vis (57) et (58) déposées à l'étape 49.

Si hay 1 cable eléctrico

50. Pase el cable eléctrico por el sujetador (N) y apriételo con el tornillo (58) que quitó en el paso 49.

Si hay 2 cables eléctricos

50. Pase el cable eléctrico por el sujetador (N) y apriételo con los 2 tornillos (57) y (58) que quitó en el paso 49.

Wenn 1 Netzkabel vorhanden ist

50. Das Netzkabel durch die Klemme (N) führen und es mit der in Schritt 49 entfernten Schraube (58) befestigen.

Wenn 2 Netzkabel vorhanden sind

50. Das Netzkabel durch die Klemme (N) führen und es mit den in Schritt 49 entfernten 2 Schrauben (57) (58) befestigen.

Quando esiste 1 cavo di alimentazione

50. Passare il cavo di alimentazione attraverso il morsetto (N) e stringerlo usando una vite (58) rimossa nel passo 49.

Quando esistono 2 cavi di alimentazione

50. Passare il cavo di alimentazione attraverso il morsetto (N) e stringerlo usando 2 viti (57) (58) rimosse nel passo 49.

1 根电源线时

50. 将电源线穿过束线夹 (N)，使用在步骤 49 中拆除的 1 颗螺丝 (58) 固定电源线。

2 根电源线时

50. 将电源线穿过束线夹 (N)，使用在步骤 49 中拆除的 2 颗螺丝 (57) (58) 固定电源线。

전선 코드가 1 개인 경우

50. 전선 코드를 클램프 (N) 에 통과시키고 순서 49 에서 제거한 나사 (58) 1 개로 고정합니다 .

전선 코드가 2 개인 경우


50. 전선 코드를 클램프 (N) 에 통과시키고 순서 49 에서 제거한 나사 (57) (58) 2 개로 고정합니다 .

電源コードが 1 本の場合

50. 電源コードをクランプ (N) に通し、手順 49 で外したビス (58) 1 本で固定する。

電源コードが 2 本の場合

50. 電源コードをクランプ (N) に通し、手順 49 で外したビス (57) (58) 2 本で固定する。



Setting the paper size plate and media type plate

Insert the paper size plate (G,V) and media type plate (H,X) into the each slots respectively.

Skewed paper feed adjustment (PF-730 only)

1. Connect the MFP power plug to the wall outlet and turn the MFP main power switch on.
2. Load paper into the cassette and make a test copy to check the image.
3. If the image is skewed (skewed paper feed), make the adjustments described below.
<Reference value> Left-right difference of 1.5 mm or less

Disposition des plaquettes du format de papier et du type de support

Introduire la plaquette du format de papier (G,V) et la plaquette du type de support (H,X) dans leur logement respectif.

Réglage de l'entraînement du papier en biais (PF-730 uniquement)

1. Insérer la fiche d'alimentation du MFP dans la prise murale et mettre l'interrupteur principal du MFP sous tension.
2. Mettre du papier dans le tiroir et effectuer une copie d'essai pour vérifier l'image.
3. Si l'image est en biais (entraînement du papier en biais), régler en procédant comme décrit ci-dessous.
<Valeur de référence> Différence de droite à gauche de 1,5 mm ou moins.

Ajuste de la placa de tamaño de papel y la placa de tipo de medio

Inserte la placa de tamaño de papel (G,V) y la placa de tipo de medio (H,X) en cada uno de las ranuras, respectivamente.

Ajuste de alimentación de papel torcida (PF-730 solamente)

1. Conecte el enchufe del MFP en el receptáculo de pared y encienda el interruptor principal del MFP.
2. Introduzca papel en el cajón y haga una copia de prueba para verificar la imagen.
3. Si la imagen está torcida (alimentación del papel torcida) haga los ajustes que se describen a continuación.
<Valor de referencia> diferencia izquierda-derecha de 1,5 mm o menor.

Einsetzen der Papierformatkarte und der Medientypkarte

Setzen Sie die Papierformatkarte (G,V) und die Medientypkarte (H,X) in die jeweiligen Führungen.

Einstellung bei verkantetem Papiereinzug (nur PF-730)

1. Stecken Sie den Netzstecker des MFP in die Wandsteckdose und schalten Sie den MFP am Hauptschalter ein.
2. Legen Sie Papier in die Papierlade ein und machen Sie eine Testkopie, um das Bild zu prüfen.
3. Nehmen Sie nachstehende Einstellungen vor, falls das Bild verkantet ist (verkanteter Papiereinzug).
<Bezugswert> Links-rechts-Differenz maximal 1,5 mm.

Impostazione della piastra di formato carta e della piastra del tipo di supporto

Inserire la piastra del formato carta (G,V) e la piastra del tipo di supporto (H,X) nei rispettivi alloggiamenti.

Regolazione alimentazione obliqua carta (solo PF-730)

1. Collegare la spina del cavo di alimentazione dell'MFP alla presa a muro della rete elettrica e accendere l'interruttore principale di alimentazione.
2. Caricare carta nel cassetto ed eseguire una copia di prova per controllare l'immagine.
3. Se l'immagine risulta obliqua (alimentazione obliqua della carta), eseguire le regolazioni descritte sotto.
<Valore di riferimento> Differenza tra destra e sinistra di 1,5 mm o inferiore

纸张尺寸标示和纸张种类标示的安装

将纸张尺寸标示 (G, V) 和纸张种类标示 (H, X) 分别插入到图示的插槽中。

歪斜进纸调节 (仅限 PF-730)

1. 将 MFP 主机上的电源插头插入电源插座中，打开主电源开关。
2. 在纸盒中放入纸张。进行测试复印以确认图像。
3. 图像倾斜 (歪斜进纸) 时进行以下调节。
<基准值> 左右差 1.5mm 以下

용지크기 플레이트와 용지종류 플레이트의 세트

용지크기 플레이트 (G, V) 와 용지종류 플레이트 (H, X) 를 각 표시 슬롯에 각각 삽입한다.


경사급지 조정 (PF-730 만)

1. MFP 본체 전원플러그를 콘센트에 꽂고 주 전원 스위치를 ON 으로 합니다.
2. 카세트에 용지를 장착합니다. 시험복사를 하고 화상을 확인합니다.
3. 화상이 기울어져 있는 (경사급지) 경우에는 다음 조정을 합니다.
<기준치> 좌우차 1.5mm 이하

用紙サイズプレートと用紙種類プレートのセット
用紙サイズプレート (G, V) と用紙種類プレート (H, X) を各表示スロットにそれぞれ挿入する。

斜め給紙調整 (PF-730 のみ)

1. MFP 本体の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。
2. カセットに用紙をセットする。テストコピーをおこない、画像を確認する。
3. 画像が傾いている (斜め給紙) 場合は次の調整をおこなう。
<基準値> 左右差 1.5mm 以下



4. Pull out the cassette (1) in the paper feeder and loosen the 4 screws (2).
5. Turn the adjusting screw (3) to adjust the cursor skew.
6. Retighten the 4 screws (2).
7. Make another test copy to check the image.

-
4. Sortir le tiroir (1) du bureau papier et desserrer les 4 vis (2).
 5. Faire tourner la vis de réglage (3) pour régler la déviation du curseur.
 6. Resserrer les 4 vis (2).
 7. Faire une autre copie d'essai pour vérifier l'image.

-
4. Extraiga el cajón (1) del alimentador de papel y afloje los 4 tornillos (2).
 5. Gire el tornillo de ajuste (3) para ajustar la desviación del cursor.
 6. Vuelva a apretar los 4 tornillos (2).
 7. Haga otra copia de prueba para verificar la imagen.


-
4. Ziehen Sie die Papierlade (1) aus dem Papiereinzug und lösen Sie die 4 Schrauben (2).
 5. Drehen Sie die Einstellschraube (3), um die Cursor-Verkantung zu korrigieren.
 6. Ziehen Sie die 4 Schrauben (2) wieder an
 7. Erstellen Sie zur Überprüfung des Bilds noch einmal eine Testkopie.

-
4. Estrarre il cassetto (1) dell'unità di alimentazione della carta e quindi allentare le 4 viti (2).
 5. Ruotare la vite di regolazione (3) per regolare l'inclinazione del cursore.
 6. Ristringere le 4 viti (2).
 7. Eseguire un'altra copia di prova per controllare l'immagine.

-
4. 拉出供纸盒 (1)，拧松 4 颗螺丝 (2)。
 5. 旋转调节螺丝 (3)，以调节游标的倾斜。
 6. 拧紧 4 颗螺丝 (2)。
 7. 再次进行测试复印，确认图像。

-
4. 금지 카세트 (1) 를 빼 내어 나사 (2) 4 개를 느슨하게 합니다 .
 5. 조정나사 (3) 을 돌려 커서 경사조정을 합니다 .
 6. 나사 (2) 4 개를 조입니다 .
 7. 다시 시험복사를 하고 화상을 확인합니다 .

-
4. ペーパーフィーダーのカセット (1) を引出し、ビス (2) 4 本を緩める。
 5. 調整ネジ (3) を回し、カーソルの傾き調整をおこなう。
 6. ビス (2) 4 本を締め付ける。
 7. 再度、テストコピーをおこない、画像を確認する。



Changing paper size (PF-740, metric specifications only)

At shipment, Letter is set for inch models and A4 is set for metric models. Use the procedure below to change the size to B5.

1. Pull out the cassette of the paper feeder.
2. Turn the front lock lever (4) 90° and remove the front deck cursor (5).

Modification du format du papier (PF-740, pour spécifications métriques seulement)

À expédition, les modèles à mesure en pouces sont réglés sur le format Letter et les modèles à mesure métrique sur le format A4. Pour passer au format B5, procéder de la manière suivante.

1. Tirer le magasin du bureau papier vers soi.
2. Faire tourner le levier de verrouillage avant (4) de 90° et déposer le curseur de platine avant (5).

Cómo cambiar el tamaño de papel (PF-740, sólo para las especificaciones métricas)

En el momento de salida de fábrica, se configura Carta para los modelos en pulgadas y A4 para los modelos en sistema métrico. Siga este procedimiento para cambiar el tamaño a B5.

1. Abra el casete del alimentador de papel.
2. Gire la palanca de bloqueo frontal (4) 90° y quite el cursor frontal de la plataforma (5).

Ändern des Papierformats (PF-740, nur metrische Spezifikationen)

Beim Werksversand ist bei Modellen mit Zollmaß das Format Letter voreingestellt und bei Modellen mit metrischem Maß das Format A4.

Das Format kann wie folgend auf B5 umgeschaltet werden.

1. Ziehen Sie die Papierlade aus dem Papiereinzug.
2. Den vorderen Verriegelungshebel (4) um 90° drehen und den vorderen Konsole-Cursor (5) abnehmen.

Cambio del formato della carta (PF-740, solo per le specifiche metriche)

Al momento della spedizione, Letter è impostato per le specifiche in pollici e A4 è impostato per le specifiche metriche. Usare la procedura riportata sotto per cambiare il formato a B5.

1. Estrarre il cassetto dell'unità di alimentatore della carta.
2. Ruotare la leva frontale di blocco (4) di 90° e rimuovere il cursore frontale del deck (5).

纸张尺寸更改 (PF-740, 仅限公制规格)

产品出厂时, 英制规格设定为 Letter、公制规格设定为 A4。要将尺寸更改为 B5 时, 请按以下步骤进行操作。

1. 拉出供纸工作台的供纸盒。
2. 将前部锁定杆 (4) 旋转 90°, 拆下堆纸板前部游标 (5)。

용지크기 변경 (PF-740, 센치 사양만)


출하시, 인치사양은 Letter, 센치사양은 A4 로 설정되어 있습니다. 크기를 B5 로 변경하는 경우에는 다음 순서를 진행해 주십시오.

1. 금지대 카세트를 빼 냅니다.
2. 잠금레버 앞 (4) 을 90° 회전시켜 데크커서 앞 (5) 을 제거합니다.


用紙サイズ変更 (PF-740, センチ仕様のみ)

出荷時、インチ仕様は Letter、センチ仕様は A4 に設定されています。サイズを B5 に変更する場合は次の手順をおこなってください。

1. ペーパーフィーダーのカセットを引き出す。
2. ロックレバー前 (4) を 90° 回転させ、デッキカーソル前 (5) を取り外す。



3. Move the front deck cursor (5) so that it is aligned with the size indicators on the top (7) and bottom (6) of the cassette.
4. Turn the front lock lever (4) 90° to lock it.
5. Move the rear deck cursor (8) in the same way.



6. Release the hook (9) and remove the deck trailing edge cursor (10).

3. Déplacer le curseur de platine avant (5) de sorte qu'il soit aligné avec les indicateurs de format en haut (7) et en bas (6) du tiroir.
4. Faire tourner le levier de verrouillage avant (4) de 90° pour le verrouiller.
5. Déplacer le curseur de platine arrière (8) en procédant de la même manière.

6. Libérer le crochet (9) et déposer le curseur du bord arrière de la platine (10).

3. Mueva el cursor frontal de la plataforma (5) para que quede alineado con las indicadores de tamaño de la parte superior (7) e inferior (6) del cajón.
4. Gire la palanca de bloqueo frontal (4) 90° para bloquearla.
5. Mueva el cursor trasero de la plataforma (8) de la misma forma.

6. Libere el gancho (9) y quite el cursor del borde inferior de la plataforma (10).

3. Den vorderen Konsole-Cursor (5) so verschieben, dass er mit den Formatanzeigen oben (7) und unten (6) an der Kassette fluchtet.
4. Den vorderen Verriegelungshebel (4) zum Verriegeln um 90° drehen.
5. Den hinteren Konsole-Cursor (8) auf gleiche Weise verschieben.

6. Den Haken (9) lösen und den Hinterkante-Cursor (10) der Konsole abnehmen.

3. Spostare il cursore frontale del deck (5) in modo che esso risulti allineato con gli indicatori di formato sulla parte superiore (7) e inferiore (6) del cassetto.
4. Ruotare la leva frontale di blocco (4) di 90°, per bloccarla.
5. Spostare il cursore posteriore del deck (8) allo stesso modo.

6. Rilasciare il gancio (9) e rimuovere il cursore del bordo di uscita del deck (10).

3. 移动堆纸板前部游标 (5), 使供纸盒下部的尺寸标记 (6) 与供纸盒上部的尺寸标记 (7) 对齐。
4. 将前部锁定杆 (4) 旋转 90° 以固定。
5. 按同样方式移动后部堆纸板后部游标 (8)。


6. 解除卡扣 (9), 拆下堆纸板后部游标 (10)。

3. 카세트 밑의 크기표시 (6) 와 카세트 위의 크기 표시 (7) 에 맞춰 데크커서 앞 (5) 을 이동시킵니다 .
4. 잠금레버 앞 (4) 을 90° 회전시켜 고정합니다 .
5. 똑같이 데크커서 뒤 (8) 를 이동시킵니다 .

6. 후크 (9) 를 해제하고 데크 뒷단커서 (10) 를 제거합니다 .

3. カセット下のサイズ表示 (6) とカセット上のサイズ表示 (7) に合わせてデッキカーソル前 (5) を移動させる。
4. ロックレバー前 (4) を 90° 回転させ固定する。
5. 同様にデッキカーソル後 (8) を移動させる。

6. フック (9) を解除し、デッキ後端カーソル (10) を取り外す。



7. Lift up the sub-cursor (11).
8. Align with the size indicator (12), engage the hook (13) and install the deck trailing edge cursor (10).

7. Lever le curseur secondaire (11).
8. Aligner avec l'indicateur de format (12), engager le crochet (13) et reposer le curseur du bord arrière de la platine (10).

7. Levante el cursor secundario (11).
8. Alinee con el indicador de tamaño (12), enganche el gancho (13) e instale el cursor del borde inferior de la plataforma. (10).


7. Den Unter-Cursor (11) anheben.
8. Auf die Formatanzeige (12) ausrichten, den Haken (13) einsetzen und den Hinterkante-Cursor (10) der Konsole anbringen.

7. Sollevare il cursore secondario (11).
8. Allineare con l'indicatore formato (12), fissare il gancio (13) e installare il cursore del bordo di uscita del deck (10).

7. 抬起副游标 (11)。
8. 对齐尺寸标记 (12)，将卡扣 (13) 嵌入以安装堆纸板后部游标 (10)。

7. 서브커서 (11) 를 세웁니다 .
8. 크기표시 (12) 에 맞춰 후크 (13) 를 판백데크 후단커서 (10) 를 부착합니다 .

7. サブカーソル (11) を起こす。
8. サイズ表示 (12) に合わせて、フック (13) をはめデッキ後端カーソル (10) を取り付ける。



Adjusting the cursor width (PF-740 only)

1. Load paper in the cassettes.
2. If the gap between the front deck cursor (5) and the paper (14) is outside the 0.5 to 1.5 mm range when the paper (14) is touching up against the rear deck cursor (8), perform the following adjustment.
* A cursor width that is too small can hinder paper feeding, while a cursor width that is too large can lead to problems such as skewed paper feed.

Réglage de la largeur du curseur (PF-740 uniquement)

1. Charger les tiroirs en papier.
2. Si l'écartement entre le curseur de platine avant (5) et le papier (14) est hors des limites de 0,5 à 1,5 mm quand le papier (14) touche le curseur de platine arrière (8), procéder au réglage suivant.
* Une largeur trop faible du curseur risque d'empêcher l'entraînement du papier et une largeur trop grande risque d'entraîner des problèmes du type entraînement du papier de biais.

Cómo ajustar la anchura del cursor (PF-740 solamente)

1. Cargue papel en los cajones.
2. Si la separación entre el cursor frontal de la plataforma (5) y el papel (14) está fuera del rango de 0,5 a 1,5 mm cuando el papel (14) toca el cursor trasero de la plataforma (8), haga el siguiente ajuste.
* Una anchura del cursor demasiado pequeña puede impedir la alimentación de papel; una anchura del cursor demasiado grande puede provocar problemas con la alimentación torcida de papel.

Einstellen der Cursor-Breite (nur PF-740)

1. Papier in die Papierladen einlegen.
2. Falls der Abstand zwischen dem vorderen Konsole-Cursor (5) und dem Papier (14) außerhalb des Bereichs 0,5 bis 1,5 mm liegt, wenn das Papier (14) am hinteren Konsole-Cursor (8) anliegt, ist folgende Einstellung vorzunehmen.
* Eine zu kleine Cursor-Breite kann den Papiereinzug behindern, wogegen eine zu große Cursor-Breite verkanteten Papiereinzug und ähnliche Probleme verursachen kann.

Regolazione della larghezza del cursore (solo PF-740)

1. Caricare carta nei cassetti.
2. Se lo spazio tra il cursore frontale del deck (5) e la carta (14) è fuori della gamma da 0,5 a 1,5 mm quando la carta (14) tocca il cursore posteriore del deck (8), eseguire la regolazione seguente.
* Una larghezza dei cursori troppo piccola può ostacolare l'alimentazione della carta, mentre una larghezza dei cursori troppo grande può essere causa di problemi, come ad esempio l'alimentazione obliqua della carta.

游标宽度的调节 (仅限 PF-740)


1. 在供纸盒中装入纸张。
2. 在堆纸板后部游标 (8) 与纸张 (14) 接触的状态下，如果堆纸板前部游标 (5) 与纸张 (14) 的间隙超出了 0.5 ~ 1.5mm 的范围，须进行以下调节。
※ 如果游标宽度过小，可能造成不供纸，游标宽度过大，则可能发生歪斜进纸等情况。

커서 폭 조정 (PF-740 만)

1. 카세트에 용지를 장착합니다 .
2. 데크커서 뒤 (8) 에 용지 (14) 가 접하고 있는 상태에서 데크커서 앞 (5) 과 용지 (14) 의 틈이 0.5 ~ 1.5mm 의 범위외의 경우에는 이하의 조정을 합니다 .
※ 커서 폭이 작으면 무급지, 커서 폭이 크면 경사급지 등이 발생할 가능성이 있습니다 .

カーソル幅の調整 (PF-740 のみ)

1. カセットに用紙をセットする。
2. デッキカーソル後 (8) に用紙 (14) が接している状態で、デッキカーソル前 (5) と用紙 (14) の隙間が 0.5 ~ 1.5mm の範囲外の場合は、以下の調整をおこなう。
※ カーソル幅が小さいと無給紙、カーソル幅が大きいと斜め給紙などが発生する可能性がある。



3. Insert a Philips-head screwdriver into the 2 long slots (15) in the front deck cursor (5) and loosen the 2 adjusting screws (16). Then move the front deck cursor (5).

4. Retighten the 2 adjusting screws (16).
5. Check that the gap between the front deck cursor (5) and the paper is between 0.5 and 1.5 mm.

3. Insérer un tournevis cruciforme dans les 2 longues fentes (15) du curseur de platine avant (5) et desserrer les 2 vis de réglage (16). Déplacer ensuite le curseur de platine avant (5).

4. Resserrer les 2 vis de réglage (16).
5. Vérifier que l'écartement entre le curseur de platine avant (5) et le papier est entre 0,5 et 1,5 mm.

3. Inserte un destornillador de cabeza Philips en las dos ranuras largas (15) en el cursor frontal de la plataforma (5) y afloje los 2 tornillos de ajuste (16). Después, mueva el cursor frontal de la plataforma (5).

4. Vuelva a apretar los 2 tornillos de ajuste (16).
5. Verifique que la separación entre el cursor frontal de la plataforma (5) y el papel sea de entre 0,5 y 1,5 mm.

3. Einen Kreuzschlitzschraubendreher in die 2 langen Öffnungen (15) im vorderen Konsole-Cursor (5) stecken und die 2 Einstellschrauben (16) lösen. Danach den vorderen Konsole-Cursor (5) verschieben.

4. Die 2 Einstellschrauben (16) wieder anziehen.
5. Vergewissern Sie sich, dass der Abstand zwischen dem vorderen Konsole-Cursor (5) und dem Papier im Bereich 0,5 bis 1,5 mm liegt.

3. Inserire un cacciavite con testa a croce tipo Philips nelle 2 fessure lunghe (15) nel cursore frontale del deck (5) e allentare le 2 viti di regolazione (16). Quindi spostare il cursore frontale del deck (5).

4. Ristringere le 2 viti di regolazione (16).
5. Controllare che lo spazio tra il cursore frontale del deck (5) e la carta sia compreso nella gamma tra 0,5 e 1,5 mm.

3. 将十字螺丝刀从堆纸板前部游标 (5) 的 2 处长孔 (15) 处插入, 拧松 2 颗调节螺丝 (16), 移动堆纸板前部游标 (5)。


4. 拧紧 2 颗调节螺丝 (16)。
5. 确认堆纸板前部游标 (5) 与纸张的间隙在 0.5 ~ 1.5mm 的范围内。

3. 데크커서 앞 (5) 2 곳의 긴 구멍 (15) 에서 플러스 드라이버를 넣어 조정나사 (16) 2 개를 느슨하게 하고 데크커서 앞 (5) 을 이동시킵니다 .

4. 조정나사 (16) 2 개를 조입니다 .
5. 데크커서 앞 (5) 과 용지의 틈이 0.5 ~ 1.5 mm 범위내가 되어 있는 것을 확인합니다 .

3. デッキカーソル前 (5) の 2 箇所 の 長穴 (15) から プラスドライバー 挿入し、調整ビス (16) 2 本を緩め、デッキカーソル前 (5) を移動させる。

4. 調整ビス (16) 2 本を締め付ける。
5. デッキカーソル前 (5) と用紙の隙間が 0.5 ~ 1.5mm の範囲内になっていることを確認する。



Adjusting the center line

The reference value for the center line is ± 0.5 mm or less at position (f) in the correct image (e). If the center line position is outside this range, perform the following adjustment.

1. Set maintenance mode U034, select LSU Out Left and Cassette 5, Cassette 6 or Cassette 7.
2. Adjust the values.
Test pattern (g): Increase the setting value. Test pattern (h): Decrease the setting value.
3. Press the Start key to confirm the setting value.

Réglage de l'axe

La valeur de référence pour l'axe est de $\pm 0,5$ mm ou moins à la position (f) d'une image correcte (e). Si la position de l'axe est hors de cette plage, effectuez le réglage suivant.

1. Passer au mode maintenance U034, sélectionner LSU Out Left et Cassette 5, Cassette 6 ou Cassette 7.
2. Régler les valeurs.
Mire d'essai (g): Augmentez la valeur de réglage. Mire d'essai (h): Diminuez la valeur de réglage.
3. Appuyer sur la touche de Start pour confirmer la valeur de réglage.

Ajuste de la línea central

El valor de referencia de la línea central es de $\pm 0,5$ mm o menor, en la posición (f) de la imagen correcta (e). Si la posición de la línea central estuviera fuera de este rango, haga el siguiente ajuste.

1. Entre al modo mantenimiento U034, seleccione LSU Out Left y Cassette 5, Cassette 6 o Cassette 7.
2. Ajuste los valores.
Patrón de prueba (g): Aumente el valor de configuración. Patrón de prueba (h): Reduzca el valor de configuración.
3. Pulse la tecla de Start para confirmar el valor de configuración.

Einstellen der Mittelinie

Der Bezugswert für die Mittelinie ist $\pm 0,5$ mm oder weniger an Position (f) des korrekten Bilds (e). Falls die Mittelinie außerhalb dieses Bereichs liegt, ist folgende Einstellung vorzunehmen.

1. In den Wartungsmodus U304 schalten und LSU Out Left und Cassette 5, Cassette 6 oder Cassette 7 wählen.
2. Die Werte einstellen.
Testmuster (g): Den Einstellwert erhöhen. Testmuster (h): Den Einstellwert verringern.
3. Den Einstellwert durch Drücken der Start-Taste bestätigen.

Regolazione della linea centrale

Il valore di riferimento per la linea centrale è $\pm 0,5$ mm o inferiore alla posizione (f) nell'immagine corretta (e). Se la posizione della linea centrale è all'infuori di questa gamma, effettuare la regolazione seguente.

1. Impostare la modalità di manutenzione U034, selezionare LSU Out Left e Cassette 5, Cassette 6 o Cassette 7.
2. Regolare i valori.
Modello di prova (g): Aumentare il valore dell'impostazione. Modello di prova (h): Diminuire il valore dell'impostazione.
3. Premere il tasto di Start per confermare il valore dell'impostazione.

中心线调节

中心线的基准值在矫正图像 (e) 的 (f) 位置为 ± 0.5 mm 以内。超出该范围时, 须进行以下调节。

1. 设置维护模式 U034, 选择 LSU Out Left、Cassette5、Cassette6 或 Cassette7。
2. 调整设定值。
测试图案 (g): 调高设定值。测试图案 (h): 调低设定值。
3. 按 Start 键, 以确定设定值。

센터라인 조정

센터라인은 적정화상 (e) 의 (f) 위치에서 기준치는 ± 0.5 mm 이내 . 여기에서 벗어나는 것은 이하의 조정을 합니다 .


1. 메인テナンス 모드 U034 을 세트하고 LSU Out Left, Cassette5, Cassette6 또는 Cassette7 을 선택합니다 .
2. 설정치를 조정합니다 .
테스트 패턴 (g) : 설정치를 높입니다 . 테스트 패턴 (h) : 설정치를 내립니다 .
3. 시작키를 누르고 설정치를 확인합니다 .

センターライン調整


センターラインは、適正画像 (e) の (f) の位置で基準値は ± 0.5 mm 以内。これから外れるときは以下の調整をおこなう。

1. メンテナンスモード U034 をセットし、LSU Out Left、Cassette5、Cassette6 または Cassette7 を選択する。
2. 設定値を調整する。
テストパターン (g) : 設定値を上げる。 テストパターン (h) : 設定値を下げる。
3. スタートキーを押し、設定値を確定する。

INSTALLATION GUIDE FOR 1000-SHEETS FINISHER



English			
Supplied parts			
A. Document finisher.....	1	E. Connecting plate.....	1
B. Eject tray.....	1	F. Wire guide.....	1
C. Upper earth plate.....	1	G. Eject guide.....	1
D. Lower earth plate.....	1	H. Staple cartridge.....	1
		I. M4 × 8 screw.....	3
		J. M4 × 30 screw.....	2
		K. M4 × 10 screw (black).....	1
			Be sure to remove any tape and/or cushioning material from supplied parts.
Français			
Pièces fournies			
A. Retoucheur de document.....	1	E. Plaque de connexion.....	1
B. Bac d'éjection.....	1	F. Guide câble.....	1
C. Prise de terre supérieure.....	1	G. Guide d'éjection.....	1
D. Prise de terre inférieure.....	1	H. Cartouche d'agrafes.....	1
		I. Vis M4 × 8.....	3
		J. Vis M4 × 30.....	2
		K. Vis M4 × 10 (noire).....	1
			Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.
Español			
Partes suministradas			
A. Finalizador de documentos.....	1	E. Placa de conexión.....	1
B. Bandeja de salida.....	1	F. Guía para el cable.....	1
C. Placa de conexión a tierra superior.....	1	G. Guía de salida.....	1
D. Placa de conexión a tierra inferior.....	1	H. Cartucho de grapas.....	1
		I. Tornillo M4 × 8.....	3
		J. Tornillo M4 × 30.....	2
		K. Tornillo M4 × 10 (negro).....	1
			Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.
Deutsch			
Gelieferte Teile			
A. Dokument Finishers.....	1	E. Verbindungsplatte.....	1
B. Auswerffach.....	1	F. Kabelführung.....	1
C. Obere Grundplatte.....	1	G. Auswerfführung.....	1
D. Untere Grundplatte.....	1	H. Heftklammermagazin.....	1
		I. M4 × 8 Schraube.....	3
		J. M4 × 30 Schraube.....	2
		K. M4 × 10 Schraube (schwarz).....	1
			Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.
Italiano			
Parti di forniture			
A. Finitrice di documenti.....	1	E. Piastra di connessione.....	1
B. Vassoio di espulsione.....	1	F. Guida cavi.....	1
C. Piastra di messa a terra superiore.....	1	G. Guida di espulsione.....	1
D. Piastra di messa a terra inferiore.....	1	H. Cartuccia punti metallici.....	1
		I. Vite M4 × 8.....	3
		J. Vite M4 × 30.....	2
		K. Vite M4 × 10 (nera).....	1
			Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.
简体中文			
附属品			
A. 装订器.....	1	E. 连接板.....	1
B. 排纸托盘.....	1	F. 电线导向板.....	1
C. 上部接地板.....	1	G. 排纸导向板.....	1
D. 下部接地板.....	1	H. 装订针盒.....	1
		I. M4×8 螺丝.....	3
		J. M4×30 螺丝.....	2
		K. M4×10 螺丝(黑).....	1
			如果附属品上带有固定胶带, 缓冲材料时务必揭下。
한국어			
동봉품			
A. 문서 피니셔.....	1	E. 연결판.....	1
B. 배출 트레이.....	1	F. 전선 가이드.....	1
C. 접지판 상.....	1	G. 배출 가이드.....	1
D. 접지판 하.....	1	H. 스테이플 카트리지.....	1
		I. 나사 M4×8.....	3
		J. 나사 M4×30.....	2
		K. 나사 M4×10 (흑).....	1
			동봉품에 고정 테이프, 완충재가 붙어 있는 경우에는 반드시 제거할 것.
日本語			
同梱品			
A. ドキュメントフィニッシャー.....	1	E. 連結板.....	1
B. 排出トレイ.....	1	F. 電線ガイド.....	1
C. アース板上.....	1	G. 排出ガイド.....	1
D. アース板下.....	1	H. ステープルカートリッジ.....	1
		I. ビス M4×8.....	3
		J. ビス M4×30.....	2
		K. ビス M4×10(黒).....	1
			同梱品に固定テープ、緩衝材がついている場合は、必ず取り外すこと。



NOTICE

The Attachment Kit (AK-730) must be installed before the document finisher is installed.

Procédure

Before installing the document finisher, make sure that the MFP's main power switch is turned off and that its power cord is unplugged from the power outlet.

1. Install by inserting the 2 hooks (1) on the back of the eject tray (B) into the holes (2) in the document finisher (A) lift.

AVIS

Le gabarit de fixation (AK-730) doit être en place avant de procéder à l'installation du retoucheur de document.

Procédure

Avant d'installer le retoucheur de document, s'assurer que l'interrupteur d'alimentation principal du MFP est hors tension et que le cordon d'alimentation est débranché de la prise secteur.

1. Procéder en insérant les 2 crochets (1) au dos du bac d'éjection (B) dans les trous (2) du dispositif de levage du retoucheur de document (A).

AVISO

El Kit de instalación (AK-730) debe instalarse antes de instalar el finalizador de documentos.

Procedimiento

Antes de instalar el finalizador de documentos, asegúrese de que el interruptor principal de la alimentación de la MFP esté desconectado y que su cable de alimentación esté desenchufado de la toma de corriente.

1. Instale insertando los 2 ganchos (1) de la parte posterior de la bandeja de salida (B) en los orificios (2) del elevador del finalizador de documentos (A).

HINWEIS

Das Gerätezusatz (AK-730) muss installiert werden, bevor man den Dokument-Finisher installiert.

Verfahren

Vor dem Einbau des Dokument-Finishers muss der MFP-Hauptschalter aktiviert, und das Netzka- bel von der Steckdose abgezogen sein.

1. Setzen Sie die 2 Haken (1) zur Befestigung an der Rückseite des Auswerffachs (B) in die Öffnungen (2) an der Hebeplatte (A) des Dokument-Finishers ein.

NOTIFICA

Il kit accessorio (AK-730) deve essere installato prima che sia installata la finitrice di documenti.

Procedura

Prima di installare la finitrice di documenti, assicurarsi che l'interruttore principale della MFP sia spento e che il cavo di alimentazione non sia inserito nella presa.

1. Installare inserendo i 2 ganci (1) sul retro del vassoio di espulsione (B) nei fori (2) sul sollevatore della finitrice di documenti (A).

注意

安装装订器之前，必须先安装连接组件 (AK-730)。

安装步骤

安装装订器时，必须先关闭 MFP 主机的主电源开关，并拔下电源插头后再进行作业。

1. 将排纸托盘排 (B) 内侧的 2 个卡扣 (1) 装入装订器 (A) 的升降板的孔 (2) 中。

주의

문서 피니셔를 장착하기 전에 연결킷 (AK-730) 의 장착을 선행할 것 .

장착순서

문서 피니셔를 장착할 때에는 반드시 MFP 본체의 주 전원 스위치를 OFF 로 하고 전원 플러그를 빼고 작업을 할 것 .

1. 배출 트레이 (B) 의 후면 후크 (1) 2 개를 문서 피니셔 (A) 의 승강판 구멍 (2) 에 넣고 장착합니다 .


注意

ドキュメントフィニッシャーを取り付ける前に、アタッチメントキット (AK-730) の取り付けをおこなうこと。


取付手順

ドキュメントフィニッシャーを取り付ける際は、必ず MFP 本体の主電源スイッチを OFF にし、電源プラグを外して作業をおこなうこと。


1. 排出トレイ (B) の裏側のフック (1) 2 個をドキュメントフィニッシャー (A) の昇降板の穴 (2) に入れて、取り付ける。



2. Secure the upper earth plate (C) and lower earth plate (D) with M4 x 8 screws (I).



3. Install the eject guide (G) by fitting the 2 eject guide pins (3) into the holes in the MFP.



4. Attach the connecting plate (E) to the MFP using 2 M4 x 30 screws (J).
5. Remove the breakaway cover (25) from the left cover.

2. Fixer la plaque de terre supérieure (C) et la plaque de terre inférieure (D) à l'aide des vis M4 x 8 (I).

3. Installer le guide d'éjection (G) en insérant les 2 ergots du guide d'éjection (3) dans les trous du MFP.

4. Fixer la plaque de connexion (E) au MFP à l'aide de 2 vis M4 x 30 (J).
5. Déposer le couvercle amovible (25) du capot gauche.

2. Asegure la placa de conexión a tierra superior (C) y la placa de conexión a tierra inferior (D) con tornillos M4 x 8 (I).

3. Instale la guía de salida (G) encajando los 2 pasadores de la guía de salida (3) en los orificios de la MFP.

4. Fije la placa de conexión (E) a la MFP mediante 2 tornillos M4 x 30 (J).
5. Quite la cubierta divisoria (25) de la cubierta izquierda.

2. Befestigen Sie die obere Grundplatte (C) und die untere Grundplatte (D) mit M4 x 8 Schrauben (I).

3. Bringen Sie die Auswerfführung (G) an, indem Sie die 2 Auswerfführungsstifte (3) in die Öffnungen des MFP stecken.

4. Bringen Sie die Verbindungsplatte (E) mit 2 M4 x 30 Schrauben (J) am MFP an.
5. Nehmen Sie die Ablösungsabdeckung (25) von der linken Abdeckung ab.

2. Fissare la piastra di messa a terra superiore (C) e la piastra di messa a terra inferiore (D) con le viti M4 x 8 (I).

3. Installare la guida di espulsione (G) inserendo i 2 perni (3) della guida di espulsione nei fori dell'MFP.

4. Applicare la piastra di connessione (E) all'MFP utilizzando le 2 viti M4 x 30 (J).
5. Rimuovere il coperchio di distacco (25) dal coperchio sinistro.

2. 将上部接地板 (C) 与下部接地板 (D) 各自使用 M4x8(I) 螺丝进行固定。

3. 将排纸导向板 (G) 的 2 根销钉 (3) 插入 MFP 主机的孔中。

4. 使用 2 颗 M4x30(J) 螺丝将连接板 (E) 安装到 MFP 主机上。
5. 去除左侧盖板上的可去除部 (25)。

2. 접지판 상 (C) 과 접지판 하 (D) 를 각각 나사 M4x8(I) 로 고정합니다 .


3. 배출 가이드 (G) 의 핀 (3) 2 개를 MFP 본체 구멍에 꽂아 장착합니다 .

4. 연결판 (E) 을 나사 M4x30(J) 2 개로 MFP 본체에 장착합니다 .
5. 좌측 커버의 분할커버부 (25) 를 떼어 냅니다 .


2. アース板上 (C) とアース板下 (D) をそれぞれビス M4x8(I) で固定する。

3. 排出ガイド (G) のピン (3) 2 本を MFP 本体の穴に差し込み取り付ける。


4. 連結板 (E) をビス M4x30(J) 2 本で、MFP 本体に取り付ける。
5. 左カバーの割りカバー部 (25) を切り取る。



6. Remove the tape and remove the rear cover (4).



7. Remove the screw (5) and pull the lock frame (6) outwards.
The connecting holes (7) can now be seen.



8. Insert the 2 pins (8) on the connecting plate (E) into the document finisher connecting holes (7) to connect the document finisher to the MFP.
* If you cannot connect the document finisher, adjust the height as described on page 7.

6. Enlever la bande adhésive et déposer le couvercle arrière (4).

7. Déposer la vis (5) et tirer le bâti de verrouillage (6) vers l'extérieur. Les trous de raccordement (7) sont maintenant visibles.

8. Insérer les 2 ergots (8) de la plaque de connexion (E) dans les trous de raccordement du retoucheur de document (7) pour connecter le retoucheur de document au MFP.
* S'il s'avère impossible de connecter le retoucheur de document, en régler la hauteur comme décrit en page 7.

6. Quite la cinta y la cubierta posterior (4).

7. Quite el tornillo (5) y tire de la carcasa de bloqueo (6) hacia fuera. Ahora se ven los orificios de conexión (7).

8. Inserte los 2 pasadores (8) de la placa de conexión (E) en los orificios de conexión del finalizador de documentos (7) para conectarlo a la MFP.
* Si no puede conectar el finalizador de documentos, ajuste la altura como se describe en la página 7.

6. Entfernen Sie das Band und die hintere Abdeckung (4).

7. Entfernen Sie die Schraube (5) und ziehen Sie den Fixierahmen (6) nach außen heraus. Die Verbindungsöffnungen (7) sind nun sichtbar.

8. Stecken Sie die 2 Stifte (8) an der Verbindungsplatte (E) in die Verbindungsöffnungen (7) des Dokument-Finisher, um den Dokument-Finisher mit dem MFP zu verbinden.
* Falls Sie den Dokument-Finisher nicht anschließen können, sollten Sie die Höhe wie auf Seite 7 beschrieben einstellen.

6. Rimuovere il nastro e quindi rimuovere il coperchio posteriore (4).

7. Rimuovere la vite (5) e tirare il telaio di bloccaggio (6) verso l'esterno. È possibile ora vedere i fori di connessione (7).

8. Inserire i 2 perni (8) della piastra di connessione (E) nei fori di connessione (7) della finitrice di documenti, per collegare la finitrice di documenti all'MFP.
* Se non è possibile collegare la finitrice di documenti, regolare l'altezza come descritto a pagina 7.

6. 拆除胶带, 拆下后盖板 (4)。

7. 拆除 1 颗螺丝 (5), 将锁框 (6) 向外拉出。可以看到连接用的孔 (7)。

8. 将连接板 (E) 的 2 根销钉 (8) 插入装订器的连接用孔 (7), 以将装订器与 MFP 主机连接。
※ 如果无法连接, 请进行 P7 的“高度调节”。

6. 테이프를 제거하고 후면커버 (4)를 떼어냅니다.


7. 나사 (5) 1 개를 빼고 잠금 프레임 (6)을 앞으로 뺍니다. 연결용 구멍 (7)이 보입니다.

8. 연결판 (E)의 핀 (8) 2 개를 문서 피니셔의 연결용 구멍 (7)에 삽입하고, 문서 피니셔를 MFP 본체에 접속합니다.
※ 연결할 수 없는 경우에는 P7의 「높이조정」을 할 것.


6. テープを外し、後カバー (4) を取り外す。

7. ビス (5) 1 本を外し、ロックフレーム (6) を手前に引く。
連結用の穴 (7) が見える。


8. 連結板 (E) のピン (8) 2 本をドキュメントフィニッシャーの連結用の穴 (7) に挿入して、ドキュメントフィニッシャーを MFP 本体に接続する。
※ 連結できない場合は、P7 の「高さ調整」を行う。



9. Push the lock frame (6) in fully so that the lock frame ribs fit into the pin slots.
10. Secure the lock frame (6) using the screw (5) removed in step 7.



11. Install the wire guide (F) using the M4 x 8 screw (I).



12. Pass the signal line (9) through the wire guide (F) and connect it to the connector (10) on the MFP.

9. Pousser à fond le bâti de verrouillage (6) de sorte que les nervures du bâti de verrouillage pénètrent dans les encoches des ergots.
10. Fixer le bâti de verrouillage (6) à l'aide de la vis (5) déposée à l'étape 7.

11. Installer le guide câble (F) à l'aide d'une vis M4 x 8 (I).

12. Faire passer la ligne d'interconnexion (9) dans le guide câble (F) et la raccorder au connecteur (10) sur le MFP.

9. Presione la carcasa de bloqueo (6) completamente hacia dentro para que sus nervaduras encajen en las ranuras de los pasadores.
10. Asegure la carcasa de bloqueo (6) por medio del tornillo (5) quitado en el paso 7.

11. Instale la guía para el cable (F) por medio del tornillo M4 x 8 (I).

12. Pase la línea de señales (9) a través de la guía para el cable (F) y conéctela al conector (10) de la MFP.

9. Drücken Sie den Fixierahmen (6) ganz ein, damit die Fixierahmenrippen in die Stiftschlitze greifen.
10. Befestigen Sie den Fixierahmen (6) mit der in Schritt 7 entfernten Schraube (5).

11. Bringen Sie die Kabelführung (F) mit der M4 x 8 Schraube (I) an.

12. Führen Sie die Signalleitung (9) durch die Kabelführung (F) und schließen Sie sie am Steckverbinder (10) des MFP an.

9. Spingere completamente il telaio di bloccaggio (6) in modo che i rilievi del telaio di bloccaggio si inseriscano nelle scanalature dei perni.
10. Fissare il telaio di bloccaggio (6) utilizzando la vite (5) rimossa nel passo 7.

11. Installare la guida cavi (F) utilizzando la vite M4 x 8 (I).

12. Far passare il cavo del segnale (9) attraverso la guida cavi (F) e collegarlo al connettore (10) sull'MFP.

9. 将锁框 (6) 推入到底, 使锁框的肋片嵌入销钉的沟槽内。
10. 使用在步骤 7 中取下的 1 颗螺丝 (5) 来固定锁框 (6)。

11. 使用 1 颗 M4x8(I) 螺丝来安装电线导向板 (F)。

12. 将信号线 (9) 在电线导向板 (F) 上配线, 与 MFP 主机的接插件 (10) 连接。

9. 잠금 프레임 (6) 을 안으로 밀고 핀의 홈에 잠금 프레임 RIB 를 끼워 넣습니다.
10. 순서 7 에서 뺀 나사 (5) 1 개로 잠금 프레임 (6) 을 고정합니다 .


11. 전선 가이드 (F) 를 나사 M4x8(I) 1 개로 장착합니다 .

12. 신호선 (9) 을 전선 가이드 (F) 에 배선하고 MFP 본체의 커넥터 (10) 에 접속합니다 .


9. 록 프레임 (6) 을 奥へ押しして、핀의 溝に 록 프레임의 리브를 是め込む。
10. 手順 7 で外したビス (5) 1 本で、록 프레임 (6) 을 固定する。

11. 電線ガイド (F) をビス M4x8(I) 1 本で取り付ける。


12. 信号線 (9) を電線ガイド (F) に配線し、MFP 本体のコンネクター (10) に接続する。



13. Install the back cover (4) using the M4 × 10 screw (K).



14. Install the interface cover (11)* on the MFP.
* The cover removed while installing the AK-730.



15. Open the document finisher front cover (12) and install the staple cartridge (H).
16. Close the front cover (12).

13. Reposer le couvercle arrière (4) à l'aide des vis M4 × 10 (K).

14. Reposer le couvercle d'interface (11)* sur le MFP.
* Le couvercle a été déposé à l'installation de l'AK-730.

15. Ouvrir le couvercle avant du retoucheur de document (12) et installer la cartouche d'agrafes (H).
16. Refermer le couvercle avant (12).

13. Instale la cubierta posterior (4) por medio del tornillo M4 × 10 (K).

14. Instale la cubierta de la interfaz (11)* en la MFP.
* La cubierta quitada durante la instalación del AK-730.

15. Abra la cubierta frontal del finalizador de documentos (12) e instale el cartucho de grapas (H).
16. Cierre la cubierta frontal (12).

13. Bringen Sie die hintere Abdeckung (4) mit der M4 × 10 Schraube (K) an.

14. Bringen Sie die Schnittstellenabdeckung (11)* am MFP an.
* Die beim Installieren des AK-730 entfernte Abdeckung.

15. Öffnen Sie die vordere Abdeckung (12) des Dokument-Finishers und setzen Sie das Heftklammermagazin (H) ein.
16. Schließen Sie die vordere Abdeckung (12).

13. Installare il pannello anteriore (4) utilizzando la vite M4 × 10 (K).

14. Installare la copertura di interfaccia (11)* sull'MFP.
* La copertura rimossa durante l'installazione dell'AK-730.

15. Aprire il pannello anteriore della finitrice di documenti (12) e installare la cartuccia punti metallici (H).
16. Chiudere il pannello anteriore (12).

13. 使用 M4×10(K) 螺丝来安装后盖板(4)。

14. 将接口盖板(11)* 安装到 MFP 主机上。
* 安装 AK-730 时取下的盖板。

15. 打开装订器的前盖板(12), 安装装订针盒(H)。
16. 关闭前盖板(12)。

13. 나사 M4×10(K) 으로 후면 커버(4) 를 장착합니다.



14. MFP 본체에 인터페이스 커버(11)* 를 장착합니다.
*AK-730 설치 시에 떼어내었던 커버.

15. 문서 피니셔의 전면커버(12) 를 열고 스테이플 카트리지(H) 를 장착합니다.
16. 전면커버(12) 를 닫습니다.

13. ビス M4×10(K) で後カバー(4) を取り付けます。

14. MFP 本体にインターフェイスカバー(11)* を取り付けます。
*AK-730 設置時に取り外したカバー。

15. ドキュメントフィニッシャーの前カバー(12) を開き、ステープルカートリッジ(H) を取り付けます。
16. 前カバー(12) を閉じる。



Adjusting the height

1. Check that the respective heights of the pins (8) on the connecting plate installed on the MFP and the connecting holes (7) on the document finisher comply with the standards below.

Compliant: The diameter (a) of the pin (8) is within the height range (b) of the curved section (13).
 Non-compliant: The diameter (a) of the pin (8) is extends beyond the height range (b) of the curved section (13).
 If the heights are non-compliant, use the procedure below to adjust the height.

Réglage de la hauteur

1. Vérifier que la hauteur des différents ergots (8) de la plaque de connexion installée sur le MFP et les trous de raccordement (7) sur le retoucheur de document sont conformes à ce qui suit.

Bon : Le diamètre (a) de l'ergot (8) est dans les limites de hauteur (b) de la partie courbée (13).
 Mauvais : Le diamètre (a) de l'ergot (8) dépasse les limites de hauteur (b) de la partie courbée (13).
 Si la hauteur n'est pas conforme, l'ajuster en procédant comme indiqué ci-dessous.

Ajuste de la altura

1. Compruebe si las alturas respectivas de los pasadores (8) de la placa de conexión instalada en la MFP y los orificios de conexión (7) del finalizador de documentos cumplen con los siguientes estándares.

Cumple: el diámetro (a) del pasador (8) está dentro del rango de altura (b) de la sección curvada (13).
 No cumple: el diámetro (a) del pasador (8) sobrepasa el rango de altura (b) de la sección curvada (13).
 Si las alturas no cumplen con las especificaciones, utilice el siguiente procedimiento para ajustar la altura.

Einstellen der Höhe

1. Vergewissern Sie sich, dass die jeweilige Höhe der Stifte (8) der am MFP angebrachten Verbindungsplatte und die Verbindungsöffnungen (7) am Dokument-Finisher den nachstehenden Vorgaben entsprechen.

Korrekt: Der Durchmesser (a) des Stifts (8) befindet sich im Höhenbereich (b) des Kurvenabschnitts (13).
 Nicht korrekt: Der Durchmesser (a) des Stifts (8) ragt über den Höhenbereich (b) des Kurvenabschnitts (13) hinaus.
 Falls die Höhen nicht korrekt sind, müssen Sie sie wie folgend einstellen.

Regolazione dell'altezza

1. Controllare che le rispettive altezze dei perni (8) sulla piastra di connessione installata sull'MFP e i fori di connessione (7) sulla finitrice di documenti corrispondano ai riferimenti mostrati sotto.

Conformità: Il diametro (a) del perno (8) è compreso nella gamma di altezza (b) della sezione curvata (13).
 Non conformità: Il diametro (a) del perno (8) si estende oltre la gamma di altezza (b) della sezione curvata (13).
 Se le altezze sono non corrispondenti, utilizzare la procedura riportata sotto per regolare l'altezza.

高度调节

1. 确认 MFP 主机上安装的连接板的销钉 (8) 和装订器的连接用孔 (7) 的高度是否符合以下标准。

符合: 销钉 (8) 的直径 a 在弯曲部 (13) 的高度 b 的范围内。
 不符合: 销钉 (8) 的直径 a 超出了弯曲部 (13) 的高度 b 的范围。
 不符合时, 通过以下步骤进行调节。

높이조정


1. MFP 본체에 장착한 연결판 핀 (8) 과 문서 피니셔의 연결용 구멍 (7) 의 높이가 이하의 기준에 적합한지 확인합니다 .

적합 : 핀 (8) 의 직경 a 가 곡선부 (13) 의 높이 b 의 범위에 들어간다 .
 부적합: 핀 (8) 의 직경 a 가 곡선부 (13) 의 높이 b 의 범위를 넘는다 .
 부적합의 경우에는 이하의 순서대로 조정합니다 .


高さ調整

1. MFP 本体に取り付けた連結板のピン (8) とドキュメントフィニッシャーの連結用の穴 (7) の高さが以下の基準に適合するか確認する。

適合: ピン (8) の直径 a が曲げ部 (13) の高さ b の範囲に収まっている。
 不適合: ピン (8) の直径 a が曲げ部 (13) の高さ b の範囲からはみだしている。
 不適合の場合は、以下の手順で調整する。



2. Remove each of the screws (14) and remove the front foot cover (15) and rear foot cover (16).



3. Remove the screw (17) to remove the spanner (18).

4. Loosen the 2 screws (19) on the front right and on the rear right of the document finisher.

2. Déposer toutes les vis (14) puis le couvercle du pied avant (15) et le couvercle du pied arrière (16).

3. Déposer la vis (17) pour libérer la clé (18).

4. Desserrer les 2 vis (19) du côté avant droit et arrière droit du retoucheur de document.

2. Quite cada uno de los tornillos (14) y quite la cubierta de la pata frontal (15) y la cubierta de la pata posterior (16).

3. Quite el tornillo (17) para extraer la llave inglesa (18).

4. Afloje los 2 tornillos (19) en los lados derecho frontal y derecho posterior del finalizador de documentos.

2. Entfernen Sie sämtliche Schrauben (14) und nehmen Sie die Vorderfußabdeckung (15) und die Hinterfußabdeckung (16).

3. Entfernen Sie die Schraube (17), um den Schlüssel (18) abzunehmen

4. Lösen Sie die 2 Schrauben (19) vorne rechts und hinten rechts am Dokument-Finisher.

2. Rimuovere ciascuna delle viti (14) e quindi rimuovere la copertura del piede anteriore (15) e la copertura del piede posteriore (16).

3. Rimuovere la vite (17) per rimuovere la chiave (18).

4. Allentare le 2 viti (19) sulla parte anteriore destra e posteriore destra della finitrice di documenti.

2. 拆除各 1 顆螺丝 (14), 取下前脚座盖板 (15)、后脚座盖板 (16)。

3. 取下螺丝 (17) 以便拆下扳手 (18)。

4. 拧松装订器右前侧与右后侧的各 2 顆螺丝 (19)。

2. 나사 (14) 각 1 개를 빼고 풋커버 앞 (15), 풋커버 뒤 (16) 를 뺍니다 .



3. 나사 (17) 1 개를 빼고 , 스패너 (18) 를 떼어 냅니다 .

4. 문서 피니셔 우측 앞과 뒤의 나사 (19) 각 2 개를 느슨하게 합니다 .

2. ビス (14) 各 1 本を外し、フットカバー前 (15)、フットカバー後 (16) を取り外す。

3. ビス (17) 1 本を外し、スパナー (18) を取り外す。

4. ドキュメントフィニッシャー右前と右後のビス (19) 各 2 本を緩める。



5. Turn the adjustment bolts (20) with the spanner (18) to adjust the height of the document finisher. Turning the adjustment bolt clockwise lifts the document finisher, and turning it counterclockwise lowers the document finisher.
6. Retighten each of the 2 screws (19) and replace the spanner (18).

7. If the distances between the document finisher and the MFP (21, 22) are unequal, use the procedure below to adjust the spacing.

5. Faire tourner les boulons de réglage (20) avec la clé (18) pour ajuster la hauteur du retoucheur de document.
Tourner le boulon de réglage dans le sens horloger pour lever le retoucheur de document, et dans le sens contraire au sens horloger pour le descendre.
6. Resserer les 2 vis (19) et repositionner la clé (18) au même endroit.

7. Si la distance entre le retoucheur de document et le MFP (21, 22) n'est pas uniforme, régler en procédant de la manière suivante.

5. Gire los pernos de ajuste (20) con la llave inglesa (18) para ajustar la altura del finalizador de documentos.
Al girar el perno de ajuste en la dirección de las manecillas del reloj se levanta el finalizador de documentos y al girar en sentido contrario a las manecillas del reloj baja el finalizador de documentos.
6. Vuelva a apretar los 2 tornillos (19) y coloque la llave inglesa en su lugar (18).

7. Si las distancias entre el finalizador de documentos y la MFP (21, 22) no son iguales, utilice el siguiente procedimiento para ajustar la separación.

5. Drehen Sie die Einstellschrauben (20) mit dem Schlüssel (18), um die Höhe des Dokument-Finishers einzustellen.
Durch Drehen der Einstellschraube im Uhrzeigersinn wird der Dokument-Finisher angehoben, während er durch Drehen entgegen dem Uhrzeigersinn abgesenkt wird.
6. Ziehen Sie die 2 Schrauben (19) wieder an und verstauen Sie den Schlüssel (18) wieder.

7. Falls die Abstände zwischen dem Dokument-Finisher und dem MFP (21, 22) nicht gleich sind, korrigieren Sie sie wie folgend.

5. Ruotare i bulloni di regolazione (20) con la chiave (18) per regolare l'altezza della finitrice di documenti.
Ruotando il bullone di regolazione in senso orario si solleva la finitrice di documenti, mentre ruotandolo in senso antiorario si abbassa la finitrice di documenti.
6. Ristringere ciascuna delle 2 viti (19) e riporre la chiave (18).

7. Se le distanze tra la finitrice di documenti e l'MFP (21, 22) sono disuguali, utilizzare la procedura riportata sotto per regolare la spaziatura.

5. 使用扳手 (18) 旋转调节螺栓 (20), 以调节装订器的高度。
将调节螺栓向顺时针方向旋转, 装订器的高度升高, 逆时针方向旋转则装订器的高度降低。
6. 拧紧各 2 颗螺丝 (19), 按原样安装扳手 (18)。


7. 装订器与 MFP 主机间的间隙 (21、22) 不等时, 按以下步骤进行调节。

5. 스패너 (18) 로 조정 볼트 (20) 를 돌려 문서 피니셔의 높이를 조정한다.
조정 볼트를 시계방향으로 돌리면 문서 피니셔의 높이가 높아지고, 반 시계방향으로 돌리면 낮아 집니다.
6. 나사 (19) 각 2 개를 조이고 스패너 (18) 를 원래 자리에 장착합니다.


7. 문서 피니셔와 MFP 본체의 간격 (21、22) 이 같지 않은 경우에는 이하의 순서대로 조정을 합니다.

5. スパナー (18) で調整ボルト (20) を回し、ドキュメントフィニッシャーの高さを調整する。
調整ボルトを時計方向に回すとドキュメントフィニッシャーの高さが高くなり、反時計方向に回すと低くなる。
6. ビス (19) 各 2 本を締め付け、スパナー (18) を元通り取り付ける。

7. ドキュメントフィニッシャーと MFP 本体の間隔 (21、22) が等しくない場合は、以下の手順で調整を行う。



8. Loosen the 2 screws (23) on the front left and on the rear left of the document finisher.



9. Turn the adjustment bolts (24) with a Philips-head screwdriver to adjust the height of the document finisher.
Turning the adjustment bolt clockwise lifts the document finisher, and turning it counterclockwise lowers the document finisher.

10. Retighten each of the 2 screws (23).

11. Replace the front foot cover (15) and rear foot cover (16).

8. Desserrer les 2 vis (23) du côté avant gauche et arrière gauche du retoucheur de document.

9. Faire tourner les boulons de réglage (24) à l'aide d'un tournevis cruciforme pour ajuster la hauteur du retoucheur de document.
Tourner le boulon de réglage dans le sens horloger pour lever le retoucheur de document, et dans le sens contraire au sens horloger pour le descendre.

10. Resserrer les 2 vis (23).

11. Reposer le couvercle du pied avant (15) et le couvercle du pied arrière (16).

8. Afloje los 2 tornillos (23) en los lados izquierdo frontal e izquierdo posterior del finalizador de documentos.

9. Gire los pernos de ajuste (24) con un destornillador de cabeza Philips para ajustar la altura del finalizador de documentos.
Al girar el perno de ajuste en la dirección de las manecillas del reloj se levanta el finalizador de documentos y al girar en sentido contrario a las manecillas del reloj baja el finalizador de documentos.

10. Vuelva a apretar los 2 tornillos (23).

11. Vuelva a colocar la cubierta de la pata frontal (15) y la cubierta de la pata posterior (16).

8. Lösen Sie die 2 Schrauben (23) vorne links und hinten links am Dokument-Finisher.

9. Stellen Sie die Einstellschrauben (24) mit einem Kreuzschlitzschraubendreher ein, um die Höhe des Dokument-Finishers zu korrigieren.
Durch Drehen der Einstellschraube im Uhrzeigersinn wird der Dokument-Finisher angehoben, während er durch Drehen entgegen dem Uhrzeigersinn abgesenkt wird.

10. Ziehen Sie die 2 Schrauben (23) nach.

11. Setzen Sie die Vorderfußabdeckung (15) und die Hinterfußabdeckung (16) wieder ein.

8. Allentare le 2 viti (23) sulla parte anteriore sinistra e posteriore sinistra della finitrice di documenti.

9. Ruotare i bulloni di regolazione (24) con un cacciavite con testa a croce tipo Philips per regolare l'altezza della finitrice di documenti.
Ruotando il bullone di regolazione in senso orario si solleva la finitrice di documenti, mentre ruotandolo in senso antiorario si abbassa la finitrice di documenti.

10. Ristringere ciascuna delle 2 viti (23).

11. Ricollocare la copertura del piede anteriore (15) e la copertura del piede posteriore (16).

8. 拧松装订器左前侧与左后侧的各2颗螺丝(23)。

9. 使用十字螺丝刀旋转调节螺栓(24),以调节装订器的高度。
将调节螺栓向顺时针方向旋转,装订器的高度升高,逆时针方向旋转则装订器的高度降低。

10. 拧紧各2颗螺丝(23)。

11. 将前脚座盖板(15)、后脚座盖板(16)按原样安装

8. 문서 피니셔 좌측 앞과 뒤의 나사(23) 각 2개를 느슨하게 합니다.

9. 플러스 드라이버로 조정 볼트(24)를 돌려 문서 피니셔 높이를 조정합니다.
조정 볼트를 시계방향으로 돌리면 문서 피니셔의 높이가 높아지고, 반 시계방향으로 돌리면 낮아 집니다.

10. 나사(23) 각 2개를 조입니다.


11. 풋커버 앞(15), 풋커버 뒤(16)를 원래대로 장착합니다.

8. ドキュメントフィニッシャー左前と左後のビス(23)各2本を緩める。

9. プラスドライバーで調整ボルト(24)を回し、ドキュメントフィニッシャーの高さを調整する。
調整ボルトを時計方向に回すとドキュメントフィニッシャーの高さが高くなり、反時計方向に回すと低くなる。

10. ビス(23)各2本を締め付ける。

11. フットカバー前(15)、フットカバー後(16)を元通りに取り付ける。



Adjusting the stapling position

1. Connect the MFP power plug to the wall outlet and turn the MFP main power switch on.
2. Make a test copy using staple mode (double stapled).
3. Check whether the stapling position is off-center. If the staple position is off-center, follow the procedure below to adjust the position.
<Reference value> 78.5 mm \pm 2.5 mm from the center of the paper

Réglage de la position d'agrafage

1. Insérer la fiche d'alimentation du MFP dans la prise murale et mettre l'interrupteur principal du MFP sous tension.
2. Procéder à une copie d'essai en mode agrafage (double agrafage).
3. Vérifier que la position d'agrafage n'est pas en décalage.
Si la position d'agrafage est décalée, la régler en procédant de la manière suivante.
<Valeur de référence> 78,5 mm \pm 2,5 mm depuis le milieu de la feuille de papier.

Ajuste de la posición de grapado

1. Conecte el enchufe del MFP en el receptáculo de pared y encienda el interruptor principal del MFP.
2. Haga una copia de prueba en el modo de grapado (grapado doble).
3. Compruebe si la posición de grapado está descentrada.
Si la posición de grapado está descentrada, realice el siguiente procedimiento para ajustar la posición.
<Valor de referencia> 78,5 mm \pm 2,5 mm del centro del papel

Einstellen der Heftposition

1. Stecken Sie den Netzstecker des MFP in die Wandsteckdose und schalten Sie den MFP am Hauptschalter ein.
2. Erstellen Sie eine Probekopie im Heftmodus (doppelt geheftet).
3. Prüfen Sie, ob die Heftposition außermittig ist.
Falls die Heftposition außermittig ist, müssen Sie sie wie folgend einstellen.
<Bezugswert> 78,5 mm \pm 2,5 mm von der Blattmitte

Regolazione della posizione di spillatura

1. Collegare la spina del cavo di alimentazione dell'MFP alla presa a muro della rete elettrica e accendere l'interruttore principale di alimentazione.
2. Eseguire una copia di prova utilizzando la modalità di spillatura con punti metallici (spillatura doppia).
3. Verificare che la posizione di spillatura non sia fuori centro.
Se la posizione di spillatura è fuori centro, seguire la procedura riportata sotto per regolare la posizione.
<Valore di riferimento> 78,5 mm \pm 2,5 mm dal centro del foglio

调节装订位置


1. 将 MFP 主机上的电源插头插入电源插座中，打开主电源开关。
2. 在装订模式（2 点固定）下进行测试复印。
3. 确认装订位置的中心偏差。装订位置偏离中心时，按以下步骤进行调节。
<基准值> 距离纸张中心 78.5mm \pm 2.5mm

스태이플 위치 조정

1. MFP 본체 전원플러그를 콘센트에 꽂고 주 전원 스위치를 ON 으로 합니다.
2. 스타이플 모드 (2 점) 에서 시험복사를 합니다.
3. 스타이플 위치의 센터 어긋남을 확인합니다. 스타이플 위치가 중심에서 벗어난 경우다음 순서로 조정을 합니다.
<기준치> 용지 센터에서 78.5mm \pm 2.5mm

ステーブル位置の調整

1. MFP 本体の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。
2. ステーブルモード (2 箇所止め) でテストコピーを行う。
3. ステーブル位置のセンターずれを確認する。ステーブル位置が中心からずれていた場合、次の手順で調整を行う。
<基準値> 用紙センターより 78.5mm \pm 2.5mm



4. Set maintenance mode U246, select Finisher and Staple HP.
5. Adjust the values.
If the paper is stapled too close to the front of the machine (a): Increase the setting value.
If the paper is stapled too close to the rear of the machine (b): Decrease the setting value.
6. Perform a test copy.

7. Repeat steps 4 to 6 until the staple position is within the reference value.
<Reference value> 78.5 mm \pm 2.5 mm from the center of the paper

4. Passer en mode maintenance U246, sélectionner Finisher et Staple HP.
5. Régler les valeurs.
Si le papier est agrafé trop près de l'avant de la machine (a): augmenter la valeur de réglage.
Si le papier est agrafé trop près de l'arrière de la machine (b): réduire la valeur de réglage.

6. Effectuer une copie de test.
7. Recommencer les étapes 4 à 6 jusqu'à ce que la position d'agrafe soit conforme à la valeur de référence
<Valeur de référence> 78,5 mm \pm 2,5 mm depuis le milieu de la feuille de papier.

4. Entre en el modo de mantenimiento U246, seleccione Finisher y Staple HP.
5. Ajuste los valores.
Si el grapado del papel se encuentra demasiado cerca del frente de la máquina (a): aumente el valor de configuración.
Si el grapado del papel se encuentra demasiado cerca de la parte posterior de la máquina (b): disminuya el valor de configuración.

6. Haga una copia de prueba.
7. Repita los pasos 4 a 6 hasta que la posición de grapado se encuentre dentro del valor de referencia.
<Valor de referencia> 78,5 mm \pm 2,5 mm del centro del pape

4. Schalten Sie in den Wartungsmodus U246, wählen Sie Finisher und Staple HP.
5. Die Werte einstellen.
Falls das Papier zu nahe am vorderen Rand des Geräts (a) abgestapelt wird: Vergrößern Sie den Stellwert.
Falls das Papier zu nahe am hinteren Rand des Geräts (b) abgestapelt wird: Verkleinern Sie den Stellwert.

6. Eine Testkopie erstellen.
7. Wiederholen Sie die Schritte 4 bis 6, bis die Heftposition im Bereich des Bezugswerts liegt.
<Bezugswert> 78,5 mm \pm 2,5 mm von der Blattmitte

4. Impostare la modalità manutenzione U246, selezionare Finisher e Staple HP.
5. Regolare i valori.
Se il foglio viene spillato troppo vicino alla parte anteriore della macchina (a): Aumentare il valore di impostazione.
Se il foglio viene spillato troppo vicino alla parte posteriore della macchina (b): Diminuire il valore di impostazione.

6. Eseguire una copia di prova.
7. Ripetere i passi 4 to 6 finché la posizione di spillatura risulta all'interno del valore di riferimento.
<Valore di riferimento> 78,5 mm \pm 2,5 mm dal centro del foglio

4. 设置维护模式 U246, 选择 Finisher、Staple HP。
5. 调整设定值。
装订位置向机器前部偏移时 (a): 调高设定值。
装订位置向机器后部偏移时 (b): 调低设定值。
6. 进行测试复印。

7. 重复步骤 4 ~ 6, 直到装订位置在基准范围内为止。
<基准值> 距离纸张中心 78.5mm \pm 2.5mm

4. 메인テナンス 모드 U246 을 세트하고 Finisher, Staple HP 를 선택합니다.
5. 설정치를 조정합니다.
스테이플 위치가 기기앞측으로 벗어난 경우 (a): 설정치를 높입니다.
스테이플 위치가 기기뒷측으로 벗어난 경우 (b): 설정치를 내입니다.
6. 시험복사를 합니다.

7. 스테이플 위치가 기준치내가 될 때까지 순서 4 ~ 6 을 반복합니다.
<기준치> 용지 센터에서 78.5mm \pm 2.5mm

4. メンテナンスモード U246 をセットし、Finisher、Staple HP を選択する。
5. 設定値を調整する。
ステープル位置が機械前側にずれている場合 (a): 設定値を上げる。
ステープル位置が機械後側にずれている場合 (b): 設定値を下げる。
6. テストコピーを行う。

7. ステープル位置が基準値内になるまで、手順 4 ~ 6 を繰り返す。
<基準値> 用紙センターより 78.5mm \pm 2.5mm

INSTALLATION GUIDE FOR 4000-SHEETS FINISHER

English

References to medium-speed MFPs in this document denote 30/30, 35/35, 45/45 and 55/50 ppm color machines, and 35, 45 and 55 ppm monochrome machines.

References to high-speed MFPs in this document denote 65/65 and 75/70 ppm color machines, and 65 and 80 ppm monochrome machines.

Français

Dans le présent document, les références aux MFP à vitesse moyenne renvoient aux machines couleurs 30/30, 35/35, 45/45 et 55/50 ppm et aux machines monochromes 35, 45 et 55 ppm.

Dans le présent document, les références aux MFP à grande vitesse renvoient aux machines couleurs 65/65 et 75/70 ppm et aux machines monochromes 65 et 80 ppm.

Español

Las referencias a las MFP de velocidad media de este documento corresponden a las máquinas a color de 30/30, 35/35, 45/45 y 55/50 ppm y a las máquinas monocromáticas de 35, 45 y 55 ppm.

Las referencias a las MFP de alta velocidad de este documento corresponden a las máquinas a color de 65/65 y 75/70 ppm y a las máquinas monocromáticas de 65 y 80 ppm.

Deutsch

Angaben für MFP der mittleren Leistungsklasse in dieser Anleitung gelten für die 30/30, 35/35, 45/45 und 55/50 ppm Vollfarbenkopierer sowie für die 35, 45 und 55 ppm Monochrommaschinen.

Angaben für MFP der Hochleistungsklasse in dieser Anleitung gelten für die 65/65 und 75/70 ppm Vollfarbenkopierer sowie für die 65 und 80 ppm Monochrommaschinen.

Italiano

I riferimenti per le MFP a velocità media riportati in questo documento indicano le macchine a colori 30/30, 35/35, 45/45 e 55/50 ppm, e le macchine monocromatiche 35, 45 e 55 ppm.

I riferimenti per le MFP a velocità alta riportati in questo documento indicano le macchine a colori 65/65 e 75/70 ppm, e le macchine monocromatiche 65 e 80 ppm.

简体中文

本文中的中速 MFP 代表彩色 30/30 页机型、35/35 页机型、45/45 页机型、55/50 页机型、黑白 35 页机型、45 页机型、55 页机型。

本文中的高速 MFP 代表彩色 65/65 页机型、75/70 页机型、黑白 65 页机型、80 页机型。

한국어


본문 중 중속 MFP 는 컬러 30/30 매기, 35/35 매기, 45/45 매기, 55/50 매기, 흑백 35 매기, 45 매기, 55 매기를 나타냅니다.

본문 중 고속 MFP 는 컬러 65/65 매기, 75/70 매기, 흑백 65 매기, 80 매기를 나타냅니다.

日本語

本文中の中速 MFP はカラー機の 30/30 枚機、35/35 枚機、45/45 枚機、55/50 枚機、モノクロ機の 35 枚機、45 枚機、55 枚機を表す。

本文中の高速 MFP はカラー機の 65/65 枚機、75/70 枚機、モノクロ機の 65 枚機、80 枚機を表す。



Supplied parts

A. Document finisher.....	1
B. Eject tray.....	1
C. Upper earth plate.....	1
D. Earth connection plate.....	1
E. Earth spring.....	1
F. Connecting plate.....	1

G. Wire guide.....	1
H. Eject guide.....	1
I. Staple cartridge.....	1
J. M4 × 8 screw.....	4
K. M4 × 30 screw.....	2
L. M4 × 10 screw (black).....	1

Be sure to remove any tape and/or cushioning material from supplied parts.

Pièces fournies

A. Retoucheur de document.....	1
B. Bac d'éjection.....	1
C. Prise de terre supérieure.....	1
D. Plaque de raccordement de mise à la terre.....	1
E. Ressort de mise à la terre.....	1
F. Plaque de connexion.....	1

G. Guide câble.....	1
H. Guide d'éjection.....	1
I. Cartouche d'agrafes.....	1
J. Vis M4 × 8.....	4
K. Vis M4 × 30.....	2
L. Vis M4 × 10 (noire).....	1

Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.

Partes suministradas

A. Finalizador de documentos.....	1
B. Bandeja de salida.....	1
C. Placa de conexión a tierra superior.....	1
D. Placa de conexión a tierra.....	1
E. Resorte de conexión a tierra.....	1
F. Placa de conexión.....	1

G. Guía para el cable.....	1
H. Guía de salida.....	1
I. Cartucho de grapas.....	1
J. Tornillo M4 × 8.....	4
K. Tornillo M4 × 30.....	2
L. Tornillo M4 × 10 (negro).....	1

Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.

Gelieferte Teile

A. Dokument Finishers.....	1
B. Auswerffach.....	1
C. Obere Grundplatte.....	1
D. Grundanschlussplatte.....	1
E. Grundfeder.....	1
F. Verbindungsplatte.....	1

G. Kabelführung.....	1
H. Auswerfführung.....	1
I. Heftklammermagazin.....	1
J. M4 × 8 Schraube.....	4
K. M4 × 30 Schraube.....	2
L. M4 × 10 Schraube (schwarz).....	1

Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.

Parti di forniture

A. Finitrice di documenti.....	1
B. Vassoio di espulsione.....	1
C. Piastra di messa a terra superiore.....	1
D. Piastra di connessione per messa a terra.....	1
E. Molla di messa a terra.....	1
F. Piastra di connessione.....	1

G. Guida cavi.....	1
H. Guida di espulsione.....	1
I. Cartuccia punti metallici.....	1
J. Vite M4 × 8.....	4
K. Vite M4 × 30.....	2
L. Vite M4 × 10 (nera).....	1

Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.

附属品

A. 装订器.....	1
B. 排纸托盘.....	1
C. 上部接地板.....	1
D. 接地安装板.....	1
E. 接地弹簧.....	1

F. 连接板.....	1
G. 电线导向板.....	1
H. 排纸导向板.....	1
I. 装订针盒.....	1
J. M4×8 螺丝.....	4
K. M4×30 螺丝.....	2

L. M4×10 螺丝 (黑).....	1
----------------------	---

如果附属品上带有固定胶带, 缓冲材料时务必揭下。

동봉품

A. 문서 피니셔.....	1
B. 배출 트레이.....	1
C. 접지판 상.....	1
D. 접지 부착판.....	1
E. 접지 스프링.....	1

F. 연결판.....	1
G. 전선 가이드.....	1
H. 배출 가이드.....	1
I. 스테이플 카트리지.....	1
J. 나사 M4×8.....	4
K. 나사 M4×30.....	2

L. 나사 M4×10 (흑).....	1
----------------------	---


동봉품에 고정 테이프, 완충재가 붙어 있는 경우에는 반드시 제거할 것.

同梱品

A. ドキュメントフィニッシャー.....	1
B. 排出トレイ.....	1
C. アース板上.....	1
D. アース取付板.....	1
E. アースパネ.....	1
F. 連結板.....	1

G. 電線ガイド.....	1
H. 排出ガイド.....	1
I. ステープルカートリッジ.....	1
J. ビス M4×8.....	4
K. ビス M4×30.....	2
L. ビス M4×10 (黒).....	1

同梱品に固定テープ、緩衝材がついている場合は、必ず取り外すこと。



NOTICE

When installing on a medium-speed MFP, the Attachment Kit (AK-730) must be installed before the document finisher is installed.

ProcEDURE

Before installing the document finisher, make sure that the MFP's main power switch is turned off and that its power cord is unplugged from the power outlet.

1. Install by inserting the 2 hooks (1) on the back of the eject tray (B) into the holes (2) in the document finisher (A) lift.

AVIS

Pour le montage sur un MFP à vitesse moyenne, le gabarit de fixation (AK-730) doit être en place avant de procéder à l'installation du retoucheur de document.

Procédure

Avant d'installer le retoucheur de document, s'assurer que l'interrupteur d'alimentation principal du MFP est hors tension et que le cordon d'alimentation est débranché de la prise secteur.

1. Procéder en insérant les 2 crochets (1) au dos du bac d'éjection (B) dans les trous (2) du dispositif de levage du retoucheur de document (A).

AVISO

Cuando instala en una MFP de velocidad media, el Kit de instalación (AK-730) debe instalarse antes de instalar el finalizador de documentos.

Procedimiento

Antes de instalar el finalizador de documentos, asegúrese de que el interruptor principal de la alimentación de la MFP esté desconectado y que su cable de alimentación esté desconectado de la toma de corriente.

1. Instale insertando los 2 ganchos (1) de la parte posterior de la bandeja de salida (B) en los orificios (2) del elevador del finalizador de documentos (A).

HINWEIS

Bei der Installation an einem MFP der mittleren Leistungsklasse muss der Gerätezusatz (AK-730) installiert werden, bevor man den Dokument-Finisher installiert.

Verfahren

Vor dem Einbau des Dokument-Finishers muss der MFP-Hauptschalter aktiviert, und das Netzkaabel von der Steckdose abgezogen sein.

1. Setzen Sie die 2 Haken (1) zur Befestigung an der Rückseite des Auswerffachs (B) in die Öffnungen (2) an der Hebeplatte (A) des Dokument-Finishers ein.

NOTIFICA

Quando si installa su una MFP a velocità media, il kit accessorio (AK-730) deve essere installato prima che sia installata la finitrice di documenti.

Procedura

Prima di installare la finitrice di documenti, assicurarsi che l'interruttore principale della MFP sia spento e che il cavo di alimentazione non sia inserito nella presa.

1. Installare inserendo i 2 ganci (1) sul retro del vassoio di espulsione (B) nei fori (2) sul sollevatore della finitrice di documenti (A).

注意

安装于中速 MFP 上时, 在安装装订器前, 需要先安装连接组件 (AK-730)。

安装步骤

安装装订器时, 必须先关闭 MFP 主机的主电源开关, 并拔下电源插头后再进行作业。

1. 将排纸托盘排 (B) 内侧的 2 个卡扣 (1) 装入装订器 (A) 的升降板的孔 (2) 中。

주의

중속 MFP 에 설치하는 경우, 문서 피니셔를 부착하기 전에 연결 키트 (AK-730) 의 부착을 할 것.

장착순서

문서 피니셔를 장착할 때에는 반드시 MFP 본체의 주 전원 스위치를 OFF 로 하고 전원 플러그를 빼고 작업을 할 것.

1. 배출 트레이 (B) 의 후면 후크 (1) 2 개를 문서 피니셔 (A) 의 승강판 구멍 (2) 에 넣고 장착합니다.


注意

中速 MFP に設置する場合、ドキュメントフィニッシャーを取り付ける前に、アタッチメントキット (AK-730) の取り付けをおこなうこと。


取付手順

ドキュメントフィニッシャーを取り付ける際は、必ず MFP 本体の主電源スイッチを OFF にし、電源プラグを外して作業をおこなうこと。

1. 排出トレイ (B) の裏側のフック (1) 2 個をドキュメントフィニッシャー (A) の昇降板の穴 (2) に入れて、取り付ける。



2. Secure the upper earth plate (C) with an M4 x 8 screw (J).



Installation on medium-speed MFPs

- Using an M4 x 8 screw (J), secure the earth spring (E) in the location indicated by the "55 ↓" marking on the earth connection plate (D).
- Attach the earth connection plate (D) to the center of the bottom of the document finisher using an M4 x 8 screw (J). Proceed to step 7.

2. Monter la fixation supérieure de la mise à la terre (C) à l'aide d'une vis M4 x 8 (J).

Montage sur des MFP à vitesse moyenne

- En procédant à l'aide d'une vis M4 x 8 (J), fixer le ressort de mise à la terre (E) à l'endroit indiqué par la marque "55 ↓" sur la plaque de raccordement de mise à la terre (D).
- Fixer la plaque de raccordement de mise à la terre (D) au milieu de la partie inférieure du retoucheur de document avec une vis M4 x 8 (J). Passer à l'étape 7.

2. Asegure la placa de conexión a tierra superior (C) con un tornillo M4 x 8 (J).

Instalación en las MFP de velocidad media

- Con un tornillo M4 x 8 (J), asegure el resorte de conexión a tierra (E) en el lugar indicado por la marca "55 ↓" de la placa de conexión a tierra (D).
- Fije la placa de conexión a tierra (D) en el centro de la parte inferior del finalizador de documentos usando un tornillo M4 x 8 (J). Vaya al paso 7.

2. Befestigen Sie die obere Grundplatte (C) mit einer M4 x 8 Schraube (J).

Installation an MFP der mittleren Leistungsklasse

- Befestigen Sie die Grundfeder (E) mit einer M4 x 8 Schraube (J) an der mit "55 ↓" bezeichneten Stelle der Grundanschlussplatte (D).
- Bringen Sie die Grundanschlussplatte (D) mit einer M4 x 8 Schraube (J) mittig an der Unterseite des Dokument-Finishers an. Gehen Sie weiter zu Schritt 7.

2. Fissare la piastra di messa a terra superiore (C) con una vite M4 x 8 (J).

Installazione sulle MFP a velocità media

- Utilizzando una vite M4 x 8 (J), fissare la molla di messa a terra (E) nella posizione indicata dal segno "55 ↓" sulla piastra di connessione per messa a terra (D).
- Applicare la piastra di connessione per messa a terra (D) al centro in basso della finitrice di documenti utilizzando una vite M4 x 8 (J). Procedere al passo 7.

2. 使用 M4×8 螺丝 (J) 来固定上部接地板 (C)。

安装于中速 MFP 上时

- 在接地安装板 (D) 上刻有 55 ↓ 的位置使用 1 颗 M4×8 螺丝 (J) 来固定接地弹簧 (E)。
- 使用 M4×8 螺丝 (J) 将接地安装板 (D) 安装到装订器下部中心位置。进至步骤 7。

2. 접지판 상 (C) 을 나사 M4×8(J) 로 고정합니다 .


중속 MFP 에 설치하는 경우

- 접지 부착판 (D) 의 각인 55 ↓ 의 위치에 나사 M4×8(J) 1 개로 접지스프링 (E) 을 고정합니다 .
- 나사 M4×8(J) 로 접지 부착판 (D) 을 문서 피니셔 하부센터에 부착합니다 . 순서 7 로 진행합니다 .

2. アース板上 (C) をビス M4×8(J) で固定する。

中速 MFP に設置の場合

- アース取付板 (D) の刻印 55 ↓ の位置にビス M4×8(J) 1 本でアースバネ (E) を固定する。
- ビス M4×8(J) でアース取付板 (D) をドキュメントフィニッシャー下部センターに取り付ける。手順 7 に進む。



Installation on high-speed MFPs

- Using an M4 × 8 screw (J), secure the earth spring (E) in the location indicated by the "65 ↑" marking on the earth connection plate (D).
- Attach the earth connection plate (D) to the front side of the bottom of the document finisher using an M4 × 8 screw (J).

Montage sur des MFP à grande vitesse

- En procédant à l'aide d'une vis M4 × 8 (J), fixer le ressort de mise à la terre (E) à l'endroit indiqué par la marque "65 ↑" sur la plaque de raccordement de mise à la terre (D).
- Fixer la plaque de raccordement de mise à la terre (D) à l'avant de la partie inférieure du retoucheur de document avec une vis M4 × 8 (J).

Instalación en las MFP de alta velocidad

- Con un tornillo M4 × 8 (J), asegure el resorte de conexión a tierra (E) en el lugar indicado por la marca "65 ↑" de la placa de conexión a tierra (D).
- Fije la placa de conexión a tierra (D) en el lado frontal de la parte inferior del finalizador de documentos usando un tornillo M4 × 8 (J).

Installation an MFP der Hochleistungsklasse

- Befestigen Sie die Grundfeder (E) mit einer M4 × 8 Schraube (J) an der mit "65 ↑" bezeichneten Stelle der Grundanschlussplatte (D).
- Bringen Sie die Grundanschlussplatte (D) mit einer M4 × 8 Schraube (J) vorne an der Unterseite des Dokument-Finishers an.

Installazione sulle MFP a velocità alta

- Utilizzando una vite M4 × 8 (J), fissare la molla di messa a terra (E) nella posizione indicata dal segno "65 ↑" sulla piastra di connessione per messa a terra (D).
- Applicare la piastra di connessione per messa a terra (D) al lato anteriore in basso della finitrice di documenti utilizzando una vite M4 × 8 (J).

安装于高速 MFP 上时


- 在接地安装板 (D) 上刻有 65 ↑ 的位置使用 1 颗 M4×8 螺丝 (J) 来固定接地弹簧 (E)。
- 使用 M4×8 螺丝 (J) 将接地安装板 (D) 安装到装订器下部前侧位置。

고속 MFP 에 설치하는 경우

- 접지 부착판 (D) 의 각인 65 ↑ 의 위치에 나사 M4×8(J) 1 개로 접지스프링 (E) 을 고정합니다 .
- 나사 M4×8(J) 로 접지 부착판 (D) 을 문서 피니셔 하부앞측에 부착합니다 .

高速 MFP に設置の場合

- アース取付板 (D) の刻印 65 ↑ の位置にビス M4×8(J) 1 本でアースバネ (E) を固定する。
- ビス M4×8(J) でアース取付板 (D) をドキュメントフィニッシャー下部前側に取り付ける。



Only for installation on high-speed MFPs

- If installing on a medium-speed MFP, proceed to step 7.
- Remove the MFP interface cover (3).
 - Remove the screw (4) and remove the controller cover (5).

Pour montage sur des MFP à grande vitesse uniquement

- Si le montage est fait sur un MFP à vitesse moyenne, passer à l'étape 7.
- Déposer le couvercle d'interface (3) du MFP.
 - Déposer la vis (4) puis le couvercle du contrôleur (5).

Solo para la instalación en las MFP de alta velocidad

- Si se instala en una MFP de velocidad media, vaya al paso 7.
- Quite la cubierta de la interfaz (3) de la MFP.
 - Quite el tornillo (4) y quite la cubierta del controlador (5).

Nur bei Installation an MFP der Hochleistungsklasse

- Gehen Sie zur Installation an einem MFP der mittleren Leistungsklasse weiter zu Schritt 7.
- Nehmen Sie die MFP-Schnittstellenabdeckung (3) ab.
 - Entfernen Sie die Schraube (4) und nehmen Sie die Controller-Abdeckung (5) ab.

Solo per l'installazione sulle MFP a velocità alta

- Se si installa su una MFP a velocità media, procedere al passo 7.
- Rimuovere la copertura di interfaccia (3) dell'MFP.
 - Rimuovere la vite (4) e quindi rimuovere il coperchio del controller (5).

仅限安装于高速 MFP 上时


- 安装于中速 MFP 上时, 进至步骤 7。
- 拆下 MFP 主机的接口盖板 (3)。
 - 拆除 1 颗螺丝 (4), 拆下控制器盖板 (5)。

고속 MFP 에 설치하는 경우만


- 중속 MFP 에 설치하는 경우에는 순서 7 로 진행합니다 .
- MFP 본체의 인터페이스커버 (3) 을 제거합니다 .
 - 나사 (4) 1 개를 빼고 컨트롤러덮개 (5) 를 제거합니다 .

高速 MFP に設置の場合のみ

- 中速 MFP に設置の場合は手順 7 に進む。
- MFP 本体のインターフェイスカバー (3) を取り外す。
 - ビス (4) 1 本外し、コントローラーフタ (5) を取り外す。



7. Install the eject guide (H) by fitting the 2 eject guide pins (6) into the holes in the MFP.




8. Attach the connecting plate (F) to the MFP using 2 M4 x 30 screws (K).

Only if installing to a medium-speed MFP

If installing on a high-speed MFP, proceed to step 10.

9. Remove the breakaway cover (30) from the left cover.



10. Remove the tape and remove the rear cover (7).

7. Installer le guide d'éjection (H) en insérant les 2 ergots du guide d'éjection (6) dans les trous du MFP.

8. Fixer la plaque de connexion (F) au MFP à l'aide de 2 vis M4 x 30 (K).

Uniquement en cas d'installation sur un MFP à vitesse moyenne

Si le montage est fait sur un MFP à grande vitesse, passer à l'étape 10.

9. Déposer le couvercle amovible (30) du capot gauche.

10. Enlever la bande adhésive et déposer le couvercle arrière (7).

7. Instale la guía de salida (H) encajando los 2 pasadores de la guía de salida (6) en los orificios de la MFP.

8. Fije la placa de conexión (F) a la MFP mediante 2 tornillos M4 x 30 (K).

Solo si instala en una MFP de velocidad media

Si se instala en una MFP de alta velocidad, vaya al paso 10.

9. Quite la cubierta divisoria (30) de la cubierta izquierda.

10. Quite la cinta y la cubierta posterior (7).

7. Bringen Sie die Auswerfführung (H) an, indem Sie die 2 Auswerfführungsstifte (6) in die Öffnungen des MFP stecken.

8. Bringen Sie die Verbindungsplatte (F) mit 2 M4 x 30 Schrauben (K) am MFP an.

Nur bei Installation eines MFP der mittleren Leistungsklasse

Gehen Sie zur Installation an einem MFP der Hochleistungsklasse weiter zu Schritt 10.

9. Nehmen Sie die Ablösungsabdeckung (30) von der linken Abdeckung ab.

10. Entfernen Sie das Band und die hintere Abdeckung (7).

7. Installare la guida di espulsione (H) inserendo i 2 perni (6) della guida di espulsione nei fori dell'MFP.

8. Applicare la piastra di connessione (F) all'MFP utilizzando le 2 viti M4 x 30 (K).

Solo se si installa ad un'MFP a velocità media

Se si installa su una MFP a velocità alta, procedere al passo 10.

9. Rimuovere il coperchio di distacco (30) dal coperchio sinistro.

10. Rimuovere il nastro e quindi rimuovere il coperchio posteriore (7).

7. 将排纸导向板 (H) 的 2 根销钉 (6) 插入 MFP 主机的孔中。

8. 使用 2 颗 M4 x 30 (K) 螺丝将连接板 (F) 安装到 MFP 主机上。

仅限安装于中速机上时

安装于高速 MFP 上时, 进至步骤 10。

9. 去除左侧盖板上的可去除部 (30)。

10. 拆除胶带, 拆下后盖板 (7)。

7. 배출 가이드 (H) 의 핀 (6) 2 개를 MFP 본체 구멍에 꽂아 장착합니다 .

8. 연결판 (F) 을 나사 M4x30(K) 2 개로 MFP 본체에 장착합니다 .

중속 MFP 에 설치할 경우만

고속 MFP 에 설치하는 경우에는 순서 10 로 진행합니다 .

9. 좌측커버의 분할커버부 (30) 를 떼어 냅니다 .

10. 테이프를 제거하고 후면커버 (7) 를 떼어 냅니다 .

7. 排出ガイド (H) のピン (6) 2 本を MFP 本体の穴に差し込み取り付けます。


8. 連結板 (F) をビス M4x30 (K) 2 本で、MFP 本体に取り付けます。

中速 MFP に設置の場合のみ


高速 MFP に設置の場合は手順 10 に進む。

9. 左カバーの割りカバー部 (30) を切り取る。


10. テープを外し、後カバー (7) を取り外す。



- 11.** Remove the screw (8) and pull the lock frame (9) outwards.
The connecting holes (10) can now be seen.



- 12.** Insert the 2 pins (11) on the connecting plate (F) into the document finisher connecting holes (10) to connect the document finisher to the MFP.
* If you cannot connect the document finisher, adjust the height as described on page 8.



- 13.** Push the lock frame (9) in fully so that the lock frame ribs fit into the pin slots.
14. Secure the lock frame (9) using the screw (8) removed in step 11.

- 11.** Déposer la vis (8) et tirer le bâti de verrouillage (9) vers l'extérieur. Les trous de raccordement (10) sont maintenant visibles.

- 12.** Insérer les 2 ergots (11) de la plaque de connexion (F) dans les trous de raccordement du retoucheur de document (10) pour connecter le retoucheur de document au MFP.
* S'il s'avère impossible de connecter le retoucheur de document, en régler la hauteur comme décrit en page 8.

- 13.** Pousser à fond le bâti de verrouillage (9) de sorte que les nervures du bâti de verrouillage pénètrent dans les encoches des ergots.
14. Fixer le bâti de verrouillage (9) à l'aide de la vis (8) déposée à l'étape 11.

- 11.** Quite el tornillo (8) y tire de la carcasa de bloqueo (9) hacia fuera. Ahora se ven los orificios de conexión (10).

- 12.** Inserte los 2 pasadores (11) de la placa de conexión (F) en los orificios de conexión del finalizador de documentos (10) para conectarlo a la MFP.
* Si no puede conectar el finalizador de documentos, ajuste la altura como se describe en la página 8.

- 13.** Presione la carcasa de bloqueo (9) completamente hacia dentro para que sus nervaduras encajen en las ranuras de los pasadores.
14. Asegure la carcasa de bloqueo (9) por medio del tornillo (8) quitado en el paso 11.

- 11.** Entfernen Sie die Schraube (8) und ziehen Sie den Fixierrahmen (9) nach außen heraus. Die Verbindungsöffnungen (10) sind nun sichtbar.

- 12.** Stecken Sie die 2 Stifte (11) an der Verbindungsplatte (F) in die Verbindungsöffnungen (10) des Dokument-Finisher, um den Dokument-Finisher mit dem MFP zu verbinden.
* Falls Sie den Dokument-Finisher nicht anschließen können, sollten Sie die Höhe wie auf Seite 8 beschrieben einstellen.

- 13.** Drücken Sie den Fixierrahmen (9) ganz ein, damit die Fixierrahmenrippen in die Stiftschlitze greifen.
14. Befestigen Sie den Fixierrahmen (9) mit der in Schritt 11 entfernten Schraube (8).

- 11.** Rimuovere la vite (8) e tirare il telaio di bloccaggio (9) verso l'esterno. È possibile ora vedere i fori di connessione (10).

- 12.** Inserire i 2 perni (11) della piastra di connessione (F) nei fori di connessione (10) della finitrice di documenti, per collegare la finitrice di documenti all'MFP.
* Se non è possibile collegare la finitrice di documenti, regolare l'altezza come descritto a pagina 8.

- 13.** Spingere completamente il telaio di bloccaggio (9) in modo che i rilievi del telaio di bloccaggio si inseriscano nelle scanalature dei perni.
14. Fissare il telaio di bloccaggio (9) utilizzando la vite (8) rimossa nel passo 11.

- 11.** 拆除 1 顆螺絲 (8)，將鎖框 (9) 向外拉出。可以看見連接用的孔 (10)。

- 12.** 將連接板 (F) 的 2 根銷釘 (11) 插入裝訂器的連接用孔 (10)，以將裝訂器與 MFP 主機連接。
※ 如果無法連接，請進行 P8 的「高度調節」。

- 13.** 將鎖框 (9) 推入到底，使鎖框的肋片嵌入銷釘的溝槽內。
14. 使用在步驟 11 中取下的 1 顆螺絲 (8) 來固定鎖框 (9)。

- 11.** 나사 (8) 1 개를 빼고 잠금 프레임 (9) 을 앞으로 뺍니다. 연결용 구멍 (10) 이 보입니다.


- 12.** 연결판 (F) 의 핀 (11) 2 개를 문서 피니셔의 연결용 구멍 (10) 에 삽입하고, 문서 피니셔를 MFP 본체에 접속합니다.
※ 연결할 수 없는 경우에는 P8 의 「높이조정」을 할 것.

- 13.** 잠금 프레임 (9) 을 안으로 밀고 핀의 홈에 잠금 프레임 RIB 를 끼워 넣습니다.
14. 순서 11 에서 뺐 나사 (8) 1 개로 잠금 프레임 (9) 을 고정합니다.


- 11.** ビス (8) 1 本を外し、ロックフレーム (9) を手前に引く。
連結用の穴 (10) が見える。

- 12.** 連結板 (F) のピン (11) 2 本をドキュメントフィニッシャーの連結用の穴 (10) に挿入して、ドキュメントフィニッシャーを MFP 本体に接続する。
※ 連結できない場合は、P8 の「高さ調整」を行う。


- 13.** ロックフレーム (9) を奥へ押し、ピンの溝にロックフレームのリップをはめ込む。
14. 手順 11 で外したビス (8) 1 本で、ロックフレーム (9) を固定する。



15. Install the wire guide (G) using the M4 × 8 screw (J).



16. Pass the signal line (12) through the wire guide (G) and connect it to the connector (13) on the MFP.



17. Install the back cover (7) using the M4 × 10 screw (L).

15. Installer le guide câble (G) à l'aide d'une vis M4 × 8 (J).

16. Faire passer la ligne d'interconnexion (12) dans le guide câble (G) et la raccorder au connecteur (13) sur le MFP.

17. Reposer le couvercle arrière (7) à l'aide des vis M4 × 10 (L).

15. Instale la guía para el cable (G) por medio del tornillo M4 × 8 (J).

16. Pase la línea de señales (12) a través de la guía para el cable (G) y conéctela al conector (13) de la MFP.

17. Instale la cubierta posterior (7) por medio del tornillo M4 × 10 (L).

15. Bringen Sie die Kabelführung (G) mit der M4 × 8 Schraube (J) an.

16. Führen Sie die Signalleitung (12) durch die Kabelführung (G) und schließen Sie sie am Steckverbinder (13) des MFP an.

17. Bringen Sie die hintere Abdeckung (7) mit der M4 × 10 Schraube (L) an.

15. Installare la guida cavi (G) utilizzando la vite M4 × 8 (J).

16. Far passare il cavo del segnale (12) attraverso la guida cavi (G) e collegarlo al connettore (13) sull'MFP.

17. Installare il pannello anteriore (7) utilizzando la vite M4 × 10 (L).

15. 使用 1 顆 M4×8(J) 螺丝来安装电线导向板 (G)。

16. 将信号线 (12) 在电线导向板 (G) 上配线, 与 MFP 主机的接插件 (13) 连接。

17. 使用 M4×10(L) 螺丝来安装后盖板 (7)。

15. 전선 가이드 (G) 를 나사 M4×8(J) 1 개로 장착합니다 .


16. 신호선 (12) 을 전선 가이드 (G) 에 배선하고 MFP 본체의 커넥터 (13) 에 접속합니다 .

17. 나사 M4×10(L) 으로 후면 커버 (7) 를 장착합니다 .


15. 電線ガイド (G) をビス M4×8(J) 1 本で取り付けます。

16. 信号線 (12) を電線ガイド (G) に配線し、MFP 本体のコネクター (13) に接続する。


17. ビス M4×10(L) で後カバー (7) を取り付けます。



18. Install the interface cover (3)* on the MFP.
* For installation on medium-speed MFPs, the cover removed while installing the AK-730.



19. Open the document finisher upper front cover (14) and install the staple cartridge (I).
20. Close the front cover (14).



Adjusting the height
1. Check that the respective heights of the pins (11) on the connecting plate installed on the MFP and the connecting holes (10) on the document finisher comply with the standards below.

18. Reposer le couvercle d'interface (3)* sur le MFP.
* Pour montage sur un MFP à vitesse moyenne, enlever le couvercle pour installer l'AK-730.

19. Ouvrir le couvercle avant supérieur (14) du retoucheur de document et installer la cartouche d'agrafes (I).
20. Refermer le couvercle avant (14).

Réglage de la hauteur
1. Vérifier que la hauteur des différents ergots (11) de la plaque de connexion installée sur le MFP et les trous de raccordement (10) sur le retoucheur de document sont conformes à ce qui suit.

18. Instale la cubierta de la interfaz (3)* en la MFP.
* Para la instalación en las MFP de velocidad media, la cubierta quitada durante la instalación del AK-730.

19. Abra la cubierta frontal superior (14) del finalizador de documentos e instale el cartucho de grapas (I).
20. Cierre la cubierta frontal (14).

Ajuste de la altura
1. Compruebe si las alturas respectivas de los pasadores (11) de la placa de conexión instalada en la MFP y los orificios de conexión (10) del finalizador de documentos cumplen con los siguientes estándares.

18. Bringen Sie die Schnittstellenabdeckung (3)* am MFP an.
* Bei Installation an MFP der mittleren Leistungsklasse die beim Installieren des AK-730 abgenommene Abdeckung.

19. Öffnen Sie die obere vordere Abdeckung (14) des Dokument-Finishers und setzen Sie das Heftklammermagazin (I) ein.
20. Schließen Sie die vordere Abdeckung (14).

Einstellen der Höhe
1. Vergewissern Sie sich, dass die jeweilige Höhe der Stifte (11) der am MFP angebrachten Verbindungsplatte und die Verbindungsöffnungen (10) am Dokument-Finisher den nachstehenden Vorgaben entsprechen.

18. Installare la copertura di interfaccia (3)* sull'MFP.
* Per l'installazione sulle MFP a velocità media, la copertura rimossa durante l'installazione dell'AK-730.

19. Aprire il coperchio superiore anteriore (14) della finitrice di documenti e installare la cartuccia punti metallici (I).
20. Chiudere il pannello anteriore (14).

Regolazione dell'altezza
1. Controllare che le rispettive altezze dei perni (11) sulla piastra di connessione installata sull'MFP e i fori di connessione (10) sulla finitrice di documenti corrispondano ai riferimenti mostrati sotto.

18. 将接口盖板 (3)* 安装到 MFP 主机上。
* 安装于中速 MFP 上时, 在为安装 AK-730 时拆下的盖板。

19. 打开装订器的前部上盖板 (14), 安装装订针盒 (I)。
20. 关闭前部上盖板 (14)。

高度调节
1. 确认 MFP 主机上安装的连接板的销钉 (11) 和装订器的连接用孔 (10) 的高度是否符合以下标准。

18. MFP 본체에 인터페이스 커버 (3)* 를 장착합니다.
* 중속 MFP 에 설치하는 경우에는 AK-730 설치 시에 제거한 커버 .


19. 문서 피니셔의 앞 상커버 (14) 를 열고 스테이플 카트리지 (I) 를 장착합니다.
20. 앞 상커버 (14) 를 닫습니다 .

높이조정
1. MFP 본체에 장착한 연결판 핀 (11) 과 문서 피니셔의 연결용 구멍 (10) 의 높이가 이하의 기준에 적합하지 확인합니다 .

18. MFP 本体にインターフェイスカバー (3)* を取り付ける。
* 中速 MFP に設置の場合は、AK-730 設置時に取り外したカバー。


19. ドキュメントフィニッシャーの前上カバー (14) を開き、ステープルカートリッジ (I) を取り付ける。
20. 前上カバー (14) を閉じる。

高さ調整
1. MFP 本体に取り付けた連結板のピン (11) とドキュメントフィニッシャーの連結用の穴 (10) の高さが以下の基準に適合するか確認する。



Compliant: The diameter A of the pin (11) is within the height range B of the curved section (15).
 Non-compliant: The diameter A of the pin (11) extends beyond the height range B of the curved section (15).

If the heights are non-compliant, use the procedure below to adjust the height.



2. Open the upper front cover (14) of the document finisher.
3. Remove the screw (16) and open the lower front cover (17).

Bon : Le diamètre A de l'ergot (11) est dans les limites de hauteur B de la partie courbée (15).

Mauvais : Le diamètre A de l'ergot (11) dépasse les limites de hauteur B de la partie courbée (15).

Si la hauteur n'est pas conforme, l'ajuster en procédant comme indiqué ci-dessous.

2. Ouvrir le couvercle avant supérieur (14) du retoucheur de document.
3. Déposer la vis (16) et ouvrir le couvercle avant inférieur (17).

Cumple: el diámetro A del pasador (11) está dentro del rango de altura B de la sección curvada (15).
 No cumple: el diámetro A del pasador (11) sobrepasa el rango de altura B de la sección curvada (15).

Si las alturas no cumplen con las especificaciones, utilice el siguiente procedimiento para ajustar la altura.

2. Abra la cubierta frontal superior (14) del finalizador de documentos.
3. Quite el tornillo (16) y abra la cubierta frontal inferior (17).

Korrekt: Der Durchmesser A des Stifts (11) befindet sich im Höhenbereich B des Kurvenabschnitts (15).

Nicht korrekt: Der Durchmesser A des Stifts (11) ragt über den Höhenbereich B des Kurvenabschnitts (15) hinaus.

Falls die Höhen nicht korrekt sind, müssen Sie sie wie folgend einstellen.

2. Öffnen Sie die obere vordere Abdeckung (14) des Dokument-Finishers.
3. Entfernen Sie die Schraube (16) und öffnen Sie die untere vordere Abdeckung (17).

Conformità: Il diametro A del perno (11) è compreso nella gamma di altezza B della sezione curvata (15).

Non conformità: Il diametro A del perno (11) si estende oltre la gamma di altezza B della sezione curvata (15).

Se le altezze sono non corrispondenti, utilizzare la procedura riportata sotto per regolare l'altezza.

2. Aprire il coperchio superiore anteriore (14) della finitrice di documenti.
3. Rimuovere la vite (16) ed aprire il coperchio inferiore anteriore (17).

符 合: 销钉 (11) 的直径 A 在弯曲部 (15) 的高度 B 的范围内。

不符合: 销钉 (11) 的直径 A 超出了弯曲部 (15) 的高度 B 的范围。

不符合时, 通过以下步骤进行调节。

2. 打开装订器的前部上盖板 (14)。
3. 拆除 1 颗螺丝 (16), 打开前部下盖板 (17)。

적 합 : 핀 (11) 의 직경 A 가 곡선부 (15) 의 높이 B 의 범위에 들어간다 .

부적합: 핀 (11) 의 직경 A 가 곡선부 (15) 의 높이 B 의 범위를 넘는다 .

부적합의 경우에는 이하의 순서대로 조정합니다 .


2. 문서 피니셔 앞 상커버 (14) 를 엽니다 .
3. 나사 (16) 1 개를 제거하고 앞 하커버 (17) 를 엽니다 .

適 合: ピン (11) の直径 A が曲げ部 (15) の高さ B の範囲に収まっている。


不適合: ピン (11) の直径 A が曲げ部 (15) の高さ B の範囲からはみだしている。

不適合の場合は、以下の手順で調整する。


2. ドキュメントフィニッシャーの前上カバー (14) を開く。
3. ビス (16) 1 本を外し、前下カバー (17) を開く。



4. Remove the 2 screws (18) and remove the foot cover (19).



5. Remove the 3 screws (20) and remove the lower rear cover (21).



6. Remove the screw (22) to remove the spanner (23).

7. Loosen the 2 screws (24) on the front right and on the rear right of the document finisher.

4. Déposer les 2 vis (18) puis le couvercle du pied (19).

5. Déposer les 3 vis (20) puis le couvercle arrière inférieur (21).

6. Déposer la vis (22) pour libérer la clé (23).
7. Desserrer les 2 vis (24) du côté avant droit et arrière droit du retoucheur de document.

4. Quite los 2 tornillos (18) y quite la cubierta de la pata (19).

5. Quite los 3 tornillos (20) y quite la cubierta posterior inferior (21).

6. Quite el tornillo (22) para extraer la llave inglesa (23).
7. Afloje los 2 tornillos (24) en los lados derecho frontal y derecho posterior del finalizador de documentos.

4. Entfernen Sie die 2 Schrauben (18) und nehmen Sie die Fußabdeckung (19) ab.

5. Entfernen Sie die 3 Schrauben (20) und nehmen Sie die untere hintere Abdeckung (21) ab.

6. Entfernen Sie die Schraube (22), um den Schlüssel (23) abzunehmen
7. Lösen Sie die 2 Schrauben (24) vorne rechts und hinten rechts am Dokument-Finisher.

4. Rimuovere le 2 viti (18) e quindi rimuovere la copertura del piede (19).

5. Rimuovere le 3 viti (20) e quindi rimuovere il coperchio inferiore posteriore (21).

6. Rimuovere la vite (22) per rimuovere la chiave (23).
7. Allentare le 2 viti (24) sulla parte anteriore destra e posteriore destra della finitrice di documenti.

4. 拆除 2 顆螺絲 (18), 拆下腳座蓋板 (19)。

5. 拆除 3 顆螺絲 (20), 拆下後部下蓋板 (21)。

6. 取下螺絲 (22) 以便拆下扳手 (23)。
7. 拧松裝訂器右前側與右後側的各 2 顆螺絲 (24)。

4. 나사 (18) 2 개를 제거하고, 풋커버 (19) 를 제거합니다 .



5. 나사 (20) 3 개를 제거하고, 뒤 하커버 (21) 를 제거합니다 .

6. 나사 (22) 1 개를 빼고, 스패너 (23) 를 떼어 냅니다 .
7. 문서 피니셔 우측 앞과 뒤의 나사 (24) 각 2 개를 느슨하게 합니다 .

4. ビス (18) 2 本を外し、フットカバー (19) を取り外す。

5. ビス (20) 3 本を外し、後下カバー (21) を取り外す。

6. ビス (22) 1 本を外し、スパナー (23) を取り外す。
7. ドキュメントフィニッシャー右前と右後のビス (24) 各 2 本を緩める。



8. Turn the adjustment bolts (25) with the spanner (23) to adjust the height of the document finisher. Turning the adjustment bolt clockwise lifts the document finisher, and turning it counterclockwise lowers the document finisher.
9. Retighten each of the 2 screws (24) and replace the spanner (23).

10. If the distances between the document finisher and the MFP (26, 27) are unequal, use the procedure below to adjust the spacing.

8. Faire tourner les boulons de réglage (25) avec la clé (23) pour ajuster la hauteur du retoucheur de document.
Tourner le boulon de réglage dans le sens horloger pour lever le retoucheur de document, et dans le sens contraire au sens horloger pour le descendre.
9. Resserer les 2 vis (24) et repositionner la clé (23) au même endroit.

10. Si la distance entre le retoucheur de document et le MFP (26, 27) n'est pas uniforme, régler en procédant de la manière suivante.

8. Gire los pernos de ajuste (25) con la llave inglesa (23) para ajustar la altura del finalizador de documentos.
Al girar el perno de ajuste en la dirección de las manecillas del reloj se levanta el finalizador de documentos y al girar en sentido contrario a las manecillas del reloj baja el finalizador de documentos.
9. Vuelva a apretar los 2 tornillos (24) y coloque la llave inglesa en su lugar (23).

10. Si las distancias entre el finalizador de documentos y la MFP (26, 27) no son iguales, utilice el siguiente procedimiento para ajustar la separación.

8. Drehen Sie die Einstellschrauben (25) mit dem Schlüssel (23), um die Höhe des Dokument-Finishers einzustellen.
Durch Drehen der Einstellschraube im Uhrzeigersinn wird der Dokument-Finisher angehoben, während er durch Drehen entgegen dem Uhrzeigersinn abgesenkt wird.
9. Ziehen Sie die 2 Schrauben (24) wieder an und verstauen Sie den Schlüssel (23) wieder.

10. Falls die Abstände zwischen dem Dokument-Finisher und dem MFP (26, 27) nicht gleich sind, korrigieren Sie sie wie folgend.

8. Ruotare i bulloni di regolazione (25) con la chiave (23) per regolare l'altezza della finitrice di documenti.
Ruotando il bullone di regolazione in senso orario si solleva la finitrice di documenti, mentre ruotandolo in senso antiorario si abbassa la finitrice di documenti.
9. Ristringere ciascuna delle 2 viti (24) e riporre la chiave (23).

10. Se le distanze tra la finitrice di documenti e l'MFP (26, 27) sono disuguali, utilizzare la procedura riportata sotto per regolare la spaziatura.

8. 使用扳手 (23) 旋转调节螺栓 (25), 以调节装订器的高度。
将调节螺栓向顺时针方向旋转, 装订器的高度升高, 逆时针方向旋转则装订器的高度降低。
9. 拧紧各 2 颗螺丝 (24), 按原样安装扳手 (23)。


10. 装订器与 MFP 主机间的间隙 (26、27) 不等时, 按以下步骤进行调节。

8. 스패너 (23) 로 조정 볼트 (25) 를 돌려 문서 피니셔의 높이를 조정한다.
조정 볼트를 시계방향으로 돌리면 문서 피니셔의 높이가 높아지고, 반 시계방향으로 돌리면 낮아 집니다.
9. 나사 (24) 각 2 개를 조이고 스패너 (23) 를 원래 자리에 장착합니다.


10. 문서 피니셔와 MFP 본체의 간격 (26、27) 이 같지 않은 경우에는 이하의 순서대로 조정을 합니다.

8. スパナー (23) で調整ボルト (25) を回し、ドキュメントフィニッシャーの高さを調整する。
調整ボルトを時計方向に回すとドキュメントフィニッシャーの高さが高くなり、反時計方向に回すと低くなる。
9. ビス (24) 各 2 本を締め付け、スパナー (23) を元通り取り付け。

10. ドキュメントフィニッシャーと MFP 本体の間隔 (26、27) が等しくない場合は、以下の手順で調整を行う。



11. Loosen the 2 screws (28) on the front left and on the rear left of the document finisher.



12. Turn the adjustment bolts (29) with a Phillips-head screwdriver to adjust the height of the document finisher. Turning the adjustment bolt clockwise lifts the document finisher, and turning it counter-clockwise lowers the document finisher.

13. Retighten each of the 2 screws (28).
14. Reinstall the foot cover (19) and lower rear cover (21).

11. Desserrer les 2 vis (28) du côté avant gauche et arrière gauche du retoucheur de document.

12. Faire tourner les boulons de réglage (29) à l'aide d'un tournevis cruciforme pour ajuster la hauteur du retoucheur de document. Tourner le boulon de réglage dans le sens horloger pour lever le retoucheur de document, et dans le sens contraire au sens horloger pour le descendre.

13. Resserrer les 2 vis (28).
14. Reposer le couvercle du pied (19) et le couvercle arrière inférieur (21).

11. Afloje los 2 tornillos (28) en los lados izquierdo frontal e izquierdo posterior del finalizador de documentos.

12. Gire los pernos de ajuste (29) con un destornillador de cabeza Philips para ajustar la altura del finalizador de documentos. Al girar el perno de ajuste en la dirección de las manecillas del reloj se levanta el finalizador de documentos y al girar en sentido contrario a las manecillas del reloj baja el finalizador de documentos.

13. Vuelva a apretar los 2 tornillos (28).
14. Vuelva a instalar la cubierta de la pata (19) y la cubierta posterior inferior (21).

11. Lösen Sie die 2 Schrauben (28) vorne links und hinten links am Dokument-Finisher.

12. Stellen Sie die Einstellschrauben (29) mit einem Kreuzschlitzschraubendreher ein, um die Höhe des Dokument-Finishers zu korrigieren. Durch Drehen der Einstellschraube im Uhrzeigersinn wird der Dokument-Finisher angehoben, während er durch Drehen entgegen dem Uhrzeigersinn abgesenkt wird.

13. Ziehen Sie die 2 Schrauben (28) nach.
14. Setzen Sie die Fußabdeckung (19) und die untere hintere Abdeckung (21) wieder ein.

11. Allentare le 2 viti (28) sulla parte anteriore sinistra e posteriore sinistra della finitrice di documenti.

12. Ruotare i bulloni di regolazione (29) con un cacciavite con testa a croce tipo Philips per regolare l'altezza della finitrice di documenti. Ruotando il bullone di regolazione in senso orario si solleva la finitrice di documenti, mentre ruotandolo in senso antiorario si abbassa la finitrice di documenti.

13. Ristringere ciascuna delle 2 viti (28).
14. Reinstallare la copertura del piede (19) e il coperchio inferiore posteriore (21).

11. 拧松装订器左前侧与左后侧的各2颗螺丝(28)。

12. 使用十字螺丝刀旋转调节螺栓(29),以调节装订器的高度。将调节螺栓向顺时针方向旋转,装订器的高度升高,逆时针方向旋转则装订器的高度降低。

13. 拧紧各2颗螺丝(28)。
14. 按原样安装脚座盖板(19)、后部下盖板(21)。

11. 문서 피니셔 좌측 앞과 뒤의 나사(28) 각 2개를 느슨하게 합니다.


12. 플러스 드라이버로 조정 볼트(29)를 돌려 문서 피니셔 높이를 조정합니다. 조정 볼트를 시계방향으로 돌리면 문서 피니셔의 높이가 높아지고, 반 시계방향으로 돌리면 낮아 집니다.

13. 나사(28) 각 2개를 조입니다.
14. 풋커버(19), 뒤 하커버(21)를 원래대로 제거합니다.

11. ドキュメントフィニッシャー左前と左後のビス(28)各2本を緩める。

12. プラスドライバーで調整ボルト(29)を回し、ドキュメントフィニッシャーの高さを調整する。調整ボルトを時計方向に回すとドキュメントフィニッシャーの高さが高くなり、反時計方向に回すと低くなる。

13. ビス(28)各2本を締め付ける。
14. フットカバー(19)、後下カバー(21)を元通りに取り付ける。



Adjusting the stapling position

1. Connect the MFP power plug to the wall outlet and turn the MFP main power switch on.
2. Make a test copy using staple mode (double stapled).
3. Check whether the stapling position is off-center. If the staple position is off-center, follow the procedure below to adjust the position.
<Reference value> 78.5 mm \pm 2.5 mm from the center of the paper

Réglage de la position d'agrafage

1. Insérer la fiche d'alimentation du MFP dans la prise murale et mettre l'interrupteur principal du MFP sous tension.
2. Procéder à une copie d'essai en mode agrafage (double agrafage).
3. Vérifier que la position d'agrafage n'est pas en décalage.
Si la position d'agrafage est décalée, la régler en procédant de la manière suivante.
<Valeur de référence> 78,5 mm \pm 2,5 mm depuis le milieu de la feuille de papier.

Ajuste de la posición de grapado

1. Conecte el enchufe del MFP en el receptáculo de pared y encienda el interruptor principal del MFP.
2. Haga una copia de prueba en el modo de grapado (grapado doble).
3. Compruebe si la posición de grapado está descentrada.
Si la posición de grapado está descentrada, realice el siguiente procedimiento para ajustar la posición.
<Valor de referencia> 78,5 mm \pm 2,5 mm del centro del papel

Einstellen der Heftposition

1. Stecken Sie den Netzstecker des MFP in die Wandsteckdose und schalten Sie den MFP am Hauptschalter ein.
2. Erstellen Sie eine Probekopie im Heftmodus (doppelt geheftet).
3. Prüfen Sie, ob die Heftposition außermittig ist.
Falls die Heftposition außermittig ist, müssen Sie sie wie folgend einstellen.
<Bezugswert> 78,5 mm \pm 2,5 mm von der Blattmitte

Regolazione della posizione di spillatura

1. Collegare la spina del cavo di alimentazione dell'MFP alla presa a muro della rete elettrica e accendere l'interruttore principale di alimentazione.
2. Eseguire una copia di prova utilizzando la modalità di spillatura con punti metallici (spillatura doppia).
3. Verificare che la posizione di spillatura non sia fuori centro.
Se la posizione di spillatura è fuori centro, seguire la procedura riportata sotto per regolare la posizione.
<Valore di riferimento> 78,5 mm \pm 2,5 mm dal centro del foglio

调节装订位置


1. 将 MFP 主机上的电源插头插入电源插座中，打开主电源开关。
2. 在装订模式（2 点固定）下进行测试复印。
3. 确认装订位置的中心偏差。装订位置偏离中心时，按以下步骤进行调节。
<基准值> 距离纸张中心 78.5mm \pm 2.5mm

스태플 위치 조정

1. MFP 본체 전원플러그를 콘센트에 꽂고 주 전원 스위치를 ON 으로 합니다.
2. 스타플 모드 (2 곳) 에서 시험복사를 합니다.
3. 스타플 위치의 센터 여긔남을 확인합니다. 스타플 위치가 중심에서 벗어난 경우다음 순서로 조정을 합니다.
<기준치> 용지 센터에서 78.5mm \pm 2.5mm

ステーブル位置の調整

1. MFP 本体の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。
2. ステーブルモード (2 箇所止め) でテストコピーを行う。
3. ステーブル位置のセンターずれを確認する。ステーブル位置が中心からずれていた場合、次の手順で調整を行う。
<基準値> 用紙センターより 78.5mm \pm 2.5mm



4. Set maintenance mode U246, select Finisher and Staple HP.
 5. Adjust the values.
 If the paper is stapled too close to the front of the machine (a): Increase the setting value.
 If the paper is stapled too close to the rear of the machine (b): Decrease the setting value.

6. Perform a test copy.
 7. Repeat steps 4 to 6 until the staple position is within the reference value.
 <Reference value> 78.5 mm \pm 2.5 mm from the center of the paper

4. Passer en mode maintenance U246, sélectionner Finisher et Staple HP.
 5. Régler les valeurs.
 Si le papier est agrafé trop près de l'avant de la machine (a): augmenter la valeur de réglage.
 Si le papier est agrafé trop près de l'arrière de la machine (b): réduire la valeur de réglage.

6. Effectuer une copie de test.
 7. Recommencer les étapes 4 à 6 jusqu'à ce que la position d'agrafe soit conforme à la valeur de référence
 <Valeur de référence> 78,5 mm \pm 2,5 mm depuis le milieu de la feuille de papier.

4. Entre en el modo de mantenimiento U246, seleccione Finisher y Staple HP.
 5. Ajuste los valores.
 Si el grapado del papel se encuentra demasiado cerca del frente de la máquina (a): aumente el valor de configuración.
 Si el grapado del papel se encuentra demasiado cerca de la parte posterior de la máquina (b): disminuya el valor de configuración.

6. Haga una copia de prueba.
 7. Repita los pasos 4 a 6 hasta que la posición de grapado se encuentre dentro del valor de referencia.
 <Valor de referencia> 78,5 mm \pm 2,5 mm del centro del pape

4. Schalten Sie in den Wartungsmodus U246, wählen Sie Finisher und Staple HP.
 5. Die Werte einstellen.
 Falls das Papier zu nahe am vorderen Rand des Geräts (a) abgestapelt wird: Vergrößern Sie den Stellwert.
 Falls das Papier zu nahe am hinteren Rand des Geräts (b) abgestapelt wird: Verkleinern Sie den Stellwert.

6. Eine Testkopie erstellen.
 7. Wiederholen Sie die Schritte 4 bis 6, bis die Heftposition im Bereich des Bezugswerts liegt.
 <Bezugswert> 78,5 mm \pm 2,5 mm von der Blattmitte

4. Impostare la modalità manutenzione U246, selezionare Finisher e Staple HP.
 5. Regolare i valori.
 Se il foglio viene spillato troppo vicino alla parte anteriore della macchina (a): Aumentare il valore di impostazione.
 Se il foglio viene spillato troppo vicino alla parte posteriore della macchina (b): Diminuire il valore di impostazione.

6. Eseguire una copia di prova.
 7. Ripetere i passi 4 to 6 finché la posizione di spillatura risulta all'interno del valore di riferimento.
 <Valore di riferimento> 78,5 mm \pm 2,5 mm dal centro del foglio

4. 设置维护模式 U246, 选择 Finisher、Staple HP。
 5. 调整设定值。
 装订位置向机器前部偏移时 (a): 调高设定值。
 装订位置向机器后部偏移时 (b): 调低设定值。

6. 进行测试复印。
 7. 重复步骤 4 ~ 6, 直到装订位置在基准范围内为止。
 <基准值> 距离纸张中心 78.5mm \pm 2.5mm


4. 메인テナンス 모드 U246 을 세트하고 Finisher, Staple HP 를 선택합니다.
 5. 설정치를 조정합니다.
 스테이플 위치가 기기앞측으로 벗어난 경우 (a): 설정치를 높입니다.
 스테이플 위치가 기기뒷측으로 벗어난 경우 (b): 설정치를 내입니다.

6. 시험복사를 합니다.
 7. 스테이플 위치가 기준치내가 될 때까지 순서 4 ~ 6 을 반복합니다.
 <기준치> 용지 센터에서 78.5mm \pm 2.5mm

4. メンテナンスモード U246 をセットし、Finisher、Staple HP を選択する。
 5. 設定値を調整する。
 ステープル位置が機械前側にずれている場合 (a): 設定値を上げる。
 ステープル位置が機械後側にずれている場合 (b): 設定値を下げる。

6. テストコピーを行う。
 7. ステープル位置が基準値内になるまで、手順 4 ~ 6 を繰り返す。
 <基準値> 用紙センターより 78.5mm \pm 2.5mm

INSTALLATION GUIDE FOR FINISHER ATTACHMENT KIT



English	
Supplied parts	
A. Drive unit	1
B. Paper entry unit	1
C. Paper entry unit cover	1
D. Edging	1
E. Rear left stay	1
F. Left scanner cover	1
G. Front left stay	1
H. Eject unit	1
I. Wire stopper	2
J. Upper front cover	1
K. Left connection cover	1

Français	
Pièces fournies	
A. Unité d'entraînement	1
B. Unité d'entrée du papier	1
C. Couvercle de l'unité d'entrée du papier	1
D. Passage	1
E. Support arrière gauche	1
F. Couvercle de scanner gauche	1
G. Support avant gauche	1
H. Unité d'éjection	1
I. Butée de câble	2
J. Couvercle avant supérieur	1
K. Couvercle de connexion gauche	1

Español	
Partes suministradas	
A. Unidad de accionamiento	1
B. Unidad de ingreso de papel	1
C. Cubierta de la unidad de ingreso de papel ...	1
D. Pestaña	1
E. Soporte izquierdo trasero	1
F. Cubierta izquierda del escáner	1
G. Soporte frontal izquierdo	1
H. Unidad de salida	1
I. Tope para cables	2
J. Cubierta frontal superior	1
K. Cubierta de conexiones izquierda	1


Deutsch	
Gelieferte Teile	
A. Antriebseinheit	1
B. Papiereinzugseinheit	1
C. Abdeckung der Papiereinzugseinheit	1
D. Kantenschutz	1
E. Hintere linke Stütze	1
F. Linke Scanner-Abdeckung	1
G. Vordere linke Stütze	1
H. Auswerfeinheit	1
I. Kabelhalter	2
J. Obere vordere Abdeckung	1
K. Linke Verbindungsabdeckung	1

Italiano	
Parti di forniture	
A. Unità guida	1
B. Unità di ingresso carta	1
C. Coperchio unità di ingresso carta	1
D. Bordo	1
E. Supporto posteriore sinistro	1
F. Coperchio sinistro dello scanner	1
G. Supporto anteriore sinistro	1
H. Unità di espulsione	1
I. Fermacavo	2
J. Coperchio superiore anterior	1
K. Coperchio connessione sinistro	1

简体中文	
附属品	
A. 驱动单元	1
B. 进纸单元	1
C. 进纸单元盖板	1
D. 电线护具	1
E. 左后部支架	1
F. 扫描仪左盖板	1
G. 左前部支架	1
H. 排纸单元	1
I. 电线固定夹	2
J. 前上部盖板	1
K. 连接左盖板	1

한국어	
동봉품	
A. 구동 유닛	1
B. 반입 유닛	1
C. 반입 유닛 커버	1
D. 에징	1
E. 좌측 뒷 받침대	1
F. 스캐너 좌측 커버	1
G. 좌측 앞 받침대	1
H. 배출 유닛	1
I. 와이어 스톱퍼	2
J. 전면 상커버	1
K. 연결 좌측커버	1

日本語	
同梱品	
A. 駆動ユニット	1
B. 搬入ユニット	1
C. 搬入ユニットカバー	1
D. エッジング	1
E. 左後ステー	1
F. スキャナー左カバー	1
G. 左前ステー	1
H. 排出ユニット	1
I. ワイヤーストッパー	2
J. 前上カバー	1
K. 連結左カバー	1



- L. Left cover..... 1
- M. Upper left cover..... 1
- N. Paper conveying unit..... 1
- O. M4 × 8 screw..... 7
- P. M4 × 20 screw..... 4
- Q. P Tite screw M3 × 8..... 1
- R. Lower connection cover..... 1

Be sure to remove any tape and/or cushioning material from supplied parts.

Before installing the AK-730, make sure that the MFP's main power switch is turned off and that its power cord is unplugged from the power outlet.

- L. Couverture gauche..... 1
- M. Couverture supérieure gauche..... 1
- N. Unité de transport du papier..... 1
- O. Vis M4 × 8..... 7
- P. Vis M4 × 20..... 4
- Q. Vis P Tite M3 × 8..... 1
- R. Couverture de connexion inférieure..... 1

Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.

Avant d'installer l'AK-730, s'assurer que l'interrupteur d'alimentation principal du MFP est coupé et que le cordon d'alimentation est débranché de la prise secteur.

- L. Cubierta izquierda..... 1
- M. Cubierta superior izquierda..... 1
- N. Unidad de transporte de papel..... 1
- O. Tornillo M4 × 8..... 7
- P. Tornillo M4 × 20..... 4
- Q. Tornillo P Tite M3 × 8..... 1
- R. Cubierta de conexiones inferior..... 1

Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.

Antes de instalar el AK-730, asegúrese de que el interruptor principal de la alimentación de la MFP esté desconectado y que su cable de alimentación esté desenchufado de la toma de corriente.

- L. Linke Abdeckung..... 1
- M. Obere linke Abdeckung..... 1
- N. Papierfördereinheit..... 1
- O. M4 × 8 Schraube..... 7
- P. M4 × 20 Schraube..... 4
- Q. P-Tite-Schraube M3 × 8..... 1
- R. Untere Verbindungsabdeckung..... 1

Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.

Vor dem Einbau des AK-730 muss der MFP-Hauptschalter ausgeschaltet und das Netzkabel von der Steckdose abgezogen sein.

- L. Coperchio sinistro..... 1
- M. Coperchio superiore sinistro..... 1
- N. Unità di trasporto carta..... 1
- O. Vite M4 × 8..... 7
- P. Vite M4 × 20..... 4
- Q. Vite P Tite M3 × 8..... 1
- R. Coperchio connessione inferior..... 1

Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.

Prima di installare l'unità AK-730, assicurarsi che l'interruttore principale dell'MFP sia spento e che il suo cavo di alimentazione sia scollegato presa di corrente.

- L. 左盖板..... 1
- M. 左上部盖板..... 1
- N. 输纸单元..... 1
- O. M4×8 螺丝..... 7
- P. M4×20 螺丝..... 4
- Q. 紧固型 P 螺丝 M3×8..... 1
- R. 连接下盖板..... 1

如果附属品上带有固定胶带, 缓冲材料时务必揭下。

安装 AK-730 时, 请务必将 MFP 主机电源关闭, 关拔下电源插头再进行安装作业。

- L. 좌측 커버..... 1
- M. 좌측 상커버..... 1
- N. 반송 유닛..... 1
- O. 나사 M4×8..... 7
- P. 나사 M4×20..... 4
- Q. 나사 M3×8P Tight..... 1
- R. 연결 하커버..... 1


동봉품에 고정 테이프, 완충재가 붙어 있는 경우에는 반드시 제거할 것 .

AK-730 을 부착할 때에는 반드시 MFP 본체의 주 전원 스위치를 OFF 로 하고 전원 플러그를 제거하고 작업을 할 것 .

- L. 左カバー..... 1
- M. 左上カバー..... 1
- N. 搬送ユニット..... 1
- O. ビス M4×8..... 7
- P. ビス M4×20..... 4
- Q. ビス M3×8P タイト..... 1
- R. 連結下カバー..... 1


同梱品に固定テープ、緩衝材がついている場合は、必ず取り外すこと。

AK-730 を取り付ける際は、必ず MFP 本体の主電源スイッチを OFF にし、電源プラグを外して作業をおこなうこと。




Procedure

1. Remove the 2 screws (2) in the left ISU cover (1).



2. Push in the top and bottom hooks (3) and open the interface cover (4).



3. Remove the 2 screws (5) inside the interface cover (4) and remove the left scanner cover (6).

Procédure

1. Déposer les 2 vis (2) du couvercle gauche de l'ISU (1).

2. Appuyer sur les crochets haut et bas (3) et ouvrir le couvercle de l'interface (4).

3. Déposer les 2 vis (5) à l'intérieur du couvercle de l'interface (4) et déposer le couvercle de scanner gauche (6).

Procedimiento

1. Quite los 2 tornillos (2) de la cubierta ISU izquierda (1).

2. Presione los ganchos superior e inferior (3) y abra la cubierta de la interfaz (4).

3. Quite los 2 tornillos (5) de interior de la cubierta de la interfaz (4) y quite la cubierta izquierda del escáner (6).

Verfahren

1. Entfernen Sie die 2 Schrauben (2) in der linken ISU-Abdeckung (1).

2. Drücken Sie die Haken (3) oben und unten ein und öffnen Sie die Schnittstellenabdeckung (4).

3. Entfernen Sie die 2 Schrauben (5) im Inneren der Schnittstellenabdeckung (4) und nehmen Sie die linke Scanner-Abdeckung (6) ab.

Procedura

1. Rimuovere le 2 viti (2) sul coperchio ISU sinistro (1).

2. Spingere i ganci (3) superiore e inferiore ed aprire la copertura di interfaccia (4).

3. Rimuovere le 2 viti (5) all'interno della copertura di interfaccia (4) e quindi rimuovere il coperchio sinistro dello scanner (6).

安装步骤

1. 卸下 ISU 左盖板 (1) 的 2 颗螺丝 (2)。

2. 按压上下的卡扣 (3) 以打开接口盖板 (4)。

3. 卸下接口盖板 (4) 内侧的 2 颗螺丝 (5)，拆下扫描仪左盖板 (6)。

설치순서

1. ISU 좌측 커버 (1) 의 나사 (2) 2 개를 제거합니다.

2. 상하의 후크 (3) 를 눌러 인터페이스 커버 (4) 를 엽니다.


3. 인터페이스 커버 (4) 안쪽의 나사 (5) 2 개를 제거하고 스캐너 좌측커버 (6) 를 제거합니다.

取付手順


1. ISU 左カバー (1) のビス (2) 2 本を取り外す。

2. 上下のフック (3) を押してインターフェイスカバー (4) を開く。


3. インターフェイスカバー (4) 内側のビス (5) 2 本を外し、スキャナー左カバー (6) を取り外す。



4. Open the front cover (7) on the MFP.
5. Pull out the paper conveyor cover (8).
6. If the operation panel (9) is lowered, raise it to the top position.



7. Remove the screw (11) from the fan cover (10).
8. Remove the screw (12) and pull the upper right cover (13) outwards slightly while removing the front right cover (14).



9. Remove the eject cover (15).
* Pull the lower front side to the left before removing the cover.

4. Ouvrir le capot avant (7) sur le MFP.
5. Sortir le couvercle du transporteur du papier (8).
6. Si le panneau de commande (9) est abaissé, le relever dans sa position maximum.

7. Déposer la vis (11) du couvercle du ventilateur (10).
8. Déposer la vis (12) et tirer légèrement le couvercle supérieur droit (13) vers l'extérieur tout en déposant le couvercle avant droit (14).

9. Déposer le capot d'éjection (15).
* Tirer le côté avant inférieur sur la gauche avant de déposer le capot.

4. Abra la cubierta frontal (7) en la MFP.
5. Extraiga la cubierta de la unidad de transporte de papel (8).
6. Si el panel de trabajo (9) está bajo, levántelo hasta la posición superior.

7. Quite el tornillo (11) de la cubierta del ventilador (10).
8. Quite el tornillo (12) y saque la cubierta superior derecha (13) ligeramente mientras quita la cubierta frontal derecha (14).

9. Quite la cubierta de expulsión (15).
* Tire del lado frontal inferior hacia la izquierda antes de quitar la cubierta.

4. Öffnen Sie die vordere Abdeckung (7) am MFP.
5. Ziehen Sie die Papierfördererabdeckung (8) heraus.
6. Heben Sie das Bedienfeld (9) in die oberste Position, falls es gesenkt ist.

7. Entfernen Sie die Schraube (11) von der Lüfterabdeckung (10).
8. Entfernen Sie die Schraube (12) und ziehen Sie die obere rechte Abdeckung (13) leicht nach außen, während Sie gleichzeitig die vordere rechte Abdeckung (14) abnehmen.

9. Entfernen Sie die Auswerfabdeckung (15).
* Ziehen Sie die untere Vorderseite nach links, bevor Sie die Abdeckung abnehmen.

4. Aprire il pannello anteriore (7) sull'MFP.
5. Estrarre il coperchio di trasporto carta (8).
6. Se il pannello operativo (9) è abbassato, sollevarlo alla posizione in alto.

7. Rimuovere la vite (11) dal coperchio ventola (10).
8. Rimuovere la vite (12) e tirare il coperchio superiore destro (13) leggermente verso l'esterno mentre si rimuove il coperchio anteriore destro (14).

9. Rimuovere il coperchio di espulsione carta (15).
* Tirare il lato anteriore in basso a sinistra prima di rimuovere il coperchio.

4. 打开 MFP 主机的前盖板 (7)。
5. 拉出输纸盖板 (8)。
6. 操作面板 (9) 处于低位时, 将其升到最高位置。

7. 卸下风扇盖板 (10) 的 1 颗螺丝 (11)。
8. 卸下 1 颗螺丝 (12), 稍稍拉出右上部盖板 (13) 的同时, 拆下右前部盖板 (14)。

9. 拆下排纸盖板 (15)。
※ 将盖板前下部向左侧拉出以拆卸。

4. MFP 본체의 전면커버 (7) 를 엽니다 .
5. 반송커버 (8) 를 당겨 냅니다 .
6. 조작판넬 (9) 이 내려가 있는 경우에는 위로 올립니다 .


7. 팬커버 (10) 의 나사 (11) 1 개를 제거합니다 .
8. 나사 (12) 1 개를 제거하고 오른쪽 상커버 (13) 를 조금 당기면서 오른쪽 전면커버 (14) 를 제거합니다 .

9. 배출커버 (15) 를 제거합니다 .
※ 전면 아래쪽을 좌측으로 당겨서 제거합니다 .


4. MFP 本体の前カバー (7) を開く。
5. 搬送カバー (8) を引き出す。
6. 操作パネル (9) が下がっている場合は上位位置に上げる。

7. ファンカバー (10) のビス (11) 1 本を外す。
8. ビス (12) 1 本を外し、右上カバー (13) を少し外に引っ張りながら右前カバー (14) を取り外す。

9. 排出カバー (15) を取り外す。
※ 前下側を左側に引いてから取り外す。



10. Remove the 2 M4 × 8 screws (black) (16) and remove the rear tray cover (17) and scanner bottom cover (18).



11. Insert the hook (19) on the upper side of the drive unit (A) and the projection (20) on the underside into the respective positioning holes (21) (22) in the back plate and secure the drive unit using the 2 M4 × 8 screws (black) (16) removed in step 10.

10. Déposer les 2 vis M4 × 8 (noire) (16) et déposer le couvercle du support arrière (17) et le couvercle inférieur du scanner (18).

11. Insérer le crochet (19) sur le côté supérieur de l'unité d'entraînement (A) et la projection (20) inférieure dans les trous de positionnement correspondant (21) (22) de la tôle arrière et fixer l'unité d'entraînement à l'aide des 2 vis M4 × 8 (noire) (16) déposées à l'étape 10.

10. Quite los 2 tornillos M4 × 8 (negro) (16) y quite la cubierta izquierda de la bandeja (17) y la cubierta inferior del escáner (18).

11. Inserte el gancho (19) del lado superior de la unidad de accionamiento (A) y el saliente (20) del lado inferior en sus respectivos orificios de posición (21) (22) en la placa posterior y asegure la unidad de accionamiento usando los 2 tornillos M4 × 8 (negro) (16) quitados en el paso 10.

10. Entfernen Sie die 2 M4 × 8 (schwarz) Schrauben (16) und nehmen Sie die hintere Fachabdeckung (17) und die Scanner-Bodenabdeckung (18) ab.

11. Setzen Sie den Haken (19) an der Oberseite der Antriebseinheit (A) und den Vorsprung (20) an der Unterseite in die entsprechenden Positionierungsöffnungen (21) (22) der Rückplatte ein und sichern Sie die Antriebseinheit mit den 2 in Schritt 10 entfernten M4 × 8 (schwarz) Schrauben (16).

10. Rimuovere le 2 viti M4 × 8 (nera) (16) e quindi rimuovere il coperchio posteriore del vassoio (17) e il coperchio in basso dello scanner (18).

11. Inserire il gancio (19) sul lato superiore dell'unità guida (A) e la parte sporgente (20) sulla parte inferiore, nei rispettivi fori di posizionamento (21) (22) nella piastra posteriore e fissare l'unità guida usando le 2 viti M4 × 8 (nera) (16) rimosse nel punto 10.

10. 卸下 2 顆螺絲 M4×8(黑)(16), 拆下托盤後部蓋板(17) 以及掃描儀底部蓋板(18)。


11. 將驅動單元(A) 上部的卡扣(19) 和下部的突出部(20) 分別插入背板的定位孔(21)(22) 中, 使用步驟 10 中卸下的 2 顆螺絲 M4×8(黑)(16) 進行固定。

10. 나사 M4×8(흑)(16) 2 개를 제거하고 트레이 뒷커버(17) 및 스캐너 밑커버(18) 를 제거합니다.


11. 구동 유닛(A) 윗쪽 후크(19) 및 아래쪽 돌기(20) 를 뒷판의 위치고정 구멍(21)(22) 에 각각 넣고 순서 10 의 나사 M4×8(흑)(16) 2 개로 고정합니다.

10. 비스 M4×8(黑)(16) 2 본을 외시, 트레이 후커버(17)および스캐너-底커버(18)를取り外す。

11. 駆動ユニット(A) 上側のフック(19)および下側の突起(20)を後板の位置決め穴(21)(22)にそれぞれ入れ、手順10のビスM4×8(黒)(16)2本で固定する。



12. Remove the paper entry unit cover (C) from the paper entry unit (B).



13. Insert the projection (23) on the paper entry unit (B) into the hole (24) in the drive unit (A) and insert the projection (25) into the hole (26) in the MFP frame to attach the paper entry unit (B). Push the paper entry unit (B) to the right and fit the projection (25) into the hole (26) until it clicks into place.

NOTICE

When installing the paper entry unit, take care not to dislodge the paper eject actuator (27). After installing the unit, check the operation of the actuator.

12. Déposer le couvercle de l'unité d'entrée du papier (C) de l'unité d'entrée du papier (B).

13. Insérer la projection (23) de l'unité d'entrée du papier (B) dans le trou (24) de l'unité d'entraînement (A) et insérer la projection (25) dans le trou (26) du bâti du MFP pour fixer l'unité d'entrée du papier (B). Pousser l'unité d'entrée du papier (B) vers la droite et insérer la projection (25) dans le trou (26) jusqu'au clic.

AVIS

À l'installation de l'unité d'entrée du papier, attention à ne pas déplacer l'actionneur d'éjection du papier (27). Après avoir installé l'unité, vérifier le bon fonctionnement de l'actuateur.

12. Quite la cubierta de la unidad de ingreso de papel (C) de la unidad de ingreso de papel (B).

13. Inserte el saliente (23) de la unidad de ingreso de papel (B) en el orificio (24) de la unidad de accionamiento (A) e inserte el saliente (25) en el orificio (26) de la carcasa de la MFP para fijar la unidad de ingreso de papel (B). Presione la unidad de ingreso de papel (B) hacia la derecha y encaje el saliente (25) en el orificio (26) hasta escuchar un clic.

AVISO

Cuando instale la unidad de ingreso de papel tenga cuidado de no desplazar el actuador de expulsión de papel (27). Después de instalar la unidad, compruebe el funcionamiento del actuador.

12. Nehmen Sie die Abdeckung der Papiereinzugseinheit (C) von der Papiereinzugseinheit (B) ab.

13. Setzen Sie den Vorsprung (23) an der Papiereinzugseinheit (B) in die Öffnung (24) der Antriebseinheit (A) ein und setzen Sie den Vorsprung (25) in die Öffnung (26) im MFP-Rahmen ein, um die Papiereinzugseinheit (B) anzubringen. Drücken Sie die Papiereinzugseinheit (B) nach rechts und drücken Sie den Vorsprung (25) in die Öffnung (26), bis er einrastet.

HINWEIS

Achten Sie beim Anbringen der Papiereinzugseinheit darauf, dass der Papierauswerfaktuator (27) nicht abspringt. Überprüfen Sie nach dem Montieren der Einheit die Funktionsfähigkeit des Aktuators.

12. Rimuovere il coperchio unità di ingresso carta (C) dell'unità di ingresso carta (B).

13. Inserire la parte sporgente (23) sull'unità di ingresso carta (B) nel foro (24) dell'unità guida (A), ed inserire la parte sporgente (25) nel foro (26) del telaio dell'MFP per fissare l'unità di ingresso carta (B). Spingere l'unità di ingresso carta (B) alla destra ed inserire la parte sporgente (25) nel foro (26) finché non scatta in posizione con un clic.

NOTIFICA

Quando si installa l'unità di ingresso carta, fare attenzione a non rimuovere l'attuatore (27) di espulsione carta. Dopo l'installazione dell'unità, controllare il funzionamento dell'attuatore.

12. 把搬运组件的盖板 (C) 从搬运组件 (B) 上取下。

13. 将进纸单元 (B) 的突出部 (23) 插入驱动单元 (A) 的孔 (24) 中, 将突出部 (25) 插入主机框架的孔 (26) 中以安装进纸单元 (B)。

将进纸单元 (B) 向右侧推, 直到突出部 (25) 嵌入孔 (26) 中并发出咔嚓声为止。

注意

安装进纸单元时, 请勿拆卸排出执行元件 (27)。安装后, 必须进行执行元件的动作确认。

12. 반입 유닛 (B) 에서 반입 유닛 커버 (C) 를 제거합니다 .

13. 반입 유닛 (B) 의 돌기 (23) 를 구동 유닛 (A) 의 구멍 (24) 에 넣고 돌기 (25) 를 본체 프레임 구멍 (26) 에 넣어 반입 유닛 (B) 를 장착합니다 .

반입 유닛 (B) 를 오른쪽으로 밀고 돌기 (25) 를 구멍 (26) 에 딸깍하고 소리가 날 때까지 끼웁니다 .

주의

반입 유닛을 부착할 때에는 배출 액츄에이터 (27) 가 빠지지 않도록 작업을 합니다 . 부착 후 액츄에이터의 동작 확인을 합니다 .


12. 搬入ユニット (B) から搬入ユニットカバー (C) を取り外す。

13. 搬入ユニット (B) の突起 (23) を駆動ユニット (A) の穴 (24) に入れ、突起 (25) を本体フレームの穴 (26) に入れて搬入ユニット (B) を取り付ける。


搬入ユニット (B) を右側に押し、突起 (25) を穴 (26) にカチッと音がするまではめ込むこと。

注意


搬入ユニットを取り付ける時は、排出のアクチュエーター (27) を外さないように作業をする。取付後、アクチュエーターの動作確認を行うこと。



14. Attach the edging (D) to the side plate, run the cable from the drive unit (A) through the edging (D) and secure it in place.



15. Insert the 2 projections (28) on the rear left stay (E) into the holes (29) in the side plate and secure the rear left stay (E) with the M4 × 8 screw (O).



16. Insert the clamped binding band (30) attached to the cable from the drive unit (A) into the hole, run the cable through the 2 edgings (31) and secure it in place.

14. Fixer le passage (D) à la tôle latérale, faire passer le câble venant de l'unité d'entraînement (A) dans le passage (D) et le fixer en place.

15. Insérer les 2 projections (28) du support arrière gauche (E) dans les trous (29) de la tôle latérale et fixer le support arrière gauche (E) à l'aide d'une vis M4 × 8 (O).

16. Insérer le collier de fixation (30) fixé au câble venant de l'unité d'entraînement (A) dans le trou, faire passer le câble dans les 2 passages (31) et le fixer en place.

14. Fije la pestaña (D) a la placa lateral, tienda el cable desde la unidad de accionamiento (A) a través de la pestaña (D) y asegúrelo en posición.

15. Inserte los 2 salientes (28) del soporte trasero izquierdo (E) en los orificios (29) de la placa lateral y asegure el soporte trasero izquierdo (E) con el tornillo M4 × 8 (O).

16. Inserte la correa de sujeción (30) fijada al cable de la unidad de accionamiento (A) en el orificio, tienda el cable a través de las 2 pestañas (31) y asegúrelo en posición.

14. Bringen Sie den Kantenschutz (D) an der Seitenplatte an, führen Sie das Kabel von der Antriebseinheit (A) durch den Kantenschutz (D) und befestigen Sie es.

15. Setzen Sie die 2 Vorsprünge (28) der hinteren linken Stütze (E) in die Öffnungen (29) der Seitenplatte ein und sichern Sie die hintere linke Stütze (E) mit der M4 × 8 Schraube (O).

16. Setzen Sie das Klemmschellenband (30) am Kabel von der Antriebseinheit (A) in die Öffnung ein, führen Sie das Kabel durch die 2 Kantenschutze (31) und befestigen Sie es.

14. Fissare il bordo (D) alla piastra laterale, far passare il cavo dall'unità guida (A) attraverso il bordo (D) e fissarlo in posizione.

15. Inserire le 2 parti sporgenti (28) sul supporto posteriore sinistro (E) nei fori (29) nella piastra laterale, e quindi fissare il supporto posteriore sinistro (E) con la vite M4 × 8 (O).

16. Inserire la fascetta di legatura con morsetto (30) applicata al cavo dell'unità guida (A) nel foro, far passare il cavo attraverso i 2 bordi (31) e fissarlo in posizione.

14. 在侧板上安装电线护具 (D), 将来自驱动单元 (A) 的电线从其中穿过以进行固定。

15. 将左后部支架 (E) 的 2 处突出部 (28) 插入侧板的孔 (29) 中, 使用 1 颗 M4×8 螺丝 (O) 来固定左后部支架 (E)。

16. 将来自驱动单元 (A) 的电线附带的带夹头束线带 (30) 插入孔中固定, 并使其从 2 处电线护具 (31) 中通过以固定。

14. 측면판에 에징 (D) 을 부착 , 구동 유닛 (A) 의 전선을 통과시키고 고정합니다 .


15. 좌측 뒷 받침대 (E) 의 돌기 (28) 2 개를 측면판의 구멍 (29) 에 넣고 나사 M4×8(O)1 개로 좌측 뒷 받침대 (E) 를 고정합니다 .

16. 구동 유닛 (A) 의 전선에 붙어 있는 클램프 부착 결속밴드 (30) 를 구멍에 넣고 고정해 2 곳의 에징 (31) 을 통과 시켜 고정합니다 .


14. 側板にエッジング (D) を取り付け、駆動ユニット (A) からの電線を通し、固定する。

15. 左後ステー (E) の 2 個の突起 (28) を側板の穴 (29) に入れて、ビス M4×8 (O) 1 本で左後ステー (E) を固定する。


16. 駆動ユニット (A) からの電線に付いているクランプ付き結束バンド (30) を穴に入れ固定し、2 箇所のエッジング (31) に通し、固定する。



17. Insert the hook (32) on the left scanner cover (F) into the hole in the side plate and secure the left scanner cover (F) with the M4 × 8 screw (O).



18. Mount the 2 screws (2) in the left ISU cover (1).



19. Insert the 2 projections (33) on the front left stay (G) into the holes in the left cover on the MFP and temporarily fasten the front left stay (G) in place with the 2 M4 × 20 screws (P).

17. Insérer le crochet (32) du couvercle de scanner gauche (F) dans le trou de la tôle latérale et fixer le couvercle de scanner gauche (F) à l'aide d'une vis M4 × 8 (O).

18. Déposer les 2 vis (2) du couvercle gauche de l'ISU (1).

19. Insérer les 2 projections (33) du support avant gauche (G) dans les trous du couvercle gauche du MFP et fixer provisoirement le support avant gauche (G) à l'aide de 2 vis M4 × 20 (P).

17. Inserte el gancho (32) de la cubierta izquierda del escáner (F) en el orificio de la placa lateral y asegure la cubierta izquierda del escáner (F) con el tornillo M4 × 8 (O).

18. Instale los 2 tornillos (2) en la cubierta ISU izquierda (1).

19. Inserte los 2 salientes (33) del soporte frontal izquierdo (G) en los orificios de la cubierta izquierda de la MFP y ajuste temporariamente el soporte frontal izquierdo (G) en posición con los 2 tornillos M4 × 20 (P).

17. Setzen Sie den Haken (32) an der linken Scanner-Abdeckung (F) in die Öffnung der Seitenplatte und sichern Sie die linke Scanner-Abdeckung (F) mit der M4 × 8 Schraube (O).

18. Befestigen Sie die 2 Schrauben (2) an der linken ISU-Abdeckung (1).

19. Setzen Sie die 2 Vorsprünge (33) der vorderen linken Stütze (G) in die Öffnungen der linken Abdeckung am MFP ein und befestigen Sie die vordere linke Stütze (G) provisorisch mit den 2 M4 × 20 Schrauben (P).

17. Inserire il gancio (32) sul coperchio sinistro dello scanner (F) nel foro della piastra laterale e fissare il coperchio sinistro dello scanner (F) con la vite M4 × 8 (O).

18. Montare le 2 viti (2) sul coperchio sinistro dell'ISU (1).

19. Inserire le 2 parti sporgenti (33) sul supporto anteriore sinistro (G) nei fori nel coperchio sinistro sull'MFP e stringere temporaneamente il supporto anteriore sinistro (G) in posizione con le 2 viti M4 × 20 (P).

17. 将扫描仪左盖板 (F) 的卡扣 (32) 插入侧板的孔中, 使用 1 颗 M4×8 螺丝 (O) 螺丝来固定扫描仪左盖板 (F)。

18. 安装 ISU 左盖板 (1) 的 2 颗螺丝 (2)。

19. 将左前部支架 (G) 的 2 处突出部 (33) 插入 MFP 主机的左盖板的孔中, 使用 2 颗 M4×20 螺丝 (P) 临时固定左前部支架 (G)。

17. 스캐너 좌측커버 (F) 의 후크 (32) 를 측면판의 구멍에 넣고 나사 M4×8(O) 1 개로 스캐너 좌측커버 (F) 를 고정합니다 .


18. ISU 좌측 커버 (1) 의 나사 (2) 2 개를 고정합니다 .

19. 좌측 앞 받침대 (G) 의 돌기 (33) 2 군데를 MFP 본체의 좌측커버의 구멍에 넣고 나사 M4×20(P) 2 개로 좌측 앞 받침대 (G) 를 반정도 조입니다 .

17. スキャナー左カバー (F) のフック (32) を側板の穴に入れて、ビス M4×8(O) 1 本でスキャナー左カバー (F) を固定する。

18. ISU 左カバー (1) のビス (2) 2 本を取り付ける。

19. 左前ステー (G) の 2 箇所突起 (33) を MFP 本体の左カバーの穴に入れ、ビス M4×20 (P) 2 本で左前ステー (G) を仮締める。



20. Position the eject unit (H) so that its rail section (34) is inside the MFP, insert the projection (35) on the rear into the hole in the side plate and then place the front end onto the plate section (37) on the front left stay (G).

NOTICE

When installing the eject unit (H), take care not to pinch the drive unit cable (36).

21. Fully tighten the 2 M4 × 20 screws (P) that were temporarily fastened in step 19 and secure the front left stay (G).

22. Secure the eject unit (H) with the 2 M4 × 8 screws (O).

20. Positionner l'unité d'éjection (H) de sorte que sa partie glissière (34) se trouve dans le MFP, insérer la projection arrière (35) dans le trou de la tôle latérale puis placer l'extrémité avant sur la partie plaque (37) du support avant gauche (G).

AVIS

À l'installation de l'unité d'éjection (H), attention à ne pas coincer le câble de l'unité d'entraînement (36).

21. Serrer à fond les 2 vis M4 × 20 (P) provisoirement serrées à l'étape 19 et fixer le support avant gauche (G).

22. Fixer l'unité d'éjection (H) avec 2 vis M4 × 8 (O).

20. Coloque la unidad de salida (H) de forma tal que la sección de su carril (34) quede dentro de la MFP, inserte el saliente (35) de la parte posterior en el orificio de la placa lateral y, a continuación, coloque el extremo frontal sobre la sección de la placa (37) del soporte frontal izquierdo (G).

AVISO

Cuando instale la unidad de salida (H) tenga cuidado de no pinzar el cable de la unidad de accionamiento (36).

21. Apriete totalmente los 2 tornillos M4 × 20 (P) que ajustó temporalmente en el paso 19 y asegure el soporte frontal izquierdo (G).

22. Asegure la unidad de salida (H) con los 2 tornillos M4 × 8 (O).

20. Richten Sie die Auswerfeinheit (H) so aus, dass der Schienenabschnitt (34) im MFP sitzt, setzen Sie den Vorsprung (35) auf der Rückseite in die Öffnung der Seitenplatte ein und setzen Sie dann das Vorderteil auf den Plattenabschnitt (37) an der vorderen linken Stütze (G).

HINWEIS

Achten Sie beim Montieren der Auswerfeinheit (H) darauf, dass das Kabel (36) der Antriebseinheit nicht eingeklemmt wird.

21. Ziehen Sie die in Schritt 19 provisorisch angezogenen 2 M4 × 20 Schrauben (P) vollständig an und sichern Sie die vordere linke Stütze (G).

22. Befestigen Sie die Auswerfeinheit (H) mit den 2 M4 × 8 Schrauben (O).

20. Posizionare l'unità di espulsione (H) in modo che la sua sezione di rotaia (34) sia all'interno dell'MFP, inserire la parte sporgente (35) sul retro, nel foro nella piastra laterale e quindi posizionare il terminale anteriore sulla sezione della piastra (37) sul supporto anteriore sinistro (G).

NOTIFICA

Quando si installa l'unità di espulsione (H), fare attenzione a non schiacciare il cavo dell'unità guida (36).

21. Stringere completamente le 2 viti M4 × 20 (P) che sono state strette temporaneamente nel punto 19 e fissare il supporto anteriore sinistro (G).

22. Fissare l'unità di espulsione (H) con le 2 viti M4 × 8 (O).

20. 将排纸单元 (H) 的导轨部分 (34) 靠 MFP 主机内侧设置, 将后部的突出部 (35) 插入侧板的孔中, 将前部放在左前部支架 (G) 的托板部 (37) 上。

注意

安装排纸单元 (H) 时, 必须注意不要夹住驱动单元的电线 (36)。

21. 将步骤 19 中临时固定的 2 颗 M4×20 螺丝 (P) 拧紧, 以固定左前部支架 (G)。

22. 使用 2 颗 M4×8 螺丝 (O) 来固定排纸单元 (H)。

20. 배출 유닛 (H) 의 레일부분 (34) 이 MFP 본체의 안쪽이 되게 세트하고 뒷쪽의 돌기 (35) 를 측면판 구멍에 넣어 앞쪽 좌측 받침대 (G) 의 플레이트부 (37) 에 얹습니다 .

주의

배출 유닛 (H) 를 부착할 때에는 구동 유닛의 전선 (36) 을 끼지 않도록 주의합니다 .

21. 순서 19 에서 반정도 조인 나사 M4×20(P) 2 개를 완전히 조이고 좌측 앞 받침대 (G) 를 고정합니다 .

22. 나사 M4×8(O) 2 개로 배출 유닛 (H) 를 고정합니다 .


20. 排出ユニット (H) のレール部分 (34) が MFP 本体の内側にくるようにセットし、後側の突起 (35) を側板の穴に入れ、前側を左前ステー (G) のプレート部 (37) に乗せる。

注意


排出ユニット (H) を取り付ける時は駆動ユニットの電線 (36) を挟まないように注意する。

21. 手順 19 で仮締めしたビス M4×20 (P) 2 本を本締めし、左前ステー (G) を固定する。

22. ビス M4×8 (O) 2 本で排出ユニット (H) を固定する。



23. Plug the 3 connectors (38) into the eject unit (H) and MFP.
 24. Secure the cables with the 2 wire stoppers (I).



25. Position the upper front cover (J) so that the screw housing (39) is not touching the front left stay (G) and align the projections (40) with the 2 holes on the right side of the upper front cover (J) before attaching the upper front cover (J) and securing it in place with the M4 x 8 screw (O).

23. Enfiler les 3 connecteurs (38) dans l'unité d'éjection (H) et le MFP.
 24. Fixer les câbles à l'aide des 2 butées de câble (I).

25. Positionner le couvercle supérieur avant (J) de sorte que le logement de la vis (39) ne soit pas en contact avec le support avant gauche (G) et aligner les projections (40) avec les 2 trous du côté droit du couvercle supérieur avant (J) avant de fixer ce couvercle supérieur avant (J) à l'aide d'une vis M4 x 8 (O).

23. Enchufe los 3 conectores (38) en la unidad de salida (H) y la MFP.
 24. Asegure los cables con los 2 topos para cables (I).

25. Coloque la cubierta frontal superior (J) de forma tal que el alojamiento del tornillo (39) no toque el soporte frontal izquierdo (G) y alinee los salientes (40) con los 2 orificios del lado derecho de la cubierta frontal superior (J) antes de instalar la cubierta frontal superior (J) y asegurarla en posición con el tornillo M4 x 8 (O).

23. Stecken Sie die 3 Stecker (38) in die Auswerfeinheit (H) und den MFP.
 24. Befestigen Sie die Kabel mit den 2 Kabelhaltern (I).

25. Positionieren Sie die obere vordere Abdeckung (J) so, dass das Schraubengehäuse (39) nicht die vordere linke Stütze (G) berührt und richten Sie die Vorsprünge (40) auf die 2 Öffnungen an der rechten Seite der oberen vorderen Abdeckung (J) aus, bevor Sie die obere vordere Abdeckung (J) anbringen und mit der M4 x 8 Schraube (O) sichern.

23. Collegare i 3 connettori (38) all'unità di espulsione (H) e all'MFP.
 24. Fissare i cavi con i 2 fermacavo (I).

25. Posizionare il coperchio superiore anteriore (J) in modo che l'alloggiamento delle viti (39) non tocchi il supporto anteriore sinistro (G), e allineare le parti sporgenti (40) con i 2 fori sul lato destro del coperchio superiore anteriore (J) prima di applicare il coperchio superiore anteriore (J) e fissarlo in posizione con la vite M4 x 8 (O).

23. 使用 3 个接插件 (38) 来连接排纸单元 (H) 以及 MFP 主机。
 24. 使用 2 个电线固定夹 (I) 来固定电线。


25. 设置前上部盖板 (J), 注意避免其左侧的螺丝固定部 (39) 碰到左前部支架 (G), 将前上部盖板 (J) 右侧的 2 处孔与突出部 (40) 对齐后安装前上部盖板 (J), 使用 1 颗 M4x8 螺丝 (O) 来固定。

23. 커넥터 (38) 3 개를 배출 유니트 (H) 및 MFP 본체에 접속합니다.
 24. 와이어 스톱퍼 (I) 2 개로 전선을 고정합니다.


25. 전면 상커버 (J) 좌측의 나사 고정부 (39) 가 좌측 앞 받침대 (G) 에 닿지 않도록 세트하고 전면 상커버 (J) 우측 구멍 돌기 (40) 2 곳을 맞춰 전면 상커버 (J) 를 부착, 나사 M4x8(O) 1 개로 고정합니다.

23. コネクター(38) 3 個を排出ユニット (H) および MFP 本体に接続する。
 24. ワイヤーストッパー (I) 2 個で電線を固定する。


25. 前上カバー (J) 左側のビス止め部 (39) が左前ステー (G) に当たらないようセットし、前上カバー (J) 右側の穴 2 箇所に突起 (40) を合わせてから前上カバー (J) を取り付け、ビス M4x8 (O) 1 本で固定する。



26. Install the front right cover (14) using the screw (12) removed in step 8.
Secure the fan cover (10) using the screw (11) removed in step 7.
* Check that connector on the inside of the fan cover (10) has not been dislodged.



27. Fit the paper entry unit cover (C) onto the paper entry unit (B).



28. Insert the 2 projections (41) on the left connection cover (K) into the holes in the front left stay (G) and secure the cover with the 2 M4 × 8 screws (O).

26. Reposer le couvercle avant droit (14) à l'aide de la vis (12) déposée à l'étape 8.
Fixer le couvercle du ventilateur (10) à l'aide de la vis (11) déposée à l'étape 7.
* Vérifier que le connecteur à l'intérieur du couvercle du ventilateur (10) n'a pas bougé.

27. Monter le couvercle de l'unité d'entrée du papier (C) sur l'unité d'entrée du papier (B).

28. Insérer les 2 projections (41) du couvercle de connexion gauche (K) dans les trous du support avant gauche (G) et fixer le couvercle à l'aide de 2 vis M4 × 8 (O).

26. Instale la cubierta frontal derecha (14) usando el tornillo (12) quitado en el paso 8.
Asegure la cubierta del ventilador (10) usando el tornillo (11) quitado en el paso 7.
* Compruebe si no se desplazó el conector del interior de la cubierta del ventilador (10).

27. Coloque la cubierta de la unidad de ingreso de papel (C) en la unidad de ingreso de papel (B).

28. Inserte los 2 salientes (41) de la cubierta de conexiones izquierda (K) en los orificios del soporte frontal izquierdo (G) y asegure la cubierta con los 2 tornillos M4 × 8 (O).

26. Bringen Sie die vordere rechte Abdeckung (14) mit der in Schritt 8 entfernten Schraube (12) an.
Befestigen Sie die Lüfterabdeckung (10) mit der in Schritt 7 entfernten Schraube (11).
* Vergewissern Sie sich, dass der Stecker auf der Innenseite der Lüfterabdeckung (10) nicht abgetrennt wurde.

27. Setzen Sie die Abdeckung (C) der Papiereinzugseinheit in die Papiereinzugseinheit (B) ein.

28. Setzen Sie die 2 Vorsprünge (41) an der linken Verbindungsabdeckung (K) in die Öffnungen der vorderen linken Stütze (G) ein und befestigen Sie die Abdeckung mit den 2 M4 × 8 Schrauben (O).

26. Installare il coperchio anteriore destro (14) utilizzando la vite (12) rimossa nel punto 8.
Fissare il coperchio ventola (10) utilizzando la vite (11) rimossa nel punto 7.
* Controllare che il connettore sull'interno del coperchio della ventola (10) non sia stato rimosso.

27. Applicare il coperchio (C) dell'unità di ingresso carta, sull'unità di ingresso carta (B).

28. Inserire le 2 parti sporgenti (41) sul coperchio connessione sinistro (K) nei fori del supporto anteriore sinistro (G) e quindi fissare il coperchio con le 2 viti M4 × 8 (O).

26. 使用在步骤 8 中卸下的 1 颗螺丝 (12) 来固定左右前盖板 (14)。
使用在步骤 7 中卸下的 1 颗螺丝 (11) 来固定风扇盖板 (10)。
※ 确认位于风扇盖板 (10) 内侧的接插件有无露出。

27. 将进纸单元盖板 (C) 安装在进纸单元 (B) 上。

28. 连接左盖板 (K) 的 2 处突出部 (41) 插入左前部支架 (G) 的孔中, 使用 2 颗 M4×8 螺丝 (O) 来固定。

26. 순서 8 에서 제거한 나사 (12) 1 개로 오른쪽 전면커버 (14) 를 부착합니다 .
순서 7 에서 제거한 나사 (11) 1 개로 팬커버 (10) 를 고정합니다 .
※ 팬커버 (10) 안쪽에 있는 커넥터가 빠져 있지 않은지를 확인합니다 .


27. 반입 유닛 커버 (C) 를 반입 유닛 (B) 에 부착합니다 .

28. 연결 좌측커버 (K) 의 돌기 (41) 2 곳을 좌측 앞 받침대 (G) 의 구멍에 넣고 나사 M4×8(O) 2 개로 고정합니다 .


26. 手順 8 で外したビス (12) 1 本で右前カバー (14) を取り付ける。
手順 7 で外したビス (11) 1 本でファンカバー (10) を固定する。
※ ファンカバー (10) 内側にあるコネクタが外れていないことを確認する。

27. 搬入ユニットカバー (C) を搬入ユニット (B) に取り付ける。


28. 連結左カバー (K) の突起 (41) 2 箇所を左前ステー (G) の穴に入れ、ビス M4×8 (O) 2 本で固定する。



- 29.** Remove the interface cover (42).
* After installing the document finisher, re-attach the interface cover (42).
- 30.** Install the left cover (L) using the 2 screws (5) removed in step 3



- 31.** Open the eject cover (43).
- 32.** Attach the upper left cover (M) and close the eject cover (43).



- 33.** Attach the lower connection cover (R) with the 2 M4 × 20 screws (P).

- 29.** Déposer le couvercle d'interface (42).
* Après avoir installé le retoucheur de document, reposer le couvercle d'interface (42).
- 30.** Reposer le couvercle gauche (L) à l'aide des 2 vis (5) déposées à l'étape 3.

- 31.** Ouvrir le couvercle d'éjection (43).
- 32.** Fixer le couvercle supérieur gauche (M) et fermer le capot d'éjection (43).

- 33.** Fixer le couvercle de connexion inférieur (R) à l'aide de 2 vis M4 × 20 (P).

- 29.** Quite la cubierta de la interfaz (42).
* Después de instalar el finalizador de documentos, vuelva a colocar la cubierta de la interfaz (42).
- 30.** Instale la cubierta izquierda (L) usando los 2 tornillos (5) quitados en el paso 3.

- 31.** Abra la cubierta de expulsión (43).
- 32.** Fije la cubierta superior izquierda (M) y cierre la cubierta de expulsión (43).

- 33.** Fije la cubierta de conexiones inferior (R) con los 2 tornillos M4 × 20 (P).

- 29.** Entfernen Sie die Schnittstellenabdeckung (42).
* Bringen Sie nach der Installation des Dokument-Finishers wieder die Schnittstellenabdeckung (42) an.
- 30.** Bringen Sie die linke Abdeckung (L) mit den in Schritt 3 entfernten 2 Schrauben (5) an.

- 31.** Öffnen Sie die Auswerfabdeckung (43).
- 32.** Bringen Sie die obere linke Abdeckung (M) wieder an und schließen Sie die Auswerfabdeckung (43).

- 33.** Bringen Sie die untere Verbindungsabdeckung (R) mit den 2 M4 × 20 Schrauben (P) an.

- 29.** Rimuovere la copertura di interfaccia (42).
* Dopo l'installazione della finitrice di documenti, fissare di nuovo la copertura di interfaccia (42).
- 30.** Installare il coperchio sinistro (L) utilizzando le 2 viti (5) rimosse nel punto 3.

- 31.** Aprire il coperchio di espulsione (43).
- 32.** Fissare il coperchio superiore sinistro (M) e chiudere il coperchio di espulsione (43).

- 33.** Fissare il coperchio connessione inferiore (R) con le 2 viti M4 × 20 (P).

- 29.** 拆下接口盖板 (42)。
※ 在装订器设置完成后, 按原样安装接口盖板 (42)。
- 30.** 使用在步骤 3 中卸下的 2 颗螺丝 (5) 来安装左盖板 (L)。

- 31.** 打开排纸盖板 (43)。
- 32.** 安装左上部盖板 (M), 关闭排纸盖板 (43)。

- 33.** 使用 2 颗 M4×20 螺丝 (P) 来安装连接下盖板 (R)。

- 29.** 인터페이스 커버 (42) 를 제거합니다.
※ 인터페이스 커버 (42) 는 문서 피니셔 설치 후에 원래대로 장착합니다.
- 30.** 순서 3 에서 제거한 나사 (5) 2 개로 좌측 커버 (L) 를 부착합니다.


- 31.** 배출커버 (43) 를 엽니다.
- 32.** 좌측 상커버 (M) 를 부착하고 배출커버 (43) 를 닫습니다.

- 33.** 나사 M4×20(P) 2 개로 연결 하커버 (R) 를 장착합니다.


- 29.** インターフェイスカバー (42) を取り外す。
※ インターフェイスカバー (42) はドキュメントフィニッシャー設置後に、元通り取り付けれる。
- 30.** 手順 3 で外したビス (5) 2 本で左カバー (L) を取り付けれる。

- 31.** 排出カバー (43) を開く。
- 32.** 左上カバー (M) を取り付け、排出カバー (43) を閉じる。

- 33.** ビス M4×20(P) 2 本で連結下カバー (R) を取り付けれる。



34. Pull the 2 slide rails (44) out from inside the MFP.
35. Align the 4 hooks (45) on the slide rails (44) with the notched sections of the paper conveying unit (N) and fit the paper conveying unit (N) onto the slide rails (44).



36. Move the slide rails (44) backwards and secure the paper conveying unit (N) to the 4 hooks (45). Check that the hooks are securely engaged through the opening (46).
37. Lift the rear right side of the paper conveying unit (N) slightly while pushing it firmly in as far as it will go. After pushing it all the way in, pull it out again and check that it stops mid-way.
38. Secure the paper conveying unit (N) with the P Tite screw M3 × 8 (Q).
39. Close the front cover (7).

34. Sortir les 2 glissières coulissantes (44) hors du MFP.
35. Aligner les 4 crochets (45) des glissières coulissantes (44) avec les encoches de l'unité de transport du papier (N) et insérer l'unité de transport du papier (N) sur ces glissières coulissantes (44).

36. Remettre les glissières coulissantes (44) en place et fixer l'unité de transport du papier (N) avec les 4 crochets (45). Vérifier que les crochets sont soigneusement engagés dans les ouvertures (46).
37. Lever légèrement le côté arrière droit de l'unité de transport du papier (N) tout en poussant cette unité à fond. Une fois poussée à fond, tirer sur l'unité et vérifier qu'elle s'arrête à mi-course.
38. Fixer l'unité de transport du papier (N) à l'aide d'une vis P Tite M3 x 8 (Q).
39. Refermer le capot avant (7).

34. Tire de los 2 carriles deslizantes (44) para sacarlos de la MFP.
35. Alinee los 4 ganchos (45) de los carriles deslizantes (44) con las secciones con muescas de la unidad de transporte de papel (N) y encaje la unidad de transporte de papel (N) en los carriles deslizantes (44).

36. Mueva los carriles deslizantes (44) hacia atrás y asegure la unidad de transporte de papel (N) a los 4 ganchos (45). A través de la abertura (46), compruebe si los ganchos están enganchados de forma segura.
37. Levante ligeramente el lado trasero derecho de la unidad de transporte de papel (N) mientras presiona firmemente hasta el fondo. Después de empujarla hasta el fondo, vuelva a sacarla y compruebe si se detiene en la mitad del recorrido.
38. Asegure la unidad de transporte de papel (N) con el tornillo P Tite M3 × 8 (Q).
39. Cierre la cubierta frontal (7).

34. Ziehen Sie die 2 Schlittenschielen (44) aus dem MFP heraus.
35. Richten Sie die 4 Haken (45) der Schlittenschielen (44) auf die Einkerbungen der Papierfördereinheit (N) aus und setzen Sie die Papierfördereinheit (N) auf die Schlittenschielen (44).

36. Verschieben Sie die Schlittenschielen (44) nach hinten und befestigen Sie die Papierfördereinheit (N) mit den 4 Haken (45). Vergewissern Sie sich durch die Öffnung (46), dass die Haken ordnungsgemäß greifen.
37. Heben Sie die hintere rechte Seite der Papierfördereinheit (N) leicht an und drücken Sie sie gleichzeitig bis zum Anschlag einwärts. Ziehen Sie sie nach dem Hineindrücken bis zum Anschlag wieder heraus und vergewissern Sie sich, dass sie mittendrin anhält.
38. Befestigen Sie die Papierfördereinheit (N) mit der P-Tite-Schraube M3 × 8 (Q).
39. Schließen Sie die vordere Abdeckung (7).

34. Estrarre le 2 rotaie di scorrimento (44) dall'interno dell'MFP.
35. Allineare i 4 ganci (45) sulle rotaie di scorrimento (44) con le sezioni intagliate dell'unità di trasporto carta (N), ed inserire l'unità di trasporto carta (N) sulle rotaie di scorrimento (44).

36. Spostare le rotaie di scorrimento (44) all'indietro e fissare l'unità di trasporto carta (N) ai 4 ganci (45). Controllare che i ganci siano innestati in modo sicuro attraverso l'apertura (46).
37. Sollevare leggermente il lato posteriore destro dell'unità di trasporto carta (N) mentre lo si spinge fermamente fino in fondo. Dopo averlo spinto fino in fondo, estrarlo di nuovo e controllare che si arresti a metà corsa.
38. Fissare l'unità di trasporto carta (N) con la vite P Tite M3 × 8 (Q).
39. Chiudere il pannello anteriore (7).

34. 拉出机身内的 2 根滑轨 (44)。
35. 将输纸单元 (N) 的缺口部与滑轨 (44) 的 4 处卡扣 (45) 对齐, 将输纸单元 (N) 放在滑轨 (44) 上。

36. 将滑轨 (44) 向后方移动, 使输纸单元 (N) 固定在 4 处卡扣 (45) 上。通过开口部 (46) 来确认是否确实卡入卡扣。
37. 将输纸单元 (N) 的右后部稍稍抬起的同时, 将其插入到底。插入到底后再将其拉出, 确认是否在中途停止。
38. 使用 1 颗紧固型 P 螺丝 M3×8(Q) 来固定输纸单元 (N)。
39. 关闭前盖板 (7)。


34. 기내의 슬라이드 레일 (44) 2 개를 빼 냅니다 .
35. 슬라이드 레일 (44) 4 곳의 후크 (45) 에 반송 유니트 (N) 를 맞춰 반송 유니트 (N) 를 슬라이드 레일 (44) 에 얹습니다 .

36. 슬라이드 레일 (44) 을 뒤 방향으로 움직여 4 곳의 후크 (45) 에 반송 유니트 (N) 을 고정시킵니다 . 확실히 후크에 걸린 것을 개구부 (46) 에서 확인합니다 .
37. 반송 유니트 (N) 오른쪽 뒤쪽을 조금 들어 올리면서 안까지 확실히 삽입합니다 . 안까지 삽입한 후 앞으로 당겨 도중에 멈추는지를 확인합니다 .
38. 나사 M3×8P Tight (Q) 1 개로 반송 유니트 (N) 를 고정합니다 .
39. 전면 커버 (7) 을 닫습니다 .

34. 胴内のスライドレール (44) 2 本を引き出す。
35. スライドレール (44) の 4 箇所フック (45) に搬送ユニット (N) の切り欠き部を合わせて搬送ユニット (N) をスライドレール (44) に載せる。

36. スライドレール (44) を後方向に動かし、4 箇所フック (45) に搬送ユニット (N) を固定させる。確実にフックに掛かったことを、開口部 (46) から確認する。
37. 搬送ユニット (N) の右後側を少し持ち上げながら、奥までしっかり挿入する。奥まで挿入した後、手前に引き出し、途中で止まることを確認する。
38. ビス M3×8P タイム (Q) 1 本で搬送ユニット (N) を固定する。
39. 前カバー (7) を閉める。

INSTALLATION GUIDE FOR CENTER-FOLDING UNIT



English			
Supplied parts			
A. Center-Folding unit.....	1	E. Front side cover.....	1
B. Front rail.....	1	F. Rear side cover.....	1
C. Rear rail.....	1	G. Output stock tray.....	1
D. Output stopper.....	1	H. Output tray.....	1
		I. Relay paper conveying unit.....	1
		J. Pin.....	1
		K. M4 × 8 screw.....	11
		L. M4 × 10 screw (black).....	2
		M. M4 × 12 screw.....	4
		N. Lock plate.....	2
		O. Binding band.....	1
		P. Guide.....	1
		Q. D7 label.....	1
		R. Operation label.....	1

Français			
Pièces fournies			
A. Plieuse.....	1	E. Capot latéral avant.....	1
B. Glissière avant.....	1	F. Capot latéral arrière.....	1
C. Glissière arrière.....	1	G. Plateau de sortie du papier.....	1
D. Butée de sortie.....	1	H. Plateau de sortie.....	1
		I. Unité de transport du papier de relais.....	1
		J. Goupille.....	1
		K. Vis M4 × 8.....	11
		L. Vis M4 × 10 (noire).....	2
		M. Vis M4 × 12.....	4
		N. Plaque de verrouillage.....	2
		O. Collier de fixation.....	1
		P. Guide.....	1
		Q. Étiquette D7.....	1
		R. Étiquette de fonctionnement.....	1

Español			
Partes suministradas			
A. Unidad de plegado.....	1	E. Cubierta lateral frontal.....	1
B. Carril frontal.....	1	F. Cubierta lateral posterior.....	1
C. Carril posterior.....	1	G. Bandeja de recolección de papel de salida.....	1
D. Tope de salida.....	1	H. Bandeja de salida.....	1
		I. Unidad de transporte de papel por relevador.....	1
		J. Pasador.....	1
		K. Tornillo M4 × 8.....	11
		L. Tornillo M4 × 10 (negro).....	2
		M. Tornillo M4 × 12.....	4
		N. Placa de cierre.....	2
		O. Correa de sujeción.....	1
		P. Guía.....	1
		Q. Etiqueta D7.....	1
		R. Etiqueta de funcionamiento.....	1


Deutsch			
Gelieferte Teile			
A. Mittenfalteinheit.....	1	E. Vordere Seitenabdeckung.....	1
B. Vordere Schiene.....	1	F. Hintere Seitenabdeckung.....	1
C. Hintere Schiene.....	1	G. Ausgabestapel Fach.....	1
D. Ausgabenschlag.....	1	H. Ausgabefach.....	1
		I. Eingesetzte Papierfördereinheit.....	1
		J. Stift.....	1
		K. M4 × 8 Schraube.....	11
		L. M4 × 10 Schraube (schwarz).....	2
		M. M4 × 12 Schraube.....	4
		N. Sperrplatte.....	2
		O. Schellenband.....	1
		P. Führung.....	1
		Q. D7 Aufkleber.....	1
		R. Bedienungsaufkleber.....	1

Italiano			
Parti di forniture			
A. Unità di piegatura centrale.....	1	E. Coperchio laterale anteriore.....	1
B. Rotaia anteriore.....	1	F. Coperchio laterale posteriore.....	1
C. Rotaia posteriore.....	1	G. Vassoio di uscita stoccaggio.....	1
D. Fermo di uscita.....	1	H. Vassoio di uscita.....	1
		I. Unità relay di trasporto carta.....	1
		J. Perno.....	1
		K. Vite M4 × 8.....	11
		L. Vite M4 × 10 (nera).....	2
		M. Vite M4 × 12.....	4
		N. Piastra di bloccaggio.....	2
		O. Fascetta di legatura.....	1
		P. Guida.....	1
		Q. Etichetta D7.....	1
		R. Etichetta di operazione.....	1

简体中文			
附属品			
A. 中缝装订一折页单元.....	1	E. 前部侧盖板.....	1
B. 前部导轨.....	1	F. 后部侧盖板.....	1
C. 后部导轨.....	1	G. 堆纸托盘.....	1
D. 排纸挡板.....	1	H. 排纸托盘.....	1
		I. 中间搬运单元.....	1
		J. 销钉.....	1
		K. M4×8 螺丝.....	11
		L. M4×10 螺丝 (黑).....	2
		M. M4×12 螺丝.....	4
		N. 锁定板.....	2
		O. 束线带.....	1
		P. 导板.....	1
		Q. D7 标签.....	1
		R. 操作标签.....	1

한국어			
동봉품			
A. 접기 유닛.....	1	E. 사이드 커버 앞.....	1
B. 레일 앞.....	1	F. 사이드 커버 뒤.....	1
C. 레일 뒤.....	1	G. 배지 저장 트레이.....	1
D. 배지 스톱퍼.....	1	H. 배지 트레이.....	1
		I. 중계 반송유닛.....	1
		J. 핀.....	1
		K. 나사 M4×8.....	11
		L. 나사 M4×10 (흑).....	2
		M. 나사 M4×12.....	4
		N. 잠금 플레이트.....	2
		O. 결속 밴드.....	1
		P. 가이드.....	1
		Q. D7 라벨.....	1
		R. 조작라벨.....	1

日本語			
同梱品			
A. 中折りユニット.....	1	E. サイドカバー前.....	1
B. レール前.....	1	F. サイドカバー後.....	1
C. レール後.....	1	G. 排紙ストックトレイ.....	1
D. 排紙ストッパー.....	1	H. 排紙トレイ.....	1
		I. 中継搬送ユニット.....	1
		J. ピン.....	1
		K. ビス M4×8.....	11
		L. ビス M4×10(黒).....	2
		M. ビス M4×12.....	4
		N. ロックプレート.....	2
		O. 結束バンド.....	1
		P. ガイド.....	1
		Q. D7 ラベル.....	1
		R. 操作ラベル.....	1



Be sure to remove any tape and/or cushioning material from supplied parts.

Procedure

Before installing the center-folding unit, turn the MFP's main power switch off and unplug the power cable from the power supply. Install the document finisher, and then install the center-folding unit.

1. Open the upper front cover (1) of the document finisher.
2. Remove the screw (2) and open the lower front cover (3).
(NOTICE)
Discard the screw (2) and do not fasten the lower front cover (3).

Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.

Procédure

Avant d'installer la plieuse mettre l'interrupteur d'alimentation principal du MFP hors tension et débrancher le câble d'alimentation de la prise de courant. Installer le finisseur de document, puis installer la plieuse.

1. Ouvrir le couvercle avant supérieur (1) du retoucheur de document.
2. Déposer la vis (2) et ouvrir le couvercle avant inférieur (3).
(AVIS)
Jeter la vis (2) et ne pas fixer le capot inférieur avant (3).

Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.

Procedimiento

Antes de instalar la unidad de plegado, desconecte el interruptor de alimentación principal de la MFP y desenchufe el cable de alimentación de la toma de corriente. Instale primero el finalizador de documentos y luego instale la unidad de plegado.

1. Abra la cubierta frontal superior (1) del finalizador de documentos.
2. Quite el tornillo (2) y abra la cubierta frontal inferior (3).
(AVISO)
Descarte el tornillo (2) y no ajuste la cubierta frontal inferior (3).

Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.

Verfahren

Bevor Sie mit dem Einbau der Mittenfalteinheit beginnen, stellen Sie sicher, dass der Hauptschalter des Kopierers ausgeschaltet und das Netzkabel aus der Steckdose gezogen ist. Bringen Sie den Dokument-Finisher zuerst und dann erst die Mittenfalteinheit an.

1. Öffnen Sie die obere vordere Abdeckung (1) des Dokument-Finishers.
2. Entfernen Sie die Schraube (2) und öffnen Sie die untere vordere Abdeckung (3).
(HINWEIS)
Entsorgen Sie die Schraube (2) und befestigen Sie nicht die untere vordere Abdeckung (3).

Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.

Procedura

Prima di installare l'unità di piegatura centrale, assicurarsi che l'interruttore principale della fotocopiatrice sia spento e che il cavo di alimentazione non sia inserito nella presa. Installare prima la finitrice e poi procedere all'installazione dell'unità di piegatura centrale.

1. Aprire il coperchio superiore anteriore (1) della finitrice di documenti.
2. Rimuovere la vite (2) ed aprire il coperchio inferiore anteriore (3).
(NOTIFICA)
Eliminare le viti (2) e non fissare il coperchio inferiore anteriore (3).

如果附属品上带有固定胶带, 缓冲材料时务必揭下。

安装步骤

安装中缝装订一折页单元前, 请关闭 MFP 的主电源开关并从电源拔下电源线。安装装订器, 然后安装中缝装订一折页单元。

1. 打开装订器的前部上盖板 (1)。
2. 拆除 1 颗螺丝 (2), 打开前部下盖板 (3)。
(注意)
废除螺丝 (2), 前部下盖板 (3) 不需固定。

동봉품에 고정 테이프, 완충재가 붙어 있는 경우에는 반드시 제거할 것.

장착순서

중철 유닛을 설치할 때에는 반드시 MFP 본체의 주전원 스위치를 OFF 로 하고 전원플러그를 뺀 후 작업을 할 것. 문서 피니셔를 설치 후, 중철 유닛을 설치 할 것.


1. 문서 피니셔 앞 상커버 (1) 를 엽니다.
2. 나사 (2) 1 개를 제거하고 앞 하커버 (3) 를 엽니다.
(주의)
나사 (2) 는 폐기하고 전면 아래커버 (3) 는 고정하지 않습니다.

同梱品に固定テープ、緩衝材がついている場合は、必ず取り外すこと。


取付手順

中折りユニットを設置するときは、必ず MFP 本体の主電源スイッチを OFF にし、電源プラグを抜いてから作業すること。ドキュメントフィニッシャーを設置後、中折りユニットを設置すること。


1. ドキュメントフィニッシャーの前上カバー (1) を開く。
2. ビス (2) 1 本を外し、前下カバー (3) を開く。
(注意)
ビス (2) は廃棄とし、前下カバー (3) は固定しない。



3. Remove the 2 screws (4) and remove the foot cover (5).



4. Remove the 3 screws (6) and remove the lower rear cover (7).



5. Remove 2 screws (8) and remove the lower middle cover (9).

3. Déposer les 2 vis (4) puis le couvercle du pied (5).

4. Déposer les 3 vis (6) puis le couvercle arrière inférieur (7).

5. Déposer les 2 vis (8) et le couvercle intermédiaire inférieur (9).

3. Quite los 2 tornillos (4) y quite la cubierta de la pata (5).

4. Quite los 3 tornillos (6) y quite la cubierta posterior inferior (7).

5. Quite los 2 tornillos (8) y quite la cubierta intermedia inferior (9).

3. Entfernen Sie die 2 Schrauben (4) und nehmen Sie die Fußabdeckung (5) ab.

4. Entfernen Sie die 3 Schrauben (6) und nehmen Sie die untere hintere Abdeckung (7) ab.

5. Entfernen Sie die 2 Schrauben (8) und nehmen Sie die untere mittlere Abdeckung (9) ab.

3. Rimuovere le 2 viti (4) e quindi rimuovere la copertura del piede (5).

4. Rimuovere le 3 viti (6) e quindi rimuovere il coperchio inferiore posteriore (7).

5. Rimuovere le 2 viti (8) e quindi rimuovere il pannello centrale inferiore (9).

3. 拆除 2 顆螺絲 (4)，拆下腳座蓋板 (5)。

4. 拆除 3 顆螺絲 (6)，拆下後部下蓋板 (7)。

5. 拆除 2 顆螺釘 (8)，拆下中部下蓋板 (9)。

3. 나사 (4) 2 개를 제거하고, 풋커버 (5) 를 제거합니다 .


4. 나사 (6) 3 개를 제거하고, 뒤 하커버 (7) 를 제거합니다 .

5. 나사 (8) 2 개를 제거하고 중하 커버 (9) 를 떼어 냅니다 .


3. ビス (4) 2 本を外し、フットカバー (5) を取り外す。

4. ビス (6) 3 本を外し、後下カバー (7) を取り外す。

5. ビス (8) 2 本を外し、中下カバー (9) を取り外す。




6. Install the lock plates (N) on the front and rear supports using an M4 x 8 screw (K) each.



7. Place the hook (11) of the front rail (B) on the notch (10) at the front of the document finisher, at the same time inserting the projection (13) on the front rail (B) in the hole (12) in the document finisher.

8. Fix the front rail (B) using 2 M4 x 12 screws (M).



9. Install the rear rail (C) at the rear of the document finisher using 2 M4 x 12 screws (M) in the same way.

6. Monter les plaques de verrouillage (N) sur les supports avant et arrière en procédant à l'aide d'une vis M4 x 8 (K) dans les deux cas.

7. Placer le crochet (11) de la glissière avant (B) dans l'encoche (10) à l'avant du retoucheur de document tout en insérant la saillie (13) de la glissière avant (B) dans le trou (12) du retoucheur de document.

8. Fixer la glissière avant (B) à l'aide de 2 vis M4 x 12 (M).

9. Monter la glissière arrière (C) au dos du retoucheur de document en procédant de la même façon et à l'aide de 2 vis M4 x 12 (M).

6. Instale las placas de cierre (N) en los soportes frontal y posterior usando un tornillo M4 x 8 (K) en cada uno.

7. Coloque el gancho (11) del carril frontal (B) en la muesca (10) de la parte frontal del finalizador de documentos al mismo tiempo que inserta el resalto (13) del carril frontal (B) en el orificio (12) del finalizador de documentos.

8. Fije el carril frontal (B) usando 2 tornillos M4 x 12 (M).

9. Instale el carril posterior (C) en la parte posterior del finalizador de documentos usando 2 tornillos M4 x 12 (M) de la misma forma.

6. Montieren Sie die Sperrplatten (N) an den vorderen und hinteren Stützen mit jeweils einer M4 x 8 Schraube (K).

7. Setzen Sie den Haken (11) der vorderen Schiene (B) in die Aussparung (10) vorne am Dokument-Finisher ein, und setzen Sie dabei auch den Vorsprung (13) an der vorderen Schiene (B) in die Öffnung (12) des Dokument-Finishers ein.

8. Befestigen Sie die vordere Schiene (B) mit den 2 M4 x 12 Schrauben (M).

9. Montieren Sie die hintere Schiene (C) auf gleiche Weise mit 2 M4 x 12 Schrauben (M) an der Rückseite des Dokument-Finishers.

6. Installare le piastre di bloccaggio (N) sui supporti anteriore e posteriore utilizzando una vite M4 x 8 (K) ciascuna.

7. Posizionare il gancio (11) della rotaia anteriore (B) sull'incavo (10) alla parte anteriore della finitrice di documenti, contemporaneamente inserire la sporgenza (13) sulla rotaia anteriore (B) nel foro (12) nella finitrice di documenti.

8. Fissare la rotaia anteriore (B) utilizzando 2 viti M4 x 12 (M).

9. Installare la rotaia posteriore (C) alla parte posteriore della finitrice di documenti utilizzando 2 viti M4 x 12 (M) alla stessa maniera.

6. 使用各 1 顆 M4x8(K) 螺釘將鎖定板 (N) 安裝在前後的支柱上。

7. 將前部導軌 (B) 的掛鉤 (11) 嵌入裝訂器前部的缺口 (10)，同時將前部導軌 (B) 的卡銷 (13) 插入到裝訂器的孔 (12) 中。

8. 使用 2 顆 M4x12(M) 螺釘來固定前部導軌 (B)。

9. 按相同方法，使用 2 顆 M4x12(M) 螺釘將後部導軌 (C) 安裝在裝訂器後部。

6. 잠금 플레이트 (N) 를 앞뒤 지주에 나사 M4x8(K) 각 1 개로 장착합니다 .

7. 문서 피니셔 앞의 이음부분 (10) 에 레일 앞 (B) 의 후크 (11) 를 걸고 동시에 문서 피니셔 구멍 (12) 에 레일 앞 (B) 의 보스 (13) 를 넣습니다 .

8. 나사 M4x12(M) 2 개로 레일 앞 (B) 을 고정합니다 .


9. 같은 방식으로 나사 M4x12(M) 2 개로 문서 피니셔 뒤에 레일 뒤 (C) 를 장착합니다 .

6. ロックプレート (N) を前後の支柱にビス M4x8(K) 各 1 本で取り付け。

7. ドキュメントフィニッシャー前の切り欠き (10) にレール前 (B) のフック (11) を引っかけ、同時にドキュメントフィニッシャーの穴 (12) にレール前 (B) のボス (13) を入れる。

8. ビス M4x12(M) 2 本でレール前 (B) を固定する。

9. 同様に、ビス M4x12(M) 2 本で、ドキュメントフィニッシャー後にレール後 (C) を取り付け。



10. Place the left rollers (14) at the front and rear of the center-folding unit (A) on the tracks (15) on the inner sides of the rails, and roll in the direction shown. The middle rollers (16) will roll onto the rails.

11. Insert the center-folding unit (A) into the document finisher along the rails.

(NOTICE)

Insert without removing the fixing tape (18) for the wire guide (17). (The fixing tape (18) is removed at step 15)

10. Disposer les rouleaux gauche (14) à l'avant et à l'arrière de la plieuse (A) sur les voies (15) de côté interne des glissières et faire rouler dans la direction indiquée. Les rouleaux intermédiaires (16) vont se placer d'eux-mêmes sur les glissières.

11. Insérer la plieuse (A) dans le retoucheur de document le long des glissières.

(AVIS)

Insérer sans enlever la bande adhésive de fixation (18) pour le guide câble (17). (La bande adhésive de fixation (18) est enlevée à l'étape 15).

10. Coloque los rodillos izquierdos (14) en las partes frontal y posterior de la unidad de plegado (A) en las pistas (15) de los lados internos de los carriles y hágalos rodar en la dirección de la ilustración. Los rodillos intermedios (16) rodarán sobre los carriles.

11. Inserte la unidad de plegado (A) en el finalizador de documentos a lo largo de los carriles.

(AVISO)

Inserte sin quitar la cinta de fijación (18) de la guía para el cable (17). (La cinta de fijación (18) se quita en el paso 15.)

10. Setzen Sie die linken Rollen (14) an der Vorderseite und Rückseite der Mittenfalteinheit (A) auf die Bahnen (15) an den Innenseiten der Schienen, und rollen Sie sie in der dargestellten Richtung. Die mittleren Rollen (16) rollen nun auf die Schienen.

11. Schieben Sie die Mittenfalteinheit (A) entlang den Schienen in den Dokument-Finisher ein.

(HINWEIS)

Schieben Sie sie ein, ohne das Klebeband (18) für die Kabelführung (17) zu entfernen. (Das Klebeband (18) wird bei Schritt 15 entfernt.)

10. Posizionare i rulli di sinistra (14) alla parte anteriore e posteriore dell'unità di piegatura centrale (A) sulle piste (15) sui lati interni delle rotaie, e farli scorrere nella direzione mostrata. I rulli intermedi (16) scorreranno sulle rotaie.

11. Inserire l'unità di piegatura centrale (A) nella finitrice di documenti lungo le rotaie.

(NOTIFICA)

Inserire senza rimuovere il nastro di fissaggio (18) per la guida cavi (17). (Il nastro di fissaggio (18) viene rimosso al punto 15)

10. 将中缝装订一折页单元 (A) 前后的左侧滑轮 (14) 放在导轨内侧的转动部 (15) 上, 并按箭头方向转动。将中间滑轮 (16) 插入到导轨上。

11. 将中缝装订一折页单元 (A) 沿着导轨插入到装订器中。

(注意)

插入时不需剥除电线导板 (17) 的固定胶带 (18)。(在步骤 15 时剥除固定胶带 (18))

10. 접기 유닛 (A) 의 앞뒤에 있는 좌측 코로 (14) 를 레일 내측에 있는 굴림부 (15) 에 얹고 화살표 방향으로 굴립니다. 중간코로 (16) 가 레일에 삽입됩니다.

11. 접기 유닛 (A) 를 레일에 붙여 문서 피니셔에 삽입합니다.

(주의)


전선 가이드 (17) 의 고정 테이프 (18) 를 떼어 내지 않고 삽입할 것. (고정 테이프 (18) 는 순서 15 에서 떼어 냅니다.)

10. 中折りユニット (A) の前後にある左コロ (14) を、レールより内側にある転がし部 (15) に乗せ、矢印方向に転がす。中間コロ (16) がレールに挿入される。


11. 中折りユニット (A) をレールに沿ってドキュメントフィニッシャーに挿入する。

(注意)

電線ガイド (17) の固定テープ (18) を剥がさずに挿入すること。(固定テープ (18) は手順 15 で剥がす)



12. Release the lock lever (19) and pull out the center-folding unit (A) to the left of the document finisher.



13. Align the holes (21) in the relay paper conveying unit (I) with the 2 projections (20) on the document finisher. Install so that the lip (22) on the top frame of the relay paper conveying unit rests on the document finisher's frame (23).

14. Install the relay paper conveying unit (I) using 4 M4 × 8 screws (K).

12. Libérer le levier de verrouillage (19) et sortir la plieuse (A) par la gauche du retoucheur de document.

13. Aligner les trous (21) de l'unité de transport de relais (I) avec les 2 saillies (20) du retoucheur de document. Procéder de sorte que la lèvre (22) du châssis supérieur de l'unité de transport de relais repose sur le châssis du retoucheur de document (23).

14. Installer l'unité de transport de relais (I) à l'aide de 4 vis M4 × 8 (K).

12. Libere la palanca de bloqueo (19) y extraiga la unidad de plegado (A) hacia la izquierda del finalizador de documentos.

13. Alinee los orificios (21) de la unidad de transporte de papel (I) con los dos resaltes (20) del finalizador de documentos. Instale de forma tal que el reborde (22) del marco superior de la unidad de transporte de papel apoye en el marco del finalizador de documentos (23).

14. Instale la unidad de transporte de papel por relevador (I) usando 4 tornillos M4 × 8 (K).

12. Lösen Sie den Verriegelungshebel (19) und ziehen Sie die Mittenfalteinheit (A) zur linken Seite des Dokument-Finishers heraus.

13. Richten Sie die Öffnungen (21) der eingesetzten Papierfördereinheit (I) auf die 2 Vorsprünge (20) des Dokument-Finishers aus. Montieren Sie so, dass die Lippe (22) am oberen Rahmen der eingesetzten Papierfördereinheit auf dem Rahmen des Dokument-Finishers (23) ruht.

14. Montieren Sie die eingesetzte Papierfördereinheit (I) mit 4 M4 × 8 Schrauben (K).

12. Rilasciare la leva di blocco (19) e quindi estrarre l'unità di piegatura centrale (A) alla sinistra della finitrice di documenti.

13. Allineare i fori (21) nell'unità relay di trasporto carta (I) con le 2 sporgenze (20) sulla finitrice di documenti. Installare in modo che il bordo (22) sulla struttura superiore dell'unità relay di trasporto carta rimanga sulla struttura (23) della finitrice di documenti.

14. Installare l'unità relay di trasporto carta (I) utilizzando 4 viti M4 × 8 (K).

12. 解除锁定杆 (19), 将中缝装订 - 折页单元 (A) 从文档整理器的左侧拉出。

13. 将装订器的 2 处突出部 (20) 与中间搬运单元 (I) 的孔 (21) 对齐。将中间搬运单元上部框架的弯曲部 (22) 放在装订器的框架上 (23) 以进行安装。

14. 使用 4 颗 M4×8(K) 螺钉来安装后中间搬运单元 (I)。

12. 잠금레버 (19) 를 해제하고 중계반송 유닛 (A) 를 문서 피니셔 좌측으로 이동시킵니다 .


13. 문서 피니셔의 돌기 (20) 2 개로 중계반송 유닛 (I) 의 구멍 (21) 을 맞춥니다 . 중계반송 유닛의 상부 프레임의 구부러진 부분 (22) 이 문서 피니셔의 프레임 (23) 에 얹히게 장착합니다 .

14. 나사 M4×8(K) 4 개로 중계반송 유닛 (I) 를 장착합니다 .

12. ロックレバー (19) を解除し、中折りユニット (A) をドキュメントフィニッシャー左側へ引き出す。

13. ドキュメントフィニッシャーの突起 (20) 2 個に中継搬送ユニット (I) の穴 (21) を合わせる。中継搬送ユニット上部フレームの折曲がり部 (22) がドキュメントフィニッシャーのフレーム (23) に乗るように取り付ける。

14. ビス M4×8(K) 4 本で、中継搬送ユニット (I) を取り付ける。



15. Remove the fixing tape (18) for the wire guide (17) and insert the pin (J) into the wire guide (17), with the 2 projections (24) on either side of the frame (25).

(NOTICE)

Insert the pin (J) to keep wires in the wire guide (17).

16. Screw the pin (J) into the document finisher to anchor the wire guide (17).

15. Enlever la bande adhésive de fixation (18) du guide câble (17) et insérer la goupille (J) dans le guide câble (17) avec les 2 saillies (24) de chaque côté du bâti (25).

(AVIS)

Insérer la goupille (J) pour que les câbles demeurent dans le guide câble (17).

16. Visser la goupille (J) dans le retoucheur de documents pour fixer le guide câble (17) en place.

15. Quite la cinta de fijación (18) de la guía para el cable (17) e inserte el pasador (J) en la guía para el cable (17) con los 2 resaltes (24) a cada lado del marco (25).

(AVISO)

Inserte el pasador (J) para mantener los cables en la guía para el cable (17).

16. Atornille el pasador (J) en el finalizador de documentos para anclar la guía para el cable (17).

15. Entfernen Sie das Klebeband (18) für die Kabelführung (17) und stecken Sie die Rändelschraube (J) in die Kabelführung (17), wobei der Rahmen (25) zwischen den 2 Vorsprüngen (24) liegen muss.

(HINWEIS)

Stecken Sie die Rändelschraube (J) ein, um die Kabel in der Kabelführung (17) zu halten.

16. Schrauben Sie die Rändelschraube (J) in den Dokument-Finisher, um die Kabelführung (17) zu verankern.

15. Rimuovere il nastro di fissaggio (18) per la guida cavi (17) e quindi inserire il perno (J) nella guida cavi (17), con le 2 sporgenze (24) su ciascun lato della struttura (25).

(NOTIFICA)

Inserire il perno (J) per mantenere i cavi nella guida cavi (17).

16. Avvitare il perno (J) nella finitrice di documenti per ancorare la guida cavi (17).

15. 剥除电线导板 (17) 的固定胶带 (18)，使框架 (25) 处于 2 个卡销 (24) 之间，将 1 个销子 (J) 从电线导板 (17) 上穿过。

(注意)

将销钉 (J) 穿过电线导板 (17) 时，注意避免电线露出电线导板 (17) 外。

16. 将销钉 (J) 的螺纹部分安装到装订器上，以固定电线导板 (17)。

15. 전선 가이드 (17) 의 고정 테이프 (18) 를 떼어 내고 보스 (24) 2 개의 사이에 프레임 (25) 이 들어 있는 상태에서 핀 (J) 1 개를 전선 가이드 (17) 에 통과시킵니다 .

(주의)

핀 (J) 은 전선이 전선 가이드 (17) 에서 나오지 않도록 통하게 합니다 .


16. 핀 (J) 의 나사부분을 문서 피니셔에 장착하고 전선 가이드 (17) 를 고정합니다 .

15. 電線ガイド (17) の固定テープ (18) を剥がし、ボス (24) 2 本の間にフレーム (25) が入っている状態で、ピン (J) 1 本を電線ガイド (17) に通す。


(注意)

ピン (J) は電線が電線ガイド (17) から出ないように通す。


16. ピン (J) のネジ部分をドキュメントフィニッシャーに取り付け、電線ガイド (17) を固定する。



17. Install the ground wire (26) to the frame using an M4 × 8 screw (K).
18. Install the binding band (O) to the wires and fit the band into the frame.



19. Plug the 2 connectors (27) into the connectors (28) on the document finisher.
20. Plug the connector (29) into the connector (30) on the relay paper conveying unit (I).



21. Align holes (32) at 2 locations in the guide (P) with projections (31) on the document finisher.
22. Install the guide (P) on the document finisher using 4 M4 × 8 screws (K).

17. Fixer le câble de terre (26) au châssis en procédant à l'aide d'une vis M4 × 8 (K).
18. Monter le collier de fixation (O) sur les câbles et assujettir le collier au châssis.

19. Enfiler les 2 connecteurs (27) dans les connecteurs (28) du retoucheur de document.
20. Enfiler le connecteur (29) dans le connecteur (30) de l'unité de transport de relais (I).

21. Aligner les trous (32) en 2 endroits du guide (P) avec les saillies (31) du retoucheur de document.
22. Monter le guide (P) sur le retoucheur de document à l'aide de 4 vis M4 × 8 (K).

17. Instale el cable de conexión a tierra (26) en el marco usando un tornillo M4 × 8 (K).
18. Instale la correa de sujeción (O) en los cables y coloque la correa en el marco.

19. Enchufe los 2 conectores (27) en los conectores (28) del finalizador de documentos.
20. Enchufe el conector (29) en el conector (30) de la unidad de transporte de papel por relevarador (I).

21. Alinee los orificios (32) de los 2 lugares de la guía (P) con los resaltes (31) del finalizador de documentos.
22. Instale la guía (P) en el finalizador de documentos usando 4 tornillos M4 × 8 (K).

17. Montieren Sie das Massekabel (26) mit einer M4 × 8 Schraube (K) an den Rahmen.
18. Bringen Sie das Schellenband (O) an den Kabeln an und setzen Sie das Band in den Rahmen ein.

19. Verbinden Sie die 2 Steckverbinder (27) mit den Steckverbindern (28) des Dokument-Finishers.
20. Verbinden Sie den Steckverbinder (29) mit dem Steckverbinder (30) der eingesetzten Papierfördereinheit (I).

21. Richten Sie die Öffnungen (32) an 2 Stellen in der Führung (P) auf die Vorsprünge (31) des Dokument-Finishers aus.
22. Montieren Sie die Führung (P) mit 4 M4 × 8 Schrauben (K) am Dokument-Finisher.

17. Installare il cavo di terra (26) alla struttura utilizzando una vite M4 × 8 (K).
18. Installare la fascetta di legatura (O) ai cavi e quindi fissare la fascetta nella struttura.

19. Inserire i 2 connettori (27) nei connettori (28) sulla finitrice di documenti.
20. Inserire il connettore (29) nel connettore (30) sull'unità relay di trasporto carta (I).

21. Allineare i fori (32) alle 2 posizioni nella guida (P) con le sporgenze (31) sulla finitrice di documenti.
22. Installare la guida (P) sulla finitrice di documenti utilizzando 4 viti M4 × 8 (K).

17. 使用 M4×8(K) 螺钉将装接地线 (26) 安装到框架上。
18. 在电线上安装束线带 (O), 将束线带 (O) 嵌入到框架上。

19. 将 2 个连接器 (27) 与装订器的连接器 (28) 相连接。
20. 将连接器 (29) 与中间搬运单元 (H) 的连接器 (30) 相连接。

21. 将装订器的 2 处突出部 (31) 与导板 (P) 的孔 (32) 对齐。
22. 使用 4 颗螺钉 M4×8(K) 将导板 (P) 安装到装订器上。

17. 나사 M4×8(K) 로 접지선 (26) 을 프레임에 장착합니다.
18. 전선에 결속 밴드 (O) 를 장착하고 프레임에 결속 밴드 (O) 를 끼웁니다.


19. 커넥터 (27) 2 개를 문서 피니셔의 커넥터 (28) 에 접속합니다.
20. 커넥터 (29) 를 중계 유니트 (I) 의 커넥터 (30) 에 접속합니다.

21. 문서 피니셔의 돌기 (31) 2 곳을 가이드 (P) 의 구멍 (32) 에 맞춥니다.
22. 나사 M4×8(K) 4 개로 문서 피니셔에 가이드 (P) 를 장착합니다.


17. ビス M4×8(K) でアース線 (26) をフレームに取り付ける。
18. 電線に結束バンド (O) を取り付け、フレームに結束バンド (O) をはめ込む。

19. コネクター (27) 2 個をドキュメントフィニッシャーのコネクター (28) に接続する。
20. コネクター (29) を中継搬送ユニット (I) のコネクター (30) に接続する。

21. ドキュメントフィニッシャーの突起 (31) 2 箇所ガイド (P) の穴 (32) に合わせる。
22. ビス M4×8(K) 4 本でドキュメントフィニッシャーにガイド (P) を取り付け。



23. Open the eject cover (33).
 24. Engage the projection (34) and hook (35) on the front side cover (E) with the center-folding unit (A). Complete installation of the front side cover (E) using an M4 × 10 screw (black) (L).



25. Engage the projection (36) and hook (37) on the rear side cover (F) with the center-folding unit (A). Complete installation of the rear side cover (F) using an M4 × 10 screw (black) (L).

23. Ouvrir le capot d'éjection (33).
 24. Engager la saillie (34) et le crochet (35) du capot latéral avant (E) dans la plieuse (A). Finaliser l'installation du capot latéral avant (E) à l'aide d'une vis M4 × 10 (noire) (L).

25. Engager la saillie (36) et le crochet (37) du capot latéral arrière (F) dans la plieuse (A). Finaliser l'installation du capot latéral arrière (F) à l'aide d'une vis M4 × 10 (noire) (L).

23. Abra la cubierta de expulsión (33).
 24. Enganche el resalto (34) y el gancho (35) de la cubierta lateral frontal (E) con la unidad de plegado (A). Complete la instalación de la cubierta lateral frontal (E) usando un tornillo M4 × 10 (negro) (L).

25. Enganche el resalto (36) y el gancho (37) de la cubierta lateral posterior (F) con la unidad de plegado (A). Complete la instalación de la cubierta lateral posterior (F) usando un tornillo M4 × 10 (negro) (L).

23. Öffnen Sie die Auswurfabdeckung (33).
 24. Hängen Sie den Vorsprung (34) und den Haken (35) der vorderen Seitenabdeckung (E) in die Mittenfalteinheit (A) ein. Befestigen Sie die vordere Seitenabdeckung (E) mit einer M4 × 10 Schraube (schwarz) (L).

25. Hängen Sie den Vorsprung (36) und den Haken (37) der hinteren Seitenabdeckung (F) in die Mittenfalteinheit (A) ein. Befestigen Sie die hintere Seitenabdeckung (F) mit einer M4 × 10 Schraube (schwarz) (L).

23. Aprire il coperchio di espulsione carta (33).
 24. Innestare la sporgenza (34) e il gancio (35) sul coperchio laterale anteriore (E) con l'unità di piegatura centrale (A). Completare l'installazione del coperchio laterale anteriore (E) utilizzando una vite M4 × 10 (nera) (L).

25. Innestare la sporgenza (36) e il gancio (37) sul coperchio laterale posteriore (F) con l'unità di piegatura centrale (A). Completare l'installazione del coperchio laterale posteriore (F) utilizzando una vite M4 × 10 (nera) (L).

23. 打开排纸盖板 (33)。
 24. 将前部侧盖板 (E) 的突出部 (34) 以及挂钩 (35) 嵌入到中缝装订一折页单元 (A) 中, 使用 1 颗 M4×10 (黑) (L) 螺钉来安装前部侧盖板 (E)。


25. 将后部侧盖板 (F) 的突出部 (36) 以及挂钩 (37) 嵌入到中缝装订一折页单元 (A) 中, 使用 1 颗 M4×10 (黑) (L) 螺钉来安装后部侧盖板 (F)。

23. 배출 커버 (33) 를 엽니다.
 24. 사이드 커버 앞 (E) 의 돌기 (34) 및 후크 (35) 를 접기 유닛 (A) 에 끼웁니다. 나사 M4×10 (흑) (L) 1 개로 사이드 커버 앞 (E) 을 장착합니다.

25. 사이드 커버 뒤 (F) 의 돌기 (36) 및 후크 (37) 를 접기 유닛 (A) 에 끼웁니다. 나사 M4×10 (흑) (L) 1 개로 사이드 커버 뒤 (F) 를 장착합니다.

23. 排出カバー (33) を開く。
 24. サイドカバー前 (E) の突起 (34) およびフック (35) を、中折りユニット (A) にはめ込む。
 ビス M4×10(黒) (L) 1 本で、サイドカバー前 (E) を取り付けます。

25. サイドカバー後 (F) の突起 (36) およびフック (37) を、中折りユニット (A) にはめ込む。
 ビス M4×10(黒) (L) 1 本で、サイドカバー後 (F) を取り付けます。



26. Insert the 2 pins (38) on the output tray (H) in the holes in the center-folding unit (A) to install the tray.
27. Install the output stock tray (G) on the output tray (H).
28. Close the eject cover (33).

26. Insérer les 2 goupilles (38) du plateau de sortie (H) dans les trous de la plieuse (A) pour installer le plateau.
27. Installer la butée de sortie du papier (G) sur le plateau de sortie (H).
28. Fermer le capot d'éjection (33).

26. Inserte los 2 pasadores (38) de la bandeja de salida (H) en los orificios de la unidad de plegado (A) para instalar la bandeja.
27. Instale la bandeja de recolección de papel de salida (G) en la bandeja de salida (H).
28. Cierre la cubierta de expulsión (33).


26. Stecken Sie die 2 Rändelschrauben (38) des Ausgabefachs (H) in die Öffnungen der Mittenfalteinheit (A) ein, um das Fach zu installieren.
27. Bringen Sie das Ausgabestapelfach (G) am Ausgabefach (H) an.
28. Schließen Sie die Auswurfabdeckung (33).

26. Inserire i 2 perni (38) sul vassoio di uscita (H) nei fori sull'unità di piegatura centrale (A) per installare il vassoio.
27. Installare il vassoio di uscita stoccaggio (G) sul vassoio di uscita (H).
28. Chiudere il coperchio di espulsione carta (33).


26. 将排纸托盘 (H) 的 2 根销钉 (38) 插入中缝装订—折页单元 (A) 的孔中, 以安装排纸托盘 (H)。
27. 将堆纸托盘 (G) 安装到排纸托盘 (H) 上。
28. 关闭排纸盖板 (33)。

26. 배지 트레이 (H) 의 핀 (38) 2 개를 접기 유닛 (A) 의 구멍에 넣고 배지 트레이 (H) 를 장착합니다.
27. 배지 저장 트레이 (G) 를 배지 트레이 (H) 에 장착합니다.
28. 배출커버 (33) 를 닫습니다.

26. 排紙 트레이 (H) のピン (38) 2 本を中折りユニット (A) の穴に入れ、排紙 트레이 (H) を取り付ける。
27. 排紙ストック 트레이 (G) を排紙 트레이 (H) に取り付ける。
28. 排出カバー (33) を閉じる。



29. Insert the 2 projections (39) on the back of the output stopper (D) in the portions circled on the center-folding unit (A).
Fit the 3 hooks (40) on the output stopper (D) in the holes (41) in the center-folding unit (A).



30. Adhere the D7 label (Q) at the location shown in the figure.

29. Insérer les 2 saillies (39) au dos de la butée de sortie (D) dans les parties encadrées de la pliouse (A).
Assujettir les 3 crochets (40) de la butée de sortie (D) dans les trous (41) de la pliouse (A).

30. Apposer l'étiquette D7 (Q) à l'endroit repéré sur la figure.

29. Inserte los 2 resaltos (39) de la parte posterior del tope de salida (D) en las porciones marcadas con un círculo de la unidad de plegado (A).
Coloque los 3 ganchos (40) del tope de salida (D) en los orificios (41) de la unidad de plegado (A).

30. Adhiera la etiqueta D7 (Q) en el lugar que se muestra en la ilustración.

29. Setzen Sie die 2 Vorsprünge (39) auf der Rückseite des Ausgabeanschlags (D) in die mit Kreis bezeichneten Positionen der Mittenfalteinheit (A) ein.
Setzen Sie die 3 Haken (40) des Ausgabeanschlags (D) in die Öffnungen (41) der Mittenfalteinheit (A) ein.

30. Kleben Sie den D7 Aufkleber (Q) an der abgebildeten Stelle an.

29. Inserire le 2 sporgenze (39) sulla parte posteriore del fermo di uscita (D) nelle porzioni cerchiare sull'unità di piegatura centrale (A).
Fissare i 3 ganci (40) sul fermo di uscita (D) nei fori (41) nell'unità di piegatura centrale (A).

30. Far aderire l'etichetta D7 (Q) alla posizione mostrata nella figura.

29. 将排纸挡板 (D) 内侧的 2 处突出部 (39) 插入到中缝装订-折页单元 (A) 的圆框部。
将排纸挡板 (D) 的 3 个挂钩 (40) 嵌入到中缝装订-折页单元 (A) 的孔 (41) 中。


30. 在图示位置黏贴 D7 标签 (Q)。

29. 배지 스톱퍼 (D) 의 안쪽에 있는 돌기 (39) 2 곳을 접기 유닛 (A) 의에 삽입합니다 .
배지 스톱퍼 (D) 의 후크 (40) 3 곳을 접기 유닛 (A) 의 구멍 (41) 에 끼웁니다 .

30. D7 라벨 (Q) 을 그림의 위치에 붙입니다 .

29. 排紙ストッパー (D) の裏側にある突起 (39) 2箇所を中折ユニット (A) の丸枠部に挿入する。
排紙ストッパー (D) のフック (40) 3箇所を中折ユニット (A) の穴 (41) にはめ込む。

30. D7 ラベル (Q) を図の位置に貼り付ける。



31. Adhere the Operation label (R) at the location shown in the figure.
 32. Reinstall the foot cover (5) and lower rear cover (7).
 33. Close the lower front cover (3) and the upper front cover (1).

31. Apposer l'étiquette de fonctionnement (R) à l'endroit repéré sur la figure.
 32. Reposer le couvercle du pied (5) et le couvercle arrière inférieur (7).
 33. Fermer le capot inférieur avant (3) et le couvercle avant supérieur (1).

31. Adhiera la etiqueta de funcionamiento (R) en el lugar que se muestra en la ilustración.
 32. Vuelva a instalar la cubierta de la pata (5) y la cubierta posterior inferior (7).
 33. Cierre la cubierta frontal inferior (3) y la cubierta frontal superior (1).


31. Kleben Sie den Bedienungsaufkleber (R) an der abgebildeten Stelle an.
 32. Bringen Sie die Fußabdeckung (5) und die untere hintere Abdeckung (7) wieder an.
 33. Schließen Sie die untere vordere Abdeckung (3) und die obere vordere Abdeckung (1).

31. Far aderire l'etichetta di operazione (R) alla posizione mostrata nella figura.
 32. Reinstallare la copertura del piede (5) e il coperchio inferiore posteriore (7).
 33. Chiudere il coperchio inferiore anteriore (3) e il coperchio superiore anteriore (1).

31. 在图示位置黏贴操作标签 (R)。
 32. 按原样安装脚座盖板 (5) 和后部下盖板 (7)。
 33. 关闭前部下盖板 (3) 和前部上盖板 (1)。

31. 조작 라벨 (R) 을 그림의 위치에 붙입니다 .
 32. 풋커버 (5) 및 뒤하 커버 (7) 를 원래대로 장착합니다 .
 33. 전면 아래커버 (3) 및 전면 윗커버 (1) 를 닫습니다 .

31. 操作ラベル (R) を図の位置に貼り付ける。
 32. フットカバー (5) および後下カバー (7) を元通りに取り付ける。
 33. 前下カバー (3) および前上カバー (1) を閉じる。



Adjustment of centerfold-stapling position

Check the distance (a) from the stapling position to the center of the paper. If the distance (a) is over the reference value, follow the procedure below to adjust the position.

<Reference value (a)> ± 2 mm

1. Set maintenance mode U246, select Booklet and Staple Pos.
2. Adjust the values.
3. Press the Start key to confirm the setting value.

Réglage de la position d'agrafage des pages centrales dépliées

Vérifier la distance (a) entre la position d'agrafage et le milieu de la feuille de papier. Si cette distance (a) est supérieure à la valeur de référence, régler la position en procédant de la manière suivante.

<Valeur de référence (a)> ± 2 mm

1. Passer en mode maintenance U246, sélectionner Booklet et Staple Pos.
2. Régler les valeurs.
3. Appuyer sur la touche de Start pour confirmer la valeur de réglage.

Ajuste de la posición de grapado de la unidad de plegado

Compruebe la distancia (a) desde la posición de grapado con respecto al centro del papel. Si dicha distancia (a) supera el valor de referencia, realice el siguiente procedimiento para ajustar la posición.

<Valor de referencia (a)> ± 2 mm

1. Entre en el modo de mantenimiento U246, seleccione Booklet y Staple Pos.
2. Ajuste los valores.
3. Pulse la tecla de Start para confirmar el valor de configuración.

Einstellung der Mittenfalt-Heftposition

Überprüfen Sie den Abstand (a) zwischen der Heftposition und der Papiermitte. Falls der Abstand (a) größer als der Bezugswert ist, ist die Position gemäß der nachstehenden Prozedur nachzustellen.

<Bezugswert (a)> ± 2 mm

1. Schalten Sie in den Wartungsmodus U246, wählen Sie Booklet und Staple Pos.
2. Die Werte einstellen.
3. Den Einstellwert durch Drücken der Start-Taste bestätigen.

Regolazione della posizione di cucitura dell'unità di piegatura centrale

Controllare la distanza (a) dalla posizione di spillatura al centro del foglio. Se la distanza (a) è superiore al valore di riferimento, seguire la procedura riportata sotto per regolare la posizione.

<Valore di riferimento (a)> ± 2 mm

1. Impostare la modalità manutenzione U246, selezionare Booklet e Staple Pos.
2. Regolare i valori.
3. Premere il tasto di Start per confermare il valore dell'impostazione.

中缝装订位置调整

检查从装订位置到纸张中心的距离 (a)。如果距离 (a) 超出标准值范围，按照下列步骤调节装订位置。

<标准值 (a) > ± 2 mm

1. 设置维护模式 U246，选择 Booklet、Staple Pos。
2. 调整设定值。
3. 按 Start 键，以确定设定值。

접기 스테이플 위치조정

스테이플 위치에서 용지 중앙까지의 거리 (a) 를 확인합니다 . 거리 (a) 가 기준치 외의 경우에는 다음 순서로 조정을 합니다 .

< 기준치 (a) > ± 2 mm


1. 메인テナンス 모드 U246 을 세트하고 Booklet, Staple Pos 를 선택합니다 .
2. 설정치를 조정합니다 .
3. 시작키를 누르고 설정치를 확인합니다 .

中とじステーブル位置調整

ステーブル位置から用紙センターまでの距離 (a) を確認する。距離 (a) が基準値外の場合、次の手順で調整を行う。

<基準値 (a) > ± 2 mm

1. メンテナンスモード U246 をセットし、Booklet、Staple Pos を選択する。
2. 設定値を調整する。
3. スタートキーを押し、設定値を確定する。



Adjustment of center folding position

Check the distance (b) from the edge of the paper to the center folding position. If the distance (b) is over the reference value, follow the procedure below to adjust the position.

<Reference value (b)>

A4, Letter: Length of paper $\times 1/2 \pm 2$ mm

A3, Ledger, B4: Length of paper $\times 1/2 \pm 3$ mm

1. Set maintenance mode U246, select Booklet and Booklet Pos.
2. Adjust the values.
3. Press the Start key to confirm the setting value.

Réglage de la position de pliage central

Vérifier la distance (b) entre le bord de la feuille de papier et la position de pliage central. Si cette distance (b) est supérieure à la valeur de référence, régler la position en procédant de la manière suivante.

<Valeur de référence (b)>

A4, Letter : Longueur de la feuille $\times 1/2 \pm 2$ mm

A3, Ledger, B4: Longueur de la feuille $\times 1/2 \pm 3$ mm

1. Passer en mode maintenance U246, sélectionner Booklet et Booklet Pos.
2. Régler les valeurs.
3. Appuyer sur la touche de Start pour confirmer la valeur de réglage.

Ajuste de la posición de plegado

Compruebe la distancia (b) desde el borde del papel a la posición de plegado. Si dicha distancia (b) supera el valor de referencia, realice el siguiente procedimiento para ajustar la posición.

<Valor de referencia (b)>

A4, Letter: Longitud del papel $\times 1/2 \pm 2$ mm

A3, Ledger, B4: Longitud del papel $\times 1/2 \pm 3$ mm

1. Entre en el modo de mantenimiento U246, seleccione Booklet y Booklet Pos.
2. Ajuste los valores.
3. Pulse la tecla de Start para confirmar el valor de configuración.

Einstellung der Mittenfaltposition

Überprüfen Sie den Abstand (b) zwischen der Papierkante und der Mittenfaltposition. Falls der Abstand (b) größer als der Bezugswert ist, ist die Position gemäß der nachstehenden Prozedur nachzustellen.

<Bezugswert (b)>

A4, Letter: Papierlänge $\times 1/2 \pm 2$ mm

A3, Ledger, B4: Papierlänge $\times 1/2 \pm 3$ mm

1. Schalten Sie in den Wartungsmodus U246, wählen Sie Booklet und Booklet Pos.
2. Die Werte einstellen.
3. Den Einstellwert durch Drücken der Start-Taste bestätigen.

Regolazione della posizione centrale di piegatura

Controllare la distanza (b) dal bordo della carta alla posizione centrale di piegatura. Se la distanza (b) è superiore al valore di riferimento, seguire la procedura riportata sotto per regolare la posizione.

<Valore di riferimento (b)>

A4, Letter: Lunghezza carta $\times 1/2 \pm 2$ mm

A3, Ledger, B4: Lunghezza carta $\times 1/2 \pm 3$ mm

1. Impostare la modalità manutenzione U246, selezionare Booklet e Booklet Pos.
2. Regolare i valori.
3. Premere il tasto di Start per confermare il valore dell'impostazione.

中缝折叠位置调整

检查从纸张头部到折叠位置的距离 (b)。如果距离 (b) 超出标准值范围, 按照下列步骤调节折叠位置。

<标准值 (b) >

A4, Letter: 纸张长度 $\times 1/2 \pm 2$ mm

A3, Ledger, B4: 纸张长度 $\times 1/2 \pm 3$ mm

1. 设置维护模式 U246, 选择 Booklet、Booklet Pos。
2. 调整设定值。
3. 按 Start 键, 以确定设定值。

접기 위치조정

용지 끝에서 접기 위치까지의 거리 (b) 를 확인합니다 . 거리 (b) 가 기준치 외의 경우에는 다음 순서로 조정을 합니다 .

<기준치 (b) >

A4, Letter: 용지길이 $\times 1/2 \pm 2$ mm

A3, Ledger, B4: 용지길이 $\times 1/2 \pm 3$ mm

1. 메인テナンス 모드 U246 을 세트하고 Booklet, Booklet Pos 를 선택합니다 .
2. 설정치를 조정합니다 .
3. 시작키를 누르고 설정치를 확인합니다 .

中折り位置調整


用紙端から中折り位置までの距離 (b) を確認する。距離 (b) が基準値外の場合、次の手順で調整を行う。

<基準値 (b) >

A4, Letter: 用紙長 $\times 1/2 \pm 2$ mm

A3, Ledger, B4: 用紙長 $\times 1/2 \pm 3$ mm

1. メンテナンスモード U246 をセットし、Booklet、Booklet Pos を選択する。
2. 設定値を調整する。
3. スタートキーを押し、設定値を確定する。



Adjustment of tri-folding position

Check the distance (c) from the edge of the paper to the second folding position. If the distance (c) is over the reference value, follow the procedure below to adjust the position.

<Reference value (c)> 7.0 ±2 mm

1. Set maintenance mode U246, select Booklet and Three Fold.
2. Adjust the values.
3. Press the Start key to confirm the setting value.

Réglage de la position de triple pliage

Vérifier la distance (c) entre le bord de la feuille de papier et la position du deuxième pliage. Si cette distance (c) est supérieure à la valeur de référence, régler la position en procédant de la manière suivante.

<Valeur de référence (c)> 7,0 ±2 mm

1. Passer en mode maintenance U246, sélectionner Booklet et Three Fold.
2. Régler les valeurs.
3. Appuyer sur la touche de Start pour confirmer la valeur de réglage.

Ajuste de la posición de plegado tríptico

Compruebe la distancia (c) desde el borde del papel a la segunda posición de plegado. Si dicha distancia (c) supera el valor de referencia, realice el siguiente procedimiento para ajustar la posición.

<Valor de referencia (c)> 7,0 ±2 mm

1. Entre en el modo de mantenimiento U246, seleccione Booklet y Three Fold.
2. Ajuste los valores.
3. Pulse la tecla de Start para confirmar el valor de configuración.

Einstellung der Dreilagenfaltposition

Überprüfen Sie den Abstand (c) zwischen der Papierkante und der zweiten Faltposition. Falls der Abstand (c) größer als der Bezugswert ist, ist die Position gemäß der nachstehenden Prozedur nachzustellen.

<Bezugswert (c)> 7,0 ±2 mm

1. Schalten Sie in den Wartungsmodus U246, wählen Sie Booklet und Three Fold.
2. Die Werte einstellen.
3. Den Einstellwert durch Drücken der Start-Taste bestätigen.

Regolazione della posizione di piegatura tripla

Controllare la distanza (c) dal bordo della carta alla posizione della seconda piegatura. Se la distanza (c) è superiore al valore di riferimento, seguire la procedura riportata sotto per regolare la posizione.

<Valore di riferimento (c)> 7,0 ±2 mm

1. Impostare la modalità manutenzione U246, selezionare Booklet e Three Fold.
2. Regolare i valori.
3. Premere il tasto di Start per confermare il valore dell'impostazione.

三折位置調整

检查从纸张头部到第2个折叠位置的距离(c)。如果距离(c)超出标准值范围,按照下列步骤调节折叠位置。

<标准(c) > 7.0±2mm

1. 设置维护模式 U246, 选择 Booklet、Three Fold。
2. 调整设定值。
3. 按 Start 键, 以确定设定值。

두번 접기 위치 조정

용지끝과 두번째 접히는 위치까지의 거리(c)를 확인합니다. 거리(c)가 기준치 외의 경우에는 다음 순서로 조절을 합니다.

<기준치(c) > 7.0±2mm

1. 메인テナンス 모드 U246 을 세트하고 Booklet, Three Fold 를 선택합니다.
2. 설정치를 조정합니다.
3. 시작키를 누르고 설정치를 확인합니다.

三折り位置調整

用紙端と二つ目の折り位置までの距離(c)を確認する。距離(c)が基準値外の場合、次の手順で調整を行う。

<基準値(c) > 7.0±2mm

1. メンテナンスモードU246 をセットし、Booklet、Three Fold を選択する。
2. 設定値を調整する。
3. スタートキーを押し、設定値を確定する。

NOTICE

This accessory is for use only with the following Applicant's Listed Machine.
Refer to the supplied guide to install the accessory in the field.
Machine: DF-790

AVIS

Cet accessoire est utilisable uniquement avec le copieur figurant dans la liste du demandeur suivant.
Se reporter au guide fourni pour installer l'accessoire dans le champ.
Modèle: DF-790

AVISO

Este accesorio es sólo para usar en las siguientes fotocopiadoras de la lista de solicitantes.
Consulte las instrucciones para la instalación de accesorios en el lugar del cliente.
Modelo: DF-790

HINWEIS

Dieses Zubehör ist nur für den Einsatz mit der folgenden Antragstellerlisten-Kopiermaschine vorgesehen.
Installieren Sie das Zubehör gemäß der mitgelieferten Anleitung im Feld.
Modell: DF-790

NOTIFICA

Questo accessorio deve essere usato solo con le seguenti fotocopiatrici nella lista dell'applicante.
Consultare la guida fornita in dotazione per il montaggio in campo dell'accessorio.
Modello: DF-790

注意

本产品适用于以下选购件。
安装时，请参照附带的说明书。
式样：DF-790


주의

본 제품은 이하의 기종에 적용됩니다.
설치할 때에는 동봉된 안내문을 참조해 주십시오.
기종:DF-790


注意

本製品は、以下の機種に適用します。
設置する際は、同梱の手順書を参照してください。
機種:DF-790

INSTALLATION GUIDE FOR MAILBOX



<p>English</p> <p>Supplied parts</p> <p>A. Mailbox 1</p> <p>B. Front mounting plate cover 1</p> <p>C. Rear mounting plate cover 1</p> <p>D. Copy eject bins 7</p>	<p>E. M4 × 12 screw 2</p> <p>F. Tray name label (for users)..... 1</p>	<p>Be sure to remove any tape and/or cushioning material from supplied parts.</p>
<p>Français</p> <p>Pièces fournies</p> <p>A. Boîte à lettres 1</p> <p>B. Couvercle de la plaque de montage avant 1</p> <p>C. Couvercle de la plaque de montage arrière1</p> <p>D. Case d'éjection de copies..... 7</p>	<p>E. Vis M4 × 12..... 2</p> <p>F. Étiquette de nom de plateau (pour les utilisateurs) 1</p>	<p>Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.</p>
<p>Español</p> <p>Partes suministradas</p> <p>A. Buzón de correo 1</p> <p>B. Cubierta de la placa de montaje frontal 1</p> <p>C. Cubierta de la placa de montaje trasera.... 1</p> <p>D. Bandejas de expulsión de copias 7</p>	<p>E. Tornillo M4 × 12 2</p> <p>F. Etiqueta de nombre de la bandeja (para usuarios)..... 1</p>	<p>Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.</p>
<p>Deutsch</p> <p>Gelieferte Teile</p> <p>A. Mailbox 1</p> <p>B. Vordere Abdeckung der Montageplatte 1</p> <p>C. Hintere Abdeckung der Montageplatte 1</p> <p>D. Kopienausgabefächer..... 7</p>	<p>E. M4 × 12 Schraube 2</p> <p>F. Fachnamenaufkleber (für Benutzer) 1</p>	<p>Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.</p>
<p>Italiano</p> <p>Parti di forniture</p> <p>A. Casella postale 1</p> <p>B. Coperchio della piastra di montaggio anteriore .. 1</p> <p>C. Coperchio della piastra di montaggio posteriore. 1</p> <p>D. Scomparti di espulsione delle copie 7</p>	<p>E. Vite M4 × 12..... 2</p> <p>F. Etichetta di nome del vassoio (per utenti) 1</p>	<p>Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.</p>
<p>简体中文</p> <p>附属品</p> <p>A. 邮箱..... 1</p> <p>B. 支撑板前盖板..... 1</p> <p>C. 支撑板后盖板..... 1</p> <p>D. 接纸盘..... 7</p>	<p>E. M4×12 螺丝 2</p> <p>F. 托盘名称标贴（用户用）..... 1</p>	<p>如果附属品上带有固定胶带，缓冲材料时必须揭下。</p>
<p>한국어</p> <p>동봉품</p> <p>A. 메일박스..... 1</p> <p>B. 부착판커버 앞..... 1</p> <p>C. 부착판커버 뒤..... 1</p> <p>D. 배출핀..... 7</p>	<p>E. 나사 M4 × 12..... 2</p> <p>F. 트레이 명칭 스티 (사용자용) 1</p>	<p>동봉품에 고정 테이프, 완충재가 붙어 있는 경우에는 반드시 제거할 것 .</p>
<p>日本語</p> <p>同梱品</p> <p>A. メールボックス..... 1</p> <p>B. 取付板カバー前..... 1</p> <p>C. 取付板カバー後..... 1</p> <p>D. 排出ピン..... 7</p>	<p>E. ビス M4×12 2</p> <p>F. トレイ名称シール(ユーザー用) 1</p>	<p>同梱品に固定テープ、緩衝材が付いている場合は必ず取り外すこと。</p>



Procedure

Be sure to turn the MFP main power switch off and disconnect the MFP power plug from the wall outlet before starting to install the mailbox.

1.Remove the front top cover (2) and rear top cover (3) at the top of the finisher (1) using a flat-blade screwdriver or the like.

Procédure

Veiller à bien mettre l'interrupteur principal du MFP sur la position d'arrêt et à débrancher la fiche d'alimentation du MFP de la prise murale avant d'entreprendre l'installation de la boîte à lettres.

1.Retirer le couvercle supérieur avant (2) et le couvercle supérieur arrière (3) situés en haut du retoucheur (1) à l'aide d'un tournevis à tête plate ou d'un outil équivalent.

Procedimiento

Asegúrese de apagar el MFP con el interruptor principal y de desconectar la clavija de alimentación del MFP de la toma de corriente de la pared antes de empezar a instalar el buzón de correo.

1.Remueva la cubierta superior delantera (2) y la cubierta superior trasera (3) en la parte superior del finalizador (1) utilizando un destornillador de punta plana o similar.

Verfahren

Schalten Sie vor der Installation der Mailbox unbedingt den Hauptschalter des MFP aus, und ziehen Sie den Netzstecker aus der Netzsteckdose.

1.Entfernen Sie die vordere obere Abdeckung (2) und die hintere obere Abdeckung (3) an der Oberseite des Finishers (1) mit einem Klingenschraubendreher oder dergleichen.

Procedura

Non mancare di spegnere l'MFP utilizzando l'interruttore principale di alimentazione e scollegare la spina del cavo di alimentazione dell'MFP dalla presa della rete elettrica, prima di cominciare a installare la casella postale.

1.Rimuovere il coperchio superiore anteriore (2) e il coperchio superiore posteriore (3) dalla parte superiore del finitore (1) utilizzando un cacciavite a punta piatta, o un attrezzo simile.

安装步骤

安装邮箱时，必须关闭 MFP 主机上的主电源开关，并拔下主装置的电源插头后进行安装。

1. 用一字形螺丝刀拆下装订器 (1) 上部的顶罩前盖板 (2) 和顶罩后盖板 (3)。

설치순서


메일박스를 부착할 때에는 반드시 MFP 본체의 주 전원 스위치를 OFF 로 하고 전원 플러그를 뽑은 후에 작업을 할 것 .

1. 피니셔 (1) 상부의 윗커버 앞 덮개 (2), 윗커버 뒤 덮개 (3) 를 마이너스 드라이버 등으로 제거합니다 .

取付手順

メールボックスを取り付ける際は、必ず MFP 本体の主電源スイッチを OFF にし、電源プラグを外して作業をおこなう。

1. フィニッシャー (1) 上部の天カバー前フタ (2) 、天カバー後フタ (3) をマイナスドライバーなどで取り外す。



2. Fit the hooks (4) located at the front and rear of the bottom of the mailbox (A) into the notches (5) located at the front and rear of the top of the finisher (1) as shown in the illustration and attach the mailbox (A) to the finisher (1).

Note: Lift the front and rear of the mailbox (A) lightly upward to make sure that the mailbox (A) does not float.

2. Insérer les crochets (4) se trouvant à l'avant et à l'arrière au fond de la boîte à lettres (A) dans les encoches (5) situées à l'avant et à l'arrière en haut du retoucheur (1) comme illustré ici, puis fixer la boîte à lettres (A) au retoucheur (1).

Note: Lever légèrement l'avant et l'arrière de la boîte à lettres (A) de sorte que celle-ci ne bouge plus.

2. Coloque los ganchos (4) ubicados en la parte inferior frontal y trasera del buzón de correo (A) en las muescas (5) ubicadas en la parte superior frontal y trasera del finalizador (1), como se muestra en la ilustración, y coloque el buzón de correo (A) en el finalizador (1).

Nota: Levante ligeramente la parte frontal y trasera del buzón de correo (A) hacia arriba para asegurarse de que el buzón de correo (A) no queda suspendido.

2. Setzen Sie die Haken (4) an der Vorder- und Rückseite der Mailbox (A) in die Öffnungen (5) vorne und hinten an der Oberseite des Finishers (1) ein, wie in der Abbildung dargestellt, und bringen Sie die Mailbox (A) am Finisher (1) an.

Hinweis: Heben Sie die Mailbox (A) vorne und hinten etwas an, um sicher zu stellen, dass die Mailbox (A) nicht pendelt.

2. Inserire i ganci (4) posizionati sul davanti e sul dietro della parte di fondo della casella postale (A), negli incavi (5) posizionati sul davanti e sul dietro della parte superiore del finitore (1) come mostrato nell'illustrazione, e fissare la casella postale (A) al finitore (1).

Nota: Sollevare leggermente la parte anteriore e posteriore (A) della casella postale verso l'alto per accertarsi che non si sposti.

2. 如图所示, 将位于邮箱 (A) 底部前后侧的卡扣 (4) 嵌入位于装订器 (1) 顶部前后侧的凹口 (5), 并将邮箱 (A) 安装至装订器 (1)。


注:
轻轻向上提升邮箱 (A) 的前后侧, 确保邮箱 (A) 未处于悬浮状态。

2. 메일박스 (A) 하부의 앞뒤에 있는 후크 (4) 를 피니셔 (1) 상부의 앞뒤에 있는 파인 홈에 (5) 에 일러스트와 같이 삽입하고 메일박스 (A) 를 피니셔측에 장착합니다.


주의
메일박스 (A) 의 앞뒤를 각각 상방향으로 가볍게 들어 메일박스 (A) 가 떠 있지 않은 것을 확인합니다.

2. メールボックス (A) 下部の前後にあるフック (4) をフィニッシャー(1) 上部の前後にある切り欠き部 (5) にイラストのように挿入し、メールボックス (A) をフィニッシャー(1) に取り付ける。


注意
メールボックス (A) の前後をそれぞれ上方向に軽く持ち上げ、メールボックス (A) が浮かないことを確認する。



3. Fix the each of the front and rear of the mailbox (A) to the finisher using a M4 × 12 screw (E).



4. Remove the rear cover (6) of the mailbox (A).



5. Remove the tape from the connector (7) of the mailbox (A), and plug it into the connector (8) on the finisher.
6. Reinstall the rear cover (6).

3. Fixer l'avant et l'arrière de la boîte à lettres (A) au retoucheur à l'aide d'une vis M4 × 12 (E).

4. Déposer le couvercle arrière (6) de la boîte à lettres (A).

5. Enlever la bande adhésive du connecteur (7) de la boîte à lettres (A) et enficher ce connecteur dans le connecteur (8) du retoucheur.
6. Reposer le couvercle arrière (6).

3. Fije las partes frontal y trasera del buzón de correo (A) al finalizador utilizando un tornillo M4 × 12 (E).

4. Quite la cubierta trasera (6) del buzón de correo (A).

5. Quite la cinta del conector (7) del buzón de correo (A) y enchúfelo en el conector (8) del finalizador.
6. Vuelva a instalar la cubierta trasera (6).

3. Befestigen Sie die Vorderseite und die Rückseite der Mailbox (A) mit einer M4 × 12 Schraube (E) am Finisher.

4. Nehmen Sie die hintere Abdeckung (6) der Mailbox (A) ab.

5. Entfernen Sie das Band vom Steckverbinder (7) der Mailbox (A) und stecken Sie ihn in den Steckverbinder (8) am Finisher.
6. Bringen Sie die hintere Abdeckung (6) wieder an.

3. Fissare ciascuna parte anteriore e posteriore della casella postale (A) al finitore utilizzando una vite M4 × 12 (E).

4. Rimuovere il coperchio posteriore (6) della casella postale (A).

5. Rimuovere il nastro dal connettore (7) della casella postale (A), e collegarlo nel connettore (8) sul finitore.
6. Reinstallare il coperchio posteriore (6).

3. 在邮箱 (A) 的前后各使用 1 颗 M4 × 12 螺丝 (E) 来将其固定在装订器上。

4. 拆下邮箱 (A) 的后部盖板 (6)。

5. 揭下邮箱 (A) 的连接器 (7) 的胶带, 将其与装订器的连接器 (8) 相连接。
6. 重新安装后盖板 (6)。

3. 메일박스 (A) 의 앞뒤를 각각 나사 M4 × 12(E) 1 개로 피니셔를 고정합니다 .


4. 메일박스 (A) 의 뒤커버 (6) 를 떼어냅니다 .

5. 메일박스 (A) 의 커넥터 (7) 테이프를 벗겨내고 피니셔 커넥터 (8) 에 접속합니다 .
6. 뒤커버 (6) 를 원래대로 장착합니다 .


3. メールボックス (A) の前後をそれぞれビス M4 × 12(E)1 本で、フィニッシャーに固定する。

4. メールボックス (A) の後カバー (6) を取り外す。

5. メールボックス (A) のコネクタ (7) のテープをはがし、フィニッシャーのコネクタ (8) に接続する。
6. 後カバー (6) を元通り取り付け。



7. Insert the 2 hooks (9) on the front mounting plate cover (B) for the mailbox into the finisher to install the cover (B).



8. Install the rear mounting plate cover (C) on the finisher in the same way.

7. Insérer les 2 crochets (9) du couvercle de la plaque de montage avant (B) de la boîte à lettres dans le retourneur pour installer ce couvercle (B).

8. Installer le couvercle de la plaque de montage arrière (C) sur le retourneur en procédant de la même manière.

7. Para instalar la cubierta (B), inserte los 2 ganchos (9) de la cubierta de la placa de montaje frontal (B) para el buzón de correo en el finalizador.

8. Instale de la misma manera la cubierta de la placa de montaje trasera (C) en el finalizador.

7. Setzen Sie die 2 Haken (9) an der vorderen Abdeckung der Montageplatte (B) für die Mailbox in den Finisher ein, um die Abdeckung (B) zu installieren.

8. Bringen Sie auf gleiche Weise die hintere Abdeckung der Montageplatte (C) am Finisher an.

7. Inserire nel finitore i 2 ganci (9) posizionati sul coperchio della piastra di montaggio anteriore (B) per la casella postale, per installare il coperchio (B).

8. Installare il coperchio della piastra di montaggio posteriore (C) sul finitore nella stessa maniera.

7. 将邮箱的安装板前部盖板 (B) 的 2 个卡扣 (9) 插入到装订器中, 以安装安装板前部盖板 (B)。


8. 按相同方法将安装板后部盖板 (C) 安装到装订器上。

7. 메일박스의 부착판 커버 앞 (B) 의 후크 (9) 2 곳을 피니셔에 삽입하고 부착판 커버 앞 (B) 을 장착합니다 .

8. 같은 방식으로 부착판 커버 뒤 (C) 를 피니셔에 장착합니다 .

7. メールボックスの取付板カバー前 (B) のフック (9) 2箇所をフィニッシャーに挿入し、取付板カバー前 (B) を取り付ける。

8. 同様に取付板カバー後 (C) をフィニッシャーに取り付ける。



9. Fit the seven copy eject bins (D) to the ejection section of the mailbox (A) from the lowest bin to the highest.
Press both ends of each copy eject bin (D) to bend it a little, then fit the bin by inserting the front and rear pins (10) into the round holes (11) at the front and rear of the mailbox.

10. Insert the MFP power plug to the outlet and turn the MFP main power switch on to check the operation.

9. Fixer les sept cases d'éjection de copies (D) sur la section d'éjection de la boîte à lettres (A), en procédant de la case située tout en bas à celle située tout en haut.
Appuyer sur les deux extrémités de chaque case d'éjection des copies (D) pour cintrer légèrement cette pièce, puis monter la case en insérant les broches avant et arrière (10) dans les trous ronds (11) à l'avant et à l'arrière de la boîte à lettres.

10. Insérer la fiche d'alimentation du MFP dans la prise et mettre l'interrupteur principal du MFP sur la position de marche pour vérifier le fonctionnement.

9. Fije las siete bandejas de expulsión de copias (D) en la sección de expulsión del buzón de correo (A) de la bandeja más baja a la más alta.
Presione ambos extremos de cada bandeja de expulsión de copias (D) para doblarlas un poco; después, coloque la bandeja insertando los pasadores delantero y trasero (10) en los orificios redondos (11) en la parte frontal y posterior del buzón de correo.

10. Enchufe el cable eléctrico del MFP en el tomacorriente y encienda el interruptor principal del MFP para verificar el funcionamiento.

9. Setzen Sie die sieben Kopienausgabefächer (D) in den Ausgabeabschnitt der Mailbox (A) ein, beginnend vom untersten Fach zum höchsten.
Drücken Sie beide Enden jedes Kopienausgabefachs (D) zusammen, um es etwas zu biegen, und setzen Sie das Fach ein, indem Sie die vorderen und hinteren Stifte (10) in die Rundlöcher (11) vorne und hinten an der Mailbox einsetzen.

10. Stecken Sie den Netzstecker des MFP in eine Netzsteckdose und schalten Sie den Hauptschalter des MFP ein, um den Betrieb zu prüfen.

9. Installare i sette scomparti di espulsione delle copie (D) nella parte di espulsione della casella postale (A), cominciando dallo scomparto più in basso fino a quello più in alto.
Premere le due estremità di ciascuno scomparto di emissione delle copie (D) in modo da piegarlo un poco, quindi installare lo scomparto inserendo i perni anteriore e posteriore (10) nei fori rotondi (11) che si trovano alla parte anteriore e posteriore della casella postale.

10. Inserire la spina del cavo di alimentazione dell'MFP nella presa della rete elettrica e accenderla utilizzando l'interruttore principale di alimentazione in modo da controllare il funzionamento.

9. 从邮箱 (A) 的排出部下面起按顺序安装 7 个接纸盘 (D)。
按住邮箱格 (D) 的左右两侧并使其稍稍下垂, 将前后的销钉 (10) 插入邮箱前后的圆孔 (11) 中。

10. 将 MFP 主机的电源插头插入插座, 然后按下主开关并确认是否接通。

9. 배출핀 (D) 7 개를 메일박스 (A) 의 배출부에 밑에서부터 순서대로 장착합니다.
배출핀 (D) 의 좌우를 밀어 조금 휘게해 앞뒤의 핀 (10) 을 메일박스의 앞뒤의 둥근 구멍 (11) 에 삽입합니다.

10. MFP 본체의 전원 플러그를 콘센트에 꽂고 주 전원 스위치를 ON 으로 해서 동작을 확인합니다.

9. 排出ピン (D) 7 枚をメールボックス (A) の排出部に下から順番に取り付ける。
排出ピン (D) の左右を押し少したわませ、前後のピン (10) をメールボックスの前後の丸穴 (11) に挿入する。

10. MFP 本体の電源プラグをコンセントに差し込み、主電源スイッチを ON にして動作を確認する。

NOTICE

This accessory is for use only with the following Applicant's Listed Machine.
Refer to the supplied guide to install the accessory in the field.
Machine: DF-790

AVIS

Cet accessoire est utilisable uniquement avec le copieur figurant dans la liste du demandeur suivant.
Se reporter au guide fourni pour installer l'accessoire dans le champ.
Modèle: DF-790

AVISO

Este accesorio es sólo para usar en las siguientes fotocopiadoras de la lista de solicitantes.
Consulte las instrucciones para la instalación de accesorios en el lugar del cliente.
Modelo: DF-790

HINWEIS

Dieses Zubehör ist nur für den Einsatz mit der folgenden Antragstellerlisten-Kopiermaschine vorgesehen.
Installieren Sie das Zubehör gemäß der mitgelieferten Anleitung im Feld.
Modell: DF-790

NOTIFICA

Questo accessorio deve essere usato solo con le seguenti fotocopiatrici nella lista dell'applicante.
Consultare la guida fornita in dotazione per il montaggio in campo dell'accessorio.
Modello: DF-790

注意

本产品适用于以下选购件。
安装时，请参照附带的说明书。
式样：DF-790


주의

본 제품은 이하의 기종에 적용됩니다.
설치할 때에는 동봉된 안내문을 참조해 주십시오.
기종:DF-790


注意

本製品は、以下の機種に適用します。
設置する際は、同梱の手順書を参照してください。
機種:DF-790

INSTALLATION GUIDE FOR PUNCH UNIT




English		E. Spring..... 1		L. Large clamp (for DF-790) 1		
Supplied parts		F. Punch PWB 1		M. Ferrite core 1		
A. Punch guide..... 1	B. Hole punch unit..... 1	G. Waste hole punch box 1	H. M3 x 8 tap Tight S screw 3	Be sure to remove any tape and/or cushioning material from supplied parts.		
C. Motor unit..... 1	D. Stop ring 1	I. Label sheet 1	J. Film 1			
		K. Small clamp (for DF-770)..... 1				
Français		E. Ressort 1		L. Grand collier (pour DF-790)..... 1		
Pièces fournies		F. PWB de perforatrice..... 1		M. Noyau de ferrite 1		
A. Guide de perforatrice..... 1	B. Perforatrice 1	G. Bac de récupération de la perforatrice..... 1	H. Vis S taraudée M3 x 8 3	Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.		
C. Moteur 1	D. Bague d'arrêt 1	I. Feuillet d'étiquettes 1	J. Film 1			
		K. Petit collier (pour DF-770)..... 1				
Español		E. Resorte 1		L. Sujetador grande (para DF-790)..... 1		
Partes suministradas		F. PWB de perforación..... 1		M. Núcleo de ferrita..... 1		
A. Guía de perforación..... 1	B. Perforadora..... 1	G. Caja para desechos de la perforación 1	H. Tornillo de ajuste M3 x 8..... 3	Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.		
C. Unidad motriz 1	D. Anillo de tope..... 1	I. Hoja con etiqueta 1	J. Película 1			
		K. Sujetador pequeño (para DF-770)..... 1				
Deutsch		E. Feder 1		L. Große Klemme (für DF-790)..... 1		
Gelieferte Teile		F. Locher-PWB 1		M. Ferritkern 1		
A. Locherführung 1	B. Lochereinheit..... 1	G. Lochungsabfallbehälter..... 1	H. M3 x 8 Passstift-Verbandschrauben 3	Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.		
C. Motoreinheit..... 1	D. Anschlagring..... 1	I. Aufkleberbogen..... 1	J. Film 1			
		K. Kleine Klemme (für DF-770)..... 1				
Italiano		E. Molla 1		L. Morsetto grande (per DF-790) 1		
Parti di forniture		F. Scheda a circuiti stampati di perforazione 1		M. Nucleo di ferrite..... 1		
A. Guida perforazione 1	B. Unità di perforazione 1	G. Scarto perforazione 1	H. Viti con testa a croce S M3 x 8..... 3	Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.		
C. Unità motore 1	D. Anello di bloccaggio..... 1	I. Foglio di etichette..... 1	J. Pellicola 1			
		K. Morsetto piccolo (per DF-770) 1				
简体中文		E. 弹簧 1		K. 固定夹 小 (DF-770 用) 1		
附属品		F. 打孔单元电路板 1		L. 固定夹 大 (DF-790 用) 1		
A. 打孔导向板..... 1	B. 打孔单元..... 1	G. 打孔纸屑盒 1	H. M3 X 8 攻丝紧固型 S 螺丝 3	M. 磁环 1		
C. 电机单元..... 1	D. 止动环..... 1	I. 标签纸 1	J. 胶片 1	如果附属品上带有固定胶带, 缓冲材料时务必揭下。		
한국어		E. 스프링 1		K. 클램프 소 (DF-770 용) 1		
동봉품		F. 펀치기판..... 1		L. 클램프 대 (DF-790 용) 1		
A. 펀치가이드..... 1	B. 펀치유닛..... 1	G. 펀치폐기박스..... 1	H. 나사 M3x8 탭타이트 S..... 3	M. 페라이트 코어..... 1		
C. 모터유닛..... 1	D. 스톱링..... 1	I. 라벨 시트..... 1	J. 필름..... 1	동봉품에 고정 테이프, 완충재가 붙어 있는 경우에는 반드시 제거할 것.		
日本語		E. バネ 1		L. クランプ大 (DF-790 用) 1		
同梱品		F. パンチ基板 1		M. フェライトコア 1		
A. パンチガイド..... 1	B. パンチユニット..... 1	G. パンチくずボックス 1	H. ビス M3x8 タップタイト S 3	同梱品に固定テープ、緩衝材が付いている場合は必ず取り外すこと。		
C. モーターユニット..... 1	D. ストップリング..... 1	I. ラベルシート 1	J. フィルム 1			
		K. クランプ小 (DF-770 用) 1				



Removing the cover (DF-770)

If installing on the DF-790, proceed to step 1 on page 3.

1. Remove the screw (1) and remove the small rear cover (2).



2. Remove the 2 screws (3) and remove the upper rear cover (4).

Procedure

Before installing the hole punch unit, make sure the MFP's main power switch is turned off and that its power cord is unplugged from the power outlet.

Install the document finisher first and then install the hole punch unit.

Procédure

Avant d'installer la perforatrice, s'assurer que l'interrupteur d'alimentation principal du MFP est hors tension et que le câble d'alimentation est débranché de la prise secteur.

Installer d'abord le finisseur de document, puis installer la perforatrice.

Dépose du couvercle (DF-770)

Pour l'installation sur le modèle DF-790, passer à l'étape 1 de la page 3.

1. Déposer la vis (1) et déposer le petit couvercle arrière (2).

2. Déposer les 2 vis (3) et déposer le couvercle supérieur arrière (4).

Procedimiento

Antes de instalar la perforadora, asegúrese de que el interruptor principal de la alimentación del MFP esté desconectado y de que el cable de alimentación esté desenchufado de la toma de corriente de la pared.

Instale primero el finalizador de documentos y luego instale la perforadora.

Extracción de la cubierta (DF-770)

Si realiza la instalación en el DF-790, vaya al paso 1 de la página 3.

1. Quite el tornillo (1) y, después, quite la cubierta trasera pequeña (2).

2. Quite los 2 tornillos (3) y, después, quite la cubierta trasera superior (4).

Verfahren

Bevor Sie mit dem Einbau der Lochereinheit beginnen, stellen Sie sicher, dass der Hauptschalter des Kopierers ausgeschaltet und das Netzkabel aus der Steckdose gezogen ist. Bringen Sie den Dokument-Finisher zuerst und dann erst die Lochereinheit an.

Entfernen der Abdeckung (DF-770)

Zur Installation des DF-790 weitergehen zu Schritt 1 auf Seite 3.

1. Die Schraube (1) entfernen und die kleine hintere Abdeckung (2) abnehmen.

2. Die 2 Schrauben (3) entfernen und die obere hintere Abdeckung (4) abnehmen.

Procedura

Prima di installare l'unità di perforazione, assicurarsi che l'interruttore principale dell'MFP sia spento e che il cavo di alimentazione sia scollegato dalla presa di corrente.

Installare prima la finitrice e poi procedere all'installazione dell'unità di perforazione.

Rimozione del coperchio (DF-770)

Se si installa sull'unità DF-790, procedere al passo 1 a pagina 3.

1. Rimuovere la vite (1) e quindi rimuovere il pannello posteriore piccolo (2).

2. Rimuovere le 2 viti (3) e quindi rimuovere il pannello superiore posteriore (4).

安装步骤

安装打孔单元时，必须事先关闭 MFP 主机的主电源开关，并拔下电源插头后再进行作业。首先安装装订器，然后安装打孔单元。

拆下盖板 (DF-770 时)

安装到 DF-790 上时，跳至 P3 的步骤 1。

1. 拆除 1 颗螺丝 (1)，拆下后部小盖板 (2)。

2. 拆除 2 颗螺丝 (3)，拆下后上部盖板 (4)。

설치순서

펀치유니트를 부착할 때에는 반드시 MFP 본체의 주 전원 스위치를 OFF 로 하고 전원플러그를 뺀 다음 작업을 할 것 . 문서 피니셔를 설치 후 , 펀치유니트를 설치 할 것 .

커버제거 (DF-770 의 경우)

DF-790 에 장착하는 경우에는 P3 의 순서 1 로 진행합니다 .

1. 나사 (1) 1 개를 제거하고 뒷 소커버 (2) 를 제거합니다 .

2. 나사 (3) 2 개를 제거하고 뒷 상커버 (4) 를 제거합니다 .

取付手順


パンチユニットを設置するときは、必ず MFP 本体の主電源スイッチを OFF にし、電源プラグを抜いてから作業すること。ドキュメントフィニッシャーを設置後、パンチユニットを設置すること。

カバーの取り外し (DF-770 の場合)

DF-790 に装着の場合は、P3 の手順 1 へ進む。


1. ビス (1) 1 本を外し、後小カバー (2) を取り外す。

2. ビス (3) 2 本を外し、後上カバー (4) を取り外す。




Removing the cover (DF-790)

1. Remove the screw (5) and remove the small rear cover (6).



2. Remove the 3 screws (7) and remove the upper rear cover (8).



Installing the hole punch unit

3. Remove the screw (9) and pull the guide (10) outwards.

Dépose du couvercle (DF-790)

1. Déposer la vis (5) et déposer le petit couvercle arrière (6).

2. Déposer les 3 vis (7) et déposer le couvercle supérieur arrière (8).

Installation de la perforatrice

3. Déposer la vis (9) et tirer le guide (10) vers l'extérieur.

Extracción de la cubierta (DF-790)

1. Quite el tornillo (5) y, después, quite la cubierta trasera pequeña (6).

2. Quite los 3 tornillos (7) y, después, quite la cubierta trasera superior (8).

Instalación de la perforadora

3. Quite el tornillo (9) y tire de la guía (10) hacia fuera.

Entfernen der Abdeckung (DF-790)

1. Die Schraube (5) entfernen und die kleine hintere Abdeckung (6) abnehmen.

2. Die 3 Schrauben (7) entfernen und die obere hintere Abdeckung (8) abnehmen.

Anbringen der Lochereinheit

3. Die Schraube (9) entfernen und die Führung (10) nach außen ziehen.

Rimozione del coperchio (DF-790)

1. Rimuovere la vite (5) e quindi rimuovere il pannello posteriore piccolo (6).

2. Rimuovere le 3 viti (7) e quindi rimuovere il pannello superiore posteriore (8).

Installare l'unità di perforazione

3. Rimuovere la vite (9) ed estrarre la guida (10) verso l'esterno.

拆下盖板 (DF-790 时)

1. 拆除 1 颗螺丝 (5), 拆下后部小盖板 (6)。

2. 拆除 3 颗螺丝 (7), 拆下后上部盖板 (8)。

安装打孔单元

3. 拆除 1 颗螺丝 (9), 将导向板 (10) 向外拉出。

커버제거 (DF-790 의 경우)

1. 나사 (5) 1 개를 제거하고 뒷 소커버 (6) 를 제거합니다 .

2. 나사 (7) 3 개를 제거하고 뒷 상커버 (8) 를 제거합니다 .

펀치유닛 부착

3. 나사 (9) 1 개를 제거하고 가이드 (10) 을 앞으로 끌어 당깁니다 .


カバーの取り外し (DF-790 の場合)

1. ビス (5) 1 本を外し、後小カバー (6) を取り外す。

2. ビス (7) 3 本を外し、後上カバー (8) を取り外す。

パンチユニットの取り付け

3. ビス (9) 1 本を外し、ガイド (10) を手前に引き出す。



4. After using alcohol to clean the shaded portion (38) of the motor shown for adhering the film (J), adhere the film.

4. Après avoir utilisé de l'alcool pour nettoyer la partie du moteur hachurée (38) sur laquelle le film (J) est apposé, coller ce film.

4. Después de utilizar alcohol para limpiar la parte sombreada (38) del motor mostrada en la ilustración para pegar la película (J), pegue la película.


4. Den in der Abbildung grau dargestellten Teil (38) des Motors zum Anbringen des Films (J) mit Alkohol reinigen und dann den Film anbringen.

4. Dopo aver usato l'alcool per pulire la parte ombreggiata (38) del motore, illustrata per l'adesione della pellicola (J), far aderire la pellicola.


4. 用酒精清洁电机斜侧处(38)的粘贴位置后, 粘贴胶片(J)。

4. 모터 사선부(38)의 부착위치를 알코올 청소 후, 필름(J)을 부착합니다.

4. モーター斜線部(38)の貼り付け位置をアルコール清掃後、フィルム(J)を貼り付ける。



5. Install the punch guide (A) so that the leading edge of the guide (11) is below the document finisher frame (12).



6. Insert the hole punch unit (B) into the document finisher.

5. Monter le guide de la perforatrice (A) de sorte que le bord d'attaque du guide (11) se trouve sous le bâti du retoucheur de document (12).

6. Insérer la perforatrice (B) dans le retoucheur de document.

5. Instale la guía de perforación (A) de forma tal que el borde delantero de la guía (11) quede debajo de la carcasa del finalizador de documentos (12).

6. Inserte la perforadora (B) en el finalizador de documentos.

5. Die Locherführung (A) so einsetzen, dass die Vorderkante der Führung (11) unter dem Rahmen (12) des Dokument-Finishers liegt.

6. Die Lochereinheit (B) in den Dokument-Finisher einsetzen.

5. Installare la guida perforazione (A) in modo che il bordo principale della guida (11) sia sotto il telaio (12) della finitrice di documenti.

6. Inserire l'unità di perforazione (B) nella finitrice di documenti.

5. 将打孔导向板 (A) 的前端 (11) 安装在装订器的框架 (12) 的下部。


6. 将打孔单元 (B) 插入到装订器中。

5. 펀치가이드 (A) 의 끝 (11) 이 문서 피니셔의 프레임 (12) 밑으로 되도록 장착합니다 .



6. 펀치유닛 (B) 를 문서 피니셔에 삽입합니다 .

5.パンチガイド (A) の先端 (11) がドキュメントフィニッシャーのフレーム (12) の下になるように取り付ける。

6.パンチユニット (B) をドキュメントフィニッシャーに挿入する。



7. Raise the hole punch unit (B) slightly and fit the hook (13) on the motor unit (C) into the groove (14) in the document finisher. At the same time, insert the rod (15) on the motor unit (C) into the hole (16) in the hole punch unit (B).



8. Secure the motor unit (C) with the 2 screws (H).

7. Lever légèrement la perforatrice (B) et insérer le crochet (13) du moteur (C) dans la rainure (14) du retoucheur de document. Insérer en même temps la tige (15) du moteur (C) dans le trou (16) de la perforatrice (B).

8. Fixer le moteur (C) à l'aide de 2 vis (H).

7. Levante ligeramente la perforadora (B) y encaje el gancho (13) de la unidad motriz (C) en la ranura (14) del finalizador de documentos. Al mismo tiempo, inserte la varilla (15) de la unidad motriz (C) en el orificio (16) de la perforadora (B).

8. Asegure la unidad motriz (C) con los 2 tornillos (H).

7. Die Lochereinheit (B) leicht anheben und den Haken (13) an der Motoreinheit (C) in die Nut (14) des Dokument-Finishers einsetzen. Dabei auch die Stange (15) an der Motoreinheit (C) in die Öffnung (16) der Lochereinheit (B) einstecken.

8. Die Motoreinheit (C) mit den 2 Schrauben (H) sichern.

7. Sollevare leggermente l'unità di perforazione (B) ed inserire il gancio (13) sull'unità motore (C) nella scanalatura (14) della finitrice di documenti. Contemporaneamente, inserire l'asta (15) sull'unità motore (C) nel foro (16) dell'unità di perforazione (B).

8. Fissare l'unità motore (C) con le 2 viti (H).

7. 稍稍抬起打孔单元 (B), 将电机单元 (C) 的卡扣 (13) 嵌入装订器的沟槽 (14) 内。与此同时, 将电机单元 (C) 的轴 (15) 插入打孔单元 (B) 的孔 (16) 中。


8. 使用 2 颗螺丝 (H) 来固定电机单元 (C)。

7. 펀치유닛 (B) 를 조금 들면서 모터유닛 (C) 후크 (13) 를 문서 피니셔의 구 (14) 에 꽂습니다 . 이것과 동시에 모터유닛 (C) 의 축 (15) 을 펀치유닛 (B) 구멍 (16) 에 삽입합니다 .


8. 나사 (H) 2 개로 모터유닛 (C) 를 고정합니다 .

7.パンチユニット (B) を少し持ち上げながら、モーターユニット (C) のフック (13) をドキュメントフィニッシャーの溝 (14) にはめ込む。これと同時に、モーターユニット (C) の軸 (15) をパンチユニット (B) の穴 (16) に挿入する。

8.ビス (H) 2 本で、モーターユニット (C) を固定する。



9. Fit the stop ring (D) over the motor unit rod (15) and fit the spring (E) between the hole punch unit and motor unit.



10. Run the hole punch unit wire (17) through the motor unit edging (18).

11. Plug the wire from the hole punch unit motor into the connector on the motor unit (19).

9. Monter la bague d'arrêt (D) sur la tige du moteur (15) et insérer le ressort (E) entre la perforatrice et le moteur.

10. Faire passer le câble de la perforatrice (17) dans le passage de câbles du moteur (18)
11. Raccorder le câble du moteur de la perforatrice au connecteur du moteur (19).

9. Coloque el anillo de tope (D) sobre la varilla de la unidad motriz (15) y coloque el resorte (E) entre la perforadora y la unidad motriz.

10. Tienda el cable de la perforadora (17) a través de la pestaña de la unidad motriz (18).
11. Enchufe el cable del motor de la perforadora al conector de la unidad motriz (19).

9. Den Anschlagring (D) auf die Stange (15) der Motoreinheit setzen und die Feder (E) zwischen Lochereinheit und Motoreinheit einsetzen.

10. Das Kabel (17) der Lochereinheit durch den Kantenschutz (18) der Motoreinheit führen.
11. Das Kabel vom Motor der Lochereinheit an den Steckverbinder der Motoreinheit (19) anschließen.

9. Inserire l'anello di bloccaggio (D) sull'asta (15) dell'unità motore ed inserire molla (E) tra l'unità di perforazione e l'unità motore.

10. Far passare il cavo dell'unità di perforazione (17) attraverso il bordo (18) dell'unità motore.
11. Collegare il cavo dal motore dell'unità di perforazione nel connettore sull'unità motore (19).

9. 将止动环 (D) 嵌入到电机单元的轴 (15) 上, 在打孔单元与电机单元之间安装弹簧 (E)。


10. 将打孔单元的电线 (17) 穿过电机单元的包边孔 (18)。
11. 将来自打孔单元的电机的电线与电机单元的接插件 (19) 相连接。

9. 모터유닛 축 (15) 에 스톱링 (D) 을 끼고 펀치유닛과 모터유닛 사이에 스프링 (E) 을 설치합니다 .

10. 펀치유닛의 전선 (17) 을 모터유닛의 에징 (18) 에 지나가게 합니다 .
11. 펀치유닛 모터에서의 전선을 모터유닛 커넥터 (19) 에 접속합니다 .

9. 모터유닛의 축 (15) にストップ링 (D) をはめ、パンチユニットとモーターユニットの間にバネ (E) を取り付けます。


10. パンチユニットの電線 (17) をモーターユニットのエッジング (18) に通す。
11. パンチユニットのモーターからの電線をモーターユニットのコネクタ (19) に接続する。



Installing the punch PWB and waste hole punch box (DF-770)

If installing on the DF-790, proceed to step 12 on page 12.

- Fit the 2 hooks (20) in the punch PWB (F) into the cut (21) in the document finisher. At the same time, insert the projection (23) on the document finisher into the hole (22) in the punch PWB (F).
- Using the screw (H), tighten the hole punch unit ground wire (24) and the punch PWB (F) together.



- Plug the 6 hole punch unit wires into the connectors (25) on the punch PWB (F).

Installation de la PWB de la perforatrice et du bac de récupération de la perforatrice (DF-770)

Pour une installation sur le modèle DF-790, passer à l'étape 12 en page 12.

- Insérer les 2 crochets (20) de la PWB de la perforatrice (F) dans la découpe (21) du retoucheur de document. Insérer en même temps la saillie (23) du retoucheur de document dans le trou (22) de la PWB de la perforatrice (F).
- Fixer le câble de terre de la perforatrice (24) à la PWB de la perforatrice (F) à l'aide d'une vis (H).

- Raccorder les 6 câbles de la perforatrice aux connecteurs (25) de la PWB de la perforatrice (F).

Instalación del PWB de perforación y la caja para desechos de la perforación (DF-770)

Si realiza la instalación en el DF-790, vaya al paso 12 de la página 12.

- Coloque los 2 ganchos (20) del PWB de perforación (F) en el corte (21) del finalizador de documentos. Al mismo tiempo, inserte el resalto (23) del finalizador de documentos en el orificio (22) del PWB de perforación (F).
- Usando el tornillo (H), apriete juntos el cable de conexión a tierra de la perforadora (24) y el PWB de perforación (F).

- Enchufe los 6 cables de la perforadora a los conectores (25) del PWB de perforación (F).

Installation der Locher-PWB und des Lochungsabfallbehälters (DF-770)

Zur Installation des DF-790 weitergehen zu Schritt 12 auf Seite 12.

- Die 2 Haken (20) in der Locher-PWB (F) in die Aussparung (21) am Dokument-Finisher einsetzen. Dabei auch den Vorsprung (23) am Dokument-Finisher in die Öffnung (22) auf der Locher-PWB (F) einsetzen.
- Mit der Schraube (H) das Massekabel (24) der Lochereinheit an der Locher-PWB (F) festziehen.

- Die 6 Kabel der Lochereinheit an die Steckverbinder (25) der Locher-PWB (F) anschließen.

Installazione della scheda a circuiti stampati di perforazione e dello scarto perforazione (DF-770)

Se si installa sull'unità DF-790, procedere al passo 12 a pagina 12.

- Inserire i 2 ganci (20) della scheda a circuiti stampati di perforazione (F) nell'incisione (21) della finitrice di documenti. Contemporaneamente, inserire la sporgenza (23) sulla finitrice di documenti nel foro (22) della scheda a circuiti stampati di perforazione (F).
- Utilizzando la vite (H), stringere insieme il cavo di terra (24) dell'unità di perforazione e la scheda a circuiti stampati di perforazione (F).

- Collegare i 6 cavi dell'unità di perforazione nei connettori (25) sulla scheda a circuiti stampati di perforazione (F).

安装电路板与打孔纸屑盒 (DF-770 时)

安装到 DF-790 上时, 跳至 P12 的步骤 12。

- 将打孔电路板 (F) 的 2 个卡扣 (20) 挂在装订器的缺口 (21) 上。同时, 将打孔电路板 (F) 的孔 (22) 卡入装订器的突出部 (23)。
- 使用 1 颗螺丝 (H) 将打孔单元的接地线 (24) 与打孔电路板 (F) 一起固定。

- 将打孔单元的 6 根电线与打孔电路板 (F) 的接插件 (25) 相连接。

기판과 펀치폐기박스의 부착 (DF-770 의 경우)

DF-790 에 장착하는 경우에는 P12 의 순서 12 로 진행합니다 .

- 펀치기판 (F) 의 후크 (20) 2 곳을 문서 피니셔의 구멍 (21) 에 걸립니다 . 동시에 펀치기판 (F) 구멍 (22) 을 문서 피니셔의 돌기 (23) 에 넣습니다 .
- 나사 (H) 1 개로 펀치유닛의 접지선 (24) 과 펀치기판 (F) 을 함께 조입니다 .


- 펀치유닛의 전선 6 선을 펀치기판 (F) 커넥터 (25) 에 접속합니다 .

基板とパンチくずボックスの取り付け (DF-770 の場合)


DF-790 に装着の場合は、P12 の手順 12 へ進む。

- パンチ基板 (F) のフック (20) 2箇所をドキュメントフィニッシャーの切り欠き (21) に引っ掛ける。同時に、パンチ基板 (F) の穴 (22) をドキュメントフィニッシャーの突起 (23) に入れる。
- ビス (H) 1本で、パンチユニットのアース線 (24) とパンチ基板 (F) を共締めする。

- パンチユニットの電線 6本を、パンチ基板 (F) のコネクタ (25) に接続する。



15. Plug the 2 punch PWB wires into the connectors (27) on the DF main PWB (26).



16. Install the small clamp (K) on the finisher, then pass and fasten the wires from the motor unit and hole punch unit.

17. Attach the ferrite core (M) to the wire.

15. Raccorder les 2 câbles de la PWB de la perforatrice aux connecteurs (27) de la PWB principale du DF (26).

16. Monter le petit collier (K) sur le retoucheur puis faire passer les câbles du moteur et de la perforatrice dans ce collier pour les fixer en place

17. Fixer le noyau en ferrite (M) au câble.

15. Enchufe los 2 cables del PWB de perforación a los conectores (27) del PWB principal del DF (26).

16. Instale el sujetador pequeño (K) en el finalizador, después tienda y ajuste los cables de la unidad motriz y la perforadora.

17. Fije el núcleo de ferrita (M) al cable.

15. Die 2 Kabel der Locher-PWB an die Steckverbinder (27) der DF-Haupt-PWB (26) anschließen.

16. Die kleine Klemme (K) am Finisher anbringen, dann die Kabel von der Motoreinheit und der Lochereinheit hindurchführen und befestigen.

17. Den Ferritkern (M) am Kabel befestigen.

15. Collegare i 2 cavi della scheda a circuiti stampati di perforazione nei connettori (27) sulla scheda principale PWB (26) della DF.

16. Installare il morsetto piccolo (K) sul finitore, e quindi passare e fissare i cavi dall'unità motore e dall'unità di perforazione.

17. Applicare il nucleo in ferrite (M) al cavo.

15. 将打孔电路板的2根电线与DF主电路板(26)的接插件(27)连接。

16. 把小固定夹(K)安装在装订器上,从电机单元和打孔单元出来的导线穿过固定夹来固定。

17. 用磁环(M)套住导线。

15. 펀치기판의 전선 2 선을 DF 주 회로기판(26)의 커넥터(27)에 접속합니다.


16. 클램프 소(K)를 피니셔에 장착, 모터 유닛과 펀치 유닛에서부터 전선을 통과시키고 고정합니다.

17. 페라이트 코어(M)를 전선으로 장착합니다.

15. パンチ基板の電線2本をDF主回路基板(26)のコンネクター(27)に接続する。

16. クランプ小(K)をフィニッシャーに取り付け、モーターユニットとパンチユニットからの電線を通し、固定する。

17. フェライトコア(M)を電線に取り付ける。



18. Replace the upper rear cover (4) and small rear cover (2).

19. Open the upper front cover (28) and insert the waste hole punch box (G).

18. Reposer le couvercle supérieur arrière (4) et le petit couvercle arrière (2).

19. Ouvrir le couvercle supérieur avant (28) et insérer le bac de récupération de la perforatrice (G).

18. Vuelva a colocar la cubierta trasera superior (4) y la cubierta trasera pequeña (2).

19. Abra la cubierta delantera superior (28) e inserte la caja para desechos de la perforación (G).

18. Die obere hintere Abdeckung (4) und die kleine hintere Abdeckung (2) wieder einsetzen.

19. Die obere vordere Abdeckung (28) öffnen und den Lochungsabfallbehälter (G) einsetzen.

18. Ricollocare il pannello superiore posteriore (4) e il pannello posteriore piccolo (2).

19. Aprire il pannello superiore anteriore (28) ed inserire lo scarto perforazione (G).

18. 按原样安装后上部盖板 (4) 与后部小盖板 (2)。


19. 打开前上部盖板 (28), 插入打孔纸屑盒 (G)。

18. 뒤 상커버 (4) 와 후 소커버 (2) 를 원래대로 부착합니다 .

19. 앞 상커버 (28) 를 열고 펀치폐기박스 (G) 를 삽입합니다 .

18. 後上カバー (4) と後小カバー (2) を元通り取り付ける。

19. 前上カバー (28) を開き、パンチくずボックス (G) を挿入する。



20. After cleaning each area with alcohol, adhere the following labels from the label sheet (J) at the locations shown in the illustration: B, C..

21. Close the upper front cover (28).

20. Après avoir nettoyé chaque zone à l'alcool, apposer les étiquettes suivantes du feuillet d'étiquettes (J) aux emplacements indiqués dans l'illustration : B, C.

21. Fermer le couvercle supérieur avant (28).

20. Después de limpiar todas las zonas con alcohol, despegue de la hoja de etiquetas (J) las etiquetas siguientes, y péguelas en los sitios que se indican en la ilustración: B, C.

21. Cierre la cubierta delantera superior (28).

20. Nachdem Sie alle Flächen mit Alkohol gereinigt haben, kleben Sie bitte die folgenden Aufkleber vom Aufkleberbogen (J) an die in der Abbildung angegebenen Stellen: B, C.

21. Die obere vordere Abdeckung (28) schließen.

20. Dopo aver pulito ciascuna zona con alcol, applicare le seguenti etichette del foglio di etichette (J) sui punti mostrati nell'illustrazione: B, C.

21. Chiudere il pannello superiore anteriore (28).

20. 用酒精清洁各区域后, 请在如图所示位置粘贴从标签纸上 (J) 撕下的下列标签 B、C。


21. 关闭前上部盖板 (28)。

20. 라벨 시트 (J) 내의 하기 라벨을 일러스트의 위치에 알코올청소 후 붙입니다: B, C .

21. 앞 상커버 (28) 를 닫습니다 .


20. ラベルシート (J) 内のB、Cをイラストの位置にアルコール清掃後貼り付ける。

21. 前上カバー(28) を閉じる。



Installing the punch PWB and waste hole punch box (DF-790)

12. Fit the 2 hooks (29) in the punch PWB (F) into the cut (30) in the document finisher. At the same time, insert the projection (32) on the document finisher into the hole (31) in the punch PWB (F).
13. Using the screw (H), tighten the hole punch unit ground wire (33) and the punch PWB (F) together.



14. Plug the 6 hole punch unit wires into the connectors (34) on the punch PWB (F).

Installation de la PWB de la perforatrice et du bac de récupération de la perforatrice (DF-790).

12. Insérer les 2 crochets (29) de la PWB de la perforatrice (F) dans la découpe (30) du retoucheur de document. Insérer en même temps la saillie (32) du retoucheur de document dans le trou (31) de la PWB de la perforatrice (F).
13. Fixer le câble de terre de la perforatrice (33) à la PWB de la perforatrice (F) à l'aide d'une vis (H).

14. Raccorder les 6 câbles de la perforatrice aux connecteurs (34) de la PWB de la perforatrice (F).

Instalación del PWB de perforación y la caja para desechos de la perforación (DF-790)

12. Coloque los 2 ganchos (29) del PWB de perforación (F) en el corte (30) del finalizador de documentos. Al mismo tiempo, inserte el resalto (32) del finalizador de documentos en el orificio (31) del PWB de perforación (F).
13. Usando el tornillo (H), apriete juntos el cable de conexión a tierra de la perforadora (33) y el PWB de perforación (F).

14. Enchufe los 6 cables de la perforadora a los conectores (34) del PWB de perforación (F).

Installation der Locher-PWB und des Lochungsabfallbehälters (DF-790)

12. Die 2 Haken (29) in der Locher-PWB (F) in die Aussparung (30) am Dokument-Finisher einsetzen. Dabei auch den Vorsprung (32) am Dokument-Finisher in die Öffnung (31) auf der Locher-PWB (F) einsetzen.
13. Mit der Schraube (H) das Massekabel (33) der Lochereinheit an der Locher-PWB (F) festziehen.

14. Die 6 Kabel der Lochereinheit an die Steckverbinder (34) der Locher-PWB (F) anschließen.

Installazione della scheda a circuiti stampati di perforazione e dello scarto perforazione (DF-790)

12. Inserire i 2 ganci (29) della scheda a circuiti stampati di perforazione (F) nell'intaglio (30) della finitrice di documenti. Contemporaneamente, inserire la sporgenza (32) sulla finitrice di documenti nel foro (31) della scheda a circuiti stampati di perforazione (F).
13. Utilizzando la vite (H), stringere insieme il cavo di terra (33) dell'unità di perforazione e la scheda a circuiti stampati di perforazione (F).

14. Collegare i 6 cavi dell'unità di perforazione nei connettori (34) sulla scheda a circuiti stampati di perforazione (F).

安装电路板与打孔纸屑盒 (DF-790 时)

12. 将打孔电路板 (F) 的 2 个卡扣 (29) 挂在装订器的缺口 (30) 上。同时, 将打孔电路板 (F) 的孔 (31) 卡入装订器的突出部 (32)。
13. 使用 1 颗螺丝 (H) 将打孔单元的接地线 (33) 与打孔电路板 (F) 一起固定。

14. 将打孔单元的 6 根电线与打孔电路板 (F) 的接插件 (34) 相连接。

기판과 펀치폐기박스의 부착 (DF-790 의 경우)


12. 펀치기판 (F) 의 후크 (29) 2 곳을 문서 피니셔의 구멍 (30) 에 겁니다. 동시에 펀치기판 (F) 구멍 (31) 을 문서 피니셔의 돌기 (32) 에 넣습니다.
13. 나사 (H) 1 개로 펀치유닛의 접지선 (33) 과 펀치기판 (F) 을 함께 조입니다.

14. 펀치유닛의 전선 6 선을 펀치기판 (F) 커넥터 (34) 에 접속합니다.


基板とパンチくずボックスの取り付け (DF-790 の場合)

- 12.パンチ基板 (F) のフック (29) 2箇所をドキュメントフィニッシャーの切り欠き (30) に引っ掛ける。同時に、パンチ基板 (F) の穴 (31) をドキュメントフィニッシャーの突起 (32) に入れる。
- 13.ビス (H) 1本で、パンチユニットのアース線 (33) とパンチ基板 (F) を共締めする。

- 14.パンチユニットの電線 6本を、パンチ基板 (F) のコネクタ (34) に接続する。



15. Plug the 2 punch PWB wires into the connectors (36) on the DF main PWB (35).



16. Install the small clamp (L) on the finisher, then pass and fasten the wires from the motor unit and hole punch unit.
17. Attach the ferrite core (M) to the wire.

15. Raccorder les 2 câbles de la PWB de la perforatrice aux connecteurs (36) de la PWB principale du DF (35).

16. Installer le grand collier (L) sur le retoucheur puis faire passer les câbles du moteur et de la perforatrice dans ce collier pour les fixer en place.
17. Fixer le noyau en ferrite (M) au câble.

15. Enchufe los 2 cables del PWB de perforación a los conectores (36) del PWB principal del DF (35).

16. Instale el sujetador grande (L) en el finalizador, después tienda y ajuste los cables de la unidad motriz y la perforadora.
17. Fije el núcleo de ferrita (M) al cable.

15. Die 2 Kabel der Locher-PWB an die Steckverbinder (36) der DF-Haupt-PWB (35) anschließen.

16. Die große Klemme (L) am Finisher anbringen, dann die Kabel von der Motoreinheit und der Lochereinheit hindurchführen und befestigen.
17. Den Ferritkern (M) am Kabel befestigen.

15. Collegare i 2 cavi della scheda a circuiti stampati di perforazione nei connettori (36) sulla scheda principale PWB (35) della DF.

16. Installare il morsetto grande (L) sul finitore, e quindi passare e fissare i cavi dall'unità motore e dall'unità di perforazione.
17. Applicare il nucleo in ferrite (M) al cavo.

15. 将打孔电路板的2根电线与DF主电路板(35)的接插件(36)连接。


16. 把大固定夹(L)安装在装订器上,从电机单元和打孔单元出来的导线穿过固定夹来固定。
17. 用磁环(M)套住导线。

15. 펀치기판의 전선 2 선을 DF 주 회로기판(35)의 커넥터(36)에 접속합니다.

16. 클램프 대(L)를 피니셔에 장착, 모터 유닛과 펀치 유닛에서부터 전선을 통과시키고 고정합니다.
17. 페라이트 코어(M)를 전선으로 장착합니다.

15. パンチ基板の電線2本をDF主回路基板(35)のコネクター(36)に接続する。

16. クランプ大(L)をフィニッシャーに取り付け、モーターユニットとパンチユニットからの電線を通し、固定する。
17. フェライトコア(M)を電線に取り付ける。



18. Replace the upper rear cover (8) and small rear cover (6).

19. Open the upper front cover (37) and insert the waste hole punch box (G).

18. Reposer le couvercle supérieur arrière (8) et le petit couvercle arrière (6).

19. Ouvrir le couvercle supérieur avant (37) et insérer le bac de récupération de la perforatrice (G).

18. Vuelva a colocar la cubierta trasera superior (8) y la cubierta trasera pequeña (6).

19. Abra la cubierta delantera superior (37) e inserte la caja para desechos de la perforación (G).

18. Die obere hintere Abdeckung (8) und die kleine hintere Abdeckung (6) wieder einsetzen.

19. Die obere vordere Abdeckung (37) öffnen und den Lochungsabfallbehälter (G) einsetzen.

18. Ricollocare il pannello superiore posteriore (8) e il pannello posteriore piccolo (6).

19. Aprire il pannello superiore anteriore (37) ed inserire lo scarto perforazione (G).

18. 按原样安装后上部盖板 (8) 与后部小盖板 (6)。


19. 打开前上部盖板 (37)，插入打孔纸屑盒 (G)。

18. 뒤 상커버 (8) 와 후 소커버 (6) 를 원래대로 부착합니다 .

19. 앞 상커버 (37) 를 열고 펀치폐기박스 (G) 를 삽입합니다 .

18. 後上カバー (8) と後小カバー (6) を元通り取り付ける。

19. 前上カバー (37) を開き、パンチくずボックス (G) を挿入する。



20. After cleaning each area with alcohol, adhere the following labels from the label sheet (J) at the locations shown in the illustration: A, C.
 21. Close the upper front cover (37).

20. Après avoir nettoyé chaque zone à l'alcool, apposer les étiquettes suivantes du feuillet d'étiquettes (J) aux emplacements indiqués dans l'illustration :
 A, C.
 21. Fermer le couvercle supérieur avant (37).

20. Después de limpiar todas las zonas con alcohol, despegue de la hoja de etiquetas (J) las etiquetas siguientes, y péguelas en los sitios que se indican en la ilustración: A, C.
 21. Cierre la cubierta delantera superior (37).


20. Nachdem Sie alle Flächen mit Alkohol gereinigt haben, kleben Sie bitte die folgenden Aufkleber vom Aufkleberbogen (J) an die in der Abbildung angegebenen Stellen: A, C.
 21. Die obere vordere Abdeckung (37) schließen.

20. Dopo aver pulito ciascuna zona con alcol, applicare le seguenti etichette del foglio di etichette (J) sui punti mostrati nell'illustrazione: A, C.
 21. Chiudere il pannello superiore anteriore (37).

20. 用酒精清洁各区域后, 请在如图所示位置粘贴从标签纸上 (J) 撕下的下列标签 A, C。
 21. 关闭前上部盖板 (37)。

20. 라벨 시트 (J) 내의 하기 라벨을 일러스트의 위치에 알코올청소 후 붙입니다: A, C .
 21. 앞 상커버 (37) 를 닫습니다 .

20. ラベルシート (J) 内の A,C をイラストの位置にアルコール清掃後貼り付ける。
 21. 前上カバー (37) を閉じる。



[Adjusting the hole punch position]

1. Connect the MFP power plug to the wall outlet and turn the MFP main power switch on.
2. Make a test copy in punch mode.
3. If any off-centering is observed, follow the procedure below to adjust the hole position.

Adjusting the hole punch entry registration

1. Enter the maintenance mode U246, select Finisher and Punch Regist.
2. Adjust the values.
When the paper fed in skewed copy example (a): Increase the setting value.
When the paper crimped copy example (b): Decrease the setting value.
3. Press the Start key to confirm the setting value.

[Réglage de la position des perforations]

1. Insérer la fiche d'alimentation du MFP dans la prise murale et mettre l'interrupteur principal du MFP sous tension.
2. Effectuer une copie d'essai en mode perforation.
3. Si les perforations sont décentrées, suivre la procédure ci-dessous pour ajuster la position de perforation.

Réglage de l'enregistrement de l'entrée des perforations

1. Passer en mode maintenance U246, sélectionner Finisher et Punch Regist.
2. Régler les valeurs.
Si le papier est alimenté de travers exemple de copie (a): Augmentez la valeur de réglage.
Si le papier est froissé exemple de copie (b): Diminuez la valeur de réglage.
3. Appuyer sur la touche de Start pour confirmer la valeur de réglage.

[Ajuste de la posición de perforación]

1. Conecte el enchufe del MFP en el receptáculo de pared y encienda el interruptor principal del MFP.
2. Haga una copia de prueba en el modo de perforación.
3. Si observa descentrado, siga el procedimiento de abajo para ajustar la posición del agujero.

Ajuste del registro de entrada de perforación

1. Entre en el modo de mantenimiento U246, seleccione Finisher y Punch Regist.
2. Ajuste los valores.
Cuando el papel alimentado está torcido copia de muestra (a): Aumente el valor de configuración.
Cuando el papel se dobló copia de muestra (b): Reduzca el valor de configuración.
3. Pulse la tecla de Start para confirmar el valor de configuración.

[Einstellen der Lochungsposition]

1. Stecken Sie den Netzstecker des MFP in die Wandsteckdose und schalten Sie den MFP am Hauptschalter ein.
2. Eine Testkopie im Lochungsmodus erstellen.
3. Falls eine außermittige Lochung erfolgte, ist die Lochungsposition wie folgend nachzustellen.

Einstellen der Lochungsregistrierung

1. Schalten Sie in den Wartungsmodus U246, wählen Sie Finisher und Punch Regist.
2. Die Werte einstellen.
Wenn Papier verkantet eingezogen wird Kopiebeispiel (a): Den Einstellwert erhöhen.
Wenn Papier verknittert wird Kopiebeispiel (b): Den Einstellwert verringern.
3. Den Einstellwert durch Drücken der Start-Taste bestätigen.

[Regolazione di posizione dei fori di perforazione]

1. Collegare la spina del cavo di alimentazione dell'MFP alla presa a muro della rete elettrica e accendere l'interruttore principale di alimentazione.
2. Eseguire una copia di prova in modalità di perforazione.
3. Nel caso in cui non lo siano, eseguire la procedura indicata qui di seguito per regolarne la posizione.

Regolazione del registro del foro di perforazione

1. Entrare in modalità manutenzione U246, selezionare Finisher e Punch Regist.
2. Regolare i valori.
Quando l'alimentazione della carta risulta obliqua esempio di copia (a): Aumentare il valore dell'impostazione.
Quando la carta risulta increspata esempio di copia (b): Diminuire il valore dell'impostazione.
3. Premere il tasto di Start per confermare il valore dell'impostazione.

[打孔位置的调节]

1. 将 MFP 主机上的电源插头插入电源插座中，打开主电源开关。
2. 在打孔模式下进行测试复印。
3. 打孔位置有偏差时，按以下步骤进行调节。

打孔装入定位调节

1. 设置维护模式 U246，选择 Finisher、Punch Regist。
2. 调整设定值。
纸张斜向搬运时的复印样本 (a)：调高设定值。
纸张作 Z 字折时的复印样本 (b)：调低设定值。
3. 按 Start 键，以确定设定值。

[핀치위치의 조정]

1. MFP 본체 전원플러그를 콘센트에 꽂고 주 전원 스위치를 ON으로 합니다.
2. 핀치모드에서 시험복사를 합니다.
3. 핀치위치가 벗어난 경우에는 다음 순서로 조정합니다.

핀치반입 레지스트 조정


1. 메인テナンス 모드 U246 를 세트하고 Finisher, Punch Regist 를 선택합니다.
2. 설정치를 조정합니다.
용지가 경사로 반송되는 경우의 복사샘플 (a): 설정치를 높입니다.
용지가 Z 折임이 있는 경우의 복사샘플 (b): 설정치를 내립니다.
3. 시작키를 누르고 설정치를 확인합니다.

[パンチ位置の調整]

1. MFP 本体の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。
2. パンチモードでテストコピーを行う。
3. パンチ位置がずれていた場合、次の手順で調整を行う。

パンチ搬入レジスト調整

1. メンテナンスモード U246 をセットし、Finisher、Punch Regist を選択する。
2. 設定値を調整する。
用紙が斜めに搬送される場合コピーサンプル (a)：設定値を上げる。
用紙が Z 折れする場合コピーサンプル (b)：設定値を下げる。
3. スタートキーを押し、設定値を確定する。



Adjusting the hole punch position feed

1. Enter the maintenance mode U246, select Finisher and Punch Feed.
2. Adjust the values.
If the punch hole position is closer to the edge than the reference value (c): Increase the setting value.
If the punch hole position is further from the edge than the reference value (c): Decrease the setting value.

3. Press the Start key to confirm the setting value.
<Reference value (c)>
Metric specification: 13 mm; Inch specification: 9.5 mm

Réglage de la position du point de perforation

1. Passer en mode maintenance U246, sélectionner Finisher et Punch Feed.
2. Régler les valeurs.
Si la perforation est plus proche du bord de la feuille que défini par la valeur de référence (c): Augmentez la valeur de réglage.
Si la perforation est plus loin du bord de la feuille que défini par la valeur de référence (c): Diminuez la valeur de réglage.

3. Appuyer sur la touche de Start pour confirmer la valeur de réglage.
<Valeur de référence (c)>
Spécifications métriques: 13 mm; Spécifications en pouces: 9,5 mm

Ajuste de la alimentación de la posición de perforación

1. Entre en el modo de mantenimiento U246, seleccione Finisher y Punch Feed.
2. Ajuste los valores.
Si la posición de perforación está más cerca del borde que el valor de referencia (c): Aumente el valor de configuración.
Si la posición de perforación está más alejada del borde que el valor de referencia (c): Reduzca el valor de configuración.

3. Pulse la tecla de Start para confirmar el valor de configuración.
<Valor de referencia (c)>
Sistema métrico: 13 mm; en pulgadas: 9,5 mm

Einstellen des Transports der Lochungsposition

1. Schalten Sie in den Wartungsmodus U246, wählen Sie Finisher und Punch Feed.
2. Die Werte einstellen.
Falls die Lochungsposition näher an der Kante liegt als der Bezugswert (c) erlaubt: Den Einstellwert erhöhen.
Falls die Lochungsposition ferner von der Kante liegt als der Bezugswert (c) erlaubt: Den Einstellwert verringern.

3. Den Einstellwert durch Drücken der Start-Taste bestätigen.
<Bezugswert (c)>
Metrischer Abstand: 13 mm; Abstand in Zoll: 9,5 mm

Regolazione spostamento di posizione dei fori di perforazione

1. Entrare in modalità manutenzione U246, selezionare Finisher e Punch Feed.
2. Regolare i valori.
Se la posizione dei fori di perforazione è più vicina al bordo rispetto al valore di riferimento (c): Aumentare il valore dell'impostazione.
Se la posizione dei fori di perforazione è più lontana dal bordo rispetto al valore di riferimento (c): Diminuire il valore dell'impostazione.

3. Premere il tasto di Start per confermare il valore dell'impostazione.
<Valore di riferimento (c)>
Specificazione in unità metrica: 13 mm; Specificazione in pollici: 9,5 mm

打孔位置搬运调节

1. 设置维护模式 U246, 选择 Finisher、Punch Feed。
2. 调整设定值。
打孔位置比基准值 (c) 短时: 调高设定值。
打孔位置比基准值 (c) 长时: 调低设定值。

3. 按 Start 键, 以确定设定值。
<基准值 (c) >
公制规格: 13mm、英制规格: 9.5mm

핀치위치 반송조정



1. 메인터너스 모드 U246 를 세트하고 Finisher, Punch Feed 를 선택합니다.
2. 설정치를 조정합니다.
핀치구멍의 위치가 기준치 (c) 보다 짧은 경우: 설정치를 높입니다.
핀치구멍의 위치가 기준치 (c) 보다 긴 경우: 설정치를 내립니다.

3. 시작키를 누르고 설정치를 확인합니다.
<기준치 (c) >
센치사양: 13mm, 인치사양: 9.5mm

パンチ位置搬送調整

1. メンテナンスモード U246 をセットし、Finisher、Punch Feed を選択する。
2. 設定値を調整する。
パンチ穴の位置が基準値 (c) より短い場合: 設定値を上げる。
パンチ穴の位置が基準値 (c) より長い場合: 設定値を下げる。

3. スタートキーを押し、設定値を確定する。
<基準値 (c) >
センチ仕様: 13mm、インチ仕様: 9.5mm



Centering the hole punch position

1. Enter the maintenance mode U246, select Finisher and Punch Width.
2. Adjust the values.
If the punch hole is too close to the front of the machine: Decrease the setting value.
If the punch hole is too close to the rear of the machine: Increase the setting value.

3. Press the Start key to confirm the setting value.

<Reference value>

Metric specification: $d = 80 \text{ mm} \pm 0.5$, $e = 40 \text{ mm} \pm 2$

Inch specification: $d = 2.75 \text{ inch} \pm 0.5$, $e = 1.375 \text{ inch} \pm 2$,
 $f = 4.25 \text{ inch} \pm 0.5$

Centrage de la position de perforation

1. Passer en mode maintenance U246, sélectionner Finisher et Punch Width.
2. Régler les valeurs.
Si la perforation est trop proche de l'avant de la machine: Diminuez la valeur de réglage.
Si la perforation est trop proche de l'arrière de la machine: Augmentez la valeur de réglage.

3. Appuyer sur la touche de Start pour confirmer la valeur de réglage.

<Valeur de référence>

Spécifications métriques: $d = 80 \text{ mm} \pm 0.5$, $e = 40 \text{ mm} \pm 2$

Spécifications en pouces: $d = 2,75 \text{ pouces} \pm 0,5$, $e = 1,375 \text{ pouces} \pm 2$,
 $f = 4.25 \text{ pouces} \pm 0,5$

Centrado de la posición de perforación

1. Entre en el modo de mantenimiento U246, seleccione Finisher y Punch Width.
2. Ajuste los valores.
Si la perforación se encuentra demasiado cerca del frente de la máquina: Reduzca el valor de configuración.
Si la perforación se encuentra demasiado cerca de la parte trasera de la máquina: Aumente el valor de configuración.

3. Pulse la tecla de Start para confirmar el valor de configuración.

<Valor de referencia>

Sistema métrico: $d = 80 \text{ mm} \pm 0,5$, $e = 40 \text{ mm} \pm 2$

En pulgadas: $d = 2,75 \text{ pulgada} \pm 0,5$, $e = 1,375 \text{ pulgada} \pm 2$,
 $f = 4.25 \pm 0,5 \text{ pulgada}$

Zentrieren der Stanzlochposition

1. Schalten Sie in den Wartungsmodus U246, wählen Sie Finisher und Punch Width.
2. Die Werte einstellen.
Falls die Lochung zu nah an der Gerätefront liegt: Den Einstellwert verringern.
Falls die Lochung zu weit weg von der Gerätefront liegt: Den Einstellwert erhöhen.

3. Den Einstellwert durch Drücken der Start-Taste bestätigen.

<Bezugswert>

Metrischer Abstand: $d = 80 \text{ mm} \pm 0,5$; $e = 40 \text{ mm} \pm 2$

Abstand in Zoll: $d = 2,75 \text{ Zoll} \pm 0,5$, $e = 1,375 \text{ Zoll} \pm 2$,
 $f = 4.25 \text{ Zoll} \pm 0,5$

Centrata della posizione dei fori di perforazione

1. Entrare in modalità manutenzione U246, selezionare Finisher e Punch Width.
2. Regolare i valori.
Se la posizione dei fori di perforazione è troppo vicina alla parte anteriore della macchina: Diminuire il valore dell'impostazione.
Se la posizione dei fori di perforazione è troppo vicina alla parte posteriore della macchina: Aumentare il valore dell'impostazione.

3. Premere il tasto di Start per confermare il valore dell'impostazione.

<Valore di riferimento>

Specificazione in unità metrica: $d = 80 \text{ mm} \pm 0,5$, $e = 40 \text{ mm} \pm 2$

Specificazione in pollici: $d = 2,75 \text{ pollici} \pm 0,5$, $e = 1,375 \text{ pollici} \pm 2$,
 $f = 4.25 \text{ pollici} \pm 0,5$

打孔位置中心调节

1. 设置维护模式 U246, 选择 Finisher、Punch Width。
2. 调整设定值。
打孔位置向机器前部偏移时: 调低设定值。
打孔位置向机器后部偏移时: 调高设定值。

3. 按 Start 键, 以确定设定值。

<基准值>

公制规格: $d=80\text{mm} \pm 0.5$ 、 $e=40\text{mm} \pm 2$

英制规格: $d=2.75\text{inch} \pm 0.5$ 、 $e=1.375\text{inch} \pm 2$ 、 $f=4.25\text{inch} \pm 0.5$

펀치위치 센터조정

1. 메인터넌스 모드 U246 를 세트하고 Finisher, Punch Width 를 선택합니다.
2. 설정치를 조정합니다.
펀치구멍이 기기 앞측으로 벗어난 경우: 설정치를 내립니다.
펀치구멍의 위치가 기기 뒷측으로 벗어난 경우: 설정치를 높입니다.

3. 시작키를 누르고 설정치를 확인합니다.

<기준치>

센치 사양: $d=80\text{mm} \pm 0.5$, $e=40\text{mm} \pm 2$

인치 사양: $d=2.75\text{inch} \pm 0.5$, $e=1.375\text{inch} \pm 2$, $f=4.25\text{inch} \pm 0.5$

パンチ位置センター調整

1. メンテナンスモード U246 をセットし、Finisher、Punch Width を選択する。
2. 設定値を調整する。
パンチ穴の位置が機械前側にずれている場合: 設定値を下げる。
パンチ穴の位置が機械後側にずれている場合: 設定値を上げる。

3. スタートキーを押し、設定値を確定する。

<基準値>

センチ仕様: $d=80\text{mm} \pm 0.5$ 、 $e=40\text{mm} \pm 2$

インチ仕様: $d=2.75\text{inch} \pm 0.5$ 、 $e=1.375\text{inch} \pm 2$ 、 $f=4.25\text{inch} \pm 0.5$

NOTICE

This accessory is for use only with the following Applicant's Listed Machine.
Refer to the supplied guide to install the accessory in the field.
Machine: DF-770, DF-790

AVIS

Cet accessoire est utilisable uniquement avec le copieur figurant dans la liste du demandeur suivant.
Se reporter au guide fourni pour installer l'accessoire dans le champ.
Modèle: DF-770, DF-790

AVISO

Este accesorio es sólo para usar en las siguientes fotocopiadoras de la lista de solicitantes.
Consulte las instrucciones para la instalación de accesorios en el lugar del cliente.
Modelo: DF-770, DF-790

HINWEIS

Dieses Zubehör ist nur für den Einsatz mit der folgenden Antragstellerlisten-Kopiermaschine vorgesehen.
Installieren Sie das Zubehör gemäß der mitgelieferten Anleitung im Feld.
Modell: DF-770, DF-790

NOTIFICA

Questo accessorio deve essere usato solo con le seguenti fotocopiatrici nella lista dell'applicante.
Consultare la guida fornita in dotazione per il montaggio in campo dell'accessorio.
Modello: DF-770, DF-790

注意

本产品适用于以下选购件。
安装时，请参照附带的说明书。
式样：DF-770, DF-790


주의

본 제품은 이하의 기종에 적용됩니다.
설치할 때에는 동봉된 안내문을 참조해 주십시오.
기종: DF-770, DF-790

注意

本製品は、以下の機種に適用します。
設置する際は、同梱の手順書を参照してください。
機種: DF-770, DF-790

INSTALLATION GUIDE FOR INNER JOB SEPARATOR



ENG Precautions

The illustrations of the machine in the Installation Guide are for color MFP.

FR Précautions

L'appareil représenté dans les illustrations du présent guide d'installation est le MFP couleur.

ES Precauciones

Las ilustraciones de la máquina que aparecen en la Guía de instalación corresponden a una MFP en color.

DE Vorsichtsmaßnahmen

Die Abbildungen der Maschine in der Installationsanleitung gelten für den Farb-MFP.

IT Precauzioni

Le illustrazioni della macchina nella guida di installazione sono per colore MFP.

CN 注意事项





安装手册中记载的机器主机的插图是彩色机。







KO 주의사항

설치순서에 기재되어 있는 기기본체 일러스트는 컬러기입니다.



JP 注意事項

設置手順書に記載している機械本体のイラストはカラー機です。









9








10




11







17





18





19





20










21





22





29



30

- Ⓔ **ENG** Enter maintenance mode U211 "Set Enhance connection", and select Inner Job Separator.
- Ⓔ **FR** Passer en mode maintenance U211, cliquer sur "Set Enhance connection" et sélectionner Inner Job Separator.
- Ⓔ **ES** Entre en el modo de mantenimiento U211 "Set Enhance connection" y seleccione Inner Job Separator.
- Ⓔ **DE** Schalten Sie in den Wartungsmodus U211 „Set Enhance connection“ und wählen Sie Inner Job Separator.
- Ⓔ **IT** Introdurre la modalità manutenzione U211 "Set Enhance connection", e selezionare Inner Job Separator.
- Ⓔ **CN** 进入维护模式，在U211 Set Enhance connection 中选择Inner Job Separator。
- Ⓔ **KO** 메인テナンス 모드에 들어가 U211 Set Enhance connection에서 Inner Job Separator를 선택합니다.
- Ⓔ **JP** メンテナンスモードに入り、U211エンハンス接続設定にてInner Job Separatorを選択する。

**INSTALLATION GUIDE FOR
100-SHEETS INNER JOB
SEPARATOR**

English Notes for installing the JS-732

Check the firmware version of the machine.
If the version is older than the following , upgrade the firmware to the latest version.

Full-color machines(30/30.35/35.45/45.55/50ppm)
MAIN: 2LC_2F00.003.121, ENGINE: 2LC_1000.006.072, MMI: 2LC_7000.003.120
Monochrome machines(35.45.55ppm)
MAIN: 2LH_2F00.003.121, ENGINE: 2LF_1000.003.072, MMI: 2LC_7000.003.120

Français Remarques pour l'installation de JS-732

Vérifiez la version du micrologiciel de la machine.
Si la version est plus ancienne que celle indiquée ci-après, effectuez la mise à niveau du micrologiciel à la version la plus récente.

Machines entièrement en couleurs(30/30.35/35.45/45.55/50ppm)
MAIN: 2LC_2F00.003.121, ENGINE: 2LC_1000.006.072, MMI: 2LC_7000.003.120
Machines monochromes(35/45/55ppm)
MAIN: 2LH_2F00.003.121, ENGINE: 2LF_1000.003.072, MMI: 2LC_7000.003.120

Español Notas sobre la instalación del JS-732

Compruebe la versión del firmware de la máquina.
Si la versión es anterior a la siguiente, actualice el firmware a la versión más reciente.

Maquinas a todo color(30/30.35/35.45/45.55/50ppm)
MAIN: 2LC_2F00.003.121, ENGINE: 2LC_1000.006.072, MMI: 2LC_7000.003.120
Maquinas monocromaticas(35/45/55ppm)
MAIN: 2LH_2F00.003.121, ENGINE: 2LF_1000.003.072, MMI: 2LC_7000.003.120

Deutsch Hinweise zur Installation des JS-732

Überprüfen Sie die Firmware-Version des Geräts.
Falls die Version älter als die folgende ist, sollten Sie die Firmware auf die neuste Version aktualisieren.

Farbgeräte(30/30.35/35.45/45.55/50ppm)
MAIN: 2LC_2F00.003.121, ENGINE: 2LC_1000.006.072, MMI: 2LC_7000.003.120
Schwarz/weiß-Geräte(35.45.55ppm)
MAIN: 2LH_2F00.003.121, ENGINE: 2LF_1000.003.072, MMI: 2LC_7000.003.120

Italiano Note per l'installazione di JS-732

Controllare la versione del firmware del sistema.
Se la versione è precedente a quella indicata qui in basso, eseguire l'aggiornamento del firmware alla versione più recente.

dispositivi a colori(30/30.35/35.45/45.55/50ppm)
MAIN: 2LC_2F00.003.121, ENGINE: 2LC_1000.006.072, MMI: 2LC_7000.003.120
solo per i dispositivi(35.45.55ppm)
MAIN: 2LH_2F00.003.121, ENGINE: 2LF_1000.003.072, MMI: 2LC_7000.003.120

简体中文 安装 JS-732 时的注意事项

请确认本机的固件版本。
固件版本早于以下版本时，请升级至最新版本。

彩色机器 (30/30.35/35.45/45.55/50 张机型)
MAIN: 2LC_2F00.003.121, ENGINE: 2LC_1000.006.072, MMI: 2LC_7000.003.120
黑白机器 (35.45.55 张机型)
MAIN: 2LH_2F00.003.121, ENGINE: 2LF_1000.003.072, MMI: 2LC_7000.003.120

한국어 JS-732 설치 시의 주의


기기 본체의 펌웨어를 확인하고 하기의 버전보다 구 버전의 경우에는 최신 펌웨어로 버전 업그레이드를 해 주시기 바랍니다 .

컬러기 (30/30.35/35.45/45.55/50 매기)
MAIN: 2LC_2F00.003.121, ENGINE: 2LC_1000.006.072, MMI: 2LC_7000.003.120
흑백기 (35.45.55 매기)
MAIN: 2LH_2F00.003.121, ENGINE: 2LF_1000.003.072, MMI: 2LC_7000.003.120



日本語 JS-732 設置時の注意

機械本体のファームウェアを確認してください。
下記バージョンより古い場合は、最新ファームウェアにバージョンアップしてください。

カラー機 (30/30.35/35.45/45.55/50 枚機)
MAIN: 2LC_2L00.003.121, ENGINE: 2LC_1000.006.072, MMI: 2LC_7000.003.120
モノクロ機 (35.45.55 枚機)
MAIN: 2LH_2L00.003.121, ENGINE: 2LF_1000.003.072, MMI: 2LC_7000.003.120



<p>English</p> <p>Supplied parts</p> <p>A. Scanner bottom cover 1</p> <p>B. Drive unit 1</p> <p>C. Inner tray 1</p> <p>D. Eject unit cover 1</p>	<p>E. Eject unit 1</p> <p>F. Stopper paper 1</p> <p>G. M4 x 8 screw 1</p> <p>H. S Tite screw M3 x 8 1</p> <p>I. P Tite screw M3 x 8 2</p>	<p>Be sure to remove any tape and/or cushioning material from supplied parts.</p>
<p>Français</p> <p>Pièces fournies</p> <p>A. Couvercle inférieur du scanner 1</p> <p>B. Unité d'entraînement 1</p> <p>C. Bac intérieur 1</p> <p>D. Couvercle de l'unité d'éjection 1</p>	<p>E. Unité d'éjection 1</p> <p>F. Butée de papier 1</p> <p>G. Vis M4 x 8 1</p> <p>H. Vis S Tite M3 x 8 1</p> <p>I. Vis P Tite M3 x 8 2</p>	<p>Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.</p>
<p>Español</p> <p>Partes suministradas</p> <p>A. Cubierta inferior del escáner 1</p> <p>B. Unidad de accionamiento 1</p> <p>C. Bandeja interna 1</p> <p>D. Cubierta de la unidad de salida 1</p>	<p>E. Unidad de salida 1</p> <p>F. Tope de papel 1</p> <p>G. Tornillo M4 x 8 1</p> <p>H. Tornillo S Tite M3 x 8 1</p> <p>I. Tornillo P Tite M3 x 8 2</p>	<p>Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.</p>
<p>Deutsch</p> <p>Gelieferte Teile</p> <p>A. Untere Abdeckung des Scanners 1</p> <p>B. Antriebseinheit 1</p> <p>C. Innere Ablage 1</p> <p>D. Abdeckung der Ausgabereinheit 1</p>	<p>E. Ausgabereinheit 1</p> <p>F. Papieranschlag 1</p> <p>G. Schraube M4 x 8 1</p> <p>H. S-Tite-Schraube M3 x 8 1</p> <p>I. P-Tite-Schraube M3 x 8 2</p>	<p>Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.</p>
<p>Italiano</p> <p>Parti di forniture</p> <p>A. Coperchio inferiore dello scanner 1</p> <p>B. Unità guida 1</p> <p>C. Vassoio interno 1</p> <p>D. Coperchio dell'unità di espulsione 1</p>	<p>E. Unità di espulsione 1</p> <p>F. Fermo carta 1</p> <p>G. Vite M4 x 8 1</p> <p>H. Vite S Tite M3 x 8 1</p> <p>I. Vite P Tite M3 x 8 2</p>	<p>Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.</p>
<p>简体中文</p> <p>附属品</p> <p>A. 扫描仪底部盖板 1</p> <p>B. 驱动单元 1</p> <p>C. 内部托盘 1</p> <p>D. 出纸单元盖板 1</p>	<p>E. 出纸单元 1</p> <p>F. 纸张挡板 1</p> <p>G. M4x8 螺丝 1</p> <p>H. 紧固型 S 螺丝 M3x8 1</p> <p>I. 紧固型 P 螺丝 M3x8 2</p>	<p>如果附属品上带有固定胶带, 缓冲材料时务必揭下。</p>
<p>한국어</p> <p>동봉품</p> <p>A. 스캐너 밑커버 1</p> <p>B. 구동 유닛 1</p> <p>C. 내부트레이 1</p> <p>D. 배출 유닛 커버 1</p>	<p>E. 배출 유닛 1</p> <p>F. 스톱퍼 용지 1</p> <p>G. 나사 M4x8 1</p> <p>H. 나사 M3x8S 타이트 1</p> <p>I. 나사 M3x8P 타이트 2</p>	<p>동봉품에 고정 테이프, 완충재가 붙어 있는 경우에는 반드시 제거할 것.</p>
<p>日本語</p> <p>同梱品</p> <p>A. スキャナー底カバー 1</p> <p>B. 駆動ユニット 1</p> <p>C. 内部トレイ 1</p> <p>D. 排出ユニットカバー 1</p>	<p>E. 排出ユニット 1</p> <p>F. ペーパーストップパー 1</p> <p>G. ビス M4x8 1</p> <p>H. ビス M3x8S タイト 1</p> <p>I. ビス M3x8P タイト 2</p>	<p>同梱品に固定テープ、緩衝材がついている場合は、必ず取り外すこと。</p>



Before installing the JS-732, make sure that the MFP's main power switch is turned off and that its power cord is unplugged from the power outlet.

Procedure

1. Remove the 2 screws (2) in the left ISU cover (1).

2. Push in the top and bottom hooks (3) and open the interface cover (4).

Avant d'installer l'JS-732, s'assurer que l'interrupteur d'alimentation principal du MFP est coupé et que le cordon d'alimentation est débranché de la prise secteur.

Procédure

1. Déposer les 2 vis (2) du couvercle gauche de l'ISU (1).

2. Appuyer sur les crochets haut et bas (3) et ouvrir le couvercle de l'interface (4).

Antes de instalar el JS-732, asegúrese de que el interruptor principal de la alimentación de la MFP esté desconectado y que su cable de alimentación esté desenchufado de la toma de corriente.

Procedimiento

1. Quite los 2 tornillos (2) de la cubierta ISU izquierda (1).

2. Presione los ganchos superior e inferior (3) y abra la cubierta de la interfaz (4).

Vor dem Einbau des JS-732 muss der MFP-Hauptschalter ausgeschaltet und das Netzkabel von der Steckdose abgezogen sein.

Verfahren

1. Entfernen Sie die 2 Schrauben (2) der linken ISU-Abdeckung (1).

2. Drücken Sie die Haken (3) oben und unten ein und öffnen Sie die Schnittstellenabdeckung (4).

Prima di installare l'unità JS-732, assicurarsi che l'interruttore principale dell'MFP sia spento e che il suo cavo di alimentazione sia scollegato presa di corrente.

Procedura

1. Rimuovere le 2 viti (2) sul coperchio ISU sinistro (1).

2. Spingere i ganci (3) superiore e inferiore ed aprire la copertura di interfaccia (4).

安装 JS-732 时, 请务必将 MFP 主机电源关闭, 关拔下电源插头再进行安装作业。

安装步骤

1. 卸下 ISU 左盖板 (1) 的 2 颗螺丝 (2)。

2. 按压上下的卡扣 (3) 以打开接口盖板 (4)。

JS-732 을 부착할 때에는 반드시 MFP 본체의 주 전원 스위치를 OFF 로 하고 전원 플러그를 제거하고 작업을 할 것 .

설치순서

1. ISU 좌측 커버 (1) 의 나사 (2) 2 개를 제거합니다 .


2. 상하의 후크 (3) 를 눌러 인터페이스 커버 (4) 를 엽니다 .

JS-732 を取り付ける際は、必ず MFP 本体の主電源スイッチを OFF にし、電源プラグを外して作業をおこなうこと。


取付手順

1. ISU 左カバー (1) のビス (2) 2 本を取り外す。


2. 上下のフック (3) を押してインターフェイスカバー (4) を開く。



3. Remove the 2 screws (5) inside the interface cover (4) and remove the left scanner cover (6).



4. Open the front cover (7) on the MFP.
5. Pull out the paper conveyor cover (8).
6. If the operation panel (9) is lowered, raise it to the top position.



7. Remove the screw (11) from the fan cover (10).
8. Remove the screw (12) and pull the upper right cover (13) outwards slightly while removing the front right cover (14). Remove the right front cover (14) by pulling the part in the dotted circle outwards.

3. Déposer les 2 vis (5) à l'intérieur du couvercle de l'interface (4) et déposer le couvercle de scanner gauche (6).

4. Ouvrir le capot avant (7) sur le MFP.
5. Sortir le couvercle du transporteur du papier (8).
6. Si le panneau de commande (9) est abaissé, le relever dans sa position maximum.

7. Déposer la vis (11) du couvercle du ventilateur (10).
8. Déposer la vis (12) et tirer légèrement le couvercle supérieur droit (13) vers l'extérieur tout en déposant le couvercle avant droit (14). Déposer le couvercle avant droit (14) en tirant la partie dans le cercle en pointillés.

3. Quite los 2 tornillos (5) de interior de la cubierta de la interfaz (4) y quite la cubierta izquierda del escáner (6).

4. Abra la cubierta frontal (7) en la MFP.
5. Extraiga la cubierta de la unidad de transporte de papel (8).
6. Si el panel de trabajo (9) está bajo, levántelo hasta la posición superior.

7. Quite el tornillo (11) de la cubierta del ventilador (10).
8. Quite el tornillo (12) y saque la cubierta superior derecha (13) ligeramente mientras quita la cubierta frontal derecha (14). Quite la cubierta frontal derecha (14) tirando hacia afuera de la parte en el círculo punteado.

3. Entfernen Sie die 2 Schrauben (5) im Inneren der Schnittstellenabdeckung (4) und entfernen Sie die linke Scannerabdeckung (6).

4. Öffnen Sie die vordere Abdeckung (7) des MFP.
5. Entfernen Sie die Abdeckung des Papiertransports (8).
6. Falls das Bedienfeld (9) abgesenkt ist, bringen Sie es in die oberste Position.

7. Entfernen Sie die Schraube (11) der Lüfterabdeckung (10).
8. Entfernen Sie die Schraube (12) und ziehen Sie die obere rechte Abdeckung (13) vorsichtig nach außen, während Sie gleichzeitig die vordere rechte Abdeckung (14) entfernen. Entfernen Sie die rechte vordere Abdeckung (14), indem Sie das Teil, das in der Zeichnung mit einem gepunkteten Kreis markiert ist, nach außen ziehen.

3. Rimuovere le 2 viti (5) all'interno della copertura di interfaccia (4) e quindi rimuovere il coperchio sinistro dello scanner (6).

4. Aprire il pannello anteriore (7) sull'MFP.
5. Estrarre il coperchio di trasporto carta (8).
6. Se il pannello operativo (9) è abbassato, sollevarlo alla posizione in alto.

7. Rimuovere la vite (11) dal coperchio ventola (10).
8. Rimuovere la vite (12) e tirare il coperchio superiore destro (13) leggermente verso l'esterno mentre si rimuove il coperchio anteriore destro (14). Rimuovere il coperchio anteriore destro (14) tirando verso l'esterno la parte nel cerchio tratteggiato.

3. 卸下接口盖板 (4) 内侧的 2 颗螺丝 (5), 拆下扫描仪左盖板 (6)。

4. 打开 MFP 主机的前盖板 (7)。
5. 拉出输纸盖板 (8)。
6. 操作面板 (9) 处于低位时, 将其升到最高位置。

7. 卸下风扇盖板 (10) 的 1 颗螺丝 (11)。
8. 卸下 1 颗螺丝 (12), 稍稍拉出右上部盖板 (13) 的同时, 拆下右前部盖板 (14)。通过向外拉虚线圈出的部分卸下右前盖板 (14)。

3. 인터페이스 커버 (4) 안쪽의 나사 (5) 2 개를 제거하고 스캐너 좌측커버 (6) 를 제거합니다.


4. MFP 본체의 전면커버 (7) 를 엽니다.
5.搬送커버 (8) 를 당겨 냅니다.
6. 조작판넬 (9) 이 내려가 있는 경우에는 위로 올립니다.

7. 팬커버 (10) 의 나사 (11) 1 개를 제거합니다.
8. 나사 (12) 1 개를 제거하고 오른쪽 상커버 (13) 를 조금 당기면서 오른쪽 전면커버 (14) 를 제거합니다. 점선 원으로 표시된 부분을 바깥 방향으로 당겨서 오른쪽 전면커버 (14) 를 제거합니다.


3. インターフェイスカバー (4) 内側のビス (5) 2 本を外し、スキャナー左カバー (6) を取り外す。

4. MFP 本体の前カバー (7) を開く。
5.搬送カバー (8) を引き出す。
6. 操作パネル (9) が下がっている場合は上位位置に上げる。


7. ファンカバー (10) のビス (11) 1 本を外す。
8. ビス (12) 1 本を外し、右上カバー (13) を少し外に引っ張りながら右前カバー (14) を取り外す。右前カバー (14) は、破線部を外側に引っ張るようにして外す。



9. Remove the screw (15) and remove the operation panel lower cover (16).



10. Remove the eject cover (17).
* Pull the lower front side to the left before removing the cover.



11. Remove the 2 M4 × 8 screws (black) (18) and remove the rear tray cover (19) and scanner bottom cover (20).

9. Déposer la vis (15) et déposer le couvercle inférieur du panneau de commande (16).

10. Déposer le capot d'éjection (17).
* Tirer le côté avant inférieur sur la gauche avant de déposer le capot.

11. Déposer les 2 vis M4 × 8 (noire) (18) et déposer le couvercle du support arrière (19) et le couvercle inférieur du scanner (20).

9. Quite el tornillo (15) y quite la cubierta inferior del panel de trabajo (16).

10. Quite la cubierta de expulsión (17).
* Tire del lado frontal inferior hacia la izquierda antes de quitar la cubierta.

11. Quite los 2 tornillos M4 × 8 (negro) (18) y quite la cubierta izquierda de la bandeja (19) y la cubierta inferior del escáner (20).

9. Entfernen Sie die Schraube (15) und entfernen Sie die untere Abdeckung des Bedienfelds (16).

10. Entfernen Sie die Abdeckung der Ausgabeeinheit (17).
* Bevor Sie die Abdeckung entfernen, ziehen Sie die untere Vorderseite nach links.

11. Entfernen Sie die 2 M4 x 8 Schrauben (schwarz) (18) und entfernen Sie die Abdeckung des hinteren Fachs (19) und die untere Abdeckung des Scanners (20).

9. Rimuovere la vite (15) e rimuovere il coperchio inferiore del pannello operativo (16).

10. Rimuovere il coperchio di espulsione carta (17).
* Tirare il lato anteriore in basso a sinistra prima di rimuovere il coperchio.

11. Rimuovere le 2 viti M4 × 8 (nera) (18) e quindi rimuovere il coperchio posteriore del vassoio (19) e il coperchio inferiore dello scanner (20).

9. 卸下螺丝 (15), 然后卸下操作面板下部盖板 (16)。

10. 拆下排纸盖板 (17)。
※ 将盖板前下部向左侧拉出以拆卸。

11. 卸下 2 颗螺丝 M4×8 (黑) (18), 拆下托盘后部盖板 (19) 以及扫描仪底部盖板 (20)。

9. 나사 (15) 를 풀고 조작판넬의 하단 커버 (16) 를 제거합니다 .


10. 배출커버 (17) 를 제거합니다 .
※ 전면 아래쪽을 좌측으로 당겨서 제거합니다 .

11. 나사 M4×8 (흑) (18) 2 개를 제거하고 트레이 뒷커버 (19) 및 스캐너 밑커버 (20) 를 제거합니다 .

9. ビス (15) 1 本を外し、操作パネル下カバー (16) を取り外す。

10. 排出カバー (17) を取り外す。
※ 前下側を左側に引いてから取り外す。

11. ビス M4×8 (黒) (18) 2 本を外し、トレイ後カバー (19) およびスキャナー底カバー (20) を取り外す。



12. Insert the hook (21) on the underside of the drive unit (B) into the respective positioning hole (22) in the back plate, using the location of the notch on the front as a guide. Then secure the drive unit using the 2 M4 × 8 screws (black) (18) removed in step 11.

NOTICE

When installing the drive unit (B), take care not to rub it against the ribs on the top of the MFP tray.

Hold the connector (23) out of the way so that it does not become trapped.

12. Insérer le crochet (21) sous l'unité d'entraînement (B) dans le trou de positionnement approprié (22) sur la plaque arrière, en prenant comme guide l'encoche à l'avant. Puis fixer l'unité d'entraînement avec les 2 vis M4 × 8 (noires) (18) retirées au point 11.

AVIS

À l'installation de l'unité d'entraînement (B), veiller à ne pas le frotter contre les nervures sur le haut du bac MFP.

Écarter le connecteur (23) de sorte qu'il ne soit pas coincé.

12. Inserte el gancho (21) del lado inferior de la unidad de accionamiento (B) en el orificio de posición respectivo (22) de la placa posterior, con la ubicación de la muesca en el frente como guía. Después, fije la unidad de accionamiento con los 2 tornillos M4 × 8 (negros) (18) quitados en el paso 11.

AVISO

Durante la instalación de la unidad de accionamiento (B), tenga cuidado de no rozar las nervaduras de la parte superior de la bandeja de la MFP. Mantenga el conector (23) alejado para no atraparlo.

12. Setzen Sie die Haken (21) auf der Unterseite der Antriebseinheit (B) in die entsprechenden Aufnahmen (22) der Rückwand. Benutzen Sie die Aussparungen auf der Vorderseite als Orientierung. Befestigen Sie die Antriebseinheit mit den 2 M4 × 8 Schrauben (schwarz) (18), die Sie in Schritt 11 gelöst haben.

HINWEIS

Beim Einsetzen der Antriebseinheit (B) achten Sie darauf, dass Sie diese nicht an den Nasen oben in der Ablage des MFP scheuern. Führen Sie den Stecker (23) so, dass dieser nicht eingeklemmt werden kann.

12. Inserire il gancio (21) sul lato inferiore dell'unità guida (B) nel rispettivo foro di posizionamento (22) sulla piastra posteriore, usando la posizione dell'intaglio sulla parte frontale come guida. Quindi fissare l'unità guida usando le 2 viti M4 × 8 (nere) (18) rimosse nel passo 11.

NOTIFICA

Quando si installa l'unità guida (B), fare attenzione a non sfregarla contro i rilievi sulla parte superiore del vassoio MFP.

Mantenere il connettore (23) all'esterno in modo che esso non rimanga intrappolato.

12. 以前部の槽口位置を参考、将驱动单元 (B) 下部的卡扣 (21) 插入背板上各自的定位孔 (22)。然后使用步骤 11 中卸下的 2 颗螺丝 M4 × 8 (黑) (18) 固定驱动单元。

注意

安装驱动单元 (B) 时, 请小心勿触碰 MFP 托盘顶部的肋片。

避开接插件 (23) 以免其被卡住。

12. 전면의 노치 위치를 기준으로 활용하여 구동 유닛 (B) 아래쪽에 있는 후크 (21) 를 후면판의 해당 위치 고정 구멍 (22) 에 삽입합니다 . 그런 다음 단계 11 에서 제거한 M4 × 8 나사 (흑) (18) 2 개로 구동 유닛을 고정합니다 .


주의

구동 유닛 (B) 를 설치할 때 이 장치가 MFP 트레이 상단의 리브 부위에 닿아서 스키지 않도록 주의하십시오 . 막히지 않도록 커넥터 (23) 를 잡습니다 .

12. 駆動ユニット (B) 下側のフック (21) を前側の切り欠き位置を目安に後側板の位置決め穴 (22) に入れ、手順 11 のビス M4×8(黒) (18) 2 本で固定する。

注意

駆動ユニット (B) を取り付ける時は、本体トレイ上のリブをこすらないように作業をすること。コネクタ (23) を挟まないように外に出しておくこと。



13. Plug the connector (23) from the drive unit (B) into the MFP.

13. Bancher le connecteur (23) de l'unité d'entraînement (B) sur le MFP.

13. Enchufe el conector (23) de la unidad de accionamiento (B) en la MFP.


13. Stecken Sie den Stecker (23) in die Antriebseinheit (B) des MFP.

13. Inserire il connettore (23) dall'unità guida (B) nell'MFP.

13. 将从驱动单元 (B) 引出的接插件 (23) 插入 MFP。

13. 구동 유닛 (B) 의 커넥터 (23) 를 MFP 에 연결합니다 .

13. 駆動ユニット (B) からのコネクタ (23) を MFP 本体に接続する。



14. Insert the projection (24) on the back of the eject unit (E) into the hole (25) in the drive unit (B) and insert the projection on the front (26) into the hole (27) in the MFP frame to attach the eject unit (E).

Push the eject unit (E) to the right and fit the hook (28) in so that it clicks into place.

NOTICE

When installing the eject unit, take care not to dislodge the paper eject actuator (29).

After installing the unit, check the operation of the actuator.

14. Insérer la projection (24) à l'arrière de l'unité d'éjection (E) dans le trou (25) de l'unité d'entraînement (B) et insérer la projection à l'avant (26) dans le trou (27) du châssis de MFP pour attacher l'unité d'éjection (E). Pousser l'unité d'éjection (E) vers la droite et emboîter le crochet (28) jusqu'au déclic.

AVIS

À l'installation de l'unité d'éjection, veiller à ne pas déplacer l'actionneur d'éjection du papier (29). Après avoir installé l'unité, vérifier le bon fonctionnement de l'actionneur.

14. Inserte el saliente (24) de la parte posterior de la unidad de salida (E) en el orificio (25) de la unidad de accionamiento (B) e inserte el saliente del frente (26) en el orificio (27) de la carcasa de la MFP para fijar la unidad de salida (E). Presione la unidad de salida (E) hacia la derecha y encaje el gancho (28) hasta que escuche un clic.

AVISO

Durante la instalación de la unidad de salida, tenga cuidado de no desplazar el actuador de expulsión de papel (29). Después de instalar la unidad, compruebe el funcionamiento del actuador.

14. Setzen Sie die Nase (24) an der Rückseite der Ausgabeeinheit (E) in das Loch (25) der Antriebseinheit (B). Dann setzen Sie die Nase (26) vorne in das Loch (27) des MFP-Rahmens, um die Ausgabeeinheit (E) anzubringen. Schieben Sie die Ausgabeeinheit (E) nach rechts und drücken Sie auf die Haken (28), damit diese einrasten.

HINWEIS

Achten Sie beim Einsetzen der Ausgabeeinheit darauf, dass der Papierausgabesensor (29) in der korrekten Position verbleibt. Nachdem die Ausgabeeinheit installiert ist, prüfen Sie die korrekte Arbeitsweise des Sensors.

14. Inserire la parte sporgente (24) sul retro dell'unità di espulsione (E) nel foro (25) dell'unità guida (B), e inserire la parte sporgente sul lato anteriore (26) nel foro (27) del telaio dell'MFP per fissare l'unità di espulsione (E). Spingere l'unità di espulsione (E) alla destra e inserire il gancio (28) in modo che esso scatti in posizione.

NOTIFICA

Quando si installa l'unità di espulsione, fare attenzione a non rimuovere l'attuatore (29) di espulsione carta. Dopo l'installazione dell'unità, controllare il funzionamento dell'attuatore.

14. 通过将出纸单元 (E) 背部的突出部分 (24) 插入驱动单元 (B) 中的孔 (25) 中, 并将前部的突出部分 (26) 插入 MFP 框架中的孔 (27) 中来安装出纸单元 (E)。

向右按出纸单元 (E) 并扣好卡扣 (28) 以使其固定到位。

注意

安装出纸单元时, 请小心勿使出纸致动器 (29) 外露。

安装好该单元后, 请检查致动器的操作。

14. 배출 유닛 (E) 후면의 프로젝션 (24) 을 구동 유닛 (B) 의 구멍 (25) 에 삽입하고 전면의 프로젝션 (26) 을 MFP 프레임의 구멍 (27) 에 삽입하여 배출 유닛 (E) 를 부착합니다. 배출 유닛 (E) 를 오른쪽으로 밀고 제자리에 장착되도록 후크 (28) 를 맞춥니다.

주의

배출 유닛을 설치할 때 용지 배출 액추에이터 (29) 를 제거하지 않도록 주의하십시오.

유닛을 설치한 후 액추에이터의 작동을 확인하십시오.


14. 排出ユニット (E) 後側の突起 (24) を駆動ユニット (B) の穴 (25) に入れ, 前側の突起 (26) を本体フレームの穴 (27) に入れて排出ユニット (E) を取り付ける。

排出ユニット (E) を右側に押し, フック (28) がカチッと音がするまではめ込むこと。

注意

排出ユニットを取り付ける時は, 排出のアクチュエーター (29) を外さないように作業をする。

取付後, アクチュエーターの動作確認を行うこと。



15. Insert the 2 hooks on the scanner bottom cover (A) into the holes and secure the cover with the M4 x 8 screw (G).

NOTICE

Take particular care to check that the hooks on the rear are securely engaged before tightening the screws.

15. Insérer les 2 crochets sur le couvercle inférieur du scanner (A) dans les trous et fixer le couvercle avec une vis M4 x 8 (G).

AVIS

S'assurer tout particulièrement que les crochets à l'arrière sont bien engagés avant de serrer les vis.

15. Inserte los 2 ganchos de la cubierta inferior del escáner (A) en los orificios y fije la cubierta con el tornillo M4 x 8 (G).

AVISO

Antes de apretar los tornillos, tenga especial cuidado de comprobar si los ganchos en la parte posterior están enganchados de forma segura.

15. Setzen Sie die 2 Schrauben in die untere Abdeckung (A) des Scanners in die entsprechenden Löcher und befestigen Sie die Abdeckung mit der M4 x 8 Schraube (G).

HINWEIS

Prüfen Sie sorgfältig, ob die Haken auf der Rückseite richtig eingerastet sind, bevor Sie die Schrauben festziehen.

15. Inserire i 2 ganci sul coperchio inferiore dello scanner (A) nei fori e fissare il coperchio con le viti M4 x 8 (G).

Fare particolare attenzione per controllare che i ganci sul retro siano agganciati in modo sicuro prima di stringere le viti.

15. 将扫描仪底部盖板 (A) 上的 2 个卡扣插入相应的孔中, 然后用 M4 x 8 螺丝 (G) 固定该盖板。

注意

拧紧该螺丝前, 请特别注意要检查后部的卡扣是否牢固衔接。

15. 스캐너 밑커버 (A) 의 후크 2 개를 구멍에 삽입하고 M4 x 8 나사 (G) 를 사용하여 커버를 고정합니다.


주의

나사를 조이기 전에 후면의 후크가 단단히 결합되어 있는지 각별히 주의하여 확인하십시오.


15. スキャナー底カバー (A) のフック 2カ所を穴に入れて, ビス M4x8 (G) 1本で固定する。

注意

特に後側のフックが確実に掛かっている事を確認した後, ビス固定をすること。



16. Insert the lower portion of the eject unit cover (D) into the right side of the MFP.
 17. Insert the ribs (31) at the top into the right side of the MFP main unit frame (32).
 18. Install the eject unit cover (D) by inserting its hook (33) into the hole (34) on the eject unit (E).



19. Re-attach the operation panel lower cover (16) using the screw (15) removed in step 9.

16. Insérer la portion inférieure du couvercle de l'unité d'éjection (D) dans le côté droit de l'imprimante.
 17. Insérer les nervures (31) au-dessus dans le côté droit du châssis de l'unité principale de l'imprimante (32).
 18. Installer le couvercle de l'unité d'éjection (D) en insérant son crochet (33) dans le trou (34) sur l'unité d'éjection (E).

19. Rattacher le couvercle inférieur du panneau de commande (16) avec la vis (15) déposée au point 9.

16. Inserte la parte inferior de la cubierta de la unidad de expulsión (D) en el lado derecho del MFP.
 17. Inserte las nervaduras (31) en la parte superior del lado derecho de la estructura (32) de la unidad principal del MFP.
 18. Instale la cubierta (D) de la unidad de expulsión introduciendo su gancho (33) en el orificio (34) de la unidad de expulsión (E).

19. Vuelva a colocar la cubierta inferior del panel de trabajo (16) con el tornillo (15) quitado en el paso 9.

16. Setzen Sie den unteren Teil der Abdeckung der Ausgabereinheit (D) auf der rechten Seite des MFP ein.
 17. Setzen Sie die Lamellen (31) oben in den Rahmen (32) des MFP auf der rechten Seite ein.
 18. Installieren Sie die Abdeckung der Ausgabereinheit (D), indem Sie die Haken (33) in die Löcher (34) der Ausgabereinheit (E) einsetzen.

19. Bringen Sie die untere Abdeckung (16) des Bedienfelds wieder an. Benutzen Sie die Schraube (15) aus Schritt 9.

16. Inserire la parte inferiore del coperchio dell'unità di espulsione (D) sul lato destro dell'MFP.
 17. Inserire le nervature (31) presenti sulla parte superiore, nel lato destro del telaio dell'unità principale dell'MFP (32).
 18. Installare il coperchio dell'unità di espulsione (D) inserendo i relativi ganci (33) nel foro (34) sull'unità di espulsione (E).

19. Riapplicare il coperchio inferiore del pannello operativo (16) usando la vite (15) rimossa nel passo 9.

16. 把出纸单元盖板 (D) 的下侧插入机器右侧。
 17. 把上侧的肋片 (31) 插入机器框架 (32) 的右侧。
 18. 把出纸单元盖板 (D) 的挂钩 (33) 装到出纸单元 (E) 的洞 (34) 中。


19. 使用步骤 9 中卸下的螺丝 (15) 重新安装操作面板下部盖板 (16)。

16. 배출 유닛 커버 (D) 의 하단 부분을 MFP 의 우측에 삽입합니다 .
 17. 상단의 리브 (31) 를 MFP 본체 프레임 (32) 의 우측에 장착합니다 .
 18. 배출 유닛 (E) 의 구멍 (34) 에 후크 (33) 를 삽입하여 배출 유닛 커버 (D) 를 설치합니다 .

19. 단계 9 에서 제거한 나사 (15) 를 사용하여 조작판넬의 하단 커버 (16) 를 다시 부착합니다 .

16. 排出ユニットカバー (D) の下側をMFP本体右側に差し込む。
 17. 上側のリブ (31) をMFP本体フレーム (32) の右側に差し込む。
 18. 排出ユニットカバー (D) のフック (33) を排出ユニット (E) の穴 (34) に入れて取り付ける。

19. 手順9で外したビス (15) 1本で操作パネル下カバー (16) を取り付ける。



- 20.** Install the front right cover (14) using the screw (12) removed in step 8.
Secure the fan cover (10) using the screw (11) removed in step 7.
Close the paper conveyor cover (8).
* Check that connector on the inside of the fan cover (10) has not been dislodged.

- 20.** Reposer le couvercle avant droit (14) à l'aide de la vis (12) déposée à l'étape 8.
Fixer le couvercle du ventilateur (10) à l'aide de la vis (11) déposée à l'étape 7.
Refermer le couvercle du transporteur du papier (8).
* Vérifier que le connecteur à l'intérieur du couvercle du ventilateur (10) n'a pas bougé.

- 20.** Instale la cubierta frontal derecha (14) usando el tornillo (12) quitado en el paso 8.
Asegure la cubierta del ventilador (10) usando el tornillo (11) quitado en el paso 7.
Cierre la unidad de transporte de papel (8).
* Compruebe si no se desplazó el conector del interior de la cubierta del ventilador (10).


- 20.** Bringen Sie die vordere rechte Abdeckung (14) wieder an. Benutzen Sie die Schraube (12) aus Schritt 8. Bringen Sie die Lüfterabdeckung (10) wieder an. Benutzen Sie die Schraube (11) aus Schritt 7. Schließen Sie die Abdeckung des Papiertransports (8).
* Prüfen Sie sorgfältig, dass der Stecker auf der Innenseite der Lüfterabdeckung (10) in der korrekten Position sitzt.

- 20.** Installare il coperchio anteriore destro (14) utilizzando la vite (12) rimossa nel punto 8.
Fissare il coperchio ventola (10) utilizzando la vite (11) rimossa nel punto 7.
Chiudere il coperchio di trasporto carta (8).
* Controllare che il connettore sull'interno del coperchio della ventola (10) non sia stato rimosso.

- 20.** 使用在步骤 8 中卸下的 1 颗螺丝 (12) 来固定右前盖板 (14)。
使用在步骤 7 中卸下的 1 颗螺丝 (11) 来固定风扇盖板 (10)。
关闭输纸盖板 (8)
※ 确认位于风扇盖板 (10) 内侧的接插件有无露出。

- 20.** 단계 8 에서 제거한 나사 (12) 1 개로 오른쪽 전면커버 (14) 를 부착합니다.
순서 7 에서 제거한 나사 (11) 1 개로 팬커버 (10) 를 고정합니다.
반송커버 (8) 를 닫습니다.
※ 팬커버 (10) 안쪽에 있는 커넥터가 빠져 있지 않은지를 확인합니다.

- 20.** 手順 8 で取り外したビス (12) 1 本で右前カバー (14) を取り付けます。
手順 7 で外したビス (11) 1 本でファンカバー (10) を固定する。
搬送カバー (8) を閉める。
※ ファンカバー (10) 内側にあるコネクタが外れていないことを確認する。



- 21.** Insert the right side portion of the inner tray (C) in the main unit.
22. While lowering the wall at the far end of the inner tray (C) so that it does not hit the rail (35), insert the inner tray (C) in the main unit.
23. Raise and hold the wall at the far end of the inner tray (C) above the front side of the rail (35), slide the inner tray (C) all the way in.

- 21.** Insérer la portion de droite du bac intérieur (C) dans l'unité principale.
22. Abaisser la cloison de l'extrémité la plus éloignée du bac intérieur (C) afin qu'elle ne heurte pas le rail (35) et insérer le bac intérieur (C) dans l'unité principale.
23. Soulever et maintenir la cloison de l'extrémité la plus éloignée du bac intérieur (C) au-dessus de l'avant du rail (35) et faire coulisser le bac intérieur (C) jusqu'au fond.

- 21.** Inserte el lado derecho de la bandeja interna (C) en la unidad principal.
22. Mientras baja la pared en el extremo más lejano de la bandeja interna (C) para que no golpee el rail (35), inserte la bandeja interna (C) en la unidad principal.
23. Levante y sujete la pared en el extremo más lejano de la bandeja interna (C) sobre la parte frontal del rail (35), deslice la bandeja interna (C) hasta introducirla hasta el fondo.


- 21.** Setzen Sie den rechten Teil der inneren Ablage (C) in das Gerät ein.
22. Senken Sie die Rückwand am hinteren Ende der inneren Ablage (C) ein wenig ab, so dass diese nicht die Schiene (35) berührt. Gleichzeitig setzen Sie die innere Ablage (C) in das Gerät ein.
23. Senken Sie die Rückwand am hinteren Ende der inneren Ablage (C) ein wenig ab, halten diese gleichzeitig über der Vorderseite der Schiene (35) und setzen die innere Ablage (C) in das Gerät ein.

- 21.** Inserire la parte lato destro del vassoio interno (C) nell'unità principale.
22. Tenendo abbassata la parete sull'estremità distante del vassoio interno (C), in modo da non colpire la guida (35), inserire il vassoio interno (C) nell'unità principale.
23. Sollevare e reggere la parete sull'estremità distante del vassoio interno (C) sopra il lato frontale della guida (35), quindi inserire a fondo il vassoio interno (C).


- 21.** 把内部接纸盘 (C) 的右侧插入机器内。
22. 插入机器时, 请不要让内部接纸盘 (C) 的里侧壁碰到导轨 (35)。
23. 在超过导轨 (35) 前的位置, 抬起内部接纸盘 (C) 的里侧壁后, 把内部接纸盘向里侧滑动。

- 21.** 내부 트레이 (C) 의 우측 부분을 본체에 삽입합니다.
22. 레일 (35) 에 부딪히지 않도록 내부 트레이 (C) 의 안쪽의 칸막이 부분을 낮추면서 본체에 내부 트레이 (C) 를 삽입합니다.
23. 내부 트레이 (C) 의 안쪽의 칸막이 부분을 레일 (35) 의 전면 위로 올려서 유지하고 내부 트레이 (C) 를 안으로 최대한 밀습니다.


- 21.** 内部トレイ (C) の右側を本体に挿入する。
22. 内部トレイ (C) の奥側の壁がレール (35) に当たらないように下げて挿入する。
23. 内部トレイ (C) の奥側の壁がレール (35) 前面を越えた位置で上に上げ、その後内部トレイ (C) を奥にスライドさせる。



24. Raise the rear left corner of the inner tray (C) and insert the hook (36) into the rail (37) on the scanner bottom cover (A).



25. Firmly slide the inner tray (C) all the way in.
26. Attach the inner tray (C) using the S Tite screw M3 x 8 (H).



27. Install the stopper paper (F) onto the scanner bottom cover (A) with the two P Tite screw M3 x 8 (I).

24. Soulever le coin arrière gauche du bac intérieur (C) et insérer le crochet (36) dans le rail (37) sur le couvercle inférieur du scanner (A).

25. Faire coulisser fermement le bac intérieur (C) jusqu'au fond.
26. Attacher le bac intérieur (C) à l'aide de la vis S Tite M3 x 8 (H).

27. Installer la butée de papier (F) sur le couvercle inférieur du scanner (A) avec les deux vis P Tite M3 x 8 (I).

24. Levante la cubierta izquierda posterior de la bandeja interna (C) e inserte el enganche (36) en el raíl (37) en la cubierta inferior (A) del escáner.

25. Deslice firmemente la bandeja interna (C) hasta introducirla hasta el fondo.
26. Fije la bandeja interna (C) con el tornillo S Tite M3 x 8 (H).

27. Instale el tope de papel (F) en la cubierta inferior del escáner (A) con los dos tornillos P Tite M3 x 8 (I).

24. Heben Sie die hintere linke Ecke der inneren Ablage (C) an und setzen Sie den Haken (36) in die Schiene (37) an der unteren Abdeckung des Scanners (A) ein.

25. Setzen Sie die innere Ablage (C) vorsichtig komplett ein.
26. Bringen Sie die innere Ablage (C) mit der S-Tite-Schraube M3 x 8 (H) an.

27. Installieren Sie den Papieranschlag (F) an der unteren Abdeckung des Scanners (A) mit 2 P-Tite-Schrauben M3 x 8 (I).

24. Sollevare l'angolo sinistro posteriore del vassoio interno (C) e inserire il gancio (36) nella guida (37) sul coperchio inferiore dello scanner (A).

25. Inserire saldamente il vassoio interno (C) fino a fine corsa.
26. Fissare il vassoio interno (C) utilizzando la vite S Tite M3 x 8 (H).

27. Installare il fermo carta (F) sul coperchio inferiore dello scanner (A) con le due viti P Tite M3 x 8 (I).

24. 抬起内部接纸盘 (C) 的左后侧, 把挂钩 (36) 插入扫描仪底部盖板 (A) 的导轨 (37) 上。

25. 把内部接纸盘 (C) 完全插到底。
26. 使用 1 颗紧固型 S 螺丝 M3×8 (H) 来固定内部接纸盘 (C)。

27. 使用 2 颗紧固型 P 螺丝 M3×8 (I), 把纸张挡板 (F) 固定到扫描仪底部盖板 (A) 上。

24. 내부 트레이 (C) 의 왼쪽 후면 모서리를 위로 올리고 후크 (36) 를 스캐너 하단 커버 (A) 의 레일 (37) 에 삽입합니다 .


25. 내부 트레이 (C) 를 안쪽으로 힘껏 밀니다 .
26. 나사 M3×8S 타이트 (H) 를 사용하여 내부 트레이 (C) 를 부착합니다 .

27. 나사 M3×8P 타이트 (I) 두 개를 사용하여 스캐너 하단 커버 (A) 에 스톱퍼 용지 (F) 를 장착합니다 .


24. 内部トレイ (C) の左後側を持ち上げ、フック (36) をスキャナー底カバー (A) のレール (37) に挿入する。

25. 内部トレイ (C) を奥までしっかり挿入する。
26. 内部トレイ (C) をビス M3×8S タイト (H) 1 本で固定する。

27. ペーパーstopper (F) をスキャナー底カバー (A) にビス M3×8P タイト (I) 2 本で固定する。



28. Install the left scanner cover (6) using the 2 screws (5) removed in step 3.
29. Close the interface cover (4).



30. Install the left ISU cover (1) using the 2 screws (2) removed in step 1.
31. Close the front cover (7).

28. Installer le couvercle de scanner gauche (6) avec les 2 vis (5) retirées au point 3.
29. Fermer le couvercle de l'interface (4).

30. Installer le couvercle gauche de l'ISU (1) avec les 2 vis (2) déposées au point 1.
31. Refermer le capot avant (7).

28. Instale la cubierta izquierda del escáner (6) con los 2 tornillos (5) quitados en el paso 3.
29. Cierre la cubierta de la interfaz (4).

30. Instale la cubierta ISU izquierda (1) con los 2 tornillos (2) quitados en el paso 1.
31. Cierre la cubierta frontal (7).

28. Bringen Sie die linke Scannerabdeckung (6) wieder an.
Benutzen Sie die 2 Schrauben (5) aus Schritt 3.
29. Schließen Sie die Schnittstellenabdeckung (4).

30. Bringen Sie die linke ISU-Abdeckung (1) wieder an.
Benutzen Sie die 2 Schrauben (2) aus Schritt 1.
31. Schließen Sie die vordere Abdeckung (7).

28. Installare il coperchio sinistro dello scanner (6) usando le 2 viti (5) rimosse nel passo 3.
29. Chiudere la copertura di interfaccia (4).

30. Installare il coperchio ISU sinistro (1) usando le 2 viti (2) rimosse nel passo 1.
31. Chiudere il pannello anteriore (7).

28. 使用步骤 3 中卸下的 2 颗螺丝 (5) 安装扫描仪左盖板 (6)。
29. 关闭接口盖板 (4)。

30. 使用步骤 1 中卸下的 2 颗螺丝 (2) 安装 ISU 左盖板 (1)。
31. 关闭前盖板 (7)。













28. 단계 3 에서 제거한 나사 (5) 2 개로 왼쪽 스캐너 커버 (6) 를 부착합니다 .
29. 인터페이스 커버 (4) 를 닫습니다 .

30. 단계 1 에서 제거한 나사 (2) 2 개로 좌측 ISU 커버 (1) 를 부착합니다 .
31. 전면 커버 (7) 를 닫습니다 .


28. 手順 3 で外したビス (5) 2 本でスキャナー左カバー (6) を取り付けます。
29. インターフェイスカバー (4) を閉じます。

30. 手順 1 で取り外したビス (2) 2 本で ISU 左カバー (1) を取り付けます。
31. 前カバー (7) を閉めます。


INSTALLATION GUIDE FOR RIGHT JOB SEPARATOR




8




9




10




11




12



13



14



INSTALLATION GUIDE FOR BANNER GUIDE

INSTALLATION GUIDE

GUIDE D'INSTALLATION

GUÍA DE INSTALACION

INSTALLATIONSANLEITUNG

GUIDA ALL'INSTALLAZIONE

安装手册



설치안내서

設置手順書





302K95672001

Banner Guide(A)



- (ENG) Precautions**
The illustrations of the machine in the Installation Guide are for color MFP. (30,35,45,55ppm)
- (FR) Précautions**
L'appareil représenté dans les illustrations du présent guide d'installation est le MFP couleur. (30,35,45,55ppm)
- (ES) Precauciones**
Las ilustraciones de la máquina que aparecen en la Guía de instalación corresponden a una MFP en color. (30,35,45,55ppm)
- (DE) Vorsichtsmaßnahmen**
Die Abbildungen der Maschine in der Installationsanleitung gelten für den Farb-MFP. (30,35,45,55ppm)
- (IT) Precauzioni**
Le illustrazioni della macchina nella guida di installazione sono per colore MFP. (30,35,45,55ppm)
- (CN) 注意事项**
安装手册中记载的机器主机的插图是彩色机。(30, 35, 45, 55 页机型)
- (KO) 주의사항**
설치순서에 기재되어 있는 기기본체 일러스트는 컬러기 입니다. (30,35,45,55매기)
- (JP) 注意事項**
設置手順書に記載している機械本体のイラストはカラー機 (30, 35, 45, 55枚機) です。



INSTALLATION GUIDE FOR FAX SYSTEM

English

To install the FAX circuit board, see page 1. To install the FAX circuit board as Dual FAX, see page 17.

References to medium-speed MFPs in this document denote 30/30, 35/35, 45/45 and 55/50 ppm color machines, and 35, 45 and 55 ppm monochrome machines. References to high-speed MFPs in this document denote 65/65 and 75/70 ppm color machines, and 65 and 80 ppm monochrome machines. (The generic procedure figures in this document show medium-speed MFPs.)

If the finisher is already installed, remove the finisher before installing FAX System(V).

Français

Pour installer la carte à circuits FAX, se reporter à la page 1. Pour installer la carte à circuits FAX comme FAX double, se reporter à la page 17.

Dans le présent document, les références aux MFP à vitesse moyenne renvoient aux machines couleurs 30/30, 35/35, 45/45 et 55/50 ppm et aux machines monochromes 35, 45 et 55 ppm.

Dans le présent document, les références aux MFP à grande vitesse renvoient aux machines couleurs 65/65 et 75/70 ppm et aux machines monochromes 65 et 80 ppm. (Dans ce document, les chiffres des processus génériques renvoient aux MPF à vitesse moyenne.)

Si le retoucheur est déjà en place, le déposer avant de monter le FAX System(V).

Español

Para instalar la tarjeta de circuitos de FAX, vea la página 1. Para instalar la tarjeta de circuitos de FAX en el FAX dual, vea la página 17.

Las referencias a las MFP de velocidad media de este documento corresponden a las máquinas a color de 30/30, 35/35, 45/45 y 55/50 ppm y a las máquinas monocromáticas de 35, 45 y 55 ppm.

Las referencias a las MFP de alta velocidad de este documento corresponden a las máquinas a color de 65/65 y 75/70 ppm y a las máquinas monocromáticas de 65 y 80 ppm. (Las ilustraciones de procedimientos genéricos de este documento muestran las MFP de velocidad media.)

Si el finalizador ya se encuentra instalado, desmóntelo antes de instalar el FAX System(V).

Deutsch

Angaben zur Installation der FAX-Leiterplatte finden Sie auf Seite 1. Angaben zur Installation der FAX-Leiterplatte als Dual FAX finden Sie auf Seite 17.

Angaben für MFP der mittleren Leistungsklasse in dieser Anleitung gelten für die 30/30, 35/35, 45/45 und 55/50 ppm Vollfarbkopierer sowie für die 35, 45 und 55 ppm Monochrommaschinen.

Angaben für MFP der Hochleistungsklasse in dieser Anleitung gelten für die 65/65 und 75/70 ppm Vollfarbkopierer sowie für die 65 und 80 ppm Monochrommaschinen. (Die Abbildungen der allgemeinen Prozeduren zeigen MFP der mittleren Leistungsklasse.)

Falls der Finisher schon installiert ist, müssen Sie ihn ausbauen, bevor Sie das FAX System(V) installieren.

Italiano

Per installare la scheda a circuiti FAX, vedere pagina 1. Per installare la scheda a circuiti FAX come Dual FAX, vedere pagina 17.

I riferimenti per le MFP a velocità media riportati in questo documento indicano le macchine a colori 30/30, 35/35, 45/45 e 55/50 ppm, e le macchine monocromatiche 35, 45 e 55 ppm.

I riferimenti per le MFP a velocità alta riportati in questo documento indicano le macchine a colori 65/65 e 75/70 ppm, e le macchine monocromatiche 65 e 80 ppm. (Le figure della procedura generica riportate in questo documento mostrano le MFP a velocità media.)

Se la finitrice è già installata, rimuovere la finitrice prima di installare il FAX System(V).

简体中文

安装传真组件时...从第 1 页开始 安装多插口组件时...从第 17 页开始

本文中的中速 MFP 代表彩色 30/30 页机型、35/35 页机型、45/45 页机型、55/50 页机型、黑白 35 页机型、45 页机型、55 页机型。

本文中的高速 MFP 代表彩色 65/65 页机型、75/70 页机型、黑白 65 页机型、80 页机型。(本文中的通用步骤的插图为中速 MFP。)

已安装装订器时,必须先拆下装订器再安装 FAX System(V)。

한국어

팩스 시스템을 설치하는 경우...1 페이지에서 시작합니다.

멀티포트를 설치하는 경우...17 페이지에서 시작합니다.

본문 중 중속 MFP 는 컬러 30/30 매기, 35/35 매기, 45/45 매기, 55/50 매기, 흑백 35 매기, 45 매기, 55 매기를 나타냅니다.

본문 중 고속 MFP 는 컬러 65/65 매기, 75/70 매기, 흑백 65 매기, 80 매기를 나타냅니다. (본문 중 공통 순서 일러스트는 중속 MFP 로 한다.)

피니셔가 이미 장착되어 있는 경우에는 피니셔를 제거하고 FAX System(V) 를 설치할 것.


日本語

ファクスシステムを設置する場合...1 ページから始める。 マルチポートを設置する場合...17 ページから始める。

本文の中速 MFP はカラー機の 30/30 枚機、35/35 枚機、45/45 枚機、55/50 枚機、モノクロ機の 35 枚機、45 枚機、55 枚機を表す。

本文中の高速 MFP はカラー機の 65/65 枚機、75/70 枚機、モノクロ機の 65 枚機、80 枚機を表す。(本文中の共通手順イラストは中速 MFP とする。)

フィニッシャーがすでに装着されている場合は、フィニッシャーを取り外してから、FAX System(V) を取り付けること。



Supplied parts

A. FAX circuit board	1
B. Modular connector cable (120 V/Australian model only) PJJWC0016Z (UL Listed.HUAN HSIN Type TL:120 V only)1	1
C. Terminal seal	1

D. Alphabet label	1
E. FAX operation section label	1
F. FAX key	1
G. FAX key cover	1
H. PTT label (110V model only)	1
I. Approval label (Australian/New Zealand models only)	2

J. Memory DIMM (16 MB)	1
-------------------------------------	---

Option

K. Memory DIMM (128 MB)	1
--------------------------------------	---

When installing the Dual FAX, (A), (B), (C) are required.

Pièces fournies

A. Carte à circuits FAX	1
B. Câble du connecteur modulaire (modèles pour l'Australie/120 V seulement)	1
C. Joint de borne	1
D. Etiquette de l'alphabet	1

E. Etiquette de la section de fonctionnement FAX	1
F. Touche FAX	1
G. Couvercle de touche FAX	1
J. Mémoire DIMM (16 MB)	1

Option

K. Mémoire DIMM (128 MB)	1
---------------------------------------	---

(H) et (I) ne sont pas fournis.
L'installation du Dual FAX requiert l'installation
des pièces (A), (B), (C).

Partes suministradas

A. Tarjeta de circuitos de fax	1
B. Cable conector modular (sólo para modelos de 120 V/Australianos)	1
C. Sello del terminal	1
D. Etiqueta de alfabeto	1

E. Etiqueta de la sección de funcionamiento de FAX	1
F. Tecla de FAX	1
G. Cubierta de la tecla de FAX	1
J. Memoria DIMM (16 MB)	1

Opción

K. Memoria DIMM (128 MB)	1
---------------------------------------	---

(H) y (I) no se suministran.
Cuando instale el fax Dual se necesitan (A), (B),
(C).

Gelieferte Teile

A. FAX-Leiterplatte	1
C. Verschlusskappe	1
D. Alphetaufkleber	1
E. Aufkleber für FAX-Bedienungsabschnitt	1
F. FAX-Taste	1
G. FAX-Tastenabdeckung	1

J. Speicher-DIMM (16 MB)	1
---------------------------------------	---

Option

K. Speicher-DIMM (128 MB)	1
--	---

(B), (H) und (I) liegen nicht bei.
Für die Installation von Dual FAX sind (A), (C)
erforderlich.

Parti di forniture

A. Scheda a circuiti FAX	1
C. Guarnizione terminale	1
D. Etichetta alfabetica	1
E. Etichetta della sezione funzionamento FAX	1
F. Tasto FAX	1

G. Copertura tasto FAX	1
J. Memoria DIMM (16 MB)	1

Opzioni

K. Memoria DIMM (128 MB)	1
---------------------------------------	---

(B), (H) e (I) non sono in dotazione.
Quando si installa il Dual FAX, sono necessari
(A), (C).

附属品

A. 传真电路板	1
B. 电话线	1
C. 端子密封	1
D. 英文字母标签	1
E. 传真操作部标签	1

F. FAX 键	1
G. FAX 键盖板	1
H. 规格标签	1
J. 内存模组 DIMM (16MB)	1

选购件

K. 内存模组 DIMM (128MB)	1
-----------------------------------	---

(I) 并非附属品。
安装多插口组件时，需要 (A)、(B)、(C)。

동봉품

A. FAX 기관	1
C. 단자씰	1
D. 알파벳 라벨	1
E. FAX 조작부 라벨	1
F. FAX 키	1

G. FAX 키커버	1
J. 메모리 DIMM (16MB)	1

옵션

K. 메모리 DIMM (128MB)	1
----------------------------------	---

(B) (H) (I) 는 동봉되어 있지 않습니다 .
멀티포트 설치 시에는 (A),(C) 가 필요합니다 .

同梱品



A. FAX 基板	1
B. モジュールコード	1
C. 端子シール	1
E. FAX 操作部ラベル	1
F. FAX キー	1
G. FAX キーカバー	1

J. メモリー-DIMM(16MB)	1
---------------------------------	---

オプション

K. メモリー-DIMM(128MB)	1
----------------------------------	---

(D) (H) (I) は、同梱されていない。
マルチポート設置時は (A), (B), (C), が必要と
なる。



Precautions

Be sure to remove any tape and/or cushioning material from supplied parts.
Be sure to turn the MFP switch OFF and unplug the MFP from the power supply before installing the fax system.

Procedure Installing the memory DIMM

1. Remove 2 screws (1), and then remove the cover (2).

2. Install the memory DIMM (J) or the optional memory DIMM (K) into the memory slot (3) on the lower level (FLS).
Install it with the IC side facing down. Insert it in the direction of the arrow until it clicks.

Précautions

Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.
Veillez à mettre l'interrupteur principal du MFP hors tension et à débrancher le MFP de la prise secteur avant d'installer le système fax.

Procédure Installation de la mémoire DIMM

1. Déposez les 2 vis (1) puis enlevez le couvercle (2).

2. Installer la mémoire DIMM (J) ou la mémoire DIMM en option (K) dans la fente mémoire (3) se trouvant au niveau inférieur (FLS).
L'installer avec le côté IC en bas. L'insérer dans la direction de la flèche jusqu'au clic.

Precauciones

Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.
Asegúrese de apagar el MFP colocando el interruptor principal a OFF y desenchufe el MFP del suministro de red eléctrica antes de instalar el sistema de fax.

Procedimiento Instalación de la memoria DIMM

1. Quite 2 tornillos (1) y, después, desmonte la cubierta (2).

2. Instale la memoria DIMM (J), o la memoria DIMM opcional (K), en la ranura para memoria (3) en el nivel inferior (FLS).
Instálelo con el lado IC hacia abajo. Insértela en la dirección que indica la flecha hasta que escuche un clic.

Vorsichtsmaßnahmen

Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.
Schalten Sie den Netzschalter des MFP aus und trennen Sie den MFP vom Netz, bevor Sie das Faxsystem installieren.

Verfahren Installation der DIMM-Speichermodule

1. Entfernen Sie 2 Schrauben (1) und nehmen Sie dann die Abdeckung (2) ab.

2. Setzen Sie das DIMM-Speichermodul (J) oder das optionale DIMM-Speichermodul (K) in die untere Position (FLS) der Speicherbank (3) ein.
Mit der IC-Seite nach unten weisend installieren. Schieben Sie das Modul in Pfeilrichtung, bis es hörbar einrastet.

Precauzioni

Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.
Assicurarsi di aver spento l'interruttore dell'MFP e di aver sfilato la spina dell'MFP dalla presa prima di installare il sistema fax.

Procedura Installazione della memoria DIMM

1. Rimuovere 2 viti (1), e quindi rimuovere il coperchio (2).

2. Installare la memoria DIMM (J) o la memoria DIMM opzionale (K) nello slot della memoria (3) al livello inferiore (FLS).
Installare con il lato IC rivolto verso il basso. Inserirla nella direzione della freccia finché non scatta in posizione.

注意事項

如果附属品上带有固定胶带，缓冲材料时必须揭下。
请务必关闭 MFP 的开关并拔下电源插头再安装传真组件。

安装步骤 安装内存模组 DIMM

1. 取下 2 个螺丝 (1)，然后取下盖板 (2)。

2. 将内存模组 DIMM (J) 或选购件内存模组 DIMM (K) 安装至下层 (FLS) 的内存插槽 (3)。安装时，将 IC 侧正面朝下。沿箭头方向将其插入到底直至发出喀嗒声。

주의사항

동봉품에 고정 테이프, 완충재가 붙어 있는 경우에는 반드시 제거할 것.
팩스 시스템을 설치하는 경우에는 MFP 본체의 주 전원 스위치를 OFF 로 하고 전원 플러그를 뺀 다음 작업을 합니다.

설치순서 메모리 DIMM 설치

1. 나사 (1) 2 개를 제거하고 커버 (2) 를 제거합니다.

2. 메모리 DIMM (J) 또는 옵션 메모리 DIMM (K) 를 하단 (FLS) 의 메모리 슬롯 (3) 에 장착합니다.
IC 면을 밑으로 할 것.
딸깍하고 소리가 날 때까지 화살표 방향으로 삽입합니다.


注意事項

同梱品に固定テープ、緩衝材が付いている場合は必ず取り外すこと。
ファクスシステムを設置する場合は、MFP 本体の主電源スイッチを OFF にし、電源プラグを抜いてから作業をおこなう。

取付手順 メモリーDIMMの取り付け

1. ビス (1) 2 本を外し、カバー (2) を取り外す。


2. メモリーDIMM (J) または、オプションのメモリーDIMM (K) を下段 (FLS) のメモリースロット (3) に取り付ける。
IC 面を下向きに取り付けること。
カチッと音がするまで矢印方向に挿入する。



3. Replace the cover (2) using the 2 screws (1).

**Removing the slot cover
(medium-speed MFPs)**

4. Open the cover (4).



5. Remove 2 screws (6) and then remove the OPT1 slot cover (5).

* Do not use OPT2.

To install the FAX circuit board as Dual FAX, see page 17.

3. Reposez le couvercle (2) à l'aide des 2 vis (1).

**Dépose du couvercle de la fente
(MFP à vitesse moyenne)**

4. Ouvrir le couvercle (4).

5. Déposer les 2 vis (6) puis le couvercle de la fente OPT1 (5).

* Ne pas utiliser OPT2.

Pour installer la carte à circuits FAX comme FAX double, se reporter à la page 17.

3. Vuelva a colocar la cubierta (2) utilizando los 2 tornillos (1).

**Desmontaje de la cubierta de la ranura
(MFP de velocidad media)**

4. Abra la cubierta (4).

5. Quite 2 tornillos (6) y, después, quite la cubierta de la ranura OPT1 (5).

* No utilice OPT2.

Para instalar la tarjeta de circuitos de FAX en el FAX dual, vea la página 17.

3. Bringen Sie die Abdeckung (2) wieder mit den 2 Schrauben (1) an.

**Entfernen der Einschubabdeckung
(MFP der mittleren Leistungsklasse)**

4. Die Abdeckung (4) öffnen.

5. 2 Schrauben (6) entfernen und dann die Abdeckung (5) des Einschubs OPT1 entfernen.

* OPT2 nicht verwenden.

Angaben zur Installation der FAX-Leiterplatte als Dual FAX finden Sie auf Seite 17.

3. Ricollocare il coperchio (2) utilizzando le 2 viti (1).

**Rimozione del coperchio vano
(MFP a velocità media)**

4. Aprire il coperchio (4).

5. Rimuovere le 2 viti (6) e quindi rimuovere il coperchio (5) del vano OPT1.

* Non utilizzare OPT2.

Per installare la scheda a circuiti FAX come Dual FAX, vedere pagina 17.

3. 使用 2 个螺丝 (1) 重新安装盖板 (2)。

拆下插槽盖板 (中速 MFP 时)

4. 打开盖板 (4)。

5. 拆除 2 颗螺丝 (6), 拆下 OPT1 的插槽盖板 (5)。

※ 不使用 OPT2。

安装多插口组件时 ... 从第 17 页开始

3. 나사 (1) 2 개로 커버 (2) 를 원래대로 장착합니다.

슬롯커버 제거 (중속 MFP 의 경우)

4. 커버 (4) 를 엽니다.

5. 나사 (6) 2 개를 제거하고 OPT1 의 슬롯커버 (5) 를 제거합니다.

※ OPT2 는 사용하지 말 것.

멀티포트 를 설치하는 경우 ... 17 페이지에서 시작합니다.

3. ビス (1) 2 本で、カバー (2) を元通り取り付ける。


スロットカバーの取り外し (中速 MFP の場合)

4. カバー (4) を開ける。

5. ビス (6) 2 本を外し、OPT1 のスロットカバー (5) を取り外す。


※ OPT2 は使用しないこと。

マルチポートを設置する場合 ... 17 ページから始める。



Removing the slot cover (For high-speed MFPs and when the finisher is installed)

4.Remove the cover (4).



5.Remove 2 screws (6) and then remove the OPT1 slot cover (5).
* Do not use OPT2.

To install the FAX circuit board as Dual FAX, see page 17.

Dépose du couvercle de la fente (Pour les MFP à grande vitesse quand le retoucheur est installé)

4.Déposer le couvercle (4).

5.Déposer les 2 vis (6) puis le couvercle de la fente OPT1 (5).
* Ne pas utiliser OPT2.

Pour installer la carte à circuits FAX comme FAX double, se reporter à la page 17.

Desmontaje de la cubierta de la ranura (Para las MFP de alta velocidad y cuando el finalizador está instalado)

4.Quite la cubierta (4).

5.Quite 2 tornillos (6) y, después, quite la cubierta de la ranura OPT1 (5).
* No utilice OPT2.

Para instalar la tarjeta de circuitos de FAX en el FAX dual, vea la página 17.

Entfernen der Einschubabdeckung (Für MFP der Hochleistungsklasse und wenn der Finisher installiert ist)

4.Die Abdeckung (4) entfernen.

5.2 Schrauben (6) entfernen und dann die Abdeckung (5) des Einschubs OPT1 entfernen.
* OPT2 nicht verwenden.

Angaben zur Installation der FAX-Leiterplatte als Dual FAX finden Sie auf Seite 17.

Rimozione del coperchio vano (Per MFP a velocità alta e quando la finitrice è installata)

4.Rimuovere il coperchio (4).

5.Rimuovere le 2 viti (6) e quindi rimuovere il coperchio (5) del vano OPT1.
* Non utilizzare OPT2.

Per installare la scheda a circuiti FAX come Dual FAX, vedere pagina 17.

拆下插槽盖板
(高速 MFP 且安装装订器时)
4. 拆下盖板 (4)。

5. 拆除 2 颗螺丝 (6)，拆下 OPT1 的插槽盖板 (5)。
※ 不使用 OPT2。

安装多插口组件时 … 从第 17 页开始

슬롯커버 제거
(고속 MFP 및 피니셔 장착 시의 경우)
4. 커버 (4) 를 제거합니다 .


5. 나사 (6) 2 개를 제거하고 OPT1 의 슬롯커버 (5) 를 제거합니다 .
※OPT2 는 사용하지 말 것 .

멀티포트를 설치하는 경우 …17 페이지에서 시작합니다 .

スロットカバーの取り外し
(高速 MFP およびフィニッシャー装着時の場合)
4. カバー (4) を取り外す。

5. ビス (6) 2 本を外し、OPT1 のスロットカバー (5) を取り外す。
※OPT2 は使用しないこと。

マルチポートを設置する場合 …17 ページから始める。



Install the FAX circuit board.

6. Insert the FAX circuit board (A) along the groove in OPT1 and secure the board with two screws (6) that have been removed in step 5.

Do not directly touch the FAX circuit board (A) terminal. Hold the top and bottom of the FAX circuit board, or the projection of the board to insert the FAX circuit board (A).

Direct the label (7) on to the FAX circuit board (A) as indicated in the illustration and insert the board along the groove.

Installer la carte à circuits FAX.

6. Insérer la carte à circuits FAX (A) le long de la rainure dans l'OPT1 et la fixer à l'aide des deux vis (6) retirées à l'étape 5.

Ne pas toucher directement la borne de la carte à circuits FAX (A). Tenir les parties inférieure et supérieure de la carte à circuits FAX ou la saillie de la carte pour insérer la carte à circuits FAX (A). Orienter l'étiquette (7) de la carte à circuits FAX (A) comme illustré et insérer la plaquette le long de la rainure.

Instale la tarjeta de circuitos de fax.

6. Inserte la tarjeta de circuitos de fax (A) a lo largo de la ranura de OPT1 y asegúrela con los dos tornillos (6) que ha quitado en el paso 5.

No toque directamente el terminal de la tarjeta de circuitos del fax (A). Sujete las partes superior e inferior de la tarjeta de circuitos de fax o la saliente de la tarjeta para insertar la tarjeta de circuitos de fax (A). Oriente la etiqueta (7) en la tarjeta de circuitos del FAX (A) como se indica en la ilustración e inserte la tarjeta a lo largo de la ranura.

Installieren der FAX-Leiterplatte.

6. FAX-Leiterplatte (A) in die Nut des Einbauschachts OPT1 einsetzen und Leiterplatte mit den in Schritt 5 ausgebauten Schrauben (6) befestigen.

Berühren Sie die Anschlüsse der FAX-Platine (A) nicht mit den Fingern. Die FAX-Leiterplatte (A) beim Einsetzen oben und unten oder an dem Vorsprung festhalten.

Die FAX-Leiterplatte (A) so in die Nut einsetzen, dass der Aufkleber (7) wie abgebildet zur Leiterplatte zeigt.

Installare la scheda a circuiti FAX.

6. Inserire la scheda a circuiti FAX (A) lungo l'incavo nell'OPT1 e fissare la scheda con le due viti (6) rimosse nell'operazione 5.

Non toccare direttamente il terminale della scheda a circuiti FAX (A). Per inserire il circuito FAX (A), tenere l'estremità superiore e la base della scheda a circuiti FAX, o la sporgenza della scheda a circuiti FAX. Orientare l'etichetta (7) sulla scheda a circuiti FAX (A) come indicato nell'illustrazione e inserire la scheda lungo l'incavo.

安装传真电路板

6. 沿着 OPT1 的沟槽插入传真电路板 (A) 并用步骤 5 中拆下的两颗螺钉 (6) 固定电路板。

请勿直接接触传真电路板 (A) 端子。

按住传真电路板的顶部和底部, 或者按住电路板的突出部将传真电路板 (A) 插入。

将传真电路板 (A) 上的标签 (7) 保持图示中的方向, 将电路板沿着沟槽方向插入。

FAX 기판 장착

6. OPT1 구에 붙여 FAX 기판 (A) 를 삽입하고 순서 5 에서 제거한 나사 (6) 2 개로 고정합니다 .

FAX 기판 (A) 의 단자에 직접 닿지 않게 할 것 .

FAX 기판 (A) 을 삽입 시에는 기판의 상하 또는 돌기를 잡을 것 .

FAX 기판 (A) 을 붙여진 라벨 (7) 그림 표기 방향대로 되도록 삽입할 것 .


FAX 基板の取り付け

6. OPT1 の溝に沿って FAX 基板 (A) を挿入し、手順 5 で外したビス (6) 2 本で固定する。

FAX 基板 (A) の端子に直接触れないこと。

FAX 基板 (A) の挿入時は基板の上下か突起を持つこと。

FAX 基板 (A) は、貼り付けられているラベル (7) が図に示す方向になるように、挿入すること。



Connect the MFP to the telephone line.

7. Plug the modular connector cable (8) into the line terminal, and then connect the other end to the telephone line.

For 100 V/120 V/Australian or Chinese models, use the supplied modular connector cable (B).

Connecter le MFP à la ligne de téléphone.

7. Brancher le câble du connecteur modulaire (8) à la borne de la ligne, puis connecter l'autre extrémité à la ligne de téléphone.

Pour les modèles 100 V/120 V/Australie ou Chine, utilisez le câble à connecteur modulaire (B) fourni.

Conecte el MFP a la línea telefónica.

7. Enchufe el cable del conector modular (8) en el terminal de línea y, a continuación, conecte el otro extremo a la línea telefónica.

Para los modelos de 100 V/120 V/Australiano o Chino, utilice el cable conector modular (B) suministrado.

Anschließen des MFP an die Telefonleitung.

7. Telefonmodulkabel (8) in die Gerätebuchse einstecken und das Kabel an der Telefondose anschließen.

Das mitgelieferte Modularsteckerkabel (B) für die 100-V/120-V/Australien- oder China-Modelle verwenden.

Collegamento dell'MFP alla linea del telefono.

7. Inserire il cavo connettore modulare (8) nel terminale della linea, e quindi collegare l'altro terminale alla linea del telefono.

Per modelli da 100 V/120 V/Australia o Cina, utilizzare il cavo connettore modulare (B) in dotazione.

将 MFP 连接到电话线

7. 将模块接插件电缆 (8) 插入电话线端子, 然后将另一端与电话线连接。

对于 100V/120V/ 澳大利亚或中国机型, 请使用随附的模块接插件电缆 (B)。

전화회선과 접속


7. 모듈코드 (8) 를 라인단자에 꼽습니다. 다른 한 쪽의 플러그는 전화회선과 접속합니다.

100V/120V/ 오스트레일리아 / 중국사양은 부속 모듈코드 (B) 를 사용할 것 .

電話回線との接続


7. モジュラーコード (8) をライン端子に差し込む。もう片方のプラグは、電話回線へ接続する。

100V/120V/ オーストラリア / 中国仕様は付属のモジュラーコード (B) を使用すること。



Connect the MFP to the separate phone (except for New Zealand model).

8. Plug the modular connector cable (9) into the telephone terminal, and then connect the other end to the separate phone.



If you don't connect the MFP to the separate phone, wipe the surface of the telephone terminal with alcohol and adhere the terminal seal (C) upon the customer's request. On 120 V models, be sure that it is not attached over the top of the approval label (10).

Connecter le MFP au téléphone séparé.

8. Brancher le câble du connecteur modulaire (9) à la borne du téléphone, puis connecter l'autre extrémité au téléphone séparé.

Si le MFP n'est pas connecté au téléphone séparé à la demande du client, nettoyer la surface de la borne de téléphone avec de l'alcool et apposer le joint de borne (C). Sur les modèles 120 V, attention à ne pas installer en recouvrant le haut de l'étiquette d'approbation (10).

Conecte el MFP al teléfono separado.

8. Enchufe el cable del conector modular (9) en el terminal del teléfono y, a continuación, conecte el otro extremo al teléfono separado.

Si no conecta el MFP a un teléfono separado, limpie la superficie del terminal del teléfono con alcohol y pegue el sello del terminal (C), a solicitud del cliente. En los modelos de 120 V, asegúrese de que no se fije sobre la etiqueta de aprobación (10).

Anschließen des MFP an das separate Telefon.

8. Das Telefonmodulkabel (9) in die Telefonbuchse einstecken und das andere Ende an das separate Telefon anschließen.

Wenn der MFP nicht an das separate Telefon angeschlossen wird, die Oberfläche der Telefonbuchse mit Alkohol abwischen und Verschlusskappe (C) einsetzen, falls vom Kunden gewünscht. Bei 120-V-Modellen darauf achten, dass der Aufkleber nicht den Genehmigungsaufkleber (10) verdeckt.

Collegamento dell'MFP al telefono separato.

8. Inserire il cavo connettore modulare (9) nel terminale del telefono, e quindi collegare l'altro terminale al telefono separato.

Nel caso in cui non si colleghi l'MFP al telefono separato, pulire la superficie del terminale del telefono con dell'alcol e applicare la guarnizione terminale (C) a richiesta del cliente. Sui modelli da 120 V, assicurarsi che essa non venga applicata sopra l'etichetta di approvazione (10).

将 MFP 连接到其它电话

8. 将模块接插件电缆 (9) 插入电话端子, 然后将另一端与其它电话连接。

如果您没有将 MFP 连接至其他电话, 请用酒精擦拭电话端子表面, 并按照客户要求粘上端子密封 (C)。120V 规格在粘贴时注意不要与认可标签 (10) 重叠。

외부 전화와 접속


8. 모듈코드 (9) 를 TEL 단자에 꼽습니다. 다른 한 쪽의 플러그는 외부 전화와 접속합니다.

외부 전화와 접속하지 않는 경우 고객의 요청에 따라 TEL 단자 주위를 알코올 청소하고 단자씰 (C) 을 붙입니다. 120V 사양은 허가 라벨 (10) 에 겹치지 않도록 붙일 것.

外付け電話との接続


8. モジュラーコード (9) を TEL 端子に差し込む。もう片方のプラグは、外付け電話と接続する。

外付け電話と接続しない場合、お客様の要望により、TEL 端子周囲をアルコール清掃し、端子シール (C) を貼り付ける。120V 仕様は認可ラベル (10) に重ならないように、貼りつけること。



Seal the terminal (for New Zealand model).

9. Wipe the surface of the telephone terminal with alcohol and adhere the terminal seal (C).
Perform this procedure for New Zealand model only.



Wiring the modular connector cable (High-speed MFPs only)

10. Remove the covers (11) and run the modular connector cable as shown in the figure.

11. Reinstall the covers (11).

Fermer hermétiquement la borne (modèle pour la Nouvelle-Zélande).

9. Effectuer cette procédure pour le modèle pour la Nouvelle-Zélande seulement.

Câblage du câble à connecteur modulaire (MFP à grande vitesse uniquement)

10. Déposer les couvercles (11) et implanter le câble à connecteur modulaire comme illustré par la figure.

11. Reposer les couvercles (11).

Selle el terminal (para el modelo Nuevo Zelandés).

9. Realice este procedimiento sólo para el modelo Nuevo Zelandés.

Tendido del cable conector modular (Solo para las MFP de alta velocidad)

10. Quite las cubiertas (11) y tienda el cable conector modular como se muestra en la ilustración.

11. Vuelva a instalar las cubiertas (11).

Versiegeln der Anschlussbuchse (für Neuseeland-Modell).

9. Dieses Verfahren nur für das Neuseeland-Modell anwenden.

Verlegung des Modularsteckerkabels (Nur MFP der Hochleistungs-klasse)

10. Die Abdeckungen (11) entfernen und das Modularsteckerkabel gemäß der Abbildung verlegen.

11. Die Abdeckungen (11) wieder anbringen.

Sigillare il terminale (per il modello Nuova Zelanda).

9. Eseguire questa procedura solo per il modello Nuova Zelanda.

Cablaggio del cavo connettore modulare (Solo per MFP a velocità alta)

10. Rimuovere i coperchi (11) e far passare il cavo connettore modulare come indicato nella figura.

11. Reinstallare i coperchi (11).

安装端子密封 (仅适用于新西兰型号)

9. 该操作步骤仅适用于新西兰型号。

电话线的配线 (仅限高速 MFP 时)

10. 拆下盖板 (11)，将电话线如图所示穿过。

11. 安装盖板 (11)。

단자씰의 부착 (뉴질랜드 사양만)

9. TEL 단자 주위를 알코올청소하고 단자씰 (C) 을 붙입니다.

모듈코드의 배선 (고속 MFP 의 경우만)

10. 커버 (11) 를 떼어 내고 모듈코드를 그림과 같이 지나가게 합니다.

11. 커버 (11) 을 장착합니다.

端子シールの貼り付け (ニュージーランド仕様のみ)

9. この手順はニュージーランド仕様のみおこなう。

モジュラーコードの配線 (高速 MFP の場合のみ)

10. カバー (11) を取り外し、モジュラーコードを図のように通す。

11. カバー (11) を取り付ける。

(Medium-speed MFPs)

12. Close the cover (4).

(For high-speed MFPs and when the finisher is installed)

12. Reinstall the cover (4).

(MFP à vitesse moyenne)

12. Fermer le couvercle (4).

(Pour les MFP à grande vitesse quand le retoucheur est installé)

12. Reposer le couvercle (4).

(MFP de velocidad media)

12. Cierre la cubierta (4).

(Para las MFP de alta velocidad y cuando el finalizador está instalado)

12. Vuelva a instalar la cubierta (4).

(MFP der mittleren Leistungsklasse)

12. Die Abdeckung (4) schließen.

(Für MFP der Hochleistungsklasse und wenn der Finisher installiert ist)

12. Die Abdeckung (4) wieder anbringen.

(Per MFP a velocità media)

12. Chiudere il coperchio (4).

(Per MFP a velocità alta e quando la finitrice è installata)

12. Reinstallare il coperchio (4).

(中速 MFP 時)

12. 关闭盖板 (4)。

(高速 MFP 且 安装装订器时)

12. 安装盖板 (4)。

(중속 MFP 의 경우)

12. 커버 (4) 를 닫습니다 .

(고속 MFP 및 피니셔 장착 시의 경우)


12. 커버 (4) 를 장착합니다 .

(中速 MFP の場合)

12. カバー(4)を閉める。

(高速 MFP およびフィニッシャー装着時の場合)

12. カバー(4)を取り付ける。



Installing the FAX key

13. Insert a flat-head screwdriver at the tip indicated by the arrows (12) as shown on the left, and slide the operation panel covers (13) (14) to remove them.

Installation de la touche FAX

13. Insérer un tournevis à lame à l'endroit repéré par les flèches (12) comme illustré ci-contre à gauche et faire glisser les couvercles du panneau de commande (13) (14) pour les déposer.

Instalación de la tecla de FAX

13. Inserte un destornillador de pala plana en la punta que indican las flechas (12) como se muestra a la izquierda y deslice las cubiertas del panel de trabajo (13) (14) para quitarlas.

Installieren der FAX-Taste

13. Einen flachen Schraubendreher an der links mit Pfeilen (12) bezeichneten Spitze einschieben und die Bedienfeldabdeckungen (13) (14) verschieben, um sie dann abzunehmen.

Installazione del tasto FAX

13. Inserire un cacciavite a testa piana nel punto indicato dalla freccia (12) come mostrato sulla sinistra, e slittare i coperchi (13) (14) del pannello operativo per rimuoverli.

安装 FAX 键


13. 如图所示, 在▲箭头(12)前方插入一字螺丝刀, 滑动并取下操作面板的盖板(13)(14)。

FAX 키 부착


13. 그림과 같이 ▲ 표시(12) 앞에 마이너스 드라이버를 삽입해 조작 패널의 커버(13)(14)를 미끄러트리면서 떼어 냅니다.

FAX 키의取り付け


13. 図のように▲印(12)の先にマイナスドライバーを挿入し、操作パネルのカバー(13)(14)をスライドさせて取り外す。



14. Remove the clear panel (15).



15. Remove the operation panel sheet (16).



16. Remove the FAX key section cover (17).

14. Déposer le panneau transparent (15).

15. Déposer la tôle du panneau de commande (16).

16. Déposer le couvercle de la partie touche FAX (17).

14. Quite el panel transparente (15).

15. Quite la hoja del panel de trabajo (16).

16. Quite la cubierta de la sección de la tecla de FAX (17).

14. Die durchsichtige Platte (15) entfernen.

15. Die Bedienfeldfolie (16) entfernen.

16. Die Abdeckung (17) des FAX-Tastenbereichs entfernen.

14. Rimuovere il pannello trasparente (15).

15. Rimuovere il foglio (16) del pannello operativo.

16. Rimuovere la copertura (17) della sezione tasto FAX.

14. 拆下透明面板(15)。

15. 拆下操作面板页(16)。

16. 拆下 FAX 键部分的盖板(17)。

14. 클리어 판넬 (15) 을 제거합니다 .


15. 조작판넬시트 (16) 를 제거합니다 .

16. FAX 키 부분의 커버 (17) 를 제거합니다 .


14. クリアパネル(15)を取り外す。

15. 操作パネルシート(16)を取り外す。

16. FAX キー部分のカバー(17)を取り外す。



17. Install the FAX key (F).



18. Install the FAX key cover (G).

17. Installer la touche FAX (F).

18. Installer le couvercle de la touche FAX (G).

17. Instale la tecla de FAX (F).

18. Instale la cubierta de la tecla de FAX (G).

17. Die FAX-Taste (F) anbringen.

18. Die Abdeckung (G) der FAX-Taste anbringen.

17. Installare il tasto FAX (F).

18. Installare la copertura (G) del tasto FAX.

17. 安装 FAX 键 (F)。


18. 安装 FAX 键盖板 (G)。

17. FAX 키 (F) 를 부착합니다 .

18. FAX 키커버 (G) 를 부착합니다 .


17. FAX キー (F) を取り付ける。

18. FAX キーカバー (G) を取り付ける。



Attach the alphabet labels (excluding 100 V models).

19. Wipe the area above the numeric keys on the operation panel sheet (16) with alcohol and attach the alphabet labels (D). In Asia and Oceania, use PQRS TUV WXYZ label, and do not use PRS TUV WXY and OPER labels.



Attach the FAX operation section label.

20. Wipe the label surface shown in the figure of the operation panel sheet (16) with alcohol and attach the FAX operation section label (E) of the corresponding language.

Apposer les étiquettes de l'alphabet (Sauf sur les modèles 100 V).

19. Nettoyer à l'alcool la surface au-dessus des touches numériques sur la tôle du panneau de commande (16) et apposer les étiquettes alphabétiques (D). En Asie et Océanie, utiliser l'étiquette PQRS TUV WXYZ et pas les étiquettes PRS TUV WXY et OPER.

Apposer l'étiquette de la section de fonctionnement FAX.

20. Nettoyer avec de l'alcool la surface de l'étiquette montrée sur l'illustration de la tôle du panneau de commande (16) et apposer l'étiquette de la section de fonctionnement FAX (E) de la langue correspondante.

Fije las etiquetas de alfabeto (a excepción de los modelos de 100 V).

19. Limpie el área sobre las teclas numéricas de la hoja del panel de trabajo (16) con alcohol y fije las etiquetas de alfabeto (D). En Asia y Oceanía, utilice la etiqueta PQRS TUV WXYZ y no use las PRS TUV WXY ni las OPER.

Fije la etiqueta de la sección de funcionamiento del FAX.

20. Limpie la superficie de la etiqueta que aparece en la figura de la hoja del panel de trabajo (16) con alcohol y fije la etiqueta de la sección de funcionamiento del FAX (E) del idioma correspondiente.

Anbringen der Alphetaufkleber (ausgenommen 100-V-Modelle).

19. Den Bereich über den Zifferntasten an der Bedienfeldfolie (16) mit Alkohol abwischen und die Alphetaufkleber (D) hier anbringen. In Asien und Ozeanien den Aufkleber PQRS TUV WXYZ verwenden; nicht die Aufkleber PRS TUV WXY und OPER verwenden.

Anbringen des Aufklebers für den FAX-Bedienungsabschnitt.

20. Die in der Abbildung der Bedienfeldfolie (16) gezeigte Klebefläche des Aufklebers mit Alkohol reinigen und den Aufkleber für den FAX-Bedienungsabschnitt (E) der entsprechenden Sprache anbringen.

Applicare le etichette alfabetiche (esclusi i modelli da 100 V).

19. Pulire l'area sopra i tasti numerici sul foglio del pannello operativo (16) con alcool ed applicare le etichette alfabetiche (D). In Asia ed Oceania, utilizzare l'etichetta PQRS TUV WXYZ e non utilizzare le etichette PRS TUV WXY e OPER.

Applicare l'etichetta della sezione funzionamento FAX.

20. Pulire con alcool la superficie dell'etichetta indicata in figura del foglio del pannello operativo (16), ed applicare l'etichetta della sezione funzionamento FAX (E) della lingua corrispondente.

粘貼英文字標簽 (100V 規格以外)

19. 使用酒精清潔操作面板頁 (16) 的數字鍵上部，粘貼英文字標簽 (D)。在亞洲和大洋州，請使用 PQRS TUV WXYZ 標簽，而不要使用 PRS TUV WXY 和 OPER 標簽。

粘貼 FAX 操作部標簽

20. 使用酒精清潔操作面板頁 (16) 的插图位置的標簽表面後，粘貼對應語言的 FAX 操作部標簽 (E)。

알파벳 라벨의 부착 (100V 사양 이외)

19. 조작판넬시트 (16) 의 텐키 윗측을 알코올 청소하고 알파벳 라벨 (D) 을 붙입니다. 아시아?오세아니아에서는 「PRS TUV WXY」 및 「OPER」 라벨을 사용하지 말고 「PQRS TUV WXYZ」의 라벨을 사용할 것.

FAX 조작부라벨의 부착


20. 조작판넬시트 (16) 의 일러스트 위치의 라벨윗면을 알코올청소 후 해당하는 언어의 FAX 조작부 라벨 (E) 을 붙입니다.

アルファベットのラベルの貼り付け (100V仕様以外)


19. この作業は不要。

FAX 操作部ラベルの貼り付け


20. 操作パネルシート (16) のイラストの位置のラベル上面をアルコール清掃後、該当する言語の FAX 操作部ラベル (E) を貼り付ける。



21. Attach the operation panel sheet (16).



22. Reinstall the clear panel (15).



23. Reinstall the operation panel covers (13) (14).

21. Fixer la tôle du panneau de commande (16).

22. Reposer le panneau transparent (15).

23. Reposer les couvercles du panneau de commande (13) (14).

21. Fije la hoja del panel de trabajo (16).

22. Vuelva a instalar el panel transparente (15).

23. Vuelva a instalar las cubiertas del panel de trabajo (13) (14).

21. Die Bedienfeldfolie (16) anbringen.

22. Die durchsichtige Platte (15) wieder anbringen.

23. Die Bedienfeldabdeckungen (13) (14) wieder anbringen.

21. Applicare il foglio del pannello operativo (16).

22. Reinstallare il pannello trasparente (15).

23. Reinstallare i coperchi (13) (14) del pannello operativo.

21. 安装操作面板页 (16)。

22. 安装透明面板 (15)。

23. 安装操作面板的盖板 (13) (14)。

21. 조작판넬시트 (16) 를 붙입니다 .


22. 클리어판넬 (15) 를 부착합니다 .

23. 조작판넬 커버 (13) (14) 을 부착합니다 .

21. 操作パネルシート(16)を取り付ける。

22. クリアパネル(15)を取り付ける。

23. 操作パネルのカバー(13)(14)を取り付ける。



Attach the PTT label (for China, 110 V models only).

24. Attach the PTT label (H) after wiping with alcohol.

Fixer l'étiquette d'approbation (pour la Chine, modèles 110 V seulement).

24. Effectuer cette procédure pour les modèles Chine ou 110 V seulement.

Coloque la etiqueta de aprobación (para China, solo para los modelos de 110 V).

24. Realice el procedimiento sólo para los modelos de Chino o 110 V.

Den Genehmigungsaufkleber anbringen (für China nur 110-V-Modelle).

24. Dieses Verfahren nur für die China- oder 110-V-Modelle anwenden.

Applicare l'etichetta di approvazione (per Cina, solo per i modelli da 110 V).

24. Eseguire questa procedura solo per modelli da Cina o 110 V.

粘貼規格標籤（仅限中国、110V 规格）


24. 用酒精清洁后，请在如图所示的位置贴上规格标签（H）。

규격라벨의 부착 (중국, 110V 사양만)

24. 이 순서는 중국, 110V 사양만 실시해 주십시오.

規格ラベルの貼り付け（中国、110V 仕様のみ）

24. この手順は中国、110V 仕様のみおこなう。



Attach the approval label (for Australian/New Zealand model only).

25. Attach the approval label (I) after wiping with alcohol.
Perform this procedure for Australian/New Zealand model only.

When installing the optional Dual FAX (when adding the FAX circuit board to OPT2), proceed to the following procedures. When not installing, proceed to page 23.

Fixer l'étiquette d'approbation (modèle pour l'Australie/Nouvelle-Zélande seulement).

25. Effectuer cette procédure pour le modèle pour l'Australie/Nouvelle-Zélande seulement.

Lorsqu'on installe le FAX double en option (lorsqu'on ajoute la carte à circuits FAX à l'OPT2), effectuer les procédures suivantes. Si on ne l'installe pas, passer à la page 23.

Coloque la etiqueta de aprobación (sólo para los modelos Australiano/Nuevo Zelandés)

25. Realice este procedimiento sólo para los modelos Australiano/Nuevo Zelandés.

Cuando instale el FAX dual opcional (cuando agrega la tarjeta de circuitos de FAX a OPT2), vaya a los siguientes procedimientos. Cuando no lo instala, vaya a la página 23.

Den Genehmigungsaufkleber anbringen (nur für Australien/Neuseeland-Modell).

25. Dieses Verfahren nur für das Australien/Neuseeland-Modell anwenden.

Wenn das optionale Dual FAX installiert wird (Hinzufügen der FAX-Leiterplatte zu OPT2), mit den folgenden Verfahren fortfahren. Erfolgt diese Installation nicht, mit Seite 23 fortfahren.

Applicare l'etichetta di approvazione (solo per il modello Australia/Nuova Zelanda).

25. Eseguire questa procedura solo per il modello Australia/Nuova Zelanda.

Quando si installa il Dual FAX opzionale (quando si aggiunge la scheda a circuiti FAX all'OPT2), continuare con la seguente procedura. Se non si esegue l'installazione passare alla pagina 23.

粘貼规格标签 (仅适用于澳大利亚 / 新西兰型号)

25. 该步骤仅适用于澳大利亚 / 新西兰型号时操作。

安装选购件的多插口组件时 (将传真电路板安装在 OPT2 上时), 请按以下步骤进行。不安装时, 按第 23 页的要求进行操作。

규격라벨의 부착 (오스트레일리아 / 뉴질랜드 사양만)


25. 알코올청소 후 규격라벨 (I) 을 부착합니다 .

옵션 멀티포트를 설치하는 경우 (FAX 기판을 OPT2 에 증설하는 경우) 에는 다음 순서로 진행합니다 . 설치하지 않는 경우에는 23 페이지로 진행합니다 .


規格ラベルの貼り付け (オーストラリア / ニューゼaland仕様のみ)

25. この手順はオーストラリア / ニューゼaland仕様のみおこなう。

オプションのマルチポートを設置する場合 (FAX 基板を OPT2 に増設する場合は、次の手順に進む。設置しない場合は、23 ページへ進む。



**Removing the slot cover
(medium-speed MFPs)**
1. Open the cover (1).



2. Remove 2 screws (2) and then remove the OPT2 slot cover (3).

Install the Dual FAX

Refer to page 1 for the supplied parts.

Installer le FAX double.

Pour plus de détails concernant les pièces fournies, se reporter à la page 1.

**Dépose du couvercle de la fente
(MFP à vitesse moyenne)**

1. Ouvrir le couvercle (1).

2. Déposer les 2 vis (2) puis le couvercle de la fente OPT2 (3).

Instale el FAX dual

Consulte la página 1 de las piezas suministradas.

**Desmontaje de la cubierta de la ranura
(MFP de velocidad media)**

1. Abra la cubierta (1).

2. Quite 2 tornillos (2) y, después, quite la cubierta de la ranura OPT2 (3).

Installieren des Dual FAX

Die mitgelieferten Teile sind auf Seite 1 aufgelistet.

**Entfernen der Einschubabdeckung
(MFP der mittleren Leistungsklasse)**

1. Die Abdeckung (1) öffnen.

2. 2 Schrauben (2) entfernen und dann die Abdeckung (3) des Einschubs OPT2 entfernen.

Installare il Dual FAX

Fare riferimento alla pagina 1 per le parti in dotazione.

**Rimozione del coperchio vano
(MFP a velocità media)**

1. Aprire il coperchio (1).

2. Rimuovere le 2 viti (2) e quindi rimuovere il coperchio (3) del vano OPT2.

安装多插口组件

同装品时, 参照第 1 页。

拆下插槽盖板 (中速 MFP 时)

1. 打开盖板 (1)。

2. 拆除 2 颗螺丝 (2), 拆下 OPT2 的插槽盖板 (3)。

멀티포트 설치

동봉품은 1 페이지를 참조합니다 .

슬롯커버 제거 (중속 MFP 의 경우)

1. 커버 (1) 를 엽니다 .

2. 나사 (2) 2 개를 제거하고 OPT2 의 슬롯커버 (3) 를 제거합니다 .


マルチポートの設置

同梱品は 1 ページを参照する。

スロットカバーの取り外し (中速 MFP の場合)


1. カバー (1) を開ける。

2. ビス (2) 2 本を外し、OPT2 のスロットカバー (3) を取り外す。



Removing the slot cover (For high-speed MFPs and when the finisher is installed)

1.Remove the cover (1).



2.Remove 2 screws (2) and then remove the OPT2 slot cover (3).

Dépose du couvercle de la fente (Pour les MFP à grande vitesse quand le retoucheur est installé)

1.Déposer le couvercle (1).

2.Déposer les 2 vis (2) puis le couvercle de la fente OPT2 (3).

Desmontaje de la cubierta de la ranura (Para las MFP de alta velocidad y cuando el finalizador está instalado)

1.Quite la cubierta (1).

2.Quite 2 tornillos (2) y, después, quite la cubierta de la ranura OPT2 (3).

Entfernen der Einschubabdeckung (Für MFP der Hochleistungsklasse und wenn der Finisher installiert ist)

1.Die Abdeckung (1) entfernen.

2.2 Schrauben (2) entfernen und dann die Abdeckung (3) des Einschubs OPT2 entfernen.

Rimozione del coperchio vano (Per MFP a velocità alta e quando la finitrice è installata)

1.Rimuovere il coperchio (1).

2.Rimuovere le 2 viti (2) e quindi rimuovere il coperchio (3) del vano OPT2.

拆下插槽盖板
(高速 MFP 且安装装订器时)
1. 拆下盖板 (1)。


2. 拆除 2 颗螺丝 (2)，拆下 OPT2 的插槽盖板 (3)。

슬롯커버 제거
(고속 MFP 및 피니셔 장착 시의 경우)
1. 커버 (1) 를 제거합니다 .

2. 나사 (2) 2 개를 제거하고 OPT2 의 슬롯커버 (3) 를 제거합니다 .

スロットカバーの取り外し(高速 MFP および
フィニッシャー装着時の場合)
1. カバー (1) を取り外す。

2. ビス (2) 2 本を外し、OPT2 のスロットカバー (3) を取り外す。



Install the FAX circuit board.

3. Insert the FAX circuit board (A) along the groove in OPT2 and secure the board with two screws (2) that have been removed in step 2.
Do not directly touch the FAX circuit board (A) terminal.
Hold the top and bottom of the FAX circuit board, or the projection of the board to insert the FAX circuit board (A).
Direct the label (4) on to the FAX circuit board (A) toward left side and insert the board along the groove.

Installer la carte à circuits FAX.

3. Insérer la carte à circuits FAX (A) le long de la rainure dans l'OPT2 et la fixer à l'aide des deux vis (2) retirées à l'étape 2.
Ne pas toucher directement la borne de la carte à circuits FAX (A).
Tenir les parties inférieure et supérieure de la carte à circuits FAX ou la saillie de la carte pour insérer la carte à circuits FAX (A).
Orienter l'étiquette (4) de la carte à circuits FAX (A) comme illustré et insérer la plaquette le long de la rainure.

Instale la tarjeta de circuitos de FAX.

3. Inserte la tarjeta de circuitos de fax (A) a lo largo de la ranura de OPT2 y asegúrela con los dos tornillos (2) que ha quitado en el paso 2.
No toque directamente el terminal de la tarjeta de circuitos del FAX (A).
Sujete las partes superior e inferior de la tarjeta de circuitos de FAX o la saliente de la tarjeta para insertar la tarjeta de circuitos de FAX (A).
Oriente la etiqueta (4) en la tarjeta de circuitos del FAX (A) como se indica en la ilustración e inserte la tarjeta a lo largo de la ranura.

Installieren der FAX-Leiterplatte.

3. FAX-Leiterplatte (A) in die Nut des Einbauschachts OPT2 einsetzen und Leiterplatte mit den in Schritt 2 ausgebauten Schrauben (2) befestigen.
Berühren Sie die Anschlüsse der FAX-Platine (A) nicht mit den Fingern.
Die FAX-Leiterplatte (A) beim Einsetzen oben und unten oder an dem Vorsprung festhalten.
Die FAX-Leiterplatte (A) so in die Nut einsetzen, dass der Aufkleber (4) wie abgebildet zur Leiterplatte zeigt.

Installare la scheda a circuiti FAX.

3. Inserire la scheda a circuiti FAX (A) lungo l'incavo nell'OPT2 e fissare la scheda con le due viti (2) rimosse nell'operazione 2.
Non toccare direttamente il terminale della scheda a circuiti FAX (A).
Per inserire il circuito FAX (A), tenere l'estremità superiore e la base della scheda a circuiti FAX, o la sporgenza della scheda a circuiti FAX.
Orientare l'etichetta (4) sulla scheda a circuiti FAX (A) come indicato nell'illustrazione e inserire la scheda lungo l'incavo.

安装传真电路板


3. 沿着 OPT2 的沟槽插入传真电路板 (A) 并用步骤 2 中拆下的两颗螺钉 (2) 固定电路板。
请勿直接接触传真电路板 (A) 端子。
按住传真电路板的顶部和底部, 或者按住电路板的突出部将传真电路板 (A) 插入。
将传真电路板 (A) 上的标签 (7) 保持图示中的方向, 将电路板沿着沟槽方向插入。

FAX 기판 장착

3. OPT2 구에 붙여 FAX 기판 (A) 를 삽입하고 순서 2 에서 제거한 나사 (2) 2 개로 고정합니다.
FAX 기판 (A) 의 단자에 직접 닿지 않게 할 것.
FAX 기판 (A) 을 삽입 시에는 기판의 상하 또는 돌기를 잡을 것.
FAX 기판 (A) 을 붙여진 라벨 (4) 그림 표기 방향대로 되도록 삽입할 것.


FAX 基板の取り付け

3. OPT2 の溝に沿って FAX 基板 (A) を挿入し、手順 2 で外したビス (2) 2 本で固定する。
FAX 基板 (A) の端子に直接触れないこと。
FAX 基板 (A) の挿入時は基板の上下か突起を持つこと。
FAX 基板 (A) は、貼り付けられているラベル (4) が図に示す方向になるように、挿入すること。



Seal the terminal.

4. Wipe the surface of the telephone terminal with alcohol and adhere the terminal seal (C).
The telephone terminal on the FAX circuit board installed to OPT2 is unavailable (invalid). Seal the terminal securely to prevent a user from connecting a separate phone.



On 120 V models, be sure that it is not attached over the top of the approval label (5).

Fermer hermétiquement la borne.

4. Nettoyer la surface de la borne de téléphone avec de l'alcool, et apposer le joint de borne (C).
La borne de téléphone de la carte à circuits FAX installée sur l'OPT2 n'est pas utilisable (invalide). Fermer hermétiquement la borne pour empêcher tout utilisateur de connecter un téléphone séparé.

Sur les modèles 120 V, attention à ne pas installer en recouvrant le haut de l'étiquette d'approbation (5).

Selle el terminal.

4. Limpie la superficie del terminal de teléfono con alcohol y pegue el sello de terminal (C).
El terminal de teléfono de la tarjeta de circuitos de FAX instalado en el OPT2 no está disponible (inválido). Selle firmemente el terminal para evitar que un usuario conecte un teléfono por separado.

En los modelos de 120 V, asegúrese de que no se fije sobre la etiqueta de aprobación (5).

Versiegeln der Anschlussbuchse.

4. Die Oberfläche der Telefonanschlussbuchse mit Alkohol abwischen und die Verschlusskappe (C) anbringen.
Die Telefonanschlussbuchse der in OPT2 installierten FAX-Leiterplatte ist nicht verfügbar (ungültig). Die Anschlussbuchse vollkommen versiegeln, um den Anschluss eines separaten Telefons zu verhindern.

Bei 120-V-Modellen darauf achten, dass der Aufkleber nicht den Genehmigungsaufkleber (5) verdeckt.

Sigillare il terminale.

4. Pulire la superficie del terminale del telefono con alcol e fare aderire la guarnizione terminale (C).
Il terminale del telefono sulla scheda a circuiti FAX installata su OPT2 non è disponibile (invalido). Sigillare il terminale saldamente per prevenire a un utente di collegare un telefono separato.

Sui modelli da 120 V, assicurarsi che essa non venga applicata sopra l'etichetta di approvazione (5).

安装端子密封

4. 用酒精擦拭电话端子表面并粘上端子密封 (C)。
安装在 OPT2 上的传真电路板的电话端子不可使用 (无效)。为了避免用户错误与其它电话连接, 必须确实粘贴好端子密封。

120V 规格在粘贴时注意不要与认可标签 (5) 重叠。

단자씰의 부착


4. TEL 단자주위를 알코올청소하고 단자씰 (C) 을 부착합니다.
OPT2 에 부착한 FAX 기판의 TEL 단자는 사용불가 (무효) 가 됩니다. 사용자가 잘못해 외부 전화를 접속하지 않도록 확실히 부착할 것.

120V 사양은 허가 라벨 (5) 에 겹치지 않도록 붙일 것.

端子シールの貼り付け

4. TEL 端子周围をアルコール清掃し、端子シール (C) を貼り付ける。
OPT2 に取り付けした FAX 基板の TEL 端子は使用不可 (無効) となる。ユーザーが誤って外付け電話を接続しないよう確実に貼り付けること。

120V 仕様は認可ラベル (5) に重ならないように、貼り付けること。



Connect the MFP to the telephone line.

5. Plug the modular connector cable (6) into the line terminal, and then connect the other end to the telephone line.

For 100 V/120 V/Australian or Chinese models, use the supplied modular connector cable (B).

Connecter le MFP à la ligne de téléphone.

5. Brancher le câble du connecteur modulaire (6) à la borne de la ligne, puis connecter l'autre extrémité à la ligne de téléphone.

Pour les modèles 100 V/120 V/Australie ou Chine, utilisez le câble à connecteur modulaire (B) fourni.

Conecte el MFP a la línea telefónica.

5. Enchufe el cable del conector modular (6) en el terminal de línea y, a continuación, conecte el otro extremo a la línea telefónica.

Para los modelos de 100 V/120 V/Australiano o Chino, utilice el cable conector modular (B) suministrado.

Anschließen des MFP an die Telefonleitung.

5. Telefonmodulkabel (6) in die Gerätebuchse einstecken und das Kabel an der Telefondose anschließen.

Das mitgelieferte Modularsteckerkabel (B) für die 100-V/120-V/Australien- oder China-Modelle verwenden.

Collegamento dell'MFP alla linea del telefono.

5. Inserire il cavo connettore modulare (6) nel terminale della linea, e quindi collegare l'altro terminale alla linea del telefono.

Per modelli da 100 V/120 V/Australia o Cina, utilizzare il cavo connettore modulare (B) in dotazione.

将 MFP 连接到电话线

5. 将模块接插件电缆 (6) 插入电话线端子, 然后将另一端与电话线连接。

对于 100V/120V/ 澳大利亚或中国机型, 请使用随附的模块接插件电缆 (B)。

전화회선과의 접속


5. 모듈코드 (6) 를 라인단자에 꼽습니다. 다른 한 쪽의 플러그는 전화회선과 접속합니다.

100V/120V/ 오스트레일리아 / 중국사양은 부속 모듈코드 (B) 를 사용할 것.

電話回線との接続

5. モジュラーコード (6) をライン端子に差し込む。もう片方のプラグは、電話回線へ接続する。

100V/120V/ オーストラリア / 中国仕様は付属のモジュラーコード (B) を使用すること。



**Wiring the modular connector cable
(High-speed MFPs only)**

6. Remove the covers (7) and run the modular connector cable as shown in the figure.

7. Reinstall the covers (7).

(Medium-speed MFPs)

8. Close the cover (1).

(For high-speed MFPs and when the finisher is installed)

8. Reinstall the cover (1).

**Câblage du câble à connecteur modulaire
(MFP à grande vitesse uniquement)**

6. Déposer les couvercles (7) et implanter le câble à connecteur modulaire comme illustré par la figure.

7. Reposer les couvercles (7).

(MFP à vitesse moyenne)

8. Fermer le couvercle (1).

(Pour les MFP à grande vitesse quand le retoucheur est installé)

8. Reposer le couvercle (1).

**Tendido del cable conector modular
(Solo para las MFP de alta velocidad)**

6. Quite las cubiertas (7) y tienda el cable conector modular como se muestra en la ilustración.

7. Vuelva a instalar las cubiertas (7).

(MFP de velocidad media)

8. Cierre la cubierta (1).

(Para las MFP de alta velocidad y cuando el finalizador está instalado)

8. Vuelva a instalar la cubierta (1).

**Verlegung des Modularsteckerkabels
(Nur MFP der Hochleistungsklasse)**

6. Die Abdeckungen (7) entfernen und das Modularsteckerkabel gemäß der Abbildung verlegen.

7. Die Abdeckungen (7) wieder anbringen.

(MFP der mittleren Leistungsklasse)

8. Die Abdeckung (1) schließen.

(Für MFP der Hochleistungsklasse und wenn der Finisher installiert ist)

8. Die Abdeckung (1) wieder anbringen.

**Cablaggio del cavo connettore modulare
(Solo per MFP a velocità alta)**

6. Rimuovere i coperchi (7) e far passare il cavo connettore modulare come indicato nella figura.

7. Reinstallare i coperchi (7).

(Per MFP a velocità media)

8. Chiudere il coperchio (1).

(Per MFP a velocità alta e quando la finitrice è installata)

8. Reinstallare il coperchio (1).

电话线的配线 (仅限高速 MFP 时)

6. 拆下盖板 (7), 将电话线如图所示穿过。

7. 安装盖板 (7)。

(中速 MFP 时)

8. 关闭盖板 (1)。

(高速 MFP 且安装装订器时)

8. 安装盖板 (1)。

모듈코드의 배선 (고속 MFP 의 경우만)

6. 커버 (7) 를 떼어 내고 모듈코드를 그림과 같이 지나가게 합니다 .

7. 커버 (7) 을 장착합니다 .

(중속 MFP 의 경우)

8. 커버 (1) 를 닫습니다 .

(고속 MFP 및 피니셔 장착 시의 경우)

8. 커버 (1) 를 장착합니다 .

モジュラーコードの配線 (高速 MFP の場合のみ)

6. カバー (7) を取り外し、モジュラーコードを図のように通す。

7. カバー (7) を取り付ける。

(中速 MFP の場合)

8. カバー (1) を開める。

(高速 MFP およびフィニッシャー装着時の場合)

8. カバー (1) を取り付ける。

Initialize the FAX circuit board.

1. Plug the MFP into a power outlet, and turn on the main power.
2. If the FAX circuit board has been installed only in OPT1 or installed both in OPT1 and OPT2 (to initialize all FAX circuit boards) Perform the maintenance mode U600 to initialize the fax control assembly.

3. If the FAX circuit board has been added to OPT2 (to initialize the FAX circuit board in OPT2)

Initialize OPT2 by pressing [PORT2], and the Start key in this order in the maintenance mode U698 and executing the maintenance mode U600. If [ALL] is selected in U698, both OPT1 and OPT2 are initialized. For details, see the service manual. Refer to the operation guide to create a FAX Box.

Initialiser la carte à circuits FAX.

1. Brancher le MFP sur une prise d'alimentation et le mettre sous tension.
2. Si la carte à circuits FAX a été installée dans l'OPT1 seulement, ou a été installée dans l'OPT1 et dans l'OPT2 (pour initialiser toutes les cartes à circuits FAX) Exécuter le mode de maintenance U600 pour initialiser l'ensemble de commande de fax.

3. Si la carte à circuits FAX a été ajoutée à l'OPT2 (pour initialiser la carte à circuits FAX dans l'OPT2)

Initialiser l'OPT2 en appuyant sur [PORT2] et la touche Départ dans cet ordre en mode de maintenance U698, et exécuter le mode de maintenance U600. Si [ALL] est sélectionné dans U698, l'OPT1 et l'OPT2 sont tous deux initialisés. Pour plus de détails, se reporter au manuel d'entretien. Se reporter au manuel d'utilisation pour créer une Boîte de FAX.

Inicialice la tarjeta de circuitos FAX.

1. Conecte el MFP a un receptáculo de pared y encienda el interruptor principal.
2. Si la tarjeta de circuitos de FAX se instaló solo en OPT1 o se instaló tanto en OPT1 como OPT2 (para inicializar todas las tarjetas de circuito de FAX) Ejecute el modo de mantenimiento U600 para inicializar el conjunto de control de fax.

3. Si la tarjeta de circuitos de FAX se agregó a OPT2 (para inicializar la tarjeta de circuitos de FAX en OPT2)

Inicialice el OPT2 presionando [PORT2] y la tecla de Inicio en ese orden en el modo de mantenimiento U698 y ejecutando el modo de mantenimiento U600. Si se selecciona [ALL] en U698, se inicializan ambos OPT1 y OPT2. Para más detalles, lea el manual de servicio. Consulte la guía de uso para crear un Buzón de FAX.

Initialisieren der FAX-Leiterplatte.

1. Netzstecker des MFP in eine Steckdose stecken und Hauptschalter einschalten.
2. Wenn die FAX-Leiterplatte nur in OPT1 oder sowohl in OPT1 als auch in OPT2 installiert worden ist (um alle FAX-Leiterplatten zu initialisieren) Wartungsmodus U600 ausführen, um die Faxsteuerbaugruppe zu initialisieren.

3. Wenn die FAX-Leiterplatte zu OPT2 hinzugefügt worden ist (um die FAX-Leiterplatte in OPT2 zu initialisieren)

OPT2 initialisieren. Dazu [PORT2] und die Start-Taste im Wartungsmodus U698 in dieser Reihenfolge drücken und den Wartungsmodus U600 ausführen. Wenn [ALL] in U698 gewählt wird, werden OPT1 und OPT2 initialisiert. Weitere Einzelheiten siehe Wartungsanleitung. Schlagen Sie zur Erzeugung einer FAX-Box in der Einführung nach.

Inizializzare la scheda a circuiti FAX.

1. Collegare l'MFP ad una presa di corrente e portare l'interruttore principale su On.
2. Se la scheda a circuiti FAX è stata installata solo nell'OPT1 o in entrambi l'OPT1 e l'OPT2 (per inicializzare tutte le schede di circuito FAX) Eseguire il modo di manutenzione U600 per inicializzare il gruppo di controllo fax.

3. Se la scheda a circuiti è stata aggiunta all'OPT2 (per inicializzare la scheda a circuiti FAX nell'OPT2)

Inizializzare OPT2 premendo [PORT2] e il tasto Avvio in questo ordine nel modo di manutenzione U698 ed eseguendo il modo di manutenzione U600. Se viene selezionato [ALL] nel modo U698, entrambi OPT1 e OPT2 sono inicializzati. Per ulteriori dettagli leggere il manuale d'istruzioni. Leggere la guida alle funzioni per creare una Casella FAX.

传真电话板的初始化

1. 将 MFP 插入电源插座，打开主电源。
2. 仅限于在 OPT1 或 OPT1 和 OPT2 上同时安装传真电路板时（全部的传真电路板初始化）
执行维修保养模式 U600，初始化传真控制组件

3. 在 OPT2 上增设时

(OPT2 的传真电路板初始化)
只进行 OPT2 初始化时，在维修保养模式 U698 状态下，按顺序按下“PORT2”、开始键，执行维修保养模式 U600。
在 U698 状态下设定“ALL”时，会使 OPT1 和 OPT2 均初始化。
有关详细信息，请参见维修手册。参照操作手册，作成传真盒。

FAX 기판의 초기화

1. MFP 본체 전원플러그를 콘센트에 꼽고 주 전원 스위치를 ON 으로 한다.
2. OPT1 만 또는 OPT1 와 OPT2 에 FAX 기판을 동시에 설치한 경우 (전부 FAX 기판을 초기화) 메인터너스 모드 U600 을 실행하고 FAX 기판을 초기화합니다.

3. OPT2 에 증설한 경우 (OPT2 의 FAX 기판을 초기화)

메인터너스 모드 U698 에서 「PORT2」, 시작키 순으로 누릅니다. 메인터너스 모드 U600 을 실행하고 FAX 기판을 초기화합니다.
U698 에서 「ALL」을 설정하면 OPT1 과 OPT2 양쪽을 초기화하기 때문에 주의할 것.
상세는 서비스 매뉴얼을 참조할 것.
사용설명서를 참조해 팩스박스를 작성합니다.



FAX 基板の初期化







1. MFP 本体の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。
2. OPT1 のみまたは OPT1 と OPT2 に FAX 基板を同時に設置した場合（すべての FAX 基板を初期化）メンテナンスモード U600 を実行し、FAX 基板を初期化する。

3. OPT2 に増設した場合 (OPT2 の FAX 基板を初期化)

メンテナンスモード U698 で「PORT2」、スタートキーの順に押す。メンテナンスモード U600 を実行し、FAX 基板を初期化する。
U698 で「ALL」を設定すると OPT1 と OPT2 両方を初期化するので注意すること。詳細はサービスマニュアルを参照のこと。
使用説明書を参照し、ファクスボックスを作成する。

INSTALLATION GUIDE FOR DOCUMENT TABLE



4**5****6****7**

(ENG) If the right job separator is not installed, proceed to step 8.

(FR) Si le séparateur de travaux correspondant n'est pas installé, passer à l'étape 8.

(ES) Si no está instalado el separador de trabajos derecho, vaya al paso 8.

(DE) Gehen Sie weiter zu Schritt 8, falls der rechte Job-Separator nicht installiert ist.

(IT) Se il separatore lavori destro non è installato, procedere al punto 8.

(CN) 如果没有安装右作业分离器，请进入步骤8。

(KO) 우측 작업 분류기가 설치되어 있지 않은 경우 순서 8로 진행합니다.

(JP) 右ジョブセパレーターが設置されていない場合、手順8へ進む。

(ENG) If the right job separator is installed, proceed to step 10.

(FR) Si le séparateur de travaux correspondant est installé, passer à l'étape 10.

(ES) Si está instalado el separador de trabajos derecho, vaya al paso 10.

(DE) Gehen Sie weiter zu Schritt 10, falls der rechte Job-Separator installiert ist.


(IT) Se il separatore lavori destro è installato, procedere al punto 10.

(CN) 如果安装了右作业分离器，请进入步骤10。


(KO) 우측 작업 분류기가 설치되어 있는 경우 순서 10로 진행합니다.







(JP) 右ジョブセパレーターが設置されている場合、手順10へ進む。







8





9






15**16****17****18**



19










20




INSTALLATION GUIDE FOR PRINTING SYSTEM









12



13




14






15



Color MFP 30/30, 35/35, 45/45, 55/50







Color MFP 65/65, 75/70



16



 NETWORK



KYOCERA Document Solutions America, Inc.**Headquarters**

225 Sand Road,
Fairfield, New Jersey 07004-0008, USA
Phone: +1-973-808-8444
Fax: +1-973-882-6000

Latin America

8240 NW 52nd Terrace Dawson Building, Suite 100
Miami, Florida 33166, USA
Phone: +1-305-421-6640
Fax: +1-305-421-6666

KYOCERA Document Solutions Canada, Ltd.

6120 Kestrel Rd., Mississauga, ON L5T 1S8,
Canada
Phone: +1-905-670-4425
Fax: +1-905-670-8116

**KYOCERA Document Solutions
Mexico, S.A. de C.V.**

Calle Arquimedes No. 130, 4 Piso, Colonia Polanco
Chapultepec, Delegacion Miguel Hidalgo,
Distrito Federal, C.P. 11560, México
Phone: +52-555-383-2741
Fax: +52-555-383-7804

KYOCERA Document Solutions Brazil, Ltda.

Av. Tambore, 1180 Mod. B-09 CEP 06460-000
Tambore-Barueri-SP, Brazil
Phone: +55-11-4195-8496
Fax: +55-11-4195-6167

**KYOCERA Document Solutions
Australia Pty. Ltd.**

Level 3, 6-10 Talavera Road North Ryde N.S.W, 2113,
Australia
Phone: +61-2-9888-9999
Fax: +61-2-9888-9588

**KYOCERA Document Solutions
New Zealand Ltd.**

Ground Floor, 19 Byron Avenue, Takapuna, Auckland,
New Zealand
Phone: +64-9-415-4517
Fax: +64-9-415-4597

KYOCERA Document Solutions Asia Limited

16/F., Mita Centre, 552-566, Castle Peak Road
Tsuenwan, NT, Hong Kong
Phone: +852-2610-2181
Fax: +852-2610-2063

**KYOCERA Document Solutions
(China) Corporation**

8F, No. 288 Nanjing Road West, Huangpu District,
Shanghai, 200003, China
Phone: +86-21-5301-1777
Fax: +86-21-5302-8300

**KYOCERA Document Solutions
(Thailand) Corp., Ltd.**

335 Ratchadapisek Road, Bangsue, Bangkok 10800,
Thailand
Phone: +66-2-586-0333
Fax: +66-2-586-0278

**KYOCERA Document Solutions
Singapore Pte. Ltd.**

12 Tai Seng Street #04-01A,
Luxasia Building, Singapore 534118
Phone: +65-6741-8733
Fax: +65-6748-3788

**KYOCERA Document Solutions
Hong Kong Limited**

16/F., Mita Centre, 552-566, Castle Peak Road
Tsuenwan, NT, Hong Kong
Phone: +852-3582-4000
Fax: +852-3185-1399

**KYOCERA Document Solutions
Taiwan Corporation**

6F., No. 37, Sec. 3, Minquan E. Rd.,
Zhongshan Dist., Taipei 104, Taiwan R.O.C.
Phone: +886-2-2507-6709
Fax: +886-2-2507-8432

KYOCERA Document Solutions Korea Co., Ltd.

18F, Kangnam bldg, 1321-1,
Seocho-Dong, Seocho-Gu, Seoul, Korea
Phone: +822-6933-4050
Fax: +822-747-0084

**KYOCERA Document Solutions
India Private Limited**

First Floor, ORCHID CENTRE
Sector-53, Golf Course Road, Gurgaon 122 002,
India
Phone: +91-0124-4671000
Fax: +91-0124-4671001

KYOCERA Document Solutions Europe B.V.

Bloemlaan 4, 2132 NP Hoofddorp,
The Netherlands
Phone: +31-20-654-0000
Fax: +31-20-653-1256

KYOCERA Document Solutions Nederland B.V.

Beechavenue 25, 1119 RA Schiphol-Rijk,
The Netherlands
Phone: +31-20-5877200
Fax: +31-20-5877260

KYOCERA Document Solutions (U.K.) Limited

Eldon Court, 75-77 London Road,
Reading, Berkshire RG1 5BS,
United Kingdom
Phone: +44-118-931-1500
Fax: +44-118-931-1108

KYOCERA Document Solutions Italia S.p.A.

Via Verdi, 89/91 20063 Cernusco s/N.(MI),
Italy
Phone: +39-02-921791
Fax: +39-02-92179-600

KYOCERA Document Solutions Belgium N.V.

Sint-Martinusweg 199-201 1930 Zaventem,
Belgium
Phone: +32-2-7209270
Fax: +32-2-7208748

KYOCERA Document Solutions France S.A.S.

Espace Technologique de St Aubin
Route de l'Orme 91195 Gif-sur-Yvette CEDEX,
France
Phone: +33-1-69852600
Fax: +33-1-69853409

KYOCERA Document Solutions Espana, S.A.

Edificio Kyocera, Avda. de Manacor No.2,
28290 Las Matas (Madrid), Spain
Phone: +34-91-6318392
Fax: +34-91-6318219

KYOCERA Document Solutions Finland Oy

Atomitie 5C, 00370 Helsinki,
Finland
Phone: +358-9-47805200
Fax: +358-9-47805390

KYOCERA Document Solutions**Europe B.V., Amsterdam (NL) Zürich Branch**

Hohlstrasse 614, 8048 Zürich,
Switzerland
Phone: +41-44-9084949
Fax: +41-44-9084950

KYOCERA Document Solutions**Deutschland GmbH**

Otto-Hahn-Strasse 12, 40670 Meerbusch,
Germany
Phone: +49-2159-9180
Fax: +49-2159-918100

KYOCERA Document Solutions Austria GmbH

Eduard-Kittenberger-Gasse 95, 1230 Vienna,
Austria
Phone: +43-1-863380
Fax: +43-1-86338-400

KYOCERA Document Solutions Nordic AB

Esbogatan 16B 164 75 Kista, Sweden
Phone: +46-8-546-550-00
Fax: +46-8-546-550-10

KYOCERA Document Solutions Norge Nuf

Postboks 150 Oppsal, 0619 Oslo,
Norway
Phone: +47-22-62-73-00
Fax: +47-22-62-72-00

KYOCERA Document Solutions Danmark A/S

Ejby Industrivej 60, DK-2600 Glostrup,
Denmark
Phone: +45-70223880
Fax: +45-45765850

KYOCERA Document Solutions Portugal Lda.

Rua do Centro Cultural, 41 (Alvalade) 1700-106 Lisboa,
Portugal
Phone: +351-21-843-6780
Fax: +351-21-849-3312

KYOCERA Document Solutions**South Africa (Pty) Ltd.**

KYOCERA House, Hertford Office Park,
90 Bekker Road (Cnr. Allandale), Midrand, South Africa.
Phone: +27-11-540-2600
Fax: +27-11-466-3050

KYOCERA Document Solutions Russia LLC

Botanichesky pereulok 5, Moscow, 129090,
Russia
Phone: +7(495)741-0004
Fax: +7(495)741-0018

KYOCERA Document Solutions Middle East

Dubai Internet City, Bldg. 17,
Office 157 P.O. Box 500817, Dubai,
United Arab Emirates
Phone: +971-04-433-0412

KYOCERA Document Solutions Inc.

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: +81-6-6764-3555
<http://www.kyoceradocumentsolutions.com>