



TASKalfa 306ci
TASKalfa 356ci
TASKalfa 406ci
PF-5120/5130/5140
DP-5100/5110
AK-5100/JS-5100
DF-5100/5110/5120
PH-5100/5110/MT-5100
FAX System 10/11

**SERVICE
MANUAL**

Published in April 2016
842R4115
2R4SM065
Rev.5

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

It may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for proper disposal.

ATTENTION

IL Y A UN RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UN MODÈLE DE TYPE INCORRECT. METTRE AU REBUT LES BATTERIES UTILISÉES SELON LES INSTRUCTIONS DONNÉES.

Il peut être illégal de jeter les batteries dans des eaux d'égout municipales. Vérifiez avec les fonctionnaires municipaux de votre région pour les détails concernant des déchets solides et une mise au rebut appropriée.

Notation of products in the manual

For the purpose of this service manual, products are identified by print speed.

| | | 100 V | 120 V | 220-240 V | Australia |
|----------------|----------|-------|-------|-----------|-----------|
| TASKalfa 306ci | : 30 ppm | × | ○ | ○ | ○ |
| TASKalfa 356ci | : 35 ppm | ○ | ○ | ○ | ○ |
| TASKalfa 406ci | : 40 ppm | ○ | ○ | ○ | ○ |

Revision history

| Revision | Date | Pages | Revised contents |
|----------|---|----------------------------------|---|
| 1 | 15 October 2015 | contents | Correction: Added the contents and correct the title |
| | | 1-4 | Correction: 1200 dpi equivalent → 9600 dpi equivalent |
| | | 2-25, 2-27 | Change: the level indicator of the loaded paper |
| | | 4-4 | Added: Exchange time (MK-3140 / MK-5200) |
| | | 4-6 to 24 | Added: Periodic maintenance Procedures |
| | | 4-62 | Delete: *: When replacing the new drum unit,..... |
| | | 4-136, 4-157 4-173, 4-201 | Delete: FFC unlock procedure |
| | | 4-152, 4-160 | Correction: imaging motor → transfer motor |
| | | 4-159, 4-167 | Added: Grease applied to the gear portion |
| | | 4-212 | Correction: Additional procedure for removing the connector |
| | | 4-186, 4-214 | Added: FFC unlock procedure |
| | | 6-99, 6-319 | Change: Folio size → 330 mm fixed |
| | | 6-103 | Added: Display conditions of the items |
| | | 7-43 | Correction: C3800 ("AEF" → "AFE") |
| | | 7-134 | Added: Factor and corrective action |
| 9-5 | Correction: Initial values of S3 and S4 | | |
| 2 | 4 November 2015 | contents | Correction: title of contents of 1-4 |
| | | 1-1 | Delete: Hagaki in paper size / cassette Correction: Warm-up Time (50% → 60%) |
| | | 1-3 | Correction: Copy speed (40 ppm model) : Conditions of the first Copy time |
| | | 1-4 | Correction: Conditions of the first print time : Conditions of the Scanner speed |
| | | 1-6 | Added: Inch size in Paper size (Document processor) |
| | | 1-13, 1-15 | Correction: Description of Job Accounting |
| | | 1-34 | Added: 35/40ppm models only (UG-34) |
| | | 1-35, 1-36 | Correction: title of contents of 1-4 : Unit description Delete: Toner |
| | | 3-33, 3-36 3-39 8-64, 9-26 | Added: 40 ppm model only |
| | | 4-159 | Correction: Motor mounting plate and screw the number (3 → 2) |
| | | 6-2, 6-35 6-196, 6-231 | Delete: U039 |
| | | 6-7, 6-190 | Delete: U942 (30 ppm model) |

| Revision | Date | Pages | Revised contents |
|-----------------|----------------------------|--|--|
| 2 | 4 November 2015 | 6-420 | Correction: U942 (35/40 ppm models) |
| | | 6-20, 6-214 | Correction: U002 |
| 3 | 27 November 2015 | contents | Correction: Content's pages of 1-7 |
| | | 3-96, 3-97 3-99, 3-100 | Correction: Figure 3-97 to 3-99, Figure 3-102 to 3-104 |
| | | 6-117 to 119 6-337 to 342 | Correction: Procedure of DP automatic adjustment |
| | | 7-4 to 99 | Correction |
| | | 9-3 | Correction: Initial values of N5 |
| 4 | 29 January 2016 | contents | Correction: Page number |
| | | 1-1 | Correction: Paper weight (Cassette) 163→220 |
| | | 1-2 | Correction: eKUIO: 2→1, FAX: 1 |
| | | 1-8 | Delete: Paper Weight |
| | | 2-29 | Correction: The description of the setup wizard |
| | | 4-32, 4-33, 4-35, 4-37, 4-39, 4-43 | Correction: Calib → Calib (Full) |
| | | 4-33 | Correction: Figure4-15 |
| | | 6-7, 6-193 | Added: U964 |
| | | 6-88, 6-303, 6-304 | Correction: Rotation direction of the exit motor |
| 9-22 | Delete: coin vender (YC32) | | |
| 5 | 22 April 2016 | 2-2 | Added:Annotation |
| | | 2-18, 2-69, 2-71 | Correction: Changing the shape of the connector cover |
| | | 2-32 | Correction: Procedure for 40 ppm model |
| | | 2-44 | Added:Patrs number of the Key counter wire |
| | | 4-28, 4-31 4-49, 4-53 4-57 | Correction: Procedure |
| | | 6-47 | Correction:direction of setting values on U072 |
| | | 6-199, 6-301, 6-302 | Added: U224 |
| | | 6-320 | Added: Initial values in U250 |
| | | 7-3 | Added: J0300 |





Safety precautions


This booklet provides safety warnings and precautions for our service personnel to ensure the safety of their customers, their machines as well as themselves during maintenance activities. Service personnel are advised to read this booklet carefully to familiarize themselves with the warnings and precautions described here before engaging in maintenance activities.

Safety warnings and precautions

Various symbols are used to protect our service personnel and customers from physical danger and to prevent damage to their property. These symbols are described below:

 **DANGER:** High risk of serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

 **WARNING:** Serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

 **CAUTION:** Bodily injury or damage to property may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

Symbols

The triangle (\triangle) symbol indicates a warning including danger and caution. The specific point of attention is shown inside the symbol.



General warning.



Warning of risk of electric shock.



Warning of high temperature.

 indicates a prohibited action. The specific prohibition is shown inside the symbol.



General prohibited action.



Disassembly prohibited.

 indicates that action is required. The specific action required is shown inside the symbol.



General action required.





Remove the power plug from the wall outlet.











Always ground the copier.

1. Installation Precautions

WARNING











- Do not use a power supply with a voltage other than that specified. Avoid multiple connections to one outlet: they may cause fire or electric shock. When using an extension cable, always check that it is adequate for the rated current. 
- Connect the ground wire to a suitable grounding point. Not grounding the copier may cause fire or electric shock. Connecting the earth wire to an object not approved for the purpose may cause explosion or electric shock. Never connect the ground cable to any of the following: gas pipes, lightning rods, ground cables for telephone lines and water pipes or faucets not approved by the proper authorities. 

CAUTION:





- Do not place the copier on an infirm or angled surface: the copier may tip over, causing injury. 
- Do not install the copier in a humid or dusty place. This may cause fire or electric shock. 
- Do not install the copier near a radiator, heater, other heat source or near flammable material. This may cause fire. 
- Allow sufficient space around the copier to allow the ventilation grills to keep the machine as cool as possible. Insufficient ventilation may cause heat buildup and poor copying performance. 
- Always handle the machine by the correct locations when moving it. 
- Always use anti-toppling and locking devices on copiers so equipped. Failure to do this may cause the copier to move unexpectedly or topple, leading to injury. 
- Avoid inhaling toner or developer excessively. Protect the eyes. If toner or developer is accidentally ingested, drink a lot of water to dilute it in the stomach and obtain medical attention immediately. If it gets into the eyes, rinse immediately with copious amounts of water and obtain medical attention. 
- Advise customers that they must always follow the safety warnings and precautions in the copier's instruction handbook. 












2. Precautions for Maintenance

WARNING

- Always remove the power plug from the wall outlet before starting machine disassembly. 
- Always follow the procedures for maintenance described in the service manual and other related brochures. 
- Under no circumstances attempt to bypass or disable safety features including safety mechanisms and protective circuits. 
- Always use parts having the correct specifications. 
- Always use the thermostat or thermal fuse specified in the service manual or other related brochure when replacing them. Using a piece of wire, for example, could lead to fire or other serious accident. 
- When the service manual or other serious brochure specifies a distance or gap for installation of a part, always use the correct scale and measure carefully. 
- Always check that the copier is correctly connected to an outlet with a ground connection. 
- Check that the power cable covering is free of damage. Check that the power plug is dust-free. If it is dirty, clean it to remove the risk of fire or electric shock. 
- Never attempt to disassemble the optical unit in machines using lasers. Leaking laser light may damage eyesight. 
- Handle the charger sections with care. They are charged to high potentials and may cause electric shock if handled improperly. 



CAUTION

- Wear safe clothing. If wearing loose clothing or accessories such as ties, make sure they are safely secured so they will not be caught in rotating sections. 
- Use utmost caution when working on a powered machine. Keep away from chains and belts. 
- Handle the fixing section with care to avoid burns as it can be extremely hot. 
- Check that the fixing unit thermistor, heat and press rollers are clean. Dirt on them can cause abnormally high temperatures. 

- Do not remove the ozone filter, if any, from the copier except for routine replacement. 
- Do not pull on the AC power cord or connector wires on high-voltage components when removing them; always hold the plug itself. 
- Do not route the power cable where it may be stood on or trapped. If necessary, protect it with a cable cover or other appropriate item. 
- Treat the ends of the wire carefully when installing a new charger wire to avoid electric leaks. 
- Remove toner completely from electronic components. 
- Run wire harnesses carefully so that wires will not be trapped or damaged. 
- After maintenance, always check that all the parts, screws, connectors and wires that were removed, have been refitted correctly. Special attention should be paid to any forgotten connector, trapped wire and missing screws. 
- Check that all the caution labels that should be present on the machine according to the instruction handbook are clean and not peeling. Replace with new ones if necessary. 
- Handle greases and solvents with care by following the instructions below: 
- Use only a small amount of solvent at a time, being careful not to spill. Wipe spills off completely.
- Ventilate the room well while using grease or solvents.
- Allow applied solvents to evaporate completely before refitting the covers or turning the power switch on.
- Always wash hands afterwards.
- Never dispose of toner or toner bottles in fire. Toner may cause sparks when exposed directly to fire in a furnace, etc. 
- Should smoke be seen coming from the copier, remove the power plug from the wall outlet immediately. 

3. Miscellaneous

WARNING

- Never attempt to heat the drum or expose it to any organic solvents such as alcohol, other than the specified refiner; it may generate toxic gas. 
- Keep the machine away from flammable liquids, gases, and aerosols. A fire or an electric shock might occur. 

This page is intentionally left blank.

CONTENTS

1 Specifications

| | |
|--|------|
| 1-1 Specifications | 1-1 |
| (1) Common function | 1-1 |
| (2) Copy Functions..... | 1-3 |
| (3) Printer Functions | 1-4 |
| (4) Scanner Functions..... | 1-4 |
| (5) Document Processor: 30ppm model standard | 1-5 |
| (6) Option | 1-6 |
| (6-1) Document Processor (DP-5100/5110) 35/40ppm models only | 1-6 |
| (6-2) Paper Feeder (PF-5120) | 1-6 |
| (6-3) Paper Feeder (PF-5130) | 1-7 |
| (6-4) Paper Feeder (PF-5140) | 1-7 |
| (6-5) Inner finisher (DF-5100) | 1-8 |
| (6-6) 1000-sheet Finisher (DF-5110): 35/40ppm models only | 1-9 |
| (6-7) 3000-sheet Finisher (DF-5120): 35/40ppm models only | 1-10 |
| (6-8) Punch Unit (PH-5100/5110): For DF-5110..... | 1-11 |
| (6-9) Mailbox (MT-5100) | 1-11 |
| (6-10) Inner job separator (JS-5100) | 1-11 |
| (6-11) FAX System10: 35/40ppm models only | 1-12 |
| (6-12) FAX System11: 30ppm model only | 1-14 |
| 1-2 Part Names..... | 1-16 |
| (1) 30 ppm model..... | 1-16 |
| (1-1) Machine Exterior | 1-16 |
| (1-2) Connectors/Interior..... | 1-18 |
| (1-3) With Optional Equipments Attached..... | 1-19 |
| (1-4) FAX System 11 | 1-20 |
| (1-5) Operation Panel Keys | 1-21 |
| (2) 35/40 ppm models | 1-22 |
| (2-1) Machine Exterior | 1-22 |
| (2-2) Connectors/Interior..... | 1-24 |
| (2-3) With Optional Equipments Attached..... | 1-25 |
| (2-4) FAX System 10 | 1-26 |
| (2-5) Operation Panel Keys | 1-27 |
| 1-3 Optional Equipment | 1-28 |
| (1) 30 ppm model..... | 1-28 |
| (2) 35/40 ppm models | 1-30 |
| (3) Option | 1-32 |
| (3-1) DP-5100 "Document Processor (Reverse Automatic)": 35/40ppm models only | 1-32 |
| (3-2) DP-5110 "Document Processor (Dual Scan)": 35/40ppm models only | 1-32 |
| (3-3) MT-5100 "Mailbox" | 1-32 |
| (3-4) DF-5110 "1,000-Sheet Finisher": 35/40ppm models only | 1-32 |
| (3-5) DF-5120 "3,000-Sheet Finisher": 35/40ppm models only | 1-32 |
| (3-6) PF-5120 "Paper Feeder (500-sheet)"..... | 1-32 |
| (3-7) PF-5130 "Paper Feeder (500-sheet x2)"..... | 1-32 |
| (3-8) PF-5140 "Large Capacity Feeder (2,000-sheet)" | 1-32 |
| (3-9) JS-5100 "Job Separator" | 1-32 |
| (3-10) DF-5100 "Inner Finisher" | 1-32 |
| (3-11) PH-5100*1, 5110*2 "Punch Unit": 35/40ppm models only (*1: inch, *2: metric) | 1-32 |
| (3-12) FAX System 10 "FAX Kit": 35/40ppm models only | 1-33 |

| | |
|--|------|
| (3-13) FAX System 11 "FAX Kit": 30ppm model only | 1-33 |
| (3-14) IB-50 "Network Interface Kit" | 1-33 |
| (3-15) IB-51 "Wireless Network Interface Kit" | 1-33 |
| (3-16) MM-16-128 "FAX Expansion Memory": 35/40ppm models only | 1-33 |
| (3-17) HD-11 "Hard Disk": 35ppm model only | 1-33 |
| (3-18) Key Counter "Key Counter": 35/40ppm models only | 1-33 |
| (3-19) MK-2 "Key card": 35/40 ppm models only | 1-33 |
| (3-20) Card Authentication Kit(B) "Card Authentication Kit" | 1-33 |
| (3-21) "Expansion Memory": 30ppm model only | 1-33 |
| (3-22) "SD/SDHC Memory Card" | 1-34 |
| (3-23) DT-5100 "Document Table" | 1-34 |
| (3-24) Internet FAX Kit(A) "Internet FAX Kit": 35/40ppm models only | 1-34 |
| (3-25) Data Security Kit(E) "Data Security Kit" | 1-34 |
| (3-26) UG-33 "ThinPrint Option" | 1-34 |
| (3-27) UG-34 "Emulation Upgrade Kit": 35/40ppm models only | 1-34 |
| (3-28) Scan extension kit(A) "OCR Scan Activation Kit": 35/40ppm models only | 1-34 |
| 1-4 Unit Compatibility | 1-35 |

2 Installation

| | |
|---|------|
| 2-1 Environment | 2-1 |
| 2-2 Installing the main unit | 2-2 |
| (1) Unpacking and checking bundled items | 2-3 |
| (1-1) 30 ppm model | 2-3 |
| (1-2) 35/40 ppm models | 2-4 |
| (2) Unpacking and checking bundled items(option units) | 2-5 |
| (2-1) Paper Feeder(PF-5120) | 2-5 |
| (2-2) Paper Feeder(PF-5130) | 2-6 |
| (2-3) Paper Feeder(PF-5140) | 2-7 |
| (2-4) Document processor(DP-5100): 35/40 ppm models only | 2-8 |
| (2-5) Document processor(DP-5110): 35/40 ppm models only | 2-9 |
| (2-6) Inner finisher(DF-5100) | 2-10 |
| (2-7) 1000-sheet finisher(DF-5110): 35/40 ppm models only | 2-11 |
| (2-8) 3000-sheet finisher(DF-5120): 35/40 ppm models | 2-12 |
| (2-9) Mailbox(MT-5100) | 2-13 |
| (2-10) Punch unit(PH-5110) | 2-14 |
| (3) Notes on main unit transportation | 2-15 |
| (4) Attaching the sub tray | 2-16 |
| (5) Setting up the Toner Container | 2-16 |
| (6) Cassette heater connection (100 V 40 ppm model only) | 2-17 |
| (7) Optional unit installation | 2-19 |
| (8) Connecting the Interface Cable | 2-20 |
| (9) Connecting the FAX cable (FAX installation only) | 2-22 |
| (10) Loading Paper | 2-23 |
| (10-1) Precaution for Loading Paper | 2-23 |
| (10-2) Set paper in the cassette | 2-24 |
| (10-3) Set paper in the high capacity feeder | 2-26 |
| (11) Connecting the Power Cord | 2-28 |
| (12) Turn the power on | 2-28 |
| (13) Default Setting | 2-29 |
| (13-1) Setting Date and Time | 2-30 |
| (13-2) Network Setup (LAN Cable Connection) | 2-31 |

| | |
|---|------|
| (13-3) Altitude Adjustment Setting | 2-32 |
| (13-4) Paper size and media type setting | 2-32 |
| (14) Installing Software | 2-33 |
| (15) Maintenance mode workflow (Maintenance mode U952) | 2-33 |
| (15-1) Setting the ID correction operation (Maintenance mode U464) | 2-33 |
| (15-2) Color registration adjustment (Maintenance mode U469) | 2-33 |
| (15-3) Adjusting the halftone automatically (Maintenance mode U410) : 30 ppm model..... | 2-33 |
| (15-4) Adjusting the halftone automatically (Maintenance mode U410) : 35/40 ppm model..... | 2-34 |
| (15-5) Output an own-status report (Maintenance mode U000) | 2-34 |
| (15-6) Clearing the counts (maintenance mode U927) | 2-34 |
| (15-7) Setting the delivery date (Maintenance mode U278) | 2-34 |
| (16) Checking LSU cleaning operation (Maintenance mode U474)..... | 2-35 |
| (17) Exiting from the maintenance mode | 2-35 |
| (18) Completion of installing the main unit (Turning the power off) | 2-35 |
| 2-3 Installing the optional equipment | 2-36 |
| (1) Memory Module: 30 ppm model only | 2-36 |
| (2) SD/SDHC memory card | 2-38 |
| (3) Hard disk (HD-11): 35 ppm model (Standard in some Markets) | 2-39 |
| (4) SSD (HD-6/HD-7): 30 ppm model only..... | 2-40 |
| (5) Gigabit Ethernet extension kit (IB-50)..... | 2-40 |
| (6) Wireless LAN interface (IB-51)..... | 2-40 |
| (7) Document table DT-5100 | 2-41 |
| (8) Key counter: 35/40 ppm models only | 2-44 |
| (9) ID card reader..... | 2-49 |
| (10) Key card MK-2: 35/40ppm models only (100 V model only) | 2-53 |
| (11) USB Keyboard..... | 2-56 |
| (12) Handset (100 V model only)..... | 2-61 |
| (12-1) When attaching the main unit directly | 2-61 |
| (12-2) In case installing the document table | 2-64 |
| (13) Cassette heater | 2-68 |
| (13-1) In case of the main unit cassette (standard for 100 V 40ppm model) | 2-68 |
| (13-2) In case of paper feeder (PF-5120) | 2-70 |
| (13-3) In case of paper feeder (PF-5130) | 2-73 |
| (13-4) In case of paper feeder (PF-5140) | 2-75 |
| 2-4 About Optional Applications | 2-77 |
| 2-5 Initializing procedures after installing the FAX system | 2-78 |

3 Machine Design

| | |
|--|-----|
| 3-1 Mechanical Configuration | 3-1 |
| (1) Cross-section view (30 ppm model) | 3-1 |
| (2) Cross-section view (35/40 ppm models) | 3-2 |
| 3-2 Extension device construction (option)..... | 3-3 |
| (1) Paper feeder cross-section view (PF-5120) | 3-3 |
| (2) Paper feeder cross-section view (PF-5130) | 3-3 |
| (3) Paper feeder cross-section view (PF-5140) | 3-4 |
| (4) Document processor cross-section view (DP-5100) : for 35/40ppm models only | 3-5 |
| (5) Document processor cross-section view (DP-5110) : for 35/40ppm models only | 3-5 |
| (6) Attachment kit cross-section view (AK-5100) | 3-6 |
| (7) Finisher cross-section view (DF-5100) | 3-6 |
| (8) Finisher cross-section view (DF-5110) : 35/40ppm models only..... | 3-7 |

| | |
|--|------|
| (9) Finisher cross-section view (DF-5120) : 35/40ppm models only | 3-8 |
| (10) Mailbox cross-section view (MT-5100) | 3-9 |
| (11) Job separator cross-section view (JS-5100) | 3-10 |
| 3-3 Paper conveying and Paper detection..... | 3-11 |
| (1) Main unit (30ppm) +PF-5120 +PF-5130 +DF-5100..... | 3-11 |
| (2) Main unit (35/40 ppm) +DP-5110+PF-5120+PF-5140 +AK-5100+DF-5120 | 3-12 |
| (3) Main unit (35/40 ppm) +DP-5100 +PF-5120+PF-5140 +AK-5100 +MT5100 | 3-13 |
| 3-4 Electric parts (30ppm) | 3-14 |
| (1) Wire connection..... | 3-14 |
| (1-1) (Machine rear side) | 3-14 |
| (1-2) Backside of the High-voltage PWB | 3-15 |
| (2) Descriptions about the major PWBs..... | 3-16 |
| (2-1) Main PWB | 3-16 |
| (2-2) Engine PWB | 3-16 |
| (2-3) High-voltage PWB | 3-17 |
| (2-4) Power source PWB | 3-17 |
| (2-5) Operation panel PWB..... | 3-18 |
| (3) Electric parts layout | 3-19 |
| (3-1) PWBs | 3-19 |
| (3-2) Sensors and Switches..... | 3-22 |
| (3-3) Motors | 3-26 |
| (3-4) Others..... | 3-30 |
| 3-5 Electric parts (35/40 ppm models)..... | 3-33 |
| (1) Wire connection..... | 3-33 |
| (1-1) (Machine rear side) | 3-33 |
| (1-2) Backside of the High-voltage PWB | 3-34 |
| (2) Descriptions about the major PWBs..... | 3-35 |
| (2-1) Main PWB | 3-35 |
| (2-2) Engine PWB | 3-35 |
| (2-3) High-voltage PWB | 3-36 |
| (2-4) Transfer high-voltage PWB | 3-36 |
| (2-5) Power source PWB | 3-36 |
| (2-6) Operation panel PWB..... | 3-37 |
| (3) Electric parts layout | 3-38 |
| (3-1) PWBs | 3-38 |
| (3-2) Sensors and Switches..... | 3-42 |
| (3-3) Motors | 3-46 |
| (3-4) Others..... | 3-50 |
| 3-6 Electric parts (Optional unit) | 3-53 |
| (1) Electric parts layout | 3-53 |
| (1-1) Paper feeder (PF-5120) | 3-53 |
| (1-2) Paper feeder (PF-5130) | 3-54 |
| (1-3) Paper feeder (PF-5140) | 3-56 |
| (1-4) Document processor (DP-5100) : for 35/40 ppm model only | 3-57 |
| (1-5) Document processor (DP-5110) : for 35/40 ppm model only | 3-58 |
| (1-6) Attachment kit (AK-5100) | 3-59 |
| (1-7) Inner finisher (DF-5100) | 3-60 |
| (1-8) Document finisher (DF-5110) : for 35/40ppm models only..... | 3-62 |
| (1-9) Document finisher (DF-5120) : for 35/40ppm models only..... | 3-64 |
| (1-10) Mailbox (MT-5100) | 3-66 |
| (1-11) Punch unit (PH-5100/5110)..... | 3-68 |

| | |
|---|-------|
| (1-12) Job separator (JS-5100)..... | 3-69 |
| 3-7 Drive system..... | 3-70 |
| (1) Drive system for the paper conveying..... | 3-70 |
| (2) Drive location..... | 3-71 |
| (3) Drive unit..... | 3-72 |
| (3-1) Feed drive unit..... | 3-72 |
| (3-2) Main drive unit..... | 3-72 |
| (3-3) Toner supply drive unit..... | 3-72 |
| 3-8 Mechanical construction..... | 3-73 |
| (1) Paper feed and conveying section..... | 3-73 |
| (1-1) Cassette paper feed section..... | 3-73 |
| (1-2) MP tray paper feed section..... | 3-75 |
| (1-3) Paper conveying section..... | 3-79 |
| (2) Optical section..... | 3-81 |
| (2-1) Image scanner section..... | 3-81 |
| (2-2) Laser scanner unit..... | 3-83 |
| (3) Developer section..... | 3-85 |
| (3-1) Developer unit..... | 3-85 |
| (4) Drum section..... | 3-89 |
| (4-1) Charger roller unit..... | 3-89 |
| (4-2) Cleaning..... | 3-91 |
| (5) Transfer and separation section..... | 3-95 |
| (5-1) Primary transfer unit..... | 3-95 |
| (5-2) Secondary transfer unit..... | 3-98 |
| (6) Fuser section..... | 3-101 |
| (6-1) Fuser unit..... | 3-101 |
| (7) Eject and feedshift section..... | 3-103 |
| (7-1) Eject unit..... | 3-103 |
| (7-2) Eject paper jam..... | 3-105 |
| (8) Duplex conveying section..... | 3-106 |
| (8-1) Duplex conveying unit..... | 3-106 |
| (9) Document processor : for 30 ppm model only..... | 3-108 |
| (9-1) Original paper feed section..... | 3-108 |
| (9-2) Original conveying section and Original switchback and eject section..... | 3-110 |
| (9-3) Reversing duplex scanning..... | 3-112 |
| 3-9 Mechanical construction (option)..... | 3-113 |
| (1) Paper feeder (PF-5120)..... | 3-113 |
| (1-1) Cassette paper feed section..... | 3-113 |
| (2) Paper feeder (PF-5130)..... | 3-115 |
| (2-1) Cassette paper feed section..... | 3-115 |
| (3) Paper feeder (PF-5140)..... | 3-118 |
| (3-1) Paper deck section..... | 3-118 |
| (4) Document processor (DP-5100) : for 35/40 ppm model only..... | 3-120 |
| (4-1) Original paper feed section..... | 3-120 |
| (4-2) Original conveying section and Original switchback and eject section..... | 3-122 |
| (4-3) Reversing duplex scanning..... | 3-124 |
| (5) Document processor (DP-5100) : for 35/40 ppm model only..... | 3-125 |
| (5-1) Original paper feed section..... | 3-125 |
| (5-2) Original conveying section and Original switchback and eject section..... | 3-127 |
| (6) Inner finisher (DF-5100)..... | 3-129 |
| (6-1) Paper conveying section..... | 3-129 |

| | |
|---|-------|
| (6-2) Bundle eject operation..... | 3-131 |
| (7) Document finisher (DF-5110) : for 35/40ppm models only..... | 3-133 |
| (7-1) Paper conveying section..... | 3-133 |
| (7-2) Bundle eject operation..... | 3-135 |
| (8) Document finisher (DF-5120) : for 35/40ppm models only..... | 3-137 |
| (8-1) Sub tray conveying section..... | 3-137 |
| (8-2) Main tray conveying section..... | 3-139 |
| (8-3) Bundle eject operation..... | 3-141 |
| (9) Mailbox (MT-5100)..... | 3-143 |
| (9-1) Ejecting to the mailbox tray..... | 3-145 |
| (10) Punch unit (PH-5110)..... | 3-146 |

4 Maintenance

| | |
|--|------|
| 4-1 Precautions for the maintenance..... | 4-1 |
| (1) Precautions..... | 4-1 |
| (2) Storage and handling of the drum..... | 4-1 |
| (3) Storage of the toner container..... | 4-1 |
| (4) Screening of the toner container..... | 4-2 |
| 4-2 Maintenance parts..... | 4-3 |
| (1) Maintenance kits..... | 4-3 |
| (1-1) 30 ppm models..... | 4-3 |
| (1-2) 35 ppm models..... | 4-3 |
| (1-3) 40 ppm models..... | 4-4 |
| (2) Maintenance kit for the document processor..... | 4-4 |
| (2-1) 30 ppm model standard DP/DP-5100: 35/40 ppm models..... | 4-4 |
| (2-2) DP-5110:35/40 ppm models only..... | 4-4 |
| (3) Executing the maintenance mode after replacing the maintenance kit..... | 4-5 |
| (4) Periodic maintenance Procedures..... | 4-6 |
| (4-1) Main body (30 ppm model)..... | 4-6 |
| (4-2) Main body (35 ppm model)..... | 4-8 |
| (4-3) Main body (40 ppm model)..... | 4-10 |
| (4-4) Standard DP (30 ppm model)..... | 4-12 |
| (4-5) DP-5100 (Option)..... | 4-13 |
| (4-6) DP-5110 (Option)..... | 4-14 |
| (4-7) PF-5120 (Option)..... | 4-16 |
| (4-8) PF-5130 (Option)..... | 4-17 |
| (4-9) PF-5140 (Option)..... | 4-18 |
| (4-10) AK-5100 (Option)..... | 4-19 |
| (4-11) JS-5100 (Option)..... | 4-19 |
| (4-12) DF-5100 (Option)..... | 4-20 |
| (4-13) DF-5110 (Option)..... | 4-21 |
| (4-14) DF-5120 (Option)..... | 4-22 |
| (4-15) PH-5100/5110/5120 (Option)..... | 4-23 |
| (4-16) MT-5100 (Option)..... | 4-24 |
| 4-3 Maintenance parts replacement procedures..... | 4-25 |
| (1) Cassette paper feed section..... | 4-25 |
| (1-1) Detaching and reattaching the pickup pulley and paper feed roller..... | 4-25 |
| (1-2) Detaching and reattaching the retard pulley..... | 4-28 |
| (1-3) Detaching and reattaching the regist cleaner..... | 4-29 |
| (2) MP paper feed section..... | 4-31 |
| (2-1) Detaching and reattaching the MP paper feed roller..... | 4-31 |

| | |
|---|-------|
| (2-2) Detaching and reattaching the MP separation pad | 4-31 |
| (3) Transfer section | 4-32 |
| (3-1) Detaching and reattaching the primary transfer unit | 4-32 |
| (3-2) Detaching and reattaching the secondary transfer roller unit | 4-33 |
| (4) Drum section | 4-34 |
| (4-1) Detaching and reattaching the drum unit | 4-34 |
| (4-2) Detaching and reattaching the main charge roller unit | 4-37 |
| (5) Developer section | 4-38 |
| (5-1) Detaching and reattaching the developer unit | 4-38 |
| (6) Fuser section | 4-42 |
| (6-1) Detaching and reattaching the fuser unit | 4-42 |
| (7) Document processor: 30 ppm model only | 4-44 |
| (7-1) Detaching and reattaching the DP pickup pulley and DP paper feed roller | 4-44 |
| (7-2) Detaching and reattaching the DP separation pad | 4-45 |
| 4-4 Maintenance parts replacement procedures (option) | 4-46 |
| (1) Paper feeder (PF-5120) | 4-46 |
| (1-1) Detaching and reattaching the pickup pulley and paper feed roller | 4-46 |
| (1-2) Detaching and reattaching the retard pulley | 4-49 |
| (2) Paper feeder (PF-5130) | 4-50 |
| (2-1) Detaching and reattaching the pickup pulley and paper feed roller | 4-50 |
| (2-2) Detaching and reattaching the retard pulley | 4-53 |
| (3) Paper feeder (PF-5140) | 4-54 |
| (3-1) Detaching and reattaching the pickup pulley and paper feed roller | 4-54 |
| (3-2) Detaching and reattaching the retard pulley | 4-57 |
| (4) Document processor (DP-5100): 35/40 ppm models only | 4-58 |
| (4-1) Detaching and reattaching the DP pickup pulley and DP paper feed roller | 4-58 |
| (4-2) Detaching and reattaching the DP separation pad | 4-59 |
| (5) Document processor (DP-5110): 35/40 ppm models only | 4-60 |
| (5-1) Detaching and reattaching the DP pickup pulley and DP paper feed roller | 4-60 |
| (5-2) Detaching and reattaching the DP separation pad | 4-61 |
| 4-5 Adjustment procedures after replacing the maintenance kit | 4-62 |
| 4-6 Disassembly and Reassembly | 4-63 |
| (1) Outer covers | 4-63 |
| (1-1) Detaching and reattaching the front cover | 4-63 |
| (1-2) Detaching and reattaching the rear left cover, rear right cover and rear lower cover | 4-66 |
| (1-3) Detaching and reattaching the ISU rear cover | 4-68 |
| (1-4) Detaching and reattaching the left cover | 4-68 |
| (1-5) Detaching and reattaching the upper right cover | 4-69 |
| (1-6) Detaching and reattaching the rear right cover | 4-69 |
| (1-7) Detaching and reattaching the right cover assembly | 4-70 |
| (1-8) Detaching and reattaching the upper right cover | 4-75 |
| (2) Optical section | 4-76 |
| (2-1) Detaching and reattaching the LSU | 4-76 |
| (2-2) Detaching and reattaching the image scanner unit (ISU) | 4-88 |
| (2-3) Detaching and reattaching the image scanner unit (ISU) upper assembly | 4-94 |
| (2-4) Detaching and reattaching the scanner carriage assembly | 4-96 |
| (3) Drive section | 4-102 |
| (3-1) Detaching and reattaching the feed drive unit (30 ppm model) | 4-102 |
| (3-2) Detaching and reattaching the feed drive unit (35/40 ppm models) | 4-114 |
| (3-3) Detaching and reattaching the main drive unit (30 ppm model) | 4-126 |

| | |
|---|-------|
| (3-4) Detaching and reattaching the main drive unit (35/40 ppm models) | 4-139 |
| (3-5) Detaching and reattaching the transfer motor (30 ppm model)..... | 4-152 |
| (3-6) Detaching and reattaching the transfer motor (35/40 ppm models) | 4-160 |
| (3-7) Detaching and reattaching the toner supply drive unit (30 ppm model) | 4-168 |
| (3-8) Detaching and reattaching the toner supply drive unit (35/40 ppm model) | 4-179 |
| (4) Others..... | 4-190 |
| (4-1) Detaching and reattaching the SSD: 35 ppm model only..... | 4-190 |
| (4-2) Detaching and reattaching the hard disk: 35/40 ppm model only | 4-192 |
| (4-3) Detaching and reattaching the lift motor..... | 4-193 |
| (4-4) Detaching and reattaching the eject unit..... | 4-195 |
| (4-5) Replacing the language sheet (30 ppm model)..... | 4-198 |
| (4-6) Replacing the language sheet (35/40 ppm models)..... | 4-198 |
| (4-7) Fan motor attachment direction..... | 4-199 |
| (5) PWBs..... | 4-200 |
| (5-1) Detaching and reattaching the engine PWB (30 ppm model) | 4-200 |
| (5-2) Detaching and reattaching the engine PWB (35/40 ppm model) | 4-204 |
| (5-3) Detaching and reattaching the main PWB (30 ppm model) | 4-208 |
| (5-4) Detaching and reattaching the main PWB (35/40 ppm models) | 4-212 |
| (5-5) Detaching and reattaching the high voltage PWB (30 ppm model)..... | 4-217 |
| (5-6) Detaching and reattaching the high voltage PWB (35/40 ppm models)..... | 4-221 |
| (5-7) Detaching and reattaching the power source PWB (30 ppm model) | 4-225 |
| (5-8) Detaching and reattaching the power source PWB (35/40 ppm models)..... | 4-233 |
| (5-9) Detaching and reattaching the operation panel PWB (30 ppm model) | 4-241 |
| (5-10) Detaching and reattaching the operation panel PWB (35/40 ppm models) | 4-245 |
| (6) Document processor: 30 ppm model only | 4-249 |
| (6-1) Detaching and reattaching the document processor..... | 4-249 |
| (6-2) Detaching and reattaching the DP rear cover | 4-250 |
| 4-7 Disassembly & Reassembly (option)..... | 4-251 |
| (1) Paper feeder (PF-5120)..... | 4-251 |
| (1-1) Detaching and reattaching the PF drive unit | 4-251 |
| (1-2) Detaching and reattaching the PF lift motor | 4-252 |
| (1-3) Detaching and reattaching the PF main PWB..... | 4-254 |
| (2) Paper feeder (PF-5130)..... | 4-255 |
| (2-1) Detaching and reattaching the PF drive unit | 4-255 |
| (2-2) Detaching and reattaching the PF lift motor | 4-256 |
| (2-3) Detaching and reattaching the PF main PWB..... | 4-258 |
| (3) Paper feeder (PF-5140)..... | 4-259 |
| (3-1) Detaching and reattaching the PF drive unit | 4-259 |
| (3-2) Detaching and reattaching the PF lift motor | 4-260 |
| (3-3) Detaching and reattaching the PF main PWB..... | 4-261 |
| (4) Document processor (DP-5100): 35/40 ppm models only..... | 4-262 |
| (4-1) Detaching and reattaching the document processor | 4-262 |
| (4-2) Detaching and reattaching the DP rear cover | 4-263 |
| (4-3) Detaching and reattaching the DP main PWB | 4-264 |
| (5) Document processor (DP-5110): 35/40 ppm models only..... | 4-266 |
| (5-1) Detaching and reattaching the document processor..... | 4-266 |
| (5-2) Detaching and reattaching the DP rear cover | 4-267 |
| (5-3) Detaching and reattaching the DP main PWB | 4-268 |
| (5-4) Detaching and reattaching the CIS | 4-270 |
| (6) Finisher (DF-5100) | 4-276 |
| (6-1) Detaching and reattaching the DF main PWB..... | 4-276 |

| | |
|---|-------|
| (7) Finisher (DF-5110): 35/40 ppm models only | 4-278 |
| (7-1) Detaching and reattaching the staple unit | 4-278 |
| (7-2) Detaching and reattaching the DF main PWB..... | 4-280 |
| (8) Finisher (DF-5120): 35/40 ppm models only | 4-281 |
| (8-1) Detaching and reattaching the staple unit | 4-281 |
| (8-2) Detaching and reattaching the DF main PWB..... | 4-283 |
| | |
| 5 Firmware | |
| 5-1 Firmware update (30 ppm model) | 5-1 |
| 5-2 Firmware update (35/40 ppm model) | 5-4 |
| | |
| 6 Maintenance mode | |
| 6-1 Maintenance mode | 6-1 |
| (1) Executing the maintenance mode | 6-1 |
| (2) Maintenance modes list (30ppm model) | 6-2 |
| (2-1) Content of the maintenance mode (30ppm model) | 6-8 |
| (3) Maintenance modes list (35/40 ppm model) | 6-197 |
| (3-1) Content of the maintenance mode (30ppm model) | 6-203 |
| 6-2 Service mode: 30ppm model only | 6-432 |
| (1) Executing the service mode | 6-432 |
| (2) Descriptions of service modes..... | 6-434 |
| | |
| 7 Troubleshooting | |
| 7-1 Paper misfeed detection..... | 7-1 |
| (1) Paper misfeed indication | 7-1 |
| (2) Paper misfeed detection condition | 7-2 |
| (3) First check items..... | 7-12 |
| (4) Items and corrective actions relating to the device that will cause paper jam | 7-15 |
| (5) Paper jam at feeding from paper feeder 1 | 7-18 |
| (6) Paper jam at feeding from cassette 2 (paper feeder 1) | 7-19 |
| (7) Paper jam at feeding from the MP tray | 7-20 |
| (8) Paper jam at the duplex re-feeding section | 7-21 |
| (9) Electrical parts that could cause a paper jam at the transfer, the fuser and the eject parts | 7-22 |
| 7-2 Self diagnostic | 7-23 |
| (1) Self diagnostic function..... | 7-23 |
| (2) Self diagnostic codes..... | 7-23 |
| (3) System Error (Fxxx) Outline | 7-99 |
| 7-3 Image formation problems | 7-106 |
| (1) Poor image (due to DP and scanner reading) | 7-107 |
| (1-1) No image appears (entirely white)..... | 7-108 |
| (1-2) No image appears (entirely black)..... | 7-110 |
| (1-3) The entire image is faint | 7-111 |
| (1-4) The background is colored | 7-113 |
| (1-5) Vertical white streaks or bands appear | 7-115 |
| (1-6) Black or color streaks appear longitudinally | 7-116 |
| (1-7) Horizontal black streaks appear | 7-118 |
| (1-8) The image is partly dark or bright..... | 7-120 |
| (1-9) Black or color dots appear in the image | 7-122 |
| (1-10) Characters are blurred | 7-123 |
| (1-11) The leading edge of the image is consistently misaligned with the original | 7-125 |

| | |
|--|-------|
| (1-12) The image is partly missing | 7-126 |
| (1-13) The image is blurred..... | 7-128 |
| (1-14) Image center does not align with the original center | 7-130 |
| (1-15) Moire | 7-131 |
| (1-16) Skewed image..... | 7-132 |
| (1-17) Abnormal image | 7-133 |
| (2) Poor image (Image forming factor: printer engine for single color) | 7-134 |
| (2-1) No image appears (entirely white)..... | 7-136 |
| (2-2) No image appears (entirely black)..... | 7-138 |
| (2-3) The entire image is faint | 7-139 |
| (2-4) The background is colored | 7-141 |
| (2-5) Vertical white streaks or bands appear | 7-142 |
| (2-6) Black or color streaks appear longitudinally | 7-143 |
| (2-7) White, black or color streaks or bands appear horizontally..... | 7-144 |
| (2-8) Uneven density vertically..... | 7-145 |
| (2-9) Uneven density horizontally | 7-146 |
| (2-10) Black or color dots appear in the image | 7-147 |
| (2-11) Offset occurs | 7-148 |
| (2-12) The image is partly missing..... | 7-148 |
| (2-13) The image is blurred..... | 7-149 |
| (2-14) Poor grayscale reproduction | 7-149 |
| (2-15) Irregular horizontal white streaks appear in the image / Dots appear in the image | 7-150 |
| (2-16) Granular iamge (low solid image desnity) | 7-150 |
| (3) Image failure (Transfer, paper conveying and fusing factor: printer engine for 4 colors) | 7-151 |
| (3-1) No image appears (entirely white)..... | 7-153 |
| (3-2) The entire image is faint | 7-154 |
| (3-3) The background is colored | 7-155 |
| (3-4) Vertical white streaks or bands appear | 7-155 |
| (3-5) Black or color streaks appear longitudinally | 7-156 |
| (3-6) White, black or color streaks or bands appear horizontally..... | 7-157 |
| (3-7) Uneven transfer..... | 7-158 |
| (3-8) Black or color dots appear in the image | 7-159 |
| (3-9) Characters are blurred (transfer shift) | 7-160 |
| (3-10) The leading edge of the image is consistently misaligned with the original | 7-161 |
| (3-11) The leading edge of the image is sporadically misaligned with the original | 7-161 |
| (3-12) Creases are generated on paper | 7-162 |
| (3-13) Offset occurs | 7-163 |
| (3-14) The image is partly missing (Outlines objects and white dots)..... | 7-164 |
| (3-15) Fusing failure | 7-165 |
| (3-16) The image is blurred..... | 7-165 |
| (3-17) Image center does not align with the original center | 7-166 |
| (3-18) Paper is dirty with toner | 7-166 |
| (3-19) Poor color reproduction | 7-167 |
| (3-20) Color registration shift | 7-168 |
| (3-21) Dirt on the backside of paper | 7-169 |
| 7-4 Electric failure | 7-170 |
| 7-5 Mechanical failure..... | 7-179 |
| 7-6 Error codes | 7-181 |
| (1) Scan to SMB error code | 7-181 |

| | |
|---|-------|
| (2) Scan to FTP error code | 7-182 |
| (3) Scan to E-mail error code | 7-183 |
| 7-7 Error codes | 7-185 |
| (1) Error codes | 7-185 |
| (2) Error codes | 7-186 |
| (2-1) Error code table: U004XX Interrupted phase B | 7-188 |
| (2-2) Error code table: U006XX Problems with the unit | 7-188 |
| (2-3) Error code table: U008XX Page transmission error | 7-188 |
| (2-4) Error code table: U009XX Page reception error | 7-188 |
| (2-5) Error code table: U010XX G3 transmission error | 7-189 |
| (2-6) Error code table: U011XX G3 reception error | 7-190 |
| (2-7) Error code table: U017XX V.34 transmission error | 7-191 |
| (2-8) Error code table: U018XX V.34 reception error | 7-191 |
| (2-9) Error code table: U044XX Encrypted transmission error | 7-191 |

8 PWBs

| | |
|---|------|
| 8-1 Description for PWB (30 ppm model) | 8-1 |
| (1) Main PWB (MPWB) | 8-1 |
| (1-1) Connector position | 8-1 |
| (1-2) PWB photograph | 8-1 |
| (1-3) Connector lists | 8-2 |
| (2) Engine PWB (EPWB) | 8-8 |
| (2-1) Connector position | 8-8 |
| (2-2) PWB photograph | 8-8 |
| (2-3) Connector lists | 8-9 |
| (3) High voltage PWB (HVPWB) | 8-22 |
| (3-1) Connector position | 8-22 |
| (3-2) PWB photograph | 8-22 |
| (3-3) Connector lists | 8-23 |
| (4) Power supply PWB (PSPWB) | 8-24 |
| (4-1) Connector position | 8-24 |
| (4-2) PWB photograph | 8-24 |
| (4-3) Connector lists | 8-25 |
| (5) Operation panel PWB (OPPWB) | 8-26 |
| (5-1) Connector position | 8-26 |
| (5-2) PWB photograph | 8-26 |
| (5-3) Connector lists | 8-27 |
| 8-2 Description for PWB (35/40 ppm models) | 8-31 |
| (1) Main PWB (MPWB) | 8-31 |
| (1-1) Connector position | 8-31 |
| (1-2) PWB photograph | 8-31 |
| (1-3) Connector lists | 8-32 |
| (2) Engine PWB (EPWB) | 8-41 |
| (2-1) Connector position | 8-41 |
| (2-2) PWB photograph | 8-41 |
| (2-3) Connector lists | 8-42 |
| (3) High voltage PWB (HVPWB) | 8-62 |
| (3-1) Connector position | 8-62 |
| (3-2) PWB photograph | 8-62 |
| (3-3) Connector lists | 8-63 |
| (4) Transfer high voltage PWB (TCHVPWB) : 40 ppm model only | 8-64 |

| | |
|---|-------|
| (4-1) Connector position | 8-64 |
| (4-2) PWB photograph | 8-64 |
| (4-3) Connector lists..... | 8-65 |
| (5) Power supply PWB (PSPWB) | 8-66 |
| (5-1) Connector position | 8-66 |
| (5-2) PWB photograph | 8-66 |
| (5-3) Connector lists..... | 8-67 |
| (6) Operation panel PWB (OPPWB)..... | 8-69 |
| (6-1) Connector position | 8-69 |
| (6-2) PWB photograph | 8-69 |
| (6-3) Connector lists..... | 8-70 |
| 8-3 Description for PWB (OPTION) | 8-74 |
| (1) PF main PWB (PFMPWB) for PF-5120..... | 8-74 |
| (1-1) Connector position | 8-74 |
| (1-2) PWB photograph | 8-74 |
| (1-3) Connector lists..... | 8-75 |
| (2) PF main PWB (PFMPWB) for PF-5130..... | 8-78 |
| (2-1) Connector position | 8-78 |
| (2-2) PWB photograph | 8-78 |
| (2-3) Connector lists..... | 8-79 |
| (3) PF main PWB (PFMPWB) for PF-5140..... | 8-82 |
| (3-1) Connector position | 8-82 |
| (3-2) PWB photograph | 8-82 |
| (3-3) Connector lists..... | 8-83 |
| (4) DP main PWB (DPMPWB) for DP-5100..... | 8-85 |
| (4-1) Connector position | 8-85 |
| (4-2) PWB photograph | 8-85 |
| (4-3) Connector lists..... | 8-86 |
| (5) DP main PWB (DPMPWB) for DP-5110..... | 8-88 |
| (5-1) Connector position | 8-88 |
| (5-2) PWB photograph | 8-88 |
| (5-3) Connector lists..... | 8-89 |
| (6) DF main PWB (DFMPWB) for DF-5100 | 8-91 |
| (6-1) Connector position | 8-91 |
| (6-2) PWB photograph | 8-91 |
| (6-3) Connector lists..... | 8-92 |
| (7) DF main PWB (DFMPWB) for DF-5110 | 8-97 |
| (7-1) Connector position | 8-97 |
| (7-2) PWB photograph | 8-97 |
| (7-3) Connector lists..... | 8-98 |
| (8) DF main PWB (DFMPWB) for DF-5120 | 8-104 |
| (8-1) Connector position | 8-104 |
| (8-2) PWB photograph | 8-104 |
| (8-3) Connector lists..... | 8-105 |
| (9) Mail box main PWB (MBMPWB) for MT-5100..... | 8-111 |
| (9-1) Connector position | 8-111 |
| (9-2) PWB photograph | 8-111 |
| (9-3) Connector lists..... | 8-112 |
| (10) Punch PWB (PUNPWB) for PH-5110..... | 8-114 |
| (10-1) Connector position | 8-114 |
| (10-2) PWB photograph | 8-114 |

| | |
|-----------------------------|-------|
| (10-3) Connector lists..... | 8-115 |
|-----------------------------|-------|

9 Appendixes

| | |
|--|------|
| 9-1 Appendixes..... | 9-1 |
| (1) Repetitive defects gauge..... | 9-1 |
| (2) Firmware environment commands..... | 9-2 |
| (3) Chart of image adjustment procedures..... | 9-11 |
| (4) Wiring diagram (30 ppm model)..... | 9-14 |
| (5) Wiring diagram (35/40 ppm models)..... | 9-22 |
| (6) Wiring diagram (Options)..... | 9-29 |
| (6-1) Paper feeder (PF-5120) wiring diagram..... | 9-29 |
| (6-2) Paper feeder (PF-5130) wiring diagram..... | 9-30 |
| (6-3) Paper feeder (PF-5140) wiring diagram..... | 9-31 |
| (6-4) Document processor (DP-5100) wiring diagram: 35/40ppm models only..... | 9-32 |
| (6-5) Document processor (DP-5110) wiring diagram: 35/40ppm models only..... | 9-33 |
| (6-6) Finisher (DF-5100) wiring diagram..... | 9-34 |
| (6-7) Finisher (DF-5110) wiring diagram: 35/40ppm models only..... | 9-35 |
| (6-8) Finisher (DF-5120) wiring diagram: 35/40ppm models only..... | 9-36 |
| (6-9) Mailbox (MT-5100) wiring diagram..... | 9-37 |
| (6-10) Punch unit (PH-5100/5110) wiring diagram..... | 9-38 |

Instaration Guide

PF-5120 (500 sheets × 1 Paper Feeder)
 PF-5130 (500 sheets × 2 Paper Feeder)
 PF-5140 (2000 sheets Paper Feeder)
 DP-5100 (Document processor: RADF)
 DP-5110 (Document processor: CIS)
 DF-5100 (Inner Finisher)
 DF-5110 (1000 sheets Finisher)
 DF-5120 (3000 sheets Finisher)
 AK-5100 (Bridge Unit)
 MT-5100 (Mail Box)
 PH-5100/5110 (Punch Unit)
 JS-5100 (Job separator)
 FAX System 10 (FAX Kit)
 FAX System 11 (FAX Kit)

This page is intentionally left blank.

1 Specifications

1-1 Specifications

(1) Common function

| Items | | Specifications | | |
|----------------------------------|--------------------|---|----------------------|----------------------|
| Product name | | 30 ppm model | 35 ppm model | 40 ppm model |
| Type | | Desktop | | |
| Printing Method | | Electrophotography by semiconductor laser | | |
| Paper Weight | Cassette | 60 to 220 g/m ² | | |
| | Multi Purpose Tray | 60 to 220 g/m ² , 230 g/m ² (Cardstock), 129 to 163 g/m ² (Banner sheet) | | |
| Paper type | Cassette | Plain, Rough, Recycled, Vellum, Preprinted, Bond, Color (Colour), Prepunched, Letterhead, Thick, High Quality, Envelope, Custom 1 to 8(Duplex: Same as Simplex) | | |
| | Multi Purpose Tray | Plain, Transparency (OHP film), Rough, Vellum, Labels, Recycled,Preprinted, Bond, Cardstock, Coated, Color (Colour), Prepunched,Letterhead, Envelope, Thick, High Quality, Custom 1 to 8 | | |
| Paper Size | Cassette | A4, A5, A6, B5, Letter, Legal, B6, Folio, 216 × 340 mm, Statement, Executive, Oficio II, 16K, B5 (ISO), Envelope #10, Envelope #9, Envelope #6 3/4, Envelope Monarch, Envelope DL, Envelope C5, Youkei 4, Youkei 2, Custom (92 × 148 mm to 216 × 356 mm) | | |
| | Multi Purpose Tray | A4, A5, A6, B5, Letter, Legal, B6, Folio, 216 × 340 mm, Statement, Executive, Oficio II, 16K, B5 (ISO), Envelope #10, Envelope #9, Envelope #6 3/4, Envelope Monarch, Envelope DL, Envelope C5, Hagaki (Cardstock), Oufuku Hagaki (Return postcard), Youkei 4, Youkei 2, Custom (70 × 148 mm to 216 × 356 mm) --- Banner sheet (240×470.1 to 210×1220 mm) | | |
| Printable Area | | Print margin for top, bottom and both sides is 4 mm | | |
| Warm-up Time (23°C/ 73.4°F, 60%) | Power on | 20 seconds or less | 24 seconds or less | |
| | Low Power | 10 seconds or less | 10 seconds or less | |
| | Sleep | 17.6 seconds or less | 19.7 seconds or less | 21.8 seconds or less |
| Paper Capacity | Cassette | 550 sheets(64g/m ²), 500 sheets(80g/m ²)* ¹ | | |
| | Multi Purpose Tray | 110 sheets (A4/Letter or smaller) (64g/m ²) 27 sheets (larger than A4/Letter) (64g/m ²) 100 sheets (A4/Letter or smaller) (80 g/m ²) 25 sheets (larger than A4/Letter) (80 g/m ²) --- 1 sheet (Banner sheet (210 x 470.1 to 210 x 1220 mm))(129 to 163 g/m ²) | | |
| Output Tray Capacity | Inner tray | 550 sheets(64g/m ²), 500 sheets(80g/m ²)* ¹ | | |
| Image Write System | | Semiconductor laser and electrophotography | | |
| Light source | | LED | | |

| Items | | Specifications | | |
|---------------------------------|---------------|---|--|---------------------------------|
| Product name | | 30 ppm model | 35 ppm model | 40 ppm model |
| Scanning method | | Flat surface scanning by the CCD image sensor | | |
| Photoconductor | | OPC drum (diameter 30 mm) | | a-Si drum (diameter 30 mm) |
| Charging system | | Contact charger roller method | | |
| Developer system | | Touch down developing system Developer: 2-component Toner replenishing: Automatic from the toner container | | |
| Transfer system | | Primary: Transfer belt method Secondary: Transfer roller method | | |
| Separation system | | Small diameter separation, separation needle | | |
| Cleaning system | Drum | Counter blade | | Counter blade + Cleaning roller |
| | Transfer belt | Fur brush cleaning + Pre-brush system | | |
| Charge erasing system | | Exposure by cleaning lamp (LED) | | |
| Fusing system | | Heat and pressure fusing with the heat roller and the press roller Heat source: halogen heater Abnormally high temperature protection devices: thermostat | | |
| Standard Memory (Max 2GB) | | 1.0GB | 2.0GB | |
| High capacity storage | Standard | - | SSD 8GB: (except 120 V model) HDD 320GB: (120 V model only) | HDD 320GB |
| | Option | SSD 32 GB/128 GB | HDD 320GB: (except 120 V model) | - |
| Interface | Standard | USB Interface Connector: 1 (Hi-Speed USB) *3 Network interface: 1 (10 BASE-T/100 BASE-TX/1000 BASE-T) | | |
| | | USB Port: 2 (Hi-Speed USB) (USB Memory Slot) | USB Port: 3 (Hi-Speed USB) (USB Memory Slot) | |
| | Option | eKUIO: 1 (Upper slot) FAX: 1 (Lower slot) | eKUIO: 2 (FAX: 2 *2) | |
| Operating Environment | Temperature | 10 to 32.5°C/50 to 90.5°F | | |
| | Humidity | 10 to 80 % | | |
| | Altitude | 3,500 m/11,482 ft maximum | | |
| | Brightness | 1,500 lux maximum | | |
| Dimension (W × D × H) | | 21.66" × 19.99" × 29" 550 × 507.5 × 736.6 mm (Including the Document Processor) | 21.66" × 19.97" × 24.13" 550 × 507 × 612.8 mm (without Document Processor) | |
| Weight(without toner container) | | Approx. 105.9 lb/Approx. 48 kg(Including the Document Processor) | Approx. 105.9 lb/Approx. 48 kg(without Document Processor) | |

| Items | Specifications | | |
|---|--|--|--------------|
| | 30 ppm model | 35 ppm model | 40 ppm model |
| Product name | | | |
| Space Required (W × D) | 31.82" × 19.97"808 × 507 mm (Using multi purpose tray) 48.78" × 20.94"1239 × 532 mm (Using 3000-sheet finisher) | | |
| Power source | 100 V Model: 100 V 50/60 Hz 11.1 A 120 V Model: 120 V 60 Hz 9.5 A 230 V Model: 200 to 240 V 50 Hz 5.0 A | 100 V Model: 100 V 50/60 Hz 12.3 A 120 V Model: 120 V 60 Hz 10.8A 230 V Model: 200 to 240 V 50 Hz 5.9A | |
| The power consumption of the product in networked standby(if all network ports are connected.) | AC100V: 1110W AC120V: 1150W AC220 to 240 V: 1150W | AC100V: 1230W AC120V: 1300W AC220 to 240 V: 1360W | |

*1: Up to upper limit height line in the cassette.

*2: When one network interface is installed, only one fax line can be installed.

*3: 220-240 V 35/40ppm models: Option

(2) Copy Functions

| Items | | Description | | | | | |
|---------------------------------|--------------|--|---------------|---------------------|---------------|---------------------|---------------|
| Product name | | 30 ppm model | | 35 ppm model | | 40 ppm model | |
| Copy Speed | B/W | A4 | 30 sheets/min | A4 | 35 sheets/min | A4 | 40 sheets/min |
| | | Letter | 32 sheets/min | Letter | 37 sheets/min | Letter | 42 sheets/min |
| | | Legal | 26 sheets/min | Legal | 30 sheets/min | Legal | 34 sheets/min |
| | | B5 | 27 sheets/min | B5 | 35 sheets/min | B5 | 40 sheets/min |
| | | A5 | 27 sheets/min | A5 | 35 sheets/min | A5 | 40 sheets/min |
| | | A6 | 27 sheets/min | A6 | 35 sheets/min | A6 | 40 sheets/min |
| | Color | A4 | 30 sheets/min | A4 | 35 sheets/min | A4 | 40 sheets/min |
| | | Letter | 32 sheets/min | Letter | 37 sheets/min | Letter | 42 sheets/min |
| | | Legal | 26 sheets/min | Legal | 30 sheets/min | Legal | 34 sheets/min |
| | | B5 | 27 sheets/min | B5 | 35 sheets/min | B5 | 40 sheets/min |
| | | A5 | 27 sheets/min | A5 | 35 sheets/min | A5 | 40 sheets/min |
| | | A6 | 27 sheets/min | A6 | 35 sheets/min | A6 | 40 sheets/min |
| First Copy Time (A4) | B/W | 6.4 seconds or less | | 5.9 seconds or less | | 5.8 seconds or less | |
| | Color | 7.8 seconds or less | | 7.3 seconds or less | | 6.9 seconds or less | |
| Zoom Level | | Manual mode: 25 to 400%, 1% increments Fixed zoom rate: 400%, 200%, 141%, 122%, 115%, 100%, 86%, 81%, 70%, 50%, 25% | | | | | |
| Continuous Copying | | 1 to 999 sheets | | | | | |
| Resolution | | 600 × 600 dpi | | | | | |
| Supported Original Types | | Sheet, Book, 3-dimensional objects (maximum original size: Legal/Folio) | | | | | |
| Original Feed System | | Fixed | | | | | |

(3) Printer Functions

| Items | | Description | | |
|----------------------------------|------------------------|--|--|---------------------|
| Product name | | 30 ppm model | 35 ppm model | 40 ppm model |
| Printing Speed | | Same as Copying Speed. | | |
| First Print Time (A4) | Black and White | 7.0 seconds or less | 5.5 seconds or less | 5.4 seconds or less |
| | Color | 8.0 seconds or less | 6.5 seconds or less | 6.4 seconds or less |
| Resolution | | 600 × 600 dpi, 9600 dpi equivalent × 600 dpi | 1200 × 1200 dpi, 9600 dpi equivalent × 600 dpi | |
| Operating System | | Windows XP, Windows Server 2003, Windows Vista, Windows 7, Windows 8, Windows 8.1, Windows Server 2008/R2, Windows Server 2012/R2, Mac OS 10.5 or later | | |
| Interface | | USB Interface Connector: 1 (Hi-Speed USB) Network interface: 1 (10 BASE-T/100 BASE-TX/1000 BASE-T) Optional Interface (Option): 2 (For IB-50/IB-51 mounting) | | |
| Page Description Language | | PRESCRIBE | | |
| Emulations | | PCL6 (PCL-XL, PCL5c), KPDL3 (PostScript3 compatible), PDF, XPS, OpenXPS | | |

(4) Scanner Functions

| Items | Description | |
|--|--|--|
| Resolution | 600 dpi, 400 dpi, 300 dpi, 200×400 dpi, 200 dpi, 200×100 dpi | |
| File Format | TIFF (MMR/JPEG compression), JPEG, PDF (MMR/JPEG compression), XPS, PDF/A, High compressive PDF, Encrypted PDF, Open XPS | |
| Scanning Speed*¹ (A4, 300 dpi, Image quality: Text/Photo original) | 1-sided: B/W 40 images/min Color 30 images/min 2-sided B/W 17 Images/min Color 13 images/min | (When using DP-5110 (Simultaneous Duplex DP)) 1-sided B/W 60 images/min Color 40 images/min 2-sided B/W 120 Images/min Color 80 images/min |
| Interface | Ethernet (10 BASE-T/100 BASE-TX/1000 BASE-T), USB | |
| Transmission System | SMB, SMTP, FTP, FTP over SSL, USB, TWAIN* ² , WIA* ³ , WSD | |

*1 When using the document processor (Dual Scan DP) (except TWAIN and WIA scanning)

*2 Available Operating System: Windows XP/Windows Vista/Windows Server 2003/Windows Server 2008/Windows Server 2008 R2/Windows 7/Windows 8/Windows 8.1/Windows Server 2012/Windows Server 2012 R2

*3 Supported Operating Systems: Windows XP/Windows Vista/Windows Server 2003/Windows Server 2008/Windows Server 2008 R2/Windows 7/Windows 8/Windows 8.1/Windows Server 2012/Windows Server 2012

(5) Document Processor: 30ppm model standard

| Items | Description |
|-----------------------------------|--|
| Supported Original Types | Sheet originals |
| Paper Size | Maximum: Legal/Folio |
| | Minimum: Statement/A6 |
| Paper Weight | 1-sided: 50 to 120 g/m ² 2-sided: 50 to 120 g/m ² |
| Loading Capacity | 75 sheets (50 to 80 g/m ²) maximum*1 |
| Dimensions (W) × (D) × (H) | 21.66" × 19.97" × 24.13" 548 × 346.5 × 131 mm |
| Weight | Approx. 8.8 lbs / Approx. 4kg |

*1 Up to upper limit height line in the document processor.

(6) Option**(6-1) Document Processor (DP-5100/5110) 35/40ppm models only**

| Items | Description | |
|-----------------------------------|--|--|
| Document scanning method | Document reversing method (DP-5100) | Simultaneous duplex scan (DP-5110) |
| Document feed method | Automatic feed | |
| Supported Original Types | Sheet originals | |
| Paper Size | Maximum: 8.5" × 14.01" 216 × 356 mm (Long-sized 216 x1900 mm / 8.5" × 74.8") | |
| | Minimum: 4.13" × 5.82" 105 mm × 148 mm | |
| Paper Weight | 1-sided: 50 to 120 g/m ² 2-sided: 50 to 120 g/m ² | |
| Loading Capacity | 75 sheets (50 to 80 g/m ²) maximum* ¹ | |
| Dimensions (W) × (D) × (H) | 21.66" × 19.97" × 24.13" 548 × 346.5 × 131 mm | 21.66" × 19.97" × 24.13" 548 × 364.5 × 131 mm |
| Weight | 8.9 lbs. or less 4 kg or less | 10.0 lbs. or less 4.5 kg or less |

*1 Up to upper limit height line in the document processor.

(6-2) Paper Feeder (PF-5120)

| Items | Description |
|-----------------------------------|--|
| Paper Supply Method | Friction roller feeder (No. of sheets: 550, 64 g/m ² , 1 cassette) (No. of sheets: 500, 80 g/m ² , 1 cassette) |
| Paper Size | A4, A5, B5, A6, Letter, Legal, B6, Folio, 216 × 340 mm, Statement, Executive, Oficio II, 16K, B5 (ISO), Envelope #10, Envelope #9, Envelope #6 3/4, Envelope Monarch, Envelope DL, Envelope C5, youkei 4, youkei 2, Custom (105 × 148 to 216 × 356 mm) |
| Supported Paper | Paper weight: 60 to 220 g/m ² Media types: Plain, Recycled, Material |
| Dimensions (W) × (D) × (H) | 21.66" × 19.97" × 6.19" 550 × 507 × 157 mm |
| Weight | Approx. 21.0 lbs Approx. 9.5 kg |

(6-3) Paper Feeder (PF-5130)

| Items | Description |
|-----------------------------------|--|
| Paper Supply Method | Friction roller feeder (No. Sheets: 550, 64 g/m ² , 2 cassette/ No. Sheets: 500, 80 g/m ² , 2 cassette) |
| Paper Size | A4, A5, B5, A6, Letter, Legal, B6, Folio, 216 × 340 mm, Statement, Executive, Oficio II, 16K, B5 (ISO), Envelope #10, Envelope #9, Envelope #6 3/4, Envelope Monarch, Envelope DL, Envelope C5, youkei 4, youkei 2, Custom (105 × 148 to 216 × 356 mm) |
| Supported Paper | Paper weight: 60 to 220 g/m ² Media types: Plain, Recycled, Material |
| Dimensions (W) × (D) × (H) | 21.66" × 19.97" × 13.51" 550 × 507 × 343 mm |
| Weight | Approx. 39.7 lbs Approx. 18 kg |

(6-4) Paper Feeder (PF-5140)

| Items | Description |
|-----------------------------------|---|
| Paper Supply Method | Friction roller feeder (No. Sheets: 2,200, 64 g/m ² /No. Sheets: 2,000, 80 g/m ²) |
| Paper Size | A4, Letter |
| Supported Paper | Paper weight: 60 to 220 g/m ² Media types: Plain, Recycled, Material |
| Dimensions (W) × (D) × (H) | 21.66" × 19.97" × 13.51" / 550 × 507 × 343 mm |
| Weight | Approx. 44.1 lbs Approx. 20 kg |

(6-5) Inner finisher (DF-5100)

| Items | | Description | |
|---|----------------------------------|---|---|
| Number of Trays | | 1 tray | |
| Paper Size(80 g/m²) Finisher tray (no stapling) | | Legal, Folio, 216 x 340 mm, Custom (70 x 298 to 210 x 1020 mm): 250 sheets equivalent or 42 mm height (Thick: 20 sheets (129 to 220 g/m ²)) A4, A5, B5, A6, Letter, Legal, B6, Folio, 216×340 mm, Statement, Executive, Oficio II, 16K, B5 (ISO), Hagaki (Cardstock), Oufukuhagaki (Return postcard), Envelope #10, Envelope #9, Envelope #6 3/4, Envelope Monarch, Envelope DL, Envelope C5, youkei 4, youkei 2, Custom (70 x 148 to 210 x 297 mm): 300 sheets equivalent or 42 mm height (Thick: 20 sheets (129 to 220 g/m ²)) | |
| Stapling | Number of sheets to limit | Legal, Oficio II, 216 x340 mm | 30 sheets (60 to 90 g/m ²) 20 sheets (91 to 105 g/m ²) 2 cover sheet only (106 g/m ² to 128 g/m ²) |
| | | A4, B5, Letter, 16K | 50 sheets (60 to 90 g/m ²) 40 sheets (91 to 105 g/m ²) 2 cover sheet only (106 to 128 g/m ²) |
| | Media types | Plain, Recycled, Prepunched, Preprinted, Bond, Letterhead, Color, Coated, Thick, High Quality, Custom 1 to 8 | |
| Dimensions (W) × (D) × (H) (with the tray pulled out) | | 25.08" × 15.60" × 6.23" 637 × 396 × 158 mm | |
| Weight | | Approx. 26.5 lbs or less Approx. 12 kg or less | |

(6-6) 1000-sheet Finisher (DF-5110): 35/40ppm models only

| Items | | Description | |
|---|----------------------------------|---|---|
| Number of Trays | | 1 tray | |
| Paper Size(80 g/m²) Finisher tray (no stapling) | | Legal, Oficio II, Folio, 216 × 340 mm, Custom (cassette: 92 × 148 mm to 216 × 356 mm/Multi Purpose tray: 70 × 148 mm to 216 × 356 mm): 500 sheets equivalent or 91 mm height A4, B5, A5, Letter, Statement, Executive, 16K: 1,000 sheets equivalent or 162 mm height | |
| Stapling | Number of sheets to limit | Legal, Oficio II, 216 × 340mm | 30 sheets (52 to 90 g/m ²) 20 sheets (91 to 105 g/m ²) 2 cover sheet only (106 g/m ² to 128 g/m ²) |
| | | A4, B5, Letter, 16K | 50 sheets (52 to 90 g/m ²) 40 sheets (91 to 105 g/m ²) 2 cover sheet only (106 g/m ² to 128 g/m ²) |
| | Media types | Plain, Recycled, Prepunched, Preprinted, Bond, Letterhead, Color, Coated, Thick, High Quality, Rough, Custom 1 to 8 | |
| Dimensions (W) × (D) × (H) (with the tray pulled out) | | 23.27" × 20.36" × 39.58" 591 × 517 × 1,005.3 mm | |
| Weight | | Approx. 50.8 lbs. or less Approx. 23 kg or less | |

(6-7) 3000-sheet Finisher (DF-5120): 35/40ppm models only

| Items | | | | Description |
|--|----------------------------------|---------------|--|---|
| Number of Trays | | | | 2 trays |
| Paper Size (80 g/m²) | Tray A (Non-Stapling) | | | Legal, Oficio II, Folio, 216 × 340 mm, Custom (cassette: 92 × 148 mm to 216 × 356 mm/Multi Purpose tray: 70 × 148 mm to 216 × 356 mm): 1500 sheets equivalent or 227 mm height A4, B5, A5, Letter, Statement, Executive, 16K: 3,000 sheets equivalent or 412mm height |
| | Tray B | | | Legal, Oficio II, Folio, 216 × 340 mm, Custom (cassette: 92 × 148 mm to 216 × 356 mm/Multi Purpose tray: 70 × 148mm to 216×356mm): 100 sheets equivalent or 14 mm height A4, B5, A5, B6, A6, B5(ISO), Cardstock, Oufuku hagaki (Return postcard), Letter, Statement, Executive, 16K: 200 sheets equivalent or 28 mm height |
| Stapling | Number of sheets to limit | | Legal, Oficio II, 216 × 340mm | 30 sheets (52 to 90 g/m ²) 20 sheets (91 to 105 g/m ²) 2 cover sheet only (106 g/m ² to 128 g/m ²) |
| | | | A4, B5, Letter, 16K | 50 sheets (52 to 90 g/m ²) 40 sheets (91 to 105 g/m ²) 2 cover sheet only (106 g/m ² to 128 g/m ²) |
| | Media types | | Plain, Recycled, Prepunched, Preprinted, Bond, Letterhead, Color, Coated, Thick, High Quality, Custom 1 to 8 | |
| Hole Punch Unit | Paper Size | Inch | 2 Hole | A4, B5, A5, Folio, 16K, Letter, Legal, Statement |
| | | | 3 Hole | A4, 16K, Letter |
| | cm | 2 Hole | A4, B5, A5, Folio, 16K, Letter, Legal, Statement | |
| | | 4 Hole | A4 | |
| | Paper Weight | | 60 to 220 g/m ² | |
| | Media types | | Plain, Preprinted, Bond, Recycled, Letterhead, Color, Thick, Coated, High Quality, Custom 1 to 8 | |
| Dimensions (W) × (D) × (H) | | | | 25.6" × 20.95" × 42.36" 650 × 532 × 1,075.8 mm |
| Weight | | | | Approx.21.0 lbs or less Approx.31 kg or less |

(6-8) Punch Unit (PH-5100/5110): For DF-5110

| Items | | | Description |
|--------------|------|--------|--|
| Paper Size | Inch | 2 Hole | A4, B5, A5, Folio, 16K, Letter, Legal, Statement |
| | | 3 Hole | A4, 16K, Letter |
| | cm | 2 Hole | A4, B5, A5, Folio, 16K, Letter, Legal, Statement |
| | | 4 Hole | A4 |
| Paper Weight | | | 60 to 220 g/m ² |
| Media types | | | Plain, Preprinted, Bond, Recycled, Letterhead, Color, Thick, Coated, High Quality, Custom 1 to 8 |

(6-9) Mailbox (MT-5100)

| Items | Description |
|----------------------------------|---|
| Number of Trays | 6 trays |
| Paper Size(80 g/m ²) | Tray 1 (to 5) 216 x 340mm, Oficioll, Foolscap (8.5 x 13.5"), Legal, Folio: 50 sheets A4, B5, A5, Letter, Executive, 16K, Statement: 100 sheets Tray A 216 x 340 mm, Oficioll, Foolscap (8.5 x 13.5"), Legal, Folio, Custom (70 x 298 to 210 x 1220 mm): 250 sheets A4, B5, A5, B6, A6, Letter, Executive, 16K, Statement, B5 (ISO), Hagaki (Cardstock), Oufukuhagaki (Return postcard), Custom (70 x 148 to 210 x 297 mm): 500 sheets |
| Dimensions (W) × (D) × (H) | 16.3" × 14.18" × 29.93" 414 × 360 × 760 mm |
| Weight | Approx. 17.7 lbs / Approx. 8 kg |

(6-10) Inner job separator (JS-5100)

| Items | Description |
|---|--|
| Number of Trays | 1 tray |
| Loadable sheets limit (80g/m ²) | 100 Sheets |
| Paper Size(80 g/m ²) | A4, A5, B5, A6, Letter, Legal, B6, Folio, 216 x 340 mm, Statement, Executive, Oficio II, 16K, B5 (ISO), Envelope #10, Envelope #9, Envelope #6 3/4, Envelope Monarch, Envelope DL, Envelope C5, youkei 4, youkei 2, Hagaki (Cardstock), Oufukuhagaki (Return postcard), Custom (70 x 148 to 210 x 1220 mm) |
| Supported Paper | Paper weight: 60 to 220 g/m ² Media types: Plain, Recycled, Material |
| Dimensions (W) × (D) × (H) | 14.18" × 12.56" × 6.07" 360 × 319 × 154 mm |
| Weight | Approx. 0.9 lbs / Approx. 0.4 kg |

(6-11) FAX System10: 35/40ppm models only**FAX function**

| Items | Description |
|---|--|
| Compatibility | G3 |
| Communication Line | Subscriber telephone line |
| Transmission Time | Less than 3 seconds (33600 bps, JBIG, ITU-T A4-R #1 chart) |
| Transmission Speed | 33600/31200/28800/26400/24000/21600/19200/16800/14400/12000/ 9600/7200/4800/2400 bps |
| Coding Scheme | JBIG/MMR/MR/MH |
| Error Correction | ECM |
| Paper Size | Max. width: 8 1/2"/216 mm, Max. length: 63"/1,600 mm |
| Number of originals to auto feed | Max. 75 sheets (with document processor) |
| Resolution | Scan: 200 × 100 dpi Normal (8 dot/mm × 3.85 line/mm) 200 × 200 dpi Fine (8 dot/mm × 7.7 line/mm) 200 × 400 dpi Super (Super Fine) (8 dot/mm × 15.4 line/mm) 400 × 400 dpi Ultra (Ultra Fine) (16 dot/mm × 15.4 line/mm) 600 × 600 dpi Print: 600 × 600 dpi |
| Gradations | 256 shades (Error diffusion) |
| One Touch Key | 1,000 keys |
| Multi-Station Transmission | Max. 500 destinations (Maximum number of stations: 500, maximum of 100 stations for i-Fax) |
| Substitute Memory Reception | 700 sheets or more (when using ITU-T A4 #1) |
| Image Memory Capacity | 16 MB (standard)(For fax transmission and reception) |
| Report Output | Send result report, FAX RX result report, Activity report, Status page |
| Option | Expansion memory, multi port, internet FAX kit |

Network FAX functions

| Items | Description |
|--------------------------------|--|
| Hardware | IBM PC-AT compatible computer |
| Interface | 10 BASE-T, 100 BASE-TX, 1000 BASE-T |
| Operating system | Windows XP, Windows Server 2003/2008/2008 R2/2012, Windows Vista, Windows 7, Windows 8 and Windows 8.1 |
| Transmission Resolution | Ultra fine (400 × 400dpi), Fine (200 × 200dpi), Normal (100 × 200dpi), 600 × 600dpi |
| Document Size | Letter, Legal, Statement, A4, A5, Folio, B5(JIS) |
| Scheduled job | Time setting by Network FAX driver (within 24 hours, 1 minute increments) |
| Transmit and Print | Fax transmission and print out at the machine is available |
| Broadcast Transmission | Max. 500 destinations (Maximum number of stations: 500, maximum of 100 stations for i-Fax) |

| Items | Description |
|-----------------------|---|
| Job Accounting | Requires the input of a Login User Name and Password in the Network FAX Driver when User Login, is turn ON in the fax machine. Requires the input of an Account ID in the Network FAX Driver when Job Accounting, is turned ON in the fax machine. |
| Cover Page | A format can be selected using the Network FAX Driver or a template can be created. |

(6-12) FAX System11: 30ppm model only**FAX function**

| Items | Description |
|---|---|
| Compatibility | G3 |
| Communication Line | Subscriber telephone line |
| Transmission Time | Less than 3 seconds (33600 bps, JBIG, ITU-T A4-R #1 chart) |
| Transmission Speed | 33600/31200/28800/26400/24000/21600/19200/16800/14400/12000/ 9600/7200/4800/2400 bps |
| Coding Scheme | JBIG/MMR/MR/MH |
| Error Correction | ECM |
| Paper Size | Max. width: 8 1/2"/216 mm, Max. length: 14 1/32"/356 mm |
| Number of originals to auto feed | Max. 75 sheets (with document processor) |
| Resolution | Scan: 200 × 100 dpi Normal (8 dot/mm × 3.85 line/mm) 200 × 200 dpi Fine (8 dot/mm × 7.7 line/mm) 200 × 400 dpi Super (Super Fine) (8 dot/mm × 15.4 line/mm) 400 × 400 dpi Ultra (Ultra Fine) (16 dot/mm × 15.4 line/mm) Print: 600 × 600 dpi |
| Gradations | 256 shades (Error diffusion) |
| One Touch Key | 100 keys |
| Multi-Station Transmission | Max. 100 destinations |
| Substitute Memory Reception | 256 sheets or more (when using ITU-T A4 #1) |
| Image Memory Capacity | 3.5 MB (standard)(For fax transmission and reception) |
| Report Output | Send result report, FAX RX result report, Activity report, Status page |
| Option | Handset (100 V model only) |

Network FAX functions


| Items | Description |
|--------------------------------|--|
| Hardware | IBM PC-AT compatible computer |
| Interface | 10 BASE-T/100 BASE-TX/1000 BASE-T |
| Operating system | Windows XP, Windows Server 2003/2008/2008 R2/2012, Windows Vista, Windows 7, Windows 8 and Windows 8.1 |
| Transmission Resolution | Ultra fine (400 × 400dpi), Fine (200 × 200dpi), Normal (100 × 200dpi) |
| Document Size | Letter, Legal, Statement, A4, A5, Folio, B5(JIS) |
| Scheduled job | Time setting by Network FAX driver (within 24 hours, 1 minute increments) |
| Transmit and Print | Fax transmission and print out at the machine is available |
| Broadcast Transmission | Max. 100 destinations |

| Items | Description |
|-----------------------|---|
| Job Accounting | Requires the input of a Login User Name and Password in the Network FAX Driver when User Login, is turn ON in the fax machine. Requires the input of an Account ID in the Network FAX Driver when Job Accounting, is turned ON in the fax machine. |
| Cover Page | A format can be selected using the Network FAX Driver or a template can be created. |

1-2 Part Names


(1) 30 ppm model

(1-1) Machine Exterior



1. Document Processor
2. Operation Panel
3. Power Switch
4. Cassette 1
5. Multi Purpose Tray
6. USB Memory Slot
7. Original Stopper
8. Original Eject Table
9. Original Table



10. Original Width Guides
11. Slit Glass
12. Inner Tray
13. Handles
14. Front Cover
15. Platen
16. Original Size Indicator Plates



- 17. Paper Width Guides
- 18. Paper Length Guide
- 19. Paper Width Adjusting Tab
- 20. Support Tray Section of the Multi Purpose Tray


- 21. Multi Purpose Tray
- 22. Paper Width Guides
- 23. Right Cover 1 Lever
- 24. Right Cover 1

(1-2) Connectors/Interior



- 1. Network Interface Connector
- 2. USB Interface Connector
- 3. Option Interface Slot
- 4. Toner Container (Yellow)


- 5. Toner Container (Cyan)
- 6. Toner Container (Magenta)
- 7. Toner Container (Black)
- 8. Waste Toner Box

(1-3) With Optional Equipments Attached

1. Mailbox (MT-5100)
2. Inner finisher (DF-5100)
3. Inner job separator (JS-5100)
4. Cassette3 (PF-5120)

5. Cassette3 (PF-5130)
6. Cassette4 (PF-5130)
7. High capacity paper feeder (PF-5140)





(1-4) FAX System 11



1. LINE Connector
Connect the modular cords for telephone line.

2. TEL Connector
When using an available telephone, connect it here.

(1-5) Operation Panel Keys

| | | | | | |
|--|---------------------------|---|--|--|--|
|  Home | Displays the Home screen. |  Status/Job Cancel | Displays the Status/Job Cancel screen. |  Send | Displays the screen for sending. You can change it to display the Address Book screen. |
| | | |  Copy | | Displays the Copy screen. |














Lights when there is paper in the job separator tray.

Touch panel. Displays buttons for configuring machine settings.


Blinks while printing or sending/receiving.

Blinks while the machine is accessing the machine memory, fax memory or USB memory (general purpose item).

Lights or blinks when an error occurs and a job is stopped.


| | | | | | |
|---|--|---|--|--|---|
|  System Menu / Counter | Displays the System Menu/Counter screen. |  Authentication/Logout | Authenticates user switching, and exits the operation for the current user (i.e. log out). |  Energy Saver | Puts the machine into Sleep Mode. Recovers from Sleep if in Sleep Mode. |
|  Numeric keys. Enter numbers and symbols. | |  Clear | Clears entered numbers and characters. |  Reset | Returns settings to their default states. |
| | |  Quick No. Search | Specifies registered information such as address numbers and user IDs by number. |  Stop | Cancels or pauses the job in progress. |
|  Interrupt | Displays the Interrupt Copy screen. |  Enter | Finalizes numeric key entry, and finalizes details during setting of functions. Operates linked with the on-screen [OK]. |  Start | Starts copying and scanning operations and processing for setting operations. |

(2) 35/40 ppm models
(2-1) Machine Exterior



- 1. Operation Panel
- 2. Power Switch
- 3. Cassette 1
- 4. Multi Purpose Tray
- 5. USB Memory Slot
- 6. Slit Glass
- 7. Inner Tray


- 8. Handles
- 9. Front Cover
- 10. Platen
- 11. Original Size Indicator Plates




- 12. Paper Width Guides
- 13. Paper Length Guide
- 14. Paper Width Adjusting Tab
- 15. Support Tray Section of the Multi Purpose Tray

- 16. Multi Purpose Tray
- 17. Paper Width Guides
- 18. Right Cover 1 Lever
- 19. Right Cover 1


(2-2) Connectors/Interior



(35 ppm model)



(40 ppm model)




- 1. Network Interface Connector
- 2. USB Interface Connector *1
- 3. Option Interface Slot
- 4. Toner Container (Yellow)

- 5. Toner Container (Cyan)
- 6. Toner Container (Magenta)
- 7. Toner Container (Black)
- 8. Waste Toner Box


*1: 220-240 V model: Option

(2-3) With Optional Equipments Attached



- 1. Cassette2 (PF-5120)
- 2. Cassette3 (PF-5130)
- 3. Cassette4 (PF-5130)
- 4. Cassette3 (PF-5140)
- 5. Inner job separator (JS-5100)
- 6. Inner finisher (DF-5100)

- 7. Document Processor (DP-5100)
- 8. Document Processor (DP-5110)
- 9. Mailbox (MT-5100)
- 10. Bridge Unit (AK-5100)
- 11. Finisher (DF-5120)
- 12. Finisher (DF-5110)

(2-4) FAX System 10**1. LINE Connector (L1)**

Connect the modular cords for telephone line. This connector is port 1.













2. TEL Connector (T1)


When using an optional handset or available telephone, connect it here.


3. LINE Connector (L2)


If installing 2 FAX kits, 2 ports are available. Connect the modular cords for telephone line.

(2-5) Operation Panel Keys


| | | |
|---|--|--|
|  | Displays the Home screen. | |
|  | Displays the System Menu screen. |  Counter Displays the Counter screen. |
|  | Displays the Status/Job Cancel screen. |  Copy Displays the Copy screen. |
|  | Displays the help guidance. |  Send Displays the screen for sending. You can change it to display the Address Book screen. |
|  | Switches the touch panel display on the Copy screen and the Send screen to a magnified view. |  FAX Displays the FAX screen. |
|  Auto Color  Full Color  Black & White | Select the color mode. Auto Color: Automatically recognizes whether a document is color or black & white and then scans the document. Full Color: Scans all documents in full color. Black & White: Scans all documents in black & white. | |

 Energy Saver
Puts the machine into Sleep Mode. Recovers from Sleep if in Sleep Mode.

 Authentication/Logout
Authenticates user switching, and exits the operation for the current user (i.e. log out).

 Interrupt
Displays the Interrupt Copy screen.

Touch panel.
Displays buttons for configuring machine settings.










Lights when there is paper in the job separator tray.

Blinks while printing or sending/receiving.

Blinks while the machine is accessing the hard disk, fax memory or USB memory (general purpose item).


Lights or blinks when an error occurs and a job is stopped.








| | | | |
|---|---|---|--|
|  | Numeric keys. Enter numbers and symbols. |  Clear Clears entered numbers and characters. |  Reset Returns settings to their default states. |
| | |  Quick No. Search Specifies registered information such as address numbers, user IDs and program numbers by number. |  Stop Cancels or pauses the job in progress. |
| | |  Enter Finalizes numeric key entry, and finalizes details during setting of functions. Operates linked with the on-screen [OK]. |  Start Starts copying and scanning operations and processing for setting operations. |

1-3 Optional Equipment

(1) 30 ppm model

The following options are available for this machine.
















Software option
(13)UG-33
(14)Data Security Kit (E)

(2) 35/40 ppm models


The following options are available for this machine.



*1: Inch, *2: Metric



Software option
 (20)Internet FAX Kit(A)
 (21)Data Security kit(E)
 (22)UG-33
 (23)UG-34
 (24)Scan extension kit(A)



(3) Option**(3-1) DP-5100 "Document Processor (Reverse Automatic)": 35/40ppm models only****(3-2) DP-5110 "Document Processor (Dual Scan)": 35/40ppm models only**

Automatically scans originals. Also you can perform duplex copying and split copying.

(3-3) MT-5100 "Mailbox"

This equipment separates the paper output tray destination to easily sort documents. Installing this option adds 6 output trays. When multiple computer users share the printer, each user can print to a specified tray.

(3-4) DF-5110 "1,000-Sheet Finisher": 35/40ppm models only

This equipment can stack high capacity paper and can offset each copy to sort. Sorted output documents can be stapled or hole punched (optional)

(3-5) DF-5120 "3,000-Sheet Finisher": 35/40ppm models only

This equipment can stack high capacity paper and can offset each copy to sort. Sorted output documents can be stapled or hole punched.

(3-6) PF-5120 "Paper Feeder (500-sheet)"

The number of sheets and setting method is same as for the standard cassette.

(3-7) PF-5130 "Paper Feeder (500-sheet x2)"

The number of sheets and setting method is same as for the standard cassette.

(3-8) PF-5140 "Large Capacity Feeder (2,000-sheet)"

In addition to the standard cassette, the high capacity feeder can be installed to load A4 or Letter 2,000 sheets of paper.

(3-9) JS-5100 "Job Separator"

This equipment separates the paper output tray destination to easily sort documents. Specify as the output tray for copy or print jobs. Or, specify as the default output tray for printing from the copy or Document Box screen, printing from the PC, and printing of the received fax data.

NOTE

Select the output tray at the copy screen or set the default setting to output documents to the inner job separator.

(3-10) DF-5100 "Inner Finisher"

This equipment can stack high capacity paper and can offset each copy to sort. Sorted output documents can be stapled.

(3-11) PH-5100*1, 5110*2 "Punch Unit": 35/40ppm models only (*1: inch, *2: metric)

Attaches to the 1,000-Sheet Finisher and is used to punch holes.

(3-12) FAX System 10 "FAX Kit": 35/40ppm models only

The FAX kit can be used as a FAX and network FAX that enables document transmission and reception from a PC. Installing 2 FAX kits enables connecting to 2 lines and multi-destination transmission in a short time. 1 port can be for reception only and it reduces the time unavailable for reception

(3-13) FAX System 11 "FAX Kit": 30ppm model only

The FAX kit can be used as a FAX and network FAX that enables document transmission and reception from a PC.

(3-14) IB-50 "Network Interface Kit"

The Network Interface Kit provides a high-speed connection for the Gigabit-per-second interface. Network printing is available with the network protocols such as TCP/IP and NetBUEI for a variety of OS of Windows, Macintosh and UNIX.

(3-15) IB-51 "Wireless Network Interface Kit"

This is a wireless LAN interface card which supports the wireless LAN specifications IEEE802.11n (Max 300Mbps) and 11g/b. With the utilities supplied, settings are possible for a variety of OS and network protocols.

(3-16) MM-16-128 "FAX Expansion Memory": 35/40ppm models only

Image storage memory (128 MB) that allows the machine to receive more pages of incoming faxed originals. Expansion memory is installed and uninstalled by our service technician.

(3-17) HD-11 "Hard Disk": 35ppm model only

With Hard Disk installed in the machine, received data can be rasterized and stored on this Hard Disk. This enables high-speed printing of multiple copies using an electric sort function. Also, you can use the Document Box functions.

(3-18) Key Counter "Key Counter": 35/40ppm models only

Use the key counter to monitor machine usage. This can be utilized for centralized management of departmental copy counts.

NOTE

When the key counter function is activated, copies can only be made when a key counter is inserted. If the key counter is not inserted, "Insert the key counter." will be displayed.

(3-19) MK-2 "Key card": 35/40 ppm models only

Using a key card enables checking copy counts by its departmental card. The key card offers a convenient solution for centralized management of copy volume for different departments in a large company.

(3-20) Card Authentication Kit(B) "Card Authentication Kit"

User login administration can be performed using ID cards. To do so, it is necessary to register ID card information on the previously registered local user list. Refer to the operation guide of the ID card authentication kit for how to register.

(3-21) "Expansion Memory": 30ppm model only

The machine can perform more multiple jobs simultaneously by adding more memory. You can increase the machine's memory up to 2,048MB by plugging in the optional memory modules (2,048MB).

(3-22) "SD/SDHC Memory Card"

SD/SDHC memory card is a micro chip card that can save optional fonts, macros, forms.

(3-23) DT-5100 "Document Table"

Place original or other documents when using the machine.

(3-24) Internet FAX Kit(A) "Internet FAX Kit": 35/40ppm models only

Activating the Internet FAX Kit sends and receives faxes via the Internet without using a phone line. This can be extended only when the FAX kit is installed.

(3-25) Data Security Kit(E) "Data Security Kit"

The Data Security Kit overwrites all unnecessary data in the storage area of the hard disk so that it cannot be retrieved. The Data Security Kit encrypts data before storing it in the hard disk. It guarantees higher security because no data cannot be decoded by ordinary output or operations.

(3-26) UG-33 "ThinPrint Option"

Direct printing without a printer driver is also available.

(3-27) UG-34 "Emulation Upgrade Kit": 35/40ppm models only

Add an emulation to operate this machine with the commands of another printer. Installing this option enables IBM Proprinter, Line Printer, and EPSON LQ-850 emulation.

(3-28) Scan extension kit(A) "OCR Scan Activation Kit": 35/40ppm models only

This option enables the use of the OCR function in the applications of the machine.

1-4 Unit Compatibility


Unit configuration of each model is as follows.

| Unit | 30 ppm model | 35 ppm model | 40 ppm model |
|-------------------------------|---|---|--|
| Cassette, primary feed | CASSETTE ASSY (302R45872_) PARTS PRIMARY FEED ASSY SP (302R49421_) Common module | | |
| Conveying, Duplex | PARTS CONVEYING ASSY SP (302R49406_) Common path line, 100% duplex productivity module | | |
| Primary transfer | TR-5195 (302R49302_) 4-color developer separation module with primary transfer belt | | |
| Secondary transfer | PARTS 2ND TRANS ASSY SP (302R49407_) Separation GND common module | | |
| LSU | LK-5195 (302R49315_) One-way single polygon motor with a single beam | | |
| Eject | PARTS EXIT ASSY SP (302R49405_) 500-sheet stack | | |
| Drum | DK-5195 (302R49305_) OPC drum module | | DK-5215 (302R69302_) a-Si drum module |
| Developing | DV-5195K (302R49307_) DV-5195M (302R49308_) DV-5195C (302R49309_) DV-5195Y (302R49310_) | DV-5205K (302R59301_) DV-5205M (302R59302_) DV-5205C (302R59303_) DV-5205Y (302R59304_) | DV-5215K (302R69304_) DV-5215M (302R69305_) DV-5215C (302R69306_) DV-5215Y (302R69307_) |
| Fuser | FK-5195 (302R49311_) : 240V FK-5196 (302R49312_) : 100V FK-5197 (302R49313_) : 120V Single heater module | FK-5205 (302R69308_) : 240V FK-5206 (302R69309_) : 100V FK-5207 (302R69310_) : 120V Twin heater module | |
| MPF | PARTS MPF TABLE ASSY L SP (302R49409_) 100 stack (without size detection) | PARTS MPF TABLE ASSY H SP (302R69402_) 100 stack (with size detection) | |
| ISU | ISU ASSY L SP (302R49314_) All-in-one carriage module Polaris common CCD equipped | ISU ASSY H SP (302R69312_) All-in-one carriage module High speed scanning CCD equipped | |
| Operation section | PARTS OPERATION UNIT L SP (302R49410_) Tiltable 4.3inch Color Touch Panel | PARTS OPERATION UNIT H JP (302R69403_) Tiltable 7inch color touch panel | |

| Unit | 30 ppm model | 35 ppm model | 40 ppm model |
|------------------|--|---|---|
| Container | <p>For 220-240 V model</p> <p>TK-5195K (1T02R40NL_)</p> <p>TK-5195M (1T02R4BNL_)</p> <p>TK-5195C (1T02R4CNL_)</p> <p>TK-5195Y (1T02R4ANL_)</p> <p>For 100 V model</p> <p>TK-5196K (1T02R40JP_)</p> <p>TK-5196M (1T02R4BJP_)</p> <p>TK-5196C (1T02R4CJP_)</p> <p>TK-5196Y (1T02R4AJP_)</p> <p>For 120 V model</p> <p>TK-5197K (1T02R40US_)</p> <p>TK-5197M (1T02R4BUS_)</p> <p>TK-5197C (1T02R4CUS_)</p> <p>TK-5197Y (1T02R4AUS_)</p> <p>For Australia</p> <p>TK-5199K (1T02R40AS_)</p> <p>TK-5199M (1T02R4BAS_)</p> <p>TK-5199C (1T02R4CAS_)</p> <p>TK-5199Y (1T02R4AAS_)</p> <p>Compatibility</p> <p>Toner capacity</p> <p>(K: 15K/MCY: 7K)</p> | <p>For 220-240 V model</p> <p>TK-5205K (1T02R50NL_)</p> <p>TK-5205M (1T02R5BNL_)</p> <p>TK-5205C (1T02R5CNL_)</p> <p>TK-5205Y (1T02R5ANL_)</p> <p>For 100 V model</p> <p>TK-5206K (1T02R50JP_)</p> <p>TK-5206M (1T02R5BJP_)</p> <p>TK-5206C (1T02R5CJP_)</p> <p>TK-5206Y (1T02R5AJP_)</p> <p>For 120 V model</p> <p>TK-5207K (1T02R50US_)</p> <p>TK-5207M (1T02R5BUS_)</p> <p>TK-5207C (1T02R5CUS_)</p> <p>TK-5207Y (1T02R5AUS_)</p> <p>For Australia</p> <p>TK-5209K (1T02R50AS_)</p> <p>TK-5209M (1T02R5BAS_)</p> <p>TK-5209C (1T02R5CAS_)</p> <p>TK-5209Y (1T02R5AAS_)</p> <p>Compatibility</p> <p>Toner capacity</p> <p>(K: 18K/MCY: 12K)</p> | <p>For 220-240 V model</p> <p>TK-5215K (1T02R60NL_)</p> <p>TK-5215M (1T02R6BNL_)</p> <p>TK-5215C (1T02R6CNL_)</p> <p>TK-5215Y (1T02R6ANL_)</p> <p>For 100 V model</p> <p>TK-5216K (1T02R60JP_)</p> <p>TK-5216M (1T02R6BJP_)</p> <p>TK-5216C (1T02R6CJP_)</p> <p>TK-5216Y (1T02R6AJP_)</p> <p>For 120 V model</p> <p>TK-5217K (1T02R60US_)</p> <p>TK-5217M (1T02R6BUS_)</p> <p>TK-5217C (1T02R6CUS_)</p> <p>TK-5217Y (1T02R6AUS_)</p> <p>For Australia</p> <p>TK-5219K (1T02R60AS_)</p> <p>TK-5219M (1T02R6BAS_)</p> <p>TK-5219C (1T02R6CAS_)</p> <p>TK-5219Y (1T02R6AAS_)</p> <p>Compatibility</p> <p>Toner capacity</p> <p>(K: 20K/MCY: 15K)</p> |

2-2 Installing the main unit

Installation procedures



IMPORTANT

- *1: Default setting: Approx. 2 minutes for 40ppm model
It will take about 6 minutes for 30/35 models since the drum initial setting is necessary.

Do not execute the maintenance mode during the initial setting drive.

(1) Unpacking and checking bundled items

Take out the main unit and accessories from the packing case.
Remove the tape and cushioning materials for packing from the main unit.

(1-1) 30 ppm model




Figure 2-2

- | | | |
|--------------------|-----------------------|----------------------|
| 1. Outer case | 8. Size label | 15. Bottom case |
| 2. Left upper pad | 9. Power cord | 16. Left bottom pad |
| 3. Right upper pad | 10. Original tray pad | 17. Right bottom pad |
| 4. Inner box | 11. Left middle pad | 18. Skid |
| 5. Inner pad | 12. Right front pad | 19. Hinge |
| 6. Accessories box | 13. Operation cover | |
| 7. Inner tray | 14. Main unit | |

Note: Make sure to install the main unit on a level surface.

(1-2) 35/40 ppm models




Figure 2-3

- | | | |
|--------------------|---------------------|----------------------|
| 1. Outer case | 7. Size label | 13. Bottom case |
| 2. Upper pad | 8. Power cord | 14. Left bottom pad |
| 3. Inner box | 9. Left middle pad | 15. Right bottom pad |
| 4. Inner pad | 10. Right front pad | 16. Skid |
| 5. Accessories box | 11. Operation cover | 17. Hinge |
| 6. Inner tray | 12. Main unit | |

Note: Make sure to install the main unit on a level surface.

(2) Unpacking and checking bundled items(option units)

(2-1) Paper Feeder(PF-5120)




Figure 2-4

- | | | |
|----------------------------|-----------------------------|----------------------------|
| 1. Main unit | 6. Right of the inner frame | 11. Guide protection plate |
| 2. Outer case | 7. Main unit cover | |
| 3. Left bottom pad | 8. Upper pad | |
| 4. Right bottom pad | 9. Pin/Screw | |
| 5. Left of the inner frame | 10. Size label | |

(2-2) Paper Feeder(PF-5130)




Figure 2-5

- | | | |
|-----------------------------|--------------------------|----------------------------|
| 1. Main unit | 7. Main unit cover | 13. Rear left upper pad |
| 2. Outer case | 8. Upper pad | 14. Front right upper pad |
| 3. Left bottom pad | 9. Reinforcement plate | 15. Rear right upper pad |
| 4. Right bottom pad | 10. Size label | 16. Guide protection plate |
| 5. Front of the inner frame | 11. Screw | |
| 6. Rear of the inner frame | 12. Front left upper pad | |

(2-3) Paper Feeder(PF-5140)






Figure 2-6


- | | | |
|-----------------------------|--------------------------|----------------------------|
| 1. Main unit | 7. Main unit cover | 13. Rear left upper pad |
| 2. Outer case | 8. Upper pad | 14. Front right upper pad |
| 3. Left bottom pad | 9. Reinforcement plate | 15. Rear right upper pad |
| 4. Right bottom pad | 10. Size label | 16. Guide protection plate |
| 5. Front of the inner frame | 11. Screw | 17. Cushion |
| 6. Rear of the inner frame | 12. Front left upper pad | |

(2-4) Document processor(DP-5100): 35/40 ppm models only**Figure 2-7**

- | | | |
|-----------------------|------------------------|---------------------------|
| 1. Outer case | 5. Poly sheet | 9. Rear right upper pad |
| 2. Rear bottom pad | 6. Original mat holder | 10. Front left upper pad |
| 3. Front bottom pad | 7. Original mat | 11. Front right upper pad |
| 4. Document processor | 8. Rear left upper pad | |

(2-5) Document processor(DP-5110): 35/40 ppm models only**Figure 2-8**

- | | | |
|------------------------|--------------------------|---------------------------|
| 1. Outer case | 7. Original mat | 13. Front left upper pad |
| 2. Rear bottom pad | 8. DP relay PWB | 14. Front right upper pad |
| 3. Front bottom pad | 9. Screw | |
| 4. Document processor | 10. DP relay PWB holder | |
| 5. Poly sheet | 11. Rear left upper pad | |
| 6. Original mat holder | 12. Rear right upper pad | |

(2-6) Inner finisher(DF-5100)**Figure 2-9**

- | | | |
|---------------------|---------------------|-----------------------|
| 1. Outer case | 5. Right bottom pad | 9. Upper pad |
| 2. Rear bottom pad | 6. Main pad | 10. Right front cover |
| 3. Front bottom pad | 7. Inner finisher | 11. Cartridge |
| 4. Left bottom pad | 8. Main unit cover | 12. Screw |

(2-7) 1000-sheet finisher(DF-5110): 35/40 ppm models only




Figure 2-10

- | | | |
|---------------------|--------------------|---------------------|
| 1. Skid | 7. Right spacer | 13. Rear upper pad |
| 2. Rear bottom pad | 8. Main tray | 14. Front upper pad |
| 3. Front bottom pad | 9. Interlock cover | 15. Outer case |
| 4. Finisher | 10. Cartridge | 16. Hinge |
| 5. Main unit cover | 11. Ground plate | |
| 6. Left spacer | 12. Joint plate | |

(2-8) 3000-sheet finisher(DF-5120): 35/40 ppm models





Figure 2-11


- | | | |
|---------------------|---------------------|---------------------|
| 1. Skid | 7. Right spacer | 13. Joint plate |
| 2. Rear bottom pad | 8. Main tray | 14. Rear upper pad |
| 3. Front bottom pad | 9. Sub tray | 15. Front upper pad |
| 4. Finisher | 10. Interlock cover | 16. Outer case |
| 5. Main unit cover | 11. Cartridge | 17. Hinge |
| 6. Rear spacer | 12. Ground plate | |

(2-9) Mailbox(MT-5100)**Figure 2-12**

- 1. Outer case
- 2. Right lower spacer
- 3. Left lower spacer
- 4. Lower cover

- 5. Mailbox
- 6. Poly sheet
- 7. Left upper spacer
- 8. Right upper spacer

- 9. Eject tray
- 10. Upper pad
- 11. Side cover

(2-10) Punch unit(PH-5110)**Figure 2-13**

1. Outer case
2. Bottom pad
3. Punch unit

4. Upper pad
5. Punch PWB
6. Waste punch box guide

7. Drive unit
8. Waste punch box

(3) Notes on main unit transportation

*: When transporting the main unit, lift the left and right of the lower part the main unit base (as marked by red circles) with four people as shown in the figure.

Do not hold the operation unit because it will cause damage.




Figure 2-14

*: Carry the paper feeder (PF-5130/5140) with two people by holding the parts as shown in the figure.




Figure 2-15

(4) Attaching the sub tray

Attach the bundled sub tray to the inner tray.

*: No sub tray is required when installing the DF-5100 inner finisher.

Procedures

1. Slide the sub tray (a) and insert four protrusions (b) into four apertures (c) on the inner tray.
2. Check two projections (d) are locked at two apertures (e) of the inner tray.




Figure 2-16

(5) Setting up the Toner Container

Set up 4 color toner containers of C, M, Y, and K.




Figure 2-17

(6) Cassette heater connection (100 V 40 ppm model only)

*: Because the cassette heater connector is not connected at shipment, connect it to the main unit.

Procedures

1. Pull out the cassette (a) from the main unit (b) and remove it in the direction of the arrow.




Figure 2-18

2. Press the lock lever (a) and pull out the primary feed unit (c) from the paper feeder (b).




Figure 2-19

3. Lift up the protrusion (b) of the hook and unlatch it from the round hole (d). Slide the connector cover (a) in the direction of the arrow and unlatch two hooks (c) from the square hole (e) to remove it.
 4. Connect the heater connector (g) to the main machine side connector (h).
 5. Reattach the connector cover (a) in the original position.
- *: Make sure the wire (f) does not float.




Figure 2-20

6. Reattach the parts in the original position.

IMPORTANT

Set maintenance mode U327 [Cassette heater On/Off] to [On] after turning the power on.

When connecting the cassette heater, do not unplug the power cord. (Power is supplied when the power is switched off)
 Also, if unplugged for a prolonged time, it may cause blurred images depending on the environment. In this case, execute [System Menu] > [Adjustment/Maintenance] > [Drum Refresh] .

(7) Optional unit installation

Install necessary optional units in the main unit by referring to the installation procedures. (See page 10-1)

*: When not in use of the optional paper feeder, attach the bundled shield plate as shown below.

Procedures

1. Fit two hooks (a) into two holes (b) on the rear lower cover.
2. Secure the shield plate (d) with the screw (c) (M4x20).




Figure 2-21

USB Interface (option) usage: 220-240 V 35/40ppm models only

Procedures

1. Remove the screw (a) (M3x8).
2. Release the hook (b) in the direction of the arrow and then remove the controller cover (c).
3. Peel off the cover sheet (d) at the backside of the controller cover (c) and reattach it.





Figure 2-22

(8) Connecting the Interface Cable


| Connection environment | Functions | Necessary Cable |
|--------------------------------------|-----------------------------|--|
| Connect a LAN cable to the main unit | Printer/Scanner/Network FAX | LAN cable (10Base-T, 100Base-TX or 100Base-T) |
| Connect a USB cable to the main unit | Printer/Scanner (TWAIN/WIA) | USB2.0 compatible cable (Hi-Speed USB compliant, Max. 5.0m long) |

In the case of the LAN connection



1. Connect the LAN cable to the network interface connector.
2. Connect the other end of the cable to the hub.

(30 ppm model)



(35/40 ppm models)






Figure 1-2-1

In the case of the USB connection



1. Connect the USB cable to the USB interface connector located on the rear side of the main unit.
2. Connect the other end of the cable to the PC.

(30 ppm model)



(35/40 ppm models)




Figure 1-2-2

(9) Connecting the FAX cable (FAX installation only)

General FAX connection example
In the case of the general telephone line

- a. Modular jack



Figure 1-2-3

ADSL

Connect a cord between the LINE connector of the main unit and the PHONE port of the splitter.

- a. Modular jack
- b. ADSL modem
- c. Splitter (PHONE port)
- d. PC




Figure 1-2-4

ISDN

Connect a cord between the LINE connector of the main unit and the analog port of the terminal adapter.

- a. Modular jack
- b. Terminal adapter (Analog port)
- c. PC




Figure 1-2-5

Modular cord connection

Connect a modular cord to the LINE connector of the main unit.

When using a commercially available telephone set, connect a modular cord to the TEL connector of the main unit.




Figure 1-2-6

(10) Loading Paper

(10-1) Precaution for Loading Paper

Before loading paper in the cassette or MP tray, fan the paper taken from a package to separate it, and then tap it on a level surface to align the edges.




Figure 2-3

In addition, note the following points.

If the paper is curled or folded, straighten it before loading. Such paper may cause a jam.

If paper is left under high temperature and high humidity after taking it out of the package, it may cause trouble with paper absorbing moisture. After setting paper in the cassette, seal the rest of the paper in the paper storage bag.

Also, seal the paper remaining on the MP tray in the paper storage bag.

If paper is left in the cassette for a long period, heat from the cassette heater may discolor it.

If the machine will not be used for a prolonged period, protect all paper from humidity by removing it from the cassettes and sealing it in the paper storage bag.

IMPORTANT

If you reuse paper already used for printing, remove staples or clips. Do not use paper with a staple or clip. This may cause poor image quality or malfunctions.

(10-2) Set paper in the cassette

The cassettes can hold plain paper, recycled paper, color paper, etc.

The cassette can hold 550 sheets of plain paper (64g/m²) or 500 sheets of plain paper (80g/m²).

The cassette can hold paper with the weight of 60 to 220g/m².

Do not hold paper heavier than 220g/m² in the cassette. Use the MP tray for a postcard of 230g/m² weight.

1. Pull the cassette completely out of the main unit.




Figure 2-4

NOTE

Do not pull out multiple cassettes simultaneously.

2. Adjust the position of the paper guides.

1. Adjust the paper width guides. Press the tab and slide the guides to the paper size to use.

2. Adjust the paper length guide. Press the tab and slide the guides to the paper size to use.




Figure 2-5

3. Load paper.

1. Fan the paper, then tap it on a level surface to align the edges.
2. Load the paper in the cassette after aligning its edges.




Figure 2-6

Note

Load the paper with the print side facing up.

Before loading paper in the cassette, fan the paper taken from a new package to separate it. (See page 2-23)

Before loading the paper, be sure that it is not curled or folded. Such paper may cause paper jams.

Make sure that the loaded paper does not exceed the level indicator (see the illustration above).

If paper is loaded without adjusting the paper length guide and paper width guides to the paper size to use, the paper may skew or become jammed.

4. Gently insert the cassette all the way into the main unit.




Figure 2-7

(10-3) Set paper in the high capacity feeder

The high capacity feeder can hold A4/Letter size plain paper, recycle paper or color paper.

The high capacity feeder can load 2,200 sheets of plain paper (64g/m²) or 2,000 sheets of plain paper (80g/m²).

The cassette can hold paper with the weight of 60 to 220g/m².

1. Pull the cassette completely out of the main unit.





Figure 2-8

2. Load paper.
 1. Fan the paper, then tap it on a level surface to align the edges.
 2. Load the paper in the cassette after aligning its edges.

**Figure 2-9****Note**


Load the paper with the print side facing up.

Before loading paper in the high capacity paper feeder, fan the paper taken from a new package to separate it. (See page 2-23)

Before loading the paper, be sure that it is not curled or folded. Such paper may cause paper jams.

Make sure that the loaded paper does not exceed the level indicator (see the illustration above).

3. Gently insert the high capacity feeder all the way.

**Figure 2-10**

(11) Connecting the Power Cord

1. Connect one end of the supplied power cord to the main unit and the other end to a power outlet.

*: Only use the power cord that comes with the main unit.

*: 30ppm model due to its construction may indicate the operation display momentarily when connecting the power cord.




Figure 2-11

(12) Turn the power on

1. Turn the power switch on.




Figure 2-12

IMPORTANT

After turning off the power switch, do not turn on the power switch again immediately. Wait 5 seconds or more, and then turn on the power switch.

(13)Default Setting

Set up necessary items in the following procedures.

*: For 30ppm model, the set-up wizard starts up at the first power-up.

30 ppm model



Figure 2-13

35/40 ppm models



Figure 2-14

(13-1)Setting Date and Time

Follow the steps below to set the local date and time at the place of installation.

1. Display the screen
 [System Menu/Counter] key or [System Menu] key
 > [Date/Timer/Energy Saver]
2. Configure the settings
 Select [Time Zone] > [Date/Time] > [Date Format] in this order for settings.

| Item | Descriptions |
|--------------------|---|
| Time Zone | Set the time difference from GMT. Choose the nearest listed location from the list. If you select a region that utilizes summer time, configure settings for summer time. |
| Date/Time | Set the date and time for the location where you use the machine. If you perform Send as E-mail, the date and time set here will be displayed on the header. Value: Year (2000 to 2037), Month (1 to 12), Day (1 to 31), Hour (00 to 23), Minute (00 to 59), Second (00 to 59) |
| Date Format | Select the display format of year, month, and date. The year is displayed in Western notation. Value: Month/Day/Year, Day/Month/Year, Year/Month/Day |

(13-2) Network Setup (LAN Cable Connection)

TCP/IP (IPv4) Settings

Set up TCP/IP (IPv4) to connect to the Windows network.

The default settings are as follows.

- TCP/IP: On
- DHCP: On
- Auto-IP: On
- IP Address: 0.0.0.0
- Subnet Mask: 0.0.0.0
- Default Gateway: 0.0.0.0

Setting procedures

1. Select [System Menu/Counter] key or [System Menu] key > [System/Network] > [Network] > [TCP/IP Setting].
2. Select [IPv4] for setting.
3. Restart the network from System Menu, or turn the power off and then on waiting 5 seconds or more.

When using DHCP server

[DHCP]: Set to [On]

When setting the static IP address

[DHCP]: Set to [Off]

[IP Address]: Enter the address.

[Subnet Mask]: Enter the address.

[Default Gateway]: Enter the address.

When setting Auto IP, set the IP address to 0.0.0.0.

*: The factory default login user name and login password are set as shown below.

| Model name | 30 ppm model | 35 ppm model | 40 ppm model |
|-----------------|--------------|--------------|--------------|
| Login User Name | 3000 | 3500 | 4000 |
| Login Password | 3000 | 3500 | 4000 |

(13-3) Altitude Adjustment Setting

Execute [Altitude Adjustment] from the System Menu when setting up at a high altitude place.

When the printing quality declines in the environment of an altitude higher than 1500m sea level, the setting of [Altitude Adjustment] mode can recover the printing quality.

Maintenance mode U140

1. Input "140" using the numeric keys and press the [Start] key.
2. Select [Altitude Adjustment].
3. Select the altitude range of [1001 to 2000m], [2001 to 3000m] or [3001 to 3500m].
4. Press the [Start] key.
5. Press the [Stop] key.

In case of [System Menu] (30ppm model only)

1. Displays the screen.
[System Menu/Counter] key > [Adjustment/Maintenance] > [Service Setting] > [Altitude Adjustment]
2. Select the altitude range of [1001 to 2000m], [2001 to 3000m] or [3001 to 3500m].
*: Standard: Altitude from 0 to 1000m
3. Press the [Start] key.

IMPORTANT

For 40ppm model, execute the U140 [Adjust Developing Bias] after high altitude adjustment.

1. Input "140" using the numeric keys and press the [Start] key.
2. Select [AC Calib].
3. Select [Calibration].
*: Set the developer (All color) to On to execute AC calibration.
4. Select [Execute] and press the [Start] key.
*: Calibration starts.
5. Turn the power switch off then on after completing Calibration. Wait more than 5 seconds between the power off and on.
*: An error code appears when there is an error.
6. Execute [System Menu/Counter] key > [Adjustment/Maintenance] > [Magnification].

If the developer leak occurs at the above,

execute U140 [AC Calib] > [Calibration] for the developer unit where the leak has occurred again.

After that, lower U140 [AC Calib] > [Calibration].

Then, execute 1 through 6 as marked Important above.

(13-4) Paper size and media type setting

1. Select [System Menu/Counter] key or [System Menu] key > [Cassette/MP tray Settings].
2. Select [Cassette Setting] > [Cassette 1 (- 4)] or [MP Tray Setting].
3. Select [Paper Size] and [Media Type] to set them.

(14)Installing Software

Install appropriate software in your PC from the bundled DVD (Product Library) if you want to use the printer function of this machine or perform TWAIN / WIA transmission or Network FAX transmission from your PC. (See the Operation Guide supplied with the main unit)

(15)Maintenance mode workflow (Maintenance mode U952)

1. Input "10871087" using the numeric keys to enter the maintenance mode.
2. Input "952" using the numeric keys and press the [Start] key.
3. Select the place to save the data to execute.
4. Select the item to execute.
5. Press the [Start] key to execute the process.
6. Press the [Stop] key.

*: If not executing the U952, set it in the procedures below.

(15-1) Setting the ID correction operation (Maintenance mode U464)

- 1.Input "464" using the numeric keys and press the [Start] key.
- 2.Select [Calib].
- 3.Select [Full].
- 4.Press the [Start] key.
*: Calibration starts.
- 5.Press the [Stop] key.

(15-2) Color registration adjustment (Maintenance mode U469)

- 1.Input "469" using the numeric keys and press the [Start] key.
- 2.Select [Auto]. Outputs the automatic adjustment chart.
- 3.Select [Execute].
- 4.Set the chart on the table and press the [Start] key.
*: Execute the automatic adjustment. [OK] is indicated when adjustment is completed.
- 5.Press the [Stop] key.

(15-3) Adjusting the halftone automatically (Maintenance mode U410)

: 30 ppm model

- 1.Input "410" using the numeric keys and press the [Start] key.
- 2.Press the [Start] key.
*: Test pattern 1 and Test pattern 2 are output on A4 paper.
- 3.Set the output Test Pattern 1 as the original.
*: Set test pattern 1 and place approximately 20 sheets of white paper on it.
- 4.Press the [Start] key.
*: The 1st auto adjustment is executed.
- 5.Set the output Test Pattern 2 as the original.
*: Set test pattern 2 and place approximately 20 sheets of white paper on it.
- 6.Press the [Start] key.
*: The 2nd auto adjustment is executed.
- 7.[Finish] appears after normal completion.
- 8.Press the [Stop] key.

(15-4) Adjusting the halftone automatically (Maintenance mode U410) : 35/40 ppm model

1. Input "410" using the numeric keys.
2. Press the [Start] key.
 - *: Test pattern 1, Test pattern 2 and Test pattern 3 are output on A4 paper.
3. Set the output Test Pattern 1 as the original.
 - *: Set test pattern 1 and place approximately 20 sheets of white paper on it.
4. Press the [Start] key.
 - *: The 1st auto adjustment is executed.
5. Set the output Test Pattern 2 as the original.
 - *: Set test pattern 2 and place approximately 20 sheets of white paper on it.
6. Press the [Start] key.
 - *: The 2nd auto adjustment is executed.
7. Set the output Test Pattern 3 as the original.
 - *: Set test pattern 3 and place approximately 20 sheets of white paper on it.
8. Press the [Start] key.
 - *: The 3rd auto adjustment is executed.
 - *: Test pattern 4 is output on A4 paper.
9. Set the output Test Pattern 4 as the original.
 - *: Set test pattern 4 and place approximately 20 sheets of white paper on it.
10. Press the [Start] key.
 - *: The 4th auto adjustment is executed.
11. [Finish] appears after normal completion.
12. Press the [Stop] key.

(15-5) Output an own-status report (Maintenance mode U000)

1. Input "000" using the numeric keys and press the [Start] key.
2. Select [Maintenance] and press the [Start] key to output the status report.
3. Press the [Stop] key.

(15-6) Clearing the counts (maintenance mode U927)

1. Input "927" using the numeric keys and press the [Start] key.
2. Select [Execute].
3. Press the [Start] key to clear the counter value.
4. Press the [Stop] key.

(15-7) Setting the delivery date (Maintenance mode U278)

1. Input "278" using the numeric keys and press the [Start] key.
2. Select [Today].
3. Press the [Start] key to set the delivery date.
4. Press the [Stop] key.

(16)Checking LSU cleaning operation (Maintenance mode U474)


- 1.Input "474" using the numeric keys and press the [Start] key.
- 2.Select [Execute].
- 3.Press the [Start] key. Cleaning the LSU slit glass.
- 4.Press the [Stop] key.

(17)Exiting from the maintenance mode

1. Input "001" using the numeric keys and press the [Start] key.
- *: The maintenance mode is exited.

(18)Completion of installing the main unit (Turning the power off)

1. Make sure that each indicator is not flashing, and then turn the power switch off.



Check if the lamp is turned off.

Figure 2-15

IMPORTANT

When the "Processing" indicator or "Memory" indicator is lit up or blinking, the main unit is operating. Turning the power switch off while the main unit is operating may cause malfunctions.

2-3 Installing the optional equipment

(1) Memory Module: 30 ppm model only

The machine can perform more multiple jobs simultaneously by adding more memory. You can increase the machine's memory up to 2,048 MB by plugging in the optional memory modules (524 MB or 1024 MB).

Precautions for Handling the Memory Modules




Figure 2-16

Static electricity that accumulates in your body through clothing or carpets may damage memory. To protect a memory, discharge static electricity from your body by touching a water pipe (faucet) or other large metal object. Wear the anti-static wrist band on the wrist.

Installing the Memory Modules

1. Turn off the main unit and disconnect the power cord and all interface cables.
2. Remove the two screws (a) (M3x8) and then remove the rear left cover (b).




Figure 2-17

3. Remove the memory module (a) from its package.
 4. With the memory (a) connection terminal pointing toward the socket (b), align the cut-out part with the socket terminal and insert it straight in on an angle.
- *: Before inserting the memory module (a), make sure that the power switch is turned off.




Figure 2-18

5. Carefully press the inserted memory module toward the main unit.
6. Reattach the covers.

Removing the Memory Module

To remove the memory module, remove the rear left cover and the memory slot cover from the main unit. Then, carefully push the two stoppers so that the memory module pops up from the socket.

Verifying the Memory Module

To verify that the memory module is working properly, print out a status page and check its content.

(2) SD/SDHC memory card

Reading the SD/SDHC memory Card

The contents of the SD/SDHC memory card are read into the main unit after turning the power on.

SD/SDHC memory card installation

1. Turn off the main unit and disconnect the power cord and all interface cables.
- *: Before inserting the memory card, make sure that the power switch is turned off.
2. Remove the screw (a) (M3x8).
3. Release the hook (b) in the direction of the arrow and then remove the controller cover (c).




Figure 2-19

4. Install an SD/SDHC memory card (a) in the memory card slot (b).




Figure 2-20

5. Reattach the covers.

Formatting an SD/SDHC Memory Card

To use an unused SD/SDHC card, you must first format it with the main unit.

*: Formatting will delete all existing data on the SD card.

If you have installed an application, do not format the SD card to avoid the removal of the application in the SD card.

All models common

Format it with a PC or Prescribe command in advance.

30 ppm model can format it from [System Menu].

1. [System Menu/Counter] key > [Common Settings] > [Format SD Card]
2. Format the SD/SDHC memory card.

(3) Hard disk (HD-11): 35 ppm model (Standard in some Markets)

Procedures

1. Turn off the main unit and disconnect the power cord and all interface cables.
2. Remove two screws (a) (M3x8) and then remove the rear left cover by sliding in the direction of the arrow.




Figure 2-21

3. Secure the hard disk (c) with three screws (b) (M3x8).
4. Connect two connectors (a) of the hard disk to two connectors (d) of the main PWB.




Figure 2-22


5. Reattach the parts in the original position.
- *: When installing a new HDD, it is automatically formatted at the first start-up.
 *: The memory LED blinks when forming a preview image in an HDD after restart if data exists in the FAX box.

Formatting a hard disk


1. Input "10871087" using the numeric keys to enter the maintenance mode.
 2. Input "024" using the numeric keys and press the [Start] key.
 3. Select [Format].
 4. Select [Full].
 5. Select [Execute].
 6. Press the [Start] key to initialize.
 7. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.
- *: When an optional HDD is inserted into the main unit for the first time, it must be formatted before use.
 Formatting will delete all existing data on the HDD.

(4) SSD (HD-6/HD-7): 30 ppm model only**(5) Gigabit Ethernet extension kit (IB-50)****(6) Wireless LAN interface (IB-51)****Procedures**

1. Turn off the main unit and disconnect the power cord and all interface cables.
2. Remove two screws (a) (M3x8) and then remove the option slot cover (b).

**Figure 2-23**

3. Insert the PWB unit (b) straight into the option slot (c).
4. Secure the PWB unit (b) with two screws (a) (M3x8) once removed.

**Figure 2-24**

- *: Install it in the upper slot for the 30ppm model (The lower slot is for FAX only)
- *: When installing a new SSD, it is automatically formatted at the first start-up.

Formatting an SSD


1. [System Menu/Counter] key > [Common Settings] > [Format SSD]
 2. Format an optional SSD.
- *: When an optional SSD is inserted into the main unit for the first time, it must be formatted before use. Formatting will delete all existing data on an SSD.
 - *: This setting does not appear if the optional security kit is installed.

(7) Document table DT-5100

Bundled parts of Document table DT-5100 (1902R60UN1)

| | |
|--|------|
| Original tray..... | 1 pc |
| tray lower cover..... | 1 pc |
| tray mounting plate..... | 1 pc |
| Reinforcement plate..... | 1 pc |
| Hook-and-loop fastener ^{*1} | 2 pc |
| Label..... | 2 pc |
| Edgings ^{*1} | 1 pc |
| Wire saddles ^{*1} | 1 pc |
| Screw (M3x8 screw with the binding head)..... | 3 pc |
| Screw (M3x20 screw with the binding head)..... | 2 pc |

^{*1}: Not used in this model.



Procedures

1. Remove the right cover (a).
2. Remove the screw (b) (M3x8).
3. Slide the right upper cover (c) in the direction of the arrow and detach it.




Figure 2-25

4. Hang the hook (c) of the reinforcement plate (b) at the backside of the right upper stay (a) and secure it with the screw (d) (M3x8).




Figure 2-26

5. Cut out two cut-out pieces (c) from the right upper cover (a) with pliers (b).




Figure 2-27

6. Reattach the right upper cover to the original position in the main unit.
 7. Hang two hooks(b) of the tray fixing plate (a) and secure it to the main unit (d) with two screws (c) (M3x20).




Figure 2-28

8. Hang six hooks of the tray lower cover (a) on the document tray (c) and secure it with the screw (d) (M3x8).




Figure 2-29

9. Hang six hooks of the tray lower cover (a) on the document tray (c) and secure it with the screw (d) (M3x8).




Figure 2-30

10. Affix the concealing labels (b) to two concaves of the document tray (a).




Figure 2-31

(8) Key counter: 35/40 ppm models only**Key counter installation requires the following parts:**

| | |
|--|------|
| Key counter (3025418011)..... | 1 pc |
| Key counter set (302A369709) | 1 pc |
| Key counter wire (302K946AJ0) | 1 pc |
| Document table DT-5100 (1902R60UN1)..... | 1 pc |

Bundled parts of key counter set (302A369709)


| | |
|--|------|
| Key counter set | 1 pc |
| Key counter cover fixing plate | 1 pc |
| Key counter fixing plate | 1 pc |
| Key counter cover | 1 pc |
| Key counter mounting plate | 1 pc |
| Edgings ^{*1} | 2 pc |
| Bands ^{*1} | 1 pc |
| Screws (M3x8 P-tite) ^{*1} | 1 pc |
| Screws (M4x10 P-tite) ^{*1} | 2 pc |
| Screws (M4x10 S-tite)..... | 2 pc |
| Screws (M3x6 Bronze)..... | 2 pc |
| Screws (M4x20 S-tite) ^{*1} | 2 pc |
| Nut M3 ^{*1} | 1 pc |
| Screw (M3x8 screw with the binding head) ^{*1} | 1 pc |
| Screws (M4x30 S-tite) ^{*1} | 1 pc |
| Screws (M4x6 TP chrome)..... | 5 pc |
| Screws (M4x10 TP chrome) ^{*1} | 2 pc |

Bundled parts of Document table DT-5100 (1902R60UN1)

| | |
|---|-----|
| Original tray | 1pc |
| tray lower cover..... | 1pc |
| tray mounting plate..... | 1pc |
| Reinforcement plate | 1pc |
| Hook-and-loop fastener ^{*1} | 2pc |
| Label ^{*2} | 2pc |
| Edgings ^{*1} | 1pc |
| Wire saddles ^{*1} | 2pc |
| Screw (M3x8 screw with the TP binding head) | 3pc |
| Screw (M3x20 screw with the binding head)..... | 2pc |

^{*1}: Not used in this model.

^{*2}: 1 pc is used for this model.



Procedures

1. Turn the power switch off and disconnect the power plug.
2. Secure the key counter set (d) to the key counter mounting plate (c) with two screws (a) (M3x6) and one nut (b) (M3).
- *: Take out the wire (h) from the center of the key counter mounting plate as shown in the figure.
3. Secure the key counter mounting plate (g) to the key counter cover (f) with two screws (e)(M4x6).
4. Secure the key counter fixing plate (c) to the key counter mounting plate (g) with two screws (j) (M4x6).




Figure 2-32

5. Remove the right cover (a).
6. Remove the screw (b) (M3x8).
7. Slide the right upper cover (c) in the direction of the arrow and detach it.




Figure 2-33

8. Cut out three cut-out pieces (c) from the right upper cover (a) with pliers (b).




Figure 2-34

9. Reattach the right upper cover to the main unit (a).
10. Hang two hooks(c) of the tray fixing plate (b) and secure it with two screws (d) (M3x20).




Figure 2-35

11. Cut off the cut-off piece (c) for the aperture (b) of the document tray (a) with pliers (d).
12. Hang two hooks (e) of the document tray (a) on the tray mounting plate (f) and secure it with the screw (g) (M3x8).




Figure 2-36

13. Secure the key counter cover fixing plate (b) to the document tray (c) with two screws (a) (M4x10).




Figure 2-37

14. Connect the connector (b) of the key counter wire (a) to the engine PWB (c).
15. Align the key counter wire (a) through three apertures (d).




Figure 2-38

16. Connect the key counter signal wire (a) to the key counter wire (b).
17. Secure the key counter cover (c) to the key counter fixing plate (e) with a screw (d) (M4x6).




Figure 2-39

18. Hang six hooks of the tray lower cover (a) on the document tray (c) and secure it with the screw (d) (M3x8).




Figure 2-40

19. Affix the concealing labels (b) to concave of the document tray (a).




Figure 2-41

20. Reattach the rear right cover to the main unit.
21. Set the key counter to the key counter socket.
22. Turn the power switch on and enter the maintenance mode.
23. Execute maintenance mode U204 to set [Key-Counter]. (See page 6-297)
24. Exiting from the maintenance mode.
25. If the key counter is disconnected, check [Set key counter] message is indicated.
26. Check that the key counter operates properly for each copy.


(9) ID card reader

ID card reader installation requires the following parts:

ID card reader holder(F) (1702R60UN1) 1 pc

Supplied parts of ID card reader holder (F) (1702R60UN1)

ID card reader holder 1 pc
 ID card cover 1 pc
 Sponge 1 pc



Procedures

1. Turn the power switch off and disconnect the power plug.
2. Attach the ID card reader (a) to the ID card reader holder (b) while aligning the USB cable (d) aligning the rib (d).
3. Hung the USB cable (c) on the hook (e).




Figure 2-42

4. Pull up the operation unit (a).
5. Remove the screw (b) (M3x8).
6. Remove the operation lid (c) from the operation unit (a) in the direction of the arrow.




Figure 2-43

7. Remove one screw (b) (M3x8) and then remove the upper exit cover (c).




Figure 2-44

8. Remove the right cover (a).
 9. Remove the screw (b) (M3x8).
 10. Slide the right upper cover (c) in the direction of the arrow and detach it.




Figure 2-45

11. Release two hooks (b) and remove the auxiliary cover (c) from the right upper cover (a).
 12. Attach the ID card cover (d) to the right upper cover (a).




Figure 2-46

13. Insert the ID card reader holder (a) into the right upper stay (b) and attach it.




Figure 2-47

14. Reattach the right upper cover to the original position.
 15. Close the right cover.
 16. Connect the USB connector (a).
 17. Wind the excess portion of the USB cable (b) and push it under the image scanner unit (c).




Figure 2-48

18. Cut out the cutout piece (b) on the upper eject cover (a) with pliers (c).
 19. Reattach the upper eject cover (a) with the screw (d) (M3x8).




Figure 2-49

20. Reattach the operation lid (c) to the operation unit (a) with the screw (b) (M3x8).




Figure 2-50

Activating Card Authentication

To install the optional function, you need the License Key. Please access the designated website of your dealer or service representative, and register the "Machine No." indicated on your machine and the "Product ID" indicated on the License Certificate supplied with the product to issue the License Key. Refer to [2-4 Optional Application] when starting the trial. (See page 2-77)

(10)Key card MK-2: 35/40ppm models only (100 V model only)**Key counter installation requires the following parts:**

| | |
|--|------|
| Key card MK-2 (8J272002) | 1 pc |
| Document table DT-5100 (1902R60UN1) | 1 pc |
| Bushing (M12034901) | 1 pc |
| Mounting plate (78660130) | 1 pc |
| Screws (M3x8 P-tite TP) (7BB202308H) | 2 pc |

Bundled parts of key card MK-2 (8J272002)


| | |
|---------------------------|------|
| Key card MK-2 | 1 pc |
| MK-2 mounting plate | 1 pc |
| Screws (M4x16) | 2 pc |

Bundled parts of Document table DT-5100 (1902R60UN1)

| | |
|---|------|
| Original tray | 1 pc |
| tray lower cover | 1 pc |
| tray mounting plate | 1 pc |
| Reinforcement plate | 1 pc |
| Hook-and-loop fastener *1 | 2 pc |
| Label *1 | 2 pc |
| Edgings *1 | 1 pc |
| Wire saddles *1 | 2 pc |
| Screw (M3x8 screw with the binding head) | 3 pc |
| Screw (M3x20 screw with the binding head) | 2 pc |

*1: Not used in this model.

*2: 1 pc is used for this model.

**Procedures**

1. Turn the power switch off and disconnect the power plug.
2. Attach the document table (a) to the main unit (b).




Figure 2-51

3. Remove four screws (b) (M3x8) from MK-2 (a).
4. Secure the MK-2 mounting plate (c) with four screws (b) (M3x8) that are removed from MK-2 (a).




Figure 2-52

5. Secure the MK-2 (b) to the document table (a) with two screws (c) (M4x16).
6. Affix the concealing label (d) to the convex of the document table (a).




Figure 2-53

7. Remove the screws (a) (M3x8) and then remove the rear right cover (b).
8. Cut out the cut-out piece (d) from the rear right cover (b) with pliers (c).




Figure 2-54

9. Pass the key counter wire (a) through the hole on the rear right cover (b) and connect it to the connector (c).
10. Attach the rear right cover (b).
11. Pull out the excess portion of the key card wire (a) to the machine rear side to position the bushing (d).
12. Secure the mounting plate (e) with two screws (f) (M3x8).




Figure 2-55


(11)USB Keyboard

USB keyboard installation requires the following parts:

| | |
|--|------|
| Document table DT-5100 (1902R60UN1)..... | 1 pc |
| USB Keyboard | 1 pc |

Bundled parts of Document table DT-5100 (1902R60UN1)

| | |
|--|------|
| Original tray..... | 1 pc |
| Tray lower cover..... | 1 pc |
| Tray mounting plate..... | 1 pc |
| Reinforcement plate..... | 1 pc |
| Hook-and-loop fastener..... | 2 pc |
| Label | 2 pc |
| Edgings | 1 pc |
| Wire saddles | 2 pc |
| Screw (M3x8 screw with the binding head)..... | 3 pc |
| Screw (M3x20 screw with the binding head)..... | 2 pc |



Procedures

1. Turn the power switch off and disconnect the power plug.
2. Pull up the operation unit (a).
3. Remove the screw (b) (M3x8).
4. Remove the operation lid (c) from the operation unit (a) in the direction of the arrow.




Figure 2-56

5. Remove one screw (b) (M3x8) and then remove the upper exit cover (c).




Figure 2-57

6. Remove the right cover (a).
 7. Remove the screw (b) (M3x8).
 8. Slide the right upper cover (c) in the direction of the arrow and detach it.




Figure 2-58

9. Hang the hook (c) of the reinforcement plate (b) at the backside of the right upper stay (a) and secure it with the screw (d) (M3x8).




Figure 2-59

10. Cut out two cut-out pieces (c) from the right upper cover (a) with pliers (b).




Figure 2-60

11. Reattach the right cover to the original position in the main unit.
 12. Hang two hooks (b) of the tray fixing plate (a) and secure it to the main unit (d) with two screws (c) (M3x20).




Figure 2-61

13. Cut off the cut-off piece (c) for the aperture (b) of the document tray (a) with pliers (d).
 14. Hang two hooks (e) of the document tray (a) on the tray mounting plate (f) and secure it with the screw (g) (M3x8).




Figure 2-62

15. Affix a pair of hook-and-loop fasteners (b) to two concaves (a) of the document tray.
16. Affix the concealing label (d) over the apertures (c) of the document tray.




Figure 2-63

17. Place the keyboard (a) on the hook-and-loop fastener (b) and press it to fix.
18. Pass the USB connector (c) through the aperture (d) of the document tray.




Figure 2-64

19. Connect the USB connector (a) to the main unit.
20. Align the USB cable (b) through the edging (c) and wind the excess cable to two wire saddles (d).
21. Affix the concealing label (e) over the apertures (f) of the document tray.




Figure 2-65

22. Hang six hooks of the tray lower cover (a) on the document tray (c) and secure it with the screw (d) (M3x8).




Figure 2-66

23. Cut out the cutout piece (b) on the upper eject cover (a) with pliers (c).
 24. Reattach the upper eject cover (a) with the screw (d) (M3x8).




Figure 2-67

25. Reattach the operation lid (c) to the operation unit (a) with the screw (b) (M3x8).




Figure 2-68

(12)Handset (100 V model only)


(12-1) When attaching the main unit directly

Handset installation requires the following parts:

Handset (1909AG9JP0)..... 1 pc

Bundled parts of handset (1909AG9JP0)

Handset..... 1 pc
 Handset holder..... 1 pc
 Handset mounting plate 1 pc
 Protection cover 1 pc
 Pins 2 pc
 Telephone wire 1 pc
 Modular cord 1 pc
 Nut M4..... 2 pc



Procedures

1. Turn the power switch off and disconnect the power plug.
2. Secure the handset mounting plate (a) to the main unit (c) with two pins (b).




Figure 2-69

3. Connect the connector (c) of the telephone wire (b) to the handset holder (a).
4. Stretch the telephone wire (d) and insert it into the cable guide (d).




Figure 2-70

5. Put the catches (c) at the backside of the handset holder (b) on two pins and slide it toward you to secure it.




Figure 2-71

6. Attach the protection cover (a) to the handset mounting plate (b).




Figure 2-72

7. Connect the phone wire (a) to the handset (b).

*: Insert the telephone wire (a) between the handset holder (c) and main unit (d).




Figure 2-73

8. Connect the modular cord (a) to the handset holder (b).




Figure 2-74

9. Connect one end of the connector (b) of the modular cord (a) to the machine left side (c).





Figure 2-75

(12-2) In case installing the document table**Handset installation requires the following parts:**

| | |
|--|------|
| handset (1909AC9JP0)..... | 1 pc |
| Document table DT-5100 (1902R60UN1)..... | 1 pc |

Bundled parts of handset (1909AC9JP0)

| | |
|--|------|
| Handset..... | 1 pc |
| Handset holder..... | 1 pc |
| Handset mounting plate* ¹ | 1 pc |
| Protection cover* ¹ | 1 pc |
| Pins..... | 2 pc |
| Telephone wire..... | 1 pc |
| Modular cord..... | 1 pc |
| Nut M4..... | 2 pc |

**Bundled parts of Document table DT-5100 (1902R60UN1)**

| | |
|--|------|
| Original tray..... | 1 pc |
| Tray lower cover..... | 1 pc |
| Tray mounting plate..... | 1 pc |
| Reinforcement plate..... | 1 pc |
| Hook-and-loop fastener* ¹ | 2 pc |
| Label..... | 2 pc |
| Edgings* ¹ | 1 pc |
| Wire saddles* ¹ | 2 pc |
| Screw (M3x8 screw with the binding head)..... | 3 pc |
| Screw (M3x20 screw with the binding head)..... | 2 pc |

*¹: Not used in this model.

Procedures

1. Turn the power switch off and disconnect the power plug.
2. Remove the right cover (a).
3. Remove the screw (b) (M3x8).
4. Slide the right upper cover (c) in the direction of the arrow and detach it.




Figure 2-76

5. Hang the hook (c) of the reinforcement plate (b) at the backside of the right upper stay (a) and secure it with the screw (d) (M3x8).




Figure 2-77

6. Cut out two cut-out pieces (c) from the right upper cover (a) with pliers (b).




Figure 2-78

7. Reattach the right upper cover to the main unit.

8. Hang two hooks (b) of the tray fixing plate (a) and secure it to the main unit (d) with two screws (c) (M3x20).




Figure 2-79

9. Remove two pins (b) and two nuts (c) from the handset mounting plate (a).
10. Secure the original tray (d) with two pins and two nuts once removed.




Figure 2-80

11. Put two catches (c) at the backside of the handset holder (b) into two pins (a) and slide it toward you to fix it on the document tray (d).
12. Connect the modular cord (e) to the handset holder (b).




Figure 2-81

13. Hang six hooks of the tray lower cover (a) on the document tray (c) and secure it with the screw (d) (M3x8).




Figure 2-82

14. Hang six hooks of the tray lower cover (a) on the document tray (c) and secure it with the screw (d) (M3x8).
 15. Affix the concealing label (f) over 2 points of the apertures (e) of the document tray.




Figure 2-83

16. Connect the telephone wire (a) to the handset (b) and handset holder (c).




Figure 2-84

17. Connect one end of the connector (b) of the modular cord (a) to the machine left side (c).




Figure 2-85

(13)Cassette heater


(13-1) In case of the main unit cassette (standard for 100 V 40ppm model)

Cassette heater installation requires the following parts:

- Cassette heater 100 set (302R49401_)..... 1 pc
- Cassette heater 120 set (302R49402_)..... 1 pc
- Cassette heater 240 set (302R49403_)..... 1 pc

Bundled parts of cassette heater 100/120/240

- Cassette heater 100..... 1 pc
- Cassette heater 120
- Cassette heater 240
- High temperature caution label 1 pc
- Heater connector cover..... 1 pc
- Wire saddles 2 pc
- Screw (M3x4 screw with the binding head)..... 2 pc



Procedures

1. Turn the power switch off and disconnect the power plug.
2. Pull out the cassette (a) from the main unit (b) and remove it in the direction of the arrow.




Figure 2-86

3. Press the lock lever (a) and pull out the primary feed unit (c) from the paper feeder (b).




Figure 2-87

4. Secure the cassette heater (a) to the base (b) with two screws (c) (M3x4).
5. Connect the heater connector (d) to the main machine side connector (e).
6. Attach the wire saddle (f) to the base (b) and secure the wire.




Figure 2-88

7. Insert two hooks (c) into the square hole (e) and attach the connector cover (a) by sliding it in the direction of the arrow.
8. Slide the protrusion (b) of the hook back and forth to check it is secured at the round hole (d).
- *: Make sure the wire (f) does not float.
9. Affix the caution label (g), aligning it with the mark-off line (h) on the base.




Figure 2-89

10. Reattach the parts in the original position.
11. Turn the power on and set maintenance mode U327 [Cassette heater On/Off] to [On].

IMPORTANT

When connecting the cassette heater, do not unplug the power cord. (Power is supplied when the power is switched off) Also, if unplugged for a prolonged time, it may cause blurred images depending on the environment. In this case, execute [System Menu] > [Adjustment/Maintenance] > [Drum Refresh] .


(13-2) In case of paper feeder (PF-5120)

Cassette heater installation requires the following parts:

- Cassette heater 100 set (303PS9401_)..... 1 pc
- Cassette heater 120 set (303PS9402_)..... 1 pc
- Cassette heater 240 set (303PS9403_)..... 1 pc

Bundled parts of cassette heater 100/120/240

- Cassette heater 100 set..... 1 pc
- Cassette heater 120 set..... 1 pc
- Cassette heater 240 set..... 1 pc
- Heater connector cover..... 1 pc
- Wire saddles 1 pc
- Screw (M3x4 screw with the binding head)..... 4 pc



Procedures

1. Turn the power switch off and disconnect the power plug.
2. Pull out the cassette (a) from the paper feeder (b) and remove it in the direction of the arrow.




Figure 2-90

3. Press the lock lever (a) and pull out the primary feed unit (c) from the paper feeder (b).




Figure 2-91

4. Insert the cassette heater set (b) into the lancing section (g) and secure it to the base (a) with four screws (c) (M3x4).
5. Connect the heater connector (d) to the main machine side connector (e).
6. Attach the wire saddle (f) to the base (a) and secure the wire.




Figure 2-92

7. Insert two hooks (c) into the square hole (e) and attach the connector cover (a) by sliding it in the direction of the arrow.
 8. Slide the protrusion (b) of the hook back and forth to check it is secured at the round hole (d).
- *: Make sure the wire (f) does not float.




Figure 2-93

9. Reattach the parts in the original position.
10. Turn the power on and set maintenance mode U327 [Cassette heater On/Off] to [On].

IMPORTANT

When connecting the cassette heater, do not unplug the power cord. (Power is supplied when the power is switched off) Also, if unplugged for a prolonged time, it may cause blurred images depending on the environment. In this case, execute [System Menu] > [Adjustment/Maintenance] > [Drum Refresh] .


(13-3) In case of paper feeder (PF-5130)

Cassette heater installation requires the following parts:

- Cassette heater 100 set (303PZ9401_) 1 pc
- Cassette heater 120 set (303PZ9402_)
- Cassette heater 240 set (303PZ9403_)

Bundled parts of cassette heater 100/120/240

- Cassette heater 100 1 pc
- Cassette heater 120
- Cassette heater 240
- High temperature caution label 1 pc
- Heater connector cover 1 pc
- Cassette mounting plate set 1 pc
- Wire saddles 5 pc
- Screw (M3x8 screw with the binding head) 4 pc



Procedures

1. Turn the power switch off and disconnect the power plug.
2. Pull out the upper cassette (a) from the paper feeder (b) and remove it in the direction of the arrow.
3. Pull out the lower cassette (a) from the paper feeder (b) and remove it in the direction of the arrow.




Figure 2-94

4. Secure the cassette heater (a) to the base with two screws (b) (M3x8).
 5. Connect the heater connector (c) to the main unit side connector and secure the wire with five wire saddles (d).
- *: Make sure the wire does not float.




Figure 2-95

6. Secure the cassette mounting plate set (b) to the base with a screw (a) (M3x4).




Figure 2-96

7. Hang the three projections of the connector cover (a) on the square holes (b) of the side plate in the direction of the arrow.
 8. Secure the connector cover (a) to the rear side plate with the screw (c) (M3x8).
 9. Affix the caution label (f), aligning it with the mark-off line (g) on the base.




Figure 2-97

10. Reattach the parts in the original position.
 11. Turn the power on and set maintenance mode U327 [Cassette heater On/Off] to [On].

IMPORTANT

When connecting the cassette heater, do not unplug the power cord. (Power is supplied when the power is switched off) Also, if unplugged for a prolonged time, it may cause blurred images depending on the environment. In this case, execute [System Menu] > [Adjustment/Maintenance] > [Drum Refresh] .

(13-4) In case of paper feeder (PF-5140)

Cassette heater installation requires the following parts:

- Cassette heater 100 set (303PT9402_) 1 pc
- Cassette heater 120 set (303PT9403_)
- Cassette heater 240 set (303PT9404_)

Bundled parts of cassette heater 100/120/240

- Cassette heater 100 1 pc
- Cassette heater 120
- Cassette heater 240
- High temperature caution label 1 pc
- Heater connector cover 1 pc
- Wire saddles 4 pc
- Screws (M3x8 screw with the binding head)..... 3 pc

Procedures

1. Turn the power switch off and disconnect the power plug.
2. Remove the cassette (a) from the paper feeder (b).
3. Pull out the paper deck (c) from the paper feeder (d).





Figure 2-98

4. Secure the cassette heater (a) to the inclined portion of the end of the base with two screws (b) (M3x8).
5. Connect the heater connector (c) to the main unit side connector and secure the wire with four wire saddles (d).
6. Make sure the wire does not float.




Figure 2-99

7. Hang the three projections of the connector cover (a) on the square holes (b) of the side plate in the direction of the arrow.
8. Secure the connector cover (a) to the rear side plate with the screw (c) (M3x8).
- *: Hold the excess portion of wires in the connector cover (a).
9. Affix the caution label (d), aligning it with the mark-off line (e) on the base.




Figure 2-100

10. Reattach the parts in the original position.
11. Turn the power on and set maintenance mode U327 [Cassette heater On/Off] to [On].

IMPORTANT

When connecting the cassette heater, do not unplug the power cord. (Power is supplied when the power is switched off) Also, if unplugged for a prolonged time, it may cause blurred images depending on the environment. In this case, execute [System Menu] > [Adjustment/Maintenance] > [Drum Refresh] .

2-4 About Optional Applications

| application | |
|---------------------------------------|-------------------------------------|
| Data Security Kit | Internet FAX kit ^{*2} |
| Card Authentication Kit ^{*1} | Emulation upgrade kit ^{*2} |
| ThinPrint Option ^{*1} | OCR extension kit ^{*1, *2} |

*1: This can be used on a trial basis for a limited time.

*2: 35/40 ppm models only

*: Restrictions such as the number of times the application can be used during the trial period differ depending on the application.

*: If you change the date/time while using the trial version of an application, you will no longer be able to use the application.

Starting Use of an Application

Use the procedure below to start using an application.

1. Select [System Menu/Counter] key > [System/Network] > [Optional Function].

NOTE

If the login user name entry screen appears during operations, enter a login user name and password, and select [Login]. Login with administrator privileges.

The factory default login user name and login password are set as shown below.

| Model name | 30 ppm model | 35 ppm model | 40 ppm model |
|-----------------|--------------|--------------|--------------|
| Login User Name | 3000 | 3500 | 4000 |
| Login Password | 3000 | 3500 | 4000 |

2. Select the desired application to start use and select [Activate].

*: You can view detailed information on the selected application by selecting [] or [Details].

| Item |
|---------------|
| Function Name |
| License |
| Trial Counts |
| Date of Trial |
| Status |

3. Select [Official] and enter a license key.

Some applications do not require you to enter a license key. If the license key entry screen does not appear, go to Step 4.

To use the application as a trial, select [Trial] without entering the license key.

4. Select [Yes] in the confirmation screen.

Icons of activated application are displayed in the Home screen.

NOTE

If you started the Security Kit or Thin Print option and entered the license key, turn the power OFF/ON. Icons of activated application are displayed in the Home screen.

2-5 Initializing procedures after installing the FAX system

1. Connect the power plug of the main unit to the outlet and turn the power on.
2. Input "10871087" using the numeric keys to enter the maintenance mode.
3. Input "600" using the numeric keys and press the [Start] key.
4. Select [Country Code] and enter a destination code using the numeric keys.

*: Refer to the following destination code list.

5. Select [Execute].
 6. Press the [Start] key to start data initialization.
- *: Press the [Stop] key to cancel the data initialization.

Destination code list

| Destination code | Destination | Destination code | Destination |
|------------------|--------------|------------------|--------------------------|
| 000 | Japan | 253 | CTR21 (European nations) |
| 007 | Argentina | ↑ | Italy |
| 009 | Australia | ↑ | Germany |
| 022 | Brazil | ↑ | Spain |
| 038 | China | ↑ | U.K. |
| 080 | Hong Kong | ↑ | Netherlands |
| 084 | Indonesia | ↑ | Sweden |
| 088 | Israel | ↑ | France |
| 097 | Korea | ↑ | Austria |
| 181 | U.S.A. | ↑ | Switzerland |
| 250 | Russia | ↑ | Belgium |
| 108 | Malaysia | ↑ | Denmark |
| 115 | Mexico | ↑ | Finland |
| 126 | New Zealand | ↑ | Portugal |
| 136 | Peru | ↑ | Ireland |
| 137 | Philippines | ↑ | Norway |
| 152 | Middle East | 254 | Taiwan |
| 156 | Singapore | | |
| 159 | South Africa | | |
| 169 | Thailand | | |

7. After completing installation, execute communication test to check if FAX normally operates.

IMPORTANT

Note the following points when installing the FAX system in the line via ISDN or PBX.

Check if the line to connect supports the V.34 (Super G3) FAX communication.

Especially, when communicating between extensions in PBX (private line via TDM), only 14400bps or 9600bps of FAX communication speed is guaranteed and communication errors or TX/RX image failure may occur at V.34 communication in such a line.

Corrective Measures

Set the following maintenance mode if the communication speed guaranteed on the line is 14400bps.

U633 [Enables or disables the V.34 communication]: Off (See page 6-165,6-395)

U630 [Setting TX speed and RX speed] (See page 6-160,6-390)

3 Machine Design

3-1 Mechanical Configuration

(1) Cross-section view (30 ppm model)




Figure 3-1

- | | |
|--------------------------------|---|
| 1. Cassette paper feed section | 9. Transfer and separation section |
| 2. MP paper feed section | 10. Fuser section |
| 3. Paper conveying section | 11. Feedshift and eject section |
| 4. Image scanner unit | 12. Duplex conveying section |
| 5. Laser scanner unit | 13. DP document feed section |
| 6. Developer unit | 14. DP original conveying section |
| 7. Toner container | 15. DP original reversing/eject section |
| 8. Drum unit | |

(2) Cross-section view (35/40 ppm models)




Figure 3-2

- | | |
|--------------------------------|------------------------------------|
| 1. Cassette paper feed section | 8. Drum unit |
| 2. MP paper feed section | 9. Transfer and separation section |
| 3. Paper conveying section | 10. Fuser section |
| 4. Image scanner unit | 11. Feedshift and eject section |
| 5. Laser scanner unit | 12. Duplex conveying section |
| 6. Developer unit | |
| 7. Toner container | |

3-2 Extension device construction (option)

(1) Paper feeder cross-section view (PF-5120)




Figure 3-3

1. Cassette paper feed section

(2) Paper feeder cross-section view (PF-5130)




Figure 3-4

1. Upper cassette paper feed section

2. Lower cassette paper feed section

(3) Paper feeder cross-section view (PF-5140)




Figure 3-5

1. Paper deck feed section

(4) Document processor cross-section view (DP-5100) : for 35/40ppm models only




Figure 3-6

- 1. DP document feed section
- 2. DP original conveying section

- 3. DP original reversing/eject section

(5) Document processor cross-section view (DP-5110) : for 35/40ppm models only




Figure 3-7

- 1. DP document feed section
- 2. DP original conveying section

- 3. DP original eject section

(6) Attachment kit cross-section view (AK-5100)




Figure 3-8

1. Exit section

2. Paper conveying section

(7) Finisher cross-section view (DF-5100)





Figure 3-9


1. Paper conveying section
2. Staple unit

3. Exit section

(8) Finisher cross-section view (DF-5110) : 35/40ppm models only**Figure 3-10**

- 1. Punch unit
- 2. Paper conveying section

- 3. Staple unit
- 4. Eject section (main tray)

(9) Finisher cross-section view (DF-5120) : 35/40ppm models only**Figure 3-11**

- 1. Punch unit
- 2. Paper conveying section
- 3. Staple unit

- 4. Eject section (upper tray)
- 5. Eject section (main tray)

(10) Mailbox cross-section view (MT-5100)




Figure 3-12

- 1. Paper conveying section
- 2. Eject section (mail tray)

- 3. Eject section (main tray)

(11) Job separator cross-section view (JS-5100)




Figure 3-13

3-3 Paper conveying and Paper detection

(1) Main unit (30ppm) +PF-5120 +PF-5130 +DF-5100




Figure 3-14

[Paper jam]

- A. Paper jam at cassette 1
- B. Paper jam at 500-sheet×1 cassette 2
- C. Paper jam at 500-sheet×2 cassette 3
- C. Paper jam at 500-sheet×2 cassette 4
- E. Paper jam at the MP tray
- F. Paper jam at right cover 1
- G. Paper jam at right cover 2
- H. Paper jam at right cover 3
- K. Paper jam at the inner finisher
- L. Paper jam at the document processor
- N. Paper jam at the conveying section
- O. Paper jam at the duplex unit
- P. Paper jam at the registration section
- Q. Paper jam at the job separator

[Sensor (Paper conveying)]

- PFFS1: PF feed sensor 1
- PFFS2: PF feed sensor 2
- PFFS3: PF feed sensor 3
- RS: Registration sensor
- ES: Eject sensor
- DUS: Duplex sensor
- DPFS: DP paper feed sensor
- DPRS: DP registration sensor
- DPFSS: DP feedshift sensor
- DFPEs: DF entry sensor
- DFMTS: DF eject sensor

(2) Main unit (35/40 ppm) +DP-5110+PF-5120+PF-5140 +AK-5100+DF-5120




Figure 3-15

[Paper jam]

- A. Paper jam at cassette 1
- B. Paper jam at 500-sheet×1 cassette 2
- C. Paper jam at 2200-sheet×1 cassette 3
- E. Paper jam at the MP tray
- F. Paper jam at right cover 1
- G. Paper jam at right cover 2
- H. Paper jam at right cover 3
- I. Paper jam at the bridge conveying section
- L. Paper jam at the document processor
- M. Paper jam at the 1000-sheet finisher
- M. Paper jam at the 3000-sheet finisher
- N. Paper jam at the conveying section
- O. Paper jam at the duplex unit
- P. Paper jam at the registration section
- Q. Paper jam at the job separator

[Sensor (Paper conveying)]

- PFFS1: PF feed sensor 1
- PFFS2: PF feed sensor 2
- RS: Registration sensor
- ES: Eject sensor
- DUS: Duplex sensor
- DPFS: DP paper feed sensor
- DPTS: DP timing sensor
- DPCISS: DPCIS sensor
- DPES: DP eject sensor
- BRCS1: BR conveying sensor 1
- BRCS2: BR conveying sensor 2
- DFPE: DF entry sensor
- DFME: DF middle sensor
- DFMT: DF eject sensor
- DFSE: DF sub eject sensor

(3) Main unit (35/40 ppm) +DP-5100 +PF-5120+PF-5140 +AK-5100 +MT5100




Figure 3-16

[Paper jam]

- A. Paper jam at cassette 1
- B. Paper jam at 550-sheet×1 cassette 2
- C. Paper jam at 2200-sheet×1 cassette 3
- E. Paper jam at the MP tray
- F. Paper jam at right cover 1
- G. Paper jam at right cover 2
- H. Paper jam at right cover 3
- I. Paper jam at the bridge conveying section
- J. Paper jam at the mailbox
- L. Paper jam at the document processor
- N. Paper jam at the conveying section
- O. Paper jam at the duplex unit
- P. Paper jam at the registration section
- Q. Paper jam at the job separator

[Sensor (Paper conveying)]

- PFFS1: PF feed sensor 1
- PFFS2: PF feed sensor 2
- RS: Registration sensor
- ES: Eject sensor
- DUS: Duplex sensor
- DPFS: DP paper feed sensor
- DPTS: DP timing sensor
- DPES: DP eject sensor
- TEJS1: Tray eject sensor 1
- TEJS2: Tray eject sensor 2

3-4 Electric parts (30ppm)

(1) Wire connection

(1-1) (Machine rear side)




Figure 3-17

1. Main PWB
2. Engine PWB

3. High-voltage PWB
4. Controller fan motor

(1-2) Backside of the High-voltage PWB**Figure 3-18**

- | | |
|---------------------------|-----------------------------|
| 5. Power source PWB | 8. Drum motor (BK) |
| 6. Power source fan motor | 9. Drum motor (M/C/Y) |
| 7. Developer motor (BK) | 10. Developer motor (M/C/Y) |

(2) Descriptions about the major PWBs

(2-1) Main PWB

It controls the software for the interface and image data processing, and the hardware generating the image scanner unit and operation section.



Figure 3-19

(2-2) Engine PWB

It controls the hardware for the generation of the high-voltage and the bias, and the paper conveying system.



Figure 3-20

(2-3) High-voltage PWB

Generating the main charger high-voltage and the developer bias, the transfer bias, separation bias and the transfer cleaning bias.




Figure 3-21

(2-4) Power source PWB

The input voltage (AC) from the AC power supply is changed to DC such as DC24V, and it controls the fuser heater.



Figure 3-22

(2-5) Operation panel PWB

It consists of the wiring relay circuit for the main PWB, the panel-left PWB, the panel-right PWB and the LCD.





Figure 3-23


(3) Electric parts layout

(3-1) PWBs


Laser scanner unit




Primary transfer unit




Toner container




Document processor



Developer unit



Drum unit



Fuser unit





Figure 3-24


1. Main PWB (MPWB) Controlling the entire software to control the interface to the PC and network and image data process, etc. Controlling the entire hardware to control the image scanner unit and operation section.
2. Engine PWB (EPWB)..... Controlling the hardware such as electric parts drive, high voltage, bias output, paper conveying, fuser temperature, etc.
3. High-voltage PWB (HVPWB) Generating the main charger high-voltage, the developer bias, the transfer bias and the separation bias.
4. Power source PWB (PSPWB) Rectifying the AC power input to the full-wave and converting it to DC24V. It controls the fuser heater.
5. Drum/developer relay PWB (DR/DLPPWB)..... Consisting of the wiring relay circuit to the engine PWB, drum units and developer units.
6. Operation panel PWB (OPPWB) It consists of the wiring relay circuit for the main PWB, panel-left PWB, panel-right PWB and LCD.
7. Operation panel-right PWB (OPPWB-R) Consisting of the LED indicator and the key switches.
8. Operation panel-left PWB (OPPWB-L)..... Consisting of the LED indicator and the key switches.
9. LED PWB (LEDPWB) Controlling the LED.
10. CCD PWB (CCDPWB)..... Scanning the original image.
11. APC PWB (APCPWB) Emitting and controlling the laser beam.
12. PD PWB (PDPWB) Controlling the synchronous lateral laser beam.
13. Developer PWB (DLPPWB)..... Wiring relay to the electric parts inside developer unit.
14. Drum PWB (DRPWB) Wiring relay to the electric parts inside drum unit. Storing the drum unique data in an EEPROM.
15. KUIO relay PWB (KUIORPWB) Consisting of the relay circuit for the engine PWB, FAX PWB, network PWB, etc.
16. Cassette heater PWB (CHPWB)..... Consisting of the relay circuit for the engine PWB, power source PWB and option cassette heater.
17. RFID PWB (RFIDPWB) Reading the toner container information.

Part name table


| No. | Name used in service manual | Name used in parts list | Part. No. |
|-----|---|--|--|
| 1 | Main PWB (MPWB) | PARTS PWB MAIN ASSY SP PARTS PWB MAIN ASSY EU SP | 302R49427_ 302R49428_ |
| 2 | Engine PWB(EPWB) | PARTS PWB ENGINE ASSY SP | 302R49426_ |
| 3 | High-voltage PWB (HVPWB) | PARTS UNIT HIGH VOLTAGE MAIN SP | 302R59404_ |
| 4 | Power source PWB (PSPWB) | PARTS SWITCHING REGULATOR 100V SP PARTS SWITCHING REGULATOR 200V SP | 302R49432_ 302R49433_ |
| 5 | Drum/Developer relay PWB (DR/ DLPRPWB) | PARTS PWB DRUM DLP CONNECT ASSY SP | 302R69404_ |
| 6 | Operation panel PWB (OPPWB) | PARTS OPERATION UNIT L SP PARTS PWB PANEL MAIN ASSY SP | 302R49410_ 302R49423_ |
| 7 | Operation panel right PWB (OPPWB-R) | PARTS OPERATION UNIT L SP PARTS OPERATION L RIGHT ASSY SP | 302R49410_ 302R49425_ |
| 8 | Operation panel left PWB (OPPWB-L) | PARTS OPERATION UNIT L SP PARTS OPERATION L LEFT ASSY SP | 302R49410_ 302R49424_ |
| 9 | LED PWB (LEDPWB) | ISU ASSY L SP (PWB LED ASSY) | 302R49314_ (3V2R60115_) |
| 10 | CCD PWB (CCDPWB) | ISU ASSY L SP (P.W.BOARD ASSY CCD) | 302R49314_ (3V2NM0107_) |
| 11 | APC PWB (APCPWB) | LK-5195 (PWB APC ASSY) | 302R49315_ (302R60112_) |
| 12 | PD PWB (PDPWB) | LK-5195 (PWB PD ASSY) | 302R49315_ (302NP0105_) |
| 13 | Developer PWB (DLPPWB) | DV-5195K DV-5195M DV-5195C DV-5195Y (PWB DLP K ASSY) (PWB DLP M ASSY) (PWB DLP C ASSY) (PWB DLP Y ASSY) | 302R49307_ 302R49308_ 302R49309_ 302R49310_ (302R60121_) (302R60120_) (302R60119_) (302R60118_) |
| 14 | Drum PWB (DRPWB) | DK-5195 (PWB DRUM ASSY) | 302R49305_ (302K00107_) |
| 15 | KUIO relay PWB (KUIORPWB) | PARTS PWB KUIO ASSY SP | 302K99427_ |
| 16 | Cassette heater PWB (CHPWB) | PARTS PWB HEATER RELAY ASSY SP | 302R69405_ |
| 17 | RFID PWB (RFIDPWB) | PARTS PWB RFID ASSY SP | 302R69411_ |

(3-2) Sensors and Switches


Laser scanner unit




Primary transfer unit




Toner container




Document processor





Developer unit



Main unit



Drum unit



Fuser unit



Figure 3-25

1. Paper sensor (PS) Detecting the presence of paper in the cassette.
2. Paper gauge sensor 1 (PGS1)..... Detecting the level of the remaining paper inside the cassette.
3. Paper gauge sensor 2 (PGS2)..... Detecting the level of the remaining paper inside the cassette.
4. Paper length sensor 1 (PLSW1) Detecting cassette paper size and presence of cassette.
5. Paper length sensor 2 (PLSW2) Detecting cassette paper size and presence of cassette.
6. Paper length sensor 3 (PLSW3) Detecting cassette paper size and presence of cassette.
7. Registration sensor (RS)..... Controlling the timing to start the secondary paper feeding.
8. Lift sensor (LS)..... Detecting the upper limit when lifting the bottom plate inside the cassette.
9. MP paper sensor (MPPS) Detecting the presence of paper on the MP tray.
10. Duplex sensor (DUS) Detecting paper jam at the duplex section.
11. Upper eject full sensor (EFS1)..... Detecting the paper-full on the job separator or attachment kit.
12. Lower eject full sensor (EFS2)..... Detecting the paper-full on the inner tray.
13. ID sensor front (IDSF)..... Measuring the toner density at the calibration.
14. ID sensor rear (IDSR) Measuring the toner density at the calibration.
15. TC belt release sensor 1 (TCBRS1) Detecting the transfer belt release position.
16. TC belt release sensor 2 (TCBRS2) Detecting the transfer belt release position.
17. Container sensor (BK)(CS-BK) Detecting the toner container rotation. (Black)
18. Container sensor (M)(CS-M)..... Detecting the toner container rotation. (Magenta)
19. Container sensor (C)(CS-M) Detecting the toner container rotation. (Cyan)
20. Container sensor (Y)(CS-M) Detecting the toner container rotation. (Yellow)
21. Home position sensor (HPS) Detecting the position of the image scanner unit.
22. Front cover switch 1 (FCSW1)..... Shutting off the 24V power supply line when the front cover is opened and reset. Interlock switch.
23. Front cover switch 2 (FCSW2)..... Detecting the front cover (left side) open.
24. Right cover switch (RCSW) Shutting off the 24V power supply line when the right cover is opened. Interlock switch.
25. Waste toner box switch (WTSSW)..... Detecting presence of the waste toner box.
26. Waste toner sensor (WTS)..... Detecting the waste toner amount inside the waste toner box.
27. Temperature and humidity sensor (TEMS)..... Detecting the temperature and humidity outside the main unit.
28. Power switch (PSSW)..... Turning on and off the main/engine PWB, the engine relay PWB and the operation panel PWB, etc.
29. Toner sensor (BK)(TS-M)..... Detecting the toner amount inside developer unit BK. (Black)
30. Toner sensor (M)(TS-M)..... Detecting the toner amount inside developer unit M. (Magenta)
31. Toner sensor (C)(TS-C) Detecting the toner amount inside developer unit C. (Cyan)
32. Toner sensor (Y)(TS-Y)..... Detecting the toner amount inside developer unit Y. (Yellow)
33. Eject sensor (ES)..... Detecting the paper jam at the fuser section.
34. Press-release sensor (FUPRS) Detecting the mode of the fuser pressure.
35. Fuser thermistor 1 (TH1)..... Detecting the heat roller temperature. (Center)
36. Fuser thermistor 2 (TH2)..... Detecting the heat roller temperature. (Edge)
37. DP original sensor (DPOS)..... Detecting the presence of the original in the document processor.
38. DP feed sensor (DPFS) Detects the primary feed timing of the document processor.
39. DP registration sensor (DPRS) Detects the primary feed timing of the document processor.
40. DP feedshift sensor (DPSBS) Detecting the position of the feedshift guide in the document processor.
41. DP open/close sensor (DPOCS) Detecting the opening and closing of the document processor.
42. LSU thermistor (LSUTH)..... Detecting the LSU temperature.


Part name table

| No. | Name used in service manual | Name used in parts list | Part. No. |
|-----|--|-----------------------------------|-----------------|
| 1 | Paper sensor (PS) | PARTS SENSOR OPT.SP | 302P79401_ |
| 2 | Paper gauge sensor 1 (PGS1) | PARTS SENSOR OPT.SP | 302P79401_ |
| 3 | Paper gauge sensor 2 (PGS2) | PARTS SENSOR OPT.SP | 302P79401_ |
| 4 | Paper length sensor 1 (PLSW1) | SW.PUSH | 7SP01000004+H01 |
| 5 | Paper length sensor 2 (PLSW2) | SW.PUSH | 7SP01000004+H01 |
| 6 | Paper length sensor 3 (PLSW3) | SW.PUSH | 7SP01000004+H01 |
| 7 | Registration sensor (RS) | PARTS SENSOR OPT.SP | 303NW9404_ |
| 8 | Lift sensor (LS) | PARTS SENSOR OPT.SP | 302P79401_ |
| 9 | MP paper sensor (MPPS) | PARTS SENSOR OPT.SP | 302P79401_ |
| 10 | Duplex sensor (DUS) | PARTS SENSOR OPT.SP | 302P79401_ |
| 11 | Upper eject full sensor (EFS1) | PARTS SENSOR OPT.SP | 302P79401_ |
| 12 | Lower eject full sensor (EFS2) | PARTS SENSOR OPT.SP | 302P79401_ |
| 13 | ID sensor front (IDSF) | PARTS ID SENSOR ASSY SP | 302R69406_ |
| 14 | ID sensor rear (IDSR) | PARTS ID SENSOR ASSY SP | 302R69406_ |
| 15 | TC belt release sensor 1 (TCBRS1) | PARTS SENSOR OPT.SP | 302P79401_ |
| 16 | TC belt release sensor 2 (TCBRS2) | PARTS SENSOR OPT.SP | 302P79401_ |
| 17 | Container sensor (BK)(CS-BK) | PARTS SENSOR OPT.SP | 302P79401_ |
| 18 | Container sensor (M)(CS-M) | PARTS SENSOR OPT.SP | 302P79401_ |
| 19 | Container sensor (C)(CS-C) | PARTS SENSOR OPT.SP | 302P79401_ |
| 20 | Container sensor (Y)(CS-Y) | PARTS SENSOR OPT.SP | 302P79401_ |
| 21 | Home position sensor (HPS) | PARTS SENSOR OPT.SP | 302P79401_ |
| 22 | Front cover switch 1 (FCSW1) | INTER LOCK SWITCH | 2FB27160 |
| 23 | Front cover switch 2 (FCSW2) | SW.PUSH | 7SP01000004+H01 |
| 24 | Right cover switch (RCSW) | INTER LOCK SWITCH | 2FB27160 |
| 25 | Waste toner box switch (WTSSW) | SW.PUSH | 7SP01000004+H01 |
| 26 | Waste toner sensor (WTS) | SW.PUSH | 7SP01000004+H01 |
| 27 | Temperature and humidity sensor (TEMS) | PARTS PWB THERMISTOR ASSY SP | 302R69419_ |
| 28 | Power switch (PSSW) | PARTS PWB SWITCH ASSY SP | 302NG9430_ |
| 29 | Toner sensor (BK)(TS-M) | DV-5195K (TONER SENSOR ASSY K) | 302R49307_ |
| 30 | Toner sensor (M)(TS-M) | DV-5195N (TONER SENSOR ASSY M) | 302R49308_ |
| 31 | Toner sensor (C)(TS-C) | DV-5195C (TONER SENSOR ASSY C) | 302R49309_ |
| 32 | Toner sensor (Y)(TS-Y) | DV-5195Y (TONER SENSOR ASSY Y) | 302R49310_ |


| No. | Name used in service manual | Name used in parts list | Part. No. |
|-----|-------------------------------|---|--|
| 33 | Eject sensor (ES) | FK-5195 FK-5196 FK-5197 (SENSOR OPT.) | 302R49311_ 302R49312_ 302R49313_ |
| 34 | Press-release sensor (FUPRS) | FK-5195 FK-5196 FK-5197 (SENSOR OPT.) | 302R49311_ 302R49312_ 302R49313_ |
| 35 | Fuser thermistor 1 (TH1) | FK-5195 FK-5196 FK-5197 (THERMISOR ASSY) | 302R49311_ 302R49312_ 302R49313_ |
| 36 | Fuser thermistor 2 (TH2) | FK-5195 FK-5196 FK-5197 (THERMISTOR FUSER) | 302R49311_ 302R49312_ 302R49313_ |
| 37 | DP original sensor (DPOS) | DP ASSY SP (SENSOR OPT.) | 302R49301_ (7NXSG2A241++H01) |
| 38 | DP paper feed sensor (DPFS) | DP ASSY SP (SENSOR OPT.) | 302R49301_ (7NXSG2A241++H01) |
| 39 | DP registration sensor (DPRS) | DP ASSY SP (SENSOR OPT.) | 302R49301_ (7NXSG2A241++H01) |
| 40 | DP feedshift sensor(DPFSS) | DP ASSY SP (SENSOR OPT.) | 302R49301_ (7NXSG2A241++H01) |
| 41 | DP open/close sensor (DPOCS) | DP ASSY SP (SENSOR OPT.) | 302R49301_ (7NXSG2A241++H01) |
| 42 | LSU thermistor (LSUTH) | LK-5195 (PWB THERMISTOR ASSY) | 302R49315_ |

(3-3) Motors


Laser scanner unit




Primary transfer unit




Toner container




Document processor




Developer unit



Main unit



Drum unit



Fuser unit




Figure 3-26

1. Developer motor (BK)(DLPM-BK)..... Driving the paper feeding and developer unit BK.
2. Transfer motor (TRM) Driving the primary transfer unit.
3. Drum motor (BK)(DRM-BK) Driving the drum unit. (Black)
4. Drum motor (M/C/Y)(DRM-M/C/Y)..... Driving the drum units. (Color)
5. Developer motor
(M/C/Y)(DLPM-M/C/Y) Driving the developer units. (Color)
6. Lift motor (LM)..... Operating the bottom plate inside the cassette.
7. Fuser motor (FUM) Driving the fuser section.
8. Eject motor (EM) Driving the eject section.
9. Scanner motor (SM)..... Driving the optical section.
10. Toner motor (BK)(TM-K) Supplying the toner to developer unit. (Black)
11. Toner motor (M)(TM-M)..... Supplying the toner to developer unit. (Magenta)
12. Toner motor (C)(TM-C) Supplying the toner to developer unit. (Cyan)
13. Toner motor (Y)(TM-K)..... Supplying the toner to developer unit. (Yellow)
14. Eject fan motor (EFM)..... Cooling the eject section.
15. Developer fan motor 1(DLPFM1) Cooling the developer.
16. Developer fan motor 2(DLPFM2)..... Cooling the developer.
17. Transfer release motor (TCBRM)..... Driving the primary transfer roller separation.
18. Polygon motor (PM) Driving polygon mirror.
19. Cleaning motor (CLM)..... Driving the LSU glass cleaning mechanism.
20. Controller fan motor (CONTFM) Cooling the main PWB.
21. Developer fan motor 3(DLPFM3)..... Cooling the developer.
22. Developer fan motor 4(DLPFM4)..... Cooling the developer.
23. Steam removal fan motor (SFM)..... Removing the steam.
24. PWB fan motor (PWBFM)..... Cooling the power source PWB and high-voltage PWB.
25. Clutch fan motor (CLFM) Cooling the clutch.
26. Vibration motor BK (VIBM-BK)..... Vibrating the developer unit BK.
27. Vibration motor M(VIBM-M) Vibrating the developer unit M.
28. Vibration motor C(VIBM-C) Vibrating the developer unit C.
29. Vibration motor Y(VIBM-Y) Vibrating the developer unit Y.
30. DP feed motor (DPFM) Driving the original feed section in the document processor.
31. DP conveying motor (DPCM)..... Driving the original conveying section in the document processor
32. DP feedshift motor (DPFSM) Driving the original feed section in the document processor.


Part name table

| No. | Name used in service manual | Name used in parts list | Part. No. |
|-----|---|---|----------------------------|
| 1 | Developer motor (BK)(DLPM-BK) | PARTS FEED DRIVE ASSY SP (MOTOR-BL W20) | 302R49408_ (302K94414_) |
| 2 | Transfer motor (TCM) | IMAGE DRIVE ASSY (MOTOR-BL W20) | 302R45841_ (302K94414_) |
| 3 | Drum motor (BK)(DRM-BK) | DR-5195 (MOTOR-BL W20 DRUM Z11) | 302R49304_ |
| 4 | Drum motor (M/C/Y)(DRM-M/C/Y) | DR-5195 (MOTOR-BL W20 DRUM Z11) | 302R49304_ |
| 5 | Developer motor (M/C/Y)(DLPM-M/ C/Y) | DR-5195 (MOTOR-BL W20) | 302R49304_ |
| 6 | Lift motor (LM) | PARTS LIFT MOTOR ASSY SP | 302R49422_ |
| 7 | Fuser motor (FUM) | PARTS MOTOR FUSER ASSY SP | 302R49422_ |
| 8 | Duplex eject motor (EM) | PARTS EXIT ASSY SP (MOTOR EJECT) | 302R49405_ (302P74407_) |
| 9 | Image scanner motor (ISUM) | PARTS MOTOR ISU SP | 302LW9406_ |
| 10 | Container motor (BK)(CM-BK) | PARTS DC MOTOR ASSY B SP | 302R49420_ |
| 11 | Container motor (M)(CM-M) | PARTS DC MOTOR ASSY B SP | 302R49420_ |
| 12 | Container motor (C)(CM-C) | PARTS DC MOTOR ASSY B SP | 302R49420_ |
| 13 | Container motor (Y)(CM-Y) | PARTS DC MOTOR ASSY B SP | 302R49420_ |
| 14 | Eject fan motor (EFM) | FAN LSU 60-25 | 302GR4408_ |
| 15 | Developer fan motor 1(DLPFM1) | PARTS FAN COOLING LSU 60 SP | 302LC9438_ |
| 16 | Developer fan motor 2(DLPFM1) | PARTS FAN COOLING LSU 60 SP | 302LC9438_ |
| 17 | Transfer release motor (TCBRM) | PARTS DC MOTOR ASSY B SP DC MOTOR ASSY B | 302R49420_ 302R40005_ |
| 18 | Polygon motor (PM) | LK-5195 (MOTOR POLYGON) | 302R49315_ |
| 19 | Cleaning motor (CLM) | PARTS DC MOTOR ASSY B SP | 302R49420_ |
| 20 | Controller fan motor (CONFM) | PARTS,FAN COOLING CONVEYING SP | 302FZ9442_ |
| 21 | Developer fan motor 3 (DLPFM3) | PARTS,FAN IMAGE SP | 302FZ9466_ |
| 22 | Developer fan motor 4 (DLPFM4) | PARTS,FAN IMAGE SP | 302FZ9466_ |
| 23 | Steam removal fan motor (SFM) | PARTS EXIT ASSY SP (FAN COOLING 40-15) | 302R49405_ (302H04412_) |
| 24 | PWB fan motor (PWBFM) | PARTS FAN COOLING LSU 60 SP | 302LC9438_ |
| 25 | Clutch fan motor (CLFM) | FAN COOLING 40-15 | 302H04412 |
| 26 | Vibration motor BK (VIBM-BK) | DV-5195K (MOTOR VIBRATION) | 302R49307_ |
| 27 | Vibration motor M(VIBM-M) | DV-5195M (MOTOR VIBRATION) | 302R49308_ |


| No. | Name used in service manual | Name used in parts list | Part. No. |
|-----|-----------------------------|-------------------------------------|----------------------------|
| 28 | Vibration motor C(VIBM-C) | DV-5195C (MOTOR VIBRATION) | 302R49309_ |
| 29 | Vibration motor Y(VIBM-Y) | DV-5195Y (MOTOR VIBRATION) | 302R49310_ |
| 30 | DP feed motor (DPFM) | DP ASSY SP (MOTOR-HB PAPER FEED) | 302R49301_ (302NM4404_) |
| 31 | DP conveying motor (DPCM) | DP ASSY SP (MOTOR-HB PAPER FEED) | 302R49301_ (302NM4404_) |
| 32 | DP feedshift motor (DPFSM) | DP ASSY SP (MOTOR ROTARY) | 302R49301_ (302KY4409_) |

(3-4) Others


Laser scanner unit




Primary transfer unit




Toner container




Document processor




Developer unit



Drum unit



Fuser unit



Main unit




Figure 3-27

1. Paper feed clutch (PCL)..... Controlling the primary paper feeding from the cassette.
2. Middle clutch (MCL) Controlling the conveying section drive.
3. Duplex clutch (DUCL) Controlling the duplex drive.
4. Registration clutch (RCL)..... Controlling the secondary paper feeding from the cassette.
5. Developer clutch (DLPCL) Controlling the drive to developer unit. (Black)
6. MP solenoid (MPSOL) Controlling the primary paper feeding from the MP tray.
7. Feedshift solenoid (FSSOL)..... Operates the feedshift guide.
8. Cleaning lamp (BK)(CL-K) Removing the remaining electric charge on the drum. (Black)
9. Cleaning lamp (M)(CL-M) Removing the remaining electric charge on the drum. (Magenta)
10. Cleaning lamp (C)(CL-C) Removing the remaining electric charge on the drum. (Cyan)
11. Cleaning lamp (Y) (CL-Y)..... Removing the remaining electric charge on the drum. (Yellow)
12. Fuser heater (FH) Heating the heat roller.
13. Speaker (SPK) Outputting sounds.

Part name table

| No. | Name used in service manual | Name used in parts list | Part. No. |
|------------|------------------------------------|--|--|
| 1 | Paper feed clutch (FCL) | PARTS FEED DRIVE ASSY SP (CLUTCH 35 Z35R) | 302R49408_ (302NR4404_) |
| 2 | Middle clutch (MCL) | PARTS FEED DRIVE ASSY SP (CLUTCH 35 Z35R) | 302R49408_ (302NR4404_) |
| 3 | Duplex clutch (DUCL) | PARTS FEED DRIVE ASSY SP (CLUTCH 35 Z35R) | 302R49408_ (302NR4404_) |
| 4 | Registration clutch (RCL) | PARTS FEED DRIVE ASSY SP (CLUTCH 35 Z35R) | 302R49408_ (302NR4404_) |
| 5 | Developer clutch (DLPCL) | PARTS FEED DRIVE ASSY SP (CLUTCH 35 Z35R) | 302R49408_ (302NR4404_) |
| 6 | MP solenoid (MPSOL) | PARTS FEED DRIVE ASSY SP (SOLENOID MPF) | 302R49408_ (302HN4416_) |
| 7 | Feedshift solenoid (FSSOL) | PARTS EXIT ASSY SP (SOLENOID PRIMARY FEED) | 302R49405_ (302K94417_) |
| 8 | Cleaning lamp (BK)(CL-BK) | DK-5195 (PWB ERASER ASSY) | 302R49305_ |
| 9 | Cleaning lamp (M)(CL-M) | DK-5195 (PWB ERASER ASSY) | 302R49305_ |
| 10 | Cleaning lamp (C)(CL-C) | DK-5195 (PWB ERASER ASSY) | 302R49305_ |
| 11 | Cleaning lamp (Y)(CL-Y) | DK-5195 (PWB ERASER ASSY) | 302R49305_ |
| 12 | Fuser heater (FH) | FK-5195 FK-5196 FK-5197 HEATER LAMP 240 HEATER LAMP 100 HEATER LAMP 120 | 302R49311_ 302R49312_ 302R49313_ |
| 13 | Speaker (SPK) | PARTS SPEAKER SP | 302LC9437_ |

3-5 Electric parts (35/40 ppm models)

(1) Wire connection

(1-1) (Machine rear side)




Figure 3-28

- | | |
|---------------------------------|-------------------------|
| 1. Main PWB | 5. DP relay PWB |
| 2. Engine PWB | 6. Controller fan motor |
| 3. High-voltage PWB | 7. Hard disk |
| 4. Transfer high-voltage PWB *1 | |

*1: 40 ppm model only

(1-2) Backside of the High-voltage PWB**Figure 3-29**

- | | |
|---------------------------|-----------------------------|
| 8. Power source PWB | 12. Drum motor (M/C/Y) |
| 9. Power source fan motor | 13. Developer motor (M/C/Y) |
| 10. Developer motor (BK) | 14. Clutch cooling fan |
| 11. Drum motor (BK) | |

(2) Descriptions about the major PWBs

(2-1) Main PWB

It controls the software for the interface and image data processing, and the hardware generating the image scanner unit and operation section.



Figure 3-30

(2-2) Engine PWB


It controls the hardware for the generation of the high-voltage and the bias, and the paper conveying system.



Figure 3-31

(2-3) High-voltage PWB

Generating the main charger high-voltage and the developer bias, the transfer bias, separation bias and the transfer cleaning bias.



(40 ppm model)



(35 ppm model)

Figure 3-32

(2-4) Transfer high-voltage PWB

Output the transfer bias and separation bias.

* : 40 ppm model only




Figure 3-33

(2-5) Power source PWB

The input voltage (AC) from the AC power supply is changed to DC such as DC24V, and it controls the fuser heater.



Figure 3-34

(2-6) Operation panel PWB

It consists of the wiring relay circuit for the main PWB, the operation panel sub PWB and the LCD.



Figure 3-35

(3) Electric parts layout

(3-1) PWBs










Figure 3-36

1. Main PWB (MPWB) Controlling the entire software to control the interface to the PC and network and image data process, etc. Controlling the entire hardware to control the image scanner unit and operation section.
2. Engine PWB (EPWB)..... Controlling the hardware such as electric parts drive, high voltage, bias output, paper conveying, fuser temperature, etc.
3. High-voltage PWB (HVPWB) Generating the main charger high-voltage and the developer bias.
4. Transfer high-voltage PWB (TCHVPWB) *1..... Generating the transfer bias and separation bias.
5. Power source PWB (PSPWB) Rectifying the AC power input to the full-wave and converting it to DC24V. It controls the fuser heater.
6. Drum/developer relay PWB (DR/DLPRWB)..... Consisting of the wiring relay circuit to the engine PWB, drum units and developer units.
7. Operation panel PWB (OPPWB) It consists of the wiring relay circuit for the main PWB, panel-left PWB, panel-right PWB and LCD.
8. Operation panel sub PWB (OPPWB-S)..... Consisting of the LED indicator and the key switches.
9. LED PWB (LEDPWB) Controlling the LED.
10. CCD PWB (CCDPWB)..... Scanning the original image.
11. APC PWB (APCPWB) Emitting and controlling the laser beam.
12. PD PWB (PDPWB) Controlling the synchronous lateral laser beam.
13. Developer PWB (DLPPWB)..... Wiring relay to the electric parts inside developer unit.
14. Drum PWB (DRPWB) Wiring relay to the electric parts inside drum unit. Storing the drum unique data in an EEPROM.
15. KUIO relay PWB (KUIORPWB) Consisting of the relay circuit for the engine PWB, FAX PWB, network PWB, etc.
16. USB PWB (USBPWB) USB hub PWB.
17. Cassette heater PWB (CHPWB)..... Consisting of the relay circuit for the engine PWB, power source PWB and option cassette heater.
18. RFID PWB (RFIDPWB) Reading the toner container information.

*1: 40 ppm model only

Part name table

| No. | Name used in service manual | Name used in parts list | Part. No. |
|-----|---------------------------------------|--|--|
| 1 | Main PWB (MPWB) | PARTS PWB MAIN ASSY SP PARTS PWB MAIN ASSY EU SP | 302R59402_ *1 302R69409_ *2 302R59403_ *1 302R69410_ *2 |
| 2 | Engine PWB(EPWB) | PARTS PWB ENGINE ASSY SP | 302R59403_ *1 302R69408_ *2 |
| 3 | High-voltage PWB (HVPWB) | PARTS UNIT HIGH VOLTAGE MAIN SP | 302R59404_ *1 302R69415_ *2 |
| 4 | Transfer high-voltage PWB (TCHVPWB) | PARTS UNIT HIGH VOLTAGE TRANSFER SP | 302R69416_ *2 |
| 5 | Power source PWB (PSPWB) | PARTS UNIT LOW VOLTAGE 100 SP PARTS UNIT LOW VOLTAGE 200 SP | 302R69417_ 302R69418_ |
| 6 | Drum/Developer relay PWB (DR/DLPRPWB) | PARTS PWB DRUM DLP CONNECT ASSY SP | 302R69404_ |
| 7 | Operation panel PWB (OPPWB) | PARTS OPERATION UNIT H SP PARTS PWB PANEL MAIN ASSY SP | 302R69403_ 302R69412_ |
| 8 | Operation panel PWB SUB (OPPWB-S) | PARTS OPERATION UNIT H SP PARTS PWB OPERATION H ASSY SP | 302R69403_ 302R69413_ |
| 9 | LED PWB (LEDPWB) | ISU ASSY H SP (PWB LED ASSY) | 302R69312_ |
| 10 | CCD PWB (CCDPWB) | ISU ASSY H SP (PWB CCD ASSY) | 302R69312_ |
| 11 | APC PWB (APCPWB) | LK-5195 (PWB APC ASSY) | 302R49315_ |
| 12 | PD PWB (PDPWB) | LK-5195 (PWB PD ASSY) | 302R49315_ |
| 13 | Developer PWB (DLPPWB) | DV-5205K DV-5205M DV-5205C DV-5205Y DV-5215K DV-5215M DV-5215C DV-5215Y (PWB DLP K ASSY) (PWB DLP M ASSY) (PWB DLP C ASSY) (PWB DLP Y ASSY) | 302R59301_ *1 302R59302_ *1 302R59303_ *1 302R59304_ *1 302R69304_ *2 302R69305_ *2 302R69306_ *2 302R69307_ *2 |
| 14 | Drum PWB (DRPWB) | DK-5195 DK-5215 (PWB DRUM ASSY) | 302R49305_ *1 602R69302_ *2 |
| 15 | KUIO relay PWB (KUIORPWB) | PARTS PWB KUIO ASSY SP | 302K99427_ |
| 16 | USB PWB (USBPWB) | PARTS PWB USB HUB ASSY SP | 302R69407_ |

| No. | Name used in service manual | Name used in parts list | Part. No. |
|------------|------------------------------------|-----------------------------------|------------------|
| 17 | Cassette heater PWB (CHPWB) | PARTS PWB HEATER RELAY ASSY SP | 302R69405_ |
| 18 | RFID PWB (RFIDPWB) | PARTS PWB RFID ASSY SP | 302R69411_ |

*1: 35 ppm model, *2: 40 ppm model

(3-2) Sensors and Switches




Figure 3-37

1. Paper sensor (PS) Detecting the presence of paper in the cassette.
2. Paper gauge sensor 1 (PGS1)..... Detecting the level of the remaining paper inside the cassette.
3. Paper gauge sensor 2 (PGS2)..... Detecting the level of the remaining paper inside the cassette.
4. Paper length sensor 1 (PLSW1) Detecting cassette paper size and presence of cassette.
5. Paper length sensor 2 (PLSW2) Detecting cassette paper size and presence of cassette.
6. Paper length sensor 3 (PLSW3) Detecting cassette paper size and presence of cassette.
7. Registration sensor (RS)..... Controlling the timing to start the secondary paper feeding.
8. Lift sensor (LS)..... Detecting the upper limit when lifting the bottom plate inside the cassette.
9. MP paper sensor (MPPS) Detecting the presence of paper on the MP tray.
10. Duplex sensor (DUS) Detecting paper jam at the duplex section.
11. Upper eject full sensor (EFS1)..... Detecting the paper-full on the job separator or attachment kit.
12. Lower eject full sensor (EFS2)..... Detecting the paper-full on the inner tray.
13. ID sensor front (IDSF)..... Measuring the toner density at the calibration.
14. ID sensor rear (IDSR) Measuring the toner density at the calibration.
15. TC belt release sensor 1 (TCBRS1) Detecting the transfer belt release position.
16. TC belt release sensor 2 (TCBRS2) Detecting the transfer belt release position.
17. Container sensor (BK)(CS-BK) Detecting the toner container rotation. (Black)
18. Container sensor (M)(CS-M)..... Detecting the toner container rotation. (Magenta)
19. Container sensor (C)(CS-M) Detecting the toner container rotation. (Cyan)
20. Container sensor (Y)(CS-M) Detecting the toner container rotation. (Yellow)
21. Home position sensor (HPS) Detecting the position of the image scanner unit.
22. Front cover switch 1 (FCSW1)..... Shutting off the 24V power supply line when the front cover is opened and reset. Interlock switch.
23. Front cover switch 2 (FCSW2)..... Detecting the front cover (left side) open.
24. Right cover switch (RCSW) Shutting off the 24V power supply line when the right cover is opened. Interlock switch.
25. Waste toner box switch (WTSSW)..... Detecting presence of the waste toner box.
26. Waste toner sensor (WTS)..... Detecting the waste toner amount inside the waste toner box.
27. Temperature and humidity sensor (TEMS)..... Detecting the temperature and humidity outside the main unit.
28. Power switch (PSSW)..... Turning on and off the main/engine PWB, the engine relay PWB and the operation panel PWB, etc.
29. Toner sensor (BK)(TS-M)..... Detecting the toner amount inside developer unit BK. (Black)
30. Toner sensor (M)(TS-M)..... Detecting the toner amount inside developer unit M. (Magenta)
31. Toner sensor (C)(TS-C) Detecting the toner amount inside developer unit C. (Cyan)
32. Toner sensor (Y)(TS-Y)..... Detecting the toner amount inside developer unit Y. (Yellow)
33. Eject sensor (ES)..... Detecting the paper jam at the fuser section.
34. Press-release sensor (FUPRS) Detecting the mode of the fuser pressure.
35. Fuser thermistor 1 (TH1)..... Detecting the heat roller temperature. (Center)
36. Fuser thermistor 2 (TH2)..... Detecting the heat roller temperature. (Edge)
37. MP tray switch (MPTSW)..... Detecting the MP tray is pulled out.
38. MP paper width sensor (MPWS)..... Detecting the MP paper width.
39. MP paper length sensor (MPLS)..... Detecting the MP paper length.
40. LSU thermistor (LSUTH)..... Detecting the LSU temperature.

Part name table

| No. | Name used in service manual | Name used in parts list | Part. No. |
|-----|--|-----------------------------------|-----------------|
| 1 | Paper sensor (PS) | PARTS SENSOR OPT.SP | 302P79401_ |
| 2 | Paper gauge sensor 1 (PGS1) | PARTS SENSOR OPT.SP | 302P79401_ |
| 3 | Paper gauge sensor 2 (PGS2) | PARTS SENSOR OPT.SP | 302P79401_ |
| 4 | Paper length sensor 1 (PLSW1) | SW.PUSH | 7SP01000004+H01 |
| 5 | Paper length sensor 2 (PLSW2) | SW.PUSH | 7SP01000004+H01 |
| 6 | Paper length sensor 3 (PLSW3) | SW.PUSH | 7SP01000004+H01 |
| 7 | Registration sensor (RS) | PARTS SENSOR OPT.SP | 303NW9404_ |
| 8 | Lift sensor (LS) | PARTS SENSOR OPT.SP | 302P79401_ |
| 9 | MP paper sensor (MPPS) | PARTS SENSOR OPT.SP | 302P79401_ |
| 10 | Duplex sensor (DUS) | PARTS SENSOR OPT.SP | 302P79401_ |
| 11 | Upper eject full sensor (EFS1) | PARTS SENSOR OPT.SP | 302P79401_ |
| 12 | Lower eject full sensor (EFS2) | PARTS SENSOR OPT.SP | 302P79401_ |
| 13 | ID sensor front (IDSF) | PARTS ID SENSOR ASSY SP | 302R69406_ |
| 14 | ID sensor rear (IDSR) | PARTS ID SENSOR ASSY SP | 302R69406_ |
| 15 | TC belt release sensor 1 (TCBRS1) | PARTS SENSOR OPT.SP | 302P79401_ |
| 16 | TC belt release sensor 2 (TCBRS2) | PARTS SENSOR OPT.SP | 302P79401_ |
| 17 | Container sensor (BK)(CS-BK) | PARTS SENSOR OPT.SP | 302P79401_ |
| 18 | Container sensor (M)(CS-M) | PARTS SENSOR OPT.SP | 302P79401_ |
| 19 | Container sensor (C)(CS-C) | PARTS SENSOR OPT.SP | 302P79401_ |
| 20 | Container sensor (Y)(CS-Y) | PARTS SENSOR OPT.SP | 302P79401_ |
| 21 | Home position sensor (HPS) | PARTS SENSOR OPT.SP | 302P79401_ |
| 22 | Front cover switch 1 (FCSW1) | INTER LOCK SWITCH | 2FB27160 |
| 23 | Front cover switch 2 (FCSW2) | SW.PUSH | 7SP01000004+H01 |
| 24 | Right cover switch (RCSW) | INTER LOCK SWITCH | 2FB27160 |
| 25 | Waste toner box switch (WTSSW) | SW.PUSH | 7SP01000004+H01 |
| 26 | Waste toner sensor (WTS) | SW.PUSH | 7SP01000004+H01 |
| 27 | Temperature and humidity sensor (TEMS) | PARTS PWB THERMISTOR ASSY SP | 302R69419_ |
| 28 | Power switch (PSSW) | PARTS PWB SWITCH ASSY SP | 302NG9430_ |
| 29 | Toner sensor (BK)(TS-M) | DV-5205K (TONER SENSOR ASSY K) | 302R59301_ *1 |
| | | DV-5215K (TONER SENSOR ASSY K) | 302R69304_ *2 |
| 30 | Toner sensor (M)(TS-M) | DV-5205M (TONER SENSOR ASSY M) | 302R59302_ *1 |
| | | DV-5215M (TONER SENSOR ASSY M) | 302R69305_ *2 |

| No. | Name used in service manual | Name used in parts list | Part. No. |
|-----|-------------------------------|--|--|
| 31 | Toner sensor (C)(TS-C) | DV-5205C (TONER SENSOR ASSY C) DV-5215C (TONER SENSOR ASSY C) | 302R59303_ *1 302R69306_ *2 |
| 32 | Toner sensor (Y)(TS-Y) | DV-5205Y (TONER SENSOR ASSY Y) DV-5215Y (TONER SENSOR ASSY Y) | 302R59304_ *1 302R69307_ *2 |
| 33 | Eject sensor (ES) | FK-5205 FK-5206 FK-5207 (SENSOR OPT.) | 302R69308_ 302R69309_ 302R69310_ |
| 34 | Press-release sensor (FUPRS) | FK-5205 FK-5206 FK-5207 (SENSOR OPT.) | 302R69308_ 302R69309_ 302R69310_ |
| 35 | Fuser thermistor 1 (TH1) | FK-5205 FK-5206 FK-5207 (THERMISTOR FUSER NC) | 302R69308_ 302R69309_ 302R69310_ |
| 36 | Fuser thermistor 2 (TH2) | FK-5205 FK-5206 FK-5207 (THERMISTOR FUSER) | 302R69308_ 302R69309_ 302R69310_ |
| 37 | MP tray switch (MPTSW) | SW.PUSH | 7SP01000004+H01 |
| 38 | MP paper width sensor (MPWS) | PARTS PWB PAPER SIZE SENSOR ASSY SP | 303R39405_ |
| 39 | MP paper length sensor (MPLS) | PARTS SENSOR OPT.SP | 302P79401_ |
| 40 | LSU thermistor (LSUTH) | LK-5195 (PWB THERMISTOR ASSY) | 302R49315_ |

*1: 35 ppm model

*2: 40 ppm model

(3-3) Motors




Figure 3-38

1. Developer motor (BK)(DLPM-BK)..... Driving the paper feeding and developer unit BK.
2. Transfer motor (TRM) Driving the primary transfer unit.
3. Drum motor (BK)(DRM-BK) Driving the drum unit. (Black)
4. Drum motor (M/C/Y)(DRM-M/C/Y)..... Driving the drum units. (Color)
5. Developer motor
(M/C/Y)(DLPM-M/C/Y) Driving the developer units. (Color)
6. Lift motor (LM)..... Operating the bottom plate inside the cassette.
7. Fuser motor (FUM) Driving the fuser section.
8. Eject motor (EM) Driving the eject section.
9. Scanner motor (SM)..... Driving the optical section.
10. Toner motor (BK)(TM-K) Supplying the toner to developer unit. (Black)
11. Toner motor (M)(TM-M)..... Supplying the toner to developer unit. (Magenta)
12. Toner motor (C)(TM-C) Supplying the toner to developer unit. (Cyan)
13. Toner motor (Y)(TM-K)..... Supplying the toner to developer unit. (Yellow)
14. Eject fan motor (EFM)..... Cooling the eject section.
15. Developer fan motor 1(DLPFM1) Cooling the developer.
16. Developer fan motor 2(DLPFM2)..... Cooling the developer.
17. Transfer release motor (TCBRM)..... Driving the primary transfer roller separation.
18. Transfer belt fan motor (TBFM)..... Cooling the transfer section.
19. Toner sucking fan motor (TFM)* Sucking scattering waste toner.
20. Polygon motor (PM) Driving polygon mirror.
21. Cleaning motor (CLM)..... Driving the LSU glass cleaning mechanism.
22. Controller fan motor (CONTFM) Cooling the main PWB.
23. Developer fan motor 3(DLPFM3)..... Cooling the developer.
24. Developer fan motor 4(DLPFM4)..... Cooling the developer.
25. Steam removal fan motor (SFM)..... Removing the steam.
26. PWB fan motor (PWBFM)..... Cooling the power source PWB and high-voltage PWB.
27. Clutch fan motor (CLFM) Cooling the clutch.
28. Vibration motor BK (VIBM-BK)..... Vibrating the developer unit BK.
29. Vibration motor M(VIBM-M) Vibrating the developer unit M.
30. Vibration motor C(VIBM-C)..... Vibrating the developer unit C.
31. Vibration motor Y(VIBM-Y) Vibrating the developer unit Y.
32. Eject paper fan motor (EPFM) Cooling the eject paper.

*: for 40 ppm model only

Part name table

| No. | Name used in service manual | Name used in parts list | Part. No. |
|-----|---|--|--------------------------------|
| 1 | Developer motor (BK)(DLPM-BK) | PARTS FEED DRIVE ASSY SP (MOTOR-BL W20) | 302R49408_ (302K94414_) |
| 2 | Transfer motor (TCM) | IMAGE DRIVE ASSY (MOTOR-BL W20) | 302R45841_ (302K94414_) |
| 3 | Drum motor (BK)(DRM-BK) | DR-5205 (MOTOR-BL W20 DRUM Z11) | 302R69301_ |
| 4 | Drum motor (M/C/Y)(DRM-M/C/Y) | DR-5205 (MOTOR-BL W20 DRUM Z11) | 302R69301_ |
| 5 | Developer motor (M/C/Y)(DLPM-M/ C/Y) | DR-5205 (MOTOR-BL W20) | 302R69301_ |
| 6 | Lift motor (LM) | PARTS LIFT MOTOR ASSY SP | 302R49422_ |
| 7 | Fuser motor (FUM) | PARTS MOTOR FUSER ASSY SP | 302R49422_ |
| 8 | Duplex eject motor (EM) | PARTS EXIT ASSY SP (MOTOR EJECT) | 302R49405_ (302P74407_) |
| 9 | Image scanner motor (ISUM) | PARTS MOTOR ISU SP | 302LW9406_ |
| 10 | Container motor (BK)(CM-BK) | PARTS DC MOTOR ASSY B SP | 302R49420_ |
| 11 | Container motor (M)(CM-M) | PARTS DC MOTOR ASSY B SP | 302R49420_ |
| 12 | Container motor (C)(CM-C) | PARTS DC MOTOR ASSY B SP | 302R49420_ |
| 13 | Container motor (Y)(CM-Y) | PARTS DC MOTOR ASSY B SP | 302R49420_ |
| 14 | Eject fan motor (EFM) | FAN LSU 60-25 | 302GR4408_ |
| 15 | Developer fan motor 1(DLPFM1) | PARTS FAN COOLING LSU 60 SP | 302LC9438_ |
| 16 | Developer fan motor 2(DLPFM1) | PARTS FAN COOLING LSU 60 SP | 302LC9438_ |
| 17 | Transfer release motor (TCBRM) | PARTS DC MOTOR ASSY B SP | 302R49420_ |
| 18 | Transfer belt fan motor (TBFM) | PARTS,FAN IMAGE SP | 302FZ9466_ |
| 19 | Toner sucking fan motor (TFM) | PARTS,FAN COOLING LSU 60 SP | 302LC9438_ *2 |
| 20 | Polygon motor (PM) | LK-5195 (MOTOR POLYGON) | 302R49315_ |
| 21 | Cleaning motor (CLM) | PARTS DC MOTOR ASSY B SP | 302R49420_ |
| 22 | Controller fan motor (CONTFM) | FAN BOX COOLING | 302FZ4404_ |
| 23 | Developer fan motor 3 (DLPFM3) | PARTS,FAN IMAGE SP | 302FZ9466_ |
| 24 | Developer fan motor 4 (DLPFM4) | PARTS,FAN IMAGE SP | 302FZ9466_ |
| 25 | Steam removal fan motor (SFM) | PARTS EXIT ASSY SP (FAN COOLING 40-15) | 302R49405_ (302H04412_) |
| 26 | PWB fan motor (PWBFM) | FAN COOLING LSU 60 | 302LC9438_ |
| 27 | Clutch fan motor (CLFM) | FAN COOLING 40-15 | 302H04412 |
| 28 | Vibration motor BK (VIBM-BK) | DV-5205K DV-5215K (MOTOR VIBRATION) | 302R59301_ *1 302R69304_ *2 |


| No. | Name used in service manual | Name used in parts list | Part. No. |
|-----|-----------------------------|---|--------------------------------|
| 29 | Vibration motor M(VIBM-M) | DV-5205M DV-5215M (MOTOR VIBRATION) | 302R59302_ *1 302R69305_ *2 |
| 30 | Vibration motor C(VIBM-C) | DV-5205C DV-5215C (MOTOR VIBRATION) | 302R59303_ *1 302R69306_ *2 |
| 31 | Vibration motor Y(VIBM-Y) | DV-5205Y DV-5215Y (MOTOR VIBRATION) | 302R59304_ *1 302R69307_ *2 |

*1: 35 ppm model


*2: 40 ppm model

(3-4) Others


Toner container




Primary transfer unit




Developer unit




Laser scanner unit



Drum unit



Main unit



Fuser unit




Figure 3-39

1. Paper feed clutch (PCL)..... Controlling the primary paper feeding from the cassette.
2. Middle clutch (MCL) Controlling the conveying section drive.
3. Duplex clutch (DUCL) Controlling the duplex drive.
4. Registration clutch (RCL)..... Controlling the secondary paper feeding from the cassette.
5. Developer clutch (DLPCL) Controlling the drive to developer unit. (Black)
6. MP solenoid (MPSOL) Controlling the primary paper feeding from the MP tray.
7. Feedshift solenoid (FSSOL)..... Operates the feedshift guide.
8. Cleaning lamp (BK)(CL-K) Removing the remaining electric charge on the drum. (Black)
9. Cleaning lamp (M)(CL-M) Removing the remaining electric charge on the drum. (Magenta)
10. Cleaning lamp (C)(CL-C) Removing the remaining electric charge on the drum. (Cyan)
11. Cleaning lamp (Y) (CL-Y)..... Removing the remaining electric charge on the drum. (Yellow)
12. Fuser heater (FH) Heating the heat roller.
13. Speaker (SPK) Outputting sounds.
14. Hard disk (HDD)* Storing image data and job accounting data.

*: 35ppm model option / 40ppm model standard

Part name table

| No. | Name used in service manual | Name used in parts list | Part. No. |
|-----|-----------------------------|--|--|
| 1 | Paper feed clutch (FCL) | PARTS FEED DRIVE ASSY SP (CLUTCH 35 Z35R) | 302R49408_ (302NR4404_) |
| 2 | Middle clutch (MCL) | PARTS FEED DRIVE ASSY SP (CLUTCH 35 Z35R) | 302R49408_ (302NR4404_) |
| 3 | Duplex clutch (DUCL) | PARTS FEED DRIVE ASSY SP (CLUTCH 35 Z35R) | 302R49408_ (302NR4404_) |
| 4 | Registration clutch (RCL) | PARTS FEED DRIVE ASSY SP (CLUTCH 35 Z35R) | 302R49408_ (302NR4404_) |
| 5 | Developer clutch (DLPCL) | PARTS FEED DRIVE ASSY SP (CLUTCH 35 Z35R) | 302R49408_ (302NR4404_) |
| 6 | MP solenoid (MPSOL) | PARTS FEED DRIVE ASSY SP (SOLENOID MPF) | 302R49408_ (302HN4416_) |
| 7 | Feedshift solenoid (FSSOL) | PARTS EXIT ASSY SP (SOLENOID PRIMARY FEED) | 302R49405_ (302K94417_) |
| 8 | Cleaning lamp (BK)(CL-BK) | DK-5195 (PWB ERASER ASSY) DK-5215 (PWB ERASER ASSY) | 302R49305_ ^{*1} 303R69302_ ^{*2} |
| 9 | Cleaning lamp (M)(CL-M) | DK-5195 (PWB ERASER ASSY) DK-5215 (PWB ERASER ASSY) | 302R49305_ ^{*1} 303R69302_ ^{*2} |
| 10 | Cleaning lamp (C)(CL-C) | DK-5195 (PWB ERASER ASSY) DK-5215 (PWB ERASER ASSY) | 302R49305_ ^{*1} 303R69302_ ^{*2} |
| 11 | Cleaning lamp (Y)(CL-Y) | DK-5195 (PWB ERASER ASSY) DK-5215 (PWB ERASER ASSY) | 302R49305_ ^{*1} 303R69302_ ^{*2} |
| 12 | Fuser heater (FH) | FK-5205 FK-5206 FK-5207 HEATER LAMP 240 HEATER LAMP 100 HEATER LAMP 120 | 302R69308_ 302R69309_ 302R69310_ |
| 13 | Speaker (SPK) | PARTS SPEAKER SP | 302LC9437_ |
| 14 | Hard disk (HDD)* | HDD ASSY SP | 302R69311_ |

*: 35ppm model option / 40ppm model standard

*1: 35 ppm model

*2: 40 ppm model

3-6 Electric parts (Optional unit)

(1) Electric parts layout

(1-1) Paper feeder (PF-5120)




Figure 3-40

1. PF main PWB (PFMPWB) Controlling the electric parts in the PF.
2. PF paper sensor (PFPS)..... Detecting presence of paper in the paper deck.
3. PF paper gauge sensor 1 (PFPGS1).... Detecting the level of the remaining paper inside the cassette.
4. PF paper gauge sensor 2 (PFPGS2).... Detecting the level of the remaining paper inside the cassette.
5. PF paper length switch 1 (PFPLSW1) .. Detecting the cassette paper size and presence of cassette.
6. PF paper length switch 2 (PFPLSW2) .. Detecting the cassette paper size and presence of cassette.
7. PF paper length switch 3 (PFPLSW3) .. Detecting the cassette paper size and presence of cassette.
8. PF lift sensor (PFLS)..... Detecting the upper limit when lifting the bottom plate inside the cassette.
9. PF feed sensor (PFFS)..... Detecting the paper conveying after cassette feed.
10. PF right cover switch (PFRCSW)..... Detecting the right cover open.
11. PF paper feed motor (PFFPM) Driving the paper feeding system.
12. PF lift motor (PFLM)..... Operating the bottom plate inside the cassette.
13. PF paper feed clutch (PFFCL) Controlling the primary paper feeding from the cassette.
14. PF conveying clutch(PFCCL)..... Controlling the paper conveying.
15. Cassette heater switch (CHSW) Interlock switch for the cassette heater.

(1-2) Paper feeder (PF-5130)






Figure 3-41

- 1. PF main PWB (PFMPWB) Controlling the electric parts in the PF.
- 2. PF paper sensor 1 (PFPS1)..... Detecting presence of paper in the upper cassette.
- 3. PF paper sensor 2 (PFPS2)..... Detecting presence of paper in the lower cassette.
- 4. PF paper gauge sensor 1 (PFPGS1).... Detecting the level of the remaining paper inside the upper cassette.


5. PF paper gauge sensor 2 (PFPGS2).... Detecting the level of the remaining paper inside the upper cassette.
6. PF paper gauge sensor 3 (PFPGS3).... Detecting the level of the remaining paper inside the lower cassette.
7. PF paper gauge sensor 4 (PFPGS4).... Detecting the level of the remaining paper inside the lower cassette.
8. PF paper length switch 1 (PFPLSW1) .. Detecting the cassette paper size and presence of upper cassette.
9. PF paper length switch 2 (PFPLSW2) .. Detecting the cassette paper size and presence of upper cassette.
10. PF paper length switch 3 (PFPLSW3) .. Detecting the cassette paper size and presence of upper cassette.
11. PF paper length switch 4 (PFPLSW4) .. Detecting the cassette paper size and presence of lower cassette.
12. PF paper length switch 5 (PFPLSW5) .. Detecting the cassette paper size and presence of lower cassette.
13. PF paper length switch 6 (PFPLSW6) .. Detecting the cassette paper size and presence of lower cassette.
14. PF lift sensor 1 (PFLS1)..... Detecting the upper limit when lifting the bottom plate inside the upper cassette.
15. PF lift sensor 2 (PFLS2)..... Detecting the upper limit when lifting the bottom plate inside the lower cassette.
16. PF feed sensor 1 (PFFS1)..... Detecting the paper conveying after upper cassette feed.
17. PF feed sensor 2 (PFFS2)..... Detecting the paper conveying after lower cassette feed.
18. PF right cover switch (PFRCSW)..... Detecting the right cover open.
19. PF paper feed motor (PFPFM) Driving the paper feeding system.
20. PF lift motor 1 (PFLM1)..... Operating the bottom plate inside the upper cassette.
21. PF lift motor 2 (PFLM2)..... Operating the bottom plate inside the lower cassette.
22. PF paper feed clutch 1 (PFCL1) Controlling the primary paper feeding from the upper cassette.
23. PF paper feed clutch 2 (PFCL2) Controlling the primary paper feeding from the lower cassette.
24. PF conveying clutch 1 (PFCCL1)..... Controlling the paper conveying section.
25. PF conveying clutch 2 (PFCCL2)..... Controlling the paper conveying section.

(1-3) Paper feeder (PF-5140)**Figure 3-42**


1. PF main PWB (PFMPWB) Controlling the electric parts in the PF.
2. PF paper sensor (PFPS)..... Detecting presence of paper in the paper deck.
3. PF paper gauge sensor 1 (PFPGS1).... Detecting the level of the remaining paper inside the deck.
4. PF paper gauge sensor 2 (PFPGS2).... Detecting the level of the remaining paper inside the deck.
5. PF deck detection switch (PFDDSW) ... Detecting the PF deck installation.
6. PF lift sensor (PFLS)..... Detecting the upper limit when lifting the bottom plate inside the deck.
7. PF feed sensor (PFFS)..... Detecting the paper conveying after deck feed.
8. PF right cover switch (PFRCSW)..... Detecting the right cover open.
9. PF paper feed motor (PFPFM) Driving the paper feeding system.
10. PF lift motor (PFLM)..... Operating the bottom plate inside the deck.
11. PF paper feed clutch (PFFCL) Controlling the primary paper feeding from the deck.
12. PF conveying clutch(PFCCL)..... Controlling the paper conveying.

(1-4) Document processor (DP-5100) : for 35/40 ppm model only**Figure 3-43**


- | | |
|--|---|
| 1. DP main PWB (DPMPWB) | Consisting of the engine PWB and relay circuit for the DP electric parts. |
| 2. DP original sensor (DPOS) | Detecting the presence of the original in the document processor. |
| 3. DP feed sensor (DPFS) | Detects the primary feed timing of the document processor. |
| 4. DP registration sensor (DPRS) | Detecting the timing to convey the original in the document processor. |
| 5. DP feedshift sensor (DPSBS) | Detecting the position of the feedshift guide in the document processor. |
| 6. DP open/close sensor (DPOCS) | Detecting the opening and closing of the document processor. |
| 7. DP original length sensor (DPOLS) | Detecting the original length in the document processor. |
| 8. DP original width sensor (DPOWS) | Detecting the original width in the document processor. |
| 9. DP feed motor (DPFM) | Driving the original feed section in the document processor. |
| 10. DP conveying motor (DPCM) | Driving the original conveying section in the document processor. |
| 11. DP feedshift motor (DPFSM) | Driving the original feed section in the document processor. |

(1-5) Document processor (DP-5110) : for 35/40 ppm model only**Figure 3-44**

- | | |
|--|--|
| 1. DP main PWB (DPMPWB) | Consisting of the engine PWB and relay circuit for the DP electric parts. |
| 2. DP original sensor (DPOS) | Detecting the presence of the original in the document processor. |
| 3. DP feed sensor (DPFS) | Detects the primary feed timing of the document processor. |
| 4. DP timing sensor (DPTS)..... | Detecting the timing to scan the original in the document processor. (Front page) |
| 5. DP eject sensor (DPES) | Detecting the document processor eject paper. |
| 6. DPCIS unit (DPCIS)..... | Scanning the backside original data. |
| 7. DPCIS sensor (DPCISS) | Detecting the original scanning timing. (Back page) |
| 8. DP top cover switch (DPTCSW) | Shutting off the 24V power supply line when the top cover is opened. Interlock switch. |
| 9. DP original length sensor (DPOLS) | Detecting the original length in the document processor. |
| 10. DP original width sensor (DPOWS) | Detecting the original width in the document processor. |
| 11. DP open/close sensor (DPOCS) | Detecting the opening and closing of the document processor. |
| 12. DP feed motor (DPFM) | Driving the original feed section in the document processor. |
| 13. DP conveying motor (DPCM)..... | Driving the original conveying section in the document processor. |
| 14. DP feed clutch (DPFCL) | Controlling drive of the original feed section in the document processor. |
| 15. DP SHD PWB (DPSPWB) | Processing the scanned image data. |
| 16. DP relay PWB (DPRPWB) | Relaying the scanned image data. |

(1-6) Attachment kit (AK-5100)**Figure 3-45**

- 1. BR main PWB (BRMPWB) Controlling the electric parts in the BR.
- 2. BR conveying sensor 1 (BRCS1)..... Detecting paper conveyed in the bridge.
- 3. BR conveying sensor 2 (BRCS2)..... Detecting paper conveyed in the bridge.
- 4. BR cover open/close switch
(BRCOCSW)..... Detecting the bridge cover open.
- 5. BR conveying motor (BRCM)..... Controlling the paper conveying to the bridge.
- 6. BR fan motor (BRFM) Cooling the paper conveyed in the bridge.

(1-7) Inner finisher (DF-5100)**Figure 3-46**

1. DF main PWB (DFMPWB)..... Controlling the electric parts.
2. DF staple relay PWB (DFSTPWB)..... Relaying the staple unit control signals.
3. DF paper entry sensor (DFPES)..... Detecting presence of paper at the paper entry section.
4. DF eject paper sensor (DFMTS)..... Detecting presence of paper the eject section.
5. DF side registration sensor 1
(DFSRS1) Detecting the adjusting plate front home position.
6. DF side registration sensor 2
(DFSRS2) Detecting the adjusting plate rear home position.
7. DF adjusting sensor (DFADS)..... Detecting the paper guides home position.
8. DF bundle eject sensor (DFBDS) Detecting the bundle eject unit position.
9. DF paddle sensor (DFPDS) Detecting the paddle home position.
10. DF tray sensor (DFTS)..... Detecting the eject tray lower limit.
11. DF slide sensor (DFSLS) Detecting the staple unit slide position.
12. DF middle motor (DFMM) Driving the middle roller.
13. DF paddle motor (DFPDM) Driving the paper guides.
14. DF eject release motor (DFERM) Driving the bundle eject unit.
15. DF side registration motor 1
(DFS RM1)..... Driving the adjusting plate front.
16. DF side registration motor 2
(DFS RM2)..... Driving the adjusting plate rear.
17. DF eject motor (DFEM)..... Driving the DF eject roller.

18. DF tray motor (DFTM)..... Ascending and descending the eject tray.
19. DF slide motor (DFSLM) Driving the staple unit.
20. DF staple unit (DFSTP)..... Paper stapler.
21. DF paper press sensor 1 (DFPPS1) Detecting the bundle eject paper pressure. (Upper limit)
22. DF paper press sensor 2 (DFPPS2) Detecting the bundle eject paper pressure. (Lower limit)
23. DF paper press solenoid (DFPPSOL)... Switching the bundle paper pressure.
24. DF setting switch (DFSSW) Detecting the DF setting. (Interlock detection)

(1-8) Document finisher (DF-5110) : for 35/40ppm models only




Figure 3-47

1. DF main PWB (DFMPWB)..... Controlling the electric parts.
2. DF staple relay PWB (DFSTPWB)..... Relaying the staple unit control signals.
3. DF paper entry sensor (DFPES)..... Detecting presence of paper at the paper entry section.
4. DF middle sensor (DFMES)..... Detecting presence of paper in the conveying section.
5. DF eject paper sensor (DFMTS)..... Detecting presence of paper the eject section.
6. DF side registration sensor 1
(DFSR1) Detecting the adjusting plate front home position.
7. DF side registration sensor 2
(DFSR2) Detecting the adjusting plate rear home position.
8. DF adjusting sensor (DFADS)..... Detecting the paper guides home position.
9. DF bundle eject sensor (DFBDS) Detecting the bundle eject unit position.
10. DF paddle sensor (DFPDS) Detecting the paddle home position.
11. DF tray sensor 1 (DFTS1)..... Detecting the eject tray home position.
12. DF tray sensor 2 (DFTS2)..... Detecting the eject tray middle position.
13. DF tray sensor 3 (DFTS3)..... Detecting the eject tray lower limit.
14. DF slide sensor (DFSL) Detecting the staple unit slide position.
15. DF tray upper surface sensor 1
(DFTUSS1) Detecting the DF main tray paper upper surface.
16. DF tray upper surface sensor 2
(DFTUSS2) Detecting the DF main tray paper upper surface.
17. DF top cover switch (DFTCSW)..... Detecting the DF top cover open/close.
18. DF front cover switch (DFFCSW) Detecting the DF front cover open/close.
19. DF paper entry motor (DFPEM)..... Driving the entry roller.
20. DF middle motor (DFMM) Driving the middle roller.
21. DF paddle motor (DFPDM) Driving the paper guides.
22. DF eject release motor (DFERM) Driving the bundle eject unit.
23. DF side registration motor 1
(DFSRM1)..... Driving the adjusting plate front.
24. DF side registration motor 2
(DFSRM2)..... Driving the adjusting plate rear.
25. DF eject motor (DFEM)..... Driving the DF eject roller.
26. DF tray motor (DFTM)..... Ascending and descending the eject tray.
27. DF slide motor (DFSLM) Driving the staple unit.
28. DF staple unit (DFSTP)..... Paper stapler.

(1-9) Document finisher (DF-5120) : for 35/40ppm models only




Figure 3-48

1. DF main PWB (DFMPWB)..... Controlling the electric parts.
2. DF staple relay PWB (DFSTPWB)..... Relaying the staple unit control signals.
3. DF paper entry sensor (DFPES)..... Detecting presence of paper at the paper entry section.
4. DF middle sensor (DFMES)..... Detecting presence of paper in the conveying section.
5. DF eject paper sensor (DFMTS)..... Detecting presence of paper the eject section.
6. DF side registration sensor 1
(DFSR1) Detecting the adjusting plate front home position.
7. DF side registration sensor 2
(DFSR2) Detecting the adjusting plate rear home position.
8. DF adjusting sensor (DFADS)..... Detecting the paper guides home position.
9. DF bundle eject sensor (DFBDS) Detecting the bundle eject unit position.
10. DF paddle sensor (DFPDS) Detecting the paddle home position.
11. DF tray sensor 1 (DFTS1)..... Detecting the eject tray home position.
12. DF tray sensor 2 (DFTS2)..... Detecting the eject tray middle position.
13. DF tray sensor 3 (DFTS3)..... Detecting the eject tray lower limit.
14. DF slide sensor (DFSLS) Detecting the staple unit slide position.
15. DF tray upper surface sensor 1
(DFTUSS1) Detecting the DF main tray paper upper surface.
16. DF tray upper surface sensor 2
(DFTUSS2) Detecting the DF main tray paper upper surface.
17. DF sub eject sensor (DFSES)..... Detecting paper ejected to the DF sub tray left.
18. DF front cover switch (DFFCSW) Detecting the DF front cover open/close.
19. DF front cover switch (DFFCSW) Detecting the DF eject cover open/close.
20. DF paper entry motor (DFPEM)..... Driving the entry roller.
21. DF middle motor (DFMM) Driving the middle roller.
22. DF paddle motor (DFPDM) Driving the paper guides.
23. DF eject release motor (DFERM) Driving the bundle eject unit.
24. DF side registration motor 1
(DFSRM1)..... Driving the adjusting plate front.
25. DF side registration motor 2
(DFSRM2)..... Driving the adjusting plate rear.
26. DF eject motor (DFEM)..... Driving the DF eject roller.
27. DF tray motor (DFTM)..... Ascending and descending the eject tray.
28. DF slide motor (DFSLM) Driving the staple unit.
29. DF eject clutch (DFECL) Driving the eject roller.
30. DF Feedshift solenoid (DFSSOL) Operates the feedshift guide.
31. DF operation PWB (DFOPPWB) Consisting of LEDs and keys.
32. DF staple unit (DFSTP)..... Paper stapler.

(1-10) Mailbox (MT-5100)





Figure 3-49

1. Mailbox main PWB (MBPWB)..... Controlling electric parts of the mailbox.
2. Tray overflow sensor 1
(TOFSW1)..... Detecting overflow of paper ejected to the sub tray 1.
3. Tray overflow sensor 2
(TOFSW2)..... Detecting overflow of paper ejected to the sub tray 2.
4. Tray overflow sensor 3
(TOFSW3)..... Detecting overflow of paper ejected to the sub tray 3.
5. Tray overflow sensor 4
(TOFSW4)..... Detecting overflow of paper ejected to the sub tray 4.
6. Tray overflow sensor 5
(TOFSW5)..... Detecting overflow of paper ejected to the sub tray 5.
7. Tray overflow sensor 6
(TOFSW6)..... Detecting overflow of paper ejected to the main tray 6.
8. Tray eject sensor 1 (photo receptor)
(TEJS1)..... Detecting paper jam.
9. Tray eject sensor 2 (photo emitter)
(TEJS2)..... Emitting LED pulses.
10. Mail home position switch
(MHPSW)..... Controlling the mailbox drive motor.
11. Mailbox cover open/close switch
(MCOSW) Detecting the mailbox cover open/close.
12. Mailbox drive motor
(MBDM)..... Driving the mailbox paper conveying.

(1-11) Punch unit (PH-5100/5110)**Figure 3-50**

- | | |
|--|---|
| 1. Punch main PWB (PUMPWB) | Controlling the electric parts of the punch unit. |
| 2. Punch home position sensor (PUHPS) | Detecting the punch cam home position. |
| 3. Punch pulse sensor (PUPS) | Controlling the punch cam rotation. |
| 4. Punch slide sensor (PUSLS) | Detecting the punch unit home position. |
| 5. Punch dust tank full sensor 1 (PUTFS1)..... | Detecting the punch dust tank full. |
| 6. Punch dust tank full sensor 2 (PUTFS2)..... | Detecting the punch dust tank full. |
| 7. Punch paper edge sensor 1 (PUPES1) | Detecting the paper edge. |
| 8. Punch paper edge sensor 2 (PUPES2) | Detecting the paper edge. |
| 9. Punch dust tank switch (PUTSSW) | Detecting the presence of the punch dust tank. |
| 10. Punch motor (PUM) | Driving the punch unit. |

- 11. Punch slide motor (PUSLM) Driving the punch unit.
- 12. Punch solenoid (PUSOL)..... Switching the punch holes. (Except 100 V model)
- 13. Punch conveying switch solenoid (PUCSSOL) Switching the paper entry guide.

(1-12) Job separator (JS-5100)




Figure 3-51

- 1. JS eject paper sensor (JSEPS) Detecting presence of the job tray paper.

3-7 Drive system

(1) Drive system for the paper conveying




Figure 3-52

Feed/developing (Black) drive

1. Developer motor (BK) : (DLPM-BK)
2. Paper feed roller
3. MP paper feed roller
4. DU conveying roller
5. registration roller
6. Developer sleeve roller (Black)

Drum (Black) drive

7. Drum motor (BK) : (DRM-BK)
8. Drum (Black)

Drum (color) drive

9. Drum motor (M/C/Y) : (DRM-M/C/Y)
10. Drum (Magenta)
11. Drum (Cyan)
12. Drum (Yellow)

Developer (Color) drive

13. Developer motor (M/C/Y) : (DLPM-M/C/Y)
14. Developer sleeve roller (Magenta)
15. Developer sleeve roller (Cyan)
16. Developer sleeve roller (Yellow)

Imaging/transfer drive


17. Transfer motor : (TCM)
18. Transfer belt drive roller

Fuser drive

19. Fuser motor : (FUM)
20. Heat roller

Eject drive

21. Eject motor : (EM)

(2) Drive location**Figure 3-53****Feed drive unit**

1. Developer motor (BK)
2. Paper feed clutch
3. Middle clutch
4. Duplex clutch
5. Registration clutch
6. Developer clutch

Main drive unit

7. Drum motor (BK)
8. Drum motor (M/C/Y)
9. Developer motor (M/C/Y)

Toner supply drive unit

10. Toner motor (BK)
11. Toner motor (M)
12. Toner motor (C)
13. Toner motor (Y)

14. Transfer motor

15. Fuser motor

(3) Drive unit

(3-1) Feed drive unit




Figure 3-54

(3-2) Main drive unit



Figure 3-55

(3-3) Toner supply drive unit




Figure 3-56

3-8 Mechanical construction

(1) Paper feed and conveying section

The paper feed and conveying section consists of the cassette paper feed section and the MP tray paper feed section, and the paper conveying section conveying the fed paper to the transfer and separate section.

(1-1) Cassette paper feed section

The cassette can load 550 sheets paper (64 g/m²) or 500 sheets paper (80 g/m²). The cassette forwards paper by rotating the pickup roller and conveys it to the paper conveying section by rotating the paper feed roller. Multi-feeding is also prevented by the operation of the retard roller.

[Components parts]

1. Paper feed roller
2. Pickup roller
3. Pickup holder
4. Retard roller
5. Retard holder
6. Friction pad
7. Cassette bottom plate
8. Paper width guides
9. Paper length guide
10. Cassette base
11. Width guide release lever




Figure 3-57




Figure 3-58

[Block diagram]
(30 ppm model)




Figure 3-59

(35/40 ppm models)




Figure 3-60

(1-2) MP tray paper feed section

The MP tray can load 100 sheets paper (80 g/m²). The paper on the MP tray is fed by rotating the MP paper feed roller while lifting up the MP bottom plate by the MP solenoid. Multi-feeding is also prevented by the effect of the MP separation pad.

(30 ppm model)

[Components parts]

1. MP paper feed roller
2. MP separation pad
3. MP bottom plate
4. MP tray
5. MP frame
6. MP paper width guides
7. Paper stopper
8. Actuator
(MP paper sensor)
9. Sub tray




Figure 3-61




Figure 3-62

[Block diagram]




Figure 3-63

(35/40 ppm models)

[Components parts]

- 1. MP paper feed roller
- 2. MP separation pad
- 3. MP bottom plate
- 4. MP tray
- 5. MP frame
- 6. MP paper width guides
- 7. Paper stopper
- 8. Actuator
(MP paper sensor)
- 9. Sub tray
- 10. Actuator
(MP paper length sensor)




Figure 3-64




Figure 3-65

[Block diagram]




Figure 3-66

(1-3) Paper conveying section

The paper conveying section conveys paper to the transfer and separation section when the paper is fed from the cassette or the MP tray, or re-fed in the duplex print. The fed paper is conveyed to where it turns the registration sensor on by the middle roller or the MP conveying roller, and then, conveyed to the transfer and separation section by the registration front and rear rollers.

[Components parts]

1. Middle roller
2. Middle pulley
3. Registration guide
4. Registration sensor
5. Registration roller left
6. Registration roller right
7. Conveying guide




Figure 3-67




Figure 3-68

[Block diagram]
(30 ppm model)




Figure 3-69

(35/40 ppm models)




Figure 3-70

(2) Optical section

The optical section consists of the image scanner section for scanning the original and the laser scanner section to write the image.

(2-1) Image scanner section

The image on the original is exposed by the exposure lamp and that reflection light is scanned by the CCD image sensor on the CCD PWB via three mirrors and the ISU lens to change the electric signal.

When using the document processor, the image scanner unit stops at the original scanning position (slit glass) and scans the image from the original conveyed in the document processor.

[Components parts]

1. CCD
2. Scanner carriage
3. ISU frame
4. Contact glass
5. Original size indicator
6. Slit glass
7. ISU lens
8. Mirror
9. Reflector
10. Exposure lamp
11. ISU shaft
12. Drive belt




Figure 3-71




Figure 3-72

[Block diagram]
(30 ppm model)




Figure 3-73

(35/40 ppm models)




Figure 3-74

(2-2) Laser scanner unit

The charged drum surface is scanned by the laser emitted from the laser scanner units. The laser reflects to the polygon mirrors (PM) by rotating the polygon motor so that the laser scans horizontally to the image. The laser scanner unit has some lenses and mirrors, that adjust the diameter of the laser to focus the laser to the drum surface. Also, the LSU cleaning motor operates to automatically clean the LSU glass.

[Components parts]

- 1. Polygon motor (PM)
- 2. fθ lens A
- 3. fθ lens B
- 4. LSU glass
- 5. LSU base
- 6. LSU cover
- 7. Mirror
- 8. Cylindrical lens
- 9. Laser emitting diode
- 10. Collimator lens
- 11. Slit glass plate
- 12. PD PWB
- 13. PD lens
- 14. PD mirror




Figure 3-75




Figure 3-76

[Block diagram]
(30 ppm model)




Figure 3-77

(35/40 ppm models)




Figure 3-78

(3) Developer section

(3-1) Developer unit

The developer section consists of the magnet roller forming the magnetic brush, the sleeve roller forming the thin layer by replacing the toner, the developer blade, and the developer screw mixing up the toner. The toner density is adjusted by impressing the bias to the magnet roller and the sleeve roller. The toner amount inside the developer unit is detected by the toner sensor (TS).

(30 ppm model)

[Components parts]

1. Sleeve roller
2. Magnet roller
3. Developer blade
4. Developer screw A
5. Developer screw B
6. Developer case
7. Toner sensor




Figure 3-79




Figure 3-80

(35/40 ppm models)

[Components parts]

1. Sleeve roller
2. Magnet roller
3. Developer blade
4. Developer screw A
5. Developer screw B
6. Developer case
7. Toner sensor




Figure 3-81




Figure 3-82

[Block diagram]
(30 ppm model)




Figure 3-83

(35/40 ppm models)




Figure 3-84

(4) Drum section

The drum section consists of the drum, the charger roller unit, and the cleaning unit. The drum surface is evenly charged to prepare forming the electrical latent image by emitting the laser.

(4-1) Charger roller unit

The charged roller with the electric charge contacts the drum surface and rotates to charge the drum evenly.

[Components parts]

1. Charger roller
2. Charger cleaning roller
3. Charger case
4. Drum




Figure 3-85




Figure 3-86

**[Block diagram]
(30 ppm model)**




Figure 3-87

(35/40 ppm models)




Figure 3-88

(4-2) Cleaning

The remaining toner on the drum surface after transferring is removed by the cleaning blade, and collected to the waste toner box by the drum screw. The cleaning lamp consists of the LED lamp, and it removes the remaining electric charge on the drum before the main charge.

(30/35 ppm models)

[Components parts]

1. Cleaning blade
2. Drum screw
3. Drum frame
4. Cleaning lamp
5. Drum




Figure 3-89




Figure 3-90

[Block diagram]
(30 ppm model)




Figure 3-91

(40 ppm model)

[Components parts]

- 1. Cleaning blade
- 2. Cleaning roller
- 3. Layer thickness roller
- 4. Drum screw
- 5. Drum frame
- 6. Cleaning lamp
- 7. Drum




Figure 3-92




Figure 3-93

[Block diagram]
(35/40 ppm models)




Figure 3-94

(5) Transfer and separation section

(5-1) Primary transfer unit

The primary transfer section consists of the transfer cleaning unit, the transfer belt and four primary transfer rollers facing each drum. When printing the color image, the toner image with a single color formed on each drum is repeatedly transferred on the transfer belt by impressing the bias to the primary transfer rollers facing each drum, and then the full color toner image is formed. Also, the ID sensor attached to the main unit measures the toner density on the transfer belt.

The transfer cleaning unit collects the remaining toner on the transfer belt after the secondary transferring, and forwards it to the waste toner box as waste toner.

[Components parts]

1. Drive roller
2. Pickup roller
3. Primary transfer roller
4. Tension roller
5. Transfer belt
6. ID sensor
7. Cleaning pre-brush
8. Cleaning fur brush
9. Cleaning roller
10. Cleaning blade
11. Cleaning screw
12. Drum
13. Skew prevention belt




Figure 3-95




Figure 3-96

[Block diagram]
(30 ppm model)




Figure 3-97

(35 ppm model)




Figure 3-98

(40 ppm model)




Figure 3-99

(5-2) Secondary transfer unit

The secondary transfer roller section consists of the secondary transfer roller attached to the paper conveying unit, and the separation brush. The DC bias from the high-voltage PWB (HVPWB) is impressed to the secondary transfer roller, and the toner image formed on the transfer belt is transferred to the paper by the potential gap. After transferring, the paper is separated by self stripping and the electric charge on the paper is removed by the separation brush contacting the ground.

[Components parts]

1. Secondary transfer roller
2. Separation brush
3. Secondary transfer section
4. Transfer front guide
5. Transfer spring




Figure 3-100




Figure 3-101

[Block diagram]
(30 ppm model)




Figure 3-102

(35 ppm model)




Figure 3-103

(40 ppm model)




Figure 3-104

(6) Fuser section

The paper from the transfer and separation section is pinched between the heat roller and the press roller. The heat roller is heated by the fuser heater (FUH), and the paper is pressed by the press roller with the pressure added by the pressure spring toward the heat roller, so toner is fused on the paper by that heat and pressure.

The surface temperature of the heat roller is detected by the fuser thermistor (FTH1,2) and controlled by the Engine PWB (EPWB). If the fuser section has abnormal temperature, the power supply line is shut off by switching the fuser thermostat (FUTS) and the fuser heater (FUH) is turned off forcibly.

(6-1) Fuser unit

[Components parts]

1. Heat roller
2. Fuser heater
3. Fuser thermostat
4. Fuser thermistor 1
5. Fuser thermistor 2
6. Press roller
7. Separator
8. Actuator
(Eject sensor)
9. Fuser eject roller
10. Fuser eject pulley
11. Fuser front guide




Figure 3-105




Figure 3-106

[Block diagram]
(30 ppm model)




Figure 3-107

(35/40 ppm models)




Figure 3-108

(7) Eject and feedshift section

The eject and feedshift section consists of the paper path from the fuser section to the inner tray or the duplex conveying section.

(7-1) Eject unit

[Components parts]

1. Upper eject roller
2. Upper eject pulley
3. Lower eject roller
4. Lower eject pulley
5. Eject conveying roller
6. Eject conveying pulley
7. Conveying pulley
8. Actuator
10. Eraser brush
(Eject paper full sensor)
9. Feedshift guide




Figure 3-109




Figure 3-110

**[Block diagram]
(30 ppm model)**




Figure 3-111

(35/40 ppm models)




Figure 3-112

(7-2) Eject paper jam

If paper ejected is caught up by the paper previously ejected, extend the length of the eject actuator.

1. If the leading edge (b) of the paper ejected is caught up by the trailing edge (a) paper previously ejected, slide the position of the eject actuator sub guide (c) to extend it.
2. Pushes down the trailing edge (a) of eject paper to prevent the (b) leading edge of next paper from being caught up.




Figure 3-113



Figure 3-114

(8) Duplex conveying section

(8-1) Duplex conveying unit

The duplex conveying section consists of the paper conveying path to forward the paper from the eject and feedshift section in the duplex print to the paper conveying section.

[Components parts]

1. DU conveying roller
2. DU conveying pulley
3. Actuator
Duplex sensor
4. DU conveying base
5. DU conveying guide




Figure 3-115




Figure 3-116

[Block diagram]
(30 ppm model)




Figure 3-117

(35/40 ppm models)




Figure 3-118

(9) Document processor : for 30 ppm model only**(9-1) Original paper feed section**

The original feed section consists of the parts in the figure, and conveys the original on the original tray to the original conveying section. The original is fed by rotating the DP forwarding pulley and the DP feed roller.

[Components parts]

1. DP forwarding pulley
2. DP feed roller
3. DP feed holder
4. DP separation pad
5. Front separation pad
6. Friction pad
7. Actuator
(DP original sensor)
8. DP original stopper
9. DP original width guide
10. Original tray
11. Actuator
DP paper feed sensor
12. Conveying pulley




Figure 3-119




Figure 3-120

[Block diagram]




Figure 3-121

(9-2) Original conveying section and Original switchback and eject section

The original conveying section consists of the parts in the figure. The conveyed original is scanned at the optical section (CCD) in the main unit when passing the DP slit glass.

The original switchback and eject section consists of the parts in the figure. The original already scanned is ejected to the original eject table by the eject roller. When scanning the original in the duplex switchback mode, the original is conveyed to the switchback tray once and then reconveyed to the original conveying section by the switchback roller.

[Components parts]

1. Actuator
(DP registration sensor)
2. DP registration roller
3. DP registration pulley
4. Scanner guide
5. DP conveying roller
6. DP conveying pulley
7. Feedshift guide
8. Switchback roller
9. Retard pulley
10. DP eject roller
11. DP eject pulley
12. Reversing guide
13. Eject tray




Figure 3-122




Figure 3-123

[Block diagram]






Figure 3-124

(9-3) Reversing duplex scanning


The first side of original is scanned at the slit glass (machine main body).




The first side of original is scanned at the slit glass (machine main body).



The original is reversed by the switchback roller.



The second side of original is scanned at the slit glass (machine main body) and the original is conveyed to the switchback tray.



Ejected to the original eject tray by the feedshift and eject rollers.




Figure 3-125

3-9 Mechanical construction (option)

(1) Paper feeder (PF-5120)

(1-1) Cassette paper feed section

The cassette can load 550 sheets paper (64 g/m²) or 500 sheets paper (80 g/m²). Paper from the cassette is picked up by rotating the pickup roller and is conveyed to the main unit by rotating the paper feed roller. Multi-feeding is also prevented by the effect of the retard roller.

[Components parts]

1. PF paper feed roller
2. PF pickup roller
3. PF pickup holder
4. PF retard roller
5. PF retard holder
6. PF friction pad
7. PF cassette bottom plate
8. PF paper width guides
9. PF paper length guide
10. PF cassette base
11. PF width guide release lever
12. PF feed roller
13. PF feed pulley
14. PF actuator
(PF paper sensor)




Figure 3-126




Figure 3-127

[Block diagram]




Figure 3-128

(2) Paper feeder (PF-5130)

(2-1) Cassette paper feed section

The cassette can load 550 sheets paper (64 g/m²) or 500 sheets paper (80 g/m²) and consists of 2 cassettes. Paper from the cassette is picked up by rotating the pickup roller and is conveyed to the main unit by rotating the paper feed roller. Multi-feeding is also prevented by the effect of the retard roller.




Figure 3-129

[Components parts]

- | | |
|--|--|
| 1. PF paper feed roller 1 | 15. PF paper feed roller 2 |
| 2. PF Pickup roller 1 | 16. PF Pickup roller 2 |
| 3. PF Pickup holder 1 | 17. PF Pickup holder 2 |
| 4. PF retard roller 1 | 18. PF retard roller 2 |
| 5. PF retard holder 1 | 19. PF retard holder 2 |
| 6. PF friction pad 1 | 20. PF friction pad 2 |
| 7. PF cassette bottom plate 1 | 21. PF cassette bottom plate 2 |
| 8. PF paper width guides 1 | 22. PF paper width guides 2 |
| 9. PF paper length guide 1 | 23. PF paper length guide 2 |
| 10. PF cassette base 1 | 24. PF cassette base 2 |
| 11. PF width guide release lever 1 | 25. PF width guide release lever 2 |
| 12. PF feed roller 2 | 26. PF feed roller 3 |
| 13. PF feed pulley 2 | 27. PF feed pulley 3 |
| 14. PF actuator 1 (PF paper sensor 1) | 28. PF actuator 2 (PF paper sensor 2) |




Figure 3-130

[Block diagram]




Figure 3-131


(3) Paper feeder (PF-5140)

(3-1) Paper deck section

The deck can load 2200 sheets paper (64 g/m²) or 2000 sheets paper (80 g/m²). Paper from the deck is picked up by rotating the pickup roller and is conveyed to the main unit by rotating the paper feed roller. Multi-feeding is also prevented by the operation of the retard roller.

[Components parts]

1. PF paper feed roller
2. PF pickup roller
3. PF pickup holder
4. PF retard roller
5. PF retard holder
6. PF friction pad
7. PF deck bottom plate
8. PF paper width guides
9. Paper length guide*1
10. PF feed roller
11. PF feed pulley
12. PF actuator
(PF paper sensor)
13. Right cover



*1: inch specification only

Figure 3-132




Figure 3-133

[Block diagram]




Figure 3-134

(4) Document processor (DP-5100) : for 35/40 ppm model only

(4-1) Original paper feed section

The original feed section consists of the parts in the figure, and conveys the original on the original tray to the original conveying section. The original is fed by rotating the DP forwarding pulley and the DP feed roller.

[Components parts]

1. DP forwarding pulley
2. DP feed roller
3. DP feed holder
4. DP separation pad
5. Front separation pad
6. Friction pad
7. Actuator
(DP original sensor)
8. DP original stopper
9. DP original width guide
10. Original tray
11. Actuator
DP paper feed sensor
12. Conveying pulley
13. Actuator
(DP original length sensor)




Figure 3-135




Figure 3-136

[Block diagram]




Figure 3-137

(4-2) Original conveying section and Original switchback and eject section

The original conveying section consists of the parts in the figure. The conveyed original is scanned at the optical section (CCD) in the main unit when passing the DP slit glass.

The original switchback and eject section consists of the parts in the figure. The original already scanned is ejected to the original eject table by the eject roller. When scanning the original in the duplex switchback mode, the original is conveyed to the switchback tray once and then reconveyed to the original conveying section by the switchback roller.

[Components parts]

1. Actuator
(DP registration sensor)
2. DP registration roller
3. DP registration pulley
4. Scanner guide
5. DP conveying roller
6. DP conveying pulley
7. Feedshift guide
8. Switchback roller
9. Retard pulley
10. DP eject roller
11. DP eject pulley
12. Reversing guide
13. Eject tray




Figure 3-138




Figure 3-139

[Block diagram]






Figure 3-140

(4-3) Reversing duplex scanning


The first side of original is scanned at the slit glass (machine main body).




The first side of original is scanned at the slit glass (machine main body).



The original is reversed by the switchback roller.



The second side of original is scanned at the slit glass (machine main body) and the original is conveyed to the switchback tray.



Ejected to the original eject tray by the feedshift and eject rollers.




Figure 3-141

(5) Document processor (DP-5100) : for 35/40 ppm model only

(5-1) Original paper feed section

The original feed section consists of the parts in the figure, and conveys the original on the original tray to the original conveying section. The original is fed by rotating the DP forwarding pulley and the DP feed roller.

[Components parts]

1. DP forwarding pulley
2. DP feed roller
3. DP feed holder
4. DP separation pad
5. Front separation pad
6. Friction pad
7. Actuator
(DP original sensor)
8. DP original stopper
9. DP original width guide
10. Original tray
11. DP paper feed sensor
12. Conveying pulley
13. Feed shaft guide plate
14. Actuator
(DP original length sensor)




Figure 3-142




Figure 3-143

[Block diagram]




Figure 3-144

(5-2) Original conveying section and Original switchback and eject section

The original conveying section consists of the parts in the figure. The 2nd side of the conveyed original is scanned when passing the CIS and the 1st side at the optical section (CCD) in the main unit when passing the DP slit glass. The original already scanned is ejected to the original eject table by the eject roller.

[Components parts]

1. DP registration roller
2. DP registration pulley
3. DPCIS sensor
4. CIS
5. DPCIS roller
6. DP conveying roller A
7. DP conveying pulley
8. DP timing sensor
9. DP conveying roller B
10. DP conveying pulley
11. Scanner guide pulley
12. Scanner guide
13. DP conveying roller C
14. DP conveying pulley
15. Actuator
(DP Eject sensor)
16. DP eject roller
17. DP eject pulley
18. Eject tray
19. Slit glass (main unit)




Figure 3-145




Figure 3-146

[Block diagram]




Figure 3-147

(6) Inner finisher (DF-5100)

(6-1) Paper conveying section

The conveying section consists of the parts as shown below. Paper on the middle tray is transferred after adjusting the side registration by moving the DF side registration guides in the staple and sort modes.

[Components parts]

1. DF entry roller
2. DF entry pulley
3. DF Middle roller
4. DF Middle pulley
5. DF Actuator
(DF entry sensor)
6. DF paper stopper
7. DF adjusting paddles
8. DF upper guide
9. DF paper width guides
10. DF bundle eject unit
11. DF eject roller
12. DF eject pulley
13. DF Actuator
(Paper press sensor)
14. DF stapler
15. DF middle tray




Figure 3-148




Figure 3-149

[Block diagram]




Figure 3-150

(6-2) Bundle eject operation

1st sheet

1. By rotating the DF entry roller and DF middle roller, paper is conveyed to the process section and then conveyed to the DF main tray by the DF eject roller.




Figure 3-151

2. The DF upper guide descends when the paper trailing edge passes the DF middle roller. Then, the DF eject roller is rotated reversely and paper is sent to the DF middle tray.




Figure 3-152

3. Then, the DF upper guide ascends and the DF bundle eject unit ascends by the DF eject release motor drive. By rotating the DF eject roller and DF adjusting paddles, paper is conveyed to the DF middle tray. The DF side registration motor 1,2 drive the DF side registration guides to adjust paper.






Figure 3-153

2nd sheet and after


4. Paper is sent to the process section as well as the 1st sheet.

**Figure 3-154**

5. The DF upper guide descends when the paper trailing edge passes the DF middle roller. Then, by rotating the DF adjusting paddles, paper is conveyed to the DF middle tray. Paper is adjusted as well as the 1st sheet.

**Figure 3-155**

6. When completing to adjust the last sheet to bundle, the DF bundle eject unit descends and by rotating the DF eject roller, the paper bundle is ejected to the DF main tray.

**Figure 3-156**

(7) Document finisher (DF-5110) : for 35/40ppm models only

(7-1) Paper conveying section

The conveying section consists of the parts as shown below. Paper on the middle tray is transferred after adjusting the side registration by moving the DF side registration guides in the staple and sort modes.

[Components parts]

1. DF entry roller
2. DF entry pulley
3. DF Middle roller
4. DF Middle pulley
5. DF Actuator
(DF middle sensor)
6. DF paper stopper
7. DF paper width guides
8. DF bundle eject unit
9. DF eject roller
10. DF eject pulley
11. DF stapler
12. DF middle tray
13. DF paddle




Figure 3-157




Figure 3-158

[Block diagram]




Figure 3-159

(7-2) Bundle eject operation

1st sheet

1. By rotating the DF entry roller and DF middle roller, paper is conveyed to the process section and then conveyed to the DF main tray by the DF eject roller.




Figure 3-160

2. The DF conveying guide descends when the paper trailing edge passes the DF middle roller. Then, the DF eject roller is rotated reversely and paper is sent to the DF middle tray.




Figure 3-161

3. Then, the DF conveying guide ascends and the DF bundle eject unit ascends by the DF eject release motor drive. By rotating the DF eject roller and DF adjusting paddles, paper is conveyed to the DF middle tray. The DF side registration motor 1,2 drive the DF side registration guides to adjust paper.






Figure 3-162

2nd sheet and after


4. Paper is sent to the process section as well as the 1st sheet.

**Figure 3-163**

5. The DF conveying guide descends when the paper trailing edge passes the DF middle roller. Then, by rotating the DF paddles and the DF adjusting paddles, paper is conveyed to the DF middle tray. Paper is adjusted as well as the 1st sheet.

**Figure 3-164**

6. When completing to adjust the last sheet to bundle, the DF bundle eject unit descends and by rotating the DF eject roller, the paper bundle is ejected to the DF main tray.

**Figure 3-165**

(8) Document finisher (DF-5120) : for 35/40ppm models only

(8-1) Sub tray conveying section

The conveying section consists of the parts as shown below. Paper on the middle tray is transferred after adjusting the side registration by moving the DF side registration guides in the staple and sort modes.

[Components parts]

1. DF entry roller
2. DF entry pulley
3. Feedshift guide
4. DF conveying roller
5. DF conveying pulley
6. DF sub eject roller
7. DF sub eject pulley
8. DF Actuator
(DF sub eject sensor)




Figure 3-166




Figure 3-167

[Block diagram]




Figure 3-168

(8-2) Main tray conveying section

The conveying section consists of the parts as shown below. Paper on the middle tray is transferred after adjusting the side registration by moving the DF side registration guides in the staple and sort modes.

[Components parts]

1. DF Middle roller
2. DF Middle pulley
3. DF Actuator
(DF middle sensor)
4. DF paper width guides
5. DF bundle eject unit
6. DF main eject roller
7. DF main eject pulley
8. DF stapler
9. DF middle tray
10. DF paddle
11. DF adjusting paddles




Figure 3-169




Figure 3-170

[Block diagram]




Figure 3-171

(8-3) Bundle eject operation

1st sheet

1. By rotating the DF middle roller, paper is conveyed to the process section and then conveyed to the DF main tray by the DF eject roller.




Figure 3-172

2. The DF conveying guide descends when the paper trailing edge passes the DF middle roller. Then, the DF eject roller is rotated reversely and paper is sent to the DF middle tray.




Figure 3-173

3. Then, the DF conveying guide ascends and the DF bundle eject unit ascends by the DF eject release motor drive. By rotating the DF eject roller and DF adjusting paddles, paper is conveyed to the DF middle tray. The DF side registration motor 1,2 drive the DF side registration guides to adjust paper.






Figure 3-174

2nd sheet and after


4. Paper is sent to the process section as well as the 1st sheet.

**Figure 3-175**

5. The DF conveying guide descends when the paper trailing edge passes the DF middle roller. Then, by rotating the DF paddles and the DF adjusting paddles, paper is conveyed to the DF middle tray. Paper is adjusted as well as the 1st sheet.

**Figure 3-176**

6. When completing to adjust the last sheet to bundle, the bundle eject unit descends and by rotating the main tray eject roller, the paper bundle is ejected to the DF main tray.

**Figure 3-177**

(9) Mailbox (MT-5100)

The mailbox ejects paper to the tray 1 to 6 designated to stack

[Components parts]

- 1. MB entry guide
- 2. MB Feedshift guide
- 3. MB Eject roller M
- 4. MB Eject pulley M
- 5. MB Actuator
(MB overflow sensor M)
- 6. MB conveying roller
- 7. MB conveying pulley
- 8. MB Feedshift guide S
- 9. MB eject roller S
- 10. MB eject pulley S
- 11. MB Actuator
(MB overflow sensor S)
- 12. MB Main tray
- 13. MB Sub tray




Figure 3-178




Figure 3-179

[Block diagram]




Figure 3-180

(9-1) Ejecting to the mailbox tray

If the belt support plate moving on the belt passes the feedshift nail lever, the feedshift nail is switches the conveying path to eject to each tray. Also, the tray eject sensor detects paper jam.




Figure 3-181

(10) Punch unit (PH-5110)

The punch unit is installed at the paper entry section of the document finisher and paper entered there is stopped to make punch holes.

[Components parts]

1. Punch cam
2. Punch cutter
3. Punch dust tank
4. Cutter holder
5. Cam shaft
6. Pulse plate




Figure 3-182




Figure 3-183

[Block diagram]




Figure 3-184

This page is intentionally left blank.

4 Maintenance

4-1 Precautions for the maintenance

(1) Precautions

Before disassembling the main unit, press the main power switch to turn the power off. Make sure that the power lamp on the operation panel is off and unplug the power cord from the wall outlet. Then, start the disassembly.

When handling the PWBs (printed wiring boards), do not touch parts with bare hands. Make sure not to damage the PWB.

If ICs are mounted on the PWB, do not touch them by hand or something charged with electrostatic.

Make sure to release the hook before disconnecting the connector with the hook.

Take care not to pinch up the wire and cable.

Use the original screws when reassembling the parts once disassembled.

If the types and the sizes of screws are not sure, refer to the parts list.

*: Due to the structure of the 30 ppm model, the operation panel is lit for a moment when the power cord is plugged in.

(2) Storage and handling of the drum

Note the following when handling and storing the drum.

When detaching the drum unit, never expose the drum surface to strong direct light.

Store in the range of ambient temperature of -20 to 40 degree C(-4°F to 104°F) and ambient humidity of 85% RH or less. Wait more than 5 seconds between the power off and on. Avoid storing the drum unit in the place where the temperature and humidity may suddenly change even if these changes are within the tolerable range.

Avoid exposure to any substance which is harmful or may affect the quality of the drum.

Do not touch the drum surface with any object.

Make sure not to touch the drum surface with bare hands or gloves.

If the drum is touched by hands or stained with oil, clean it.

(3) Storage of the toner container

Store the toner container in a cool, dark place.

Do not place the toner container under direct sunshine or in a damp environment.

(4) Screening of the toner container

Look at the screening film on the brand protection seal affixed to the toner container through the windows of the validation viewer.

Look at the screening film through two windows to check the genuineness.

A black-colored band when seen through the the anti-counterfeit film portion left side window (● marking).

A shiny or gold-colored band when seen through the anti-counterfeit film portion right side window (☀ marking).

(☀ mark).

When seen as the above, it is genuine. Otherwise (e.g. both seen in gold), it is a counterfeit.




Figure 4-1

The brand protection seal has an incision as shown below to prohibit reuse.




Figure 4-2

4-2 Maintenance parts

(1) Maintenance kits

(1-1) 30 ppm models

| Maintenance part name | | Part No. | Alternative parts No. |
|--|--|--------------------------|-----------------------|
| Name used in service manual | Name used in parts list | | |
| MK-5195A MK-5197A (200,000 images) | MK-5195A/MAINTENANCE KIT MK-5197A/MAINTENANCE KIT ROLLER RETARD ASSY DRUM UNIT DLP K UNIT FUSER ASSY MIDDLE TRANSFER UNIT 2ND TRANS ASSY SP HOLDER PICK UP ASSY SP | 1702R48NL0 1702R47US1 | 072R48NL 072R47US |
| MK-5195B (200,000 images) | MK-5195B/MAINTENANCE KIT DRUM UNIT DLP M UNIT DLP C UNIT DLP Y UNIT | 1702R40UN0 | 072R40UN |

(1-2) 35 ppm models

| Maintenance part name | | Part No. | Alternative parts No. |
|--|--|--|----------------------------------|
| Name used in service manual | Name used in parts list | | |
| MK-5205A MK-5206A MK-5207A (200,000 images) | MK-5205A/MAINTENANCE KIT MK-5206A/MAINTENANCE KIT MK-5207A/MAINTENANCE KIT ROLLER RETARD ASSY DRUM UNIT DLP K UNIT FUSER ASSY MIDDLE TRANSFER UNIT 2ND TRANS ASSY SP HOLDER PICK UP ASSY SP | 1702R58NL0 1702R59JP1 1702R57US1 | 072R58NL 072R59JP 072R57US |
| MK-5205B (200,000 images) | MK-5205B/MAINTENANCE KIT DRUM UNIT DLP M UNIT DLP C UNIT DLP Y UNIT | 1702R50UN0 | 072R50UN |

(1-3) 40 ppm models

| Maintenance part name | | Part No. | Alternative parts No. |
|--|--|--|----------------------------------|
| Name used in service manual | Name used in parts list | | |
| MK-5215A MK-5216A MK-5217A (300,000 images) | MK-5215A/MAINTENANCE KIT MK-5216A/MAINTENANCE KIT MK-5217A/MAINTENANCE KIT ROLLER RETARD ASSY DRUM UNIT DLP K UNIT FUSER ASSY MIDDLE TRANSFER UNIT 2ND TRANS ASSY SP HOLDER PICK UP ASSY SP | 1702R68NL0 1702R69JP1 1702R67US1 | 072R68NL 072R69JP 072R67US |
| MK-5215B (300,000 images) | MK-5215B/MAINTENANCE KIT DRUM UNIT DLP M UNIT DLP C UNIT DLP Y UNIT | 1702R60UN0 | 072R60UN |

(2) Maintenance kit for the document processor**(2-1) 30 ppm model standard DP/DP-5100: 35/40 ppm models**

| Maintenance part name | | Part No. | Alternative parts No. |
|-----------------------------|--|------------|-----------------------|
| Name used in service manual | Name used in parts list | | |
| MK-3140 (200,000 Sheets) | MK-3140/MAINTENANCE KIT DP PAD ASSY DP PULLEY ASSY | 1702P60UN0 | 072P60UN |

(2-2) DP-5110:35/40 ppm models only

| Maintenance part name | | Part No. | Alternative parts No. |
|-----------------------------|---|------------|-----------------------|
| Name used in service manual | Name used in parts list | | |
| MK-5200 (200,000 Sheets) | MK-5200/MAINTENANCE KIT HOLDER PICUP ASSY HOLDER PAD ASSY | 1703R40UN0 | 073R40UN |

(3) Executing the maintenance mode after replacing the maintenance kit

Execute the following maintenance modes after replacing the above maintenance kit.

| Section | Mode No. | Maintenance item | MK-5***A | MK-5***B |
|------------------------------|----------|--|---------------------|---------------------|
| Replac- ing set- tings | U119 | Drum unit initial settings | ○ | ○ |
| | U930 | Checking/clearing the main charger roller counts | ○ | ○ |
| | U140 | Developer bias adjustment (AC Calib/Calibration) | ○ ^{*1} | ○ ^{*1} |
| | U469 | Color registration adjustment | ○ | × |
| | U127 | Checking/clearing the transfer counts | ○ | × |
| | U167 | Checking/clearing the fuser counts | ○ | × |
| | U251 | Checking/clearing the maintenance counts | ○ | × |
| Image adjust- ment | U464 | ID correction operation setting (Calib) | ○ | ○ |
| | U469 | Color registration adjustment (Auto) | ○ | ○ |
| | U411 | Adjusting the uneven density (Normal Mode) | ○ ^{*1, *2} | ○ ^{*1, *2} |
| | U464 | ID correction operation setting (Calib) | ○ ^{*2} | ○ ^{*2} |
| | U410 | Adjusting the halftone automatically | ○ | ○ |
| Mainte- nance | U251 | Checking/clearing the maintenance counts | ○ | ○ |

*1: 40 ppm model only

*2: at the time of drum replacement only

(4) Periodic maintenance Procedures

Check the maintenance counts by the maintenance mode U901.

(4-1) Main body (30 ppm model)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | | Remark |
|------------|------------------------------|-------------------------------|-----------|----------|----------|----------|---|
| | | Set UP | User Call | 200 | 400 | | |
| | | | | | | | Please do not use spray containing flammable gas for air-blow or air-brush purposes. |
| A | <Set Up> | | | | | | |
| 1 | TONER (CARTRIDGE) | --- | | | | | |
| 2 | WASTE TONER BOX WT-5190 | --- | | | | | |
| 3 | IMAGE QUALITY | --- | CH AD | CH AD | CH AD | CH AD | |
| 4 | MK-5195A | 1702R48NL0 072R48NL | | | RE | RE | BK DRUM UNIT, TRANSFER UNIT, BK DLP UNIT, FUSER UNIT 2ND TRANS ASSY SP, HOLDER PICK UP ASSY SP, RETARD ROLLER ASSY |
| 5 | MK-5197A | 1702R47US1 072R47US | | | RE | RE | |
| 6 | MK-5195B | 1702R40UN0 072R40UN | | | RE | RE | CMY DRUM UNIT, CMY DLP UNIT |
| 7 | INSIDE OF MACHINE | --- | | CL | CL | CL | VACUUM: Remove toner and paper dust especially at the paper conveying part and around the image formation part. |
| B | <Cover> | | | | | | |
| 1 | OUTER COVERS | --- | CH | | CL | CL | Alcohol or dry cloth |
| C | <PF and Conveying section> | | | | | | |
| 1 | PARTS CLEANER REGIST ASSY SP | 302R494120 | | CL | CL | CL | VACUUM: Remove paper dust. |
| 2 | PARTS PRIMARY FEED ASSY SP | 302R494210 2R494210 | | CL | | | Alcohol or dry cloth |
| 3 | PARTS HOLDER PICK UP ASSY SP | 302R494170 2R494170 | | CL | | | Alcohol or dry cloth |
| 4 | RETARD ROLLER ASSY | 302F909171 2F909171 | | CL | | | Alcohol or dry cloth |
| 5 | PARTS ROLLER MPF ASSY SP | 302MV94020 | | CL | CH RE | CH RE | Alcohol or dry cloth if no replacement. CH:Performing U901 and check feeding count: Target to replace at 100K. |
| 6 | PARTS HOLDER SEPARATION SP | 302R494180 | | CL | CH RE | CH RE | Alcohol or dry cloth if no replacement. CH:Performing U901 and check feeding count: Target to replace at 100K. |

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | | Remark |
|------------|-----------------------------------|-------------------------------|-----------|----------|----------|----------|--|
| | | Set UP | User Call | 200 | 400 | | |
| 7 | ROLLERS ,PULLEYS | --- | | CL | CL | CL | Alcohol or dry cloth |
| 8 | GUIDES | --- | | CL | CL | CL | Alcohol or dry cloth |
| D | <Exit and Duplex Section> | | | | | | |
| 1 | ROLLERS ,PULLEYS | --- | | CL | CL | CL | Alcohol or dry cloth |
| 2 | GUIDES | --- | | | CL | CL | Alcohol or dry cloth |
| E | <Image scanner section> | | | | | | |
| 1 | CONTACT GLASS CONTACT GLASS DP | 302H917031 302H917040 | CL CL | CL CL | CL CL | CL CL | Slit glass for DP: Clean by dry cloth or alcohol. (attention: wet cloth is strictly prohibited.) When inatalling DP,clean with dry cloth. Contact glass for putting the original on: Dry cloth after cleaning with alcohol (FACE SIDE) Wipe the back side with dry cloth after cleaning with alcohol only when unusual image (line or stain) appears. (BACK SIDE) |
| F | <Drive and other section> | | | | | | |
| 1 | CLUTCHS | --- | | CH RE | CH | CH | Check the copy registration and paper feed condition on registration and paper feed section. |
| 2 | SENSORS | --- | | CH | CH | CH | Dry cloth or airblow if light reception part of photo sensor is dirt or paper dust. |

(4-2)Main body (35 ppm model)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | | Remark |
|------------|------------------------------|-------------------------------|-----------|----------|----------|----------|---|
| | | Set UP | User Call | 200 | 400 | | |
| | | | | | | | Please do not use spray containing flammable gas for air-blow or air-brush purposes. |
| A | <Set Up> | | | | | | |
| 1 | TONER (CARTRIDGE) | --- | | | | | |
| 2 | WASTE TONER BOX WT-5190 | --- | | | | | |
| 3 | IMAGE QUALITY | --- | CH AD | CH AD | CH AD | CH AD | |
| 4 | MK-5205A | 1702R58NL0 072R58NL | | | RE | RE | BK DRUM UNIT, TRANSFER UNIT, BK DLP UNIT, FUSER UNIT 2ND TRANS ASSY SP, HOLDER PICK UP ASSY SP, RETARD ROLLER ASSY |
| 5 | MK-5206A | 1702R59JP1 072R59JP | | | RE | RE | |
| 6 | MK-5207A | 1702R57US1 072R57US | | | RE | RE | |
| 7 | MK-5205B | 1702R50UN0 072R50UN | | | RE | RE | CMY DRUM UNIT,CMY DLP UNIT |
| 8 | INSIDE OF MACHINE | --- | | CL | CL | CL | VACUUM: Remove toner and paper dust especially at the paper conveying part and around the image formation part. |
| B | <Cover> | | | | | | |
| 1 | OUTER COVERS | --- | CH | | CL | CL | Alcohol or dry cloth |
| C | <PF and Conveying section> | | | | | | |
| 1 | PARTS CLEANER REGIST ASSY SP | 302R494120 | | CL | CL | CL | VACUUM: Remove paper dust. |
| 2 | PARTS PRIMARY FEED ASSY SP | 302R494210 2R494210 | | CL | | | Alcohol or dry cloth |
| 3 | PARTS HOLDER PICK UP ASSY SP | 302R494170 2R494170 | | CL | | | Alcohol or dry cloth |
| 4 | RETARD ROLLER ASSY | 302F909171 2F909171 | | CL | | | Alcohol or dry cloth |
| 5 | PARTS ROLLER MPF ASSY SP | 302MV94020 | | CL | CH RE | CH RE | Alcohol or dry cloth if no replacement. CH:Performing U901 and check feeding count: Target to replace at 100K. |
| 6 | PARTS HOLDER SEPARATION SP | 302R494180 | | CL | CH RE | CH RE | Alcohol or dry cloth if no replacement. CH:Performing U901 and check feeding count: Target to replace at 100K. |
| 7 | ROLLERS ,PULLEYS | --- | | CL | CL | CL | Alcohol or dry cloth |

| Parts name | | Parts No. | PM maintenance (x1000 counts) | | | | Remark |
|------------|-----------------------------------|--------------------------|-------------------------------|-----------|----------|----------|---|
| | | | Set UP | User Call | 200 | 400 | |
| 8 | GUIDES | --- | | CL | CL | CL | Alcohol or dry cloth |
| D | <Exit and Duplex Section> | | | | | | |
| 1 | ROLLERS ,PULLEYS | --- | | CL | CL | CL | Alcohol or dry cloth |
| 2 | GUIDES | --- | | | CL | CL | Alcohol or dry cloth |
| E | <Image scanner section> | | | | | | |
| 1 | CONTACT GLASS CONTACT GLASS DP | 302H917031 302H917040 | CL CL | CL CL | CL CL | CL CL | Slit glass for DP: Clean by dry cloth or alcohol. (attention: wet cloth is strictly prohibited.) When inatalling DP, clean with dry cloth. Contact glass for putting the original on: Dry cloth after cleaning with alcohol (FACE SIDE) Wipe the back side with dry cloth after cleaning with alcohol only when unusual image (line or stain) appears. (BACK SIDE) |
| F | <Drive and other section> | | | | | | |
| 1 | CLUTCHS | --- | | CH RE | CH | CH | Check the copy registration and paper feed condition on registration and paper feed section. |
| 2 | SENSORS | --- | | CH | CH | CH | Dry cloth or airblow if light reception part of photo sensor is dirt or paper dust. |

(4-3)Main body (40 ppm model)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | | Remark |
|------------|------------------------------|-------------------------------|-----------|----------|----------|----------|---|
| | | Set UP | User Call | 300 | 600 | | |
| | | | | | | | Please do not use spray containing flammable gas for air-blow or air-brush purposes. |
| A | <Set Up> | | | | | | |
| 1 | TONER (CARTRIDGE) | --- | | | | | |
| 2 | WASTE TONER BOX WT-5191 | --- | | | | | |
| 3 | IMAGE QUALITY | --- | CH AD | CH AD | CH AD | CH AD | |
| 4 | MK-5215A | 1702R68NL0 072R68NL | | | RE | RE | BK DRUM UNIT, TRANSFER UNIT, BK DLP UNIT, FUSER UNIT 2ND TRANS ASSY SP, HOLDER PICK UP ASSY SP, RETARD ROLLER ASSY |
| 5 | MK-5216A | 1702R69JP1 072R69JP | | | RE | RE | |
| 6 | MK-5217A | 1702R67US1 072R67US | | | RE | RE | |
| 7 | MK-5215B | 1702R60UN0 072R60UN | | | RE | RE | CMY DRUM UNIT,CMY DLP UNIT |
| 8 | INSIDE OF MACHINE | --- | | CL | CL | CL | VACUUM: Remove toner and paper dust especially at the paper conveying part and around the image formation part. |
| B | <Cover> | | | | | | |
| 1 | OUTER COVERS | --- | CH | | CL | CL | Alcohol or dry cloth |
| C | <PF and Conveying section> | | | | | | |
| 1 | PARTS CLEANER REGIST ASSY SP | 302R494120 | | CL | CL | CL | VACUUM: Remove paper dust. |
| 2 | PARTS PRIMARY FEED ASSY SP | 302R494210 2R494210 | | CL | | | Alcohol or dry cloth |
| 3 | PARTS HOLDER PICK UP ASSY SP | 302R494170 2R494170 | | CL | | | Alcohol or dry cloth |
| 4 | RETARD ROLLER ASSY | 302F909171 2F909171 | | CL | | | Alcohol or dry cloth |
| 5 | PARTS ROLLER MPF ASSY SP | 302MV94020 | | CL | CH RE | CH RE | Alcohol or dry cloth if no replacement. CH:Performing U901 and check feeding count: Target to replace at 100K. |
| 6 | PARTS HOLDER SEPARATION SP | 302R494180 | | CL | CH RE | CH RE | Alcohol or dry cloth if no replacement. CH:Performing U901 and check feeding count: Target to replace at 100K. |
| 7 | ROLLERS ,PULLEYS | --- | | CL | CL | CL | Alcohol or dry cloth |

| Parts name | | Parts No. | PM maintenance (x1000 counts) | | | | Remark |
|------------|-----------------------------------|--------------------------|-------------------------------|-----------|----------|----------|---|
| | | | Set UP | User Call | 300 | 600 | |
| 8 | GUIDES | --- | | CL | CL | CL | Alcohol or dry cloth |
| D | <Exit and Duplex Section> | | | | | | |
| 1 | ROLLERS ,PULLEYS | --- | | CL | CL | CL | Alcohol or dry cloth |
| 2 | GUIDES | --- | | | CL | CL | Alcohol or dry cloth |
| E | <Image scanner section> | | | | | | |
| 1 | CONTACT GLASS CONTACT GLASS DP | 302H917031 302H917040 | CL CL | CL CL | CL CL | CL CL | Slit glass for DP: Clean by dry cloth or alcohol. (attention: wet cloth is strictly prohibited.) When inatalling DP, clean with dry cloth. Contact glass for putting the original on: Dry cloth after cleaning with alcohol (FACE SIDE) Wipe the back side with dry cloth after cleaning with alcohol only when unusual image (line or stain) appears. (BACK SIDE) |
| F | <Drive and other section> | | | | | | |
| 1 | CLUTCHS | --- | | CH RE | CH | CH | Check the copy registration and paper feed condition on registration and paper feed section. |
| 2 | SENSORS | --- | | CH | CH | CH | Dry cloth or airblow if light reception part of photo sensor is dirt or paper dust. |

(4-4)Standard DP (30 ppm model)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | | Remark |
|--|-----------------------------------|-------------------------------|-----------|----------|----------|----------|--|
| | | Set UP | User Call | 200 | 400 | | |
| Please do not use spray containing flammable gas for air-blow or air-brush purposes. | | | | | | | |
| A | <Set Up> | | | | | | |
| 1 | IMAGE QUALITY | --- | CH AD | CH AD | CH AD | CH AD | |
| B | <Cover> | | | | | | |
| 1 | OUTER COVERS | --- | | CL | CL | CL | CL:Alcohol |
| C | <PF and Conveying section> | | | | | | |
| 1 | MK-3140 | 1702P60UN0 072P60UN | | | RE | RE | HOLDER PICKUP ASSY, HOLDER PAD ASSY |
| 2 | PARTS HOLDER PICKUP ASSY SP | 303R394020 3R394020 | | CL | | | CL:Alcohol (If necessary, replace the MK-3140) |
| 3 | PARTS HOLDER PAD ASSY SP | 303R394030 3R394030 | | CL | | | CL:Alcohol (If necessary, replace the MK-3140) |
| D | <Conveying and Reversing section> | | | | | | |
| 1 | PARTS ROLLER CONVEYING A SP | 303R394060 3R394060 | | CL | CL | CL | Alcohol or dry cloth |
| 2 | PULLEY CONVEYING x5 | 3V2NM18240 2NM18240 | | CL | CL | CL | Alcohol or dry cloth |
| 3 | PULLEY GUIDE READING x4 | 303LL24190 3LL24190 | | CL | CL | CL | Alcohol or dry cloth |
| 4 | PARTS ROLLER LOOP SP | 303R394090 3R394090 | | CL | CL | CL | Alcohol or dry cloth |
| 5 | PULLEY CONVEYING BK x5 | 303M824210 3M824210 | | CL | CL | CL | Alcohol or dry cloth |
| 6 | GUIDE READING | 3V2NM18520 2NM18520 | | CL | CL | CL | Alcohol or dry cloth |
| E | <Other section> | | | | | | |
| 1 | PLATE ORIGINAL | 302H918021 2H918021 | | CL | CL | CL | Alcohol or dry cloth |
| 2 | CONTACT GLASS DP | 302H917040 2H917040 | | CL | CL | CL | Slit glass for DP (Main body side) Alcohol or dry cloth (wet cloth is strictly prohibited.)?? |

(4-5)DP-5100 (Option)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | | Remark |
|------------|-----------------------------------|-------------------------------|-----------|----------|----------|----------|--|
| | | Set UP | User Call | 200 | 400 | | |
| | | | | | | | Please do not use spray containing flammable gas for air-blow or air-brush purposes. |
| A | <Set Up> | | | | | | |
| 1 | IMAGE QUALITY | --- | CH AD | CH AD | CH AD | CH AD | |
| B | <Cover> | | | | | | |
| 1 | OUTER COVERS | --- | | CL | CL | CL | CL:Alcohol |
| C | <PF and Conveying section> | | | | | | |
| 1 | MK-3140 | 1702P60UN0 072P60UN | | | RE | RE | HOLDER PICKUP ASSY, HOLDER PAD ASSY |
| 2 | PARTS HOLDER PICKUP ASSY SP | 303R394020 3R394020 | | CL | | | CL:Alcohol (If necessary, replace the MK-3140) |
| 3 | PARTS HOLDER PAD ASSY SP | 303R394030 3R394030 | | CL | | | CL:Alcohol (If necessary, replace the MK-3140) |
| D | <Conveying and Reversing section> | | | | | | |
| 1 | PARTS ROLLER CONVEYING A SP | 303R394060 3R394060 | | CL | CL | CL | Alcohol or dry cloth |
| 2 | PULLEY CONVEYING x5 | 3V2NM18240 2NM18240 | | CL | CL | CL | Alcohol or dry cloth |
| 3 | PULLEY GUIDE READING x4 | 303LL24190 3LL24190 | | CL | CL | CL | Alcohol or dry cloth |
| 4 | PARTS ROLLER LOOP SP | 303R394090 3R394090 | | CL | CL | CL | Alcohol or dry cloth |
| 5 | PULLEY CONVEYING BK x5 | 303M824210 3M824210 | | CL | CL | CL | Alcohol or dry cloth |
| 6 | GUIDE READING | 3V2NM18520 2NM18520 | | CL | CL | CL | Alcohol or dry cloth |
| E | <Other section> | | | | | | |
| 1 | PLATE ORIGINAL | 302H918021 2H918021 | | CL | CL | CL | Alcohol or dry cloth |
| 2 | CONTACT?GLASS?DP | 302H917040 2H917040 | | CL | CL | CL | Slit glass for DP (Main body side) Alcohol or dry cloth (wet cloth is strictly prohibited.) |

(4-6)DP-5110 (Option)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | | Remark |
|------------|-----------------------------------|-------------------------------|-----------|----------|----------|----------|--|
| | | Set UP | User Call | 200 | 400 | | |
| | | | | | | | Please do not use spray containing flammable gas for air-blow or air-brush purposes. |
| A | <Set Up> | | | | | | |
| 1 | IMAGE QUALITY | --- | CH AD | CH AD | CH AD | CH AD | |
| B | <Cover> | | | | | | |
| 1 | OUTER COVERS | --- | | CL | CL | CL | CL:Alcohol |
| C | <PF and Conveying section> | | | | | | |
| 1 | MK-5200 | 1703R40UN0 073R40UN | | | RE | RE | HOLDER PICKUP ASSY, HOLDER PAD ASSY |
| 2 | PARTS HOLDER PICUP ASSY SP | 303R494010 3R494010 | | CL | | | CL:Alcohol (If necessary, replace the MK-5200) |
| 3 | PARTS HOLDER PAD ASSY SP | 303R394030 3R394030 | | CL | | | CL:Alcohol (If necessary, replace the MK-5200) |
| 4 | PULLEY GUIDE READING | 303LL24190 3LL24190 | | CL | CL | CL | Alcohol or dry cloth |
| 5 | SENSOR OPT. | 7NXPS122GD4A H01 | | CL | CL | CL | CL:Airbrush or dry cloth (Front of the resist) |
| D | <Conveying and Reversing section> | | | | | | |
| 1 | PARTS ROLLER REGIST SP | 303R494090 3R494090 | | CL | CL | CL | CL:Alcohol |
| 2 | PARTS ROLLER CONVEYING CIS SP | 303R494100 3R494100 | | CL | CL | CL | CL:Alcohol |
| 3 | PULLEY REGISTRATION BK x6 | 303M824220 3M824220 | | CL | CL | CL | Alcohol or dry cloth |
| 4 | PARTS ROLLER CIS SP | 303R494060 3R494060 | | CL | CL | CL | Alcohol or dry cloth |
| 5 | GLASS CIS | 303R424120 3R424120 | | CL | CL | CL | Alcohol or dry cloth (wet cloth is strictly prohibited.) |
| 6 | PULLEY CONVEYING BK x6 | 303M824210 3M824210 | | CL | CL | CL | Alcohol or dry cloth |
| 7 | PULLEY GUIDE READING x3 | 303LL24190 3LL24190 | | CL | CL | CL | Alcohol or dry cloth |
| 8 | GUIDE READING | 303R424220 3R424220 | | CL | CL | CL | Alcohol or dry cloth |

| Parts name | | Parts No. | PM maintenance (x1000 counts) | | | | Remark |
|------------|------------------|------------------------|-------------------------------|-----------|-----|-----|--|
| | | | Set UP | User Call | 200 | 400 | |
| 9 | SENSOR OPT. | 7NXPS124GD1+ H01 | | CL | CL | CL | CL:Airbrush ordry cloth (Front of the CIS) |
| E | <Other section> | | | | | | |
| 1 | PLATE ORIGINAL | 302H918021 2H918021 | | CL | CL | CL | Alcohol or dry cloth |
| 2 | CONTACT?GLASS?DP | 302H917040 2H917040 | | CL | CL | CL | Slit glass for DP (Main body side) Alcohol or dry cloth (wet cloth is strictly prohibited.) |

(4-7)PF-5120 (Option)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | Remark |
|--|------------------------------|-------------------------------|-----------|-------------------------------|----------|---|
| | | Set UP | User Call | Based on cycle of the machine | | |
| Please do not use spray containing flammable gas for air-blow or air-brush purposes. | | | | | | |
| A | <Set Up> | | | | | |
| 1 | PAPER LINE | --- | CH AD | | | CH:check the center alignment gap. (check after center adjustment of copier) |
| B | <Cover> | | | | | |
| 1 | OUTER COVERS | --- | | CL | CL | Alcohol or dry cloth |
| C | <PF Section> | | | | | |
| 1 | PARTS PRIMARY FEED ASSY SP | 302R494210 2R494210 | | CL | | Alcohol or dry cloth |
| 2 | PARTS HOLDER PICK UP ASSY SP | 302R494170 2R494170 | | CL | CH RE | Alcohol or dry cloth if no replacement. CH:Performing U901 and check feeding count: Target to replace at 300K. |
| 3 | RETARD ROLLER ASSY | 302F909171 2F909171 | | CL | CH RE | Alcohol or dry cloth if no replacement. CH:Performing U901 and check feeding count: Target to replace at 300K. |
| D | <Conveying Section> | | | | | |
| 1 | PARTS ROLLER CONVEYING VF SP | 303PS94050 3PS94050 | | CL | CL | Alcohol or dry cloth |
| F | <Drive and other section> | | | | | |
| ? | SENSORS | --- | | CL | CL | Dry cloth or airblow if light reception part of photo sensor is dirt or paper dust. |

(4-8)PF-5130 (Option)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | Remark |
|--|------------------------------------|-------------------------------|-----------|-------------------------------|----------|---|
| | | Set UP | User Call | Based on cycle of the machine | | |
| Please do not use spray containing flammable gas for air-blow or air-brush purposes. | | | | | | |
| A | <Set Up> | | | | | |
| 1 | PAPER LINE | --- | CH AD | | | CH:check the center alignment gap. (check after center adjustment of copier) |
| B | <Cover> | | | | | |
| 1 | OUTER COVERS | --- | | CL | CL | Alcohol or dry cloth |
| C | <PF Section> | | | | | |
| 1 | PARTS PRIMARY FEED ASSY SP x2 | 302R494210 2R494210 | | CL | | Alcohol or dry cloth |
| 2 | PARTS HOLDER PICK UP ASSY SP x2 | 302R494170 2R494170 | | CL | CH RE | Alcohol or dry cloth if no replacement. CH:Performing U901 and check feeding count: Target to replace at 300K. |
| 3 | RETARD ROLLER ASSY x2 | 302F909171 2F909171 | | CL | CH RE | Alcohol or dry cloth if no replacement. CH:Performing U901 and check feeding count: Target to replace at 300K. |
| D | <Conveying Section> | | | | | |
| 1 | PARTS ROLLER CONVEYING VF SP x2 | 303PS94050 3PS94050 | | CL | CL | Alcohol or dry cloth |
| F | <Drive and other section> | | | | | |
| ? | SENSORS | --- | | CL | CL | Dry cloth or airblow if light reception part of photo sensor is dirt or paper dust. |

(4-9)PF-5140 (Option)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | Remark |
|--|------------------------------|-------------------------------|-----------|-------------------------------|----------|---|
| | | Set UP | User Call | Based on cycle of the machine | | |
| Please do not use spray containing flammable gas for air-blow or air-brush purposes. | | | | | | |
| A | <Set Up> | | | | | |
| 1 | PAPER LINE | --- | CH AD | | | CH:check the center alignment gap. (check after center adjustment of copier) |
| B | <Cover> | | | | | |
| 1 | OUTER COVERS | --- | | CL | CL | Alcohol or dry cloth |
| C | <PF Section> | | | | | |
| 1 | PARTS PRIMARY FEED ASSY SP | 302R494210 2R494210 | | CL | | Alcohol or dry cloth |
| 2 | PARTS HOLDER PICK UP ASSY SP | 302R494170 2R494170 | | CL | CH RE | Alcohol or dry cloth if no replacement. CH:Performing U901 and check feeding count: Target to replace at 300K. |
| 3 | RETARD ROLLER ASSY | 302F909171 2F909171 | | CL | CH RE | Alcohol or dry cloth if no replacement. CH:Performing U901 and check feeding count: Target to replace at 300K. |
| D | <Conveying Section> | | | | | |
| 1 | PARTS ROLLER CONVEYING VF SP | 303PS94050 3PS94050 | | CL | CL | Alcohol or dry cloth |
| F | <Drive and other section> | | | | | |
| ? | SENSORS | --- | | CL | CL | Dry cloth or airblow if light reception part of photo sensor is dirt or paper dust. |

(4-10)AK-5100 (Option)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | Remark |
|------------|---|-------------------------------|-----------|-------------------------------|--|----------------------|
| | | Set UP | User Call | Based on cycle of the machine | | |
| 1 | OUTER COVERS | | CL | CL | | Alcohol or dry cloth |
| 2 | PARTS ROLLER CONVEYING A SP 3PY94010 | | CL | CL | | Alcohol |
| 3 | PARTS ROLLER CONVEYING B SP x2 3PY94020 | | CL | CL | | Alcohol |
| 4 | PULLEY DU LOW x6 2F929260 | | CL | CL | | Alcohol |

(4-11)JS-5100 (Option)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | Remark |
|------------|---------------------------------|-------------------------------|-----------|-------------------------------|--|--------------------------|
| | | Set UP | User Call | Based on cycle of the machine | | |
| 1 | OUTER COVERS | | CL | CL | | Alcohol or dry cloth |
| 2 | PARTS SENSOR OPT SP 3PX94030 | | CL | CL | | CL:Airbrush or dry cloth |

(4-12)DF-5100 (Option)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | Remark |
|--|--------------------------------------|-------------------------------|-----------|-------------------------------|----|---|
| | | Set UP | User Call | Based on cycle of the machine | | |
| Please do not use spray containing flammable gas for air-blow or air-brush purposes. | | | | | | |
| A | <Cover> | | | | | |
| 1 | OUTER COVERS, TRAY | --- | | | CL | Alcohol or dry cloth |
| B | | | | | | |
| 1 | ROLLER FEED | 303PX24030 3PX24030 | | | CL | Alcohol or dry cloth |
| 2 | PULLEY MIDDLE A x2 | 302H722760 2H722760 | | | CL | Alcohol or dry cloth |
| 3 | ROLLER MIDDLE | 303PX36680 3PX36680 | | | CL | Alcohol or dry cloth |
| 4 | PULLEY MIDDLE x2 | 303NB36661 3NB36661 | | | CL | Alcohol or dry cloth |
| 5 | PULLEY PAPER FEED x2 | 3BR07040 3BR07040 | | | CL | Alcohol or dry cloth |
| 6 | PULLEY EXIT x2 | 303RD36130 3RD36130 | | | CL | Alcohol or dry cloth |
| 7 | PULLEY EXIT ONEWAYCLUTCH x2 | 303RD36180 3RD36180 | | | CL | Alcohol or dry cloth |
| 8 | STATIC-ELIMINATOR EJECT CENTER x2 | 303NB36500 3NB36500 | | | CH | CH: Remove paper dust at the end of brush |
| C | <Sensor> | | | | | |
| 1 | SENSOR OPT | 7NXPSR11GD6 MH01 | | | CL | Airbrush |
| 2 | SENSOR OPT x6 | 7NXSG2A241++ H01 | | | CL | Airbrush |

(4-13)DF-5110 (Option)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | Remark |
|--|--------------------------------------|-------------------------------|-----------|-------------------------------|----|---|
| | | Set UP | User Call | Based on cycle of the machine | | |
| Please do not use spray containing flammable gas for air-blow or air-brush purposes. | | | | | | |
| A | <Cover> | | | | | |
| 1 | OUTER COVERS, TRAY | --- | | | CL | Alcohol or dry cloth |
| B | <PF, Conveying and exit sections> | | | | | |
| 1 | ROLLER FEED LOWER | 303PV07020 3PV07020 | | | CL | Alcohol or dry cloth |
| 2 | ROLLER FEED UPPER x2 | 303PW07050 3PW07050 | | | CL | Alcohol or dry cloth |
| 3 | ROLLER MIDDLE | 303PW36070 3PW36070 | | | CL | Alcohol or dry cloth |
| 4 | PULLEY MIDDLE x2 | 303NB36661 3NB36661 | | | CL | Alcohol or dry cloth |
| 5 | ROLLER EXIT | 303PV36010 3PV36010 | | | CL | Alcohol or dry cloth |
| 6 | PULLEY EXIT x2 | 303NB36200 3NB36200 | | | CL | Alcohol or dry cloth |
| 7 | STATIC ELIMINATOR EJECT | 63212210 63212210 | | | CH | CH: Remove paper dust at the end of brush |
| 8 | STATIC-ELIMINATOR EJECT CENTER x3 | 303NB36500 3NB36500 | | | CH | CH: Remove paper dust at the end of brush |
| C | <Sensor> | | | | | |
| 1 | SENSOR OPT x2 | 7NXPS133GD1+ H01 | | | CL | Airbrush |
| 2 | SENSOR OPT x6 | 7NXSG2A241++ H01 | | | CL | Airbrush |
| 3 | SENSOR A,SEPARATION | 303H327460 3H327460 | | | CL | Airbrush |
| 4 | SENSOR OPT | 7NXKB1281AA2 H01 | | | CL | Airbrush |

(4-14)DF-5120 (Option)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | Remark |
|--|--------------------------------------|-------------------------------|-----------|-------------------------------|----|---|
| | | Set UP | User Call | Based on cycle of the machine | | |
| Please do not use spray containing flammable gas for air-blow or air-brush purposes. | | | | | | |
| A | <Cover> | | | | | |
| 1 | OUTER COVERS, TRAY | --- | | | CL | Alcohol or dry cloth |
| B | <PF, Conveying and exit sections> | | | | | |
| 1 | ROLLER FEED LOWER | 303PW07040 3PW07040 | | | CL | Alcohol or dry cloth |
| 2 | ROLLER FEED UPPER x2 | 303PW07050 3PW07050 | | | CL | Alcohol or dry cloth |
| 3 | ROLLER MIDDLE | 303PW36070 3PW36070 | | | CL | Alcohol or dry cloth |
| 4 | PULLEY MIDDLE x4 | 303NB36661 3NB36661 | | | CL | Alcohol or dry cloth |
| 5 | ROLLER EXIT | 303PW36150 3PW36150 | | | CL | Alcohol or dry cloth |
| 6 | PULLEY EXIT x2 | 303NB36200 3NB36200 | | | CL | Alcohol or dry cloth |
| 7 | ROLLER SUB EXIT | 303PW24110 3PW24110 | | | CL | Alcohol or dry cloth |
| 8 | ROLLER SUB CONVEYING | 303PW24120 3PW24120 | | | CL | Alcohol or dry cloth |
| 9 | PULLEY SUB EJECT x2 | 303B817020 3B817020 | | | CL | Alcohol or dry cloth |
| 10 | STATIC ELIMINATOR EJECT | 63212210 63212210 | | | CH | CH: Remove paper dust at the end of brush |
| 11 | STATIC-ELIMINATOR EJECT CENTER x3 | 303NB36500 3NB36500 | | | CH | CH: Remove paper dust at the end of brush |
| 12 | STATIC-ELIMINATOR SUB EJECT | 303PW24150 3PW24150 | | | CH | CH: Remove paper dust at the end of brush |
| C | <Sensor> | | | | | |
| 1 | SENSOR OPT x2 | 7NXPS133GD1+ H01 | | | CL | Airbrush |
| 2 | SENSOR OPT x11 | 7NXSG2A241++ H01 | | | CL | Airbrush |

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | Remark |
|------------|---|-------------------------------|-----------|-------------------------------|--|----------|
| | | Set UP | User Call | Based on cycle of the machine | | |
| 3 | SENSOR A,SEPARATION 303H327460 3H327460 | | | CL | | Airbrush |
| 4 | SENSOR OPT 7NXKB1281AA2 H01 | | | CL | | Airbrush |
| 5 | PWB SENSOR A ASSY 303R101020 3R101020 | | | CL | | Airbrush |
| 6 | PWB SENSOR B ASSY 303R101030 3R101030 | | | CL | | Airbrush |
| 7 | PWB SENSOR C ASSY 303R101040 3R101040 | | | CL | | Airbrush |
| 8 | PWB SENSOR D ASSY 303R101050 3R101050 | | | CL | | Airbrush |

(4-15)PH-5100/5110/5120 (Option)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | | Remark |
|------------|---|-------------------------------|-----------|-------------------------------|--|--|
| | | Set UP | User Call | Based on cycle of the machine | | |
| C | <Sensor> | | | | | Please do not use spray containing flammable gas for air-blow or air-brush purposes. |
| 1 | SENSOR OPT 7NXSG2A241++ H01 x3 | | | CL | | Airbrush |
| 2 | PWB SENSOR A ASSY 303R101020 3R101020 | | | CL | | Airbrush |
| 3 | PWB SENSOR B ASSY 303R101030 3R101030 | | | CL | | Airbrush |
| 4 | PWB SENSOR C ASSY 303R101040 3R101040 | | | CL | | Airbrush |
| 5 | PWB SENSOR D ASSY 303R101050 3R101050 | | | CL | | Airbrush |

(4-16)MT-5100 (Option)

CH:Check / CL:Clean / AD:Adjust / LU:Lubrication / RE:Replace

| Parts name | Parts No. | PM maintenance (x1000 counts) | | | |
|-----------------------|--------------------------------|-------------------------------|-----------|-------------------------------|---|
| | | Set UP | User Call | Based on cycle of the machine | |
| A <Cover> | | | | | |
| 1 | OUTER COVERS?TRAY | | | CL | Alcohol or dry cloth |
| B <Conveying Section> | | | | | |
| 1 | ROLLER CONVEYING x2 | 303R024090 3R024090 | | CL | Alcohol or dry cloth |
| 2 | PULLEY 15 MPF FEED x4 | 302H008220 2H008220 | | CL | Alcohol or dry cloth |
| 3 | ROLLER EJECT A x5 | 303R024100 3R024100 | | CL | Alcohol or dry cloth |
| 4 | PULLEY EJECT x10 | 303LW24060 3LW24060 | | CL | Alcohol or dry cloth |
| 5 | ROLLER EJECT C | 303R024110 3R024110 | | CL | Alcohol or dry cloth |
| 6 | PULLEY EJECT x4 | 303R024140 3R024140 | | CL | Alcohol or dry cloth |
| 7 | STATIC ELIMINATOR x5 | 303LJ28040 3LJ28040 | | CH | CH: Remove paper dust at the end of brush |
| 8 | STATIC-ELIMINATOR EJECT SIDE | 303NB36490 3NB36490 | | CH | CH: Remove paper dust at the end of brush |
| 9 | STATIC-ELIMINATOR EJECT CENTER | 303NB36500 3NB36500 | | CH | CH: Remove paper dust at the end of brush |
| C <Sensor> | | | | | |
| 1 | SENSOR OPT x8 | 7NXSG2A241++ H01 | | CL | Airbrush |
| 2 | SENSOR A,SEPARATION | 303H327460 3H327460 | | CL | Airbrush |
| 3 | SENSOR OPT | 7NXKB1281AA2 H01 | | CL | Airbrush |

4-3 Maintenance parts replacement procedures

Replacement of the maintenance kit is required after 200,000 images (30/35ppm models)/about 300,000 images (40ppm model). The message [Replace MK.] appears at the replacement timing.

Execute maintenance mode U251 to reset the count after replacing the maintenance kit in the following procedures.

(1) Cassette paper feed section

(1-1) Detaching and reattaching the pickup pulley and paper feed roller

Procedures

1. Pull out the cassette (a) from the main unit (b) and remove it in the direction of the arrow.




Figure 4-1

2. Pinch the lock lever (a) and pull the primary paper feed unit (c) from the main unit (b).




Figure 4-2

- Remove the spring (b) from the primary paper feed unit (a).

IMPORTANT

- *: Check if the pressure spring (b) is securely in the protrusion (c) when reattaching it.




Figure 4-3

- Tilt up the pickup holder (b) on the primary paper feed unit and remove it from the bushing (c).





Figure 4-4

Notes when attaching

*: When attaching the primary paper feed unit (a), insert the protrusion (b) into the main unit side guide (c).

**Figure 4-5**

(1-2) Detaching and reattaching the retard pulley

Procedures

1. Turn over the primary paper feed unit (a).
2. Remove the spring (b).

IMPORTANT

*: Check if the pressure spring (b) is securely in the protrusion (c) when reattaching it.




Figure 4-6

3. Turn over the primary paper feed unit (a) again.
4. Remove the retard holder fulcrum (c) with the flat-blade screwdriver (b) and remove the retard holder (d).
5. Attach the new retard holder.
6. Attach the new pickup holder.
7. Reattach the parts in the original position.

IMPORTANT

When replacing the new pickup holder or retard holder, take care not to touch the roller surface.





Figure 4-7

Execute the following setting after replacing the feed roller.

Clearing the maintenance counts (maintenance mode U251): Clear

(1-3) Detaching and reattaching the regist cleaner


1. Open the front cover (a).

**Figure 4-8**

(for 30/35 ppm models only)

2. Hold A and B, and remove the waste toner box (a).

*: There is no waste toner duct in 30/35 ppm models.

**Figure 4-9**

(for 40 ppm model only)

2. Hold A and B, and remove the waste toner box (a).




Figure 4-10

3. Remove the screw (a)(M3x12).
4. Slide the regist cleaner (b) in the direction of the arrow and release the lock.
5. Pinch the regist cleaner (b) and pull it out.
6. Check the sponge of the regist cleaner (b) and clean or replace it.
7. Reattach the parts in the original position.




Figure 4-11

(2) MP paper feed section

(2-1) Detaching and reattaching the MP paper feed roller

Procedures

1. Open the right cover (a).
2. Pinch the holder (b) and remove the MP feed roller (c) in the direction of the arrow.




Figure 4-12

(2-2) Detaching and reattaching the MP separation pad

Procedures

1. Remove the MP separation pad (a) in the direction of the arrow.
2. Attach the new MP separation pad.
3. Attach the new MP paper feed roller.
4. Reattach the parts in the original position.

IMPORTANT

When replacing the new MP separation pad or MP paper feed roller, take care not to touch the roller surface.




Figure 4-13

Execute the following setting after replacing the MP paper feed roller.

Clearing the maintenance counts (maintenance mode U251): Clear

(3) Transfer section

(3-1) Detaching and reattaching the primary transfer unit

Procedures

1. Open the right cover (a).
2. Hold the handle (a) and pull out the primary transfer unit (c) in the direction of the arrow.
3. Check the primary transfer unit (c) and clean or replace it.
4. Reattach the parts in the original position.

IMPORTANT

When pulling out the primary transfer unit, hold the center of it on the way to avoid hitting it to the right cover (a).




Figure 4-14

Execute the following setting after replacing the primary transfer unit.

1. Checking/clearing the transfer counts (maintenance mode U127): Clear
2. ID correction operation setting (maintenance mode U464): Calib (Full)
3. Color registration adjustment (maintenance mode U469): Auto
4. Adjusting the halftone automatically (maintenance mode U410): Normal Mode

(3-2) Detaching and reattaching the secondary transfer roller unit

Procedures

1. Open the right cover (a).
2. Release the front lever hook(c) of the secondary transfer unit(b) toward you with a flat-blade screwdriver(d) and release the front lock(e) by pressing it with a flat-blade screwdriver(d).
3. Likewise, release the rear lever hook(f) and rear lock(g) with a flat-blade screwdriver(d).
4. Pull out the secondary transfer unit(b) in the direction of the arrow while rotating it toward you.
5. Check the secondary transfer unit (b) and clean or replace it.
6. Reattach the parts in the original position.




Figure 4-15

Execute the following setting after replacing the secondary transfer unit.

1. Checking/clearing the transfer counts (maintenance mode U127): Clear
2. ID correction operation setting (maintenance mode U464): Calib (Full)
3. Color registration adjustment (maintenance mode U469): Auto
4. Adjusting the halftone automatically (maintenance mode U410): Normal Mode

(4) Drum section

(4-1) Detaching and reattaching the drum unit

Procedures

1. Open the front cover (a).




Figure 4-16

(for 30/35 ppm models only)

2. Hold A and B, and remove the waste toner box (a).

*: There is no waste toner duct in 30/35 ppm models.




Figure 4-17

(for 40 ppm model only)

2. Hold A and B, and remove the waste toner box (a).




Figure 4-18

3. Push up the lock lever (a) and remove four drum units (b) (Y,C,M,K).
4. Attach the new drum units.
5. Reattach the parts in the original position.





Figure 4-19

Execute the following setting after replacing the drum unit.

1. Drum unit initial setting (maintenance mode U119): Execute (40 ppm model only)
2. Clearing the main charger roller counts (maintenance mode U930): Clear
3. Developer bias adjustment ?maintenance mode U140): AC Calibration
4. ID correction operation setting (maintenance mode U464): Calib (Full)
5. Color registration adjustment (maintenance mode U469): Auto
6. Adjusting the uneven density (maintenance mode U412): Normal Mode (40 ppm model only)
7. Adjusting the halftone automatically (maintenance mode U410): Normal Mode


IMPORTANT

1. When installing the drum unit, make sure to press the pressing part (a).

**Figure 4-20**

2. After inserting the drum unit, push the lock shaft (a) until it clicks.

*: Make sure to pull out the lock shaft (a) when inserting the drum unit. Otherwise, it causes the drum damage.

**Figure 4-21**

(4-2) Detaching and reattaching the main charge roller unit

Procedures

1. Open the front cover (a).
2. Detach the waste toner box.
3. Detach the drum unit (a).
4. Turn over the drum unit (a).
5. Push the lock lever (b).
6. Pull up the main charge roller unit (c) while pressing it and remove it from the drum unit in the direction of the arrow.
7. Check the main charge roller unit (c) and clean or replace it.
8. Reattach the parts in the original position.




Figure 4-22

IMPORTANT

1. When attaching the main charge roller unit (a), align the insert guide (b) to the guide rib (c).
2. Insert the protrusion (d) into the positioning (e) and press down A portion to check it clicks to lock.
3. Check that the spring B (f) is inserted into the spring C (g).




Figure 4-23

Execute the following setting after replacing the main charge roller.

1. Clearing the main charger roller counts (maintenance mode U930): Clear
2. Developer bias adjustment (maintenance mode U140): AC Calibration
3. ID correction operation setting (maintenance mode U464): Calib (Full)
4. Color registration adjustment (maintenance mode U469): Auto
5. Adjusting the uneven density (maintenance mode U412): Normal Mode (40 ppm model only)
6. Adjusting the halftone automatically (maintenance mode U410): Normal Mode

(5) Developer section

(5-1) Detaching and reattaching the developer unit

Procedures

1. Open the front cover (a).




Figure 4-24

(for 30/35 ppm models only)

2. Hold A and B, and remove the waste toner box (a).

*: There is no waste toner duct in 30/35 ppm models.




Figure 4-25

(for 40 ppm model only)

2. Hold A and B, and remove the waste toner box (a).




Figure 4-26

3. Push up the lock lever (a) and remove four developer units (b) (Y,C,M,K).
4. Attach the new developer units.
5. Reattach the parts in the original position.





Figure 4-27

Execute the following setting after replacing the developer unit.

1. Developer bias adjustment ?maintenance mode U140): AC Calibration (40 ppm model only)
2. ID correction operation setting (maintenance mode U464): Calib (Full)
3. Color registration adjustment (maintenance mode U469): Auto
4. Adjusting the halftone automatically (maintenance mode U410): Normal Mode


IMPORTANT

1. When installing the developer unit, securely insert it by pressing the front side pressing part (a).

**Figure 4-28**


2. After inserting the developer unit, securely push the lock shaft (a).

*: Make sure to pull out the lock shaft (a) when inserting the developer unit. Otherwise, it causes the drum damage.

**Figure 4-29**

Unpacking the maintenance kit

1. Push up the lock lever (a) and remove four developer units (c) from the unit protective cover (b).
2. Peel off two tapes (d) and pull out the protective sheet (e) straight from the developer unit (c).
3. Remove the toner supply cover (f) in the direction of the arrow.



*: Take care not to touch the lower blade, sleeve roller, etc. of the developer unit during the work.




Figure 4-30

(6) Fuser section

(6-1) Detaching and reattaching the fuser unit

Procedures

1. Open the right cover (a) of the main unit (b).




Figure 4-31

2. Remove the screw (a)(M3x8) and remove the fuser wire cover (b).
3. Disconnect two connectors (c) of the fuser unit.




Figure 4-32

4. Remove two screws (a)(M3x8) and remove the fuser unit (b).
5. Attach the new fuser unit.
6. Reattach the parts in the original position.





Figure 4-33

Execute the following setting after replacing the fuser unit.


1. Checking/clearing the fuser counts (maintenance mode U167): Clear
2. ID correction operation setting (maintenance mode U464): Calib (Full)
3. Color registration adjustment (maintenance mode U469): Auto
4. Adjusting the halftone automatically (maintenance mode U410): Normal Mode

(7) Document processor: 30 ppm model only**(7-1) Detaching and reattaching the DP pickup pulley and DP paper feed roller****Procedures**

1. Open the DP top cover (b) of the document processor (a).

**Figure 4-34**

2. Push the lock lever (a) toward the machine rear side.
3. Release the hook (b).
4. Rotate the lock lever (a) to the release position (c).
5. Shift the machine front side of the DP paper feed roller shaft (d) toward the machine left side to remove it from the holding part (e).
6. Then, lift the shaft and pull the DP paper feed roller unit (f) out toward the machine front side.

**Figure 4-35**

(7-2) Detaching and reattaching the DP separation pad

Procedures

1. Push both hooks (b) inward and remove the DP separation pad assembly (a).
2. Attach the new DP separation pad assembly.
3. Reattach the parts in the original position.

*:Check if the pressure spring (c) is securely in the protrusion (d) when reattaching it.

4. Attach the new DP paper feed roller unit.
5. Reattach the parts in the original position.




Figure 4-36

4-4 Maintenance parts replacement procedures (option)

(1) Paper feeder (PF-5120)

(1-1) Detaching and reattaching the pickup pulley and paper feed roller

Procedures

1. Pull out the cassette (a) from the paper feeder (b) and remove it in the direction of the arrow.




Figure 4-37

2. Pinch the lock lever (a) and pull the primary paper feed unit (c) from the paper feeder (b).




Figure 4-38

- Remove the spring (b) from the primary paper feed unit (a).

Notes when attaching

- *: Check if the pressure spring is securely in the protrusion (c) when reattaching it.




Figure 4-39

- Tilt up the pickup holder (b) on the primary paper feed unit and remove it from the bushing (c).





Figure 4-40

Notes when attaching

*: When attaching the primary paper feed unit (a), insert the protrusion (b) into the main unit side guide (c).

**Figure 4-41**

(1-2) Detaching and reattaching the retard pulley

Procedures

1. Turn over the primary paper feed unit (a).
2. Remove the spring (b).

Notes when attaching

- *: Check if the pressure spring is securely in the protrusion (c) when reattaching it.




Figure 4-42

3. Turn over the primary paper feed unit (a) again.
4. Remove the retard holder fulcrum (c) with the flat-blade screwdriver (b) and remove the retard holder (d).
5. Attach the new retard holder.
6. Attach the new pickup holder.
7. Reattach the parts in the original position.

IMPORTANT

When replacing the new pickup holder or retard holder, take care not to touch the roller surface.




Figure 4-43

(2) Paper feeder (PF-5130)

(2-1) Detaching and reattaching the pickup pulley and paper feed roller

Procedures

1. Pull out the upper cassette (a) from the paper feeder (b) and pull it out on an angle.
2. Pull out the lower cassette from the paper feeder (b) and pull it out on an angle.




Figure 4-44

3. Pinch the lock lever (a) and pull the primary paper feed unit (c) from the upper stage of the paper feeder (b).
4. Pinch the lock lever (a) and pull the primary paper feed unit (c) from the lower stage of the paper feeder (b).




Figure 4-45

5. Remove the spring (b) from the primary paper feed unit (a).

Notes when attaching

- *: Check if the pressure spring is securely in the protrusion (c) when reattaching it.




Figure 4-46

6. Tilt up the pickup holder (b) on the primary paper feed unit (a) and remove it from the bushing (c).





Figure 4-47

Notes when attaching

*: When attaching the primary paper feed unit (a), insert the protrusion (b) into the main unit side guide (c).

**Figure 4-48**

(2-2) Detaching and reattaching the retard pulley

Procedures

1. Turn over the primary paper feed unit (a).
2. Remove the spring (b).

IMPORTANT

*: Check if the pressure spring (b) is securely in the protrusion (c) when reattaching it.




Figure 4-49

3. Turn over the primary paper feed unit (a) again.
4. Remove the retard holder fulcrum (c) with the flat-blade screwdriver and remove the retard holder (d).
5. Attach the new retard holder.
6. Attach the new pickup holder.
7. Reattach the parts in the original position.

IMPORTANT

When replacing the new pickup holder or retard holder, take care not to touch the roller surface.




Figure 4-50

(3) Paper feeder (PF-5140)

(3-1) Detaching and reattaching the pickup pulley and paper feed roller

Procedures

1. Pull out the paper deck (a) from the paper feeder (b).




Figure 4-51

2. Pinch the lock lever (a) and pull the primary paper feed unit (c) from the paper feeder (b).




Figure 4-52

- Remove the spring (b) from the primary paper feed unit (a).

IMPORTANT

- *: Check if the pressure spring (b) is securely in the protrusion (c) when reattaching it.




Figure 4-53

- Tilt up the pickup holder (b) on the primary paper feed unit (a) and remove it from the bushing (c).





Figure 4-54

Notes when attaching

*: When attaching the primary paper feed unit (a), insert the protrusion (b) into the main unit side guide (c).

**Figure 4-55**

(3-2) Detaching and reattaching the retard pulley

Procedures

1. Turn over the primary paper feed unit (a).
2. Remove the spring (b).

IMPORTANT

*: Check if the pressure spring (b) is securely in the protrusion (c) when reattaching it.




Figure 4-56

3. Turn over the primary paper feed unit (a) again.
4. Remove the retard holder fulcrum (c) with the flat-blade screwdriver and remove the retard holder (d).
5. Attach the new retard holder.
6. Attach the new pickup holder.
7. Reattach the parts in the original position.

IMPORTANT

When replacing the new pickup holder or retard holder, take care not to touch the roller surface.






Figure 4-57

(4) Document processor (DP-5100): 35/40 ppm models only**(4-1) Detaching and reattaching the DP pickup pulley and DP paper feed roller****Procedures**

1. Open the DP top cover (b) of the document processor (a).

**Figure 4-58**

2. Push the lock lever (a) toward the machine rear side.
3. Release the hook (b).
4. Rotate the lock lever (a) to the release position (c).
5. Shift the machine front side of the DP paper feed roller shaft (d) toward the machine left side to remove it from the holding part (e).
6. Then, lift the shaft and pull the DP paper feed roller unit (f) out toward the machine front side.

**Figure 4-59**

(4-2) Detaching and reattaching the DP separation pad

Procedures

1. Push both hooks (b) inward and remove the DP separation pad assembly (a).
2. Attach the new DP separation pad assembly.
3. Reattach the parts in the original position.

*:Check if the pressure spring (c) is securely in the protrusion (d) when reattaching it.

4. Attach the new DP paper feed roller unit.
5. Reattach the parts in the original position.






Figure 4-60

(5) Document processor (DP-5110): 35/40 ppm models only**(5-1) Detaching and reattaching the DP pickup pulley and DP paper feed roller****Procedures**

1. Open the DP top cover (b) of the document processor (a).

**Figure 4-61**

2. Push the lock lever (a) toward the machine rear side.
3. Release the hook (b).
4. Rotate the lock lever (a) to the release position (c).
5. Shift the machine front side of the DP paper feed roller shaft (d) toward the machine left side to remove it from the holding part (e).
6. Then, lift the shaft and pull the DP paper feed roller unit (f) out toward the machine front side.

**Figure 4-62**

(5-2) Detaching and reattaching the DP separation pad

Procedures

1. Push both hooks (b) inward and remove the DP separation pad assembly (a).
2. Attach the new DP separation pad assembly.
3. Reattach the parts in the original position.

*:Check if the pressure spring (c) is securely in the protrusion (d) when reattaching it.

4. Attach the new DP paper feed roller unit.
5. Reattach the parts in the original position.





Figure 4-63

4-5 Adjustment procedures after replacing the maintenance kit

Execute the following procedures after replacing the above maintenance kit.



*1: 40 ppm model only

Execute the following maintenance modes after replacing the maintenance kit.

Executable with the preset in the U952 maintenance mode workflow. (See page 6-191,6-425)

| Maintenance kits | Maintenance item |
|--|--|
| MK-5195A/5205A/5215A MK-5206A/5216A MK-5197A/5207A/5217A | U119*1/ U930/ U140*1/ U127/ U167/ U464/ U469/ U412*1/ U410/ U251 |
| MK-5195B/5205B/5215B | U119*1/ U930/ U140*1/ U464/ U469/ U412*1/ U410/ U251 |
| MK-3140/5200 | - |

*1: 40 ppm model only

4-6 Disassembly and Reassembly

(1) Outer covers

(1-1) Detaching and reattaching the front cover

Procedures

1. Open the front cover (a).




Figure 4-64

(for 30/35 ppm models only)

2. Hold A and B, and remove the waste toner box (a).

*: There is no waste toner duct in 30/35 ppm models.




Figure 4-65

(for 40 ppm model only)

2. Hold A and B, and remove the waste toner box (a).




Figure 4-66

3. Release the hook (b) with the flat-blade screwdriver (c) and remove the strap (e) in the direction of the arrow.





Figure 4-67

4. Push down the stopper (b) of the front cover (a).
5. Slide the front cover in the direction of the arrow and remove the fulcrum (d) from the fulcrum shaft (c).

**Figure 4-68**

(1-2) Detaching and reattaching the rear left cover, rear right cover and rear lower cover

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-69

2. Remove the screw (a)(M3x8).
3. Detach the rear right cover (b) while rotating it in the direction of the arrow making two hooks (c) as a fulcrum.




Figure 4-70

4. Remove the screw (e)(M3x8).
5. Remove the rear lower cover (f) while removing the hook (c) in the direction of the arrow.




Figure 4-71

(1-3) Detaching and reattaching the ISU rear cover

Procedures

1. Remove the screw (a)(M3x8).
2. Detach the ISU rear cover (b) in the direction of the arrow.




Figure 4-72

(1-4) Detaching and reattaching the left cover

Procedures

1. Remove six screws (a)(M3x8).
2. Release three hooks (c) and remove the left cover (b) in the direction of the arrow.




Figure 4-73

(1-5) Detaching and reattaching the upper right cover

Procedures

1. Open the right cover.
2. Remove the screw (a)(M3x8).
3. Slide the right upper cover (b) in the direction of the arrow and detach it.




Figure 4-74

(1-6) Detaching and reattaching the rear right cover

Procedures

1. Detach the rear left cover.
2. Detach the rear right cover.
3. Detach the rear lower cover.
4. Open the right cover.
5. Detach the upper right cover.
6. Remove two screws (a)(M3x8) and remove the rear right cover (b).




Figure 4-75

(1-7) Detaching and reattaching the right cover assembly

Procedures

1. Open the manual feed table (a).
2. Remove two stop rings (c) with the flat-blade screwdriver (b).




Figure 4-76

3. Remove two straps (a) in the direction of the arrow.






Figure 4-77


4. Open the right cover (a).
5. Rotate the wire cover (b).
6. Release the wire (c) from the hook (d) and disconnect the connector (a).

**Figure 4-78**


7. Close the conveying unit (a).

**Figure 4-79**

8. Tilt up the right cover shaft (a).
9. Slide the right cover shaft (a) in the direction of the arrow.

**Figure 4-80**

10. Open the conveying unit (a).

**Figure 4-81**

11. Twist two straps (a) and detach them.




Figure 4-82

12. Slide the rear side fulcrum (a) and pull out the shaft of the front side fulcrum (b).

13. Tilt up the right cover assembly (c) and remove it in the direction of the arrow.




Figure 4-83

14. Pull out the right cover shaft (a).
15. Remove the stop ring (b) and pull out the fulcrum pin (c).
16. Detach the conveying unit in the direction of the arrow.




Figure 4-84

(1-8) Detaching and reattaching the upper right cover

Procedures

1. Open the right cover (a) of the main unit (b).




Figure 4-85

2. Remove the screw (a)(M3x8).
3. Slide the right upper cover (b) in the direction of the arrow and detach it.




Figure 4-86

(2) Optical section

(2-1) Detaching and reattaching the LSU

Procedures

1. Open the manual feed table (a).
2. Remove two stop rings (c) with the flat-blade screwdriver (b).




Figure 4-87

3. Remove two straps (a) in the direction of the arrow.






Figure 4-88


4. Open the right cover (a).
5. Rotate the wire cover (b).
6. Disconnect the connector (c).

**Figure 4-89**


7. Close the conveying unit (a).

**Figure 4-90**

8. Tilt up the right cover shaft (a).
9. Slide the right cover shaft (a) in the direction of the arrow.

**Figure 4-91**

10. Open the conveying unit (a).

**Figure 4-92**

11. Twist two straps (a) and detach them.




Figure 4-93

12. Slide the rear side fulcrum (a) and pull out the shaft of the front side fulcrum (b).
13. Tilt up the right cover assembly (c) and remove it in the direction of the arrow.




Figure 4-94

14. Open the front cover (a).




Figure 4-95

(for 30/35 ppm models only)

15. Hold A and B, and remove the waste toner box (a).

*: There is no waste toner duct in 30/35 ppm models.




Figure 4-96

(for 40 ppm model only)

15. Hold A and B, and remove the waste toner box (a).




Figure 4-97

16. Remove the screw (a)(M3x8).
17. Slide the regist cleaner (b) in the direction of the arrow and release the lock.
18. Pinch the regist cleaner (b) and pull it out.






Figure 4-98

19. Remove six screws (a)(M3x8).
20. Release three hooks (c) and remove the left cover (b) in the direction of the arrow.

**Figure 4-99**

21. Remove four screws (a)(M3x8) and remove the LSU left stay (b).

**Figure 4-100**

22. Hold the handle (a) and pull out the primary transfer unit (b) in the direction of the arrow.




Figure 4-101

23. Remove four screws (a)(M3x8).
 24. Release the hook (c) with the flat-blade screwdriver (b) and remove the regist guide assembly (d) in the direction of the arrow.

IMPORTANT

Securely hang the hook (e) when attaching the regist guide assembly (d). Otherwise, it causes paper jams.




Figure 4-102

25. Loosen the fixing screws (c) with a screwdriver (b) through the aperture (a) and remove the LSU (d).

*: The fixing screws (c) are not removed.




Figure 4-103

26. Pull out the laser scanner unit (a) half way.
27. Detach the FFC cover (b).




Figure 4-104

28. Detach the FFC connector (a) and the FFC connector with a lock (b).
29. Pull out the laser scanner unit (c).
30. Check the laser scanner unit (c) and clean or replace it.
31. Reattach the parts in the original position.




Figure 4-105

Notes when replacing the laser scanner unit

Execute the following adjustment after replacing the laser scanner unit.

1. Color registration adjustment (maintenance mode U469): Angle
 - (1) Input "469" using the numeric keys and press the [Start] key.
 - (2) Select [Manual].
 - (3) Select [Print].
 - (4) Press the [Start] key to output the manual adjustment chart.
 - (5) Execute the following adjustment if the gap between V-1 and V-5 match scale position is 2 scales or more for each color.




Figure 4-106

- (6) Open the front cover and pull out the waste toner box.
- (7) Rotate the hex hole (a) by using a hex wrench (5mm).

Direction of rotation

The gap between V-1 and V-5 match scale is 2 scales or more (sample 1): counter-clockwise

The gap between V-1 and V-5 match scale is -2 scales or more (sample 2): clockwise

Number of rotation

The gap between V-1 and V-5 match scale multiplied by 4 clicks.

- (8) Reattach the waste toner box in the original position and close the front cover.
- (9) Output the adjustment chart to check it is within the range.
- (10) Press the [Stop] key.




Figure 4-107

2. Color registration adjustment (maintenance mode U469): Regist
 - (1)Input "469" using the numeric keys and press the [Start] key.
 - (2)Select [Auto].
 - *:Output the auto adjustment chart.
 - (3)Select [Execute].
 - (4)Set the chart on the table and press the [Start] key.
 - *:Execute the automatic adjustment. When adjustment has normally completed, [OK] is displayed.
 - (5)Press the [Stop] key.

3. ID correction operation setting (maintenance mode U464): Calib
 - (1)Input "464" using the numeric keys and press the [Start] key.
 - (2)Select [Calib].
 - (3)Select [Full] and press the [Start] key.
 - *:Calibration starts.
 - (4)Press the [Stop] key.

4. Adjusting the uneven density (maintenance mode U412): Uneven Density (40 ppm model only)
 - (1)Input "412" using the numeric keys and press the [Start] key.
 - (2)Select [Normal Mode].
 - (3)Press the [Start] key.
 - *:Output the test pattern with the initial light intensity setting. (1st sheet)
 - (4)Place approximately 20 sheets of white paper on the test pattern for an original.
 - (5)Press the [Start] key. Correction starts.
 - (6)Press the [Start] key after completing correction. Output the test pattern. (2nd sheet)
 - *:Output with 20% less light intensity than the 1st test pattern.
 - (7)Place approximately 20 sheets of white paper on the test pattern for an original.
 - (8)Press the [Start] key. Correction starts.
 - (9)Press the [Start] key after completing correction. Output the test pattern. (3rd sheet)
 - (10)Place approximately 20 sheets of white paper on the test pattern for an original.
 - (11)Press the [Start] key.
 - *:Check the result of the correction. When correction has normally completed, [Fin] is displayed.
 - (12)Press the [Stop] key.

5. Checking LSU cleaning operation (maintenance mode U474): Execute
 - (1)Input "474" using the numeric keys and press the [Start] key.
 - (2)Select [Execute].
 - (3)Press the [Start] key.
 - *:Cleaning of the LSU slit glass is executed.
 - (4)Press the [Stop] key.

6. Exiting from the maintenance mode
 - (1)Input "001" using the numeric keys and press the [Start] key.
 - *:The maintenance mode is exited.

(2-2) Detaching and reattaching the image scanner unit (ISU)

Procedures

1. Remove the screw (a)(M3x8) and remove the rear right cover (b).
2. Release the DP interface wire (c) from the wire saddle(e) and remove it from the two connectors (d).




Figure 4-108

3. Open the document processor (a).
4. Lift up the document processor (a) in the direction of the arrow and remove the hinge (c) from the main unit (b).




Figure 4-109

(30 ppm model)

5. Remove two screws (a)(M3x8).
6. Slide the rear left cover (b) in the direction of the arrow and detach it.
7. Disconnect the FFC (d) from the main PWB connector (c).




Figure 4-110

8. Remove the screw (a)(M3x8).
9. Detach the rear right cover (b) while rotating it in the direction of the arrow making two hooks (c) as a fulcrum.
10. Disconnect the connector (d) from the engine PWB connector (c).
11. Go to procedure 12.




Figure 4-111

(35/40 ppm models)

5. Remove two screws (a)(M3x8).
6. Slide the rear left cover (b) in the direction of the arrow and detach it.




Figure 4-112

7. Remove the screw (a)(M3x8).
8. Detach the rear right cover (b) while rotating it in the direction of the arrow making two hooks (c) as a fulcrum.
9. Disconnect the FFC (e) from the engine PWB connector (d).
10. Disconnect the connector (g) from the engine PWB connector (f).
11. Go to procedure 12.






Figure 4-113

12. Open the right cover.
13. Remove the screw (a)(M3x8).
14. Slide the right upper cover (b) in the direction of the arrow and detach it.

**Figure 4-114**

15. Tilt up the operation unit (a).
16. Remove the screw (b)(M3x8).
17. Remove the operation lid (c) from the operation unit (a) in the direction of the arrow.

**Figure 4-115**

18. Remove the screw (a)(M3x8) and remove the upper exit cover (b).




Figure 4-116

19. Remove the screw (a)(M3x8).
20. Release the hook (b) in the direction of the arrow and remove the left controller cover (c).




Figure 4-117

21. Remove four pins (a) from the ISU.
22. Remove four screws (b)(M3X8) of the unit fixing plate.
23. Detach the ISU (c) in the direction of the arrow.
24. Check the ISU (c) and clean or replace it.
25. Reattach the parts in the original position.




Figure 4-118

(2-3) Detaching and reattaching the image scanner unit (ISU) upper assembly

Procedures

1. Remove the screw (a)(M3x8) and remove the rear right cover (b).
2. Release the DP interface wire (c) from the wire saddle(e) and remove it from the two connectors (d).

*: The number of connectors depends on the document processor to install.




Figure 4-119

3. Open the document processor (a).
4. Lift up the document processor (a) in the direction of the arrow and remove the hinge (c) from the main unit (b).




Figure 4-120

5. Remove four screws (a)(M3x8) from the ISU upper assembly (b).




Figure 4-121

6. Push the ISU bottom frame (a) to release the hook (b) and then detach the ISU upper assembly (c).

IMPORTANT

Lift up the ISU upper assembly (c) from the rear side (d) so that the glass does not peel.




Figure 4-122

(2-4) Detaching and reattaching the scanner carriage assembly

Procedures

1. Detach the document processor.
2. Detach the ISU upper assembly.

(30 ppm model)

3. Remove two screws (a)(M3x8).
4. Slide the rear left cover (b) in the direction of the arrow and detach it.
5. Disconnect the FFC (d) from the main PWB connector (c).




Figure 4-123

6. Peel off the sheet (a).
7. Peel off the FFC (b).




Figure 4-124

(35/40 ppm models)

3. Remove the screw (a)(M3x8).
4. Detach the rear right cover (b) while rotating it in the direction of the arrow making two hooks (c) as a fulcrum.
5. Disconnect the FFC (d) from the main PWB connector (c).




Figure 4-125

6. Peel off the sheet (a).
7. Peel off the FFC (b).




Figure 4-126

8. Shift the ISU shaft (a).
9. Remove the stop ring (b) and shim (c).
10. Remove the drive belt (e) from the two pulleys (d).




Figure 4-127

11. Remove the ferrite cores from the two holders (e) and remove the FFC (f).
12. Remove the scanner carriage (a) and ISU shaft (b) from the ISU lower assembly (c).
13. Pull out the ISU shaft (b) from the scanner carriage assembly (a).




Figure 4-128

14. Remove the drive belt (b) from the belt holder (a).
15. Check the scanner carriage (c) and clean or replace it.
16. Reattach the parts in the original position.




Figure 4-129

Notes when attaching

When attaching the scanner carriage, attach FFC in the following procedures.

*: During the work, take care not to touch the CCD PWB or to give a shock.

*: Take care not to touch the grease applied on the scanner carriage rail or to adhere dust and foreign objects.

Procedures

1. Pass FFC (c) through two hooks (e) on the bottom of the scanner carriage (a) and insert it into the ferrite core (f).
- *: Pass FFC so that the marking (d) is on the surface.
2. Connect FFC (c) to the connector (b) of the CCD PWB.




Figure 4-130

(30 ppm model)

3. Affix three double-adhesive tapes (b) within the three marking positions (a) on the base.
4. Peel off the back sheet of the double-adhesive tape, and affix FFC (c) so that it aligns with the marking.
5. Fold FFC (c) in right angle aligning with the marking (d) on FFC surface at the end position of the marking.
6. Insert FFC (c) into the ferrite core (e) and connect to the main PWB.
7. Peel off the back sheet of three double-adhesive tapes (g) of the FFC protective sheet.
8. Insert the FFC protection sheet (f) into the ferrite core (e), and then affix it on the base so that the end line of it align with the two projection step (h).
9. Insert the ISU shaft into the scanner carriage, and then reattach the parts in the original position.




Figure 4-131

(35/40 ppm models)

3. Affix three double-adhesive tapes (b) within the three marking positions (a) on the base.
4. Peel off the back sheet of the double-adhesive tape, and affix FFC (c) so that it aligns with the marking.
5. Affix the double-adhesive tape (f) so that it align with the marking (e) on FFC surface.
6. Fold FFC (c) upward at the marking (d) on the back side and affix it.
7. Fold FFC (c) in right angle aligning with the marking and insert it into the ferrite core (g), and then connect to the engine PWB.
8. Peel off the back sheet of two double-adhesive tape (i) of the FFC protective sheet.
9. Insert the FFC protection sheet (h) into the ferrite core (g), and then affix it on the base so that the end line of it align with the two projection step (j).
10. Insert the ISU shaft into the scanner carriage, and then reattach the parts in the original position.




Figure 4-132

(3) Drive section

(3-1) Detaching and reattaching the feed drive unit (30 ppm model)

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-133

2. Remove the screw (a)(M3x8).
3. Detach the rear right cover (b) while rotating it in the direction of the arrow making two hooks (c) as a fulcrum.




Figure 4-134

4. Remove the screw (a)(M3x8).
5. Release three hooks (c) of the rear lower cover (b) and detach it in the direction of the arrow.




Figure 4-135

6. Remove the screw (a)(M3x8) and remove the rear middle stay (b).




Figure 4-136

7. Release the wire (c) from the wire saddle (b) and disconnect the connector (a).
8. Remove two screws (d)(M3x8).
9. Remove the high voltage wire guide (e) in the direction of the arrow to release the protrusion (f) and hook (g).




Figure 4-137

10. Remove three screws (b)(M3x8).
11. Release two board supports (e).
12. Release two hooks (c).
13. Detach the high voltage PWB (a) while rotating it in the direction of the arrow making three hooks (d) as fulcrum.




Figure 4-138

14. Release the wire (e) from the hook (a) and five wire saddles B (d)




Figure 4-139

15. Remove three screws (a)(M3x8).
16. Release the hook (b) and remove the transfer high voltage assembly (c).




Figure 4-140

IMPORTANT

When attaching the transfer high voltage assembly (a), check the hook (b) clicks.




Figure 4-141

17. Disconnect three connectors (a).
18. Remove the wire (b) from the two hooks (c).
19. Remove three screws (d)(M3x8) and remove the heater PWB holder plate (e).




Figure 4-142

20. Remove two screws (a)(M3x8).
21. Remove the PF drawer holder (c) by sliding it to the front and removing it from the lancing (b).

IMPORTANT

When attaching the PF drawer holder (c), make sure to hang it to the two lancing (b).




Figure 4-143

22. Disconnect all the connectors from the power source PWB (a).
23. Remove two screws (b)(M3x8).
24. Release the board support (c) and remove the power source PWB (a).




Figure 4-144

25. Remove the wire (a) from the three wire saddles (b).




Figure 4-145

26. Remove the wire (b) from the hook (a).
27. Remove ten screws (c)(M3x8) and remove the high voltage PWB holder (d) in the direction of the arrow.

IMPORTANT

When reattaching the high voltage PWB holder (d), check the spring terminal (e) is in the catch (f) of the holder.




Figure 4-146

28. Disconnect the fan connector (a).
29. Remove two screws (b)(M3x8).
30. Slide the hook (c) in the direction of the arrow and remove the clutch fan assembly (d).




Figure 4-147

31. Remove the wire (a) from the wire saddle (c) and ten hooks (b) of the wire holder.




Figure 4-148

32. Remove two screws (b)(M3x8).
33. Detach the high voltage PWB holder plate (a).




Figure 4-149

34. Remove five screws (a)(M3x8).
35. Release the hook (b) and remove the inlet assembly (c).




Figure 4-150

36. Disconnect two connectors (a).
37. Remove four screws (b)(M3x8) and remove the drive unit (c).
38. Check the feed drive unit (c) and clean or replace it.
39. Reattach the parts in the original position.




Figure 4-151

IMPORTANT

Check if the MP cam (c) is put on the shaded part (b) when attaching the feed drive unit (a).




Figure 4-152

(3-2) Detaching and reattaching the feed drive unit (35/40 ppm models)

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-153

2. Remove the screw (a)(M3x8).
3. Detach the rear right cover (b) while rotating it in the direction of the arrow making two hooks (c) as a fulcrum.




Figure 4-154

4. Remove the screw (a)(M3x8).
5. Release three hooks (c) of the rear lower cover (b) and detach it in the direction of the arrow.




Figure 4-155

6. Remove the screw (a)(M3x8) and remove the rear middle stay (b).

IMPORTANT

Check if the spring (d) is in the protrusion (c) when attaching the rear middle stay.




Figure 4-156

7. Release the wire (c) from the wire saddle (b) and disconnect the connector (a).
8. Remove two screws (d)(M3x8).
9. Remove the high voltage wire guide (e) in the direction of the arrow to release the protrusion (f) and hook (g).




Figure 4-157

10. Remove four screws (b)(M3x8).
11. Release two board supports (e).
12. Release two hooks (c).
13. Rotate the high voltage PWB (a) making the four hooks (d) into a fulcrum and detach it.




Figure 4-158

14. Disconnect the connector (a) and release the wire saddle A(b).
15. Release the wire (e) from the hook (c) and four wire saddles B (d).




Figure 4-159

16. Remove three screws (a)(M3x8).
17. Release the hook (b) and remove the transfer high voltage assembly (c).




Figure 4-160

IMPORTANT

When attaching the transfer high voltage assembly (a), check the hook (b) clicks.




Figure 4-161

18. Disconnect three connectors (a).
19. Remove the wire (b) from the two hooks (c).
20. Remove three screws (d)(M3x8) and remove the heater PWB holder plate (e).





Figure 4-162

21. Remove two screws (a)(M3x8).
22. Remove the PF drawer holder (c) by sliding it to the front and removing it from the lancing (b).

IMPORTANT

When attaching the PF drawer holder (c), make sure to hang it to the two lancing (b).

**Figure 4-163**

23. Disconnect all the connectors from the power source PWB (a).
24. Remove three screws (b)(M3x8).
25. Release two hooks (c) and the board support (d), and remove the power source PWB (a).




Figure 4-164

26. Remove the wire (a) from the three wire saddles (b).




Figure 4-165

27. Remove the wire (b) from the hook (a).
28. Remove ten screws (c) (M3x8) and remove the high voltage PWB holder (d) in the direction of the arrow.

IMPORTANT

When reattaching the high voltage PWB holder (d), check the spring terminal (e) is in the catch (f) of the holder.




Figure 4-166

29. Disconnect the fan connector (a).
30. Remove two screws (b)(M3x8).
31. Slide the hook (c) in the direction of the arrow and remove the clutch fan assembly (d).




Figure 4-167

32. Remove the wire (a) from the wire saddle (c) and ten hooks (b) of the wire holder.




Figure 4-168

33. Remove two screws (b)(M3x8).
34. Detach the high voltage PWB holder plate (a).




Figure 4-169

35. Remove five screws (a)(M3x8).
36. Release the hook (b) and remove the inlet assembly (c).




Figure 4-170

37. Disconnect two connectors (a).
38. Remove four screws (b)(M3x8) and remove the drive unit (c).
39. Check the feed drive unit (c) and clean or replace it.
40. Reattach the parts in the original position.




Figure 4-171

IMPORTANT

Check if the MP cam (c) is put on the shaded part (b) when attaching the feed drive unit (a).




Figure 4-172

(3-3) Detaching and reattaching the main drive unit (30 ppm model)

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-173

2. Remove the screw (a)(M3x8).
3. Detach the rear right cover (b) while rotating it in the direction of the arrow making two hooks (c) as a fulcrum.






Figure 4-174

4. Remove the screw (a)(M3x8).
5. Release three hooks (c) of the rear lower cover (b) and detach it in the direction of the arrow.

**Figure 4-175**

6. Remove the screw (a)(M3x8) and remove the rear middle stay (b).

**Figure 4-176**

7. Release the wire (c) from the wire saddle (b) and disconnect the connector (a).
8. Remove two screws (d)(M3x8).
9. Remove the high voltage wire guide (e) in the direction of the arrow to release the protrusion (f) and hook (g).




Figure 4-177

10. Remove three screws (b)(M3x8).
11. Release two board supports (e).
12. Release two hooks (c).
13. Detach the high voltage PWB (a) while rotating it in the direction of the arrow making three hooks (d) as fulcrum.




Figure 4-178

14. Release the wire (e) from the hook (a) and five wire saddles B (d).




Figure 4-179

15. Remove three screws (a)(M3x8).
16. Release the hook (b) and remove the transfer high voltage assembly (c).




Figure 4-180

IMPORTANT

When attaching the transfer high voltage assembly (a), check the hook (b) clicks.




Figure 4-181

17. Disconnect three connectors (a).
18. Remove the wire (b) from the two hooks (c).
19. Remove three screws (d)(M3x8) and remove the heater PWB holder plate (e).




Figure 4-182

20. Remove two screws (a)(M3x8).
21. Remove the PF drawer holder (c) by sliding it to the front and removing it from the lancing (b).

IMPORTANT

When attaching the PF drawer holder (c), make sure to hang it to the two lancing (b).




Figure 4-183

22. Disconnect all the connectors from the power source PWB (a).
23. Remove two screws (b)(M3x8).
24. Release the board support (c) and remove the power source PWB (a).





Figure 4-184

25. Remove the wire (a) from the three wire saddles (b).




Figure 4-185

26. Remove the wire (b) from the hook (a).
 27. Remove ten screws (c)(M3x8) and remove the high voltage PWB holder (d) in the direction of the arrow.

IMPORTANT

When reattaching the high voltage PWB holder (d), check the spring terminal (e) is in the catch (f) of the holder.




Figure 4-186

28. Disconnect the fan connector (a).
29. Remove two screws (b)(M3x8).
30. Slide the hook (c) in the direction of the arrow and remove the clutch fan assembly (d).




Figure 4-187

31. Remove the wire (a) from the three wire saddles (b).
32. Disconnect three connectors (d) of the motor (c).




Figure 4-188

33. Disconnect all the connectors from the engine PWB (b).
34. Remove eight screws (a)(M3x8) and remove the engine PWB (b).




Figure 4-189

35. Remove the wire (b) from the wire saddle (a).




Figure 4-190

36. Remove five screws (a)(M3x8).
37. Release two hooks (b) with the flat-blade screwdriver (c) and remove the engine PWB mounting plate (d) in the direction of the arrow.




Figure 4-191

38. Remove five screws (a)(M3x8) and remove the main drive unit (b).
39. Check the main drive unit (b) and clean or replace it.
40. Reattach the parts in the original position.




Figure 4-192

(3-4) Detaching and reattaching the main drive unit (35/40 ppm models)

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-193

2. Remove the screw (a)(M3x8).
3. Detach the rear right cover (b) while rotating it in the direction of the arrow making two hooks (c) as a fulcrum.




Figure 4-194

4. Remove the screw (a)(M3x8).
5. Release three hooks (c) of the rear lower cover (b) and detach it in the direction of the arrow.




Figure 4-195

6. Remove the screw (a)(M3x8) and remove the rear middle stay (b).

IMPORTANT

Check if the spring (d) is in the protrusion (c) when attaching the rear middle stay.




Figure 4-196

7. Release the wire (c) from the wire saddle (b) and disconnect the connector (a).
8. Remove two screws (d)(M3x8).
9. Remove the high voltage wire guide (e) in the direction of the arrow to release the protrusion (f) and hook (g).




Figure 4-197

10. Remove four screws (b)(M3x8).
11. Release two board supports (e).
12. Release two hooks (c).
13. Rotate the high voltage PWB (e) making the four hooks (d) into a fulcrum and detach it.




Figure 4-198

14. Disconnect the connector (a) and release the wire saddle A(b).
15. Release the wire (e) from the hook (c) and four wire saddles B (d).




Figure 4-199

16. Remove three screws (a)(M3x8).
17. Release the hook (b) and remove the transfer high voltage assembly (c).




Figure 4-200

IMPORTANT

When attaching the transfer high voltage assembly (a), check the hook (b) clicks.




Figure 4-201

18. Disconnect three connectors (a).
19. Remove the wire (b) from the two hooks (c).
20. Remove three screws (d)(M3x8) and remove the heater PWB holder plate (e).





Figure 4-202

21. Remove two screws (a)(M3x8).
22. Remove the PF drawer holder (c) by sliding it to the front and removing it from the lancing (b).

IMPORTANT

When attaching the PF drawer holder (c), make sure to hang it to the two lancing (b).

**Figure 4-203**

23. Disconnect all the connectors from the power source PWB (a).
24. Remove three screws (b)(M3x8).
25. Release two hooks (c) and the board support (d), and remove the power source PWB (a).




Figure 4-204

26. Remove the wire (a) from the three wire saddles (b).




Figure 4-205

27. Remove the wire (b) from the hook (a).
28. Remove ten screws (c)(M3x8) and remove the high voltage PWB holder (d) in the direction of the arrow.

IMPORTANT

When reattaching the high voltage PWB holder (d), check the spring terminal (e) is in the catch (f) of the holder.




Figure 4-206

29. Disconnect the fan connector (a).
30. Remove two screws (b)(M3x8).
31. Slide the hook (c) in the direction of the arrow and remove the clutch fan assembly (d).




Figure 4-207

32. Remove the wire (a) from the three wire saddles (b).
33. Disconnect three connectors (d) of the motor (c).




Figure 4-208

- 34. Disconnect all the connectors from the engine PWB (b).
- 35. Remove eight screws (a)(M3x8) and remove the engine PWB (b).




Figure 4-209

Notes when detaching

In the case of the FFC connector with a lock, release the lock cover (a) and pull out the FFC (b).




Figure 4-210

36. Remove the wire (b) from the wire saddle (a).




Figure 4-211

37. Remove five screws (a)(M3x8).
38. Release two hooks (b) with the flat-blade screwdriver (c) and remove the engine PWB mounting plate (d) in the direction of the arrow.




Figure 4-212

39. Remove five screws (a)(M3x8) and remove the main drive unit (b).
40. Check the main drive unit (b) and clean or replace it.
41. Reattach the parts in the original position.




Figure 4-213

(3-5) Detaching and reattaching the transfer motor (30 ppm model)

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-214

2. Remove the screw (a)(M3x8).
3. Detach the rear right cover (b) while rotating it in the direction of the arrow making two hooks (c) as a fulcrum.




Figure 4-215

4. Remove the screw (a)(M3x8).
5. Release three hooks (c) of the rear lower cover (b) and detach it in the direction of the arrow.




Figure 4-216

6. Remove the screw (a)(M3x8) and remove the rear middle stay (b).




Figure 4-217

7. Release the wire (c) from the wire saddle (b) and disconnect the connector (a).
8. Remove two screws (d)(M3x8).
9. Remove the high voltage wire guide (e) in the direction of the arrow to release the protrusion (f) and hook (g).




Figure 4-218

10. Remove three screws (b)(M3x8).
11. Release two board supports (e).
12. Release two hooks (c).
13. Detach the high voltage PWB (a) while rotating it in the direction of the arrow making three hooks (d) as fulcrum.




Figure 4-219

14. Disconnect the fan connector (a).
15. Remove two screws (b)(M3x8).
16. Slide the hook (c) in the direction of the arrow and remove the clutch fan assembly (d).




Figure 4-220

17. Disconnect all the connectors from the engine PWB (b).
18. Remove eight screws (a)(M3x8) and remove the engine PWB (b).




Figure 4-221

19. Remove the wire (b) from the wire saddle (a).




Figure 4-222

20. Remove five screws (a)(M3x8).
 21. Release two hooks (b) with the flat-blade screwdriver (c) and remove the engine PWB mounting plate (d) in the direction of the arrow.





Figure 4-223

22. Disconnect the connector (a).
23. Remove two screws (b)(M3x8) and remove the transfer motor (c) in the direction of the arrow.
24. Check the transfer motor (c) and clean or replace it.
25. Reattach the parts in the original position.

IMPORTANT

Apply grease as below to the drive gears when replacing them.

**Figure 4-224**

(3-6) Detaching and reattaching the transfer motor (35/40 ppm models)

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-225

2. Remove the screw (a)(M3x8).
3. Detach the rear right cover (b) while rotating it in the direction of the arrow making two hooks (c) as a fulcrum.




Figure 4-226

4. Remove the screw (a)(M3x8).
5. Release three hooks (c) of the rear lower cover (b) and detach it in the direction of the arrow.




Figure 4-227

6. Remove the screw (a)(M3x8) and remove the rear middle stay (b).

IMPORTANT

Check if the spring (d) is in the protrusion (c) when attaching the rear middle stay.




Figure 4-228

7. Release the wire (c) from the wire saddle (b) and disconnect the connector (a).
8. Remove two screws (d)(M3x8).
9. Remove the high voltage wire guide (e) in the direction of the arrow to release the protrusion (f) and hook (g).




Figure 4-229

10. Remove four screws (b)(M3x8).
11. Release two board supports (e).
12. Release two hooks (c).
13. Rotate the high voltage PWB (e) making the four hooks (d) into a fulcrum and detach it.




Figure 4-230

14. Disconnect the fan connector (a).
15. Remove two screws (b)(M3x8).
16. Slide the hook (c) in the direction of the arrow and remove the clutch fan assembly (d).




Figure 4-231

17. Disconnect all the connectors from the engine PWB (b).
18. Remove eight screws (a)(M3x8) and remove the engine PWB (b).




Figure 4-232

Notes when detaching

In the case of the FFC connector with a lock, release the lock cover (a) and pull out the FFC (b).




Figure 4-233

19. Remove the wire (b) from the wire saddle (a).




Figure 4-234

20. Remove five screws (a)(M3x8).
 21. Release two hooks (b) with the flat-blade screwdriver (c) and remove the engine PWB mounting plate (d) in the direction of the arrow.





Figure 4-235

22. Disconnect the connector (a).
23. Remove three screws (b)(M3x8) and remove the transfer motor (c) in the direction of the arrow.
24. Check the transfer motor (c) and clean or replace it.
25. Reattach the parts in the original position.

IMPORTANT

Apply grease as below to the drive gears when replacing them.

**Figure 4-236**

(3-7) Detaching and reattaching the toner supply drive unit (30 ppm model)

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-237

2. Remove the screw (a)(M3x8).
3. Detach the rear right cover (b) while rotating it in the direction of the arrow making two hooks (c) as a fulcrum.




Figure 4-238

4. Remove the screw (a)(M3x8).
5. Release three hooks (c) of the rear lower cover (b) and detach it in the direction of the arrow.




Figure 4-239

6. Remove the screw (a)(M3x8) and remove the rear middle stay (b).




Figure 4-240

7. Release the wire (c) from the wire saddle (b) and disconnect the connector (a).
8. Remove two screws (d)(M3x8).
9. Remove the high voltage wire guide (e) in the direction of the arrow to release the protrusion (f) and hook (g).




Figure 4-241

10. Remove three screws (b)(M3x8).
11. Release two board supports (e).
12. Release two hooks (c).
13. Detach the high voltage PWB (a) while rotating it in the direction of the arrow making three hooks (d) as fulcrum.




Figure 4-242

14. Disconnect the fan connector (a).
15. Remove two screws (b)(M3x8).
16. Slide the hook (c) in the direction of the arrow and remove the clutch fan assembly (d).




Figure 4-243

17. Disconnect all the connectors from the engine PWB (b).
18. Remove eight screws (a)(M3x8) and remove the engine PWB (b).




Figure 4-244

19. Remove the screw (a)(M3x8).
20. Release the hook (b) in the direction of the arrow and remove the left controller cover (c) in the direction of the arrow.




Figure 4-245

21. Remove the wire (a) from the hook (b).
22. Remove two screws (c)(M3x8).
23. Remove the fan connector (d) and remove the controller fan assembly (e).




Figure 4-246

- 24. Disconnect all the connectors from the main PWB (a).
- 25. Remove six screws (b)(M3x8) and remove the main PWB (a).





Figure 4-247

26. Remove the wire (b) from the wire saddle (a).




Figure 4-248

27. Remove five screws (a)(M3x8).
 28. Release two hooks (b) with the flat-blade screwdriver (c) and remove the engine PWB mounting plate (d) in the direction of the arrow.




Figure 4-249

29. Remove the holder (a) and remove FFC (b).
30. Remove four screws (c)(M3x8) and remove the main PWB holder plate (d).




Figure 4-250

31. Remove the wire (a) from the three wire saddles (b).
32. Remove five screws (c)(M3x8) and remove the controller frame (d).




Figure 4-251

33. Remove the wire (b) from the wire saddle (a).
34. Disconnect four connectors (c).
35. Remove four screws (d)(M3x8) and remove the toner supply drive unit (e).
36. Check the toner supply drive unit (e) and clean or replace it.
37. Reattach the parts in the original position.




Figure 4-252

(3-8) Detaching and reattaching the toner supply drive unit (35/40 ppm model)

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-253

2. Remove the screw (a)(M3x8).
3. Detach the rear right cover (b) while rotating it in the direction of the arrow making two hooks (c) as a fulcrum.




Figure 4-254

4. Remove the screw (a)(M3x8).
5. Release three hooks (c) of the rear lower cover (b) and detach it in the direction of the arrow.




Figure 4-255

6. Remove the screw (a)(M3x8) and remove the rear middle stay (b).

IMPORTANT

Check if the spring (d) is in the protrusion (c) when attaching the rear middle stay.




Figure 4-256

7. Release the wire (c) from the wire saddle (b) and disconnect the connector (a).
8. Remove two screws (d)(M3x8).
9. Remove the high voltage wire guide (e) in the direction of the arrow to release the protrusion (f) and hook (g).




Figure 4-257

10. Remove four screws (b)(M3x8).
11. Release two board supports (e).
12. Release two hooks (c).
13. Rotate the high voltage PWB (e) making the four hooks (d) into a fulcrum and detach it.




Figure 4-258

14. Disconnect the fan connector (a).
15. Remove two screws (b)(M3x8).
16. Slide the hook (c) in the direction of the arrow and remove the clutch fan assembly (d).




Figure 4-259

17. Disconnect all the connectors from the engine PWB (b).
18. Remove eight screws (a)(M3x8) and remove the engine PWB (b).




Figure 4-260

Notes when detaching

In the case of the FFC connector with a lock, release the lock cover (a) and pull out the FFC (b).




Figure 4-261

19. Remove the HDD wire (a) from the three hooks (b).
20. Disconnect the fan connector (c).
21. Remove two screws (d)(M3x8) and remove the fan holder (e).




Figure 4-262

22. Remove the screw (a)(M3x8).
23. Release the hook (b) in the direction of the arrow and remove the left controller cover (c).




Figure 4-263

- 24. Disconnect all the connectors from the main PWB (a).
- 25. Remove nine screws (b)(M3x8) and remove the main PWB (a).





Figure 4-264

Notes when detaching

In the case of the FFC connector with a lock, release the lock cover (a) and pull out the FFC (b).




Figure 4-265

26. Remove the wire (b) from the wire saddle (a).




Figure 4-266

27. Remove five screws (a)(M3x8).
28. Release two hooks (b) with the flat-blade screwdriver (c) and remove the engine PWB mounting plate (d) in the direction of the arrow.




Figure 4-267

29. Remove four screws (a)(M3x8) and remove the main PWB holder plate (b).




Figure 4-268

30. Remove the wire (a) from the three wire saddles (b).
 31. Remove five screws (c)(M3x8) and remove the controller frame (d).




Figure 4-269

32. Remove the wire (b) from the wire saddle (a).
33. Disconnect four connectors (c).
34. Remove four screws (d)(M3x8) and remove the toner supply drive unit (e).
35. Check the toner supply drive unit (e) and clean or replace it.
36. Reattach the parts in the original position.






Figure 4-270

(4) Others**(4-1) Detaching and reattaching the SSD: 35 ppm model only****Procedures**

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.

**Figure 4-271**

2. Disconnect the fan connector (a).
3. Remove two screws (b)(M3x8) and remove the fan holder (c).


**Figure 4-272**

4. Remove the screw (a)(M3x8).
 5. Remove the SSD (b) from the connector (c).
- *: Use a Phillips 1 screwdriver and take care not to damage the screws.

IMPORTANT

To avoid damage when attaching the SSD (b), align the screw hole (d) to the positioning boss (e).

- *: When replacing the SSD, execute U917 (See page 6-417) to backup internal data (address book).

**Figure 4-273**

(4-2) Detaching and reattaching the hard disk: 35/40 ppm model only

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-274

2. Disconnect two connectors (a).
3. Remove three screws (b)(M3x8) and remove the hard disk (c).
4. Check the hard disk (c) and clean or replace it.
5. Reattach the parts in the original position.

*: Execute maintenance mode U024 (See page 6-222) when formatting a new HDD.




Figure 4-275

(4-3) Detaching and reattaching the lift motor

Procedures

1. Pull out the cassette (a) from the paper feeder (b) and remove it in the direction of the arrow.




Figure 4-276

2. Pinch the lock lever (a) and pull the primary paper feed unit (c) from the paper feeder (b).




Figure 4-277

3. Remove the connector (a) and two screws (b)(M3x8).
4. Release the hook (d) from the square hole (c) of the side frame and remove the sensor holder (e).




Figure 4-278

5. Remove the connector (a) and two screws (b)(M3x8).
6. Release the hook (d) from the square hole (c) of the side frame and remove the lift motor (e).
7. Check the lift motor (e) and clean or replace it.
8. Reattach the parts in the original position.




Figure 4-279

(4-4) Detaching and reattaching the eject unit

Procedures

1. Open the right cover (a) of the main unit (b).




Figure 4-280

2. Remove the screw (a)(M3x8) and remove the fuser wire cover (b).
3. Disconnect two connectors (c) of the fuser unit.




Figure 4-281

4. Remove two screws (a)(M3x8) and remove the fuser unit (b).
5. Attach the new fuser unit.
6. Reattach the parts in the original position.




Figure 4-282

7. Remove the screw (a)(M3x8).
8. Slide the right upper cover (b) in the direction of the arrow and detach it.




Figure 4-283

9. Disconnect the connector (b) of the eject fan (a).
10. Push the protrusion (c) with a screwdriver tip (d), etc. and release the lock.
11. Slide the eject fan (a) in the direction of the arrow and detach it.




Figure 4-284

12. Disconnect the connector (a) of the eject unit.
13. Remove two screws (b)(M3x8) and detach the eject unit (c).
14. Check the eject unit (c) and clean or replace it.
15. Reattach the parts in the original position.




Figure 4-285

(4-5) Replacing the language sheet (30 ppm model)

Procedures

1. Lift up and slide the leading edge of the operation panel cover A (d) with the flat-blade screwdriver (m).
2. Release four hooks (e) and remove the operation panel cover A (d).
3. Release two protrusions (f) and remove the clear panel A (c) from the operation panel (a).
4. Remove the operation panel sheet A (b).
5. Replace the operation panel sheet of the applicable language.
6. Reattach the clear panel A (c) and operation panel cover A (d) in the original position.
7. Remove the panel cover B (i), clear panel B (h) and operation panel sheet B (g) as well.
8. Replace the operation panel sheet of the applicable language and reattach the parts in the original position.




Figure 4-286

(4-6) Replacing the language sheet (35/40 ppm models)

Procedures

1. Lift up and slide the leading edge of the operation panel cover (d) with the flat-blade screwdriver (g).
2. Release four hooks (e) and remove the operation panel cover (d).
3. Release two protrusions (f) and remove the clear panel (c) from the operation panel (a).
4. Remove the operation panel sheet (b).
5. Replace the operation panel sheet of the applicable language.
6. Reattach the clear panel (c) and operation panel cover (d) in the original position.




Figure 4-287

(4-7) Fan motor attachment direction

*: When reattaching the fan motor, be aware of the attachment direction (intake/exhaust).

30 ppm models




Figure 4-288

35/40 ppm models




Figure 4-289


- a. Developer fan motor 3: intake *1
- b. Developer fan motor 4: intake *1
- c. Eject fan motor: intake *2
- d. Transfer belt fan motor: intake *2
- e. Toner sucking fan motor: intake *1

- f. PWB fan motor: intake *3
- g. Developer fan motor 2: intake *3
- h. Developer fan motor 1: intake *3
- i. Controller fan motor: intake *2
- j. Clutch fan motor: intake *2
- k. Eject paper fan motor: intake *2


*1: rating label side: top side
 *2: rating label side: inside
 *3: rating label side: outside

(5) PWBs**(5-1) Detaching and reattaching the engine PWB (30 ppm model)****Procedures**

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding in the direction of the arrow.

**Figure 4-290**

2. Remove the screw (a)(M3x8) and remove the rear right cover (b) in the direction of the arrow.

**Figure 4-291**

3. Disconnect all the connectors from the engine PWB (b).
4. Remove eight screws (a)(M3x8) and remove the engine PWB (b).
5. Check or replace the engine PWB (b), and then reattach the parts in the original position.




Figure 4-292

Notes when replacing the engine PWB

When replacing the engine PWB (a), make sure to remove the EEPROM (b) (YS1) from the old board and install it in the new board.




Figure 4-293

Execute the following setting after replacing the engine PWB.

1. Machine No. (maintenance mode U004)

*: If the C0180 error occurs, execute U004 to match the serial numbers in the PWBs.

- (1) Input "004" using the numeric keys and press the [Start] key.
- (2) Select [Execute] and press the [Start] key.
- (3) Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

2. Firmware update (See page 5-1)

*: Check the latest firmware and upgrade it.

3. Adjusting the scanner automatically (maintenance mode U411)


Adjusting the table scanning automatically

- (1) Set the specified original (P/N: 7505000107) on the table.
- (2) Enter maintenance item U411.
- (3) Select [Target].
- (4) Press [Left/Right] cursor key or [#], [*] key and select [Auto].
- (5) Press the [Up/Down] cursor key and select [Table(ChartA)].
- (6) Press the [Start] key to read the barcode of the original chart and to start the automatic adjustment.
- (7) When automatic adjustment has normally completed, [OK] is displayed.

DP 1st side scanning auto adjustment

- (1) Set the specified original (P/N: 7505000106) face-up on the DP.

*: Cut the trailing edge of the DP adjustment original (ChartB) as follows to use.



- (2) Enter maintenance item U411.
- (3) Select [DP FU(ChartB)].
- (4) Press the [Start] key to start Auto adjustment.
- (5) When automatic adjustment has normally completed, [OK] is displayed.

*: If there is a problem with the 2nd side timing after adjusting the scanner, execute [DP FD(ChartB)].
Also, if there is a problem with the DP 1st side color, execute [DP FU(ChartA)].

4. ID correction operation setting (maintenance mode U464): Calib

- (1) Input "464" using the numeric keys and press the [Start] key.
 - (2) Select [Calib].
 - (3) Select [Full] and press the [Start] key.
- *: Calibration starts.
- (4) Press the [Stop] key.

5. Adjusting the halftone automatically (maintenance mode U410)

- (1) Input "410" using the numeric keys and press the [Start] key.
 - (2) Press the [Start] key.
- *: Test pattern 1 and Test pattern 2 are output on A4 paper.
- (3) Set the output Test Pattern 1 as the original.
- *: Set test pattern 1 and place approximately 20 sheets of white paper on it.
- (4) Press the [Start] key.
- *: The 1st auto adjustment is executed.
- (5) Set the output Test Pattern 2 as the original.
- *: Set test pattern 2 and place approximately 20 sheets of white paper on it.
- (6) Press the [Start] key.
- *: The 2nd auto adjustment is executed.
- (7) [Finish] appears after normal completion.
 - (8) Press the [Stop] key.

(5-2) Detaching and reattaching the engine PWB (35/40 ppm model)

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-294

2. Remove the screw (a)(M3x8) and remove the rear right cover (b) in the direction of the arrow.




Figure 4-295

3. Disconnect all the connectors from the engine PWB (b).
4. Remove eight screws (a)(M3x8) and remove the engine PWB (b).
5. Check or replace the engine PWB (b), and then reattach the parts in the original position.




Figure 4-296

Notes when detaching

In the case of the FFC connector with a lock, release the lock cover (a) and pull out the FFC (b).




Figure 4-297

Notes when replacing the engine PWB

When replacing the engine PWB (a), make sure to remove the EEPROM (b) (YS1) from the old board and install it in the new board.




Figure 4-298

Execute the following setting after replacing the engine PWB.

1. Machine No. (maintenance mode U004)

*: If the C0180 error occurs, execute U004 to match the serial numbers in the PWBs.

- (1) Input "004" using the numeric keys and press the [Start] key.
- (2) Select [Execute] and press the [Start] key.
- (3) Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

2. Firmware update (See page 5-4)

*: Check the latest firmware and upgrade it.

3. Adjusting the scanner automatically (maintenance mode U411)

Adjusting the table scanning automatically


- (1) Set the specified original (P/N: 7505000107) on the table.
- (2) Enter maintenance item U411.
- (3) Select [Target].
- (4) Select [Auto].
- (5) Press the [Start] key.
- (6) Select [Table(ChartA)].
- (7) Press the [Start] key to read the barcode of the original chart and to start the automatic adjustment.
- (8) When automatic adjustment has normally completed, [OK] is displayed.

*: After adjusting the scanner, if there is a problem with the DP 1st side color execute [DP FU(ChartA)].

DP 1st side scanning auto adjustment: Reversing DP (DP-5100) only

(1) Set the specified original (P/N: 7505000106) face-up on the DP.

*: Cut the trailing edge of the DP adjustment original (ChartB) as follows to use.



(2) Enter maintenance item U411.

(3) Select [DP FU(ChartB)].

(4) Press the [Start] key to start Auto adjustment.

(5) When automatic adjustment has normally completed, [OK] is displayed.

4. ID correction operation setting (maintenance mode U464): Calib

(1) Input "464" using the numeric keys and press the [Start] key.

(2) Select [Calib].

(3) Select [Full] and press the [Start] key.

*: Calibration starts.

(4) Press the [Stop] key.

5. Adjusting the halftone automatically (maintenance mode U410)

(1) Input "410" using the numeric keys.

(2) Press the [Start] key.

*: Test pattern 1, Test pattern 2 and Test pattern 3 are output on A4 paper.

(3) Set the output Test Pattern 1 as the original.

*: Set test pattern 1 and place approximately 20 sheets of white paper on it.

(4) Press the [Start] key.

*: The 1st auto adjustment is executed.

(5) Set the output Test Pattern 2 as the original.

*: Set test pattern 2 and place approximately 20 sheets of white paper on it.

(6) Press the [Start] key.

*: The 2nd auto adjustment is executed.

(7) Set the output Test Pattern 3 as the original.

*: Set test pattern 3 and place approximately 20 sheets of white paper on it.

(8) Press the [Start] key.

*: The 3rd auto adjustment is executed.

*: Test pattern 4 is output on A4 paper.

(9) Set the output Test Pattern 4 as the original.

*: Set test pattern 4 and place approximately 20 sheets of white paper on it.

(10) Press the [Start] key.

*: The 4th auto adjustment is executed.

(11) [Finish] appears after normal completion.

(12) Press the [Stop] key.

(5-3) Detaching and reattaching the main PWB (30 ppm model)

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-299

2. Remove the screw (a)(M3x8).
3. Release the hook (b) in the direction of the arrow and remove the left controller cover (c) in the direction of the arrow.




Figure 4-300

4. Remove the wire (a) from the hook (b).
5. Remove two screws (c)(M3x8).
6. Remove the fan connector (d) and remove the controller fan assembly (e).




Figure 4-301

7. Disconnect all the connectors from the main PWB (a).
8. Remove six screws (b)(M3x8) and remove the main PWB (a).
9. Check the main PWB (a) and clean or replace it if necessary.
- *: Replace the optional memory from the old PWB to the new one, if installed.
10. Reattach the parts in the original position.





Figure 4-302

Notes when replacing the main PWB

- *: There is no EEPROM in the main PWB for 30 ppm model.
- *: When replacing the main PWB, in order to maintain the user information, insert a USB memory and execute U917 to export data. (See page 6-185)
- *: Since the MAC address changes, check the network settings.
Example: If the printer name is registered with the IP address, reset the IP address.

Execute the following setting after replacing the main PWB.

1. Machine No. (maintenance mode U004)
 - *:If the C0180 error occurs, execute U004 to match the serial numbers in the PWBs.
 - (1)Input "004" using the numeric keys and press the [Start] key.
 - (2)Select [Execute] and press the [Start] key.
 - (3)Turn the power switch off then on. Wait more than 5 seconds between the power off and on.
2. Firmware update (See page 5-1)
 - *:Check the latest firmware and upgrade it.
3. Insert the USB memory and execute U917 to import data.

4. ID correction operation setting (maintenance mode U464): Calib
 (1)Input "464" using the numeric keys and press the [Start] key.
 (2)Select [Calib].
 (3)Select [Full] and press the [Start] key.
 *:Calibration starts.
 (4)Press the [Stop] key.
5. Adjusting the halftone automatically (maintenance mode U410)
 (1)Input "410" using the numeric keys and press the [Start] key.
 *:Execution information screen is displayed.
 *:Test patterns 1 and 2 are output on the A4 paper.
 (2)Place the output test pattern 1 as the original.
 *:Place approximately 20 sheets of white paper on the test pattern 1 and set them.
 (3)Press the [Start] key.
 *:The first auto adjustment is executed.
 (4)Place the output test pattern 2 as the original.
 (5)Press the [Start] key.
 *:The second auto adjustment is executed.
 (6)[Finish] appears after normal completion.

6. Reactivating the license

Reactivate the license when equipping the license of the optional product.

- (1)Card Authentication Kit (B)

*:When using the SSFC card, execute maintenance mode U222 and set [SSFC].

(See page 6-85,6-299)

- (2)UG-33 (ThinPrint)

- (3)Data Security Kit (E)

*:Re-entering 4-digit encryption codes entered at setup is necessary.

7. Resetting the initial settings

Reset the user default setting and FAX default setting (e.g. the local FAX information) from the System Menu or Command Center.

8. Resetting the maintenance mode

Reset the following maintenance mode if necessary.

| No. | Maintenance mode relating to the main unit | No. | Maintenance mode relating to the main unit |
|------|--|------|--|
| U250 | Maintenance counter preset | U603 | User data 1 |
| U251 | Maintenance counter clear | U604 | User data 2 |
| U253 | Double/single count switch | U610 | System 1 |
| U260 | Feed/eject counter switch | U611 | System 2 |
| U345 | Maintenance timing pre-caution setting | U612 | System 3 |
| U402 | Print margin adjustment | U625 | Communication Setting |
| U403 | Scanning margin adjustment (table) | U695 | FAX function customization |
| U404 | Scanning margin adjustment (DP) | | |
| U425 | Target adjustment | | |

9. Exiting from the maintenance mode

Input "001" using the numeric keys and press the [Start] key.

(5-4) Detaching and reattaching the main PWB (35/40 ppm models)

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-303

(Procedure 2 to 7: Document processor (CIS) only)

2. Remove the screw (f)(M3x8) and remove the rear right cover (g).
3. Remove the CIS connector (i) while pulling the release lever (h).
4. Remove three screws (d)(M3x8) and remove the DP relay PWB holder (e).
5. Disconnect all the connectors from the DP relay PWB holder (a).
6. Remove two screws (b)(M3x8).
7. Detach the DP relay PWB (a) while removing the backside connector (c).





Figure 4-304

8. Remove the HDD wire (a) from the three hooks (b).
9. Disconnect the fan connector (c).
10. Remove two screws (d)(M3x8) and remove the fan holder (e).




Figure 4-305

11. Remove the screw (a)(M3x8).
12. Release the hook (b) in the direction of the arrow and remove the left controller cover (c).




Figure 4-306

13. Disconnect all the connectors from the main PWB (a).
14. Remove eight screws (b)(M3x8) and remove the main PWB (a).
15. Check the main PWB (a) and clean or replace it if necessary.
- *: Replace the optional memory from the old PWB to the new one, if installed.
16. Reattach the parts in the original position.





Figure 4-307

Notes when detaching

In the case of the FFC connector with a lock, release the lock cover (a) and pull out the FFC (b).




Figure 4-308

Notes when replacing the main PWB

When replacing the main PWB (a), make sure to remove the EEPROM (b) (YS14) from the old board and install it in the new board.




Figure 4-309

Execute the following setting after replacing the main PWB.

1. Machine No. (maintenance mode U004)

*: If the C0180 error occurs, execute U004 to match the serial numbers in the PWBs.

- (1) Input "004" using the numeric keys and press the [Start] key.
- (2) Select [Execute] and press the [Start] key.
- (3) Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

2. Firmware update (See page 5-4)

*: Check the latest firmware and upgrade it.

3. ID correction operation setting (maintenance mode U464): Calib

- (1) Input "464" using the numeric keys and press the [Start] key.
- (2) Select [Calib].
- (3) Select [Full] and press the [Start] key.

*: Calibration starts.

- (4) Press the [Stop] key.

4. Adjusting the halftone automatically (maintenance mode U410)

(1) Input "410" using the numeric keys and press the [Start] key.

*:Execution information screen is displayed.

*:Test patterns 1, 2 and 3 are output on the A4 paper.

(2) Place the output test pattern 1 as the original.

*:Place approximately 20 sheets of white paper on the test pattern 1 and set them.

(3) Press the [Start] key.

*:The first auto adjustment is executed.

(4) Place the output test pattern 2 as the original.

(5) Press the [Start] key.

*:The second auto adjustment is executed.

(6) Place the output test pattern 3 as the original.

(7) Press the [Start] key.

*:The third auto adjustment is executed.

*:Test patterns 4 is output on the A4 paper.

(8) Place the output test pattern 4 as the original.

(9) Press the [Start] key.

*:The forth auto adjustment is executed.

(10) [Finish] appears after normal completion.

5. Resetting the initial settings

Reset the user default setting and FAX default setting (e.g. the local FAX information) from the System Menu or Command Center.

6. Resetting the maintenance mode

Reset the following maintenance mode if necessary.

| No. | Maintenance mode relating to the main unit | No. | Maintenance mode relating to the main unit |
|------|--|------|--|
| U250 | Maintenance counter preset | U603 | User data 1 |
| U251 | Maintenance counter clear | U604 | User data 2 |
| U253 | Double/single count switch | U610 | System 1 |
| U260 | Feed/eject counter switch | U611 | System 2 |
| U345 | Maintenance timing pre-caution setting | U612 | System 3 |
| U402 | Print margin adjustment | U625 | Communication Setting |
| U403 | Scanning margin adjustment (table) | U695 | FAX function customization |
| U404 | Scanning margin adjustment (DP) | | |
| U425 | Target adjustment | | |

7. Exiting from the maintenance mode

Input "001" using the numeric keys and press the [Start] key.

(5-5) Detaching and reattaching the high voltage PWB (30 ppm model)

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-310

2. Remove the screw (a)(M3x8) and remove the rear right cover (b) in the direction of the arrow.




Figure 4-311

3. Remove the screw (a)(M3x8) and remove the rear lower cover (b) in the direction of the arrow.




Figure 4-312

4. Remove the screw (a)(M3x8) and remove the rear middle stay (b).




Figure 4-313

5. Release the wire (c) from the wire saddle (b) and disconnect the connector (a).
6. Remove two screws (d)(M3x8).
7. Remove the high voltage wire guide (e) in the direction of the arrow to release the protrusion (f) and hook (g).




Figure 4-314

8. Remove three screws (b)(M3x8).
9. Release two board supports (e).
10. Release two hooks (c).
11. Detach the high voltage PWB (a) while rotating it in the direction of the arrow making three hooks (d) as fulcrum.
12. Check or replace the high voltage PWB (a), and then reattach the parts in the original position.




Figure 4-315

(5-6) Detaching and reattaching the high voltage PWB (35/40 ppm models)

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-316

2. Remove the screw (a)(M3x8) and remove the rear right cover (b) in the direction of the arrow.




Figure 4-317

3. Remove the screw (a)(M3x8) and remove the rear lower cover (b) in the direction of the arrow.




Figure 4-318

4. Remove the screw (a)(M3x8) and remove the rear middle stay (b).

IMPORTANT

Check if the spring (d) is in the protrusion (c) when attaching the rear middle stay.




Figure 4-319

5. Release the wire (c) from the wire saddle (b) and disconnect the connector (a).
6. Remove two screws (d)(M3x8).
7. Remove the high voltage wire guide (e) in the direction of the arrow to release the protrusion (f) and hook (g).




Figure 4-320

8. Remove four screws (b)(M3x8).
9. Release two board supports (e).
10. Release two hooks (c).
11. Rotate the high voltage PWB (a) making the four hooks (d) into a fulcrum and detach it.
12. Check or replace the high voltage PWB (a), and then reattach the parts in the original position.




Figure 4-321

(5-7) Detaching and reattaching the power source PWB (30 ppm model)

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-322

2. Remove the screw (a)(M3x8) and remove the rear right cover (b) in the direction of the arrow.




Figure 4-323

3. Remove the screw (a)(M3x8) and remove the rear lower cover (b) in the direction of the arrow.




Figure 4-324

4. Remove the screw (a)(M3x8) and remove the rear middle stay (b).




Figure 4-325

5. Release the wire (c) from the wire saddle (b) and disconnect the connector (a).
6. Remove two screws (d)(M3x8).
7. Remove the high voltage wire guide (e) in the direction of the arrow to release the protrusion (f) and hook (g).




Figure 4-326

8. Remove three screws (b)(M3x8).
9. Release two board supports (e).
10. Release two hooks (c).
11. Detach the high voltage PWB (a) while rotating it in the direction of the arrow making three hooks (d) as fulcrum.




Figure 4-327

12. Release the wire (e) from the hook (a) and five wire saddles B (d).




Figure 4-328

13. Remove three screws (a)(M3x8).
14. Release the hook (b) and remove the transfer high voltage assembly (c).




Figure 4-329

IMPORTANT

When attaching the transfer high voltage assembly (a), check the hook (b) clicks.




Figure 4-330

15. Disconnect three connectors (a).
16. Remove the wire (b) from the two hooks (c).
17. Remove three screws (d)(M3x8) and remove the heater PWB holder plate (e).




Figure 4-331

18. Remove two screws (a)(M3x8).
19. Remove the PF drawer holder (c) by sliding it to the front and removing it from the lancing (b).

IMPORTANT

When attaching the PF drawer holder (c), make sure to hang it to the two lancing (b).




Figure 4-332

20. Disconnect all the connectors from the power source PWB (a).
21. Remove two screws (b)(M3x8).
22. Release the board support (c) and remove the power source PWB (a).
23. Check or replace the power source PWB (a), and then reattach the parts in the original position.




Figure 4-333

(5-8) Detaching and reattaching the power source PWB (35/40 ppm models)

Procedures

1. Remove two screws (a)(M3x8) and remove the rear left cover (b) by sliding it in the direction of the arrow.




Figure 4-334

2. Remove the screw (a)(M3x8) and remove the rear right cover (b) in the direction of the arrow.




Figure 4-335

3. Remove the screw (a)(M3x8) and remove the rear lower cover (b) in the direction of the arrow.




Figure 4-336

4. Remove the screw (a)(M3x8) and remove the rear middle stay (b).

IMPORTANT

Check if the spring (d) is in the protrusion (c) when attaching the rear middle stay.




Figure 4-337

5. Release the wire (c) from the wire saddle (b) and disconnect the connector (a).
6. Remove two screws (d)(M3x8).
7. Remove the high voltage wire guide (e) in the direction of the arrow to release the protrusion (f) and hook (g).




Figure 4-338

8. Remove four screws (b)(M3x8).
9. Release two board supports (e).
10. Release two hooks (c).
11. Rotate the high voltage PWB (a) making the four hooks (d) into a fulcrum and detach it.




Figure 4-339

12. Disconnect the connector (a) and release the wire saddle A(b).
13. Release the wire (e) from the hook (c) and four wire saddles B (d).




Figure 4-340

14. Remove three screws (a)(M3x8).
15. Release the hook (b) and remove the transfer high voltage assembly (c).




Figure 4-341

IMPORTANT

When attaching the transfer high voltage assembly (a), check the hook (b) clicks.




Figure 4-342

16. Disconnect three connectors (a).
17. Remove the wire (b) from the two hooks (c).
18. Remove three screws (d)(M3x8) and remove the heater PWB holder plate (e).




Figure 4-343

19. Remove two screws (a)(M3x8).
20. Remove the PF drawer holder (c) by sliding it to the front and removing it from the lancing (b).

IMPORTANT

When attaching the PF drawer holder (c), make sure to hang it to the two lancing (b).




Figure 4-344

21. Disconnect all the connectors from the power source PWB (a).
22. Remove three screws (b)(M3x8).
23. Release two hooks (c) and the board support (d), and remove the power source PWB (a).
24. Check or replace the power source PWB (a), and then reattach the parts in the original position.




Figure 4-345

(5-9) Detaching and reattaching the operation panel PWB (30 ppm model)

Procedures

1. Tilt up the operation unit (a).
2. Remove the screw (b)(M3x8).
3. Remove the operation lid (c) from the operation unit (a) in the direction of the arrow.




Figure 4-346

4. Remove the screw (a)(M3x8) and remove the upper exit cover (b).




Figure 4-347

5. Open the front cover (a).
6. Tilt down the operation unit (b).




Figure 4-348

7. Open the right cover.
8. Remove two screws (a)(M3x8).
9. Release two hooks (b) and remove the front eject cover (c).




Figure 4-349

10. Remove the wire (a) from the wire saddles (b).
11. Disconnect three connectors (d) and USB connector (e) from the operation unit (c).
12. Remove the screw (f)(M3x8) and remove the ground terminal (g).




Figure 4-350

13. Remove two screws (b)(M3x8) from the right hinge (a).
14. Remove the operation unit (c) from the left hinge (d) in the direction of the arrow.




Figure 4-351

15. Remove five screws (a)(M3x8).
16. Release two hooks (b) and remove the rear operation cover (d) from the operation cover (c).




Figure 4-352

17. Disconnect all FFCs and the connectors from the operation PWB (a).
18. Remove four screws (b)(M3x8) and ground wire (c).
19. Remove the operation PWB (a) from the operation cover (c).





Figure 4-353


(5-10) Detaching and reattaching the operation panel PWB (35/40 ppm models)

Procedures

1. Tilt up the operation unit (a).
2. Remove the screw (b)(M3x8).
3. Remove the operation lid (c) from the operation unit (a) in the direction of the arrow.

**Figure 4-354**

4. Remove the screw (a)(M3x8) and remove the upper exit cover (b).

**Figure 4-355**

5. Open the front cover (a).
6. Tilt down the operation unit (b).




Figure 4-356

7. Open the right cover.
8. Remove two screws (a)(M3x8).
9. Release two hooks (b) and remove the front eject cover (c).




Figure 4-357

10. Disconnect three connectors (b) from the operation unit (a).
11. Remove the wire (c) from the wire saddles (d).
12. Remove the screw (e)(M3x8) and remove the ground terminal (f).




Figure 4-358

13. Remove two screws (b)(M3x8) from the right hinge (a).
14. Remove the operation unit (c) from the left hinge (d) in the direction of the arrow.




Figure 4-359

- 15. Remove five screws (a)(M3x8).
- 16. Remove the operation rear cover (c) from the operation cover (b).




Figure 4-360

- 17. Disconnect all FFCs and the connectors from the operation PWB (c).
- 18. Remove four screws (a)(M3x8) and ground wire (d).
- 19. Remove the operation PWB (c) from the operation cover (b).






Figure 4-361

(6) Document processor: 30 ppm model only**(6-1) Detaching and reattaching the document processor****Procedures**

1. Remove the screw (a)(M3x8) and remove the rear right cover (b).
2. Release the DP interface wire (c) from the wire saddle(e) and remove it from the two connectors (d).

**Figure 4-362**

3. Open the document processor (a).
4. Lift up the document processor (a) in the direction of the arrow and remove the hinge (c) from the main unit (b).

**Figure 4-363**

(6-2) Detaching and reattaching the DP rear cover

Procedures

1. Open the DP top cover (b) of the document processor (a).




Figure 4-364

2. Release two hooks (b) with the flat-blade screwdriver (a) and remove the DP rear cover (d).




Figure 4-365

4-7 Disassembly & Reassembly (option)

(1) Paper feeder (PF-5120)

(1-1) Detaching and reattaching the PF drive unit

Procedures

1. Remove two screws (a)(M3x8).
2. Remove PF rear cover (c) from the paper feed unit (b).




Figure 4-366

3. Disconnect the connector (b) of the motor (a).
4. Remove three screws (b)(M3x8) and remove the PF drive unit (d).
5. Check or replace the PF drive unit (d), and then reattach the parts in the original position.




Figure 4-367

(1-2) Detaching and reattaching the PF lift motor

Procedures

1. Pull out the cassette (a) from the paper feeder (b) and remove it in the direction of the arrow.




Figure 4-368

2. Pinch the lock lever (c) and pull the primary paper feed unit (d).




Figure 4-369

3. Remove the connector (a) and two screws (b)(M3x8).
4. Release the hook (d) from the square hole (c) of the side frame and remove the sensor holder (e).




Figure 4-370

5. Remove the connector (a) and two screws (b)(M3x8).
6. Release the hook (d) from the square hole (c) of the side frame and remove the PF lift motor (e).
7. Check or replace the PF lift motor (e), and then reattach the parts in the original position.




Figure 4-371

(1-3) Detaching and reattaching the PF main PWB

Procedures

1. Remove two screws (a)(M3x8).
2. Remove PF rear cover (c) from the paper feed unit (b).




Figure 4-372

3. Disconnect all the connectors from the PF main PWB (a).
4. Remove two screws (b)(M3x8) and remove the PF main PWB (a).
5. Check or replace the PF main PWB (a), and then reattach the parts in the original position.





Figure 4-373

(2) Paper feeder (PF-5130)

(2-1) Detaching and reattaching the PF drive unit

Procedures

1. Remove two screws (a)(M3x8).
2. Remove PF rear cover (c) from the paper feed unit (b).




Figure 4-374

3. Release two wire saddles (d) and disconnect two connectors (a) of the PF drive unit.
4. Remove five screws (b)(M3x8) and remove the PF drive unit (c).
5. Check or replace the PF drive unit (c), and then reattach the parts in the original position.




Figure 4-375

(2-2) Detaching and reattaching the PF lift motor

Procedures

1. Pull out the upper cassette (a) from the paper feeder (b) and pull it out on an angle.
2. Pull out the lower cassette (a) from the paper feeder (b) and pull it out on an angle.




Figure 4-376

3. Pinch the lock lever (c) and pull the primary paper feed unit (d) from the upper stage.
4. Pinch the lock lever (c) and pull the primary paper feed unit (d) from the lower stage.




Figure 4-377

5. Disconnect the connector (b) of the upper sensor holder (a) and remove two screws (c)(M3X8).
6. Release the hook (e) from the square hole (c) of the side frame and remove the sensor holder (a).
7. Remove the sensor holder (a) of the lower stage as well.




Figure 4-378

8. Disconnect the connector (b) and remove two screws (c)(M3X8) of the upper stage PF lift motor (a).
9. Release the hook (e) from the square hole (d) of the side frame and remove the PF lift motor (a).
10. Remove the PF lift motor (a) of the lower stage as well.
11. Check or replace the PF lift motor (a), and then reattach the parts in the original position.





Figure 4-379

(2-3) Detaching and reattaching the PF main PWB

Procedures

1. Remove two screws (a)(M3x8).
2. Remove PF rear cover (c) from the paper feed unit (b).



3. Disconnect all the connectors from the PF main PWB (a).
4. Remove two screws (b)(M3x8).
5. Release two hooks (c) and remove the PF main PWB (a).
6. Check or replace the PF main PWB (a), and then reattach the parts in the original position.





Figure 4-381

(3) Paper feeder (PF-5140)

(3-1) Detaching and reattaching the PF drive unit

Procedures

1. Remove two screws (a)(M3x8).
2. Remove PF rear cover (c) from the paper feed unit (b).




Figure 4-382

3. Remove the connector (a) of the motor.
4. Remove three screws (b)(M3x8) and remove the PF drive unit (c).
5. Check or replace the PF drive unit (c), and then reattach the parts in the original position.




Figure 4-383

(3-2) Detaching and reattaching the PF lift motor

Procedures

1. Remove two screws (a)(M3x8).
2. Remove PF rear cover (c) from the paper feed unit (b).




Figure 4-384

3. Disconnect the connector (b) of the PF lift motor (a).
4. Remove three screws (b)(M3x8) and remove the PF lift motor (a).
5. Check or replace the PF lift motor (a), and then reattach the parts in the original position.




Figure 4-385

(3-3) Detaching and reattaching the PF main PWB

Procedures

1. Remove two screws (a)(M3x8).
2. Remove PF rear cover (c) from the paper feed unit (b).




Figure 4-386

3. Disconnect all the connectors from the PF main PWB (a).
4. Remove two screws (b)(M3x8).
5. Release two hooks (c) and remove the PF main PWB (a).
6. Check or replace the PF main PWB (a), and then reattach the parts in the original position.




Figure 4-387

(4) Document processor (DP-5100): 35/40 ppm models only

(4-1) Detaching and reattaching the document processor

Procedures

1. Remove the screw (a)(M3x8) and remove the rear right cover (b).
2. Release the DP interface wire (c) from the wire saddle(e) and remove it from the two connectors (d).




Figure 4-388

3. Open the document processor (a).
4. Lift up the document processor (a) in the direction of the arrow and remove the hinge (c) from the main unit (b).




Figure 4-389

(4-2) Detaching and reattaching the DP rear cover

Procedures

1. Open the DP top cover (b) of the document processor (a).




Figure 4-390

2. Release two hooks (b) with the flat-blade screwdriver (a) and remove the DP rear cover (d).




Figure 4-391

(4-3) Detaching and reattaching the DP main PWB

Procedures

1. Open the DP top cover (b) of the document processor (a).




Figure 4-392

2. Release two hooks (b) with the flat-blade screwdriver (a) and remove the DP rear cover (d).




Figure 4-393

3. Remove the screw (a)(M3x8).
4. Release two hooks (c) with the flat-blade screwdriver (b) and remove the DP rear right cover (d).




Figure 4-394

5. Remove two screws (a)(M3x8).
6. Disconnect all the connectors from the DP main PWB (b).
7. Detach the DP main PWB (b) from the document processor (c).
8. Check or replace the DP main PWB (b), and then reattach the parts in the original position.






Figure 4-395

(5) Document processor (DP-5110): 35/40 ppm models only**(5-1) Detaching and reattaching the document processor****Procedures**

1. Remove the screw (a)(M3x8) and remove the rear right cover (b).
2. Release the DP interface wire (c) from the wire saddle(e) and remove it from the three connectors (d).
3. Remove the CIS connector (g) while pulling the release lever (f).

**Figure 4-396**

4. Open the document processor (a).
5. Lift up the document processor (a) in the direction of the arrow and remove the hinge (c) from the main unit (b).

**Figure 4-397**

(5-2) Detaching and reattaching the DP rear cover

Procedures

1. Open the DP top cover (b) of the document processor (a).




Figure 4-398

2. Release two hooks (b) with the flat-blade screwdriver (a) and remove the DP rear cover (d).




Figure 4-399

(5-3) Detaching and reattaching the DP main PWB

Procedures

1. Open the DP top cover (b) of the document processor (a).




Figure 4-400

2. Release two hooks (b) with the flat-blade screwdriver (a) and remove the DP rear cover (c).




Figure 4-401

3. Remove the screw (a)(M3x8).
4. Release two hooks (c) with the flat-blade screwdriver (b) and remove the DP rear right cover (d).




Figure 4-402

5. Remove two screws (a)(M3x8).
6. Disconnect all the connectors from the DP main PWB (b).
7. Detach the DP main PWB (b) from the document processor (c).
8. Check or replace the DP main PWB (b), and then reattach the parts in the original position.




Figure 4-403

(5-4) Detaching and reattaching the CIS

Procedures

1. Remove the screw (a)(M3x8) and remove the rear right cover (b).
2. Remove the CIS connector (c) while pulling the release lever (d).




Figure 4-404

3. Open the DP top cover (b) of the document processor (a).




Figure 4-405

4. Release two hooks (b) with the flat-blade screwdriver (a) and remove the DP rear cover (d).




Figure 4-406

5. Remove the screw (a)(M3x8).
6. Release two hooks (c) with the flat-blade screwdriver (b) and remove the DP rear right cover (d).




Figure 4-407

7. Push the lock lever (a) toward the machine rear side.
8. Release the hook (b).
9. Rotate the lock lever (a) to the release position (c).
10. Shift the machine front side of the DP paper feed roller shaft (d) toward the machine left side to remove it from the holding part (e).
11. Then, lift the shaft and pull the DP paper feed roller unit (f) out toward the machine front side.




Figure 4-408

12. Remove the relay wire connector (a).
13. Release the wire saddle (b) and pull out the wire and CIS connector wire.




Figure 4-409

14. Remove two screws (a)(M3x8).
15. Remove the jam clearing dial (b).




Figure 4-410

16. Remove four screws (a)(M3x8).
 17. Slide the conveying guide (b) in the direction of the arrow by the amount of backlash.
- *: Release the protrusion (c) of the CIS guide.






Figure 4-411

18. Remove four screws (a)(M3x8).
19. Detach the CIS assembly (b) in the direction of the arrow.

**Figure 4-412**

20. Remove two FFCs (c) from the SHD PWB (b) at the backside of the CIS assembly (a).

**Figure 4-413**

21. Release two hooks (b) of the front and rear glass holder (a) while pressing it in the direction of the arrow and remove it.
22. Remove CIS glass (d), front and rear spacers (e) from the CIS assembly (c).

*: The front and rear spacers (e) are not fixed. Take care not to lose them.

IMPORTANT

Check the position of black marking (f) for distinction of the surface / back side of the glass. Also, make sure not to touch the glass surface. If it is dirty, wipe it off with a dry cloth.




Figure 4-414

23. Detach the CIS assembly (b) in the direction of the arrow.
- *: Take care not to lose two springs (e).
24. Remove three screws (b)(M3x8) and remove the SHD PWB (d) from the CIS assembly (c).
25. Check or replace the CIS assembly (a), and then reattach the parts in the original position.

IMPORTANT

When assembling, check the spring (e) is in the boss of the CIS assembly (c).




Figure 4-415

(6) Finisher (DF-5100)

(6-1) Detaching and reattaching the DF main PWB

Procedures

1. Slide the DF main unit (a) in the direction of the arrow.
2. Remove the screw (b)(M3x8) and remove the DF front right cover (c).




Figure 4-416

3. Remove two screws (a)(M3x8).
4. Detach the inner finisher (c) from the main unit (b).




Figure 4-417

5. Remove two screws (a)(M3x8).
6. Remove the DF rear cover (b) in the direction of the arrow.




Figure 4-418

7. Disconnect all the connectors from the DF main PWB (a).
8. Remove four screws (b)(M3x8) and remove the DF main PWB (a).
9. Check or replace the DF main PWB (a), and then reattach the parts in the original position.







Figure 4-419

(7) Finisher (DF-5110): 35/40 ppm models only**(7-1) Detaching and reattaching the staple unit****Procedures**

1. Open the DF front cover (a).
2. Pull out the waste toner box and remove it.

**Figure 4-420**

3. Insert a flat-blade screwdriver (c) under the lever (b) of the staple cover (a) and lift it up to release the lock and open the staple cover (a).

**Figure 4-421**

4. Disconnect two connectors (b) from the staple unit (a).




Figure 4-422

5. Lift up the staple unit (a) from the front side to release the hook (b) and pull it out toward you.
6. Check or replace the staple unit (a), and then reattach the parts in the original position.




Figure 4-423

(7-2) Detaching and reattaching the DF main PWB

Procedures

1. Remove two screws (a)(M3x8).
2. Release five hooks (b) and remove the DF rear cover (c).




Figure 4-424

3. Disconnect all the connectors from the DF main PWB (a).
4. Remove four screws (b)(M3x8) and remove the DF main PWB (a).
5. Check or replace the DF main PWB (a), and then reattach the parts in the original position.






Figure 4-425

(8) Finisher (DF-5120): 35/40 ppm models only**(8-1) Detaching and reattaching the staple unit****Procedures**

1. Open the DF front cover (a).
2. Pull out the waste toner box and remove it.

**Figure 4-426**

3. Insert a flat-blade screwdriver (c) under the lever (b) of the staple cover (a) and lift it up to release the lock and open the staple cover (a).

**Figure 4-427**

4. Disconnect two connectors (b) from the staple unit (a).




Figure 4-428

5. Lift up the staple unit (a) from the front side to release the hook (b) and pull it out toward you.
6. Check or replace the staple unit (a), and then reattach the parts in the original position.




Figure 4-429

(8-2) Detaching and reattaching the DF main PWB

Procedures

1. Remove five screws (a)(M3x8).
2. Release four hooks (b) and remove the DF rear cover (c).




Figure 4-430

3. Disconnect all the connectors from the DF main PWB (a).
4. Remove four screws (b)(M3x8) and remove the DF main PWB (a).
5. Check or replace the DF main PWB (a), and then reattach the parts in the original position.





Figure 4-431

5 Firmware

5-1 Firmware update (30 ppm model)

Execute the following to update the firmware below.

*: The processing time is reduced with simultaneous processing by group.

[GROUP1 UPDATE]

| Target firmware name | Master file name | Message |
|---|------------------|---------|
| Optional language data (Optional language data for the controller) | DL_OPT.2R4 | OPT |
| Controller firmware | DL_CTRL.2R4 | CTRL |
| First color table data (Printer) | DL_PCLT1.2R4 | P-CLUT1 |
| Second color table data (Printer) | DL_PCLT2.2R4 | P-CLUT2 |
| First color table data (Copy) | DL_CCLT1.2R4 | C-CLUT1 |
| Second color table data (Copy) | DL_CCLT2.2R4 | C-CLUT2 |

[GROUP2 UPDATE]

| Target firmware name | Master file name | Message |
|----------------------|------------------|---------|
| FAX firmware | DL_FAX.2R4 | FAX |

[GROUP3 UPDATE]

| Target firmware name | Master file name | Message |
|---|------------------|----------|
| Mail Box | DL_03R0.2R6 | MAIL-BOX |
| Inner DF | DL_03PX.2R6 | INNER-DF |
| Firmware for the second PF (paper feeder) | DL_03PZ.2R6 | PF2 |
| Firmware for the first PF (paper feeder) | DL_03PZ.2R6 | PF1 |
| Engine firmware | DL_ENGN.2R4 | ENGN |

[GROUP4 UPDATE]: No applicable firmware is available.

[GROUP5 UPDATE]

| Target firmware name | Master file name | Message |
|--|------------------|---------|
| Optional language data (Optional language data for the Panel) | DL_OPT.2R4 | OPT |
| Dictionary data | DL_DIC.2R4 | DIC |
| Browser data | DL_BRWS.2R4 | BRWS |
| Panel firmware | DL_PANL.2R4 | PANL |

Verify the signature at firmware update

Verify the signature of the update file to prevent the firmware update with illegally falsified data.

File names of the signature and firmware certificate

| Target | Signature file name | Firmware certificate file name |
|-----------------------------------|---------------------|--------------------------------|
| Controller data | 2R4_CTRL_sign.bin | 2R4_CTRL_cert.pem |
| Panel data | 2R4_PANL_sign.bin | 2R4_PANL_cert.pem |
| Optional language data | 2R4_OPT_sign.bin | 2R4_OPT_cert.pem |
| Dictionary data | 2R4_DIC_sign.bin | 2R4_DIC_cert.pem |
| Browser data | 2R4_BRWS_sign.bin | 2R4_BRWS_cert.pem |
| Color table 1 (Printer) | 2R4_PCLT1_sign.bin | 2R4_PCLT1_cert.pem |
| Color table 2 (Printer) (Printer) | 2R4_PCLT2_sign.bin | 2R4_PCLT2_cert.pem |
| First color table data (Copy) | 2R4_CCLT1_sign.bin | 2R4_CCLT1_cert.pem |
| Second color table data (Copy) | 2R4_CCLT2_sign.bin | 2R4_CCLT2_cert.pem |
| FAX PWB | 2R4_FAX_sign.bin | 2R4_FAX_cert.pem |
| Engine PWB | 2R4_ENGN_sign.bin | 2R4_ENGN_cert.pem |
| PF | 2R6_03PZ_sign.bin | 2R6_03PZ_cert.pem |
| Inner DF | 2R6_03PX_sign.bin | 2R6_03PX_cert.pem |
| Mail Box | 2R6_03R0_sign.bin | 2R6_03R0_cert.pem |

Preparations

Unzip the file containing the downloaded firmware and then copy the firmware, high-speed master file (skip files: ES_SKIP.ON) and the file for signature verification in the root folder of the USB memory.

*: If the high-speed master file exists, the same version firmware update is skipped.

Procedures

1. Turn the power switch (a) on and "Ready to copy" is displayed. After checking that the screen is properly displayed, turn the power switch (a) off.
2. Insert the USB memory (b) with the firmware into the USB memory slot (c).
3. Turn the power switch (a) on.




Figure 5-1

4. "FW-Update" and the progress indicator is displayed.

*: Several kinds of firmware updates are processed simultaneously.




Figure 5-2

5. "Completed" is displayed when the firmware update is completed.

6. Check if the new firmware versions are displayed.




Figure 5-3

*: When there is no corresponding master file, "No Change" is displayed.

**" is displayed after the firmware version update that has been skipped.

*: "-----" is displayed when the FAX PWB, optional equipment, etc. are not installed.

*: The result of the signature verification is indicated as follows.

| Official signature verification file | Indicate the result |
|--|---------------------|
| Both certificate and signature files exist and verification is successful. | Version number |
| Both certificate and signature files exist but verification is unsuccessful. | S000 |
| Neither certificate nor signature files exist. Or either of them does not exist. | S001 |

7. Unplug the power cord and disconnect the USB memory.

8. Plug in the power cord and turn the power switch (a) on.

*: 30ppm model due to its construction may indicate the operation display momentarily when connecting the power cord.

9. Check that the "Home" screen is displayed and then turn the power switch (a) off.

Precautions

Never turn the power switch (a) off or disconnect the USB memory (b) during the firmware update.

Safe-Update

When the firmware update was interrupted by power shut-off or disconnecting the USB memory during the firmware update, the firmware update is retried at the next power-on.

Turn the main power on again while the USB memory is installed.

*: The firmware update that was already completed before power shut-down is skipped.

5-2 Firmware update (35/40 ppm model)

Perform the following to update the firmware below.

*: The processing time is reduced with simultaneous processing by group.

[GROUP1 UPDATE]

| Target firmware name | Master file name | Message |
|-----------------------------------|------------------|---------|
| Controller firmware | DL_CTRL.2R6 | CTRL |
| Panel data | DL_PANL.2R6 | PANL |
| Optional language data | DL_OPT.2R6 | OPT |
| Dictionary data | DL_DIC.2R6 | DIC |
| Browser data | DL_BRWS.2R6 | BRWS |
| First color table data (Printer) | DL_PCLT1.2R6 | P-CLUT1 |
| Second color table data (Printer) | DL_PCLT2.2R6 | P-CLUT2 |
| First color table data (Copy) | DL_CCLT1.2R6 | C-CLUT1 |
| Second color table data (Copy) | DL_CCLT2.2R6 | C-CLUT2 |
| OCR dictionary data | DL_OCR.2R6 | OCR |

[GROUP2 UPDATE]

| Target firmware name | Master file name | Message |
|----------------------|------------------|---------|
| Slot 1 FAX firmware | DL_FAX.3R2 | FAX1 |
| Slot 2 FAX firmware | DL_FAX.3R2 | FAX2 |

[GROUP3 UPDATE]

| Target firmware name | Master file name | Message |
|---|------------------|----------|
| Mail Box | DL_03R0.2R6 | MAIL-BOX |
| PUNCHUNIT | DL_03R1.2R6 | P-UNIT |
| DF | DL_03PW.2R6 | DF |
| Inner DF | DL_03PX.2R6 | INNER-DF |
| Firmware for the second PF (paper feeder) | DL_03PZ.2R6 | PF2 |
| Firmware for the first PF (paper feeder) | DL_03PZ.2R6 | PF1 |
| Engine firmware | DL_ENGN.2R6 | ENGN |

[GROUP4 UPDATE]: No applicable firmware is available.

[GROUP5 UPDATE]

| Target firmware name | Master file name | Message |
|----------------------|------------------|---------|
| Panel firmware | DL_PANL.2R6 | PANL |

[GROUP6 UPDATE]

| Target firmware name | Master file name | Message |
|----------------------|------------------|---------|
| Energy saver CPU | DL_ECMM.2R6 | ECMM |

Verify the signature at firmware update

Verify the signature of the update file to prevent the firmware update with illegally falsified data.

File names of the signature and firmware certificate

| Target | Signature file name | Firmware certificate file name |
|--------------------------------|---------------------|--------------------------------|
| Controller data | 2R6_CTRL_sign.bin | 2R6_CTRL_cert.pem |
| Panel data | 2R6_PANL_sign.bin | 2R6_PANL_cert.pem |
| Optional language data | 2R6_OPT_sign.bin | 2R6_OPT_cert.pem |
| Dictionary data | 2R6_DIC_sign.bin | 2R6_DIC_cert.pem |
| Browser data | 2R6_BRWS_sign.bin | 2R6_BRWS_cert.pem |
| Color table 1 (Printer) | 2R6_PCLT1_sign.bin | 2R6_PCLT1_cert.pem |
| Color table 2 (Printer) | 2R6_PCLT2_sign.bin | 2R6_PCLT2_cert.pem |
| First color table data (Copy) | 2R6_CCLT1_sign.bin | 2R6_CCLT1_cert.pem |
| Second color table data (Copy) | 2R6_CCLT2_sign.bin | 2R6_CCLT2_cert.pem |
| OCR dictionary data | 2R6_OCR_sign.bin | 2R6_OCR_cert.pem |
| FAX PWB | 3R2_FAX_sign.bin | 3R2_FAX_cert.pem |
| Engine PWB | 2R6_ENGN_sign.bin | 2R6_ENGN_cert.pem |
| PF | 2R6_03PZ_sign.bin | 2R6_03PZ_cert.pem |
| DF | 2R6_03PW_sign.bin | 2R6_03PW_cert.pem |
| Inner DF | 2R6_03PX_sign.bin | 2R6_03PX_cert.pem |
| Mail Box | 2R6_03R0_sign.bin | 2R6_03R0_cert.pem |
| PUNCHUNIT | 2R6_03R1_sign.bin | 2R6_03R1_cert.pem |
| Panel PWB | 2R6_SPNL_sign.bin | 2R6_SPNL_cert.pem |
| Energy saver CPU | 2R6_ECMM_sign.bin | 2R6_ECMM_cert.pem |

Preparations

Unzip the file containing the downloaded firmware and then copy the firmware and high-speed master file (skip files: ES_SKIP.ON) in the root folder of the USB memory.

*: If the high-speed master file exists, the same version firmware update is skipped.

Procedures

1. After turning the power switch (a) on and the screen is properly displayed, turn the power switch (a) off.
2. Insert the USB memory (b) with the firmware into the USB memory slot.
3. Turn the power switch (a) on.




Figure 5-4

4. "FW-Update" and the progress indicator is displayed.

*: Several kinds of firmware updates are processed simultaneously.




Figure 5-5

5. "Completed" is displayed when the firmware update is completed.

6. Check if the new firmware versions are displayed.




Figure 5-6

*: When there is no corresponding master file, "No Change" is displayed.

"*" is displayed after the firmware version update that has been skipped.

*: "-----" is displayed when the FAX PWB, the option equipment, etc. is not installed.

*: The result of the signature verification is indicated as follows.

| Official signature verification file | Indicate the result |
|--|---------------------|
| Both certificate and signature files exist and verification is successful. | Version number |
| Both certificate and signature files exist but verification is unsuccessful. | S000 |
| Neither certificate nor signature files exist. Or either of them does not exist. | S001 |

7. Unplug the power cord and disconnect the USB memory.

8. Plug in the power cord and turn the power switch (a) on.

9. Check that the "Home" screen is displayed and then turn the power switch (a) off.

Precautions

Never turn the power switch (a) off or disconnect the USB memory (b) during the firmware update.

Safe-Update

When the firmware update was interrupted by power shut-off or disconnecting the USB memory during the firmware update, the firmware update is retried at the next power-on.

Turn the main power on again while the USB memory is installed.


*: The firmware update that was already completed before power shut-down is skipped.

6 Maintenance mode

6-1 Maintenance mode

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing the maintenance mode



(2) Maintenance modes list (30ppm model)

| Section | No. | Maintenance item | Outline |
|---|------------------|--|---|
| General | U000 | Printing Maintenance Report | Printing the reports and exporting them to a USB memory |
| | U001 | Exiting the maintenance mode | Exiting from the maintenance mode |
| | U002 | Set Factory Default | Initializing to the factory-default setting |
| | U004 | Machine serial number | Display of the machine serial number and setting |
| | U010 | Setting the maintenance mode ID | Setting the maintenance mode ID |
| | U019 | Firmware Version | Displays the firmware version of the PWB |
| Initializa- tion | U021 | Initializes Memory | Initializing the backup RAM |
| | U025 | Firmware update (S) | Updates the firmware |
| Drive Paper feed Convey- ing Cooling | U030 | Motor operation check | Drive the drive motor |
| | U031 | Check the conveying switch | Check the conveying switch On/Off |
| | U032 | Clutch operation check | Check the paper conveying clutch operation |
| | U033 | Solenoid operation check | Drive the paper conveying and toner supply solenoids |
| | U034 | Paper timing adjustment | Adjusting the leading edge timing and the center line |
| | U035 | Folio size setting | Sets the Folio paper length and width. |
| | U037 | Fan motor operation check | Drive each fan motor. |
| | | | |
| | U051 | Registration paper loop amount adjustment | Adjusts the paper loop amount between the rollers |
| | U053 | Adjusting the motor speed | Sets each motor's speed correction |
| U059 | Fan mode setting | Sets the drive mode of the conveying fan motor | |
| Optical | U065 | Adjusting the magnification for table scanning | Adjusting the magnification for table scanning |
| | U066 | Adjusting the table scanning timing | Adjusting the leading edge timing for table scanning |
| | U067 | Adjusting the table scanning center line | Adjusting the center line for table scanning |
| | U068 | DP scanning position adjustment | Adjusting the starting position for DP scanning |
| | U070 | DP magnification adjustment | Adjusting the magnification for DP scanning |
| | U071 | Adjusting the DP leading edge Timing | Adjusting the DP scanning timing |
| | U072 | Adjusting the DP original center | Adjusting the center line for DP scanning |
| | U089 | MIP-PG pattern output | Output MIP-PG pattern |

| Section | No. | Maintenance item | Outline |
|----------------------------|------|--|---|
| High voltage system | U100 | Main high voltage adjustment | Adjust the drum surface potential |
| | U101 | Primary transfer voltage adjustment | Sets high voltage except the main high voltage and outputs |
| | U106 | Secondary transfer voltage adjustment | Set the secondary transfer voltage correction |
| | U107 | Primary transfer cleaning voltage adjustment | Set the primary transfer belt cleaning voltage |
| | U110 | Drum counter | Displays/sets the drum counter |
| | U117 | Drum unit number | Displays the drum number |
| | U118 | Drum unit history | Displays the drum history |
| | U119 | Setting the drum | Sets the initial LSU light intensity |
| | U120 | Drum drive distance counter | Displays the drum drive distance counter |
| | U127 | Clearing the transfer count | Displaying the counts |
| | U128 | Leading edge timing | Adjust the transfer high-voltage output ON/OFF timing |
| Developer system | U132 | Forcible toner supply operation | Execute the toner supply in the toner control level |
| | U135 | Checking the toner motor operation | Drives the toner motor |
| | U136 | Toner level detection setting | Sets the number of pages printable at toner near end |
| | U139 | Temperature, humidity | Displays the machine inside and outside humidity |
| | U140 | Developer bias adjustment | Adjust the developer bias values or set the high altitude mode. |
| | U147 | Setting the toner applying mode | Sets the overcharge toner removal mode |
| | U148 | Drum refresh mode setting | Setting auto drum refresh |
| | U155 | Toner sensor output | Displays the toner sensor output |
| | U156 | Toner control level adjustment | Displays/adjusts the toner supply level |
| | U157 | Developer drive time | Displays/sets the developer drive time |
| | U158 | Developer counter | Displays/sets the developer counter |
| Fuser | U161 | Fuser temperature adjustment | Sets the fuser control temperature |
| | U167 | Clearing the fuser count | Displaying/clearing the counts |
| | U199 | Fuser temperature | Monitor the fuser temperature |

| Section | No. | Maintenance item | Outline |
|--|--------------------------------|--|---|
| Operation section / Support equipment | U200 | All LEDs lighting | Light all the LEDs on the operation panel |
| | U201 | Initializing the touch panel | Correct the X and Y axis position of the touch panel |
| | U203 | Check DP operation | Checking the DP paper conveying operation with the DP alone |
| | U207 | Operation key check | Check the operation panel key operation |
| | U211 | Enhancement unit connection setting | Sets the connection of the enhancement units |
| | U221 | USB host lock function setting | Sets USB Host lock function ON/OFF |
| | U222 | Setting the IC card type | Sets the ID card type |
| | U223 | Operation panel lock | Set On/Off of the operation unit lock |
| | U230 | Optional device serial number | Displays the optional device serial number |
| | U240 | Finisher operation check | Checks the drive operation |
| | U241 | Finisher switch check | Check the switch operation |
| | U243 | Checking the DP motor | Drive the PF motor and solenoid |
| | U244 | DP switch check | Drive the DP sensor |
| | U246 | Finisher adjustment | Sets the finisher adjustment value |
| U247 | Paper feed operation check | Drives the PF motor and clutch | |
| Mode Setting | U250 | Checking/clearing the maintenance cycle | Changes the preset value |
| | U251 | Checking/clearing the maintenance counter | Displaying/clearing/changing the counter value |
| | U252 | Destination | Sets the machine operation and indication depending on the specification of the destination |
| | U253 | Switching the double/single counts | Sets the counter by color mode |
| | U260 | Switching the timing for copy counting | Setting the count-up timing |
| | U265 | Setting by destination | Sets the OEM code |
| | U276 | Switching the copy count mode | Set the single color copy count mode |
| | U278 | Delivery date setting | Register Delivery Date |
| | U284 | Setting the 2-color copy | Switches the 2-color copy mode |
| | U285 | Set Service Status Page | Setting the print coverage report output |
| | U290 | Setting the drive to save the HyPAS application | Sets the drive to save the HyPAS application |
| | U323 | Abnormal temperature and humidity notification setting | Switches the indication mode of the abnormal temperature and humidity detection |
| | U325 | Paper interval setting | Sets the print interval at high coverage |
| | U326 | Black line cleaning indication | Switch the black line cleaning guidance indication |
| U327 | Cassette heater On/Off setting | Selects the cassette heater control setting | |

| Section | No. | Maintenance item | Outline |
|-------------------------|------------|--|--|
| Mode Setting | U332 | Adjusting the black coverage coefficient | Setting the coefficient of the custom size |
| | U341 | Printer cassette setting | Sets the cassette to printer output only |
| | U343 | Duplex priority mode | Switches the duplex printing priority mode |
| | U345 | Setting the value for maintenance due indication | Setting the maintenance timing display |
| | U346 | Selecting Sleep Mode | Setting the BAM related sleep mode |
| Image processing | U402 | Adjusting the printing margins | Adjusts the scan image margins |
| | U403 | Adjusting margins for scanning an original on the contact glass | Adjusts the margin for scanning originals |
| | U404 | Adjusting margins for scanning an original from the document processor | Adjusts the margin for scanning originals |
| | U407 | Adjusting the writing timing (Duplex/Reversal) | Adjusting the writing timing when duplex printing |
| | U410 | Adjusting the halftone automatically | Acquiring the data for the automatic halftone adjustment and the ID correction |
| | U411 | Scanner auto adjustment | Adjusting the scanner and DP automatically |
| | U425 | Set Target | Inputs the Lab value printed on an adjustment original |
| | U429 | Adjusting the color balance offset | Adjusts the color balance offset |
| | U464 | ID correction setting | Sets the ID correction |
| | U465 | ID correction data | Displays the light intensity control value after the ID correction |
| | U467 | Color registration correction operation setting | Sets the color registration correction |
| | U468 | Color registration correction data | Displays the color registration correction data |
| | U469 | Color registration adjustment | Corrects the color registration |
| | U470 | Setting the JPEG compression rate | Sets the JPEG compression rate |
| Image processing | U474 | Checking the LSU cleaning | Sets the LSU cleaning operation check and cleaning cycle |
| | U485 | Image process mode setting | Sets the image processing |
| | U486 | Color/BW mode setting | Sets the image processing |
| | U520 | TDRS setting | Checking/setting the TDRS |

| Section | No. | Maintenance item | Outline |
|---------|----------------------------|---|--|
| FAX | U600 | Initialize: All Data | Initializes all data and image memory. |
| | U601 | Initialize: Keep data | Initializing the software switches of other than the machine data |
| | U603 | User data 1 | Makes user settings to enable the use as a FAX |
| | U604 | User data 2 | Makes user settings to enable the use as a FAX |
| | U605 | Data clear | Initializing the FAX communication data |
| | U610 | System 1 | Set the number of lines to be ignored when receiving a FAX at 100% magnification and in the auto reduction mode. |
| | U611 | System 2 | Number of adjustment lines for automatic reduction. |
| | U612 | System 3 | Setting regarding the FAX communication operation |
| | U620 | FAX system | Sets the signal detection method for remote switching |
| | U625 | Communication settings | Sets the auto redialing interval and the number of times of auto redialing |
| | U630 | Communication control procedures 1 | Setting the FAX communication |
| | U631 | Communication control procedures 2 | Sets the FAX communication |
| | U632 | Communication control procedures 3 | Setting the FAX communication |
| | U633 | Communication control procedures 4 | Setting the FAX communication |
| | U634 | Communication control procedures 5 | Set the acceptable error when judging the received TCF signal |
| | U640 | Communication time setting 1 | Setting the detection time by remote switching mode |
| | U641 | Communication time setting 2 | Sets the time-out time for the fax communication |
| | U650 | Modem 1 | Sets the G3 transmission cable equalizer |
| | U651 | Modem 2 | Sets the modem output level |
| | U660 | Ring setting | Setting the NCU (network control unit) |
| | U670 | List output | Outputting the list of the FAX communication data |
| U695 | FAX function customization | FAX batch transmission is set up. | |
| U699 | Software switch: Set | Sets the software switches individually | |

| Section | No. | Maintenance item | Outline | |
|----------------|------------------------|--|--|--|
| Others | U901 | Clearing the counters by paper source | Displays/clears the counters by paper source | |
| | U903 | Clearing the jam counter | Displays/clears number of occurrence by jam trigger code | |
| | U904 | Clearing the service call error counter | Displays/clears the service call error and system error counts | |
| | U905 | Optional counter | Displaying the counts | |
| | U906 | Resetting the partial operation | Resets the partial operation | |
| | U908 | Total counter | Displays the FAX count | |
| | U910 | Black rate data | Clearing the print coverage data and its period | |
| | U911 | Counter by media type | Displays/clears the counts by media type | |
| | U917 | Read/Write Backup Data | Reading/writing the backup data to a USB memory | |
| | U920 | Billing counter | Displays the billing count | |
| | U927 | Clearing all the billing/life counters | Clearing the billing count and machine life count | |
| | U928 | Machine life counter | Displays the machine life count | |
| | U930 | Clear the main charger roller counts | Displaying/setting the counts | |
| | | | | |
| | U952 | Maintenance mode workflow | Execute the maintenance flow with the Workflow data | |
| | U964 | Log check | Transfer the log files to a USB memory | |
| | U969 | Toner area code | Displays the toner area code | |
| | U977 | Setting the data capture mode | Stores the data sent to the main unit into a USB memory | |
| | U984 | Developer unit number | Displays the developer unit number | |
| U985 | Developer unit history | Displays the developer unit number history | | |
| U991 | Scanner counter | Displays the scanner count | | |

(2-1) Content of the maintenance mode (30ppm model)

| | |
|-------------|---|
| U000 | Printing Maintenance Report (Message: Mainte Report) |
|-------------|---|

Contents

Prints the list of the current settings of the maintenance items, paper jam and service call error occurrences. Output the event log and service status page.

Also, sends output data to a USB memory.

Purpose

Checks the current settings of the maintenance items, paper jam and service call error occurrences.

Before initializing or replacing the backup memory, print the list of the current settings of the maintenance items to reenter the settings after initialization or replacement.

Method

1. Press the [Start] key.
2. Select the item to output.

| Items | Output list |
|-----------------------|-------------------------------|
| Maintenance | Maintenance mode setting list |
| User Status | Output User Status Page |
| Service Status | Output Service Status Page |
| Event | Output the event log report |
| Network Status | Output Network Status Page |
| All | All reports output |

3. Turn it On/Off by the [◀] [▶] keys.

4. Press the [Start] key.

* : Insert a USB memory into the USB memory slot to output to it.

5. Select the item to output.

| Items | Output list |
|------------------|---|
| Print | A report is printed. |
| USB(Text) | Destination: send to USB memory (text format) |
| USB(HTML) | Destination: send to USB memory (HTML format) |

6. Press the [Start] key to output the list.

* : If A4 paper is available, it is output with this size. If A4 paper is unavailable, select the paper source. Output status is displayed.

* : The output data is sent to the USB memory.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

Detail of event log

Event Log

MFP (2) 2014/10/19 15:15

TASKalfa 406ci (3) [XXXXXXXX] (4) [XXXXXXXX] (5) [XXXXXXXX]

(1) Firmware version 2R6_2000.000.000 2014.09.19

(7) Paper Jam Log

| # | Count. | Event Descriptions | Date and Time |
|----|---------|--------------------|------------------|
| 12 | 5555555 | 0501.01.08.01.00 | 2014/02/12 17:30 |
| 11 | 4444444 | 4002.01.08.01.00 | 2014/02/12 17:30 |
| 10 | 3333333 | 0501.01.08.01.00 | 2014/02/12 17:30 |
| 9 | 2222222 | 4002.01.08.01.00 | 2014/02/12 17:30 |
| 8 | 1111111 | 0501.01.08.01.00 | 2014/02/12 17:30 |
| 7 | 9999999 | 4002.01.08.01.00 | 2014/02/12 17:30 |
| 6 | 8888888 | 0501.01.08.01.00 | 2014/02/12 17:30 |
| 5 | 7777777 | 0501.01.08.01.00 | 2014/02/12 17:30 |
| 4 | 6666666 | 4002.01.08.01.00 | 2014/02/12 17:30 |
| 3 | 5555555 | 0501.01.08.01.00 | 2014/02/12 17:30 |
| 2 | 4444444 | 4002.01.08.01.00 | 2014/02/12 17:30 |
| 1 | 1 | 4002.01.08.01.00 | 2014/02/12 17:30 |

(11) Counter Log

| (f) | Count | Item | Count |
|--------|-------|------------|-------|
| J0000: | 0 | J4302: | 0 |
| J0100: | 1 | J4303: | 1 |
| J0101: | 11 | J4304: | 11 |
| J0104: | 222 | J4309: | 2 |
| J0105: | 1 | J9000: | 1 |
| J0106: | 1 | J9004: | 0 |
| J0107: | 1 | J9010: | 1 |
| J0110: | 1 | J9060: | 1 |
| J0111: | 1 | J9061: | 2 |
| J0211: | 1 | J9062: | 1 |
| J0212: | 1 | J9110: | 1 |
| J0213: | 999 | J9120: | 0 |
| J0501: | 1 | J9200: | 1 |
| J0502: | 1 | J9210: | 1 |
| J0503: | 1 | J9220: | 2 |
| J0504: | 1 | | |
| J0508: | 1 | (g) C0000: | 0 |
| J0509: | 1 | C0001: | 1 |
| J0511: | 1 | C0002: | 2 |
| J0512: | 1 | C0003: | 3 |
| J0513: | 1 | C0004: | 4 |
| J0514: | 1 | C0005: | 5 |
| J0518: | 1 | C0006: | 6 |
| J0519: | 1 | C0007: | 7 |
| J1403: | 1 | C0008: | 8 |
| J1404: | 1 | C0009: | 9 |
| J1413: | 1 | C0010: | 10 |
| J1414: | 1 | C0011: | 11 |
| J1604: | 1 | C0012: | 12 |
| J1614: | 1 | C0013: | 13 |
| J4002: | 1 | C0014: | 14 |
| J4003: | 1 | C0015: | 15 |
| J4004: | 1 | C0016: | 16 |
| J4009: | 1 | C0017: | 17 |
| J4012: | 1 | C0018: | 18 |
| J4013: | 1 | C0019: | 19 |
| J4014: | 1 | C0020: | 20 |
| J4019: | 1 | C0021: | 21 |
| J4201: | 1 | C0022: | 22 |
| J4202: | 0 | C0023: | 23 |
| J4203: | 1 | | |
| J4204: | 1 | (h) T00: | 10 |
| J4208: | 0 | M00: | 20 |
| J4209: | 1 | M02: | 30 |
| J4211: | 11 | | |
| J4212: | 222 | | |
| J4213: | 1 | | |
| J4214: | 2 | | |
| J4218: | 1 | | |
| J4219: | 2 | | |
| J4301: | 1 | | |

(8) Service Call Log

| # | Count. | Service Code | Data and Time |
|---|---------|--------------|------------------|
| 8 | 1111111 | 01.6000 | 2014/02/12 17:30 |
| 7 | 9999999 | 01.2100 | 2014/02/12 17:30 |
| 6 | 8888888 | 01.4000 | 2014/02/12 17:30 |
| 5 | 7777777 | 01.6000 | 2014/02/12 17:30 |
| 4 | 6666666 | 01.2100 | 2014/02/12 17:30 |
| 3 | 5555555 | 01.4000 | 2014/02/12 17:30 |
| 2 | 4444444 | 01.6000 | 2014/02/12 17:30 |
| 1 | 1 | 01.2100 | 2014/02/12 17:30 |

(9) Maintenance Log

| # | Count. | Item. | Data and Time |
|---|---------|-------|------------------|
| 7 | 9999999 | 01.21 | 2014/02/12 17:30 |
| 6 | 8888888 | 01.40 | 2014/02/12 17:30 |
| 5 | 7777777 | 01.60 | 2014/02/12 17:30 |
| 4 | 6666666 | 01.21 | 2014/02/12 17:30 |
| 3 | 5555555 | 01.40 | 2014/02/12 17:30 |
| 2 | 4444444 | 01.60 | 2014/02/12 17:30 |
| 1 | 1 | 01.21 | 2014/02/12 17:30 |

(10) Unknown toner Log

| # | Count. | Item. | Data and Time |
|---|---------|-------|------------------|
| 5 | 1111111 | 01.00 | 2014/02/12 17:30 |
| 4 | 9999999 | 01.00 | 2014/02/12 17:30 |
| 3 | 8888888 | 01.00 | 2014/02/12 17:30 |
| 2 | 7777777 | 01.00 | 2014/02/12 17:30 |
| 1 | 6666666 | 01.00 | 2014/02/12 17:30 |

(6) [XXXXXXXXXXXX]

Figure 6-1

Description of event log

| No. | Items | Contents | | |
|--|--|---|--|---|
| (1) | System version | | | |
| (2) | System date | | | |
| (3) | Engine firmware version | | | |
| (4) | Engine boot version | | | |
| (5) | Operation panel firmware version | | | |
| (6) | Machine serial number | | | |
| (7) | Paper Jam Log | # | Count. | Event |
| | | Remembers 1 to 16 th of occurrence. If the past paper jam occurrence is less than 16, all of them are indicated. The oldest log is deleted when exceeding 16 events. | The total page count at the time of a paper jam. | Log code (5 types in hexadecimal) (a) Cause of paper jam (b) Paper source (c) Paper size (d) Paper type (e) Paper eject |
| | | (a)Detail of Cause of paper jam (Hexadecimal) | | |
| | | : Refer to "7-1 Paper Misfeed Detection" (See page 7-1),for the detail of Cause of paper jam. (See page 7-2) | | |
| | | (b) Detail of paper source (Hexadecimal) | | |
| | | 00: MP tray 01: Cassette 1 02: Cassette 2 (paper feeder) 03: Cassette 3 (paper feeder) 04: Cassette 4 (paper feeder) 05 to 09: Reserved | | |
| (c) Detail of paper size (Hexadecimal) | | | | |
| 00: Not specified 01: Monarch 02: Business 03: International DL 04: International C5 05: Executive 06: Letter-R 08: Letter-E 07: Legal 08: A4R 88: A4E 09: B5R 89: B5E 0A: A3 | 0B: B4 0C: Ledger 0D: A5R 0E: A6 0F: B6 10: Commercial #9 11: Commercial #6 12: ISO B5 13: Custom size 1E: C4 1F: Hagaki 20: Oufuku Hagaki 21: Oficio II | 22: Special 1 23: Special 2 24: A3 Wide 25: Ledger Wide 26: Full bleed paper (12 x 8) 27: 8K 28: 16K-R A8: 16K-E 32: Statement-R B2: Statement-E 33: Folio 34: Youkei type 2 35: Youkei type 4 | | |

| No. | Items | Contents | | |
|--------------|------------------|---|---|--|
| (7) cont. | Paper Jam Log | (d) Detail of paper type (Hexadecimal) | | |
| | | 01: Plain 02: Transparency 03: Preprinted 04: Labels 05: Bond 06: Recycled 07: Vellum 08: Rough 09: Letterhead | 0A: Color 0B: Prepunched 0C: Envelope 0D: Cardstock 0E: Coated 0F: 2nd side 10: Media 16 11: High quality | 15: Custom 1 16: Custom 2 17: Custom 3 18: Custom 4 19: Custom 5 1A: Custom 6 1B: Custom 7 1C: Custom 8 |
| (8) | Service Call Log | # | Count. | Service Code |
| | | Remembers 1 to 8 th of occurrence of self diagnostics error. If the occurrence of the previous self-diagnostic error is 8 or less, all of the diagnostics errors are logged. | The total page count at the time of the self diagnostic error. | Self diagnostic error code (See page 7-23) Example: 01.6000 01: Self diagnostic error6000: Self diagnostic error code number |
| (9) | Maintenance Log | # | Count. | item |
| | | Remembers 1 to 8 of occurrence of unknown toner detection. If the occurrence of the previous unknown toner detection is less than 8, all of the unknown toner detection are logged. | Total page count at the time of the replacement of the maintenance item. The toner replacement log is triggered by toner empty. This record may contain such a reference as the toner container is inserted twice or a used toner container is inserted. | Maintenance item code (1-byte value to indicate 2 items) First byte (Replacing item) 01: Toner container Second byte (Type of replacing item) 00: Black 01: Cyan 02: Magenta 03: Yellow First byte (Replacing item) 02: Maintenance kit Second byte (Type of replacing item) 01: 01: MK-5195A (30ppm model) 02: MK-5195B (30ppm model) 01: MK-5205A (35ppm model) 02: MK-5205B (35ppm model) 01: MK-5215A (40ppm model) 02: MK-5215B (40ppm model) |

| No. | Items | Contents | | |
|------|--|---|---|--|
| (10) | Unknown Toner Log | <p>#</p> <p>Remembers 1 to 5 of occurrence of unknown toner detection. If the occurrence of the previous unknown toner detection is less than 5, all of the unknown toner detection are logged.</p> | <p>Count.</p> <p>The total page count at the time of the request of toner container replacement, when using the non-genuine toner container.</p> | <p>item</p> <p>Unknown toner log code (1 byte, 2 categories)</p> <p>First byte (Replacing item) 01: Toner container (Fixed to 01) Second byte (Type of replacing item) 00: Black 01: Cyan 02: Magenta 03: Yellow</p> |
| (11) | <p>Counter Log</p> <p>Consist of three log counters of paper jams, self diagnostics errors, and maintenance replacement items.</p> | <p>(f) Paper jam</p> <p>Indicates the log counter of paper jams depending on location. Refer to Paper Jam Log.</p> <p>All instances including those not having occurred are displayed.</p> | <p>(g) Self diagnostic error</p> <p>Indicates the log counter of self diagnostics errors depending on cause.</p> <p>Example: C6000: 004 Self diagnostic error 6000 has happened four times.</p> | <p>(h) Replacement for maintenance Items</p> <p>Indicates the log counter depending on the maintenance replacing item.</p> <p>T: Toner container 00: Black 01: Cyan 02: Magenta 03: Yellow</p> <p>M: Maintenance kit 01: MK-5195A (30ppm model) 02: MK-5195B (30ppm model) 01: MK-5205A (35ppm model) 02: MK-5205B (35ppm model) 01: MK-5215A (40ppm model) 02: MK-5215B (40ppm model)</p> <p>Example: T00: 1 The toner container (Black) has been replaced once.</p> <p>The toner replacement log is triggered by toner empty. This record may contain such a reference as the toner container is inserted twice or a used toner container is inserted.</p> |

Detail of service status page

Service Status Page

MFP (2) 2014/10/30 15:15
 TASKalfa 406ci (3) (4) (5)
 (1) Firmware Version 2R6_2000.000.0002014.10.30 [XXXXXXXX] [XXXXXXXX] [XXXXXXXX]

Controller Information

Memory status

| | |
|----------------|--------|
| Standard Size | 1.0 GB |
| Option Slot | 1.0 GB |
| (7) Total Size | 2.0 GB |

Time

| | |
|---------------------|------------------|
| (8) Local Time Zone | +01:00_Tokyo |
| (9) Date and Time | 10/30/2014 02:33 |
| (10) Time Server | 10.183.53.13 |

Installed Options

| | |
|----------------------------------|-----------------|
| (11) Paper Feeder2 | Installed |
| (12) Paper Feeder3 | Cassette(500x2) |
| (13) HDD | Installed |
| (14) SD Card | Not Installed |
| (15) SSD | Not Installed |
| (16) Finisher | 1000-Finisher |
| (17) Mail box | Not Installed |
| (18) Job separator | Not Installed |
| (19) Card Authentication Kit (B) | Installed |
| (20) Internet FAX Kit (A) | Installed |
| (21) Security Kit (E) | Not Installed |
| (22) Security Kit (F) | Not Installed |
| (23) UG-33 | Installed |
| (24) UG-34 | Installed |
| (25) USB Keyboard | Installed |
| (26) USB Keyboard Type | US-English |
| (27) Scan extension kit(A) | Not Installed |

Print Settings

| | |
|-----------------------|-----------|
| (28) MP Tray Priority | Auto Feed |
|-----------------------|-----------|

(29) **Print Coverage**
Average(%) / Usage Page(A4/Letter Conversion)

| | |
|---------------------------|---------------------------------|
| (30) Total | |
| K: 1.10 | / 1111111.11 |
| C: 2.20 | / 2222222.22 |
| M: 3.30 | / 3333333.33 |
| Y: 4.40 | / 4444444.44 |
| (31) Copy | |
| K: 1.10 | / 1111111.11 |
| C: 2.20 | / 2222222.22 |
| M: 3.30 | / 3333333.33 |
| Y: 4.40 | / 4444444.44 |
| (32) Printer | |
| K: 1.10 | / 1111111.11 |
| C: 2.20 | / 2222222.22 |
| M: 3.30 | / 3333333.33 |
| Y: 4.40 | / 4444444.44 |
| (33) FAX | |
| K: 1.10 | / 1111111.11 |
| (34) Period | (27/10/2010 - 03/11/2010 08:40) |
| (35) Last Page K/C/M/Y(%) | 1.00 / 2.22 / 3.33 / 4.44 |

FAX Information

| | |
|-----------------------|------|
| (36) Rings (Normal) | 3 |
| (37) Rings (FAX/TEL) | 3 |
| (38) Rings (TAD) | 3 |
| (39) Option DIMM Size | 16MB |

(40) **FRPO Status**

| | | |
|------------------|-----------|-----|
| User Top Margin | A1+A2/100 | 0.0 |
| User Left Margin | A3+A4/100 | 0.0 |

RP Code

| | |
|----------------------------|--|
| (41) <u>1234 5678 9012</u> | |
| (42) 5678 9012 3456 | |
| (43) 9012 3456 7890 | |
| (44) 3456 7890 1234 | |

(45) **Altitude Adjustment**

| | |
|--------|--------|
| Status | Normal |
|--------|--------|

1 (6) [XXXXXXXXXX]

Figure 6-2

Service Status Page

MFP

2014/10/30 15:15

TASKalfa 406ci

Firmware Version 2R6_2000.000.000

[XXXXXXXX] [XXXXXXXX] [XXXXXXXX]

Engine Information

(46) NVRAM Version _CI04709_CI04709
 (47) FAX Slot1 2NM_1200.001.089
 FAX BOOT Version 2NM_5000.001.006
 FAX APL Version 2NM_5100.004.001
 FAX IPL Version 2NM_5200.001.006
 (48) MAC Address 00:C0:EE:D0:01:0D

Send Information

(49) Date and Time 14/03/05 15:30
 (50) Address mail@bjd.ne.jp

1/2 (51) (52)
 (53) 100/100
 (54) 0/0/0/0/
 (55) 0000000/0000000/0000000/0000000/0000000/0000000/0000000/
 0000000/0000000/0000000/0000000/0000000/0000000/0000000/0000000/0000000/0000000/
 F00/U00/0/0/0/0/0/30/30/70/70/abcde/1/0/1/ (56) (57) (58) (59) (60) (61) (62) (63) (64) (65) (66) (67) (68) (69) (70)
 (71) 0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/
 0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/
 (72) 0000/0100/0500/1000/0000/0100/0500/1000/0000/0100/0500/1000/0000/0100/0500/1000/
 0000/0100/0500/1000/0000/0100/0500/1000/0000/0100/0500/1000/0000/0100/0500/1000/
 (73) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000000000/
 (74) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000
 (75) 0000000000000000/0000000000000000/0000000000000000/
 (76) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 (77) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000/
 (78) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000/
 (79) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000/
 (80) 0000000000000000/0000000000000000/0000000000000000/
 (81) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000/
 (82) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000/
 (83) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000/
 (84) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000/
 (85) 12345678/11223344/00001234abcd567800001234abcd5678/01234567890123456789012345678901/0008/00/07
 12345678/11223344/00001234abcd567800001234abcd5678/01234567890123456789012345678901/0008/00/07
 12345678/11223344/00001234abcd567800001234abcd5678/01234567890123456789012345678901/0008/00/07
 12345678/11223344/00001234abcd567800001234abcd5678/01234567890123456789012345678901/0008/00/07
 (86) XXXXXXXX/
 (87) [ABCDEFGHJIJ][ABCDEFGHJIJ]
 [ABCDEFGHJIJ][ABCDEFGHJIJ] (88) (89)
 [ABCDEFGHJIJ][ABCDEFGHJIJ] (90) (91)
 (92) 00070107FE/0700FE00FE/00FE000100/0000000000/0000000000/0000000000/00000A010A/0A0A0A3200/0000000000/0000000000/
 0008000000/080000001D/0096009B00/9B009BFFFB/0082000000/000000001F/0000002C00/0000000000/0000000000/
 (93) 3/
 0/0/12.3/56.7 (94) (95) (96) (97)
 (98) 1/1/1/0/1/0/0/ 2010/12/15 12:34:56
 1/5/ (99)(100)
 1/1/ (101) (102)
 (103) 1/
 (104) ABCDEFGHIJKL/ABCDEFGHIJKL/ABCDEFGHIJKL/ABCDEFGHIJKL/ABCDEFGHIJKL/
 (105) ABCDEFGHIJKL/ABCDEFGHIJKL/ABCDEFGHIJKL/ABCDEFGHIJKL/ABCDEFGHIJKL/

Figure 6-3

| No. | Items | Contents |
|------|--|--|
| (1) | Firmware Version | - |
| (2) | System date | - |
| (3) | Engine firmware version | - |
| (4) | Engine boot version | - |
| (5) | Operation panel firmware version | - |
| (6) | Machine serial number | - |
| (7) | Total memory size | - |
| (8) | Local time zone | - |
| (9) | Report output date | Day/Month/Year hour:minute |
| (10) | NTP server name | - |
| (11) | Availability of the paper feed unit 2 | Installed/Not Installed |
| (12) | Availability of the paper feed unit 3 | Cassette(500-sheet×2) / Cassette(2000-sheet) / Not Installed |
| (13) | Availability of the optional HDD | Installed/Not Installed |
| (14) | Availability of the SD memory card | Installed/Not Installed |
| (15) | Availability of the SSD | Installed/Not Installed |
| (16) | Availability of the finisher | 1000-sheet finisher/inner finisher/ 3000-sheet finisher/not installed |
| (17) | Availability of Mailbox | Installed/Not Installed |
| (18) | Availability of job separator | Installed/Not Installed |
| (19) | Availability of the ID Card Authentication Kit | Introduced/ before introduction/trial |
| (20) | Availability of the Internet FAX Kit(A) | Introduced/ before introduction (not indicated for 30ppm model) |
| (21) | Availability of the Security Kit(E) | Installed/Not Installed |
| (22) | Availability of the Security Kit(F) | Introduced/ before introduction (not indicated for 30ppm model) |
| (23) | Availability of UG-33 | Introduced/ before introduction/trial |
| (24) | Availability of UG-34 | Introduced/ before introduction (not indicated for 30ppm model) |
| (25) | USB keyboard connection status | Connected/Not connected |
| (26) | Type of the USB keyboard | US-English/US-English with Euro symbol/German France |
| (27) | Availability of the Scan extension kit(A) | Introduced/ before introduction/trial (not indicated for 30ppm model) |
| (28) | MP tray priority setting | Off/Auto/Always |
| (29) | Page count converted to the A4/Letter size | Print Coverage provides a close-matching reference of toner consumption and will not match the actual toner consumption. |

| No. | Items | Contents |
|------|--|--|
| (30) | Entire average coverage | Black/Cyan/Magenta/Yellow |
| (31) | Average coverage for copy | Black/Cyan/Magenta/Yellow |
| (32) | Average printer coverage | Black/Cyan/Magenta/Yellow |
| (33) | Average coverage for FAX | Black/Cyan/Magenta/Yellow |
| (34) | Cleared date and output date | - |
| (35) | Coverage on the last output page | - |
| (36) | Number of rings | 0 to 15 |
| (37) | Number of rings before automatic switching | 0 to 15 |
| (38) | Number of rings before connecting to the answering machine | 0 to 15 |
| (39) | Optional DIMM size | - |
| (40) | FRPO setting | - |
| (41) | RP code | Coding the engine firmware version and the date of the previous update. |
| (42) | RP code | Code the main software version and the date of the latest update. |
| (43) | RP code | Coding the engine firmware version and the date of the previous update. |
| (44) | RP code | Code the main software version and the date of the previous update. |
| (45) | High altitude adjustment set data | Normal/1001-2000m/2001-3000m/3001-3500m |
| (46) | NVRAM version | _ 1F3 1225 _ 1F3 1225 (a)(b)(c)(d)(e)(f) (a) Consistency of the current firmware version and the database _ (underscore): OK * (Asterisk): NG (b) Database version (c) The oldest time stamp of database version (d) Consistency of the present software version and the ME firmware version _ (underscore): OK * (Asterisk): NG (e) ME firmware version (f) The oldest time stamp of the ME firmware version Normal if (a) and (d) are underscored, and (b) and (e) are identical with (c) and (f). |
| (47) | FAX firmware version | - |
| (48) | Mac address | - |
| (49) | The last sent date and time | - |
| (50) | Transmission address | - |
| (51) | Destination information | - |

| No. | Items | Contents |
|------|--|---|
| (52) | Area information | - |
| (53) | Margin setting | Top margin/Left margin |
| (54) | L parameters | Top margin integer part/Top margin decimal part/Left margin integer part /Left margin decimal part |
| (55) | Life counter (cassette 1) | Machine life/MP tray/Cassette/Paper feeder 1/Paper feeder 2/Paper feeder 3/Duplex |
| | Life counter (cassette 2) | Drum unit K/Drum unit C/Drum unit M/Drum unit Y/Primary transfer unit/Developer unit K/Developer unit C/ Developer unit M/Developer unit Y/ Maintenance kit A/Maintenance kit B |
| (56) | Panel lock information | F00: OFF F01: Partial lock1 F02: Partial lock2 F03: Partial lock3 F04: Full lock |
| (57) | USB information | U00: Not Connected U01: Full speed U02: Hi speed |
| (58) | Paper handling information | 0: Paper source select 1: Paper source fixed |
| (59) | Auto cassette change | 0: OFF 1: ON (Default) |
| (60) | Color printing double count mode | 0: All single counts 3: Folio (Less than 330 mm length), Single counts |
| (61) | Black and white printing double count mode | 0: All single counts 3: Folio (Less than 330 mm length), Single counts |
| (62) | Billing counts timing | 0: When secondary paper feed starts 1: When the paper is ejected |
| (63) | Temperature (machine inside) | - |
| (64) | Temperature (machine outside) | - |
| (65) | Relative humidity (machine outside) | - |
| (66) | Absolute humidity (machine outside) | - |
| (67) | Asset Number | - |
| (68) | Job end judgment time-out time | - |
| (69) | Job end detection mode | 0: Detects as one job, even if contained multiple jobs 1: Detects as individual job, dividing multiple jobs at a break in job |
| (70) | Prescribe environment reset | 0: Off 1: On |

| No. | Items | Contents | |
|------|--|--|---|
| (71) | Media type attributes 1 to 28 (Not used: 18, 19, 20) *: For details on settings, refer to MDAT command in "Prescribe Commands Reference Manual". | Weight settings 0: Light 1: Normal 1 2: Normal 2 3: Normal 3 4: Heavy 1 5: Heavy 2 6: Heavy 3 7: Extra Heavy | Fuser settings 0: High 1: Middle 2: Low 3: Vellum Duplex settings 0: Disable 1: Enable |
| (72) | IO Calibration information | K/C/M/Y | |
| (73) | Bias Calibration information | - | |
| (74) | Sensor initial information | - | |
| (75) | Calibration information | - | |
| (76) | Calibration information | - | |
| (77) | Calibration information | - | |
| (78) | Calibration information | - | |
| (79) | Calibration information | - | |
| (80) | Paper loop correction shift amount | - | |
| (81) | Paper loop correction interval | - | |
| (82) | Paper loop correction patch amount | - | |
| (83) | Calibration information | - | |
| (84) | Calibration information | - | |
| (85) | RFID information (K,C,M,Y) | - | |
| (86) | RFID reader/writer version | - | |
| (87) | Optional paper feeder firmware version | - | |
| (88) | Color table version for printer | - | |
| (89) | Color table 2 version for printer | - | |
| (90) | Color table version for copy | - | |
| (91) | Color table 2 version for copy | - | |
| (92) | Maintenance information | - | |
| (93) | MC correction | 1 to 7 | |
| (94) | Configuring the toner coverage counters | 0: Full-color count display 1: Color coverage count display | |
| (95) | Low coverage setting | 0.1 to 100.0 | |
| (96) | Middle coverage setting | 0.1 to 100.0 | |
| (97) | Data sanitization information | FAX Board/Main Memory/Panel Memory/SSD/Executed time 1: Success 0: Fail - : Not performed or Not installed | |

| No. | Items | Contents | | | | | | | | | | | | | | | | | | | | |
|--|-----------------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| (98) | Toner low setting | 0: Disabled 1: Enabled | | | | | | | | | | | | | | | | | | | | |
| (99) | Toner low detection level | 0 to 100 (%) | | | | | | | | | | | | | | | | | | | | |
| (100) | Full-page print mode | 0: Normal mode (Factory setting) 1: Full-page mode | | | | | | | | | | | | | | | | | | | | |
| (101) | Wake-up mode | 0: Off (Don't wake up) 1: On (Do wake up) | | | | | | | | | | | | | | | | | | | | |
| (102) | Wake-up timer | Displays the wake-up time | | | | | | | | | | | | | | | | | | | | |
| (103) | BAM conformity mode setting | 0: Non-conformity mode 1: Conformity Mode | | | | | | | | | | | | | | | | | | | | |
| (104) | Drum serial number | Black/Cyan/Magenta/yellow | | | | | | | | | | | | | | | | | | | | |
| (105) | Developer serial number | Black/Cyan/Magenta/yellow | | | | | | | | | | | | | | | | | | | | |
| <p data-bbox="416 792 619 824">Code conversion</p> <table border="1" data-bbox="416 842 1099 938"> <tbody> <tr> <td data-bbox="416 842 485 891">A</td> <td data-bbox="485 842 553 891">B</td> <td data-bbox="553 842 622 891">C</td> <td data-bbox="622 842 691 891">D</td> <td data-bbox="691 842 759 891">E</td> <td data-bbox="759 842 828 891">F</td> <td data-bbox="828 842 896 891">G</td> <td data-bbox="896 842 965 891">H</td> <td data-bbox="965 842 1034 891">I</td> <td data-bbox="1034 842 1099 891">J</td> </tr> <tr> <td data-bbox="416 891 485 938">0</td> <td data-bbox="485 891 553 938">1</td> <td data-bbox="553 891 622 938">2</td> <td data-bbox="622 891 691 938">3</td> <td data-bbox="691 891 759 938">4</td> <td data-bbox="759 891 828 938">5</td> <td data-bbox="828 891 896 938">6</td> <td data-bbox="896 891 965 938">7</td> <td data-bbox="965 891 1034 938">8</td> <td data-bbox="1034 891 1099 938">9</td> </tr> </tbody> </table> | | | A | B | C | D | E | F | G | H | I | J | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
| A | B | C | D | E | F | G | H | I | J | | | | | | | | | | | | | |
| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | | | | | | | | | | | | | |

| | |
|-------------|--|
| U001 | Exiting the maintenance mode (Message: Exit Mainte) |
|-------------|--|

Contents

Exits the maintenance mode and returns to the normal copy mode.

Purpose

Exit the maintenance mode.

Method

- 1.Press the [Start] key.
- 2.The normal copy mode is entered.

| | |
|-------------|---|
| U002 | Set Factory Default (Message: Set Factory Def) |
|-------------|---|

Contents

Sets the machine initial setting values to the factory default.

Purpose

Executes the machine initial settings when shipping from factory.

Method

- 1.Press the [Start] key.
- 2.Select [Mode1(All)].
- 3.Press the [Start] key.

| Items | Contents |
|-------------------|---|
| Mode1(All) | Sets the machine initial setting values to the factory default. |

- 4.Turn the power switch off.

* :An error code is displayed in case of the initialization error.

When errors occur, turn the power switch off then on, and execute initialization using maintenance mode U002.

Wait more than 5 seconds between the power off and on.

Error codes

| Codes | Contents |
|--------------|----------------------------|
| 0001 | Controller (Entity error) |
| 0002 | Controller (Counter error) |
| 0003 | Controller (OS error) |
| 0020 | Engine error |

| | |
|-------------|---|
| U004 | Machine serial number (Message: Machine No.) |
|-------------|---|

Contents

Sets or displays the machine serial number.

Purpose

Checks the machine serial number

After the main/engine PWB replacement, execute if the "C0180 machine number mismatch" occurs.

Method

1. Press the [Start] key.

When the machine serial number in the engine PWB matches the one in the main PWB,

| Items | Contents |
|-------------------------|-------------------------------------|
| Machine No.(Eng) | Displays the machine serial number. |

When the machine serial number in the engine PWB does not match the one in the main PWB,

| Items | Contents |
|--------------------------|---|
| Machine No.(Main) | Displays the machine serial number in the main PWB. |
| Machine No.(Eng) | Displays the machine serial number in the engine PWB. |

Setting

Execute if the serial numbers do not match.

1. Select [Execute].

2. Press the [Start] key.

* :The serial number writing starts.

3. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U010 | Setting the maintenance mode ID (Message: Set Mainte ID) |
|-------------|---|

Contents

Change the maintenance mode ID for service.

Purpose

Modify maintenance mode ID for service for more security.

Method

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|-------------------|--|
| Change | Change the maintenance mode ID for service. |
| Initialize | Initializes the maintenance mode ID for service. |

Method: Change

1. Select [New ID].
2. Press ten keys (0–9, *, #) to enter a new 8-digit ID.
* : Either [*] or [#] must be included.
3. Press the [Start] key to set the setting value.
4. Select [New ID(Reconfirm)].
5. Press ten keys (0–9, *, #) to re-enter the new 8-digit ID.

| Items | Contents |
|--------------------------|---|
| New ID | Enter a new 8-digit maintenance ID |
| New ID(Reconfirm) | Enter a new 8-digit maintenance ID (to confirm) |
| Execute | Change the maintenance mode ID for service. |

6. Select [Execute].
7. Press the [Start] key to set the setting value.

Method: Initialize

1. Select [Initialize].
2. Select [Execute].
3. Press the [Start] key to initialize the maintenance mode ID.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

Error codes

| Codes | Contents |
|-------------|--------------------------------------|
| 0001 | Do not include "#" or "*" in the ID. |
| 0002 | ID does not match. |
| 0003 | 8-digit ID is not input |

| | |
|-------------|---|
| U019 | Firmware Version (Message: Firm Version) |
|-------------|---|

Contents

Displays the firmware version installed in each PWB.

Purpose

Check the firmware version installed in each PWB

Method

1. Press the [Start] key.

* :The firmware version is displayed.

2. Change the screen using the [Up/Down cursor] key.

| Items | Contents |
|---------------------------|----------------------------------|
| Main | Main firmware |
| MMI | Operation firmware |
| Browser | Browser firmware |
| Engine | Engine firmware |
| Engine Boot | Engine boot |
| RFID | RFID |
| Dictionary | Dictionary firmware |
| Option Language | Optional language firmware |
| Color Table1(Copy) | Color table 1 firmware (copy) |
| Color Table2(Copy) | Color table 2 firmware (copy) |
| Color Table2(Prn) | Color table 1 firmware (printer) |
| Color Table2(Prn) | Color table 2 firmware (printer) |
| Cass2 | Paper feeder 1 firmware |
| Cass2 Boot | Paper Feeder 1 boot |
| Cass3 | Paper feeder 2 firmware |
| Cass3 Boot | Paper Feeder 2 boot |
| DF | finisher firmware |
| DF Boot | finisher boot |
| MT | mailbox Firmware |
| MT Boot | mailbox boot |
| Fax APL | Fax APL |
| Fax Boot | FAX Boot |
| Fax APL | Fax APL |
| HyPAS EMB API | HyPAS EMB API |
| Application Name 1 | Application 1 software |
| Application Name 2 | Application 2 software |
| Application Name 3 | Application 3 software |
| Application Name 4 | Application 4 software |

| Items | Contents |
|----------------------------|-------------------------|
| Application Name 5 | Application 5 software |
| Application Name 6 | Application 6 software |
| Application Name 7 | Application 7 software |
| Application Name 8 | Application 8 software |
| Application Name 9 | Application 9 software |
| Application Name 10 | Application 10 software |
| Application Name 11 | Application 11 software |
| Application Name 12 | Application 12 software |
| Application Name 13 | Application 13 software |
| Application Name 14 | Application 14 software |
| Application Name 15 | Application 15 software |
| Application Name 16 | Application 16 software |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U021 | Initializes Memory (Message: Init Memory) |
|-------------|--|

Contents

Initializes all settings, except those pertinent to the type of machine, namely each counter, service call error history and mode setting. Also, initializes the backup RAM according to the area specification selected in the maintenance mode U252 (Setting the destination).

Purpose

Initialize the backup data except machine settings to the factory default in the field

Method

1. Press the [Start] key.
2. Select [Execute].

| Items | Contents |
|----------------|---|
| Execute | Initialize data according to the destination information. |

3. Press the [Start] key.

* :All data other than for adjustments is initialized by the destination setting.

4. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

* :An error code is displayed in case of the initialization error.

When errors occur, turn the power switch off then on, and execute initialization using maintenance mode U021.

Error codes

| Items | Contents |
|-------------|----------------------------|
| 0001 | Controller (Entity error) |
| 0002 | Controller (Counter error) |
| 0020 | Engine error |
| 0040 | Scanner error |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U025 | Firmware update (S) (Message: Firm Update(S)) |
|-------------|--|

Contents

Executes Firmware-Update from the USB memory while "Very High" is selected in the Security Level settings under the System Menu.

Supplement

Initiate the firmware upgrade by a service person by executing U025 while a USB memory is inserted

Method

- 1.Press the [Start] key.
- 2.Select [Execute].

| Items | Contents |
|----------------|----------------------|
| Execute | Updates the firmware |

- 3.Press the [Start] key.

* :This is not executable when a USB memory is not installed.

- 4.After normal completion, turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U030 | Motor operation check (Message: Chk Motor) |
|-------------|---|

Contents

Drive each motor.

Contents

Execute to check each motor's operation.

Method

1. Press the [Start] key.
2. Select the motor to operate.
3. Press the [Start] key.

* :Each operation starts.

| Items | Contents |
|----------------------|-----------------------------|
| Feed | Operate the imaging motor. |
| DLP(CMY) | Operate the DLP (CMY) motor |
| Fuser | Operate the fuser motor |
| SB(CW) | Drive the SB(CW) motor |
| SB(CCW) | Drive the SB(CCW) motor |
| Belt Release | Operate the bridge motor |
| Bridge | Operate the belt release |
| Fuser Release | Operate the fuser release |

* :To stop the operation, press the [Stop] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U031 | Check the conveying switch (Message: Chk Switch) |
|-------------|---|

Contents

Displays the on/off status of each switch and sensor to detect paper on the paper conveying path.

Purpose

Execute to check the conveying switches and sensors are operating correctly.

Method

1. Press the [Start] key.
2. Check the switches and sensors by manually turning them on/off.
3. The switch indication is inverted when the switch is detected.

| Items | Contents |
|---------------------|---|
| Regist Sens | Display the regist sens switch state |
| Fuser | Displays the fuser switch status |
| Bridge1 Feed | Displays the bridge 1 feed switch state |
| Bridge2 Feed | Displays the bridge 2 feed switch state |
| Exit Full | Display the exit full switch state |
| JobSepa Full | Display the job separator full switch state |
| JobSepa | Display the job separator switch state |
| Feed2 | Displays the cassette2 feed switch state |
| Feed3 | Displays the cassette3 feed switch state |
| Feed4 | Displays the cassette4 feed switch state |
| DU Sens | Display the DU sens switch state |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U032 | Clutch operation check (Message:Check Clutch Operation) |
|-------------|--|

Contents

Supply power to each clutch.

Purpose

Execute to check each clutch's operation.

Method

- 1.Press the [Start] key.
- 2.Select the clutch to operate.
- 3.Press the [Start] key.

* :Each operation starts.

| Items | Contents |
|---------------|-------------------------------------|
| DLP | Operates the developer clutch (BK). |
| Feed | Operates the paper feed clutch |
| Mid | Operates the middle clutch |
| DU | Operate the duplex clutch |
| Regist | Operate the registration clutch |
| Mpf | Operate the MP clutch |
| Motor | Operate the motor |

* :The clutch operation is available while the motor is operated.

- 4.To stop the operation, press the [Stop] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U033 | Solenoid operation check (Message: Chk Solenoid) |
|-------------|---|

Contents

Supply power to each solenoid.

Purpose

Execute to check each solenoid's operation.

Method

- 1.Press the [Start] key.
- 2.Select the solenoid to operate.
- 3.Press the [Start] key.

* :Each operation starts.

| Items | Contents |
|--------------------|----------------------------------|
| Branch Exit | Operate the feed-shift solenoid. |
| MPT | Operate the MP solenoid |
| Motor | Operate the motor |

* :The solenoid operation is available while the motor is operated.

- 4.To stop the operation, press the [Stop] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U034 | Paper timing adjustment (Message: Adj Paper Timing) |
|-------------|--|

Contents

Adjust the leading edge registration or center line.

Purpose

Executed if there is a regular error between the leading edges of the copy image and original.
Adjusted if there is a regular error between the center lines of the copy image and original.

Method

1. Press the [Start] key.
2. Select the item to adjust.
- * :The screen for adjusting is displayed.

| Items | Contents |
|-------------------------|---|
| LSU Out Top Full | Adjust the leading edge registration (full speed) |
| LSU Out Top 3/4 | Adjust the leading edge registration (3/4 speed) |
| LSU Out Top Half | Adjust the leading edge registration (half speed) |
| LSU Out Left | Adjusts the center line |

Adjustment: LSU Out Top

1. Select the item to adjust.
2. Press the [System Menu/Counter] key.
3. Press the [Start] key to output a test pattern.
4. Press the [System Menu/Counter] key.

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------|---|---------------|-----------------|----------------|
| MPT | Adjust the leading edge timing for the MP tray | -3.0 to 3.0 | 0 | 0.1mm |
| Cassette | Adjusts the leading edge timing for cassette feed | -3.0 to 3.0 | 0 | 0.1mm |
| PF*1 | Adjust the leading edge timing for the paper feeder | -3.0 to 3.0 | 0 | 0.1mm |
| Dup | Adjusting the leading edge timing when duplex copying | -3.0 to 3.0 | 0 | 0.1mm |

*1: 500 x 1 cassette only

5. Press the [◀] [▶] keys or the numeric keys to change the counter value.
For the test pattern 1, increase the value.
For the test pattern 2, decrease the value.

* :When the setting value is increased, the image moves backward, and it moves forward when the setting value is decreased.




Figure 6-4

6. Press the [Start] key to set the setting value.

Precautions

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034 > U066 (P.6-240) > U071 (P.6-244)

Adjustment: LSU Out Left

1. Select the item to adjust.
2. Press the [System Menu/Counter] key.
3. Press the [Start] key to output a test pattern.
4. Press the [System Menu/Counter] key.

| Items | Contents | Setting range | Initial setting | Data variation |
|---------------|--|---------------|-----------------|----------------|
| MPT | Adjust the center line for the MP tray | -3.0 to 3.0 | 0 | 0.1mm |
| Cass1 | Adjust the center line for cassette 1 feed | -3.0 to 3.0 | 0 | 0.1mm |
| Cass2 | Adjust the center line for cassette 2 (Optional unit) feed | -3.0 to 3.0 | 0 | 0.1mm |
| Cass3 | Adjust the center line for cassette 3 (Optional unit) feed | -3.0 to 3.0 | 0 | 0.1mm |
| Cass4 | Adjust the center line for cassette 4 (Optional unit) feed | -3.0 to 3.0 | 0 | 0.1mm |
| Duplex | Adjusting the center line when duplex copying (Back page) | -3.0 to 3.0 | 0 | 0.1mm |

5. Press the [◀] [▶] keys or the numeric keys to change the counter value.
For the test pattern 1, increase the value.
For the test pattern 2, decrease the value.

* :When the setting value is increased, the image moves to right, and it moves to left when the setting value is decreased.




Figure 6-5

6.Press the [Start] key to set the setting value.

Precautions

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034 < U067(P.6-241) < U072(P.6-246)

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U035 | Folio size setting (Message: Set FOLIO Size) |
|-------------|--|

Contents

Changes the printable area when copying with Folio paper.

Purpose

Setting the actual size of Folio to use prevents the image dropout at the trailing edge or right/left edges.

Method

- 1.Press the [Start] key.
- 2.Select the item to set.
- 3.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|---------------|------------------------------|-----------------|-----------------|----------------|
| Length | Sets the Folio paper length. | 318 to 356 (mm) | 330 | 1(mm) |
| Width | Sets the Folio paper width. | 200 to 216 (mm) | 210 | 1(mm) |

4.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U037 | Fan motor operation check (Message: Chk Motor) |
|-------------|---|

Contents

Drive each fan motor.

Contents

Execute to check each fan motor's operation.

Method

1. Press the [Start] key.
2. Select the fan motor to operate.
3. Press the [Start] key.

* :Each operation starts.

| Items | Contents |
|---------------------|-------------------------------------|
| All | Operate all the fan motors |
| DLP | Operate the developer fan motor 1 |
| Belt Cooling | Operate the transfer belt fan motor |
| Exit Cooling | Operate the exit fan motor |
| LVU CL Fan | Operate the developer fan motor 2 |
| WTNR Fan | Operates the toner suction motor |
| CON Fan | Operate the Controller fan motor |

* :To stop the operation, press the [Stop] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|--|--|
| | |
|--|--|

| | |
|-------------|--|
| U051 | Registration paper loop amount adjustment (Message: Adj Paper Loop) |
|-------------|--|

Contents

Adjusts the paper loop amount.

Purpose

The leading edge of the image may drop, image position may shift irregularly or paper is folded in a Z-shape.

* :Use to check/adjust skew feed.

Method

1.Press the [Start] key.

2.Select the item to adjust.

* :The screen for adjusting is displayed.

| Items | Contents |
|-------------|--|
| Full | Paper loop amount adjustment at full speed |
| Half | Paper loop amount adjustment at half speed |
| 3/4 | Paper loop amount adjustment at 3/4 speed |

Adjustment

1.Select the item to adjust.

2.Press the [System Menu/Counter] key.

3.Place an original and press the [Start] key to make a test copy.

4.Press the [System Menu/Counter] key.

* :The screen for adjusting is displayed.


| Items | Contents | Setting range | Initial setting | Data variation |
|--------------|---|---------------|-----------------|----------------|
| MPT | MPT loop amount adjustment | -30 to 20 | 0/0/0 | 1mm |
| Cass1 | Cassette 1 loop amount adjustment | -30 to 20 | 0/0/0 | 1mm |
| PF | PF (Cassette2,3,4) loop amount adjustment | -30 to 20 | 0/0/0 | 1mm |
| Dup | Duplex loop amount adjustment | -30 to 20 | 0/0/0 | 1mm |

5.Press the [◀] [▶] keys or the numeric keys to change the counter value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the paper loop amount increase, and it decreases when the setting value is decreased.

**Figure 6-6**

6.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U053 | Adjusting the motor speed (Message: Adj Motor Speed) |
|-------------|---|

Contents

Execute the motor speed fine tuning.

Purpose

No need to change the basic settings. Change the set value when an image failure occurs.

Method

1. Press the [Start] key.
 2. Select the item to adjust.
- * :The screen for adjusting is displayed.

| Items | Contents |
|-------------|--------------------|
| Full | Full speed setting |
| Half | Half speed setting |
| 3/4 | 3/4 speed setting |

Setting

1. Select the item to adjust.
- * :The screen for adjusting is displayed.

| Items | Contents | Setting range | Initial setting | Data variation |
|---------------------|---|---------------|-----------------|----------------|
| Drum(K) | Adjusting the drum motor(BK) | -5000 to 5000 | 0/0/0 | - |
| Drum(CMY) | Adjusting the drum motor(M/C/Y) | -5000 to 5000 | 0/0/0 | - |
| Drum Mono(K) | Adjust the drum motor (K) at the time of monochrome printing. | -5000 to 5000 | 0/0/0 | - |
| Dev(K) | Adjusting the developer motor(BK) | -5000 to 5000 | 0/0/0 | - |
| Dev(CMY) | Adjusting the developer motor(M/C/Y) | -5000 to 5000 | 0/0/0 | - |
| Fixing | Adjusting the fuser motor(FUM) | -5000 to 5000 | 0/0/0 | - |
| Trans Belt | Adjusting the transfer belt motor | -5000 to 5000 | 0/0/0 | - |
| SB | Adjusts the DP feedshift motor (DPSPM) rotation | -5000 to 5000 | 0/0/0 | - |
| SB Reverse | Adjusts the DP feedshift motor (DPSPM) reverse rotation | -5000 to 5000 | 0/0/0 | - |
| Brg1 | Adjusting the BR conveying motor (BRCM) | -5000 to 5000 | 0/0/0 | - |
| PF2 | Adjusting the PF paper feed motor (PFPFM) | -5000 to 5000 | 0/0/0 | - |
| PF3 | Adjusting the PF paper feed motor (PFPFM) | -5000 to 5000 | 0/0/0 | - |

2. Press the [◀] [▶] keys or the numeric keys to change the counter value.
3. Press the [Start] key to set the setting value.

Completion

- Press the [Stop] key.
- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U059 | Fan mode setting (Message: Set Fan Mode) |
|-------------|---|

Contents

Sets the conveying fan motor drive mode during paper conveying.

Purpose

A fan is added in the conveying unit so that the leading edge of paper is conveyed along with the conveying path to prevent paper creases.

Method

1. Press the [Start] key.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|--------------|---------------------------------------|----------------------|------------------------|-----------------------|
| Cycle | Changes the fan control timing cycle. | 0 to 10000 | | 1000 sheets |

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U065 | Adjusting the magnification for table scanning (Message: Adj Scn) |
|-------------|--|

Contents

Adjust the magnification in the main and sub scanning direction of the table scanning.

Purpose

Adjusts the magnification in the main and sub scanning direction of the table scanning if the above incorrect

Precautions

The magnification adjustment in the main scanning direction could cause black streaks depending on the content of the original document.

Adjust the magnification of the scanner in the following order.

U065(main scanning direction)(P.6-238)>U065((sub scanning direction)(P.6-238)

Method

- 1.Press the [Start] key.
- 2.Press the [System Menu/Counter] key.
- 3.Place an original and press the [Start] key to make a test copy.
- 4.Press the [System Menu/Counter] key.
- 5.Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------------|---|---------------|-----------------|----------------|
| Main Scan | Scanner magnification in the main scanning direction | -15 to 15 | 0 | 0.10% |
| Sub Scan | Adjusts scanner magnification in the sub-scanning direction | -25 to 25 | 0 | 0.10% |


Adjustment: Main Scan

- 1.Press the [◀] [▶] keys or the numeric keys to change the counter value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the image widens, and it narrows when the setting value is decreased.

**Figure 6-7**

- 2.Press the [Start] key to set the setting value.

Adjustment: Sub Scan

- 1.Press the [◀] [▶] keys or the numeric keys to change the counter value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the image get longer, and it shortens when the setting value is decreased.




Figure 6-8

2.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U066 | Adjusting the table scanning timing (Message: Table Timing) |
|-------------|--|

Contents

Adjusts the leading edge timing for the table scanning.

Purpose

Executed if there is a regular error between the leading edges of the copy image and original.

Adjustment

1. Press the [Start] key.
2. Press the [System Menu/Counter] key.
3. Place an original and press the [Start] key to make a test copy.
4. Press the [System Menu/Counter] key.
5. Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|---------------|--|---------------|-----------------|----------------|
| Front | Adjusts the scanner leading edge margin. | -45 to 45 | 0 | 0.085 mm |
| Rotate | Scanner leading edge registration (rotate copying) | -45 to 45 | 0 | 0.085 mm |

6. Press the [◀] [▶] keys or the numeric keys to change the counter value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the image moves forward, and it moves backward when the setting value is decreased.

Leading edge registration of the copy image (+1.0/-1.5 mm or less)




Figure 6-9

7. Press the [Start] key to set the setting value.

Precautions

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034(P.6-228) > U065(P.6-238) > U066

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U067 | Adjusting the table scanning center line (Message: Table Center) |
|-------------|---|

Contents

Adjusts the center line for the table scanning.

Purpose

Adjusted if there is a regular error between the center lines of the copy image and original.

Adjustment

1. Press the [Start] key.
2. Press the [System Menu/Counter] key.
3. Place an original and press the [Start] key to make a test copy.
4. Press the [System Menu/Counter] key.
5. Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|---------------|--------------------------------------|---------------|-----------------|----------------|
| Front | Adjusts the scanner center line | -40 to 40 | 0 | 0.085 mm |
| Rotate | Scanner center line (rotate copying) | -40 to 40 | 0 | 0.085 mm |

1. Press the [◀] [▶] keys or the numeric keys to change the counter value.

For the copy example 1, decrease the value.

For the copy example 2, increase the value.

* :When the setting value is increased, the image moves to left, and it moves to right when the setting value is decreased.

Center line of the copy image (within ± 2.0 mm)




Figure 6-10

2. Press the [Start] key to set the setting value.

Precautions

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034(P.6-228) > U065(P.6-238) > U067

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U068 | DP scanning position adjustment (Message: DP Scn Start Pos) |
|-------------|--|

Contents

Adjusts the starting position for scanning originals from the DP.
Execute test copy at the four scanning positions after adjustment.

Purpose

Adjust if the image fogging occurs because the scanning position is not proper when the DP is used

* :Execute U071 to adjust the timing of the DP leading edge when the scanning position is changed.

Method

- 1.Press the [Start] key.
- 2.Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------|--|----------------------|------------------------|-----------------------|
| DP Read | Adjusts the starting position for scanning originals. | -33 to 33 | 0 | 0.158 mm |
| Black Line | Adjusts the scanning position for the test copy originals. | 0 to 3 | 0 | - |

Adjustment: DP Read

- 1.Select [DP Read].
- 2.Press the [◀] [▶] keys or the numeric keys to change the counter value.
* :When the setting value is increased, the image moves backward, and it moves forward when the setting value is decreased.
- 3.Press the [Start] key to set the setting value.

Adjustment: Black Line

- 1.Select [Black Line].
- 2.Press the [◀] [▶] keys or the numeric keys to change the counter value.
- 3.Press the [Start] key to set the setting value.
- 4.Set the original (the one of which density is known) in the DP and press the [System Menu/Counter] key.
- 5.Press the [Start] key to execute the test copy.
- 6.Perform the test copy at each scanning position with the setting value from 0 to 3 and check that no black line appears and the image is normally scanned.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U070 | DP magnification adjustment (Message: Adj DP Motor) |
|-------------|--|

Contents

Adjusting the magnification for DP scanning.

Purpose

Adjusted if the magnification is incorrect in the auxiliary scanning direction when the DP is used

Adjustment

- 1.Press the [Start] key.
- 2.Press the [System Menu/Counter] key.
- 3.Place an original on the DP and press the [Start] key to make a test copy.
* :Check the duplex scanning by setting [Duplex] when test copying.
- 4.Press the [System Menu/Counter] key.
- 5.Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|---------------------|---|----------------------|------------------------|-----------------------|
| SubScan(F) | Adjusting the magnification for table scanning | -25 to 25 | - | 0.1 % |
| SubScan(B) | Adjusts the 2nd side magnification in the sub scanning direction when duplex scanning | -25 to 25 | - | 0.1 % |
| Duplex 1side | Adjusts the 1st side magnification in the sub scanning direction when duplex scanning | -25 to 25 | -3 | 0.1 % |

- 6.Press the [◀] [▶] keys or the numeric keys to change the counter value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the image get longer, and it shortens when the setting value is decreased.




Figure 6-11

- 7.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U071 | Adjusting the DP leading edge Timing (Message: DP Timing) |
|-------------|--|

Contents

Adjusts the DP original scanning timing.

Purpose

Adjusted if there is a regular error between the leading or trailing edges of the original and the copy image when the DP is used

Method


1. Press the [Start] key.
2. Press the [System Menu/Counter] key.
3. Place an original on the DP and press the [Start] key to make a test copy.
 - * :Check the duplex scanning by setting [Duplex] when test copying.
4. Press the [System Menu/Counter] key.
5. Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------|--|---------------|-----------------|----------------|
| Front Head | Leading edge registration. (Front page) | -32 to 32 | 0 | 0.245m m |
| Front Tail | Trailing edge registration. (Front page) | -32 to 32 | 0 | 0.245m m |
| Back Head | Leading edge registration. (Back page) | -32 to 32 | 0 | 0.245m m |
| Back Tail | Trailing edge registration. (Back page) | -32 to 32 | 0 | 0.245m m |

Adjustment: Front Head/Back Head

1. Press the [◀] [▶] keys or the numeric keys to change the counter value.
 - For the copy example 1, increase the value.
 - For the copy example 2, decrease the value.

* :When the setting value is increased, the image moves forward, and it moves backward when the setting value is decreased.

**Figure 6-12**

2. Press the [Start] key to set the setting value.

Precautions

Check the 2nd side after adjusting the 1st side. Adjust if necessary.

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034(P.6-228) > U071

Adjustment: Front Tail/Back Tail

1. Press the [◀] [▶] keys or the numeric keys to change the counter value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the image get longer, and it shortens when the setting value is decreased.




Figure 6-13

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U072 | Adjusting the DP original center (Message: DP Center) |
|-------------|--|

Contents

Adjusts the DP original center line.

Purpose

Adjusted if there is a regular error between the center lines of the original and the copy image when the DP is used

Adjustment

1. Press the [Start] key.
2. Press the [System Menu/Counter] key.
3. Place an original on the DP and press the [Start] key to make a test copy.
* :Check the duplex scanning by setting [Duplex] when test copying.
4. Press the [System Menu/Counter] key.
5. Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|--------------|------------------------------|---------------|-----------------|----------------|
| Front | DP center line. (Front page) | -40 to 40 | - | 0.085 mm |
| Back | DP center line. (Back page) | -40 to 40 | - | 0.085 mm |

6. Press the [◀] [▶] keys or the numeric keys to change the counter value.

For the copy example 1, decrease the value.

For the copy example 2, increase the value.

* :When the setting value is increased, the image moves to left, and it moves to right when the setting value is decreased.




Figure 6-14

7. Press the [Start] key to set the setting value.

Precautions

Check the 2nd side after adjusting the 1st side. Adjust if necessary.

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034 (P.6-228) > U065 (P.6-238) > U067 (P.6-241) > U072

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U089 | MIP-PG pattern output (Message: Output MIP-PG) |
|-------------|---|

Contents

Select and output the MIP-PG pattern generated by the main unit.





Purpose

When adjusting the image scanning items, execute to check the machine status except the scanner section using the MIP-PG pattern output without image scanning process.

Method

1. Press the [Start] key.
2. Select the MIP-PG pattern to output

| Items | Contents |
|---------------------|---|
| Printer Gray | For grayscale level check  |
| White | For drum quality check (Blank PG)  |
| White(Color) | Color for drum quality check (Blank PG)  |
| Gray(C) | For drum quality check (Cyan PG)  |
| Gray(M) | For drum quality check (Magenta PG)  |

| Items | Contents |
|------------------------|---|
| Gray(Y) | For drum quality check (Yellow PG)  |
| Gray(K) | For drum quality check (Gray PG)  |
| Color Belt | PG for the developer status and engine ID check (four color PG)  |
| Color Gradation | Printing 64 grayscales to check 4 colors  |
| Sample Set | Outputs the following output patterns for the long life unit warranty application PG for the developer status and engine ID check (four color PG) For drum quality check (Yellow PG) For drum quality check (Cyan PG) For drum quality check (Magenta PG) For drum quality check (Gray PG) |

- 3.Press the [System Menu/Counter] key.
- 4.Press the [Start] key to output a MIP-PG pattern.
- 5.Press the [System Menu/Counter] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U100 | Main high voltage adjustment (Message: Main HV Output) |
|-------------|---|

Contents

Adjust the surface potential by changing the voltage impressed to the main charge roller.

Purpose

Change the set value to adjust the image when an image failure (background image) occurs.

Method

1. Press the [Start] key.
2. Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|-------------------------|--|
| Set DC Bias | Displays the main charge DC bias correction value for each color. |
| Adj DC Bias | Adjust the surface potential additional value |
| Set DC Bias Base | Displays the main charge DC bias base value for each color. (Adjusted value before correction) |
| Chk Current | Displays the electric current flows |
| Set Main HV | Sets the main high voltage mode |
| MCH | Set MC correction |

Setting: Set DC Bias

1. Displays the current setting.

| Items | Contents |
|---------------|---|
| DC1(C) | Cyan main charge DC bias correction value (Full speed) |
| DC1(M) | Magenta main charge DC bias correction value (Full speed) |
| DC1(Y) | Yellow main charge DC bias correction value (Full speed) |
| DC1(K) | Black main charge DC bias correction value (Full speed) |

Setting: Adj DC Bias

1. Select the item to set.

2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

* :When the setting value is increased, the image get thinner, and it gets thicker when the setting value is decreased.

| Items | Contents | Setting range | Initial setting |
|---------------------|---|---------------|-----------------|
| DC2(C) | Cyan main charge DC bias additional value (Full speed) | -1000 to 1000 | 0 |
| DC2 3/4(C) | Cyan main charge DC bias additional value (3/4 speed) | -1000 to 1000 | 0 |
| DC2 Half(C) | Cyan main charge DC bias additional value (Half speed) | -1000 to 1000 | 0 |
| DC2(M) | Magenta main charge DC bias additional value (Full speed) | -1000 to 1000 | 0 |
| DC2 3/4(C) | Magenta main charge DC bias additional value (3/4 speed) | -1000 to 1000 | 0 |
| DC2 Half(M) | Magenta main charge DC bias additional value (Half speed) | -1000 to 1000 | 0 |
| DC2(Y) | Yellow main charge DC bias additional value (Full speed) | -1000 to 1000 | 0 |
| DC2 3/4(Y) | Yellow main charge DC bias additional value (3/4 speed) | -1000 to 1000 | 0 |
| DC2 Half(Y) | Yellow main charge DC bias additional value (Half speed) | -1000 to 1000 | 0 |
| DC2(K) | Black main charge DC bias additional value (Full speed) | -1000 to 1000 | 0 |
| DC2 3/4(K) | Black main charge DC bias additional value (3/4 speed) | -1000 to 1000 | 0 |
| DC2s Half(K) | Black main charge DC bias additional value (Half speed) | -1000 to 1000 | 0 |

3. Press the [Start] key to set the setting value.

Setting: Set DC Bias Base

1. Displays the current setting.

| Items | Contents |
|----------------------|---|
| DC1 B(C) | Cyan main charge DC bias base value (Full speed) |
| DC1 B3/4(C) | Cyan main charge DC bias base value (3/4 speed) |
| DC1 B Half(C) | Cyan main charge DC bias base value (Half speed) |
| DC1 B(M) | Magenta main charge DC bias base value (Full speed) |
| DC1 B 3/4(M) | Magenta main charge DC bias base value (3/4 speed) |
| DC1 B Half(M) | Magenta main charge DC bias base value (Half speed) |
| DC1 B(Y) | Yellow main charge DC bias base value (Full speed) |

| Items | Contents |
|----------------------|--|
| DC1 B 3/4(Y) | Yellow main charge DC bias base value (3/4 speed) |
| DC1 B Half(Y) | Yellow main charge DC bias base value (Half speed) |
| DC1 B(K) | Black main charge DC bias base value (Full speed) |
| DC1 B 3/4(K) | Black main charge DC bias base value (3/4 speed) |
| DC1 B Half(K) | Black main charge DC bias base value (Half speed) |

Refer: Chk Current

1. Displays the current setting.

| Items | Contents |
|----------|------------------------|
| C | Cyan inflow current |
| M | Magenta inflow current |
| Y | Yellow inflow current |
| K | Black inflow current |

Setting: Set Main HV

1. Select the item to set.

| Items | Contents | Setting range | Initial setting |
|-------------------|---|---------------|-----------------|
| White Line | Switch On/Off the white streak prevention control | On/Off | Off |
| Agent Time | Aging time by surface speed gap | 0 to 255 | 0 |

2. Press the [Start] key to set the setting value.

Setting: MCH

1. Select the item to set.

| Items | Contents | Setting range | Initial setting |
|--------------|----------------|---------------|-----------------|
| Value | MCH correction | 1 to 7 | 4 |

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U101 | Primary transfer voltage adjustment (Message: 1st TC Output) |
|-------------|---|

Contents

Set the primary transfer control voltage

Purpose

Change setting if a failure such as faint image, etc. occurs.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|-------------------------|--------------------------------------|
| Normal | Set the primary transfer voltage |
| Add Color | Sets 2nd side additional value |
| Add Color 2nd | Sets 2nd side additional value. |
| Surround Correct | Setting the environmental correction |

Setting: Normal

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------|--|---------------|-----------------|----------------|
| Full | Yellow primary transfer voltage (full speed) | 0 to 400 | 70 | - |
| Half | Yellow primary transfer voltage (half speed) | 0 to 400 | 43 | - |
| 3/4 | Yellow primary transfer voltage (3/4 speed) | 0 to 400 | 56 | - |

3. Press the [Start] key to set the setting value.

Setting: Add Color

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------|---|---------------|-----------------|----------------|
| C | Sets the additional value (Cyan) | -200 to 200 | -4 | - |
| M | Sets the additional value (Magenta) | -200 to 200 | -4 | - |
| Y | Sets the additional value (Yellow) | -200 to 200 | 0 | - |
| K | Sets the additional value (Black) | -200 to 200 | 17 | - |
| B/W | Monochrome mode (toner applying amount) | -200 to 200 | -27 | - |

3. Press the [Start] key to set the setting value.

Setting: Add Color 2nd

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------|-------------------------------------|---------------|-----------------|----------------|
| C | 2nd side additional value (Cyan) | -200 to 200 | 4 | - |
| M | 2nd side additional value (Magenta) | -200 to 200 | 4 | - |
| Y | 2nd side additional value (Yellow) | -200 to 200 | 0 | - |
| K | 2nd side additional value (Black) | -200 to 200 | 17 | - |

3. Press the [Start] key to set the setting value.

Setting: Surround Correct

1. Select the item to set.
2. By using the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------------------|--|-----------------|-----------------|----------------|
| Mode | Environmental correction (On/Off) | 0: On 1: Off | On | - |
| Rev Bias | Reverse bias cleaning | -200 to 200 | 30 | - |
| High Altitude | High altitude correction control (2nd side correction) | -200 to 200 | 85 | - |

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U106 | Secondary transfer voltage adjustment (Message: 2nd TC Output) |
|-------------|---|

Contents

Set the secondary transfer control voltage.

Purpose

Change setting if a failure such as faint image, etc. occurs.

Method

1.Press the [Start] key.

2.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|------------------------|--|
| Light/Normal1 | Transfer control value for Light and Normal1 |
| Normal2/3 | Transfer control value for Normal 2 / 3 |
| Light/Normal123 | Transfer control value for Light to Normal1,2,3 |
| Heavy1 | Transfer control value for Normal 1 / 3 |
| Heavy2/3 | Transfer control value for Heavy 2 / 3 |
| OHP | Transfer control value for Transparency |
| Light-Normal3 | Transfer control value for Light to Normal3 |
| Bias | Bias setting |
| High Altitude | High altitude correction control setting (2nd side correction) |
| Paper End | Turning off the secondary transfer at the paper end |

Setting: Light/Normal1

1.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|------------|---|
| 1st | 1st side transfer control value at full speed |
| 2nd | 2nd side transfer control value at full speed |

2.Select the item to set.

3.Press the [◀] [▶] keys or the numeric keys to change the counter value.

1st

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 600 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 400 | - |

2nd

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 700 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 400 | - |

4.Press the [Start] key to set the setting value.

Setting: Normal2/3

1.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|------------|---|
| 1st | 1st side transfer control value at full speed |
| 2nd | 2nd side transfer control value at full speed |

2.Select the item to set.

3.Press the [◀] [▶] keys or the numeric keys to change the counter value.

1st

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 650 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 500 | - |

2nd

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 750 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 500 | - |

4.Press the [Start] key to set the setting value.

Setting: Light/Normal123

1.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|----------------|--|
| 1st B/W | 1st side transfer control value in monochrome mode |
| 2nd B/W | 2nd side transfer control value in monochrome mode |

2.Select the item to set.

3.Press the [◀] [▶] keys or the numeric keys to change the counter value.

1st

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 550 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 400 | - |

2nd

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 650 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 300 | - |

4. Press the [Start] key to set the setting value.

Setting: Heavy1

1. Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|--------------------|---|
| 1st 3/4 | 1st side transfer control value at 3/4 speed |
| 2nd 3/4 | 2nd side transfer control value at 3/4 speed |
| 1st Half | 1st side transfer control value at half speed |
| 2nd Half | 2nd side transfer control value at half speed |
| 1st 3/4 B/W | 1st side transfer control value at 3/4 speed in monochrome mode |
| 2nd 3/4 B/W | 2nd side transfer control value at 3/4 speed in monochrome mode |

2. Select the item to set.

3. Press the [◀] [▶] keys or the numeric keys to change the counter value.

1st 3/4

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 530 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 380 | - |

2nd 3/4

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 650 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 330 | - |

1st Half

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 350 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 250 | - |

2nd Half

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 350 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 250 | - |

1st 3/4 B/W

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 480 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 330 | - |

2nd 3/4 B/W

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 580 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 280 | - |

4. Press the [Start] key to set the setting value.

Setting: Heavy2/3

1. Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|---------------------|--|
| 1st Half | 1st side transfer control value at half speed |
| 2nd Half | 2nd side transfer control value at half speed |
| 1st Half B/W | 1st side transfer control value at half speed in monochrome mode |
| 2nd Half B/W | 2nd side transfer control value at half speed in monochrome mode |

2. Select the item to set.

3. Press the [◀] [▶] keys or the numeric keys to change the counter value.

1st Half

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 450 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 300 | - |

2nd Half

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 550 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 250 | - |

1st Half B/W

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 450 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 300 | - |

2nd Half B/W

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 550 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 250 | - |

4. Press the [Start] key to set the setting value.

Setting: OHP

1. Select the item to set.

2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 450 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 300 | - |

3. Press the [Start] key to set the setting value.

Setting: Light-Normal3

1. Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|-----------------|--------------------------------|
| 1st 3/4 | 1st side setting at 3/4 speed |
| 2nd 3/4 | 2nd side setting at 3/4 speed |
| 1st Half | 1st side setting at half speed |
| 2nd Half | 2nd side setting at half speed |

2. Select the item to set.

3. Press the [◀] [▶] keys or the numeric keys to change the counter value.

1st 3/4

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 490 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 380 | - |

2nd 3/4

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 560 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 380 | - |

1st Half

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 330 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 250 | - |

2nd Half

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 380 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 250 | - |

4. Press the [Start] key to set the setting value.

Setting: Bias

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------------------|---|---------------|-----------------|----------------|
| Reverse 2nd | Secondary transfer cleaning negative bias | -1 to 200 | -1 | - |
| Cleaning 2nd | Secondary transfer cleaning positive bias | 0 to 200 | 5 | - |
| Calb Cleaning | Calibration cleaning bias | 0 to 200 | 40 | - |

3. Press the [Start] key to set the setting value.

Setting: High Altitude

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------------------|---------------------------|---------------|-----------------|----------------|
| Light/Normal1 | Light and Normal1 setting | 0 to 100 | 85 | - |
| Normal2/3 | Setting of Normal 1/2 | 0 to 100 | 80 | - |

3. Press the [Start] key to set the setting value.

Setting: Paper End

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------------|----------------------|---------------|-----------------|----------------|
| Heavy2/3 | Setting for Thick2,3 | 0 to 100 | 35 | - |
| Ext Heavy | Ext Heavy setting | 0 to 100 | 35 | - |

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U107 | Primary transfer cleaning voltage adjustment (Message: Adj 1st TC Clean) |
|-------------|---|

Contents

Sets the transfer belt cleaning control voltage

Purpose

Change the setting when offset images appear with the transfer belt cleaning failure.

Method

1.Press the [Start] key.

2.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|----------------|----------------|
| Belt(A) | Belt A setting |
| Belt(B) | Belt B setting |
| Belt(C) | Belt C setting |
| Belt(D) | Belt D setting |

Setting

1.Select the item to set.

2.Press the [◀] [▶] keys or the numeric keys to change the counter value.

Belt(A)

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------|--------------------|---------------|-----------------|----------------|
| Full | Full speed setting | 0 to 300 | 30 | - |
| Half | Half speed setting | 0 to 300 | 23 | - |
| 3/4 | 3/4 speed setting | 0 to 300 | 26 | - |

Belt(B)

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------|--------------------|---------------|-----------------|----------------|
| Full | Full speed setting | 0 to 300 | 45 | - |
| Half | Half speed setting | 0 to 300 | 45 | - |
| 3/4 | 3/4 speed setting | 0 to 300 | 45 | - |

Belt(C)

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------|--------------------|---------------|-----------------|----------------|
| Full | Full speed setting | 0 to 300 | 110 | - |
| Half | Half speed setting | 0 to 300 | 110 | - |
| 3/4 | 3/4 speed setting | 0 to 300 | 110 | - |

Belt(D)

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------|--------------------|---------------|-----------------|----------------|
| Full | Full speed setting | 0 to 300 | | - |
| Half | Half speed setting | 0 to 300 | | - |
| 3/4 | 3/4 speed setting | 0 to 300 | | - |

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U110 | Drum counter (Message: Drum Cnt) |
|-------------|---|

Contents

Displays the drum counter values.

Purpose

Execute to check the drum usage status.

Method

1. Press the [Start] key.

* :The drum counter is displayed.

| Items | Contents |
|----------|-----------------------------------|
| C | Displays the cyan drum counter |
| M | Displays the magenta drum counter |
| Y | Displays the yellow drum counter |
| K | Displays the black drum counter |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U117 | Drum unit number (Message: Drum No.) |
|-------------|---|

Contents

Displays the drum number.

Purpose

Execute to check the drum number.

Method

1.Press the [Start] key.

* :Displays the drum number.

| Items | Contents |
|--------------|----------------------------------|
| C | Displays the cyan drum number |
| M | Displays the magenta drum number |
| Y | Displays the yellow drum number |
| K | Displays the black drum number |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U118 | Drum unit history (Message: Drum History) |
|-------------|--|

Contents

Displays the machine serial number and drum counter history.

Purpose

Execute to check the machine serial number and drum counter values.

Method

1.Press the [Start] key.

* :Select the item to refer to.

| Items | Contents |
|--------------|-----------------------------------|
| C | Displays the cyan drum history |
| M | Displays the magenta drum history |
| Y | Displays the yellow drum history |
| K | Displays the black drum history |

* :Displays the machine serial number and 3 items of the drum counter history.

| Items | Contents |
|------------------------------|-------------------------------|
| Machine History1 to 3 | Machine serial number history |
| Cnt History1 to 3 | The drum counter history |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U119 | Setting the drum (Message: Set Drum) |
|-------------|---|

Contents

Set the drum sensitivity.

Purpose

Execute when the drum unit or laser scanner unit is replaced.
After completing, execute maintenance mode U464 [Calibration].

Method

1. Press the [Start] key.
2. Select [Execute].

| Items | Contents |
|----------------|--|
| Execute | Detect the main charge current and save the current value. |

3. Press the [Start] key.
* :Starts the drum setup operation.
4. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.
* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U120 | Drum drive distance counter (Message: Drum Drv Dist Cnt) |
|-------------|---|

Contents

Displays the drum drive distance counter.

Purpose

Execute to displays the drum drive distance counter.

Method

1. Press the [Start] key.
* :Displays the count.

| Items | Contents |
|----------|--|
| C | Displays the cyan drum drive distance counter |
| M | Displays the magenta drum drive distance counter |
| Y | Displays the yellow drum drive distance counter |
| K | Displays the black drum drive distance counter |

Completion

Press the [Stop] key.
* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U127 | Clearing the transfer count (Message: Clr Trans Cnt) |
|-------------|---|

Contents

Display and clear the transfer counts for the transfer high-voltage output correction etc.

Purpose

Verify the primary/secondary transfer unit counts after replacing Also, clear the counts after replacement

Method

1.Press the [Start] key.

* : The transfer counter value appears.

| Items | Contents |
|-----------------|---|
| Mid(Cnt) | Displays or clears the primary transfer counter |
| 2nd(Cnt) | Displays or clears the secondary transfer counter |

Setting: Mid(Cnt)

* :Clear only. This cannot be changed.

1.Select [Clear].

2.Press the [Start] key to set the counter value.

Setting: 2nd(Cnt)

1.Press the [◀] [▶] keys or the numeric keys to change the counter value.

2.Press the [Start] key to set the counter value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U128 | Leading edge timing (Message: Adj Trans Timing) |
|-------------|--|

Contents

Adjust On/Off timing of the transfer high voltage output.

Purpose

Prevent paper from being rolled up by the drum.

Method

1. Press the [Start] key.

2. Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|-------------------|--|
| Timing 1st | Transfer On timing adjustment value (1st side) |
| Timing 2nd | Transfer On timing adjustment value (2nd side) |

Setting: Timing 1st

1. Select the item to set.

2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------|--------------------------------------|---------------|-----------------|----------------|
| On Timing | Transfer On timing adjustment value | -200 to 200 | 0 | 0.5mm |
| Off Timing | Transfer Off timing adjustment value | -200 to 200 | 0 | 0.5mm |

3. Press the [Start] key to set the setting value.

Setting: Timing 2nd

1. Select the item to set.

2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------------|---|---------------|-----------------|----------------|
| 1side < 60 | Secondary transfer voltage on timing (1st side, weight less than 60gsm) | -200 to 200 | 0 | 0.5mm |
| 1side >= 60 | Secondary transfer voltage on timing (1st side, weight 60gsm or more) | -200 to 200 | 0 | 0.5mm |
| 2side < 60 | Secondary transfer voltage on timing (2nd side, weight less than 60gsm) | -200 to 200 | 0 | 0.5mm |
| 2side >= 60 | Secondary transfer voltage on timing (2nd side, weight 60gsm or more) | -200 to 200 | 0 | 0.5mm |

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------|---------------------------------------|---------------|-----------------|----------------|
| Off Timing | Secondary transfer voltage off timing | -200 to 200 | 0 | 0.5mm |

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U132 | Forcible toner supply operation (Message: Supply Toner) |
|-------------|--|

Contents

Toner is supplied forcibly until the toner sensor output value reaches the toner supply level.

Purpose

Execute if toner empty is often detected.

Method

1. Press the [Start] key.

2. Select [Execute].

3. Press the [Start] key.

* :Execute toner supply forcibly until the toner sensor output value reaches the toner supply level.

| Items | Contents |
|------------------|-----------------------------------|
| Supply(C) | Cyan toner supply level |
| Supply(M) | Magenta toner supply level |
| Supply(Y) | Yellow toner supply level |
| Supply(K) | Black toner supply level |
| Sensor(C) | Cyan toner sensor output value |
| Sensor(M) | Magenta toner sensor output value |
| Sensor(Y) | Yellow toner sensor output value |
| Sensor(K) | Black toner sensor output value |
| Execute | Installs toner |

4. To stop the operation, press the [Stop] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U135 | Checking the toner motor operation (Message: Chk Toner Motor) |
|-------------|---|

Contents

Drives the toner motor.

Purpose

Execute to check the toner motor operation.

Precautions

If driven for a long time or several times repeatedly, the developer unit will be full of toner inside and it may lock up.

Method

- 1.Press the [Start] key.
 - 2.Select [Toner].
 - 3.Press the [Start] key.
- * :The operation starts.

| Items | Contents |
|--------------|----------------------------|
| Toner | Drives the toner motor(TM) |

- 4.To stop the operation, press the [Stop] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U136 | Toner level detection setting (Message: Set Toner NearEnd) |
|-------------|--|

Contents

Execute the level setting of printable pages between toner near end and toner empty.

Purpose

Change the timing of detecting toner near end earlier than the current setting if the interval between toner near end and toner empty is too short.

Setting

- 1.Press the [Start] key.
 - 2.Select the item to set.
- * :Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------|---|---------------|-----------------|----------------|
| CMY | Black/Cyan/Magenta/Yellow toner level setting | 0 to 9 | 3 | - |
| K | Setting the black toner level | 0 to 9 | 3 | - |

If the set value is increased, the time interval from the toner near end to the toner empty becomes longer.

If the set value is reduced, the time interval from toner near end to toner empty becomes shorter.

0: no toner near end detection

- 3.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U139 | Temperature, humidity (Message: Temp/Humidity) |
|-------------|---|

Contents

Displays the machine inside and outside temperature and machine outside humidity.

Purpose

Check the machine inside and outside temperature and machine outside humidity.

Method

1. Press the [Start] key.

* :Each value is displayed.

| Items | Contents |
|---------------------|--|
| Ext Temp | Displays the machine outside temperature. |
| Ext Humidity | Displays the machine outside humidity. |
| Dev Temp | Displays the developer (K) temperature inside the machine. |
| LSU Temp(K) | Displays the LSU (K) temperature inside the machine. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U140 | Developer bias adjustment (Message: Adj Dev Bias) |
|-------------|--|

Contents

Displays/changes the developer bias set values or sets high altitude mode.

Purpose

Execute to check/change the developer bias set values.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|----------------------------|--|
| Sleeve DC | Set the developer sleeve roller DC bias. |
| Sleeve AC | Set the developer sleeve roller AC bias. |
| Mag DC | Set the developer magnet roller DC bias. |
| Sleeve Freq | Set the developer sleeve roller frequency. |
| Sleeve Duty | Set the developer sleeve roller duty. |
| Mag Duty | Set the developer magnet roller duty. |
| Altitude Adjustment | Sets the altitude adjustment mode |

Setting: Sleeve DC

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------|------------------|---------------|-----------------|----------------|
| C | Sets the cyan | 0 to 350 | 200 | 1V |
| M | Sets the magenta | 0 to 350 | 200 | 1V |
| Y | Sets the yellow | 0 to 350 | 200 | 1V |
| K | Sets the black | 0 to 350 | 200 | 1V |

3. Press the [Start] key to set the setting value.

Setting: Sleeve AC

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------|------------------|---------------|-----------------|----------------|
| C | Sets the cyan | 100 to 175 | 145 | 1V |
| M | Sets the magenta | 100 to 175 | 145 | 1V |
| Y | Sets the yellow | 100 to 175 | 145 | 1V |
| K | Sets the black | 100 to 175 | 145 | 1V |

3. Press the [Start] key to set the setting value.

Setting: Mag DC

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------|------------------|---------------|-----------------|----------------|
| C | Sets the cyan | 0 to 750 | 470 | 1V |
| M | Sets the magenta | 0 to 750 | 470 | 1V |
| Y | Sets the yellow | 0 to 750 | 470 | 1V |
| K | Sets the black | 0 to 750 | 470 | 1V |

3. Press the [Start] key to set the setting value.

Setting: Sleeve Freq

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|---------------|----------------------------|---------------|-----------------|----------------|
| Normal | Execute full speed setting | 3600 | 3600 | 1Hz |

3. Press the [Start] key to set the setting value.

Setting: Sleeve Duty

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|---------------|----------------------------|---------------|-----------------|----------------|
| Normal | Execute full speed setting | 34 | 34 | 1% |

3. Press the [Start] key to set the setting value.

Setting: Mag Duty

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|---------------|----------------------------|---------------|-----------------|----------------|
| Normal | Execute full speed setting | 50 to 80 | 34 | 1% |

3. Press the [Start] key to set the setting value.

Setting: Altitude Adjustment

1. Select the item to set.

| Items | Contents |
|----------------------|----------------------|
| Normal | Sets 1000m or less |
| 1001 to 2000m | Set at 1001 to 2000m |
| 2001 to 3000m | Set at 2001 to 3000m |
| 3001 to 3500m | Set at 3001 to 3500m |

* :Initial setting: Normal

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U147 | Setting the toner applying mode (Message: Set Toner Apply) |
|-------------|---|

Contents

Mode selection for the operation to remove overcharged toner in the developer unit (Toner applying mode). Also, sets the operation to take toner accumulated on the developer blade back to the developer unit (vibration motor control).

Purpose

Change the setting to reduce the toner applying amount. Execute to change the vibration motor control frequency.

* :Density is lowered if overcharged toner stays in the developer unit.

Method

- 1.Press the [Start] key.
- 2.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|----------------|--|
| Mode | Sets the toner applying mode. |
| Drum T7 | Sets the toner applying width at the cleaning mode. |
| Dev T7 | Sets the upper limit of the toner applying amount for each operation mode. |
| Motor | Sets the vibration motor operation. |

Setting: Mode

- 1.Select the item to set.

| Items | Contents |
|------------|---|
| On | Sets the toner applying operation with the normal amount. |
| Off | Sets the toner applying operation with less than the normal amount. |

* :Initial setting: On

- 2.Press the [Start] key to set the setting value.

Setting: Drum T7

- 1.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|--------------|---|---------------|----------------------------|----------------|
| Value | Sets the toner applying width at the cleaning mode. | 0 to 25 | 150 (Indicated as 15.0) | 0.1mm |

- 2.Press the [Start] key to set the setting value.

Setting: Dev T7

1.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|--------------|--|---------------|--------------------------|----------------|
| Value | Sets the upper limit of the toner applying amount for each operation mode. | 0 to 25 | 20 (Indicated as 2.0) | 1% |

2.Press the [Start] key to set the setting value.

Setting: Motor

1.By using the [◀] [▶] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------------------|--|---------------|-----------------|----------------|
| Print(Normal) | Sets the continuous printing (normal environment) | 10 to 2550 | - | 10 |
| Print(H/H) | Sets continuous printing (high temperature, high humidity) | 10 to 2550 | - | 10 |
| Print End | Setting when completing printing | 1 to 255 | - | 1 |

2.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U148 | Drum refresh mode setting (Message: Set Drum Refresh) |
|-------------|--|

Contents

Sets the mode to use the drum refresh in the user adjustment.

Purpose

Change the setting if the drum refresh is frequently operated.

Setting

1.Press the [Start] key.

2.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|---------------|------------------------|-----------------------------|-----------------|----------------|
| Normal | Sets Auto drum refresh | 0: Off 1 to 3: Standard? | 1 | - |

3.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U155 | Toner sensor output (Message: Toner S Output) |
|-------------|--|

Contents

Displays the toner sensor output

Purpose

Execute to check each color's output value when an image failure occurs.

Method

1. Press the [Start] key.
 2. Select the item to refer to.
- * :Switched to each reference screen.

| Items | Contents |
|--------------------|---|
| Waste Toner | Displays the toner sensor value |
| Toner | Displays the toner sensor value and supply level value for each color |

Method: Waste Toner

1. Check each sensor value.
- * :Displays the waste toner sensor value.

| Items | Contents |
|------------------|--|
| Full | Displays the waste toner sensor value 1 (WTS1) |
| Near Full | Displays the waste toner sensor value 2 (WTS2) |

Method: Toner

1. Check each sensor value.
- * :Displays the toner sensor value.

| Items | Contents |
|------------------|--|
| Sensor(C) | Displays the cyan toner sensor output value |
| Sensor(M) | Displays the magenta toner sensor output value |
| Sensor(Y) | Displays the yellow toner sensor output value |
| Sensor(K) | Displays the black toner sensor output value |
| Supply(C) | Displays the cyan toner supply level value |
| Supply(M) | Displays the magenta toner supply level value |
| Supply(Y) | Displays the yellow toner supply level value |
| Supply(K) | Displays the black toner supply level value |

Completion

- Press the [Stop] key.
- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U156 | Toner control level adjustment (Message: Adj Tnr Ctrl Lv) |
|-------------|--|

Contents

Displays the toner supply level for each color.

Purpose

Execute displaying the toner supply level for each color.

Setting

- 1.Press the [Start] key.
- 2.Select [Supply].

| Items | Contents |
|---------------|---------------------------------|
| Supply | Displays the toner supply level |

- 3.Displays the toner supply level for each color.

| Items | Contents |
|----------|---|
| C | Displays the cyan toner supply level |
| M | Displays the magenta toner supply level |
| Y | Displays the yellow toner supply level |
| K | Displays the black toner supply level |

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U157 | Developer drive time (Message: Dev Time) |
|-------------|---|

Contents

Displays the developer drive time to be a reference for the toner density control correction.

Purpose

Execute to check the developer drive time since replacing the developer unit.

Method

- 1.Press the [Start] key.
- * :Displays the developer drive time.

| Items | Contents |
|----------|---|
| C | Displays the Cyan developer unit drive time. |
| M | Displays the Magenta developer unit drive time. |
| Y | Displays the Yellow developer unit drive time. |
| K | Displays the Black developer unit drive time. |

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U158 | Developer counter (Message: Dev Cnt) |
|-------------|---|

Contents

Displays the developer counter

Purpose

Execute to check the developer unit usage status.

Method

1. Press the [Start] key.

* :The developer count is displayed.

| Items | Contents |
|--------------|---|
| C | Displays the cyan developer counter. |
| M | Displays the magenta developer counter. |
| Y | Displays the yellow developer counter. |
| K | Displays the black developer counter. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U161 | Fuser temperature adjustment (Message: Adj Fuser Temp) |
|-------------|---|

Contents

Sets the fuser temperature.

Purpose

Normally no need to change. However, change the setting as corrective measures for paper curl, creases and fusing failure on thick paper.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|---------------|---|
| Center | Set the center thermistor temperature. |
| Edge | Sets the edge thermistor control temperature. |

Setting: Center

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------------|--|---------------|-----------------|----------------|
| Pressure Start | Sets the temperature to start pressing | 0 to 200 | 30 | 1°C |
| Drive Start | Sets the drive start temperature | 0 to 200 | 100 | 1°C |
| Ready | Sets the Ready temperature | 100 to 200 | 145 | 1°C |
| Steady | Sets the secondary stability temperature | 100 to 200 | 155 | 1°C |
| Printing | Set the temperature during printing | 100 to 200 | 155 | 1°C |
| Waiting | Set the standby temperature | 100 to 200 | 155 | 1°C |

3. Press the [Start] key to set the setting value.

Setting: Edge

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------------|--|---------------|-----------------|----------------|
| Ready | Sets the Ready temperature | 100 to 200 | 105 | 1°C |
| Steady | Sets the secondary stability temperature | 100 to 200 | - | 1°C |
| Waiting | Set the standby temperature | 100 to 200 | - | 1°C |

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U167 | Clearing the fuser count (Message: Clr Trans Cnt) |
|-------------|--|

Contents

Displays and clears the fuser count.

Purpose

Verify the fuser count after replacement Also, clear the counts after replacement

Method

1.Press the [Start] key.

* : The fuser count is displayed.

| Items | Contents |
|--------------|--------------------------|
| Cnt | Displays the fuser count |
| Clear | Clears the fuser count |

Method: Clear

1.Select [Clear].

2.Press the [Start] key.

* :Fuser unit counter is cleared.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U199 | Fuser temperature (Message: Fuser Temp) |
|-------------|--|

Contents

Fuser temperature is displayed.

Purpose

Execute to check the fuser temperature.

Method

1.Press the [Start] key.

* :Fuser temperature is displayed.

| Items | Contents |
|---------------------------|--|
| Heat Roller Edge | Displays the heat roller edge temperature (°C) |
| Heat Roller Center | Displays the heat roller center temperature (°C) |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U200 | All LEDs lighting (Message: All LEDs ON) |
|-------------|---|

Contents

All the LEDs on the operation panel are lit.

Purpose

Execute to check the operation panel LED lighting.

Method

1. Press the [Start] key.
2. Select [Execute].
3. Press the [Start] key.
* :All the LEDs on the operation panel are blinking.
4. Press the [Stop] key to turn the display off.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U201 | Initializing the touch panel (Message: Init Touch Panel) |
|-------------|---|

Contents

Adjusts touch panel detecting positions.

Purpose

Correct and confirm the touch panel detecting positions, when the panel PWB or the operation panel is replaced or if the detecting positions are not aligned.

Method

- 1.Press the [Start] key.
 - 2.Select the item to execute.
 - 3.Press the [Start] key.
- * :The screen for executing is displayed.

| | |
|------------------|------|
| Init Touch Panel | U201 |
| 01 Initialize | |
| 02 Check | |

| Items | Contents |
|-------------------|---|
| Initialize | Automatically corrects the touch panel display position |
| Check | Checks the touch panel display position |

Method: Initialize


- 1.Press the center of "+".
 - 2.Repeat 3 times.
- 3.After finishing setting, the [Check] screen is automatically displayed.



Method: Check

- 4.Press the indicated three "+", and then check the display position.

* :If out of the specified value, select [Initialize] and press the [Start] key to return to Step. 1.



Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U203 | Check DP operation (Message: Chk DP Ope) |
|-------------|---|

Contents

Simulate the original conveying operation separately in the DP.

Purpose

Check the DP operation

Method

1. Press the [Start] key.
2. Place an original in the DP if running this simulation with paper.
3. Select the scan speed

| Items | Contents |
|---------------------|--------------------------|
| Normal Speed | Normal scanning (600dpi) |
| High Speed | High speed scanning |

Method: Normal Speed/High Speed

4. Select the item to operate.

| Items | Contents |
|-------------------------|---|
| CCD ADP | With paper, a single-sided original is fed to the CCD |
| CCD RADP | With paper, a double-sided original is fed to the CCD |
| CCD ADP (Non-P) | Without paper, a single-sided original is fed to the CCD (continuous operation) |
| CCD RADP (Non-P) | Without paper, a double-sided original is fed to the CCD (continuous operation) |

5. Press the [Start] key.
* :The operation starts.
6. To stop the operation, press the [Stop] key.

Completion

Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U207 | Operation key check (Message: Chk Panel Key) |
|-------------|---|

Contents

Check the operation panel keys.

Purpose

Check the operation of all the keys and LEDs on the operation panel.

Method

1. Press the [Start] key to display execution window.
2. [Count 0] appears and the job separator LED is turned on.
3. When pressing the keys on the operation panel from the left upper side and each row in order, the count is counted up by one.
4. If pressing all the keys, all the LEDs are lit.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U211 | Enhancement unit connection setting (Message: Set EH Connection) |
|-------------|---|

Contents

Execute the inner job separator installation setting.

Purpose

Execute when installing the inner job separator.

* :Make sure to set to [Off] to prevent wrong LED lighting when not installed.

Method

1. Press the [Start] key.
 2. Select [Inner Job Separator].
- * :The screen for setting is displayed.

| Items | Contents |
|----------------------|-----------------------------|
| Inner JobSepa | Inner job separator setting |

Method

1. Select the item to set.

| Items | Contents |
|------------|--|
| On | Installing the inner job separator |
| Off | The inner job separator is not installed |

* :Initial setting: Off

2. Press the [Start] key to set the setting value.
3. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

| | |
|-------------|--|
| U221 | USB host lock function setting (Message: Set USB Host Lock) |
|-------------|--|

Contents

Sets ON/OFF of the USB Host lock function. When setting it to on, the device connected to the USB host is not recognized.

Purpose

Change the setting according to the user's request

Method

1.Press the [Start] key.

2.Select [Host Lock].

* :The screen for setting is displayed.

| Items | Contents |
|------------------|---|
| Host Lock | Turns the USB Host lock function on/off |

3.Select the item to set.

| Items | Contents |
|------------|---|
| On | The USB Host lock function is available |
| Off | The USB Host lock function is not available |

* :Initial setting: Off

4.Press the [Start] key to set the setting value.

5.Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U222 | Setting the IC card type (Message: Set IC Card Type) |
|-------------|---|

Contents

Sets the ID card type

Purpose

Change the type of ID card

Setting

1.Press the [Start] key.

2.Select the item to set.

| Items | Contents |
|--------------|--|
| Other | Select when the ID card type is other than SSFC. |
| SSFC | When the ID card type is SSFC, |

* :Initial setting: Other

3.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U223 | Operation panel lock (Message: Lock Panel Ope) |
|-------------|---|

Contents

Execute setting the operation panel function.

Purpose

Execute to prohibit the system menu and job cancel operations from the operation panel by the users other than those with administrator privileges.

Setting

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|-----------------------|--|
| Unlock | Unlock System Menu operation |
| Partial Lock 1 | Lock System Menu operation and Input/Output setting |
| Partial Lock 2 | Lock System Menu operation, Input/Output setting and Job execution setting |
| Partial Lock 3 | Lock System Menu operation, Input/Output setting, Job execution setting and Paper settings |
| Lock | Lock System Menu operation and Job Cancel operation |

* :Initial setting: Unlock

3. Press the [Start] key to set the setting value.

| Operation item | Partial Lock 1 | Lock |
|---|----------------|-------------|
| Entering the maintenance mode | Prohibition | Prohibition |
| Switching to System Menu | Prohibition | Prohibition |
| Send, Send from Document Box | Prohibition | Prohibition |
| Switches the Yellow developer On/Off setting | Prohibition | Prohibition |
| Switch to registration/editing Document Box | Prohibition | Prohibition |
| Pressing the [Stop] key | Permission | Prohibition |
| Pressing the [Status/Job Cancel] key | Permission | Prohibition |
| Disconnect the FAX line | Permission | Prohibition |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U230 | Optional device serial number (Message: Optional Device Serial No) |
|-------------|---|

Contents

Displays the optional device serial number

Purpose

Specify the production lot from the serial number to help the investigation when a problem occurs.

Method

1. Press the [Start] key.

* :Displays the serial number.

| Items | Contents |
|-----------------|--------------------------------------|
| DP | Displays the DP serial number. |
| Finisher | Displays the finisher serial number. |
| PF1 | Displays the PF1 serial number. |
| PF2 | Displays the PF2 serial number. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U240 | Finisher operation check (Message: Chk Fin Ope) |
|-------------|--|

Contents

Turn the finisher's motors and solenoids on.

Purpose

Execute for the finisher's motors and solenoids operation check.

Method

1. Press the [Start] key.
 2. Select the item to operate.
- * :The screen for setting is displayed.

| Items | Contents |
|-----------------|-----------------------------------|
| Motor | Finisher motor operation check |
| Solenoid | Finisher solenoid operation check |
| Mail Box | Mail Box motor operation check |

Method: Motor

1. Select the item to operate.
 2. Press the [Start] key.
- * :The operation starts.

| Items | Contents |
|-------------------------|--|
| Middle(H) | Drive the DF middle motor (DFMM) at high speed. |
| Middle(L) | Drive the DF middle motor (DFMM) at low speed. |
| Eject Pull(H) | Drive the DF exit motor (DFEM) at high speed in the reversing direction. |
| Eject Pull(L) | Drive the DF exit motor (DFEM) at low speed in the reversing direction. |
| Eject Conv(H) | Drive the DF exit motor (DFEM) at high speed in the conveying direction. |
| Eject Conv(L) | Drive the DF exit motor (DFEM) at low speed in the conveying direction. |
| Tray | Drive the DF tray motor (DFTM). Operation pattern: After descending to the lower limit, ascends and descends again when passing 1s after detecting the middle sensor off. Ascends again when detecting the middle sensor on and stops at the upper limit. |
| Staple | Drive the DF staple motor (DFSTM) |
| Staple Move | Drive the DF slide motor (DFSLM) |
| Width Test(A4R) | Drive the DF side registration motor 1,2 (DFSRM1,2) |
| Width Test(LTR) | Drive the DF side registration motor 1,2 (DFSRM1,2) |
| Beat | Drive the DF paddle motor (DFPDM) |
| Eject Unlock(HP) | Drive the DF exit release motor (DFERM) at the home position |
| Eject Unlock(30) | Drive the DF exit release motor (DFERM) at the 30-sheet bundle position |
| Eject Unlock(50) | Drive the DF exit release motor (DFERM) at the 50-sheet bundle position |

| Items | Contents |
|---------------------------|---|
| Eject Unlock(Fix) | Drive the DF exit release motor (DFERM) at the fixed position |
| Eject Unlock(Full) | Drive the DF exit release motor (DFERM) at the full open position |

* :To stop the operation, press the [Stop] key.

Method: Solenoid

- 1.Select the item to operate.
- 2.Press the [Start] key.

* :The operation starts.

| Items | Contents |
|--------------------|-------------------------------|
| Press Paper | Turn the paper press solenoid |

* :To stop the operation, press the [Stop] key.

Method: Mail Box

- 1.Select the item to operate.
- 2.Press the [Start] key.

* :The operation starts.

| Items | Contents |
|---------------|--|
| Conv | Drives the MB drive motor (MBDM) to convey paper |
| Branch | Drives the MB drive motor (MBDM) for feed-shift |

* :To stop the operation, press the [Stop] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U241 | Finisher switch check (Message: Chk Fin Switch) |
|-------------|--|

Contents

Displays the status of finisher's switches and sensors operation.

Purpose

Execute for the finisher's switches and sensors operation check.

Method

- 1.Press the [Start] key.
 - 2.Select the item to operate.
- * :The screen for setting is displayed.

| Items | Contents |
|-----------------|--|
| Finisher | Finisher switch sensor operation check |
| Mail Box | Mail Box switch sensor operation check |

Method: Finisher

- 1.Check the switches and sensors by manually turning them on/off.
- * :The switch indication is inverted when the switch is detected.

| Items | Contents |
|--------------------------|--|
| Tray L-Limit | DF tray sensor 4: DFTS4 |
| HP | DF paper entry sensor (DFPES) |
| Middle Tray Eject | DF middle exit sensor (DFMES) |
| Staple HP | DF slide sensor (DFSLS) |
| Middle Tray | DF main tray exit sensor (DFMTS) |
| Width Front HP | DF side registration sensor 1 (DFSRS1) |
| Width Tail HP | DF side registration sensor 2 (DFSRS2) |
| Bundle Eject HP | DF bundle exit sensor (DFBDS) |
| Match Paddle | DF adjustment sensor (DFADS) |
| Lead Paddle | DF paddle sensor (DFPDS) |
| Press Paper Up | DF press paper sensor 1 |
| Press Paper Down | DF press paper sensor 2 |
| Set | DF installation detection switch |

Method: Mail Box

1. Check the switches and sensors by manually turning them on/off.

* :The switch indication is inverted when the switch is detected.

| Items | Contents |
|--------------------|--------------------------------------|
| Eject | MB eject sensor (MBES) |
| Cover | MB cover open close switch (MBCOCSW) |
| Over Flow1 | MB overflow sensor 1 (MBOFS1) |
| Over Flow2 | MB overflow sensor 2 (MBOFS2) |
| Over Flow3 | MB overflow sensor 3 (MBOFS3) |
| Over Flow4 | MB overflow sensor 4 (MBOFS4) |
| Over Flow5 | MB overflow sensor 5 (MBOFS5) |
| Over FlowTA | MB overflow sensor tray A |
| Motor HP | MB paper entry sensor (MBPES) |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U243 | Checking the DP motor (Message: Check DP Motor) |
|-------------|--|

Contents

Drive the motor or solenoid of the document processor.

Purpose

Check the operation of the motor or solenoid of the document processor.

Method

- 1.Press the [Start] key.
- 2.Select the item to operate.

| Items | Contents |
|------------------------|--|
| Feed Motor(CW) | Drive the DP feed motor (DPFM) |
| Feed Motor(CCW) | Reversely drives the DP feed motor (DPFM) |
| Conv Motor(CW) | Rotate the DP conveying motor (DPCM) |
| Conv Motor(CCW) | Rotate the DP conveying motor (DPCM) reversely |
| Rev Motor | Execute the automatic adjustment in the DP feedshift motor (DPFSM) |

- 3.Press the [Start] key. Each operation starts.
- * :To stop the operation, press the [Stop] key.

Completion

Press the [Stop] key.
* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U244 | DP switch check (Message: Check DP SW) |
|-------------|---|

Contents

Displays each switch and sensor status of the document processor.

Purpose

Execute to check the operation of switches and sensors of the document processor.

Method

- 1.Press the [Start] key.
- 2.Check the switches and sensors by manually turning them on/off.
- * :The switch indication is inversed when the switch is detected.

| Items | Contents |
|-------------------|--|
| Feed | Check the DP feed sensor (DPFS). |
| Regist | Checks the DP registratio sensor (DPRS) |
| Set | Checks the DP original sensor (DPOS) |
| Cover Open | Check the DP interlock switch (DPILSW) |
| Open | Checks the DP open close switch (DPOCSW) |

Completion

Press the [Stop] key.
* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U246 | Finisher adjustment (Message: Adj Fin) |
|-------------|---|

Contents

Execute adjustment for the finisher installation.

Purpose

Front/rear width adjuster home position adjustment

Adjust when the consistency of the side registration guides and paper is not good and paper jam occurs.

Front/rear staple home position adjustment

Adjust if the staple is not centered on the paper in the staple mode.

Method

1.Press the [Start] key.

2.Select [Finisher].

* :The screen for setting is displayed.

| Items | Contents |
|-----------------|---------------------------------------|
| Finisher | Setting the finisher adjustment value |

Method: Finisher

1.Select the item to set.

| Items | Contents |
|-----------------------|---|
| Width Front HP | Front width adjuster home position adjustment |
| Width Tail HP | Rear width adjuster home position adjustment |
| Staple HP | Front/rear staple home position adjustment |

Setting: Width Front HP / Width Tail HP

1.Select [Width Front HP].

2.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Content to adjust | Setting range | Initial setting | Data variation |
|--|----------------------|------------------------|-----------------------|
| Front width adjuster home position adjustment | -30 to 30 | 0 | 0.973mm |
| Rear width adjuster home position adjustment | -30 to 30 | 0 | 0.973mm |

3.Press the [Start] key to set the setting value.

4.Press the [Stop] key to return to the screen to select the maintenance item No.

5.Enter U240 and select [Motor] and then [Width Test(A4R)].

* :The middle tray side registration guides move to A4R size position.

6.Insert paper into the side registration guides to check the consistence.


7.Repeat the above adjustment until the consistency is appropriate.

Setting: Staple HP

1. Select [Staple HP].
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Content to adjust | Setting range | Initial setting | Data variation |
|--|---------------|-----------------|----------------|
| Front/rear staple home position adjustment | -15 to 15 | 0 | 0.0972mm |

- * :Increase the set value if the staple position is shifted to the machine front side (sample1).
Lower the set value if the staple position is shifted to the machine rear side (sample2).



3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U247 | Paper feed operation check (Message: Chk Paper Feeder) |
|-------------|---|

Contents

Turn the motor and clutch power on for each feed unit.

Purpose

Execute to check motor and clutch operation of each feed unit.

Method

1. Press the [Start] key.
 2. Select the item to operate.
- * :The screen for setting is displayed.

| Items | Contents |
|------------|----------------------------------|
| PF | Operates 1-tray paper feeder |
| 2PF | Operates 2-tray paper feeder |
| LCF | Operate the high capacity feeder |

Setting: PF

1. Select the item to set.

| Display | | Contents |
|---------------|----------------|---------------------------------|
| Mode | Off | PF paper feed motor (PFPFM) OFF |
| | On | PF paper feed motor (PFPFM) ON |
| Device | Feed2 Clutch | PF paper feed clutch (PFFCL) ON |
| | V Feed2 Clutch | PF conveying clutch (PFCCL) ON |

2. Select [Execute].
 3. Press the [Start] key. Starts the motor operation.
- * :To stop the operation of the motor, press the [Stop] key.

Setting: 2PF

1. Select the item to set.

| Display | | Contents |
|---------------|----------------|------------------------------------|
| Mode | Off | PF paper feed motor (PFPFM) OFF |
| | On | PF paper feed motor (PFPFM) ON |
| Device | Feed3 Clutch | PF paper feed clutch 1 (PFFCL1) ON |
| | Feed4 Clutch | PF paper feed clutch 2 (PFFCL2) ON |
| | V Feed3 Clutch | PF conveying clutch 1 (PFCCL1) ON |
| | V Feed4 Clutch | PF conveying clutch 2 (PFCCL2) ON |

2. Select [Execute].
 3. Press the [Start] key. Starts the motor operation.
- * :To stop the operation of the motor, press the [Stop] key.

Setting: LCF

1. Select the item to set.

| Display | | Contents |
|---------------|----------------|---------------------------------|
| Mode | Off | PF paper feed motor (PFPFM) OFF |
| | On | PF paper feed motor (PFPFM) ON |
| Device | Feed3 Clutch | PF paper feed clutch (PFFCL) ON |
| | V Feed3 Clutch | PF conveying clutch (PFCCL) ON |

2. Select [Execute].

3. Press the [Start] key. Starts the motor operation.

* :To stop the operation of the motor, press the [Stop] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U250 | Checking/clearing the maintenance cycle (Message: Mnt Cnt Pre-set) |
|-------------|---|

Contents

Changes the pre-set values for the maintenance cycle and automatic grayscale adjustment.

Purpose

Change the timing to display the message for maintenance and automatic grayscale adjustment

Setting

1. Press the [Start] key.

2. Select the item to set.

3. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|---------------------|---|---------------|-----------------|
| M.Cnt A | Changes the maintenance counter (Kit A) | 0 to 9999999 | 200000 |
| M.Cnt B | Change the maintenance counter preset value (Kit B) | 0 to 9999999 | 200000 |
| M.Cnt HT | Change the maintenance counter preset value (HT adjustment) | 0 to 9999999 | 0 |
| Cassette1 | Change the maintenance counter preset value (Cassette 1) | 0 to 9999999 | 300000 |
| Cassette2 *1 | Change the maintenance counter preset value (Cassette 2) | 0 to 9999999 | 300000 |
| Cassette3 *2 | Change the maintenance counter preset value (Cassette 3) | 0 to 9999999 | 300000 |
| Cassette4 *3 | Change the maintenance counter preset value (Cassette 4) | 0 to 9999999 | 300000 |

*1: 500 PF only, *2: 500×2/2000 PF only, *3: 500×2 PF only

4. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U251 | Checking/clearing the maintenance counter (Message: Clr Mnt Cnt) |
|-------------|---|

Contents

Displays, clears or changes the maintenance count.

Purpose

Execute to check the maintenance count

Also, clear the count at the maintenance.

Setting

1.Press the [Start] key.

2.Select the item to set.

3.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range |
|---------------------|--|----------------------|
| M.Cnt A | Maintenance cycle counter (Kit A) | 0 to 9999999 |
| M.Cnt B | Maintenance cycle counter (Kit B) | 0 to 9999999 |
| M.Cnt HT | Maintenance cycle counter (HT adjustment) | 0 to 9999999 |
| Cassette1 | Maintenance cycle counter value (cassette 1) | 0 to 9999999 |
| Cassette2 *1 | Maintenance cycle counter value (cassette 2) | 0 to 9999999 |
| Cassette3 *2 | Maintenance cycle counter value (cassette 3) | 0 to 9999999 |
| Cassette4 *3 | Maintenance cycle counter value (cassette 4) | 0 to 9999999 |
| Clear | Clears all the maintenance counts | 0 |

*1: 500 PF only, *2: 500×2/2000 PF only, *3: 500×2 PF only

Clearing

1.Select [Clear].

2.Press the [Start] key to clear the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U252 | Destination (Message: Set Dest) |
|-------------|--|

Contents

Switch the operations and screens of the main unit according to the destination.

Purpose

Execute after initializing the backup RAM, in order to return the setting to the value before replacement or initialization

Method

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|------------------------------------|---------------|
| Europe Metric ^{*2} | Europe Metric |
| Inch ^{*2} | Inch |
| Asia Pacific ^{*2} | Asia Pacific |
| Japan Metric ^{*1} | Japan metric |
| Australia ^{*2} | Australia |
| China ^{*2} | China |
| Korea ^{*2} | Korea |

*1: 100 V model only, *2: Except 100 V model

* :Initial setting: Destination

3. Press the [Start] key.

* :Initializes according to the destination

4. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

| | |
|-------------|--|
| U253 | Switching the double/single counts (Message: Set D/S Count) |
|-------------|--|

Contents

Switches the count timing for the total counter and other counters by color mode.

Purpose

Select, according to user's request (copy service provider), if the maximum size paper is to be counted as one sheet (single count) or two sheets (double count)

Setting

1. Press the [Start] key.
2. Select [Color] or [B/W].

| Items | Contents |
|----------------------|--|
| Full Color | Switch the counter for full color mode (Single/Double Count) |
| Mono Color *1 | Switch the counter for mono color mode (Single/Double Count) |
| B/W | Switch the counter for B/W mode (Single/Double Count) |

*1: Appears if U276 set to other than [Mode0]

3. Select [SGL(All)] or [DBL(Folio)].

| Items | Contents |
|-------------------|--|
| SGL(All) | Sets single count for all the paper sizes |
| DBL(Legal) | Set single count for Legal size or smaller |
| DBL(Folio) | Set double count for Folio size or larger *2 |

* :Initial setting: SGL(All)

*2: The Folio length can be set to between 318 and 356 mm using maintenance mode U035. However, the double count will be applied when the set value is 330 mm (Initial value) or longer.

4. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U260 | Switching the timing for copy counting (Message: Set Count Mode) |
|-------------|---|

Contents

Switches the count timing for the total counter and other counters between paper feed and eject.

Purpose

Change the count timing according to the user's request

Setting

1. Press the [Start] key.
2. Selects the copy count timing.

| Items | Contents |
|--------------|-----------------------------------|
| Feed | When secondary paper feed starts. |
| Eject | Selects the paper eject timing |

* :Initial setting: Eject

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U265 | Setting by destination (Message: Set Model Dest) |
|-------------|---|

Contents

Sets the OEM code.

Purpose

Execute when replacing the main PWB, etc.

Setting

1. Press the [Start] key.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents |
|--------------|-----------------------|
| No. | Displays the OEM code |

3. Press the [Start] key to set the setting value.

4. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U276 | Switching the copy count mode (Message: Set Chg Count) |
|-------------|---|

Contents

Set the single color count mode

Purpose

Execute to change the billing counter to count up in the single color mode.

Setting

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|--------------|--|
| Mode0 | Count the single color count in the full color counter |
| Mode1 | Count the single color count in the single color counter |

* :Initial setting: Mode1

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U278 | Delivery date setting (Message: Set Delivery Date) |
|-------------|---|

Contents

Registers the date of delivery of the machine.

Purpose

Execute when installing the machine. Execute to check the delivery date of the machine.

Method

1. Press the [Start] key.
 2. Select [Today].
 3. Press the [Start] key.
- * :Sets the delivery date of the machine.

Clearing

1. Select [Clear].
 2. Press the [Start] key.
- * :Clears the delivery date of the machine.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U284 | Setting the 2-color copy (Message: Set 2 Color Copy) |
|-------------|---|

Contents

Sets whether to use the 2-color copy.

Purpose

Change the setting according to the user's request

Setting

- 1.Press the [Start] key.
- 2.Select the item to set.

| Items | Contents |
|-------------------|--|
| B/W | 2-color copy enabled, B/W count |
| Mono Color | 2-color copy enabled, mono color count |
| Off | 2-color copy disabled |

* :Initial setting: Mono Color

* :When setting it to on, 2-color copy appears on the color function screen.

- 3.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U285 | Set Service Status Page (Message: Set Svc Sts Page) |
|-------------|--|

Contents

Determines whether to display the digital dot coverage report on the report print.

Purpose

Change the setting according to the user's request

Setting

- 1.Press the [Start] key.
- 2.Select the item to set.

| Items | Contents |
|------------|--|
| On | Displays the digital dot coverage. |
| Off | Not to display the digital dot coverage. |

* :Initial setting: On

- 3.Press the [Start] key. Set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U290 | Setting the drive to save the HyPAS application (Message: Set Drive App) |
|-------------|---|

Contents

Sets the drive to save the HyPAS application

* :Indicated when the HyPAS application is not installed in the SD card and SSD.

Purpose

Sets to save to the SD card or optional SSD.

Setting

- 1.Press the [Start] key.
- 2.Select the item to set.

| Items | Contents |
|----------------|--------------------|
| SD Card | Set in the SD card |
| SSD | Set in the SSD |

* :Initial setting: SD card (0)

- 3.Press the [Start] key. Set the setting value.

- 4.Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U323 | Abnormal temperature and humidity notification setting (Message: Warning Heat Hum) |
|-------------|---|

Contents

Sets whether to indicate the notification when detecting abnormal temperature and humidity.

Purpose

Change the setting according to the user's request

Setting

- 1.Press the [Start] key.
- 2.Select the item to set.

| Items | Contents |
|------------|--|
| On | Indicate the abnormal temperature and humidity notification |
| Off | Do not indicate the abnormal temperature and humidity notification |

* :Initial setting: On

- 3.Press the [Start] key. Set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U325 | Paper interval setting (Message: Set Paper Int) |
|-------------|--|

Contents

Sets the print interval at high coverage.

Purpose

Changes the print interval at high coverage.

Setting

1. Press the [Start] key.
2. Select the item to set.
3. By using the [◀] [▶] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|------------------|---|---------------|-----------------|
| Interval | Sets On/Off of print interval at high coverage. | On/Off | Off |
| Average | Set the average number of sheets (parameter) | 1 to 255 | 100 |
| Threshold | Sets the coverage threshold to start lowering. | - | - |
| Rate | Displays the down rate | - | - |

4. Press the [Start] key to set the setting value.

Setting: Threshold

1. Select the item to set.
2. By using the [◀] [▶] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|----------|--|---------------|-----------------|
| C | Coverage threshold to start lowering for Cyan | 1 to 100 | 15 |
| M | Coverage threshold to start lowering for Magenta | 1 to 100 | 15 |
| Y | Coverage threshold to start lowering for Yellow | 1 to 100 | 15 |
| K | Coverage threshold to start lowering for Black | 1 to 100 | 20 |

3. Press the [Start] key to set the setting value.

Method: Rate

* :Display each setting values.

| Items | Contents | Setting range | Initial setting |
|----------|-------------------|---------------|-----------------|
| C | Cyan down rate | 50 to 100 | 100 |
| M | Magenta down rate | 50 to 100 | 100 |
| Y | Yellow down rate | 50 to 100 | 100 |
| K | Black down rate | 50 to 100 | 100 |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U326 | Black line cleaning indication (Message: Set Clean Bk Line) |
|-------------|--|

Contents

Sets whether to indicate the black lines cleaning guidance when detecting black lines.

Purpose

Displays the cleaning guidance to reduce the service call with the black lines by dust on the contact glass when scanning from the document processor.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|------------------------|--|
| Black Line Mode | Sets On/Off of the black line cleaning guidance indication |

3. Select the item to set.

| Items | Contents |
|--------------|---|
| On | Indicate the black lines cleaning guidance |
| Off | Black line cleaning guidance is not indicated |

* :Initial setting: On

4. Press the [Start] key. Set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U327 | Cassette heater On/Off setting (Message: Set Cass Heater) |
|-------------|--|

Contents

Selects the cassette heater control setting.

Purpose

Selects the cassette heater control setting
Sets the cassette heater for the optional cassette.

Method

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|--------------|---|
| On | Sets the cassette heater control On (installed). |
| Off | Sets the cassette heater control Off (not installed). |

* :Initial setting: Off

* :Drum refresh is not executed at power-up when the cassette heater control is [On].

3. Press the [Start] key. Set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U332 | Adjusting the black coverage coefficient (Message: Adj Calc Rate) |
|-------------|--|

Contents

Sets the coefficient of custom size with A4/Letter size. The coefficient set here is used to convert the black ratio in relation to the A4/Letter size and to display the result in the service status page.

Purpose

Set the coefficient for converting the black ratio for custom sizes in relation to the A4/Letter size

Setting

1. Press the [Start] key.
2. Select the item to set.
3. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|---------------|--|---------------------------------|--------------------------|
| Rate | Set the coefficient for converting the black ratio for custom sizes in relation to the A4/Letter size. | 0.1 to 3.0 | 1.0 |
| Mode | Switch full-color count and color coverage count display | 0: Full color 1: by coverage | 0 |
| Level1 | Sets low coverage threshold value | 0.1 to 99.8 | 10 (Indicated as 1.0) |
| Level2 | Sets middle coverage threshold value | 0.2 to 99.9 | 25 (Indicated as 2.5) |

4. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U341 | Printer cassette setting (Message: Set Prn Cass) |
|-------------|---|

Contents

Sets the cassette to printer output only.

Purpose

Execute it when securing a cassette for printer. The cassette set to on is for printer only and it cannot be used for copy.

Setting

1. Press the [Start] key.
 2. Select the item to set.
- * : Multiple cassettes are selectable.

| Items | Contents |
|----------------|---|
| Cass1 | Setting cassette 1 to the printer paper source |
| Cass *1 | Setting cassette 2 to the printer paper source (paper feeder) |
| Cass *2 | Setting cassette 3 to the printer paper source (paper feeder) |
| Cass *3 | Setting cassette 4 to the printer paper source (paper feeder) |

*1: 500 PF only, *2: 500×2/2000 PF only, *3: 500×2 PF only

* : Initial setting: Off (Cassette1?4)?

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U343 | Duplex priority mode (Message: Set Dup PriMode) |
|-------------|--|

Contents

Switches between duplex or simplex copy for the initial copy mode.

Purpose

Set the frequently used settings depending on the user's usage.

Setting

1. Press the [Start] key.
- * : Select the item to set.

| Items | Contents |
|------------|------------------|
| On | Duplex copy |
| Off | Single-side copy |

* : Initial setting: Off

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U345 | Setting the value for maintenance due indication (Message: Set Mnt Time Disp) |
|-------------|--|

Contents

Sets when to display a message notifying that the time for maintenance is about to reach, by setting the number of prints that can be made before the current maintenance cycle reaches. Displays the maintenance precaution message when the page count reaches the set value before the maintenance count.

Purpose

Change the time for maintenance precaution display.

Setting

1. Press the [Start] key.
2. Select the item to set.
3. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|--------------|---|----------------------|------------------------|
| Cnt | Setting the maintenance time precaution display (Remaining number of prints that can be made before the current maintenance cycle reaches) | 0 to 9999 | 0 |

4. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U346 | Selecting Sleep Mode (Message: Slct Sleep Mode) |
|-------------|--|

Contents

Changes the sleep mode settings.

Purpose

Changes the sleep mode settings.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|--------------------------|-------------------------------------|
| Timer/Sleep Level | BAM conformity country setting |
| Auto sleep | Switches AutoSleep function setting |

Setting: Timer/Sleep Level

1. Select the item to set.

| Items | Contents |
|-------------------------|--|
| More Energy Save | BAM conformity setting On Sleep mode is disabled (Quick Recovery setting is disabled) |
| Less Energy Save | BAM conformity setting Off Sets Sleep Level (Quick Recovery or Energy Saver) |

- * :Initial setting: More Energy Save
2. Press the [Start] key. Set the setting value.
 3. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Setting: Auto sleep

1. Select the item to set.

| Items | Contents |
|------------|--|
| On | The sleep mode is disabled from the system menu. |
| Off | The sleep mode is enabled from the system menu. |

- * :Initial setting: On
2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U402 | Adjusting the printing margins (Message: Print Margin) |
|-------------|---|

Contents

Adjusts the scan image margins.

Purpose

Make the adjustment if margins are incorrect

* :If the leading edge margin is less than the specified value, it may cause jam at the fuser.

* :If there is no bottom margin, when continuously printing, it may cause an image smudge on the second page.

Adjustment

- 1.Press the [Start] key.
- 2.Press the [System Menu/Counter] key.
- 3.Press the [Start] key to output a test pattern.
- 4.Press the [System Menu/Counter] key.
- 5.Select the item to set.

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------|---|---------------|-----------------|----------------|
| Lead | Adjusts the printer leading edge margin | 0.0 to 10.0 | 4.0 | 0.1 mm |
| A Margin | Printer left margin | 0.0 to 10.0 | 3.0 | 0.1 mm |
| C Margin | Printer right margin | 0.0 to 10.0 | 3.0 | 0.1 mm |
| Trail | Printer trailing edge margin | 0.0 to 10.0 | 3.9 | 0.1 mm |

- 6.Press the [◀] [▶] keys or the numeric keys to change the counter value.

* :When the setting value is increased, the margin widens, and it narrows when the setting value is decreased.




Figure 6-15

- 7.Press the [Start] key to set the setting value.

Precautions

Appropriate margins are not obtained after this adjustment, execute the following maintenance mode.

U034 (P.6-228) > U402

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U403 | Adjusting margins for scanning an original on the contact glass (Message: Scan Margin Tbl) |
|-------------|--|

Contents

Adjusts the margins for the table scanning.

Purpose

Make the adjustment if margins are incorrect

Adjustment

1. Press the [Start] key.
2. Press the [System Menu/Counter] key.
3. Place an original and press the [Start] key to make a test copy.
4. Press the [System Menu/Counter] key.
5. Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------|--|---------------|-----------------|----------------|
| A Margin | Adjusts the scanner left margin | 0.0 to 10.0 | 2.0 | 0.5mm |
| B Margin | Adjusts the scanner leading edge margin. | 0.0 to 10.0 | 2.0 | 0.5mm |
| C Margin | Adjusts the scanner right margin | 0.0 to 10.0 | 2.0 | 0.5mm |
| D Margin | Adjusts the scanner trailing edge margin | 0.0 to 10.0 | 2.0 | 0.5mm |

6. Press the [◀] [▶] keys or the numeric keys to change the counter value.

* :When the setting value is increased, the margin widens, and it narrows when the setting value is decreased.




Figure 6-16

7. Press the [Start] key to set the setting value.

Precautions

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034(P.6-228) > U402(P.6-334) > U403

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U404 | Adjusting margins for scanning an original from the document processor (Message: Scan Margin DP) |
|-------------|---|

Contents

Adjusts the margins for DP scanning.

Purpose

Make the adjustment if margins are incorrect

Adjustment

1. Press the [Start] key.
2. Press the [System Menu/Counter] key.
3. Place an original on the DP and press the [Start] key to make a test copy.
4. Press the [System Menu/Counter] key.
5. Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------|-------------------------------------|---------------|-----------------|----------------|
| A Margin | Adjusts the DP left margin | 0.0 to 10.0 | 3.0 | 0.5mm |
| B Margin | Adjusts the DP leading edge margin | 0.0 to 10.0 | 2.5 | 0.5mm |
| C Margin | Sets the DP right margin | 0.0 to 10.0 | 3.0 | 0.5mm |
| D Margin | Adjusts the DP trailing edge margin | 0.0 to 10.0 | 4.0 | 0.5mm |

6. Press the [◀] [▶] keys or the numeric keys to change the counter value.

* :When the setting value is increased, the margin widens, and it narrows when the setting value is decreased.




Figure 6-17

7. Press the [Start] key to set the setting value.

Precautions

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034 (P.6-228) > U402 (P.6-334) > U403 (P.6-335) > U404

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U407 | Adjusting the writing timing (Duplex/Reversal) (Message: WR DR Timing) |
|-------------|---|

Contents

Adjusts the writing timing when duplex printing.

Purpose

Adjusted when the back page image of duplex copying is printed in rotated 180 degrees from the scanner reading image (image on the memory)

Precautions

Adjust this after finishing the following maintenance modes.

U034(P.6-228) > U402(P.6-334) > U66(P.6-240)>

U403 (P.6-335) > U71 (P.6-244) > U404 (P.6-336) > U407

Adjustment

- 1.Press the [Start] key.
- 2.Press the [System Menu/Counter] key.
- 3.Place an original on the DP and press the [Start] key to make a test copy.
- 4.Press the [System Menu/Counter] key.
- 5.Select [Adj Data].

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------|--|---------------|-----------------|----------------|
| Adj Data | Adjusts the leading edge timing when writing the image in the memory | -47 to 47 | 0 | 1dot |

- 6.Press the [◀] [▶] keys or the numeric keys to change the counter value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the image moves forward, and it moves backward when the setting value is decreased.

Leading edge registration of the copy image (+1.0/-1.5 mm or less)




Figure 6-18

- 7.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U410 | Adjusting the halftone automatically (Message: Adj Half Tone) |
|-------------|---|

Contents

Acquires the data for the automatic halftone adjustment and ID correction.

Purpose

Execute when the quality of reproduced halftones has dropped

Adjustment

1. Press the [Start] key.
 - * :Displays the execution information screen.
 - * :Test pattern 1 and Test pattern 2 are output on the A4 paper.
2. Set the test pattern output on the original glass with the arrow facing the rear side and print side face-down.
 - * :Load about 20 sheets of the blank paper on Test Pattern 1.




Figure 6-19

3. Press the [Start] key.
 - * :The first auto adjustment is executed.
4. Set the output Test Pattern 2 as the original.
 - * :Load about 20 sheets of the blank paper on Test Pattern 2.
5. Press the [Start] key.
 - * :The second auto adjustment is executed.
6. [Finish] appears after normal completion.
 - * :An error code appears when an error occurs.

Error codes

| Codes | Occurrence position | Contents |
|-------------|---------------------|--|
| S001 | Scanner | Original reference patch is not detected |
| S002 | | Original deviation is in excess in the main scanning direction |
| S003 | | Original deviation is in excess in the sub-scanning direction |
| S004 | | Original skew is in excess |
| S005 | | Original type error |
| SFFF | | Other scanner error |
| E001 | Engine | Engine status error |
| E002 | | Adjustment result error |
| EFFF | | Other engine error |

| Codes | Occurrence position | Contents |
|--------------|----------------------------|--|
| C001 | Controller | Pause status |
| C002 | | Adjustment result error |
| C110 | | Adjustment value (increase amount) value error (black) |
| C120 | | Adjustment value (increase amount) value error (cyan) |
| C140 | | Adjustment value (increase amount) value error (magenta) |
| C180 | | Adjustment value (increase amount) value error (yellow) |
| C210 | | Adjustment value (increase rate) error (black) |
| C220 | | Adjustment value (increase rate) value error (cyan) |
| C240 | | Adjustment value (increase rate) value error (magenta) |
| C280 | | Adjustment value (increase rate) value error (yellow) |
| CFFF | | Other controller error |

| | |
|-------------|--|
| U411 | Scanner auto adjustment (Message: Auto Adj Scn) |
|-------------|--|

Contents



Uses the specified originals and automatically adjusts the following items in the scanner and the DP scanning sections.

Scanner section: Original size magnification, leading edge timing, center line, chromatic aberration in main/sub scanning direction, MTF correction, color/monochrome input gamma, color correction matrix automatic adjustment


DP scanning section: Original size magnification, leading edge timing and center line MTF correction, Input gamma, automatic adjustment of color correction matrix

Purpose

Automatically adjusts the scanner and the DP scanning sections.

| Items | Contents | Original for adjustment (P/N) |
|--|---|---|
| Table (Chart A) | Automatically adjusts the table scanning. Magnification in the sub-scanning direction Leading edge timing Center line Chromatic aberration in the main scanning direction Input gamma in monochrome mode Input gamma in color mode Color correction matrix | 7505000107  |
| DP FU(ChartB) DP FD(ChartB) | Execute the 1st side automatic adjustment in the DP scanning section. Execute the 2nd side automatic adjustment in the DP scanning section. Magnification in the sub-scanning direction Leading edge timing Center line Trailing edge timing | 7505000106  |
| DP FU(ChartA) | Execute the 1st side automatic adjustment in the DP scanning section. Input gamma in monochrome mode Input gamma in color mode Color correction matrix | 7505000107 |
| All | Automatically adjusts the DP scanning after the automatic adjustment of the table scanning. Automatic adjustment in the scanning section. | 7505000107 7505000106 |
| Target | Set-up for obtaining the target value | 7505000107 |

*: Cut the trailing edge of the DP adjustment original (ChartB) as shown below.



Method: Table (Chart A)

Automatic input of the target value

* :Usually, it adjusts here.

- 1.Set the specified original (P/N: 7505000107) on the table.
- 2.Enter maintenance item U411.
- 3.Select [Target].
- 4.Press the [◀] [▶] keys, [#] or [*] key to select [Auto].
- 5.Select [Table(ChartA)] using the [Up/Down cursor] key.
- 6.Press the [Start] key to read the barcode of the original chart and to start the automatic adjustment.
- 7.When automatic adjustment has normally completed, [OK] is displayed.

* :When the error code "1e" or "1f" is displayed during the automatic adjustment in the table scanning and the barcode is not read, adjust the following after manually inputting the target value.

Manual input of the target value

- 1.Enter the target values which are shown on the lower part of the front page of the adjustment original (P/N: 7505000107) by executing the maintenance mode U425.
- 2.Set the specified original (P/N: 7505000107) on the table.
- 3.Enter maintenance item U411.
- 4.Select [Target].
- 5.Press the [◀] [▶] keys, [#] or [*] key to select [U425].
- 6.Select [Table(ChartA)] using the [Up/Down cursor] key.
- 7.Press the [Start] key to start Auto adjustment.
- 8.When automatic adjustment has normally completed, [OK] is displayed.

If the image position is shifted largely at the DP adjustment below, an error might occur when adjusting it with ChartA. First, use ChartB (image position) to adjust it and then use ChartA (color).

Method: DP FU (Chart B)

* :Adjusting the first side of the DP duplex scanning

- 1.Set the specified original (P/N: 7505000106) face-up on the DP.
- 2.Enter maintenance item U411.
- 3.Select [DP FU(ChartB)].
- 4.Press the [Start] key to start Auto adjustment.
- 5.When automatic adjustment has normally completed, [OK] is displayed.

Method: DP FD (Chart B)

* :Adjusting the second side of the DP duplex scanning

- 1.Set the specified original (P/N: 7505000106) face-up on the DP.
- 2.Enter maintenance item U411.
- 3.Select [DP FD(ChartB)].
- 4.Press the [Start] key to start Auto adjustment.
- 5.When automatic adjustment has normally completed, [OK] is displayed.

Method: DP FU (Chart A)**Automatic input of the target value**

1. Set the specified original (P/N: 7505000107) face-up on the DP.
2. Enter maintenance item U411.
3. Select [Target].
4. Press the [◀] [▶] keys, [#] or [*] key to select [Auto].
5. Select [DP FU(ChartA)] using the [Up/Down cursor] key.
6. Press the [Start] key to read the barcode of the original chart and to start the automatic adjustment.
7. When automatic adjustment has normally completed, [OK] is displayed.

* :When the error code "1e" or "1f" is displayed during the automatic adjustment in the DP scanning and the barcode is not read, adjust the following after manually inputting the target value.

Manual input of the target value

1. Enter the target values which are shown on the lower part of the front page of the adjustment original (P/N: 7505000107) by executing the maintenance mode U425.
2. Set the specified original (P/N: 7505000107) face-up on the DP.
3. Enter maintenance item U411.
4. Select [Target].
5. Press the [◀] [▶] keys, [#] or [*] key to select [U425].
6. Select [DP FU(ChartA)] using the [Up/Down cursor] key.
7. Press the [Start] key to start Auto adjustment.
8. When automatic adjustment has normally completed, [OK] is displayed.

* :If an error occurs during auto adjustment, error code "NGXX" is displayed and operation stops. In this case, check the error and execute the automatic adjustment again.

Error codes

| Codes | Contents | Corrective action |
|--------------|---|---|
| 00 | Automatic adjustment success | - |
| 01 | Black band detection error (Table scanning leading edge skew in the sub-scanning direction) | 1. Set the original correctly and execute the adjustment again. 2. Check lighting of the lamp or replace it. |
| 04 | Black band is not detected (Table leading edge in the sub-scanning direction) | |
| 05 | Black band is not detected (Table far end in the main scanning direction) | |
| 06 | Black band is not detected (Table near end in the main scanning direction) | |
| 07 | Black band is not detected (Table trailing edge in the sub-scanning direction) | |

| Codes | Contents | Corrective action |
|-----------|---|--|
| 08 | Black band is not detected (DP far end in the main scanning direction) | <ol style="list-style-type: none"> 1. Check the attachment position of DP. 2. Check lighting of the lamp or replace it. 3. Check the back and front of the adjustment original. |
| 09 | Black band is not detected (DP near end in the main scanning direction) | |
| 0a | Black band is not detected (DP leading edge in the sub-scanning direction) | |
| 0b | Black band is not detected (Original check of DP leading edge in the sub-scanning direction) | |
| 0c | Black band is not detected (DP trailing edge in the sub-scanning direction) | |
| 0d | White band is not detected (DP trailing edge in the sub-scanning direction) | |
| 0e | DMA time out | Turn the power switch off then on, and execute again. |
| 0f | Magnification error in the sub-scanning direction | <ol style="list-style-type: none"> 1. Turn the power switch off then on, and execute again. 2. Adjust manually. (U065 to U067, U070 to U072) |
| 10 | Leading edge error in the sub-scanning direction | |
| 11 | Trailing edge error in the sub-scanning direction | |
| 12 | DP skew error in the sub-scanning direction | |
| 13 | Maintenance request error | Turn the power switch off then on, and execute again. |
| 14 | Center line error in the main scanning direction | <ol style="list-style-type: none"> 1. Turn the power off and on, and execute again. 2. Adjust manually. (U065 to U067, U070 to U072) |
| 15 | DP skew error in the main scanning direction | |
| 16 | Magnification error in the main scanning direction | |
| 17 | Service call error | Turn the power off and on, and execute again. |
| 18 | DP paper jam error | Set the original correctly and execute again. |
| 19 | PWB replacement error | - |
| 1a | Original error | <ol style="list-style-type: none"> 1. Clean the contact glass and slit glass. 2. Exchange the adjustment original. |
| 1b | Input gamma adjustment original error | Set the original correctly and execute again. |
| 1c | Matrix adjustment original error | |
| 1d | Original for the white reference correction coefficient error | |

| Codes | Contents | Corrective action |
|----------------|---|--|
| 1e | Lab value detection error | Check the following and execute again. Is the bar code dirty? Is the original position correct? Is the bar code position correct? |
| 1f | Lab value comparison error | Check the following and execute again. Is the acquired bar code the same? Is the original position correct? Is the bar code position correct? |
| 20 21 30 | Input gamma correction coefficient error Color correction matrix coefficient error Chromatic aberration adjustment original error | Set the original correctly and execute again. |
| 63 | Completed to obtain the test RAW | - |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U425 | Set Target (Message: Set Target) |
|-------------|---|

Contents

Enter the lab values which are shown on the back page of the adjustment original (P/N: 302NM9434_).

Purpose

Enter data in order to correct for differences in originals during the automatic adjustment

Method

- 1.Press the [Start] key.
- 2.Select the item to set.

| Items | Contents |
|---------------|--|
| ChartA | Setting the adjustment value of the table scanning |
| ChartB | Sets the adjustment value of the DP scanning |

Method: ChartA

- 1.Press the [Start] key.
- 2.Select the item to set.

| Items | Contents |
|------------------------|---|
| White | Setting the white patch for the adjustment original |
| Black | Setting the black patch for the adjustment original |
| Gray1 | Setting the Gray1 patch for the adjustment original |
| Gray2 | Setting the Gray2 patch for the adjustment original |
| Gray3 | Setting the Gray3 patch for the adjustment original |
| C | Setting the cyan patch for the adjustment original |
| M | Setting the magenta patch for the adjustment original |
| Y | Setting the yellow patch for the adjustment original |
| R | Setting the red patch for the adjustment original |
| G | Setting the green patch for the adjustment original |
| B | Setting the blue patch for the adjustment original |
| Adjust Original | Setting the main scanning and sub-scanning directions |

Setting: White

- 1.Select the item to set.
- 2.By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 93.6 | - |
| a | A value setting | -200.0 to 200.0 | 0.9 | - |
| b | B value setting | -200.0 to 200.0 | -0.4 | - |

- 3.Press the [Start] key to set the setting value.

Setting: Black

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 10.6 | - |
| a | A value setting | -200.0 to 200.0 | -0.2 | - |
| b | B value setting | -200.0 to 200.0 | -0.7 | - |

3. Press the [Start] key to set the setting value.

Setting: Gray1

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 76.2 | - |
| a | A value setting | -200.0 to 200.0 | -0.2 | - |
| b | B value setting | -200.0 to 200.0 | 1.2 | - |

3. Press the [Start] key to set the setting value.

Setting: Gray2

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 25.2 | - |
| a | A value setting | -200.0 to 200.0 | -0.2 | - |
| b | B value setting | -200.0 to 200.0 | -0.2 | - |

3. Press the [Start] key to set the setting value.

Setting: Gray3

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 51.3 | - |
| a | A value setting | -200.0 to 200.0 | -0.3 | - |
| b | B value setting | -200.0 to 200.0 | 0.3 | - |

3. Press the [Start] key to set the setting value.

Setting: C

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 72.6 | - |
| a | A value setting | -200.0 to 200.0 | -32.8 | - |
| b | B value setting | -200.0 to 200.0 | -11.5 | - |

3. Press the [Start] key to set the setting value.

Setting: M

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 48.1 | - |
| a | A value setting | -200.0 to 200.0 | 69.9 | - |
| b | B value setting | -200.0 to 200.0 | -6.1 | - |

3. Press the [Start] key to set the setting value.

Setting: Y

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 86.2 | - |
| a | A value setting | -200.0 to 200.0 | -18.6 | - |
| b | B value setting | -200.0 to 200.0 | 81.7 | - |

3. Press the [Start] key to set the setting value.

Setting: R

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 46.7 | - |
| a | A value setting | -200.0 to 200.0 | 54.2 | - |
| b | B value setting | -200.0 to 200.0 | 38.6 | - |

3. Press the [Start] key to set the setting value.

Setting: G

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 67.8 | - |
| a | A value setting | -200.0 to 200.0 | -51.3 | - |
| b | B value setting | -200.0 to 200.0 | 48.9 | - |

3. Press the [Start] key to set the setting value.

Setting: B

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 38.8 | - |
| a | A value setting | -200.0 to 200.0 | 25.3 | - |
| b | B value setting | -200.0 to 200.0 | -22.8 | - |

3. Press the [Start] key to set the setting value.

Setting: Adjust Original

* : This setting is usually unnecessary.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------------|--|----------------|-----------------|----------------|
| Lead | Set the adjustment value of the leading edge. | 4.0 to 6.0 | 5.0 | 0.1mm |
| Main Scan | Sets the adjustment value of the left edge. | 9.0 to 11.0 | 10.0 | 0.1mm |
| Sub Scan | Set the adjustment value of the trailing edge. | 265.0 to 267.0 | 266.0 | 0.1mm |

1. Measure the distances A, B and C from the upper edge of black belt 1 to the lower edge of black belt 3 of the adjustment original.
Measurement procedure
1) Measure the distance "A", "B" and "C" between two points as follows. (A: 30mm from the left edge, B: 105mm from the left edge, C: 180mm from the left edge)
? Measure the distance from the leading edge to the top edge of black belt 1.
2) Apply the following formula for the values obtained: $((A+B+C)/3)$
2. Enter the value solved in "Lead" using the [◀] [▶] keys.
3. Press the [Start] key to set the setting value.
4. Measure the distance "F" from the left edge to the right edge of black belt 2 on the adjustment original.
Measurement procedure
Measure the distance "F" from the left edge at 21mm from the top edge of black belt 1 to the right edge of black belt 2.
5. Enter the values measured in "Main Scan" using the [◀] [▶] keys.

6. Press the [Start] key to set the setting value.
7. Measure the distance "D" and "E" from the top edge of black belt 1 to the bottom edge of black belt 3 on the adjustment original at two positions.
Measurement procedure
 - 1) Measure the distance "D" and "E" between two points as follows. (D: Measure the distance from the leading edge to the trailing edge of black belt 3 on the adjustment original at 30mm of the left edge and deduct A. E: Measure the distance from the leading edge to the trailing edge of black belt 3 on the adjustment original at 180mm of the left edge and deduct C.)
 - 2) Apply the following formula for the values obtained: $(D/2+E/2)$
8. Enter the value solved in "Sub Scan" using the [\blacktriangleleft] [\blacktriangleright] keys keys.
9. Press the [Start] key to set the setting value.




Figure 6-20

Setting: DP(CharB)

* :This setting is usually unnecessary.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------------|--|----------------|-----------------|----------------|
| Lead | Set the adjustment value of the leading edge. | 14.0 to 16.0 | 15.0 | 0.1mm |
| Main Scan | Sets the adjustment value of the left edge. | 14.0 to 16.0 | 15.0 | 0.1mm |
| Sub Scan | Set the adjustment value of the trailing edge. | 265.0 to 269.0 | 267.0 | 0.1mm |

1. Measure the distance "A" from the leading edge to the black belt (inside) on the adjustment original.
2. Enter the values measured in "Lead" using the [◀] [▶] keys.
3. Measure the distance "B" from the left edge to the black belt (inside) on the adjustment original.
4. Enter the values measured in "Main Scan" using the [◀] [▶] keys.
5. Measure the distance "C" from the leading black belt (inside) to the trailing black belt (inside) on the adjustment original.
6. Enter the values measured in "Sub Scan" using the [◀] [▶] keys.
7. Press the [Start] key to set the setting value.




Figure 6-21

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U429 | Adjusting the color balance offset (Message: Color Balance) |
|-------------|--|

Contents

Displays/changes the density of each color in various image quality mode.

Purpose

Execute to change each color's balance.

Method

1. Press the [Start] key.
1. Select the image mode to change the setting.
- * : The screen for setting is displayed.

| Items | Contents |
|-----------------------|---|
| Text+Photo | Density of each color in the text+photo mode |
| Photo | Density of each color in the photo mode |
| Photo/Printout | Each color's density in the printed photo mode |
| Text | Density of each color in the text mode |
| Graphics/Map | Density of each color in the map mode |
| Copy/Printout | Each color's density in the printed document mode |

Setting: Text+Photo

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|----------|------------------------------------|---------------|-----------------|
| C | Cyan color balance offset value | -5 to 5 | 0 |
| M | Magenta color balance offset value | -5 to 5 | 0 |
| Y | Yellow color balance offset value | -5 to 5 | 0 |
| K | Black color balance offset value | -5 to 5 | 0 |

* : When the setting value is increased, the image gets thicker, and it is thinner when the setting value is decreased.

3. Press the [Start] key to set the setting value.

Setting: Photo

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|----------|------------------------------------|---------------|-----------------|
| C | Cyan color balance offset value | -5 to 5 | 0 |
| M | Magenta color balance offset value | -5 to 5 | 0 |
| Y | Yellow color balance offset value | -5 to 5 | 0 |
| K | Black color balance offset value | -5 to 5 | 0 |

* : When the setting value is increased, the image gets thicker, and it is thinner when the setting value is decreased.

3. Press the [Start] key to set the setting value.

Setting: Photo/Printout

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|----------|------------------------------------|---------------|-----------------|
| C | Cyan color balance offset value | -5 to 5 | 0 |
| M | Magenta color balance offset value | -5 to 5 | 0 |
| Y | Yellow color balance offset value | -5 to 5 | 0 |
| K | Black color balance offset value | -5 to 5 | 0 |

* :When the setting value is increased, the image gets thicker, and it is thinner when the setting value is decreased.

3. Press the [Start] key to set the setting value.

Setting: Text

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|----------|------------------------------------|---------------|-----------------|
| C | Cyan color balance offset value | -5 to 5 | 0 |
| M | Magenta color balance offset value | -5 to 5 | 0 |
| Y | Yellow color balance offset value | -5 to 5 | 0 |
| K | Black color balance offset value | -5 to 5 | 0 |

* :When the setting value is increased, the image gets thicker, and it is thinner when the setting value is decreased.

3. Press the [Start] key to set the setting value.

Setting: Graphics/Map

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|----------|------------------------------------|---------------|-----------------|
| C | Cyan color balance offset value | -5 to 5 | 0 |
| M | Magenta color balance offset value | -5 to 5 | 0 |
| Y | Yellow color balance offset value | -5 to 5 | 0 |
| K | Black color balance offset value | -5 to 5 | 0 |

* :When the setting value is increased, the image gets thicker, and it is thinner when the setting value is decreased.

3. Press the [Start] key to set the setting value.

Setting: Copy/Printout

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|----------|------------------------------------|---------------|-----------------|
| C | Cyan color balance offset value | 0 to 10 | 5 |
| M | Magenta color balance offset value | 0 to 10 | 5 |
| Y | Yellow color balance offset value | 0 to 10 | 5 |
| K | Black color balance offset value | 0 to 10 | 5 |

* :When the setting value is increased, the image gets thicker, and it is thinner when the setting value is decreased.

3. Press the [Start] key to set the setting value.

Supplement

Test copy of the original is available by pressing the [System Menu/Counter] key as interruption copy mode when executing this maintenance mode.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U464 | ID correction setting (Message: Set ID Adj Mode) |
|-------------|---|

Contents

Set permission/prohibition of the ID correction operation (calibration). Executes each setting of the calibration.

Purpose

Execute the calibration setting when an image failure occurs or depending on the user's request. Execute Calibration when replacing the maintenance kit.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|----------------------|---|
| Permission | Permit/Prohibit Calibration |
| Time Interval | Sets the time interval to execute calibration after completing printing. |
| Mode | Color print mode setting |
| Leaving Time | Setting the time to determine whether to execute calibration when recovering from Sleep mode |
| Target Value | Setting the target sensor value for the thick layer calibration and light intensity calibration |
| Calib | Executing Calibration |

Setting: Permission

1. Select [On] or [Off].

| Items | Contents |
|------------|-------------------------|
| On | Permitting Calibration |
| Off | Prohibiting Calibration |

* :Initial setting: On

2. Press the [Start] key to set the setting value.

Setting: Time Interval

1. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|------------------|----------------------|---------------|-----------------|
| Time(sec) | Calibration interval | 0 to 9999 | 1200 (sec) |

* :Setting is changeable in 10 count increments.

2. Press the [Start] key to set the setting value.

Setting: Mode

1. Select the item to set.

| Items | Contents |
|---------------|----------------------------------|
| Short | Color print mode setting: Short |
| Normal | Color print mode setting: Normal |
| Long | Color print mode setting: Long |
| Auto | Color print mode setting: Auto |

* :Initial setting: Normal

2. Press the [Start] key to set the setting value.

Setting: Leaving Time

3. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|------------------|-------------------------|---------------|-----------------|
| Time(min) | Setting the sleep timer | 0 to 1440 | 1080 (min) |

4. Press the [Start] key to set the setting value.

Setting: Target Value

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|---------------------|------------------------------------|---------------|-----------------|
| Thickness(C) | Toner layer calibration (Cyan) | 0 to 1000 | 700 |
| Thickness(M) | Toner layer calibration (Magenta) | 0 to 1000 | 640 |
| Thickness(Y) | Toner layer calibration (Yellow) | 0 to 1000 | 550 |
| Thickness(K) | Toner layer calibration (Black) | 0 to 1000 | 700 |
| Gamma(C) | Light amount calibration (Cyan) | 0 to 1000 | 445 |
| Gamma(M) | Light amount calibration (Magenta) | 0 to 1000 | 445 |
| Gamma(Y) | Light amount calibration (Yellow) | 0 to 1000 | 375 |
| Gamma(K) | Light amount calibration (Black) | 0 to 1000 | 465 |

3. Press the [Start] key to set the setting value.

Method: Calib

1. Select the item to execute.
2. Press the [Start] key.

* :Calibration is started.

Same operation as [System Menu] - [Adjustment/Maintenance] - [Calibration].

| Items | Contents |
|---------------|---|
| Regist | Execute the registration correction calibration |
| Full | Executes Full Calibration |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U465 | ID correction data (Message: ID Adj Data) |
|-------------|--|

Contents

Refers to the ID correction data.

Purpose

Execute for data check.

Method

- 1.Press the [Start] key.
 - 2.Select [Laser Power].
- * :The screen is switched.

| Items | Contents |
|--------------------|--|
| Laser Power | Displays the light intensity control value |

* :The current value is displayed.

| Items | Contents |
|--------------|---|
| C | Displays the Cyan light intensity control value. |
| M | Displays the Magenta light intensity control value. |
| Y | Displays the Yellow light intensity control value. |
| K | Displays the Black light intensity control value. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U467 | Color registration correction operation setting (Message: Set Reg Adj Mode) |
|-------------|--|

Contents

Sets the color registration correction operation.

Also, sets the execution condition of the color registration correction by the LSU temperature variation.

Purpose

If the color registration is unstable due to the sensor failure, etc., set it to off to temporarily fix the control value.

Method

1. Press the [Start] key.

2. Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|---------------------|---|
| Color Regist | Sets the color registration correction |
| Timing | Execute the color registration correction if the LSU temperature changes by the specified value after the previous correction |

Setting: Color Regist

1. Select the item to set.

| Items | Contents |
|------------|---|
| On | Permitting the color registration correction operation |
| Off | Prohibiting the color registration correction operation |

* :Initial setting: On

2. Press the [Start] key to set the setting value.

Setting: Timing

1. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|-----------------|--|---------------|-----------------|
| LSU Temp | Execution condition by the LSU temperature variation | 2 to 20 | 10 |

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U468 | Color registration correction data (Message: Cor Reg Data) |
|-------------|---|

Contents

Displays the color registration correction data.

Purpose

Execute for data check.

Method

1. Press the [Start] key.
2. Select the item to refer to.

* :The screen is switched.

| Items | Contents |
|-------------------|--|
| Auto(C) | Displaying the automatic color registration correction value (Cyan) |
| Auto(M) | Displaying the automatic color registration correction value (Magenta) |
| Auto(Y) | Displaying the automatic color registration correction value (Yellow) |
| Manual(C) | Displays the manual color registration correction value (Cyan) |
| Manual(M) | Displays the manual color registration correction value (Magenta) |
| Manual(Y) | Displays the manual color registration correction value (Yellow) |
| Initialize | Initializing the correction result |

Refer: Auto(C) / Auto(M) / Auto(Y)

1. Select [Auto(C)], [Auto(M)] or [Auto(Y)].

* :The current value is displayed.

| Items | Contents |
|------------------|---|
| Main Scan | Automatic color registration adjustment value in the main scanning direction. |
| Sub Scan | Automatic color registration adjustment value in the sub scanning direction. |
| Mag | Automatic color registration correction value for magnification |

Refer: Manual(C) / Manual(M) / Manual(Y)

1. Select [Manual(C)], [Manual(M)] or [Manual(Y)]

* :The current value is displayed.

| Items | Contents |
|------------------|--|
| Main Scan | Manual color registration adjustment value in the main scanning direction. |
| Sub Scan | Manual color registration adjustment in the sub scanning direction. |
| Mag1 | Manual color registration correction value 1 for magnification |
| Mag2 | Manual color registration correction value 2 for magnification |
| Mag3 | Manual color registration correction value 3 for magnification |
| Mag4 | Manual color registration correction value 4 for magnification |

Method: Initialize

1. Select [Initialize].

* :The operation is executed.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U469 | Color registration adjustment (Message: Adj Cor Reg) |
|-------------|---|

Contents

Corrects the color registration data.

Purpose

Execute when replacing the laser scanner unit.

* :Make sure to execute U464 Calib before executing this maintenance mode.

Method

1.Press the [Start] key.

2.Select the item to set.

* :Select [Auto] to output the automatic adjustment chart.

* :Select [Manual] to enter the setting display.

| Items | Contents |
|---------------|---|
| Auto | Adjust the color registration automatically |
| Manual | Adjust the color registration manually |

Method: Auto

1.Select the item to execute.

| Items | Contents |
|----------------|--|
| Print | Output the automatic adjustment chart. |
| Execute | Start scanning and execute the automatic adjustment. |

Method: Print

1.Press the [Start] key.

* :Output the automatic adjustment chart.

Method: Execute

1.Place an original on the table and press the [Start] key.

* :Execute the automatic adjustment.

2.When adjustment has normally completed, [OK] is displayed.

* :An error code appears when there is an error.

Error codes list

| Error codes | Place of occurrence | Factor |
|-------------|---------------------|--|
| S001 | Scanner | Original reference patch is not detected |
| S002 | | Scanned image position shifted in excess in the main scanning direction. |
| S003 | | Scanned image position shifted in excess in the sub scanning direction. |
| S004 | | Original skew is in excess |
| S005 | | Original type mismatch |
| SFFF | | Other scanning error |
| E001 | Engine | Engine error |
| CFFF | Controller | Other errors |

Setting: Manual

1. Select the item to execute.
* : The screen for setting is displayed.

| Items | Contents |
|-------------------|---|
| Regist(CH) | Sets the color registration adjustment value (CH) |
| Regist(MH) | Sets the color registration adjustment value (MH) |
| Regist(YH) | Sets the color registration adjustment value (YH) |
| Print | Output the manual adjustment chart. |

Method: Print

1. Press the [Start] key.
* : Output the manual adjustment chart.

Chart sample

There are H-1 to 9 in the chart For each color of m, c and y (upper part).




Figure 6-22

Find the positions where two lines are best matched on each chart.

- * : If it is at "0", the correction is unnecessary. In case of the illustration below, "B" is the value that should be set.




Figure 6-23

Method: Regist(CH)

- 1.Change the screen using the [Up/Down cursor] key.
- 2.Select the item to set.
- 3.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|-------|-----------------------|---------------|-----------------|
| CH-1 | CH-1 adjustment value | -9 to 9 | - |
| CH-2 | CH-2 adjustment value | -9 to 9 | - |
| CH-3 | CH-3 adjustment value | -9 to 9 | - |
| CH-4 | CH-4 adjustment value | -9 to 9 | - |
| CH-5 | CH-5 adjustment value | -9 to 9 | - |
| CV-3 | CV-3 adjustment value | -9 to 9 | - |

- 4.Press the [Start] key to set the setting value.

Method: Regist(MH)

- 1.Change the screen using the [Up/Down cursor] key.
- 2.Select the item to set.
- 3.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|-------|-----------------------|---------------|-----------------|
| MH-1 | MH-1 adjustment value | -9 to 9 | - |
| MH-2 | MH-2 adjustment value | -9 to 9 | - |
| MH-3 | MH-3 adjustment value | -9 to 9 | - |
| MH-4 | MH-4 adjustment value | -9 to 9 | - |
| MH-5 | MH-5 adjustment value | -9 to 9 | - |
| MV-3 | MV-3 adjustment value | -9 to 9 | - |

- 4.Press the [Start] key to set the setting value.

Method: Regist(YH)

- 1.Change the screen using the [Up/Down cursor] key.
- 2.Select the item to set.
- 3.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|-------|-----------------------|---------------|-----------------|
| YH-1 | YH-1 adjustment value | -9 to 9 | - |
| YH-2 | YH-2 adjustment value | -9 to 9 | - |
| YH-3 | YH-3 adjustment value | -9 to 9 | - |
| YH-4 | YH-4 adjustment value | -9 to 9 | - |
| YH-5 | YH-5 adjustment value | -9 to 9 | - |
| YV-3 | YH-3 adjustment value | -9 to 9 | - |

- 4.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U470 | Setting the JPEG compression rate (Message: Adj JPEG Rate) |
|-------------|---|

Contents

Sets the JPEG compression rate by image mode.

Purpose

Change the setting depending on the image desired by the user . Lower the set value to reduce the image roughness by changing the compression rate in case of 200% or more of the enlarged copy . If the set value is reduced, compression is high and image quality is lowered. If the set value is increased, image quality is improved but processing speed is slower.

Method

- 1.Press the [Start] key.
 - 2.Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|---------------|--|
| Copy | Compression rate of the copy |
| Send | Compression rate of the Send |
| System | Compression rate of the temporary saving in the system |

Method: Copy

- 1.Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|--------------|------------------------------------|
| Photo | Compression rate of the photo mode |
| Text | Compression rate of the text mode |

Setting: Photo

- 1.Select the item to set.
- 2.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|-------------|--|---------------|-----------------|
| Y | Compression rate of the brightness | 1 to 100 | 90 |
| CbCr | Compression rate of the color difference | 1 to 100 | 90 |

- 3.Press the [Start] key to set the setting value.

Setting: Text

- 1.Select the item to set.
- 2.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|-------------|--|---------------|-----------------|
| Y | Compression rate of the brightness | 1 to 100 | 90 |
| CbCr | Compression rate of the color difference | 1 to 100 | 90 |

- 3.Press the [Start] key to set the setting value.

Method: Send

1. Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|--------------------------|---|
| Photo | Compression rate of the photo mode |
| Text | Compression rate of the text mode |
| HC-PDF(BG) | Sets the compression rate for high compression PDF |
| HC-PDF(Char) | Set the compression rate for High compression PDF (text color). |
| HC-PDF(File Size) | Set the compression rate for High compression PDF (compression priority). |

Setting: Photo

1. Select the item to set.

2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|--------------|--|---------------|-----------------|
| Y1 | Compression rate of the brightness | 1 to 100 | 30(%) |
| Y2 | Compression rate of the brightness | 1 to 100 | 40(%) |
| Y3 | Compression rate of the brightness | 1 to 100 | 51(%) |
| Y4 | Compression rate of the brightness | 1 to 100 | 70(%) |
| Y5 | Compression rate of the brightness | 1 to 100 | 90(%) |
| CbCr1 | Compression rate of the color difference | 1 to 100 | 30(%) |
| CbCr2 | Compression rate of the color difference | 1 to 100 | 40(%) |
| CbCr3 | Compression rate of the color difference | 1 to 100 | 51(%) |
| CbCr4 | Compression rate of the color difference | 1 to 100 | 70(%) |
| CbCr5 | Compression rate of the color difference | 1 to 100 | 90(%) |

3. Press the [Start] key to set the setting value.

Setting: Text

1. Select the item to set.

2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|--------------|--|---------------|-----------------|
| Y1 | Compression rate of the brightness | 1 to 100 | 30(%) |
| Y2 | Compression rate of the brightness | 1 to 100 | 40(%) |
| Y3 | Compression rate of the brightness | 1 to 100 | 51(%) |
| Y4 | Compression rate of the brightness | 1 to 100 | 70(%) |
| Y5 | Compression rate of the brightness | 1 to 100 | 90(%) |
| CbCr1 | Compression rate of the color difference | 1 to 100 | 30(%) |
| CbCr2 | Compression rate of the color difference | 1 to 100 | 40(%) |
| CbCr3 | Compression rate of the color difference | 1 to 100 | 51(%) |

| Items | Contents | Setting range | Initial setting |
|--------------|--|---------------|-----------------|
| CbCr4 | Compression rate of the color difference | 1 to 100 | 70(%) |
| CbCr5 | Compression rate of the color difference | 1 to 100 | 90(%) |

3.Press the [Start] key to set the setting value.

Setting: HC-PDF(BG)

1.Select the item to set.

2.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|--------------|--|---------------|-----------------|
| Y1 | Compression rate of the brightness | 1 to 100 | 15(%) |
| Y2 | Compression rate of the brightness | 1 to 100 | 25(%) |
| Y3 | Compression rate of the brightness | 1 to 100 | 90(%) |
| CbCr1 | Compression rate of the color difference | 1 to 100 | 15(%) |
| CbCr2 | Compression rate of the color difference | 1 to 100 | 25(%) |
| CbCr3 | Compression rate of the color difference | 1 to 100 | 90(%) |

3.Press the [Start] key to set the setting value.

Setting: HC-PDF(Char)

1.Select the item to set.

2.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|--------------|--|---------------|-----------------|
| Y1 | Compression rate of the brightness | 1 to 100 | 15(%) |
| Y2 | Compression rate of the brightness | 1 to 100 | 75(%) |
| Y3 | Compression rate of the brightness | 1 to 100 | 90(%) |
| CbCr1 | Compression rate of the color difference | 1 to 100 | 15(%) |
| CbCr2 | Compression rate of the color difference | 1 to 100 | 75(%) |
| CbCr3 | Compression rate of the color difference | 1 to 100 | 90(%) |

3.Press the [Start] key to set the setting value.

Setting: HC-PDF(File Size)

1.Select the item to set.

2.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|--------------|--|---------------|-----------------|
| Y1 | Compression rate of the brightness | 1 to 100 | 15(%) |
| Y2 | Compression rate of the brightness | 1 to 100 | 25(%) |
| Y3 | Compression rate of the brightness | 1 to 100 | 75(%) |
| CbCr1 | Compression rate of the color difference | 1 to 100 | 15(%) |
| CbCr2 | Compression rate of the color difference | 1 to 100 | 25(%) |
| CbCr3 | Compression rate of the color difference | 1 to 100 | 75(%) |

3.Press the [Start] key to set the setting value.

Setting: System

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|-------|--|---------------|-----------------|
| Y | Compression rate of the brightness | 1 to 100 | 90(%) |
| CbCr | Compression rate of the color difference | 1 to 100 | 90(%) |

3. Press the [Start] key to set the setting value.

Supplement

Test copy of the original is available by pressing the [System Menu/Counter] key as interruption copy mode when executing this maintenance mode.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U474 | Checking the LSU cleaning (Message: Chk LSU Cleaning) |
|-------------|--|

Contents

Execute the LSU cleaning by operating the LSI cleaning motor. Also, sets the cleaning operation interval.

Method

1. Press the [Start] key.
2. Select the item to execute.

| Items | Contents |
|---------|----------------------------------|
| Execute | Executes the cleaning operation. |
| Cycle | Sets the cleaning cycle. |

Method: Execute

1. Press the [Start] key.
- * :The LSU slit glass is cleaned.

Setting: Cycle

1. Select the item to set.
2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|--------|------------------------------|--|-----------------|
| Cnt | Sets the cleaning cycle. | 0 to 5000 *1 | 1000 |
| Timing | Sets the LSU cleaning timing | Print (during job) Print End (after completing job) | Print End |

***1: Set in 100 sheet increments**

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U485 | Image process mode setting (Message: Set Img Proc Mode) |
|-------------|--|

Contents

Sets the PDF image rotation.

Purpose

Change the PDF image rotation setting.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|-------------|----------------------------|
| Mode | Set the image process mode |

Setting: Mode

1. Select the item to set.

| Items | Contents |
|---------------------|----------------------|
| PDF Rotation | Rotate the PDF image |

2. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| setting | Contents |
|----------|---|
| 0 | The image rotation is designated to the internal parameter |
| 1 | The image rotation is designated to the actual image |
| 2 | The image rotation is designated to the internal parameter (CTM rotation) |

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U486 | Color/BW mode setting (Message: Set ACS mode) |
|-------------|--|

Contents

Sets the operation mode after detecting color originals with color/BW mixed originals.

Purpose

Mode: To prioritize the productivity when copying color/BW mixed originals in ACS mode, change the setting to Mode3. However, if setting it to Mode3, even when monochrome originals come after color originals, C/M/Y developer maintenance counts are counted up.

Permission: set in case of color background image when printing an envelope in BW half speed mode processed as color printing.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|-------------------|--|
| Mode | Color/BW mode setting |
| Permission | Permit monochrome printing at half speed |

Setting: Mode

1. Select the item to set.

| Items | Contents |
|-----------------|---|
| 0: Mode1 | For users mostly printing in monochrome mode and color/monochrome mixed mode is not high during continuous printing. Monochrome printing remains in the color process speed after switching to color and other process is switched . |
| 1: Mode2 | For users mostly printing in monochrome mode and color/monochrome mixed mode is not high during continuous printing. Even when receiving a monochrome print request during color printing, color printing operation is continued until 9 pages and color mode is switched to monochrome mode when starting printing of the 10th page (Color process is stopped). |
| 2: Mode3 | Appropriate for users who mostly print in color. Once switched to the color mode, monochrome printing after that remains in the color process including the surface speed. |
| 3: Auto | Mode 1 to 3 is automatically selected depending on user's usage. Select Mode 1 to 3 based on color print ratio and switch rate from the print volume during the specified period. |

- * :Initial setting: 1 (Mode2)
2. Press the [Start] key to set the setting value.

Setting: Permission

- 1.Press the [Start] key.
- 2.Select the item to set.

| Items | Contents |
|---------------|--|
| 1: On | Permit: monochrome printing (three colors separated) |
| 0: Off | Prohibit: color printing (four color process) |

* :Initial setting: Off

- 3.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U520 | TDRS setting (Message: Set TDRS) |
|-------------|---|

Contents

Checks/sets the TDRS

Purpose

Execute to check/set the TDRS

Method

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|----------------------|---|
| Registration | Changes to the TDRS Manager registration dialog |
| Information | Transition to the Device Agent description dialog |
| On/Off Config | Changes to the TDRS features setting dialog |

Setting: Registration

3. Select the item to set.

| Items | Contents |
|--------------------|---|
| TDRS User | Registering process for user and password |
| Access Code | Registers Access Code |

Setting: Access Code

4. Select the item to set.

| Items | Contents |
|---------------------|---------------------------------|
| Regist | Registers in the TDRS Manager |
| TDRS Server | Sets the TDRS server URL |
| TDRS User | Sets the TDRS Username |
| Access Code | Sets the TDRS access code |
| Proxy Server | Sets the TDRS proxy server URL |
| Proxy Port | Sets the TDRS proxy port number |
| Proxy User | Sets the TDRS proxy username |
| Text | Sets the TDRS description |

- * :[Regist] is not executable if a USB memory is not installed.
- * :When the USB memory is inserted, TDRS information is automatically retrieved and displayed.
After obtaining the TDRS information, select [Regist] and then register the TDRS information by pressing the [OK] or [Start] key.
- * :After the normal completion, [Complete] is indicated in the status information of the item that was performed.
When an error occurs, the following numbers are indicated in the status information of the item that has been operated.
- * :If [User/Processing Registration using a Password] is selected in the previous dialog, the "TDRS User" will be indicated.
If [Processing Registration using an Access Code] is selected, the "Access Code" will be indicated.

Error codes

| Items | Contents | Items | Contents |
|--------------|--|--------------|--------------------------------------|
| e0001 | HDD is unavailable. | t0001 | Fatal error |
| e0002 | The USB memory is unavailable. | t0002 | Error in processing the network |
| e0003 | The file to import does not exist in the USB memory. | t0003 | An illegal parameter error |
| e0004 | Reading from the USB memory has failed. | t0004 | Insufficient resource |
| e0005 | Unmounting the USB memory has failed. | t0005 | Communication error |
| e0006 | Moving or renaming the file has failed. | t0006 | Error in processing communication. |
| e0007 | Opening the file has failed. | t0007 | Login error |
| e0008 | Closing the file has failed. | t0008 | External error |
| e0009 | Error in reading the file | t0009 | Authentication error |
| e000A | Copying the file has failed. | t000A | HTTP error: Request error |
| e000B | Opening the directory has failed. | t000B | HTTP error: Error due to the server |
| e000C | Creating the working directory has failed. | | HTTP error: Error due to the client. |
| e000D | Deleting the working file has failed. | | |

Setting: Information

1. Select the item to set.

| Items | Contents |
|-------------------|-------------------------------------|
| Agent ID | Agent ID |
| Agent Type | Agent Type |
| Model | Refers to the model name |
| Serial No | Refers to the machine serial number |
| Offline | Refers to the TDRS connection state |

Setting: On/Off Config

1. Select the item to set.

| Items | Contents |
|------------|---------------|
| On | Enables TDRS |
| Off | Disables TDRS |

* :Initial setting: Off

2. Press the [Start] key to set the setting value.

3. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U600 | Initialize: All Data (Message: Init: All Data) |
|-------------|---|

Contents

Initializes software switches, and all data and image memory in the backup data on the FAX PWB according to the destination and OEM setting.

Initializes the file system and then initializes the communication record and the registered contents if the file system is checked and an error is detected there.

Purpose

Initialize the FAX PWB

Method

1. Press the [Start] key.

* :The screen for entering the destination code and OEM code is displayed.

2. Select [Country Code] and enter a destination code using the numeric keys.

* :Refer to the following destination code list.

| Items | Contents |
|---------------------|-------------------------------|
| Country Code | Setting Destination code |
| OEM Code | Sets the OEM code |
| Execute | Executing data initialization |

* :No need to change the default value of [OEM Code].

3. Select [Execute].

4. Press the [Start] key to execute the initialization.

* :Press the [Stop] key to cancel the data initialization.

5. The firmware version is displayed after the data initialization.

The firmware version of 3 types of application, boot and IPL is displayed.

* :Where an irregular value is input, when it initializes, the following errors are displayed.

| Kind of error |
|--|
| Unknown Country (When Country Code is unknown) |
| Unknown OEM (When OEM Code is unknown) |
| Unknown Country (When both are unknown) |

Destination code list

| Destina- tion code | Destination | Destina- tion code | Destination |
|-----------------------|-------------|-----------------------|--------------------------|
| 000 | Japan | 253 | CTR21 (European nations) |
| 007 | Argentina | ↑ | Italy |
| 009 | Australia | ↑ | Germany |
| 022 | Brazil | ↑ | Spain |
| 038 | China | ↑ | U.K. |
| 080 | Hong Kong | ↑ | Netherlands |
| 084 | Indonesia | ↑ | Sweden |
| 088 | Israel | ↑ | France |
| 097 | Korea | ↑ | Austria |

| Destina- tion code | Destination | Destina- tion code | Destination |
|-------------------------------|--------------------|-------------------------------|--------------------|
| 181 | U.S.A. | ↑ | Switzerland |
| 250 | Russia | ↑ | Belgium |
| 108 | Malaysia | ↑ | Denmark |
| 115 | Mexico | ↑ | Finland |
| 126 | New Zealand | ↑ | Portugal |
| 136 | Peru | ↑ | Ireland |
| 137 | Philippines | ↑ | Norway |
| 152 | Middle East | 254 | Taiwan |
| 156 | Singapore | | |
| 159 | South Africa | | |
| 169 | Thailand | | |

| | |
|-------------|--|
| U601 | Initialize: Keep data (Message: Init Keep Data) |
|-------------|--|

Contents

Initializes software switches other than the machine data on the FAX PWB according to the destination and OEM setting.

Purpose

Initialize the FAX PWB without changing the user registration data and the factory defaults

Method

1. Press the [Start] key.
* :The screen for entering the destination code and OEM code is displayed.
2. Select [Country Code].
3. Press the [◀] [▶] keys or the numeric keys to change the counter value.
* :Refer to the destination code list. (P.6-378 Refer to page 1-6-58)

| Items | Contents |
|---------------------|-------------------------------|
| Country Code | Setting Destination code |
| OEM Code | Sets the OEM code |
| Execute | Executing data initialization |

* :No need to change the default value of [OEM Code].

4. Select [Execute].
5. Press the [Start] key to execute the initialization.
* :Press the [Stop] key to cancel the data initialization.
6. The firmware version is displayed after the data initialization.
The firmware version of 3 types of application, boot and IPL is displayed.
* :Where an irregular value is input, when it initializes, the following errors are displayed.

| Kind of error |
|--|
| Unknown Country (When Country Code is unknown) |
| Unknown OEM (When OEM Code is unknown) |
| Unknown Country (When both are unknown) |

| | |
|-------------|---|
| U603 | User data 1 (Message: User Data 1) |
|-------------|---|

Contents

Sets the line type for FAX use

Purpose

Execute as required

Method

1. Press the [Start] key.
2. Select [Line Type].

| Items | Contents |
|------------------|-----------------|
| Line Type | Line Type |

3. Select the item to set.

| Items | Contents |
|--------------|-----------------|
| DTMF | DTMF |
| 10PPS | 10PPS |
| 20PPS | 20PPS |

* :Initial setting: DTMF

4. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U604 | User data 2 (Message: User Data 2) |
|-------------|---|

Contents

Sets the number of rings for the automatic FAX/telephone switching for FAX use

Purpose

Adjust the number of rings to longer or shorter at the automatic FAX/telephone switching

Method

1. Press the [Start] key.
2. Select [Rings(F/T)].
3. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Items | Contents | Setting range | Initial setting |
|----------------------|-------------------------------|---------------|--|
| Rings (F/T) # | Number of fax/telephone rings | 0 to 15 | 0 (100 V model) 1 (220-240 V model) 2 (Australia) 3 (New Zealand) |

- * :If the default is set to "0", the main unit will start FAX reception without any ringing.
4. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U605 | Data clear (Message: Clr Data) |
|-------------|---|

Contents

Initializes data related to the fax transmission such as transmission history or various ID.

Purpose

Clear the communication history

Method

1. Press the [Start] key.
2. Select [Clear Com.Rec.].

| Items | Contents |
|-----------------|--|
| Comm Rec | Delete data of communication history and protocol list of displayed port |

3. Press the [Start] key.

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U610 | System 1 (Message: System Setting 1) |
|-------------|---|

Contents

Set the number of lines to be ignored when receiving a fax at 100% magnification and in the auto reduction mode.

Method

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|-----------------------|--|
| Cut Line: A4 | Set the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode. |
| Cut Line: 100% | Set the number of lines to be ignored when receiving a fax at 100% magnification. |
| Cut Line: Auto | Number of lines to be ignored when receiving in the auto reduction mode. |

Setting: Cut Line: A4

Set the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when the data is recorded in the auto reduction mode onto A4R or Letter R paper. If the number of excess lines is below the setting, those lines are ignored. If over the setting, the entire data on a page is further reduced so that it can be recorded on the same page.

1. By using [◀] [▶] or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting | Data variation |
|--|----------------------|------------------------|-----------------------|
| Number of lines to be ignored when receiving in the A4R auto reduction mode. | 0 to 22 | 0 | - |

* : Increase the setting value if a page received in the reduction mode is reduced too much with the trailing edge margin. Decrease the value if there is dropout in received image.

2. Press the [Start] key to set the setting value.

Setting: Cut Line: 100%

Sets the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when recording the data at 100% magnification. If the number of excess lines is below the setting, those lines are ignored. If it is over the setting, they are recorded on the next page.

1. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Contents | Setting range | Initial setting | Data variation |
|---|----------------------|------------------------|-----------------------|
| Set the number of lines to be ignored when receiving a fax at 100% magnification. | 0 to 22 | 3 | - |

* : Increase the setting value if a blank second page is output in the full magnification reception. Decrease the value if there is dropout in received image.

2. Press the [Start] key to set the setting value.

Setting: Cut Line: Auto

Set the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when the data is recorded in the auto reduction mode.

If the number of excess lines is below the setting, those lines are ignored. If over the setting, the entire data on a page is further reduced so that it can be recorded on the same page.

1. Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Contents | Setting range | Initial setting | Data variation |
|--|---------------|-----------------|----------------|
| Number of lines to be ignored when receiving in the auto reduction mode. | 0 to 22 | 0 | - |

* : Increase the setting value if a page received in the reduction mode is reduced too much with the trailing edge margin. Decrease the value if there is dropout in received image.

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U611 | System 2 (Message: System Setting 2) |
|-------------|---|

Contents

Sets the number of adjustment lines for automatic reduction.

Purpose

Sets the number of adjustment lines for automatic reduction.

Method

- 1.Press the [Start] key.
- 2.Select the item to set.

| Items | Contents |
|----------------------|---|
| ADJ LINES | Sets the number of adjustment lines for automatic reduction. |
| ADJ LINES(A4) | Number of adjustment lines for automatic reduction when A4 paper is set. |
| ADJ LINES(LT) | Number of adjustment lines for automatic reduction when letter size paper is set. |

Setting: ADJ LINES

Sets the number of adjustment lines for automatic reduction.

- 1.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Contents | Setting range | Initial setting | Data variation |
|---|----------------------|------------------------|-----------------------|
| Number of adjustment lines for automatic reduction. | 0 to 22 | 7 | - |

- 2.Press the [Start] key to set the setting value.

Setting: ADJ LINES(A4)

Sets the number of adjustment lines for automatic reduction.

- 1.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Contents | Setting range | Initial setting | Data variation |
|--|----------------------|------------------------|-----------------------|
| Number of adjustment lines for automatic reduction when A4 paper is set. | 0 to 22 | 22 | - |

- 2.Press the [Start] key to set the setting value.

Setting: ADJ LINES(LT)

Sets the number of adjustment lines for automatic reduction when letter size paper is set.

- 1.Press the [◀] [▶] keys or the numeric keys to change the counter value.

| Contents | Setting range | Initial setting | Data variation |
|---|----------------------|------------------------|-----------------------|
| Number of adjustment lines for automatic reduction when letter size paper is set. | 0 to 22 | 26 | - |

- 2.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U612 | System 3 (Message: System Setting 3) |
|-------------|---|

Contents

Sets the FAX operation and automatic printing of the protocol list.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|----------------------|--|
| Auto reduce | Selects auto reduction in the sub-scanning direction |
| Protocol List | Sets the automatic protocol list printing. |

Setting: Auto Reduce

Sets whether to receive a long document by automatically reducing it in the sub-scanning direction or at 100% magnification.

1. Select the item to set.

| Items | Contents |
|--------------|---|
| On | Auto reduction is executed if the received document is longer than the FAX paper. |
| Off | Auto reduction is not performed. |

- * :Initial setting: On
2. Press the [Start] key to set the setting value.

Setting: Protocol List

Sets the automatic protocol list printing.

1. Select the item to set.

| Items | Contents |
|--------------|--|
| Off | The protocol list is not printed out automatically. |
| Err | Automatically printed if a communication error occurs. |
| On | Automatically printed out after communication. |

- * :Initial setting: Off
2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U620 | FAX system (Message: FAX System) |
|-------------|---|

Contents

Sets the signal detection method for remote switching.
Change the setting according to the type of telephone connected to the main unit.

Purpose

Sets the remote switching conditions according to the user's telephone type, preference, etc.

Setting

1. Press the [Start] key.
2. Select [Remote Mode] and press the [Start] key.

| Items | Contents |
|--------------------|-----------------------------------|
| Remote Mode | Setting the remote switching mode |

3. Select the item to set.

| Items | Contents |
|--------------|------------------------------------|
| One | Sets the one-shot type detection |
| Cont | Sets the continuous type detection |

* :Initial setting: One

4. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U625 | Communication settings (Message: Set Comm) |
|-------------|---|

Contents

Sets the auto redialing interval and the number of times of auto redialing.

Purpose

FAX transmission may not be available if redialing interval is short. If long, it takes much time to complete transmission. Changes the setting to prevent the following problems.

Method

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|-----------------|--|
| Interval | Sets the auto redialing interval |
| Times | Sets the number of times of auto redialing |

Setting: Interval

1. By using [◀] [▶] or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting | Data variation |
|------------------------------------|----------------------|------------------------|-----------------------|
| Sets the redialing interval | 1 to 9 minutes | 3 minutes | - |

2. Press the [Start] key to set the setting value.

Setting: Times

1. By using [◀] [▶] or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting | Data variation |
|--|----------------------|------------------------|-----------------------|
| Sets the number of times of redialing | 0 to 15 times | 3 times | - |

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U630 | Communication control procedures 1 (Message: Comm Ctrl 1) |
|-------------|--|

Contents

Sets the FAX communication.

Purpose

Sets the following to correspond to field claims

Reducing the transmission time to improve the accuracy of reception when using a low quality line

Improving the accuracy of communication during the international communication

Method

1.Press the [Start] key.

2.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|-----------------|---|
| TX Speed | Sets the communication starting speed. |
| RX Speed | Sets the reception speed. |
| TX Echo | Sets the waiting period to prevent echo problems at the sender. |
| RX Echo | Sets the reception speed. |

Setting: TX Speed

Sets the transmission speed of the sender. When the destination unit has the V.34 capability, V.34 is selected for transmission regardless of this setting.

1.Select the communication speed.

| Items | Contents |
|-----------------------|-----------------|
| 14400bps/V17 | V.17 14400bps |
| 9600bps/V29 | V.29 9600bps |
| 4800bps/V27ter | V.27ter 4800bps |
| 2400bps/V27ter | V.27ter 2400bps |

* :Initial setting: 14400bps/V17

2.Press the [Start] key to set the setting value.

Setting: RX Speed

Sets the reception capacity to advise the transmitter by the DIS/NSF signal. When the destination unit has the V.34 capability, V.34 is selected for transmission regardless of this setting.

1.Select the reception speed.

| Items | Contents |
|-----------------|---------------------------|
| 14400bps | V.17, V.33, V.29, V.27ter |
| 9600bps | V.29, V.27ter |
| 4800bps | V.27ter |
| 2400bps | V.27ter (fallback only) |

* :Initial setting: 14400bps

2.Press the [Start] key to set the setting value.

Setting: TX Echo

Sets the time to send the DCS signal after the DIS signal is received. Execute when an error occurs with echo at the transmitter side.

1.Select the item to set.

| Items | Contents |
|------------|---|
| 500 | Sends the DCS 500 ms after receiving a DIS. |
| 300 | Sends the DCS 300 ms after receiving a DIS. |

* :Initial setting: 300

2.Press the [Start] key to set the setting value.

Setting: RX Echo

Sets the time to send the NSF, CSI or DIS signal after the CED signal is received. Execute when an error occurs with echo at the receiver side.

1.Select the item to set.

| Items | Contents |
|------------|--|
| 500 | Sends the NSF, CSI or DIS 500ms after receiving the CED. |
| 75 | Sends the NSF, CSI or DIS 75ms after receiving the CED. |

* :Initial setting: 75

2.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U631 | Communication control procedures 2 (Message: Comm Ctrl 2) |
|-------------|--|

Contents

Sets the FAX communication.

Purpose

Sets the transmission and reception of ECM

Sets the CED frequency

Method

1.Press the [Start] key.

2.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|-----------------|---------------------------------|
| ECM TX | Sets ECM transmission. |
| ECM RX | Sets ECM reception. |
| CED Freq | The frequency of CED is set up. |

Setting: ECM TX

Set to OFF when the reduction of transmission costs is of higher priority than image quality.

* :Do not set it to Off when connecting to the IP telephone line.

1.Select the item to set.

| Items | Contents |
|--------------|-------------------------------|
| On | ECM transmission is enabled. |
| Off | ECM transmission is disabled. |

* :Initial setting: On

2.Press the [Start] key. Set the setting value.

Setting: ECM RX

Set to OFF when the reduction of transmission costs is of higher priority than image quality.

* :Do not set it to Off when connecting to the IP telephone line.

1.Select the item to set.

| Items | Contents |
|--------------|----------------------------|
| On | ECM reception is enabled. |
| Off | ECM reception is disabled. |

* :Initial setting: On

2.Press the [Start] key to set the setting value.

Setting: CED Freq

Sets the CED frequency Execute it as one of the communication accuracy improvement measures for the international communication.

1. Select the item to set.

| Items | Contents |
|-------|----------|
| 2100 | 2100Hz |
| 1100 | 1100Hz |

* :Initial setting: 2100

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U632 | Communication control procedures 3 (Message: Comm Ctrl 3) |
|-------------|--|

Contents

Sets the FAX communication.

Purpose

Reducing the error communication when using a low quality line

Corresponds to field claims when automatic FAX/telephone switching

Method

1.Press the [Start] key.

1.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|------------------------|---|
| DIS 4Byte | Sets the DIS signal to 4 bytes. |
| Num OF CNG(F/T) | Sets the number of the CNG detection in the automatic FAX/telephone switching mode. |

Setting: DIS 4Byte

Sets whether to send bit 33 and later bits of the DIS/DTC signal.

1.Select the item to set.

| Items | Contents |
|------------|---|
| On | Bit 33 and later bits of the DIS/DTC signal are not sent. |
| Off | Bit 33 and later bits of the DIS/DTC signal are sent. |

* :Initial setting: Off

2.Press the [Start] key to set the setting value.

Setting: Num OF CNG(F/T)

Sets the CNG detection times in the automatic FAX/telephone switching mode. Sets the line type for FAX use

1.Select the item to set.

| Items | Contents |
|--------------|--------------------|
| 1Time | Detects CNG once. |
| 2Time | Detects CNG twice. |

* :Initial setting: 1Time (100 V model)/2Time (Others)

2.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U633 | Communication control procedures 4 (Message: Comm Ctrl 4) |
|-------------|--|

Contents

Sets the FAX communication.

Purpose

Reducing the error communication when using a low quality line

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|--------------------|---|
| V.34 | Enables or disables the V.34 communication. |
| V.34-3429Hz | Sets the V.34 symbol speed (3429 Hz). |
| DIS 2Res | Sets the number of times of DIS signal reception. |
| RTN Check | Sets the reference for the RTN signal output. |

Setting: V.34

Sets whether to enable/disable the V.34 communication individually for transmission and reception.

1. Select the item to set.

| Items | Contents |
|------------|---|
| On | V.34 communication is enabled for both transmission and reception. |
| TX | V.34 communication is enabled for transmission only. |
| RX | V.34 communication is enabled for reception only. |
| Off | V.34 communication is disabled for both transmission and reception. |

* :Initial setting: On

2. Press the [Start] key to set the setting value.

Setting: V.34-3429Hz

Sets if the V.34 symbol speed 3429 Hz is used.

1. Select the item to set.

| Items | Contents |
|------------|--|
| On | V.34 symbol speed 3429 Hz is used. |
| Off | V.34 symbol speed 3429 Hz is not used. |

* :Initial setting: On

2. Press the [Start] key to set the setting value.

Setting: DIS 2Res

Sets the number of times to receive the DIS signal to once or twice. Execute it as one of the corrective measures for transmission errors and other problems.

1. Select the item to set.

| Items | Contents |
|--------------|--------------------------------|
| Once | Responds to the first signal. |
| Twice | Responds to the second signal. |

* :Initial setting: Once

1. Press the [Start] key to set the setting value.

Setting: RTN Check

Sets the error line rate to be a reference to the RTN signal transmission. If transmission errors occur frequently due to the line quality, lower this setting to reduce them.

1. Select the item to set.

| Items | Contents |
|------------|------------------------|
| 5% | Error line rate of 5% |
| 10% | Error line rate of 10% |
| 15% | Error line rate of 15% |
| 20% | Error line rate of 20% |

* :Initial setting: 15%

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U634 | Communication control procedures 5 (Message: Comm Ctrl 5) |
|-------------|--|

Contents

Sets the maximum number of error bytes judged acceptable when receiving a TCF signal. Execute it as one of measures to ease transmission conditions if transmission errors occur.

Purpose

* :Relax the communication conditions

Setting

- 1.Press the [Start] key.
- 2.Select [TCF Check].
- 3.By using [◀] [▶] or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|------------------|--|---------------|-----------------|
| TCF Check | Sets the allowed error bytes when detecting the TCF signal | 1 to 255 | 0 |

- 4.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U640 | Communication time setting 1 (Message: Comm Time 1) |
|-------------|--|

Contents

Sets the detection time when one-shot detection is selected for remote switching.
Sets the detection time when continuous detection is selected for remote switching.

Purpose

Sets the remote switching conditions according to the user's telephone type, preference, etc.

Method

- 1.Press the [Start] key.
- 2.Select the item to set.
- 3.By using [◀] [▶] or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|--------------------|--|---------------|----------------------|
| Time(One) | Sets the one-shot detection time for remote switching. | 0 to 255 | 7 1 (New Zealand) |
| Time (Cont) | Sets the continuous detection time for remote switching. | 0 to 255 | 80 |

- 4.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U641 | Communication time setting 2 (Message: Comm Time 2) |
|-------------|--|

Contents

Sets the time-out time for the fax communication.

Purpose

Mainly, executed to improve the accuracy of communication for international communication

Method

1. Press the [Start] key.
1. Select the item to set.

| Items | Contents |
|---------------------|-----------------------------|
| T0 Time Out | Sets the T0 time-out time. |
| T1 Time Out | Sets the T1 time-out time. |
| T2 Time Out | Sets the T2 time-out time. |
| Ta Time Out | Sets the Ta time-out time. |
| Tb1 Time Out | Sets the Tb1 time-out time. |
| Tb2 Time Out | Sets the Tb2 time-out time. |
| Tc Time Out | Sets the Tc time-out time. |
| Td Time Out | Sets the Td time-out time. |

Setting: T0 Time Out

Sets the time before detecting a CED or DIS signal after a dialing signal is sent.

Sets to prevent disconnection of a line that occurs depending on the quality of the exchange, or when the destination unit sets the auto switching function.

1. By using [◀] [▶] or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|----------------------------|----------------------|------------------------|
| Sets the T0 time-out time. | 30 to 90 s | 56 58 (100 V model) |

2. Press the [Start] key to set the setting value.

Setting: T1 Time Out

Sets the time before receiving the correct signal after call reception.

*This setting is usually unnecessary.

1. By using [◀] [▶] or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|----------------------------|----------------------|------------------------|
| Sets the T1 time-out time. | 30 to 90 s | 36 38 (100 V model) |

2. Press the [Start] key to set the setting value.

Setting: T2 Time Out

The T2 time-out time is specified as follows.
 From CFR signal output to image data reception
 From image data reception to the next signal reception
 In ECM, from RNR signal detection to the next signal reception

1. By using [◀] [▶] or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|----------------------------|---------------|-----------------|
| Sets the T2 time-out time. | 1 to 255 | 69 |

2. Press the [Start] key to set the setting value.

Setting: Ta Time Out

Sets the time to start ringing for an operator through the external telephone after receiving a call in the FAX/telephone automatic switching mode. (See figure 1-3-18). If either receiving a FAX signal within this time or passing this time, the mode automatically switches to the FAX reception mode. Execute when a reception error occurs when in the automatic FAX/telephone switching.

1. By using [◀] [▶] or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|----------------------------|---------------|-----------------|
| Sets the Ta time-out time. | 1 to 255 s | 30 |

2. Press the [Start] key to set the setting value.




Figure 6-24 Ta/Tb1/Tb2 time-out time

Setting: Tb1 Time Out

Sets the time to start sending the ring back tone after receiving a call as a fax machine in the FAX/telephone automatic switching mode, (See figure 1-3-18). Execute when a reception error occurs when in the automatic FAX/telephone switching.

1. By using [◀] [▶] or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|-----------------------------|---------------|-----------------|
| Sets the Tb1 time-out time. | 1 to 255 | 20 |

2. Press the [Start] key to set the setting value.

Setting: Tb2 Time Out

Sets the time to start ringing for an operator through the external telephone after receiving a call in the FAX/telephone automatic switching mode. (See figure 1-3-27). Execute when a reception error occurs when in the automatic FAX/telephone switching.

1.By using [◀] [▶] or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|-----------------------------|---------------|-----------------|
| Sets the Tb2 time-out time. | 1 to 255 | 80 |

2.Press the [Start] key to set the setting value.

Setting: Tc Time Out

In the TAD mode, set the time to check if there are any triggers for shifting to FAX reception after a connected handset receives a call. Unless switched to FAX reception during this period, operated as a normal phone after this.

In the TAD mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.

1.By using [◀] [▶] or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|----------------------------|---------------|-----------------|
| Sets the Tc time-out time. | 1 to 255 s | 60 |

2.Press the [Start] key to set the setting value.

Setting: Td Time Out

Sets the length of time to determine silent status, one of the triggers for Tc time check.

In the TAD mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call. Be sure not to set too short, otherwise the mode may be switched to fax while the unit is being used as a telephone.

1.By using [◀] [▶] or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|----------------------------|---------------|--|
| Sets the Td time-out time. | 1 to 255 | 30 (100 V model) 6 (220-240 V model) 9 (120 V model) |

2.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U650 | Modem 1 (Message: Modem 1) |
|-------------|---|

Contents

Sets the G3 cable equalizer. Sets the modem detection level.

Purpose

Adjusts the equalizer to be compatible with the line characteristics
Set to Improve the accuracy of communication when using a low quality line

Method

- 1.Press the [Start] key.
- 2.Select the item to set.

| Items | Contents |
|----------------------|---|
| Reg G3 TX Eqr | Sets the G3 transmission cable equalizer. |
| Reg G3 RX Eqr | Sets the G3 reception cable equalizer. |
| RX Mdm Level | Sets the modem detection level. |

Setting: Reg G3 TX Eqr

- 1.Select [0dB], [4dB], [8dB] or [12dB].
* :Initial setting: 0dB
- 2.Press the [Start] key to set the setting value.

Setting: Reg G3 RX Eqr

- 1.Select [0dB], [4dB], [8dB] or [12dB].
* :Initial setting: 0dB
- 2.Press the [Start] key to set the setting value.

Setting: RX Mdm Level

- 1.Select [-33dBm], [-38dBm], [-43dBm] or [-48dBm].
* :Initial setting: -43dBm
- 2.Press the [Start] key to set the setting value.

Completion

- Press the [Stop] key.
* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---------------------------------------|
| U651 | Modem 2 (Message: Modem 2) |
|-------------|---------------------------------------|

Contents

Sets the modem output level.

Purpose

Adjust to make the equalizer compatible with the line characteristics when installing the main unit

Setting

1. Press the [Start] key.
2. Select the item to set.
3. By using [◀] [▶] or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|------------------------|---|----------------------|--|
| Sgl LVL Modem | Sets the modem output level | -15 to 0 | -10 (100 V model) -11 (220-240 V model/ 120 V model) -12 (Australia) |
| DTMF LEV (Cent) | DTMF output level (center value) | -15.0 to 0.0 | -9 (100 V model) -8 (220-240 V model) -6 (120 V model) -7 (Australia) -8 (New Zealand) |
| DTMF LEV (Diff) | Sets the DTMF output level (level difference) | 0 to 5.5 | 2 1.5 (Australia) 1 (New Zealand) |

4. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U660 | Ring setting (Message: Set Calls) |
|-------------|--|

Contents

Sets the NCU (network control unit).

Purpose

Execute as required

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|--------------------|---|
| Exchange | Setting the PBX/PSTN connection |
| Dial Tone | Sets the PSTN dial tone detection. |
| Busy Tone | Sets the busy tone detection. |
| PBX Setting | Setting the PBX connection |
| DC Loop | Sets the loop current detection before dialing. |

Setting: Exchange

Selects if the FAX is connected to either a PBX or public switched telephone network.

1. Select the item to set.

| Items | Contents |
|--------------|---|
| PSTN | Connected to the public switched telephone network. |
| PBX | Connecting to the PBX |

* :Initial setting: PSTN

2. Press the [Start] key to set the setting value.

Setting: Dial Tone

Selects whether or not to check for a dial tone to check if the telephone is off the hook when a fax is connected to a public switched telephone network.

1. Select the item to set.

| Items | Contents |
|--------------|--------------------------------|
| On | The dial tone is detected. |
| Off | The dial tone is not detected. |

* :Initial setting: On

2. Press the [Start] key to set the setting value.

Setting: Busy Tone

Sets whether the line is disconnected immediately after a busy tone is detected, or the busy tone is not detected and the line remains connected until T0 time-out time, when a FAX signal is sent FAX transmission may fail due to incorrect busy tone detection. When setting it to OFF, this problem may be improved. However, the line is not disconnected within the T0 time-out time even if the destination line is busy.

1. Select the item to set.

| Items | Contents |
|------------|--------------------------------|
| On | Detects the busy tone. |
| Off | Does not detect the busy tone. |

* :Initial setting: On/Off (Australia)

2. Press the [Start] key to set the setting value.

Setting: PBX Setting

Selects the mode to connect an outside call when connected to a PBX.

*According to the type of the PBX connected, select the mode to connect an outside call.

1. Select the item to set.

| Items | Contents |
|--------------|------------------|
| Flash | Flashing mode |
| Loop | Code number mode |

* :Initial setting: Loop

2. Press the [Start] key to set the setting value.

Setting: DC Loop

Sets if the loop current is detected before dialing.

1. Select the item to set.

| Items | Contents |
|------------|--|
| On | Detects the loop current before dialing. |
| Off | Detects the loop current before dialing. |

* :Initial setting: On

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U670 | List output (Message: Output List) |
|-------------|---|

Contents

Outputs the list of fax communication data.

* :Printing a list is disabled either when a job is remaining in the buffer or when [Pause All Print Jobs] is pressed to halt printing.

Purpose

Check conditions of use, settings and transmission procedures of the FAX.

Method

- 1.Press the [Start] key.
- 2.Select the item to execute.
- 3.Press the [Start] key.
- 4.Output selected list.

| Items | Contents |
|------------------------|--|
| Sys Conf Report | Prints the list of software switches, local telephone number, confidential boxes, firmware versions and other information. |
| Action List | Prints the list of the error logs and communication lines. |
| Self Sts Report | Prints the list of FAX communication settings only in the maintenance mode (self-status report). |
| Protocol List | Outputs a list of communication procedures. |
| Error List | Output the error list. |
| Addr List(No.) | Outputs address book in the IDs order |
| Addr List(Idx) | Outputs address book in the order of names. |
| One-touch List | Outputs a list of one-touch. |
| Group List | Outputs the group list. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U695 | FAX function customization (Message: Customize FAX Func) |
|-------------|---|

Contents

FAX package transmission is set up. Changes print size priority when receiving small size.

Purpose

Execute as required

Method

1. Select the item to set.

| Items | Contents |
|----------------------|--|
| FAX Bulk TX | FAX batch transmission is set up. |
| A5 Pt Pri Chg | Change of print size priority at the time of small size reception. |

Setting: FAX Bulk TX

1. By using [◀] [▶] keys, select [On] or [Off].

| Items | Contents |
|--------------|-------------------------------------|
| On | FAX batch transmission is enabled. |
| Off | FAX batch transmission is disabled. |

* :Initial setting: On

2. Press the [Start] key to set the setting value.

Setting: A5 Pt Pri Chg

1. By using [◀] [▶] keys, select [On] or [Off].

| Items | Contents |
|--------------|--|
| On | At the time of A5 size reception: A5 >B5 >A4 >B4 >A3 |
| Off | At the time of A5 size reception: A5 >A4 >B5 >A3 >B4 |

2. Initial setting: Off

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U699 | Software switch: Set (Message: Set Soft SW) |
|-------------|--|

Contents

Sets the software switches on the FAX PWB individually.

Purpose

Change the setting when a problem such as split output of received originals occurs

* :Since the communication performance is largely affected, normally this setting need not be changed.

Method

- 1.Press the [Start] key.
- 2.Select [SW No.].
- 3.Enter the desired software switch number (3 digits) using the numeric keys and press the [Start] key.

| Items | Contents |
|---------------|--|
| SW No. | Specifies the software switch number (2 to 3 digits) |

- 4.Press the keys of bit 0 to 7 to switch each bit between 0 and 1.

| Items | Contents |
|------------|-------------------------------------|
| Bit | Set the software switch bit (8bit). |

- 5.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

**List of software switches which can be configured
Communication control procedures**

| No. | Bit | Contents |
|-----------|------|-------------------------------|
| 36 | 7654 | Coding format in transmission |
| | 3210 | Coding format in reception |
| 37 | 5 | 33600bps/V34 |
| | 4 | 31200bps/V34 |
| | 3 | 28800bps/V34 |
| | 2 | 26400bps/V34 |
| | 1 | 24000bps/V34 |
| | 0 | 21600bps/V34 |
| 38 | 7 | 19200bps/V34 |
| | 6 | 16800bps/V34 |
| | 5 | 14400bps/V34 |
| | 4 | 12000bps/V34 |
| | 3 | 9600bps/V34 |
| | 2 | 7200bps/V34 |
| | 1 | 4800bps/V34 |

| No. | Bit | Contents |
|-----|-----|---|
| 38 | 0 | 2400bps/V34 |
| 41 | 3 | FSK detection in V.8 |
| 42 | 4 | 4800 bps transmission when low-speed setting is active |
| | 2 | FIF length when transmitting DIS/DTC signal 4 times or more |

Communication time setting

| No. | Bit | Contents |
|-----|----------|--|
| 53 | 76543210 | T3 timeout setting |
| 54 | 76543210 | T4 timeout setting (auto transmission) |
| 55 | 76543210 | T5 timeout setting |
| 60 | 76543210 | Time before transmission of CNG (1100 Hz) signal |
| 63 | 76543210 | T0 timeout setting (manual transmission) |
| 64 | 7 | Phase C timeout in ECM reception |
| 66 | 76543210 | Timeout 1 in countermeasures against echo |
| 68 | 76543210 | Timeout for FSK detection start in V.8 |

Modem setting

| No. | Bit | Contents |
|-----|-------|----------------|
| 89 | 76543 | RX gain adjust |

NCU setting

| No. | Bit | Contents |
|-----|----------|--|
| 121 | 7654 | Dial tone/busy tone detection pattern |
| 122 | 7654 | Busy tone detection pattern |
| | 1 | Busy tone detection in FAX/TEL automatic switching |
| 125 | 76543210 | Registering the access code for connection to PSTN |
| 126 | 7654 | Ringback tone ON/OFF cycle for the automatic FAX/telephone switching |
| 68 | 76543210 | Timeout for FSK detection start in V.8 |

Calling time setting

| No. | Bit | Contents |
|-----|----------|----------------------------------|
| 133 | 76543210 | DTMF signal transmission time |
| 134 | 76543210 | DTMF signal pause time |
| 141 | 76543210 | Ringer detection cycle (minimum) |
| 142 | 76543210 | Ringer detection cycle (maximum) |
| 143 | 76543210 | Ringer ON time detection |
| 144 | 76543210 | Ringer OFF time detection |
| 145 | 76543210 | Ringer OFF time undetected |

| No. | Bit | Contents |
|-----|----------|---|
| 147 | 76543210 | Dial tone detection time (continuous tone) |
| 148 | 76543210 | Allowable dial tone interruption time |
| 149 | 76543210 | Time for transmitting selection signal after closing the DC circuit |
| 151 | 76543210 | Ringer frequency detection invalid time |

| | |
|-------------|--|
| U901 | Clearing the counters by paper source (Message: Clr Paper FD Cnt) |
|-------------|--|

Contents

Displays and clears the counts by paper source.

Purpose

Check the maintenance parts replacement timing. Executes to clear counters when replacing the maintenance parts.

Method

1.Press the [Start] key.

* :Displays the counts by paper source.

| Items | Contents |
|-----------------|--|
| MPT | Display/clear the MP tray feed counter |
| Cass1 | Displays/clears Cassette 1 count |
| Cass2 *1 | Displays/clears Cassette 2 count |
| Cass3 *2 | Displays/clears Cassette 3 count |
| Cass4 *3 | Displays/clears Cassette 4 count |
| Dup | Displays/clears the duplex unit count |

*1: 500 PF only, *2: 500×2/2000 PF only, *3: 500×2 PF only

2.Select the counter to clear.

* :Unable to clear [Cass2], [Cass3] and [Cass4]

3.Press the [Start] key to clear the counter value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U903 | Clearing the jam counter (Message: Clr Paper JAM Cnt) |
|-------------|--|

Contents

Displays/clears the jam counter by paper jam type.

Purpose

Execute to check the paper jam status. Executes to clear counters when replacing the maintenance parts.

Method

1. Press the [Start] key.
2. Select the item to execute.

| Items | Contents |
|------------------|--------------------------------------|
| Cnt | Displaying/clearing the jam counts |
| Total Cnt | Displaying the accumulate jam counts |

Method: Cnt

1. Select [Cnt].
 - * :Number of occurrence is displayed by jam code.
Code of no occurrence is not indicated.
2. Change the screen using the [▲] [▼] key.
3. Select [Clear] to clear the jam counts.
 - * :Individual counters cannot be cleared.
4. Press the [Start] key to clear the counter value.

Method: Total Cnt

1. Select [Total Cnt].
 - * :Accumulate number of occurrence is displayed by jam code.
2. Change the screen using the [▲] [▼] key.
 - * :Unable to clear the accumulated jam counter values.

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U904 | Clearing the service call error counter (Message: Clr Svc Call Cnt) |
|-------------|--|

Contents

Displays/clears the number of times of service call errors by service call error type.

Purpose

Executes to check the service call error. Executes to clear counters when replacing the maintenance parts.

Method

1. Press the [Start] key.
2. Select the item to execute.

| Items | Contents |
|------------------|--|
| Cnt | Displays/clears the service call counter. |
| Total Cnt | Displays accumulate service call error counts. |

Method: Cnt

1. Select [Cnt].
 - * :Number of occurrence is displayed by service call error.
Code of no occurrence is not indicated.
2. Change the screen using the [▲] [▼] key.
3. Select [Clear] to clear the service call error counter.
 - * :Individual counters cannot be cleared.
4. Press the [Start] key to clear the counter value.

Method: Total Cnt

1. Select [Total Cnt].
 - * :Accumulate number of occurrence is displayed by service call error.
2. Change the screen using the [▲] [▼] key.
 - * :Unable to clear the accumulated service call error counter values.

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U905 | Optional counter (Message: Option Cnt) |
|-------------|---|

Contents

Displays the counter values of the document processor and inner finisher.

Purpose

Execute to check the usage status of the document processor or inner finisher.

Method

1. Press the [Start] key.
 2. Select the device to check.
- * :Switched to the counter screen.

| Items | Contents |
|--------------|--|
| DP | Displays the document processor count. |
| DF | Displays the document finisher count. |

Method: DP

* :Each counter is displayed.

| Items | Contents |
|--------------|--------------------------------------|
| ADP | Simplex original count is displayed. |
| RADP | Duplex original count is displayed. |

Method: DF

* :Each counter is displayed.

| Items | Contents |
|---------------|------------------------------|
| Sorter | Displays the sorter counter. |
| Staple | Displays the staple counter. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U906 | Resetting the partial operation (Message: Reset Dis Func) |
|-------------|--|

Contents

Release the service call error with partial operation.

Purpose

If the partial operation is executed with a broken cassette, etc., make sure to execute it after repairing the parts.

Method

- 1.Press the [Start] key.
- 2.Select [Execute].

| Items | Contents |
|----------------|------------------------------|
| Execute | Reset the partial operation. |

- 3.Press the [Start] key to release the partial operation.
- 4.Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U908 | Total counter (Message: Total Cnt) |
|-------------|---|

Contents

Displays the total counter.

Purpose

Displays the total counter for check.

Method

- 1.Press the [Start] key.
- * :Displays the total count.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U910 | Black rate data (Message: Clr Coverage Dat) |
|-------------|--|

Contents

Clears the accumulated data for the print coverage per A4 size paper and its period of time (as shown on the service status page).

Purpose

Clears data as required at the time such as maintenance

Method

1. Press the [Start] key.
2. Select [Execute].

| Items | Contents |
|----------------|---------------------------------|
| Execute | Clears the print coverage data. |

3. Press the [Start] key to clear the print coverage data.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U911 | Counter by media type (Message: Paper SZ Cnt) |
|-------------|--|

Contents

Displays the paper feed counts by paper size.

Purpose

Displays the counts to confirm when replacing the maintenance parts .

Method

1. Press the [Start] key.
- * :Displays the paper feed counts by paper size.

| Items | Contents |
|------------------|--|
| A4 | Displays Statement feed capacity |
| B5 | Displays B5 feed capacity |
| A5 | Displays B5 feed capacity |
| Folio | Displays Folio feed capacity. |
| Legal | Displays Legal feed capacity |
| Letter | Displays Letter feed capacity |
| Statement | Displays Statement feed capacity |
| ETC | Displays paper feed capacity of Other. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U917 | Read/Write Backup Data (Message: R/W Bkup Data) |
|-------------|--|

Contents

Retrieves the backup data to a USB memory from the main unit, or writes the data from the USB memory to the main unit.

Purpose

Makes a back up of the main unit information, and import or export to restore the main unit information

Method

1. Turn the power switch off.
2. Insert a USB memory into the USB memory slot.
3. Turn the power switch on.
 - * :Wait for about 10 seconds until the main unit recognizes a USB memory.
4. Enter maintenance mode U917.
5. Select [Export] or [Import], and press the [Start] key.

| Items | Contents |
|---------------|---|
| Import | Imports data from the USB memory to the main unit. |
| Export | Retrieving data from the main unit to the USB memory. |

6. Select the object item.

* :Change the screen using the [▲] [▼] key.

| Items | Contents | Depending data* |
|------------------|-----------------------------|--|
| Address | Address book information | - |
| Job AcCnt | Job accounting information | - |
| One Touch | One-touch key information | Address book information |
| User | User management information | Job accounting information |
| Document | Document box information | Job accounting, User information |
| Shortcut | Short-cut information | Job accounting, User, Document Box information |
| Fax Fwd | FAX forward information | Job accounting, User, Document Box information |
| System | System setting information | - |
| Network | Network setting information | - |
| Job Set | Job setting information | - |
| Printer | Printer setting information | - |
| Fax Set | FAX setting information | - |

| Items | Contents | Depending data* |
|------------------|---------------------------|---|
| Program | Program information | Information of Address book, Job accounting, User management, Document box, FAX transfer and FAX setting |
| Panel Set | Panel setting information | Information of Address book, Job accounting, User management, Document box, FAX transfer, FAX setting and Program |

* :Since data are dependent with each other, data other than selected are also retrieved or written.

7. Select the object item.

8. Press the [Start] key. Starts reading or writing.

* :The progress of selected item is displayed in %.

* :When an error occurs, the operation is canceled and an error code appears.

9. [Finish] appears after normal completion.

10. When selecting [Import], turn the power switch off then on, after completing writing. Wait more than 5 seconds between the power off and on.

Error codes

| Codes | Contents |
|-----------------------|--|
| e000 | Unspecified error |
| e0001 | Parameter error |
| e0002 | Generating a dummy file has failed. |
| e0003 | The XML file to import does not exist |
| e0004 | The exported file does not exist |
| e0100 to e01ff | Error in handling addressbook |
| e0200 to e02ff | Error in handling One-touch |
| e0300 to e03ff | Error in handling user management |
| e0400 to e04ff | Error in handling panel program data |
| e0500 to e05ff | Error in handling forwarding FAX data |
| e0600 to e06ff | Error in handling the system configuration |
| e0700 to e07ff | Error in handling network parameters |
| e0800 to e08ff | Error in handling job accounting |
| e0900 to e09ff | Error in handling short-cuts |
| e0a00 to e0aff | Error in handling job information |
| e0b00 to e0bff | Error in handling FAX data |
| e0c00: toe0cff | Error in handling printer data |
| e0d00 to e0dff | Error in handling panel data |
| e0e00 to e0eff | Error in handling document boxes |
| e1000 to e1fff | Error in the device-related process |
| e2000 to e2fff | Error in handling SOAP IF |
| e3000 to e3fff | Error in handling KM-WSDL IF |

| Codes | Contents |
|-----------------------|---|
| e4000 to e4fff | Error in process for import (e4002) A file mandatory for importing is missing (e4008) Invalid file header |
| e5000 to e5fff | Error in the SOAP data rewriting process |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U920 | Billing counter (Message: Chg Cnt) |
|-------------|--|

Contents

Displays the billing count.

Purpose

Execute to check the current billing counts

Method

1.Press the [Start] key.

* :Switched to each display screen.

* :Change the screen using the [▲] [▼] key.

| Items | Contents |
|-------------------|--|
| Col Copy H | Color copy counts (Coverage: High) |
| Col Copy M | Color copy counts (Coverage: Middle) |
| Col Copy L | Color copy counts (Coverage: Low) |
| Mono Copy | Displays mono color copy count |
| B/W Copy | B/W copy count is displayed. |
| Col Prn H | Color print counts (Coverage: High) |
| Col Prn M | Color print counts (Coverage: Middle) |
| Col Prn L | Color print counts (Coverage: Low) |
| B/W Prn | B/W print count is displayed |
| B/W FAX | FAX count |
| Simplex | Simplex print count is displayed |
| Duplex | Duplex print count is displayed |
| Comb(Off) | Combine print counts (Off) is displayed |
| Comb(2in1) | Combine print counts (2in1) is displayed |
| Comb(4in1) | Combine print counts (4in1) is displayed |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U927 | Clearing all the billing/life counters (Message: Clr Chg/Life Cnt) |
|-------------|---|

Contents

Clears all charge counts and machine life counts.

Supplement

The total charge counts and the machine life counts can be cleared only once if all count values are 1000 or less.

Method

1. Press the [Start] key.
2. Select [Execute].

| Items | Contents |
|----------------|---|
| Execute | Initializes the billing count and machine life count. |

3. Press the [Start] key.

* :Clears all charge counts and machine life counts.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U928 | Machine life counter (Message: Life Cnt) |
|-------------|---|

Contents

The current machine life counts is displayed.

Purpose

Executed to check the machine life count

Method

1. Press the [Start] key.
- * :The current machine life counts is displayed.

| Items | Contents |
|--------------|---------------------------------|
| Cnt | Displays the machine life count |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U930 | Clear the main charger roller counts (Message: Clr Chg Cnt) |
|-------------|--|

Contents

Displays and clears the current main charger roller counts.

Purpose

To verify the main charger roller counts after replacing. Also, clear the counts after replacement

Method

1.Press the [Start] key.

* :The main charge roller counter for each color is displayed.

| Items | Contents |
|--------------|---|
| C | The current main charger roller count for C is displayed. |
| M | The current main charger roller count for M is displayed. |
| Y | The current main charger roller count for Y is displayed. |
| K | The current main charger roller count for K is displayed. |

Method: Clear

1.Select the item to set.

1.Select [Clear].

2.Press the [Start] key to clear the counter value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|--|--|
| | |
|--|--|

| | |
|-------------|---|
| U952 | MMaintenance mode workflow (Message: Mainte Work Flow) |
|-------------|---|

Contents

Execute the maintenance items in the order of registration in the main unit or the USB memory.

Purpose

Execute to register regular maintenance items.

Method

1. Press the [Start] key.
 2. Select the item to execute.
- * : The screen for executing is displayed.

| Items | Contents |
|-------------------|--|
| Continue | Resume interrupted workflow. |
| Exec(USB) | Executes the workflow in a USB memory. |
| Execute | Execute the workflow saved in the main unit. |
| Entry(USB) | Executes the workflow in a USB memory. |
| Entry | Register the workflow in the main unit manually. |
| Log | Displays the latest workflow execution history. |

Method: Continue

1. Select maintenance item number to execute.
 2. Press the [Start] key.
- * : Selected maintenance mode is executed.

Method: Execute (USB)

1. Check the LED display is off and turn the power switch off.
2. Insert a USB memory into the USB memory slot.
3. Turn the power switch on.
4. Enter maintenance item U952.
5. Select [Exec(USB)].
6. Select [workflow].

| Items | Contents |
|-----------------------------|-------------------------------|
| WorkFlowData 01 - 07 | Workflow data in a USB memory |

7. Press the [Start] key.
- * : Execute the maintenance items in the order of registration in the workflow.

Method: Excute

1. Select the place to save the data to execute.

| Items | Contents |
|-------------------|-------------------------------------|
| Data 1 - 6 | Workflow save area in the main unit |

2. Select the item to execute.
3. Press the [Start] key to start the processing.

Method: Entry(USB)

1. Check the LED display is off and turn the power switch off.
2. Insert a USB memory into the USB memory slot.

3. Turn the power switch on.
4. Enter maintenance item U952.
5. Select [Entry(USB)].
6. Select [workflow].

| Items | Contents |
|-----------------------------|-------------------------------|
| WorkflowData 01 - 07 | Workflow data in a USB memory |

7. Select the workflow save area.

| Items | Contents |
|-------------------|-------------------------------------|
| Data 1 - 8 | Workflow save area in the main unit |

8. Select [Execute].
- * :Registers the workflow in a USB memory to the main unit.

Method: Entry

1. Select [Entry].
2. Select the workflow save area.

| Items | Contents |
|-------------------|-------------------------------------|
| Data 1 - 8 | Workflow save area in the main unit |

3. Press [◀] [▶] or the numeric keys to input the maintenance item No. in the workflow.

| Items | Contents |
|--------------------|--------------------------------|
| Flow 1 - 14 | Registered maintenance numbers |

4. Press the [Start] key to set the setting value.
5. Press the [Start] key.
- * :Execute the maintenance items in the order of registration in the workflow.

e.g.

When inserting a USB memory the following items can be registered: commands, texts and maintenance numbers (variable).

File format: xxx.mwf

- 1, SET UP, 464, 469, 410, 000, 927, 278
- 2, WARRANTY, 089, 000
- 3, MK-A, 930, 127, 167, 464, 469, 410, 251
- 4, MK-B, 930, 464, 469, 410, 251
- 5, EH SETUP, 411, 034, 246, 211

Completion

- Press the [Stop] key.
- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|------------------|
| U964 | Log check |
|-------------|------------------|

Contents

Transfer the log files save in the NAND to a USB memory.

Purpose

Transfer the log file saved in the NAND to a USB memory for investigation when a failure occurs.

Method

1. Check the LED display is off and turn the power switch off.
2. Insert a USB memory into the USB memory slot.
3. Turn the power switch on.
4. Enter maintenance item U952.
5. Select [Execute].

| Items | Contents |
|----------------|------------------------|
| Execute | Transfer the log file. |

6. Press the [Start] key.

* :Starts transferring the log files saved in the NAND to a USB memory.
[Processing] is displayed. (About 3 to 5 minutes)

7. [Completed] appears after normal completion.

8. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

* :An error code appears when there is an error.

Supplement

How to retrieve the log when the operation panel freezes

Log retrieving starts when pressing four keys on the operation panel (*, 8, 6, Clear) for 3 to 6 seconds.

The memory lamp is blinking during retrieving and turns off when completed.

The log retrieved this way can be saved in a USB memory.

Error codes

| Display | Contents |
|--------------------------|---|
| No USB Storage | The USB memory is not installed |
| No File | No file |
| Mount Error | USB memory mount error |
| File Delete Error | Failed to delete existing files in the USB memory |
| Copy Error | NAND to USB memory copy failure |
| Unmount Error | USB memory unmount error |
| Other Error | Other error |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U969 | Toner area code (Message: Toner Area Code) |
|-------------|---|

Contents

Displays the toner area code.

Purpose

Execute to check the currently set toner area code and model code

Method

1.Press the [Start] key.

* :Displays the toner area code and model code

| Items | Contents |
|-------------------|---------------------------|
| Area Code | Toner container area code |
| Model Code | Model code |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U977 | Setting the data capture mode (Message: Set Data Capture) |
|-------------|--|

Contents

Stores the data sent to the main unit into a USB memory.

Purpose

Store the data sent to the main unit into a USB memory to check it.

Method

1.Press the [Start] key.

2.Select [Execute].

| Items | Contents |
|----------------|------------------------------|
| Execute | Stores data in a USB memory. |

3.Press the [Start] key.

* :When the operation is completed abnormally, an error code is displayed.

Error codes

| Items | Contents |
|-----------|---|
| 1 | USB memory is broken. USB memory was disconnected during data processing or is write-protected. |
| 4 | USB memory is full. |
| 50 | Other error occurs |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U984 | Developer unit number (Message: Dev No.) |
|-------------|---|

Contents

Displays the developer unit number.

Purpose

Execute to check the developer unit number.

Method

1. Press the [Start] key.

* :Displays the developer unit number.

| Items | Contents |
|--------------|---|
| C | Displays the Cyan developer unit number. |
| M | Displays the Magenta developer unit number. |
| Y | Indicates the Yellow developer unit number. |
| K | Displays the Black developer unit number. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U985 | Developer unit history (Message: Dev History) |
|-------------|--|

Contents

Displays the machine serial number and developer counter history.

Purpose

Displays the machine serial number and developer count to check.

Method

1. Press the [Start] key.

* : Select color to refer to.

| Items | Contents |
|--------------|--|
| C | Displays the Cyan developer unit history. |
| M | Displays the Magenta developer unit history. |
| Y | Indicates the Yellow developer unit history. |
| K | Displays the Black developer unit history. |

* : Displays the machine serial number and 3 items of the developer counter history.

| Items | Contents |
|-------------------------------|-------------------------------|
| Machine History 1 to 3 | Machine serial number history |
| Cnt History1 to 3 | Developer counter history |

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U991 | Scanner counter (Message: Scanner Counter) |
|-------------|---|

Contents

Displays the scanner operation counts.

Purpose

Display the number of scanner operation to check the usage status.

Method

1. Press the [Start] key.

* : Current number of operation is displayed.

| Items | Contents |
|-------------------|---|
| Copy Scan | Displays times of copy and scan operations. |
| Fax Scan | Displays times of FAX scan operations. |
| Other Scan | Displays times of other scan operations. |

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

(3) Maintenance modes list (35/40 ppm model)

| Section | No. | Maintenance item | Outline |
|---|------------------|--|---|
| General | U000 | Printing Maintenance Report | Printing the reports and exporting them to a USB memory |
| | U001 | Exiting the maintenance mode | Exiting from the maintenance mode |
| | U002 | Set Factory Default | Initializing to the factory-default setting |
| | U003 | Setting the telephone number of the service person | Sets the telephone number of the service person. |
| | U004 | Machine serial number | Display of the machine serial number and setting |
| | U010 | Setting the maintenance mode ID | Setting the maintenance mode ID |
| | U018 | Firmware self verification | Check the firmware falsification. |
| | U019 | Firmware Version | Displays the firmware version of the PWB |
| Initializa- tion | U021 | Initializes Memory | Initializing the backup RAM |
| | U024 | Formatting an HDD | Formats/configures the HDD |
| | U025 | Firmware update (S) | Updates the firmware |
| | U026 | Retrieve the backup data | Retrieve the backup data |
| Drive Paper feed Convey- ing Cooling | U030 | Motor operation check | Drive the drive motor |
| | U031 | Check the conveying switch | Check the conveying switch On/Off |
| | U032 | Clutch operation check | Check the paper conveying clutch operation |
| | U033 | Solenoid operation check | Drive the paper conveying and toner supply solenoids |
| | U034 | Paper timing adjustment | Adjusting the leading edge timing and the center line |
| | U035 | Folio size setting | Sets the Folio paper length and width. |
| | U037 | Fan motor operation check | Drive each fan motor. |
| | | | |
| | U051 | Registration paper loop amount adjustment | Adjusts the paper loop amount between the rollers |
| | U053 | Adjusting the motor speed | Sets each motor's speed correction |
| U059 | Fan mode setting | Sets the drive mode of the conveying fan motor | |
| Optical | U061 | Lamp lighting check | Turns the exposure lamp on |
| | U063 | Shading position adjustment | Changes the scanner shading position |
| | U065 | Adjusting the magnification for table scanning | Adjusting the magnification for table scanning |
| | U066 | Adjusting the table scanning timing | Adjusting the leading edge timing for table scanning |
| | U067 | Adjusting the table scanning center line | Adjusting the center line for table scanning |
| | U068 | DP scanning position adjustment | Adjusting the starting position for DP scanning |

| Section | No. | Maintenance item | Outline |
|----------------------------|------|---|---|
| Optical | U070 | DP magnification adjustment | Adjusting the magnification for DP scanning |
| | U071 | Adjusting the DP leading edge Timing | Adjusting the DP scanning timing |
| | U072 | Adjusting the DP original center | Adjusting the center line for DP scanning |
| | U073 | Scanner motor operation check | Move the scanner in the set condition |
| | U087 | Setting the DP scanning position change operation | Change the scanning position as the corrective measures for the black lines |
| | U089 | MIP-PG pattern output | Output MIP-PG pattern |
| | U091 | White lines correction setting | Sets the white lines detection threshold |
| High voltage system | U100 | Main high voltage adjustment | Adjust the drum surface potential |
| | U101 | Primary transfer voltage adjustment | Sets high voltage except the main high voltage and outputs |
| | U106 | Secondary transfer voltage adjustment | Set the secondary transfer voltage correction |
| | U107 | Primary transfer cleaning voltage adjustment | Set the primary transfer belt cleaning voltage |
| | U110 | Drum counter | Displays/sets the drum counter |
| | U117 | Drum unit number | Displays the drum number |
| | U118 | Drum unit history | Displays the drum history |
| | U119 | Setting the drum | Sets the initial LSU light intensity |
| | U120 | Drum drive distance counter | Displays the drum drive distance counter |
| | U127 | Clearing the transfer count | Displaying the counts |
| | U128 | Leading edge timing | Adjust the transfer high-voltage output ON/OFF timing |
| Developer system | U132 | Forcible toner supply operation | Execute the toner supply in the toner control level |
| | U135 | Checking the toner motor operation | Drives the toner motor |
| | U136 | Toner level detection setting | Sets the number of pages printable at toner near end |
| | U139 | Temperature, humidity | Displays the machine inside and outside humidity |
| | U140 | Developer bias adjustment | Adjust the developer bias values or set the high altitude mode. |
| | U147 | Setting the toner applying mode | Sets the overcharge toner removal mode |
| | U148 | Drum refresh mode setting | Setting auto drum refresh |
| | U155 | Toner sensor output | Displays the toner sensor output |
| | U156 | Toner control level adjustment | Displays/adjusts the toner supply level |
| | U157 | Developer drive time | Displays/sets the developer drive time |
| | U158 | Developer counter | Displays/sets the developer counter |

| Section | No. | Maintenance item | Outline |
|--|-----------------|---|---|
| Fuser | U161 | Fuser temperature adjustment | Sets the fuser control temperature |
| | U167 | Clearing the fuser count | Displaying/clearing the counts |
| | U199 | Fuser temperature | Monitor the fuser temperature |
| Operation section / Support equipment | U200 | All LEDs lighting | Light all the LEDs on the operation panel |
| | U201 | Initializing the touch panel | Correct the X and Y axis position of the touch panel |
| | U203 | Check DP operation | Checking the DP paper conveying operation with the DP alone |
| | U204 | Key card/key counter setting | Key card/key counter connection setting |
| | U207 | Operation key check | Check the operation panel key operation |
| | U211 | Enhancement unit connection setting | Sets the connection of the enhancement units |
| | U221 | USB host lock function setting | Sets USB Host lock function ON/OFF |
| | U222 | Setting the IC card type | Sets the ID card type |
| | U223 | Operation panel lock | Set On/Off of the operation unit lock |
| | U224 | Install Original Panel Display | Changes the opening screen and the service call screen to user specified data. |
| | U230 | Optional device serial number | Displays the optional device serial number |
| | U234 | Setting destination for punch | Set the punch destination |
| | U237 | Finisher eject volume limit | Sets the main tray stack capacity |
| | U240 | Finisher operation check | Checks the drive operation |
| | U241 | Finisher switch check | Check the switch operation |
| | U243 | Checking the DP motor | Drive the PF motor and solenoid |
| U244 | DP switch check | Drive the DP sensor | |
| Operation section / Support equipment | U245 | Checking the message | Check message |
| | U246 | Finisher adjustment | Sets the finisher adjustment value |
| | U247 | Paper feed operation check | Drives the PF motor and clutch |
| Mode Setting | U250 | Checking/clearing the maintenance cycle | Changes the preset value |
| | U251 | Checking/clearing the maintenance counter | Displaying/clearing/changing the counter value |
| | U252 | Destination | Sets the machine operation and indication depending on the specification of the destination |
| | U253 | Switching the double/single counts | Sets the counter by color mode |
| | U260 | Switching the timing for copy counting | Setting the count-up timing |
| | U265 | Setting by destination | Sets the OEM code |
| | U271 | Setting the page count unit | Set the long paper count unit |

| Section | No. | Maintenance item | Outline |
|------------------|------|--|---|
| Mode Setting | U276 | Switching the copy count mode | Set the single color copy count mode |
| | U278 | Delivery date setting | Register Delivery Date |
| | U284 | Setting the 2-color copy | Switches the 2-color copy mode |
| | U285 | Set Service Status Page | Setting the print coverage report output |
| | U323 | Abnormal temperature and humidity notification setting | Switches the indication mode of the abnormal temperature and humidity detection |
| | U325 | Paper interval setting | Sets the print interval at high coverage |
| | U326 | Black line cleaning indication | Switch the black line cleaning guidance indication |
| | U327 | Cassette heater control setting | Selects the cassette heater control setting |
| | U332 | Adjusting the black coverage coefficient | Setting the coefficient of the custom size |
| | U341 | Printer cassette setting | Sets the cassette to printer output only |
| | U343 | Duplex priority mode | Switches the duplex printing priority mode |
| | U345 | Setting the value for maintenance due indication | Setting the maintenance timing display |
| | U346 | Selecting Sleep Mode | Setting the BAM related sleep mode |
| Image processing | U402 | Adjusting the printing margins | Adjusts the scan image margins |
| | U403 | Adjusting margins for scanning an original on the contact glass | Adjusts the margin for scanning originals |
| | U404 | Adjusting margins for scanning an original from the document processor | Adjusts the margin for scanning originals |
| | U407 | Adjusting the writing timing (Duplex/Reversal) | Adjusting the writing timing when duplex printing |
| | U410 | Adjusting the halftone automatically | Acquiring the data for the automatic halftone adjustment and the ID correction |
| | U411 | Scanner auto adjustment | Adjusting the scanner and DP automatically |
| | U412 | Adjusting the uneven density | Corrects the LSU density unevenness |
| | U425 | Set Target | Inputs the Lab value printed on an adjustment original |
| | U429 | Adjusting the color balance offset | Adjusts the color balance offset |
| | U464 | ID correction setting | Sets the ID correction |
| | U465 | ID correction data | Displays the light intensity control value after the ID correction |
| | U467 | Color registration correction operation setting | Sets the color registration correction |
| | U468 | Color registration correction data | Displays the color registration correction data |
| | U469 | Color registration adjustment | Corrects the color registration |
| | U470 | Setting the JPEG compression rate | Sets the JPEG compression rate |

| Section | No. | Maintenance item | Outline |
|-------------------------|----------------------------|---|--|
| Image processing | U474 | Checking the LSU cleaning | Sets the LSU cleaning operation check and cleaning cycle |
| | U485 | Image process mode setting | Sets the image processing |
| | U486 | Color/BW mode setting | Sets the image processing |
| | U520 | TDRS setting | Checking/setting the TDRS |
| FAX | U600 | Initialize: All Data | Initializes all data and image memory. |
| | U601 | Initialize: Keep data | Initializing the software switches of other than the machine data |
| | U603 | User data 1 | Makes user settings to enable the use as a FAX |
| | U604 | User data 2 | Makes user settings to enable the use as a FAX |
| | U605 | Data clear | Initializing the FAX communication data |
| | U610 | System 1 | Set the number of lines to be ignored when receiving a FAX at 100% magnification and in the auto reduction mode. |
| | U611 | System 2 | Number of adjustment lines for automatic reduction. |
| | U612 | System 3 | Setting regarding the FAX communication operation |
| | U620 | FAX system | Sets the signal detection method for remote switching |
| | U625 | Communication settings | Sets the auto redialing interval and the number of times of auto redialing |
| | U630 | Communication control procedures 1 | Setting the FAX communication |
| | U631 | Communication control procedures 2 | Sets the FAX communication |
| | U632 | Communication control procedures 3 | Setting the FAX communication |
| | U633 | Communication control procedures 4 | Setting the FAX communication |
| | U634 | Communication control procedures 5 | Set the acceptable error when judging the received TCF signal |
| | U640 | Communication time setting 1 | Setting the detection time by remote switching mode |
| | U641 | Communication time setting 2 | Sets the time-out time for the fax communication |
| | U650 | Modem 1 | Sets the G3 transmission cable equalizer |
| | U651 | Modem 2 | Sets the modem output level |
| | U660 | Ring setting | Setting the NCU (network control unit) |
| U670 | List output | Outputting the list of the fax communication data | |
| U671 | FAX backup data clear | Clear the FAX backup data | |
| U695 | FAX function customization | FAX batch transmission is set up. | |

| Section | No. | Maintenance item | Outline |
|---------------|------------------------------------|--|--|
| FAX | U698 | Setting the maintenance port | Set the port to apply |
| | U699 | Software switch: Set | Sets the software switches individually |
| Others | U901 | Clearing the counters by paper source | Displays/clears the counters by paper source |
| | U903 | Clearing the jam counter | Displays/clears number of occurrence by jam trigger code |
| | U904 | Clearing the service call error counter | Displays/clears the service call error and system error counts |
| | U905 | Optional counter | Displaying the counts |
| | U906 | Resetting the partial operation | Resets the partial operation |
| | U908 | Total counter | Displays the FAX count |
| | U910 | Black rate data | Clearing the print coverage data and its period |
| | U911 | Counter by media type | Displays/clears the counts by media type |
| | U917 | Read/Write Backup Data | Reading/writing the backup data to a USB memory |
| | U920 | Billing counter | Displays the billing count |
| | U927 | Clearing all the billing/life counters | Clearing the billing count and machine life count |
| | U928 | Machine life counter | Displays the machine life count |
| | U930 | Clear the main charger roller counts | Displaying/setting the counts |
| | U933 | Setting the maintenance mode log | Sets the maintenance mode log |
| | U942 | DP loop amount setting | Adjust the paper loop amount when using the document processor |
| | U952 | MMaintenance mode workflow | Execute the maintenance flow with the Workflow data |
| | U964 | Log check | Transfer the log files to a USB memory |
| | U969 | Toner area code | Displays the toner area code |
| | U977 | Setting the data capture mode | Stores the data sent to the main unit into a USB memory |
| | U984 | Developer unit number | Displays the developer unit number |
| U985 | Developer unit history | Displays the developer unit number history | |
| U989 | HDD scan disk | Execute the HDD scan disk | |
| U990 | Clearing the scanner lighting time | Displays the accumulated CIS lighting time | |
| U991 | Scanner counter | Displays the scanner count | |

(3-1) Content of the maintenance mode (30ppm model)

| | |
|-------------|---|
| U000 | Printing Maintenance Report (Message: Output Maintenance Report) |
|-------------|---|

Contents

Prints the list of the current settings of the maintenance items, paper jam and service call error occurrences. Output the event log and service status page.

Also, sends output data to a USB memory.

Purpose

Checks the current settings of the maintenance items, paper jam and service call error occurrences.

Before initializing or replacing the backup memory, print the list of the current settings of the maintenance items to reenter the settings after initialization or replacement.

Method

1. Press the [Start] key.
2. Select the item to output.

| Items | Output list |
|-----------------------|-------------------------------|
| Maintenance | Maintenance mode setting list |
| User Status | Output User Status Page |
| Service Status | Output Service Status Page |
| Event | Output the event log report |
| Network Status | Output Network Status Page |
| All | All reports output |

3. Press the [Start] key to output the list.

* :If A4 paper is available, it is output with this size. If A4 paper is unavailable, select the paper source. Output status is displayed.

Method: when sending output data to a USB memory

1. Press the [Start] key.
2. Insert a USB memory into the USB memory slot.
3. Select the item to send.
4. Select [USB(Text)] or [USB(HTML)].

| Items | Output list |
|------------------|---|
| Print | A report is printed. |
| USB(Text) | Destination: send to USB memory (text format) |
| USB(HTML) | Destination: send to USB memory (HTML format) |

5. Press the [Start] key.

* :The output data is sent to the USB memory.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

Detail of event log

Event Log

MFP (2) 2014/10/19 15:15

TASKalfa 406ci (3) [XXXXXXXX] (4) [XXXXXXXX] (5) [XXXXXXXX]

(1) Firmware version 2R6_2000.000.000 2014.09.19

(7) Paper Jam Log

| # | Count. | Event Descriptions | Date and Time |
|----|---------|--------------------|------------------|
| 12 | 5555555 | 0501.01.08.01.00 | 2014/02/12 17:30 |
| 11 | 4444444 | 4002.01.08.01.00 | 2014/02/12 17:30 |
| 10 | 3333333 | 0501.01.08.01.00 | 2014/02/12 17:30 |
| 9 | 2222222 | 4002.01.08.01.00 | 2014/02/12 17:30 |
| 8 | 1111111 | 0501.01.08.01.00 | 2014/02/12 17:30 |
| 7 | 9999999 | 4002.01.08.01.00 | 2014/02/12 17:30 |
| 6 | 8888888 | 0501.01.08.01.00 | 2014/02/12 17:30 |
| 5 | 7777777 | 0501.01.08.01.00 | 2014/02/12 17:30 |
| 4 | 6666666 | 4002.01.08.01.00 | 2014/02/12 17:30 |
| 3 | 5555555 | 0501.01.08.01.00 | 2014/02/12 17:30 |
| 2 | 4444444 | 4002.01.08.01.00 | 2014/02/12 17:30 |
| 1 | 1 | 4002.01.08.01.00 | 2014/02/12 17:30 |

(11) Counter Log

| (f) | Count | Item | Count |
|--------|-------|------------|-------|
| J0000: | 0 | J4302: | 0 |
| J0100: | 1 | J4303: | 1 |
| J0101: | 11 | J4304: | 11 |
| J0104: | 222 | J4309: | 2 |
| J0105: | 1 | J9000: | 1 |
| J0106: | 1 | J9004: | 0 |
| J0107: | 1 | J9010: | 1 |
| J0110: | 1 | J9060: | 1 |
| J0111: | 1 | J9061: | 2 |
| J0211: | 1 | J9062: | 1 |
| J0212: | 1 | J9110: | 1 |
| J0213: | 999 | J9120: | 0 |
| J0501: | 1 | J9200: | 1 |
| J0502: | 1 | J9210: | 1 |
| J0503: | 1 | J9220: | 2 |
| J0504: | 1 | | |
| J0508: | 1 | (g) C0000: | 0 |
| J0509: | 1 | C0001: | 1 |
| J0511: | 1 | C0002: | 2 |
| J0512: | 1 | C0003: | 3 |
| J0513: | 1 | C0004: | 4 |
| J0514: | 1 | C0005: | 5 |
| J0518: | 1 | C0006: | 6 |
| J0519: | 1 | C0007: | 7 |
| J1403: | 1 | C0008: | 8 |
| J1404: | 1 | C0009: | 9 |
| J1413: | 1 | C0010: | 10 |
| J1414: | 1 | C0011: | 11 |
| J1604: | 1 | C0012: | 12 |
| J1614: | 1 | C0013: | 13 |
| J4002: | 1 | C0014: | 14 |
| J4003: | 1 | C0015: | 15 |
| J4004: | 1 | C0016: | 16 |
| J4009: | 1 | C0017: | 17 |
| J4012: | 1 | C0018: | 18 |
| J4013: | 1 | C0019: | 19 |
| J4014: | 1 | C0020: | 20 |
| J4019: | 1 | C0021: | 21 |
| J4201: | 1 | C0022: | 22 |
| J4202: | 0 | C0023: | 23 |
| J4203: | 1 | | |
| J4204: | 1 | (h) T00: | 10 |
| J4208: | 0 | M00: | 20 |
| J4209: | 1 | M02: | 30 |
| J4211: | 11 | | |
| J4212: | 222 | | |
| J4213: | 1 | | |
| J4214: | 2 | | |
| J4218: | 1 | | |
| J4219: | 2 | | |
| J4301: | 1 | | |

(8) Service Call Log

| # | Count. | Service Code | Data and Time |
|---|---------|--------------|------------------|
| 8 | 1111111 | 01.6000 | 2014/02/12 17:30 |
| 7 | 9999999 | 01.2100 | 2014/02/12 17:30 |
| 6 | 8888888 | 01.4000 | 2014/02/12 17:30 |
| 5 | 7777777 | 01.6000 | 2014/02/12 17:30 |
| 4 | 6666666 | 01.2100 | 2014/02/12 17:30 |
| 3 | 5555555 | 01.4000 | 2014/02/12 17:30 |
| 2 | 4444444 | 01.6000 | 2014/02/12 17:30 |
| 1 | 1 | 01.2100 | 2014/02/12 17:30 |

(9) Maintenance Log

| # | Count. | Item. | Data and Time |
|---|---------|-------|------------------|
| 7 | 9999999 | 01.21 | 2014/02/12 17:30 |
| 6 | 8888888 | 01.40 | 2014/02/12 17:30 |
| 5 | 7777777 | 01.60 | 2014/02/12 17:30 |
| 4 | 6666666 | 01.21 | 2014/02/12 17:30 |
| 3 | 5555555 | 01.40 | 2014/02/12 17:30 |
| 2 | 4444444 | 01.60 | 2014/02/12 17:30 |
| 1 | 1 | 01.21 | 2014/02/12 17:30 |

(10) Unknown toner Log

| # | Count. | Item. | Data and Time |
|---|---------|-------|------------------|
| 5 | 1111111 | 01.00 | 2014/02/12 17:30 |
| 4 | 9999999 | 01.00 | 2014/02/12 17:30 |
| 3 | 8888888 | 01.00 | 2014/02/12 17:30 |
| 2 | 7777777 | 01.00 | 2014/02/12 17:30 |
| 1 | 6666666 | 01.00 | 2014/02/12 17:30 |

(6) [XXXXXXXXXX]

Figure 6-25

Description of event log

| No. | Items | Contents | | |
|--|--|---|--|---|
| (1) | System version | | | |
| (2) | System date | | | |
| (3) | Engine firmware version | | | |
| (4) | Engine boot version | | | |
| (5) | Operation panel firmware version | | | |
| (6) | Machine serial number | | | |
| (7) | Paper Jam Log | # | Count. | Event |
| | | 1 to 16 are recorded. If the past paper jam occurrence is less than 16, all of them are indicated. The oldest log is deleted when exceeding 16 events. | The total page count at the time of a paper jam. | Log code (5 types in hexadecimal) (a) Cause of paper jam (b) Paper source (c) Paper size (d) Paper type (e) Paper eject |
| | | Detail of Cause of paper jam (Hexadecimal) | | |
| | | : Refer to "17-1 Paper Misfeed Detection" (See page 7-1),for the detail of Cause of paper jam. (See page 7-2) | | |
| | | (b) Detail of paper source (Hexadecimal) | | |
| | | 00: MP tray 01: Cassette 1 02: Cassette 2 (paper feeder) 03: Cassette 3 (paper feeder) 04: Cassette 4 (paper feeder) 05 to 09: Reserved | | |
| (c) Detail of paper size (Hexadecimal) | | | | |
| 00: Not specified 01: Monarch 02: Business 03: International DL 04: International C5 05: Executive 06: Letter-R 06: Letter-E 07: Legal 08: A4R 88: A4E 09: B5R 89: B5E 0A: A3 | 0B: B4 0C: Ledger 0D: A5R 0E: A6 0F: B6 10: Commercial #9 11: Commercial #6 12: ISO B5 13: Custom size 1E: C4 1F: Hagaki 20: Oufuku Hagaki 21: Oficio II | 22: Special 1 23: Special 2 24: A3 Wide 25: Ledger Wide 26: Full bleed paper (12 x 8) 27: 8K 28: 16K-R A8: 16K-E 32: Statement-R B2: Statement-E 33: Folio 34: Youkei type 2 35: Youkei type 4 | | |

| No. | Items | Contents | | |
|----------------------------|------------------|---|---|--|
| (7) cont. | Paper Jam Log | (d) Detail of paper type (Hexadecimal) | | |
| | | 01: Plain 02: Transparency 03: Preprinted 04: Labels 05: Bond 06: Recycled 07: Vellum 08: Rough 09: Letterhead | 0A: Color 0B: Prepunched 0C: Envelope 0D: Cardstock 0E: Coated 0F: 2nd side 10: Media 16 11: High quality | 15: Custom 1 16: Custom 2 17: Custom 3 18: Custom 4 19: Custom 5 1A: Custom 6 1B: Custom 7 1C: Custom 8 |
| (8) | Service Call Log | # | Count. | Service Code |
| | | Remembers 1 to 8 th of occurrence of self diagnostics error. If the occurrence of the previous self-diagnostic error is 8 or less, all of the diagnostics errors are logged. | The total page count at the time of the self diagnostic error. | Self diagnostic error code (See page 7-23) Example: 01.6000 01: Self diagnostic error6000: Self diagnostic error code number |
| (9) | Maintenance Log | # | Count. | item |
| | | Remembers 1 to 8 of occurrence of unknown toner detection. If the occurrence of the previous unknown toner detection is less than 8, all of the unknown toner detection are logged. | Total page count at the time of the replacement of the maintenance item. The toner replacement log is triggered by toner empty. This record may contain such a reference as the toner container is inserted twice or a used toner container is inserted. | Maintenance item code (1-byte value to indicate 2 items) First byte (Replacing item) 01: Toner container Second 1 byte (replacement item type) 00: Black 01: Cyan 02: Magenta 03: Yellow First byte (Replacing item) 02: Maintenance kit Second 1 byte (replacement item type) 01: MK-5195A (30ppm model) 02: MK-5195B (30ppm model) 01: MK-5205A (35ppm model) 02: MK-5205B (35ppm model) 01: MK-5215A (40ppm model) 02: MK-5215B (40ppm model) |

| No. | Items | Contents | | |
|------|---|---|--|---|
| (10) | Unknown Toner Log | # | Count. | item |
| | | Remembers 1 to 5 of occurrence of unknown toner detection. If the occurrence of the previous unknown toner detection is less than 5, all of the unknown toner detection are logged. | The total page count at the time of the request of toner container replacement, when using the non-genuine toner container. | Unknown toner log code (1 byte, 2 categories) First byte (Replacing item) 01: Toner container (Fixed to 01) Second byte (Type of replacing item) 00: Black 01: Cyan 02: Magenta 03: Yellow |
| (11) | Counter Log Consist of three log counters of paper jams, self diagnostics errors, and maintenance replacement items. | (f) Paper jam | (g) Self diagnostic error | (h) Replacement for maintenance Items |
| | | Indicates the log counter of paper jams depending on location. Refer to Paper Jam Log. All instances including those not having occurred are displayed. | Indicates the log counter of self diagnostics errors depending on cause. Example: C6000: 004 Self diagnostic error 6000 has happened four times. | Indicates the log counter depending on the maintenance replacing item. T: Toner container 00: Black 01: Cyan 02: Magenta 03: Yellow M: Maintenance kit 01: MK-5195A (30ppm model) 02: MK-5195B (30ppm model) 01: MK-5205A (35ppm model) 02: MK-5205B (35ppm model) 01: MK-5215A (40ppm model) 02: MK-5215B (40ppm model) Example: T00: 1 The toner container (Black) has been replaced once. The toner replacement log is triggered by toner empty. This record may contain such a reference as the toner container is inserted twice or a used toner container is inserted. |

Detail of service status page

Service Status Page

MFP (2) 2014/10/30 15:15
 TASKalfa 406ci (3) (4) (5)
 (1) Firmware Version 2R6_2000.000.0002014.10.30 [XXXXXXXX] [XXXXXXXX] [XXXXXXXX]

| | | | |
|---|---------------------------------|---------------------------------|---------------|
| Controller Information | | FAX Information | |
| Memory status | | (36) Rings (Normal) | 3 |
| Standard Size | 1.0 GB | (37) Rings (FAX/TEL) | 3 |
| Option Slot | 1.0 GB | (38) Rings (TAD) | 3 |
| (7) Total Size | 2.0 GB | (39) Option DIMM Size | 16MB |
| Time | | (40) FRPO Status | |
| (8) Local Time Zone | +01:00_Tokyo | User Top Margin | A1+A2/100 0.0 |
| (9) Date and Time | 10/30/2014 02:33 | User Left Margin | A3+A4/100 0.0 |
| (10) Time Server | 10.183.53.13 | | |
| Installed Options | | | |
| (11) Paper Feeder2 | Installed | | |
| (12) Paper Feeder3 | Cassette(500x2) | | |
| (13) HDD | Installed | | |
| (14) SD Card | Not Installed | | |
| (15) SSD | Not Installed | | |
| (16) Finisher | 1000-Finisher | | |
| (17) Mail box | Not Installed | | |
| (18) Job separator | Not Installed | | |
| (19) Card Authentication Kit (B) | Installed | | |
| (20) Internet FAX Kit (A) | Installed | | |
| (21) Security Kit (E) | Not Installed | | |
| (22) Security Kit (F) | Not Installed | | |
| (23) UG-33 | Installed | | |
| (24) UG-34 | Installed | | |
| (25) USB Keyboard | Installed | | |
| (26) USB Keyboard Type | US-English | | |
| (27) Scan extension kit(A) | Not Installed | | |
| Print Settings | | | |
| (28) MP Tray Priority | Auto Feed | e-MPS error control | Y6 0 |
| (29) Print Coverage | | RP Code | |
| Average(%) / Usage Page(A4/Letter Conversion) | | (41) 1234 5678 9012 | |
| (30) Total | | (42) 5678 9012 3456 | |
| K: 1.10 | / 1111111.11 | (43) 9012 3456 7890 | |
| C: 2.20 | / 2222222.22 | (44) 3456 7890 1234 | |
| M: 3.30 | / 3333333.33 | | |
| Y: 4.40 | / 4444444.44 | | |
| (31) Copy | | (45) Altitude Adjustment | |
| K: 1.10 | / 1111111.11 | Status | Normal |
| C: 2.20 | / 2222222.22 | | |
| M: 3.30 | / 3333333.33 | | |
| Y: 4.40 | / 4444444.44 | | |
| (32) Printer | | | |
| K: 1.10 | / 1111111.11 | | |
| C: 2.20 | / 2222222.22 | | |
| M: 3.30 | / 3333333.33 | | |
| Y: 4.40 | / 4444444.44 | | |
| (33) FAX | | | |
| K: 1.10 | / 1111111.11 | | |
| (34) Period | (27/10/2010 - 03/11/2010 08:40) | | |
| (35) Last Page K/C/M/Y(%) | 1.00 / 2.22 / 3.33 / 4.44 | | |

1 (6) [XXXXXXXXXX]

Figure 6-26

Service Status Page

MFP

2014/10/30 15:15

TASKalfa 406ci

Firmware Version 2R6_2000.000.000

[XXXXXXXX] [XXXXXXXX] [XXXXXXXX]

Engine Information

(46) NVRAM Version _CI04709_CI04709
 (47) FAX Slot1 2NM_1200.001.089
 FAX BOOT Version 2NM_5000.001.006
 FAX APL Version 2NM_5100.004.001
 FAX IPL Version 2NM_5200.001.006
 (48) MAC Address 00:C0:EE:D0:01:0D

Send Information

(49) Date and Time 14/03/05 15:30
 (50) Address mail@bjd.ne.jp

1/2 (51) (52)
 (53) 100/100
 (54) 0/0/0/0/
 (55) 0000000/0000000/0000000/0000000/0000000/0000000/0000000/
 0000000/0000000/0000000/0000000/0000000/0000000/0000000/0000000/0000000/0000000/
 F00/U00/0/0/0/0/0/30/30/70/70/abcde/1/0/1/ (56) (57) (58) (59) (60) (61) (62) (63) (64) (65) (66) (67) (68) (69) (70)
 (71) 0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/
 0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/
 (72) 0000/0100/0500/1000/0000/0100/0500/1000/0000/0100/0500/1000/0000/0100/0500/1000/
 0000/0100/0500/1000/0000/0100/0500/1000/0000/0100/0500/1000/0000/0100/0500/1000/
 (73) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000000000/
 (74) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000
 (75) 0000000000000000/0000000000000000/0000000000000000/
 (76) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 (77) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000/
 (78) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000/
 (79) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000/
 (80) 0000000000000000/0000000000000000/0000000000000000/
 (81) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000/
 (82) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000/
 (83) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000/
 (84) 0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/0000000000000000/
 0000000000/
 (85) 12345678/11223344/00001234abcd567800001234abcd5678/012345678901234567890123456789012345678901/0008/00/07
 12345678/11223344/00001234abcd567800001234abcd5678/012345678901234567890123456789012345678901/0008/00/07
 12345678/11223344/00001234abcd567800001234abcd5678/012345678901234567890123456789012345678901/0008/00/07
 12345678/11223344/00001234abcd567800001234abcd5678/012345678901234567890123456789012345678901/0008/00/07
 (86) XXXXXXXX/
 (87) [ABCDEFGHJIJ][ABCDEFGHJIJ]
 [ABCDEFGHJIJ][ABCDEFGHJIJ] (88) (89)
 [ABCDEFGHJIJ][ABCDEFGHJIJ] (90) (91)
 (92) 00070107FE/0700FE00FE/00FE000100/0000000000/0000000000/0000000000/00000A010A/0A0A0A3200/0000000000/0000000000/
 0008000000/080000001D/0096009B00/9B009BFFFB/0082000000/000000001F/0000002C00/0000000000/0000000000/
 (93) 3/
 0/0/12.3/56.7 (94) (95) (96) (97)
 (98) 1/1/1/0/1/0/0/ 2010/12/15 12:34:56
 1/5/ (99)(100)
 1/1/ (101) (102)
 (103) 1/
 (104) ABCDEFGHIJKL/ABCDEFGHIJKL/ABCDEFGHIJKL/ABCDEFGHIJKL/ABCDEFGHIJKL/
 (105) ABCDEFGHIJKL/ABCDEFGHIJKL/ABCDEFGHIJKL/ABCDEFGHIJKL/ABCDEFGHIJKL/

Figure 6-27

| No. | Items | Contents |
|------|--|--|
| (1) | Firmware Version | - |
| (2) | System date | - |
| (3) | Engine firmware version | - |
| (4) | Engine boot version | - |
| (5) | Operation panel firmware version | - |
| (6) | Machine serial number | - |
| (7) | Total memory size | - |
| (8) | Local time zone | - |
| (9) | Report output date | Day/Month/Year hour : minute |
| (10) | NTP server name | - |
| (11) | Availability of the paper feed unit 2 | Installed/Not Installed |
| (12) | Availability of the paper feed unit 3 | Cassette(500-sheet×2) / Cassette(2000-sheet) / Not Installed |
| (13) | Availability of the optional HDD | Installed/Not Installed |
| (14) | Availability of the SD memory card | Installed/Not Installed |
| (15) | Availability of the SSD | Installed/Not Installed |
| (16) | Availability of the finisher | 1000-sheet finisher/inner finisher/ 3000-sheet finisher/not installed |
| (17) | Availability of Mailbox | Installed/Not Installed |
| (18) | Availability of job separator | Installed/Not Installed |
| (19) | Availability of the ID Card Authentication Kit | Introduced/ before introduction/trial |
| (20) | Availability of the Internet FAX Kit(A) | Introduced/ before introduction (not indicated for 30ppm model) |
| (21) | Availability of the Security Kit(E) | Installed/Not Installed |
| (22) | Availability of the Security Kit(F) | Introduced/ before introduction (not indicated for 30ppm model) |
| (23) | Availability of UG-33 | Introduced/ before introduction/trial |
| (24) | Availability of UG-34 | Introduced/ before introduction (not indicated for 30ppm model) |
| (25) | USB keyboard connection status | Connected/Not connected |
| (26) | Type of the USB keyboard | US-English/US-English with Euro symbol/German France |
| (27) | Availability of the Scan extension kit(A) | Introduced/ before introduction/trial (not indicated for 30ppm model) |
| (28) | MP tray priority setting | Off/Auto/Always |
| (29) | Page count converted to the A4/Letter size | Print Coverage provides a close-matching reference of toner consumption and will not match the actual toner consumption. |

| No. | Items | Contents |
|------|--|--|
| (30) | Entire average coverage | Black/Cyan/Magenta/Yellow |
| (31) | Average coverage for copy | Black/Cyan/Magenta/Yellow |
| (32) | Average printer coverage | Black/Cyan/Magenta/Yellow |
| (33) | Average coverage for FAX | Black/Cyan/Magenta/Yellow |
| (34) | Cleared date and output date | - |
| (35) | Coverage on the last output page | - |
| (36) | Number of rings | 0 to 15 |
| (37) | Number of rings before automatic switching | 0 to 15 |
| (38) | Number of rings before connecting to the answering machine | 0 to 15 |
| (39) | Optional DIMM size | - |
| (40) | FRPO setting | - |
| (41) | RP code | Coding the engine firmware version and the date of the previous update. |
| (42) | RP code | Code the main software version and the date of the latest update. |
| (43) | RP code | Coding the engine firmware version and the date of the previous update. |
| (44) | RP code | Code the main software version and the date of the previous update. |
| (45) | High altitude adjustment set data | Normal/1001-2000m/2001-3000m/3001-3500m |
| (46) | NVRAM version | _ 1F3 1225 _ 1F3 1225 (a)(b)(c)(d)(e)(f) (a) Consistency of the current firmware version and the database _ (underscore): OK * (Asterisk): NG (b) Database version (c) The oldest time stamp of database version (d) Consistency of the present software version and the ME firmware version _ (underscore): OK * (Asterisk): NG (e) ME firmware version (f) The oldest time stamp of the ME firmware version Normal if (a) and (d) are underscored, and (b) and (e) are identical with (c) and (f). |
| (47) | FAX firmware version | - |
| (48) | Mac address | - |
| (49) | The last sent date and time | - |
| (50) | Transmission address | - |
| (51) | Destination information | - |

| No. | Items | Contents |
|------|--|---|
| (52) | Area information | - |
| (53) | Margin setting | Top margin/Left margin |
| (54) | L parameters | Top margin integer part/Top margin decimal part/Left margin integer part /Left margin decimal part |
| (55) | Life counter (cassette 1) | Machine life/MP tray/Cassette/Paper feeder 1/Paper feeder 2/Paper feeder 3/Duplex |
| | Life counter (cassette 2) | Drum unit K/Drum unit C/Drum unit M/Drum unit Y/Primary transfer unit/Developer unit K/Developer unit C/ Developer unit M/Developer unit Y/ Maintenance kit A/Maintenance kit B |
| (56) | Panel lock information | F00: OFF F01: Partial lock1 F02: Partial lock2 F03: Partial lock3 F04: Full lock |
| (57) | USB information | U00: Not Connected U01: Full speed U02: Hi speed |
| (58) | Paper handling information | 0: Paper source select 1: Paper source fixed |
| (59) | Auto cassette change | 0: OFF 1: ON (Default) |
| (60) | Color printing double count mode | 0: All single counts 3: Folio (Less than 330 mm length), Single counts |
| (61) | Black and white printing double count mode | 0: All single counts 3: Folio (Less than 330 mm length), Single counts |
| (62) | Billing counts timing | 0: When secondary paper feed starts 1: When the paper is ejected |
| (63) | Temperature (machine inside) | - |
| (64) | Temperature (machine outside) | - |
| (65) | Relative humidity (machine outside) | - |
| (66) | Absolute humidity (machine outside) | - |
| (67) | Asset Number | - |
| (68) | Job end judgment time-out time | - |
| (69) | Job end detection mode | 0: Detects as one job, even if contained multiple jobs 1: Detects as individual job, dividing multiple jobs at a break in job |
| (70) | Prescribe environment reset | 0: Off 1: On |

| No. | Items | Contents |
|------|--|---|
| (71) | Media type attributes 1 to 28 (Not used: 18, 19, 20) *: For details on settings, refer to MDAT command in "Prescribe Commands Reference Manual". | Weight settings Fuser settings 0: Light 0: High 1: Normal 1 1: Middle 2: Normal 2 2: Low 3: Normal 3 3: Vellum 4: Heavy 1 5: Heavy 2 Duplex settings 6: Heavy 3 0: Disable 7: Extra Heavy 1: Enable |
| (72) | IO Calibration information | K/C/M/Y |
| (73) | Bias Calibration information | - |
| (74) | Sensor initial information | - |
| (75) | Calibration information | - |
| (76) | Calibration information | - |
| (77) | Calibration information | - |
| (78) | Calibration information | - |
| (79) | Calibration information | - |
| (80) | Paper loop correction shift amount | - |
| (81) | Paper loop correction interval | - |
| (82) | Paper loop correction patch amount | - |
| (83) | Calibration information | - |
| (84) | Calibration information | - |
| (85) | RFID information (K,C,M,Y) | - |
| (86) | RFID reader/writer version | - |
| (87) | Optional paper feeder firmware version | - |
| (88) | Color table version for printer | - |
| (89) | Color table 2 version for printer | - |
| (90) | Color table version for copy | - |
| (91) | Color table 2 version for copy | - |
| (92) | Maintenance information | - |
| (93) | MC correction | 1 to 7 |
| (94) | Configuring the toner coverage counters | 0: Full-color count display 1: Color coverage count display |
| (95) | Low coverage setting | 0.1 to 100.0 |
| (96) | Middle coverage setting | 0.1 to 100.0 |
| (97) | Data sanitization information | FAX Board/Main Memory/Panel Memory/SSD/Executed time 1: Success 0: Fail - : Not performed or Not installed |

| No. | Items | Contents | | | | | | | | | | | | | | | | | | | | |
|--|-----------------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| (98) | Toner low setting | 0: Disabled 1: Enabled | | | | | | | | | | | | | | | | | | | | |
| (99) | Toner low detection level | 0 to 100 (%) | | | | | | | | | | | | | | | | | | | | |
| (100) | Full-page print mode | 0: Normal mode (Factory setting) 1: Full-page mode | | | | | | | | | | | | | | | | | | | | |
| (101) | Wake-up mode | 0: Off (Don't wake up) 1: On (Do wake up) | | | | | | | | | | | | | | | | | | | | |
| (102) | Wake-up timer | Displays the wake-up time | | | | | | | | | | | | | | | | | | | | |
| (103) | BAM conformity mode setting | 0: Non-conformity mode 1: Conformity Mode | | | | | | | | | | | | | | | | | | | | |
| (104) | Drum serial number | Black/Cyan/Magenta/yellow | | | | | | | | | | | | | | | | | | | | |
| (105) | Developer serial number | Black/Cyan/Magenta/yellow | | | | | | | | | | | | | | | | | | | | |
| <p style="text-align: center;">Code conversion</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tbody> <tr> <td>A</td><td>B</td><td>C</td><td>D</td><td>E</td><td>F</td><td>G</td><td>H</td><td>I</td><td>J</td> </tr> <tr> <td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td> </tr> </tbody> </table> | | | A | B | C | D | E | F | G | H | I | J | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
| A | B | C | D | E | F | G | H | I | J | | | | | | | | | | | | | |
| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | | | | | | | | | | | | | |

| | |
|-------------|--|
| U001 | Exiting the maintenance mode (Message: Exit Maintenance Mode) |
|-------------|--|

Contents

Exits the maintenance mode and returns to the normal copy mode.

Purpose

Exit the maintenance mode.

Method

- 1.Press the [Start] key.
- 2.The normal copy mode is entered.

| | |
|-------------|---|
| U002 | Set Factory Default (Message: Set Factory Default) |
|-------------|---|

Contents

Sets the machine initial setting values to the factory default.

Purpose

Executes the machine initial settings when shipping from factory.

Method

- 1.Press the [Start] key.
- 2.Select [Mode1(All)].
- 3.Press the [Start] key.

| Items | Contents |
|-------------------|---|
| Mode1(All) | Sets the machine initial setting values to the factory default. |

- 4.Turn the power switch off.

* :An error code is displayed in case of the initialization error.

When errors occur, turn the power switch off then on, and execute initialization using maintenance mode U002.

Wait more than 5 seconds between the power off and on.

Error codes

| Codes | Contents |
|--------------|----------------------------|
| 0001 | Controller (Entity error) |
| 0002 | Controller (Counter error) |
| 0003 | Controller (OS error) |
| 0020 | Engine error |

| | |
|-------------|--|
| U003 | Setting the telephone number of the service person (Message: Set Telephone Number for Service Call) |
|-------------|--|

Contents

Sets the phone number indicated at the service call error.

Purpose

Execute to set the service telephone number at the installation of the machine.

Setting

1. Press the [Start] key.
 - * :Input keys are indicated on the touch panel.
2. Input telephone number (15 digits maximum).
3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U004 | Machine serial number (Message: Machine Number) |
|-------------|--|

Contents

Sets or displays the machine serial number.

Purpose

Checks the machine serial number

After the main/engine PWB replacement, execute if the "C0180 machine number mismatch" occurs.

Method

1. Press the [Start] key.

When the machine serial number in the engine PWB matches the one in the main PWB,

| Items | Contents |
|-------------------------|-------------------------------------|
| Machine No.(Eng) | Displays the machine serial number. |

When the machine serial number in the engine PWB does not match the one in the main PWB,

| Items | Contents |
|--------------------------|---|
| Machine No.(Main) | Displays the machine serial number in the main PWB. |
| Machine No.(Eng) | Displays the machine serial number in the engine PWB. |

Setting

Execute if the serial numbers do not match.

1. Select [Execute].
2. Press the [Start] key.
 - * :The serial number writing starts.
3. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U010 | Setting the maintenance mode ID (Message: Set Maintenance Mode ID) |
|-------------|---|

Contents

Change the maintenance mode ID for service.

Purpose

Modify maintenance mode ID for service for more security.

Method

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|--------------------------|--|
| New ID | Enter a new 8-digit maintenance ID |
| New ID(Reconfirm) | Enter a new 8-digit maintenance ID (to confirm) |
| Initialize | Initializes the maintenance mode ID for service. |

Setting: New ID

1. Select [New ID].
2. Press ten keys (0–9, *, #) to enter a new 8-digit ID.
* : Either [*] or [#] must be included.
3. Press the [Start] key to set the setting value.
4. Select [New ID(Reconfirm)].
5. Press ten keys (0–9, *, #) to re-enter the new 8-digit ID.
6. Press the [Start] key to set the setting value.

Method: Initialize

1. Select [Initialize].
2. Press the [Start] key to initialize the maintenance mode ID.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

Error codes

| Codes | Contents |
|--------------|--------------------------------------|
| 0001 | Do not include "#" or "*" in the ID. |
| 0002 | ID does not match. |
| 0003 | 8-digit ID is not input |

| | |
|-------------|--|
| U018 | Firmware self verification (Message: Check Firmware Checksum) |
|-------------|--|

Contents

Verifies that the firmware is not falsified³.

Purpose

Re-calculate the checksum to verify the firmware is not falsified.

Method

1.Press the [Start] key.

| Items | Contents |
|-----------------|--------------------------------------|
| Expected | Displays the checksum expected value |
| Result | Displays the checksum calculation |
| Execute | Execute self-verification |

2.Select [Execute].

3.Press the [Start] key.

After execution, display the checksum obtained in the [Expected].

The following appears if the verification result is illegal.

| Items | Contents |
|--------------|--|
| f001 | The expected value file does not exist |
| f002 | Expected value file read failure |
| f003 | Illegal data of the expected value file (not 64-byte data) |
| s001 | Fails to obtain the checksum |
| NG | Expected value and checksum are different |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U019 | Firmware Version (Message: Firmware Version) |
|-------------|---|

Contents

Displays the firmware version installed in each PWB.

Purpose

Check the firmware version installed in each PWB

Method

1. Press the [Start] key.

* :The firmware version is displayed.

2. Change the screen using the [Up/Down cursor] key.

| Items | Contents |
|---------------------------------|----------------------------------|
| Main | Main firmware |
| MMI | Operation firmware |
| Panel Main | Panel firmware |
| Panel Boot | Panel Boot |
| Browser | Browser firmware |
| Engine | Engine firmware |
| Engine Boot | Engine boot |
| RFID | RFID |
| Energy-saving Micom | Energy-saving Micom firmware |
| Energy-saving Micom Boot | Energy-saving Micom boot |
| Dictionary | Dictionary firmware |
| Option Language | Optional language firmware |
| OCR | OCR dictionary firmware |
| HyPAS Embedded API | HyPAS Embedded API Software |
| Color Table1(Copy) | Color table 1 firmware (copy) |
| Color Table2(Copy) | Color table 2 firmware (copy) |
| Color Table2(Prn) | Color table 1 firmware (printer) |
| Color Table2(Prn) | Color table 2 firmware (printer) |
| PF1 | Paper feeder 1 firmware |
| PF1 Boot | Paper Feeder 1 boot |
| PF2 | Paper feeder 2 firmware |
| PF2 Boot | Paper Feeder 2 boot |
| DF | finisher firmware |
| DF Boot | finisher boot |
| PH | Punch firmware |
| PH Boot | Punch Boot |
| MT | mailbox Firmware |

| Items | Contents |
|----------------------------|-------------------------|
| MT Boot | mailbox boot |
| Fax APL1 | Fax APL1 |
| Fax Boot1 | FAX Boot1 |
| Fax IPL1 | Fax IPL1 |
| Fax APL2 | Fax APL2 |
| Fax Boot2 | FAX Boot2 |
| Fax IPL2 | Fax IPL2 |
| Application Name 01 | Application 1 software |
| Application Name 02 | Application 2 software |
| Application Name 03 | Application 3 software |
| Application Name 04 | Application 4 software |
| Application Name 05 | Application 5 software |
| Application Name 06 | Application 6 software |
| Application Name 07 | Application 7 software |
| Application Name 08 | Application 8 software |
| Application Name 09 | Application 9 software |
| Application Name 10 | Application 10 software |
| Application Name 11 | Application 11 software |
| Application Name 12 | Application 12 software |
| Application Name 13 | Application 13 software |
| Application Name 14 | Application 14 software |
| Application Name 15 | Application 15 software |
| Application Name 16 | Application 16 software |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U021 | Initializes Memory (Message: Initialize Memory) |
|-------------|--|

Contents

Initializes all settings, except those pertinent to the type of machine, namely each counter, service call error history and mode setting. Also, initializes the backup RAM according to the area specification selected in the maintenance mode U252 (Setting the destination).

Purpose

Initialize the backup data except machine settings to the factory default in the field

Method

1. Press the [Start] key.
2. Select [Execute].

| Items | Contents |
|----------------|---|
| Execute | Initialize data according to the destination information. |

3. Press the [Start] key.

* :All data other than for adjustments is initialized by the destination setting.

4. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

* :An error code is displayed in case of the initialization error.

When errors occur, turn the power switch off then on, and execute initialization using maintenance mode U021.

Error codes

| Items | Contents |
|-------------|----------------------------|
| 0001 | Controller (Entity error) |
| 0002 | Controller (Counter error) |
| 0020 | Engine error |
| 0040 | Scanner error |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U024 | Formatting an HDD (Message: Format HDD) |
|-------------|--|

Contents

Initialize the HDD.

Purpose

Initialize the HDD when replacing the HDD in the field.

Precautions

The following settings are initialized if the HDD is initialized.

System Menu (User Management, Job Accounting, Address Book, One Touch Key, Document Box, etc.). Shortcut key, Panel program.

If executing full-format, the following installed software is deleted.

Optional language, HyPAS application (FMU, etc.), OCR dictionary software, color table.

Method

1.Press the [Start] key.

2.Select [Format].

| Items | Contents |
|---------------|--------------------------|
| Format | Executing the HDD format |

3.Select the item to execute.

| Items | Contents |
|-------------|--|
| Full | Full format |
| Data | Data format (save in the application software) |

4.Select [Execute].

| Items | Contents |
|---------------|------------------|
| Excute | Starts operation |

5.Press the [Start] key to execute the initialization.

6.Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

* :Manually reinstall deleted software.

Optional language, OCR dictionary software, (OCRDATA): Install using a USB memory.

Install the HyPAS application (FMU, etc.) from the Application screen.

Color table: Execute U485

* :If there is no OCR dictionary software, a warning dialog is displayed, and the OCR function is unavailable.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U025 | Firmware update (S) (Message: Firm Update(Security)) |
|-------------|---|

Contents

Executes Firmware-Update from the USB memory while "Very High" is selected in the Security Level settings under the System Menu.

Supplement

Initiate the firmware upgrade by a service person by executing U025 while a USB memory is inserted

Method

- 1.Press the [Start] key.
- 2.Select [Execute].

| Items | Contents |
|----------------|----------------------|
| Execute | Updates the firmware |

- 3.Press the [Start] key.

* :This is not executable when a USB memory is not installed.

- 4.After normal completion, turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U026 | Retrieve the backup data (Message: Pulling Backup Data) |
|-------------|--|

Contents

Execute to retrieve backup data after replacing the main PWB.

Purpose

Restores the setting values backup from the HDD to the flash memory on the main PWB.

Method

- 1.Press the [Start] key.
- 2.Select [Execute].

| Items | Contents |
|----------------|----------------------|
| Execute | Updates the firmware |

- 3.Press the [Start] key.

- 4.Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

* :Indicates "NG" when completing abnormally.

Saved data:

U278 Delivery date setting

U402 margin adjustment

U952 Maintenance workflow data

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U030 | Motor operation check (Message: Check Motor Operation) |
|-------------|---|

Contents

Drive each motor.

Contents

Execute to check each motor's operation.

Method

1. Press the [Start] key.
2. Select the motor to operate.
3. Press the [Start] key.

* :Each operation starts.

| Items | Contents |
|----------------------|-----------------------------|
| Feed | Operate the imaging motor. |
| DLP(CMY) | Operate the DLP (CMY) motor |
| Fuser | Operate the fuser motor |
| SB(CW) | Drive the SB(CW) motor |
| SB(CCW) | Drive the SB(CCW) motor |
| Belt Release | Operate the bridge motor |
| Bridge | Operate the belt release |
| Fuser Release | Operate the fuser release |

* :To stop the operation, press the [Stop] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U031 | Check the conveying switch (Message: Check Conveying Switch) |
|-------------|---|

Contents

Displays the on/off status of each switch and sensor to detect paper on the paper conveying path.

Purpose

Execute to check the conveying switches and sensors are operating correctly.

Method

1. Press the [Start] key.
2. Check the switches and sensors by manually turning them on/off.
3. The switch indication is inverted when the switch is detected.

| Items | Contents |
|---------------------|---|
| Regist Sens | Display the regist sens switch state |
| Fuser | Displays the fuser switch status |
| DU Sens | Display the DU sens switch state |
| Bridge1 Feed | Displays the bridge 1 feed switch state |
| Bridge2 Feed | Displays the bridge 2 feed switch state |
| Exit Full | Display the exit full switch state |
| JobSepa Full | Display the job separator full switch state |
| JobSepa | Display the job separator switch state |
| Feed2 | Displays the cassette2 feed switch state |
| Feed3 | Displays the cassette3 feed switch state |
| Feed4 | Displays the cassette4 feed switch state |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U032 | Clutch operation check (Message:Check Clutch Operation) |
|-------------|--|

Contents

Supply power to each clutch.

Purpose

Execute to check each clutch's operation.

Method

- 1.Press the [Start] key.
- 2.Select the clutch to operate.
- 3.Press the [Start] key.

* :Each operation starts.

| Items | Contents |
|-------------------|-------------------------------------|
| DLP | Operates the developer clutch (BK). |
| Regist | Operate the registration clutch |
| Mid Roller | Operates the middle clutch |
| Duplex | Operate the duplex clutch |
| Feed1 | Operates the paper feed clutch |
| Motor | Operate the motor |

* :The clutch operation is available while the motor is operated.

- 4.To stop the clutch drive, press the [Stop] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U033 | Solenoid operation check (Message: Check Solenoid Operation) |
|-------------|---|

Contents

Supply power to each solenoid.

Purpose

Execute to check each solenoid's operation.

Method

1. Press the [Start] key.
2. Select the solenoid to operate.
3. Press the [Start] key.
 - * :Each operation starts.
 - * :Select the motor before checking the motor rotation.

| Items | Contents |
|--------------------|----------------------------------|
| Branch Exit | Operate the feed-shift solenoid. |
| MPT | Operate the MP solenoid |
| Motor | Operate the motor |

* :The solenoid operation is available while the motor is operated.

4. To stop the operation of the solenoid, press the [Stop] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U034 | Paper timing adjustment (Message: Adjust Paper Timing Data) |
|-------------|--|

Contents

Adjust the leading edge registration or center line.

Purpose

Executed if there is a regular error between the leading edges of the copy image and original.
Adjusted if there is a regular error between the center lines of the copy image and original.

Method

1. Press the [Start] key.
 2. Select the item to adjust.
- * :The screen for adjusting is displayed.

| Items | Contents |
|-------------------------|---|
| LSU Out Top Full | Adjust the leading edge registration (full speed) |
| LSU Out Top 3/4 | Adjust the leading edge registration (3/4 speed) |
| LSU Out Top Half | Adjust the leading edge registration (half speed) |
| LSU Out Left | Adjusts the center line |

Adjust: LSU Out Top Full/LSU Out Top 3/4/LSU Out Top Half

1. Select the item to adjust.
2. Press the [System Menu] key.
3. Press the [Start] key to output a test pattern.
4. Press the [System Menu] key.

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------|---|---------------|-----------------|----------------|
| MPT | Adjust the leading edge timing for the MP tray | -3.0 to 3.0 | 0 | 0.1mm |
| Cassette | Adjusts the leading edge timing for cassette feed | -3.0 to 3.0 | 0 | 0.1mm |
| PF*1 | Adjust the leading edge timing for the paper feeder | -3.0 to 3.0 | 0 | 0.1mm |
| Duplex | Adjusting the leading edge timing when duplex copying | -3.0 to 3.0 | 0 | 0.1mm |

*1: 500 x 1 cassette only

5. By using the [+] [-] keys or the numeric keys, change the setting value.
For the test pattern 1, increase the value.
For the test pattern 2, decrease the value.

* :When the setting value is increased, the image moves backward, and it moves forward when the setting value is decreased.




Figure 6-28

6. Press the [Start] key to set the setting value.

Precautions

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034 > U066 (P.6-240) > U071 (P.6-244)

Adjustment: LSU Out Left

1. Select the item to adjust.
2. Press the [System Menu] key.
3. Press the [Start] key to output a test pattern.
4. Press the [System Menu] key.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------------|--|---------------|-----------------|----------------|
| MPT | Adjust the center line for the MP tray | -3.0 to 3.0 | 0 | 0.1mm |
| Cassette1 | Adjust the center line for cassette 1 feed | -3.0 to 3.0 | 0 | 0.1mm |
| Cassette2 | Adjust the center line for cassette 2 (Optional unit) feed | -3.0 to 3.0 | 0 | 0.1mm |
| Cassette3 | Adjust the center line for cassette 3 (Optional unit) feed | -3.0 to 3.0 | 0 | 0.1mm |
| Cassette4 | Adjust the center line for cassette 4 (Optional unit) feed | -3.0 to 3.0 | 0 | 0.1mm |
| Duplex | Adjusting the center line when duplex copying (Back page) | -3.0 to 3.0 | 0 | 0.1mm |

5. By using the [+] [-] keys or the numeric keys, change the setting value.

For the test pattern 1, increase the value.

For the test pattern 2, decrease the value.

* :When the setting value is increased, the image moves to right, and it moves to left when the setting value is decreased.




Figure 6-29

6. Press the [Start] key to set the setting value.

Precautions

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034 < U067(P.6-241) < U072(P.6-246)

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U035 | Folio size setting (Message: Adjust Folio Size) |
|-------------|---|

Contents

Changes the printable area when copying with Folio paper.

Purpose

Setting the actual size of Folio to use prevents the image dropout at the trailing edge or right/left edges.

Method

1. Press the [Start] key.
2. Select the item to set.
3. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|---------------|------------------------------|-----------------|-----------------|----------------|
| Length | Sets the Folio paper length. | 318 to 356 (mm) | 330 | 1(mm) |
| Width | Sets the Folio paper width. | 200 to 216 (mm) | 210 | 1(mm) |

4. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U037 | Fan motor operation check (Message: Check Fan Motor Operation) |
|-------------|---|

Contents

Drive each fan motor.

Contents

Execute to check each fan motor's operation.

Method

1. Press the [Start] key.
2. Select the fan motor to operate.
3. Press the [Start] key.

* :Each operation starts.

| Items | Contents |
|---------------------|-----------------------------------|
| All | Operate all the fan motors |
| DLP | Operate the developer fan motor 1 |
| Exit Paper | Connected to the exit fan motor |
| Exit Cooling | Operate the exit fan motor |
| LVU CL Fan | Operate the developer fan motor 2 |
| WTNR Fan | Operates the toner suction motor |
| CON Fan | Operate the Controller fan motor |

* :To stop the operation, press the [Stop] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|--|--|
| | |
|--|--|

| | |
|-------------|--|
| U051 | Registration paper loop amount adjustment (Message: Adjust Paper Loop Amount) |
|-------------|--|

Contents

Adjusts the paper loop amount.

Purpose

The leading edge of the image may drop, image position may shift irregularly or paper is folded in a Z-shape.

* :Use to check/adjust skew feed.

Method

1.Press the [Start] key.

2.Select the item to adjust.

* :The screen for adjusting is displayed.

| Items | Contents |
|-------------|--|
| Full | Paper loop amount adjustment at full speed |
| Half | Paper loop amount adjustment at half speed |
| 3/4 | Paper loop amount adjustment at 3/4 speed |

Adjustment

1.Select the item to adjust.

2.Press the [System Menu] key.

3.Place an original and press the [Start] key to make a test copy.

4.Press the [System Menu] key.

* :The screen for adjusting is displayed.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------------|---|---------------|--|----------------|
| MPT | MPT loop amount adjustment | -30 to 20 | -4/-3* ¹ -3/-2* ¹ -3 | 1mm |
| Cassette1 | Cassette 1 loop amount adjustment | -30 to 20 | -4/-3* ¹ -3/-2* ¹ -3 | 1mm |
| PF | PF (Cassette2,3,4) loop amount adjustment | -30 to 20 | 4 4/5* ¹ 4 | 1mm |
| Duplex | Duplex loop amount adjustment | -30 to 20 | -6/-5* ¹ -5/-3* ¹ -4 | 1mm |

*1: 40 ppm model

5. By using the [+] [-] keys or the numeric keys, change the setting value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the paper loop amount increase, and it decreases when the setting value is decreased.




Figure 6-30

6. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U053 | Adjusting the motor speed (Message:Adjust Motor Speed) |
|-------------|---|

Contents

Execute the motor speed fine tuning.

Purpose

No need to change the basic settings. Change the set value when an image failure occurs.

Method

- 1.Press the [Start] key.
 - 2.Select the item to adjust.
- * :The screen for adjusting is displayed.

| Items | Contents |
|-------------|--------------------|
| Full | Full speed setting |
| Half | Half speed setting |
| 3/4 | 3/4 speed setting |

Setting

- 1.Select the item to adjust.
- * :The screen for adjusting is displayed.

| Items | Contents | Setting range | Initial setting | Data variation |
|---------------------|---|---------------|-----------------|----------------|
| Drum(K) | Adjusting the drum motor(BK) | -5000 to 5000 | 0/0/0 | - |
| Drum(CMY) | Adjusting the drum motor(M/C/Y) | -5000 to 5000 | 0/0/0 | - |
| Drum Mono(K) | Adjust the drum motor (K) at the time of monochrome printing. | -5000 to 5000 | 0/0/0 | - |
| Dev(K) | Adjusting the developer motor(BK) | -5000 to 5000 | 0/0/0 | - |
| Dev(CMY) | Adjusting the developer motor(M/C/Y) | -5000 to 5000 | 0/0/0 | - |
| Fixing | Adjusting the fuser motor(FUM) | -5000 to 5000 | 0/0/0 | - |
| Trans Belt | Adjusting the transfer belt motor | -5000 to 5000 | 0/0/0 | - |
| SB | Adjusts the DP feedshift motor (DPSPM) rotation | -5000 to 5000 | 0/0/0 | - |
| SB Reverse | Adjusts the DP feedshift motor (DPSPM) reverse rotation | -5000 to 5000 | 0/0/0 | - |
| Bridge1 | Adjusting the BR conveying motor (BRCM) | -5000 to 5000 | 0/0/0 | - |
| PF2 | Adjusting the PF paper feed motor (PFPFM) | -5000 to 5000 | 0/0/0 | - |
| PF3 | Adjusting the PF paper feed motor (PFPFM) | -5000 to 5000 | 0/0/0 | - |

- 2.By using the [+] [-] keys or the numeric keys, change the setting value.
- 3.Press the [Start] key to set the setting value.

Completion

- Press the [Stop] key.
- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U059 | Fan mode setting (Message: Set Fan Mode) |
|-------------|---|

Contents

Sets the conveying fan motor drive mode during paper conveying.

Purpose

A fan is added in the conveying unit so that the leading edge of paper is conveyed along with the conveying path to prevent paper creases.

Method

1. Press the [Start] key.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------------|---------------------------------------|---------------|-----------------|----------------|
| Interval Cycle | Changes the fan control timing cycle. | 0 to 10000 | 0 | Sheet |

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U061 | Lamp lighting check (Message: Check Lamp ON) |
|-------------|---|

30/40ppm models only

Contents

Turns the exposure lamp on.

Purpose

Light the exposure lamp to confirm.

Method

1. Press the [Start] key.
2. Select the item to operate.

| Items | Contents |
|------------|--|
| CCD | Turns the exposure lamp on |
| CIS | Turn the CIS lamp on (when the simultaneous duplex scanning document processor is installed) |

3. Press the [Start] key. Lamps are lit.
- * :Press the [Stop] key to turn the lamp off.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U063 | Shading position adjustment (Message: Adjust Shading Position) |
|-------------|---|

Contents

Changes the scanner shading position.

Purpose

Execute if the vertical white lines appears on the image and they are not improved after cleaning the shading plate, namely there are scratches or dirt inside the shading plate.

By changing the shading position, shading is available where there is no influence of dirt or scratch of the shading plate.

Setting

- 1.Press the [Start] key.
- 2.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------|--------------------------------------|----------------------|------------------------|-----------------------|
| Position | Changes the scanner shading position | 0 to 18 | 0 | 0.091m m |

* :If the set value is increased, the shading position moves toward the machine left side and toward the right side if the value is reduced.

- 3.Press the [Start] key to set the setting value.

Precautions

Test copy of the original is available by pressing the [System Menu] key as interruption copy mode when executing this maintenance mode.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U065 | Adjusting the magnification for table scanning (Message: Adjust Scanner Motor Speed) |
|-------------|---|

Contents

Adjust the magnification in the main and sub scanning direction of the table scanning.

Purpose

Adjusts the magnification in the main and sub scanning direction of the table scanning if the above incorrect

Precautions

The magnification adjustment in the main scanning direction could cause black streaks depending on the content of the original document.

Adjust the magnification of the scanner in the following order.

U065(main scanning direction)(P.6-238)>U065((sub scanning direction)(P.6-238)

Method

- 1.Press the [Start] key.
- 2.Press the [System Menu] key.
- 3.Place an original and press the [Start] key to make a test copy.
- 4.Press the [System Menu] key.
- 5.Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------------|---|---------------|-----------------|----------------|
| Main Scan | Scanner magnification in the main scanning direction | -15 to 15 | 0 | 0.10% |
| Sub Scan | Adjusts scanner magnification in the sub-scanning direction | -25 to 25 | 0 | 0.10% |


Adjustment: Main Scan

- 1.By using the [+] [-] keys or the numeric keys, change the setting value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the image widens, and it narrows when the setting value is decreased.

**Figure 6-31**

- 2.Press the [Start] key to set the setting value.

Adjustment: Sub Scan

1. By using the [+] [-] keys or the numeric keys, change the setting value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the image get longer, and it shortens when the setting value is decreased.




Figure 6-32

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U066 | Adjusting the table scanning timing (Message: Adjust Table Leading Edge Timing) |
|-------------|--|

Contents

Adjusts the leading edge timing for the table scanning.

Purpose

Executed if there is a regular error between the leading edges of the copy image and original.

Adjustment

1. Press the [Start] key.
2. Press the [System Menu] key.
3. Place an original and press the [Start] key to make a test copy.
4. Press the [System Menu] key.
5. Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|---------------|--|---------------|-----------------|----------------|
| Front | Adjusts the scanner leading edge margin. | -45 to 45 | 0 | 0.085 mm |
| Rotate | Scanner leading edge registration (rotate copying) | -45 to 45 | 0 | 0.085 mm |

6. By using the [+] [-] keys or the numeric keys, change the setting value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the image moves forward, and it moves backward when the setting value is decreased.

Leading edge registration of the copy image (+1.0/-1.5 mm or less)




Figure 6-33

7. Press the [Start] key to set the setting value.

Precautions

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034 (P.6-228) > U065 (P.6-238) > U066

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U067 | Adjusting the table scanning center line (Message: Adjust Table Center) |
|-------------|--|

Contents

Adjusts the center line for the table scanning.

Purpose

Adjusted if there is a regular error between the center lines of the copy image and original.

Adjustment

1. Press the [Start] key.
2. Press the [System Menu] key.
3. Place an original and press the [Start] key to make a test copy.
4. Press the [System Menu] key.
5. Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|---------------|--------------------------------------|---------------|-----------------|----------------|
| Front | Adjusts the scanner center line | -40 to 40 | 0 | 0.085 mm |
| Rotate | Scanner center line (rotate copying) | -40 to 40 | 0 | 0.085 mm |

1. By using the [+] [-] keys or the numeric keys, change the setting value.

For the copy example 1, decrease the value.

For the copy example 2, increase the value.

* :When the setting value is increased, the image moves to left, and it moves to right when the setting value is decreased.

Center line of the copy image (within ± 2.0 mm)




Figure 6-34

2. Press the [Start] key to set the setting value.

Precautions

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034(P.6-228) > U065(P.6-238) > U067

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U068 | DP scanning position adjustment (Message: Adjust DP Scan Position) |
|-------------|---|

Contents

Adjusts the starting position for scanning originals from the DP.
Execute test copy at the four scanning positions after adjustment.

Purpose

Adjust if the image fogging occurs because the scanning position is not proper when the DP is used

* :Execute U071 to adjust the timing of the DP leading edge when the scanning position is changed.

Method

- 1.Press the [Start] key.
- 2.Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------|--|----------------------|------------------------|-----------------------|
| DP Read | Adjusts the starting position for scanning originals. | -33 to 33 | 0 | 0.158 mm |
| Black Line | Adjusts the scanning position for the test copy originals. | 0 to 3 | 0 | - |

Adjustment: DP Read

- 1.Select [DP Read].
- 2.By using the [+] [-] keys or the numeric keys, change the setting value.
* :When the setting value is increased, the image moves backward, and it moves forward when the setting value is decreased.
- 3.Press the [Start] key to set the setting value.

Adjustment: Black Line

- 1.Select [Black Line].
- 2.By using the [+] [-] keys or the numeric keys, change the setting value.
- 3.Press the [Start] key to set the setting value.
- 4.Set the original (the one of which density is known) in the DP and press the [System Menu] key.
- 5.Press the [Start] key to execute the test copy.
- 6.Perform the test copy at each scanning position with the setting value from 0 to 3 and check that no black line appears and the image is normally scanned.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U070 | DP magnification adjustment (Message: Adjust DP Motor Speed) |
|-------------|---|

Contents

Adjusting the magnification for DP scanning.

Purpose

Adjusted if the magnification is incorrect in the auxiliary scanning direction when the DP is used

Adjustment

1. Press the [Start] key.
2. Press the [System Menu] key.
3. Place an original on the DP and press the [Start] key to make a test copy.
* :Check the duplex scanning by setting [Duplex] when test copying.
4. Press the [System Menu] key.
5. Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------------|---|---------------|-----------------|----------------|
| Sub Scan (F) | Adjusting the magnification for table scanning | -25 to 25 | - | 0.1 % |
| Sub Scan (B) | Adjusts the 2nd side magnification in the sub scanning direction when duplex scanning | -25 to 25 | - | 0.1 % |
| Sub Scan (CIS) | Adjusts the 2nd side magnification in the sub scanning direction when duplex scanning (CIS) | -25 to 25 | - | 0.1 % |
| Duplex 1side | Adjusts the 1st side magnification in the sub scanning direction when duplex scanning (CCD) | -25 to 25 | -3 | 0.1 % |

6. By using the [+] [-] keys or the numeric keys, change the setting value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the image get longer, and it shortens when the setting value is decreased.




Figure 6-35

7. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U071 | Adjusting the DP leading edge Timing (Message: Adjust DP Leading Edge Timing) |
|-------------|--|

Contents

Adjusts the DP original scanning timing.

Purpose

Adjusted if there is a regular error between the leading or trailing edges of the original and the copy image when the DP is used

Method

1. Press the [Start] key.
2. Press the [System Menu] key.
3. Place an original on the DP and press the [Start] key to make a test copy.
* :Check the duplex scanning by setting [Duplex] when test copying.
4. Press the [System Menu] key.
5. Select the item to adjust.

Paper reversing scanner

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------|--|---------------|-----------------|----------------|
| Front Head | Leading edge registration. (Front page) | -32 to 32 | 0 | 0.245m m |
| Front Tail | Trailing edge registration. (Front page) | -32 to 32 | 0 | 0.245m m |
| Back Head | Leading edge registration. (Back page) | -32 to 32 | 0 | 0.245m m |
| Back Tail | Trailing edge registration. (Back page) | -32 to 32 | 0 | 0.245m m |

Simultaneous duplex scanning machine

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------|---|---------------|-----------------|----------------|
| Front Head | Leading edge registration. (Front page) | -30 to 30 | 0 | 0.2644m m |
| Front Tail | Trailing edge registration. (Front page) | -30 to 30 | 0 | 0.2644m m |
| Back Head | Leading edge registration. (Back page) | -30 to 30 | 0 | 0.2644m m |
| Back Tail | Trailing edge registration. (Back page) | -30 to 30 | 0 | 0.2644m m |
| CIS Head | Adjusts the leading edge timing for the CIS scanning | -30 to 30 | 0 | 0.266mm |
| CIS Tail | Adjusts the trailing edge timing for the CIS scanning | -30 to 30 | 0 | 0.266mm |

Adjustment: Front Head/Back Head/CIS

1. By using the [+] [-] keys or the numeric keys, change the setting value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the image moves forward, and it moves backward when the setting value is decreased.




Figure 6-36

2. Press the [Start] key to set the setting value.

Precautions

Check the 2nd side after adjusting the 1st side. Adjust if necessary.

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034(P.6-228) > U071

Adjustment: Front Tail/Back Tail/CIS Tail

1. By using the [+] [-] keys or the numeric keys, change the setting value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the image get longer, and it shortens when the setting value is decreased.




Figure 6-37

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U072 | Adjusting the DP original center (Message: Adjust DP Original Center) |
|-------------|--|

Contents

Adjusts the DP original center line.

Purpose

Adjusted if there is a regular error between the center lines of the original and the copy image when the DP is used

Adjustment

1. Press the [Start] key.
2. Press the [System Menu] key.
3. Place an original on the DP and press the [Start] key to make a test copy.
 - * :Check the duplex scanning by setting [Duplex] when test copying.
4. Press the [System Menu] key.
5. Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|--------------|-------------------------------|---------------|-----------------|----------------|
| Front | DP center line. (Front page) | -40 to 40 | - | 0.085 mm |
| Back | DP center line. (Back page) | -40 to 40 | - | 0.085 mm |
| CIS | Adjusts the DPCIS center line | -20 to 20 | - | 0.085 mm |

6. By using the [+] [-] keys or the numeric keys, change the setting value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the image moves to right, and it moves to left when the setting value is decreased.




Figure 6-38

7. Press the [Start] key to set the setting value.

Precautions

Check the 2nd side after adjusting the 1st side. Adjust if necessary.

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034 (P.6-228) > U065 (P.6-238) > U067 (P.6-241) > U072

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U073 | Scanner motor operation check (Message: Check Scanner Motor Operation) |
|-------------|---|

Contents

Simulate the scanner operation in any condition.

Purpose

Execute the scanner operation to check the abnormal operation and dust adhesion on the slit glass.

Method

1. Press the [Start] key.
2. Select the item to execute.

| Items | Contents |
|----------------------|--|
| Scanner Motor | Execute the scan operation |
| Home Position | Home positioning operation |
| Dust Check | Check if there is dust by turning the exposure lamp on |
| DP Reading | scan position operation for the document processor |

3. Select [Execute].
4. Press the [Start] key.
* : Scanning starts with the condition specified.
5. To stop the operation, press the [Stop] key.

Setting: Scanner Motor

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------|----------------------------------|-----------------|-----------------|----------------|
| Zoom | Magnification | 25 to 400 (%) | 100 | 1% |
| Size | Original size | 100 to 10200 | 10200 | 100 |
| Lamp | Turning the exposure lamp on/off | 0: Off 1: On | 1: On | - |

Paper size corresponding to each set value

| setting | Destination | setting | Destination | setting | Destination |
|-------------|---------------|-------------|-------------|--------------|-------------|
| 4300 | B5 | 6100 | B5R | 8600 | B4 |
| 5000 | A4 | 6600 | 8 1/2"×11" | 9000 | 11"×15" |
| 5000 | A5R | 7100 | A4R | 10000 | A3 |
| 5100 | | 7800 | Folio | 10200 | 11"×17" |
| 5100 | 5 1/2"×8 1/2" | 8400 | 8 1/2"×14" | | |

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

- * : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U087 | Setting the DP scanning position change operation (Message: Set DP Scanning Position Operation) |
|-------------|--|

Contents

If dust can be detected by comparing the original trailing edge scanned data with the scanned data after the original feed, change the original scan position next time.

Also, reduce the black lines by image correction.

Purpose

Use as the corrective measures for the black lines appearing with dust on the original scanning position when using the document processor.

Setting

1. Press the [Start] key.
2. Select the item to set.
3. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|-------------------|--|---------------|-----------------|
| Front | Set the 1st side scanning data threshold | 0 to 128 | 48 |
| Back | Sets the 2nd side scanning data threshold when duplex scanning | 0 to 128 | 48 |
| Black Line | Initialize the original scanning position | - | - |

* :If the set value is reduced, dark density image is regarded as dust and dust detection becomes more likely.

If the set value is increased, dust detection becomes less likely.

Method: Black Line

1. Select [Clear].
 2. Press the [Start] key.
- * :Original scan position returns to the initial line.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U089 | MIP-PG pattern output (Message: Output MIP-PG Pattern) |
|-------------|---|

Contents

Select and output the MIP-PG pattern generated by the main unit.





Purpose

When adjusting the image scanning items, execute to check the machine status except the scanner section using the MIP-PG pattern output without image scanning process.

Method

1. Press the [Start] key.
2. Select the MIP-PG pattern to output

| Items | Contents |
|---------------------|--|
| Printer Gray | For grayscale level check  |
| White | For drum quality check (Blank PG)  |
| White(Color) | Color for drum quality check (Blank PG)  |
| Gray(C) | For drum quality check (Cyan PG)  |
| Gray(M) | For drum quality check (Magenta PG)  |

| Items | Contents |
|------------------------|---|
| Gray(Y) | For drum quality check (Yellow PG)  |
| Gray(K) | For drum quality check (Gray PG)  |
| Color Belt | PG for the developer status and engine ID check (four color PG)  |
| Color Gradation | Printing 64 grayscales to check 4 colors  |
| Sample Set | Outputs the following output patterns for the long life unit warranty application PG for the developer status and engine ID check (four color PG) For drum quality check (Yellow PG) For drum quality check (Cyan PG) For drum quality check (Magenta PG) For drum quality check (Gray PG) |

- 3.Press the [System Menu] key.
- 4.Press the [Start] key to output a MIP-PG pattern.
- 5.Press the [System Menu] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U091 | White lines correction setting (Message: Set White Line Correction) |
|-------------|--|

Contents

Set the error detection threshold for white lines correction and display the abnormal pixel count.

Purpose

Execute when replacing the CIS, DP main PWB or CIS roller.

Setting

1. Press the [Start] key.
2. Select the item to set.
3. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------------------------|--|---|-----------------|----------------|
| Coefficient(R) | Displays the red pixel error counts | 0 to 8191 | - | - |
| Coefficient(G) | Displays the green pixel error counts | 0 to 8191 | - | - |
| Coefficient(B) | Displays the Blue pixel error counts | 0 to 8191 | - | - |
| Threshold(R) | Sets the red error detection threshold | 0 to 1023 | 112 | - |
| Threshold(G) | Sets the green error detection threshold | 0 to 1023 | 112 | - |
| Threshold(B) | Sets the blue error detection threshold | 0 to 1023 | 112 | - |
| Threshold(Abnormal) | Sets the abnormal pixel threshold | 0 to 8191 | 75 | - |
| Mode | Set the white lines correction mode | 0: No correction 1: Correction 2: Test mode | 0 | - |
| Execute | Execute retaining the white reference data | - | - | - |

- * :Normally do not change the threshold from the initial value of 112.
 Increase the value if white lines appear while the CIS roller/glass is not dirty.
 Reduce the set value if thin lines disappear depending on the original to use.
 Set in the range of 50 to 200. (In the case of out of range, it may affect the image output)

4. Press the [Start] key to set the setting value.

Method: Execute

1. Select [Execute].
2. Press the [Start] key.
 - * :Starts retaining the white reference data.
3. Press the [System / Menu] key.
4. Set the gray original face-down on the document processor and set paper in the cassette.
 - * :Match the original and paper size.
5. Press the [Start] key.
 - * :Outputs 2-sheet test pattern.
 - "1st sheet: black band of about 60mm width
 - 2nd sheet: blank (or may be gray band of about 60mm width)"
6. Setting is correctly complete if no vertical line is observed on both sheets.
 - If a vertical black line appears on blank paper or a gray band or vertical white line appear on the black band, execute the white line correction again after cleaning the CIS roller or CIS glass.
 - White line correction is complete if both sheets have vertical black lines or vertical white lines.
 - However, check the engine since there are factors of vertical streaks at the engine Side.
7. Press the [System / Menu] key.
 - * :Mode is set to [1].

How to check the test copy

| Blank paper | Black band | Factor | Corrective action |
|-------------|-------------|--------------------------------|---|
| No lines | No lines | - | Completion |
| Black line | White lines | CIS roller/glass contamination | Execute the U091 CIS roller/glass contamination |
| Black line | No lines | Engine PWB | Check engine PWB after completing U091 |
| No lines | White lines | Engine PWB | Check engine PWB after completing U091 |

Completion

- Press the [Stop] key.
- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U100 | Main high voltage adjustment (Message: Adjust Main High Voltage Output) |
|-------------|--|

Contents

Adjust the surface potential by changing the voltage impressed to the main charge roller.

Purpose

Change the set value to adjust the image when an image failure (background image) occurs.

Method

1. Press the [Start] key.
2. Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|--------------------------------------|--|
| Adj AC Bias ^{*1} | Adjust the main charge AC bias of each color |
| Set AC Auto Adj ^{*1} | Sets the automatic AC bias adjustment |
| Set DC Bias | Displays the main charge DC bias correction value for each color. |
| Adj DC Bias | Adjust the surface potential additional value |
| Set DC Bias Base | Displays the main charge DC bias base value for each color. (Adjusted value before correction) |
| Chk Current | Displays the in-rush current |
| Set AC Gain ^{*1} | Set the AC Gain |
| Set Main HV ^{*2} | Sets the main high voltage mode |
| MCH ^{*2} | Set MC correction |

*1: 40 ppm models only, *2: 35 ppm models only

Setting: Adj AC Bias

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

* :When the setting value is increased, the image get thinner, and it gets thicker when the setting value is decreased.

Set value is variable depending on the environment.

| Items | Contents | Setting range | Initial setting |
|-------------------|-----------------------------|---------------|-----------------|
| AC Bias(C) | Cyan main charge AC bias | 0 to 2300 | - |
| AC Bias(M) | Magenta main charge AC bias | 0 to 2300 | - |
| AC Bias(Y) | Yellow main charge AC bias | 0 to 2300 | - |
| AC Bias(K) | Black main charge AC bias | 0 to 2300 | - |

3. Press the [Start] key to set the setting value.

Setting: Set AC Auto Adj

1. Select the item to set.

| Items | Contents |
|-------|----------------------------|
| On | Adjust automatically |
| Off | Not adjusted automatically |

* :Initial setting: On

2. Press the [Start] key to set the setting value.

Setting: Set DC Bias

1. Displays the current setting.

| Items | Contents |
|-------------|---|
| DC1 Bias(C) | Cyan main charge DC bias correction value (Full speed) |
| DC1 Bias(M) | Magenta main charge DC bias correction value (Full speed) |
| DC1 Bias(Y) | Yellow main charge DC bias correction value (Full speed) |
| DC1 Bias(K) | Black main charge DC bias correction value (Full speed) |

*1:35ppm model, *2: 40ppm model

Setting: Adj DC Bias

1. Select the item to set.

2. By using the [+], [-] keys or the numeric keys, change the setting value.

* :When the setting value is increased, the image get thinner, and it gets thicker when the setting value is decreased.

| Items | Contents | Setting range | Initial setting |
|-------------------------|---|--|-----------------|
| DC2 Bias(C) | Cyan main charge DC bias additional value (Full speed) | -1000?1000 ^{*1} -500?500 ^{*2} | 0 |
| DC2 Bias 3/4(C) | Cyan main charge DC bias additional value (3/4 speed) | -1000?1000 ^{*1} -500?500 ^{*2} | 0 |
| DC2 Bias Half(C) | Cyan main charge DC bias additional value (Half speed) | -1000?1000 ^{*1} -500?500 ^{*2} | 0 |
| DC2 Bias(M) | Magenta main charge DC bias additional value (Full speed) | -1000?1000 ^{*1} -500?500 ^{*2} | 0 |
| DC2 Bias 3/4(M) | Magenta main charge DC bias additional value (3/4 speed) | -1000?1000 ^{*1} -500?500 ^{*2} | 0 |
| DC2 Bias Half(M) | Magenta main charge DC bias additional value (Half speed) | -1000?1000 ^{*1} -500?500 ^{*2} | 0 |
| DC2 Bias(Y) | Yellow main charge DC bias additional value (Full speed) | -1000?1000 ^{*1} -500?500 ^{*2} | 0 |
| DC2 Bias 3/4(Y) | Yellow main charge DC bias additional value (3/4 speed) | -1000?1000 ^{*1} -500?500 ^{*2} | 0 |
| DC2 Bias Half(Y) | Yellow main charge DC bias additional value (Half speed) | -1000?1000 ^{*1} -500?500 ^{*2} | 0 |
| DC2 Bias(K) | Black main charge DC bias additional value (Full speed) | -1000?1000 ^{*1} -500?500 ^{*2} | 0 |
| DC2 Bias 3/4(K) | Black main charge DC bias additional value (3/4 speed) | -1000?1000 ^{*1} -500?500 ^{*2} | 0 |
| DC2 Bias Half(K) | Black main charge DC bias additional value (Half speed) | -1000?1000 ^{*1} -500?500 ^{*2} | 0 |

^{*1}: 35 ppm model only, ^{*2}: 40 ppm model

3. Press the [Start] key to set the setting value.

Setting: Set DC Bias Base

1. Displays the current setting.

| Items | Contents |
|------------------------------|---|
| DC1 Bias Base(C) | Cyan main charge DC bias base value (Full speed) |
| DC1 Bias Base 3/4(C) | Cyan main charge DC bias base value (3/4 speed) |
| DC1 Bias Base Half(C) | Cyan main charge DC bias base value (Half speed) |
| DC1 Bias Base(M) | Magenta main charge DC bias base value (Full speed) |
| DC1 Bias Base 3/4(M) | Magenta main charge DC bias base value (3/4 speed) |
| DC1 Bias Base Half(M) | Magenta main charge DC bias base value (Half speed) |
| DC1 Bias Base(Y) | Yellow main charge DC bias base value (Full speed) |
| DC1 Bias Base 3/4(Y) | Yellow main charge DC bias base value (3/4 speed) |
| DC1 Bias Base Half(Y) | Yellow main charge DC bias base value (Half speed) |
| DC1 Bias Base(K) | Black main charge DC bias base value (Full speed) |
| DC1 Bias Base 3/4(K) | Black main charge DC bias base value (3/4 speed) |
| DC1 Bias Base Half(K) | Black main charge DC bias base value (Half speed) |

*1: 35 ppm model only, *2: 40 ppm model

Refer: Chk Current

1. Displays the current setting.

| Items | Contents |
|----------|------------------------|
| C | Cyan inflow current |
| M | Magenta inflow current |
| Y | Yellow inflow current |
| K | Black inflow current |

Setting: Set AC Gain

1. Select the item to set.

| Items | Contents |
|--------------|--|
| Auto | Automatic environmental setting (default) |
| Mode1 | In case of C2201/C2202 errors occurrence (multiplication value 0.95) |
| Mode2 | If the horizontal lines appear in the main charge roller circumference interval (Multiplication value 1.05) |
| Mode3 | In case of the level where the C2201/C2202 errors occur and horizontal lines in the main charge roller circumference interval are pointed out in |

* :Initial setting: Auto

2. Press the [Start] key to set the setting value.

Setting: Set Main HV

1. Select the item to set.

| Items | Contents | Setting range | Initial setting |
|-------------------|---|---------------|-----------------|
| White Line | Switch On/Off the white streak prevention control | On/Off | Off |
| Agent Time | Aging time by surface speed gap | 0 to 255 | 0 |

2. Press the [Start] key to set the setting value.

Setting: MCH

1. Select the item to set.

| Items | Contents | Setting range | Initial setting |
|--------------|----------------|---------------|-----------------|
| Value | MCH correction | 1 to 7 | 4 |

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U101 | Primary transfer voltage adjustment (Message: Adjust 1st Transfer Voltage Output) |
|-------------|--|

Contents

Set the primary transfer control voltage

Purpose

Change setting if a failure such as faint image, etc. occurs.

Method

1.Press the [Start] key.

2.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|-------------------------|--|
| Normal | Set the primary transfer voltage |
| Add Color | Sets 2nd side additional value |
| Add Color 2nd | Sets the 2nd side additional value (in reference to the 1st side additional value) |
| Surround Correct | Setting the environmental correction |

Setting: Normal

1.Select the item to set.

2.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|--------------|--|----------------------|---------------------------------------|-----------------------|
| Full | Yellow primary transfer voltage (full speed) | 0 to 400 | 70 ^{*1} 110 ^{*2} | - |
| Half | Yellow primary transfer voltage (half speed) | 0 to 400 | 45 ^{*1} 65 ^{*2} | - |
| 3/4 | Yellow primary transfer voltage (3/4 speed) | 0 to 400 | 58 ^{*1} 88 ^{*2} | - |

^{*1}:35ppm model, ^{*2}: 40ppm model

3.Press the [Start] key to set the setting value.

Setting: Add Color

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------|---|---------------|-------------------------------------|----------------|
| C | Sets the additional value (Cyan) | -200 to 200 | -5 ^{*1} 0 ^{*2} | - |
| M | Sets the additional value (Magenta) | -200 to 200 | -5 ^{*1} 0 ^{*2} | - |
| Y | Sets the additional value (Yellow) | -200 to 200 | 0 ^{*1} 0 ^{*2} | - |
| K | Sets the additional value (Black) | -200 to 200 | 20 ^{*1} 0 ^{*2} | - |
| B/W | Monochrome mode (toner applying amount) | -200 to 200 | 0 ^{*1} 0 ^{*2} | - |

^{*1}:35ppm model, ^{*2}: 40ppm model

3. Press the [Start] key to set the setting value.

Setting: Add Color 2nd

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------|-------------------------------------|---------------|------------------------------------|----------------|
| C | 2nd side additional value (Cyan) | -200 to 200 | 0 ^{*1} 0 ^{*2} | - |
| M | 2nd side additional value (Magenta) | -200 to 200 | 0 ^{*1} 0 ^{*2} | - |
| Y | 2nd side additional value (Yellow) | -200 to 200 | 0 ^{*1} 0 ^{*2} | - |
| K | 2nd side additional value (Black) | -200 to 200 | 0 ^{*1} 0 ^{*2} | - |

^{*1}:35ppm model, ^{*2}: 40ppm model

3. Press the [Start] key to set the setting value.

Setting: Surround Correct

1. Select the item to set.

2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------------------|--|-----------------|-----------------|----------------|
| Mode | Environmental correction (On/Off) | 0: On 1: Off | 0: On | - |
| Rev Bias | Reverse bias cleaning | -200 to 200 | 30 | - |
| High Altitude | High altitude correction control (2nd side correction) | -200 to 200 | 85 | - |

*1: 35ppm model, *2: 40ppm model

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U106 | Secondary transfer voltage adjustment (Message: Adjust 2nd Transfer Roller Output) |
|-------------|---|

Contents

Set the secondary transfer control voltage.

Purpose

Change setting if a failure such as faint image, etc. occurs.

Method

- 1.Press the [Start] key.
- 2.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|------------------------|--|
| Light/Normal1 | Transfer control value for Light and Normal1 |
| Normal2/3 | Transfer control value for Normal 2 / 3 |
| Light/Normal123 | Transfer control value for Light to Normal1,2,3 |
| Heavy1 | Transfer control value for Normal 1 / 3 |
| Heavy2/3 | Transfer control value for Heavy 2 / 3 |
| OHP | Transfer control value for Transparency |
| Light-Normal3 | Transfer control value for Light to Normal3 |
| Bias | Bias setting |
| High Altitude | High altitude correction control setting (2nd side correction) |
| Paper End | Turning off the secondary transfer at the paper end |

Setting: Light/Normal1

- 1.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|------------|---|
| 1st | 1st side transfer control value at full speed |
| 2nd | 2nd side transfer control value at full speed |

- 2.Select the item to set.

- 3.By using the [+] [-] keys or the numeric keys, change the setting value.

1st

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|---------------------------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 600 ^{*1} 60 ^{*2} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 400 ^{*1} 40 ^{*2} | - |

*1:35ppm model, *2: 40ppm model

2nd

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|---|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 700 * ¹ 70 * ² | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 400 * ¹ 35 * ² | - |

*¹:35ppm model, *²: 40ppm model

4.Press the [Start] key to set the setting value.

Setting: Normal2/3

1.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|------------|---|
| 1st | 1st side transfer control value at full speed |
| 2nd | 2nd side transfer control value at full speed |

2.Select the item to set.

3.By using the [+] [-] keys or the numeric keys, change the setting value.

1st

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|---|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 650 * ¹ 65 * ² | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 500 * ¹ 45 * ² | - |

*¹:35ppm model, *²: 40ppm model

2nd

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|---|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 750 * ¹ 75 * ² | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 500 * ¹ 40 * ² | - |

*¹:35ppm model, *²: 40ppm model

4.Press the [Start] key to set the setting value.

Setting: Light/Normal123

1. Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|----------------|--|
| 1st B/W | 1st side transfer control value in monochrome mode |
| 2nd B/W | 2nd side transfer control value in monochrome mode |

2. Select the item to set.

3. By using the [+] [-] keys or the numeric keys, change the setting value.

1st

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|---------------------------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 550 ^{*1} 55 ^{*2} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 400 ^{*1} 35 ^{*2} | - |

^{*1}:35ppm model, ^{*2}: 40ppm model

2nd

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|---------------------------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 650 ^{*1} 65 ^{*2} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 300 ^{*1} 30 ^{*2} | - |

^{*1}:35ppm model, ^{*2}: 40ppm model

4. Press the [Start] key to set the setting value.

Setting: Heavy1

1. Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|--------------------|---|
| 1st 3/4 | 1st side transfer control value at 3/4 speed |
| 2ND 3/4 | 2nd side transfer control value at 3/4 speed |
| 1st Half | 1st side transfer control value at half speed |
| 2nd Half | 2nd side transfer control value at half speed |
| 1st 3/4 B/W | 1st side transfer control value at 3/4 speed in monochrome mode |
| 2nd 3/4 B/W | 2nd side transfer control value at 3/4 speed in monochrome mode |

2. Select the item to set.

3. By using the [+] [-] keys or the numeric keys, change the setting value.

1st 3/4

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|---------------------------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 530 ^{*1} 53 ^{*2} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 380 ^{*1} 35 ^{*2} | - |

*1:35ppm model, *2: 40ppm model

2ND 3/4

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|---------------------------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 650 ^{*1} 65 ^{*2} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 330 ^{*1} 30 ^{*2} | - |

*1:35ppm model, *2: 40ppm model

1st Half

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 35 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 25 | - |

2nd Half

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-----------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 35 | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 25 | - |

1st 3/4 B/W

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|---------------------------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 480 ^{*1} 48 ^{*2} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 330 ^{*1} 30 ^{*2} | - |

*1:35ppm model, *2: 40ppm model

2nd 3/4 B/W

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|---------------------------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 580 ^{*1} 60 ^{*2} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 280 ^{*1} 25 ^{*2} | - |

^{*1}:35ppm model, ^{*2}: 40ppm model

4.Press the [Start] key to set the setting value.

Setting: Heavy2/3

1.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|---------------------|--|
| 1st Half | 1st side transfer control value at half speed |
| 2ND Half | 2nd side transfer control value at half speed |
| 1st Half B/W | 1st side transfer control value at half speed in monochrome mode |
| 2nd Half B/W | 2nd side transfer control value at half speed in monochrome mode |

2.Select the item to set.

3.By using the [+] [-] keys or the numeric keys, change the setting value.

1st Half

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|---------------------------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 450 ^{*1} 45 ^{*2} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 300 ^{*1} 30 ^{*2} | - |

^{*1}:35ppm model, ^{*2}: 40ppm model

2ND Half

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|---------------------------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 550 ^{*1} 60 ^{*2} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 250 ^{*1} 25 ^{*2} | - |

^{*1}:35ppm model, ^{*2}: 40ppm model

1st Half B/W

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|---------------------------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 450 ^{*1} 45 ^{*2} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 300 ^{*1} 30 ^{*2} | - |

^{*1}:35ppm model, ^{*2}: 40ppm model

2nd Half B/W

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|---------------------------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 550 ^{*1} 60 ^{*2} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 250 ^{*1} 25 ^{*2} | - |

^{*1}:35ppm model, ^{*2}: 40ppm model

4.Press the [Start] key to set the setting value.

Setting: OHP

1.Select the item to set.

2.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|---------------------------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 450 ^{*1} 45 ^{*2} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 300 ^{*1} 30 ^{*2} | - |

^{*1}:35ppm model, ^{*2}: 40ppm model

3.Press the [Start] key to set the setting value.

Setting: Light-Normal3

1.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|-----------------|--------------------------------|
| 1st 3/4 | 1st side setting at 3/4 speed |
| 2nd 3/4 | 2nd side setting at 3/4 speed |
| 1st Half | 1st side setting at half speed |
| 2nd Half | 2nd side setting at half speed |

2.Select the item to set.

3.By using the [+] [-] keys or the numeric keys, change the setting value.

1st 3/4

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 490 ^{*1} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 380 ^{*1} | - |

2nd 3/4

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 560 ^{*1} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 380 ^{*1} | - |

1st Half

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 330 ^{*1} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 250 ^{*1} | - |

2nd Half

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------------|--|---------------|-------------------|----------------|
| W<160 | Setting paper width less than 160 | 0 to 2000 | 380 ^{*1} | - |
| 160<=W<210 | Setting paper width of 160 or more and less than 210 | 0 to 2000 | 250 ^{*1} | - |

*1: 35 ppm model only

4.Press the [Start] key to set the setting value.

Setting: Bias

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------------------|---|---------------|-----------------|----------------|
| Reverse 2nd | Secondary transfer cleaning negative bias | -1 to 200 | -1 | - |
| Cleaning 2nd | Secondary transfer cleaning positive bias | 0 to 200 | 5 | - |
| Calb Cleaning | Calibration cleaning bias | 0 to 200 | 40 | - |

3. Press the [Start] key to set the setting value.

Setting: High Altitude

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------------------|---------------------------|---------------|--------------------------------------|----------------|
| Light/Normal1 | Light and Normal1 setting | 0 to 100 | 85 ^{*1} 40 ^{*2} | - |
| Normal2/3 | Setting of Normal 1/2 | 0 to 100 | 80 ^{*1} 40 ^{*2} | - |

*1: 35ppm model, *2: 40ppm model

3. Press the [Start] key to set the setting value.

Setting: Paper End

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------------|----------------------|---------------|--------------------------------------|----------------|
| Heavy2/3 | Setting for Thick2,3 | 0 to 100 | 35 ^{*1} 40 ^{*2} | - |
| Ext Heavy | Ext Heavy setting | 0 to 100 | 35 ^{*1} 40 ^{*2} | - |

*1: 35ppm model, *2: 40ppm model

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U107 | Primary transfer cleaning voltage adjustment (Message: Adjust 1st Transfer Unit Cleaning Output) |
|-------------|---|

Contents

Sets the transfer belt cleaning control voltage

Purpose

Change the setting when offset images appear with the transfer belt cleaning failure.

Method

- 1.Press the [Start] key.
- 2.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|----------------|----------------|
| Belt(A) | Belt A setting |
| Belt(B) | Belt B setting |
| Belt(C) | Belt C setting |
| Belt(D) | Belt D setting |

Setting

- 1.Select the item to set.
- 2.By using the [+] [-] keys or the numeric keys, change the setting value.

Belt(A)

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------|--------------------|---------------|--------------------------------------|----------------|
| Full | Full speed setting | 0 to 300 | 35 ^{*1} 40 ^{*2} | - |
| Half | Half speed setting | 0 to 300 | 26 ^{*1} 30 ^{*2} | - |
| 3/4 | 3/4 speed setting | 0 to 300 | 31 ^{*1} 35 ^{*2} | - |

*1:35ppm model, *2: 40ppm model

Belt(B)

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------|--------------------|---------------|--------------------------------------|----------------|
| Full | Full speed setting | 0 to 300 | 35 ^{*1} 60 ^{*2} | - |
| Half | Half speed setting | 0 to 300 | 26 ^{*1} 60 ^{*2} | - |
| 3/4 | 3/4 speed setting | 0 to 300 | 31 ^{*1} 60 ^{*2} | - |

*1:35ppm model, *2: 40ppm model

Belt(C)

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------|--------------------|---------------|--|----------------|
| Full | Full speed setting | 0 to 300 | 130 ^{*1} 150 ^{*2} | - |
| Half | Half speed setting | 0 to 300 | 130 ^{*1} 150 ^{*2} | - |
| 3/4 | 3/4 speed setting | 0 to 300 | 130 ^{*1} 150 ^{*2} | - |

^{*1}:35ppm model, ^{*2}: 40ppm model

Belt(D)

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------|--------------------|---------------|--|----------------|
| Full | Full speed setting | 0 to 300 | 130 ^{*1} 150 ^{*2} | - |
| Half | Half speed setting | 0 to 300 | 130 ^{*1} 150 ^{*2} | - |
| 3/4 | 3/4 speed setting | 0 to 300 | 130 ^{*1} 150 ^{*2} | - |

^{*1}: 35 ppm model only

3.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U110 | Drum counter (Message: Drum Unit Counter) |
|-------------|--|

Contents

Displays the drum counter values.

Purpose

Execute to check the drum usage status.

Method

1.Press the [Start] key.

* :The drum counter is displayed.

| Items | Contents |
|--------------|-----------------------------------|
| C | Displays the cyan drum counter |
| M | Displays the magenta drum counter |
| Y | Displays the yellow drum counter |
| K | Displays the black drum counter |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U117 | Drum unit number (Message: Drum Unit Number) |
|-------------|---|

Contents

Displays the drum number.

Purpose

Execute to check the drum number.

Method

1.Press the [Start] key.

* :Displays the drum number.

| Items | Contents |
|--------------|----------------------------------|
| C | Displays the cyan drum number |
| M | Displays the magenta drum number |
| Y | Displays the yellow drum number |
| K | Displays the black drum number |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U118 | Drum unit history (Message: Drum Unit History) |
|-------------|---|

Contents

Displays the machine serial number and drum counter history.

Purpose

Execute to check the machine serial number and drum counter values.

Method

1.Press the [Start] key.

* :Select the item to refer to.

| Items | Contents |
|----------|-----------------------------------|
| C | Displays the cyan drum history |
| M | Displays the magenta drum history |
| Y | Displays the yellow drum history |
| K | Displays the black drum history |

* :Displays the machine serial number and 3 items of the drum counter history.

| Items | Contents |
|------------------------------|-------------------------------|
| Machine History1 to 3 | Machine serial number history |
| Cnt History1 to 3 | The drum counter history |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U119 | Setting the drum (Message: Set Up Drum Unit) |
|-------------|---|

Contents

Set the drum sensitivity.

Purpose

Execute when the drum unit or laser scanner unit is replaced.

After completing, execute maintenance mode U464 [Calibration].

Method

1.Press the [Start] key.

2.Select [Execute].

| Items | Contents |
|----------------|--|
| Execute | Detect the main charge current and save the current value. |

3.Press the [Start] key.

* :Starts the drum setup operation.

4.Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U120 | Drum drive distance counter (Message: Drum Driving Distance Counter) |
|-------------|---|

Contents

Displays the drum drive distance counter.

Purpose

Execute to displays the drum drive distance counter.

Method

- 1.Press the [Start] key.
- * :Displays the count.

| Items | Contents |
|--------------|--|
| C | Displays the cyan drum drive distance counter |
| M | Displays the magenta drum drive distance counter |
| Y | Displays the yellow drum drive distance counter |
| K | Displays the black drum drive distance counter |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U127 | Clearing the transfer count (Message: Clear Transfer Roller Counter) |
|-------------|---|

Contents

Display and clear the transfer counts for the transfer high-voltage output correction etc.

Purpose

Verify the primary/secondary transfer unit counts after replacing Also, clear the counts after replacement

Method

- 1.Press the [Start] key.
- * : The transfer counter value appears.

| Items | Contents |
|-----------------------|---|
| Mid Trans(Cnt) | Displays or clears the primary transfer counter |
| 2nd Trans(Cnt) | Displays or clears the secondary transfer counter |

Setting: Mid Trans(Cnt)

* :Clear only. This cannot be changed.

- 1.Select [Clear].
- 2.Press the [Start] key to set the counter value.

Setting: 2nd Trans(Cnt)

- 1.By using the [+] [-] keys or the numeric keys, change the setting value.
- 2.Press the [Start] key to set the counter value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U128 | Leading edge timing (Message: Adjust Transfer Timing) |
|-------------|--|

Contents

Adjust On/Off timing of the transfer high voltage output.

Purpose

Prevent paper from being rolled up by the drum.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|-------------------|--|
| Timing 1st | Transfer On timing adjustment value (1st side) |
| Timing 2nd | Transfer On timing adjustment value (2nd side) |

Setting: Timing 1st

1. Select the item to set.
2. By using the [+] [-] keys the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------|--------------------------------------|---------------|-----------------|----------------|
| On Timing | Transfer On timing adjustment value | -200 to 200 | 0 | 0.5mm |
| Off Timing | Transfer Off timing adjustment value | -200 to 200 | 0 | 0.5mm |

3. Press the [Start] key to set the setting value.

Setting: Timing 2nd

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------------|---|---------------|-----------------|----------------|
| 1side < 60 | Secondary transfer voltage on timing (1st side, weight less than 60gsm) | -200 to 200 | 0 | 0.5mm |
| 1side >= 60 | Secondary transfer voltage on timing (1st side, weight 60gsm or more) | -200 to 200 | 0 | 0.5mm |
| 2side < 60 | Secondary transfer voltage on timing (2nd side, weight less than 60gsm) | -200 to 200 | 0 | 0.5mm |
| 2side >= 60 | Secondary transfer voltage on timing (2nd side, weight 60gsm or more) | -200 to 200 | 0 | 0.5mm |

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------------|---------------------------------------|---------------|-----------------|----------------|
| Off Timing | Secondary transfer voltage off timing | -200 to 200 | 0 | 0.5mm |

3.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U132 | Forcible toner supply operation (Message: Supply Toner Forcefully) |
|-------------|---|

Contents

Toner is supplied forcibly until the toner sensor output value reaches the toner supply level.

Purpose

Execute if toner empty is often detected.

Method

1.Press the [Start] key.

2.Select [Execute].

| Items | Contents |
|----------------|----------------|
| Execute | Installs toner |

3.Press the [Start] key.

* :Execute toner supply forcibly until the toner sensor output value reaches the toner supply level.

| Items | Contents |
|------------------|-----------------------------------|
| Supply(C) | Cyan toner supply level |
| Supply(M) | Magenta toner supply level |
| Supply(Y) | Yellow toner supply level |
| Supply(K) | Black toner supply level |
| Sensor(C) | Cyan toner sensor output value |
| Sensor(M) | Magenta toner sensor output value |
| Sensor(Y) | Yellow toner sensor output value |
| Sensor(K) | Black toner sensor output value |

4.To stop the operation, press the [Stop] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U135 | Checking the toner motor operation (Message: Check Toner Motor Operation) |
|-------------|--|

Contents

Drives the toner motor.

Purpose

Execute to check the toner motor operation.

Precautions

If driven for a long time or several times repeatedly, the developer unit will be full of toner inside and it may lock up.

Method

- 1.Press the [Start] key.
 - 2.Select [Toner].
 - 3.Press the [Start] key.
- * :The operation starts.

| Items | Contents |
|--------------|----------------------------|
| Toner | Drives the toner motor(TM) |

- 4.To stop the operation, press the [Stop] key.

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U136 | Toner level detection setting (Message: Set Toner Near End Detection) |
|-------------|--|

Contents

Execute the level setting of printable pages between toner near end and toner empty.

Purpose

Change the timing of detecting toner near end earlier than the current setting if the interval between toner near end and toner empty is too short.

Setting

1. Press the [Start] key.
2. Select the item to set.

* :By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------|---|---------------|-----------------|----------------|
| CMY | Black/Cyan/Magenta/Yellow toner level setting | 0 to 9 | 3 | - |
| K | Setting the black toner level | 0 to 9 | 3 | - |

If the set value is increased, the time interval from the toner near end to the toner empty becomes longer.

If the set value is reduced, the time interval from toner near end to toner empty becomes shorter.

0: no toner near end detection

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U139 | Temperature, humidity (Message: Temperature/Humidity) |
|-------------|--|

Contents

Displays the machine inside and outside temperature and machine outside humidity.

Purpose

Check the machine inside and outside temperature and machine outside humidity.

Method

1. Press the [Start] key.

* :Each value is displayed.

| Items | Contents |
|--------------------------|--|
| External Temp | Displays the machine outside temperature. |
| External Humidity | Displays the machine outside humidity. |
| Dev Temp | Displays the developer (K) temperature inside the machine. |
| LSU Temp(K) | Displays the LSU (K) temperature inside the machine. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U140 | Developer bias adjustment (Message: Adjust Developing Bias) |
|-------------|--|

Contents

Displays/changes the developer bias set values or sets high altitude mode.

Purpose

Execute to check/change the developer bias set values.

Method

1.Press the [Start] key.

2.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|------------------------------|--|
| Sleeve DC | Set the developer sleeve roller DC bias. |
| Sleeve AC | Set the developer sleeve roller AC bias. |
| Mag DC | Set the developer magnet roller DC bias. |
| Mag AC*¹ | Set the developer magnet roller AC bias. |
| Sleeve Freq | Set the developer sleeve roller frequency. |
| Sleeve Duty | Set the developer sleeve roller duty. |
| Mag Duty | Set the developer magnet roller duty. |
| AC Calib*¹ | Execute and set AC Calibration |
| Image Preference | Sets the toner density |
| Altitude Adjustment | Sets the altitude adjustment mode |

*1: 40 ppm model only

Setting: Sleeve DC

1.Select the item to set.

2.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|--------------|------------------|----------------------|---------------------------------------|-----------------------|
| C | Sets the cyan | 0 to 350 | 200 ^{*1} 90 ^{*2} | - |
| M | Sets the magenta | 0 to 350 | 200 ^{*1} 90 ^{*2} | - |
| Y | Sets the yellow | 0 to 350 | 200 ^{*1} 90 ^{*2} | - |
| K | Sets the black | 0 to 350 | 200 ^{*1} 90 ^{*2} | - |

*1:35ppm model, *2: 40ppm model

3.Press the [Start] key to set the setting value.

Setting: Sleeve AC

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------|------------------|---------------|-----------------|----------------|
| C | Sets the cyan | 100 to 170 | 145 | - |
| M | Sets the magenta | 100 to 170 | 145 | - |
| Y | Sets the yellow | 100 to 170 | 145 | - |
| K | Sets the black | 100 to 170 | 145 | - |

3. Press the [Start] key to set the setting value.

Setting: Mag DC

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------|------------------|---------------|--|----------------|
| C | Sets the cyan | 0 to 750 | 510 ^{*1} 400 ^{*2} | - |
| M | Sets the magenta | 0 to 750 | 510 ^{*1} 400 ^{*2} | - |
| Y | Sets the yellow | 0 to 750 | 510 ^{*1} 400 ^{*2} | - |
| K | Sets the black | 0 to 750 | 510 ^{*1} 400 ^{*2} | - |

^{*1}:35ppm model, ^{*2}: 40ppm model

3. Press the [Start] key to set the setting value.

Setting: Mag AC

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------|------------------|---------------|-----------------|----------------|
| C | Sets the cyan | 100 to 270 | 250 | - |
| M | Sets the magenta | 100 to 270 | 250 | - |
| Y | Sets the yellow | 100 to 270 | 250 | - |
| K | Sets the black | 100 to 270 | 250 | - |

3. Press the [Start] key to set the setting value.

Setting: Sleeve Freq

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|--------|----------------------------|---------------|--|----------------|
| Normal | Execute full speed setting | 3500 to 5400 | 3600 ^{*1} 4700 ^{*2} | - |

^{*1}:35ppm model, ^{*2}: 40ppm model

3. Press the [Start] key to set the setting value.

Setting: Sleeve Duty

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|--------|----------------------------|---------------|--------------------------------------|----------------|
| Normal | Execute full speed setting | 30 to 50 | 68 ^{*1} 43 ^{*2} | 1% |

^{*1}:35ppm model, ^{*2}: 40ppm model

3. Press the [Start] key to set the setting value.

Setting: Mag Duty

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|--------|----------------------------|---------------|--------------------------------------|----------------|
| Normal | Execute full speed setting | 50 to 80 | 34 ^{*1} 68 ^{*2} | 1% |

^{*1}:35ppm model, ^{*2}: 40ppm model

3. Press the [Start] key to set the setting value.

Setting: AC Calib

1. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|-------------|--|
| Calibration | Executing AC Calibration (Developer AC bias setting) Execution timing 1. Setup at high altitude 2. When replacing the developer unit or drum unit 3. When the developer leakage occurs 4. When the solid image density is low after executing the AC calibration |

| Items | Contents |
|----------------------|---|
| Magnification | Setting the AC calibration target bias value Execution timing 1. When the developer leak occurs after executing the AC calibration |

Setting: Calibration

1. Select the item to set.
2. Set the developer to On to execute AC calibration.

| Items | Contents |
|----------|--------------------------------|
| C | Turns on/off Cyan developer |
| M | Turns on/off Magenta developer |
| Y | Turns on/off Yellow developer |
| K | Turns on/off Black developer |

* :Initial setting: Off

3. Select [Execute].

| Items | Contents |
|----------------|-----------------------|
| Execute | Executing Calibration |

4. Press the [Start] key. AC calibration is started.
 5. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.
- * :An error code appears when there is an error.

Setting: Magnification

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------|------------------|---------------|-----------------|----------------|
| C | Sets the cyan | -20 to 20 | 5 | - |
| M | Sets the magenta | -20 to 20 | 5 | - |
| Y | Sets the yellow | -20 to 20 | 5 | - |
| K | Sets the black | -20 to 20 | 5 | - |

3. Press the [Start] key to set the setting value.

Setting: Image Preference

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------------|-----------------------------|---------------|--|----------------|
| Copy | Sets the copy toner density | -1 to 1 | 0 1 (120 V model) -1 (Australia) | - |

3. Press the [Start] key to set the setting value.

* :If the set value is reduced, toner consumption decreases.

4. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Setting: Altitude Adjustment

1. Select the item to set.

| Items | Contents |
|----------------------|----------------------|
| Normal | Sets 1000m or less |
| 1001 to 2000m | Set at 1001 to 2000m |
| 2001 to 3000m | Set at 2001 to 3000m |
| 3001 to 3500m | Set at 3001 to 3500m |

* :Initial setting: Normal

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U147 | Setting the toner applying mode (Message: Set Toner Apply Mode) |
|-------------|--|

Contents

Mode selection for the operation to remove overcharged toner in the developer unit (Toner applying mode). Also, sets the operation to take toner accumulated on the developer blade back to the developer unit (vibration motor control).

Purpose

Change the setting to reduce the toner applying amount. Execute to change the vibration motor control frequency.

* :Density is lowered if overcharged toner stays in the developer unit.

Method

- 1.Press the [Start] key.
- 2.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|----------------------|--|
| Mode | Sets the toner applying mode. |
| Drum T7 | Sets the toner applying width at the cleaning mode. |
| Developing T7 | Sets the upper limit of the toner applying amount for each operation mode. |
| Motor | Sets the vibration motor operation. |

Setting: Mode

- 1.Select the item to set.

| Items | Contents |
|------------|---|
| On | Sets the toner applying operation with the normal amount. |
| Off | Sets the toner applying operation with less than the normal amount. |

* :Initial setting: On

- 2.Press the [Start] key to set the setting value.

Setting: Drum T7

- 1.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|--------------|---|---------------|----------------------------|----------------|
| Value | Sets the toner applying width at the cleaning mode. | 0 to 25 | 150 (Indicated as 15.0) | 0.1mm |

- 2.Press the [Start] key to set the setting value.

Setting: Developing T7

1.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|--------------|--|---------------|--------------------------|----------------|
| Value | Sets the upper limit of the toner applying amount for each operation mode. | 0 to 25 | 20 (Indicated as 2.0) | 1% |

2.Press the [Start] key to set the setting value.

Setting: Motor

1.By using the [+] [-] keys the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------------------|--|---------------|-----------------|----------------|
| Print(Normal) | Sets the continuous printing (normal environment) | 10 to 2550 | - | 10 |
| Print(H/H) | Sets continuous printing (high temperature, high humidity) | 10 to 2550 | - | 10 |
| Print End | Setting when completing printing | 1 to 255 | - | 1 |

2.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U148 | Drum refresh mode setting (Message: Set Drum Refresh Mode) |
|-------------|---|

Contents

Sets the mode to use the drum refresh in the user adjustment.

Purpose

Change the setting if the drum refresh is frequently operated.

Setting

1.Press the [Start] key.

2.By using the [+] [-] keys the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|---------------|------------------------|---|------------------|
| Normal | Sets Auto drum refresh | (35 ppm models) 0: Off / 1 to 3: Standard (40 ppm models) 0: Off / 1: Short 2: Standard / 3: Long | 1 *1 2 *2 |

*1:35ppm model, *2: 40ppm model

3.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U155 | Toner sensor output (Message: Toner Sensor Output Value) |
|-------------|---|

Contents

Displays the toner sensor output

Purpose

Execute to check each color's output value when an image failure occurs.

Method

1. Press the [Start] key.
 2. Select the item to refer to.
- * : Switched to each reference screen.

| Items | Contents |
|--------------------|---|
| Waste Toner | Displays the toner sensor value |
| Toner | Displays the toner sensor value and supply level value for each color |

Method: Waste Toner

1. Check each sensor value.
- * : Displays the waste toner sensor value.

| Items | Contents |
|------------------|--|
| Full | Displays the waste toner sensor value 1 (WTS1) |
| Near Full | Displays the waste toner sensor value 2 (WTS2) |

Method: Toner

1. Check each sensor value.
- * : Displays the toner sensor value.

| Items | Contents |
|------------------|--|
| Sensor(C) | Displays the cyan toner sensor output value |
| Sensor(M) | Displays the magenta toner sensor output value |
| Sensor(Y) | Displays the yellow toner sensor output value |
| Sensor(K) | Displays the black toner sensor output value |
| Supply(C) | Displays the cyan toner supply level value |
| Supply(M) | Displays the magenta toner supply level value |
| Supply(Y) | Displays the yellow toner supply level value |
| Supply(K) | Displays the black toner supply level value |

Completion

- Press the [Stop] key.
- * : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U156 | Toner control level adjustment (Message: Adjust Toner Control Level) |
|-------------|---|

Contents

Displays the toner supply level for each color.

Purpose

Execute displaying the toner supply level for each color.

Setting

- 1.Press the [Start] key.
- 2.Select [Supply].

| Items | Contents |
|---------------|---------------------------------|
| Supply | Displays the toner supply level |

- 3.Displays the toner supply level for each color.

| Items | Contents |
|--------------|---|
| C | Displays the cyan toner supply level |
| M | Displays the magenta toner supply level |
| Y | Displays the yellow toner supply level |
| K | Displays the black toner supply level |

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U157 | Developer drive time (Message: Developing Unit Drive Time) |
|-------------|---|

Contents

Displays the developer drive time to be a reference for the toner density control correction.

Purpose

Execute to check the developer drive time since replacing the developer unit.

Method

1. Press the [Start] key.

* :Displays the developer drive time.

| Items | Contents |
|--------------|---|
| C | Displays the Cyan developer unit drive time. |
| M | Displays the Magenta developer unit drive time. |
| Y | Displays the Yellow developer unit drive time. |
| K | Displays the Black developer unit drive time. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U158 | Developer counter (Message: Developing Unit Counter) |
|-------------|---|

Contents

Displays the developer counter

Purpose

Execute to check the developer unit usage status.

Method

1. Press the [Start] key.

* :The developer count is displayed.

| Items | Contents |
|--------------|---|
| C | Displays the cyan developer counter. |
| M | Displays the magenta developer counter. |
| Y | Displays the yellow developer counter. |
| K | Displays the black developer counter. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U161 | Fuser temperature adjustment (Message: Adjust Fuser Control Temperature) |
|-------------|---|

Contents

Sets the fuser temperature.

Purpose

Normally no need to change. However, change the setting as corrective measures for paper curl, creases and fusing failure on thick paper.

Method

1. Press the [Start] key.
2. Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|---------------|---|
| Center | Set the center thermistor temperature. |
| Edge | Sets the edge thermistor control temperature. |

Setting: Center

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------------|--|---------------|--------------------------------------|----------------|
| Pressure Start | Sets the temperature to start pressing | 0 to 200 | 30 | 1°C |
| Drive Start | Sets the drive start temperature | 0 to 200 | 100 | 1°C |
| Ready | Sets the Ready temperature | 100 to 200 | 150 ^{*1} /160 ^{*2} | 1°C |
| Steady | Sets the secondary stability temperature | 100 to 200 | 155 ^{*1} /165 ^{*2} | 1°C |
| Printing | Set the temperature during printing | 100 to 200 | 160 ^{*1} /170 ^{*2} | 1°C |
| Waiting | Set the standby temperature | 100 to 200 | 150 ^{*1} /160 ^{*2} | 1°C |

*1:35ppm model, *2: 40ppm model

3. Press the [Start] key to set the setting value.

Setting: Edge

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|---------------|--|---------------|--------------------------------------|----------------|
| Ready | Sets the Ready temperature | 100 to 200 | 105 ^{*1} /115 ^{*2} | 1°C |
| Steady | Sets the secondary stability temperature | 100 to 200 | 140 ^{*1} /150 ^{*2} | 1°C |

| Items | Contents | Setting range | Initial setting | Data variation |
|---------|-----------------------------|---------------|--------------------------------------|----------------|
| Waiting | Set the standby temperature | 100 to 200 | 140 ^{*1} /150 ^{*2} | 1°C |

^{*1}:35ppm model, ^{*2}: 40ppm model

3.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U167 | Clearing the fuser count (Message: Clear Fuser Counter) |
|-------------|--|

Contents

Displays and clears the fuser count.

Purpose

Verify the fuser count after replacement Also, clear the counts after replacement

Method

1.Press the [Start] key.

* : The fuser count is displayed.

| Items | Contents |
|--------------|--------------------------|
| Cnt | Displays the fuser count |
| Clear | Clears the fuser count |

Method: Clear

1.Select [Clear].

2.Press the [Start] key.

* :Fuser unit counter is cleared.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.



| | |
|-------------|---|
| U199 | Fuser temperature (Message: Fuser Temperature) |
|-------------|---|

Contents

Fuser temperature is displayed.

Purpose

Execute to check the fuser temperature.

Method

1. Press the [Start] key.

* :Fuser temperature is displayed.

| Items | Contents |
|---------------------------|--|
| Heat Roller Edge | Displays the heat roller edge temperature (°C) |
| Heat Roller Center | Displays the heat roller center temperature (°C) |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U200 | All LEDs lighting (Message: Turn ON All Panel LEDs) |
|-------------|--|

Contents

All the LEDs on the operation panel are lit.

Purpose

Execute to check the operation panel LED lighting.

Method

1. Press the [Start] key.

2. Select [Execute].

3. Press the [Start] key.

* :All the LEDs on the operation panel are blinking.

4. Press the [Stop] key to turn the display off.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U201 | Initializing the touch panel (Message: Initialize Touch Panel) |
|-------------|--|

Contents


Adjusts touch panel detecting positions.

Purpose

Correct and confirm the touch panel detecting positions, when the panel PWB or the operation panel is replaced or if the detecting positions are not aligned.

Method


1. Press the [Start] key.
 2. Select the item to execute.
 3. Press the [Start] key.
- * :The screen for executing is displayed.




| Items | Contents |
|-------------------|---|
| Initialize | Automatically corrects the touch panel display position |
| Check | Checks the touch panel display position |

Method: Initialize


1. Press the center of "+".
2. Repeat 2 times.



3. If 2 points of [] appear, press them simultaneously.
 - * :Target [] and press one while pressing another. The set value is retrieved when pressing at the same time.
 - * :Press with a fingertip. (Do not push by finger)
4. Repeat 2 times.



- 5. Press the center of "+" as well as in the procedure 1.
- 6. Repeat 3 times.




- 7. [Initialize Completed] appears after setting and the touch panel is automatically corrected.
- 8. After finishing setting, the [Check] screen is automatically displayed.




Method: Check
Single Tap Check

- 1. Press the indicated three "+", and then check the display position.




- 2. Check that the gap of the X and Y axis of the displayed coordinate is 6 or less.

* :If out of the specified value, select [Initialize] and press the [Start] key to return to Step. 1.




Multi Tap Check

1. Select [Execute] and press the [Start] key.
2. Press 2 points of [] simultaneously. (Step1)
* :Displays the detected point with a red dot if it is out of the default value.
3. Press 2 points of [] simultaneously. (Step2)
* :[Completed] appears in Step1 and Step2 if it is within the default value.



4. [Multi Tap Check completed.] appears when the setting is complete.

**Completion**

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U203 | Check DP operation (Message: Check DP Operation) |
|-------------|---|

Contents

Simulate the original conveying operation separately in the DP.

Purpose

Check the DP operation

Method

1. Press the [Start] key.
2. Place an original in the DP if running this simulation with paper.
3. Select the scan speed

| Items | Contents |
|---------------------|--|
| Normal Speed | Normal scanning (600dpi) |
| High Speed | High speed scanning |
| Mode | Set the conveying timing inspection mode |
| Reset | Reset the conveying timing inspection data |
| Result | Check the conveying timing |

Method: Normal Speed/High Speed

4. Select the item to operate.

| Items | Contents |
|-------------------------|---|
| CCD ADP | With paper, a single-sided original is fed to the CCD |
| CCD RADP | With paper, a double-sided original is fed to the CCD |
| CIS | With paper, a double-sided original is fed to the CIS |
| CCD ADP (Non-P) | Without paper, a single-sided original is fed to the CCD (continuous operation) |
| CCD RADP (Non-P) | Without paper, a double-sided original is fed to the CCD (continuous operation) |
| CIS(Non-P) | Without paper, a double-sided original is fed to the CIS (continuous operation) |

5. Press the [Start] key.

* :The operation starts.

6. To stop the operation, press the [Stop] key.

Setting: Mode

1. Select the item to set.

| Items | Contents |
|------------|---|
| On | Set the conveying timing inspection mode to On |
| Off | Set the conveying timing inspection mode to Off |

2. Press the [Start] key to set the setting value.

Method: Reset

1. Select [Execute].
2. Press the [Start] key to reset.

Method: Result

1. Displays the conveying timing data.

Completion

- Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U204 | Key card/key counter setting (Message: Set Key-Card/Key-Counter) |
|-------------|---|

Contents

Sets the optional key card or key counter connection.

Purpose

Execute when installing the key card or key counter.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|----------------|--|
| Device | Sets the key card/key counter connection. |
| Message | Sets the message indicated when the device is not installed. |

Setting: Device

1. Select the type of the optional counter.

| Items | Contents |
|--------------------|--------------------------|
| Key-Card | Key card installation |
| Key-Counter | Key counter installation |
| Off | Not installed |

* :Initial setting: Off

2. Press the [Start] key to set the setting value.
3. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Setting: Message

1. Select the item to set.

| Items | Contents |
|--------------------|---|
| Key Device | Prioritized display of the key device on the login screen when multiple devices are used. |
| Coin Vendor | Prioritized display of the coin vendor on the login screen when multiple devices are used . |

* :Initial setting: Coin Vendor

2. Press the [Start] key to set the setting value.
3. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

- Press the [Stop] key.
The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U207 | Operation key check (Message: Check Panel Key Operation) |
|-------------|---|

Contents

Check the operation panel keys.

Purpose

Check the operation of all the keys and LEDs on the operation panel.

Method

1. Press the [Start] key to display execution window.
 2. [Count 0] appears and the LED at the most left column in the operation panel is turned on.
 3. Pressing the keys in order from the top at the row where the LED is lit, count increases one by one. When pressing all the keys at the row and there is an LED at the next right side row, the LED is lit.
- * :The job separator LED is lit during execution and turns off when completing.

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U211 | Enhancement unit connection setting (Message: Set Enhancement Connection) |
|-------------|--|

Contents

Execute the inner job separator installation setting.

Purpose

Execute when installing the inner job separator.

- * :Make sure to set to [Off] to prevent wrong LED lighting when not installed.

Method

1. Press the [Start] key.
 2. Select [Inner Job Separator].
- * :The screen for setting is displayed.

| Items | Contents |
|----------------------------|-----------------------------|
| Inner Job Separator | Inner job separator setting |

Method

1. Select the item to set.

| Items | Contents |
|------------|--|
| On | Installing the inner job separator |
| Off | The inner job separator is not installed |

- * :Initial setting: Off

2. Press the [Start] key to set the setting value.
3. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U221 | USB host lock function setting (Message: Set USB Host Lock Function) |
|-------------|---|

Contents

Sets ON/OFF of the USB Host lock function. When setting it to on, the device connected to the USB host is not recognized.

Purpose

Change the setting according to the user's request

Method

1.Press the [Start] key.

2.Select [Host Lock].

* :The screen for setting is displayed.

| Items | Contents |
|------------------|---|
| Host Lock | Turns the USB Host lock function on/off |

3.Select the item to set.

| Items | Contents |
|------------|---|
| On | The USB Host lock function is available |
| Off | The USB Host lock function is not available |

* :Initial setting: Off

4.Press the [Start] key to set the setting value.

5.Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U222 | Setting the IC card type (Message: Set IC Card Type) |
|-------------|---|

Contents

Sets the ID card type

Purpose

Change the type of ID card

Setting

1.Press the [Start] key.

2.Select the item to set.

| Items | Contents |
|--------------|--|
| Other | Select when the ID card type is other than SSFC. |
| SSFC | When the ID card type is SSFC, |

* :Initial setting: Other

3.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U223 | Operation panel lock (Message: Set Panel Operation Lock) |
|-------------|---|

Contents

Execute setting the operation panel function.

Purpose

Execute to prohibit the system menu and job cancel operations from the operation panel by the users other than those with administrator privileges.

Setting

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|-----------------------|--|
| Unlock | Unlock System Menu operation |
| Partial Lock 1 | Lock System Menu operation and Input/Output setting |
| Partial Lock 2 | Lock System Menu operation, Input/Output setting and Job execution setting |
| Partial Lock 3 | Lock System Menu operation, Input/Output setting, Job execution setting and Paper settings |
| Lock | Lock System Menu operation and Job Cancel operation |

* :Initial setting: Unlock

3. Press the [Start] key to set the setting value.

| Operation item | Partial Lock 1 | Lock |
|---|----------------|-------------|
| Entering the maintenance mode | Prohibition | Prohibition |
| Switching to System Menu | Prohibition | Prohibition |
| Send, Send from Document Box | Prohibition | Prohibition |
| Switches the Yellow developer On/Off setting | Prohibition | Prohibition |
| Switch to registration/editing Document Box | Prohibition | Prohibition |
| Pressing the [Stop] key | Permission | Prohibition |
| Pressing the [Status/Job Cancel] key | Permission | Prohibition |
| Disconnect the FAX line | Permission | Prohibition |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U224 | Install Original Panel Display (Message: Install Original Panel Display) |
|-------------|---|

Description

Changes the image data and the message of the opening screen at the machine startup and the image data and the message of the service call screen to user specified data.

Purpose

Set according to the preference of the user.

Setting

1. Write the image data or the message data to the USB memory.
2. Insert USB memory in USB memory slot of the machine.
3. Turn the power switch on.
4. Enter the maintenance item.
5. Press the [Start] key.
6. Select the [Install] or [UnInstall].

| Items | Contents |
|-----------|--|
| Install | Installs the image data or the message data |
| UnInstall | Restores the original image data or message data |

7. Select the item.

| Items | Contents | Display area |
|-----------------|------------------------|---|
| Opening Img | Startup screen | Entire start display |
| Call Img | Service call screen | Graphic display area |
| Home Menu Img | Home Menu screen | Home Menu display area |
| Call Msg Top | Service call message 1 | Message display area (top) |
| Call Msg Detail | Service call message 2 | Message display area (descriptive area) |

8. Press the [Start] key. Installation or uninstallation is started.
9. When normally completed, [OK] is displayed.

Supplement 1**File information**

| Contents | File name | Image size (in pixels) | File format |
|------------------------|----------------------------|----------------------------|-------------------|
| Startup screen | opening_ext_image.png | Length: 480 Width : 800 | PNG |
| Service call screen | callwin_ext_image.png | Length: 200 Width : 180 | PNG |
| Home Menu screen | menu_background.png | Length: 480 Width : 800 | PNG |
| Service call message 1 | callwin_ext_mes_top.txt | - | TEXT (Unicode) |
| Service call message 2 | callwin_ext_mes_detail.txt | - | TEXT (Unicode) |

Supplement 2**Displaying start display**

The pre-installed graphics file is displayed at power on or recovering from sleeping.

Graphics display on service call display

The pre-installed graphics file is displayed at a service call.

How to change the message

Entering #562 (4 letters) using the numeric keypad during a service call display will let service call messages 1 and 2.

How to reset the message display

Reverting the maintenance mode will automatically reset the message to the previous.

Caution

The graphics file for start display must be opaque. (To avoid the background from overlapping at recovering from sleeping.)

The total size of the files installable is approximately 4 MB.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U230 | Optional device serial number (Message: Optional Device Serial No) |
|-------------|---|

Contents

Displays the optional device serial number

Purpose

Specify the production lot from the serial number to make it help of investigation at problem occurrence.

Method

1. Press the [Start] key.

* :Displays the serial number.

| Items | Contents |
|-----------------|--------------------------------------|
| DP | Displays the DP serial number. |
| Finisher | Displays the finisher serial number. |
| PF1 | Displays the PF1 serial number. |
| PF2 | Displays the PF2 serial number. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U234 | Setting destination for punch (Message: Set Punch Destination) |
|-------------|---|

Contents

Sets destination of the punch unit for the finisher.

Purpose

Execute when installing the punch unit for the destination different from the main unit.

Setting

1. Press the [Start] key.

2. Select [Destination].

| Items | Contents |
|----------------------|-----------------------------------|
| Auto | Match the destination setting. |
| Japan Metric | Japan metric |
| Inch | North American inch specification |
| Europe Metric | European metric |

* :Initial setting: Japan Metric

3. Press the [Start] key to set the setting value.

4. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U237 | Finisher eject volume limit (Message: Set Finisher Paper Stack Limit) |
|-------------|--|

Contents

Sets the stacking count of the main tray and middle tray.

Purpose

Execute when stacking failure occurs.

Method

1. Press the [Start] key.
2. Select [Main Tray].
3. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------------|----------------------------------|---------------|-----------------|----------------|
| Main Tray | Main tray stack capacity setting | 0 to 1 | 0 | 1 |

4. Press the [Start] key to set the setting value.

5. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

| Main tray input value | Main Tray | |
|-----------------------|---------------------|---------------------|
| | 3000-sheet finisher | 1000-sheet finisher |
| 0 | 3000 sheets | 1000 sheets |
| 1 | 1500 sheets | 500 sheets |

* :Initial setting: 0

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U240 | Finisher operation check (Message: Check Finisher Operation) |
|-------------|---|

Contents

Turn the finisher's motors and solenoids on.

Purpose

Execute for the finisher's motors and solenoids operation check.

Method

1. Press the [Start] key.
 2. Select the item to operate.
- * :The screen for setting is displayed.

| Items | Contents |
|-----------------|-----------------------------------|
| Motor | Finisher motor operation check |
| Solenoid | Finisher solenoid operation check |
| Mail Box | Mail Box motor operation check |

Method: Motor

1. Select the item to operate.
 2. Press the [Start] key.
- * :The operation starts.

| Items | Contents |
|-------------------------|--|
| Feed In(H) *1 | Drive the DF paper entry motor (DFPEM) at high speed. |
| Feed In(L) *1 | Drive the DF paper entry motor (DFPEM) at low speed. |
| Middle(H) | Drive the DF middle motor (DFMM) at high speed. |
| Middle(L) | Drive the DF middle motor (DFMM) at low speed. |
| Eject Pull(H) | Drive the DF exit motor (DFEM) at high speed in the reversing direction. |
| Eject Pull(L) | Drive the DF exit motor (DFEM) at low speed in the reversing direction. |
| Eject Conv(H) | Drive the DF exit motor (DFEM) at high speed in the conveying direction. |
| Eject Conv(L) | Drive the DF exit motor (DFEM) at low speed in the conveying direction. |
| Tray | Drive the DF tray motor (DFTM). Operation pattern: After descending to the lower limit, ascends and descends again when passing 1s after detecting the middle sensor off. ascends again when detecting the middle sensor on and stops at the upper limit. |
| Staple Move | Drive the DF slide motor (DFSLM) |
| Staple | Drive the DF staple motor (DFSTM) |
| Width Test(A4R) | Drive the DF side registration motor 1,2 (DFSRM1,2) |
| Width Test(LTR) | Drive the DF side registration motor 1,2 (DFSRM1,2) |
| Beat | Drive the DF paddle motor (DFPDM) |
| Eject Unlock(HP) | Drive the DF exit release motor (DFERM) at the home position |

| Items | Contents |
|---------------------------|---|
| Eject Unlock(30) | Drive the DF exit release motor (DFERM) at the 30-sheet bundle position |
| Eject Unlock(50) | Drive the DF exit release motor (DFERM) at the 50-sheet bundle position |
| Eject Unlock(Fix) | Drive the DF exit release motor (DFERM) at the fixed position |
| Eject Unlock(Full) | Drive the DF exit release motor (DFERM) at the full open position |
| Punch *2 | Drive the punch motor (PUM). |
| Push More *2 | Drive the punch slide motor (PUSLM). |

*1: 1000/3000 DF only*2: Punch only

* :To stop the operation, press the [Stop] key.

Method: Solenoid

1.Select the item to operate.

2.Press the [Start] key.

* :The operation starts.

| Items | Contents |
|-----------------------|---|
| Sub Tray *1 | Turn the DF feed-shift solenoid (DFSSOL) on |
| Punch *2 | Turn the punch solenoid (PUSOL) on |
| Feed In *3 | Turn the entry guide solenoid on |
| Press Paper *4 | Turn the paper press solenoid |

*1: 3000 DF only*2: Punch only*3: 1000/3000 DF only*4: Inner DF only

* :To stop the operation, press the [Stop] key.

Method: Mail Box

1.Select the item to operate.

2.Press the [Start] key.

* :The operation starts.

| Items | Contents |
|---------------|--|
| Conv | Drives the MB drive motor (MBDM) to convey paper |
| Branch | Drives the MB drive motor (MBDM) for feed-shift |

* :To stop the operation, press the [Stop] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U241 | Finisher switch check (Message: Check Finisher Switches) |
|-------------|---|

Contents

Displays the status of finisher's switches and sensors operation.

Purpose

Execute for the finisher's switches and sensors operation check.

Method

1. Press the [Start] key.
 2. Select the item to operate.
- * :The screen for setting is displayed.

| Items | Contents |
|-----------------|--|
| Finisher | Finisher switch sensor operation check |
| Mail Box | Mail Box switch sensor operation check |
| Punch | Punch unit switch sensor operation check |

Method: Finisher

1. Check the switches and sensors by manually turning them on/off.

* :The switch indication is inversed when the switch is detected.

| Items | Contents |
|----------------------------|---------------------------------------|
| Front Cover *1 | DF front cover switch (DFFCSW) |
| Eject Cover *2 | DF exit cover switch (DFECSW) |
| Top Cover *3 | DF top cover switch (DFTCSW) |
| Tray U-Limit *1 | DF tay sesor 1: DFTS1 |
| Tray HP2 *2 | DF tay sesor 2: DFTS2 |
| Tray Middle *1 | DF tay sesor 3: DFTS3 |
| Tray L-Limit | DF tay sesor 4: DFTS4 |
| Tray Top *1 | DF tray upper side sensor (DFTUSS) |
| HP | DF paper entry sensor (DFPES) |
| Sub Tray Eject *2 | DF sub tray exit sensor (DFSES) |
| Middle Tray Eject | DF middle exit sensor (DFMES) |
| Staple HP | DF slide sensor (DFSLS) |
| Middle Tray | DF main tray exit sensor (DFMTS) |
| Width Front HP | DF side registration sensor 1 (DFSR1) |
| Width Tail HP | DF side registration sensor 2 (DFSR2) |
| Bundle Eject HP | DF bundle exit sensor (DFBDS) |
| Match Paddle | DF adjustment sensor (DFADS) |
| Lead Paddle | DF paddle sensor (DFPDS) |
| Press Paper Up *4 | DF press paper sensor 1 |
| Press Paper Down *4 | DF press paper sensor 2 |
| Set *4 | DF installation detection switch |

*1: 1000/3000 DF only, *2: 3000 DF only*3: 1000 DF only*4: Inner DF only

Method: Mail Box

1. Check the switches and sensors by manually turning them on/off.

* :The switch indication is inverted when the switch is detected.

| Items | Contents |
|--------------------|--------------------------------------|
| Eject | MB eject sensor (MBES) |
| Cover | MB cover open close switch (MBCOCSW) |
| Over Flow1 | MB overflow sensor 1 (MBOFS1) |
| Over Flow2 | MB overflow sensor 2 (MBOFS2) |
| Over Flow3 | MB overflow sensor 3 (MBOFS3) |
| Over Flow4 | MB overflow sensor 4 (MBOFS4) |
| Over Flow5 | MB overflow sensor 5 (MBOFS5) |
| Over FlowTA | MB overflow sensor tray A |
| Motor HP | MB paper entry sensor (MBPES) |

Method: Punch

1. Check the switches and sensors by manually turning them on/off.

* :The switch indication is inverted when the switch is detected.

| Items | Contents |
|--------------------|------------------------------------|
| Punch HP | Punch home position sensor (PUHPS) |
| Edge Face 2 | Punch paper end sensor (PUPES) |
| Edge Face 4 | Punch paper end sensor (PUPES) |
| Tank | Punch tank set switch (PUTSSW) |
| Tank Full 1 | Punch tank full sensor (PUTFS) |
| Tank Full 2 | Punch tank full sensor (PUTFS) |
| Tank Full 3 | Punch tank full sensor (PUTFS) |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U243 | Checking the DP motor (Message: Check DP Motors) |
|-------------|---|

Contents

Drive the motor or solenoid of the document processor.

Purpose

Check the operation of the motor or solenoid of the document processor.

Method

1. Press the [Start] key.
2. Select the item to operate.

| Items | Contents |
|------------------------|--|
| Feed Motor(CW) | Drive the DP feed motor (DPFM) |
| Feed Motor(CCW) | Reversely drives the DP feed motor (DPFM) |
| Conv Motor(CW) | Rotate the DP conveying motor (DPCM) |
| Conv Motor(CCW) | Rotate the DP conveying motor (DPCM) reversely |
| Rev Motor | Execute the automatic adjustment in the DP feedshift motor (DPFSM) |
| Feed clutch *1 | Drive the DP feed clutch (DPFCL). |

*1: Simultaneous duplex scan model only

3. Press the [Start] key. Each operation starts.

* :To stop the operation, press the [Stop] key.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U244 | DP switch check (Message: Check DP Switches) |
|-------------|---|

Contents

Displays each switch and sensor status of the document processor.

Purpose

Execute to check the operation of switches and sensors of the document processor.

Method

- 1.Press the [Start] key.
- 2.Check the switches and sensors by manually turning them on/off.
* :The switch indication is inversed when the switch is detected.

| Items | Contents |
|---------------------|---|
| Feed *2 | Check the DP feed sensor (DPFS). |
| Regist | Checks the DP registratio sensor (DPRS) |
| Timing *1 | Check the DP timing sensor (DPTS). |
| CIS Head *1 | Check the DPCIS sensor (DPCS). |
| Set | Checks the DP original sensor (DPOS) |
| Longitudinal | Check the DP original length switch (DPOLSW). |
| Cover Open | Check the DP interlock switch (DPILSW) |
| Open | Checks the DP open close switch (DPOCSW) |
| Eject *1 | Check the DP eject sensor (DPES). |

*1: Simultaneous duplex scan model only, *2: Other than simultaneous duplex scan model

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U245 | Checking the message (Message: Check Display Message) |
|-------------|--|

Contents

Displays messages indicated on the touch panel of the operation panel.

Purpose

Execute to check messages indicated.

Method

- 1.Press the [Start] key.
- 2.Using the [▲] [▼] key, display messages in order.
* :Enter the message number using the numeric keys to display the message of the designated number.
- 3.By using the [+] [-] keys key, switch the language.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U246 | Finisher adjustment (Message: Adjust Finisher) |
|-------------|---|

Contents

Execute adjustment for the finisher installation.

Purpose

Punch registration stop timing adjustment in the punch mode.

?Adjust if paper skews or is folded in A z-shape in the punch mode.

Punch position stop timing adjustment in the punch mode.

?Adjust if the punch hole position is not as specified in the punch mode.

Punch center position timing adjustment in the punch mode.

?Adjust the punch center position if it is shifted in the punch mode.

Front/rear width adjuster home position adjustment

Adjust when the consistency of the side registration guides and paper is not good and paper jam occurs.

Front/rear staple home position adjustment

Adjust if the staple is not centered on the paper in the staple mode.

Method

1.Press the [Start] key.

2.Select [Finisher].

* :The screen for setting is displayed.

| Items | Contents |
|-----------------|---------------------------------------|
| Finisher | Setting the finisher adjustment value |

Method: Finisher

1.Select the item to set.

| Items | Contents |
|--------------------------|--|
| Punch Regist *1 | Punch registration stop timing adjustment in the punch mode. |
| Punch Feed *1 | Punch position stop timing adjustment in the punch mode. |
| Punch Width *1 | Punch center position timing adjustment in the punch mode. |
| Width Front HP | Front width adjuster home position adjustment |
| Width Tail HP | Rear width adjuster home position adjustment |
| Staple HP | Front/rear staple home position adjustment |
| Punch(L) Width *1 | Long-edge punch position adjustment (width) |
| 2Punch(L)1 *1 | 2-hole long-edge punch position adjustment (1st hole) |
| 2Punch(L)2 *1 | 2-hole long-edge punch position adjustment (2nd hole) |
| 3/4Punch(L)1 *1 | 3-hole and 4-hole long-edge punch position adjustment (1st hole) |
| 3/4Punch(L)2 *1 | 3-hole and 4-hole long-edge punch position adjustment (2nd hole) |
| 3/4Punch(L)3 *1 | 3-hole and 4-hole long-edge punch position adjustment (3rd hole) |
| 4Punch(L)4 *1 | 4-hole long-edge punch position adjustment (4th hole) |


*1: Only when punch unit is installed

Setting: Punch Regist

1. Select [Punch Regist].
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Content to adjust | Setting range | Initial setting | Data variation |
|--|---------------|-----------------|----------------|
| Adjusting the punch registration stop timing | -20 to 20 | 0 | 0.19mm |

- * :Increase the value if paper is skewed (sample 1).
Reduce the set value if paper is folded in a Z-shape (sample2).




3. Press the [Start] key to set the setting value.

Setting: Punch Feed

1. Select [Punch Feed].
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Content to adjust | Setting range | Initial setting | Data variation |
|---------------------------------|---------------|-----------------|----------------|
| Adjusting the punch stop timing | -10 to 10 | 0 | 0.52mm |

- * :Increase the specified value if the punch position is shorter than specified.
Reduce the specified value if the punch position is longer than specified.




3. Press the [Start] key to set the setting value.

Setting: Punch Width

1. Select [Punch Width].
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Content to adjust | Setting range | Initial setting | Data variation |
|---|---------------|-----------------|----------------|
| Punch center position timing adjustment | -4 to 4 | 0 | 0.52 mm |

- * :Reduce the specified value if the punch position is shorter than specified.
Increase the specified value if the punch position is longer than specified.



- 3.Press the [Start] key to set the setting value.

Setting: Width Front HP / Width Tail HP

- 1.Select [Width Front HP].
- 2.By using the [+] [-] keys or the numeric keys, change the setting value.

| Content to adjust | Setting range | Initial setting | Data variation |
|---|---------------|-----------------|----------------|
| Front width adjuster home position adjustment | -30 to 30 | 0 | 0.97mm |
| Rear width adjuster home position adjustment | -30 to 30 | 0 | 0.97mm |

- 3.Press the [Start] key to set the setting value.
- 4.Press the [Stop] key to return to the screen to select the maintenance item No.
- 5.Enter U240 and select [Motor] and then [Width Test(A4R)].
 - * :The middle tray side registration guides move to A4R size position.
- 6.Insert paper into the side registration guides to check the consistence.
- 7.Repeat the above adjustment until the consistency is appropriate.


Setting: Staple HP

- 1.Select [Staple HP].
- 2.By using the [+] [-] keys or the numeric keys, change the setting value.

| Content to adjust | Setting range | Initial setting | Data variation |
|--|---------------|-----------------|-------------------------|
| Front/rear staple home position adjustment | -15 to 15 | 0 | 0.19 mm *1 0.10mm *2 |

*1: 1000/3000 DF only, *2: Inner DF only

- * :Increase the set value if the staple position is shifted to the machine front side (sample1).
Lower the set value if the staple position is shifted to the machine rear side (sample2).




- 3.Press the [Start] key to set the setting value.

Setting: Punch(L) Width

1. Select [Punch(L) Width].
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Content to adjust | Setting range | Initial setting | Data variation |
|---|---------------|-----------------|----------------|
| Long-edge punch position adjustment (width) | -15 to 15 | 0 | 0.19mm |

- * :Increase the specified value if the punch position is shorter than specified.
Reduce the specified value if the punch position is longer than specified.




3. Press the [Start] key to set the setting value.

Setting: 2Punch(L)1

1. Select [2Punch(L)1].
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Content to adjust | Setting range | Initial setting | Data variation |
|---|---------------|-----------------|----------------|
| 2-hole long-edge punch position adjustment (1st hole) | -10 to 10 | 0 | 0.26mm |

- * :Increase the specified value if the punch position is shorter than specified.
Reduce the specified value if the punch position is longer than specified.




3. Press the [Start] key to set the setting value.

Setting: 2Punch(L)2

1. Select [2Punch(L)2].
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Content to adjust | Setting range | Initial setting | Data variation |
|---|---------------|-----------------|----------------|
| 2-hole long-edge punch position adjustment (2nd hole) | -10 to 10 | 0 | 0.26mm |

- * :Increase the specified value if the punch position is shorter than specified.
 Reduce the specified value if the punch position is longer than specified.




3. Press the [Start] key to set the setting value.

Setting: 3/4Punch(L)1

1. Select [3/4Punch(L)1].
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Content to adjust | Setting range | Initial setting | Data variation |
|--|---------------|-----------------|----------------|
| 3-hole and 4-hole long-edge punch position adjustment (1st hole) | -10 to 10 | 0 | 0.26mm |

- * :Increase the specified value if the punch position is shorter than specified.
Reduce the specified value if the punch position is longer than specified.




3. Press the [Start] key to set the setting value.

Setting: 3/4Punch(L)2

1. Select [3/4Punch(L)2].
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Content to adjust | Setting range | Initial setting | Data variation |
|--|---------------|-----------------|----------------|
| 3-hole and 4-hole long-edge punch position adjustment (2nd hole) | -10 to 10 | 0 | 0.26mm |

- * :Increase the specified value if the punch position is shorter than specified.
Reduce the specified value if the punch position is longer than specified.




3. Press the [Start] key to set the setting value.

Setting: 3/4Punch(L)3

1. Select [3/4Punch(L)3].
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Content to adjust | Setting range | Initial setting | Data variation |
|--|---------------|-----------------|----------------|
| 3-hole and 4-hole long-edge punch position adjustment (3rd hole) | -10 to 10 | 0 | 0.26mm |

- * : Increase the specified value if the punch position is shorter than specified.
Reduce the specified value if the punch position is longer than specified.




3. Press the [Start] key to set the setting value.

Setting: 4Punch(L)4

1. Select [4Punch(L)4].
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Content to adjust | Setting range | Initial setting | Data variation |
|---|---------------|-----------------|----------------|
| 4-hole long-edge punch position adjustment (4th hole) | -10 to 10 | 0 | 0.26mm |

- * : Increase the specified value if the punch position is shorter than specified.
Reduce the specified value if the punch position is longer than specified.



3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

- * : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U247 | Paper feed operation check (Message: Check Paper Feeder) |
|-------------|---|

Contents

Turn the motor and clutch power on for each feed unit.

Purpose

Execute to check motor and clutch operation of each feed unit.

Method

1. Press the [Start] key.
 2. Select the item to operate.
- * :The screen for setting is displayed.

| Items | Contents |
|------------|----------------------------------|
| PF | Operates 1-tray paper feeder |
| 2PF | Operates 2-tray paper feeder |
| LCF | Operate the high capacity feeder |

Setting: PF

1. Select the item to set.

| Display | | Contents |
|----------------|----------------|---------------------------------|
| Motor | Off | PF paper feed motor (PFPFM) OFF |
| | On | PF paper feed motor (PFPFM) ON |
| Clutch | Feed2 Clutch | PF paper feed clutch (PFFCL) ON |
| | V Feed2 Clutch | PF conveying clutch (PFCCL) ON |
| Execute | | Starts operation |

2. Select [Execute].
 3. Press the [Start] key. Starts the motor operation.
- * :To stop the operation of the motor, press the [Stop] key.

Setting: 2PF

1. Select the item to set.

| Display | | Contents |
|----------------|----------------|------------------------------------|
| Motor | Off | PF paper feed motor (PFPFM) OFF |
| | On | PF paper feed motor (PFPFM) ON |
| Clutch | Feed3 Clutch | PF paper feed clutch 1 (PFFCL1) ON |
| | Feed4 Clutch | PF paper feed clutch 2 (PFFCL2) ON |
| | V Feed3 Clutch | PF conveying clutch 1 (PFCCL1) ON |
| | V Feed4 Clutch | PF conveying clutch 2 (PFCCL2) ON |
| Execute | | Starts operation |

2. Select [Execute].
 3. Press the [Start] key. Starts the motor operation.
- * :To stop the operation of the motor, press the [Stop] key.

Setting: LCF

1. Select the item to set.

| Display | | Contents |
|----------------|----------------|---------------------------------|
| Motor | Off | PF paper feed motor (PFPFM) OFF |
| | On | PF paper feed motor (PFPFM) ON |
| Clutch | Feed3 Clutch | PF paper feed clutch (PFFCL) ON |
| | V Feed3 Clutch | PF conveying clutch (PFCCL) ON |
| Execute | | Starts operation |

2. Select [Execute].

3. Press the [Start] key. Starts the motor operation.

* : To stop the operation of the motor, press the [Stop] key.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U250 | Checking/clearing the maintenance cycle (Message: Set Maintenance Counter Pre-set) |
|-------------|---|

Contents

Changes the pre-set values for the maintenance cycle and automatic grayscale adjustment.

Purpose

Change the timing to display the message for maintenance and automatic grayscale adjustment

Setting

1. Press the [Start] key.
2. Select the item to set.
3. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|----------------------------|---|---------------|--|
| M.Cnt A | Changes the maintenance counter (Kit A) | 0 to 9999999 | 200000 ^{*4} 300000 ^{*5} |
| M.Cnt B | Change the maintenance counter preset value (Kit B) | 0 to 9999999 | 200000 ^{*4} 300000 ^{*5} |
| M.Cnt HT | Change the maintenance counter preset value (HT adjustment) | 0 to 9999999 | 0 |
| Casse1 | Change the maintenance counter preset value (Cassette 1) | 0 to 9999999 | 300000 |
| Cass2 ^{*1} | Change the maintenance counter preset value (Cassette 2) | 0 to 9999999 | 300000 |
| Cass3 ^{*2} | Change the maintenance counter preset value (Cassette 3) | 0 to 9999999 | 300000 |
| Cass4 ^{*3} | Change the maintenance counter preset value (Cassette 4) | 0 to 9999999 | 300000 |

^{*1}: 500 PF only, ^{*2}: 500×2/2000 PF only, ^{*3}: 500×2 PF only

^{*4}: 35 ppm model, ^{*5}: 40 ppm model

4. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U251 | Checking/clearing the maintenance counter (Message: Clear Maintenance Counter) |
|-------------|---|

Contents

Displays, clears or changes the maintenance count.

Purpose

Execute to check the maintenance count

Also, clear the count at the maintenance.

Setting

1.Press the [Start] key.

2.Select the item to set.

3.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range |
|-----------------|--|----------------------|
| M.Cnt A | Maintenance cycle counter (Kit A) | 0 to 9999999 |
| M.Cnt B | Maintenance cycle counter (Kit B) | 0 to 9999999 |
| M.Cnt HT | Maintenance cycle counter (HT adjustment) | 0 to 9999999 |
| Cass1 | Maintenance cycle counter value (cassette 1) | 0 to 9999999 |
| Cass2 *1 | Maintenance cycle counter value (cassette 2) | 0 to 9999999 |
| Cass3 *2 | Maintenance cycle counter value (cassette 3) | 0 to 9999999 |
| Cass4 *3 | Maintenance cycle counter value (cassette 4) | 0 to 9999999 |
| Clear | Clears all the maintenance counts | 0 |

*1: 500 PF only, *2: 500×2/2000 PF only, *3: 500×2 PF only

Clearing

1.Select [Clear].

2.Press the [Start] key to clear the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U252 | Destination (Message: Set Destination) |
|-------------|---|

Contents

Switch the operations and screens of the main unit according to the destination.

Purpose

Execute after initializing the backup RAM, in order to return the setting to the value before replacement or initialization

Method

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|-----------------------------------|-----------------|
| Japan Metric^{*1} | Japan metric |
| Inch^{*2} | Inch |
| Europe Metric^{*2} | Europe Metric |
| Asia Pacific^{*2} | Asia Pacific |
| Australia^{*2} | Australia |
| China^{*2} | China |
| Korea^{*2} | Korea |

*1: 100 V model only, *2: Except 100 V model

* :Initial setting: Destination

3. Press the [Start] key.

* :Initializes according to the destination

4. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

* :An error code is displayed when an error occurs.

When errors occur, turn the power switch off then on, and execute initialization using maintenance mode U252.

Error codes

| Items | Contents |
|--------------|---------------------------|
| 0001 | Controller (Entity Error) |
| 0002 | Controller error |
| 0020 | Engine error |
| 0040 | Scanner error |

| | |
|-------------|--|
| U253 | Switching the double/single counts (Message: Set Double/Single Count) |
|-------------|--|

Contents

Switches the count timing for the total counter and other counters by color mode.

Purpose

Select, according to user's request (copy service provider), if the maximum size paper is to be counted as one sheet (single count) or two sheets (double count)

Setting

1. Press the [Start] key.
2. Select [Color] or [B/W].

| Items | Contents |
|----------------------|--|
| Full Color | Switch the counter for full color mode (Single/Double Count) |
| Mono Color *1 | Switch the counter for B/W mode (Single/Double Count) |
| B/W | Switch the counter for B/W mode (Single/Double Count) |

*1: Appears if U276 set to other than [Mode0]

3. Select [SGL(All)] or [DBL(Folio)].

| Items | Contents |
|-------------------|--|
| SGL(All) | Sets single count for all the paper sizes |
| DBL(Legal) | Set single count for Legal size or smaller |
| DBL(Folio) | Set double count for Folio size or larger *2 |

* :Initial setting: SGL(All)

*2: The Folio length can be set to between 318 and 356 mm using maintenance mode U035. However, the double count will be applied when the set value is 330mm (Initial value) or longer.

4. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U260 | Switching the timing for copy counting (Message: Set Copy Count Mode) |
|-------------|--|

Contents

Switches the count timing for the total counter and other counters between paper feed and eject.

Purpose

Change the count timing according to the user's request

Setting

1. Press the [Start] key.
2. Selects the copy count timing.

| Items | Contents |
|--------------|-----------------------------------|
| Feed | When secondary paper feed starts. |
| Eject | Selects the paper eject timing |

* :Initial setting: Eject

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U265 | Setting by destination (Message: Set Model Destination) |
|-------------|--|

Contents

Sets the OEM code.

Purpose

Execute when replacing the main PWB, etc.

Setting

1. Press the [Start] key.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents |
|------------|-----------------------|
| No. | Displays the OEM code |

3. Press the [Start] key to set the setting value.

4. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U271 | Setting the page count unit (Message: Set Page Count Unit) |
|-------------|---|

Contents

Execute the long paper count setting.

Purpose

Execute to change the long paper count.

* :If double count is set in U253, the value multiplied with this is the long paper count.

Setting

- 1.Press the [Start] key.
- 2.Select the item to set.
- 3.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------|---|---------------|-----------------|----------------|
| Banner A | Count setting of Long Paper A (470.1mm to 915mm/18.51" to 36") | 2 to 30 | 2 | - |
| Banner B | Count setting of Long Paper B (915.1mm to 1220mm/36.01" to 48") | 2 to 30 | 3 | - |

- 4.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U276 | Switching the copy count mode (Message: Set Charge Count Mode) |
|-------------|---|

Contents

Set the single color count mode

Purpose

Execute to change the billing counter to count up in the single color mode.

Setting

- 1.Press the [Start] key.
- 2.Select the item to set.

| Items | Contents |
|--------------|--|
| Mode0 | Count the single color count in the full color counter |
| Mode1 | Count the single color count in the single color counter |

* :Initial setting: Mode1

- 3.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U278 | Delivery date setting (Message: Set Delivery Date) |
|-------------|---|

Contents

Registers the date of delivery of the machine.

Purpose

Execute when installing the machine. Execute to check the delivery date of the machine.

Method

- 1.Press the [Start] key.
 - 2.Select [Today].
 - 3.Press the [Start] key.
- * :Sets the delivery date of the machine.

Clearing

- 1.Select [Clear].
 - 2.Press the [Start] key.
- * :Clears the delivery date of the machine.

Completion

Press the [Stop] key.
* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U284 | Setting the 2-color copy (Message: Set 2 Color Copy) |
|-------------|---|

Contents

Sets whether to use the 2-color copy.

Purpose

Change the setting according to the user's request

Setting

- 1.Press the [Start] key.
- 2.Select the item to set.

| Items | Contents |
|-------------------|--|
| B/W | 2-color copy enabled, B/W count |
| Mono Color | 2-color copy enabled, mono color count |
| Off | 2-color copy disabled |

- * :Initial setting: Mono Color
* :When setting it to on, 2-color copy appears on the color function screen.
3.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.
* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U285 | Set Service Status Page (Message: Set Service Status Page) |
|-------------|---|

Contents

Determines whether to display the digital dot coverage report on the report print.

Purpose

Change the setting according to the user's request

Setting

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|--------------|--|
| On | Displays the digital dot coverage. |
| Off | Not to display the digital dot coverage. |

* :Initial setting: On

3. Press the [Start] key. Set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U323 | Abnormal temperature and humidity notification setting (Message: Set Abnormal Heat and Humidity Warning) |
|-------------|---|

Contents

Sets whether to indicate the notification when detecting abnormal temperature and humidity.

Purpose

Change the setting according to the user's request

Setting

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|--------------|--|
| On | Indicate the abnormal temperature and humidity notification |
| Off | Do not indicate the abnormal temperature and humidity notification |

* :Initial setting: On

3. Press the [Start] key. Set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U325 | Paper interval setting (Message: Set Paper Interval (Add Toner)) |
|-------------|---|

Contents

Sets the print interval at high coverage.

Purpose

Changes the print interval at high coverage.

Setting

1. Press the [Start] key.
2. Select the item to set.
3. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|------------------|---|---------------|-----------------|
| Interval | Sets On/Off of print interval at high coverage. | On/Off | Off |
| Average | Set the average number of sheets (parameter) | 1 to 255 | 100 |
| Threshold | Sets the coverage threshold to start lowering. | - | - |
| Rate | Displays the down rate | - | - |

4. Press the [Start] key to set the setting value.

Setting: Threshold

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|----------|--|---------------|-----------------|
| C | Coverage threshold to start lowering for Cyan | 1 to 100 | 15 |
| M | Coverage threshold to start lowering for Magenta | 1 to 100 | 15 |
| Y | Coverage threshold to start lowering for Yellow | 1 to 100 | 15 |
| K | Coverage threshold to start lowering for Black | 1 to 100 | 20 |

3. Press the [Start] key to set the setting value.

Method: Rate

* :Display each setting values.

| Items | Contents | Setting range | Initial setting |
|----------|-------------------|---------------|-----------------|
| C | Cyan down rate | 50 to 100 | 100 |
| M | Magenta down rate | 50 to 100 | 100 |
| Y | Yellow down rate | 50 to 100 | 100 |
| K | Black down rate | 50 to 100 | 100 |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U326 | Black line cleaning indication (Message: Set Black Line Clean Display) |
|-------------|---|

Contents

Sets whether to indicate the black lines cleaning guidance when detecting black lines.

Purpose

Displays the cleaning guidance to reduce the service call with the black lines by dust on the contact glass when scanning from the document processor.

Method

1. Press the [Start] key.
2. Select the item to set.
 - * :The screen for setting is displayed.

| Items | Contents |
|------------------------|--|
| Black Line Mode | Sets On/Off of the black line cleaning guidance indication |

3. Select the item to set.

| Items | Contents |
|------------|---|
| On | Indicate the black lines cleaning guidance |
| Off | Black line cleaning guidance is not indicated |

* :Initial setting: On

4. Press the [Start] key. Set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U327 | Cassette heater control setting (Message: Set Cassette Heater Control) |
|-------------|---|

Contents

Selects the cassette heater control setting.

Purpose

Selects the cassette heater control setting

Sets the cassette heater for the optional cassette.

Method

- 1.Press the [Start] key.
- 2.Select the item to set.

| Items | Contents |
|--------------|---|
| On | Sets the cassette heater control On (installed). |
| Off | Sets the cassette heater control Off (not installed). |

* :Initial setting: Off

* :Drum refresh is not executed at power-up when the cassette heater control is [On].

- 3.Press the [Start] key. Set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U332 | Adjusting the black coverage coefficient (Message: Adjust Coverage Size Calculation Rate) |
|-------------|--|

Contents

Sets the coefficient of custom size with A4/Letter size. The coefficient set here is used to convert the black ratio in relation to the A4/Letter size and to display the result in the service status page.

Purpose

Set the coefficient for converting the black ratio for custom sizes in relation to the A4/Letter size

Setting

- 1.Press the [Start] key.
- 2.Select the item to set.
- 3.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|---------------|--|---------------------------------|------------------------|
| Rate | Set the coefficient for converting the black ratio for custom sizes in relation to the A4/Letter size. | 0.1 to 3.0 | 1.0 |
| Mode | Switch full-color count and color coverage count display | 0: Full color 1: by coverage | 0 |
| Level1 | Sets low coverage threshold value | 0.1 to 99.8 | 1.0 |
| Level2 | Sets middle coverage threshold value | 0.2 to 99.9 | 2.5 |

- 4.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U341 | Printer cassette setting (Message: Set Printer Exclusive Cassette) |
|-------------|---|

Contents

Sets the cassette to printer output only.

Purpose

Execute it when securing a cassette for printer. The cassette set to on is for printer only and it cannot be used for copy.

Setting

1. Press the [Start] key.
2. Select the item to set.

* : Multiple cassettes are selectable.

| Items | Contents |
|---------------------------------|---|
| Cassette1 | Setting cassette 1 to the printer paper source |
| Cassette2 * ¹ | Setting cassette 2 to the printer paper source (paper feeder) |
| Cassette3 * ² | Setting cassette 3 to the printer paper source (paper feeder) |
| Cassette4 * ³ | Setting cassette 4 to the printer paper source (paper feeder) |

*¹: 500 PF only, *²: 500×2/2000 PF only, *³: 500×2 PF only

* : Initial setting: Off (Cassette1?4)

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U343 | Duplex priority mode (Message: Set Duplex Priority Mode) |
|-------------|---|

Contents

Switches between duplex or simplex copy for the initial copy mode.

Purpose

Set the frequently used settings depending on the user's usage.

Setting

1. Press the [Start] key.
- * : Select the item to set.

| Items | Contents |
|------------|------------------|
| On | Duplex copy |
| Off | Single-side copy |

* : Initial setting: Off

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U345 | Setting the value for maintenance due indication (Message: Set Maintenance Time Soon Display) |
|-------------|--|

Contents

Sets when to display a message notifying that the time for maintenance is about to reach, by setting the number of prints that can be made before the current maintenance cycle reaches. Displays the maintenance precaution message when the page count reaches the set value before the maintenance count.

Purpose

Change the time for maintenance precaution display.

Setting

1. Press the [Start] key.
2. Select the item to set.
3. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|-----------------|---|---------------|-----------------|
| Cnt | Setting the maintenance time precaution display (Remaining number of prints that can be made before the current maintenance cycle reaches) | 0 to 9999 | 0 |
| SSD Life | Setting the maintenance time precaution display for the SSD replacement. | 0 to 99 | 5(%) |

4. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U346 | Selecting Sleep Mode (Message: Selecting Sleep Mode) |
|-------------|---|

Contents

Changes the sleep mode settings.

Purpose

Changes the sleep mode settings.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|--------------------------|-------------------------------------|
| Timer/Sleep Level | BAM conformity country setting |
| Auto sleep | Switches AutoSleep function setting |
| Power Off Setting | Set display for the power shutdown |

Setting: Timer/Sleep Level

1. Select the item to set.

| Items | Contents |
|-------------------------|--|
| More Energy Save | BAM conformity setting On Sleep mode is disabled (Quick Recovery setting is disabled) |
| Less Energy Save | BAM conformity setting Off Sets Sleep Level (Quick Recovery or Energy Saver) |

* :Initial setting: More Energy Save

2. Press the [Start] key. Set the setting value.
3. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Setting: Auto sleep

1. Select the item to set.

| Items | Contents |
|------------|--|
| On | The sleep mode is disabled from the system menu. |
| Off | The sleep mode is enabled from the system menu. |

* :Initial setting: On

2. Press the [Start] key to set the setting value.

Setting: Power Off Setting

1. Select the item to set.

| Items | Contents |
|---------------------|--|
| User Confirm | Sets the user check screen |
| Msg - Remote | Set the warning message - remote disconnection |

* :Initial setting: On

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U402 | Adjusting the printing margins (Message: Adjust Print Margin) |
|-------------|--|

Contents

Adjusts the scan image margins.

Purpose

Make the adjustment if margins are incorrect

* :If the leading edge margin is less than the specified value, it may cause jam at the fuser.

* :If there is no bottom margin, when continuously printing, it may cause an image smudge on the second page.

Adjustment

- 1.Press the [Start] key.
- 2.Press the [System Menu] key.
- 3.Press the [Start] key to output a test pattern.
- 4.Press the [System Menu] key.
- 5.Select the item to set.

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------|---|---------------|-----------------|----------------|
| Lead | Adjusts the printer leading edge margin | 0.0 to 10.0 | 4.0 | 0.1 mm |
| A Margin | Printer left margin | 0.0 to 10.0 | 3.0 | 0.1 mm |
| C Margin | Printer right margin | 0.0 to 10.0 | 3.0 | 0.1 mm |
| Trail | Printer trailing edge margin | 0.0 to 10.0 | 3.9 | 0.1 mm |

- 6.By using the [+] [-] keys or the numeric keys, change the setting value.

* :When the setting value is increased, the margin widens, and it narrows when the setting value is decreased.




Figure 6-39

- 7.Press the [Start] key to set the setting value.

Precautions

Appropriate margins are not obtained after this adjustment, execute the following maintenance mode.

U034 (P.6-228) > U402

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U403 | Adjusting margins for scanning an original on the contact glass (Message: Adjust Scanning Margin(Table)) |
|-------------|---|

Contents

Adjusts the margins for the table scanning.

Purpose

Make the adjustment if margins are incorrect

Adjustment

- 1.Press the [Start] key.
- 2.Press the [System Menu] key.
- 3.Place an original and press the [Start] key to make a test copy.
- 4.Press the [System Menu] key.
- 5.Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------|--|---------------|-----------------|----------------|
| A Margin | Adjusts the scanner left margin | 0.0 to 10.0 | 2.0 | 0.5mm |
| B Margin | Adjusts the scanner leading edge margin. | 0.0 to 10.0 | 2.0 | 0.5mm |
| C Margin | Adjusts the scanner right margin | 0.0 to 10.0 | 2.0 | 0.5mm |
| D Margin | Adjusts the scanner trailing edge margin | 0.0 to 10.0 | 2.0 | 0.5mm |

6.By using the [+] [-] keys or the numeric keys, change the setting value.

* :When the setting value is increased, the margin widens, and it narrows when the setting value is decreased.




Figure 6-40

7.Press the [Start] key to set the setting value.

Precautions

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034(P.6-228) > U402(P.6-334) > U403

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U404 | Adjusting margins for scanning an original from the document processor (Message: Adjust Scanning Margin(DP)) |
|-------------|---|

Contents

Adjusts the margins for DP scanning.

Purpose

Make the adjustment if margins are incorrect

Adjustment

1. Press the [Start] key.
2. Press the [System Menu] key.
3. Place an original on the DP and press the [Start] key to make a test copy.
4. Press the [System Menu] key.
5. Select the item to adjust.

| Items | Contents | Setting range | Initial setting | Data variation |
|--------------------------|--|---------------|-----------------|----------------|
| A Margin | Adjusts the DP left margin | 0.0 to 10.0 | 3.0 | 0.5mm |
| B Margin | Adjusts the DP leading edge margin | 0.0 to 10.0 | 2.5 | 0.5mm |
| C Margin | Sets the DP right margin | 0.0 to 10.0 | 3.0 | 0.5mm |
| D Margin | Adjusts the DP trailing edge margin | 0.0 to 10.0 | 4.0 | 0.5mm |
| A Margin(Back) *1 | Adjusts the DP left margin (2nd side) | 0.0 to 10.0 | 3.0 | 0.5mm |
| B Margin(Back) *1 | Adjusts the DP leading edge margin (2nd side) | 0.0 to 10.0 | 2.5 | 0.5mm |
| C Margin(Back) *1 | Adjusts the DP right margin (2nd side) | 0.0 to 10.0 | 3.0 | 0.5mm |
| D Margin(Back) *1 | Adjusts the DP trailing edge margin (2nd side) | 0.0 to 10.0 | 4.0 | 0.5mm |

*1: Simultaneous duplex scan model only

6. By using the [+] [-] keys or the numeric keys, change the setting value.

*: When the setting value is increased, the margin widens, and it narrows when the setting value is decreased.




Figure 6-41

7. Press the [Start] key to set the setting value.

Precautions

Check the copy image after the adjustment. If the image is still incorrect, adjust the following in the maintenance mode.

U034 (P.6-228) > U402 (P.6-334) > U403 (P.6-335) > U404

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U407 | Adjusting the writing timing (Duplex/Reversal) (Message: Adjust Scanning Margin(DP)) |
|-------------|---|

Contents

Adjusts the writing timing when duplex printing.

Purpose

Adjusted when the back page image of duplex copying is printed in rotated 180 degrees from the scanner reading image (image on the memory)

Precautions

Adjust this after finishing the following maintenance modes.

U034(P.6-228) > U402(P.6-334) > U66(P.6-240)>

U403 (P.6-335) > U71 (P.6-244) > U404 (P.6-336) > U407

Adjustment

- 1.Press the [Start] key.
- 2.Press the [System Menu] key.
- 3.Place an original on the DP and press the [Start] key to make a test copy.
- 4.Press the [System Menu] key.
- 5.Select [Adj Data].

| Items | Contents | Setting range | Initial setting | Data variation |
|-----------------|--|---------------|-----------------|----------------|
| Adj Data | Adjusts the leading edge timing when writing the image in the memory | -47 to 47 | 0 | 1dot |

- 6.By using the [+] [-] keys or the numeric keys, change the setting value.

For the copy example 1, increase the value.

For the copy example 2, decrease the value.

* :When the setting value is increased, the image moves forward, and it moves backward when the setting value is decreased.

Leading edge registration of the copy image (+1.0/-1.5 mm or less)




Figure 6-42

- 7.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U410 | Adjusting the halftone automatically (Message: Half Tone Auto Adjustment) |
|-------------|--|

Contents

Acquires the data for the automatic halftone adjustment and ID correction.

Purpose

Execute when the quality of reproduced halftones has dropped

Adjustment

1. Press the [Start] key.
 - * :Displays the execution information screen.
 - * :Test pattern 1, Test patter 2 and Test pattern 3 are output on the A4 paper.
2. Set the test pattern output on the original glass with the arrow facing the rear side and print side face-down.
 - * :Load about 20 sheets of the blank paper on Test Pattern 1.




Figure 6-43

3. Press the [Start] key.
 - * :The first auto adjustment is executed.
4. Set the output Test Pattern 2 as the original.
 - * :Load about 20 sheets of the blank paper on Test Pattern 2.
5. Press the [Start] key.
 - * :The second auto adjustment is executed.
6. Set the output Test Pattern 3 as the original.
 - * :Load about 20 sheets of the blank paper on Test Pattern 3.
7. Press the [Start] key.
 - * :The third auto adjustment is executed and Test pattern 4 is output.
8. Set the output Test Pattern 4 as the original.
 - * :Load about 20 sheets of the blank paper on Test Pattern 4.
9. Press the [Start] key.
 - * :The 4th auto adjustment is executed.
10. [Finish] appears after normal completion.
11. An error code appears when an error occurs.

Error codes

| Codes | Occurrence position | Contents |
|--------------|----------------------------|--|
| S001 | Scanner | Original reference patch is not detected |
| S002 | | Original deviation is in excess in the main scanning direction |
| S003 | | Original deviation is in excess in the sub-scanning direction |
| S004 | | Original skew is in excess |
| S005 | | Original type error |
| SFFF | | Other scanner error |
| E001 | Engine | Engine status error |
| E002 | | Adjustment result error |
| EFFF | | Other engine error |
| C001 | Controller | Pause status |
| C002 | | Adjustment result error |
| C110 | | Adjustment value (increase amount) value error (black) |
| C120 | | Adjustment value (increase amount) value error (cyan) |
| C140 | | Adjustment value (increase amount) value error (magenta) |
| C180 | | Adjustment value (increase amount) value error (yellow) |
| C210 | | Adjustment value (increase rate) error (black) |
| C220 | | Adjustment value (increase rate) value error (cyan) |
| C240 | | Adjustment value (increase rate) value error (magenta) |
| C280 | | Adjustment value (increase rate) value error (yellow) |
| CFFF | | Other controller error |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U411 | Scanner auto adjustment (Message: Scanner Auto Adjustment) |
|-------------|---|

Contents



Uses the specified originals and automatically adjusts the following items in the scanner and the DP scanning sections.

Scanner section: Original size magnification, leading edge timing, center line, chromatic aberration in main/sub scanning direction, MTF correction, color/monochrome input gamma, color correction matrix automatic adjustment

DP scanning section: Original size magnification, leading edge timing and center line MTF correction, Input gamma, automatic adjustment of color correction matrix


Purpose

Automatically adjusts the scanner and the DP scanning sections.

| Items | Contents | Original for adjustment (P/N) |
|--|---|---|
| Table (Chart A) | Automatically adjusts the table scanning. Magnification in the sub scanning direction / Leading edge timing Center line / chromatic aberration Sub scanning chromatic aberration / MTF correction gamma in color mode / color correction matrix Input gamma in monochrome mode | 7505000107  |
| DP FU(ChartB) DP FD(ChartB) | Execute the 1st side automatic adjustment in the DP scanning section. Execute the 2nd side automatic adjustment in the DP scanning section. Magnification in the sub-scanning direction Leading edge timing Center line Trailing edge timing | 7505000106  |
| DP FU(ChartA) | Execute the 1st side automatic adjustment in the DP scanning section. Main scanning chromatic aberration / sub scanning chromatic aberration / MTF correction gamma in color mode / color correction matrix Input gamma in monochrome mode | 7505000107 |

| Items | Contents | Original for adjustment (P/N) |
|--------------------------|---|---|
| DP FD(ChartA) | Execute the 2nd side automatic adjustment in the DP scanning section. Main scanning chromatic aberration / sub scanning chromatic aberration / MTF correction gamma in color mode / color correction matrix | 7505000107 |
| Target | Set-up for obtaining the target value | 7505000107 |
| DP Auto Adj | Adjusting the document processor scanning section with the chart output by the local machine Magnification in the sub-scanning direction Leading edge timing Center line | Without Chart B, executed in a simplified manner. |

*: Cut the trailing edge of the DP adjustment original (ChartB) as shown below.



Method: Table (Chart A)

Automatic input of the target value

* :Usually, it adjusts here.

- 1.Set the specified original (P/N: 7505000107) on the table.
- 2.Enter maintenance item U411.
- 3.Select [Target].
- 4.Select [Auto].
- 5.Press the [Start] key.
- 6.Select [Table(ChartA)].
- 7.Press the [Start] key to read the barcode of the original chart and to start the automatic adjustment.
- 8.When automatic adjustment has normally completed, [OK] is displayed.

* :When the error code "1e" or "1f" is displayed during the automatic adjustment in the table scanning and the barcode is not read, adjust the following after manually inputting the target value.

Manual input of the target value

- 1.Enter the target values which are shown on the lower part of the front page of the adjustment original (P/N: 7505000107) by executing the maintenance mode U425.
- 2.Set the specified original (P/N: 7505000107) on the table.
- 3.Enter maintenance item U411.
- 4.Select [Target].
- 5.Select [U425].

6. Press the [Start] key.
7. Select [Table(ChartA)].
8. Press the [Start] key to start Auto adjustment.
9. When automatic adjustment has normally completed, [OK] is displayed.

If the image position is shifted largely at the DP adjustment below, an error might occur when adjusting it with ChartA. First, use ChartB (image position) to adjust it and then use ChartA (color).

Method: DP FU (Chart B)

* :Adjusting the first side of the DP duplex scanning

1. Set the specified original (P/N: 7505000106) face-up on the DP.
2. Enter maintenance item U411.
3. Select [DP FU(ChartB)].
4. Press the [Start] key to start Auto adjustment.
5. When automatic adjustment has normally completed, [OK] is displayed.

Method: DP FD (Chart B)

* :Adjusting the second side of the DP duplex scanning

1. Set the specified original (P/N: 7505000106) face-up on the DP.
2. Enter maintenance item U411.
3. Select [DP FD(ChartB)].
4. Press the [Start] key to start Auto adjustment.
5. When automatic adjustment has normally completed, [OK] is displayed.

Method: DP FU (Chart A)

Automatic input of the target value

1. Set the specified original (P/N: 7505000107) face-up on the DP.
2. Enter maintenance item U411.
3. Select [Target].
4. Select [Auto].
5. Press the [Start] key.
6. Select [DP FU(ChartA)].
7. Press the [Start] key to read the barcode of the original chart and to start the automatic adjustment.
8. When automatic adjustment has normally completed, [OK] is displayed.

* :When the error code "1e" or "1f" is displayed during the automatic adjustment in the DP scanning and the barcode is not read, adjust the following after manually inputting the target value.

Manual input of the target value

1. Enter the target values which are shown on the lower part of the front page of the adjustment original (P/N: 7505000107) by executing the maintenance mode U425.
2. Set the specified original (P/N: 7505000107) face-up on the DP.
3. Enter maintenance item U411.
4. Select [Target].
5. Select [U425].
6. Press the [Start] key.
7. Select [DP FU(ChartA)].
8. Press the [Start] key to start Auto adjustment.
9. When automatic adjustment has normally completed, [OK] is displayed.

Method: DP FD (Chart A)**Automatic input of the target value**

1. Set the specified original (P/N: 7505000107) face-up on the DP.
2. Enter maintenance item U411.
3. Select [Target].
4. Select [Auto].
5. Press the [Start] key.
6. Select [DP FD(ChartA)].
7. Press the [Start] key to read the barcode of the original chart and to start the automatic adjustment.
8. When automatic adjustment has normally completed, [OK] is displayed.

* :When the error code "1e" or "1f" is displayed during the automatic adjustment in the DP scanning and the barcode is not read, adjust the following after manually inputting the target value.

Manual input of the target value

1. Enter the target values which are shown on the lower part of the front page of the adjustment original (P/N: 7505000107) by executing the maintenance mode U425.
2. Set the specified original (P/N: 7505000107) face-up on the DP.
3. Enter maintenance item U411.
4. Select [Target].
5. Select [U425].
6. Press the [Start] key.
7. Select [DP FU(ChartA)].
8. Press the [Start] key to start Auto adjustment.
9. When automatic adjustment has normally completed, [OK] is displayed.

Method: DP Auto Adj

1. Set A4/Letter paper.
2. Press the [Start] key to print the adjustment original.
3. Set the adjustment original output on the table and press the [Start] key.
4. Set the output adjustment original with face-up on the DP.
5. Press the [Start] key and scan the original.
6. Press the [Start] key to start the 1st side automatic adjustment.
7. Set the output adjustment original with face-up on the DP.
8. Press the [Start] key and scan the original.
9. Press the [Start] key to start the 2nd side automatic adjustment.

* :When automatic adjustment has normally completed, [OK] is displayed. If an error occurs during auto adjustment, error code "NGXX" is displayed and operation stops. In this case, check the error and execute the automatic adjustment again.

Error codes

| Codes | Contents | Corrective action |
|-------|---|--|
| 00 | Automatic adjustment success | - |
| 01 | Black band detection error (Table scanning leading edge skew in the sub-scanning direction) | 1. Set the original correctly and execute the adjustment again. 2. Check lighting of the lamp or replace it. |
| 04 | Black band is not detected (Table leading edge in the sub-scanning direction) | |
| 05 | Black band is not detected (Table far end in the main scanning direction) | |
| 06 | Black band is not detected (Table near end in the main scanning direction) | |
| 07 | Black band is not detected (Table trailing edge in the sub-scanning direction) | |
| 08 | Black band is not detected (DP far end in the main scanning direction) | |
| 09 | Black band is not detected (DP near end in the main scanning direction) | |
| 0a | Black band is not detected (DP leading edge in the sub-scanning direction) | 1. Check the attachment position of DP. 2. Check lighting of the lamp or replace it. 3. Check the back and front of the adjustment original. |
| 0b | Black band is not detected (Original check of DP leading edge in the sub-scanning direction) | |
| 0c | Black band is not detected (DP trailing edge in the sub-scanning direction) | |
| 0d | White band is not detected (DP trailing edge in the sub-scanning direction) | |
| 0e | DMA time out | |
| 0f | Magnification error in the sub-scanning direction | 1. Turn the power switch off then on, and execute again. 2. Adjust manually. (U065 to U067, U070 to U072) |
| 10 | Leading edge error in the sub-scanning direction | |
| 11 | Trailing edge error in the sub-scanning direction | |
| 12 | DP skew error in the sub-scanning direction | |
| 13 | Maintenance request error | Turn the power switch off then on, and execute again. |
| 14 | Center line error in the main scanning direction | 1. Turn the power off and on, and execute again. 2. Adjust manually. (U065 to U067, U070 to U072) |
| 15 | DP skew error in the main scanning direction | |
| 16 | Magnification error in the main scanning direction | |

| Codes | Contents | Corrective action |
|-------------------------------------|--|--|
| 17 | Service call error | Turn the power off and on, and execute again. |
| 18 | DP paper jam error | Set the original correctly and execute again. |
| 19 | PWB replacement error | - |
| 1a | Original error | Clean the contact glass and slit glass. Exchange the adjustment original. |
| 1b 1c 1d | Input gamma adjustment original error Matrix adjustment original error Original for the white reference correction coefficient error | Set the original correctly and execute again. |
| 1e | Lab value detection error | Check the following and execute again. Is the bar code dirty? Is the original position correct? Is the bar code position correct? |
| 1f | Lab value comparison error | Check the following and execute again. Is the acquired bar code the same? Is the original position correct? Is the bar code position correct? |
| 20 21 30 | Input gamma correction coefficient error Color correction matrix coefficient error Chromatic aberration adjustment original error | Set the original correctly and execute again. |
| 63 | Completed to obtain the test RAW | - |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U412 | Adjusting the uneven density (Message: Adjust Uneven Density) |
|-------------|--|

Contents

Scan the test pattern image distribution directly from the scanner .

Purpose

Execute when the drum unit or laser scanner unit is replaced.

Correct uneven developer/transfer density in the main scanning direction.

* :After completing, execute maintenance mode U464 [Calibration].

Method

1.Press the [Start] key.

2.Select the item to set.

* :The screen for executing is displayed.

| Items | Contents |
|----------------------|--|
| Normal Mode | Normal Mode |
| On/Off Config | Uneven density correction On/Off setting |

Method: Normal Mode

1.Press the [Start] key.

* :Output the test patten with the initial light intensity setting. (1st sheet)

2.Set the test pattern 1 and place approximately 20 sheets of white paper on it.

3.Press the [Start] key. Scanning starts.

* :Test pattern is output after completing scanning. (2nd sheet)

* :According to the test pattern of 1st sheet, output with -20% light intensity setting.

4.Set the test pattern 1 and place approximately 20 sheets of white paper on it.

5.Press the [Start] key. Scanning starts.

* :Test pattern is output after completing scanning. (3rd sheet)

6.Set the test pattern 1 and place approximately 20 sheets of white paper on it.

7.Press the [Start] key.

* :Check the correction result. [Finish] appears after normal completion.

1st retrial

8.[Retry] appears unless normally completed.

9.Execute Step 3 to 7

2nd retrial

10.[Retry] appears unless normally completed.

11.Execute Step 3 to 7

* :An error code appears when an error occurs.

Error codes list

| Display | Contents | Display | Contents |
|---------|--|---------|------------------------|
| S001 | Patch is not detected | E002 | Background image error |
| S002 | Original position shift in the main scanning direction | E003 | Density error |
| S003 | Original position shift in the sub-scanning direction | E004 | Uneven density error |
| S004 | Original skew error | FFFF | Other engine error |
| S005 | Original type error | C001 | Controller error |
| SFFF | Other scanner error | CFFF | Other controller error |
| E001 | Engine status error | | |

Setting: On/Off Config

1. Select the item to set.

| Items | Contents |
|-------|---------------------------------------|
| On | Enable the uneven density correction |
| Off | Disable the uneven density correction |

* :Initial setting: On

* :Automatically set to on after completing correction.

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U425 | Set Target (Message: Set Target) |
|-------------|---|

Contents

Enter the lab values which are shown on the back page of the adjustment original (P/N: 7505000107).

Purpose

Enter data in order to correct for differences in originals during the automatic adjustment

Method

- 1.Press the [Start] key.
- 2.Select the item to set.

| Items | Contents |
|---------------|--|
| ChartA | Setting the adjustment value of the table scanning |
| ChartB | Sets the adjustment value of the DP scanning |

Method: ChartA

- 1.Press the [Start] key.
- 2.Select the item to set.

| Items | Contents |
|------------------------|---|
| White | Setting the white patch for the adjustment original |
| Black | Setting the black patch for the adjustment original |
| Gray1 | Setting the Gray1 patch for the adjustment original |
| Gray2 | Setting the Gray2 patch for the adjustment original |
| Gray3 | Setting the Gray3 patch for the adjustment original |
| C | Setting the cyan patch for the adjustment original |
| M | Setting the magenta patch for the adjustment original |
| Y | Setting the yellow patch for the adjustment original |
| R | Setting the red patch for the adjustment original |
| G | Setting the green patch for the adjustment original |
| B | Setting the blue patch for the adjustment original |
| Adjust Original | Setting the main scanning and sub-scanning directions |

Setting: White

- 1.Select the item to set.
- 2.By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 93.6 | - |
| a | A value setting | -200.0 to 200.0 | 0.9 | - |
| b | B value setting | -200.0 to 200.0 | -0.4 | - |

- 3.Press the [Start] key to set the setting value.

Setting: Black

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 10.6 | - |
| a | A value setting | -200.0 to 200.0 | -0.2 | - |
| b | B value setting | -200.0 to 200.0 | -0.7 | - |

3. Press the [Start] key to set the setting value.

Setting: Gray1

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 76.2 | - |
| a | A value setting | -200.0 to 200.0 | -0.2 | - |
| b | B value setting | -200.0 to 200.0 | 1.2 | - |

3. Press the [Start] key to set the setting value.

Setting: Gray2

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 25.2 | - |
| a | A value setting | -200.0 to 200.0 | -0.2 | - |
| b | B value setting | -200.0 to 200.0 | -0.2 | - |

3. Press the [Start] key to set the setting value.

Setting: Gray3

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 51.3 | - |
| a | A value setting | -200.0 to 200.0 | -0.3 | - |
| b | B value setting | -200.0 to 200.0 | 0.3 | - |

3. Press the [Start] key to set the setting value.

Setting: C

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 72.6 | - |
| a | A value setting | -200.0 to 200.0 | -32.8 | - |
| b | B value setting | -200.0 to 200.0 | -11.5 | - |

3. Press the [Start] key to set the setting value.

Setting: M

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 48.1 | - |
| a | A value setting | -200.0 to 200.0 | 69.9 | - |
| b | B value setting | -200.0 to 200.0 | -6.1 | - |

3. Press the [Start] key to set the setting value.

Setting: Y

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 86.2 | - |
| a | A value setting | -200.0 to 200.0 | -18.6 | - |
| b | B value setting | -200.0 to 200.0 | 81.7 | - |

3. Press the [Start] key to set the setting value.

Setting: R

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|-------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 46.7 | - |
| a | A value setting | -200.0 to 200.0 | 54.2 | - |
| b | B value setting | -200.0 to 200.0 | 38.6 | - |

3. Press the [Start] key to set the setting value.

Setting: G

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 67.8 | - |
| a | A value setting | -200.0 to 200.0 | -51.3 | - |
| b | B value setting | -200.0 to 200.0 | 48.9 | - |

3. Press the [Start] key to set the setting value.

Setting: B

1. Select the item to set.
2. By using [Left/Right cursor] keys or the numeric keys, enter the values which are shown on the back page of the adjustment original.

| Items | Contents | Setting range | Initial setting | Data variation |
|----------|---------------------|-----------------|-----------------|----------------|
| L | L parameter setting | 0.0 to 100.0 | 38.8 | - |
| a | A value setting | -200.0 to 200.0 | 25.3 | - |
| b | B value setting | -200.0 to 200.0 | -22.8 | - |

3. Press the [Start] key to set the setting value.

Setting: Adjust Original

* : This setting is usually unnecessary.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------------|--|----------------|-----------------|----------------|
| Lead | Set the adjustment value of the leading edge. | 4.0 to 6.0 | 5.0 | 0.1mm |
| Main Scan | Sets the adjustment value of the left edge. | 9.0 to 11.0 | 10.0 | 0.1mm |
| Sub Scan | Set the adjustment value of the trailing edge. | 265.0 to 267.0 | 266.0 | 0.1mm |

1. Measure the distances "A", "B" and "C" from the upper edge of black belt 1 to the lower edge of black belt 3 of the adjustment original.
Measurement procedure
1) Measure the distance "A", "B" and "C" between two points as follows. (A: 30mm from the left edge, B: 105mm from the left edge, C: 180mm from the left edge)
? Measure the distance from the leading edge to the top edge of black belt 1.
2) Apply the following formula for the values obtained: $((A+B+C)/3)$
2. Enter the value solved in "Lead" using the the [+] [-] keys keys.
3. Press the [Start] key to set the setting value.
4. Measure the distance "F" from the left edge to the right edge of black belt 2 on the adjustment original.
Measurement procedure
Measure the distance "F" from the left edge at 21mm from the top edge of black belt 1 to the right edge of black belt 2.
5. Enter the values measured in "Main Scan" using the the [+] [-] keys keys.

6. Press the [Start] key to set the setting value.
7. Measure the distance "D" and "E" from the top edge of black belt 1 to the bottom edge of black belt 3 on the adjustment original at two positions.
Measurement procedure
 - 1) Measure the distance "D" and "E" between two points as follows. (D: Measure the distance from the leading edge to the trailing edge of black belt 3 on the adjustment original at 30mm of the left edge and deduct A. E: Measure the distance from the leading edge to the trailing edge of black belt 3 on the adjustment original at 180mm of the left edge and deduct C.)
 - 2) Apply the following formula for the values obtained: $(D/2+E/2)$
8. Enter the value solved in "Sub Scan" using the the [+] [-] keys keys.
9. Press the [Start] key to set the setting value.





Figure 6-44

Setting: DP(ChartB)

* :This setting is usually unnecessary.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------------|--|----------------|-----------------|----------------|
| Lead | Set the adjustment value of the leading edge. | 14.0 to 16.0 | 15.0 | 0.1mm |
| Main Scan | Sets the adjustment value of the left edge. | 14.0 to 16.0 | 15.0 | 0.1mm |
| Sub Scan | Set the adjustment value of the trailing edge. | 265.0 to 269.0 | 267.0 | 0.1mm |

- 1.Measure the distance "A" from the leading edge to the black belt (inside) on the adjustment original.
- 2.Enter the value solved in "Lead" using the the [+] [-] keys keys.
- 3.Measure the distance "B" from the left edge to the black belt (inside) on the adjustment original.
- 4.Enter the values measured in "Main Scan" using the the [+] [-] keys keys.
- 5.Measure the distance "C" from the leading black belt (inside) to the trailing black belt (inside) on the adjustment original.
- 6.Enter the values measured in "Sub Scan" using the the [+] [-] keys keys.
- 7.Press the [Start] key to set the setting value.



Original for adjustment
(P/N: 7505000106)

Figure 6-45

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U429 | Adjusting the color balance offset (Message: Adjust Color Balance Offset) |
|-------------|--|

Contents

Displays/changes the density of each color in various image quality mode.

Purpose

Execute to change each color's balance.

Method

1. Press the [Start] key.
1. Select the image mode to change the setting.
- * : The screen for setting is displayed.

| Items | Contents |
|-----------------------|---|
| Text+Photo | Density of each color in the text+photo mode |
| Photo | Density of each color in the photo mode |
| Photo/Printout | Each color's density in the printed photo mode |
| Text | Density of each color in the text mode |
| Graphics/Map | Density of each color in the map mode |
| Copy/Printout | Each color's density in the printed document mode |

Setting: Text+Photo

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|----------|------------------------------------|---------------|-----------------|
| C | Cyan color balance offset value | -5 to 5 | 0 |
| M | Magenta color balance offset value | -5 to 5 | 0 |
| Y | Yellow color balance offset value | -5 to 5 | 0 |
| K | Black color balance offset value | -5 to 5 | 0 |

* : When the setting value is increased, the image gets thicker, and it is thinner when the setting value is decreased.

3. Press the [Start] key to set the setting value.

Setting: Photo

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|----------|------------------------------------|---------------|-----------------|
| C | Cyan color balance offset value | -5 to 5 | 0 |
| M | Magenta color balance offset value | -5 to 5 | 0 |
| Y | Yellow color balance offset value | -5 to 5 | 0 |
| K | Black color balance offset value | -5 to 5 | 0 |

* : When the setting value is increased, the image gets thicker, and it is thinner when the setting value is decreased.

3. Press the [Start] key to set the setting value.

Setting: Photo/Printout

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|----------|------------------------------------|---------------|-----------------|
| C | Cyan color balance offset value | -5 to 5 | 0 |
| M | Magenta color balance offset value | -5 to 5 | 0 |
| Y | Yellow color balance offset value | -5 to 5 | 0 |
| K | Black color balance offset value | -5 to 5 | 0 |

* :When the setting value is increased, the image gets thicker, and it is thinner when the setting value is decreased.

3. Press the [Start] key to set the setting value.

Setting: Text

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|----------|------------------------------------|---------------|-----------------|
| C | Cyan color balance offset value | -5 to 5 | 0 |
| M | Magenta color balance offset value | -5 to 5 | 0 |
| Y | Yellow color balance offset value | -5 to 5 | 0 |
| K | Black color balance offset value | -5 to 5 | 0 |

* :When the setting value is increased, the image gets thicker, and it is thinner when the setting value is decreased.

3. Press the [Start] key to set the setting value.

Setting: Graphics/Map

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|----------|------------------------------------|---------------|-----------------|
| C | Cyan color balance offset value | -5 to 5 | 0 |
| M | Magenta color balance offset value | -5 to 5 | 0 |
| Y | Yellow color balance offset value | -5 to 5 | 0 |
| K | Black color balance offset value | -5 to 5 | 0 |

* :When the setting value is increased, the image gets thicker, and it is thinner when the setting value is decreased.

3. Press the [Start] key to set the setting value.

Setting: Copy/Printout

1. Select the item to set.

2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|----------|------------------------------------|---------------|-----------------|
| C | Cyan color balance offset value | 0 to 10 | 5 |
| M | Magenta color balance offset value | 0 to 10 | 5 |
| Y | Yellow color balance offset value | 0 to 10 | 5 |
| K | Black color balance offset value | 0 to 10 | 5 |

* :When the setting value is increased, the image gets thicker, and it is thinner when the setting value is decreased.

3. Press the [Start] key to set the setting value.

Supplement

Test copy of the original is available by pressing the [System Menu] key as interruption copy mode when executing this maintenance mode.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U464 | ID correction setting (Message: Set ID Adjustment Mode) |
|-------------|--|

Contents

Set permission/prohibition of the ID correction operation (calibration). Executes each setting of the calibration.

Purpose

Execute the calibration setting when an image failure occurs or depending on the user's request. Execute Calibration when replacing the maintenance kit.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|----------------------|---|
| Permission | Permit/Prohibit Calibration |
| Time Interval | Sets the time interval to execute calibration after completing printing. |
| Mode | Color print mode setting |
| Leaving Time | Setting the time to determine whether to execute calibration when recovering from Sleep mode |
| Target Value | Setting the target sensor value for the thick layer calibration and light intensity calibration |
| Calib | Executing Calibration |

Setting: Permission

1. Select [On] or [Off].

| Items | Contents |
|------------|-------------------------|
| On | Permitting Calibration |
| Off | Prohibiting Calibration |

* :Initial setting: On

2. Press the [Start] key to set the setting value.

Setting: Time Interval

1. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|------------------|----------------------|---------------|---------------------------------|
| Time(sec) | Calibration interval | 0 to 9999 | 1200/900* ¹ (sec) |

*1: 40 ppm model

* :Setting is changeable in 10 count increments.

2. Press the [Start] key to set the setting value.

Setting: Mode

1. Select the item to set.

| Items | Contents |
|---------------|----------------------------------|
| Short | Color print mode setting: Short |
| Normal | Color print mode setting: Normal |
| Long | Color print mode setting: Long |
| Auto | Color print mode setting: Auto |

* :Initial setting: Normal

2. Press the [Start] key to set the setting value.

Setting: Leaving Time

3. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|------------------|-------------------------|---------------|-----------------|
| Time(min) | Setting the sleep timer | 0 to 1440 | 1080 (min) |

4. Press the [Start] key to set the setting value.

Setting: Target Value

1. Select the item to set.
2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|---------------------|------------------------------------|---------------|-----------------------|
| Thickness(C) | Toner layer calibration (Cyan) | 0 to 1000 | 680/930 ^{*1} |
| Thickness(M) | Toner layer calibration (Magenta) | 0 to 1000 | 610/900 ^{*1} |
| Thickness(Y) | Toner layer calibration (Yellow) | 0 to 1000 | 540/870 ^{*1} |
| Thickness(K) | Toner layer calibration (Black) | 0 to 1000 | 700/170 ^{*1} |
| Gamma(C) | Light amount calibration (Cyan) | 0 to 1000 | 445/430 ^{*1} |
| Gamma(M) | Light amount calibration (Magenta) | 0 to 1000 | 445/430 ^{*1} |
| Gamma(Y) | Light amount calibration (Yellow) | 0 to 1000 | 375/360 ^{*1} |
| Gamma(K) | Light amount calibration (Black) | 0 to 1000 | 465/430 ^{*1} |

*1: 40 ppm model

3. Press the [Start] key to set the setting value.

Method: Calib

1. Select the item to execute.
2. Press the [Start] key.

* :Calibration is started.

Same operation as [System Menu] - [Adjustment/Maintenance] - [Calibration].

| Items | Contents |
|---------------|---|
| Regist | Execute the registration correction calibration |
| Full | Executes Full Calibration |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U465 | ID correction data (Message: ID Adjustment Data) |
|-------------|---|

Contents

Refers to the ID correction data.

Purpose

Execute for data check.

Method

1.Press the [Start] key.

2.Select [Laser Power].

* :The screen is switched.

| Items | Contents |
|--------------------|--|
| Laser Power | Displays the light intensity control value |

* :The current value is displayed.

| Items | Contents |
|--------------|---|
| C | Displays the Cyan light intensity control value. |
| M | Displays the Magenta light intensity control value. |
| Y | Displays the Yellow light intensity control value. |
| K | Displays the Black light intensity control value. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U467 | Color registration correction operation setting (Message: Set Color Regist Adjustment Mode) |
|-------------|--|

Contents

Sets the operation of the color registration correction and transfer belt speed correction.
Also, sets the execution condition of the color registration correction by the LSU temperature variation.

Purpose

If the color registration is unstable due to the sensor failure, etc., set it to off to temporarily fix the control value.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|---------------------|---|
| Color Regist | Sets the color registration correction |
| Timing | Execute the color registration correction if the LSU temperature changes by the specified value after the previous correction |

Setting: Color Regist

1. Select the item to set.

| Items | Contents |
|------------|---|
| On | Permitting the color registration correction operation |
| Off | Prohibiting the color registration correction operation |

* :Initial setting: On

2. Press the [Start] key to set the setting value.

Setting: Timing

1. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|-----------------|--|---------------|-----------------|
| LSU Temp | Execution condition by the LSU temperature variation | 2 to 20 | 10 |

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U468 | Color registration correction data (Message: Color Regist Adjustment Data) |
|-------------|---|

Contents

Displays the color registration correction data and transfer belt speed correction data.

Purpose

Execute for data check.

Method

1. Press the [Start] key.
2. Select the item to refer to.

* :The screen is switched.

| Items | Contents |
|-------------------|--|
| Auto(C) | Displaying the automatic color registration correction value (Cyan) |
| Auto(M) | Displaying the automatic color registration correction value (Magenta) |
| Auto(Y) | Displaying the automatic color registration correction value (Yellow) |
| Manual(C) | Displays the manual color registration correction value (Cyan) |
| Manual(M) | Displays the manual color registration correction value (Magenta) |
| Manual(Y) | Displays the manual color registration correction value (Yellow) |
| Initialize | Initializing the correction result |

Refer: Auto(C) / Auto(M) / Auto(Y)

1. Select [Auto(C)], [Auto(M)] or [Auto(Y)].

* :The current value is displayed.

| Items | Contents |
|----------------------|---|
| Main Scan | Automatic color registration adjustment value in the main scanning direction. |
| Sub Scan | Automatic color registration adjustment value in the sub scanning direction. |
| Magnification | Automatic color registration correction value for magnification |

Refer: Manual(C) / Manual(M) / Manual(Y)

1. Select [Manual(C)], [Manual(M)] or [Manual(Y)]

* :The current value is displayed.

| Items | Contents |
|-----------------------|--|
| Main Scan | Manual color registration adjustment value in the main scanning direction. |
| Sub Scan | Manual color registration adjustment in the sub scanning direction. |
| Magnification1 | Manual color registration correction value 1 for magnification |
| Magnification2 | Manual color registration correction value 2 for magnification |
| Magnification3 | Manual color registration correction value 3 for magnification |
| Magnification4 | Manual color registration correction value 4 for magnification |

Method: Initialize

1. Select [Initialize].

* :The operation is executed.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U469 | Color registration adjustment (Message: Adjust Color Registration) |
|-------------|---|

Contents

Corrects the color registration data.

Purpose

Execute when replacing the laser scanner unit.

* :Make sure to execute U464 Calib before executing this maintenance mode.

Method

1.Press the [Start] key.

2.Select the item to set.

* :Select [Auto] to output the automatic adjustment chart.

* :Select [Manual] to enter the setting display.

| Items | Contents |
|---------------|---|
| Auto | Adjust the color registration automatically |
| Manual | Adjust the color registration manually |

Method: Auto

1.Select the item to execute.

| Items | Contents |
|----------------|--|
| Print | Output the automatic adjustment chart. |
| Execute | Start scanning and execute the automatic adjustment. |

Method: Print

1.Press the [Start] key.

* :Output the automatic adjustment chart.

Method: Excute

1.Place an original on the table and press the [Start] key.

* :Execute the automatic adjustment.

2.When adjustment has normally completed, [OK] is displayed.

* :An error code appears when there is an error.

Error codes list

| Error codes | Place of occurrence | Factor |
|-------------|---------------------|--|
| S001 | Scanner | Original reference patch is not detected |
| S002 | | Scanned image position shifted in excess in the main scanning direction. |
| S003 | | Scanned image position shifted in excess in the sub scanning direction. |
| S004 | | Original skew is in excess |
| S005 | | Original type mismatch |
| SFFF | | Other scanning error |
| E001 | Engine | Engine error |
| CFFF | Controller | Other errors |

Method: Manual

1. Select the item to execute.
* :The screen for setting is displayed.

| Items | Contents |
|--------|--|
| Regist | Sets the color registration adjustment value |
| Print | Output the manual adjustment chart. |

Method: Print

1. Press the [Start] key to output the manual adjustment chart.

Chart sample

There are H-1 to 9 in the chart For each color of m, c and y (upper part).




Figure 6-46

Find the positions where two lines are best matched on each chart.

* :If it is at "0", the correction is unnecessary. In case of the illustration below, "B" is the value that should be set.




Figure 6-47

Method: Regist

1. Select the item to set.
2. By using the [+] [-] keys change the setting value.

| Items | Contents | Setting range | Initial setting |
|-------|-----------------------|---------------|-----------------|
| CH-1 | CH-1 adjustment value | -9 to 9 | - |
| CH-2 | CH-2 adjustment value | -9 to 9 | - |
| CH-3 | CH-3 adjustment value | -9 to 9 | - |
| CH-4 | CH-4 adjustment value | -9 to 9 | - |
| CH-5 | CH-5 adjustment value | -9 to 9 | - |
| CV-3 | CV-3 adjustment value | -9 to 9 | - |
| MH-1 | MH-1 adjustment value | -9 to 9 | - |
| MH-2 | MH-2 adjustment value | -9 to 9 | - |
| MH-3 | MH-3 adjustment value | -9 to 9 | - |
| MH-4 | MH-4 adjustment value | -9 to 9 | - |
| MH-5 | MH-5 adjustment value | -9 to 9 | - |
| MV-3 | MV-3 adjustment value | -9 to 9 | - |
| YH-1 | YH-1 adjustment value | -9 to 9 | - |
| YH-2 | YH-2 adjustment value | -9 to 9 | - |
| YH-3 | YH-3 adjustment value | -9 to 9 | - |
| YH-4 | YH-4 adjustment value | -9 to 9 | - |
| YH-5 | YH-5 adjustment value | -9 to 9 | - |
| YV-3 | YV-3 adjustment value | -9 to 9 | - |

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U470 | Setting the JPEG compression rate (Message: Adjust JPEG Compression Rate) |
|-------------|--|

Contents

Sets the JPEG compression rate by image mode.

Purpose

Change the setting depending on the image. desired by the user. Lower the set value to reduce the image roughness by changing the compression rate in case of 200% or more of the enlarged copy . If the set value is reduced, compression is high and image quality is lowered. If the set value is increased, image quality is improved but processing speed is slower.

Method

- 1.Press the [Start] key.
 - 2.Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|---------------|--|
| Copy | Compression rate of the copy |
| Send | Compression rate of the Send |
| System | Compression rate of the temporary saving in the system |

Method: Copy

- 1.Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|--------------|------------------------------------|
| Photo | Compression rate of the photo mode |
| Text | Compression rate of the text mode |

Setting: Photo

- 1.Select the item to set.
- 2.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|-------------|--|---------------|-----------------|
| Y | Compression rate of the brightness | 1 to 100 | 90 |
| CbCr | Compression rate of the color difference | 1 to 100 | 90 |

- 3.Press the [Start] key to set the setting value.

Setting: Text

- 1.Select the item to set.
- 2.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|-------------|--|---------------|-----------------|
| Y | Compression rate of the brightness | 1 to 100 | 90 |
| CbCr | Compression rate of the color difference | 1 to 100 | 90 |

- 3.Press the [Start] key to set the setting value.

Method: Send

1. Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|--------------------------|---|
| Photo | Compression rate of the photo mode |
| Text | Compression rate of the text mode |
| HC-PDF(BG) | Sets the compression rate for high compression PDF |
| HC-PDF(Char) | Set the compression rate for High compression PDF (text color). |
| HC-PDF(File Size) | Set the compression rate for High compression PDF (compression priority). |

Setting: Photo

1. Select the item to set.

2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|--------------|--|---------------|-----------------|
| Y1 | Compression rate of the brightness | 1 to 100 | 30(%) |
| Y2 | Compression rate of the brightness | 1 to 100 | 40(%) |
| Y3 | Compression rate of the brightness | 1 to 100 | 51(%) |
| Y4 | Compression rate of the brightness | 1 to 100 | 70(%) |
| Y5 | Compression rate of the brightness | 1 to 100 | 90(%) |
| CbCr1 | Compression rate of the color difference | 1 to 100 | 30(%) |
| CbCr2 | Compression rate of the color difference | 1 to 100 | 40(%) |
| CbCr3 | Compression rate of the color difference | 1 to 100 | 51(%) |
| CbCr4 | Compression rate of the color difference | 1 to 100 | 70(%) |
| CbCr5 | Compression rate of the color difference | 1 to 100 | 90(%) |

3. Press the [Start] key to set the setting value.

Setting: Text

1. Select the item to set.

2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|--------------|--|---------------|-----------------|
| Y1 | Compression rate of the brightness | 1 to 100 | 30(%) |
| Y2 | Compression rate of the brightness | 1 to 100 | 40(%) |
| Y3 | Compression rate of the brightness | 1 to 100 | 51(%) |
| Y4 | Compression rate of the brightness | 1 to 100 | 70(%) |
| Y5 | Compression rate of the brightness | 1 to 100 | 90(%) |
| CbCr1 | Compression rate of the color difference | 1 to 100 | 30(%) |
| CbCr2 | Compression rate of the color difference | 1 to 100 | 40(%) |
| CbCr3 | Compression rate of the color difference | 1 to 100 | 51(%) |

| Items | Contents | Setting range | Initial setting |
|--------------|--|---------------|-----------------|
| CbCr4 | Compression rate of the color difference | 1 to 100 | 70(%) |
| CbCr5 | Compression rate of the color difference | 1 to 100 | 90(%) |

3.Press the [Start] key to set the setting value.

Setting: HC-PDF(BG)

1.Select the item to set.

2.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|--------------|--|---------------|-----------------|
| Y1 | Compression rate of the brightness | 1 to 100 | 15(%) |
| Y2 | Compression rate of the brightness | 1 to 100 | 25(%) |
| Y3 | Compression rate of the brightness | 1 to 100 | 90(%) |
| CbCr1 | Compression rate of the color difference | 1 to 100 | 15(%) |
| CbCr2 | Compression rate of the color difference | 1 to 100 | 25(%) |
| CbCr3 | Compression rate of the color difference | 1 to 100 | 90(%) |

3.Press the [Start] key to set the setting value.

Setting: HC-PDF(Char)

1.Select the item to set.

2.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|--------------|--|---------------|-----------------|
| Y1 | Compression rate of the brightness | 1 to 100 | 15(%) |
| Y2 | Compression rate of the brightness | 1 to 100 | 75(%) |
| Y3 | Compression rate of the brightness | 1 to 100 | 90(%) |
| CbCr1 | Compression rate of the color difference | 1 to 100 | 15(%) |
| CbCr2 | Compression rate of the color difference | 1 to 100 | 75(%) |
| CbCr3 | Compression rate of the color difference | 1 to 100 | 90(%) |

3.Press the [Start] key to set the setting value.

Setting: HC-PDF(File Size)

1.Select the item to set.

2.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|--------------|--|---------------|-----------------|
| Y1 | Compression rate of the brightness | 1 to 100 | 15(%) |
| Y2 | Compression rate of the brightness | 1 to 100 | 25(%) |
| Y3 | Compression rate of the brightness | 1 to 100 | 75(%) |
| CbCr1 | Compression rate of the color difference | 1 to 100 | 15(%) |
| CbCr2 | Compression rate of the color difference | 1 to 100 | 25(%) |
| CbCr3 | Compression rate of the color difference | 1 to 100 | 75(%) |

3.Press the [Start] key to set the setting value.

Setting: System

1. Select the item to set.

2. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|-------------|--|---------------|-----------------|
| Y | Compression rate of the brightness | 1 to 100 | 90(%) |
| CbCr | Compression rate of the color difference | 1 to 100 | 90(%) |

3. Press the [Start] key to set the setting value.

Supplement

Test copy of the original is available by pressing the [System Menu] key as interruption copy mode when executing this maintenance mode.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U474 | Checking the LSU cleaning (Message: Check LSU Cleaning Operation) |
|-------------|--|

Contents

Execute the LSU cleaning by operating the LSI cleaning motor. Also, sets the cleaning operation interval and timing to enter the operation.

Method

1. Press the [Start] key.
2. Select the item to execute.

| Items | Contents |
|----------------|----------------------------------|
| Execute | Executes the cleaning operation. |
| Cycle | Sets the cleaning operation. |

Method: Execute

1. Press the [Start] key.
* :The LSU slit glass is cleaned.

Method: Cycle

1. Select the item to set.

| Items | Contents | Setting range | Initial setting |
|---------------|------------------------------|----------------------|------------------------|
| Cnt | Sets the cleaning cycle. | 0 to 5000 | 1000 |
| Timing | Sets the LSU cleaning timing | Print / Print End | Print End |

Setting: Cnt

1. By using the [+] [-] keys or the numeric keys, change the setting value.
* :Settable in 100-sheet increments. (Actual control x5 (=500 sheets))
2. Press the [Start] key to set the setting value.

Setting: Timing

1. Select the item to set.

| setting | Contents |
|------------------|--------------------------------|
| Print | Clean during job |
| Print End | Clean after completing the job |

* :Initial setting: Print End

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U485 | Image process mode setting (Message:Set Image Process Mode) |
|-------------|--|

Contents

Sets the detection level of the output of the confidential document when scanned. SAAlso, sets the PDF image rotation method. Also, changes/installs the color table.

Purpose

Change the detection level if the confidential document is not clearly printed and it cannot be detected when scanned. Also, execute to change the PDF image rotation method.
Execute to change the copy and printer color mode.

Method

- 1.Press the [Start] key.
 - 2.Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|--------------------|----------------------------|
| Mode | Set the image process mode |
| Color Table | Sets the color table |

Setting: Mode

- 1.Select the item to set.

| Items | Contents |
|---------------------|----------------------|
| PDF Rotation | Rotate the PDF image |

- 2.By using the [+] [-] keys or the numeric keys, change the setting value.

| setting | Contents |
|----------|---|
| 0 | The image rotation is designated to the internal parameter |
| 1 | The image rotation is designated to the actual image |
| 2 | The image rotation is designated to the internal parameter (CTM rotation) |

- 3.Press the [Start] key to set the setting value.

Setting: Color Table

- 1.Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|---------------------------|---|
| Color Table1(Prn) | Setting the default printer color table |
| Color Table2(Prn) | Sets the custom printer color table |
| Color Table1(Copy) | Setting the default copy color table |
| Color Table2(Copy) | Sets the custom copy color table |
| Install | Color table installation |
| Uninstall(Prn) | Uninstalling the printer color table |
| Uninstall(Copy) | Uninstalling the copy color table |

Setting: Color Table 1(Prn)/Color Table 2(Prn)/Color Table 1(Copy)/Color Table 2(Copy)

1. Select the color table to set to D.

| setting |
|---------|
| TYPE_CA |
| TYPE_FU |
| TYPE_KO |
| TYPE_KY |
| TYPE_RH |
| TYPE_TO |

2. Press the [Start] key to set the setting value.

3. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Method: Install

* :Insert the USB memory with the color table files before selecting them.

Check if there is the color table file in the root folder of a USB memory.

1. Select [Execute].

| Items | Contents |
|----------------|--------------------------|
| Execute | Color table installation |

2. Press the [Start] key to install.

* :The following is indicated after completing installation.

| Code | Contents |
|-------------|----------------------------------|
| OK | Normal completion |
| E001 | Error in connecting a USB memory |
| E002 | Error in handling a file |
| EEEE | Other errors |

Method: Uninstall(Prn)/Uninstall(Copy)

1. Selects the color table to uninstall.

* :Simultaneous uninstallation of multiple items is available.

| setting |
|---------|
| TYPE_CA |
| TYPE_FU |
| TYPE_KO |
| TYPE_KY |
| TYPE_RH |
| TYPE_TO |

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U486 | Color/BW mode setting (Message: Set ACS mode (Color/BW Operation)) |
|-------------|---|

Contents

Sets the operation mode after detecting color originals with color/BW mixed originals.

Purpose

Mode: To prioritize the productivity when copying color/BW mixed originals in ACS mode, change the setting to Mode3. However, if setting it to Mode3, even when monochrome originals come after color originals, C/M/Y developer maintenance counts are counted up.

Permission: set in case of color background image when printing an envelope in BW half speed mode processed as color printing.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|-------------------|--|
| Mode | Color/BW mode setting |
| Permission | Permit monochrome printing at half speed |

Setting: Mode

1. Select the item to set.

| Items | Contents |
|--------------|---|
| Mode1 | For users mostly printing in monochrome mode and color/monochrome mixed mode is not high during continuous printing. Monochrome printing remains in the color process speed after switching to color and other process is switched . |
| Mode2 | For users mostly printing in monochrome mode and color/monochrome mixed mode is not high during continuous printing. Even when receiving a monochrome print request during color printing, color printing operation is continued until 9 pages and color mode is switched to monochrome mode when starting printing of the 10th page (Color process is stopped). |
| Mode3 | Appropriate for users who mostly print in color. Once switched to the color mode, monochrome printing after that remains in the color process including the surface speed. |
| Auto | Mode 1 to 3 is automatically selected depending on the user's usage. Select Mode 1 to 3 based on color print ratio and switch rate from the print volume during the specified period. |

* :Initial setting: Mode2

2. Press the [Start] key to set the setting value.

Setting: Permission

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|-------|--|
| On | Permit: monochrome printing (three colors separated) |
| Off | Prohibit: color printing (four color process) |

* :Initial setting: Off

3. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U520 | TDRS setting (Message: Set TDRS) |
|-------------|---|

Contents

Checks/sets the TDRS

Purpose

Execute to check/set the TDRS

Method

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|----------------------|---|
| Registration | Changes to the TDRS Manager registration dialog |
| Information | Transition to the Device Agent description dialog |
| On/Off Config | Changes to the TDRS features setting dialog |

Setting: Registration

3. Select the item to set.

| Items | Contents |
|--------------------|---|
| TDRS User | Registering process for user and password |
| Access Code | Registers Access Code |

Setting: Access Code

4. Select the item to set.

| Items | Contents |
|---------------------|---------------------------------|
| Regist | Registers in the TDRS Manager |
| TDRS Server | Sets the TDRS server URL |
| TDRS User | Sets the TDRS Username |
| Access Code | Sets the TDRS access code |
| Proxy Server | Sets the TDRS proxy server URL |
| Proxy Port | Sets the TDRS proxy port number |
| Proxy User | Sets the TDRS proxy username |
| Text | Sets the TDRS description |

- * :[Regist] is not executable if a USB memory is not installed.
- * :When the USB memory is inserted, TDRS information is automatically retrieved and displayed.
After obtaining the TDRS information, select [Regist] and then register the TDRS information by pressing the [OK] or [Start] key.
- * :After the normal completion, [Complete] is indicated in the status information of the item that was performed.
When an error occurs, the following numbers are indicated in the status information of the item that has been operated.
- * :If [User/Processing Registration using a Password] is selected in the previous dialog, the "TDRS User" will be indicated.
If [Processing Registration using an Access Code] is selected, the "Access Code" will be indicated.

Error codes

| Items | Contents | Items | Contents |
|--------------|--|--------------|--------------------------------------|
| e0001 | HDD is unavailable. | t0001 | Fatal error |
| e0002 | The USB memory is unavailable. | t0002 | Error in processing the network |
| e0003 | The file to import does not exist in the USB memory. | t0003 | An illegal parameter error |
| e0004 | Reading from the USB memory has failed. | t0004 | Insufficient resource |
| e0005 | Unmounting the USB memory has failed. | t0005 | Communication error |
| e0006 | Moving or renaming the file has failed. | t0006 | Error in processing communication. |
| e0007 | Opening the file has failed. | t0007 | Login error |
| e0008 | Closing the file has failed. | t0008 | External error |
| e0009 | Error in reading the file | t0009 | Authentication error |
| e000A | Copying the file has failed. | t000A | HTTP error: Request error |
| e000B | Opening the directory has failed. | t000B | HTTP error: Error due to the server |
| e000C | Creating the working directory has failed. | t000C | HTTP error: Error due to the client. |
| e000D | Deleting the working file has failed. | | |

Setting: Information

1. Select the item to set.

| Items | Contents |
|-------------------|-------------------------------------|
| Agent ID | Agent ID |
| Agent Type | Agent Type |
| Model | Refers to the model name |
| Serial No | Refers to the machine serial number |
| Offline | Refers to the TDRS connection state |

Setting: On/Off Config

1. Select the item to set.

| Items | Contents |
|------------|---------------|
| On | Enables TDRS |
| Off | Disables TDRS |

* :Initial setting: Off

2. Press the [Start] key to set the setting value.

3. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U600 | Initialize: All Data (Message: Initialize: All Data) |
|-------------|---|

Contents

Initializes software switches, and all data and image memory in the backup data on the FAX PWB according to the destination and OEM setting.

Initializes the file system and then initializes the communication record and the registered contents if the file system is checked and an error is detected there.

Purpose

Initialize the FAX PWB

Method

1.Press the [Start] key.

2.Select [Execute].

* :The screen for entering the destination code and OEM code is displayed.

| Items | Contents |
|----------------|-------------------------------|
| Execute | Executing data initialization |

3.Select [Country Code] and enter a destination code using the numeric keys.

* :Refer to the following destination code list.

| Items | Contents |
|---------------------|--------------------------|
| Country Code | Setting Destination code |
| OEM Code | Sets the OEM code |

* :No need to change the default value of [OEM Code].

4.Press the [Start] key to set the setting value.

* :Data initialization starts.

Press the [Stop] key to cancel the data initialization.

5.The firmware version is displayed after the data initialization.

The firmware version of 3 types of application, boot and IPL is displayed.

* :When initialization is successful, "Completed" is displayed for one second.

* :Where an irregular value is input, when it initializes, the following errors are displayed.

| Kind of error |
|--|
| Unknown Country (When Country Code is unknown) |
| Unknown OEM (When OEM Code is unknown) |
| Unknown Country (When both are unknown) |

Destination code list

| Destina- tion code | Destination | Destina- tion code | Destination |
|-----------------------|-------------|-----------------------|--------------------------|
| 000 | Japan | 253 | CTR21 (European nations) |
| 007 | Argentina | ↑ | Italy |
| 009 | Australia | ↑ | Germany |
| 022 | Brazil | ↑ | Spain |
| 038 | China | ↑ | U.K. |

| Destina- tion code | Destination | Destina- tion code | Destination |
|-------------------------------|--------------------|-------------------------------|--------------------|
| 080 | Hong Kong | ↑ | Netherlands |
| 084 | Indonesia | ↑ | Sweden |
| 088 | Israel | ↑ | France |
| 097 | Korea | ↑ | Austria |
| 181 | U.S.A. | ↑ | Switzerland |
| 250 | Russia | ↑ | Belgium |
| 108 | Malaysia | ↑ | Denmark |
| 115 | Mexico | ↑ | Finland |
| 126 | New Zealand | ↑ | Portugal |
| 136 | Peru | ↑ | Ireland |
| 137 | Philippines | ↑ | Norway |
| 152 | Middle East | 254 | Taiwan |
| 156 | Singapore | | |
| 159 | South Africa | | |
| 169 | Thailand | | |

| | |
|-------------|---|
| U601 | Initialize: Keep data (Message: Initialize: Keep Data) |
|-------------|---|

Contents

Initializes software switches other than the machine data on the FAX PWB according to the destination and OEM setting.

Purpose

Initialize the FAX PWB without changing the user registration data and the factory defaults

Method

1.Press the [Start] key.

2.Select [Execute].

* :The screen for entering the destination code and OEM code is displayed.

| Items | Contents |
|----------------|-------------------------------|
| Execute | Executing data initialization |

3.Select [Country Code].

4.By using the [+] [-] keys or the numeric keys, change the setting value.

* :Refer to the destination code list. (P.6-378Refer to page 1-6-58)

| Items | Contents |
|---------------------|--------------------------|
| Country Code | Setting Destination code |
| OEM Code | Sets the OEM code |

* :No need to change the default value of [OEM Code].

5.Press the [Start] key to set the setting value.

* :Data initialization starts.

Press the [Stop] key to cancel the data initialization.

6.The firmware version is displayed after the data initialization.

The firmware version of 3 types of application, boot and IPL is displayed.

* :When initialization is successful, "Completed" is displayed for one second.

| | |
|-------------|---|
| U603 | User data 1 (Message: User Data 1) |
|-------------|---|

Contents

Sets the line type for FAX use

Purpose

Execute as required

Method

1. Press the [Start] key.
2. Select [Line Type].

| Items | Contents |
|------------------|-----------|
| Line Type | Line Type |

3. Select the item to set.

| Items | Contents |
|--------------|----------|
| DTMF | DTMF |
| 10PPS | 10PPS |
| 20PPS | 20PPS |

* :Initial setting: DTMF

4. Press the [Start] key to set the setting value.

* :Display the screen.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U604 | User data 2 (Message: User Data 2) |
|-------------|---|

Contents

Sets the number of rings for the automatic FAX/telephone switching for FAX use

Purpose

Adjust the number of rings to longer or shorter at the automatic FAX/telephone switching

Method

1. Press the [Start] key.
2. Select [Rings(F/T)].
3. By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|--------------------|-------------------------------|---------------|--|
| Rings (F/T) | Number of fax/telephone rings | 0 to 15 | 0 (100 V model) 1 (220-240 V model) 2 (Australia) 3 (New Zealand) |

* :If the default is set to "0", the main unit will start FAX reception without any ringing.

4. Press the [Start] key to set the setting value.

* :Display the screen.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U605 | Data clear (Message: Clear Data) |
|-------------|---|

Contents

Initializes data related to the fax transmission such as transmission history or various ID.

Purpose

Clear the communication history

Method

1. Press the [Start] key.
2. Select [Clear Com.Rec.].

| Items | Contents |
|-----------------------|--|
| Clear Com.Rec. | Delete data of communication history and protocol list of displayed port |

3. Press the [Start] key.

* :When initialization is successful, "Completed" is displayed for one second.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U610 | System 1 (Message: System Setting 1) |
|-------------|---|

Contents

Set the number of lines to be ignored when receiving a fax at 100% magnification and in the auto reduction mode.

Method

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|-----------------------|--|
| Cut Line: 100% | Set the number of lines to be ignored when receiving a fax at 100% magnification. |
| Cut Line: Auto | Number of lines to be ignored when receiving in the auto reduction mode. |
| Cut Line: A4 | Set the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode. |

Setting: Cut Line: 100%

Sets the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when recording the data at 100% magnification.

If the number of excess lines is below the setting, those lines are ignored. If it is over the setting, they are recorded on the next page.

1. By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting | Data variation |
|---|----------------------|------------------------|-----------------------|
| Set the number of lines to be ignored when receiving a fax at 100% magnification. | 0 to 22 | 3 | - |

- * : Increase the setting value if a blank second page is output in the full magnification reception. Decrease the value if there is dropout in received image.

2. Press the [Start] key to set the setting value.

Setting: Cut Line: Auto

Set the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when the data is recorded in the auto reduction mode.

If the number of excess lines is below the setting, those lines are ignored. If over the setting, the entire data on a page is further reduced so that it can be recorded on the same page.

1. By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting | Data variation |
|--|----------------------|------------------------|-----------------------|
| Number of lines to be ignored when receiving in the auto reduction mode. | 0 to 22 | 0 | - |

- * : Increase the setting value if a page received in the reduction mode is reduced too much with the trailing edge margin. Decrease the value if there is dropout in received image.

2. Press the [Start] key to set the setting value.

Setting: Cut Line: Auto

Set the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when the data is recorded in the auto reduction mode onto A4R or Letter R paper. If the number of excess lines is below the setting, those lines are ignored. If over the setting, the entire data on a page is further reduced so that it can be recorded on the same page.

1. By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting | Data variation |
|--|---------------|-----------------|----------------|
| Number of lines to be ignored when receiving in the A4R auto reduction mode. | 0 to 22 | 0 | - |

* :Increase the setting value if a page received in the reduction mode is reduced too much with the trailing edge margin. Decrease the value if there is dropout in received image.

2. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U611 | System 2 (Message: System Setting 2) |
|-------------|---|

Contents

Sets the number of adjustment lines for automatic reduction.

Purpose

Sets the number of adjustment lines for automatic reduction.

Method

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|----------------------|---|
| ADJ LINES | Sets the number of adjustment lines for automatic reduction. |
| ADJ LINES(A4) | Number of adjustment lines for automatic reduction when A4 paper is set. |
| ADJ LINES(LT) | Number of adjustment lines for automatic reduction when letter size paper is set. |

Setting: ADJ LINES

Sets the number of adjustment lines for automatic reduction.

1. By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting | Data variation |
|---|----------------------|------------------------|-----------------------|
| Number of adjustment lines for automatic reduction. | 0 to 22 | 7 | - |

2. Press the [Start] key to set the setting value.
* :Display the screen.

Setting: ADJ LINES(A4)

Sets the number of adjustment lines for automatic reduction.

1. By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting | Data variation |
|--|----------------------|------------------------|-----------------------|
| Number of adjustment lines for automatic reduction when A4 paper is set. | 0 to 22 | 22 | - |

2. Press the [Start] key to set the setting value.
* : "Completed" is displayed.

Setting: ADJ LINES(LT)

Sets the number of adjustment lines for automatic reduction when letter size paper is set.

1. By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting | Data variation |
|---|----------------------|------------------------|-----------------------|
| Number of adjustment lines for automatic reduction when letter size paper is set. | 0 to 22 | 26 | - |

2. Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U612 | System 3 (Message: System Setting 3) |
|-------------|---|

Contents

Sets the FAX operation and automatic printing of the protocol list.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|----------------------|--|
| Auto reduce | Selects auto reduction in the sub-scanning direction |
| Protocol List | Sets the automatic protocol list printing. |

Setting: Auto Reduce

Sets whether to receive a long document by automatically reducing it in the sub-scanning direction or at 100% magnification.

1. Select the item to set.

| Items | Contents |
|--------------|---|
| On | Auto reduction is executed if the received document is longer than the FAX paper. |
| Off | Auto reduction is not performed. |

- * :Initial setting: On
2. Press the [Start] key to set the setting value.
- * : "Completed" is displayed.

Setting: Protocol List

Sets the automatic protocol list printing.

1. Select the item to set.

| Items | Contents |
|--------------|--|
| Off | The protocol list is not printed out automatically. |
| Err | Automatically printed if a communication error occurs. |
| On | Automatically printed out after communication. |

- * :Initial setting: Off
2. Press the [Start] key to set the setting value.
- * : "Completed" is displayed.

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U620 | FAX system (Message: FAX System) |
|-------------|---|

Contents

Sets the signal detection method for remote switching.
Change the setting according to the type of telephone connected to the main unit.

Purpose

Sets the remote switching conditions according to the user's telephone type, preference, etc.

Setting

1. Press the [Start] key.
2. Select [Remote Mode] and press the [Start] key.

| Items | Contents |
|--------------------|-----------------------------------|
| Remote Mode | Setting the remote switching mode |

3. Select the item to set.

| Items | Contents |
|--------------|------------------------------------|
| One | Sets the one-shot type detection |
| Cont | Sets the continuous type detection |

* :Initial setting: One

4. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U625 | Communication settings (Message: Set Communication) |
|-------------|--|

Contents

Sets the auto redialing interval and the number of times of auto redialing.

Purpose

FAX transmission may not be available if redialing interval is short. If long, it takes much time to complete transmission. Changes the setting to prevent the following problems.

Method

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|-----------------|--|
| Interval | Sets the auto redialing interval |
| Times | Sets the number of times of auto redialing |

Setting: Interval

1. By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting | Data variation |
|-----------------------------|----------------------|------------------------|-----------------------|
| Sets the redialing interval | 1 to 9 minutes | 3 minutes | - |

2. Press the [Start] key to set the setting value.
* : "Completed" is displayed.

Setting: Times

1. By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting | Data variation |
|---------------------------------------|----------------------|------------------------|-----------------------|
| Sets the number of times of redialing | 0 to 15 times | 3 times | - |

2. Press the [Start] key to set the setting value.
* : "Completed" is displayed.

Completion

Press the [Stop] key.

- * : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U630 | Communication control procedures 1 (Message: Communication Control 1) |
|-------------|--|

Contents

Sets the FAX communication.

Purpose

Sets the following to correspond to field claims

Reducing the transmission time to improve the accuracy of reception when using a low quality line

Improving the accuracy of communication during the international communication

Method

1. Press the [Start] key.

2. Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|-----------------|---|
| TX Speed | Sets the communication starting speed. |
| RX Speed | Sets the reception speed. |
| TX Echo | Sets the waiting period to prevent echo problems at the sender. |
| RX Echo | Sets the reception speed. |

Setting: TX Speed

Sets the transmission speed of the sender. When the destination unit has the V.34 capability, V.34 is selected for transmission regardless of this setting.

1. Select the communication speed.

| Items | Contents |
|-----------------------|-----------------|
| 14400bps/V17 | V.17 14400bps |
| 9600bps/V29 | V.29 9600bps |
| 4800bps/V27ter | V.27ter 4800bps |
| 2400bps/V27ter | V.27ter 2400bps |

* :Initial setting: 14400bps/V17

2. Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Setting: RX Speed

Sets the reception capacity to advise the transmitter by the DIS/NSF signal. When the destination unit has the V.34 capability, V.34 is selected for transmission regardless of this setting.

1. Select the reception speed.

| Items | Contents |
|-----------------|---------------------------|
| 14400bps | V.17, V.33, V.29, V.27ter |
| 9600bps | V.29, V.27ter |
| 4800bps | V.27ter |
| 2400bps | V.27ter (fallback only) |

* :Initial setting: 14400bps

2. Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Setting: TX Echo

Sets the time to send the DCS signal after the DIS signal is received. Execute when an error occurs with echo at the transmitter side.

1. Select the item to set.

| Items | Contents |
|------------|---|
| 500 | Sends the DCS 500 ms after receiving a DIS. |
| 300 | Sends the DCS 300 ms after receiving a DIS. |

* :Initial setting: 300

2. Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Setting: RX Echo

Sets the time to send the NSF, CSI or DIS signal after the CED signal is received. Execute when an error occurs with echo at the receiver side.

1. Select the item to set.

| Items | Contents |
|------------|--|
| 500 | Sends the NSF, CSI or DIS 500ms after receiving the CED. |
| 75 | Sends the NSF, CSI or DIS 75ms after receiving the CED. |

* :Initial setting: 75

2. Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U631 | Communication control procedures 2 (Message: Communication Control 2) |
|-------------|--|

Contents

Sets the FAX communication.

Purpose

Sets the transmission and reception of ECM

Sets the CED frequency

Method

1.Press the [Start] key.

2.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|-----------------|---------------------------------|
| ECM TX | Sets ECM transmission. |
| ECM RX | Sets ECM reception. |
| CED Freq | The frequency of CED is set up. |

Setting: ECM TX

Set to OFF when the reduction of transmission costs is of higher priority than image quality.

* :Do not set it to Off when connecting to the IP telephone line.

1.Select the item to set.

| Items | Contents |
|--------------|-------------------------------|
| On | ECM transmission is enabled. |
| Off | ECM transmission is disabled. |

* :Initial setting: On

2.Press the [Start] key. Set the setting value.

* : "Completed" is displayed.

Setting: ECM RX

Set to OFF when the reduction of transmission costs is of higher priority than image quality.

* :Do not set it to OFF when connecting to the IP (Internet Protocol) telephone line.

1.Select the item to set.

| Items | Contents |
|--------------|----------------------------|
| On | ECM reception is enabled. |
| Off | ECM reception is disabled. |

* :Initial setting: On

2.Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Setting: CED Freq

Sets the CED frequency. Execute it as one of the communication accuracy improvement measures for the international communication.

1. Select the item to set.

| Items | Contents |
|-------|----------|
| 2100 | 2100Hz |
| 1100 | 1100Hz |

* :Initial setting: 2100

2. Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U632 | Communication control procedures 3 (Message: Communication Control 3) |
|-------------|--|

Contents

Sets the FAX communication.

Purpose

Reducing the error communication when using a low quality line

Corresponds to field claims when automatic FAX/telephone switching

Method

1.Press the [Start] key.

1.Select the item to set.

* :The screen for setting is displayed.

| Items | Contents |
|------------------------|---|
| DIS 4Byte | Sets the DIS signal to 4 bytes. |
| Num OF CNG(F/T) | Sets the number of the CNG detection in the automatic FAX/telephone switching mode. |

Setting: DIS 4Byte

Sets whether to send bit 33 and later bits of the DIS/DTC signal.

1.Select the item to set.

| Items | Contents |
|------------|---|
| On | Bit 33 and later bits of the DIS/DTC signal are not sent. |
| Off | Bit 33 and later bits of the DIS/DTC signal are sent. |

* :Initial setting: Off

2.Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Setting: Num OF CNG(F/T)

Sets the CNG detection times in the automatic FAX/telephone switching mode.

1.Select the item to set.

| Items | Contents |
|--------------|--------------------|
| 1Time | Detects CNG once. |
| 2Time | Detects CNG twice. |

* :Initial setting: 1Time (100 V model)/2Time (Others)

2.Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U633 | Communication control procedures 4 (Message: Communication Control 4) |
|-------------|--|

Contents

Sets the FAX communication.

Purpose

Reducing the error communication when using a low quality line

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|--------------------|---|
| V.34 | Enables or disables the V.34 communication. |
| V.34-3429Hz | Sets the V.34 symbol speed (3429 Hz). |
| DIS 2Res | Sets the number of times of DIS signal reception. |
| RTN Check | Sets the reference for the RTN signal output. |

Setting: V.34

Sets whether to enable/disable the V.34 communication individually for transmission and reception.

1. Select the item to set.

| Items | Contents |
|------------|---|
| On | V.34 communication is enabled for both transmission and reception. |
| TX | V.34 communication is enabled for transmission only. |
| RX | V.34 communication is enabled for reception only. |
| Off | V.34 communication is disabled for both transmission and reception. |

- * :Initial setting: On
2. Press the [Start] key to set the setting value.
- * : "Completed" is displayed.

Setting: V.34-3429Hz

Sets if the V.34 symbol speed 3429 Hz is used.

1. Select the item to set.

| Items | Contents |
|------------|--|
| On | V.34 symbol speed 3429 Hz is used. |
| Off | V.34 symbol speed 3429 Hz is not used. |

- * :Initial setting: On
2. Press the [Start] key to set the setting value.
- * : "Completed" is displayed.

Setting: DIS 2Res

Sets the number of times to receive the DIS signal to once or twice. Execute it as one of the corrective measures for transmission errors and other problems.

1. Select the item to set.

| Items | Contents |
|--------------|--------------------------------|
| Once | Responds to the first signal. |
| Twice | Responds to the second signal. |

* :Initial setting: Once

1. Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Setting: RTN Check

Sets the error line rate to be a reference to the RTN signal transmission. If transmission errors occur frequently due to the line quality, lower this setting to reduce them.

1. Select the item to set.

| Items | Contents |
|------------|------------------------|
| 5% | Error line rate of 5% |
| 10% | Error line rate of 10% |
| 15% | Error line rate of 15% |
| 20% | Error line rate of 20% |

* :Initial setting: 15%

2. Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U634 | Communication control procedures 5 (Message: Communication Control 5) |
|-------------|--|

Contents

Sets the maximum number of error bytes judged acceptable when receiving a TCF signal. Execute it as one of measures to ease transmission conditions if transmission errors occur.

Purpose

* :Relax the communication conditions

Setting

- 1.Press the [Start] key.
- 2.Select [TCF Check].
- 3.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|------------------|--|---------------|-----------------|
| TCF Check | Sets the allowed error bytes when detecting the TCF signal | 1 to 255 | 0 |

- 4.Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U640 | Communication time setting 1 (Message: Communication Time 1) |
|-------------|---|

Contents

Sets the detection time when one-shot detection is selected for remote switching.
Sets the detection time when continuous detection is selected for remote switching.

Purpose

Sets the remote switching conditions according to the user's telephone type, preference, etc.

Method

- 1.Press the [Start] key.
- 2.Select the item to set.
- 3.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|--------------------|--|---------------|----------------------|
| Time(One) | Sets the one-shot detection time for remote switching. | 0 to 255 | 7 1 (New Zealand) |
| Time (Cont) | Sets the continuous detection time for remote switching. | 0 to 255 | 80 |

- 4.Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U641 | Communication time setting 2 (Message: Communication Time 2) |
|-------------|---|

Contents

Sets the time-out time for the fax communication.

Purpose

Mainly, executed to improve the accuracy of communication for international communication

Method

1. Press the [Start] key.
1. Select the item to set.

| Items | Contents |
|---------------------|-----------------------------|
| T0 TIME OUT | Sets the T0 time-out time. |
| T1 TIME OUT | Sets the T1 time-out time. |
| T2 TIME OUT | Sets the T2 time-out time. |
| Ta TIME OUT | Sets the Ta time-out time. |
| Tb1 TIME OUT | Sets the Tb1 time-out time. |
| Tb2 TIME OUT | Sets the Tb2 time-out time. |
| Tc TIME OUT | Sets the Tc time-out time. |
| Td TIME OUT | Sets the Td time-out time. |

Setting: T0 Time Out

Sets the time before detecting a CED or DIS signal after a dialing signal is sent.

Sets to prevent disconnection of a line that occurs depending on the quality of the exchange, or when the destination unit sets the auto switching function.

1. By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|----------------------------|---------------|------------------------|
| Sets the T0 time-out time. | 30 to 90 s | 56 58 (100 V model) |

2. Press the [Start] key to set the setting value.
* : "Completed" is displayed.

Setting: T1 Time Out

Sets the time before receiving the correct signal after call reception.

*This setting is usually unnecessary.

1. By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|----------------------------|---------------|------------------------|
| Sets the T1 time-out time. | 30 to 90 s | 36 38 (100 V model) |

2. Press the [Start] key to set the setting value.
* : "Completed" is displayed.

Setting: T2 Time Out

The T2 time-out time is specified as follows.
 From CFR signal output to image data reception
 From image data reception to the next signal reception
 In ECM, from RNR signal detection to the next signal reception

1. By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|----------------------------|---------------|-----------------|
| Sets the T2 time-out time. | 1 to 255 | 69 |

2. Press the [Start] key to set the setting value.
 * : "Completed" is displayed.

Setting: Ta Time Out

Sets the time to start ringing for an operator through the external telephone after receiving a call in the FAX/telephone automatic switching mode. (See figure 1-3-18). If either receiving a FAX signal within this time or passing this time, the mode automatically switches to the FAX reception mode. Execute when a reception error occurs when in the automatic FAX/telephone switching.

1. By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|----------------------------|---------------|-----------------|
| Sets the Ta time-out time. | 1 to 255 s | 30 |

2. Press the [Start] key to set the setting value.
 * : "Completed" is displayed.




Figure 6-48 Ta/Tb1/Tb2 time-out time

Setting: Tb1 Time Out

Sets the time to start sending the ring back tone after receiving a call as a fax machine in the FAX/telephone automatic switching mode, (See figure 1-3-18). Execute when a reception error occurs when in the automatic FAX/telephone switching.

1. By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|-----------------------------|---------------|-----------------|
| Sets the Tb1 time-out time. | 1 to 255 | 20 |

2. Press the [Start] key to set the setting value.
 * : "Completed" is displayed.

Setting: Tb2 Time Out

Sets the time to start ringing for an operator through the external telephone after receiving a call in the FAX/telephone automatic switching mode. (See figure 1-3-27). Execute when a reception error occurs when in the automatic FAX/telephone switching.

1.By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|-----------------------------|---------------|-----------------|
| Sets the Tb2 time-out time. | 1 to 255 | 80 |

2.Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Setting: Tc Time Out

In the TAD mode, set the time to check if there are any triggers for shifting to FAX reception after a connected handset receives a call. Unless switched to FAX reception during this period, operated as a normal phone after this.

In the TAD mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.

1.By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|----------------------------|---------------|-----------------|
| Sets the Tc time-out time. | 1 to 255 s | 60 |

2.Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Setting: Td Time Out

Sets the length of time to determine silent status, one of the triggers for Tc time check.

In the TAD mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call. Be sure not to set too short, otherwise the mode may be switched to fax while the unit is being used as a telephone.

1.By using the [+] [-] keys or the numeric keys, change the setting value.

| Contents | Setting range | Initial setting |
|----------------------------|---------------|--|
| Sets the Td time-out time. | 1 to 255 | 6 30 (100 V model) 9 (120 V model) |

2.Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U650 | Modem 1 (Message: Modem 1) |
|-------------|---|

Contents

Sets the G3 cable equalizer. Sets the modem detection level.

Purpose

Adjusts the equalizer to be compatible with the line characteristics
Set to Improve the accuracy of communication when using a low quality line

Method

1. Press the [Start] key.
2. Select the item to set.

| Items | Contents |
|----------------------|---|
| Reg G3 TX Eqr | Sets the G3 transmission cable equalizer. |
| Reg G3 RX Eqr | Sets the G3 reception cable equalizer. |
| RX Mdm Level | Sets the modem detection level. |

Setting: Reg G3 TX Eqr

1. Select [0dB], [4dB], [8dB] or [12dB].
* :Initial setting: 0dB
2. Press the [Start] key to set the setting value.
* : "Completed" is displayed.

Setting: Reg G3 RX Eqr

1. Select [0dB], [4dB], [8dB] or [12dB].
* :Initial setting: 0dB
2. Press the [Start] key to set the setting value.
* : "Completed" is displayed.

Setting: RX Mdm Level

1. Select [-33dBm], [-38dBm], [-43dBm] or [-48dBm].
* :Initial setting: -43dBm
2. Press the [Start] key to set the setting value.
* : "Completed" is displayed.

Completion

- Press the [Stop] key.
* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U651 | Modem 2 (Message: Modem 2) |
|-------------|---|

Contents

Sets the modem output level.

Purpose

Adjust to make the equalizer compatible with the line characteristics when installing the main unit

Setting

1. Press the [Start] key.
2. Select the item to set.
3. By using [+] [-] or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting |
|------------------------|---|----------------------|--|
| Sgl LVL Modem | Sets the modem output level | -15 to 0 | 11 10 (100 V model) 12 (Australia) |
| DTMF LEV (Cent) | DTMF output level (center value) | -15.0 to 0.0 | -8 -9 (100 V model) -7 (Australia) -6 (120 V model) |
| DTMF LEV (Diff) | Sets the DTMF output level (level difference) | 0 to 5.5 | 2 1.5 (Australia) 1 (New Zealand) |

4. Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U660 | Ring setting (Message: Set Calls) |
|-------------|--|

Contents

Sets the NCU (network control unit).

Purpose

Execute as required

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|--------------------|---|
| Exchange | Setting the PBX/PSTN connection |
| Dial Tone | Sets the PSTN dial tone detection. |
| Busy Tone | Sets the busy tone detection. |
| PBX Setting | Setting the PBX connection |
| DC Loop | Sets the loop current detection before dialing. |

Setting: Exchange

Selects if the FAX is connected to either a PBX or public switched telephone network.

1. Select the item to set.

| Items | Contents |
|--------------|---|
| PSTN | Connected to the public switched telephone network. |
| PBX | Connecting to the PBX |

- * :Initial setting: PSTN
2. Press the [Start] key to set the setting value.
- * : "Completed" is displayed.

Setting: Dial Tone

Selects whether or not to check for a dial tone to check if the telephone is off the hook when a fax is connected to a public switched telephone network.

1. Select the item to set.

| Items | Contents |
|--------------|--------------------------------|
| On | The dial tone is detected. |
| Off | The dial tone is not detected. |

- * :Initial setting: On
2. Press the [Start] key to set the setting value.
- * : "Completed" is displayed.

Setting: Busy Tone

Sets whether the line is disconnected immediately after a busy tone is detected, or the busy tone is not detected and the line remains connected until T0 time-out time, when a FAX signal is sent FAX transmission may fail due to incorrect busy tone detection. When setting it to OFF, this problem may be improved. However, the line is not disconnected within the T0 time-out time even if the destination line is busy.

1. Select the item to set.

| Items | Contents |
|------------|--------------------------------|
| On | Detects the busy tone. |
| Off | Does not detect the busy tone. |

* :Initial setting: On/Off (Australia)

2. Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Setting: PBX Setting

Selects the mode to connect an outside call when connected to a PBX.

* According to the type of the PBX connected, select the mode to connect an outside call.

1. Select the item to set.

| Items | Contents |
|--------------|------------------|
| Flash | Flashing mode |
| Loop | Code number mode |

* :Initial setting: Loop

2. Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Setting: DC Loop

Sets if the loop current is detected before dialing.

1. Select the item to set.

| Items | Contents |
|------------|--|
| On | Detects the loop current before dialing. |
| Off | Detects the loop current before dialing. |

* :Initial setting: On

2. Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U670 | List output (Message: Output List) |
|-------------|---|

Contents

Outputs the list of fax communication data.

* :Printing a list is disabled either when a job is remaining in the buffer or when [Pause All Print Jobs] is pressed to halt printing.

Purpose

Check conditions of use, settings and transmission procedures of the FAX.

Method

- 1.Press the [Start] key.
- 2.Select the item to execute.
- 3.Press the [Start] key.
- 4.Output selected list.

| Items | Contents |
|------------------------|--|
| Sys Conf Report | Prints the list of software switches, local telephone number, confidential boxes, firmware versions and other information. |
| Action List | Prints the list of the error logs and communication lines. |
| Self Sts Report | Prints the list of FAX communication settings only in the maintenance mode (self-status report). |
| Protocol List | Outputs a list of communication procedures. |
| Error List | Output the error list. |
| Addr List(No.) | Outputs address book in the IDs order |
| Addr List(Idx) | Outputs address book in the order of names. |
| One-touch List | Outputs a list of one-touch. |
| Group List | Outputs the group list. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U671 | FAX backup data clear (Message: Clear FAX Back Up Data) |
|-------------|--|

Contents

Clears the FAX/i-FAX communication history and scheduled FAX transmission backup data in the FAX PWB.

Execute the memory DIMM initialization.

Purpose

Execute to prevent information disclosure of the backup data.

Setting

- 1.Press the [Start] key.
- 2.Select the item to output.

| Items | Contents |
|--------------------------|---|
| RESERVATION CLEAR | Clears the scheduled FAX data in the FAX PWB. |
| RECOVERY FAX DIMM | Enable to use the DIMM used in another machine. |
| FAX DIMM CLEAR | Clears all the data in the DIMM. |

- 3.Press the [Start] key.
* :Clears the backup data.
- 4.When selecting [RECOVERY FAX DIMM] or [FAX DIMM CLEAR], turn the power switch off and on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U695 | FAX function customization (Message: Customize FAX Function) |
|-------------|---|

Contents

FAX package transmission is set up. Changes print size priority when receiving small size.

Purpose

Execute as required

Method

1. Select the item to set.

| Items | Contents |
|----------------------|--|
| FAX Bulk TX | FAX batch transmission is set up. |
| A5 Pt Pri Chg | Change of print size priority at the time of small size reception. |

Setting: FAX Bulk TX

1. By using the [+] [-] keys keys, select [On] or [Off].

| Items | Contents |
|--------------|-------------------------------------|
| On | FAX batch transmission is enabled. |
| Off | FAX batch transmission is disabled. |

* :Initial setting: On

2. Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Setting: A5 Pt Pri Chg

1. By using the [+] [-] keys keys, select [On] or [Off].

| Items | Contents |
|--------------|--|
| On | At the time of A5 size reception: A5 >B5 >A4 >B4 >A3 |
| Off | At the time of A5 size reception: A5 >A4 >B5 >A3 >B4 |

2. Initial setting: Off

3. Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U698 | Setting the maintenance port (Message: Set Port for Maintenance) |
|-------------|---|

Contents

Sets the port applicable to the maintenance mode.

Purpose

Sets the maintenance mode target port when installing multiple ports .

Setting is unnecessary if the same contents are set for both ports. Sets only when different items are set for each port.

* :This maintenance mode only appears when the multiple ports are installed.

Setting

1.Press the [Start] key.

2.Press [Port Select].

* :Current setting display is inverted.

3.Select the item to set.

| Items | Contents |
|---------------|---------------------------------|
| ALL | All ports |
| PORT 1 | Port 1 (FAX PWB port) |
| PORT 2 | Port 2 (Optional multiple port) |

4.Press the [Start] key to set the setting value.

Precautions

These contents to set are cleared when exiting the maintenance mode or turning the power off and the settings are necessary when entering the maintenance mode.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U699 | Software switch: Set (Message: Set: Soft SW) |
|-------------|---|

Contents

Sets the software switches on the FAX PWB individually.

Purpose

Change the setting when a problem such as split output of received originals occurs

* :Since the communication performance is largely affected, normally this setting need not be changed.

Method

- 1.Press the [Start] key.
- 2.Select [SW No.].
- 3.Enter the desired software switch number (3 digits) using the numeric keys and press the [Start] key.

| Items | Contents |
|---------------|--|
| SW No. | Specifies the software switch number (2 to 3 digits) |

- 4.Press the keys of bit 0 to 7 to switch each bit between 0 and 1.

| Items | Contents |
|------------|-------------------------------------|
| Bit | Set the software switch bit (8bit). |

- 5.Press the [Start] key to set the setting value.

* : "Completed" is displayed.

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

**List of software switches which can be configured
Communication control procedures**

| No. | Bit | Contents |
|-----------|------|-------------------------------|
| 36 | 7654 | Coding format in transmission |
| | 3210 | Coding format in reception |
| 37 | 5 | 33600bps/V34 |
| | 4 | 31200bps/V34 |
| | 3 | 28800bps/V34 |
| | 2 | 26400bps/V34 |
| | 1 | 24000bps/V34 |
| | 0 | 21600bps/V34 |
| 38 | 7 | 19200bps/V34 |
| | 6 | 16800bps/V34 |
| | 5 | 14400bps/V34 |
| | 4 | 12000bps/V34 |
| | 3 | 9600bps/V34 |
| | 2 | 7200bps/V34 |
| | 1 | 4800bps/V34 |

| No. | Bit | Contents |
|-----|-----|---|
| 38 | 0 | 2400bps/V34 |
| 41 | 3 | FSK detection in V.8 |
| 42 | 4 | 4800 bps transmission when low-speed setting is active |
| | 2 | FIF length when transmitting DIS/DTC signal 4 times or more |

Communication time setting

| No. | Bit | Contents |
|-----|----------|--|
| 53 | 76543210 | T3 timeout setting |
| 54 | 76543210 | T4 timeout setting (auto transmission) |
| 55 | 76543210 | T5 timeout setting |
| 60 | 76543210 | Time before transmission of CNG (1100 Hz) signal |
| 63 | 76543210 | T0 timeout setting (manual transmission) |
| 64 | 7 | Phase C timeout in ECM reception |
| 66 | 76543210 | Timeout 1 in countermeasures against echo |
| 68 | 76543210 | Timeout for FSK detection start in V.8 |

Modem setting

| No. | Bit | Contents |
|-----|-------|----------------|
| 89 | 76543 | RX gain adjust |

NCU setting

| No. | Bit | Contents |
|-----|----------|--|
| 121 | 7654 | Dial tone/busy tone detection pattern |
| 122 | 7654 | Busy tone detection pattern |
| | 1 | Busy tone detection in FAX/TEL automatic switching |
| 125 | 76543210 | Registering the access code for connection to PSTN |
| 126 | 7654 | Ringback tone ON/OFF cycle for the automatic FAX/telephone switching |
| 68 | 76543210 | Timeout for FSK detection start in V.8 |

Calling time setting

| No. | Bit | Contents |
|-----|----------|----------------------------------|
| 133 | 76543210 | DTMF signal transmission time |
| 134 | 76543210 | DTMF signal pause time |
| 141 | 76543210 | Ringer detection cycle (minimum) |
| 142 | 76543210 | Ringer detection cycle (maximum) |
| 143 | 76543210 | Ringer ON time detection |
| 144 | 76543210 | Ringer OFF time detection |
| 145 | 76543210 | Ringer OFF time undetected |

| No. | Bit | Contents |
|-----|----------|---|
| 147 | 76543210 | Dial tone detection time (continuous tone) |
| 148 | 76543210 | Allowable dial tone interruption time |
| 149 | 76543210 | Time for transmitting selection signal after closing the DC circuit |
| 151 | 76543210 | Ringer frequency detection invalid time |

| | |
|-------------|--|
| U901 | Clearing the counters by paper source (Message: Clear Paper Feeder Counter) |
|-------------|--|

Contents

Displays and clears the counts by paper source.

Purpose

Check the maintenance parts replacement timing. Executes to clear counters when replacing the maintenance parts.

Method

1.Press the [Start] key.

* :Displays the counts by paper source.

| Items | Contents |
|---------------------|--|
| MPT | Display/clear the MP tray feed counter |
| Cassette1 | Displays/clears Cassette 1 count |
| Cassette2 *1 | Displays Cassette 2 count |
| Cassette3 *2 | Displays Cassette 3 count |
| Cassette4 *3 | Displays Cassette 4 count |
| Duplex | Displays/clears the duplex unit count |

*1: 500 PF only, *2: 500×2/2000 PF only, *3: 500×2 PF only

2.Select the counter to clear.

* :Unable to clear [Cassette2], [Cassette3] and [Cassette4]

3.Press the [Start] key to clear the counter value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U903 | Clearing the jam counter (Message: Clear Paper Misfeed Counter) |
|-------------|--|

Contents

Displays/clears the jam counter by paper jam type.

Purpose

Execute to check the paper jam status. Executes to clear counters when replacing the maintenance parts.

Method

1. Press the [Start] key.
2. Select the item to execute.

| Items | Contents |
|------------------|--------------------------------------|
| Cnt | Displaying/clearing the jam counts |
| Total Cnt | Displaying the accumulate jam counts |

Method: Cnt

1. Select [Cnt].
 - * :Number of occurrence is displayed by jam code.
Code of no occurrence is not indicated.
2. Select [Clear] to clear the jam counts.
 - * :Individual counters cannot be cleared.
3. Press the [Start] key to clear the counter value.

Method: Total Cnt

1. Select [Total Cnt].
 - * :Accumulate number of occurrence is displayed by jam code.
2. Change the screen using the [▲] [▼] key.
 - * :Unable to clear the accumulated jam counter values.

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U904 | Clearing the service call error counter (Message: Clear Service Call Counter) |
|-------------|--|

Contents

Displays/clears the number of times of service call errors by service call error type.

Purpose

Executes to check the service call error. Executes to clear counters when replacing the maintenance parts.

Method

1. Press the [Start] key.
2. Select the item to execute.

| Items | Contents |
|------------------|--|
| Cnt | Displays/clears the service call counter. |
| Total Cnt | Displays accumulate service call error counts. |

Method: Cnt

1. Select [Cnt].
 - * :Number of occurrence is displayed by service call error.
Code of no occurrence is not indicated.
2. Select [Clear] to clear the service call error counter.
 - * :Individual counters cannot be cleared.
3. Press the [Start] key to clear the counter value.

Method: Total Cnt

1. Select [Total Cnt].
 - * :Accumulate number of occurrence is displayed by service call error.
Unable to clear the accumulated service call error counter values.

Completion

- Press the [Stop] key.
- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U905 | Optional counter (Message: Option Counter) |
|-------------|---|

Contents

Displays the counter values of the document processor, 1000-sheet finisher, 3000-sheet finisher and inner finisher.

Purpose

Execute to check the usage status of the document processor, 1000-sheet finisher, 3000-sheet finisher and inner finisher.

Method

1. Press the [Start] key.
 2. Select the device to check.
- * : Switched to the counter screen.

| Items | Contents |
|--------------|--|
| DP | Displays the document processor count. |
| DF | Displays the document finisher count. |

Method: DP

* : Each counter is displayed.

| Items | Contents |
|--------------|--|
| ADP | Simplex original count is displayed. |
| RADP | Duplex original count is displayed. |
| CIS | Displays the count of simultaneous duplex scanning |

Method: DF

* : Each counter is displayed.

| Items | Contents |
|---------------|---------------------------------------|
| Sorter | Displays the sorter counter. |
| Staple | Displays the staple counter. |
| Punch | Displays the punch counter. |
| Stack | Displays the main tray eject counter. |

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U906 | Resetting the partial operation (Message: Reset Disable Function Mode) |
|-------------|---|

Contents

Release the service call error with partial operation.

Purpose

If the partial operation is executed with a broken cassette, etc., make sure to execute it after repairing the parts.

Method

- 1.Press the [Start] key.
- 2.Select [Execute].

| Items | Contents |
|----------------|------------------------------|
| Execute | Reset the partial operation. |

- 3.Press the [Start] key to release the partial operation.
- 4.Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U908 | Total counter (Message: Total Counter) |
|-------------|---|

Contents

Displays the total counter.

Purpose

Displays the total counter for check.

Method

- 1.Press the [Start] key.
- * :Displays the total count.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U910 | Black rate data (Message: Clear Coverage Data) |
|-------------|---|

Contents

Clears the accumulated data for the print coverage per A4 size paper and its period of time (as shown on the service status page).

Purpose

Clears data as required at the time such as maintenance

Method

1. Press the [Start] key.
2. Select [Execute].

| Items | Contents |
|----------------|---------------------------------|
| Execute | Clears the print coverage data. |

3. Press the [Start] key to clear the print coverage data.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U911 | Counter by media type (Message: Paper Size Counter) |
|-------------|--|

Contents

Displays the paper feed counts by paper size.

Purpose

Displays the counts to confirm when replacing the maintenance parts .

Method

1. Press the [Start] key.
- * :Displays the paper feed counts by paper size.

| Items | Contents |
|------------------|--------------------------------------|
| A4 | Displays A4 feed counts |
| B5 | Displays B5 feed counts |
| A5 | Displays A5 feed counts |
| Folio | Displays Folio feed counts. |
| Legal | Displays Legal feed counts |
| Letter | Displays Letter feed counts |
| Statement | Displays Statement feed counts |
| ETC | Displays paper feed counts of Other. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U917 | Read/Write Backup Data (Message: Read/Write Backup HDD Data(USB)) |
|-------------|--|

Contents

Retrieves the backup data to a USB memory from the main unit, or writes the data from the USB memory to the main unit.

Purpose

Makes a back up of the main unit information, and import or export to restore the main unit information

Method

1. Turn the power switch off.
2. Insert a USB memory into the USB memory slot.
3. Turn the power switch on.
 - * :Wait for about 10 seconds until the main unit recognizes a USB memory.
4. Enter maintenance mode U917.
5. Select [Export] or [Import], and press the [Start] key.

| Items | Contents |
|---------------|---|
| Import | Imports data from the USB memory to the main unit. |
| Export | Retrieving data from the main unit to the USB memory. |

6. Select the object item.

| Items | Contents | Depending data* |
|---------------------|-----------------------------|--|
| Address Book | Address book information | - |
| Job Account | Job accounting information | - |
| One Touch | One-touch key information | Address book information |
| User | User management information | Job accounting information |
| Document Box | Document box information | Job accounting, User information |
| Shortcut | Short-cut information | Job accounting, User, Document Box information |
| Fax Forward | FAX forward information | Job accounting, User, Document Box information |
| System | System setting information | - |
| Network | Network setting information | - |
| Job Setting | Job setting information | - |
| Printer | Printer setting information | - |
| Fax Setting | FAX setting information | - |

| Items | Contents | Depending data* |
|----------------------|---------------------------|---|
| Program | Program information | Information of Address book, Job accounting, User management, Document box, FAX transfer and FAX setting |
| Panel Setting | Panel setting information | Information of Address book, Job accounting, User management, Document box, FAX transfer, FAX setting and Program |

* :Since data are dependent with each other, data other than selected are also retrieved or written.

7. Select the object item.

8. Press the [Start] key. Starts reading or writing.

* :The progress of selected item is displayed in %.

* :When an error occurs, the operation is canceled and an error code appears.

9. [Finish] appears after normal completion.

10. When selecting [Import], turn the power switch off then on, after completing writing. Wait more than 5 seconds between the power off and on.

Error codes

| Codes | Contents |
|-----------------------|--|
| e000 | Unspecified error |
| e0001 | Parameter error |
| e0002 | Generating a dummy file has failed. |
| e0003 | The XML file to import does not exist |
| e0004 | The exported file does not exist |
| e0100 to e01ff | Error in handling addressbook |
| e0200 to e02ff | Error in handling One-touch |
| e0300 to e03ff | Error in handling user management |
| e0400 to e04ff | Error in handling panel program data |
| e0500 to e05ff | Error in handling forwarding FAX data |
| e0600 to e06ff | Error in handling the system configuration |
| e0700 to e07ff | Error in handling network parameters |
| e0800 to e08ff | Error in handling job accounting |
| e0900 to e09ff | Error in handling short-cuts |
| e0a00 to e0aff | Error in handling job information |
| e0b00 to e0bff | Error in handling FAX data |
| e0c00: toe0cff | Error in handling printer data |
| e0d00 to e0dff | Error in handling panel data |
| e0e00 to e0eff | Error in handling document boxes |
| e1000 to e1fff | Error in the device-related process |
| e2000 to e2fff | Error in handling SOAP IF |
| e3000 to e3fff | Error in handling KM-WSDL IF |

| Codes | Contents |
|-----------------------|---|
| e4000 to e4fff | Error in process for import (e4002) A file mandatory for importing is missing (e4008) Invalid file header |
| e5000 to e5fff | Error in the SOAP data rewriting process |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U920 | Billing counter (Message: Charge Counter) |
|-------------|--|

Contents

Displays the billing count.

Purpose

Execute to check the current billing counts

Method

1. Press the [Start] key.
 2. Select the item to display.
- * : Switched to each display screen.

| Items | Contents |
|----------------------|----------------------|
| Main Function | Main function counts |
| Sub Function | Sub functions count |

Method: Main Function

* : The charge counts for the main functions are displayed.

| Items | Contents |
|------------------------|---------------------------------------|
| Col Copy (H) | Color copy counts (Coverage: High) |
| Col Copy (M) | Color copy counts (Coverage: Middle) |
| Col Copy (L) | Color copy counts (Coverage: Low) |
| Mono Color Copy | Displays mono color copy count. |
| B/W Copy | B/W copy count is displayed. |
| Col Prn (H) | Color print counts (Coverage: High) |
| Col Prn (M) | Color print counts (Coverage: Middle) |
| Col Prn (L) | Color print counts (Coverage: Low) |
| B/W Prn | B/W print count is displayed |
| B/W FAX | FAX count |

Method: Sub Function

* : The charge counts for the sub functions are displayed.

| Items | Contents |
|-------------------|--|
| Simplex | Simplex print count is displayed |
| Duplex | Duplex print count is displayed |
| Comb(Off) | Combine print counts (Off) is displayed |
| Comb(2in1) | Combine print counts (2in1) is displayed |
| Comb(4in1) | Combine print counts (4in1) is displayed |

Completion

Press the [Stop] key.

* : The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U927 | Clearing all the billing/life counters (Message: Clear All Charge/Life Counter (one time only)) |
|-------------|--|

Contents

Clears all charge counts and machine life counts.

Supplement

The total charge counts and the machine life counts can be cleared only once if all count values are 1000 or less.

Method

1. Press the [Start] key.
2. Select [Execute].

| Items | Contents |
|----------------|---|
| Execute | Initializes the billing count and machine life count. |

3. Press the [Start] key.

* :Clears all charge counts and machine life counts.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U928 | Machine life counter (Message: Machine Life Counter) |
|-------------|---|

Contents

The current machine life counts is displayed.

Purpose

Executed to check the machine life count

Method

1. Press the [Start] key.
- * :The current machine life counts is displayed.

| Items | Contents |
|--------------|---------------------------------|
| Cnt | Displays the machine life count |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U930 | Clear the main charger roller counts (Message: Clear Charger Roller Counter) |
|-------------|---|

Contents

Displays and clears the current main charger roller counts.

Purpose

To verify the main charger roller counts after replacing. Also, clear the counts after replacement

Method

1.Press the [Start] key.

* :The main charge roller counter for each color is displayed.

| Items | Contents |
|--------------|---|
| C | The current main charger roller count for C is displayed. |
| M | The current main charger roller count for M is displayed. |
| Y | The current main charger roller count for Y is displayed. |
| K | The current main charger roller count for K is displayed. |

Method: Clear

1.Select the item to set.

1.Select [Clear].

2.Press the [Start] key to clear the counter value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U933 | Setting the maintenance mode log (Message: Set Maintenance Mode Execute Log) |
|-------------|---|

Contents

Sets the function to record the in/out date of the maintenance mode or date executing each maintenance item individually and output the log file.

Purpose

Record the maintenance mode history to analyze the cause when a problem occurs.

Method

1. Press the [Start] key.
 2. Select the item to set.
- * :The screen for setting is displayed.

| Items | Contents |
|----------------|--------------------------------|
| Export | Exports Maintenance Log. |
| Setting | Maintenance log output setting |

Method: Export

1. Select [Execute].

| Items | Contents |
|----------------|---|
| Execute | Export the maintenance log to a USB memory. |

2. Press the [Start] key.
- Export the maintenance log to a USB memory.
 * :If a USB memory is not inserted, [Execute] is grayed out .
 * :Display OK/NG after execution.

Setting: Setting

1. Select the item to set.
- * :Select the key including the number to set indicated by each block.
 * :The screen for setting is displayed.

| Items | Contents |
|------------------|---|
| U000-U019 | Sets the maintenance log output for U000 to U019. |
| U020-U029 | Sets the maintenance log output for U020 to U029. |
| U030-U059 | Sets the maintenance log output for U030 to U059. |
| U060-U099 | Sets the maintenance log output for U060 to U099. |
| U100-U129 | Sets the maintenance log output for U100 to U129. |
| U130-U159 | Sets the maintenance log output for U130 to U159. |
| U160-U199 | Sets the maintenance log output for U160 to U199. |
| U200-U249 | Sets the maintenance log output for U200 to U249. |
| U250-U349 | Sets the maintenance log output for U250 to U349. |
| U400-U499 | Sets the maintenance log output for U400 to U499. |
| U500-U599 | Sets the maintenance log output for U500 to U599. |
| U600-U699 | Sets the maintenance log output for U600 to U699. |
| U900-U999 | Sets the maintenance log output for U900 to U999. |

2.Set on/off for the number desired to set.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | | |
|-------------|---|-------------------------------------|
| U942 | DP loop amount setting (Message: Adjust DP Original Loop Amount) | Simultaneous duplex scan model only |
|-------------|---|-------------------------------------|

Contents

Adjust the paper loop amount when using the document processor.

Purpose

Execute when original no-feed jam, skew or creases on the original appears.

Method

- 1.Press the [Start] key.
- 2.Press the [System Menu] key.
- 3.Place an original on the DP and press the [Start] key to make a test copy.
- 4.Press the [System Menu] key.
- 5.Select the item to adjust.
- 6.By using the [+] [-] keys or the numeric keys, change the setting value.

| Items | Contents | Setting range | Initial setting | Data variation |
|------------|----------------------------------|---------------|-----------------|----------------|
| Cis | Single-side original loop amount | -31 to 31 | 0 | 0.2445mm |

* :When the setting value is increased, the paper loop amount increase, and it decreases when the setting value is decreased.

Increase the set value if no feed jam or skew feed occurs and reduce the set value if creases appear on the original.

- 7.Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U952 | MMaintenance mode workflow (Message: Maintenance Mode Work Flow) |
|-------------|---|

Contents

Execute the maintenance items in the order of registration in the main unit or the USB memory.

Purpose

Execute to register regular maintenance items.

Method

1. Press the [Start] key.
 2. Select the item to execute.
- * : The screen for executing is displayed.

| Items | Contents |
|---------------------|--|
| Continue | Resume interrupted workflow. |
| Execute(USB) | Executes the workflow in a USB memory. |
| Execute | Execute the workflow saved in the main unit. |
| Entry(USB) | Executes the workflow in a USB memory. |
| Entry | Register the workflow in the main unit manually. |
| Log | Displays the latest workflow execution history. |

Method: Continue

1. Select maintenance item number to execute.
 2. Press the [Start] key.
- * : Selected maintenance mode is executed.

Method: Execute(USB)

1. Check the LED display is off and turn the power switch off.
2. Insert a USB memory into the USB memory slot.
3. Turn the power switch on.
4. Enter maintenance item U952.
5. Select [Execute(USB)].
6. Select [workflow].

| Items | Contents |
|-----------------------------|-------------------------------|
| WorkFlowData 01 - 07 | Workflow data in a USB memory |

7. Press the [Start] key.
- * : Execute the maintenance items in the order of registration in the workflow.

Method: Excute

1. Select the place to save the data to execute.

| Items | Contents |
|-------------------|-------------------------------------|
| Data 1 - 8 | Workflow save area in the main unit |

2. Select the item to execute.
3. Press the [Start] key to start the processing.

Method: Entry(USB)

1. Check the LED display is off and turn the power switch off.
2. Insert a USB memory into the USB memory slot.
3. Turn the power switch on.
4. Enter maintenance item U952.
5. Select [Entry(USB)].
6. Select [workflow].

| Items | Contents |
|-----------------------------|-------------------------------|
| WorkflowData 01 - 07 | Workflow data in a USB memory |

7. Select the workflow save area.

| Items | Contents |
|-------------------|-------------------------------------|
| Data 1 - 8 | Workflow save area in the main unit |

8. Select [Execute].
- * :Registers the workflow in a USB memory to the main unit.

Method: Entry

1. Select [Entry].
2. Select the workflow save area.

| Items | Contents |
|-------------------|-------------------------------------|
| Data 1 - 8 | Workflow save area in the main unit |

3. By using the [+] [-] keys or the numeric keys, enter the maintenance number to register in the workflow.

| Items | Contents |
|--------------------|--------------------------------|
| Flow 1 - 14 | Registered maintenance numbers |

4. Press the [Start] key to set the setting value.
5. Press the [Start] key.
- * :Execute the maintenance items in the order of registration in the workflow.

e.g.

When inserting a USB memory the following items can be registered: commands, texts and maintenance numbers (variable).

File format: xxx.mwf

- 1, SET UP, 464, 469, 410, 000, 927, 278
- 2, WARRANTY, 089, 000
- 3, MK-A, 119, 930, 140, 127, 167, 464, 469, 412, 410, 251
- 4, MK-B, 119, 930, 140, 464, 469, 412, 410, 251
- 5, EH SETUP, 411, 034, 246, 211

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|------------------|
| U964 | Log check |
|-------------|------------------|

Contents

Transfer the log files save in the HDD to a USB memory.

Purpose

Transfer the log file saved in the HDD to a USB memory for investigation when a failure occurs.

Method

1. Check the LED display is off and turn the power switch off.
2. Insert a USB memory into the USB memory slot.
3. Turn the power switch on.
4. Enter maintenance item U952.
5. Select [Execute].

| Items | Contents |
|----------------|------------------------|
| Execute | Transfer the log file. |

6. Press the [Start] key.
 - * :Starts transferring the log files saved in the HDD to a USB memory.
[Processing] is displayed. (About 3 to 5 minutes)
7. [Completed] appears after normal completion.
8. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.
 - * :An error code appears when there is an error.

Supplement

How to retrieve the log when the operation panel freezes

Log retrieving starts when pressing four keys on the operation panel (*, 8, 6, Clear) for 3 to 6 seconds.

The memory lamp is blinking during retrieving and turns off when completed.

The log retrieved this way can be saved in a USB memory.

Error codes

| Display | Contents |
|--------------------------|---|
| No USB Storage | The USB memory is not installed |
| No File | No file |
| Mount Error | USB memory mount error |
| File Delete Error | Failed to delete existing files in the USB memory |
| Copy Error | HDD to USB memory copy failure |
| Unmount Error | USB memory unmount error |
| Other Error | Other error |

Completion

Press the [Stop] key.

- * :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U969 | Toner area code (Message: Toner Area Code) |
|-------------|---|

Contents

Displays the toner area code.

Purpose

Execute to check the currently set toner area code and model code.

Method

1. Press the [Start] key.

* :Displays the toner area code and model code

| Items | Contents |
|-------------------|---------------------------|
| Area Code | Toner container area code |
| Model Code | Model code |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U977 | Setting the data capture mode (Message: Set Data Capture Mode) |
|-------------|---|

Contents

Stores the data sent to the main unit into a USB memory.

Purpose

Store the data sent to the main unit into a USB memory to check it.

Method

1. Press the [Start] key.

2. Select [Execute].

| Items | Contents |
|----------------|------------------------------|
| Execute | Stores data in a USB memory. |

3. Press the [Start] key.

* :When the operation is completed abnormally, an error code is displayed.

Error codes

| Items | Contents |
|-----------|---|
| 1 | USB memory is broken. USB memory was disconnected during data processing or is write-protected. |
| 4 | USB memory is full. |
| 50 | Other error occurs |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U984 | Developer unit number (Message: Developing Unit Number) |
|-------------|--|

Contents

Displays the developer unit number.

Purpose

Execute to check the developer unit number.

Method

1.Press the [Start] key.

* :Displays the developer unit number.

| Items | Contents |
|----------|---|
| C | Displays the Cyan developer unit number. |
| M | Displays the Magenta developer unit number. |
| Y | Indicates the Yellow developer unit number. |
| K | Displays the Black developer unit number. |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U985 | Developer unit history (Message: Developing Unit History) |
|-------------|--|

Contents

Displays the machine serial number and developer counter history.

Purpose

Displays the machine serial number and developer count to check.

Method

1.Press the [Start] key.

* :Select color to refer to.

| Items | Contents |
|----------|--|
| C | Displays the Cyan developer unit history. |
| M | Displays the Magenta developer unit history. |
| Y | Indicates the Yellow developer unit history. |
| K | Displays the Black developer unit history. |

* :Displays the machine serial number and 3 items of the developer counter history.

| Items | Contents |
|-------------------------------|-------------------------------|
| Machine History 1 to 3 | Machine serial number history |
| Cnt History1 to 3 | Developer counter history |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|--|
| U989 | HDD scan disk (Message: HDD Scandisk) |
|-------------|--|

Contents

Apply Scandisk to the HDD for data recovery.

Purpose

Execute recovery of HDD management data error by turning the power off while accessing to the HDD.

Method

1. Press the [Start] key.
2. Select [Execute].

| Items | Contents |
|----------------|-----------------------|
| Execute | HDD scan disk request |

3. Press the [Start] key to execute scandisk.
4. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U990 | Clearing the scanner lighting time (Message: Clear Scanner Lamp ON Time) |
|-------------|---|

Contents

Displays the accumulated CIS lighting time

Purpose

Execute to check the CIS usage.

Method

1. Press the [Start] key.
- * :CIS accumulated lighting time is displayed in minutes.

| Items | Contents |
|--------------|---|
| CIS | Displays the accumulated CIS lamp lighting time |

Completion

Press the [Stop] key.

* :The screen for selecting a maintenance item No. is displayed.

| | |
|-------------|---|
| U991 | Scanner counter (Message: Scanner Counter) |
|-------------|---|

Contents

Displays the scanner operation counts.

Purpose

Display the number of scanner operation to check the usage status.

Method

1. Press the [Start] key.

* :Current number of operation is displayed.

| Items | Contents |
|-------------------|---|
| Copy Scan | Displays times of copy and scan operations. |
| Fax Scan | Displays times of FAX scan operations. |
| Other Scan | Displays times of other scan operations. |

Completion

Press the [Stop] key.


* :The screen for selecting a maintenance item No. is displayed.

6-2 Service mode: 30ppm model only

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing the service mode

[Message Display]



NOTE

If the login user name entry screen appears, enter a login user name and password, and select [Login]. Login with the administrator privileges. The factory default login user name and login password are set as shown below.

Login User Name : 3000

Login Password : 3000

Service settings

| Items | Contents | page |
|------------------------------|---|-------------|
| FAX country code *1 | Initializes all data and image memory. | P.6-434 |
| FAX recall setting *1 | Set for connection. | P.6-435 |
| Altitude Adjustment | Sets the altitude adjustment mode. | P.6-436 |
| MC | Sets the main charger output. | P.6-436 |
| DEV-CLN | Execute developer refreshing. | P.6-437 |
| Memory diagnostics | Diagnose memory at power up (whether reading and writing are executable). | P.6-437 |

*1: For FAX kit installed model only

(2) Descriptions of service modes

FAX country code

Contents

Initializes software switches, and all data and image memory in the backup data on the FAX PWB according to the destination and OEM setting.

Purpose

To initialize the FAX PWB.

Method

1. Enter the Service Setting menu.
2. Using the [▲] [▼] key, select [FAX country code].
3. Press the [Start] key.
4. Enter the destination code using the numeric keys.
5. Press the [Start] key to set the setting value.
6. Press the [Start] key. Data initialization starts.

Destination code list

| Destina- tion code | Destination | Destina- tion code | Destination |
|-----------------------|--------------|-----------------------|--------------------------|
| 000 | Japan | 253 | CTR21 (European nations) |
| 007 | Argentina | ↑ | Italy |
| 009 | Australia | ↑ | Germany |
| 022 | Brazil | ↑ | Spain |
| 038 | China | ↑ | U.K. |
| 080 | Hong Kong | ↑ | Netherlands |
| 084 | Indonesia | ↑ | Sweden |
| 088 | Israel | ↑ | France |
| 097 | Korea | ↑ | Austria |
| 181 | U.S.A. | ↑ | Switzerland |
| 250 | Russia | ↑ | Belgium |
| 108 | Malaysia | ↑ | Denmark |
| 115 | Mexico | ↑ | Finland |
| 126 | New Zealand | ↑ | Portugal |
| 136 | Peru | ↑ | Ireland |
| 137 | Philippines | ↑ | Norway |
| 152 | Middle East | 254 | Taiwan |
| 156 | Singapore | | |
| 159 | South Africa | | |
| 169 | Thailand | | |

Completion

Press the [Stop] key.

| |
|----------------------------|
| FAX ringing setting |
|----------------------------|

Contents

Selects if the FAX is connected to either a PBX or public switched telephone network.
 Selects the mode to connect an outside call when connected to a PBX.
 Registering the access code for connection to PSTN

Purpose

Execute as required.

Method

1. Enter the Service Setting menu.
2. Using the [▲] [▼] key, select [FAX recall setting].
3. Press the [Start] key.

| Items | Contents |
|---------------------------------------|---------------------------------|
| Exchange selection | PBX/PSTN connection setting |
| PBX setting | PBX external connection setting |
| PSTN connection number setting | PSTN access code setting |

Setting: Exchange selection

1. Using the [▲] [▼] key, select [Exchange selection].
2. Press the [Start] key.
3. Using the [▲] [▼] key, select [PBX] or [PSTN].
4. Press the [Start] key to set the setting value.

Setting: PBX setting

1. Using the [▲] [▼] key, select [PBX setting].
2. Press the [Start] key.
3. Using the [▲] [▼] key, select [Loop], [Flash] or [Earth].
4. Press the [Start] key to set the setting value.

Setting: PSTN access code setting

1. Using the [▲] [▼] key, select [PSTN connection number setting].
2. Press the [Start] key.
3. Enter the access code using the numeric keys. (0 to 9, 00 to 99)
4. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

Altitude Adjustment**Description**

Sets the altitude adjustment mode.

Purpose

Execute when print quality deteriorates in the installation at the altitude of 1,500 meters or higher

Method

1. Enter the Service Setting menu.
2. Using the [▲] [▼] key, select [Altitude Adj.].
3. Press the [Start] key.
4. Using the [▲] [▼] keys, select [Normal], [1001 - 2000m], [2001 - 3000m] or [3001 - 3500m].
5. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

MC**Description**

Sets the main charger output.

* :Executable only when the altitude adjustment mode is set to "Normal".

Purpose

Execute when the image density declines, dirt of a background or an offset has occurred.

Method

1. Enter the Service Setting menu.
2. Using the [▲] [▼] key, select [MC].
3. Press the [Start] key.
4. Using the [▲] [▼] key, select the setting "1" to "4".
5. Press the [Start] key to set the setting value.

Completion

Press the [Stop] key.

DEV-CLN**Description**

The laser output of the image data, exposure, developing and primary transfer is executed for ten pages equivalent. (Paper is not fed)

Purpose

Execute when the image failure or problem in the developer unit occurs

Method

1. Enter the Service Setting menu.
2. Using the [▲] [▼] key, select [DEV-CLN].
3. Press the [Start] key.

* :Developer refresh is executed by forming image with toner on the primary transfer belt.

Completion

Press the [Stop] key.

Memory diagnostics**Contents**

Diagnose memory at power-up (whether reading and writing are executable).

Purpose

Check if the memory device is defective that may cause an unresolvable F-code error, locking or abnormal images. Checks the memory failure.

Method

1. Enter the Service Setting menu.
2. Using the [▲] [▼] key, select [Mem.Diagnostics].
3. Press [Start].
4. Turn the power switch off then on. Wait more than 5 seconds between the power off and on.

Completion

Press the [Stop] key.

This page is intentionally left blank.

7 Troubleshooting

7-1 Paper misfeed detection

(1) Paper misfeed indication

When a paper misfeed occurs, the machine immediately stops printing and displays the paper misfeed message on the operation panel. To remove paper misfed in the machine, pull out the cassette, open the front cover or paper conveying cover.

The locations are displayed on the operation panel when a paper jam has occurred.

Jam location indication




Figure 7-1

- | | |
|---|---|
| A. Misfeed in the cassette 1 | I. Misfeed inside the bridge conveying |
| B. Misfeed in the cassette 2 (550-sheet × 1) | J. Misfeed inside the mail box paper |
| C. Misfeed in the cassette 3 (550-sheet × 2) | K. Misfeed inside the inner finisher |
| C. Misfeed in the cassette 3 (2250-sheet × 1) | L. Paper jam at the document processor |
| D. Misfeed in the cassette 4 (550-sheet × 2) | M. Misfeed inside the 1000-sheet finisher |
| E. Misfeed in MP tray | M. Misfeed inside the 3000-sheet finisher |
| F. Misfeed inside the right cover 1 | |
| G. Misfeed inside the right cover 2 | |
| H. Misfeed inside the right cover 3 | |

(2) Paper misfeed detection condition

Main unit + Optional unit




Figure 7-2

List of JAM Code

| Code | Contents | Detection conditions | JAM Position* |
|------|--|---|---------------|
| 0000 | Initial jam | The power is turned on when a sensor in the conveying system is on. | - |
| 0100 | Secondary feeding timeout | Secondary paper feed request given by the controller is unreachable. | - |
| 0101 | Wait for ready of the print-process package | Before the paper feeding, the reply of Standby-Ready from the driving function does not come for 40 seconds, or before the secondary paper feeding, the reply of StartReady from the drive function does not come for 40 seconds. | - |
| 0104 | Wait for ready of conveying package | Before the paper feeding or the secondary paper feeding starts, the permission notice of the paper feeding or the secondary paper feeding does not come for 40 seconds. | - |
| 0105 | Drive prevention jam | A drive does not stop. | - |
| 0106 | Paper feeding request for duplex printing time out | Paper feeding request for duplex printing given by the controller is unreachable. | - |
| 0107 | Wait for ready of fuser package | Fuser package does not become ready. | - |
| 0110 | Right cover open jam | The right cover is opened during printing. | - |
| 0111 | Front cover open jam | The front cover is opened during printing. | - |
| 0114 | Bridge cover open jam | The bridge cover is opened during printing. | - |
| 0211 | Cassette cover 2 open jam | The cassette cover 2 is opened during printing. | - |
| 0212 | Cassette cover 3 open jam | The cassette cover 3 is opened during printing. | - |
| 0213 | Cassette cover 4 open jam | The cassette cover 4 is opened during printing. | - |
| 0300 | DF ejection jam | An ejection-completed error has occurred. | - |
| 0501 | No paper feeding jam | Registration sensor (RS) does not turn on during paper feed from cassette 1. | A |
| 0502 | | PF feed sensor 1 (PFFS1) does not turn on during paper feed from cassette 2. | B |
| 0503 | | PF feed sensor 2 (PFFS2) does not turn on during paper feed from cassette 3. | C |
| 0504 | | PF feed sensor 3 (PFFS3) does not turn on during paper feed from cassette 4. | D |
| 0508 | | Registration sensor (RS) does not turn on during paper feed from duplex section. | F |
| 0509 | | Registration sensor (RS) does not turn on during paper feed from MP tray. | E |

| Code | Contents | Detection conditions | JAM Position* |
|-------------|-------------------------------------|---|----------------------|
| 0511 | Multiple sheets jam | Registration sensor (RS) does not turn off during paper feed from cassette 1. | P |
| 0512 | | PF feed sensor 1 (PFFS1) does not turn off during paper feed from cassette 2. | N |
| 0513 | | PF feed sensor 2 (PFFS2) does not turn off during paper feed from cassette 3. | N |
| 0514 | | PF feed sensor 3 (PFFS3) does not turn off during paper feed from cassette 4. | N |
| 0518 | | Registration sensor (RS) does not turn off during paper feed from duplex section. | P |
| 0519 | | Registration sensor (RS) does not turn off during paper feed from MP tray. | P |
| 1403 | PF feed sensor 2 non arrival jam | PF feed sensor 2 (PFFS2) does not turn on during paper feed from cassette 3. | C |
| 1404 | | PF feed sensor 2 (PFFS2) does not turn on during paper feed from cassette 4. | H |
| 1413 | PF feed sensor 2 stay jam | PF feed sensor 2 (PFFS2) does not turn off during paper feed from cassette 3. | H |
| 1414 | | PF feed sensor 2 (PFFS2) does not turn off during paper feed from cassette 4. | H |
| 1604 | PF feed sensor 3 non arrival jam | PF feed sensor 3 (PFFS3) does not turn on during paper feed from cassette 4. | H |
| 1614 | PF feed sensor 3 stay jam | PF feed sensor 3 (PFFS3) does not turn off during paper feed from cassette 4. | H |
| 4002 | Registration sensor non arrival jam | Registration sensor (RS) does not turn on during paper feed from cassette 2. | N |
| 4003 | | Registration sensor (RS) does not turn on during paper feed from cassette 3. | N |
| 4004 | | Registration sensor (RS) does not turn on during paper feed from cassette 4. | N |
| 4012 | Registration sensor stay jam | Registration sensor (RS) does not turn off during paper feed from cassette 2. | P |
| 4013 | | Registration sensor (RS) does not turn off during paper feed from cassette 3. | P |
| 4014 | | Registration sensor (RS) does not turn off during paper feed from cassette 4. | P |

| Code | Contents | Detection conditions | JAM Position* |
|-------------|-------------------------------|--|----------------------|
| 4201 | Fuser sensor non arrival jam | Fuser sensor (ES) does not turn on during paper feed from cassette 1. | P |
| 4202 | | Fuser sensor (ES) does not turn on during paper feed from cassette 2. | P |
| 4203 | | Fuser sensor (ES) does not turn on during paper feed from cassette 3. | P |
| 4204 | | Fuser sensor (ES) does not turn on during paper feed from cassette 4. | P |
| 4208 | | Fuser sensor (ES) does not turn on during paper feed from duplex section. | P |
| 4209 | | Fuser sensor (ES) does not turn on during paper feed from MP tray. | P |
| 4211 | Fuser sensor stay jam | Fuser sensor (ES) does not turn off during paper feed from cassette 1. | I |
| 4212 | | Fuser sensor (ES) does not turn off during paper feed from cassette 2. | I |
| 4213 | | Fuser sensor (ES) does not turn off during paper feed from cassette 3. | I |
| 4214 | | Fuser sensor (ES) does not turn off during paper feed from cassette 4. | I |
| 4218 | | Fuser sensor (ES) does not turn off during paper feed from duplex section. | I |
| 4219 | | Fuser sensor (ES) does not turn off during paper feed from MP tray. | I |
| 4301 | Duplex sensor non arrival jam | Duplex sensor (DUS) does not turn on during paper feed from cassette 1. | O |
| 4302 | | Duplex sensor (DUS) does not turn on during paper feed from cassette 2. | O |
| 4303 | | Duplex sensor (DUS) does not turn on during paper feed from cassette 3. | O |
| 4304 | | Duplex sensor (DUS) does not turn on during paper feed from cassette 4. | O |
| 4309 | | Duplex sensor (DUS) does not turn on during paper feed from MP tray. | O |

| Code | Contents | Detection conditions | JAM Position* |
|-------------|---------------------------------------|--|----------------------|
| 4311 | Duplex sensor stay jam | Duplex sensor (DUS) does not turn off during paper feed from cassette 1. | O |
| 4312 | | Duplex sensor (DUS) does not turn off during paper feed from cassette 2. | O |
| 4313 | | Duplex sensor (DUS) does not turn off during paper feed from cassette 3. | O |
| 4314 | | Duplex sensor (DUS) does not turn off during paper feed from cassette 4. | O |
| 4319 | | Duplex sensor (DUS) does not turn off during paper feed from MP tray. | O |
| 4901 | BR conveying sensor 1 non arrival jam | BR conveying sensor 1 (BRCS1) does not turn on during paper feed from cassette 1. | I |
| 4902 | | BR conveying sensor 1 (BRCS1) does not turn on during paper feed from cassette 2. | I |
| 4903 | | BR conveying sensor 1 (BRCS1) does not turn on during paper feed from cassette 3. | I |
| 4904 | | BR conveying sensor 1 (BRCS1) does not turn on during paper feed from cassette 4. | I |
| 4908 | | BR conveying sensor 1 (BRCS1) does not turn on during paper feed from duplex section. | I |
| 4909 | | BR conveying sensor (BRCS1) does not turn on during paper feed from MP tray. | I |
| 4911 | BR conveying sensor 1 stay jam | BR conveying sensor 1 (BRCS1) does not turn off during paper feed from cassette 1. | N |
| 4912 | | BR conveying sensor 1 (BRCS1) does not turn off during paper feed from cassette 2. | N |
| 4913 | | BR conveying sensor 1 (BRCS1) does not turn off during paper feed from cassette 3. | N |
| 4914 | | BR conveying sensor 1 (BRCS1) does not turn off during paper feed from cassette 4. | N |
| 4918 | | BR conveying sensor 1 (BRCS1) does not turn off during paper feed from duplex section. | N |
| 4919 | | BR conveying sensor 1 (BRCS1) does not turn off during paper feed from MP tray. | N |

| Code | Contents | Detection conditions | JAM Position* |
|------|---------------------------------------|---|---------------|
| 5001 | BR conveying sensor 2 non arrival jam | BR conveying sensor 2 (BRCS2) does not turn on during paper feed from cassette 1. | N |
| 5002 | | BR conveying sensor 2 (BRCS2) does not turn on during paper feed from cassette 2. | N |
| 5003 | | BR conveying sensor 2 (BRCS2) does not turn on during paper feed from cassette 3. | N |
| 5004 | | BR conveying sensor 2 (BRCS2) does not turn on during paper feed from cassette 4. | N |
| 5008 | | BR conveying sensor 2 (BRCS2) does not turn on during paper feed from duplex section. | N |
| 5009 | | BR conveying sensor 2 (BRCS2) does not turn on during paper feed from MP tray. | N |
| 5011 | BR conveying sensor 2 stay jam | BR conveying sensor 2 (BRCS2) does not turn off during paper feed from cassette 1. | N |
| 5012 | | BR conveying sensor 2 (BRCS2) does not turn off during paper feed from cassette 2. | N |
| 5013 | | BR conveying sensor 2 (BRCS2) does not turn off during paper feed from cassette 3. | N |
| 5014 | | BR conveying sensor 2 (BRCS2) does not turn off during paper feed from cassette 4. | N |
| 5018 | | BR conveying sensor 2 (BRCS2) does not turn off during paper feed from duplex section. | N |
| 5019 | | BR conveying sensor 2 (BRCS2) does not turn off during paper feed from MP tray. | N |
| 6000 | DF entry failure | DF paper entry sensor (DFPES) became on before the eject signal is output from the main unit. (3000-sheet DF) | M |
| 6001 | | DF paper entry sensor (DFPES) became on before the eject signal is output from the main unit. (1000-sheet DF) | M |
| 6002 | | DF paper entry sensor (DFPES) became on before the eject signal is output from the main unit. (Inner DF) | K |
| 6012 | DF unit open jam | DF unit opened during the DF operation. (Inner DF) | - |
| 6020 | Front cover open jam | Front cover opened during the DF operation. (3000-sheet DF) | - |
| 6021 | Front cover open jam | Front cover opened during the DF operation. (1000-sheet DF) | - |
| 6041 | Top cover open jam | Top cover opened during the DF operation. (1000-sheet DF) | - |

| Code | Contents | Detection conditions | JAM Position* |
|-------------|---------------------------------------|---|----------------------|
| 6100 | DF paper entry sensor non arrival jam | DF paper entry sensor (DFPES) does not become on when passing the specified time after receiving the main unit eject signal. (3000-sheet DF) | M |
| 6101 | | DF paper entry sensor (DFPES) does not become on when passing the specified time after receiving the main unit eject signal. (1000-sheet DF) | M |
| 6102 | | DF paper entry sensor (DFPES) does not become on when passing the specified time after receiving the main unit eject signal. (Inner DF) | K |
| 6110 | DF entry sensor stay jam | DF paper entry sensor (DFPES) is not turned off when passing the specified time after it is turned on. (3000-sheet DF) | M |
| 6111 | | DF paper entry sensor (DFPES) is not turned off when passing the specified time after it is turned on. (1000-sheet DF) | M |
| 6112 | | DF paper entry sensor (DFPES) is not turned off when passing the specified time after it is turned on. (Inner DF) | K |
| 6200 | DF sub eject sensor non arrival jam | DF sub eject sensor (DFSES) is not turned on when passing the specified time after DF paper entry sensor (DFPES) is turned on. | M |
| 6210 | DF sub eject sensor stay jam | DF sub eject sensor (DFSES) is not turned off when passing the specified time after it is turned on. | M |
| 6300 | DF middle sensor non arrival jam | DF middle sensor (DFMES) is not turned on when passing the specified time after the DF paper entry sensor (DFPES) is turned on. (3000-sheet DF) | M |
| 6301 | | DF middle sensor (DFMES) is not turned on when passing the specified time after the DF paper entry sensor (DFPES) is turned on. (1000-sheet DF) | M |
| 6310 | DF middle sensor stay jam | DF middle sensor (DFMES) is not turned off when passing the specified time after it is turned on. (3000-sheet DF) | M |
| 6311 | | DF middle sensor (DFMES) is not turned off when passing the specified time after it is turned on. (1000-sheet DF) | M |

| Code | Contents | Detection conditions | JAM Position* |
|-------------|--|--|----------------------|
| 6410 | DF tray top sensor stay jam | DF eject sensor (DFMETS) is not turned off when passing the specified time after it is turned on. (3000-sheet DF) | M |
| 6411 | | DF eject sensor (DFMETS) is not turned off when passing the specified time after it is turned on. (1000-sheet DF) | M |
| 6412 | | DF eject sensor (DFMETS) is not turned off when passing the specified time after it is turned on. (Inner DF) | K |
| 6510 | DF bundle eject sensor stay jam | DF bundle eject sensor (DFBDS) is not turned off after starting the bundle eject. (3000-sheet DF) | M |
| 6511 | | DF bundle eject sensor (DFBDS) is not turned off after starting the bundle eject. (1000-sheet DF) | M |
| 6512 | | DF bundle eject sensor (DFBDS) is not turned off after starting the bundle eject. (Inner DF) | K |
| 6810 | DF side registration sensor 1 stay jam | DF side registration sensor 1 (DFSRS1) is not turned off when passing the specified time after DF side registration motor 1 (DFS RM1) is driven. (3000-sheet DF) | M |
| 6811 | | DF side registration sensor 1 (DFSRS1) is not turned off when passing the specified time after DF side registration motor 1 (DFS RM1) is driven. (1000-sheet DF) | M |
| 6812 | | DF side registration sensor 1 (DFSRS1) is not turned off when passing the specified time after DF side registration motor 1 (DFS RM1) is driven. (Inner DF) | K |
| 6910 | DF side registration sensor 2 stay jam | DF side registration sensor 2 (DFSRS2) is not turned off when passing the specified time after DF side registration motor 2 (DFS RM2) is driven. (3000-sheet DF) | M |
| 6911 | | DF side registration sensor 2 (DFSRS2) is not turned off when passing the specified time after DF side registration motor 2 (DFS RM2) is driven. (1000-sheet DF) | M |
| 6912 | | DF side registration sensor 2 (DFSRS2) is not turned off when passing the specified time after DF side registration motor 2 (DFS RM2) is driven. (Inner DF) | K |

| Code | Contents | Detection conditions | JAM Position* |
|------|--|---|---------------|
| 7000 | DF staple error | DF staple sensor (DFSTS) is not turned on when passing the specified time after DF staple motor (DFSTM) is driven. (3000-sheet DF) | M |
| 7001 | | DF staple sensor (DFSTS) is not turned on when passing the specified time after DF staple motor (DFSTM) is driven. (1000-sheet DF) | M |
| 7002 | | DF staple sensor (DFSTS) is not turned on when passing the specified time after DF staple motor (DFSTM) is driven. (Inner DF) | K |
| 7800 | MB eject sensor non arrival jam | MB eject sensor (MBES) does not become on when passing the specified time after receiving the main unit eject signal. | J |
| 7810 | MB eject sensor stay jam | MB eject sensor (MBES) is not turned off when passing the specified time after it is turned on. | J |
| 7900 | Middle puddle jam | Home position cannot be detected when passing 1s after the motor starts up. (3000-sheet DF) | M |
| 7901 | | Home position cannot be detected when passing 1s after the motor starts up. (1000-sheet DF) | M |
| 7902 | | Home position cannot be detected when passing 1s after the motor starts up. (Inner DF) | J |
| 9000 | DP no original feeding jam | DP feed sensor (DPFS) is not turned on when feeding originals from the DP. (5 retrials) | L |
| 9004 | DP switchback jam | DP registration sensor (DPRS) is not turned on when passing the specified time after the DP feed-shift sensor (DPSFS) is turned on. | L |
| 9009 | DP original conveying jam | The next original was in standby for the secondary feed during image scanning. | L |
| 9010 | Document processor open | Document processor is opened during original conveying. | - |
| 9011 | DP top cover open | DP top cover was opened during original conveying. | - |
| 9110 | DP feed sensor stay jam | DP feed sensor (DPFS) does not turn off when passing the specified time after DP registration sensor (DPRS) is turned on. | L |
| 9200 | DP registration sensor non arrival jam | DP registration sensor (DPRS) is not turned on when passing the specified time after DP feed sensor (DPFS) is turned on. | L |
| 9210 | DP registration sensor stay jam | DP registration sensor (DPRS) is not turned off when passing the specified time after DP feed sensor (DPFS) is turned off. | L |
| 9300 | DPCIS sensor non arrival jam | DPCIS sensor (DPCS) is not turned on when passing the specified time after DP feed sensor (DPFS) is turned on. | L |

| Code | Contents | Detection conditions | JAM Position* |
|-------------|----------------------------------|---|----------------------|
| 9310 | DPCIS sensor stay jam | DPCIS sensor (DPCS) is not turned off when passing the specified time after the DP feed sensor (DPFS) is turned off. | L |
| 9400 | DP timing sensor non arrival jam | DP timing sensor (DPTS) is not turned on when passing the specified time during original conveying. (5 retrials) | L |
| 9410 | DP timing sensor stay jam | DP timing sensor (DPTS) is not turned off when passing the specified time after DP registration sensor (DPRS) is turned on. | L |
| 9600 | DP eject sensor non arrival jam | DP eject sensor (DPES) is not turned on when passing the specified time after DP timing sensor (DPTS) is turned on. | L |
| 9610 | DP eject sensor stay jam | DP eject sensor (DPES) is not turned off when the specified time after DP timing sensor (DPTS) is turned off. | L |

* Refer to figure 7-2 for the paper misfeed indication (see page P.7-2).

(3) First check items

If the paper is fed askew, jammed, curled, or leading-edge dog-eared, first check the following items.

| Check items | Check description | Corrective Action |
|--------------------------------|---|---|
| Paper | 1. Check if the paper delivered is dog-eared, skewed or creased. | 1. If a dog-ear occurs, check if there are any objects existing in the conveying paths, and if any, fix it. 2. If the paper is fed askew or creased, execute No.2. below |
| | 2. Check how paper is loaded in the cassette (paper feeder). Check that the paper has been properly aligned with the paper width guides and the rear guide; it has been loaded without skewing; or it is not damaged. (creased paper, main unit jam) | Adjust the paper width guides to the size of the paper. |
| | 3. Check how paper is loaded. Check if the cutting edge of the paper bundle inside is crumpled or bent. | If the cutting edge of the paper bundle is crumpled, fan the paper before loading. If the paper is folded, stretch before loading in the cassette. |
| | 4. Check if the paper is moist, wavy, or curled. | 1. Load the paper in the cassette upside down. 2. Load the paper in the cassette after rotating it 180 degrees. 3. Change the paper. |
| | 5. Check if the paper loaded in the cassette was stored in a continuously humid place. | Instruct the user to store the paper in a dry, less humid place. |
| | 6. Check if the paper conforms to the specification. | Isolate the cause of the problem by replacing the paper with the recommended paper. (see page P.1-1) |
| Settings/ Detection | 1. Check if the margin is 4.0 ± 2.5 mm from the leading edge of paper. | If there is no margin of 4.0 ± 2.5 mm from the leading edge, adjust the leading margin by U402. (see page P.6-111, P.6-334) |
| | 2. Check the operation panel if the paper size is correctly set. (Multiple jam)(MFP: Perform U000 to obtain an Event Log to check if the paper size and the size of the paper loaded are met when jam has occurred and if the size of the original document and the paper size are met.) (see page P.1-1) | If the paper size is incorrectly displayed, set the size of the paper cassette properly. |
| | 3. Check that paper settings are made in accordance with the paper being used. (Jam caused by faulty separation) | Select Original/Paper settings under [Common Settings] in the system menu to set media type and weight of paper. |

| Check items | Check description | Corrective Action |
|--|--|--|
| Rear cover | Check if the rear cover of the main unit is slightly pulled or closed | Open the rear cover and close it firmly. (Check the position of the safety switch) |
| Conveying guide Entry guide Feedshift guide | 1. Check that the foreign objects including torn paper, paper clips, etc., do not exist in the paper conveying paths. | If foreign objects such as torn paper, etc. remain in the paper conveying path, remove them |
| | 2. Check that the paper conveying guide and the separation needles are not contaminated with toner, paper dust, etc. | 1. If dirty, clean the guide, ribs (with a cloth), and the separation needles (with a cleaning brush). 2. If the ribs of the conveying guides were broken or deposited with toner, replace the conveying guide. |
| | 3. Check that the paper conveying guide has no burrs, deformations, or abrasions; and it is properly attached without being floated. | Clean the conveying guide or the paper entry guide. Remove any protrusions including burrs. If floated, reattach. If deformation or abrasion is observed, replace it. |
| | 4. Check that the guide is smoothly operative. Check that the guide is smoothly operative by hand. | If the guide does not operate smoothly, replace the guide or the unit. |
| | 5. Check that the guide is smoothly operative. | If the guide is inoperative or won't operate smoothly, reattach the guide or replace the unit. |
| Conveying roller Paper feed roller | 1. Check the conveying rollers have no paper dust, toner, or foreign objects stuck. Check the variation of the external diameter of the roller or abrasion is not observed with the conveying roller. | Clean the conveying rollers or the pulleys. If variation in the external diameter or abrasion is observed, replace it. |
| | 2. Turn the safety switch of the cover on and check if the motor and clutch operate. | 1. If the conveying motor or the clutch is inoperative, replace it. 2. If stained, replace the clutch. 3. If the clutch is kept turned on due to a pulled wire, realign the wire. |
| | 3. Check that the conveying roller rotates without overloading. Check the bushing or the roller shaft is not contaminated. Check that the spring has not fallen off and is attached so that it is properly applying pressure against the rollers or pulleys. | Clean the roller shaft or bushing. Reattach it while checking the pressure of the spring. |

| Check items | Check description | Corrective Action |
|---------------|--|--|
| Sensor | 1. Check if it does not operate with smoothness due to an abnormal move or dropping off of the actuator of the conveying switch. | Reattach the actuator or the return spring. |
| | 2. Check that the surface of the sensor is not contaminated with toner, paper dust, etc. | If dirty, clean the sensor. |
| | 3. Check the sensors are operated normally. | If the sensor is inoperative, replace the switch. |
| Static | Check if the location is susceptible to build static discharge at the conveying guide during printing. | Reattach and reconnect the static discharge sheet at the eject unit and the metal guide at the transfer unit so that they are properly grounded. |

(4) Items and corrective actions relating to the device that will cause paper jam

| Jam types | Check description | Corrective Action |
|---|--|--|
| No paper feeding jam or the leading edge of paper is curled back at the position of the roller (J0501, J0502, J0503, J0504, J0509) | 1. Check if the jammed paper or printed paper has a tear at its leading edge caused by the roller. | Replace the paper feed roller. (Rubber roller life: 200K image (30/35ppm models), 300K image (40ppm model)) Decrease the spring pressure to pinch the retard rollers if the component is under to its expected life. |
| | 2. Check for abrasion and paper dust on the feed roller and pickup rollers. | Clean the paper feed roller and the pickup roller. Or, if not corrected, replace. |
| | 3. Check the pickup roller and paper feed roller are rotating. | If the clutch is disconnected or or stained, replace the conveying drive unit. |
| | 4. Check that the conveying force of the pickup roller is sufficient. | Increase the conveying force during paper pickup by increasing the spring load of the pickup roller. |

| Jam types | Check description | Corrective Action |
|--|---|--|
| Multiple-feed Jam (J0511, J0512, J0513, J0514, J0519) | 1. Check if the cutting edge of the paper bundle is crumpled or the cassette is loaded with multiple times of replenishing paper. | If the cutting edge of the paper bundle is crumpled or the cassette is loaded with multiple times of replenishing paper, load new paper. |
| | 2. Checking paper size Check that the size of the loaded paper and the paper size chosen on the operation panel match. | If the paper size does not match 1. If the cassette paper width guides has gaps with paper, set them properly. 2. Insert the cassette until the paper size detector switch is turned on. If the size is not detectable even after inserting all the way, check the position of the size detection switch, or replace the size detection switch. |
| | | If the paper size matches 1. If paper out of the specification, such as coated paper, inkjet paper, etc., is used, replace the paper. 2. Reattach the retard roller in the primary paper feed unit if it is mounted to the opposite direction. 3. Check if the retard spring has fallen off of the mounting position. 4. If the retard spring has not dropped off of the mount position, decrease the spring pressure that is applied to the separation rollers. 5. Replace the retard roller unit. |
| | 3. Check if paper dust and abrasion are observed on the retard roller. | If the retard roller is dirty, clean. If abrasion is observed, replace it. |
| | 4. Check if the clutches are rotating together with other components when only the motor is turned on. | If the clutches rotate along with other components and rust or other objects are observed, replace the feed drive unit. |
| Duplex no paper feeding Jam (J0508) Duplex Multiple-feed Jam (J0518) | Check if the registration sensor is detected. | If the registration sensor is not working, replace the registration sensor. |

| Jam types | Check description | Corrective Action |
|--|---|---|
| PF feed sensor stay jam (J1413, J1414, J1614) | 1. Check the operation of the sensor. | If the sensor is inoperative, replace it. |
| | 2. Check if the PF paper feed clutch rotates together with other components. | If rusty, replace the clutch. Re-assemble the clutch so that it is not continuously energized. Change of wiring position, etc. |
| | 3. Check if the conveying guide is attached while twisted. (If the attached parts of the guide is are lifted, the actuator does not protrude sufficiently.) | If the bracket is attached while twisted, remove the screw securing the conveying guide and properly reattach the bracket in the right position. |
| | 4. Check if wrinkles are observed due to the slack of paper during paper feeding. | Adjust the paper width guides to the size of the paper. |
| PF feed sensor non arrival jam (J1403/J1404, J1604) | 1. Check the operation of the sensor. | If the sensor is inoperative, replace it. |
| | 2. Check the operation of the motor. Check the transmission of the gear drive by the clutch operation. *: Confirm that the conveying roller rotates and moves smoothly in the thrust direction. | If the roller does not rotate smoothly, loosen the screws securing the gear bracket and retighten them while adjusting the mounting position of the gear bracket so that the driving gears are engaged. (so that the gap between the gear bracket and frame is eliminated.) |
| Eject sensor non arrival jam, stay jam (J420X, J421X) | 1. If paper jams at the feedshift guide, check if the guide is smoothly operative. | If the clearance between the housing and the feedshift guide is too small for the guide to smoothly move, replace the feedshift guide. |
| | 2. Check if the actuator of the eject sensor operates smoothly. | 1. If the actuator is not in the proper position, or does not return due to falling of the return spring, reattach it. 2. If the actuator is damaged or deformed, replace it. |
| | 3. Make sure the eject sensor does not show a false detection. | Replace the defective eject sensor or the eject unit. |

(5) Paper jam at feeding from paper feeder 1

Electrical parts that could cause paper jam during paper conveying at the primary feed (to the registration roller)

Timing of detection

| Jam code |
|--------------|
| J0501, J0511 |

Corrective Action

| Related parts | |
|-----------------------------|------------------|
| Registration sensor(RS) | Engine PWB(EPWB) |
| Paper feed clutch(FCL) | |
| Middle clutch(MCL) | |
| Developer motor BK(DLPM-BK) | |

| Check action at the occurrence Step J0501/J0502 | Corrective action at the occurrence | Point of checking connection of On/Off control signal output connector (terminal) |
|---|---|--|
| 1 | Items for Initial Checks | (see page P.7-12) |
| 2 | Registration sensor(RS): Conduct connectivity check, mounting location check, operation check | Engine PWB(EPWB) YC12-26: 30 ppm model YC18-26: 35/40 ppm models |
| 3 | Paper feed clutch(FCL): Operation check | Engine PWB(EPWB) YC13-A5: 30 ppm model YC19-A5: 35/40 ppm models |
| 4 | Middle clutch(MCL): Operation check | Engine PWB(EPWB) YC13-A7: 30 ppm model YC19-A7: 35/40 ppm models |
| 5 | Developer motor BK(DLPM-BK): Operation check | Engine PWB(EPWB) YC15-9/10/11/12: 30 ppm model YC22-9/10/11/12: 35/40 ppm models |
| 6 | Engine PWB(EPWB): Replace | |

(6) Paper jam at feeding from cassette 2 (paper feeder 1)

Electrical parts that could cause paper jam during paper conveying at the primary feed (to the registration roller)

Timing of detection

| Jam code |
|----------------------------|
| J0502, J0512, J4002, J4012 |

Corrective Action

| Related parts | |
|-----------------------------|---------------------|
| PF paper feed sensor(PFFS) | PF main PWB(PFMPWB) |
| PF paper feed clutch(PFFCL) | Engine PWB(EPWB) |
| PF paper feed motor(PFFM) | |

| Check action at the occurrence Step J0502/J0512 | Corrective action at the occurrence | Point of checking connection of On/Off control signal output connector (terminal) |
|---|--|---|
| 1 | Items for Initial Checks | (see page P.7-12) |
| 2 | PF Feed sensor 1 (PFFS1): Conduct connectivity check, mounting location check, operation check | PF main PWB(PFMPWB) YC4-5 |
| 3 | PF paper feed clutch(PFFCL1): Operation check | PF main PWB(PFMPWB) YC9-3 |
| 4 | PF paper feed motor(PFFM): Operation check | PF main PWB(PFMPWB) YC8-3/4/5/6 |
| 5 | PF main PWB(PFMPWB): Replace | |

| Check action at the occurrence Step J4002/J4012 | Corrective action at the occurrence | Point of checking connection of On/Off control signal output connector (terminal) |
|---|---|--|
| 1 | Items for Initial Checks | (see page P.7-12) |
| 2 | Registration sensor(RS): Conduct connectivity check, mounting location check, operation check | Engine PWB(EPWB) YC12-26: 30 ppm model YC18-26: 35/40 ppm models |
| 3 | Middle clutch(MCL): Operation check | Engine PWB(EPWB) YC13-A7: 30 ppm model YC19-A7: 35/40 ppm models |
| 4 | Developer motor BK(DLPM-BK): Operation check | Engine PWB(EPWB) YC15-9/10/11/12: 30 ppm model YC22-9/10/11/12: 35/40 ppm models |
| 5 | Engine PWB(EPWB): Replace | |

(7) Paper jam at feeding from the MP tray

Electrical parts that could cause paper jam during paper conveying at the primary feed (to the registration roller)

Timing of detection

| Jam code |
|-------------|
| J0509,J0519 |

Corrective Action

| Related parts | |
|-----------------------------|------------------|
| Registration sensor(RS) | Engine PWB(EPWB) |
| MP solenoid(MPSOL) | |
| Developer motor BK(DLPM-BK) | |
| Middle clutch(MCL) | |

| Check action at the occurrence Step J0509/J0519 | Corrective action at the occurrence | Point of checking connection of On/Off control signal output connector (terminal) |
|---|---|--|
| 1 | Items for Initial Checks | (see page P.7-12) |
| 2 | Registration sensor(RS): Conduct connectivity check, mounting location check, operation check | Engine PWB(EPWB) YC12-26: 30 ppm model YC18-26: 35/40 ppm models |
| 3 | MP solenoid(MPSOL): Operation check | Engine PWB(EPWB) YC12-29: 30 ppm model YC18-29: 35/40 ppm models |
| 4 | Middle clutch(MCL): Operation check | Engine PWB(EPWB) YC13-A7: 30 ppm model YC19-A7: 35/40 ppm models |
| 5 | Developer motor BK(DLPM-BK): Operation check | Engine PWB(EPWB) YC15-9/10/11/12: 30 ppm model YC22-9/10/11/12: 35/40 ppm models |
| 6 | Engine PWB(EPWB): Replace | |

(8) Paper jam at the duplex re-feeding section

Electrical parts that could cause paper jam during paper conveying at the primary feed (to the registration roller)

Timing of detection

| Jam code |
|-------------|
| J0508,J0518 |

Corrective Action

| Related parts | |
|-----------------------------|------------------|
| Registration sensor(RS) | Engine PWB(EPWB) |
| Duplex clutch(DUCL) | |
| Paper feed clutch(FCL) | |
| Developer motor BK(DLPM-BK) | |

| Check action at the occurrence Step J0508/J0518 | Corrective action at the occurrence | Point of checking connection of On/Off control signal output connector (terminal) |
|---|---|--|
| 1 | Items for Initial Checks | (see page P.7-12) |
| 2 | Registration sensor(RS): Conduct connectivity check, mounting location check, operation check | Engine PWB(EPWB) YC12-26: 30 ppm model YC19-26: 35/40 ppm models |
| 3 | Duplex clutch(DUCL): Operation check | Engine PWB(EPWB) YC13-A9: 30 ppm model YC19-A9: 35/40 ppm models |
| 4 | Middle clutch(MCL): Operation check | Engine PWB(EPWB) YC13-A7: 30 ppm model YC19-A7: 35/40 ppm models |
| 5 | Developer motor BK(DLPM-BK): Operation check | Engine PWB(EPWB) YC15-9/10/11/12: 30 ppm model YC22-9/10/11/12: 35/40 ppm models |
| 6 | Engine PWB(EPWB): Replace | |

(9) Electrical parts that could cause a paper jam at the transfer, the fuser and the eject parts

Timing of detection

| Jam code |
|--------------|
| J4201, J4211 |

Corrective Action

| Related parts | |
|-----------------------------|------------------|
| Eject sensor(ES) | Engine PWB(EPWB) |
| Developer motor BK(DLPM-BK) | |
| Eject motor(EM) | |

| Checking procedure at the occurrence J4201/J4211 | Corrective action at the occurrence | Point of checking connection of On/Off control signal output connector (terminal) |
|---|--|--|
| 1 | Items for Initial Checks | (see page P.7-12) |
| 2 | Eject sensor(ES): Conduct connectivity check, mounting location check, operation check | Engine PWB(EPWB) YC24-B18: 30 ppm model YC31-B18: 35/40 ppm models |
| 3 | Eject motor(EM): Operation check | Engine PWB(EPWB) YC24-B3/B4/B5/B6: 30 ppm model YC31-B3/B4/B5/B6: 35/40 ppm models |
| 4 | Developer motor BK(DLPM-BK): Operation check | Engine PWB(EPWB) YC15-9/10/11/12: 30 ppm model YC22-9/10/11/12: 35/40 ppm models |
| 5 | Engine PWB(EPWB): Replace | |

7-2 Self diagnostic

(1) Self diagnostic function

This machine is equipped with a self-diagnostic function. When a problem is detected, the machine stops operating and displays an error message on the operation panel. An error message consists of a message prompting a contact to service personnel and a four-digit error code indicating the type of error.

(2) Self diagnostic codes

If the part causing the problem was not supplied, use the unit including the part for replacement.

*: * Before attempting to check the fuser unit and the low voltage power supply PWB, be sure to turn the power switch off and unplug the machine from power. (Allow at least 5 s before starting to conduct service until the capacitors on the circuit boards have been completely discharged.)

*: Due to its construction, the 30ppm model the operation panel may turn on momentarily when connecting the power cord.

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|-------------------------|--|
| 0030 | FAX PWB system error The FAX process cannot be continued due to the malfunction of the FAX PWB. | FAX PWB | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and reinstall the FAX PWB, and then plug in the power cord and turn the power on. 2. Reinstall the FAX firmware. 3. Replace the FAX PWB. |
| 0070 | FAX PWB incompatible detection error In the initial communication with the FAX PWB, any normal communication command is not transmitted. | FAX PWB | <ol style="list-style-type: none"> 1. Install the FAX system designed for the model. 2. Reinstall the FAX firmware. |
| 0100 | Backup memory device error Outputs an abnormal status from the flash memory. | Flash memory (Main PWB) | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Check that the connectors on the main PWB are properly connected, and if not, re-connect them. 3. Replace the main PWB. (see page P.4-208,P.4-212) |
| 0120 | MAC address data error In case MAC address is invalid data | Flash memory (Main PWB) | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Check the MAC address on the network status page. 3. If it is blank, obtain an EEPROM with its MAC address written by the service support and install it. 4. Replace the main PWB. (see page P.4-208,P.4-212) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|--------------------------------|---|
| 0130 | <p>Backup memory Read/write error (main PWB)</p> <p>Read/write to the NAND memory cannot be executed.</p> | Flash memory (Main PWB) | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Check that the connectors on the main PWB are properly connected, and if not, re-connect them. 3. Replace the main PWB. (see page P.4-208,P.4-212) |
| 0140 | <p>Backup memory data error (Main PWB)</p> <p>At power up, the data that was read from the NAND memory has been determined to be a error.</p> | Flash memory (Main PWB) | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Execute U021 initialize memory. (see page P.6-25,P.6-221) 3. Replace the main PWB. (see page P.4-208,P.4-212) |
| 0150 | <p>EEPROM read/write error (Engine PWB)</p> <p>No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated 5 times successively.</p> <p>Mismatch of reading data from two locations occurs 8 times successively.</p> <p>Mismatch between writing data and reading data occurs 8 times successively.</p> | EEPROM (Engine PWB) | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Check that the EEPROM is properly installed on the engine PWB and if not, reinstall it. 3. Replace the engine PWB. (see page P.4-200,P.4-204) 4. Check the EEPROM and if it is damaged, contact the service support. |
| 0160 | <p>EEPROM data error (Engine PWB)</p> <p>Reading data from EEPROM is detected abnormal.</p> | EEPROM (Engine PWB) | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Execute U021 initialize memory. (see page P.6-25,P.6-221) 3. If the EEPROM data is corrupted, contact the service support. |
| 0170 | <p>Billing counting error</p> <p>Mismatch between the value of the main PWB and engine PWB, in one of the value of billing counter, life counter, or scanner counter.</p> | EEPROM (Main PWB) (Engine PWB) | <ol style="list-style-type: none"> 1. Check that the EEPROM installed in the main PWB is correct and, if not, install the correct EEPROM for the model. 2. Replace the main PWB. (see page P.4-208,P.4-212) 3. Replace the engine PWB. (see page P.4-200,P.4-204) 4. If the EEPROM data is corrupted, contact the service support. |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|----------------------|--|
| 0180 | <p>Machine number mismatch</p> <p>When the power is turned on, the machine number does not match the one stored in the main PWB and in the engine PWB.</p> | EEPROM (Main PWB) | <ol style="list-style-type: none"> 1. Check that the EEPROM installed in the main PWB is correct and, if not, install the correct EEPROM for the model. 2. Confirm the serial number data for the main PWB and the engine PWB by using U004. (see page P.6-21,P.6-216)If the mutually different machine number data between "Machine No. (Main)" and "Machine No. (Eng)" is displayed, or if there is a difference between the actual machine number and the number of "Machine No. (Eng)", install the correct EEPROM, and then execute U004. |
| 0360 | <p>Communication error between the engine ASIC</p> <p>During the readback data checked after data transmission, the checksum error or the video signal is not inverted. (failed 10 consecutive times)</p> | Engine PWB | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Check that the connectors on the engine PWB are properly connected, and if not, re-connect them. 3. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 0620 | <p>FAX image DIMM error</p> <p>FAX image DIMM not mounted</p> <p>FAX image DIMM access error</p> <p>(35/40 ppm model only)</p> | FAX image DIMM | <ol style="list-style-type: none"> 1. Install the FAX image DIMM bundled in the FAX kit in the main PWB. 2. Reinstall the FAX image DIMM in the main PWB socket. 3. Check the FAX image DIMM terminal and clean it if foreign objects adhere. 4. Replace with the new FAX image DIMM. |
| | | Main PWB | Replace the main PWB. (see page P.4-208,P.4-212) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|---|-------------------------------|---|
| 0640 | Hard disk error During the file access after Ready, the I/O error of SSD is detected. (SSD format error after rebooting. For example, System initialization, Sanitization, Encrypted format when installing security kit.) | HDD (35/40 ppm model only) | <ol style="list-style-type: none"> 1. Replace the HDD if abnormal sounds are heard. 2. Check if there is a loose connection, break or damage in the SATA cable between the HDD and Main PWB or it is connected to the right connector. HDD - Main PWB(YC1,YC27) 3. Change the SATA cable. 4. Execute the HDD initialization (FULL) in the U024. (see page P.6-222) 5. Replace the HDD if an error is detected after the U024 initialization. |
| | | SSD | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Unplug the power cord from the wall outlet, and reinstall the SSD. 3. Check the connection failure between the KUIO connector of the main PWB and SSD, and reconnect it. 4. Initialize the SSD. |
| | | Main PWB | Replace the main PWB. (see page P.4-208,P.4-212) |
| 0650 | FAX image DIMM check error When installing the FAX image DIMM used in another machine. (35/40 ppm model only) | FAX DIMM | <ol style="list-style-type: none"> 1. Check if a previously used FAX image DIMM is used instead of the FAX image DIMM bundled in the FAX kit. 2. If installing the DIMM used in another machine, execute U671 [RECOVERY FAX DIMM]. 3. Check if the FAX DIMM is firmly inserted into the socket on the Main PWB. 4. Replace with the new FAX image DIMM. |
| | | Main PWB | Replace the main PWB. (see page P.4-208,P.4-212) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|---|----------|---------------|--|
| 0660 Hard disk encryption key error (35/40 ppm model only) | | EEPROM | Execute U004 if it occurs after replacing the EEPROM. (see page P.6-21,P.6-216) |
| | | HDD | 1. Replace the HDD if abnormal sounds are heard. 2. Check if there is a loose connection, break or damage in the SATA cable between the HDD and Main PWB or it is connected to the right connector. HDD - Main PWB(YC1,YC27) 3. Change the SATA cable. 4. Execute the HDD initialization (FULL) in the U024. (see page P.6-222) 5. Replace the HDD if an error is detected after the U024 initialization. |
| | | Main PWB | Replace the main PWB. (see page P.4-208,P.4-212) |
| 0670 Hard disk overwriting Erasing error (35/40 ppm model only) | | HDD | 1. Replace the HDD if abnormal sounds are heard. 2. Check if there is a loose connection, break or damage in the SATA cable between the HDD and Main PWB or it is connected to the right connector. HDD - Main PWB(YC1,YC27) 3. Change the SATA cable. 4. Execute the HDD initialization (FULL) in the U024. (see page P.6-222) 5. Replace the HDD if an error is detected after the U024 initialization. |
| | | Main PWB | Replace the main PWB. (see page P.4-208,P.4-212) |
| 0680 SSD error In case of inability of communication with the SSD. (for 35 ppm model only) | | SSD | 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Unplug the power cord from the wall outlet, and reinstall the SSD. 3. Check the connection failure between the KUIO connector of the main PWB and SSD, and reconnect it. 4. Initialize the SSD. |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|---|---|
| 0800 | <p>Image formation problems</p> <p>The printing sequence JAM (J010X) is detected for 2 consecutive times.</p> | Main PWB | <ol style="list-style-type: none"> 1. Check if the problem is a printing operation error detection in a particular file, and if it is possible to obtain the reproduction of the phenomena by the identification of the job that detected the error, and take the job log. 2. If the problem occurs in an unspecified job, check the connectors on the main PWB, and reattach it. 3. Replace the main PWB. (see page P.4-208,P.4-212) |
| 0830 | <p>FAX PWB flash Program area Checksum error</p> <p>The program stored in the flash memory on the FAX PWB is broken and cannot be executed.</p> | <p>FAX firmware</p> <p>FAX PWB</p> | <p>Reinstall the FAX firmware.</p> <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and reinstall the FAX PWB, and then plug in the power cord and turn the power on. 2. Check the connection failure between the KUIO connector of the main PWB and FAX PWB, and reconnect it. 3. Execute [Initializing] by U600. (see page P.6-149,P.6-378) 4. Replace the FAX PWB. |
| 0840 | <p>Faults of RTC</p> <p>[Check at powerup]</p> <p>The RTC setting has reverted to a previous state. Or, the machine has not been turned on for 5 years (regularly compared with a set value stored in the EEPROM).</p> <p>The RTC setting is older than 00:01 on January 1, 2000.</p> <p>[Checked periodically (at every 5 minutes) after powerup.]</p> <p>The RTC setting has reverted to a state older than the last time it was checked.</p> <p>10 minutes have been passed since the previous check.</p> | <p>Settings of RTC</p> <p>Backup battery (Main PWB)</p> <p>Main PWB</p> | <p>Execute Date Setting using the system menu.</p> <ol style="list-style-type: none"> 1. Check if the backup battery on the main PWB is not short-circuited. 2. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. If the same service call error is displayed, replace the backup battery. <ol style="list-style-type: none"> 1. If the communication error (due to a noise, etc.) is present with the RTC on the main PWB, check that the PWB is properly grounded or secured by screws. 2. Replace the main PWB. (see page P.4-208,P.4-212) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|------------------------------|--|
| 0870 | FAX PWB - Main PWB image data transfer error High-capacity data transfer between the FAX PWB and the main PWB was not normally performed even if the data transfer was retried the specified times. | FAX PWB | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Reinstall the FAX PWB, and then plug in the power cord and turn the power on. 2. Check the connection failure between the KUIO connector of the main PWB and FAX PWB, and reconnect it. 3. Replace the FAX PWB. |
| | | Main PWB | Replace the main PWB. (see page P.4-208,P.4-212) |
| 0920 | Fax file system error The backup data is not retained for file system abnormality of the flash memory of the FAX PWB. | FAX PWB | <ol style="list-style-type: none"> 1. Execute [Initializing] by U600. (see page P.6-149,P.6-378) 2. Reinstall the FAX firmware. 3. Unplug the power cord from the wall outlet, and wait five seconds. Reinstall the FAX PWB, and then plug in the power cord and turn the power on. 4. Check the connection failure between the KUIO connector of the main PWB and FAX PWB, and reconnect it. 5. Replace the FAX PWB. |
| 0970 | 24V power down detect | Low voltage power supply PWB | <ol style="list-style-type: none"> 1. Check that the interlock switch (ILSW) is turned on properly by the front cover closing. 2. Check if there is a defective connection in the connector of the low voltage power supply PWB, and then check the 24V output from the YC13. 3. Replace the low voltage power supply PWB. (see page P.4-225,P.4-233) |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Check that the connectors on the main PWB are properly connected, and if not, re-connect them. 3. Replace the engine relay PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|--|---|
| 1010 | Lift motor error (main unit) | Bottom plate | Check if the bottom plate can move smoothly and repair or replace it if any problem is found. |
| | The following states have been detected 5 times in succession. After the cassette is installed, the upper limit detection sensor does not turn on within 12 s. | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. If a wire is pinched by another component, or has defective conduction, replace it. Lift motor - Engine PWB(YC21): 30 ppm model - Engine PWB(YC4): 35/40 ppm models Lift sensor - Engine PWB(YC12): 30 ppm model - Engine PWB(YC18): 35/40 ppm models |
| | During printing, after the upper limit detection sensor detects off, and 1 s after ascending control, and the upper limit detection sensor does not detect on. | Lift motor Drive transmission system | 1. Check if the gears rotate smoothly. If not, clean the bushes and gears. 2. Check for broken gears and replace if any are found. |
| | In case the lock signal High is detected 500ms in succession. | Lift motor | Replace the lift motor. (see page P.4-193) |
| | | Lift sensor(LS) (upper limit detection sensor) | 1. Check if the lift sensor can be turned ON/OFF to suit the rise of the cassette bottom plate. 2. Replace the lift sensor. |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|--|---|
| 1020 | <p>PF lift motor error (Paper feeder first cassette)</p> <p>The following states have been detected 5 times in succession.</p> <p>After the cassette is installed, the upper limit detection sensor does not turn on when passing the specified time.</p> <p>During printing, after the upper limit detection sensor detects off, and 1 s after ascending control, and the upper limit detection sensor does not detect on.</p> <p>In case the lift motor current detection AD value exceeds the threshold 500ms in succession while the lift motor is operated.</p> | Bottom plate | Check if the bottom plate can move smoothly and repair or replace it if any problem is found. |
| | | Defective connector cable or poor contact in the connector | <ol style="list-style-type: none"> 1. Reconnect the connector if its connection is loose. 2. If a wire is pinched by another component, or has defective conduction, replace it. PF lift motor - PF main PWB (YC6) PF lift sensor - PF main PWB (YC4) PF main PWB - Engine PWB(YC23): 30 ppm model - Engine PWB(YC20): 35/40 ppm models |
| | | Lift motor Drive transmission system | <ol style="list-style-type: none"> 1. Check if the gears rotate smoothly. If not, clean the bushes and gears. 2. Check for broken gears and replace if any are found. |
| | | PF lift motor | Replace the PF lift motor. (see page P.4-252) |
| | | PF lift sensor (upper limit detection sensor) | <ol style="list-style-type: none"> 1. Check if the PF lift sensor can be turned ON/OFF to suit the rise of the cassette bottom plate. 2. Replace the PF lift sensor. |
| | | PF main PWB | Replace the PF main PWB. (see page P.4-254) |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|--|---|
| 1030 | <p>PF lift motor error (Paper feeder second cassette)</p> <p>The following states have been detected 5 times in succession.</p> <p>After the cassette is installed, the upper limit detection sensor does not turn on when passing the specified time.</p> <p>During printing, after the upper limit detection sensor detects off, and 1 s after ascending control, and the upper limit detection sensor does not detect on.</p> <p>In case the lift motor current detection AD value exceeds the threshold 500ms in succession while the lift motor is operated.</p> | Bottom plate | Check if the bottom plate can move smoothly and repair or replace it if any problem is found. |
| | | Defective connector cable or poor contact in the connector | <ol style="list-style-type: none"> 1. Reconnect the connector if its connection is loose. 2. If a wire is pinched by another component, or has defective conduction, replace it. PF lift motor - PF main PWB (YC6) PF lift sensor - PF main PWB (YC4) PF main PWB - Engine PWB(YC23): 30 ppm model - Engine PWB(YC20): 35/40 ppm models |
| | | Lift motor Drive transmission system | <ol style="list-style-type: none"> 1. Check if the gears rotate smoothly. If not, clean the bushes and gears. 2. Check for broken gears and replace if any are found. |
| | | PF lift motor | Replace the PF lift motor. (see page P.4-256,P.4-260) |
| | | PF lift sensor (upper limit detection sensor) | <ol style="list-style-type: none"> 1. Check if the PF lift sensor can be turned ON/OFF to suit the rise of the cassette bottom plate. 2. Replace the PF lift sensor. |
| | | PF main PWB | Replace the PF main PWB. (see page P.4-258, P.4-261) |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|---|---|---|--|
| 1040 PF lift motor error (Paper feeder third cassette) The following states have been detected 5 times in succession. After the cassette is installed, the upper limit detection sensor does not turn on when passing the specified time. During printing, after the upper limit detection sensor detects off, and 1 s after ascending control, and the upper limit detection sensor does not detect on. In case the lift motor current detection AD value exceeds the threshold 500ms in succession while the lift motor is operated. | Bottom plate | Check if the bottom plate can move smoothly and repair or replace it if any problem is found. | |
| | Defective connector cable or poor contact in the connector | | 1. Reconnect the connector if its connection is loose. 2. If a wire is pinched by another component, or has defective conduction, replace it. PF lift motor - PF main PWB (YC6) PF lift sensor - PF main PWB (YC4) PF main PWB - Engine PWB(YC20): 30 ppm model - Engine PWB(YC23): 35/40 ppm models |
| | Lift motor Drive transmission system | | 1. Check if the gears rotate smoothly. If not, clean the bushes and gears. 2. Check for broken gears and replace if any are found. |
| | PF lift motor | | Replace the PF lift motor. (see page P.4-256,P.4-260) |
| | PF lift sensor (upper limit detection sensor) | | 1. Check if the PF lift sensor can be turned ON/OFF to suit the rise of the cassette bottom plate. 2. Replace the PF lift sensor. |
| | PF main PWB | | Replace the PF main PWB. (see page P.4-258,P.4-261) |
| | Engine PWB | | Replace the engine PWB. (see page P.4-200,P.4-204) |
| 1800 Paper feeder 1 Communication error (first cassette) A communication error from the paper feeder is detected 10 times in succession. | Paper feeder | Check the wiring connection status with the main unit, and if necessary, reconnect it. | |
| | PF main PWB | | 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. PF main PWB - Engine PWB(YC23): 30 ppm model - Engine PWB(YC20): 35/40 ppm models 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Reinstall the PF firmware. 4. Replace the PF main PWB. (see page P.4-254) |
| | Engine PWB | | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|--|----------------------|--|
| 1810 | Paper feeder 2 Communication error (second cassette) A communication error from the paper feeder is detected 10 times in succession. | Paper feeder | Check the wiring connection status with the main unit, and if necessary, reconnect it. |
| | | PF main PWB | 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. PF main PWB - Engine PWB(YC23): 30 ppm model - Engine PWB(YC20): 35/40 ppm models 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Reinstall the PF firmware. 4. Replace the PF main PWB. (see page P.4-258,P.4-261) |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 1900 | Paper feeder 1 EEPROM error (first cassette) When writing the data, read and write data does not match 3 times in succession. | PF main PWB (EEPROM) | 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Confirm that the wiring connector to the main unit is firmly connected, and if necessary, connect the connector all the way in. 3. Replace the PF main PWB. (see page P.4-254) |
| 1910 | Paper feeder 2 EEPROM error (second cassette) When writing the data, read and write data does not match 3 times in succession. | PF main PWB (EEPROM) | 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Confirm that the wiring connector with the PF1 is firmly connected, and if necessary, connect the connector all the way in. 3. Replace the PF main PWB. (see page P.4-258,P.4-261) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|--|-----------------|--|
| 2101 | Developer motor steady-state error (BK) After the motor is stabilized, the stable signal is turned OFF for continuous 2 s. | Developer unit | 1. Check that the developer roller can be rotated by hand, and if it is locked, replace the developer unit. |
| | | Developer motor | 1. Check if the couplings and gears rotate smoothly, and if necessary replace them. 2. Reconnect the connector if its connection is loose. 3. Check the continuity within the connector wire. If none, replace the wire. Developer motor - Engine PWB(YC15): 30 ppm model - Engine PWB(YC22): 35/40 ppm models 4. Replace the developer motor. (see page P.4-102,P.4-114) |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 2102 | Developer motor steady-state error (M/C/Y) After the motor is stabilized, the ready signal is turned OFF for continuous 1 s. | Developer unit | 1. Check that the developer roller can be rotated by hand, and if it is locked, replace the developer unit. |
| | | Developer motor | 1. Check if the couplings and gears rotate smoothly, and if necessary replace them. 2. Reconnect the connector if its connection is loose. 3. Check the continuity within the connector wire. If none, replace the wire. Developer motor - Engine PWB(YC16): 30 ppm model - Engine PWB(YC23): 35/40 ppm models 4. Replace the developer motor. (see page P.4-126,P.4-139) |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|--|--|
| 2112 | Developer motor startup error (M/C/Y) After the motor starts up, the ready signal is not turned ON for continuous 2 s. | Developer unit | 1. Check that the developer roller can be rotated by hand, and if it is locked, replace the developer unit. |
| | | Developer motor | 1. Check if the couplings and gears rotate smoothly, and if necessary replace them. 2. Reconnect the connector if its connection is loose. 3. Check the continuity within the connector wire. If none, replace the wire. Developer motor - Engine PWB(YC16): 30 ppm model - Engine PWB(YC23): 35/40 ppm models 4. Replace the developer motor. (see page P.4-126,P.4-139) |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 2201 | Drum motor BK steady-state error After the motor is stabilized, the ready signal is turned OFF for continuous 1 s. | Drum unit BK | Check that the drum can be rotated by hand, and if it is locked, replace the drum unit BK. |
| | | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. Check the continuity within the connector wire. If none, replace the wire. Drum motor BK - Engine PWB(YC16): 30 ppm model - Engine PWB(YC23): 35/40 ppm models |
| | | Drive transmission system for the drum motor BK | 1. Check if the couplings and gears rotate smoothly, and if not, clean or grease the gears. 2. Check for broken couplings and gears, and replace if any are found. |
| | | Drum motor BK | Replace the drum motor BK. (see page P.4-126,P.4-139) |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|---|--|---|
| 2202 | Drum motor M/C/Y steady-state error After the motor is stabilized, the ready signal is turned OFF for continuous 1 s. | Drum unit M/C/Y | Check that the drum can be rotated by hand, and if it is locked, replace the drum unit M/C/Y. |
| | | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. Check the continuity within the connector wire. If none, replace the wire. Drum motor M/C/Y - Engine PWB(YC16): 30 ppm model - Engine PWB(YC23): 35/40 ppm models |
| | | Drive transmission system for the drum motor M/C/Y | 1. Check if the couplings and gears rotate smoothly, and if not, clean or grease the gears. 2. Check for broken couplings and gears, and replace if any are found. |
| | | Drum motor M/C/Y | Replace the drum motor M/C/Y. (see page P.4-126,P.4-139) |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |
| 2211 | Drum motor BK startup error After the motor starting, the stable signal is not turned ON within 2 s. | Drum unit BK | Check that the drum can be rotated by hand, and if it is locked, replace the drum unit BK. |
| | | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. Check the continuity within the connector wire. If none, replace the wire. Drum motor BK - Engine PWB(YC16): 30 ppm model - Engine PWB(YC23): 35/40 ppm models |
| | | Drum Drive transmission system for the drum motor BK | 1. Check if the couplings and gears rotate smoothly, and if not, clean or grease the gears. 2. Check for broken couplings and gears, and replace if any are found. |
| | | Drum motor BK | Replace the drum motor BK. (see page P.4-126,P.4-139) |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|--|--|--|
| 2212 | Drum motor M/C/Y startup error After the motor starting, the stable signal is not turned ON within 2 s. | Drum unit M/C/Y | Check that the drum can be rotated by hand, and if it is locked, replace the drum unit M/C/Y. |
| | | Defective connector cable or poor contact in the connector | <ol style="list-style-type: none"> 1. Reconnect the connector if its connection is loose. 2. Check the continuity within the connector wire. If none, replace the wire. Drum motor M/C/Y - Engine PWB(YC16): 30 ppm model - Engine PWB(YC23): 35/40 ppm models |
| | | Drive transmission system for the drum motor M/C/Y | <ol style="list-style-type: none"> 1. Check if the couplings and gears rotate smoothly, and if not, clean or grease the gears. 2. Check for broken couplings and gears, and replace if any are found. |
| | | Drum motor M/C/Y | Replace the drum motor M/C/Y. (see page P.4-126,P.4-139) |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |
| 2500 | Paper feed motor error In case the Ready signal does not turn ON 2s in succession after the motor starts up. In case the Ready signal does not turn ON 1s in succession after the motor is in the steady-state. | Defective connector cable or poor contact in the connector | <ol style="list-style-type: none"> 1. Reconnect the connector if its connection is loose. 2. Check the continuity within the connector wire. If none, replace the wire. Paper feed motor - Engine PWB(YC15): 30 ppm model - Engine PWB(YC22): 35/40 ppm models |
| | | Drive transmission system for the paper feed motor | <ol style="list-style-type: none"> 1. Check if the rollers and gears rotate smoothly. If not, clean or grease the bushes and gears. 2. Check for broken gears and replace if any are found. |
| | | Paper feed motor | Replace the paper feed motor. (see page P.4-102,P.4-114) |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|---|--|--|
| 2600 | Paper feeder 1 Drive motor error During the motor drive, the ready signal is not turned H for continuous 2 s. | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. Check the continuity within the connector wire. If none, replace the wire. PF drive motor - PF main PWB(YC8) |
| | | Drive transmission system for the PF drive motor | 1. Check if the rollers and gears rotate smoothly. If not, clean or grease the bushes and gears. 2. Check for broken gears and replace if any are found. |
| | | PF drive motor | Replace the PF drive motor. (see page P.4-251) |
| | | PF main PWB | Replace the PF main PWB. (see page P.4-254) |
| 2610 | Paper feeder 2 Drive motor error During the motor drive, the ready signal is not turned H for continuous 2 s. | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. Check the continuity within the connector wire. If none, replace the wire. PF drive motor - PF main PWB(YC8) |
| | | Drive transmission system for the PF drive motor | 1. Check if the rollers and gears rotate smoothly. If not, clean or grease the bushes and gears. 2. Check for broken gears and replace if any are found. |
| | | PF drive motor | Replace the PF drive motor. (see page P.4-255,P.4-259) |
| | | PF main PWB | Replace the PF main PWB. (see page P.4-258, P.4-261) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|---|--|---|
| 2700 | 3-color release error In case the position signal does not change when passing 5s after the transfer belt release was switched. | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. Check the continuity within the connector wire. If none, replace the wire. Transfer release motor - Engine PWB(YC10): 30 ppm model - Engine PWB(YC17): 35/40 ppm models |
| | | Drive transmission system for the transfer release motor | 1. Check if the rollers and gears rotate smoothly. If not, clean or grease the bushes and gears. 2. Check for broken gears and replace if any are found. |
| | | Transfer release motor | Replace the transfer release motor. |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |
| 2760 | Transfer motor startup error After the motor starting, the stable signal is not turned ON within 2 s. | Primary transfer unit | 1. Check that the belt can be rotated by hand, and if it is locked, remove the cause. 2. Replace the primary transfer unit. (see page P.4-32) |
| | | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. Check the continuity within the connector wire. If none, replace the wire. Transfer motor - Engine PWB(YC15): 30 ppm model - Engine PWB(YC22): 35/40 ppm models |
| | | Drive transmission system for the transfer motor | 1. Check if the rollers and gears rotate smoothly. If not, clean or grease the bushes and gears. 2. Check for broken gears and replace if any are found. |
| | | Transfer motor | Replace the transfer motor. |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|--|---|
| 2820 | Transfer motor steady-state error After the motor is stabilized, the ready signal is turned OFF for continuous 1 s. | Primary transfer unit | 1. Check that the belt can be rotated by hand, and if it is locked, check for foreign objects such as jammed paper, and if jammed, remove it. 2. Replace the primary transfer unit. (see page P.4-32) |
| | | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. Check the continuity within the connector wire. If none, replace the wire. Transfer motor - Engine PWB(YC15): 30 ppm model - Engine PWB(YC22): 35/40 ppm models |
| | | Drive transmission system for the transfer motor | 1. Check if the rollers and gears rotate smoothly. If not, clean or grease the bushes and gears. 2. Check for broken gears and replace if any are found. |
| | | Transfer motor | Replace the transfer motor. |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|--|----------------------|--|
| 3100 | Carriage error When turning the power on, or when the reading of the original document by table or DP scanning has completed, the home position sensor is not turned off, even if the home position sensor is on and the scanner carriage moves to the scanning direction. Or, the home position sensor does not turn on, even if the home position sensor is off and the scanner carriage moves to the return direction. | Scanner motor | <ol style="list-style-type: none"> 1. Move the scanner by hand to check whether it smoothly moves. 2. Check that the scanner drive belt is not disengaged. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Scanner motor - Engine PWB(YC19): 30 ppm model - Engine PWB(YC27): 35/40 ppm models 4. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 5. Replace the scanner motor. |
| | | Home position sensor | <ol style="list-style-type: none"> 1. Check that the sensor is correctly positioned. 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Home position sensor - CCD PWB (YC3) CCD PWB - Main PWB(YC2014): 30 ppm model - Engine PWB(YC5): 35/40 ppm models 3. Replace the home position sensor. |
| | | CCD PWB | <ol style="list-style-type: none"> 1. Replace scanner carriage. (see page P.4-96) 2. Execute the U411 Adjusting the scanner automatically. (see page P.6-117,P.6-341) |
| | | Main PWB | Replace the main PWB. (see page P.4-208) |
| | | Engine PWB | Replace the engine PWB. (see page P.4-204) |
| 3200 | Lamp error The white standard data obtained when the lamp is turned on at the time of an initialization is lower than the rated value. | LED PWB | Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. LED PWB - CCD PWB (YC2) CCD PWB - Main PWB(YC2014): 30 ppm model - Engine PWB(YC5): 35/40 ppm models |
| | | Mirror | Replace the image scanner carriage and execute U411 if the mirror is dropped off by drop shock. (see page P.6-117,P.6-341) |
| | | CCD PWB | Replace the image scanner carriage and execute U411. (see page P.6-117,P.6-341) |
| | | Main PWB | Replace the main PWB. (see page P.4-208) |
| | | Engine PWB | Replace the engine PWB. (see page P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|--|---------------|---|
| 3210 | CIS lamp error The white standard data obtained when the lamp is turned on at the time of an initialization is lower than the rated value. (35/40 ppm model only) | CIS | <ol style="list-style-type: none"> 1. Execute the U906 resetting the partial operation. (see page P.6-415) 2. Execute [CIS] in the U061 lamp lighting check. (see page P.6-236) 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. CIS - DPSHD PWB (YC2,5) DPSHD PWB (YC1) - Engine PWB (YC7) 4. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 5. Replace CIS and execute U091 and U411. (see page P.6-251,P.6-341) |
| | | DPSHD PWB | Replace the SPSHD PWB. (see page P.4-270) |
| 3300 | CCD AGC error In case a normal input could not be obtained from the CCD at AGC. | LED lamp PWB | <ol style="list-style-type: none"> 1. Execute [CCD] in the U061 lamp lighting check. (see page P.6-236) 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. LED PWB - CCD PWB (YC2) CCD PWB (YC1) - Engine PWB (YC5) 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 4. Replace the image scanner carriage and execute U411. (see page P.6-341) |
| | | CCD PWB | Replace the image scanner carriage and execute U411. (see page P.4-96,P.6-341) |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|------------------------|--|
| 3310 | CIS AGC error In case a normal input could not be obtained from the CIS at AGC. (35/40 ppm model only) | CIS | <ol style="list-style-type: none"> Execute the U906 resetting the partial operation. (see page P.6-415) Execute [CIS] in the U061 lamp lighting check. (see page P.6-236) Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DPCIS - DPSHD PWB (YC2) DPSHD PWB (YC3) - DPIF PWB (YC2) If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. Replace DPCIS and execute U091 and U411. (see page P.6-251,P.6-341) |
| | | DPSHD PWB | Replace the DPSHD PWB. (see page P.4-270) |
| 3500 | Scanner and ASIC communication error A communication error is detected. (Read back values are different.) | CCD PWB | <ol style="list-style-type: none"> Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. CCD PWB - Main PWB(YC2014): 30 ppm model - Engine PWB(YC5): 35/40 ppm models If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. If the LED is not lit, replace the scanner carriage and execute U411. (see page P.6-117,P.6-341) |
| | | Main PWB Engine PWB | <ol style="list-style-type: none"> Check the engine firmware and upgrade to the latest version if necessary. Replace the main PWB. (see page P.4-208) Replace the engine PWB. (see page P.4-204) |
| 3800 | AFE error When writing the data, read and write data does not match 3 times in succession. In case no response is received from AFE for 100ms. (35/40 ppm model only) | Engine PWB | <ol style="list-style-type: none"> Check if the FFC connector is deformed and insert the FFC all the way. CCD PWB (YC1) - Engine PWB (YC5) If the FFC is disconnected, replace it. Replace the engine PWB and execute U411. (see page P.4-204) |
| | | CCD PWB | Replace the ISU and execute U411. (see page P.6-341) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|--------------------------|--|
| 4001 | Polygon motor startup error After the polygon motor starts, the motor stable signal is not turned ON after 30 s. | Polygon motor | 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Polygon motor - Engine PWB(YC5): 30 ppm model - Engine PWB(YC10): 35/40 ppm models 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Replace the LSU. (see page P.4-76) |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 4011 | Polygon motor steady-state error After the polygon motor stabilization, the motor stable signal is turned OFF for consecutive 15 s or more. | Polygon motor | 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Polygon motor - Engine PWB 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Replace the LSU. (see page P.4-76) |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 4011 | BD initialization error(K) In case the BD signal is not detected for 1s after starting the polygon motor drive. | Laser scanner unit (LSU) | 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. LSU - Main PWB(YC2016): 30 ppm model - Engine PWB(YC8): 35/40 ppm models 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Replace the LSU. (see page P.4-76) |
| | | Main PWB Engine PWB | 1. Check the controller firmware and engine firmware, and upgrade to the latest version. 2. Replace the main PWB. (see page P.4-208,P.4-212) 3. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|--------------------------|---|
| 4102 | BD initialization error(C) In case the BD signal is not detected for 1s after starting the polygon motor drive. | Laser scanner unit (LSU) | 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. LSU - Main PWB(YC2016): 30 ppm model - Engine PWB(YC8): 35/40 ppm models 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Replace the LSU. (see page P.4-76) |
| | | Main PWB Engine PWB | 1. Check the controller firmware and engine firmware, and upgrade to the latest version. 2. Replace the main PWB. (see page P.4-208,P.4-212) 3. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 4103 | BD initialization error(M) In case the BD signal is not detected for 1s after starting the polygon motor drive. | Laser scanner unit (LSU) | 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. LSU - Main PWB(YC2016): 30 ppm model - Engine PWB(YC8): 35/40 ppm models 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Replace the LSU. (see page P.4-76) |
| | | Main PWB Engine PWB | 1. Check the controller firmware and engine firmware, and upgrade to the latest version. 2. Replace the main PWB. (see page P.4-208) 3. Replace the engine PWB. (see page P.4-204) |
| 4104 | BD initialization error(Y) In case the BD signal is not detected for 1s after starting the polygon motor drive. | Laser scanner unit (LSU) | 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. LSU - Main PWB(YC2016): 30 ppm model - Engine PWB(YC8): 35/40 ppm models 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Replace the LSU. (see page P.4-76) |
| | | Main PWB Engine PWB | 1. Check the controller firmware and engine firmware, and upgrade to the latest version. 2. Replace the main PWB. (see page P.4-208,P.4-212) 3. Replace the engine PWB. (see page P.4-200,P.4-204) |



| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|--------------------------|---|
| 4201 | BD steady-state error (K) During the polygon motor steady rotation, the BD signal is not detected. | Laser scanner unit (LSU) | 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. LSU - Main PWB(YC2016): 30 ppm model - Engine PWB(YC8): 35/40 ppm models 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Replace the LSU. (see page P.4-76) |
| | | Main PWB Engine PWB | 1. Check the controller firmware and engine firmware, and upgrade to the latest version. 2. Replace the main PWB. (see page P.4-208,P.4-212) 3. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 4600 | Cleaning motor Error In case the cleaning motor CW drive time is 2100ms or less. In case the CW or CCW operation continues 6.4s or more in succession. | Cleaning wire | 1. Execute [LSU cleaning] using [Adjustment/Maintenance] of the system menu. 2. Check that the drive gear and cleaning spiral can rotate and they are not unusually loaded, and if necessary, clean and grease. |
| | | Cleaning motor | 1. Confirm that the cleaning motor has been firmly attached. 2. Replace the LSU. (see page P.4-76) |
| | | Engine PWB | 1. Reconnect the connector if its connection is loose. 2. If a wire is pinched by another component, or has defective conduction, replace it. Cleaning motor - Engine PWB(YC5): 30 ppm model - Engine PWB(YC10): 35/40 ppm models 3. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 4700 | VIDEO_ASIC device error Communication with the video ASIC has failed 5 times successively. After writing to the VIDEO ASIC, the error that the reading value from the same address does not match occurs 8 times successively. | Main PWB | 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Check that the connectors on the main PWB are properly connected, and if not, re-connect them. 3. Replace the main PWB. (see page P.4-208,P.4-212) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|---|----------|--|--|
| 5101 Main charger error (Black) In case the incoming current is too low to detect Black when adjusting the Vpp of the main charge. (40 ppm model only) | | Charger roller unit (Black) | 1. Check if the main charger roller can be rotated manually and reattach it to the drum unit. 2. Check if the main charger roller side contact and main unit side contact are dirty or deformed. Clean or correct it. |
| | | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. Check the continuity within the connector wire. If none, replace the wire. High voltage PWB - Engine PWB(YC8): 30 ppm model - Engine PWB(YC12): 35 ppm model - Engine PWB(YC13): 40 ppm model |
| | | High voltage PWB | 1. Check if the main charger roller contact on the high voltage PWB is deformed or dirty. 2. Replace the high voltage PWB. (see page P.4-217,P.4-221) |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |
| 5102 Main charger error (Cyan) In case the incoming current is too low to detect Cyan when adjusting the Vpp of the main charge. (40 ppm model only) | | Charger roller unit (Cyan) | 1. Check if the main charger roller can be rotated manually and reattach it to the drum unit. 2. Check if the main charger roller side contact and main unit side contact are dirty or deformed. Clean or correct it. |
| | | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. Check the continuity within the connector wire. If none, replace the wire. High voltage PWB - Engine PWB(YC8): 30 ppm model - Engine PWB(YC12): 35 ppm model - Engine PWB(YC13): 40 ppm model |
| | | High voltage PWB | 1. Check if the main charger roller contact on the high voltage PWB is deformed or dirty. 2. Replace the high voltage PWB. (see page P.4-217,P.4-221) |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|---|----------|--|--|
| 5103 Main charger error (Magenta) In case the incoming current is too low to detect Magenta when adjusting the Vpp of the main charge. (40 ppm model only) | | Charger roller unit (Magenta) | 1. Check if the main charger roller can be rotated manually and reattach it to the drum unit. 2. Check if the main charger roller side contact and main unit side contact are dirty or deformed. Clean or correct it. |
| | | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. Check the continuity within the connector wire. If none, replace the wire. High voltage PWB - Engine PWB(YC8): 30 ppm model - Engine PWB(YC12): 35 ppm model - Engine PWB(YC13): 40 ppm model |
| | | High voltage PWB | 1. Check if the main charger roller contact on the high voltage PWB is deformed or dirty. 2. Replace the high voltage PWB. (see page P.4-217,P.4-221) |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |
| 5104 Main charger error (Yellow) In case the incoming current is too low to detect Yellow when adjusting the Vpp of the main charge. (40 ppm model only) | | Charger roller unit (Yellow) | 1. Check if the main charger roller can be rotated manually and reattach it to the drum unit. 2. Check if the main charger roller side contact and main unit side contact are dirty or deformed. Clean or correct it. |
| | | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. Check the continuity within the connector wire. If none, replace the wire. High voltage PWB - Engine PWB(YC8): 30 ppm model - Engine PWB(YC12): 35 ppm model - Engine PWB(YC13): 40 ppm model |
| | | High voltage PWB | 1. Check if the main charger roller contact on the high voltage PWB is deformed or dirty. 2. Replace the high voltage PWB. (see page P.4-217,P.4-221) |
| | | Engine PWB | Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|---|------------------------------|--|
| 6000 | Broken fuser heater wire (main) During warm up, the temperature detected by the center thermistor does not reach 100 °C/212.0 °F for 20 s. During warm up, the temperature detected by the center thermistor does not reach the stable display temperature for 30 s, after it reaches 100 °C/212.0 °F. | Fuser unit | <ol style="list-style-type: none"> 1. Make sure there is no paper jam. 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Fuser unit - Engine PWB(YC7): 30 ppm model - Engine PWB(YC11): 35/40 ppm models 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 4. If the fuser heater is not turned on (broken thermostat wire), replace the fuser unit. (see page P.4-42) |
| | | Low voltage power supply PWB | <ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Low voltage power supply PWB - Engine PWB(YC34): 30 ppm model - Engine PWB(YC6): 35/40 ppm models 2. Replace the low voltage power supply PWB. (see page P.4-225,P.4-233) |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 6020 | Fuser thermistor 1 High temperature error The temperature detected by the thermistor 1 (center) exceeded 240 °C/464.0 °F for 1s in succession. | Fuser unit | <ol style="list-style-type: none"> 1. Make sure there is no paper jam. 2. Check if the fuser roller has foreign objects such as the toner contamination. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Fuser unit - Engine PWB(YC7): 30 ppm model - Engine PWB(YC11): 35/40 ppm models 4. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 5. Replace the fuser unit.(see page P.4-42) |
| | | Low voltage power supply PWB | <ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Low voltage power supply PWB - Engine PWB(YC34): 30 ppm model - Engine PWB(YC6): 35/40 ppm models 2. If the fuser heater is turned on at all times, replace the low voltage power supply PWB. (see page P.4-225,P.4-233) |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Check if the engine PWB is properly secured with screws. 3. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|-------------------------------|--|
| 6030 | <p>Fuser thermistor 1 wire break</p> <p>In case the fuser thermistor 1 (center) detects low temperature for 1.6s while the fuser thermistor 2 (edge) detects the temperature of 30 °C/86 °F or more.</p> | Fuser unit | <ol style="list-style-type: none"> 1. Make sure there is no paper jam. 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Fuser unit - Engine PWB(YC7): 30 ppm model - Engine PWB(YC11): 35/40 ppm models 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 4. Replace the fuser unit. (see page P.4-42) |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 6040 | <p>Fuser heater error</p> <p>In case the input from the fuser thermistor 1 (center) is abnormal for 1s in succession.</p> <p>The fuser unit detection port is at H level for 1s in succession in all the operation mode.</p> | Fuser unit | <ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Fuser unit - Engine PWB(YC7): 30 ppm model - Engine PWB(YC11): 35/40 ppm models 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Replace the fuser unit. (see page P.4-42) |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| | | Fuser thermistor 1 | Replace the fuser unit. (see page P.4-42) |
| | | Fuser thermostat (wire break) | <ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Fuser unit - Low voltage power supply PWB(YC102): 30 ppm model - Low voltage power supply PWB(YC2) : 35/40 ppm models 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Replace the fuser unit. (see page P.4-42) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|--|--|--|---|
| <p>6000 6020 6030 6220 6230 Common</p> | <p>Broken fuser heater wire Abnormally high fuser center thermistor temperature Broken fuser center thermistor wire Abnormally high fuser edge thermistor temperature Broken fuser edge thermistor wire</p> | <p>Connector pin</p> | <p>If the interface connector pins of the fuser unit and the main unit are deformed owing to foreign objects, replace the connectors or the units including the connectors.</p> |
| | | <p>Triac TRA31/ TR302: for main heater control TRA301: for sub heater control (35/40 ppm model only)</p> | <p>Disconnect the power cord and check if the conduction (A1 - A2) of the triac TRA31/TR302 and TR301 (35/40ppm models only) shows the mega ohm level resistance and there is no short-circuit. If there is a short-circuit, replace the low voltage power supply PWB. (see page P.4-225,P.4-233)</p> |
| <p>Low voltage power supply PWB (30 ppm model)</p> | | |  |
| <p>Figure 7-3</p> | | | <p>Low voltage power supply PWB (35/40 ppm models)</p> |
|  | | | <p>Figure 7-4</p> |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|---|---------------------------------------|---|
| 6050 | <p>Fuser thermistor 1 Low temperature error</p> <p>In case the temperature detected by the thermistor 1 (center) continues 100 °C/212.0 °F or less for 1 second during ready.</p> <p>In case the temperature detected by the thermistor 1 (center) continues 70 °C/158.0 °F or less for 1 second during low power mode.</p> | Reduction of the power supply voltage | <ol style="list-style-type: none"> 1. Check that no voltage drop of more than 10% of the rated is caused during printing. 2. If the power is overloaded, change the AC outlet that supplies power. |
| | | Fuser unit | <ol style="list-style-type: none"> 1. Make sure there is no paper jam. 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Fuser unit - Engine PWB(YC7): 30 ppm model - Engine PWB(YC11): 35/40 ppm models 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 4. If the fuser heater is not turned on (broken thermostat wire), replace the fuser unit. (see page P.4-42) |
| | | Low voltage power supply PWB | <ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Low voltage power supply PWB - Engine PWB(YC105): 30 ppm model - Engine PWB(YC40): 35/40 ppm models 2. Replace the low voltage power supply PWB. (see page P.4-225,P.4-233) |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|------------------------------|---|
| 6200 | <p>Fuser heater error (sub)</p> <p>In case the temperature detected by the fuser thermistor (edge) does not reach 100 °C/212.0 °F when turning on the sub heater for 30s in succession during warm-up.</p> <p>In case the temperature detected by the fuser thermistor (center) does not reach the Ready temperature when turning on the main heater for 30s in succession after the temperature detected by the fuser thermistor (edge) reaches 100 °C/212.0 °F during warm-up.</p> | Fuser unit | <ol style="list-style-type: none"> 1. Make sure there is no paper jam. 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Fuser unit - Engine PWB(YC7): 30 ppm model - Engine PWB(YC11): 35/40 ppm models 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 4. If the fuser sub heater is not turned on (broken thermostat wire), replace the fuser unit. (see page P.4-42) |
| | | Low voltage power supply PWB | <ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Low voltage power supply PWB - Engine PWB(YC105): 30 ppm model - Engine PWB(YC40): 35/40 ppm models 2. Replace the low voltage power supply PWB. (see page P.4-225,P.4-233) |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|---|------------------------------|--|
| 6220 | Fuser heater high temperature error (sub) The temperature detected by the fuser thermistor 2 (edge) exceeded 240 °C/ 464.0 °F for 1s in succession. | Fuser unit | <ol style="list-style-type: none"> 1. Make sure there is no paper jam. 2. Check if the fuser roller has foreign objects such as the toner contamination. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Fuser unit - Engine PWB(YC7): 30 ppm model - Engine PWB(YC11): 35/40 ppm models 4. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 5. Replace the fuser unit. (see page P.4-42) |
| | | Low voltage power supply PWB | <ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Low voltage power supply PWB - Engine PWB(YC105): 30 ppm model - Engine PWB(YC40): 35/40 ppm models 2. If the fuser heater is turned on at all times, replace the low voltage power supply PWB. (see page P.4-225,P.4-233) |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Check if the engine PWB is properly secured with screws. 3. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 6230 | Fuser thermistor 2 wire break Fuser thermistor 2 (edge) detects low temperature for 1.6 s. | Fuser unit | <ol style="list-style-type: none"> 1. Make sure there is no paper jam. 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Fuser unit - Engine PWB(YC7): 30 ppm model - Engine PWB(YC11): 35/40 ppm models 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 4. Replace the fuser unit. (see page P.4-42) |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|--|---------------------------------------|---|
| 6250 | Fuser thermistor 2 Low temperature error In case the temperature detected by the fuser thermistor 2 (edge) continues 100 °C/212.0 °F or less for 1 second during ready and printing. In case the temperature detected by the fuser thermistor 2 (edge) continues 60 °C/140.0 °F or less for 1 second during low power mode. | Reduction of the power supply voltage | <ol style="list-style-type: none"> 1. Check that no voltage drop of more than 10% of the rated is caused during printing. 2. If the power is overloaded, change the AC outlet that supplies power. |
| | | Fuser unit | <ol style="list-style-type: none"> 1. Make sure there is no paper jam. 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Fuser unit - Engine PWB(YC7): 30 ppm model - Engine PWB(YC11): 35/40 ppm models 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 4. If the fuser heater is not turned on (broken thermostat wire), replace the fuser unit. (see page P.4-42) |
| | | Low voltage power supply PWB | <ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Low voltage power supply PWB - Engine PWB(YC105): 30 ppm model - Engine PWB(YC40): 35/40 ppm models 2. Replace the low voltage power supply PWB. (see page P.4-225,P.4-233) |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 6400 | Zero-cross signal error During the fuser heater on, the zero-cross signal is not input for 1 s successively. | Low voltage power supply PWB | <ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Low voltage power supply PWB - Engine PWB(YC105): 30 ppm model - Engine PWB(YC40): 35/40 ppm models 2. Replace the low voltage power supply PWB. (see page P.4-225,P.4-233) |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|--|---------------|--|
| 6610 | The fuser pressure release error The fuser release sensor does not turn on or off, after 10 s from starting pressurization or depressurization operation. | Fuser unit | <ol style="list-style-type: none"> 1. Make sure there is no paper jam. 2. Check if the fuser pressure can be reduced by inverse rotation of the fuser gear by hand. 3. Check if the envelope sensor light is blocked out by the actuator during depressurization operation. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Fuser pressure release sensor <ul style="list-style-type: none"> - Engine PWB(YC7): 30 ppm model - Engine PWB(YC11): 35/40 ppm models 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the fuser unit. (see page P.4-42) |
| | | Fuser motor | <ol style="list-style-type: none"> 1. Check if the fuser motor is rotating. 2. When turning the power on, check if the fuser motor rotates reversely. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Fuser motor <ul style="list-style-type: none"> - Engine PWB (YC17): 30 ppm model - Engine PWB(YC24): 35/40 ppm models 4. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 5. Replace the fuser motor. |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 6910 | Engine firmware unexpected error The drum motor drive continued more than 60 minutes except during printing. (engine lock) In case the developer bias is detected as on for 3340ms or more while the main charge bias is off. Backup task was not processed for 30s or more. | Engine PWB | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Check if the engine PWB is properly secured with screws. (Ground Confirmation) 3. Check that the connectors on the engine PWB are properly connected, and if not, re-connect them. 4. Check the engine firmware and upgrade to the latest version if necessary. 5. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|---|--|---|
| 7001 | Toner motor error(Black) In case the toner container rotation detection pulse signal does not change for 500ms in succession when turning the toner motor on, "Shake the toner container." message is indicated. (Resets by front cover open/close) The toner container rotation detection signals does change after repeating the above operation three times. | Toner container | 1. Check that the spiral of the toner container can be rotated by hand 2. Replace the toner container. |
| | | Drive transmission system for the toner motor | 1. Check if the couplings and gears rotate smoothly, and if not, clean or grease the gears. 2. Check for broken couplings and gears, and replace if any are found. |
| | | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. If a wire is pinched by another component, or has defective conduction, replace it. Toner motor - Engine PWB(YC14): 30 ppm model - Engine PWB(YC21): 35/40 ppm models |
| | | Toner motor | 1. Check how the toner motor is attached. 2. Replace the toner motor. (see page P.4-168,P.4-179) |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7002 | Toner motor error(Cyan) In case the toner container rotation detection pulse signal does not change for 500ms in succession when turning the toner motor on, "Shake the toner container." message is indicated. (Resets by front cover open/close) The toner container rotation detection signals does change after repeating the above operation three times. | Toner container | 1. Check that the spiral of the toner container can be rotated by hand 2. Replace the toner container. |
| | | Drive transmission system for the toner motor | 1. Check if the couplings and gears rotate smoothly, and if not, clean or grease the gears. 2. Check for broken couplings and gears, and replace if any are found. |
| | | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. If a wire is pinched by another component, or has defective conduction, replace it. Toner motor - Engine PWB(YC14): 30 ppm model - Engine PWB(YC21): 35/40 ppm models |
| | | Toner motor | 1. Check how the toner motor is attached. 2. Replace the toner motor. (see page P.4-168,P.4-179) |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|--|--|--|
| 7003 | Toner motor error (Magenta) In case the toner container rotation detection pulse signal does not change for 500ms in succession when turning the toner motor on, "Shake the toner container." message is indicated. (Resets by front cover open/close) The toner container rotation detection signals does change after repeating the above operation three times. | Toner container | 1. Check that the spiral of the toner container can be rotated by hand 2. Replace the toner container. |
| | | Drive transmission system for the toner motor | 1. Check if the couplings and gears rotate smoothly, and if not, clean or grease the gears. 2. Check for broken couplings and gears, and replace if any are found. |
| | | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. If a wire is pinched by another component, or has defective conduction, replace it. 3. Toner motor - Engine PWB(YC14): 30 ppm model - Engine PWB(YC21): 35/40 ppm models |
| | | Toner motor | 1. Check how the toner motor is attached. 2. Replace the toner motor. (see page P.4-168,P.4-179) |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7004 | Toner motor error (Yellow) In case the toner container rotation detection pulse signal does not change for 500ms in succession when turning the toner motor on, "Shake the toner container." message is indicated. (Resets by front cover open/close) The toner container rotation detection signals does change after repeating the above operation three times. | Toner container | 1. Check that the spiral of the toner container can be rotated by hand 2. Replace the toner container. |
| | | Drive transmission system for the toner motor | 1. Check if the couplings and gears rotate smoothly, and if not, clean or grease the gears. 2. Check for broken couplings and gears, and replace if any are found. |
| | | Defective connector cable or poor contact in the connector | 1. Reconnect the connector if its connection is loose. 2. If a wire is pinched by another component, or has defective conduction, replace it. Toner motor - Engine PWB(YC14): 30 ppm model - Engine PWB(YC21): 35/40 ppm models |
| | | Toner motor | 1. Check how the toner motor is attached. 2. Replace the toner motor. (see page P.4-168,P.4-179) |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|--------------------------|--|
| 7101 | Toner sensor error (Black) For a certain period of time, the sensor output value is less than 0.1V, or more than 3.2V. | Toner container | <ol style="list-style-type: none"> 1. Check that the toner container is properly installed, and if necessary, re-install. 2. Check that the toner supply inlet of the toner container can be opened by the lever operation. 3. Replace the toner container. |
| | | Toner sensor | <ol style="list-style-type: none"> 1. Confirm that the connector of the developer unit is firmly connected, and if necessary, push the unit all the way in. Toner sensor - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 2. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 3. Check if the gears and spirals in the developer unit rotate smoothly. 4. Replace the developer unit. (see page P.4-38) |
| | | Toner motor | <ol style="list-style-type: none"> 1. Check that the toner motor is properly attached. 2. Check if the couplings and gears can rotate or if they are not unusually loaded, and if necessary, replace. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Toner motor - Engine PWB(YC14): 30 ppm model - Engine PWB(YC21): 35/40 ppm models 4. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 5. Replace the toner motor. (see page P.4-168,P.4-179) |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|--------------------------|--|
| 7102 | Toner sensor error (Cyan) For a certain period of time, the sensor output value is less than 0.1V, or more than 3.2V. | Toner container | <ol style="list-style-type: none"> 1. Check that the toner container is properly installed, and if necessary, re-install. 2. Check that the toner supply inlet of the toner container can be opened by the lever operation. 3. Replace the toner container. |
| | | Toner sensor | <ol style="list-style-type: none"> 1. Confirm that the connector of the developer unit is firmly connected, and if necessary, push the unit all the way in. Toner sensor - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 2. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 3. Check if the gears and spirals in the developer unit rotate smoothly. 4. Replace the developer unit. (see page P.4-38) |
| | | Toner motor | <ol style="list-style-type: none"> 1. Check that the toner motor is properly attached. 2. Check if the couplings and gears can rotate or if they are not unusually loaded, and if necessary, replace. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Toner motor - Engine PWB(YC14): 30 ppm model - Engine PWB(YC21): 35/40 ppm models 4. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 5. Replace the toner motor. (see page P.4-168,P.4-179) |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|--------------------------|--|
| 7103 | Toner sensor error (Magenta) For a certain period of time, the sensor output value is less than 0.1V, or more than 3.2V. | Toner container | <ol style="list-style-type: none"> 1. Check that the toner container is properly installed, and if necessary, re-install. 2. Check that the toner supply inlet of the toner container can be opened by the lever operation. 3. Replace the toner container. |
| | | Toner sensor | <ol style="list-style-type: none"> 1. Confirm that the connector of the developer unit is firmly connected, and if necessary, push the unit all the way in. Toner sensor - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 2. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 3. Check if the gears and spirals in the developer unit rotate smoothly. 4. Replace the developer unit. (see page P.4-38) |
| | | Toner motor | <ol style="list-style-type: none"> 1. Check that the toner motor is properly attached. 2. Check if the couplings and gears can rotate or if they are not unusually loaded, and if necessary, replace. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Toner motor - Engine PWB(YC14): 30 ppm model - Engine PWB(YC21): 35/40 ppm models 4. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 5. Replace the toner motor. (see page P.4-168,P.4-179) |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|--------------------------|--|
| 7104 | Toner sensor error (Yellow) For a certain period of time, the sensor output value is less than 0.1V, or more than 3.2V. | Toner container | <ol style="list-style-type: none"> 1. Check that the toner container is properly installed, and if necessary, re-install. 2. Check that the toner supply inlet of the toner container can be opened by the lever operation. 3. Replace the toner container. |
| | | Toner sensor | <ol style="list-style-type: none"> 1. Confirm that the connector of the developer unit is firmly connected, and if necessary, push the unit all the way in. Toner sensor - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 2. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 3. Check if the gears and spirals in the developer unit rotate smoothly. 4. Replace the developer unit. (see page P.4-38) |
| | | Toner motor | <ol style="list-style-type: none"> 1. Check that the toner motor is properly attached. 2. Check if the couplings and gears can rotate or if they are not unusually loaded, and if necessary, replace. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Toner motor - Engine PWB(YC14): 30 ppm model - Engine PWB(YC21): 35/40 ppm models 4. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 5. Replace the toner motor. (see page P.4-168,P.4-179) |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|--|--------------------------|---|
| 7200 | Broken inner thermistor wire (Developer) The sensor input sampling value is greater than the reference value. (After detection, controlled at 25 °C/77.0 °F) | Developer unit BK | <ol style="list-style-type: none"> 1. Confirm that the connector of the developer unit BK is firmly connected, and if necessary, push the unit all the way in. Toner sensor BK - Drum/Developer relay PWB(YC8) Drum/Developer relay PWB - Engine PWB(YC6) 2. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 3. Replace the developer unit BK. (see page P.4-38) |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7210 | Short-circuited inner thermistor (Developer) The sensor input sampling value is less than the reference value. (After detection, controlled at 25 °C/77.0 °F) | Developer unit BK | <ol style="list-style-type: none"> 1. Confirm that the connector of the developer unit BK is firmly connected, and if necessary, push the unit all the way in. Toner sensor BK - Drum/Developer relay PWB(YC8) Drum/Developer relay PWB - Engine PWB(YC6) 2. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 3. Replace the developer unit BK. (see page P.4-38) |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|--------------------------|---|
| 7221 | Broken inner thermistor wire (LSU) The sensor input sampling value is greater than the reference value. (After detection, controlled at 25 °C/77.0 °F) | Laser scanner unit (LSU) | 1. Confirm that the wiring connector of the LSU is firmly connected, and if necessary, connect the connector all the way in. LSU - Main PWB(YC2016): 30 ppm model LSU - Engine PWB(YC8): 35/40 ppm models 2. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 3. Replace the LSU. (see page P.4-76) |
| | | Main PWB Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the main PWB. (see page P.4-208,P.4-212) 3. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7231 | Short-circuited inner thermistor (LSU) The sensor input sampling value is less than the reference value. (After detection, controlled at 25 °C/77.0 °F) | Laser scanner unit (LSU) | 1. Confirm that the wiring connector of the LSU is firmly connected, and if necessary, connect the connector all the way in. LSU - Main PWB(YC2016): 30 ppm model LSU - Engine PWB(YC8): 35/40 ppm models 2. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 3. Replace the LSU. (see page P.4-76) |
| | | Main PWB Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the main PWB. (see page P.4-208,P.4-212) 3. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7401 | Developer unit type Mismatch error (Black) Improper adaptation of the main unit and developer unit is detected. | Developer unit | 1. Check if the developer unit of different models is mounted, and replace it to the correct one. (see page P.4-38) 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Developer unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|--------------------------|---|
| 7402 | <p>Developer unit type Mismatch error (Cyan)</p> <p>Improper adaptation of the main unit and developer unit is detected.</p> | Developer unit | <ol style="list-style-type: none"> 1. Check if the developer unit of different models is mounted, and replace it to the correct one. (see page P.4-38) 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Developer unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7403 | <p>Developer unit type Mismatch error (Magenta)</p> <p>Improper adaptation of the main unit and developer unit is detected.</p> | Developer unit | <ol style="list-style-type: none"> 1. Check if the developer unit of different models is mounted, and replace it to the correct one. (see page P.4-38) 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Developer unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|--------------------------|---|
| 7404 | Developer unit type mismatch error (Yellow) Improper adaptation of the main unit and developer unit is detected. | Developer unit | 1. Check if the developer unit of different models is mounted, and replace it to the correct one. (see page P.4-38) 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Developer unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7411 | Drum unit type Mismatch error (Black) Improper adaptation of the main unit and drum unit is detected. | Drum unit | 1. Check if the drum unit of different models is attached, and replace it to the correct one. (see page P.4-34) 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Drum unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|--------------------------|--|
| 7412 | Drum unit type Mismatch error (Cyan) Improper adaptation of the main unit and drum unit is detected. | Drum unit | 1. Check if the drum unit of different models is attached, and replace it to the correct one. (see page P.4-34) 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Drum unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7413 | Drum unit type Mismatch error (Magenta) Improper adaptation of the main unit and drum unit is detected. | Drum unit | 1. Check if the drum unit of different models is attached, and replace it to the correct one. (see page P.4-34) 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Drum unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|--------------------------|--|
| 7414 | <p>Drum unit type Mismatch error (Yellow)</p> <p>Improper adaptation of the main unit and drum unit is detected.</p> | Drum unit | <ol style="list-style-type: none"> 1. Check if the drum unit of different models is attached, and replace it to the correct one. (see page P.4-34) 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Drum unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7601 | <p>ID sensor error (front)</p> <p>When the measured value of the ID sensor matches any of the following.</p> <p>The dark potential P/S-wave is greater than 0.8V.</p> <p>If the light potential S-wave is lower than the dark potential S-wave.</p> <p>If the light potential P-wave is lower than the dark potential P-wave (+0.5V).</p> | ID sensor | <ol style="list-style-type: none"> 1. Clean the ID sensor surface. 2. Check how the ID sensor is attached. 3. Check if the error is detected after performing the calibration. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. ID sensor - Engine PWB (YC13): 30 ppm model - Engine PWB(YC19): 35/40 ppm models 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the ID sensor. |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|------------------------------------|--|
| 7602 | <p>ID sensor error (rear)</p> <p>When the measured value of the ID sensor matches any of the following.</p> <p>The dark potential P/S-wave is greater than 0.8V.</p> <p>If the light potential S-wave is lower than the dark potential S-wave.</p> | ID sensor | <ol style="list-style-type: none"> 1. Clean the ID sensor surface. 2. Check how the ID sensor is attached. 3. Check if the error is detected after performing the calibration. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. ID sensor - Engine PWB (YC13): 30 ppm model - Engine PWB(YC19): 35/40 ppm models 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the ID sensor. |
| | <p>If the light potential P-wave is lower than the dark potential P-wave (+0.5V).</p> | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7611 | <p>Bias calibration reading value error (Black)</p> <p>During the calibration, the ID sensor cannot read a patch density on the primary transfer belt normally.</p> | Primary transfer belt ID sensor | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Execute [Calibration] using [Adjustment/Maintenance] of the system menu. 3. Check the occurrence of this service call error in the Event Log. 4. When the same service call error is detected again, clean if there is any dirt or stains on the primary transfer belt or the ID sensor surface. 5. Check whether or not the ID sensor shutter is open, by opening and closing the paper tray. 6. If not corrected, replace the primary transfer unit. (see page P.4-32) 7. After performing the test print, if the poor density occurs, check whether there is any failure in the drum unit, developer unit, LSU. |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|------------------------------------|--|
| 7612 | <p>Bias calibration reading value error (Cyan)</p> <p>During the calibration, the ID sensor cannot read a patch density on the primary transfer belt normally.</p> | Primary transfer belt ID sensor | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Execute [Calibration] using [Adjustment/Maintenance] of the system menu. 3. Check the occurrence of this service call error in the Event Log. 4. When the same service call error is detected again, clean if there is any dirt or stains on the primary transfer belt or the ID sensor surface. 5. Check whether or not the ID sensor shutter is open, by opening and closing the paper tray. 6. If not corrected, replace the primary transfer unit. (see page P.4-32) 7. After performing the test print, if the poor density occurs, check whether there is any failure in the drum unit, developer unit, LSU. |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7613 | <p>Bias calibration reading value error (Magenta)</p> <p>During the calibration, the ID sensor cannot read a patch density on the primary transfer belt normally.</p> | Primary transfer belt ID sensor | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Execute [Calibration] using [Adjustment/Maintenance] of the system menu. 3. Check the occurrence of this service call error in the Event Log. 4. When the same service call error is detected again, clean if there is any dirt or stains on the primary transfer belt or the ID sensor surface. 5. Check whether or not the ID sensor shutter is open, by opening and closing the paper tray. 6. If not corrected, replace the primary transfer unit. (see page P.4-32) 7. After performing the test print, if the poor density occurs, check whether there is any failure in the drum unit, developer unit, LSU. |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|---|--|
| 7614 | <p>Bias calibration reading value error (Yellow)</p> <p>During the calibration, the ID sensor cannot read a patch density on the primary transfer belt normally.</p> | Primary transfer belt ID sensor | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Execute [Calibration] using [Adjustment/Maintenance] of the system menu. 3. Check the occurrence of this service call error in the Event Log. 4. When the same service call error is detected again, clean if there is any dirt or stains on the primary transfer belt or the ID sensor surface. 5. Check whether or not the ID sensor shutter is open, by opening and closing the paper tray. 6. If not corrected, replace the primary transfer unit. (see page P.4-32) 7. After performing the test print, if the poor density occurs, check whether there is any failure in the drum unit, developer unit, LSU. |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7620 | <p>Color Registration timing of detection</p> <p>Color patches printed on the primary transfer belt are not within the ID sensor readable range. Or the poor density occurs.</p> | Primary transfer belt ID sensor LSU | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Execute [Calibration] using [Adjustment/Maintenance] of the system menu. 3. Check the occurrence of this service call error in the Event Log. 4. When the same service call error is detected again, clean if there is any dirt or stains on the primary transfer belt or the ID sensor surface. 5. Check whether or not the ID sensor shutter is open, by opening and closing the paper tray. 6. If not corrected, replace the primary transfer unit. (see page P.4-32) 7. After performing the test print, if the poor density occurs, check whether there is any failure in the drum unit, developer unit, LSU. 8. When checking the printing position of the color, if any color shift occurs, re-install the LSU and the drum unit. 9. If not corrected, replace the LSU. (see page P.4-76) |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|---------------------------------|--|
| 7800 | Broken outer thermistor wire The temperature and humidity sensor input sampling value is abnormal compared with the reference. (After detection, controlled at 25 °C/77.0 °F) | Temperature and humidity sensor | 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Temperature and humidity sensor - Engine PWB(YC10): 30 ppm model - Engine PWB(YC17): 35/40 ppm models 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Replace the temperature sensor PWB. |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7810 | Short-circuited outer thermistor The sensor input sampling value is less than the reference value. (After detection, controlled at 25 °C/77.0 °F) | Temperature and humidity sensor | 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Temperature and humidity sensor - Engine PWB(YC10): 30 ppm model - Engine PWB(YC17): 35/40 ppm models 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Replace the temperature sensor PWB. |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|--------------------------|---|
| 7901 | <p>Drum unit EEPROM error (Black)</p> <p>No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated 5 times successively.</p> <p>Mismatch of reading data from two locations occurs 8 times successively.</p> <p>Mismatch between writing data and reading data occurs 8 times successively.</p> | Drum unit | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Confirm that the connector of the drum unit is firmly connected, and if necessary, push the unit all the way in. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Drum unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 4. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 5. Replace the drum unit. (see page P.4-34) |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7902 | <p>Drum unit EEPROM error (Cyan)</p> <p>No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated 5 times successively.</p> <p>Mismatch of reading data from two locations occurs 8 times successively.</p> <p>Mismatch between writing data and reading data occurs 8 times successively.</p> | Drum unit | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Confirm that the connector of the drum unit is firmly connected, and if necessary, push the unit all the way in. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Drum unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 4. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 5. Replace the drum unit. (see page P.4-34) |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|--|--------------------------|---|
| 7903 | Drum unit EEPROM error (Magenta) No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated 5 times successively. Mismatch of reading data from two locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively. | Drum unit | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Confirm that the connector of the drum unit is firmly connected, and if necessary, push the unit all the way in. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Drum unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 4. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 5. Replace the drum unit. (see page P.4-34) |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7904 | Drum unit EEPROM error (Yellow) No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated 5 times successively. Mismatch of reading data from two locations occurs 8 times successively. Mismatch between writing data and reading data occurs 8 times successively. | Drum unit | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Confirm that the connector of the drum unit is firmly connected, and if necessary, push the unit all the way in. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Drum unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 4. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 5. Replace the drum unit. (see page P.4-34) |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|--------------------------|--|
| 7911 | <p>Developer unit EEPROM error (Black)</p> <p>No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated 5 times successively.</p> <p>Mismatch of reading data from two locations occurs 8 times successively.</p> <p>Mismatch between writing data and reading data occurs 8 times successively.</p> | Developer unit | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Confirm that the connector of the developer unit is firmly connected, and if necessary, push the unit all the way in. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Developer unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 4. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 5. Replace the developer unit. (see page P.4-38) |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7912 | <p>Developer unit EEPROM error (Cyan)</p> <p>No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated 5 times successively.</p> <p>Mismatch of reading data from two locations occurs 8 times successively.</p> <p>Mismatch between writing data and reading data occurs 8 times successively.</p> | Developer unit | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Confirm that the connector of the developer unit is firmly connected, and if necessary, push the unit all the way in. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Developer unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 4. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 5. Replace the developer unit. (see page P.4-38) |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|--------------------------|--|
| 7913 | <p>Developer unit EEPROM error (Magenta)</p> <p>No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated 5 times successively.</p> <p>Mismatch of reading data from two locations occurs 8 times successively.</p> <p>Mismatch between writing data and reading data occurs 8 times successively.</p> | Developer unit | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Confirm that the connector of the developer unit is firmly connected, and if necessary, push the unit all the way in. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Developer unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 4. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 5. Replace the developer unit. (see page P.4-38) |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 7914 | <p>Developer unit EEPROM error (Yellow)</p> <p>No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated 5 times successively.</p> <p>Mismatch of reading data from two locations occurs 8 times successively.</p> <p>Mismatch between writing data and reading data occurs 8 times successively.</p> | Developer unit | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Confirm that the connector of the developer unit is firmly connected, and if necessary, push the unit all the way in. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Developer unit - Drum/Developer relay PWB Drum/Developer relay PWB - Engine PWB(YC6) 4. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 5. Replace the developer unit. (see page P.4-38) |
| | | Drum/developer relay PWB | Replace the drum/developer relay PWB |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|----------------------------|--|
| 8000 | <p>Finisher incompatible detection error</p> <p>Improper adaptation of the main unit and finisher is detected.</p> <p>(30 ppm model only)</p> | Finisher | Check if the Finisher of a different model is mounted, and replace it with the correct one. |
| 8010 | <p>Punch motor error 1</p> <p>The punch home position sensor is not turned on when passing 200ms during the punch motor drive.</p> <p>(35/40 ppm model only)</p> | Punch motor | <ol style="list-style-type: none"> 1. Execute [Motor] > [Punch] in U240 Checking the operation of the finisher. (see page P.6-305) 2. Check if the punch unit can be moved manually without being caught. 3. Check if the motor drive is delivered to the punch cam. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Punch motor - Punch PWB (YC4) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the punch motor. |
| | | Punch home position sensor | <ol style="list-style-type: none"> 1. Execute [Punch] > [Punch HP] in U241 Checking the operation of the finisher switch. (see page P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Punch home position sensor - Punch PWB (YC8) 4. Replace the punch home position sensor. |
| | | Punch PWB | <ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Punch PWB - DF main PWB (YC7) 2. Replace the punch PWB. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-280,P.4-283) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|---|----------------|--|
| 8020 | Punch motor error 2 In case the home position cannot be in position for 3 s or less when initializing or waiting for the home position. (35/40 ppm model only) | Punch motor | <ol style="list-style-type: none"> 1. Execute [Motor] > [Punch] in U240 Checking the operation of the finisher. (see page P.6-305) 2. Check if the punch unit can be moved manually without being caught. 3. Check if the motor drive is delivered to the punch cam. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Punch motor - Punch PWB (YC4) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the punch motor. |
| | | Punch unit PWB | <ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Punch PWB - DF main PWB (YC7) 2. Replace the punch PWB. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-280,P.4-283) |
| 8030 | Punch motor error 3 In case the home position ON state does not turn OFF within 50ms during operation. (35/40 ppm model only) | Punch motor | <ol style="list-style-type: none"> 1. Execute [Motor] > [Punch] in U240 Checking the operation of the finisher. (see page P.6-305) 2. Check if the punch unit can be moved manually without being caught. 3. Check if the motor drive is delivered to the punch cam. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Punch motor - Punch PWB (YC4) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the punch motor. |
| | | Punch unit PWB | <ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Punch PWB - DF main PWB (YC7) 2. Replace the punch PWB. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-280,P.4-283) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|-----------------------|---|
| 8090 | <p>DF paddle motor error</p> <p>In case the DF paddle sensor does not detect ON/OFF when 1s passes while the DF paddle motor drives.</p> | DF paddle motor error | <ol style="list-style-type: none"> 1. Execute [Motor] > [Beat] in U240 Checking the operation of the finisher. (see page P.6-88,P.6-305) 2. Check if the paddle is rotating. 3. Check if the motor drive is delivered to the paddle. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF paddle motor - DF main PWB(YC9) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the DF paddle motor. |
| | | DF paddle sensor | <ol style="list-style-type: none"> 1. Execute [Finisher]>[Bundle Eject HP] in U241 Checking the operation of the finisher switch. (see page P.6-90,P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF paddle sensor - DF main PWB(YC19) 4. Replace the DF paddle sensor. |
| | | DF main PWB | <p>Replace the DF main PWB. (see page P.4-276,P.4-280,P.4-283)</p> |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|------------------------|---|
| 8100 | <p>DF eject release motor error</p> <p>The DF bundle eject sensor does not detect ON/OFF when 1s passes while the DF eject release motor drives.</p> | DF eject release motor | <ol style="list-style-type: none"> 1. Execute [Motor] > [Eject Unlock (Full)] in U240 Checking the operation of the finisher. (see page P.6-88,P.6-305) 2. Check if the eject guide of the finisher tray is open and otherwise, correct it. 3. Check if the motor drive is delivered to the eject guide. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF eject release motor - DF main PWB(YC8) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the DF eject release motor. |
| | | DF bundle eject sensor | <ol style="list-style-type: none"> 1. Execute [Finisher]>[Bundle Eject HP] in U241 Checking the operation of the finisher switch. (see page P.6-90,P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF bundle eject sensor - DF main PWB(YC19) 4. Replace the DF bundled paper eject sensor. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-276,P.4-280,P.4-283) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|--|---|
| 8140 | DF tray error 1 In case unable to detect the DF tray sensor 1 or DF tray upper level sensor is turned ON when the main tray ascends and 30 s have passed. | DF tray motor | <ol style="list-style-type: none"> 1. Execute [Motor] > [Tray] in U240 Checking the operation of the finisher. (see page P.6-88,P.6-305) 2. Check if the main tray can be moved up and down manually without getting caught. 3. Check if the motor drive is delivered to the main tray. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF tray motor - DF main PWB(YC12) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the DF tray motor. |
| | | DF tray sensor 1 DF tray upper surface sensor | <ol style="list-style-type: none"> 1. Execute [Finisher]>[Tray U-Limit, Tray Top] in U241 Checking the operation of the finisher switch. (see page P.6-90,P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF tray sensor 1 - DF main PWB(YC19) DF tray upper surface sensor - DF main PWB(YC15) 4. Replace the DF tray sensor 1 or DF tray upper surface sensor. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-276,P.4-280,P.4-283) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|--|--|
| 8150 | <p>DF tray error 2</p> <p>In case unable to detect the DF tray sensor 1 or DF tray upper level sensor is turned OFF when the main tray descends and 5 s have passed.</p> <p>(35/40 ppm model only)</p> | DF tray motor | <ol style="list-style-type: none"> 1. Execute [Motor] > [Tray] in U240 Checking the operation of the finisher. (see page P.6-305) 2. Check if the main tray can be moved up and down manually without getting caught. 3. Check if the motor drive is delivered to the main tray. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF tray motor - DF main PWB(YC11) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the DF tray motor. |
| | | DF tray sensor 1 DF tray upper surface sensor | <ol style="list-style-type: none"> 1. Execute [Finisher]>[Tray U-Limit, Tray Top] in U241 Checking the operation of the finisher switch. (see page P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF tray sensor 1 - DF main PWB(YC19) DF tray upper surface sensor - DF main PWB(YC15) 4. Replace the DF tray sensor 1 or DF tray upper surface sensor. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-280,P.4-283) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|------------------|---|
| 8160 | <p>DF tray error 3</p> <p>(1000-sheet Finisher) In case unable to detect the DF tray sensor 3 is turned ON when the main tray descends and 30 s have passed.</p> <p>(3000-sheet Finisher) In case unable to detect the DF tray sensor 3 is turned ON when the main tray descends and 60 s have passed.</p> | DF tray motor | <ol style="list-style-type: none"> 1. Execute [Motor] > [Tray] in U240 Checking the operation of the finisher. (see page P.6-88,P.6-305) 2. Check if the main tray can be moved up and down manually without getting caught. 3. Check if the motor drive is delivered to the main tray. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF tray motor - DF main PWB(YC11) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the DF tray motor. |
| | (inner finisher) In case unable to detect the DF tray home position sensor is turned ON when the main tray descends and 4 s have passed. | DF tray sensor 3 | <ol style="list-style-type: none"> 1. Execute [Finisher]>[Tray Middle] in U241 Checking the operation of the finisher switch. (see page P.6-90,P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF tray sensor 3 - DF main PWB(YC19) 4. Replace the DF tray sensor 3. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-276,P.4-280,P.4-283) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|-------------------------------|---|
| 8170 | <p>DF side registration motor 1 error 1</p> <p>In case unable to detect the DF side registration sensor 1 is turned ON when passing 3 s during operation.</p> | DF side registration motor 1 | <ol style="list-style-type: none"> 1. Execute [Motor] > [Width Test] in U240 Checking the operation of the finisher. (see page P.6-88,P.6-305) 2. Check if the side registration front guide can be moved manually without being caught up. 3. Check if the motor drive is delivered to the side registration front guide. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF side registration motor 1 - DF main PWB(YC9) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the DF side registration motor 1. |
| | | DF side registration sensor 1 | <ol style="list-style-type: none"> 1. Execute [Finisher]>[Width Front] in U241 Checking the operation of the finisher switch. (see page P.6-90,P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF side registration sensor 1 - DF main PWB(YC11) 4. Replace the DF side registration sensor 1. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-276,P.4-280,P.4-283) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|-------------------------------|---|
| 8180 | <p>DF side registration motor 1 error 2</p> <p>In case JAM6810 (DF side registration sensor 1 stay jam) is detected twice in succession.</p> | DF side registration motor 1 | <ol style="list-style-type: none"> 1. Execute [Motor] > [Width Test] in U240 Checking the operation of the finisher. (see page P.6-88,P.6-305) 2. Check if the side registration front guide can be moved manually without being caught up. 3. Check if the motor drive is delivered to the side registration front guide. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF side registration motor 1 - DF main PWB(YC9) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the DF side registration motor 1. |
| | | DF side registration sensor 1 | <ol style="list-style-type: none"> 1. Execute [Finisher]>[Width Front] in U241 Checking the operation of the finisher switch. (see page P.6-90,P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF side registration sensor 1 - DF main PWB(YC19) 4. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 5. Replace the DF side registration sensor 1. |
| | | DF main PWB | <p>Replace the DF main PWB. (see page P.4-276,P.4-280,P.4-283)</p> |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|-------------------------------|---|
| 8190 | <p>DF side registration motor 2 error 1</p> <p>In case unable to detect the DF side registration sensor 2 is turned ON when passing 3 s during operation.</p> | DF side registration motor 2 | <ol style="list-style-type: none"> 1. Execute [Motor] > [Width Test] in U240 Checking the operation of the finisher. (see page P.6-88,P.6-305) 2. Check if the side registration rear guide can be moved manually without being caught up. 3. Check if the motor drive is delivered to the side registration rear guide. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF side registration motor 2 - DF main PWB(YC9) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the DF side registration motor 2. |
| | | DF side registration sensor 2 | <ol style="list-style-type: none"> 1. Execute [Finisher]>[Width Tail HP] in U241 Checking the operation of the finisher switch. (see page P.6-90,P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF side registration sensor 2 - DF main PWB(YC19) 4. Replace the DF side registration sensor 2. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-276,P.4-280,P.4-283) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|-------------------------------|---|
| 8200 | <p>DF side registration motor 2 error 2</p> <p>In case JAM6910 (DF side registration sensor 2 stay jam) is detected twice in succession.</p> | DF side registration motor 2 | <ol style="list-style-type: none"> 1. Execute [Motor] > [Width Test] in U240 Checking the operation of the finisher. (see page P.6-88,P.6-305) 2. Check if the side registration rear guide can be moved manually without being caught up. 3. Check if the motor drive is delivered to the side registration rear guide. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF side registration motor 2 - DF main PWB(YC9) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the DF side registration motor 2. |
| | | DF side registration sensor 2 | <ol style="list-style-type: none"> 1. Execute [Finisher]>[Width Tail HP] in U241 Checking the operation of the finisher switch. (see page P.6-90,P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF side registration sensor 2 - DF main PWB(YC19) 4. Replace the DF side registration sensor 2. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-276,P.4-280,P.4-283) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|------------------|--|
| 8210 | <p>DF slide motor error</p> <p>Incase unable to detect the DF staple sensor is turned ON when passing 3 s during the intial operation.</p> | DF slide motor | <ol style="list-style-type: none"> 1. Execute [Motor] > [Staple Move] in U240 Checking the operation of the finisher. (see page P.6-88,P.6-305) 2. Check if the staple unit can move manually forward and backward without being caught. 3. Check if the motor drive is delivered to the staple unit. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF slide motor - DF main PWB(YC8) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the DF slide motor. |
| | | DF staple sensor | <ol style="list-style-type: none"> 1. Execute [Finisher]>[Staple HP] in U241 Checking the operation of the finisher switch. (see page P.6-90,P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF staple sensor - DF main PWB(YC10) 4. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 5. Replace the DF staple sensor. |
| | | DF main PWB | <p>Replace the DF main PWB. (see page P.4-276,P.4-280,P.4-283)</p> |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|------------------|---|
| 8230 | DF staple motor error 1 In case staple JAM (DF) is detected twice in succession. (2nd jam detection condition was that the home position was not detected 600ms after the motor start-up) | DF staple motor | 1. Remove the staple unit and check if it can be moved manually without jamming. 2. Check if the FFC cable connector is broken or deformed and insert the FFC cable all the way. Staple unit - DF main PWB(YC10) 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 4. Replace the staple unit. |
| | | DF staple sensor | Replace the staple unit. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-276,P.4-280,P.4-283) |
| 8250 | Main tray error 4 In case the lock signal is 0.7V or less for 10 s in succession during the DF tray motor drive. (35/40 ppm model only) | DF tray motor | 1. Execute [Motor] > [Tray] in U240 Checking the operation of the finisher. (see page P.6-305) 2. Check if the main tray can be moved up and down manually without getting caught. 3. Check if the motor drive is delivered to the main tray. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF tray motor - DF main PWB(YC11) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the DF tray motor. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-280,P.4-283) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|------------------|--|
| 8260 | <p>DF middle motor home position detection error</p> <p>A middle paddle jam has been detected 2 times in succession.</p> | DF middle motor | <ol style="list-style-type: none"> 1. Execute [Motor] > [Middle(H)(L)] in U240 Checking the operation of the finisher. (see page P.6-88,P.6-305) 2. Check if the motor drive is delivered to the paddle. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF middle motor - DF main PWB(YC8) 4. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 5. Replace the DF middle motor. |
| | | DF paddle sensor | <ol style="list-style-type: none"> 1. Execute [Finisher]>[Lead Paddle] in U241 Checking the operation of the finisher switch. (see page P.6-90,P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF paddle sensor - DF main PWB(YC19) 4. Replace the DF paddle sensor. |
| | | DF main PWB | <p>Replace the DF main PWB. (see page P.4-276,P.4-280,P.4-283)</p> |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|--------------------|---|
| 8410 | Punch slide motor error 1 In case the punch slide sensor is not turned ON when the home position has moved 60mm. (35/40 ppm model only) | Punch slide motor | <ol style="list-style-type: none"> 1. Execute [Motor] > [Punch Move] in U240 Checking the operation of the finisher. (see page P.6-305) 2. The punch slide section of the punch unit moves back and forth manually without being caught. 3. Check if the motor drive is delivered to the punch section. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Punch slide motor - Punch PWB (YC3) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the punch slide motor. |
| | | Punch slide sensor | <ol style="list-style-type: none"> 1. Execute [Punch] > [Punch HP] in U241 Checking the operation of the finisher switch. (see page P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Punch slide sensor - Punch PWB (YC6) 4. Replace the punch slide sensor. |
| | | Punch PWB | <ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Punch PWB - DF main PWB (YC7) 2. Replace the Punch PWB. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-280,P.4-283) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|-----------------------------|--|
| 8420 | <p>Punch slide motor error 2</p> <p>During paper edge detection, in case a paper edge cannot be detected even when the paper moves 60mm</p> <p>(35/40 ppm model only)</p> | Punch slide motor | <ol style="list-style-type: none"> 1. Execute [Motor] > [Punch Move] in U240 Checking the operation of the finisher. (see page P.6-305) 2. The punch slide section of the punch unit moves back and forth manually without being caught. 3. Check if the motor drive is delivered to the punch section. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Punch slide motor - Punch PWB(YC3) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the punch slide motor. |
| | | Punch paper edge sensor 1,2 | <ol style="list-style-type: none"> 1. Execute [Punch] > [Edge] Face1,2,3,4 in U241 Checking the operation of the finisher switch. (see page P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Punch paper edge sensor 1,2 - Punch PWB (YC8,YC5) 4. Replace the punch paper edge sensor 1,2. |
| | | Punch unit PWB | <ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Punch PWB - DF main PWB (YC7) 2. Replace the Punch PWB. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-280,P.4-283) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|-------------------------|--|
| 8430 | Punch unit communication error In case no communication is established with the punch unit. (35/40 ppm model only) | Punch PWB | 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. Punch PWB - DF main PWB (YC7) 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Replace the Punch PWB. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-280,P.4-283) |
| 8500 | Mailbox communication error In case no communication is established after confirming connection with the mail box. | MB main PWB | 1. Turn the power switch off. Then, after waiting 5 seconds, turn the power on. 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. MB main PWB - DF main PWB 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 4. Replace the MB main PWB. |
| | | DF main PWB | Replace the DF main PWB. (see page P.4-276,P.4-280,P.4-283) |
| 8510 | MB drive motor error 1 In case unable to detect the MB home position sensor is turned ON when passing 5 s during the initial operation. | MB conveying motor | 1. Correct the mechanism if the conveying roller gets caught when rotating it manually. 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. MB drive motor - MB main PWB(YC4) 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 4. Replace the MB drive motor. |
| | | MB home position sensor | 1. Execute [Mail Box] > [Motor HP] in U241 Checking the operation of the finisher switch. (see page P.6-90,P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. MB home position sensor - MB main PWB(YC3) 4. Replace the MB home position sensor. |
| | | MB main PWB | Replace the MB main PWB. |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|--|-------------------------|---|
| 8520 | MB drive motor error 2 In case unable to detect the MB home position sensor is turned OFF when passing 1 s during standby. | MB drive motor | <ol style="list-style-type: none"> 1. Execute [Mail Box] > [Conv] in U240 Checking the operation of the finisher. (see page P.6-88,P.6-305) 2. Check if the conveying roller of the mail box can be rotated manually without being caught. 3. Check if the motor drive is delivered to the conveying roller. 4. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. MB drive motor - MB main PWB(YC4) 5. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 6. Replace the MB drive motor. |
| | | MB home position sensor | <ol style="list-style-type: none"> 1. Execute [Mail Box] > [Motor HP] in U241 Checking the operation of the finisher switch. (see page P.6-90,P.6-307) 2. Check if there is a failure in the position of the sensor or mounting plate. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. MB home position sensor - MB main PWB(YC3) 4. Replace the MB home position sensor. |
| | | MB main PWB | Replace the MB main PWB. |
| 8800 | Document Finisher Main program error In case there is abnormality in the main program when turning the power on. | DF main PWB | <ol style="list-style-type: none"> 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF main PWB - Engine PWB(YC24): 30 ppm model - Engine PWB(YC31): 35/40 ppm models 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Replace the DF main PWB. (see page P.4-276,P.4-280,P.4-283) |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|--|---------------|---|
| 8900 | Document finisher backup error Mismatch between writing data and reading data occurs 3 times successively. | DF main PWB | 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF main PWB - Engine PWB(YC24): 30 ppm model - Engine PWB(YC31): 35/40 ppm models 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 3. Replace the DF main PWB. (see page P.4-276,P.4-280,P.4-283) |
| | | Engine PWB | 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 8990 | Finisher setup error In case the bridge (AK) is not installed while the DF is connected. (35/40 ppm model only) | Finisher | 1. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DF main PWB - Engine PWB(YC24): 30 ppm model - Engine PWB(YC31): 35/40 ppm models 2. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. |
| | | DF main PWB | 1. Check EEPROM mount and correct it. 2. Replace the DF main PWB. (see page P.4-276,P.4-280,P.4-283) |
| 9070 | Communication error between the DP and SHD A communication error is detected. (35/40 ppm model only) | DPSHD PWB | 1. Execute the U906 Resetting the partial operation. (see page P.6-415) 2. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DPSHD PWB - DP main PWB 3. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 4. Replace the DPSHD PWB. (see page P.4-270) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|-------------|--|----------------------|--|
| 9180 | DP feed-shift motor error The HP cannot be detected even after executing the HP detection retrial 3 consecutive times. HP detection: when the DP feed-shift motor is driven to move to the HP, the HP is not detected after it is rotated once. | DP feed-shift motor | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Confirm that the connector of the DP feed-shift motor is firmly connected, and if necessary, push the unit all the way in. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DP feed-shift motor - Engine PWB (YC6) 4. If the wire is disconnected, short-circuited or has a ground fault, or the connector pin is deformed, replace the wire. 5. Replace the DF feed-shift motor. |
| | | DP feed-shift sensor | <ol style="list-style-type: none"> 1. Rotate the DP feed-shift motor manually to check that it is not unusually difficult to rotate. 2. Check if the DP feed-shift sensor is out of position because it has dropped off and if the sensor light is interrupted by the actuator. 3. Confirm that the wiring connector is firmly connected, and if necessary, connect the connector all the way in. DP feed-shift sensor - DP main PWB (YC4) DP main PWB - Engine PWB (YC6) 4. If the wiring is disconnected, short-circuited or has a ground fault, replace the wire. 5. Replace the DP feed-shift sensor. |
| | | Engine PWB | <ol style="list-style-type: none"> 1. Check the engine firmware and upgrade to the latest version if necessary. 2. Replace the engine PWB. (see page P.4-200,P.4-204) |
| 9500 | IPU PWB error A (35/40 ppm model only) | Main PWB DPIF PWB | <ol style="list-style-type: none"> 1. Reconnect the connector if its connection is loose. Main PWB (YC4) - DPIF PWB (YC10) 2. Replace the main PWB. (see page P.4-212) 3. Replace the DPIF PWB. (see page P.4-212) 4. Please contact your service support department. |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|----------------------|---|-----------------------|--|
| 9510 | IPU PWB error B (35/40 ppm model only) | Main PWB DPSHD PWB | 1. Reconnect the connector if its connection is loose. DPIF PWB - DPSHD PWB (YC4) 2. Replace the main PWB. (see page P.4-212) 3. Replace the DPSHD PWB. (see page P.4-270) 4. Please contact your service support department. |
| 9530 9540 9550 | Backup data error The internal data changes by replacing multiple parts at the same time, interfering with the machine operation and will not enter ready mode. | PWBs | In case two or more of the parts below were replaced at the same time, reattach them. Applicable parts: Memory, PWBs *When replacing the applicable parts, 2 or more do not replace then at the same time. *When replacing the above applicable parts, do not work the following at the same time. Replace the drum unit or the developing unit. Replace the drum unit for one color with another in the same machine. |
| F000 | Communication error between Main PWB - Operation panel PWB | Main PWB | 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Check the wiring and connectors between the main PWB - the operation panel PWB. Operation panel PWB - Main PWB (YC2002): 30 ppm model - Main PWB (YC12) : 35/40 ppm model 3. Check the connection of the DDR memory on the main PWB by reinstalling it or replacing it. 4. Execute U021 initialize memory. (see page P.6-25,P.6-221) 5. Replace the main PWB. (see page P.4-208,P.4-212) |
| F010 | Main PWB Checksum error | Main PWB | 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. If not corrected, replace the main PWB and check operation. (see page P.4-208,P.4-212) |

| Indication | Contents | Related parts | Check procedures/corrective measures |
|------------|---|------------------------|---|
| F020 | <p>Main PWB memory error</p> <p>In case an error occurs at the start-up DIMM read/write check.</p> | Main PWB | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. If not corrected, replace the main PWB and check operation. (see page P.4-208,P.4-212) |
| F040 | <p>Communication error between controller - Print engine</p> | Main PWB Engine PWB | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Repair or replace the wire from the main PWB that may be grounded. (Check for a short-circuit between 5V and 3.3V.) 3. Check the connector of the FFC connecting the main PWB to the engine PWB and reconnect it. Or replace the FFC. 4. Check both the main and engine firmware, and upgrade to the latest version, if necessary. 5. Replace the main PWB. (see page P.4-208,P.4-212) 6. Replace the engine PWB. (see page P.4-200,P.4-204) |
| F050 | <p>Print engine main program error</p> | Engine PWB | <ol style="list-style-type: none"> 1. Unplug the power cord from the wall outlet, and wait five seconds. Then plug in the power cord and then turn on the power switch. 2. Confirm that the EEPROM has been properly installed. 3. Check both the main and engine firmware, and upgrade to the latest version, if necessary. 4. If not corrected, replace the engine PWB. (see page P.4-200,P.4-204) |

(3) System Error (Fxxxx) Outline

The document is described for the outline of the factors of the Fxxx errors that are not described in the self-diagnosis error code list.

Please utilize it as the measures when the system is not recovered after power off/on or it frequently occurs.

*: Please initially check the following when the error (Fxxx) is indicated.

- Check the DIMM (DDR memory) and neighboring parts: Check the contact on the control PWB by releasing and reinserting the DIMM.

If the error repeats after that, replace the DIMM.

*: Power is partially supplied to this machine when the power is turned off.

Unplug the power plug and check if the F-code error is not released when passing one minute or more after turning the power off and then on.

| No. | Content | Check procedure & check point | Remark (Common) | 30 ppm model | 35/40 ppm models |
|------|--|--|--|---|--|
| - | <p>Lock-up at Welcome display (TASKalfa/Eco-sys) (The display unchanges after a certain time (Note))</p> <p>(Note) 30 ppm model: 70 s 35/40 ppm models: 60 s</p> | <ol style="list-style-type: none"> 1. Check connection of the harness (Panel to Main PWB), (Main PWB to HDD) and connectors and check function. 2. Check contact of the DDR memory by detaching and reattaching. and check function. replace it if available and check function. 3. Format the HDD and check function. (U024 FULL formatting) * 4. Execute the U021Memory initializing to initialize the controller backup memory and check function. 5. Replace the Operation panel PWB and check function. 6. Replace the Main PWB and check function. 7. Retrieve the USBLOG and contact the Service Administrative Division. <p>*: HDD standard model only</p> | <p>*User data and installed software is deleted if executing the U024. Reinstallation is required.</p> | <p>[Main - Panel Interface] Main PWB: YC2011 Operation panel PWB: YC4</p> | <p>[Main - Panel Interface] Main PWB: YC6,YC12,YS1,YS3 Operation panel PWB: YC9,YC12</p> |
| F000 | <p>F000 appears in a certain time (Note) after the Welcome display continues</p> <p>Operation panel- Main PWB communication error panel core- Main core communication error *2</p> <p>(Note) 30 ppm model: 70 s 35/40 ppm models: 60 s</p> | <ol style="list-style-type: none"> 1. Check connection of the harness (Panel to Main PWB), (Main PWB to HDD) and connectors and check function. 2. Check contact of the DDR memory by detaching and reattaching. and check function. replace it if available and check function. 3. Format the HDD and check function. (U024 FULL formatting) * 4. Execute the U021Memory initializing to initialize the controller backup memory and check function. 5. Replace the Main PWB and check function. 6. Replace the Operation panel PWB and check function. 7. Retrieve the USBLOG and contact the Service Administrative Division. <p>*: HDD standard model only *2: Dual Core CPU model only</p> | | <p>[Main - Engine Interface] Main PWB: YC6004 Engine PWB: YC3</p> | <p>[Main - Engine Interface] Main PWB: YC43 Engine PWB: YC3</p> |
| F12X | <p>An error is detected at scan control section</p> | <ol style="list-style-type: none"> 1. Check connection of the harness (Scan/DP - Main PWB) and connectors and check function. 2. Format the HDD and check function. (U024 FULL formatting) * 3. Execute the U021Memory initializing to initialize the controller backup memory and check function. 4. Replace the Scan/DP board and check function. 5. Replace the Main PWB and check function. 6. Retrieve the USBLOG and contact the Service Administrative Division. <p>*: HDD standard model only</p> | | <p>[DP - Engine Interface] Engine PWB: YC20 DP relay connector</p> | <p>[DP - Engine Interface] Engine PWB: YC6,YC7,YC38 DP relay connector</p> |

| No. | Content | Check procedure & check point | Remark (Common) | 30 ppm model | 35/40 ppm models |
|------|---|---|---|--|---|
| F13X | An error is detected at panel control section | <ol style="list-style-type: none"> 1. Check connection of the harness (Panel - Main PWB) and connectors and check function. 2. Format the HDD and check function. (U024 FULL formatting) * 3. Execute the U021Memory initializing to initialize the controller backup memory and check function. 4. Replace the Operetion panel PWB and check function. 5. Replace the Main PWB and check function. 6. Retrieve the USBLOG and contact the Service Administrative Division. <p>*: HDD standard model only</p> | | [Main - Panel Interface] Main PWB: YC2011 Operetion panel PWB: YC4 | [Main - Panel Interface] Main PWB: YC6,YC12,YS1,YS3 Operetion panel PWB: YC9,YC12 |
| F14X | An error is detected at the FAX control section | <ol style="list-style-type: none"> 1. Check connection of the harness (FAX - Main PWB) and connectors and check function. 2. Format the HDD and check function. (U024 FULL formatting) * 3. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4. Execute the U671 Clear FAX back up data (FAX DIMM clear) and check function. *2 (Take cae of the received data since it is cleared) 5. Replace the FAX_DIMM and check function. *2 6. Replace the FAX board and check function. 7. Replace the Main PWB and check function. 8. Retrieve the USBLOG and contact the Service Administrative Division. <p>*: HDD standard model only *2: Models with the flash memory for FAX data only</p> | | [Main - KUIO Interface] Main PWB: YC6001?YC6002 KUIO PWB: YC3?YC4 | [Main - KUIO Interface] Main PWB: YC8?YC9 KUIO PWB: YC3?YC4 |
| F15X | An error is detected at the authentication device control section | <ol style="list-style-type: none"> 1. Check connection of the harness (Authentication device - Main PWB) and connectors and check function. 2. Format the HDD and check function. (U024 FULL formatting) * 3. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4. Replace the Main PWB and check function. 5. Replace the HDD and check function. * 6. Retrieve the USBLOG and contact the Service Administrative Division. <p>*: HDD standard model only</p> | Authentication device: Card Reader, etc | [USB Cable] Main PWB: YC2007 | [Main - USB HUB Interface] Main PWB: YC50?YC12 USB HUB PWB: YC??YC3?YC4?YC5 |
| F18X | An error is detected at the Video control section | <ol style="list-style-type: none"> 1. Check connection of the harness (Engine - Main PWB) and connectors and check function. 2. Format the HDD and check function. (U024 FULL formatting) * 3. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4. Replace the Engine PWB and check function. 5. Replace the Main PWB and check function. 6. Retrieve the USBLOG and contact the Service Administrative Division. <p>*: HDD standard model only</p> | | [Main - Engine Interface] Main PWB: YC6004 Engine PWB: YC3 | [Main - Engine Interface] Main PWB: YC43 Engine PWB: YC3 |

| No. | Content | Check procedure & check point | Remark (Common) | 30 ppm model | 35/40 ppm models |
|--------------------------------------|---|---|---|--------------|--|
| F1DX | An error is detected at the Image memory management section | <ol style="list-style-type: none"> 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Replace the HDD and check function. * 5. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only | *The F1D4 error is RAM allocation error. <ol style="list-style-type: none"> 1. Check it with the U340 2. Initialize the setting valued with the U021 | - | - |
| F21X F22X F23X | An error is detected at the Image processing section | <ol style="list-style-type: none"> 1. Check contact of the DDR memory and check function. 2. Format the HDD and check function. (U024 FULL formatting) * 3. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4. Replace the Main PWB and check function. 5. Replace the HDD and check function. * 6. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only | | - | [Main - DP Relay Interface]? Main PWB: YC10 DP relay PWB: YC25 (CIS DP only) |
| F24X | An error is detected at the System management section | <ol style="list-style-type: none"> 1. Check contact of the DDR memory and check function. 2. Format the HDD and check function. (U024 FULL formatting) * 3. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4. Replace the Main PWB and check function. 5. Replace the HDD and check function. * 6. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only | *The F248 error is printer process error. if it repeats with a certain print data, retrieve the capture data and USBLOG. | - | [DDR2 memory contact check] Main PWB: YS1 or YS2 A certain part of the memory be faulty. The frequency of failure occurrence is dependent on the frequency of access to the faulty bit. The ASIC may be faulty if the memory is not sensitive. |
| F25X | An error is detected at the Network management section | <ol style="list-style-type: none"> 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Retrieve the USBLOG and the packet capture data and contact the Service Administrative Division. *: HDD standard model only | *This may be owing to the users network environment. | - | - |
| F26X F27X F28X F29X F2AX | An error is detected at the System management section | <ol style="list-style-type: none"> 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Replace the HDD and check function. * 5. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only | | - | - |

| No. | Content | Check procedure & check point | Remark (Common) | 30 ppm model | 35/40 ppm models |
|--|--|--|-----------------|--|---|
| F2BX F2CX F2DX F2EX F2FX F30X F31X F32X | An error is detected at the Network control section | <ol style="list-style-type: none"> 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Retrieve the USBLOG and the packet capture data and contact the Service Administrative Division. *: HDD standard model only | | - | - |
| F33X | An error is detected at the Scan management section | <ol style="list-style-type: none"> 1. Check connection of the harness (Scan/DP board - Main PWB) and connectors and check function. 2. Format the HDD and check function. (U024 FULL formatting) * 3. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4. Replace the Scan/DP board and check function. 5. Replace the Main PWB and check function. 6. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only | | [DP - Engine Interface] Engine PWB: YC20 | [DP - Engine Interface] Engine PWB: YC6,YC7,YC38 |
| F34X | An error is detected at the Panel management section | <ol style="list-style-type: none"> 1. Check connection of the harness (Operation panel PWB - Main PWB) and connectors and check function. *2 2. Format the HDD and check function. (U024 FULL formatting) * 3. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4. Replace the Operation panel PWB and check function. *2 5. Replace the Main PWB and check function. 6. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only *2: Dual Core CPU model and HyPAS model | | [Main - Panel Interface] Main PWB: YC2011 Operation panel PWB: YC4 | [Main - Panel Interface] Main PWB: YC6,YC12,YS1,YS3 Operation panel PWB: YC9,YC12 |
| F35X | An error is detected at the Print control section | <ol style="list-style-type: none"> 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Replace the HDD and check function. * 5. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only | | - | - |

| No. | Content | Check procedure & check point | Remark (Common) | 30 ppm model | 35/40 ppm models |
|------|--|---|--|--|---|
| F37X | An error is detected at the FAX management section | <ol style="list-style-type: none"> 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. 3) Execute the U671 Clear FAX back up data (FAX DIMM clear) and check function. (Take cae of the received data since it is cleared) 4. Replace the FAX_DIMM and check function. *2 5. Replace the Main PWB and check function. 6. Replace the HDD and check function. * 7. Retrieve the USBLOG and contact the Service Administrative Division. <p>*: HDD standard model only *2: Models with the flash memory for FAX data only</p> | | [Check the FAX DIMM contact] FAX DIMM: No | [Check the FAX DIMM contact] Main PWB: YS5 |
| F38X | An error is detected at the Authentication/permit management section | <ol style="list-style-type: none"> 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Replace the HDD and check function. * 5. Retrieve the USBLOG and contact the Service Administrative Division. <p>*: HDD standard model only</p> | | - | - |
| F39X | An error is detected at the KMAS management section | <ol style="list-style-type: none"> 1. Check connection of the harness (KMAS - Main PWB) and connectors and check function. 2. Format the HDD and check function. (U024 FULL formatting) * 3. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4. Replace the Main PWB and check function. 5. Replace the HDD and check function. * 6. Retrieve the USBLOG and contact the Service Administrative Division. <p>*: HDD standard model only</p> | | - | - |
| F3AX | An error is detected at the Entity control section | <ol style="list-style-type: none"> 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Replace the HDD and check function. * 5. Retrieve the USBLOG and contact the Service Administrative Division. <p>*: HDD standard model only</p> | | - | - |
| F3BX | | | | | |
| F3CX | | | | | |
| F3DX | | | | | |
| F3EX | | | | | |
| F3FX | | | | | |
| F40X | | | | | |
| F41X | | | | | |
| F42X | An error is detected at the Print image process section | <ol style="list-style-type: none"> 1. Replace the Main PWB and check function. 2. Retrieve the USBLOG (or retrieve the print capture data by case) | *The F46F error is printer process error. if it repeats with a certain print data, retrieve the capture data and USBLOG. | - | - |
| F43X | | | | | |
| F44X | | | | | |
| F45X | | | | | |
| F46X | | | | | |

| No. | Content | Check procedure & check point | Remark (Common) | 30 ppm model | 35/40 ppm models |
|------|--|--|---|--------------|------------------|
| F47X | An error is detected at the Image edit process control section | 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Replace the HDD and check function. * 5. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only | | - | - |
| F48X | | | | | |
| F49X | | | | | |
| F4AX | An error is detected at the Print image process section | 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Replace the HDD and check function. * 5. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only | | - | - |
| F4CX | | | | | |
| F4DX | An error is detected at the Entity control section | 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Replace the HDD and check function. * 5. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only | | - | - |
| F4EX | | | | | |
| F50X | An error is detected at the FAX control section | 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Replace the HDD and check function. * 5. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only | The USB log is necessary for analysis. Please cooperate in retrieving it. | - | - |
| F51X | An error is detected at the Job control section | 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Replace the HDD and check function. * 5. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only | The USB log is necessary for analysis. Please cooperate in retrieving it. | - | - |
| F52X | | | | | |
| F53X | | | | | |
| F55X | | | | | |
| F56X | | | | | |
| F57X | | | | | |
| F58X | An error is detected at the Device control section | 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Replace the HDD and check function. * 5. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only | The USB log is necessary for analysis. Please cooperate in retrieving it. | - | - |
| F59X | | | | | |
| F5AX | | | | | |
| F5BX | | | | | |
| F5CX | | | | | |
| F5DX | | | | | |
| F5EX | | | | | |

| No. | Content | Check procedure & check point | Remark (Common) | 30 ppm model | 35/40 ppm models |
|------|--|---|---|--------------|------------------|
| F62X | Abnormality detected at service section | <ol style="list-style-type: none"> 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Replace the HDD and check function. * 5. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only | The USB log is necessary for analysis. Please cooperate in retrieving it. | - | - |
| F68X | An error is detected at the Storage device control section | <ol style="list-style-type: none"> 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Replace the HDD and check function. * 5. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only | *F684 is Overwrite error with the HDD security kit | - | - |
| F69X | An error is detected at the HyPAS section | <ol style="list-style-type: none"> 1. Format the HDD and check function. (U024 FULL formatting) * 2. Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3. Replace the Main PWB and check function. 4. Replace the HDD and check function. * 5. Retrieve the USBLOG and contact the Service Administrative Division. *: HDD standard model only | | - | - |
| F6AX | | | | | |
| F6BX | | | | | |
| F6CX | | | | | |

7-3 Image formation problems

Isolate the place of the image failure occurrence.

<How to isolate the cause>

Print Test Page to check an image failure.

[System Menu] > [Adjustment/Maintenance] > [Service Setting]

Yes: engine factor

No: Scanner factor

Check if image failure is enlarged or reduced in the zoom mode.

Yes: Scanner factor

1. Scanner factor: Refer to [Image failure at Copy or Send](See page 7-107).
(LED lamp for originals on the contact glass --> CCD failure at scanning factor)


Isolate with the original scanning position.

- a. DP simplex (Main unit CCD scan)
- b. On the contact glass (scan by the main unit CCD)


2. Refer to image failure with engine factor (See page 7-134).
(Main charge --> Drum --> LSU --> Developer --> Primary transfer image formation process failure)

<Image data flow>


Copying :




Sending :



Printing data from PC :



(1) Poor image (due to DP and scanner reading)



(1-1)No image appears (entirely white)



(1-2)No image appears (entirely black)




(1-3)The entire image is faint




(1-4)The background is colored



(1-5)Vertical white streaks or bands appear



(1-6)Black or color streaks appear longitudinally



(1-7)Horizontal black streaks appear




(1-8)The image is partly dark or bright



(1-9)Black or color dots appear in the image



(1-10)Characters are blurred



(1-11)The leading edge of the image is consistently misaligned with the original




(1-12)The image is partly missing



(1-13)The image is blurred




(1-14)Image center does not align with the original center




(1-15)Moiré



(1-16)Skewed image



(1-17)Abnormal image

(1-1) No image appears (entirely white)


1. Table scanning

| | Trouble location | Check | Corrective action |
|---|--------------------------------|--|--|
| 1 | Contact glass assy | Check the position where the contact glass is attached. | If the contact glass is dislocated, reattach it. |
| 2 | FFC cable CCD | Check the FFC cable connection between the CCD PWB and the main PWB (30ppm model) / the engine PWB (35/40ppm models). Or, check the wire's continuity. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 3 | Home position sensor | Check the location where the home position sensor is attached. | If the home position sensor is out of position, reattach it. |
| 4 | Scanner drive belt | Check that the scanner drive belt is loosely attached. | If the scanner drive belt is attached loosely, secure the screw again. |
| 5 | Scanner drive gear | Check that the scanner drive gear is loosely attached. | If the scanner drive gear is attached loosely, secure the screw again. |
| 6 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 7 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 8 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

2. DP scanning

| | Trouble location | Check | Corrective action |
|---|--------------------|---|--|
| 1 | Original | Check the side of set original document. | Set the original again if the set side of it is incorrect. |
| 2 | Contact glass assy | Check the position where the contact glass is attached. | If the contact glass is dislocated, reattach it. |

| | Trouble location | Check | Corrective action |
|---|--------------------------------|---|--|
| 3 | FFC cable CCD | Check the FFC cable connection between the CCD PWB and the main PWB (30ppm model) /the engine PWB (35/40ppm models). Or, check the wire's continuity. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 4 | Home position sensor | Check the location where the home position sensor is attached. | If the home position sensor is out of position, reattach it. |
| 5 | Scanner drive belt | Check that the scanner drive belt is loosely attached. | If the scanner drive belt is attached loosely, secure the screw again. |
| 6 | Scanner drive gear | Check that the scanner drive gear is loosely attached. | If the scanner drive gear is attached loosely, secure the screw again. |
| 7 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 6-341) |
| 8 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 9 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |


(1-2) No image appears (entirely black)

1. Table scanning

| | Trouble location | Check | Corrective action |
|---|--------------------------------|---|--|
| 1 | FFC cable CCD | Check the FFC cable connection between the CCD PWB and the main PWB (30ppm model) /the engine PWB (35/40ppm models). Or, check the wire's continuity. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 2 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 3 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 4 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

2. DP scanning

| | Trouble location | Check | Corrective action |
|---|--------------------------------|---|--|
| 1 | DP scanning position | Check the value using maintenance mode U068 [DPRead]. | If a large value is observed in maintenance mode U068 [DPRead], adjust it. (See page 6-43,6-242) |
| 2 | FFC cable CCD | Check the FFC cable connection between the CCD PWB and the main PWB (30ppm model) /the engine PWB (35/40ppm models). Or, check the wire's continuity. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 3 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 6-341) |
| 4 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 5 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |


(1-3) The entire image is faint

1. Table scanning

| | Trouble location | Check | Corrective action |
|----|--------------------------------|---|--|
| 1 | Density adjustment | Check the setting of the density adjustment. | Deactivate EcoPrint if it is activated. Or, if the density is too low, choose an image quality that suits the original document type. Increase density. Perform the background color adjustment using the system menu. |
| 2 | Bleed-through prevention | Check the setting of bleedthrough prevention. | Turn the bleed-through prevention off if it is turned on. |
| 3 | Scanner adjustment | Check the scanner automatic adjustment. | Execute maintenance mode U411 [table] to adjust automatically. (See page 6-117,6-341) |
| 4 | Contact glass | Check if the contact glass is dirty. | If the contact glass is dirty, clean it and the shading plate at the backside of it. |
| 5 | Home position sensor | Check the location where the home position sensor is attached. | If the home position sensor is out of position, reattach it. |
| 6 | FFC cable CCD | Check the FFC cable connection between the CCD PWB and the main PWB (30ppm model) /the engine PWB (35/40ppm models). Or, check the wire's continuity. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 7 | Scanner carriage | Check the location where the scanner carriage is attached. | If the scanner carriage is out of position, reattach it. |
| 8 | LED PWB | Check if the LED is lit. | If the LED is not lit, replace the scanner carriage and execute U411. (See page 4-96) |
| 9 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 10 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 11 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

2. DP scanning

| | Trouble location | Check | Corrective action |
|----|--------------------------------|---|--|
| 1 | Density adjustment | Check the setting of the density adjustment. | Deactivate EcoPrint if it is activated. Or, if the density is too low, choose an image quality that suits the original document type. Increase density. Perform the background color adjustment using the system menu. |
| 2 | Bleed-through prevention | Check the setting of bleedthrough prevention. | Turn the bleed-through prevention off if it is turned on. |
| 3 | Scanner adjustment | Check the scanner automatic adjustment. | Execute maintenance mode U411 [DP] to adjust automatically. (See page 6-117,6-341) |
| 4 | Contact glass | Check if the contact glass is dirty. | If the contact glass is dirty, clean it and the shading plate at the backside of it. |
| 5 | Home position sensor | Check the location where the home position sensor is attached. | If the home position sensor is out of position, reattach it. |
| 6 | DP scanning position | Check if the DP scanning position is shifted. | If the DP scanning position is shifted, adjust it using the maintenance mode U068 [DPRead]. (See page 6-43,6-242) |
| 7 | FFC cable CCD | Check the FFC cable connection between the CCD PWB and the main PWB (30ppm model) /the engine PWB (35/40ppm models). Or, check the wire's continuity. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 8 | Scanner carriage | Check the location where the scanner carriage is attached. | If the scanner carriage is out of position, reattach it. |
| 9 | LED PWB | Check if the LED is lit. | If the LED is not lit, replace the scanner carriage and execute U411. (See page 4-96) |
| 10 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 11 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 12 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |


(1-4) The background is colored

1. Table scanning

| | Trouble location | Check | Corrective action |
|----|--------------------------------|---|---|
| 1 | Original | 1. Check if the background density of the original document is too dense. 2. Check if the original document is floated during scanning. | 1. If the background density of the original document is too dense, perform automatic background adjustment. Or, adjust density with background adjustment. 2. If the original document is floated during scanning, press down it. |
| 2 | Scanner adjustment. | Check the scanner automatic adjustment. | Execute maintenance mode U411 [Table]. (See page 6-117,6-341) |
| 3 | Contact glass | Check if the contact glass is dirty. | If the contact glass is dirty, clean it and the shading plate at the backside of it. |
| 4 | Contact glass assy | Check the position where the contact glass is attached. | If the contact glass is dislocated, reattach it. |
| 5 | Home position sensor | Check the position where the home position sensor is attached. | If the home position sensor is out of position, reattach it. |
| 6 | FFC cable CCD | Check the FFC cable connection between the CCD PWB and the main PWB (30ppm model) /the engine PWB (35/40ppm models). Or check continuity of the wire. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 7 | Scanner carriage | Check the location where the scanner carriage is attached. | If the scanner carriage is out of position, reattach it. |
| 8 | LED PWB | Check if the LED is lit. | If the LED is not lit, replace the scanner4-96 carriage and execute U411. (See page 4-96) |
| 9 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 10 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 11 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

2. DP scanning

| | Trouble location | Check | Corrective action |
|----|--------------------------------|---|---|
| 1 | Original | 1. Check if the background density of the original document is too dense. 2. Check if the original document is floated during scanning. | 1. If the background density of the original document is too dense, perform automatic background adjustment. Or, adjust density with background adjustment. 2. If the original document is floated during scanning, press down it. |
| 2 | Scanner adjustment | Check the scanner automatic adjustment. | Execute maintenance mode U411 [DP]. (See page 6-117,6-341) |
| 3 | Contact glass | Check if the contact glass is dirty. | If the contact glass is dirty, clean it and the shading plate at the backside of it. (See page 4-94) |
| 4 | Contact glass assy | Check the position where the contact glass is attached. | If the contact glass is dislocated, reattach it. |
| 5 | Home position sensor | Check the position where the home position sensor is attached. | If the home position sensor is out of position, reattach it. |
| 6 | DP installing | Check if the DP frame is deformed or the hinge is broken. | Replace the DP if broken. |
| 7 | FFC cable CCD | Check the FFC cable connection between the CCD PWB and the main PWB (30ppm model) /the engine PWB (35/40ppm models). Or check continuity of the wire. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 8 | Scanner carriage | Check the location where the scanner carriage is attached. | If the scanner carriage is out of position, reattach it. |
| 9 | LED PWB | Check if the LED is lit. | If the LED is not lit, replace the scanner carriage and execute U411. (See page 4-96) |
| 10 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 11 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 12 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |


(1-5) Vertical white streaks or bands appear

1. Table scanning

| | Trouble location | Check | Corrective action |
|---|--------------------------------|---|---|
| 1 | Original | Check if the original document is dirty. | Replace the original document if it is dirty. |
| 2 | Contact glass Shading plate | Check if the contact glass and shading plate are dirty. | If the contact glass is dirty, clean it and the shading plate at the backside of it. (See page 4-94) |
| 3 | Scanner carriage | Check if dust or dirt adheres the scanner carriage. | If dust or dirt adheres to the scanner carriage, remove it from the optical path. |
| 4 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 5 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 6 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

2. DP scanning

| | Trouble location | Check | Corrective action |
|---|--------------------------------|--|---|
| 1 | Original | Check if the original document is dirty. | Replace the original document if it is dirty. |
| 2 | Slit glass Shading plate | Check if the slit glass and the shading plate are dirty. | If the slit glass and the shading plate are dirty, clean them. |
| 3 | Scanner carriage | Check if dust or dirt adheres the scanner carriage. | If dust or dirt adheres to the scanner carriage, remove it from the optical path. |
| 4 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 5 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 6 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |


(1-6) Black or color streaks appear longitudinally

1. Table scanning

| | Trouble location | Check | Corrective action |
|----|--------------------------------|---|--|
| 1 | Original | Check if the original document is dirty. | Replace the original document if it is dirty. |
| 2 | Original | Check if the original document size and its detected size match. | In case the original document size and its detected original document size are different, set the correct original document size or activate border erase. |
| 3 | Contact glass Shading plate | Check if the contact glass and shading plate are dirty. | If the contact glass is dirty, clean it and the shading plate at the backside of it. (See page 4-94) |
| 4 | Contact glass assy | Check the position where the contact glass is attached. | If the contact glass is dislocated, reattach it. |
| 5 | Scanner carriage | Check if dust or dirt adheres the scanner carriage. | If dust or dirt adheres to the scanner carriage, remove it from the optical path. |
| 6 | Scanner adjustment | Check if there are streaks or bands outside the original document . | 1. Execute maintenance mode U067 [Front] to adjust. (See page 6-42,6-241) 2. Execute maintenance mode U411 [Table] to adjust automatically (Adjusting the half-tone automatically). (See page 6-117,6-341) |
| 7 | CCD PWB | Check if dust adheres to the CCD PWB glass surface. | If dust adheres to the CCD PWB glass surface, clean it with air blower brush. |
| 8 | Mirror | Check if the mirror dropped off or it is dirty. | 1. Replace the scanner carriage and execute U411 if the mirror is dropped off due to drop shock. 2. If the mirror are dirty, clean them. |
| 9 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 10 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 11 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

2. DP scanning

| | Trouble location | Check | Corrective action |
|----|-------------------------------|---|--|
| 1 | Original | Check if the original document is dirty. | Replace the original document if it is dirty. |
| 2 | Original | Check if the original document size and its detected size match. | In case the original document size and its detected original document size are different, set the correct original document size or activate border erase. |
| 3 | DP scanning position | Check if the DP scanning position is shifted. | If the DP scanning position is shifted, adjust it using in the maintenance mode U068 [DPRead]. (See page 6-43,6-242) |
| 4 | Slit glass | Check if the slit glass is dirty. | If the slit glass is dirty, clean it. |
| 5 | Scanner carriage | Check if dust or dirt adheres the scanner carriage. | If dust or dirt adheres to the scanner carriage, remove it from the optical path. |
| 6 | CCD PWB | Check if dust adheres to the CCD PWB glass surface. | If dust adheres to the CCD PWB glass surface, clean it with air blower brush. |
| 7 | Scanner adjustment | Check if there are streaks or bands outside the original document . | 1. Execute maintenance mode U067 [Front] to adjust. (See page 6-42,6-241) 2. Execute maintenance mode U411 [Table] to adjust automatically (Adjusting the half-tone automatically). (See page 6-117,6-341) |
| 8 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 9 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 10 | Engine PWB 35/40 ppm model | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

(1-7) Horizontal black streaks appear


1. Table scanning

| | Trouble location | Check | Corrective action |
|---|--------------------------------|---|--|
| 1 | Original | Check if the original document is dirty. | Replace the original document if it is dirty. |
| 2 | Contact glass | Check if the contact glass is dirty. | If the contact glass is dirty, clean it and the shading plate at the backside of it. (See page 4-94) |
| 3 | Scanner adjustment | Check if the image at the backside of the size indication plate appears. | <ol style="list-style-type: none"> 1. If the image at the backside of the size indication plate appears, adjust it using the maintenance mode U066 [Front]. (See page 6-41,6-240) 2. Execute maintenance mode U411 [Table] to adjust and automatically. (See page 6-117,6-341) |
| 4 | FFC cable CCD | Check the FFC cable connection between the CCD PWB and the main PWB (30ppm model) /the engine PWB (35/40ppm models). Or check continuity of the wire. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 5 | LED PWB | Check if the LED is lit. | If the lamp is not lit, replace the scanner carriage and execute U411. (See page 4-96) |
| 6 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 7 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

2. DP scanning

| | Trouble location | Check | Corrective action |
|---|------------------|--|---|
| 1 | Original | Check if the original document is dirty. | Replace the original document if it is dirty. |
| 2 | Slit glass | Check if the slit glass is dirty. | If the slit glass is dirty, clean it. |

| | Trouble location | Check | Corrective action |
|---|--------------------------------|---|--|
| 3 | FFC cable CCD | Check the FFC cable connection between the CCD PWB and the main PWB (30ppm model) /the engine PWB (35/40ppm models). Or check continuity of the wire. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 4 | LED PWB | Check if the LED is lit. | If the lamp is not lit, replace the scanner carriage and execute U411. (See page 4-96) |
| 5 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 6 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

(1-8) The image is partly dark or bright


1. Table scanning

| | Trouble location | Check | Corrective action |
|---|--------------------------------|---|--|
| 1 | Original | Check if the original document is dirty. | Replace the original document if it is dirty. |
| 2 | Original | Check if the original document has folds or creases. | If the original document has folds or creases, straighten it. |
| 3 | Platen mat | Check if the DP or platen mat position is shifted. | If the DP or platen mat position is shifted, refit it. |
| 4 | Contact glass | Check if the contact glass is dirty. | If the contact glass is dirty, clean it and the shading plate at the backside of it. |
| 5 | Contact glass assy | Check the position where the contact glass is attached. | If the contact glass is dislocated, reattach it. |
| 6 | Scanner carriage | Check if dust or dirt adheres the scanner carriage. | If dust or dirt adheres to the scanner carriage, remove it from the optical path. |
| 7 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 8 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 9 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

2. DP scanning

| | Trouble location | Check | Corrective action |
|---|-------------------------|--|---|
| 1 | Original | Check if the original document is dirty. | Replace the original document if it is dirty. |
| 2 | Original | Check if the original document has folds or creases. | In case the original document has folds or creases, straighten it. |
| 3 | DP scanning guide | Check if the scanner guide moves smoothly. | Reattach the DP scanning guide if it does not move smoothly. |
| 4 | Slit glass | Check if the slit glass is dirty. | If the slit glass is dirty, clean it with the shading plate at the backside.(See page 4-94) |

| | Trouble location | Check | Corrective action |
|---|--------------------------------|---|---|
| 5 | Contact glass assy | Check the position where the contact glass is attached. | If the contact glass is dislocated, reattach it. |
| 6 | Scanner carriage | Check if dust or dirt adheres the scanner carriage. | If dust or dirt adheres to the scanner carriage, remove it from the optical path. |
| 7 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 8 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 9 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |


(1-9) Black or color dots appear in the image

1. Table scanning

| | Trouble location | Check | Corrective action |
|---|--------------------------------|---|--|
| 1 | Original | Check if the original document is dirty. | Replace the original document if it is dirty. |
| 2 | Contact glass | Check if the contact glass is dirty. | If the contact glass is dirty, clean it and the shading plate at the backside of it. |
| 3 | FFC cable CCD | Check the FFC cable connection between the CCD PWB and the main PWB (30ppm model) /the engine PWB (35/40ppm models). Or check continuity of the wire. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 4 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 5 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

2. DP scanning

| | Trouble location | Check | Corrective action |
|---|--------------------------------|---|--|
| 1 | Original | Check if the original document is dirty. | Replace the original document if it is dirty. |
| 2 | Slit glass | Check if the slit glass is dirty. | If the slit glass is dirty, clean it with the shading plate at the backside. |
| 3 | FFC cable CCD | Check the FFC cable connection between the CCD PWB and the main PWB (30ppm model) /the engine PWB (35/40ppm models). Or check continuity of the wire. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 4 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 5 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

(1-10) Characters are blurred


1. Table scanning

| | Trouble location | Check | Corrective action |
|---|-----------------------|--|--|
| 1 | Optical rail | Check if the scanner carriage moves smoothly. | If the scanner carriage does not move smoothly, remove foreign objects on the optical rails. |
| 2 | Scanner shaft | Check if the scanner carriage moves smoothly. | If the scanner carriage does not move smoothly, clean the scanner shaft. |
| 3 | Scanner carriage | Check if the scanner carriage moves smoothly. | If the scanner carriage contacts the frame while moving and does not move smoothly, reattach it. |
| 4 | Scanner drive section | Check if there is any foreign matter in between the scanner drive belt and the scanner drive gear. | Remove foreign objects if mixed up. |
| 5 | Scanner drive belt | Check if foreign objects adhere to the scanner drive belt or it is scratched. | If foreign objects adhere to the scanner drive belt, remove them. Or, replace it if scratched. |

2. DP scanning

| | Trouble location | Check | Corrective action |
|---|---------------------|--|---|
| 1 | DP conveying pulley | Check if the DP conveying pulley smoothly rotates. | Reassemble the conveying pulley and spring if the DP conveying pulley does not move smoothly. |
| 2 | DP installation | Check how DP is attached to the main unit. | If attachment to the main unit is faulty, reattach it after confirming the positioning. |
| 3 | Hinge | Check if the vertical motion of the DP hinge is smooth and it can continue opened. | Replace the hinges if the DP does not move smoothly or it cannot continue opened. |
| 4 | DP original mat | Check the position where the DP original mat position is attached. | If the original mat is out of position, reattach it. |
| 5 | Original | Check the leading edge of the original document is folded. | If the leading edge of the original document is folded, straighten it. |
| 6 | DP scanning guide | Check if the scanner guide is deformed. | Replace the scanner guide if deformed. |

| | Trouble location | Check | Corrective action |
|---|--|---|---|
| 7 | DP conveying roller (Before and after scanning) | Check if the DP conveying roller is contaminated. | Clean the DP conveying roller if contaminated. |
| 8 | Drive belt | Check the drive belt jumping. | If the drive belt jumps, readjust the belt tension. |


(1-11) The leading edge of the image is consistently misaligned with the original

1. Table scanning

| | Trouble location | Check | Corrective action |
|---|----------------------|--|---|
| 1 | Original | Check if the original document is set correctly. | If the original document is not set correctly, set it again. |
| 2 | Scanner carriage | Check the carriage fixing of the scanner drive belt. | Check if the scanner drive belt is securely set at the carriage fix part. |
| 3 | Scanner adjustment | Check the scanner position adjustment. | <ol style="list-style-type: none"> Execute maintenance mode U066 [Front] to adjust. (See page 6-41,6-240) Execute maintenance mode U411 [Table] to adjust automatically. (See page 6-117,6-341) |
| 4 | Home position sensor | Check the position where the home position sensor is attached. | If the home position sensor is out of position, reattach it. |
| 5 | Scanner drive belt | Check that the scanner drive belt is loosely attached. | If the scanner drive belt tension is loose, give it tension. |
| 6 | Scanner drive gear | Check that the scanner drive gear is loosely attached. | If the scanner drive gear is attached loosely, secure the screw again. |

2. DP scanning

| | Trouble location | Check | Corrective action |
|---|---------------------------|---|--|
| 1 | Scanner adjustment | Check the DP scanning position adjustment. | <ol style="list-style-type: none"> Execute maintenance mode U071 [CCD-Head] to adjust. (See page 6-45,6-244) Execute maintenance mode U411 [DP] to adjust automatically. (See page 6-115,6-339) |
| 2 | Original conveying roller | Check if the original document conveying roller is dirty or worn. | If the original document conveying roller is dirty, clean it and bushing. Replace the roller if it is worn. |
| 3 | DP drive motor | Check if the DP drive motor rotation is unstable. | Apply grease to the drive gear if the DP drive motor rotation is unstable. Replace the DP drive motor if no improvement is observed. |

(1-12) The image is partly missing


1. Table scanning

| | Trouble location | Check | Corrective action |
|---|--------------------------------|---|---|
| 1 | Original | Check if the original document is set correctly. | If the original document is not set correctly, set it again. |
| 2 | Original | Check if the original document size and paper size match in the operation panel indication. | If the original document size and paper size do not match in the operation panel indication, manually set the original document size. |
| 3 | Contact glass | Check if the contact glass is dirty. | If the contact glass is dirty, clean it and the shading plate at the backside of it. |
| 4 | Contact glass assy | Check the position where the contact glass is attached. | If the contact glass is dislocated, reattach it. |
| 5 | FFC cable CCD | Check the FFC cable connection between the CCD PWB and the main PWB (30ppm model) /the engine PWB (35/40ppm models). Or check continuity of the wire. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 6 | Scanner carriage | Check the location where the scanner carriage is attached. | If the scanner carriage is out of position, reattach it. |
| 7 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 8 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 9 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

2. DP scanning

| | Trouble location | Check | Corrective action |
|---|------------------|---|--|
| 1 | Original | Check if the original document is set correctly. | If the original document is not set correctly, set it again. |
| 2 | Original | Check if the original document size and paper size match in the operation panel indication. | If the original document size and paper size do not match in the operation panel indication, manually set the original document size |

| | Trouble location | Check | Corrective action |
|---|--------------------------------|---|--|
| 3 | Slit glass | Check if the slit glass is dirty. | If the slit glass is dirty, clean it. |
| 4 | FFC cable CCD | Check the FFC cable connection between the CCD sensor and main PWB (30ppm model) / Engine PWB (35/40ppm models). Or check continuity of the wire. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 5 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 6 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 7 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

(1-13) The image is blurred


1. Table scanning

| | Trouble location | Check | Corrective action |
|---|--------------------------------|--|--|
| 1 | Original | Check if the original document is wavy. | If the original document is wavy, straighten it to plain. Or, replace. |
| 2 | Contact glass | Check if the contact glass is condensed. | If the contact glass is condensed, remove it. |
| 3 | Scanner carriage | Check if the scanner carriage is condensed inside. | If the scanner carriage is condensed inside, remove it. |
| 4 | CCD PWB | Check if the CCD PWB glass surface has condensation. | If the CCD sensor glass surface has condensation, remove it. |
| 5 | Scanner adjustment | Check the scanner automatic adjustment. | Execute maintenance mode U411 [Table]. (See page 6-117,6-341) |
| 6 | Scanner carriage | Check the position of the lens and CCD PWB. | If the position of the lens and CCD PWB is shifted, replace the scanner carriage and execute U411. (See page 4-96) |
| 7 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 8 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

2. DP scanning

| | Trouble location | Check | Corrective action |
|---|------------------|--|---|
| 1 | Original | Check if the original document is wavy. | In case the original document is wavy, straighten it to plain. Or, replace. |
| 2 | Slit glass | Check if the slit glass is condensed. | If the slit glass is condensed, remove it. |
| 3 | Scanner carriage | Check if the scanner carriage is condensed inside. | If condensed, remove it. |
| 4 | CCD PWB | Check if the CCD PWB glass surface is condensed. | If the CCD PWB glass surface has condensation, remove it. |

| | Trouble location | Check | Corrective action |
|---|--------------------------------|---|--|
| 5 | Scanner adjustment | Check the scanner automatic adjustment. | Execute maintenance mode U411 [Table]. (See page 6-117,6-341) |
| 6 | Scanner carriage | Check the position of the lens and CCD PWB. | If the position of the lens and CCD PWB is shifted, replace the scanner carriage and execute U411. (See page 4-96) |
| 7 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 8 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |


(1-14) Image center does not align with the original center

1. Table scanning

| | Trouble location | Check | Corrective action |
|---|--------------------|---|---|
| 1 | Original | Check if the original document is set correctly. | If the original document is not set correctly, set it again. |
| 2 | Contact glass assy | Check the position where the contact glass is attached. | If the contact glass is dislocated, reattach it. |
| 3 | Scanner adjustment | Check the scanner position. | <ol style="list-style-type: none"> Execute maintenance mode U067 [Front] to adjust. (See page 6-42,6-241) Execute maintenance mode U411 [Table] to adjust automatically. (See page 6-117,6-341) |

2. DP scanning

| | Trouble location | Check | Corrective action |
|---|--------------------|--|--|
| 1 | Original | Check if the original document is set correctly. | If the original document is not set correctly, set it again. |
| 2 | Scanner adjustment | Check the DP scanning position adjustment. | <ol style="list-style-type: none"> Execute maintenance mode U072 [Front] to adjust. (See page 6-47,6-246) Execute maintenance mode U411 [DP] to adjust automatically. (See page 6-117,6-341) |


(1-15) Moire

1. Table scanning

| | Trouble location | Check | Corrective action |
|---|-----------------------|--|---|
| 1 | Print quality mode | Check if the moire changes depending on the print quality mode. | If the moire changes depending on the print quality mode, change it. 1. Print in Text mode or Printer mode. 2. Weaken (reduce) the sharpness. |
| 2 | Original | Check if moire is generated depending on original document scanning direction. | If moire is generated, rotate the original document set direction 90 degrees. |
| 3 | Magnification setting | Check if it occurs in 100% magnification. | Slightly reduce the magnification in main scanning direction using maintenance mode U065. (See page 6-39,6-238) |
| 4 | Scanner adjustment | Check if the scanner automatically adjustment has been executed. | Execute maintenance mode U411 [Table]. (See page 6-117,6-341) |

2. DP scanning

| | Trouble location | Check | Corrective action |
|---|--------------------|--|---|
| 1 | Print quality mode | Check if the moire changes depending on the print quality mode. | If the moire changes depending on the print quality mode, change it. 1. Print in Text mode or Printer mode. 2. Weaken (reduce) the sharpness. |
| 2 | Scanner adjustment | Check if the scanner automatically adjustment has been executed. | Execute maintenance mode U411 [DP]. (See page 6-117,6-341) |


(1-16) Skewed image

1. Table scanning

| | Trouble location | Check | Corrective action |
|---|----------------------------------|---|--|
| 1 | Original | Check if the original document is placed askew. | If the original document is placed askew, place it correctly. |
| 2 | Main unit and scanner unit level | Check if the scanner height position is distorted or shifted. | If the scanner height position is distorted or shifted, adjust the entire scanner unit height. |
| 3 | Scanner carriage | Check the location where the scanner carriage is attached. | If the scanner carriage is out of position, reattach it. |

2. DP scanning

| | Trouble location | Check | Corrective action |
|---|------------------------|--|---|
| 1 | Original | Check if the original document has folds or creases. | In case the original document has folds or creases, straighten it. |
| 2 | DP document feeding | Check if the original document is fed askew. | If the original document is skew fed, set the original document side registration guide again. |
| 3 | Scanner carriage | Check the location where the scanner carriage is attached. | If the scanner carriage is out of position, reattach it. |
| 4 | Original feed roller | Check if the original document feed roller is dirty. | Clean the original document feed roller if it is dirty. Replace it if it is not improved after cleaning it. |
| 5 | DP registration roller | Check if the DP registration roller is dirty and its rotation. | Clean the DP registration roller. If the rotation is not smooth, clean the busing and reattach it. |
| 6 | Original set | Check if cursors are aligned to original documents. | Align the cursor to fit the original document, if necessary. |

(1-17) Abnormal image


1. Table scanning

| | Trouble location | Check | Corrective action |
|---|--------------------------------|---|--|
| 1 | FFC cable CCD | Check the FFC cable connection between the CCD PWB and the main PWB (30ppm model) /the engine PWB (35/40ppm models). Or check continuity of the wire. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 2 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 3 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 4 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

2. DP scanning

| | Trouble location | Check | Corrective action |
|---|--------------------------------|---|--|
| 1 | FFC cable CCD | Check the FFC cable connection between the CCD PWB and the main PWB (30ppm model) /the engine PWB (35/40ppm models). Or check continuity of the wire. | If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. |
| 2 | CCD PWB | CCD PWB is defective. | Replace the scanner carriage and execute the U411. (See page 4-96) |
| 3 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 4 | Engine PWB 35/40 ppm models | Engine PWB is defective. | Replace the engine PWB. (See page 4-204) |

(2) Poor image (Image forming factor: printer engine for single color)



(2-1)No image appears (entirely white)



(2-2)No image appears (entirely black)




(2-3)The entire image is faint



(2-4)The background is colored



(2-5)Vertical white streaks or bands appear



(2-6)Black or color streaks appear longitudinally



(2-7)White, black or color streaks or bands appear horizontally



(2-8)Uneven density vertically



(2-9)Uneven density horizontally



(2-10)Black or color dots appear in the image




(2-11)Offset occurs



(2-12)The image is partly missing



(2-13)The image is blurred




(2-14)Poor grayscale reproduction




(2-15)Irregular horizontal white streaks appear in the image / Dots appear in the image





(2-16) Granular image (low solid image density)


(2-1) No image appears (entirely white)

| Image sample | Factor |
|---|--|
|  | <ol style="list-style-type: none"> 1. Developer bias is not output or not impressed. (Contact failure) 2. The developer lock shaft is not inserted. (The DS gap is wide) 3. Developer roller rotation failure. 4. Defective primary transfer. 5. Laser is not output from the laser scanner unit (LSU). 6. Drum does not rotate. |

| | Trouble location | Check | Corrective action |
|---|-------------------------------|--|---|
| 1 | Developer unit | Select [Color Belt] from U089 and print 4-color bands PG to check the following with the color which is defective. (See page 6-48,6-249) | |
| | | Check insertion of the lock shaft. | If the lock shaft is not inserted properly, insert it securely. |
| | | Check if the developer drive gear is broken. | Replace the developer unit if broken. |
| | | Check if the developer roller can be rotated manually. | Replace the developer unit if it has a problem. (See page 4-38) |
| | | Check dirt and deformation of the developer unit and high voltage PWB contact terminal. | Clean the terminal if it is dirty. Correct the terminal if it is deformed so that it contacts. |
| 2 | Main drive motor unit (C,M,Y) | Check if the gear and coupling in the drive unit that drive the developer unit are damaged. | Replace the main drive unit if broken. |
| 3 | Developer clutch (BK) | Check if the developer clutch in the conveying drive unit is connected. | Replace the conveying drive unit if broken. |
| 4 | High voltage PWB | <ol style="list-style-type: none"> 1. Check that the terminals on the high voltage PWB surely contact with the developer roller and primary transfer roller. 2. Check the connection between the high voltage PWB and connector. Or, | <ol style="list-style-type: none"> 1. Clean the terminal if it is dirty. 2. Correct the terminal if it is deformed so that it contacts. 3. If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. High voltage PWB to Engine PWB |
| | | The high voltage PWB (developer, transfer) output failure. | Replace the high voltage PWB. (See page 4-217,4-221) |


| | Trouble location | Check | Corrective action |
|---|---|--|--|
| 5 | Transfer high voltage PWB *40 ppm model only | <ol style="list-style-type: none"> 1. Check that the terminal on the high voltage PWB 2 surely contacts with the primary transfer roller. 2. Check the connection between the high voltage PWB and connector. Or, check the wire's continuity. | <ol style="list-style-type: none"> 1. Clean the terminal if it is dirty. 2. Correct the terminal if it is deformed so that it contacts. 3. If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. Transfer high voltage PWB to Engine PWB |
| | | Transfer current output failure on the transfer high-voltage PWB. | Replace the transfer high voltage PWB. |
| 6 | Laser scanner unit (LSU) | Check the connector connection. Or check the wire's continuity. | <ol style="list-style-type: none"> 1. Reinsert the FFC cable if it is incompletely inserted. Replace the wire if there is no continuity. 2. Replace the LSU. (See page 4-76) |
| 7 | Main PWB 30 ppm model | Check if the main PWB control signal is output. | Replace the main PWB. (See page 4-208) |
| 8 | Engine PWB | Check if the engine PWB control signal is output.. | Replace the engine PWB. (See page 4-200,4-204) |

(2-2) No image appears (entirely black)

| Image sample | Factor |
|---|--|
|  | <ol style="list-style-type: none"> 1. Main charge is not applied. Drum surface potential error 2. The LSU laser is on for all colors. 3. Abnormal developer bias output |

| | Trouble location | Check | Corrective action |
|---|--------------------------|--|--|
| 1 | Charger roller | Check attachment of the main charge roller. | Reattach the main charge roller if it is improperly attached. |
| | | Check if the terminal on the high voltage PWB to the main charge roller is deformed. | Correct the terminal if it is deformed so that it contacts. |
| 2 | Drum unit | Check if there is the terminal failure with the high voltage PWB. | <ol style="list-style-type: none"> 1. Correct the terminal if it is deformed so that it contacts. 2. Replace the drum unit. |
| | | Check the ground contact for the drum ground failure. | Correct the terminal if it is deformed so that it contacts. |
| 3 | Developer unit | Check if there is the contact failure with the high voltage PWB. | <ol style="list-style-type: none"> 1. Correct the terminal if it is deformed so that it contacts. 2. Reattach the new developer unit. |
| 4 | High voltage PWB | Check the connector connection. Or check the wire's continuity. | <ol style="list-style-type: none"> 1. If the connector is not inserted enough, reconnect it. Replace the wire if there is no continuity. 2. High voltage PWB to Engine PWB |
| | | There is the main charge current failure or developer bias output failure from the high voltage PWB. | Replace the high voltage PWB. (See page 4-217,4-221) |
| 5 | Laser scanner unit (LSU) | Failure in turning the laser diode on/off control failure on the LSU PWB. | Replace the LSU. (See page 4-76) |
| 6 | Main PWB 30 ppm model | Video data output failure in the main PWB. | Replace the main PWB. (See page 4-208) |
| 7 | Engine PWB | Video data output failure in the main PWB. | Replace the engine PWB. (See page 4-200,4-204) |


(2-3) The entire image is faint

| Image sample | Factor |
|---|---|
|  | <ol style="list-style-type: none"> 1. Variance in environments (dew formation) 2. Toner is insufficient. Or it is deteriorated (becomes had to charge). 3. Developer bias output is low. 4. Primary transfer current output is low. 5. LSU laser power is low. 6. Drum surface potential is high. |

| | Trouble location | Check | Corrective action |
|---|------------------|---|---|
| 1 | Drum unit | Check if the drum is condensed. | Execute the drum refreshing. ([System Menu] > [Adjustment/Maintenance]) |
| 2 | Developer unit | Select [Color Belt] from U089 and print 4-color bands PG to check the following with the color which is defective. (See page 6-48,6-249) | |
| | | Check if printed at low density continuously. | <ol style="list-style-type: none"> 1. Execute the developer refresh (DEV-CLN) and then calibration if printing at low density. ([System Menu] > [Adjustment/Maintenance]) 2. Execute maintenance mode U464 for Calibration. (See page 6-131,6-358) 3. Execute maintenance mode U410 for Automatic harftone adjustment. (See page 6-115,6-339) |
| | | Check if the developer bias connection terminal is deformed. | Correct the terminal if it is deformed so that it contacts. |
| | | Developer bias setting failure. | <ol style="list-style-type: none"> 1. Execute maintenance mode U140 for Developer bias adjustment. (See page 6-71,6-280) 2. Execute maintenance mode U464 for Calibration. (See page 6-131,6-358) |
| 3 | Developer unit | There is the contact failure with the drum due to the dirt or damage of the DS pulleys in the sides of the developer roller. | Clean the DS pulleys. Replace the developer unit if broken. |
| | | Check the contact between the developer roller and drum surface. (Pressure failure) | Reattach the new developer unit. |
| | | Check if the toner control sensor is normal. | Replace the developer unit. |

| | Trouble location | Check | Corrective action |
|----|---|--|--|
| 4 | Toner container | Shake the toner container up and down about ten times and check the below. 1. Check "Add toner" indication. 2. Check if the toner supply vent opens. | Replace the toner container if "Add toner" is indicated or the toner supply vent does not open. |
| 5 | Toner motor | Check the toner motor rotation. | Check connection if the toner motor does not rotate. Or, replace the motor. |
| 6 | High voltage PWB | Check the contact and output of the high voltage connection terminal of the developer, main charge and transfer bias. | 1. Correct the terminal if it is deformed so that it contacts. 2. Replace the high voltage PWB. (See page 4-217,4-221) |
| 7 | Primary transfer unit | Check the primary transfer roller attachment to confirm the belt contact with the drum. | 1. Reattach the primary transfer roller. 2. Replace the primary transfer unit. (See page 4-32) |
| | | Check the high voltage contact deformation. | Correct the terminal if it is deformed so that it contacts. |
| 8 | Transfer high voltage PWB *40 ppm model only | Primary transfer current output failure on the transfer high voltage PWB. | Replace the transfer high voltage PWB. |
| 9 | LSU | 1. LSU laser beam power failure. 2. Internal mirror contamination | Replace the LSU. (See page 4-76) |
| 10 | Drum unit | 1. Check if the eraser lamp is dirty. 2. Check the lamp on/off. 3. Check if the drum surface is worn down. | 1. Clean the eraser lamp if it is dirty. 2. Replace the drum unit if it is not improved after cleaning, it is not turned on or the surface is worn. (See page 4-34) |
| 11 | Charger roller | Check the terminal with the high voltage PWB. | Remove foreign objects if adhering to the terminal. |
| 12 | Main PWB 30 ppm model | Main PWB is defective. | Replace the main PWB. (See page 4-208) |
| 13 | Engine PWB | Engine PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |


(2-4) The background is colored

| Image sample | Factor |
|---|--|
|  | <ol style="list-style-type: none"> 1. Toner is deteriorated (becomes had to charge). 2. Over-supply of toner. 3. Developer bias voltage is high. 4. Toner layer on the developer roller surface is thick (too much toner adheres). 5. The drum surface potential is low (low temperature environment) |

| | Trouble location | Check | Corrective action |
|---|------------------|---|--|
| 1 | Developer unit | <p>Select [Color Belt] from U089 and print 4-color bands PG to check the following with the color which is defective. (See page 6-48,6-249)</p> <ol style="list-style-type: none"> 1. Check if printed high coverage continuously with over-supply of toner or high temperature. 2. Check if the developer bias connection terminal is dirty or deformed. 3. Developer bias setting failure. | <p>Execute the calibration after executing the developer refresh (DEV-CLN). ([System Menu] > [Adjustment/Maintenance])</p> <p>Clean the developer bias connection terminal, if it is dirty. Correct the terminal if it is deformed so that it contacts.</p> <ol style="list-style-type: none"> 1. Execute maintenance mode U140 for Developer bias adjustment. (See page 6-71,6-280) 2. Execute maintenance mode U464 for Calibration. (See page 6-131,6-358) 3. Execute maintenance mode U410 for Automatic halftone adjustment. (See page 6-115,6-339) |
| 2 | Drum unit | <ol style="list-style-type: none"> 1. Check if the machine is used in an environment of low temperature. 2. Check if the drum unit is attached improperly. 3. Check if the ground connection terminal is dirty or conductive grease is applied to it. 4. Check if the main charge roller is dirty. | <p>If the room temperature is 16 °C/60.8 °F or less, try to use in the environment of more than 16 °C/60.8 °F.</p> <p>Reattach the drum unit. (See page 4-34)</p> <p>Clean the terminal if it is dirty. Apply conductive grease to the receptacle side bearing of the drum drive shaft if little grease is applied.</p> <p>Clean the main charge roller if it is dirty. Or, replace.</p> |
| 3 | High voltage PWB | There is the contact failure or output failure of the developer bias or main charge current from the high voltage PWB. | Correct the terminal if it is deformed. Or, replace the high voltage PWB. (See page 4-217,4-221) |


| | Trouble location | Check | Corrective action |
|---|------------------|--|---|
| 4 | Engine PWB | Engine PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| 5 | Toner motor | Check if the toner motor is rotating constantly. Check if the wiring is short-circuited. | Replace the wire if it is short-circuited and the toner motor rotates constantly. |

(2-5) Vertical white streaks or bands appear

| Image sample | Factor |
|---|--|
|  | <ol style="list-style-type: none"> 1. DP slit glass is dirty. 2. Foreign objects inside the developer unit. 3. Contamination inside the machine. 4. Dirt inside the drum unit. |


| | Trouble location | Check | Corrective action |
|---|---------------------------------|---|---|
| 1 | LSU | Check if the LSU slit glass is dirty. | <ol style="list-style-type: none"> 1. If the LSU slit glass is dirty, execute the laser scanner cleaning. 2. Replace the LSU if it is dirty inside. (See page 4-76) |
| 2 | Developer unit | Select [Color Belt] from U089 and print 4-color bands PG to check the following with the color which is defective. (See page 6-48,6-249) | |
| | | Check if there are foreign objects in the developer unit. | Clean or replace the developer unit with the color which is defective. (See page 4-38) |
| 3 | Light path between LSU and Drum | Check if the light path is interrupted by foreign objects such as dust, toner, etc. | If there are foreign objects in the frame between the developer unit and drum unit, and on the seal, remove them. |
| 4 | Drum unit | Check if the main charge roller is dirty. | Clean the main charge roller if it is dirty. Or, replace. (See page 4-37) |
| | | The drum has scratches. | Replace the drum unit. |
| | | Check if the eraser lamp is dirty. | Clean the eraser lamp if it is dirty. |

(2-6) Black or color streaks appear longitudinally

| Image sample | Factor |
|---|---|
|  | <ol style="list-style-type: none"> 1. Charger roller dirt. 2. Drum unit scratch or dirt. 3. Cleaning blade is damaged or jammed by paper dust. |


| | Trouble location | Check | Corrective action |
|---|---------------------|---|--|
| 1 | Charger roller unit | Check if the main charge roller surface has lines as marks of toner. | Clean the main charge roller if lines appear on the surface. Or replace the main charge roller. (See page 4-37) |
| 2 | Drum unit | <p>Check if the drum surface is dirty.</p> <p>Check if the drum surface is scratched.</p> <p>Check if the cleaning blade edge is damaged.</p> <p>Check if there is wear or paper dust pinched in.</p> <p>Check if toner is accumulated at the cleaning section.</p> | <p>Drum refreshing is executed. ([System menu] > [Adjustment/Maintenance])</p> <p>Replace the drum unit. (See page 4-34)</p> |
| 3 | Developer unit | Foreign objects adhere to the developer roller surface. | <ol style="list-style-type: none"> 1. Clean the developer roller surface. 2. Replace the developer unit if it is contaminated by foreign matter. (See page 4-38) |

(2-7) White, black or color streaks or bands appear horizontally

| Image sample | Factor |
|---|---|
|  | <ol style="list-style-type: none"> 1. developer unit dirt, contact dirt. Sleeve roller scratch. 2. Drum unit scratch or dirt. Ground is defective. 3. Charger roller is deformed. 4. Primary transfer roller terminal dirt. |


| | Trouble location | Check | Corrective action |
|---|---|---|---|
| 1 | Developer unit | <ol style="list-style-type: none"> 1. Check the print image on paper has a problem in the interval of the circumference of the developer roller. 2. Check if the sides of the developer roller and the bias terminal are dirty. 3. There is the cleaning failure at the developer roller surface. 4. Check if there are scratches on the sleeve roller. | <ol style="list-style-type: none"> 1. If the sides of the developer roller and the bias terminal are dirty, clean them. 2. Execute developer refreshing (DEV-CLN). ([System Menu] > [Adjustment/Maintenance]) 3. Replace the developer unit. (See page 4-38) |
| 2 | Drum unit | <ol style="list-style-type: none"> 1. Check the print image on paper has a problem in the interval of the circumference of the drum. 2. Check the drum surface potential erasing failure. 3. Check if the drum is scratched. 4. Check the ground terminal of the drum or drum drive shaft. | <p>Execute drum refreshing. ([System Menu] > [Adjustment/Maintenance])</p> <p>Lower the MC (main charge) value. [Adjustment/Maintenance]</p> <p>Replace the drum unit. (See page 4-34)</p> <ol style="list-style-type: none"> 1. Check the drum unit attachment and reattach it if its fixing is insufficient. 2. Replace the drum unit. (See page 4-34) |
| 3 | Charger roller | Check the print image on paper has a problem in the interval of the circumference of the main charger roller. | Replace the main charge roller if deformed. |
| 4 | Primary transfer roller (Transfer belt) | Check if the high voltage PWB contact with the primary transfer roller is dirty with toner. Check if the terminal is deformed and there is no contact. | <ol style="list-style-type: none"> 1. Clean the terminal if it is dirty. 2. Correct the terminal if it is deformed so that it contacts. 3. Replace the primary transfer unit. (See page 4-32) |
| 5 | High voltage PWB | Contact failure of the high voltage PWB or uneven bias voltage. | Check if how the high voltage PWB is attached and secure it with screws to secure grounding. Or, replace. (See page 4-217,4-221) |

(2-8) Uneven density vertically

| Image sample | Factor |
|---|---|
|  | <ol style="list-style-type: none"> 1. Uneven LSU laser beam emission. 2. Transfer belt contact failure with the drum. 3. Drum condensation. 4. Uneven toner layer on the developer roller |


| | Trouble location | Check | Corrective action |
|---|--|--|--|
| 1 | LSU | Laser is not output evenly from LSU. (Internal mirror drop-off) | Reattach the LSU. Or, replace. (See page 4-76) |
| 2 | Primary transfer roller (Primary transfer unit) | Check the fitting condition of the primary transfer roller. (Uneven pressure to the drum) | If the transfer roller and belt are at incorrect position, correct it and reattach them. Replace the primary transfer unit. (See page 4-32) |
| 3 | Drum unit | <ol style="list-style-type: none"> 1. Check if toner spreads evenly on the drum. 2. Check if it is used at high humidity. 3. Check if the drum surface is worn down. | <ol style="list-style-type: none"> 1. Drum refreshing is executed. ([System menu] > [Adjustment/Maintenance]) 2. Use in the environment without condensation. 3. Replace the drum unit. (See page 4-34) |
| 4 | Developer unit | <ol style="list-style-type: none"> 1. Check if the toner layer thickness on the developer roller is even. 2. Check if the DS pulleys the sides of the developer rollers are dirty or damaged. Failure of the developer roller to contact the drum surface 3. Foreign objects inside the developer unit. | <ol style="list-style-type: none"> 1. Execute the developer refresh (DEV-CLN) to evenly distribute the toner in the developer unit. ([System Menu] > [Adjustment/Maintenance]) 2. Clean the developer roller and DS pulley. Replace the developer unit if broken. (See page 4-38) |

(2-9) Uneven density horizontally

| Image sample | Factor |
|---|---|
|  | <ol style="list-style-type: none"> 1. Uneven rotation of the main drive. 2. Main charger roller rotation error. 3. Improper contact on the developer unit terminals. 4. LSU is defective. |


| | Trouble location | Check | Corrective action |
|---|------------------|--|--|
| 1 | Main drive | Check to see if the drive mechanism for the developer unit and drum unit is smoothly operative. | <ol style="list-style-type: none"> 1. Check the fitting condition of the developer unit and drum unit and clean the drive transmission section and apply grease if it is dirty. 2. Check if the main drive unit is surely secured with screws and reattached it. |
| 2 | Drum unit | The drum surface is worn down. | Replace the drum unit. |
| 3 | Charger roller | <ol style="list-style-type: none"> 1. Check if the main charge roller is attached wrongly. 2. Check if the main charge roller is deformed. | <ol style="list-style-type: none"> 1. Reattach the main charge roller if it is improperly attached. 2. Replace the main charge roller if deformed. (See page 4-37) |
| | | Check if the direction of the fur brush on the surface of the main charge cleaning roller is uniform. | Clean the main charge cleaning roller or replace the main charge roller. (See page 4-37) |
| 4 | Developer unit | <ol style="list-style-type: none"> 1. Check if the developer bias connection terminal of the developer unit is dirty with toner. 2. The DS pulleys at the sides of the developer unit are damaged. | <ol style="list-style-type: none"> 1. Clean the terminal if it is dirty. 2. Clean the developer unit or replace it if the DS pulley is damaged. (See page 4-38) |
| 5 | LSU | Check the image if it is the phenomenon from uneven laser beam output. | Replace the LSU. (See page 4-76) |

(2-10) Black or color dots appear in the image

| Image sample | Factor |
|---|---|
|  | <ol style="list-style-type: none"> 1. Charger roller dirt. 2. Drum unit scratch or dirt. 3. The cleaning blade is damaged or jammed by paper dust. |


| | Trouble location | Check | Corrective action |
|---|------------------|---|---|
| 1 | Drum unit | Check the print image on paper has a problem in the interval of the circumference of the drum. | Replace the drum unit if the drum is scratched. (See page 4-34) |
| 2 | Charger roller | Check the print image on paper has a problem in the interval of the circumference of the charger roller. | If the print image on paper has a problem in the interval of the circumference of the charger roller, replace the charge roller. (See page 4-37) |
| 3 | Developer unit | <p>Check if the developer bias leaks.</p> <p>Check the print image on paper has a problem in the interval of the circumference of the developer roller.</p> | <ol style="list-style-type: none"> 1. Clean the edge of the developer roller if leaked. 2. If used at high altitude, set the high altitude at [Adjustment/Maintenance] in [System Menu]. <ol style="list-style-type: none"> 1. If the print image on paper has a problem in the interval of the circumference of the developer roller, clean the developer roller. 2. Replace the developer unit. (See page 4-38) |

(2-11) Offset occurs

| Image sample | Factor |
|---|---|
|  | <ol style="list-style-type: none"> 1. Drum unit cleaning failure, scratch or dirt. 2. Developer bias leakage. |


| | Trouble location | Check | Corrective action |
|---|------------------|--|--|
| 1 | Drum unit | Check the print image on paper has a problem in the interval of the circumference of the drum. | If the drum unit is dirty with paper duct, toner, etc., clean it and reattach it. Or, replace. (See page 4-34) |
| 2 | Developer unit | Check if offsets are observed in the constant interval which is equivalent to the circumference of the developer roller. | If the developer unit is dirty with toner, etc., clean it and reattach it. Or, replace. (See page 4-38) |

(2-12) The image is partly missing

| Image sample | Factor |
|---|--|
|  | <ol style="list-style-type: none"> 1. Drum unit scratch or dirt. 2. Primary transfer belt surface deformation or dirt. |


| | Trouble location | Check | Corrective action |
|---|--|--|---|
| 1 | Drum unit | Check the print image on paper has a problem in the interval of the circumference of the drum. | If the print image on paper has a problem in the interval of the circumference of the drum, execute drum refreshing. ([System Menu] > [Adjustment/Maintenance]) |
| 2 | Primary transfer belt (Primary transfer unit) | Check if the primary transfer belt surface is deformed or dirty. | If the surface is deformed or dirty, clean the primary transfer belt or replace the unit. (See page 4-32) |

(2-13) The image is blurred

| Image sample | Factor |
|---|--|
|  | <ol style="list-style-type: none"> 1. Drum unit condensation. 2. DP slit glass dirt. |


| | Trouble location | Check | Corrective action |
|---|------------------|--|--|
| 1 | Drum unit | The drum surface is condensed. | Drum refreshing is executed. ([System Menu] > [Adjustment/Maintenance]) |
| 2 | LSU | Check if the LSU slit glass is entirely dirty. | <ol style="list-style-type: none"> 1. Execute the U474 LSU cleaning if the LSU slit glass is dirty. (See page 6-143,6-371) 2. Replace the LSU. (See page 4-76) |

(2-14) Poor grayscale reproduction

| Image sample | Factor |
|---|---|
|  | <ol style="list-style-type: none"> 1. Image adjustment failure |


| | Trouble location | Check | Corrective action |
|---|------------------|--|---|
| 1 | Image adjustment | Check if color adjustment is sufficient. | <ol style="list-style-type: none"> 1. Execute Calibration. ([System Menu] > [Adjustment/Maintenance]) 2. Execute maintenance mode U410 for Automatic halftone adjustment. (See page 6-115,6-339) |

**(2-15) Irregular horizontal white streaks appear in the image
/ Dots appear in the image**

| Image sample | Factor |
|---|--|
|  | <ol style="list-style-type: none"> 1. Installation at a high altitude. 2. Defective drum unit grounding. 3. Using the paper with high surface resistance. |


| | Trouble location | Check | Corrective action |
|---|------------------|---|---|
| 1 | Developer unit | Check if the operating environment is 1000m or more above sea level. (Developer bias leakage) | In the case of the high altitude place of 1000m above sea level or higher, change the high altitude setting in U140. (Normal/1001-2000m/2001-3000m/3001-3500m) (See page 6-71,6-280) |
| 2 | Drum unit | Check if there is contact failure between the main charger roller and high voltage PWB contact. | <ol style="list-style-type: none"> 1. Correct the terminal if it is deformed so that it contacts. 2. Reattach the drum unit (main charge roller). |
| | | Check the ground contact for the drum ground failure. | Correct the terminal if it is deformed so that it contacts. |
| 3 | Paper | Check if high surface resistance paper is used. | Change paper to different type. |

(2-16) Granular iamge (low solid image desnity)

| Image sample | Factor |
|---|---|
|  | <ol style="list-style-type: none"> 1. Installation at a high altitude. 2. Using the paper with high surface resistance. |

| | Trouble location | Check | Corrective action |
|---|------------------|--|---|
| 1 | Developer unit | Check if the operating environment is 1000m or more above sea level. | In the case of the high altitude place of 1000m above sea level or higher, change the high altitude setting in U140. (Normal/1001-2000m/2001-3000m/3001-3500m) (See page 6-71,6-280) |
| 2 | Paper | Check if high surface resistance paper is used. | Change paper to different type. |

(3) Image failure (Transfer, paper conveying and fusing factor: printer engine for 4 colors)



(3-1)No image appears (entirely white)



(3-2)The entire image is faint




(3-3)The background is colored



(3-4)Vertical white streaks or bands appear



(3-5)Black or color streaks appear longitudinally




(3-6)White, black or color streaks or bands appear horizontally



(3-7)Uneven transfer



(3-8)Black or color dots appear in the image




(3-9)Characters are blurred (transfer shift)



(3-10)The leading edge of the image is consistently misaligned with the original



(3-11)The leading edge of the image is sporadically misaligned with the original



(3-12)Creases are generated on paper



(3-13)Offset occurs



(3-14)The image is partly missing (Outlines objects and white dots)



(3-15) Fusing failure



(3-16)The image is blurred



(3-17)Image center does not align with the original center




(3-18)Paper is dirty with toner



(3-19)Poor color reproduction




(3-20)Color registration shift




(3-21)Dirt on the backside of paper

(3-1) No image appears (entirely white)

| Image sample | Factor |
|---|---------------------------------------|
|  | 1. No secondary transfer bias output. |


| | Trouble location | Check | Corrective action |
|---|---------------------------|--|---|
| 1 | Secondary transfer roller | Check if the right cover is securely closed. | Check the right cover lock. Open and close the right cover. |
| 2 | High voltage PWB | 1. Check how the connector is inserted. High voltage PWB to Engine PWB 2. Check the wire's continuity. | 1. If the connector is not inserted enough, reconnect it. 2. Replace the wire if there is no continuity. 3. Replace the high voltage PWB. (See page 4-217,4-221) |
| 3 | Engine PWB | 1. Check how the connector is inserted. 2. Check the wire's continuity. 3. Check if the secondary transfer high voltage on signal is output from Engine PWB. | 1. If the connector is not inserted enough, reconnect it. 2. Replace the wire if there is no continuity. 3. Replace the engine PWB if no signal is output. (See page 4-200,4-204) |

(3-2) The entire image is faint

| Image sample | Factor |
|---|---|
|  | <ol style="list-style-type: none"> 1. Paper is moist. 2. The contact pressure between the secondary transfer roller and primary transfer belt is low. 3. The secondary transfer bias impression is failed. |


| | Trouble location | Check | Corrective action |
|---|---------------------------|---|--|
| 1 | Paper | <ol style="list-style-type: none"> 1. Check if paper is moist. 2. Check the humidity of where paper is stored. | Replace paper if it is moist. If the place to store paper is moist, move it to a low humidity place. |
| 2 | Paper conveying unit | Check if the right cover is securely closed. | Check the right cover lock. Open and close the right cover. |
| 3 | Secondary transfer roller | Check the secondary transfer roller position. (Pressure failure) | If the secondary transfer roller is taken off, refit it. |
| 4 | High voltage PWB | Check if there is dirt or deformation in the terminal of the high voltage PWB to the secondary transfer roller. (Secondary transfer bias error) | <ol style="list-style-type: none"> 1. Clean the terminal if it is dirty. 2. Correct the terminal if it is deformed so that it contacts. 3. Replace the high voltage PWB (40ppm model: transfer high voltage PWB). |

(3-3) The background is colored

| Image sample | Factor |
|---|---|
|  | <ol style="list-style-type: none"> 1. Primary transfer unit grounding failure. 2. Secondary transfer roller dirt. |


| | Trouble location | Check | Corrective action |
|---|---------------------------|--|--|
| 1 | Primary transfer unit | Check if the belt surface is whitened. | Replace the primary transfer unit if the entire belt surface is whitened and is not improved after executing the calibration. (See page 4-32) |
| | | Check if the ground plate of the primary transfer unit is deformed. | If the ground plate is deformed, correct it to secure ground. |
| 2 | Secondary transfer roller | <ol style="list-style-type: none"> 1. Check the transfer bias ground failure. 2. Check if the roller full surface is entirely dirty. | <ol style="list-style-type: none"> 1. Correct the terminal to securely contact the roller shaft. 2. Clean or replace the secondary transfer roller if its surface is entirely dirty. |

(3-4) Vertical white streaks or bands appear

| Image sample | Factor |
|---|--|
|  | <ol style="list-style-type: none"> 1. Primary transfer unit dirt. 2. Secondary transfer roller dirt. |


| | Trouble location | Check | Corrective action |
|---|---------------------------|--|--|
| 1 | Primary transfer unit | Check if the white streaks position match the position of dirt on the primary transfer belt. | <ol style="list-style-type: none"> 1. Clean the primary transfer belt if contaminated. 2. Replace the primary transfer unit. (See page 4-32) |
| 2 | Secondary transfer roller | Check if the white streaks position match the position of dirt on the secondary transfer roller. | Clean the secondary transfer roller if contaminated. Replace the secondary transfer roller if it is not improved after cleaning it. (See page 4-33) |
| 3 | Eject guide | Check if paper slides the eject guide ribs intensely. | Correct the ribs if white steaks appear at the position of the ribs but paper is not wavy. |

(3-5) Black or color streaks appear longitudinally

| Image sample | Factor |
|---|---|
|  | <ol style="list-style-type: none"> 1. Primary transfer belt cleaning bias impression failure. 2. Secondary transfer roller dirt. 3. Separation needle dirt. 4. Dirty fuser unit inside. |


| | Trouble location | Check | Corrective action |
|---|---------------------------|---|---|
| 1 | Primary transfer unit | Check if paper dust is accumulated around the cleaning section. | <ol style="list-style-type: none"> 1. Clean the cleaning section if paper dust accumulates. 2. Replace the primary transfer unit if it is not improved after cleaning it. (See page 4-32) |
| | | Check dirt and deformation of the cleaning bias connector and high voltage terminals. | <ol style="list-style-type: none"> 1. Clean the connector and connection terminal if they are dirty. 2. Correct the terminal if deformed. 3. Replace the high voltage PWB. (40ppm model: transfer high voltage PWB) (See page 4-217,4-221) |
| | | Check dirt or scratch on the primary transfer belt circumference. | Replace the primary transfer unit if it is dirty or has scratches. (See page 4-32) |
| 2 | Secondary transfer roller | Check dirt, deformation or wear of the secondary transfer roller. | <ol style="list-style-type: none"> 1. Clean the secondary transfer roller if contaminated. 2. Replace the secondary transfer roller if it is deformed or worn out. (See page 4-33) |
| 3 | Separation needle | Check if the separation needles are dirty with paper dust and toner. | Clean the separation needles if they are dirty. |
| 4 | Fuser unit | <ol style="list-style-type: none"> 1. The paper separation plate is contaminated with toner. 2. Check if the paper weight setting matches the paper to use. | <ol style="list-style-type: none"> 1. Clean the paper separation plate if contaminated. 2. Change the setting if the paper weight setting does not match the paper to use. |
| 5 | Eject guide | The ribs are dirty with toner. | Clean it if dirty. |

(3-6) White, black or color streaks or bands appear horizontally

| Image sample | Factor |
|---|---|
|  | <ol style="list-style-type: none"> 1. Primary transfer unit grounding failure. 2. Secondary transfer roller dirt. |


| | Trouble location | Check | Corrective action |
|---|---------------------------|--|--|
| 1 | Primary transfer unit | Check if the phenomenon appears in the interval of the circumference of the primary transfer belt. | <ol style="list-style-type: none"> 1. Clean the primary transfer belt with soft cloth. 2. Replace the primary transfer unit if it is not improved after cleaning it. (See page 4-32) |
| 2 | Secondary transfer roller | <ol style="list-style-type: none"> 1. Check if the right cover is closed. 2. Check if the secondary transfer roller surely contacts the transfer belt. | <ol style="list-style-type: none"> 1. Close the right cover firmly. 2. Refit the press spring for the secondary transfer roller. Replace it if is deformed. |
| 3 | Fuser unit | Check the print image on paper has a problem in the interval of the circumference of the fuser roller. | Clean the fuser roller if it appears in the image. Replace the fuser unit if it is not improved after cleaning it. (See page 4-42) |

(3-7) Uneven transfer

| Image sample | Factor |
|---|---|
|  | <ol style="list-style-type: none"> 1. Primary transfer unit grounding failure. 2. Secondary transfer roller dirt. |


| | Trouble location | Check | Corrective action |
|---|---------------------------|---|---|
| 1 | Primary transfer unit | Check if paper dust is accumulated around the cleaning section. | <ol style="list-style-type: none"> 1. Clean the cleaning section if paper dust accumulates. 2. Replace the primary transfer unit if it is not improved after cleaning it. (See page 4-32) |
| | | Check dirt and deformation of the cleaning bias connector and high voltage terminals. | <ol style="list-style-type: none"> 1. Clean the connector or connection terminal if dirty. 2. Correct the terminal if deformed. 3. Replace the high voltage PWB. (40ppm model: transfer high voltage PWB) (See page 4-217,4-221) |
| | | Primary transfer belt is dirty or has scratches. | Replace the primary transfer unit. (See page 4-32) |
| 2 | Secondary transfer roller | Check dirt, deformation or wear of the secondary transfer roller. | <ol style="list-style-type: none"> 1. Clean the secondary transfer belt if contaminated. 2. Replace the secondary transfer roller if it is not improved after cleaning it. (See page 4-33) |
| 3 | Fuser unit | Check if the roller drive section and fuser pressure release mechanism are deformed, worn or damaged. | Replace the fuser unit if the roller drive section and fuser pressure release mechanism are deformed, worn or damaged. (See page 4-42) |

(3-8) Black or color dots appear in the image

| Image sample | Factor |
|---|--|
|  | <ol style="list-style-type: none"> 1. Primary transfer belt scratch or dirt. 2. Secondary transfer roller dirt. 3. Dirty fuser unit inside. |


| | Trouble location | Check | Corrective action |
|---|---------------------------|---|---|
| 1 | Primary transfer unit | Check the primary transfer belt cleaning. | <ol style="list-style-type: none"> 1. Clean the cleaning section. 2. Replace the unit if it is not improved after cleaning it. (See page 4-32) |
| | | Check for dirt or scratches in the interval of the primary transfer belt outer circumference. | Replace the primary transfer unit. (See page 4-32) |
| 2 | Secondary transfer roller | Check the print image on paper has a problem in the interval of the circumference of the secondary transfer roller. | <ol style="list-style-type: none"> 1. Clean the secondary transfer roller if it appears in the image. 2. Replace the secondary transfer roller if it is not improved after cleaning it. (See page 4-33) |
| 3 | Fuser unit | Check the print image on paper has a problem in the interval of the circumference of the fuser roller. | <ol style="list-style-type: none"> 1. Clean the fuser roller if it appears in the image. 2. Replace the fuser unit if it is not improved after cleaning it. (See page 4-42) |

(3-9) Characters are blurred (transfer shift)


| Image sample | Factor |
|---|--|
|  | <ol style="list-style-type: none"> 1. Paper is out of specification. 2. Imbalanced fuser unit pressures. |

| | Trouble location | Check | Corrective action |
|---|-----------------------|--|--|
| 1 | Paper | <ol style="list-style-type: none"> 1. Check if the paper is within the specification. 2. Check if the paper type and weight settings are proper. | <ol style="list-style-type: none"> 1. If paper type is out of specification, use proper paper. 2. If the paper setting is improper, set it in accordance with the paper. |
| 2 | Fuser unit | <ol style="list-style-type: none"> 1. Check the pressure balance between the left and right sides of the fuser unit. 2. Check if the paper entry guide to the fuser is deformed. | <ol style="list-style-type: none"> 1. Replace the fuser unit in case of the balance failure. (See page 4-42) 2. Replace the fuser unit if deformed. (See page 4-42) |
| 3 | Paper conveying motor | Check if the paper conveying drive is smooth. | If the drive is not smooth, apply grease to the gears. |
| 4 | Paper conveying guide | The paper conveying guide is deformed. | Replace the paper conveying guide if deformed. |


(3-10) The leading edge of the image is consistently misaligned with the original

| Image sample | Factor |
|---|--|
|  | <ol style="list-style-type: none"> 1. Improper leading edge timing adjustment. 2. Improper original deflection amount before the registration. |


| | Trouble location | Check | Corrective action |
|---|---------------------|--|--|
| 1 | Registration roller | Correct the contact if it is deformed. | If the adjustment is insufficient, adjust the leading edge timing in the maintenance mode U034. (See page 6-31,6-228) |
| | | Check of the registration sensor on timing (for paper deflection) is proper. | If paper feed failure occurs, clean the feed roller or replace paper to check if it is improved. |

(3-11) The leading edge of the image is sporadically misaligned with the original


| | Trouble location | Check | Corrective action |
|---|--|--|--|
| 1 | Registration clutch, Registration roller | Check if the registration roller is dirty and the registration clutch and feed motor operate smoothly. | <ol style="list-style-type: none"> 1. Clean the DP registration roller. 2. Reattach it if it is improperly attached. 3. Replace the feed drive unit if it does not move smoothly. |

(3-12) Creases are generated on paper


| | Trouble location | Check | Corrective action |
|---|-------------------------|---|---|
| 1 | Paper side registration | Check if the paper width guide set position matches the paper. | If the paper size does not match, align the side registration cursors to the paper edges. |
| 2 | Paper | <ol style="list-style-type: none"> 1. Check if it is curled or wavy. 2. Check if the place to store paper is moist. | <ol style="list-style-type: none"> 1. If paper is curled or wavy, replace it. 2. If the place to store paper is moist, move it to a low humidity place. |
| 3 | Registration roller | Balance is not secured between the front and rear springs. | Attach the parts with the regular spring pressure. |
| 4 | Fuser unit | The fuser pressure spring of the fuser unit is faulty. | Replace the fuser unit. (See page 4-42) |

(3-13) Offset occurs


| | Trouble location | Check | Corrective action |
|---|-----------------------|--|--|
| 1 | Paper | <ol style="list-style-type: none"> 1. Check if the paper is within the specification. 2. Check if the paper type and weight settings are proper. | <ol style="list-style-type: none"> 1. If paper type is out of specification, use proper paper. 2. Set paper type and weight. |
| 2 | Primary transfer unit | Check if offsets are occurred in the interval of the outer circumference of the primary transfer belt. | <ol style="list-style-type: none"> 1. Clean the primary transfer belt if it appears in the outer circumference interval. 2. Make the cleaning bias terminal of the cleaning roller securely contact the terminal of the high voltage PWB. 3. Replace the primary transfer unit. (See page 4-32) |
| 3 | Fuser unit | Check the print image on paper has a problem in the interval of the circumference of the fuser roller. | If the roller of the fuser unit is dirty, clean it or replace the unit. (See page 4-42) |

(3-14) The image is partly missing (Outlines objects and white dots)


| | Trouble location | Check | Corrective action |
|---|---------------------------|---|---|
| 1 | Paper | Check if paper is moist. Check if the place to store paper is moist. | <ol style="list-style-type: none"> 1. Replace paper if it is moist. If the place to store paper is moist, move it to a low humidity place. 2. Install the cassette heater if necessary. |
| 2 | Primary transfer unit | Check if dirty, scratch or deformation appear in the interval of the circumference of the primary transfer belt. | <ol style="list-style-type: none"> 1. Clean the primary transfer belt with soft cloth. 2. Replace the primary transfer unit. (See page 4-32) |
| 3 | Secondary transfer roller | Check the print image on paper has a problem in the interval of the circumference of the secondary transfer roller. | <ol style="list-style-type: none"> 1. Clean the secondary transfer roller. 2. Replace the secondary transfer roller. (See page 4-33) |

(3-15) Fusing failure

| | Trouble location | Check | Corrective action |
|---|----------------------|--|--|
| 1 | Paper | <ol style="list-style-type: none"> 1. Check if the paper is within the specification. 2. Check if the paper type and weight settings are proper. | <ol style="list-style-type: none"> 1. If paper type is out of specification, use proper paper. 2. Set the paper weight to match the paper. |
| 2 | Paper weight setting | Check the paper weight setting. | If the paper weight setting is insufficient, set the paper weight in accordance with the paper thickness. |
| 3 | Fuser unit | Fuser pressure setting (spring) is faulty. | Replace the fuser unit. (See page 4-42) |


(3-16) The image is blurred

| | Trouble location | Check | Corrective action |
|---|------------------|--|---|
| 1 | Paper | Check if paper is moist. Check if the place to store paper is moist. | <ol style="list-style-type: none"> 1. Replace paper if it is moist. 2. If the place to store paper is moist, move it to a low humidity place. |

(3-17) Image center does not align with the original center


| | Trouble location | Check | Corrective action |
|---|---------------------------|---|---|
| 1 | Paper setting | Check if paper is set correctly. | Set paper if it is not set correctly. |
| 2 | Image position adjustment | Check the center alignment during writing images. | If the adjustment is insufficient, adjust the center line in the maintenance mode U034. (See page 6-31,6-228) |

(3-18) Paper is dirty with toner

| Image sample | Factor |
|---|---|
|  | 1. Toner scattering inside the machine at continuous high coverage print. |


| | Trouble location | Check | Corrective action |
|---|-------------------------------------|---|--|
| 1 | Paper conveying guide | Check if the paper conveying guide is dirty with toner. | Clean the developer unit, drum unit and primary transfer unit if the paperconveying guide is dirty with toner. |
| 2 | Toner scattering inside the machine | Check if a large volume with high coverage was continuously output. | Clean the machine inside. |

(3-19) Poor color reproduction


| Image sample | Factor |
|---|--|
|  | <ol style="list-style-type: none"> 1. Paper storage condition is bad. Defective Paper type setting. 2. Developer bias impression failure (high voltage contact). 3. Deterioration of toner or developer powder. 4. Drum surface potential erasing failure (main charge roller contact). 5. High voltage PWB failure. 6. Not executing Calibration. |

| | Trouble location | Check | Corrective action |
|---|------------------------|--|--|
| 1 | Paper | Check if paper is moist. Check if the place to store paper is moist. | <ol style="list-style-type: none"> 1. Replace paper if it is moist. 2. If the place to store paper is moist, move it to a low humidity place. |
| 2 | Paper specification | Granular image (slightly uneven gloss) appears in the high density image area. | <ol style="list-style-type: none"> 1. Check the paper specification and use proper paper. 2. Change to color paper if rough paper for monochrome print is used. |
| 3 | Paper type | Check paper type and weight. | If The paper type and weight do not match the paper, set them properly. |
| 4 | Image adjustment | Check if the target density adjustment was done. | <ol style="list-style-type: none"> 1. Execute maintenance mode U464 for [Calibration]. (See page 6-131,6-358) 2. Execute maintenance mode U410 for Automatic halftone adjustment. (See page 6-115,6-339) |
| 5 | Developer unit | Toner is not charged. | Execute the calibration after executing the developer refresh (DEV-CLN). ([System Menu] > [Adjustment/Maintenance]) |
| 6 | Drum unit | Check the drum surface condensation. | Execute the drum refreshing. ([System Menu] > [Adjustment/Maintenance]) |
| 7 | Printer driver setting | Check the printer color table selection. | <ol style="list-style-type: none"> 1. Change the printer color table selection to the proper mode in the color reproduction mode in [Imaging] tab of the printer driver. 2. Download necessary color tables. |
| | | Check the printer data is CMYK. | If the printer data is CMYK, select the proper mode in the KPD L color conversion process. |

(3-20) Color registration shift

| Image sample | Factor |
|---|--|
|  | <ol style="list-style-type: none"> 1. ID sensor density detection error 2. Primary transfer belt deterioration. (whitened) 3. Primary transfer belt skew (color registration shift in the main scanning direction) 4. Motor speed control error (color registration shift in the sub-scanning direction) |

| | Trouble location | Check | Corrective action |
|---|-------------------------------|---|--|
| 1 | Color registration adjustment | Check if the color registration has been adjusted before executing the calibration. | <ol style="list-style-type: none"> 1. Execute maintenance mode U464 for [Calibration]. (See page 6-131,6-358) 2. Execute maintenance mode U469 for Color registration adjustment. (See page 6-137,6-364) |
| 2 | ID sensor | Check if the ID sensor shutter is opened when executing calibration. | <ol style="list-style-type: none"> 1. If the sensor shutter is not opened, correct it to open. 2. Clean the ID sensor. Or, replace. |
| 3 | Primary transfer unit | Check if the ID sensor can detect the image density correctly after executing the calibration with degraded belt. | Execute the calibration and replace the primary transfer unit if the color registration patches appear twice at the left and right sides of the transfer belt. (See page 4-32) |
| | | Check the belt skew. | Reattach the primary transfer unit. Replace the frame if deformed. |
| 4 | Engine PWB | Extreme color registration shift. (The motor speed is not correctly controlled.) | Replace the engine PWB. |

(3-21) Dirt on the backside of paper

| | Trouble location | Check | Corrective action |
|---|---------------------------|---|--|
| 1 | Secondary transfer roller | Check if the secondary transfer roller is dirty with toner. | <ol style="list-style-type: none"> 1. Clean the secondary transfer roller. 2. Check if the transfer bias terminal contacts the roller. |
| 2 | Fuser pressure roller | Check if foreign objects such as toner dirt, etc. mix in or adhere to the fuser press roller. | <ol style="list-style-type: none"> 1. Clean the fuser pressure roller if foreign objects adhere. 2. If the paper thickness setting does not match the paper, set the proper paper thickness. |
| 3 | Paper conveying guide | The paper conveying guide is dirty with toner. | Clean the paper conveying guide, developer unit, drum unit and primary transfer unit if the paper conveying guide is dirty with toner. |

7-4 Electric failure

If the parts of the problem cause is not supplied, replace the unit that includes it.
Take care of the errors in the order of error cause number.

| Failure status | Cause of trouble | Check method and remedy |
|---|---|---|
| (1) The machine does not operate at all when turning the power on. | 1. Power is not supplied to the outlet. | Check input voltage. |
| | 2. Power plug connection is defective. | Check the contact between the power plug and outlet is secure. |
| | 3. Broken power cord. | Check the continuity and replace if there is no continuity. |
| | 4. Connected to the power switch. | Check the continuity between the power switch contacts and replace it if there is no continuity. |
| | 5. Low voltage power supply PWB is defective. | Replace the low voltage power supply PWB. (See page 4-225,4-233) |
| | 6. Engine PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| | 7. Main PWB is defective. | Replace the main PWB and check its operation. (See page 4-208,4-212) |
| (2) The scanner motor does not rotate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Scanner motor to Engine PWB(YC19): 30ppm model Scanner motor to Engine PWB(YC27): 35/40ppm models |
| | 2. If condensed, remove it. | Check if each gear and gear rotate smoothly. Apply grease to the busing and gears if they are faulty. Check each gear if it is damaged and replace it if it is. |
| | 3. Motor failure is defective. | Replace the scanner motor. |
| | 4. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (3) Eject motor does not rotates. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Eject motor to Engine PWB (YC31): 30 ppm model Eject motor to Engine PWB (YC24): 35/40 ppm models |
| | 2. If condensed, remove it. | Check if each gear and gear rotate smoothly. Apply grease to the busing and gears if they are faulty. Check each gear if it is damaged and replace it if it is. |
| | 3. Motor is defective. | Reattach or replace the eject motor. |
| | 4. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |

| Failure status | Cause of trouble | Check method and remedy |
|---|---|---|
| (4) The fuser motor does not rotate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Fuser motor to Engine PWB (YC17): 30ppm model Fuser motor to Engine PWB (YC24): 35/40ppm models |
| | 2. Motor is defective. | Reattach or replace the fuser motor. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (5) The vibration motor does not rotated. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Vibration motor to Drum/developer PWB to Engine PWB |
| | 2. Motor is defective. | Connected to the eject fan motor. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (6) Connected to the eject fan motor. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Eject fan motor to Engine PWB (YC10): 30ppm model Eject fan motor to Engine PWB (YC17): 35/40ppm models |
| | 2. Motor is defective. | Connected to the eject fan motor. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (7) Developer fan motor 1 does not rotate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Developer fan motor 1 to Engine PWB (YC21): 30ppm model Developer fan motor 1 to Engine PWB (YC4) 35/40ppm models |
| | 2. Motor is defective. | Replace the developer fan motor 1. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (8) Developer fan motor 2 does not rotate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Developer fan motor 1 to Engine PWB (YC21): 30ppm model Developer fan motor 1 to Engine PWB (YC4) 35/40ppm models |
| | 2. Motor is defective. | Replace the developer fan motor 2. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |

| Failure status | Cause of trouble | Check method and remedy |
|--|---|---|
| (9) Developer fan motor 3 does not rotate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Developer fan motor 3 to Engine PWB (YC10): 30ppm model Developer fan motor 3 to Engine PWB (YC17): 35/40ppm models |
| | 2. Motor is defective. | Replace the developer fan motor 3. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (10) Developer fan motor 4 does not rotate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Developer fan motor 3 to Engine PWB (YC10): 30ppm model Developer fan motor 3 to Engine PWB (YC17): 35/40ppm models |
| | 2. Motor is defective. | Replace the developer fan motor 4. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (11) The transfer belt fan motor does not rotate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Transfer belt fan motor to Engine PWB (YC10): 30ppm model Transfer belt fan motor to Engine PWB (YC17): 35/40ppm models |
| | 2. Motor is defective. | Replace the transfer belt fan motor. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (12) The steam removal fan motor does not rotate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Steam removal fan motor to Engine PWB (YC24): 30ppm model Steam removal fan motor to Engine PWB (YC31): 35/40ppm models |
| | 2. Motor is defective. | Replace the steam removal fan motor. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |

| Failure status | Cause of trouble | Check method and remedy |
|--|---|--|
| (13) The controller fan motor does not rotate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Controller fan motor to Engine PWB (YC21): 30ppm model Controller fan motor to Engine PWB (YC4): 35/40ppm models |
| | 2. Motor is defective. | Replace the controller fan motor. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (14)The PWB fan motor does not rotate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. PWB fan motor to Engine PWB (YC34): 30ppm model PWB fan motor to Engine PWB (YC14): 35/40ppm models |
| | 2. Motor is defective. | Replaces the PWB fan motor. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (15) The toner sucking fan motor does not rotate. *40 ppm model only | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Toner sucking fan motor to Engine PWB (YC17) |
| | 2. Motor failure | Replace the toner sucking fan motor. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (16) Paper feed clutch does not operate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Feed clutch to Engine PWB (YC13) Feed clutch to Engine PWB (YC19) |
| | 2. Clutch is defective. | Replaces the feed drive unit. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (17) Registration clutch does not operate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Registration clutch to Engine PWB (YC13): 30ppm model Registration clutch to Engine PWB (YC19): 35/40ppm models |
| | 2. Clutch is defective. | Replaces the feed drive unit. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |

| Failure status | Cause of trouble | Check method and remedy |
|---|---|---|
| (18) The duplex clutch does not operate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Duplex clutch to Engine PWB (YC13): 30ppm model Duplex clutch to Engine PWB (YC19): 35/40ppm model |
| | 2. Defective is defective. | Replaces the feed drive unit. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (19) The BK developer clutch does not operate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. BK developer clutch to Engine PWB (YC13): 30ppm model BK developer clutch to Engine PWB (YC18): 35/40ppm models |
| | 2. Clutch is defective. | Replaces the feed drive unit. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (20) Middle clutch does not operate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Middle clutch to Engine PWB (YC13): 30ppm model Middle clutch to Engine PWB (YC19): 35/40ppm models |
| | 2. Clutch is defective. | Replaces the feed drive unit. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (21) MP solenoid does not function | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. MP solenoid to Engine PWB (YC12): 30ppm model MP solenoid to Engine PWB (YC18): 35/40ppm models |
| | 2. Solenoid is defective. | Replaces the feed drive unit. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (22) The feed-shift solenoid does not operate | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Feed-shift solenoid to Engine PWB (YC24): 30ppm model Feed-shift solenoid to Engine PWB (YC31): 35/40ppm models |
| | 2. Solenoid is defective. | Replace the exit unit. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |

| Failure status | Cause of trouble | Check method and remedy |
|--|---|--|
| (23) Load paper message appears with paper load in the cassette. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Paper sensor (PS) to Engine PWB (YC12): 30ppm model Paper sensor (PS) to Engine PWB (YC18): 35/40ppm models |
| | 2. Deformed actuator. | Check and replace if failed. |
| | 3. Sensor is defective. | Replace the paper sensor (PS). |
| | 4. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (24) "Add paper" message is indicated while paper is set to the MP tray. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. MP paper detection sensor to Engine PWB (YC12): 30ppm model MP paper detection sensor to Engine PWB (YC18): 35/40ppm models |
| | 2. Deformed actuator. | Check and replace if failed. |
| | 3. Sensor is defective. | Replace the MP paper detection sensor. |
| | 4. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (25) Paper size of the MP tray is detected wrongly. *35/40 ppm models only | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. MP paper width detection sensor to Engine PWB (YC20): 30ppm model MP paper length detection sensor to Engine PWB (YC20): 35/40ppm models |
| | 2. Switch is defective. | Replace the MP paper width detection sensor and MP paper length detection sensor. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |

| Failure status | Cause of trouble | Check method and remedy |
|---|--|--|
| (26) Jam occurs at the feed, conveying or eject section at the same time of turning the power switch on. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Registration sensor to Engine PWB (YC12): 30ppm model Duplex sensor to Engine PWB (YC12): 30ppm model Fuser sensor to Engine PWB (YC7): 30ppm model Upper/Lower eject full sensor to Engine PWB (YC31): 30ppm model Registration sensor to Engine PWB (YC18); 35/40ppm models Duplex sensor to Engine PWB (YC18): 35/40ppm models Fuser sensor to Engine PWB (YC11): 35/40ppm models Upper/Lower eject full sensor to Engine PWB (YC31): 35/40ppm models |
| | 2. Paper pieces, etc. remain around the registration sensor, duplex sensor, fuser eject sensor, and upper eject full sensor or lower eject sensor. | Check if there are paper pieces and remove them if any. |
| | 3. Sensor is defective. | Replace the registration sensor, duplex sensor, fuser eject sensor and eject full sensor or lower eject full sensor. |
| | 4. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (27) The cover open message appears after closing the front cover or right cover. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. Connected to the interlock switch |
| | 2. Switch is defective. | Check the interlock switch and replace it if necessary. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) Replace the low voltage power supply PWB. (See page 4-217,4-221) |
| (28) The DP feed motor does not rotate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. DP feed motor to Engine PWB (YC20): 30ppm model DP feed motor to Engine PWB (YC20): 35/40ppm models |
| | 2. Defective drive transmission system. | Check if each gear and gear rotate smoothly. Apply grease to the housing and gears if they are faulty. Check each gear if it is damaged and replace it if it is. |
| | 3. Motor is defective. | Replace the DP feed motor. |
| | 4. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |

| Failure status | Cause of trouble | Check method and remedy |
|--|---|---|
| (29) The DP conveying motor does not rotate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. DP deed motor to Engine PWB (YC20): 30ppm model DP deed motor to Engine PWB (YC20): 35/40ppm models |
| | 2. Defective drive transmission system. | Check if each gear and gear rotate smoothly. Apply grease to the busing and gears if they are faulty. Check each gear if it is damaged and replace it if it is. |
| | 3. Motor is defective. | Replace the DP conveying motor. |
| | 4. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (30) The DP feed-shift motor does not rotate. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. DP deed motor to Engine PWB (YC20): 30ppm model DP deed motor to Engine PWB (YC20): 35/40ppm models |
| | 2. Motor is defective. | Replace the DP feed-shift motor. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (31) The original jams upon turning the power on. | 1. Paper pieces, etc. remain around the DP feed sensor, DP registration sensor or DP feed-shift sensor. | Check if there are paper pieces and remove them if any. |
| | 2. Sensor failure | Replace the DP feed sensor, DP registration sensor or DP feed-shift sensor. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| (32) The cover open message appears even if closing the DP upper cover. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. DP deed motor to Engine PWB (YC20): 30ppm model DP deed motor to Engine PWB (YC20): 35/40ppm models |
| | 2. Sensor is defective. | Replace the DP cover open/close sensor. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |

| Failure status | Cause of trouble | Check method and remedy |
|---|---|---|
| (33) The LED is lit though there is no paper in the job separator. | 1. Wire failure or connection failure of the connector. | If the connector is not inserted enough, reconnect it. Or check the wire's continuity. Replace the wire if there is no continuity. JS eject sensor to Engine PWB (YC24): 30ppm model JS eject sensor to Engine PWB (YC31): 35/40ppm models |
| | 2. Sensor is defective. | Replace the JS eject sensor. |
| | 3. PWB is defective. | Replace the engine PWB. (See page 4-200,4-204) |
| | 4. The job separator is not installed. | If not installed, check the maintenance mode U211 and set it to [Off]. |

7-5 Mechanical failure

If the parts of the problem cause is not supplied, replace the unit that includes it.

| Failure status | Failure point and check method | Corrective action |
|---|---|---|
| (1) No primary paper feed. | Check if the surface of the roller below is dirty with paper dust, etc. Pickup roller Paper feed roller MP paper feed roller | Clean the roller surface with alcohol. |
| | Check if the roller below is deformed. Pickup roller Paper feed roller MP paper feed roller | Check and replace if deformed. (See page 4-25,4-31) |
| | Feed unit mounting error. | Check and repair if failed. |
| (2) No secondary paper feed. | Check if the surface of the roller below is dirty with paper dust, etc. DP registration roller DP registration pulley | Clean the roller surface with alcohol. |
| | Detaching and reattaching the duplex paper conveying unit. | Check and repair if failed. |
| (3) Skewed paper feed. | Poor attachment of the paper width guide in a cassette. | Check if the paper width guide is set at the correct position and repair or replace it if it has a problem. |
| (4) Multiple sheets of paper are fed. | 1. Check if there is extreme curl on paper. | If curled, replace paper. |
| | 2. Paper is not loaded in the cassette correctly. | Load paper. |
| | 3. Check if the retard pulley is worn. | Replace if worn out. (See page 4-28) |
| (5) Paper jam occurs. | Check if there is extreme curl on paper. | If curled, replace paper. |
| | Check if the registration roller contacts the registration pulley correctly. | Check and repair if failed. |
| | extreme dirt or deformation of the heat roller and press roller. | Check and replace the fuser unit if failed. (See page 4-42) |
| (6) Toner drops to the paper conveying section. | Check if the developer unit, drum unit or primary transfer unit is extremely dirty. | Clean the developer unit, drum unit and primary transfer unit. |
| (7) "Add toner" indication does not disappear. (BK) | 1. Check if the spiral of the toner container rotates. 2. Check if the toner supply vent opens by lever operation. | Replace the toner container. |
| | Check if the roller of the developer unit rotates and developer clutch, etc. delivering drive are not damaged. | 1. Replace the developer unit. 2. Paper conveying drive unit. |

| Failure status | Failure point and check method | Corrective action |
|--|--|--|
| (8) "Add toner" indication does not disappear. (C.M.Y) | 1. Check if the spiral of the toner container rotates. 2. Check if the toner supply vent opens by lever operation. | Replace the toner container. |
| | Check if the roller of the developer unit rotates and coupling, etc. delivering drive are not damaged. | 1. Replace the developer unit. 2. Replace the main drive unit. |
| (9) An abnormal sound is generated | Check if each roller, pulley and gear rotate smoothly. | Apply grease to the bushing and roller shaft. |
| | Check if the roller of the developer unit rotates. | Replace the developer unit if it is locked. |
| | Check if the cause is the primary transfer unit cleaning section or main unit drive section. | 1. Clean the cleaning section if it is clogged with toner. 2. Apply grease if the sliding noise heard from the side of the main unit side waste toner joint gear. |
| | Check the occurrence at the fuser unit. Printing. Or, in case the fuser motor rotates reversely to release the fuser pressure at power-up. | Check the meshing of the gears and reattach the fuser unit. Grease is applied to the gear related to the fuser drive fuser. |
| | Check if it occurs when the cassette lift motor works. | Check if the cassette lift motor is securely attached and reattach it. |

7-6 Error codes

Scan to PC (SMB/FTP/Email) transmission error codes, contents, checkpoints and remedies are described.

The error code not listed here may be the software failure.

Turn the power switch off then on, and execute again.

(1) Scan to SMB error code

| Codes | Content | Check method and remedy |
|-------|---|--|
| 1101 | The destination host does not exist in the network. | <ol style="list-style-type: none"> 1. Check the destination host name. 2. Check the network setting of the device. 3. Check the network setting connecting to the device. |
| 1102 | Login to the destination host has failed. | <ol style="list-style-type: none"> 1. Check user name and password. 2. Check the network setting connecting to the device. 3. Check sharing settings of the destination host and folder. |
| 1103 | The destination host, destination folder and file are invalid. | <ol style="list-style-type: none"> 1. Check if invalid characters are included in the destination host name, destination folder or file name. 2. Check if the destination folder name and file name conform with the naming syntax. 3. Check the destination host and destination folder. |
| 1105 | The SMB protocol is not valid. | <ol style="list-style-type: none"> 1. Check the SMB protocol setting of the device. |
| 2101 | Connection to the destination host has failed. | <ol style="list-style-type: none"> 1. Check the destination host name. 2. Check if the LAN cable is connected to the device. 3. Check the SMB port number. 4. Check the network setting of the device. 5. Check the network setting connecting to the device. |
| 2201 | Scanned data writing has failed. | <ol style="list-style-type: none"> 1. Check the transmission file name. 2. Check the network setting of the device. 3. Check the network setting connecting to the device. |
| 2203 | No response is received from the destination host for the specified time. | <ol style="list-style-type: none"> 1. Check the network setting connecting to the device. 2. Check if the LAN cable is connected to the device. |

(2) Scan to FTP error code

| Codes | Content | Check method and remedy |
|--------------|---|--|
| 1101 | The FTP server does not exist in the network. | <ol style="list-style-type: none"> 1. Check the FTP server name. 2. Check the network setting of the device. 3. Check the network setting connecting to the device. |
| 1102 | Logging in the FTP server failed. | <ol style="list-style-type: none"> 1. Check user name and password. 2. Check the FTP server. |
| 1103 | The destination folder is invalid. | <ol style="list-style-type: none"> 1. Check if invalid characters are included in the destination folder or file name. 2. Check the FTP server. |
| 1105 | The FTP protocol is invalid. | <ol style="list-style-type: none"> 1. Check the FTP protocol setting of the device. |
| 1131 | TLS initialization failed. | <ol style="list-style-type: none"> 1. Check the security setting of the device. |
| 1132 | The TLS negotiation failed. | <ol style="list-style-type: none"> 1. Check the security setting of the device. 2. Check the FTP server. |
| 2101 | Connection to the FTP server failed. | <ol style="list-style-type: none"> 1. Check the FTP server name. 2. Check if the LAN cable is connected to the device. 3. Check the FTP port number. 4. Check the network setting of the device. 5. Check the network setting connecting to the device. 6. Check the FTP server. |
| 2102 | Connection to the FTP server failed. DMA time out | <ol style="list-style-type: none"> 1. Check the FTP server name. 2. Check the FTP port number. 3. Check the network setting of the device. 4. Check the network setting connecting to the device. 5. Check the FTP server. |
| 2103 | The server is unable to communicate. | <ol style="list-style-type: none"> 1. Check the FTP server name. 2. Check the FTP port number. 3. Check the network setting of the device. 4. Check the network setting connecting to the device. 5. Check the FTP server. |
| 2201 | Communication with the FTP server failed. | <ol style="list-style-type: none"> 1. Check the network setting of the device. 2. Check the network setting connecting to the device. 3. Check the destination folder name. 4. Check the FTP server. |
| 2202 | Communication with the FTP server failed. DMA time out | <ol style="list-style-type: none"> 1. Check the network setting of the device. 2. Check the network setting connecting to the device. |
| 2203 | No response is received from the server for the specified time. | <ol style="list-style-type: none"> 1. Check the network setting of the device. 2. Check the network setting connecting to the device. |
| 2231 | Communication with the FTP server failed. (FTPS communication) | <ol style="list-style-type: none"> 1. Check the network setting of the device. 2. Check the network setting connecting to the device. |

| Codes | Content | Check method and remedy |
|--------------|--|---|
| 3101 | An error response is received from the FTP server. | <ol style="list-style-type: none"> 1. Check the network setting of the device. 2. Check the network setting connecting to the device. 3. Check the FTP server. |

(3) Scan to E-mail error code

| Codes | Content | Check method and remedy |
|--------------|--|--|
| 1101 | No SMTP/POP3 server exists in the network. | <ol style="list-style-type: none"> 1. Check the SMTP/POP3 server name. 2. Check the network setting of the device. 3. Check the network setting connecting to the device. |
| 1102 | The SMTP/POP3 login failed. | <ol style="list-style-type: none"> 1. Check user name and password. 2. Check the SMTP/POP3 server. |
| 1104 | The domain in the destination address is in the transmission denial designation by the domain restriction. | <ol style="list-style-type: none"> 1. Check the SMTP setting of the device. |
| 1105 | The SMTP protocol is valid. | <ol style="list-style-type: none"> 1. Check the SMTP protocol setting of the device. |
| 1106 | Sender address is not registered. | <ol style="list-style-type: none"> 1. Check the SMTP protocol setting of the device. |
| 2101 | Connection to the SMTP/POP3 server failed. | <ol style="list-style-type: none"> 1. Check the SMTP/POP3 server name. 2. Check if the LAN cable is connected to the device. 3. Check the SMTP/POP3 port number. 4. Check the network setting of the device. 5. Check the network setting connecting to the device. 6. Check the SMTP/POP3 server. |
| 2102 | Connection to the SMTP/POP3 server failed. DMA time out | <ol style="list-style-type: none"> 1. Check the SMTP/POP3 server name. 2. Check the SMTP/POP3 port number. 3. Check the network setting of the device. 4. Check the network setting connecting to the device. 5. Check the SMTP/POP3 server. |
| 2103 | The server is unable to communicate. | <ol style="list-style-type: none"> 1. Check the SMTP/POP3 server name. 2. Check the SMTP/POP3 port number. 3. Check the network setting of the device. 4. Check the network setting connecting to the device. 5. Check the SMTP/POP3 server. |
| 2201 | Communication with the SMTO/PO3 server failed. | <ol style="list-style-type: none"> 1. Check the network setting of the device. 2. Check the network setting connecting to the device. |
| 2202 | Communication with the SMTP/POP3 failed. DMA time out | <ol style="list-style-type: none"> 1. Check the network setting of the device. 2. Check the network setting connecting to the device. |
| 2204 | The file size has exceeded. | <ol style="list-style-type: none"> 1. Check the network setting of the device. |

| Codes | Content | Check method and remedy |
|--------------|--|---|
| 3101 | An error response is received from the SMTP/POP3 server. | <ol style="list-style-type: none"> 1. Check the network setting of the device. 2. Check the network setting connecting to the device. 3. Check the SMTP/POP3 server. |
| 3102 | Server response error | <ol style="list-style-type: none"> 1. Check the SMTP/POP3 server. 2. Retry after a time interval. |
| 3201 | No SMTP authentication authority to support. | <ol style="list-style-type: none"> 1. Check the SMTP server. 2. (SMTP authentication authorities are CRAM-MD5, DIGEST-MD5, PLAIN and LOGIN) |
| 4803 | Establishing the SSL session failed. | <ol style="list-style-type: none"> 1. Check the self-certificate of the device. 2. Check the SMTP/POP3 server certificate. 3. Check the SMTP/POP3 settings of the SMTP/POP3 server and device. |

7-7 Error codes

(1) Error codes

Error codes are listed on the communication reports, activity report, etc. The codes consist of an error code indication U followed by a 5-digit number. (The V.34 error is indicated with E of the error code and 5-digit number)

Regarding the 5-digit number, upper 3 digits indicate error and large classification of cause, lower 2 digits small classification of cause. The lower 2 digits are 00 for the item not requiring the category.




Figure 7-1

(2) Error codes

| Error codes | Content |
|----------------------|---|
| U00000/E00000 | No response or busy every time when redialing the specified times. |
| U00100/E00100 | Press the [Stop] key. |
| U00200/E00200 | Press the [Stop] key. |
| U00300/E00300 | Destination receiver machine is out of paper during transmission. |
| U004XX/E004XX | Communication was interrupted due to the function unmatched when receiving the call (Receiver). Error corresponding to U004XX (Phase B interruption) (See page 7-188). |
| U006XX/E006XX | Communication was interrupted due to trouble of the own machine. Error corresponding to U006XX (Machine problem) (See page 7-188). |
| U00700/E00700 | Communication was interrupted because of a problem in the destination unit. |
| U008XX/E008XX | Some pages were not correctly transmitted when transmitting in the G3 mode. Error corresponding to U008XX (Part of transmission error) (See page 7-188). |
| U009XX/E009XX | Some pages were not correctly received when receiving in the G3 mode. Error corresponding to U009XX (Part of transmission error) (See page 7-188). |
| U010XX/E010XX | Communication was interrupted due to signal errors during transmission in the G3 mode. Error corresponding to U010XX (Transmission in G3 mode) (See page 7-189). |
| U011XX/E011XX | Communication was interrupted due to signal errors during reception in the G3 mode. Error corresponding to U011XX (Reception in G3 mode) (See page 7-190). |
| U01400/E01400 | Invalid one-touch key, etc. were designated during communication. |
| U01500/E01500 | A communication occurred at V.8 mode when calling. |
| U01600/E01600 | A communication error occurred in V.8 mode when answering the call. |
| U017XX/E017XX | A communication error occurred before starting the T.30 .protocol when transmitting in V.34 mode. Error corresponding to U017XX (Transmission in V.34 mode) (See page 7-191). |
| U018XX/E018XX | A communication error occurred before starting the T.30 protocol when receiving in V.34 mode. Error corresponding to U018XX (Reception in V.34 mode) (See page 7-191). |
| U03000/E03000 | Originals were not set on the destination machine at polling reception. |
| U03200/E03200 | Communication was interrupted since the permission ID number and permission phone number did not match at polling reception (Destination machine is our own). Communication was interrupted since the permit ID number and permit phone number did not match when receiving F-code bulletin board from the own machine. |
| U03300/E03300 | Communication was interrupted since individual numbers did not match at polling reception (Destination machine is our own or other). |
| U03400/E03400 | Communication was interrupted due to the designated F-code confidential box No. unmatched when receiving the F-code bulletin board between own machines. |
| U03500/E03500 | Communication was interrupted due to the F-code confidential box No. unmatched when receiving the F-code bulletin board between own machines. |
| U03600/E03600 | Communication was interrupted due to the designated F-code confidential box No. unmatched when receiving the F-code bulletin board between own machines. |
| U03700/E03700 | Destination machine does not have the F-code bulletin board transmission function at the F-code bulletin board reception. Or data was not saved in any of the destination machine's F-code confidential box. |

| Error codes | Content |
|----------------------|---|
| U04000/E04000 | The designated F-code confidential box No. was not registered in the destination machine when transmitting F-code between own machines. |
| U04100/E04100 | The destination machine does not have the F-code reception function at the F-code transmission. |
| U04200/E04200 | Designated encryption box was not registered in the destination receiver machine. |
| U04300/E04300 | The encrypted transmission was attempted but the destination receiver machine did not have the encryption function. |
| U044XX/E044XX | Communication was interrupted due to the encryption key error in the encrypted transmission. Error corresponding to U044 (Reception in V.34 mode) (See page 7-191). |
| U04500/E04500 | Communication was interrupted since the encryption key did not match in the encrypted reception. |
| U05100/E05100 | Communication was interrupted since the permission number did not match due to the password check receipt or receipt restriction. |
| U05200/E05200 | Communication was interrupted since the permission number did not match, the denial number matched or own phone number was not informed due to the password check receipt or receipt restriction. |
| U05300/E05300 | Password check reception or restricted reception was interrupted because the permit ID's did not match, the rejected FAX number's did match, or the destination receiver did not return its phone number. |
| U14000/E14000 | Memory overflow at the F-code confidential reception. |
| U14100/E14100 | The destination machine made memory overflow when transmitting F-code between own machines. |
| U19000/E19000 | Memory overflowed during memory reception. |
| U19100/E19100 | Destination receiver machine has memory overflow during reception. |
| U19300/E19300 | Transmission was failed with an error when encoding in JBIG. |

(2-1) Error code table: U004XX Interrupted phase B

| Error codes | Content |
|----------------------|---|
| U00430/E00430 | Communication was interrupted by the permission number mismatch at polling request. (Sender's event) Or F-code bulletin board transmission request is received but communication is interrupted with permission number mismatch. (Sender's event) |
| U00431/E00431 | Communication was cancelled since the F-code confidential box ID No. was not registered at F-code bulletin board transmission. |
| U00432/E00432 | Communication was cancelled with the F-code confidential box ID No. mismatch at F-code bulletin board transmission. |
| U00433/E00433 | Data was not set in the F-code confidential box when receiving the F-code bulletin board transmission. |
| U00440/E00440 | The F-code confidential reception was cancelled since designated F-code box No. was not registered. |
| U00450/E00450 | Password check transmission or restricted transmission was interrupted because the permit ID's did not match. |
| U00460/E00460 | Communication was interrupted since the encryption box number designated in the encrypted reception was not registered. |
| U00462/E00462 | Communication was interrupted since the encryption key for the designated encryption box was not registered. |

(2-2) Error code table: U006XX Problems with the unit

| Error codes | Content |
|----------------------|---|
| U00601/E00601 | Original feed jam or exceeding the maximum original length. |
| U00613/E00613 | Error in the optical writing section. |
| U00656/E00656 | Data was not sent due to the modem error. |
| U00690/E00690 | System error has occurred. |

(2-3) Error code table: U008XX Page transmission error

| Error codes | Content |
|----------------------|---|
| U00800/E00800 | Some pages could not be sent since RTN or PIN signal was received. |
| U00811/E00811 | Some pages were not correctly transmitted when resending in the ECM mode. |

(2-4) Error code table: U009XX Page reception error

| Error codes | Content |
|----------------------|--|
| U00900/E00900 | RTN or PIN signal was sent since some pages were not received correctly. |
| U00910/E00910 | Some pages were not correctly received when receiving again in the ECM mode. |

(2-5) Error code table: U010XX G3 transmission error

| Error codes | Content |
|----------------------|---|
| U01000/E01000 | FTT signal was received after sending TCF signal at 2400bps (repeated the specified times). Or RTN signal was received in response to Q signal (except EOP) when transmitting at 2400bps. |
| U01001/E01001 | The function indicated by the DIS signal does not match the own machine. |
| U01016/E01016 | After sending the EOM signal, the MCF signal was received but no DIS signal and it lead to the T1 timeout. |
| U01019/E01019 | A message signal cannot be received after sending the CNC signal and command resending time is exceeded (between own models). |
| U01020/E01020 | A message signal cannot be received after sending the CTC signal and command resending time is exceeded (ECM). |
| U01021/E01021 | could not receive the message signal after sending the EOR?Q signal and exceeded the command resending time (ECM). |
| U01022/E01022 | A message signal could not received and command resending time is exceeded after sending the RR signal (ECM). |
| U01028/E01028 | The T5 timeout is detected at the ECM transmission (ECM). |
| U01052/E01052 | DCN signal was received after sending RR signal. |
| U01080/E01080 | PIP signal was received after sending PPS.NULL signal. |
| U01092/E01092 | Communication was interrupted since the combination of symbol speed and communication speed was impossible in V.34 mode. |
| U01093/E01093 | A DCN or other inappropriate signal was received during phase B of transmission. |
| U01094/E01094 | The preset number of command retransfers for DCS/NSS signals was exceeded during phase B of transmission. |
| U01095/E01095 | No relevant signal was received after transmission of a (PPS) Q signal, and the preset number of command retransfers was exceeded during phase D of transmission. |
| U01096/E01096 | A DCN signal or invalid command was received during phase D of transmission. |
| U01097/E01097 | Command resending time is exceeded after sending the RR signal. Or no response is received. |

(2-6) Error code table: U011XX G3 reception error

| Error codes | Content |
|----------------------|---|
| U01100/E01100 | The function indicated by the DCS signal does not match the own machine. |
| U01101/E01101 | Functions indicated by the NSS signal (except communicating type) does not match the own machine. |
| U01102/E01102 | The DTC (NSC) signal was received without transmission data at the own machine. |
| U01110/E01110 | No response is received after sending DIS signal. |
| U01111/E01111 | No response is received after sending DTC (NSC) signal. |
| U01113/E01113 | No response is received after sending FTT signal. |
| U01125/E01125 | No response is received after sending the CNS signal. |
| U01129/E01129 | No response was received after sending SPA signal (Short protocol). |
| U01141/E01141 | DCN signal is received after sending DTC signal. |
| U01143/E01143 | DCN signal is received after sending FTT signal. |
| U01155/E01155 | DCN signal was received after sending SPA signal (Short protocol). |
| U01160/E01160 | When receiving, the maximum transmission time per line has exceeded. |
| U01162/E01162 | When receiving, reception is interrupted by modem error. |
| U01191/E01191 | Communication was interrupted since an error occurred during the image data reception sequences in V.34 mode. |
| U01193/E01193 | No response is received, DCN or invalid command is received in Phase C/D during reception. |
| U01194/E01194 | The DCN signal was received at Phase B during reception. |
| U01195/E01195 | No message is received at Phase C during reception. |
| U01196/E01196 | The error line control over or decoding error occurred in the message during reception. |

(2-7) Error code table: U017XX V.34 transmission error

| Error codes | Content |
|----------------------|--|
| U01700/E01700 | A communication error occurred at Phase 2 (line probing). |
| U01720/E01720 | A communication error occurred at Phase 4 (modem parameter exchange). |
| U01721/E01721 | Communication was interrupted since the communication speed was not available to commonly use with the destination transmitter machine. (Or interrupted) |

U01700/E01700: INF00/A/Abar?B/Bbar in case of polling?/INF0h could not be detected, etc.

A communication error that occurs at the transmitting unit in the period after transmission of INFO0 and before entering phase 3 (primary channel equivalent device training).

U01720/E01720: PPh/ALT/MPh/E could not be detected, etc.

A communication error that occurs at the transmitting unit in the period after initiating the control channel and before entering the T.30 process.

U01721/E01721: In case no communication speed is available commonly for sender and receiver when completing the MPh replacement (including the combination of impossible speed and symbol speed), DCN is received from the receiver and the line is disconnected.

(NSF), (CSI) and DIS is sent from the receiver, and the line is disconnected after sending the DCN.

(2-8) Error code table: U018XX V.34 reception error

| Error codes | Content |
|----------------------|---|
| U01800/E01800 | A communication error occurred at Phase 2 (line probing). |
| U01810/E01810 | A communication error occurred at Phase 3 (primary channel equivalent device training). |
| U01820/E01820 | A communication error occurred at Phase 4 (modem parameter exchange). |
| U01821/E01821 | Communication was interrupted since the communication speed was not available to commonly use with the destination transmitter machine. |

U01800/E01800: INF00/B/Bbar?A/Abar in case of polling?/probing tone could not be detected, etc. A communication error occurring from INF00 send to Phase 3 (primary channel equivalent device training) at the receiver.

U01810/E01810: S/Sbar/PP/TRN could not be detected.

A communication error in Phase 3 (primary channel equivalent device training) at the receiver.

U01820/E01820: PPh/ALT/MPh/E could not be detected, etc.

A communication error from entering the control channel at the receiver to entering the T.30 steps in the control channel.

U01821/E01821: In case no communication speed is available commonly for sender and receiver when completing the MPh replacement (including the combination of impossible speed and symbol speed) and the line is disconnected by sending DCN to the destination.

(2-9) Error code table: U044XX Encrypted transmission error

| Error codes | Content |
|----------------------|---|
| U04400/E04400 | Communication was interrupted since the encryption key did not match in the encrypted transmission. |
| U04401/E04401 | A call failed since the encryption key was not registered in the encrypted transmission. |

8 PWBs

8-1 Description for PWB (30 ppm model)

(1) Main PWB (MPWB)

(1-1) Connector position




Figure 8-1

(1-2) PWB photograph



Figure 8-2

(1-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|--------------------------|-----|-----------|-------------------------------|
| YC5 Connected to the engine PWB | 1 | GND | - | - | Ground |
| | 2 | 5V3_IL | I | DC5V | DC5V power input |
| | 3 | GND | - | - | Ground |
| | 4 | 3.3V0 | O | DC3.3V | DC3.3V power output |
| | 5 | GND | - | - | Ground |
| | 6 | 5V0 | O | DC5V | DC5V power output |
| | 7 | GND | - | - | Ground |
| | 8 | 24V0 | I | DC24V | DC24V power input |
| YC19 Connected to the controller fan | 1 | 24V0 | O | DC24V | DC24V power input |
| | 2 | FANDRVN | O | - | CONF: On/Off |
| YC2001 Connected to the operation panel PWB | 1 | +5V | O | DC5V | DC5V power output |
| | 2 | +5V | O | DC5V | DC5V power output |
| | 3 | GND | - | - | Ground |
| | 4 | GND | - | - | Ground |
| YC2002 Connected to the operation panel PWB | 1 | GND | - | - | Ground |
| | 2 | PANEL_STAT US | I | DC0V/3.3V | Operation panel status signal |
| | 3 | INT_ENERGY _SAVER_KEY | I | DC0V/3.3V | Energy Saver key: On/Off |
| | 4 | PANEL_RESE T | O | DC0V/3.3V | Operation panel reset signal |
| | 5 | AUDIO | O | Analog | Audio output signal |
| | 6 | LIGHTOFF_P OWERON | O | DC0V/3.3V | Sleep recovery signal |
| | 7 | SHUTDOWN | O | DC0V/3.3V | 24V voltage drop signal |
| | 8 | LED_PROCE SSING_N | O | DC0V/3.3V | Processing LED control signal |
| | 9 | LED_ATTENT ION_N | O | DC0V/3.3V | Attention LED control signal |
| | 10 | LED_MEMOR Y_N | O | DC0V/3.3V | Memory LED control signal |
| | 11 | SUSPEND_P OWER | O | DC5V | DC5V power input from MPWB |
| | 12 | ENERGY_SA VE | O | DC0V/3.3V | Energy save signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--------------------------------------|-----|----------------|-----|-----------|---------------------------|
| YC2002 | 13 | BEEP_POWERON | O | DC0V/3.3V | Sleep recovery signal |
| Connected to the operation panel PWB | 14 | SECOND_TRAY_SW | O | DC0V/3.3V | JEPS: On/Off |
| | 15 | GND | - | - | Ground |
| YC2007 | 1 | VBUS | O | DC5V | DC5V power output |
| Connected to the USB host | 2 | DATA- | I/O | LVDS | USB data signal |
| | 3 | DATA+ | I/O | LVDS | USB data signal |
| | 4 | NC | - | - | Not used |
| | 5 | GND | - | - | Ground |
| YC2008 | 1 | VBUS | O | DC5V | DC5V power output |
| Connected to the IC card reader | 2 | DATA- | I/O | LVDS | USB data signal |
| | 3 | DATA+ | I/O | LVDS | USB data signal |
| | 4 | NC | - | - | Not used |
| | 5 | GND | - | - | Ground |
| YC2011 | 1 | VBUS | O | DC5V | DC5V power output |
| Connected to the operation panel PWB | 2 | DATA+ | I/O | - | USB data signal |
| | 3 | DATA- | I/O | - | USB data signal |
| | 4 | NC | - | - | Not used |
| | 5 | GND | - | - | Ground |
| YC2014 | 1 | 12V2 | O | DC12V | DC12V power output |
| Connected to the CCD PWB | 2 | 12V2 | O | DC12V | DC12V power output |
| | 3 | NC | - | - | Not used |
| | 4 | 5V2_C | O | DC5V | DC5V power output |
| | 5 | 5V2_C | O | DC5V | DC5V power output |
| | 6 | NC | - | - | Not used |
| | 7 | GND | - | - | Ground |
| | 8 | CCDOSR | I | Analog | Image analog signal RED |
| | 9 | GND | - | - | Ground |
| | 10 | CCDOSG(EVEN) | I | Analog | Image analog signal GREEN |
| | 11 | GND | - | - | Ground |
| | 12 | CCDOSB(ODD) | I | Analog | Image analog signal BLUE |
| | 13 | GND | - | - | Ground |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--------------------------|---------------|----------|-----|-----------|--|
| YC2014 | 14 | CCDSW | O | DC0V/3.3V | CCD color/BW switching signal |
| Connected to the CCD PWB | 15 | CCDSH | O | DC0V/3.3V | Shift gate signal |
| | 16 | GND | - | - | Ground |
| | 17 | GND | - | - | Ground |
| | 18 | CCDPH1+ | O | LVDS | CCD shift register clock signal |
| | 19 | CCDPH1- | O | LVDS | CCD shift register clock signal |
| | 20 | GND | - | - | Ground |
| | 21 | CCDCP- | O | LVDS | CCD clamp gate signal- |
| | 22 | CCDCP+ | O | LVDS | CCD clamp gate signal+ |
| | 23 | GND | - | - | Ground |
| | 24 | CCDRS+ | O | LVDS | CCD reset gate signal+ |
| | 25 | CCDRS- | O | LVDS | CCD reset gate signal- |
| | 26 | GND | - | - | Ground |
| | 27 | NC | - | - | Not used |
| | 28 | 3.3V2 | O | DC3.3V | DC3.3V power output |
| | 29 | HP_SWN | I | DC0V/3.3V | HPS: On/Off |
| | 30 | GND | - | - | Ground |
| | 31 | M_LED_C | I | DC0 to 2V | LED cathode |
| | 32 | M_LED_A | O | DC3V | LED anode |
| | YC2016 | 1 | GND | - | - |
| Connected to the APC PWB | 2 | GND | - | - | Ground |
| | 3 | LDERR | O | | Laser power Y |
| | 4 | Vcont_Y | O | Analog | APCPWB laser power reference voltage Y |
| | 5 | GND | - | - | Ground |
| | 6 | DATA_Y | O | LVDS+ | Video data signal Y |
| | 7 | DATAB_Y | O | LVDS- | Video data signal Y |
| | 8 | GND | - | - | Ground |
| | 9 | ENABLE_Y | O | DC0V/3.3V | APCPWB laser enable signal Y |
| | 10 | S/H_Y | O | | Sample hold Y |
| | 11 | Vcont_C | O | Analog | APCPWB laser power reference voltage C |
| | 12 | GND | - | - | Ground |
| | 13 | DATA_C | O | LVDS+ | Video data signal C |
| | 14 | DATAB_C | O | LVDS- | Video data signal C |
| | 15 | GND | - | - | Ground |
| | 16 | ENABLE_C | O | DC0V/3.3V | APCPWB laser enable signal C |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---------------------------------|-----|----------|-----|-----------|--|
| YC2016 | 17 | S/H_C | O | DC0V/3.3V | Sample hold C |
| Connected to the APC PWB | 18 | Vcont_M | O | Analog | APCPWB laser power reference voltage M |
| | 19 | GND | - | - | Ground |
| | 20 | DATA_M | O | LVDS+ | Video data signal M |
| | 21 | DATAB_M | O | LVDS- | Video data signal M |
| | 22 | GND | - | - | Ground |
| | 23 | ENABLE_M | O | DC0V/3.3V | APCPWB laser enable signal M |
| | 24 | S/H_M | O | DC0V/3.3V | Sample hold M |
| | 25 | Vcont_K | O | Analog | APCPWB laser power reference voltage K |
| | 26 | GND | - | - | Ground |
| | 27 | DATA_K | O | LVDS+ | Video data signal K |
| | 28 | DATAB_K | O | LVDS- | Video data signal K |
| | 29 | GND | - | - | Ground |
| | 30 | ENABLE_K | O | DC0V/3.3V | APCPWB laser enable signal K |
| | 31 | S/H_K | O | DC0V/3.3V | Sample hold K |
| | 32 | 5V | O | DC0V/5V | Output DC5V power to APC/BD PWB |
| | 33 | 5V | O | DC0V/5V | Output DC5V power to APC/BD PWB |
| | 34 | 5V | O | DC0V/5V | Output DC5V power to APC/BD PWB |
| | 35 | 5V | O | DC0V/5V | Output DC5V power to APC/BD PWB |
| | 36 | BD | I | DC0V/3.3V | BD signal |
| | 37 | TH | I | DC0V/3.3V | LSU thermistor |
| 38 | GND | - | - | Ground | |
| 39 | GND | - | - | Ground | |
| 40 | GND | - | - | Ground | |
| YC6001 | 1 | VBUS1 | O | DC5V | DC5V power output to IFPWB |
| Connected to the KUIO relay PWB | 2 | USB_DN1 | I/O | - | USB data signal |
| | 3 | USB_DP1 | I/O | - | USB data signal |
| | 4 | GND | - | - | Ground |
| | 5 | AUDIO1 | I | Analog | AUDIO signal |
| | 6 | WAKEUP1 | O | DC0V/3.3V | Control signal |
| | 7 | RESET1 | I | DC0V/3.3V | Reset signal |
| | 8 | GND | - | - | Ground |
| | 9 | VBUS0 | O | DC5V | DC5V power output to IFPWB |
| | 10 | USB_DN0 | I/O | - | USB data signal |
| | 11 | USB_DP0 | I/O | - | USB data signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---------------------------------|-----|------------|-----|----------------------|-----------------------------------|
| YC6001 | 12 | GND | - | - | Ground |
| Connected to the KUIO relay PWB | 13 | AUDIO0 | I | Analog | AUDIO signal |
| | 14 | WAKEUP0 | O | DC0V/3.3V | Control signal |
| | 15 | RESET | I | DC0V/3.3V | Reset signal |
| YC6002 | 1 | GND | - | - | Ground |
| Connected to the KUIO relay PWB | 2 | 5V_CUT0 | I | DC0V/5V | DC5V cut signal/power |
| | 3 | GND | - | - | Ground |
| | 4 | 5V | O | DC5V | DC5V power output to KUIORPWB |
| | 5 | GND | - | - | Ground |
| | 6 | 5V_CUT1 | I | DC0V/5V | DC5V cut signal/power |
| YC6003 | 1 | GND | - | - | Ground |
| Connected to the engine PWB | 2 | 24V2 | I | DC24V | DC24V power input |
| YC6004 | 1 | LDERR | O | DC0V/3.3V | LD overcurrent detection signal |
| Connected to the engine PWB | 2 | GND | - | - | Ground |
| | 3 | LSU_THERM | O | Analog | LSU thermistor voltage |
| | 4 | GND | - | - | Ground |
| | 5 | G6_EG_SCLK | O | DC0V/ 3.3V(pulse) | G6 clock signal |
| | 6 | G6_EG_SI | O | DC0V/ 3.3V(pulse) | G6 data output signal |
| | 7 | G6_EG_SDIR | I | DC0V/ 3.3V(pulse) | G6 communication direction signal |
| | 8 | G6_EG_SBSY | I | DC0V/ 3.3V(pulse) | G6 communication busy signal |
| | 9 | G6_EG_SO | I | DC0V/ 3.3V(pulse) | G6 data input signal |
| | 10 | G6_EG_IRN | I | DC0V/3.3V | G6 interrupt signal |
| | 11 | GND | - | - | Ground |
| | 12 | MAIN_SDA | I/O | DC0V/ 3.3V(pulse) | Main communication data signal |
| | 13 | MAIN_SCLK | I | DC0V/ 3.3V(pulse) | Main communication clock signal |
| | 14 | GND | - | - | Ground |
| | 15 | HLD_ENG | O | DC0V/3.3V | Engine stop signal |
| | 16 | HLD_SCAN | O | DC0V/3.3V | Scanner stop signal |
| | 17 | C2E_INT | O | DC0V/3.3V | Sleep recovery signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|-----------------------------------|-----|---------------------|-----|----------------------|---|
| YC6004 | 18 | PVSYNC | I | DC0V/3.3V | Vertical synchronizing signal |
| Connected to the engine PWB | 19 | GND | - | - | Ground |
| | 20 | OFFMODE | I | DC3.3V | Off mode signal |
| | 21 | GND | - | - | Ground |
| | 22 | SAPPHIRE_S CLK | I | DC0V/ 3.3V(pulse) | Clock signal |
| | 23 | SAPPHIRE_SI | O | DC0V/ 3.3V(pulse) | Serial communication data output signal |
| | 24 | SAPPHIRE_S O | I | DC0V/ 3.3V(pulse) | Serial communication data input signal |
| | 25 | SAPPHIRE_R DY | O | DC0V/3.3V | Ready signal |
| | 26 | SAPPHIRE_S EL | I | DC0V/3.3V | Select signal |
| | 27 | SAPPHIRE_O VMON | I | DC0V/3.3V | Sub-scanning monitoring signal |
| | 28 | SAPPHIRE_P AGEST | I | DC0V/3.3V | Sub-scanning reference signal |
| | 29 | JS_LED | I | DC0V/3.3V | JOB separator LED lighting signal |
| | 30 | HP_SWN | O | DC0V/3.3V | HPS: On/Off |

(2) Engine PWB (EPWB)

(2-1) Connector position




Figure 8-3

(2-2) PWB photograph



Figure 8-4

(2-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|---------------------------|-----|---------------------|-----|----------------------|---|
| YC3 | 1 | HP_SWN | I | DC0V/3.3V | HPS: On/Off |
| Connected to the main PWB | 2 | JS_LED | O | DC0V/5V | JOB separator LED lighting signal |
| | 3 | SAPPHIRE_P AGEST | O | DC0V/3.3V | Sub-scanning reference signal |
| | 4 | SAPPHIRE_O VMON | I | DC0V/3.3V | Sub-scanning monitoring signal |
| | 5 | SAPPHIRE_S EL | O | DC0V/3.3V | Select signal |
| | 6 | SAPPHIRE_R DY | I | DC0V/3.3V | Ready signal |
| | 7 | SAPPHIRE_S O | O | DC0V/ 3.3V(pulse) | Serial communication data output signal |
| | 8 | SAPPHIRE_SI | I | DC0V/ 3.3V(pulse) | Serial communication data input signal |
| | 9 | SAPPHIRE_S CLK | O | DC0V/ 3.3V(pulse) | Clock signal |
| | 10 | GND | - | - | Ground |
| | 11 | OFFMODE | O | DC0V/3.3V | Off mode signal |
| | 12 | GND | - | - | Ground |
| | 13 | PVSYNC | O | | Vertical synchronizing signal |
| | 14 | C2E_INT | I | DC0V/3.3V | Sleep recovery signal |
| | 15 | HLD_SCAN | I | DC0V/3.3V | Scanner stop signal |
| | 16 | HLD_ENG | I | DC0V/3.3V | Engine stop signal |
| | 17 | GND | - | - | Ground |
| | 18 | MAIN_SCLK | O | DC0V/ 3.3V(pulse) | Main communication clock signal |
| | 19 | MAIN_SDA | I/O | DC0V/ 3.3V(pulse) | Main communication data signal |
| | 20 | GND | - | - | Ground |
| | 21 | G6_EG_IRN | O | DC0V/3.3V | G6 communication interrupt signal |
| | 22 | G6_EG_SO | O | DC0V/ 3.3V(pulse) | G6 communication data output signal |
| | 23 | G6_EG_SBSY | O | DC0V/3.3V | G6 communication busy signal |
| | 24 | G6_EG_SDIR | O | DC0V/3.3V | G6 communication direction signal |
| | 25 | G6_EG_SI | I | DC0V/ 3.3V(pulse) | G6 communication data input signal |
| | 26 | G6_EG_SCLK | I | DC0V/ 3.3V(pulse) | G6 communication clock signal |
| | 27 | GND | - | - | Ground |
| | 28 | LSU_THERM | I | Analog | LSU thermistor voltage |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|--------------|-----|----------------------|----------------------------------|
| YC3 | 29 | GND | - | - | Ground |
| Connected to the main PWB | 30 | LDERR | I | DC0V/3.3V | LD overcurrent detection signal |
| YC4 | 1 | 24V0 | O | DC24V | DC24V power output to MPWB |
| Connected to the main PWB | 2 | GND | - | - | Ground |
| | 3 | 5V0 | I | DC5V | DC5V power input from MPWB |
| | 4 | GND | - | - | Ground |
| | 5 | 3.3V0 | I | DC3.3V | DC3.3V power input from MPWB |
| | 6 | GND | - | - | Ground |
| | 7 | 5V3_IL | O | DC5V | DC5V power output to MPWB |
| | 8 | GND | - | - | Ground |
| YC5 | 1 | +24V2 | O | DC24V | DC24V power output to PM |
| Connected to the polygon motor, cleaning motor | 2 | GND | - | - | Ground |
| | 3 | POLREM | O | DC0V/5V | PM remote signal |
| | 4 | POLRDYN | I | DC0V/3.3V | PM synchronizing signal |
| | 5 | PDLCLK | O | DC0V/5V(pulse) | PM clock signal |
| | 6 | LSU_CL_MOT 2 | O | DC0V/24V(pulse) | CLM drive control signal |
| | 7 | LSU_CL_MOT 1 | O | DC0V/24V(pulse) | CLM drive control signal |
| | 8 | 3.3V2_LED | - | - | Not used |
| | 9 | GND | - | - | Not used |
| YC6 | 1 | GND | - | - | Ground |
| Connected to the drum/developer relay PWB | 2 | VIBR_MOT_REM | O | DC0V/3.3V | VIBM remote signal |
| | 3 | TCSSENS_Y | I | Analog | TS-Y detection signal |
| | 4 | TCSSENS_C | I | Analog | TS-C detection signal |
| | 5 | TCSSENS_M | I | Analog | TS-M detection signal |
| | 6 | ERS_CL_REM | O | DC0V/3.3V | Eraser CL remote signal |
| | 7 | GND | - | - | Ground |
| | 8 | 3.3V2 | O | DC3.3V | DC3.3V power output to DR/DLPPWB |
| | 9 | EEP_SCL | O | DC0V/ 3.3V(pulse) | EEPROM clock signal |
| | 10 | EEP_SDA | I/O | DC0V/ 3.3V(pulse) | EEPROM data I/O signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|--------------|-----|----------------|---|
| YC6 Connected to the drum/developer relay PWB | 11 | 24V2 | O | DC24V | DC24V power output to DR/DLPPWB |
| | 12 | GND | - | - | Ground |
| | 13 | DLP_TH | I | Analog | Developer thermistor voltage |
| | 14 | TCSENS_Bk | I | Analog | TS-K detection signal |
| | 15 | ERS_Bk_REM | O | DC0V/24V | Eraser Bk remote signal |
| YC7 Connected to the fuser sensor, fuser release sensor, fuser thermistor 1, fuser thermistor 2, transfer belt release sensor 1, transfer belt release sensor 2 | 1 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to ES |
| | 2 | GND | - | - | Ground |
| | 3 | FSR_JAM_SENS | I | DC0V/3.3V | ES: On/Off |
| | 4 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to FUPRS |
| | 5 | GND | - | - | Ground |
| | 6 | FSR_RLS_SENS | I | DC0V/3.3V | FUPRS: On/Off |
| | 7 | GND | - | - | Ground |
| | 8 | MAIN_TH2 | I | Analog | Non-contact thermistor voltage (detection) |
| | 9 | MAIN_TH1 | I | Analog | Non-contact thermistor voltage (compensation) |
| | 10 | GUIDE_TH2 | I | Analog | Contact thermistor voltage |
| | 11 | GND | - | - | Ground |
| | 12 | FUS_DET | I | DC0V/3.3V | Fuser unit connection signal |
| | 13 | GND | - | - | Ground |
| | 14 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to TCBRS1 |
| | 15 | GND | - | - | Ground |
| | 16 | 3REJECT_SENS | I | DC0V/3.3V | TCBRS1: On/Off |
| | 17 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to TCBRS2 |
| | 18 | GND | - | - | Ground |
| | 19 | 4REJECT_SENS | I | DC0V/3.3V | TCBRS2: On/Off |
| YC8 Connected to the high voltage PWB | 1 | 24V3_IL | O | DC24V | 24V power output |
| | 2 | 24V3_IL | O | DC24V | 24V power output |
| | 3 | DACSLD1 | O | DC0V/5V | DAC load signal 1 |
| | 4 | DACSLD2 | O | DC0V/5V | DAC load signal 2 |
| | 5 | DACSCLK | O | DC0V/5V(pulse) | DAC clock signal |
| | 6 | SGND | - | - | Ground |
| | 7 | DACSDI | O | DC0V/5V(pulse) | DAC data signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|----------------|---------------|-----------|----------------------|---|
| YC8 | 8 | HVREM | O | DC0V/24V | Secondary transfer (reverse) / PB remote signal |
| Connected to the high voltage PWB | 9 | HVCLK | O | DC0V/10V | Developer clock (SLV) signal |
| | 10 | MISENS | I | Analog | Main charger (K) current detection |
| | 11 | GND | - | - | Ground |
| | 12 | GND | - | - | Ground |
| YC10 | A1 | 5V2 | O | DC5V | 5V power output |
| Connected to the RFID, eject fan motor, transfer release motor, waste toner box switch, waste toner detection sensor, temperature/humidity sensor, developer fan motor 3, developer fan motor 4 | A2 | 3.3V2 | O | DC3.3V | 3.3V power output |
| | A3 | RFID_SCL | O | DC0V/ 3.3V(pulse) | RFID communication clock signal |
| | A4 | GND | - | - | Ground |
| | A5 | RFID_SDA | I/O | DC0V/3.3V | RFID communication data signal |
| | A6 | 3.3V2 | O | DC3.3V | 3.3V power output |
| | A7 | GND | - | - | Ground |
| | A8 | SUB_SDA | I/O | DC0V/ 3.3V(pulse) | Communication data signal |
| | A9 | SUB_SCL | O | DC0V/ 3.3V(pulse) | Communication clock signal |
| | A10 | BELT_FAN_REM | - | - | Not used |
| | A11 | 24V2 | - | - | Not used |
| | A12 | WTNR_FAN | O | DC0V/24V | TFM: On/Off |
| | A13 | 24V2 | O | DC24V | 24V power output |
| | A14 | NC | - | - | Not used |
| | A15 | NC | - | - | Not used |
| | A16 | 24V2 | O | DC24V | 24V power output |
| | A17 | EXIT_FAN | O | DC0V/24V | EFM: On/Off |
| | B1 | BELT_RLS_REMA | O | DC0V/24V | TCBRM: On/Off |
| | B2 | BELT_RLS_REMB | O | DC0V/24V | TCBRM: On/Off |
| | B3 | GND | - | - | Ground |
| | B4 | WTNR_SET_SENS | I | DC0V/3.3V | WTSSW: On/Off |
| B5 | WTNR_LED_3.3V2 | O | DC3.3V | 3.3V power output | |
| B6 | WTNR_LED | O | DC0V/3.3V | WST(LED): On/Off | |
| B7 | WTNR_TR_3.3V2 | O | DC3.3V | 3.3V power output | |

| Connector | Pin | Signal | I/O | Voltage | Description |
|-------------|-----|------------------|-----|-----------|--------------------------------------|
| YC10 | B8 | WTNR_TR | I | Analog | WST detection voltage |
| | B9 | HUMCLK | O | DC0V/3.3V | TEMS clock signal |
| | B10 | HUMOUT | I | Analog | TEMS (humidity) detection voltage |
| | B11 | GND | - | - | Ground |
| | B12 | AIRTEMP | I | Analog | TEMS (temperature) detection voltage |
| | B13 | DLP_FAN3 | O | DC0V/24V | DLPFM3: On/Off |
| | B14 | 24V2 | O | DC24V | 24V power output |
| | B15 | DLP_FAN4 | O | DC0V/24V | DLPFM4: On/Off |
| | B16 | 24V2 | O | DC24V | 24V power output |
| | B17 | NC | - | - | Not used |
| YC12 | 1 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to PS |
| | 2 | GND | - | - | Ground |
| | 3 | PAPEMP_SE NS | I | DC0V/3.3V | PS: On/Off |
| | 4 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to PGS1 |
| | 5 | GND | - | - | Ground |
| | 6 | PAPVL1_SEN S | I | DC0V/3.3V | PGS1: On/Off |
| | 7 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to PGS2 |
| | 8 | GND | - | - | Ground |
| | 9 | PAPVL2_SEN S | I | DC0V/3.3V | PGS2: On/Off |
| | 10 | CAS_WID0 | I | DC0V/3.3V | PLSW1: On/Off |
| | 11 | GND | - | - | Ground |
| | 12 | CAS_WID1 | I | DC0V/3.3V | PLSW2: On/Off |
| | 13 | GND | - | - | Ground |
| | 14 | CAS_WID2 | I | DC0V/3.3V | PLSW3: On/Off |
| | 15 | GND | - | - | Ground |
| | 16 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to DUS |
| | 17 | GND | - | - | Ground |
| | 18 | DU1_SENS | I | DC0V/3.3V | DUS: On/Off |
| | 19 | 3.3V3_LED | O | DC3.3V | DC3.3V power output to MPPS |
| | 20 | GND | - | - | Ground |
| | 21 | MPF_SET_SE NS | I | DC0V/3.3V | MPPS: On/Off |
| | 22 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to LS |
| | 23 | GND | - | - | Ground |

| Connector | Pin | Signal | I/O | Voltage | Description |
|-------------|-----|---------------------|-----|-----------|--------------------------------|
| YC12 | 24 | CAS_LIFTUP _SENS | I | DC0V/3.3V | LS: On/Off |
| | 25 | GND | - | - | Ground |
| | 26 | REG_SENS | I | DC0V/3.3V | RS: On/Off |
| | 27 | 3.3V2 | O | DC3.3V | DC3.3V power output to RS |
| | 28 | 24V2 | O | DC24V | DC24V power output to MPSOL |
| | 29 | MPF_SOL_R EM | O | DC0V/24V | MPSOL: On/Off |
| | 30 | NC | - | - | Not used |
| YC13 | A1 | DEV_CL_RE M | O | DC0V/24V | DLPCL-BK: On/Off |
| | A2 | 24V2 | O | DC24V | DC24V power output to DLPCL-BK |
| | A3 | RESIST_CL_ REM | O | DC0V/24V | RCL: On/Off |
| | A4 | 24V2 | O | DC24V | DC24V power output to RCL |
| | A5 | FEED_CL_RE M | O | DC0V/24V | FCL: On/Off |
| | A6 | 24V2 | O | DC24V | DC24V power output to FCL |
| | A7 | MID_CL_REM | O | DC0V/24V | MCL: On/Off |
| | A8 | 24V2 | O | DC24V | DC24V power output to MCL |
| | A9 | DU1_REM | O | DC0V/24V | DUCL: On/Off |
| | A10 | 24V2 | O | DC24V | DC24V power output to DUCL |
| | B1 | +3.3V2 | O | DC3.3V | DC3.3V power output to IDS1 |
| | B2 | REG_F_LED | O | Analog | IDS1 control signal |
| | B3 | GND | - | - | Ground |
| | B4 | REG_SENS_ F_P | I | Analog | IDS1 detection signal |
| | B5 | REG_SENS_ F_S | I | Analog | IDS1 detection signal |
| | B6 | +3.3V2 | O | DC3.3V | DC3.3V power output to IDS2 |
| | B7 | REG_R_LED | O | Analog | IDS2 control signal |
| | B8 | GND | - | - | Ground |
| | B9 | REG_SENS_ R_P | I | Analog | IDS2 detection signal |
| | B10 | REG_SENS_ R_S | I | Analog | IDS2 detection signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|---------------|-----|----------------|-------------------------------|
| YC14 Connected to the transfer belt fan motor, container motor (BK), container motor (M), container motor (C), container motor (Y), container sensor (BK), container sensor (M), container sensor (C), container sensor (Y) | 1 | 24V2 | O | DC24V | DC24V power output to TM-Y |
| | 2 | TMOT_Y_DIR | O | DC0V/24V | TM-Y drive control signal |
| | 3 | 24V2 | O | DC24V | DC24V power output to TM-C |
| | 4 | TMOT_C_DIR | O | DC0V/24V | TM-C drive control signal |
| | 5 | 24V2 | O | DC24V | DC24V power output to TM-M |
| | 6 | TMOT_M_DIR | O | DC0V/24V | TM-M drive control signal |
| | 7 | 24V2 | O | DC24V | DC24V power output to TM-K |
| | 8 | TMOT_BK_DIR | O | DC0V/24V | TM-K drive control signal |
| | 9 | 3.3V2_LED | O | DC3.3V | DC3.3V power output CS-Y |
| | 10 | GND | - | - | Ground |
| | 11 | PULSE_SENS_Y | I | DC0V/3.3V | CL-Y: On/Off |
| | 12 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to CS-C |
| | 13 | GND | - | - | Ground |
| | 14 | PULSE_SENS_C | I | DC0V/3.3V | CL-C: On/Off |
| | 15 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to CS-M |
| | 16 | GND | - | - | Ground |
| | 17 | PULSE_SENS_M | I | DC0V/3.3V | CL-M: On/Off |
| | 18 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to CS-K |
| | 19 | GND | - | - | Ground |
| | 20 | PULSE_SENS_BK | I | DC0V/3.3V | CS-K: On/Off |
| YC15 Connected to the transfer motor, developer motor (BK) | 1 | 24V2_IL | O | DC24V | DC24V power output to TCM |
| | 2 | GND | - | - | Ground |
| | 3 | IMAGE_MOT_REM | O | DC0V/5V | TCM remote signal |
| | 4 | IMAGE_MOT_CLK | O | DC0V/5V(pulse) | TCM clock signal |
| | 5 | IMAGE_MOT_RDY | I | DC0V/3.3V | TCM synchronizing signal |
| | 6 | IMAGE_MOT_DIR | O | DC0V/5V | TCM rotation switching signal |
| | 7 | 24V2_IL | O | DC24V | DC24V power output to DLPM-K |
| | 8 | GND | - | - | Ground |
| | 9 | FEED_MOT_REM | O | DC0V/5V | DLPM-K remote signal |

| Connector | Pin | Signal | I/O | Voltage | Description | |
|-------------|---|--------------|--------------|-----------------|----------------------------------|--------------------------------------|
| YC15 | 10 | FEED_MOT_CLK | O | DC0V/5V(pulse) | DLPM-K clock signal | |
| | Connected to the transfer motor, developer motor (BK) | 11 | FEED_MOT_RDY | I | DC0V/3.3V | DLPM-K synchronizing signal |
| | | 12 | FEED_MOT_DIR | O | DC0V/5V | DLPM-K rotation switching signal |
| YC16 | 1 | 24V2_IL | O | DC24V | DC24V power output to DLPM-M/C/Y | |
| | Connected to the developer motor (M/C/Y), drum motor (BK) | 2 | GND | - | - | Ground |
| | | 3 | DLPC_MOT_REM | O | DC0V/5V | DLPM-M/C/Y remote signal |
| | | 4 | DLPC_MOT_CLK | O | DC0V/5V(pulse) | DLPM-M/C/Y clock signal |
| | | 5 | DLPC_MOT_RDY | I | DC0V/3.3V | DLPM-M/C/Y synchronizing signal |
| | | 6 | DLPC_MOT_DIR | O | DC0V/5V | DLPM-M/C/Y rotation switching signal |
| | | 7 | 24V2_IL | O | DC24V | DC24V power output to DRM-K |
| | | 8 | GND | - | - | Ground |
| | | 9 | DRMK_MOT_REM | O | DC0V/5V | DRM-K remote signal |
| | | 10 | DRMK_MOT_CLK | O | DC0V/5V(pulse) | DRM-K clock signal |
| | | 11 | DRMK_MOT_RDY | I | DC0V/3.3V | DRM-K synchronizing signal |
| | | 12 | DRMK_MOT_DIR | O | DC0V/5V | DRM-K rotation switching signal |
| | | 13 | NC | - | - | Not used |
| YC17 | 1 | FUSER_MOT_B/ | O | DC0V/24V(pulse) | FUM drive control signal | |
| | Connected to the fuser motor | 2 | FUSER_MOT_A/ | O | DC0V/24V(pulse) | FUM drive control signal |
| | | 3 | FUSER_MOT_B | O | DC0V/24V(pulse) | FUM drive control signal |
| | | 4 | FUSER_MOT_A | O | DC0V/24V(pulse) | FUM drive control signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|--------------|-----|-----------------|-------------------------------------|
| YC18 Connected to the drum motor (M/C/Y) | 1 | 24V2_IL | O | DC24V | DC24V power output to DRM-M/C/Y |
| | 2 | GND | - | - | Ground |
| | 3 | DRMC_MOT_REM | O | DC0V/5V | DRM-M/C/Y remote signal |
| | 4 | DRMC_MOT_CLK | O | DC0V/5V(pulse) | DRM-M/C/Y clock signal |
| | 5 | DRMC_MOT_RDY | I | DC0V/3.3V | DRM-M/C/Y synchronizing signal |
| | 6 | DRMC_MOT_DIR | O | DC0V/5V | DRM-M/C/Y rotation switching signal |
| YC19 Connected to the scanner motor | 1 | SCAN_MOT_B3 | O | DC0V/24V(pulse) | SM drive control signal |
| | 2 | SCAN_MOT_A1 | O | DC0V/24V(pulse) | SM drive control signal |
| | 3 | SCAN_MOT_B1 | O | DC0V/24V(pulse) | SM drive control signal |
| | 4 | SCAN_MOT_A3 | O | DC0V/24V(pulse) | SM drive control signal |
| YC20 Connected to the DP original detection sensor, DP original feed sensor, DP registration sensor, DP cover open/close sensor, DP feedshift sensor, DP feed motor, DP conveying motor, DP feedshift motor | A1 | 3.3V3 | O | DC3.3V | DC3.3V power output to DPOS |
| | A2 | GND | - | - | Ground |
| | A3 | DP_SET_SENS | I | DC0V/3.3V | DPOS: On/Off |
| | A4 | 3.3V2 | O | DC3.3V | DC3.3V power output to DPFS |
| | A5 | GND | - | - | Ground |
| | A6 | DP_FEED_SENS | I | DC0V/3.3V | DPFS: On/Off |
| | A7 | 3.3V2 | O | DC3.3V | DC3.3V power output to DPRS |
| | A8 | GND | - | - | Ground |
| | A9 | DP_OPEN_SENS | I | DC0V/3.3V | DPRS: On/Off |
| | A10 | 3.3V2 | O | DC3.3V | DC3.3V power output |
| | A11 | GND | - | - | Ground |
| | A12 | DP_JHP_SENS | I | DC0V/3.3V | DPCOCS: On/Off |
| | A13 | 3.3V2 | O | DC3.3V | DC3.3V power output to DPFSS |
| | A14 | GND | - | - | Ground |
| | A15 | DP_REG_SENS | I | DC0V/3.3V | DPFSS: On/Off |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|------------------|-----|-----------------|------------------------------|
| YC20 Connected to the DP original detection sensor, DP original feed sensor, DP registration sensor, DP cover open/close sensor, DP feedshift sensor, DP feed motor, DP conveying motor, DP feedshift motor | B1 | DP_CONVMO T_B | O | DC0V/24V(pulse) | DPOCM drive control signal |
| | B2 | DP_CONVMO T_B | O | DC0V/24V(pulse) | DPOCM drive control signal |
| | B3 | DP_CONVMO T_A | O | DC0V/24V(pulse) | DPOCM drive control signal |
| | B4 | DP_CONVMO T_A | O | DC0V/24V(pulse) | DPOCM drive control signal |
| | B5 | DP_FEEDMO T_B | O | DC0V/24V(pulse) | DPOFM drive control signal |
| | B6 | DP_FEEDMO T B | O | DC0V/24V(pulse) | DPOFM drive control signal |
| | B7 | DP_FEEDMO T_A | O | DC0V/24V(pulse) | DPOFM drive control signal |
| | B8 | DP_FEEDMO T_A | O | DC0V/24V(pulse) | DPOFM drive control signal |
| | B9 | DP_SEPMOT _B | O | DC0V/24V(pulse) | DPSPM drive control signal |
| | B10 | DP_SEPMOT _A | O | DC0V/24V(pulse) | DPSPM drive control signal |
| | B11 | DP_SEPMOT _B | O | DC0V/24V(pulse) | DPSPM drive control signal |
| | B12 | DP_SEPMOT _A | O | DC0V/24V(pulse) | DPSPM drive control signal |
| | B13 | NC | - | - | Not used |
| | B14 | NC | - | - | Not used |
| | B15 | NC | - | - | Not used |
| YC21 Connected to the developer fan motor 1, developer fan motor 2, lift motor, clutch fan motor, cassette heater PWB | 1 | 24V2 | O | DC24V | DC24V power output to DLPFM1 |
| | 2 | DLP_FAN1 | O | DC0V/24V | DLPFM1: On/Off |
| | 3 | 24V2 | O | DC24V | DC24V power output to DLPFM2 |
| | 4 | DLP_FAN2 | O | DC0V/24V | DLPFM2: On/Off |
| | 5 | LIFT_MOT_D R | O | DC0V/24V | LM drive control signal |
| | 6 | LIFT_MOT_R ET | O | DC0V/24V | LM drive control signal |
| | 7 | CL_FAN | O | DC0V/24V | CONTFM: On/Off |
| | 8 | 24V2 | O | DC24V | DC24V power output |
| | 9 | 5V2 | O | DC5V | DC5V power output |
| | 10 | GND | - | - | Ground |

| Connector | Pin | Signal | I/O | Voltage | Description |
|-------------|-----|----------------|-----|----------------------|--|
| YC22 | 1 | GND | - | - | Ground |
| | 2 | 24V2 | O | DC24V | DC24V power output to PFPWB |
| YC23 | 1 | PF_CAS_OPEN | I | DC0V/3.3V | Cassette open/close signal output |
| | 2 | PAUSE | O | DC0V/3.3V | Pause signal |
| | 3 | PF_SDO | O | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | 4 | PF_SDI | I | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | 5 | PF_RDY | I | DC0V/3.3V | Ready signal |
| | 6 | PF_CLK | O | DC0V/ 3.3V(pulse) | Clock signal |
| | 7 | PF_SEL2 | O | DC0V/3.3V | Cassette 3 select signal |
| | 8 | PF_SEL1 | O | DC0V/3.3V | Cassette 2 select signal |
| | 9 | GND | - | - | Ground |
| | 10 | 3.3V3 | O | DC3.3V | DC3.3V power output to PF |
| | 11 | PF_VER_SENS | I | DC0V/3.3V | PFCS1: On/Off |
| YC24 | A1 | BRIDGE_FAN | O | DC0V/3.3V | BRFM: On/Off |
| | A2 | BRIDGE REM | O | DC0V/3.3V | Bridge motor remote signal |
| | A3 | BRIDGE CLK | O | DC0V/ 3.3V(pulse) | Bridge motor clock signal |
| | A4 | BRIDGE_PH0 | O | DC0V/3.3V | Bridge motor excitation switching signal 1 |
| | A5 | BRIDGE_PH1 | O | DC0V/3.3V | Bridge motor excitation switching signal 2 |
| | A6 | BRIDGE_DET | I | DC0V/3.3V | Bridge presence detection signal |
| | A7 | BRIDGE_SENS1 | I | DC0V/3.3V | Bridge conveying detection signal 1 |
| | A8 | BRIDGE_SENS2 | I | DC0V/3.3V | Bridge conveying detection signal 2 |
| | A9 | BREDGE_OPEN_SW | I | DC0V/3.3V | Bridge open detection signal |
| | A10 | GND | - | - | Ground |
| | A11 | GND | - | - | Ground |
| | A12 | 3.3V2 | O | DC3.3V | DC3.3V power output to BRMPWB |
| | A13 | 24V2 | O | DC24V | DC24V power output to BRMPWB |
| | A14 | DF_RDY | O | DC0V/3.3V | Ready signal |
| | A15 | DF_SEL | O | DC0V/3.3V | Select signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----------------|----------------|-----------|----------------------|----------------------------------|
| YC24 | A16 | DF_SDO | O | DC0V/ 3.3V(pulse) | Serial communication data signal |
| Connected to the AK, MT, inner finisher, eject motor, eject feedshift solenoid, upper eject full sensor, lower eject full sensor, steam removal fan motor, JS paper detection sensor, front cover open/close switch 1 | A17 | DF_SDI | I | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | A18 | NC | - | - | Not used |
| | A19 | DF_DET | I | DC0V/3.3V | Connection detection signal |
| | A20 | DF_CLK | I | DC0V/ 3.3V(pulse) | Clock signal |
| | B1 | CON_FAN | O | DC0V/24V | SFM: On/Off |
| | B2 | 24V2 | O | DC24V | DC24V power output to SFM |
| | B3 | SB_MOT_B1 | O | DC0V/24V(pulse) | EM drive control signal |
| | B4 | SB_MOT_B3 | O | DC0V/24V(pulse) | EM drive control signal |
| | B5 | SB_MOT_A3 | O | DC0V/24V(pulse) | EM drive control signal |
| | B6 | SB_MOT_A1 | O | DC0V/24V(pulse) | EM drive control signal |
| | B7 | 24V2 | O | DC0V/24V | 24V power output to FSSOL |
| | B8 | EJE_SOL_PULL | O | DC0V/24V | FSSOL: On/Off (actuate) |
| | B9 | EJE_SOL_RETURN | O | DC0V/24V | FSSOL: On/Off (keep) |
| | B10 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to EFS1 |
| | B11 | GND | - | - | Ground |
| | B12 | EJE_FULL_UP | I | DC0V/3.3V | EFS1: On/Off |
| | B13 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to EFS2 |
| | B14 | GND | - | - | Ground |
| | B15 | EJE_FULL_DOWN | I | DC0V/3.3V | EFS2: On/Off |
| | B16 | 3.3V3_LED | O | DC3.3V | DC3.3V power output to EPS |
| B17 | GND | - | - | Ground | |
| B18 | EXITUP_PAP_SENS | I | DC0V/3.3V | EPS: On/Off | |
| B19 | FCOVOR_OPEN | I | DC0V/3.3V | FCSW2: On/Off | |
| B20 | GND | - | - | Ground | |
| YC25 | 1 | GND | - | - | Ground |
| Connected to the MT or inner finisher | 2 | GND | - | - | Ground |
| | 3 | 24V2 | O | DC24V | DC24V power output to MBMPWB |
| | 4 | 24V2 | O | DC24V | DC24V power output to MBMPWB |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|-----------|-----|----------------------|------------------------------|
| YC29 | 1 | GND | - | - | Ground |
| Connected to the power supply PWB | 2 | GND | - | - | Ground |
| | 3 | 24V0 | I | DC24V | DC24V power input from PSPWB |
| | 4 | 24V0 | I | DC24V | DC24V power input from PSPWB |
| YC30 | 1 | POWERSW | I | DC0V/3.3V | PSSW: On/Off |
| Connected to the power switch | 2 | GND | - | - | Ground |
| YC31 | 1 | 24V0 | O | DC24V | DC24V power output to RCSW |
| Connected to the right cover open/close switch, front cover open/close switch 1 | 2 | 24V0IL | I | DC24V | DC24V power input from FCSW |
| YC32 | 1 | 24V2 | O | DC24V | DC24V power output to MPWB |
| Connected to the main PWB | 2 | GND | - | - | Ground |
| YC34 | 1 | 24V3_IL | O | DC24V | DC24V power output |
| Connected to the power supply PWB | 2 | LVU_SLEEP | O | DC0V/24V | Sleep signal |
| | 3 | ZCROSS | I | DC0V/ 3.3V(pulse) | Zero cross signal |
| | 4 | RELAYREM | O | DC0V/3.3V | Power relay control signal |
| | 5 | MHREM | O | DC0V/3.3V | Main heater control |
| | 6 | LVU_FAN | O | DC0V/24V | PWBFM: On/Off |
| | 7 | 24V2 | O | DC24V | DC24V power output to PWBFM |

(3) High voltage PWB (HVPWB)

(3-1) Connector position




Figure 8-5

(3-2) PWB photograph




Figure 8-6

(3-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|-----------------------------------|-----|---------|-----|----------------------|--|
| YC1 | 1 | +24V3 | I | DC24V | DC24V power input |
| Connected to the engine PWB | 2 | +24V3 | I | DC24V | DC24V power input |
| | 3 | DACSLD1 | I | DC0V/3.3V | DAC load signal 1 |
| | 4 | DACSLD2 | I | DC0V/3.3V | DAC load signal 2 |
| | 5 | DACSCLK | I | DC0V/ 3.3V(pulse) | DAC clock signal |
| | 6 | SGND | - | - | Ground |
| | 7 | DACSDAT | I | DC0V/ 3.3V(pulse) | DAC data signal |
| | 8 | HVREM | I | DC0V/3.3V | Secondary transfer (reverse) / PB remote signal |
| | 9 | HVCLK | I | DC0V/3.3V | Developer clock (SLV) signal |
| | 10 | MISENS | O | Analog | Main charger (K) current detection |
| | 11 | PGND | - | - | Ground |
| | 12 | PGND | - | - | Ground |

(4) Power supply PWB (PSPWB)

(4-1) Connector position




Figure 8-7

(4-2) PWB photograph



Figure 8-8

(4-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|----------------------------------|-----|------------|-----|------------------|-----------------------------|
| YC101 | 1 | LIVE | I | AC100V | AC power input |
| Connected to the inlet | 2 | NEUTRAL | I | AC100V | AC power input |
| YC102 | 1 | NEUTRAL | O | AC100V | AC power supply to FH |
| Connected to the fuser heater | 2 | NC | - | - | Not used |
| | 3 | LIVE | O | AC100V | AC power supply to FH |
| YC105 | 1 | MHREM | I | DC0V/3.3V | FH: On/Off |
| Connected to the engine PWB | 2 | RELAYREM | I | DC0V/3.3V | Power relay signal |
| | 3 | ZCROSS | O | DC0V/3.3V(pulse) | Zero cross signal |
| | 4 | PSLEEPN | I | DC0V/24V | Sleep signal |
| | 5 | 24V3_IL | I | DC24V | DC24V power input from EPWB |
| CN3 | 1 | DH_LIVE | O | AC100V | AC power supply to CH |
| Connected to the cassette heater | 2 | DH_LIVE | O | AC100V | AC power supply to CH |
| | 3 | NC | - | - | Not used |
| | 4 | NC | - | - | Not used |
| | 5 | DH_NEUTRAL | O | AC100V | AC power supply to CH |
| | 6 | DH_NEUTRAL | O | AC100V | AC power supply to CH |
| CN4 | 1 | 24V0 | O | DC24V | DC24V power output to EPWB |
| Connected to the engine PWB | 2 | 24V0 | O | DC24V | DC24V power output to EPWB |
| | 3 | GND | - | - | Ground |
| | 4 | GND | - | - | Ground |

(5) Operation panel PWB (OPPWB)

(5-1) Connector position




Figure 8-9

(5-2) PWB photograph




Figure 8-10

(5-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|----------------------|-----|---------|-----|----------------------|----------------------------------|
| YC2 | 1 | GND | - | - | Ground |
| Connected to the LCD | 2 | R0 | O | DC0V/3.3V | LCD control signal |
| | 3 | R1 | O | DC0V/3.3V | LCD control signal |
| | 4 | R2 | O | DC0V/3.3V | LCD control signal |
| | 5 | R3 | O | DC0V/3.3V | LCD control signal |
| | 6 | R4 | O | DC0V/3.3V | LCD control signal |
| | 7 | R5 | O | DC0V/3.3V | LCD control signal |
| | 8 | GND | - | - | Ground |
| | 9 | G0 | O | DC0V/3.3V | LCD control signal |
| | 10 | G1 | O | DC0V/3.3V | LCD control signal |
| | 11 | G2 | O | DC0V/3.3V | LCD control signal |
| | 12 | G3 | O | DC0V/3.3V | LCD control signal |
| | 13 | G4 | O | DC0V/3.3V | LCD control signal |
| | 14 | G5 | O | DC0V/3.3V | LCD control signal |
| | 15 | GND | - | - | Ground |
| | 16 | B0 | O | DC0V/3.3V | LCD control signal |
| | 17 | B1 | O | DC0V/3.3V | LCD control signal |
| | 18 | B2 | O | DC0V/3.3V | LCD control signal |
| | 19 | B3 | O | DC0V/3.3V | LCD control signal |
| | 20 | B4 | O | DC0V/3.3V | LCD control signal |
| | 21 | B5 | O | DC0V/3.3V | LCD control signal |
| | 22 | GND | - | - | Ground |
| | 23 | DCLK | O | DC0V/ 3.3V(pulse) | LCD dot clock |
| | 24 | 3.3V | O | DC3.3V | DC3.3V power output to LCD |
| | 25 | 3.3V | O | DC3.3V | DC3.3V power output to LCD |
| | 26 | 3.3V | O | DC3.3V | DC3.3V power output to LCD |
| | 27 | 3.3V | O | DC3.3V | DC3.3V power output to LCD |
| | 28 | DE | O | DC0V/3.3V | LCD data enable signal |
| | 29 | HSYNC | O | DC0V/ 3.3V(pulse) | Horizontal synchronizing signal |
| | 30 | VSYNC | O | DC0V/ 3.3V(pulse) | Vertical synchronizing signal |
| | 31 | LED_EN | O | DC0V/3.3V | LED driver enable signal |
| | 32 | LED_PWM | O | DC0V/3.3V | LED driver PWM signal |
| | 33 | TSC_INT | I | DC0V/3.3V | Panel interrupt signal |
| | 34 | I2C_SDA | I/O | DC0V/ 3.3V(pulse) | Serial communication data signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---------------------------------|-----|--------------------------|-----|----------------------|-------------------------------|
| YC2 | 35 | I2C_SCL | I | DC0V/ 3.3V(pulse) | Panel clock signal |
| | | | | | |
| YC4 | 1 | VBUS | O | DC5V | DC5V power output |
| Connected to the main PWB | 2 | DATE- | I/O | LVDS | USB data signal |
| | 3 | DATE+ | I/O | LVDS | USB data signal |
| | 4 | NC | - | - | Not used |
| | 5 | GND | - | - | Ground |
| YC6 | 1 | GND | - | - | Ground |
| Connected to the main PWB | 2 | SECOND_TR AY_SW | I | DC0V/3.3V | JEPS: On/Off |
| | 3 | BEEP_POWE RON | I | DC0V/3.3V | Sleep recovery signal |
| | 4 | ENERGY_SA VE | I | DC0V/3.3V | Energy save signal |
| | 5 | SUSPEND_P OWER | I | DC3.3V | DC3.3V power input from MPWB |
| | 6 | LED_MEMOR Y_N | I | DC0V/3.3V | Memory LED control signal |
| | 7 | LED_ATTENT ION_N | I | DC0V/3.3V | Attention LED control signal |
| | 8 | LED_PROCE SSING_N | I | DC0V/3.3V | Processing LED control signal |
| | 9 | SHUTDOWN | I | DC0V/3.3V | 24V voltage drop signal |
| | 10 | LIGHTOFF_P OWERON | I | DC0V/3.3V | Sleep recovery signal |
| | 11 | AUDIO | I | Analog | Audio output signal |
| | 12 | PANEL_RESE T | I | DC0V/3.3V | Operation panel reset signal |
| | 13 | INT_ENERGY _SAVER_KEY | O | DC0V/3.3V | Energy Saver key: On/Off |
| | 14 | PANEL_STAT US | O | DC0V/3.3V | Operation panel status signal |
| | 15 | GMD | - | - | Ground |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|-----------|-----|----------------------|---|
| YC7 | 1 | GND | - | - | Ground |
| Connected to the operation panel left PWB | 2 | SCAN0 | O | DC0V/ 3.3V(pulse) | Scan signal |
| | 3 | KEYLEFT1 | I | DC0V/ 3.3V(pulse) | Operation panel key scan return signal |
| | 4 | LEDLEFT1 | O | DC0V/ 3.3V(pulse) | Operation panel LED display drive signal |
| | 5 | KEYLEFT2 | I | DC0V/ 3.3V(pulse) | Operation unit key scan return signal |
| | 6 | SCAN1 | O | DC0V/ 3.3V(pulse) | Scan signal |
| | 7 | SCAN2 | O | DC0V/ 3.3V(pulse) | Scan signal |
| | 8 | SCAN3 | O | DC0V/ 3.3V(pulse) | Scan signal |
| | 9 | KEYLEFT0 | I | DC0V/ 3.3V(pulse) | Operation unit key scan return signal |
| | 10 | LEDLEFT0 | O | DC0V/ 3.3V(pulse) | Operation panel LED display drive signal U |
| | 11 | LEDLEFT2 | O | DC0V/ 3.3V(pulse) | Operation panel LED display drive signal |
| | 12 | S LED2 | O | DC0V/3.3V | Memory LED control signal |
| YC8 | 1 | SCAN0 | O | DC0V/ 3.3V(pulse) | Scan signal |
| Connected to the operation panel right PWB | 2 | SCAN1 | O | DC0V/ 3.3V(pulse) | Scan signal |
| | 3 | SCAN2 | O | DC0V/ 3.3V(pulse) | Scan signal |
| | 4 | SCAN3 | O | DC0V/ 3.3V(pulse) | Scan signal |
| | 5 | SCAN4 | O | DC0V/ 3.3V(pulse) | Scan signal |
| | 6 | LEDRIGHT0 | O | DC0V/ 3.3V(pulse) | Operation panel LED display drive signal |
| | 7 | KEYRIGHT0 | I | DC0V/ 3.3V(pulse) | Operation unit key scan return signal |
| | 8 | KEYRIGHT1 | I | DC0V/ 3.3V(pulse) | Operation unit key scan return signal |
| | 9 | KEYRIGHT2 | I | DC0V/ 3.3V(pulse) | Operation unit key scan return signal |
| | 10 | KEYRIGHT3 | I | DC0V/ 3.3V(pulse) | Operation unit key scan return signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|-------------------|-----|----------------------|--|
| YC8 | 11 | KEYRIGHT4 | I | DC0V/ 3.3V(pulse) | Operation unit key scan return signal |
| Connected to the operation panel right PWB | 12 | LEDRIGHT1 | O | DC0V/ 3.3V(pulse) | Operation panel LED display drive signal |
| | 13 | P_LED | O | DC0V/3.3V | Processing LED control signal |
| | 14 | M_LED | O | DC0V/3.3V | Memory LED control signal |
| | 15 | A_LED | O | DC0V/3.3V | Attention LED control signal |
| | 16 | INT_POWER KEY | I | DC0V/3.3V | Power key: On/Off |
| | 17 | SUSPEMD_P OWER | O | DC3.3V | DC3.3V power output to OPPWB |
| | 18 | GND | - | - | Ground |
| YC9 | 1 | SPK+ | O | Analog | Speaker sound signal (+) |
| Connected to the speaker | 2 | SPK- | O | Analog | Speaker sound signal (-) |
| | | | | | |
| YC14 | 1 | DAT2 | I/O | DC0V/ 3.3V(pulse) | Data bus signal |
| Connected to the SD card | 2 | DAT3 CO | I/O | DC0V/3.3V | Control signal |
| | 3 | CMD | I/O | DC0V/3.3V | Control signal |
| | 4 | VDD | - | DC0V/3.3V | Control signal |
| | 5 | CLK | - | DC0V/3.3V | Control signal |
| | 6 | VSS | - | - | Ground |
| | 7 | DAT0 | I/O | DC0V/ 3.3V(pulse) | Data bus signal |
| | 8 | DAT1 | I/O | DC0V/ 3.3V(pulse) | Data bus signal |
| YC17 | 1 | NC | - | - | Not used |
| Connected to the main PWB | 2 | +5V | I | DC5V | DC5V power input from MPWB |
| | 3 | +5V | I | DC5V | DC5V power input from MPWB |
| | 4 | GND | - | - | Ground |
| | 5 | GND | - | - | Ground |
| | 6 | NC | - | - | Not used |
| YC21 | 1 | LED_A | O | DC0V/5V | LED control signal |
| Connected to the LCD | 2 | LED_C | I | DC0V/5V | LED control signal |

8-2 Description for PWB (35/40 ppm models)

(1) Main PWB (MPWB)

(1-1) Connector position




Figure 8-11

(1-2) PWB photograph

35 ppm model




Figure 8-12

40 ppm model




Figure 1-8-1

(1-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|---------------------|-----|----------------------|-------------------------------|
| YC1 Connected to the hard disc | 1 | GND | - | - | Ground |
| | 2 | SATA1TXDP | O | - | HDD data signal |
| | 3 | SATA1TXDN | O | - | HDD data signal |
| | 4 | GND | - | - | Ground |
| | 5 | SATA1RXDN | I | - | HDD data signal |
| | 6 | SATA1RXDP | I | - | HDD data signal |
| | 7 | GND | - | - | Ground |
| YC4 Connected to the DP relay PWB | 1 | DP_CONECT N | I | DC0V/3.3V | DPMPWB control signal |
| | 2 | DP_SYSCLK OUT | O | DC0V/ 3.3V(pulse) | DPMPWB clock signal |
| | 3 | PCIEN3_DP2 A | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 4 | GND | - | - | Ground |
| | 5 | PCIEP3_DP2 A | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 6 | GND | - | - | Ground |
| | 7 | GND | - | - | Ground |
| | 8 | PCIEN_REFC LK_DP | O | DC0V/ 3.3V(pulse) | DPMPWB clock signal |
| | 9 | GND | - | - | Ground |
| | 10 | PCIEP_REFC LK_DP | O | DC0V/ 3.3V(pulse) | DPMPWB clock signal |
| | 11 | PCIEN3_A2D P | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 12 | GND | - | - | Ground |
| | 13 | PCIEP3_A2D P | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 14 | GND | - | - | Ground |
| | 15 | GND | - | - | Ground |
| | 16 | URAN_RSTN | O | DC0V/3.3V | DPMPWB control signal |
| | 17 | PCIEN2_DP2 A | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 18 | +3.3V3 | - | DC3.3V | DC3.3V power output to DPMPWB |
| | 19 | PCIEP2_DP2 A | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 20 | +3.3V3 | - | DC3.3V | DC3.3V power output to DPMPWB |
| | 21 | GND | - | - | Ground |

| Connector | Pin | Signal | I/O | Voltage | Description |
|-------------------------------|-----|----------------|-----|----------------------|-------------------------------|
| YC4 | 22 | +3.3V3 | - | DC3.3V | DC3.3V power output to DPMPWB |
| Connected to the DP relay PWB | 23 | PCIEN2_A2D P | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 24 | +3.3V3 | - | DC3.3V | DC3.3V power output to DPMPWB |
| | 25 | PCIEP2_A2D P | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 26 | +3.3V3 | - | DC3.3V | DC3.3V power output to DPMPWB |
| | 27 | GND | - | - | Ground |
| | 28 | +3.3V3 | - | DC3.3V | DC3.3V power output to DPMPWB |
| | 29 | PCIEN1_DP2 A | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 30 | +3.3V3 | - | DC3.3V | DC3.3V power output to DPMPWB |
| | 31 | PCIEP1_DP2 A | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 32 | +3.3V3 | - | DC3.3V | DC3.3V power output to DPMPWB |
| | 33 | GND | - | - | Ground |
| | 34 | +3.3V3 | - | DC3.3V | DC3.3V power output to DPMPWB |
| | 35 | PCIEN1_A2D P | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 36 | GND | - | - | Ground |
| | 37 | PCIEP1_A2D P | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 38 | GND | - | - | Ground |
| | 39 | GND | - | - | Ground |
| | 40 | GND | - | - | Ground |
| | 41 | PCIEN0_DP2 A | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 42 | GND | - | - | Ground |
| | 43 | PCIEP0_DP2 A | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 44 | GND | - | - | Ground |
| | 45 | GND | - | - | Ground |
| | 46 | PCIEN0_A2D P | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 47 | GND | - | - | Ground |
| | 48 | PCIEPO_A2D P | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 49 | PCIE3_SWRS T_A | O | DC0V/ 3.3V(pulse) | DPMPWB clock signal |
| | 50 | GND | - | - | Ground |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|----------|-----|----------------------|------------------------------|
| YC5 | 1 | TD1+ | O | DC0V/ 3.3V(pulse) | Transmission data signal |
| Connected to Network | 2 | TD1- | O | DC0V/ 3.3V(pulse) | Transmission data signal |
| | 3 | TD2+ | O | DC0V/ 3.3V(pulse) | Transmission data signal |
| | 4 | TD2- | O | DC0V/ 3.3V(pulse) | Transmission data signal |
| | 5 | CT1 | O | DC3.3V | DC3.3V power output |
| | 6 | CT2 | O | DC3.3V | DC3.3V power output |
| | 7 | TD3+ | O | DC0V/ 3.3V(pulse) | Transmission data signal |
| | 8 | TD3- | O | DC0V/ 3.3V(pulse) | Transmission data signal |
| | 9 | TD4+ | O | DC0V/ 3.3V(pulse) | Transmission data signal |
| | 10 | TD4- | O | DC0V/ 3.3V(pulse) | Transmission data signal |
| | 11 | GRLED_A1 | O | DC0V/3.3V | LED emission signal |
| | 12 | GRLED_K1 | O | DC0V/3.3V | LED emission signal |
| | 13 | YWLED_A2 | O | DC0V/3.3V | LED emission signal |
| | 14 | YWLED_K2 | O | DC0V/3.3V | LED emission signal |
| YC6 | 1 | GND | - | - | Ground |
| Connected to the opera- tion panel PWB | 2 | LCD_OFF | O | DC0V/3.3V | Control signal |
| | 3 | LOCKN | O | DC0V/3.3V | Lock signal |
| | 4 | GND | - | - | - |
| | 5 | TX0N | O | DC0V/ 3.3V(pulse) | Transmission data signal |
| | 6 | TX0P | O | DC0V/ 3.3V(pulse) | Transmission data signal |
| | 7 | GND | - | - | Ground |
| YC8 | 1 | VBUS1 | O | DC3.3V | DC3.3V power output to IFPWB |
| Connected to the KUIO relay PWB | 2 | USB_DN1 | I/O | - | USB data signal |
| | 3 | USB_DP1 | I/O | - | USB data signal |
| | 4 | GND | - | - | Ground |
| | 5 | AUDIO1 | I | Analog | AUDIO signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|--------------------|-----|----------------------|--------------------------------------|
| YC8 Connected to the KUIO relay PWB | 6 | WAKEUP1 | O | DC0V/3.3V | Control signal |
| | 7 | RESET1 | I | DC0V/3.3V | Reset signal |
| | 8 | GND | - | - | Ground |
| | 9 | VBUS0 | O | DC3.3V | DC3.3V power output to IFPWB |
| | 10 | USB_DN0 | I/O | - | USB data signal |
| | 11 | USB_DP0 | I/O | - | USB data signal |
| | 12 | GND | - | - | Ground |
| | 13 | AUDIO0 | I | Analog | AUDIO signal |
| | 14 | WAKEUP0 | O | DC0V/3.3V | Control signal |
| | 15 | RESET | I | DC0V/3.3V | Reset signal |
| YC9 Connected to the KUIO relay PWB | 1 | GND | - | - | Ground |
| | 2 | 5V_CUT0 | I | DC0V/3.3V | DC5V cut signal |
| | 3 | GND | - | - | Ground |
| | 4 | 5V | O | DC5V | DC5V power output to IFPWB |
| | 5 | GND | - | - | Ground |
| | 6 | 5V_CUT1 | I | DC0V/3.3V | DC5V cut signal |
| YC12 Connected to the opera- tion panel PWB | 1 | JOB_LED | O | DC0V/3.3V | JOB LED control signal |
| | 2 | ANY_KEY | I | DC0V/3.3V | ANY KEY recovery signal |
| | 3 | C2P_SCK | O | DC0V/ 3.3V(pulse) | Panel clock signal |
| | 4 | P2C_SBSY | I | DC0V/3.3V | Panel busy signal |
| | 5 | P2C_SDIR | I | DC0V/3.3V | Panel communication direction signal |
| | 6 | C2P_SDAT | O | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | 7 | P2C_SDAT | I | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | 8 | GND | - | - | Ground |
| | 9 | PANEL_RESE T | O | DC0V/3.3V | Reset signal |
| | 10 | BEEP_POWE RON | O | DC0V/3.3V | Sleep recovery signal |
| | 11 | LED_MEMOR Y | O | DC0V/3.3V | Memory LED control signal |
| | 12 | LED_ATTENT ION | O | DC0V/3.3V | Attention LED control signal |
| | 13 | LED_PROCE SSING | O | DC0V/3.3V | Processing LED control signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|------------------|-----|-----------|-----------------------------|
| YC12 Connected to the operation panel PWB | 14 | AUDIO | O | Analog | Audio output signal |
| | 15 | INT_POWER KEY | I | DC0V/3.3V | Power key: On/Off |
| | 16 | GND | - | - | Ground |
| | 17 | LIGHTOFF_POWERON | O | DC0V/3.3V | Sleep recovery signal |
| YC14 Connected to the power supply PWB | 1 | 5V1 | I | DC5V | DC5V power input from PSPWB |
| | 2 | GND | - | - | Ground |
| | 3 | 5V1 | I | DC5V | DC5V power input from PSPWB |
| | 4 | GND | - | - | Ground |
| | 5 | 5V1 | I | DC5V | DC5V power input from PSPWB |
| | 6 | GND | - | - | Ground |
| | 7 | 5V1 | I | DC5V | DC5V power input from PSPWB |
| | 8 | GND | - | - | Ground |
| | 9 | 5V1 | I | DC5V | DC5V power input from PSPWB |
| | 10 | GND | - | - | Ground |
| YC20 Connected to the USB | B1 | VBUS_B | O | DC5V | DC5V power output |
| | B2 | D-_B | I/O | - | USB data signal |
| | B3 | D+_B | I/O | - | USB data signal |
| | B4 | GND_B | - | - | Ground |
| YC23 Connected to the controller fan motor | 1 | SPEED_CONTROL | O | DC12V | CONFM: On/Off |
| | 2 | GND | - | - | Ground |
| | 3 | 5V | O | DC5V | DC5V power output |
| Connected to the power switch | 1 | POWER_SW | O | DC0V/3.3V | PSSW: On/Off |
| | 2 | GND | - | - | Ground |
| YC27 Connected to the HDD | 1 | GND | - | - | Ground |
| | 2 | +5V_HDD | O | DC5V | DC5V power output to HDD |
| | 3 | GND | - | - | Ground |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|----------|-----|----------------------|------------------------|
| YC30 Connected to the operation panel PWB | 1 | +5V | O | DC5V | DC5V power output |
| | 2 | +5V | O | DC5V | DC5V power output |
| | 3 | +5V | O | DC5V | DC5V power output |
| | 4 | GND | - | - | Ground |
| | 5 | GND | - | - | Ground |
| | 6 | GND | - | - | Ground |
| YC31 Connected to the SD card | 1 | CD/DAT3 | I/O | DC0V/3.3V | Control signal |
| | 2 | CMD | I/O | DC0V/3.3V | Control signal |
| | 3 | VSS | - | - | Ground |
| | 4 | VDD | - | DC0V/3.3V | Control signal |
| | 5 | CLK | - | DC0V/3.3V | Control signal |
| | 6 | VSS | - | - | Ground |
| | 7 | DAT0 | I/O | DC0V/ 3.3V(pulse) | Data bus signal |
| | 8 | DAT1 | I/O | DC0V/ 3.3V(pulse) | Data bus signal |
| | 9 | DAT2 | I/O | DC0V/ 3.3V(pulse) | Data bus signal |
| | 10 | CD | I | DC0V/3.3V | Control signal |
| | 11 | COMMON | - | DC0V/3.3V | Control signal |
| | 12 | WP | I | DC0V/3.3V | Control signal |
| YC43 Connected to the engine PWB | 1 | GND | - | - | Ground |
| | 2 | GND | - | - | Ground |
| | 3 | GND | - | - | Ground |
| | 4 | GND | - | - | Ground |
| | 5 | GND | - | - | Ground |
| | 6 | OS_SAD1P | O | DC0V/ 3.3V(pulse) | Serializer output data |
| | 7 | OS_SAD1N | O | DC0V/ 3.3V(pulse) | Serializer output data |
| | 8 | GND | - | - | Ground |
| | 9 | OS_SAD2P | O | DC0V/ 3.3V(pulse) | Serializer output data |
| | 10 | OS_SAD2N | O | DC0V/ 3.3V(pulse) | Serializer output data |
| | 11 | GND | - | - | Ground |
| | 12 | OS_SAD3P | O | DC0V/ 3.3V(pulse) | Serializer output data |

| Connector | Pin | Signal | I/O | Voltage | Description |
|-----------------------------------|-----|---------------------|-----|----------------------|--------------------------|
| YC43 | 13 | OS_SAD3N | O | DC0V/ 3.3V(pulse) | Serializer output data |
| Connected to the engine PWB | 14 | GND | - | - | Ground |
| | 15 | OS_SACKP | O | DC0V/ 3.3V(pulse) | Serializer transfer data |
| | 16 | OS_SACKN | O | DC0V/ 3.3V(pulse) | Serializer transfer data |
| | 17 | GND | - | - | Ground |
| | 18 | OS_SAD4P | O | DC0V/ 3.3V(pulse) | Serializer output data |
| | 19 | OS_SAD4N | O | DC0V/ 3.3V(pulse) | Serializer output data |
| | 20 | GND | - | - | Ground |
| | 21 | SAR_1_CH11 _N | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 22 | SAR_1_CH11 _P | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 23 | GND | - | - | Ground |
| | 24 | SAR_1_CH12 _N | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 25 | SAR_1_CH12 _P | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 26 | GND | - | - | Ground |
| | 27 | SAR_1_CH13 _N | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 28 | SAR_1_CH13 _P | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 29 | GND | - | - | Ground |
| | 30 | SAR_1_VCLK 1_N | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 31 | SAR_1_VCLK 1_P | I | DC0V/ 3.3V(pulse) | Image data signal |
| | 32 | GND | - | - | Ground |
| | 33 | SAT_1_VSYN C_D_N | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 34 | SAT_1_VSYN C_D_P | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 35 | SAT_1_VSYN C_C_N | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 36 | SAT_1_VSYN C_C_P | O | DC0V/ 3.3V(pulse) | Image data signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|-----------------------------------|----------------------|---------------------|----------------------|---------------------------------|-----------------------------------|
| YC43 | 37 | SAT_1_VSYN C_B_N | O | DC0V/ 3.3V(pulse) | Image data signal |
| Connected to the engine PWB | 38 | SAT_1_VSYN C_B_P | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 39 | SAT_1_VSYN C_A_N | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 40 | SAT_1_VSYN C_A_P | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 41 | SAT_1_HSYN C_D_N | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 42 | SAT_1_HSYN C_D_P | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 43 | SAT_1_HSYN C_C_N | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 44 | SAT_1_HSYN C_C_P | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 45 | SAT_1_HSYN C_B_N | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 46 | SAT_1_HSYN C_B_P | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 47 | SAT_1_HSYN C_A_N | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 48 | SAT_1_HSYN C_A_P | O | DC0V/ 3.3V(pulse) | Image data signal |
| | 49 | HLD_SCN | I | DC0V/3.3V | Scanner stop signal |
| | 50 | ENG_WKUP_ REQ | I | DC0V/3.3V | Sleep recovery signal |
| | 51 | HLD_ENG | I | DC0V/3.3V | Engine stop signal |
| | 52 | ENG_ENN | I | DC0V/3.3V | Enable signal |
| | 53 | JS_LED_REM | O | DC0V/3.3V | JOB separator LED lighting signal |
| | 54 | E2C_IRN | O | DC0V/3.3V | G6 interrupt signal |
| | 55 | E2C_SDAT | O | DC0V/ 3.3V(pulse) | G6 data output signal |
| | 56 | E2C_SBSY | O | DC0V/ 3.3V(pulse) | G6 communication busy signal |
| | 57 | E2C_SDIR | O | DC0V/ 3.3V(pulse) | G6 communication direction signal |
| 58 | C2E_SDAT | I | DC0V/ 3.3V(pulse) | G6 data input signal | |
| 59 | C2E_SCKN | I | DC0V/ 3.3V(pulse) | Main communication clock signal | |
| 60 | E2C_PLUGIN _READY | O | DC0V/3.3V | Plug-in notification signal | |

| Connector | Pin | Signal | I/O | Voltage | Description |
|------------------------------|-----|----------|-----|-----------|---------------------------|
| YC43 | 61 | E2C_COMP | O | DC0V/3.3V | Power notification signal |
| Connected to the engine PWB | 62 | GND | - | - | Ground |
| | 63 | GND | - | - | Ground |
| | 64 | GND | - | - | Ground |
| | 65 | GND | - | - | Ground |
| | 66 | GND | - | - | Ground |
| | 67 | GND | - | - | Ground |
| | 68 | GND | - | - | Ground |
| YC50 | 1 | VBUS | O | DC5V | DC5V power output |
| Connected to the USB hub PWB | 2 | DATA- | I/O | - | USB data signal |
| | 3 | DATA+ | I/O | - | USB data signal |
| | 4 | NC | - | - | Not used |
| | 5 | GND | - | - | Ground |
| YC52 | 1 | +5V2 | O | DC5V | DC5V power output |
| Connected to the USB hub PWB | 2 | +5V2 | O | DC5V | DC5V power output |
| | 3 | +5V2 | O | DC5V | DC5V power output |
| | 4 | GND | - | - | Ground |
| | 5 | GND | - | - | Ground |
| | 6 | GND | - | - | Ground |

(2) Engine PWB (EPWB)

(2-1) Connector position




Figure 8-9

(2-2) PWB photograph



Figure 8-10

(2-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|---------------------------|-----|---------------------|-----|----------------------|---|
| YC3 | 1 | GND | - | - | Ground |
| Connected to the main PWB | 2 | GND | - | - | Ground |
| | 3 | GND | - | - | Ground |
| | 4 | GND | - | - | Ground |
| | 5 | GND | - | - | Ground |
| | 6 | GND | - | - | Ground |
| | 7 | GND | - | - | Ground |
| | 8 | E2C_COMP | O | DC0V/3.3V | Power condition reflection notification signal |
| | 9 | E2C_PLUGIN_READY | O | DC0V/3.3V | Plug-in transition condition reflection notification signal |
| | 10 | C2E_SCKN | I | DC0V/ 3.3V(pulse) | G6 communication clock signal |
| | 11 | C2E_SDAT | I | DC0V/ 3.3V(pulse) | G6 communication data input signal |
| | 12 | E2C_SDIR | O | DC0V/3.3V | G6 communication direction signal |
| | 13 | E2C_SBSY | O | DC0V/3.3V | G6 communication busy signal |
| | 14 | E2C_SDAT | O | DC0V/ 3.3V(pulse) | G6 communication data output signal |
| | 15 | E2C_IRN | O | DC0V/3.3V | G6 communication interrupt signal |
| | 16 | JS_LED_REM | O | DC0V/3.5V | JOB separator LED lighting signal |
| | 17 | ENG_ENN | I | DC0V/3.5V | Enable signal |
| | 18 | HLD_ENG | I | DC0V/3.3V | Engine stop signal |
| | 19 | ENG_WKUP_REQ | I | DC0V/3.3V | Sleep recovery signal |
| | 20 | HLD_SCN | I | DC0V/3.3V | Scanner stop signal |
| | 21 | SAT_1_HSYN C_A_P | O | LVDS | Image data signal |
| | 22 | SAT_1_HSYN C_A_N | O | LVDS | Image data signal |
| | 23 | SAT_1_HSYN C_B_P | O | LVDS | Image data signal |
| | 24 | SAT_1_HSYN C_B_N | O | LVDS | Image data signal |
| | 25 | SAT_1_HSYN C_C_P | O | LVDS | Image data signal |
| | 26 | SAT_1_HSYN C_C_N | O | LVDS | Image data signal |
| | 27 | SAT_1_HSYN C_D_P | O | LVDS | Image data signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---------------------------------|----------|---------------------|------|------------------------|-------------------|
| YC3 | 28 | SAT_1_HSYN C_D_N | O | LVDS | Image data signal |
| Connected to the main PWB | 29 | SAT_1_VSYN C_A_P | O | LVDS | Image data signal |
| | 30 | SAT_1_VSYN C_A_N | O | LVDS | Image data signal |
| | 31 | SAT_1_VSYN C_B_P | O | LVDS | Image data signal |
| | 32 | SAT_1_VSYN C_B_N | O | LVDS | Image data signal |
| | 33 | SAT_1_VSYN C_C_P | O | LVDS | Image data signal |
| | 34 | SAT_1_VSYN C_C_N | O | LVDS | Image data signal |
| | 35 | SAT_1_VSYN C_D_P | O | LVDS | Image data signal |
| | 36 | SAT_1_VSYN C_D_N | O | LVDS | Image data signal |
| | 37 | GND | - | - | Ground |
| | 38 | SAR_1_VCLK 1_P | I | LVDS | Image data signal |
| | 39 | SAR_1_VCLK 1_N | I | LVDS | Image data signal |
| | 40 | GND | - | - | Ground |
| | 41 | SAR_1_CH13 _P | I | LVDS | Image data signal |
| | 42 | SAR_1_CH13 _N | I | LVDS | Image data signal |
| | 43 | GND | - | - | Ground |
| | 44 | SAR_1_CH12 _P | I | LVDS | Image data signal |
| | 45 | SAR_1_CH12 _N | I | LVDS | Image data signal |
| | 46 | GND | - | - | Ground |
| | 47 | SAR_1_CH11 _P | I | LVDS | Image data signal |
| | 48 | SAR_1_CH11 _N | I | LVDS | Image data signal |
| 49 | GND | - | - | Ground | |
| 50 | OS_SAD4N | O | LVDS | Serializer output data | |
| 51 | OS_SAD4P | O | LVDS | Serializer output data | |
| 52 | GND | - | - | Ground | |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|---------------|-----|-----------|---------------------------|
| YC3 Connected to the main PWB | 53 | OS_SACKN | O | LVDS | Serializer transfer clock |
| | 54 | OS_SACKP | O | LVDS | Serializer transfer clock |
| | 55 | GND | - | - | Ground |
| | 56 | OS_SAD3N | O | LVDS | Serializer output data |
| | 57 | OS_SAD3P | O | LVDS | Serializer output data |
| | 58 | GND | - | - | Ground |
| | 59 | OS_SAD2N | O | LVDS | Serializer output data |
| | 60 | OS_SAD2P | O | LVDS | Serializer output data |
| | 61 | GND | - | - | Ground |
| | 62 | OS_SAD1N | O | LVDS | Serializer output data |
| | 63 | OS_SAD1P | O | LVDS | Serializer output data |
| | 64 | GND | - | - | Ground |
| | 65 | GND | - | - | Ground |
| | 66 | GND | - | - | Ground |
| | 67 | GND | - | - | Ground |
| 68 | GND | - | - | Ground | |
| YC4 Connected to the developer fan motor 1, developer fan motor 2, lift motor, clutch fan motor, cassette heater PWB | 1 | 24V2 | O | DC24V | DC24V power output |
| | 2 | DLP_FAN1 | O | DC0V/24V | DLPFM1: On/Off |
| | 3 | 24V2 | O | DC24V | DC24V power output |
| | 4 | DLP_FAN2 | O | DC0V/24V | DLPFM2: On/Off |
| | 5 | LIFT_MOT_D R | O | DC0V/24V | LM?On/Off |
| | 6 | LIFT_MOT_R ET | O | DC0V/24V | LM: On/Off |
| | 7 | CL_FAN | O | DC0V/24V | CONTFM: On/Off |
| | 8 | 24V2 | O | DC24V | DC24V power output |
| | 9 | 5V2 | O | DC5V | DC5V power output |
| | 10 | GND | - | - | Ground |
| YC5 Connected to the CCD PWB | 1 | M_LED_A | O | DC0V/10V | LED anode voltage |
| | 2 | M_LED_C | I | DC0V/10V | LED cathode voltage |
| | 3 | GND | - | - | Ground |
| | 4 | HP_SWN | I | DC0V/3.3V | HPS: On/Off |
| | 5 | 3.3V2 | O | DC3.3V | DC3.3V power output |
| | 6 | 3.3V2 | O | DC3.3V | DC3.3V power output |
| | 7 | 3.3V2 | O | DC3.3V | DC3.3V power output |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--------------------------------|-----|------------------|-----|----------------------|--|
| YC5 | 8 | NC | - | - | Not used |
| Connected to the CCD PWB | 9 | GND | - | - | Ground |
| | 10 | DSI_CIS_2_5 P | I | LVDS | Serial input data |
| | 11 | DSI_CIS_2_5 N | I | LVDS | Serial input data |
| | 12 | GND | - | - | Ground |
| | 13 | DSI_CIS_2_4 P | I | LVDS | Serial input data |
| | 14 | DSI_CIS_2_4 N | I | LVDS | Serial input data |
| | 15 | GND | - | - | Ground |
| | 16 | DSI_CIS_2_3 P | I | LVDS | Serial input data |
| | 17 | DSI_CIS_2_3 N | I | LVDS | Serial input data |
| | 18 | GND | - | - | Ground |
| | 19 | DSI_CISCK_2 P | I | LVDS | Transfer clock |
| | 20 | DSI_CISCK_2 N | I | LVDS | Transfer clock |
| | 21 | GND | - | - | Ground |
| | 22 | DSI_CIS_2_2 P | I | LVDS | Serial input data |
| | 23 | DSI_CIS_2_2 N | I | LVDS | Serial input data |
| | 24 | GND | - | - | Ground |
| | 25 | DSI_CIS_2_1 P | I | LVDS | Serial input data |
| | 26 | DSI_CIS_2_1 N | I | LVDS | Serial input data |
| | 27 | GND | - | - | Ground |
| | 28 | AFE_RD | I | DC0V/3.3V | AFE serial communication read signal |
| | 29 | AFE_WD | O | DC0V/3.3V | AFE serial communication write signal |
| | 30 | AFE_CLK | O | DC0V/ 3.3V(pulse) | AFE serial communication clock signal |
| | 31 | AFE_CS | O | DC0V/3.3V | AFE serial communication select signal |
| | 32 | GND | - | - | Ground |
| | 33 | AFE_MCLK_P | O | LVDS | AFE clock signal |
| | 34 | AFE_MCLK_N | O | LVDS | AFE clock signal |
| | 35 | GND | - | - | Ground |

| Connector | Pin | Signal | I/O | Voltage | Description |
|------------------------------|-------------------|----------------------|-----------------|--------------------------|--------------------------------|
| YC5 | 36 | NC | - | - | Not used |
| Connected to the CCD PWB | 37 | 12V5 | O | DC12V | DC12V power output |
| | 38 | 12V5 | O | DC12V | DC12V power output |
| YC6 | A1 | DP_FEED_SENS | I | DC0V/3.3V | DPFS: On/Off |
| Connected to the DP main PWB | A2 | GND | - | - | Ground |
| | A3 | DP_REG_TM G_SENS | I | DC0V/3.3V | DPRS: On/Off |
| | A4 | DP_SET_SEN S | I | DC0V/3.3V | DPOS: On/Off |
| | A5 | GND | - | - | Ground |
| | A6 | DP_OPEN_S ENS | I | DC0V/3.3V | DPOCS: On/Off |
| | A7 | DP_JHP_EXI T_SENS | I | DC0V/3.3V | DPFSS: On/Off |
| | A8 | DP_VSIZE_S W | I | DC0V/3.3V | DPOLS: On/Off |
| | A9 | DP_WID_VOL | I | Analog | DPOWS: On/Off |
| | A10 | DP_DET | I | DC0V/3.3V | DP connection detection signal |
| | A11 | 3.3V2 | O | DC3.3V | DC3.3V power output |
| | A12 | GND | - | - | Ground |
| | A13 | 3.3V2 | O | DC3.3V | DC3.3V power output |
| | A14 | 3.3V3 | O | DC3.3V | DC3.3V power output |
| | A15 | GND | - | - | Ground |
| | A16 | DP_SEL | I | DC0V/3.3V | DP select signal |
| | A17 | NC | - | - | Not used |
| | A18 | NC | - | - | Not used |
| | B1 | DP_FEEDCL_ REM | O | DC0V/24V | DPFCL: On/Off |
| | B2 | 24V6_IL | O | DC24V | DC24V power output |
| | B3 | DP_CIS_FAN | - | - | Not used |
| B4 | 24V6_IL | O | DC24V | DC24V power output | |
| B5 | DO_MOT_FA N | - | - | Not used | |
| B6 | 24V6_IL | O | DC24V | DC24V power output | |
| B7 | DP_CONVMO T_/B | O | DC0V/24V(pulse) | DPC drive control signal | |
| B8 | DP_CONVMO T_/A | O | DC0V/24V(pulse) | DPC drive control signal | |

| Connector | Pin | Signal | I/O | Voltage | Description |
|------------------------------------|-----|--------------------|-----|----------------------|---|
| YC6 | B9 | DP_CONVMO T_B | O | DC0V/24V(pulse) | DPC drive control signal |
| Connected to the DP main PWB | B10 | DP_CONVMO T_A | O | DC0V/24V(pulse) | DPC drive control signal |
| | B11 | DP_FEEDMO T_B | O | DC0V/24V(pulse) | DPFM drive control signal |
| | B12 | DP_FEEDMO T_A | O | DC0V/24V(pulse) | DPFM drive control signal |
| | B13 | DP_FEEDMO T_B | O | DC0V/24V(pulse) | DPFM drive control signal |
| | B14 | DP_FEEDMO T_A | O | DC0V/24V(pulse) | DPFM drive control signal |
| | B15 | DP_SEPMOT _B | O | DC0V/24V(pulse) | DPFSM drive control signal |
| | B16 | DP_SEPMOT _A | O | DC0V/24V(pulse) | DPFSM drive control signal |
| | B17 | DP_SEPMOT _B | O | DC0V/24V(pulse) | DPFSM drive control signal |
| | B18 | DP_SEPMOT _A | O | DC0V/24V(pulse) | DPFSM drive control signal |
| YC7 | 1 | 24V6 | O | DC24V | DC24V power output |
| Connected to the DPSHD PWB | 2 | 24V6 | O | DC24V | DC24V power output |
| | 3 | GND | - | - | Ground |
| | 4 | GND | - | - | Ground |
| | 5 | SHD_SIR_PA GEST | O | DC0V/3.3V | Sub-scanning image processing signal |
| | 6 | SHD_SIR_SE L | O | DC0V/3.3V | Serial communication select signal |
| | 7 | SHD_SIR_SC LK | O | DC0V/ 3.3V(pulse) | Serial communication clock signal |
| | 8 | SHD_SIR_SD O | O | DC0V/ 3.3V(pulse) | Serial communication data output signal |
| | 9 | SHD_SIR_SDI | I | DC0V/ 3.3V(pulse) | Serial communication data input signal |
| | 10 | SHD_SIR_OV M | I | DC0V/3.3V | Sub-scanning monitoring signal |
| | 11 | SHD_SIR_RD Y | I | DC0V/3.3V | Serial communication ready signal |
| | 12 | DP_CISTMG | I | DC0V/3.3V | DPTS: On/Off |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--------------------------------|-----|-----------|-----|-----------|--------------------------------|
| YC8 | 1 | GND | - | - | Ground |
| Connected to the APC PWB | 2 | GND | - | - | Ground |
| | 3 | LDERR | I | DC0V/3.3V | LD overcurrent detection |
| | 4 | VREF_Y | O | Analog | Laser output VREF (Y) |
| | 5 | GND | - | - | Ground |
| | 6 | DATA_1P_Y | O | LVDS | Image data Y |
| | 7 | DATA_1N_Y | O | LVDS | Image data Y |
| | 8 | GND | - | - | Ground |
| | 9 | OUTPEYN | O | DC0V/3.3V | Laser output enabling signal Y |
| | 10 | SAMPLEY | O | DC0V/3.3V | Sample hold signal Y |
| | 11 | VREFC | O | Analog | Laser output VREF (C) |
| | 12 | GND | - | - | Ground |
| | 13 | VDOC1N | O | LVDS | Image data C |
| | 14 | VDOC1P | O | LVDS | Image data C |
| | 15 | GND | - | - | Ground |
| | 16 | OUTPECN | O | DC0V/3.3V | Laser output enabling signal C |
| | 17 | SAMPLEC | O | DC0V/3.3V | Sample hold signal C |
| | 18 | VREFM | O | Analog | Laser output VREF (M) |
| | 19 | GND | - | - | Ground |
| | 20 | VDOM1N | O | LVDS | Image data M |
| | 21 | VDM1P | O | LVDS | Image data M |
| | 22 | GND | - | - | Ground |
| | 23 | OUTPEMN | O | DC0V/3.3V | Laser output enabling signal M |
| | 24 | SAMPLEM | O | DC0V/3.3V | Sample hold signal M |
| | 25 | VREFK | O | Analog | Laser output VREF (BK) |
| | 26 | GND | - | - | Ground |
| | 27 | VDOK1N | O | LVDS | Image data K |
| | 28 | VDOK1P | O | LVDS | Image data K |
| | 29 | GND | - | - | Ground |
| | 30 | OUTPEKN | O | DC0V/3.3V | Laser output enabling signal K |
| | 31 | SAMPLEK | O | DC0V/3.3V | Sample hold signal K |
| | 32 | 5V4_IL | O | DC5V | DC5V power output |
| | 33 | 5V4_IL | O | DC5V | DC5V power output |
| | 34 | 5V4_IL | O | DC5V | DC5V power output |
| | 35 | 5V4_IL | O | DC5V | DC5V power output |
| | 36 | PDKN | I | DC0V/3.3V | BD signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|--------------|-----|-----------------|---|
| YC8 Connected to the APC PWB | 37 | LSUTHERM_BK | I | Analog | LSU thermistor voltage |
| | 38 | GND | - | - | Ground |
| | 39 | GND | - | - | Ground |
| | 40 | GND | - | - | Ground |
| YC10 Connected to the polygon motor, cleaning motor | 1 | 24V2 | O | DC24V | DC24V power output |
| | 2 | GND | - | - | Ground |
| | 3 | POLREM | O | DC0V/5V | PM remote signal |
| | 4 | POLRDYN | I | DC0V/3.3V | PM ready signal |
| | 5 | PDLCLK | O | DC0V/5V(pulse) | PM clock signal |
| | 6 | LSU_CL_MOT2 | O | DC0V/24V(pulse) | CLM: On/Off |
| | 7 | LSU_CL_MOT1 | O | DC0V/24V(pulse) | CLM: On/Off |
| | 8 | 3.3V2_LED | - | - | Not used |
| | 9 | GND | - | - | Not used |
| YC11 Connected to the fuser sensor, fuser release sensor, fuser thermistor (center), fuser thermistor (edge), transfer belt release sensor 1, transfer belt release sensor 2 | 1 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to ES |
| | 2 | GND | - | - | Ground |
| | 3 | FSR_JAM_SENS | I | DC0V/3.3V | ES: On/Off |
| | 4 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to FUPRS |
| | 5 | GND | - | - | Ground |
| | 6 | FSR_RLS_SENS | I | DC0V/3.3V | FUPRS: On/Off |
| | 7 | GND | - | - | Ground |
| | 8 | MAIN_TH2 | I | Analog | Non-contact thermistor voltage (detection) |
| | 9 | MAIN_TH1 | I | Analog | Non-contact thermistor voltage (compensation) |
| | 10 | GUIDE_TH2 | I | Analog | Contact thermistor voltage |
| | 11 | GND | - | - | Ground |
| | 12 | FUS_DET | I | DC0V/3.3V | Fuser unit connection signal |
| | 13 | GND | - | - | Ground |
| | 14 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to TCBRS1 |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|------------------|-----|-----------------|--|
| YC11 | 15 | GND | - | - | Ground |
| | 16 | 3REJECT_SE NS | I | DC0V/3.3V | TCBRS1: On/Off |
| | 17 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to TCBRS2 |
| | 18 | GND | - | - | Ground |
| | 19 | 4REJECT_SE NS | I | DC0V/3.3V | TCBRS2: On/Off |
| YC12 | 1 | 24V2_IL | O | DC24V | 24V power output |
| Connected to the high volt- age PWB (40 ppm model) | 2 | 24V2_IL | O | DC24V | 24V power output |
| | 3 | DACSLD1 | O | DC0V/5V | DAC load signal 1 |
| | 4 | DACSLD2 | O | DC0V/5V | DAC load signal 2 |
| | 5 | DACSCLK | O | DC0V/5V(pulse) | DAC clock signal |
| | 6 | SGND | - | - | Ground |
| | 7 | DACSDAT | O | DC0V/5V(pulse) | DAC data signal |
| | 8 | HVREM | O | DC0V/24V | Secondary transfer (reverse) / PB remote signal |
| | 9 | HVCLKSLV | O | DC0V/10V(pulse) | Developer clock (SLV) signal |
| | 10 | MKISENS | I | Analog | Main charger (K) current detection |
| | 11 | PGND | - | - | Ground |
| | 12 | PGND | - | - | Ground |
| | 13 | HVCLKMAG | O | DC0V/10V(pulse) | Developer clock (MAG) signal |
| | 14 | MHCHGCLK | O | DC0V/10V(pulse) | Main charger clock signal |
| | 15 | MYISENS | I | Analog | Main charger (Y) current detection |
| | 16 | MMISENS | I | Analog | Main charger (M) current detection |
| | 17 | MCISENS | I | Analog | Main charger (C) current detection |
| | 18 | T2CNT | O | Analog | Secondary transfer control voltage |
| | 19 | CLCNT | O | Analog | Cleaning control voltage |
| | 20 | DISCHARGE | I | Analog | Discharge detection voltage |
| YC12 | 1 | 24V2_IL | O | DC24V | 24V power output |
| Connected to the high volt- age PWB (35 ppm model) | 2 | 24V2_IL | O | DC24V | 24V power output |
| | 3 | DACSLD1 | O | DC0V/5V(pulse) | DAC load signal 1 |
| | 4 | DACSLD2 | O | DC0V/5V(pulse) | DAC load signal 2 |
| | 5 | DACSCLK | O | DC0V/5V(pulse) | DAC clock signal |
| | 6 | SGND | - | - | Ground |
| | 7 | DACSDAT | O | DC0V/5V(pulse) | DAC data signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|--------------|-----|----------------------|---|
| YC12 Connected to the high voltage PWB (35 ppm model) | 8 | HVREM | O | DC0V/24V | Secondary transfer (reverse) / PB remote signal |
| | 9 | HVCLKSLV | O | DC0V/10V(pulse) | Developer clock (SLV) signal |
| | 10 | MKISENS | I | Analog | Main charger (K) current detection |
| | 11 | PGND | - | - | Ground |
| | 12 | PGND | - | - | Ground |
| YC14 Connected to the power supply PWB, transfer high voltage PWB (40 ppm model) | 1 | 24V2 | O | DC24V | DC24V power output |
| | 2 | LVU_FAN | O | DC0V/24V | PWBFM: On/Off |
| | 3 | ZCROSS | I | DC0V/ 3.3V(pulse) | Zero cross signal |
| | 4 | LVU_SLEEP | O | DC0V/5V | Sleep signal |
| | 5 | GND | - | - | Ground |
| | 6 | GND | - | - | Ground |
| | 7 | T1KCNT | O | Analog | Primary transfer (K) control voltage |
| | 8 | T1CCNT | O | Analog | Primary transfer (C) control voltage |
| | 9 | HVREM | O | DC0V/24V | High voltage remote signal |
| | 10 | T1YCNT | O | Analog | Primary transfer (Y) control voltage |
| | 11 | T1MCNT | O | Analog | Primary transfer (M) control voltage |
| | 12 | 24V2_IL | O | DC24V | DC24V power output |
| YC14 Connected to the power supply PWB, transfer high voltage PWB (35 ppm model) | 1 | 24V2 | O | DC24V | DC24V power output |
| | 2 | LVU_FAN | O | DC0V/24V | PWBFM: On/Off |
| | 3 | ZCROSS | I | DC0V/ 3.3V(pulse) | Zero cross signal |
| | 4 | LVU_SLEEP | O | DC0V/5V | Sleep signal |
| | 5 | GND | - | - | Ground |
| YC15 Connected to the drum/ developer relay PWB | 1 | GND | - | - | Ground |
| | 2 | VIBR_MOT_REM | O | DC0V/3.3V | VIBM remote signal |
| | 3 | TCSSENS_Y | I | Analog | TS-Y detection signal |
| | 4 | TCSSENS_C | I | Analog | TS-C detection signal |
| | 5 | TCSSENS_M | I | Analog | TS-M detection signal |
| | 6 | ERS_CL_REM | O | DC0V/3.3V | Eraser CL remote signal |
| | 7 | GND | - | - | Ground |
| | 8 | 3.3V2 | O | DC3.3V | DC3.3V power output to DR/DLPPWB |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-------------------|-------------------|-----------|----------------------|---------------------------------|
| YC15 Connected to the drum/ developer relay PWB | 9 | EEP_SCL | O | DC0V/ 3.3V(pulse) | EEPROM clock signal |
| | 10 | EEP_SDA | I/O | DC0V/ 3.3V(pulse) | EEPROM data I/O signal |
| | 11 | 24V2 | O | DC24V | DC24V power output to DR/DLPPWB |
| | 12 | GND | - | - | Ground |
| | 13 | DLP_TH | I | Analog | Developer thermistor voltage |
| | 14 | TCSSENS_BK | I | Analog | TS-K detection signal |
| | 15 | ERS_BK_RE M | O | DC0V/3.3V | Eraser Bk remote signal |
| YC17 Connected to the RFID, belt fan motor, toner suction fan motor, eject paper fan motor, eject fan motor, transfer release motor, waste toner box switch, waste toner detection sensor, temperature/humidity sensor, developer fan motor 3, developer fan motor 4 | A1 | 5V2 | O | DC5V | 5V power output |
| | A2 | 3.3V2 | O | DC3.3V | 3.3V power output |
| | A3 | RFID_SCL | O | DC0V/ 3.3V(pulse) | RFID communication clock signal |
| | A4 | GND | - | - | Ground |
| | A5 | RFID_SDA | I/O | DC0V/3.3V | RFID communication data signal |
| | A6 | 3.3V2 | O | DC3.3V | 3.3V power output |
| | A7 | GND | - | - | Ground |
| | A8 | SUB_SDA | I/O | DC0V/ 3.3V(pulse) | Communication data signal |
| | A9 | SUB_SCL | O | DC0V/ 3.3V(pulse) | Communication clock signal |
| | A10 | BELT_FAN_R EM | O | DC0V/24V | EPFM: On/Off |
| | A11 | 24V2 | O | DC24V | 24V power output |
| | A12 | WTNR_FAN | O | DC0V/24V | TFM: On/Off |
| | A13 | 24V2 | O | DC24V | 24V power output |
| | A14 | NC | - | - | Not used |
| | A15 | NC | - | - | Not used |
| | A16 | 24V2 | O | DC24V | 24V power output |
| | A17 | EXIT_FAN | O | DC0V/24V | EFM: On/Off |
| | B1 | BELT_RLS_R EMA | O | DC0V/24V | TCBRM: On/Off |
| | B2 | BELT_RLS_R EMB | O | DC0V/24V | TCBRM: On/Off |
| | B3 | GND | - | - | Ground |
| B4 | WTNR_SET_ SENS | I | DC0V/3.3V | WTSSW: On/Off | |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-------------|----------------|-----------|-----------|--------------------------------------|
| YC17 | B5 | WTNR_LED_3.3V2 | O | DC3.3V | 3.3V power output |
| | B6 | WTNR_LED | O | DC0V/3.3V | WST(LED): On/Off |
| | B7 | WTNR_TR_3.3V2 | O | DC3.3V | 3.3V power output |
| | B8 | WTNR_TR | I | Analog | WST detection voltage |
| | B9 | HUMCLK | O | DC0V/3.3V | TEMS clock signal |
| | B10 | HUMOUT | I | Analog | TEMS (humidity) detection voltage |
| | B11 | GND | - | - | Ground |
| | B12 | AIRTEMP | I | Analog | TEMS (temperature) detection voltage |
| | B13 | DLP_FAN3 | O | DC0V/24V | DLPFM3: On/Off, TBFM: On/Off |
| | B14 | 24V2 | O | DC24V | 24V power output |
| | B15 | DLP_FAN4 | O | DC0V/24V | DLPFM4: On/Off |
| | B16 | 24V2 | O | DC24V | 24V power output |
| | B17 | NC | - | - | Not used |
| | YC18 | 1 | 3.3V2_LED | O | DC3.3V |
| Connected to the paper detection sensor, paper level sensor 1, paper level sensor 2, paper width detection sensor 1, paper width detection sensor 2, paper width detection sensor 3, duplex sensor, MP paper detection sensor, lift sensor, registration sensor, MP solenoid | 2 | GND | - | - | Ground |
| | 3 | PAPEMP_SENS | I | DC0V/3.3V | PS: On/Off |
| | 4 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to PGS1 |
| | 5 | GND | - | - | Ground |
| | 6 | PAPVL1_SENS | I | DC0V/3.3V | PGS1: On/Off |
| | 7 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to PGS2 |
| | 8 | GND | - | - | Ground |
| | 9 | PAPVL2_SENS | I | DC0V/3.3V | PGS2: On/Off |
| | 10 | CAS_WID0 | I | DC0V/3.3V | PLSW1: On/Off |
| | 11 | GND | - | - | Ground |
| | 12 | CAS_WID1 | I | DC0V/3.3V | PLSW2: On/Off |
| | 13 | GND | - | - | Ground |
| | 14 | CAS_WID2 | I | DC0V/3.3V | PLSW3: On/Off |
| | 15 | GND | - | - | Ground |
| | 16 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to DUS |
| | 17 | GND | - | - | Ground |
| | 18 | DU1_SENS | I | DC0V/3.3V | DUS: On/Off |
| | 19 | 3.3V3_LED | O | DC3.3V | DC3.3V power output to MPPS |
| | 20 | GND | - | - | Ground |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|---------------------|-----|-----------|--------------------------------|
| YC18 | 21 | MPF_SET_SE NS | I | DC0V/3.3V | MPPS: On/Off |
| | 22 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to LS |
| | 23 | GND | - | - | Ground |
| | 24 | CAS_LIFTUP _SENS | I | DC0V/3.3V | LS: On/Off |
| | 25 | GND | - | - | Ground |
| | 26 | REG_SENS | I | DC0V/3.3V | RS: On/Off |
| | 27 | 3.3V2 | O | DC3.3V | DC3.3V power output to RS |
| | 28 | 24V2 | O | DC24V | DC24V power output to MPSOL |
| | 29 | MPF_SOL_R EM | O | DC0V/24V | MPSOL: On/Off |
| | 30 | NC | - | - | Not used |
| YC19 | A1 | DEV_CL_RE M | O | DC0V/24V | DLPCL-BK: On/Off |
| | A2 | 24V2 | O | DC24V | DC24V power output to DLPCL-BK |
| | A3 | RESIST_CL_ REM | O | DC0V/24V | RCL: On/Off |
| | A4 | 24V2 | O | DC24V | DC24V power output to RCL |
| | A5 | FEED_CL_RE M | O | DC0V/24V | FCL: On/Off |
| | A6 | 24V2 | O | DC24V | DC24V power output to FCL |
| | A7 | MID_CL_REM | O | DC0V/24V | MCL: On/Off |
| | A8 | 24V2 | O | DC24V | DC24V power output to MCL |
| | A9 | DU1_REM | O | DC0V/24V | DUCL: On/Off |
| | A10 | 24V2 | O | DC24V | DC24V power output to DUCL |
| Connected to the devel- oper clutch, registration clutch, pri- mary feed clutch, mid- dle clutch, duplex clutch, front ID sensor, rear ID sen- sor | B1 | +3.3V2 | O | DC3.3V | DC3.3V power output to IDS1 |
| | B2 | REG_F_LED | O | Analog | IDS1 control signal |
| | B3 | GND | - | - | Ground |
| | B4 | REG_SENS_ F_P | I | Analog | IDS1 detection signal |
| | B5 | REG_SENS_ F_S | I | Analog | IDS1 detection signal |
| | B6 | +3.3V2 | O | DC3.3V | DC3.3V power output to IDS2 |
| | B7 | REG_R_LED | O | Analog | IDS2 control signal |
| | B8 | GND | - | - | Ground |
| | B9 | REG_SENS_ R_P | I | Analog | IDS2 detection signal |
| | B10 | REG_SENS_ R_S | I | Analog | IDS2 detection signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|-------------------|-----|----------------------|-----------------------------------|
| YC20 | A1 | MPF_TRAY_SW | I | DC0V/3.3V | MPTSW: On/Off |
| Connected to the MP tray switch, MP paper paper width size detection switch, MP paper length sensor, PF main PWB | A2 | GND | - | - | Ground |
| | A3 | 3.3V2 | O | DC3.3V | DC3.3V power output |
| | A4 | MPF_WID_V OL | I | Analog | MPWS detection voltage |
| | A5 | GND | - | - | Ground |
| | A6 | 3.3V2_LED | O | DC3.3V | DC3.3V power output |
| | A7 | GND | - | - | Ground |
| | A8 | MPF_LONG_ SENS | I | DC0V/3.3V | MPLS: On/Off |
| | A9 | NC | - | - | Not used |
| | A10 | NC | - | - | Not used |
| | A11 | NC | - | - | Not used |
| | B1 | PF_CAS_OPE N | I | DC0V/3.3V | Cassette open/close signal output |
| | B2 | PAUSE | O | DC0V/3.3V | Pause signal |
| | B3 | PF_SDO | O | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | B4 | PF_SDI | I | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | B5 | PF_RDY | I | DC0V/3.3V | Ready signal |
| | B6 | PF_SCLK | O | DC0V/ 3.3V(pulse) | Clock signal |
| | B7 | PF_SEL2 | O | DC0V/3.3V | Cassette 3 select signal |
| | B8 | PF_SEL1 | O | DC0V/3.3V | Cassette 2 select signal |
| | B9 | GND | - | - | Ground |
| | B10 | 3.3V3 | O | DC3.3V | DC3.3V power output to PF |
| | B11 | PF_VER_SEN S | I | DC0V/3.3V | PFCS1: On/Off |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-------------|---------------|---------|----------------|-------------------------------|
| YC21 | 1 | 24V2 | O | DC24V | DC24V power output to TM-Y |
| Connected to the transfer belt fan motor, container motor (BK), container motor (M), container motor (C), container motor (Y), container sensor (BK), container sensor (M), container sensor (C), container sensor (Y) | 2 | TMOT_Y_DIR | O | DC0V/24V | TM-Y drive control signal |
| | 3 | 24V2 | O | DC24V | DC24V power output to TM-C |
| | 4 | TMOT_C_DIR | O | DC0V/24V | TM-C drive control signal |
| | 5 | 24V2 | O | DC24V | DC24V power output to TM-M |
| | 6 | TMOT_M_DIR | O | DC0V/24V | TM-M drive control signal |
| | 7 | 24V2 | O | DC24V | DC24V power output to TM-K |
| | 8 | TMOT_BK_DIR | O | DC0V/24V | TM-K drive control signal |
| | 9 | 3.3V2_LED | O | DC3.3V | DC3.3V power output CS-Y |
| | 10 | GND | - | - | Ground |
| | 11 | PULSE_SENS_Y | I | DC0V/3.3V | CL-Y: On/Off |
| | 12 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to CS-C |
| | 13 | GND | - | - | Ground |
| | 14 | PULSE_SENS_C | I | DC0V/3.3V | CL-C: On/Off |
| | 15 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to CS-M |
| | 16 | GND | - | - | Ground |
| | 17 | PULSE_SENS_M | I | DC0V/3.3V | CL-M: On/Off |
| | 18 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to CS-K |
| | 19 | GND | - | - | Ground |
| | 20 | PULSE_SENS_BK | I | DC0V/3.3V | CS-K: On/Off |
| | YC22 | 1 | 24V3_IL | O | DC24V |
| Connected to the transfer motor, developer motor (BK) | 2 | GND | - | - | Ground |
| | 3 | IMAGE_MOT_REM | O | DC0V/5V | TCM remote signal |
| | 4 | IMAGE_MOT_CLK | O | DC0V/5V(pulse) | TCM clock signal |
| | 5 | IMAGE_MOT_RDY | I | DC0V/3.3V | TCM synchronizing signal |
| | 6 | IMAGE_MOT_DIR | O | DC0V/5V | TCM rotation switching signal |
| | 7 | 24V3_IL | O | DC24V | DC24V power output to DLPM-K |
| | 8 | GND | - | - | Ground |

| Connector | Pin | Signal | I/O | Voltage | Description | |
|-------------|---|--------------|--------------|-----------------|----------------------------------|--------------------------------------|
| YC22 | 9 | FEED_MOT_REM | O | DC0V/5V | DLPM-K remote signal K | |
| | Connected to the transfer motor, developer motor (BK) | 10 | FEED_MOT_CLK | O | DC0V/5V(pulse) | Developer-K clock signal K |
| | | 11 | FEED_MOT_RDY | I | DC0V/3.3V | DLPM-K synchronizing signal K |
| | | 12 | FEED_MOT_DIR | O | DC0V/5V | DLPM-K rotation switching signal K |
| YC23 | 1 | 24V3_IL | O | DC24V | DC24V power output to DLPM-M/C/Y | |
| | Connected to the developer motor (M/C/Y), drum motor (BK) | 2 | GND | - | - | Ground |
| | | 3 | DLPC_MOT_REM | O | DC0V/5V | DLPM-M/C/Y remote signal |
| | | 4 | DLPC_MOT_CLK | O | DC0V/5V(pulse) | DLPM-M/C/Y clock signal |
| | | 5 | DLPC_MOT_RDY | I | DC0V/3.3V | DLPM-M/C/Y synchronizing signal |
| | | 6 | DLPC_MOT_DIR | O | DC0V/5V | DLPM-M/C/Y rotation switching signal |
| | | 7 | 24V3_IL | O | DC24V | DC24V power output to DRM-K |
| | | 8 | GND | - | - | Ground |
| | | 9 | DRMK_MOT_REM | O | DC0V/5V | DRM-K remote signal |
| | | 10 | DRMK_MOT_CLK | O | DC0V/5V(pulse) | DRM-K clock signal |
| | | 11 | DRMK_MOT_RDY | I | DC0V/3.3V | DRM-K synchronizing signal |
| | | 12 | DRMK_MOT_DIR | O | DC0V/5V | DRM-K rotation switching signal |
| | | 13 | NC | - | - | Not used |
| YC24 | 1 | FUSER_MOT_B/ | O | DC0V/24V(pulse) | FUM drive control signal | |
| | Connected to the fuser motor | 2 | FUSER_MOT_A/ | O | DC0V/24V(pulse) | FUM drive control signal |
| | | 3 | FUSER_MOT_B | O | DC0V/24V(pulse) | FUM drive control signal |
| | | 4 | FUSER_MOT_A | O | DC0V/24V(pulse) | FUM drive control signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|----------------|-----|------------------|--|
| YC25 Connected to the drum motor (M/C/Y) | 1 | 24V2_IL | O | DC24V | DC24V power output to DRM-M/C/Y |
| | 2 | GND | - | - | Ground |
| | 3 | DRMC_MOT_REM | O | DC0V/5V | DRM-M/C/Y remote signal |
| | 4 | DRMC_MOT_CLK | O | DC0V/5V(pulse) | DRM-M/C/Y clock signal |
| | 5 | DRMC_MOT_RDY | I | DC0V/3.3V | DRM-M/C/Y synchronizing signal |
| | 6 | DRMC_MOT_DIR | O | DC0V/5V | DRM-M/C/Y rotation switching signal |
| YC27 Connected to the scanner motor | 1 | SCAN_MOT_B3 | O | DC0V/24V(pulse) | SM drive control signal |
| | 2 | SCAN_MOT_A1 | O | DC0V/24V(pulse) | SM drive control signal |
| | 3 | SCAN_MOT_B1 | O | DC0V/24V(pulse) | SM drive control signal |
| | 4 | SCAN_MOT_A3 | O | DC0V/24V(pulse) | SM drive control signal |
| YC31 Connected to the AK, MT, inner finisher, eject motor, eject feedshift solenoid, upper eject full sensor, lower eject full sensor, steam removal fan motor, JS paper detection sensor, front cover open/close switch | A1 | BRIDGE_FAN | O | DC0V/3.3V | BRFM: On/Off |
| | A2 | BRIDGE_REM | O | DC0V/3.3V(pulse) | Bridge motor remote signal |
| | A3 | BRIDGE_CLK | O | DC0V/3.3V(pulse) | Bridge motor clock signal |
| | A4 | BRIDGE_PH0 | O | DC0V/3.3V | Bridge motor excitation switching signal 1 |
| | A5 | BRIDGE_PH1 | O | DC0V/3.3V | Bridge motor excitation switching signal 2 |
| | A6 | BRIDGE_DET | I | DC0V/3.3V | Bridge presence detection signal |
| | A7 | BRIDGE_SENS1 | I | DC0V/3.3V | Bridge conveying detection signal 1 |
| | A8 | BRIDGE_SENS2 | I | DC0V/3.3V | Bridge conveying detection signal 2 |
| | A9 | BRIDGE_OPEN_SW | I | DC0V/3.3V | Bridge open detection signal |
| | A10 | GND | - | - | Ground |
| | A11 | GND | - | - | Ground |
| | A12 | 3.3V2 | O | DC3.3V | DC3.3V power output to BRMPWB |
| | A13 | 24V2 | O | DC24V | DC24V power output to BRMPWB |
| | A14 | DF_RDY | O | DC0V/3.3V | Ready signal |
| | A15 | DF_SEL | O | DC0V/3.3V | Select signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----------------|----------------|-----------|----------------------|----------------------------------|
| YC31 | A16 | DF_SDO | O | DC0V/ 3.3V(pulse) | Serial communication data signal |
| Connected to the AK, MT, inner finisher, eject motor, eject feedshift solenoid, upper eject full sensor, lower eject full sensor, steam removal fan motor, JS paper detection sensor, front cover open/close switch | A17 | DF_SDI | I | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | A18 | NC | - | - | Not used |
| | A19 | DF_DET | I | DC0V/3.3V | Connection detection signal |
| | A20 | DF_CLK | I | DC0V/ 3.3V(pulse) | Clock signal |
| | B1 | CON_FAN | O | DC0V/24V | SFM: On/Off |
| | B2 | 24V2 | O | DC24V | DC24V power output to SFM |
| | B3 | SB_MOT_B1 | O | DC0V/24V(pulse) | EM drive control signal |
| | B4 | SB_MOT_B3 | O | DC0V/24V(pulse) | EM drive control signal |
| | B5 | SB_MOT_A3 | O | DC0V/24V(pulse) | EM drive control signal |
| | B6 | SB_MOT_A1 | O | DC0V/24V(pulse) | EM drive control signal |
| | B7 | 24V2 | O | DC0V/24V | 24V power output to FSSOL |
| | B8 | EJE_SOL_PULL | O | DC0V/24V | FSSOL: On/Off (actuate) |
| | B9 | EJE_SOL_RETURN | O | DC0V/24V | FSSOL: On/Off (keep) |
| | B10 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to EFS1 |
| | B11 | GND | - | - | Ground |
| | B12 | EJE_FULL_UP | I | DC0V/3.3V | EFS1: On/Off |
| | B13 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to EFS2 |
| | B14 | GND | - | - | Ground |
| | B15 | EJE_FULL_DOWN | I | DC0V/3.3V | EFS2: On/Off |
| | B16 | 3.3V3_LED | O | DC3.3V | DC3.3V power output to EPS |
| B17 | GND | - | - | Ground | |
| B18 | EXITUP_PAP_SENS | I | DC0V/3.3V | EPS: On/Off | |
| B19 | FCOVOR_OPEN | I | DC0V/3.3V | FCSW2: On/Off | |
| B20 | GND | - | - | Ground | |
| YC33 | 1 | GND | - | - | Ground |
| Connected to the key counter | 2 | DC1_SET | I | DC0V/3.3V | Set signal |
| | 3 | DC1_COUNT | O | DC0V/24V | Count signal |
| | 4 | 24V2 | O | DC24V | DC24V power output |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-------------|-----------|-----|-----------|----------------------------|
| YC34 | A1 | 5V2 | O | DC5V | DC5V power output |
| Connected to the key card | A2 | 5V2 | O | DC5V | DC5V power output |
| | A3 | 5V2 | O | DC5V | DC5V power output |
| | A4 | 5V2 | O | DC5V | DC5V power output |
| | A5 | 5V2 | O | DC5V | DC5V power output |
| | A6 | +5V2 | O | DC5V | DC5V power output |
| | A7 | 5V2 | O | DC5V | DC5V power output |
| | A8 | 5V2 | O | DC5V | DC5V power output |
| | A9 | MK2_ENBL | I | DC0V/3.3V | Copy enabling signal |
| | A10 | 24V2 | O | DC24V | DC24V power output |
| | B1 | MK2_RKEY7 | O | DC0V/5V | Key card RKEY7 signal |
| | B2 | MK2_RKEY6 | O | DC0V/5V | Key card RKEY6 signal |
| | B3 | MK2_RKEY5 | O | DC0V/5V | Key card RKEY5 signal |
| | B4 | MK2_RKEY4 | O | DC0V/5V | Key card RKEY4 signal |
| | B5 | MK2_RKEY3 | O | DC0V/5V | Key card RKEY3 signal |
| | B6 | MK2_RKEY2 | O | DC0V/5V | Key card RKEY2 signal |
| | B7 | MK2_RKEY1 | O | DC0V/5V | Key card RKEY1 signal |
| | B8 | MK2_RKEY0 | O | DC0V/5V | Key card RKEY0 signal |
| | B9 | GND | - | - | Ground |
| | B10 | MK2_COUNT | O | DC0V/24V | Key card RKEY_COUNT signal |
| | YC35 | 1 | 5V0 | I | DC5V |
| Connected to the power supply PWB | 2 | GND | - | - | Ground |
| | 3 | GND | - | - | Ground |
| | 4 | GND | - | - | Ground |
| | 5 | GND | - | - | Ground |
| | 6 | 24V2 | I | DC24V | DC24V power input |
| | 7 | 24V2 | I | DC24V | DC24V power input |
| | 8 | 24V2 | I | DC24V | DC24V power input |
| YC37 | 1 | 24V2 | O | DC24V | DC24V power output |
| Connected to the conveying unit open/close switch, front cover open/close switch | 2 | 24V2_IL | I | DC24V | DC24V power input |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|---------|-----|---------|--------------------|
| YC38 | 1 | 24V2 | O | DC24V | DC24V power output |
| Connected to the DP conveying cover open/close switch (CIS model) | 2 | GND | - | - | Not used |
| | 3 | 24V6_IL | I | DC24V | DC24V power input |

(3) High voltage PWB (HVPWB)

(3-1) Connector position




Figure 8-11

(3-2) PWB photograph




Figure 8-12

(3-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|-----------|-----|----------------------|---|
| YC1 | 1 | 24V2_IL | I | DC24V | DC24V power input |
| Connected to the engine PWB (40 ppm model) | 2 | 24V2_IL | I | DC24V | DC24V power input |
| | 3 | DACSLD1 | I | DC0V/3.3V | DAC load signal 1 |
| | 4 | DACSLD2 | I | DC0V/3.3V | DAC load signal 2 |
| | 5 | DACSCLK | I | DC0V/ 3.3V(pulse) | DAC clock signal |
| | 6 | SGND | - | - | Ground |
| | 7 | DACSDAT | I | DC0V/ 3.3V(pulse) | DAC data signal |
| | 8 | HVREM | I | DC0V/3.3V | Secondary transfer (reverse) / PB remote signal |
| | 9 | HVCLKSLV | I | DC0V/3.3V | Developer clock (SLV) signal |
| | 10 | MISENS | O | Analog | Main charger (K) current detection |
| | 11 | PGND | - | - | Ground |
| | 12 | PGND | - | - | Ground |
| | 13 | HVCLKMAG | I | DC0V/24V(pulse) | Developer clock (MAG) signal |
| | 14 | MHCHGCLK | I | DC0V/24V(pulse) | Main charger clock signal |
| | 15 | MYISENS | O | Analog | Main charger (Y) current detection |
| | 16 | MMISENS | O | Analog | Main charger (M) current detection |
| | 17 | MCISENS | O | Analog | Main charger (C) current detection |
| | 18 | T2CNT | I | Analog | Secondary transfer control voltage |
| | 19 | CLCNT | I | Analog | Cleaning control voltage |
| | 20 | DISCHARGE | O | Analog | Discharge detection voltage |
| YC1 | 1 | 24V2_IL | I | DC24V | DC24V power input |
| Connected to the engine PWB (35 ppm model) | 2 | 24V2_IL | I | DC24V | DC24V power input |
| | 3 | DACSLD1 | I | DC0V/3.3V | DAC load signal 1 |
| | 4 | DACSLD2 | I | DC0V/3.3V | DAC load signal 2 |
| | 5 | DACSCLK | I | DC0V/ 3.3V(pulse) | DAC clock signal |
| | 6 | SGND | - | - | Ground |
| | 7 | DACSDAT | I | DC0V/ 3.3V(pulse) | DAC data signal |
| | 8 | HVREM | I | DC0V/3.3V | Secondary transfer (reverse) / PB remote signal |
| | 9 | HVCLK | I | DC0V/3.3V | Developer clock (SLV) signal |
| | 10 | MISENS | O | Analog | Main charger (K) current detection |
| | 11 | GND | - | - | Ground |
| | 12 | GND | - | - | Ground |

(4) Transfer high voltage PWB (TCHVPWB) : 40 ppm model only

(4-1) Connector position




Figure 8-13

(4-2) PWB photograph




Figure 8-14

(4-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|---------|-----|----------|--------------------------------------|
| CN1 Connected to the engine PWB | 1 | 24V2_IL | I | DC24V | DC24V power input |
| | 2 | T1MCNT | I | Analog | Primary transfer (M) control voltage |
| | 3 | T1YCNT | I | Analog | Primary transfer (Y) control voltage |
| | 4 | HVREM | I | DC0V/24V | High voltage remote signal |
| | 5 | T1CCNT | I | Analog | Primary transfer (C) control voltage |
| | 6 | T1KCNT | I | Analog | Primary transfer (K) control voltage |
| | 7 | GND | - | - | Ground |

(5) Power supply PWB (PSPWB)

(5-1) Connector position




Figure 8-15

(5-2) PWB photograph




Figure 8-16

(5-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|----------------------------------|-----|------------|-----|-----------|-----------------------|
| TB1 | 1 | LIVE | I | AC100V | AC power input |
| Connected to the inlet | | | | | |
| TB2 | 1 | NEUTRAL | I | AC100V | AC power input |
| Connected to the inlet | | | | | |
| YC2 | 1 | SH | O | AC100V | AC power output to SH |
| Connected to the fuser heater | 2 | NC | - | - | Not used |
| | 3 | LIVE_OUT | O | AC100V | AC power output to SH |
| | 4 | LIVE_OUT | O | AC100V | AC power output to MH |
| | 5 | NC | - | - | Not used |
| | 6 | MH | O | AC100V | AC power output to MH |
| YC4 | 1 | DH_LIVE | 0 | AC100V | AC power output to CH |
| Connected to the cassette heater | 2 | DH_LIVE | 0 | AC100V | AC power output to CH |
| | 3 | NC | - | - | Not used |
| | 4 | NC | - | - | Not used |
| | 5 | DH_NEUTRAL | 0 | AC100V | AC power output to CH |
| | 6 | DH_NEUTRAL | 0 | AC100V | AC power output to CH |
| YC5 | 1 | 24V2 | 0 | DC24V | DC24V power output |
| Connected to the engine PWB | 2 | 24V2 | 0 | DC24V | DC24V power output |
| | 3 | 24V2 | 0 | DC24V | DC24V power output |
| | 4 | GND | - | - | Ground |
| | 5 | GND | - | - | Ground |
| | 6 | GND | - | - | Ground |
| | 7 | GND | - | - | Ground |
| | 8 | 5V0 | 0 | DC5V | DC5V power output |
| YC6 | 1 | GND | - | - | Ground |
| Connected to the engine PWB | 2 | 24V2IL | I | DC24V | DC24V power input |
| | 3 | RELAYREM | I | DC0V/3.3V | Power relay signal |
| | 4 | MHREM | I | DC0V/3.3V | MH: On/Off |
| | 5 | SHREM | I | DC0V/3.3V | SH: On/Off |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|-----------|-----|----------------------|--------------------|
| YC6 Connected to the engine PWB | 6 | GND | - | - | Ground |
| | 7 | 24V2 | I | DC24V | DC24V power input |
| | 8 | DHREM | I | DC0V/3.3V | CH: On/Off |
| | 9 | 5V0 | I | DC5V | DC5V power input |
| YC7 Connected to the main PWB | 1 | GND | - | - | Ground |
| | 2 | 5V0 | O | DC5V | DC5V power output |
| | 3 | GND | - | - | Ground |
| | 4 | 5V0 | O | DC5V | DC5V power output |
| | 5 | GND | - | - | Ground |
| | 6 | 5V0 | O | DC5V | DC5V power output |
| | 7 | GND | - | - | Ground |
| | 8 | 5V0 | O | DC5V | DC5V power output |
| | 9 | GND | - | - | Ground |
| | 10 | 5V0 | O | DC5V | DC5V power output |
| YC8 Connected to the DF main PWB, MT main PWB, PF main PWB | 1 | 24V2PF | O | DC24V | DC24V power output |
| | 2 | 24V2DF | O | DC24V | DC24V power output |
| | 3 | 24V2DF | O | DC24V | DC24V power output |
| | 4 | 24V2 | O | DC24V | DC24V power output |
| | 5 | GND | - | - | Ground |
| | 6 | GND | - | - | Ground |
| | 7 | GND | - | - | Ground |
| | 8 | GND | - | - | Ground |
| YC9 Connected to the engine PWB | 1 | GND | - | - | Ground |
| | 2 | LVU_SLEEP | I | DC0V/24V | Sleep signal |
| | 3 | ZCROSS | O | DC0V/ 3.3V(pulse) | Zero cross signal |

(6) Operation panel PWB (OPPWB)

(6-1) Connector position




Figure 8-17

(6-2) PWB photograph




Figure 8-18

(6-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|-----------------|-----|----------------------|--|
| YC1 | 1 | JOB_LED | I | DC0V/3.3V | JOB LED control signal (inner DF) |
| Connected to the operation panel key PWB | 2 | PROCESS- ING | I | DC0V/3.3V | Processing LED control signal |
| | 3 | MEMORY | I | DC0V/3.3V | Memory LED control signal |
| | 4 | ATTENTION | I | DC0V/3.3V | Attention LED control signal |
| | 5 | GND | - | - | Ground |
| | 6 | KEY3 | I | DC0V/ 3.3V(pulse) | Op2eration panel key scan return signal 3 |
| | 7 | SCAN0 | O | DC0V/ 3.3V(pulse) | Scan signal 0 |
| | 8 | KEY2 | I | DC0V/ 3.3V(pulse) | Operation panel key scan return signal 2 |
| | 9 | KEY1 | I | DC0V/ 3.3V(pulse) | Operation panel key scan return signal 1 |
| | 10 | KEY0 | I | DC0V/ 3.3V(pulse) | Operation panel key scan return signal 0 |
| | 11 | NC | - | - | Not used |
| | 12 | LED2 | O | DC0V/ 3.3V(pulse) | Operation panel LED display drive signal 2 |
| | 13 | LED1 | O | DC0V/ 3.3V(pulse) | Operation panel LED display drive signal 1 |
| | 14 | LED0 | O | DC0V/ 3.3V(pulse) | Operation panel LED display drive signal 0 |
| | 15 | NC | - | - | Not used |
| | 16 | SCAN1 | O | DC0V/ 3.3V(pulse) | Scan signal 1 |
| | 17 | SCAN3 | O | DC0V/ 3.3V(pulse) | Scan signal 3 |
| | 18 | GND | - | - | Ground |
| | 19 | SCAN2 | O | DC0V/ 3.3V(pulse) | Scan signal 2 |
| | 20 | SCAN4 | O | DC0V/ 3.3V(pulse) | Scan signal 4 |
| | 21 | KEY4 | I | DC0V/ 3.3V(pulse) | Operation panel key scan return signal 4 |
| | 22 | KEY5 | I | DC0V/ 3.3V(pulse) | Operation panel key scan return signal 5 |
| | 23 | NC | - | - | Not used |
| | 24 | LED3 | O | DC0V/ 3.3V(pulse) | Operation panel LED display drive signal 3 |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|------|--------------------|--------|----------------------|--|
| YC1 | 25 | NC | - | - | Not used |
| Connected to the operation panel key PWB | 26 | KEY6 | I | DC0V/ 3.3V(pulse) | Operation panel key scan return signal 6 |
| | 27 | GND | - | - | Ground |
| | 28 | INT_POWER KEY_N | O | DC0V/3.3V | Power key: On/Off |
| | 29 | NC | - | - | Not used |
| | 30 | 5V0 | - | - | Ground |
| YC2 | 1 | GND | - | - | Ground |
| Connected to the LCD | 2 | R0 | O | DC0V/3.3V | Red data signal (LSB) |
| | 3 | R1 | O | DC0V/3.3V | Red data signal |
| | 4 | R2 | O | DC0V/3.3V | Red data signal |
| | 5 | R3 | O | DC0V/3.3V | Red data signal |
| | 6 | R4 | O | DC0V/3.3V | Red data signal |
| | 7 | R5 | O | DC0V/3.3V | Red data signal (MSB) |
| | 8 | GND | - | - | Ground |
| | 9 | G0 | O | DC0V/3.3V | Green data signal (LSB) |
| | 10 | G1 | O | DC0V/3.3V | Green data signal |
| | 11 | G2 | O | DC0V/3.3V | Green data signal |
| | 12 | G3 | O | DC0V/3.3V | Green data signal |
| | 13 | G4 | O | DC0V/3.3V | Green data signal |
| | 14 | G5 | O | DC0V/3.3V | Green data signal (MSB) |
| | 15 | GND | - | - | Ground |
| | 16 | B0 | O | DC0V/3.3V | Blue data signal (LSB) |
| | 17 | B1 | O | DC0V/3.3V | Blue data signal |
| | 18 | B2 | O | DC0V/3.3V | Blue data signal |
| | 19 | B3 | O | DC0V/3.3V | Blue data signal |
| | 20 | B4 | O | DC0V/3.3V | Blue data signal |
| | 21 | B5 | O | DC0V/3.3V | Blue data signal (MSB) |
| | 22 | GND | - | - | Ground |
| | 23 | DCLK | O | DC0V/ 3.3V(pulse) | LCD dot clock signal |
| | 24 | 3.3V | - | DC3.3V | 3.3V power for LCD |
| | 25 | 3.3V | - | DC3.3V | 3.3V power for LCD |
| 26 | 3.3V | - | DC3.3V | 3.3V power for LCD | |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|------------------|-----|----------------------|----------------------------------|
| YC2 Connected to the LCD | 27 | 3.3V | - | DC3.3V | 3.3V power for LCD |
| | 28 | DE | O | DC0V/ 3.3V(pulse) | LCD data enabling signal |
| | 29 | HSYNC | O | DC0V/ 3.3V(pulse) | Horizontal synchronizing signal |
| | 30 | VSYNC | O | DC0V/ 3.3V(pulse) | Vertical synchronizing signal |
| | 31 | LED_EN | O | DC0V/ 3.3V(pulse) | LED driver enabling signal |
| | 32 | LED_PWM | O | DC0V/ 3.3V(pulse) | LED driver PWM signal |
| | 33 | TSC_INT | I | DC0V/ 3.3V(pulse) | Touch panel interrupt signal |
| | 34 | I2C_SDA | I/O | DC0V/ 3.3V(pulse) | Touch panel control signal |
| | 35 | I2C_SCL | O | DC0V/ 3.3V(pulse) | Touch panel control clock signal |
| YC3 Connected to the speaker | 1 | VO2 | O | Analog | Speaker sound signal (+) |
| | 2 | VO1 | O | Analog | Speaker sound signal (-) |
| YC6 Connected to the LCD | 1 | LED_A | O | DC0V/5V | LED control signal |
| | 2 | LED_C | I | DC0V/5V | LED control signal |
| YC8 Connected to the touch panel | 1 | BOT_Y- | I | Analog | Touch panel XP position signal |
| | 2 | LEFT_X+ | I | Analog | Touch panel YN position signal |
| | 3 | TOP_Y+ | I | Analog | Touch panel XN position signal |
| | 4 | RIGHT_X- | I | Analog | Touch panel YP position signal |
| YC12 Connected to the main PWB | A1 | +5V | - | DC5V | DC5V power |
| | A2 | +5V | - | DC5V | DC5V power |
| | A3 | +5V | - | DC5V | DC5V power |
| | A4 | +5V | - | DC5V | DC5V power |
| | A5 | JOB_LED | I | DC0V/3.3V | JOB LED control signal |
| | A6 | ANY_KEY | O | DC0V/3.3V | ANY KEY recovery signal |
| | A7 | LIGHTOFF_POWERON | I | DC0V/3.3V | Sleep recovery signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---------------------------------|-----|--------------------|-----|----------------------|--------------------------------------|
| YC12 | A8 | C2P_SCK | I | DC0V/ 3.3V(pulse) | Panel clock signal |
| Connected to the main PWB | A9 | P2C_SBSY | O | DC0V/3.3V | Panel busy signal |
| | A10 | P2C_SDIR | O | DC0V/3.3V | Panel communication direction signal |
| | A11 | C2P_SDAT | O | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | A12 | P2C_SDAT | I | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | B1 | GND | - | - | Ground |
| | B2 | INT_POWER KEY | O | DC0V/3.3V | Power key: On/Off |
| | B3 | AUDIO | I | Analog | Audio output signal |
| | B4 | LED_PROCE SSING | I | DC0V/3.3V | Processing LED control signal |
| | B5 | LED_ATTENT ION | I | DC0V/3.3V | Attention LED control signal |
| | B6 | LED_MEMOR Y | I | DC0V/3.3V | Memory LED control signal |
| | B7 | BEEP_POWE RON | I | DC0V/3.3V | Sleep recovery signal |
| | B8 | PANEL_RESE | I | DC0V/3.3V | Reset signal |
| | B9 | GND | - | - | Ground |
| | B10 | GND | - | - | Ground |
| B11 | GND | - | - | Ground | |
| B12 | GND | - | - | Ground | |
| YC22 | 1 | GND | - | - | Ground |
| Connected to the main PWB | 2 | LCD_OFF | I | DC0V/3.3V | Control signal |
| | 3 | LOCKN | O | DC0V/3.3V | Lock signal |
| | 4 | GND | - | - | Ground |
| | 5 | RX0N | I | LVDS | Transmission data signal |
| | 6 | RX0P | I | LVDS | Transmission data signal |
| | 7 | GND | - | - | Ground |

8-3 Description for PWB (OPTION)

(1) PF main PWB (PFMPWB) for PF-5120

(1-1) Connector position




Figure 8-19

(1-2) PWB photograph




Figure 8-20

(1-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|---------------------|-----|-----------|-------------------------------|
| YC3 Connected to the paper detection sensor, paper level sensor 1, paper level sensor 2, paper length detection sensor 1, paper length detection sensor 2, paper length detection sensor 3 | 1 | 3.3V4_LED | O | DC3.3V | DC3.3V power output to PFPS |
| | 2 | GND | - | - | Ground |
| | 3 | CAS1_EMPT Y | I | DC0V/3.3V | PFPS: On/Off |
| | 4 | 3.3V4_LED | O | DC3.3V | DC3.3V power output to PFPGS1 |
| | 5 | GND | - | - | Ground |
| | 6 | CAS1_QUAN T1 | I | DC0V/3.3V | PFPGS1: On/Off |
| | 7 | 3.3V4_LED | O | DC3.3V | DC3.3V power output to PFPGS2 |
| | 8 | GND | - | - | Ground |
| | 9 | CAS1_QUAN T2 | I | DC0V/3.3V | PFPGS2: On/Off |
| | 10 | GND | - | - | Ground |
| | 11 | CAS1_SIZE1_ SENS | I | DC0V/3.3V | PFPLSW1: On/Off |
| | 12 | GND | - | - | Ground |
| | 13 | CAS1_SIZE2_ SENS | I | DC0V/3.3V | PFPLSW2: On/Off |
| | 14 | GND | - | - | Ground |
| | 15 | CAS1_SIZE3_ SENS | I | DC0V/3.3V | PFPLSW3: On/Off |
| YC4 Connected to the lift upper limit sensor, feed sensor, right cover switch | 1 | 3.3V4_LED | O | DC3.3V | DC3.3V power output to PFLS |
| | 2 | GND | - | - | Ground |
| | 3 | ULIM_SW_1 | I | DC0V/3.3V | PFLS: On/Off |
| | 4 | 3.3V4 | O | DC3.3V | DC3.3V power output to PFFS |
| | 5 | VER_SENS_1 | I | DC0V/3.3V | PFFS: On/Off |
| | 6 | GND | - | - | Ground |
| | 7 | COVER_OPE N | I | DC0V/3.3V | PFRCSW: On/Off |
| | 8 | GND | - | - | Ground |
| YC6 Connected to the lift motor | 1 | L_MOT1_RET | O | DC0V | PFLM drive control signal |
| | 2 | L_MOT1_DR | O | DC0V/24V | PFLM drive control signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|-----------------|-----|----------------------|--|
| YC8 Connected to the paper feed motor | 1 | +24V | O | DV24V | DC24V power output to PFFM |
| | 2 | GND | - | - | Ground |
| | 3 | START/STOP | O | DC0V/5V | PFFM drive control signal |
| | 4 | CLOCK | O | DC0V/5V(pulse) | PFFM drive control signal |
| | 5 | LD | I | DC0V/3.3V | PFFM drive control signal |
| | 6 | CW/CCW | O | DC0V/5V | PFFM drive control signal |
| YC9 Connected to the conveying clutch and paper feed clutch | 1 | VER_CL1 | O | DC0V/24V | PFCCL: On/Off |
| | 2 | 24V1 | O | DV24V | DC24V power output to PFCCL |
| | 3 | FEED_CL1 | O | DC0V/24V | PFFCL: On/Off |
| | 4 | 24V1 | O | DV24V | DC24V power output to PFFCL |
| | 5 | VER_CL2 | - | - | Not used |
| YC10 Connected to the PF main PWB | 1 | GND | - | - | Ground |
| | 2 | GND | - | - | Ground |
| | 3 | 24V2 | O | DV24V | DC24V power output to PF |
| YC11 Connected to the engine PWB | 1 | 24V1 | I | DC24V | DC24V power input from the main unit |
| | 2 | GND | - | - | Ground |
| YC12 Connected to the engine PWB | 1 | VER_SENS | O | DC0V/3.3V | PFFS: On/Off |
| | 2 | +3.3V3 | I | DC3.3V | DC3.3V power input from the main unit |
| | 3 | GND | - | - | Ground |
| | 4 | PF_CAS1_SE L | I | DC0V/3.3V | Cassette select signal 1 |
| | 5 | PF_CAS2_SE L | I | DC0V/3.3V | Cassette select signal 2 |
| | 6 | EH_CLK | I | DC0V/ 3.3V(pulse) | Clock signal |
| | 7 | EH_RDY | O | DC0V/3.3V | Ready signal |
| | 8 | EH_SDO | O | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | 9 | EH_SDI | I | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | 10 | PF_PAU | I | DC0V/3.3V | Pause signal |
| | 11 | PF_CAS_OPE N | O | DC0V/3.3V | Cassette insertion and removal signal output |

| Connector | Pin | Signal | I/O | Voltage | Description |
|------------------------------|-----|----------------|-----|----------------------|---|
| YC13 | 1 | AN_PF_CAS_OPEN | I | DC0V/3.3V | Cassette insertion and removal signal input |
| Connected to the PF main PWB | 2 | AN_PF_PAUSE | O | DC0V/3.3V | Pause signal |
| | 3 | AN_PF_SDI | O | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | 4 | AN_PF_SDO | I | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | 5 | AN_PF_RDY | I | DC0V/3.3V | Ready signal |
| | 6 | AN_PF_CLK | O | DC0V/ 3.3V(pulse) | Clock signal |
| | 7 | PF_CAS2_SELECT | O | DC0V/3.3V | Cassette select signal 4 |
| | 8 | GND | - | - | Ground |
| | 9 | +3.3V3 | O | DC3.3V | DC3.3V power output to PF |

(2) PF main PWB (PFMPWB) for PF-5130

(2-1) Connector position




Figure 8-21

(2-2) PWB photograph




Figure 8-22

(2-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|---------------------|-----|-----------|-------------------------------|
| YC3 Connected to the paper detection sensor 1, paper level sensor 1, paper level sensor 2, paper length detection switch 1, paper length detection switch 2, paper length detection switch 3 | 1 | 3.3V4_LED | O | DC3.3V | DC3.3V power output to PFPS1 |
| | 2 | GND | - | - | Ground |
| | 3 | CAS1_EMPT Y | I | DC0V/3.3V | PFPS1: On/Off |
| | 4 | 3.3V4_LED | O | DC3.3V | DC3.3V power output to PFPGS1 |
| | 5 | GND | - | - | Ground |
| | 6 | CAS1_QUAN T1 | I | DC0V/3.3V | PFPGS1: On/Off |
| | 7 | 3.3V4_LED | O | DC3.3V | DC3.3V power output to PFPGS2 |
| | 8 | GND | - | - | Ground |
| | 9 | CAS1_QUAN T2 | I | DC0V/3.3V | PFPGS2: On/Off |
| | 10 | GND | - | - | Ground |
| | 11 | CAS1_SIZE1_ SENS | I | DC0V/3.3V | PFPLSW1: On/Off |
| | 12 | GND | - | - | Ground |
| | 13 | CAS1_SIZE2_ SENS | I | DC0V/3.3V | PFPLSW2: On/Off |
| | 14 | GND | - | - | Ground |
| | 15 | CAS1_SIZE3_ SENS | I | DC0V/3.3V | PFPLSW3: On/Off |
| YC4 Connected to the lift upper limit sensor 1, feed sensor 1, right cover switch, lift upper limit sensor 2, feed sensor 2 | 1 | 3.3V4_LED | O | DC3.3V | DC3.3V power output to PFLS 1 |
| | 2 | GND | - | - | Ground |
| | 3 | ULIM_SW_1 | I | DC0V/3.3V | PFLS1: On/Off |
| | 4 | 3.3V4 | O | DC3.3V | DC3.3V power output to PFFS 1 |
| | 5 | VER_SENS_1 | I | DC0V/3.3V | PFFS1: On/Off |
| | 6 | GND | - | - | Ground |
| | 7 | COVER_OPE N | I | DC0V/3.3V | PFRCSW: On/Off |
| | 8 | GND | - | - | Ground |
| | 9 | 3.3V5_LED | O | DC3.3V | DC3.3V power output to PFLS2 |
| | 10 | GND | - | - | Ground |
| | 11 | ULIM_SW_2 | I | DC0V/3.3V | PFLS2: On/Off |
| | 12 | 3.3V5 | O | DC3.3V | DC3.3V power output to PFFS2 |
| | 13 | VER_SENS_2 | I | DC0V/3.3V | PFFS2: On/Off |
| | 14 | GND | - | - | Ground |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|-----------------|-----|----------------|-------------------------------|
| YC5 Connected to the paper detection sensor 2, paper detection sensor 3, paper detection sensor 4, paper length detection switch 4, paper length detection switch 5, paper length detection switch 6 | 1 | 3.3V5_LED | O | DC3.3V | DC3.3V power output to PFPS2 |
| | 2 | GND | - | - | Ground |
| | 3 | CAS2_EMPTY | I | DC0V/3.3V | PFPS2: On/Off |
| | 4 | 3.3V4_LED | O | DC3.3V | DC3.3V power output to PFPGS3 |
| | 5 | GND | - | - | Ground |
| | 6 | CAS2_QUANT1 | I | DC0V/3.3V | PFPGS3: On/Off |
| | 7 | 3.3V4_LED | O | DC3.3V | DC3.3V power output to PFPGS4 |
| | 8 | GND | - | - | Ground |
| | 9 | CAS2_QUANT2 | I | DC0V/3.3V | PFPGS4: On/Off |
| | 10 | GND | - | - | Ground |
| | 11 | CAS2_SIZE1_SENS | I | DC0V/3.3V | PFPLSW4: On/Off |
| | 12 | GND | - | - | Ground |
| | 13 | CAS2_SIZE2_SENS | I | DC0V/3.3V | PFPLSW5: On/Off |
| | 14 | GND | - | - | Ground |
| | 15 | CAS2_SIZE3_SENS | I | DC0V/3.3V | PFPLSW6: On/Off |
| | 16 | GND | - | - | Not used |
| YC6 Connected to the lift motor 1, lift motor 2 | 1 | L_MOT1_RET | O | DC0V | PFLM1 drive control signal |
| | 2 | L_MOT1_DR | O | DC0V/24V | PFLM1 drive control signal |
| | 3 | L_MOT2_RET | O | DC0V | PFLM2 drive control signal |
| | 4 | L_MOT2_DR | O | DC0V/24V | PFLM2 drive control signal |
| YC8 Connected to the paper feed motor | 1 | +24V | O | DV24V | DC24V power output to PFFM |
| | 2 | GND | - | - | Ground |
| | 3 | START/STOP | O | DC0V/5V | PFFM drive control signal |
| | 4 | CLOCK | O | DC0V/5V(pulse) | PFFM drive control signal |
| | 5 | LD | I | DC0V/3.3V | PFFM drive control signal |
| | 6 | CW/CCW | O | DC0V/5V | PFFM drive control signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|-----------------|-----|----------------------|--|
| YC9 Connected to the conveying clutch 1, paper feed clutch 1, conveying clutch 2, paper feed clutch 2 | 1 | VER_CL1 | O | DC0V/24V | PFCL1: On/Off |
| | 2 | 24V1 | O | DV24V | DC24V power output to PFCL1 |
| | 3 | FEED_CL1 | O | DC0V/24V | PFCL1: On/Off |
| | 4 | 24V1 | O | DV24V | DC24V power output to PFCL1 |
| | 5 | VER_CL2 | O | DC0V/24V | PFCL2: On/Off |
| | 6 | 24V1 | O | DV24V | DC24V power output to PFCL2 |
| | 7 | FEED_CL2 | O | DC0V/24V | PFCL2: On/Off |
| | 8 | 24V1 | O | DV24V | DC24V power output to PFCL2 |
| YC11 Connected to the PF main PWB (PF-5120) | 1 | 24V1 | I | DC24V | DC24V power input from PF |
| | 2 | GND | - | - | Ground |
| YC12 Connected to the PF main PWB (PF-5120) | 1 | VER_SENS | O | DC0V/3.3V | PFFS1: On/Off |
| | 2 | +3.3V3 | I | DC3.3V | DC3.3V power input from PF |
| | 3 | GND | - | - | Ground |
| | 4 | PF_CAS1_SE L | I | DC0V/3.3V | Cassette select signal 4 |
| | 5 | PF_CAS2_SE L | - | - | Not used |
| | 6 | EH_CLK | I | DC0V/ 3.3V(pulse) | Clock signal |
| | 7 | EH_RDY | O | DC0V/3.3V | Ready signal |
| | 8 | EH_SDO | O | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | 9 | EH_SDI | I | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | 10 | PF_PAU | I | DC0V/3.3V | Pause signal |
| | 11 | PF_CAS_OPE N | O | DC0V/3.3V | Cassette insertion and removal signal output |

(3) PF main PWB (PFMPWB) for PF-5140

(3-1) Connector position




Figure 8-23

(3-2) PWB photograph



Figure 8-24

(3-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|---------------------|-----|-----------------|-------------------------------|
| YC3 Connected to the paper detection sensor, paper level sensor 1, paper level sensor 2, paper deck detection switch | 1 | 3.3V4_LED | O | DC3.3V | DC3.3V power output to PFPS |
| | 2 | GND | - | - | Ground |
| | 3 | CAS1_EMPT Y | I | DC0V/3.3V | PFPS: On/Off |
| | 4 | 3.3V4_LED | O | DC3.3V | DC3.3V power output to PFPGS1 |
| | 5 | GND | - | - | Ground |
| | 6 | CAS1_QUAN T1 | I | DC0V/3.3V | PFPGS1: On/Off |
| | 7 | 3.3V4_LED | O | DC3.3V | DC3.3V power output to PFPGS2 |
| | 8 | GND | - | - | Ground |
| | 9 | CAS1_QUAN T2 | I | DC0V/3.3V | PFPGS2: On/Off |
| | 10 | GND | - | - | Ground |
| | 11 | CAS1_SIZE1_ SENS | I | DC0V/3.3V | PFDDSW1: On/Off |
| | 12 | GND | - | - | Not used |
| | 13 | CAS1_SIZE2_ SENS | - | - | Not used |
| | 14 | GND | - | - | Not used |
| | 15 | CAS1_SIZE3_ SENS | - | - | Not used |
| YC4 Connected to the lift upper limit sensor, feed sensor, right cover switch | 1 | 3.3V4_LED | O | DC3.3V | DC3.3V power output to PFLS 1 |
| | 2 | GND | - | - | Ground |
| | 3 | ULIM_SW_1 | I | DC0V/3.3V | PFLS1: On/Off |
| | 4 | 3.3V4 | O | DC3.3V | DC3.3V power output to PFFS |
| | 5 | VER_SENS_1 | I | DC0V/3.3V | PFFS: On/Off |
| | 6 | GND | - | - | Ground |
| | 7 | COVER_OPE N | I | DC0V/3.3V | PFRCSW: On/Off |
| | 8 | GND | - | - | Ground |
| YC6 Connected to the lift motor | 1 | L_MOT1_RET | O | DC0V/24V(pulse) | PFLM drive control signal |
| | 2 | L_MOT1_DR | O | DC0V/24V(pulse) | PFLM drive control signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|-----------------|-----|----------------------|--|
| YC8 Connected to the paper feed motor | 1 | +24V | O | DV24V | DC24V power output to PFFM |
| | 2 | GND | - | - | Ground |
| | 3 | START/STOP | O | DC0V/5V | PFFM drive control signal |
| | 4 | CLOCK | O | DC0V/5V | PFFM drive control signal |
| | 5 | LD | I | DC0V/3.3V | PFFM drive control signal |
| | 6 | CW/CCW | O | DC0V/5V | PFFM drive control signal |
| YC9 Connected to the conveying clutch and paper feed clutch | 1 | VER_CL1 | O | DC0V/24V | PFCCL1: On/Off |
| | 2 | 24V1 | O | DV24V | DC24V power output to PFCCL1 |
| | 3 | FEED_CL1 | O | DC0V/24V | PFFCL1: On/Off |
| | 4 | 24V1 | O | DV24V | DC24V power output to PFFCL1 |
| | 5 | VER_CL2 | - | - | Not used |
| YC11 Connected to the PF main PWB (PF-5120) | 1 | 24V1 | I | DC24V | DC24V power input from PF |
| | 2 | GND | - | - | Ground |
| YC12 Connected to the PF main PWB (PF-5120) | 1 | VER_SENS | O | - | PFFS1: On/Off |
| | 2 | +3.3V3 | I | DC3.3V | DC3.3V power input from PF |
| | 3 | GND | - | - | Ground |
| | 4 | PF_CAS1_SE L | I | DC0V/3.3V | Cassette select signal 4 |
| | 5 | PF_CAS2_SE L | - | - | Not used |
| | 6 | EH_CLK | I | DC0V/ 3.3V(pulse) | Clock signal |
| | 7 | EH_RDY | O | DC0V/3.3V | Ready signal |
| | 8 | EH_SDO | O | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | 9 | EH_SDI | I | DC0V/ 3.3V(pulse) | Serial communication data signal |
| | 10 | PF_PAU | I | DC0V/3.3V | Pause signal |
| | 11 | PF_CAS_OPE N | O | DC0V/3.3V | Cassette insertion and removal signal output |

(4) DP main PWB (DPMPWB) for DP-5100

(4-1) Connector position




Figure 8-25

(4-2) PWB photograph



Figure 8-26

(4-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|------------------|-----|-----------|---------------------------------------|
| YC1 Connected to the engine PWB | 1 | +3.3V3 | I | DC3.3V | DC3.3V power input from the main unit |
| | 2 | 3.3V2 | I | DC3.3V | DC3.3V power input from the main unit |
| | 3 | GND | - | - | Ground |
| | 4 | 3.3V2 | I | DC3.3V | DC3.3V power input from the main unit |
| | 5 | DP_DET | O | DC0V | DP connection detection voltage |
| | 6 | DP_HSIZE SW | O | Analog | DPOWS detection voltage |
| | 7 | DP_VSIZE SW | O | DC0V/3.3V | DPOLS: On/Off |
| | 8 | DP_JHPSW_ EXITSW | O | DC0V/3.3V | DPFSS: On/Off |
| | 9 | DP_OPENSW | O | DC0V/3.3V | DPOCS: On/Off |
| | 10 | GND | - | - | Ground |
| YC2 Connected to the engine PWB | 1 | DP_SETSW | O | DC0V/3.3V | DPOS: On/Off |
| | 2 | DP_REGSW_ TMGSW | O | DC0V/3.3V | DPRS: On/Off |
| | 3 | GND | - | - | Ground |
| | 4 | DP_FEEDSW | O | DC0V/3.3V | DPFS: On/Off |
| YC3 Connected to the original length detection sensor, original width detection sensor | 1 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to DPOLS |
| | 2 | GND | - | - | Ground |
| | 3 | DP_VSIZE SW | I | DC0V/3.3V | DPOLS: On/Off |
| | 4 | 3.3V2 | O | DC3.3V | DC3.3V power output to DPOWS |
| | 5 | DP_WSIZE | I | Analog | DPOWS detection voltage |
| | 6 | GND | - | - | Ground |
| | 7 | NC | - | - | Not used |
| YC4 Connected to the feedshift sensor | 1 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to DPFSS |
| | 2 | GND | - | - | Ground |
| | 3 | DP_JHPSW_ EXITSW | I | DC0V/3.3V | DPFSS: On/Off |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|-----------|-----|-----------|------------------------------|
| YC5 Connected to the original detection sensor, DP open/close sensor | 1 | 3.3V3_LED | O | DC3.3V | DC3.3V power output to DPOS |
| | 2 | GND | - | - | Ground |
| | 3 | DP_SETSW | I | DC0V/3.3V | DPOS: On/Off |
| | 4 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to DPOCS |
| | 5 | GND | - | - | Ground |
| | 6 | DP_OPENSW | I | DC0V/3.3V | DPOCS: On/Off |
| YC6 Connected to the paper feed section, registration sensor | 1 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to DPFS |
| | 2 | GND | - | - | Ground |
| | 3 | DP_FEEDSW | I | DC0V/3.3V | DPFS: On/Off |
| | 4 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to DPRS |
| | 5 | GND | - | - | Ground |
| | 6 | DP_TMGSW | I | DC0V/3.3V | DPRS: On/Off |

(5) DP main PWB (DPMPWB) for DP-5110

(5-1) Connector position




Figure 8-27

(5-2) PWB photograph



Figure 8-28

(5-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|-------------------|-----|-----------|---------------------------------------|
| YC1 | 1 | +3.3V3 | I | DC3.3V | DC3.3V power input from the main unit |
| Connected to the engine PWB | 2 | 3.3V2 | I | DC3.3V | DC3.3V power input from the main unit |
| | 3 | GND | - | - | Ground |
| | 4 | 3.3V2 | I | DC3.3V | DC3.3V power input from the main unit |
| | 5 | DP_DET | O | DC0V | DP connection detection voltage |
| | 6 | DP_HSIZE SW | O | Analog | DPOWS detection voltage |
| | 7 | DP_VSIZE SW | O | DC0V/3.3V | DPOLS: On/Off |
| | 8 | DP_JHPSW_ EXIT SW | O | DC0V/3.3V | DPES: On/Off |
| | 9 | DP_OPENS W | O | DC0V/3.3V | DPOCS: On/Off |
| | 10 | GND | - | - | Ground |
| YC2 | 1 | DP_SET SW | O | DC0V/3.3V | DPOS: On/Off |
| Connected to the engine PWB | 2 | DP_REG SW_ TMGS W | O | DC0V/3.3V | DPTS: On/Off |
| | 3 | GND | - | - | Ground |
| | 4 | DP_FEED SW | O | DC0V/3.3V | DPFS: On/Off |
| YC3 | 1 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to DPOLS |
| Connected to the original length detection sensor, original width detection sensor | 2 | GND | - | - | Ground |
| | 3 | DP_VSIZE SW | I | DC0V/3.3V | DPOLS: On/Off |
| | 4 | 3.3V2 | O | DC3.3V | DC3.3V power output to DPOWS |
| | 5 | DP_WSIZE | I | Analog | DPOWS detection voltage |
| | 6 | GND | - | - | Ground |
| | 7 | NC | - | - | Not used |
| YC4 | 1 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to DPES |
| Connected to the eject sensor | 2 | GND | - | - | Ground |
| | 3 | DP_JHPSW_ EXIT SW | I | DC0V/3.3V | DPES: On/Off |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|-----------|-----|-----------|------------------------------|
| YC5 | 1 | 3.3V3_LED | O | DC3.3V | DC3.3V power output to DPOS |
| Connected to the original detection sensor, DP open/close sensor | 2 | GND | - | - | Ground |
| | 3 | DP_SETSW | I | DC0V/3.3V | DPOS: On/Off |
| | 4 | 3.3V2_LED | O | DC3.3V | DC3.3V power output to DPOCS |
| | 5 | GND | - | - | Ground |
| | 6 | DP_OPENSW | I | DC0V/3.3V | DPOCS: On/Off |
| YC7 | 1 | 3.3V2 | O | DC3.3V | DC3.3V power output to DPTS |
| Connected to the DP timing sensor | 2 | DP_TMGSW | I | DC0V/3.3V | DPTS: On/Off |
| | 3 | GND | - | - | Ground |
| YC8 | 1 | 3.3V2 | O | DC3.3V | DC3.3V power output to DPFS |
| Connected to the paper feed section | 2 | DP_FEEDSW | I | DC0V/3.3V | DPFS: On/Off |
| | 3 | GND | - | - | Ground |
| | 4 | NC | - | - | Not used |

(6) DF main PWB (DFMPWB) for DF-5100

(6-1) Connector position




Figure 8-29

(6-2) PWB photograph




Figure 8-30

(6-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|--------------------|-----|----------------------|---|
| YC3 (30 ppm model) Engine PWB (35/40 ppm models) Connected to the power supply PWB | 1 | GND | - | - | Ground |
| | 2 | GND | - | - | Ground |
| | 3 | 24V1 | I | DC24V | DC24V power input from the main unit |
| | 4 | 24V1 | I | DC24V | DC24V power input from the main unit |
| YC4 Connected to the DF set switch | 1 | 24V1 | O | DC24V | DC24V power output to DFSSW |
| | 2 | SET SW (INTERLOCK) | I | DC0V/24V | DFSSW: On/Off |
| YC5 Connected to the engine PWB | 1 | ENG RDY | O | DC0V/3.3V | Ready signal |
| | 2 | ENG SEL | I | DC0V/3.3V | Select signal |
| | 3 | ENG DI | I | DC0V/ 3.3V(pulse) | Serial communication data signal input |
| | 4 | ENG DO | O | DC0V/ 3.3V(pulse) | Serial communication data signal output |
| | 5 | ENG PAU | - | - | Not used |
| | 6 | DET | - | - | Ground |
| | 7 | ENG CLK | I | DC0V/ 3.3V(pulse) | Serial clock signal |
| | 8 | GND | - | - | Ground |
| YC8 Connected to the eject motor, slide motor, eject release motor | 1 | EJECT MOT 2B | O | DC0V/24V(pulse) | DFEM drive control signal |
| | 2 | EJECT MOT 1B | O | DC0V/24V(pulse) | DFEM drive control signal |
| | 3 | EJECT MOT 2A | O | DC0V/24V(pulse) | DFEM drive control signal |
| | 4 | EJECT MOT 1A | O | DC0V/24V(pulse) | DFEM drive control signal |
| | 5 | STP MOV MOT 2B | O | DC0V/24V(pulse) | DFSLM drive control signal |
| | 6 | STP MOV MOT 1B | O | DC0V/24V(pulse) | DFSLM drive control signal |
| | 7 | STP MOV MOT 2A | O | DC0V/24V(pulse) | DFSLM drive control signal |
| | 8 | STP MOV MOT 1A | O | DC0V/24V(pulse) | DFSLM drive control signal |

| Connector | Pin | Signal | I/O | Voltage | Description | |
|-------------|---|--------------------|----------------------|-----------------|----------------------------|-----------------------------|
| YC8 | 9 | EJE RELS MOT 2B | O | DC0V/24V(pulse) | DFERM drive control signal | |
| | Connected to the eject motor, slide motor, eject release motor | 10 | EJE RELS MOT 1B | O | DC0V/24V(pulse) | DFERM drive control signal |
| | | 11 | EJE RELS MOT 2A | O | DC0V/24V(pulse) | DFERM drive control signal |
| | | 12 | EJE RELS MOT 1A | O | DC0V/24V(pulse) | DFERM drive control signal |
| YC9 | 1 | PADDLE MOT 2B | O | DC0V/24V(pulse) | DFPDM drive control signal | |
| | Connected to the paddle motor, side registration motor 1, side registration motor 2 | 2 | PADDLE MOT 1B | O | DC0V/24V(pulse) | DFPDM drive control signal |
| | | 3 | PADDLE MOT 2A | O | DC0V/24V(pulse) | DFPDM drive control signal |
| | | 4 | PADDLE MOT 1A | O | DC0V/24V(pulse) | DFPDM drive control signal |
| | | 5 | SIDE REG R MOT 2B | O | DC0V/24V(pulse) | DFSRM2 drive control signal |
| | | 6 | SIDE REG R MOT 1B | O | DC0V/24V(pulse) | DFSRM2 drive control signal |
| | | 7 | SIDE REG R MOT 2A | O | DC0V/24V(pulse) | DFSRM2 drive control signal |
| | | 8 | SIDE REG R MOT 1A | O | DC0V/24V(pulse) | DFSRM2 drive control signal |
| | | 9 | SIDE REG F MOT 2B | O | DC0V/24V(pulse) | DFSRM1 drive control signal |
| | | 10 | SIDE REG F MOT 1B | O | DC0V/24V(pulse) | DFSRM1 drive control signal |
| | | 11 | SIDE REG F MOT 2A | O | DC0V/24V(pulse) | DFSRM1 drive control signal |
| | | 12 | SIDE REG F MOT 1A | O | DC0V/24V(pulse) | DFSRM1 drive control signal |
| YC10 | 1 | STP MOT OUT1 | O | DC0V/24V(pulse) | DFSTM drive control signal | |
| | Connected to the stapler | 2 | STP MOT OUT1 | O | DC0V/24V(pulse) | DFSTM drive control signal |
| | | 3 | STP MOT OUT1 | O | DC0V/24V(pulse) | DFSTM drive control signal |
| | | 4 | STP MOT OUT1 | O | DC0V/24V(pulse) | DFSTM drive control signal |
| | | 5 | STP MOT OUT2 | O | DC0V/24V(pulse) | DFSTM drive control signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-------------|---------------------|------|-----------------|----------------------------|
| YC10 | 6 | STP MOT OUT2 | O | DC0V/24V(pulse) | DFSTM drive control signal |
| Connected to the stapler | 7 | STP MOT OUT2 | O | DC0V/24V(pulse) | DFSTM drive control signal |
| | 8 | STP MOT OUT2 | O | DC0V/24V(pulse) | DFSTM drive control signal |
| | 9 | GND | - | - | Ground |
| | 10 | LS | I | DC0V/3.3V | Staple unit LS signal |
| | 11 | READY | I | DC0V/3.3V | Staple unit READY signal |
| | 12 | 5V | O | DC5V | DC5V power output |
| | 13 | HP | I | DC0V/3.3V | Staple unit HP signal |
| YC11 | 1 | TRY MOT OUT2 | O | DC0V/24V(pulse) | DFTM drive control signal |
| Connected to the tray motor | 2 | TRY MOT OUT1 | O | DC0V/24V(pulse) | DFTM drive control signal |
| | YC13 | 1 | 24V2 | O | DC24V |
| Connected to the paper pressing solenoid | 2 | PAP PRE SOL ACT | O | DC0V/24V | DFPPSOL: On/Off (actuate) |
| | 3 | PAP PRE SOL KEEP | O | DC0V/24V | DFPPSOL: On/Off (keep) |
| YC17 | 1 | ENTRY SENS A | O | DC5V | DC5V power output to DFPES |
| Connected to the paper entry sensor | 2 | GND | - | - | Ground |
| | 3 | ENTRY SENS SIG | I | DC0V/3.3V | DFPES: On/Off |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|----------------------------|-----|-----------|-----------------------------|
| YC19 | 1 | SID REG R HP SENS A | O | DC5V | DC5V power output to DFERS2 |
| Connected to the side reg- istration sen- sor 1, side registration sensor 2, tray paper full sensor 1, tray paper full sensor 2, bundle eject sensor, adjustment sensor, slide sensor | 2 | GND | - | - | Ground |
| | 3 | SID REG R HP SENS SIG | I | DC0V/3.3V | DFERS2: On/Off |
| | 4 | SID REG F HP SENS A | O | DC5V | DC5V power output to DFERS1 |
| | 5 | GND | - | - | Ground |
| | 6 | SID REG F HP SENS SIG | I | DC0V/3.3V | DFERS1: On/Off |
| | 7 | GND | - | - | Ground |
| | 8 | PAP SENS SIG | I | DC0V/3.3V | DFMETS: On/Off |
| | 9 | 3.3V | O | DC3.3V | DC3.3V power output |
| | 10 | MTRY FULL SENS A | O | DC5V | DC5V power output to DFETS |
| | 11 | GND | - | - | Ground |
| | 12 | MTRY FULL SENS SIG | I | DC0V/3.3V | DFETS: On/Off |
| | 13 | Paddle HP SENS A | O | DC5V | DC5V power output to DFPPDS |
| | 14 | GND | - | - | Ground |
| | 15 | PADDLE HP SENS SIG | I | DC0V/3.3V | DFPPDS: On/Off |
| | 16 | PAP PRE LOW SENS A | O | DC5V | DC5V power output to DFPPS2 |
| | 17 | GND | - | - | Ground |
| | 18 | PAP PRE LOW SENS SIG | I | DC0V/3.3V | DFPPS2: On/Off |
| | 19 | PAP PRE UP SENS A | O | DC5V | DC5V power output to DFPPS1 |
| | 20 | GND | - | - | Ground |
| | 21 | PAP PRE UP SENS SIG | I | DC0V/3.3V | DFPPS1: On/Off |
| | 22 | BUNDLE HP SENS A | O | DC5V | DC5V power output to DFBDSD |
| | 23 | GND | - | - | Ground |
| | 24 | BUNDLE HP SENS SIG | I | DC0V/3.3V | DFBDSD: On/Off |
| | 25 | ADJUST HP SENS A | O | DC5V | DC5V power output to DFADS |

| Connector | Pin | Signal | I/O | Voltage | Description |
|----------------------------------|-----|---------------------|-----|-----------------|-----------------------------|
| YC19 | 26 | GND | - | - | Ground |
| | 27 | ADJUST HP SENS SIG | I | DC0V/3.3V | DFADS: On/Off |
| | 28 | STP MOV HP SENS A | O | DC5V | DC5V power output to DFSL S |
| | 29 | GND | - | - | Ground |
| | 30 | STP MOV HP SENS SIG | I | DC0V/3.3V | DFSL S: On/Off |
| YC21 | 1 | MIDDLE MOT 1B | O | DC0V/24V(pulse) | DFMM drive control signal |
| Connected to the DF middle motor | 2 | MIDDLE MOT 1A | O | DC0V/24V(pulse) | DFMM drive control signal |
| | 3 | MIDDLE MOT 2A | O | DC0V/24V(pulse) | DFMM drive control signal |
| | 4 | MIDDLE MOT 2B | O | DC0V/24V(pulse) | DFMM drive control signal |

(7) DF main PWB (DFMPWB) for DF-5110

(7-1) Connector position




Figure 8-31

(7-2) PWB photograph




Figure 8-32

(7-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|----------------|-----|----------------------|---|
| YC3 Connected to the power supply PWB | 1 | GND | - | - | Ground |
| | 2 | GND | - | - | Ground |
| | 3 | 24V1 | I | DC24V | DC24V power input from the main unit |
| | 4 | 24V1 | I | DC24V | DC24V power input from the main unit |
| YC4 Connected to the front cover switch, top cover switch | 1 | 24V1 | O | DC24V | DC24V power output to DFFCSW |
| | 2 | FRONT COV SIG | I | DC0V/24V | DFFCSW: On/Off |
| | 3 | TOP COV SOURCE | O | DC24V | DC24V power output to DFTCSW |
| | 4 | TOP COV SIG | I | DC0V/24V | DFTCSW: On/Off |
| YC5 Connected to the engine PWB | 1 | ENG RDY | O | DC0V/3.3V | Ready signal |
| | 2 | ENG SEL | I | DC0V/3.3V | Select signal |
| | 3 | ENG DI | I | DC0V/ 3.3V(pulse) | Serial communication data signal input |
| | 4 | ENG DO | O | DC0V/ 3.3V(pulse) | Serial communication data signal output |
| | 5 | ENG PAU | - | - | Not used |
| | 6 | DET | - | - | Ground |
| | 7 | ENG CLK | I | DC0V/ 3.3V(pulse) | Serial clock signal |
| | 8 | GND | - | - | Ground |
| YC6 Connected to the punch PWB | 1 | 5V | O | DC5V | DC5V power output |
| | 2 | 3.3V | O | DC3.3V | DC3.3V power output |
| | 3 | 3.3V | O | DC3.3V | DC3.3V power output |
| | 4 | GND | - | - | Ground |
| | 5 | GND | - | - | Ground |
| | 6 | PHPES REM | O | DC0V/3.3V | PUPES: On/Off |
| | 7 | PHMOT REM | O | DC0V/3.3V | PUM: On/Off |
| | 8 | PU RDY | I | DC0V/3.3V | Ready signal |
| | 9 | PU SEL | O | DC0V/3.3V | Select signal |
| | 10 | PU CLK | O | DC0V/3.3V | Clock signal |
| | 11 | PU DI | I | DC0V/3.3V | Serial communication data signal input |
| | 12 | PU DO | O | DC0V/3.3V | Serial communication data signal output |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|-----------------|-----|-----------------|----------------------------|
| YC7 | 1 | GND | - | - | Ground |
| Connected to the punch PWB | 2 | 24V2 | O | DC24V | DC24V power output |
| YC8 | 1 | EJECT MOT 2B | O | DC0V/24V(pulse) | DFEM drive control signal |
| Connected to the eject motor, slide motor, eject release motor, paper entry motor, middle motor | 2 | EJECT MOT 1B | O | DC0V/24V(pulse) | DFEM drive control signal |
| | 3 | EJECT MOT 2A | O | DC0V/24V(pulse) | DFEM drive control signal |
| | 4 | EJECT MOT 1A | O | DC0V/24V(pulse) | DFEM drive control signal |
| | 5 | STP MOV MOT 2B | O | DC0V/24V(pulse) | DFSLM drive control signal |
| | 6 | STP MOV MOT 1B | O | DC0V/24V(pulse) | DFSLM drive control signal |
| | 7 | STP MOV MOT 2A | O | DC0V/24V(pulse) | DFSLM drive control signal |
| | 8 | STP MOV MOT 1A | O | DC0V/24V(pulse) | DFSLM drive control signal |
| | 9 | EJE RELS MOT 2B | O | DC0V/24V(pulse) | DFERM drive control signal |
| | 10 | EJE RELS MOT 1B | O | DC0V/24V(pulse) | DFERM drive control signal |
| | 11 | EJE RELS MOT 2A | O | DC0V/24V(pulse) | DFERM drive control signal |
| | 12 | EJE RELS MOT 1A | O | DC0V/24V(pulse) | DFERM drive control signal |
| | 13 | ENTRY MOT 2B | O | DC0V/24V(pulse) | DFPEM drive control signal |
| | 14 | ENTRY MOT 1B | O | DC0V/24V(pulse) | DFPEM drive control signal |
| | 15 | ENTRY MOT 2A | O | DC0V/24V(pulse) | DFPEM drive control signal |
| | 16 | ENTRY MOT 1A | O | DC0V/24V(pulse) | DFPEM drive control signal |
| | 17 | MIDDLE MOT 2B | O | DC0V/24V(pulse) | DFMM drive control signal |
| | 18 | MIDDLE MOT 1B | O | DC0V/24V(pulse) | DFMM drive control signal |
| | 19 | MIDDLE MOT 2A | O | DC0V/24V(pulse) | DFMM drive control signal |
| | 20 | MIDDLE MOT 1A | O | DC0V/24V(pulse) | DFMM drive control signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|-------------------|-----|-----------------|-----------------------------|
| YC9 | 1 | PADDLE MOT 2B | O | DC0V/24V(pulse) | DFPDM drive control signal |
| Connected to the paddle motor, side registration motor 1, side registration motor 2 | 2 | PADDLE MOT 1B | O | DC0V/24V(pulse) | DFPDM drive control signal |
| | 3 | PADDLE MOT 2A | O | DC0V/24V(pulse) | DFPDM drive control signal |
| | 4 | PADDLE MOT 1A | O | DC0V/24V(pulse) | DFPDM drive control signal |
| | 5 | SIDE REG R MOT 2B | O | DC0V/24V(pulse) | DFSRM2 drive control signal |
| | 6 | SIDE REG R MOT 1B | O | DC0V/24V(pulse) | DFSRM2 drive control signal |
| | 7 | SIDE REG R MOT 2A | O | DC0V/24V(pulse) | DFSRM2 drive control signal |
| | 8 | SIDE REG R MOT 1A | O | DC0V/24V(pulse) | DFSRM2 drive control signal |
| | 9 | SIDE REG F MOT 2B | O | DC0V/24V(pulse) | DFSRM1 drive control signal |
| | 10 | SIDE REG F MOT 1B | O | DC0V/24V(pulse) | DFSRM1 drive control signal |
| | 11 | SIDE REG F MOT 2A | O | DC0V/24V(pulse) | DFSRM1 drive control signal |
| | 12 | SIDE REG F MOT 1A | O | DC0V/24V(pulse) | DFSRM1 drive control signal |
| YC10 | 1 | STPMOT OUT1 | O | DC0V/24V(pulse) | DFSTP drive control signal |
| Connected to the staple unit | 2 | STPMOT OUT1 | O | DC0V/24V(pulse) | DFSTP drive control signal |
| | 3 | STPMOT OUT1 | O | DC0V/24V(pulse) | DFSTP drive control signal |
| | 4 | STPMOT OUT1 | O | DC0V/24V(pulse) | DFSTP drive control signal |
| | 5 | STPMOT OUT2 | O | DC0V/24V(pulse) | DFSTP drive control signal |
| | 6 | STPMOT OUT2 | O | DC0V/24V(pulse) | DFSTP drive control signal |
| | 7 | STPMOT OUT2 | O | DC0V/24V(pulse) | DFSTP drive control signal |
| | 8 | STPMOT OUT2 | O | DC0V/24V(pulse) | DFSTP drive control signal |
| | 9 | GND | - | - | Ground |
| | 10 | LS | I | DC0V/3.3V | Staple unit LS signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--------------------------------------|-----|---------------------|-----|-----------------|--------------------------------|
| YC10 | 11 | READY | I | DC0V/3.3V | Staple unit READY signal |
| | 12 | 5V | O | DC5V | DC5V power output |
| | 13 | HP | I | DC0V/3.3V | Staple unit HP signal |
| YC11 | 1 | TRY MOT OUT2 | O | DC0V/24V(pulse) | DFTM drive control signal |
| Connected to the DF tray motor | 2 | TRY MOT OUT1 | O | DC0V/24V(pulse) | DFTM drive control signal |
| YC16 | 1 | MTRY U SENS K | I | DC0V/3.3V | DFTUSS1: On/Off |
| | 2 | GND | - | - | Ground |
| | 3 | MTRY U SENS SIG | I | DC0V/3.3V | DFTUSS2: On/Off |
| | 4 | 3.3V | O | DC3.3V | DC3.3V power output to DFTUSS2 |
| | 5 | 3.3V | O | DC3.3V | DC3.3V power output to DFTUSS1 |
| | 6 | MTRY U SENS K | O | DC0V/3.3V | DFTUSS1: On/Off |
| YC17 | 1 | MID EJE SENS A | O | DC5V | DC5V power output to DFMES |
| | 2 | GND | - | - | Ground |
| | 3 | MID EJE SENS SIG | I | DC0V/3.3V | DFMES: On/Off |
| | 4 | GND | - | - | Ground |
| | 5 | ENTRY SENS SIG | I | DC0V/3.3V | DFPES: On/Off |
| | 6 | 3.3V | O | DC3.3V | DC3.3V power output |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|--------------------------|-----|-----------|-----------------------------|
| YC19 | 1 | SID REG R HP SENS A | O | DC5V | DC5V power output to DFSRS2 |
| Connected to the side reg- istration sen- sor 1, side registration sensor 2, tray paper full sensor 1, tray paper full sensor 2, bundle eject sensor, adjustment sensor, slide sensor | 2 | GND | - | - | Ground |
| | 3 | SID REG R HP SENS SIG | I | DC0V/3.3V | DFSRS2: On/Off |
| | 4 | SID REG F HP SENS A | O | DC5V | DC5V power output to DFSRS1 |
| | 5 | GND | - | - | Ground |
| | 6 | SID REG F HP SENS SIG | I | DC0V/3.3V | DFSRS1: On/Off |
| | 7 | GND | - | - | Ground |
| | 8 | PAP SENS SIG | I | DC0V/3.3V | DFMTS: On/Off |
| | 9 | 3.3V | O | DC3.3V | DC3.3V power output |
| | 10 | BUNDLE HP SENS A | O | DC5V | DC5V power output to DFBDS |
| | 11 | GND | - | - | Ground |
| | 12 | BUNDLE HP SENS SIG | I | DC0V/3.3V | DFBDS: On/Off |
| | 13 | PADDLE HP SENS A | O | DC5V | DC5V power output to DFPDS |
| | 14 | GND | - | - | Ground |
| | 15 | PADDLE HP SENS SIG | I | DC0V/3.3V | DFPDS: On/Off |
| | 16 | MTRY HALF SENS A | O | DC5V | DC5V power output to DFTS2 |
| | 17 | GND | - | - | Ground |
| | 18 | MTRY HALF SENS SIG | I | DC0V/3.3V | DFTS2: On/Off |
| | 19 | MTRY FULL SENS A | O | DC5V | DC5V power output to DFTS3 |
| | 20 | GND | - | - | Ground |
| | 21 | MTRY FULL SENS SIG | I | DC0V/3.3V | DFTS3: On/Off |
| | 22 | MTRY HP SENS A | O | DC5V | DC5V power output to DFTS1 |
| | 23 | GND | - | - | Ground |
| | 24 | MTRY HP SENS SIG | I | DC0V/3.3V | DFTS1: On/Off |
| | 25 | ADJUST HP SENS A | O | DC5V | DC5V power output to DFADS |
| | 26 | GND | - | - | Ground |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|---------------------|-----|-----------|----------------------------|
| YC19 | 27 | ADJUST HP SENS SIG | I | DC0V/3.3V | DFADS: On/Off |
| Connected to the side registration sensor 1, side registration sensor 2, tray paper full sensor 1, tray paper full sensor 2, bundle eject sensor, adjustment sensor, slide sensor | 28 | STP MOV HP SENS A | O | DC5V | DC5V power output to DFSLs |
| | 29 | GND | - | - | Ground |
| | 30 | STP MOV HP SENS SIG | I | DC0V/3.3V | DFSLs: On/Off |
| | | | | | |

(8) DF main PWB (DFMPWB) for DF-5120

(8-1) Connector position




Figure 8-33

(8-2) PWB photograph




Figure 8-34

(8-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|------------------|-----|----------------------|---|
| YC3 Connected to the power supply PWB | 1 | GND | - | - | Ground |
| | 2 | GND | - | - | Ground |
| | 3 | 24V1 | I | DC24V | DC24V power input from the main unit |
| | 4 | 24V1 | I | DC24V | DC24V power input from the main unit |
| YC4 Connected to the front cover switch, eject cover switch | 1 | 24V1 | O | DC24V | DC24V power output to DFFCSW |
| | 2 | FRONT COV SIG | I | DC0V/24V | DFFCSW: On/Off |
| | 3 | EJECT COV SOURCE | O | DC24V | DC24V power output to DFECSSW |
| | 4 | EJECT COV SIG | I | DC0V/24V | DFECSSW: On/Off |
| YC5 Connected to the engine PWB | 1 | ENG RDY | O | DC0V/3.3V | Ready signal |
| | 2 | ENG SEL | I | DC0V/3.3V | Select signal |
| | 3 | ENG DI | I | DC0V/ 3.3V(pulse) | Serial communication data signal input |
| | 4 | ENG DO | O | DC0V/ 3.3V(pulse) | Serial communication data signal output |
| | 5 | ENG PAU | - | - | Not used |
| | 6 | DET | - | - | Ground |
| | 7 | ENG CLK | I | DC0V/ 3.3V(pulse) | Serial clock signal |
| | 8 | GND | - | - | Ground |
| YC6 Connected to the punch PWB | 1 | 5V | O | DC5V | DC5V power output |
| | 2 | 3.3V | O | DC3.3V | DC3.3V power output |
| | 3 | 3.3V | O | DC3.3V | DC3.3V power output |
| | 4 | GND | - | - | Ground |
| | 5 | GND | - | - | Ground |
| | 6 | PHPES REM | O | DC0V/3.3V | PUPES: On/Off |
| | 7 | PHMOT REM | O | DC0V/3.3V | PUM: On/Off |
| | 8 | PU RDY | I | DC0V/3.3V | Ready signal |
| | 9 | PU SEL | O | DC0V/3.3V | Select signal |
| | 10 | PU CLK | O | DC0V/3.3V | Clock signal |
| | 11 | PU DI | I | DC0V/3.3V | Serial communication data signal input |
| | 12 | PU DO | O | DC0V/3.3V | Serial communication data signal output |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|-----------------|-----|-----------------|----------------------------|
| YC7 | 1 | GND | - | - | Ground |
| Connected to the punch PWB | 2 | 24V2 | O | DC24V | DC24V power output |
| YC8 | 1 | EJYEECT MOT 2B | O | DC0V/24V(pulse) | DFEM drive control signal |
| Connected to the eject motor, slide motor, eject release motor, paper entry motor, middle motor | 2 | EJYEECT MOT 1B | O | DC0V/24V(pulse) | DFEM drive control signal |
| | 3 | EJYEECT MOT 2A | O | DC0V/24V(pulse) | DFEM drive control signal |
| | 4 | EJYEECT MOT 1A | O | DC0V/24V(pulse) | DFEM drive control signal |
| | 5 | STP MOV MOT 2B | O | DC0V/24V(pulse) | DFSLM drive control signal |
| | 6 | STP MOV MOT 1B | O | DC0V/24V(pulse) | DFSLM drive control signal |
| | 7 | STP MOV MOT 2A | O | DC0V/24V(pulse) | DFSLM drive control signal |
| | 8 | STP MOV MOT 1A | O | DC0V/24V(pulse) | DFSLM drive control signal |
| | 9 | EJE RELS MOT 2B | O | DC0V/24V(pulse) | DFERM drive control signal |
| | 10 | EJE RELS MOT 1B | O | DC0V/24V(pulse) | DFERM drive control signal |
| | 11 | EJE RELS MOT 2A | O | DC0V/24V(pulse) | DFERM drive control signal |
| | 12 | EJE RELS MOT 1A | O | DC0V/24V(pulse) | DFERM drive control signal |
| | 13 | ENTRY MOT 2B | O | DC0V/24V(pulse) | DFPEM drive control signal |
| | 14 | ENTRY MOT 1B | O | DC0V/24V(pulse) | DFPEM drive control signal |
| | 15 | ENTRY MOT 2A | O | DC0V/24V(pulse) | DFPEM drive control signal |
| | 16 | ENTRY MOT 1A | O | DC0V/24V(pulse) | DFPEM drive control signal |
| | 17 | MIDDLE MOT 2B | O | DC0V/24V(pulse) | DFMM drive control signal |
| | 18 | MIDDLE MOT 1B | O | DC0V/24V(pulse) | DFMM drive control signal |
| | 19 | MIDDLE MOT 2A | O | DC0V/24V(pulse) | DFMM drive control signal |
| | 20 | MIDDLE MOT 1A | O | DC0V/24V(pulse) | DFMM drive control signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|-------------------|------|-----------------|-----------------------------|
| YC9 | 1 | PADDLE MOT 2B | O | DC0V/24V(pulse) | DFPDM drive control signal |
| Connected to the paddle motor, side registration motor 1, side registration motor 2, eject clutch | 2 | PADDLE MOT 1B | O | DC0V/24V(pulse) | DFPDM drive control signal |
| | 3 | PADDLE MOT 2A | O | DC0V/24V(pulse) | DFPDM drive control signal |
| | 4 | PADDLE MOT 1A | O | DC0V/24V(pulse) | DFPDM drive control signal |
| | 5 | SIDE REG R MOT 2B | O | DC0V/24V(pulse) | DFSRM2 drive control signal |
| | 6 | SIDE REG R MOT 1B | O | DC0V/24V(pulse) | DFSRM2 drive control signal |
| | 7 | SIDE REG R MOT 2A | O | DC0V/24V(pulse) | DFSRM2 drive control signal |
| | 8 | SIDE REG R MOT 1A | O | DC0V/24V(pulse) | DFSRM2 drive control signal |
| | 9 | SIDE REG F MOT 2B | O | DC0V/24V(pulse) | DFSRM1 drive control signal |
| | 10 | SIDE REG F MOT 1B | O | DC0V/24V(pulse) | DFSRM1 drive control signal |
| | 11 | SIDE REG F MOT 2A | O | DC0V/24V(pulse) | DFSRM1 drive control signal |
| | 12 | SIDE REG F MOT 1A | O | DC0V/24V(pulse) | DFSRM1 drive control signal |
| | 13 | EJECT CL | O | DC0V/24V | DFECL: On/Off |
| | | 14 | 24V2 | I | DC24V |
| YC10 | 1 | STP MOT OUT1 | O | DC0V/24V(pulse) | DFSTP drive control signal |
| Connected to the stapler | 2 | STP MOT OUT1 | O | DC0V/24V(pulse) | DFSTP drive control signal |
| | 3 | STP MOT OUT1 | O | DC0V/24V(pulse) | DFSTP drive control signal |
| | 4 | STP MOT OUT1 | O | DC0V/24V(pulse) | DFSTP drive control signal |
| | 5 | STP MOT OUT2 | O | DC0V/24V(pulse) | DFSTP drive control signal |
| | 6 | STP MOT OUT2 | O | DC0V/24V(pulse) | DFSTP drive control signal |
| | 7 | STP MOT OUT2 | O | DC0V/24V(pulse) | DFSTP drive control signal |
| | 8 | STP MOT OUT2 | O | DC0V/24V(pulse) | DFSTP drive control signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|------------------|-----|-----------------|--------------------------------|
| YC10 Connected to the stapler | 9 | GND | - | - | Ground |
| | 10 | LS | I | DC0V/3.3V | Staple unit LS signal |
| | 11 | READY | I | DC0V/3.3V | Staple unit READY signal |
| | 12 | 5V | O | DC5V | DC5V power output |
| | 13 | HP | I | DC0V/3.3V | Staple unit HP signal |
| YC12 Connected to the DF tray motor | 1 | BRAKE | O | DC0V/24V(pulse) | DFTN drive control signal |
| | 2 | DIR | O | DC0V/24V(pulse) | DFTN drive control signal |
| | 3 | CLK | O | DC0V/24V(pulse) | DFTN drive control signal |
| | 4 | ENABLE | O | DC0V/24V(pulse) | DFTN drive control signal |
| | 5 | GND | - | - | Ground |
| | 6 | 24V2 | O | DC24V | DC24V power output |
| YC13 Connected to the feedshift solenoid | 1 | 24V2 | O | DC24V | DC24V power output |
| | 2 | SUB MID SOL ACT | O | DC0V/24V | DFSSOL: On/Off |
| | 3 | SUB MID SOL KEEP | O | DC0V/24V | DFSSOL: On/Off |
| YC15 Connected to the DF operation panel PWB | 1 | LED1 | O | DC0V/3.3V | LED output |
| | 2 | LED2 | O | DC0V/3.3V | LED output |
| | 3 | LED3 | O | DC0V/3.3V | LED output |
| | 4 | LED4 | O | DC0V/3.3V | LED output |
| | 5 | KEY1 | I | DC0V/3.3V | Key input |
| | 6 | KEY2 | I | DC0V/3.3V | Key input |
| | 7 | GND | - | - | Ground |
| | 8 | 3.3V | O | DC3.3V | DC3.3V power output to DFTUSS1 |
| | 9 | MTRY U SENS K | O | DC0V/3.3V | DFTUSS1: On/Off |
| YC16 Connected to the tray paper full sensor | 1 | MTRY U SENS K | I | DC0V/3.3V | DFTUSS1: On/Off |
| | 2 | GND | - | - | Ground |
| | 3 | MTRY U SENS SIG | I | DC0V/3.3V | DFTUSS2: On/Off |
| | 4 | 3.3V | O | DC3.3V | DC3.3V power output to DFTUSS2 |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|-----------------------|-----|-----------|------------------------------|
| YC17 Connected to the middle sensor, paper entry sensor, sub tray eject sensor | 1 | MID EJE SENS A | O | DC5V | DC5V power output to DFMES |
| | 2 | GND | - | - | Ground |
| | 3 | MID EJE SENS SIG | I | DC0V/3.3V | DFMES: On/Off |
| | 4 | GND | - | - | Ground |
| | 5 | ENTRY SENS SIG | I | DC0V/3.3V | DFPES: On/Off |
| | 6 | 3.3V | O | DC3.3V | DC3.3V power output to DFPES |
| | 7 | STRY EJE SENS A | O | DC5V | DC5V power output to DFSES |
| | 8 | GND | - | - | Ground |
| | 9 | STRY EJE SENS SIG | I | DC0V/3.3V | DFSES: On/Off |
| YC18 Connected to the tray sensor 3 | 1 | MTRY FULL SENS A | O | DC5V | DC5V power output to DFTS3 |
| | 2 | GND | - | - | Ground |
| | 3 | MTRY FULL SENS SIG | I | DC0V/3.3V | DFTS3: On/Off |
| YC19 Connected to the side registration sensor 1, side registration sensor 2, tray paper full sensor 1, tray paper full sensor 2, bundle eject sensor, adjustment sensor, slide sensor | 1 | SID REG R HP SENS A | O | DC5V | DC5V power output to DFSRS2 |
| | 2 | GND | - | - | Ground |
| | 3 | SID REG R HP SENS SIG | I | DC0V/3.3V | DFSRS2: On/Off |
| | 4 | SID REG F HP SENS A | O | DC5V | DC5V power output to DFSRS1 |
| | 5 | GND | - | - | Ground |
| | 6 | SID REG F HP SENS SIG | I | DC0V/3.3V | DFSRS1: On/Off |
| | 7 | GND | - | - | Ground |
| | 8 | PAP SENS SIG | I | DC0V/3.3V | DFMTS: On/Off |
| | 9 | 3.3V | O | DC3.3V | DC3.3V power output |
| | 10 | BUNDLE HP SENS A | O | DC5V | DC5V power output to DFBDS |
| | 11 | GND | - | - | Ground |
| | 12 | BUNDLE HP SENS SIG | I | DC0V/3.3V | DFBDS: On/Off |
| | 13 | PADDLE HP SENS A | O | DC5V | DC5V power output to DFPDS |

| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|---------------------|-----|-----------|----------------------------|
| YC19 | 14 | GND | - | - | Ground |
| Connected to the side registration sensor 1, side registration sensor 2, tray paper full sensor 1, tray paper full sensor 2, bundle eject sensor, adjustment sensor, slide sensor | 15 | PADDLE HP SENS SIG | I | DC0V/3.3V | DFPDS: On/Off |
| | 16 | MTRY HALF SENS A | O | DC5V | DC5V power output to DFTS2 |
| | 17 | GND | - | - | Ground |
| | 18 | MTRY HALF SENS SIG | I | DC0V/3.3V | DFTS2: On/Off |
| | 19 | MTRY HP1 SENS A | O | DC5V | DC5V power output to DFTS1 |
| | 20 | GND | - | - | Ground |
| | 21 | MTRY HP1 SENS SIG | I | DC0V/3.3V | DFTS1: On/Off |
| | 22 | NC | - | - | Not used |
| | 23 | NC | - | - | Not used |
| | 24 | NC | - | - | Not used |
| | 25 | ADJUST HP SENS A | O | DC5V | DC5V power output to DFADS |
| | 26 | GND | - | - | Ground |
| | 27 | ADJUST HP SENS SIG | I | DC0V/3.3V | DFADS: On/Off |
| | 28 | STP MOV HP SENS A | O | DC5V | DC5V power output to DFSLs |
| | 29 | GND | - | - | Ground |
| | 30 | STP MOV HP SENS SIG | I | DC0V/3.3V | DFSLs: On/Off |

(9) Mail box main PWB (MBMPWB) for MT-5100

(9-1) Connector position




Figure 8-35

(9-2) PWB photograph




Figure 8-36

(9-3) Connector lists

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|-----------------|-----|----------------------|---|
| YC1 (30 ppm model) Connected to the engine PWB (35/40 ppm models) Connected to the engine PWB, power supply PWB | 1 | READY | I | DC0V/3.3V | Mail box ready signal |
| | 2 | SELECT | I | DC0V/3.3V | Mail box select signal |
| | 3 | SDI | I | DC0V/ 3.3V(pulse) | Mail box serial communication data signal |
| | 4 | SDO | O | DC0V/ 3.3V(pulse) | Mail box serial communication data signal |
| | 5 | PAUSE | O | DC0V/3.3V | Mail box pause signal |
| | 6 | DETECT(GND) | - | - | Ground |
| | 7 | SCLK | I | DC0V/ 3.3V(pulse) | Mail box clock signal |
| | 8 | GND (to Engine) | - | - | Ground |
| | 9 | GND (to LVU) | - | - | Ground |
| | 10 | GND (to LVU) | - | - | Ground |
| | 11 | 24V | I | DC24V | DC24V power input |
| | 12 | 24V | I | DC24V | DC24V power input |
| YC2 Connected to the tray overflow sensor 1, 2, 3 and 4, tray eject sensor (photo receptor) | 1 | LED | O | DC0V/3.3V | LED signal |
| | 2 | GND | - | - | Ground |
| | 3 | EJECT | I | DC0V/3.3V | TEJS: On/Off |
| | 4 | 3.3V | O | DC3.3V | DC3.3V power output |
| | 5 | ANODE | O | DC3.3V | DC3.3V power output |
| | 6 | GND | - | - | Ground |
| | 7 | OFS1 | I | DC0V/3.3V | TOFSW1: On/Off |
| | 8 | ANODE | O | DC3.3V | DC3.3V power output |
| | 9 | GND | - | - | Ground |
| | 10 | OFS2 | I | DC0V/3.3V | TOFSW2: On/Off |
| | 11 | ANODE | O | DC3.3V | DC3.3V power output |
| | 12 | GND | - | - | Ground |
| | 13 | OFS3 | I | DC0V/3.3V | TOFSW3: On/Off |
| | 14 | ANODE | O | DC3.3V | DC3.3V power output |
| | 15 | GND | - | - | Ground |
| | 16 | OFS4 | I | DC0V/3.3V | TOFSW4: On/Off |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|--------------|-----|----------------------|---------------------------|
| YC3 | 1 | 3.3V | O | DC3.3V | DC3.3V power output |
| Connected to the tray overflow sensor 5, tray overflow sensor 6, tray eject sensor (photo receptor), tray eject sensor (photo transmitter), MB feedshift HP sensor, MB cover open/close sensor | 2 | LED | O | DC0V/ 3.3V(pulse) | TEJS (photo transmitter) |
| | 3 | ANODE | O | DC3.3V | DC3.3V power output |
| | 4 | GND | - | - | Ground |
| | 5 | OFS5 | I | DC0V/3.3V | TOFSW5: On/Off |
| | 6 | ANODE | O | DC3.3V | DC3.3V power output |
| | 7 | GND | - | - | Ground |
| | 8 | OFS6 | I | DC0V/3.3V | TOFSW6: On/Off |
| | 9 | ANODE | - | - | Not used |
| | 10 | GND | - | - | Not used |
| | 11 | OFS7 | - | - | Not used |
| | 12 | ANODE | O | DC3.3V | DC3.3V power output |
| | 13 | GND | - | - | Ground |
| | 14 | SHIFT HP SIG | I | DC0V/3.3V | MHPS: On/Off |
| | 15 | ANODE | O | DC3.3V | DC3.3V power output |
| | 16 | GND | - | - | Ground |
| | 17 | COVER OPEN | I | DC0V/3.3V | MCOS: On/Off |
| YC4 | 1 | MOTOR_A | O | DC0V/24V(pulse) | MBDM drive control signal |
| Mail box drive motor | 2 | MOTOR A | O | DC0V/24V(pulse) | MBDM drive control signal |
| | 3 | MOTOR B | O | DC0V/24V(pulse) | MBDM drive control signal |
| | 4 | MOTOR_B | O | DC0V/24V(pulse) | MBDM drive control signal |

(10)Punch PWB (PUNPWB) for PH-5110

(10-1) Connector position




Figure 8-37

(10-2) PWB photograph



Figure 8-38

(10-3) Connector lists


| Connector | Pin | Signal | I/O | Voltage | Description |
|---|-----|-----------------|-----|----------------------|---|
| YC1 | 1 | PH_SDI | I | DC0V/ 3.3V(pulse) | Serial communication data signal input |
| Connected to the DF main PWB | 2 | PH_SDO | O | DC0V/ 3.3V(pulse) | Serial communication data signal output |
| | 3 | PH_CLK | I | DC0V/ 3.3V(pulse) | Clock signal |
| | 4 | PH_SEL | I | DC0V/3.3V | Select signal |
| | 5 | PH_RDY | O | DC0V/3.3V | Ready signal |
| | 6 | PHMOT_REQ | I | DC0V/3.3V | PUM: On/Off |
| | 7 | PHPES_REQ | I | DC0V/3.3V | PUPES: On/Off |
| | 8 | GND | - | - | Ground |
| | 9 | GND | - | - | Ground |
| | 10 | 3.3V | I | DC3.3V | DC3.3V power input from the main unit |
| | 11 | 3.3V | I | DC3.3V | DC3.3V power input from the main unit |
| | 12 | NC | - | - | Not used |
| YC2 | 1 | GND | - | - | Ground |
| Connected to the DF main PWB | 2 | 24V2 | I | DC24V | DC24V power input from DF |
| | | | | | |
| YC3 | 1 | PHADJ_MOT 2B | O | DC0V/24V(pulse) | PUSLM drive control signal |
| Connected to the punch slide motor, conveying guide release solenoid | 2 | PHADJ_MOT 1B | O | DC0V/24V(pulse) | PUSLM drive control signal |
| | 3 | PHADJ_MOT 2A | O | DC0V/24V(pulse) | PUSLM drive control signal |
| | 4 | PHADJ_MOT 1A | O | DC0V/24V(pulse) | PUSLM drive control signal |
| | 5 | 24V2 | O | DC24V | DC24V power output to PUSOL |
| | 6 | GDSOL_PUL | O | DC0V/24V | PUSOL: On/Off (actuate) |
| | 7 | GDSOL_HLD | O | DC0V/24V | PUSOL: On/Off (keep) |
| YC4 | 1 | PHMOT_P | O | DC0V/24V(pulse) | PUM drive control signal |
| Connected to the punch motor | 2 | NC | - | - | Not used |
| | 3 | PHMOT_N | O | DC0V/24V(pulse) | PUM drive control signal |

| Connector | Pin | Signal | I/O | Voltage | Description |
|--|-----|------------|-----|-----------|-------------------------------|
| YC5 Connected to the punch solenoid, punch paper edge sensor 2 | 1 | 24V2 | O | DC24V | DC24V power output to PUSOL |
| | 2 | PHSOL_PUL | O | DC0V/24V | PUSOL: On/Off (actuate) |
| | 3 | PHSOL_RET | O | DC0V/24V | PUSOL: On/Off (return) |
| | 4 | PHLED_B | O | DC0V/3.3V | PUPES1_B: On/Off |
| | 5 | PHLED_C | O | DC0V/3.3V | PUPES1_C: On/Off |
| | 6 | PHLED_D | O | DC0V/3.3V | PUPES1_D: On/Off |
| | 7 | PHLED_AN | O | DC3.3V | DC3.3V power output to PUPES1 |
| YC6 Connected to the punch slide sensor, punch tank set switch, punch tank full sensor 1, punch tank full sensor 2 | 1 | SENS3.3V | O | DC3.3V | DC3.3V power output to PUHPS |
| | 2 | GND | - | - | Ground |
| | 3 | PHADJ_HP | O | DC0V/3.3V | PUHPS_A: On/Off |
| | 4 | TANKLED_A | O | DC0V/3.3V | PUPES2_A: On/Off |
| | 5 | TANKLED_B | O | DC0V/3.3V | PUPES2_B: On/Off |
| | 6 | TANKLED_C | O | DC0V/3.3V | PUPES2_C: On/Off |
| | 7 | TANKLED_AN | O | DC3.3V | DC3.3V power output to PUPES2 |
| | 8 | GND | - | - | Ground |
| | 9 | PHTNK_SET | I | DC0V/3.3V | PUTSSW: On/Off |
| | 10 | TANK_FULL | I | DC0V/3.3V | PUTFS: On/Off |
| | 11 | GND | - | - | Ground |
| YC8 Connected to the punch pulse sensor, punch home position sensor, punch paper edge sensor 1 | 1 | SENS3.3V | O | DC3.3V | DC3.3V power output to PUPS |
| | 2 | GND | - | - | Ground |
| | 3 | PHMOT_PLS | I | DC0V/3.3V | PUPS: On/Off |
| | 4 | SENS3.3V | O | DC3.3V | DC3.3V power output to PUHPS |
| | 5 | GND | - | - | Ground |
| | 6 | PHMOT_HP | I | DC0V/3.3V | PUHPS: On/Off |
| | 7 | PHPES_DET | I | DC0V/3.3V | PUPES1: On/Off |
| | 8 | GND | - | - | Ground |

9 Appendixes

9-1 Appendixes

(1) Repetitive defects gauge



* : The repetitive marks interval may vary depending on operating conditions.

(2) Firmware environment commands

The printer maintains a number of printing parameters in its memory. These parameters may be changed permanently with the FRPO (Firmware RePrOgram) commands.

This section provides information on how to use the FRPO command and its parameters using examples.

Using FRPO commands for reprogramming the firmware

The current settings of the FRPO parameters are listed as the optional values on the service status page.

Note: Before changing any FRPO parameters, print out a service status page, so you will know the parameter-values before the changes are made. To return FRPO parameters to their factory default values, send the FRPO INIT (FRPO-INITialize) command. (!R! FRPO INIT; EXIT;)

The FRPO command is sent to the printer in the following sequence:

!R! FRPO parameter, value; EXIT;

Example: Changing emulation mode to PC-PR201/65A

!R! FRPO P1, 11; EXIT;

FRPO parameters

| Items | FRPO | Setting value | Factory setting |
|----------------------------|------|---|-----------------------|
| Top margin | A1 | Integer value in inch | 0 |
| | A2 | decimal value in 1/100 inch increments | 0 |
| Left margin | A3 | Integer value in inch | 0 |
| | A4 | decimal value in 1/100 inch increments | 0 |
| Page length | A5 | Integer value in inch | 13 16(100 V model) |
| | A6 | decimal value in 1/100 inch increments | 61 |
| Page width | A7 | Integer value in inch | 13 16(100 V model) |
| | A8 | decimal value in 1/100 inch increments | 61 |
| Default pattern resolution | B8 | 0: 300 dpi 1: 600 dpi | 0 |
| Page orientation | C1 | 0: Portrait 1: Landscape | 0 |
| Default font* | C2 | Middle two digits of power-up font | 0 |
| | C3 | Last two digits of power-up font | 0 |
| | C5 | First two digits of power-up font | 0 |
| PCL font switching | C8 | 0: HP compatible mode 32: Compatibility mode | 0 |
| Total host buffer size | H8 | 0 to 99 in units of the size defined by FRPO S5 | 5 |

| Items | FRPO | Setting value | Factory setting |
|---|------|---|---|
| Form feed time-out value | H9 | Value in units of 5 seconds (0 to 99). | 6 1(100 V model) |
| Reduction (100 V model only) | J0 | 0: 100% 5: 70 % 6: 81 % 7: 86 % 8: 94 % 9: 98 % | 0 |
| Auto linefeed mode (100 V model only) (Japanese emulation only) | J7 | 0: Auto linefeed 1: No auto linefeed | 0 |
| Horizontal offset (100 V model only) | K0 | -7 to +7 (Integer), unit: cm | 0 |
| | K1 | -99 to +99 (Decimal), unit: 1/100 cm | 0 |
| Vertical offset (100 V model only)* | K2 | -7 to -7 (Integer), unit: cm | 0 |
| | K3 | -99 to +99 (Decimal), unit: 1/100 cm | 0 |
| Kanji font number setting (100 V model only) | K4 | 0: Same as V7 1: Mincho 40 dots 2: Gothic 40 dots 5: Mincho 48 dots 6: Gothic 48 dots | 0 |
| New/old JIS code switching | K6 | 0: JIS X 0208: 1990 1: JIS X 0208: 1978 8: JIS X 0213: 2004 | 0 |
| Duplex printing mode selection | N4 | 0: OFF 1: Long-edge mode (long-edge bind) 2: Short-edge mode (Short-edge bind) | 0 |
| Sleep timer time-out time | N5 | 1 to 240 minutes | 30 ppm model: 30 35/45 ppm model: 45 |
| Ecoprint level | N6 | 0: OFF 2: ON | 0 |
| Resolution (35/40 ppm models only) | N8 | 0: 300 dpi 1: 600 dpi 3: 1200 dpi | 1 |
| Default emulation mode | P1 | 6 : PCL6 (except PCL XL) 9 : KPDL | 6 9(120 V model) |
| Carriage-return action | P2 | 0: Ignores 0x0d 1: CR 2: CR+LF | 1 |

| Items | FRPO | Setting value | Factory setting |
|---|------|--|-----------------------|
| Linefeed action | P3 | 0: Ignores 0x0d 1: LF 2: CR+LF | 1 |
| KPDL auto switching | P4 | 0: None 1: Auto switching | 0 1(120 V model) |
| KPDL auto switching alternate emulation | P5 | Same as P1 (except 9) | 6 |
| AES option Page eject command and action when automatic emulation switching (AES) is triggered | P7 | If the data is neither applicable to KPDL nor alternate emulation after the AES is started, it is processed in the alternate emulation . 0: All page eject commands 1: None 2: All page eject commands and Prescribe EXIT command 3: Prescribe EXIT command only 4: ^L command only 6: Prescribe EXIT command and ^L command If the data is neither applicable to KPDL nor alternate emulation after the AES is started, it is processed in KPDL. 10: Data other than KPDL print data is printed in the alternate emulation. | 10 11(120 V model) |
| Command recognition character | P9 | ASCII code of 33 to 126 | 82(R) |
| Stacker setting at start-up | R0 | 1: Inner tray 3: When the 1000-sheet finisher is installed 7: When the 3000-sheet finisher is installed | 1 |

| Items | FRPO | Setting value | Factory setting |
|---|------|---|---------------------|
| Paper size(start-up) | R2 | 0: Size of the default paper cassette (See R4.) 1: Envelope Monarch 2: Envelope #10 3: Envelope DL 4: Envelope C5 5: Executive 6: Letter 7: Legal 8: ISO A4 9: JIS B5 13: ISO A5 14: ISO A6 15: JIS B6 16: Envelope #9 17: Envelope #6-3/4 18: ISO B5 19: Custom 20: B4toA4(100 V model only) 21: A3toA4(100 V model only) 22: A4toA4[98%](100 V model only) 23: STKtoA4(100 V model only) 31: Hagaki 32: Oufuku Hagaki 33: Oficio II 40: 16K 42: 8.5x13.5 50: Statement 51: Folio 52: Youkei type 2 53: Youkei type 4 | 0 |
| Default paper source | R4 | 0: MP paper feed section 1: Cassette 1 2: Cassette 2 3: Cassette 3 4: Cassette 4 | 1 |
| Sort pin full detection | S3 | 0: Stop at paper full detection 1: Output tray change at paper full detection | 0 |
| A4/Letter override | S4 | 0: OFF 1: ON | 1 0(100 V model) |
| Host buffer size rate (H8 value and integration) | S5 | 0: 10KB 1: 100KB 2: 1MB | 1 |
| RAM disk size | S6 | 1 to 1024 MB | 400 |

| Items | FRPO | Setting value | Factory setting |
|------------------------------------|------|---|----------------------|
| RAM disk mode | S7 | 0: OFF 1: ON | 1 |
| Wide A4 | T6 | 0: OFF 1: ON | 0 |
| Line spacing | U0 | Lines per inch (integer value) | 6 |
| | U1 | Lines per inch (fraction value) | 0 |
| Character spacing | U2 | Characters per inch (integer value) | 10 |
| | U3 | Characters per inch (fraction value) | 0 |
| Country code of the resident fonts | U6 | 0: US 1: France 2: Germany 3: U.K. 4: Denmark 5: Sweden 6: Italy 7: Spain 8: Japan 9: US legal 10: IBM PC-850 (Multi-lingual) 11: IBM PC-860 (Portuguese) 12: IBM PC-863 (Canadian French) 13: IBM PC-865 (Norwegian) 14: Norway 15: Denmark 2 16: Spain 2 17: Latin America | 41 0(100 V model) |
| Supported symbol sets | U7 | 0: Same as the default emulation mode (P1) 1: IBM 6: PCL | 53 0(100 V model) |
| Default font pitch* | U8 | Default font pitch/integer | 10 |
| | U9 | Default font pitch/decimal | 0 |
| ANK outline font size at start-up* | V0 | Integer value of ANK outline font size at power-up Upper 2-digit/valid value: 00 to 09 | 0 |
| | V1 | Integer value of ANK outline font size at power-up Lower 2-digit/valid value: 00 to 99 | 12 |
| | V2 | Decimal value of ANK outline font size at power-up Valid value: 00, 25, 50, 75 | 0 |

| Items | FRPO | Setting value | Factory setting |
|---|------|--|-----------------|
| ANK outline font size at start-up* | V3 | ANK outline font name at power-up | Courier |
| Initial Kanji outline font side at start-up (100 V model only)* | V4 | Upper 2-digit integer value of Kanji outline font size at start-up Valid value range: 00 to 09 | 0 |
| | V5 | 2-digit integer value of the Kanji outline font size at start-up Valid value range: 00 to 99 | 10 |
| | V6 | 2-digit decimal value of the Kanji outline font size at start-up Valid value: 00, 25, 50, 75 | 0 |
| Initial Kanji outline font name (100 V model only)* | V7 | Kanji outline font name at start-up | MTHSMIN-CHO-W3 |
| Default weight(courier and letter Gothic) | V9 | 0: Courier = darkness Letter Gothic = darkness 1: Courier = regular Letter Gothic = darkness 4: Courier = darkness Letter Gothic = regular 5: Courier = regular Letter Gothic = regular | 5 |
| Color mode | W1 | 0: BW 1: Color (CMYK color) | 1 |
| Gloss mode | W6 | 0: OFF 1: ON | 0 |






| Items | FRPO | Setting value | Factory setting |
|--|----------------|---|-----------------|
| Paper type for the MP tray | X0 | 1: Plain 2: Transparency 3: Preprinted 4: Labels 5: Bond 6: Recycled 7: Vellum 8: Rough (except 100 V model) 9: Letterhead 10: Color 11: Prepunched 12: Envelope 13: Hagaki 14: Coated 16: Thick 17: High quality 21 to 28 : Custom 1 to Custom 8 | 1 |
| Paper type (Paper cassettes 1) | X1 | 1: Plain 3: Preprinted 5: Bond 6: Recycled 7: Vellum 8: Rough (except 100 V model) 9: Letterhead 10: Color 11: Prepunched 12: Envelope 16: Thick 17: High quality 21 to 28 : Custom 1 to Custom 8 | 1 |
| Paper type (Option paper cassette 2 to 4) | X2 X3 X4 | 1: Plain 3: Preprinted 5: Bond 6: Recycled 9: Letterhead 10: Color 11: Prepunched 17: High quality 21 to 28 : Custom 1 to Custom 8 | 1 |
| Cassette selection mode (PCL) | X1 | 0: Paper selection depending on an escape sequence compatible with HP-LJ5Si 2: Paper selection depending on an escape sequence compatible with HP-LJ8000 | 0 |
| Auto error clear at an error | Y0 | 0: OFF 1: ON | 0 |
| Auto error clear timeout time | Y1 | Value in units of 5 seconds (0 to 99). | 6 |






| Items | FRPO | Setting value | Factory setting |
|---|------|---|-----------------|
| Paper error detection at duplex printing Paper size and type error detection at fixed paper source | Y3 | 0: Not detected 1: Detected | 63 |
| Forced duplex printing setting (Media type is Preprinted, Pre-punched and Letterhead only) | Y4 | 0: OFF 1: ON | 0 |
| PDF direct printing | Y5 | 0: Zoom depending on paper size 1: Loads paper which is the same size as the image 2: Loads Letter, A4 size paper depending on the image size Enlarges or reduces the image to fit in the current paper size 3: Loads Letter, A4 size paper depending on the image size 8: Printed in full magnification 9: Loads Letter, A4 size paper depending on the image size 10: Loads Letter, A4 size paper depending on the image size Enlarges or reduces the image to fit in the current paper size 13 to 99: Same action as default value(0) | 0 |
| Job box error control | Y6 | 0: No error control 1: Output the error list 2: Displays the error 3: Displays the error and prints the error report | 3 |


*: Ignored depending on emulation

This page is intentionally left blank.

(3) Chart of image adjustment procedures

| Adjusting order | Item | Image | Maintenance mode | | Page | Setting procedure | | Remarks |
|-----------------|--|---|------------------|------------------|--|--|---|--|
| | | | Item No. | Mode | | Method | Setting | |
| 1 | Adjusting the center line of the MP tray (printing adjustment) Adjusting the LSU print start timing |  | U034 | LSU Out Left | P.6-31 30 ppm model P.6-228 35/40 ppm models | <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Lsu Out Left]. 3. Press the system menu key. 4. Press the start key. (output a test pattern) 5. Press the system menu key. 6. Select [MPT]. | <ol style="list-style-type: none"> 1. By using the [Left/Right] cursor, [+/-] cursor, or the numeric keys, change the setting value. 2. Press the start key to set the setting value. Completion: Press the stop key. | When the setting value is increased, the image moves leftward. *Adjustment selects [Duplex] at the time of duplex mode. |
| 2 | Adjusting the center line of the cassettes (printing adjustment) Adjusting the LSU print start timing |  | U034 | LSU Out Left | P.6-31 30 ppm model P.6-228 35/40 ppm models | <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Lsu Out Left]. 3. Press the system menu key. 4. Press the start key. (output a test pattern) 5. Press the system menu key. 6. Select?[Cass1] to [Cass4]. | <ol style="list-style-type: none"> 1. By using the [Left/Right] cursor, [+/-] cursor, or the numeric keys, change the setting value. 2. Press the start key to set the setting value. Completion: Press the stop key. | When the setting value is increased, the image moves leftward. *Adjustment selects [Duplex] at the time of duplex mode. |
| 3 | Adjusting the leading edge registration of the MP tray (printing adjustment) Changes the secondary feed timing. |  | U034 | LSU Out Top Full | P.6-31 30 ppm model P.6-228 35/40 ppm models | <ol style="list-style-type: none"> 1. Press the start key. 2. Select [LSU Out Top Full]. 3. Press the system menu key. 4. Press the start key. (output a test pattern) 5. Press the system menu key. 6. Select [MPT]. | <ol style="list-style-type: none"> 1. By using the [Left/Right] cursor, [+/-] cursor, or the numeric keys, change the setting value. 2. Press the start key to set the setting value. Completion: Press the stop key. | When the setting value is increased, the image moves downward. *Adjustment selects [Duplex] at the time of duplex mode. |
| 4 | Adjusting the leading edge registration of the cassette (printing adjustment) Changes the secondary feed timing. |  | U034 | LSU Out Top Full | P.6-31 30 ppm model P.6-228 35/40 ppm models | <ol style="list-style-type: none"> 1. Press the start key. 2. Select [LSU Out Top Full]. 3. Press the system menu key. 4. Press the start key. (output a test pattern) 5. Press the system menu key. 6. Select [Cass]. | <ol style="list-style-type: none"> 1. By using the [Left/Right] cursor, [+/-] cursor, or the numeric keys, change the setting value. 2. Press the start key to set the setting value. Completion: Press the stop key. | When the setting value is increased, the image moves downward. *Adjustment selects [Duplex] at the time of duplex mode. |
| 5 | Adjusting the leading edge margin (printing adjustment) Changes the LSU illumination start timing. |  | U402 | Lead | P.6-111 30 ppm model P.6-334 35/40 ppm models | <ol style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Press the start key. (output a test pattern) 4. Press the system menu key. 5. Select [Lead]. | <ol style="list-style-type: none"> 1. By using the [Left/Right] cursor, [+/-] cursor, or the numeric keys, change the setting value. 2. Press the start key to set the setting value. Completion: Press the stop key. | When the setting value is increased, the margin widens. |

| Adjusting order | Item | Image | Maintenance mode | | Page | Setting procedure | | Remarks | |
|-----------------|--|---|------------------|---|--|--------------------------|--|---|---|
| | | | Item No. | Mode | | Method | Setting | | |
| 6 | Adjusting the trailing edge margin (printing adjustment) Changes the LSU illumination end timing. |  | U402 | Trail | P.6-111 30 ppm model P.6-334 35/40 ppm models | (Original: test pattern) | 1. Press the start key. 2. Press the system menu key. 3. Press the start key. (output a test pattern) 4. Press the system menu key. 5. Select [Trail]. | 1. By using the [Left/Right] cursor , [+/-] cursor, or the numeric keys, change the setting value. 2. Press the start key to set the setting value. Completion: Press the stop key. | When the setting value is increased, the margin widens. |
| 7 | Adjusting the left and right margins (printing adjustment) Changes the LSU illumination start/end timing. |  | U402 | A Margin C Margin | P.6-111 30 ppm model P.6-334 35/40 ppm models | (Original: test pattern) | 1. Press the start key. 2. Press the system menu key. 3. Press the start key. (output a test pattern) 4. Press the system menu key. 5. Select [A Margin] or [C Margin]. | 1. By using the [Left/Right] cursor , [+/-] cursor, or the numeric keys, change the setting value. 2. Press the start key to set the setting value. Completion: Press the stop key. | When the setting value is increased, the margin widens. |
| 8 | Adjusting magnification of the scanner in the main scanning direction Processes data. |  | U065 | Main Scan | P.6-39 30 ppm model P.6-238 35/40 ppm models | (Original: test copy) | 1. Press the start key. 2. Press the system menu key. 3. Place an original and press the start key to make a test copy. (Test copy output) 4. Press the system menu key. 5. Select [Main Scan]. | 1. By using the [Left/Right] cursor , [+/-] cursor, or the numeric keys, change the setting value. 2. Press the start key to set the setting value. Completion: Press the stop key. | U065: When using on the contact glass When the setting value is increased, the image widens. |
| 9 | Adjusting magnification of the scanner in the sub scanning direction (scanning adjustment) Changes the original scanning speed. |  | U065 U070 | Sub Scan Sub Scan(F) Sub Scan(B) Sub Scan(CIS) | P.6-39 P.6-44 30 ppm model P.6-238 P.6-243 35/40 ppm models | (Original: test copy) | 1. Press the start key. 2. Press the system menu key. 3. Place an original and press the start key to make a test copy. (Test copy output) 4. Press the system menu key. 5. Select the item to be adjusted. U065: [Sub Scan] or [Rotate] U070: [Sub Scan(F)], [Sub Scan(B)] or [Sub Scan(CIS)] | 1. By using the [Left/Right] cursor , [+/-] cursor, or the numeric keys, change the setting value. 2. Press the start key to set the setting value. Completion: Press the stop key. | U065: When using on the contact glass When the setting value is increased, the image widens. U070: When using document processor When the setting value is increased, the image get longer. |
| 10 | Adjusting the center line (scanning adjustment) Scan data is processed. |  | U067 U072 | Front Rotate Front Back CIS | P.6-42 P.6-47 30 ppm model P.6-241 P.6-246 35/40 ppm models | (Original: test copy) | 1. Press the start key. 2. Press the system menu key. 3. Place an original and press the start key to make a test copy. (Test copy output) 4. Press the system menu key. 5. Select the item to be adjusted. U067: [Front] or [Rotate] U072: [Front], [Back] or [CIS] | 1. By using the [Left/Right] cursor , [+/-] cursor, or the numeric keys, change the setting value. 2. Press the start key to set the setting value. Completion: Press the stop key. | U067: When using on the contact glass Adjustment at the time of rotate copy, select [Rotate]. When the setting value is increased, the image moves leftward. U072: When copying from the document processor Back adjustment selects [Back] at the time of duplex mode. When the setting value is increased, the image moves rightward. |

| Adjusting order | Item | Image | Maintenance mode | | Page | Setting procedure | | Remarks |
|-----------------|--|---|---|--|--|---|--|--|
| | | | Item No. | Mode | | Method | Setting | |
| 11 | Adjusting the leading edge registration (scanning adjustment) Changes the original scan start timing. |  | U066 U071 (Original: test copy) | Front Rotate Front Head Back Head | P.6-41 P.6-45 30 ppm model P.6-240 P.6-244 35/40 ppm models | 1. Press the start key. 2. Press the system menu key. 3. Place an original and press the start key to make a test copy. (Test copy output) 4. Press the system menu key. 5. Select the item to be adjusted. U067: [Front] or [Rotate] U071: [Front Head] or [Back Head] | 1. By using the [Left/Right] cursor, [+/-] cursor, or the numeric keys, change the setting value. 2. Press the start key to set the setting value. Completion: Press the stop key. | U066: When using on the contact glass Adjustment at the time of rotate copy, select [Rotate]. When the setting value is increased, the image moves forward. U071: When using document processor Back adjustment selects [Back Head] at the time of duplex mode. When the setting value is increased, the image moves forward. |


When maintenance item U411 (Automatic adjustment in the scanner) is run using the specified original (P/N 7505000107), the following adjustments are automatically made:

- Scanner magnification adjustment in the sub scanning direction (U065)
- Adjusts the scanner leading edge registration (U066)
- Adjusting the scanner center line (U067)
- Chromatic aberration in the main scanning direction
- Chromatic aberration in the sub scanning direction
- MTF correction
- Input gamma in color mode
- Color correction matrix
- Input gamma in monochrome mode

When maintenance item U411 (Automatic adjustment in the scanner) is run using the specified original (P/N 7505000106), the following adjustments are automatically made:

*:When running this test chart, you first must clean the feed rollers with alcohol and ensure the DP width guides are correctly positioned against the original.

*:Cut the trailing edge of the DP adjustment original (ChartB) as follows.




- Adjusting the DP magnification (U070)
- Adjusting the DP leading edge registration (U071)
- Adjusting the DP center line (U072)

Image quality


| Items | Specifications |
|---|---|
| 100% magnification | Printer: ±0.8% Copy: ±1.5% Using DP: ±2.0% |
| Magnificaiton | Copy: ±2.0% Using DP: ±2.5% |
| Lateral squareness | Copy: ±2.0mm/200mm Using DP: ±2.5mm/200mm |
| Leading edge timing | Print: 2.0 mm or less Copy: 2.0mm or less Using DP: 2.5mm or less |
| Skewed paper feed (left-right difference) | Print: 1.0mm /100mm or less Copy: 1.0mm /100mm or less(table) Using DP: 1.5mm /100mm or less |
| Lateral image shifting | Print: ±2.0 mm or less(cassette) ±3.0mm or less(MP tray) Copy: ±2.0mm or less(cassette) ±3.0mm or less(MP tray) Using DP: ±2.0mm or less(cassette) ±3.0mm or less(MP tray) |


(4) Wiring diagram (30 ppm model)

No.1




No.2







No.4




No.5




No.6



No.7




No.8




(5) Wiring diagram (35/40 ppm models)


No.1




No.2




No.3







No.5



No.6







OPERATION PANEL UNIT

(6) Wiring diagram (Options)


(6-1) Paper feeder (PF-5120) wiring diagram




(6-2)Paper feeder (PF-5130) wiring diagram




(6-3)Paper feeder (PF-5140) wiring diagram




(6-4) Document processor (DP-5100) wiring diagram: 35/40ppm models only




(6-5)Document processor (DP-5110) wiring diagram: 35/40ppm models only




(6-6) Finisher (DF-5100) wiring diagram




(6-7)Finisher (DF-5110) wiring diagram: 35/40ppm models only




(6-8)Finisher (DF-5120) wiring diagram: 35/40ppm models only



(6-9)Mailbox (MT-5100) wiring diagram



(6-10)Punch unit (PH-5100/5110) wiring diagram



PF-5120

(500 sheets × 1 Paper Feeder)

Installation Guide

INSTALLATION GUIDE

GUIDE D'INSTALLATION

GUÍA DE INSTALACION

INSTALLATIONSANLEITUNG


GUIDA ALL'INSTALLAZIONE


安装手册

설치안내서


設置手順書

PF-5120







①




②




③




④








⑤



⑥







English

Adjusting the leading edge timing

1. Check the gap between the paper center (1) and the line (2) of test pattern (a). If the gap exceeds the reference value, adjust the gap according to the following procedure.
<Reference value> -0mm to +1.0mm
2. Set the maintenance mode U034 and select [LSU Out Top Full] > [PF].

Français

Réglage de la synchronisation du bord de tête

1. Vérifier l'espace entre le centre du papier (1) et la ligne (2) du motif de (a). Si l'écart excède la valeur de référence, le régler selon la procédure suivante.
<Valeur de référence> -0mm à +1,0mm
2. Passez en mode maintenance U034 et sélectionnez [LSU Out Top Full] > [PF].

Español

Cómo ajustar la sincronización del borde superior

1. Compruebe el espacio entre el centro del papel (1) y la línea (2) del patrón de prueba (a). Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.
<Valor de referencia> De -0mm a +1,0mm
2. Configure el modo de mantenimiento U034 y seleccione [LSU Out Top Full] > [PF].

Deutsch

Einstellen des Vorderkanten-Timing

1. Überprüfen Sie den Abstand zwischen der Papiermitte (1) und der Linie (2) auf der Testseite (a). Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.
<Bezugswert> -0 mm bis +1,0mm
2. Aktivieren Sie den Wartungsmodus U034 und wählen Sie [LSU Out Top Full] > [PF].

Italiano

Regolazione della sincronizzazione del bordo principale

1. Controllare lo spazio tra il centro del foglio (1) e la linea (2) dello schema di prova (a). Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.
<Valore di riferimento> da -0 mm a +1,0mm
2. Impostare la modalità manutenzione U034 e selezionare [LSU Out Top Full] > [PF].

简体中文

前端对位调节

1. 确认纸张的中心(1)和测试样张(a)的线(2)之间的偏移值。如果偏移值超过标准值,则按照下列步骤进行调整。
<标准值> -0mm ~ +1.0mm
2. 进入维修保养模式 U034, 把 [LSU Out Top Full] > [PF]。

한국어


선단 타이밍 조정

1. 용지 중앙 (1) 과 테스트 패턴 (a) 의 라인 (2) 사이의 격차를 확인하십시오 . 차이가 기준치 외의 경우 다음의 순서대로 조정을 합니다 .
< 기준치 > -0mm ~ +1.0mm
2. 메인テナンス 모드 U034 를 설정하고 [LSU Out Top Full] > [PF] 를 선택합니다 .

日本語

先端タイミング調整

1. 紙のセンター(1)とテストパターン(a)の線(2)のずれを確認する。ずれが基準値外の場合、次の手順で調整をおこなう。
<基準値> -0mm ~ +1.0mm
2. メンテナンスモード U034 をセットし、[LSU Out Top Full] > [PF] を選択する。



3. Adjust the values.

Test pattern (b) : Increase the setting value.

Test pattern (c) : Decrease the setting value.

Amount of change per step: 0.1mm

4. Press the [Start] key to confirm the setting value.

5. Print the test pattern.

6. Repeat the steps 2 to 5 above until the gap of line (2) in test pattern (a) is within the reference.

<Reference value> -0mm to +1.0mm

3. Régler les valeurs.

Mire d'essai (b) : Augmentez la valeur de réglage.

Mire d'essai (c) : Diminuez la valeur de réglage.

Changement par graduation d'échelle: 0,1mm

4. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.

5. Imprimez le motif de test.

6. Répéter les étapes 2 à 5 ci-dessus jusqu'à ce que l'espace de la ligne (2) dans le motif de test (a) soit dans la référence.

<Valeur de référence> -0mm à +1,0mm

3. Ajuste los valores.

Patrón de prueba (b) : Aumente el valor de configuración.

Patrón de prueba (c) : Reduzca el valor de configuración.

Magnitud del cambio por incremento: 0,1mm

4. Pulse la tecla de [Inicio] para confirmar el valor de configuración.

5. Imprima el patrón de prueba.

6. Repita los pasos del 2 al 5 anteriores hasta que el espacio de línea (2) del patrón de prueba (a) esté dentro de los valores de referencia.

<Valor de referencia> De -0mm a +1,0mm

3. Die Werte einstellen.

Testmuster (b) : Den Einstellwert erhöhen.

Testmuster (c) : Den Einstellwert verringern.

Änderung pro Schritt: 0,1mm

4. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.

5. Drucken Sie die Testseite aus.

6. Wiederholen Sie die Schritte 2 bis 5 solange, bis der Abstand der Linie (2) auf der Testseite (a) sich innerhalb der Referenz befindet.

<Bezugswert> -0 mm bis +1,0mm

3. Regolare i valori.

Modello di prova (b) : Aumentare il valore dell'impostazione.

Modello di prova (c) : Diminuire il valore dell'impostazione.

Entità modifica per passo: 0,1mm

4. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.

5. Stampare lo schema di prova.

6. Ripetere i punti da 2 a 5 sopra indicati fino a portare lo spazio della linea (2) nello schema di prova (a) all'interno del riferimento.

<Valore di riferimento> da -0 mm a +1,0 mm

3. 調整設定値。

测试图案 (b) : 调高设定值。

测试图案 (c) : 调低设定值。

设定值的一个调整单位变化量: 0.1mm

4. 按 [开始] 键, 以确定设定值。

5. 打印测试图案。

6. 重复步骤 2 ~ 5, 直至测试样张 (a) 的线 (2) 的偏移值达到标准值以内。

<标准值> -0mm ~ +1.0mm

3. 설정치를 조정합니다 .

테스트 패턴 (b) : 설정치를 높입니다 .

테스트 패턴 (c) : 설정치를 내립니다 .

1 스텝당 변화량:0.1mm

4. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .

5. 시험 패턴을 인쇄합니다 .

6. 테스트 패턴 (a) 에서 라인 (2) 의 격차가 기준 이내가 될 때까지 2 단계 ~ 5 단계를 반복 수행합니다 .

<기준치> -0mm ~ +1.0mm

3. 設定値を調整する。

テストパターン (b) : 設定値を上げる。

テストパターン (c) : 設定値を下げる。


1 ステップ当たりの変化量:0.1mm

4. [スタート] キーを押し、設定値を確定する。

5. テストパターンを出力する。

6. テストパターン (a) の線 (2) のずれが基準値内になるまで手順 2 ~ 5 を繰り返す。

<基準値> -0mm ~ +1.0mm



Adjusting the center line

1. Check the gap between the paper center (3) and the line (4) of test pattern (c). If the gap exceeds the reference value, adjust the gap according to the following procedure.
<Reference value> within ± 2.0 mm.
2. Set the maintenance mode U034 and select [LSU Out Left] > [Cass2]/[Cassette2] or [Cass3]/[Cassette3].
([Cass*] : Display for 30 ppm model, [Cassette*] : Display for 35 and 40 ppm model)

Réglage de l'axe

1. Vérifier l'espace entre le centre du papier (3) et la ligne (4) du motif de (c). Si l'écart excède la valeur de référence, le régler selon la procédure suivante.
<Valeur de référence> $\pm 2,0$ mm max.
2. Passez en mode maintenance U034 et sélectionnez [LSU Out Left] > [Cass2]/[Cassette2] ou [Cass3]/[Cassette3].
([Cass*] : Affichage pour le modèle 30 ppm, [Cassette*] : Affichage pour les modèles 35 et 40 ppm)

Ajuste de la línea central

1. Compruebe el espacio entre el centro del papel (3) y la línea (4) del patrón de prueba (c). Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.
<Valor de referencia> Dentro de $\pm 2,0$ mm.
2. Configure el modo de mantenimiento U034 y seleccione [LSU Out Left] > [Cass2]/[Cassette2] o [Cass3]/[Cassette3].
([Cass*] : Opción mostrada para el modelo de 30 ppm, [Cassette*] : Opción mostrada para los modelos de 35 y 40 ppm)

Einstellen der Mittelinie

1. Überprüfen Sie den Abstand zwischen der Papiermitte (3) und der Linie (4) auf der Testseite (c). Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.
<Bezugswert> Innerhalb $\pm 2,0$ mm.
2. Aktivieren Sie den Wartungsmodus U034 und wählen Sie [LSU Out Left] > [Cass2]/[Cassette2] oder [Cass3]/[Cassette3].
([Cass*] : Anzeige für das 30-Seiten-Modell, [Cassette*] : Anzeige für das 35- und 40-Seiten-Modell)

Regolazione della linea centrale

1. Controllare lo spazio tra il centro del foglio (3) e la linea (4) dello schema di prova (c). Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.
<Valore di riferimento> Entro $\pm 2,0$ mm.
2. Impostare la modalità manutenzione U034 e selezionare [LSU Out Left] > [Cass2]/[Cassette2] o [Cass3]/[Cassette3].
([Cass*] : Visualizzazione per modello da 30 ppm, [Cassette*] : Visualizzazione per modelli da 35 e 40 ppm)

中心线调节


1. 确认纸张的中心(3)和测试样张(c)的线(4)之间的偏移值。如果偏移值超过标准值,则按照下列步骤进行调整。
<标准值> ± 2.0 mm 以内
2. 进入维修保养模式 U034,把 [LSU Out Left] > [Cass2]/[Cassette2] 或 [Cass3]/[Cassette3]。
([Cass*]: 在 30 张机器上的显示, [Cassette*]: 在 35 张机器/40 张机器上的显示)

센터라인 조정

1. 용지 중앙(3)과 테스트 패턴(c)의 라인(4) 사이의 격차를 확인하십시오. 차이가 기준치 외의 경우 다음의 순서대로 조정을 합니다.
<기준치> ± 2.0 mm 이내
2. 메인テナンス 모드 U034 를 설정하고 [LSU Out Left] > [Cass2]/[Cassette2] 또는 [Cass3]/[Cassette3] 을 선택합니다.
([Cass*] : 30ppm 모델용 디스플레이, [Cassette*] : 35ppm 및 40ppm 모델용 디스플레이)

センターライン調整

1. 紙のセンター(3)とテストパターン(d)の線(4)のずれを確認する。ずれが基準値外の場合、次の手順で調整をおこなう。
<基準値> ± 2.0 mm 以内
2. メンテナンスモード U034 をセットし、[LSU Out Left] > [Cass2]/[Cassette2] または [Cass3]/[Cassette3] を選択する。
([Cass※]: 30 枚機での表示, [Cassette※]: 35 枚機/40 枚機での表示)



3. Adjust the values.

Test pattern (e) : Increase the setting value.

Test pattern (f) : Decrease the setting value.

Amount of change per step: 0.1mm

4. Press the [Start] key to confirm the setting value.

5. Print the test pattern.

6. Repeat the steps 2 to 5 above until the gap of line (4) in test pattern (c) is within the reference.

<Reference value> within ± 2.0 mm.

3. Régler les valeurs.

Mire d'essai (e) : Augmentez la valeur de réglage.

Mire d'essai (f) : Diminuez la valeur de réglage.

Changement par graduation d'échelle: 0,1mm

4. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.

5. Imprimez le motif de test.

6. Répéter les étapes 2 à 5 ci-dessus jusqu'à ce que l'espace de la ligne (4) dans le motif de test (c) soit dans la référence.

<Valeur de référence> $\pm 2,0$ mm max.

3. Ajuste los valores.

Patrón de prueba (e) : Aumente el valor de configuración.

Patrón de prueba (f) : Reduzca el valor de configuración.

Magnitud del cambio por incremento: 0,1mm

4. Pulse la tecla de [Inicio] para confirmar el valor de configuración.

5. Imprima el patrón de prueba.

6. Repita los pasos del 2 al 5 anteriores hasta que el espacio de línea (4) del patrón de prueba (c) esté dentro de los valores de referencia.

<Valor de referencia> dentro de $\pm 2,0$ mm.

3. Die Werte einstellen.

Testmuster (e) : Den Einstellwert erhöhen.

Testmuster (f) : Den Einstellwert verringern.

Änderung pro Schritt: 0,1mm

4. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.

5. Drucken Sie die Testseite aus.

6. Wiederholen Sie die Schritte 2 bis 5 solange, bis der Abstand der Linie (4) auf der Testseite (c) sich innerhalb der Referenz befindet.

<Bezugswert> Innerhalb $\pm 2,0$ mm.

3. Regolare i valori.

Modello di prova (e) : Aumentare il valore dell'impostazione.

Modello di prova (f) : Diminuire il valore dell'impostazione.

Entità modifica per passo: 0,1mm

4. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.

5. Stampare lo schema di prova.

6. Ripetere i punti da 2 a 5 sopra indicati fino a portare lo spazio della linea (4) nello schema di prova (c) all'interno del riferimento.

<Valore di riferimento> entro $\pm 2,0$ mm

3. 調整設定値。

测试图案 (e) : 调高设定值。

测试图案 (f) : 调低设定值。

设定值的一个调整单位变化量 : 0.1mm

4. 按 [开始] 键, 以确定设定值。

5. 打印测试图案。

6. 重复步骤 2 ~ 5, 直至测试样张 (c) 的线 (4) 的偏移值达到标准值以内。

<标准值> ± 2.0 mm 以内

3. 설정치를 조정합니다 .

테스트 패턴 (e) : 설정치를 높입니다 .

테스트 패턴 (f) : 설정치를 내립니다 .

1 스텝당 변화량 : 0.1mm

4. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .

5. 시험 패턴을 인쇄합니다 .

6. 테스트 패턴 (c) 에서 라인 (4) 의 격차가 기준 이내가 될 때까지 2 단계 ~ 5 단계를 반복 수행합니다 .

<기준치> ± 2.0 mm 이내

3. 設定値を調整する。

テストパターン (e) : 設定値を上げる。

テストパターン (f) : 設定値を下げる。

1 ステップ当たりの変化量 : 0.1mm

4. [スタート] キーを押し、設定値を確定する。

5. テストパターンを出力する。

6. テストパターン (d) の線 (4) のずれが基準値内になるまで手順 2 ~ 5 を繰り返す。

<基準値> ± 2.0 mm 以内

PF-5130

(500 sheets × 2 Paper Feeder)

Installation Guide

INSTALLATION GUIDE

GUIDE D'INSTALLATION

GUÍA DE INSTALACION

INSTALLATIONSANLEITUNG


GUIDA ALL'INSTALLAZIONE


安装手册

설치안내서


設置手順書

PF-5130







1




2




3











4




5






14




15





- ENG Select holes (1) and install each stopper (E,F) with 2 S Tite screws M4 x 20 (D) so that the stoppers will be grounded on the floor.
- FR Sélectionner les trous (1) et installer chaque butée (E,F) avec 2 vis S Tite M4 x 20 (D) de sorte que les butées reposent sur le sol.
- ES Seleccione los orificios (1) e instale cada tope (E,F) con los 2 tornillos S Tite M4 x 20 (D) de manera que los topes se conecten a tierra en el suelo.
- DE Wählen Sie die Öffnungen (1) und befestigen Sie jeden Anschlag (E,F) mit den 2 S-Tite-Schrauben M4 x 20 (D) so an, dass die Anschläge am Boden aufsitzen.
- IT Selezionare i fori (1) ed installare ogni fermo (E,F) con le 2 viti S Tite M4 x 20 (D) in modo che i fermi siano posti a terra sul pavimento.
- CN 在孔 (1) 处各用 2 颗 M4×20 紧固型 S 螺丝 (D) 安装限位器 (E,F) , 使之和地板接触。
- KO 전도방지쇠 (E,F) 가 바닥면에 접지될 수 있도록 구멍 (1) 을 선택해 나사 M4×20 S 타이트 (D) 각 2 개로 설치합니다 .
- JP 転倒防止金具(E,F)が床面に接地するように、穴(1)を選択してビスM4×20 Sタイト(D)各2本で取り付けます。

16



17





English

Adjusting the leading edge timing

1. Check the gap between the paper center (1) and the line (2) of test pattern (a). If the gap exceeds the reference value, adjust the gap according to the following procedure.
<Reference value> -0mm to +1.0mm
2. Set the maintenance mode U034 and select [LSU Out Top Full] > [PF].

Français

Réglage de la synchronisation du bord de tête

1. Vérifier l'espace entre le centre du papier (1) et la ligne (2) du motif de (a). Si l'écart excède la valeur de référence, le régler selon la procédure suivante.
<Valeur de référence> -0mm à +1,0mm
2. Passez en mode maintenance U034 et sélectionnez [LSU Out Top Full] > [PF].

Español

Cómo ajustar la sincronización del borde superior

1. Compruebe el espacio entre el centro del papel (1) y la línea (2) del patrón de prueba (a). Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.
<Valor de referencia> De -0mm a +1,0mm
2. Configure el modo de mantenimiento U034 y seleccione [LSU Out Top Full] > [PF].

Deutsch

Einstellen des Vorderkanten-Timing

1. Überprüfen Sie den Abstand zwischen der Papiermitte (1) und der Linie (2) auf der Testseite (a). Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.
<Bezugswert> -0 mm bis +1,0mm
2. Aktivieren Sie den Wartungsmodus U034 und wählen Sie [LSU Out Top Full] > [PF].

Italiano

Regolazione della sincronizzazione del bordo principale

1. Controllare lo spazio tra il centro del foglio (1) e la linea (2) dello schema di prova (a). Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.
<Valore di riferimento> da -0 mm a +1,0mm
2. Impostare la modalità manutenzione U034 e selezionare [LSU Out Top Full] > [PF].

简体中文

前端对位调节

1. 确认纸张的中心(1)和测试样张(a)的线(2)之间的偏移值。如果偏移值超过标准值,则按照下列步骤进行调整。
<标准值> -0mm ~ +1.0mm
2. 进入维修保养模式 U034,把 [LSU Out Top Full] > [PF]。

한국어


선단 타이밍 조정

1. 용지 중앙 (1) 과 테스트 패턴 (a) 의 라인 (2) 사이의 격차를 확인하십시오 . 차이가 기준치 외의 경우 다음의 순서대로 조정을 합니다 .
< 기준치 > -0mm ~ +1.0mm
2. 메인テナンス 모드 U034 를 설정하고 [LSU Out Top Full] > [PF] 를 선택합니다 .

日本語

先端タイミング調整

1. 紙のセンター(1)とテストパターン(a)の線(2)のずれを確認する。ずれが基準値外の場合、次の手順で調整をおこなう。
<基準値> -0mm ~ +1.0mm
2. メンテナンスモード U034 をセットし、[LSU Out Top Full] > [PF] を選択する。



3. Adjust the values.

Test pattern (b) : Increase the setting value.

Test pattern (c) : Decrease the setting value.

Amount of change per step: 0.1mm

4. Press the [Start] key to confirm the setting value.

5. Print the test pattern.

6. Repeat the steps 2 to 5 above until the gap of line (2) in test pattern (a) is within the reference.

<Reference value> -0mm to +1.0mm

3. Régler les valeurs.

Mire d'essai (b) : Augmentez la valeur de réglage.

Mire d'essai (c) : Diminuez la valeur de réglage.

Changement par graduation d'échelle: 0,1mm

4. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.

5. Imprimez le motif de test.

6. Répéter les étapes 2 à 5 ci-dessus jusqu'à ce que l'espace de la ligne (2) dans le motif de test (a) soit dans la référence.

<Valeur de référence> -0mm à +1,0mm

3. Ajuste los valores.

Patrón de prueba (b) : Aumente el valor de configuración.

Patrón de prueba (c) : Reduzca el valor de configuración.

Magnitud del cambio por incremento: 0,1mm

4. Pulse la tecla de [Inicio] para confirmar el valor de configuración.

5. Imprima el patrón de prueba.

6. Repita los pasos del 2 al 5 anteriores hasta que el espacio de línea (2) del patrón de prueba (a) esté dentro de los valores de referencia.

<Valor de referencia> De -0mm a +1,0mm

3. Die Werte einstellen.

Testmuster (b) : Den Einstellwert erhöhen.

Testmuster (c) : Den Einstellwert verringern.

Änderung pro Schritt: 0,1mm

4. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.

5. Drucken Sie die Testseite aus.

6. Wiederholen Sie die Schritte 2 bis 5 solange, bis der Abstand der Linie (2) auf der Testseite (a) sich innerhalb der Referenz befindet.

<Bezugswert> -0 mm bis +1,0mm

3. Regolare i valori.

Modello di prova (b) : Aumentare il valore dell'impostazione.

Modello di prova (c) : Diminuire il valore dell'impostazione.

Entità modifica per passo: 0,1mm

4. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.

5. Stampare lo schema di prova.

6. Ripetere i punti da 2 a 5 sopra indicati fino a portare lo spazio della linea (2) nello schema di prova (a) all'interno del riferimento.

<Valore di riferimento> da -0 mm a +1,0mm

3. 調整設定値。

测试图案 (b) : 调高设定值。

测试图案 (c) : 调低设定值。

设定值的一个调整单位变化量: 0.1mm

4. 按 [开始] 键, 以确定设定值。

5. 打印测试图案。

6. 重复步骤 2 ~ 5, 直至测试样张 (a) 的线 (2) 的偏移值达到标准值以内。

<标准值> -0mm ~ +1.0mm

3. 설정치를 조정합니다 .

테스트 패턴 (b) : 설정치를 높입니다 .

테스트 패턴 (c) : 설정치를 내립니다 .

1 스텝당 변화량:0.1mm

4. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .

5. 시험 패턴을 인쇄합니다 .

6. 테스트 패턴 (a) 에서 라인 (2) 의 격차가 기준 이내가 될 때까지 2 단계 ~ 5 단계를 반복 수행합니다 .

<기준치> -0mm ~ +1.0mm

3. 設定値を調整する。

テストパターン (b) : 設定値を上げる。

テストパターン (c) : 設定値を下げる。


1 ステップ当たりの変化量:0.1mm

4. [スタート] キーを押し、設定値を確定する。

5. テストパターンを出力する。

6. テストパターン (a) の線 (2) のずれが基準値内になるまで手順 2 ~ 5 を繰り返す。

<基準値> -0mm ~ +1.0mm



Adjusting the center line

1. Check the gap between the paper center (3) and the line (4) of test pattern (c). If the gap exceeds the reference value, adjust the gap according to the following procedure.
<Reference value> within $\pm 2,0\text{mm}$.
2. Set the maintenance mode U034 and select [LSU Out Left] > [Cass2]/[Cassette2] or [Cass3]/[Cassette3].
([Cass*] : Display for 30 ppm model, [Cassette*] : Display for 35 and 40 ppm model)

Réglage de l'axe

1. Vérifier l'espace entre le centre du papier (3) et la ligne (4) du motif de (c). Si l'écart excède la valeur de référence, le régler selon la procédure suivante.
<Valeur de référence> $\pm 2,0\text{mm}$ max.
2. Passez en mode maintenance U034 et sélectionnez [LSU Out Left] > [Cass2]/[Cassette2] ou [Cass3]/[Cassette3].
([Cass*] : Affichage pour le modèle 30 ppm, [Cassette*] : Affichage pour les modèles 35 et 40 ppm)

Ajuste de la línea central

1. Compruebe el espacio entre el centro del papel (3) y la línea (4) del patrón de prueba (c). Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.
<Valor de referencia> Dentro de $\pm 2,0\text{mm}$.
2. Configure el modo de mantenimiento U034 y seleccione [LSU Out Left] > [Cass2]/[Cassette2] o [Cass3]/[Cassette3].
([Cass*] : Opción mostrada para el modelo de 30 ppm, [Cassette*] : Opción mostrada para los modelos de 35 y 40 ppm)

Einstellen der Mittelinie

1. Überprüfen Sie den Abstand zwischen der Papiermitte (3) und der Linie (4) auf der Testseite (c). Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.
<Bezugswert> Innerhalb $\pm 2,0\text{mm}$.
2. Aktivieren Sie den Wartungsmodus U034 und wählen Sie [LSU Out Left] > [Cass2]/[Cassette2] oder [Cass3]/[Cassette3].
([Cass*] : Anzeige für das 30-Seiten-Modell, [Cassette*] : Anzeige für das 35- und 40-Seiten-Modell)

Regolazione della linea centrale

1. Controllare lo spazio tra il centro del foglio (3) e la linea (4) dello schema di prova (c). Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.
<Valore di riferimento> Entro $\pm 2,0\text{mm}$.
2. Impostare la modalità manutenzione U034 e selezionare [LSU Out Left] > [Cass2]/[Cassette2] o [Cass3]/[Cassette3].
([Cass*] : Visualizzazione per modello da 30 ppm, [Cassette*] : Visualizzazione per modelli da 35 e 40 ppm)

中心线调节


1. 确认纸张的中心 (3) 和测试样张 (c) 的线 (4) 之间的偏移值。如果偏移值超过标准值，则按照下列步骤进行调整。
<标准值> $\pm 2.0\text{mm}$ 以内
2. 进入维修保养模式 U034，把 [LSU Out Left] > [Cass2]/[Cassette2] 或 [Cass3]/[Cassette3]。
([Cass*] : 在 30 张机器上的显示, [Cassette*] : 在 35 张机器 / 40 张机器上的显示)

센터라인 조정

1. 용지 중앙 (3) 과 테스트 패턴 (c) 의 라인 (4) 사이의 격차를 확인하십시오 . 차이가 기준치 외의 경우 다음의 순서대로 조정을 합니다 .
<기준치> $\pm 2.0\text{mm}$ 이내
2. 메인テナンス 모드 U034 를 설정하고 [LSU Out Left] > [Cass2]/[Cassette2] 또는 [Cass3]/[Cassette3] 을 선택합니다 .
([Cass*] : 30ppm 모델용 디스플레이 , [Cassette*] : 35ppm 및 40ppm 모델용 디스플레이)

センターライン調整

1. 紙のセンター (3) とテストパターン (d) の線 (4) のずれを確認する。ずれが基準値外の場合、次の手順で調整をおこなう。
<基準値> $\pm 2.0\text{mm}$ 以内
2. メンテナンスモード U034 をセットし、[LSU Out Left] > [Cass2]/[Cassette2] または [Cass3]/[Cassette3] を選択する。
([Cass※] : 30 枚機での表示, [Cassette※] : 35 枚機 / 40 枚機での表示)



3. Adjust the values.

Test pattern (e) : Increase the setting value.

Test pattern (f) : Decrease the setting value.

Amount of change per step: 0.1mm

4. Press the [Start] key to confirm the setting value.

5. Print the test pattern.

6. Repeat the steps 2 to 5 above until the gap of line (4) in test pattern (c) is within the reference.

<Reference value> within ± 2.0 mm.

3. Régler les valeurs.

Mire d'essai (e) : Augmentez la valeur de réglage.

Mire d'essai (f) : Diminuez la valeur de réglage.

Changement par graduation d'échelle: 0,1mm

4. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.

5. Imprimez le motif de test.

6. Répéter les étapes 2 à 5 ci-dessus jusqu'à ce que l'espace de la ligne (4) dans le motif de test (c) soit dans la référence.

<Valeur de référence> $\pm 2,0$ mm max.

3. Ajuste los valores.

Patrón de prueba (e) : Aumente el valor de configuración.

Patrón de prueba (f) : Reduzca el valor de configuración.

Magnitud del cambio por incremento: 0,1mm

4. Pulse la tecla de [Inicio] para confirmar el valor de configuración.

5. Imprima el patrón de prueba.

6. Repita los pasos del 2 al 5 anteriores hasta que el espacio de línea (4) del patrón de prueba (c) esté dentro de los valores de referencia.

<Valor de referencia> dentro de $\pm 2,0$ mm.

3. Die Werte einstellen.

Testmuster (e) : Den Einstellwert erhöhen.

Testmuster (f) : Den Einstellwert verringern.

Änderung pro Schritt: 0,1mm

4. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.

5. Drucken Sie die Testseite aus.

6. Wiederholen Sie die Schritte 2 bis 5 solange, bis der Abstand der Linie (4) auf der Testseite (c) sich innerhalb der Referenz befindet.

<Bezugswert> Innerhalb $\pm 2,0$ mm.

3. Regolare i valori.

Modello di prova (e) : Aumentare il valore dell'impostazione.

Modello di prova (f) : Diminuire il valore dell'impostazione.

Entità modifica per passo: 0,1mm

4. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.

5. Stampare lo schema di prova.

6. Ripetere i punti da 2 a 5 sopra indicati fino a portare lo spazio della linea (4) nello schema di prova (c) all'interno del riferimento.

<Valore di riferimento> entro $\pm 2,0$ mm

3. 調整設定値。

测试图案 (e) : 调高设定值。

测试图案 (f) : 调低设定值。

设定值的一个调整单位变化量: 0.1mm

4. 按 [开始] 键, 以确定设定值。

5. 打印测试图案。

6. 重复步骤 2 ~ 5, 直至测试样张 (c) 的线 (4) 的偏移值达到标准值以内。

<标准值> ± 2.0 mm 以内

3. 설정치를 조정합니다 .

테스트 패턴 (e) : 설정치를 높입니다 .

테스트 패턴 (f) : 설정치를 내립니다 .

1 스텝당 변화량 : 0.1mm

4. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .

5. 시험 패턴을 인쇄합니다 .

6. 테스트 패턴 (c) 에서 라인 (4) 의 격차가 기준 이내가 될 때까지 2 단계 ~ 5 단계를 반복 수행합니다 .

<기준치> ± 2.0 mm 이내

3. 設定値を調整する。

テストパターン (e) : 設定値を上げる。

テストパターン (f) : 設定値を下げる。

1 ステップ当たりの変化量: 0.1mm

4. [スタート] キーを押し、設定値を確定する。

5. テストパターンを出力する。

6. テストパターン (d) の線 (4) のずれが基準値内になるまで手順 2 ~ 5 を繰り返す。

<基準値> ± 2.0 mm 以内

PF-5140

(2000 sheets Paper Feeder)

Installation Guide

INSTALLATION GUIDE

GUIDE D'INSTALLATION

GUÍA DE INSTALACION

INSTALLATIONSANLEITUNG


GUIDA ALL'INSTALLAZIONE


安装手册

설치안내서


設置手順書

PF-5140







1




2




3




4











5




6






15




16





- ENG Select holes (1) and install each stopper (E,F) with two S Tite screws M4 x 20 (D) so that the stoppers will be grounded on the floor.
- FR Sélectionner les trous (1) et installer chaque butée (E,F) avec les deux vis S Tite M4 x 20 (D) de sorte que les butées reposent sur le sol.
- ES Seleccione los orificios (1) e instale cada tope (E,F) con los dos tornillos S Tite M4 x 20 (D) de manera que los topes se conecten a tierra en el suelo.
- DE Wählen Sie die Öffnungen (1) und befestigen Sie jeden Anschlag (E,F) mit die beiden S-Tite-Schrauben M4 x 20 (D) so an, dass die Anschläge am Boden aufsitzen.
- IT Selezionare i fori (1) ed installare ogni fermo (E,F) con le due viti S Tite M4 x 20 (D) in modo che i fermi siano posti a terra sul pavimento.
- CN 在孔 (1) 处各用 2 颗 M4×20 紧固型 S 螺丝 (D) 安装限位器 (E,F) , 使之和地板接触。
- KO 전도방지쇠 (E,F) 가 바닥면에 접지될 수 있도록 구멍 (1) 을 선택해 나사 M4×20 S 타이트 (D) 각 2 개로 설치합니다 .
- JP 転倒防止金具(E,F)が床面に接地するように、穴(1)を選択してビスM4×20 Sタイト(D)各2本で取り付ける。

17



18





English

Adjusting the leading edge timing

1. Check the gap between the paper center (1) and the line (2) of test pattern (a). If the gap exceeds the reference value, adjust the gap according to the following procedure.

<Reference value> -0mm to +1.0mm

2. Set the maintenance mode U034 and select [LSU Out Top Full] > [PF].

Français

Réglage de la synchronisation du bord de tête

1. Vérifier l'espace entre le centre du papier (1) et la ligne (2) du motif de (a). Si l'écart excède la valeur de référence, le régler selon la procédure suivante.

<Valeur de référence> -0mm à +1,0 mm

2. Passez en mode maintenance U034 et sélectionnez [LSU Out Top Full] > [PF].

Español

Cómo ajustar la sincronización del borde superior

1. Compruebe el espacio entre el centro del papel (1) y la línea (2) del patrón de prueba (a). Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.

<Valor de referencia> De -0 mm a +1,0 mm

2. Configure el modo de mantenimiento U034 y seleccione [LSU Out Top Full] > [PF].

Deutsch

Einstellen des Vorderkanten-Timing

1. Überprüfen Sie den Abstand zwischen der Papiermitte (1) und der Linie (2) auf der Testseite (a). Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.

<Bezugswert> -0 mm bis +1,0 mm

2. Aktivieren Sie den Wartungsmodus U034 und wählen Sie [LSU Out Top Full] > [PF].

Italiano

Regolazione della sincronizzazione del bordo principale

1. Controllare lo spazio tra il centro del foglio (1) e la linea (2) dello schema di prova (a). Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.

<Valore di riferimento> da -0 mm a +1,0 mm

2. Impostare la modalità manutenzione U034 e selezionare [LSU Out Top Full] > [PF].

简体中文

前端对位调节

1. 确认纸张的中心(1)和测试样张(a)的线(2)之间的偏移值。如果偏移值超过标准值,则按照下列步骤进行调整。

<标准值> -0mm ~ +1.0mm

2. 进入维修保养模式 U034, 把 [LSU Out Top Full] > [PF]。

한국어

선단 타이밍 조정

1. 용지 중앙 (1) 과 테스트 패턴 (a) 의 라인 (2) 사이의 격차를 확인하십시오 . 차이가 기준치 외의 경우 다음의 순서대로 조정을 합니다 .

< 기준치 > -0mm ~ +1.0mm

2. 메인テナンス 모드 U034 를 설정하고 [LSU Out Top Full] > [PF] 를 선택합니다 .


日本語

先端タイミング調整

1. 紙のセンター(1)とテストパターン(a)の線(2)のずれを確認する。ずれが基準値外の場合、次の手順で調整をおこなう。

<基準値> -0mm ~ +1.0mm

2. メンテナンスモード U034 をセットし、[LSU Out Top Full] > [PF] を選択する。



3. Adjust the values.

Test pattern (b) : Increase the setting value.

Test pattern (c) : Decrease the setting value.

Amount of change per step: 0.1mm

4. Press the [Start] key to confirm the setting value.

5. Print the test pattern.

6. Repeat the steps 2 to 5 above until the gap of line (2) in test pattern (a) is within the reference.

<Reference value> -0mm to +1.0mm

3. Régler les valeurs.

Mire d'essai (b) : Augmentez la valeur de réglage.

Mire d'essai (c) : Diminuez la valeur de réglage.

Changement par graduation d'échelle: 0,1 mm

4. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.

5. Imprimez le motif de test.

6. Répéter les étapes 2 à 5 ci-dessus jusqu'à ce que l'espace de la ligne (2) dans le motif de test (a) soit dans la référence.

<Valeur de référence> -0 mm à +1,0 mm

3. Ajuste los valores.

Patrón de prueba (b) : Aumente el valor de configuración.

Patrón de prueba (c) : Reduzca el valor de configuración.

Magnitud del cambio por incremento: 0,1 mm

4. Pulse la tecla de [Inicio] para confirmar el valor de configuración.

5. Imprima el patrón de prueba.

6. Repita los pasos del 2 al 5 anteriores hasta que el espacio de línea (2) del patrón de prueba (a) esté dentro de los valores de referencia.

<Valor de referencia> De -0 mm a +1,0 mm

3. Die Werte einstellen.

Testmuster (b) : Den Einstellwert erhöhen.

Testmuster (c) : Den Einstellwert verringern.

Änderung pro Schritt: 0,1 mm

4. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.

5. Drucken Sie die Testseite aus.

6. Wiederholen Sie die Schritte 2 bis 5 solange, bis der Abstand der Linie (2) auf der Testseite (a) sich innerhalb der Referenz befindet.

<Bezugswert> -0 mm bis +1,0 mm

3. Regolare i valori.

Modello di prova (b) : Aumentare il valore dell'impostazione.

Modello di prova (c) : Diminuire il valore dell'impostazione.

Entità modifica per passo: 0,1 mm

4. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.

5. Stampare lo schema di prova.

6. Ripetere i punti da 2 a 5 sopra indicati fino a portare lo spazio della linea (2) nello schema di prova (a) all'interno del riferimento.

<Valore di riferimento> da -0 mm a +1,0 mm

3. 調整設定値。

测试图案 (b) : 调高设定值。

测试图案 (c) : 调低设定值。

设定值的一个调整单位变化量: 0.1mm

4. 按 [开始] 键, 以确定设定值。

5. 打印测试图案。

6. 重复步骤 2 ~ 5, 直至测试样张 (a) 的线 (2) 的偏移值达到标准值以内。

<标准值> -0mm ~ +1.0mm

3. 설정치를 조정합니다 .

테스트 패턴 (b) : 설정치를 높입니다 .

테스트 패턴 (c) : 설정치를 내립니다 .

1 스텝당 변화량:0.1mm

4. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .

5. 시험 패턴을 인쇄합니다 .

6. 테스트 패턴 (a) 에서 라인 (2) 의 격차가 기준 이내가 될 때까지 2 단계 ~ 5 단계를 반복 수행합니다 .

<기준치> -0mm ~ +1.0mm

3. 設定値を調整する。

テストパターン (b) : 設定値を上げる。

テストパターン (c) : 設定値を下げる。


1 ステップ当たりの変化量:0.1mm

4. [スタート] キーを押し、設定値を確定する。

5. テストパターンを出力する。

6. テストパターン (a) の線 (2) のずれが基準値内になるまで手順 2 ~ 5 を繰り返す。

<基準値> -0mm ~ +1.0mm



Adjusting the center line

1. Check the gap between the paper center (3) and the line (4) of test pattern (c). If the gap exceeds the reference value, adjust the gap according to the following procedure.
<Reference value> within $\pm 2,0$ mm.
2. Set the maintenance mode U034 and select [LSU Out Left] > [Cass2]/[Cassette2] or [Cass3]/[Cassette3].
([Cass*] : Display for 30 ppm model, [Cassette*] : Display for 35 and 40 ppm model)

Réglage de l'axe

1. Vérifier l'espace entre le centre du papier (3) et la ligne (4) du motif de (c). Si l'écart excède la valeur de référence, le régler selon la procédure suivante.
2. Passez en mode maintenance U034 et sélectionnez [LSU Out Left] > [Cass2]/[Cassette2] ou [Cass3]/[Cassette3].
([Cass*] : Affichage pour le modèle 30 ppm, [Cassette*] : Affichage pour les modèles 35 et 40 ppm)

Ajuste de la línea central

1. Compruebe el espacio entre el centro del papel (3) y la línea (4) del patrón de prueba (c). Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.
<Valor de referencia> Dentro de $\pm 2,0$ mm.
2. Configure el modo de mantenimiento U034 y seleccione [LSU Out Left] > [Cass2]/[Cassette2] o [Cass3]/[Cassette3].
([Cass*] : Opción mostrada para el modelo de 30 ppm, [Cassette*] : Opción mostrada para los modelos de 35 y 40 ppm)

Einstellen der Mittelinie

1. Überprüfen Sie den Abstand zwischen der Papiermitte (3) und der Linie (4) auf der Testseite (c). Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.
<Bezugswert> Innerhalb $\pm 2,0$ mm.
2. Aktivieren Sie den Wartungsmodus U034 und wählen Sie [LSU Out Left] > [Cass2]/[Cassette2] oder [Cass3]/[Cassette3].
([Cass*] : Anzeige für das 30-Seiten-Modell, [Cassette*] : Anzeige für das 35- und 40-Seiten-Modell)

Regolazione della linea centrale

1. Controllare lo spazio tra il centro del foglio (3) e la linea (4) dello schema di prova (c). Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.
<Valore di riferimento> Entro $\pm 2,0$ mm.
2. Impostare la modalità manutenzione U034 e selezionare [LSU Out Left] > [Cass2]/[Cassette2] o [Cass3]/[Cassette3].
([Cass*] : Visualizzazione per modello da 30 ppm, [Cassette*] : Visualizzazione per modelli da 35 e 40 ppm)

中心线调节


1. 确认纸张的中心 (3) 和测试样张 (c) 的线 (4) 之间的偏移值。如果偏移值超过标准值，则按照下列步骤进行调整。
<标准值> ± 2.0 mm 以内
2. 进入维修保养模式 U034，把 [LSU Out Left] > [Cass2]/[Cassette2] 或 [Cass3]/[Cassette3]。
([Cass*] : 在 30 张机器上的显示，[Cassette*] : 在 35 张机器 / 40 张机器上的显示)

센터라인 조정

1. 용지 중앙 (3) 과 테스트 패턴 (c) 의 라인 (4) 사이의 격차를 확인하십시오 . 차이가 기준치 외의 경우 다음의 순서대로 조정을 합니다 .
<기준치> ± 2.0 mm 이내
2. 메인テナンス 모드 U034 를 설정하고 [LSU Out Left] > [Cass2]/[Cassette2] 또는 [Cass3]/[Cassette3] 을 선택합니다 .
([Cass*] : 30ppm 모델용 디스플레이 , [Cassette*] : 35ppm 및 40ppm 모델용 디스플레이)

センターライン調整

1. 紙のセンター(3) とテストパターン (d) の線 (4) のずれを確認する。ずれが基準値外の場合、次の手順で調整をおこなう。
<基準値> ± 2.0 mm 以内
2. メンテナンスモード U034 をセットし、[LSU Out Left] > [Cass2]/[Cassette2] または [Cass3]/[Cassette3] を選択する。
([Cass※]: 30 枚機での表示、[Cassette※]: 35 枚機 / 40 枚機での表示)



3. Adjust the values.

Test pattern (e) : Increase the setting value.

Test pattern (f) : Decrease the setting value.

Amount of change per step: 0.1mm

4. Press the [Start] key to confirm the setting value.

5. Print the test pattern.

6. Repeat the steps 2 to 5 above until the gap of line (4) in test pattern (c) is within the reference.

<Reference value> within ± 2.0 mm.

3. Régler les valeurs.

Mire d'essai (e) : Augmentez la valeur de réglage.

Mire d'essai (f) : Diminuez la valeur de réglage.

Changement par graduation d'échelle: 0,1 mm

4. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.

5. Imprimez le motif de test.

6. Répéter les étapes 2 à 5 ci-dessus jusqu'à ce que l'espace de la ligne (4) dans le motif de test (c) soit dans la référence.

<Valeur de référence> $\pm 2,0$ mm max.

3. Ajuste los valores.

Patrón de prueba (e) : Aumente el valor de configuración.

Patrón de prueba (f) : Reduzca el valor de configuración.

Magnitud del cambio por incremento: 0,1 mm

4. Pulse la tecla de [Inicio] para confirmar el valor de configuración.

5. Imprima el patrón de prueba.

6. Repita los pasos del 2 al 5 anteriores hasta que el espacio de línea (4) del patrón de prueba (c) esté dentro de los valores de referencia.

<Valor de referencia> dentro de $\pm 2,0$ mm.

3. Die Werte einstellen.

Testmuster (e) : Den Einstellwert erhöhen.

Testmuster (f) : Den Einstellwert verringern.

Änderung pro Schritt: 0,1 mm

4. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.

5. Drucken Sie die Testseite aus.

6. Wiederholen Sie die Schritte 2 bis 5 solange, bis der Abstand der Linie (4) auf der Testseite (c) sich innerhalb der Referenz befindet.

<Bezugswert> Innerhalb $\pm 2,0$ mm.

3. Regolare i valori.

Modello di prova (e) : Aumentare il valore dell'impostazione.

Modello di prova (f) : Diminuire il valore dell'impostazione.

Entità modifica per passo: 0,1 mm

4. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.

5. Stampare lo schema di prova.

6. Ripetere i punti da 2 a 5 sopra indicati fino a portare lo spazio della linea (4) nello schema di prova (c) all'interno del riferimento.

<Valore di riferimento> entro $\pm 2,0$ mm

3. 調整設定値。

测试图案 (e) : 调高设定值。

测试图案 (f) : 调低设定值。

设定值的一个调整单位变化量: 0.1mm

4. 按 [开始] 键, 以确定设定值。

5. 打印测试图案。

6. 重复步骤 2 ~ 5, 直至测试样张 (c) 的线 (4) 的偏移值达到标准值以内。

<标准值> ± 2.0 mm 以内

3. 설정치를 조정합니다 .

테스트 패턴 (e) : 설정치를 높입니다 .

테스트 패턴 (f) : 설정치를 내립니다 .

1 스텝당 변화량 : 0.1mm

4. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .

5. 시험 패턴을 인쇄합니다 .

6. 테스트 패턴 (c) 에서 라인 (4) 의 격차가 기준 이내가 될 때까지 2 단계 ~ 5 단계를 반복 수행합니다 .

<기준치> ± 2.0 mm 이내

3. 設定値を調整する。

テストパターン (e) : 設定値を上げる。

テストパターン (f) : 設定値を下げる。

1 ステップ当たりの変化量: 0.1mm

4. [スタート] キーを押し、設定値を確定する。

5. テストパターンを出力する。

6. テストパターン (d) の線 (4) のずれが基準値内になるまで手順 2 ~ 5 を繰り返す。

<基準値> ± 2.0 mm 以内

DP-5100

(Document processor: RADF)

Installation Guide

INSTALLATION GUIDE

GUIDE D'INSTALLATION

GUÍA DE INSTALACION

INSTALLATIONSANLEITUNG


GUIDA ALL'INSTALLAZIONE


安装手册

설치안내서

設置手順書



DP-5100







1

2




3


4




5




6




7




8




9



10





English

[Operation check]

- 1.To check the machine operation, prepare original (a) where 4 lines (b) are drawn 20 mm from the edges of the A4 sheet and 1 line (c) is drawn at its center.
- 2.Connect the power plug of the MFP into the wall outlet and turn the main power switch on.
- 3.Set the original (a) on the DP and perform a test copy to check the operation and the copy example.

Français

[Vérification du fonctionnement]

- 1.Pour vérifier le bon fonctionnement de l'appareil, préparer un original (a) sur lequel sont tracées 4 lignes (b) à 20 mm des bords de la feuille A4 et 1 ligne (c) en son axe.
- 2.Brancher la fiche d'alimentation du MFP sur la prise murale et mettre l'appareil sous tension.
- 3.Placer l'original (a) sur le DP et effectuer une copie de test pour vérifier le fonctionnement et l'exemple de copie.

Español

[Verifique el funcionamiento]

- 1.Para comprobar el funcionamiento del aparato, prepare un original (a) que contenga 4 líneas (b) dibujadas a 20 mm de los bordes de la hoja A4 y 1 línea (c) dibujada en el centro.
- 2.Conecte el enchufe eléctrico del MFP en el tomacorriente de la pared y encienda el interruptor principal.
- 3.Coloque el original (a) en el DP y haga una copia de prueba para verificar el funcionamiento y el ejemplo de copia.

Deutsch

[Funktionsprüfung]

- 1.Zum Prüfen der Gerätefunktion das Original (a) vorbereiten, auf das 4 Linien (b) 20 mm von den Kanten des A4-Blattes und 1 Linie (c) in der Mitte gezeichnet sind.
- 2.Den Netzstecker am MFP in die Steckdose stecken und den Strom einschalten.
- 3.Das Original (a) auf den DP legen und eine Testkopie erstellen, um die Funktion und das Kopierbeispiel zu prüfen.

Italiano

[Verifica del funzionamento]

- 1.Per verificare il funzionamento della macchina, preparare l'originale (a) tirando 4 linee (b) a 20 mm dai bordi del foglio A4 e una linea (c) al centro.
- 2.Inserire la spina dell'alimentazione dell'MFP nella presa a muro, quindi posizionare l'interruttore principale su On.
- 3.Posizionare l'originale(a) sul DP ed eseguire una copia di prova per verificare il funzionamento e l'esempio di copia.

简体中文

[动作确认]

1. 若要检查机器动作，准备一张 A4 原稿 (a)，距纸张边缘 20mm 画出 4 条线 (b) 并且在原稿中心画出 1 条线 (c)。
2. 将 MFP 的电源插头插入墙壁插座并打开主电源。
3. 在 DP 上设定原稿 (a) 并进行测试复印，确认机器动作和复印样本。

한국어


[동작확인]

1. 기계 작동 확인을 위해서, A4 용지 선단에서 20mm 떨어진 곳에 4 개의 선 (b) 과 센터에 1 개의 선 (c) 이 그려진 원고 (a) 를 준비.
2. 콘센트에 MFP 전원플러그를 꽂고 메인 전원 스위치를 ON 으로 합니다.
3. DP 상에 원고 (a) 를 준비하고 테스트 카피를 확인하여 작동 상태와 카피 샘플을 확인합니다.

日本語

[動作確認]

1. A4 サイズ用紙の端から 20mm の位置に線 (b) 4 本と、用紙の中心に線 (c) 1 本を引いた動作確認用の原稿 (a) を用意する。
2. MFP の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。
3. 原稿 (a) を DP にセットし、テストコピーを行い、動作およびコピーサンプルを確認する。



4. Compare original (a) with the copy example. If the gap exceeds the reference value, perform the following adjustments according to the type of the gap.

Check images of the DP after checking and adjusting images of the MFP. For details, see the service manual.

NOTICE: If there is any image fogging, adjust the U068 DP scanning position. If you change the scanning position with U068, adjust the U071 DP leading edge timing.

4. Comparer l'original (a) avec l'exemple de copie. Si l'écart excède la valeur de référence, effectuer les réglages suivants en fonction du type d'écart.

Vérifier les images du DP après avoir contrôlé et réglé les images du MFP. Pour plus de détails, se reporter au manuel d'entretien.

REMARQUE: Si l'image est floue, régler la position de balayage de U068 du DP. Si la position de balayage de U068 est modifiée, régler la synchronisation du bord d'attaque de U071.

4. Compare el original (a) con el ejemplo de copia. Si la separación supera el valor de referencia, realice los siguientes ajustes según el tipo de separación.

Compruebe las imágenes del DP después de comprobar y ajustar las imágenes del MFP. Para más detalles, lea el manual de servicio.

AVISO: Si la imagen estuviera borrosa, ajuste la posición de escaneo U068 del DP. Si cambia la posición de escaneo con U068, ajuste la sincronización de borde superior U071 del DP.

4. Das Original (a) mit dem Kopierbeispiel vergleichen. Wenn der Abstand größer als der Bezugswert ist, die folgenden Einstellungen gemäß dem Abstandstyp durchführen.

Die Bilder des DP nach dem Prüfen und Einstellen der Bilder des MFP prüfen. Weitere Einzelheiten siehe Wartungsanleitung.

ANMERKUNG: Falls das Bild verschwommen wirkt, ist die U068 DP Scan-Position zu verstellen. Wenn Sie die Scan-Position mit U068 verstellen, müssen Sie das U071 DP-Vorderkanten-Timing entsprechend verstellen.

4. Confrontare l'originale (a) con l'esempio di copia. Se lo scostamento supera il valore di riferimento, eseguire le seguenti regolazioni in funzione del tipo di scostamento.

Controllare le immagini del DP dopo avere effettuato i controlli e le regolazioni delle immagini sull'MFP. Per ulteriori dettagli leggere il manuale d'istruzioni.

AVVISO: Se è presente una qualsiasi sfocatura dell'immagine, regolare la posizione di scansione DP U068. Se si cambia la posizione di scansione con U068, regolare la sincronizzazione del bordo principale DP U071.

4. 对比复印样本和原稿(a), 如果偏移值在标准值以上时, 对偏移原稿进行调整。

对 MFP 的图像确认和调整后再对 DP 的图像进行确认。详细内容请参见维修手册。

(注意) 如果图像出现底灰, 用 U068 来调整 DP 的扫描位置。如果用 U068 更改了扫描位置, 则再用 U071 对 DP 的前端定时进行调整。

4. 원고 (a) 와 카피 샘플을 비교하여 차이가 기준치를 벗어나는 경우, 차이 (틈) 의 형태에 따라 다음을 조정합니다.

MFP 의 화상확인 및 조정을 하고나서 DP 의 화상확인을 할 것. 상세는 서비스 매뉴얼을 참조할 것.

(주의) 화상 카브리가 발생하는 경우, U068DP 스캔위치 조정을 합니다. U068 에서 스캔위치를 변경한 경우 U071DP 선단 타이밍 조정을 합니다.

4. 原稿 (a) とコピーサンプルを比較し、基準値以上のずれがある場合、ずれ方に応じて調整を行う。

MFP の画像確認及び調整を行ってから DP の画像確認を行うこと。詳細はサービスマニュアルを参照のこと。

(注意) 画像カブリが発生する場合、U068 DP 読み取り位置の調整を行う。U068 で読み取り位置を変更した場合、U071 DP 先端タイミング調整を行う。

Be sure to adjust in the following order. If not, the adjustment cannot be performed correctly.

For checking the angle of leading edge, see page 6. <Reference value> Simplex copying: within ± 2.0 mm; Duplex copying: within ± 3.0 mm

For checking the magnification, see page 9. <Reference value> Within $\pm 1.5\%$

For checking the leading edge timing, see page 11. <Reference value> Within ± 2.5 mm

For checking the center line, see page 13. <Reference value> Simplex copying: within ± 2.0 mm; Duplex copying: within ± 3.0 mm

When using the original for adjustment, automatic adjustment of magnification, leading edge timing and center line can be performed at a time.

For the automatic adjustment using the original for adjustment, see page 16.

Veillez à effectuer le réglage en procédant dans l'ordre suivant. Sinon, il sera impossible d'obtenir un réglage correct.

Pour vérifier l'angle du bord avant, reportez-vous à la page 6. <Valeur de référence> Copie recto seul: $\pm 2,0$ mm max.; copie recto verso: $\pm 3,0$ mm max.

Pour vérifier l'agrandissement, reportez-vous à la page 9. <Valeur de référence> $\pm 1,5\%$ max.

Pour vérifier la synchronisation du bord avant, reportez-vous à la page 11. <Valeur de référence> $\pm 2,5$ mm max.

Pour vérifier la ligne médiane, reportez-vous à la page 13. <Valeur de référence> Copie recto seul: $\pm 2,0$ mm max.; Copie recto verso: $\pm 3,0$ mm max.

Lorsque vous utilisez l'original pour effectuer le réglage, vous pouvez effectuer automatiquement le réglage de l'agrandissement, de la synchronisation du bord avant et de la ligne médiane en une seule fois.

Pour le réglage automatique en utilisant l'original pour effectuer le réglage, reportez-vous à la page 16.

Asegúrese de ajustar en el siguiente orden. De lo contrario, el ajuste no puede hacerse correctamente.

Para verificar el ángulo del borde superior, vea la página 6. <Valor de referencia> Copia simple: dentro de $\pm 2,0$ mm; Copia duplex: dentro de $\pm 3,0$ mm

Para verificar el cambio de tamaño, vea la página 9. <Valor de referencia> Dentro de $\pm 1,5\%$

Para verificar la sincronización del borde superior, vea la página 11. <Valor de referencia> Dentro de $\pm 2,5$ mm

Para verificar la línea central, vea la página 13. <Valor de referencia> Copia simple: dentro de $\pm 2,0$ mm; Copia duplex: dentro de $\pm 3,0$ mm

Cuando utilice el original para el ajuste, puede hacerse un ajuste automático del cambio de tamaño, sincronización del borde superior y línea central al mismo tiempo.

Para el ajuste automático utilizando el original para el ajuste, vea la página 16.

Die Einstellung in der folgenden Reihenfolge durchführen. Anderenfalls kann die Einstellung nicht korrekt durchgeführt werden.

Angaben zur Prüfung des Winkels der Vorderkante auf Seite 6. <Bezugswert> Simplexkopie: innerhalb $\pm 2,0$ mm; Duplexkopie: innerhalb $\pm 3,0$ mm

Angaben zur Prüfung der Vergrößerung auf Seite 9. <Bezugswert> Innerhalb $\pm 1,5\%$

Angaben zur Prüfung des Vorderkanten-Timings auf Seite 11. <Bezugswert> Innerhalb $\pm 2,5$ mm

Angaben zur Prüfung der Mittellinie auf Seite 13. <Bezugswert> Simplexkopie: innerhalb $\pm 2,0$ mm; Duplexkopie: innerhalb $\pm 3,0$ mm

Bei Verwendung des Originals für die Einstellung können die automatischen Einstellungen für Vergrößerung, Vorderkanten-Timing und Mittellinie gleichzeitig durchgeführt werden.

Angaben zur automatischen Einstellung mithilfe des Originals auf Seite 16.

Accertarsi di eseguire le regolazioni in questa sequenza: in caso contrario, la regolazione non può essere effettuata correttamente.

Per controllare l'angolo del bordo principale, vedere pagina 6. <Valore di riferimento> Copia simplex: entro $\pm 2,0$ mm; Copia duplex: entro $\pm 3,0$ mm

Per controllare l'ingrandimento, vedere pagina 9. <Valore di riferimento> Entro $\pm 1,5\%$

Per controllare la sincronizzazione del bordo principale, vedere pagina 11. <Valore di riferimento> Entro $\pm 2,5$ mm

Per controllare la linea centrale, vedere pagina 13. <Valore di riferimento> Copia simplex: entro $\pm 2,0$ mm; Copia duplex: entro $\pm 3,0$ mm

Quando si utilizza l'originale per la regolazione, la regolazione automatica dell'ingrandimento, della sincronizzazione del bordo principale e della linea centrale possono essere eseguiti contemporaneamente.

Per la regolazione automatica eseguita con l'originale, vedere pagina 16.

必須按照以下步驟進行調整，否則不能達到準確調整的要求。

• 確認前端傾斜度 第 6 頁 <標準值> 單面： ± 2.0 mm 以內，雙面： ± 3.0 mm 以內

• 確認等倍值 第 9 頁 <標準值> $\pm 1.5\%$ 以內

• 確認前端定時調整 第 11 頁 <標準值> ± 2.5 mm 以內

• 確認中心線 第 13 頁 <標準值> 單面： ± 2.0 mm 以內，雙面： ± 3.0 mm 以內

使用調整用的原稿時，可以同時自動進行等倍值，前端定時以及中心線的調整。

• 通過調整用原稿進行自動調整 第 16 頁

반드시 하기의 순서로 조정을 할 것. 순서대로 조정을 하지 않는 경우 바른 조정을 할 수 없습니다.

• 선단경사확인 6 페이지 <기준치> 단면： ± 2.0 mm 이내, 양면： ± 3.0 mm 이내

• 등배도 확인 9 페이지 <기준치> $\pm 1.5\%$ 이내

• 선단 타이밍 확인 11 페이지 <기준치> ± 2.5 mm 이내

• 센터 라인 확인 13 페이지 <기준치> 단면： ± 2.0 mm 이내, 양면： ± 3.0 mm 이내

조정용 원고를 사용하면 등배도 조정, 선단 타이밍 조정, 센터 라인 조정의 자동조정이 한번에 수행됩니다.

• 조정용 원고를 사용한 자동조정은 16 페이지 참조

必ず下記の順序で調整を行うこと。順序通りに調整を行わない場合、正しい調整ができない。

• 先端斜め確認 6 ページ <基準値> 片面： ± 2.0 mm 以内、両面： ± 3.0 mm 以内


• 等倍度確認 9 ページ <基準値> $\pm 1.5\%$ 以内

• 先端タイミング確認 11 ページ <基準値> ± 2.5 mm 以内

• センターライン確認 13 ページ <基準値> 片面： ± 2.0 mm 以内、両面： ± 3.0 mm 以内

調整用原稿を使用すると、等倍度調整、先端タイミング調整、センターライン調整の自動調整が一度におこなえる。

• 調整用原稿による自動調整 16 ページ



[Checking the angle of leading edge]

1. Check the horizontal gap between line (1) of original (a) and line (2) of copy example positions. If the gap exceeds the reference value, adjust the gap according to the following procedure.

- <Reference value> For single copying: within ± 2.0 mm.
For duplex copying: within ± 3.0 mm.

[Vérification de l'angle du bord avant]

1. Vérifier l'écart horizontal entre la position de la ligne (1) de l'original (a) et celle de la ligne (2) de l'exemple de copie. Si l'écart excède la valeur de référence, le régler selon la procédure suivante.

- <Valeur de référence> Pour la copie recto : $\pm 2,0$ mm max.
Pour la copie recto-verso : $\pm 3,0$ mm max.

[Verificación del ángulo del borde superior]

1. Compruebe la separación horizontal entre la línea (1) del original (a) y la línea (2) de las posiciones del ejemplo de copia. Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.

- <Valor de referencia> Para el copiado por una cara: dentro de $\pm 2,0$ mm.
Para el copiado dúplex: dentro de $\pm 3,0$ mm.

[Überprüfen des Winkels der Vorderkante]

1. Den horizontalen Abstand zwischen der Linie (1) des Originals (a) und der Linie (2) der Kopierbeispielspositionen prüfen. Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.

- <Bezugswert> Einzelkopie: innerhalb $\pm 2,0$ mm.
Duplexkopie: innerhalb $\pm 3,0$ mm.

[Controllo dell'angolo del bordo principale]

1. Verificare lo scostamento orizzontale fra la linea (1) dell'originale (a) e la linea (2) delle posizioni dell'esempio di copia. Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.

- <Valore di riferimento> Per la copia singola: entro $\pm 2,0$ mm.
Per la copia duplex: entro $\pm 3,0$ mm.

[确认前端倾斜度]

1. 确认原稿 (a) 上的线 (1) 和复印样本上的线 (2) 的左右偏移值。如果偏移值超过标准值，则按照下列步骤进行调整。

- <标准值> 单面复印时： ± 2.0 mm 以内。
双面复印时： ± 3.0 mm 以内。

[선단 경사확인]


1. 원고 (a) 의 선 (1) 과 샘플 카피의 선 (2) 의 좌우 차이를 확인합니다. 차이가 기준치 외의 경우 다음의 순서대로 조정을 합니다.

- <기준치> 단면의 경우 : ± 2.0 mm 이내
양면의 경우 : ± 3.0 mm 이내

[先端斜め確認]

1. 原稿 (a) の線 (1) とコピーサンプルの線 (2) の左右のずれを確認する。ずれが基準値外の場合、次の手順で調整を行う。

- <基準値> 片面の場合 : ± 2.0 mm 以内
両面の場合 : ± 3.0 mm 以内



2. Turn off the main power switch of the machine. Open DP. Perform the steps 3, 4, 5, 6 and 9 in its reverse order on pages 1 and 2 to remove the DP from the MFP.
3. Loosen three adjustment screws (3) for the right side hinge.
4. Adjust the position of the right hinge.
In case of copy sample (d): Move the right hinge up (⇨).
In case of copy sample (e): Move the right hinge down (⇩).
Amount of change per scale: Approx. 0.6 mm (4)
5. After the adjustment, retighten three adjusting screws (3) which were loosened in step 3.

2. Mettez la machine hors tension. Ouvrez le DP. Effectuez les étapes 3, 4, 5, 6 et 9 dans l'ordre inverse aux pages 1 et 2 pour retirer le DP du MFP.
3. Desserrez trois vis de réglage (3) pour la charnière droite.
4. Ajustez la position de la charnière droite.
Dans le cas de l'exemple de copie (d) : Déplacer la charnière de droite vers le haut (⇨).
Dans le cas de l'exemple de copie (e) : Déplacer la charnière de droite vers le bas (⇩).
Changement par graduation d'échelle : environ 0,6 mm (4)
5. Après l'ajustement, resserrez les trois vis de réglage (3) qui ont été desserrées à l'étape 3.

2. Apague el interruptor de encendido de la máquina. Abra el DP. Realice los pasos 3, 4, 5, 6 y 9 de las páginas 1 y 2 pero al revés para quitar el DP del dispositivo MFP.
3. Suelte los tres tornillos de ajuste (3) de la bisagra en el lado derecho.
4. Ajuste la posición de la bisagra derecha.
En caso de muestra de copia (d): Suba la bisagra derecha (⇨).
En caso de muestra de copia (e): Baje la bisagra derecha (⇩).
Magnitud del cambio por escala: aprox. 0,6 mm (4)
5. Después del ajuste, vuelva a apretar los tres tornillos de ajuste (3) que se aflojaron en el paso 3.


2. Schalten Sie das Gerät über den Hauptschalter aus. Öffnen Sie DP. Führen Sie die Schritte 3, 4, 5, 6 und 9 in umgekehrter Reihenfolge wie auf den Seiten 1 und 2 beschrieben aus. Entfernen Sie den DP vom MFP.
3. Lösen Sie die drei Einstellschrauben (3) am rechten Scharnier.
4. Justieren Sie die Position des rechten Scharniers.
Bei Verwendung der Kopiervorlage (d): Bewegen Sie das rechte Scharnier nach oben (⇨).
Bei Verwendung der Kopiervorlage (e): Bewegen Sie das rechte Scharnier nach unten (⇩).
Änderung pro Maßstab: Ungefähr 0,6 mm (4)
5. Nachdem Sie die Einstellung vorgenommen haben, ziehen Sie die drei Justierschrauben (3) wieder an, die Sie in Schritt 3 gelöst hatten.

2. Spegner l'interruttore di alimentazione della macchina. Aprire il DP. Eseguire i punti 3, 4, 5, 6 e 9 eseguendo le operazioni in ordine contrario rispetto a quanto indicato a pagina 1 e 2 per rimuovere il DP dal dispositivo MFP.
3. Allentare le tre viti di regolazione (3) sulla cerniera di destra.
4. Regolare la posizione della cerniera di destra.
Nel caso dell'esempio copia (d): Alzare la cerniera destra (⇨).
Nel caso dell'esempio copia (e): Abbassare la cerniera destra (⇩).
Entità modifica per scala: circa 0,6 mm (4)
5. Dopo la regolazione, serrare di nuovo le tre viti di regolazione (3), allentate al punto 3.

2. 关闭机器的主电源开关。打开DP。按照第1~2页的步骤3、4、5、6和9的相反顺序，把DP从机器上取下。
3. 拧松3颗右铰链的调整螺丝(3)。
4. 调整右铰链的位置。
当处于样张(d)：将右铰链向上(⇨)移动。
当处于样张(e)：将右铰链向下(⇩)移动。
按比例尺的更改量：约0.6mm(4)
5. 调整完成后，重新拧紧在步骤3中松开的3颗调整螺丝(3)。

2. 기계의 전원을 OFF 합니다. DP를 엽니다. 1~2 페이지의 단계 3,4,5,6,9를 역순으로 MFP에서 DP를 떼어냅니다.
3. 오른쪽 힌지의 조정나사(3) 3개를 풉니다.
4. 우측 힌지의 위치를 조정합니다.
복사 샘플(d)의 경우: 우측 힌지를 위쪽(⇨)에 움직입니다.
복사 샘플(e)의 경우: 우측 힌지를 아래쪽(⇩)에 움직입니다.
눈금당 변화량: 약 0.6 mm (4)
5. 조정종료 후 순서 3에서 느슨하게 한 조정나사(3) 3개를 조입니다.

2. 機械の主電源スイッチをOFFにする。DPを開く。1~2ページの手順3,4,5,6,9の逆手順でDPをMFPから取り外す。
3. 右ヒンジの調整ビス(3)3本を緩める。
4. 右ヒンジの位置を調整する。
コピーサンプル(d)の場合: 右ヒンジを上(⇨)へ動かす。
コピーサンプル(e)の場合: 右ヒンジを下(⇩)へ動かす。
1目盛り当たりの変化量: 約0.6mm(4)
5. 調整終了後、手順3で緩めた調整ビス(3)3本を締め付ける。



6. Perform the steps 3, 4, 5, 6 and 9 on pages 1 and 2 to reinstall the DP on the MFP.
7. Turn on the main power switch of the machine. Perform a test copy.
8. Repeat the steps above until the gap of line (2) of copy example shows the following reference values.
 <Reference value> For single copying: within ± 2.0 mm.
 For duplex copying: within ± 3.0 mm.
9. Remove the original mat and attach it again in accordance with step 8 and 9 on page 2.

6. Effectuez les étapes 3, 4, 5, 6 et 9 aux pages 1 et 2 pour réinstaller le DP sur le MFP.
7. Mettez la machine sous tension. Effectuez une copie de test.
8. Répétez les étapes ci-dessus jusqu'à ce que l'écart de la ligne (2) de l'exemple de copie indique les valeurs de référence suivantes.
 <Valeur de référence> Pour la copie recto : $\pm 2,0$ mm max.
 Pour la copie recto-verso : $\pm 3,0$ mm max.
9. Retirez le tapis d'original et remettez-le en place conformément aux étapes 8 et 9 à la page 2.

6. Realice los pasos 3, 4, 5, 6 y 9 de las páginas 1 y 2 para reinstalar el DP en el dispositivo MFP.
7. Encienda el interruptor de encendido de la máquina. Haga una copia de prueba.
8. Repita los pasos anteriores hasta que la separación de la línea (2) del ejemplo de copia presente los siguientes valores de referencia.
 <Valor de referencia> Para el copiado por una cara: dentro de $\pm 2,0$ mm.
 Para el copiado dúplex: dentro de $\pm 3,0$ mm.
9. Quite la almohadilla de originales y vuelva a colocarla según lo indicado en los pasos 8 y 9 en la página 2.


6. Führen Sie auf den Seiten 1 und 2 die Schritte 3, 4, 5, 6 und 9 aus, um den DP wieder am MFP zu installieren.
7. Schalten Sie das Gerät über den Hauptschalter ein. Eine Testkopie erstellen.
8. Die obigen Schritte wiederholen, bis der Abstand der Linie (2) des Kopierbeispiels die folgenden Bezugswerte aufweist.
 <Bezugswert> Einzelkopie: innerhalb $\pm 2,0$ mm.
 Duplexkopie: innerhalb $\pm 3,0$ mm.
9. Entfernen Sie die Originalmatte und befestigen Sie sie wieder, wie in den Schritten 8 und 9 auf Seite 2 gezeigt.

6. Eseguire i punti 3, 4, 5, 6 e 9 a pagina 1 e 2 per reinstallare il DP sul sistema MFP.
7. Accendere l'interruttore di alimentazione della macchina. Eseguire una copia di prova.
8. Ripetere le operazioni sopra descritte fino a quando lo scostamento della linea (2) dell'esempio di copia riporterà i valori di riferimento seguenti.
 <Valore di riferimento> Per la copia singola: entro $\pm 2,0$ mm.
 Per la copia duplex: entro $\pm 3,0$ mm.
9. Rimuovere il coprioriginale e riposizionarlo attenendosi alla procedura descritta ai punti 8 e 9 di pagina 2.

6. 按照第 1 ~ 2 页的步骤 3, 4, 5, 6, 9, 把 DP 再次装回机器。
7. 打开机器的主电源开关。进行测试复印。
8. 重复上述步骤直至复印样本上的线 (2) 的偏移值达到标准值范围内。
 <标准值> 单面时 : ± 2.0 mm 以内
 双面时 : ± 3.0 mm 以内
9. 取下原稿垫, 参考第 2 页的步骤 8、9, 再次安装。

6. 1~2 페이지의 3,4,5,6,9 단계에서 DP 를 다시 설치합니다 .
7. 기계의 전원을 ON 합니다 . 테스트 카피를 합니다 .
8. 샘플 카피 선 (2) 차이가 기준치내가 될 때까지 조정을 반복합니다 .
 <기준치 > 단면의 경우 : ± 2.0 mm 이내
 양면의 경우 : ± 3.0 mm 이내
9. 원고 매트 를 제거하고 2 페이지의 단계 8 ~ 9 에 따라 다시 부착합니다 .

6. 1 ~ 2 페이지の手順 3, 4, 5, 6, 9 の手順で DP を再度取り付け。
7. 機械の主電源スイッチを ON にする。テストコピーを行う。
8. コピーサンプルの線 (2) のずれが基準値内になるまで、調整を繰り返す。
 <基準値> 片面の場合 : ± 2.0 mm 以内
 両面の場合 : ± 3.0 mm 以内
9. 原稿マットを取り外し、2 ページの手順 8, 9 を参考に再度取り付け。



[Checking the magnification]

1. Check the gap between line (1) of original (a) and line (2) of copy example. If the gap exceeds the reference value, adjust the gap according to the following procedure.
<Reference value> within $\pm 1.5\%$

2. Use the maintenance mode U070 to adjust the magnification.
Sub Scan(F): (single copying) Adjusts the scanner sub-scan magnification (front side)
Sub Scan(B): (duplex copying) Adjusts the scanner sub-scan magnification (back side)
Duplex 1side: Front side adjustment for the duplex scanning

[Vérification de l'agrandissement]

1. Vérifier l'écart entre la ligne (1) de l'original (a) et la ligne (2) de l'exemple de copie. Si l'écart excède la valeur de référence, le régler selon la procédure suivante.
<Valeur de référence> $\pm 1,5\%$ max

2. Pour régler l'agrandissement, utilisez le mode entretien U070.
Sub Scan(F): (copie recto) Permet de régler l'agrandissement du balayage secondaire du scanner (recto)
Sub Scan(B): (copie recto-verso) Permet de régler l'agrandissement du balayage secondaire du scanner (verso)
Duplex 1side: Réglage du recto pour la numérisation recto verso

[Verificación del cambio de tamaño]

1. Compruebe la separación entre la línea (1) del original (a) y la línea (2) del ejemplo de copia. Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.
<Valor de referencia> dentro de $\pm 1,5\%$

2. Para ajustar la ampliación utilice el modo de mantenimiento U070.
Sub Scan(F): (copiado por una cara) Ajusta el cambio de tamaño de la dirección de exploración secundaria del escáner (anverso)
Sub Scan(B): (copiado dúplex) Ajusta el cambio de tamaño de la dirección de exploración secundaria del escáner (reverso)
Duplex 1side: Ajuste del anverso para el escaneado dúplex

[Überprüfen der Vergrößerung]

1. Den Abstand zwischen der Linie (1) des Originals (a) und der Linie (2) des Kopierbeispiels prüfen. Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.
<Bezugswert> Innerhalb $\pm 1,5\%$

2. Zum Einstellen der Vergrößerung den Wartungsmodus U070 verwenden.
Sub Scan(F): (Einzelkopie) Zur Einstellung der Subscan-Vergrößerung (Vorderseite)
Sub Scan(B): (Duplexkopie) Zur Einstellung der Subscan-Vergrößerung (Rückseite)
Duplex 1side: Einstellung der Vorderseite für Duplex-Scan

[Controllo dell'ingrandimento]

1. Verificare lo scostamento fra la linea (1) dell'originale (a) e la linea (2) dell'esempio di copia. Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.
<Valore di riferimento> Entro $\pm 1,5\%$

2. Usare la modalità di manutenzione U070 per regolare l'ingrandimento.
Sub Scan(F): (copia singola) Regola l'ingrandimento della scansione ausiliare dello scanner (facciata anteriore)
Sub Scan(B): (copia duplex) Regola l'ingrandimento della scansione ausiliare dello scanner (retro)
Duplex 1side: Regolazione della facciata anteriore per la scansione fronte-retro

[确认等倍值]

1. 确认原稿 (a) 上的线 (1) 和复印样本上的线 (2) 之间的偏移值。如果偏移值超过标准值, 则按照下列步骤进行调整。
<标准值> $\pm 1.5\%$ 以内

2. 使用维修模式 U070 调整等倍值。
Sub Scan(F): (单面复印) 读取副扫描等倍度的调整 (正面)
Sub Scan(B): (双面复印) 读取副扫描等倍度的调整 (反面)
Duplex 1side: 双面扫描的正面调整

[등배도확인]


1. 원고 (a) 선 (1) 과 샘플 카피의 선 (2) 의 차이를 확인합니다. 차이가 기준이외의 경우, 다음 순서로 조절을 합니다.
<기준치> $\pm 1.5\%$ 이내

2. 메인テナンス 모드 U070 에서 조정합니다.
Sub Scan(F): (단면복사) 스캔 부주사등배도의 조정 (앞면)
Sub Scan(B): (양면복사) 스캔 부주사등배도의 조정 (뒷면)
Duplex 1side: 양면 스캔의 앞면 조정

[等倍度確認]

1. 原稿 (a) の線 (1) とコピーサンプルの線 (2) のずれを確認する。ずれが基準値外の場合、次の手順で調整を行う。
<基準値> $\pm 1.5\%$ 以内

2. メンテナンスモード U070 をセットし、調整を行う。
Sub Scan(F): (片面コピー) 読み込み副走査等倍度の調整 (表面)
Sub Scan(B): (両面コピー) 読み込み副走査等倍度の調整 (裏面)
Duplex 1side: 両面読み込みの表面調整



3. Adjust the values.

For the shorter length copy example (f): Increases the value.
For the longer length copy example (g): Decreases the value.
Amount of change per step: 0.10 %

4. Press the [Start] key to confirm the setting value.

5. Perform a test copy.

6. Repeat the steps 2 to 5 above until the gap of line (2) of copy example shows the reference value.

<Reference value> within ±1.5%

3. Régler les valeurs.

Pour l'exemple de copie dont la longueur est plus courte (f) : augmenter la valeur.
Pour l'exemple de copie dont la longueur est plus longue (g) : diminuer la valeur.
Changement par graduation d'échelle : 0,10 %

4. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.

5. Effectuer une copie de test.

6. Répéter les étapes 2 à 5 jusqu'à ce que l'écart de la ligne (2) de l'exemple de copie indique la valeur de référence.

<Valeur de référence> ±1,5% max

3. Ajuste los valores.

Para el ejemplo de copia más corto (f): aumenta el valor.
Para el ejemplo de copia más largo (g): disminuye el valor.
Magnitud del cambio por incremento: 0,10 %

4. Pulse la tecla de [Inicio] para confirmar el valor de configuración.

5. Haga una copia de prueba.

6. Repita los pasos 2 a 5 anteriores hasta que la separación de la línea (2) del ejemplo de copia presente el valor de referencia.

<Valor de referencia> dentro de ±1,5%

3. Die Werte einstellen.

Für die kürzere Länge des Kopierbeispiels (f): Den Wert erhöhen.
Für die längere Länge des Kopierbeispiels (g): Den Wert verringern.
Änderung pro Schritt: 0,10 %

4. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.

5. Eine Testkopie erstellen.

6. Die Schritte 2 bis 5 wiederholen, bis der Abstand der Linie (2) des Kopierbeispiels den Bezugswert aufweist.

<Bezugswert> Innerhalb ±1,5%

3. Regolare i valori.

Per l'esempio di copia di lunghezza inferiore (f): aumenta il valore.
Per l'esempio di copia di lunghezza superiore (g): riduce il valore.
Entità modifica per passo: 0,10 %

4. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.

5. Eseguire una copia di prova.

6. Ripetere le operazioni sopra descritte da 2 a 5 fino a quando lo scostamento della linea (2) dell'esempio di copia riporterà i valori di riferimento.

<Valore di riferimento> Entro ±1,5%

3. 調整設定値。

在长度偏短时 复印样本 (f) : 调高设定值
在长度偏长时 复印样本 (g) : 调低设定值
设定值的一个调整单位变化量 : 0.10%

4. 按 [开始] 键, 以确定设定值。

5. 进行测试复印。

6. 重复上述步骤 2 到 5, 直至复印样本上的线 (2) 之间的偏移值达到标准值范围内。

<标准值> ±1.5% 以内

3. 설정치를 조정합니다 .

길이가 짧은 경우 샘플 카피 (f) : 설정치를 높입니다 .
길이가 긴 경우 샘플 카피 (g) : 설정치를 내립니다 .
1 스텝당 변화량 : 0.10%

4. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .

5. 테스트 카피를 합니다 .

6. 샘플 카피 선 (2) 의 차이가 기준치내가 될 때까지 2 ~ 5 를 반복합니다 .

<기준치> ±1.5% 이내

3. 設定値を調整する。


長さが短い場合コピーサンプル (f) : 設定値を上げる。
長さが長い場合コピーサンプル (g) : 設定値を下げる。
1 ステップ当たりの変化量 : 0.10%

4. [スタート] キーを押し、設定値を確定する。

5. テストコピーを行う。

6. コピーサンプルの線 (2) のずれが基準値内になるまで手順 2 ~ 5 を繰り返す。

<基準値> ±1.5% 以内



[Checking the leading edge timing]

1. Check the gap between line (1) on original (a) and line (2) of copy example. If the gap exceeds the reference value, adjust the gap according to the following procedure.
<Reference value> within ± 2.5 mm

2. Use the maintenance mode U071 to adjust the timing.
Front Head: Adjusts the leading edge timing (front side)
Front Tail: Adjusts the trailing edge timing (front side)
Back Head: Adjusts the leading edge timing (back side)
Back Tail: Adjusts the trailing edge timing (back side)

[Vérification de la synchronisation du bord avant]

1. Vérifier l'écart entre la ligne (1) de l'original (a) et la ligne (2) de l'exemple de copie. Si l'écart excède la valeur de référence, le régler selon la procédure suivante.
<Valeur de référence> $\pm 2,5$ mm max

2. Pour régler la synchronisation, utilisez le mode entretien U071.
Front Head: Permet de régler la synchronisation du bord de tête (recto)
Front Tail: Permet de régler la synchronisation du bord arrière (recto)
Back Head: Permet de régler la synchronisation du bord de tête (verso)
Back Tail: Permet de régler la synchronisation du bord arrière (verso)

[Cambio de la sincronización de borde superior]

1. Compruebe la separación entre la línea (1) del original (a) y la línea (2) del ejemplo de copia. Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.
<Valor de referencia> dentro de $\pm 2,5$ mm

2. Para ajustar la sincronización utilice el modo de mantenimiento U071.
Front Head: Ajusta la sincronización del borde superior (anverso).
Front Tail: Ajusta la sincronización del borde inferior (anverso).
Back Head: Ajusta la sincronización del borde superior (reverso).
Back Tail: Ajusta la sincronización del borde inferior (reverso).

[Überprüfen des Vorderkanten-Timings]

1. Den Abstand zwischen der Linie (1) des Originals (a) und der Linie (2) des Kopierbeispiels prüfen. Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.
<Bezugswert> Innerhalb $\pm 2,5$ mm

2. Zum Einstellen des Timing den Wartungsmodus U071 verwenden.
Front Head: Zur Einstellung des Vorderkanten-Timing (Vorderseite)
Front Tail: Zur Einstellung des Hinterkanten-Timing (Vorderseite)
Back Head: Zur Einstellung des Vorderkanten-Timing (Rückseite)
Back Tail: Zur Einstellung des Hinterkanten-Timing (Rückseite)

[Controllo della sincronizzazione del bordo principale]

1. Verificare lo scostamento fra la linea (1) sull'originale (a) e la linea (2) dell'esempio di copia. Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.
<Valore di riferimento> Entro $\pm 2,5$ mm

2. Usare la modalità di manutenzione U071 per regolare la sincronizzazione.
Front Head: Regola la sincronizzazione del bordo principale (facciata anteriore)
Front Tail: Regola la sincronizzazione del bordo di uscita (facciata anteriore)
Back Head: Regola la sincronizzazione del bordo principale (retro)
Back Tail: Regola la sincronizzazione del bordo di uscita (retro)

[确认前端定时调整]

1. 确认原稿 (a) 上的线 (1) 和复印样本上的线 (2) 之间的偏移值。如果偏移值超过标准值，则按照下列步骤进行调整。
<标准值> ± 2.5 mm 以内

2. 使用维修模式 U071 调整定时。
Front Head : 调整前端定时 (正面)
Front Tail : 调整后端定时 (正面)
Back Head : 调整前端定时 (反面)
Back Tail : 调整后端定时 (反面)

[선단 타이밍 확인]


1. 원고 (a) 선 (1) 과 샘플 카피 선 (2) 의 차이를 확인합니다 . 차이가 기준치 외의 경우 다음 순서로 조정을 합니다 .
< 기준치 > ± 2.5 mm 이내

2. 메인テナンス 모드 U071 에서 조정합니다 .
Front Head : 선단 타이밍 (앞면) 을 조정합니다 .
Front Tail : 후단 타이밍 (앞면) 을 조정합니다 .
Back Head : 선단 타이밍 (뒷면) 을 조정합니다 .
Back Tail : 후단 타이밍 (뒷면) 을 조정합니다 .

[先端タイミング確認]

1. 原稿 (a) の線 (1) とコピーサンプルの線 (2) のずれを確認する。ずれが基準値外の場合、次の手順で調整を行う。
<基準値> ± 2.5 mm 以内

2. メンテナンスモード U071 をセットし、調整を行う。
Front Head : 先端タイミング (表面) の調整
Front Tail : 後端タイミング (表面) の調整
Back Head : 先端タイミング (裏面) の調整
Back Tail : 後端タイミング (裏面) の調整



3. Adjust the values.

For the faster leading edge timing, copy examples (h): Decreases the value.

For the slower leading edge timing, copy examples (i): Increases the value.

Amount of change per step: 0.25 mm

4. Press the [Start] key to confirm the setting value.

5. Perform a test copy.

6. Repeat the steps 2 to 5 above until the gap of line (2) of copy example shows the reference value.

<Reference value> within ± 2.5 mm

3. Régler les valeurs.

Pour les exemples de copie dont la synchronisation du bord avant est plus rapide (h) : diminuer la valeur.

Pour les exemples de copie dont la synchronisation du bord avant est plus lente (i) : augmenter la valeur.

Changement par graduation d'échelle : 0,25 mm

4. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.

5. Effectuer une copie de test.

6. Répéter les étapes 2 à 5 jusqu'à ce que l'écart de la ligne (2) de l'exemple de copie indique la valeur de référence.

<Valeur de référence> $\pm 2,5$ mm max

3. Ajuste los valores.

Para una sincronización más rápida de extremo guía, ejemplos de copia (h): disminuye el valor.

Para una sincronización más lenta de extremo guía, ejemplos de copia (i): aumenta el valor.

Magnitud del cambio por incremento: 0,25 mm

4. Pulse la tecla de [Inicio] para confirmar el valor de configuración.

5. Haga una copia de prueba.

6. Repita los pasos 2 a 5 anteriores hasta que la separación de la línea (2) del ejemplo de copia presente el valor de referencia.

<Valor de referencia> dentro de $\pm 2,5$ mm

3. Die Werte einstellen.

Für den schnelleren Vorderkantentakt, Kopierbeispiel (h): Den Wert verringern.

Für den langsameren Vorderkantentakt, Kopierbeispiel (i): Den Wert erhöhen.

Änderung pro Schritt: 0,25 mm

4. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.

5. Eine Testkopie erstellen.

6. Die Schritte 2 bis 5 wiederholen, bis der Abstand der Linie (2) des Kopierbeispiels den Bezugswert aufweist.

<Bezugswert> Innerhalb $\pm 2,5$ mm

3. Regolare i valori.

Per accelerare la fasatura del bordo di entrata, esempi di copia (h): riduce il valore.

Per rallentare la fasatura del bordo di entrata, esempi di copia (i): aumenta il valore.

Entità modifica per passo: 0,25 mm

4. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.

5. Eseguire una copia di prova.

6. Ripetere le operazioni sopra descritte da 2 a 5 fino a quando lo scostamento della linea (2) dell'esempio di copia riporterà i valori di riferimento.

<Valore di riferimento> Entro $\pm 2,5$ mm

3. 調整設定値。

在前端定时偏快时 复印样本 (h) : 调低设定值

在前端定时偏慢时 复印样本 (i) : 调高设定值

设定值的一个调整单位变化量 : 0.25mm

4. 按 [开始] 键, 以确定设定值。

5. 进行测试复印。

6. 重复上述步骤 2 到 5, 直至复印样本上的线 (2) 的偏移值达到标准值范围内。

< 标准值 > ± 2.5 mm 以内

3. 설정치를 조정합니다.

선단 타이밍이 빠른 경우 샘플 카피 (h): 설정치를 내립니다.

선단 타이밍이 늦은 경우 샘플 카피 (i): 설정치를 올립니다.

1 스텝당 변화량: 0.25mm

4. [복사 / 시작] 키를 누르고 설정치를 확인합니다.

5. 테스트 카피를 합니다.

6. 샘플 카피 선 (2) 의 차이가 기준치내가 될 때까지 2 ~ 5 를 반복합니다.

< 기준치 > ± 2.5 mm 이내

3. 設定値を調整する。

先端タイミングが早い場合コピーサンプル (h): 設定値を下げる。

先端タイミングが遅い場合コピーサンプル (i): 設定値を上げる。


1 ステップ当たりの変化量: 0.25mm

4. [スタート] キーを押し、設定値を確定する。

5. テストコピーを行う。

6. コピーサンプルの線 (2) のずれが基準値内になるまで手順 2 ~ 5 を繰り返す。

< 基準値 > ± 2.5 mm 以内



[Checking the center line]

1. Check the gap between center line (1) on original (a) and center line (2) of copy example. If the gap exceeds the reference value, adjust the gap according to the following procedure.

<Reference value>

Horizontal difference of center line (2) for the single copying: ± 2.0 mm
Horizontal difference of center line (2) for the duplex copying: ± 3.0 mm

2. Use the maintenance mode U072 to adjust the timing.

Front: Adjusts the center line (front side)
Back: Adjusts the center line (back side)

[Vérification de la ligne médiane]

1. Vérifier l'écart entre l'axe (1) de l'original (a) et l'axe (2) de l'exemple de copie. Si l'écart excède la valeur de référence, le régler selon la procédure suivante.

<Valeur de référence>

Différence horizontale de l'axe (2) pour la copie recto : $\pm 2,0$ mm
Différence horizontale de l'axe (2) pour la copie recto-verso : $\pm 3,0$ mm

2. Pour régler la ligne médiane, utiliser le mode entretien U072.

Front: Permet de régler l'axe (recto)
Back: Permet de régler l'axe (verso)

[Verificación de la línea central]

1. Compruebe la separación entre la línea de centro (1) del original (a) y la línea de centro (2) del ejemplo de copia. Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.

<Valor de referencia>

Diferencia horizontal de la línea de centro (2) para el copiado por una cara: $\pm 2,0$ mm

Diferencia horizontal de la línea de centro (2) para el copiado dúplex: $\pm 3,0$ mm

2. Para ajustar la línea central utilice el modo de mantenimiento U072.

Front: ajusta la línea central (anverso).
Back: ajusta la línea central (reverso).

[Überprüfen der Mittellinie]

1. Den Abstand zwischen der Mittellinie (1) des Originals (a) und der Mittellinie (2) des Kopierbeispiels prüfen. Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.

<Bezugswert>

Horizontaler Unterschied der Mittellinie (2) für die Einzelkopie: $\pm 2,0$ mm
Horizontaler Unterschied der Mittellinie (2) für die Duplexkopie: $\pm 3,0$ mm

2. Zum Einstellen der Mittellinie den Wartungsmodus U072 verwenden.

Front: Zur Einstellung der Mittellinie (Vorderseite)
Back: Zur Einstellung der Mittellinie (Rückseite)

[Controllo della linea centrale]

1. Verificare lo scostamento fra la linea centrale (1) sull'originale (a) e la linea centrale (2) dell'esempio di copia. Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.

<Valore di riferimento>

Differenza orizzontale della linea centrale (2) per la copia singola: $\pm 2,0$ mm
Differenza orizzontale della linea centrale (2) per la copia duplex: $\pm 3,0$ mm

2. Usare la modalità di manutenzione U072 per regolare la linea centrale.

Front: Regola la linea centrale (facciata anteriore)
Back: Regola la linea centrale (retro)

[确认中心线]

1. 确认原稿 (a) 中心线 (1) 和复印样本中心线 (2) 之间的偏移值。如果偏移值超过标准值, 则按照下列步骤进行调整。

<标准值> 单面复印时, 中心线 (2) 的左右偏移值: ± 2.0 mm 以内
双面复印时, 中心线 (2) 的左右偏移值: ± 3.0 mm 以内

2. 使用维修模式 U072 调整中心线。

Front: 中心位置 (正面) 的调整
Back: 中心位置 (反面) 的调整

[센터 라인 확인]

1. 원고 (a) 센터라인 (1) 과 샘플 카피 센터라인 (2) 의 차이를 확인합니다 . 차이가 기준치 외의 경우 다음 순서로 조정합니다 .

<기준치> 단면의 경우 센터라인 (2) 의 좌우차이: ± 2.0 mm 이내
양면의 경우 센터라인 (2) 의 좌우차이: ± 3.0 mm 이내

2. 메인テナンス 모드 U072 에서 조정합니다 .

Front: 센터 위치 (앞면) 의 조정
Back: 센터 위치 (뒷면) 의 조정


[センターライン確認]

1. 原稿 (a) の中心線 (1) とコピーサンプルの中心線 (2) のずれを確認する。ずれが基準値外の場合、次の手順で調整を行う。

<基準値> 片面の場合、中心線 (2) の左右ずれ: ± 2.0 mm 以内
両面の場合、中心線 (2) の左右ずれ: ± 3.0 mm 以内

2. メンテナンスモード U072 をセットし、調整を行う。

Front: センター位置 (表面) の調整
Back: センター位置 (裏面) の調整



3. Adjust the values.

If the center moves more front, copy example (j): Increases the value.

If the center moves inner, copy sample (k): Decreases the value.

Amount of change per step: 0.085 mm

4. Press the [Start] key to confirm the setting value.

5. Perform a test copy.

6. Repeat the steps 2 to 5 above until the gap of line (2) of copy example shows the reference value.

<Reference value>

Horizontal difference of center line (2) for the single copying: ± 2.0 mm

Horizontal difference of center line (2) for the duplex copying: ± 3.0 mm

3. Régler les valeurs.

Pour l'exemple de copie (j) dont l'axe se déplace davantage vers l'avant : augmenter la valeur.

Pour l'exemple de copie (k) dont l'axe se déplace vers l'intérieur : diminuer la valeur.

Changement par graduation d'échelle : 0,085 mm

4. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.

5. Effectuer une copie de test.

6. Répéter les étapes 2 à 5 jusqu'à ce que l'écart de la ligne (2) de l'exemple de copie indique la valeur de référence.

<Valeur de référence>

Différence horizontale de l'axe (2) pour la copie recto : $\pm 2,0$ mm

Différence horizontale de l'axe (2) pour la copie recto-verso : $\pm 3,0$ mm

3. Ajuste los valores.

Si el centro se desplaza más hacia el frente, ejemplo de copia (j): aumenta el valor.

Si el centro se desplaza hacia dentro, ejemplo de copia (k): disminuye el valor.

Magnitud del cambio por incremento: 0,085 mm

4. Pulse la tecla de [Inicio] para confirmar el valor de configuración.

5. Haga una copia de prueba.

6. Repita los pasos 2 a 5 anteriores hasta que la separación de la línea (2) del ejemplo de copia presente el valor de referencia.

<Valor de referencia>

Diferencia horizontal de la línea de centro (2) para el copiado por una cara: $\pm 2,0$ mm

Diferencia horizontal de la línea de centro (2) para el copiado dúplex: $\pm 3,0$ mm

3. Die Werte einstellen.

Wenn die Mitte nach vorne verlagert ist, Kopierbeispiel (j): Den Wert erhöhen.

Wenn die Mitte nach innen verlagert ist, Kopierbeispiel (k): Den Wert verringern.

Änderung pro Schritt: 0,085 mm

4. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.

5. Eine Testkopie erstellen.

6. Die Schritte 2 bis 5 wiederholen, bis der Abstand der Linie (2) des Kopierbeispiels den Bezugswert aufweist.

<Bezugswert>

Horizontaler Unterschied der Mittellinie (2) für die Einzelkopie: $\pm 2,0$ mm

Horizontaler Unterschied der Mittellinie (2) für die Duplexkopie: $\pm 3,0$ mm

3. Regolare i valori.

Se il centro si sposta più avanti, esempio di copia (j): aumenta il valore.

Se il centro si sposta verso l'interno, esempio di copia (k): riduce il valore.

Entità modifica per passo: 0,085 mm

4. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.

5. Eseguire una copia di prova.

6. Ripetere le operazioni sopra descritte da 2 a 5 fino a quando lo scostamento della linea (2) dell'esempio di copia riporterà i valori di riferimento.

<Valore di riferimento>

Differenza orizzontale della linea centrale (2) per la copia singola: $\pm 2,0$ mm

Differenza orizzontale della linea centrale (2) per la copia duplex: $\pm 3,0$ mm

3. 調整設定値。

当中心向前偏移时 复印样本 (j) : 调高设定值

当中心向内偏移时 复印样本 (k) : 调低设定值

设定值的一个调整单位变化量: 0.085mm

4. 按 [开始] 键, 以确定设定值。

5. 进行测试复印。

6. 重复上述步骤 2 到 5, 直至复印样本上的线 (2) 的偏移值达到标准值范围内。

<标准值>

单面复印时, 中心线 (2) 的左右偏移值: ± 2.0 mm 以内

双面复印时, 中心线 (2) 的左右偏移值: ± 3.0 mm 以内

3. 설정치를 조정합니다 .

센터가 앞으로 이동한 경우가 샘플 카피 (j): 설정치를 높입니다 .

센터가 뒤로 이동한 경우 샘플 카피 (k) : 설정치를 내립니다 .

1 스텝당 변화량 : 0.085mm

4. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .

5. 테스트 카피를 합니다 .

6. 샘플 카피 선 (2) 차이가 기준치 내가 될 때까지 순서 2 ~ 5 를 반복합니다 .

< 기준치 >

단면의 경우 센터라인 (2) 의 좌우차이 : ± 2.0 mm 이내

양면의 경우 센터라인 (2) 의 좌우차이 : ± 3.0 mm 이내

3. 設定値を調整する。

センターが手前にずれている場合コピーサンプル (j) : 設定値を上げる。

センターが奥にずれている場合コピーサンプル (k) 設定値を下げる。

1 ステップ当たりの変化量: 0.085mm

4. [スタート] キーを押し、設定値を確定する。


5. テストコピーを行う。

6. コピーサンプルの線 (2) ずれが基準値内になるまで手順 2 ~ 5 を繰り返す。

<基準値>

片面の場合、中心線 (2) の左右ずれ: ± 2.0 mm 以内

両面の場合、中心線 (2) の左右ずれ: ± 3.0 mm 以内



**[Automatic adjustment using the original for adjustment]
If there is no DP auto adjustment original.**

1. Set the maintenance mode U411 and press [DP Auto Adj] to output the adjustment original.
2. Set the printed original on the contact glass and press the [Start] key.
3. Set the original on the DP face up and press the [Start] key to carry out surface adjustment.

4. "OK" appears on the display and press the [Start] key to complete the adjustment.

* If ERROR XX appears, the adjustment failed. Check the original set position and repeat steps 2 and 3 until "OK" appears.
For details, see the service manual.

**[Réglage automatique en utilisant l'original pour effectuer le réglage]
Si la machine n'est pas pourvue de la fonction réglage automatique d'original du DP**

1. Passez en mode maintenance U411 et appuyez sur [DP Auto Adj] pour imprimer l'original de réglage.
2. Placer l'original qui vient d'être imprimé sur la vitre d'exposition et appuyer sur la touche [Départ].
3. Placer l'original sur le DP côté imprimé en haut et appuyer sur la touche [Départ] pour procéder au réglage de la surface.

4. "OK" s'affiche sur l'écran. Appuyez sur la touche [Départ] pour terminer le réglage.

* Si le message ERROR XX (erreur XX) s'affiche, le réglage a échoué. Vérifier la position de l'original et recommencer les opérations 2 et 3 jusqu'à ce que le message "OK" apparaisse.
Pour plus de détails, se reporter au manuel d'entretien.

**[Ajuste automático utilizando el original para el ajuste]
Si no existe el original de ajuste automático del DP**

1. Configure el modo de mantenimiento U411 y pulse [DP Auto Adj] para imprimir el original de ajuste.
2. Coloque el original impreso sobre el cristal de contacto y pulse la tecla de [Inicio].
3. Coloque el original en el DP cara arriba y pulse la tecla de [Inicio] para realizar un ajuste de anverso.

4. Aparece "OK" en la pantalla. Pulse la tecla [Inicio] para finalizar el ajuste.

* Si aparece ERROR XX, el ajuste ha fallado. Compruebe la posición ajustada del original y repita los pasos 2 y 3 hasta que aparezca "OK" en la pantalla.
Para más detalles, lea el manual de servicio.

[Automatische Einstellung mithilfe des Originals]

Falls keine automatische Einstellung des Originals des DP vorhanden ist

1. Aktivieren Sie den Wartungsmodus U411 und wählen Sie [DP Auto Adj], um das Original für die Anpassung auszudrucken.
2. Das ausgedruckte Original auf das Kontaktglas legen und die [Start]-Taste betätigen.
3. Das Original mit der Druckseite nach oben einlegen und die [Start]-Taste betätigen, um die Oberflächeneinstellung ausführen zu lassen.

4. "OK" erscheint auf der Anzeige. Drücken Sie die Taste [Start], um die Einstellung abzuschließen.

* Wenn ERROR XX (FEHLER XX) angezeigt wird, ist die Einstellung fehlgeschlagen. Überprüfen Sie die Originalpositionierung und wiederholen Sie Schritte 2 und 3, bis "OK" angezeigt wird.
Weitere Einzelheiten siehe Wartungsanleitung.

[Regolazione automatica eseguita con l'originale]

Se non è presente l'autoregolazione originale DP

1. Impostare la modalità manutenzione U411, quindi premere [DP Auto Adj] per stampare l'originale da utilizzare per la regolazione.
2. Posizionare l'originale stampato sul vetro di appoggio e premere il tasto di [Avvio].
3. Posizionare l'originale sul DP rivolto verso l'alto e premere il tasto di [Avvio] per eseguire la regolazione della superficie.

4. Quando sul display compare "OK", premere il tasto [Avvio] per completare la regolazione.

* Se compare ERROR XX (ERRORE XX), la regolazione non è riuscita. Verificare la posizione di impostazione dell'originale e ripetere le operazioni 2 e 3 fino a quando appare "OK".
Per ulteriori dettagli leggere il manuale d'istruzioni.

[通过调整用原稿进行自动调整]

没有 DP 调整用原稿时

1. 进入维修保养模式 U411, 选择 [DP Auto Adj], 输出测试原稿。
2. 将输出的原稿放在稿台上, 按 [开始] 键。
3. 将原稿面朝上放在 DP 主机上, 按 [开始] 键以进行正面的调整。

4. 显示屏上显示 "OK", 按 [开始] 键后, 调整结束。

* 如果出现 ERROR XX (错误 XX), 则表示调整失败。检查原稿设定位置并重复步骤 2 和 3, 直到 "OK" (完成) 出现。
详细内容请参照维修手册。

[조정용 원고를 이용한 자동조정]

DP 조정용 원고가 없는 경우

1. 메인テナンス 모드 U411 을 설정하고 [DP Auto Adj] 를 눌러 조정된 원고를 출력합니다 .
2. 출력한 원고를 원고 유리에 장착하고 [복사 / 시작] 키를 누릅니다 .
3. 원고를 FaceUp 으로 DP 에 세트하고 [복사 / 시작] 키를 눌러 표면조정을 합니다 .

4. 디스플레이에 "OK" 가 나타나면 [복사 / 시작] 키를 눌러 조정을 완료합니다 .

* ERROR XX 가 표시된 경우에는 조정실패입니다 . 원고 장착위치를 확인하고 "OK" 가 표시될 때까지 순서 2 ~ 3 를 반복합니다 .
상세는 서비스 매뉴얼을 참조 .


[調整用原稿による自動調整]

DP 調整用原稿が無い場合

1. メンテナンスモード U411 をセットし、[DP Auto Adj] を押し原稿を出力する。
2. 出力した原稿をコンタクトガラス上にセットし、[スタート] キーを押す。
3. 原稿を FaceUp で DP へセットし、[スタート] キーを押し、表面の調整を行う。

4. ディスプレイに「OK」が表示され、[スタート] キーを押せば調整完了となる。

※ERROR XX が表示された場合は調整失敗である。原稿のセット位置を確認し、「OK」が表示されるまで手順 2 ~ 3 を繰り返す。
詳細はサービスマニュアルを参照のこと。



Using a DP auto adjustment original

1. Place the front side of the DP auto adjustment original so that the arrow mark appears facing up. Set it on the DP so the leading edge of the arrow mark is facing the DP feed direction.
2. Set the maintenance mode U411 and press [DP FU(CharTB)] > the [Start] key in that order to carry out the front side adjustment.

3. If "OK" appears on the display, the adjustment is complete.

* If ERROR XX appears, the adjustment failed. Check the original set position and repeat steps 1 and 2 until "OK" appears. For details, see the service manual.

Avec la fonction réglage automatique d'original du DP

1. Placez le recto de l'original de réglage du chargeur de document de sorte que la flèche apparaisse sur la face vers le haut. Placez-le sur le chargeur de document de sorte que le bord de tête de la flèche soit orienté dans la direction d'alimentation du chargeur de document.
2. Passez en mode maintenance U411 et appuyez sur [DP FU(CharTB)] > touche [Départ] dans cet ordre pour effectuer le réglage du recto.

3. Si "OK" s'affiche sur l'écran, le réglage est terminé.

* Si le message ERROR XX (erreur XX) s'affiche, le réglage a échoué. Vérifier la position de l'original et recommencer les opérations 1 et 2 jusqu'à ce que le message "OK" apparaisse. Pour plus de détails, se reporter au manuel d'entretien.

Uso del original de ajuste automático del DP

1. Coloque el anverso del original de ajuste automático del alimentador de originales DP de modo que la marca de flecha esté hacia arriba. Colóquelo en el DP de modo que el borde anterior de la marca de flecha esté en la dirección de alimentación del DP.
2. Configure el modo de mantenimiento U411 y pulse [DP FU(CharTB)] > tecla [Inicio] en ese orden para llevar a cabo un ajuste del anverso.

3. Si aparece "OK" en la pantalla, el ajuste se ha completado.

* Si aparece ERROR XX, el ajuste ha fallado. Compruebe la posición ajustada del original y repita los pasos 1 y 2 hasta que aparezca "OK" en la pantalla. Para más detalles, lea el manual de servicio.

Gebrauch der automatischen Einstellung des Originals des DP

1. Legen Sie die Vorderseite des Originals für die automatische Einstellung des Vorlageneinzugs so ein, dass der Pfeil nach oben weist. Legen Sie das Original so in den Vorlageneinzug, dass die Pfeilspitze in die Einzugsrichtung des Vorlageneinzugs weist.
2. Aktivieren Sie den Wartungsmodus U411 und wählen Sie nacheinander [DP FU(CharTB)] > Taste [Start], um die Einstellungen für die Vorderseite vorzunehmen.

3. Wenn "OK" angezeigt wird, ist die Einstellung abgeschlossen.

* Wenn ERROR XX (FEHLER XX) angezeigt wird, ist die Einstellung fehlgeschlagen. Überprüfen Sie die Originalpositionierung und wiederholen Sie Schritte 1 und 2, bis "OK" angezeigt wird. Weitere Einzelheiten siehe Wartungsanleitung.

Uso di un'autoregolazione originale DP

1. Posizionare la facciata anteriore dell'originale da utilizzare per la regolazione automatica dell'alimentatore documenti in modo che la freccia sia rivolta verso l'alto. Posizionarlo sull'alimentatore di documenti in modo che il bordo superiore della freccia sia orientato nella direzione di alimentazione dell'alimentatore di documenti.
2. Impostare la modalità manutenzione U411, quindi premere, nell'ordine, [DP FU(CharTB)] > tasto [Avvio] per eseguire la regolazione della facciata anteriore.

3. Se sul display compare "OK", la regolazione è completata.

* Se compare ERROR XX (ERRORE XX), la regolazione non è riuscita. Verificare la posizione di impostazione dell'originale e ripetere le operazioni 1 e 2 fino a quando appare "OK". Per ulteriori dettagli leggere il manuale d'istruzioni.

使用 DP 自动调整用稿时

1. 把 DP 自动调整原稿的正面（有箭头的一面）向上，同时使箭头的前端方向对准 DP 的走纸方向。
2. 进入维修保养模式 U411，按照 [DP FU(CharTB)] > [开始] 键的顺序按，开始正面调整。

3. 如果显示屏显示 "OK"，则表示调整结束。

* 如果出现 ERROR XX（错误 XX），则表示调整失败。检查原稿设定位置并重复步骤 1 和 2，直到 "OK"（完成）出现。详细内容请参照维修手册。

DP 자동조정용 원고를 사용하는 경우

1. DP 자동 조정원고의 앞면의 화살표가 위로 향하게 세트합니다. 화살표의 선단을 DP 피드방향으로 DP 에 세트합니다.
2. 메인テナンス 모드 U411 을 설정하고 [DP FU(CharTB)] > [복사 / 시작] 키를 눌러 앞면 조정을 수행합니다.

3. 디스플레이에 "OK" 가 표시되면 조정완료가 됩니다.


* ERROR XX 가 표시된 경우에는 조정실패입니다. 원고 장착위치를 확인하고 "OK" 가 표시될 때까지 순서 1 ~ 2 를 반복합니다. 상세는 서비스 매뉴얼을 참조.

DP 自動調整原稿を使用する場合

1. DP 自動調整原稿の表面（矢印が書かれてる面）を上に向け、矢印の先端方向から DP にセットする。
2. メンテナンスモード U411 をセットし、[DP FU(CharTB)] > [スタート] キーの順に押し、表面の調整を行う。

3. ディスプレイに「OK」が表示されれば調整完了となる。

※ERROR XX が表示された場合は調整失敗である。原稿のセット位置を確認し、「OK」が表示されるまで手順 1 ~ 2 を繰り返す。詳細はサービスマニュアルを参照のこと。



4. After completing the adjustment of the front side, place the back side of the DP auto adjustment original so that the arrow mark appears facing down. Set it on the DP so the trailing edge of the arrow mark is facing the DP feed direction.
5. Set the maintenance mode U411 and press [DP FD(CharB)] > the [Start] key in that order to carry out the back side adjustment.

6. If "OK" appears on the display, the adjustment is complete.
* If ERROR XX appears, the adjustment failed. Check the original set position and repeat steps 4 and 5 until "OK" appears.
For details, see the service manual.

4. Après avoir terminé le réglage du verso, placez le recto de l'original de réglage du chargeur de document de sorte que la flèche apparaisse sur la face vers le bas. Placez-le sur le chargeur de document de sorte que le bord de fin de la flèche soit orienté dans la direction d'alimentation du chargeur de document.
5. Passez en mode maintenance U411 et appuyez sur [DP FD(CharB)] > touche [Départ] dans cet ordre pour effectuer le réglage du verso.

6. Si "OK" s'affiche sur l'écran, le réglage est terminé.
* Si le message ERROR XX (erreur XX) s'affiche, le réglage a échoué. Vérifier la position de l'original et recommencer les opérations 4 et 5 jusqu'à ce que le message "OK" apparaisse.
Pour plus de détails, se reporter au manuel d'entretien.

4. Después de terminar el ajuste del anverso, coloque el reverso del original de ajuste automático del DP de modo que la marca de flecha esté hacia abajo. Colóquelo en el DP de modo que el borde posterior de la marca de flecha esté en la dirección de alimentación del DP.
5. Configure el modo de mantenimiento U411 y pulse [DP FD(CharB)] > tecla [Inicio] en ese orden para llevar a cabo un ajuste del reverso.

6. Si aparece "OK" en la pantalla, el ajuste se ha completado.
* Si aparece ERROR XX, el ajuste ha fallado. Compruebe la posición ajustada del original y repita los pasos 4 y 5 hasta que aparezca "OK" en la pantalla.
Para más detalles, lea el manual de servicio.

4. Nachdem Sie die Einstellung für die Vorderseite abgeschlossen haben, legen Sie die Rückseite des Originals für die automatische Einstellung des Vorlageneinzugs so ein, dass der Pfeil nach unten weist. Legen Sie das Original so in den Vorlageneinzug, dass das Pfeilende in die Einzugsrichtung des Vorlageneinzugs weist.
5. Aktivieren Sie den Wartungsmodus U411 und wählen Sie nacheinander [DP FD(CharB)] > Taste [Start], um die Einstellungen für die Rückseite vorzunehmen.

6. Wenn "OK" angezeigt wird, ist die Einstellung abgeschlossen.
* Wenn ERROR XX (FEHLER XX) angezeigt wird, ist die Einstellung fehlgeschlagen. Überprüfen Sie die Originalpositionierung und wiederholen Sie Schritte 4 und 5, bis "OK" angezeigt wird.
Weitere Einzelheiten siehe Wartungsanleitung.

4. Dopo aver completato la regolazione della facciata anteriore, posizionare il retro dell'originale da utilizzare per la regolazione automatica dell'alimentatore di documenti in modo che la freccia sia rivolta verso il basso. Posizionarlo sull'alimentatore di documenti in modo che il bordo inferiore della freccia sia orientato nella direzione di alimentazione dell'alimentatore di documenti.
5. Impostare la modalità manutenzione U411, quindi premere, nell'ordine, [DP FD(CharB)] > tasto [Avvio] per eseguire la regolazione del retro.

6. Se sul display compare "OK", la regolazione è completata.
* Se compare ERROR XX (ERRORE XX), la regolazione non è riuscita. Verificare la posizione di impostazione dell'originale e ripetere le operazioni 4 e 5 fino a quando appare "OK".
Per ulteriori dettagli leggere il manuale d'istruzioni.

4. 正面的調整结束后,把 DP 自动调整原稿的反面(有箭头的一面)向下,同时使箭头的后端方向(没有箭头的方向)对准 DP 的走纸方向。
5. 进入维修保养模式 U411,按照 [DP FD(CharB)] > [开始] 键的顺序按键,开始反面调整。

6. 如果显示屏显示 "OK",则表示调整结束。
* 如果出现 ERROR XX (错误 XX),则表示调整失败。检查原稿设定位置并重复步骤 4 和 5,直到 "OK" (完成)出现。
详细内容请参照维修手册。

4. 앞면 조정이 완료되면 화살표가 아래로 향하게 세트합니다. 화살표의 후단을 DP 피드방향으로 DP 에 세트합니다.
5. 메인テナンス 모드 U411 을 설정하고 [DP FD(CharB)] > [복사 / 시작] 키 를 눌러 뒷면 조정을 수행합니다.

6. 디스플레이에 "OK" 가 표시되면 조정완료가 됩니다.
* ERROR XX 가 표시된 경우에는 조정실패입니다. 원고 장착위치를 확인하고 "OK" 가 표시될 때까지 순서 4 ~ 5 를 반복합니다.
상세는 서비스 매뉴얼을 참조

4. 表面の調整完了後,DP 自動調整原稿の裏面(矢印が書かれている面)を下に向け、矢印の後端方向(切欠き部方向)から DP にセットする。
5. メンテナンスモード U411 をセットし、[DP FD(CharB)] > [スタート] キーの順に押し、裏面の調整を行う。

6. ディスプレイに「OK」が表示されれば調整完了となる。
※ERROR XX が表示された場合は調整失敗である。原稿のセット位置を確認し、OK が表示されるまで手順 4 ~ 5 を繰り返す。
詳細はサービスマニュアルを参照のこと。

DP-5110

(Document processor: CIS)

Installation Guide

INSTALLATION GUIDE

GUIDE D'INSTALLATION

GUÍA DE INSTALACION

INSTALLATIONSANLEITUNG


GUIDA ALL'INSTALLAZIONE


安装手册

설치안내서


設置手順書

DP-5110







①




②




③




④











⑤




⑥







14




15




16



17





English

[Operation check]

- 1.To check the machine operation, prepare original (a) where 4 lines (b) are drawn 20 mm from the edges of the A4 sheet and 1 line (c) is drawn at its center.
- 2.Connect the power plug of the MFP into the wall outlet and turn the main power switch on.
- 3.Set the original (a) on the DP and perform a test copy to check the operation and the copy example.

Français

[Vérification du fonctionnement]

- 1.Pour vérifier le bon fonctionnement de l'appareil, préparer un original (a) sur lequel sont tracées 4 lignes (b) à 20 mm des bords de la feuille A4 et 1 ligne (c) en son axe.
- 2.Brancher la fiche d'alimentation du MFP sur la prise murale et mettre l'appareil sous tension.
- 3.Placer l'original (a) sur le DP et effectuer une copie de test pour vérifier le fonctionnement et l'exemple de copie.

Español

[Verifique el funcionamiento]

- 1.Para comprobar el funcionamiento del aparato, prepare un original (a) que contenga 4 líneas (b) dibujadas a 20 mm de los bordes de la hoja A4 y 1 línea (c) dibujada en el centro.
- 2.Conecte el enchufe eléctrico del MFP en el tomacorriente de la pared y encienda el interruptor principal.
- 3.Coloque el original (a) en el DP y haga una copia de prueba para verificar el funcionamiento y el ejemplo de copia.

Deutsch

[Funktionsprüfung]

- 1.Zum Prüfen der Gerätefunktion das Original (a) vorbereiten, auf das 4 Linien (b) 20 mm von den Kanten des A4-Blattes und 1 Linie (c) in der Mitte gezeichnet sind.
- 2.Den Netzstecker am MFP in die Steckdose stecken und den Strom einschalten.
- 3.Das Original (a) auf den DP legen und eine Testkopie erstellen, um die Funktion und das Kopierbeispiel zu prüfen.

Italiano

[Verifica del funzionamento]

- 1.Per verificare il funzionamento della macchina, preparare l'originale (a) tirando 4 linee (b) a 20 mm dai bordi del foglio A4 e una linea (c) al centro.
- 2.Inserire la spina dell'alimentazione dell'MFP nella presa a muro, quindi posizionare l'interruttore principale su On.
- 3.Posizionare l'originale(a) sul DP ed eseguire una copia di prova per verificare il funzionamento e l'esempio di copia.

简体中文

[动作确认]

1. 若要检查机器动作，准备一张 A4 原稿 (a)，距纸张边缘 20mm 画出 4 条线 (b) 并且在原稿中心画出 1 条线 (c)。
2. 将 MFP 的电源插头插入墙壁插座并打开主电源。
3. 在 DP 上设定原稿 (a) 并进行测试复印，确认机器动作和复印样本。

한국어


[동작확인]

1. 기계 작동 확인을 위해서, A4 용지 선단에서 20mm 떨어진 곳에 4 개의 선 (b) 과 센터에 1 개의 선 (c) 이 그려진 원고 (a) 를 준비.
2. 콘센트에 MFP 전원플러그를 꽂고 메인 전원 스위치를 ON 으로 합니다.
3. DP 상에 원고 (a) 를 준비하고 테스트 카피를 확인하여 작동 상태와 카피 샘플을 확인합니다.

日本語

[動作確認]

1. A4 サイズ用紙の端から 20mm の位置に線 (b) 4 本と、用紙の中心に線 (c) 1 本を引いた動作確認用の原稿 (a) を用意する。
2. MFP の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。
3. 原稿 (a) を DP にセットし、テストコピーを行い、動作およびコピーサンプルを確認する。



4. Compare original (a) with the copy example. If the gap exceeds the reference value, perform the following adjustments according to the type of the gap.

Check images of the DP after checking and adjusting images of the MFP. For details, see the service manual.

NOTICE: If there is any image fogging, adjust the U068 DP scanning position. If you change the scanning position with U068, adjust the U071 DP leading edge timing.

4. Comparer l'original (a) avec l'exemple de copie. Si l'écart excède la valeur de référence, effectuer les réglages suivants en fonction du type d'écart.

Vérifier les images du DP après avoir contrôlé et réglé les images du MFP. Pour plus de détails, se reporter au manuel d'entretien.

REMARQUE: Si l'image est floue, régler la position de balayage de U068 du DP. Si la position de balayage de U068 est modifiée, régler la synchronisation du bord d'attaque de U071.

4. Compare el original (a) con el ejemplo de copia. Si la separación supera el valor de referencia, realice los siguientes ajustes según el tipo de separación.

Compruebe las imágenes del DP después de comprobar y ajustar las imágenes del MFP. Para más detalles, lea el manual de servicio.

AVISO: Si la imagen estuviera borrosa, ajuste la posición de escaneo U068 del DP. Si cambia la posición de escaneo con U068, ajuste la sincronización de borde superior U071 del DP.

4. Das Original (a) mit dem Kopierbeispiel vergleichen. Wenn der Abstand größer als der Bezugswert ist, die folgenden Einstellungen gemäß dem Abstandstyp durchführen.

Die Bilder des DP nach dem Prüfen und Einstellen der Bilder des MFP prüfen. Weitere Einzelheiten siehe Wartungsanleitung.

ANMERKUNG: Falls das Bild verschwommen wirkt, ist die U068 DP Scan-Position zu verstellen. Wenn Sie die Scan-Position mit U068 verstellen, müssen Sie das U071 DP-Vorderkanten-Timing entsprechend verstellen.

4. Confrontare l'originale (a) con l'esempio di copia. Se lo scostamento supera il valore di riferimento, eseguire le seguenti regolazioni in funzione del tipo di scostamento.

Controllare le immagini del DP dopo avere effettuato i controlli e le regolazioni delle immagini sull'MFP. Per ulteriori dettagli leggere il manuale d'istruzioni.

AVVISO: Se è presente una qualsiasi sfocatura dell'immagine, regolare la posizione di scansione DP U068. Se si cambia la posizione di scansione con U068, regolare la sincronizzazione del bordo principale DP U071.

4. 对比复印样本和原稿(a), 如果偏移值在标准值以上时, 对偏移原稿进行调整。

对 MFP 的图像确认和调整后再对 DP 的图像进行确认。详细内容请参见维修手册。

(注意) 如果图像出现底灰, 用 U068 来调整 DP 的扫描位置。如果用 U068 更改了扫描位置, 则再用 U071 对 DP 的前端定时进行调整。

4. 원고 (a) 와 카피 샘플을 비교하여 차이가 기준치를 벗어나는 경우, 차이 (틈) 의 형태에 따라 다음을 조정합니다.

MFP 의 화상확인 및 조정을 하고나서 DP 의 화상확인을 할 것. 상세는 서비스 매뉴얼을 참조할 것.

(주의) 화상 카브리가 발생하는 경우, U068DP 스캔위치 조정을 합니다. U068 에서 스캔위치를 변경한 경우 U071DP 선단 타이밍 조정을 합니다.

4. 原稿 (a) とコピーサンプルを比較し、基準値以上のずれがある場合、ずれ方に応じて調整を行う。

MFP の画像確認及び調整を行ってから DP の画像確認を行うこと。詳細はサービスマニュアルを参照のこと。

(注意) 画像カブリが発生する場合、U068 DP 読み取り位置の調整を行う。U068 で読み取り位置を変更した場合、U071 DP 先端タイミング調整を行う。

Be sure to adjust in the following order. If not, the adjustment cannot be performed correctly.

For checking the angle of leading edge, see page 7. <Reference value> Simplex copying: within ± 2.0 mm; Duplex copying: within ± 3.0 mm

For checking the magnification, see page 10. <Reference value> Within $\pm 1.5\%$

For checking the leading edge timing, see page 12. <Reference value> Within ± 2.5 mm

For checking the center line, see page 14. <Reference value> Simplex copying: within ± 2.0 mm; Duplex copying: within ± 3.0 mm

When using the original for adjustment, automatic adjustment of magnification, leading edge timing and center line can be performed at a time.

For the automatic adjustment using the original for adjustment, see page 17.

Veillez à effectuer le réglage en procédant dans l'ordre suivant. Sinon, il sera impossible d'obtenir un réglage correct.

Pour vérifier l'angle du bord avant, reportez-vous à la page 7. <Valeur de référence> Copie recto seul: $\pm 2,0$ mm max.; copie recto verso: $\pm 3,0$ mm max.

Pour vérifier l'agrandissement, reportez-vous à la page 10. <Valeur de référence> $\pm 1,5\%$ max.

Pour vérifier la synchronisation du bord avant, reportez-vous à la page 12. <Valeur de référence> $\pm 2,5$ mm max.

Pour vérifier la ligne médiane, reportez-vous à la page 14. <Valeur de référence> Copie recto seul: $\pm 2,0$ mm max.; Copie recto verso: $\pm 3,0$ mm max.

Lorsque vous utilisez l'original pour effectuer le réglage, vous pouvez effectuer automatiquement le réglage de l'agrandissement, de la synchronisation du bord avant et de la ligne médiane en une seule fois.

Pour le réglage automatique en utilisant l'original pour effectuer le réglage, reportez-vous à la page 17.

Asegúrese de ajustar en el siguiente orden. De lo contrario, el ajuste no puede hacerse correctamente.

Para verificar el ángulo del borde superior, vea la página 7. <Valor de referencia> Copia simple: dentro de $\pm 2,0$ mm; Copia duplex: dentro de $\pm 3,0$ mm

Para verificar el cambio de tamaño, vea la página 10. <Valor de referencia> Dentro de $\pm 1,5\%$

Para verificar la sincronización del borde superior, vea la página 12. <Valor de referencia> Dentro de $\pm 2,5$ mm

Para verificar la línea central, vea la página 14. <Valor de referencia> Copia simple: dentro de $\pm 2,0$ mm; Copia duplex: dentro de $\pm 3,0$ mm

Cuando utilice el original para el ajuste, puede hacerse un ajuste automático del cambio de tamaño, sincronización del borde superior y línea central al mismo tiempo.

Para el ajuste automático utilizando el original para el ajuste, vea la página 17.

Die Einstellung in der folgenden Reihenfolge durchführen. Anderenfalls kann die Einstellung nicht korrekt durchgeführt werden.

Angaben zur Prüfung des Winkels der Vorderkante auf Seite 7. <Bezugswert> Simplexkopie: innerhalb $\pm 2,0$ mm; Duplexkopie: innerhalb $\pm 3,0$ mm

Angaben zur Prüfung der Vergrößerung auf Seite 10. <Bezugswert> Innerhalb $\pm 1,5\%$

Angaben zur Prüfung des Vorderkanten-Timings auf Seite 12. <Bezugswert> Innerhalb $\pm 2,5$ mm

Angaben zur Prüfung der Mittellinie auf Seite 14. <Bezugswert> Simplexkopie: innerhalb $\pm 2,0$ mm; Duplexkopie: innerhalb $\pm 3,0$ mm

Bei Verwendung des Originals für die Einstellung können die automatischen Einstellungen für Vergrößerung, Vorderkanten-Timing und Mittellinie gleichzeitig durchgeführt werden.

Angaben zur automatischen Einstellung mithilfe des Originals auf Seite 17.

Accertarsi di eseguire le regolazioni in questa sequenza: in caso contrario, la regolazione non può essere effettuata correttamente.

Per controllare l'angolo del bordo principale, vedere pagina 7. <Valore di riferimento> Copia simplex: entro $\pm 2,0$ mm; Copia duplex: entro $\pm 3,0$ mm

Per controllare l'ingrandimento, vedere pagina 10. <Valore di riferimento> Entro $\pm 1,5\%$

Per controllare la sincronizzazione del bordo principale, vedere pagina 12. <Valore di riferimento> Entro $\pm 2,5$ mm

Per controllare la linea centrale, vedere pagina 14. <Valore di riferimento> Copia simplex: entro $\pm 2,0$ mm; Copia duplex: entro $\pm 3,0$ mm

Quando si utilizza l'originale per la regolazione, la regolazione automatica dell'ingrandimento, della sincronizzazione del bordo principale e della linea centrale possono essere eseguiti contemporaneamente.

Per la regolazione automatica eseguita con l'originale, vedere pagina 17.

必须按照以下步骤进行调整,否则不能达到准确调整的要求。

• 确认前端倾斜度 第7页 <标准值> 单面: ± 2.0 mm 以内, 双面: ± 3.0 mm 以内

• 确认等倍值 第10页 <标准值> $\pm 1.5\%$ 以内

• 确认前端定时调整 第12页 <标准值> ± 2.5 mm 以内

• 确认中心线 第14页 <标准值> 单面: ± 2.0 mm 以内, 双面: ± 3.0 mm 以内

使用调整用的原稿时,可以同时自动进行等倍值,前端定时以及中心线的调整。

• 通过调整用原稿进行自动调整 第17页

반드시 하기의 순서로 조정을 할 것. 순서대로 조정을 하지 않는 경우 바른 조정을 할 수 없습니다.

• 선단경사확인 7 페이지 <기준치> 단면: ± 2.0 mm 이내, 양면: ± 3.0 mm 이내

• 등배도 확인 10 페이지 <기준치> $\pm 1.5\%$ 이내

• 선단 타이밍 확인 12 페이지 <기준치> ± 2.5 mm 이내

• 센터 라인 확인 14 페이지 <기준치> 단면: ± 2.0 mm 이내, 양면: ± 3.0 mm 이내

조정용 원고를 사용하면 등배도 조정, 선단 타이밍 조정, 센터 라인 조정의 자동조정이 한번에 수행됩니다.

• 조정용 원고를 사용한 자동조정은 17 페이지 참조

必ず下記の順序で調整を行うこと.順序通りに調整を行わない場合,正しい調整ができない。

• 先端斜め確認 7 ページ <基準値> 片面: ± 2.0 mm 以内, 両面: ± 3.0 mm 以内


• 等倍度確認 10 ページ <基準値> $\pm 1.5\%$ 以内

• 先端タイミング確認 12 ページ <基準値> ± 2.5 mm 以内

• センターライン確認 14 ページ <基準値> 片面: ± 2.0 mm 以内, 両面: ± 3.0 mm 以内

調整用原稿を使用すると,等倍度調整,先端タイミング調整,センターライン調整の自動調整が一度におこなえる。

• 調整用原稿による自動調整 17 ページ



[Checking the angle of leading edge]

1. Check the horizontal gap between line (1) of original (a) and line (2) of copy example positions. If the gap exceeds the reference value, adjust the gap according to the following procedure.

- <Reference value> For single copying: within ± 2.0 mm.
For duplex copying: within ± 3.0 mm.

[Vérification de l'angle du bord avant]

1. Vérifier l'écart horizontal entre la position de la ligne (1) de l'original (a) et celle de la ligne (2) de l'exemple de copie. Si l'écart excède la valeur de référence, le régler selon la procédure suivante.

- <Valeur de référence> Pour la copie recto : $\pm 2,0$ mm max.
Pour la copie recto-verso : $\pm 3,0$ mm max.

[Verificación del ángulo del borde superior]

1. Compruebe la separación horizontal entre la línea (1) del original (a) y la línea (2) de las posiciones del ejemplo de copia. Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.

- <Valor de referencia> Para el copiado por una cara: dentro de $\pm 2,0$ mm.
Para el copiado dúplex: dentro de $\pm 3,0$ mm.

[Überprüfen des Winkels der Vorderkante]

1. Den horizontalen Abstand zwischen der Linie (1) des Originals (a) und der Linie (2) der Kopierbeispielspositionen prüfen. Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.

- <Bezugswert> Einzelkopie: innerhalb $\pm 2,0$ mm.
Duplexkopie: innerhalb $\pm 3,0$ mm.

[Controllo dell'angolo del bordo principale]

1. Verificare lo scostamento orizzontale fra la linea (1) dell'originale (a) e la linea (2) delle posizioni dell'esempio di copia. Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.

- <Valore di riferimento> Per la copia singola: entro $\pm 2,0$ mm.
Per la copia duplex: entro $\pm 3,0$ mm.

[确认前端倾斜度]

1. 确认原稿 (a) 上的线 (1) 和复印样本上的线 (2) 的左右偏移值。如果偏移值超过标准值, 则按照下列步骤进行调整。

- <标准值> 单面复印时: ± 2.0 mm 以内。
双面复印时: ± 3.0 mm 以内。

[선단 경사확인]


1. 원고 (a) 의 선 (1) 과 샘플 카피의 선 (2) 의 좌우 차이를 확인합니다. 차이가 기준치 외의 경우 다음의 순서대로 조정을 합니다.

- <기준치> 단면의 경우: ± 2.0 mm 이내
양면의 경우: ± 3.0 mm 이내

[先端斜め確認]

1. 原稿 (a) の線 (1) とコピーサンプルの線 (2) の左右のずれを確認する。ずれが基準値外の場合、次の手順で調整を行う。

- <基準値> 片面の場合: ± 2.0 mm 以内
両面の場合: ± 3.0 mm 以内



2. Turn off the main power switch of the machine. Open DP. Perform the steps 3,4,11,12,13 and 16 in its reverse order on pages 1,2 and 3 to remove the DP from the MFP.
3. Loosen three adjustment screws (3) for the right side hinge.
4. Adjust the position of the right hinge.
In case of copy sample (d): Move the right hinge up (⇒).
In case of copy sample (e): Move the right hinge down (⇐).
Amount of change per scale: Approx. 0.6 mm (4)
5. After the adjustment, retighten three adjusting screws (3) which were loosened in step 3.

2. Mettez la machine hors tension. Ouvrez le DP. Effectuez les étapes 3,4,11,12,13 et 16 dans l'ordre inverse aux pages 1,2 et 3 pour retirer le DP du MFP
3. Desserrez trois vis de réglage (3) pour la charnière droite.
4. Ajustez la position de la charnière droite.
Dans le cas de l'exemple de copie (d) : Déplacer la charnière de droite vers le haut (⇒).
Dans le cas de l'exemple de copie (e) : Déplacer la charnière de droite vers le bas (⇐).
Changement par graduation d'échelle : environ 0,6 mm (4)
5. Après l'ajustement, resserrez les trois vis de réglage (3) qui ont été desserrées à l'étape 3.

2. Apague el interruptor de encendido de la máquina. Abra el DP. Realice los pasos 3,4,11,12,13 y 16 de las páginas 1,2 y 3 pero al revés para quitar el DP del dispositivo MFP.
3. Suelte los tres tornillos de ajuste (3) de la bisagra en el lado derecho.
4. Ajuste la posición de la bisagra derecha.
En caso de muestra de copia (d): Suba la bisagra derecha (⇒).
En caso de muestra de copia (e): Baje la bisagra derecha (⇐).
Magnitud del cambio por escala: aprox. 0,6 mm (4)
5. Después del ajuste, vuelva a apretar los tres tornillos de ajuste (3) que se aflojaron en el paso 3.


2. Schalten Sie das Gerät über den Hauptschalter aus. Öffnen Sie DP. Führen Sie die Schritte 3,4,11,12,13 und 16 in umgekehrter Reihenfolge wie auf den Seiten 1,2 und 3 beschrieben aus. Entfernen Sie den DP vom MFP.
3. Lösen Sie die drei Einstellschrauben (3) am rechten Scharnier.
4. Justieren Sie die Position des rechten Scharniers.
Bei Verwendung der Kopiervorlage (d): Bewegen Sie das rechte Scharnier nach oben (⇒).
Bei Verwendung der Kopiervorlage (e): Bewegen Sie das rechte Scharnier nach unten (⇐).
Änderung pro Maßstab: Ungefähr 0,6 mm (4)
5. Nachdem Sie die Einstellung vorgenommen haben, ziehen Sie die drei Justierschrauben (3) wieder an, die Sie in Schritt 3 gelöst hatten.

2. Spegner l'interruttore di alimentazione della macchina. Aprire il DP. Eseguire i punti 3,4,11,12,13 e 16 eseguendo le operazioni in ordine contrario rispetto a quanto indicato a pagina 1,2 e 3 per rimuovere il DP dal dispositivo MFP
3. Allentare le tre viti di regolazione (3) sulla cerniera di destra.
4. Regolare la posizione della cerniera di destra.
Nel caso dell'esempio copia (d): Alzare la cerniera destra (⇒).
Nel caso dell'esempio copia (e): Abbassare la cerniera destra (⇐).
Entità modifica per scala: circa 0,6 mm (4)
5. Dopo la regolazione, serrare di nuovo le tre viti di regolazione (3), allentate al punto 3.

2. 关闭机器的主电源开关。打开 DP。按照第 1 ~ 3 页的步骤 3, 4, 11, 12, 13 和 16 的相反顺序, 把 DP 从机器上取下。
3. 拧松 3 颗右铰链的调整螺丝 (3)。
4. 调整右铰链的位置。
当处于样张 (d) : 将右铰链向上 (⇒) 移动。
当处于样张 (e) : 将右铰链向下 (⇐) 移动。
按比例尺的更改量: 约 0.6mm (4)
5. 调整完成后, 重新拧紧在步骤 3 中松开的 3 颗调整螺丝 (3)。

2. 기계의 전원을 OFF 합니다. DP 를 엽니다. 1~3 페이지의 단계 3,4,11,12,13,16 를 역순으로 MFP 에서 DP 를 떼어 냅니다.
3. 오른쪽 힌지의 조정나사 (3) 3 개를 풀습니다.
4. 우측 힌지의 위치를 조정합니다.
복사 샘플 (d) 의 경우 : 우측 힌지를 위쪽 (⇒) 에 움직입니다.
복사 샘플 (e) 의 경우 : 우측 힌지를 아래쪽 (⇐) 에 움직입니다.
눈금당 변화량: 약 0.6 mm (4)
5. 조정종료 후 순서 3 에서 느슨하게 한 조정나사 (3) 3 개를 조입니다.

2. 機械の主電源スイッチを OFF にする。DP を開く。1 ~ 3 ページの手順 3, 4, 11, 12, 13, 16 の逆手順で DP を MFP から取り外す。
3. 右ヒンジの調整ビス (3) 3 本を緩める。
4. 右ヒンジの位置を調整する。
コピーサンプル (d) の場合: 右ヒンジを上 (⇒) へ動かす。
コピーサンプル (e) の場合: 右ヒンジを下 (⇐) へ動かす。
1 目盛り当たりの変化量: 約 0.6mm (4)
5. 調整終了後、手順 3 で緩めた調整ビス (3) 3 本を締め付ける。



6. Perform the steps 3,4,11,12,13 and 16 on pages 1,2 and 3 to reinstall the DP on the MFP.
7. Turn on the main power switch of the machine. Perform a test copy.
8. Repeat the steps above until the gap of line (2) of copy example shows the following reference values.
 <Reference value> For single copying: within ± 2.0 mm.
 For duplex copying: within ± 3.0 mm.
9. Remove the original mat and attach it again in accordance with step 15 and 16 on page 3.

6. Effectuez les étapes 3,4,11,12,13 et 16 aux pages 1,2 et 3 pour réinstaller le DP sur le MFP.
7. Mettez la machine sous tension. Effectuez une copie de test.
8. Répétez les étapes ci-dessus jusqu'à ce que l'écart de la ligne (2) de l'exemple de copie indique les valeurs de référence suivantes.
 <Valeur de référence> Pour la copie recto : $\pm 2,0$ mm max.
 Pour la copie recto-verso : $\pm 3,0$ mm max.
9. Retirez le tapis d'original et remettez-le en place conformément aux étapes 15 et 16 à la page 3.

6. Realice los pasos 3,4,11,12,13 y 16 de las páginas 1,2 y 3 para reinstalar el DP en el dispositivo MFP.
7. Encienda el interruptor de encendido de la máquina. Haga una copia de prueba.
8. Repita los pasos anteriores hasta que la separación de la línea (2) del ejemplo de copia presente los siguientes valores de referencia.
 <Valor de referencia> Para el copiado por una cara: dentro de $\pm 2,0$ mm.
 Para el copiado dúplex: dentro de $\pm 3,0$ mm.
9. Quite la almohadilla de originales y vuelva a colocarla según lo indicado en los pasos 15 y 16 en la página 3.


6. Führen Sie auf den Seiten 1,2 und 3 die Schritte 3,4,11,12,13 und 16 aus, um den DP wieder am MFP zu installieren.
7. Schalten Sie das Gerät über den Hauptschalter ein. Eine Testkopie erstellen.
8. Die obigen Schritte wiederholen, bis der Abstand der Linie (2) des Kopierbeispiels die folgenden Bezugswerte aufweist.
 <Bezugswert> Einzelkopie: innerhalb $\pm 2,0$ mm.
 Duplexkopie: innerhalb $\pm 3,0$ mm.
9. Entfernen Sie die Originalmatte und befestigen Sie sie wieder, wie in den Schritten 15 und 16 auf Seite 3 gezeigt.

6. Eseguire i punti 3,4,11,12,13 e 16 a pagina 1,2 e 3 per reinstallare il DP sul sistema MFP.
7. Accendere l'interruttore di alimentazione della macchina. Eseguire una copia di prova.
8. Ripetere le operazioni sopra descritte fino a quando lo scostamento della linea (2) dell'esempio di copia riporterà i valori di riferimento seguenti.
 <Valore di riferimento> Per la copia singola: entro $\pm 2,0$ mm.
 Per la copia duplex: entro $\pm 3,0$ mm.
9. Rimuovere il coprioriginale e riposizionarlo attenendosi alla procedura descritta ai punti 15 e 16 di pagina 3.

6. 按照第 1 ~ 3 页的步骤 3, 4, 11, 12, 13, 16 把 DP 再次装回机器。
7. 打开机器的主电源开关。进行测试复印。
8. 重复上述步骤直至复印样本上的线 (2) 的偏移值达到标准值范围内。
 <标准值> 单面时 : ± 2.0 mm 以内
 双面时 : ± 3.0 mm 以内
9. 取下原稿垫, 参考第 3 页的步骤 15、16, 再次安装。

6. 1~3 페이지의 3,4,11,12,13,16 단계에서 DP 를 다시 설치합니다 .
7. 기계의 전원을 ON 합니다 . 테스트 카피를 합니다 .
8. 샘플 카피 선 (2) 차이가 기준치내가 될 때까지 조정을 반복합니다 .
 <기준치> 단면의 경우 : ± 2.0 mm 이내
 양면의 경우 : ± 3.0 mm 이내
9. 원고 매트 를 제거하고 3 페이지의 단계 15 ~ 16 에 따라 다시 부착합니다 .

6. 1 ~ 3 페이지の手順 3, 4, 11, 12, 13, 16 の手順で DP を再度取り付けれる。
7. 機械の主電源スイッチを ON にする。テストコピーを行う。
8. コピーサンプルの線 (2) のずれが基準値内になるまで、調整を繰り返す。
 <基準値> 片面の場合 : ± 2.0 mm 以内
 両面の場合 : ± 3.0 mm 以内
9. 原稿マットを取り外し、3 ページの手順 15, 16 を参考に再度取り付けれる



[Checking the magnification]

1. Check the gap between line (1) of original (a) and line (2) of copy example. If the gap exceeds the reference value, adjust the gap according to the following procedure.
<Reference value> within ±1.5%

2. Use the maintenance mode U070 to adjust the magnification.
Sub Scan(F): Adjusts the scanner sub-scan magnification (front side)
Sub Scan (CIS): Adjusts the scanner CIS sub-scan magnification

[Vérification de l'agrandissement]

1. Vérifier l'écart entre la ligne (1) de l'original (a) et la ligne (2) de l'exemple de copie. Si l'écart excède la valeur de référence, le régler selon la procédure suivante.
<Valeur de référence> ±1,5% max

2. Pour régler l'agrandissement, utilisez le mode entretien U070.
Sub Scan(F): Permet de régler l'agrandissement du balayage secondaire du scanner(recto)
Sub Scan (CIS): Permet de régler l'agrandissement du balayage secondaire du CIS du scanner

[Verificación del cambio de tamaño]

1. Compruebe la separación entre la línea (1) del original (a) y la línea (2) del ejemplo de copia. Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.
<Valor de referencia> dentro de ±1,5%

2. Para ajustar la ampliación utilice el modo de mantenimiento U070.
Sub Scan(F): Ajusta el cambio de tamaño de la dirección de exploración secundaria del escáner.(anverso)
Sub Scan (CIS): Ajusta el cambio de tamaño de la dirección de exploración secundaria CIS del escáner

[Überprüfen der Vergrößerung]

1. Den Abstand zwischen der Linie (1) des Originals (a) und der Linie (2) des Kopierbeispiels prüfen. Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.
<Bezugswert> Innerhalb ±1,5%

2. Zum Einstellen der Vergrößerung den Wartungsmodus U070 verwenden.
Sub Scan(F): Zur Einstellung der Subscan-Vergrößerung(Vorderseite)
Sub Scan (CIS): Zur Einstellung der Scanner-CIS-Subscan-Vergrößerung

[Controllo dell'ingrandimento]

1. Verificare lo scostamento fra la linea (1) dell'originale (a) e la linea (2) dell'esempio di copia. Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.
<Valore di riferimento> Entro ±1,5%

2. Usare la modalità di manutenzione U070 per regolare l'ingrandimento.
Sub Scan(F): Regola l'ingrandimento della scansione ausiliare dello scanner(facciata anteriore)
Sub Scan (CIS): Regola l'ingrandimento della scansione ausiliare CIS dello scanner

[确认等倍值]

1. 确认原稿 (a) 上的线 (1) 和复印样本上的线 (2) 之间的偏移值。如果偏移值超过标准值, 则按照下列步骤进行调整。
<标准值> ±1.5% 以内

2. 使用维修模式 U070 调整等倍值。
Sub Scan(F) : 读取副扫描等倍度的调整 (正面)
Sub Scan(CIS) : CIS 的读取副扫描等倍度的调整

[등배도확인]


1. 원고 (a) 선 (1) 과 샘플 카피의 선 (2) 의 차이를 확인합니다 .
차이가 기준이외의 경우, 다음 순서로 조정을 합니다 .
<기준치> ±1.5% 이내

2. 메인テナンス 모드 U070 에서 조정합니다 .
Sub Scan(F) : 스캔 부주사등배도의 조정 (앞면)
Sub Scan(CIS) : CIS 의 스캔 부주사 등배도의 조정

[等倍度確認]

1. 原稿 (a) の線 (1) とコピーサンプルの線 (2) のずれを確認する。
ずれが基準値外の場合、次の手順で調整を行う。
<基準値> ±1.5% 以内

2. メンテナンスモード U070 をセットし、調整を行う。
Sub Scan(F) : 読み込み副走査等倍度の調整 (表面)
Sub Scan(CIS) : CIS 読み込み副走査等倍度の調整



3. Adjust the values.

For the shorter length copy example (f): Increases the value.
For the longer length copy example (g): Decreases the value.
Amount of change per step: 0.10 %

4. Press the [Start] key to confirm the setting value.
5. Perform a test copy.

6. Repeat the steps 2 to 5 above until the gap of line (2) of copy example shows the reference value.

<Reference value> within ±1.5%

3. Régler les valeurs.

Pour l'exemple de copie dont la longueur est plus courte (f) : augmenter la valeur.
Pour l'exemple de copie dont la longueur est plus longue (g) : diminuer la valeur.
Changement par graduation d'échelle : 0,10 %

4. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
5. Effectuer une copie de test.

6. Répéter les étapes 2 à 5 jusqu'à ce que l'écart de la ligne (2) de l'exemple de copie indique la valeur de référence.

<Valeur de référence> ±1,5% max

3. Ajuste los valores.

Para el ejemplo de copia más corto (f): aumenta el valor.
Para el ejemplo de copia más largo (g): disminuye el valor.
Magnitud del cambio por incremento: 0,10 %

4. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
5. Haga una copia de prueba.

6. Repita los pasos 2 a 5 anteriores hasta que la separación de la línea (2) del ejemplo de copia presente el valor de referencia.

<Valor de referencia> dentro de ±1,5%

3. Die Werte einstellen.

Für die kürzere Länge des Kopierbeispiels (f): Den Wert erhöhen.
Für die längere Länge des Kopierbeispiels (g): Den Wert verringern.
Änderung pro Schritt: 0,10 %

4. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
5. Eine Testkopie erstellen.

6. Die Schritte 2 bis 5 wiederholen, bis der Abstand der Linie (2) des Kopierbeispiels den Bezugswert aufweist.

<Bezugswert> Innerhalb ±1,5%

3. Regolare i valori.

Per l'esempio di copia di lunghezza inferiore (f): aumenta il valore.
Per l'esempio di copia di lunghezza superiore (g): riduce il valore.
Entità modifica per passo: 0,10 %

4. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
5. Eseguire una copia di prova.

6. Ripetere le operazioni sopra descritte da 2 a 5 fino a quando lo scostamento della linea (2) dell'esempio di copia riporterà i valori di riferimento.

<Valore di riferimento> Entro ±1,5%

3. 調整設定値。

在长度偏短时 复印样本 (f) : 调高设定值
在长度偏长时 复印样本 (g) : 调低设定值
设定值的一个调整单位变化量 : 0.10%

4. 按 [开始] 键, 以确定设定值。
5. 进行测试复印。

6. 重复上述步骤 2 到 5, 直至复印样本上的线 (2) 之间的偏移值达到标准值范围内。

< 标准值 > ±1.5% 以内

3. 설정치를 조정합니다 .

길이가 짧은 경우 샘플 카피 (f) : 설정치를 높입니다 .
길이가 긴 경우 샘플 카피 (g) : 설정치를 내립니다 .
1 스텝당 변화량 : 0.10%

4. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .
5. 테스트 카피를 합니다 .

6. 샘플 카피 선 (2) 의 차이가 기준치내가 될 때까지 2 ~ 5 를 반복합니다 .

< 기준치 > ±1.5% 이내


3. 設定値を調整する。

長さが短い場合コピーサンプル (f) : 設定値を上げる。
長さが長い場合コピーサンプル (g) : 設定値を下げる。
1 ステップ当たりの変化量 : 0.10%

4. [スタート] キーを押し、設定値を確定する。
5. テストコピーを行う。

6. コピーサンプルの線 (2) のずれが基準値内になるまで手順 2 ~ 5 を繰り返す。

< 基準値 > ±1.5% 以内



[Checking the leading edge timing]

1. Check the gap between line (1) on original (a) and line (2) of copy example. If the gap exceeds the reference value, adjust the gap according to the following procedure.
<Reference value> within ± 2.5 mm

2. Use the maintenance mode U071 to adjust the timing.

Front Head: Adjusts the leading edge timing (front side)
 Front Tail: Adjusts the trailing edge timing (front side)
 CIS Head: Adjusts the leading edge timing for CIS scanning.
 CIS Tail: Adjusts the trailing edge timing for CIS scanning.

[Vérification de la synchronisation du bord avant]

1. Vérifier l'écart entre la ligne (1) de l'original (a) et la ligne (2) de l'exemple de copie. Si l'écart excède la valeur de référence, le régler selon la procédure suivante.
<Valeur de référence> $\pm 2,5$ mm max

2. Pour régler la synchronisation, utilisez le mode entretien U071.

Front Head: Permet de régler la synchronisation du bord de tête (recto)
 Front Tail: Permet de régler la synchronisation du bord arrière (recto)
 CIS Head: Permet de régler la synchronisation du bord de tête pour le balayage par le CIS.
 CIS Tail: Permet de régler la synchronisation du bord arrière pour le balayage par le CIS.

[Cambio de la sincronización de borde superior]

1. Compruebe la separación entre la línea (1) del original (a) y la línea (2) del ejemplo de copia. Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.
<Valor de referencia> dentro de $\pm 2,5$ mm

2. Para ajustar la sincronización utilice el modo de mantenimiento U071.

Front Head: Ajusta la sincronización del borde superior (anverso).
 Front Tail: Ajusta la sincronización del borde inferior (anverso).
 CIS Head: Ajusta la sincronización del borde superior para exploración CIS.
 CIS Tail: Ajusta la sincronización del borde inferior para exploración CIS.

[Überprüfen des Vorderkanten-Timings]

1. Den Abstand zwischen der Linie (1) des Originals (a) und der Linie (2) des Kopierbeispiels prüfen. Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.
<Bezugswert> Innerhalb $\pm 2,5$ mm

2. Zum Einstellen des Timing den Wartungsmodus U071 verwenden.

Front Head: Zur Einstellung des Vorderkanten-Timing (Vorderseite)
 Front Tail: Zur Einstellung des Hinterkanten-Timing (Vorderseite)
 CIS Head: Zur Einstellung des Vorderkanten-Timing für CIS-Scannen.
 CIS Tail: Zur Einstellung des Hinterkanten-Timing für CIS-Scannen.

[Controllo della sincronizzazione del bordo principale]

1. Verificare lo scostamento fra la linea (1) sull'originale (a) e la linea (2) dell'esempio di copia. Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.
<Valore di riferimento> Entro $\pm 2,5$ mm

2. Usare la modalità di manutenzione U071 per regolare la sincronizzazione.

Front Head: Regola la sincronizzazione del bordo principale (facciata anteriore)
 Front Tail: Regola la sincronizzazione del bordo di uscita (facciata anteriore)
 CIS Head: Regola la sincronizzazione del bordo principale per scansione CIS.
 CIS Tail: Regola la sincronizzazione del bordo di uscita per scansione CIS.

[确认前端定时调整]

1. 确认原稿 (a) 上的线 (1) 和复印样本上的线 (2) 之间的偏移值。如果偏移值超过标准值，则按照下列步骤进行调整。
<标准值> ± 2.5 mm 以内

2. 使用维修模式 U071 调整定时。

Front Head: 调整前端定时 (正面)
 Front Tail: 调整后端定时 (正面)
 CIS Head: 调整 CIS 读取时的前端定时
 CIS Tail: 调整 CIS 读取时的后端定时

[선단 타이밍확인]

1. 원고 (a) 선 (1) 과 샘플 카피 선 (2) 의 차이를 확인합니다. 차이가 기준치 외의 경우 다음 순서로 조정을 합니다.
<기준치> ± 2.5 mm 이내

2. 메인テナンス 모드 U071 에서 조정합니다.


Front Head: 선단 타이밍 (앞면) 을 조정합니다.
 Front Tail: 후단 타이밍 (앞면) 을 조정합니다.
 CIS Head: CIS 스캔 시의 선단 타이밍을 조정합니다.
 CIS Tail: CIS 스캔 시의 후단 타이밍을 조정합니다.

[先端タイミング確認]

1. 原稿 (a) の線 (1) とコピーサンプルの線 (2) のずれを確認する。ずれが基準値外の場合、次の手順で調整を行う。
<基準値> ± 2.5 mm 以内

2. メンテナンスモード U071 をセットし、調整を行う。

Front Head: 先端タイミング (表面) の調整
 Front Tail: 後端タイミング (表面) の調整
 CIS Head: CIS 読み込み時の先端タイミングの調整
 CIS Tail: CIS 読み込み時の後端タイミングの調整



3. Adjust the values.

For the faster leading edge timing, copy examples (h): Decreases the value.

For the slower leading edge timing, copy examples (i): Increases the value.

Amount of change per step: 0.25 mm

4. Press the [Start] key to confirm the setting value.

5. Perform a test copy.

6. Repeat the steps 2 to 5 above until the gap of line (2) of copy example shows the reference value.

<Reference value> within ± 2.5 mm

3. Régler les valeurs.

Pour les exemples de copie dont la synchronisation du bord avant est plus rapide (h) : diminuer la valeur.

Pour les exemples de copie dont la synchronisation du bord avant est plus lente (i) : augmenter la valeur.

Changement par graduation d'échelle : 0,25 mm

4. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.

5. Effectuer une copie de test.

6. Répéter les étapes 2 à 5 jusqu'à ce que l'écart de la ligne (2) de l'exemple de copie indique la valeur de référence.

<Valeur de référence> $\pm 2,5$ mm max

3. Ajuste los valores.

Para una sincronización más rápida de extremo guía, ejemplos de copia (h): disminuye el valor.

Para una sincronización más lenta de extremo guía, ejemplos de copia (i): aumenta el valor.

Magnitud del cambio por incremento: 0,25 mm

4. Pulse la tecla de [Inicio] para confirmar el valor de configuración.

5. Haga una copia de prueba.

6. Repita los pasos 2 a 5 anteriores hasta que la separación de la línea (2) del ejemplo de copia presente el valor de referencia.

<Valor de referencia> dentro de $\pm 2,5$ mm

3. Die Werte einstellen.

Für den schnelleren Vorderkantentakt, Kopierbeispiel (h): Den Wert verringern.

Für den langsameren Vorderkantentakt, Kopierbeispiel (i): Den Wert erhöhen.

Änderung pro Schritt: 0,25 mm

4. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.

5. Eine Testkopie erstellen.

6. Die Schritte 2 bis 5 wiederholen, bis der Abstand der Linie (2) des Kopierbeispiels den Bezugswert aufweist.

<Bezugswert> Innerhalb $\pm 2,5$ mm

3. Regolare i valori.

Per accelerare la fasatura del bordo di entrata, esempi di copia (h): riduce il valore.

Per rallentare la fasatura del bordo di entrata, esempi di copia (i): aumenta il valore.

Entità modifica per passo: 0,25 mm

4. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.

5. Eseguire una copia di prova.

6. Ripetere le operazioni sopra descritte da 2 a 5 fino a quando lo scostamento della linea (2) dell'esempio di copia riporterà i valori di riferimento.

<Valore di riferimento> Entro $\pm 2,5$ mm

3. 調整設定値。

在前端定时偏快时 复印样本 (h) : 调低设定值

在前端定时偏慢时 复印样本 (i) : 调高设定值

设定值的一个调整单位变化量 : 0.25mm

4. 按 [开始] 键, 以确定设定值。

5. 进行测试复印。

6. 重复上述步骤 2 到 5, 直至复印样本上的线 (2) 的偏移值达到标准值范围内。

< 标准值 > ± 2.5 mm 以内

3. 설정치를 조정합니다.

선단 타이밍이 빠른 경우 샘플 카피 (h): 설정치를 내립니다.

선단 타이밍이 늦은 경우 샘플 카피 (i): 설정치를 올립니다.

1 스텝당 변화량: 0.25mm

4. [복사 / 시작] 키를 누르고 설정치를 확인합니다.

5. 테스트 카피를 합니다.

6. 샘플 카피 선 (2) 의 차이가 기준치내가 될 때까지 2 ~ 5 를 반복합니다.

< 기준치 > ± 2.5 mm 이내

3. 設定値を調整する。

先端タイミングが早い場合コピーサンプル (h): 設定値を下げる。

先端タイミングが遅い場合コピーサンプル (i): 設定値を上げる。


1 ステップ当たりの変化量: 0.25mm

4. [スタート] キーを押し、設定値を確定する。

5. テストコピーを行う。

6. コピーサンプルの線 (2) のずれが基準値内になるまで手順 2 ~ 5 を繰り返す。

< 基準値 > ± 2.5 mm 以内



[Checking the center line]

1. Check the gap between center line (1) on original (a) and center line (2) of copy example. If the gap exceeds the reference value, adjust the gap according to the following procedure.

<Reference value>

Horizontal difference of center line (2) for the single copying: ± 2.0 mm
Horizontal difference of center line (2) for the duplex copying: ± 3.0 mm

2. Use the maintenance mode U072 to adjust the timing.

Front: Adjusts the center line (front side)

CIS: Adjusts the CIS center line

[Vérification de la ligne médiane]

1. Vérifier l'écart entre l'axe (1) de l'original (a) et l'axe (2) de l'exemple de copie. Si l'écart excède la valeur de référence, le régler selon la procédure suivante.

<Valeur de référence>

Différence horizontale de l'axe (2) pour la copie recto : $\pm 2,0$ mm
Différence horizontale de l'axe (2) pour la copie recto-verso : $\pm 3,0$ mm

2. Pour régler la ligne médiane, utiliser le mode entretien U072.

Front: Permet de régler l'axe (recto)

CIS: Permet de régler l'axe du CIS

[Verificación de la línea central]

1. Compruebe la separación entre la línea de centro (1) del original (a) y la línea de centro (2) del ejemplo de copia. Si la separación supera el valor de referencia, ajústela siguiendo este procedimiento.

<Valor de referencia>

Diferencia horizontal de la línea de centro (2) para el copiado por una cara: $\pm 2,0$ mm

Diferencia horizontal de la línea de centro (2) para el copiado dúplex: $\pm 3,0$ mm

2. Para ajustar la línea central utilice el modo de mantenimiento U072.

Front: ajusta la línea central (anverso).

CIS: ajusta la línea central CIS

[Überprüfen der Mittellinie]

1. Den Abstand zwischen der Mittellinie (1) des Originals (a) und der Mittellinie (2) des Kopierbeispiels prüfen. Wenn der Abstand größer als der Bezugswert ist, den Abstand mit dem folgenden Verfahren einstellen.

<Bezugswert>

Horizontaler Unterschied der Mittellinie (2) für die Einzelkopie: $\pm 2,0$ mm
Horizontaler Unterschied der Mittellinie (2) für die Duplexkopie: $\pm 3,0$ mm

2. Zum Einstellen der Mittellinie den Wartungsmodus U072 verwenden.

Front: Zur Einstellung der Mittellinie (Vorderseite)

CIS: Zur Einstellung der CIS-Mittellinie

[Controllo della linea centrale]

1. Verificare lo scostamento fra la linea centrale (1) sull'originale (a) e la linea centrale (2) dell'esempio di copia. Se lo scostamento supera il valore di riferimento, regolare lo scostamento stesso seguendo questa procedura.

<Valore di riferimento>

Differenza orizzontale della linea centrale (2) per la copia singola: $\pm 2,0$ mm
Differenza orizzontale della linea centrale (2) per la copia duplex: $\pm 3,0$ mm

2. Usare la modalità di manutenzione U072 per regolare la linea centrale.

Front: Regola la linea centrale (facciata anteriore)

CIS: Regola la linea centrale CIS

[确认中心线]

1. 确认原稿 (a) 中心线 (1) 和复印样本中心线 (2) 之间的偏移值。如果偏移值超过标准值, 则按照下列步骤进行调整。

<标准值> 单面复印时, 中心线 (2) 的左右偏移值: ± 2.0 mm 以内
双面复印时, 中心线 (2) 的左右偏移值: ± 3.0 mm 以内

2. 使用维修模式 U072 调整中心线。

Front: 中心位置 (正面) 的调整

CIS: CIS 的中心位置的调整

[센터 라인 확인]

1. 원고 (a) 센터라인 (1) 과 샘플 카피 센터라인 (2) 의 차이를 확인합니다 . 차이가 기준치 외의 경우 다음 순서로 조정합니다 .

<기준치> 단면의 경우 센터라인 (2) 의 좌우차이: ± 2.0 mm 이내
양면의 경우 센터라인 (2) 의 좌우차이: ± 3.0 mm 이내

2. 메인テナンス 모드 U072 에서 조정합니다 .

Front: 센터 위치 (앞면) 의 조정

CIS: CIS 의 센터 위치조정

[センターライン確認]


1. 原稿 (a) の中心線 (1) とコピーサンプルの中心線 (2) のずれを確認する。ずれが基準値外の場合、次の手順で調整を行う。

<基準値> 片面の場合、中心線 (2) の左右ずれ: ± 2.0 mm 以内
両面の場合、中心線 (2) の左右ずれ: ± 3.0 mm 以内

2. メンテナンスモード U072 をセットし、調整を行う。

Front: センター位置 (表面) の調整

CIS: CIS のセンター位置の調整



3. Adjust the values.

If the center moves more front, copy example (j): Increases the value.
If the center moves inner, copy sample (k): Decreases the value.
Amount of change per step: 0.085 mm

- 4. Press the [Start] key to confirm the setting value.**
5. Perform a test copy.

6. Repeat the steps 2 to 5 above until the gap of line (2) of copy example shows the reference value.

<Reference value>

Horizontal difference of center line (2) for the single copying: ± 2.0 mm
Horizontal difference of center line (2) for the duplex copying: ± 3.0 mm

3. Régler les valeurs.

Pour l'exemple de copie (j) dont l'axe se déplace davantage vers l'avant : augmenter la valeur.

Pour l'exemple de copie (k) dont l'axe se déplace vers l'intérieur : diminuer la valeur.

Changement par graduation d'échelle : 0,085 mm

- 4. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.**
5. Effectuer une copie de test.

6. Répéter les étapes 2 à 5 jusqu'à ce que l'écart de la ligne (2) de l'exemple de copie indique la valeur de référence.

<Valeur de référence>

Différence horizontale de l'axe (2) pour la copie recto : $\pm 2,0$ mm

Différence horizontale de l'axe (2) pour la copie recto-verso : $\pm 3,0$ mm

3. Ajuste los valores.

Si el centro se desplaza más hacia el frente, ejemplo de copia (j): aumenta el valor.

Si el centro se desplaza hacia dentro, ejemplo de copia (k): disminuye el valor.

Magnitud del cambio por incremento: 0,085 mm

- 4. Pulse la tecla de [Inicio] para confirmar el valor de configuración.**
5. Haga una copia de prueba.

6. Repita los pasos 2 a 4 anteriores hasta que la separación de la línea (2) del ejemplo de copia presente el valor de referencia.

<Valor de referencia>

Diferencia horizontal de la línea de centro (2) para el copiado por una cara: $\pm 2,0$ mm

Diferencia horizontal de la línea de centro (2) para el copiado dúplex: $\pm 3,0$ mm

3. Die Werte einstellen.

Wenn die Mitte nach vorne verlagert ist, Kopierbeispiel (j): Den Wert erhöhen.

Wenn die Mitte nach innen verlagert ist, Kopierbeispiel (k): Den Wert verringern.

Änderung pro Schritt: 0,085 mm

- 4. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.**
5. Eine Testkopie erstellen.

6. Die Schritte 2 bis 5 wiederholen, bis der Abstand der Linie (2) des Kopierbeispiels den Bezugswert aufweist.

<Bezugswert>

Horizontaler Unterschied der Mittellinie (2) für die Einzelkopie: $\pm 2,0$ mm

Horizontaler Unterschied der Mittellinie (2) für die Duplexkopie: $\pm 3,0$ mm

3. Regolare i valori.

Se il centro si sposta più avanti, esempio di copia (j): aumenta il valore.

Se il centro si sposta verso l'interno, esempio di copia (k): riduce il valore.

Entità modifica per passo: 0,085 mm

- 4. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.**
5. Eseguire una copia di prova.

6. Ripetere le operazioni sopra descritte da 2 a 5 fino a quando lo scostamento della linea (2) dell'esempio di copia riporterà i valori di riferimento.

<Valore di riferimento>

Differenza orizzontale della linea centrale (2) per la copia singola: $\pm 2,0$ mm

Differenza orizzontale della linea centrale (2) per la copia duplex: $\pm 3,0$ mm

3. 調整設定値。

当中心向前偏移时 复印样本(j): 调高设定值

当中心向内偏移时 复印样本(k): 调低设定值

设定值的一个调整单位变化量: 0.085mm

- 4. 按 [开始] 键, 以确定设定值。**
5. 进行测试复印。

6. 重复上述步骤 2 到 5, 直至复印样本上的线 (2) 的偏移值达到标准值范围内。

<标准值>

单面复印时, 中心线 (2) 的左右偏移值: ± 2.0 mm 以内

双面复印时, 中心线 (2) 的左右偏移值: ± 3.0 mm 以内

3. 설정치를 조정합니다.

센터 앞으로 이동한 경우가 샘플 카피 (j): 설정치를 높입니다.

센터가 뒤로 이동한 경우 샘플 카피 (k): 설정치를 내립니다.

1 스텝당 변화량: 0.085mm

- 4. [복사 / 시작] 키를 누르고 설정치를 확인합니다.**
5. 테스트 카피를 합니다.

6. 샘플 카피 선 (2) 의 차이가 기준치내가 될 때까지 2 ~ 5 를 반복합니다.

<기준치>

단면의 경우 센터라인 (2) 의 좌우차이: ± 2.0 mm 이내

양면의 경우 센터라인 (2) 의 좌우차이: ± 3.0 mm 이내

3. 設定値を調整する。

センターが手前にずれている場合コピーサンプル (j): 設定値を上げる。

センターが奥にずれている場合コピーサンプル (k) 設定値を下げる。

1 ステップ当たりの変化量: 0.085mm


- 4. [スタート] キーを押し、設定値を確定する。**
5. テストコピーを行う。

6. コピーサンプルの線 (2) ずれが基準値内になるまで手順 2 ~ 5 を繰り返す。

<基準値>

片面の場合、中心線 (2) の左右ずれ: ± 2.0 mm 以内

両面の場合、中心線 (2) の左右ずれ: ± 3.0 mm 以内



**[Automatic adjustment using the original for adjustment]
If there is no DP auto adjustment original.**

1. Set the maintenance mode U411 and press [DP Auto Adj] to output the adjustment original.
2. Set the printed original on the contact glass and press the [Start] key.
3. Set the original on the DP face up and press the [Start] key to carry out surface adjustment.

4. Set the original on the DP face down and press the [Start] key to carry out the back side adjustment.
5. "OK" appears on the display and press the [Start] key to complete the adjustment.
* If ERROR XX appears, the adjustment failed. Check the original set position and repeat steps 2 and 4 until "OK" appears.
For details, see the service manual.

**[Réglage automatique en utilisant l'original pour effectuer le réglage]
Si la machine n'est pas pourvue de la fonction réglage automatique d'original du DP**

1. Passez en mode maintenance U411 et appuyez sur [DP Auto Adj] pour imprimer l'original de réglage.
2. Placer l'original qui vient d'être imprimé sur la vitre d'exposition et appuyer sur la touche [Départ].
3. Placer l'original sur le DP côté imprimé en haut et appuyer sur la touche [Départ] pour procéder au réglage de la surface.

4. Placez l'original sur le chargeur de document DP face vers le bas et appuyez sur la touche [Départ] pour effectuer le réglage du verso.
5. "OK" s'affiche sur l'écran. Appuyez sur la touche [Départ] pour terminer le réglage.
* Si le message ERROR XX (erreur XX) s'affiche, le réglage a échoué. Vérifier la position de l'original et recommencer les opérations 2 et 4 jusqu'à ce que le message "OK" apparaisse.
Pour plus de détails, se reporter au manuel d'entretien.

**[Ajuste automático utilizando el original para el ajuste]
Si no existe el original de ajuste automático del DP**

1. Configure el modo de mantenimiento U411 y pulse [DP Auto Adj] para imprimir el original de ajuste.
2. Coloque el original impreso sobre el cristal de contacto y pulse la tecla de [Inicio].
3. Coloque el original en el DP cara arriba y pulse la tecla de [Inicio] para realizar un ajuste de anverso.

4. Coloque el original en el DP boca abajo y pulse la tecla [Inicio] para llevar a cabo un ajuste del reverso.
5. Aparece "OK" en la pantalla. Pulse la tecla [Inicio] para finalizar el ajuste.
* Si aparece ERROR XX, el ajuste ha fallado. Compruebe la posición ajustada del original y repita los pasos 2 y 4 hasta que aparezca "OK" en la pantalla.
Para mas detalles, lea el manual de servicio.

**[Automatische Einstellung mithilfe des Originals]
Falls keine automatische Einstellung des Originals des DP vorhanden ist**

1. Aktivieren Sie den Wartungsmodus U411 und wählen Sie [DP Auto Adj], um das Original für die Anpassung auszudrucken.
2. Das ausgedruckte Original auf das Kontaktglas legen und die [Start]-Taste betätigen.
3. Das Original mit der Druckseite nach oben einlegen und die [Start]-Taste betätigen, um die Oberflächeneinstellung ausführen zu lassen.

4. Legen Sie das Original mit der Druckseite nach unten auf den Vorlageneinzug. Drücken Sie die Taste [Start] und führen Sie die Einstellungen für die Rückseite aus.
5. "OK" erscheint auf der Anzeige. Drücken Sie die Taste [Start], um die Einstellung abzuschließen.
* Wenn ERROR XX (FEHLER XX) angezeigt wird, ist die Einstellung fehlgeschlagen. Überprüfen Sie die Originalpositionierung und wiederholen Sie Schritte 2 und 4, bis "OK" angezeigt wird. Weitere Einzelheiten siehe Wartungsanleitung.

**[Regolazione automatica eseguita con l'originale]
Se non è presente l'autoregolazione originale DP**

1. Impostare la modalità manutenzione U411, quindi premere [DP Auto Adj] per stampare l'originale da utilizzare per la regolazione.
2. Posizionare l'originale stampato sul vetro di appoggio e premere il tasto di [Avvio].
3. Posizionare l'originale sul DP rivolto verso l'alto e premere il tasto di [Avvio] per eseguire la regolazione della superficie.

4. Posizionare l'originale sull'alimentatore di documenti e premere il tasto [Avvio] per eseguire la regolazione del retro.
5. Quando sul display compare "OK", premere il tasto [Avvio] per completare la regolazione.
* Se compare ERROR XX (ERRORE XX), la regolazione non è riuscita. Verificare la posizione di impostazione dell'originale e ripetere le operazioni 2 e 4 fino a quando appare "OK".
Per ulteriori dettagli leggere il manuale d'istruzioni.

[通过调整用原稿进行自动调整]

没有 DP 调整用原稿时

1. 进入维修保养模式 U411, 选择 [DP Auto Adj], 输出测试原稿。
2. 将输出的原稿放在稿台上, 按 [开始] 键。
3. 将原稿面朝上放在 DP 主机上, 按 [开始] 键以进行正面的调整。

4. 把原稿面朝下放置到 DP, 按 [开始] 键, 开始反面调整。
5. 显示屏上显示 "OK", 按 [开始] 键后, 调整结束。
* 如果出现 ERROR XX (错误 XX), 则表示调整失败。检查原稿设定位置并重复步骤 2 和 4, 直到 "OK" (完成) 出现。
详细内容请参照维修手册。

[조정용 원고를 이용한 자동조정]

DP 조정용 원고가 없는 경우

1. 메인テナンス 모드 U411 을 설정하고 [DP Auto Adj] 를 눌러 조정된 원고를 출력합니다 .
2. 출력한 원고를 원고 유리에 장착하고 [복사 / 시작] 키를 누릅니다 .
3. 원고를 FaceUp 으로 DP 에 세트하고 [복사 / 시작] 키를 눌러 표면조정을 합니다 .


4. 원고를 FaceDown 로 DP 에 세트하고 [복사 / 시작] 키를 눌러 뒷면 조정을 합니다 .
5. 디스플레이에 "OK" 가 나타나면 [복사 / 시작] 키를 눌러 조정을 완료 합니다 .
*ERROR XX 가 표시된 경우에는 조정실패입니다 . 원고 장착위치를 확인하고 "OK" 가 표시될 때까지 순서 2 ~ 4 를 반복합니다 .
상세는 서비스 매뉴얼을 참조 .

[調整用原稿による自動調整]

DP 調整用原稿が無い場合

1. メンテナンスモード U411 をセットし、[DP Auto Adj] を押し、原稿を出力する。
2. 出力した原稿をコンタクトガラス上にセットし、[スタート] キーを押す。
3. 原稿を FaceUp で DP へセットし、[スタート] キーを押し、表面の調整を行う。

4. 原稿を FaceDown で DP へセットし、[スタート] キーを押し、裏面の調整を行う。
5. ディスプレイに「OK」が表示され、[スタート] キーを押せば調整完了となる。
※ERROR XX が表示された場合は調整失敗である。原稿のセット位置を確認し、「OK」が表示されるまで手順 2 ~ 4 を繰り返す。
詳細はサービスマニュアルを参照のこと。



Using a DP auto adjustment original

1. Place the front side of the DP auto adjustment original so that the arrow mark appears facing up. Set it on the DP so the leading edge of the arrow mark is facing the DP feed direction.
2. Set the maintenance mode U411 and press [DP FU(ChartB)] > the [Start] key in that order to carry out the front side adjustment.

3. If "OK" appears on the display, the adjustment is complete.

* If ERROR XX appears, the adjustment failed. Check the original set position and repeat steps 1 and 2 until "OK" appears. For details, see the service manual.

Avec la fonction réglage automatique d'original du DP

1. Placez le recto de l'original de réglage du chargeur de document de sorte que la flèche apparaisse sur la face vers le haut. Placez-le sur le chargeur de document de sorte que le bord de tête de la flèche soit orienté dans la direction d'alimentation du chargeur de document.
2. Passez en mode maintenance U411 et appuyez sur [DP FU(ChartB)] > touche [Départ] dans cet ordre pour effectuer le réglage du recto.

3. Si "OK" s'affiche sur l'écran, le réglage est terminé.

* Si le message ERROR XX (erreur XX) s'affiche, le réglage a échoué. Vérifier la position de l'original et recommencer les opérations 1 et 2 jusqu'à ce que le message "OK" apparaisse. Pour plus de détails, se reporter au manuel d'entretien.

Uso del original de ajuste automático del DP

1. Coloque el anverso del original de ajuste automático del alimentador de originales DP de modo que la marca de flecha esté hacia arriba. Colóquelo en el DP de modo que el borde anterior de la marca de flecha esté en la dirección de alimentación del DP.
2. Configure el modo de mantenimiento U411 y pulse [DP FU(ChartB)] > tecla [Inicio] en ese orden para llevar a cabo un ajuste del anverso.

3. Si aparece "OK" en la pantalla, el ajuste se ha completado.

* Si aparece ERROR XX, el ajuste ha fallado. Compruebe la posición ajustada del original y repita los pasos 1 y 2 hasta que aparezca "OK" en la pantalla. Para más detalles, lea el manual de servicio.

Gebrauch der automatischen Einstellung des Originals des DP

1. Legen Sie die Vorderseite des Originals für die automatische Einstellung des Vorlageneinzugs so ein, dass der Pfeil nach oben weist. Legen Sie das Original so in den Vorlageneinzug, dass die Pfeilspitze in die Einzugsrichtung des Vorlageneinzugs weist.
2. Aktivieren Sie den Wartungsmodus U411 und wählen Sie nacheinander [DP FU(ChartB)] > Taste [Start], um die Einstellungen für die Vorderseite vorzunehmen.

3. Wenn "OK" angezeigt wird, ist die Einstellung abgeschlossen.

* Wenn ERROR XX (FEHLER XX) angezeigt wird, ist die Einstellung fehlgeschlagen. Überprüfen Sie die Originalpositionierung und wiederholen Sie Schritte 1 und 2, bis "OK" angezeigt wird. Weitere Einzelheiten siehe Wartungsanleitung.

Uso di un'autoregolazione originale DP

1. Posizionare la facciata anteriore dell'originale da utilizzare per la regolazione automatica dell'alimentatore documenti in modo che la freccia sia rivolta verso l'alto. Posizionarlo sull'alimentatore di documenti in modo che il bordo superiore della freccia sia orientato nella direzione di alimentazione dell'alimentatore di documenti.
2. Impostare la modalità manutenzione U411, quindi premere, nell'ordine, [DP FU(ChartB)] > tasto [Avvio] per eseguire la regolazione della facciata anteriore.

3. Se sul display compare "OK", la regolazione è completata.

* Se compare ERROR XX (ERRORE XX), la regolazione non è riuscita. Verificare la posizione di impostazione dell'originale e ripetere le operazioni 1 e 2 fino a quando appare "OK". Per ulteriori dettagli leggere il manuale d'istruzioni.

使用 DP 自动调整用稿时

1. 把 DP 自动调整原稿的正面（有箭头的一面）向上，同时使箭头的前端方向对准 DP 的走纸方向。
2. 进入维修保养模式 U411，按照 [DP FU(ChartB)] > [开始] 键的顺序按，开始正面调整。

3. 如果显示屏显示 "OK"，则表示调整结束。

* 如果出现 ERROR XX（错误 XX），则表示调整失败。检查原稿设定位置并重复步骤 1 和 2，直到 "OK"（完成）出现。详细内容请参照维修手册。

DP 자동조정용 원고를 사용하는 경우

1. DP 자동 조정원고의 앞면의 화살표가 위로 향하게 세트합니다. 화살표의 선단을 DP 피드방향으로 DP 에 세트합니다.
2. 메인テナンス 모드 U411 을 설정하고 [DP FU(ChartB)] > [복사 / 시작] 키를 눌러 앞면 조정을 수행합니다.

3. 디스플레이에 "OK" 가 표시되면 조정완료가 됩니다.


* ERROR XX 가 표시된 경우에는 조정실패입니다. 원고 장착위치를 확인하고 "OK" 가 표시될 때까지 순서 1 ~ 2 를 반복합니다. 상세는 서비스 매뉴얼을 참조.

DP 自動調整原稿を使用する場合

1. DP 自動調整原稿の表面（矢印が書かれてる面）を上に向け、矢印の先端方向から DP にセットする。
2. メンテナンスモード U411 をセットし、[DP FU(ChartB)] > [スタート] キーの順に押し、表面の調整を行う。

3. ディスプレイに「OK」が表示されれば調整完了となる。

※ERROR XX が表示された場合は調整失敗である。原稿のセット位置を確認し、「OK」が表示されるまで手順 1 ~ 2 を繰り返す。詳細はサービスマニュアルを参照のこと。



4. After completing the adjustment of the front side, place the back side of the DP auto adjustment original so that the arrow mark appears facing down. Set it on the DP so the leading edge of the arrow mark is facing the DP feed direction.
5. Set the maintenance mode U411 and press [DP FD(CharB)] > the [Start] key in that order to carry out the back side adjustment.

6. If "OK" appears on the display, the adjustment is complete.
* If ERROR XX appears, the adjustment failed. Check the original set position and repeat steps 4 and 5 until "OK" appears.
For details, see the service manual.

4. Après avoir terminé le réglage du verso, placez le recto de l'original de réglage du chargeur de document de sorte que la flèche apparaisse sur la face vers le bas. Placez-le sur le chargeur de document de sorte que le bord de tête de la flèche soit orienté dans la direction d'alimentation du chargeur de document.
5. Passez en mode maintenance U411 et appuyez sur [DP FD(CharB)] > touche [Départ] dans cet ordre pour effectuer le réglage du verso.

6. Si "OK" s'affiche sur l'écran, le réglage est terminé.
* Si le message ERROR XX (erreur XX) s'affiche, le réglage a échoué. Vérifier la position de l'original et recommencer les opérations 4 et 5 jusqu'à ce que le message "OK" apparaisse.
Pour plus de détails, se reporter au manuel d'entretien.

4. Después de terminar el ajuste del anverso, coloque el reverso del original de ajuste automático del DP de modo que la marca de flecha esté hacia abajo. Colóquelo en el DP de modo que el borde anterior de la marca de flecha esté en la dirección de alimentación del DP.
5. Configure el modo de mantenimiento U411 y pulse [DP FD(CharB)] > tecla [Inicio] en ese orden para llevar a cabo un ajuste del reverso.

6. Si aparece "OK" en la pantalla, el ajuste se ha completado.
* Si aparece ERROR XX, el ajuste ha fallado. Compruebe la posición ajustada del original y repita los pasos 4 y 5 hasta que aparezca "OK" en la pantalla.
Para más detalles, lea el manual de servicio.

4. Nachdem Sie die Einstellung für die Vorderseite abgeschlossen haben, legen Sie die Rückseite des Originals für die automatische Einstellung des Vorlageneinzugs so ein, dass der Pfeil nach unten weist. Legen Sie das Original so in den Vorlageneinzug, dass die Pfeilspitze in die Einzugsrichtung des Vorlageneinzugs weist.
5. Aktivieren Sie den Wartungsmodus U411 und wählen Sie nacheinander [DP FD(CharB)] > Taste [Start], um die Einstellungen für die Rückseite vorzunehmen.

6. Wenn "OK" angezeigt wird, ist die Einstellung abgeschlossen.
* Wenn ERROR XX (FEHLER XX) angezeigt wird, ist die Einstellung fehlgeschlagen. Überprüfen Sie die Originalpositionierung und wiederholen Sie Schritte 4 und 5, bis "OK" angezeigt wird.
Weitere Einzelheiten siehe Wartungsanleitung.

4. Dopo aver completato la regolazione della facciata anteriore, posizionare il retro dell'originale da utilizzare per la regolazione automatica dell'alimentatore di documenti in modo che la freccia sia rivolta verso il basso. Posizionarlo sull'alimentatore di documenti in modo che il bordo superiore della freccia sia orientato nella direzione di alimentazione dell'alimentatore di documenti.
5. Impostare la modalità manutenzione U411, quindi premere, nell'ordine, [DP FD(CharB)] > tasto [Avvio] per eseguire la regolazione del retro.

6. Se sul display compare "OK", la regolazione è completata.
* Se compare ERROR XX (ERRORE XX), la regolazione non è riuscita. Verificare la posizione di impostazione dell'originale e ripetere le operazioni 4 e 5 fino a quando appare "OK".
Per ulteriori dettagli leggere il manuale d'istruzioni.

4. 正面的調整结束后,把 DP 自动调整原稿的反面(有箭头的一面)向下,同时使箭头的前端方向对准 DP 的走纸方向。
5. 进入维修保养模式 U411,按照 [DP FD(CharB)] > [开始] 键的顺序按键,开始反面调整。

6. 如果显示屏显示 "OK",则表示调整结束。
* 如果出现 ERROR XX (错误 XX),则表示调整失败。检查原稿设定位置并重复步骤 4 和 5,直到 "OK" (完成)出现。
详细内容请参照维修手册。

4. 앞면 조정이 완료되면 화살표가 아래로 향하게 세트합니다. 화살표의 선단을 DP 피드방향으로 DP 에 세트합니다.
5. 메인テナンス 모드 U411 을 설정하고 [DP FD(CharB)] > [복사 / 시작] 키 를 눌러 뒷면 조정을 수행합니다.

6. 디스플레이에 "OK" 가 표시되면 조정완료가 됩니다.
* ERROR XX 가 표시된 경우에는 조정실패입니다. 원고 장착위치를 확인하고 "OK" 가 표시될 때까지 순서 4 ~ 5 를 반복합니다.
상세는 서비스 매뉴얼을 참조

4. 表面の調整完了後、DP 自動調整原稿の裏面(矢印が書かれている面)を下に向け、矢印の先端方向から DP にセットする。
5. メンテナンスモード U411 をセットし、[DP FD(CharB)] > [スタート] キーの順に押し、裏面の調整を行う。


6. ディスプレイに「OK」が表示されれば調整完了となる。
※ERROR XX が表示された場合は調整失敗である。原稿のセット位置を確認し、「OK」が表示されるまで手順 4 ~ 5 を繰り返す。
詳細はサービスマニュアルを参照のこと。

DF-5100

(Inner Finisher)

Installation Guide

DF-5100



4. Set the maintenance mode U246 and select [Finisher] > [Staple HP].
 5. Adjust the values.
 If the paper is stapled too close to the front of the machine (a): Increase the setting value.
 If the paper is stapled too close to the rear of the machine (b): Decrease the setting value.
 Amount of change per step: 0.19 mm

6. Press the [Start] key to confirm the setting value.
 7. Perform a test copy.
 8. Repeat steps 4 to 7 until the staple position is within the reference value.
 <Reference value> 60.0 mm ± 2.0 mm from the center of the paper

4. Passez en mode maintenance U246 et sélectionnez [Finisher] > [Staple HP].
 5. Réglez les valeurs.
 Si le papier est agrafé trop près de l'avant de la machine (a): augmenter la valeur de réglage.
 Si le papier est agrafé trop près de l'arrière de la machine (b): réduire la valeur de réglage.
 Changement par graduation d'échelle : 0,19 mm

6. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
 7. Effectuer une copie de test.
 8. Recommencer les étapes 4 à 7 jusqu'à ce que la position d'agrafe soit conforme à la valeur de référence.
 <Valeur de référence> 60,0 mm ± 2,0 mm depuis le milieu de la feuille de papier

4. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [Staple HP].
 5. Ajuste los valores.
 Si el grapado del papel se encuentra demasiado cerca del frente de la máquina (a): aumente el valor de configuración.
 Si el grapado del papel se encuentra demasiado cerca de la parte posterior de la máquina (b): disminuya el valor de configuración.
 Magnitud del cambio por incremento: 0,19 mm

6. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
 7. Haga una copia de prueba.
 8. Repita los pasos 4 a 7 hasta que la posición de grapado se encuentre dentro del valor de referencia.
 <Valor de referencia> 60,0 mm ± 2,0 mm del centro del papel

4. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [Staple HP].
 5. Die Werte einstellen.
 Falls das Papier zu nahe am vorderen Rand des Geräts (a) abgestapelt wird: Vergrößern Sie den Stellwert.
 Falls das Papier zu nahe am hinteren Rand des Geräts (b) abgestapelt wird: Verkleinern Sie den Stellwert.
 Änderung pro Schritt: 0,19 mm

6. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
 7. Eine Testkopie erstellen.
 8. Wiederholen Sie die Schritte 4 bis 7, bis die Heftposition im Bereich des Bezugswerts liegt.
 <Bezugswert> 60,0 mm ± 2,0 mm von der Blattmitte

4. Impostare la modalità manutenzione U246, quindi selezionare [Finisher] > [Staple HP].
 5. Regolare i valori.
 Se il foglio viene spillato troppo vicino alla parte anteriore della macchina (a): Aumentare il valore di impostazione.
 Se il foglio viene spillato troppo vicino alla parte posteriore della macchina (b): Diminuire il valore di impostazione.
 Entità modifica per passo: 0,19 mm

6. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
 7. Eseguire una copia di prova.
 8. Ripetere i passi 4 to 7 finché la posizione di spillatura risulta all'interno del valore di riferimento.
 <Valore di riferimento> 60,0 mm ± 2,0 mm dal centro del foglio

4. 进入维修保养模式 U246, 把 [Finisher]>[Staple HP]。
 5. 调整设定值。
 装订位置向机器前部偏移时 (a): 调高设定值。
 装订位置向机器后部偏移时 (b): 调低设定值。
 设定值的一个调整单位变化量: 0.19mm



6. 按 [开始] 键, 以确定设定值。
 7. 进行测试复印。
 8. 重复步骤 4 ~ 7, 直到装订位置在基准范围内为止。
 <基准值> 距离纸张中心 60.0mm±2.0mm

4. 메인テナンス 모드 U246 을 설정하고 [Finisher] > [Staple HP] 를 선택합니다.
 5. 설정치를 조정합니다.
 스테이플 위치가 기기앞측으로 벗어난 경우 (a): 설정치를 높입니다.
 스테이플 위치가 기기뒷측으로 벗어난 경우 (b): 설정치를 낮춥니다.
 1 스텝당 변화량: 0.19mm


6. [복사 / 시작] 키를 누르고 설정치를 확인합니다.
 7. 시험복사를 합니다.
 8. 스테이플 위치가 기준치내에 될 때까지 순서 4 ~ 7 을 반복합니다.
 < 기준치 > 용지 센터에서 60.0mm±2.0mm

4. メンテナンスモード U246 をセットし、[Finisher] > [Staple HP] を選択する。
 5. 設定値を調整する。
 ステープル位置が機械前側にずれている場合 (a): 設定値を上げる。
 ステープル位置が機械後側にずれている場合 (b): 設定値を下げる。
 1 ステップ当たりの変化量: 0.19mm


6. [スタート] キーを押し、設定値を確認する。
 7. テストコピーを行う。
 8. ステープル位置が基準値内になるまで、手順 4 ~ 7 を繰り返す。
 < 基準値 > 用紙センターより 60.0mm±2.0mm




7




8





9



10



11



English

Adjusting the stapling position

1. Connect the machine power plug to the wall outlet and turn the machine main power switch on.
2. Make a test copy using staple mode (double stapled).
3. Check whether the stapling position is off-center. If the staple position is off-center, follow the procedure below to adjust the position.
<Reference value> 60.0 mm \pm 2.0 mm from the center of the paper

Français

Ajustement de la position d'agrafage

1. Insérer la fiche d'alimentation de la machine dans la prise murale et mettre la machine sous tension.
2. Procéder à une copie d'essai en mode agrafage (double agrafage).
3. Vérifier que la position d'agrafage n'est pas en décalage. Si la position d'agrafage est décalée, la régler en procédant de la manière suivante.
<Valeur de référence> 60,0 mm \pm 2,0 mm depuis le milieu de la feuille de papier

Español

Ajuste de la posición de grapado

1. Conecte el enchufe de la máquina al receptáculo de pared y encienda el interruptor principal de la máquina.
2. Haga una copia de prueba en el modo de grapado (grapado doble).
3. Compruebe si la posición de grapado está descentrada. Si la posición de grapado está descentrada, realice el siguiente procedimiento para ajustar la posición.
<Valor de referencia> 60,0 mm \pm 2,0 mm del centro del papel

Deutsch

Justage der Heftposition

1. Stecken Sie den Netzstecker des Geräts in die Wandsteckdose und schalten Sie das Gerät am Gauptschalter ein.
2. Erstellen Sie eine Probekopie im Heftmodus (doppelt geheftet).
3. Prüfen Sie, ob die Heftposition außermittig ist. Falls die Heftposition außermittig ist, müssen Sie sie wie folgend einstellen.
<Bezugswert> 60,0 mm \pm 2,0 mm von der Blattmitte

Italiano

Regolazione della posizione di pinzatura

1. Collegare la spina alla presa di corrente a muro e accendere l'interruttore di alimentazione della macchina.
2. Eseguire una copia di prova utilizzando la modalità di spillatura con punti metallici (spillatura doppia).
3. Verificare che la posizione di spillatura non sia fuori centro. Se la posizione di spillatura è fuori centro, seguire la procedura riportata sotto per regolare la posizione.
<Valore di riferimento> 60,0 mm \pm 2,0 mm dal centro del foglio

简体中文

调节装订位置

1. 将机器上的电源插头插入电源插座中，打开主电源开关。
2. 在装订模式（2点固定）下进行测试复印。
3. 确认装订位置的中心偏差。装订位置偏离中心时，按以下步骤进行调节。
<基准值> 距离纸张中心 60.0mm \pm 2.0mm

한국어

스태이플 위치 조정

1. 본체 전원플러그를 콘센트에 꽂고 주 전원 스위치를 ON으로 합니다.
2. 스타이플 모드 (2점 고정) 에서 시험복사를 합니다.
3. 스타이플 위치의 센터 어긋남을 확인합니다. 스타이플 위치가 중심에서 벗어난 경우, 다음 순서로 조정을 합니다.
<기준치> 용지 센터에서 60.0mm \pm 2.0mm

日本語

ステーブル位置の調整

1. 機械本体の電源プラグをコンセントに差し込み、主電源スイッチをONにする。
2. ステーブルモード(2箇所止め)でテストコピーを行う。
3. ステーブル位置のセンターずれを確認する。ステーブル位置が中心からずれていた場合、次の手順で調整を行う。
<基準値> 用紙センターより 60.0mm \pm 2.0mm

DF-5110

(1000 sheets Finisher)

Installation Guide

INSTALLATION GUIDE

GUIDE D'INSTALLATION

GUÍA DE INSTALACION

INSTALLATIONSANLEITUNG


GUIDA ALL'INSTALLAZIONE








安装手册









설치안내서






設置手順書


DF-5110











English

Adjusting the stapling position

1. Connect the machine power plug to the wall outlet and turn the machine main power switch on.
2. Make a test copy using staple mode (double stapled).
3. Check whether the stapling position is off-center. If the staple position is off-center, follow the procedure below to adjust the position.
<Reference value> 60.0 mm \pm 2.0 mm from the center of the paper

Français

Ajustement de la position d'agrafage

1. Insérer la fiche d'alimentation de la machine dans la prise murale et mettre la machine sous tension.
2. Procéder à une copie d'essai en mode agrafage (double agrafage).
3. Vérifier que la position d'agrafage n'est pas en décalage. Si la position d'agrafage est décalée, la régler en procédant de la manière suivante.
<Valeur de référence> 60,0 mm \pm 2,0 mm depuis le milieu de la feuille de papier

Español

Ajuste de la posición de grapado

1. Conecte el enchufe de la máquina al receptáculo de pared y encienda el interruptor principal de la máquina.
2. Haga una copia de prueba en el modo de grapado (grapado doble).
3. Compruebe si la posición de grapado está descentrada. Si la posición de grapado está descentrada, realice el siguiente procedimiento para ajustar la posición.
<Valor de referencia> 60,0 mm \pm 2,0 mm del centro del papel

Deutsch

Justage der Heftposition

1. Stecken Sie den Netzstecker des Geräts in die Wandsteckdose und schalten Sie das Gerät am Hauptschalter ein.
2. Erstellen Sie eine Probekopie im Heftmodus (doppelt geheftet).
3. Prüfen Sie, ob die Heftposition außermittig ist. Falls die Heftposition außermittig ist, müssen Sie sie wie folgend einstellen.
<Bezugswert> 60,0 mm \pm 2,0 mm von der Blattmitte

Italiano

Regolazione della posizione di pinzatura

1. Collegare la spina alla presa di corrente a muro e accendere l'interruttore di alimentazione della macchina.
2. Eseguire una copia di prova utilizzando la modalità di spillatura con punti metallici (spillatura doppia).
3. Verificare che la posizione di spillatura non sia fuori centro. Se la posizione di spillatura è fuori centro, seguire la procedura riportata sotto per regolare la posizione.
<Valore di riferimento> 60,0 mm \pm 2,0 mm dal centro del foglio

简体中文

调节装订位置

1. 将机器上的电源插头插入电源插座中，打开主电源开关。
2. 在装订模式（2点固定）下进行测试复印。
3. 确认装订位置的偏差。装订位置偏离中心时，按以下步骤进行调节。
<基准值> 距离纸张中心 60.0mm \pm 2.0mm

한국어


스태이플 위치 조정

1. 본체 전원플러그를 콘센트에 꽂고 주 전원 스위치를 ON으로 합니다.
2. 스타이플 모드(2점)에서 시험복사를 합니다.
3. 스타이플 위치의 센터 어긋남을 확인합니다. 스타이플 위치가 중심에서 벗어난 경우, 다음 순서로 조정을 합니다.
<기준치> 용지 센터에서 60.0mm \pm 2.0mm

日本語

ステーブル位置の調整

1. 機械本体の電源プラグをコンセントに差し込み、主電源スイッチをONにする。
2. ステーブルモード(2箇所止め)でテストコピーを行う。
3. ステーブル位置のセンターずれを確認する。ステーブル位置が中心からずれていた場合、次の手順で調整を行う。
<基準値> 用紙センターより 60.0mm \pm 2.0mm



4. Set the maintenance mode U246 and select [Finisher] > [Staple HP].
 5. Adjust the values.
 If the paper is stapled too close to the front of the machine (a): Increase the setting value.
 If the paper is stapled too close to the rear of the machine (b): Decrease the setting value.
 Amount of change per step: 0.19 mm

6. Press the [Start] key to confirm the setting value.
 7. Perform a test copy.
 8. Repeat steps 4 to 7 until the staple position is within the reference value.
 <Reference value> 60.0 mm \pm 2.0 mm from the center of the paper

4. Passez en mode maintenance U246 et sélectionnez [Finisher] > [Staple HP].
 5. Régler les valeurs.
 Si le papier est agrafé trop près de l'avant de la machine (a): augmenter la valeur de réglage.
 Si le papier est agrafé trop près de l'arrière de la machine (b): réduire la valeur de réglage.
 Changement par graduation d'échelle : 0,19 mm

6. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
 7. Effectuer une copie de test.
 8. Recommencer les étapes 4 à 7 jusqu'à ce que la position d'agrafe soit conforme à la valeur de référence.
 <Valeur de référence> 60,0 mm \pm 2,0 mm depuis le milieu de la feuille de papier

4. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [Staple HP].
 5. Ajuste los valores.
 Si el grapado del papel se encuentra demasiado cerca del frente de la máquina (a): aumente el valor de configuración.
 Si el grapado del papel se encuentra demasiado cerca de la parte posterior de la máquina (b): disminuya el valor de configuración.
 Magnitud del cambio por incremento: 0,19 mm

6. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
 7. Haga una copia de prueba.
 8. Repita los pasos 4 a 7 hasta que la posición de grapado se encuentre dentro del valor de referencia.
 <Valor de referencia> 60,0 mm \pm 2,0 mm del centro del papel

4. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [Staple HP].
 5. Die Werte einstellen.
 Falls das Papier zu nahe am vorderen Rand des Geräts (a) abgestapelt wird: Vergrößern Sie den Stellwert.
 Falls das Papier zu nahe am hinteren Rand des Geräts (b) abgestapelt wird: Verkleinern Sie den Stellwert.
 Änderung pro Schritt: 0,19 mm

6. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
 7. Eine Testkopie erstellen.
 8. Wiederholen Sie die Schritte 4 bis 7, bis die Heftposition im Bereich des Bezugswerts liegt.
 <Bezugswert> 60,0 mm \pm 2,0 mm von der Blattmitte

4. Impostare la modalità manutenzione U246, quindi selezionare [Finisher] > [Staple HP].
 5. Regolare i valori.
 Se il foglio viene spillato troppo vicino alla parte anteriore della macchina (a): Aumentare il valore di impostazione.
 Se il foglio viene spillato troppo vicino alla parte posteriore della macchina (b): Diminuire il valore di impostazione.
 Entità modifica per passo: 0,19 mm

6. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
 7. Eseguire una copia di prova.
 8. Ripetere i passi 4 to 7 finché la posizione di spillatura risulta all'interno del valore di riferimento.
 <Valore di riferimento> 60,0 mm \pm 2,0 mm dal centro del foglio

4. 进入维修保养模式 U246, 把 [Finisher]>[Staple HP]。
 5. 调整设定值。
 装订位置向机器前部偏移时 (a): 调高设定值。
 装订位置向机器后部偏移时 (b): 调低设定值。
 设定值的一个调整单位变化量: 0.19mm

6. 按 [开始] 键, 以确定设定值。
 7. 进行测试复印。
 8. 重复步骤 4 ~ 7, 直到装订位置在基准范围内为止。
 <基准值> 距离纸张中心 60.0mm \pm 2.0mm

4. 메인テナンス 모드 U246 을 설정하고 [Finisher] > [Staple HP] 를 선택합니다.
 5. 설정치를 조정합니다.
 스테이플 위치가 기기앞측으로 벗어난 경우 (a): 설정치를 높입니다.
 스테이플 위치가 기기뒷측으로 벗어난 경우 (b): 설정치를 낮춥니다.
 1 스텝당 변화량: 0.19mm

6. [복사 / 시작] 키를 누르고 설정치를 확인합니다.
 7. 시험복사를 합니다.
 8. 스테이플 위치가 기준치내가 될 때까지 순서 4 ~ 7 을 반복합니다.
 < 기준치 > 용지 센터에서 60.0mm \pm 2.0mm

4. メンテナンスモード U246 をセットし、[Finisher] > [Staple HP] を選択する。
 5. 設定値を調整する。
 ステープル位置が機械前側にずれている場合 (a): 設定値を上げる。
 ステープル位置が機械後側にずれている場合 (b): 設定値を下げる。
 1 ステップ当たりの変化量: 0.19mm

6. [スタート] キーを押し、設定値を確定する。
 7. テストコピーを行う。
 8. ステープル位置が基準値内になるまで、手順 4 ~ 7 を繰り返す。
 < 基準値 > 用紙センターより 60.0mm \pm 2.0mm

DF-5120

(3000 sheets Finisher)

Installation Guide

INSTALLATION GUIDE

GUIDE D'INSTALLATION

GUÍA DE INSTALACION

INSTALLATIONSANLEITUNG


GUIDA ALL'INSTALLAZIONE









安装手册









설치안내서








設置手順書


DF-5120











English

Adjusting the stapling position

1. Connect the machine power plug to the wall outlet and turn the machine main power switch on.
2. Make a test copy using staple mode (double stapled).
3. Check whether the stapling position is off-center. If the staple position is off-center, follow the procedure below to adjust the position.
<Reference value> 60.0 mm \pm 2.0 mm from the center of the paper

Français

Ajustement de la position d'agrafage

1. Insérer la fiche d'alimentation de la machine dans la prise murale et mettre la machine sous tension.
2. Procéder à une copie d'essai en mode agrafage (double agrafage).
3. Vérifier que la position d'agrafage n'est pas en décalage. Si la position d'agrafage est décalée, la régler en procédant de la manière suivante.
<Valeur de référence> 60,0 mm \pm 2,0 mm depuis le milieu de la feuille de papier

Español

Ajuste de la posición de grapado

1. Conecte el enchufe de la máquina al receptáculo de pared y encienda el interruptor principal de la máquina.
2. Haga una copia de prueba en el modo de grapado (grapado doble).
3. Compruebe si la posición de grapado está descentrada. Si la posición de grapado está descentrada, realice el siguiente procedimiento para ajustar la posición.
<Valor de referencia> 60,0 mm \pm 2,0 mm del centro del papel

Deutsch

Justage der Heftposition

1. Stecken Sie den Netzstecker des Geräts in die Wandsteckdose und schalten Sie das Gerät am Hauptschalter ein.
2. Erstellen Sie eine Probekopie im Heftmodus (doppelt geheftet).
3. Prüfen Sie, ob die Heftposition außermittig ist. Falls die Heftposition außermittig ist, müssen Sie sie wie folgend einstellen.
<Bezugswert> 60,0 mm \pm 2,0 mm von der Blattmitte

Italiano

Regolazione della posizione di pinzatura

1. Collegare la spina alla presa di corrente a muro e accendere l'interruttore di alimentazione della macchina.
2. Eseguire una copia di prova utilizzando la modalità di spillatura con punti metallici (spillatura doppia).
3. Verificare che la posizione di spillatura non sia fuori centro. Se la posizione di spillatura è fuori centro, seguire la procedura riportata sotto per regolare la posizione.
<Valore di riferimento> 60,0 mm \pm 2,0 mm dal centro del foglio

简体中文

调节装订位置

1. 将机器上的电源插头插入电源插座中，打开主电源开关。
2. 在装订模式（2点固定）下进行测试复印。
3. 确认装订位置的偏差。装订位置偏离中心时，按以下步骤进行调节。
<基准值> 距离纸张中心 60.0mm \pm 2.0mm

한국어


스태플 위치 조정

1. 본체 전원플러그를 콘센트에 꽂고 주 전원 스위치를 ON으로 합니다.
2. 스타플 모드(2점)에서 시험복사를 합니다.
3. 스타플 위치의 센터 어긋남을 확인합니다. 스타플 위치가 중심에서 벗어난 경우, 다음 순서로 조정을 합니다.
<기준치> 용지 센터에서 60.0mm \pm 2.0mm

日本語

ステーブル位置の調整

1. 機械本体の電源プラグをコンセントに差し込み、主電源スイッチをONにする。
2. ステーブルモード(2箇所止め)でテストコピーを行う。
3. ステーブル位置のセンターずれを確認する。ステーブル位置が中心からずれていた場合、次の手順で調整を行う。
<基準値> 用紙センターより 60.0mm \pm 2.0mm



4. Set the maintenance mode U246 and select [Finisher] > [Staple HP].
5. Adjust the values.
If the paper is stapled too close to the front of the machine (a): Increase the setting value.
If the paper is stapled too close to the rear of the machine (b): Decrease the setting value.
Amount of change per step: 0.19 mm

6. Press the [Start] key to confirm the setting value.
7. Perform a test copy.
8. Repeat steps 4 to 7 until the staple position is within the reference value.
<Reference value> 60.0 mm \pm 2.0 mm from the center of the paper

4. Passez en mode maintenance U246 et sélectionnez [Finisher] > [Staple HP].
5. Régler les valeurs.
Si le papier est agrafé trop près de l'avant de la machine (a): augmenter la valeur de réglage.
Si le papier est agrafé trop près de l'arrière de la machine (b): réduire la valeur de réglage.
Changement par graduation d'échelle : 0,19 mm

6. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
7. Effectuer une copie de test.
8. Recommencer les étapes 4 à 7 jusqu'à ce que la position d'agrafe soit conforme à la valeur de référence.
<Valeur de référence> 60,0 mm \pm 2,0 mm depuis le milieu de la feuille de papier

4. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [Staple HP].
5. Ajuste los valores.
Si el grapado del papel se encuentra demasiado cerca del frente de la máquina (a): aumente el valor de configuración.
Si el grapado del papel se encuentra demasiado cerca de la parte posterior de la máquina (b): disminuya el valor de configuración.
Magnitud del cambio por incremento: 0,19 mm

6. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
7. Haga una copia de prueba.
8. Repita los pasos 4 a 7 hasta que la posición de grapado se encuentre dentro del valor de referencia.
<Valor de referencia> 60,0 mm \pm 2,0 mm del centro del papel

4. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [Staple HP].
5. Die Werte einstellen.
Falls das Papier zu nahe am vorderen Rand des Geräts (a) abgestapelt wird: Vergrößern Sie den Stellwert.
Falls das Papier zu nahe am hinteren Rand des Geräts (b) abgestapelt wird: Verkleinern Sie den Stellwert.
Änderung pro Schritt: 0,19 mm

6. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
7. Eine Testkopie erstellen.
8. Wiederholen Sie die Schritte 4 bis 7, bis die Heftposition im Bereich des Bezugswerts liegt.
<Bezugswert> 60,0 mm \pm 2,0 mm von der Blattmitte

4. Impostare la modalità manutenzione U246, quindi selezionare [Finisher] > [Staple HP].
5. Regolare i valori.
Se il foglio viene spillato troppo vicino alla parte anteriore della macchina (a): Aumentare il valore di impostazione.
Se il foglio viene spillato troppo vicino alla parte posteriore della macchina (b): Diminuire il valore di impostazione.
Entità modifica per passo: 0,19 mm

6. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
7. Eseguire una copia di prova.
8. Ripetere i passi 4 to 7 finché la posizione di spillatura risulta all'interno del valore di riferimento.
<Valore di riferimento> 60,0 mm \pm 2,0 mm dal centro del foglio

4. 进入维修保养模式 U246, 把 [Finisher]>[Staple HP] 。
5. 调整设定值。
装订位置向机器前部偏移时 (a) : 调高设定值。
装订位置向机器后部偏移时 (b) : 调低设定值。
设定值的一个调整单位变化量 : 0.19mm

6. 按 [开始] 键, 以确定设定值。
7. 进行测试复印。
8. 重复步骤 4 ~ 7, 直到装订位置在基准范围内为止。
<基准值> 距离纸张中心 60.0mm \pm 2.0mm

4. 메인テナンス 모드 U246 을 설정하고 [Finisher] > [Staple HP] 를 선택합니다 .
5. 설정치를 조정합니다 .
스테이플 위치가 기기앞측으로 벗어난 경우 (a): 설정치를 높입니다 .
스테이플 위치가 기기뒷측으로 벗어난 경우 (b): 설정치를 낮춥니다 .
1 스텝당 변화량 : 0.19mm

6. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .
7. 시험복사를 합니다 .
8. 스테이플 위치가 기준치내가 될 때까지 순서 4 ~ 7 을 반복합니다 .
< 기준치 > 용지 센터에서 60.0mm \pm 2.0mm

4. メンテナンスモード U246 をセットし, [Finisher] > [Staple HP] を選択する。
5. 設定値を調整する。
ステープル位置が機械前側にずれている場合 (a) : 設定値を上げる。
ステープル位置が機械後側にずれている場合 (b) : 設定値を下げる。
1 ステップ当たりの変化量 : 0.19mm

6. [スタート] キーを押し、設定値を確定する。
7. テストコピーを行う。
8. ステープル位置が基準値内になるまで、手順 4 ~ 7 を繰り返す。
< 基準値 > 用紙センターより 60.0mm \pm 2.0mm

[Adjusting the hole punch position]

1. Connect the MFP power plug to the wall outlet and turn the MFP main power switch on.
2. Make a test copy in punch mode.
3. If any off-centering is observed, follow the procedure below to adjust the hole position.
(For the reference value, refer to each adjustment content.)

[Réglage de la position des perforations]

1. Insérer la fiche d'alimentation du MFP dans la prise murale et mettre l'interrupteur principal du MFP sous tension.
2. Effectuer une copie d'essai en mode perforation.
3. Si les perforations sont décentrées, suivre la procédure ci-dessous pour ajuster la position de perforation.
(Pour la valeur de référence, se reporter à chaque contenu d'ajustement.)

[Ajuste de la posición de perforación]

1. Conecte el enchufe del MFP en el receptáculo de pared y encienda el interruptor principal del MFP.
2. Haga una copia de prueba en el modo de perforación.
3. Si observa descentrado, siga el procedimiento de abajo para ajustar la posición del agujero.
(Para información sobre el valor de referencia, consulte el contenido de cada ajuste.)

[Einstellen der Lochungsposition]

1. Stecken Sie den Netzstecker des MFP in die Wandsteckdose und schalten Sie den MFP am Hauptschalter ein.
2. Eine Testkopie im Lochungsmodus erstellen.
3. Falls eine außermittige Lochung erfolgte, ist die Lochungsposition wie folgend nachzustellen.
(Den Referenzwert finden Sie im jeweiligen Einstellungsabschnitt.)

[Regolazione di posizione dei fori di perforazione]

1. Collegare la spina del cavo di alimentazione dell'MFP alla presa a muro della rete elettrica e accendere l'interruttore principale di alimentazione.
2. Eseguire una copia di prova in modalità di perforazione.
3. Nel caso in cui non lo siano, eseguire la procedura indicata qui di seguito per regolarne la posizione.
(Per informazioni sul valore di riferimento vedere il contenuto di ogni regolazione.)

[打孔位置的调节]


1. 将 MFP 主机上的电源插头插入电源插座中, 打开主电源开关。
2. 在打孔模式下进行测试复印。
3. 打孔位置有偏差时, 按以下步骤进行调节。
(标准值请参照各调整内容。)

[핀치위치의 조정]

1. MFP 본체 전원플러그를 콘센트에 꽂고 주 전원 스위치를 ON 으로 합니다.
2. 펀치모드에서 시험복사를 합니다.
3. 펀치위치가 벗어난 경우에는 다음 순서로 조정합니다.
(기준 값에 대해서는 각 조정 내용을 참조하십시오.)

[パンチ位置の調整]

1. MFP 本体の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。
2. パンチモードでテストコピーを行う。
3. パンチ位置がずれていた場合、次の手順で調整を行う。
(基準値は、各調整内容を参照のこと。)



Adjusting the hole punch entry registration

1. Set the maintenance mode U246 and select [Finisher] > [Punch Regist].
2. Adjust the values.
When the paper fed in skewed copy example (a): Increase the setting value.
When the paper crimped copy example (b): Decrease the setting value.
Amount of change per step: 0.19mm
3. Press the [Start] key to confirm the setting value.

Réglage de l'enregistrement de l'entrée des perforations

1. Passer en mode maintenance U246, sélectionner [Finisher] > [Punch Regist].
2. Régler les valeurs.
Si le papier est alimenté de travers exemple de copie (a): Augmentez la valeur de réglage.
Si le papier est froissé exemple de copie (b): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19mm
3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.

Ajuste del registro de entrada de perforación

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [Punch Regist].
2. Ajuste los valores.
Cuando el papel alimentado está torcido copia de muestra (a): Aumente el valor de configuración.
Cuando el papel se dobló copia de muestra (b): Reduzca el valor de configuración.
Magnitud del cambio por incremento: 0,19mm
3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.

Einstellen der Lochungsregistrierung

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [Punch Regist].
2. Die Werte einstellen.
Wenn Papier verkantet eingezogen wird Kopiebeispiel (a): Den Einstellwert erhöhen.
Wenn Papier verknittert wird Kopiebeispiel (b): Den Einstellwert verringern.
Änderung pro Schritt: 0,19mm
3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.

Regolazione del registro del foro di perforazione

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [Punch Regist].
2. Regolare i valori.
Quando l'alimentazione della carta risulta obliqua esempio di copia (a): Aumentare il valore dell'impostazione.
Quando la carta risulta increspata esempio di copia (b): Diminuire il valore dell'impostazione.
Entità modifica per passo: 0,19mm
3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.

打孔装入定位调节


1. 进入维修保养模式 U246, 把 [Finisher] > [Punch Regist].
2. 调整设定值。
纸张斜向搬运时的复印样本 (a): 调高设定值。
纸张作 Z 字折时的复印样本 (b): 调低设定值。
设定值的一个调整单位变化量: 0.19mm
3. 按 [开始] 键, 以确定设定值。

펀치반입 레지스트 조정

1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [Punch Regist] 를 선택합니다 .
2. 설정치를 조정합니다 .
용지가 기울어져서 반송되는 경우의 복사샘플 (a): 설정치를 높입니다 .
용지가 Z 꺾임이 있는 경우 복사샘플 (b): 설정치를 내립니다 .
1 스텝당 변화량: 0.19mm
3. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .

パンチ搬入レジスト調整

1. メンテナンスモード U246 をセットし、[Finisher] > [Punch Regist] を選択する。
2. 設定値を調整する。
用紙が斜めに搬送される場合コピーサンプル (a): 設定値を上げる。
用紙が Z 折れる場合コピーサンプル (b): 設定値を下げる。
1 ステップ当たりの変化量: 0.19mm
3. [スタート] キーを押し、設定値を確定する。



Adjusting the hole punch position feed

1. Set the maintenance mode U246 and select [Finisher] > [Punch Feed].
2. Adjust the values.
If the punch hole position is closer to the edge than the reference value (c): Increase the setting value.
If the punch hole position is further from the edge than the reference value (c): Decrease the setting value.
Amount of change per step: 0.52mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (c)>
Metric specification: 13.0mm ±2mm
Inch specification: 9.5mm ±2mm (0.37" ± 0.08")

Réglage de la position du point de perforation

1. Passer en mode maintenance U246, sélectionner [Finisher] > [Punch Feed].
2. Régler les valeurs.
Si la perforation est plus proche du bord de la feuille que défini par la valeur de référence (c): Augmentez la valeur de réglage.
Si la perforation est plus loin du bord de la feuille que défini par la valeur de référence (c): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,52mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (c)>
Spécifications métriques: 13,0mm ±2mm
Spécifications en pouces: 9,5mm ±2mm (0,37" ± 0,08")

Ajuste de la alimentación de la posición de perforación

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [Punch Feed].
2. Ajuste los valores.
Si la posición de perforación está más cerca del borde que el valor de referencia (c): Aumente el valor de configuración.
Si la posición de perforación está más alejada del borde que el valor de referencia (c): Reduzca el valor de configuración.
Magnitud del cambio por incremento: 0,52mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (c)>
Sistema métrico: 13,0mm ±2mm
En pulgadas: 9,5mm ±2mm (0,37" ± 0,08")

Einstellen des Transports der Lochungsposition

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [Punch Feed].
2. Die Werte einstellen.
Falls die Lochungsposition näher an der Kante liegt als der Bezugswert (c) erlaubt: Den Einstellwert erhöhen.
Falls die Lochungsposition ferner von der Kante liegt als der Bezugswert (c) erlaubt: Den Einstellwert verringern. Änderung pro Schritt: 0,52 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (c)>
Metrischer Abstand: 13,0mm ±2mm
Abstand in Zoll: 9,5mm ±2mm (0,37" ± 0,08")

Regolazione spostamento di posizione dei fori di perforazione

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [Punch Feed].
2. Regolare i valori.
Se la posizione dei fori di perforazione è più vicina al bordo rispetto al valore di riferimento (c): Aumentare il valore dell'impostazione.
Se la posizione dei fori di perforazione è più lontana dal bordo rispetto al valore di riferimento (c): Diminuire il valore dell'impostazione.
Entità modifica per passo: 0,52 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (c)>
Specificazione in unità metrica: 13,0mm ±2mm
Specificazione in pollici: 9,5mm ±2mm (0,37" ± 0,08")

打孔位置搬运调节

1. 进入维修保养模式 U246, 把 [Finisher] > [Punch Feed]。
2. 调整设定值。
打孔位置比基准值 (c) 短时: 调高设定值。
打孔位置比基准值 (c) 长时: 调低设定值。
设定值的一个调整单位变化量: 0.52mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (c)>
公制规格: 13.0mm ±2mm
英制规格: 9.5mm ±2mm (0.37" ± 0.08")

펀치위치 반송조정


1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [Punch Feed] 를 선택합니다 .
2. 설정치를 조정합니다 .
펀치구멍의 위치가 기준치 (c) 보다 짧은 경우: 설정치를 높입니다 .
펀치구멍의 위치가 기준치 (c) 보다 긴 경우: 설정치를 내립니다 .
1 스텝당 변화량: 0.52mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .
4. 테스트 카피를 합니다 .
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행합니다 .
< 기준치 (c) >
센티사양: 13.0mm ±2mm
인치사양: 9.5mm ±2mm (0.37" ± 0.08")

パンチ位置搬送調整

1. メンテナンスモード U246 をセットし、[Finisher] > [Punch Feed] を選択する。
2. 設定値を調整する。
パンチ穴の位置が基準値 (c) より短い場合: 設定値を上げる。
パンチ穴の位置が基準値 (c) より長い場合: 設定値を下げる。
1 ステップ当たりの変化量: 0.52mm

3. [スタート] キーを押し、設定値を確定する。
4. テストコピーを行う。
5. パンチ穴の位置が基準値内になるまで、手順 1 ~ 4 を繰り返す。
< 基準値 (c) >
センチ仕様: 13.0mm ±2mm
インチ仕様: 9.5mm ±2mm (0.37" ± 0.08")



Centering the hole punch position

1. Set the maintenance mode U246 and select [Finisher] > [Punch Width].
2. Adjust the values.
If the punch hole is too close to the front of the machine: Decrease the setting value.
If the punch hole is too close to the rear of the machine: Increase the setting value.
Amount of change per step: 0.52mm

Centrage de la position de perforation

1. Passer en mode maintenance U246, sélectionner [Finisher] > [Punch Width].
2. Régler les valeurs.
Si la perforation est trop proche de l'avant de la machine: Diminuez la valeur de réglage.
Si la perforation est trop proche de l'arrière de la machine: Augmentez la valeur de réglage.
Changement par graduation d'échelle: 0,52mm

Centrado de la posición de perforación

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [Punch Width].
2. Ajuste los valores.
Si la perforación se encuentra demasiado cerca del frente de la máquina: Reduzca el valor de configuración.
Si la perforación se encuentra demasiado cerca de la parte trasera de la máquina: Aumente el valor de configuración.
Magnitud del cambio por incremento: 0,52 mm

Zentrieren der Stanzlochposition

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [Punch Width].
2. Die Werte einstellen.
Falls die Lochung zu nah an der Gerätefront liegt: Den Einstellwert verringern.
Falls die Lochung zu weit weg von der Gerätefront liegt: Den Einstellwert erhöhen.
Änderung pro Schritt: 0,52 mm

Centratura della posizione dei fori di perforazione

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [Punch Width].
2. Regolare i valori.
Se la posizione dei fori di perforazione è troppo vicina alla parte anteriore della macchina: Diminuire il valore dell'impostazione.
Se la posizione dei fori di perforazione è troppo vicina alla parte posteriore della macchina: Aumentare il valore dell'impostazione.
Entità modifica per passo: 0,52 mm

打孔位置中心调节

1. 进入维修保养模式 U246，把 [Finisher] > [Punch Width]。
2. 调整设定值。
打孔位置向机器前部偏移时：调低设定值。
打孔位置向机器后部偏移时：调高设定值。
设定值的一个调整单位变化量：0.52mm

펀치위치 센터조정

1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [Punch Width] 를 선택합니다 .
2. 설정치를 조정합니다 .
펀치구멍의 위치가 기기 앞쪽으로 벗어난 경우: 설정치를 내립니다 .
펀치구멍의 위치가 기기 뒷쪽으로 벗어난 경우: 설정치를 높입니다 .
1 스텝당 변화량: 0.52mm

パンチ位置センター調整

1. メンテナンスモード U246 をセットし、[Finisher] > [Punch Width] を選択する。
2. 設定値を調整する。
パンチ穴の位置が機械前側にずれている場合: 設定値を下げる。
パンチ穴の位置が機械後側にずれている場合: 設定値を上げる。
1 ステップ当たりの変化量: 0.52mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (d) >
Metric specification: d = 40.0mm ± 2mm, e=80.0mm±0.5mm (e:Unadjustable)
Inch specification: d = 34.93mm ± 2mm (1.38" ± 0.08"), e=69.85mm±0.5mm(2.75"±0.02") (e:Unadjustable)

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (d) >
Spécifications métriques: d = 40,0mm ± 2mm , e=80.0mm±0.5mm(e:Ajustement impossible)
Spécifications en pouces: d = 34,93 mm ± 2mm (1,38" ± 0,08"), e=69.85mm±0.5mm(2.75"±0.02") (e:Ajustement impossible)

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (d) >
Sistema métrico: d = 40,0mm ± 2mm, e=80.0mm±0.5mm (e:No ajustable)
En pulgadas: d = 34,93mm ± 2mm (1,38" ± 0,08"), e=69.85mm±0.5mm(2.75"±0.02") (e:No ajustable)


3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (d) >
Metrischer Abstand: d = 40,0mm ± 2mm, e=80.0mm±0.5mm (e:Nicht einstellbar)
Abstand in Zoll: d = 34,93 mm ± 2mm (1,38" ± 0,08"), e=69.85mm±0.5mm(2.75"±0.02") (e:Nicht einstellbar)

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (d) >
Specificazione in unità metrica: d = 40,0mm ± 2mm, e=80.0mm±0.5mm (e:Non regolabile)
Specificazione in pollici: d = 34,93 mm ± 2mm (1,38" ± 0,08"), e=69.85mm±0.5mm(2.75"±0.02")(e:Non regolabile)

3. 按 [开始] 键，以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4，直至打孔的孔的位置达到标准值。
<基准值 (d) >
公制规格: d=40.0mm±2mm, e=80.0mm±0.5mm (e:不可调整)
英制规格: d=34.93mm±2mm(1.38" ± 0.08"), e=69.85mm±0.5mm(2.75" ± 0.02") (e:不可调整)

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .
4. 테스트 카피를 합니다 .
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행합니다 .
<기준치 (d) >
센터사양: d=40.0mm±2mm, e=80.0mm±0.5mm (e: 조정 불가)
인치사양: d=34.93mm±2mm(1.38" ± 0.08"), e=69.85mm±0.5mm(2.75" ± 0.02") (e: 조정 불가)

3. [スタート] キーを押し、設定値を確定する。
4. テストコピーを行う。
5. パンチ穴の位置が基準値内になるまで、手順 1 ~ 4 を繰り返す。
<基準値 (d) >
センチ仕様: d=40.0mm±2mm, e=80.0mm±0.5mm (e: 調整不可)
インチ仕様: d=34.93mm±2mm(1.38" ± 0.08"), e=69.85mm±0.5mm(2.75" ± 0.02") (e: 調整不可)



Adjusting the long-edge hole punch position (width)

1. Set the maintenance mode U246 and select [Finisher] > [Punch(L) Width].
2. Adjust the values.
If the punch hole position is closer to the edge than the reference value (f): Increase the setting value.
If the punch hole position is further from the edge than the reference value (f): Decrease the setting value. Amount of change per step: 0.19 mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (f)>
Metric specification: 13.0mm ± 1mm
Inch specification: 9.5mm ± 1mm (0.37" ± 0.04")

Ajustement de la position de perforation sur le bord long (largeur)

1. Passer en mode maintenance U246, sélectionner [Finisher] > [Punch(L)Width].
2. Régler les valeurs.
Si la perforation est plus proche du bord de la feuille que défini par la valeur de référence (f): Augmentez la valeur de réglage.
Si la perforation est plus loin du bord de la feuille que défini par la valeur de référence (f): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19 mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (f) >
Spécifications métriques: 13,0mm ±1mm
Spécifications en pouces: 9,5mm ±1mm (0,37" ±0,04")

Ajuste de la posición de perforación de agujeros en el borde largo (ancho)

1. Configurar el modo de mantenimiento U246 y seleccionar [Finisher] > [Punch(L)Width].
2. Ajuste los valores.
Si la posición de perforación está más cerca del borde que el valor de referencia (f): Aumente el valor de configuración.
Si la posición de perforación está más alejada del borde que el valor de referencia (f): Reduzca el valor de configuración.
Magnitud del cambio por incremento: 0,19 mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (f)>
Sistema métrico: 13,0mm ±1mm
En pulgadas: 9,5mm ±1mm (0,37" ±0,04")

Lochposition der langen Seite einstellen (Breite)

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [Punch(L) Width].
2. Die Werte einstellen.
Falls die Lochungposition näher an der Kante liegt als der Bezugswert (f) erlaubt: Den Einstellwert erhöhen.
Falls die Lochungposition ferner von der Kante liegt als der Bezugswert (f) erlaubt: Den Einstellwert verringern. Änderung pro Schritt: 0,19 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (f) >
Metrischer Abstand: 13,0mm ±1mm
Abstand in Zoll: 9,5mm ±1mm (0,37" ± 0,04")

Regolazione della posizione di foratura sul lato lungo (larghezza)

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [Punch(L)Width].
2. Regolare i valori.
Se la posizione dei fori di perforazione è più vicina al bordo rispetto al valore di riferimento (f): Aumentare il valore dell'impostazione.
Se la posizione dei fori di perforazione è più lontana dal bordo rispetto al valore di riferimento (f): Diminuire il valore dell'impostazione.
Entità modifica per passo: 0,19 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (f)>
Specificazione in unità metrica: 13,0mm ±1mm
Specificazione in pollici: 9,5mm ±1mm (0,37" ± 0,04")

长边打孔位置调整(宽度)

1. 进入维修保养模式 U246, 把 [Finisher] > [Punch(L)Width].
2. 调整设定值。
打孔位置比基准值 (f) 短时: 调高设定值。
打孔位置比基准值 (f) 长时: 调低设定值。
设定值的一个调整单位变化量: 0.19mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (f) >
公制规格: 13.0mm ± 1mm
英制规格: 9.5mm ± 1mm (0.37" ± 0.04")

긴 면 1 공 펀치 위치 조정 (폭)


1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [Punch(L)Width] 를 선택합니다 .
2. 설정치를 조정합니다 .
펀치구멍의 위치가 기준치 (f) 보다 짧은 경우: 설정치를 높입니다 .
펀치구멍의 위치가 기준치 (f) 보다 긴 경우: 설정치를 내립니다 .
1 스텝당 변화량: 0.19mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .
4. 테스트 카피를 합니다 .
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행 합니다 .
< 기준치 (f) >
센티사양: 13.0mm ± 1mm
인치사양: 9.5mm ± 1mm (0.37" ± 0.04")

長辺パンチ位置調整(幅)

1. メンテナンスモード U246 をセットし, [Finisher] > [Punch(L) Width] を選択する.
2. 設定値を調整する.
パンチ穴位置が基準値 (f) より短い場合: 設定値を上げる.
パンチ穴位置が基準値 (f) より長い場合: 設定値を下げる.
1 ステップ当たりの変化量: 0.19mm

3. [スタート] キーを押し, 設定値を確定する.
4. テストコピーを行う.
5. パンチ穴の位置が基準値内になるまで, 手順 1 ~ 4 を繰り返す.
< 基準値 (f) >
センチ仕様: 13.0mm ± 1mm
インチ仕様: 9.5mm ± 1mm (0.37" ± 0.04")



(Table.1)

| | g |
|---------|---------------|
| LetterR | 99.7mm ± 1mm |
| A4R | 108.5mm ± 1mm |
| B5R | 88.5mm ± 1mm |
| 16開R | 96.5mm ± 1mm |

(Table.2)

| | g |
|---------|-------------------------------|
| LetterR | 104.8mm ± 1mm (4.13" ± 0.04") |
| A4R | 113.6mm ± 1mm (4.47" ± 0.04") |
| B5R | 93.6mm ± 1mm (3.69" ± 0.04") |
| 16開R | 101.6mm ± 1mm (4.0" ± 0.04") |

Adjusting the long-edge 2-hole punch position (1st hole)

1. Set the maintenance mode U246 and select [Finisher] > [2Punch(L) 1].
2. Adjust the values.
If the 1st hole punch position is shorter than the reference (g): Increase the setting value.
If the 1st hole punch position is longer than the reference (g): Decrease the setting value.
Amount of change per step: 0.19 mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (g)>
Metric specification: Refer to (Table.1) above.
Inch specification: Refer to (Table.2) above.

Ajustement de la position de perforation à 2 trous sur le bord long (1er trou)

1. Passer en mode maintenance U246, sélectionner [Finisher] > [2Punch(L)1].
2. Régler les valeurs.
Si la position de perforation du 1er trou est plus courte que la référence (g): Augmentez la valeur de réglage.
Si la position de perforation du 1er trou est plus longue que la référence (g): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19 mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (g) >
Spécifications métriques: Se reporter au (Table.1) ci-dessus.
Spécifications en pouces: Se reporter au (Table.2) ci-dessus.

Ajuste de la posición de perforación de 2 agujeros en el borde largo (1er agujero)

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [2Punch(L)1].
2. Ajuste los valores.
Si la posición de perforación del 1er agujero es más corta que la de referencia (g): Aumente el valor de configuración.
Si la posición de perforación del 1er agujero es más larga que la de referencia (g): Reduzca el valor de configuración. Magnitud del cambio por incremento: 0,19 mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (g)>
Sistema métrico: Consulte (Table.1) arriba.
En pulgadas: Consulte (Table.2) arriba.

2-fach Lochposition der langen Seite einstellen (1. Lochposition)

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [2Punch(L)1].
2. Die Werte einstellen.
Falls die erste Lochposition kürzer als die Referenz (g) ist: Den Einstellwert erhöhen.
Falls die erste Lochposition länger als die Referenz (g) ist: Den Einstellwert verringern. Änderung pro Schritt: 0,19 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (g) >
Metrischer Abstand: Siehe oben (Table.1).
Abstand in Zoll: Siehe oben (Table.2).

Regolazione della posizione di foratura a due fori sul lato lungo (1° foro)

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [2Punch(L)1].
2. Regolare i valori.
Se la posizione di foratura 1 è più corta rispetto al riferimento (g): Aumentare il valore dell'impostazione.
Se la posizione di foratura 1 è più lunga rispetto al riferimento (g): Diminuire il valore dell'impostazione. Entità modifica per passo: 0,19 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (g)>
Specificazione in unità metrica: Fare riferimento alla (Table.1) sopra riportata.
Specificazione in pollici: Fare riferimento alla (Table.2) sopra riportata.

2 孔长边打孔位置调整 (第 1 孔)

1. 进入维修保养模式 U246, 把 [Finisher] > [2Punch(L)1].
2. 调整设定值。
第 1 孔的位置比标准值 (g) 短时: 调高设定值。
第 1 孔的位置比标准值 (g) 长时: 调低设定值。
设定值的一个调整单位变化量: 0.19mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (g) >
公制规格: 参照上图 (Table. 1)
英制规格: 参照上图 (Table. 2)

긴 면 2 공 펀치 위치 조정 (첫 번째)


1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [2Punch(L)1] 를 선택합니다.
2. 설정치를 조정합니다.
첫 번째 펀치 구멍 위치가 기준 (g) 보다 짧은 경우: 설정치를 높입니다.
첫 번째 펀치 구멍 위치가 기준 (g) 보다 긴 경우: 설정치를 낮춥니다.
1 스텝당 변화량: 0.19mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다.
4. 테스트 카피를 합니다.
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행합니다.
< 기준치 (g) >
센티사양: 위의 그림 (Table. 1) 을 참조하십시오.
인치사양: 위의 그림 (Table. 2) 을 참조하십시오.

2 穴長辺パンチ位置調整 (1 穴目)

1. メンテナンスモード U246 をセットし, [Finisher] > [2Punch(L)1] を選択する。
2. 設定値を調整する。
1 穴目の位置が基準値 (g) より短い場合: 設定値を上げる。
1 穴目の位置が基準値 (g) より長い場合: 設定値を下げる。
1 ステップ当たりの変化量: 0.19mm

3. [スタート] キーを押し, 設定値を確定する。
4. テストコピーを行う。
5. パンチ穴の位置が基準値内になるまで, 手順 1 ~ 4 を繰り返す。
< 基準値 (g) >
センチ仕様: 上図 Table. 1 参照
インチ仕様: 上図 Table. 2 参照



Adjusting the long-edge 2-hole punch position (2nd hole)

1. Set the maintenance mode U246 and select [Finisher] > [2Punch(L)2].
2. Adjust the values.
If the 2nd hole punch position is shorter than the reference (h): Increase the setting value.
If the punch hole position is further from the edge than the reference value (h): Decrease the setting value.
Amount of change per step: 0.19 mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (h)>
Metric specification: 80.0mm ± 0.5mm
Inch specification: 69.85mm ± 0.5mm (2.75" ± 0.02")

Ajustement de la position de perforation à 2 trous sur le bord long (2e trou)

1. Passer en mode maintenance U246, sélectionner [Finisher] > [2Punch (L)2].
2. Régler les valeurs.
Si la position de perforation du 2e trou est plus courte que la référence (h): Augmentez la valeur de réglage.
Si la position de perforation du 2e trou est plus longue que la référence (h): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19 mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (h) >
Spécifications métriques: d = 80mm ± 0,5mm
Spécifications en pouces: d = 69,85mm ± 0,5mm (2,75" ± 0,02")

Ajuste de la posición de perforación de 2 agujeros en el borde largo (2º agujero)

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [2Punch(L)2].
2. Ajuste los valores.
Si la posición de perforación del 2er agujero es más corta que la de referencia (h): Aumente el valor de configuración.
Si la posición de perforación del 2er agujero es más larga que la de referencia (h): Reduzca el valor de configuración.
Magnitud del cambio por incremento: 0,19 mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (h)>
Sistema métrico: 80.0mm ±0.5mm
En pulgadas: 69,85mm ±0,5mm (2,75" ± 0,02")

2-fach Lochposition der langen Seite einstellen (2. Lochposition)

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [2Punch(L)2].
2. Die Werte einstellen.
Falls die zweite Lochposition kürzer als die Referenz (h) ist: Den Einstellwert erhöhen.
Falls die zweite Lochposition länger als die Referenz (h) ist: Den Einstellwert verringern. Änderung pro Schritt: 0,19 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (h) >
Metrischer Abstand: 80,0mm ± 0,5mm
Abstand in Zoll: 69,85mm ± 0,5mm (2,75" ± 0,02")

Regolazione della posizione di foratura a due fori sul lato lungo (2° foro)

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [2Punch(L)2].
2. Regolare i valori.
Se la posizione di foratura 2 è più corta rispetto al riferimento (h): Aumentare il valore dell'impostazione.
Se la posizione di foratura 2 è più lunga rispetto al riferimento (h): Diminuire il valore dell'impostazione. Entità modifica per passo: 0,19 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (h)>
Specificazione in unità metrica: 80,0mm ±0,5mm
Specificazione in pollici: 69,85mm ±0,5mm (2,75" ± 0,02")

2 孔长边打孔位置调整 (第 2 孔)

1. 进入维修保养模式 U246, 把 [Finisher] > [2Punch(L)2].
2. 调整设定值。
第 2 孔的位置比标准值 (h) 短时: 调高设定值。
第 2 孔的位置比标准值 (h) 长时: 调低设定值。
设定值的一个调整单位变化量: 0.19mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (h) >
公制规格: 80.0mm ± 0.5mm
英制规格: 69.85mm ± 0.5mm (2.75" ± 0.02")

긴 면 2공 펀치 위치 조정 (두 번째 공)


1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [2Punch(L)2] 를 선택합니다.
2. 설정치를 조정합니다.
두 번째 펀치 구멍 위치가 기준 (h) 보다 짧은 경우: 설정치를 높입니다.
두 번째 펀치 구멍 위치가 기준 (h) 보다 긴 경우: 설정치를 내립니다.
1 스텝당 변화량: 0.19mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다.
4. 테스트 카피를 합니다.
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행합니다.
< 기준치 (h) >
센티사양: 80.0mm ± 0.5mm
인치사양: 69.85mm ± 0.5mm (2.75" ± 0.02")

2 穴長辺パンチ位置調整 (2 穴目)

1. メンテナンスモード U246 をセットし, [Finisher] > [2Punch(L)2] を選択する。
2. 設定値を調整する。
2 穴目の位置が基準値 (h) より短い場合: 設定値を上げる。
2 穴目の位置が基準値 (h) より長い場合: 設定値を下げる。
1 ステップ当たりの変化量: 0.19mm

3. [スタート] キーを押し, 設定値を確定する。
4. テストコピーを行う。
5. パンチ穴の位置が基準値内になるまで, 手順 1 ~ 4 を繰り返す。
< 基準値 (h) >
センチ仕様: 80.0mm ± 0.5mm
インチ仕様: 69.85mm ± 0.5mm (2.75" ± 0.02")



(Table.1)

| | i |
|-----|--------------|
| A4R | 28.5mm ± 1mm |

(Table.2)

| | i |
|---------|------------------------------|
| LetterR | 31.8mm ± 1mm (1.25" ± 0.04") |
| A4R | 40.5mm ± 1mm (1.59" ± 0.04") |
| 16開R | 28.5mm ± 1mm (1.12" ± 0.04") |

Adjusting the long-edge 3-hole or 4-hole punch position (1st hole)

1. Set the maintenance mode U246 and select [Finisher] > [3/4Punch(L)1].
2. Adjust the values.
If the 1st hole punch position is shorter than the reference (i): Increase the setting value.
If the 1st hole punch position is longer than the reference (i): Decrease the setting value.
Amount of change per step: 0.19 mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (i)>
Metric specification(4-hole): Refer to (Table.1) above.
Inch specification(3-hole): Refer to (Table.2) above.

Ajustement de la position de perforation à 3 ou 4 trous sur le bord long (1er trou)

1. Passer en mode maintenance U246, sélectionner [Finisher] > [3/4Punch (L)1].
2. Régler les valeurs.
Si la position de perforation du 1er trou est plus courte que la référence (i): Augmentez la valeur de réglage.
Si la position de perforation du 1er trou est plus longue que la référence (i): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19 mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (i) >
Spécifications métriques(4 trous): Se reporter au (Table.1) ci-dessus.
Spécifications en pouces(3 trous): Se reporter au (Table.2) ci-dessus.

Ajuste de la posición de perforación de 3 o 4 agujeros en el borde largo (1er agujero)

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [3/4Punch(L)1].
2. Ajuste los valores.
Si la posición de perforación del 1er agujero es más corta que la de referencia (i): Aumente el valor de configuración.
Si la posición de perforación del 1er agujero es más larga que la de referencia (i): Reduzca el valor de configuración. Magnitud del cambio por incremento: 0,19 mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (i)>
Sistema métrico(4 agujeros): Consulte (Table.1) arriba.
En pulgadas(3 agujeros): Consulte (Table.2) arriba.

3-fach oder 4-fach Lochposition der langen Seite einstellen (1. Lochposition)

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [3/4Punch(L)1].
2. Die Werte einstellen.
Falls die erste Lochposition kürzer als die Referenz (i) ist: Den Einstellwert erhöhen.
Falls die erste Lochposition länger als die Referenz (i) ist: Den Einstellwert verringern. Änderung pro Schritt: 0,19 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (i) >
Metrischer Abstand(4-fach Lochung): Siehe oben (Table.1).
Abstand in Zoll(3-fach Lochung): Siehe oben (Table.2).

Regolazione della posizione di foratura a tre o quattro fori sul lato lungo (1° foro)

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [3/4Punch(L)1].
2. Regolare i valori.
Se la posizione di foratura 1 è più corta rispetto al riferimento (i): Aumentare il valore dell'impostazione.
Se la posizione di foratura 1 è più lunga rispetto al riferimento (i): Diminuire il valore dell'impostazione. Entità modifica per passo: 0,19 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (i)>
Specificazione in unità metrica(4 fori): Fare riferimento alla (Table.1) sopra riportata.
Specificazione in pollici(3 fori): Fare riferimento alla (Table.2) sopra riportata.

3 孔、4 孔长边打孔位置调整 (第 1 孔)

1. 进入维修保养模式 U246, 把 [Finisher] > [3/4Punch(L)1]。
2. 调整设定值。
第 1 孔的位置比标准值 (i) 短时: 调高设定值。
第 1 孔的位置比标准值 (i) 长时: 调低设定值。
设定值的一个调整单位变化量: 0.19mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (i) >
公制规格 (4 孔): 参照上图 (Table.1)
英制规格 (3 孔): 参照上图 (Table.2)

긴 면 3 공 또는 4 공 편치 위치 조정 (첫 번째 구멍)


1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [3/4Punch(L)1] 를 선택합니다.
2. 설정치를 조정합니다.
첫 번째 편치 구멍 위치가 기준 (i) 보다 짧은 경우: 설정치를 높입니다.
첫 번째 편치 구멍 위치가 기준 (i) 보다 긴 경우: 설정치를 낮춥니다.
1 스텝당 변화량: 0.19mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다.
4. 테스트 카피를 합니다.
5. 편치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행합니다.
< 기준치 (i) >
센티사양 (4 공): 위의 그림 (Table.1) 을 참조하십시오.
인치사양 (3 공): 위의 그림 (Table.2) 을 참조하십시오.

3 穴、4 穴長辺パンチ位置調整 (1 穴目)

1. メンテナンスモード U246 をセットし、[Finisher] > [3/4Punch (L) 1] を選択する。
2. 設定値を調整する。
1 穴目の位置が基準値 (i) より短い場合: 設定値を上げる。
1 穴目の位置が基準値 (i) より長い場合: 設定値を下げる。
1 ステップ当たりの変化量: 0.19mm

3. [スタート] キーを押し、設定値を確定する。
4. テストコピーを行う。
5. パンチ穴の位置が基準値内になるまで、手順 1 ~ 4 を繰り返す。
< 基準値 (i) >
センチ仕様 (4 穴): 上図 Table.1 参照
インチ仕様 (3 穴): 上図 Table.2 参照



Adjusting the long-edge 3-hole or 4-hole punch position (2nd hole)

1. Set the maintenance mode U246 and select [Finisher] > [3/4Punch(L)2].
2. Adjust the values.
If the 2nd hole punch position is shorter than the reference (j): Increase the setting value.
If the 2nd hole punch position is longer than the reference (j): Decrease the setting value.
Amount of change per step: 0.19 mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (j)>
Metric specification(4-hole): 80.0mm ± 0.5mm
Inch specification(3-hole): 107.95mm ± 0.5mm (4.25" ± 0.02")

Ajustement de la position de perforation à 3 ou 4 trous sur le bord long (2e trou)

1. Passer en mode maintenance U246, sélectionner [Finisher] > [3/4Punch(L)2].
2. Régler les valeurs.
Si la position de perforation du 2e trou est plus courte que la référence (j): Augmentez la valeur de réglage.
Si la position de perforation du 2e trou est plus longue que la référence (j): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19 mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (j) >
Spécifications métriques(4 trous): d = 80,0mm ± 0,5mm
Spécifications en pouces(3 trous): d = 107,95mm ± 0,5mm (2,75" ± 0,02")

Ajuste de la posición de perforación de 3 o 4 agujeros en el borde largo (2º agujero)

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [3/4Punch(L)2].
2. Ajuste los valores.
Si la posición de perforación del 2º agujero es más corta que la de referencia (j): Aumente el valor de configuración.
Si la posición de perforación del 2º agujero es más larga que la de referencia (j): Reduzca el valor de configuración. Magnitud del cambio por incremento: 0,19 mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (j)>
Sistema métrico(4 agujeros): 80,0mm±0,5mm
En pulgadas(3 agujeros): 107,95mm±1mm (4,25" ± 0,02")

3-fach oder 4-fach Lochposition der langen Seite einstellen (2. Lochposition)

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [3/4Punch(L)2].
2. Die Werte einstellen.
Falls die zweite Lochposition kürzer als die Referenz (j) ist: Den Einstellwert erhöhen.
Falls die zweite Lochposition länger als die Referenz (j) ist: Den Einstellwert verringern. Änderung pro Schritt: 0,19 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (j) >
Metrischer Abstand(4-fach Lochung): 80,0mm ± 0,5mm
Abstand in Zoll(3-fach Lochung): 107,95mm ± 0,5mm(4,25" ± 0,02")

Regolazione della posizione di foratura a tre o quattro fori sul lato lungo (2º foro)

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [3/4Punch(L)2].
2. Regolare i valori.
Se la posizione di foratura 2 è più corta rispetto al riferimento (j): Aumentare il valore dell'impostazione.
Se la posizione di foratura 2 è più lunga rispetto al riferimento (j): Diminuire il valore dell'impostazione. Entità modifica per passo: 0,19 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (j)>
Specificazione in unità metrica(4 fori): 80,0mm ± 0,5mm
Specificazione in pollici(3 fori): 107,95mm ± 0,5mm (4,25" ± 0,02")

3 孔、4 孔长边打孔位置调整 (第 2 孔)

1. 进入维修保养模式 U246, 把 [Finisher] > [3/4Punch(L)2]。
2. 调整设定值。
第 2 孔的位置比标准值 (j) 短时: 调高设定值。
第 2 孔的位置比标准值 (j) 长时: 调低设定值。
设定值的一个调整单位变化量: 0.19mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (j) >
公制规格 (4 孔): 80.0mm ± 0.5mm
英制规格 (3 孔): 107.95mm ± 0.5mm (4.25" ± 0.02")

긴 면 3 공 또는 4 공 펀치 위치 조정 (두 번째 구멍)


1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [3/4Punch(L)2] 를 선택합니다 .
2. 설정치를 조정합니다 .
첫 번째 펀치 구멍 위치가 기준 (j) 보다 짧은 경우: 설정치를 높입니다 .
첫 번째 펀치 구멍 위치가 기준 (j) 보다 긴 경우: 설정치를 낮춥니다 .
1 스텝당 변화량: 0.19mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .
4. 테스트 카피를 합니다 .
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행 합니다 .
< 기준치 (j) >
센티사양 (4 공): 80.0mm ± 0.5mm
인치사양 (3 공): 107.95mm ± 0.5mm (4.25" ± 0.02")

3 穴、4 穴長辺パンチ位置調整 (2 穴目)

1. メンテナンスモード U246 をセットし、[Finisher] > [3/4Punch(L)2] を選択する。
2. 設定値を調整する。
2 穴目の位置が基準値 (j) より短い場合: 設定値を上げる。
2 穴目の位置が基準値 (j) より長い場合: 設定値を下げる。
1 ステップ当たりの変化量: 0.19mm

3. [スタート] キーを押し、設定値を確定する。
4. テストコピーを行う。
5. パンチ穴の位置が基準値内になるまで、手順 1 ~ 4 を繰り返す。
< 基準値 (j) >
センチ仕様 (4 穴): 80.0mm ± 0.5mm
インチ仕様 (3 穴): 107.95mm ± 0.5mm (4.25" ± 0.02")



Adjusting the long-edge 3-hole or 4-hole punch position (3rd hole)

1. Set the maintenance mode U246 and select [Finisher] > [3/4Punch(L)3].
2. Adjust the values.
If the 3rd hole punch position is shorter than the reference (k): Increase the setting value.
If the 3rd hole punch position is longer than the reference (k): Decrease the setting value.
Amount of change per step: 0.19 mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (k)>
Metric specification(4-hole): 160.0 mm ± 0.5mm
Inch specification(3-hole) : 215.9 mm ± 0.5mm (8.5" ± 0.02")

Ajustement de la position de perforation à 3 ou 4 trous sur le bord long (3e trou)

1. Passer en mode maintenance U246, sélectionner [Finisher] > [3/4Punch(L)3].
2. Régler les valeurs.
Si la position de perforation du 3e trou est plus courte que la référence (k): Augmentez la valeur de réglage.
Si la position de perforation du 3e trou est plus longue que la référence (k): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19 mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (k) >
Spécifications métriques(4 trous): 160,0mm ± 0,5mm
Spécifications en pouces(3 trous): 215,9 mm ± 0,5mm (8,5" ± 0,02")

Ajuste de la posición de perforación de 3 o 4 agujeros en el borde largo (3er agujero)

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [3/4Punch(L)3].
2. Ajuste los valores.
Si la posición de perforación del 3er agujero es más corta que la de referencia (k): Aumente el valor de configuración.
Si la posición de perforación del 3er agujero es más larga que la de referencia (k): Reduzca el valor de configuración. Magnitud del cambio por incremento: 0,19 mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (k)>
Sistema métrico(4 agujeros): 160,0mm±0,5mm
En pulgadas(3 agujeros): 215,9mm±1mm (8,5" ± 0,02")

3-fach oder 4-fach Lochposition der langen Seite einstellen (3. Lochposition)

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [3/4Punch(L)3].
2. Die Werte einstellen.
Falls die dritte Lochposition kürzer als die Referenz (k) ist: Den Einstellwert erhöhen.
Falls die dritte Lochposition länger als die Referenz (k) ist: Den Einstellwert verringern. Änderung pro Schritt: 0,19 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (k) >
Metrischer Abstand(4-fach Lochung):160,0mm ±0,5mm
Abstand in Zoll(3-fach Lochung):215,9mm ±0,5mm(8,5" ±0,02")

Regolazione della posizione di foratura a tre o quattro fori sul lato lungo (3° foro)

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [3/4Punch(L)3].
2. Regolare i valori.
Se la posizione di foratura 3 è più corta rispetto al riferimento (k): Aumentare il valore dell'impostazione.
Se la posizione di foratura 3 è più lunga rispetto al riferimento (k): Diminuire il valore dell'impostazione. Entità modifica per passo: 0,19 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (k)>
Specificazione in unità metrica(4 fori): 160,0mm ±0,5mm
Specificazione in pollici(3 fori): 215,9mm ±0,5mm (8,5" ± 0,02")

3 孔、4 孔长边打孔位置调整 (第 3 孔)

1. 进入维修保养模式 U246, 把 [Finisher] > [3/4Punch(L)3]。
2. 调整设定值。
第 3 孔的位置比标准值 (k) 短时: 调高设定值。
第 3 孔的位置比标准值 (k) 长时: 调低设定值。
设定值的一个调整单位变化量: 0.19mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (k) >
公制规格 (4 孔): 160.0mm ± 0.5mm
英制规格 (3 孔): 215.9mm ± 0.5mm (8.5" ± 0.02")

긴 면 3 공 또는 4 공 펀치 위치 조정 (세 번째 구멍)


1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [3/4Punch(L)3] 를 선택합니다.
2. 설정치를 조정합니다.
세 번째 펀치 구멍 위치가 기준 (K) 보다 짧은 경우: 설정치를 높입니다.
세 번째 펀치 구멍 위치가 기준 (K) 보다 긴 경우: 설정치를 낮춥니다.
1 스텝당 변화량: 0.19mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다.
4. 테스트 카피를 합니다.
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행합니다.
< 기준치 (k) >
센티사양 (4 공): 160.0mm ± 0.5mm
인치사양 (3 공): 215.9mm ± 0.5mm (8.5" ± 0.02")

3 穴、4 穴長辺パンチ位置調整 (3 穴目)

1. メンテナンスモード U246 をセットし、[Finisher] > [3/4Punch(L)3] を選択する。
2. 設定値を調整する。
3 穴目の位置が基準値 (k) より短い場合: 設定値を上げる。
3 穴目の位置が基準値 (k) より長い場合: 設定値を下げる。
1 ステップ当たりの変化量: 0.19mm

3. [スタート] キーを押し、設定値を確定する。
4. テストコピーを行う。
5. パンチ穴の位置が基準値内になるまで、手順 1 ~ 4 を繰り返す。
< 基準値 (k) >
センチ仕様 (4 穴): 160.0mm ± 0.5mm
インチ仕様 (3 穴): 215.9mm ± 0.5mm (8.5" ± 0.02")



Adjusting the long-edge 4-hole punch position (4th hole)

1. Enter the maintenance mode U246, select [Finisher] > [4Punch(L)4].
2. Adjust the values.
If the 4th hole punch position is shorter than the reference (l): Increase the setting value.
If the 4th hole punch position is longer than the reference (l): Decrease the setting value.
Amount of change per step: 0.19 mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (l)>
Metric specification(4-hole): 240.0 mm ± 0.5mm

Ajustement de la position de perforation à 4 trous sur le bord long (4e trou)

1. Passer en mode maintenance U246, sélectionner [Finisher] > [4Punch(L)4].
2. Régler les valeurs.
Si la position de perforation du 4e trou est plus courte que la référence (l): Augmentez la valeur de réglage.
Si la position de perforation du 4e trou est plus longue que la référence (l): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19 mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (l) >
Spécifications métriques(4 trous): 240,0mm ± 0,5mm

Ajuste de la posición de perforación de 4 agujeros en el borde largo (4º agujero)

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [4Punch(L)4].
2. Ajuste los valores.
Si la posición de perforación del 4º agujero es más corta que la de referencia (l): Aumente el valor de configuración.
Si la posición de perforación del 4º agujero es más larga que la de referencia (l): Reduzca el valor de configuración. Magnitud del cambio por incremento: 0,19 mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (l)>
Sistema métrico(4 agujeros): 240,0mm±0,5mm

4-fach Lochposition der langen Seite einstellen (4. Lochposition)

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [4Punch(L)4].
2. Die Werte einstellen.
Falls die vierte Lochposition kürzer als die Referenz (l) ist: Den Einstellwert erhöhen.
Falls die vierte Lochposition länger als die Referenz (l) ist: Den Einstellwert verringern. Änderung pro Schritt: 0,19 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (l) >
Metrischer Abstand(4-fach Lochung): 240,0mm ±0,5mm

Regolazione della posizione di foratura a quattro fori sul lato lungo (4° foro)

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [4Punch(L)4].
2. Regolare i valori.
Se la posizione di foratura 4 è più corta rispetto al riferimento (l): Aumentare il valore dell'impostazione.
Se la posizione di foratura 4 è più lunga rispetto al riferimento (l): Diminuire il valore dell'impostazione. Entità modifica per passo: 0,19 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (l)>
Specificazione in unità metrica(4 fori): 240,0mm ±0,5mm

4孔长边打孔位置调整(第4孔)

1. 进入维修保养模式 U246, 把 [Finisher] > [4Punch(L)4].
2. 调整设定值。
第4孔的位置比标准值(1)短时: 调高设定值。
第4孔的位置比标准值(1)长时: 调低设定值。
设定值的一个调整单位变化量: 0.19mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (1) >
公制规格 (4孔): 240.0mm ± 0.5mm

긴 면 4공 펀치 위치 조정 (네 번째 구멍)

1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [4Punch(L)4] 를 선택합니다 .
2. 설정치를 조정합니다 .
네번째 펀치 구멍 위치가 기준 (l) 보다 짧은 경우: 설정치를 높입니다 .
네번째 펀치 구멍 위치가 기준 (l) 보다 긴 경우: 설정치를 내립니다 .
1 스텝당 변화량: 0.19mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .
4. 테스트 카피를 합니다 .
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행합니다 .
<기준치 (l) >
센티사양 (4 공): 240.0mm ± 0.5mm

4穴長辺パンチ位置調整 (4穴目)

1. メンテナンスモード U246 をセットし, [Finisher] > [4Punch(L)4] を選択する。
2. 設定値を調整する。
4穴目の位置が基準値(1)より短い場合: 設定値を上げる。
4穴目の位置が基準値(1)より長い場合: 設定値を下げる。
1ステップ当たりの変化量: 0.19mm









3. [スタート] キーを押し, 設定値を確定する。
4. テストコピーを行う。
5. パンチ穴の位置が基準値内になるまで, 手順 1 ~ 4 を繰り返す。
<基準値 (1) >
センチ仕様 (4穴): 240.0mm ± 0.5mm

AK-5100

(Bridge Unit)

Installation Guide

AK-5100










303PY5671001




MT-5100

(Mail Box)

Installation Guide

MT-5100





PH-5100/5110

(Punch Unit)

Installation Guide

INSTALLATION GUIDE

GUIDE D'INSTALLATION

GUÍA DE INSTALACION

INSTALLATIONSANLEITUNG


GUIDA ALL'INSTALLAZIONE


安装手册

설치안내서


設置手順書

PH-5100/PH-5110







1




2




3




4










5




6







13




14




15




16





17




18




19




20




21




22



23



24



English

[Adjusting the hole punch position]

1. Connect the MFP power plug to the wall outlet and turn the MFP main power switch on.
 2. Make a test copy in punch mode.
 3. If any off-centering is observed, follow the procedure below to adjust the hole position.
(For the reference value, refer to each adjustment content.)
-

Français

[Réglage de la position des perforations]

1. Insérer la fiche d'alimentation du MFP dans la prise murale et mettre l'interrupteur principal du MFP sous tension.
 2. Effectuer une copie d'essai en mode perforation.
 3. Si les perforations sont décentrées, suivre la procédure ci-dessous pour ajuster la position de perforation.
(Pour la valeur de référence, se reporter à chaque contenu d'ajustement.)
-

Español

[Ajuste de la posición de perforación]

1. Conecte el enchufe del MFP en el receptáculo de pared y encienda el interruptor principal del MFP.
 2. Haga una copia de prueba en el modo de perforación.
 3. Si observa descentrado, siga el procedimiento de abajo para ajustar la posición del agujero.
(Para información sobre el valor de referencia, consulte el contenido de cada ajuste.)
-

Deutsch

[Einstellen der Lochungsposition]

1. Stecken Sie den Netzstecker des MFP in die Wandsteckdose und schalten Sie den MFP am Hauptschalter ein.
 2. Eine Testkopie im Lochungsmodus erstellen.
 3. Falls eine außermittige Lochung erfolgte, ist die Lochungsposition wie folgend nachzustellen.
(Den Referenzwert finden Sie im jeweiligen Einstellungsabschnitt.)
-

Italiano

[Regolazione di posizione dei fori di perforazione]

1. Collegare la spina del cavo di alimentazione dell'MFP alla presa a muro della rete elettrica e accendere l'interruttore principale di alimentazione.
 2. Eseguire una copia di prova in modalità di perforazione.
 3. Nel caso in cui non lo siano, eseguire la procedura indicata qui di seguito per regolarne la posizione.
(Per informazioni sul valore di riferimento vedere il contenuto di ogni regolazione.)
-

简体中文

[打孔位置的调节]

1. 将 MFP 主机上的电源插头插入电源插座中，打开主电源开关。
 2. 在打孔模式下进行测试复印。
 3. 打孔位置有偏差时，按以下步骤进行调节。
(标准值请参照各调整内容。)
-

한국어


[펀치위치의 조정]

1. MFP 본체 전원플러그를 콘센트에 꽂고 주 전원 스위치를 ON 으로 합니다 .
 2. 펀치모드에서 시험복사를 합니다 .
 3. 펀치위치가 벗어난 경우에는 다음 순서로 조정합니다 .
(기준 값에 대해서는 각 조정 내용을 참조하십시오 .)
-

日本語

[パンチ位置の調整]

1. MFP 本体の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。
 2. パンチモードでテストコピーを行う。
 3. パンチ位置がずれていた場合、次の手順で調整を行う。
(基準値は、各調整内容を参照のこと。)
-



Adjusting the hole punch entry registration

1. Set the maintenance mode U246 and select [Finisher] > [Punch Regist].
2. Adjust the values.
When the paper fed in skewed copy example (a): Increase the setting value.
When the paper crimped copy example (b): Decrease the setting value.
Amount of change per step: 0.19mm
3. Press the [Start] key to confirm the setting value.

Réglage de l'enregistrement de l'entrée des perforations

1. Passer en mode maintenance U246, sélectionner [Finisher] > [Punch Regist].
2. Régler les valeurs.
Si le papier est alimenté de travers exemple de copie (a): Augmentez la valeur de réglage.
Si le papier est froissé exemple de copie (b): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19mm
3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.

Ajuste del registro de entrada de perforación

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [Punch Regist].
2. Ajuste los valores.
Cuando el papel alimentado está torcido copia de muestra (a): Aumente el valor de configuración.
Cuando el papel se dobló copia de muestra (b): Reduzca el valor de configuración.
Magnitud del cambio por incremento: 0,19mm
3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.

Einstellen der Lochungsregistrierung

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [Punch Regist].
2. Die Werte einstellen.
Wenn Papier verkantet eingezogen wird Kopiebeispiel (a): Den Einstellwert erhöhen.
Wenn Papier verknittert wird Kopiebeispiel (b): Den Einstellwert verringern.
Änderung pro Schritt: 0,19mm
3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.

Regolazione del registro del foro di perforazione

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [Punch Regist].
2. Regolare i valori.
Quando l'alimentazione della carta risulta obliqua esempio di copia (a): Aumentare il valore dell'impostazione.
Quando la carta risulta increspata esempio di copia (b): Diminuire il valore dell'impostazione.
Entità modifica per passo: 0,19mm
3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.

打孔装入定位调节


1. 进入维修保养模式 U246, 把 [Finisher] > [Punch Regist].
2. 调整设定值。
纸张斜向搬运时的复印样本 (a): 调高设定值。
纸张作 Z 字折时的复印样本 (b): 调低设定值。
设定值的一个调整单位变化量: 0.19mm
3. 按 [开始] 键, 以确定设定值。

펀치반입 레지스트 조정

1. 메인터넌스 모드 U246 를 설정하고 [Finisher] > [Punch Regist] 를 선택합니다 .
2. 설정치를 조정합니다 .
용지가 기울어져서 반송되는 경우의 복사샘플 (a): 설정치를 높입니다 .
용지가 Z 꺾임이 있는 경우 복사샘플 (b): 설정치를 내립니다 .
1 스텝당 변화량 : 0.19mm
3. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .

パンチ搬入レジスト調整

1. メンテナンスモード U246 をセットし、[Finisher] > [Punch Regist] を選択する。
2. 設定値を調整する。
用紙が斜めに搬送される場合コピーサンプル (a) : 設定値を上げる。
用紙が Z 折れる場合コピーサンプル (b) : 設定値を下げる。
1 ステップ当たりの変化量: 0.19mm
3. [スタート] キーを押し、設定値を確定する。



Adjusting the hole punch position feed

1. Set the maintenance mode U246 and select [Finisher] > [Punch Feed].
2. Adjust the values.
If the punch hole position is closer to the edge than the reference value (c): Increase the setting value.
If the punch hole position is further from the edge than the reference value (c): Decrease the setting value.
Amount of change per step: 0.52mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (c)>
Metric specification: 13.0mm ±2mm
Inch specification: 9.5mm ±2mm (0.37" ± 0.08")

Réglage de la position du point de perforation

1. Passer en mode maintenance U246, sélectionner [Finisher] > [Punch Feed].
2. Régler les valeurs.
Si la perforation est plus proche du bord de la feuille que défini par la valeur de référence (c): Augmentez la valeur de réglage.
Si la perforation est plus loin du bord de la feuille que défini par la valeur de référence (c): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,52mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (c)>
Spécifications métriques: 13,0mm ±2mm
Spécifications en pouces: 9,5mm ±2mm (0,37" ± 0,08")

Ajuste de la alimentación de la posición de perforación

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [Punch Feed].
2. Ajuste los valores.
Si la posición de perforación está más cerca del borde que el valor de referencia (c): Aumente el valor de configuración.
Si la posición de perforación está más alejada del borde que el valor de referencia (c): Reduzca el valor de configuración.
Magnitud del cambio por incremento: 0,52mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (c)>
Sistema métrico: 13,0mm ±2mm
En pulgadas: 9,5mm ±2mm (0,37" ± 0,08")

Einstellen des Transports der Lochungsposition

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [Punch Feed].
2. Die Werte einstellen.
Falls die Lochungsposition näher an der Kante liegt als der Bezugswert (c) erlaubt: Den Einstellwert erhöhen.
Falls die Lochungsposition ferner von der Kante liegt als der Bezugswert (c) erlaubt: Den Einstellwert verringern. Änderung pro Schritt: 0,52 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (c)>
Metrischer Abstand: 13,0mm ±2mm
Abstand in Zoll: 9,5mm ±2mm (0,37" ± 0,08")

Regolazione spostamento di posizione dei fori di perforazione

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [Punch Feed].
2. Regolare i valori.
Se la posizione dei fori di perforazione è più vicina al bordo rispetto al valore di riferimento (c): Aumentare il valore dell'impostazione.
Se la posizione dei fori di perforazione è più lontana dal bordo rispetto al valore di riferimento (c): Diminuire il valore dell'impostazione.
Entità modifica per passo: 0,52 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (c)>
Specificazione in unità metrica: 13,0mm ±2mm
Specificazione in pollici: 9,5mm ±2mm (0,37" ± 0,08")

打孔位置搬运调节

1. 进入维修保养模式 U246, 把 [Finisher] > [Punch Feed] 选择。
2. 调整设定值。
打孔位置比基准值 (c) 短时: 调高设定值。
打孔位置比基准值 (c) 长时: 调低设定值。
设定值的一个调整单位变化量: 0.52mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (c)>
公制规格: 13.0mm ±2mm
英制规格: 9.5mm ±2mm (0.37" ± 0.08")

펀치위치 반송조정


1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [Punch Feed] 를 선택합니다 .
2. 설정치를 조정합니다 .
펀치구멍의 위치가 기준치 (c) 보다 짧은 경우: 설정치를 높입니다 .
펀치구멍의 위치가 기준치 (c) 보다 긴 경우: 설정치를 내립니다 .
1 스텝당 변화량: 0.52mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .
4. 테스트 카피를 합니다 .
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행합니다 .
< 기준치 (c) >
센티사양: 13.0mm ±2mm
인치사양: 9.5mm ±2mm (0.37" ± 0.08")

パンチ位置搬送調整

1. メンテナンスモード U246 をセットし、[Finisher] > [Punch Feed] を選択する。
2. 設定値を調整する。
パンチ穴の位置が基準値 (c) より短い場合: 設定値を上げる。
パンチ穴の位置が基準値 (c) より長い場合: 設定値を下げる。
1 ステップ当たりの変化量: 0.52mm

3. [スタート] キーを押し、設定値を確定する。
4. テストコピーを行う。
5. パンチ穴の位置が基準値内になるまで、手順 1 ~ 4 を繰り返す。
< 基準値 (c) >
センチ仕様: 13.0mm ±2mm
インチ仕様: 9.5mm ±2mm (0.37" ± 0.08")



Centering the hole punch position

1. Set the maintenance mode U246 and select [Finisher] > [Punch Width].
2. Adjust the values.
If the punch hole is too close to the front of the machine: Decrease the setting value.
If the punch hole is too close to the rear of the machine: Increase the setting value.
Amount of change per step: 0.52mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (d) >
Metric specification: $d = 40.0\text{mm} \pm 2\text{mm}, e = 80.0\text{mm} \pm 0.5\text{mm}$ (e: Unadjustable)
Inch specification: $d = 34.93\text{mm} \pm 2\text{mm} (1.38'' \pm 0.08'')$,
 $e = 69.85\text{mm} \pm 0.5\text{mm} (2.75'' \pm 0.02'')$ (e: Unadjustable)

Centrage de la position de perforation

1. Passer en mode maintenance U246, sélectionner [Finisher] > [Punch Width].
2. Régler les valeurs.
Si la perforation est trop proche de l'avant de la machine: Diminuez la valeur de réglage.
Si la perforation est trop proche de l'arrière de la machine: Augmentez la valeur de réglage.
Changement par graduation d'échelle: 0,52mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (d) >
Spécifications métriques: $d = 40,0\text{mm} \pm 2\text{mm}, e = 80,0\text{mm} \pm 0,5\text{mm}$ (e: Ajustement impossible)
Spécifications en pouces: $d = 34,93 \text{ mm} \pm 2\text{mm} (1,38'' \pm 0,08'')$,
 $e = 69,85\text{mm} \pm 0,5\text{mm} (2,75'' \pm 0,02'')$ (e: Ajustement impossible)

Centrado de la posición de perforación

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [Punch Width].
2. Ajuste los valores.
Si la perforación se encuentra demasiado cerca del frente de la máquina: Reduzca el valor de configuración.
Si la perforación se encuentra demasiado cerca de la parte trasera de la máquina: Aumente el valor de configuración.
Magnitud del cambio por incremento: 0,52 mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (d) >
Sistema métrico: $d = 40,0\text{mm} \pm 2\text{mm}, e = 80,0\text{mm} \pm 0,5\text{mm}$ (e: No ajustable)
En pulgadas: $d = 34,93\text{mm} \pm 2\text{mm} (1,38'' \pm 0,08'')$,
 $e = 69,85\text{mm} \pm 0,5\text{mm} (2,75'' \pm 0,02'')$ (e: No ajustable)

Zentrieren der Stanzlochposition

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [Punch Width].
2. Die Werte einstellen.
Falls die Lochung zu nah an der Gerätefront liegt: Den Einstellwert verringern.
Falls die Lochung zu weit weg von der Gerätefront liegt: Den Einstellwert erhöhen.
Änderung pro Schritt: 0,52 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (d) >
Metrischer Abstand: $d = 40,0\text{mm} \pm 2\text{mm}, e = 80,0\text{mm} \pm 0,5\text{mm}$ (e: Nicht einstellbar)
Abstand in Zoll: $d = 34,93 \text{ mm} \pm 2\text{mm} (1,38'' \pm 0,08'')$,
 $e = 69,85\text{mm} \pm 0,5\text{mm} (2,75'' \pm 0,02'')$ (e: Nicht einstellbar)

Centrata della posizione dei fori di perforazione

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [Punch Width].
2. Regolare i valori.
Se la posizione dei fori di perforazione è troppo vicina alla parte anteriore della macchina: Diminuire il valore dell'impostazione.
Se la posizione dei fori di perforazione è troppo vicina alla parte posteriore della macchina: Aumentare il valore dell'impostazione.
Entità modifica per passo: 0.52 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (d) >
Specificazione in unità metrica: $d = 40,0\text{mm} \pm 2\text{mm}, e = 80,0\text{mm} \pm 0,5\text{mm}$ (e: Non regolabile)
Specificazione in pollici: $d = 34,93 \text{ mm} \pm 2\text{mm} (1,38'' \pm 0,08'')$,
 $e = 69,85\text{mm} \pm 0,5\text{mm} (2,75'' \pm 0,02'')$ (e: Non regolabile)

打孔位置中心调节

1. 进入维修保养模式 U246, 把 [Finisher] > [Punch Width].
2. 调整设定值。
打孔位置向机器前部偏移时: 调低设定值。
打孔位置向机器后部偏移时: 调高设定值。
设定值的一个调整单位变化量: 0.52mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (d) >
公制规格: $d = 40.0\text{mm} \pm 2\text{mm}, e = 80.0\text{mm} \pm 0.5\text{mm}$ (e: 不可调整)
英制规格: $d = 34.93\text{mm} \pm 2\text{mm} (1.38'' \pm 0.08'')$,
 $e = 69.85\text{mm} \pm 0.5\text{mm} (2.75'' \pm 0.02'')$ (e: 不可调整)

펀치위치 센터조정


1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [Punch Width] 를 선택합니다 .
2. 설정치를 조정합니다 .
펀치구멍의 위치가 기기 앞측으로 벗어난 경우: 설정치를 내립니다 .
펀치구멍의 위치가 기기 뒷측으로 벗어난 경우: 설정치를 높입니다 .
1 스텝당 변화량: 0.52mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .
4. 테스트 카피를 합니다 .
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행합니다 .
< 기준치 (d) >
센터 사양: $d = 40.0\text{mm} \pm 2\text{mm}, e = 80.0\text{mm} \pm 0.5\text{mm}$ (e: 조정 불가)
인치 사양: $d = 34.93\text{mm} \pm 2\text{mm} (1.38'' \pm 0.08'')$,
 $e = 69.85\text{mm} \pm 0.5\text{mm} (2.75'' \pm 0.02'')$ (e: 조정 불가)

パンチ位置センター調整

1. メンテナンスモード U246 をセットし, [Finisher] > [Punch Width] を選択する。
2. 設定値を調整する。
パンチ穴の位置が機械前側にずれている場合: 設定値を下げる。
パンチ穴の位置が機械後側にずれている場合: 設定値を上げる。
1 ステップ当たりの変化量: 0.52mm

3. [スタート] キーを押し, 設定値を確定する。
4. テストコピーを行う。
5. パンチ穴の位置が基準値内になるまで, 手順 1 ~ 4 を繰り返す。
< 基準値 (d) >
センチ仕様: $d = 40.0\text{mm} \pm 2\text{mm}, e = 80\text{mm} \pm 0.5\text{mm}$ (e: 調整不可)
インチ仕様: $d = 34.93\text{mm} \pm 2\text{mm} (1.38'' \pm 0.08'')$,
 $e = 69.85\text{mm} \pm 0.5\text{mm} (2.75'' \pm 0.02'')$ (e: 調整不可)



Adjusting the long-edge hole punch position (width)

1. Set the maintenance mode U246 and select [Finisher] > [Punch(L) Width].
2. Adjust the values.
If the punch hole position is closer to the edge than the reference value (f): Increase the setting value.
If the punch hole position is further from the edge than the reference value (f): Decrease the setting value. Amount of change per step: 0.19 mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (f)>
Metric specification: 13.0mm ± 1mm
Inch specification: 9.5mm ± 1mm (0.37" ± 0.04")

Ajustement de la position de perforation sur le bord long (largeur)

1. Passer en mode maintenance U246, sélectionner [Finisher] > [Punch(L)Width].
2. Régler les valeurs.
Si la perforation est plus proche du bord de la feuille que défini par la valeur de référence (f): Augmentez la valeur de réglage.
Si la perforation est plus loin du bord de la feuille que défini par la valeur de référence (f): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19 mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (f) >
Spécifications métriques: 13,0mm ±1mm
Spécifications en pouces: 9,5mm ±1mm (0,37" ±0,04")

Ajuste de la posición de perforación de agujeros en el borde largo (ancho)

1. Configurar el modo de mantenimiento U246 y seleccionar [Finisher] > [Punch(L)Width].
2. Ajuste los valores.
Si la posición de perforación está más cerca del borde que el valor de referencia (f): Aumente el valor de configuración.
Si la posición de perforación está más alejada del borde que el valor de referencia (f): Reduzca el valor de configuración.
Magnitud del cambio por incremento: 0,19 mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (f)>
Sistema métrico: 13,0mm ±1mm
En pulgadas: 9,5mm ±1mm (0,37" ±0,04")

Lochposition der langen Seite einstellen (Breite)

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [Punch(L) Width].
2. Die Werte einstellen.
Falls die Lochungsposition näher an der Kante liegt als der Bezugswert (f) erlaubt: Den Einstellwert erhöhen.
Falls die Lochungsposition ferner von der Kante liegt als der Bezugswert (f) erlaubt: Den Einstellwert verringern. Änderung pro Schritt: 0,19 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (f) >
Metrischer Abstand: 13,0mm ±1mm
Abstand in Zoll: 9,5mm ±1mm (0,37" ± 0,04")

Regolazione della posizione di foratura sul lato lungo (larghezza)

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [Punch(L)Width].
2. Regolare i valori.
Se la posizione dei fori di perforazione è più vicina al bordo rispetto al valore di riferimento (f): Aumentare il valore dell'impostazione.
Se la posizione dei fori di perforazione è più lontana dal bordo rispetto al valore di riferimento (f): Diminuire il valore dell'impostazione.
Entità modifica per passo: 0,19 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (f)>
Specificazione in unità metrica: 13,0mm ±1mm
Specificazione in pollici: 9,5mm ±1mm (0,37" ± 0,04")

长边打孔位置调整(宽度)

1. 进入维修保养模式 U246, 把 [Finisher] > [Punch(L)Width].
2. 调整设定值。
打孔位置比基准值 (f) 短时: 调高设定值。
打孔位置比基准值 (f) 长时: 调低设定值。
设定值的一个调整单位变化量: 0.19mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (f) >
公制规格: 13.0mm ± 1mm
英制规格: 9.5mm ± 1mm (0.37" ± 0.04")

긴 면 1 공 펀치 위치 조정 (폭)


1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [Punch(L)Width] 를 선택합니다 .
2. 설정치를 조정합니다 .
펀치구멍의 위치가 기준치 (f) 보다 짧은 경우: 설정치를 높입니다 .
펀치구멍의 위치가 기준치 (f) 보다 긴 경우: 설정치를 내립니다 .
1 스텝당 변화량: 0.19mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .
4. 테스트 카피를 합니다 .
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행 합니다 .
< 기준치 (f) >
센티사양: 13.0mm ± 1mm
인치사양: 9.5mm ± 1mm (0.37" ± 0.04")

長辺パンチ位置調整(幅)

1. メンテナンスモード U246 をセットし, [Finisher] > [Punch(L) Width] を選択する.
2. 設定値を調整する.
パンチ穴位置が基準値 (f) より短い場合: 設定値を上げる.
パンチ穴位置が基準値 (f) より長い場合: 設定値を下げる.
1 ステップ当たりの変化量: 0.19mm

3. [スタート] キーを押し, 設定値を確定する.
4. テストコピーを行う.
5. パンチ穴の位置が基準値内になるまで, 手順 1 ~ 4 を繰り返す.
< 基準値 (f) >
センチ仕様: 13.0mm ± 1mm
インチ仕様: 9.5mm ± 1mm (0.37" ± 0.04")



(Table.1)

| | g |
|---------|---------------|
| LetterR | 99.7mm ± 1mm |
| A4R | 108.5mm ± 1mm |
| B5R | 88.5mm ± 1mm |
| 16開R | 96.5mm ± 1mm |

(Table.2)

| | g |
|---------|-------------------------------|
| LetterR | 104.8mm ± 1mm (4.13" ± 0.04") |
| A4R | 113.6mm ± 1mm (4.47" ± 0.04") |
| B5R | 93.6mm ± 1mm (3.69" ± 0.04") |
| 16開R | 101.6mm ± 1mm (4.0" ± 0.04") |

Adjusting the long-edge 2-hole punch position (1st hole)

1. Set the maintenance mode U246 and select [Finisher] > [2Punch(L) 1].
2. Adjust the values.
If the 1st hole punch position is shorter than the reference (g): Increase the setting value.
If the 1st hole punch position is longer than the reference (g): Decrease the setting value.
Amount of change per step: 0.19 mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (g)>
Metric specification: Refer to (Table.1) above.
Inch specification: Refer to (Table.2) above.

Ajustement de la position de perforation à 2 trous sur le bord long (1er trou)

1. Passer en mode maintenance U246, sélectionner [Finisher] > [2Punch(L)1].
2. Régler les valeurs.
Si la position de perforation du 1er trou est plus courte que la référence (g): Augmentez la valeur de réglage.
Si la position de perforation du 1er trou est plus longue que la référence (g): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19 mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (g) >
Spécifications métriques: Se reporter au (Table.1) ci-dessus.
Spécifications en pouces: Se reporter au (Table.2) ci-dessus.

Ajuste de la posición de perforación de 2 agujeros en el borde largo (1er agujero)

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [2Punch(L)1].
2. Ajuste los valores.
Si la posición de perforación del 1er agujero es más corta que la de referencia (g): Aumente el valor de configuración.
Si la posición de perforación del 1er agujero es más larga que la de referencia (g): Reduzca el valor de configuración. Magnitud del cambio por incremento: 0,19 mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (g)>
Sistema métrico: Consulte (Table.1) arriba.
En pulgadas: Consulte (Table.2) arriba.

2-fach Lochposition der langen Seite einstellen (1. Lochposition)

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [2Punch(L)1].
2. Die Werte einstellen.
Falls die erste Lochposition kürzer als die Referenz (g) ist: Den Einstellwert erhöhen.
Falls die erste Lochposition länger als die Referenz (g) ist: Den Einstellwert verringern. Änderung pro Schritt: 0,19 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (g) >
Metrischer Abstand: Siehe oben (Table.1).
Abstand in Zoll: Siehe oben (Table.2).

Regolazione della posizione di foratura a due fori sul lato lungo (1° foro)

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [2Punch(L)1].
2. Regolare i valori.
Se la posizione di foratura 1 è più corta rispetto al riferimento (g): Aumentare il valore dell'impostazione.
Se la posizione di foratura 1 è più lunga rispetto al riferimento (g): Diminuire il valore dell'impostazione. Entità modifica per passo: 0,19 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (g)>
Specificazione in unità metrica: Fare riferimento alla (Table.1) sopra riportata.
Specificazione in pollici: Fare riferimento alla (Table.2) sopra riportata.

2 孔长边打孔位置调整 (第 1 孔)

1. 进入维修保养模式 U246, 把 [Finisher] > [2Punch(L)1].
2. 调整设定值。
第 1 孔的位置比标准值 (g) 短时: 调高设定值。
第 1 孔的位置比标准值 (g) 长时: 调低设定值。
设定值的一个调整单位变化量: 0.19mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (g) >
公制规格: 参照上图 (Table. 1)
英制规格: 参照上图 (Table. 2)

긴 면 2 공 펀치 위치 조정 (첫 번째)


1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [2Punch(L)1] 를 선택합니다.
2. 설정치를 조정합니다.
첫 번째 펀치 구멍 위치가 기준 (g) 보다 짧은 경우: 설정치를 높입니다.
첫 번째 펀치 구멍 위치가 기준 (g) 보다 긴 경우: 설정치를 낮춥니다.
1 스텝당 변화량: 0.19mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다.
4. 테스트 카피를 합니다.
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행합니다.
< 기준치 (g) >
센티사양: 위의 그림 (Table.1) 을 참조하십시오.
인치사양: 위의 그림 (Table.2) 을 참조하십시오.

2 穴長辺パンチ位置調整 (1 穴目)

1. メンテナンスモード U246 をセットし、[Finisher] > [2Punch(L)1] を選択する。
2. 設定値を調整する。
1 穴目の位置が基準値 (g) より短い場合: 設定値を上げる。
1 穴目の位置が基準値 (g) より長い場合: 設定値を下げる。
1 ステップ当たりの変化量: 0.19mm

3. [スタート] キーを押し、設定値を確定する。
4. テストコピーを行う。
5. パンチ穴の位置が基準値内になるまで、手順 1 ~ 4 を繰り返す。
< 基準値 (g) >
センチ仕様: 上図 Table. 1 参照
インチ仕様: 上図 Table. 2 参照



Adjusting the long-edge 2-hole punch position (2nd hole)

1. Set the maintenance mode U246 and select [Finisher] > [2Punch(L)2].
2. Adjust the values.
If the 2nd hole punch position is shorter than the reference (h): Increase the setting value.
If the punch hole position is further from the edge than the reference value (h): Decrease the setting value.
Amount of change per step: 0.19 mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (h)>
Metric specification: 80.0mm ± 0.5mm
Inch specification: 69.85mm ± 0.5mm (2.75" ± 0.02")

Ajustement de la position de perforation à 2 trous sur le bord long (2e trou)

1. Passer en mode maintenance U246, sélectionner [Finisher] > [2Punch (L)2].
2. Régler les valeurs.
Si la position de perforation du 2e trou est plus courte que la référence (h): Augmentez la valeur de réglage.
Si la position de perforation du 2e trou est plus longue que la référence (h): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19 mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (h) >
Spécifications métriques: d = 80mm ± 0,5mm
Spécifications en pouces: d = 69,85mm ± 0,5mm (2,75" ± 0,02")

Ajuste de la posición de perforación de 2 agujeros en el borde largo (2º agujero)

1. Configurar el modo de mantenimiento U246 y seleccionar [Finisher] > [2Punch(L)2].
2. Ajuste los valores.
Si la posición de perforación del 2er agujero es más corta que la de referencia (h): Aumente el valor de configuración.
Si la posición de perforación del 2er agujero es más larga que la de referencia (h): Reduzca el valor de configuración.
Magnitud del cambio por incremento: 0,19 mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (h)>
Sistema métrico: 80.0mm ±0.5mm
En pulgadas: 69,85mm ±0,5mm (2,75" ± 0,02")

2-fach Lochposition der langen Seite einstellen (2. Lochposition)

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [2Punch(L)2].
2. Die Werte einstellen.
Falls die zweite Lochposition kürzer als die Referenz (h) ist: Den Einstellwert erhöhen.
Falls die zweite Lochposition länger als die Referenz (h) ist: Den Einstellwert verringern. Änderung pro Schritt: 0,19 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (h) >
Metrischer Abstand: 80,0mm ± 0,5mm
Abstand in Zoll: 69,85mm ± 0,5mm (2,75" ± 0,02")

Regolazione della posizione di foratura a due fori sul lato lungo (2° foro)

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [2Punch(L)2].
2. Regolare i valori.
Se la posizione di foratura 2 è più corta rispetto al riferimento (h): Aumentare il valore dell'impostazione.
Se la posizione di foratura 2 è più lunga rispetto al riferimento (h): Diminuire il valore dell'impostazione. Entità modifica per passo: 0,19 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (h)>
Specificazione in unità metrica: 80,0mm ±0,5mm
Specificazione in pollici: 69,85mm ±0,5mm (2,75" ± 0,02")

2 孔长边打孔位置调整 (第 2 孔)

1. 进入维修保养模式 U246, 把 [Finisher] > [2Punch(L)2].
2. 调整设定值。
第 2 孔的位置比标准值 (h) 短时: 调高设定值。
第 2 孔的位置比标准值 (h) 长时: 调低设定值。
设定值的一个调整单位变化量: 0.19mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (h) >
公制规格: 80.0mm ± 0.5mm
英制规格: 69.85mm ± 0.5mm (2.75" ± 0.02")

긴 면 2공 펀치 위치 조정 (두 번째 공)


1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [2Punch(L)2] 를 선택합니다 .
2. 설정치를 조정합니다 .
두 번째 펀치 구멍 위치가 기준 (h) 보다 짧은 경우: 설정치를 높입니다 .
두 번째 펀치 구멍 위치가 기준 (h) 보다 긴 경우: 설정치를 내립니다 .
1 스텝당 변화량: 0.19mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .
4. 테스트 카피를 합니다 .
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행 합니다 .
< 기준치 (h) >
센티사양: 80.0mm ± 0.5mm
인치사양: 69.85mm ± 0.5mm (2.75" ± 0.02")

2 穴長辺パンチ位置調整 (2 穴目)

1. メンテナンスモード U246 をセットし, [Finisher] > [2Punch(L)2] を選択する.
2. 設定値を調整する.
2 穴目の位置が基準値 (h) より短い場合: 設定値を上げる.
2 穴目の位置が基準値 (h) より長い場合: 設定値を下げる.
1 ステップ当たりの変化量: 0.19mm

3. [スタート] キーを押し, 設定値を確定する.
4. テストコピーを行う.
5. パンチ穴の位置が基準値内になるまで, 手順 1 ~ 4 を繰り返す.
< 基準値 (h) >
センチ仕様: 80.0mm ± 0.5mm
インチ仕様: 69.85mm ± 0.5mm (2.75" ± 0.02")



(Table.1)

| | i |
|-----|--------------|
| A4R | 28.5mm ± 1mm |

(Table.2)

| | i |
|---------|------------------------------|
| LetterR | 31.8mm ± 1mm (1.25" ± 0.04") |
| A4R | 40.5mm ± 1mm (1.59" ± 0.04") |
| 16開R | 28.5mm ± 1mm (1.12" ± 0.04") |

Adjusting the long-edge 3-hole or 4-hole punch position (1st hole)

1. Set the maintenance mode U246 and select [Finisher] > [3/4Punch(L)1].
2. Adjust the values.
If the 1st hole punch position is shorter than the reference (i): Increase the setting value.
If the 1st hole punch position is longer than the reference (i): Decrease the setting value.
Amount of change per step: 0.19 mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (i)>
Metric specification(4-hole): Refer to (Table.1) above.
Inch specification(3-hole): Refer to (Table.2) above.

Ajustement de la position de perforation à 3 ou 4 trous sur le bord long (1er trou)

1. Passer en mode maintenance U246, sélectionner [Finisher] > [3/4Punch (L)1].
2. Régler les valeurs.
Si la position de perforation du 1er trou est plus courte que la référence (i): Augmentez la valeur de réglage.
Si la position de perforation du 1er trou est plus longue que la référence (i): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19 mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (i) >
Spécifications métriques(4 trous): Se reporter au (Table.1) ci-dessus.
Spécifications en pouces(3 trous): Se reporter au (Table.2) ci-dessus.

Ajuste de la posición de perforación de 3 o 4 agujeros en el borde largo (1er agujero)

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [3/4Punch(L)1].
2. Ajuste los valores.
Si la posición de perforación del 1er agujero es más corta que la de referencia (i): Aumente el valor de configuración.
Si la posición de perforación del 1er agujero es más larga que la de referencia (i): Reduzca el valor de configuración. Magnitud del cambio por incremento: 0,19 mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (i)>
Sistema métrico(4 agujeros): Consulte (Table.1) arriba.
En pulgadas(3 agujeros): Consulte (Table.2) arriba.

3-fach oder 4-fach Lochposition der langen Seite einstellen (1. Lochposition)

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [3/4Punch(L)1].
2. Die Werte einstellen.
Falls die erste Lochposition kürzer als die Referenz (i) ist: Den Einstellwert erhöhen.
Falls die erste Lochposition länger als die Referenz (i) ist: Den Einstellwert verringern. Änderung pro Schritt: 0,19 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (i) >
Metrischer Abstand(4-fach Lochung): Siehe oben (Table.1).
Abstand in Zoll(3-fach Lochung): Siehe oben (Table.2).

Regolazione della posizione di foratura a tre o quattro fori sul lato lungo (1° foro)

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [3/4Punch(L)1].
2. Regolare i valori.
Se la posizione di foratura 1 è più corta rispetto al riferimento (i): Aumentare il valore dell'impostazione.
Se la posizione di foratura 1 è più lunga rispetto al riferimento (i): Diminuire il valore dell'impostazione. Entità modifica per passo: 0,19 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (i)>
Specificazione in unità metrica(4 fori): Fare riferimento alla (Table.1) sopra riportata.
Specificazione in pollici(3 fori): Fare riferimento alla (Table.2) sopra riportata.

3孔、4孔长边打孔位置调整(第1孔)

1. 进入维修保养模式U246,把[Finisher]>[3/4Punch(L)1]。
2. 调整设定值。
第1孔的位置比标准值(i)短时:调高设定值。
第1孔的位置比标准值(i)长时:调低设定值。
设定值的一个调整单位变化量:0.19mm

3. 按[开始]键,以确定设定值。
4. 进行测试复印。
5. 重复步骤1~4,直至打孔的孔的位置达到标准值。
<基准值(i)>
公制规格(4孔):参照上图(Table.1)
英制规格(3孔):参照上图(Table.2)

긴 면 3공 또는 4공 펀치 위치 조정 (첫 번째 구멍)


1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [3/4Punch(L)1] 를 선택합니다 .
2. 설정치를 조정합니다 .
첫 번째 펀치 구멍 위치가 기준 (i) 보다 짧은 경우: 설정치를 높입니다 .
첫 번째 펀치 구멍 위치가 기준 (i) 보다 긴 경우: 설정치를 낮춥니다 .
1 스텝당 변화량 : 0.19mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .
4. 테스트 카피를 합니다 .
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행 합니다 .
< 기준치 (i) >
센티사양 (4 공): 위의 그림 (Table.1) 을 참조하십시오 .
인치사양 (3 공): 위의 그림 (Table.2) 을 참조하십시오 .

3穴、4穴長辺パンチ位置調整(1穴目)

1. メンテナンスモードU246 をセットし、[Finisher] > [3/4Punch (L) 1] を選択する。
2. 設定値を調整する。
1穴目の位置が基準値(i)より短い場合:設定値を上げる。
1穴目の位置が基準値(i)より長い場合:設定値を下げる。
1ステップ当たりの変化量:0.19mm

3. [スタート] キーを押し、設定値を確定する。
4. テストコピーを行う。
5. パンチ穴の位置が基準値内になるまで、手順1 ~ 4を繰り返す。
<基準値(i)>
センチ仕様(4穴):上図Table.1参照
インチ仕様(3穴):上図Table.2参照



Adjusting the long-edge 3-hole or 4-hole punch position (2nd hole)

1. Set the maintenance mode U246 and select [Finisher] > [3/4Punch(L)2].
2. Adjust the values.
If the 2nd hole punch position is shorter than the reference (j): Increase the setting value.
If the 2nd hole punch position is longer than the reference (j): Decrease the setting value.
Amount of change per step: 0.19 mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (j)>
Metric specification(4-hole): 80.0mm ± 0.5mm
Inch specification(3-hole): 107.95mm ± 0.5mm (4.25" ± 0.02")

Ajustement de la position de perforation à 3 ou 4 trous sur le bord long (2e trou)

1. Passer en mode maintenance U246, sélectionner [Finisher] > [3/4Punch(L)2].
2. Régler les valeurs.
Si la position de perforation du 2e trou est plus courte que la référence (j): Augmentez la valeur de réglage.
Si la position de perforation du 2e trou est plus longue que la référence (j): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19 mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (j) >
Spécifications métriques(4 trous): d = 80,0mm ± 0,5mm
Spécifications en pouces(3 trous): d = 107,95mm ± 0,5mm (2,75" ± 0,02")

Ajuste de la posición de perforación de 3 o 4 agujeros en el borde largo (2º agujero)

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [3/4Punch(L)2].
2. Ajuste los valores.
Si la posición de perforación del 2º agujero es más corta que la de referencia (j): Aumente el valor de configuración.
Si la posición de perforación del 2º agujero es más larga que la de referencia (j): Reduzca el valor de configuración. Magnitud del cambio por incremento: 0,19 mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (j)>
Sistema métrico(4 agujeros): 80,0mm±0,5mm
En pulgadas(3 agujeros): 107,95mm±1mm (4,25" ± 0,02")

3-fach oder 4-fach Lochposition der langen Seite einstellen (2. Lochposition)

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [3/4Punch(L)2].
2. Die Werte einstellen.
Falls die zweite Lochposition kürzer als die Referenz (j) ist: Den Einstellwert erhöhen.
Falls die zweite Lochposition länger als die Referenz (j) ist: Den Einstellwert verringern. Änderung pro Schritt: 0,19 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (j) >
Metrischer Abstand(4-fach Lochung): 80,0mm ± 0,5mm
Abstand in Zoll(3-fach Lochung): 107,95mm ± 0,5mm(4,25" ± 0,02")

Regolazione della posizione di foratura a tre o quattro fori sul lato lungo (2º foro)

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [3/4Punch(L)2].
2. Regolare i valori.
Se la posizione di foratura 2 è più corta rispetto al riferimento (j): Aumentare il valore dell'impostazione.
Se la posizione di foratura 2 è più lunga rispetto al riferimento (j): Diminuire il valore dell'impostazione. Entità modifica per passo: 0,19 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (j)>
Specificazione in unità metrica(4 fori): 80,0mm ± 0,5mm
Specificazione in pollici(3 fori): 107,95mm ± 0,5mm (4,25" ± 0,02")

3 孔、4 孔长边打孔位置调整 (第 2 孔)

1. 进入维修保养模式 U246, 把 [Finisher] > [3/4Punch(L)2]。
2. 调整设定值。
第 2 孔的位置比标准值 (j) 短时: 调高设定值。
第 2 孔的位置比标准值 (j) 长时: 调低设定值。
设定值的一个调整单位变化量: 0.19mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (j) >
公制规格 (4 孔): 80.0mm ± 0.5mm
英制规格 (3 孔): 107.95mm ± 0.5mm (4.25" ± 0.02")

긴 면 3 공 또는 4 공 펀치 위치 조정 (두 번째 구멍)


1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [3/4Punch(L)2] 를 선택합니다.
2. 설정치를 조정합니다.
첫 번째 펀치 구멍 위치가 기준 (j) 보다 짧은 경우: 설정치를 높입니다.
첫 번째 펀치 구멍 위치가 기준 (j) 보다 긴 경우: 설정치를 내립니다.
1 스텝당 변화량: 0.19mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다.
4. 테스트 카피를 합니다.
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행합니다.
< 기준치 (j) >
센티사양 (4 공): 80.0mm ± 0.5mm
인치사양 (3 공): 107.95mm ± 0.5mm (4.25" ± 0.02")

3 穴、4 穴長辺パンチ位置調整 (2 穴目)

1. メンテナンスモード U246 をセットし、[Finisher] > [3/4Punch(L)2] を選択する。
2. 設定値を調整する。
2 穴目の位置が基準値 (j) より短い場合: 設定値を上げる。
2 穴目の位置が基準値 (j) より長い場合: 設定値を下げる。
1 ステップ当たりの変化量: 0.19mm

3. [スタート] キーを押し、設定値を確定する。
4. テストコピーを行う。
5. パンチ穴の位置が基準値内になるまで、手順 1 ~ 4 を繰り返す。
< 基準値 (j) >
センチ仕様 (4 穴): 80.0mm ± 0.5mm
インチ仕様 (3 穴): 107.95mm ± 0.5mm (4.25" ± 0.02")



Adjusting the long-edge 3-hole or 4-hole punch position (3rd hole)

1. Set the maintenance mode U246 and select [Finisher] > [3/4Punch(L)3].
2. Adjust the values.
If the 3rd hole punch position is shorter than the reference (k): Increase the setting value.
If the 3rd hole punch position is longer than the reference (k): Decrease the setting value.
Amount of change per step: 0.19 mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (k)>
Metric specification(4-hole): 160.0 mm ± 0.5mm
Inch specification(3-hole) : 215.9 mm ± 0.5mm (8.5" ± 0.02")

Ajustement de la position de perforation à 3 ou 4 trous sur le bord long (3e trou)

1. Passer en mode maintenance U246, sélectionner [Finisher] > [3/4Punch(L)3].
2. Régler les valeurs.
Si la position de perforation du 3e trou est plus courte que la référence (k): Augmentez la valeur de réglage.
Si la position de perforation du 3e trou est plus longue que la référence (k): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19 mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (k) >
Spécifications métriques(4 trous): 160,0mm ± 0,5mm
Spécifications en pouces(3 trous): 215,9 mm ± 0,5mm (8,5" ± 0,02")

Ajuste de la posición de perforación de 3 o 4 agujeros en el borde largo (3er agujero)

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [3/4Punch(L)3].
2. Ajuste los valores.
Si la posición de perforación del 3er agujero es más corta que la de referencia (k): Aumente el valor de configuración.
Si la posición de perforación del 3er agujero es más larga que la de referencia (k): Reduzca el valor de configuración. Magnitud del cambio por incremento: 0,19 mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (k)>
Sistema métrico(4 agujeros): 160,0mm±0,5mm
En pulgadas(3 agujeros): 215,9mm±1mm (8,5" ± 0,02")

3-fach oder 4-fach Lochposition der langen Seite einstellen (3. Lochposition)

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [3/4Punch(L)3].
2. Die Werte einstellen.
Falls die dritte Lochposition kürzer als die Referenz (k) ist: Den Einstellwert erhöhen.
Falls die dritte Lochposition länger als die Referenz (k) ist: Den Einstellwert verringern. Änderung pro Schritt: 0,19 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (k) >
Metrischer Abstand(4-fach Lochung):160,0mm ±0,5mm
Abstand in Zoll(3-fach Lochung):215,9mm ±0,5mm(8,5" ±0,02")

Regolazione della posizione di foratura a tre o quattro fori sul lato lungo (3° foro)

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [3/4Punch(L)3].
2. Regolare i valori.
Se la posizione di foratura 3 è più corta rispetto al riferimento (k): Aumentare il valore dell'impostazione.
Se la posizione di foratura 3 è più lunga rispetto al riferimento (k): Diminuire il valore dell'impostazione. Entità modifica per passo: 0,19 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (k)>
Specificazione in unità metrica(4 fori): 160,0mm ±0,5mm
Specificazione in pollici(3 fori): 215,9mm ±0,5mm (8,5" ± 0,02")

3孔、4孔长边打孔位置调整(第3孔)

1. 进入维修保养模式 U246, 把 [Finisher] > [3/4Punch(L)3]。
2. 调整设定值。
第3孔的位置比标准值(k)短时: 调高设定值。
第3孔的位置比标准值(k)长时: 调低设定值。
设定值的一个调整单位变化量: 0.19mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (k) >
公制规格 (4孔): 160.0mm ± 0.5mm
英制规格 (3孔): 215.9mm ± 0.5mm (8.5" ± 0.02")

긴 면 3공 또는 4공 펀치 위치 조정 (세 번째 구멍)


1. 메인터너스 모드 U246 를 설정하고 [Finisher] > [3/4Punch(L)3] 를 선택합니다.
2. 설정치를 조정합니다.
세 번째 펀치 구멍 위치가 기준 (k) 보다 짧은 경우: 설정치를 높입니다.
세 번째 펀치 구멍 위치가 기준 (k) 보다 긴 경우: 설정치를 내립니다.
1 스텝당 변화량: 0.19mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다.
4. 테스트 카피를 합니다.
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행합니다.
< 기준치 (k) >
센티사양 (4공): 160.0mm ± 0.5mm
인치사양 (3공): 215.9mm ± 0.5mm (8.5" ± 0.02")

3穴、4穴長辺パンチ位置調整(3穴目)

1. メンテナンスモード U246 をセットし、[Finisher] > [3/4Punch(L)3] を選択する。
2. 設定値を調整する。
3穴目の位置が基準値(k)より短い場合: 設定値を上げる。
3穴目の位置が基準値(k)より長い場合: 設定値を下げる。
1ステップ当たりの変化量: 0.19mm

3. [スタート] キーを押し、設定値を確定する。
4. テストコピーを行う。
5. パンチ穴の位置が基準値内になるまで、手順 1 ~ 4 を繰り返す。
< 基準値 (k) >
センチ仕様 (4穴): 160.0mm ± 0.5mm
インチ仕様 (3穴): 215.9mm ± 0.5mm (8.5" ± 0.02")



Adjusting the long-edge 4-hole punch position (4th hole)

1. Enter the maintenance mode U246, select [Finisher] > [4Punch(L)4].
2. Adjust the values.
If the 4th hole punch position is shorter than the reference (l): Increase the setting value.
If the 4th hole punch position is longer than the reference (l): Decrease the setting value.
Amount of change per step: 0.19 mm

3. Press the [Start] key to confirm the setting value.
4. Perform a test copy.
5. Repeat the steps 1 to 4 until the hole punch position is within the reference.
<Reference value (l)>
Metric specification(4-hole):240.0 mm ± 0.5mm

Ajustement de la position de perforation à 4 trous sur le bord long (4e trou)

1. Passer en mode maintenance U246, sélectionner [Finisher] > [4Punch(L)4].
2. Régler les valeurs.
Si la position de perforation du 4e trou est plus courte que la référence (l): Augmentez la valeur de réglage.
Si la position de perforation du 4e trou est plus longue que la référence (l): Diminuez la valeur de réglage.
Changement par graduation d'échelle: 0,19 mm

3. Appuyer sur la touche de [Départ] pour confirmer la valeur de réglage.
4. Effectuer une copie de test.
5. Répéter les étapes 1 à 4 jusqu'à ce que la position de perforation soit dans la référence.
<Valeur de référence (l) >
Spécifications métriques(4 trous): 240,0mm ± 0,5mm

Ajuste de la posición de perforación de 4 agujeros en el borde largo (4º agujero)

1. Configure el modo de mantenimiento U246 y seleccione [Finisher] > [4Punch(L)4].
2. Ajuste los valores.
Si la posición de perforación del 4º agujero es más corta que la de referencia (l): Aumente el valor de configuración.
Si la posición de perforación del 4º agujero es más larga que la de referencia (l): Reduzca el valor de configuración. Magnitud del cambio por incremento: 0,19 mm

3. Pulse la tecla de [Inicio] para confirmar el valor de configuración.
4. Haga una copia de prueba.
5. Repita los pasos del 1 al 4 hasta que la posición de perforación de los agujeros esté dentro de los valores de referencia.
<Valor de referencia (l)>
Sistema métrico(4 agujeros): 240,0mm±0,5mm

4-fach Lochposition der langen Seite einstellen (4. Lochposition)

1. Aktivieren Sie den Wartungsmodus U246 und wählen Sie [Finisher] > [4Punch(L)4].
2. Die Werte einstellen.
Falls die vierte Lochposition kürzer als die Referenz (l) ist: Den Einstellwert erhöhen.
Falls die vierte Lochposition länger als die Referenz (l) ist: Den Einstellwert verringern. Änderung pro Schritt: 0,19 mm

3. Den Einstellwert durch Drücken der [Start]-Taste bestätigen.
4. Eine Testkopie erstellen.
5. Wiederholen Sie die Schritte 1 bis 4 solange, bis die Lochposition sich innerhalb der Referenz befindet.
<Bezugswert (l) >
Metrischer Abstand(4-fach Lochung):240,0mm ±0,5mm

Regolazione della posizione di foratura a quattro fori sul lato lungo (4° foro)

1. Impostare la modalità manutenzione U246 e selezionare [Finisher] > [4Punch(L)4].
2. Regolare i valori.
Se la posizione di foratura 4 è più corta rispetto al riferimento (l): Aumentare il valore dell'impostazione.
Se la posizione di foratura 4 è più lunga rispetto al riferimento (l): Diminuire il valore dell'impostazione. Entità modifica per passo: 0,19 mm

3. Premere il tasto di [Avvio] per confermare il valore dell'impostazione.
4. Eseguire una copia di prova.
5. Ripetere i punti da 1 a 4 fino a portare la posizione di foratura all'interno del riferimento.
<Valore di riferimento (l)>
Specificazione in unità metrica(4 fori): 240,0mm ±0,5mm

4 孔长边打孔位置调整 (第 4 孔)

1. 进入维修保养模式 U246, 把 [Finisher] > [4Punch(L)4].
2. 调整设定值。
第 4 孔的位置比标准值 (l) 短时: 调高设定值。
第 4 孔的位置比标准值 (l) 长时: 调低设定值。
设定值的一个调整单位变化量: 0.19mm

3. 按 [开始] 键, 以确定设定值。
4. 进行测试复印。
5. 重复步骤 1 ~ 4, 直至打孔的孔的位置达到标准值。
<基准值 (l) >
公制规格 (4 孔): 240.0mm ± 0.5mm

긴 면 4 공 펀치 위치 조정 (네 번째 구멍)

1. 메인テナンス 모드 U246 를 설정하고 [Finisher] > [4Punch(L)4] 를 선택합니다 .
2. 설정치를 조정합니다 .
네번째 펀치 구멍 위치가 기준 (l) 보다 짧은 경우: 설정치를 높입니다 .
네번째 펀치 구멍 위치가 기준 (l) 보다 긴 경우: 설정치를 내립니다 .
1 스텝당 변화량: 0.19mm

3. [복사 / 시작] 키를 누르고 설정치를 확인합니다 .
4. 테스트 카피를 합니다 .
5. 펀치 구멍 위치가 기준 이내가 될 때까지 1 단계 ~ 4 단계를 반복 수행합니다 .
< 기준치 (l) >
센티사양 (4 공): 240.0mm ± 0.5mm

4 穴長辺パンチ位置調整 (4 穴目)

1. メンテナンスモード U246 をセットし, [Finisher] > [4Punch(L)4] を選択する。
2. 設定値を調整する。
4 穴目の位置が基準値 (1) より短い場合: 設定値を上げる。
4 穴目の位置が基準値 (1) より長い場合: 設定値を下げる。
1 ステップ当たりの変化量: 0.19mm





3. [スタート] キーを押し, 設定値を確定する。
4. テストコピーを行う。
5. パンチ穴の位置が基準値内になるまで, 手順 1 ~ 4 を繰り返す。
< 基準値 (1) >
センチ仕様 (4 穴): 240.0mm ± 0.5mm

JS-5100


(Job separator)

Installation Guide


JS-5100




1




2




3




4




5




6



7



8



9

(30ppm)

- (EN) Set the maintenance mode U211, and set [Inner JobSepa] > [On].
- (FR) Passez en mode maintenance U211 et paramétrer [Inner JobSepa] > [On].
- (ES) Configure el modo de mantenimiento U211 y configure [Inner JobSepa] > [On] .
- (DE) Aktivieren Sie den U-Parameter U211 und [Inner JobSepa] > [On].
- (IT) Accedere al modo manutenzione U211, e selezionare [Inner JobSepa] > [On].
- (CN) 进入维修保养模式 U211, 把 [Inner JobSepa] > [On]。
- (KR) 메인テナンス 모드 U211 을 설정하고 [Inner JobSepa] > [On]를 설정합니다.
- (JP) メンテナンスモード U211 をセットし、[Inner JobSepa] > [On] を設定する。

(35ppm/40ppm)

- (EN) Set the maintenance mode U211, and set [Inner Job Separator] > [On].
- (FR) Passez en mode maintenance U211 et paramétrer [Inner Job Separator] > [On].
- (ES) Configure el modo de mantenimiento U211 y configure [Inner Job Separator] > [On] .
- (DE) Aktivieren Sie den U-Parameter U211 und [Inner Job Separator] > [On].
- (IT) Accedere al modo manutenzione U211, e selezionare [Inner Job Separator] > [On].
- (CN) 进入维修保养模式 U211, 把 [Inner Job Separator] > [On]。
- (KR) 메인テナンス 모드 U211 을 설정하고 [Inner Job Separator] > [On]를 설정합니다.
- (JP) メンテナンスモード U211 をセットし、[Inner Job Separator] > [On] を設定する。



303R55671001

FAX System 10

(FAX Kit)

Installation Guide

INSTALLATION GUIDE

GUIDE D'INSTALLATION

GUÍA DE INSTALACION

INSTALLATIONSANLEITUNG


GUIDA ALL'INSTALLAZIONE


安装手册

설치안내서








設置手順書

FAX System 10






| | 100V | 120V | 230V | 240V | 110V | 220V | 220-240V |
|----------|-------|--|--------|---------------------------|--------|-------|----------------|
| | Japan | North America/ Latin America | Europe | Australia/ New Zealand | Taiwan | China | Asia/ Korea |
| A | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| B | 1 | 1* *PJJWC0016 Z (UL Listed. HUAN HSIN Type TL) | - | 1 | - | 1 | - |
| C | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| D | - | 1 | 1 | 1 | 1 | 1 | 1 |
| E | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| F | - | - | - | 1 | - | - | - |
| G | - | - | - | - | - | 1 | - |
| H | - | - | - | - | - | 1 | - |
| I | - | - | - | - | - | 1 | - |
| J | - | - | - | - | 1 | - | - |
| K | 1 | 1 | 1 | 1 | 1 | 1 | 1 |



- | | |
|--------------------------------------|-----------------------------------|
| ENG (For New Zealand model) | IT (Per il modello Nuova Zelanda) |
| FR (Modèle pour la Nouvelle-Zélande) | CN (仅适用于新西兰型号) |
| ES (Para el modelo Nuevo Zelandés) | KO (뉴질랜드 사양만) |
| DE (Für Neuseeland-Modell) | JP (ニュージーランド仕様のみ) |



ENG ⑧ - ⑭ : (Excluding 100 V models)

FR ⑧ - ⑭ : (Sauf sur les modèles 100 V)

ES ⑧ - ⑭ : (A excepción de los modelos de 100 V)

DE ⑧ - ⑭ : (Ausgenommen 100-V-Modelle)


IT ⑧ - ⑭ : (Esclusi i modelli da 100 V)

CN ⑧ ~ ⑭ : (100V 规格以外)


KO ⑧ - ⑭ : (100V 사양 이외)

JP ⑧ ~ ⑭ : (100V仕様以外)


⑧





⑨




⑩




⑪







12



13



14



15 (ENG) (When installing the Multiport)

(FR) (En cas d'installation de la deuxième ligne de fax)

(ES) (Al instalar la segunda línea de fax)


(DE) (Wenn Sie eine zweite Fax-Karte installieren)

(IT) (Quando si installa la seconda linea Fax)


(CN) (安装了多功能端口)

(KO) (멀티포트를 설치하는 경우)

(JP) (マルチポートを設置する場合)



16



17

ENG

Initialize the FAX circuit board.

- 1.If the FAX PWBs were installed simultaneously to OPT1 and OPT2 (all Fax PWBs are initialized), perform the maintenance mode U600 to initialize the FAX PWBs.
- 2.If the FAX circuit board has been added to OPT2 (to initialize the FAX circuit board in OPT2)
Initialize OPT2 by pressing [PORT2], and the [Start] key in this order in the maintenance mode U698 and executing the maintenance mode U600. If [ALL] is selected in U698, both OPT1 and OPT2 are initialized.
For details, see the service manual.

FR

Initialiser la carte à circuits FAX.

- 1.Si les cartes de circuit imprimé du fax ont été installées en même temps que OPT1 et OPT2 (toutes les cartes de circuit imprimé du fax sont initialisées), exécutez le mode maintenance U600 pour initialiser les cartes de circuit imprimé du fax.
- 2.Si la carte à circuits FAX a été ajoutée à l'OPT2 (pour initialiser la carte à circuits FAX dans l'OPT2)
Initialiser l'OPT2 en appuyant sur [PORT2] et la touche [Départ] dans cet ordre en mode de maintenance U698, et exécuter le mode de maintenance U600. Si [ALL] est sélectionné dans U698, l'OPT1 et l'OPT2 de détails, se reporter au manuel d'entretien.

ES

Inicialice la tarjeta de circuitos FAX.

- 1.Si se instalaron FAX PWB simultáneamente a OPT1 y OPT2 (se inician todos los FAX PWB), ejecute el modo de mantenimiento U600 para inicializar los FAX PWB.
- 2.Si la tarjeta de circuitos de FAX se agregó a OPT2 (para inicializar la tarjeta de circuitos de FAX en OPT2)
Inicialice el OPT2 presionando [PORT2] y la tecla de [Inicio] en ese orden en el modo de mantenimiento U698 y ejecutando el modo de mantenimiento U600. Si se selecciona [ALL] en U698, se inicializan ambos OPT1 y OPT2. Para más detalles, lea el manual de servicio.

DE

Initialisieren der FAX-Leiterplatte.

- 1.Falls die FAX-Karten gleichzeitig in OPT1 und OPT2 installiert werden (alle FAX-Karten werden initialisiert), führen Sie den Wartungsmodus U600 aus, um die FAX-Karten zu initialisieren.
- 2.Wenn die FAX-Leiterplatte zu OPT2 hinzugefügt worden ist (um die FAX-Leit-erplatte in OPT2 zu initialisieren)
OPT2 initialisieren. Dazu [PORT2] und die [Start]-Taste im Wartungsmodus U698 in dieser Reihenfolge drücken und den Wartungsmodus U600 ausführen. Wenn [ALL] in U698 gewählt wird, werden OPT1 und OPT2 initialisiert. Weitere Einzelheiten siehe Wartungsanleitung.

IT

Inizializzare la scheda a circuiti FAX.

- 1.Se sono state installate simultaneamente le schede FAX PWB su OPT1 e OPT2 (tutte le schede FAX PWB sono inizializzate), eseguire il modo manutenzione U600 per inizializzare le schede FAX PWB.
- 2.Se la scheda a circuiti è stata aggiunta all'OPT2 (per inizializzare la scheda a circuiti FAX nell'OPT2)
Inizializzare OPT2 premendo [PORT2] e il tasto [Avvio] in questo ordine nel modo di manutenzione U698 ed eseguendo il modo di manutenzione U600. Se viene selezionato [ALL] nel modo U698, entrambi OPT1 e OPT2 sono inizializzati. Per ulteriori dettagli leggere il manuale d'istruzioni.

CN

传真电路板的初始化

- 1.当把传真电路板同时安装到 OPT1 和 OPT2 时 (全部的传真电路板初始化), 执行维修保养模式 U600, 初始化传真电路板。
- 2.在 OPT2 上增设时
(OPT2 的传真电路板初始化)
只进行 OPT2 初始化时, 在维修保养模式 U698 状态下, 按顺序按下 [PORT2]、[开始]键, 执行维修保养模式 U600。在 U698 状态下设定 [ALL]时, 会使 OPT1 和 OPT2 均初始化。有关详细信息, 请参见维修手册。

KO

FAX 회로기판의 초기화

- 1.OPT1 과 OPT2 에 FAX 회로기판을 동시에 설치한 경우 (모든 FAX 회로기판이 초기화됨), 메인터넌스 모드 U600 을 수행하여 FAX 회로기판을 초기화합니다 .
- 2.OPT2 에 증설한 경우 (OPT2 의 FAX 기판을 초기화)
메인터넌스모드 U698 에서 [PORT2], [시작]키 순으로 누릅니다 .
메인터넌스 모드 U600 을 실행하고 FAX 회로기판을 초기화합니다 .U698 에서 [ALL]을 설정하면 OPT1 과 OPT2 양쪽을 초기화하기 때문에 주의할 것 .
상세는 서비스 매뉴얼을 참조할 것 .

JP

FAX 基板の初期化


- 1.OPT1 と OPT2 に FAX 基板を同時に設置した場合 (すべての FAX 基板を初期化) メンテナンスモード U600 を実行し、FAX 基板を初期化する。
- 2.OPT2 に増設した場合 (OPT2 の FAX 基板を初期化)
メンテナンスモード U698 で [PORT2]、[スタート]キーの順に押す。メンテナンスモード U600 を実行し、FAX 基板を初期化する。U698 で [ALL] を設定すると OPT1 と OPT2 両方を初期化するので注意すること。詳細はサービスマニュアルを参照のこと。

FAX System 11

(FAX Kit)

Installation Guide

12



13

ENG

Initialize the FAX circuit board.

Perform the maintenance mode U600 to initialize the FAX PWBs.

FR

Initialiser la carte à circuits FAX.

Exécuter le mode maintenance U600 pour initialiser les cartes de circuit imprimé du fax.

ES

Inicialice la tarjeta de circuitos FAX.

Ejecute el modo de mantenimiento U600 para inicializar los FAX PWB.

DE

Initialisieren der FAX-Leiterplatte.

Führen Sie den Wartungsmodus U600 aus, um die FAX-Karte zu initialisieren.

IT

Inizializzare la scheda a circuiti FAX.

Eeguire il modo manutenzione U600 per inizializzare le schede FAX PWB.

CN

传真电路板的初始化

执行维修保养模式 U600，初始化传真电路板。

KO

FAX 회로기판의 초기화

메인テナンス 모드 U600을 수행하여 FAX 기판을 초기화합니다.

JP


FAX 基板の初期化

メンテナンスモード U600 を実行し、FAX 基板を初期化する。









FAX System 11



2015. 7
303RH56710-01



| | 100V | 120V | 230V | 240V | 110V | 220V | 220-240V |
|----------|-------|--|--------|---------------------------|--------|-------|----------------|
| | Japan | North America/ Latin America | Europe | Australia/ New Zealand | Taiwan | China | Asia/ Korea |
| A | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| B | 1 | 1* | - | 1 | - | 1 | - |
| | | *PJJWC0016 Z (UL Listed. HUAN HSIN Type TL) | | | | | |
| C | - | - | - | 1 | - | - | - |
| D | - | 1 | 1 | 1 | 1 | 1 | 1 |
| E | - | - | - | 1 | - | - | - |
| F | - | - | - | - | - | 1 | - |
| G | - | - | - | - | - | 1 | - |
| H | - | - | - | - | - | 1 | - |
| I | - | - | - | - | 1 | - | - |



KYOCERA Document Solutions America, Inc.**Headquarters**

225 Sand Road,
Fairfield, New Jersey 07004-0008, USA
Phone: +1-973-808-8444
Fax: +1-973-882-6000

Latin America

8240 NW 52nd Terrace Dawson Building, Suite 100
Miami, Florida 33166, USA
Phone: +1-305-421-6640
Fax: +1-305-421-6666

KYOCERA Document Solutions Canada, Ltd.

6120 Kestrel Rd., Mississauga, ON L5T 1S8,
Canada
Phone: +1-905-670-4425
Fax: +1-905-670-8116

KYOCERA Document Solutions**Mexico, S.A. de C.V.**

Calle Arquimedes No. 130, 4 Piso, Colonia Polanco
Chapultepec, Delegacion Miguel Hidalgo,
Distrito Federal, C.P. 11560, México
Phone: +52-555-383-2741
Fax: +52-555-383-7804

KYOCERA Document Solutions Brazil, Ltda.

Alameda África, 545, Pólo Empresarial Consbrás,
Tamboré, Santana de Parnaíba, State of São Paulo, CEP
06543-306, Brazil
Phone: +55-11-2424-5353
Fax: +55-11-2424-5304

KYOCERA Document Solutions Chile SpA

Jose Ananias 505, Macul. Santiago, Chile
Phone: +562-2350-7000
Fax: +562-2350-7150

KYOCERA Document Solutions**Australia Pty. Ltd.**

Level 3, 6-10 Talavera Road North Ryde N.S.W, 2113,
Australia
Phone: +61-2-9888-9999
Fax: +61-2-9888-9588

KYOCERA Document Solutions**New Zealand Ltd.**

Ground Floor, 19 Byron Avenue, Takapuna, Auckland,
New Zealand
Phone: +64-9-415-4517
Fax: +64-9-415-4597

KYOCERA Document Solutions Asia Limited

Unit 3 & 5, 16/F., Mita Centre, 552-566, Castle Peak Road
Tsuen Wan, New Territories, Hong Kong
Phone: +852-2496-5678
Fax: +852-2610-2063

KYOCERA Document Solutions**(China) Corporation**

8F, No. 288 Nanjing Road West, Huangpu District,
Shanghai, 200003, China
Phone: +86-21-5301-1777
Fax: +86-21-5302-8300

KYOCERA Document Solutions**(Thailand) Corp., Ltd.**

335 Ratchadapisek Road, Wongsawang, Bangsue,
Bangkok 10800,
Thailand
Phone: +66-2-586-0333
Fax: +66-2-586-0278

KYOCERA Document Solutions**Singapore Pte. Ltd.**

12 Tai Seng Street #04-01A,
Luxasia Building, Singapore 534118
Phone: +65-6741-8733
Fax: +65-6748-3788

KYOCERA Document Solutions**Hong Kong Limited**

Unit 1,2,4,6,8 & 10, 16/F., Mita Centre, 552-566, Castle
Peak Road Tsuen Wan, New Territories, Hong Kong
Phone: +852-3582-4000
Fax: +852-3185-1399

KYOCERA Document Solutions**Taiwan Corporation**

6F., No.37, Sec. 3, Minquan E. Rd.,
Zhongshan Dist., Taipei 104, Taiwan R.O.C.
Phone: +886-2-2507-6709
Fax: +886-2-2507-8432

KYOCERA Document Solutions Korea Co., Ltd.

#3F Daewoo Foundation Bldg 18, Toegye-ro, Jung-gu,
Seoul, Korea
Phone: +822-6933-4050
Fax: +822-747-0084

KYOCERA Document Solutions**India Private Limited**

Second Floor, Centrum Plaza, Golf Course Road,
Sector-53, Gurgaon, Haryana 122002, India
Phone: +91-0124-4671000
Fax: +91-0124-4671001

KYOCERA Document Solutions Europe B.V.

Bloemlaan 4, 2132 NP Hoofddorp,
The Netherlands
Phone: +31-20-654-0000
Fax: +31-20-653-1256

KYOCERA Document Solutions Nederland B.V.

Beechavenue 25, 1119 RA Schiphol-Rijk,
The Netherlands
Phone: +31-20-5877200
Fax: +31-20-5877260

KYOCERA Document Solutions (U.K.) Limited

Eldon Court, 75-77 London Road,
Reading, Berkshire RG1 5BS,
United Kingdom
Phone: +44-118-931-1500
Fax: +44-118-931-1108

KYOCERA Document Solutions Italia S.p.A.

Via Monfalcone 15, 20132, Milano, Italy,
Phone: +39-02-921791
Fax: +39-02-92179-600

KYOCERA Document Solutions Belgium N.V.

Sint-Martinusweg 199-201 1930 Zaventem,
Belgium
Phone: +32-2-7209270
Fax: +32-2-7208748

KYOCERA Document Solutions France S.A.S.

Espace Technologique de St Aubin
Route de l'Orme 91195 Gif-sur-Yvette CEDEX,
France
Phone: +33-1-69852600
Fax: +33-1-69853409

KYOCERA Document Solutions Espana, S.A.

Edificio Kyocera, Avda. de Manacor No.2,
28290 Las Matas (Madrid), Spain
Phone: +34-91-6318392
Fax: +34-91-6318219

KYOCERA Document Solutions Finland Oy

Atomitie 5C, 00370 Helsinki,
Finland
Phone: +358-9-47805200
Fax: +358-9-47805390

**KYOCERA Document Solutions
Europe B.V., Amsterdam (NL) Zürich Branch**

Hohlstrasse 614, 8048 Zürich,
Switzerland
Phone: +41-44-9084949
Fax: +41-44-9084950

**KYOCERA Bilgitas Document Solutions
Turkey A.S.**

Gülbahar Mahallesi Otello Kamil Sk. No:6 Mecidiyeköy
34394 Şişli İstanbul, Turkey
Phone: +90-212-356-7000
Fax: +90-212-356-6725

**KYOCERA Document Solutions
Deutschland GmbH**

Otto-Hahn-Strasse 12, 40670 Meerbusch,
Germany
Phone: +49-2159-9180
Fax: +49-2159-918100

KYOCERA Document Solutions Austria GmbH

Altmannsdorferstraße 91, Stiege 1, 2. OG, Top 1, 1120,
Wien, Austria
Phone: +43-1-863380
Fax: +43-1-86338-400

KYOCERA Document Solutions Nordic AB

Esbogatan 16B 164 75 Kista, Sweden
Phone: +46-8-546-550-00
Fax: +46-8-546-550-10

KYOCERA Document Solutions Norge Nuf

Olaf Helsetsv. 6, 0619 Oslo, Norway
Phone: +47-22-62-73-00
Fax: +47-22-62-72-00

KYOCERA Document Solutions Danmark A/S

Ejby Industrivej 60, DK-2600 Glostrup,
Denmark
Phone: +45-70223880
Fax: +45-45765850

KYOCERA Document Solutions Portugal Lda.

Rua do Centro Cultural, 41 (Alvalade) 1700-106 Lisboa,
Portugal
Phone: +351-21-843-6780
Fax: +351-21-849-3312

**KYOCERA Document Solutions
South Africa (Pty) Ltd.**

KYOCERA House, Hertford Office Park,
90 Bekker Road (Cnr. Allandale), Midrand, South Africa
Phone: +27-11-540-2600
Fax: +27-11-466-3050

KYOCERA Document Solutions Russia LLC.

Building 2, 51/4, Schepkina St., 129110, Moscow,
Russia
Phone: +7(495)741-0004
Fax: +7(495)741-0018

KYOCERA Document Solutions Middle East

Dubai Internet City, Bldg. 17,
Office 157 P.O. Box 500817, Dubai,
United Arab Emirates
Phone: +971-04-433-0412

KYOCERA Document Solutions Inc.

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: +81-6-6764-3555
<http://www.kyoceradocumentsolutions.com>