



TASKalfa 420i

TASKalfa 520i

SERVICE

MANUAL

Published in June 2011
2KSSM064
Rev. 4

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

It may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for proper disposal.

ATTENTION

IL Y A UN RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UN MODÈLE DE TYPE INCORRECT. METTRE AU REBUT LES BATTERIES UTILISÉES SELON LES INSTRUCTIONS DONNÉES.

Il peut être illégal de jeter les batteries dans des eaux d'égout municipales. Vérifiez avec les fonctionnaires municipaux de votre région pour les détails concernant des déchets solides et une mise au rebut appropriée.

Revision history

Revision	Date	Replaced pages	Remarks
1	December 14, 2009	1-3-4, 1-3-5, 1-3-10, 1-3-12 to 1-3-16, 1-3-22, 1-3-23, 1-3-38, 1-3-41 to 1-3-43, 1-3-58, 1-3-59, 1-3-60, 1-3-74, 1-3-81, 1-3-84, 1-3-94 to 1-3-97, 1-3-100, 1-3-101, 1-4-3, 1-4-4, 1-4-8, 1-5-24, 1-5-25, 1-5-28, 1-6-1, 2-3-6, 2-3-7, 2-3-15 to 2-3-17, 2-4-1, 2-4-3 to 2-4-6	-
2	February 4, 2010	1-2-4, 1-2-11, 1-3-2, 1-3-3, 1-3-5, 1-3-25, 1-3-26, 1-3-50 to 1-3-53, 1-3-74, 1-3-95, 1-4-8, 1-4-11, 2-1-11	-
3	May 7, 2010	1-1-1	-
4	June 27,2011	1-3-94, 1-3-95	-


This page is intentionally left blank.


Safety precautions


This booklet provides safety warnings and precautions for our service personnel to ensure the safety of their customers, their machines as well as themselves during maintenance activities. Service personnel are advised to read this booklet carefully to familiarize themselves with the warnings and precautions described here before engaging in maintenance activities.

Safety warnings and precautions


Various symbols are used to protect our service personnel and customers from physical danger and to prevent damage to their property. These symbols are described below:


 **DANGER:** High risk of serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.


 **WARNING:** Serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.


 **CAUTION:** Bodily injury or damage to property may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

Symbols


The triangle () symbol indicates a warning including danger and caution. The specific point of attention is shown inside the symbol.


 General warning.

 Warning of risk of electric shock.


 Warning of high temperature.


 indicates a prohibited action. The specific prohibition is shown inside the symbol.


 General prohibited action.

 Disassembly prohibited.

 indicates that action is required. The specific action required is shown inside the symbol.



 General action required.

 Remove the power plug from the wall outlet.



 Always ground the copier.







1. Installation Precautions

WARNING

- Do not use a power supply with a voltage other than that specified. Avoid multiple connections to one outlet: they may cause fire or electric shock. When using an extension cable, always check that it is adequate for the rated current. 
- Connect the ground wire to a suitable grounding point. Not grounding the copier may cause fire or electric shock. Connecting the earth wire to an object not approved for the purpose may cause explosion or electric shock. Never connect the ground cable to any of the following: gas pipes, lightning rods, ground cables for telephone lines and water pipes or faucets not approved by the proper authorities. 











CAUTION:

- Do not place the copier on an infirm or angled surface: the copier may tip over, causing injury. 
- Do not install the copier in a humid or dusty place. This may cause fire or electric shock. 
- Do not install the copier near a radiator, heater, other heat source or near flammable material.





This may cause fire. 
- Allow sufficient space around the copier to allow the ventilation grills to keep the machine as cool as possible. Insufficient ventilation may cause heat buildup and poor copying performance. 
- Always handle the machine by the correct locations when moving it. 
- Always use anti-toppling and locking devices on copiers so equipped. Failure to do this may cause the copier to move unexpectedly or topple, leading to injury. 
- Avoid inhaling toner or developer excessively. Protect the eyes. If toner or developer is accidentally ingested, drink a lot of water to dilute it in the stomach and obtain medical attention immediately. If it gets into the eyes, rinse immediately with copious amounts of water and obtain medical attention. 
- Advise customers that they must always follow the safety warnings and precautions in the copier's instruction handbook. 

2.Precautions for Maintenance

WARNING

- Always remove the power plug from the wall outlet before starting machine disassembly. 
- Always follow the procedures for maintenance described in the service manual and other related brochures. 
- Under no circumstances attempt to bypass or disable safety features including safety mechanisms and protective circuits. 
- Always use parts having the correct specifications. 
- Always use the thermostat or thermal fuse specified in the service manual or other related brochure when replacing them. Using a piece of wire, for example, could lead to fire or other serious accident. 
- When the service manual or other serious brochure specifies a distance or gap for installation of a part, always use the correct scale and measure carefully. 
- Always check that the copier is correctly connected to an outlet with a ground connection. 
- Check that the power cable covering is free of damage. Check that the power plug is dust-free. If it is dirty, clean it to remove the risk of fire or electric shock. 
- Never attempt to disassemble the optical unit in machines using lasers. Leaking laser light may damage eyesight. 
- Handle the charger sections with care. They are charged to high potentials and may cause electric shock if handled improperly. 

CAUTION

- Wear safe clothing. If wearing loose clothing or accessories such as ties, make sure they are safely secured so they will not be caught in rotating sections. 
- Use utmost caution when working on a powered machine. Keep away from chains and belts. 
- Handle the fixing section with care to avoid burns as it can be extremely hot. 
- Check that the fixing unit thermistor, heat and press rollers are clean. Dirt on them can cause abnormally high temperatures. 

• Do not remove the ozone filter, if any, from the copier except for routine replacement.



• Do not pull on the AC power cord or connector wires on high-voltage components when removing them; always hold the plug itself.



• Do not route the power cable where it may be stood on or trapped. If necessary, protect it with a cable cover or other appropriate item.



• Treat the ends of the wire carefully when installing a new charger wire to avoid electric leaks.



• Remove toner completely from electronic components.



• Run wire harnesses carefully so that wires will not be trapped or damaged.



• After maintenance, always check that all the parts, screws, connectors and wires that were removed, have been refitted correctly. Special attention should be paid to any forgotten connector, trapped wire and missing screws.



• Check that all the caution labels that should be present on the machine according to the instruction handbook are clean and not peeling. Replace with new ones if necessary.



• Handle greases and solvents with care by following the instructions below:



- Use only a small amount of solvent at a time, being careful not to spill. Wipe spills off completely.
- Ventilate the room well while using grease or solvents.
- Allow applied solvents to evaporate completely before refitting the covers or turning the power switch on.
- Always wash hands afterwards.

• Never dispose of toner or toner bottles in fire. Toner may cause sparks when exposed directly to fire in a furnace, etc.



• Should smoke be seen coming from the copier, remove the power plug from the wall outlet immediately.



3. Miscellaneous

WARNING

• Never attempt to heat the drum or expose it to any organic solvents such as alcohol, other than the specified refiner; it may generate toxic gas.



This page is intentionally left blank.

CONTENTS

1-1 Specifications	
1-1-1 Specifications	1-1-1
1-1-2 Parts names	1-1-4
(1) Machine	1-1-4
(2) Operation panel	1-1-7
1-1-3 Machine cross section	1-1-8
1-2 Installation	
1-2-1 Installation environment	1-2-1
1-2-2 Unpacking and installation	1-2-2
(1) Installation procedure	1-2-2
(2) Setting initial copy modes	1-2-10
1-2-3 Installing the key counter (option)	1-2-11
1-2-4 Replacing the expanded memory	1-2-16
1-3 Maintenance Mode	
1-3-1 Maintenance mode	1-3-1
(1) Executing a maintenance item	1-3-1
(2) Maintenance modes item list	1-3-2
(3) Contents of the maintenance mode items	1-3-6
1-3-2 Management mode	1-3-107
(1) Using the management mode	1-3-107
(2) Common Settings	1-3-108
(3) Copy Settings	1-3-111
(4) Sending Settings	1-3-111
(5) Document Box Settings	1-3-111
(6) Printer Settings	1-3-112
(7) Printing Reports/Sending Notice	1-3-112
(8) Adjustment/Maintenance	1-3-113
(9) Date/Timer	1-3-113
(10) Editing Destination (Address Book/Adding One Touch Keys)	1-3-114
(11) Internet Browser Setup	1-3-115
(12) Applications	1-3-116
(13) System Settings	1-3-116
(14) User Login Administration	1-3-118
(15) Job accounting	1-3-119
1-4 Troubleshooting	
1-4-1 Paper misfeed detection	1-4-1
(1) Paper misfeed indication	1-4-1
(2) Paper misfeed detection conditions	1-4-2
(3) Paper misfeeds	1-4-12
1-4-2 Self-diagnosis	1-4-24
(1) Self-diagnostic function	1-4-24
(2) Self diagnostic codes	1-4-26
1-4-3 Image formation problems	1-4-48
(1) No image appears (entirely white)	1-4-49
(2) No image appears (entirely black)	1-4-49
(3) Image is too light	1-4-50
(4) Background is visible	1-4-50
(5) A white line appears longitudinally	1-4-50
(6) A black line appears longitudinally	1-4-51
(7) A black line appears laterally	1-4-51
(8) One side of the copy image is darker than the other	1-4-51
(9) Black dots appear on the image	1-4-51
(10) Image is blurred	1-4-52
(11) The leading edge of the image is consistently misaligned with the original	1-4-52
(12) The leading edge of the image is sporadically misaligned with the original	1-4-52
(13) Paper creases	1-4-52
(14) Offset occurs	1-4-53

(15) Image is partly missing.....	1-4-53
(16) Fusing is poor.....	1-4-53
(17) Image is out of focus.....	1-4-53
(18) Image center does not align with the original center.....	1-4-54
(19) Image is not square.....	1-4-54
1-4-4 Electric problems.....	1-4-55
1-4-5 Mechanical problems.....	1-4-60
1-4-6 Send error code.....	1-4-62
(1) Scan to SMB error codes.....	1-4-62
(2) Scan to FTP error codes.....	1-4-63
(3) Scan to E-mail error codes.....	1-4-64
(4) Network Twain error codes.....	1-4-65
(5) Software trouble error codes.....	1-4-65
1-5 Assembly and Disassembly	
1-5-1 Precautions for assembly and disassembly.....	1-5-1
(1) Precautions.....	1-5-1
(2) Drum.....	1-5-1
(3) Toner.....	1-5-1
(4) How to tell a genuine Kyocera Mita toner container.....	1-5-2
1-5-2 Paper feed section.....	1-5-3
(1) Detaching and refitting the forwarding, paper feed and separation pulleys.....	1-5-3
(2) Detaching and refitting the MP separation, MP paper feed and MP forwarding pulleys.....	1-5-5
(3) Detaching and refitting the left and right registration cleaner.....	1-5-10
1-5-3 Optical section.....	1-5-12
(1) Detaching and refitting the exposure lamp.....	1-5-12
(2) Detaching and refitting the scanner wires.....	1-5-16
(3) Detaching and refitting the ISU (reference).....	1-5-20
(4) Detaching and refitting the laser scanner unit.....	1-5-22
(5) Adjusting the skew of the laser scanner unit (reference).....	1-5-24
1-5-4 Drum section.....	1-5-25
(1) Detaching and refitting the drum unit.....	1-5-25
(2) Detaching and refitting the main charger unit.....	1-5-26
(3) Detaching and refitting the drum separation claws.....	1-5-27
1-5-5 Developing section.....	1-5-28
(1) Detaching and refitting the developing unit.....	1-5-28
1-5-6 Transfer section.....	1-5-29
(1) Detaching and refitting the transfer roller unit.....	1-5-29
1-5-7 Fuser section.....	1-5-30
(1) Detaching and refitting the fuser unit.....	1-5-30
(2) Detaching and refitting the heat roller separation claws.....	1-5-31
(3) Detaching and refitting the press roller.....	1-5-32
(4) Detaching and refitting the fuser heater.....	1-5-33
(5) Detaching and refitting the heat roller.....	1-5-34
(6) Detaching and refitting the fuser thermistor 1 and 2.....	1-5-35
(7) Adjusting front position of the fuser unit (adjusting lateral squareness).....	1-5-36
1-5-8 Others.....	1-5-37
(1) Detaching and refitting the ozone filter 1 and 2.....	1-5-37
(2) Detaching and refitting the dust filter 1 and 2.....	1-5-38
(3) Detaching and refitting the ISU filter.....	1-5-39
(4) Detaching and refitting the hard disk.....	1-5-40
(5) Direction of installing the principal fan motors.....	1-5-43
1-6 Requirements on PWB Replacement	
1-6-1 Upgrading the firmware.....	1-6-1
1-6-2 Adjustment-free variable resistors (VR).....	1-6-1
1-6-3 Remarks on main PWB replacement.....	1-6-2
1-6-4 Remarks on engine PWB replacement.....	1-6-3
2-1 Mechanical construction	
2-1-1 Paper feed section.....	2-1-1
(1) Cassette paper feed section.....	2-1-1
(2) MP tray paper feed section.....	2-1-3

2-1-2	Optical section	2-1-5
	(1) Image scanner section	2-1-5
	(2) Laser scanner section	2-1-7
2-1-3	Drum section	2-1-9
2-1-4	Developing section	2-1-11
	(1) Single component developing system	2-1-13
2-1-5	Transfer and separation sections	2-1-14
2-1-6	Fuser section	2-1-15
2-1-7	Eject and switchback sections	2-1-17
2-1-8	Duplex section	2-1-19
2-2 Electrical Parts Layout		
2-2-1	Electrical parts layout	2-2-1
	(1) PWBs	2-2-1
	(2) Switches and sensors	2-2-3
	(3) Motors	2-2-5
	(4) Others	2-2-6
2-3 Operation of the PWBs		
2-3-1	Power source PWB	2-3-1
2-3-2	Engine PWB	2-3-5
2-3-3	Main PWB	2-3-14
2-3-4	ISM PWB	2-3-23
2-3-5	Main operation PWB	2-3-26
2-4 Appendixes		
	Maintenance parts list	2-4-1
	Maintenance kits	2-4-2
	Periodic maintenance procedures	2-4-3
	Chart of image adjustment procedures	2-4-7
	Wiring diagram No.1	2-4-9
	Wiring diagram No.2	2-4-10
	Wiring diagram No.3	2-4-11
	Wiring diagram No.4	2-4-12
	Wiring diagram No.5	2-4-13
INSTALLATION GUIDE		
	DOCUMENT PROCESSOR	
	PAPER FEEDER	
	3000 SHEETS PAPER FEEDER	
	DOCUMENT FINISHER	
	3000 SHEETS DOCUMENT FINISHER	
	CENTER-FOLDING UNIT	
	MAILBOX	
	HOLE PUNCH UNIT	
	BUILT-IN FINISHER	
	JOB SEPARATOR	
	FAX System	

This page is intentionally left blank.

1-1-1 Specifications

Machine

Type	Desktop
Printing method.....	Electrophotography by semiconductor laser, tandem drum system
Supported original types	Sheets, books and three-dimensional objects
	Maximum original size: A3/Ledger
Original feed system	Fixed
Paper weight.....	Cassette : 60 to 105 g/m ² MP tray : 45 to 200 g/m ²
Paper type	Cassette: Plain, Rough, Vellum, Recycled, Preprinted, Bond, Color (Colour), Prepunched, Letterhead, High Quality, Custom 1 to 8 (Duplex: Same as Simplex) MP tray: Plain, Transparency (OHP film), Rough, Vellum, Labels, Recycled, Preprinted, Bond, Cardstock (Hagaki), Color (Colour), Prepunched, Letterhead, Thick, Envelope, High Quality, Custom 1 to 8
Paper size	Cassette: A3, B4, A4, A4R, B5, B5R, A5R, Ledger, Legal, Letter, LetterR, Statement, Oficio II, 8.5 x 13.5", Folio, 8K, 16K, 16KR MP tray: A3, B4, A4, A4R, B5, B5R, A5R, B6R, A6R, Ledger, Legal, Letter, LetterR, ExecutiveR, Statement, Oficio II, 8.5 x 13.5", Folio, 8K, 16K, 16KR, Postcards (100 x 148 mm), Return postcard (148 x 200 mm), Envelope DL, Envelope C5, Envelope C4, Envelope #10 (Commercial #10), Envelope #9 (Commercial #9), Envelope #6 (Commercial #6 3/4), Monarch, ISO B5, Youkei 2, Youkei 4
Zoom level	Manual mode: 25 to 400%, 1% increments Auto mode: Preset zoom
Printing speed.....	42 ppm model A4/Letter: 42 sheets/min. A4R/LetterR: 27 sheets/min. A3/Ledger: 23 sheets/min. B4/Legal: 23 sheets/min. B5: 42 sheets/min. B5R: 22 sheets/min. A5R: 16 sheets/min. 52 ppm model A4/Letter: 52 sheets/min. A4R/LetterR: 31 sheets/min. A3/Ledger: 26 sheets/min. B4/Legal: 26 sheets/min. B5: 52 sheets/min. B5R: 24 sheets/min. A5R: 18 sheets/min.
First copy time	3.9 s or less
Warm-up time	Room temperature 22°C/71.6°F, 60% RH Power on: 30 s or less Sleep mode: 15 s or less
Paper capacity	Cassette : 500 sheets (80 g/m ²) MP tray : 200 sheets (80 g/m ²)
Output tray capacity.....	Top tray : 250 sheets (80 g/m ²) When built-in finisher installed: 150 sheets (80 g/m ²) When job separator installed: 250 sheets (80 g/m ²)
Continuous copying	1 to 999 sheets
Light source	Inert gas lamp
Scanning system	Flat bed scanning by CCD image sensor
Photoconductor.....	a-Si (drum diameter 40 mm)
Image write system.....	Semiconductor laser and electrophotography
Charging system.....	Single positive corona charging
Developing system	Dry, reverse developing (single component system) Developer: 1-component, magnetism toner Toner replenishing: automatic from a toner container

2KR/2KS

Transfer system	Transfer roller
Separation system	Curvature separation and separation electrode
Cleaning system	Cleaning blade and roller
Charge erasing system	Exposure by cleaning lamp
Fusing system	Heat roller
	Heat source: halogen heaters
	Abnormally high temperature protection devices: thermostats
Main memory	Standard : 2048 MB
	Maximum: 2048 MB
Hard disk	160 GB
Interface	USB interface connector: 1 (USB Hi-speed)
	USB memory slot: 2 (Full-speed USB)
	Network interface: 1 (10 BASE-T/100 BASE-TX)
	Optional interface: 2 (KUIO/W)
Resolution	600 x 600 dpi
Operating environment	Temperature: 10 to 32.5°C/50 to 90.5°F
	Humidity: 15 to 80% RH
	Altitude: 2500 m/8,202 ft maximum
	Brightness: 1500 lux maximum
Dimensions	599 (W) x 646 (D) x 745 (H) mm (main unit only)
	23 9/16" (W) x 25 7/16" (D) x 29 5/16" (H) (main unit only)
Weight	85 kg/187 lbs
Space required	753 (W) x 646 (D) mm (using MP tray)
	29 5/8" (W) x 25 7/16" (D) (using MP tray)
Power source	120 V AC, 60 Hz, 12 A
	220 to 240 V AC, 50 Hz, 6.3 A
Options	Document processor, paper feeder, 3000-sheet paper feeder, document finisher, 3000-sheet document finisher, centerfold unit, mailbox, punch unit, built-in finisher, job separator, key counter, fax kit, expansion memory, data security kit and printed document guard kit

Printer functions

Printing speed	Same as copying speed
First print time	4.8 s or less
Resolution	600 dpi
Operating system	Windows 2000 (Service Pack 2 or later), Windows XP, Windows Server 2003, Windows Vista, Apple Macintosh OS 10.x
Interface	USB interface connector: 1 (USB Hi-speed)
	Network interface: 1 (10 BASE-T/100 BASE-TX)
PDL	PRESCRIBE

Scanner functions

Operating system.....	Windows 2000 (Service Pack 2 or later), Windows XP, Windows Vista		
System requirements.....	CPU 600 MHz or higher RAM 128 MB or more		
Resolution.....	600 dpi, 400 dpi, 300 dpi, 200 dpi, 200 x 100 dpi, 200 x 400 dpi		
File format.....	TIFF (MMR/JPEG compression), JPEG, XPS, PDF (MMR/JPEG compression), PDF (high compression)		
Scanning speed.....	A4, 600 dpi, Image quality: Text/Photo original, B/W Single scanning: 52 images/min		
Interface.....	Ethernet (10 BASE-T/100 BASE-TX)		
Network protocol.....	TCP/IP		
Transmission system	PC transmission	SMB	Scan to SMB
		FTP	Scan to FTP, FTP over SSL
	E-mail transmission	SMTP	Scan to E-mail
	Twain scan		
	WIA scan		

NOTE: These specifications are subject to change without notice.

1-1-2 Parts names

(1) Machine




Figure 1-1-1

- 1. Original cover (option)
- 2. Original size indicator plates
- 3. Clip holder
- 4. Slit glass
- 5. Attention indicator
- 6. Receive indicator
- 7. Left cover 1
- 8. Left cover 1 lever
- 9. Left cover 2
- 10. Left cover 2 handle
- 11. Contact glass
- 12. Operation panel
- 13. Cassette 1
- 14. Cassette 2




Figure 1-1-2

- 15. Toner container stopper
- 16. Toner container
- 17. Waste toner box
- 18. Paper feed unit (A2)
- 19. Paper feed unit cover (A3)
- 20. Knob




Figure 1-1-3

- 21. USB memory slot (A1)
- 22. Front cover
- 23. Paper width adjusting tab
- 24. Paper length guide
- 25. Top tray
- 26. Main power switch
- 27. Paper width guide
- 28. MP tray (multi purpose tray)
- 29. Optional interface slot (OPT2)
- 30. USB memory slot (A2)
- 31. USB interface connector (B1)
- 32. Network interface connector
- 33. Optional interface slot (OPT1)

(2) Operation panel




Figure 1-1-4

- | | |
|-------------------------------------|---------------------------------|
| 1. System menu key/indicator | 14. Program key/indicator |
| 2. Counter key/indicator | 15. Application key/indicator |
| 3. Help key/indicator | 16. Document box key/indicator |
| 4. Print indicator | 17. Accessibility key/indicator |
| 5. Send indicator | 18. Send key/indicator |
| 6. Receive indicator | 19. Copy key/indicator |
| 7. Memory indicator | 20. Numeric keys |
| 8. Attention indicator | 21. Clear key |
| 9. Interrupt key/indicator | 22. Quick No. search key |
| 10. Logout key/indicator | 23. Enter key |
| 11. Power key/indicator | 24. Start key/indicator |
| 12. Main power indicator | 25. Stop key |
| 13. Status/Job cancel key/indicator | 26. Reset key |

1-1-3 Machine cross section




Figure 1-1-5 Machine cross section

- | | |
|--------------------------------|-------------------------------------|
| 1. Cassette paper feed section | 7. Toner container section |
| 2. MP tray paper feed section | 8. Transfer and separation sections |
| 3. Image scanner section | 9. Fuser section |
| 4. Laser scanner section | 10. Eject and switchback sections |
| 5. Drum section | 11. Duplex section |
| 6. Developing section | |

1-2-1 Installation environment

1. Temperature: 10 to 32.5°C/50 to 90.5°F
2. Humidity: 15 to 80%RH
3. Power supply: 120 V AC, 12 A
220 to 240 V AC, 6.3 A
4. Power source frequency: 50 Hz \pm 0.3%/60 Hz \pm 0.3%
5. Installation location

Avoid direct sunlight or bright lighting. Ensure that the photoconductor will not be exposed to direct sunlight or other strong light when removing paper jams.

Avoid locations subject to high temperature and high humidity or low temperature and low humidity; an abrupt change in the environmental temperature; and cool or hot, direct air.

Avoid places subject to dust and vibrations.

Choose a surface capable of supporting the weight of the machine.

Place the machine on a level surface (maximum allowance inclination: 1°).

Avoid air-borne substances that may adversely affect the machine or degrade the photoconductor, such as mercury, acidic or alkaline vapors, inorganic gasses, NOx, SOx gases and chlorine-based organic solvents.

Select a well-ventilated location.
6. Allow sufficient access for proper operation and maintenance of the machine.

Machine front: 1000 mm/39 3/8" Machine rear: 100 mm/3 15/16"

Machine right: 300 mm/11 13/16" Machine left: 300 mm/11 13/16"





Figure 1-2-1 Installation dimensions

1-2-2 Unpacking and installation

(1) Installation procedure



Moving the machine

When moving the machine, pull out the four handles on the right and left sides and hold them.




Figure 1-2-2

Unpacking.




Figure 1-2-3 Unpacking

- | | |
|---------------------|-----------------------|
| 1. Machine | 11. Document tray |
| 2. Outer case | 12. Power cord |
| 3. Inner frame | 13. Plastic bag |
| 4. Skid | 14. Operation guide |
| 5. Bottom left pad | 15. Paper size plates |
| 6. Bottom right pad | 16. Plastic bag |
| 7. Upper left pad | 17. Cursor pins |
| 8. Upper right pad | 18. Hinge joints |
| 9. Sheets | 19. Bar code labels |
| 10. Machine cover | |

Caution: Place the machine on a level surface.

Remove the tapes and pad.

1. Remove two tapes.
2. Remove the pad.




Figure 1-2-4

Install the optional paper feeder.

1. Install the optional paper feeder as necessary.
2. Verify levelness at the four corners of the platen using a level gauge, and adjust the level bolts at the bottom of the machine to optimize levelness.

Release the lever holding mirror 1 and 2 frames.

1. Turn the lever of the machine rear side with the tool to release the lever holding the mirror 1 and 2 frames.




Figure 1-2-5

Release of cassette lift plate.

1. Pull cassette 1 and 2 out.
Remove the lift plate stopper from each cassette and attach it to the storage location. When moving the machine, attach the lift plate in original position.




Figure 1-2-6

Load paper.

1. Pull the cassette out.
2. Holding the paper width adjusting tab both ends, move the paper width guides to fit the paper size.




Figure 1-2-7

3. Adjust the length adjustment plate to fit the paper size.




Figure 1-2-8

- Align the paper flush against the left side of the cassette.




Figure 1-2-9

Install the toner container.

- Open the front cover.
- Tap the top of the toner container five to six times.




Figure 1-2-10

- Shake the toner container approximately 10 times in the horizontal direction to stir toner.




Figure 1-2-11

4. Gently push the toner container into the machine along the rails. Push the container all the way into the machine until it locks in place.




Figure 1-2-12

Install the waste toner box.

1. Install the waste toner box in the machine.
2. Close the front cover.




Figure 1-2-13

Install the optional original cover or the DP.

1. Install the optional original cover or DP.

Install other optional devices.

1. Install the optional devices (job separator, built-in finisher, document finisher and/or fax kit etc.) as necessary.

Connect the power cord.

1. Connect the power cord to the connector on the machine.
2. Insert the power plug into the wall outlet.

Installing toner.

1. Turn the main power switch on. Toner installation is started.
2. The drive chain is disengaged when toner installation is completed.
Run maintenance mode U130 if [Add Toner] remains displayed even after the drive chain is disengaged.

Setting the delivery date (maintenance item U278).

1. Enter the maintenance mode by entering 10871087 using the numeric keys.
2. Enter 278 using the numeric keys and press the start key.
3. Select [TODAY] and press the start key. The delivery date is set.
4. Press the stop key.

Output an own-status report (maintenance item U000).

1. Enter 000 using the numeric keys and press the start key.
2. Select [MAINTENANCE] and press the start key to output a list of the current settings of the maintenance items.
3. Press the stop key.

Exit maintenance mode.

1. Enter 001 using the numeric keys and press the start key. The machine exits the maintenance mode.

Print out the user setting list.

1. Select [Report Print] to output the user various setting reports.

Make test copies.

1. Place an original and make test copies.

Attaching the language label (230 V specifications only).

1. According to need, attach the correspond language label.

Completion of the machine installation.

(2) Setting initial copy modes

Factory settings are as follows:

Maintenance item No.	Contents	Factory setting
U253	Switching between double and single counts	DOUBLE COUNT(A3/LEDGER)
U260	Selecting the timing for copy counting	After ejection
U285	Setting service status page	ON
U326	Setting the black line cleaning indication	ON/8
U328	Side ejection setting	OFF
U342	Setting the ejection restriction	ON
U343	Switching between duplex/simplex copy mode	OFF

1-2-3 Installing the key counter (option)

Installing the key counter requires the following component:

Key counter (P/N 3025418011)

Key counter set (P/N 302A369708)

Supplied parts of key counter set:

Key counter socket assembly (P/N 3029236241)

Key counter cover (P/N 3066060011)

Key counter mount (P/N 3066060041)

Key counter retainer (P/N 302GR03020)

Key counter cover retainer (P/N 302GR03010)

Two (2) Edgings (P/N 7YZM210006++H01)

One (1) Band (P/N M21AH010)

One (1) M3 × 8 tap-tight P screw (P/N 5MBTPB3008PW++R)

Two (2) M4 × 10 tap-tight P screws (P/N 5MBTPB4010PW++R)

Two (2) M4 × 10 tap-tight S screws (P/N 5MBTPB4010TW++R)

Two (2) M3 × 6 bronze flat-head screws (P/N 7BB003306H)

One (1) M4 × 20 tap-tight S screw (P/N 7BB100420H)

One (1) M3 bronze nut (P/N 7BC1003055++H01)

One (1) M3 × 8 bronze binding screw (P/N B1B03080)

One (1) M4 × 30 tap-tight S screw (P/N B1B54300)

Five (5) M4 × 6 chrome TP screws (P/N B4A04060)

Two (2) M4 × 10 chrome TP screws (P/N B4A04100)

Procedure

1. Press the power key on the operation panel to off. Make sure that the main power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Fit the key counter socket assembly to the key counter retainer using two screws and nut.
3. Fit the key counter mount to the key counter cover using two screws.
4. Fit the key counter retainer to the key counter mount using two screws.




Figure 1-2-14

5. Remove the ISU filter cover.
6. Remove ten screws and then remove the rear cover.




Figure 1-2-15

7. Remove two screws and then remove the scanner right cover.




Figure 1-2-16

8. Remove three screws and then remove the right upper cover.
9. Cut out the aperture plate on the right upper cover using nippers.




Figure 1-2-17

10. Release the wire saddle and then stretch the key counter wire.
11. Close the wire saddle.




Figure 1-2-18

12. Refit the rear cover and ISU filter cover.
13. Pass the key counter wire through the aperture and then refit the upper right cover.




Figure 1-2-19

14. Pass the connector of the key counter wire through the aperture in the key counter cover retainer.
15. Insert the hook of the key counter cover retainer in the slit of the right upper cover.
16. Fit the key counter cover retainer to the machine using the M4 x 20 screw.
17. Refit the scanner right cover.




Figure 1-2-20

18. Connect the connector of the key counter signal cable to the connector of the key counter wire.
19. Fit the key counter cover with the key counter socket assembly inserted to the key counter cover retainer using the M4 x 6 screw.
20. Insert the key counter into the key counter socket assembly.




Figure 1-2-21

21. Turn the main power switch on and enter the maintenance mode.
22. Run maintenance item U204 and select [KEY COUNTER].
23. Exit the maintenance mode.
24. Check that the message requesting the key counter to be inserted is displayed on the touch panel when the key counter is pulled out.
25. Check that the counter counts up as prints are made.

1-2-4 Replacing the expanded memory

Procedure

1. Press the power key on the operation panel to off. Make sure that the main power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Remove the screw and remove the main PWB lid.
3. Open clamps on both ends of the memory socket on the main PWB.
4. Remove the expanded memory.
5. Insert the expanded memory into the memory socket so that the notch on the memory align with the corresponding protrusion in the slot.

The memory module is secured to the memory socket with the clamps.

6. Refit the main PWB lid.
7. Print a status page to check the expanded memory (See page 1-3-6).





Figure 1-2-22

1-3-1 Maintenance mode

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a maintenance item



(2) Maintenance modes item list

Section	Item No.	Content of maintenance item	Initial setting*
General	U000	Outputting an own-status report	-
	U001	Exiting the maintenance mode	-
	U002	Setting the factory default data	-
	U003	Setting the service telephone number	*****
	U004	Displaying the machine number	-
	U019	Displaying the ROM version	-
Initialization	U021	Initializing counters and mode settings	-
	U024	HDD formatting	-
Drive, paper feed, paper conveying and cooling system	U030	Checking motor operation	-
	U031	Checking switches for paper conveying	-
	U032	Checking clutch operation	-
	U033	Checking solenoid operation	-
	U034	Adjusting the print start timing Adjusting the leading edge registration Adjusting the center line	0/0/0/0/0/0 0/0/0/0/0/0
	U035	Setting the printing area for folio paper Length/Width	330/210
	U037	Checking the operation of the fan motors	-
	U051	Adjusting the deflection in the paper	0/0/0/0
	U053	Setting the adjustment of the motor speed Drive motor Eject motor Polygon motor Paper feed motor	0 0 0 0
	U059	Setting fan mode	MODE1
Optical	U061	Turning the exposure lamp on	-
	U063	Adjusting the shading position	0
	U065	Adjusting the scanner magnification Main scanning direction/Auxiliary scanning direction	0/0
	U066	Adjusting the scanner leading edge registration	0/0
	U067	Adjusting the scanner center line	0/0
	U068	Adjusting the scanning position for originals from the DP	0/0
	U070	Adjusting the DP magnification	0/0/0/0
	U071	Adjusting the DP scanning timing	0/0/0/0/0/0
	U072	Adjusting the DP center line	0/0/0
	U073	Checking scanner operation	-
	U074	Adjusting the DP input light luminosity	0
	U080	Setting the economy mode	60
	U081	Adjusting the correct exposure	0/0/0
	U087	Setting DP reading position modification operation	145/145/145
	U089	Outputting a MIP-PG pattern	-
	U091	Setting the white line correction	75/0
	U093	Setting the exposure density gradient	0/0/0/0/0

*: Factory initial setting, *1: The item initialized for executing U021

Section	Item No.	Content of maintenance item	Initial setting*
Optical	U099	Adjusting original size detection	40/30/20/40/30/20/40/30/20/ 19/19/19/150 (DP not installed) 50/50/50/50/50/50/50/50/50/ 49/49/49/150 (DP installed)
High voltage	U100	Setting the main high voltage	-
	U101	Setting the other high voltages Developing bias AC component frequency at image formation Developing shift bias potential at image formation Developing bias AC component duty at image formation Transfer control voltage Separation control voltage	28 1 50 130 20
	U102	Setting the cleaning interval for the main charger	5 ^{*1}
	U109	Displaying the drum type	-
	U110	Checking the drum count	-
	U111	Checking the drum drive time	-
	U112	Setting toner refresh operation Time of toner refreshment Developing bias on time	120 540
	U114	Setting separation charger mode	MODE3
	U117	Checking the drum number	-
	U118	Displaying the drum history	-
	U127	Checking the transfer count	-
Developing	U130	Initial setting for the developing unit	-
	U136	Setting toner near end mode	OFF
	U139	Displaying the temperature and humidity	-
	U144	Setting toner disposal operation	MODE2
	U155	Checking sensors for toner	-
	U157	Checking the developing drive time	-
	U158	Checking the developing count	-
Fuser and cleaning	U161	Setting the fuser control temperature Driving start temperature when warm-up starts Control temperature for displaying [Ready for copying.] Control temperature during printing Printing speed control at over-hearing on the fuser ends	185 ^{*1} 200 ^{*1} 200 ^{*1} MODE1
	U163	Resetting the fuser problem data	-
	U167	Checking/clearing the fuser counts	-
	U196	Turning the fuser heater on	-
	U198	Setting the fuser phase control	ON
	U199	Checking the fuser temperature	-
Operation panel and support equipment	U200	Turning all LEDs on	-
	U201	Initializing the touch panel	-
	U202	Setting the KMAS host monitoring system	-
	U203	Checking DP operation	-
	U204	Setting the presence or absence of a key card or key counter	OFF/KEY-DEVICE ^{*1}
	U206	Setting the presence or absence of the coin vender	-
	U207	Checking the operation panel keys	-

*: Factory initial setting, *1: The item initialized for executing U021

Section	Item No.	Content of maintenance item	Initial setting*
Operation panel and support equipment	U208	Setting the paper size for the paper feeder	Inch specifications: Letter*1 Metric specifications: A4*1
	U221	Setting the USB host lock function	OFF*1
	U222	Setting the IC card type	-
	U223	Operation panel lock	Unlock*1
	U224	Panel sheet extension	-
	U234	Setting punch destination	AUTO
	U236	Setting the limit for the ejection section of the built-in finisher	OFF*1
	U237	Setting finisher stack quantity	0/0*1
	U240	Checking the operation of the finisher	-
	U241	Checking the operation of the switches of the finisher	-
	U243	Checking the operation of the DP motors	-
	U244	Checking the DP switches	-
	U245	Checking messages	-
	U246	Setting the finisher 3000-sheet document finisher Centerfold unit Built-in finisher	0/0/0/0/0/0*1 0/0/0/0/0/0/0*1 0/0/0*1
	U247	Setting the paper feed device	-
Mode setting	U250	Setting the maintenance cycle	-
	U251	Checking/clearing the maintenance count	-
	U252	Setting the destination	-
	U253	Switching between double and single counts	DOUBLE COUNT (A3/LEDGER)*1
	U260	Selecting the timing for copy counting	After ejection*1
	U265	Setting OEM purchaser code	-
	U278	Setting the delivery date	-
	U285	Setting service status page	ON
	U326	Setting the black line cleaning indication	ON/8*1
	U328	Side ejection setting	OFF*1
	U332	Setting the size conversion factor	1.0*1
	U341	Specific paper feed location setting for printing function	-
	U342	Setting the ejection restriction	ON*1
	U343	Switching between duplex/simplex copy mode	OFF*1
	U345	Setting the value for maintenance due indication	0*1
Image processing	U402	Adjusting margins of image printing	4.0/3.0/3.0/3.9/4.0/4.0
	U403	Adjusting margins for scanning an original on the platen	2.0/2.0/2.0/2.0
	U404	Adjusting margins for scanning an original from the DP	3.0/2.5/3.0/4.0/ 3.0/2.5/3.0/4.0
	U407	Adjusting the leading edge registration for memory image printing	0
	U410	Adjusting the halftone automatically	-
	U411	Adjusting the scanner automatically	-

*: Factory initial setting, *1: The item initialized for executing U021

Section	Item No.	Content of maintenance item	Initial setting*
Image processing	U425	Setting the target	-
	U470	Setting the JPEG compression ratio System Copy Send	90/90*1 90/90/90/90*1 30/40/51/70/90*1 30/40/51/70/90*1 30/40/51/70/90*1 30/40/51/70/90*1 15/25/60*1 15/25/60*1
	U473	Adjusting laser power output	0
	U485	Setting the image processing mode	1/0*1
Network scanner	U510	Setting the enterprise mode	-
Others	U901	Checking/clearing copy counts by paper feed locations	-
	U902	Checking/clearing the punch-hole scrap counter	35000/0
	U903	Checking/clearing the paper jam counts	-
	U904	Checking/clearing the service call counts	-
	U905	Checking/clearing counts by optional devices	-
	U906	Resetting partial operation control	-
	U908	Checking the total counter value	-
	U910	Clearing the black ratio data	-
	U911	Checking copy counts by paper sizes	-
	U917	Setting backup data reading/writing	-
	U920	Checking the copy counts	-
	U927	Clearing the all copy counts and machine life counts (one time only)	-
	U928	Checking machine life counts	-
	U931	Setting the automatic toner install	OFF
	U935	Relay board maintenance	MODE0*1
	U942	Setting of deflection for feeding from DP	0/0/0
	U964	Checking of log	-
	U969	Checking of toner area code	-
	U977	Data capture mode	-
	U984	Checking the developing unit number	-
	U985	Displaying the developing unit history	-
U989	HDD scandisk	-	
U990	Checking/clearing the time for the exposure lamp to light	-	
U991	Checking the scanner count	-	

*: Factory initial setting, *1: The item initialized for executing U021

(3) Contents of the maintenance mode items

Maintenance item No.	Description																																
U000	<p>Outputting an own-status report</p> <p>Description Outputs lists of the current settings of the maintenance items, and paper jam and service call occurrences. Outputs the event log or service status page. Also sends output data to the USB memory. Printing a report is disabled either when a job is remaining in the buffer or when [Pause All Print Jobs] is pressed to halt printing.</p> <p>Purpose To check the current setting of the maintenance items, or paper jam or service call occurrences. Before initializing or replacing the backup RAM, output a list of the current settings of the maintenance items to reenter the settings after initialization or replacement.</p> <p>Method</p> <ol style="list-style-type: none"> Press the start key. Select the item to be output. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Output list</th> </tr> </thead> <tbody> <tr> <td>MAINTENANCE</td> <td>List of the current settings of the maintenance modes</td> </tr> <tr> <td>USER STATUS</td> <td>Outputs the user status page</td> </tr> <tr> <td>SERVICE STATUS</td> <td>Outputs the service status page</td> </tr> <tr> <td>EVENT</td> <td>Outputs the event log</td> </tr> <tr> <td>NETWORK STATUS</td> <td>Outputs the network status page</td> </tr> <tr> <td>ALL</td> <td>Outputs the all reports</td> </tr> </tbody> </table> <ol style="list-style-type: none"> Press the start key. The interrupt print mode is entered and a list is output. When A4/Letter paper is available, a report of this size is output. If not, specify the paper feed location. When output is complete, the screen for selecting an item is displayed. The output status is displayed. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> </tr> </thead> <tbody> <tr> <td>READY</td> <td>Standing by for output (including while outputting other reports)</td> </tr> <tr> <td>ACTIVE</td> <td>Performing output processing</td> </tr> <tr> <td>COMPLETE</td> <td>Output processing completed normally</td> </tr> <tr> <td>ERROR</td> <td>Output processing terminated with an error</td> </tr> </tbody> </table> <p>Method: Send to the USB memory</p> <ol style="list-style-type: none"> Press the power key on the operation panel, and after verifying the main power indicator has gone off, switch off the main power switch. Insert USB memory in USB memory slot. Turn the main power switch on. Enter the maintenance item. Press the start key. Select the item to be send. Select [TEXT] or [HTML]. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Output list</th> </tr> </thead> <tbody> <tr> <td>Print</td> <td>Outputs the report</td> </tr> <tr> <td>To USB (TEXT)</td> <td>Sends output data to the USB memory (text type)</td> </tr> <tr> <td>To USB (HTML)</td> <td>Sends output data to the USB memory (HTML type)</td> </tr> </tbody> </table> <ol style="list-style-type: none"> Press the start key. Output will be sent to the USB memory. 	Display	Output list	MAINTENANCE	List of the current settings of the maintenance modes	USER STATUS	Outputs the user status page	SERVICE STATUS	Outputs the service status page	EVENT	Outputs the event log	NETWORK STATUS	Outputs the network status page	ALL	Outputs the all reports	Display	Description	READY	Standing by for output (including while outputting other reports)	ACTIVE	Performing output processing	COMPLETE	Output processing completed normally	ERROR	Output processing terminated with an error	Display	Output list	Print	Outputs the report	To USB (TEXT)	Sends output data to the USB memory (text type)	To USB (HTML)	Sends output data to the USB memory (HTML type)
Display	Output list																																
MAINTENANCE	List of the current settings of the maintenance modes																																
USER STATUS	Outputs the user status page																																
SERVICE STATUS	Outputs the service status page																																
EVENT	Outputs the event log																																
NETWORK STATUS	Outputs the network status page																																
ALL	Outputs the all reports																																
Display	Description																																
READY	Standing by for output (including while outputting other reports)																																
ACTIVE	Performing output processing																																
COMPLETE	Output processing completed normally																																
ERROR	Output processing terminated with an error																																
Display	Output list																																
Print	Outputs the report																																
To USB (TEXT)	Sends output data to the USB memory (text type)																																
To USB (HTML)	Sends output data to the USB memory (HTML type)																																

Maintenance item No.	Description																																																																																																																																																																																																																										
U000	<p data-bbox="271 291 383 324">Event log</p> <div data-bbox="335 380 1364 1489" style="border: 1px solid black; padding: 10px;"> <h3 data-bbox="367 403 582 459">Event Log</h3> <p data-bbox="367 459 430 481">MFP</p> <p data-bbox="367 492 798 515">Firmware version 2KS_2000.001.001 2009.06.17</p> <p data-bbox="502 526 766 548">(1) (2)</p> <div style="display: flex; justify-content: space-between;"> <div data-bbox="351 560 550 593">(3) Paper Jam Log</div> <div data-bbox="885 560 1101 593">(4) Service Call Log</div> </div> <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <th style="width: 10%;">#</th> <th style="width: 15%;">Count.</th> <th style="width: 40%;">Event Descriptions</th> <th style="width: 10%;">#</th> <th style="width: 15%;">Count.</th> <th style="width: 10%;">Service Code</th> </tr> <tr> <td>16</td> <td>1876543</td> <td>10.01.08.01.01</td> <td>8</td> <td>1881214</td> <td>F0.0030</td> </tr> <tr> <td>15</td> <td>166554</td> <td>10.01.08.01.02</td> <td>7</td> <td>178944</td> <td>01.1010</td> </tr> <tr> <td>14</td> <td>4988</td> <td>10.01.08.01.01</td> <td>6</td> <td>5296</td> <td>F0.4000</td> </tr> <tr> <td>13</td> <td>4988</td> <td>10.01.08.01.02</td> <td>5</td> <td>5295</td> <td>F0.3100</td> </tr> <tr> <td>12</td> <td>4988</td> <td></td> <td>4</td> <td>2099</td> <td>01.2000</td> </tr> <tr> <td>11</td> <td>4988</td> <td></td> <td>3</td> <td>1054</td> <td>01.2000</td> </tr> <tr> <td>10</td> <td>1103</td> <td></td> <td>2</td> <td>809</td> <td>01.2500</td> </tr> <tr> <td>9</td> <td>1103</td> <td></td> <td>1</td> <td>30</td> <td>01.2500</td> </tr> <tr> <td>8</td> <td>1103</td> <td>12.03.08.01.01</td> <td colspan="3" rowspan="10" style="vertical-align: top;"> (5) Maintenance Log <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <th>#</th> <th>Count.</th> <th>Item</th> </tr> <tr> <td>8</td> <td>1045571</td> <td>01.00</td> </tr> <tr> <td>7</td> <td>104511</td> <td>01.00</td> </tr> <tr> <td>6</td> <td>7045</td> <td>01.00</td> </tr> <tr> <td>5</td> <td>3454</td> <td>01.00</td> </tr> <tr> <td>4</td> <td>3454</td> <td>02.00</td> </tr> <tr> <td>3</td> <td>3454</td> <td>02.00</td> </tr> <tr> <td>2</td> <td>417</td> <td>02.00</td> </tr> <tr> <td>1</td> <td>34</td> <td>02.20</td> </tr> </table> </td> </tr> <tr> <td>7</td> <td>1103</td> <td>12.03.08.01.01</td> </tr> <tr> <td>6</td> <td>1027</td> <td>12.03.08.01.01</td> </tr> <tr> <td>5</td> <td>1027</td> <td>12.03.0A.01.01</td> </tr> <tr> <td>4</td> <td>1027</td> <td>12.03.08.01.01</td> </tr> <tr> <td>3</td> <td>1027</td> <td>12.03.08.01.02</td> </tr> <tr> <td>2</td> <td>406</td> <td>12.03.0A.01.01</td> </tr> <tr> <td>1</td> <td>36</td> <td>12.03.08.01.01</td> </tr> </table> <div style="margin-top: 10px;"> <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; vertical-align: top;"> (6) Unknown toner Log <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <th>#</th> <th>Count.</th> <th>Item</th> </tr> <tr> <td>5</td> <td>3454</td> <td>01.00</td> </tr> <tr> <td>4</td> <td>3454</td> <td>01.00</td> </tr> <tr> <td>3</td> <td>3454</td> <td>01.00</td> </tr> <tr> <td>2</td> <td>406</td> <td>01.00</td> </tr> <tr> <td>1</td> <td>32</td> <td>01.00</td> </tr> </table> </td> <td style="width: 50%; vertical-align: top;"> (7) Counter Log <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">(f) J04:000</td> <td style="width: 12.5%;">J20:000</td> <td style="width: 12.5%;">J70:000</td> <td style="width: 12.5%;">J93:002</td> <td style="width: 25%;">(g) C0100:001</td> <td style="width: 12.5%;">C4000:001</td> <td style="width: 12.5%;">C8020:001</td> <td style="width: 12.5%;">(h) M00:01</td> </tr> <tr> <td>J05:000</td> <td>J21:000</td> <td>J71:000</td> <td>J94:000</td> <td>C1010:001</td> <td>C4010:001</td> <td>C8030:001</td> <td>M00:01</td> </tr> <tr> <td>J09:000</td> <td>J22:000</td> <td>J72:000</td> <td>J95:000</td> <td>C1020:001</td> <td>C4100:001</td> <td>C8040:001</td> <td></td> </tr> <tr> <td>J10:000</td> <td>J23:000</td> <td>J73:000</td> <td>J96:000</td> <td>C1030:001</td> <td>C6000:001</td> <td>C8050:001</td> <td></td> </tr> <tr> <td>J11:002</td> <td>J30:002</td> <td>J74:002</td> <td></td> <td>C1040:001</td> <td>C6020:001</td> <td>C8060:001</td> <td></td> </tr> <tr> <td>J12:000</td> <td>J40:002</td> <td>J75:002</td> <td></td> <td>C2000:001</td> <td>C6030:001</td> <td>C8070:001</td> <td></td> </tr> <tr> <td>J13:000</td> <td>J41:000</td> <td>J76:000</td> <td></td> <td>C2250:001</td> <td>C6040:001</td> <td>C8140:001</td> <td></td> </tr> <tr> <td>J14:000</td> <td>J42:000</td> <td>J78:000</td> <td></td> <td>C2500:001</td> <td>C6050:001</td> <td>C8170:001</td> <td></td> </tr> <tr> <td>J15:000</td> <td>J43:000</td> <td>J80:000</td> <td></td> <td>C2600:001</td> <td>C6100:001</td> <td>C8180:001</td> <td></td> </tr> <tr> <td></td> <td>J44:000</td> <td>J81:000</td> <td></td> <td>C3100:001</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>J82:000</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </table> </td> </tr> </table> <div style="margin-top: 10px; text-align: center;"> <table border="1" style="margin: auto; border-collapse: collapse;"> <tr> <td style="padding: 5px;">10.01.08.01.01</td> </tr> <tr> <td style="padding: 5px;">(a) (b) (c) (d) (e)</td> </tr> </table> </div> </div> </div>	#	Count.	Event Descriptions	#	Count.	Service Code	16	1876543	10.01.08.01.01	8	1881214	F0.0030	15	166554	10.01.08.01.02	7	178944	01.1010	14	4988	10.01.08.01.01	6	5296	F0.4000	13	4988	10.01.08.01.02	5	5295	F0.3100	12	4988		4	2099	01.2000	11	4988		3	1054	01.2000	10	1103		2	809	01.2500	9	1103		1	30	01.2500	8	1103	12.03.08.01.01	(5) Maintenance Log <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <th>#</th> <th>Count.</th> <th>Item</th> </tr> <tr> <td>8</td> <td>1045571</td> <td>01.00</td> </tr> <tr> <td>7</td> <td>104511</td> <td>01.00</td> </tr> <tr> <td>6</td> <td>7045</td> <td>01.00</td> </tr> <tr> <td>5</td> <td>3454</td> <td>01.00</td> </tr> <tr> <td>4</td> <td>3454</td> <td>02.00</td> </tr> <tr> <td>3</td> <td>3454</td> <td>02.00</td> </tr> <tr> <td>2</td> <td>417</td> <td>02.00</td> </tr> <tr> <td>1</td> <td>34</td> <td>02.20</td> </tr> </table>			#	Count.	Item	8	1045571	01.00	7	104511	01.00	6	7045	01.00	5	3454	01.00	4	3454	02.00	3	3454	02.00	2	417	02.00	1	34	02.20	7	1103	12.03.08.01.01	6	1027	12.03.08.01.01	5	1027	12.03.0A.01.01	4	1027	12.03.08.01.01	3	1027	12.03.08.01.02	2	406	12.03.0A.01.01	1	36	12.03.08.01.01	(6) Unknown toner Log <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <th>#</th> <th>Count.</th> <th>Item</th> </tr> <tr> <td>5</td> <td>3454</td> <td>01.00</td> </tr> <tr> <td>4</td> <td>3454</td> <td>01.00</td> </tr> <tr> <td>3</td> <td>3454</td> <td>01.00</td> </tr> <tr> <td>2</td> <td>406</td> <td>01.00</td> </tr> <tr> <td>1</td> <td>32</td> <td>01.00</td> </tr> </table>	#	Count.	Item	5	3454	01.00	4	3454	01.00	3	3454	01.00	2	406	01.00	1	32	01.00	(7) Counter Log <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">(f) J04:000</td> <td style="width: 12.5%;">J20:000</td> <td style="width: 12.5%;">J70:000</td> <td style="width: 12.5%;">J93:002</td> <td style="width: 25%;">(g) C0100:001</td> <td style="width: 12.5%;">C4000:001</td> <td style="width: 12.5%;">C8020:001</td> <td style="width: 12.5%;">(h) M00:01</td> </tr> <tr> <td>J05:000</td> <td>J21:000</td> <td>J71:000</td> <td>J94:000</td> <td>C1010:001</td> <td>C4010:001</td> <td>C8030:001</td> <td>M00:01</td> </tr> <tr> <td>J09:000</td> <td>J22:000</td> <td>J72:000</td> <td>J95:000</td> <td>C1020:001</td> <td>C4100:001</td> <td>C8040:001</td> <td></td> </tr> <tr> <td>J10:000</td> <td>J23:000</td> <td>J73:000</td> <td>J96:000</td> <td>C1030:001</td> <td>C6000:001</td> <td>C8050:001</td> <td></td> </tr> <tr> <td>J11:002</td> <td>J30:002</td> <td>J74:002</td> <td></td> <td>C1040:001</td> <td>C6020:001</td> <td>C8060:001</td> <td></td> </tr> <tr> <td>J12:000</td> <td>J40:002</td> <td>J75:002</td> <td></td> <td>C2000:001</td> <td>C6030:001</td> <td>C8070:001</td> <td></td> </tr> <tr> <td>J13:000</td> <td>J41:000</td> <td>J76:000</td> <td></td> <td>C2250:001</td> <td>C6040:001</td> <td>C8140:001</td> <td></td> </tr> <tr> <td>J14:000</td> <td>J42:000</td> <td>J78:000</td> <td></td> <td>C2500:001</td> <td>C6050:001</td> <td>C8170:001</td> <td></td> </tr> <tr> <td>J15:000</td> <td>J43:000</td> <td>J80:000</td> <td></td> <td>C2600:001</td> <td>C6100:001</td> <td>C8180:001</td> <td></td> </tr> <tr> <td></td> <td>J44:000</td> <td>J81:000</td> <td></td> <td>C3100:001</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>J82:000</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </table>	(f) J04:000	J20:000	J70:000	J93:002	(g) C0100:001	C4000:001	C8020:001	(h) M00:01	J05:000	J21:000	J71:000	J94:000	C1010:001	C4010:001	C8030:001	M00:01	J09:000	J22:000	J72:000	J95:000	C1020:001	C4100:001	C8040:001		J10:000	J23:000	J73:000	J96:000	C1030:001	C6000:001	C8050:001		J11:002	J30:002	J74:002		C1040:001	C6020:001	C8060:001		J12:000	J40:002	J75:002		C2000:001	C6030:001	C8070:001		J13:000	J41:000	J76:000		C2250:001	C6040:001	C8140:001		J14:000	J42:000	J78:000		C2500:001	C6050:001	C8170:001		J15:000	J43:000	J80:000		C2600:001	C6100:001	C8180:001			J44:000	J81:000		C3100:001					J82:000							10.01.08.01.01	(a) (b) (c) (d) (e)
#	Count.	Event Descriptions	#	Count.	Service Code																																																																																																																																																																																																																						
16	1876543	10.01.08.01.01	8	1881214	F0.0030																																																																																																																																																																																																																						
15	166554	10.01.08.01.02	7	178944	01.1010																																																																																																																																																																																																																						
14	4988	10.01.08.01.01	6	5296	F0.4000																																																																																																																																																																																																																						
13	4988	10.01.08.01.02	5	5295	F0.3100																																																																																																																																																																																																																						
12	4988		4	2099	01.2000																																																																																																																																																																																																																						
11	4988		3	1054	01.2000																																																																																																																																																																																																																						
10	1103		2	809	01.2500																																																																																																																																																																																																																						
9	1103		1	30	01.2500																																																																																																																																																																																																																						
8	1103	12.03.08.01.01	(5) Maintenance Log <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <th>#</th> <th>Count.</th> <th>Item</th> </tr> <tr> <td>8</td> <td>1045571</td> <td>01.00</td> </tr> <tr> <td>7</td> <td>104511</td> <td>01.00</td> </tr> <tr> <td>6</td> <td>7045</td> <td>01.00</td> </tr> <tr> <td>5</td> <td>3454</td> <td>01.00</td> </tr> <tr> <td>4</td> <td>3454</td> <td>02.00</td> </tr> <tr> <td>3</td> <td>3454</td> <td>02.00</td> </tr> <tr> <td>2</td> <td>417</td> <td>02.00</td> </tr> <tr> <td>1</td> <td>34</td> <td>02.20</td> </tr> </table>			#	Count.	Item	8	1045571	01.00	7	104511	01.00	6	7045	01.00	5	3454	01.00	4	3454	02.00	3	3454	02.00	2	417	02.00	1	34	02.20																																																																																																																																																																																											
#	Count.	Item																																																																																																																																																																																																																									
8	1045571	01.00																																																																																																																																																																																																																									
7	104511	01.00																																																																																																																																																																																																																									
6	7045	01.00																																																																																																																																																																																																																									
5	3454	01.00																																																																																																																																																																																																																									
4	3454	02.00																																																																																																																																																																																																																									
3	3454	02.00																																																																																																																																																																																																																									
2	417	02.00																																																																																																																																																																																																																									
1	34	02.20																																																																																																																																																																																																																									
7	1103	12.03.08.01.01																																																																																																																																																																																																																									
6	1027	12.03.08.01.01																																																																																																																																																																																																																									
5	1027	12.03.0A.01.01																																																																																																																																																																																																																									
4	1027	12.03.08.01.01																																																																																																																																																																																																																									
3	1027	12.03.08.01.02																																																																																																																																																																																																																									
2	406	12.03.0A.01.01																																																																																																																																																																																																																									
1	36	12.03.08.01.01																																																																																																																																																																																																																									
(6) Unknown toner Log <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <th>#</th> <th>Count.</th> <th>Item</th> </tr> <tr> <td>5</td> <td>3454</td> <td>01.00</td> </tr> <tr> <td>4</td> <td>3454</td> <td>01.00</td> </tr> <tr> <td>3</td> <td>3454</td> <td>01.00</td> </tr> <tr> <td>2</td> <td>406</td> <td>01.00</td> </tr> <tr> <td>1</td> <td>32</td> <td>01.00</td> </tr> </table>	#	Count.	Item	5	3454	01.00	4	3454	01.00	3	3454	01.00	2	406	01.00	1	32	01.00	(7) Counter Log <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">(f) J04:000</td> <td style="width: 12.5%;">J20:000</td> <td style="width: 12.5%;">J70:000</td> <td style="width: 12.5%;">J93:002</td> <td style="width: 25%;">(g) C0100:001</td> <td style="width: 12.5%;">C4000:001</td> <td style="width: 12.5%;">C8020:001</td> <td style="width: 12.5%;">(h) M00:01</td> </tr> <tr> <td>J05:000</td> <td>J21:000</td> <td>J71:000</td> <td>J94:000</td> <td>C1010:001</td> <td>C4010:001</td> <td>C8030:001</td> <td>M00:01</td> </tr> <tr> <td>J09:000</td> <td>J22:000</td> <td>J72:000</td> <td>J95:000</td> <td>C1020:001</td> <td>C4100:001</td> <td>C8040:001</td> <td></td> </tr> <tr> <td>J10:000</td> <td>J23:000</td> <td>J73:000</td> <td>J96:000</td> <td>C1030:001</td> <td>C6000:001</td> <td>C8050:001</td> <td></td> </tr> <tr> <td>J11:002</td> <td>J30:002</td> <td>J74:002</td> <td></td> <td>C1040:001</td> <td>C6020:001</td> <td>C8060:001</td> <td></td> </tr> <tr> <td>J12:000</td> <td>J40:002</td> <td>J75:002</td> <td></td> <td>C2000:001</td> <td>C6030:001</td> <td>C8070:001</td> <td></td> </tr> <tr> <td>J13:000</td> <td>J41:000</td> <td>J76:000</td> <td></td> <td>C2250:001</td> <td>C6040:001</td> <td>C8140:001</td> <td></td> </tr> <tr> <td>J14:000</td> <td>J42:000</td> <td>J78:000</td> <td></td> <td>C2500:001</td> <td>C6050:001</td> <td>C8170:001</td> <td></td> </tr> <tr> <td>J15:000</td> <td>J43:000</td> <td>J80:000</td> <td></td> <td>C2600:001</td> <td>C6100:001</td> <td>C8180:001</td> <td></td> </tr> <tr> <td></td> <td>J44:000</td> <td>J81:000</td> <td></td> <td>C3100:001</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td>J82:000</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </table>	(f) J04:000	J20:000	J70:000	J93:002	(g) C0100:001	C4000:001	C8020:001	(h) M00:01	J05:000	J21:000	J71:000	J94:000	C1010:001	C4010:001	C8030:001	M00:01	J09:000	J22:000	J72:000	J95:000	C1020:001	C4100:001	C8040:001		J10:000	J23:000	J73:000	J96:000	C1030:001	C6000:001	C8050:001		J11:002	J30:002	J74:002		C1040:001	C6020:001	C8060:001		J12:000	J40:002	J75:002		C2000:001	C6030:001	C8070:001		J13:000	J41:000	J76:000		C2250:001	C6040:001	C8140:001		J14:000	J42:000	J78:000		C2500:001	C6050:001	C8170:001		J15:000	J43:000	J80:000		C2600:001	C6100:001	C8180:001			J44:000	J81:000		C3100:001					J82:000																																																																																																																						
#	Count.	Item																																																																																																																																																																																																																									
5	3454	01.00																																																																																																																																																																																																																									
4	3454	01.00																																																																																																																																																																																																																									
3	3454	01.00																																																																																																																																																																																																																									
2	406	01.00																																																																																																																																																																																																																									
1	32	01.00																																																																																																																																																																																																																									
(f) J04:000	J20:000	J70:000	J93:002	(g) C0100:001	C4000:001	C8020:001	(h) M00:01																																																																																																																																																																																																																				
J05:000	J21:000	J71:000	J94:000	C1010:001	C4010:001	C8030:001	M00:01																																																																																																																																																																																																																				
J09:000	J22:000	J72:000	J95:000	C1020:001	C4100:001	C8040:001																																																																																																																																																																																																																					
J10:000	J23:000	J73:000	J96:000	C1030:001	C6000:001	C8050:001																																																																																																																																																																																																																					
J11:002	J30:002	J74:002		C1040:001	C6020:001	C8060:001																																																																																																																																																																																																																					
J12:000	J40:002	J75:002		C2000:001	C6030:001	C8070:001																																																																																																																																																																																																																					
J13:000	J41:000	J76:000		C2250:001	C6040:001	C8140:001																																																																																																																																																																																																																					
J14:000	J42:000	J78:000		C2500:001	C6050:001	C8170:001																																																																																																																																																																																																																					
J15:000	J43:000	J80:000		C2600:001	C6100:001	C8180:001																																																																																																																																																																																																																					
	J44:000	J81:000		C3100:001																																																																																																																																																																																																																							
	J82:000																																																																																																																																																																																																																										
10.01.08.01.01																																																																																																																																																																																																																											
(a) (b) (c) (d) (e)																																																																																																																																																																																																																											

Figure 1-3-1

Maintenance item No.	Description			
U000	Detail of event log			
	No.	Items Description		
(1)	System version			
(2)	System date			
(3)	Paper Jam Log	#	Count.	Event
		Remembers 1 to 16 of occurrence. If the occurrence of the previous paper jam is less than 16, all of the paper jams are logged. When the occurrence exceeds 16, the oldest occurrence is removed.	The total page count at the time of the paper jam.	Log code (2 digit, hexadecimal, 5 categories) (a) Cause of a paper jam (b) Paper source (c) Paper size (d) Paper type (e) Paper eject
		(a) Cause of paper jam (Hexadecimal)		
		04: Cover open 05: Secondary paper feed does not start 09: 3000-sheet paper feeder sequence error jam 10: No paper feed from cassette 1 11: No paper feed from cassette 2 12: No paper feed from optional cassette 3 13: No paper feed from optional cassette 4 14: No paper feed from MP tray 15: Jam in paper feeder horizontal paper conveying section 1 16: Jam in paper feeder horizontal paper conveying section 2 17: Jam in paper feeder horizontal paper conveying section 3 18: Misfeed in vertical paper conveying section 19: Misfeed in paper feeder vertical paper conveying section 20: Misfeed in MP tray vertical paper conveying section 21: Multiple sheets in paper feed section 22: Multiple sheets in vertical conveying section 23: Multiple sheets in MP tray conveying section 30: Misfeed in registration/transfer section 40: Misfeed in fuser section (MP tray) 41: Misfeed in fuser section (cassette 1) 42: Misfeed in fuser section (cassette 2) 43: Misfeed in fuser section (optional cassette 3) 44: Misfeed in fuser section (optional cassette 4) 46: Misfeed in fuser section (optional 3000-sheet paper feeder) 47: Misfeed in fuser section (duplex section) 50: Misfeed in eject section 51: Misfeed in job separator eject section 52: Misfeed in feedshift section 60: Duplex paper conveying section 1 61: Duplex paper conveying section 2 70: No original feed 71: An original jam in the original feed/conveying section 1 72: An original jam in the original feed/conveying section 2 73: An original jam in the original conveying section 74: An original jam in the original registration section 75: An original jam in the original registration section 76: An original jam in the original feed/conveying section 78: Document processor top cover open 80: Jam between the finisher and machine (3000-sheet document finisher) 81: Paper entry sensor nonarrival jam		

Maintenance item No.	Description																																																																																																																																						
U000	<table border="1" data-bbox="284 309 1418 1854"> <thead> <tr> <th data-bbox="284 309 359 342">No.</th> <th data-bbox="359 309 603 342">Items</th> <th colspan="3" data-bbox="603 309 1418 342">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="284 342 359 795">(3) cont.</td> <td data-bbox="359 342 603 795">Paper Jam Log</td> <td colspan="3" data-bbox="603 342 1418 795"> 82: Jam in stapler 83: Exit sensor stay jam 84: Jam in eject section of right sub tray (3000-sheet document finisher) 85: Jam in eject section of left sub tray (3000-sheet document finisher) 86: Jam in eject section of internal tray 1 (3000-sheet document finisher) 87: Jam in eject section of internal tray 2 (3000-sheet document finisher) 88: Jam in eject section of main tray (3000-sheet document finisher) 89: Jam in centerfold unit (3000-sheet document finisher) 90: Jam in mailbox (3000-sheet document finisher) 91: Finisher cover open 92: Exit sensor non-arrival jam (document finisher) 93: Reverse sensor jam (document finisher) 94: Paper entry sensor stay/remaining jam (document finisher) 95: Paper conveying sensor jam (document finisher) 96: Jam between the built-in finisher and machine (built-in finisher) </td> </tr> <tr> <td colspan="5" data-bbox="603 795 1418 835">(b) Detail of paper source (Hexadecimal)</td> </tr> <tr> <td colspan="5" data-bbox="603 835 1418 1055"> 00: MP tray 01: Cassette 1 02: Cassette 2 03: Cassette 3 (paper feeder) 04: Cassette 4 (paper feeder) 08: 3000-sheet paper feeder 05/06/07/09: Reserved </td> </tr> <tr> <td colspan="5" data-bbox="603 1055 1418 1095">(c) Detail of paper size (Hexadecimal)</td> </tr> <tr> <td colspan="5" data-bbox="603 1095 1418 1512"> <table border="1" data-bbox="603 1095 1418 1512"> <tbody> <tr> <td data-bbox="603 1095 874 1126">01: Monarch</td> <td data-bbox="874 1095 1150 1126">0C: Ledger</td> <td colspan="2" data-bbox="1150 1095 1418 1126">24: A3 wide</td> </tr> <tr> <td data-bbox="603 1126 874 1158">02: Business</td> <td data-bbox="874 1126 1150 1158">0D: A5</td> <td colspan="2" data-bbox="1150 1126 1418 1158">25: Ledger wide</td> </tr> <tr> <td data-bbox="603 1158 874 1189">03: International DL</td> <td data-bbox="874 1158 1150 1189">0E: A6</td> <td colspan="2" data-bbox="1150 1158 1418 1189">26: Full bleed paper</td> </tr> <tr> <td data-bbox="603 1189 874 1220">04: International C5</td> <td data-bbox="874 1189 1150 1220">0F: B6</td> <td colspan="2" data-bbox="1150 1189 1418 1220">(12 x 8)</td> </tr> <tr> <td data-bbox="603 1220 874 1252">05: Executive</td> <td data-bbox="874 1220 1150 1252">10: Commercial #9</td> <td colspan="2" data-bbox="1150 1220 1418 1252">27: 8K</td> </tr> <tr> <td data-bbox="603 1252 874 1283">06: Letter-R</td> <td data-bbox="874 1252 1150 1283">11: Commercial #6</td> <td colspan="2" data-bbox="1150 1252 1418 1283">28: 16K-R</td> </tr> <tr> <td data-bbox="603 1283 874 1314">86: Letter-E</td> <td data-bbox="874 1283 1150 1314">12: ISO B5</td> <td colspan="2" data-bbox="1150 1283 1418 1314">A8: 16K-E</td> </tr> <tr> <td data-bbox="603 1314 874 1346">07: Legal</td> <td data-bbox="874 1314 1150 1346">13: Custom size</td> <td colspan="2" data-bbox="1150 1314 1418 1346">32: Statement-R</td> </tr> <tr> <td data-bbox="603 1346 874 1377">08: A4R</td> <td data-bbox="874 1346 1150 1377">1E: C4</td> <td colspan="2" data-bbox="1150 1346 1418 1377">B2: Statement-E</td> </tr> <tr> <td data-bbox="603 1377 874 1408">88: A4E</td> <td data-bbox="874 1377 1150 1408">1F: Postcard</td> <td colspan="2" data-bbox="1150 1377 1418 1408">33: Folio</td> </tr> <tr> <td data-bbox="603 1408 874 1440">09: B5R</td> <td data-bbox="874 1408 1150 1440">20: Reply-paid postcard</td> <td colspan="2" data-bbox="1150 1408 1418 1440">34: Western type 2</td> </tr> <tr> <td data-bbox="603 1440 874 1471">89: B5E</td> <td data-bbox="874 1440 1150 1471">21: Oficio II</td> <td colspan="2" data-bbox="1150 1440 1418 1471">35: Western type 4</td> </tr> <tr> <td data-bbox="603 1471 874 1503">0A: A3</td> <td data-bbox="874 1471 1150 1503">22: Special 1</td> <td colspan="2"></td> </tr> <tr> <td data-bbox="603 1503 874 1534">0B: B4</td> <td data-bbox="874 1503 1150 1534">23: Special 2</td> <td colspan="2"></td> </tr> </tbody> </table> </td> </tr> <tr> <td colspan="5" data-bbox="603 1512 1418 1552">(d) Detail of paper type (Hexadecimal)</td> </tr> <tr> <td colspan="5" data-bbox="603 1552 1418 1854"> <table border="1" data-bbox="603 1552 1418 1854"> <tbody> <tr> <td data-bbox="603 1552 874 1583">01: Plain</td> <td data-bbox="874 1552 1150 1583">0A: Color</td> <td colspan="2" data-bbox="1150 1552 1418 1583">15: Custom 1</td> </tr> <tr> <td data-bbox="603 1583 874 1615">02: Transparency</td> <td data-bbox="874 1583 1150 1615">0B: Prepunched</td> <td colspan="2" data-bbox="1150 1583 1418 1615">16: Custom 2</td> </tr> <tr> <td data-bbox="603 1615 874 1646">03: Preprinted</td> <td data-bbox="874 1615 1150 1646">0C: Envelope</td> <td colspan="2" data-bbox="1150 1615 1418 1646">17: Custom 3</td> </tr> <tr> <td data-bbox="603 1646 874 1677">04: Labels</td> <td data-bbox="874 1646 1150 1677">0D: Cardstock</td> <td colspan="2" data-bbox="1150 1646 1418 1677">18: Custom 4</td> </tr> <tr> <td data-bbox="603 1677 874 1709">05: Bond</td> <td data-bbox="874 1677 1150 1709">0E: Coated</td> <td colspan="2" data-bbox="1150 1677 1418 1709">19: Custom 5</td> </tr> <tr> <td data-bbox="603 1709 874 1740">06: Recycled</td> <td data-bbox="874 1709 1150 1740">0F: 2nd side</td> <td colspan="2" data-bbox="1150 1709 1418 1740">1A: Custom 6</td> </tr> <tr> <td data-bbox="603 1740 874 1771">07: Vellum</td> <td data-bbox="874 1740 1150 1771">10: Media 16</td> <td colspan="2" data-bbox="1150 1740 1418 1771">1B: Custom 7</td> </tr> <tr> <td data-bbox="603 1771 874 1803">08: Rough</td> <td data-bbox="874 1771 1150 1803">11: High quality</td> <td colspan="2" data-bbox="1150 1771 1418 1803">1C: Custom 8</td> </tr> <tr> <td data-bbox="603 1803 874 1834">09: Letterhead</td> <td></td> <td colspan="2"></td> </tr> </tbody> </table> </td> </tr> </tbody> </table>			No.	Items	Description			(3) cont.	Paper Jam Log	82: Jam in stapler 83: Exit sensor stay jam 84: Jam in eject section of right sub tray (3000-sheet document finisher) 85: Jam in eject section of left sub tray (3000-sheet document finisher) 86: Jam in eject section of internal tray 1 (3000-sheet document finisher) 87: Jam in eject section of internal tray 2 (3000-sheet document finisher) 88: Jam in eject section of main tray (3000-sheet document finisher) 89: Jam in centerfold unit (3000-sheet document finisher) 90: Jam in mailbox (3000-sheet document finisher) 91: Finisher cover open 92: Exit sensor non-arrival jam (document finisher) 93: Reverse sensor jam (document finisher) 94: Paper entry sensor stay/remaining jam (document finisher) 95: Paper conveying sensor jam (document finisher) 96: Jam between the built-in finisher and machine (built-in finisher)			(b) Detail of paper source (Hexadecimal)					00: MP tray 01: Cassette 1 02: Cassette 2 03: Cassette 3 (paper feeder) 04: Cassette 4 (paper feeder) 08: 3000-sheet paper feeder 05/06/07/09: Reserved					(c) Detail of paper size (Hexadecimal)					<table border="1" data-bbox="603 1095 1418 1512"> <tbody> <tr> <td data-bbox="603 1095 874 1126">01: Monarch</td> <td data-bbox="874 1095 1150 1126">0C: Ledger</td> <td colspan="2" data-bbox="1150 1095 1418 1126">24: A3 wide</td> </tr> <tr> <td data-bbox="603 1126 874 1158">02: Business</td> <td data-bbox="874 1126 1150 1158">0D: A5</td> <td colspan="2" data-bbox="1150 1126 1418 1158">25: Ledger wide</td> </tr> <tr> <td data-bbox="603 1158 874 1189">03: International DL</td> <td data-bbox="874 1158 1150 1189">0E: A6</td> <td colspan="2" data-bbox="1150 1158 1418 1189">26: Full bleed paper</td> </tr> <tr> <td data-bbox="603 1189 874 1220">04: International C5</td> <td data-bbox="874 1189 1150 1220">0F: B6</td> <td colspan="2" data-bbox="1150 1189 1418 1220">(12 x 8)</td> </tr> <tr> <td data-bbox="603 1220 874 1252">05: Executive</td> <td data-bbox="874 1220 1150 1252">10: Commercial #9</td> <td colspan="2" data-bbox="1150 1220 1418 1252">27: 8K</td> </tr> <tr> <td data-bbox="603 1252 874 1283">06: Letter-R</td> <td data-bbox="874 1252 1150 1283">11: Commercial #6</td> <td colspan="2" data-bbox="1150 1252 1418 1283">28: 16K-R</td> </tr> <tr> <td data-bbox="603 1283 874 1314">86: Letter-E</td> <td data-bbox="874 1283 1150 1314">12: ISO B5</td> <td colspan="2" data-bbox="1150 1283 1418 1314">A8: 16K-E</td> </tr> <tr> <td data-bbox="603 1314 874 1346">07: Legal</td> <td data-bbox="874 1314 1150 1346">13: Custom size</td> <td colspan="2" data-bbox="1150 1314 1418 1346">32: Statement-R</td> </tr> <tr> <td data-bbox="603 1346 874 1377">08: A4R</td> <td data-bbox="874 1346 1150 1377">1E: C4</td> <td colspan="2" data-bbox="1150 1346 1418 1377">B2: Statement-E</td> </tr> <tr> <td data-bbox="603 1377 874 1408">88: A4E</td> <td data-bbox="874 1377 1150 1408">1F: Postcard</td> <td colspan="2" data-bbox="1150 1377 1418 1408">33: Folio</td> </tr> <tr> <td data-bbox="603 1408 874 1440">09: B5R</td> <td data-bbox="874 1408 1150 1440">20: Reply-paid postcard</td> <td colspan="2" data-bbox="1150 1408 1418 1440">34: Western type 2</td> </tr> <tr> <td data-bbox="603 1440 874 1471">89: B5E</td> <td data-bbox="874 1440 1150 1471">21: Oficio II</td> <td colspan="2" data-bbox="1150 1440 1418 1471">35: Western type 4</td> </tr> <tr> <td data-bbox="603 1471 874 1503">0A: A3</td> <td data-bbox="874 1471 1150 1503">22: Special 1</td> <td colspan="2"></td> </tr> <tr> <td data-bbox="603 1503 874 1534">0B: B4</td> <td data-bbox="874 1503 1150 1534">23: Special 2</td> <td colspan="2"></td> </tr> </tbody> </table>					01: Monarch	0C: Ledger	24: A3 wide		02: Business	0D: A5	25: Ledger wide		03: International DL	0E: A6	26: Full bleed paper		04: International C5	0F: B6	(12 x 8)		05: Executive	10: Commercial #9	27: 8K		06: Letter-R	11: Commercial #6	28: 16K-R		86: Letter-E	12: ISO B5	A8: 16K-E		07: Legal	13: Custom size	32: Statement-R		08: A4R	1E: C4	B2: Statement-E		88: A4E	1F: Postcard	33: Folio		09: B5R	20: Reply-paid postcard	34: Western type 2		89: B5E	21: Oficio II	35: Western type 4		0A: A3	22: Special 1			0B: B4	23: Special 2			(d) Detail of paper type (Hexadecimal)					<table border="1" data-bbox="603 1552 1418 1854"> <tbody> <tr> <td data-bbox="603 1552 874 1583">01: Plain</td> <td data-bbox="874 1552 1150 1583">0A: Color</td> <td colspan="2" data-bbox="1150 1552 1418 1583">15: Custom 1</td> </tr> <tr> <td data-bbox="603 1583 874 1615">02: Transparency</td> <td data-bbox="874 1583 1150 1615">0B: Prepunched</td> <td colspan="2" data-bbox="1150 1583 1418 1615">16: Custom 2</td> </tr> <tr> <td data-bbox="603 1615 874 1646">03: Preprinted</td> <td data-bbox="874 1615 1150 1646">0C: Envelope</td> <td colspan="2" data-bbox="1150 1615 1418 1646">17: Custom 3</td> </tr> <tr> <td data-bbox="603 1646 874 1677">04: Labels</td> <td data-bbox="874 1646 1150 1677">0D: Cardstock</td> <td colspan="2" data-bbox="1150 1646 1418 1677">18: Custom 4</td> </tr> <tr> <td data-bbox="603 1677 874 1709">05: Bond</td> <td data-bbox="874 1677 1150 1709">0E: Coated</td> <td colspan="2" data-bbox="1150 1677 1418 1709">19: Custom 5</td> </tr> <tr> <td data-bbox="603 1709 874 1740">06: Recycled</td> <td data-bbox="874 1709 1150 1740">0F: 2nd side</td> <td colspan="2" data-bbox="1150 1709 1418 1740">1A: Custom 6</td> </tr> <tr> <td data-bbox="603 1740 874 1771">07: Vellum</td> <td data-bbox="874 1740 1150 1771">10: Media 16</td> <td colspan="2" data-bbox="1150 1740 1418 1771">1B: Custom 7</td> </tr> <tr> <td data-bbox="603 1771 874 1803">08: Rough</td> <td data-bbox="874 1771 1150 1803">11: High quality</td> <td colspan="2" data-bbox="1150 1771 1418 1803">1C: Custom 8</td> </tr> <tr> <td data-bbox="603 1803 874 1834">09: Letterhead</td> <td></td> <td colspan="2"></td> </tr> </tbody> </table>					01: Plain	0A: Color	15: Custom 1		02: Transparency	0B: Prepunched	16: Custom 2		03: Preprinted	0C: Envelope	17: Custom 3		04: Labels	0D: Cardstock	18: Custom 4		05: Bond	0E: Coated	19: Custom 5		06: Recycled	0F: 2nd side	1A: Custom 6		07: Vellum	10: Media 16	1B: Custom 7		08: Rough	11: High quality	1C: Custom 8		09: Letterhead			
No.	Items	Description																																																																																																																																					
(3) cont.	Paper Jam Log	82: Jam in stapler 83: Exit sensor stay jam 84: Jam in eject section of right sub tray (3000-sheet document finisher) 85: Jam in eject section of left sub tray (3000-sheet document finisher) 86: Jam in eject section of internal tray 1 (3000-sheet document finisher) 87: Jam in eject section of internal tray 2 (3000-sheet document finisher) 88: Jam in eject section of main tray (3000-sheet document finisher) 89: Jam in centerfold unit (3000-sheet document finisher) 90: Jam in mailbox (3000-sheet document finisher) 91: Finisher cover open 92: Exit sensor non-arrival jam (document finisher) 93: Reverse sensor jam (document finisher) 94: Paper entry sensor stay/remaining jam (document finisher) 95: Paper conveying sensor jam (document finisher) 96: Jam between the built-in finisher and machine (built-in finisher)																																																																																																																																					
(b) Detail of paper source (Hexadecimal)																																																																																																																																							
00: MP tray 01: Cassette 1 02: Cassette 2 03: Cassette 3 (paper feeder) 04: Cassette 4 (paper feeder) 08: 3000-sheet paper feeder 05/06/07/09: Reserved																																																																																																																																							
(c) Detail of paper size (Hexadecimal)																																																																																																																																							
<table border="1" data-bbox="603 1095 1418 1512"> <tbody> <tr> <td data-bbox="603 1095 874 1126">01: Monarch</td> <td data-bbox="874 1095 1150 1126">0C: Ledger</td> <td colspan="2" data-bbox="1150 1095 1418 1126">24: A3 wide</td> </tr> <tr> <td data-bbox="603 1126 874 1158">02: Business</td> <td data-bbox="874 1126 1150 1158">0D: A5</td> <td colspan="2" data-bbox="1150 1126 1418 1158">25: Ledger wide</td> </tr> <tr> <td data-bbox="603 1158 874 1189">03: International DL</td> <td data-bbox="874 1158 1150 1189">0E: A6</td> <td colspan="2" data-bbox="1150 1158 1418 1189">26: Full bleed paper</td> </tr> <tr> <td data-bbox="603 1189 874 1220">04: International C5</td> <td data-bbox="874 1189 1150 1220">0F: B6</td> <td colspan="2" data-bbox="1150 1189 1418 1220">(12 x 8)</td> </tr> <tr> <td data-bbox="603 1220 874 1252">05: Executive</td> <td data-bbox="874 1220 1150 1252">10: Commercial #9</td> <td colspan="2" data-bbox="1150 1220 1418 1252">27: 8K</td> </tr> <tr> <td data-bbox="603 1252 874 1283">06: Letter-R</td> <td data-bbox="874 1252 1150 1283">11: Commercial #6</td> <td colspan="2" data-bbox="1150 1252 1418 1283">28: 16K-R</td> </tr> <tr> <td data-bbox="603 1283 874 1314">86: Letter-E</td> <td data-bbox="874 1283 1150 1314">12: ISO B5</td> <td colspan="2" data-bbox="1150 1283 1418 1314">A8: 16K-E</td> </tr> <tr> <td data-bbox="603 1314 874 1346">07: Legal</td> <td data-bbox="874 1314 1150 1346">13: Custom size</td> <td colspan="2" data-bbox="1150 1314 1418 1346">32: Statement-R</td> </tr> <tr> <td data-bbox="603 1346 874 1377">08: A4R</td> <td data-bbox="874 1346 1150 1377">1E: C4</td> <td colspan="2" data-bbox="1150 1346 1418 1377">B2: Statement-E</td> </tr> <tr> <td data-bbox="603 1377 874 1408">88: A4E</td> <td data-bbox="874 1377 1150 1408">1F: Postcard</td> <td colspan="2" data-bbox="1150 1377 1418 1408">33: Folio</td> </tr> <tr> <td data-bbox="603 1408 874 1440">09: B5R</td> <td data-bbox="874 1408 1150 1440">20: Reply-paid postcard</td> <td colspan="2" data-bbox="1150 1408 1418 1440">34: Western type 2</td> </tr> <tr> <td data-bbox="603 1440 874 1471">89: B5E</td> <td data-bbox="874 1440 1150 1471">21: Oficio II</td> <td colspan="2" data-bbox="1150 1440 1418 1471">35: Western type 4</td> </tr> <tr> <td data-bbox="603 1471 874 1503">0A: A3</td> <td data-bbox="874 1471 1150 1503">22: Special 1</td> <td colspan="2"></td> </tr> <tr> <td data-bbox="603 1503 874 1534">0B: B4</td> <td data-bbox="874 1503 1150 1534">23: Special 2</td> <td colspan="2"></td> </tr> </tbody> </table>					01: Monarch	0C: Ledger	24: A3 wide		02: Business	0D: A5	25: Ledger wide		03: International DL	0E: A6	26: Full bleed paper		04: International C5	0F: B6	(12 x 8)		05: Executive	10: Commercial #9	27: 8K		06: Letter-R	11: Commercial #6	28: 16K-R		86: Letter-E	12: ISO B5	A8: 16K-E		07: Legal	13: Custom size	32: Statement-R		08: A4R	1E: C4	B2: Statement-E		88: A4E	1F: Postcard	33: Folio		09: B5R	20: Reply-paid postcard	34: Western type 2		89: B5E	21: Oficio II	35: Western type 4		0A: A3	22: Special 1			0B: B4	23: Special 2																																																																													
01: Monarch	0C: Ledger	24: A3 wide																																																																																																																																					
02: Business	0D: A5	25: Ledger wide																																																																																																																																					
03: International DL	0E: A6	26: Full bleed paper																																																																																																																																					
04: International C5	0F: B6	(12 x 8)																																																																																																																																					
05: Executive	10: Commercial #9	27: 8K																																																																																																																																					
06: Letter-R	11: Commercial #6	28: 16K-R																																																																																																																																					
86: Letter-E	12: ISO B5	A8: 16K-E																																																																																																																																					
07: Legal	13: Custom size	32: Statement-R																																																																																																																																					
08: A4R	1E: C4	B2: Statement-E																																																																																																																																					
88: A4E	1F: Postcard	33: Folio																																																																																																																																					
09: B5R	20: Reply-paid postcard	34: Western type 2																																																																																																																																					
89: B5E	21: Oficio II	35: Western type 4																																																																																																																																					
0A: A3	22: Special 1																																																																																																																																						
0B: B4	23: Special 2																																																																																																																																						
(d) Detail of paper type (Hexadecimal)																																																																																																																																							
<table border="1" data-bbox="603 1552 1418 1854"> <tbody> <tr> <td data-bbox="603 1552 874 1583">01: Plain</td> <td data-bbox="874 1552 1150 1583">0A: Color</td> <td colspan="2" data-bbox="1150 1552 1418 1583">15: Custom 1</td> </tr> <tr> <td data-bbox="603 1583 874 1615">02: Transparency</td> <td data-bbox="874 1583 1150 1615">0B: Prepunched</td> <td colspan="2" data-bbox="1150 1583 1418 1615">16: Custom 2</td> </tr> <tr> <td data-bbox="603 1615 874 1646">03: Preprinted</td> <td data-bbox="874 1615 1150 1646">0C: Envelope</td> <td colspan="2" data-bbox="1150 1615 1418 1646">17: Custom 3</td> </tr> <tr> <td data-bbox="603 1646 874 1677">04: Labels</td> <td data-bbox="874 1646 1150 1677">0D: Cardstock</td> <td colspan="2" data-bbox="1150 1646 1418 1677">18: Custom 4</td> </tr> <tr> <td data-bbox="603 1677 874 1709">05: Bond</td> <td data-bbox="874 1677 1150 1709">0E: Coated</td> <td colspan="2" data-bbox="1150 1677 1418 1709">19: Custom 5</td> </tr> <tr> <td data-bbox="603 1709 874 1740">06: Recycled</td> <td data-bbox="874 1709 1150 1740">0F: 2nd side</td> <td colspan="2" data-bbox="1150 1709 1418 1740">1A: Custom 6</td> </tr> <tr> <td data-bbox="603 1740 874 1771">07: Vellum</td> <td data-bbox="874 1740 1150 1771">10: Media 16</td> <td colspan="2" data-bbox="1150 1740 1418 1771">1B: Custom 7</td> </tr> <tr> <td data-bbox="603 1771 874 1803">08: Rough</td> <td data-bbox="874 1771 1150 1803">11: High quality</td> <td colspan="2" data-bbox="1150 1771 1418 1803">1C: Custom 8</td> </tr> <tr> <td data-bbox="603 1803 874 1834">09: Letterhead</td> <td></td> <td colspan="2"></td> </tr> </tbody> </table>					01: Plain	0A: Color	15: Custom 1		02: Transparency	0B: Prepunched	16: Custom 2		03: Preprinted	0C: Envelope	17: Custom 3		04: Labels	0D: Cardstock	18: Custom 4		05: Bond	0E: Coated	19: Custom 5		06: Recycled	0F: 2nd side	1A: Custom 6		07: Vellum	10: Media 16	1B: Custom 7		08: Rough	11: High quality	1C: Custom 8		09: Letterhead																																																																																																		
01: Plain	0A: Color	15: Custom 1																																																																																																																																					
02: Transparency	0B: Prepunched	16: Custom 2																																																																																																																																					
03: Preprinted	0C: Envelope	17: Custom 3																																																																																																																																					
04: Labels	0D: Cardstock	18: Custom 4																																																																																																																																					
05: Bond	0E: Coated	19: Custom 5																																																																																																																																					
06: Recycled	0F: 2nd side	1A: Custom 6																																																																																																																																					
07: Vellum	10: Media 16	1B: Custom 7																																																																																																																																					
08: Rough	11: High quality	1C: Custom 8																																																																																																																																					
09: Letterhead																																																																																																																																							

Maintenance item No.	Description				
U000	(3) cont.	Paper Jam Log	(e) Detail of paper exit location (Hexadecimal)		
			01: Face down (FD) 02: Face up (FU)/ Document finisher face up (FU)/ 3000-sheet document finisher left sub tray (FU) 03: Document finisher face down (FD) 04: Reserved 05: Reserved 06: 3000-sheet document finisher right sub tray (FU) 07: 3000-sheet document finisher left sub tray (FD) 09: 3000-sheet document finisher right sub tray (FD) 0A: Center-folding unit tray 0B: Mailbox tray 1 (FD) 0C: Mailbox tray 1 (FU) 0D: Reserved 0E: Reserved 15: Mailbox tray 2 (FD) 16: Mailbox tray 2 (FU) 1F: Mailbox tray 3 (FD) 20: Mailbox tray 3 (FU) 29: Mailbox tray 4 (FD) 2A: Mailbox tray 4 (FU) 33: Mailbox tray 5 (FD) 34: Mailbox tray 5 (FU) 3D: Mailbox tray 6 (FD) 3E: Mailbox tray 6 (FU) 47: Mailbox tray 7 (FD) 48: Mailbox tray 7 (FU)		
	(4)	Service Call Log	#	Count.	Service Code
	(5)		Maintenance Log	#	Count.
				Item	

Maintenance item No.	Description				
U000	Description				
	No.	Items	Description		
	(6)	Unknown Toner Log	<p>#</p> <p>Remembers 1 to 5 of occurrence of unknown toner detection. If the occurrence of the previous unknown toner detection is less than 5, all of the unknown toner detection are logged.</p>	<p>Count.</p> <p>The total page count at the time of the [Toner Empty] error with using an unknown toner container.</p>	<p>Item</p> <p>Unknown toner log code (1 byte, 2 categories)</p> <p>First byte 01: Fixed (Toner container)</p> <p>Second byte 00: Fixed (Black)</p>
	(7)	<p>Counter Log</p> <p>Comprised of three log counters including paper jams, self diagnostics errors, and replacement of the toner container.</p>	<p>(f) Paper jam</p> <p>Indicates the log counter of paper jams depending on location.</p> <p>Refer to Paper Jam Log.</p> <p>All instances including those are not occurred are displayed.</p>	<p>(g) Self diagnostic error</p> <p>Indicates the log counter of self diagnostics errors depending on cause. (See page 1-4-26)</p> <p>Example: C6000: 4</p> <p>Self diagnostics error 6000 has happened four times.</p>	<p>(h) Maintenance item replacing</p> <p>Indicates the log counter depending on the maintenance item for maintenance.</p> <p>T: Toner container 00: Black M: Maintenance kit 00: MK-726</p> <p>Example: T00: 1 The toner container has been replaced once.</p>

Maintenance item No.	Description												
U000	<p>Service status page (1)</p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p>Service Status Page MFP</p> <p style="text-align: right;">(2) 17/06/2009 08:40</p> <p>(1) Firmware version 2KS_2000.000.000 2009.06.17 (3) [XXXXXXXX] (4) [XXXXXXXX] (5) [XXXXXXXX]</p> <hr/> <p>Controller Information</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">Memory status</td> <td colspan="2">(28) FRPO Status</td> </tr> <tr> <td>(6) Total Size</td> <td>1.0 GB</td> <td>Default Pattern Switch</td> <td>B8 0</td> </tr> <tr> <td></td> <td></td> <td>Default Font Number</td> <td>C5*10000+C2*100+C3 00000</td> </tr> </table> <p>Time</p> <p>(7) Local Time Zone +01:00 Tokio (8) Date and Time 17/06/2009 08:40 (9) Time Server 10.183.53.13</p> <p>Installed Options</p> <p>(10) Document Processor Installed (11) Paper feeder Cassette (12) Finisher 3000-Finisher (13) Mail Box Not Installed (14) Job Sparator Installed (15) Security Kit Data Security Kit (E) Software Type II</p> <p>Digital Dot Coverage</p> <p>(16) Average(%) / Usage Page(A4/Letter Conversion) (17) Total K: 1.10 / 1111111.11 (18) Copy K: 1.10 / 1111111.11 (19) Printer K: 1.10 / 1111111.11 (20) FAX K: 1.10 / 1111111.11 (21) Period (03/11/2009 - 27/10/2009 08:40) (22) Last Page (%) 1.00</p> <p>(23) FAX Information Slot1/Slot2 (24) Rings (Normal) 3 (25) Rings (FAX/TEL) 3 (26) Rings (TAD) 3 (27) Option DIMM Size 16 MB</p> <p style="text-align: right;">e-MPS error control Y6 0</p> <hr/> <p style="text-align: center;">1 (29) [XXXXXXXXXXXXXXXXXXXX]</p> </div>	Memory status		(28) FRPO Status		(6) Total Size	1.0 GB	Default Pattern Switch	B8 0			Default Font Number	C5*10000+C2*100+C3 00000
Memory status		(28) FRPO Status											
(6) Total Size	1.0 GB	Default Pattern Switch	B8 0										
		Default Font Number	C5*10000+C2*100+C3 00000										

Figure 1-3-2

Maintenance item No.	Description		
U000	<p>Service status page (2)</p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p>Service Status Page MFP</p> <p style="text-align: right;">17/06/2009 08:40</p> <p>Firmware version 2KS_2000.000.000 2009.06.17 [XXXXXXXX] [XXXXXXXX] [XXXXXXXX]</p> <hr/> <p>Engine Information</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; vertical-align: top;"> <p>(30) NVRAM Version _Bb04B29_Bb04B29</p> <p>(31) Scanner Version 2KS_1200.001.089</p> <p>(32) FAX Slot1</p> <p style="padding-left: 20px;">FAX BOOT Version 5JP_5000.001.001</p> <p style="padding-left: 20px;">FAX APL Version 5JP_5100.001.001</p> <p style="padding-left: 20px;">FAX IPL Version 5JP_5200.001.001</p> <p>(33) MAC Address 00:C0:EE:D0:01:0D</p> </td> <td style="width: 50%; vertical-align: top; padding-left: 20px;"> <p>Send Information</p> <p>(34) Date and Time 09/06/17</p> <p>(35) Address</p> </td> </tr> </table> <p>(36) 1/2</p> <p>(37) 100/100</p> <p>(38) 0/0/0/0/0/0/0/</p> <p>(39) 0000000/0000000/0000000/0000000/0000000/0000000/0000000/0000000/0000000/0000000/0000000/</p> <p style="padding-left: 20px;">F00/U00/0/0/0/30/30/70/70/abcde/1/</p> <p>(40)(41)(42)(43)(44)(45)(46)(47)(48)(49)(50)</p> <p>(51) 0000/</p> <p>(52) 12345678/11223344/00001234abcd567800001234abcd5678/01234567890123456789012345678901/0008/00/07</p> <p>(53) XXXXXXXX</p> <p>(54) 0000000000/F80C001A37/302A183C00/000100013D/8791BEC305/0000003100/000F5D0000/01FD000000/0000000FB7/0000000000/0000260000/0000000000/0000000000/0000000000/0000008400/0000000000/011E000F51/0000000FB7/0000000000/0000260000/0000000000/0000</p> <p>(55) ABCDEFGHIJ/</p> </div> <hr style="width: 80%; margin: 10px auto;"/> <p style="text-align: center;">2 [XXXXXXXXXXXXXXXXXXXX]</p>	<p>(30) NVRAM Version _Bb04B29_Bb04B29</p> <p>(31) Scanner Version 2KS_1200.001.089</p> <p>(32) FAX Slot1</p> <p style="padding-left: 20px;">FAX BOOT Version 5JP_5000.001.001</p> <p style="padding-left: 20px;">FAX APL Version 5JP_5100.001.001</p> <p style="padding-left: 20px;">FAX IPL Version 5JP_5200.001.001</p> <p>(33) MAC Address 00:C0:EE:D0:01:0D</p>	<p>Send Information</p> <p>(34) Date and Time 09/06/17</p> <p>(35) Address</p>
<p>(30) NVRAM Version _Bb04B29_Bb04B29</p> <p>(31) Scanner Version 2KS_1200.001.089</p> <p>(32) FAX Slot1</p> <p style="padding-left: 20px;">FAX BOOT Version 5JP_5000.001.001</p> <p style="padding-left: 20px;">FAX APL Version 5JP_5100.001.001</p> <p style="padding-left: 20px;">FAX IPL Version 5JP_5200.001.001</p> <p>(33) MAC Address 00:C0:EE:D0:01:0D</p>	<p>Send Information</p> <p>(34) Date and Time 09/06/17</p> <p>(35) Address</p>		

Figure 1-3-3

Maintenance item No.	Description	
U000	Detail of service status page	
	No.	Description
	(1)	System version
	(2)	System date
	(3)	Engine soft version
	(4)	Engine boot version
	(5)	Operation panel mask version
	(6)	Total RAM size
	(7)	Local time zone
	(8)	Report output date
	(9)	Day/Month/Year hour:minute
	(10)	NTP server name
	(11)	Installed/Not Installed
	(12)	Presence or absence of the optional DP
	(13)	Cassette/LCF/Not Installed
	(14)	Presence or absence of the optional paper feeder
	(15)	Inner Finisher Tray/3000-Finisher/1000-Finisher/Not Installed
	(16)	Presence or absence of the optional document finisher
	(17)	Installed/Not Installed
	(18)	Presence or absence of the optional mailbox
	(19)	Installed/Not Installed
	(20)	Presence or absence of the optional job separator
	(21)	Installed/Not Installed
	(22)	Presence or absence of the optional data security kit
	(23)	Installed/Not Installed
	(24)	Page of relation to the A4/Letter
	(25)	Average coverage for total
	(26)	Average coverage for copy
	(27)	Average coverage for printer
	(28)	Average coverage for fax
	(29)	Cleared date and output date
	(30)	Coverage on the final output page
	(31)	Fax kit information
	(32)	This item is printed only when the fax kit is installed.
	(33)	Number of rings
	(34)	0 to 15
	(35)	Number of rings before automatic switching
	(36)	0 to 15
	(37)	Number of rings before connecting to answering machine
	(38)	0 to 15
	(39)	Optional DIMM size
	(40)	FRPO setting
	(41)	Machine serial number

Maintenance item No.	Description																																																																
U000	<table border="1"> <thead> <tr> <th data-bbox="292 304 363 338">No.</th> <th data-bbox="363 304 807 338">Description</th> <th data-bbox="807 304 1414 338">Supplement</th> </tr> </thead> <tbody> <tr> <td data-bbox="292 338 363 887">(30)</td> <td data-bbox="363 338 807 887">NV RAM version</td> <td data-bbox="807 338 1414 887"> _ Bb 04B29 _ Bb 04B29 (a) (b) (c) (d) (e) (f) (a) Consistency of the present software version and the database _ (underscore): OK * (Asterisk): NG (b) Database version (c) The oldest time stamp of database version (d) Consistency of the present software version and the ME firmware version _ (underscore): OK * (Asterisk): NG (e) ME firmware version (f) The oldest time stamp of the ME database version Normal if (a) and (d) are underscored, and (b) and (e) are identical with (c) and (f). </td> </tr> <tr> <td data-bbox="292 887 363 920">(31)</td> <td data-bbox="363 887 807 920">Scanner firmware version</td> <td data-bbox="807 887 1414 920"></td> </tr> <tr> <td data-bbox="292 920 363 954">(32)</td> <td data-bbox="363 920 807 954">Fax firmware version</td> <td data-bbox="807 920 1414 954">This item is printed only when the fax kit is installed.</td> </tr> <tr> <td data-bbox="292 954 363 987">(33)</td> <td data-bbox="363 954 807 987">Mac address</td> <td data-bbox="807 954 1414 987"></td> </tr> <tr> <td data-bbox="292 987 363 1021">(34)</td> <td data-bbox="363 987 807 1021">Send date</td> <td data-bbox="807 987 1414 1021"></td> </tr> <tr> <td data-bbox="292 1021 363 1055">(35)</td> <td data-bbox="363 1021 807 1055">Send address</td> <td data-bbox="807 1021 1414 1055"></td> </tr> <tr> <td data-bbox="292 1055 363 1088">(36)</td> <td data-bbox="363 1055 807 1088">Destination information/Area information</td> <td data-bbox="807 1055 1414 1088"></td> </tr> <tr> <td data-bbox="292 1088 363 1122">(37)</td> <td data-bbox="363 1088 807 1122">Margin settings</td> <td data-bbox="807 1088 1414 1122">Top margin/Left margin</td> </tr> <tr> <td data-bbox="292 1122 363 1200">(38)</td> <td data-bbox="363 1122 807 1200">Margin/Page length/Page width settings</td> <td data-bbox="807 1122 1414 1200">Top margin integer part/Top margin decimal part/ Left margin integer part/Left margin decimal part/ Page length integer part/Page length decimal part/ Page width integer part/Page width decimal part</td> </tr> <tr> <td data-bbox="292 1200 363 1234">(39)</td> <td data-bbox="363 1200 807 1234">Life counter (The first line)</td> <td data-bbox="807 1200 1414 1234">Machine life counter/MP tray counter/ Cassette 1 counter/Cassette 2 counter/ Cassette 3 counter/Cassette 4 counter/Duplex counter</td> </tr> <tr> <td data-bbox="292 1234 363 1267"></td> <td data-bbox="363 1234 807 1267">Life counter (The second line)</td> <td data-bbox="807 1234 1414 1267">Drum unit counter/Developing unit counter/ Maintenance kit counter/</td> </tr> <tr> <td data-bbox="292 1267 363 1301">(40)</td> <td data-bbox="363 1267 807 1301">Panel lock information</td> <td data-bbox="807 1267 1414 1301">0: OFF/1: Partial lock/2: Full lock</td> </tr> <tr> <td data-bbox="292 1301 363 1335">(41)</td> <td data-bbox="363 1301 807 1335">USB information</td> <td data-bbox="807 1301 1414 1335">0: Not installed/1: Full speed/2: Hi speed</td> </tr> <tr> <td data-bbox="292 1335 363 1368">(42)</td> <td data-bbox="363 1335 807 1368">Paper handling information</td> <td data-bbox="807 1335 1414 1368">0: Paper source unit select/1: Paper source unit</td> </tr> <tr> <td data-bbox="292 1368 363 1402">(43)</td> <td data-bbox="363 1368 807 1402">Black and white printing double count mode</td> <td data-bbox="807 1368 1414 1402">0: All single counts 3: Folio, Single count, Less the 330 mm (length)</td> </tr> <tr> <td data-bbox="292 1402 363 1435">(44)</td> <td data-bbox="363 1402 807 1435">Billing counting timing</td> <td data-bbox="807 1402 1414 1435"></td> </tr> <tr> <td data-bbox="292 1435 363 1469">(45)</td> <td data-bbox="363 1435 807 1469">Temperature (machine inside)</td> <td data-bbox="807 1435 1414 1469"></td> </tr> <tr> <td data-bbox="292 1469 363 1503">(46)</td> <td data-bbox="363 1469 807 1503">Temperature (machine outside)</td> <td data-bbox="807 1469 1414 1503"></td> </tr> <tr> <td data-bbox="292 1503 363 1536">(47)</td> <td data-bbox="363 1503 807 1536">Relative temperature (machine outside)</td> <td data-bbox="807 1503 1414 1536"></td> </tr> <tr> <td data-bbox="292 1536 363 1570">(48)</td> <td data-bbox="363 1536 807 1570">Absolute temperature (machine outside)</td> <td data-bbox="807 1536 1414 1570"></td> </tr> </tbody> </table>		No.	Description	Supplement	(30)	NV RAM version	_ Bb 04B29 _ Bb 04B29 (a) (b) (c) (d) (e) (f) (a) Consistency of the present software version and the database _ (underscore): OK * (Asterisk): NG (b) Database version (c) The oldest time stamp of database version (d) Consistency of the present software version and the ME firmware version _ (underscore): OK * (Asterisk): NG (e) ME firmware version (f) The oldest time stamp of the ME database version Normal if (a) and (d) are underscored, and (b) and (e) are identical with (c) and (f).	(31)	Scanner firmware version		(32)	Fax firmware version	This item is printed only when the fax kit is installed.	(33)	Mac address		(34)	Send date		(35)	Send address		(36)	Destination information/Area information		(37)	Margin settings	Top margin/Left margin	(38)	Margin/Page length/Page width settings	Top margin integer part/Top margin decimal part/ Left margin integer part/Left margin decimal part/ Page length integer part/Page length decimal part/ Page width integer part/Page width decimal part	(39)	Life counter (The first line)	Machine life counter/MP tray counter/ Cassette 1 counter/Cassette 2 counter/ Cassette 3 counter/Cassette 4 counter/Duplex counter		Life counter (The second line)	Drum unit counter/Developing unit counter/ Maintenance kit counter/	(40)	Panel lock information	0: OFF/1: Partial lock/2: Full lock	(41)	USB information	0: Not installed/1: Full speed/2: Hi speed	(42)	Paper handling information	0: Paper source unit select/1: Paper source unit	(43)	Black and white printing double count mode	0: All single counts 3: Folio, Single count, Less the 330 mm (length)	(44)	Billing counting timing		(45)	Temperature (machine inside)		(46)	Temperature (machine outside)		(47)	Relative temperature (machine outside)		(48)	Absolute temperature (machine outside)	
No.	Description	Supplement																																																															
(30)	NV RAM version	_ Bb 04B29 _ Bb 04B29 (a) (b) (c) (d) (e) (f) (a) Consistency of the present software version and the database _ (underscore): OK * (Asterisk): NG (b) Database version (c) The oldest time stamp of database version (d) Consistency of the present software version and the ME firmware version _ (underscore): OK * (Asterisk): NG (e) ME firmware version (f) The oldest time stamp of the ME database version Normal if (a) and (d) are underscored, and (b) and (e) are identical with (c) and (f).																																																															
(31)	Scanner firmware version																																																																
(32)	Fax firmware version	This item is printed only when the fax kit is installed.																																																															
(33)	Mac address																																																																
(34)	Send date																																																																
(35)	Send address																																																																
(36)	Destination information/Area information																																																																
(37)	Margin settings	Top margin/Left margin																																																															
(38)	Margin/Page length/Page width settings	Top margin integer part/Top margin decimal part/ Left margin integer part/Left margin decimal part/ Page length integer part/Page length decimal part/ Page width integer part/Page width decimal part																																																															
(39)	Life counter (The first line)	Machine life counter/MP tray counter/ Cassette 1 counter/Cassette 2 counter/ Cassette 3 counter/Cassette 4 counter/Duplex counter																																																															
	Life counter (The second line)	Drum unit counter/Developing unit counter/ Maintenance kit counter/																																																															
(40)	Panel lock information	0: OFF/1: Partial lock/2: Full lock																																																															
(41)	USB information	0: Not installed/1: Full speed/2: Hi speed																																																															
(42)	Paper handling information	0: Paper source unit select/1: Paper source unit																																																															
(43)	Black and white printing double count mode	0: All single counts 3: Folio, Single count, Less the 330 mm (length)																																																															
(44)	Billing counting timing																																																																
(45)	Temperature (machine inside)																																																																
(46)	Temperature (machine outside)																																																																
(47)	Relative temperature (machine outside)																																																																
(48)	Absolute temperature (machine outside)																																																																

Maintenance item No.	Description		
U000	No.	Description	Supplement
	(49)	Fixed assets number	
	(50)	Job complete judgment timeout time setting for local interface	
	(51)	Media type attributes 1 to 28 (Not used: 18, 19, 20)	Weight settings 0: Light/1: Normal 1 / 2: Normal 2 / 3: Normal 3/ 4: Heavy 1 / 5: Heavy 2 / 6: Heavy 3 / 7: Extra Heavy Fuser settings 0: High / 1: Middle / 2: Low / 3: Vellum Duplex settings 0: Disable / 1: Enable
	(52)	RFID information	
	(53)	RFID reader/writer version information	
	(54)	Maintenance information	
	(55)	Drum serial number	Black/Cyan/Magenta/Yellow
<p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>			
U001	<p>Exiting the maintenance mode Description Exits the maintenance mode and returns to the normal copy mode. Purpose To exit the maintenance mode. Method Press the start key. The normal copy mode is entered.</p>		
U002	<p>Setting the factory default data Description Restores the machine conditions to the factory default settings. Purpose To move the mirror frame of the scanner to the position for transport (position in which the frame can be fixed). Method 1. Press the start key. 2. Press [MODE1(ALL)] on the touch panel. 3. Press the start key. The mirror frame of the scanner returns to the position for transport. 4. Turn the main power switch off and on. An error code is displayed in case of an initialization error. Refer to the table of the error codes on P.1-3-19. When ERROR 09 occurred, turn main power switch off then on, format the hard disk using maintenance item U024, and execute initialization using maintenance item U002. For other errors occurred, turn main power switch off then on, and execute initialization using maintenance item U002.</p>		




Maintenance item No.	Description										
U003	<p>Setting the service telephone number</p> <p>Description Sets the telephone number to be displayed when a service call code is detected.</p> <p>Purpose To set the telephone number to call service when installing the machine.</p> <p>Method Press the start key. The currently set telephone number is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. The keys to enter the number are displayed on the touch panel. 2. Enter a telephone number (up to 15 digits). 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>										
U004	<p>Displaying the machine number</p> <p>Description Sets or displays the machine number.</p> <p>Purpose To check or set the machine number.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. If the machine serial number of engine PWB matches with that of main PWB <table border="1" data-bbox="331 1014 1398 1099"> <thead> <tr> <th data-bbox="336 1014 636 1055">Display</th> <th data-bbox="636 1014 1393 1055">Operation</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1055 636 1099">MACHINE No.</td> <td data-bbox="636 1055 1393 1099">Displays the machine serial number</td> </tr> </tbody> </table> <p>If the machine serial number of engine PWB does not match with that of main PWB</p> <table border="1" data-bbox="331 1149 1398 1272"> <thead> <tr> <th data-bbox="336 1149 636 1189">Display</th> <th data-bbox="636 1149 1393 1189">Operation</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1189 636 1229">MACHINE No. (MAIN)</td> <td data-bbox="636 1189 1393 1229">Displays the machine serial number of main</td> </tr> <tr> <td data-bbox="336 1229 636 1272">MACHINE No. (ENGINE)</td> <td data-bbox="636 1229 1393 1272">Displays the machine serial number of engine</td> </tr> </tbody> </table> <p>Setting Carry out if the machine serial number does not match.</p> <ol style="list-style-type: none"> 1. Press [EXECUTE]. 2. Press the start key. Writing of serial No. starts. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Operation	MACHINE No.	Displays the machine serial number	Display	Operation	MACHINE No. (MAIN)	Displays the machine serial number of main	MACHINE No. (ENGINE)	Displays the machine serial number of engine
Display	Operation										
MACHINE No.	Displays the machine serial number										
Display	Operation										
MACHINE No. (MAIN)	Displays the machine serial number of main										
MACHINE No. (ENGINE)	Displays the machine serial number of engine										



Maintenance item No.	Description																																																				
U019	<p>Displaying the ROM version</p> <p>Description Displays the part number of the ROM fitted to each PWB.</p> <p>Purpose To check the part number or to decide, if the newest version of ROM is installed.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The ROM version are displayed. 2. Change the screen using the cursor up/down keys. <table border="1" data-bbox="335 542 1398 1621"> <thead> <tr> <th data-bbox="335 542 715 584">Display</th> <th data-bbox="715 542 1398 584">Description</th> </tr> </thead> <tbody> <tr><td data-bbox="335 584 715 622">MAIN</td><td data-bbox="715 584 1398 622">Main ROM</td></tr> <tr><td data-bbox="335 622 715 660">MMI</td><td data-bbox="715 622 1398 660">Operation ROM</td></tr> <tr><td data-bbox="335 660 715 698">ENGINE</td><td data-bbox="715 660 1398 698">Engine ROM</td></tr> <tr><td data-bbox="335 698 715 736">ENGINE BOOT</td><td data-bbox="715 698 1398 736">Engine booting</td></tr> <tr><td data-bbox="335 736 715 775">SCANNER</td><td data-bbox="715 736 1398 775">Scanner ROM</td></tr> <tr><td data-bbox="335 775 715 813">BROWSER</td><td data-bbox="715 775 1398 813">Browser ROM</td></tr> <tr><td data-bbox="335 813 715 851">OPTION LANGUAGE</td><td data-bbox="715 813 1398 851">Optional language ROM</td></tr> <tr><td data-bbox="335 851 715 889">DICTIONARY</td><td data-bbox="715 851 1398 889">-</td></tr> <tr><td data-bbox="335 889 715 927">DBA</td><td data-bbox="715 889 1398 927">Database connection</td></tr> <tr><td data-bbox="335 927 715 965">Solution Framework</td><td data-bbox="715 927 1398 965">Solution framework</td></tr> <tr><td data-bbox="335 965 715 1003">DP</td><td data-bbox="715 965 1398 1003">Optional DP ROM</td></tr> <tr><td data-bbox="335 1003 715 1041">500x2PF</td><td data-bbox="715 1003 1398 1041">Optional paper feeder ROM</td></tr> <tr><td data-bbox="335 1041 715 1079">3000PF</td><td data-bbox="715 1041 1398 1079">Optional 3000-sheet paper feeder ROM</td></tr> <tr><td data-bbox="335 1079 715 1117">1000DF</td><td data-bbox="715 1079 1398 1117">Optional document finisher ROM</td></tr> <tr><td data-bbox="335 1117 715 1155">3000DF MAIN</td><td data-bbox="715 1117 1398 1155">Optional 3000-sheet document finisher main ROM</td></tr> <tr><td data-bbox="335 1155 715 1193">3000DF MIDDLE</td><td data-bbox="715 1155 1398 1193">Optional 3000-sheet document finisher Inner tray ROM</td></tr> <tr><td data-bbox="335 1193 715 1232">MAIL BOX</td><td data-bbox="715 1193 1398 1232">Optional mailbox ROM</td></tr> <tr><td data-bbox="335 1232 715 1270">BOOKLET</td><td data-bbox="715 1232 1398 1270">Optional center-folding unit ROM</td></tr> <tr><td data-bbox="335 1270 715 1308">INNER DF</td><td data-bbox="715 1270 1398 1308">Optional built-in finisher ROM</td></tr> <tr><td data-bbox="335 1308 715 1346">FAX BOOT1</td><td data-bbox="715 1308 1398 1346">Optional fax control PWB booting (port 1)</td></tr> <tr><td data-bbox="335 1346 715 1384">FAX APL1</td><td data-bbox="715 1346 1398 1384">Optional fax control PWB APL (port 1)</td></tr> <tr><td data-bbox="335 1384 715 1422">FAX IPL1</td><td data-bbox="715 1384 1398 1422">Optional fax control PWB IPL (port 1)</td></tr> <tr><td data-bbox="335 1422 715 1460">FAX BOOT2</td><td data-bbox="715 1422 1398 1460">Fax control PWB booting (port 2: optional dual FAX)</td></tr> <tr><td data-bbox="335 1460 715 1498">FAX APL2</td><td data-bbox="715 1460 1398 1498">Fax control PWB APL (port 2: optional dual FAX)</td></tr> <tr><td data-bbox="335 1498 715 1536">FAX IPL2</td><td data-bbox="715 1498 1398 1536">Fax control PWB IPL (port 2: optional dual FAX)</td></tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MAIN	Main ROM	MMI	Operation ROM	ENGINE	Engine ROM	ENGINE BOOT	Engine booting	SCANNER	Scanner ROM	BROWSER	Browser ROM	OPTION LANGUAGE	Optional language ROM	DICTIONARY	-	DBA	Database connection	Solution Framework	Solution framework	DP	Optional DP ROM	500x2PF	Optional paper feeder ROM	3000PF	Optional 3000-sheet paper feeder ROM	1000DF	Optional document finisher ROM	3000DF MAIN	Optional 3000-sheet document finisher main ROM	3000DF MIDDLE	Optional 3000-sheet document finisher Inner tray ROM	MAIL BOX	Optional mailbox ROM	BOOKLET	Optional center-folding unit ROM	INNER DF	Optional built-in finisher ROM	FAX BOOT1	Optional fax control PWB booting (port 1)	FAX APL1	Optional fax control PWB APL (port 1)	FAX IPL1	Optional fax control PWB IPL (port 1)	FAX BOOT2	Fax control PWB booting (port 2: optional dual FAX)	FAX APL2	Fax control PWB APL (port 2: optional dual FAX)	FAX IPL2	Fax control PWB IPL (port 2: optional dual FAX)
Display	Description																																																				
MAIN	Main ROM																																																				
MMI	Operation ROM																																																				
ENGINE	Engine ROM																																																				
ENGINE BOOT	Engine booting																																																				
SCANNER	Scanner ROM																																																				
BROWSER	Browser ROM																																																				
OPTION LANGUAGE	Optional language ROM																																																				
DICTIONARY	-																																																				
DBA	Database connection																																																				
Solution Framework	Solution framework																																																				
DP	Optional DP ROM																																																				
500x2PF	Optional paper feeder ROM																																																				
3000PF	Optional 3000-sheet paper feeder ROM																																																				
1000DF	Optional document finisher ROM																																																				
3000DF MAIN	Optional 3000-sheet document finisher main ROM																																																				
3000DF MIDDLE	Optional 3000-sheet document finisher Inner tray ROM																																																				
MAIL BOX	Optional mailbox ROM																																																				
BOOKLET	Optional center-folding unit ROM																																																				
INNER DF	Optional built-in finisher ROM																																																				
FAX BOOT1	Optional fax control PWB booting (port 1)																																																				
FAX APL1	Optional fax control PWB APL (port 1)																																																				
FAX IPL1	Optional fax control PWB IPL (port 1)																																																				
FAX BOOT2	Fax control PWB booting (port 2: optional dual FAX)																																																				
FAX APL2	Fax control PWB APL (port 2: optional dual FAX)																																																				
FAX IPL2	Fax control PWB IPL (port 2: optional dual FAX)																																																				


Maintenance item No.	Description																												
U021	<p>Initializing counters and mode settings</p> <p>Description Initializes all settings, except those pertinent to the type of machine, namely each counter, service call history and mode setting. Also initializes backup RAM according to region specification selected in maintenance item U252 Setting the destination. Refer to *1 of the maintenance mode item list about the item initialized.</p> <p>Purpose To return the machine settings to their factory default.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press [EXECUTE] on the touch panel. 3. Press the start key. All data other than that for adjustments due to variations between machines is initialized based on the destination setting. 4. Turn the main power switch off and on. <p>An error code is displayed in case of an initialization error. When ERROR 09 occurred, turn main power switch off then on, format the hard disk using maintenance item U024, and execute initialization using maintenance item U021. For other errors occurred, turn main power switch off then on, and execute initialization using maintenance item U021.</p> <p>Error codes</p> <table border="1" data-bbox="331 913 1396 1496"> <thead> <tr> <th>Codes</th> <th>Description</th> </tr> </thead> <tbody> <tr><td>ERROR 01</td><td>Configuration initialization error</td></tr> <tr><td>ERROR 02</td><td>Counter initialization error</td></tr> <tr><td>ERROR 03</td><td>One-touch initialization error</td></tr> <tr><td>ERROR 04</td><td>Panel program initialization error</td></tr> <tr><td>ERROR 05</td><td>Event log initialization error</td></tr> <tr><td>ERROR 06</td><td>Account initialization error</td></tr> <tr><td>ERROR 07</td><td>Address book initialization error</td></tr> <tr><td>ERROR 08</td><td>Department initialization error</td></tr> <tr><td>ERROR 09</td><td>Document box initialization error</td></tr> <tr><td>ERROR 0a</td><td>Permissibility initialization error</td></tr> <tr><td>ERROR 0b</td><td>Job log initialization error</td></tr> <tr><td>ERROR 20</td><td>Engine initialization error</td></tr> <tr><td>ERROR 40</td><td>Scanner initialization error</td></tr> </tbody> </table>	Codes	Description	ERROR 01	Configuration initialization error	ERROR 02	Counter initialization error	ERROR 03	One-touch initialization error	ERROR 04	Panel program initialization error	ERROR 05	Event log initialization error	ERROR 06	Account initialization error	ERROR 07	Address book initialization error	ERROR 08	Department initialization error	ERROR 09	Document box initialization error	ERROR 0a	Permissibility initialization error	ERROR 0b	Job log initialization error	ERROR 20	Engine initialization error	ERROR 40	Scanner initialization error
Codes	Description																												
ERROR 01	Configuration initialization error																												
ERROR 02	Counter initialization error																												
ERROR 03	One-touch initialization error																												
ERROR 04	Panel program initialization error																												
ERROR 05	Event log initialization error																												
ERROR 06	Account initialization error																												
ERROR 07	Address book initialization error																												
ERROR 08	Department initialization error																												
ERROR 09	Document box initialization error																												
ERROR 0a	Permissibility initialization error																												
ERROR 0b	Job log initialization error																												
ERROR 20	Engine initialization error																												
ERROR 40	Scanner initialization error																												
U024	<p>HDD formatting</p> <p>Description Initializes the HDD. In addition, the following settings are also initialized by initializing the HDD. System menu (user login administration, job accounting, address book, one-touch keys and document box etc.), shortcuts and panel programs Initializing the HDD will cause installed applications to be deleted. Reinstall applications as necessary after initializing the HDD.</p> <p>Purpose To initialize the HDD when replacing the HDD after shipping.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press [EXECUTE] on the touch panel. 3. Press the start key to initialize the hard disk. 4. Turn the main power switch off and on. 																												


Maintenance item No.	Description																				
U030	<p>Checking motor operation</p> <p>Description Drives each motor.</p> <p>Purpose To check the operation of each motor.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the motor to be operated. 3. Press the start key. The operation starts. <table border="1" data-bbox="336 573 1398 779"> <thead> <tr> <th>Display</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>MAIN</td> <td>Drive motor (DM) is turned ON</td> </tr> <tr> <td>FEED</td> <td>Paper feed motor (PFM) is turned ON</td> </tr> <tr> <td>EJECT(FW)</td> <td>Eject motor (EM) is turned on clockwise</td> </tr> <tr> <td>EJECT(REV)</td> <td>Eject motor (EM) is turned on counterclockwise</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. To stop operation, press the stop key. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Operation	MAIN	Drive motor (DM) is turned ON	FEED	Paper feed motor (PFM) is turned ON	EJECT(FW)	Eject motor (EM) is turned on clockwise	EJECT(REV)	Eject motor (EM) is turned on counterclockwise										
Display	Operation																				
MAIN	Drive motor (DM) is turned ON																				
FEED	Paper feed motor (PFM) is turned ON																				
EJECT(FW)	Eject motor (EM) is turned on clockwise																				
EJECT(REV)	Eject motor (EM) is turned on counterclockwise																				
U031	<p>Checking switches for paper conveying</p> <p>Description Displays the on-off status of each paper detection switch on the paper path.</p> <p>Purpose To check if the switches for paper conveying operate correctly.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Turn each switch on and off manually to check the status. <p>When a switch is detected to be in the ON position, the display for that switch will be highlighted.</p> <table border="1" data-bbox="336 1216 1398 1630"> <thead> <tr> <th>Display</th> <th>Switches</th> </tr> </thead> <tbody> <tr> <td>FEED1</td> <td>Feed switch 1 (FSW1)</td> </tr> <tr> <td>FEED2</td> <td>Feed switch 2 (FSW2)</td> </tr> <tr> <td>FEED3</td> <td>Feed switch 3 (FSW3)</td> </tr> <tr> <td>MP TRAY</td> <td>MP feed switch (MPFSW)</td> </tr> <tr> <td>REGIST</td> <td>Registration switch (RSW)</td> </tr> <tr> <td>EJECT</td> <td>Eject switch (ESW)</td> </tr> <tr> <td>BRANCH</td> <td>Feedshift switch (FSSW)</td> </tr> <tr> <td>DUPLEX</td> <td>Duplex paper conveying switch (DUPPCSW)</td> </tr> <tr> <td>JOB SEPARATOR</td> <td>Job separator eject switch (JESW)*</td> </tr> </tbody> </table> <p>*: Optional.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Switches	FEED1	Feed switch 1 (FSW1)	FEED2	Feed switch 2 (FSW2)	FEED3	Feed switch 3 (FSW3)	MP TRAY	MP feed switch (MPFSW)	REGIST	Registration switch (RSW)	EJECT	Eject switch (ESW)	BRANCH	Feedshift switch (FSSW)	DUPLEX	Duplex paper conveying switch (DUPPCSW)	JOB SEPARATOR	Job separator eject switch (JESW)*
Display	Switches																				
FEED1	Feed switch 1 (FSW1)																				
FEED2	Feed switch 2 (FSW2)																				
FEED3	Feed switch 3 (FSW3)																				
MP TRAY	MP feed switch (MPFSW)																				
REGIST	Registration switch (RSW)																				
EJECT	Eject switch (ESW)																				
BRANCH	Feedshift switch (FSSW)																				
DUPLEX	Duplex paper conveying switch (DUPPCSW)																				
JOB SEPARATOR	Job separator eject switch (JESW)*																				

Maintenance item No.	Description																						
U032	<p>Checking clutch operation</p> <p>Description Turns each clutch on.</p> <p>Purpose To check the operation of each clutch.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the clutch to be operated. 3. Press the start key. The clutch turns on for 1 s. <table border="1" data-bbox="331 568 1396 1057"> <thead> <tr> <th>Display</th> <th>Clutches</th> </tr> </thead> <tbody> <tr> <td>PF1</td> <td>Paper feed clutch 1 (PFCL1)</td> </tr> <tr> <td>PF2</td> <td>Paper feed clutch 2 (PFCL2)</td> </tr> <tr> <td>PF MP TRAY</td> <td>MP paper feed clutch (MPPFCL)</td> </tr> <tr> <td>FEED1</td> <td>Feed clutch 1 (FCL1)</td> </tr> <tr> <td>FEED2</td> <td>Feed clutch 2 (FCL2)</td> </tr> <tr> <td>FEED3</td> <td>Feed clutch 3 (FCL3)</td> </tr> <tr> <td>FEED MP TRAY</td> <td>MP feed clutch (MPFCL)</td> </tr> <tr> <td>REGIST</td> <td>Registration clutch (RCL)</td> </tr> <tr> <td>DUPLEX</td> <td>Duplex feed clutch (DUPFCL)</td> </tr> <tr> <td>MOTOR ON</td> <td>The drive motor (DM) and the paper feed motor (PFM) are turned ON.</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. To stop motor driving, press [MOTOR ON] again. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Clutches	PF1	Paper feed clutch 1 (PFCL1)	PF2	Paper feed clutch 2 (PFCL2)	PF MP TRAY	MP paper feed clutch (MPPFCL)	FEED1	Feed clutch 1 (FCL1)	FEED2	Feed clutch 2 (FCL2)	FEED3	Feed clutch 3 (FCL3)	FEED MP TRAY	MP feed clutch (MPFCL)	REGIST	Registration clutch (RCL)	DUPLEX	Duplex feed clutch (DUPFCL)	MOTOR ON	The drive motor (DM) and the paper feed motor (PFM) are turned ON.
Display	Clutches																						
PF1	Paper feed clutch 1 (PFCL1)																						
PF2	Paper feed clutch 2 (PFCL2)																						
PF MP TRAY	MP paper feed clutch (MPPFCL)																						
FEED1	Feed clutch 1 (FCL1)																						
FEED2	Feed clutch 2 (FCL2)																						
FEED3	Feed clutch 3 (FCL3)																						
FEED MP TRAY	MP feed clutch (MPFCL)																						
REGIST	Registration clutch (RCL)																						
DUPLEX	Duplex feed clutch (DUPFCL)																						
MOTOR ON	The drive motor (DM) and the paper feed motor (PFM) are turned ON.																						
U033	<p>Checking solenoid operation</p> <p>Description Applies current to each solenoid in order to check its ON status.</p> <p>Purpose To check the operation of each solenoid.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the solenoid to be operated. 3. Press the start key. The solenoid turns on for 1 s. <table border="1" data-bbox="331 1503 1396 1742"> <thead> <tr> <th>Display</th> <th>Solenoids</th> </tr> </thead> <tbody> <tr> <td>TONER</td> <td>Toner feed solenoid (TNFSOL)</td> </tr> <tr> <td>BRANCH1</td> <td>Feedshift solenoid (FSSOL)</td> </tr> <tr> <td>BRANCH2</td> <td>Job feedshift solenoid (JFSSOL)*</td> </tr> <tr> <td>MOTOR ON</td> <td>The drive motor (DM) and the paper feed motor (PFM) are turned on.</td> </tr> </tbody> </table> <p>*Optional.</p> <ol style="list-style-type: none"> 4. To stop motor driving, press [MOTOR ON] again. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Solenoids	TONER	Toner feed solenoid (TNFSOL)	BRANCH1	Feedshift solenoid (FSSOL)	BRANCH2	Job feedshift solenoid (JFSSOL)*	MOTOR ON	The drive motor (DM) and the paper feed motor (PFM) are turned on.												
Display	Solenoids																						
TONER	Toner feed solenoid (TNFSOL)																						
BRANCH1	Feedshift solenoid (FSSOL)																						
BRANCH2	Job feedshift solenoid (JFSSOL)*																						
MOTOR ON	The drive motor (DM) and the paper feed motor (PFM) are turned on.																						

Maintenance item No.	Description																																									
<p>U034</p> <p>Adjusting the print start timing</p> <p>Description Adjusts the leading edge registration or center line.</p> <p>Purpose Make the adjustment if there is a regular error between the leading edges of the copy image and original. Make the adjustment if there is a regular error between the center lines of the copy image and original.</p> <p>Method</p> <ol style="list-style-type: none"> Press the start key. Select the item to be adjusted. The setting screen for the selected item is displayed. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>LSU OUT TOP</td> <td>Leading edge registration adjustment</td> </tr> <tr> <td>LSU OUT LEFT</td> <td>Center line adjustment</td> </tr> </tbody> </table> <p>Adjustment: Leading edge registration adjustment</p> <ol style="list-style-type: none"> Select the item to be adjusted. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 20%;">Display</th> <th style="width: 40%;">Description</th> <th style="width: 15%;">Setting range</th> <th style="width: 10%;">Initial setting</th> <th style="width: 15%;">Change in value per step</th> </tr> </thead> <tbody> <tr> <td>LSUOUT TOP MPT (L)</td> <td>Paper feed from MP tray (when large size paper is used)</td> <td>-10.0 to 10.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>LSUOUT TOP CAS (L)</td> <td>Paper feed from cassette (when large size paper is used)</td> <td>-10.0 to 10.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>LSUOUT TOP DUP (L)</td> <td>Duplex mode (second) (when large size paper is used)</td> <td>-10.0 to 10.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>LSUOUT TOP MPT (S)</td> <td>Paper feed from MP tray (when small size paper is used)</td> <td>-10.0 to 10.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>LSUOUT TOP CAS (S)</td> <td>Paper feed from cassette (when small size paper is used)</td> <td>-10.0 to 10.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>LSUOUT TOP DUP (S)</td> <td>Duplex mode (second) (when small size paper is used)</td> <td>-10.0 to 10.0</td> <td>0</td> <td>0.1 mm</td> </tr> </tbody> </table> <p>Large size: 218 mm or more in width of paper.</p> <ol style="list-style-type: none"> Press the system menu key. Press the start key to output a test pattern. Press the system menu key. Change the setting value using the +/- or numeric keys. For output example 1, increase the value. For output example 2, decrease the value. <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Correct image</p> </div> <div style="text-align: center;">  <p>Output example 1</p> </div> <div style="text-align: center;">  <p>Output example 2</p> </div> </div> <p style="text-align: center;">Figure 1-3-4</p> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Remark When changing the setting value of [Large] each item is modified, equal to amount of the value which is changed adds also the value of [Small] each item and is pulled.</p>	Display	Description	LSU OUT TOP	Leading edge registration adjustment	LSU OUT LEFT	Center line adjustment	Display	Description	Setting range	Initial setting	Change in value per step	LSUOUT TOP MPT (L)	Paper feed from MP tray (when large size paper is used)	-10.0 to 10.0	0	0.1 mm	LSUOUT TOP CAS (L)	Paper feed from cassette (when large size paper is used)	-10.0 to 10.0	0	0.1 mm	LSUOUT TOP DUP (L)	Duplex mode (second) (when large size paper is used)	-10.0 to 10.0	0	0.1 mm	LSUOUT TOP MPT (S)	Paper feed from MP tray (when small size paper is used)	-10.0 to 10.0	0	0.1 mm	LSUOUT TOP CAS (S)	Paper feed from cassette (when small size paper is used)	-10.0 to 10.0	0	0.1 mm	LSUOUT TOP DUP (S)	Duplex mode (second) (when small size paper is used)	-10.0 to 10.0	0	0.1 mm	
Display	Description																																									
LSU OUT TOP	Leading edge registration adjustment																																									
LSU OUT LEFT	Center line adjustment																																									
Display	Description	Setting range	Initial setting	Change in value per step																																						
LSUOUT TOP MPT (L)	Paper feed from MP tray (when large size paper is used)	-10.0 to 10.0	0	0.1 mm																																						
LSUOUT TOP CAS (L)	Paper feed from cassette (when large size paper is used)	-10.0 to 10.0	0	0.1 mm																																						
LSUOUT TOP DUP (L)	Duplex mode (second) (when large size paper is used)	-10.0 to 10.0	0	0.1 mm																																						
LSUOUT TOP MPT (S)	Paper feed from MP tray (when small size paper is used)	-10.0 to 10.0	0	0.1 mm																																						
LSUOUT TOP CAS (S)	Paper feed from cassette (when small size paper is used)	-10.0 to 10.0	0	0.1 mm																																						
LSUOUT TOP DUP (S)	Duplex mode (second) (when small size paper is used)	-10.0 to 10.0	0	0.1 mm																																						




Maintenance item No.	Description																																			
U034	<p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div style="text-align: center;">  </div> <p>Adjustment: Center line adjustment</p> <ol style="list-style-type: none"> Select the item to be adjusted. <table border="1" data-bbox="331 533 1396 1037"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>LSUOUT LEFT (MPT)</td> <td>Paper feed from MP tray</td> <td>-10.0 to 10.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>LSUOUT LEFT (CAS 1)</td> <td>Paper feed from cassette 1</td> <td>-10.0 to 10.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>LSUOUT LEFT (CAS 2)</td> <td>Paper feed from cassette 2</td> <td>-10.0 to 10.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>LSUOUT LEFT (CAS 3)</td> <td>Paper feed from optional cassette 3</td> <td>-10.0 to 10.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>LSUOUT LEFT (CAS 4)</td> <td>Paper feed from optional cassette 4</td> <td>-10.0 to 10.0</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>LSUOUT LEFT (DUP)</td> <td>Duplex mode (second)</td> <td>-10.0 to 10.0</td> <td>0</td> <td>0.1 mm</td> </tr> </tbody> </table> <ol style="list-style-type: none"> Press the system menu key. Press the start key to output a test pattern. Press the system menu key. Change the setting value using the +/- or numeric keys. For output example 1, increase the value. For output example 2, decrease the value. <div style="text-align: center;"> <p>Center line of printing (within ± 0.5 mm)</p>  <p>Correct image Output example 1 Output example 2</p> </div> <p>Figure 1-3-5</p> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Remark If the setting value for feeding from the MP tray is changed, the difference from the former value is added to or subtracted from the values of other items.</p>	Display	Description	Setting range	Initial setting	Change in value per step	LSUOUT LEFT (MPT)	Paper feed from MP tray	-10.0 to 10.0	0	0.1 mm	LSUOUT LEFT (CAS 1)	Paper feed from cassette 1	-10.0 to 10.0	0	0.1 mm	LSUOUT LEFT (CAS 2)	Paper feed from cassette 2	-10.0 to 10.0	0	0.1 mm	LSUOUT LEFT (CAS 3)	Paper feed from optional cassette 3	-10.0 to 10.0	0	0.1 mm	LSUOUT LEFT (CAS 4)	Paper feed from optional cassette 4	-10.0 to 10.0	0	0.1 mm	LSUOUT LEFT (DUP)	Duplex mode (second)	-10.0 to 10.0	0	0.1 mm
Display	Description	Setting range	Initial setting	Change in value per step																																
LSUOUT LEFT (MPT)	Paper feed from MP tray	-10.0 to 10.0	0	0.1 mm																																
LSUOUT LEFT (CAS 1)	Paper feed from cassette 1	-10.0 to 10.0	0	0.1 mm																																
LSUOUT LEFT (CAS 2)	Paper feed from cassette 2	-10.0 to 10.0	0	0.1 mm																																
LSUOUT LEFT (CAS 3)	Paper feed from optional cassette 3	-10.0 to 10.0	0	0.1 mm																																
LSUOUT LEFT (CAS 4)	Paper feed from optional cassette 4	-10.0 to 10.0	0	0.1 mm																																
LSUOUT LEFT (DUP)	Duplex mode (second)	-10.0 to 10.0	0	0.1 mm																																

Maintenance item No.	Description																				
<p>U034</p>	<p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div style="text-align: center;">  <pre> graph LR U034[U034] --> U067["U067 (P.1-3-30)"] U067 --> U072["U072 (P.1-3-36)"] </pre> </div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>																				
<p>U035</p>	<p>Setting the printing area for folio paper Description Changes the printing area for copying on folio paper. Purpose To prevent cropped images on the trailing edge or left/right side of copy paper by setting the actual printing area for folio paper.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. 3. Change the setting using the +/- keys. <table border="1" data-bbox="336 871 1398 994"> <thead> <tr> <th>Display</th> <th>Setting</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>LENGTH DATA</td> <td>Length</td> <td>330 to 356 mm</td> <td>330</td> </tr> <tr> <td>WIDTH DATA</td> <td>Width</td> <td>200 to 220 mm</td> <td>210</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Setting	Setting range	Initial setting	LENGTH DATA	Length	330 to 356 mm	330	WIDTH DATA	Width	200 to 220 mm	210								
Display	Setting	Setting range	Initial setting																		
LENGTH DATA	Length	330 to 356 mm	330																		
WIDTH DATA	Width	200 to 220 mm	210																		
<p>U037</p>	<p>Checking the operation of the fan motors Description Drives the fan motors. Description To check the operation of the fan motors.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the fan motor to be operated. 3. Press the start key. The operation starts. <table border="1" data-bbox="336 1429 1398 1845"> <thead> <tr> <th>Display</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>Fixing Fan</td> <td>Fuser fan motor (FUFM) is turned on</td> </tr> <tr> <td>Developing Fan</td> <td>Developing fan motor (DEVFM) is turned on</td> </tr> <tr> <td>Controller Box Fan</td> <td>Controller fan motor (CONFM) is turned on</td> </tr> <tr> <td>Internal Fan</td> <td>LSU fan motor (LSUFM) is turned on</td> </tr> <tr> <td>Conveying Fan</td> <td>Paper conveying fan motor 1, 2, 3 (PCFM1, 2, 3) are turned on</td> </tr> <tr> <td>Power Source Fan</td> <td>Power source fan motor 1, 2 (PSFM1, 2) are turned on</td> </tr> <tr> <td>Triple Fan</td> <td>Duplex fan motor 1, 2, 3 (DUPFM1, 2, 3) are turned on</td> </tr> <tr> <td>ISU Fan</td> <td>Scanner fan motor (SFM) is turned on</td> </tr> <tr> <td>ALL</td> <td>All fan motor are turned on</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. To stop operation, press the stop key. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Operation	Fixing Fan	Fuser fan motor (FUFM) is turned on	Developing Fan	Developing fan motor (DEVFM) is turned on	Controller Box Fan	Controller fan motor (CONFM) is turned on	Internal Fan	LSU fan motor (LSUFM) is turned on	Conveying Fan	Paper conveying fan motor 1, 2, 3 (PCFM1, 2, 3) are turned on	Power Source Fan	Power source fan motor 1, 2 (PSFM1, 2) are turned on	Triple Fan	Duplex fan motor 1, 2, 3 (DUPFM1, 2, 3) are turned on	ISU Fan	Scanner fan motor (SFM) is turned on	ALL	All fan motor are turned on
Display	Operation																				
Fixing Fan	Fuser fan motor (FUFM) is turned on																				
Developing Fan	Developing fan motor (DEVFM) is turned on																				
Controller Box Fan	Controller fan motor (CONFM) is turned on																				
Internal Fan	LSU fan motor (LSUFM) is turned on																				
Conveying Fan	Paper conveying fan motor 1, 2, 3 (PCFM1, 2, 3) are turned on																				
Power Source Fan	Power source fan motor 1, 2 (PSFM1, 2) are turned on																				
Triple Fan	Duplex fan motor 1, 2, 3 (DUPFM1, 2, 3) are turned on																				
ISU Fan	Scanner fan motor (SFM) is turned on																				
ALL	All fan motor are turned on																				


Maintenance item No.	Description																				
U051	<p>Adjusting the deflection in the paper</p> <p>Description Adjusts the deflection in the paper.</p> <p>Purpose Make the adjustment if the leading edge of the copy image is missing or varies randomly, or if the copy paper is Z-folded.</p> <p>Adjustment</p> <ol style="list-style-type: none"> Press the start key. Select the item to be adjusted. <table border="1" data-bbox="331 562 1398 770"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>MPT</td> <td>Paper feed from MP tray</td> <td>-30 to 20</td> <td>0</td> </tr> <tr> <td>CASSETTE</td> <td>Paper feed from cassette</td> <td>-30 to 20</td> <td>0</td> </tr> <tr> <td>DUPLEX</td> <td>Duplex mode (second)</td> <td>-30 to 20</td> <td>0</td> </tr> <tr> <td>MPT (THICK)</td> <td>Paper feed from MP tray (thick paper)</td> <td>-30 to 20</td> <td>0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> Press the system menu key. Place an original and press the start key to make a test copy. Press the system menu key. Change the setting value using the +/- or numeric keys. For output example 1, increase the value. For output example 2, decrease the value. The greater the value, the larger the deflection; the smaller the value, the smaller the deflection. <div data-bbox="624 1014 1082 1240" style="text-align: center;">  <p>Original Copy example 1 Copy example 2</p> </div> <p>7. Press the start key. The value is set.</p> <p>Completion Press the stop key. The indication for selecting a maintenance item No. appears.</p>	Display	Description	Setting range	Initial setting	MPT	Paper feed from MP tray	-30 to 20	0	CASSETTE	Paper feed from cassette	-30 to 20	0	DUPLEX	Duplex mode (second)	-30 to 20	0	MPT (THICK)	Paper feed from MP tray (thick paper)	-30 to 20	0
Display	Description	Setting range	Initial setting																		
MPT	Paper feed from MP tray	-30 to 20	0																		
CASSETTE	Paper feed from cassette	-30 to 20	0																		
DUPLEX	Duplex mode (second)	-30 to 20	0																		
MPT (THICK)	Paper feed from MP tray (thick paper)	-30 to 20	0																		
U053	<p>Setting the adjustment of the motor speed</p> <p>Description Performs fine adjustment of the speeds of the motors.</p> <p>Purpose To adjust the speed of the respective motors when the magnification is not correct.</p> <p>Method</p> <ol style="list-style-type: none"> Press the start key. Select the item to be adjusted. <table border="1" data-bbox="331 1693 1398 1933"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>MAIN MOTOR</td> <td>Drive motor (DM) speed adjustment</td> <td>-40 to 40</td> <td>0</td> </tr> <tr> <td>EJECT MOTOR</td> <td>Eject motor (EM) speed adjustment</td> <td>-7 to 15</td> <td>0</td> </tr> <tr> <td>POLYGON MOTOR</td> <td>Polygon motor (PM) speed adjustment</td> <td>-20 to 20</td> <td>0</td> </tr> <tr> <td>FEED MOTOR</td> <td>Paper feed motor (PFM) speed adjustment</td> <td>-40 to 40</td> <td>0</td> </tr> </tbody> </table>	Display	Description	Setting range	Initial setting	MAIN MOTOR	Drive motor (DM) speed adjustment	-40 to 40	0	EJECT MOTOR	Eject motor (EM) speed adjustment	-7 to 15	0	POLYGON MOTOR	Polygon motor (PM) speed adjustment	-20 to 20	0	FEED MOTOR	Paper feed motor (PFM) speed adjustment	-40 to 40	0
Display	Description	Setting range	Initial setting																		
MAIN MOTOR	Drive motor (DM) speed adjustment	-40 to 40	0																		
EJECT MOTOR	Eject motor (EM) speed adjustment	-7 to 15	0																		
POLYGON MOTOR	Polygon motor (PM) speed adjustment	-20 to 20	0																		
FEED MOTOR	Paper feed motor (PFM) speed adjustment	-40 to 40	0																		

Maintenance item No.	Description						
<p>U053</p>	<p>Adjustment</p> <ol style="list-style-type: none"> 1. Press the system menu key. 2. Press the start key to output an A3/Ledger VTC pattern. <div data-bbox="612 376 858 696" style="text-align: center;"> </div> <p style="text-align: right;">Correct values for an A3/Ledger output are: A = 350 ± 1.4 mm B = 250 ± 1.0 mm</p> <p style="text-align: center;">Figure 1-3-7</p> <ol style="list-style-type: none"> 3. Press the system menu key. 4. Change the setting value using the +/- or numeric keys. <ul style="list-style-type: none"> A: Drive motor speed adjustment Increasing the setting makes the image longer in the auxiliary scanning direction, and decreasing it makes the image shorter in the auxiliary scanning direction. B: Polygon motor speed adjustment Increasing the setting makes the image shorter in the main scanning direction, and decreasing it makes the image longer in the main scanning direction. 5. Press the start key. The value is set. <p>Completion Press the stop key. The indication for selecting a maintenance item No. appears.</p>						
<p>U059</p>	<p>Setting fan mode</p> <p>Description Specifies mode for paper conveying fan motors during conveying paper.</p> <p>Purpose To prevent contamination caused by paper conveying fan motors scattering toner, select MODE2.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the mode. <table border="1" data-bbox="333 1447 1398 1632"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>MODE1</td> <td>Paper conveying motors are not deactivated in printing on paper with a width of less than 220 mm or less</td> </tr> <tr> <td>MODE2</td> <td>Paper conveying motors are deactivated in printing on paper with a width of less than 220 mm or less</td> </tr> </tbody> </table> <p>Initial setting: MODE1</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MODE1	Paper conveying motors are not deactivated in printing on paper with a width of less than 220 mm or less	MODE2	Paper conveying motors are deactivated in printing on paper with a width of less than 220 mm or less
Display	Description						
MODE1	Paper conveying motors are not deactivated in printing on paper with a width of less than 220 mm or less						
MODE2	Paper conveying motors are deactivated in printing on paper with a width of less than 220 mm or less						


Maintenance item No.	Description										
U061	<p>Turning the exposure lamp on</p> <p>Description Turns the exposure lamp on.</p> <p>Purpose To check the exposure lamp.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="333 533 1398 658"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>CCD</td> <td>The exposure lamp lights</td> </tr> <tr> <td>CIS</td> <td>The CIS lights (when dual scan DP is installed)</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The lamp lights. 4. To turn the lamp off, press the stop key. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	CCD	The exposure lamp lights	CIS	The CIS lights (when dual scan DP is installed)				
Display	Description										
CCD	The exposure lamp lights										
CIS	The CIS lights (when dual scan DP is installed)										
U063	<p>Adjusting the shading position</p> <p>Description Changes the shading position of the scanner.</p> <p>Purpose Used when white lines continue to appear longitudinally on the image after the shading plate is cleaned. This is due to flaws or stains inside the shading plate. To prevent this problem, the shading position should be changed so that shading is possible without being affected by the flaws or stains.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="333 1151 1398 1263"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>SHADING POSITION</td> <td>Shading position</td> <td>0 to 24</td> <td>0</td> <td>0.11 mm</td> </tr> </tbody> </table> <p>Increasing the setting moves the shading position toward the machine left, and decreasing it moves the position toward the machine right.</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Supplement While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	SHADING POSITION	Shading position	0 to 24	0	0.11 mm
Display	Description	Setting range	Initial setting	Change in value per step							
SHADING POSITION	Shading position	0 to 24	0	0.11 mm							



Maintenance item No.	Description															
<p>U065</p>	<p>Adjusting the scanner magnification</p> <p>Description Adjusts the magnification of the original scanning.</p> <p>Purpose Make the adjustment if the magnification in the main scanning direction is incorrect. Make the adjustment if the magnification in the auxiliary scanning direction is incorrect.</p> <p>Caution Adjust the magnification of the scanner in the following order.</p> <div style="text-align: center;">  </div> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be adjusted. <table border="1" data-bbox="331 739 1396 958"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Y SCAN ZOOM</td> <td>Scanner magnification in the main scanning direction</td> <td>-15 to 15</td> <td>0</td> <td>0.1 %</td> </tr> <tr> <td>X SCAN ZOOM</td> <td>Scanner magnification in the auxiliary scanning direction</td> <td>-25 to 25</td> <td>0</td> <td>0.05 %</td> </tr> </tbody> </table> <p>Adjustment: Main scanning direction</p> <ol style="list-style-type: none"> 1. Press the system menu key. 2. Place an original and press the start key to make a test copy. 3. Press the system menu key. 4. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div style="text-align: center;">  <p>Original Copy example 1 Copy example 2</p> </div> <p style="text-align: center;">Figure 1-3-8</p> <ol style="list-style-type: none"> 5. Press the start key. The value is set. <p>Adjustment: Auxiliary scanning direction</p> <ol style="list-style-type: none"> 1. Press the system menu key. 2. Place an original and press the start key to make a test copy. 3. Press the system menu key. 4. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div style="text-align: center;">  <p>Original Copy example 1 Copy example 2</p> </div> <p style="text-align: center;">Figure 1-3-9</p> <ol style="list-style-type: none"> 5. Press the start key. The value is set. 	Display	Description	Setting range	Initial setting	Change in value per step	Y SCAN ZOOM	Scanner magnification in the main scanning direction	-15 to 15	0	0.1 %	X SCAN ZOOM	Scanner magnification in the auxiliary scanning direction	-25 to 25	0	0.05 %
Display	Description	Setting range	Initial setting	Change in value per step												
Y SCAN ZOOM	Scanner magnification in the main scanning direction	-15 to 15	0	0.1 %												
X SCAN ZOOM	Scanner magnification in the auxiliary scanning direction	-25 to 25	0	0.05 %												


Maintenance item No.	Description															
U065	<p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>															
U066	<p>Adjusting the scanner leading edge registration Description Adjusts the scanner leading edge registration of the original scanning. Purpose Make the adjustment if there is a regular error between the leading edges of the copy image and original. Adjustment 1. Press the start key. 2. Select the item to be adjusted.</p> <table border="1" data-bbox="333 633 1398 819"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>FRONT</td> <td>Scanner leading edge registration</td> <td>-45 to 45</td> <td>0</td> <td>0.11 mm</td> </tr> <tr> <td>TAIL</td> <td>Scanner leading edge registration (rotate copying)</td> <td>-45 to 45</td> <td>0</td> <td>0.11 mm</td> </tr> </tbody> </table> <p>3. Press the system menu key. 4. Place an original and press the start key to make a test copy. 5. Press the system menu key. 6. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value.</p> <div data-bbox="627 1005 1075 1308" data-label="Image"> </div> <p style="text-align: center;">Figure 1-3-10</p> <p>7. Press the start key. The value is set.</p> <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <pre> graph LR U066[U066] --> U403[U403 (P.1-3-82)] U403 --> U071[U071 (P.1-3-34)] U071 --> U404[U404 (P.1-3-83)] </pre> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	FRONT	Scanner leading edge registration	-45 to 45	0	0.11 mm	TAIL	Scanner leading edge registration (rotate copying)	-45 to 45	0	0.11 mm
Display	Description	Setting range	Initial setting	Change in value per step												
FRONT	Scanner leading edge registration	-45 to 45	0	0.11 mm												
TAIL	Scanner leading edge registration (rotate copying)	-45 to 45	0	0.11 mm												

Maintenance item No.	Description																						
<p>U067</p> <p>Adjusting the scanner center line</p> <p>Description Adjusts the scanner center line of the original scanning.</p> <p>Purpose Make the adjustment if there is a regular error between the center lines of the copy image and original.</p> <p>Adjustment</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be adjusted. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> <th style="text-align: left;">Setting range</th> <th style="text-align: left;">Initial setting</th> <th style="text-align: left;">Change in value per step</th> </tr> </thead> <tbody> <tr> <td>FRONT</td> <td>Scanner center line</td> <td>-40 to 40</td> <td>0</td> <td>0.08 mm</td> </tr> <tr> <td>ROTATE</td> <td>Scanner center line (rotate copying)</td> <td>-40 to 40</td> <td>0</td> <td>0.08 mm</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the system menu key. 4. Place an original and press the start key to make a test copy. 5. Press the system menu key. 6. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div style="text-align: center;"> <p>Scanner center line</p>  <p>Original Copy example 1 Copy example 2</p> </div> <p style="text-align: center;">Figure 1-3-11</p> <ol style="list-style-type: none"> 7. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div style="text-align: center;"> <table border="1" style="margin: auto; border-collapse: collapse;"> <tr> <td style="padding: 5px;">U067</td> <td style="padding: 5px; text-align: center;">→</td> <td style="padding: 5px;">U403 (P.1-3-82)</td> <td style="padding: 5px; text-align: center;">→</td> <td style="padding: 5px;">U072 (P.1-3-36)</td> <td style="padding: 5px; text-align: center;">→</td> <td style="padding: 5px;">U404 (P.1-3-83)</td> </tr> </table> </div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	FRONT	Scanner center line	-40 to 40	0	0.08 mm	ROTATE	Scanner center line (rotate copying)	-40 to 40	0	0.08 mm	U067	→	U403 (P.1-3-82)	→	U072 (P.1-3-36)	→	U404 (P.1-3-83)	
Display	Description	Setting range	Initial setting	Change in value per step																			
FRONT	Scanner center line	-40 to 40	0	0.08 mm																			
ROTATE	Scanner center line (rotate copying)	-40 to 40	0	0.08 mm																			
U067	→	U403 (P.1-3-82)	→	U072 (P.1-3-36)	→	U404 (P.1-3-83)																	

Maintenance item No.	Description															
U068	<p>Adjusting the scanning position for originals from the DP</p> <p>Description Adjusts the position for scanning originals from the DP. Performs the test copy at the four scanning positions after adjusting.</p> <p>Purpose Used when the image fogging occurs because the scanning position is not proper when the DP is used. Run U071 to adjust the timing of DP leading edge when the scanning position is changed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. <table border="1" data-bbox="331 562 1398 779"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>DP READ</td> <td>Starting position adjustment for scanning originals</td> <td>-55 to 55</td> <td>0</td> <td>0.11 mm</td> </tr> <tr> <td>BLACK LINE</td> <td>Scanning position for the test copy originals</td> <td>0 to 3</td> <td>0</td> <td>-</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 2. Select [DP READ] of the screen for selecting an item. 3. Change the setting using the +/- or numeric keys. When the setting value is increased, the scanning position moves to the right and it moves to the left when the setting value is decreased. 4. Press the start key. The value is set. 5. Select [BLACK LINE] of the screen for selecting an item. 6. Select the scanning position using the +/- or numeric keys. 7. Press the start key. The value is set. 8. Set the original (the one which density is known) in the DP and press the system menu key. The screen for the test copy mode is displayed. 9. Press the start key. Test copy is executed. 10. Perform the test copy at each scanning position with the setting value from 0 to 3 and check that no black line appears and the image is normally scanned. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	DP READ	Starting position adjustment for scanning originals	-55 to 55	0	0.11 mm	BLACK LINE	Scanning position for the test copy originals	0 to 3	0	-
Display	Description	Setting range	Initial setting	Change in value per step												
DP READ	Starting position adjustment for scanning originals	-55 to 55	0	0.11 mm												
BLACK LINE	Scanning position for the test copy originals	0 to 3	0	-												

Maintenance item No.	Description																									
<p>U070</p>	<p>Adjusting the DP magnification</p> <p>Description Adjusts the DP original scanning speed.</p> <p>Purpose Make the adjustment if the magnification is incorrect in the main scanning direction or auxiliary scanning direction when the DP is used.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be adjusted. <table border="1" data-bbox="333 562 1398 922"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>MOTOR ADJ (FRONT)</td> <td>Magnification in the auxiliary scanning direction of CCD (first side)</td> <td>-25 to 25</td> <td>0</td> <td>0.05 %</td> </tr> <tr> <td>MOTOR ADJ (BACK)</td> <td>Magnification in the auxiliary scanning direction of CCD (second side)</td> <td>-25 to 25</td> <td>0</td> <td>0.05 %</td> </tr> <tr> <td>Y SCAN ZOOM (CIS)*</td> <td>Magnification in the main scanning direction of CIS</td> <td>-15 to 15</td> <td>0</td> <td>0.01 %</td> </tr> <tr> <td>X SCAN ZOOM (CIS)*</td> <td>Magnification in the auxiliary scanning direction of CIS</td> <td>-50 to 50</td> <td>0</td> <td>0.05 %</td> </tr> </tbody> </table> <p>*: Dual scan DP only.</p> <p>Adjustment: Main scanning direction of CIS</p> <ol style="list-style-type: none"> 1. Press the system menu key. 2. Place an original on the DP and press the start key to make a test copy. 3. Press the system menu key. 4. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div data-bbox="647 1189 1056 1429" style="text-align: center;">  <p>Original Copy example 1 Copy example 2</p> </div> <p style="text-align: center;">Figure 1-3-12</p> <ol style="list-style-type: none"> 5. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <pre> graph LR U070[U070] --> U071[U071 (P.1-3-34)] U071 --> U404[U404 (P.1-3-83)] </pre>	Display	Description	Setting range	Initial setting	Change in value per step	MOTOR ADJ (FRONT)	Magnification in the auxiliary scanning direction of CCD (first side)	-25 to 25	0	0.05 %	MOTOR ADJ (BACK)	Magnification in the auxiliary scanning direction of CCD (second side)	-25 to 25	0	0.05 %	Y SCAN ZOOM (CIS)*	Magnification in the main scanning direction of CIS	-15 to 15	0	0.01 %	X SCAN ZOOM (CIS)*	Magnification in the auxiliary scanning direction of CIS	-50 to 50	0	0.05 %
Display	Description	Setting range	Initial setting	Change in value per step																						
MOTOR ADJ (FRONT)	Magnification in the auxiliary scanning direction of CCD (first side)	-25 to 25	0	0.05 %																						
MOTOR ADJ (BACK)	Magnification in the auxiliary scanning direction of CCD (second side)	-25 to 25	0	0.05 %																						
Y SCAN ZOOM (CIS)*	Magnification in the main scanning direction of CIS	-15 to 15	0	0.01 %																						
X SCAN ZOOM (CIS)*	Magnification in the auxiliary scanning direction of CIS	-50 to 50	0	0.05 %																						

Maintenance item No.	Description
U070	<p>Adjustment: Auxiliary scanning direction of CCD/CIS</p> <ol style="list-style-type: none"> 1. Press the system menu key. 2. Place an original on the DP and press the start key to make a test copy. 3. Press the system menu key. 4. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div style="text-align: center;">  <p>Original Copy example 1 Copy example 2</p> </div> <p style="text-align: center;">Figure 1-3-13</p> <ol style="list-style-type: none"> 5. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div style="text-align: center;">  <pre> graph LR U070[U070] --> U071[U071 (P.1-3-34)] U071 --> U404[U404 (P.1-3-83)] </pre> </div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Maintenance item No.	Description																																			
<p>U071</p>	<p>Adjusting the DP scanning timing</p> <p>Description Adjusts the DP original scanning timing.</p> <p>Purpose Make the adjustment if there is a regular error between the leading or trailing edges of the original and the copy image when the DP is used.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be adjusted. <table border="1" data-bbox="331 562 1398 1005"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>FRONT HEAD</td> <td>Leading edge registration of CCD (first side)</td> <td>-66 to 66</td> <td>0</td> <td>0.08 mm</td> </tr> <tr> <td>FRONT TAIL</td> <td>Trailing edge registration of CCD (first side)</td> <td>-66 to 66</td> <td>0</td> <td>0.08 mm</td> </tr> <tr> <td>BACK HEAD</td> <td>Leading edge registration of CCD (second side)</td> <td>-66 to 66</td> <td>0</td> <td>0.08 mm</td> </tr> <tr> <td>BACK TAIL</td> <td>Trailing edge registration of CCD (second side)</td> <td>-66 to 66</td> <td>0</td> <td>0.08 mm</td> </tr> <tr> <td>HEAD (CIS)*</td> <td>Leading edge registration of CIS</td> <td>-66 to 66</td> <td>0</td> <td>0.08 mm</td> </tr> <tr> <td>TAIL (CIS)*</td> <td>Trailing edge registration of CIS</td> <td>-66 to 66</td> <td>0</td> <td>0.08 mm</td> </tr> </tbody> </table> <p>*: Dual scan DP only.</p> <p>Adjustment: Leading edge registration</p> <ol style="list-style-type: none"> 1. Press the system menu key. 2. Place an original on the DP and press the start key to make a test copy. 3. Press the system menu key. 4. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div style="text-align: center;">  <p>Original Copy example 1 Copy example 2</p> </div> <p style="text-align: center;">Figure 1-3-14</p> <ol style="list-style-type: none"> 5. Press the start key. The value is set. <p>Caution If the CCD first side is adjusted, check the CCD second side and if adjustment is required, carry out the adjustment. Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div style="border: 1px solid black; padding: 5px; display: inline-block; margin-right: 10px;">U071</div> → <div style="border: 1px solid black; padding: 5px; display: inline-block;">U404 (P.1-3-83)</div>	Display	Description	Setting range	Initial setting	Change in value per step	FRONT HEAD	Leading edge registration of CCD (first side)	-66 to 66	0	0.08 mm	FRONT TAIL	Trailing edge registration of CCD (first side)	-66 to 66	0	0.08 mm	BACK HEAD	Leading edge registration of CCD (second side)	-66 to 66	0	0.08 mm	BACK TAIL	Trailing edge registration of CCD (second side)	-66 to 66	0	0.08 mm	HEAD (CIS)*	Leading edge registration of CIS	-66 to 66	0	0.08 mm	TAIL (CIS)*	Trailing edge registration of CIS	-66 to 66	0	0.08 mm
Display	Description	Setting range	Initial setting	Change in value per step																																
FRONT HEAD	Leading edge registration of CCD (first side)	-66 to 66	0	0.08 mm																																
FRONT TAIL	Trailing edge registration of CCD (first side)	-66 to 66	0	0.08 mm																																
BACK HEAD	Leading edge registration of CCD (second side)	-66 to 66	0	0.08 mm																																
BACK TAIL	Trailing edge registration of CCD (second side)	-66 to 66	0	0.08 mm																																
HEAD (CIS)*	Leading edge registration of CIS	-66 to 66	0	0.08 mm																																
TAIL (CIS)*	Trailing edge registration of CIS	-66 to 66	0	0.08 mm																																













Maintenance item No.	Description
U071	<p>Adjustment: Trailing edge registration</p> <ol style="list-style-type: none"> 1. Press the system menu key. 2. Place an original on the DP and press the start key to make a test copy. 3. Press the system menu key. 4. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div data-bbox="644 461 999 692" style="text-align: center;"> <p>Original Copy example 1 Copy example 2</p> </div> <p style="text-align: center;">Figure 1-3-15</p> <ol style="list-style-type: none"> 5. Press the start key. The value is set. <p>Caution If the CCD first side is adjusted, check the CCD second side and if adjustment is required, carry out the adjustment. Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="288 994 624 1064" style="text-align: center;"> <pre> graph LR U071[U071] --> U404[U404 (P.1-3-83)] </pre> </div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Maintenance item No.	Description																				
<p>U072</p>	<p>Adjusting the DP center line</p> <p>Description Adjusts the scanning start position for the DP original.</p> <p>Purpose Make the adjustment if there is a regular error between the centers of the original and the copy image when the DP is used.</p> <p>Adjustment</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be adjusted. <table border="1" data-bbox="331 562 1398 759"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>FRONT</td> <td>DP center line of CCD (first side)</td> <td>-40 to 40</td> <td>0</td> <td>0.08 mm</td> </tr> <tr> <td>BACK</td> <td>DP center line of CCD (second side)</td> <td>-40 to 40</td> <td>0</td> <td>0.08 mm</td> </tr> <tr> <td>CIS*</td> <td>DP center line of CIS</td> <td>-40 to 40</td> <td>0</td> <td>0.08 mm</td> </tr> </tbody> </table> <p>*: Dual scan DP only.</p> <ol style="list-style-type: none"> 3. Press the system menu key. 4. Place an original on the DP and press the start key to make a test copy. 5. Press the system menu key. 6. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div data-bbox="636 965 1066 1198" style="text-align: center;"> </div> <p style="text-align: center;">Figure 1-3-16</p> <ol style="list-style-type: none"> 7. Press the start key. The value is set. <p>Caution If the CCD first side is adjusted, check the CCD second side and if adjustment is required, carry out the adjustment. Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="285 1503 624 1576" style="text-align: center;"> <pre> graph LR U072[U072] --> U404[U404 (P.1-3-83)] </pre> </div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	FRONT	DP center line of CCD (first side)	-40 to 40	0	0.08 mm	BACK	DP center line of CCD (second side)	-40 to 40	0	0.08 mm	CIS*	DP center line of CIS	-40 to 40	0	0.08 mm
Display	Description	Setting range	Initial setting	Change in value per step																	
FRONT	DP center line of CCD (first side)	-40 to 40	0	0.08 mm																	
BACK	DP center line of CCD (second side)	-40 to 40	0	0.08 mm																	
CIS*	DP center line of CIS	-40 to 40	0	0.08 mm																	


Maintenance item No.	Description																																																						
U073	<p>Checking scanner operation</p> <p>Description Simulates the scanner operation under arbitrary conditions.</p> <p>Purpose To check scanner operation.</p> <p>Start</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be operated. <table border="1" data-bbox="331 533 1396 741"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>SCANNER MOTOR</td> <td>Scanner operation</td> </tr> <tr> <td>HOME POSITION</td> <td>Home position operation</td> </tr> <tr> <td>DUST CHECK</td> <td>Dust adhesion check operation with lamp on</td> </tr> <tr> <td>DP READING</td> <td>DP scanning position operation</td> </tr> </tbody> </table> <p>Setting: [SCANNER MOTOR]</p> <ol style="list-style-type: none"> 1. Select [SCANNER MOTOR]. 2. Select the item. 3. Change the setting using the +/- keys. <table border="1" data-bbox="331 904 1396 1070"> <thead> <tr> <th>Display</th> <th>Operating conditions</th> <th>Setting range</th> </tr> </thead> <tbody> <tr> <td>ZOOM</td> <td>Magnification</td> <td>25 to 400 %</td> </tr> <tr> <td>SIZE</td> <td>Original size</td> <td>See below.</td> </tr> <tr> <td>LAMP</td> <td>On and off of the exposure lamp</td> <td>0 (off) or 1 (on)</td> </tr> </tbody> </table> <p>Original sizes for each setting in SIZE</p> <table border="1" data-bbox="331 1122 1396 1435"> <thead> <tr> <th>Setting</th> <th>Paper size</th> <th>Setting</th> <th>Paper size</th> </tr> </thead> <tbody> <tr> <td>5000</td> <td>A4</td> <td>5000</td> <td>A5R</td> </tr> <tr> <td>4300</td> <td>B5</td> <td>7800</td> <td>Folio</td> </tr> <tr> <td>5100</td> <td>11" x 8 1/2"</td> <td>10200</td> <td>11" x 17"</td> </tr> <tr> <td>10000</td> <td>A3</td> <td>9000</td> <td>11" x 15"</td> </tr> <tr> <td>8600</td> <td>B4</td> <td>8400</td> <td>8 1/2" x 14"</td> </tr> <tr> <td>7100</td> <td>A4R</td> <td>6600</td> <td>8 1/2" x 11"</td> </tr> <tr> <td>6100</td> <td>B5R</td> <td>5100</td> <td>5 1/2" x 8 1/2"</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. Scanning starts under the selected conditions. 5. To stop operation, press the stop key. <p>Method: [HOME POSITION]</p> <ol style="list-style-type: none"> 1. Select [HOME POSITION]. 2. Press the start key. The mirror frame of the scanner moves to the home position. <p>Method: [DUST CHECK]</p> <ol style="list-style-type: none"> 1. Select [DUST CHECK]. 2. Press the start key. The exposure lamp lights. 3. To turn the exposure lamp off, press the stop key. <p>Method: [DP READING]</p> <ol style="list-style-type: none"> 1. Select [DP READING]. 2. Press the start key. The mirror frame of the scanner moves to the reading position. <p>Completion Press the stop key when scanning stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	SCANNER MOTOR	Scanner operation	HOME POSITION	Home position operation	DUST CHECK	Dust adhesion check operation with lamp on	DP READING	DP scanning position operation	Display	Operating conditions	Setting range	ZOOM	Magnification	25 to 400 %	SIZE	Original size	See below.	LAMP	On and off of the exposure lamp	0 (off) or 1 (on)	Setting	Paper size	Setting	Paper size	5000	A4	5000	A5R	4300	B5	7800	Folio	5100	11" x 8 1/2"	10200	11" x 17"	10000	A3	9000	11" x 15"	8600	B4	8400	8 1/2" x 14"	7100	A4R	6600	8 1/2" x 11"	6100	B5R	5100	5 1/2" x 8 1/2"
Display	Description																																																						
SCANNER MOTOR	Scanner operation																																																						
HOME POSITION	Home position operation																																																						
DUST CHECK	Dust adhesion check operation with lamp on																																																						
DP READING	DP scanning position operation																																																						
Display	Operating conditions	Setting range																																																					
ZOOM	Magnification	25 to 400 %																																																					
SIZE	Original size	See below.																																																					
LAMP	On and off of the exposure lamp	0 (off) or 1 (on)																																																					
Setting	Paper size	Setting	Paper size																																																				
5000	A4	5000	A5R																																																				
4300	B5	7800	Folio																																																				
5100	11" x 8 1/2"	10200	11" x 17"																																																				
10000	A3	9000	11" x 15"																																																				
8600	B4	8400	8 1/2" x 14"																																																				
7100	A4R	6600	8 1/2" x 11"																																																				
6100	B5R	5100	5 1/2" x 8 1/2"																																																				

Maintenance item No.	Description								
U074	<p>Adjusting the DP input light luminosity</p> <p>Description Sets the luminosity correction for scanning originals from the DP.</p> <p>Purpose Modify the setting only if a spotted background appears when a bluish original is scanned from the DP.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="336 535 1398 618"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>INPUT DATA</td> <td>DP input light luminosity correction</td> <td>0 to 3</td> <td>0</td> </tr> </tbody> </table> <p>Settings 0: No correction / 1: Slight correction / 2: Medium correction / 3: Strong correction</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Supplement While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	INPUT DATA	DP input light luminosity correction	0 to 3	0
Display	Description	Setting range	Initial setting						
INPUT DATA	DP input light luminosity correction	0 to 3	0						
U080	<p>Setting the economy mode</p> <p>Description Sets the level in the economy mode.</p> <p>Purpose To increase or decrease the image density in the eco-print mode.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the setting value using the +/- or numeric keys. <table border="1" data-bbox="336 1169 1398 1252"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>ECO MODE</td> <td>Exposure is toner economy mode</td> <td>0 to 100</td> <td>60</td> </tr> </tbody> </table> <p>Increasing the setting makes the image darker; decreasing it makes the image lighter.</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Supplement While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	ECO MODE	Exposure is toner economy mode	0 to 100	60
Display	Description	Setting range	Initial setting						
ECO MODE	Exposure is toner economy mode	0 to 100	60						

Maintenance item No.	Description																						
U081	<p>Adjusting the correct exposure</p> <p>Description Adjusts the correct exposure in text and photo mode, text mode or photo mode.</p> <p>Purpose To be executed as required.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. 3. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="333 535 1398 730"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>MIX ADJ</td> <td>Adjusts the correct exposure in text and photo mode</td> <td>-3 to 3</td> <td>0</td> </tr> <tr> <td>TEXT ADJ</td> <td>Adjusts the correct exposure in text mode</td> <td>-3 to 3</td> <td>0</td> </tr> <tr> <td>PHOTO ADJ</td> <td>Adjusts the correct exposure in photo mode</td> <td>-3 to 3</td> <td>0</td> </tr> </tbody> </table> <p>Increasing the setting makes the image darker; decreasing it makes the image lighter.</p> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Supplement While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	MIX ADJ	Adjusts the correct exposure in text and photo mode	-3 to 3	0	TEXT ADJ	Adjusts the correct exposure in text mode	-3 to 3	0	PHOTO ADJ	Adjusts the correct exposure in photo mode	-3 to 3	0						
Display	Description	Setting range	Initial setting																				
MIX ADJ	Adjusts the correct exposure in text and photo mode	-3 to 3	0																				
TEXT ADJ	Adjusts the correct exposure in text mode	-3 to 3	0																				
PHOTO ADJ	Adjusts the correct exposure in photo mode	-3 to 3	0																				
U087	<p>Setting DP reading position modification operation</p> <p>Description The presence or absence of dust is determined by comparing the scan data of the original trailing edge and that taken after the original is conveyed past the DP original scanning position. If dust is identified, the DP original scanning position is adjusted for the following originals.</p> <p>Purpose When using DP, to solve the problem when black lines occurs due to the dust with respect to original reading position.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. The setting screen for the selected item is displayed. <table border="1" data-bbox="333 1368 1398 1496"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>CCD</td> <td>Setting of standard data when dust is detected</td> </tr> <tr> <td>BLACK LINE</td> <td>Initialization of original reading position</td> </tr> </tbody> </table> <p>Setting: Standard data when dust is detected</p> <ol style="list-style-type: none"> 1. Select the item to be set. 2. Change the value using the +/- or numeric keys. <table border="1" data-bbox="333 1626 1398 1794"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>CCD R</td> <td>Lowest density of the R regard as the dust</td> <td>0 to 255</td> <td>145</td> </tr> <tr> <td>CCD G</td> <td>Lowest density of the G regard as the dust</td> <td>0 to 255</td> <td>145</td> </tr> <tr> <td>CCD B</td> <td>Lowest density of the B regard as the dust</td> <td>0 to 255</td> <td>145</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Setting: Initialization of original reading position</p> <ol style="list-style-type: none"> 1. Select [CLEAR]. 2. Press the start key. The setting is cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	CCD	Setting of standard data when dust is detected	BLACK LINE	Initialization of original reading position	Display	Description	Setting range	Initial setting	CCD R	Lowest density of the R regard as the dust	0 to 255	145	CCD G	Lowest density of the G regard as the dust	0 to 255	145	CCD B	Lowest density of the B regard as the dust	0 to 255	145
Display	Description																						
CCD	Setting of standard data when dust is detected																						
BLACK LINE	Initialization of original reading position																						
Display	Description	Setting range	Initial setting																				
CCD R	Lowest density of the R regard as the dust	0 to 255	145																				
CCD G	Lowest density of the G regard as the dust	0 to 255	145																				
CCD B	Lowest density of the B regard as the dust	0 to 255	145																				

Maintenance item No.	Description															
<p>U089</p>	<p>Outputting a MIP-PG pattern</p> <p>Description Selects and outputs the MIP-PG pattern created in the machine.</p> <p>Purpose To check copier status other than scanner when adjusting image printing, using MIP-PG pattern output (without scanning).</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the MIP-PG pattern to be output and press the start key. <table border="1" data-bbox="331 562 1321 1444"> <thead> <tr> <th data-bbox="338 562 598 600">Display</th> <th data-bbox="598 562 903 600">PG pattern to be output</th> <th data-bbox="903 562 1315 600">Purpose</th> </tr> </thead> <tbody> <tr> <td data-bbox="338 600 598 815">GRAYSCALE</td> <td data-bbox="598 600 903 815">  </td> <td data-bbox="903 600 1315 815">To check the laser scanner unit engine output characteristics</td> </tr> <tr> <td data-bbox="338 815 598 1025">MONO1 (Output density: 0)</td> <td data-bbox="598 815 903 1025">  </td> <td data-bbox="903 815 1315 1025">To check the drum quality</td> </tr> <tr> <td data-bbox="338 1025 598 1236">MONO4 (Output density: 70)</td> <td data-bbox="598 1025 903 1236">  </td> <td data-bbox="903 1025 1315 1236">To check the drum quality</td> </tr> <tr> <td data-bbox="338 1236 598 1444">256-LEVEL</td> <td data-bbox="598 1236 903 1444">  </td> <td data-bbox="903 1236 1315 1444">To check resolution reproducibility in printing</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the system menu key. 4. Press the start key. A MIP-PG pattern is output. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	PG pattern to be output	Purpose	GRAYSCALE		To check the laser scanner unit engine output characteristics	MONO1 (Output density: 0)		To check the drum quality	MONO4 (Output density: 70)		To check the drum quality	256-LEVEL		To check resolution reproducibility in printing
Display	PG pattern to be output	Purpose														
GRAYSCALE		To check the laser scanner unit engine output characteristics														
MONO1 (Output density: 0)		To check the drum quality														
MONO4 (Output density: 70)		To check the drum quality														
256-LEVEL		To check resolution reproducibility in printing														

Maintenance item No.	Description																																																				
U091	<p>Setting the white line correction</p> <p>Description Sets the error detection threshold value for white line correction and displays the count result of abnormal pixels.</p> <p>Purpose To perform when replacing the CIS, DP driver PWB or CIS roller.</p> <p>Method: white line correction</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press [EXECUTE]. 3. Press the start key. Holding of white reference data is started. 4. The count result of abnormal pixels is displayed. <table border="1" data-bbox="335 593 1396 761"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Calculation(R)</td> <td>Abnormal pixel count result for color R</td> </tr> <tr> <td>Calculation(G)</td> <td>Abnormal pixel count result for color G</td> </tr> <tr> <td>Calculation(B)</td> <td>Abnormal pixel count result for color B</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 5. Press the system menu key. 6. Place a gray original on the DP with the gray side down. Load paper in the cassette. The paper should be the same size as the original. 7. Press the start key. Two test pattern sheets will be printed. (1st sheet: blank sheet, 2nd sheet: Approx. 60 mm black band) 8. If no vertical lines appear on either sheet, the setting has been completed normally. If vertical black lines appear on the blank sheet and vertical white lines appear in the black band in the same position, clean the CIS roller and the CIS glass and then repeat white line correction. If vertical black lines or vertical white lines appear on both sheets, white line correction has been completed normally. However, the cause of the vertical lines lies in the engine, and thus the engine must be checked. <p>How to view test copies</p> <table border="1" data-bbox="335 1131 1396 1366"> <thead> <tr> <th>blank sheet</th> <th>black band</th> <th>Causes</th> <th>Corrective measures</th> </tr> </thead> <tbody> <tr> <td>No lines</td> <td>No lines</td> <td>-</td> <td>Complete</td> </tr> <tr> <td>Black lines</td> <td>White lines</td> <td>Dirty CIS roller or CIS glass</td> <td>Clean CIS roller or CIS glass and then perform U091 again</td> </tr> <tr> <td>Black lines</td> <td>No lines</td> <td>Engine side</td> <td>U091 ends, check engine</td> </tr> <tr> <td>No lines</td> <td>White lines</td> <td>Engine side</td> <td>U091 ends, check engine</td> </tr> </tbody> </table> <p>Setting: Threshold value setting</p> <ol style="list-style-type: none"> 1. Select the item to be set. 2. Change the value using the +/- or numeric keys. <table border="1" data-bbox="335 1500 1396 1892"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Threshold(R)</td> <td>Displaying of abnormal pixel detection threshold value for color R</td> <td>-</td> <td>-</td> </tr> <tr> <td>Threshold(G)</td> <td>Displaying of abnormal pixel detection threshold value for color G</td> <td>-</td> <td>-</td> </tr> <tr> <td>Threshold(Com)*</td> <td>Setting of abnormal pixel detection threshold value for color</td> <td>0 to 1023</td> <td>112</td> </tr> <tr> <td>Abnorm Pixel Threshold</td> <td>Abnormal pixel threshold value setting</td> <td>0 to 8191</td> <td>75</td> </tr> <tr> <td>MODE</td> <td>Switching between white line correction mode ON/OFF</td> <td>0: OFF/1: ON/ 2: Test mode</td> <td>0</td> </tr> </tbody> </table> <p>*: Normally the Threshold (Com) value should not be changed from 112, the initial setting. If white lines appear even though the CIS roller and glass are not dirty, raise the set value. If fine lines in some originals disappear, lower the set value. Set within the range 50 to 200. (If set outside this range, the image may be affected.)</p>	Display	Description	Calculation(R)	Abnormal pixel count result for color R	Calculation(G)	Abnormal pixel count result for color G	Calculation(B)	Abnormal pixel count result for color B	blank sheet	black band	Causes	Corrective measures	No lines	No lines	-	Complete	Black lines	White lines	Dirty CIS roller or CIS glass	Clean CIS roller or CIS glass and then perform U091 again	Black lines	No lines	Engine side	U091 ends, check engine	No lines	White lines	Engine side	U091 ends, check engine	Display	Description	Setting range	Initial setting	Threshold(R)	Displaying of abnormal pixel detection threshold value for color R	-	-	Threshold(G)	Displaying of abnormal pixel detection threshold value for color G	-	-	Threshold(Com)*	Setting of abnormal pixel detection threshold value for color	0 to 1023	112	Abnorm Pixel Threshold	Abnormal pixel threshold value setting	0 to 8191	75	MODE	Switching between white line correction mode ON/OFF	0: OFF/1: ON/ 2: Test mode	0
Display	Description																																																				
Calculation(R)	Abnormal pixel count result for color R																																																				
Calculation(G)	Abnormal pixel count result for color G																																																				
Calculation(B)	Abnormal pixel count result for color B																																																				
blank sheet	black band	Causes	Corrective measures																																																		
No lines	No lines	-	Complete																																																		
Black lines	White lines	Dirty CIS roller or CIS glass	Clean CIS roller or CIS glass and then perform U091 again																																																		
Black lines	No lines	Engine side	U091 ends, check engine																																																		
No lines	White lines	Engine side	U091 ends, check engine																																																		
Display	Description	Setting range	Initial setting																																																		
Threshold(R)	Displaying of abnormal pixel detection threshold value for color R	-	-																																																		
Threshold(G)	Displaying of abnormal pixel detection threshold value for color G	-	-																																																		
Threshold(Com)*	Setting of abnormal pixel detection threshold value for color	0 to 1023	112																																																		
Abnorm Pixel Threshold	Abnormal pixel threshold value setting	0 to 8191	75																																																		
MODE	Switching between white line correction mode ON/OFF	0: OFF/1: ON/ 2: Test mode	0																																																		

Maintenance item No.	Description																								
U091	3. Press the start key. The value is set. 4. After changing the Threshold(Com) value, turn the main power switch off and on. Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.																								
U093	<p>Setting the exposure density gradient</p> <p>Description Changes the exposure density gradient in the manual density mode, depending on respective image quality modes.</p> <p>Purpose To set how the image density is altered by a change of one step in the manual density adjustment for respective image quality modes. Also used to make copy images darker or lighter.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the image quality mode. The setting screen for the selected item is displayed. <table border="1" data-bbox="331 757 1398 1005"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>TEXT</td> <td>Density in the text mode</td> </tr> <tr> <td>MIXED</td> <td>Density in the text and photo mode</td> </tr> <tr> <td>OTHER</td> <td>Density in modes other than the text mode or the text and photo mode</td> </tr> <tr> <td>FAX TEXT</td> <td>Density in the text in fax mode</td> </tr> <tr> <td>FAX PHOTO</td> <td>Density in the photo in fax mode</td> </tr> </tbody> </table> <p>Setting: [TEXT]</p> <ol style="list-style-type: none"> 1. Select the item to be set. 2. Adjust the setting using the +/- or numeric keys. <table border="1" data-bbox="331 1137 1398 1292"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>TEXT DARKER</td> <td>Change in density when manual density is set dark</td> <td>0 to 3</td> <td>0</td> </tr> <tr> <td>TEXT LIGHTER</td> <td>Change in density when manual density is set light</td> <td>0 to 3</td> <td>0</td> </tr> </tbody> </table> <p>Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.</p>  <p>Figure 1-3-17</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. 	Display	Description	TEXT	Density in the text mode	MIXED	Density in the text and photo mode	OTHER	Density in modes other than the text mode or the text and photo mode	FAX TEXT	Density in the text in fax mode	FAX PHOTO	Density in the photo in fax mode	Display	Description	Setting range	Initial setting	TEXT DARKER	Change in density when manual density is set dark	0 to 3	0	TEXT LIGHTER	Change in density when manual density is set light	0 to 3	0
Display	Description																								
TEXT	Density in the text mode																								
MIXED	Density in the text and photo mode																								
OTHER	Density in modes other than the text mode or the text and photo mode																								
FAX TEXT	Density in the text in fax mode																								
FAX PHOTO	Density in the photo in fax mode																								
Display	Description	Setting range	Initial setting																						
TEXT DARKER	Change in density when manual density is set dark	0 to 3	0																						
TEXT LIGHTER	Change in density when manual density is set light	0 to 3	0																						

Maintenance item No.	Description																																																
U093	<p>Setting: [MIXED]</p> <ol style="list-style-type: none"> Select the item to be set. Adjust the setting using the +/- or numeric keys. <table border="1" data-bbox="335 358 1396 515"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>MIXED DARKER</td> <td>Change in density when manual density is set dark</td> <td>0 to 3</td> <td>0</td> </tr> <tr> <td>MIXED LIGHTER</td> <td>Change in density when manual density is set light</td> <td>0 to 3</td> <td>0</td> </tr> </tbody> </table> <p>Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.</p> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Setting: [OTHER]</p> <ol style="list-style-type: none"> Select the item to be set. Adjust the setting using the +/- or numeric keys. <table border="1" data-bbox="335 705 1396 862"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>OTHER DARKER</td> <td>Change in density when manual density is set dark</td> <td>0 to 3</td> <td>0</td> </tr> <tr> <td>OTHER LIGTER</td> <td>Change in density when manual density is set light</td> <td>0 to 3</td> <td>0</td> </tr> </tbody> </table> <p>Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.</p> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Setting: [FAX TEXT]</p> <ol style="list-style-type: none"> Select the item to be set. Adjust the setting using the +/- or numeric keys. <table border="1" data-bbox="335 1052 1396 1265"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>FAX TEXT DARKER</td> <td>Change in density when manual density is set dark</td> <td>0 to 3</td> <td>0</td> </tr> <tr> <td>FAX TEXT LIGHTER</td> <td>Change in density when manual density is set light</td> <td>0 to 3</td> <td>0</td> </tr> </tbody> </table> <p>Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.</p> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Setting: [FAX PHOTO]</p> <ol style="list-style-type: none"> Select the item to be set. Adjust the setting using the +/- or numeric keys. <table border="1" data-bbox="335 1456 1396 1668"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>FAX PHOTO DARKER</td> <td>Change in density when manual density is set dark</td> <td>0 to 3</td> <td>0</td> </tr> <tr> <td>FAX PHOTO LIGHTER</td> <td>Change in density when manual density is set light</td> <td>0 to 3</td> <td>0</td> </tr> </tbody> </table> <p>Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.</p> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Supplement While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	MIXED DARKER	Change in density when manual density is set dark	0 to 3	0	MIXED LIGHTER	Change in density when manual density is set light	0 to 3	0	Display	Description	Setting range	Initial setting	OTHER DARKER	Change in density when manual density is set dark	0 to 3	0	OTHER LIGTER	Change in density when manual density is set light	0 to 3	0	Display	Description	Setting range	Initial setting	FAX TEXT DARKER	Change in density when manual density is set dark	0 to 3	0	FAX TEXT LIGHTER	Change in density when manual density is set light	0 to 3	0	Display	Description	Setting range	Initial setting	FAX PHOTO DARKER	Change in density when manual density is set dark	0 to 3	0	FAX PHOTO LIGHTER	Change in density when manual density is set light	0 to 3	0
Display	Description	Setting range	Initial setting																																														
MIXED DARKER	Change in density when manual density is set dark	0 to 3	0																																														
MIXED LIGHTER	Change in density when manual density is set light	0 to 3	0																																														
Display	Description	Setting range	Initial setting																																														
OTHER DARKER	Change in density when manual density is set dark	0 to 3	0																																														
OTHER LIGTER	Change in density when manual density is set light	0 to 3	0																																														
Display	Description	Setting range	Initial setting																																														
FAX TEXT DARKER	Change in density when manual density is set dark	0 to 3	0																																														
FAX TEXT LIGHTER	Change in density when manual density is set light	0 to 3	0																																														
Display	Description	Setting range	Initial setting																																														
FAX PHOTO DARKER	Change in density when manual density is set dark	0 to 3	0																																														
FAX PHOTO LIGHTER	Change in density when manual density is set light	0 to 3	0																																														

Maintenance item No.	Description																																																														
U099	<p>Adjusting original size detection</p> <p>Description Checks the operation of the original size sensor and sets the sensing threshold value.</p> <p>Purpose To adjust the sensitiveness of the sensor and size judgement time if the original size sensor malfunctions frequently due to incident light or the like.</p> <p>Method</p> <ol style="list-style-type: none"> Press the start key. Select the item. The screen for executing each item is displayed. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> </tr> </thead> <tbody> <tr> <td>DATA1</td> <td>Displaying original size sensor transmission data</td> </tr> <tr> <td>B/W LEVEL1</td> <td>B/W LEVEL setting original size sensor threshold value Setting original size judgment time</td> </tr> <tr> <td>DATA2</td> <td>Displaying original size sensor transmission data (when DP is installed)</td> </tr> </tbody> </table> <p>Method: Display the data for the sensor</p> <ol style="list-style-type: none"> Place the original and close the original cover or DP. The detection sensor transmission data is displayed. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> </tr> </thead> <tbody> <tr> <td>ORIGINAL AREA R</td> <td>Detected original width size (R)</td> </tr> <tr> <td>ORIGINAL AREA G</td> <td>Detected original width size (G)</td> </tr> <tr> <td>ORIGINAL AREA B</td> <td>Detected original width size (B)</td> </tr> <tr> <td>ORIGINAL AREA</td> <td>Detected original width size</td> </tr> <tr> <td>SIZE SW L</td> <td>Displays the original size sensor (OSS) ON/OFF</td> </tr> </tbody> </table> <ol style="list-style-type: none"> To return to the screen for selecting an item, press the stop key. <p>Setting: Detection sensor threshold value</p> <ol style="list-style-type: none"> Select an item to be set. Adjust the setting using the +/- or numeric keys. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="text-align: left;">Display</th> <th rowspan="2" style="text-align: left;">Description</th> <th rowspan="2" style="text-align: left;">Setting range</th> <th colspan="2" style="text-align: center;">Initial setting</th> </tr> <tr> <th style="text-align: center;">DP not installed</th> <th style="text-align: center;">DP installed</th> </tr> </thead> <tbody> <tr> <td>ORIGINAL R1 - 3</td> <td>Original threshold value for color R</td> <td>0 to 255</td> <td style="text-align: center;">40/30/20</td> <td style="text-align: center;">50/50/50</td> </tr> <tr> <td>ORIGINAL G1 - 3</td> <td>Original threshold value for color G</td> <td>0 to 255</td> <td style="text-align: center;">40/30/20</td> <td style="text-align: center;">50/50/50</td> </tr> <tr> <td>ORIGINAL B1 - 3</td> <td>Original threshold value for color B</td> <td>0 to 255</td> <td style="text-align: center;">40/30/20</td> <td style="text-align: center;">50/50/50</td> </tr> <tr> <td>LIGHT SOURCE R</td> <td>Light source threshold value for color R</td> <td>0 to 255</td> <td style="text-align: center;">19</td> <td style="text-align: center;">49</td> </tr> <tr> <td>LIGHT SOURCE G</td> <td>Light source threshold value for color G</td> <td>0 to 255</td> <td style="text-align: center;">19</td> <td style="text-align: center;">49</td> </tr> <tr> <td>LIGHT SOURCE B</td> <td>Light source threshold value for color B</td> <td>0 to 255</td> <td style="text-align: center;">19</td> <td style="text-align: center;">49</td> </tr> <tr> <td>WAIT TIME</td> <td>Time from activation of the original detection switch (ODSW) to original size judgment</td> <td>0 to 255</td> <td style="text-align: center;">150</td> <td style="text-align: center;">150</td> </tr> </tbody> </table> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	DATA1	Displaying original size sensor transmission data	B/W LEVEL1	B/W LEVEL setting original size sensor threshold value Setting original size judgment time	DATA2	Displaying original size sensor transmission data (when DP is installed)	Display	Description	ORIGINAL AREA R	Detected original width size (R)	ORIGINAL AREA G	Detected original width size (G)	ORIGINAL AREA B	Detected original width size (B)	ORIGINAL AREA	Detected original width size	SIZE SW L	Displays the original size sensor (OSS) ON/OFF	Display	Description	Setting range	Initial setting		DP not installed	DP installed	ORIGINAL R1 - 3	Original threshold value for color R	0 to 255	40/30/20	50/50/50	ORIGINAL G1 - 3	Original threshold value for color G	0 to 255	40/30/20	50/50/50	ORIGINAL B1 - 3	Original threshold value for color B	0 to 255	40/30/20	50/50/50	LIGHT SOURCE R	Light source threshold value for color R	0 to 255	19	49	LIGHT SOURCE G	Light source threshold value for color G	0 to 255	19	49	LIGHT SOURCE B	Light source threshold value for color B	0 to 255	19	49	WAIT TIME	Time from activation of the original detection switch (ODSW) to original size judgment	0 to 255	150	150
Display	Description																																																														
DATA1	Displaying original size sensor transmission data																																																														
B/W LEVEL1	B/W LEVEL setting original size sensor threshold value Setting original size judgment time																																																														
DATA2	Displaying original size sensor transmission data (when DP is installed)																																																														
Display	Description																																																														
ORIGINAL AREA R	Detected original width size (R)																																																														
ORIGINAL AREA G	Detected original width size (G)																																																														
ORIGINAL AREA B	Detected original width size (B)																																																														
ORIGINAL AREA	Detected original width size																																																														
SIZE SW L	Displays the original size sensor (OSS) ON/OFF																																																														
Display	Description	Setting range	Initial setting																																																												
			DP not installed	DP installed																																																											
ORIGINAL R1 - 3	Original threshold value for color R	0 to 255	40/30/20	50/50/50																																																											
ORIGINAL G1 - 3	Original threshold value for color G	0 to 255	40/30/20	50/50/50																																																											
ORIGINAL B1 - 3	Original threshold value for color B	0 to 255	40/30/20	50/50/50																																																											
LIGHT SOURCE R	Light source threshold value for color R	0 to 255	19	49																																																											
LIGHT SOURCE G	Light source threshold value for color G	0 to 255	19	49																																																											
LIGHT SOURCE B	Light source threshold value for color B	0 to 255	19	49																																																											
WAIT TIME	Time from activation of the original detection switch (ODSW) to original size judgment	0 to 255	150	150																																																											

Maintenance item No.	Description																								
U100	<p>Setting the main high voltage</p> <p>Description Performs main charging.</p> <p>Purpose To check main charging.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be operated. 3. Press the start key. The selected operation starts. <table border="1" data-bbox="335 564 1398 689"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>MC</td> <td>Turning the main charger on</td> </tr> <tr> <td>LASER</td> <td>Turning the main charger on and the laser scanner unit on and off</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. To stop operation, press the stop key. <p>Completion Press the stop key when main charger output stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MC	Turning the main charger on	LASER	Turning the main charger on and the laser scanner unit on and off																		
Display	Description																								
MC	Turning the main charger on																								
LASER	Turning the main charger on and the laser scanner unit on and off																								
U101	<p>Setting the other high voltages</p> <p>Description Sets the developing bias control voltage, the transfer control voltage, and the separation control voltage or checks the output of these voltages.</p> <p>Purpose To check the developing bias, the transfer voltage and the separation voltage or to take measures against drop of image density or background fog.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. 3. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="335 1220 1398 1561"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>DEV BIAS</td> <td>Developing bias AC component frequency at image formation</td> <td>20 to 32</td> <td>28</td> </tr> <tr> <td>DEV SBIAS</td> <td>Developing shift bias potential at image formation</td> <td>0 to 3</td> <td>1</td> </tr> <tr> <td>DEV DUTY</td> <td>Developing bias AC component duty at image formation</td> <td>0 to 100</td> <td>50</td> </tr> <tr> <td>TC DATA</td> <td>Transfer control voltage</td> <td>0 to 300</td> <td>130</td> </tr> <tr> <td>SC DATA</td> <td>Separation control voltage</td> <td>0 to 60</td> <td>20</td> </tr> </tbody> </table> <p>Increasing the DEV BIAS setting makes the image darker; decreasing it makes the image lighter. Increasing the DEV SBIAS setting makes the image darker. Increasing the DEV DUTY setting makes the image lighter; decreasing it makes the image darker. Increasing the TC DATA setting makes the transfer voltage higher, and decreasing it makes the voltage lower. Increasing the SC DATA setting makes the separation voltage higher, and decreasing it makes the voltage lower.</p> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	DEV BIAS	Developing bias AC component frequency at image formation	20 to 32	28	DEV SBIAS	Developing shift bias potential at image formation	0 to 3	1	DEV DUTY	Developing bias AC component duty at image formation	0 to 100	50	TC DATA	Transfer control voltage	0 to 300	130	SC DATA	Separation control voltage	0 to 60	20
Display	Description	Setting range	Initial setting																						
DEV BIAS	Developing bias AC component frequency at image formation	20 to 32	28																						
DEV SBIAS	Developing shift bias potential at image formation	0 to 3	1																						
DEV DUTY	Developing bias AC component duty at image formation	0 to 100	50																						
TC DATA	Transfer control voltage	0 to 300	130																						
SC DATA	Separation control voltage	0 to 60	20																						

Maintenance item No.	Description								
U102	<p>Setting the cleaning interval for the main charger</p> <p>Description Changes the intervals at which the main charger is cleaned.</p> <p>Purpose To change the setting when the background is visible.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="333 535 1398 647"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>IINTERVAL</td> <td>Main charger cleaning operation intervals</td> <td>0 to 20 (unit: 1000 sheets)</td> <td>5</td> </tr> </tbody> </table> <p>When set to 0, the cleaning for the main charger is not operated.</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	IINTERVAL	Main charger cleaning operation intervals	0 to 20 (unit: 1000 sheets)	5
Display	Description	Setting range	Initial setting						
IINTERVAL	Main charger cleaning operation intervals	0 to 20 (unit: 1000 sheets)	5						
U109	<p>Displaying the drum type</p> <p>Description Displays the drum surface potential set as EEPROM of the drum unit.</p> <p>Purpose To check the drum surface potential.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. Drum surface potential (V) is displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>								
U110	<p>Checking the drum count</p> <p>Description Displays the drum counts for checking.</p> <p>Purpose To check the drum status.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The drum counter count is displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>								
U111	<p>Checking the drum drive time</p> <p>Description Displays the drum drive time for checking a figure, which is used as a reference when correcting the high voltage based on time.</p> <p>Purpose To check the drum status.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The drum drive time is displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>								

Maintenance item No.	Description																		
U112	<p>Setting toner refresh operation</p> <p>Description Sets the toner refresh operation time and the developing bias on time at power on and after copying.</p> <p>Purpose To change the toner refresh operation time and the developing bias on time at power on and after copying if image flow level is low.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. 3. Change the setting using the +/- keys. <table border="1" data-bbox="333 593 1396 719"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>ON TIME(SEC)</td> <td>Toner refresh operation time</td> <td>50 to 150 (sec)</td> <td>120</td> </tr> <tr> <td>BIAS TIME(MSEC)</td> <td>Developing bias on time</td> <td>500 to 1000 (msec)</td> <td>540</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	ON TIME(SEC)	Toner refresh operation time	50 to 150 (sec)	120	BIAS TIME(MSEC)	Developing bias on time	500 to 1000 (msec)	540						
Display	Description	Setting range	Initial setting																
ON TIME(SEC)	Toner refresh operation time	50 to 150 (sec)	120																
BIAS TIME(MSEC)	Developing bias on time	500 to 1000 (msec)	540																
U114	<p>Setting separation charger mode</p> <p>Description Sets the separation charger mode.</p> <p>Purpose To change the setting if the fuser offset or carrier leaking occurs.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="333 1126 1396 1209"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>MODE</td> <td>Separation charger mode</td> <td>0 to 8 (0 to 3)*</td> <td>3</td> </tr> </tbody> </table> <p>*: Entering a value other than 0 to 3 will engage the MODE3 (value 3) separation mode.</p> <p>Details on the modes</p> <table border="1" data-bbox="333 1321 1396 1720"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>MODE0 (Value 0)</td> <td>Full page separation for both first and second pages</td> </tr> <tr> <td>MODE1 (Value 1)</td> <td>First page: Separation on leading and trailing edges Second page: Full page separation</td> </tr> <tr> <td>MODE2 (Value 2)</td> <td>Full page separation is activated for both first and second pages provided the ambient temperature is less than 19°C/66.2°F. First page: Separation is activated for both leading and trailing edges, second page: Full page separation, provided the ambient temperature is more than 20°C/68°F.</td> </tr> <tr> <td>MODE3 (Value 3)</td> <td>Separation is activated on both leading and trailing edges for both first and second pages</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	MODE	Separation charger mode	0 to 8 (0 to 3)*	3	Display	Description	MODE0 (Value 0)	Full page separation for both first and second pages	MODE1 (Value 1)	First page: Separation on leading and trailing edges Second page: Full page separation	MODE2 (Value 2)	Full page separation is activated for both first and second pages provided the ambient temperature is less than 19°C/66.2°F. First page: Separation is activated for both leading and trailing edges, second page: Full page separation, provided the ambient temperature is more than 20°C/68°F.	MODE3 (Value 3)	Separation is activated on both leading and trailing edges for both first and second pages
Display	Description	Setting range	Initial setting																
MODE	Separation charger mode	0 to 8 (0 to 3)*	3																
Display	Description																		
MODE0 (Value 0)	Full page separation for both first and second pages																		
MODE1 (Value 1)	First page: Separation on leading and trailing edges Second page: Full page separation																		
MODE2 (Value 2)	Full page separation is activated for both first and second pages provided the ambient temperature is less than 19°C/66.2°F. First page: Separation is activated for both leading and trailing edges, second page: Full page separation, provided the ambient temperature is more than 20°C/68°F.																		
MODE3 (Value 3)	Separation is activated on both leading and trailing edges for both first and second pages																		

Maintenance item No.	Description						
<p>U117</p>	<p>Checking the drum number Description Displays the drum number. Purpose To check the drum number. Method 1. Press the start key. The drum number is displayed. Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>						
<p>U118</p>	<p>Displaying the drum history Description Displays the past record of machine number and the drum counter. Purpose To check the count value of machine number and the drum counter. Method 1. Press the start key. Past record of 5 cases is displayed.</p> <table border="1" data-bbox="333 837 1398 965"> <thead> <tr> <th data-bbox="336 842 636 880">Display</th> <th data-bbox="636 842 1394 880">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 880 636 918">MACHINE No.1 to 5</td> <td data-bbox="636 880 1394 918">Past record of machine number</td> </tr> <tr> <td data-bbox="336 918 636 956">COUNT 1 to 5</td> <td data-bbox="636 918 1394 956">Past record of drum counter</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MACHINE No.1 to 5	Past record of machine number	COUNT 1 to 5	Past record of drum counter
Display	Description						
MACHINE No.1 to 5	Past record of machine number						
COUNT 1 to 5	Past record of drum counter						
<p>U127</p>	<p>Checking the transfer count Description Displays and clears the counts of the transfer counter. Purpose To check the fuser count after replacement of the transfer roller. Also to clear the counts after replacing roller. Method 1. Press the start key. The current counts of the transfer counter is displayed. Clearing 1. Select [CLEAR]. 2. Press the start key. The count is cleared. Setting 1. Change the count using the +/- or numeric keys. 2. Press the start key. The count is set. Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>						

Maintenance item No.	Description								
U130	<p>Initial setting for the developing unit</p> <p>Description Replenishes toner to the developing unit to a certain level from the toner container that has been installed.</p> <p>Purpose To operate when installing the machine or replacing the developing unit.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Press the start key. Toner installation is started and the output value of the sensor and execution time are displayed. <table border="1" data-bbox="331 562 1398 689"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>TONER SENSOR</td> <td>Output value of the sensor</td> </tr> <tr> <td>TIME(SEC)</td> <td>Execution time</td> </tr> </tbody> </table> <p>Completion Press the stop key after initial setting is complete. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	TONER SENSOR	Output value of the sensor	TIME(SEC)	Execution time		
Display	Description								
TONER SENSOR	Output value of the sensor								
TIME(SEC)	Execution time								
U136	<p>Setting toner near end mode</p> <p>Description Sets whether to restrict printing operation when the toner is empty.</p> <p>Purpose To set to ON to remove restrictions on printing operation when toner empty is detected.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [ON] or [OFF]. <table border="1" data-bbox="331 1095 1398 1223"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Do not display an error or restrict printing operation when the toner is empty</td> </tr> <tr> <td>OFF</td> <td>Display an error and restrict printing operation when the toner is empty</td> </tr> </tbody> </table> <p>Initial setting: OFF</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Do not display an error or restrict printing operation when the toner is empty	OFF	Display an error and restrict printing operation when the toner is empty		
Display	Description								
ON	Do not display an error or restrict printing operation when the toner is empty								
OFF	Display an error and restrict printing operation when the toner is empty								
U139	<p>Displaying the temperature and humidity</p> <p>Description Displays the detected external temperature and humidity.</p> <p>Purpose To check the external temperature and humidity.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The detected external temperature (°C/°F) and humidity (%) are displayed. <table border="1" data-bbox="331 1664 1410 1832"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Temperature</td> <td>External temperature (°C/°F)</td> </tr> <tr> <td>Humidity</td> <td>External humidity (%)</td> </tr> <tr> <td>Absolute Humidity</td> <td>External absolute humidity (%)</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Temperature	External temperature (°C/°F)	Humidity	External humidity (%)	Absolute Humidity	External absolute humidity (%)
Display	Description								
Temperature	External temperature (°C/°F)								
Humidity	External humidity (%)								
Absolute Humidity	External absolute humidity (%)								

Maintenance item No.	Description														
<p>U144</p>	<p>Setting toner disposal operation</p> <p>Description Sets toner disposal operation after completion of copying.</p> <p>Purpose To set whether or not toner is disposal on the drum after low density copying. Normally no change is necessary from the initial setting.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="333 564 1398 875"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>MODE0</td> <td>Toner not disposal</td> </tr> <tr> <td>MODE1</td> <td>Toner disposal after simplex or duplex copying</td> </tr> <tr> <td>MODE2</td> <td>Toner disposal after simplex copying</td> </tr> <tr> <td>MODE3</td> <td>Executes toner disposal every after 52 pages of printing (simplex and duplex copying)</td> </tr> <tr> <td>MODE4</td> <td>Executes toner disposal every after 52 pages of printing (simplex only)</td> </tr> </tbody> </table> <p>Initial setting: MODE2</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MODE0	Toner not disposal	MODE1	Toner disposal after simplex or duplex copying	MODE2	Toner disposal after simplex copying	MODE3	Executes toner disposal every after 52 pages of printing (simplex and duplex copying)	MODE4	Executes toner disposal every after 52 pages of printing (simplex only)		
Display	Description														
MODE0	Toner not disposal														
MODE1	Toner disposal after simplex or duplex copying														
MODE2	Toner disposal after simplex copying														
MODE3	Executes toner disposal every after 52 pages of printing (simplex and duplex copying)														
MODE4	Executes toner disposal every after 52 pages of printing (simplex only)														
<p>U155</p>	<p>Checking sensors for toner</p> <p>Description Displays the on-off status of each sensor or switch related to toner.</p> <p>Purpose To check if the sensors and switches operate correctly.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Turn each switch on and off manually to check the status. When the on-status of a switch is detected, that switch is displayed in reverse. <table border="1" data-bbox="333 1339 1398 1659"> <thead> <tr> <th>Display</th> <th>Switches and sensors</th> </tr> </thead> <tbody> <tr> <td>DEVELOPER SENSOR</td> <td>Toner sensor (TNS)</td> </tr> <tr> <td>CONTAINER SET</td> <td>Toner container detection switch (TCDSW)</td> </tr> <tr> <td>CONTAINER SENSOR</td> <td>Toner container sensor (TCS)</td> </tr> <tr> <td>DISPOSAL TANK SET</td> <td>Waste toner detection switch (WTDSW)</td> </tr> <tr> <td>DISPOSAL TANK SENSOR</td> <td>Overflow sensor (OFS)</td> </tr> <tr> <td>MOTOR</td> <td>The toner feed solenoid (TNFSOL) and the paper feed motor (PFM) are turned on</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. To stop motor driving, press [MOTOR ON] again. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Switches and sensors	DEVELOPER SENSOR	Toner sensor (TNS)	CONTAINER SET	Toner container detection switch (TCDSW)	CONTAINER SENSOR	Toner container sensor (TCS)	DISPOSAL TANK SET	Waste toner detection switch (WTDSW)	DISPOSAL TANK SENSOR	Overflow sensor (OFS)	MOTOR	The toner feed solenoid (TNFSOL) and the paper feed motor (PFM) are turned on
Display	Switches and sensors														
DEVELOPER SENSOR	Toner sensor (TNS)														
CONTAINER SET	Toner container detection switch (TCDSW)														
CONTAINER SENSOR	Toner container sensor (TCS)														
DISPOSAL TANK SET	Waste toner detection switch (WTDSW)														
DISPOSAL TANK SENSOR	Overflow sensor (OFS)														
MOTOR	The toner feed solenoid (TNFSOL) and the paper feed motor (PFM) are turned on														

Maintenance item No.	Description																										
U157	<p>Checking the developing drive time</p> <p>Description Displays the developing drive time for checking, which is used as a reference when correcting the toner control.</p> <p>Purpose To check the developing drive time after replacing the developing unit.</p> <p>Method 1. Press the start key. The developing drive time is displayed in minutes.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>																										
U158	<p>Checking the developing count</p> <p>Description Displays the developing count for checking.</p> <p>Purpose To check the developing count after replacing the developing unit.</p> <p>Method 1. Press the start key. The developing counter count is displayed.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>																										
U161	<p>Setting the fuser control temperature</p> <p>Description Changes the fuser control temperature.</p> <p>Purpose Normally no change is necessary. However, can be used to prevent curling or creasing of paper, or solve a fuser problem on thick paper. MODE changes printing speed control at over-heating on the fuser ends.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. 3. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="331 1285 1398 1579"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>DRIVE START TEMP</td> <td>Driving start temperature when warm-up starts</td> <td>0 to 255 (°C)</td> <td>185</td> </tr> <tr> <td>READY CONTROL T</td> <td>Control temperature for displaying [Ready for printing.]</td> <td>0 to 255 (°C)</td> <td>200</td> </tr> <tr> <td>PRINT CONTROL T</td> <td>Control temperature during printing</td> <td>0 to 255 (°C)</td> <td>200</td> </tr> <tr> <td>MODE</td> <td>Printing speed control at over-heating on the fuser ends</td> <td>1/2</td> <td>1</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Setting: [MODE]</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the mode. <table border="1" data-bbox="331 1738 1398 1924"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>MODE1</td> <td>Printing halts for approximately 24 s provided the temperature on the fuser ends reaches 235°C/455°F before printing is resumed</td> </tr> <tr> <td>MODE2</td> <td>Printing speed is decelerated by 75% with a fuser-end temperature greater than 228°C/442°F</td> </tr> </tbody> </table> <p>Initial setting: MODE1</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. 	Display	Description	Setting range	Initial setting	DRIVE START TEMP	Driving start temperature when warm-up starts	0 to 255 (°C)	185	READY CONTROL T	Control temperature for displaying [Ready for printing.]	0 to 255 (°C)	200	PRINT CONTROL T	Control temperature during printing	0 to 255 (°C)	200	MODE	Printing speed control at over-heating on the fuser ends	1/2	1	Display	Description	MODE1	Printing halts for approximately 24 s provided the temperature on the fuser ends reaches 235°C/455°F before printing is resumed	MODE2	Printing speed is decelerated by 75% with a fuser-end temperature greater than 228°C/442°F
Display	Description	Setting range	Initial setting																								
DRIVE START TEMP	Driving start temperature when warm-up starts	0 to 255 (°C)	185																								
READY CONTROL T	Control temperature for displaying [Ready for printing.]	0 to 255 (°C)	200																								
PRINT CONTROL T	Control temperature during printing	0 to 255 (°C)	200																								
MODE	Printing speed control at over-heating on the fuser ends	1/2	1																								
Display	Description																										
MODE1	Printing halts for approximately 24 s provided the temperature on the fuser ends reaches 235°C/455°F before printing is resumed																										
MODE2	Printing speed is decelerated by 75% with a fuser-end temperature greater than 228°C/442°F																										

Maintenance item No.	Description						
<p>U161</p>	<p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>						
<p>U163</p>	<p>Resetting the fuser problem data Description Resets the detection of a service call code indicating a problem in the fuser section. Purpose To prevent accidents due to an abnormally high fuser temperature. Method <ol style="list-style-type: none"> 1. Press the start key. 2. Press [EXECUTE] on the touch panel. 3. Press the start key. The fuser problem data is initialized. 4. Turn the main power switch off and on. </p>						
<p>U167</p>	<p>Checking/clearing the fuser counts Description Displays and clears the fuser counts for checking. Purpose To check the fuser count after replacement of the fuser unit. Also to clear the counts after replacing unit. Method <ol style="list-style-type: none"> 1. Press the start key. The fuser counts is displayed. Clearing <ol style="list-style-type: none"> 1. Select [CLEAR]. 2. Press the start key. The count is cleared. Setting <ol style="list-style-type: none"> 1. Change the count using the +/- or numeric keys. 2. Press the start key. The count is set. Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>						
<p>U196</p>	<p>Turning the fuser heater on Description Turns the fuser heater 1 or 2 on. Purpose To check fuser heaters turning on. Method <ol style="list-style-type: none"> 1. Press the start key. 2. Select the heater to be turned on. 3. Press the start key. The selected heater turns on for 2 s and then turns off. <table border="1" data-bbox="333 1592 1398 1718"> <thead> <tr> <th data-bbox="338 1599 636 1632">Display</th> <th data-bbox="636 1599 1393 1632">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="338 1632 636 1666">MAIN</td> <td data-bbox="636 1632 1393 1666">Fuser heater 1 (FH1)</td> </tr> <tr> <td data-bbox="338 1666 636 1718">SUB</td> <td data-bbox="636 1666 1393 1718">Fuser heater 2 (FH2)</td> </tr> </tbody> </table> Completion Press the stop key when fuser heaters 1 and 2 are off. The screen for selecting the maintenance item No. is displayed.</p>	Display	Description	MAIN	Fuser heater 1 (FH1)	SUB	Fuser heater 2 (FH2)
Display	Description						
MAIN	Fuser heater 1 (FH1)						
SUB	Fuser heater 2 (FH2)						

Maintenance item No.	Description										
U198	<p>Setting the fuser phase control</p> <p>Description Enables or disables fuser-phase control.</p> <p>Purpose Turn to OFF to reduce the audible sound that may be generated by the power source PWB. Depending on the environment of installation, this may cause a voltage drop, potentially resulting in flickering fluorescent tubes, etc.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1" data-bbox="333 593 1398 719"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Fuser phase control present</td> </tr> <tr> <td>OFF</td> <td>Fuser phase control absent</td> </tr> </tbody> </table> <p>Initial setting: ON</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Fuser phase control present	OFF	Fuser phase control absent				
Display	Description										
ON	Fuser phase control present										
OFF	Fuser phase control absent										
U199	<p>Checking the fuser temperature</p> <p>Description Displays the fuser temperature, the external temperature and the absolute humidity.</p> <p>Purpose To check the fuser temperature, the external temperature and the absolute humidity.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The fuser temperature (°C/°F), external temperature (°C/°F) and the absolute humidity (%) are displayed. <table border="1" data-bbox="333 1153 1398 1361"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>FIX CENTER TEMP</td> <td>Fuser center temperature (°C/°F)</td> </tr> <tr> <td>FIX EDGE TEMP</td> <td>Fuser edge temperature (°C/°F)</td> </tr> <tr> <td>SURROUND TEMP</td> <td>External temperature (°C/°F)</td> </tr> <tr> <td>HUMIDITY</td> <td>Absolute humidity (%)</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	FIX CENTER TEMP	Fuser center temperature (°C/°F)	FIX EDGE TEMP	Fuser edge temperature (°C/°F)	SURROUND TEMP	External temperature (°C/°F)	HUMIDITY	Absolute humidity (%)
Display	Description										
FIX CENTER TEMP	Fuser center temperature (°C/°F)										
FIX EDGE TEMP	Fuser edge temperature (°C/°F)										
SURROUND TEMP	External temperature (°C/°F)										
HUMIDITY	Absolute humidity (%)										
U200	<p>Turning all LEDs on</p> <p>Description Turns all the LEDs on the operation panel on.</p> <p>Purpose To check if all the LEDs on the operation panel light.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. All the LEDs on the operation panel light. 2. Press the stop key. The LEDs turns off. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>										

Maintenance item No.	Description						
<p>U201</p>	<p>Initializing the touch panel</p> <p>Description Automatically correct the positions of the X- and Y-axes of the touch panel.</p> <p>Purpose To automatically correct the display positions on the touch panel after it is replaced.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the [INITIALIZE] or [CHECK]. <table border="1" data-bbox="333 533 1398 660"> <thead> <tr> <th data-bbox="336 533 636 577">Display</th> <th data-bbox="636 533 1394 577">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 577 636 611">INITIALIZE</td> <td data-bbox="636 577 1394 611">Adjusts the display on the panel automatically.</td> </tr> <tr> <td data-bbox="336 611 636 656">CHECK</td> <td data-bbox="636 611 1394 656">Checks the display on the touch panel.</td> </tr> </tbody> </table> <p>Method: [INITIALIZE]</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press the center of the + keys. Be sure to press three + keys displayed in order. The touch panel is adjusted automatically. 3. Press the indicated three + keys, and then check the display. 4. Press the stop key. The screen for selecting a maintenance item No. is displayed. <p>Method: [CHECK]</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press the indicated three + keys, and then check the display. When adjusting the display, press [INITIALIZE] to execute the adjustment automatically. 3. Press the stop key. The screen for selecting a maintenance item No. is displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	INITIALIZE	Adjusts the display on the panel automatically.	CHECK	Checks the display on the touch panel.
Display	Description						
INITIALIZE	Adjusts the display on the panel automatically.						
CHECK	Checks the display on the touch panel.						
<p>U202</p>	<p>Setting the KMAS host monitoring system</p> <p>Description Initializes or operates the KMAS host monitoring system. This is an optional device which is currently supported only by Japanese specification machines, so no setting is necessary.</p>						

Maintenance item No.	Description																																
U203	<p>Checking DP operation</p> <p>Description Simulates the original conveying operation separately in the DP.</p> <p>Purpose To check the DP operation.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Place an original in the DP if running this simulation with paper. 3. Select the item to be operated. <table border="1" data-bbox="331 562 1398 1014"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>CCD ADP (NON P)</td> <td>Without paper, single-sided original of CCD (continuous operation)</td> <td>-</td> <td>-</td> </tr> <tr> <td>CCD ADP</td> <td>With paper, single-sided original of CCD</td> <td>-</td> <td>-</td> </tr> <tr> <td>CCD RADP (NON P)</td> <td>Without paper, double-sided original of CCD (continuous operation)</td> <td>-</td> <td>-</td> </tr> <tr> <td>CCD RADP</td> <td>With paper, double-sided original of CCD</td> <td>-</td> <td>-</td> </tr> <tr> <td>CIS RADP (NON P)*</td> <td>Without paper, double-sided original of CIS (continuous operation)</td> <td>-</td> <td>-</td> </tr> <tr> <td>CIS RADP*</td> <td>With paper, double-sided original of CIS</td> <td>-</td> <td>-</td> </tr> <tr> <td>SPEED</td> <td>Switching between normal reading (600 dpi) and high-speed reading</td> <td>0 (Normal)/ 1 (High-speed)</td> <td>0</td> </tr> </tbody> </table> <p>*: Dual scan DP only.</p> <ol style="list-style-type: none"> 4. Press the start key. The operation starts. 5. To stop continuous operation, press the stop key. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	CCD ADP (NON P)	Without paper, single-sided original of CCD (continuous operation)	-	-	CCD ADP	With paper, single-sided original of CCD	-	-	CCD RADP (NON P)	Without paper, double-sided original of CCD (continuous operation)	-	-	CCD RADP	With paper, double-sided original of CCD	-	-	CIS RADP (NON P)*	Without paper, double-sided original of CIS (continuous operation)	-	-	CIS RADP*	With paper, double-sided original of CIS	-	-	SPEED	Switching between normal reading (600 dpi) and high-speed reading	0 (Normal)/ 1 (High-speed)	0
Display	Description	Setting range	Initial setting																														
CCD ADP (NON P)	Without paper, single-sided original of CCD (continuous operation)	-	-																														
CCD ADP	With paper, single-sided original of CCD	-	-																														
CCD RADP (NON P)	Without paper, double-sided original of CCD (continuous operation)	-	-																														
CCD RADP	With paper, double-sided original of CCD	-	-																														
CIS RADP (NON P)*	Without paper, double-sided original of CIS (continuous operation)	-	-																														
CIS RADP*	With paper, double-sided original of CIS	-	-																														
SPEED	Switching between normal reading (600 dpi) and high-speed reading	0 (Normal)/ 1 (High-speed)	0																														

Maintenance item No.	Description														
<p>U204</p>	<p>Setting the presence or absence of a key card or key counter</p> <p>Description Sets the presence or absence of the optional key card or key counter.</p> <p>Purpose To run this maintenance item if a key card or key counter is installed.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. The setting screen for the selected item is displayed. <table border="1" data-bbox="333 533 1396 658"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>KEY-DEVICE</td> <td>Sets the presence or absence of the key card or key counter</td> </tr> <tr> <td>MESSAGE</td> <td>Sets the message when optional equipment is not installed</td> </tr> </tbody> </table> <p>Setting: [KEY-DEVICE]</p> <ol style="list-style-type: none"> 1. Select the optional counter to be installed. <table border="1" data-bbox="333 759 1396 925"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>KEY-CARD</td> <td>The key card is installed</td> </tr> <tr> <td>KEY-COUNTER</td> <td>The key counter is installed</td> </tr> <tr> <td>OFF</td> <td>Not installed</td> </tr> </tbody> </table> <p>Initial setting: OFF</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. 3. Turn the main power switch off and on. <p>Setting: [MESSAGE]</p> <ol style="list-style-type: none"> 1. Select the [KEY-DEVICE] or [COIN VENDOR]. 2. Press the start key. The setting is set. 3. Turn the main power switch off and on. 	Display	Description	KEY-DEVICE	Sets the presence or absence of the key card or key counter	MESSAGE	Sets the message when optional equipment is not installed	Display	Description	KEY-CARD	The key card is installed	KEY-COUNTER	The key counter is installed	OFF	Not installed
Display	Description														
KEY-DEVICE	Sets the presence or absence of the key card or key counter														
MESSAGE	Sets the message when optional equipment is not installed														
Display	Description														
KEY-CARD	The key card is installed														
KEY-COUNTER	The key counter is installed														
OFF	Not installed														
<p>U206</p>	<p>Setting the presence or absence of the coin vender</p> <p>Description Sets the presence or absence of the optional coin vender. Also sets the details for coin vender operation, such as mode and unit price. This is an optional device which is currently supported only by Japanese specification machines, so no setting is necessary.</p>														

Maintenance item No.	Description
U207	<p>Checking the operation panel keys</p> <p>Description Checks operation of the operation panel keys.</p> <p>Purpose To check operation of all the keys and LEDs on the operation panel.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. COUNT0 is displayed and the leftmost LED on the operation panel lights. 3. As the keys lined up in the same line as the lit indicator are pressed in the order from the top to the bottom, the figure shown on the touch panel increases in increments of 1. When all the keys in that line are pressed and if there are any LEDs corresponding to the keys in the line on the immediate right, the top LED in that line will light. 4. When all the keys on the operation panel have been pressed, all the LEDs light for up to 10 seconds. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>
U208	<p>Setting the paper size for the paper feeder</p> <p>Description Sets the size of paper used in 3000-sheet paper feeder.</p> <p>Purpose To change the setting when the size of paper used in the paper feeder is changed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the paper size (A4, B5 or Letter). Initial setting: Letter (Inch specifications)/A4 (Metric specifications) 3. Press the start key. The setting is set. 4. Turn the main power switch off and on.

Maintenance item No.	Description										
<p>U221</p>	<p>Setting the USB host lock function</p> <p>Description Specifies ON/OFF the USB host lock function. Setting this to ON causes the machine to be unable to recognize the device connected to the USB host.</p> <p>Purpose Set according to the preference of the user.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="333 562 1398 647"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>USB HOST LOCK</td> <td>USB host lock function ON/OFF setting</td> </tr> </tbody> </table> <p>Setting</p> <ol style="list-style-type: none"> 1. Select [ON] or [OFF]. <table border="1" data-bbox="333 750 1398 875"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>USB host lock function ON</td> </tr> <tr> <td>OFF</td> <td>USB host lock function OFF</td> </tr> </tbody> </table> <p>Initial setting: OFF</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. 3. Turn the main power switch off and on. 	Display	Description	USB HOST LOCK	USB host lock function ON/OFF setting	Display	Description	ON	USB host lock function ON	OFF	USB host lock function OFF
Display	Description										
USB HOST LOCK	USB host lock function ON/OFF setting										
Display	Description										
ON	USB host lock function ON										
OFF	USB host lock function OFF										
<p>U222</p>	<p>Setting the IC card type</p> <p>Description Sets the IC card type. This is an optional device which is currently supported only by Japanese specification machines, so no setting is necessary.</p>										

Maintenance item No.	Description																
U223	<p>Operation panel lock</p> <p>Description Sets the operation panel lock function to ON or OFF.</p> <p>Purpose To restrict operation in the system menu on the operation panel.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="335 533 1396 701"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Unlock</td> <td>Release the lock of the operation from the system menu.</td> </tr> <tr> <td>Partial Lock</td> <td>Partially lock the operation from the system menu.</td> </tr> <tr> <td>Lock</td> <td>Entirely lock the operation from the system menu.</td> </tr> </tbody> </table> <p>Initial setting: Unlock</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Unlock	Release the lock of the operation from the system menu.	Partial Lock	Partially lock the operation from the system menu.	Lock	Entirely lock the operation from the system menu.								
Display	Description																
Unlock	Release the lock of the operation from the system menu.																
Partial Lock	Partially lock the operation from the system menu.																
Lock	Entirely lock the operation from the system menu.																
U224	<p>Panel sheet extension</p> <p>Description Changes the image data and the message of the opening screen at the machine startup and the image data and the message of the service call screen to user specified data.</p> <p>Purpose Set according to the preference of the user.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Write the image data or the message data to the USB memory. 2. Insert USB memory in USB memory slot of the machine. 3. Turn the main power switch on. 4. Enter the maintenance item. 5. Press the start key. 6. Select the [Install] or [UnInstall]. <table border="1" data-bbox="335 1279 1396 1406"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Install</td> <td>Installs the image data or the message data</td> </tr> <tr> <td>UnInstall</td> <td>Restores the original image data or message data</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 7. Select the item. <table border="1" data-bbox="335 1451 1396 1659"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Opening Img</td> <td>Startup screen</td> </tr> <tr> <td>Call Img</td> <td>Service call image</td> </tr> <tr> <td>Call Msg Top</td> <td>Service call screen 1</td> </tr> <tr> <td>Call Msg Detail</td> <td>Service call screen 2</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 8. Press the start key. Installation or uninstallation is started. 9. When normally completed, [COMPLETE] is displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Install	Installs the image data or the message data	UnInstall	Restores the original image data or message data	Display	Description	Opening Img	Startup screen	Call Img	Service call image	Call Msg Top	Service call screen 1	Call Msg Detail	Service call screen 2
Display	Description																
Install	Installs the image data or the message data																
UnInstall	Restores the original image data or message data																
Display	Description																
Opening Img	Startup screen																
Call Img	Service call image																
Call Msg Top	Service call screen 1																
Call Msg Detail	Service call screen 2																

Maintenance item No.	Description										
<p>U234</p>	<p>Setting punch destination Description Sets the destination of punch unit of 3000-sheet document finisher. Purpose To be set when installing a different punch unit from the destination of the machine.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the destination. <table border="1" data-bbox="336 535 1398 741"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>AUTO</td> <td>With no punch unit</td> </tr> <tr> <td>JAPAN METRIC</td> <td>Metric (Japan) specifications</td> </tr> <tr> <td>INCH</td> <td>Inch (North America) specifications</td> </tr> <tr> <td>EUROPE METRIC</td> <td>Metric (Europe) specifications</td> </tr> </tbody> </table> <p>Initial setting: AUTO</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. 4. Turn the main power switch off and on. 	Display	Description	AUTO	With no punch unit	JAPAN METRIC	Metric (Japan) specifications	INCH	Inch (North America) specifications	EUROPE METRIC	Metric (Europe) specifications
Display	Description										
AUTO	With no punch unit										
JAPAN METRIC	Metric (Japan) specifications										
INCH	Inch (North America) specifications										
EUROPE METRIC	Metric (Europe) specifications										
<p>U236</p>	<p>Setting the limit for the ejection section of the built-in finisher Description If the machine is equipped with an built-in finisher, this mode sets whether A5R/B5R/statement size paper is output to the machine top tray or not. Purpose If the machine is equipped with an built-in finisher and if paper jams occur due to curling of paper in the built-in ejection section when two-sided copying onto A5R/B5R/statement size paper is performed, this mode is used to change the setting to ON to disable ejection to the machine top tray.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1" data-bbox="336 1234 1398 1361"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Does not eject to the machine top tray.</td> </tr> <tr> <td>OFF</td> <td>Eject to the machine top tray.</td> </tr> </tbody> </table> <p>Initial setting: OFF</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Does not eject to the machine top tray.	OFF	Eject to the machine top tray.				
Display	Description										
ON	Does not eject to the machine top tray.										
OFF	Eject to the machine top tray.										

Maintenance item No.	Description																		
U237	<p>Setting finisher stack quantity</p> <p>Description Sets the number of sheets of each stack on the main tray and on the Inner tray in 3000-sheet document finisher.</p> <p>Purpose To change the setting when a stack malfunction has occurred.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="333 564 1398 689"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>MAIN TRAY</td> <td>Number of sheets of stack on the main tray</td> </tr> <tr> <td>MIDDLE TRAY</td> <td>Number of sheets of stack on the internal tray for staple copying</td> </tr> </tbody> </table> <p>Setting: [MAIN TRAY]</p> <ol style="list-style-type: none"> 1. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="333 795 1398 920"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Number of sheets of stack on the main tray: 3000 sheets</td> </tr> <tr> <td>1</td> <td>Number of sheets of stack on the main tray: 1500 sheets</td> </tr> </tbody> </table> <p>Initial setting: 0</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. 3. Turn the main power switch off and on. <p>Setting: [MIDDLE TRAY]</p> <ol style="list-style-type: none"> 1. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="333 1115 1398 1240"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Number of sheets of stack on the internal tray for staple copying: 50 sheets</td> </tr> <tr> <td>1</td> <td>Number of sheets of stack on the internal tray for staple copying: 30 sheets</td> </tr> </tbody> </table> <p>Initial setting: 0 Number of sheets of stack on the internal tray for non-staple copying: 10 sheets</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. 3. Turn the main power switch off and on. 	Display	Description	MAIN TRAY	Number of sheets of stack on the main tray	MIDDLE TRAY	Number of sheets of stack on the internal tray for staple copying	Display	Description	0	Number of sheets of stack on the main tray: 3000 sheets	1	Number of sheets of stack on the main tray: 1500 sheets	Display	Description	0	Number of sheets of stack on the internal tray for staple copying: 50 sheets	1	Number of sheets of stack on the internal tray for staple copying: 30 sheets
Display	Description																		
MAIN TRAY	Number of sheets of stack on the main tray																		
MIDDLE TRAY	Number of sheets of stack on the internal tray for staple copying																		
Display	Description																		
0	Number of sheets of stack on the main tray: 3000 sheets																		
1	Number of sheets of stack on the main tray: 1500 sheets																		
Display	Description																		
0	Number of sheets of stack on the internal tray for staple copying: 50 sheets																		
1	Number of sheets of stack on the internal tray for staple copying: 30 sheets																		

Maintenance item No.	Description																																																		
<p>U240</p>	<p>Checking the operation of the finisher</p> <p>Description Turns each motor and solenoid of the 3000-sheet document finisher ON.</p> <p>Purpose To check the operation of each motor and solenoid of the 3000-sheet document finisher.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be checked. The screen for executing each item is displayed. <table border="1" data-bbox="333 535 1398 741"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>FINISHER MOTOR</td> <td>Checking the motor of the 3000-sheet document finisher</td> </tr> <tr> <td>FINISHER SOL</td> <td>Checking the solenoid of the 3000-sheet document finisher</td> </tr> <tr> <td>MAIL BOX</td> <td>Checking the motor and solenoid of the mailbox</td> </tr> <tr> <td>BOOKLET</td> <td>Checking the motor of the centerfold unit</td> </tr> </tbody> </table> <p>Method: [FINISHER MOTOR]</p> <ol style="list-style-type: none"> 1. Select the item to be operated. 2. Press the start key. The operation starts. <table border="1" data-bbox="333 875 1398 1704"> <thead> <tr> <th>Display</th> <th>Motor</th> </tr> </thead> <tbody> <tr> <td>FEED IN MOTOR M</td> <td>Paper entry motor (PEM) is turned on at middle speed</td> </tr> <tr> <td>FEED IN MOTOR L</td> <td>Paper entry motor (PEM) is turned on at low speed</td> </tr> <tr> <td>CONV MOTOR H</td> <td>Paper conveying motor (PCM) is turned on at high speed</td> </tr> <tr> <td>CONV MOTOR M</td> <td>Paper conveying motor (PCM) is turned on at middle speed</td> </tr> <tr> <td>CONV MOTOR L</td> <td>Paper conveying motor (PCM) is turned on at low speed</td> </tr> <tr> <td>EJECT MOTOR H</td> <td>Eject motor (EJM) is turned on at high speed</td> </tr> <tr> <td>EJECT MOTOR M</td> <td>Eject motor (EJM) is turned on at middle speed</td> </tr> <tr> <td>EJECT MOTOR L</td> <td>Eject motor (EJM) is turned on at low speed</td> </tr> <tr> <td>SUB PATH MOTOR H</td> <td>Relief path motor (RPM) is turned on counterclockwise</td> </tr> <tr> <td>SUB PATH MOTOR M</td> <td>Relief path motor (RPM) is turned on clockwise</td> </tr> <tr> <td>BUNDLE UP MOTOR</td> <td>Paper conveying belt motor 1 (PCBM1) is turned on</td> </tr> <tr> <td>BUNDLE DOWN MOTOR</td> <td>Paper conveying belt motor 2 (PCBM2) is turned on</td> </tr> <tr> <td>WIDTH TEST(A3)</td> <td>Side registration motor 1/2 (SRM1/2) are turned on</td> </tr> <tr> <td>WIDTH TEST(LD)</td> <td>Side registration motor 1/2 (SRM1/2) are turned on</td> </tr> <tr> <td>STAPLE FR MOTOR</td> <td>Staple moving motor 1 (STMM1) is turned on</td> </tr> <tr> <td>STAPLE S MOTOR</td> <td>Staple moving motor 2 (STMM2) is turned on</td> </tr> <tr> <td>STAPLE MOTOR</td> <td>Staple motor (STM) is turned on</td> </tr> <tr> <td>TRAY MOTOR</td> <td>Main tray motor (MTM) is turned on</td> </tr> <tr> <td>PUNCH MOTOR</td> <td>Punch motor (PUNM) is turned on</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. To stop operation, press the stop key. 	Display	Description	FINISHER MOTOR	Checking the motor of the 3000-sheet document finisher	FINISHER SOL	Checking the solenoid of the 3000-sheet document finisher	MAIL BOX	Checking the motor and solenoid of the mailbox	BOOKLET	Checking the motor of the centerfold unit	Display	Motor	FEED IN MOTOR M	Paper entry motor (PEM) is turned on at middle speed	FEED IN MOTOR L	Paper entry motor (PEM) is turned on at low speed	CONV MOTOR H	Paper conveying motor (PCM) is turned on at high speed	CONV MOTOR M	Paper conveying motor (PCM) is turned on at middle speed	CONV MOTOR L	Paper conveying motor (PCM) is turned on at low speed	EJECT MOTOR H	Eject motor (EJM) is turned on at high speed	EJECT MOTOR M	Eject motor (EJM) is turned on at middle speed	EJECT MOTOR L	Eject motor (EJM) is turned on at low speed	SUB PATH MOTOR H	Relief path motor (RPM) is turned on counterclockwise	SUB PATH MOTOR M	Relief path motor (RPM) is turned on clockwise	BUNDLE UP MOTOR	Paper conveying belt motor 1 (PCBM1) is turned on	BUNDLE DOWN MOTOR	Paper conveying belt motor 2 (PCBM2) is turned on	WIDTH TEST(A3)	Side registration motor 1/2 (SRM1/2) are turned on	WIDTH TEST(LD)	Side registration motor 1/2 (SRM1/2) are turned on	STAPLE FR MOTOR	Staple moving motor 1 (STMM1) is turned on	STAPLE S MOTOR	Staple moving motor 2 (STMM2) is turned on	STAPLE MOTOR	Staple motor (STM) is turned on	TRAY MOTOR	Main tray motor (MTM) is turned on	PUNCH MOTOR	Punch motor (PUNM) is turned on
Display	Description																																																		
FINISHER MOTOR	Checking the motor of the 3000-sheet document finisher																																																		
FINISHER SOL	Checking the solenoid of the 3000-sheet document finisher																																																		
MAIL BOX	Checking the motor and solenoid of the mailbox																																																		
BOOKLET	Checking the motor of the centerfold unit																																																		
Display	Motor																																																		
FEED IN MOTOR M	Paper entry motor (PEM) is turned on at middle speed																																																		
FEED IN MOTOR L	Paper entry motor (PEM) is turned on at low speed																																																		
CONV MOTOR H	Paper conveying motor (PCM) is turned on at high speed																																																		
CONV MOTOR M	Paper conveying motor (PCM) is turned on at middle speed																																																		
CONV MOTOR L	Paper conveying motor (PCM) is turned on at low speed																																																		
EJECT MOTOR H	Eject motor (EJM) is turned on at high speed																																																		
EJECT MOTOR M	Eject motor (EJM) is turned on at middle speed																																																		
EJECT MOTOR L	Eject motor (EJM) is turned on at low speed																																																		
SUB PATH MOTOR H	Relief path motor (RPM) is turned on counterclockwise																																																		
SUB PATH MOTOR M	Relief path motor (RPM) is turned on clockwise																																																		
BUNDLE UP MOTOR	Paper conveying belt motor 1 (PCBM1) is turned on																																																		
BUNDLE DOWN MOTOR	Paper conveying belt motor 2 (PCBM2) is turned on																																																		
WIDTH TEST(A3)	Side registration motor 1/2 (SRM1/2) are turned on																																																		
WIDTH TEST(LD)	Side registration motor 1/2 (SRM1/2) are turned on																																																		
STAPLE FR MOTOR	Staple moving motor 1 (STMM1) is turned on																																																		
STAPLE S MOTOR	Staple moving motor 2 (STMM2) is turned on																																																		
STAPLE MOTOR	Staple motor (STM) is turned on																																																		
TRAY MOTOR	Main tray motor (MTM) is turned on																																																		
PUNCH MOTOR	Punch motor (PUNM) is turned on																																																		



Maintenance item No.	Description																																														
U240	<p>Method: [FINISHER SOL]</p> <ol style="list-style-type: none"> 1. Select the item to be operated. 2. Press the start key. The operation starts. <table border="1" data-bbox="331 353 1396 855"> <thead> <tr> <th data-bbox="336 360 635 398">Display</th> <th data-bbox="635 360 1391 398">Solenoid</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 398 635 436">FEED IN SOL</td> <td data-bbox="635 398 1391 436">Paper entry solenoid (PESOL)</td> </tr> <tr> <td data-bbox="336 436 635 474">REAR DOWN SOL 1</td> <td data-bbox="635 436 1391 474">Trailing edge holder solenoid 1 (TEHSOL1)</td> </tr> <tr> <td data-bbox="336 474 635 512">REAR DOWN SOL 2</td> <td data-bbox="635 474 1391 512">Trailing edge holder solenoid 2 (TEHSOL2)</td> </tr> <tr> <td data-bbox="336 512 635 551">SUB PATH SOL</td> <td data-bbox="635 512 1391 551">Relief path solenoid (RPSOL)</td> </tr> <tr> <td data-bbox="336 551 635 589">SUB TRAY R SOL</td> <td data-bbox="635 551 1391 589">Feedshift solenoid 1 (FSSOL1)</td> </tr> <tr> <td data-bbox="336 589 635 627">SUB TRAY L SOL</td> <td data-bbox="635 589 1391 627">Feedshift solenoid 2 (FSSOL2)</td> </tr> <tr> <td data-bbox="336 627 635 665">BOOKLET SOL</td> <td data-bbox="635 627 1391 665">Centerfold feedshift solenoid (CFSSOL)</td> </tr> <tr> <td data-bbox="336 665 635 703">PADDLE SOL</td> <td data-bbox="635 665 1391 703">Paddle solenoid (PDSOL)</td> </tr> <tr> <td data-bbox="336 703 635 741">HOLD DOWN SOL</td> <td data-bbox="635 703 1391 741">Paper holder solenoid (PHSOL)</td> </tr> <tr> <td data-bbox="336 741 635 779">EJECT SOL</td> <td data-bbox="635 741 1391 779">Pressure switching solenoid (PSWSOL)</td> </tr> <tr> <td data-bbox="336 779 635 817">PUNCH SOL</td> <td data-bbox="635 779 1391 817">Punch pattern solenoid (PPSOL)</td> </tr> </tbody> </table> <p>Method: [MAIL BOX]</p> <ol style="list-style-type: none"> 1. Select the item to be operated. 2. Press the start key. The operation starts. <table border="1" data-bbox="331 987 1396 1115"> <thead> <tr> <th data-bbox="336 994 635 1032">Display</th> <th data-bbox="635 994 1391 1032">Motor</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1032 635 1070">CARRY ROLL</td> <td data-bbox="635 1032 1391 1070">Mailbox drive motor (MBDM) is turned on at paper conveying</td> </tr> <tr> <td data-bbox="336 1070 635 1108">BRANCH ROLL</td> <td data-bbox="635 1070 1391 1108">Mailbox drive motor (MBDM) is turned on at feedshift operation</td> </tr> </tbody> </table> <p>Method: [BOOKLET]</p> <ol style="list-style-type: none"> 1. Select the item to be operated. 2. Press the start key. The operation starts. <table border="1" data-bbox="331 1245 1396 1576"> <thead> <tr> <th data-bbox="336 1252 635 1290">Display</th> <th data-bbox="635 1252 1391 1290">Motor</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1290 635 1328">CONV MOTOR</td> <td data-bbox="635 1290 1391 1328">Centerfold main motor (CMM)</td> </tr> <tr> <td data-bbox="336 1328 635 1366">BLADE MOTOR</td> <td data-bbox="635 1328 1391 1366">Blade motor (BLM)</td> </tr> <tr> <td data-bbox="336 1366 635 1404">BUNDLE UP MOTOR</td> <td data-bbox="635 1366 1391 1404">Centerfold paper conveying belt motor 1 (CPCBM1)</td> </tr> <tr> <td data-bbox="336 1404 635 1442">BUNDLE DOWN MOTOR</td> <td data-bbox="635 1404 1391 1442">Centerfold paper conveying belt motor 2 (CPCBM2)</td> </tr> <tr> <td data-bbox="336 1442 635 1480">WIDTH TEST(A3)</td> <td data-bbox="635 1442 1391 1480">Centerfold side registration motor 1/2 (CSRM1/2)</td> </tr> <tr> <td data-bbox="336 1480 635 1518">WIDTH TEST(LD)</td> <td data-bbox="635 1480 1391 1518">Centerfold side registration motor 1/2 (CSRM1/2)</td> </tr> <tr> <td data-bbox="336 1518 635 1556">STAPLE MOTOR</td> <td data-bbox="635 1518 1391 1556">Centerfold staple motor (CSTM)</td> </tr> </tbody> </table> <p>Completion Press the stop key with the operation stopped. The screen for selecting a maintenance item No. is displayed.</p>	Display	Solenoid	FEED IN SOL	Paper entry solenoid (PESOL)	REAR DOWN SOL 1	Trailing edge holder solenoid 1 (TEHSOL1)	REAR DOWN SOL 2	Trailing edge holder solenoid 2 (TEHSOL2)	SUB PATH SOL	Relief path solenoid (RPSOL)	SUB TRAY R SOL	Feedshift solenoid 1 (FSSOL1)	SUB TRAY L SOL	Feedshift solenoid 2 (FSSOL2)	BOOKLET SOL	Centerfold feedshift solenoid (CFSSOL)	PADDLE SOL	Paddle solenoid (PDSOL)	HOLD DOWN SOL	Paper holder solenoid (PHSOL)	EJECT SOL	Pressure switching solenoid (PSWSOL)	PUNCH SOL	Punch pattern solenoid (PPSOL)	Display	Motor	CARRY ROLL	Mailbox drive motor (MBDM) is turned on at paper conveying	BRANCH ROLL	Mailbox drive motor (MBDM) is turned on at feedshift operation	Display	Motor	CONV MOTOR	Centerfold main motor (CMM)	BLADE MOTOR	Blade motor (BLM)	BUNDLE UP MOTOR	Centerfold paper conveying belt motor 1 (CPCBM1)	BUNDLE DOWN MOTOR	Centerfold paper conveying belt motor 2 (CPCBM2)	WIDTH TEST(A3)	Centerfold side registration motor 1/2 (CSRM1/2)	WIDTH TEST(LD)	Centerfold side registration motor 1/2 (CSRM1/2)	STAPLE MOTOR	Centerfold staple motor (CSTM)
Display	Solenoid																																														
FEED IN SOL	Paper entry solenoid (PESOL)																																														
REAR DOWN SOL 1	Trailing edge holder solenoid 1 (TEHSOL1)																																														
REAR DOWN SOL 2	Trailing edge holder solenoid 2 (TEHSOL2)																																														
SUB PATH SOL	Relief path solenoid (RPSOL)																																														
SUB TRAY R SOL	Feedshift solenoid 1 (FSSOL1)																																														
SUB TRAY L SOL	Feedshift solenoid 2 (FSSOL2)																																														
BOOKLET SOL	Centerfold feedshift solenoid (CFSSOL)																																														
PADDLE SOL	Paddle solenoid (PDSOL)																																														
HOLD DOWN SOL	Paper holder solenoid (PHSOL)																																														
EJECT SOL	Pressure switching solenoid (PSWSOL)																																														
PUNCH SOL	Punch pattern solenoid (PPSOL)																																														
Display	Motor																																														
CARRY ROLL	Mailbox drive motor (MBDM) is turned on at paper conveying																																														
BRANCH ROLL	Mailbox drive motor (MBDM) is turned on at feedshift operation																																														
Display	Motor																																														
CONV MOTOR	Centerfold main motor (CMM)																																														
BLADE MOTOR	Blade motor (BLM)																																														
BUNDLE UP MOTOR	Centerfold paper conveying belt motor 1 (CPCBM1)																																														
BUNDLE DOWN MOTOR	Centerfold paper conveying belt motor 2 (CPCBM2)																																														
WIDTH TEST(A3)	Centerfold side registration motor 1/2 (CSRM1/2)																																														
WIDTH TEST(LD)	Centerfold side registration motor 1/2 (CSRM1/2)																																														
STAPLE MOTOR	Centerfold staple motor (CSTM)																																														




Maintenance item No.	Description																																																												
U241	<p>Checking the operation of the switches of the finisher</p> <p>Description Displays the status of each switch of 3000-sheet document finisher.</p> <p>Purpose To check the operation of each switch of 3000-sheet document finisher.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be checked. <table border="1" data-bbox="336 535 1398 701"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>FINISHER</td> <td>Checking the switch of the document finisher</td> </tr> <tr> <td>MAIL BOX</td> <td>Checking the switch of the mailbox</td> </tr> <tr> <td>BOOKLET</td> <td>Checking the switch of the center-folding unit</td> </tr> </tbody> </table> <p>Method: [FINISHER]</p> <ol style="list-style-type: none"> 1. Turn each switch or sensor on and off manually to check the status. When the on-status of a switch or sensor is detected, that switch or sensor is displayed in reverse. <table border="1" data-bbox="336 835 1398 1912"> <thead> <tr> <th>Display</th> <th>Switches and sensors</th> </tr> </thead> <tbody> <tr> <td>FRONT COVER SW</td> <td>Front cover switch (FCSW)</td> </tr> <tr> <td>TOP COVER SW</td> <td>Top cover switch (TCSW)</td> </tr> <tr> <td>RIGHT COVER SW</td> <td>Sub tray right switch (STRSW)</td> </tr> <tr> <td>SET SW</td> <td>Joint switch (JSW)</td> </tr> <tr> <td>BOOKLET SW</td> <td>Centerfold set switch (CSSW)</td> </tr> <tr> <td>PUNCH TANK SW</td> <td>Punch waste box sensor (PWBS)</td> </tr> <tr> <td>TRAY L-LIMIT SW</td> <td>Main tray lower limit detection sensor (MTLLDS)</td> </tr> <tr> <td>TRAY U-LIMIT SW</td> <td>Main tray upper limit detection sensor (MTULDS)</td> </tr> <tr> <td>TRAY MIDDLE SW</td> <td>Main tray middle position detection sensor (MTMPDS)</td> </tr> <tr> <td>PAPER HOLD DOWN SW</td> <td>Paper holder home position sensor (PHHPS)</td> </tr> <tr> <td>LOAD DET SW</td> <td>Main tray paper upper surface detection sensor 1,2 (MTPUSDS1,2)</td> </tr> <tr> <td>HP SW</td> <td>Paper entry sensor (PES)</td> </tr> <tr> <td>EJECT SW 1</td> <td>Eject switch 1 (ESW1)</td> </tr> <tr> <td>EJECT SW 2</td> <td>Eject switch 2 (ESW2)</td> </tr> <tr> <td>EJECT SW 3</td> <td>Eject switch 3 (ESW3)</td> </tr> <tr> <td>STAPLE HP SW 1</td> <td>Staple home position switch 1 (STHPSW1)</td> </tr> <tr> <td>STAPLE HP SW 2</td> <td>Staple home position switch 2 (STHPSW2)</td> </tr> <tr> <td>MIDDLE FEED SW1</td> <td>Inner tray paper entry sensor 1 (ITPES1)</td> </tr> <tr> <td>MIDDLE FEED SW2</td> <td>Inner tray paper entry sensor 2 (ITPES2)</td> </tr> <tr> <td>BUNDLE DET SW 1</td> <td>Paper detection sensor 1 (PDS1)</td> </tr> <tr> <td>BUNDLE DET SW 2</td> <td>Paper detection sensor 2 (PDS2)</td> </tr> <tr> <td>BUNDLE UP HP SW</td> <td>Paper conveying belt home position sensor 1 (PCBHPS1)</td> </tr> <tr> <td>BUNDLE DOWN HP SW</td> <td>Paper conveying belt home position sensor 2 (PCBHPS2)</td> </tr> <tr> <td>WIDTH HP SW 1</td> <td>Side registration home position sensor 1 (SRHPS1)</td> </tr> <tr> <td>WIDTH HP SW 2</td> <td>Side registration home position sensor 2 (SRHPS2)</td> </tr> </tbody> </table>	Display	Description	FINISHER	Checking the switch of the document finisher	MAIL BOX	Checking the switch of the mailbox	BOOKLET	Checking the switch of the center-folding unit	Display	Switches and sensors	FRONT COVER SW	Front cover switch (FCSW)	TOP COVER SW	Top cover switch (TCSW)	RIGHT COVER SW	Sub tray right switch (STRSW)	SET SW	Joint switch (JSW)	BOOKLET SW	Centerfold set switch (CSSW)	PUNCH TANK SW	Punch waste box sensor (PWBS)	TRAY L-LIMIT SW	Main tray lower limit detection sensor (MTLLDS)	TRAY U-LIMIT SW	Main tray upper limit detection sensor (MTULDS)	TRAY MIDDLE SW	Main tray middle position detection sensor (MTMPDS)	PAPER HOLD DOWN SW	Paper holder home position sensor (PHHPS)	LOAD DET SW	Main tray paper upper surface detection sensor 1,2 (MTPUSDS1,2)	HP SW	Paper entry sensor (PES)	EJECT SW 1	Eject switch 1 (ESW1)	EJECT SW 2	Eject switch 2 (ESW2)	EJECT SW 3	Eject switch 3 (ESW3)	STAPLE HP SW 1	Staple home position switch 1 (STHPSW1)	STAPLE HP SW 2	Staple home position switch 2 (STHPSW2)	MIDDLE FEED SW1	Inner tray paper entry sensor 1 (ITPES1)	MIDDLE FEED SW2	Inner tray paper entry sensor 2 (ITPES2)	BUNDLE DET SW 1	Paper detection sensor 1 (PDS1)	BUNDLE DET SW 2	Paper detection sensor 2 (PDS2)	BUNDLE UP HP SW	Paper conveying belt home position sensor 1 (PCBHPS1)	BUNDLE DOWN HP SW	Paper conveying belt home position sensor 2 (PCBHPS2)	WIDTH HP SW 1	Side registration home position sensor 1 (SRHPS1)	WIDTH HP SW 2	Side registration home position sensor 2 (SRHPS2)
Display	Description																																																												
FINISHER	Checking the switch of the document finisher																																																												
MAIL BOX	Checking the switch of the mailbox																																																												
BOOKLET	Checking the switch of the center-folding unit																																																												
Display	Switches and sensors																																																												
FRONT COVER SW	Front cover switch (FCSW)																																																												
TOP COVER SW	Top cover switch (TCSW)																																																												
RIGHT COVER SW	Sub tray right switch (STRSW)																																																												
SET SW	Joint switch (JSW)																																																												
BOOKLET SW	Centerfold set switch (CSSW)																																																												
PUNCH TANK SW	Punch waste box sensor (PWBS)																																																												
TRAY L-LIMIT SW	Main tray lower limit detection sensor (MTLLDS)																																																												
TRAY U-LIMIT SW	Main tray upper limit detection sensor (MTULDS)																																																												
TRAY MIDDLE SW	Main tray middle position detection sensor (MTMPDS)																																																												
PAPER HOLD DOWN SW	Paper holder home position sensor (PHHPS)																																																												
LOAD DET SW	Main tray paper upper surface detection sensor 1,2 (MTPUSDS1,2)																																																												
HP SW	Paper entry sensor (PES)																																																												
EJECT SW 1	Eject switch 1 (ESW1)																																																												
EJECT SW 2	Eject switch 2 (ESW2)																																																												
EJECT SW 3	Eject switch 3 (ESW3)																																																												
STAPLE HP SW 1	Staple home position switch 1 (STHPSW1)																																																												
STAPLE HP SW 2	Staple home position switch 2 (STHPSW2)																																																												
MIDDLE FEED SW1	Inner tray paper entry sensor 1 (ITPES1)																																																												
MIDDLE FEED SW2	Inner tray paper entry sensor 2 (ITPES2)																																																												
BUNDLE DET SW 1	Paper detection sensor 1 (PDS1)																																																												
BUNDLE DET SW 2	Paper detection sensor 2 (PDS2)																																																												
BUNDLE UP HP SW	Paper conveying belt home position sensor 1 (PCBHPS1)																																																												
BUNDLE DOWN HP SW	Paper conveying belt home position sensor 2 (PCBHPS2)																																																												
WIDTH HP SW 1	Side registration home position sensor 1 (SRHPS1)																																																												
WIDTH HP SW 2	Side registration home position sensor 2 (SRHPS2)																																																												


Maintenance item No.	Description																																												
U241	<p>Method: [MAIL BOX]</p> <p>1. Turn each switch or sensor on and off manually to check the status. When the on-status of a switch or sensor is detected, that switch or sensor is displayed in reverse.</p> <table border="1" data-bbox="331 353 1396 813"> <thead> <tr> <th data-bbox="331 353 635 398">Display</th> <th data-bbox="635 353 1396 398">Switches and sensors</th> </tr> </thead> <tbody> <tr> <td data-bbox="331 398 635 432">HP SW</td> <td data-bbox="635 398 1396 432">Mail paper entry switch (MPESW)</td> </tr> <tr> <td data-bbox="331 432 635 465">EJECT SW</td> <td data-bbox="635 432 1396 465">Tray eject sensor (TEJS)</td> </tr> <tr> <td data-bbox="331 465 635 499">COVER SW</td> <td data-bbox="635 465 1396 499">Mailbox cover open/close switch (MBCOSW)</td> </tr> <tr> <td data-bbox="331 499 635 533">OVER FLOW SW 1</td> <td data-bbox="635 499 1396 533">Tray overflow switch 1 (TOFSW1)</td> </tr> <tr> <td data-bbox="331 533 635 566">OVER FLOW SW 2</td> <td data-bbox="635 533 1396 566">Tray overflow switch 2 (TOFSW2)</td> </tr> <tr> <td data-bbox="331 566 635 600">OVER FLOW SW 3</td> <td data-bbox="635 566 1396 600">Tray overflow switch 3 (TOFSW3)</td> </tr> <tr> <td data-bbox="331 600 635 633">OVER FLOW SW 4</td> <td data-bbox="635 600 1396 633">Tray overflow switch 4 (TOFSW4)</td> </tr> <tr> <td data-bbox="331 633 635 667">OVER FLOW SW 5</td> <td data-bbox="635 633 1396 667">Tray overflow switch 5 (TOFSW5)</td> </tr> <tr> <td data-bbox="331 667 635 701">OVER FLOW SW 6</td> <td data-bbox="635 667 1396 701">Tray overflow switch 6 (TOFSW6)</td> </tr> <tr> <td data-bbox="331 701 635 734">OVER FLOW SW 7</td> <td data-bbox="635 701 1396 734">Tray overflow switch 7 (TOFSW7)</td> </tr> </tbody> </table> <p>Method: [BOOKLET]</p> <p>1. Turn each switch or sensor on and off manually to check the status. When the on-status of a switch or sensor is detected, that switch or sensor is displayed in reverse.</p> <table border="1" data-bbox="331 947 1396 1406"> <thead> <tr> <th data-bbox="331 947 635 992">Display</th> <th data-bbox="635 947 1396 992">Switches and sensors</th> </tr> </thead> <tbody> <tr> <td data-bbox="331 992 635 1025">BUNDLE UP HP SW</td> <td data-bbox="635 992 1396 1025">Centerfold paper conveying belt sensor 1 (CPCBS1)</td> </tr> <tr> <td data-bbox="331 1025 635 1059">BUNDLE DOWN HP SW</td> <td data-bbox="635 1025 1396 1059">Centerfold paper conveying belt sensor 2 (CPCBS2)</td> </tr> <tr> <td data-bbox="331 1059 635 1093">BLADE HP SW</td> <td data-bbox="635 1059 1396 1093">Blade home position sensor (BLHPS)</td> </tr> <tr> <td data-bbox="331 1093 635 1126">WIDTH HP SW U</td> <td data-bbox="635 1093 1396 1126">Centerfold side registration sensor 2 (CSRS2)</td> </tr> <tr> <td data-bbox="331 1126 635 1160">WIDTH HP SW L</td> <td data-bbox="635 1126 1396 1160">Centerfold side registration sensor 1 (CSRS1)</td> </tr> <tr> <td data-bbox="331 1160 635 1193">FEED IN SW</td> <td data-bbox="635 1160 1396 1193">Centerfold paper entry sensor (CPES)</td> </tr> <tr> <td data-bbox="331 1193 635 1227">PAPER DET SW</td> <td data-bbox="635 1193 1396 1227">Centerfold paper detection sensor (CPDS)</td> </tr> <tr> <td data-bbox="331 1227 635 1261">TRAY PAPER DET SW</td> <td data-bbox="635 1227 1396 1261">Tray paper detection sensor (TPDS)</td> </tr> <tr> <td data-bbox="331 1261 635 1294">EJECT SW</td> <td data-bbox="635 1261 1396 1294">Centerfold eject switch (CESW)</td> </tr> <tr> <td data-bbox="331 1294 635 1328">TRAY DET SW</td> <td data-bbox="635 1294 1396 1328">Centerfold top cover switch (CTCSW)</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Switches and sensors	HP SW	Mail paper entry switch (MPESW)	EJECT SW	Tray eject sensor (TEJS)	COVER SW	Mailbox cover open/close switch (MBCOSW)	OVER FLOW SW 1	Tray overflow switch 1 (TOFSW1)	OVER FLOW SW 2	Tray overflow switch 2 (TOFSW2)	OVER FLOW SW 3	Tray overflow switch 3 (TOFSW3)	OVER FLOW SW 4	Tray overflow switch 4 (TOFSW4)	OVER FLOW SW 5	Tray overflow switch 5 (TOFSW5)	OVER FLOW SW 6	Tray overflow switch 6 (TOFSW6)	OVER FLOW SW 7	Tray overflow switch 7 (TOFSW7)	Display	Switches and sensors	BUNDLE UP HP SW	Centerfold paper conveying belt sensor 1 (CPCBS1)	BUNDLE DOWN HP SW	Centerfold paper conveying belt sensor 2 (CPCBS2)	BLADE HP SW	Blade home position sensor (BLHPS)	WIDTH HP SW U	Centerfold side registration sensor 2 (CSRS2)	WIDTH HP SW L	Centerfold side registration sensor 1 (CSRS1)	FEED IN SW	Centerfold paper entry sensor (CPES)	PAPER DET SW	Centerfold paper detection sensor (CPDS)	TRAY PAPER DET SW	Tray paper detection sensor (TPDS)	EJECT SW	Centerfold eject switch (CESW)	TRAY DET SW	Centerfold top cover switch (CTCSW)
Display	Switches and sensors																																												
HP SW	Mail paper entry switch (MPESW)																																												
EJECT SW	Tray eject sensor (TEJS)																																												
COVER SW	Mailbox cover open/close switch (MBCOSW)																																												
OVER FLOW SW 1	Tray overflow switch 1 (TOFSW1)																																												
OVER FLOW SW 2	Tray overflow switch 2 (TOFSW2)																																												
OVER FLOW SW 3	Tray overflow switch 3 (TOFSW3)																																												
OVER FLOW SW 4	Tray overflow switch 4 (TOFSW4)																																												
OVER FLOW SW 5	Tray overflow switch 5 (TOFSW5)																																												
OVER FLOW SW 6	Tray overflow switch 6 (TOFSW6)																																												
OVER FLOW SW 7	Tray overflow switch 7 (TOFSW7)																																												
Display	Switches and sensors																																												
BUNDLE UP HP SW	Centerfold paper conveying belt sensor 1 (CPCBS1)																																												
BUNDLE DOWN HP SW	Centerfold paper conveying belt sensor 2 (CPCBS2)																																												
BLADE HP SW	Blade home position sensor (BLHPS)																																												
WIDTH HP SW U	Centerfold side registration sensor 2 (CSRS2)																																												
WIDTH HP SW L	Centerfold side registration sensor 1 (CSRS1)																																												
FEED IN SW	Centerfold paper entry sensor (CPES)																																												
PAPER DET SW	Centerfold paper detection sensor (CPDS)																																												
TRAY PAPER DET SW	Tray paper detection sensor (TPDS)																																												
EJECT SW	Centerfold eject switch (CESW)																																												
TRAY DET SW	Centerfold top cover switch (CTCSW)																																												


Maintenance item No.	Description																										
U243	<p>Checking the operation of the DP motors</p> <p>Description Turns the motors or solenoids in the DP on.</p> <p>Purpose To check the operation of the DP motors and solenoids.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be operated. 3. Press the start key. The operation starts. <table border="1" data-bbox="336 566 1398 898"> <thead> <tr> <th>Display</th> <th>Motor and solenoid</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>DP FEED MOT</td> <td>Original feed motor (OFM)</td> <td>In operation</td> </tr> <tr> <td>DP CON MOT</td> <td>Original conveying motor (OCM)</td> <td>In operation</td> </tr> <tr> <td>DP REV MOT</td> <td>Original switchback motor (OSBM)</td> <td>In operation</td> </tr> <tr> <td>DP LIFT MOT</td> <td>DP lift motor (DPLM)</td> <td>In operation</td> </tr> <tr> <td>DP REV PRS SOL</td> <td>Switchback pressure solenoid (SBPSOL)</td> <td>On for 0.5 s</td> </tr> <tr> <td>DP REV BRCH SOL</td> <td>Switchback feedshift solenoid (SBFSSOL)</td> <td>On for 0.5 s</td> </tr> <tr> <td>CIS FAN*</td> <td>DP fan motor (DPFM)</td> <td>In operation</td> </tr> </tbody> </table> <p>*: Dual scan DP only.</p> <ol style="list-style-type: none"> 4. To turn each motor off, press the stop key. <p>Completion Press the stop key when operation stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Motor and solenoid	Operation	DP FEED MOT	Original feed motor (OFM)	In operation	DP CON MOT	Original conveying motor (OCM)	In operation	DP REV MOT	Original switchback motor (OSBM)	In operation	DP LIFT MOT	DP lift motor (DPLM)	In operation	DP REV PRS SOL	Switchback pressure solenoid (SBPSOL)	On for 0.5 s	DP REV BRCH SOL	Switchback feedshift solenoid (SBFSSOL)	On for 0.5 s	CIS FAN*	DP fan motor (DPFM)	In operation		
Display	Motor and solenoid	Operation																									
DP FEED MOT	Original feed motor (OFM)	In operation																									
DP CON MOT	Original conveying motor (OCM)	In operation																									
DP REV MOT	Original switchback motor (OSBM)	In operation																									
DP LIFT MOT	DP lift motor (DPLM)	In operation																									
DP REV PRS SOL	Switchback pressure solenoid (SBPSOL)	On for 0.5 s																									
DP REV BRCH SOL	Switchback feedshift solenoid (SBFSSOL)	On for 0.5 s																									
CIS FAN*	DP fan motor (DPFM)	In operation																									
U244	<p>Checking the DP switches</p> <p>Description Displays the status of the respective switches in the DP.</p> <p>Purpose To check if respective switches in the DP operate correctly.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Turn the respective switches on and off manually to check the status. If the on-status of a switch is detected, the corresponding switch is displayed in reverse. <table border="1" data-bbox="336 1361 1398 1899"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>FD SW</td> <td>Original feed switch (OFSW)</td> </tr> <tr> <td>REG SW</td> <td>Original registration switch (ORSW)</td> </tr> <tr> <td>TMG SW</td> <td>DP timing switch 1 (DPTSW1)</td> </tr> <tr> <td>EJT SW</td> <td>Original eject switch (OESW)</td> </tr> <tr> <td>TRY SW</td> <td>Switchback tray switch (SBTSW)</td> </tr> <tr> <td>SET SW</td> <td>Original set switch (OSSW)</td> </tr> <tr> <td>SZ SW A</td> <td>Original size length switch (OSLSW)</td> </tr> <tr> <td>L F U SW</td> <td>Tray upper limit switch (TULSW)</td> </tr> <tr> <td>L F L SW</td> <td>Tray lower limit switch (TLLSW)</td> </tr> <tr> <td>COV OP SW</td> <td>DP interlock switch (DPILSW)</td> </tr> <tr> <td>P OP SW</td> <td>DP open/close switch (DPOCSW)</td> </tr> <tr> <td>CIS SW*</td> <td>DP timing switch 2 (DPTSW2)</td> </tr> </tbody> </table> <p>*: Dual scan DP only.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	FD SW	Original feed switch (OFSW)	REG SW	Original registration switch (ORSW)	TMG SW	DP timing switch 1 (DPTSW1)	EJT SW	Original eject switch (OESW)	TRY SW	Switchback tray switch (SBTSW)	SET SW	Original set switch (OSSW)	SZ SW A	Original size length switch (OSLSW)	L F U SW	Tray upper limit switch (TULSW)	L F L SW	Tray lower limit switch (TLLSW)	COV OP SW	DP interlock switch (DPILSW)	P OP SW	DP open/close switch (DPOCSW)	CIS SW*	DP timing switch 2 (DPTSW2)
Display	Description																										
FD SW	Original feed switch (OFSW)																										
REG SW	Original registration switch (ORSW)																										
TMG SW	DP timing switch 1 (DPTSW1)																										
EJT SW	Original eject switch (OESW)																										
TRY SW	Switchback tray switch (SBTSW)																										
SET SW	Original set switch (OSSW)																										
SZ SW A	Original size length switch (OSLSW)																										
L F U SW	Tray upper limit switch (TULSW)																										
L F L SW	Tray lower limit switch (TLLSW)																										
COV OP SW	DP interlock switch (DPILSW)																										
P OP SW	DP open/close switch (DPOCSW)																										
CIS SW*	DP timing switch 2 (DPTSW2)																										

Maintenance item No.	Description																						
U245	<p>Checking messages</p> <p>Description Displays a list of messages on the touch panel of the operation panel.</p> <p>Purpose To check the messages to be displayed.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be displayed. 3. Displays the message one by one using cursor up/down keys. Switches the language on the touch panel using the cursor +/- keys. When a message number is entered with the numeric keys and then the start key is pressed, the message corresponding the specified number is displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>																						
U246	<p>Setting the finisher</p> <p>Description Provides various settings for the 3000-sheet document finisher, if furnished.</p> <p>Purpose</p> <p>Adjustment of registration stop timing in punch mode Adjust if skewed paper conveying occurs or if the copy paper is Z-folded in punch mode.</p> <p>Adjustment of paper stop timing in the punch mode To adjust this item when the position of a punch hole is different from the specified one.</p> <p>Adjustment of front/rear side registration home position of Inner tray Provides optimization when paper jam occurs due to an inferior fitting of the Inner tray adjuster guides to paper.</p> <p>Adjusting of front and back/slanted stapling home position Adjusts the stapling position in the staple mode if the position is not proper. Provides adjustment of slanted stapling.</p> <p>Adjustment of upper/lower side registration home position of center-folding unit Provides optimization when paper jam occurs due to an inferior fitting of the centerfold adjuster guides to paper.</p> <p>Adjustment of booklet stapling position Adjusts the booklet stapling position in the stitching mode if the position is not proper.</p> <p>Adjustment of center folding position Adjusts the center folding position in the stitching mode if the position is not proper.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. The screen for setting each item is displayed. <table border="1" data-bbox="333 1451 1398 1621"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>FINISHER 3000</td> <td>Adjustment of the 3000-sheet document finisher</td> </tr> <tr> <td>BOOKLET FOLDER</td> <td>Adjustment of the centerfold unit</td> </tr> <tr> <td>FINISHER B'-IN</td> <td>Adjustment of the built-in finisher</td> </tr> </tbody> </table> <p>Setting: [FINISHER 3000]</p> <ol style="list-style-type: none"> 1. Select the item to set. The screen for setting each item is displayed. <table border="1" data-bbox="333 1727 1398 2018"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>PUNCH REG ADJ</td> <td>Adjustment of registration stop timing in punch mode</td> </tr> <tr> <td>PUNCH POSITION ADJ</td> <td>Adjustment of the paper stop timing in punch mode</td> </tr> <tr> <td>WIDTH F HP ADJ</td> <td>Adjustment of front side registration home position</td> </tr> <tr> <td>WIDTH R HP ADJ</td> <td>Adjustment of rear side registration home position</td> </tr> <tr> <td>STAPLE HP ADJ</td> <td>Adjustment of front and back stapling home position</td> </tr> <tr> <td>TURNUED STAPLE HP ADJ</td> <td>Adjustment of slanted stapling home position</td> </tr> </tbody> </table>	Display	Description	FINISHER 3000	Adjustment of the 3000-sheet document finisher	BOOKLET FOLDER	Adjustment of the centerfold unit	FINISHER B'-IN	Adjustment of the built-in finisher	Display	Description	PUNCH REG ADJ	Adjustment of registration stop timing in punch mode	PUNCH POSITION ADJ	Adjustment of the paper stop timing in punch mode	WIDTH F HP ADJ	Adjustment of front side registration home position	WIDTH R HP ADJ	Adjustment of rear side registration home position	STAPLE HP ADJ	Adjustment of front and back stapling home position	TURNUED STAPLE HP ADJ	Adjustment of slanted stapling home position
Display	Description																						
FINISHER 3000	Adjustment of the 3000-sheet document finisher																						
BOOKLET FOLDER	Adjustment of the centerfold unit																						
FINISHER B'-IN	Adjustment of the built-in finisher																						
Display	Description																						
PUNCH REG ADJ	Adjustment of registration stop timing in punch mode																						
PUNCH POSITION ADJ	Adjustment of the paper stop timing in punch mode																						
WIDTH F HP ADJ	Adjustment of front side registration home position																						
WIDTH R HP ADJ	Adjustment of rear side registration home position																						
STAPLE HP ADJ	Adjustment of front and back stapling home position																						
TURNUED STAPLE HP ADJ	Adjustment of slanted stapling home position																						

Maintenance item No.	Description																												
U246	<p>Setting: Adjustment of registration stop timing</p> <ol style="list-style-type: none"> 1. Select [PUNCH REG ADJ]. 2. Change the setting value using the cursor up/down keys. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Description</th> <th style="text-align: center;">Setting range</th> <th style="text-align: center;">Initial setting</th> <th style="text-align: center;">Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of registration stop timing</td> <td style="text-align: center;">-20 to 20</td> <td style="text-align: center;">0</td> <td style="text-align: center;">1 ms</td> </tr> </tbody> </table> <p>If skewed paper conveying occurs (sample 1), increase the preset value. If the copy paper is Z-folded (sample 2), decrease the preset value.</p> <div style="text-align: center;">  <p style="display: flex; justify-content: space-around; margin-top: 5px;"> Sample 1 Sample 2 </p> </div> <p style="text-align: center;">Figure 1-3-18</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Setting: Adjustment of the paper stop timing</p> <ol style="list-style-type: none"> 1. Select [PUNCH POSITION ADJ]. 2. Change the setting value using the +/- or numeric keys. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Description</th> <th style="text-align: center;">Setting range</th> <th style="text-align: center;">Initial setting</th> <th style="text-align: center;">Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of the paper stop timing</td> <td style="text-align: center;">-10 to 10</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0.49 mm</td> </tr> </tbody> </table> <p>If the distance of the position of a punch hole is smaller than the specified value A, increase the preset value. If the distance is larger than the value A, decrease the preset value.</p> <div style="text-align: center;">  </div> <p style="text-align: right; margin-right: 100px;">Preset value A: 5.5 ± 2 mm (inch) 9.5 ± 2 mm (metric)</p> <p style="text-align: center;">Figure 1-3-19</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Setting: Adjustment of front/rear side registration home position</p> <ol style="list-style-type: none"> 1. Select [WIDTH F HP ADJ] or [WIDTH R HP ADJ]. 2. Change the setting value using the +/- or numeric keys. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Description</th> <th style="text-align: center;">Setting range</th> <th style="text-align: center;">Initial setting</th> <th style="text-align: center;">Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of front side registration home position</td> <td style="text-align: center;">-10 to 10</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0.31 mm</td> </tr> <tr> <td>Adjustment of rear side registration home position</td> <td style="text-align: center;">-10 to 10</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0.31 mm</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The value is set. 4. Press the stop key. The screen for selecting a maintenance item No. is displayed. 5. Enter maintenance mode U240 and select [FINISHER MOTOR], then [WIDTH TEST (A3)]. The width guides of the Inner tray will move to A3-size position. 6. Pull the Inner tray, insert paper between the guides and check that paper is abut the guides. 7. Repeat the above adjustment until paper is properly in position. 	Description	Setting range	Initial setting	Change in value per step	Adjustment of registration stop timing	-20 to 20	0	1 ms	Description	Setting range	Initial setting	Change in value per step	Adjustment of the paper stop timing	-10 to 10	0	0.49 mm	Description	Setting range	Initial setting	Change in value per step	Adjustment of front side registration home position	-10 to 10	0	0.31 mm	Adjustment of rear side registration home position	-10 to 10	0	0.31 mm
Description	Setting range	Initial setting	Change in value per step																										
Adjustment of registration stop timing	-20 to 20	0	1 ms																										
Description	Setting range	Initial setting	Change in value per step																										
Adjustment of the paper stop timing	-10 to 10	0	0.49 mm																										
Description	Setting range	Initial setting	Change in value per step																										
Adjustment of front side registration home position	-10 to 10	0	0.31 mm																										
Adjustment of rear side registration home position	-10 to 10	0	0.31 mm																										

Maintenance item No.	Description																
U246	<p>Setting: Adjustment of front and back stapling home position</p> <ol style="list-style-type: none"> 1. Select [STAPLE HP ADJ]. 2. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="331 353 1398 472"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of front and back stapling home position</td> <td>-10 to 10</td> <td>0</td> <td>0.32 mm</td> </tr> </tbody> </table> <p>When staple positions are off toward the front side of the machine (sample 1), increase the preset value. When staple positions are off toward the rear side of the machine (sample 2), decrease the preset value.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Sample 1</p> </div> <div style="text-align: center;">  <p>Sample 2</p> </div> </div> <p style="text-align: center;">Figure 1-3-20</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Setting: Adjustment of slanted stapling home position</p> <ol style="list-style-type: none"> 1. Select [TURNED STAPLE HP ADJ]. 2. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="331 1019 1398 1137"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of slanted stapling home position</td> <td>-10 to 10</td> <td>0</td> <td>0.99°</td> </tr> </tbody> </table> <p>To increase the angle for slanted stapling (sample 1), decrease the preset value. To decrease the angle for slanted stapling (sample 2), increase the preset value.</p> <div style="display: flex; align-items: center; justify-content: center;">  </div> <p style="text-align: center;">Figure 1-3-21</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. 	Description	Setting range	Initial setting	Change in value per step	Adjustment of front and back stapling home position	-10 to 10	0	0.32 mm	Description	Setting range	Initial setting	Change in value per step	Adjustment of slanted stapling home position	-10 to 10	0	0.99°
Description	Setting range	Initial setting	Change in value per step														
Adjustment of front and back stapling home position	-10 to 10	0	0.32 mm														
Description	Setting range	Initial setting	Change in value per step														
Adjustment of slanted stapling home position	-10 to 10	0	0.99°														

Maintenance item No.	Description																																														
U246	<p>Setting: [BOOKLET FOLDER]</p> <p>1. Select the item to be set.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> </tr> </thead> <tbody> <tr> <td>WIDTH U HP ADJ</td> <td>Adjustment of upper side registration home position</td> </tr> <tr> <td>WIDTH L HP ADJ</td> <td>Adjustment of lower side registration home position</td> </tr> <tr> <td>STAPLE POS ADJ (A4R/LTR)</td> <td>Adjustment of booklet stapling position for A4/Letter size</td> </tr> <tr> <td>STAPLE POS ADJ (B4R/LGR)</td> <td>Adjustment of booklet stapling position for B4/Legal size</td> </tr> <tr> <td>STAPLE POS ADJ (A3/LD)</td> <td>Adjustment of booklet stapling position for A3/Ledger size</td> </tr> <tr> <td>SADDLE POS ADJ (A4R/LTR)</td> <td>Adjustment of center folding position for A4/Letter size</td> </tr> <tr> <td>SADDLE POS ADJ (B4R/LGR)</td> <td>Adjustment of center folding position for B4/Legal size</td> </tr> <tr> <td>SADDLE POS ADJ (A3/LD)</td> <td>Adjustment of center folding position for A3/Ledger size</td> </tr> </tbody> </table> <p>Setting: Adjustment of upper/lower side registration home position</p> <p>1. Select [WIDTH U HP ADJ] or [WIDTH L HP ADJ].</p> <p>2. Change the setting using the +/- or numeric keys.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Description</th> <th style="text-align: center;">Setting range</th> <th style="text-align: center;">Initial setting</th> <th style="text-align: center;">Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of upper side registration home position</td> <td style="text-align: center;">-20 to 20</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0.104 mm</td> </tr> <tr> <td>Adjustment of lower side registration home position</td> <td style="text-align: center;">-46 to 46</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0.104 mm</td> </tr> </tbody> </table> <p>3. Press the start key. The value is set.</p> <p>4. Press the stop key. The screen for selecting a maintenance item No. is displayed.</p> <p>5. Enter maintenance mode U240 and select [BOOKLET], then [WIDTH TEST(A3)]. The width guides of the centerfold unit will move to A3-size position.</p> <p>6. Pull the centerfold unit, insert paper between the guides and check that paper is abut the guides.</p> <p>7. Repeat the above adjustment until paper is properly in position.</p> <p>Setting: Adjustment of booklet stapling position</p> <p>1. Select [STAPLE POS ADJ (A4R/LTR)], [STAPLE POS ADJ (B4R/LGR)] or [STAPLE POS ADJ (A3/LD)].</p> <p>2. Change the setting using the +/- or numeric keys.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Description</th> <th style="text-align: center;">Setting range</th> <th style="text-align: center;">Initial setting</th> <th style="text-align: center;">Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of booklet stapling position for A4/Letter size</td> <td style="text-align: center;">-10 to 10</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0.55 mm</td> </tr> <tr> <td>Adjustment of booklet stapling position for B4/Legal size</td> <td style="text-align: center;">-10 to 10</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0.55 mm</td> </tr> <tr> <td>Adjustment of booklet stapling position for A3/Ledger size</td> <td style="text-align: center;">-10 to 10</td> <td style="text-align: center;">0</td> <td style="text-align: center;">0.55 mm</td> </tr> </tbody> </table> <p>When staples are placed too far right (sample 1), decrease the preset value. When staples are placed too far left (sample 2), increase the preset value. Reference value: within ± 2 mm</p> <div style="text-align: center;">  <p style="text-align: center;">Sample 1 Sample 2</p> </div> <p style="text-align: center;">Figure 1-3-22</p> <p>3. Press the start key. The value is set.</p>	Display	Description	WIDTH U HP ADJ	Adjustment of upper side registration home position	WIDTH L HP ADJ	Adjustment of lower side registration home position	STAPLE POS ADJ (A4R/LTR)	Adjustment of booklet stapling position for A4/Letter size	STAPLE POS ADJ (B4R/LGR)	Adjustment of booklet stapling position for B4/Legal size	STAPLE POS ADJ (A3/LD)	Adjustment of booklet stapling position for A3/Ledger size	SADDLE POS ADJ (A4R/LTR)	Adjustment of center folding position for A4/Letter size	SADDLE POS ADJ (B4R/LGR)	Adjustment of center folding position for B4/Legal size	SADDLE POS ADJ (A3/LD)	Adjustment of center folding position for A3/Ledger size	Description	Setting range	Initial setting	Change in value per step	Adjustment of upper side registration home position	-20 to 20	0	0.104 mm	Adjustment of lower side registration home position	-46 to 46	0	0.104 mm	Description	Setting range	Initial setting	Change in value per step	Adjustment of booklet stapling position for A4/Letter size	-10 to 10	0	0.55 mm	Adjustment of booklet stapling position for B4/Legal size	-10 to 10	0	0.55 mm	Adjustment of booklet stapling position for A3/Ledger size	-10 to 10	0	0.55 mm
Display	Description																																														
WIDTH U HP ADJ	Adjustment of upper side registration home position																																														
WIDTH L HP ADJ	Adjustment of lower side registration home position																																														
STAPLE POS ADJ (A4R/LTR)	Adjustment of booklet stapling position for A4/Letter size																																														
STAPLE POS ADJ (B4R/LGR)	Adjustment of booklet stapling position for B4/Legal size																																														
STAPLE POS ADJ (A3/LD)	Adjustment of booklet stapling position for A3/Ledger size																																														
SADDLE POS ADJ (A4R/LTR)	Adjustment of center folding position for A4/Letter size																																														
SADDLE POS ADJ (B4R/LGR)	Adjustment of center folding position for B4/Legal size																																														
SADDLE POS ADJ (A3/LD)	Adjustment of center folding position for A3/Ledger size																																														
Description	Setting range	Initial setting	Change in value per step																																												
Adjustment of upper side registration home position	-20 to 20	0	0.104 mm																																												
Adjustment of lower side registration home position	-46 to 46	0	0.104 mm																																												
Description	Setting range	Initial setting	Change in value per step																																												
Adjustment of booklet stapling position for A4/Letter size	-10 to 10	0	0.55 mm																																												
Adjustment of booklet stapling position for B4/Legal size	-10 to 10	0	0.55 mm																																												
Adjustment of booklet stapling position for A3/Ledger size	-10 to 10	0	0.55 mm																																												

Maintenance item No.	Description																																
U246	<p>Setting: Adjustment of center folding position</p> <ol style="list-style-type: none"> 1. Select [SADDLE POS ADJ (A4R/LTR)], [SADDLE POS ADJ (B4R/LGR)] or [SADDLE POS ADJ (A3/LD)]. 2. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="331 353 1396 555"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adjustment of center folding position for A4/Letter size</td> <td>-10 to 10</td> <td>0</td> <td>0.55 mm</td> </tr> <tr> <td>Adjustment of center folding position for B4/Legal size</td> <td>-10 to 10</td> <td>0</td> <td>0.55 mm</td> </tr> <tr> <td>Adjustment of center folding position for A3/Ledger size</td> <td>-10 to 10</td> <td>0</td> <td>0.55 mm</td> </tr> </tbody> </table> <p>When the centerfold position too far right (sample 1), increase the preset value. When the centerfold position too far left (sample 2), decrease the setting value. Reference value: within ± 3 mm</p>  <p style="text-align: center;">Figure 1-3-23</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Setting: [FINISHER B'-IN]</p> <ol style="list-style-type: none"> 1. Select the desired cursor position. 2. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="331 1182 1396 1384"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>FRONT</td> <td>Front side registration cursor stop position</td> <td>-4 to +4</td> <td>0</td> </tr> <tr> <td>REAR</td> <td>Rear side registration cursor stop position</td> <td>-4 to +4</td> <td>0</td> </tr> <tr> <td>END</td> <td>Trailing edge registration cursor stop position</td> <td>-4 to +4</td> <td>0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Change in value per step	Adjustment of center folding position for A4/Letter size	-10 to 10	0	0.55 mm	Adjustment of center folding position for B4/Legal size	-10 to 10	0	0.55 mm	Adjustment of center folding position for A3/Ledger size	-10 to 10	0	0.55 mm	Display	Description	Setting range	Initial setting	FRONT	Front side registration cursor stop position	-4 to +4	0	REAR	Rear side registration cursor stop position	-4 to +4	0	END	Trailing edge registration cursor stop position	-4 to +4	0
Description	Setting range	Initial setting	Change in value per step																														
Adjustment of center folding position for A4/Letter size	-10 to 10	0	0.55 mm																														
Adjustment of center folding position for B4/Legal size	-10 to 10	0	0.55 mm																														
Adjustment of center folding position for A3/Ledger size	-10 to 10	0	0.55 mm																														
Display	Description	Setting range	Initial setting																														
FRONT	Front side registration cursor stop position	-4 to +4	0																														
REAR	Rear side registration cursor stop position	-4 to +4	0																														
END	Trailing edge registration cursor stop position	-4 to +4	0																														

Maintenance item No.	Description																														
<p>U247</p>	<p>Setting the paper feed device</p> <p>Description Turns on motors and clutches of 3000-sheet paper feeder or paper feeder.</p> <p>Purpose To check the operation of motors and clutches of paper feed device.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The value varies depending to the option furnished. 2. Select the item to be operated. 3. Press the start key. The operation starts. <p>3000-sheet paper feeder.</p> <table border="1"> <thead> <tr> <th>Display</th> <th>Motor and clutches</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>LCF FEED</td> <td>PF conveying motor (PFCM)</td> <td>In operation</td> </tr> <tr> <td>CLUTCH B</td> <td>PF conveying clutch (PFCCL)</td> <td>On for 1 s</td> </tr> <tr> <td>CLUTCH P1</td> <td>PF paper feed clutch 1 (PFPFCL1)</td> <td>On for 1 s</td> </tr> <tr> <td>CLUTCH P2</td> <td>PF paper feed clutch 2 (PFPFCL2)</td> <td>On for 1 s</td> </tr> </tbody> </table> <p>Paper feeder</p> <table border="1"> <thead> <tr> <th>Display</th> <th>Motor and clutches</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>DESK FEED</td> <td>PF drive motor (PFDM)</td> <td>In operation</td> </tr> <tr> <td>CLUTCH FEED</td> <td>PF feed clutch (PFFCL)</td> <td>On for 1 s</td> </tr> <tr> <td>CLUTCH U</td> <td>PF paper feed clutch 1 (PFPFCL1)</td> <td>On for 1 s</td> </tr> <tr> <td>CLUTCH L</td> <td>PF paper feed clutch 2 (PFPFCL2)</td> <td>On for 1 s</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. To turn each motor off, press the stop key. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Motor and clutches	Operation	LCF FEED	PF conveying motor (PFCM)	In operation	CLUTCH B	PF conveying clutch (PFCCL)	On for 1 s	CLUTCH P1	PF paper feed clutch 1 (PFPFCL1)	On for 1 s	CLUTCH P2	PF paper feed clutch 2 (PFPFCL2)	On for 1 s	Display	Motor and clutches	Operation	DESK FEED	PF drive motor (PFDM)	In operation	CLUTCH FEED	PF feed clutch (PFFCL)	On for 1 s	CLUTCH U	PF paper feed clutch 1 (PFPFCL1)	On for 1 s	CLUTCH L	PF paper feed clutch 2 (PFPFCL2)	On for 1 s
Display	Motor and clutches	Operation																													
LCF FEED	PF conveying motor (PFCM)	In operation																													
CLUTCH B	PF conveying clutch (PFCCL)	On for 1 s																													
CLUTCH P1	PF paper feed clutch 1 (PFPFCL1)	On for 1 s																													
CLUTCH P2	PF paper feed clutch 2 (PFPFCL2)	On for 1 s																													
Display	Motor and clutches	Operation																													
DESK FEED	PF drive motor (PFDM)	In operation																													
CLUTCH FEED	PF feed clutch (PFFCL)	On for 1 s																													
CLUTCH U	PF paper feed clutch 1 (PFPFCL1)	On for 1 s																													
CLUTCH L	PF paper feed clutch 2 (PFPFCL2)	On for 1 s																													

Maintenance item No.	Description									
U250	<p>Setting the maintenance cycle</p> <p>Description Changes preset values for maintenance cycle and automatic grayscale adjustment.</p> <p>Purpose Provides changing the time when the message to acknowledge to conduct maintenance and automatic grayscale adjustment is periodically displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. The current pre-set value is displayed. <table border="1" data-bbox="331 533 1396 689"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> </tr> </thead> <tbody> <tr> <td>Maintenance Count A</td> <td>Preset values for maintenance cycle</td> <td>0 to 9999999</td> </tr> <tr> <td>COUNT GRAY ADJUST*100</td> <td>Preset values for automatic grayscale adjustment</td> <td>0 to 99900*</td> </tr> </tbody> </table> <p>*: The setting can be changed by 100 per step.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Select the item to be cleared. To clear all items, select [ALL CLEAR]. 2. Press the clear key. 3. Press the start key. The setting value is cleared. <p>Setting</p> <ol style="list-style-type: none"> 1. Select the item to be changed. 2. Enter the setting value using the +/- or numeric keys. 3. Press the start key. The setting value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Maintenance Count A	Preset values for maintenance cycle	0 to 9999999	COUNT GRAY ADJUST*100	Preset values for automatic grayscale adjustment	0 to 99900*
Display	Description	Setting range								
Maintenance Count A	Preset values for maintenance cycle	0 to 9999999								
COUNT GRAY ADJUST*100	Preset values for automatic grayscale adjustment	0 to 99900*								
U251	<p>Checking/clearing the maintenance count</p> <p>Description Displays and clears or changes the maintenance count and automatic grayscale adjustment count.</p> <p>Purpose To verify the maintenance counter count and automatic grayscale count. Also to clear the count during maintenance service.</p> <p>Method Press the start key. The maintenance count is displayed.</p> <table border="1" data-bbox="331 1384 1396 1512"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> </tr> </thead> <tbody> <tr> <td>Maintenance Count A</td> <td>Count value for maintenance cycle</td> <td>0 to 9999999</td> </tr> <tr> <td>COUNT GRAY ADJUST</td> <td>Automatic grayscale adjustment count</td> <td>0 to 9999999</td> </tr> </tbody> </table> <p>Clearing</p> <ol style="list-style-type: none"> 1. Select the item to be cleared. To clear all items, select [ALL CLEAR]. 2. Press the clear key. 3. Press the start key. The count is cleared. <p>Setting</p> <ol style="list-style-type: none"> 1. Select the item to be changed. 2. Enter the count using the numeric keys. 3. Press the start key. The count is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Maintenance Count A	Count value for maintenance cycle	0 to 9999999	COUNT GRAY ADJUST	Automatic grayscale adjustment count	0 to 9999999
Display	Description	Setting range								
Maintenance Count A	Count value for maintenance cycle	0 to 9999999								
COUNT GRAY ADJUST	Automatic grayscale adjustment count	0 to 9999999								

Maintenance item No.	Description																						
<p>U252</p>	<p>Setting the destination</p> <p>Description Switches the operations and screens of the machine according to the destination.</p> <p>Purpose To be executed after initializing the backup RAM, in order to return the setting to the value before replacement or initialization.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the destination. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> </tr> </thead> <tbody> <tr> <td>EUROPE METRIC</td> <td>Metric (Europe) specifications</td> </tr> <tr> <td>INCH</td> <td>Inch (North America) specifications</td> </tr> <tr> <td>ASIA PACIFIC</td> <td>Metric (Asia Pacific) specifications</td> </tr> <tr> <td>AUSTRALIA</td> <td>Australia specifications</td> </tr> <tr> <td>CHINA</td> <td>China specifications</td> </tr> <tr> <td>KOREA</td> <td>Korea specifications</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. 4. Turn the main power switch off and on. <p>Supplement The specified initial settings are provided according to the destinations in the maintenance items below. To change the initial settings in those items, be sure to run maintenance item U021 after changing the destination.</p> <p style="text-align: center;">Initial setting according to the destinations</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Maintenance No.</th> <th style="text-align: left;">Title</th> <th style="text-align: left;">Inch spec.</th> <th style="text-align: left;">Europe/Asia Pacific spec.</th> </tr> </thead> <tbody> <tr> <td>208</td> <td>Setting the paper size for the paper feeder</td> <td>Letter</td> <td>A4</td> </tr> </tbody> </table>	Display	Description	EUROPE METRIC	Metric (Europe) specifications	INCH	Inch (North America) specifications	ASIA PACIFIC	Metric (Asia Pacific) specifications	AUSTRALIA	Australia specifications	CHINA	China specifications	KOREA	Korea specifications	Maintenance No.	Title	Inch spec.	Europe/Asia Pacific spec.	208	Setting the paper size for the paper feeder	Letter	A4
Display	Description																						
EUROPE METRIC	Metric (Europe) specifications																						
INCH	Inch (North America) specifications																						
ASIA PACIFIC	Metric (Asia Pacific) specifications																						
AUSTRALIA	Australia specifications																						
CHINA	China specifications																						
KOREA	Korea specifications																						
Maintenance No.	Title	Inch spec.	Europe/Asia Pacific spec.																				
208	Setting the paper size for the paper feeder	Letter	A4																				

Maintenance item No.	Description										
U253	<p>Switching between double and single counts</p> <p>Description Switches the count system for the total counter and other counters.</p> <p>Purpose Used to select, according to the preference of the user (copy service provider), if A3/Ledger paper is to be counted as one sheet (single count) or two sheets (double count).</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the count system. <table border="1" data-bbox="331 562 1396 770"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ALL SINGLE</td> <td>Single count for all size paper</td> </tr> <tr> <td>DOUBLE COUNT(A3/LEDGER)</td> <td>Double count for A3/Ledger size or larger</td> </tr> <tr> <td>DOUBLE COUNT(B4)</td> <td>Double count for B4 size or larger</td> </tr> <tr> <td>DOUBLE COUNT(FOLIO/LEGAL)</td> <td>Double count for FOLIO/Legal size or larger</td> </tr> </tbody> </table> <p>Initial setting: DOUBLE COUNT(A3/LEDGER)</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ALL SINGLE	Single count for all size paper	DOUBLE COUNT(A3/LEDGER)	Double count for A3/Ledger size or larger	DOUBLE COUNT(B4)	Double count for B4 size or larger	DOUBLE COUNT(FOLIO/LEGAL)	Double count for FOLIO/Legal size or larger
Display	Description										
ALL SINGLE	Single count for all size paper										
DOUBLE COUNT(A3/LEDGER)	Double count for A3/Ledger size or larger										
DOUBLE COUNT(B4)	Double count for B4 size or larger										
DOUBLE COUNT(FOLIO/LEGAL)	Double count for FOLIO/Legal size or larger										
U260	<p>Selecting the timing for copy counting</p> <p>Description Changes the copy count timing for the total counter and other counters.</p> <p>Purpose To be set according to user (copy service provider) request. If a paper jam occurs frequently in the optional document finisher when the number of copies is counted at the time of paper ejection, copies are provided without copy counts. The copy service provider cannot charge for such copying. To prevent this, the copy timing should be made earlier. If a paper jam occurs frequently in the paper conveying or fuser sections when the number of copies is counted before the paper reaches those sections, copying is charged without a copy being made. To prevent this, the copy timing should be made later.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the copy count timing. <table border="1" data-bbox="331 1386 1396 1509"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>FEED</td> <td>When secondary paper feed starts</td> </tr> <tr> <td>EJECT</td> <td>When the paper is ejected</td> </tr> </tbody> </table> <p>Initial setting: EJECT</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	FEED	When secondary paper feed starts	EJECT	When the paper is ejected				
Display	Description										
FEED	When secondary paper feed starts										
EJECT	When the paper is ejected										

Maintenance item No.	Description
U265	<p>Setting OEM purchaser code</p> <p>Description Sets the OEM purchaser code.</p> <p>Purpose Sets the code when replacing the main PWB and the like.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the preset value using the numeric keys. 3. Press the start key. The setting is set. 4. Turn the main power switch off and on.
U278	<p>Setting the delivery date</p> <p>Description Enter delivery date in month, day, and year.</p> <p>Purpose To operate when installing the machine. Perform this to confirm the delivery date.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [TODAY]. 3. Press the start key. The delivery date is set. <p>Clearing</p> <ol style="list-style-type: none"> 1. Select [CLEAR]. 2. Press the start key. The delivery date is cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>
U285	<p>Setting service status page</p> <p>Description Determines displaying the digital dot coverage report on reporting.</p> <p>Purpose According to user request, changes the setting.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press [COVERAGE]. Highlighted: ON, Non-highlighted: OFF Initial setting: ON 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Maintenance item No.	Description																				
U326	<p>Setting the black line cleaning indication</p> <p>Description Sets whether to display the cleaning guidance when detecting the black line.</p> <p>Purpose Displays the cleaning guidance in order to make the call for service with the black line decrease by the rubbish on the contact glass when scanning from the DP.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to set. The screen for setting each item is displayed. <table border="1" data-bbox="331 562 1398 689"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>BLACK LINE MODE</td> <td>Black line cleaning guidance ON/OFF setting</td> </tr> <tr> <td>BLACK LINE COUNT</td> <td>Setting counts of the cleaning guidance indication</td> </tr> </tbody> </table> <p>Setting: [BLACK LINE MODE]</p> <ol style="list-style-type: none"> 1. Select ON or OFF. <table border="1" data-bbox="331 795 1398 922"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Displays the cleaning guidance</td> </tr> <tr> <td>OFF</td> <td>Not to display the cleaning guidance</td> </tr> </tbody> </table> <p>Initial setting: ON Setting count value is displayed only if the setting is ON.</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. <p>Setting: [BLACK LINE COUNT]</p> <ol style="list-style-type: none"> 1. Change the setting value using the +/- or numeric keys. <table border="1" data-bbox="331 1115 1398 1227"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>COUNT *1000</td> <td>Setting counts of the cleaning guidance indication (x 1000 sheets)</td> <td>0 to 255</td> <td>8</td> </tr> </tbody> </table> <p>When setting is 0, the black line cleaning indication is displayed only if the black line is detected.</p> <ol style="list-style-type: none"> 2. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	BLACK LINE MODE	Black line cleaning guidance ON/OFF setting	BLACK LINE COUNT	Setting counts of the cleaning guidance indication	Display	Description	ON	Displays the cleaning guidance	OFF	Not to display the cleaning guidance	Display	Description	Setting range	Initial setting	COUNT *1000	Setting counts of the cleaning guidance indication (x 1000 sheets)	0 to 255	8
Display	Description																				
BLACK LINE MODE	Black line cleaning guidance ON/OFF setting																				
BLACK LINE COUNT	Setting counts of the cleaning guidance indication																				
Display	Description																				
ON	Displays the cleaning guidance																				
OFF	Not to display the cleaning guidance																				
Display	Description	Setting range	Initial setting																		
COUNT *1000	Setting counts of the cleaning guidance indication (x 1000 sheets)	0 to 255	8																		



Maintenance item No.	Description								
<p>U328</p>	<p>Side ejection setting</p> <p>Description Sets whether to eject to the side of the machine when an optional curl eliminator is installed.</p> <p>Purpose Set according to the preference of the user.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [ON] or [OFF]. <table border="1" data-bbox="333 533 1398 660"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>To eject to the side of the machine</td> </tr> <tr> <td>OFF</td> <td>Not to eject to the side of the machine</td> </tr> </tbody> </table> <p>Initial setting: OFF</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. 4. Turn the main power switch off and on. 	Display	Description	ON	To eject to the side of the machine	OFF	Not to eject to the side of the machine		
Display	Description								
ON	To eject to the side of the machine								
OFF	Not to eject to the side of the machine								
<p>U332</p>	<p>Setting the size conversion factor</p> <p>Description Sets the coefficient of nonstandard sizes in relation to the A4/Letter size. The coefficient set here is used to convert the black ratio in relation to the A4/Letter size and to display the result in user simulation.</p> <p>Purpose To set the coefficient for converting the black ratio for nonstandard sizes in relation to the A4/Letter size.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="333 1099 1398 1182"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Calculation Rate</td> <td>Size parameter</td> <td>0.1 to 3.0</td> <td>1.0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Calculation Rate	Size parameter	0.1 to 3.0	1.0
Display	Description	Setting range	Initial setting						
Calculation Rate	Size parameter	0.1 to 3.0	1.0						


Maintenance item No.	Description														
U341	<p>Specific paper feed location setting for printing function</p> <p>Description Sets a paper feed location specified for printer output.</p> <p>Purpose To use a paper feed location only for printer output. A paper feed location specified for printer output cannot be used for copy output.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the paper feed location for the printer. Two or more cassette can be selected. <table border="1" data-bbox="331 593 1396 840"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>CASSETTE 1</td> <td>Cassette 1</td> </tr> <tr> <td>CASSETTE 2</td> <td>Cassette 2</td> </tr> <tr> <td>CASSETTE 3</td> <td>Cassette 3 (optional paper feeder)</td> </tr> <tr> <td>CASSETTE 4</td> <td>Cassette 4 (optional paper feeder)</td> </tr> <tr> <td>LCF</td> <td>Optional 3000-sheet paper feeder</td> </tr> </tbody> </table> <p>When an optional paper feed device is not installed, the corresponding count is not displayed.</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	CASSETTE 1	Cassette 1	CASSETTE 2	Cassette 2	CASSETTE 3	Cassette 3 (optional paper feeder)	CASSETTE 4	Cassette 4 (optional paper feeder)	LCF	Optional 3000-sheet paper feeder		
Display	Description														
CASSETTE 1	Cassette 1														
CASSETTE 2	Cassette 2														
CASSETTE 3	Cassette 3 (optional paper feeder)														
CASSETTE 4	Cassette 4 (optional paper feeder)														
LCF	Optional 3000-sheet paper feeder														
U342	<p>Setting the ejection restriction</p> <p>Description Sets or cancels the restriction on the number of sheets to be ejected continuously when the internal eject tray is selected as the eject location.</p> <p>Purpose According to user request, sets or cancels restriction on the number of sheets.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [ON] or [OFF]. <table border="1" data-bbox="331 1310 1396 1429"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Sets restriction on the number of sheets</td> </tr> <tr> <td>OFF</td> <td>Cancel restriction on the number of sheets</td> </tr> </tbody> </table> <p>Initial setting: ON</p> <p>Details of restriction (number of sheets to be ejected continuously after the start key is pressed)</p> <table border="1" data-bbox="331 1534 1396 1697"> <thead> <tr> <th>Condition</th> <th>Number of sheets</th> </tr> </thead> <tbody> <tr> <td>When no optional ejection device is installed</td> <td>250 sheets</td> </tr> <tr> <td>When the job separator is installed</td> <td>150 sheets</td> </tr> <tr> <td>When the finisher is installed</td> <td>100 sheets</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Sets restriction on the number of sheets	OFF	Cancel restriction on the number of sheets	Condition	Number of sheets	When no optional ejection device is installed	250 sheets	When the job separator is installed	150 sheets	When the finisher is installed	100 sheets
Display	Description														
ON	Sets restriction on the number of sheets														
OFF	Cancel restriction on the number of sheets														
Condition	Number of sheets														
When no optional ejection device is installed	250 sheets														
When the job separator is installed	150 sheets														
When the finisher is installed	100 sheets														

Maintenance item No.	Description						
<p>U343</p>	<p>Switching between duplex/simplex copy mode</p> <p>Description Switches the initial setting between duplex and simplex copy.</p> <p>Purpose To be set according to frequency of use: set to the more frequently used mode.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1" data-bbox="333 533 1398 660"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Duplex copy</td> </tr> <tr> <td>OFF</td> <td>Simplex copy</td> </tr> </tbody> </table> <p>Initial setting: OFF</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Duplex copy	OFF	Simplex copy
Display	Description						
ON	Duplex copy						
OFF	Simplex copy						
<p>U345</p>	<p>Setting the value for maintenance due indication</p> <p>Description Sets when to display a message notifying that the time for maintenance is about to be reached, by setting the number of copies that can be made before the current maintenance cycle ends. When the difference between the number of copies of the maintenance cycle and that of the maintenance count reaches the set value, the message is displayed.</p> <p>Purpose To change the time for maintenance due indication.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the setting using the +/- or numeric keys. <table border="1" data-bbox="333 1169 1398 1310"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> </tr> </thead> <tbody> <tr> <td>COUNT</td> <td>Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)</td> <td>0 to 9999</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	COUNT	Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)	0 to 9999
Display	Description	Setting range					
COUNT	Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)	0 to 9999					

Maintenance item No.	Description																																			
U402	<p>Adjusting margins of image printing</p> <p>Description Adjusts margins for image printing.</p> <p>Purpose Make the adjustment if margins are incorrect.</p> <p>Adjustment</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be adjusted. <table border="1" data-bbox="331 533 1396 913"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>LEAD</td> <td>Printer leading edge margin</td> <td>0 to 10.0</td> <td>4.0</td> <td>0.1 mm</td> </tr> <tr> <td>A</td> <td>Printer left margin</td> <td>0 to 10.0</td> <td>3.0</td> <td>0.1 mm</td> </tr> <tr> <td>C</td> <td>Printer right margin</td> <td>0 to 10.0</td> <td>3.0</td> <td>0.1 mm</td> </tr> <tr> <td>TRAIL</td> <td>Printer trailing edge margin</td> <td>0 to 10.0</td> <td>3.9</td> <td>0.1 mm</td> </tr> <tr> <td>TRAIL(DUP)</td> <td>Printer trailing edge margin (second side)</td> <td>0 to 10.0</td> <td>4.0</td> <td>0.1 mm</td> </tr> <tr> <td>TRAIL(MPT)</td> <td>Printer trailing edge margin (MP tray)</td> <td>0 to 10.0</td> <td>4.0</td> <td>0.1 mm</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the system menu key. 4. Press the start key to output a test pattern. 5. Press the system menu key. 6. Change the setting value using the +/- or numeric keys. Increasing the value makes the margin wider, and decreasing it makes the margin narrower. <div data-bbox="558 1093 1141 1489" style="text-align: center;"> </div> <p style="text-align: center;">Figure 1-3-24</p> <ol style="list-style-type: none"> 7. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="284 1720 829 1796" style="text-align: center;"> <pre> graph LR U402[U402] --> U403[U403 (P.1-3-82)] U403 --> U404[U404 (P.1-3-83)] </pre> </div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	LEAD	Printer leading edge margin	0 to 10.0	4.0	0.1 mm	A	Printer left margin	0 to 10.0	3.0	0.1 mm	C	Printer right margin	0 to 10.0	3.0	0.1 mm	TRAIL	Printer trailing edge margin	0 to 10.0	3.9	0.1 mm	TRAIL(DUP)	Printer trailing edge margin (second side)	0 to 10.0	4.0	0.1 mm	TRAIL(MPT)	Printer trailing edge margin (MP tray)	0 to 10.0	4.0	0.1 mm
Display	Description	Setting range	Initial setting	Change in value per step																																
LEAD	Printer leading edge margin	0 to 10.0	4.0	0.1 mm																																
A	Printer left margin	0 to 10.0	3.0	0.1 mm																																
C	Printer right margin	0 to 10.0	3.0	0.1 mm																																
TRAIL	Printer trailing edge margin	0 to 10.0	3.9	0.1 mm																																
TRAIL(DUP)	Printer trailing edge margin (second side)	0 to 10.0	4.0	0.1 mm																																
TRAIL(MPT)	Printer trailing edge margin (MP tray)	0 to 10.0	4.0	0.1 mm																																

Maintenance item No.	Description																												
<p>U403</p>	<p>Adjusting margins for scanning an original on the platen</p> <p>Description Adjusts margins for scanning the original on the contact glass.</p> <p>Purpose Make the adjustment if margins are incorrect.</p> <p>Adjustment</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be adjusted. <table border="1" data-bbox="331 533 1396 772"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>A MARGIN</td> <td>Scanner left margin</td> <td>0 to 10.0</td> <td>2.0</td> <td>0.5 mm</td> </tr> <tr> <td>B MARGIN</td> <td>Scanner leading edge margin</td> <td>0 to 10.0</td> <td>2.0</td> <td>0.5 mm</td> </tr> <tr> <td>C MARGIN</td> <td>Scanner right margin</td> <td>0 to 10.0</td> <td>2.0</td> <td>0.5 mm</td> </tr> <tr> <td>D MARGIN</td> <td>Scanner trailing edge margin</td> <td>0 to 10.0</td> <td>2.0</td> <td>0.5 mm</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the system menu key. 4. Place an original and press the start key to make a test copy. 5. Press the system menu key. 6. Change the setting value using the +/- keys. Increasing the value makes the margin wider, and decreasing it makes the margin narrower. <div data-bbox="539 952 1165 1400" style="text-align: center;"> <p>The diagram shows a rectangular scanner bed with four margin indicators. At the top, a vertical double-headed arrow indicates the 'Scanner leading edge margin' with a range of $(3.0 \pm 2.5 \text{ mm})$. On the left side, a horizontal double-headed arrow indicates the 'Scanner left margin' with a range of $(2.5 + 1.5/-2.0 \text{ mm})$. On the right side, a horizontal double-headed arrow indicates the 'Scanner right margin' with a range of $(2.5 + 1.5/-2.0 \text{ mm})$. At the bottom, a vertical double-headed arrow indicates the 'Scanner trailing edge margin' with a range of $(3.0 \pm 2.0 \text{ mm})$.</p> </div> <p style="text-align: center;">Figure 1-3-25</p> <ol style="list-style-type: none"> 7. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="287 1635 622 1713" style="text-align: center;"> <table border="1"> <tr> <td style="padding: 5px;">U403</td> <td style="text-align: center; vertical-align: middle;">→</td> <td style="padding: 5px;">U404 (P.1-3-83)</td> </tr> </table> </div> <p>Completion Press the stop key. The indication for selecting a maintenance item No. appears.</p>	Display	Description	Setting range	Initial setting	Change in value per step	A MARGIN	Scanner left margin	0 to 10.0	2.0	0.5 mm	B MARGIN	Scanner leading edge margin	0 to 10.0	2.0	0.5 mm	C MARGIN	Scanner right margin	0 to 10.0	2.0	0.5 mm	D MARGIN	Scanner trailing edge margin	0 to 10.0	2.0	0.5 mm	U403	→	U404 (P.1-3-83)
Display	Description	Setting range	Initial setting	Change in value per step																									
A MARGIN	Scanner left margin	0 to 10.0	2.0	0.5 mm																									
B MARGIN	Scanner leading edge margin	0 to 10.0	2.0	0.5 mm																									
C MARGIN	Scanner right margin	0 to 10.0	2.0	0.5 mm																									
D MARGIN	Scanner trailing edge margin	0 to 10.0	2.0	0.5 mm																									
U403	→	U404 (P.1-3-83)																											

Maintenance item No.	Description																																													
U404	<p>Adjusting margins for scanning an original from the DP</p> <p>Description Adjusts margins for scanning the original from the DP.</p> <p>Purpose Make the adjustment if margins are incorrect when the DP is used.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode.</p> <div style="text-align: center;">  <pre> graph LR U402["U402 (P.1-3-81)"] --> U403["U403 (P.1-3-82)"] U403 --> U404["U404"] </pre> </div> <p>Adjustment</p> <ol style="list-style-type: none"> Press the start key. Select the item to be adjusted. <table border="1" data-bbox="331 712 1396 1236"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>A MARGIN</td> <td>Left margin</td> <td>0 to 10.0</td> <td>3.0</td> <td>0.5 mm</td> </tr> <tr> <td>B MARGIN</td> <td>Leading edge margin</td> <td>0 to 10.0</td> <td>2.5</td> <td>0.5 mm</td> </tr> <tr> <td>C MARGIN</td> <td>Right margin</td> <td>0 to 10.0</td> <td>3.0</td> <td>0.5 mm</td> </tr> <tr> <td>D MARGIN</td> <td>Trailing edge margin</td> <td>0 to 10.0</td> <td>4.0</td> <td>0.5 mm</td> </tr> <tr> <td>A MARGIN (BACK)*</td> <td>Left margin (second side)</td> <td>0 to 10.0</td> <td>3.0</td> <td>0.5 mm</td> </tr> <tr> <td>B MARGIN (BACK)*</td> <td>Leading edge margin (second side)</td> <td>0 to 10.0</td> <td>2.5</td> <td>0.5 mm</td> </tr> <tr> <td>C MARGIN (BACK)*</td> <td>Right margin (second side)</td> <td>0 to 10.0</td> <td>3.0</td> <td>0.5 mm</td> </tr> <tr> <td>D MARGIN (BACK)*</td> <td>Trailing edge margin (second side)</td> <td>0 to 10.0</td> <td>4.0</td> <td>0.5 mm</td> </tr> </tbody> </table> <p>*: Dual scan DP only.</p> <ol style="list-style-type: none"> Press the system menu key. Place an original on the DP and press the start key to make a test copy. Press the system menu key. Change the setting value using the +/- keys. Increasing the value makes the margin wider, and decreasing it makes the margin narrower. <div style="text-align: center;">  </div> <p>Figure 1-3-26</p> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	A MARGIN	Left margin	0 to 10.0	3.0	0.5 mm	B MARGIN	Leading edge margin	0 to 10.0	2.5	0.5 mm	C MARGIN	Right margin	0 to 10.0	3.0	0.5 mm	D MARGIN	Trailing edge margin	0 to 10.0	4.0	0.5 mm	A MARGIN (BACK)*	Left margin (second side)	0 to 10.0	3.0	0.5 mm	B MARGIN (BACK)*	Leading edge margin (second side)	0 to 10.0	2.5	0.5 mm	C MARGIN (BACK)*	Right margin (second side)	0 to 10.0	3.0	0.5 mm	D MARGIN (BACK)*	Trailing edge margin (second side)	0 to 10.0	4.0	0.5 mm
Display	Description	Setting range	Initial setting	Change in value per step																																										
A MARGIN	Left margin	0 to 10.0	3.0	0.5 mm																																										
B MARGIN	Leading edge margin	0 to 10.0	2.5	0.5 mm																																										
C MARGIN	Right margin	0 to 10.0	3.0	0.5 mm																																										
D MARGIN	Trailing edge margin	0 to 10.0	4.0	0.5 mm																																										
A MARGIN (BACK)*	Left margin (second side)	0 to 10.0	3.0	0.5 mm																																										
B MARGIN (BACK)*	Leading edge margin (second side)	0 to 10.0	2.5	0.5 mm																																										
C MARGIN (BACK)*	Right margin (second side)	0 to 10.0	3.0	0.5 mm																																										
D MARGIN (BACK)*	Trailing edge margin (second side)	0 to 10.0	4.0	0.5 mm																																										

Maintenance item No.	Description										
<p>U407</p>	<p>Adjusting the leading edge registration for memory image printing</p> <p>Description Adjusts the leading edge registration during memory copying.</p> <p>Purpose Make the following adjustment if there is a regular error between the leading edge of the copy image on the front face and that on the reverse face during duplex switchback copying.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode.</p> <div data-bbox="288 539 1315 703" style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <pre> graph LR U034["U034 (P.1-3-22)"] --> U402["U402 (P.1-3-81)"] U402 --> U066["U066 (P.1-3-29)"] U066 --> U403["U403 (P.1-3-82)"] U403 --> U071["U071 (P.1-3-34)"] U071 --> Arrow1[] U404["U404 (P.1-3-83)"] --> U407["U407"] </pre> </div> <p>Adjustment</p> <ol style="list-style-type: none"> Press the start key. <table border="1" data-bbox="333 810 1398 954" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>ADJUST DATA</td> <td>Leading edge registration for memory image printing</td> <td>-47 to 47</td> <td>0</td> <td>0.1 mm</td> </tr> </tbody> </table> <ol style="list-style-type: none"> Press the system menu key. Place an original and press the start key to make a test copy. Press the system menu key. Change the setting value using the +/- or numeric keys. For copy example 1, decrease the value. For copy example 2, increase the value. <div data-bbox="647 1160 1056 1397" style="text-align: center; margin: 10px 0;">  <p style="display: flex; justify-content: space-around; margin-top: 5px;"> Original Copy example 1 Copy example 2 </p> </div> <p style="text-align: center;">Figure 1-3-27</p> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	ADJUST DATA	Leading edge registration for memory image printing	-47 to 47	0	0.1 mm
Display	Description	Setting range	Initial setting	Change in value per step							
ADJUST DATA	Leading edge registration for memory image printing	-47 to 47	0	0.1 mm							

Maintenance item No.	Description										
U410	<p>Adjusting the halftone automatically</p> <p>Description Carries out processing for the data acquisition that is required in order to perform automatic adjustment of the halftone.</p> <p>Purpose Performed when the quality of reproduced halftones has dropped.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [EXECUTE]. 3. Press the start key. A test pattern is outputted. 4. Place the output test pattern as the original. Align the corner inside the circle with the left inside corner of the original marker. <div data-bbox="715 672 986 1025" style="text-align: center;"> </div> <p style="text-align: center;">Test pattern</p> <p style="text-align: center;">Figure 1-3-28</p> <ol style="list-style-type: none"> 5. Place approximately 20 sheets of white paper on the test pattern and set them. 6. Press the start key. Adjustment is made. 7. When normally completed, [ALL COMP.] is displayed. If a problem occurs during auto adjustment, error code is displayed. <p>Error codes</p> <table border="1" data-bbox="331 1332 1396 1529"> <thead> <tr> <th>Codes</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>S01</td> <td>Patch not detected</td> </tr> <tr> <td>S02</td> <td>Original deviation in the main scanning direction</td> </tr> <tr> <td>S03</td> <td>Original deviation in the auxiliary scanning direction</td> </tr> <tr> <td>S04</td> <td>Original inclination error</td> </tr> </tbody> </table> <p>If [S**] appears, check the original. If [C**] appears, execute again maintenance item U410.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Codes	Description	S01	Patch not detected	S02	Original deviation in the main scanning direction	S03	Original deviation in the auxiliary scanning direction	S04	Original inclination error
Codes	Description										
S01	Patch not detected										
S02	Original deviation in the main scanning direction										
S03	Original deviation in the auxiliary scanning direction										
S04	Original inclination error										

Maintenance item No.	Description																										
<p>U411</p>	<p>Adjusting the scanner automatically</p> <p>Description Uses a specified original and automatically adjusts the following items in the scanner and the DP scanning sections.</p> <p>Purpose To perform automatic adjustment of various items in the scanner and the DP scanning sections.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. The screen for executing is displayed. <table border="1" data-bbox="333 562 1398 819"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Original to be used for adjustment (P/N)</th> </tr> </thead> <tbody> <tr> <td>SCANNER</td> <td>Automatic adjustment in the scanner section</td> <td>302FZ56990</td> </tr> <tr> <td>DP(FACE UP)</td> <td>Automatic adjustment in the DP scanning section (first page)</td> <td>302AC68243</td> </tr> <tr> <td>DP(FACE DOWN)*</td> <td>Automatic adjustment in the DP scanning section (second page)</td> <td>302AC68243/303JX57010/ 303JX57020</td> </tr> </tbody> </table> <p>*: Dual scan DP only.</p> <p>Method: [SCANNER]</p> <ol style="list-style-type: none"> 1. Enter the target values which are shown on the specified original (P/N: 302FZ56990) executing maintenance item U425. 2. Set a specified original (P/N: 302FZ56990) on the platen. 3. Select the item. <table border="1" data-bbox="333 1041 1398 1422"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ALL</td> <td>Automatic adjustment using the platen for: original size magnification/ leading edge timing/center line, input gamma, chromatic aberration filter, MTF filter and matrix.</td> </tr> <tr> <td>INPUT</td> <td>Automatic adjustment using the platen for: original size magnification/ leading edge timing/center line.</td> </tr> <tr> <td>C.A.</td> <td>Automatic adjustment using the platen for: chromatic aberration filter.</td> </tr> <tr> <td>MTF</td> <td>Automatic adjustment using the platen for: MTF filter.</td> </tr> <tr> <td>GAMMA</td> <td>Automatic adjustment using the platen for: input gamma.</td> </tr> <tr> <td>MATRIX</td> <td>Automatic adjustment using the platen for: matrix.</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. Auto adjustment starts. When automatic adjustment has normally completed, [Complete] is displayed. If a problem occurs during auto adjustment, [ERROR XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and either repeat the procedure from the beginning, or adjust the remaining items manually by running the corresponding maintenance items. 	Display	Description	Original to be used for adjustment (P/N)	SCANNER	Automatic adjustment in the scanner section	302FZ56990	DP(FACE UP)	Automatic adjustment in the DP scanning section (first page)	302AC68243	DP(FACE DOWN)*	Automatic adjustment in the DP scanning section (second page)	302AC68243/303JX57010/ 303JX57020	Display	Description	ALL	Automatic adjustment using the platen for: original size magnification/ leading edge timing/center line, input gamma, chromatic aberration filter, MTF filter and matrix.	INPUT	Automatic adjustment using the platen for: original size magnification/ leading edge timing/center line.	C.A.	Automatic adjustment using the platen for: chromatic aberration filter.	MTF	Automatic adjustment using the platen for: MTF filter.	GAMMA	Automatic adjustment using the platen for: input gamma.	MATRIX	Automatic adjustment using the platen for: matrix.
Display	Description	Original to be used for adjustment (P/N)																									
SCANNER	Automatic adjustment in the scanner section	302FZ56990																									
DP(FACE UP)	Automatic adjustment in the DP scanning section (first page)	302AC68243																									
DP(FACE DOWN)*	Automatic adjustment in the DP scanning section (second page)	302AC68243/303JX57010/ 303JX57020																									
Display	Description																										
ALL	Automatic adjustment using the platen for: original size magnification/ leading edge timing/center line, input gamma, chromatic aberration filter, MTF filter and matrix.																										
INPUT	Automatic adjustment using the platen for: original size magnification/ leading edge timing/center line.																										
C.A.	Automatic adjustment using the platen for: chromatic aberration filter.																										
MTF	Automatic adjustment using the platen for: MTF filter.																										
GAMMA	Automatic adjustment using the platen for: input gamma.																										
MATRIX	Automatic adjustment using the platen for: matrix.																										

Maintenance item No.	Description																									
U411	<p>Method: [DP(FACE UP)]</p> <ol style="list-style-type: none"> 1. Measure the leading edge, main scanning, and auxiliary scanning of the specified original (P/N: 302AC68243) and enter the values by executing maintenance item U425. 2. Set a specified original (P/N: 302AC68243) in the DP. Cut the trailing edge of the original. <div data-bbox="483 405 1222 663" style="text-align: center;"> </div> <p style="text-align: center;">Figure 1-3-29</p> <ol style="list-style-type: none"> 3. Press [INPUT]. <table border="1" data-bbox="333 781 1398 898"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>INPUT</td> <td>Automatic adjustment of first page using the DP for: original size magnification/leading edge timing/center line.</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. Auto adjustment starts. When automatic adjustment has normally completed, [Complete] is displayed. If a problem occurs during auto adjustment, [ERROR XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and either repeat the procedure from the beginning, or adjust the remaining items manually by running the corresponding maintenance items. <p>Method: [DP(FACE DOWN)]</p> <ol style="list-style-type: none"> 1. Select [ORIGINAL TARGET] and press the start key. The screen for executing is displayed. <table border="1" data-bbox="333 1146 1398 1272"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>NORMAL TARGET</td> <td>Execution is not required.</td> </tr> <tr> <td>ORIGINAL TARGET</td> <td>Uses the specified original for acquiring data as the target data.</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 2. Place the specified original for acquiring gamma target data (P/N: 303JX57010) on the platen, and press the start key. 3. Place the specified original for acquiring matrix target data (P/N: 303JX57020) on the platen, and press the start key. When normally completed, [Complete] is displayed. 4. Select the item (place all originals face down). <table border="1" data-bbox="333 1460 1398 1910"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Original to be used for adjustment (P/N)</th> </tr> </thead> <tbody> <tr> <td>ALL</td> <td>Automatic adjustment of second page using the DP for: original size magnification/leading edge timing/center line, input gamma, chromatic aberration filter, MTF filter and matrix.</td> <td>302AC68243/303JX57010/ 303JX57020</td> </tr> <tr> <td>INPUT</td> <td>Automatic adjustment of second page using the DP for: original size magnification/leading edge timing/center line.</td> <td>302AC68243</td> </tr> <tr> <td>MTF/GAMMA</td> <td>Automatic adjustment of second page using the DP for: MTF filter and input gamma.</td> <td>303JX57010</td> </tr> <tr> <td>MATRIX</td> <td>Automatic adjustment of second page using the DP for: matrix.</td> <td>303JX57020</td> </tr> </tbody> </table>	Display	Description	INPUT	Automatic adjustment of first page using the DP for: original size magnification/leading edge timing/center line.	Display	Description	NORMAL TARGET	Execution is not required.	ORIGINAL TARGET	Uses the specified original for acquiring data as the target data.	Display	Description	Original to be used for adjustment (P/N)	ALL	Automatic adjustment of second page using the DP for: original size magnification/leading edge timing/center line, input gamma, chromatic aberration filter, MTF filter and matrix.	302AC68243/303JX57010/ 303JX57020	INPUT	Automatic adjustment of second page using the DP for: original size magnification/leading edge timing/center line.	302AC68243	MTF/GAMMA	Automatic adjustment of second page using the DP for: MTF filter and input gamma.	303JX57010	MATRIX	Automatic adjustment of second page using the DP for: matrix.	303JX57020
Display	Description																									
INPUT	Automatic adjustment of first page using the DP for: original size magnification/leading edge timing/center line.																									
Display	Description																									
NORMAL TARGET	Execution is not required.																									
ORIGINAL TARGET	Uses the specified original for acquiring data as the target data.																									
Display	Description	Original to be used for adjustment (P/N)																								
ALL	Automatic adjustment of second page using the DP for: original size magnification/leading edge timing/center line, input gamma, chromatic aberration filter, MTF filter and matrix.	302AC68243/303JX57010/ 303JX57020																								
INPUT	Automatic adjustment of second page using the DP for: original size magnification/leading edge timing/center line.	302AC68243																								
MTF/GAMMA	Automatic adjustment of second page using the DP for: MTF filter and input gamma.	303JX57010																								
MATRIX	Automatic adjustment of second page using the DP for: matrix.	303JX57020																								


Maintenance item No.	Description
U411	<p>[INPUT]</p> <ol style="list-style-type: none"> 1. Select [INPUT]. 2. Place a specified original (P/N: 302AC68243). 3. Press the start key. Auto adjustment starts. <p>[MTF/GAMMA]</p> <ol style="list-style-type: none"> 1. Select [MTF/GAMMA]. 2. Place a specified original (P/N: 303JX57010). 3. Press the start key. Auto adjustment starts. <p>[MATRIX]</p> <ol style="list-style-type: none"> 1. Select [MATRIX]. 2. Place a specified original (P/N: 303JX57020). 3. Press the start key. Auto adjustment starts. <p>When [ALL] is selected, the adjustment of [INPUT], [MTF/GAMMA] and [MATRIX] can be executed at once. When adjusting, place the three specified originals, and then press the start key. Set the original 303JX57020, and then place 303JX57010 and 302AC68243 in order on the top of the original.</p> <p>When automatic adjustment has normally completed, [COMPLETE] is displayed. If a problem occurs during auto adjustment, [ERROR XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and either repeat the procedure from the beginning, or adjust the remaining items manually by running the corresponding maintenance items.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item is displayed.</p>

Maintenance item No.	Description	
U411	Error Codes	
	Codes	Description
	ERROR 01	Black band detection error (scanner leading edge registration)
	ERROR 02	Black band detection error (scanner center line)
	ERROR 03	Black band detection error (scanner main scanning direction magnification)
	ERROR 04	Black band is not detected (scanner leading edge registration)
	ERROR 05	Black band is not detected (scanner center line)
	ERROR 06	Black band is not detected (scanner main scanning direction magnification)
	ERROR 07	Black band is not detected (scanner auxiliary scanning direction magnification)
	ERROR 08	Black band is not detected (DP main scanning direction magnification far end)
	ERROR 09	Black band is not detected (DP main scanning direction magnification near end)
	ERROR 0a	Black band is not detected (DP auxiliary scanning direction magnification leading edge)
	ERROR 0b	Black band is not detected (DP auxiliary scanning direction magnification leading edge original check)
	ERROR 0c	Black band is not detected (DP auxiliary scanning direction trailing edge)
	ERROR 0d	Black band is not detected (DP auxiliary scanning direction trailing edge 2)
	ERROR 0e	DMA time out
	ERROR 0f	Auxiliary scanning direction magnification error
	ERROR 10	Auxiliary scanning direction leading edge detection error
	ERROR 11	Auxiliary scanning direction trailing edge detection error
	ERROR 12	Auxiliary scanning direction skew 1.5 error
	ERROR 13	Maintenance request error
	ERROR 14	Main scanning direction center line error
	ERROR 15	Main scanning direction skew 1.5 error
	ERROR 16	Main scanning direction magnification error
	ERROR 17	Service call error
	ERROR 18	DP JAM error
	ERROR 19	PWB error
	ERROR 1a	Original error

Maintenance item No.	Description																																										
U425	<p>Setting the target</p> <p>Description Enters the lab values that is indicated on the back of the chart (P/N: 302FZ56990) used for adjustment. Also enters the measurement value of the chart (P/N: 302AC68243) used for adjustment.</p> <p>Purpose Performs data input in order to correct for differences in originals during automatic adjustment.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 566 1398 790"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>CCD</td> <td>Entering the target values of the chart (P/N: 302FZ56990) used for adjustment</td> </tr> <tr> <td>DP</td> <td>Entering the measurement value of the chart (P/N: 302AC68243) used for adjustment</td> </tr> <tr> <td>CIS</td> <td>Execution is not required</td> </tr> </tbody> </table> <p>Setting: [CCD]</p> <ol style="list-style-type: none"> 1. Select the item to be set. <table border="1" data-bbox="336 898 1398 1352"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>N875</td> <td>Setting the N875 patch for the original for adjustment</td> </tr> <tr> <td>N475</td> <td>Setting the N475 patch for the original for adjustment</td> </tr> <tr> <td>N125</td> <td>Setting the N125 patch for the original for adjustment</td> </tr> <tr> <td>CYAN</td> <td>Setting the cyan patch for the original for adjustment</td> </tr> <tr> <td>MAGENTA</td> <td>Setting the magenta patch for the original for adjustment</td> </tr> <tr> <td>YELLOW</td> <td>Setting the yellow patch for the original for adjustment</td> </tr> <tr> <td>RED</td> <td>Setting the red patch for the original for adjustment</td> </tr> <tr> <td>GREEN</td> <td>Setting the green patch for the original for adjustment</td> </tr> <tr> <td>BLUE</td> <td>Setting the blue patch for the original for adjustment</td> </tr> <tr> <td>ADJUST ORIGINAL</td> <td>Setting the main and auxiliary scanning directions</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 2. Select the item to be set. <table border="1" data-bbox="336 1404 1398 1570"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> </tr> </thead> <tbody> <tr> <td>L</td> <td>Setting the L value</td> <td>0.0 to 100.0</td> </tr> <tr> <td>A</td> <td>Setting the A value</td> <td>-200.0 to 200.0</td> </tr> <tr> <td>B</td> <td>Setting the B value</td> <td>-200.0 to 200.0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Enters the value that is indicated on the back of the chart using the +/- or numeric keys. 4. Press the start key. The value is set. 	Display	Description	CCD	Entering the target values of the chart (P/N: 302FZ56990) used for adjustment	DP	Entering the measurement value of the chart (P/N: 302AC68243) used for adjustment	CIS	Execution is not required	Display	Description	N875	Setting the N875 patch for the original for adjustment	N475	Setting the N475 patch for the original for adjustment	N125	Setting the N125 patch for the original for adjustment	CYAN	Setting the cyan patch for the original for adjustment	MAGENTA	Setting the magenta patch for the original for adjustment	YELLOW	Setting the yellow patch for the original for adjustment	RED	Setting the red patch for the original for adjustment	GREEN	Setting the green patch for the original for adjustment	BLUE	Setting the blue patch for the original for adjustment	ADJUST ORIGINAL	Setting the main and auxiliary scanning directions	Display	Description	Setting range	L	Setting the L value	0.0 to 100.0	A	Setting the A value	-200.0 to 200.0	B	Setting the B value	-200.0 to 200.0
Display	Description																																										
CCD	Entering the target values of the chart (P/N: 302FZ56990) used for adjustment																																										
DP	Entering the measurement value of the chart (P/N: 302AC68243) used for adjustment																																										
CIS	Execution is not required																																										
Display	Description																																										
N875	Setting the N875 patch for the original for adjustment																																										
N475	Setting the N475 patch for the original for adjustment																																										
N125	Setting the N125 patch for the original for adjustment																																										
CYAN	Setting the cyan patch for the original for adjustment																																										
MAGENTA	Setting the magenta patch for the original for adjustment																																										
YELLOW	Setting the yellow patch for the original for adjustment																																										
RED	Setting the red patch for the original for adjustment																																										
GREEN	Setting the green patch for the original for adjustment																																										
BLUE	Setting the blue patch for the original for adjustment																																										
ADJUST ORIGINAL	Setting the main and auxiliary scanning directions																																										
Display	Description	Setting range																																									
L	Setting the L value	0.0 to 100.0																																									
A	Setting the A value	-200.0 to 200.0																																									
B	Setting the B value	-200.0 to 200.0																																									

Maintenance item No.	Description
U425	<p>Setting: [ADJUST ORIGINAL]</p> <ol style="list-style-type: none"> 1. Measure the distance from the left edge to the black belt (a) of the original at A, B and C. Measurement procedure <ol style="list-style-type: none"> 1) Measure the distance from the edge to the black belt (a) of the original at A (35 mm from the leading edge), B (110 mm from the leading edge) and C (185 mm from the leading edge), respectively. 2) Apply the following formula for the values obtained: $((A + C) / 2 + B) / 2$ 2. Enter the values solved using the +/- keys in [MAIN ADJ]. 3. Press the start key. The value is set. 4. Measure the distance from the leading edge to the black belt (b) of the original at D, E and F. Measurement procedure <ol style="list-style-type: none"> 1) Measure the length from the edge to the black belt (b) of the original at D (30 mm from the left edge), E (148.5 mm from the left edge) and F (267 mm from the left edge), respectively. 2) Apply the following formula for the values obtained: $((D + F) / 2 + E) / 2$ 5. Enter the values solved using the +/- keys in [SUB LEAD ADJ]. 6. Press the start key. The value is set. 7. Measure the length (G) from the leading edge of the black belt (b) to the bottom of the N475 patch of the original. 8. Enter the measured value using the +/- keys in [SUB TAIL ADJ]. 9. Press the start key. The value is set. 10. To return to the screen for selecting an item, press the stop key. <div style="text-align: center;"> <p>Original for adjustment (P/N: 302FZ56990)</p> </div> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-left: auto; margin-right: auto;"> <p>[MAIN ADJ] = $((A + C) / 2 + B) / 2$</p> <p>[SUB LEAD ADJ] = $((D + F) / 2 + E) / 2$</p> <p>[SUB TAIL ADJ] = G</p> </div>

Figure 1-3-30

Maintenance item No.	Description
U425	<p>Setting: [DP]</p> <ol style="list-style-type: none"> 1. Measure the distance from the leading edge to the black belt (inside) of the original at A. 2. Enter the measured value using the +/- keys in [LEAD]. 3. Measure the distance from the left edge to the black belt (inside) of the original at B. 4. Enter the measured value using the +/- keys in [MAIN SCAN]. 5. Measure the distance from the black belt of leading edge (inside) to the black belt of trailing edge (inside) of the original at C. 6. Enter the measured value using the +/- keys in [SUB SCAN]. 7. Press the start key. The value is set. <div style="text-align: center;">  <p>Original for adjustment (P/N: 302AC68243)</p> </div> <p>Figure 1-3-31</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Maintenance item No.	Description																																																																				
U470	<p>Setting the JPEG compression ratio</p> <p>Description Sets the compression ratio for JPEG images in each image quality mode.</p> <p>Purpose To change the setting in accordance with the image that the user is copying. For example, in order to soften the coarseness of the image when making copies at over 200% magnification, change the level of compression by raising the value. Lowering the value will increase the compression and thereby lower the image quality; Raising the value will increase image quality but lower the image processing speed.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. The setting screen for the selected item is displayed. <table border="1" data-bbox="331 613 1398 781"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>System</td> <td>Compression ratio for temporary storage in system</td> </tr> <tr> <td>Copy</td> <td>Compression ratio for copying</td> </tr> <tr> <td>Send</td> <td>Compression ratio for sending</td> </tr> </tbody> </table> <p>Setting: [System]</p> <ol style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the +/- or numeric keys. <table border="1" data-bbox="331 909 1398 1032"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Y</td> <td>Brightness</td> <td>1 to 100</td> <td>90</td> </tr> <tr> <td>C</td> <td>Color differential</td> <td>1 to 100</td> <td>90</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Setting: [Copy]</p> <ol style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the +/- or numeric keys. <table border="1" data-bbox="331 1193 1398 1402"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Text Y</td> <td>Brightness in the text mode</td> <td>1 to 100</td> <td>90</td> </tr> <tr> <td>Text C</td> <td>Color differential in the text mode</td> <td>1 to 100</td> <td>90</td> </tr> <tr> <td>Photo Y</td> <td>Brightness in the photo mode</td> <td>1 to 100</td> <td>90</td> </tr> <tr> <td>Photo C</td> <td>Color differential in the photo mode</td> <td>1 to 100</td> <td>90</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Setting: [Send]</p> <ol style="list-style-type: none"> 1. Select [Text], [Photo] or [HC-PDF]. 2. Select the item to be set. 3. Change the setting value using the +/- or numeric keys. <table border="1" data-bbox="331 1592 1398 1912"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Text Y (1) to (5)</td> <td>Brightness in the text mode</td> <td>1 to 100</td> <td>30/40/51/70/90</td> </tr> <tr> <td>Text C (1) to (5)</td> <td>Color differential in the text mode</td> <td>1 to 100</td> <td>30/40/51/70/90</td> </tr> <tr> <td>Photo Y (1) to (5)</td> <td>Brightness in the photo mode</td> <td>1 to 100</td> <td>30/40/51/70/90</td> </tr> <tr> <td>Photo C (1) to (5)</td> <td>Color differential in the photo mode</td> <td>1 to 100</td> <td>30/40/51/70/90</td> </tr> <tr> <td>HC-PDF Y (1) to (3)</td> <td>Brightness of high compression PDF</td> <td>1 to 100</td> <td>15/25/60</td> </tr> <tr> <td>HC-PDF C (1) to (3)</td> <td>Color differential of high compression PDF</td> <td>1 to 100</td> <td>15/25/60</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. The value is set. 	Display	Description	System	Compression ratio for temporary storage in system	Copy	Compression ratio for copying	Send	Compression ratio for sending	Display	Description	Setting range	Initial setting	Y	Brightness	1 to 100	90	C	Color differential	1 to 100	90	Display	Description	Setting range	Initial setting	Text Y	Brightness in the text mode	1 to 100	90	Text C	Color differential in the text mode	1 to 100	90	Photo Y	Brightness in the photo mode	1 to 100	90	Photo C	Color differential in the photo mode	1 to 100	90	Display	Description	Setting range	Initial setting	Text Y (1) to (5)	Brightness in the text mode	1 to 100	30/40/51/70/90	Text C (1) to (5)	Color differential in the text mode	1 to 100	30/40/51/70/90	Photo Y (1) to (5)	Brightness in the photo mode	1 to 100	30/40/51/70/90	Photo C (1) to (5)	Color differential in the photo mode	1 to 100	30/40/51/70/90	HC-PDF Y (1) to (3)	Brightness of high compression PDF	1 to 100	15/25/60	HC-PDF C (1) to (3)	Color differential of high compression PDF	1 to 100	15/25/60
Display	Description																																																																				
System	Compression ratio for temporary storage in system																																																																				
Copy	Compression ratio for copying																																																																				
Send	Compression ratio for sending																																																																				
Display	Description	Setting range	Initial setting																																																																		
Y	Brightness	1 to 100	90																																																																		
C	Color differential	1 to 100	90																																																																		
Display	Description	Setting range	Initial setting																																																																		
Text Y	Brightness in the text mode	1 to 100	90																																																																		
Text C	Color differential in the text mode	1 to 100	90																																																																		
Photo Y	Brightness in the photo mode	1 to 100	90																																																																		
Photo C	Color differential in the photo mode	1 to 100	90																																																																		
Display	Description	Setting range	Initial setting																																																																		
Text Y (1) to (5)	Brightness in the text mode	1 to 100	30/40/51/70/90																																																																		
Text C (1) to (5)	Color differential in the text mode	1 to 100	30/40/51/70/90																																																																		
Photo Y (1) to (5)	Brightness in the photo mode	1 to 100	30/40/51/70/90																																																																		
Photo C (1) to (5)	Color differential in the photo mode	1 to 100	30/40/51/70/90																																																																		
HC-PDF Y (1) to (3)	Brightness of high compression PDF	1 to 100	15/25/60																																																																		
HC-PDF C (1) to (3)	Color differential of high compression PDF	1 to 100	15/25/60																																																																		

Maintenance item No.	Description														
<p>U470</p>	<p>Supplement While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>														
<p>U473</p>	<p>Adjusting laser power output Description Adjusts the laser output power Purpose Performed when the quality of dots, lines or low density has dropped.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Set Density (EmitTime/Dot)]. 3. Select the item. <table border="1" data-bbox="331 779 1398 987"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0 (100%)</td> <td>LSU laser output (100%)</td> </tr> <tr> <td>1 (90%)</td> <td>LSU laser output (90%)</td> </tr> <tr> <td>2 (80%)</td> <td>LSU laser output (80%)</td> </tr> <tr> <td>3 (70%)</td> <td>LSU laser output (70%)</td> </tr> </tbody> </table> <p>Initial setting: 0</p> <ol style="list-style-type: none"> 4. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	0 (100%)	LSU laser output (100%)	1 (90%)	LSU laser output (90%)	2 (80%)	LSU laser output (80%)	3 (70%)	LSU laser output (70%)				
Display	Description														
0 (100%)	LSU laser output (100%)														
1 (90%)	LSU laser output (90%)														
2 (80%)	LSU laser output (80%)														
3 (70%)	LSU laser output (70%)														
<p>U485</p>	<p>Setting the image processing mode Description Adjusts the sensitivity of scanning a confidential document. Changes how to apply rotation to a PDF document.</p> <p>Purpose To change the detection level when the confidential document guard is not printed well for detection in scanning. Also, changes the process of how PDF images are rotated.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="331 1512 1398 1637"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Conf. Doc. Detection</td> <td>Confidential document guard detection level</td> </tr> <tr> <td>PDF Rotate</td> <td>Processing the rotation of PDF images</td> </tr> </tbody> </table> <p>Setting: [Conf. Doc. Detection]</p> <ol style="list-style-type: none"> 1. Change the setting value using +/- or numeric keys. <table border="1" data-bbox="331 1738 1398 1852"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Conf. Doc. Detection</td> <td>Confidential document guard detection level</td> <td>1 to 5</td> <td>1</td> </tr> </tbody> </table> <p>A smaller value raises the detection sensitivity but increases the possibility of false detection. A larger value lowers the detection sensitivity but decreases the possibility of false detection.</p> <ol style="list-style-type: none"> 2. Press the start key. The value is set. 	Display	Description	Conf. Doc. Detection	Confidential document guard detection level	PDF Rotate	Processing the rotation of PDF images	Display	Description	Setting range	Initial setting	Conf. Doc. Detection	Confidential document guard detection level	1 to 5	1
Display	Description														
Conf. Doc. Detection	Confidential document guard detection level														
PDF Rotate	Processing the rotation of PDF images														
Display	Description	Setting range	Initial setting												
Conf. Doc. Detection	Confidential document guard detection level	1 to 5	1												

Maintenance item No.	Description										
U485	<p>Setting: [PDF Rotate]</p> <ol style="list-style-type: none"> Change the setting value using +/- or numeric keys. <table border="1" data-bbox="331 331 1398 456"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Applies rotation to the internal parameter</td> </tr> <tr> <td>1</td> <td>Applies rotation to the 'actual image' itself</td> </tr> </tbody> </table> <p>Initial setting: 0</p> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	0	Applies rotation to the internal parameter	1	Applies rotation to the 'actual image' itself				
Display	Description										
0	Applies rotation to the internal parameter										
1	Applies rotation to the 'actual image' itself										
U510	<p>Setting the enterprise mode</p> <p>Description Sets whether or not the application function is enabled.</p> <p>Purpose According to user request, changes the setting.</p> <p>Setting</p> <ol style="list-style-type: none"> Press the start key. Select [MODE1]. Select the item. <table border="1" data-bbox="331 918 1398 1128"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Application function is enabled</td> </tr> <tr> <td>OFF</td> <td>Application function is disabled</td> </tr> <tr> <td>INSTALL</td> <td>Executing the install</td> </tr> <tr> <td>UNINSTALL</td> <td>Executing the uninstall</td> </tr> </tbody> </table> <ol style="list-style-type: none"> Press the start key. The setting is set. <p>Method: [INSTALL]</p> <ol style="list-style-type: none"> Insert the USB memory that contains the application into the USB memory slot on the machine. Turn the main power switch on. Enter the maintenance item. Press the start key. Select [INSTALL]. Press the start key. Installation of application is started. When normally completed, [Complete] is displayed. <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Application function is enabled	OFF	Application function is disabled	INSTALL	Executing the install	UNINSTALL	Executing the uninstall
Display	Description										
ON	Application function is enabled										
OFF	Application function is disabled										
INSTALL	Executing the install										
UNINSTALL	Executing the uninstall										

Maintenance item No.	Description																
<p>U901</p>	<p>Checking/clearing copy counts by paper feed locations</p> <p>Description Displays or clears copy counts by paper feed locations.</p> <p>Purpose To check the time to replace consumable parts. Also to clear the counts after replacing the consumable parts.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The counts by paper feed locations are displayed. <table border="1" data-bbox="336 506 1398 837"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>MP TRAY</td> <td>MP tray</td> </tr> <tr> <td>CASSETTE 1</td> <td>Cassette 1</td> </tr> <tr> <td>CASSETTE 2</td> <td>Cassette 2</td> </tr> <tr> <td>CASSETTE 3</td> <td>Cassette 3 (optional paper feeder)</td> </tr> <tr> <td>CASSETTE 4</td> <td>Cassette 4 (optional paper feeder)</td> </tr> <tr> <td>DUPLEX</td> <td>Duplex unit</td> </tr> <tr> <td>LCF</td> <td>Optional 3000-sheet paper feeder</td> </tr> </tbody> </table> <p>When an optional paper feed device is not installed, the corresponding count is not displayed.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Select the counts to be cleared. CASSETTE 3, CASSETTE 4 and LCF cannot be cleared. 2. Select the counts for all and press [ALL CLEAR]. 3. Press the start key. The counts is cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MP TRAY	MP tray	CASSETTE 1	Cassette 1	CASSETTE 2	Cassette 2	CASSETTE 3	Cassette 3 (optional paper feeder)	CASSETTE 4	Cassette 4 (optional paper feeder)	DUPLEX	Duplex unit	LCF	Optional 3000-sheet paper feeder
Display	Description																
MP TRAY	MP tray																
CASSETTE 1	Cassette 1																
CASSETTE 2	Cassette 2																
CASSETTE 3	Cassette 3 (optional paper feeder)																
CASSETTE 4	Cassette 4 (optional paper feeder)																
DUPLEX	Duplex unit																
LCF	Optional 3000-sheet paper feeder																
<p>U902</p>	<p>Checking/clearing the punch-hole scrap counter</p> <p>Description Sets the punch limit and displays and clears the punch-hole scrap count when 3000-sheet document finisher is installed.</p> <p>Purpose Sets the punch limit to notify the user of the time to collect punch-hole scrap. Also, used to manually clear the punch-hole scrap count if a message requiring collection of punch-hole scrap is shown on the touch panel after collection. If punch-hole scrap is collected with the machine power turned off, the punch-hole scrap count is not cleared and consequently this problem occurs.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. 3. Change the value using the numeric keys. <table border="1" data-bbox="336 1536 1398 1688"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> </tr> </thead> <tbody> <tr> <td>PUNCH LIMIT (*1000)</td> <td>Punch limit (maximum number of punching times)</td> <td>0 to 9999000</td> </tr> <tr> <td>PUNCH WASTE COUNT</td> <td>Punch-hole scrap count (current number of punching times)</td> <td>0 to 9999999</td> </tr> </tbody> </table> <p>The punch limit can be set in increments of 1000.</p> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Clearing</p> <ol style="list-style-type: none"> 1. Enter 0 using the numeric keys. 2. Press the start key. The count is cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	PUNCH LIMIT (*1000)	Punch limit (maximum number of punching times)	0 to 9999000	PUNCH WASTE COUNT	Punch-hole scrap count (current number of punching times)	0 to 9999999							
Display	Description	Setting range															
PUNCH LIMIT (*1000)	Punch limit (maximum number of punching times)	0 to 9999000															
PUNCH WASTE COUNT	Punch-hole scrap count (current number of punching times)	0 to 9999999															

Maintenance item No.	Description						
U903	<p>Checking/clearing the paper jam counts</p> <p>Description Displays or clears the jam counts by jam locations.</p> <p>Purpose To check the paper jam status. Also to clear the jam counts after replacing consumable parts.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. The screen for selecting an item is displayed. <table border="1" data-bbox="333 533 1398 658"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Count</td> <td>Displays/clears the jam counts</td> </tr> <tr> <td>Total Count</td> <td>Displays the total jam counts</td> </tr> </tbody> </table> <p>Method: [Count]</p> <ol style="list-style-type: none"> 1. Select [Count]. The count of jam code by type is displayed. Codes for which the count value is 0 are not displayed. 2. Change the screen using the cursor up/down keys. 3. Select the counts for all jam codes and press [ALL CLEAR]. The individual counter cannot be cleared. 4. Press the start key. The count is cleared. <p>Method: [Total Count]</p> <ol style="list-style-type: none"> 1. Select [Total Count]. The total number of jam code by type is displayed. 2. Change the screen using the cursor up/down keys. The total number of jam count cannot be cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Count	Displays/clears the jam counts	Total Count	Displays the total jam counts
Display	Description						
Count	Displays/clears the jam counts						
Total Count	Displays the total jam counts						
U904	<p>Checking/clearing the service call counts</p> <p>Description Displays or clears the service call code counts by types.</p> <p>Purpose To check the service call code status by types. Also to clear the service call code counts after replacing consumable parts.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press the start key. The screen for selecting an item is displayed. <table border="1" data-bbox="333 1440 1398 1565"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Count</td> <td>Displays/clears the call for service counts</td> </tr> <tr> <td>Total Count</td> <td>Displays the total call for service counts</td> </tr> </tbody> </table> <p>Method: [Count]</p> <ol style="list-style-type: none"> 1. Select [Count]. The count for service call detection by type is displayed. Codes for which the count value is 0 are not displayed. 2. Change the screen using the cursor up/down keys. 3. Select the counts for all service call codes and press [ALL CLEAR]. The individual counter cannot be cleared. 4. Press the start key. The count is cleared. <p>Method: [Total Count]</p> <ol style="list-style-type: none"> 1. Select [Total Count]. The total number of service call counts by type is displayed. 2. Change the screen using the cursor up/down keys. The total number of service call count cannot be cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Count	Displays/clears the call for service counts	Total Count	Displays the total call for service counts
Display	Description						
Count	Displays/clears the call for service counts						
Total Count	Displays the total call for service counts						

Maintenance item No.	Description																																
<p>U905</p>	<p>Checking/clearing counts by optional devices</p> <p>Description Displays the counts of DP or finisher.</p> <p>Purpose To check the use of DP and finisher.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the device, the count of which is to be checked. 3. Press the start key. The count of the selected device is displayed. <table border="1" data-bbox="333 564 1398 719"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>DP</td> <td>Counts of optional DP</td> </tr> <tr> <td>FINISHER</td> <td>Counts of optional document finisher, built-in finisher or 3000-sheet document finisher</td> </tr> </tbody> </table> <p>DP</p> <table border="1" data-bbox="333 799 1398 965"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ADP</td> <td>No. of single-sided originals that has passed through the DP</td> </tr> <tr> <td>RADP</td> <td>No. of double-sided originals that has passed through the DP</td> </tr> <tr> <td>CONCURRENT</td> <td>No. of dual scan originals that has passed through the DP</td> </tr> </tbody> </table> <p>Document finisher/Built-in finisher</p> <table border="1" data-bbox="333 1041 1398 1167"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>CP CNT</td> <td>No. of copies that has passed</td> </tr> <tr> <td>STAPLE</td> <td>Frequency the stapler has been activated</td> </tr> </tbody> </table> <p>3000-sheet document finisher</p> <table border="1" data-bbox="333 1247 1398 1496"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>CP CNT</td> <td>No. of copies that has passed</td> </tr> <tr> <td>STAPLE</td> <td>Frequency the stapler has been activated</td> </tr> <tr> <td>PUNCH</td> <td>Frequency the punch has been activated</td> </tr> <tr> <td>STACK</td> <td>Frequency the stacker has been activated</td> </tr> <tr> <td>SADDLE</td> <td>Frequency the center holding has been activated</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	DP	Counts of optional DP	FINISHER	Counts of optional document finisher, built-in finisher or 3000-sheet document finisher	Display	Description	ADP	No. of single-sided originals that has passed through the DP	RADP	No. of double-sided originals that has passed through the DP	CONCURRENT	No. of dual scan originals that has passed through the DP	Display	Description	CP CNT	No. of copies that has passed	STAPLE	Frequency the stapler has been activated	Display	Description	CP CNT	No. of copies that has passed	STAPLE	Frequency the stapler has been activated	PUNCH	Frequency the punch has been activated	STACK	Frequency the stacker has been activated	SADDLE	Frequency the center holding has been activated
Display	Description																																
DP	Counts of optional DP																																
FINISHER	Counts of optional document finisher, built-in finisher or 3000-sheet document finisher																																
Display	Description																																
ADP	No. of single-sided originals that has passed through the DP																																
RADP	No. of double-sided originals that has passed through the DP																																
CONCURRENT	No. of dual scan originals that has passed through the DP																																
Display	Description																																
CP CNT	No. of copies that has passed																																
STAPLE	Frequency the stapler has been activated																																
Display	Description																																
CP CNT	No. of copies that has passed																																
STAPLE	Frequency the stapler has been activated																																
PUNCH	Frequency the punch has been activated																																
STACK	Frequency the stacker has been activated																																
SADDLE	Frequency the center holding has been activated																																
<p>U906</p>	<p>Resetting partial operation control</p> <p>Description Resets the service call code for partial operation control.</p> <p>Purpose To be reset after partial operation is performed due to problems in the cassettes or other sections, and the related parts are serviced.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press [Execute]. 3. Press the start key to reset partial operation control. 4. Turn the main power switch off and on. 																																

Maintenance item No.	Description
U908	<p>Checking the total counter value</p> <p>Description Displays the total counter value.</p> <p>Purpose To check the total counter value.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for total count value is displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>
U910	<p>Clearing the black ratio data</p> <p>Description Clears the accumulated black ratio data for A4 sheet.</p> <p>Purpose To clear data as required at times such as during maintenance service.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [EXCUTE]. 3. Press the start key. The accumulated black ratio data is cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>
U911	<p>Checking copy counts by paper sizes</p> <p>Description Displays the paper feed counts by paper sizes.</p> <p>Purpose To check the counts after replacing consumable parts.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for the paper feed counts by paper size is displayed. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>

Maintenance item No.	Description																																				
<p>U917</p>	<p>Setting backup data reading/writing</p> <p>Description Retrieves the backup data to a USB memory from the machine; or writes the data from the USB memory to the machine.</p> <p>Purpose To store and write data when replacing the HDD.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the power key on the operation panel, and after verifying the main power indicator has gone off, switch off the main power switch. 2. Insert USB memory in USB memory slot. 3. Turn the main power switch on. 4. Enter the maintenance item. 5. Press the start key. 6. Select [Export] or [Import]. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> </tr> </thead> <tbody> <tr> <td>Export</td> <td>Retrieving from the machine to a USB memory</td> </tr> <tr> <td>Import</td> <td>Writing data from the USB memory to the machine</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 7. Select the item. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> <th style="text-align: left;">Depending data*1</th> </tr> </thead> <tbody> <tr> <td>Address Book</td> <td>Address book</td> <td>-</td> </tr> <tr> <td>Job Acct.</td> <td>Job accounting</td> <td>-</td> </tr> <tr> <td>FAX Forward</td> <td>FAX transfer information</td> <td>Job accounting, user management and document box information</td> </tr> <tr> <td>One Touch</td> <td>Information on one-touch</td> <td>Address book</td> </tr> <tr> <td>User</td> <td>User managements</td> <td>Job accounting</td> </tr> <tr> <td>Shortcut</td> <td>Shortcut information</td> <td>Job accountings, user managements and document box information</td> </tr> <tr> <td>Document Box</td> <td>Document box information</td> <td>Job accountings and user managements</td> </tr> <tr> <td>Program</td> <td>Program information</td> <td>Job accountings, user managements and document box information</td> </tr> <tr> <td>ADDRESS BOOK ONE TOUCH*2</td> <td>Address book and Information on one-touch</td> <td>Address book and Information on one-touch</td> </tr> </tbody> </table> <p>*1: Since data are dependent with each other, data other than those assigned are also retrieved or written in. *2: When ADDRESS BOOK ONE TOUCH is selected, editing with the Set up tool is not possible, however, Import/Export in high speed mode is possible.</p> <ol style="list-style-type: none"> 8. Press the start key. Starts reading or writing. The progress of selected item is displayed in %. When an error occurs, the operation is canceled and an error code is displayed (see page 1-3-101). 9. When normally completed, [Finished] is displayed. 10. Turn the main power switch off and on after completing writing when selecting [Import]. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Export	Retrieving from the machine to a USB memory	Import	Writing data from the USB memory to the machine	Display	Description	Depending data*1	Address Book	Address book	-	Job Acct.	Job accounting	-	FAX Forward	FAX transfer information	Job accounting, user management and document box information	One Touch	Information on one-touch	Address book	User	User managements	Job accounting	Shortcut	Shortcut information	Job accountings, user managements and document box information	Document Box	Document box information	Job accountings and user managements	Program	Program information	Job accountings, user managements and document box information	ADDRESS BOOK ONE TOUCH*2	Address book and Information on one-touch	Address book and Information on one-touch
Display	Description																																				
Export	Retrieving from the machine to a USB memory																																				
Import	Writing data from the USB memory to the machine																																				
Display	Description	Depending data*1																																			
Address Book	Address book	-																																			
Job Acct.	Job accounting	-																																			
FAX Forward	FAX transfer information	Job accounting, user management and document box information																																			
One Touch	Information on one-touch	Address book																																			
User	User managements	Job accounting																																			
Shortcut	Shortcut information	Job accountings, user managements and document box information																																			
Document Box	Document box information	Job accountings and user managements																																			
Program	Program information	Job accountings, user managements and document box information																																			
ADDRESS BOOK ONE TOUCH*2	Address book and Information on one-touch	Address book and Information on one-touch																																			

Maintenance item No.	Description			
U917	Error Codes			
	Codes	Description	Codes	Description
	321e0001	Parameter error	321e002f	Box open error
	321e0002	File write error	321e0030	Box close error
	321e0003	File initialization error	321e0031	Box creation error
	321e0004	File error	321e0032	Box creation error
	321e0005	Processing error	321e0033	Box deletion error
	321e0006	Address book clear error (contact)	321e0034	Box movement error
	321e0007	Address book open error (contact)	321e0035	Fax memory directory creation error
	321e0008	Address book list error (contact)	321e0036	Fax memory error in writing
	321e0009	Address book list error (contact)	321e0037	Fax memory error in reading
	321e000a	Address book clear error (group)	321e0038	Shortcut error in writing
	321e000b	Address book open error (group)	321e0039	Shortcut error in reading
	321e000c	Address book list error (group)	321e003a	Program error in writing
	321e000d	Address book list error (group)	321e003b	Program error in reading
	321e000e	One-touch open error	321e003c	Address/One Touch directory creation error
	321e000f	One-touch list error	321e003d	Address/One Touch error in writing
	321e0010	One-touch list error	321e003e	Address/One Touch error in reading
	321e0011	Job accounting clear error	321e003f	File reading error
	321e0012	Job accounting file open error	321e0040	File writing error
	321e0013	Job accounting file open error	321e0041	Data mismatch
	321e0014	Job accounting error in writing	321e0042	Log file open error
	321e0015	Job accounting list error	321e0043	Log file error in writing
	321e0016	Job accounting list error	321e0044	Directory open error
	321e0017	User managements backup error	321e0045	Directory error in reading
	321e0018	User managements clear error	321d0000	Unspecified error
	321e0019	User managements file open error	321d0001	HDD unavailable
	321e001a	User managements file open error	321d0002	USB memory is not inserted
	321e001b	User managements file open error	321d0003	File for writing is not found in the USB
	321e001c	User managements error in writing	321d0004	File for reading is not found in the HDD
	321e001d	User managements list error	321d0005	USB error in writing
	321e001e	User managements list error	321d0006	USB error in reading
	321e001f	User managements list error	321d0007	USB unmount error
	321e0020	User managements list error	321d0008	File rename error
	321e0021	User managements file open error	321d0009	File open error
	321e0022	User managements error	321d000a	File close error
	321e0023	User managements error	321d000b	File reading error
	321e0024	User managements file open error	321d000c	File writing error
	321e0025	User managements error	321d000d	File copy error
	321e0026	User managements file open error	321d000e	File compressed error
	321e0027	User managements error	321d000f	File decompressed error
	321e0028	Box file open error	321d0010	Directory open error
	321e0029	Box error in writing	321d0011	Directory creation error
	321e002a	Box error in reading	321d0012	File writing error
	321e002b	Box list error	321d0013	File reading error
	321e002c	Box list error	321d0014	File deletion error
	321e002d	Box error	321d0015	Log file copy error to the USB
	321e002e	Box error		

Maintenance item No.	Description								
<p>U920</p>	<p>Checking the copy counts Description Checks the copy counts. Purpose To check the copy counts.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The current counts are displayed. <table border="1" data-bbox="331 506 1396 672"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Copy Count</td> <td>Count value of copy</td> </tr> <tr> <td>Printer Count</td> <td>Count value of printer</td> </tr> <tr> <td>Fax Count</td> <td>Count value of fax</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Copy Count	Count value of copy	Printer Count	Count value of printer	Fax Count	Count value of fax
Display	Description								
Copy Count	Count value of copy								
Printer Count	Count value of printer								
Fax Count	Count value of fax								
<p>U927</p>	<p>Clearing the all copy counts and machine life counts (one time only) Description Resets all of the counts back to zero. Supplement The total account counter and the machine life counter can be cleared only once if all count values are 1000 or less.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press [EXECUTE]. 3. Press the start key. All copy counts and machine life counts are cleared. [CAN NOT EXECUTE] is displayed if the count cannot be cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>								
<p>U928</p>	<p>Checking machine life counts Description Displays the machine life counts. Purpose To check the machine life counts.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The current machine life counts is displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>								

Maintenance item No.	Description						
U931	<p>Setting the automatic toner install</p> <p>Description Sets automatic toner installation on or off when power is turned on.</p> <p>Purpose Changed to off when deactivating automatic toner installation.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1" data-bbox="333 533 1398 658"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Automatic toner install function ON</td> </tr> <tr> <td>OFF</td> <td>Automatic toner install function OFF</td> </tr> </tbody> </table> <p>Initial setting: OFF</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. 4. The machine automatically returns to the same status as when the power is turned on. 	Display	Description	ON	Automatic toner install function ON	OFF	Automatic toner install function OFF
Display	Description						
ON	Automatic toner install function ON						
OFF	Automatic toner install function OFF						
U935	<p>Relay board maintenance</p> <p>Description Sets the mode when call for service (C0060) occurs.</p> <p>Purpose Sets the machine status temporarily when call for service (C0060) occurs. However, after the setting, call for service (C0060) occurs again when progress of period.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="333 1093 1398 1218"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>MODE0</td> <td>Setting mode: OFF</td> </tr> <tr> <td>MODE1</td> <td>Setting mode: ON (Usable up to three times of use)</td> </tr> </tbody> </table> <p>Initial setting: MODE0</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. 4. Turn the main power switch off and on. <p>Supplement After removing the cause of the problem, be sure to change the setting in OFF.</p>	Display	Description	MODE0	Setting mode: OFF	MODE1	Setting mode: ON (Usable up to three times of use)
Display	Description						
MODE0	Setting mode: OFF						
MODE1	Setting mode: ON (Usable up to three times of use)						

Maintenance item No.	Description																				
U942	<p>Setting of deflection for feeding from DP</p> <p>Description Adjusts the deflection generated when the DP is used.</p> <p>Purpose Use this mode if an original non-feed jam, oblique feed or wrinkling of original occurs when the DP is used.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be adjusted. <table border="1" data-bbox="333 535 1398 701"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting</th> <th>Initial</th> <th>Change in</th> </tr> </thead> <tbody> <tr> <td>REGIST TOP</td> <td>Deflection of single-sided original</td> <td>-31 to 31</td> <td>0</td> <td>0.18 mm</td> </tr> <tr> <td>REGIST BACK</td> <td>Deflection of double-sided original</td> <td>-31 to 31</td> <td>0</td> <td>0.18 mm</td> </tr> <tr> <td>REGIST MIX</td> <td>Deflection of dual scanning</td> <td>-31 to 31</td> <td>0</td> <td>0.18 mm</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the system menu key. 4. Place an original on the DP and press the start key to make a test copy. 5. Press the system menu key. 6. Change the setting value using the +/- or numeric keys. The greater the value, the larger the deflection; the smaller the value, the smaller the deflection. If an original non-feed jam or oblique feed occurs, increase the setting value. If wrinkling of original occurs, decrease the value. 7. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting	Initial	Change in	REGIST TOP	Deflection of single-sided original	-31 to 31	0	0.18 mm	REGIST BACK	Deflection of double-sided original	-31 to 31	0	0.18 mm	REGIST MIX	Deflection of dual scanning	-31 to 31	0	0.18 mm
Display	Description	Setting	Initial	Change in																	
REGIST TOP	Deflection of single-sided original	-31 to 31	0	0.18 mm																	
REGIST BACK	Deflection of double-sided original	-31 to 31	0	0.18 mm																	
REGIST MIX	Deflection of dual scanning	-31 to 31	0	0.18 mm																	
U964	<p>Checking of log</p> <p>Description Sends a log file saved on the HDD to a USB memory.</p> <p>Purpose To transfer a log file saved on the HDD to a USB memory as a means of investigating malfunctions.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Insert USB memory in USB memory slot. 2. Turn the main power switch on. 3. Enter the maintenance item. 4. Press the start key. 5. Select [Execute]. 6. Press the start key. Starts sending the log file saved on the HDD to the USB memory. 7. When normally completed, [Finished] is displayed. When an error occurs, an error code is displayed. 8. Turn the main power switch off and on. <p>Error codes</p> <table border="1" data-bbox="333 1608 1398 1939"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>No Usb Storage</td> <td>USB memory is not inserted</td> </tr> <tr> <td>No File</td> <td>File is not found</td> </tr> <tr> <td>Mount Error</td> <td>USB memory mount error</td> </tr> <tr> <td>File Delete Error</td> <td>File deletion error</td> </tr> <tr> <td>Copy Error</td> <td>File copy error</td> </tr> <tr> <td>Unmount Error</td> <td>USB memory unmount error</td> </tr> <tr> <td>Other Error</td> <td>Other error</td> </tr> </tbody> </table>	Display	Description	No Usb Storage	USB memory is not inserted	No File	File is not found	Mount Error	USB memory mount error	File Delete Error	File deletion error	Copy Error	File copy error	Unmount Error	USB memory unmount error	Other Error	Other error				
Display	Description																				
No Usb Storage	USB memory is not inserted																				
No File	File is not found																				
Mount Error	USB memory mount error																				
File Delete Error	File deletion error																				
Copy Error	File copy error																				
Unmount Error	USB memory unmount error																				
Other Error	Other error																				


Maintenance item No.	Description						
U969	<p>Checking of toner area code</p> <p>Description Displays the toner area code.</p> <p>Purpose To check the toner area code.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The toner area code is displayed. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>						
U977	<p>Data capture mode</p> <p>Description Store the print data sent to the machine into USB memory.</p> <p>Purpose In case to occur the error at printing, check the print data sent to the machine.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Insert USB memory in USB memory slot. 2. Turn the main power switch on. 3. Enter the maintenance item. 4. Press the start key. 5. Select [Execute]. 6. Press the start key. 7. Send the print data to the machine. <p>Once the print data is stored into USB memory, [Complete] will be displayed.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>						
U984	<p>Checking the developing unit number</p> <p>Description Displays the developing unit number.</p> <p>Purpose To check the developing unit number.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The number is displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>						
U985	<p>Displaying the developing unit history</p> <p>Description Displays the past record of machine number and the developing counter.</p> <p>Purpose To check the count value machine number and the developing counter.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. Past record of 5 cases is displayed. <table border="1" data-bbox="331 1706 1396 1892"> <thead> <tr> <th data-bbox="339 1718 635 1749">Display</th> <th data-bbox="635 1718 1396 1749">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="339 1749 635 1821">MACHINE No. HISTORY1 to 5</td> <td data-bbox="635 1749 1396 1821">Historical records of the machine number</td> </tr> <tr> <td data-bbox="339 1821 635 1892">DEVELOP COUNT HISTORY1 to 5</td> <td data-bbox="635 1821 1396 1892">Historical records of developing counter</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MACHINE No. HISTORY1 to 5	Historical records of the machine number	DEVELOP COUNT HISTORY1 to 5	Historical records of developing counter
Display	Description						
MACHINE No. HISTORY1 to 5	Historical records of the machine number						
DEVELOP COUNT HISTORY1 to 5	Historical records of developing counter						

Maintenance item No.	Description								
<p>U989</p>	<p>HDD scandisk Description Restores data in the hard disk by scanning the disk. Purpose If power is turned off while accessing to the hard disk is performed, the control information in the hard disk drive may be damaged. Use this mode to restore the data. Method 1. Press the start key. 2. Press [EXECUTE]. 3. Press the start key. When scanning of the disk is complete, the execution result is displayed. 4. Turn the main power switch off and on.</p>								
<p>U990</p>	<p>Checking/clearing the time for the exposure lamp to light Description Displays, clears or changes the accumulated time for the CIS to light. Purpose To check duration of use of the CIS. Also to clear the accumulated time for the CIS after replacement. Method 1. Press the start key. The accumulated time of illumination for the CIS is displayed in minutes. 2. Clear the accumulated time using the +/- or numeric keys. 3. Press the start key. The time is set. Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>								
<p>U991</p>	<p>Checking the scanner count Description Displays the scanner operation count. Purpose To check the status of use of the scanner. Method 1. Press the start key.</p> <table border="1" data-bbox="333 1317 1398 1485"> <thead> <tr> <th data-bbox="339 1326 636 1361">Display</th> <th data-bbox="636 1326 1391 1361">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="339 1361 636 1397">COPY SCAN COUNT</td> <td data-bbox="636 1361 1391 1397">Scanner operation count for copying</td> </tr> <tr> <td data-bbox="339 1397 636 1433">FAX SCAN COUNT</td> <td data-bbox="636 1397 1391 1433">Scanner operation count for fax</td> </tr> <tr> <td data-bbox="339 1433 636 1469">OTHER SCAN COUNT</td> <td data-bbox="636 1433 1391 1469">Scanner operation count except for copying</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance No. item is displayed.</p>	Display	Description	COPY SCAN COUNT	Scanner operation count for copying	FAX SCAN COUNT	Scanner operation count for fax	OTHER SCAN COUNT	Scanner operation count except for copying
Display	Description								
COPY SCAN COUNT	Scanner operation count for copying								
FAX SCAN COUNT	Scanner operation count for fax								
OTHER SCAN COUNT	Scanner operation count except for copying								

1-3-2 Management mode

In addition to a maintenance function for service, the machine is equipped with a management function which can be operated by users (mainly by the administrator). In this management mode, settings such as default settings can be changed.

(1) Using the management mode



(2) Common Settings

Switching the Language for Display [Language]

1. Press [Change] of Language.
2. Press the key for the language you want to use.
3. Press [OK].
The touch panel language will be changed.

Default Screen

1. Press [Change] of Default Screen.
2. Select the screen to be displayed as the default screen.
3. Press [OK].

Sound

1. Press [Next] of Sound and then [Next] of Buzzer.
2. Press [Change] of Volume, Key Confirmation, Job Finish, Ready, or Warning.
3. Select the buzzer volume level, or other sound options.

Original/Paper Settings

1. Press [Next] of Original/Paper Settings and then [Next] of Custom Original Size.
2. Press [Change] of any one of Custom 1 to Custom 4, on which you wish to register the size.
3. Press [On], and then press [+], [-] or numeric keys to enter X (horizontal) and Y (vertical) dimensions.
4. Press [OK].

Adding a Custom Size and Media Type for Paper to Print

1. Press [Next] of Original/Paper Settings and then [Next] of Custom Paper Size.
2. Press [Change] of any one of Custom 1 to Custom 4, on which you want to register the size.
3. Press [On], and then press [+], [-] or numeric keys to enter X (horizontal) and Y (vertical) dimensions. Press [Media Type] to select the type of paper and press [OK] if necessary.
4. Press [OK].

Paper Size and Media Type Setup for Cassettes

1. Press [Next] of Original/Paper Settings, [Next] of Cassette Setting, [Next] of Cassette 1 to Cassette 4, on which you want to register the size, and then [Change] of Paper Size.
2. To detect paper size automatically, press [Auto] and select Metric or Inch for Paper Size. To select paper size, press [Standard Sizes 1] or [Standard Sizes 2] for Paper Size.
3. Press [OK]. The previous screen reappears.
4. Press [Change] of Media Type to select media type and press [OK].

Paper Size and Media Type Setup for Multi Purpose Tray

1. Press [Next] of Original/Paper Settings, [Next] of MP Tray Setting and then [Change] of Paper Size.
2. To detect paper size automatically, press [Auto] and select Metric or Inch for Paper Size. To select paper size, press [Standard Sizes 1], [Standard Sizes 2], [Others] or [Size Entry] for Paper Size. If you select [Size Entry], press [+], [-] to enter X (horizontal) and Y (vertical) dimensions. Press [# keys] to enter the paper size using the numeric keys.
3. Press [OK]. The previous screen reappears.
4. Press [Change] of Media Type to select the media type and press [OK].

Paper Weight

1. Press [Next] of Original/Paper Settings and then [Next] of Media Type Setting.
2. Press [Next] for the media type whose weight you want to change.
3. Press [Change] of Paper Weight.
4. Select the weight and press [OK].
5. Press [Close]. The previous screen reappears.
6. To change the duplex printing settings for Custom 1 (-8), press [Next] of Custom 1(-8) and then [Change] of Duplex. Select [Prohibit] or [Permit] and press [OK]. The previous screen reappears.
7. Press [Close].
8. To change the name for Custom 1(-8), press [Next] of Custom 1(-8) and then [Change] of Name. Enter the name and press [OK].

Default Paper Source

1. Press [Next] of Original/Paper Settings and then [Change] of Default Paper Source.
2. Select a paper cassette for the default setting.
3. Press [OK].

Automatic Detection of Originals (Available for metric models only)

1. Press [Next] of Original/Paper Settings and then [Change] of Original Auto Detect.
2. Select [A6] or [Hagaki] of A6/Hagaki. Select [Off] to disable automatic detection or [On] to enable automatic detection of Folio and 11x15" respectively.
3. Press [OK].

Media for Auto Selection

1. Press [Next] of Original/Paper Settings and then [Change] of Media for Auto (B & W).
2. Select [All Media Types] or any media type for paper selection.
3. Press [OK].

Paper Source for Cover Paper

1. Press [Next] of Original/Paper Settings, cursor down key and then [Change] of Paper Source for Cover.
2. Select the paper source to load cover paper.
3. Press [OK].

Special Paper Action

1. Press [Next] of Original/Paper Settings, cursor down key and then [Change] of Special Paper Action.
2. Select [Adjust Print Direction] or [Speed Priority].
3. Press [OK].

Switching Unit of Measurement

1. Press [Change] of Measurement.
2. Select [mm] for metric or [inch] for inch.
3. Press [OK].

Error Handling

1. Press [Next] of Error Handling.
2. Press [Change] at the error you wish to change the handling.
3. Select the error handling method in the selection screen for each of the errors and then press [OK].
4. The previous screen appears. To set the handling for a different error, repeat steps 2 and 3.

Paper Output

1. Press [Next] of Paper Output.
2. Press [Change] of Copy/Custom Box, Printer, FAX Port 1 or FAX Port 2.
3. Select Output Tray.
For [Finisher Tray], [Tray B], [Tray C] or [Tray 1] to [Tray 7], select [Face Up] (print surface up) or [Face Down] (print surface down) as the paper orientation at output.
4. Press [OK].

Orientation Confirmation

1. Press [Change] of Orientation Confirmation.
2. Select the default for [Off] or [On].
3. Press [OK].

Function Defaults

1. Press cursor down key, [Next] of Function Defaults and then [Change] of Original Orientation.
2. Select [Top Edge Top] or [Top Edge Left] for the default.
3. Press [OK].

Continuous Scan

1. Press cursor down key, [Next] of Function Defaults and then [Change] of Continuous Scan.
2. Select [Off] or [On] for the default. Use the procedure below to select the default quality setting for originals.
3. Press [OK].

Original Image

1. Press cursor down key, [Next] of Function Defaults and then [Change] of Original Image.
2. Select the [Text+Photo], [Photo], [Text], [for OCR] or [Printed Document] as the default.
3. Press [OK].

Scan Resolution

1. Press cursor down key, [Next] of Function Defaults and then [Change] of Scan Resolution.
2. Select the default resolution.
3. Press [OK].

Color Selection (Copy)

1. Press cursor down key, [Next] of Function Defaults and then [Change] of mode Color Selection(Copy).
2. Select the default color setting.
3. Press [OK].

Color Selection (Send/Store)

1. Press cursor down key, [Next] of Function Defaults and then [Change] of mode Color Sel. (Send/Store).
2. Select the default color mode.
3. Press [OK].

File Format

1. Press cursor down key, [Next] of Function Defaults and then [Change] of File Format.
2. Select the default file format.
3. Press [OK].

File Separation

1. Press cursor down key, [Next] of Function Defaults and then [Change] of File Separation.
2. Select the default for [Off] or [Each Page].
3. Press [OK].

Density

1. Press cursor down key, [Next] of Function Defaults, cursor down key and then [Change] of Density.
2. Select the default density.
3. Press [OK].

Zoom

1. Press cursor down key, [Next] of Function Defaults, cursor down key and then [Change] of Zoom.
2. Select the default zoom setting.
3. Press [OK].

File Name Entry

1. Press cursor down key, [Next] of Function Defaults, cursor down key and then [Change] of File Name Entry.
2. Press [File Name] to enter the file name in not more than 32 characters.
3. Press [OK].
4. Press [Date and Time] to add the date/time to the job, or press [Job No.] to add the job number to the job. The added information will be displayed in Additional Info.
5. Press [OK].

E-mail Subject/Body

1. Press cursor down key, [Next] of Function Defaults, cursor down key, and then [Change] of E-mail Subject/Body.
2. Press [Subject] to enter an E-mail subject not more than 60 characters.
3. Press [OK].
4. Press [Body] to enter an E-mail Body not more than 500 characters.
5. Press [OK].
6. Check that the entries are correct and press [OK].

Border Erase Default

1. Press cursor down key, [Next] of Function Defaults, cursor down key and then [Change] of Border Erase Default.
2. Press [+] or [-] for the Border and Gutter width to erase.
You can use the number keypad to enter the number directly.
3. Press [OK].

Border Erase to Back Page

1. Press cursor down key, [Next] of Function Defaults, cursor down key and then [Change] of Border Erase to Back Page.
2. Press [Same as Front Page] or [Do Not Erase].
3. Press [OK].

Margin Default

1. Press cursor down key, [Next] of Function Defaults, cursor down key and then [Change] of Margin Default.
2. Use the [+] or [-] to enter the margin widths for Left/Right and Top/Bottom(-0.75 - +0.75).
You can use the number keypad to enter the number directly.
3. Press [OK].

Auto Image Rotation

1. Press cursor down key, [Next] of Function Defaults, cursor down key and then [Change] of Auto Image Rotation.
2. Select the default for [Off] or [On].
3. Press [OK].

EcoPrint

1. Press cursor down key, [Next] of Function Defaults, cursor down key twice, and then [Change] of EcoPrint.
2. Select [Off] or [On] for the default.
3. Press [OK].

PDF/TIFF/JPEG Image

1. Press cursor down key and [Next] of Function Defaults. Press cursor down key twice and then [Change] of PDF/TIFF/JPEG Image.
2. Select the default image quality from [1] (Low Quality) to [5] (High Quality).
3. Press [OK].

High Comp. PDF Image

1. Press cursor down key and [Next] of Function Defaults. Press cursor down key twice and [Change] of High Comp. PDF Image.
2. Select the default for [Compression Ratio Priority], [Standard], or [Quality Priority].
3. Press [OK].

Color TIFF Compression Settings

1. Press cursor down key and [Next] of Function Defaults. Press cursor down key twice and then [Change] of Color TIFF Compression.
2. Select [TIFF V6] or [TTN2].
3. Press [OK].

Repeat Copying

1. Press cursor down key and [Next] of Function Defaults. Press cursor down key twice and [Change] of Repeat Copy.
2. Select the default for [Off] or [On].
3. Press [OK].

Collate/Offset

1. Press cursor down key, [Next] of Function Defaults, cursor down key twice and then [Change] of Collate/Offset.
2. Select the defaults for Collate and Offset respectively.
3. Press [OK].

JPEG/TIFF Print

1. Press cursor down key, [Next] of Function Defaults, cursor down key twice and then [Change] of JPEG/TIFF Print.
2. Select the default for [Fit to Paper Size], [Image Resolution], or [Fit to Print Resolution].
3. Press [OK].

XPS Fit to Page

1. Press cursor down key, [Next] of Function Defaults, cursor down key twice and then [Change] of XPS Fit to Page.
2. Select [Off] or [On] for the default.
3. Press [OK].

(3) Copy Settings**Paper Selection**

1. Press [Change] of Paper Selection.
2. Press [Auto] or [Default Paper Source].
3. Press [OK].

Auto Paper Selection

1. Press [Change] of Auto Paper Selection.
2. Press [Most Suitable Size] or [Same as Original Size].
3. Press [OK].

Auto % Priority

1. Press [Change] of Auto % Priority.
2. Select the default for [Off] or [On].
3. Press [OK].

Reserve Next Priority

1. Press [Change] of Reserve Next Priority.
2. Select the default for [Off] or [On].
3. Press [OK].

Preset Limit

1. Press [Change] of Preset Limit.
2. Press [+] or [-] or use the numeric keys to enter the limit for the number of copies.
3. Press [OK].

Quick Setup Registration

1. Press [Next] of Quick Setup Registration.
2. Press [Change] of the function to be registered in Quick Setup.
3. Select a key (1-6) allocated on the Quick Setup Registration screen. Press [Off] to delete a key from the Quick Setup.
4. Press [OK]. If you overwrite the setting, a confirmation screen appears. Press [Yes].

(4) Sending Settings**Quick Setup Registration**

1. Press [Next] of Quick Setup Registration.
2. Press [Change] of the function to be registered in Quick Setup.
3. Select a key (1-6) allocated on the Quick Setup Registration screen. Press [Off] to delete a key from the Quick Setup.
4. Press [OK]. If you overwrite the setting, a confirmation screen appears. Press [Yes].

Destination Check before Send

1. Press [Change] of Dest. Check before Send.
2. Select [Off] or [On].
3. Press [OK].

Color Type

1. Press [Change] of Color Type.
2. Select [RGB] or [sRGB].
3. Press [OK].

Entry Check for New Destination

1. Press [Change] of Entry Check for New Dest.
2. Select [Off] or [On].
3. Press [OK].

Setting the Default Send Screen

1. Press [Change] of Default Screen.
2. Press [Destination] or [Address Book].
3. Press [OK].

(5) Document Box Settings**Quick Setup Registration**

1. Press [Next] of Quick Setup Registration.
2. Press [Next] of Store File or Send.
3. Press [Change] of the function to be registered in Quick Setup.
4. Select a key (1-6) allocated on the Quick Setup screen. Press [Off] to delete a key from the Quick Setup.
5. Press [OK]. If you overwrite the setting, a confirmation screen appears. Press [Yes].

(6) Printer Settings

Emulation

1. Press [Change] of Emulation.
2. Select the desired emulation.
3. Press [OK].

Setting of Alternative Emulation

1. Press [Change] of Emulation, [KPD(L)Auto] and then [Alt Emulation].
2. Select the desired alternative emulation and then press [OK].
3. Press [OK].

Setting of KPD(L) error report

1. Press [Change] of Emulation, [KPD(L)] or [KPD(L)Auto] and then [KPD(L) Error Report].
2. Press [On] or [Off] and then press [OK].
3. Press [OK].

EcoPrint

1. Press [Change] of EcoPrint.
2. Press [Off] or [On].
3. Press [OK].

Override A4/Letter

1. Press [Change] of Override A4/Letter.
2. Press [Off] or [On].
3. Press [OK].

Duplex

1. Press [Change] of Duplex.
2. Press [1-sided], [2-sided Bind LongEdge], or [2-sided Bind ShortEdge].
3. Press [OK].

Copies

1. Press [Change] of Copies.
2. Press [+], [-] or the numeric keys to set the default number of copies.
3. Press [OK].

Orientation

1. Press [Change] of Orientation.
2. Press [Portrait] or [Landscape].
3. Press [OK].

Form Feed Timeout

1. Press cursor down key and [Change] of Form Feed Timeout.
2. Press [+] or [-] to set the Form Feed Timeout. You can set the timeout delay in seconds. You cannot use the number keypad to enter this value.
3. Press [OK].

LF Action

1. Press cursor down key and [Change] of LF Action.
2. Press [LF Only], [LF and CR] or [Ignore LF].
3. Press [OK].

CR Action

1. Press cursor down key and [Change] of CR Action.
2. Press [CR Only], [LF and CR] or [Ignore CR].
3. Press [OK].

Paper Feed Mode

1. Press cursor down key and [Change] of Paper Feed Mode.
2. Press [Auto] or [Fixed].
3. Press [OK].

(7) Printing Reports/Sending Notice

Printing Reports

1. Press [Next] of Print Report.
2. Press [Print] for the report you want to print. Printing starts. A confirmation screen appears. Press [Yes].

Send Result Report

1. Press [Next] of Result Report Setting, [Next] of Send Result Report and then [Change] of E-mail/Folder.
2. Press [Off], [On], or [Error Only].
3. Press [OK].

(8) Adjustment/Maintenance

Copy Density Adjustment

1. Press [Next] of Copy Density Adjustment.
2. Press [Change] of Auto or of Manual.
3. Press [-3] - [+3] (Lighter-Darker) to adjust density.
4. Press [OK].

Send/Box Density Adjust

1. Press and [Next] of Send/Box Density Adjust.
2. Press [Change] of Auto or of Manual.
3. Press [-3] - [+3] (Lighter-Darker) to adjust density.
4. Press [OK].

Print Density

1. Press [Change] of Print Density.
2. Press [1] - [5] (Lighter-Darker) to adjust density.
3. Press [OK].

Drum Refresh

1. Press [Next] of Drum Refresh.
2. Press [Execute] to Drum Refresh.
3. After Drum Refresh is completed, press [OK] to return to the Adjustment/Maintenance screen.

Correcting Fine Black Lines

1. Press [Change] of Correcting Black Line.
2. Press [Off], [On(Low)] or [On(High)].
3. Press [OK].

Display Brightness

1. Press [Change] of Display Brightness.
2. Press [1] - [4] (Darker- Lighter) to adjust brightness.
3. Press [OK].

Silent Mode

1. Press [Change] of Silent Mode.
2. Press [Off] or [On].
3. Press [OK].

Charger Auto Cleaning


1. Press [Change] of Silent Mode.
2. Press [Off] or [On].
3. Press [OK].

Auto Color Correction

1. Press cursor down key and [Change] of Auto Color Correction.
2. Press one of keys [1] to [5] (Color - B & W) to set the detection level.
3. Press [OK].

Gray Adjustment

1. Press cursor down key and then [Next] of Gray Adjustment.
2. Press [Execute]. A color pattern is printed.
3. As shown in the illustration, place the printed side down on the platen with the three black boxes aligned to the top.



4. Press [Execute]. The color pattern is read and adjustment begins.
5. Press [OK] in the adjustment end confirmation screen.

System Initialization

1. Press [Execute] of System Initialization.
2. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
3. When the confirmation screen appears, press [Yes]. Initialization starts.
4. Once the initialization ends, the message Task is completed. Turn the main power switch off and on. appears. Turn the main power switch off.

(9) Date/Timer

Date/Time

1. Press [Change] of Date/Time.
2. Press [+] or [-] to enter the date and time respectively.
3. Press [OK].

Date Format

1. Press [Change] of Date Format.
2. Select [MM/DD/YYYY], [DD/MM/YYYY], or [YYYY/MM/DD] and press [OK].

Time Zone

1. Press [Change] of Time Zone.
2. Select the location.
3. Press [Off] or [On] of Summer Time and press [OK].

Auto Panel Reset

1. Press [Change] of Auto Panel Reset.
2. Press [Off] or [On].
3. Press [OK].

Panel Reset Timer

1. Press [Change] of Panel Reset Timer.
2. Press [+] or [-] to enter the time until Auto Panel Reset is turned on.
You cannot use the number keypad to enter this value.
3. Press [OK].

Sleep Timer

1. Press [Change] of Sleep Timer.
2. Press [+], [-] or the numeric keys to enter the time until Auto Sleep is turned on.
3. Press [OK].

Auto Error Clear ON/OFF

1. Press [Change] of Auto Error Clear.
2. Press [Off] or [On].
3. Press [OK].

Error Clear Timer

1. Press cursor down key and then [Change] of Error Clear Timer.
2. Press [+] or [-] to enter the time until printing restarts.
You cannot use the number keypad to enter this value.
3. Press [OK].

Interrupt Clear Timer

1. Press cursor down key and then [Change] of Interrupt Clear Timer.
2. Press [+] or [-] to enter the time for the interrupt clear timer.
3. Press [OK].

(10) Editing Destination (Address Book/Adding One Touch Keys)**Adding a Contact**

1. Press [Register/Edit] of Address Book, [Add], [Contact] and then [Next].
2. To specify the address number, press [Change] in Address Number.
3. Press [+], [-] or numeric keys to enter a particular Address Number (1-2500).
To have the number assigned automatically, enter "0000".
4. Press [OK]. The screen shown in step 2 reappears.
5. Press [Change] of Name.
6. Enter the destination name (up to 32 characters) to be displayed on the Address Book and press [OK]. The screen shown in step 2 reappears.
7. Press [E-mail] to add an e-mail address, [SMB] to add a folder on the computer, or [FTP] to add an FTP folder.

The procedure differs depending on the transmission method selected.

E-mail Address

1. Press [Change] of E-mail Address, enter the E-mail address and press [OK].
The table below explains the items to be entered.

The Folder (FTP) Address

1. Press [Change] of Host Name, Path, Login User Name and Login Password, enter the information for each item and press [OK].

The Folder (SMB) Address

1. Press [Change] of Host Name, Path, Login User Name and Login Password, enter the information for each item and press [OK].
8. Check if the destination entry is correct and press [Register]. The destination is added to the Address Book.

Adding a Group

1. Press [Register/Edit] of Address Book, [Add], [Group] and then [Next].
2. To specify the address number, press [Change] in Address Number.
3. Use [+], [-] or the numeric keys to enter an address number (1 to 2500).
To have the number assigned automatically, set "0000".
4. Press [OK]. The Add Group screen reappears.
5. Press [Change] of Name.
6. Enter the group name displayed on the Address Book not more than 32 characters.
7. Press [Member].
8. Press [Add].
9. Select a destination (contacts) to add to the group.
10. Press [OK].
If you have more destinations to add, repeat Steps 8 to 10.
11. Check if the selected destination was added to the group and press [Register]. Now the group is added to the Address Book.

Editing a Destination

1. Press [Register/Edit] of Address Book.
2. Select a destination or group to edit.
3. Press [Detail].

The procedure differs depending on the details to be edited.

Editing an Individual Destination

1. Change Address Number, Name and destination type and address.
2. After you have completed the changes, press [Register].
3. Press [Yes] in the change confirmation screen to register the changed destination.

Editing a Group

1. Change Address Number and Name.
2. Press [Member].
3. To delete any destination from the group, select the destination and press [Delete]. Press [Yes] on the screen to confirm the deletion.
4. After you have completed the changes, press [Register].
5. Press [Yes] in the change confirmation screen to register the changed group.

Deleting an Individual Destination or Group

1. Press [Delete]. Press [Yes] on the screen to confirm the deletion. Deletion is performed.

Adding a Destination on One Touch Key

1. Press [Register/Edit] of One touch Key.
2. Select a One Touch Key number (0001 to 1000) for the destination. Pressing Quick No. Search key or [No.] enables direct entry of a One Touch Key number. Select a One Touch Key with no registered destination.
3. Press [Register/Edit]. The address book appears.
4. Select a destination (individual or group) to add to the One Touch Key number. Pressing [Detail] shows the detailed information of the selected destination.
5. Press [OK]. The destination will be added to the One Touch Key.

Editing One Touch Key

1. Press [Register/Edit] of One Touch Key.
2. Select a One Touch Key number (0001 to 1000) for the destination. Pressing Quick No. Search key or [No.] enables direct entry of a One Touch Key number.

The procedure differs depending on the details to be edited.

Changing the Registered Information

1. Press [Register/Edit].
2. Select a new destination (individual or group). Pressing [Detail] shows the detailed information of the selected destination.
3. Press [OK].
4. Press [Yes] on the screen to add the destination to the One Touch Key.

Deleting the Registered Information

1. Press [Delete].
2. Press [Yes] on the screen to confirm the deletion of the data registered in the One Touch Key.

Sort Settings

1. Press [Next] of Address Book Defaults and then [Change] of Sort.
2. Select [No.] or [Name].
3. Press [OK].

Narrow Down Settings

1. Press [Next] of Address Book Defaults and then [Change] of Narrow Down.
2. Select the type of destination filter.
3. Press [OK].

(11) Internet Browser Setup**Internet Browser Setting**

1. Press [Change] of Internet Browser.
2. Press [On] or [Off].
3. Press [OK].

Browser Preferences

1. Press [Next] of Browser Environment.
2. To set your home page, press [Change] of Home Page, press [URL], enter the URL and then press [OK]. Press [OK] again.
3. To set the text size, press [Change] of Text Size, select [Large], [Medium] or [Small] as the text size and then press [OK].
4. To set the display mode, press [Change] of Display Mode, select [Normal], [Just-Fit Rendering] or [Smart-Fit Rendering] as the display mode and then press [OK].
5. To specify the settings for accepting cookies, press [Change] of Cookie, select [Accept All], [Reject All] or [Prompt before Accepting] as your cookie acceptance policy and then press [OK].

Proxy Settings

1. Press [Change] of Proxy and then press [On].
 - To set a proxy server (HTTP)**
 1. Press [Keyboard] of Proxy Server (HTTP), enter the proxy address and press [OK].
 2. Press [# Keys] and enter the port number.
 - To set a proxy server (HTTPS)**
 1. Press [Keyboard] of Proxy Server (HTTPS), enter the proxy address and press [OK].
 2. Press [# Keys] and enter the port number.
 - To set domains for which no proxy is used**
 1. Press [Keyboard] of Do Not Use Proxy for Following Domains, enter the domain name and press [OK].
 2. Press [OK].

(12) Applications**Installing Applications**

1. Insert the USB memory containing the application to be installed into the USB memory slot (A1).
2. Press [Add].
3. Select the application to be installed and press [Install].
You can view detailed information on the selected application by pressing [Detail].
4. When the confirmation screen appears, press [Yes].
Installation of the application begins. Depending on the application being installed, the installation may take some time. Once the installation ends, the original screen reappears.
5. To install another application, repeat steps 3 to 4.
6. To remove the USB memory, press [Remove Memory] and wait until the Removable Memory can be safely removed message appears. Then remove the USB memory.

Activating/Deactivating Application Use

1. Select the desired application and press [Activate].
You can view detailed information on the selected application by pressing [Detail].
2. Enter the license key and press [Official]. Some applications do not require you to enter a license key. If the license key entry screen does not appear, go to Step 3.
To use the application as a trial, press [Trial] without entering the license key.
3. When the confirmation screen appears, press [Yes].

Deleting Applications

1. Select the application to be deleted and press [Delete].
You can view detailed information on the selected application by pressing [Detail].
2. When the deletion confirmation screen appears, press [Yes]. The application is deleted.

(13) System Settings**Restarting the System**

1. Press [Execute] of Restart.
2. When the confirmation screen appears, press [Yes]. The system is restarted.

Network Setup**TCP/IP (IPv4) Setup**

1. Press [Next] of Network and then [Next] of TCP/IP Setting.
2. Press [Change] of TCP/IP.
3. Press [On] and then press [OK].
4. Press [Change] of IPv4.
5. Press [DHCP].
6. Press [Off] of DHCP and then press [OK].
7. Press [Bonjour].
8. Press [Off] of Bonjour and then press [OK].
9. Press [IP Address] and enter the address using the numeric keys.
10. Press [Subnet Mask] and enter the address using the numeric keys.
11. Press [Default Gateway] and enter the address using the numeric keys.
12. Check if all the address entries are correct and press [OK].
13. After changing the setting, restart the system or turn the machine OFF and then ON again.

TCP/IP (IPv6) Setup

1. Press [Next] of Network and then [Next] of TCP/IP Setting.
2. Press [Change] of TCP/IP.
3. Press [On] and then press [OK].
4. Press [Next] of IPv6.
5. Press [Change] of IPv6.
6. Press [On].
7. Press [OK].
8. After changing the setting, restart the system or turn the machine OFF and then ON again.

Manual Setting (IPv6)

1. Press [Next] of Network and then [Next] of TCP/IP Setting.
2. Press [Next] of IPv6.
3. Press [Next] of Manual Setting.
4. Press [IP Address (Manual)] to enter IP address.
5. Press [OK].
Press [# Keys] of Prefix Length (0 - 128) to enter the prefix length using the numeric keys.
6. Press [Default Gateway] to enter the default gateway.
7. Check that all the entries are correct and Press [OK].
8. After changing the setting, restart the system or turn the machine OFF and then ON again.

RA (Stateless) Settings

1. Press [Next] of Network and then [Next] of TCP/IP Setting.
2. Press [Next] of IPv6.
3. Press [Change] of RA(Stateless).
4. Press [On] or [Off] of RA (Stateless).
5. Press [OK].
6. After changing the setting, restart the system or turn the machine OFF and then ON again.

DHCP (IPv6) Settings

1. Press [Next] of Network and then [Next] of TCP/IP Setting.
2. Press [Next] of IPv6.
3. Press [Change] of DHCP.
4. Press [On] or [Off] of DHCP.
5. Press [OK].
6. After changing the setting, restart the system or turn the machine OFF and then ON again.

NetWare Setup

1. Press [Next] of Network and then [Change] of NetWare.
2. Press [On].
3. Press the key for the frame type you want to use.
4. Press [OK].
5. After changing the setting, restart the system or turn the machine OFF and then ON again.

AppleTalk Setup

1. Press [Next] of Network and then [Change] of AppleTalk.
2. Press [On] or [Off].
3. Press [OK].
4. After changing the setting, restart the system or turn the machine OFF and then ON again.

WSD Scan Setup

1. Press [Next] of Network and then [Change] of WSD Scan.
2. Press [On] or [Off].
3. Press [OK].
4. After changing the setting, restart the system or turn the machine OFF and then ON again.

WSD Print Setup

1. Press [Next] of Network and then [Change] of WSD Print.
2. Press [On] or [Off].
3. Press [OK].
4. After changing the setting, restart the system or turn the machine OFF and then ON again.

SSL Setup

1. Press [Next] of Network, [Next] of Secure Protocol, and then [Next] of SSL.
2. Press [On] or [Off].
3. Press [OK].
4. After changing the setting, restart the system or turn the machine OFF and then ON again.

IPP Security Setup

1. Press [Next] of Network, [Next] of Secure Protocol, and then [Change] of IPP Security.
2. Press [IPP over SSL Only] or [IPP or IPP over SSL].
3. Press [OK].
4. After changing the setting, restart the system or turn the machine OFF and then ON again.

HTTP Security Setup

1. Press [Next] of Network, [Next] of Secure Protocol, and then [Change] of HTTPS Security.
2. Press [HTTP or HTTPS] or [HTTPS Only].
3. Press [OK].
4. After changing the setting, restart the system or turn the machine OFF and then ON again.

LDAP Security Setup

1. Press [Next] of Network, [Next] of Secure Protocol, and then [Change] of LDAP Security.
2. Press [Off], [LDAP over SSL] or [LDAPv3/TLS].
3. Press [OK].
4. After changing the setting, restart the system or turn the machine OFF and then ON again.

IPSec Setting

1. Press [Next] of Network, and then [Change] of IPSec.
2. Press [On].
3. Press [OK].
4. After changing the setting, restart the system or turn the machine OFF and then ON again.

LAN Interface Setup

1. Press [Next] of Network and then [Change] of LAN Interface.
2. Select [Auto], [10BASE-T Half], [10BASE-T Full], [100BASE-TX Half] or [100BASE-TX Full] as the LAN interface.
3. Press [OK].
4. After changing the setting, restart the system or turn the machine OFF and then ON again.

Interface Block Setting

USB Host (USB memory slot setting)

1. Press [Next] of Interface Block Setting and then [Change] of USB Host.
2. Press [Block].
3. Press [OK].

USB Device (USB interface setting)

1. Press [Next] of Interface Block Setting and then [Change] of USB Device.
2. Press [Block].
3. Press [OK].

Optional interface (Optional interface card setting)

1. Press [Next] of Interface Block Setting and then [Change] of Optional Interface 1 or Optional Interface 2.
2. Press [Block].
3. Press [OK].

Document Guard Setting

1. Press and then [Change] of Document Guard.
2. Press [On].
To scan documents, press [Off].
3. Press [OK].

Optional Functions

Starting Application Use

1. Press [Next] of Optional Function.
2. Select the desired application and press [Activate]. You can view detailed information on the selected application by pressing [Detail].
3. In the license key entry screen, press [Official]. Some applications do not require you to enter an license key. If the license key entry screen does not appear, go to Step 4.
To use the application as a trial, press [Trial] without entering the license key.
4. When the confirmation screen appears, press [Yes].

Checking Application Details

1. Press [Next] of Optional Function.
2. Select the application you want to check the details of and press [Detail].
You can now view detailed information on the selected application.

(14) User Login Administration

Enabling/Disabling User Login Administration

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of User Login Setting and then [Change] of User Login.
3. Select [Local Authentication] or [Network Authentication]. Select [Off] to disable user login administration.
If you select [Network Authentication], enter the host name (62 characters or less) and domain name (256 characters or less) for the Authentication Server. Select [NTLM] or [Kerberos] as the server type.
4. Press [OK].

Adding a User

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of User Login Setting, [Register/Edit] of Local User List, and then [Add].
3. Press [Change] of User Name.
4. Enter the user name and press [OK].
5. Enter the login user name and E-mail address following 3 and 4 above.
6. Press [Change] of Login Password and then [Password].
7. Enter the login password and press [OK].
8. Press [Confirm Password].
9. Enter the same login password to confirm and press [OK].
10. Press [OK].
11. Press [Change] of Access Level.
12. Select the user access privilege and press [OK].
13. Press [Change] of Account Name.
14. Select the account and press [OK].
15. Press [Register] to add a new user on the local user list.

Changing User Properties

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of User Login Setting and [Register/Edit] of Local User List.
3. Select the user whose properties you wish to change.

The procedure differs depending on the details to be edited.

Changing user information

1. Press [Detail].
2. Refer to steps 3 to 14 of Adding a User to change a user property.
3. Press [Register].
4. Press [Yes] in the registration confirmation screen. The user information is changed.

Deleting a user

1. Press [Delete].
2. Press [Yes] on the screen to confirm deletion. The selected user will be deleted.

Unknown login user name Job

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Change] of Unknown ID Job.
3. Press [Reject] or [Permit].
4. Press [OK].

Group Authorization

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of User Login Setting, [Next] of Group Authorization Set., and then [Change] of Group Authorization.
3. Press [On].
4. Press [OK].

Group List

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of User Login Setting, [Next] of Group Authorization Set., [Register/Edit] of Group List, and then [Add].
3. Press [Change] of Group ID.
4. Enter the group ID and press [OK].
5. Press [Change] of Group Name.
6. Enter the group name and press [OK].
7. Press [Change] of Access Level.
8. Select the user access privilege and press [OK].
9. Press [Change] of Print Restriction.
10. Select [Reject Usage] or [Off] and press [OK].
11. Follow steps 9 and 10 above to set Copy Restriction, Send Restriction, FAX TX Restriction, Storing Restr. in Box, and Storing Restr. in Memory.
12. Press [Register] to add a new group on the group list.

Obtain Network User Property

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of User Login Setting, [Change] of Obtain NW User Property.
3. Press [On].
4. Press [Server Name].
5. Enter the LDAP server name or the IP address and press [OK].
6. Press [# keys] to enter the LDAP port number using the numeric keys.
7. Press [Name 1].
8. Enter the LDAP Attribute to obtain the user name to be displayed and press [OK].
9. Follow steps 7 and 8 above to set Name 2.
10. Press [E-mail Address].
11. Enter the LDAP Attribute to obtain the e-mail address and press [OK].
12. Press [Search Timeout] to set the amount of time to wait before time-out.
13. Press [+], [-] or the numeric keys to enter the time.
14. Press [LDAP Security] to select the type of encryption according to the type of security employed by the LDAP server.
15. Select [Off], [LDAP over SSL], or [LDAPv3/TLS] and press [OK].

(15) Job accounting

Enabling/Disabling Job Accounting

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of Job Accounting Setting, and then [Change] of Job Accounting.
3. Press [On]. To disable job accounting, press [Off].
4. Press [OK].

Adding an Account

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of Job Accounting Setting, [Register/Edit] of Accounting List, and then [Add].
3. Press [Change] of Account Name.
4. Enter the account name and press [OK]. The Account screen reappears.
5. Follow steps 3 and 4 above to enter the Account ID.
6. Activate or deactivate restriction.
7. Press [Register] to add a new account on the Account List.

Managing Accounts

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of Job Accounting Setting and then [Register/Edit] of Accounting List.
3. Select an account to change or delete.

Changing account information

1. Press [Detail].
2. Refer to steps 3 to 5 of Adding an Account and steps 3 to 6 of Restricting Using the Machine to change account information.
3. Press [Register].
4. Press [Yes] in the registration confirmation screen. The account information is changed.

Deleting an account

1. Press [Delete].
2. Press [Yes]. To delete the account.

Managing the Copier/Printer Counts

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of Job Accounting Setting, [Next] of Default Setting and then [Change] of Copier/Printer Count.
3. Press [Total] or [Split].
4. Press [OK].

Applying Restriction

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of Job Accounting Setting, [Register/Edit] of Accounting List, and then [Add].
3. Press [Change] for the item to be restricted.
4. Select the restriction mode.
If [Counter Limit] is selected, press [+],[-] or numeric keys to select the number of pages.
5. Press [OK].
6. Repeat steps 3 to 5 for other accounts to be restricted.
7. Press [Register]. The restricted account is added.

Applying Limit of Restriction

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of Job Accounting Setting, [Next] of Default Setting and then [Change] of Apply Limit.
3. Select [Immediately], [Subsequently], or [Alert Only].
4. Press [OK].

Default Counter Limit

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].

2. Press [Next] of Job Accounting Setting, [Next] of Default Setting and then [Next] of Default Counter Limit.
3. Press [Change] for the item you want to modify and then press [+] or [-] or use the numeric keys to enter the default restriction on the number of sheets.
4. Press [OK].
5. To set another default restriction, repeat steps 3 to 4.

Total Job Accounting/Resetting the Counter

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of Job Accounting Setting and then [Next] of Total Job Accounting.
3. Press [Check] at the function to check the count. The results will be displayed.
4. Confirm the count and press [Close].
5. Press [Execute] of Counter Reset to reset the counter.
6. Press [Yes] on the screen to confirm the reset. The counter is reset.

Each Job Accounting/Resetting the Counter

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of Job Accounting Setting and [Check] of Each Job Accounting.
3. Select the account to check the count.
4. Press [Detail].
5. Press [Check] at the function to check the count. The results will be displayed.
6. Confirm the count and press [Close].
7. Press [Execute] of Counter Reset to reset the counter.
8. Press [Yes] on the screen to confirm the reset. The counter will be reset.

Counting by Paper Size

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of Job Accounting Setting, [Next] of Default Setting, [Change] of Count by Paper Size, [Change] of Paper Size 1 to 5 and then [On].
3. Select the paper size.
4. Press [Media Type] to specify media type.
5. Select the media type and press [OK].
6. Press [Close].

Printing an Accounting Report

1. If user login administration is disabled, the user authentication screen appears. Enter your login user name and password and then press [Login].
2. Press [Next] of Job Accounting Setting and then [Print] of Print Accounting Report.
3. Press [Yes] on the screen to confirm the printing.

1-4-1 Paper misfeed detection

(1) Paper misfeed indication

When a paper misfeed occurs, the machine immediately stops copying and displays the jam location on the operation panel.

Paper misfeed counts sorted by the detection condition can be checked in maintenance item U903.

To remove paper jammed in the machine, open the front cover, left cover or pull the cassette out.

To remove original jammed in the optional DP, open the DP top cover.

To remove the jammed paper in optional document finisher, detach the finisher from the machine.

Paper misfeed detection can be reset by opening and closing the respective covers to turn safety switch off and on.




Figure 1-4-1

- (A) Misfeed in cassette 1
- (B) Misfeed in cassette 2
- (C) Misfeed in optional cassette 3 or 4
- (D) Misfeed in MP tray
- (E) Misfeed in left cover 1, 2 or 3
- (F) Misfeed in duplex section
- (G) Misfeed in paper feed section
- (H) Misfeed in optional DP
- (I) Misfeed in optional document finisher
- (J) Misfeed in optional built-in finisher
- (K) Misfeed in optional job separator

(2) Paper misfeed detection conditions




Figure 1-4-2

Section	Description	Conditions	Specified time
System	00 Initial JAM	The power is turned on when a sensor in the conveying system is on.	-
	04 Cover open	Cover is open during copying.	-
	05 Secondary paper feed does not start	Secondary paper feed does not start within specified time of arrival of paper at the registration section.	40 s
	09 Sequence error jam	A communication sequence error occurs between the machine and the 3000-sheet paper feeder.	-
Paper feed section	10 No paper feed from cassette 1	Feed switch 1 (FSW1) does not turn on within the specified time of paper feed clutch 1 (PFCL1) turning on; the clutch is then successively turned off for 1 s and turned back on, but the switch again fails to turn on within the specified time.	1152 ms
	11 No paper feed from cassette 2	Feed switch 2 (FSW2) does not turn on within the specified time of paper feed clutch 2 (PFCL2) turning on; the clutch is then successively turned off for 1 s and turned back on, but the switch again fails to turn on within the specified time.	1209 ms
	12 No paper feed from cassette 3	Feed switch 3 (FSW3) does not turn on within the specified time of PF paper feed clutch 1 (PFPFCL1) turning on; the clutch is then successively turned off for 1 s and turned back on, but the switch again fails to turn on within the specified time (paper feed from paper feeder).	1209 ms
		Feed switch 3 (FSW3) does not turn on within the specified time of PF paper feed clutch 1 (PFPFCL1) turning on (paper feed from 3000-sheet paper feeder).	780 ms
	13 No paper feed from cassette 4	The PF feed switch (PFFSW) does not turn on within the specified time of PF paper feed clutch 2 (PFPFCL2) turning on; the clutch is then successively turned off for 1 s and turned back on, but the switch again fails to turn on within the specified time (paper feed from paper feeder).	1209 ms
	14 No paper feed from MP tray	The MP feed switch (MPFSW) does not turn on within the specified time of the MP paper feed clutch (MPPFCL) turning on; the clutch is then successively turned off for 1 s and turned back on, but the switch again fails to turn on within the specified time.	3913 ms
	15 Jam in paper feeder horizontal paper conveying section 1	Paper path sensor 3 (PPS3) does not turn on within specified time of PF paper feed clutch 2 (PFPFCL2) turning on (paper feed from 3000-sheet paper feeder).	360 ms
	16 Jam in paper feeder horizontal paper conveying section 2	Paper path sensor 2 (PPS2) does not turn on within specified time of the paper path sensor 3 (PPS3) turning on (paper feed from 3000-sheet paper feeder).	380 ms
17 Jam in paper feeder horizontal paper conveying section 3	Paper path sensor 1 (PPS1) does not turn on within specified time of the paper path sensor 2 (PPS2) turning on (paper feed from 3000-sheet paper feeder).	250 ms	

Section	Description	Conditions	Specified time
Paper feed section	18 Misfeed in vertical paper conveying section	The registration switch (RSW) does not turn on within specified time of feed switch 1 (FSW1) turning on.	1283 ms
		Feed switch 1 (FSW1) does not turn on within specified time of feed switch 2 (FSW2) turning on.	1478 ms
		Feed switch 2 (FSW2) does not turn on within specified time of feed switch 3 (FSW3) turning on.	1474 ms
	19 Misfeed in paper feeder vertical paper conveying section	Feed switch 3 (FSW3) does not turn on within specified time of the PF feed switch (PFFSW) turning on.	1217 ms
	20 Misfeed in MP tray vertical paper conveying section	The registration switch (RSW) does not turn on within specified time of the MP feed switch (MPFSW) turning on.	3043 ms
	21 Multiple sheets in paper feed section	The feed switch 1 (FSW1) does not turn off within specified time of its turning on.	Paper length + 3357 ms
		The feed switch 2 (FSW2) does not turn off within specified time of its turning on.	Paper length + 3357 ms
		The feed switch 3 (FSW3) does not turn off within specified time of its turning on (paper feed from paper feeder).	Paper length + 3357 ms
		The feed switch 3 (FSW3) does not turn off within specified time of its turning on (paper feed from 3000-sheet paper feeder).	1050 ms
		The PF feed switch (PFFSW) does not turn off within specified time of its turning on.	Paper length + 3357 ms
		The MP feed switch (MPFSW) does not turn off within specified time of its turning on.	Paper length + 3357 ms
		The feed switch 1 (FSW1) does not turn off within specified time of the paper feed clutch 1 (PFCL1) turning on.	1152 ms
		The feed switch 2 (FSW2) does not turn off within specified time of the paper feed clutch 2 (PFCL2) turning on.	1209 ms
		The feed switch 3 (FSW3) does not turn off within specified time of the PF paper feed clutch 1 (PFPFCL1) turning on.	2643 ms
		The PF feed switch (PFFSW) does not turn off within specified time of the PF paper feed clutch 2 (PFPFCL2) turning on.	3913 ms
		The MP feed switch (MPFSW) does not turn off within specified time of the MP paper feed clutch (MPPFCL) turning on.	3913 ms
22 Multiple sheets in vertical conveying section	The feed switch 1 (FSW1) does not turn off within specified time of the feed switch 2 (FSW2) turning off.	1478 ms	
	The feed switch 2 (FSW2) does not turn off within specified time of the feed switch 3 (FSW3) turning off.	1539 ms	
	The feed switch 1 (FSW1) does not turn off within specified time of the feed switch 2 (FSW2) turning on	1478 ms	
	The feed switch 2 (FSW2) does not turn off within specified time of the feed switch 3 (FSW3) turning on.	1474 ms	

Section	Description	Conditions	Specified time
Paper feed section	23 Multiple sheets in MP tray conveying section	The registration switch (RSW) does not turn off within specified time of the MP feed switch (MPFSW) turning off.	2739 ms
		The registration switch (RSW) does not turn off within specified time of the MP feed switch (MPFSW) turning on.	3043 ms
Paper conveying section	30 Misfeed in registration/transfer section	The registration switch (RSW) does not turn off within specified time of the feed switch 1 (FSW1) turning off.	1170 ms
		The registration switch (RSW) does not turn off within specified time of the feed switch 1 (FSW1) turning on.	1278 ms
Fuser section	40 Misfeed in fuser section (MP tray)	The eject switch (ESW) does not turn on within specified time of the registration clutch (RCL) turning on.	2243 ms
		The feedshift switch (FSSW) does not turn on within specified time of the registration clutch (RCL) turning on.	2243 ms
	41 Misfeed in fuser section (cassette 1)	The eject switch (ESW) does not turn on within specified time of the registration clutch (RCL) turning on.	2243 ms
		The feedshift switch (FSSW) does not turn on within specified time of the registration clutch (RCL) turning on.	2243 ms
	42 Misfeed in fuser section (cassette 2)	The eject switch (ESW) does not turn on within specified time of the registration clutch (RCL) turning on.	2243 ms
		The feedshift switch (FSSW) does not turn on within specified time of the registration clutch (RCL) turning on.	2243 ms
	43 Misfeed in fuser section (cassette 3)	The eject switch (ESW) does not turn on within specified time of the registration clutch (RCL) turning on.	2243 ms
		The feedshift switch (FSSW) does not turn on within specified time of the registration clutch (RCL) turning on.	2243 ms
	44 Misfeed in fuser section (cassette 4)	The eject switch (ESW) does not turn on within specified time of the registration clutch (RCL) turning on.	2243 ms
		The feedshift switch (FSSW) does not turn on within specified time of the registration clutch (RCL) turning on.	2243 ms
	46 Misfeed in fuser section (3000-sheet paper feeder)	The eject switch (ESW) does not turn on within specified time of the registration clutch (RCL) turning on.	2243 ms
		The feedshift switch (FSSW) does not turn on within specified time of the registration clutch (RCL) turning on.	2243 ms
	47 Misfeed in fuser section (duplex section)	The eject switch (ESW) does not turn on within specified time of the registration clutch (RCL) turning on.	2243 ms
		The feedshift switch (FSSW) does not turn on within specified time of the registration clutch (RCL) turning on.	2243 ms
Eject section	50 Misfeed in eject section	The eject switch (ESW) does not turn off within specified time of the registration switch (RSW) turning off.	2243 ms
		The eject switch (ESW) does not turn off within specified time of the registration clutch (RCL) turning on.	2243 ms

Section	Description	Conditions	Specified time
Eject section	51 Misfeed in job separator eject section	The job eject switch (JESW) does not turn on within specified time of the feedshift switch (FSSW) turning on.	1587 ms
		The job eject switch (JESW) does not turn off within specified time of the feedshift switch (FSSW) turning off.	1587 ms
		The job eject switch (JESW) does not turn off within specified time of the feedshift switch (FSSW) turning on.	1587 ms
Feedshift section	52 Misfeed in feedshift section	The feedshift switch (FSSW) does not turn on within specified time of the start of eject motor (EM) reverse rotation.	1196 ms
		During paper switchback operation, the feedshift switch (FSSW) does not turn off within specified time of the its turning on.	2313 ms
		The feedshift switch (FSSW) does not turn off within specified time of the registration switch (RSW) turning off.	2243 ms
		The feedshift switch (FSSW) does not turn off within specified time of the registration clutch (RCL) turning on.	2243 ms
Duplex section	60 Duplex paper conveying section 1	The duplex paper conveying switch (DUPPCSW) does not turn on within specified time of the feedshift switch (FSSW) turning on.	2196 ms
		The duplex paper conveying switch (DUPPCSW) does not turn off within specified time of the feedshift switch (FSSW) turning off.	2196 ms
	61 Duplex paper conveying section 2	The feed switch 1 (FSW1) does not turn on within specified time of the duplex paper conveying switch (DUPPCSW) turning on.	1543 ms
		The feed switch 1 (FSW1) does not turn off within specified time of the duplex paper conveying switch (DUPPCSW) turning off.	1543 ms
DP	70 No original feed	The original feed switch (OFSW) does not turn on within specified time during the first sheet feeding (Retry 5 times).	1159 ms
		The original feed switch (OFSW) does not turn on within specified time during the second sheet feeding (Retry 5 times).	1159 ms
		During original tray ascent, the tray upper limit switch (TULSW) does not turn on within specified time.	2 s
	71 An original jam in the original feed section	The original registration switch (ORSW) does not turn on within specified time of the original feed switch (OFSW) turning on.	1013 ms
	72 An original jam in the original conveying section	DP timing switch 1 (DPTSW1) turns off within the specified time since the switch turns on.	914 ms

Section	Description	Conditions	Specified time
DP	73 An original jam in the original registration section	During single scanning, the DP timing switch 1 (DPTSW1) does not turn on within specified time of the original registration switch (ORSW) turning on (Retry 5 times).	1774 ms
		During duplex switchback scanning, the DP timing switch 1 (DPTSW1) does not turn on within specified time of the original registration switch (ORSW) turning on (Retry 5 times).	1774 ms
		During dual scanning, the DP timing switch 2 (DPTSW2) does not turn on within specified time of the original registration switch (ORSW) turning on (Retry 5 times).	1014 ms
	74 An original jam in the original feed section	The original feed switch (OFSW) or original registration switch (ORSW) does not turn off within specified time of the DP timing switch 1 (DPTSW1) turning on.	2084 ms
		Scanning of previous original is not complete when DP timing switch 1 (DPTSW1) turns on.	-
	75 An original jam in the original conveying section	During single scanning, the DP timing switch 1 (DPTSW1) does not turn off within specified time of the original registration switch (ORSW) turning off.	1416 ms
		During duplex switchback scanning, the DP timing switch 1 (DPTSW1) does not turn off within specified time of the original registration switch (ORSW) turning off.	1416 ms
		During dual scanning, the DP timing switch 2 (DPTSW2) does not turn off within specified time of the original registration switch (ORSW) turning off.	656 ms
	76 An original jam in the original switchback section 1	During duplex switchback scanning, the switchback tray switch (SBTSW) does not turn on within specified time of the DP timing switch 1 (DPTSW1) turning on.	2318 ms
	77 An original jam in the original switchback section 2	During duplex switchback scanning, the original registration switch (ORSW) does not turn on within specified time since original switchback operation starts.	935 ms
	78 DP cover open JAM	The DP or DP top cover is opened during original feeding.	-
		When the power is turned on or original feeding starts, the original feed switch (OFSW), the original registration switch (ORSW) or DP timing switch 1, 2 (DPTSW1, 2) turning on.	-
	79 An original jam in the original eject section	During single scanning or dual scanning, the original eject switch (OESW) does not turn on within specified time of the DP timing switch 1 (DPTSW1) turning on.	1705 ms
		During duplex switchback scanning, the original eject switch (OESW) does not turn on within specified time since switchback ejection starts.	841 ms
		During single scanning or dual scanning, the original eject switch (OESW) does not turn off within specified time of the DP timing switch 1 (DPTSW1) turning off.	1705 ms

Section	Description	Conditions	Specified time
Finisher	80 Jam between the finisher and machine	Paper ejection is not output from the machine to the document finisher within specified time of the paper entry sensor (PES) turning on.	15 s
	81 Paper entry sensor non arrival jam	(3000-sheet document finisher) The paper entry sensor (PES) is not turned off even if a specified time has elapsed after the machine eject signal was received.	1052 ms
		(3000-sheet document finisher) The paper entry sensor (PES) is not turned on even if a specified time has elapsed after the machine eject signal was received.	1052 ms
		(3000-sheet document finisher) The paper entry sensor (PES) does not turn off within specified time of its turning on.	2313 ms
		(Document finisher) The paper entry sensor (PES) is not turned on even if a specified time has elapsed after the machine eject signal was received.	733 ms
		(Built-in finisher) The paper conveying switch (PCSW) is not turned on even if a specified time has elapsed after the machine eject signal was received.	1217 ms
		(Built-in finisher) The paper conveying switch (PCSW) does not turn off within specified time of its turning on when paper is conveyed to the intermediate tray from the paper conveying unit.	Paper length + 869 ms
		(3000-sheet document finisher) The home position is not detected within the specified time when driving the staple motor.	600 ms
	82 Jam in stapler	(Document finisher) The staple home position sensor (STSPS) is not turned on within the specified time when driving the staple motor (STM).	-
		(Built-in finisher) The staple home position sensor (STHPS) is not turned on within the specified time when driving the staple motor (STM).	600 ms
		(3000-sheet document finisher) Eject switch 1 (ESW1) is not turned off within specified time of its turning on.	1182 ms
	83 Eject sensor stay jam	(Document finisher) In the straight mode, the exit sensor (EPS) is not turned off within specified time of its turning on.	-
		(Document finisher) In the bundle discharge mode or the staple mode, bundle discharge operation does not turn off within specified time since the operation starts.	902 ms
		(Built-in finisher) The paper conveying switch (PCSW) does not turn off within specified time of its turning on when paper is ejected to the finisher tray from the intermediate tray.	Paper length + 869 ms

Section	Description	Conditions	Specified time
Finisher	84 Jam in eject section of right sub tray (3000-sheet document finisher only)	Eject switch 2 (ESW2) is not turned off even if a specified time has elapsed after the machine eject signal was received.	1209 ms
		Eject switch 2 (ESW2) is not turned on even if a specified time has elapsed after the machine eject signal was received.	1209 ms
		Eject switch 2 (ESW2) is not turned off within specified time of its turning on.	2313 ms
	85 Jam in eject section of left sub tray (3000-sheet document finisher only)	Eject switch 3 (ESW3) does not turn off within specified time of paper entry sensor (PES) turning on.	1426 ms
		Eject switch 3 (ESW3) does not turn on within specified time of paper entry sensor (PES) turning on.	1426 ms
		Eject switch 3 (ESW3) is not turned off within specified time of its turning on.	2313 ms
	86 Jam in eject section of internal tray 1 (3000-sheet document finisher only)	Internal tray entry sensor 1 (ITPES1) is not turned on even if a specified time has elapsed after the eject signal was received.	2070 ms
	87 Jam in eject section of inner tray 2 (3000-sheet document finisher only)	Inner tray entry sensor 2 (ITPES2) does not turn on within specified time of the paper entry sensor (PES) turning on.	1322 ms
		Inner tray entry sensor 2 (ITPES2) does not turn off within specified time of the paper entry sensor (PES) turning off.	676 ms
	88 Jam in eject section of main tray (3000-sheet document finisher only)	Eject switch 1 (ESW1) is not turned on within specified time.	1324 ms
		At the time of bundle up initial operation, paper conveying belt home position sensor 1 (PCBHPS1) does not turn on.	-
		At the time of bundle down initial operation, paper conveying belt home position sensor 2 (PCBHPS2) does not turn on.	-
		At the time of side registration standby operation, side registration home position sensor 1 (SRHPS1) does not turn off within specified time.	500 ms
		At the time of side registration standby operation, side registration home position sensor 2 (SRHPS2) does not turn off within specified time.	500 ms

Section	Description	Conditions	Specified time
Finisher	89 Jam in center-folding unit (3000-sheet document finisher only)	The centerfold paper entry sensor (CPES) does not turn off within specified time of centerfold paper conveying sensor (CPCS) turning on.	5373 ms
		The centerfold paper entry sensor (CPES) does not turn on within specified time of centerfold paper conveying sensor (CPCS) turning on.	5373 ms
		The centerfold paper entry sensor (CPES) is not turned off within specified time of its turning on.	2313 ms
		The centerfold eject switch (CESW) is not turned on within specified time.	4080 ms
		The centerfold eject switch (CESW) is not turned off within specified time of its turning on.	8200 ms
		Centerfold side registration sensor 1 (CSRS1) is not turned on within specified time.	600 ms
		Centerfold side registration sensor 2 (CSRS2) is not turned on within specified time.	600 ms
		The home position is not detected within the specified time after driving the centerfold staple motor (CSTM).	1000 ms
		The centerfold paper conveying sensor (CPCS) is not turned off within specified time.	1370 ms
		The centerfold paper conveying sensor (CPCS) is not turned on within specified time.	1370 ms
		The centerfold paper conveying sensor (CPCS) is not turned off within specified time of its turning on.	2313 ms
		90 Jam in mailbox (3000-sheet document finisher only)	The tray eject sensor (TEJS) does not turn on within specified time from start of paper eject (tray 1).
	The tray eject sensor (TEJS) does not turn on within specified time from start of paper eject (tray 2).		4633 ms
	The tray eject sensor (TEJS) does not turn on within specified time from start of paper eject (tray 3).		4147 ms
	The tray eject sensor (TEJS) does not turn on within specified time from start of paper eject (tray 4).		3660 ms
	The tray eject sensor (TEJS) does not turn on within specified time from start of paper eject (tray 5).		3173 ms
	The tray eject sensor (TEJS) does not turn on within specified time from start of paper eject (tray 6).		2687 ms
	The tray eject sensor (TEJS) does not turn on within specified time from start of paper eject (tray 7).		2200 ms
	The tray eject sensor (TEJS) is not turned off within specified time of its turning on.	Depends on paper size	

Section	Description	Conditions	Specified time
Finisher	91 Finisher cover open	(3000-sheet document finisher) The front cover, top cover or right sub tray is opened when starting the finisher operation. The centerfold unit top cover is opened when starting the center-fold operation. The mailbox cover is opened when starting the operation.	-
		(Document finisher) The finisher cover becomes open during paper is running. Paper is remaining in paths at power on.	-
	92 Eject paper sensor non-arrival jam (document finisher only)	In the straight mode, the eject paper sensor (EPS) is not turned on even if a specified time has elapsed after the paper entry sensor (PES) was turned on.	-
	93 Reverse sensor jam (document finisher only)	The reverse sensor (SBS) does not turn on within specified time of paper entry sensor (PES) turning on (unfinished reversing canceled).	437 ms
		The reverse sensor (SBS) is not turned on within specified time (unfinished reversing set).	431 ms
		The reverse sensor (SBS) is not turned off within specified time its turning on (resident reversing canceled).	1826 ms
		The reverse sensor (SBS) is not turned off within specified time its turning on (resident reversing set).	700 ms
	94 Paper entry sensor stay/remaining jam (document finisher only)	The paper entry sensor (PES) is not turned off within specified time its turning on.	1370 ms
	95 Paper conveying sensor jam (document finisher only)	The paper conveying sensor (PCS) is not turned off within specified time its turning on (reversing canceled).	1370 ms
		The paper conveying sensor (PCS) is not turned off within specified time its turning on (reversing set).	656 ms
	96 Jam between the built-in finisher and machine (built-in finisher only)	Paper ejection is not output from the machine to the document finisher within specified time of the intermediate tray sensor (ITS) turning on.	1217 ms

(3) Paper misfeeds

Problem	Causes/check procedures	Corrective measures
(1) A paper jam in the paper feed, conveying or eject section is indicated as soon as the main power switch is turned on.	A piece of paper torn from copy paper is caught around feed switch 1/2/3, registration switch, eject switch or feedshift switch.	Check visually and remove it, if any.
	Defective switch.	Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Feed switch 1/2/3, registration switch, eject switch, feedshift switch
(2) A paper jam in the paper feed section is indicated during copying (no paper feed from cassette 1). Jam code 10	Paper is extremely curled.	Replace the paper.
	Check if the paper feed pulley, separation pulley or forwarding pulley of the cassette 1 are deformed.	Check visually and replace any deformed pulleys.
	Broken feed switch 1 actuator.	Check visually and replace switch.
	Defective feed switch 1.	Run maintenance item U031 and turn feed switch 1 on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
	Check if the paper feed clutch 1 malfunctions.	Run maintenance item U032 and select the paper feed clutch 1 on the touch panel to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the paper feed clutch 1.	Check (see page 1-4-57).
(3) A paper jam in the paper feed section is indicated during copying (no paper feed from cassette 2). Jam code 11	Paper is extremely curled.	Replace the paper.
	Check if the paper feed pulley, separation pulley or forwarding pulley of the cassette 2 are deformed.	Check visually and replace any deformed pulleys.
	Broken feed switch 2 actuator.	Check visually and replace switch.
	Defective feed switch 2.	Run maintenance item U031 and turn feed switch 2 on and off manually. Replace feed switch 2 if indication of the corresponding switch on the touch panel is not displayed in reverse.
	Check if the paper feed clutch 2 malfunctions.	Run maintenance item U032 and select the paper feed clutch 2 on the touch panel to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the paper feed clutch 2.	Check (see page 1-4-57).

Problem	Causes/check procedures	Corrective measures	
(4) A paper jam in the paper feed section is indicated during copying (no paper feed from cassette 3). Jam code 12	Paper feeder		
	Paper is extremely curled.	Replace the paper.	
	Check if the paper feed pulley, forwarding pulley and separation pulley of cassette 3 are deformed.	Check visually and replace any deformed pulleys.	
	Broken feed switch 3 actuator.	Check visually and replace switch.	
	Defective feed switch 3.	Run maintenance item U031 and turn feed switch 3 on and off manually. Replace feed switch 3 if indication of the corresponding switch on the touch panel is not displayed in reverse.	
	Check if PF paper feed clutch 1 malfunctions.	Run maintenance item U247 and select PF paper feed clutch 1 on the touch panel to be turned on and off. Check the status and remedy if necessary.	
	Electrical problem with PF paper feed clutch 1.	Check (see service manual of paper feeder).	
	3000-sheet paper feeder		
	Paper is extremely curled.	Replace the paper.	
	Broken feed switch 3 actuator.	Check visually and replace switch.	
	Defective feed switch 3.	Run maintenance item U031 and turn feed switch 3 on and off manually. Replace feed switch 3 if indication of the corresponding switch on the touch panel is not displayed in reverse.	
	Check if the clutch malfunctions.	Run maintenance item U247 and select following clutch on the touch panel to be turned on and off. Check the status and remedy if necessary. PF paper feed clutch 1/2, PF paper conveying clutch	
	Electrical problem with clutch.	Check (see service manual of 3000-sheet paper feeder).	
	(5) A paper jam in the paper feed section is indicated during copying (no paper feed from cassette 4). Jam code 13	Paper is extremely curled.	Replace the paper.
Check if the paper feed pulley, forwarding pulley and separation pulley of cassette 4 are deformed.		Check visually and replace any deformed pulleys.	
Broken paper feeder feed switch actuator.		Check visually and replace switch.	
Defective PF feed switch.		With 5 V DC present at YC3-7 on the PF main PWB, check if YC3-5 on the PF main PWB remains low or high when the PF feed switch is turned on and off. If it does, replace the PF feed switch.	
Check if PF paper feed clutch 2 malfunctions.		Run maintenance item U247 and select PF paper feed clutch 2 on the touch panel to be turned on and off. Check the status and remedy if necessary.	
Electrical problem with PF paper feed clutch 2.	Check (see service manual of paper feeder).		

Problem	Causes/check procedures	Corrective measures
(6) A paper jam in the paper feed section is indicated during copying (no paper feed from MP tray). Jam code 14	Paper is extremely curled.	Replace the paper.
	Check if the MP paper feed pulley, MP forwarding pulley and MP separation pulley are deformed.	Check visually and replace any deformed pulleys.
	Broken MP feed switch actuator.	Check visually and replace switch.
	Defective MP feed switch.	Run maintenance item U031 and turn MP feed switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
	Check if the MP paper feed clutch malfunctions.	Run maintenance item U032 and select MP paper feed clutch on the touch panel to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the MP paper feed clutch.	Check (see page 1-4-57).
(7) A paper jam in the paper feed section is indicated during copying (jam in 3000-sheet paper feeder horizontal paper conveying section). Jam code 15	Paper is extremely curled.	Replace the paper.
	Check if the paper side guides are deformed.	Check visually and replace.
	Defective paper path sensor 3.	With 5 V DC present at CN6-12 on the PF main PWB, check if CN6-11 on the PF main PWB remains low or high when paper path sensor 3 is turned on and off. If it does, replace paper path sensor 3.
	Check if PF paper feed clutch 2 malfunctions.	Run maintenance item U247 and select PF paper feed clutch 2 on the touch panel to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with PF paper feed clutch 2.	Check (see service manual of 3000-sheet paper feeder).
(8) A paper jam in the paper feed section is indicated during copying (jam in 3000-sheet paper feeder horizontal paper conveying section). Jam code 16	Paper is extremely curled.	Replace the paper.
	Check if the paper side guides are deformed.	Check visually and replace.
	Defective paper path sensor 2.	With 5 V DC present at CN6-9 on the PF main PWB, check if CN6-8 on the PF main PWB remains low or high when paper path sensor 2 is turned on and off. If it does, replace paper path sensor 2.
	Check if PF paper feed clutch 1 malfunctions.	Run maintenance item U247 and select PF paper feed clutch 1 on the touch panel to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with PF paper feed clutch 1.	Check (see service manual of 3000-sheet paper feeder).

Problem	Causes/check procedures	Corrective measures
(9) A paper jam in the paper feed section is indicated during copying (jam in 3000-sheet paper feeder horizontal paper conveying section). Jam code 17	Paper is extremely curled.	Replace the paper.
	Check if the paper side guides are deformed.	Check visually and replace.
	Defective paper path sensor 1.	With 5 V DC present at CN6-6 on the PF main PWB, check if CN6-5 on the PF main PWB remains low or high when paper path sensor 1 is turned on and off. If it does, replace paper path sensor 1.
	Check if PF paper conveying clutch malfunctions.	Run maintenance item U247 and select PF paper conveying clutch on the touch panel to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with PF paper conveying clutch.	Check (see service manual of 3000-sheet paper feeder).
(10) A paper jam in the paper feed section is indicated during copying (jam in vertical paper conveying section). Jam code 18	Broken feed switch 1/2/3 actuator.	Check visually and replace switch.
	Defective switch.	Run maintenance item U031 and turn following switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Feed switch 1/2/3, registration switch
	Defective feed pulleys or feed rollers.	Check visually and replace.
(11) A paper jam in the paper feed section is indicated during copying (jam in paper feeder vertical paper conveying section). Jam code 19	Broken feed switch 3 actuator.	Check visually and replace switch.
	Defective feed switch 3.	Run maintenance item U031 and turn feed switch 3 on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
	Broken PF feed switch actuator.	Check visually and replace switch.
	Defective PF feed switch.	With 5 V DC present at YC3-7 on the PF main PWB, check if YC3-5 on the PF main PWB remains low or high when the PF feed switch is turned on and off. If it does, replace the PF feed switch.
(12) A paper jam in the paper feed section is indicated during copying (jam in MP tray vertical paper conveying section). Jam code 20	Broken MP feed switch actuator.	Check visually and replace switch.
	Defective switch.	Run maintenance item U031 and turn following switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. MP feed switch, registration switch

Problem	Causes/check procedures	Corrective measures
(13) A paper jam in the paper feed section is indicated during copying (multiple sheets in paper feed section). Jam code 21	Broken feed switch 1/2/3 or MP feed switch actuator.	Check visually and replace switch.
	Defective switch.	Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Feed switch 1/2/3, MP feed switch
	Broken PF feed switch actuator.	Check visually and replace switch.
	Defective PF feed switch.	With 5 V DC present at YC3-7 on the PF main PWB, check if YC3-5 on the PF main PWB remains low or high when the PF feed switch is turned on and off. If it does, replace the PF feed switch.
	Check if the clutch malfunctions.	Run maintenance item U032 and select following clutch on the touch panel to be turned on and off. Check the status and remedy if necessary. Paper feed clutch 1/2, MP paper conveying clutch
	Electrical problem with clutch.	Check (see page 1-4-57).
	Check if PF paper feed clutch 1/2 malfunctions.	Run maintenance item U247 and select PF paper feed clutch 1/2 on the touch panel to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with PF paper feed clutch 1/2.	Check (see service manual of 3000-sheet paper feeder).
(14) A paper jam in the paper feed section is indicated during copying (multiple sheets in vertical conveying section). Jam code 22	Broken feed switch 1/2/3 actuator.	Check visually and replace switch.
	Defective switch.	Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Feed switch 1/2/3
	Defective feed pulleys or feed rollers.	Check visually and replace.
(15) A paper jam in the paper feed section is indicated during copying (multiple sheets in MP tray conveying section). Jam code 23	Broken MP feed switch actuator.	Check visually and replace switch.
	Defective switch.	Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. MP feed switch, registration switch
(16) A paper jam in the paper conveying section is indicated during copying (jam in registration/transfer section). Jam code 30	Broken feed switch 1 actuator.	Check visually and replace switch.
	Defective switch.	Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Feed switch 1, registration switch
	The contact between the right and left registration rollers is not correct.	Check visually and replace.

Problem	Causes/check procedures	Corrective measures
(17) A paper jam in the fuser section is indicated during copying (jam in fuser section). Jam codes 40 to 44, 46 and 47	Broken eject switch or feedshift switch actuator.	Check visually and replace switch.
	Defective switch.	Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Eject switch, feedshift switch
	Check if the registration clutch malfunctions.	Run maintenance item U032 and select the registration clutch on the touch panel to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the registration clutch.	Check (see page 1-4-57).
(18) A paper jam in the eject section is indicated during copying (jam in eject section). Jam code 50	Broken eject switch actuator.	Check visually and replace switch.
	Defective switch.	Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Registration switch, eject switch
	Check if the registration clutch malfunctions.	Run maintenance item U032 and select the registration clutch on the touch panel to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the registration clutch.	Check (see page 1-4-57).
(19) A paper jam in the eject section is indicated during copying (jam in job separator eject section). Jam code 51	Broken feedshift switch or job eject switch actuator.	Check visually and replace switch.
	Defective switch.	Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Feedshift switch, job eject switch
(20) A paper jam in the feedshift section is indicated during copying (jam in feedshift section). Jam code 52	Check if the feedshift solenoid malfunctions.	Run maintenance item U033 and select the feedshift solenoid on the touch panel to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the feedshift solenoid.	Check (see page 1-4-57).
	Broken feedshift switch actuator.	Check visually and replace switch.
	Defective switch.	Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Feedshift switch, registration switch
	Check if the registration clutch malfunctions.	Run maintenance item U032 and select the registration clutch on the touch panel to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the registration clutch.	Check (see page 1-4-57).

Problem	Causes/check procedures	Corrective measures
(21) A paper jam in the duplex section is indicated during copying (jam in duplex paper conveying section 1). Jam code 60	Broken feedshift switch or duplex paper conveying switch actuator.	Check visually and replace switch.
	Defective switch.	Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Feedshift switch, duplex paper conveying switch
(22) A paper jam in the duplex section is indicated during copying (jam in duplex paper conveying section 2). Jam code 61	Broken duplex paper conveying switch or feed switch 1 actuator.	Check visually and replace switch.
	Defective switch.	Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Duplex paper conveying switch, feed switch 1
(23) An original jams in DP is indicated during copying (no original feed). Jam code 70	Defective original feed switch.	Run maintenance item U244 and turn the original feed switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
	Defective original feed motor.	Run maintenance item U243 and select original feed motor on the touch panel to be turned on and off. Check the status and remedy if necessary.
	Defective tray upper limit switch.	Run maintenance item U244 and turn the tray upper limit switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
	Defective original lift motor.	Run maintenance item U243 and select original lift motor on the touch panel to be turned on and off. Check the status and remedy if necessary.
(24) An original jams in DP is indicated during copying (jam in the original feed section). Jam code 71	Defective switch.	Run maintenance item U244 and turn the following switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Original feed switch, original registration switch
	Defective motor.	Run maintenance item U243 and select the following motor on the touch panel to be turned on and off. Check the status and remedy if necessary. Original feed motor, original conveying motor
(25) An original jams in DP is indicated during copying (jam in the original conveying section). Jam code 72	Defective DP timing switch 1.	Run maintenance item U244 and turn the DP timing switch 1 on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
	Defective motor.	Run maintenance item U243 and select the following motor on the touch panel to be turned on and off. Check the status and remedy if necessary. Original feed motor, original conveying motor
(26) An original jams in DP is indicated during copying (jam in the original registration section). Jam code 73	Defective switch.	Run maintenance item U244 and turn the following switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Original registration switch, DP timing switch 1/2
	Defective motor.	Run maintenance item U243 and select the following motor on the touch panel to be turned on and off. Check the status and remedy if necessary. Original feed motor, original conveying motor

Problem	Causes/check procedures	Corrective measures
(27) An original jams in DP is indicated during copying (jam in the original feed section). Jam code 74	Defective switch.	Run maintenance item U244 and turn the following switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. DP timing switch1, original feed switch, original registration switch
	Defective motor.	Run maintenance item U243 and select the following motor on the touch panel to be turned on and off. Check the status and remedy if necessary. Original feed motor, original conveying motor
(28) An original jams in DP is indicated during copying (jam in the original conveying section). Jam code 75	Defective switch.	Run maintenance item U244 and turn the following switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Original registration switch, DP timing switch 1/2
	Defective motor.	Run maintenance item U243 and select the following motor on the touch panel to be turned on and off. Check the status and remedy if necessary. Original feed motor, original conveying motor
(29) An original jams in DP is indicated during copying (jam in the original switchback section 1). Jam code 76	Defective switch.	Run maintenance item U244 and turn the following switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. DP timing switch 1, switchback tray switch
	Defective motor.	Run maintenance item U243 and select the following motor on the touch panel to be turned on and off. Check the status and remedy if necessary. Original conveying motor, original switchback motor
(30) An original jams in DP is indicated during copying (jam in the original switchback section 2). Jam code 77	Defective original registration switch.	Run maintenance item U244 and turn the original registration switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
	Defective motor.	Run maintenance item U243 and select the following motor on the touch panel to be turned on and off. Check the status and remedy if necessary. Original switchback motor, original feed motor
(31) A original jam in the DP is indicated as soon as the main power switch is turned on. (DP cover open JAM). Jam code 78	A piece of paper torn from original is caught around original feed switch, original registration switch or DP timing switch 1/2.	Check visually and remove it, if any.
	Defective switch.	Run maintenance item U244 and turn the following switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Original feed switch, original registration switch, DP timing switch 1/2
(32) An original jams in DP is indicated during copying (jam in the original eject section). Jam code 79	Defective switch.	Run maintenance item U244 and turn the following switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. DP timing switch 1, original eject switch
	Defective motor.	Run maintenance item U243 and select the following motor on the touch panel to be turned on and off. Check the status and remedy if necessary. Original feed motor, original switchback motor

Problem	Causes/check procedures	Corrective measures	
(33) A paper jam in finisher is indicated during copying (jam between finisher and machine). Jam code 80	Defective paper entry sensor.	(3000-sheet document finisher) Run maintenance item U241 and turn the paper entry sensor on and off manually. Replace the sensor if indication of the corresponding sensor on the touch panel is not displayed in reverse.	
(34) A paper jam in finisher is indicated during copying (paper jam during paper insertion to the finisher). Jam code 81	3000-sheet document finisher		
	Extremely curled paper.	Change the paper.	
	Defective paper entry sensor.	Run maintenance item U241 and turn the paper entry sensor on and off manually. Replace the sensor if indication of the corresponding sensor on the touch panel is not displayed in reverse.	
	Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.	
	Document finisher		
	Extremely curled paper.	Change the paper.	
	Defective paper entry sensor.	With 5 V DC present at CN3-1 and CN3-3 on the finisher main PWB, check if CN3-2 and CN3-4 on the finisher main PWB remains low or high when the paper entry sensor is turned on and off. If it does, replace the paper entry sensor.	
	Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.	
	Built-in finisher		
	Extremely curled paper.	Replace the paper.	
	Defective paper conveying switch.	With 5 V DC present at YC2-23 on the finisher control PWB, check if YC2-21 on the finisher control PWB remains low or high when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch.	
	Check if the feedshift roller or feedshift pulley is deformed.	Check and remedy.	
(35) A paper jam in finisher is indicated during copying (finisher stapler jam). Jam code 82	3000-sheet document finisher/Document finisher		
	Defective staple home position sensor.	Run maintenance item U241 and turn the staple home position sensor on and off manually. Replace the sensor if indication of the corresponding sensor on the touch panel is not displayed in reverse.	
	Built-in finisher		
	The stapler is blocked with a staple.	Remove the stapler cartridge, and check the cartridge and the stapling section of the stapler. Remove the staple if any.	
Defective stapler section.	With 5 V DC present at YC2-24 on the finisher control PWB, check if YC2-19 on the finisher control PWB remains low or high. If it does, replace the stapler section.		

Problem	Causes/check procedures	Corrective measures
(36) A paper jam in finisher is indicated during copying (eject sensor stay jam). Jam code 83	3000-sheet document finisher	
	Defective eject switch 1.	Run maintenance item U241 and turn eject switch 1 on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
	Document finisher	
	Defective eject paper sensor.	With 5 V DC present at CN7-1 on the finisher main PWB, check if CN7-3 on the finisher main PWB remains low or high when the eject paper sensor is turned on and off. If it does, replace the eject paper sensor.
	Check if the paper conveying motor malfunctions.	Check and remedy.
	Check if the eject roller and eject pulley contact each other.	Check and remedy.
	Check if the eject guide is deformed.	Check and remedy.
	Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.
	Built-in finisher	
	Defective paper conveying switch.	With 5 V DC present at YC2-23 on the finisher control PWB, check if YC2-21 on the finisher control PWB remains low when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch.
Check if the feedshift roller or feedshift pulley is deformed.	Check and remedy.	
(37) A paper jam in finisher is indicated during copying (right sub tray eject jam). Jam code 84	Defective eject switch 2.	Run maintenance item U241 and turn eject switch 2 on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
(38) A paper jam in finisher is indicated during copying (left sub tray eject jam). Jam code 85	Defective eject switch 3.	Run maintenance item U241 and turn eject switch 3 on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
(39) A paper jam in finisher is indicated during copying (internal tray paper entry sensor 1 jam). Jam code 86	Defective internal tray paper entry sensor 1.	Run maintenance item U241 and turn internal tray paper entry sensor 1 on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
(40) A paper jam in finisher is indicated during copying (inner tray paper entry sensor 2 jam). Jam code 87	Defective inner tray paper entry sensor 2.	Run maintenance item U241 and turn inner tray paper entry sensor 2 on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.

Problem	Causes/check procedures	Corrective measures
(41) A paper jam in finisher is indicated during copying (main tray eject jam). Jam code 88	Defective eject switch 1.	Run maintenance item U241 and turn eject switch 1 on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
(42) A paper jam in finisher is indicated during copying (centerfolding unit jam). Jam code 89	Defective sensor/switch.	Run maintenance item U241 and turn the following switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Centerfold paper entry sensor, centerfold eject switch, centerfold paper conveying sensor
(43) A paper jam in finisher is indicated during copying (mailbox jam). Jam code 90	Defective tray eject sensor.	Run maintenance item U241 and turn tray eject sensor on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
(44) A paper jam in finisher is indicated during copying (switchback sensor jam). Jam code 93	Defective switchback sensor.	With 5 V DC present at CN3-5 on the finisher main PWB, check if CN3-7 on the finisher main PWB remains low or high when the switchback sensor is turned on and off. If it does, replace the switchback sensor.
	Check if the switchback motor malfunctions.	Check.
	Check if the switchback roller and switchback pulley contact each other.	Check and remedy.
	Check if the switchback guide is deformed.	Check and remedy.
	Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.
(45) A paper jam in finisher is indicated during copying (paper entry sensor stay jam). Jam code 94	Extremely curled paper.	Change the paper.
	Defective paper entry sensor.	With 5 V DC present at CN3-1 and CN3-3 on the finisher main PWB, check if CN3-2 and CN3-4 on the main PCB remains low or high when the paper entry sensor is turned on and off. If it does, replace the paper entry sensor.
	Check if the paper entry guide is deformed.	Check and remedy.
	Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.

Problem	Causes/check procedures	Corrective measures
(46) A paper jam in finisher is indicated during copying (paper conveying sensor jam). Jam code 95	Defective paper conveying sensor.	With 5 V DC present at CN9-1 on the finisher main PWB, check if CN9-3 on the finisher main PWB remains low or high when the paper conveying sensor is turned on and off. If it does, replace the paper conveying sensor.
	Check if the paper conveying motor malfunctions.	Check.
	Check if the paper conveying roller and paper conveying pulley contact each other.	Check and remedy.
	Check if the paper conveying guide is deformed.	Check and remedy.
	Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.
(47) A paper jam in built-in finisher is indicated during copying (jam between finisher and machine). Jam code 96	Defective intermediate tray sensor.	With 5 V DC present at YC3-1 on the finisher control PWB, check if YC3-2 on the finisher control PWB remains low or high when the intermediate tray sensor is turned on and off. If it does, replace the intermediate tray sensor.

1-4-2 Self-diagnosis

(1) Self-diagnostic function

This unit is equipped with a self-diagnostic function. When a problem is detected, copying is disabled and the problem displayed as a code consisting of C followed by a number, indicating the nature of the problem.

A message is also displayed requesting the user to call for service.

After removing the problem, the self-diagnostic function can be reset by turning safety switches off and back on.

List of system errors

When an unexpected error is detected for some reason, a system error will be indicated. (When 0800 error is detected, JAM05 is indicated.) After a system error is indicated, the error can be cleared by turning the power switch off and then on. If the error is detected continuously, however, perform the operation shown in Table 1-4-1. If a system error occurs frequently, a fault may have occurred. Check the details of the C call to take proper measures.

System error	Contents	Operation
0800	Image processing problem	Repetition of JAM05 → System error → JAM05
1800	Paper feeder communication error (optional paper feeder)	System error → service call → partial operation
4100	BD initialization problem	System error → Normal service call processing
8800	Document finisher communication error (optional 3000-sheet document finisher)	System error → service call → partial operation
9000	DP communication problem (optional DP)	System error → service call → partial operation

Table 1-4-1

In addition, it is a system error if the following error code is displayed. When an error has occurred, clear the error by turning the main power switch off then on.

CF1XX, CF2XX, CF3XX, CF4XX, CF5XX, CF6XX, CF7XX, CFAXX, CFBXX, 0xFBXX

Partial operation control

If one of the following service codes is detected, partial operation control will be activated. Take actions to clear the cause of the trouble and perform maintenance item U906 to reset partial operation control.

Code	Contents
C0840	Faults of RTC
C1010	Lift motor 1 error
C1020	Lift motor 2 error
C1030	PF lift motor 1 error (optional paper feeder)
C1040	PF lift motor 2 error (optional paper feeder)
C1100	PF lift motor 1 error (optional 3000-sheet paper feeder)
C1110	PF lift motor 2 error (optional 3000-sheet paper feeder)
C1120	PF left lift position problem (optional 3000-sheet paper feeder)
C1130	PF right lift position problem (optional 3000-sheet paper feeder)
C2600	PF paper conveying/drive motor error (optional 3000-sheet paper feeder/paper feeder)
C3210	CIS lamp problem
C3310	CIS AGC problem
C8020	Punch motor problem (optional 3000-sheet document finisher)
C8030	Tray upper limit detection problem (optional document finisher)
C8040	Belt problem (optional document finisher)
C8050	Paper conveying belt motor 1 problem (optional 3000-sheet document finisher)
C8060	Paper conveying belt motor 2 problem (optional 3000-sheet document finisher)
C8070	Inner tray communication error (optional 3000-sheet document finisher)

Code	Contents
C8140	Main tray problem (optional 3000-sheet document finisher) Tray elevation motor problem (optional document finisher)
C8170	Side registration motor 1 problem (optional 3000-sheet document finisher) Finisher front side registration motor problem (optional built-in finisher)
C8180	Side registration motor 2 problem (optional 3000-sheet document finisher) Finisher rear side registration motor problem (optional built-in finisher)
C8190	Finisher trailing edge registration motor problem (optional built-in finisher)
C8210	Stapler moving motor 1 error (optional 3000-sheet document finisher) Stapler problem (optional document finisher) Finisher stapler problem (optional built-in finisher)
C8220	Stapler moving motor 2 error (optional 3000-sheet document finisher)
C8230	Stapler motor problem (optional 3000-sheet document finisher)
C8300	Center-folding unit communication error (optional center-folding unit of 3000-sheet document finisher)
C8310	Centerfold side registration motor 2 problem (optional center-folding unit of 3000-sheet document finisher)
C8320	Centerfold paper conveying belt motor problem (optional center-folding unit of 3000-sheet document finisher) Adjustment motor 2 problem (optional document finisher)
C8330	Blade motor problem (optional center-folding unit of 3000-sheet document finisher) Adjustment motor 1 problem (optional document finisher)
C8340	Centerfold staple motor problem (optional center-folding unit of 3000-sheet document finisher)
C8350	Centerfold side registration motor 1 problem (optional center-folding unit of 3000-sheet document finisher) Roller motor problem (optional document finisher)
C8360	Centerfold main motor problem (optional center-folding unit of 3000-sheet document finisher) Slide motor problem (optional document finisher)
C8440	Sensor adjusting problem (optional document finisher)
C8460	EEPROM problem (optional document finisher)
C8500	Mailbox communication error (optional mailbox of 3000-sheet document finisher)
C8510	Mailbox drive motor problem (optional mailbox of 3000-sheet document finisher)
C9040	DP lift motor going up error (optional DP)
C9050	DP lift motor going down error (optional DP)
C9060	DP EEPROM error (optional DP)
C9070	Communication problem between DP and SHD (optional DP)
C9080	Communication problem between DP and CIS (optional DP)

Measures against the service codes detecting fuser problems

If one of the following service codes is detected, take actions to clear the cause of the trouble and perform maintenance item U163 to reset the service code.

Code	Contents
C6000	Fuser heater break
C6020	Abnormally high fuser thermistor temperature
C6030	Fuser thermistor break error
C6040	Fuser thermistor 1 detection error
C6050	Abnormally low fuser thermistor temperature
C6400	Zero-cross signal error

(2) Self diagnostic codes

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C0030	Fax control PWB system problem Processing with the fax software was disabled due to a hardware or software problem.	Defective fax control PWB.	Replace the fax control PWB and verify the operation.
C0060	Main PWB type mismatch error	Defective PWB.	Run maintenance item U935 to contact the Service Administrative Division.
C0070	Abnormal detection of fax control PWB incompatibility In the initial communication with the fax control PWB, any normal communication command is not transmitted.	Defective fax software.	Install the fax software.
		Defective fax control PWB.	Replace the fax control PWB and verify the operation.
C0100	Backup memory (EEPROM) device problem (Main PWB) Reading from or writing to EEPROM cannot be performed.	Defective main PWB.	Replace the main PWB and check for correct operation.
		Device damage of EEPROM.	Contact the Service Administrative Division.
C0120	MAC address data error For data in which the MAC address is invalid.	Defective main PWB.	Replace the main PWB and check for correct operation.
C0150	Backup memory (EEPROM) device problem (Engine PWB) No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively. Mismatch of reading data from two locations occurs eight times successively. Mismatch between writing data and reading data occurs eight times successively.	Defective engine PWB.	Replace the engine PWB and check for correct operation.
		Device damage of EEPROM.	Contact the Service Administrative Division.
C0160	Backup memory (EEPROM) data problem (Engine PWB) Reading data from EEPROM is abnormal.	Data damage of EEPROM.	Contact the Service Administrative Division.
C0170	Copy counts problem A checksum error is detected in the main and engine backup memories for the copy counters.	Data damage of EEPROM.	Contact the Service Administrative Division.
		Defective PWB.	Replace the main PWB or engine PWB and check for correct operation.
C0180	Machine number mismatch error Machine number of main PWB and engine PWB does not match.	Data damage of EEPROM.	Contact the Service Administrative Division.
C0620	FAX image DIMM problem DIMM is not installed correctly. DIMM cannot be accessed.	DIMM installed incorrectly.	Check if the DIMM is inserted into the socket on the main PWB correctly.
		Defective main PWB.	Replace the main PWB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C0630	DMA problem DMA transmission of image data does not complete within the specified period of time.	Poor contact in the connector terminals.	Check the connection the signal cable for CIS and the main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective main PWB.	Replace the main PWB and check for correct operation.
C0640	Hard disk drive problem The hard disk cannot be accessed.	Poor contact in the connector terminals.	Check the connection of connector YC49 on the main PWB and the connector on the hard disk. Repair or replace if necessary.
		Defective hard disk.	Run U024 (HDD formatting) without turning the power off to initialize the hard disk. Replace the hard disk drive and check for correct operation if the problem is still detected after initialization.
		Defective main PWB.	Replace the main PWB and check for correct operation.
C0650	FAX image DIMM check problem Improper DIMM is installed.	DIMM installed incorrectly.	Check if the DIMM is inserted into the socket on the main PWB correctly.
		DIMM of another machine is installed.	Perform maintenance mode U671 (RECOVERY FAX DIMM).
		Defective main PWB.	Replace the main PWB and check for correct operation.
C0800	Image processing problem JAM05 is detected twice.	Defective main PWB.	Replace the main PWB and check for correct operation.
C0830	Fax control PWB flash program area checksum error A checksum error occurred with the program of the fax control PWB.	Defective fax software.	Install the fax software.
		Defective fax control PWB.	Replace the fax control PWB and verify the operation.
C0840	Faults of RTC The time is judged to go back based on the comparison of the RTC time and the current time or five years or more have passed.	Defective main PWB.	Replace the main PWB and check for correct operation.
		The battery is disconnected from the main PWB.	Check visually and remedy if necessary.
C0870	Fax control PWB to main PWB high capacity data transfer problem High-capacity data transfer between the fax control PWB and the scanner MIP PWB was not normally performed even if the data transfer was retried 10 times.	Poor contact in the connector terminals.	Check the connection of connector on the interface PWB and the connector on the fax control PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective PWB.	Replace the fax control PWB or main PWB and check for correct operation.
C0920	Fax file system error The backup data is not retained for file system abnormality of flash memory of the fax control PWB.	Defective fax control PWB.	Replace the fax control PWB and verify the operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C1010	Lift motor 1 error After cassette 1 is inserted, lift switch 1 does not turn on within 12 s. This error is detected four times successively.	Poor contact in the connector terminals.	Check the connection of connector of lift motor 1 and the connector YC8 on the engine PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Broken gears or couplings of lift motor 1.	Replace lift motor 1.
		Defective lift motor 1.	Check for continuity across the coil. If none, replace lift motor 1.
		Poor contact in the connector terminals.	Check the connection of connector of lift switch 1 and the connector YC8 on the engine PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective lift switch 1.	Check if YC8-B9 on the engine PWB goes low when lift switch 1 is turned off. If not, replace lift switch 1.
		Defective engine PWB.	Replace the engine PWB and check for correct operation.
C1020	Lift motor 2 error After cassette 2 is inserted, lift switch 2 does not turn on within 12 s. This error is detected four times successively.	Poor contact in the connector terminals.	Check the connection of connector of lift motor 2 and the connector YC8 on the engine PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Broken gears or couplings of lift motor 2.	Replace lift motor 2.
		Defective lift motor 2.	Check for continuity across the coil. If none, replace lift motor 2.
		Poor contact in the connector terminals.	Check the connection of connector of lift switch 2 and the connector YC8 on the engine PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective lift switch 2.	Check if YC8-B15 on the engine PWB goes low when lift switch 2 is turned off. If not, replace lift switch 2.
		Defective engine PWB.	Replace the engine PWB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C1030	<p>PF lift motor 1 error (optional paper feeder) After cassette 3 is inserted, PF lift switch 1 does not turn on within 12 s. This error is detected two times successively. During driving the motor, the lift overcurrent protective monitor signal is detected for 500 ms or more two times successively. However, the first 1 s after PF lift motor 1 is turned on is excluded from detection.</p>	Poor contact in the connector terminals.	Check the connection of connector YC15 on the engine PWB and the connector on the PF main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Broken gears or couplings of PF lift motor 1.	Replace PF lift motor 1.
		Defective PF lift motor 1.	Check for continuity across the coil. If none, replace PF lift motor 1.
		Defective PF lift switch 1.	Check if YC1-7 on the PF main PWB goes low when PF lift switch 1 is turned off. If not, replace PF lift switch 1.
C1040	<p>PF lift motor 2 error (optional paper feeder) After cassette 4 is inserted, PF lift switch 2 does not turn on within 12 s. This error is detected two times successively. During driving the motor, the lift overcurrent protective monitor signal is detected for 500 ms or more two times successively. However, the first 1 s after PF lift motor 2 is turned on is excluded from detection.</p>	Poor contact in the connector terminals.	Check the connection of connector YC15 on the engine PWB and the connector on the PF main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Broken gears or couplings of PF lift motor 2.	Replace PF lift motor 2.
		Defective PF lift motor 2.	Check for continuity across the coil. If none, replace PF lift motor 2.
		Defective PF lift switch 2.	Check if YC1-9 on the PF main PWB goes low when PF lift switch 2 is turned off. If not, replace PF lift switch 2.
C1100	<p>PF lift motor 1 error (optional 3000-sheet paper feeder) A motor over-current signal is detected continuously for 1 s or longer.</p>	Poor contact in the connector terminals.	Check the connection of connector YC15 on the engine PWB and the connector on the PF main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		PF lift motor 1 does not rotate correctly (the motor is overloaded).	Check the gears and remedy if necessary.
C1110	<p>PF lift motor 2 error (optional 3000-sheet paper feeder) A motor over-current signal is detected continuously for 1 s or longer.</p>	Poor contact in the connector terminals.	Check the connection of connector YC15 on the engine PWB and the connector on the PF main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		PF lift motor 2 does not rotate correctly (the motor is overloaded).	Check the gears and remedy if necessary.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C1120	PF left lift position problem (optional 3000-sheet paper feeder) Level switch 1 does not turn on within 30 s of PF lift motor 1 turning on.	Poor contact in the connector terminals.	Check the connection of connector YC15 on the engine PWB and the connector on the PF main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective level switch 1.	Check if YC5-4 on the PF main PWB goes low when level switch 1 is turned off. If not, replace level switch 1.
		Defective PF lift motor 1.	Check for continuity across the coil. If none, replace PF lift motor 1.
		The PF left lift does not rise properly.	Check the gears and belts, and remedy if necessary.
C1130	PF right lift position problem (optional 3000-sheet paper feeder) Level switch 2 does not turn on within 30 s of PF lift motor 2 turning on.	Poor contact in the connector terminals.	Check the connection of connector YC15 on the engine PWB and the connector on the PF main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective level switch 2.	Check if YC5-7 on the PF main PWB goes low when level switch 2 is turned off. If not, replace level switch 2.
		Defective PF lift motor 2.	Check for continuity across the coil. If none, replace PF lift motor 2.
		The PF right lift does not rise properly.	Check the gears and belts, and remedy if necessary.
C1800	Paper feeder communication error (optional paper feeder) A communication error from paper feeder is detected 10 times in succession.	Poor contact in the connector terminals.	Check the connection of connector YC15 on the engine PWB and the connector on the PF main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective PWB.	Replace the PF main PWB or engine PWB and check for correct operation.
C1900	Paper feeder EEPROM error (optional paper feeder) When writing the data, the write data and the read data is not continuously in agreement three times.	Poor contact in the connector terminals.	Check the connection of connector YC15 on the engine PWB and the connector on the PF main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective engine PWB.	Replace the engine PWB and check for correct operation.
		Defective paper feeder.	Replace the paper feeder with another unit and check the operation. If the operation is normal, replace or repair optional paper feeder.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C2000	Drive motor problem Stable OFF is detected for 1 s continuously after drive motor stability. The drive motor is not stabilized in 6 s since the motor is activated.	Poor contact in the connector terminals.	Check the connection of connector YC11 on the engine PWB and the connector on the drive motor, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective drive motor.	Replace the drive motor.
		Defective engine PWB.	Replace the engine PWB and check for correct operation.
C2250	Main charger cleaning motor error A locking error has been detected three times in a row during a reciprocating cleaning motion.	Poor contact in the connector terminals.	Check the connection of connector YC5 on the engine PWB and the connector on the main charger cleaning motor, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective main charger cleaning motor.	Replace the main charger cleaning motor.
		Defective engine PWB.	Replace the engine PWB and check for correct operation.
C2500	Paper feed motor error Stable OFF is detected for 1 s continuously after paper feed motor stability. The paper feed motor is not stabilized in 6 s since the motor is activated.	Poor contact in the connector terminals.	Check the connection of connector YC11 on the engine PWB and the connector on the paper feed motor, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective paper feed motor.	Replace the paper feed motor.
		Defective engine PWB.	Replace the engine PWB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C2600	PF paper conveying/drive motor error (optional 3000-sheet paper feeder/ paper feeder) The lock signal of the motor is detected above 450 ms.	Poor contact in the connector terminals.	Check the connection of connector YC15 on the engine PWB and the connector on the PF main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective PF paper conveying/drive motor.	Replace the PF paper conveying/drive motor.
		Defective PWB.	Replace the PF main PWB or engine PWB and check for correct operation.
C3100	Scanner carriage problem The home position is not correct when the power is turned on or at the start of copying using the table.	Poor contact in the connector terminals.	Check the connection of connector YC8 on the ISM PWB and the connector of the home position switch, and the connection of connector YC7 on the ISM PWB and the connector on the scanner motor and the continuity across the connector terminals. Repair or replace if necessary.
		Defective home position switch.	Replace the scanner home position switch.
		Defective scanner motor.	Replace the scanner motor.
		The mirror frame, exposure lamp, or scanner wire is defective.	Check if the mirror frames and exposure lamp are on the rail. And check the scanner wire winds correctly.
		Defective PWB.	Replace the ISM PWB or ISC PWB and check for correct operation.
C3200	Exposure lamp problem When input value at the time of exposure lamp illumination does not exceed the threshold value between 5 s.	Poor contact in the connector terminals.	Check the connection of connector YC5 on the ISM PWB and the connector on the inverter PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective exposure lamp or inverter PWB.	Replace the exposure lamp or inverter PWB.
		Incorrect shading position.	Adjust the position of the contact glass (shading plate). If the problem still occurs, replace the home position switch.
		Defective PWB.	Replace the ISM PWB, ISC PWB or CCD PWB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C3210	CIS lamp problem When input value at the time of CIS illumination does not exceed the threshold value between 5 s.	Poor contact in the connector terminals.	Check the connection of connector on the ISM PWB and the connector on the DP driver PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective DP driver PWB.	Replace the DP driver PWB and check for correct operation.
		Defective DP inverter PWB.	Replace the DP inverter PWB and check for correct operation.
		Defective CIS.	Replace the CIS and check for correct operation.
C3300	Optical system (AGC) problem After AGC, correct input is not obtained at CCD.	Poor contact in the connector terminals.	Check the connection of connector YC5 on the ISM PWB and the connector on the inverter PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective exposure lamp or inverter PWB.	Replace the exposure lamp or inverter PWB.
		Defective PWB.	Replace the ISM PWB, ISC PWB or CCD PWB and check for correct operation.
C3310	CIS AGC problem After AGC, correct input is not obtained at CIS.	Defective DP driver PWB.	Replace the DP driver PWB and check for correct operation.
		CIS output problem.	Replace the CIS and check for correct operation.
		Defective DP inverter PWB.	Replace the DP inverter PWB and check for correct operation.
C3500	Communication error between scanner and SHD An error code is detected.	Poor contact in the connector terminals.	Check the connection of connector YC2 on the CCD PWB and the connector YC2 on the ISC PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective PWB.	Replace the CCD PWB or ISC PWB and check for correct operation.
C3900	Backup memory read/write problem (ISC PWB) Read and write data does not match.	Defective backup RAM or PWB.	Replace the ISC PWB or ISM PWB and check for correct operation.
C3910	Backup memory data problem (ISC PWB) Data in the specified area of the backup memory does not match the specified values.	Defective backup RAM or PWB.	Replace the ISC PWB or ISM PWB and check for correct operation.
C4000	Polygon motor synchronization problem The polygon motor does not reach the stable speed within 20 s of the START signal turning on.	Poor contact in the connector terminals.	Check the connection of connector YC3 on the engine PWB and laser scanner unit, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective polygon motor.	Replace the laser scanner unit.
		Defective engine PWB.	Replace the engine PWB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C4010	Polygon motor steady-state problem Stable OFF is detected for 20 s continuously after polygon motor stability.	Poor contact in the connector terminals.	Check the connection of connector YC3 on the engine PWB and laser scanner unit, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective polygon motor.	Replace the laser scanner unit.
		Defective engine PWB.	Replace the engine PWB and check for correct operation.
C4100	BD initialization problem 5 consecutive BD errors were detected during an 800 ms interval after the polygon motor stabilized.	Poor contact in the connector terminals.	Check the connection of connector YC3 on the engine PWB and laser scanner unit, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective polygon motor.	Replace the laser scanner unit.
		Defective engine PWB.	Replace the engine PWB and check for correct operation.
C6000	Fuser heater break Fuser thermistor 1 detected less than 70°C/158°F for 10 s during warm-up and ready in. During warm-up, the temperature at the fuser unit thermistor 1 does not rise by 1°C/1.8°F continuously for 5 s. Fuser thermistor 2 detected less than 40°C/104°F for 10 s during warm-up and ready in. During warm-up, the temperature at the fuser unit thermistor 2 does not rise by 1°C/1.8°F continuously for 5 s.	Defective fuser heater 1 or 2.	Replace the fuser heater 1 or 2.
		Installation defectiveness on fuser thermistor 1 or 2.	Check the mounting state of the fuser thermistor 1. If any problem is found, repair it.
		Defective fuser thermostat.	Replace the fuser thermostat.
		Defective PWB.	Replace the power source PWB or engine PWB and check for correct operation.
C6020	Abnormally high fuser thermistor temperature Fuser thermistor 1 or 2 is detected 250°C/482°F or more for 40 ms.	Installation defectiveness on fuser thermistor 1 or 2.	Check the mounting state of the fuser thermistor 1 or 2. If any problem is found, repair it.
		Defective fuser thermistor unit 1 or 2.	Replace the fuser thermistor 1 or 2.
		Defective engine PWB.	Replace the engine PWB and check for correct operation.
C6030	Fuser thermistor break error The fuser thermistor break signal is detected continuously for 1 s.	Installation defectiveness on fuser thermistor 1 or 2.	Check the mounting state of the fuser thermistor 1 or 2. If any problem is found, repair it.
		Defective fuser thermistor 1 or 2.	Replace the fuser thermistor 1 or 2.
		Defective engine PWB.	Replace the engine PWB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C6040	Fuser thermistor 1 detection error Fuser thermistor 1 detected an abnormal value for at least 1 s.	Installation defectiveness on fuser thermistor 1.	Check the mounting state of the fuser thermistor 1. If any problem is found, repair it.
		Defective fuser thermistor 1.	Replace the fuser thermistor 1.
		Defective engine PWB.	Replace the engine PWB and check for correct operation.
C6050	Abnormally low fuser thermistor temperature Fuser thermistor 1 is detected 80°C/176°F less than 1 s continuously during copying.	Defective fuser heater 1 or 2.	Replace the fuser heater 1 or 2.
		Installation defectiveness on fuser thermistor 1.	Check the mounting state of the fuser thermistor 1. If any problem is found, repair it.
		Defective PWB.	Replace the power source PWB or engine PWB and check for correct operation.
C6400	Zero-cross signal error While fuser heater ON/OFF control is performed, the zero-cross signal is not input within 3 s.	Defective PWB.	Replace the power source PWB or engine PWB and check for correct operation.
C6410	Fuser unit connector insertion problem Absence of the fuser unit is detected.	Fuser unit connector inserted incorrectly.	Reinsert the fuser unit connector if necessary.
		Defective fuser unit connector.	Replace the fuser unit.
C7300	Toner container problem Toner level is not detected when toner empty is detected.	Poor contact in the connector terminals.	Check the connection of connector YC5 on the engine PWB and the continuity across the connector terminals. Repair or replace if necessary.
		Defective toner container sensor.	Replace the toner container sensor.
C7400	Developing unit connector insertion problem Absence of the developing unit is detected.	Developing unit connector inserted incorrectly.	Reinsert the developing unit connector if necessary.
		Defective developing unit connector.	Replace the developing unit.
C7410	Drum unit connector insertion problem Absence of the drum unit is detected.	Drum unit connector inserted incorrectly.	Reinsert the drum unit connector if necessary.
		Defective drum unit connector.	Replace the drum unit.
C7800	Broken external thermistor wire The thermistor output value is 4.5 V or more.	Poor contact in the connector terminals.	Check the connection of connector YC10 on the engine PWB and the continuity across the connector terminals. Repair or replace if necessary.
		Defective humidity sensor.	Replace the humidity sensor.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C7900	Drum EEPROM error Reading from or writing to EEPROM cannot be performed.	Poor contact in the connector terminals.	Check the connection of connector on the engine PWB and the continuity across the connector terminals. Repair or replace if necessary.
		Defective drum unit.	Replace the drum unit.
C7910	Developing unit EEPROM error Reading from or writing to EEPROM cannot be performed.	Poor contact in the connector terminals.	Check the connection of connector on the engine PWB and the continuity across the connector terminals. Repair or replace if necessary.
		Defective developing unit.	Replace the developing unit.
C8020	Punch motor problem (optional 3000-sheet document finisher) The error signal of the punch motor is detected for more than 500 ms while the punch motor is operating.	Poor contact in the connector terminals.	Check the connection of connector on the punch PWB and the continuity across the connector terminals. Repair or replace if necessary.
		Defective punch motor.	Replace the punch motor.
		Defective PWB.	Replace the punch PWB or finisher main PWB and check for correct operation.
C8030	Tray upper limit detection problem (optional document finisher) When the tray elevation motor raises a tray, the ON status of the tray upper limit sensor is detected.	The tray upper limit sensor, paper surface sensor 1/2 connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective tray upper limit sensor, paper surface sensor 1/2.	Replace the sensor.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.
C8040	Belt problem (optional document finisher) The belt sensor does not turn on/off within specified time of the belt solenoid turning on.	The belt sensor, belt solenoid connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective belt sensor.	Replace the belt sensor.
		Defective belt solenoid.	Replace the belt solenoid.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C8050	Paper conveying belt motor 1 problem (optional 3000-sheet document finisher) Paper conveying belt home position sensor 1 does not turn off within 1.5 s. Paper conveying belt home position sensor 1 does not turn on within 2.5 s. Jam 88 is indicated.	Poor contact in the connector terminals.	Check the connection of connector YC2 on the inner tray PWB and the connector on paper conveying belt motor 1, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective paper conveying belt home position sensor 1.	Replace paper conveying belt home position sensor 1.
		Defective paper conveying belt motor 1.	Replace paper conveying belt motor 1.
		Defective PWB.	Replace the inner tray PWB or finisher main PWB and check for correct operation.
C8060	Paper conveying belt motor 2 problem (optional 3000-sheet document finisher) Paper conveying belt home position sensor 2 does not turn off within 1.5 s. Paper conveying belt home position sensor 2 does not turn on within 1.5 s.	Poor contact in the connector terminals.	Check the connection of connector YC6 on the inner tray PWB and the connector on paper conveying belt motor 2, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective paper conveying belt home position sensor 2.	Replace paper conveying belt home position sensor 2.
		Defective paper conveying belt motor 2.	Replace paper conveying belt motor 2.
		Defective PWB.	Replace the inner tray PWB or finisher main PWB and check for correct operation.
C8070	Inner tray communication error (optional 3000-sheet document finisher) Communication with the inner tray is not possible although the connection is detected.	Poor contact in the connector terminals.	Check the connection of connector YC6 and YC24 on the finisher main PWB and the connector YC1 and YC4 on the inner tray PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective PWB.	Replace the inner tray PWB or finisher main PWB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C8140	<p>Main tray problem (optional 3000-sheet document finisher) The main tray is not detected by the main tray upper limit detection sensor or the main tray paper upper surface detection sensor within 20 s since the tray has started ascending. The main tray upper limit detection sensor or the main tray paper upper surface detection sensor is not detected to be turned off in 20 s after the main tray has descended. The main tray low limit detection sensor is not detected to be turned on in 20 s after the main tray has descended. During main tray ascent, the main tray upper limit detection sensor or the main tray paper upper surface detection sensor stays on for more than 2 s.</p>	Poor contact in the connector terminals.	Check the connection of connector YC11 on the finisher main PWB and the connector on the main tray motor, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective main tray motor.	Replace the main tray motor.
		Defective main tray upper limit detection sensor/main tray paper upper surface detection sensor/main tray lower limit detection sensor.	Replace the sensor.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.
	<p>Tray elevation motor problem (optional document finisher) The tray low limit sensor or paper surface sensor 1/2 cannot be detected to be on within 10 s since the tray elevation motor is activated.</p>	The tray elevation motor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The tray elevation motor malfunctions.	Replace the tray elevation motor.
		The tray lower limit sensor, paper surface sensor 1/2 connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective tray lower limit sensor, paper surface sensor 1/2.	Replace the sensor.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.

Code	Contents	Remarks		
		Causes	Check procedures/corrective measures	
C8170	Side registration motor 1 problem (optional 3000-sheet document finisher) When operation returned to a home position is performed at the time of initial operation and a home position is not detected even if 3 s passed. Jam 88 is indicated.	Poor contact in the connector terminals.	Check the connection of connector YC2 on the inner tray PWB and the connector on side registration motor 1, and the continuity across the connector terminals. Repair or replace if necessary.	
		Defective side registration motor 1.	Replace side registration motor 1.	
		Defective PWB.	Replace the inner tray PWB or finisher main PWB and check for correct operation.	
	Finisher front side registration motor problem (optional built-in finisher) When the front-side registration home-position sensor is turned on during initialization, the sensor did not turn on while it has moved by 106 pulses. When the front-side registration home-position sensor is turned off during initialization, the sensor did not turn on in 3 s.	The front side registration motor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.	
		Defective front side registration motor.	Replace front side registration motor.	
		The front side registration home position sensor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.	
		Defective front side registration home position sensor.	Replace the front side registration home position sensor.	
		Defective finisher control PWB.	Replace the finisher control PWB and check for correct operation.	
	C8180	Side registration motor 2 problem (optional 3000-sheet document finisher) When operation returned to a home position is performed at the time of initial operation and a home position is not detected even if 3 s passed. Jam 88 is indicated.	Poor contact in the connector terminals.	Check the connection of connector YC8 on the inner tray PWB and the connector of side registration motor 2, and the continuity across the connector terminals. Repair or replace if necessary.
			Defective side registration motor 2.	Replace side registration motor 2.
Defective PWB.			Replace the inner tray PWB or finisher main PWB and check for correct operation.	
Finisher rear side registration motor problem (optional built-in finisher) When the rear-side registration home-position sensor is turned on during initialization, the sensor did not turn on while it has moved by 106 pulses. When the rear-side registration home-position sensor is turned off during initialization, the sensor did not turn on in 3 s.		The rear side registration motor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.	
		Defective rear side registration motor.	Replace rear side registration motor.	
		The rear side registration home position sensor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.	
		Defective rear side registration home position sensor.	Replace the rear side registration home position sensor.	
		Defective finisher control PWB.	Replace the finisher control PWB and check for correct operation.	

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C8190	Finisher trailing edge registration motor problem (optional built-in finisher) When the trailing edge registration home-position sensor is turned on during initialization, the sensor did not turn on while it has moved by 106 pulses. When the trailing edge registration home-position sensor is turned off during initialization, the sensor did not turn on in 3 s.	The trailing edge registration motor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective trailing edge registration motor.	Replace trailing edge registration motor.
		The trailing edge registration home position sensor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective trailing edge registration home position sensor.	Replace the trailing edge registration home position sensor.
		Defective finisher control PWB.	Replace the finisher control PWB and check for correct operation.
C8210	Stapler moving motor 1 error (optional 3000-sheet document finisher) When operation returned to a home position is performed at the time of initial operation and a home position is not detected even if 1.5 s passed.	Poor contact in the connector terminals.	Check the connection of connector YC9 on the finisher main PWB and the connector of stapler moving motor 1, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective stapler moving motor 1.	Replace stapler moving motor 1.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.
	Stapler problem (optional document finisher) Jam 82 is indicated.	The stapler connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The stapler is blocked with a staple.	Remove the stapler cartridge, and check the cartridge and the stapling section of the stapler.
		The stapler is broken.	Replace the stapler and check for correct operation.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.
	Finisher stapler problem (optional built-in finisher) The stapler home position sensor does not change state from nondetection to detection within 200 ms of the start of stapler motor counterclockwise (forward) rotation. During initialization, the stapler home position sensor does not change state from non-detection to detection within 600 ms of the start of stapler motor clockwise (reverse) rotation.	The stapler connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The stapler is blocked with a staple.	Remove the stapler cartridge, and check the cartridge and the stapling section of the stapler.
		The stapler is broken.	Replace the front stapler and check for correct operation.
		Defective finisher control PWB.	Replace the finisher control PWB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C8220	Stapler moving motor 2 error (optional 3000-sheet document finisher) When operation returned to a home position is performed at the time of initial operation and a home position is not detected even if 3.5 s passed.	Poor contact in the connector terminals.	Check the connection of connector YC10 on the finisher main PWB and the connector of staple relay PWB and stapler moving motor 2, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective stapler moving motor 2.	Replace stapler moving motor 2.
		Defective staple relay PWB.	Replace the staple relay PWB and check for correct operation.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.
C8230	Stapler motor problem (optional 3000-sheet document finisher) Jam 82 is indicated.	Poor contact in the connector terminals.	Check the connection of connector YC10 on the finisher main PWB and the connector of staple relay PWB and stapler motor, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective stapler motor.	Replace the stapler motor.
		Defective staple relay PWB.	Replace the staple relay PWB and check for correct operation.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.
C8300	Center-folding unit communication error (optional center-folding unit of 3000-sheet document finisher) Communication with the center-folding unit is not possible although the connection is detected.	Poor contact in the connector terminals.	Check the connection of connector YC5 and YC20 on the finisher main PWB and the connector YC1 and YC2 on the centerfold main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective center-fold set switch.	Replace the centerfold set switch.
		Defective center-fold main PWB.	Replace the centerfold main PWB and check for correct operation.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.
C8310	Centerfold side registration motor 2 problem (optional center-folding unit of 3000-sheet document finisher) The home position is not detected when initial operation even if 1 s passed.	Poor contact in the connector terminals.	Check the connection of connector YC6 on the centerfold main PWB and the connector of centerfold side registration motor 2, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective center-fold side registration motor 2.	Replace centerfold side registration motor 2.
		Defective PWB.	Replace the centerfold main PWB or finisher main PWB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C8320	Centerfold paper conveying belt motor problem (optional center-folding unit of 3000-sheet document finisher) The home position is not detected when initial operation even if 2.5 s passed.	Poor contact in the connector terminals.	Check the connection of connector YC6, YC7 on the centerfold main PWB and the connector of centerfold paper conveying belt motor 1/2, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective centerfold paper conveying belt motor 1/2.	Replace centerfold paper conveying belt motor 1/2.
		Defective PWB.	Replace the centerfold main PWB or finisher main PWB and check for correct operation.
	Adjustment motor 2 problem (optional document finisher) The adjustment sensor 2 does not turn on/off within specified time of the adjustment motor 2 turning on.	The adjustment sensor 2, adjustment motor 2 connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective adjustment sensor 2.	Replace the adjustment sensor 2.
		Defective adjustment motor 2.	Replace the adjustment motor 2.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.
	C8330	Blade motor problem (optional center-folding unit of 3000-sheet document finisher) The home position is not detected when initial operation even if 1.5 s passed.	Poor contact in the connector terminals.
Defective blade motor.			Replace the blade motor.
Defective PWB.			Replace the centerfold main PWB or finisher main PWB and check for correct operation.
Adjustment motor 1 problem (optional document finisher) The adjustment sensor 1 does not turn on/off within specified time of the adjustment motor 1 turning on.		The adjustment sensor 1, adjustment motor 1 connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective adjustment sensor 1.	Replace the adjustment sensor 1.
		Defective adjustment motor 1.	Replace the adjustment motor 1.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C8340	Centerfold staple motor problem (optional center-folding unit of 3000-sheet document finisher) Jam 89 is indicated.	Poor contact in the connector terminals.	Check the connection of connector YC9 on the centerfold main PWB and the connector of the centerfold staple motor, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective centerfold staple motor.	Replace the centerfold staple motor.
		Defective PWB.	Replace the centerfold main PWB or finisher main PWB and check for correct operation.
C8350	Centerfold side registration motor 1 problem (optional center-folding unit of 3000-sheet document finisher) The home position is not detected when initial operation even if 1 s passed.	Poor contact in the connector terminals.	Check the connection of connector YC7 on the centerfold main PWB and the connector of centerfold side registration motor 1, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective centerfold side registration motor 1.	Replace centerfold side registration motor 1.
		Defective PWB.	Replace the centerfold main PWB or finisher main PWB and check for correct operation.
	Roller motor problem (optional document finisher) The roller sensor does not turn on/off within specified time of the roller motor turning on.	The roller sensor, roller motor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective roller sensor.	Replace the roller sensor.
		Defective roller motor.	Replace the roller motor.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.
C8360	Centerfold main motor problem (optional center-folding unit of 3000-sheet document finisher) The motor lock signal is detected above 1 s during driving the centerfold main motor.	Poor contact in the connector terminals.	Check the connection of connector YC12 on the centerfold main PWB and the connector of the centerfold main motor, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective centerfold main motor.	Replace the centerfold main motor.
		Defective PWB.	Replace the centerfold main PWB or finisher main PWB and check for correct operation.
	Slide motor problem (optional document finisher) The slide sensor does not turn on/off within specified time of the slide motor turning on.	The slide sensor, slide motor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective slide sensor.	Replace the slide sensor.
		Defective slide motor.	Replace the slide motor.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C8440	Sensor adjusting problem (optional document finisher) The sensor cannot be adjusted within the specified range.	The paper entry sensor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective paper entry sensor.	Replace the paper entry sensor and check for correct operation.
		The optical path of the paper entry sensor is blocked by foreign matter.	Remove the foreign matter.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.
C8460	EEPROM problem (optional document finisher) Reading from or writing to EEPROM cannot be performed.	Defective EEPROM or finisher main PWB.	Replace the finisher main PWB and check for correct operation.
C8500	Mailbox communication error (optional mailbox of 3000-sheet document finisher) Communication with the mailbox is not possible although the connection is detected.	Poor contact in the connector terminals.	Check the connection of the connector of the mailbox and the connector YC7 on the finisher main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective PWB.	Replace the mailbox main PWB or finisher main PWB and check for correct operation.
C8510	Mailbox drive motor problem (optional mailbox of 3000-sheet document finisher) The motor lock signal is detected above 500 ms during driving the mailbox drive motor.	Poor contact in the connector terminals.	Check the connection of connector YC5 on the mailbox main PWB and the connector of the mailbox drive motor, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective mailbox drive motor.	Replace the mailbox drive motor.
		Defective PWB.	Replace the mailbox main PWB or finisher main PWB and check for correct operation.
C8800	Document finisher communication error (optional 3000-sheet document finisher) A communication error from document finisher is detected 10 times in succession.	Poor contact in the connector terminals.	Check the connection of connector on the engine PWB and the connector on the finisher main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective PWB.	Replace the finisher main PWB or engine PWB and check for correct operation.
C8900	Finisher backup problem (optional 3000-sheet document finisher) Read and write data does not match 3 times in succession.	Poor contact in the connector terminals.	Check the connection of connector on the finisher main PWB and the connector of the machine, and the continuity across the connector terminals. Repair or replace if necessary.
		EEPROM installed incorrectly.	Install EEPROM correctly.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.


Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C8910	Punch backup problem (optional of 3000-sheet document finisher) Read and write data does not match 3 times in succession.	Poor contact in the connector terminals.	Check the connection of connector on the punch PWB and the connector YC4 on the finisher main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective punch PWB.	Replace the punch PWB and check for correct operation.
C8920	Mailbox backup problem (optional mailbox of 3000-sheet document finisher) Read and write data does not match.	Poor contact in the connector terminals.	Check the connection of connector on the mailbox main PWB and the connector YC7 on the finisher main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective mailbox main PWB.	Replace the mailbox main PWB and check for correct operation.
C8930	Center-folding backup problem (optional center-folding unit of 3000-sheet document finisher) Read and write data does not match 3 times in succession.	Poor contact in the connector terminals.	Check the connection of connector on the centerfold main PWB and the connector YC5 on the finisher main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		EEPROM installed incorrectly.	Install EEPROM correctly.
		Defective center-fold main PWB.	Replace the centerfold main PWB and check for correct operation.
C9000	DP communication problem (optional DP) A communication error is detected.	Poor contact in the connector terminals.	Check the connection of connector YC6 on the ISM PWB and the connector of the DP, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective PWB.	Replace the DP driver PWB or ISM PWB and check for correct operation.
C9040	DP lift motor going up error (optional DP) The tray upper limit switch does not turn on within 2 s of DP lift motor turning on.	Loose connection of the DP lift motor connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Malfunction of the DP lift motor.	Replace the DP lift motor and check for correct operation.
		Loose connection of the tray upper limit switch connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Malfunction of the tray upper limit switch.	Replace the tray upper limit switch and check for correct operation.
		Defective DP driver PWB.	Replace the DP driver PWB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C9050	DP lift motor going down error (optional DP) The tray lower limit switch does not turn on within 2 s of DP lift motor turning on.	Loose connection of the DP lift motor connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Malfunction of the DP lift motor.	Replace the DP lift motor and check for correct operation.
		Loose connection of the tray lower limit switch connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Malfunction of the tray lower limit switch.	Replace the tray lower limit switch and check for correct operation.
		Defective DP driver PWB.	Replace the DP driver PWB and check for correct operation.
C9060	DP EEPROM error (optional DP) Read and write data does not match. Data in the specified area of the backup memory does not match the specified values.	Defective DP driver PWB.	Replace the DP driver PWB and check for correct operation.
		Device damage of EEPROM.	Contact the Service Administrative Division.
C9070	Communication problem between DP and SHD (optional DP) A communication error is detected.	Loose connection of the SHD PWB.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective SHD PWB.	Replace the SHD PWB and check for correct operation.
C9080	Communication problem between DP and CIS (optional DP) A communication error is detected.	Loose connection of CIS.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective CIS.	Replace CIS and check for correct operation.
C9500			Contact the Service Administrative Division.
C9510			Contact the Service Administrative Division.
C9520			Contact the Service Administrative Division.
F000	Operation panel PWB communication error	Defective main PWB.	Replace the main PWB and check for correct operation.
		Defective operation panel PWB.	Replace the operation panel PWB and check for correct operation.
F040	Engine PWB communication error	Defective main PWB.	Replace the main PWB and check for correct operation.
		Defective engine PWB.	Replace the engine PWB and check for correct operation.
F041	Scanner PWB communication error	Defective main PWB.	Replace the main PWB and check for correct operation.
		Defective ISM PWB.	Replace the ISM PWB and check for correct operation.
F050	Engine ROM checksum error	Defective engine PWB.	Replace the engine PWB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
F090	Fax control PWB communication error	Defective main PWB.	Replace the main PWB and check for correct operation.
F278	Power supply in drive system error	Main power switch was turned off without using the power key, or a power failure has occurred.	Turn on power. (To switch off power, first press the power key until the main power indicator goes off, then turn the main power switch off.)

1-4-3 Image formation problems

(1) No image appears (entirely white).



See page 1-4-49.

(2) No image appears (entirely black).



See page 1-4-49.

(3) Image is too light.



See page 1-4-50.

(4) Background is visible.




See page 1-4-50.

(5) A white line appears longitudinally.



See page 1-4-50.

(6) A black line appears longitudinally.



See page 1-4-51.

(7) A black line appears laterally.



See page 1-4-51.

(8) One side of the copy image is darker than the other.




See page 1-4-51.

(9) Black dots appear on the image.



See page 1-4-51.

(10) Image is blurred.



See page 1-4-52.

(11) The leading edge of the image is consistently misaligned with the original.




See page 1-4-52.

(12) The leading edge of the image is sporadically misaligned with the original.




See page 1-4-52.

(13) Paper creases.



See page 1-4-52.

(14) Offset occurs.




See page 1-4-53.

(15) Image is partly missing.



See page 1-4-53.

(16) Fusing is poor.



See page 1-4-53.

(17) Image is out of focus.




See page 1-4-53.

(18) Image center does not align with the original center.




See page 1-4-54.

(19) Image is not square.




See page 1-4-54.


(1) No image appears (entirely white).

Copy example	Causes		Check procedures/corrective measures
	No transfer charging.	The connector terminals of the high voltage PWB make poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective engine PWB.	Check if YC13-10 on the engine PWB goes low when maintenance item U101 is run. If not, replace the engine PWB.
		Defective high voltage PWB.	Check if transfer charging takes place when CN1-10 on the high voltage PWB goes low while maintenance item U101 is run. If not, replace the high voltage PWB.
	No LSU laser is output.	Defective laser scanner unit.	Replace the laser scanner unit (see page 1-5-22).
		Defective main PWB.	Check if YC3-11 on the main PWB goes low when maintenance item U100 is run. If not, replace the main PWB.
	No developing bias output.	The connector terminals of the high voltage PWB make poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective engine PWB.	Check if YC13-1 on the engine PWB goes low when maintenance item U101 is run. If not, replace the engine PWB.
		Defective high voltage PWB.	Check if developing bias is output when CN1-1 on the high voltage PWB goes low while maintenance item U101 is run. If not, replace the high voltage PWB.


(2) No image appears (entirely black).

Copy example	Causes		Check procedures/corrective measures
	No main charging.	Broken main charger wire.	Replace the main charger unit (see page 1-5-26).
		Leaking main charger housing.	Clean the main charger wire and grid.
		The connector terminals of the high voltage PWB make poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective engine PWB.	Check if YC13-4 on the engine PWB goes low when maintenance item U100 is run. If not, replace the engine PWB.
		Defective high voltage PWB.	Check if main charging takes place when CN1-4 on the high voltage PWB goes low while maintenance item U100 is run. If not, replace the high voltage PWB.
	Exposure lamp fails to light.	Poor contact in the exposure lamp connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective inverter PWB.	Check if the exposure lamp lights when the terminal on the inverter PWB goes low while maintenance item U061 is run. If not, replace the inverter PWB.
		Defective ISM PWB.	Run maintenance item U061 and check if YC5-4 on the ISM PWB goes low. If not, replace the ISM PWB.


(3) Image is too light.

Copy example	Causes	Check procedures/corrective measures	
	Insufficient toner.	If the display shows the message requesting toner replenishment, replace the container.	
	Deteriorated toner.	Perform the drum refresh operation.	
	Defective transfer charging output.	The connector terminals of the high voltage PWB make poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective engine PWB.	Check if YC13-10 on the engine PWB goes low when maintenance item U101 is run. If not, replace the engine PWB.
Defective high voltage PWB.	Check if transfer charging takes place when CN1-10 on the high voltage PWB goes low while maintenance item U101 is run. If not, replace the high voltage PWB.		


(4) Background is visible.

Copy example	Causes	Check procedures/corrective measures
	Deteriorated toner.	Perform the drum refresh operation.
	Dirty main charger wire.	Clean the wire or, if it is extremely dirty, replace it (see page 1-5-26).


(5) A white line appears longitudinally.

Copy example	Causes	Check procedures/corrective measures
	Foreign matter in the developing unit.	Check if the magnetic brush is formed uniformly. Replace the developing unit if any foreign matter (see page 1-5-28).
	Dirty shading plate.	Clean the shading plate.


(6) A black line appears longitudinally.

Copy example	Causes	Check procedures/corrective measures
	Dirty contact glass.	Clean the contact glass.
	Dirty or flawed drum.	Perform the drum refresh operation. If the drum is flawed, replace the drum unit (see page 1-5-25).
	Deformed or worn cleaning blade.	Replace the drum unit (see page 1-5-25).
	Dirty scanner mirror.	Clean the scanner mirror.
	Dirty main charger wire.	Clean the wire or, if it is extremely dirty, replace it (see page 1-5-26).


(7) A black line appears laterally.

Copy example	Causes	Check procedures/corrective measures
	Flawed drum.	Replace the drum unit (see page 1-5-25).
	Dirty developing section.	Clean any part contaminated with toner in the developing section.
	Leaking main charger housing.	Clean the main charger wire and grid.
	Leaking separation electrode.	Clean the separation electrode.


(8) One side of the copy image is darker than the other.

Copy example	Causes	Check procedures/corrective measures
	Dirty main charger wire.	Clean the wire or, if it is extremely dirty, replace it (see page 1-5-26).
	Defective exposure lamp.	Check if the exposure lamp light is distributed evenly to run maintenance item U061. If not, replace the exposure lamp (see page 1-3-27 and page 1-5-12).


(9) Black dots appear on the image.

Copy example	Causes	Check procedures/corrective measures
	Dirty or flawed drum.	Perform the drum refresh operation. If the drum is flawed, replace the drum unit (see page 1-5-25).
	Dirty contact glass.	Clean the contact glass.
	Deformed or worn cleaning blade.	Replace the drum unit (see page 1-5-25).
	Dirty drum separation claws.	Clean the drum separation claws.
	Dirty the heat roller separation claws.	Clean the heat roller separation claws.


(10) Image is blurred.

Copy example	Causes	Check procedures/corrective measures
	Scanner moves erratically.	Check if there is any foreign matter on the front and rear scanner rails. If any, remove it.
	Deformed press roller.	Replace the press roller (see page 1-5-32).
	Paper conveying section drive problem.	Check the gears and belts and, if necessary, grease them.


(11) The leading edge of the image is consistently misaligned with the original.

Copy example	Causes	Check procedures/corrective measures
	Misadjusted leading edge registration.	Run maintenance mode U034 to readjust the leading edge registration (see page 1-3-22).
	Misadjusted scanner leading edge registration.	Run maintenance mode U066 to readjust the scanner leading edge registration (see page 1-3-29).


(12) The leading edge of the image is sporadically misaligned with the original.

Copy example	Causes	Check procedures/corrective measures
	Feed clutch, paper feed clutch, MP paper feed clutch or registration clutch installed or operating incorrectly.	Check the installation position and operation of each clutch. If any of them operates incorrectly, replace it.


(13) Paper creases.

Copy example	Causes	Check procedures/corrective measures
	Paper curled.	Check the paper storage conditions.
	Paper damp.	Check the paper storage conditions.
	Defective pressure springs.	Replace the pressure springs.
	Defective separation.	Check the drum separation claws and heat roller separation claws.


(14) Offset occurs.

Copy example	Causes	Check procedures/corrective measures
	Defective cleaning blade.	Replace the drum unit (see page 1-5-25).
	Defective fuser unit.	Check the heat roller and press roller.
	Wrong types of paper.	Check if the paper meets specifications. Replace paper.


(15) Image is partly missing.

Copy example	Causes	Check procedures/corrective measures
	Paper damp.	Check the paper storage conditions.
	Paper creased.	Replace the paper.
	Drum condensation.	Perform the drum refresh operation.
	Dirty or flawed drum.	Perform the drum refresh operation. If the drum is flawed, replace the drum unit (see page 1-5-25).


(16) Fusing is poor.

Copy example	Causes	Check procedures/corrective measures
	Wrong types of paper.	Check if the paper meets specifications. Replace paper.
	Defective pressure springs.	Replace the pressure springs.
	Flawed press roller.	Replace the press roller (see page 1-5-32).
	Flawed fuser heater.	Replace the fuser heaters (see page 1-5-33).


(17) Image is out of focus.

Copy example	Causes	Check procedures/corrective measures
	Defective image scanning unit.	Replace the image scanning unit (see page 1-5-20).
	Drum condensation.	Perform the drum refresh operation.

(18) Image center does not align with the original center.

Copy example	Causes	Check procedures/corrective measures
	Misadjusted image center line.	Run maintenance item U034 to readjust the center line of image printing (see page 1-3-23).
	Misadjusted scanner center line.	Run maintenance item U067 to readjust the scanner leading edge registration (see page 1-3-30).
	Original is not placed correctly.	Place the original correctly.

(19) Image is not square.

Copy example	Causes	Check procedures/corrective measures
	Laser scanner unit positioned incorrectly.	Adjust the installation position of the laser scanner unit (see page 1-5-24).

1-4-4 Electric problems

Troubleshooting to each failure must be in the order of the numbered symptoms.

Problem	Causes	Check procedures/corrective measures
(1) The machine does not operate when the main power switch is turned on.	1. The power cord is not plugged in properly.	Check the contact between the power plug and the outlet.
	2. No electricity at the power outlet.	Measure the input voltage.
	3. Broken power cord.	Check for continuity. If none, replace the cord.
	4. Defective main power switch.	Check for continuity across the contacts. If none, replace the main power switch.
	5. Defective power source PWB.	With AC present, check for 24 V DC at YC1-1 on the power source PWB, 5 V DC at YC1-6 and 3.3 V DC at YC1-5. If none, replace the power source PWB.
(2) The eject motor does not operate.	1. Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
	3. Defective eject motor.	Run maintenance item U030 and check if the eject motor operates. If not, replace the eject motor.
	4. Defective engine PWB.	Run maintenance item U030 and check if the eject motor operates. If not, replace the engine PWB.
(3) The scanner motor does not operate.	1. Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	2. Broken motor coil.	Check for continuity across the coil. If none, replace the motor.
(4) Power source fan motor 1/2 does not operate.	1. Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	2. Broken motor coil.	Check for continuity across the coil. If none, replace the motor.
	3. Defective motor.	Run maintenance item U037 and check if the motor operates when the following terminals on the PWB goes low. If not, replace the corresponding motor. Power source fan motor 1/2: YC4-1 on the power source PWB
	4. Defective power source PWB.	Run maintenance item U037 and check if following terminals on the PWB goes low. If not, replace the power source PWB. Power source fan motor 1/2: YC4-1 on the power source PWB

Problem	Causes	Check procedures/corrective measures
(5) Fuser fan motor, developing fan motor, LSU fan motor, paper conveying fan motor 1/2/3 or duplex fan motor 1/2/3 does not operate.	1. Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	2. Broken motor coil.	Check for continuity across the coil. If none, replace the motor.
	3. Defective motor.	Run maintenance item U037 and check if the motor operates when the following terminals on the PWB goes low. If not, replace the corresponding motor. Fuser fan motor: YC10-A14 on the engine PWB Developing fan motor: YC12-B12 on the engine PWB LSU fan motor: YC12-B3 on the engine PWB Paper conveying fan motor 1/2/3: YC4-B7 on the engine PWB Duplex fan motor 1/2/3: YC4-B10 on the engine PWB
	4. Defective engine PWB.	Run maintenance item U037 and check if following terminals on the PWB goes low. If not, replace the engine PWB. Fuser fan motor: YC10-A14 on the engine PWB Developing fan motor: YC12-B12 on the engine PWB LSU fan motor: YC12-B3 on the engine PWB Paper conveying fan motor 1/2/3: YC4-B7 on the engine PWB Duplex fan motor 1/2/3: YC4-B10 on the engine PWB
(6) Controller fan motor does not operate.	1. Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	2. Broken motor coil.	Check for continuity across the coil. If none, replace the motor.
	3. Defective motor.	Run maintenance item U037 and check if the motor operates when the following terminals on the PWB goes low. If not, replace the corresponding motor. Controller fan motor: YC23-1 on the main PWB
	4. Defective main PWB.	Run maintenance item U037 and check if following terminals on the PWB goes low. If not, replace the main PWB. Controller fan motor: YC23-1 on the main PWB
(7) Scanner fan motor does not operate.	1. Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	2. Broken motor coil.	Check for continuity across the coil. If none, replace the motor.
	3. Defective motor.	Run maintenance item U037 and check if the motor operates when the following terminals on the PWB goes low. If not, replace the corresponding motor. Scanner fan motor: YC3-2 on the ISM PWB
	4. Defective ISM PWB.	Run maintenance item U037 and check if following terminals on the ISM PWB goes low. If not, replace the ISM PWB. Scanner fan motor: YC3-2 on the ISM PWB
	5. Defective ISC PWB.	Run maintenance item U037 and check if following terminals on the ISC PWB goes high. If not, replace the ISC PWB. Scanner fan motor: YC3-24 on the ISC PWB

Problem	Causes	Check procedures/corrective measures
(8) Paper feed clutch 1/ 2, feed clutch 1/2/3, MP paper feed clutch, MP feed clutch, registration clutch, duplex feed clutch or developing clutch does not oper- ate.	1. Poor contact in the con- nector terminals.	Reinsert the connector. Also check for continuity within the con- nector cable. If none, remedy or replace the cable.
	2. Broken clutch coil.	Check for continuity across the coil. If none, replace the clutch.
	3. Defective engine PWB.	Run maintenance item U032 and check if following terminals on the engine PWB goes low. If not, replace the engine PWB. Paper feed clutch 1: YC10-B1 on the engine PWB Paper feed clutch 2: YC10-B4 on the engine PWB Feed clutch 1: YC23-2 on the engine PWB Feed clutch 2: YC8-A12 on the engine PWB Feed clutch 3: YC8-A5 on the engine PWB MP paper feed clutch: YC12-A9 on the engine PWB MP feed clutch: YC12-A11 on the engine PWB Registration clutch: YC10-B6 on the engine PWB Duplex feed clutch: YC4-B2 on the engine PWB Developing clutch: YC7-1 on the engine PWB
(9) The feedshift sole- noid or toner feed solenoid does not operate.	1. Poor contact in the con- nector terminals.	Reinsert the connector. Also check for continuity within the con- nector cable. If none, remedy or replace the cable.
	2. Broken solenoid coil.	Check for continuity across the coil. If none, replace the solenoid.
	3. Defective engine PWB.	Run maintenance item U033 and check if the solenoid operates. If not, replace the engine PWB.
(10) The exposure lamp does not turn on or off.	1. Poor contact in the con- nector terminals.	Reinsert the connector. Also check for continuity within the con- nector cable. If none, remedy or replace the cable.
	2. Defective inverter PWB.	Run maintenance item U061 and check if the exposure lamp turns on with the inverter PWB go low. If not, replace the inverter PWB.
	3. Defective ISC PWB.	Run maintenance item U061 and check if YC3-23 on the ISC PWB goes high. If not, replace the ISC PWB.
	4. Defective ISM PWB.	Run maintenance item U061 and check if YC5-4 on the ISM PWB goes low. If not, replace the ISM PWB.
(11) Main charging is not performed.	1. Broken main charger wire.	Replace the main charger unit (see page 1-5-26).
	2. Leaking main charger housing.	Clean the main charger wire and grid.
	3. The connector terminals of the high voltage PWB make poor contact.	Reinsert the connector. Also check for continuity within the con- nector cable. If none, remedy or replace the cable.
	4. Defective engine PWB.	Check if YC13-4 on the engine PWB goes low when maintenance item U100 is run. If not, replace the engine PWB.
	5. Defective high voltage PWB.	Check if main charging takes place when CN1-4 on the high volt- age PWB goes low while maintenance item U100 is run. If not, replace the high voltage PWB.
(12) No developing bias is output.	1. The connector terminals of the high voltage PWB make poor contact.	Reinsert the connector. Also check for continuity within the con- nector cable. If none, remedy or replace the cable.
	2. Defective engine PWB.	Check if YC13-1 on the engine PWB goes low when maintenance item U101 is run. If not, replace the engine PWB.
	3. Defective high voltage PWB.	Check if developing bias is output when CN1-1 on the high volt- age PWB goes low while maintenance item U101 is run. If not, replace the high voltage PWB.

Problem	Causes	Check procedures/corrective measures
(13) Transfer charging is not performed.	1. The connector terminals of the high voltage PWB make poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	2. Defective engine PWB.	Check if YC13-10 on the engine PWB goes low when maintenance item U101 is run. If not, replace the engine PWB.
	3. Defective high voltage PWB.	Check if transfer charging takes place when CN1-10 on the high voltage PWB goes low while maintenance item U101 is run. If not, replace the high voltage PWB.
(14) The original size is not detected correctly.	1. Original is not placed correctly.	Check the original and correct if necessary.
	2. Poor contact in the original detection switch or original size sensor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	3. Defective original detection switch.	If the level of YC4-2 on the ISM PWB does not go low when the original detection switch is turned on and off, replace the original detection switch.
	4. Defective original size sensor.	Check if sensor operates correctly. If not, replace it.
(15) The touch panel keys do not work.	1. Poor contact in the touch panel connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	2. Defective touch panel or main operation PWB.	If any keys do not work after running the maintenance item U201 to initialize the touch panel, replace the touch panel or main operation unit PWB.
(16) The message requesting paper to be loaded is shown when paper is present on the cassette 1/2 or MP tray.	1. Poor contact in the connector terminals of paper switch 1/2 or MP paper switch.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	2. Defective paper switch 1/2 or MP paper switch.	If the level of following terminal on PWB does not change when the switch is turned on and off, replace the switch. Paper switch 1: YC8-B12 on the feed PWB Paper switch 2: YC8-B18 on the feed PWB MP paper switch: YC12-A6 on the engine PWB
(17) The size of paper on the cassette 1/2 or MP tray is not displayed correctly.	1. Poor contact in the connector terminals of paper size length switch 1/2, paper size width switch 1/2, MP paper size length switch or MP paper size width switch.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	2. Defective paper size length switch 1/2 or MP paper size length switch.	If the level of following terminal on PWB does not change when the switch is turned on and off, replace the switch. Paper size length switch 1: YC8-B2 on the engine PWB Paper size length switch 2: YC8-A19 on the engine PWB MP paper size length switch: YC12-B14 on the engine PWB
	3. Defective paper size width switch 1/2 or MP paper size width switch.	If the level of following terminal on PWB does not change when the width guide in the cassette 1/2 or insert guide on the MP tray is moved, replace the switch. Paper size width switch 1: YC9-3, 4, 5 on the engine PWB Paper size width switch 2: YC9-9, 10, 11 on the engine PWB MP paper size width switch: YC12-A1, A2, A3 on the engine PWB

Problem	Causes	Check procedures/corrective measures
(18) A paper jam in the paper feed, paper conveying, fuser, eject or duplex section is indicated when the main power switch is turned on.	1. A piece of paper torn from copy paper is caught around feed switch 1/2/3, registration switch, feedshift switch, eject switch or duplex paper conveying switch.	Check visually and remove it, if any.
	2. Defective feed switch 1/2/3, registration switch, feedshift switch, eject switch or duplex paper conveying switch.	Run maintenance item U031 and turn each switch on and off manually. Replace the switch if indication of the corresponding switch is not displayed in reverse.
(19) The message requesting cover to be closed is displayed when the front cover or left cover 1/2 is closed.	1. Poor contact in the connector terminals of front cover switch, left cover 1/2 switch.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	2. Defective front cover switch, left cover 1 switch or left cover 2 switch.	Check for continuity across each switch. If there is no continuity when the switch is on, replace it.
(20) Others.	1. Wiring is broken, shorted or makes poor contact.	Check for continuity. If none, repair.

1-4-5 Mechanical problems

Problem	Causes/check procedures	Corrective measures
(1) No primary paper feed.	Check if the surfaces of the following rollers or pulleys are dirty with paper powder: Forwarding pulley, paper feed pulley, separation pulley, feed roller, registration roller, MP forwarding pulley, MP paper feed pulley and MP separation pulley	Clean with isopropyl alcohol.
	Check if the forwarding pulley, paper feed pulley or separation pulley is deformed.	Replace the pulley if it is deformed (see page 1-5-3).
	Check if the MP forwarding pulley, MP paper feed pulley or MP separation pulley is deformed.	Replace the pulley if it is deformed (see page 1-5-5).
	Electrical problem with the following clutches: Paper feed clutch 1/2, feed clutch 1/2/3, MP paper feed clutch and MP feed clutch	See page 1-4-57.
(2) No secondary paper feed.	Check if the surfaces of the right and left registration rollers are dirty with paper powder.	Clean with isopropyl alcohol.
	Electrical problem with the registration clutch.	See page 1-4-57.
(3) Skewed paper feed.	Width guide in a cassette installed incorrectly.	Check the width guide visually and correct or replace if necessary.
	Deformed width guide in a cassette.	Check visually and replace any deformed guide.
	Check if a pressure spring along the paper conveying path is deformed or out of place.	Repair or replace.
(4) The scanner does not travel.	Check if the scanner wire is loose.	Reinstall the scanner wire (see page 1-5-16).
	The scanner motor malfunctions.	See page 1-4-55.
(5) Multiple sheets of paper are fed at one time.	Paper is extremely curled.	Replace the paper.
	Check if the separation pulley is worn.	Replace the separation pulley if it is worn (see page 1-5-3).
	Check if the MP separation pulley is worn.	Replace the MP separation pulley if it is worn (see page 1-5-5).

Problem	Causes/check procedures	Corrective measures
(6) Paper jams.	Paper is extremely curled.	Replace the paper.
	Deformed guides along the paper conveying path.	Check visually and replace any deformed guides.
	Check if the contact between the right and left registration rollers is correct.	Check visually and remedy if necessary.
	Check if the contact between the feed roller and feed pulley is correct.	Check visually and remedy if necessary.
	Check if the press roller is extremely dirty or deformed.	Clean or replace the press roller.
	Check if the contact between the heat roller and its separation claws is correct.	Repair if any springs are off the separation claws.
	Check if the contact between the eject roller and pulley is correct.	Check visually and remedy if necessary.
	The feedshift solenoid malfunctions.	See page 1-4-57.
	Check if the duplex feed pulley, upper duplex feed roller or lower duplex feed roller is deformed.	Check visually and replace the pulley or roller if deformed.
(7) Toner drops on the paper conveying path.	Check if the developing unit is extremely dirty.	Clean the developing unit.
(8) Abnormal noise is heard.	Check if the pulleys, rollers and gears operate smoothly.	Grease the bearings and gears.
	Check if the following clutches are installed correctly: Paper feed clutch 1/2, feed clutch 1/2/3, MP paper feed clutch and MP feed clutch	Correct.

1-4-6 Send error code

(1) Scan to SMB error codes

Code	Display	Remarks	
		Causes	Check procedures/corrective measures
1102	Error: User/Password or Shared Name/Folder Name	Domain name is not entered.	Enter the user name with the form of either [Domain¥User], [Domain/User] or [Domain@User].
		Assign disable user/password.	Enter the correct user name/password.
		Assign the user who is not allowed to access to folder.	Enter correct user name/password. Check the access limit of destination folder.
		Assign disable shared name.	Enter the correct shared name. Check if the prohibited letters below are used to shared name. @ () ! & # \$ % ^ ~ []`
		Host name error.	Check if the prohibited letters are used to shared name. " & ' () ; < >
1103	Error: Pathname or File Name	Domain name is not enter	Enter the user name with the form of either [Domain¥User], [Domain/User] or [Domain@User].
		Connect to the folder which is not permitted for reference/writing.	Enter correct user name/password. Check the access limit of destination folder.
		Assign disable folder path.	Enter correct folder path.
1105	Error: Not support protocol	SMB Protocol is set to OFF.	Check ON in the [Scanner]-[SMB] screen in COMMAND CENTER.
2101	Error: Can not connect	Enter the disable host name/IP address.	Enter the correct host name or IP address.
		Assign the wrong port number.	Enter the correct port number.
		Network is not connected.	Check if the server is operating properly. Check the network connection (cable. network condition within LAN, etc.).
2103	Error: Response wait with timeout	The server is unable to communicate.	Check if the server is operating properly.
2201	Error: Network transfer	Error occurs on the network.	Check the network connection (cable. network condition within LAN, etc.).
2203	Error: Response wait with timeout	Response is not returned from the server above specified time.	Check the network connection (cable. network condition within LAN, etc.).
9181	Error: Page max count over	The number of pages of a send file exceeded 999 pages.	Set the number of pages as 999 or less.

(2) Scan to FTP error codes

Code	Display	Remarks	
		Causes	Check procedures/corrective measures
1101	Error: Host name	Enter the disable host name/ IP address.	Enter the correct host name or IP address.
1102	Error: User/Password	Domain name is not entered.	Enter the user name with the form of either [Domain¥User] or [Domain/User].
		Assign disable user/pass- word.	Enter the correct user name/password.
1103	Error: Pathname or File Name	Connect to the folder which is not permitted for reference/ writing.	Enter correct user name/password. Check the access limit of destination folder.
		Assign disable folder path.	Enter correct folder path.
1105	Error: Not support protocol	FTP Protocol is set to OFF.	Check ON in the [Scanner]-[FTP] screen in COMMAND CENTER.
2101	Error: Can not connect	Enter the disable host name/ IP address.	Enter the correct host name or IP address.
		Assign the wrong port num- ber.	Enter the correct port number.
		Network is not connected.	Check if the server is operating properly. Check the network connection (cable. net- work condition within LAN, etc.).
2102	Error: Can not connect with timeout	The server is unable to com- municate.	Check if the server is operating properly.
		Send the server which does not support FTP server.	Enter the correct host name or IP address.
2103	Error: Response wait with timeout	The server is unable to com- municate.	Check if the server is operating properly.
2201	Error: Network transfer	Error occurs on the network.	Check the network connection (cable. net- work condition within LAN, etc.).
2202	Error: Network transfer with timeout	Error occurs on the network.	Check the network connection (cable. net- work condition within LAN, etc.).
2203	Error: Response wait with timeout	Response is not returned from the server above speci- fied time.	Check the network connection (cable. net- work condition within LAN, etc.).
3101	Error: Server response	The server is error status.	Check if the server is working properly.
9181	Error: Page max count over	The number of pages of a send file exceeded 999 pages.	Set the number of pages as 999 or less.

(3) Scan to E-mail error codes

Code	Display	Remarks	
		Causes	Check procedures/corrective measures
1101	Error: Host name	SMTP sever name is not set. Error SMTP server name.	Register [SMTP Server Name] in [Advanced]-[SMTP] -[General] in COMMAND CENTER.
1102	Error: User/Password	User ID for the authentication is not entered or entered wrongly. Wrong authentication password is entered.	Enter the correct user ID/password for authentication at [Advance] in COMMAND CENTER. Enter the password of [Login User Name] of the [POP3] page or the [SMTP] page correctly.
1104	Error: No Recipient address	The destination address is not specified.	Specify the destination address.
1105	Error: Not support protocol	SMTP Protocol is set to OFF.	Check ON [SMTP] in [Advanced]-[SMTP] -[General] in COMMAND CENTER.
1106	Error: No Sender Info	Sender address is not enter	Enter the correct [Sender Address] in [Advanced]-[SMTP] -[General] in COMMAND CENTER.
2101	Error: Can not connect	Select [Other authenticate] when authenticating POP before SMTP.	Select valid POP3 user other than [Other].
		The specified server is not SMTP server.	Enter the correct [SMTP Server Name] in [Advanced]-[SMTP] -[General] in COMMAND CENTER.
		Network is not connected.	Check if the server is operating properly. Check the network connection (cable. network condition within LAN, etc.).
2102	Error: Can not connect with timeout	The server is unable to communicate.	Check if the server is operating properly.
2103	Error: Response wait with timeout	The server is unable to communicate.	Check if the server is operating properly.
2201	Error: Network transfer	Error occurs on the network.	Check the network connection (cable. network condition within LAN, etc.).
2202	Error: Network transfer with timeout	Error occurs on the network.	Check the network connection (cable. network condition within LAN, etc.).
2203	Error: Response wait with timeout	Response is not returned from the server above specified time.	Check the network connection (cable. network condition within LAN, etc.).
2204	Error: E-Mail Size limit	The size of E-mail exceeds its limit.	Change the [E-mail Size Limit] in [Advanced]-[SMTP] -[General]-[E-mail Setting] in COMMAND CENTER.
3101	Error: Server response	The server is error status.	Check if the server is working properly.
		Server setting is not authenticated normally.	Check the settings for client/server authentication.
3201	Error: Not Found Authentication Mechanism	Unsupported SMTP Authentication Mechanism is found.	Check the settings for client/server Authentication Mechanism.
9181	Error: Page max count over	The number of pages of a send file exceeded 999 pages.	Set the number of pages as 999 or less.

(4) Network Twain error codes

Code	Display	Remarks	
		Causes	Check procedures/corrective measures
2202	Error: Network transfer with timeout	Response is not returned from the server above specified time.	Check the network connection (cable, network condition within LAN, etc.).
9181	Error: Page max count over	The number of pages of a send file exceeded 999 pages.	Set the number of pages as 999 or less.

(5) Software trouble error codes

Code	Display	Remarks	
		Causes	Check procedures/corrective measures
5101	Error: Not yet connected	Operation handle error. Error for stored status in the operation handle.	Turn the main power switch off and on.
5102	Error: Already connected	Operation handle error. Error for stored status in the operation handle.	Turn the main power switch off and on.
5103	Error: Not yet opened	Error for stored status in the operation handle.	Turn the main power switch off and on.
5104	Error: Already opened	Error for stored status in the operation handle.	Turn the main power switch off and on.
7101	Error: Memory Allocation	Insufficient memory space.	Turn the main power switch off and on.
7102	Error: Socket Create	Unable to create a communication socket.	Turn the main power switch off and on.
720f	Error: Unknown error	Unable to determine the cause.	Turn the main power switch off and on.

This page is intentionally left blank.

1-5-1 Precautions for assembly and disassembly

(1) Precautions

Before starting disassembly, press the power key on the operation panel to off. Make sure that the main power indicator is off before turning off the main power switch. And then unplug the power cable from the wall outlet.

Turning off the main power switch before pressing the Power key to off may cause damage to the equipped hard disk.

When the fax kit is installed, be sure to disconnect the modular code before starting disassembly.

When handling PWBs (printed wiring boards), do not touch parts with bare hands.

The PWBs are susceptible to static charge.

Do not touch any PWB containing ICs with bare hands or any object prone to static charge.

When removing the hook of the connector, be sure to release the hook.

Take care not to get the cables caught.

To reassemble the parts, use the original screws. If the types and the sizes of screws are not known, refer to the PARTS LIST.

(2) Drum

Note the following when handling or storing the drum.

When removing the drum unit, never expose the drum surface to strong direct light.

Keep the drum at an ambient temperature between -20°C/-4°F and 40°C/104°F and at a relative humidity not higher than 90% RH. Avoid abrupt changes in temperature and humidity.

Avoid exposure to any substance which is harmful to or may affect the quality of the drum.

Do not touch the drum surface with any object. Should it be touched by hands or stained with oil, clean it.

(3) Toner

Store the toner container in a cool, dark place.

Avoid direct light and high humidity.

(4) How to tell a genuine Kyocera Mita toner container

As a means of brand protection, the Kyocera Mita toner container utilizes an optical security technology to enable visual validation. A validation viewer is required to accomplish this.

Hold the validation viewer over the left side part of the brand protection seal on the toner container. Through each window of the validation viewer, the left side part of the seal should be seen as follows:

A black-colored band when seen through the left side window (●)

A shiny or gold-colored band when seen through the right side window (☼)

The above will reveal that the toner container is a genuine Kyocera Mita branded toner container, otherwise, it is a counterfeit.




Figure 1-5-1

The brand protection seal has an incision as shown below to prohibit reuse.




Figure 1-5-2

1-5-2 Paper feed section

(1) Detaching and refitting the forwarding, paper feed and separation pulleys

Follow the procedure below to replace the forwarding, paper feed and separation pulleys.

Procedure

Removing the primary paper feed units

1. Open the front cover and pull out the cassettes 1 and 2.
2. Remove the screw and remove the primary paper feed unit.




Figure 1-5-3

Removing the forwarding pulley

3. Remove the stopper and spring from the primary paper feed unit.
4. Raise the forwarding pulley retainer in the direction the arrow, and remove from the primary paper feed unit.




Figure 1-5-4

5. Remove the stop ring from the forwarding pulley retainer.
6. Remove the forwarding pulley from the forwarding pulley shaft.




Figure 1-5-5

Removing the paper feed pulley

7. Remove two stop rings from the primary paper feed unit.
8. Pull the paper feed pulley shaft in the direction of the arrow and remove the paper feed pulley.




Figure 1-5-6

Removing the separation pulley

9. Remove the stop ring from the primary paper feed unit.
10. Pull the separation pulley shaft in the direction of the arrow and remove the separation pulley.




Figure 1-5-7

11. Replace the forwarding, paper feed and separation pulleys.
12. Install the separation and paper feed pulleys to the primary paper feed unit.
13. Install the forwarding pulley to the forwarding pulley retainer.
When refitting the forwarding pulley, orient it correctly as shown in Figure 1-5-8.
14. Refit the forwarding pulley retainer to the primary paper feed unit.
15. Refit the primary paper feed unit.




Figure 1-5-8

16. When the forwarding pulley, paper feed pulley, separation pulley or the primary paper feed unit is replaced, perform maintenance mode U901 to clear the counter value (see page 1-3-96).

(2) Detaching and refitting the MP separation, MP paper feed and MP forwarding pulleys

Follow the procedure below to replace the MP separation, MP paper feed and MP forwarding pulleys.

Procedure

Removing the MP unit

1. Remove four screws and remove the right lower cover.




Figure 1-5-9

2. Remove two screws and two MP holder plates.
3. Remove two pins, two screws and two connectors, and then remove the MP unit.




Figure 1-5-10

Removing the MP separation pulley

4. Reverse the MP unit and remove the spring and stop ring from the MP separation pulley shaft and move the bushing inside.




Figure 1-5-11

5. Raise the MP separation shaft as shown in the figure, remove the holder plate and the bushing, and then remove the MP separation pulley.

Take care not to remove the spring pin of the gear at the rear of the MP separation pulley shaft. If it is removed, refit it to its original position.




Figure 1-5-12

Removing the MP paper feed pulley

6. Remove the connector of the MP paper switch and remove the wire from the three clamps.
7. Remove the screw and remove the MP unit cover.




Figure 1-5-13

8. Remove the stop ring and bushing on the front of the MP paper feed pulley shaft.




Figure 1-5-14

9. Raise the MP paper feed pulley shaft as shown in the figure, remove the stop ring, and then remove the MP paper feed pulley.




Figure 1-5-15

Removing the MP forwarding pulley

10. Remove the sponge.
 11. Remove the stop ring and MP paper feed clutch.
 When refitting, insert the cutout in the MP paper feed clutch over the stopper on the machine.




Figure 1-5-16

12. Remove the screw from the cam at the rear of the MP forwarding pulley shaft and move the cam and the bushing toward the inner side.




Figure 1-5-17

- 13. Remove the stop ring of the MP paper feed pulley shaft and slide the bushing in the direction of the arrow.




Figure 1-5-18

- 14. Slide the MP forwarding pulley shaft temporarily toward the rear side and then raise it to remove from the MP unit. Remove the shaft while raising the actuator of the MP paper switch.




Figure 1-5-19

- 15. Remove the bushing and cam on the rear of the MP forwarding pulley shaft.




Figure 1-5-20

16. Remove the stop ring and slide the MP forwarding pulley with the forwarding pulley retainer from the shaft to remove it.
17. Replace the MP separation, MP paper feed and MP forwarding pulleys.




Figure 1-5-21

18. Install the MP forwarding pulley to the MP forwarding pulley shaft.
19. Refit the MP forwarding pulley shaft to the MP unit.
20. Install the MP paper feed pulley to the MP unit.
21. Refit the MP unit cover to the MP unit.
When refitting the MP unit cover, the films on the cover are positioned under the MP paper feed pulley shaft.
22. Install the MP separation pulley to the MP unit.
23. Refit the MP unit.




Figure 1-5-22

24. When the MP forwarding pulley, MP paper feed pulley or the MP separation pulley is replaced, perform maintenance mode U901 to clear the counter value (see page 1-3-96).

(3) Detaching and refitting the left and right registration cleaner

Take the following procedure when the left or right registration cleaner is to be replaced.

Procedure

Removing the left registration cleaner

1. Open the left cover 1 and remove the transfer roller unit. (see page 1-5-29).
2. Remove two roller stoppers and remove the left registration roller.
3. Remove two registration guides.




Figure 1-5-23

4. Remove the left registration cleaner.
5. Replace the left registration cleaner and registration guides.
Install the left registration cleaner and registration guides.
6. Refit the left registration roller, roller stoppers and transfer roller unit.





Figure 1-5-24

Removing the right registration cleaner

1. Remove the developing unit and drum unit.
(see pages 1-5-28 and 1-5-25).
2. Remove the right registration cleaner.
3. Replace the right registration cleaner and
Install the cleaner.
4. Refit the drum unit and developing unit.

**Figure 1-5-25**

1-5-3 Optical section

(1) Detaching and refitting the exposure lamp

Replace the exposure lamp as follows.

Procedure

1. Remove the original cover or the DP.
2. Remove the ISU filter cover.
3. Remove ten screws and then remove the rear cover.




Figure 1-5-26

4. Remove the clip holder.
5. Open the front cover and left cover 1.
6. Remove four screws and remove front left cover.




Figure 1-5-27

7. Remove the screw and pin.
8. Remove the left upper cover.




Figure 1-5-28

9. Remove two screws and then remove the scanner left cover.




Figure 1-5-29

10. Remove two screws and then remove the scanner right cover.
11. Remove the contact glass.




Figure 1-5-30

12. Remove the connector from the inverter PWB.
13. Draw the connector into the machine inside from opening.




Figure 1-5-31

14. Remove the sponge from the wire guide and release the wire.
15. Move the mirror 1 frame to notch position.
16. Release the wire holder and then remove the wire.




Figure 1-5-32

17. Remove the screw and then remove the exposure lamp from mirror 1 frame.
18. Check or replace the exposure lamp and then install the lamp.
19. Refit all the removed parts.




Figure 1-5-33

(2) Detaching and refitting the scanner wires

Take the following procedure when the scanner wires are broken or to be replaced.

NOTE

When fitting the wires, be sure to use those specified below.

Machine front: (P/N: 302H717380), black

Machine rear: (P/N: 302H717390), gray

Fitting requires the following tools

Two frame securing tools (P/N 302FZ17100)

Two scanner wire stoppers (P/N 3596811)

Procedure

Detaching the scanner wires

1. Remove the exposure lamp (see page 1-5-12).
2. Remove each screw and then remove front and rear wire holder plates from mirror 1 frame.
3. Remove the mirror 1 frame.




Figure 1-5-34

4. Remove the round terminals from the scanner wire springs on scanner unit left side.
5. Remove the scanner wire.




Figure 1-5-35

Fitting the scanner wires

6. Move the mirror 2 frame as shown in the figure and insert two frame securing tools into the positioning holes at the front and rear of the machine center to fix the mirror 2 frame in position.




Figure 1-5-36

7. Hook the round terminals onto the catches inside of the scanner unit. (1)
8. Loop the scanner wires around the outer grooves in the pulleys on the mirror 2 frame, winding from below to above. (2)
9. Loop the scanner wire around the groove in the scanner wire pulley at the scanner unit right, winding from above to below. (3)
10. Wind the scanner wires around the scanner wire drum five turns from the rear toward the hole in the drum. (4)
11. Insert the locating ball on the scanner wire into the hole in the scanner wire drum. (5)
12. Wind the scanner wires three turns from the inner toward the hole in the drum. (6)
13. Install the scanner wire stoppers to the scanner wire drum to fix the wires. (7)
14. Loop the scanner wire around the groove in the scanner wire pulley at the scanner unit left, winding from below to above. (8)
15. Loop the scanner wires around the inner grooves in the pulleys on the mirror 2 frame, winding from below to above. (9)
16. Hook the scanner wires around the scanner wire guides at the machine left. (10)
17. Hook the round terminal onto the scanner wire spring. (11)





Figure 1-5-37

18. Remove the two scanner wire stoppers and frame securing tools.
19. Focusing on the locating ball of the wire drum, move aside the wires to inside.
20. Move the mirror 2 frame from side to side to correctly locate the wires in position.
21. Refit the mirror 1 frame.
22. Move the mirror 1 and 2 frames to the machine left, and insert the two frame securing tools into the positioning holes at the front and rear of the scanner unit to secure the frames in position.
23. Hold the wires and fix each front and rear wire holder plate to mirror 1 frame with the screw.
24. Remove the two frame securing tools.
25. Refit the exposure lamp.

**Figure 1-5-38**

(3) Detaching and refitting the ISU (reference)

Follow the procedure below to replace the ISU.

Fitting requires the following tools

Two positions pins (P/N 18568120)

Procedure

Detaching the ISU

1. Remove the contact glass (see page 1-5-12).
2. Remove seven screws and then remove the ISU cover.




Figure 1-5-39

3. Remove three screws and two connectors, and then remove the ISU.
4. Check or replace the ISU.




Figure 1-5-40

Refitting the ISU

5. Adjust the position of ISU to the frame hole of number and the same number which are recorded in the lens of ISU and then insert two positioning pins.
 Example: When a lens number is 5, move ISU so that the positioning hole of 5 of the number stamped in the scanner unit suit and insert two pins.
6. Remove two positioning pins after fixing ISU with three screws.





Figure 1-5-41

7. Refit two connectors.
8. Refit the ISU cover.
 Screw tightening order
 1) Three screws A
 2) Four screws B
9. Refit the contact glass.




Figure 1-5-42

(4) Detaching and refitting the laser scanner unit

Take the following procedure when the laser scanner unit is to be replaced.

Procedure

1. Remove the developing unit and drum unit (see pages 1-5-28 and 1-5-25).
2. Remove the right lower cover and front left cover (see pages 1-5-5 and 1-5-12).
3. Remove four screws and remove the front right cover.




Figure 1-5-43

4. Remove three screws and remove the top tray.




Figure 1-5-44

5. Remove five screws and remove the inner cover.




Figure 1-5-45

6. Remove two screws and two connectors, and then remove the fan duct.




Figure 1-5-46

7. Remove six screws and remove the toner container retainer.




Figure 1-5-47

8. Remove two pins, two springs, one screw and one connector.
9. Remove the laser scanner unit.
10. Replace the laser scanner unit and install the unit.
11. Refit the toner container retainer, fan duct and inner cover.
12. Refit the top tray, front right cover, right lower cover and front left cover.
13. Refit the drum unit and the developing unit.




Figure 1-5-48

(5) Adjusting the skew of the laser scanner unit (reference)

Perform the following adjustment if the leading and trailing edges of the copy image are laterally skewed (lateral square-ness not obtained).

Procedure




Figure 1-5-49




Figure 1-5-50

1-5-4 Drum section

(1) Detaching and refitting the drum unit

Follow the procedure below to replace the drum unit.

Cautions:

Avoid direct sunlight or strong light when detaching and refitting the drum unit.
Never touch the drum surface when holding the drum unit.

Procedure

1. Remove the developing unit (see page 1-5-28).
2. Remove the main charger unit (see page 1-5-26).
3. Remove the screw and the drum unit.
4. Replace the drum unit and install the unit.




Figure 1-5-51

(2) Detaching and refitting the main charger unit

Follow the procedure below to replace the main charger unit.

Procedure

1. Remove the developing unit (see page 1-5-28).
2. Release the inserted part and remove the connector cover.
3. Remove the connector.




Figure 1-5-52

4. Remove the screw.
5. While pushing the hole with a sharp-pointed object, remove the main charger unit.




Figure 1-5-53

6. Release the inserted part and remove the cleaning motor unit from the main charger unit.
7. Replace the main charger unit.
8. Refit the cleaning motor unit to the main charger unit.
9. Install the main charger unit.




Figure 1-5-54

(3) Detaching and refitting the drum separation claws

Follow the procedure below to replace the drum separation claws.

Procedure

1. Remove the developing unit (see page 1-5-28).
2. Remove the drum unit (see page 1-5-25).
3. Remove two screws and remove the lower cleaning seal.




Figure 1-5-55

4. Release the inserted part and remove the drum separation claws from the lower cleaning seal.
5. Replace the drum separation claws and install the claws.
6. Refit the lower cleaning seal to the drum unit.
7. Refit the drum unit and developing unit.




Figure 1-5-56

1-5-5 Developing section

(1) Detaching and refitting the developing unit

Follow the procedure below to replace the developing unit.

Procedure

1. Open the front cover.
2. Remove the toner container and waste toner box.
3. Remove the pin and turn the developing release lever in the direction of the arrow.




Figure 1-5-57

4. Remove the developing unit.
5. Replace the developing unit and install the unit.
6. Perform maintenance mode U130 (see page 1-3-49).




Figure 1-5-58

1-5-6 Transfer section

(1) Detaching and refitting the transfer roller unit

Follow the procedure below to replace the transfer roller unit.

Procedure

1. Open the left cover 1.
2. While holding down the projection, slide the transfer roller unit toward the front to remove it.
3. Replace the transfer roller unit and install the unit.
4. Perform maintenance mode U127 to clear the counter value (see page 1-3-48).




Figure 1-5-59

1-5-7 Fuser section

(1) Detaching and refitting the fuser unit

Follow the procedure below to check or replace the fuser unit.

Procedure

1. Remove the clip holder.
2. Open the front cover and left cover 1.
3. Remove four screws and remove front left cover.




Figure 1-5-60

4. Remove the screw and remove the fuser unit.
5. Check or replace the fuser unit and install the unit.
6. Perform maintenance mode U167 to clear the counter value (see page 1-3-52).




Figure 1-5-61

(2) Detaching and refitting the heat roller separation claws

Follow the procedure below to replace the heat roller separation claws.

Procedure

1. Remove the fuser unit (see page 1-5-30).
2. Remove the two pins and remove the upper fuser cover while holding the four claws.




Figure 1-5-62

3. Remove the heat roller separation claws from the upper fuser cover.
4. Replace the heat roller separation claws and install the claws to upper fuser cover.
5. Refit the upper fuser cover.
6. Refit the fuser unit.




Figure 1-5-63

(3) Detaching and refitting the press roller

Follow the procedure below to replace the press roller.

Procedure

1. Remove the fuser unit (see page 1-5-30).
2. Remove the upper fuser cover (see page 1-5-31).
3. Remove the front and rear press springs.




Figure 1-5-64

4. Remove the press roller from the fuser unit.
5. Replace the press roller and install the roller to fuser unit.
6. Refit the upper fuser cover.
7. Refit the fuser unit.




Figure 1-5-65

(4) Detaching and refitting the fuser heater

Follow the procedure below to replace the fuser heater.

Procedure

1. Remove the fuser unit (see page 1-5-30).
2. Remove the upper fuser cover (see page 1-5-31).
3. Remove two screws and the connector.




Figure 1-5-66

4. Pull out the fuser heater from the fuser unit.




Figure 1-5-67

5. Replace the fuser heater and install the heater to fuser unit.
6. Refit the upper fuser cover.
7. Refit the fuser unit.

(5) Detaching and refitting the heat roller

Follow the procedure below to replace the heat roller.

Procedure

1. Remove the fuser unit (see page 1-5-30).
2. Remove the upper fuser cover (see page 1-5-31).
3. Remove the press roller and fuser heater (see page 1-5-32 and 1-5-33).
4. Remove the fuser gear.




Figure 1-5-68

5. Remove the heat roller from the fuser unit. Remove the C ring, gear, bearing and bushing on the rear side of the heat roller and remove the C ring, ground plate, bearing and bushing on the front side.
6. Replace the heat roller and install the roller to the fuser unit.




Figure 1-5-69

7. Refit the fuser gear.
8. Refit the fuser heater, press roller and upper fuser cover.
9. Refit the fuser unit.

(6) Detaching and refitting the fuser thermistor 1 and 2

Follow the procedure below to replace the fuser thermistor 1 and 2.

Procedure

1. Remove the fuser unit (see page 1-5-30).
2. Remove the upper fuser cover (see page 1-5-31).
3. Release the stopper of the fuser thermistor 2.
4. Remove the connector and remove the fuser thermistor 2.
5. Replace the fuser thermistor 2 and install the thermistor to fuser unit.




Figure 1-5-70

6. Remove the press roller and fuser heater (see page 1-5-32 and 1-5-33).
7. Remove the heat roller (see page 1-5-34).
8. Remove the screw and the connector, and then remove the fuser thermistor 1.
9. Replace the fuser thermistor 1 and install the thermistor to fuser unit.
10. Refit the heat roller, fuser heater, press roller and upper fuser cover.
11. Refit the fuser unit.




Figure 1-5-71

(7) Adjusting front position of the fuser unit (adjusting lateral squareness)

Follow the procedure below if the drum is not parallel to the fuser unit and therefore paper is not fed straight to the fuser section and the trailing edge of image on either the front or rear side becomes longer.

Procedure




Figure 1-5-72




Figure 1-5-73

1-5-8 Others

(1) Detaching and refitting the ozone filter 1 and 2

Follow the procedure below to replace the ozone filter 1 and 2.

Procedure

1. Remove the ozone filter 1 from the machine left side.




Figure 1-5-74

2. Open the filter cover of the machine rear side and remove the ozone filter 2.
3. Replace the ozone filter 1 and 2 and install the filters.




Figure 1-5-75

(2) Detaching and refitting the dust filter 1 and 2

Follow the procedure below to replace the dust filter 1 and 2.

Procedure

1. Open the MP tray.
2. Remove the dust filter 1 and 2 from the machine.
3. Replace the dust filter 1 and 2 and install the filters.




Figure 1-5-76

(3) Detaching and refitting the ISU filter

Follow the procedure below to replace the ISU filter.

Procedure

1. Remove the ISU filter cover.
2. Replace the ISU filter and install the filter to the ISU filter cover.




Figure 1-5-77

(4) Detaching and refitting the hard disk

Follow the procedure below to replace the hard disk.

Procedure

1. Remove the ISU filter cover.
2. Remove ten screws and then remove the rear cover.




Figure 1-5-78

3. Remove the screw and then remove the main PWB lid.
4. Remove the fifteen screws and then remove the shield lid.




Figure 1-5-79

5. Remove two cable clamps.
6. Pressing the lock lever and remove the following connectors.
 - Connector (Blue)
 - Connector (Black)
7. Remove the power source connector.




Figure 1-5-80

8. Remove two screws and then remove the hard disk mount assembly.




Figure 1-5-81

9. Pressing the lock lever and remove the following connectors.
 - Connector (Blue)
 - Connector (Black)
 - Two power source connectors
10. Replace the hard disk mount assembly and refit all the removed parts.
11. Perform maintenance mode U024 (HDD initializing) (see page 1-3-19).
Reinstall applications as necessary after initializing the HDD.
12. Perform maintenance mode U917 (backup data writing) (see page 1-3-100).




Figure 1-5-82

(5) Direction of installing the principal fan motors

When detaching or refitting the fan motors, be careful of the airflow direction (intake or exhaust).




Figure 1-5-83 Machine right




Figure 1-5-84 Machine left




Figure 1-5-85 Machine rear

1-6-1 Upgrading the firmware

Follow the procedure below to upgrade the firmware of main PWB, engine PWB, scanner and panel.

Procedure

1. Perform maintenance item U000 (maintenance report output) and check U019 ROM version.
2. Press the power key on the operation panel to off. Make sure that the main power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
3. Insert USB memory in a notch hole of the machine.
4. Insert the power plug and turn the main power switch on. Upgrading firmware starts.

Caution:

Never turn the main power switch off during upgrading.




Figure 1-6-1

5. [100% Completed] is displayed on the touch panel when upgrading is complete.
6. Turn the main power switch off and unplug the power cable from the wall outlet.
7. Remove USB memory from the machine.
8. Insert the power plug and turn the main power switch on.
9. Perform maintenance item U000 (maintenance report output) and check that U019 ROM version has been upgraded.

1-6-2 Adjustment-free variable resistors (VR)

The variable resistors listed below are set at the factory prior to shipping and cannot be adjusted in the field.

High voltage PWB: VR2, VR42, VR201, VR204

1-6-3 Remarks on main PWB replacement

When replacing the main PWB, remove EEPROM (YC14) from the main PWB that has been removed and then reattach it to the new main PWB.




Figure 1-6-2

1-6-4 Remarks on engine PWB replacement

When replacing the engine PWB, remove the EEPROM (U3) from the engine PWB that has been removed and then reattach it to the new engine PWB.




Figure 1-6-3

When removing YC1, YC2, YC3, YC4, YC8, YC9, YC11 from the main PWB and YC2 from the engine PWB, press the lock lever.

When connecting the hard disk cables (YC1, YC2) to the PWB, match "BLACK" and "BLUE" marked on the PWB with the connector colors.




Figure 1-6-4

2-1-1 Paper feed section

The paper feed section consists of the primary feed and secondary feed subsections. Primary feed conveys paper from the cassettes 1, 2 or MP tray to the left and right registration rollers, at which point secondary feed takes place and the paper travels to the transfer section in sync with the printing timing.

(1) Cassette paper feed section

Each cassette consists of a lift driven by the lift motor and other components. Each cassette can hold up to 500 sheets of paper. Paper is fed from the cassette by the rotation of the forwarding pulley and paper feed pulley. The separation pulley prevents multiple sheets from being fed at one time, via the torque limiter.




Figure 2-1-1 Cassette paper feed section

- | | | |
|---------------------------|--------------------------------|--------------------------------|
| (1) Cassette base | (10) Lift switch 2 (LSW2) | (19) Registration switch (RSW) |
| (2) Cassette lift | (11) Right registration roller | (20) Feed switch 1 (FSW1) |
| (3) Cassette | (12) Left registration roller | (21) Actuator (Feed switch 1) |
| (4) Forwarding pulley | (13) Feed roller 1 | (22) Feed switch 2 (FSW2) |
| (5) Paper feed pulley | (14) Feed pulley | (23) Actuator (Feed switch 2) |
| (6) Separation pulley | (15) Feed roller 2 | (24) Feed switch 3 (FSW3) |
| (7) Paper switch 1 (PSW1) | (16) Feed pulley | (25) Actuator (Feed switch 3) |
| (8) Paper switch 2 (PSW2) | (17) Feed roller 3 | |
| (9) Lift switch 1 (LSW1) | (18) Feed pulley | |




Figure 2-1-2 Cassette paper feed section block diagram

(2) MP tray paper feed section

The MP tray can hold up to 200 sheets of paper at one time. Paper is fed from the MP tray by the rotation of the MP forwarding pulley and MP paper feed pulley. Also during paper feed, the MP separation pulley prevents multiple sheets from being fed at one time by the torque limiter.




Figure 2-1-3 MP tray paper feed section

- | | |
|--------------------------|---|
| (1) MP tray | (9) MP feed roller 2 |
| (2) MP lift guide | (10) MP feed pulley |
| (3) Paper width guide | (11) MP paper switch (MPPSW) |
| (4) MP forwarding pulley | (12) MP feed switch (MPFSW) |
| (5) MP paper feed pulley | (13) MP paper size length switch (MPPLSW) |
| (6) MP separation pulley | (14) MP paper size width switch (MPPWSW) |
| (7) Paper stopper | |
| (8) MP feed roller 1 | |




Figure 2-1-4 MP tray paper feed section block diagram

2-1-2 Optical section

The optical section consists of the scanner, mirror frame and image scanner section for scanning and the laser scanner unit for printing.

(1) Image scanner section

The original image is illuminated by the exposure lamp (EL) and scanned by the CCD in the CCD PWB (CCDPWB) via the three mirrors and lens, the reflected light being converted to an electrical signal. The mirror 1 and 2 frame travel to scan on the optical rails on the front and rear of the machine to scan from side to side. The speed of the mirror 2 frame is half the speed of the mirror 1 frame.




Figure 2-1-5 Image scanner section

- | | |
|------------------------|---------------------------------------|
| (1) Mirror 1 frame | (8) CCD PWB (CCDPWB) |
| (2) Exposure lamp (EL) | (9) ISC PWB (ISCPWB) |
| (3) Scanner reflector | (10) ISU cover |
| (4) Mirror A | (11) Scanner wire drum |
| (5) Mirror 2 frame | (12) Contact glass |
| (6) Mirror B | (13) Home position switch (HPSW) |
| (7) ISU lens | (14) Original detection switch (ODSW) |




Figure 2-1-6 Image scanner section block diagram

(2) Laser scanner section

The image data scanned by the CCD PWB (CCDPWB) is processed on the main PWB (MPWB) and transmitted from engine PWB (EPWB) as image printing data to the laser scanner unit (LSU). By repeatedly turning the laser on and off, the laser scanner unit forms a latent image on the drum surface.




Figure 2-1-7 Laser scanner section

- (1) APC PWB (APCPWB)
- (2) Collimator lens
- (3) Cylindrical lens
- (4) Polygon motor (PM)
- (5) Polygon mirror
- (6) $f\theta$ lens
- (7) Mirror
- (8) Mirror
- (9) PD sensor mirror
- (10) Cylindrical correcting lens
- (11) PD PWB (PDPWB)




Figure 2-1-8 Laser scanner section block diagram

2-1-3 Drum section

The drum section consists of the drum, main charger unit and cleaning section.

The drum is electrically charged uniformly by means of a main charger unit to form a latent image on the surface. In addition, the main charger unit is equipped with the main charger cleaning motor, and it is cleaning automatically.

The cleaning section consists of the cleaning blade that removes residual toner from the drum surface after the transfer process, and the cleaning spiral that carries the residual toner back to the waste toner box.

The cleaning lamp (CL) consists of LEDs and removes residual charge on the drum before main charging.




Figure 2-1-9 Drum section

- (1) Drum
- (2) Main charger unit
- (3) Main charger wire
- (4) Main charger grid
- (5) Main charger spiral
- (6) Cleaning roller
- (7) Cleaning spiral
- (8) Cleaning blade
- (9) Cleaning lamp (CL)
- (10) Drum separation claws




Figure 2-1-10 Drum section block diagram

2-1-4 Developing section

The developing section consists of the developing unit and the toner container.

The developing unit consists of the developing sleeve where a magnetic toner blade is formed, the doctor blade and the developing spirals that agitate the toner. When the toner sensor (TNS) detects a low toner level in the developing unit, the toner replenishment signal is output to the engine PWB (EPWB). The engine PWB (EPWB) that has received the signal turns on the toner replenishment solenoid (TNFSOL) and replenishes toner from the toner container to the developing unit. Also, the toner container sensor (TCS) checks whether or not toner remains in the toner container.




Figure 2-1-11 Developing section

- (1) Developing unit
- (2) Developing sleeve
- (3) Left developing spiral
- (4) Right developing spiral
- (5) Magnetic toner blade
- (6) Toner sensor (TNS)
- (7) Toner container
- (8) Toner container sensor (TCS)




Figure 2-1-12 Developing section block diagram

(1) Single component developing system

This machine uses the single component developing system, and reversal processing is performed with a + charged drum and a + charged magnetic toner.

With the single component developing system, toner is electrically charged by friction with the developing sleeve and + charged when it passes through the magnetic toner blade. The toner that has passed through the magnetic toner blade forms a uniform layer on the developing sleeve. When the toner layer comes to the location where the developing sleeve is the nearest to the drum, toner moves between the drum and the developing sleeve by an electric field of the magnetic pole. Then, when the developing sleeve rotates and passes through the nearest location to the drum, on the portion of the drum that has been exposed to light, toner is attracted toward the drum by potential difference between the developing bias and the drum surface and development is performed. On the other hand, on the portion of the drum that has not been exposed to light, toner is attracted toward the sleeve and development is not performed. When toner comes to an area where the gap between the drum and the developing sleeve is large, an electric field disappears and toner does not leave the developing sleeve. Development is complete.




Figure 2-1-13 Single component developing system

2-1-5 Transfer and separation sections

The transfer and separation section consists mainly of the transfer roller, separation electrode and drum separation claws. A high voltage generated by the high-voltage PWB (HVPWB) is applied to the transfer roller for transfer charging. Paper after transfer is separated from the drum by applying separation bias that is output from the high-voltage PWB (HVPWB) to the separation electrode.




Figure 2-1-14 Transfer and separation sections

- (1) Transfer roller
- (2) Transfer guide
- (3) Separation electrode
- (4) Drum separation claws
- (5) Drum




Figure 2-1-15 Transfer and separation sections block diagram

2-1-6 Fuser section

The fuser section consists of the parts shown in Figure. When paper reaches the fuser section after the transfer process, it passes between the press roller and heat roller, which is heated by fuser heaters 1 or 2 (FH1 or FH2). Pressure is applied by the fuser pressure springs so that the toner on the paper is melted, fused and fixed onto the paper. The heat roller is heated by fuser heaters 1 or 2 (FH1 or FH2) inside it; its surface temperature is detected by the fuser thermistor 1 and 2 (FTH1/2), and is regulated by the fuser heaters turning on and off.

If the fuser section becomes abnormally hot, fuser thermostat 1 and 2 (FTS1/2) operates shutting the power to the fuser heaters off. When the fusing process is completed, the paper is separated from the heat roller by its separation claws and is conveyed from the machine to eject and switchback section.




Figure 2-1-16 Fuser section

- (1) Heat roller
- (2) Fuser heater 1 (FH1)
- (3) Fuser heater 2 (FH2)
- (4) Heat roller separation claws
- (5) Fuser thermistor 1 (FTH1)
- (6) Fuser thermistor 2 (FTH2)
- (7) Fuser thermostat 1 (FTS1)
- (8) Fuser thermostat 2 (FTS2)
- (9) Press roller
- (10) Press roller separation claws




Figure 2-1-17 Fuser section block diagram

2-1-7 Eject and switchback sections

The eject and switchback sections eject paper on which fixing has ended with the eject roller that is rotated by forward rotation of the eject motor.

In duplex copying, paper is turned over by reverse rotation of the eject motor. When paper is transferred to the job separator or the internal finisher, the feedshift solenoid (FSSOL) is turned on to activate the feedshift guide to switch the paper transfer path.




Figure 2-1-18 Eject and switchback sections

- (1) Feedshift guide
- (2) Eject roller
- (3) Eject pulley
- (4) Switchback roller
- (5) Switchback pulley
- (6) Feedshift guide
- (7) Eject switch (ESW)
- (8) Actuator (Eject switch)
- (9) Feedshift switch (FSSW)
- (10) Actuator (Feedshift switch)




Figure 2-1-19 Eject and switchback sections block diagram

2-1-8 Duplex section

The duplex section consists of the components shown in figure. In duplex mode, after copying on to the reverse face of the paper, the paper is reversed in the switchback section and conveyed to the duplex section. The paper is then conveyed to the paper feed section by the upper and lower duplex feed rollers.




Figure 2-1-20 Duplex section

- (1) Feedshift guide
- (2) Upper duplex feed roller
- (3) Lower duplex feed roller
- (4) Duplex feed pulley
- (5) Duplex paper conveying switch (DUPPCSW)
- (6) Actuator (Duplex paper conveying switch)




Figure 2-1-21 Duplex section block diagram

2-2-1 Electrical parts layout

(1) PWBs




Figure 2-2-1 PWBs

- 1. Engine PWB (EPWB)..... Controls the other PWBs, electrical components and optional devices.
- 2. Main PWB (MPWB) Controls the image processing and operation panel.
- 3. Power source PWB (PSPWB) Generates +24 V DC, 5 V DC and 3.3 V DC; controls the fuser heaters.
- 4. High voltage PWB (HVPWB) Main charging. Generates developing bias and high voltages for transfer.
- 5. ISM PWB (ISMPWB) Controls the scanner section.
- 6. Inverter PWB (INPWB) Controls the exposure lamp.
- 7. ISC PWB (ISCPWB) Controls the shading correction and AGC of CCD.
- 8. CCD PWB (CCDPWB)..... Reads the image of originals.
- 9. Main operation PWB (OPWB-M) Controls touch panel and LCD indication.
- 10. Right operation PWB (OPWB-R) Consists of the operation keys and display LEDs.
- 11. Left operation PWB (OPWB-L) Consists of the operation keys and display LEDs.
- 12. Upper operation PWB (OPWB-U)..... Consists of the operation keys and display LEDs.
- 13. Front operation PWB (OPWB-F)..... Consists of the display LEDs.
- 14. LCD inverter PWB (LINPWB) Controls LCD back light.
- 15. LCD PWB (LCDPWB)..... Controls LCD indication.
- 16. Interface PWB (INPWB)..... Consists of wiring relay circuits.
- 17. APC PWB (APCPWB) Generates and controls the laser beam.
- 18. PD PWB (LDPWB)..... Detects horizontal synchronizing timing of laser beam.

19. Drum PWB (DRPWB) Controls the drum section.
 20. Developing PWB (DEVPWB) Controls the developing section.
 21. Fuser PWB (FUPWB) Controls the fuser section.

List of correspondences of PWB names

No.	Name used in service manual	Name used in parts list
1	Engine PWB (EPWB)	PARTS PWB ENGINE SP
2	Main PWB (MPWB)	PARTS MAIN PWB ASSY SP
3	Power source PWB (PSPWB)	LVU 100/LVU 200
4	High voltage PWB (HVPWB)	HVU
5	ISM PWB (ISMPWB)	PARTS PWB ISM ASSY SP
6	Inverter PWB (INPWB)	PARTS UNIT LAMP INVERTER
7	ISC PWB (ISCPWB)	PARTS PWB ISC SP
8	CCD PWB (CCDPWB)	-
9	Main operation PWB (OPWB-M)	PARTS PWB PANEL MAIN SP
10	Right operation PWB (OPWB-R)	PARTS PWB PANEL RIGHT ASSY SP
11	Left operation PWB (OPWB-L)	PARTS PWB PANEL LEFT ASSY SP
12	Upper operation PWB (OPWB-U)	OPERATION UPPER PWB ASS'Y
13	Front operation PWB (OPWB-F)	OPERATION FRONT PWB ASS'Y
14	LCD inverter PWB (LINPWB)	LCD INVERTER
15	LCD PWB (LCDPWB)	LCD OPERATION
16	Interface PWB (IFPWB)	PARTS PWB KUIO IF ASSY SP
17	APC PWB (APCPWB)	-
18	PD PWB (PDPWB)	-
19	Drum PWB (DRPWB)	-
20	Developing PWB (DEVPWB)	-
21	Fuser PWB (FUPWB)	-

(2) Switches and sensors




Figure 2-2-2 Switches and sensors

- | | | |
|--|-------|---|
| 1. Main power switch (MSW) | | Turns the AC power on and off. |
| 2. Interlock switch (ILSW) | | Turns the AC power for the fuser heaters on and off. |
| 3. Safety switch 1 (SSW1) | | Breaks the safety circuit when the left cover 1 is opened. |
| 4. Safety switch 2 (SSW2) | | Breaks the safety circuit when the front cover is opened. |
| 5. Paper switch 1 (PSW1) | | Detects the presence of paper in cassette 1. |
| 6. Paper switch 2 (PSW2) | | Detects the presence of paper in cassette 2. |
| 7. Lift switch 1 (LSW1) | | Detects lift reaching the upper limit in cassette 1. |
| 8. Lift switch 2 (LSW2) | | Detects lift reaching the upper limit in cassette 2. |
| 9. Paper size length switch 1 (PLSW1) | | Detects the length of paper in the cassette 1. |
| 10. Paper size length switch 2 (PLSW2) | | Detects the length of paper in the cassette 2. |
| 11. Paper size width switch 1 (PWSW1) | | Detects the width of paper in the cassette 1. |
| 12. Paper size width switch 2 (PWSW2) | | Detects the width of paper in the cassette 2. |
| 13. MP paper switch (MPPSW) | | Detects the presence of paper on the MP tray. |
| 14. MP paper size length switch (MPPLSW) | | Detects the length of paper on the MP tray. |
| 15. MP paper size width switch (MPPWSW) | | Detects the width of paper on the MP tray. |
| 16. Feed switch 1 (FSW1) | | Detects a paper misfeed in the paper cassette paper feed section. |
| 17. Feed switch 2 (FSW2) | | Detects a paper misfeed in the paper cassette paper feed section. |
| 18. Feed switch 3 (FSW3) | | Detects a paper misfeed in the paper cassette paper feed section. |
| 19. MP feed switch (MPFSW) | | Detects a paper misfeed in the MP tray paper feed section. |
| 20. Home position switch (HPSW) | | Detects the optical system in the home position. |

- 21. Original detection switch (ODSW) Detects the opening/closing of the original platen.
- 22. Original size sensor (OSS) Detects the size of the original.
- 23. Registration switch (RSW) Controls the secondary paper feed start timing.
- 24. Eject switch (ESW) Detects a paper misfeed in the fuser section.
- 25. Feedshift switch (FSSW) Detects a paper misfeed in the switchback section in a duplex copy.
- 26. Toner sensor (TNS)..... Detects the toner density in the developing unit.
- 27. Toner container detection switch
(TCDSW) Detects the presence of the toner container.
- 28. Toner container sensor (TCS)..... Detects the quantity of toner in a toner container.
- 29. Waste toner box detection switch
(WTDSW)..... Detects the presence of the waste toner box.
- 30. Overflow sensor (OFS) Detects when the waste toner box is full.
- 31. Humidity sensor (HUMS) Detects absolute humidity.
- 32. Fuser thermistor 1 (FTH1) Detects the heat roller temperature.
- 33. Fuser thermistor 2 (FTH2) Detects the heat roller temperature.
- 34. Front cover switch (FRCSW) Detects the opening and closing of the front cover.
- 35. Left cover 1 switch (LC1SW) Detects the opening and closing of the left cover 1.
- 36. Left cover 2 switch (LC2SW) Detects the opening and closing of the left cover 2.
- 37. Duplex paper conveying switch
(DUPPCSW) Detects a paper jam in the duplex section.

(3) Motors




Figure 2-2-3 Motors

- | | |
|---|--|
| 1. Drive motor (DM) | Drives the machine. |
| 2. Paper feed motor (PFM) | Drives paper feed section. |
| 3. Lift motor 1 (LM1)..... | Drives cassette 1 lift. |
| 4. Lift motor 2 (LM2)..... | Drives cassette 2 lift. |
| 5. Scanner motor (SM)..... | Drives the scanner section. |
| 6. Eject motor (EM)..... | Drives the eject section. |
| 7. Fuser fan motor (FUFM) | Cools the fuser section. |
| 8. Developing fan motor (DEVFM)..... | Cools the developing section. |
| 9. Power source fan motor 1 (PSFM1) | Cools the power source PWB. |
| 10. Power source fan motor 2 (PSFM2) | Cools the power source PWB. |
| 11. LSU fan motor (LSUFM) | Cools the LSU. |
| 12. Controller fan motor (CONFM)..... | Cools the controller box. |
| 13. Scanner fan motor (SFM) | Cools the scanner section. |
| 14. Duplex fan motor 1 (DUPFM1)..... | Cools the machine interior and supports paper transfer for duplex copying. |
| 15. Duplex fan motor 2 (DUPFM2)..... | Cools the machine interior and supports paper transfer for duplex copying. |
| 16. Duplex fan motor 4 (DUPFM3)..... | Cools the machine interior and supports paper transfer for duplex copying. |
| 17. Paper conveying fan motor 1 (PCFM1) | Cools the machine interior (around the paper conveying). |
| 18. Paper conveying fan motor 2 (PCFM2) | Cools the machine interior (around the paper conveying). |
| 19. Paper conveying fan motor 3 (PCFM3) | Cools the machine interior (around the paper conveying). |
| 20. Main charger cleaning motor (MCCM)..... | Drives the main charger auto cleaning. |
| 21. Polygon motor (PM)..... | Drives the polygon mirror. |

(4) Others




Figure 2-2-4 Others

- | | |
|--|---|
| 1. Paper feed clutch 1 (PFCL1) | Primary paper feed from the cassette 1. |
| 2. Paper feed clutch 2 (PFCL2) | Primary paper feed from the cassette 2. |
| 3. Feed clutch 1 (FCL1) | Controls the drive of feed roller. |
| 4. Feed clutch 2 (FCL2) | Controls the drive of feed roller. |
| 5. Feed clutch 3 (FCL3) | Controls the drive of feed roller. |
| 6. MP paper feed clutch (MPPFCL) | Primary paper feed from the MP tray. |
| 7. MP feed clutch (MPFCL) | Controls the drive of MP feed roller. |
| 8. Registration clutch (RCL) | Secondary paper feed. |
| 9. Duplex feed clutch (DUPFCL) | Controls the drive of the duplex feed roller. |
| 10. Developing clutch (DEVCL) | Controls the drive of the developing section. |
| 11. Feedshift solenoid (FSSOL) | Operates the feedshift guide. |
| 12. Toner feed solenoid (TNFSOL) | Replenishes toner. |
| 13. Exposure lamp (EL) | Exposes originals. |
| 14. Cleaning lamp (CL) | Removes residual charge from the drum surface. |
| 15. Fuser heater 1 (FH1) | Heats the heat roller. |
| 16. Fuser heater 2 (FH2) | Heats the heat roller. |
| 17. Fuser thermostat 1 (FTS1) | Prevents overheating in the fuser section. |
| 18. Fuser thermostat 2 (FTS2) | Prevents overheating in the fuser section. |
| 19. Hard disk unit 1 (HDD1) | Stores the image data and information of job accounting mode. |
| 20. Hard disk unit 2 (HDD2) | Stores the image data and information of job accounting mode. |
| 21. Cassette heater (CH) | Dehumidifies the cassette section. |

2-3-1 Power source PWB




Figure 2-3-1 Power source PWB silk-screen diagram

Connector	Pin No.	Signal	I/O	Voltage	Description
TB Connected to the inlet and main power switch	TB1	LIVE	I	120 V AC 220-240 V AC	AC power input
	TB2	COM	I	120 V AC 220-240 V AC	AC power input
	TB3	LIVE	O	120 V AC 220-240 V AC	AC power output to MSW
	TB4	LIVE	I	120 V AC 220-240 V AC	AC power input from MSW
YC1 Connected to the engine PWB and DP	1	+24VD	O	24 V DC	24 V DC power output to EPWB
	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	GND	-	-	Ground
	5	+3.3VD	O	3.3 V DC	3.3 V DC power output to EPWB
	6	+5VD	O	5 V DC	5 V DC power output to EPWB
	7	+24VDF	O	24 V DC	24 V DC power output to EPWB and DPDPWB
YC2 Connected to the engine PWB	1	GND	-	-	Ground
	2	HITON_S	I	0/3.3 V DC	FH2: On/Off
	3	HITON_M	I	0/3.3 V DC	FH1: On/Off
	4	+5VD	O	5 V DC	5 V DC power output to EPWB
	5	ZCROSS	O	0/3.3 V DC (pulse)	Zero-cross signal
	6	FANREM	I	0/24 V DC	PSFM1,2: On/Off
YC3 Connected to the document finisher	1	SGND	-	-	Ground
	2	SGND	-	-	Ground
	3	SGND	-	-	Ground
	4	SGND	-	-	Ground
	5	SGND	-	-	Ground
	6	SGND	-	-	Ground
YC4 Connected to the power source fan motor 1/2	1	FANREM	O	0/24 V DC	PSFM1,2: On/Off
	2	+24VD	O	24 V DC	24 V DC power output
YC5 Connected to the relay PWB and interlock switch	1	MH	O	120/0 V AC 220-240/0 V AC	FH1: On/Off
	2	SH	O	120/0 V AC 220-240/0 V AC	FH2: On/Off
	3	LIVE	O	120 V AC 220-240 V AC	AC power output to RYPWB

Connector	Pin No.	Signal	I/O	Voltage	Description
YC6 Connected to the ISM PWB	1	+24VD	O	24 V DC	24 V DC power output to ISM PWB
	2	+24VD	O	24 V DC	24 V DC power output to ISM PWB
	3	+24VD	O	24 V DC	24 V DC power output to ISM PWB
	4	PGND	-	-	Ground
	5	PGND	-	-	Ground
	6	PGND	-	-	Ground
	7	SGND	-	-	Ground
	8	SGND	-	-	Ground
	9	SGND	-	-	Ground
	10	SGND	-	-	Ground
	11	+12VD	O	12 V DC	12 V DC power output to ISM PWB
	12	+5VD	-	-	Not used
	13	+3.3VD	-	-	Not used
	14	+3.3VD	-	-	Not used
YC7 Connected to the cas- sette heater	1	LIVE	O	120 V AC 220-240 V AC	AC power output to CH
	2	NC	-	-	Not used
	3	NEUTRAL	O	120 V AC 220-240 V AC	AC power output to CH
YC8 Connected to the paper feeder, doc- ument fin- isher and hard disk	1	+24VDF	O	24 V DC	24 V DC power output to paper feeder
	2	+24VDF	O	24 V DC	24 V DC power output to document finisher
	3	+5VDF	O	5 V DC	5 V DC power output to document finisher
	4	P.GND	-	-	Ground
	5	F.GND	-	-	Ground
	6	P.GND	-	-	Ground
	7	+12V	O	12 V DC	12 V DC power output to hard disk
	8	GND	-	-	Ground
	9	GND	-	-	Ground
	10	+5VD	O	5 V DC	5 V DC power output to hard disk
YC9 Connected to the main operation PWB	1	+12VD	O	12 V DC	12 V DC power output to OPWB-M
	2	+5V	O	5 V DC	5 V DC power output to OPWB-M
	3	+5V	O	5 V DC	5 V DC power output to OPWB-M
	4	GND	-	-	Ground
	5	GND	-	-	Ground
	6	GND	-	-	Ground
	7	NC	-	-	Not used

Connector	Pin No.	Signal	I/O	Voltage	Description
YC10 Connected to the main PWB, DP and engine PWB	1	SLEEP_N	I	0/5 V DC	SLEEP signal
	2	+5VDF	O	5 V DC	5 V DC power output to DPDPWB
	3	5V	O	5 V DC	5 V DC power output to MPWB
	4	5V	O	5 V DC	5 V DC power output to MPWB
	5	5V	O	5 V DC	5 V DC power output to MPWB
	6	5V	O	5 V DC	5 V DC power output to MPWB
	7	NC	-	-	Not used
	8	NC	-	-	Not used
	9	NC	-	-	Not used
	10	NC	-	-	Not used
	11	GND	-	-	Ground
	12	NC	-	-	Not used
	13	GND	-	-	Ground
	14	GND	-	-	Ground
	15	GND	-	-	Ground
	16	GND	-	-	Ground

2-3-2 Engine PWB




Figure 2-3-2 Engine PWB silk-screen diagram

Connector	Pin No.	Signal	I/O	Voltage	Description
YC2 Connected to the main PWB	1	MAIN_SCL	I	0/3.3 V DC (pulse)	MPWB clock signal
	2	HLD_ENG	I	0/3.3 V DC	MPWB hold signal
	3	MAIN_SI	I	0/3.3 V DC (pulse)	MPWB serial communication data signal
	4	EG_SLEEPG	I	0/3.3 V DC	MPWB sleep signal: On/Off
	5	GND	-	-	Ground
	6	GND	-	-	Ground
	7	GND	-	-	Ground
	8	VMRE_P	I	0/3.3 V DC (pulse)	Image control signal
	9	GND	-	-	Ground
	10	VMRE_N	I	0/3.3 V DC (pulse)	Image control signal
	11	VCLK_P	I	0/3.3 V DC (pulse)	Video data clock signal
	12	VD_D0_P	I	0/3.3 V DC (pulse)	Video data control signal
	13	VCLK_N	I	0/3.3 V DC (pulse)	Video data clock signal
	14	VD_D0_N	I	0/3.3 V DC (pulse)	Video data control signal
	15	GND	-	-	Ground
	16	VD_D1_P	I	0/3.3 V DC (pulse)	Video data control signal
	17	GND	-	-	Ground
	18	VD_D1_N	I	0/3.3 V DC (pulse)	Video data control signal
	19	GND	-	-	Ground
	20	VD_D2_P	I	0/3.3 V DC (pulse)	Video data control signal
	21	GND	-	-	Ground
	22	VD_D2_N	I	0/3.3 V DC (pulse)	Video data control signal
	23	GND	-	-	Ground
	24	VD_D3_P	I	0/3.3 V DC (pulse)	Video data control signal
	25	GND	-	-	Ground
	26	VD_D3_N	I	0/3.3 V DC (pulse)	Video data control signal
	27	HSYNC_DP	O	0/3.3 V DC (pulse)	Horizontal synchronization signal
	28	VSYNC_DP	O	0/3.3 V DC (pulse)	Vertical synchronization signal
	29	HSYNC_DN	O	0/3.3 V DC (pulse)	Horizontal synchronization signal
	30	VSYNC_DN	O	0/3.3 V DC (pulse)	Vertical synchronization signal
	31	HSYNC_CP	O	0/3.3 V DC (pulse)	Horizontal synchronization signal
	32	VSYNC_CP	O	0/3.3 V DC (pulse)	Vertical synchronization signal
	33	HSYNC_CN	O	0/3.3 V DC (pulse)	Horizontal synchronization signal
	34	VSYNC_CN	O	0/3.3 V DC (pulse)	Vertical synchronization signal
	35	HSYNC_BP	O	0/3.3 V DC (pulse)	Horizontal synchronization signal
	36	VSYNC_BP	O	0/3.3 V DC (pulse)	Vertical synchronization signal
	37	HSYNC_BN	O	0/3.3 V DC (pulse)	Horizontal synchronization signal
	38	VSYNC_BN	O	0/3.3 V DC (pulse)	Vertical synchronization signal
	39	HSYNC_AP	O	0/3.3 V DC (pulse)	Horizontal synchronization signal
	40	VSYNC_AP	O	0/3.3 V DC (pulse)	Vertical synchronization signal
	41	HSYNC_AN	O	0/3.3 V DC (pulse)	Horizontal synchronization signal
	42	VSYNC_AN	O	0/3.3 V DC (pulse)	Vertical synchronization signal
	43	GND	-	-	Ground
	44	GND	-	-	Ground

Connector	Pin No.	Signal	I/O	Voltage	Description
YC2 Connected to the main PWB	45	GND	-	-	Ground
	46	MAIN_EGIRN	I	0/3.3 V DC	MPWB interrupt signal
	47	MAIN_SO	O	0/3.3 V DC (pulse)	MPWB serial communication data signal
	48	MAIN_SDIR	I	0/3.3 V DC	MPWB communication direction signal
	49	MAIN_SBSY	I	0/3.3 V DC	MPWB busy signal
	50	24V_OFF	I	0/3.3 V DC	MPWB 24 V down signal
YC3 Connected to the laser scanner unit	1	5VSAFE	I	5 V DC	5 V DC power output to APCPWB
	2	SAMPLE1	O	0/3.3 V DC	APCPWB sample/hold signal
	3	POWCONT	O	Analog	APCPWB power control signal
	4	LASER	O	0/3.3 V DC	Laser diode output signal
	5	VD+	O	0/3.3 V DC (pulse)	Video data signal
	6	VD-	O	0/3.3 V DC (pulse)	Video data signal
	7	GND	-	-	Ground
	8	PD	I	0/3.3 V DC	Laser sync signal
	9	GND	-	-	Ground
	10	R24V	O	24 V DC	24 V DC power output to PM
	11	GND	-	-	Ground
	12	SCAN	O	0/24 V DC	PM: On/Off
	13	SCRDYN	I	0/3.3 V DC	PM ready signal
	14	SCCLK	O	0/3.3 V DC (pulse)	PM clock signal
YC4 Connected to the registration switch, fuser unit, duplex feed clutch, duplex paper conveying switch, paper conveying fan motor 1/2/3 and duplex fan motor 1/2/3	A1	GND	-	-	Ground
	A2	RGFEPS	I	0/3.3 V DC	RSW: On/Off
	A3	+5V	O	5 V DC	5 V DC power output to RSW
	A4	FUSP0	I	0/3.3 V DC	Fuser unit distinction signal
	A5	+3.3V	O	3.3 V DC	3.3 V DC power output to FUPWB
	A6	THFUSER	I	Analog	FTH1 detection voltage signal
	A7	GND	-	-	Ground
	A8	THCSTD	I	Analog	FTH2 detection voltage signal
	A9	THCSEN	I	Analog	FTH2 detection voltage signal
	A10	OPEN	-	-	Not used
	B1	R24V	O	24 V DC	24 V DC power output to DUPFCL
	B2	DUCL	O	0/24 V DC	DUPFCL: On/Off
	B3	GND	-	-	Ground
	B4	DUFEPS	I	0/3.3 V DC	DUPPCSW: On/Off
	B5	+5V	O	5 V DC	5 V DC power output to DUPPCSW
	B6	+24V2	O	24 V DC	24 V DC power output to PCFM1,2,3
	B7	FAN_CONV	O	0/24 V DC	PCFM1,2,3: On/Off
	B8	DUSET	I	0/3.3 V DC	Duplex unit distinction signal
	B9	+24V2	O	24 V DC	24 V DC power output to DUPFM1,2,3
	B10	FAN5	O	0/24 V DC	DUPFM1,2,3: On/Off

Connector	Pin No.	Signal	I/O	Voltage	Description
Connected to the MP feed switch, toner container sensor, developing PWB, toner feed solenoid, toner container detection switch and drum PWB	A1	GND	-	-	Ground
	A2	MPFFEPS	I	0/3.3 V DC	MPFSW: On/Off
	A3	+5V	O	5 V DC	5 V DC power output to MPFSW
	A4	+5V	O	5 V DC	5 V DC power output to TCS
	A5	ETONPS	I	0/3.3 V DC	TCS detection signal
	A6	GND	-	-	Ground
	A7	DEVEP0	I	0/3.3 V DC	Developing unit distinction signal
	A8	+5VD	O	5 V DC	5 V DC power output to DEVPWB
	A9	TNEDIN	I	0/3.3 V DC	TNS detection signal
	A10	GND	-	-	Ground
	A11	DVUNITN	I	0/3.3 V DC	Developing unit detection signal
	A12	DVHIT	O	0/3.3 V DC	DEVPWB FUSE CUT signal
	A13	EEDATA	I/O	0/5 V DC (pulse)	DEVPWB EEPROM DATA signal
	A14	EESCLK	O	0/5 V DC (pulse)	DEVPWB EEPROM clock signal
Connected to the developing clutch	B1	R24V	O	24 V DC	24 V DC power output to TNFSOL
	B2	TONERSOL	O	0/24 V DC	TNFSOL: On/Off
	B3	TOBOSW	I	0/3.3 V DC	TCDSW: On/Off
	B4	GND	-	-	Ground
	B5	DRUMP0	I	0/3.3 V DC	Drum unit distinction signal
	B6	ERASER	O	0/24 V DC	CL: On/Off
	B7	+24V2	O	24 V DC	24 V DC power output to CL
	B8	EEDATA	I/O	0/5 V DC (pulse)	DRPWB EEPROM DATA signal
	B9	EESCLK	O	0/5 V DC (pulse)	DRPWB EEPROM clock signal
	B10	GND	-	-	Ground
	B11	DRUNIT	I	0/3.3 V DC	Drum unit detection signal
	B12	+5V	O	5 V DC	5 V DC power output to DRPWB
	B13	MCMFWD	O	0/24 V DC	MCCM: On/Off (forward)
	B14	MCMREV	O	0/24 V DC	MCCM: On/Off (reverse)
Connected to the developing clutch	1	DLPCL	O	0/24 V DC	DEVCL: On/Off
	2	+24V2	O	24 V DC	24 V DC power output to DEVCL
Connected to the feed switch 2/3, feed clutch 2/3, left cover 2 switch, lift motor 1/2, paper size length switch 1/2, lift switch 1/2 and paper switch 1/2	A1	GND	-	-	Ground
	A2	FEED2SW	I	0/3.3 V DC	FSW3: On/Off
	A3	+5V2	O	5 V DC	5 V DC power output to FSW3
	A4	R24V	O	24 V DC	24 V DC power output to FCL3
	A5	FEED3CL	O	0/24 V DC	FCL3: On/Off
	A6	GND	-	-	Ground
	A7	FEED2SW	I	0/3.3 V DC	FSW2: On/Off
	A8	+5V2	O	5 V DC	5 V DC power output to FSW2
	A9	GND	-	-	Ground
	A10	FECOSW	I	0/3.3 V DC	LC2SW: On/Off
	A11	R24V	O	24 V DC	24 V DC power output to FCL2
	A12	FEED2CL	O	0/24 V DC	FCL2: On/Off
	A13	UPLIFSW2	I	0/3.3 V DC	LM1 paper gauge signal

Connector	Pin No.	Signal	I/O	Voltage	Description
YC8	A14	GND	-	-	Ground
Connected to the feed switch 2/3, feed clutch 2/3, left cover 2 switch, lift motor 1/2, paper size length switch 1/2, lift switch 1/2 and paper switch 1/2	A15	UPLIFSW1	I	0/3.3 V DC	LM1 paper gauge signal
	A16	GND	-	-	Ground
	A17	UPLIMOH1	O	0/24 V DC	LM1: On/Off
	A18	GND	-	-	Ground
	A19	LOLESW	I	0/3.3 V DC	PLSW2: On/Off
	B1	GND	-	-	Ground
	B2	UPLESW	I	0/3.3 V DC	PLSW1: On/Off
	B3	LOLIFSW2	I	0/3.3 V DC	LM2 paper gauge signal
	B4	GND	-	-	Ground
	B5	LOLIFSW1	I	0/3.3 V DC	LM2 paper gauge signal
	B6	GND	-	-	Ground
	B7	LOLIMOH1	O	0/24 V DC	LM2: On/Off
	B8	GND	-	-	Ground
	B9	UPLIPS	I	0/3.3 V DC	LSW1: On/Off
	B10	+5V	O	5 V DC	5 V DC power output to LSW1
	B11	GND	-	-	Ground
	B12	UPPAPS	I	0/3.3 V DC	PSW1: On/Off
	B13	+5V2	O	5 V DC	5 V DC power output to PSW1
	B14	GND	-	-	Ground
B15	LOLIPS	I	0/3.3 V DC	LSW2: On/Off	
B16	+5V	O	5 V DC	5 V DC power output to LSW2	
B17	GND	-	-	Ground	
B18	LOPAPS	I	0/3.3 V DC	PSW2: On/Off	
B19	+5V2	O	5 V DC	5 V DC power output to PSW2	
YC9	1	R24V	O	24 V DC	24 V DC power output to PWSW1
Connected to the paper size width switch 1/2	2	UP24V	I	24 V DC	24 V DC power input from PWSW1
	3	UPWIDE0	I	0/3.3 V DC	PWSW1: On/Off
	4	UPWIDE1	I	0/3.3 V DC	PWSW1: On/Off
	5	UPWIDE2	I	0/3.3 V DC	PWSW1: On/Off
	6	GND	-	-	Ground
	7	R24V	O	24 V DC	24 V DC power output to PWSW2
	8	LO24V	I	24 V DC	24 V DC power input from PWSW2
	9	LOWIDE0	I	0/3.3 V DC	PWSW2: On/Off
	10	LOWIDE1	I	0/3.3 V DC	PWSW2: On/Off
	11	LOWIDE2	I	0/3.3 V DC	PWSW2: On/Off
	12	GND	-	-	Ground

Connector	Pin No.	Signal	I/O	Voltage	Description
Connected to the feed-shift solenoid, feedshift switch, eject switch, fuser fan motor, left cover 1 switch, paper feed clutch 1/2, humidity sensor and eject motor	A1	CHGSOL2	O	0/24 V DC	FSSOL: On/Off (return)
	A2	CHGSOL1	O	0/24 V DC	FSSOL: On/Off (activate)
	A3	+24V2	O	24 V DC	24 V DC power output to FSSOL
	A4	GND	-	-	Ground
	A5	DUPS	I	0/3.3 V DC	FSSW: On/Off
	A6	+5V	O	5 V DC	5 V DC power output to FSSW
	A7	GND	-	-	Ground
	A8	FDLULPS	-	-	Not used
	A9	+5V	-	-	Not used
	A10	GND	-	-	Ground
	A11	FDEJPS	I	0/3.3 V DC	ESW: On/Off
	A12	+5V	O	5 V DC	5 V DC power output to ESW
	A13	24V1	O	24 V DC	5 V DC power output to FUFM
	A14	FAN1	O	0/24 V DC	FUFM: On/Off
	A15	GND	-	-	Ground
	A16	SIDCOSW	I	0/3.3 V DC	LC1SW: On/Off
	B1	UPFECL	O	0/24 V DC	PFCL1: On/Off
	B2	UP24V	O	24 V DC	24 V DC power output to PFCL1
	B3	LO24V	O	24 V DC	24 V DC power output to PFCL2
	B4	LOFECL	O	0/24 V DC	PFCL2: On/Off
	B5	+24V2	O	24 V DC	24 V DC power output to RCL
	B6	REGFECL	O	0/24 V DC	RCL: On/Off
	B7	+3.3V	O	3.3 V DC	3.3 V DC power output to HUMS
	B8	SDA	I	Analog	HUMS detection voltage signal
	B9	GND	-	-	Ground
	B10	SCL	I	Analog	Thermistor detection voltage signal
	B11	STEPBD	O	0/24 V DC (pulse)	EM drive control signal
	B12	STEPB	O	0/24 V DC (pulse)	EM drive control signal
	B13	STEPAD	O	0/24 V DC (pulse)	EM drive control signal
	B14	STEPA	O	0/24 V DC (pulse)	EM drive control signal
	B15	OPEN	-	-	Not used
	B16	OPEN	-	-	Not used
Connected to the drive motor and paper feed motor	1	+24V2	O	24 V DC	24 V DC power output to DM
	2	PGND	-	-	Ground
	3	MMOT_RDY	I	0/3.3 V DC	DM ready signal
	4	MMOT_CLK	O	0/3.3 V DC (pulse)	DM clock signal
	5	MMOT_REM	O	0/24 V DC	DM: On/Off
	6	+24V2	O	24 V DC	24 V DC power output to PFM
	7	PGND	-	-	Ground
	8	SMOT_RDY	I	0/3.3 V DC	PFM ready signal
	9	SMOT_CLK	O	0/3.3 V DC (pulse)	PFM clock signal
	10	SMOT_REM	O	0/24 V DC	PFM: On/Off

Connector	Pin No.	Signal	I/O	Voltage	Description
YC12 Connected to the MP unit, waste toner box detection switch, overflow sensor, front cover switch, LSU fan motor and developing fan motor	A1	MPFSIZE0	I	0/3.3 V DC	MPPWSW: On/Off
	A2	MPFSIZE1	I	0/3.3 V DC	MPPWSW: On/Off
	A3	MPFSIZE2	I	0/3.3 V DC	MPPWSW: On/Off
	A4	GND	-	-	Ground
	A5	+5VD	O	5 V DC	5 V DC power output
	A6	MPFPAPS	I	0/3.3 V DC	MPPSW: On/Off
	A7	GND	-	-	Ground
	A8	R24V	O	24 V DC	24 V DC power output
	A9	MPFPAPCL	O	0/24 V DC	MPPFCL: On/Off
	A10	R24V	O	24 V DC	24 V DC power output
	A11	MPFFECL	O	0/24 V DC	MPFCL: On/Off
	B1	NC	-	-	Not used
	B2	+24V1	-	-	Ground
	B3	DEVFAN	O	0/24 V DC	CFM2: On/Off
	B4	+5VD	O	5 V DC	5 V DC power output
	B5	TOOVSE	I	0/3.3 V DC	WTDSW: On/Off
	B6	GND	-	-	Ground
	B7	OVFLSW	I	0/3.3 V DC	OFS: On/Off
	B8	GND	-	-	Ground
	B9	FRTCOSW	I	0/3.3 V DC	FRCSW: On/Off
	B10	GND	-	-	Ground
	B11	+24V1	O	0/24 V DC	CFM1: On/Off
	B12	FAN4	-	-	Ground
	B13	+5VDPI	O	5 V DC	5 V DC power output
	B14	MPFLEPS	I	0/3.3 V DC	MPPLSW: On/Off
B15	GND	-	-	Ground	
YC13 Connected to the high-voltage PWB	1	BVSEL1	O	Analog	Developing bias control voltage
	2	R24V	O	24 V DC	24 V DC power output to HVPWB
	3	GND	-	-	Ground
	4	MHVDR	O	0/3.3 V DC	Main charging: On/Off
	5	HVCLK	O	0/3.3 V DC (pulse)	Developing bias clock signal
	6	RHVDR	O	0/3.3 V DC	Separation charging: On/Off
	7	RICTL	O	Analog	Separation charging control voltage
	8	TICTL	O	Analog	Transfer charging control voltage
	9	BVSEL2	O	Analog	Developing bias control voltage
	10	THVDR	O	0/3.3 V DC	Transfer charging: On/Off

Connector	Pin No.	Signal	I/O	Voltage	Description
YC14 Connected to the document finisher	1	DET	I	0/5 V DC	Document finisher connection signal
	2	DFSDO	O	0/5 V DC (pulse)	Document finisher serial communication data signal
	3	DFSDI	I	0/5 V DC (pulse)	Document finisher serial communication data signal
	4	DFSCLK	O	0/5 V DC (pulse)	Document finisher clock signal
	5	DFSEL	O	0/5 V DC	Document finisher select signal
	6	SISEL	-	-	Not used
	7	DFRDY	I	0/5 V DC	Document finisher ready signal
	8	SIRDY	-	-	Not used
YC15 Connected to the paper feeder	1	GND	-	-	Ground
	2	+5V	O	5 V DC	5 V DC power output to paper feeder
	3	PFSEL	O	0/5 V DC	Paper feeder select signal
	4	PFCLK	O	0/5 V DC (pulse)	Paper feeder clock signal
	5	PFSDI	I	0/5 V DC (pulse)	Paper feeder serial communication data signal
	6	PFSDO	O	0/5 V DC (pulse)	Paper feeder serial communication data signal
	7	PFREADY	I	0/5 V DC	Paper feeder ready signal
	8	PFFEED	O	0/5 V DC	Paper feeder feed signal
YC16 Connected to the built-in finisher	1	+24V	O	24 V DC	24 V DC power output to built-in finisher
	2	+24V	O	24 V DC	24 V DC power output to built-in finisher
	3	PGND	-	-	Ground
	4	PGND	-	-	Ground
	5	+5VD	O	5 V DC	5 V DC power output to built-in finisher
	6	SGND	-	-	Ground
	7	DFSEL	O	0/5 V DC	Built-in finisher select signal
	8	DFRDY	I	0/5 V DC	Built-in finisher ready signal
	9	SDI	I	0/5 V DC (pulse)	Built-in finisher serial communication data signal
	10	SDO	O	0/5 V DC (pulse)	Built-in finisher serial communication data signal
	11	SCLK	O	0/5 V DC (pulse)	Built-in finisher clock signal
	12	OPEN	-	-	Not used
YC17 Connected to the job separator	1	JOB_EJT_SIG	I	0/3.3 V DC	JESW: On/Off
	2	+5VD	O	5 V DC	5 V DC power output to JESW
	3	GND	-	-	Ground
	4	GND	-	-	Ground
	5	SET SIG	I	0/3.3 V DC	Job separator connection signal
	6	GND	-	-	Ground
	7	EPDSW	I	0/3.3 V DC	EPDSW: On/Off
	8	+5VD	O	5 V DC	5 V DC power output to EPDSW
	9	LED REM	O	0/3.3 V DC	LED: On/Off
	10	+5VD LED	O	5 V DC	5 V DC power output to LEDPWB
	11	FSSOL2	O	0/24 V DC	JFSSOL: On/Off (return)
	12	FSSOL1	O	0/24 V DC	JFSSOL: On/Off (activate)
	13	+24VDR	O	24 V DC	24 V DC power output to JFSSOL

Connector	Pin No.	Signal	I/O	Voltage	Description
YC19 Connected to the total counter, key card and key counter	1	+24V2	O	24 V DC	24 V DC power output to total counter
	2	T_CNT_REM1	O	0/24 V DC	Total counter signal
	3	GND	-	-	Ground
	4	SET_MS_SIG	I	0/3.3 V DC	Connection signal
	5	GND	-	-	Ground
	6	KEY_SET_SIG	I	0/3.3 V DC	Key counter connection signal
	7	+24V3	O	24 V DC	24 V DC power output to key counter
	8	KEY_CNT_REM	O	0/24 V DC	Key counter signal
	9	SET_KT_SIG	I	0/3.3 V DC	Connection signal
	10	GND	-	-	Ground
YC21 Connected to the power source PWB	1	+24VDR	I	24 V DC	24 V DC power input from PSPWB
	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	GND	-	-	Ground
	5	+3.3V	I	3.3 V DC	3.3 V DC power input from PSPWB
	6	+5VD	I	5 V DC	5 V DC power input from PSPWB
	7	+24VDR	I	24 V DC	24 V DC power input from PSPWB
YC22 Connected to the power source PWB	1	FAN3N	O	0/24 V DC	PSFM1,2: On/Off
	2	ZCROSS	I	0/3.3 V DC (pulse)	Zero-cross signal
	3	+5VD	I	5 V DC	5 V DC power input from PSPWB
	4	_HITON_M	O	0/3.3 V DC	FH1: On/Off
	5	_HITON_S	O	0/3.3 V DC	FH2: On/Off
	6	GND	-	-	Ground
	7	SLEEP	O	0/3.3 V DC	Sleep signal
YC23 Connected to the feed clutch 1 and feed switch 1	1	+24V2	O	24 V DC	24 V DC power output
	2	FEED1CL	O	0/24 V DC	FCL1: On/Off
	3	SGND	-	-	Ground
	4	UPFEPS	-	0/3.3 V DC	FSW1: On/Off
	5	+5VD	O	5 V DC	5 V DC power output to FSW1

2-3-3 Main PWB




Figure 2-3-3 Main PWB silk-screen diagram

Connector	Pin No.	Signal	I/O	Voltage	Description
YC1 Connected to the hard disk 1	1	GND	-	-	Ground
	2	TXP	O	0/3.3 V DC (pulse)	Transmission data
	3	TXN	O	0/3.3 V DC (pulse)	Transmission data
	4	GND	-	-	Ground
	5	RXN	I	0/3.3 V DC (pulse)	Received data
	6	RXP	I	0/3.3 V DC (pulse)	Received data
	7	GND	-	-	Ground
YC2 Connected to the hard disk 2	1	GND	-	-	Ground
	2	TXP	O	0/3.3 V DC (pulse)	Transmission data
	3	TXN	O	0/3.3 V DC (pulse)	Transmission data
	4	GND	-	-	Ground
	5	RXN	I	0/3.3 V DC (pulse)	Received data
	6	RXP	I	0/3.3 V DC (pulse)	Received data
	7	GND	-	-	Ground
YC3 Connected to the engine PWB	1	EG_SCLK	O	0/3.3 V DC (pulse)	EPWB clock signal
	2	HLD_ENG	O	0/3.3 V DC	EPWB hold signal
	3	EG_SI	O	0/3.3 V DC (pulse)	EPWB serial communication data signal
	4	SLEEP	O	0/3.3 V DC	EPWB sleep signal: On/Off
	5	GND	-	-	Ground
	6	GND	-	-	Ground
	7	VMREA P	-	-	Not used
	8	VMRED P	O	0/3.3 V DC (pulse)	Image control signal
	9	VMREA N	-	-	Not used
	10	VMRED N	O	0/3.3 V DC (pulse)	Image control signal
	11	VD A0 P	-	-	Not used
	12	VD D0 P	O	0/3.3 V DC (pulse)	Video data control signal
	13	VD A0 N	-	-	Not used
	14	VD D0 N	O	0/3.3 V DC (pulse)	Video data control signal
	15	VD A1 P	-	-	Not used
	16	VD D1 P	O	0/3.3 V DC (pulse)	Video data control signal
	17	VD A1 N	-	-	Not used
	18	VD D1 N	O	0/3.3 V DC (pulse)	Video data control signal
	19	VD A2 P	-	-	Not used
	20	VD D2 P	O	0/3.3 V DC (pulse)	Video data control signal
	21	VD A2 N	-	-	Not used
	22	VD D2 N	O	0/3.3 V DC (pulse)	Video data control signal
	23	VD A3 P	-	-	Not used
	24	VD D3 P	O	0/3.3 V DC (pulse)	Video data control signal
	25	VD A3 N	-	-	Not used
	26	VD D3 N	O	0/3.3 V DC (pulse)	Video data control signal
	27	VMREB P	-	-	Not used
	28	VMREC P	-	-	Not used
	29	VMREB N	-	-	Not used
	30	VMREC N	-	-	Not used

Connector	Pin No.	Signal	I/O	Voltage	Description
YC3 Connected to the engine PWB	31	VD B0 P	-	-	Not used
	32	VD C0 P	-	-	Not used
	33	VD B0 N	-	-	Not used
	34	VD C0 N	-	-	Not used
	35	VD B1 P	-	-	Not used
	36	VD C1 P	-	-	Not used
	37	VD B1 N	-	-	Not used
	38	VD C1 N	-	-	Not used
	39	VD B2 P	-	-	Not used
	40	VD C2 P	-	-	Not used
	41	VD B2 N	-	-	Not used
	42	VD C2 N	-	-	Not used
	43	VD B3 P	-	-	Not used
	44	VD C3 P	-	-	Not used
	45	VD B3 N	-	-	Not used
	46	VD C3 N	-	-	Not used
	47	VCLKOUT P	O	0/3.3 V DC (pulse)	Video data clock signal
	48	GND	-	-	Ground
	49	VCLKOUT N	O	0/3.3 V DC (pulse)	Video data clock signal
	50	GND	-	-	Ground
YC4 Connected to the engine PWB	1	GND	-	-	Ground
	2	GND	-	-	Ground
	3	HSYNCDN P	I	0/3.3 V DC (pulse)	Horizontal synchronization signal
	4	VSYNCD P	I	0/3.3 V DC (pulse)	Vertical synchronization signal
	5	HSYNCDN N	I	0/3.3 V DC (pulse)	Horizontal synchronization signal
	6	VSYNCD N	I	0/3.3 V DC (pulse)	Vertical synchronization signal
	7	HSYNCCN P	I	0/3.3 V DC (pulse)	Horizontal synchronization signal
	8	VSYNCC P	I	0/3.3 V DC (pulse)	Vertical synchronization signal
	9	HSYNCCN N	I	0/3.3 V DC (pulse)	Horizontal synchronization signal
	10	VSYNCC N	I	0/3.3 V DC (pulse)	Vertical synchronization signal
	11	HSYNCBN P	I	0/3.3 V DC (pulse)	Horizontal synchronization signal
	12	VSYNCB P	I	0/3.3 V DC (pulse)	Vertical synchronization signal
	13	HSYNCBN N	I	0/3.3 V DC (pulse)	Horizontal synchronization signal
	14	VSYNCB N	I	0/3.3 V DC (pulse)	Vertical synchronization signal
	15	HSYNCAN P	I	0/3.3 V DC (pulse)	Horizontal synchronization signal
	16	VSYNCA P	I	0/3.3 V DC (pulse)	Vertical synchronization signal
	17	HSYNCAN N	I	0/3.3 V DC (pulse)	Horizontal synchronization signal
	18	VSYNCA N	I	0/3.3 V DC (pulse)	Vertical synchronization signal
	19	GND	-	-	Ground
	20	GND	-	-	Ground
	21	EG_IRN	O	0/3.3 V DC	EPWB interrupt signal
	22	NC	-	-	Not used
	23	EG_SO	I	0/3.3 V DC (pulse)	EPWB serial communication data signal
	24	NC	-	-	Not used

Connector	Pin No.	Signal	I/O	Voltage	Description
YC4 Connected to the engine PWB	25	EG_SDIR	O	0/3.3 V DC	EPWB communication direction signal
	26	NC	-	-	Not used
	27	EG_SBSY	O	0/3.3 V DC	EPWB busy signal
	28	NC	-	-	Not used
	29	+24V DOWN	O	0/3.3 V DC	EPWB 24 V down signal
	30	NC	-	-	Not used
YC5-1 Connected to the ethernet	1	CT	O	3.3 V DC	3.3 V DC power output
	2	TD+	O	0/3.3 V DC (pulse)	Transmission data
	3	TD-	O	0/3.3 V DC (pulse)	Transmission data
	4	RD+	I	0/3.3 V DC (pulse)	Received data
	5	RD-	I	0/3.3 V DC (pulse)	Received data
	6	CT	O	3.3 V DC	3.3 V DC power output
	7	CAT PHY	O	0/3.3 V DC	Control signal
	8	ANO PHY	O	3.3 V DC	3.3 V DC power output
	9	CAT MAC	-	-	Ground
	10	ANO MAC	O	0/3.3 V DC	Control signal
YC5-2 Connected to the USB	U1	VBUS	I	5 V DC	5 V DC power input
	U2	DATA-	I/O	-	USB data signal
	U3	DATA+	I/O	-	USB data signal
	U4	GND	-	-	Ground
YC8 Connected to the interface PWB	1	GND	-	-	Ground
	2	AUDIO	I	Analog	AUDIO signal
	3	SEL AUDIO0	O	0/3.3 V DC	SEL AUDIO0 signal
	4	SEL AUDIO1	O	0/3.3 V DC	SEL AUDIO1 signal
	5	_REG	I	0/3.3 V DC	REG signal
	6	A8	O	0/3.3 V DC (pulse)	Address bus signal
	7	A15	O	0/3.3 V DC (pulse)	Address bus signal
	8	A7	O	0/3.3 V DC (pulse)	Address bus signal
	9	A14	O	0/3.3 V DC (pulse)	Address bus signal
	10	A6	O	0/3.3 V DC (pulse)	Address bus signal
	11	A13	O	0/3.3 V DC (pulse)	Address bus signal
	12	A5	O	0/3.3 V DC (pulse)	Address bus signal
	13	A12	O	0/3.3 V DC (pulse)	Address bus signal
	14	A4	O	0/3.3 V DC (pulse)	Address bus signal
	15	A11	O	0/3.3 V DC (pulse)	Address bus signal
	16	A3	O	0/3.3 V DC (pulse)	Address bus signal
	17	A10	O	0/3.3 V DC (pulse)	Address bus signal
	18	A2	O	0/3.3 V DC (pulse)	Address bus signal
	19	A9	O	0/3.3 V DC (pulse)	Address bus signal
	20	A1	O	0/3.3 V DC (pulse)	Address bus signal
	21	GND	-	-	Ground
	22	GND	-	-	Ground
	23	D8	I/O	0/3.3 V DC (pulse)	Data bus signal
	24	D0	I/O	0/3.3 V DC (pulse)	Data bus signal
	25	D9	I/O	0/3.3 V DC (pulse)	Data bus signal

Connector	Pin No.	Signal	I/O	Voltage	Description
YC8 Connected to the inter- face PWB	26	D1	I/O	0/3.3 V DC (pulse)	Data bus signal
	27	D10	I/O	0/3.3 V DC (pulse)	Data bus signal
	28	D2	I/O	0/3.3 V DC (pulse)	Data bus signal
	29	D11	I/O	0/3.3 V DC (pulse)	Data bus signal
	30	D3	I/O	0/3.3 V DC (pulse)	Data bus signal
	31	GND	-	-	Ground
	32	GND	-	-	Ground
	33	D12	I/O	0/3.3 V DC (pulse)	Data bus signal
	34	D4	I/O	0/3.3 V DC (pulse)	Data bus signal
	35	D13	I/O	0/3.3 V DC (pulse)	Data bus signal
	36	D5	I/O	0/3.3 V DC (pulse)	Data bus signal
	37	D14	I/O	0/3.3 V DC (pulse)	Data bus signal
	38	D6	I/O	0/3.3 V DC (pulse)	Data bus signal
	39	D15	I/O	0/3.3 V DC (pulse)	Data bus signal
	40	D7	I/O	0/3.3 V DC (pulse)	Data bus signal
	41	GND	-	-	Ground
	42	GND	-	-	Ground
	43	KUIODREQT0	I	0/3.3 V DC (pulse)	KUIODREQT0 signal
	44	KUIODREQT1	I	0/3.3 V DC (pulse)	KUIODREQT1 signal
	45	KUIODREQR0	I	0/3.3 V DC (pulse)	KUIODREQR0 signal
	46	KUIODREQR1	I	0/3.3 V DC (pulse)	KUIODREQR1 signal
	47	KUIOIORN0	O	0/3.3 V DC (pulse)	KUIOIORN0 signal
	48	KUIOIORN1	O	0/3.3 V DC (pulse)	KUIOIORN1 signal
	49	KUIOIOWN0	O	0/3.3 V DC (pulse)	KUIOIOWN0 signal
	50	KUIOIOWN1	O	0/3.3 V DC (pulse)	KUIOIOWN1 signal
YC9 Connected to the inter- face PWB	1	KUIOCSN0	O	0/3.3 V DC (pulse)	KUIOCSN0 signal
	2	KUIOCSN1	O	0/3.3 V DC (pulse)	KUIOCSN1 signal
	3	KUIOACKN0	I	0/3.3 V DC (pulse)	KUIOACKN0 signal
	4	KUIOACKN1	I	0/3.3 V DC (pulse)	KUIOACKN1 signal
	5	KUIOIRN0	I	0/3.3 V DC	KUIOIRN0 signal
	6	KUIOIRN1	I	0/3.3 V DC	KUIOIRN1 signal
	7	KUIORDY0	O	0/3.3 V DC	KUIORDY0 signal
	8	KUIORDY1	O	0/3.3 V DC	KUIORDY1 signal
	9	GND	-	-	Ground
	10	GND	-	-	Ground
	11	KUIODACKRN0	O	0/3.3 V DC (pulse)	KUIODACKRN0 signal
	12	KUIODACKRN1	O	0/3.3 V DC (pulse)	KUIODACKRN1 signal
	13	KUIODACKTN0	O	0/3.3 V DC (pulse)	KUIODACKTN0 signal
	14	KUIODACKTN1	O	0/3.3 V DC (pulse)	KUIODACKTN1 signal
	15	KUIORSTN0	O	0/3.3 V DC	KUIORSTN0 signal
	16	KUIORSTN1	O	0/3.3 V DC	KUIORSTN1 signal
	17	GND	-	-	Ground
	18	GND	-	-	Ground
	19	SLEEP	O	0/3.3 V DC	SLEEP signal
	20	CFOEN0	O	0/3.3 V DC (pulse)	CFOEN0 signal

Connector	Pin No.	Signal	I/O	Voltage	Description
YC9 Connected to the interface PWB	21	EXTBOEN	O	0/3.3 V DC (pulse)	EXTBOEN signal
	22	CFWEN0	O	0/3.3 V DC (pulse)	CFWEN0 signal
	23	EXTBDIR	O	0/3.3 V DC (pulse)	EXTBDIR signal
	24	CFRST0	O	0/3.3 V DC	CFRST0 signal
	25	CF0CSN0	O	0/3.3 V DC (pulse)	CF0CSN0 signal
	26	CFWAITN0	I	0/3.3 V DC	CFWAITN0 signal
	27	CF0CSN1	O	0/3.3 V DC (pulse)	CF0CSN1 signal
	28	CF0CDET1	I	0/3.3 V DC	CF0CDET1 signal
	29	GND	-	-	Ground
	30	CF0CDET2	I	0/3.3 V DC	CF0CDET2 signal
YC10 Connected to the DP	1	GND	-	-	Ground
	2	GND	-	-	Ground
	3	3.3V	O	3.3 V DC	3.3 V DC power output to DPRPWB
	4	3.3V	O	3.3 V DC	3.3 V DC power output to DPRPWB
	5	3.3V	O	3.3 V DC	3.3 V DC power output to DPRPWB
	6	3.3V	O	3.3 V DC	3.3 V DC power output to DPRPWB
	7	VCLKB	I	0/3.3 V DC (pulse)	DPRPWB clock signal
	8	VSYNCB	I	0/3.3 V DC (pulse)	DPRPWB VSYNCB signal
	9	HSYNCB	I	0/3.3 V DC (pulse)	DPRPWB HSYNCB signal
	10	MREB	I	0/3.3 V DC (pulse)	DPRPWB MREB signal
	11	GND	-	-	Ground
	12	DRB0	I	0/3.3 V DC (pulse)	Image data signal
	13	DRB1	I	0/3.3 V DC (pulse)	Image data signal
	14	DRB2	I	0/3.3 V DC (pulse)	Image data signal
	15	DRB3	I	0/3.3 V DC (pulse)	Image data signal
	16	DRB4	I	0/3.3 V DC (pulse)	Image data signal
	17	DRB5	I	0/3.3 V DC (pulse)	Image data signal
	18	DRB6	I	0/3.3 V DC (pulse)	Image data signal
	19	DRB7	I	0/3.3 V DC (pulse)	Image data signal
	20	GND	-	-	Ground
	21	DGB0	I	0/3.3 V DC (pulse)	Image data signal
	22	DGB1	I	0/3.3 V DC (pulse)	Image data signal
	23	DGB2	I	0/3.3 V DC (pulse)	Image data signal
	24	DGB3	I	0/3.3 V DC (pulse)	Image data signal
	25	DGB4	I	0/3.3 V DC (pulse)	Image data signal
	26	DGB5	I	0/3.3 V DC (pulse)	Image data signal
	27	DGB6	I	0/3.3 V DC (pulse)	Image data signal
	28	DGB7	I	0/3.3 V DC (pulse)	Image data signal
	29	GND	-	-	Ground
	30	DBB0	I	0/3.3 V DC (pulse)	Image data signal
	31	DBB1	I	0/3.3 V DC (pulse)	Image data signal
	32	DBB2	I	0/3.3 V DC (pulse)	Image data signal
	33	DBB3	I	0/3.3 V DC (pulse)	Image data signal
	34	DBB4	I	0/3.3 V DC (pulse)	Image data signal
	35	DBB5	I	0/3.3 V DC (pulse)	Image data signal

Connector	Pin No.	Signal	I/O	Voltage	Description
YC10 Connected to the optional DP	36	DBB6	I	0/3.3 V DC (pulse)	Image data signal
	37	DBB7	I	0/3.3 V DC (pulse)	Image data signal
	38	TWS_SCM_HALF	O	0/3.3 V DC	DPRPWB control signal
	39	RES_SLEEP	O	0/3.3 V DC	DPRPWB control signal
	40	TWS_DET1	I	0/3.3 V DC	DPRPWB control signal
	41	GND	-	-	Ground
	42	LA2	O	0/3.3 V DC (pulse)	Address bus signal
	43	LA3	O	0/3.3 V DC (pulse)	Address bus signal
	44	LA4	O	0/3.3 V DC (pulse)	Address bus signal
	45	LA5	O	0/3.3 V DC (pulse)	Address bus signal
	46	LA6	O	0/3.3 V DC (pulse)	Address bus signal
	47	LA7	O	0/3.3 V DC (pulse)	Address bus signal
	48	LA8	O	0/3.3 V DC (pulse)	Address bus signal
	49	LA9	O	0/3.3 V DC (pulse)	Address bus signal
	50	LA10	O	0/3.3 V DC (pulse)	Address bus signal
	51	LA11	O	0/3.3 V DC (pulse)	Address bus signal
	52	LA12	O	0/3.3 V DC (pulse)	Address bus signal
	53	LA13	O	0/3.3 V DC (pulse)	Address bus signal
	54	LA14	O	0/3.3 V DC (pulse)	Address bus signal
	55	LA15	O	0/3.3 V DC (pulse)	Address bus signal
	56	LA16	O	0/3.3 V DC (pulse)	Address bus signal
	57	LA17	O	0/3.3 V DC (pulse)	Address bus signal
	58	GND	-	-	Ground
	59	LD0	I/O	0/3.3 V DC (pulse)	Data bus signal
	60	LD1	I/O	0/3.3 V DC (pulse)	Data bus signal
	61	LD2	I/O	0/3.3 V DC (pulse)	Data bus signal
	62	LD3	I/O	0/3.3 V DC (pulse)	Data bus signal
	63	LD4	I/O	0/3.3 V DC (pulse)	Data bus signal
	64	LD5	I/O	0/3.3 V DC (pulse)	Data bus signal
	65	LD6	I/O	0/3.3 V DC (pulse)	Data bus signal
	66	LD7	I/O	0/3.3 V DC (pulse)	Data bus signal
	67	GND	-	-	Ground
	68	INT	I	0/3.3 V DC	DPRPWB control signal
	69	RESETZ	O	0/3.3 V DC	DPRPWB control signal
	70	GND	-	-	Ground
	71	CEZ	O	0/3.3 V DC (pulse)	DPRPWB control signal
72	WEZ	O	0/3.3 V DC (pulse)	DPRPWB control signal	
73	OEZ	O	0/3.3 V DC (pulse)	DPRPWB control signal	
74	SCLKIN	O	0/3.3 V DC (pulse)	DPRPWB clock signal	
75	3.3V	O	3.3 V DC	3.3 V DC power output to DPRPWB	
76	3.3V	O	3.3 V DC	3.3 V DC power output to DPRPWB	
77	3.3V	O	3.3 V DC	3.3 V DC power output to DPRPWB	
78	3.3V	O	3.3 V DC	3.3 V DC power output to DPRPWB	
79	GND	-	-	Ground	
80	GND	-	-	Ground	

Connector	Pin No.	Signal	I/O	Voltage	Description
YC11 Connected to the ISC PWB	1	GND	-	-	Ground
	2	G6_SC_SCLK	O	0/3.3 V DC (pulse)	ISCPWB clock signal
	3	GND	-	-	Ground
	4	G6_SC_SI	O	0/3.3 V DC (pulse)	ISCPWB serial communication data signal
	5	GND	-	-	Ground
	6	G6_SC_SO	I	0/3.3 V DC (pulse)	ISCPWB serial communication data signal
	7	G6_SC_SBSY	I	0/3.3 V DC	ISCPWB busy signal
	8	G6_SC_SDIR	I	0/3.3 V DC	ISCPWB communication direction signal
	9	G6_SC_IRN	I	0/3.3 V DC	ISCPWB interrupt signal
	10	HLD_SCN	O	0/3.3 V DC	ISCPWB scanner hold signal
	11	GND	-	-	Ground
	12	GND	-	-	Ground
	13	GND	-	-	Ground
	14	IS_SAD4N	I	0/3.3 V DC (pulse)	Image data signal
	15	IS_SAD4P	I	0/3.3 V DC (pulse)	Image data signal
	16	GND	-	-	Ground
	17	IS_SACKN	I	0/3.3 V DC (pulse)	ISCPWB clock signal
	18	IS_SACKP	I	0/3.3 V DC (pulse)	ISCPWB clock signal
	19	GND	-	-	Ground
	20	IS_SAD3N	I	0/3.3 V DC (pulse)	Image data signal
	21	IS_SAD3P	I	0/3.3 V DC (pulse)	Image data signal
	22	GND	-	-	Ground
	23	IS_SAD2N	I	0/3.3 V DC (pulse)	Image data signal
	24	IS_SAD2P	I	0/3.3 V DC (pulse)	Image data signal
	25	GND	-	-	Ground
	26	IS_SAD1N	I	0/3.3 V DC (pulse)	Image data signal
	27	IS_SAD1P	I	0/3.3 V DC (pulse)	Image data signal
	28	GND	-	-	Ground
	29	GND	-	-	Ground
	30	GND	-	-	Ground
	31	GND	-	-	Ground
YC12 Connected to the main operation PWB	1	FPSTAT	I	0/3.3 V DC	Operation panel status signal
	2	S LED0	O	0/3.3 V DC	Operation panel LED display signal
	3	S LED1	O	0/3.3 V DC	Operation panel LED display signal
	4	PANEL RESET	O	0/3.3 V DC	OPWB-M reset signal
	5	HLD PANEL	O	0/3.3 V DC	Operation panel displaying enable signal
	6	SW FOOTN	-	-	Not used
	7	+24V DOWN	O	0/3.3 V DC	24 V DC down signal
	8	SUPND ENTER	O	0/3.3 V DC	Energy save mode control signal
	9	AUDIO	O	Analog	Audio output signal
	10	SGND	-	-	Ground
	11	PH KEY	I	0/3.3 V DC	Power key: On/Off
	12	SGND	-	-	Ground
	13	SUPND POWER	O	5 V DC	5 V DC power to OPWB-M

Connector	Pin No.	Signal	I/O	Voltage	Description
YC17 Connected to the main operation PWB	1	VBUS	I	5 V DC	5 V DC power input
	2	DATA-	I/O	-	USB data signal
	3	DATA+	I/O	-	USB data signal
	4	NC	-	-	Not used
	5	GND	-	-	Ground
YC20 Connected to the USB	U1	VBUS	O	5 V DC	5 V DC power output
	U2	DATA-	I/O	-	USB data signal
	U3	DATA+	I/O	-	USB data signal
	U4	GND	-	-	Ground
YC21 Connected to the USB	1	VBUS	O	5 V DC	5 V DC power output
	2	DATA-	I/O	-	USB data signal
	3	DATA+	I/O	-	USB data signal
	4	NC	-	-	Not used
	5	GND	-	-	Ground
YC23 Connected to the controller fan motor	1	CLT FAN	O	0/5 V DC	CONFM: On/Off
	2	GND	-	-	Ground
	3	+5V	O	5 V DC	5 V DC power output to CONFM
YC24 Connected to the power source PWB	1	5V	I	5 V DC	5 V DC power input from PSPWB
	2	5V	I	5 V DC	5 V DC power input from PSPWB
	3	5V	I	5 V DC	5 V DC power input from PSPWB
	4	5V	I	5 V DC	5 V DC power input from PSPWB
	5	GND	-	-	Ground
	6	GND	-	-	Ground
	7	GND	-	-	Ground
	8	GND	-	-	Ground
YC25 Connected to the interface PWB	1	5V	O	5 V DC	5 V DC power output to IFPWB
	2	GND	-	-	Ground

2-3-4 ISM PWB




Figure 2-3-4 ISM PWB silk-screen diagram

Connector	Pin No.	Signal	I/O	Voltage	Description
YC1 Connected to the power source PWB	1	24V1	I	24 V DC	24 V DC power input from PSPWB
	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	12V1	I	12 V DC	12 V DC power input from PSPWB
YC2 Connected to the ISC PWB	1	DPTMG	O	0/3.3 V DC	DP timing signal
	2	DPRDY	O	0/3.3 V DC	DP ready signal
	3	HPSW	O	0/3.3 V DC	HPSW: On/Off
	4	DPEND	O	0/3.3 V DC	DP end signal
	5	+12V	O	12 V DC	12 V DC power output to ISCPWB
	6	DPSEL	I	0/3.3 V DC	DP select signal
	7	+12V	O	12 V DC	12 V DC power output to ISCPWB
	8	DPSDI	I	0/3.3 V DC (pulse)	Serial communication data signal
	9	+5V	I	5 V DC	5 V DC power input from ISCPWB
	10	DPCLK	I	0/3.3 V DC (pulse)	DP clock signal
	11	FANREM	I	0/3.3 V DC	SFM: On/Off
	12	DPSDO	O	0/3.3 V DC (pulse)	Serial communication data signal
	13	SM_FR	I	0/3.3 V DC (pulse)	SM control signal
	14	DP_CO	O	0/3.3 V DC	DP open signal
	15	GND	-	-	Ground
	16	GND	-	-	Ground
	17	SMTVREF	I	0/3.3 V DC (pulse)	SM control signal
	18	GND	-	-	Ground
	19	SM_STP	I	0/3.3 V DC (pulse)	SM control signal
	20	INV_CLK	I	0/3.3 V DC (pulse)	INPWB clock signal
	21	SM_STB	I	0/3.3 V DC (pulse)	SM control signal
	22	COSW1	O	0/3.3 V DC	ODSW: On/Off
	23	MON24V	O	0/3.3 V DC	Control signal
	24	INVTH	O	0/3.3 V DC	EL control signal
	25	SLAMP	I	0/3.3 V DC	EL: On/Off
	26	NC	-	-	Not used
YC3 Connected to the scan- ner fan motor	1	+24V	O	24 V DC	24 V DC power output to SFM
	2	FANREM	O	0/24 V DC	SFM: On/Off
YC4 Connected to the origi- nal detec- tion switch	1	SGND	-	-	Ground
	2	COSW1	I	0/3.3 V DC	ODSW: On/Off
	3	+5V	O	5 V DC	24 V DC power output to ODSW
	4	NC	-	-	Not used
YC5 Connected to the inverter PWB	1	INV_CL	O	0/3.3 V DC (pulse)	INPWB clock signal
	2	INVTH	I	0/3.3 V DC	EL control signal
	3	PGND	-	-	Ground
	4	SLAMPO	O	0/3.3 V DC	EL: On/Off
	5	+24V	O	24 V DC	24 V DC power output to INPWB

Connector	Pin No.	Signal	I/O	Voltage	Description
YC6 Connected to the DP	1	DPCLK	O	0/3.3 V DC (pulse)	DP clock signal
	2	DPSDO	I	0/3.3 V DC (pulse)	Serial communication data signal
	3	DPSDI	O	0/3.3 V DC (pulse)	Serial communication data signal
	4	DPSEL	O	0/3.3 V DC	DP select signal
	5	DPEND	I	0/3.3 V DC	DP end signal
	6	DPRDY	I	0/3.3 V DC	DP ready signal
	7	DPTMG	I	0/3.3 V DC	DP timing signal
	8	DP CO	I	0/3.3 V DC	DP open signal
	9	NC	-	-	Not used
	10	NC	-	-	Not used
	11	GND	-	-	Ground
	12	GND	-	-	Ground
	13	GND	-	-	Ground
	14	GND	-	-	Ground
YC7 Connected to the scanner motor	1	SMOT BN	O	0/24 V DC (pulse)	SM drive control signal
	2	SMOT AN	O	0/24 V DC (pulse)	SM drive control signal
	3	SMOT BP	O	0/24 V DC (pulse)	SM drive control signal
	4	SMOT AP	O	0/24 V DC (pulse)	SM drive control signal
YC8 Connected to the home position switch	1	SGND	-	-	Ground
	2	HPSW	I	0/3.3 V DC	HPSW: On/Off
	3	+5V	O	5 V DC	5 V DC power output to HPSW

2-3-5 Main operation PWB




Figure 2-3-5 Main operation PWB silk-screen diagram

Connector	Pin No.	Signal	I/O	Voltage	Description
YC1 Connected to the touch panel	1	TOP Y+	I	Analog	Touch panel Y+ position signal
	2	LEFT X+	I	Analog	Touch panel X+ position signal
	3	BOT Y-	I	Analog	Touch panel Y- position signal
	4	RIGHT X-	I	Analog	Touch panel X- position signal
YC2 Connected to the LCD	1	SGND	-	-	Ground
	2	SGND	-	-	Ground
	3	B5(MSB)	O	0/3.3 V DC	LCD control signal
	4	B4	O	0/3.3 V DC	LCD control signal
	5	B3	O	0/3.3 V DC	LCD control signal
	6	SGND	-	-	Ground
	7	B2	O	0/3.3 V DC	LCD control signal
	8	B1	O	0/3.3 V DC	LCD control signal
	9	B0(LSB)	O	0/3.3 V DC	LCD control signal
	10	SGND	-	-	Ground
	11	G5(MSB)	O	0/3.3 V DC	LCD control signal
	12	G4	O	0/3.3 V DC	LCD control signal
	13	G3	O	0/3.3 V DC	LCD control signal
	14	SGND	-	-	Ground
	15	G2	O	0/3.3 V DC	LCD control signal
	16	G1	O	0/3.3 V DC	LCD control signal
	17	G0(LSB)	O	0/3.3 V DC	LCD control signal
	18	SGND	-	-	Ground
	19	R5(MSB)	O	0/3.3 V DC	LCD control signal
	20	R4	O	0/3.3 V DC	LCD control signal
	21	R3	O	0/3.3 V DC	LCD control signal
	22	SGND	-	-	Ground
	23	R2	O	0/3.3 V DC	LCD control signal
	24	R1	O	0/3.3 V DC	LCD control signal
	25	R0(LSB)	O	0/3.3 V DC	LCD control signal
	26	SGND	-	-	Ground
	27	DE	O	0/3.3 V DC	LCD control signal
	28	SGND	-	-	Ground
	29	L_R	O	0/3.3 V DC	LCD control signal
	30	U_D	O	0/3.3 V DC	LCD control signal
	31	SGND	-	-	Ground
	32	DCLK	O	0/3.3 V DC (pulse)	LCD clock signal
	33	NC	-	-	Not used
	34	SGND	-	-	Ground
	35	+5V	O	5 V DC	5 V DC power output to LCD
	36	+5V	O	5 V DC	5 V DC power output to LCD
	37	+5V	O	5 V DC	5 V DC power output to LCD
	38	+5V	O	5 V DC	5 V DC power output to LCD
39	SGND	-	-	Ground	
40	SGND	-	-	Ground	

Connector	Pin No.	Signal	I/O	Voltage	Description
YC3 Connected to the main PWB	1	VBUS	I	5 V DC	5 V DC power input
	2	DN	I/O	-	USB data signal
	3	DP	I/O	-	USB data signal
	4	ID	-	-	Not used
	5	GND	-	-	Ground
YC4 Connected to the main PWB	1	SUPND POWER	I	5 V DC	5 V DC power input from MPWB
	2	GND	-	-	Ground
	3	PH KEY	O	0/5 V DC	Power key: On/Off
	4	GND	-	-	Ground
	5	AUDIO	I	Analog	Audio output signal
	6	SUPND_ENTR	I	0/3.3 V DC	Energy save mode control signal
	7	+24V_DOWN	I	0/3.3 V DC	24 V DC down signal
	8	SW_FOOTN	-	-	Not used
	9	HOLDPANEL	I	0/3.3 V DC	Operation panel displaying enable signal
	10	PANEL_RESET	I	0/3.3 V DC	MPWB reset signal
	11	S_LED1	I	0/3.3 V DC	Operation panel LED display signal
	12	S_LED0	I	0/3.3 V DC	Operation panel LED display signal
	13	PANEL_STATU S	O	0/3.3 V DC	Operation panel status signal
YC6 Connected to the LCD inverter PWB	1	GND	-	-	Ground
	2	+12V	O	12 V DC	12 V DC power output to LINPWB
	3	LCDBKLT	O	0/3.3 V DC	LCD back light: On/Off
	4	ADJUST	O	Analog	LCD back light brightness adjustment signal
	5	GND	-	-	Ground
YC7 Connected to the right operation PWB	1	KEY0	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 0
	2	KEY1	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 1
	3	KEY2	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 2
	4	KEY3	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 3
	5	KEY4	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 4
	6	SCAN0	O	0/3.3 V DC (pulse)	Scan signal 0
	7	SCAN1	O	0/3.3 V DC (pulse)	Scan signal 1
	8	SCAN2	O	0/3.3 V DC (pulse)	Scan signal 2
	9	SCAN3	O	0/3.3 V DC (pulse)	Scan signal 3
	10	SCAN6	O	0/3.3 V DC (pulse)	Scan signal 6
	11	LED0	O	0/3.3 V DC (pulse)	Operation panel LED display drive signal 0
	12	LED1	O	0/3.3 V DC (pulse)	Operation panel LED display drive signal 1
	13	PH KEY	I	0/5 V DC	Power key: On/Off
	14	SUPND POWER	O	5 V DC	5 V DC power output to OPWB-R
	15	GND	-	-	Ground

Connector	Pin No.	Signal	I/O	Voltage	Description
YC8 Connected to the left operation PWB	1	SCAN6	O	0/3.3 V DC (pulse)	Scan signal 6
	2	KEY5	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 5
	3	KEY6	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 6
	4	KEY7	I	0/3.3 V DC (pulse)	Operation panel key scan return signal 7
	5	SCAN0	O	0/3.3 V DC (pulse)	Scan signal 0
	6	SCAN1	O	0/3.3 V DC (pulse)	Scan signal 1
	7	SCAN2	O	0/3.3 V DC (pulse)	Scan signal 2
	8	SCAN3	O	0/3.3 V DC (pulse)	Scan signal 3
	9	LED2	O	0/3.3 V DC (pulse)	Operation panel LED display drive signal 2
	10	LED3	O	0/3.3 V DC (pulse)	Operation panel LED display drive signal 3
	11	LED4	O	0/3.3 V DC (pulse)	Operation panel LED display drive signal 4
	12	GND	-	-	Ground
YC9 Connected to the upper operation PWB	1	SCAN4	O	0/3.3 V DC (pulse)	Scan signal 4
	2	SCAN5	O	0/3.3 V DC (pulse)	Scan signal 5
	3	LED5	O	0/3.3 V DC (pulse)	Operation panel LED display drive signal 5
	4	LED6	O	0/3.3 V DC (pulse)	Operation panel LED display drive signal 6
	5	LED7	O	0/3.3 V DC (pulse)	Operation panel LED display drive signal 7
	6	S_LED0	O	0/5 V DC	Operation panel LED display drive signal 0
	7	S_LED1	O	0/5 V DC	Operation panel LED display drive signal 1
	8	GND	-	-	Ground
YC10 Connected to the front operation PWB	1	SCAN5	O	0/3.3 V DC (pulse)	Scan signal 5
	2	LED5	O	0/3.3 V DC (pulse)	Operation panel LED display drive signal 5
	3	LED6	O	0/3.3 V DC (pulse)	Operation panel LED display drive signal 6
	4	S_LED1	O	0/5 V DC	Operation panel LED display drive signal 1
	5	GND	-	-	Ground
YC11 Connected to the speaker	1	VO2	O	Analog	Speaker sound signal (+)
	2	VO1	O	Analog	Speaker sound signal (-)
YC15 Connected to the power source PWB	1	GND	-	-	Ground
	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	+5V	I	5 V DC	5 V DC power input from PSPWB
	5	+5V	I	5 V DC	5 V DC power input from PSPWB
	6	+12V	I	12 V DC	12 V DC power input from PSPWB

This page is intentionally left blank.

Maintenance parts list

Maintenance part name		Part No.	Alternative part No.
Name used in service manual	Name used in parts list		
Paper feed pulley	PULLEY,PAPER FEED	2AR07220	-
Separation pulley	PULLEY,SEPARATION	2AR07230	-
Forwarding pulley	PULLEY FEED A	2BJ06010	-
MP paper feed pulley	UPPER PULLEY,BYPASS	61706770	-
MP separation pulley	PULLEY,SEPARATION	2AR07230	-
MP forwarding pulley	PULLEY FEED A	2BJ06010	-
MP feed roller 1	PARTS ROLLER2 BYPASSFEED SP	302KS94160	2KS94160
MP feed roller 2	PARTS ROLLER4 BYPASSFEED SP	302KS94170	2KS94170
MP feed pulley	RIGHT PULLEY,FEED	33906660	-
Left registration roller	UPPER ROLLER REGIST	302KS06010	2KS06010
Right registration roller	RIGHT ROLLER REGIST	302FG06211	2FG06211
Feed pulley	PULLEY FEED	2BL16080	-
Feed roller 1	PULLEY MIDDLE FEED A	302GR06010	2GR06010
Feed roller 1	PULLEY MIDDLE FEED B	302GR06020	2GR06020
Feed roller 2	PARTS ROLLER B FEED SP	302KS94140	2KS94140
Feed roller 3	PARTS ROLLER C FEED SP	302KS94150	2KS94150
Registration switch	SWITCH REGISTRATION	2FG27110	-
Left registration cleaner	UNDER CLEANER REGIST	2BL07950	-
Registration guide	GUIDE REGIST F	2BL16130	-
Right registration cleaner	PARTS,REGISTRATION CLEAN	2BL93450	-
Transfer guide	PARTS,GUIDE TRANSFER	302GR94480	2GR94480
Laser scanner unit	PARTS LSU	302KS93040	2KS93040
Slit glass	PARTS CONTACT GLASS ADF ASSY	302H793480	2H793480
Contact glass	PARTS CONTACT GLASS (M) ASSY SP	302KS94250	2KS94250
	PARTS CONTACT GLASS (I) ASSY SP	302KS94260	2KS94260
Mirror 1	MIRROR A	2FB12140	-
Mirror 2 and mirror 3	MIRROR B	2FB12180	-
Lens	-	-	-
Reflector	REFRECTOR SCANNER	302GR17250	2GR17250
Exposure lamp	PARTS LAMP SCANNER	302H794260	2H794260
Optical rail F	-	-	-
Optical rail R	-	-	-
Original size sensor	SENSOR ORIGINAL	2C927090	-
Transfer roller unit	TR-710	302GR93281	2GR93281
Developing unit	DV-715	302GR93034	2GR93034
Drum unit	DK-716	302GR93042	2GR93042
Main charger unit	MC-710	302GR93071	2GR93071
Drum separation claw	PARTS CLAW SEPARATION ASSY	302GR93190	2GR93190
Fuser unit	PARTS FUSER 120 UNIT	302KS93010	2KS93010
Fuser unit	PARTS FUSER 230 UNIT	302KS93020	2KS93020
Heat roller	PARTS,ROLLER HEAT SP	302GR94270	2GR94270
Heat roller separation claw	CLAW HEAT ROLLER	2BL20080	-
Press roller	PARTS,ROLLER PRESS SP	302GR94280	2GR94280
Press roller separation claw	CLAW PRESS ROLLER	302BL20351	2BL20351

Maintenance part name		Part No.	Alternative part No.
Name used in service manual	Name used in parts list		
Upper duplex feed roller	ROLLER DU FEED UP	2BL07020	-
Lower duplex feed roller	ROLLER DU FEED LOW	2BL07030	-
Duplex feed pulley	PULLEY DU	2BL07040	-
Eject roller	PARTS ROLLER EXIT SP	302KS94180	2KS94180
Switchback roller	PARTS ROLLER FEED SHIFT SP	302KS94200	2KS94200
Eject pulley	PULLEY EXIT C	2BL21520	-
Eject pulley	PULLEY EXIT	302GR28060	2GR28060
Switchback pulley	PULLEY FEED SHIFT	302GR28150	2GR28150
Dust filter 1	PARTS FILTER DUST F1 ASSY	302GR94431	2GR94431
Dust filter 2	PARTS FILTER DUST F2 ASSY	302GR94441	2GR94441

Maintenance kits

Maintenance part name		Part No.	Alternative part No.
Name used in service manual	Name used in parts list		
Maintenance kit	MK-726 (120 V specifications)	1702KR7US0	072KR7US
	MK-726 (220 - 240 V specifications)	1702KR8NLO	072KR8NL
Paper feed pulley	PULLEY,PAPER FEED	-	-
Separation pulley	PULLEY,SEPARATION	-	-
Forwarding pulley	PULLEY FEED A	-	-
Left registration cleaner	UNDER CLEANER REGIST	-	-
Registration guide	GUIDE REGIST F	-	-
Right registration cleaner	PARTS,REGISTRATION CLEAN	-	-
Transfer roller unit	TR-710	-	-
Transfer guide	PARTS,GUIDE TRANSFER	-	-
Developing unit	DLP UNIT	-	-
Drum unit	DK-716	-	-
Fuser unit	PARTS FUSER 120 UNIT	-	-
	PARTS FUSER 230 UNIT	-	-
MP paper feed pulley	UPPER PULLEY,BYPASS	-	-
Cassette pad	PAD,CASSETTE	-	-

Periodic maintenance procedures

Section	Maintenance part/location	User call	500K	Points and cautions	Page
Test copy and test print	Perform at the maximum copy size	Test copy	Test copy		



Section	Maintenance part/location	User call	500K	Points and cautions	Page
Paper feed section	Paper feed pulley	Check Clean	Replace	Clean with alcohol. Replace after feeding 500,000 sheets.	P.1-5-3
	Separation pulley	Check Clean	Replace	Clean with alcohol. Replace after feeding 500,000 sheets.	P.1-5-3
	Forwarding pulley	Check Clean	Replace	Clean with alcohol. Replace after feeding 500,000 sheets.	P.1-5-3
	MP paper feed pulley	Check Clean	Replace	Clean with alcohol. Replace after feeding 500,000 sheets.	P.1-5-5
	MP separation pulley	Check Clean	Replace	Clean with alcohol. Replace after feeding 500,000 sheets.	P.1-5-5
	MP forwarding pulley	Check Clean	Replace	Clean with alcohol. Replace after feeding 500,000 sheets.	P.1-5-5
	MP feed roller 1	Check Clean	Clean	Clean with alcohol.	
	MP feed pulley	Check Clean	Clean	Clean with alcohol.	
	MP feed roller 2	Check Clean	Clean	Clean with alcohol.	
	Left registration roller	Check Clean	Clean	Clean with alcohol.	
	Right registration roller	Check Clean	Clean	Clean with alcohol.	
	Feed pulley	Check Clean	Clean	Clean with alcohol.	
	Feed roller 1	Check Clean	Clean	Clean with alcohol.	
	Feed roller 2	Check Clean	Clean	Clean with alcohol.	
	Feed roller 3	Check Clean	Clean	Clean with alcohol.	
	Registration switch	Check Clean	Clean	Clean with a dry cloth.	
	Left registration cleaner	Clean	Replace	Vacuum. Replace after feeding 500,000 sheets.	P.1-5-10
	Registration guide	-	Replace	Replace after feeding 500,000 sheets.	
Right registration cleaner	Clean	Replace	Vacuum. Replace after feeding 500,000 sheets.	P.1-5-10	
Transfer guide	Check Clean	Replace	Clean with alcohol. Replace after feeding 500,000 sheets.		



Section	Maintenance part/location	User call	500K	Points and cautions	Page
Optical section	Laser scanner unit	Check Clean	-	Clean the shield glass with a dry cloth.	P.1-5-22
	Contact glass	Clean	Clean	Clean with alcohol and then a dry cloth.	
	Slit glass	Clean	Clean	Clean with a dry cloth or alcohol (do not clean with a wet cloth).	
	Mirror 1	Clean	-	Clean with alcohol and then a dry cloth only if vertical black lines appear on the copy image.	
	Mirror 2 and mirror 3	Clean	-	Clean with alcohol and then a dry cloth only if vertical black lines appear on the copy image.	
	Lens	Clean	-	Clean with a dry cloth only if vertical black lines appear on the copy image.	
	Reflector	Clean	-	Clean with a dry cloth only if vertical black lines appear on the copy image.	
	Exposure lamp	Check Replace	-	Replace if an image problem occurs.	P.1-5-12
	Optical rail	Grease	-	Check noise and shifting and then apply scanner rail grease EM-50L.	
	Original size sensor	Check Clean	-	Clean the sensor emitter and sensor receiver with alcohol or a dry cloth only if there is a problem.	



Section	Maintenance part/location	User call	500K	Points and cautions	Page
Transfer/separation sections	Transfer roller unit	Clean Replace	Replace	Clean with a cleaning brush or alcohol. Replace after feeding 500,000 sheets.	P.1-5-29



Section	Maintenance part/location	User call	500K	Points and cautions	Page
Developing section	Developing unit	Check Replace	Replace	Replace after feeding 500,000 sheets.	P.1-5-28



Section	Maintenance part/location	User call	500K	Points and cautions	Page
Drum section	Drum unit	Check Replace	Replace	Replace after feeding 500,000 sheets.	P.1-5-25
	Main charger unit	Clean	-	Clean with a wet cloth and then a dry cloth.	P.1-5-26
	Drum separation claw	Check Replace	-	Replace if the leading edge of the claws are damaged.	P.1-5-27



Section	Maintenance part/location	User call	500K	Points and cautions	Page
Fuser section	Fuser unit	Check Replace	Replace	Replace after feeding 500,000 sheets.	P.1-5-30
	Heat roller	Check Replace	-	Check and replace when user call occurs.	P.1-5-34
	Heat roller separation claw	Check Replace	Clean	Clean with alcohol. Check and replace when user call occurs.	P.1-5-31
	Press roller	Check Replace	-	Check and replace when user call occurs.	P.1-5-32
	Press roller separation claw	Check Replace	Clean	Clean with alcohol. Check and replace when user call occurs.	



Section	Maintenance part/location	User call	500K	Points and cautions	Page
Duplex section	Upper duplex feed roller	Check Clean	Clean	Clean with alcohol.	
	Lower duplex feed roller	Check Clean	Clean	Clean with alcohol.	
	Duplex feed pulley	Check	Clean	Clean with alcohol.	



Section	Maintenance part/location	User call	500K	Points and cautions	Page
Eject section	Eject roller	Check Clean	Clean	Clean with alcohol.	
	Eject pulley	Check Clean	Clean	Clean with alcohol.	
	Switchback roller	Check Clean	Clean	Clean with alcohol.	
	Switchback pulley	Check Clean	Clean	Clean with alcohol.	



















Section	Maintenance part/location	User call	500K	Points and cautions	Page
Covers	Covers	Clean	Clean	Clean with alcohol or a dry cloth.	
	Original platen	Clean	Clean	Clean with alcohol or a dry cloth.	



Section	Maintenance part/location	User call	500K	Points and cautions	Page
Other	Dust filter 1	Clean	Clean	Vacuum.	P.1-5-38
	Dust filter 2	Clean	Clean	Vacuum.	P.1-5-38
	Gears	-	Check Clean	Check noise and then apply grease EM-50L.	
	Bushes	-	Check Clean	Check noise and then apply grease EM-50L.	
	Paper conveying section	Clean	Clean	Clean with alcohol or a dry cloth.	
	Image quality	Check Adjust	Check Adjust		

Chart of image adjustment procedures

Adjusting order	Item	Image	Description	Maintenance mode		Original	Page	Remarks
				Item No.	Mode			
1	Adjusting the magnification in the main scanning direction (printing adjustment)		Polygon motor speed adjustment	U053	POLYGON MOTOR	U053 test pattern	P.1-3-25	
2	Adjusting the magnification in the auxiliary scanning direction (printing adjustment)		Drive motor speed adjustment	U053	TMAIN MOTOR	U053 test pattern	P.1-3-25	
3	Adjusting the center line of the MP tray (printing adjustment)		Adjusting the LSU print start timing	U034	LSUOUT LEFT (MPT)	U034 test pattern	P.1-3-23	To make an adjustment for duplex copying, select LSUOUT LEFT (DUP).
4	Adjusting the center line of the cassettes (printing adjustment)		Adjusting the LSU print start timing	U034	LSUOUT LEFT (CAS 1) LSUOUT LEFT (CAS 2) LSUOUT LEFT (CAS 3) LSUOUT LEFT (CAS 4)	U034 test pattern	P.1-3-23	Cassette 1: select Center (Feed 1) Cassette 2: select Center (Feed 2) Cassette 3: select Center (Feed 3) Cassette 4: select Center (Feed 4)
5	Adjusting the leading edge registration of the MP tray (printing adjustment)		Registration motor turning on timing (secondary paper feed start timing)	U034	LSUOUT TOP MPT	U034 test pattern	P.1-3-22	To make an adjustment for duplex copying, select LSUOUT TOP DUP.
6	Adjusting the leading edge registration of the cassette (printing adjustment)		Registration motor turning on timing (secondary paper feed start timing)	U034	LSUOUT TOP CAS	U034 test pattern	P.1-3-22	
7	Adjusting the leading edge margin (printing adjustment)		LSU illumination start timing	U402	LESD	U402 test pattern	P.1-3-81	
8	Adjusting the trailing edge margin (printing adjustment)		LSU illumination end timing	U402	TRAIL	U402 test pattern	P.1-3-81	
9	Adjusting the left and right margins (printing adjustment)		LSU illumination start/end timing	U402	A/C	U402 test pattern	P.1-3-81	
10	Adjusting magnification of the scanner in the main scanning direction (scanning adjustment)		Data processing	U065	Y SCAN ZOOM	Test chart	P.1-3-28	No adjustment for copying using the DP.

Adjusting order	Item	Image	Description	Maintenance mode		Original	Page	Remarks
				Item No.	Mode			
11	Adjusting magnification of the scanner in the auxiliary scanning direction (scanning adjustment)		Original scanning speed	U065	X SCAN ZOOM	Test chart	P.1-3-28	U065: For copying an original placed on the contact glass U070: For copying originals from the DP. To make an adjustment for duplex copying, select MOTOR ADJ (BACK) or X SCAN ZOOM (CIS).
				U070	MOTOR ADJ (FRONT) MOTOR ADJ (BACK) X SCAN ZOOM (CIS)		P.1-3-32	
12	Adjusting the center line (scanning adjustment)		Adjusting the original scan data (image adjustment)	U067	FRONT ROTATE	Test chart	P.1-3-30	U067: For copying an original placed on the contact glass To make an adjustment for rotate copying, select ROTATE. U072: For copying originals from the DP. To make an adjustment for duplex copying, select BACK or CIS.
				U072	FRONT BACK CIS		P.1-3-36	
13	Adjusting the leading edge registration (scanning adjustment)		Original scan start timing	U066	FRONT TAIL	Test chart	P.1-3-29	U066: For copying an original placed on the contact glass To make an adjustment for trailing edge registration, select TAIL. U071: For copying originals from the DP. To make an adjustment for duplex copying, select BACK HEAD or HEAD (CIS).
				U071	FRONT HEAD BACK HEAD HEAD (CIS)		P.1-3-34	
14	Adjusting the leading edge margin (scanning adjustment)		Adjusting the original scan data (image adjustment)	U403	B MARGIN	Test chart	P.1-3-82	U403: For copying an original placed on the contact glass U404: For copying originals from the DP.
				U404	B MARGIN		P.1-3-83	
15	Adjusting the trailing edge margin (scanning adjustment)		Adjusting the original scan data (image adjustment)	U403	D MARGIN	Test chart	P.1-3-82	U403: For copying an original placed on the contact glass U404: For copying originals from the DP.
				U404	D MARGIN		P.1-3-83	
16	Adjusting the left and right margins (scanning adjustment)		Adjusting the original scan data (image adjustment)	U403	A MARGIN C MARGIN	Test chart	P.1-3-82	U403: For copying an original placed on the contact glass U404: For copying originals from the DP.
				U404	A MARGIN C MARGIN		P.1-3-83	

When maintenance item U411 (Automatic adjustment in the scanner) is run using the specified original (P/N 302FZ56990),

the following adjustments are automatically made:

Adjusting the scanner magnification (U065)

Adjusting the scanner leading edge registration (U066)

Adjusting the scanner center line (U067)

When maintenance item U411 (Automatic adjustment in the DP) is run using the specified original (P/N 302AC68243),

the following adjustments are automatically made:

Adjusting the DP magnification (U070)


Adjusting the DP leading edge registration (U071)

Adjusting the DP center line (U072)


Image quality

Item	Specifications
100% magnification	Machine: $\pm 0.8\%$ Using DP: $\pm 1.5\%$
Enlargement/reduction	Machine: $\pm 1.0\%$ Using DP: $\pm 1.5\%$
Lateral squareness	Machine: ± 1.5 mm/375 mm Using DP: ± 3.0 mm/375 mm
Leading edge registration	Cassette: ± 2.5 mm MP tray: ± 2.5 mm Duplex: ± 2.5 mm
Skewed paper feed (left-right difference)	Cassette: 1.5 mm or less MP tray: 1.5 mm or less Duplex: 2.0 mm or less
Lateral image shifting	Cassette: ± 2.0 mm MP tray: ± 2.0 mm Duplex: ± 3.0 mm


Wiring diagram No.1




Wiring diagram No.2



Wiring diagram No.3



Wiring diagram No.4



Wiring diagram No.5

