

OKI[®]

B4200

MONOCHROME LED PAGE PRINTER

Maintenance Manual

Notice

Disclaimer

Every effort has been made to ensure that the information in this document is complete, accurate, and up-to-date. Oki Data assumes no responsibility for the results of errors or omissions beyond its control. Oki Data also cannot guarantee that changes in software and equipment made by other manufacturers and referred to in this document will not affect the applicability of the information in it. Mention of software products manufactured by other companies does not necessarily constitute endorsement by Oki Data.

Windows and Windows NT are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

ZIP Code is a registered trademark of the United States Postal Service.

Copyright Information

Copyright 2003 by Oki Data. All Rights Reserved
First Edition: April, 2003
Written and produced by the Oki Data Training and Publications Department.

Contact Information

Please address any comments on this publication to:

Mailing Address

Oki Data Americas
Training and Publications Department
2000 Bishops Gate Boulevard
Mount Laurel, NJ 08054-4620

e-Mail Address

pubs@okidata.com

Web Site

Please visit Oki Data's multilingual web site at:
<http://www.okidata.com>

Trademark Information

OKI and OKI DATA are registered trademarks of Oki Electric Industry Company, Ltd.
OKIDATA and OKIPAGE are registered trademarks of Oki Electric Industry Company, Ltd.
OKICOLOR is a trademark of Oki Electric Industry Co., Ltd.
OKI and OkiLAN are registered trademarks of Oki Electric Industry Company, Ltd.
Adobe, ATM, PostScript and Type Manager are trademarks of Adobe Systems, Inc. which may be registered in certain jurisdictions.
American Express is a registered trademark of American Express Co.
Energy Star is a registered trademark of the United States Environmental Protection Agency.
Touch-Tone is a registered trademark of American Telephone and Telegraph.

Preface

This Maintenance Manual describes the field maintenance methods for B4200 Monochrome LED Page Printers.

This manual is written for use by service personnel. Please note that you should refer to the User's Guide for detailed handling and operating methods of the equipment.

Table of Contents

Notice	2
---------------------	----------

Preface	3
----------------------	----------

Table of Contents	4
--------------------------------	----------

Configuration	6
----------------------------	----------

System Configuration	6
Printer Configuration	7
Optional Configuration	8
Specification.	9
Safety Standards.	11
Certification Label	11
Warning Label	11
Warning/Caution Marking	12

Parts Replacement	13
--------------------------------	-----------

Caution for Parts Replacement.	13
Service Tools.....	13
Parts Layout	14
Lower Base Unit.	15
Upper cover unit	16
Base Unit	17
How to Change Parts	18
Upper Cover Assy	19
LED Head.	20
Operator Panel Assy	21
Lower Base Unit.	22
Pulse Motor (Main/Drum)	23
Pulse Motor (Registration)	24
Face Up Stacker Assy.	25
Eject Roller Assy	26
Motor Assy	27
Hopping Roller Shaft Assy.	28
Stacker Cover Assy	29
Registration Roller	30
Roller Transfer Assy.	31
Fusing Unit	32
Back-up Roller	33
Sensor Plate (Inlet)	34
Sensor Plate (Outlet), Sensor Wire Assy	35
Manual Feed Guide Assy	36
Sensor Plate (Paper Supply)	37
GRG-PCB.	38
Power Supply Board and High Voltage/Sensor Unit	39
Cassette Guide L Assy	40
Cassette Guide R Assy	41

Adjustment	42
-------------------------	-----------

Adjustment Function	42
-------------------------------	----

Status Monitor)	42
Adjustment When Replacing a Part	42
Uploading/Downloading EEPROM data	42

Periodical Maintenance	43
-------------------------------------	-----------

Periodical Replacement Parts	43
Cleaning	43
Cleaning of LED Lens Array	43
Cleaning Page Function	44

Troubleshooting Procedures	45
---	-----------

Troubleshooting Tips	45
Points to Check before Correcting Image Problems	45
Tips for Correcting Image Problems.	45
Preparation for Troubleshooting	45
Operator Panel Display	45
LED indicator	45
LED Function Table	46
Troubleshooting Flow	47
Status Monitor Message List	48
Status Message Troubleshooting.....	50
Image Troubleshooting	58

Wiring Diagram	67
-----------------------------	-----------

Interconnect Signal Diagram.	67
PCB Layout and Connector Signal List	68
Main Control Board (GRG-PCB)	68
Power Supply/Sensor Board	69
FAN Connector Pin Assignment (To fan motor).....	69
DM Connector Pin Assignment (To main/drum motor)...	69
RM Connector Pin Assignment (To registration motor)...	70
HEAD1 Connector Pin Assignment (To LED head).....	71
HEAD2 Connector Pin Assignment (To LED head).....	71
PANEL Connector Pin Assignment (To operator panel)..	72
ENVELOPE Connector Pin Assignment (To option feeder I/F)	72
2NDTRAY Connector Pin Assignment (To option tray I/F)	72
POWER Connector Pin Assignment (To power supply/sensor board).....	73
CENT Connector Pin Assignment (To Centro parallel I/F)74	
USB Connector Pin Assignment To USB I/F).....	75
OPTION Connector Pin Assignment (To option RAM / RS232C or Network).....	76
Resistance Check	77

Parts List	79
-------------------------	-----------

Appendix A RS-232C Serial Interface (op-	
---	--

tion)..... 84

Appendix B Centronics Parallel Interface86

Appendix C Universal Serial Bus (USB) ... 90

Universal Serial Bus Specification Revision 2.0
full speed compliance. 90

Appendix D High Capacity Second Paper Feeder..... 94

Outline 94
Function 94
 Paper Types 94
 Weight and Thickness 94
External View and Component Names 94
Mechanism Description 94
 General Mechanism 94
 Hopper Mechanism 95
Parts Replacement 95
 Precautions Concerning Parts Replacement. 95
 Service Tools..... 95
 Parts Layout 97
 Parts Replacement Methods 98
 Stepping Motor (Hopping) 99
 GRT-PCB 101
 Hopping Roller Shaft Assy and One-way Clutch Gear... 101
Troubleshooting 102
 Troubleshooting Tips 102
 Preparation for Troubleshooting. 102
 Operator Panel Display. 102
 Troubleshooting Method 102
 LED Status Message List 102
 JAM Error Troubleshooting Flowchart..... 104
Connection Diagram 105
 Interconnection Diagram 105
 PCB Layout 105
Parts List. 106
 High Capacity Paper Feeder List 107
 2nd Tray Parts List 111

Configuration

1. System Configuration

B4200 consists of control and engine blocks in the standard configuration, as shown in Figure 1-1. In addition, the options marked with asterisk (*) are available.




Figure 1-1

2. Printer Configuration

The printer unit consists of the following hardware components:

- Electrophotographic Processor
- Paper Feeder
- Controller
- Operator Panel
- Power Supply Unit

The printer unit configuration is shown in Figure 1-2.





Figure 1-2


3. Optional Configuration

The options shown below are available for use with B4200. These are available separately from the printer unit.


- High Capacity Second Paper Feeder




- RS-232C Serial Interface Board



- SDRAM DIMM




(i) 16MB




(ii) 32MB

- Flash DIMM



(i) 8MB




(ii) 16MB

11	Power Consumption	120VAC	230VAC	
		Peak	: Approx. 700W	Approx. 700W
		Typical operation	: Approx. 340W	Approx. 350W
		Idle	: Approx. 66W	Approx. 68W
		Power save mode	: Approx. 8W	Approx. 9W
		(Without option)		
Power save mode	: Approx. 12W	Approx. 13W		
	(With full option)			

12		In Operation	Power Off Mode	During Storage	Unit
	Temperature	50-90 (10-32)	32-110 (0-43)	14-110 (-10-43)	F (C)
	Humidity	20-80	10-90	10-90	%RH
	Maximum wet bulb temperature	77 (77)	80.4 (26.8)	_____	F (C)
	Minimum difference between wet and dry bulb temperatures	35.6 (2)	35.6 (2)	_____	F (C)

- Storage conditions specified above apply to printers in packed condition.
- Temperature and humidity must be in the range where no condensation occurs.




13	Noise	During operation: 53 dB (A) or less Standby: 38 dB (A) or less Quiet mode: Background level
----	-------	---

14	Consumables	Image drum cartridge 25,000 (at continuous printing) 17,000 (3 page/job) without Power Save 11,000 (1 page/job) without Power Save 7,000 (1 page/job) with Power Save (Minimum)
----	-------------	--

5. Safety Standards

A. Certification Label


The safety certification label is affixed to the printer in the position described below.



B. Warning Label


The warning labels are affixed to the sections which may cause bodily injury.

Follow the instructions on warning labels during maintenance.



C. Warning/Caution Marking

The following warning and caution markings are made on the power supply/sensor board.



The heat sink and transformer core present a risk of electric shock. Test before touching. Circuits may still be live after fuses open.

Parts Replacement

This section explains the procedures for replacement of parts, assemblies, and units in the field. Only the disassembly procedures are explained here. For reassembly, reverse the disassembly procedure.

1. Caution for Parts Replacement


1. Before replacing parts, remove the AC cord and interface cable.

Remove the AC cord:

- a. Turn off (“O”) the power switch of the printer
- b. Disconnect the AC inlet plug of the AC cord from the AC receptacle.
- c. Disconnect the AC cord and interface cable from the printer.

Reconnect the printer:




- a. Connect the AC cord and interface cable to the printer.
- b. Connect the AC inlet plug to the AC receptacle.
- c. Turn on (“I”) the power switch of the printer.








2. Do not disassemble the printer as long as it is operating normally.
3. Do not remove parts which do not have to be touched; try to keep the disassembly to a minimum.
4. Use specified service tools.
5. When disassembling, follow the laid out sequences. Parts may be damaged if these sequences are not followed.
6. Since screws, collars and other small parts are likely to be lost, they should temporarily be attached to the original positions during disassembly.
7. When handling IC's such as microprocessors, ROMs and RAMs, or circuit boards, do not wear gloves that are likely to generate static electricity.
8. Do not place printed circuit boards directly on the equipment or floor.

Service Tools

The tools required for field replacement of printed circuit boards, assemblies, and units are listed below.


No.	Service Tools	Qty.	Application
1	 No. 1-100 Phillips screwdriver	1	2~2.5 mm screws
2	 No. 2-100 Phillips screwdriver	1	3~5 mm screws
3	 No. 3-100 screwdriver	1	

No.	Service Tools	Qty.	Application
4		1	
5		1	
6		1	
7		1	
8		1	Cleans LED Head


2. Parts Layout

This section explains the layout of main components of the equipment.


A. Lower Base Unit



B. Upper cover unit




C. Base Unit



3. How to Change Parts


This section explains how to change parts and assemblies listed in the disassembly diagram below. Within the parts replacement procedures, those parts below are RSPL parts.



A. Upper Cover Assy

1. With the power switch turned off, unplug the AC power cord from the outlet.
2. Disconnect the interface cable (1).
3. Press the button (2) on right side of the Upper cover and open the stacker cover assy (3).
4. Take out the image drum unit (4).
5. Remove one screw (5), and remove the I/F cover (6) from the back side of the printer.
6. Open the manual feed guide assy (7). Unlock the latches at two locations on the front side. Lift the front side of the upper cover (8) up and unlock the latches at two locations on the back side. Lift and remove the upper cover assy (8).


Note: When removing or reinstalling the upper cover, be careful not to get the motor cables tangled or caught.



B. LED Head

1. Press the button on right side of the upper cover and open the stacker cover assy (1).
2. Open the hook section on the left side of the head holder and remove the LED head (2).
3. Remove the head cable (3) from the head connector.


Note: Be sure not to touch directly or push on the SLA part of the LED head.



C. Operator Panel Assy


1. Unlock two latches on the upper cover from the rear side, lift the operator panel assy (1) from the back and remove it.
2. Remove the Sumi card (operator panel) (2) from the connector (CN1) (3).

Note: You can remove the operator panel assy while the upper cover installed on the unit. However, it is much easier to remove the panel assy after removal of upper cover.




D. Lower Base Unit

1. Remove the upper cover assy (see “Upper Cover Assy” on page 19).
2. Remove the operator panel assy (see “Operator Panel Assy” on page 21).
3. Remove the face up stacker assy (see “Face Up Stacker Assy” on page 25).
4. Remove the roller transfer assy (see “Roller Transfer Assy” on page 31).
5. Remove the connecting cables (2) and (3) of the pulse motors from the connectors (DM, RM) of the GRG-PCB (1).
6. Remove the LED head cables (4) from the connector (HEAD1).
7. Remove the Thermistor cable (5) from the connector (THERM).
8. Remove the connecting cable (8) of the heater from the connector (CN2).
9. Open the manual feed guide assy, remove seven screws (7), then remove the lower base unit (6).




E. Pulse Motor (Main/Drum)

1. Remove the upper cover assy (see “Upper Cover Assy” on page 19).
2. Remove the lower base unit (see “Lower Base Unit” on page 22).
3. Remove two screws (1) and remove the pulse motor (main/drum) (2) from the motor bracket (3).




View A




F. Pulse Motor (Registration)

1. Remove the upper cover assy (see “Upper Cover Assy” on page 19).
2. Remove the lower base unit (see “Lower Base Unit” on page 22).
3. Remove two screws (1) and remove the pulse motor (registration) (2) from the motor bracket (3).




View A




G. Face Up Stacker Assy

1. Remove the upper cover assy (see “Upper Cover Assy” on page 19).
2. Remove the operator panel assy (see “Operator Panel Assy” on page 21).
3. Remove the Sumi card (Operator panel cable) (1) off the latch section of face up stacker (2).
4. Remove three screws (3) and remove both the shield plate (4) and face up stacker (2) together.
5. Unlock the latches at two locations, and remove the face up stacker (2).




H. Eject Roller Assy

1. Remove the upper cover assy (see “Upper Cover Assy” on page 19).
2. Remove the operator panel assy (see “Operator Panel Assy” on page 21).
3. Remove the face up stacker assy (see “Face Up Stacker Assy” on page 25).
4. Remove the stacker cover assy (see “Stacker Cover Assy” on page 29).
5. Disengage the eject roller assy (1) from the lower base (2) by pressing the latch section of the eject roller assy (1) in the direction of the arrow shown below, and remove the eject roller assy (1).




I. Motor Assy

1. Remove the upper cover assy (see “Upper Cover Assy” on page 19).
2. Remove the operator panel assy (see “Operator Panel Assy” on page 21).
3. Remove the face up stacker assy (see “Face Up Stacker Assy” on page 25).
4. Remove the lower base unit (see “Lower Base Unit” on page 22).
5. Stand the lower base unit on its side as shown, and unlock two latches, then remove the motor assy (1).
6. Remove two screws (2) and remove the bracket-Motor-Sub (3) from the Motor bracket.



J. Hopping Roller Shaft Assy


1. Remove the upper cover (see “Upper Cover Assy” on page 19).
2. Remove the operator panel assy (see “Operator Panel Assy” on page 21).
3. Remove the face up stacker assy (see “Face Up Stacker Assy” on page 25).
4. Remove the lower base unit (see “Lower Base Unit” on page 22).
5. Remove the motor assy (see “Motor Assy” on page 27).
6. With the lower base unit (1) standing on its side, remove the one-way clutch gear (2) and the bearing (A) (3).
7. Remove the hopping roller shaft assy (4) (the bearing B (5) comes off, so be careful not to lose it).



K. Stacker Cover Assy


1. Remove the upper cover assy (see “Upper Cover Assy” on page 19).
2. Remove the operator panel assy (see “Operator Panel Assy” on page 21).
3. Remove the face up stacker assy (see “Face Up Stacker Assy” on page 25).
4. Remove the motor assy (see “Motor Assy” on page 27).
5. Remove the reset lever R (1).
6. Remove one screw, detach the reset spring (2) from the lower base unit (3), turn the reset lever L (4) in the direction of arrow A until it stops, and remove it in the direction of arrow B.
7. Unlock two latches of the lower base unit (3), then remove the stacker cover assy (5).

Note : When reinstalling the reset lever L (4), fit it onto the guide of the lower base unit (3), turn it in the direction of arrow C while pressing down the shaft of back up roller, and engage the reset lever L (4).




L. Registration Roller

1. Remove the upper cover (see 2.3.1).
2. Remove the operator panel assy (see 2.3.3).
3. Remove the face up stacker assy (see 2.3.7).
4. Remove the lower base unit (see 2.3.4).
5. Remove the motor assy (see 2.3.9).
6. Unlock the latch at the left side of the paper guide (R) (1) and remove the paper guide (R) (1).
7. With the lower base unit standing on its side, remove the one-way clutch gear (2) and the bearing (3).
8. Remove the Registration Gear by unlocking the latch of the Gear (4).
9. Remove the Registration Bearing L (5).
10. Press the registration roller (6) in the direction of arrow A and lift up the left side of it, then remove the registration roller Assy (7).
11. Pull out the registration roller Assy (7) in the direction of arrow B.
12. Remove the pressure roller Assy gear (8) by unlocking the latch of the gear (8).
13. Remove the bearing-Registration L (9) and bearing Registration R (10).
14. Remove the Spring A from the bearing (9, 10).



M. Roller Transfer Assy

1. With the power switch turned off, unplug the AC cord from the outlet.
2. Open the stacker cover.
3. Remove the spacer (1).
4. Release the roller transfer assy 2 by unlocking two latches of the bearing TR (never apply excessive force when unlocking the latch) and slide the roller transfer assy left to remove the gear from the bracket.
5. Lift the right side of the roller transfer assy (2), and shift it to the right side, then pull it out from the main unit (at this time, the bearings (3) of the left side and holder-TR (4) of the right side of the roller transfer assy (2) will also come off).




N. Fusing Unit

1. Remove the upper cover (see “Upper Cover Assy” on page 19).
2. Remove the operator panel assy (see “Operator Panel Assy” on page 21).
3. Remove the face up stacker assy (see “Face Up Stacker Assy” on page 25).
4. Remove the lower base unit (see “Lower Base Unit” on page 22).
5. Remove the stacker cover assy (see “Stacker Cover Assy” on page 29).
6. Remove the connecting cable (1) of the heater and connecting cable (2) of the thermistor from the hooks of the lower base.
7. Remove four screws (3), lift and remove the fusing unit (4).


Caution: Fusing unit may be hot. Use care when handling.

- Notes:
1. When reinstalling or removing the fusing unit, tighten or loosen the screws while holding the fusing unit assy (4) down with your hand (it is being pushed up by back up roller).
 2. When reinstalling the screws (3), be sure to direct the screws into preexisting thread and avoid damaging the threads.
 3. Do not apply excessive torque when tightening the screws (3).




O. Back-up Roller

1. Remove the fusing unit assy (see “Fusing Unit” on page 32).
2. Lift the left side of the back-up roller (1), and pull it out to the left side (at this time, two bearing Holders (back-up) (2) and the bias springs (back-up) (3) and the two ball-bearings (4), washer C (5) will also come off).




P. Sensor Plate (Inlet)

1. Remove the upper cover (see “Upper Cover Assy” on page 19).
2. Remove the operator panel assy (see “Operator Panel Assy” on page 21).
3. Remove the face up stacker assy (see “Face Up Stacker Assy” on page 25).
4. Remove the lower base unit (see “Lower Base Unit” on page 22).
5. Unlock the latch at the left side of the paper guide (R) (1) and remove the paper guide (R) (1).
6. Press the clamps of three sensor plates (inlet and paper) (2), and remove them by pressing them upward from the bottom.



Q. Sensor Plate (Outlet), Sensor Wire Assy



1. Remove the upper cover assy (see “Upper Cover Assy” on page 19).
2. Remove the operator panel assy (see “Operator Panel Assy” on page 21).
3. Remove the eject roller assy (see “Eject Roller Assy” on page 26).
4. Remove the face up stacker assy (see “Face Up Stacker Assy” on page 25).
5. Remove the lower base unit (see “Lower Base Unit” on page 22).
6. Remove the fusing unit assy (see “Fusing Unit” on page 32).
7. Press the clamps of the sensor plate (outlet) (1), and remove the sensor plate by pushing it up.
8. Turn the clamps of the sensor wire assy (2) remove the sensor wire assy from the lower base unit.



R. Manual Feed Guide Assy


1. Remove the upper cover assy (see “Upper Cover Assy” on page 19).
2. Open the manual feed guide assy (1), and release the engagement on both sides with the main unit by carefully bending the manual feed guide assy (1).

Note : When remounting, verify the proper the engagements as shown in the diagram.



S. Sensor Plate (Paper Supply)


1. Remove the upper cover assy (see “Upper Cover Assy” on page 19).
2. Remove the operator panel assy (see “Operator Panel Assy” on page 21).
3. Remove the face up stacker assy (see “Face Up Stacker Assy” on page 25).
4. Remove the lower base unit (see “Lower Base Unit” on page 22).
5. Press the clamps of the sensor plate (paper supply) (1) to unlock the latch, and remove it from the base plate (2).



T. GRG-PCB

1. Remove the upper cover assy (see “Upper Cover Assy” on page 19).
2. Remove the operator panel assy (see “Operator Panel Assy” on page 21).
3. Remove the face up stacker assy (see “Face Up Stacker Assy” on page 25.).
4. Remove the lower base unit (see “Lower Base Unit” on page 22).
5. Remove three screws (1) and two screws (2).
6. Remove the connector FAN, and disconnect the fan motor (3).
7. Remove the three connectors PWZ, PS1 and HVIF.
8. Remove the GRG-PCB (4) and plate earth A (5).

Note : When reinstalling the GRG-PCB 4 onto the base plate (6), insert the edge of the GRG-PCB (4) in two slots of the base plate (6).




U. Power Supply Board and High Voltage/Sensor Unit

1. Remove the upper cover assy (see “Upper Cover Assy” on page 19).
2. Remove the lower base unit (see “Lower Base Unit” on page 22).
3. Remove two screws (1) and the guide plate (2).
4. Remove the AC inlet (3) from the guide plate (2).
5. Remove the screw (4) and remove the grounding (earth) wire (5).
6. Remove the connectors CN2 from power supply board (6) and CN1 from high voltage/sensor unit (10).
7. Remove ten screws (7), and remove the power supply board 6 and high voltage/sensor unit (10).
8. Remove the Insulation plate (8) from the base plate (9).

Notes : 1.Be careful about the sensor (paper supply) when reinstalling the lower base.


2.Make sure that no excessive force is applied to the power supply switch.

3.When installing the power supply/sensor onto the base plate, be careful not to bend the base plate (it is desirable to place a block underneath it to prevent bending).




V. Cassette Guide L Assy

1. Remove the paper cassette.
2. Remove the upper cover assy (see “Upper Cover Assy” on page 19).
3. Remove the lower base unit (see “Lower Base Unit” on page 22).
4. Remove two screws (1), and remove the beam plates (2).
5. Remove the cassette guide L Assy (3) by shifting it in the direction of the arrow as shown below.
6. Remove the earth plate (4).



W. Cassette Guide R Assy

1. Remove the paper cassette.
2. Remove the upper cover assy (see “Upper Cover Assy” on page 19).
3. Remove the lower base unit (see “Lower Base Unit” on page 22).
4. Remove two screws (1), and remove the beam plates (2).
5. Remove the cassette guide R Assy (3) by shifting it in the direction of arrow.
6. Remove the earth plate (4) and the cassette lock spring (5).



Adjustment

This chapter explains adjustment necessary when a part is replaced. This adjustment is made by changing the parameter values set in EEPROM on the main control board. The status monitor can be used for assessing trouble diagnosis.

1. Adjustment Function

A. Status Monitor)

This utility is located on the CD-ROM that comes with the printer. Use the utility for basic troubleshooting diagnosis, following the prompts. Execute fixes as needed.

2. Adjustment When Replacing a Part

Adjustment is necessary when replacing any of the following parts.

Part Replaced	Adjustment
LED Head	Set the LED head drive time.
Image Drum Cartridge	Reset the image drum counter (refer to User's Guide).
Main Control Board	EEPROM data Upload/Download

A. Uploading/Downloading EEPROM data

When the controller printed circuit board is replaced, the contents of the old EEPROM shall be copied to the new EEPROM on the new board to preserve customer settings. For the purpose, use the EEPROM operation on the Option of the Maintenance Utility. To copy follow the steps below.

1. Be sure to confirm that the printer and the PC are connected with a centronics I/F cable. Then execute the Maintenance Utility.
Note: Printer driver will be uninstalled.
2. Select the Option on the Maintenance Utility.
3. Click the "UPLOAD EEPROM" button on the "EEPROM Operations."
4. The contents of the EEPROM data are displayed on the "DIALOG" of the Maintenance Utility. The contents of the old EEPROM are then copied into the memory of the PC.
5. Replace the controller P.C.B. with a new one while it displays the above "DIALOG."
6. After the replacement, click "Downloaded EEPROM" on the "EEPROM Operations". EEPROM upload has been completed.

In case of troubles such as centronics I/F failure, etc. EEPROM data may not be uploaded properly. In such case, it is necessary to adjust the following settings manually after the replacement using the Maintenance Utility.

- Factory setting

The maintenance utility is designed to be used only by field engineer and it should not be released to the end-users.

Periodical Maintenance

1. Periodical Replacement Parts

The parts are to be replaced periodically as specified below:

Part Name	Condition for Replacement	Cleaning	Remarks
Toner Cartridge 2.5K (Type 9)	About 2,500 sheets of paper have been printed.	LED head	Consumables
Image Drum Cartridge (Type 9)	About 25,000 sheets of paper have been printed. See "Image drum cartridge" on page 10.		Consumables

2. Cleaning

Remove any toner or dust accumulated inside the printer. Clean in and around the printer with a piece of cloth when necessary. Use the toner vacuum to clean inside the printer.


Note: Do not touch the image drum, LED lens array, or LED head connector block.

A. Cleaning of LED Lens Array

Clean the LED lens array or replace the toner cartridge when white lines or stripes (void, light printing) are generated vertically down the page, as shown below.


Note: The LED lens array must be cleaned with an LED head cleaner included in the replacement toner kit.

*White lines or stripes
(void, light printing)*



1. Set the LED head cleaner to the LED lens array as shown in the figure, then slide the cleaner back and forth horizontally several times to clean the head.

Note: Gently press the LED head cleaner onto the LED lens array.



2. Throw the cleaner pad away.

B. Cleaning Page Function

There is a charge roller cleaning function with this printer, which can be executed by the user.

1. Press the control switch to take the printer off line.
2. Open the manual feed tray and insert a sheet of letter sized plain paper between the paper guides.
3. Press and hold down the control switch for at least five seconds.
4. The printer grips the paper and prints a cleaning page.
5. Return the printer to on line by pressing the control switch.
6. If subsequent printing appears faded or uneven, try replacing the toner cartridge.

Troubleshooting Procedures

1. Troubleshooting Tips

1. Check the troubleshooting section in the User's Guide.
2. Gather as much information about the situation as possible.
3. Inspect the equipment under the conditions close to those in which the problem had occurred.

2. Points to Check before Correcting Image Problems

1. Is the printer being run in proper ambient conditions?
2. Are supplies (toner) and routine replacement part (image drum cartridge) being replaced properly?
3. Is the printing paper normal (acceptable quality)?
4. Is the image drum cartridge being loaded properly?

3. Tips for Correcting Image Problems

1. Do not touch, or bring foreign matter into contact with the surface of the image drum.
2. Do not expose the image drum to direct sunlight.
3. Keep hands off the fuser unit as it heats up during operation.
4. Do not expose the image drum to light for longer than 5 minutes at room temperature.

4. Preparation for Troubleshooting


A. Operator Panel Display

The failure status of printer is displayed on the status monitor of the PC. Take proper action according to the message displayed on the status monitor.

B. LED indicator

The printer is equipped with four LEDs. These LEDs indicate the following states:

1. Power
2. Ready
3. Manual Feed
4. Error



C. LED Function Table

Status	○ Ready (green)	 Manual Feed (amber)	⚠ Error (amber)	Remark
Online(Ready)	ON	OFF	Undefined	
Offline	OFF	OFF	Undefined	
Data Arrive	Flash 2	OFF	Undefined	
Data Processing	Flash 2	OFF	Undefined	
Data Exist	Flash 1	OFF	Undefined	
Printing	Flash 2	OFF	Undefined	
Printing (copy)	Undefined	OFF	Undefined	
Canceling Job	Flash 1	OFF	Undefined	
Canceling Job	Flash 1	OFF	Undefined	
Warming Up	Flash 1	OFF	OFF	
Power Saving	Undefined	OFF	OFF	
Toner Low	Undefined	Undefined	Flash 1 or Flash 2	
Toner Empty	Undefined	OFF	Flash 2	
Toner Sensor Error	Undefined	Undefined	Flash 1	
Change Drum	Undefined	Undefined	Flash 3	
Print Demo	Flash 2	Undefined	Undefined	
Print Fonts	Flash 2	Undefined	Undefined	
Print Menu Map	Flash 2	Undefined	Undefined	
Print Cleaning	Flash 2	Undefined	Undefined	
Invalid data	Undefined	OFF	Flash 2	
tttt tray paper out (BACK GROUND)	Undefined	Undefined	Flash 1	
Tray2 cover open	Undefined	Undefined	Flash 1	
File System Error (File System full)	Undefined	Undefined	Flash 1	
File System Error (Write Protect)	Undefined	Undefined	Flash 1	
File System Error (Operation failure)	Undefined	Undefined	Flash 1	
Manual Paper Request	Undefined	Flash 2	Undefined	
tttt Tray mmmm Paper Request	OFF	OFF	Flash 2	
Tray2 cover open	OFF	OFF	Flash 2	
tttt Tray mmmm Paper Media Mismatch	OFF	OFF	Flash 2	
tttt Tray mmmm Paper Size Mismatch	OFF	OFF	Flash 2	
RS232C Overflow Error	OFF	OFF	Flash 2	
RS232C Overrun Error	OFF	OFF	Flash 2	
RS232C Parity Error	OFF	OFF	Flash 2	
RS232C Framing Error	OFF	OFF	Flash 2	
Toner Empty	OFF	OFF	Flash 2	
Page Buffer Overflow	OFF	OFF	Flash 2	
Paper Size Error	OFF	OFF	Flash 2	

Flash 1: Slow blinking
Flash 2: Blinking
Flash 3: Fast blinking

Status	○ Ready (green)	Manual Feed (amber)	Error (amber)	Remark
Paper Includ Jam	OFF	OFF	Flash 2	
Paper Feed Jam	OFF	OFF	Flash 2	
Paper Exit Jam	OFF	OFF	Flash 2	
Change Drum	OFF	OFF	Flash 2	
I/D Not Installed	OFF	Undefined	Flash 2	
Cover Open	OFF	Undefined	Flash 2	
Restarting Printer	OFF	OFF	Flash 2	
Fatal Error	Flash 3	Flash 3	Flash 3	
During initializing	OFF	OFF	OFF	
Initializing EEPROM	OFF	OFF	OFF	
Checking RAM	OFF	OFF	OFF	
During initializing EEPROM	Flash 2 (3 times)	Flash 2 (3 times)	Flash 2 (3 times)	
Drum counter being reset	Flash 2 (2 times)	Flash 2 (2 times)	Flash 2 (2 times)	
Forced ROM start-up function Rising	Flash 2	Flash 2	Flash 2	
During initializing	ON and then OFF	ON and then OFF	ON and then OFF	


Flash 1: Slow blinking

Flash 2: Blinking

Flash 3: Fast blinking

5. Troubleshooting Flow

Should there be a problem with the printer, carry out troubleshooting according to the following procedure flow:



A. Status Monitor Message List

The table below lists the statuses and troubles to be displayed on the status monitor in the message format.

Category	Status Message	Code	Display Content	Remedy
Normal Status	Warming Up	10003	Warming-up status	Normal operation
	Online (Ready)	10001	Online (ready) status	Normal operation
	Power Save Mode	10094	Power save status	Normal Operation
	Toner Low	10006	The toner amount in the toner cartridge is small.	Normal Operation
	Toner Sensor	10093	The toner sensor is faulty.	Replace the toner sensor.
	Change Drum	40093	Life of I/D drum	Change the I/D Unit and reset Drum counter see "Adjustment When Replacing a Part" on page 42.
	Manual Paper In	10097	The paper is in the manual feed mode.	Normal operation
	Printing In Progress	10098	Printing in progress X=0 Non Warning X=1 Toner Low X=2, 3 Change Drum	Normal operation
	Ejection In Progress	10099	Ejection in progress X=0, Non Warning X=1, Toner Low X=2, 3 Change Drum	Normal operation
	Manual Request Executive Letter Legal 14 Legal 13 A6 A5 A4 B5 Monarch COM-10 DL C5 COM-9	411xx	Request the paper to be set in the manual feed mode. The paper sizes are as follows: Executive, Letter, Legal 14, Legal 13, A4, A5, A6,B5, Monarch, DL, C5, COM-10, COM-9 xx: Paper size in the tray being selected	Set the requested paper in the manual feed mode.
Paper size error	Paper Size Error	30034	Paper of improper size was fed. 2.52" (64 mm) L 15.77" (400.56 mm)	Check the paper. Also check whether more than one sheet of paper was fed simultaneously. To release the error display, open the cover, then close it. If this error occurs frequently, see Paper Size Error on page 55.

Category	Status Message	Code	Display Content	Remedy
Paper Jam	Paper Input Jam	40077	A paper jam occurred when sheets of paper were being supplied.	Check the paper. To release the error display, open the cover, then close it. If this error occurs frequently, see Paper Input Jam on page 52.
	Paper Feed Jam	40078	A paper jam occurred during paper feeding.	Open the cover, then remove the jammed paper. To release the error display, close the cover. If this error occurs frequently, see Paper Feed Jam on page 53.
	Paper Exit Jam	40079	A paper jam occurred during paper ejection.	Open the cover, then remove the jammed paper. To release the error display, close the cover. If this error occurs frequently, see Paper Exit Jam on page 54.
	ID Not Installed	40033		Install I/D Unit
Cover open	Cover Open	40021	The upper cover is open.	To release the error display, close the cover. If this error occurs frequently, replace the power supply board.
Buffer overflow	Page Buffer Overflow	30097	The page buffer overflowed because there is a large amount of print data.	To release the error display, press the reset button on the status motor of the printer driver. Install RAM or reduce the amount of print data.
Device configuration error	Program ROM Check Error		An error occurred during program ROM check.	Replace program ROM or the main control board. (When replacing the main control board, also adjust EEPROM data.) (See "Adjustment When Replacing a Part" on page 42)
	Resident RAM Check Error		An error occurred during resident RAM check.	Replace the main control board. (When replacing the main control board, also adjust EEPROM data.) (See "Adjustment When Replacing a Part" on page 42)
	EEPROM Check Error		An error occurred during EEPROM check.	Replace the main control board. (When replacing the main control board, also adjust EEPROM data.) (See "Adjustment When Replacing a Part" on page 42)
	Option RAM Check Error		An error occurred during option RAM check.	Check the connection of the Option RAM PC board. If the optional RAM PC board is faulty, replace it.
	Fuser Error	40084	A heater timeout error occurred.	See Section Fusing Unit Error on page 56.
	Thermistor Open Check Error		The thermistor is open.	Replace the heater Assy.
	Thermistor Short Check Error		A thermistor short occurred.	Replace the heater Assy.
	Watch Dog Timeout Error		A watchdog timeout occurred.	To release the error display, turn on the power supply again. Replace the main control board.
	Motor Timeout Error		A motor timeout occurred.	To release the error display, turn on the power supply again. Replace the main control board.

Status Message Troubleshooting


If the problems cannot be corrected by using the status message/problem list, follow the troubleshooting flowcharts given here to identify and fix the problem.

No.	Trouble	Flowchart Number
1	The printer does not work normally after the power is turned on.	①

No.	Trouble	Flowchart Number
2	Jam Alarm <ul style="list-style-type: none"> — Paper input jam — Paper feed jam — Paper exit jam 	②-1 ②-2 ②-3
3	Paper Size Error	③
4	Fusing Unit Error	④
5	SSIO (Synchronous Serial Input/Output) error I/F timeout (no response) between the printer and an optional tray (High Capacity Second Paper Feeder, Power Envelope Feeder).	⑤
6	Fan Error	⑥


①. The printer does not work normally after the power is turned on.

- Turn the power off, then back on.




②-1 Paper input jam


- Does the JAM error occur when the power is turned on?
 - Yes Is the paper at the inlet sensor?
 - Yes Remove the paper.
 - No Is the operation of the inlet sensor plate normal (moves freely when touched)?
 - No Replace the inlet sensor plate.
 - Yes Clean the inlet sensor on the power supply/sensor board, or replace the power supply/sensor board.
- No Does the JAM alarm occur after paper feeding?
 - Yes Is the paper fed to the inlet sensor plate?
 - Yes Is the operation of the input sensor plate normal (moves freely when touched)?
 - No Replace the inlet sensor plate.
 - Yes Clean the inlet sensor on the power supply/sensor board or replace the power supply/sensor board.
 - No Replace the hopping roller rubber or paper cassette.
- No Is the hopping roller rotating?
 - Yes Set the paper tray properly.
- No Is the registration motor rotating?
 - Yes Replace the one-way clutch gear of the hopping roller assembly.
- No Is RM connector on the main control board being connected properly?
 - No Connect RM connector properly.
- Yes Is the coil resistance (normal resistance: both between Pins 1 and 2, as well as Pins 3 and 4 are about 7.9 Ω) of the registration motor normal?
 - No Replace the registration motor.
- Yes Replace the main control board.



②-2 Paper feed jam




②-2-a




[JAM error]

②-3 **Paper exit jam**



③ Paper size error

- Is paper of the specified size being used?
 - No Use paper of the specified size.
- Yes Are inlet sensor plates 1 and 2 operating properly (moves freely when touched)?
 - No Replace the inlet sensor plate or clean the inlet sensor on the power supply/sensor board.
- Yes Does the outlet sensor plate operate properly (moves freely when touched)?
 - No Replace the outlet sensor plate or clean the outlet sensor on the power supply/sensor board.
- Yes Replace the power supply/sensor board.



④ Fusing unit error (ERROR 170) (ERROR 171) (ERROR 172) (ERROR 173)

Status Message : Thermistor Open Error
: Thermistor Short Check Error
: Fuser Error Heater temp High
: Fuser Error Heater temp Low

- Turn the power off, then back on again.

▼ Yes Is the thermistor open or shorted? Measure the resistance between thermistor contacts (heater contacts 120V/2Ω or 240V/7Ω, and thermistor contacts 200KΩ at room temperature) (see Figure below).

- Yes Replace the fusing unit.

▼ No Is the thermistor connector connected to the main control board connector?

- No Connect the thermistor connector property.


▼ Yes Is the heater of the fusing unit turned on (when the heater is turned on, light is emitted)?

- Yes Check the thermistor connector or replace the main control board or the fusing unit.

▼ No Is the AC voltage being supplied to the connector for the heater of the power supply board? (see Figure below)

- No Replace the main control board or the power supply/sensor board.


▼ Yes Check the heater connector cord and the heater connector for poor contact .



⑤ Synchronous serial I/O error or I/F timeout between printer and optional tray


Status Message : SSIO Error

: Tray2 Timeout Error or Feeder Timeout Error




6. Image Troubleshooting


Procedures for troubleshooting for abnormal image printouts are explained below. The Image Troubleshooting Figure below shows typical abnormal images.




Ⓐ Light or blurred images entirely




Ⓑ Dark background density




Ⓒ Blank paper



Ⓓ Black vertical belts or stripes



Ⓔ Cyclical defect



Ⓕ White vertical belts or streaks


Figure: Image Troubleshooting

Problem	Flowchart number
Images are light or blurred entirely (A)	①
Dark background density (B)	②
Blank paper is output (C)	③
Black vertical belts or stripes (D)	④
Cyclical defect (E)	⑤
Print voids	⑥
Poor fusing (images are blurred or peels off when the printed characters and images on the paper are touched by hand)	⑦
White vertical belts or streaks (F)	⑧


①. Images are light or blurred entirely.

- Is toner low (is the TONER LOW message displayed)?
 - Yes Supply toner.
- No Is paper of the specified grade being used?
 - No Use paper of the specified grade.
- Yes Is the lens surface of the LED head dirty?
 - Yes Clean the lens.
- No Is the LED head being installed properly (check the HEAD1 connector of the main control board and PC connector on the LED head for proper connection)?
 - No Install the LED head properly.
- Yes Is the contact plate of the transfer roller in contact with the contact assembly of the power supply/sensor board properly (see Figure)?
 - No Adjust the contact plate of the transfer roller to make a proper contact with the power supply/sensor board and shaft of the transfer roller.
- Yes Is the contact of the developing roller and the contact of the toner supply roller of the image drum cartridge in contact with the contact assembly properly (see Image Troubleshooting Figure on page 58, (A) and (B))?
 - No Adjust the contacts of the developing and toner supply roller to make a proper contact with the contact assembly.
- Yes Replace the transfer roller.
- Has the problem been solved?
 - Yes End
- No Replace the image drum cartridge.
- Has the problem been solved?
 - Yes End


Note: After replacing the image drum cartridge, reset the drum counter by clicking the "Reset" button in the Status Monitor. (see User's Guide).
- No Is the tension between the back-up roller (7.52kg) and the surface of back-up roller normal?
 - No Replace the back-up roller or bias spring.
- Yes Replace the main control board or power supply/sensor board.




②. Dark background density



③. Blank paper is output.



④. Black vertical belts or stripes




⑤. Cyclical Defect

Unit	Frequency	Remedy
Image drum	3.71" (94.2mm)	Replace or clean the image drum cartridge.
Developing roller	1.86" (47.12mm)	Replace the image drum cartridge.
Toner supply roller	2.96" (75.27mm)	Replace the image drum cartridge.
Charging roller	1.21" (30.63mm)	Replace the image drum cartridge.
Cleaning roller	0.93" (23.56mm)	Replace the image drum cartridge.
Transfer roller	1.95" (49.6mm)	Replace the transfer roller.
Heat roller	2.44" (62.0mm)	Replace the fusing unit assy.
Back-up roller	2.73" (69.4mm)	Replace the back-up roller.

Note: After replacing the image drum cartridge, reset the drum counter by clicking the "Reset" button in the Status Monitor. (see User's Guide).

⑥. Prints voids




⑦. Poor Fusing

Poor fusing (images are blurred or peel off when the printed characters and images on the paper are touched by hand).

- Is paper of the specified grade being used?
 - No Use paper of the specified grade.
- Yes Is the tension between the back-up roller (7.52kg) and the surface of back-up roller normal?
 - No Replace the back-up roller or bias spring.
- Yes Is the contact of the fusing unit assy in proper contact with the contact assy (see "Figure 5-4" on page 65 - G)?
 - No Adjust the contact of the fusing unit assy to make a proper contact with the contact assembly.
- Yes Replace the fusing unit assembly.
- Has the problem been solved?
 - Yes End
- No Replace the main control board or power supply/sensor board.

⑧. White vertical belts or streaks






Figure 5-4





Figure 5-5


Wiring Diagram

1. Interconnect Signal Diagram




2. PCB Layout and Connector Signal List

A. Main Control Board (GRG-PCB)



B. Power Supply/Sensor Board



FAN Connector Pin Assignment (To fan motor)

Opening	Pin Number	I/O*	Signal	Description
1	1	O	FANPOW	Power supply for fan driving
2	2	C	OV	Ground
3	3	I	FANALM-N	Fan alarm

DM Connector Pin Assignment (To main/drum motor)

Opening	Pin Number	I/O*	Signal	Description
1	1	O	DMPH1-P	Coil 1-P
2	2	O	DMPH1-N	Coil 1-N
3	3	O	DMPH2-P	Coil 2-P
4	4	O	DMPH2-N	Coil 2-N

Excitation Sequence

Pin Number	Line Color	Step Number			
		1	2	3	4
2	Yellow	+	-	-	+
4	Black	+	+	-	-
1	Orange	-	+	+	-
3	Brown	-	-	+	+

* I: In, O: Out, C: Common - Rotary direction is clockwise viewed from the output axis

RM Connector Pin Assignment (To registration motor)

Opening	Pin Number	I/O*	Signal	Description
1	1	O	RMPH1-P	Coil 1-P
2	2	O	RMPH1-N	Coil 1-N
3	3	O	RMPH2-P	Coil 2-P
4	4	O	RMPH2-N	Coil 2-N

* I: In, O: Out

Excitation Sequence

Pin Number	Line Color	Step Number			
		1	2	3	4
2	Yellow	+	-	-	+
4	Black	+	+	-	-
1	Orange	-	+	+	-
3	Brown	-	-	+	+

Clockwise viewed from the output axis

HEAD1 Connector Pin Assignment (To LED head)

		PIN NO.	I/O*	Signal	Description
1		1	C	0VLOGIC	Ground for Logic
	2	2	O	HDCLK-P	Clock
3		3	C	0VLOGIC	Ground for Logic
	4	4	O	HDD2-P	Data 2
5		5	O	HDD3-P	Data 3
	6	6	C	0VLED	Ground for LED
7		7	O	HDD0-P	Data 0
	8	8	O	HDD1-P	Data 1
9		9	C	+3.3V	+3.3V power supply for LED driving
	10	10	O	HDDL-D-P	Load
11		11	O	HDSTB1-N	Strobe 1
	12	12	C	HDSTB2-N	Strobe 2
13		13	O	HDSTB3-N	Strobe 3
	14	14	C	HDSTB4-N	Strobe 4

* O: Out
C: Common

HEAD2 Connector Pin Assignment (To LED head)

		PIN NO.	I/O*	Signal	Description
1		1	O	+3.3V	+3.3V power supply for LED driving
	2	2	O		
3		3	O		
	4	4	O		
5		5	O		
	6	6	O		
7		7	C	0VLED	Ground for LED
	8	8	C		
9		9	C		
	10	10	C		
11		11	C	FG	FG
	12	12	C		

* O: Out
C: Common

PANEL Connector Pin Assignment (To operator panel)

		PIN NO.	I/O*	Signal	Description
1		1	C	+5V	+5V power supply
	2	2	O	READY	Signal for READY
3		3	O	PAPER	Signal for PAPER
	4	4	O	ALARM	Signal for ALARM
5		5	I	SW-N	Signal for Switch
	6	6	C	0VL	Ground

* I: In
O: Out
C: Common

ENVELOPE Connector Pin Assignment (To option feeder I/F)

		PIN NO.	I/O*	Signal	Description
5	8	1	O	PAPERIN-N	Paper sense 1
2	7	2	O	SCLK-N	Clock
1	4	3	O	DATA-N	Data
3	6	4	I	PAPERIN-N	OPT send data ready
		5	C	OVP	Analog ground
		6	O	30V	+30V power supply
		7	C	0V	Logic ground
		8	O	5V	+5V power supply

* I: In
O: Out
C: Common

2NDTRAY Connector Pin Assignment (To option tray I/F)

		PIN NO.	I/O*	Signal	Description
1		1	O	PAPERIN-N	Paper sense 1
2		2	O	SCLK-N	Clock
3		3	O	DATA-N	Data
4		4	I	PAPERIN-N	OPT send data ready
5		5	C	OVP	Analog ground
6		6	O	30V	+30V power supply
7		7	C	0V	Logic ground
8		8	O	5V	+5V power supply

* I: In
O: Out
C: Common

POWER Connector Pin Assignment (To power supply/sensor board)

Pin No.	I/O*	Signal	Description	Pin No.	I/O*	Signal	Description
2	O	TRSEL-P	TR control switch	1	I	SQCR-N	Sequence clear signal of serial I/F
4	I	THERMCMP-P	Heater temperature	3	I	SCLK-N	Clock signal of serial I/F
6	I	CVOPN-N	Cover open (+5V)	5	I	PSIN1-N	Paper sense
8	O	DOUT-P	Serial data output	7	I	WRSNS-N	Reading of paper edge
10	I	RXD2-P	Serial data input	9	C	OVL	Ground for logic
12	I	+5V	Logic circuit supply voltage	11	I	+5V	Logic circuit supply voltage
14	I	+3.3V	LED head supply voltage	13	I	+3.3V	LED head supply voltage
16	C	OVL	Logic ground	15	C	OVL	Logic ground
18	I	+30V	Motor and fan drive voltage and source voltage for high voltage supply	17	I	+30V	Motor and fan drive voltage and source voltage for high voltage supply
20	O	HEATON-N	Heater on	19	O	TRSEL2-N	TR control switch
22	I		NC	21	C	0VP	Power (motor) ground
24	I	+12V	High voltage supply	23	C	0VP	Power (motor) ground
26	O	TRSEL3-N	TR control switch	25	C	0VP	Power (motor) ground

* O : Out
I : In
C : Common

CENT Connector Pin Assignment (To Centro parallel I/F)

Pin No.	I/O*	Signal	Description	Pin No.	I/O*	Signal	Description
1	I	STROBE-N	Strobe	19	C	SG	Ground
2	C	DATA1-P	Data bit 0	20	C	SG	Ground
3	C	DATA2-P	Data bit 1	21	C	SG	Ground
4	C	DATA3-P	Data bit 2	22	C	SG	Ground
5	C	DATA4-P	Data bit 3	23	C	SG	Ground
6	C	DATA5-P	Data bit 4	24	C	SG	Ground
7	C	DATA6-P	Data bit 5	25	C	SG	Ground
8	C	DATA7-P	Data bit 6	26	C	SG	Ground
9	C	DATA8-P	Data bit 7	27	C	SG	Ground
10	O	ACK-N	Acknowledge	28	C	SG	Ground
11	O	BUSY-P	Busy	29	C	SG	Ground
12	O	PE-P	paper end	30	C	SG	Ground
13	O	SEL-P	Select	31	I	IPRIME-N	Input prime
14	I	AUTOFEED-N	Auto feed	32	O	FAULT-N	Fault
15		NC	Not connected	33	C	SG	Ground
16	C	SG	Ground	34		NC	Not connected
17	C	FG		35	O	HILEVEL	Always kept high
18	O	P-LOGIC-H	+5V power supply	36	I	SELIN-N	Select in

* O : Out

I : In

C : Common

USB Connector Pin Assignment To USB I/F

2	1
3	4

PIN NO.	I/O*	Signal	Description
1	I	Vcc	+5V Power supply
2	I/O	D-	USB Data
3	I/O	D+	USB Data
4	C	0V	Ground







* I: In
O: Out
C: Common



OPTION Connector Pin Assignment (To option RAM / RS232C or Network)

Pin No.	I/O*	Signal	Description	Pin No.	I/O*	Signal	Description
01	O	A0	OR write enable	51	I/O	D16	Data bit 16
02	C	0V	Logic ground	52	I/O	D0	Data bit 0
03	O	A1	Address bit 1	53	I/O	D17	Data bit 17
04	O	A2	Address bit 2	54	I/O	D1	Data bit 1
05	O	RSDTR0-N	RS232C Data terminal ready	58	I/O	D18	Data bit 18
06	O	A3	Address bit 3	56	I/O	D2	Data bit 2
07	O	A4	Address bit 4	57	I/O	D19	Data bit 19
08	C	0V	Logic ground	58	I/O	D3	Data bit 3
09	O	A5	Address bit 5	59	I/O	D20	Data bit 20
10	O	A6	Address bit 6	60	I/O	D4	Data bit 4
11	C	+5V	Logic power supply	61	I/O	D21	Data bit 21
12	O	A7	Address bit 7	62	I/O	D5	Data bit 5
13	O	A8	Address bit 8	63	I/O	D22	Data bit 22
14	C	0V	Logic ground	64	I/O	D6	Data bit 6
15	O	A9	Address bit 9	65	I/O	D23	Data bit 23
16	O	A10	Address bit 10	66	I/O	D7	Data bit 7
17	C	+5V	Logic power supply	67	I/O	D24	Data bit 24
18	O	A11	Address bit 11	68	I/O	D8	Data bit 8
19	O	A12	Address bit 12	69	I/O	D25	Data bit 25
20	C	0V	logic ground	70	I/O	D9	Data bit 9
21	O	A13	Address bit 13	71	I/O	D26	Data bit 26
22	O	A14	Address bit 14	72	I/O	D10	Data bit 10
23	C	+5V	Logic power supply	73	I/O	D27	Data bit 27
24	O	A15	Address bit 15	74	I/O	D11	Data bit 11
25	O	A16	address bit 16	75	I/O	D28	Data bit 28
26	C	0V	Logic ground	76	I/O	D12	Data bit 12
27	O	A17	Address bit 17	77	I/O	D29	Data bit 29
28	O	A18	Address bit 18	78	I/O	D13	Data bit 13
29	C	+5V	Logic power supply	79	I/O	D30	Data bit 30
30	O	A19	Address bit 19	80	I/O	D14	Data bit 14
31	O	A20	Address bit 20	81	I/O	D31	Data bit 31
32	C	0V	Logic ground	82	I/O	D15	Data bit 15
33	O	A21	Address bit 21	83	O	DRAS2-N	DRAM select 2
34	O	A22	Address bit 22	84	O	DRAS3-N	DRAM select 3
35	O	A23	Address bit 23	85	O	DRAS4-N	DRAM select 2
36	O	0V	Logic ground	86	O	DRAS5-N	DRAM select 5
37	O	0V	Logic ground	87	O	DCAS3-N	DCAS3
38	C	0V	Logic ground	88	O	DCAS2-N	DCAS2
39	O	RSRTS0-N	RS232C request to send	89	O	DCAS1-N	DCAS1
40	O	CS1-N	ROM/SRAM select 1	90	O	DCAS0-N	DCAS0
41	O	CS2-N	ROM/SRAM select 2	91	O	RD-N	RD-N
42	O	CS3-N	ROM/SRAM select 3	92	O	WR-N	WR-N
43	I	SCRREQ-P	SCC send request	93	I	INT1-N	Interrupt request 1
44	C	0V	Logic ground	94	I	INT2-N	Interrupt request 2
45	I	SCSREQ-P	SCC receive request	95	O	EEPRMCS1-P	EEPROM select
46	O	IOS0-N	I/O select 0	96	O	EEPRMCLK-P	EEPROM clock
47	O	IOS1-N	I/O select 1	97	C	SSTXD-P	EEPROM data
48	O	RSTXD0-N	RS232C send data	98	I	DRDY-N	Data read
49	O	-8V	RS232C line voltage	99	C	+8V	RS232C line voltage
50	I	RSRXD0-P	RS232C receive data	100	O	RESET-N	Reset signal


* O : Out
I : In
C : Common


3. Resistance Check

Unit	Circuit Diagram	Illustration	Resistance
Registration motor	 <p>1 ○ → Orange 2 ○ → Yellow 3 ○ → Brown 4 ○ → Black</p>	 <p>Yellow</p>	<p>Between Pins 1 and 2: 7.9Ω Between Pins 3 and 4: 7.9Ω</p>
Main/drum motor	 <p>1 ○ → Orange 2 ○ → Yellow 3 ○ → Brown 4 ○ → Black</p>	 <p>White</p>	<p>Between Pins 1 and 2: 8.6Ω Between Pins 3 and 4: 8.6Ω</p>
Fusing unit	 <p>1 ○ — Thermostat — Heater — 2 ○ 3 ○ — Thermistor — 4 ○</p>		<p>Between Pins 1 and 2: 120V 2Ω 240V 7Ω Between Pins 3 and 4: 200KΩ (at room temperature)</p>

Unit	Fan	Resistance	
Circuit Diagram	 <p>1 ○ Red +30 V</p> <p>3 ○ FANALM-N</p> <p>2 ○ Black 0 V</p>	Illustration	

Parts List





For B4200

#:New Parts

No.	Part No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
1	51112301	Hopping Roller Shaft	1	3	6	12	
2	53342401	Rubber-Hopping Roller	1	3	6	12	
3	51607402	Bearing	2	6	12	24	
4	51228901	One-way Clutch Gear	2	6	12	24	
5	42174301	Roller-Regist	1	3	6	12	#
6	51607501	Bearing(Registration)	1	3	6	12	
7	42174201	Roller-Pressure	1	3	6	12	#
8	41279501	Holder-Regist L	1	3	6	12	
9	41279601	Holder-Regist R	1	3	6	12	
10	41279801	Gear-Pressure	1	3	6	12	
11	41279401	Bearing-Pressure	2	6	12	24	
12	41281201	Spring-Tension	2	6	12	24	
13	41280401	Plate-Contact PA	1	3	6	12	
14	41279301	Bearing-Regist L	1	3	6	12	
15	41279701	Gear-Regist	1	3	6	12	
16	42208501	Roller Assy.-Transfer	1	3	6	12	#
17	40438001	Bearing TR	1	3	6	12	
18	41301801	Roller-Back up	1	3	6	12	
19	41584101	Spring Bias	2	6	12	24	
20	41536201	Holder-BU	2	6	12	24	
21	41584201	Bearing-Ball	2	6	12	24	
22	42208601	Lever-Reset L Assy.	1	3	6	12	#
23	50805901	Reset Lever R	1	3	6	12	
24	53068901	Switch Arm	1	3	6	12	
25	50924201	Reset Spring	1	3	6	12	
26	42126101	Idle Gear	1	3	6	12	#
27	51229201	Eject Roller Idle Gear	1	3	6	12	
28	51010701	Sensor Plate(Inlet)	3	9	18	36	
29	40771401	Lever-Eject Sensor Assembly	1	3	6	12	
30	41027701	Sensor Wire Assembly	1	3	6	12	
31	42468801	Toner Sensor(Adhesion)	1	3	6	12	
32	51010903	Diselectrification Bar Shaft	1	3	6	12	
33		Diselectrification Film	1	3	6	12	
34-a	42209201	Heat Assy	1	10	20	40	120V #
34-b	42209202	Heat Assy	1	10	20	40	230V #
35	40772501	Roller Assy.-Eject	1	3	6	12	
36	42145701	Cover Assy.-Front	1	3	6	12	#

No.	Part No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
37	42200401	Cover Assy.-Stacker	1	3	6	12	#
38	42129101	Holder-Head	1	3	6	12	#
39	42146701	Film-FG	1	3	6	12	#
40	42146501	Spring-Head	2	6	12	24	#
41	42408201	Cable-Assy-Head	1	5	10	20	#
42	42146601	Contact-Head	1	3	6	12	#
43	42266801	LED Head Unit-51MXF	1	5	10	20	#
44	42208301	Frame Subassy.-Lower	1	3	6	12	#
45		Damper Frame	1	3	6	12	
46	42122701	Bracket-Motor(Caulking)	1	3	6	12	#
47	42352501	Bracket-Sub-M	1	3	6	12	#
48	42196001	Motor-Pulse(Main)	1	3	6	12	#
49	42196101	Motor-Pulse(Regist)	1	3	6	12	#
50	42121701	Gear-M3	1	3	6	12	#
51	42121801	Gear-M2	1	3	6	12	#
52	42121901	Gear-R2	1	3	6	12	#
53	50517201	Washer C	1	3	6	12	
54		FG Plate OP	1	3	6	12	
55	42209101	Guide-Paper R(Adhesive)	1	3	6	12	#
56	42200501	Plate-Base Assy.	1	3	6	12	#
57		Polyethylene Tape	2	6	12	24	L=90mm
58	40828301	Guide-Paper H	2	6	12	24	
59		CS-RING(CS3-SUS)	2	6	12	24	
60	42209401	Cassette guide L Assy.	1	3	6	12	#
61	42209501	Cassette guide R Assy.	1	3	6	12	#
62		Beam Plate	2	6	12	24	
63		FG Plate(bm)	2	6	12	24	
64	51019701	Sensor Plate(Paper Supply)	1	3	6	12	
65	51011501	Cassette Sensor Plate	1	3	6	12	
66	42146301	Insulator	1	3	6	12	#
67	42263804	Board-GRG	1	5	10	20	#
68-a	41991601	Power Supply Unit	1	5	10	20	100V/120V #
68-b	41991701	Power Supply Unit	1	5	10	20	230V #
69	42284101	Board-HLB	1	5	10	20	#
70	56639214	Sumi-Card(30P)	1	5	10	20	#
71	42101001	Cord Assy.(13p-5P,8p)	1	5	10	20	#
72	42283501	Fan Motor	1	3	6	12	#
73	42209601	Cassette Assy.-Paper	1	3	6	12	#

No.	Part No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
74	42146201	Plate-Guide	1	3	6	12	#
75	40997101	Cord Assy.-OP	1	5	10	20	
76	42146801	Face Up Stacker Assy.	1	3	6	12	#
77	42200201	Frame Assy.-OP Panel	1	3	6	12	B4200 #
78	42147201	Cover-Upper Assy.	1	3	6	12	#
79	42129601	Cover-IF	1	3	6	12	#
90	42406601	Holder-Tr_R	1	3	6	12	#
91	42406701	Spacer-Tr_L	1	3	6	12	#
92		Plate-Earth_A	1	3	6	12	#
	Option						
81	42160909	Board GRL	1				
82	42160910	Board GRL-2	1				
83							
84	42264009	Board GRM	1				
85	42264010	Board GRM-2	1				
86							
87	42264205	Board GRJ	1				
	Consumable						
88	42102801	Image Drum Unit Type 9	1				
90	42103001	Toner Cartridge Type 9 (2.5K)	1				

Appendix A RS-232C Serial Interface (option)

1. Connector

- Printer side: 25-pin receptacle
Type DB-25S (made by Cannon) or equivalent
- Cable side: 25-pin plug
Type DB-25S (made by Cannon)
Shell
Type DB-C8-J10-F2-1 (made by Nihon Kouku Denshi) or equivalent

Note: Plug shall be fixable with a lock screw.

2. Cable


- Cable length: 6 ft (1.8 m) max. (cable shall be shielded)

Note: Cable is not provided.

3. Interface signal

Pin No.	Signal Name	Abbreviation	Signal Direction	Functions
1	Frame Ground	FG		Frame Ground
2	Transmitted Data	TD	← PR	Transmitted Data
3	Received Data	RD	→ PR	Received Data
4	Request to Send	RTS	← PR	Stay space level
5	-			(Not connected)
6	-			(Not connected)
7	Signal Ground	SG		Signal Ground
8	-			(Not connected)
9 ~ 17	-			(Not connected)
18	-			(Not connected)
19	-			(Not connected)
20	Data Terminal Ready	DTR	← PR	Data terminal ready
21 ~ 25	-			(Not connected)

- Connector Pin Arrangement



(View from the cable side)


When the Ready/Busy protocol is used for the buffer busy control method, the busy signal can be set to Pin-20 (DTR) in the menu.

4. Signal Level


- MARK polarity : -3V to -15V (LOGIC = 1)
- SPACE polarity : +3V to +15V (LOGIC = 0)

5. Interface Circuit

a. Receiving Circuit



b. Sending Circuit



6. Receive Margin

37% min. at all reception rates.

7. Communications Protocol

- a. READY/BUSY protocol
- b. X-ON/X-OFF protocol

Appendix B Centronics Parallel Interface

1. Connector

- Printer side: 36-pin receptacle
(single port) Type 57RE-40360-730B-D29A (made by Daiichi Denshi), CNAX05841A36AT (made by Ougat) or equivalent
- Cable side: 36-pin plug
Type 57-30360 (made by Daiichi Denshi) or equivalent
Plug-552274-1 (AMP), 552073-1 (AMP) or equivalent

Note: Plug shall be fixable with a lock screw.

2. Cable


- Cable length: 6 ft (1.8 m) max. (A shielded cable composed of twisted pair wires is recommended for noise prevention.)

Note: Cable is not provided and is not available from Oki.

3. Table of Parallel I/F Signals

Pin No.	Signal name	Signal direction	Functions
1	$\overline{\text{DATA STROBE}}$	→ PR	Parallel data sampling strobe
2	DATA BIT - 1		
3	DATA BIT - 2		
4	DATA BIT - 3		
5	DATA BIT - 4	→ PR	PR Parallel input and output data
6	DATA BIT - 5		
7	DATA BIT - 6		
8	DATA BIT - 7		
9	DATA BIT - 8		
10	$\overline{\text{ACKNOWLEDGE}}$	← PR	Completion of data input or end of a function
11	BUSY	← PR	During print processing or alarm
12	PAPER END	← PR	End of paper
13	SELECT	← PR	Select state (ON-LINE)
14	$\overline{\text{AUTOFEED}}$	→ PR	Request to change mode
15	-		(Not used)
16	0V		Signal ground
17	CHASSIS GROUND		Chassis ground
18	+5V	← PR	50 mA max.
19	0V		Signal ground
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31	$\overline{\text{INPUT PRIME}}$	→ PR	Initializing signal
32	$\overline{\text{FAULT}}$	← PR	End of paper or during alarm
33	-		Signal ground
34	-		(Not used)
35	-		High level (3.3 k)
36	$\overline{\text{SELECT IN}}$	→ PR	Request to change mode

• Connector Pin Arrangement



4. Signal Level


- LOW : 0 V to +0.8 V
- HIGH : +2.4 V to 5.0 V

5. Specifications


Item	Description
Mode	Compatibility mode, Nibble mode, ECP mode
Data bit length	8 bits (in the compatibility mode)
Input prime	Valid/Invalid
Receive buffer	0.1M, 0.2M, 0.5M Bytes
Control	Handshaking control is performed in each mode. Data received from the host is stored in the receive buffer. Busy control is performed. Signal lead control is performed.

6. Timing Charts


a. Data receiving timing




b. On-line → off-line switching timing by ON-LINE SW



c. Off-line → on-line switching timing by ON-LINE SW



d. INPUT PRIME timing (when set to the effective INPUT PRIME signal)



Appendix C Universal Serial Bus (USB)

1. Universal Serial Bus Specification Revision 2.0 full speed compliance

1. Connector

- Printer side: “B” Receptacle (Upstream Input to the USB Device)
- Cable side: Series “B” Plug

2. Cable


- Cable length: Max 5m (A cable must meet USB Spec Rev 1.1 for normal operation)

Note: Cable is not provided and is not available from Oki.

3. Table of USB I / F signals

Contact Number	Signal Name
1	Vbus
2	D -
3	D +
4	GND
Shell	Shielded

4. Connector pin arrangement




5. Mode & Class of Device

- Full - speed Driver
- Self - powered Device

6. Data Signaling Rate

- Full - speed function - 12Mb/s

7. Interface circuit



8. Signal Level

- Input/Output Level

Parameter	Symbol	Min.	Max.	Units
Input Levels :				
High (driven)	V _{IH}	2.0		V
High (floating)	V _{IHZ}	2.7	3.6	V
Low	V _{IL}		0.8	V
Output Levels :				
Low	OL	0.0	0.3	V
High (driven)	OH	2.8	3.6	V
Output Signal Crossover Voltage	V _{CRS}	1.3	2.0	V


- Signaling Levels

Bus State	Signaling Levels	
	Required	Acceptable
Differential "1"	(D+) - (D-) > 200mV and D+ > V _{IH} (min)	(D+) - (D-) > 200mV
Differential "0"	(D-) - (D+) > 200mV and D- > V _{IH} (min)	(D-) - (D+) > 200mV
Single-ended 0 (SE0)	D+ and D- < V _{IL} (max)	D+ and D- < V _{IH} (min)
Data J state:		
Low-speed	Differential "0"	
Full-speed	Differential "1"	
Data K state:		
Low-speed	Differential "1"	
Full-speed	Differential "0"	
Idle state:		
Low-speed	D- > V _{IHZ} (min) and D+ < V _{IL} (max)	D- > V _{IHZ} (min) and D+ < V _{IH} (min)
Full-speed	D+ > V _{IHZ} (min) and D- < V _{IL} (max)	D+ > V _{IHZ} (min) and D- < V _{IH} (min)
Resume state	Data K state	
Start-of-Packet (SOP)	Data lines switch from Idle to K state	
End-of-Packet (EOP)	SE0 for 1 bit time ¹ followed by a J state for 1 bit time	SE0 for 1 bit time ¹ followed by a J state
Disconnect (at downstream port)	SE0 for 2.5μs	
Connect (at downstream port)	Idle for 2ms	Idle for 2.5μs
Reset	D+ and D- < V _{IL} (max) for 10ms	D+ and D- < V _{IL} (max) for 2.5μs


Note: The width of EOP is defined in bit times relative to the device type receiving the EOP. The nbit time is approximate.

9. Timing Chart


a. Packet Voltage Levels




b. Disconnect Detection




c. Full-speed Device Connect Detection




d. Differential Data Jitter



e. Differential-to-EOP Transition Skew and EOP Width



f. Receiver Jitter Tolerance



Appendix D High Capacity Second Paper Feeder

1. Outline

A. Function

The printer is mounted on top of this High Capacity Second Paper Feeder. The High Capacity Second Paper Feeder supplies paper automatically through the operation of pulse motor (hopping), which is driven by signals sent from the printer.


Paper Types

- Standard paper: Xerox 4200 (20-lb)
- Special paper: OHP sheets (for PPC), Label sheets (PPC sheets); use of envelopes or thick paper is not possible.
- Cut sheet size: Letter, Executive, Legal13, Legal14, A4, A5, B5
- Special size: Width: 5.83" to 8.50" (148 to 216mm)
- Length: 8.27" to 14.00" (210 to 355.6mm)

Weight and Thickness

- 16-lb to 24-lb (60~90 g/m²)
- Paper setting quantity: 500 sheets of paper weighing 64 g/m²

B. External View and Component Names




2. Mechanism Description

A. General Mechanism

The High Capacity Second Paper Feeder feeds the paper into the printer by receiving the signal from the printer, which drives the pulse motor inside the High Capacity Second Paper Feeder, which is transmitted to rotate the one-way clutch of the hopping frame assembly. The paper is delivered from the hopper into the printer through the turning of the hopping roller and feed roller. Once delivered into the printer, the paper is then controlled and fed through by pulse motor (registration) of the printer.

B. Hopper Mechanism

The hopper automatically feeds the printer with the paper being set, single sheet at a time. The paper is loaded in the paper cassette, then transported by the pulse motor with the brake shoe one sheet at a time.



3. Parts Replacement



This section covers the procedures for the disassembly, reassembly and installations in the field. For reassembly procedures, follow the disassembly procedures in the reverse order.




A. Precautions Concerning Parts Replacement

1. Parts replacements must be carried out by first turning the printer power switch off “O” and removing the printer from the High Capacity Second Paper Feeder.
2. Do not disassemble the High Capacity Paper Feeder if it is operating normally.
3. Establish the extent of disassembly suitable for the purpose of the procedure and do not disassemble any more than necessary.
4. Only specified service tools may be used.
5. Disassembly must be carried out according to the prescribed procedures. Parts may be damaged if such procedures are not followed.
6. Small parts such as screws and collars can easily be lost, therefore these parts should be temporarily fixed in the original location.
7. When handling printed circuit boards, do not use any glove which may generate static electricity.
8. Do not place the printed circuit boards directly on the equipment or floor.

Service Tools


The table below shows the tools required for the replacement of printed circuit boards, assemblies and units in the field.

No.	Service Tools	Qty.	Application
1	 No. 1-100 Phillips screwdriver	1	2~2.5 mm screws
2	 No. 2-100 Phillips screwdriver	1	3~5 mm screws

No.	Service Tools	Qty.	Application	
3		No. 3-100 screwdriver	1	
4		Digital multimeter	1	
5		Pliers	1	


B. Parts Layout

This section describes the layout of the main components.




C. Parts Replacement Methods

This section describes the parts replacement methods for the components listed in the disassembly order diagram below.



Stepping Motor (Hopping)



1. Turn the printer power switch off, pull out the AC cord from the outlet. Remove the printer off High Capacity Second Paper Feeder.
2. Take the paper cassette assy (1) out of High Capacity Second Paper Feeder.
3. Remove six screws (2) and remove the upper plate (3). Remove two screws (4) and remove the hopping frame assy (5).
4. Remove the front cover assy (6) off the guide boss on the guide L (2nd) assy (7) by bending the guide L (2nd) assy (7) in the direction of arrow shown in the magnified view below.
5. Pull the sheet guide assy (8) in the direction of arrow (a) and also push in the direction of arrow (b) to unlock the notch, and bring the sheet guide assy (8) in the direction of arrow (c) to remove the sheet guide assy (8).




6. Remove three screws (9) which are holding the guide R (2nd) assy (10) to the bottom plate (11). Remove the screw (12) which is keeping the rear cover (13) and guide R (2nd) assy (10). Remove the guide R (2nd) assy (10).
7. Remove the protect (M) (14), guide bracket (15), planet gears (16) and planet gear bracket (17).
8. Remove the E-ring (18) which is keeping the sheet link (19) on the guide R (2nd) assy (10), and pull out the hinge stand (20).

9. Remove three remaining screws (21) which are keeping the motor on the motor bracket (22), and remove the connector off the Stepping Motor (23).
10. Remove two screws (24) on the Stepping Motor (23).

Note: The guide bracket (15) must be attached as shown in the following illustration:



Note: The upper plate (3) must be attached as shown in the following illustration.



GRT-PCB


Note : Refer to Detail A on the previous page.

1. Remove the pulse motor (see “Stepping Motor (Hopping)” on page 99).
2. Remove the connectors (27, 28) from the GRT PCB (26).
3. Remove the screw (29) and remove the GRT PCB (26).

Hopping Roller Shaft Assy and One-way Clutch Gear

1. Follow up to step (3) of (“Stepping Motor (Hopping)” on page 99) and remove the hopping frame assy.
2. Remove the screw (1) and remove the earth plate (2). Remove the sensor lever (T) (3) and remove the tension spring (4) and remove the ground plate (5). Remove the gear (6) and remove the metal bush (7) and hopping roller shaft assy (8).
3. Remove the E-ring (9) and remove the one-way clutch gear (10) on the right side of the feed roller (11).

Note : The metal bush (12) also comes off. Be careful not to lose it.



Note: The tension lever and the sensor lever require concurrent replacing.

4. Troubleshooting


A. Troubleshooting Tips

1. Check the troubleshooting section in the User's Guide.
2. Gather as much information about the situation as possible.
3. Inspect the equipment under the conditions close to those in which the problem had occurred.

B. Preparation for Troubleshooting


A. Operator Panel Display

The status of the problem is displayed on the LED on the Operator panel.









B. Troubleshooting Method










When a problem occurs, go through the troubleshooting according to the following procedure.



LED Status Message List


The listing of the statuses and problems displayed in the form of messages on the status monitor in the Table below.

Classification	LED Status Message	Description	Recovery method
Jam error (feeding)	 Blinking	Notifies of occurrence of jam while the paper is being fed from High Capacity Second Paper Feeder.	<ul style="list-style-type: none"> • Check the paper in the High Capacity Second Paper Feeder. • Carry out the recovery printing by opening and closing the cover, and turn the error display off. • When the problem occurs frequently, go through the Troubleshooting.
	 OFF		
	 OFF		
Jam error (ejection)	 Blinking	Notifies of occurrence of jam while the paper is being ejected from the printer.	<ul style="list-style-type: none"> • Check the paper in the printer. Carry out the recovery printing by opening and closing the cover to reset the error display.
	 OFF		
	 OFF		

Classification	LED Status Message	Description	Recovery method
Paper size error	 Blinking  OFF  OFF	Notifies of incorrect size paper feeding from High Capacity Second Paper Feeder.	<ul style="list-style-type: none"> • Check the paper in the High Capacity Second Paper Feeder. • Also check to see if there was a feeding of multiple sheets. • Carry out the recovery printing by opening and closing the cover to reset the error display.
Tray paper out	 Blinking  OFF  OFF	Notifies of no paper state of the High Capacity Second Paper feeder.	<ul style="list-style-type: none"> • Load the paper in High Capacity Second Paper Feeder.
Paper size request	 Blinking  OFF  OFF	Notifies correct paper size for the High capacity Second Paper Feeder.	<ul style="list-style-type: none"> • Load the requested size paper in the High Capacity Second Paper Feeder.


JAM Error Troubleshooting Flowchart

Paper Inlet Jam.




5. Connection Diagram

A. Interconnection Diagram




B. PCB Layout

GRT-PCB



6. Parts List


High Capacity Second Paper Feeder




A. High Capacity Paper Feeder List

No.	Description	Part Number	Q'ty.	Remark
1	Hopping roller shaft assy		1	
2	One-way clutch gear		1	
3	Stepping motor		1	
4	GRT PCB		1	
5	Cassette assy (2nd tray)		1	
6	DIN8P-DIN8P Connector Cord		1	


2nd Tray ASSEMBLY



SECTION1 CABINET & CASSETTE ASSEMBLY



SECTION2 MECHANICAL ASSEMBLY



B. 2nd Tray Parts List

No.	Description	Part Number	Q'ty.	Remark
1	Plate, upper		1	
2	Sheet guide assembly		1	
3	Front cover assembly		1	
4	Inner guide assembly		1	
5	Cassette assembly (2nd tray)		1	
6	Separation frame assembly		1	
7	Cover, rear		1	
8	Stick finger		1	
9	Hopping flame assembly		1	
10	Bush, metal (ADF)		1	
11	Gear (z70)		1	
12	Lever, sensor (p)		1	
13	Feed roller assembly		1	
14	Cable & connector		1	
15	Stepping motor		1	
16	Bracket		1	
17	Gear (z24)		2	
18	Gear (z87/z60)		1	
19	Plate, bottom		1	
20	2nd cassette guide (L) assy		1	
21	Hopping roller assembly		1	
22	2nd cassette guide (R) assy		1	
23	One-way clutch gear		1	
24	Board GRT		1	
25	Spring, Tension		1	
26	Lever, sensor (T)		1	
27	DIN8P-DIN8P Connector Cord		1	