

C710/MPS710 Maintenance Manual

072710C

Copyright Information

Copyright © 2010 by Oki Data. All Rights Reserved

Disclaimer

Every effort has been made to ensure that the information in this document is complete, accurate, and up-to-date. The manufacturer assumes no responsibility for the results of errors beyond its control. The manufacturer also cannot guarantee that changes in software and equipment made by other manufacturers and referred to in this guide will not affect the applicability of the information in it. Mention of software products manufactured by other companies does not necessarily constitute endorsement by the manufacturer.

While all reasonable efforts have been made to make this document as accurate and helpful as possible, we make no warranty of any kind, expressed or implied, as to the accuracy or completeness of the information contained herein.

The most up-to-date drivers and manuals are available from the web site:
<http://www.okiprintingsolutions.com>

Document Revision History

| Rev.No | Date | Corrected items | | | Person in charge |
|--------|------------|-----------------|--------|-----------------------------|------------------|
| | | No. | Page | Description of change | |
| 1 | 2008-05-07 | | | Issue | CSFP11 N. Sunaga |
| 2 | 2008-11-25 | | 61, 73 | Addition of "Warning", etc. | EP5 T. Sugiyama |
| 3 | 2009-01-09 | | | Drawing Maintenance | EP5 Y. Fujisawa |
| | | | | | |

| Rev.No | Date | Corrected items | | | Person in charge |
|--------|------|-----------------|------|-----------------------|------------------|
| | | No. | Page | Description of change | |
| | | | | | |

PREFACE

This manual provides an overview of method for maintaining the C710n.

This manual is intended for maintenance staff. For more information about how to operate the C710n, please refer to User 's manual.

- Note!**
- Manual may be revised and updated at any time without notice.
 - Unexpected mistakes may exist in the manual.
OKI will not assume any responsibility whatsoever for damage to the equipment repaired/adjusted/changed by the user etc with this manual.
 - The parts used for this printer may be damaged when handling inappropriately. We strongly recommend maintaining this machine by our registration maintenance staff.
 - Please operate the machine after removing static electricity.

Index

| | | | |
|--|-----------|--|--|
| 1. Configuration..... | 6 | | |
| 1.1 System configuration | 7 | | |
| 1.2 The Configuration of printer..... | 8 | | |
| 1.3 Optional parts | 9 | | |
| 1.4 Specifications | 10 | | |
| 1.5 Specification of interface | 13 | | |
| 1.5.1 Specification of USB interface | 13 | | |
| 1.5.1.1 General of USB interface | 13 | | |
| 1.5.1.2 Connector and cable of USB interface..... | 13 | | |
| 1.5.1.3 USB interface signal | 13 | | |
| 1.5.2 Specification of network interface | 14 | | |
| 1.5.2.1 General of network interface..... | 14 | | |
| 1.5.2.2 Connector and cable of network interface | 14 | | |
| 1.5.2.3 Signal of network interface | 14 | | |
| 1.5.3 Specification of parallel interface | 15 | | |
| 1.5.3.1 General of parallel interface..... | 15 | | |
| 1.5.3.2 Connector and cable of parallel interface | 15 | | |
| 1.5.3.3 Parallel interface level | 15 | | |
| 1.5.3.4 Signal of interface | 15 | | |
| 2. Operating instructions..... | 16 | | |
| 2.1 Electrophotographic processing mechanism..... | 17 | | |
| 2.2 Printing process..... | 21 | | |
| 3. Set up | 32 | | |
| 3.1 Notes and precautions..... | 33 | | |
| 3.2 Unpack method | 34 | | |
| 3.3 Setting method | 35 | | |
| Set space..... | 35 | | |
| 3.4 List of equipments and accessories | 36 | | |
| 3.5 Assembling method | 37 | | |
| 3.5.1 Assemble the main body of the printer | 37 | | |
| 3.5.2 Cable connect | 43 | | |
| 3.5.3 Optional part installation and confirmation..... | 45 | | |
| 3.6 Setting content print (Configuration)..... | 56 | | |
| 3.7 Connecting method | 57 | | |
| 3.8 User used Paper confirmation | 59 | | |
| 4. Component replacement | 60 | | |
| 4.1 Precautions on component replacement..... | 61 | | |
| 4.2 Method of component replacement..... | 63 | | |
| 4.2.1 Belt unit..... | 63 | | |
| 4.2.2 Fuser unit..... | 64 | | |
| 4.2.3 Left side cover..... | 64 | | |
| 4.2.4 Right side cover | 65 | | |
| 4.2.5 Faceup tray | 65 | | |
| 4.2.6 Rear cover..... | 66 | | |
| 4.2.7 LED Assy/ LED Assy spring..... | 66 | | |
| 4.2.8 Control PCB..... | 67 | | |
| 4.2.9 Print engine controller PCB..... | 68 | | |
| 4.2.10 Top cover Assy..... | 69 | | |
| 4.2.11 Top cover | 70 | | |
| 4.2.12 Control panel Assy | 70 | | |
| 4.2.13 Board PRG/ LCD | 71 | | |
| 4.2.14 Frame panel Assy | 72 | | |
| 4.2.15 Low voltage power supply/Low voltage FAN/ Hopping motor/ Fuse motor..... | 73 | | |
| 4.2.16 Guide eject Assy/ Color resist Assy/ Board-PRY | 74 | | |
| 4.2.17 FAN(Fuser) / Belt motor/ High-voltage board/ Cover open switch | 75 | | |
| 4.2.18 MPT Assy | 75 | | |
| 4.2.19 Feeder unit/ Board-RSF/MPT hopping roller/ Frame Assy separator/ Cover front | 76 | | |
| 4.2.20 Board-PRZ liftup motor/ Hopping motor/ Solenoid/Paper end sensor | 77 | | |
| 4.2.21 Feed roller..... | 78 | | |
| 4.2.22 Shaft eject Assy (FU)/ Shaft eject Assy(FD/ Eject sensor | 79 | | |
| 4.3 Oiling spots..... | 80 | | |

| | |
|---|------------|
| 5. Maintenance Menu | 91 |
| 5.1 System maintenance menu (for maintenance engineer) | 92 |
| 5.2 Maintenance Utilities | 93 |
| 5.3 Maintenance menu functions..... | 95 |
| 5.3.1 Self-diagnostic mode | 95 |
| 5.3.1.1 Operation panel | 95 |
| 5.3.1.2 Ordinary self-diagnostic mode (level 1) | 97 |
| 5.3.1.2.1 How to enter the self-diagnostic mode (level 1) | 97 |
| 5.3.1.2.2 How to exit the self-diagnostic mode | 97 |
| 5.3.1.3 Switch scan test..... | 98 |
| 5.3.1.4 Motor clutch test..... | 100 |
| 5.3.1.5 Test print..... | 102 |
| 5.3.1.6 Color registration correction test..... | 106 |
| 5.3.1.7 Density correction test | 107 |
| 5.3.1.8 Consumable item counter display..... | 109 |
| 5.3.1.9 Number of print copies counter display | 110 |
| 5.3.1.10 Switching between the Factory mode and the Shipping mode | 110 |
| 5.3.1.11 Self-diagnostic function setting..... | 111 |
| 5.3.1.12 LED head serial number display | 112 |
| 5.3.1.13 NVRAM parameter setting | 112 |
| 5.3.2 Various prints with the printer as a standalone unit | 112 |
| 5.3.3 Functions of keys at power on | 113 |
| 5.4 Setups upon completion of part replacement..... | 114 |
| 5.4.1 Precautions when replacing the engine control board..... | 114 |
| 5.4.2 EEPROM setting upon completion of CU board | 115 |
| replacement..... | 115 |
| 5.5 Density control manual setting | 116 |
| 5.6 Printer boot menu list..... | 117 |
| 6. Periodic Maintenance | 118 |
| 6.1 Cleaning | 119 |
| 6.2 How to clean the LED lens array | 120 |
| 6.3 How to clean the pickup roller | 122 |
| 6.4 How to clean inside of printer | 123 |

| | |
|--|------------|
| 7. Troubleshooting and repair procedure | 125 |
| 7.1 Before starting the repair work | 126 |
| 7.2 Confirmation items before taking corrective action against abnormalities | 126 |
| 7.3 Precautions when taking corrective action against abnormality | 126 |
| 7.4 Preparation for troubleshooting | 126 |
| 7.5 Troubleshooting method | 127 |
| 7.5.1 LCD message list..... | 127 |
| 7.5.2 Preparation for troubleshooting..... | 148 |
| 7.5.3 Troubleshooting the abnormal images..... | 180 |
| 7.5.4 Network troubleshooting | 187 |
| 7.5.4.1 Connection error occurs with the Web browser | 187 |
| 7.5.4.2 Print operation is not possible..... | 193 |
| 7.5.4.3 Cannot create Certificate | 194 |
| 7.5.4.4 Installation of Certificate is not possible..... | 194 |
| 7.5.4.5 Other questionnaires | 196 |
| 7.5.4.6 Restrictions when using Internet Explore 7 | 198 |
| 7.6 Fuse check | 199 |
| 7.7 Paper cassette switches versus Paper size correspondence table | 200 |
| 7.8 Data protection kit-A1 | 201 |
| 7.8.1 Data protection kit-A1 (DPK-A1) overview | 201 |
| 8. Connection diagrams..... | 205 |
| 8.1 Resistance value check | 206 |
| 8.2 Parts location..... | 210 |
| 8.3 F/W version number | 221 |
| 8.3.1 ROM control number..... | 221 |
| 8.3.2 ROM version check and display..... | 222 |
| 8.3.3 PCB Maintenance Indication Stamp | 222 |

1. Configuration

| | |
|--|----|
| 1.1 System configuration | 7 |
| 1.2 The Configuration of printer | 8 |
| 1.3 Optional parts | 9 |
| 1.4 Specifications | 10 |
| 1.5 Specification of interface | 13 |

1.1 System configuration

Figure 1-1-1 represents the system configuration of the printer.




Fig1-1

1.2 The Configuration of printer

The parts in the C710n are shown as below.

- Electrophotography process mechanism
- Paper feed path
- Control part (CU part/ PU part)
- Operator panel
- Power part (High-voltage part/low-voltage part)

The Configuration of the printer is shown in Fig 1-2.





Fig 1-2


1.3 Optional parts

The optional parts for this printer are shown as below.


- (1) Optional tray(second tray/ third tray)




- (2) Duplex Unit



- (3) Optional memory



- (4) Built-in hard disk
(Standard built-in hard disk, data protection kit A1)



1.4 Specifications

| Division | Item | |
|----------------|-------------------------------------|------------------------------|
| Dimension | Width | 435mm |
| | Depth | 536mm |
| | Height | 389mm |
| | Weight | About 28kg |
| Width of print | Width of print | Letter size, vertical |
| Print speed | Engine speed (A4) | 30PPM(Color) |
| | | 32PPM(Mono) |
| Print start | First print time | 8sec(mono), 9sec(color) (A4) |
| | Warmup time | 60sec |
| | Low noise mode | Unavailable |
| Resolution | LED head | 600dpi |
| | Maximum input resolution | 600×1200dpi |
| | Output resolution | True 600×1200dpi |
| | | True 600×600dpi |
| | Step | 4 step 600×600dpi |
| Econo mode | Save toner by decreasing brightness | |
| CPU | Core | PowerPC750 |
| | I-cash, / D-cash | L2=256KB |
| | Clock | 700MHz |
| | Bus width | 64bit |
| RAM | Resident | 256MB |

| Division | Item | |
|-------------------------------------|---|---|
| ROM | Program+font | 64MB |
| Power consumption | Input power supply | (120V)110~127VAC±10%, (230V)220~240VAC±10% |
| | Power save mode | Less than 17W |
| | Idle | 100W (Average) |
| | Usual operation | 530W (It differs from operating environment) |
| | Peak | 1200W |
| Operating environment (Temperature) | During operating | 10°C~32°C, 17°C~27°C (Temperature requirement for full-color print) |
| | During non-operating | 0°C~43°C, power off |
| | During keeping (for a year at most) | -10°C~43°C, with drum and toner |
| | During transferring (for a month at most) | -29°C~50°C, with drum, without toner |
| | During transferring (for a month at most) | -29°C~50°C, with drum, without toner |
| Operating environment (Humidity) | During operating | 20%~80%, 50%~70% (Humidity requirement for full-color print) The highest wet bulb temperature is 25°C |
| | During non-operating | 10%~90%, The highest wet bulb temperature is 26.8°C, power off |
| | During keeping | 10%~90%, The highest wet bulb temperature is 35°C |
| | During transferring | 10%~90%, The highest wet bulb temperature is 40°C |

| Division | Item | |
|----------------------------------|---|--|
| Operation life | Printer operation life | 600,000 pieces A4 transvers direction, 5years |
| | Print duty (M=L/12, A=L/12/5) | Max 100,000 pages / month Average 6,000 pages/ month |
| | MTBF (2.3% duty) | Unavailable |
| | MPBF | 50,000 pages |
| | MTTR | Within 20 minutes |
| | Toner operation life (5% duty) | Mounting toner: 4,000 pages(black), 4,000 pages (color) |
| | | Standard: 10,000 pages(black), 10,000 pages(color) S type: 5,000 pages(black), 5,000 pages(color) For the first new drum: about 9,200 pages(standard), 4,200 pages(S type) |
| | Image drum operation life | 20,000 pages (when 3 pages /job) 12,000 pages (when 1 page/job) 27,000 pages (when continuously print) Drum count all reset |
| Transcribing belt operation life | 60,000 pages (A4 transverse size, when 3 pages /job) count auto reset | |
| Fuser operation life | 60,000 pages (A4 size) count auto reset | |
| Operation sound | During operation | 55.6dBA (ISO 7779 front) (without option unit) |
| | During standby | 37dB(ISO 7779 front) |
| | Power save mode | Background level |

| Division | Item | |
|--------------------|---|---|
| Paper handling | Paper stack capacity (1st tray) | Legal /Universal cassette 530 pieces (70kg) |
| | Paper stack capacity (optional tray) | Legal /Universal cassette 530 pieces (70kg) |
| | Paper stack capacity (Manual/auto) | Standard multipurpose tray or 100 pieces (70kg), or 10 pieces of envelop |
| | Paper rejection | 350 pieces (70kg), facedown/ 100 pieces (70kg), faceup tray |
| | Duplex | Standard/ Option |
| | Paper size | A4, A5, B5, A6*, letter, legal(13/13.5/14), Executive, post card**, return post card**, custom***, envelope , Index card 3x5in, Photo size 4x6 5x7in * : The paper of A6 cannot be used in tray 1, 2, 3 **: The post card, return post card and envelope can be used in MPT only ***: As for custom, the available size can be adjusted by using different tray. The length is up to 1220mm. |
| Minimum paper size | Tray 1 | A5 |
| | Tray 2(option) | A5 |
| | Tray 3(option) | A5 |
| | MPT | Postcard |
| Thickness of paper | Tray 1 | 64g/m ² ~188g/m ² |
| | Tray 2(option) | 64g/m ² ~203g/m ² |
| | Tray 3(option) | 64g/m ² ~203g/m ² |
| | MPT | 64g/m ² ~220g/m ² |

| Division | Item | |
|----------------------------|----------------------------|--|
| Control panel | LCD | Resolution 128×64 dot graphic panel Paper size is not displayed |
| | LED (color) | 2 (Green×1, dark umbar×1) |
| | Switch | 8 |
| Status switch/ sensor | Paper out | Have |
| | Paper low | None |
| | Toner low | Have (Y, M, C, K) |
| | Cover open | Have |
| | Temperature of fuser | Have |
| | Paper size | Have (Manual setting) |
| | Stacker full | Have |
| Communication interface | Standard (On the PCB) | <ul style="list-style-type: none"> • Hi-Speed USB • Ethernet • Centronics |
| | Input and output switch | Auto |
| Emulation | Standard | PCL(PCL5c, HP-GL) / PCL XL2.1 |
| | | PostScript3 (Clone) |
| | Emulation switch | Auto |
| Font | Bitmap Typeface | Have |
| | Scalable font | Have |
| | Rasterizer | Have |
| | Barcode | Have |
| | OCR | Have |
| | Japanese PCL font | Have |
| | Japanese PS font | Have |

| Division | Item | |
|-------------------------------|---|---|
| Option (can be removed) | RAM | 256/512MB DIMM |
| | 2.5" IDE HDD It is possible to be installed by user | <ul style="list-style-type: none"> • Standatd built-in HDD • Data protection kit A1 |
| | Tray mechanism | 2nd tray mechanism, 3rd tray mechanism |
| | Cassette | Universal (530 pieces) |
| | Double print unit | Standard/ Option |
| | Others | Univailable |
| Others | USB-IF logo | Have |
| | Windows logo | Have |
| | UPS operation | The operation with UPS(Uninterruptible Power Supplies) is not guaranteed Please do not use the UPS |

1.5 Specification of interface

1.5.1 Specification of USB interface


1.5.1.1 General of USB interface

- (1) Spec.
USB (Support Hi speed USB)
- (2) Transmission mode
Full speed (Maximum 12Mbps 0.25%)
High speed(Maximum 480Mbps 0.05%)
- (3) Power control
Self power device

1.5.1.2 Connector and cable of USB interface

- (1) Connector
 - Printer side: B Receptacle (female)
Up-stream port
(UBR24-4K5C00 (made by ACON)) Equivalent goods

Connector pins array



- Cable side: B plug(male)

(2) Cable

The length of the cable: the cable of less than 5m with USB 2.0 spec.
(Less than 2m is recommended)
(Please use the shielded wire for the cable.)

1.5.1.3 USB interface signal

| | Signal name | Function |
|-------|-------------|-----------------------|
| 1 | Vbus | Power (+5V) |
| 2 | D- | For data transmission |
| 3 | D+ | For data transmission |
| 4 | GND | Signal Ground |
| Shell | Shield | |

1.5.2 Specification of network interface

1.5.2.1 General of network interface

Spec.

Network Protocol


| | |
|--------------|---|
| TCP/IP sepc. | Network layer ARP, IP, ICMP, IPv6 |
| | Transfer layer TCP, UDP |
| | Application layer LPR, Port9100, FTP, HTTP, HTTPS, IPP, SNMPv1/v3, TELENET, DHCP/BOOTP, DNS, DDNS, WINS, UPmP, Bonjour, SNTP, SMTP, POP, Windows Rally (WSD Print, LLTD). |
| NetBEUI: | SMB, NetBIOS |
| Netware: | Remote printer mode(Maximum 8 print sever) Print sever mode (Maximum 8 files sever: 32 queue) For encrypted password (when it is print sever mode) NetWare6J/5J/4.1J (NDS, bindery) SNMP |
| EtherTalk: | ELAP, AARP, DDP, AEP, NBP, ZIP, RTMP, ATP, PAP |
| IEEE802.1X: | EAP-TLS, PEAP |

1.5.2.2 Connector and cable of network interface

(1) Connector

100BASE-TX/10 BASE-T (Auto switch, cannot be used simultaneously)

Connector pins array



(2) Cable

Non-shield twisted-pair cable with RJ-45 connector
(Category 5 is recommended)

1.5.2.3 Signal of network interface

| Pin No. | Signal name | Direction | Function |
|---------|-------------|--------------|---------------------|
| 1 | TXD+ | FROM PRINTER | Transmission data + |
| 2 | TXD- | FROM PRINTER | Transmission data - |
| 3 | RXD+ | TO PRINTER | Receive data + |
| 4 | - | - | Not use |
| 5 | - | - | Not use |
| 6 | RXD- | TO PRINTER | Receive data - |
| 7 | - | - | Not use |
| 8 | - | - | Not use |

1.5.3 Specification of parallel interface

1.5.3.1 General of parallel interface

Spec.

IEEE1284-1994 conforming parallel interface

| Item | Content |
|-----------------|--|
| Related mode | Compatible mode, nibble mode, and ECP mode |
| Data bit length | Compatible: 8, nibble: 4, ECP: 9bit |

1.5.3.2 Connector and cable of parallel interface


(1) Connector

Printer side : 36-Pole connector (Female)

57LE-40360-12(D56) (made by DDK) equivalent goods

Cable side : 36-Pole connector (male)

57FE-30360-20N(D8) (made by DDK) equivalent goods



Pin layout seen from interface cable side

(2) Cable

IEEE1284-1994 cable of less than 1.8m is used.

(For avoiding noise interference, please use shielded cable with the twisted-pair wire.)

1.5.3.3 Parallel interface level

Low level 0.0V~+0.8V

High level +2.4V~+5.0V

1.5.3.4 Signal of interface

| Pin NO. | Name of signal | Direction | Function |
|---------|-----------------------------|--------------|---|
| 1 | nStrobe (HostClk) | TO PRINTER | It is a pulse to read data. Data is read by posterior end. |
| 2~9 | DATA 1~DATA 8 | Bi-direction | It is parallel data of 8 bits. The high level is "1", and the Low level is "0". |
| 10 | nAck(PtrClk) | FROM PRINTER | It is a signal that shows the data reception completion. |
| 11 | Busy(PtrBusy) | FROM PRINTER | It is a signal that shows if the printer is receiving the data. Data cannot be received when it is at the high level. |
| 12 | PError(AckDataReq) | FROM PRINTER | The paper error is shown when it is at the high level. |
| 13 | Select(Xflag) | FROM PRINTER | When parallel interface is effective, it is always in high-level state. |
| 14 | nAutoFd(HostBusy) | TO PRINTER | It is used by the bidirectional communication. |
| 15 | - | - | Not use |
| 16 | GND | - | Signal ground |
| 17 | FG | - | Chassis ground |
| 18 | +5V | FROM PRINTER | It cannot supply power outside. |
| 19~30 | GND | - | Signal ground |
| 31 | nInit(nInit) | TO PRINTER | The printer is initialized with the low level. |
| 32 | nFault(nDataAvail) | FROM PRINTER | When the printer is in alarm state, it becomes low level. |
| 33 | GND | - | Signal ground |
| 34 | - | - | Not use |
| 35 | HILEVEL | FROM PRINTER | It is pulled up to +5V at 3.3KΩ in the printer. |
| 36 | nSelectIn (IEEE1284 active) | TO PRINTER | It is used by bidirectional communication. It must be low level when it is in compatible mode. |

- Notes!**
- The signal name showed in the bracket is a signal name in nibble mode.
 - It only describes the function in compatible mode.
 - The nibble mode of IEEEstd1284-1994 regulated by Institute of Electrical and Electronics Engineers is supported. Using the computer and the cable unsupported this standard may lead to unexpected operation.

2. Operating instructions

| | |
|---|----|
| 2.1 Electrophotographic processing mechanism..... | 17 |
| 2.2 Printing process..... | 21 |

2.1 Electrophotographic processing mechanism

(1) Electrophotographic processing

The general of Electrophotography process is described as below.

1. Charging

The voltage is impressed to CH roller, and the surface of OPC drum is electrified.

2. Exposure

LED head irradiates light to the image signal on the surface of the electrified OPC drum. The electricity of the irradiated part on the surface of the OPC drum is attenuated by changing in light intensity, the electrostatic latent image is formed on the surface of the OPC drum.

3. Development

The electrified toner adheres to the electrostatic latent image of the OPC drum by electrostatic force, and the image is developed on the surface of the OPC drum.

4. Transfer

The paper is overlapped on the surface of the OPC drum, and the electricity is generated on the back of the paper by transfer roller, the toner image is transcribed to the paper.

5. Fusing

Heat and pressure are applied to the toner image on the paper in order to make it fusing.

6. Drum cleaning

The drum cleaning blade removes the toner left on the OPC drum after transfer.

7. Electricity removal


The electric potential left on the drum is removed.

8. Belt cleaning

The belt cleaning blade removes the toner left on the belt.


(2) Charging

The voltage is impressed to the charging roller in contact with the surface of OPC drum, and the surface of OPC drum is charged.



(3) Exposure


The light generated from LED head is irradiated onto the surface of the electrified OPC drum. The electricity of the irradiated part on the surface of the OPC drum is attenuated by changing in light intensity, the electrostatic latent image is formed on the surface of the OPC drum.



(4) Development

The toner adheres to the electrostatic latent image on the surface of the drum, and the electrostatic latent image is changed into the toner image.

1. The sponge roller makes the toner adhere to the developing roller.




2. The electrostatic latent image on the surface of the OPC drum surface is visualized by toner.

(5) Transfer

The paper is overlapped on the surface of the OPC drum, and the electricity is generated on the back of the paper by transfer roller.


When high voltage is impressed from the power supply to the transfer roller, the electricity induced in the transfer roller is moved to the surface of the paper via contact surface, and the toner is drawn from the surface of the OPC drum to the surface of the paper.



(6) Fusing


When the paper passes through the heat roller and backup roller unit, heat and pressure are applied to the toner image on the paper and the toner is fused onto the paper.

The halogen lamps of 800W and 300W are built in heat roller. The backup roller without built-in halogen lamp is heated by the heat transmission from the heat roller. The fusing temperature is controlled by the temperature detected by the thermistor that is not in contacting with the surface of the heat roller. On the other hand, the temperature detected by the thermistor rubbing the surface of backup roller is used for controlling the fusing temperature under specified conditions. Furthermore, a thermostat is used to limit the temperature rise, if the temperature rise of heat roller exceeds a set point, the thermostat would be open and the voltage supply to the heater would be cut off. The backup roller unit is pressed on the heat roller by the spring on both sides.




(7) Drum cleaning

The Unfused toner left on the OPC drum is cleaned up by the drum cleaning blade, and all residual toner is collected in the waste toner area of the toner cartridge.




(8) Electricity removal

The electricity on the surface of the OPC drum is attenuated by irradiating the light to the surface of the OPC drum after transfer.



(9) Belt cleaning

The toner left on the transport belt is cleaned up by the belt cleaning blade, and all residual toner is collected in the waste toner box of the transport belt unit.




2.2 Printing process

The paper fed from tray 1 or tray 2, tray.3 is transferred by feeder roller, resister roller L, and transfer roller. It is transferred by MPT paper feed roller and resister roller U when the paper is fed from MPT. After that, the paper on the belt passes through the electrophotography process of KYMC, and sequentially the unfused toner image is generated on the paper. And then, the toner is fused by heat and pressure when it is passed through the fuse unit. After fusing, the paper is delivered to the faceup or facedown stacker by utilization of different delivery methods by opening or closing the faceup stacker.

The operation of single-sided printing is described as above. The operation of duplex printing is described as below.

As for the duplex print, the paper passed the fuse unit after initially back printing is drawn into the Duplex unit by separator DUP. The paper entered into the paper reversing path is transferred from the paper reversing path to the inside of Duplex by reverse operation of reversal roller. The paper passed over the inside of Duplex is fed from paper feed path of Duplex by the transfer roller set in the transfer path of Duplex inside, which is shared with the same paper feed path from the tray. The following operation is same as single-sided printing with paper feeding from the tray.



(1) Paper feed from 1st tray

1. As shown in Fig.2-1, while the solenoid is set as ON, the paper-feeding motor is rotated (counter clockwise) to transfer the paper until the IN1 sensor is turned ON. (When the solenoid is turned ON, the paper-feeding roller is driven.)
2. After the IN1 sensor is turned ON, a certain amount of paper is transferred and the resist roller L is bumped. (In this process, the skew of the paper is compensated.)
3. As shown in Fig.2-2, the solenoid is turned OFF, and the paper is transferred by resist roller L. (When the solenoid is turned OFF, the resist roller L is driven.)




Figure 2-1




Figure 2-2

(2) Paper feed from MPT

1. As shown in Fig.2-3, while the solenoid is set as OFF, the paper-feeding motor is rotated (clockwise) to transfer the paper until the IN2 sensor is turned ON. (When the paper-feeding motor is rotated clockwise, the MPT paper-feeding roller is driven.)
2. After the IN2 sensor is turned ON, a certain amount of paper is transferred and the resist roller U is bumped. (In this process, the skew of the paper is compensated.)
3. As shown in Fig.2-4, the paper-feeding motor is rotated (counter clockwise), and the paper is transferred by resist roller U. (When the paper-feeding motor is rotated counter clockwise, the resist roller U is driven.)




Figure 2-3




Figure 2-4

(3) Transport belt

1. When the transport belt motor is rotated in the direction of the arrow, the transport belt is driven. As for the belt unit, a transfer roller is set over under each color drum. The belt is caught and installed between the transfer roller and drum.

As for the transport belt and transfer roller, if the specified voltage is impressed, the paper on the transport belt would be delivered to the fuser unit while transcribing the toner image on each color drum.




Figure 2-5

(4) Updown operation of ID unit

1. The up and down operation of the ID unit is done by driving the liftup motor.
2. Fig. 2-6 shows the operation of each ID unit when color printing. When the liftup motor is rotated (counter clockwise), the liftup link slides to left, and each ID unit is in DOWN condition as shown in Fig. 2-6. Under this condition, the color printing is available.
3. Fig. 2-7 shows the operation of each ID unit when mono printing. When the liftup motor is rotated (clockwise), the liftup link slides to right, and each ID unit (except K-ID unit) is in UP condition as shown in Fig. 2-7. Under this condition, the mono printing is available.

The operation of each ID unit when color printing

C-ID unit DOWN
 M-ID unit DOWN
 Y-ID unit DOWN
 K-ID unit DOWN




Figure 2-6

The operation of each ID unit when mono printing

C-ID unit Liftup
 M-ID unit Liftup
 Y-ID unit Liftup
 K-ID unit DOWN




Figure 2-7

(5) Fuse unit and paper delivery

1. The fuse unit and the delivery roller are driven by the DC motor as shown in Fig. 2-8. When the fuse motor is rotated (counter clockwise), the heat roller will begin to rotate. The heat roller makes the toner image fused to the paper by heat and pressure.
2. The paper exits while the delivery roller rotates.




Figure 2-8

(6) Cover open operation of color blur sensor and density sensor

1. As shown in Fig. 2-9, when the fuse motor is rotated (clockwise), the cover open gear is operated and the cover of color blur sensor and density sensor is open.
2. When the fuse motor is rotated (counter clockwise) in the opposite direction, the cover open gear is moved out of engagement and the cover of color blur sensor and the density sensor is close.




Figure 2-9

General of color blur correction


The color blur correction is operated by reading the pattern for correction printed on the belt with a sensor set in the sensor shutter under the belt unit.

The pattern is detected by this sensor, and the correction is operated.

Color blur correction auto-start timing

- When the power is on
- When the cover is closed after the cover is opened once
- When more than 400 copies are printed or when more than 6 hours have elapsed since the last print

The amount of toner of the pattern, the toner left on the sensor and the open-close trouble of the shutter etc. may lead to correction error. However, as the error message may not display even if the error is occurred, it is necessary to perform the color blur correction (see 5.3.2.6) by the utilization of the self-diagnostic mode and confirm the error display.



Error-confirming method and Error-solving method

Use the color blur correction test function in self-diagnostic mode to confirm the error. (See 5.3.1.6)

Error solving method

- CALIBRATION(L or R), DYNAMICRANGE(L or R)

Check 1: When the above display appears, please check the connection of sensor cable (FFC).

When the connection is abnormal, please set it properly.

Check 2: Please check if the surface of the sensor is dirty with the toner and paper melts etc.

Check 3: Please confirm if the open and close operation of sensor shutter is normal by utilization of MOTOR&CLUTCH TEST in self-diagnostic mode. Exchange the shutter unit when the open and close operation is in trouble.

If there are no problems in check 1, 2, and 3, please check the circuit.

Please exchange the color adjust sensor PCB, relay PCB, PU PCB, and the cable one by one, and then check if the error is displayed.

- BELT REFLX ERR

Check 4: When this display appears, please check the cleaning of the toner left on the surface of the belt after finishing the above-mentioned check 1, 2, and 3. Remove the belt unit, and rotate the left inboard drive gear. Please confirm that the surface of the belt is cleaned completely.

When the residual toner left on the surface of the belt could not be cleaned completely even if the drive gear is rotated, please exchange the belt unit.

- (Y or M or C) LEFT, (Y or M or C) RIGHT, (Y or M or C) HORIZONTAL

Check 5: When the above display appears, please confirm if the toner of NG color is empty.

Please exchange the toner cartridge as required.

General of the density correction


The density correction is operated by reading the pattern for correction printed on the belt with a sensor set in the sensor shutter under the belt unit.

Density correction auto-start timing

- The environment is remarkably different from last time when the power is on.
- When one or more ID count among the four ID count show the status of new part, at the power on
- The ID count value exceeds 500-count from last operation.
- When one or more UD is replaced with the new ID.
- When the belt is replaced with the new belt
- When toner cartridge is replace due to Toner Low, or Toner Empty so that Toner Low or Toner Empty has disappeared

The amount of toner of the pattern, the toner dirt and the open-close trouble of the shutter etc. may lead to correction error.

However, as the error message may not display even if the error is occurred, it is necessary to perform the density correction (see 5.3.1.7) by the utilization of the self-diagnostic mode and confirm the error display.



Error-confirming method and Error-solving method

Use the density correction test function in self-diagnostic mode to confirm the error.

(See 5.3.1.7)

Error solving method

- CALIBRATION ERR, DENS SENSOR ERR

Check 1: When the above display appears, please check the connection of sensor cable.

When the connection is abnormal, please set it properly.

Check 2: Please check if the surface of the sensor is dirty with the toner and paper melts etc.

Please wipe the dirt off if the sensor is dirty.

If there are no problems in check 1, 2, and 3, please check the circuit.

Please exchange the density sensor, relay PCB, PU PCB, and the cable one by one, and then check if the error is displayed.

- DENS SHUTTER ERR

Check 3: Please confirm if the open and close operation of sensor shutter is normal by utilization of MOTOR&CLUTCH TEST in self-diagnostic mode. Exchange the shutter unit when the open and close operation is in trouble.

- DENS ID ERR

Check 4: Remove the ID unit, and confirm if the toner abnormally leaves on the surface of the drum.


Exchange LED head (Focus control). Or exchange the ID unit.

When a new ID unit is tried to use, please set the fuse keep mode of the maintenance menu.

Toner sensor detection principle

Toner low is detected by the toner sensor (reflect sensor) installed in the equipment. The light board is installed in ID, and its rotation is synchronized with the mixing of toner. Moreover, the shutter is installed in ID. Toner cartridge set properly by the lever of toner cartridge and synchronized toner sensor can be detected.

The following problems may lead to abnormal detection and the toner sensor error is occurred.



Toner count principle

After the image data is transformed into binary data which can be printed by the printer, the data is counted as print dot number by LSI. The amount of the used toner is calculated from this count value, and the residual amount is displayed on the menu.

Toner LOW detection (residual amount display on LCD) by the toner sensor is to detect a certain amount of the reduction of the toner left in ID.

The principle of ID counter, belt counter, fuse counter

- ID counter : when 3 pieces of A4 paper are continuously printed, one third of the rotation of the drum is set as one count.
- Belt counter : when 3 pieces of A4 paper are continuously printed, one third of the rotation of the drum is assumed as one count.
- Fuse counter : The length of paper of legal 13 inch is set as nominal value. If the length of paper is less than this nominal value, it is assumed as one count. If the length of paper is more than this nominal value, the counted number is determined by the times of legal 13 inch. (The number after decimal point is rounded up.)

Counter spec

| | Total printed page number | MPT printed page number | Tray 1 printed page number | Tray 2 printed page number | Tray 3 printed page number | Color-printed page number | Mono-printed page number |
|---|---|--|---------------------------------------|---------------------------------------|---------------------------------------|---|---|
| Description | Total printed page number | Hopping page number from MPT | Hopping page number from Tray1 | Hopping page number from Tray2 | Hopping page number from Tray3 | Printed page number by color-printing | Printed page number by mono-printing |
| Count method A4 conversion or size independence | Count up after passing the writing sensor | Count up if MPF(MPT) hopping is finished | Count up if Tray1 hopping is finished | Count up if Tray2 hopping is finished | Count up if Tray3 hopping is finished | The page number is counted up by detecting the paper passing the fuser in color-printing mode after the job is finished. (1*) The value is A4/Letter value. Please refer to A4/ Letter conversion table (P31). | The page number is counted up by detecting the paper passing the fuser in mono-printing mode after the job is finished. (1*) The value is A4/ Letter value. Please refer to A4/ Letter conversion table (P31). |
| Operation when paper jammed | Cannot count when paper feeding (hopping) jam and feed jam are occurred. It can count except the above-mentioned jam. As total printed page number is counted up when the front end of the page passes the writing sensor, according to the jam type, the feeding jam (380) is also included in the limits for counted. | | | | | Cannot count if the jam is occurred before the paper passes the fuser. It can count if the jam is occurred after the paper passes the fuser. | |
| Operation for Duplex | Front/Back count(+2) | Only front count (+1) | | | | Double count If the color page and mono page exist together, the color printing page number would be plus 1 and the mono printing page number would be plus 1. | |
| Reset condition | None | None | | | | 1)When "Format Flash ROM" of system maintenance menu is performed. 2) When CU PCB is replaced. 3) When MENU RESET of system maintenance menu is performed. 4) When CU PCB is replaced. | |
| Value storage destination | PU | PU | PU | PU | PU | CU | CU |
| Menu/MenuMap output | ○ (*2) | ○ | ○ | ○ | ○ | ○ | ○ |
| EngineMenuMap output | ○ | ○ (*3) | ○ (*3) | ○ (*3) | ○ (*3) | - | - |

*1. Count cannot be updated if the power is turned off when the jam is occurred.

*2. In the initial state MenuMap output is not available. It is possible to switch in the system maintenance menu.

*3. EngineMenuMap output divides into Engine Menu Print (the first page) and Engine EEPROM Dump Print (the last page), however, the number of paper fed from each tray is output only to the latter one (DUMP display only).

A4/Letter conversion table

The paper is counted up as this sheet.

| Paper size | Simplex | Duplex |
|--------------------------|---------|--------|
| LETTER | 1 | 2 |
| EXECUTIVE | 1 | 2 |
| LEGAL14 | 1 | 2 |
| LEGAL13.5 | 1 | 2 |
| LEGAL13 | 1 | 2 |
| A4 | 1 | 2 |
| A5 | 1 | 2 |
| A6 | 1 | - |
| B5 | 1 | 2 |
| COM-9 | 1 | - |
| COM-10 | 1 | - |
| MONARCH | 1 | - |
| DL | 1 | - |
| C5 | 1 | - |
| CUSTOM | 1 | 2 |
| CUSTOM LENGTH > 330mm | 2 | 4 |
| CUSTOM LENGTH > 900mm | 4 | - |

3. Set up

| | |
|--|----|
| 3.1 Notes and precautions..... | 33 |
| 3.2 Unpack method | 34 |
| 3.3 Setting method | 35 |
| 3.4 List of equipments and accessories | 36 |
| 3.5 Assembling method | 37 |
| 3.6 Setting content print (Configuration)..... | 56 |
| 3.7 Connecting method | 57 |
| 3.8 User used Paper confirmation | 59 |

3.1 Notes and precautions

Warning

- Do not set it in any high-temperature locations or near any heat sources.
- Do not set it in a place where the chemical reaction may occur (laboratory etc.).
- Do not set it near any liquid that may ignite such as alcohol and thinner.
- Do not keep it out of reach of children.
- Do not place it on an unstable or uneven surface (unstable table and slanting place, etc.).
- Do not put it in direct sunshine. And do not put it in a moist or dusty place.
- Do not set it in wet or corrosive environment.
- Do not set it in a place where may cause vibration.
- If the printer is dropped down or the cover is damaged, please pull out the power plug from the outlet and contact the customer center.
This may cause an electric shock, fire, injury.
- Please read this manual carefully before connecting the power supply cable, printer cable, ground cable.
This may cause fire.
- Do not insert any foreign objects into the vent hole.
This may cause an electric shock, fire, injury.
- Do not put a vessel(s) filled with water on the printer.
This may cause an electric shock, fire.
- Do not touch the fuser unit when you open the cover of the printer.
It is hot and could cause burns.
- Do not throw the toner cartridge, the image drum cartridge into the fire.
It may cause burns due to dust explosion.
- Do not use inflammable sprays near the printer.
It may cause fire because some parts in the printer may become very hot.
- If the cover becomes abnormally hot, smoke rises, it smells strange or it sounds abnormal, please pull out the power plug from the outlet and contact the customer center.
It may cause fire.

Warning

- If the liquid such as water enters the printer, please pull out the power plug from the outlet and contact the customer center. It may cause fire.
- If you drop the foreign objects such as clip in the printer, please pull out the power plug from the outlet and take the foreign objects out.
This may cause an electric shock, fire, injury.
- Do not disassemble the printer unless following the correct procedure written in the manual. This may cause an electric shock, fire, injury.

Caution

- Do not set it in a place where the vent hole of the printer is blocked.
- Do not set it directly on heavy wool or shag carpet.
- Do not place it in locations of poor ventilation such as enclosed areas.
- Give particular attention to adequate ventilation care when using it continuously in a narrow room for a long time.
- Do not place it close to strong magnetic fields and noise source.
- Do not place it next to the monitor and television.
- Hold tightly the both sides of the printer when you move the printer.
- Because the weight of the printer is approximately 33kg (in a state of packing), it needs more than two adults to lift it up.
- Do not come close to the paper exit part while printing.
This may cause injury.

Please explain the safety precautions about installation and handling with showing the all precautions in user's manual to customer. Especially, the details about power supply cable and the ground cable must be explained completely.

3.2 Unpack method




Warning

Personal injuries may occur.



Because the weight of the printer is approximately 33kg
(in a state of packing), it needs more than two adults to lift it up.

- Take out the gripe on each side as shown in the following figure, and lift the cardboard box up.




3.3 Setting method

- Set the printer under these conditions.
 - Surrounding environment: : 10~32°C
 - Surrounding humidity: : 20~80%RH (Relative humidity)
 - Highest wet bulb temperature: : 25°C
- Protect the printer from dew formation.
- Use the humidifier or the static electricity prevention mats etc. when setting the printer in the environment where the humidity is 30% or less.


Set space

- The flat desk should be wide enough to put the printer on.
- Ensure that there is enough room around the printer for proper ventilation.

Plan view




Side view




3.4 List of equipments and accessories

- Make sure that the appearance of the equipment is not damaged or dirty etc.
- Make sure that the following accessories are supplied with your printer.
- If you are missing any of these accessories, contact your customer service department immediately.




Because the weight of the printer body is approximately 28kg (33kg in a state of packing), it needs more than two adults to lift it up.

- Printer (Body)



- Image drum cartridge (1 Cyan, 1 the magenta, 1 yellow, and 1 black)
(mounted in the printer)



Explain to the customer that the toner cartridge and the image drum cartridge can be separated.

- Printer software CD-ROM
- Power supply cord
- Guarantee card and user registration card
- User's manual (Setup)
- User's manual (CD-ROM)


Notes! The printer cable is not included.

3.5 Assembling method


3.5.1 Assemble the main body of the printer

Remove the protective materials.


- (1) Peel off the desiccant and the protection tape (four places) on the printer.



- (2) Peel off the paper on the front of printer.




- (3) Peel off the protection tape (2 places) on the back of the printer.




- (4) Confirm that the duplex print unit is fixed tightly.


- (5) Pull the paper cassette out.



- (6) Pull the retainer out in the direction of the arrow (1). Return the paper cassette to the main body of the printer.




- (7) Press down the OPEN button, and open the top cover.



- (8) Remove the stopper (orange) when pressing down the lever of the fuser unit (blue) in the direction of arrow ①.

Note! If you do not use the printer for a long time or transport it, please use the stopper. Please keep it carefully.




Set the image drum cartridge.


- (1) Take the image drum cartridge (four) out slowly.

Note!


- The image drum (green cylinder) is very fragile. Please pay special attention to handling it.
- Do not expose the image drum cartridge to direct sunshine and strong light (about 1500 lux). And do not expose it to room light for more than 5 minutes.



- (2) Put the image drum cartridge on the newspaper etc, peel off the tape of protection sheet 1 and pull it out in the direction of the arrow.




- (3) Pull the protection sheet 2 out from image drum cartridge in the direction of arrow.




- (4) Remove all protection sheets from the image drum cartridge.

(5) Return the image drum cartridge back to the printer.




(6) Close the top cover.




Note! If the message of [please exchange the toner] on the control panel doesn't disappear indefinitely, please make sure that the lever of the toner cartridge is fully moved in the direction of the arrow.

Set the paper into the paper cassette.

- (1) Pull out the paper cassette.
Do not peel off the rubber attached to the plate.
- (2) Adjust the paper stopper and the paper guide to match the size of the paper, and then fix them tightly.




- (3) Flex the paper back and forth. Do not fold or crease the paper. Straighten the edges on a level surface.



- (4) Place the paper in the cassette with the side to be printed facing down.


- Notes!**
- Place the paper with the top of the page nearest the paper cassette tab.
 - Do not place the paper higher than the "▽" mark on the paper guide. (530 pieces for 70kg paper)

- (5) Place the paper in position by paper guide.
- (6) Rotate the paper size dial to match the paper.
- (7) Return the paper cassette back to the printer.




Set the paper in multi-paper tray.


- (1) Open the multi-paper tray, and open the paper supporter.



- (2) Match the manual insertion guide to the size of the paper.
 (3) Flex the paper back and forth. Straighten the edges on a level surface.




- (4) Place the printed side facing up, and insert the paper along the manual insertion guide straightly until bumping up.



Note! Set papers so that paper should not exceed the "▽" mark. (100 sheets of paper with ream weight of 70 kg or 10 envelopes)


- (5) Press down the set button.



3.5.2 Cable connect

Power condition

- Keep the following items.
AC voltage : 110~127V \pm 10%/ 220~240V \pm 10%
Frequency of the power supply : 50Hz or 60Hz \pm 2Hz
- Use the voltage adjusting transformer etc. when the power supply is unstable.
- The maximum power consumption of this printer is 1,200W. Confirm the power supply can provide enough power.
- The operation with UPS (uninterruptible power supplies) is not guaranteed. Explain to the customers that do not use UPS (uninterruptible power supplies).


| | | |
|---|---------------------------------------|--|
| Warning | It may cause an electric shock, fire. |  |
| <ul style="list-style-type: none"> • Installation and removal of the power supply cord and the ground cable must be performed after pressing down the power switch to OFF. • Please connect the ground cable with a specified ground terminal. Please contact the dealer if you cannot get it. • Be careful not to connect it with the lightning rod, the water pipe, the gas pipe, and the earth of the telephone wire. • Connection of the ground terminal must be performed before inserting the power plug into the power outlet. And, removal of the ground terminal must be performed after pulling the power plug out of the power outlet. • Please hold the power plug to disconnect or plug in the power supply cord. • Please insert the power plug firmly into the outlet. • Do not pull out or plug in the power plug with wet hands. • Do not locate the printer in a place where the cord may be abused by persons walking on, and do not place the heavy objects on the power cord. • Do not use the power supply cord that is bundled or connect the power supply with an extension cord. • Do not use a damaged power supply cord. • Do not use a multiple outlet extension cord. • Please connect this printer into an outlet different from that to which other electric products is connected. Especially, the operation of the printer might be affected by the electrical noise when the printer is connected simultaneously with the air-conditioner, the copier and shredder etc. Please use the noise filter or the noise cut-off transformer sold at the market if you have to connect the printer into a same outlet. • Please use the attached power cord and insert it into the outlet directly. Do not use an unspecified power cord. • Do not use an extension cable. Please use a cable that is more than 15A current rating if you have to use an extension cable. • If the extension cord is used, the printer might operate abnormally by the decrease of AC voltage. • Do not unplug the power cord or switch off the power during printing. • Please unplug the power cord if you do not use the printer for a long time (long vacation or travel etc). • Do not use the attached power cord of this printer to the other electric products. | | |

Explain completely the connection of the power supply cable and the ground cable with showing the user's manual to customer.


Connect the power cord.

Note! Confirm that the power switch is turned to OFF "O".

- (1) Insert the power cord into the printer.




- (2) Connect the ground cable with the ground terminal of the outlet.




Warning It may cause an electric shock. 

The ground cable must be connected.

- (3) Insert the power plug into the outlet.



Press down the power switch to ON (|).





If the printer is completely started up, the message "Can print" would be displayed on the control panel shown as follows.


Note! When the printer is getting cold, it may lead to error if the power is turned on. (Error number 126,171,175,177,320). At this time, please turn off the power and wait for a while, and then turn on the power again.


Turn the power off.

Note! If you turn off the power without properly shutting down, it may cause damage to the printer. Please follow the following procedure to turn the power off.

- (1) Press down the  [Return] switch for more than 4 seconds, the [shutdown menu] message would display.



- (2) Press down the  [Set] switch.
If the message [shutdown] is displayed, the shutdown operation would start.
- (3) If the message [Turn off the power/shutdown completely] is displayed, press down the power switch to OFF "O".




When you do not use the printer for long time

Please explain to the customer about the following items.

Unplug the power cord if you do not use the printer for a long time (long vacation or travel etc).
Install the stopper to the fuser.

Note! Please remove the ground terminal after pulling the power plug out of the power outlet.




Note! Even if the power plug of this printer is pulled out for a long time (four weeks or more), the functional problems will not be caused easily. However, please explain to the customer that the deterioration of consumable such as toners and the image drums is not guaranteed.

3.5.3 Optional part installation and confirmation

(1) Installation of the optional tray unit (second/ third tray)

It is a traditional paper tray for adding paper into printer.

530 pieces of 70kg paper can be set. Using it with a standard paper cassette and a multi-purpose tray can print 1690 pieces of pages continuously.



(1)-1. Turn the printer power to OFF and pull out the power cord from the outlet.


Turn the power off with following the procedure in chapter 3.5.2 [Turn the power off.].

- Notes!**
- If you turn off the power without properly shutting down, it may cause damage to the printer. Please operate the [shutdown menu].
 - It may cause damage to the printer, if you install the optional tray with power ON.


(1)-2. Install the optional tray unit to the printer.

Note! Because the weight of the printer body is approximately 31kg, it needs more than two adults to lift it up.

- ① Match the tab into the hole in the bottom of the printer.
- ② Put the printer on the optional tray unit slowly. Please remove it following the steps 1-2 in reverse order.



Note! When you install two optional trays to the printer, set the optional tray directly on top of the other optional tray, and then put them on the printer.



(1)-3. Connect the power cord and printer cable to the printer and turn the power on.

Note! If the message [SERVICE CALL182:FATAL ERROR] is displayed, reinstall the optional tray unit.

(1)-4. Print the setting content and confirm if the option tray unit is installed properly.

- ① Print the setting content with following the procedure in chapter 3.6.
- ② Confirm the content of [tray 2] is display in header part.

```

Tray Sequence : Down
Unit of Measurement : millimeter
Tray1 Config
Paper Size : Cassette Size
Media Type : Plain
Media Weight : Medium Light
Tray2 Config
Paper Size : Cassette Size
Media Type : Plain
Media Weight : Medium Light
  
```

Note! If the content of [tray 2] is not displayed, reinstall the second tray unit.


(1)-5. Set the number of tray by the printer driver.

The printer driver setup for recognizing the option tray unit is required.

If the printer driver is not set up, please set up the printer driver completely referring to the user's manual (Setup) firstly, and then finish the following setting procedure.

Note! The authority of the computer administrator is required.

For windows PS printer driver



(For Windows XP)

- ① For Windows Vista, click on [start] => [control panel] => [printer].
For Windows XP, click on [start] => [control panel] => [printer and other hardware] => [printers and faxes].
For WindowsServer 2003, click on [start] => [printers and faxes].
For Windows 2000, click on [start] => [Settings] => [printers].
- ② Click the [C710(PS)] icon with right-click button on your mouse and choose the [Properties].
- ③ Choose [get information from printer] from [installable options] in [Device options] tab, and click [setup] or [get information from printer]. For USB connection, set [Optional paper source] manually.
- ④ Click [OK].

For Windows PCL XPS printer driver




(For Windows XP)

- 1 For Windows Vista, click on [start] => [control panel] => [printer].
For Windows XP, click on [start] => [control panel] => [printer and other hardware] => [printers and Faxes].
For WindowsServer 2003, click on [start] => [printers and faxes].
For Windows 2000, click on [start] => [Settings] => [printers].
- 2 Click [C710(**)] (** is PCL or PCL XPS (printer driver type)) icon with right-click button on your mouse and choose [Properties].
- 3 Choose [get information from printer] in [Device options] tab. For USB connection, input the optional tray number in [Optional devices] manually.
- 4 Click [OK].

For Macintosh

When the optional device has been added into in Macintosh before installing the printer driver, the device information is gotten automatically. Please finish the following procedure to set up the optional device, if you want to add an optional device after installing the printer driver.

For network connection



- 1 Select the printer in [select], and click [reset].
- 2 Click [Configurations].
- 3 Choose [Optional paper source], and click [OK].
- 4 Close [select].

For USB connection

- 1 Drag the printer icon on the desktop to the Recycle Bin, and empty it.
- 2 Use the desktop printer Utility to reset desktop printer. If desktop printer is reset, the setting should also be updated.


Memo Please refer to [desktop printer setup] of [Set up for USB connection in Macintosh] in user's manual (Setup) for the desktop printer setup method.

For Mac OS X

When the optional device has been added into in Mac OS X before installing the printer driver, the device information is gotten automatically. However, if the printer is connected by [IP print] and [Bonjour (Rendezvous)], the device information could not be gotten automatically.

If the printer is connected by [AppleTalk], the device information could also not be gotten automatically when the optional device has been added into in Mac OS X before installing the printer driver.

Please finish the following setting procedure for above.




- 1 Double-click [Applications] for hard disk => [utility] => [print setting utility] ([Applications] => [Utility] => [print center] in Mac OS X)
- 2 Select [C710], click [Show info] and open [printer info].
- 3 Choose [installable options].
- 4 Select the [Optional paper source], and click [Apply].
- 5 Close [printer info].

(2) Installation of duplex unit

This unit is used for printing on two sides of paper.


Note! For two-sides printing, it is recommended to add expansion memory. For details, see "Expansion memories."

Type: DXU-C4D




(2)-1. Turning OFF the printer power and disconnecting the power cord

Note! If an expansion memory is installed with the power switched ON, the printer may be broken.




(2)-2. Peeling the protective tapes off the duplex unit



(2)-3. Install Duplex Unit

- ❶ Insert the duplex unit into the lower part on the back of the printer as far as it will go.
- ❷ Ensure that the claw on either side of the duplex unit is securely accommodated in the hole of the printer.




(3) Add the optional memory.

It is used to increase the memory capacity of the printer.

Please add the optional memory as following problems occur:

“Out of memory” error [memory overflow] occurs when printing complex data.

Combination print error occurs when printing the whole file at once.



Optional memory

| Type name | Memory capacity (Total memory capacity) |
|-----------------|--|
| None (Standard) | 256MB (256MB) |
| MEM256E | +256MB (512MB) |
| MEM512C | +512MB (768MB) |


- Notes!**
- The operation cannot be guaranteed when using an unspecified product. Please use OKI product.
 - It is recommended to add 256MB optional memory when long size printing.
 - The slot for memory is one slot.

(3)-1. Turn the power of printer off, and pull out the power cord.

Turn off the power with following the procedure in chapter 3.5.2 [Turn the power off].


- Notes!**
- If you turn off the power without properly shutting down, it may cause damage to the optional memory. Operate the [shutdown menu].
 - It may cause damage to the printer, if you install the optional memory with power ON.

(3)-2. Open the top cover and front cover.



OPEN button


- ① Press down the OPEN button, and open the top cover.



Multi-purpose tray

Handle


- ② Open the multi-purpose tray.




Front cover

- ③ Pull up on the handle (blue) at the center of the front cover, and open the front cover forward.

(3)-3. Remove the side cover.




(3)-4. Install the memory.



- Notes!**
- Do not touch any electrical parts and terminals of connectors.
 - Be careful to install the memory in the proper direction. A notch on the terminal of the memory is matched to the connector of the slot.


(3)-5. Install the side cover.



(3)-6. Connect the power cord and printer cable to the printer, and turn the power on.

Note! If the message [SERVICE CALL031:FATAL ERROR] is displayed, please reinstall the memory.


(3)-7. Print the setting content and confirm if the optional memory is installed properly.



- ① Print the setting content with following the procedure in chapter 3.6.
- ② Confirm the total memory capacity displayed in [Total Memory] of [System] part.

Note! If total memory capacity displayed in [Total Memory] is incorrect, please reinstall the memory.

(4) Install the built-in hard disk.



Note! Be careful that the font cannot be downloaded.

There are 2 types of built-in hard disk as C710n options.

- Standard built-in hard disk (Type name: HDD-C1B)
 It is a built-in hard disk added to the printer.
 It is used under following conditions:
 Authentication print, print job save, buffer print operate
 Combination print error occurs when printing the whole file at once.
- Data protection kit-A1 (Type name: DPK-A1)
 Please refer to chapter 7.8.


One of the above hard disks could be installed.

(4)-1. Turn the power of printer off, and pull out the power cord.


Please turn off the power with following the procedure in chapter 3.5.2 [Turn the power off].

- Notes!**
- If you turn off the power without properly shutting down, it may cause damage to the printer. Please operate the [shutdown menu].
 - It may cause damage to the printer, if you install the optional memory with power ON.


(4)-2. Open the top cover and front cover.



- 1 Press down the OPEN button, and open the top cover.




- 2 Open the multi-purpose tray.




- 3 Pull up on the handle (blue) at the center of the front cover, and open the front cover forward.

(4)-3. Remove the side cover.




- 1 Loosen the screw (one place).
- 2 Remove the side cover.
Pull it outward to remove while holding the upper edge of the side cover to lift.

(4)-4. Install the built-in hard disk.



- ① Insert the tab of the built-in hard disk into the slot on the printer.
- ② Fix the disk with screws (2 places).
- ③ Push the connector into the slot until a slight click is heard.


(4)-5. Install the side cover.



- ① Install the side cover.
- ② Fix the side cover with the screw. (one place)
- ③ Close the top cover and front cover.

(4)-6. Connect the power cord and printer cable to the printer, and turn the power on.

(4)-7. Print the setting content and confirm if the built-in hard disk is installed properly.



- ① Print the setting content with following the procedure in chapter 3.6.
- ② Confirm the built-in hard disk capacity displayed in [HDD].

Memo The capacity of built-in hard disk might be different from the example of the above figure.

Note! Please reinstall the built-in hard disk when the capacity of HDD is not displayed.

Note! Read the manual of the hard disk when you install the built-in hard disk for IC card authentication.

Note! Read the manual of the kit when you install data protection kit-A1.


And, the printer driver setup for recognizing the built-in hard disk is required.

If the printer driver is not set up, please set up the printer driver completely referring to the user's manual (Setup) firstly, and then finish the following setting procedure.

(4)-8. Set [hard disk] by printer driver

Note! The authority of the computer administrator is required.

For windows PS printer driver



(For Windows XP)

- ① For Windows Vista, click on [start] => [control panel] => [printer].
For Windows XP, click on [start] => [control panel] => [printer and other hardware] => [printers and Faxes].
For WindowsServer 2003, click on [start] => [printers and faxes].
For Windows 2000, click on [start] => [Settings] => [printers].
- ② Click the [C710(PS)] icon with right-click button on your mouse and choose the [Properties].
- ③ Choose [get information from printer] from [installable options] in [Device options] tab, and click [setup] or [get information from printer]. For USB connection, set [Hard disk] as [Install] manually.
- ④ Click [OK].

For Windows PCL XPS printer driver



(For Windows XP)


- ① For Windows Vista, click on [start] => [control panel] => [printer].
For Windows XP, click on [start] => [control panel] => [printer and other hardware] => [printers and Faxes].
For WindowsServer 2003, click on [start] => [printers and faxes].
For Windows 2000, click on [start] => [Settings] => [printers].
- ② Click [C710 (PCL)] icon with right-click button on your mouse and choose [Properties].
- ③ Choose [get information from printer] in [Device options] tab. For USB connection, select the option [Hard disk] manually.
- ④ Click [OK].

For Macintosh

When the optional device has been added into in Macintosh before installing the printer driver, the device information is gotten automatically.

Please finish the following procedure to set up the optional device, if you want to add an optional device after installing the printer driver.

For network connection



- ① Select the printer in [select], and click [reset].
- ② Click [Configurations].
- ③ Set [Hard disk] as [Install], and click [OK].
- ④ Close [select].

For USB connection

- ① Drag the printer icon on the desktop to the Recycle Bin, and empty it.
- ② Use the desktop printer Utility to reset desktop printer. If desktop printer is reset, the setting should also be updated.

Memo Please refer to [desktop printer setup] of [Set up for USB connection in Macintosh] in user's manual (Setup) for the desktop printer setup method.

For Mac OS X

When the optional device has been added into in Mac OS X before installing the printer driver, the device information is gotten automatically. However, if the printer is connected by [IP print] and [Bonjour (Rendezvous)], the device information could not be gotten automatically.

If the printer is connected by [AppleTalk], the device information could also not be gotten automatically when the optional device has been added into in Mac OS X before installing the printer driver.

Please finish the following setting procedure for above.







- ① Double-click [Applications] for hard disk => [utility] => [print setting utility] ([Applications] => [Utility] => [print center] in Mac OS X)
- ② Select [C710], click [Show info] and open [printer info].
- ③ Choose [installable options].
- ④ Select the [Hard disk] option, and click [Apply].
- ⑤ Close [printer info].
- ⑥ Confirm the added printer is shown in [Printer list], and close [print center].



(For Mac OS X 10.2, choose the added printer, and select the option [Hard disk] of [Installable options] panel in [Show info] menu of [Printer], and click [Apply].)

3.6 Setting content print (Configuration)


To confirm the printer operates normally, please print the [Configuration].

- (1) Set A4 paper in tray.
- (2) Press the  button for several times so that [printer Information] is displayed, and press down the  button.
- (3) Press the  button and select [Configuration], press down the setting button.
- (4) Press down the  button.

The setting content print is started.

Memo When printing the network setting information (2 pieces Network Information), press the  button after (2), and press down the  button after [Network] is displayed.

(C710n sample)




3.7 Connecting method

<USB connection>

Note! Please refer to user's manual for operation environment.

Prepare for USB cable

- Notes!**
- The printer cable is not included.
Provide the USB2.0 cable for special user.
 - When connecting the cable in [Hi-Speed] mode of USB 2.0, please use the USB cable with Hi-Speed spec.
 - Select the USB cable of less than 5m. It is recommended to use the USB cable of less than 2m.




Turn the printer and computer OFF.

Memo Although USB cable can plug-and-play with computer and printer power on, after this the setup of printer driver and USB driver may be required. Here the printer is turned off to plug-and-play the USB cable.

Connect the computer to the printer.

- (1) Insert the USB cable into the USB interface connector of printer.
- (2) Insert the USB cable into the USB interface connector of computer.

Note! Do not insert the USB cable into the network interface connector. It may cause trouble.



USB Interface connector


Memo Please refer to user's manual for setup of printer driver.

< Ethernet cable connection >

Note! Refer to user's manual for operation environment.

Prepare for Ethernet cable

Note! The Ethernet cable and Hub is not included in printer.
Provide the Ethernet cable and Hub for special user.




Turn the printer and computer OFF.

Connect the computer to the printer.

- (1) Insert the Ethernet cable into the network interface connector of printer.
- (2) Insert the Ethernet cable into Hub.


Memo Refer to user's manual for setup of printer driver.




< Parallel connection >

Prepare for Ethernet cable

Note! The parallel cable is not included in printer. Provide it for special user.




Turn the printer and computer OFF.



Connect the computer to the printer.

- (1) Insert the parallel cable into the parallel interface connector of printer, and Lock it firmly by metal fittings.
- (2) Insert the parallel cable into the parallel interface connector of computer, and fix it firmly with screws.



3.8 User used Paper confirmation

Load the paper used by user, set the media type/weight, print the setting content/demo, and confirm if the toner is chipped off.

| Type | Thickness | settings of control panel | | [Thickness of paper] settings of printer driver*2 |
|----------------|--------------------------------------|-----------------------------------|------------------------------|---|
| | | Media weight (Thickness of paper) | Media type (Type of paper)*1 | |
| Plain paper*3 | 55~64kg (64~74g/m ²) | Light | Plain paper | Light |
| | 65~70kg (75~82g/m ²) | Medium Light | | Medium Light |
| | 71~89kg (83~104g/m ²) | Medium | | Medium |
| | 90~103kg (105~120g/m ²) | Heavy | | Heavy |
| | 104~162kg (121~188g/m ²) | Ultra heavy1 | | Ultra heavy1 |
| | 163~189kg (189~220g/m ²) | Ultra heavy2 | | Ultra heavy2 |
| Post card*4 | — | — | — | — |
| Envelope*4 | — | — | — | — |
| Label paper | Less than 0.1~0.17mm | Heavy | Label paper | Label paper1 |
| | 0.17~0.2mm | Ultra heavy1 | | Label paper2 |
| Transparencies | — | — | Transparency film | Transparency film |

*1 : The factory default setting of media type of the printer is set as [plain paper].

*2 : The thickness and type of paper could be set by control panel and printer driver. The settings set by printed driver have priority. When [Paper feed method] is selected as [Auto select] or [Paper thickness] is set as [print setting] in the printer driver, the print operation is set by control panel.

*3 : The thickness of the paper for duplex printing is 55~103kg (64~120g/m²).

*4 : The setting of media weight and media type for postcard and envelope is not required.

Memo If the media weight is set as [Heavy] or [Ultra Heavy1, 2], or the media type is set as [label paper], the print speed would be reduced.

4. Component replacement

In this chapter, the procedures for replacement of part and assembly and unit are described.

The replacement procedure is described by removal of the parts. Please install the new parts with following the replacement procedure in reverse order.

The parts (such as ①, ②) shown in this manual are different from the parts used in the Disassembly for Maintenance figure (43856301TL) and RSPL (43856301TR).

| | |
|--|----|
| 4.1 Precautions on component replacement | 61 |
| 4.2 Method of component replacement | 63 |
| 4.3 Oiling spots | 80 |

4.1 Precautions on component replacement

(1) Remove the AC cord and the interface cable before replacing the parts.

(a) Remove the AC cord according to the following procedure.

- ① Switch the power switch of printer off "O".
- ② Disconnect the AC insertion plug of the AC power cord from the AC power source.
- ③ Disconnect the earth wire from the earth terminal of the AC power source outlet.
- ④ Disconnect the AC cord and the interface cable with the printer.



There is a risk of electric shock during replacement of the low voltage power supply. Use insulating gloves or avoid direct contact with any conducting part of the power supply, and caution should be exercised during replacement.

The capacitor may take one minute to complete discharge after the AC cord is unplugged. Also, there is a possibility that the capacitor doesn't discharge because of a breakage of the PCB, etc., so remember the possibility of electric shock to avoid electric shock.

(b) Reconnect the printer according to the following procedure.

- ① Connect the AC cord and the interface cable with the printer.
- ② Connect the earth wire to the earth terminal of the AC power source outlet.
- ③ Connect the AC power cord insertion plug to the AC power source outlet.
- ④ Switch the power switch of printer on "I".

(2) Do not disassemble it if the printer works normally.

(3) Disassemble it as required. Do not remove the part that is not shown in the replacement procedure.


(4) Please use the specified maintenance tool.

(5) Disassemble it according to the proper procedure. It may cause damage to the parts if disassemble it without following the proper procedure.

(6) As the small parts such as the screws are lost easily, please fix them to the original position temporarily.

(7) Do not use gloves that may cause static electricity easily when handling IC and the circuit board such as microprocessor, ROM, and RAM.








(8) Do not put the PCB on the device and the floor directly.



[Maintenance tool]

The required tools for replacing the PCB and the unit are shown in Table 4-1-1.




Table 4-1-1 Maintenance tools

| No. | Maintenance tools | Amount | Purpose | Note |
|-----|---|--------|-------------------------|------------------------------|
| 1 |  No. 2-200 ⊕ Magnetic driver | 1 | 3 - 5mm Screw | |
| 2 |  No. 3-100 Driver | 1 | | |
| 3 |  No. 5-200 Driver | 1 | | |
| 4 |  Digital multimeter | 1 | | |
| 5 |  Combination pliers | 1 | | |
| 6 |  Handy cleaner (the type corresponds to the toner) | 1 | | Refer to the following note. |
| 7 |  E Ring pliers | 1 | For E ring detaching | |

Note! Use the specified cleaner corresponding to the toner. It may cause a fire when using a general-purpose cleaner.

The required tools for using the maintenance utility are shown in Table 4-1-2.

Table 4-1-2 required tools


| No. | Maintenance tools | Amount | Purpose | Note |
|-----|---|--------|---------|---|
| 1 |  Notebook Please install the maintenance utility. | 1 | | Refer to the chapter 5.2 for the maintenance utility. |
| 2 |  USB cable | 1 | | |
| 3 |  Ethernet cable (Cross cable) | 1 | | |

4.2 Method of component replacement


In this chapter, the replacement of parts and assemblies is described by the disassemble figures.


4.2.1 Belt unit


- (1) Open the top cover.
- (2) Remove the ID unit ①.



Note! Cover the removed image drum cartridge with black paper.




- (3) Rotate the lock lever (blue, 2 places) of the belt unit ② in the direction of arrow , and hold the lever (blue) to remove the belt unit.




4.2.2 Fuser unit

- (1) Open the top cover.
- (2) Push up the fix lever of fuser unit in the direction of arrow, and remove the fuser unit ①.




4.2.3 Left side cover

- (1) Open the top cover.
- (2) Open the feeder unit.
- (3) Remove the screw ① (silver), and remove the left side cover ②.




4.2.4 Right side cover

- (1) Open the top cover.
- (2) Open the feeder unit.
- (3) Loosen the screw ① and remove the right side cover ②.




4.2.5 Faceup tray

- (1) Draw out the duplex unit ①.
- (2) Open the faceup tray ② in the direction of arrow, and unlock the left and right pins while bending. Remove the faceup tray ②.




4.2.6 Rear cover

- (1) Open the faceup tray.
- (2) Remove the two screws ① (silver).
- (3) As shown in fig 2, insert the minus driver into the hole A to disengage the claw A (2 place).
- (4) Disengage the claw B (2 places) and pull the upper side of the rear cover ② in the direction of A.
- (5) As shown in fig 3, push the lower side of the rear cover ② in the direction of B, and disengage the claw C (3 places) to remove the rear cover ②.



4.2.7 LED Assy/ LED Assy spring


- (1) Open the top cover
- (2) After removing the cable, as shown in fig 2, push the LED assy ① tightly in the direction of arrow. Take the hook A out firstly, and then take the hook B out, at last remove the LED assy.
(At this time, the two springs ② is removed with LED Assy ①.)



4.2.8 Control PCB


- (1) Open the top cover.
- (2) Remove the right side cover. (See section 4.2.4)
- (3) Remove the Rear cover. (See section 4.2.6)
- (4) Remove the eight screws ① (silver), remove the connector and disengage the claw A to take the plate-shield-Assy (PCL) ② out.
- (5) Remove the two screws (silver) ⑦, and remove the HOST USB PCB ⑨ by holding the tip of nylon stud ⑧ with a pair of pliers.
- (6) Remove the screw ③ and disconnect the head cable ④.
- (7) Remove the seven screws ⑤ (silver) and all cables, and take the control PCB ⑥ out.



Note! To attach the head cable, insert the end of the film-FG inside the plate-side-R, preventing from touching the edge of the plate-side-R.



4.2.9 Print engine controller PCB


- (1) Remove the plate shield Assy (PCL). (See section 4.2.8(1)-(3))
- (2) Remove all connectors and two screws ① (silver) to take the print engine controller PCB ② out.






4.2.10 Top cover Assy

- (1) Remove the left side cover. (See section 4.2.3)
- (2) Remove the right side cover. (See section 4.2.4)
- (3) Remove the rear cover. (See section 4.2.6)
- (4) Remove the plate shield Assy (PLD/GDI) and take the control PCB out. (See section 4.2.8 (1)-(7))
- (5) Remove the connectors of the stack full sensor cable and ID-FAN cable, remove the connector and the hanging RFID cable ①.
- (6) Remove two E type stop rings ② and two torsion springs ③, and remove the top cover Assy ④.




4.2.11 Top cover

- (1) Remove the top cover Assy. (See section 4.2.10)
- (2) Remove ten screws ① (Black), and remove the top cover ②.




4.2.12 Control panel Assy

- (1) Open the top cover.
- (2) Insert the minus driver into the upper side of the slit (3 places) to disengage the claws on the control panel Assy ①, remove the connector and take the control panel Assy ① out.




4.2.13 Board PRG/ LCD

- (1) Remove the control panel Assy. (See section 4.2.12)
- (2) Remove the screws ① (2 places), remove the connector and cable of LCD ③ and remove the Board PRG ②.
- (3) Remove the screws ④ (2 places), and remove the LCD ③.




4.2.14 Frame panel Assy

- (1) Open the top cover.
- (2) Open the feeder unit.
- (3) Remove the right side cover. (See section 4.2.4)
- (4) Remove the plate shield Assy. (See section 4.2.8 (3))
- (5) Remove the connector of frame panel Assy and remove the hanging cable.
- (6) Remove the control panel Assy. (See section 4.2.12)
- (7) Remove the two screws ① (silver), disengage the claws (3 places) on frame panel Assy, and remove the frame panel Assy ②.



- (8) Remove the lever lock ③, compression spring ④, torsion spring ⑤, button switch ⑥, cable Assy ⑦ from the frame panel ⑧.



4.2.15 Low voltage power supply/Low voltage FAN/ Hopping motor/ Fuse motor





There is a risk of electric shock during replacement of the low voltage power supply.

Use insulating gloves or avoid direct contact with any conducting part of the power supply, and caution should be exercised during replacement.

The capacitor may take one minute to complete discharge after the AC cord is unplugged. Also, there is a possibility that the capacitor doesn't discharge because of a breakage of the PCB, etc., so remember the possibility of electric shock to avoid electric shock.

- (1) Take the cassette Assy out.
 - (2) Remove the print engine controller PCB. (See section 4.2.9)
 - (3) Remove the control PCB. (See section 4.2.8)
 - (4) Remove all cables from Guide cable PowerLow.
 - (5) Remove the fuse I/F connector from low voltage power supply, disengage the claws (2 places), and remove the Guide cable PowerLow ①.
 - (6) Remove the two screws ② (silver) and four connectors (CN1, CN2, CN3), and remove the low voltage power supply ③.
- At the same time, remove the screw ④ and remove the AC inlet Assy ⑤.
- (7) Disengage the claw C and remove the low voltage FAN ⑥.
 - (8) Disengage the claw D(2 places) and claw E, and remove the motor cover ⑦.
 - (9) Remove the 3 or 4 screws ⑩ (silver) and connector, and take the fuse motor ⑪ out.
 - (10) Remove the three screws ⑫ (silver) and connector, and take the ID motor ⑬ out.


- Notes!**
- Be careful to install the low voltage FAN ⑥ in the proper direction.
 - Please confirm the setting of AC input voltage when installing the low voltage power supply ③.
 - 100V: the short plug is mounted to the connector CN6
 - 230V: the short plug is not mounted to the connector CN6
 - Low-voltage power supply ③ and AC Inlet Assy ⑤ should be replaced together. (The pair of low-voltage power supply and AC Inlet Assy meets the safety standards.)
 - The number of screws varies between fuser motors.
 - Three screws: 43963301 (Sanyo)
 - Four screws: 43070601 (Nidec)



Note! CN6: A connector used to switch the AC input voltage setting
100V short plug is mounted/ 230V short plug is not mounted.


4.2.16 Guide eject Assy/ Color resist Assy/ Board-PRY

- (1) Remove the left side cover, right side cover, rear cover, top cover Assy. (See section 4.2.3, 4.2.4, 4.2.6, 4.2.10)
- (2) Remove the print engine controller PCB, control PCB and low-voltage power supply. (See section 4.2.8, 4.2.9, 4.2.15(3))
- (3) Remove the connector of belt thermistor, remove the two torsion springs ①, and disengage four claws (4 places) by minus driver, remove the cover driver ②.
- (4) Remove the screws ③ (silver) and connectors (6 places), remove the Board PRY ④.
- (5) Remove the two screws ⑤ (silver) and remove the color resist Assy ⑥.
- (6) Remove the two screws ⑦ (silver), remove the cable ⑧ of fuse I/F connector from clamp, and slide the claw of cable guide ⑨ to disengage, remove the guide eject Assy ⑩.




4.2.17 FAN(Fuser) / Belt motor/ High-voltage board/ Cover open switch

- (1) Remove the left side cover. (See section 4.2.3)
- (2) Remove the screw ① (silver) and connector, and remove the belt motor ②.
- (3) Remove the connector, and rotate the FAN (Fuser) ③ clockwise to remove.
- (4) Remove the connector and disengage the claw A (2 places), and remove the cover open switch ④.
- (5) Remove the 2 screws ⑤ and connectors (2 places), and disengage the claw B (7 places). Remove the high-voltage power supply ⑥.




4.2.18 MPT Assy

- (1) Open the MPT Assy ①.
- (2) Remove the stoppers (2 places) while pushing the arms (2 places) on MPT Assy ① outside, pull the supporters (2 places) in the direction of the arrow and remove them, and remove the MPT Assy ①.




4.2.19 Feeder unit/ Board-RSF/MPT hopping roller/ Frame Assy separator/ Cover front


- (1) Open the top cover.
- (2) Remove the plate shield and remove the connector. (See section 4.2.8)
- (3) Disengage the claws of stay L ① and stay R ②, slide the feeder unit ③ to right and remove it.
- (4) Remove the motor cover. (See section 4.2.15)
- (5) Disengage the claw, and remove the cover sensor ④.
- (6) Remove the connector and remove the Board-RSF ⑤.
- (7) Remove the MPT Assy. (See section 4.2.18)
- (8) Rotate until the claw of lever ⑥ is disengaged, and remove it.
- (9) Remove the two screws (Black), and remove the stay L ①.
- (10) Remove the four screws ⑧ (Black), disengage the claw B (2 places), and remove the feeder Assy ⑨.
- (11) Remove the two lock shafts ⑩ and two springs ⑪, and disengage the claws (4 places) and remove the guide Assy ⑫.
- (12) Remove the hopping roller shaft ⑬.
- (13) Remove the supporters (2 places), and remove the frame Assy separator ⑭ and spring ⑮.



4.2.20 Board-PRZ liftup motor/ Hopping motor/ Solenoid/ Paper end sensor

- (1) Remove the left side cover, right side cover, rear cover, top cover unit, feeder unit. (See section 4.2.3, 4.2.4, 4.2.6, 4.2.10, 4.2.19)
- (2) Remove the print engine controller PCB, control PCB. (See section 4.2.8, 4.2.9)
- (3) Remove the guide cable Power Low, low-voltage power supply, low-voltage FAN. (See section 2.2.15)
- (4) Remove the cover driver, Board-PRY, color resist Assy, eject Assy. (See section 4.2.16)
- (5) Remove the two screws ① (silver), and remove the plate driver ②.
- (6) Remove the connector of 2ND tray and remove the hopping cover ③.
- (7) Remove the FAN(Fuser). (See section 4.2.17)
- (8) Remove the latches (2 places) and remove the gear ④, remove the latch and remove the gear ⑤, remove the gear ⑥ of latch and remove the shaft ⑦.
- (9) Remove the two screws ⑧ (silver) and remove the side plate R Assy ⑨.
- (10) Remove the ten screws ⑩ (silver), outer plate ⑪, two gear idle IDs ⑫, two gear idle IDs ⑬, two gears ⑭, gear ⑮, two colors ⑯, one washer ⑰, gear ⑱, ⑲, ⑲, ⑲, and spring ⑳ of solenoid.
- (11) Remove the latches (2 places), and remove the guide Assy side R ㉓ while slide it up.
- (12) Remove the screw ㉔ (silver), and remove the plate lockout ID ㉕ and four screws ㉖, remove the inner plate ㉗.
- (13) Remove the two screws ㉘ (silver) and connector, and remove the liftup motor ㉙.
- (14) Remove the screw ㉚ (silver) and remove the solenoid ㉛.
- (15) Remove the screw ㉜ (silver) and remove the hopping motor ㉝.
- (16) Remove the paper end sensor lever ㉞, the end sensor lever spring ㉟, remove the paper end sensor ㊱ and remove the connector.






⑨ Side plate Assy


4.2.21 Feed roller

- (1) Remove the cassette.
- (2) Remove the latch and remove the feed roller (2 pieces)①.



4.2.22 Shaft eject Assy (FU)/ Shaft eject Assy(FD/ Eject sensor

- (1) Remove the eject Assy. (See section 4.2.16)
- (2) Disengage the claws (2 places), and disassemble the Assy into guide eject lower ① and guide eject upper ②.
- (3) Remove the gear idle eject ③, ④, ⑤, ⑥ and remove the shaft Assy eject (FU) ⑦ and shaft Assy eject (FD) ⑧.
- (4) Remove the lever eject sensor ⑨ and eject sensor ⑩.



4.3 Oiling spots

This chapter shows the oiling spots. Do not oil the other spots that are not shown here.

It is not necessary to inject the machine-oil during disassembling. However, please add the specified oil when you wipe the oil off.

Oiling operation

(1) Oil type and name


EM-30L: MOLYKOTE

HP-300: MOLYKOTE


PM: Pan motor oil 10W-40 or ZOA 10W-30

(2) Grease limit sample


| Class | S | A | B | C | D | E | F |
|-----------------------|--------|-------|-------|------|------|------|------|
| Spreading amount (cc) | 0.0005 | 0.003 | 0.005 | 0.01 | 0.03 | 0.05 | 0.1 |
| W(mm) | 1.24 | 2.25 | 2.67 | 3.37 | 4.86 | 5.76 | 7.26 |
| Sample | • | • | • | • | • | • | • |




① Plate-Assy.-Base




② Gear-Assy.-HP





③ Gear-Planet-Assy.




④-1 Plate-Assy. -Side R




④-2 Plate-Assy.-Side R




④-3 Plate-Assy.-Side R




④-4 Plate-Assy.-Side R




④-5 Plate-Assy.-Side R




⑤ Plate-Assy.-Side L




⑥ Holder Assy.-Regist-L




⑦ Holder Assy.-Regist-R



⑧ Fuser Assy




⑨ Guide-Assy. -Eject-U




⑩-1 Printer Unit-PX741


EM-30L Class C
Spread MOLYKOTE (EM-30L)
evenly on the front end of terminals.





⑩-2 Printer Unit-PX741




⑪ Belt-Assy.



⑫ Sensor Assy. -Color Regist




⑬ Roller-Assy. -Idle(FD)




Grease spreading method

EM-30L Class S
After installing ① to ②, please spread a thin layer of MOLYKOTE (EM-30L) on the sliding surfaces (patching parts) of ① and ②.




⑭ Roller-Assy. -BIAS(FU)C




Grease spreading method


EM-30L Class S
 After installing ③ to ②, please spread a thin layer of MOLYKOTE (EM-30L) on the sliding surfaces (patching parts) of ① and ②.



⑮ Cassette-Assy-PX741



EM-30L Class B
 Apply a small amount of MOLYKOTE(EM-30L) to sliding portions of sheet metal and shaft(the hatched area)



5. Maintenance Menu

Adjustment of this printer can be performed from the Maintenance Utilities by entering the corresponding menu from the keyboard of the operator panel.

This printer contains the maintenance menu in addition to the normal operation menus. Select an appropriate menu in accordance with the objective of adjustment.

| | |
|--|-----|
| 5.1 System maintenance menu (for maintenance engineer) | 92 |
| 5.2 Maintenance Utilities | 93 |
| 5.3 Maintenance menu functions..... | 95 |
| 5.4 Setups upon completion of part replacement..... | 114 |
| 5.5 Density control manual setting | 116 |
| 5.6 Printer boot menu list..... | 117 |

5.1 System maintenance menu (for maintenance engineer)

While pressing the MENU+ and MENU- keys, turn on the power to enter the maintenance menu.

The menu indications are shown in English only regardless of the destination of the printer.

Note! The system maintenance menu is internally use only, and should not be disclosed to end user because destination and other parameters can be modified using this menu.

Table 5-1 Maintenance menu function table

| Category | Item (1st Line) | Value (2nd Line) | DF | Function |
|--------------------|------------------|--|------------|--|
| System Maintenance | Enter Password | ***** ***** | 000 000 | Enter the password to enter the system maintenance menu. Default value is "000000". A password can be entered in the range of 6- to 12-digit alphanumeric. For more details, refer to the "Password" sheet. |
| OKIUSER | OKIUSER | ODA OEL APS JP1 JPOEM1 OEMA OEML | * | Set the destination. JPOEM1 : Japanese OEM OEMA : Overseas OEM outside Japan of A4 size default OEMA : Overseas OEM outside Japan of the Letter size default When the printer exits the menu, the printer reboots automatically. |
| Maintenance Menu | | | | [Display condition] Encrypted hard disk function is disabled. |
| | Format HDD | Execute | - | Initializes the hard disk. When this menu item is executed, the system exits the menu and starts initializing the hard disk. [Display condition] HDD is installed. ("Boot Menu" - "Storage Setup" = "Enable HDD" is set to "YES".) |
| | Format Flash ROM | Execute | - | Initializes the flash ROM. When this menu item is executed, the system exits the menu and starts formatting the flash memory device that is installed resident (on-board). * Use of this menu item is prohibited. |
| | Reset EEPROM | Execute | - | Returns the EEPROM contents to the setup by the manufacturer when shipped from the factory (factory default profile) value. Upon completion of the setting change, the system reboots automatically. * Some specific items are not initialized. |

| Category | Item (1st Line) | Value (2nd Line) | DF | Function |
|------------------------|------------------------|-------------------|----|---|
| Maintenance Print Menu | Maintenance Print Menu | Enable Disable | * | Selects whether or not to display "Print Information" - "ID Check Pattern" and "Engine Status". When this menu item is set to "Disable", the function menu "Print Information" - "ID Check Pattern" and "Engine Status" are not displayed all the time. When exiting this menu upon completion of setting change, the printer reboots automatically. |
| Fuse Keep Mode | Fuse Keep Mode | Execute | - | When the ENTER key is pressed, the command is issued from CU to PU to set the system in ON LINE. Replace the consumable part with the new part while the power is turned on. (In this case, fuse of the new consumable part is not cut, and the operational counts are reset so that the count value of old consumable part is not added.) The check mode is terminated when the power is turned off. The check mode is disabled when the power is turned on next time. |
| Personality | IBM 5577 | Enable Disable | * | Changes the default of Support PDL per brand. PDL which is "Disable" in this menu is not displayed at "Print Setup" - "Personality" of Function menu. INVALID DATA shows up and received data is abandoned when print data of PDL which is "Disable" is received. |
| | IBM PPR III XL | Enable Disable | * | |
| | EPSON FX | Enable Disable | * | |
| | HP-GL/2 | Enable Disable | * | |
| Change Password | | | - | Changes the password. When the ENTER switch is pressed after entering in this menu, the messages "NEW PASSWORD" and "VERIFY PASSWORD" are displayed enabling user to enter a new password. |
| | New Password | ***** ***** | - | Sets the new password to enter the maintenance menu. A password can be entered in the range of 6- to 12-digit alphanumeric. |
| | Verify Password | ***** ***** | - | Prompting user to verify the new password that has been set by "NEWPASSWORD", to enter the system maintenance menu. A password can be entered in the range of 6- to 12-digit alphanumeric. |
| Diagnostic Mode | | | - | Enters the self-diagnostic mode. |

5.2 Maintenance Utilities

The maintenance utilities enables user to perform the adjustment shown in Table 5-2.

Details of the maintenance utilities are available in the following documents.

- (1) Maintenance Utilities Operation Manual:
 42678801FUOI Rev18 and higher (Japanese)
 42678801FUO2 Rev18 and higher (English)

(2) The maintenance utilities programs shown below.

| Applicable OS | Filename | Model number |
|---|-----------|-------------------------------|
| Win9X/Me/NT/2000/XP (Japanese/English) | MuWin.zip | 42678801FW01 Rev18 and higher |

Table 5-2 Maintenance utilities adjustment items

| Item | Adjustment contents | Maintenance Utilities Operation Manual item number | Operation on the operator panel (Item number corresponds to that of the Maintenance Manual.) |
|------|--|--|--|
| 1 | PU board replacement Copies the EEPROM data of the existing PU board. Adjustment objective: Copies the EEPROM data of the existing PU board to the new PU board when the existing PU board needs to be replaced with the new PU board during maintenance. | Section 2.4.1.1.1 | Operation from the operator panel cannot be made. |
| 2 | PU serial number setting Re-writing the printer serial number saved in PU. Adjustment objective: When copying the EEPROM data of the PU board is not possible (due to I/F error or others), re-write the serial number in the new replacement PU board. | Section 2.4.1.1.2.1 | Operation from the operator panel cannot be made. |
| 3 | Factory/Shipping mode Switching between the Factory mode and the Shipping mode. Adjustment objective: When copying the EEPROM data of the PU board is not possible (due to I/F error or others), implement switching between the Factory mode and the Shipping mode. When the replacement board is supplied for maintenance, it has been set in the Factory mode as the default setting. Switching from the Factory mode to the Shipping mode needs to be performed using this function. | Section 2.4.1.1.2.3 | Section 5.3.2.10 |

| Item | Adjustment contents | Maintenance Utilities Operation Manual item number | Operation on the operator panel (Item number corresponds to that of the Maintenance Manual.) |
|------|--|--|--|
| 4 | CU board replacement Re-writing the EEPROM setup value of the CU board. Adjustment objective: Re-writes the EEPROM data of the existing CU board to the new CU board when the existing CU board needs to be replaced with the new CU board during maintenance. See note: | Section 2.4.1.1.3 | Operation from the operator panel cannot be made. |
| 5 | Serial number information setting Re-writing the printer serial number, selections, output mode and printer serial number that are saved in CU. | Section 2.4.1.1.4.3 | Operation from the operator panel cannot be made. |
| 6 | Setup information of board items Verifying the serial number information and the Factory/Shipping mode. | Section 2.4.1.1.7 | Operation from the operator panel cannot be made. |
| 7 | USB software upgrade Upgrading the USB software | Section 2.4.2.2.1 | Operation from the operator panel cannot be made. |
| 8 | NIC software upgrade Upgrading the NIC software | Section 2.4.2.2.2 | Operation from the operator panel cannot be made. |
| 9 | NIC Web Page upgrade NIC Web Page upgrade | Section 2.4.2.2.3 | Operation from the operator panel cannot be made. |
| 10 | Mac address setting Setting the Mac address | Section 2.4.2.2.4 | Operation from the operator panel cannot be made. |
| 11 | Consumable items counter maintenance function Copies the consumable items counter data Drum counter (Y, M, C, K) Fuser counter Belt counter Toner counter (Y, M, C, K) Adjustment objective: Copies the data of the respective consumable item counters in the case when an existing consumable item that is in the middle of its usage is removed and installed in another printer. | Section 2.4.1.2.1 | Operation from the operator panel cannot be made. |

Note! For the CU board of the C710, replace the entire EEPROM that is installed in CU using socket.

| | Item | Adjustment contents | Maintenance Utilities Operation Manual item number | Operation on the operator panel (Item number corresponds to that of the Maintenance Manual.) |
|----|--|---|--|--|
| 12 | Destination PnP information setting | Sets/verifies the printer (CU) destination, device ID and USB ID. | Section 2.4.1.2.9 | Section 5.4.3 |
| 13 | Password initialization | Initialization of administrator password | Section 2.4.2.2.13 | |
| 14 | Network log save function | Saving the network log | Section 2.4.2.2.14 | |
| 15 | Consumable items counter display | Verifies present data of the consumable items counter. | Section 2.4.1.3.1 | Section 5.1 ENG STATUS PRINT |
| 16 | Menu setup value confirmation | Displays the setup values that have been set in the printer (CU). | Section 2.4.1.3.2 | Menu map print (Refer to the User's Manual.) |
| 17 | Printer information confirmation | Verifies the Mac address and various F/W versions of the printer. | Section 2.4.1.3.3 | Menu map print (Refer to the User's Manual.) |
| 18 | Verifies the installed CPU/ memory values. | Verifies the CPU information of if the installed CPU and information of the installed memory. | Section 2.4.1.3.4 | Menu map print (Refer to the User's Manual.) |
| 19 | Test print | Executes the local print function, and sends the specified file. Adjustment objective: Checks operation of the printer as the standalone printer, and sends the downloaded file. | Section 2.4.1.4.1 | Local print (Refer to the system specification.) |
| 20 | Switch scan test | Execution of switch scan test Adjustment objective: Operation check of the respective sensors | Section 2.4.1.5.1 | |
| 21 | Motor clutch test | Execution of motor clutch test Adjustment objective: Operation check of the respective motors and clutches. | Section 2.4.1.5.2 | |
| 22 | Color registration correction test | Color registration correction test Execution of color registration correction test. | Section 2.4.1.5.3 | |
| 23 | Density correction test | Execution of density correction test | Section 2.4.1.5.4 | |

| | Item | Adjustment contents | Maintenance Utilities Operation Manual item number | Operation on the operator panel (Item number corresponds to that of the Maintenance Manual.) |
|----|--|---|--|--|
| 24 | Automatic density correction control parameter setting [Use prohibition] | Setting the automatic density correction control parameter | Use prohibition | |
| 25 | Counter display | Checking reading of the consumable items counter, consumables continue counter and waste toner counter. | Section 2.4.1.5.7 | |
| 26 | Local parameter setting | Switching of Factory mode and Shipping mode, confirmation of fuse status | Section 2.4.1.5.8 | |
| 27 | Engine parameter setting | Setting values of the engine parameter items | Section 2.4.1.5.9 | |

*1: Function restriction is applied.

Note! Do not perform any operations/settings for the items that are specified as [Use of this menu item is prohibited.] If this caution is not observed, it may result in danger of abnormal operations of the printer.

5.3 Maintenance menu functions

5.3.1 Self-diagnostic mode

This section describes the self-diagnostic LEVEL 0 and LEVEL 1 respectively.


5.3.1.1 Operation panel

The following description on operating the self-diagnostic is premised on the operation panel layout as shown below.



Self-diagnostic mode layout (overall)


- (1) How to select the menu items
- XXXXX Menu items can be selected directly.
 - XXXXX Menu items can be selected by pressing either [MENU+] or [MENU-] key.



LEVEL0

(1) How to select the menu items

- XXXX Menu items can be selected by long pressing of [BACK] or [ONLINE], or by short pressing of [MENU+] or [ONLINE].
- XXXX Menu items can be selected by pressing either [MENU+] or [MENU-] key. Long pressing of [BACK] returns the screen to the menu item selection screen.




LEVEL1

(1) How to select the menu items

XXXXXX Menu items can be selected by pressing either [MENU+] or [MENU-] key, and executed by pressing [ENTER].

XXXXXX Menu items can be entered by pressing of [ENTER] or [BACK], and can be selected by pressing of [MENU+] or [MENU-].

The test can be executed by pressing [ENTER], and can be exited by pressing [BACK].



5.3.1.2 Ordinary self-diagnostic mode (level 1)

Menu items of the ordinary self-diagnostic mode are shown below.

| | Item | Self-diagnostic menu | Adjustment contents | Maintenance utilities |
|----|--|----------------------|--|--|
| 1 | Switch scan test | SWITCH SCAN | Entry sensor check and switch check | No.20 |
| 2 | Motor clutch test | MOTOR&CLTCH TEST | Motor and clutch operation test | No.21 |
| 3 | Test print execution | TEST PRINT | PU built-in test pattern print | Operation from the maintenance utilities cannot be made. |
| 4 | Color registration correction test | REG ADJUST TEST | Color registration mechanism check | No.22 |
| 5 | Density correction test | DENS ADJ TEST | Density correction mechanism check | No.23 |
| 6 | Consumable item counter display | CONSUMABLE STATUS | Consumable items consumption status display | No.25 |
| 7 | Consumable item accumulative counter display | PRINTER STATUS | Consumable items accumulative consumption status display | No.25 |
| 8 | Factory/Shipping mode selection | FACTORY MODE SET | Switching between the Factory mode and the Shipping mode | No.3, No.26 |
| 9 | FUSE status check | | Respective FUSEs status display | No.26 |
| 10 | Engine parameter setting | SENSOR SETTING | Valid/Invalid setups of error detection by various sensors | No.27 |
| 11 | NVRAM parameter setting | NVRAM PARAMETER | Do not use this item | Use of this menu item is prohibited |

5.3.1.2.1 How to enter the self-diagnostic mode (level 1)

Note! For C710, password is required to enter the system maintenance menu mode. Refer to Table 5-1 (C710)

1. While pressing the MENU+, MENU-, and HELP keys simultaneously, turn on the power to enter the system maintenance mode.
2. Press the MENU+ key or MENU- key several times until the message "ENGINE DIAG MODE" is displayed. Then, press the ENTER key to display "DIAGNOSTIC MODE".

| |
|---------------------------|
| DIAGNOSTICMODE |
| XX.XX.XX FACTORY/SHIPPING |

3. XXX.XX.XX of the message "DIAGNOSTIC MODE XX.XX.XX" that is displayed on the LCD display area indicates the PU firmware version number. The FACTORY WORKING MODE setup value is displayed in the right of the lower row. S-MODE of "SHIPPING" is displayed normally.
4. Press the MENU+ key or MENU- key to advance to the desired step of each self-diagnostic menu. (The menu items rotate when either the MENU+ key or MENU- key is pressed.)


5.3.1.2.2 How to exit the self-diagnostic mode

1. Turn off the power once and back on 10 seconds later.


5.3.1.3 Switch scan test

This self-diagnostic menu is used to check the entry sensor and the switch.

1. Enter the self-diagnostic mode (level 1) and press the MENU+, MENU- key until "SWITCH SCAN" is displayed in the upper row of the display area. (Pressing the MENU+ key increments the test item and pressing the MENU- key decrements the test item.)



2. Press either the MENU+ or MENU- key until the desired menu item corresponding to the unit to be tested in Table 5-3 is displayed in the lower row of the display area. (Pressing the MENU+ key increments the test item and pressing the MENU- key decrements the test item.)
3. Pressing the ENTER key starts the test. Name and present status of the corresponding unit are displayed.



Activate the respective units. (Figure 5-1) Status of the respective units are displayed on the corresponding areas of the LCD display. (Display changes depending on each sensor. Refer to Table 5-3 for details.)

4. Press the CANCEL key to return to the status of step 2.
5. Repeat steps 2 to 4 as required.
6. Press the BACK key to exit the test. (Returns to the status of step 1.)




Figure 5-1 Switch and sensor location diagram

Table 5-3 SWITCH SCAN details

<Item having no function> Asterisk mark (*) is displayed in the lower row of display area.

* 1: "L" is displayed when the cover is opened.

| Display area, upper row | 1 | | 2 | | 3 | | 4 | |
|-------------------------|--|---|-------------------------------------|---|--------------------------------------|---|-------------------------|---|
| | Details | Display area, lower row | Details | Display area, lower row | Details | Display area, lower row | Details | Display area, lower row |
| PAPER ROUTE : PU | Entrance sensor 1 | H: No paper L: Paper exists | Entrance sensor 2 | H: No paper L: Paper exists | Write sensor | H: No paper L: Paper exists | Exit sensor | H: No paper L: Paper exists |
| TONER SENS | Toner sensor K | H: Light is interrupted L: Reflected | Toner sensor Y | H: Light is interrupted L: Reflected | Toner sensor M | H: Light is interrupted L: Reflected | Toner sensor C | H: Light is interrupted L: Reflected |
| CVO UP_LU_FU | Cover open switch | H: Close L: Open | | | | | | |
| ST_FD_FU JOBOFF | Stacker down sensor | H: No paper L: Paper exists | | | | | | |
| REG L/R_OHP_WG | Color registration sensor L | AD value: ***H | Color registration sensor R | AD value: ***H | | | | |
| HT THERMISTER | Fuser thermistor, upper sensor | AD value: ***H | Fuser thermistor, lower sensor | AD value: ***H | Fuser thermistor, upper sensor, side | AD value: ***H | Heater frame thermistor | AD value: ***H |
| HUM_TEMP_DEN | Humidity sensor | AD value: ***H | Humidity sensor | AD value: ***H | Humidity sensor (k) | AD value: ***H | Humidity sensor (YMC) | AD value: ***H |
| BELT_T | Belt thermistor | AD value: ***H | | | | | | |
| ID UP/DOWN | GREY | GREY | | | | | ID UpDown Sns | H: Down L: Up |
| RFID COLOR*1 | RFID antenna K | UID: ***H | RFID antenna Y | UID: ***H | RFID antenna M | UID: ***H | RFID antenna C | UID: ***H |
| T1 PE_PNE_CVO | Tray 1 paper end sensor | H: No paper L: Paper exists | | | | | | |
| T1 CASSETTE SIZE*1 | Size setting switch 1 | Port level H, L | Size setting switch 2 | Port level H, L | Size setting switch 3 | Port level H, L | Size setting switch 4 | Port level H, L |
| T2 PE_PNE_CVO_CA | Tray 2 paper end sensor | H: No paper L: Paper exists | | | | | | |
| T2 HOP_LF_FED | 2nd-Hopping Sns | H: No paper L: Paper exists | | | Tray 2 entrance sensor | H: No paper L: Paper exists | | |
| T2 CASSETTE SIZE*1 | Size setting switch 1 | Port level H, L | Size setting switch 2 | Port level H, L | Size setting switch 3 | Port level H, L | Size setting switch 4 | Port level H, L |
| T3 PE_PNE_CVO | Tray 3 paper end sensor | H: No paper L: Paper exists | | | | | | |
| T3 HOP_LF_FED | 3rd-Hopping Sns | H: No paper L: Paper exists | | | Tray 3 entrance sensor | H: No paper L: Paper exists | | |
| T3 CASSETTE SIZE | Size setting switch 1 | Port level H, L | Size setting switch 2 | Port level H, L | Size setting switch 3 | Port level H, L | Size setting switch 4 | Port level H, L |
| DUP IN_RA_FNT | Duplex (2-sided) print entrance sensor | H: No paper L: Paper exists | | | Duplex (2-sided) print front sensor | H: No paper L: Paper exists | | |
| DUP SK_CVO | Duplex (2-sided) print bottom sensor | H: No paper L: Paper exists | Duplex (2-sided) print cover sensor | H: Close L: Open | | | | |

5.3.1.4 Motor clutch test

This self-diagnostic menu is used to test the motor and clutch.

1. Enter the self-diagnostic mode (level 1) and press the MENU+, MENU- key until "SWITCH SCAN" is displayed in the upper row of the display area.
(Pressing the MENU+ key increments the test item and pressing the MENU- key decrements the test item.)
2. Press either the MENU+ or MENU- key until the desired menu item corresponding to the unit to be tested in Table 5-4 is displayed in the lower row of the display area. (Pressing the MENU+ key increments the test item and pressing the MENU- key decrements the test item.)

| |
|---------------------|
| MOTOR & CLUTCH TEST |
| ID MOTOR |

3. Pressing the ENTER key starts the test. The unit name starts flashing and the corresponding unit is activated for 10 seconds. (Refer to Figure 5-2.)

Note! After the corresponding unit has activated for 10 seconds, it returns to the status of step2, and is re-activated when the corresponding switch is pressed.

- The clutch solenoid repeats turning on and off during the normal print drive. (If a clutch solenoid cannot be activated independently, the motor is driven at the same time.) * "ID UP/DOWN" keeps activated until the CANCEL key is pressed.
- If [ENTER] is pressed long (2 sec) when selecting a motor, the motor keeps running.

4. When the CANCEL key is pressed, the corresponding unit stops activating. (Display of the corresponding unit keeps displayed.)
5. Repeat steps 2 to 4 as required.
6. Pressing the BACK key terminates the test. (Returns to the status of step 1.)




Figure 5-2

Table 5-4

| Unit name display | Drive restriction condition | Remarks |
|-------------------|--|---------|
| ID MOTOR | To be driven when all of the ID (K/Y/M/C) are removed. | - |
| BELT MOTOR | To be driven when all of the ID (K/Y/M/C) are removed. | - |
| FUSER_RLS | - | - |
| REGIST MOTOR | - | - |
| T1 HOPPING MOTOR | - | - |
| FRONT MOTOR | - | - |
| REGIST SHUTTER | - | - |
| EXIT SOLENOID | - | - |
| DUPLEX MOTOR | - | - |
| DUPLEX CLUTCH | - | - |
| T2 HOPPING MOTOR | - | OPTION |
| T2 FEED CLUTCH | - | OPTION |
| T3 HOPPING MOTOR | - | OPTION |
| T3 FEED CLUTCH | - | OPTION |
| ID UP/DOWN | TOP/FRONT cover closed status | - |
| LV FAN TEST | - | - |
| FUSER FAN TEST | - | - |
| DUPLEX FAN TEST | - | OPTION |
| ID FAN TEST | - | - |

Note! Display while ID Up/Down execution is in progress

| |
|----------------------|
| MOTOR & CLUTCH TEST |
| ID UP/DOWN *** |

*** Number of times of execution

Display when the REGIST SHUTTER [ENTER] key is pressed long

| |
|-----------------------|
| MOTOR & CLUTCH TEST |
| SHT *** |

*** Number of times of execution

5.3.1.5 Test print

This self-diagnostic menu is used to print the test pattern that is built inside PU. Other test patterns are stored in the controller.

This test print cannot be used to check the print quality.

Diagnosis for the abnormal print image should be performed in accordance with section 7.

1. Enter the self-diagnostic mode (level 1) and keep pressing the MENU+, MENU- key until "TEST PRINT" is displayed in the upper row of the display area. Then, press the ENTER key. (Pressing the MENU+ key increments the test item and pressing the MENU- key decrements the test item.)
2. The setting items that can be applied to the test print only is displayed in the lower row of display area. Keep pressing the MENU+, MENU- key until the desired menu item is displayed. (Pressing the MENU+ key increments the test item and pressing the MENU- key decrements the test item.) (If all setting items need no entry [Default setting], go to step 5.)
3. Keep pressing the MENU+, MENU- key, and press the ENTER key at the menu item set by step 2. Then, the setting item is displayed in the upper row of display area, and the setting value is displayed in the lower row of display area.

Pressing the MENU+ key increments the setting value. Pressing the MENU- key decrements the setting value. (The setting value that is displayed at last is applied.) Pressing the BACK key determines the entry value, and returns to step 2. Repeat step 3 as required.

| |
|--------------|
| TEST PATTERN |
| 1 |

| Display | Setting value | Function |
|---------------|---------------|--|
| PRINT EXECUTE | – | Pressing the ENTER key starts print/Pressing the CANCEL key terminates print. (In units of page) |
| TEST PATTERN | 0 | 0: White paper print 1–7: Refer to next page. (Pattern print) 8–15: White paper print |
| TEST CASSETTE | TRAY1 | Selecting source of paper supply. If the TRAY 2 is not installed, TRAY2 is not displayed. If the TRAY 3 is not installed, TRAY3 is not displayed. |
| | TRAY2 | |
| | TRAY3 | |
| | MFP | |
| PAGE | 0000 | Setting number of the test print copies |
| COLOR | ON | Selecting either color/monochrome print * When ON is specified, ON/OFF setting for each color becomes available. |
| | OFF | |
| DUPLEX | 2 PAGES STACK | Duplex (2-sided) print is performed by the stack of two sheets of paper. Selecting OFF for duplex (2-sided) print. Duplex (1-sided) print is performed by the stack of one sheet of paper. |
| | OFF | |
| | 1PAGES STACK | |

- is the initial default value. The menu item that is set here is valid in this menu item only.
(The setting item is not saved in EEPROM.)

Note! PAGE setting

Pressing the MENU+ key or the MENU- key shifts the digit. Pressing the ONLINE key increments the setting value. Pressing the MENU+ key increments the setting value. If print is executed while the number of print copies remains in "0000", printing will continue infinitely.

COLOR setting

When the ENTER key is pressed while ON is set, the following contents are displayed on the panel.

Print setting for each color

Pressing the MENU+ key or the MENU- key shifts the setting. Pressing the ONLINE key or the CANCEL, the ON/OFF switchover will be set. Pressing the BACK key returns the panel display.

| | | |
|-------|---|---------------|
| COLOR | → | Y : ON M : ON |
| ON | | C : ON K : ON |

- While the message "PRINT EXECUTE" that is set by the operation specified in step 2 is being displayed, press the ENTER key and the test print is executed with the setting value that has been set by steps 2 and 3.

Pressing the CANCEL key stops the test print.

If any alarm that is shown in the following details column is issued at startup of test print or while test print is in progress, the test print is interrupted. (For error details, refer to section 5.3.2.14 Panel display details. However, the comment to be displayed is different in the case of the PU test print.)


| Panel display | Details |
|-----------------------------------|---------------------------------|
| STACKER FULL | Stacker full |
| PAPER END SELECTED TRAY | No paper |
| DUPLEX UNIT IS NOT INSTALLED | DUPLEX is not installed |
| SELECTED TRAY IS NOT INSTALLED | Selected tray is not installed. |
| REMOVE PAPER OUT OF DUPLEX | DUPLEX internal error |
| INSTALL CASSETTE TRAY OPEN | Cassette removal |

Print pattern (It cannot be used for checking PQ.)

0, 8 to 15..... White paper print



Pattern 1




Pattern 2




Pattern 3



Pattern 4



Pattern 5



Pattern 6



Pattern 7

Note! If the solid print (pattern 7) among the local print function is selected and printed with the setting of 100% each color, offset occurs. To prevent print from this trouble, the print setting of each color should be made in accordance with the instruction specified in step 5.3.2.5-3 when performing the sold print, and number of print colors should be two colors or less.

- During printing, the following messages are displayed.

| |
|-------|
| P=*** |
| W=*** |

P : Number of test print copies (unit: copies)
W : Print waiting time (unit: second)

- Displays are switched by pressing the MENU+ key.

| |
|-------------------|
| T=*** U=*** [###] |
| H=***%L=*** [###] |

U : *** = Upper heater temperature measurement value [unit:°C]
[***] = Print execution target temperature [unit:°C]
L : *** = Lower heater temperature measurement value [unit:°C]
[###] = Lower thermistor read-out AD value [unit: HEX]
T : Environment temperature measurement value [unit:°C]
H : Environment humidity measurement value [unit: %]

- Displays are switched by pressing the MENU+ key.

| |
|-----------------------|
| KTR=* . ** YTR=* . ** |
| MTR=* . ** CTR=* . ** |

YTR, MTR, CTR and KTR indicate the transfer voltage setting value for each color (unit: KV)

- Displays are switched by pressing the MENU+ key.

| |
|---------------------|
| KR=* . ** YR=* . ** |
| MR=* . ** CR=* . ** |

KR : BLACK transfer roller resistance value [unit: uA]
YR : YELLOW transfer roller resistance value [unit: uA]
MR : MAGENTA transfer roller resistance value [unit: uA]
CR : CYAN transfer roller resistance value [unit: uA]

- Displays are switched by pressing the MENU+ key.

| |
|------------------|
| ETMP=***UTMP=*** |
| REG=****EXT=*** |

ETMP : Hopping motor constant speed correction parameter
(environment temperature) [unit: DEC]
UTMP : Fuser motor constant speed correction parameter
(fuse target temperature) [unit: DEC]
REG : Hopping motor constant speed timer value (I/O setting value)
[unit: HEX]
EXT : Fuse motor constant speed timer value (I/O setting value) [unit: HEX]

- Displays are switched by pressing the MENU+ key.

| |
|---------|
| ID=**** |
| |

KID, YID, MID and CID are the constant speed timer value of the respective ID motors (I/O setting value) [unit: HEX]

- Displays are switched by pressing the MENU+ key.

| |
|-------------------|
| BELT=**** |
| FRM [***] (xxx) |

BELT : Hopping motor constant speed timer value (I/O setting value) [unit: HEX]
FRM : [***] = Frame thermistor read-out AD value [unit: HEX]
(XXX) = Frame temperature [unit: °C]

- Displays are switched by pressing the MENU+ key.

| |
|-----------------|
| DB:k**y**m**c** |
| |

DB : Develop voltage setting table ID number [unit: HEX]

- Displays are switched by pressing the MENU+ key.

| |
|--------------------|
| TR1 : k**y**m**c** |
| TR2 : k**y**m**c** |

TR1 : Transfer voltage parameter VTR1 table ID number [unit: HEX]

TR2 : Transfer voltage parameter VTR2 table ID number [unit: HEX]

- Displays are switched by pressing the MENU+ key.

| |
|-----------------|
| TROFF : ** |
| BELT xxx (***) |

TROFF : Transfer OFF voltage setting table ID number [unit: HEX]

BELT : XXX = Belt thermistor read-out AD value [unit: HEX]

*** Belt temperature [unit: °C]

5. Repeat steps 2 to 4 as required.
6. Pressing the CANCEL key terminates the test. (Returns to the status of step 1.)

5.3.1.6 Color registration correction test

This self-diagnostic menu item is used for the color registration error adjustment and to investigate cause of the error of a printer.

If the color registration error is recognized by the color registration correction test, correct it by following section 2 "Color registration correction method overview".

1. Enter the self-diagnostic mode (level 1) and keep pressing the [MENU+] or [MENU-] key until the following message is displayed.

| |
|-----------------|
| REG ADJUST TEST |
| |

2. When the [ENTER] key is pressed, the following message is displayed. Keep pressing the [MENU+] or [MENU-] key until the target item is displayed.

| |
|-----------------|
| REG ADJUST TEST |
| REG ADJ EXECUTE |

3. When the [ENTER] key is pressed, test of the item that is displayed on the panel is executed.

<<During execution of REG ADJ EXECUTE>>

- ① The color registration correction test is executed. (The [ONLINE] lamp flashes.)
- ② When the test is complete, the test result (OK or error name) is displayed in the upper row of the display area, and ****RESULT is displayed in the lower row of the display area

| |
|----------------|
| OK |
| REG ADJ RESULT |

When the [MENU+] key is pressed, the test results are displayed by incrementing them.

When the [MENU-] key is pressed, the test results are displayed by decrementing them.

Pressing the [BACK] key returns the screen to the state of step 2.

Remarks The following message is displayed during initialization, when the cover is opened and during alarm.

| |
|----------------|
| NG |
| REG ADJ RESULT |

- ③ When the [CANCEL] key is pressed while test is in progress (while the [ONLINE] lamp is lighting), the screen returns to the state of step 2.

<<During execution of REG ADJ RESULT>>

The same as the key operations of step 2. During execution of REG ADJ EXECUTE.

<<During execution of BLT REFLECT TEST>>

- ① The color registration correction test is executed. (The [ONLINE] lamp flashes.)
- ② When the test is complete, the test result (OK or error name) is displayed in the upper row of the display area, and ****RESULT is displayed in the lower row of the display area

| |
|------------------|
| OK |
| BLT REFLECT RSLT |

When the [MENU+] key is pressed, the test results are displayed by incrementing them.

When the [MENU-] key is pressed, the test results are displayed by decrementing them.

Pressing the [BACK] key returns the screen to the state of step 2.

- ③ When the [CANCEL] key is pressed while test is in progress (while the [ONLINE] lamp is lighting), the screen returns to the state of step 2.

<<During execution of BLT REFLECT RSLT>>

The same as the key operations of step ②. During execution of BLT REFLECT TEST.

Remarks The following message is displayed during initialization, when the cover is opened and during alarm.

| |
|------------------|
| NG |
| REG REFLECT RSLT |

4. Repeat steps 2 and 3 as required.
5. Pressing the [BACK] terminates the test. (Returns to the status of step 1.)

Color registration correction test items

| Display | Details |
|------------------|--|
| REG ADJ EXECUTE | Executing the color registration correction |
| REG ADJ RESULT | Referring to result of the color registration correction |
| BLT REFLECT TEST | Executing judgment of GOOD/BAD of reflectance rate of color registration correction belt |
| BLT REFLECT RSLT | Referring to result of the judgment of GOOD/BAD of reflectance rate of color registration correction belt. |

5.3.1.7 Density correction test

This self-diagnostic menu item is used to test the density correction function of a printer, and to refer to result of the test execution.

At the same time, GOOD/BAD of the density correction function is judged by executing this test.

If an error is issued, correct it by following section 2 "Density correction method overview".

1. Enter the self-diagnostic mode (level 1) and keep pressing the [MENU+] or [MENU-] key until the following message is displayed.

| |
|---------------|
| DENS ADJ TEST |
|---------------|

2. When the [ENTER] key is pressed, the following message is displayed. Keep pressing the [MENU+] or [MENU-] key until the target item is displayed.

| |
|---------------|
| DENS ADJ TEST |
|---------------|

| |
|------------------|
| DENS ADJ EXECUTE |
|------------------|

3. When the [ENTER] key is pressed, test of the item that is displayed on the panel is executed.

<<During execution of REG ADJ EXECUTE>>

- ① The density correction test is executed. (The [ONLINE] lamp flashes.)
- ② When the test is complete, the test result (OK or error name) is displayed in the upper row of the display area, and ****RESULT is displayed in the lower row of the display area

| |
|----|
| OK |
|----|

| |
|-----------------|
| DENS ADJ RESULT |
|-----------------|

[When the [MENU+] key is pressed, the test results are displayed by incrementing them.

When the [MENU-] key is pressed, the test results are displayed by decrementing them.

Pressing the [BACK] key returns the screen to the state of step 2.

- ③ When the [CANCEL] key is pressed while test is in progress (while the [ON LINE] lamp is lighting), the screen returns to the state of step 2.

<<During execution of DENS ADJ RESULT>>

The same as the key operations of step 2. During execution of DENS ADJ EXECUTE.

<<During execution of DENS ADJ PAR - SET>>

Setup of the density correction parameter is displayed.

<<During execution of AUTO CALIBRATION>>

- ① The automatic setting of the density sensor sensitivity correction value is executed. (The [ON LINE] lamp flashes.)
- ② When the test is complete, the test result (OK or error name) is displayed in the upper row of the display area, and ****RESULT is displayed in the lower row of the display area

| |
|-----------------|
| OK |
| DENS ADJ RESULT |

When the [MENU+] key is pressed, the test results are displayed by incrementing them.

When the [MENU-] key is pressed, the test results are displayed by decrementing them.

Pressing the [BACK] key returns the screen to the state of step 2.

- ③ When the [CANCEL] key is pressed while test is in progress (while the [ON LINE] lamp is lighting), the screen returns to the state of step 2.

Remarks The following message is displayed during initialization, when the cover is opened and during alarm.

| |
|-----------------|
| NG |
| DENS ADJ RESULT |

- 4. Repeat step 3 as required.

- 5. Pressing the [BACK] key terminates the test. (Returns to the status of step 1.)

Density correction test items

| Display | Details |
|------------------|---|
| DENS ADJ EXECUTE | Executing the density correction |
| DENS ADJ PAR-SET | Setting the control values with respect to the automatic density correction |
| DENS ADJ RESULT | Referring to result of the density correction |
| AUTO CALIBRATION | Automatic setting of the density sensor sensitivity correction value |

5.3.1.8 Consumable item counter display

This self-diagnostic menu is used to display the consumption status of the consumable items.

1. Enter the ordinary self-diagnostic mode and press the MENU+, MENU- key until "CONSUMABLE STATUS" is displayed in the display area. (Pressing the MENU+ key increments the test item and pressing the MENU- key decrements the test item.)
2. When the MENU+, MENU- key is pressed, consumption statuses of the consumable items are displayed in order. (Pressing the ONLINE or CANCEL key is invalid.)
3. Pressing the BACK key terminates the test. (Returns to the status of step 1.)

| Display area, upper row | Display area, lower row | Format | Unit | Details |
|-------------------------|-------------------------|--------|--------|--|
| K-ID UNIT | *****IMAGES | DEC | Images | Number of rotations from the time when the ID UNITS of respective colors are installed up to the present time is displayed after converting them to the units of A4 3Page/Job. |
| Y-ID UNIT | *****IMAGES | DEC | Images | |
| M-ID UNIT | *****IMAGES | DEC | Images | |
| C-ID UNIT | *****IMAGES | DEC | Images | |
| FUSER UNIT | *****PRINTS | DEC | Prints | Number of copies from the time of installation of a new fuser unit up to the present time is displayed. |
| TR BELT UNIT | *****IMAGES | DEC | Images | Number of copies from the time of installation of a new belt unit up to the present time is displayed. |
| K-TONER (FULL) | *****% | DEC | % | Amount of consumption of the respective toners is displayed. |
| Y-TONER (FULL) | *****% | DEC | % | |
| M-TONER (FULL) | *****% | DEC | % | |
| C-TONER (FULL) | *****% | DEC | % | |
| M-WASTE TNR CNT | *****TIMES | DEC | Times | Amount of waste toner is displayed. * When the times reaches 32 times or more, the waste toner full is issued. |
| C-WASTE TNR CNT | *****TIMES | DEC | Times | |

| Display area, upper row | Display area, lower row | Format | Unit | Details |
|-------------------------|-------------------------|--------|-------|--|
| K-STC MODE CNT | *****TIMES | DEC | Times | Number of print dot counts of the toner of the respective colors are displayed. (Accumulative value since start of the system operation.) |
| Y-STC MODE CNT | *****TIMES | DEC | Times | |
| M-STC MODE CNT | *****TIMES | DEC | Times | |
| C-STC MODE CNT | *****TIMES | DEC | Times | |
| K OVER RIDE CNT | *****TIMES | DEC | Times | Number of times of continues of the toner cartridge of the respective colors are displayed. |
| Y OVER RIDE CNT | *****TIMES | DEC | Times | |
| M OVER RIDE CNT | *****TIMES | DEC | Times | |
| C OVER RIDE CNT | *****TIMES | DEC | Times | |

5.3.1.9 Number of print copies counter display

This self-diagnostic menu is used to display status of the number of copies of a printer.

1. Enter the ordinary self-diagnostic mode and press the MENU+, MENU- key until "PRINTER STATUS" is displayed in the display area. (Pressing the MENU+ key increments the test item and pressing the MENU- key decrements the test item.)
2. When the MENU+, MENU- key is pressed, statuses of the number of print copies are displayed in order.(Pressing the ONLINE or CANCEL key is invalid.)
3. Pressing the BACK key terminates the test. (Returns to the status of step 1.)

| Display area, upper row | Display area, lower row | Format | Unit | Details |
|-------------------------|-------------------------|--------|--------|--|
| K-IMPRESSIONS | *****IMAGES | DEC | Images | Number of print copies of the respective colors are displayed. |
| Y-IMPRESSIONS | *****IMAGES | DEC | Images | |
| M-IMPRESSIONS | *****IMAGES | DEC | Images | |
| C-IMPRESSIONS | *****IMAGES | DEC | Images | |
| TOTAL SHEET CNT | *****COUNTS | DEC | Prints | Total number of print copies are displayed. |

5.3.1.10 Switching between the Factory mode and the Shipping mode

This self-diagnostic menu item is used to switch between the Factory mode and the Shipping mode.

1. Enter the self-diagnostic mode (level 1) and keep pressing the [MENU+] or [MENU-] key until the following message is displayed.

| |
|------------------|
| FACTORY MODE SET |
|------------------|

2. When the [ENTER] key is pressed, the following message is displayed. Keep pressing the [MENU+] or [MENU-] key until the target item (refer to the following table) is displayed.

| |
|-----------------|
| FACTORY MODE |
| SHIPPING MODE * |

3. While the desired item to set is being displayed, press the [ENTER] key that enables selection of the setting values.
4. While the desired setting value is being displayed, press the [ENTER] key for long period (3 seconds) that registers the displayed value in EEPROM. (Returns to the status of step 2.)
5. Repeat steps 2 to 4 as required.
6. Pressing the [BACK] key terminates the test. (Returns to the status of step 1.)

| Display | Setting value | Function |
|--|-----------------|--|
| FACTORY MODE | FACTORY MODE | Sets the Factory working mode (fuse cut invalid mode). |
| | SHIPPING MODE | Releases the Factory working mode to make the fuse cut function valid. |
| FUSE INTACT Note: ***** indicates INTACT or BLOWN. | BELT UNIT ***** | Checks the fuse status of the transport belt unit. |
| | FUSE UNIT ***** | Checks the fuse status of the fuser unit. |
| | K-ID UNIT ***** | Checks the fuse status of the K-1D unit. |
| | Y-ID UNIT ***** | Checks the fuse status of the Y-1D unit. |
| | M-ID UNIT ***** | Checks the fuse status of the Y-1D unit. |
| | C-ID UNIT ***** | Checks the fuse status of the C-1D unit. |

5.3.1.11 Self-diagnostic function setting

This self-diagnostic menu is used to set valid/invalid of the error detection by the various sensors.

The error detection can be made invalid or valid for locating source of abnormality. However, this menu item requires expert knowledge to set among the engine operations. Handle this menu item with utmost care.

Be sure to return the setting to the default setting upon completion of usage of this item.

1. Enter the self-diagnostic mode (level 1) and keep pressing the [MENU+] or [MENU-] key until the following message is displayed.

| |
|----------------|
| SENSOR SETTING |
| |

2. When the [ENTER] key is pressed, the following message is displayed. Keep pressing the [MENU+] or [MENU-] key until the target item (refer to the table below) is displayed.

| |
|--------------|
| TONER SENSOR |
| ENABLE * |

3. When the [ENTER] key is pressed, the following message is displayed.
Pressing the [MENU+] key increments the setting value.
Pressing the [MENU-] key decrements the setting value.
4. While the desired setting value is being displayed, press the [ENTER] key for long period (3 seconds) that registers the displayed value in EEPROM. (Returns to the status of step 2.)
5. Repeat steps 2 to 4 as required.
6. Pressing the [BACK] key terminates (except the status of step 4) the setting. (Returns to the status of step 1.)

| Display | Setting value | Operation at the setting value | Function |
|-----------------|---------------|--------------------------------|--|
| TONER SENSOR | ENABLE | Detects | Valid/Invalid of toner sensor operation |
| | DISABLE | Not to detect | |
| BELT UNIT CHECK | ENABLE | Checks | Valid/Invalid of belt installation check operation |
| | DISABLE | Not to check | |

| Display | Setting value | Operation at the setting value | Function |
|--|---------------|--------------------------------|--|
| ID UNIT CHECK | ENABLE | Checks | Valid/Invalid of ID installation check operation |
| | DISABLE | Not to check | |
| UP/DOWN SENSOR | ENABLE | Detects | Valid/Invalid of ID UP/DOWN sensor operation |
| | DISABLE | Not to detect | |
| REG ADJUST ERROR | ENABLE | Stops | Valid/Invalid of error stop by the color registration detection value |
| | DISABLE | Not to stop | |
| DRUM OVER LIFE | STOP | Not to continue | Setting of valid/invalid of continuance when drum comes to end of its life |
| | CONTINUANCE | To continue | |
| WR POINT REV TBL=**H± * .***mm | 00H~FFH | Correction value | The correction value is added to the existing write-down position. |
| BOTTOM WRT POINT TBL=**H± * .***mm | 00H~FFH | Cut value | Amount of cut at the rear end of a paper is set. |

Hatched portion: Default is shown

5.3.1.12 LED head serial number display

This self-diagnostic menu item is used to check whether the downloaded LED head data matches the serial number of the actual LED head.

1. Enter the self-diagnostic mode (level 1) and press the MENU+, MENU- key until "SWITCH SCAN" is displayed in the upper row of the display area. (Pressing the MENU+ key increments the test item and pressing the MENU- key decrements the test item.)
2. When the MENU+ key or the MENU- key is pressed, serial numbers of the K/Y/M/C LED head data are displayed in order.
3. Pressing the BACK key terminates the test. (Returns to the status of step 1.)



** ** * ** *: Rev number

XXXXXXXXXXXXXXXXXXXX: serial number

5.3.1.13 NVRAM parameter setting

Do not use this menu item.

5.3.2 Various prints with the printer as a standalone unit

Menu map print

Information of the program version number and that of the control block configuration are printed out.

Operation:

- ① While the system is in the [ON LINE] state, press the ENTER key once to display [Information menu].
- ② Press the ENTER key to display [Menu map print/execute].
- ③ Press the ENTER key.

Network information print

Operation:

- ① While the system is in the [ON LINE] state, press the ENTER key once to display [Information menu].
- ② Press the ENTER key.
- ③ Press the MENU+ key several times to display [Network/execute].
- ④ Press the ENTER key.

Alternately, press 5seconds the push switch located near the network connector on the back of printer.

Demo print

Prints the demo patterns of the various destinations that are saved in the ROM.

Operation:

- ① While the system is in the [ON LINE] state, press the ENTER key once to display [Information menu].
- ② Press the ENTER key.
- ③ Press the MENU+ key several times to display [DEMO1/execute].
- ④ Press the ENTER key.

5.3.3 Functions of keys at power on

Functions of the respective keys when the printer power is turned on are displayed below. Each of the following keys becomes valid if the key is kept pressed until "RAM CHECK" is displayed in the upper row of LCD and the several asterisk (*) marks are displayed in the lower row.

(1) MENU+ key & MENU- key & ENTER key

The printer starts up in the CU program upgrade mode. If the printer starts up in this mode, the network does not function.

(2) BACK key & ONLINE key & CANCEL key

The object that is added by the download mode is not started but the CU program is started up.

(3) MENU+ key & MENU- key & HELP key

The system maintenance menu is started up.

(4) MENU+ key & MENU- key & ENTER key

The printer starts up in the mode that sets the printer in the on-line mode all the time by ignoring the warning/error. (Factory assistance function)

(5) ONLINE key

The printer starts up in the dedicated mode in which the objects such as network or USB is going to be downloaded.

(6) ENTER key

The Admin menu is started up.

5.4 Setups upon completion of part replacement

The adjustments that are required upon completion of part replacement are described below.

| Replacement parts | Adjustment contents |
|------------------------------|--|
| LED head See note. | Not required |
| Drum cartridges (Y, M, C, K) | Not required |
| Fuser unit | Not required |
| Belt unit | Not required |
| PU board | Copying the EEPROM information and utilities are required. |
| CU board | EEPROM replacement Be sure to use the EEPROM of the user's printer. |

Note! For compatibility between new/old LEDs and identification, refer to section 4.2.6 "LED Assembly".

5.4.1 Precautions when replacing the engine control board


- When access to the EEPROM of the board to remove is possible:
(When the SERVICE CALL 104 [Engine EEPROM Error] is not displayed:)
 - Obtain the EEPROM information from the board that user is going to be removed, by using the PU board replacement function (Maintenance Utilities Operation Manual section 2.4.1.1.1 PU board replacement function) of the Maintenance Utilities, and save it in the hard disk of PC temporarily.
 - Copy the EEPROM information that has been saved in the hard disk of PC by step (1), into the EEPROM of the new replacement board by using the PU board replacement function (Maintenance Utilities Operation Manual section 2.4.1.1.1 PU board replacement function) of the Maintenance Utilities.

Note! When obtaining and copying the EEPROM information by using the Maintenance Utilities, set the printer into the "Forced ONLINE mode" by following the procedure described below. If the printer is in the error state, the error display is issued even during the forced ONLINE mode.

- When turning on the printer power, keep pressing [BACK] + [MENU-] + [ENTER] until "STATUS MODE" is displayed on the operator panel.
- If the printer is normal, "ON LINE" display is shown. If the printer has an error, the error display is shown. However, the printer has entered the ON LINE state in which communication is enabled.

- When access to the EEPROM of the board to remove is impossible:
If the SERVICE CALL 104 (Engine EEPROM Error) is displayed on the operator panel with the board that user is going to remove, or is EEPROM data cannot be read-out, perform the following procedure by using the Maintenance Utilities.
 - Setting the PU serial number
(Maintenance Utilities Operation Manual section 2.4.1.2 PU board setting)
The SAP serial number is applied to printer. The SAP serial number is displayed in the top-most row of the serial number label. Its number indicates the production place with 2 digits, manufacture date with 2 digits, serial number (sequential number) with 6 digits and revision number with 2 digits totaling 12 digit number.
 - The PU serial number is the 10 digit number excluding the revision number of 2 digits among the 12 digit SAP serial number.
 - Perform the above setting by using the Maintenance Utilities section "2.4.1.1.2 PU board setting function" – section "2.4.1.1.2.1 PU serial number setting".
 - To specify the PU serial number, enter the 11 digit number after adding "0" (zero in single-byte character) at the top. (Be careful that the read-out data shows the 10 digit number.)
Enter the 11 digit number by adding "0" (zero in single-byte character) before the 10 digit number excluding the revision 2 digits that is shown in conceptual drawing of "PU serial number setting" screen as shown below.

Enter the 11 digit number after adding "0" (zero in single-byte character) before the 10 digit number. (Enter "0AEO1234567".)



Serial number label conceptual drawing

- The PU serial number is output to the Printer Serial Number column of the Menu Map header portion. Therefore, confirmation upon completion of rewriting the PU serial number can be performed by printing the Menu Map.

(2) Switching to the Shipping mode

When the engine control board is replaced with the new engine control board, the new board has been set in the Factory working mode. Therefore, it should be switched to the Shipping mode.

- Switch the mode by using the Maintenance Utilities section "2.4.1.1.2 PU board setting function" – section 2.4.1.1.2.2 Factory/Shipping mode" screen.

Note! The life control may contain an error because the life information of belt, toner and ID are cleared when the EEPROM (engine control board) is replaced, until the unit replacement is completed. The counts that are cleared by the EEPROM replacement are shown below. All the counts except the Total Sheets Fed are cleared when the unit is replaced with the new unit, the error is corrected at that time.

| Item | Contents | Count contents |
|--|-----------------------------------|---|
| Fuser unit | Fuser unit life count | Number of print copies after the new fuser unit is installed, after the data is converted to equivalent number of A4 size paper counts. |
| Belt unit | Belt unit life count | Number of print copies after the new belt unit is installed, after the data is converted to equivalent number of A4 size paper counts. |
| ID unit : Black ID unit : Yellow ID unit : Magenta ID unit : Cyan | Life count of respective ID units | Number of print copies after the new ID unit is installed, after the data is converted to equivalent number of A4 size paper counts. |
| Total number of papers fed | Printer life count | Total number of papers fed |
| Print : Black Print : Yellow Print : Magenta Print : Cyan | Number of print copies of each ID | Number of print copies after the new ID unit is installed. |

5.4.2 EEPROM setting upon completion of CU board replacement

When replacing the CU board, the user setup data that the user has been using should be inherited to the new replacement CU board. Method of inheriting the user setup data is shown below.

- ① Swap the EEPROM directly from the old board to the new board. (See below.)
- ② Copy the EEPROM data by using the Maintenance Utilities. (Refer to section 5.2)


However, if the service call 40 (EEPROM error) is being issued, the above methods of 1 and 2 cannot be used.

After replacing the CU board with the new board, set the network information such as IP address and others.

Swapping the EEPROM upon completion of CU board replacement

The EEPROM is installed in the CU board using the IC socket. Swap the EEPROM as described below.






1. Remove the EEPROM seal and the MAC address seal from the old CU board.
2. Insert a screwdriver tip between the EEPROM of old board and the IC socket, and remove the EEPROM while taking care not to bend the EEPROM leads.
3. Install the EEPROM to the new CU board. When installing it, check that the silk-screen print of the EEPROM and that of the new CU board show the same direction.
4. Attach the MAC address seal that has been removed from the old CU board, to the new CU board.
5. Confirm that the same IP address as that of the MAC address seal of the board has been set by performing the menu print.



5.5 Density control manual setting


When a printer is shipped from the factory, the automatic density correction mode has been set in "Automatic". If a printer is used after the density correction mode is set to "Manual", density may change during usage of a printer. Actions to be taken when density is not normal.

Note! Perform the followings while a printer is in the still state. Do not perform the followings during warm-up.

- (1) Press the MENU  or MENU  key several times until the [Calibration] is displayed. Then, press the ENTER key.
- (2) Press the MENU  or MENU  key to display [Adjust Density Execute].
- (3) Press the ENTER  key.

The automatic density correction starts.

5.6 Printer boot menu list

While pressing the  SET button, turn on the power to display the Boot Menu.

Memo To display the Boot Menu, entry of password is required. Default value of password is "aaaaaa".

| Category | Item | Setting value | Function |
|-----------------|-----------------------------------|--|---|
| | Enter Password | ***** | Enter password to enter Boot Menu. Enter the password of 6 to 12 digits of alphanumeric. The initial value is "aaaaaa". |
| Parallel Setup | Parallel | Enable | Setting Valid/Invalid of parallel interface. |
| | | Disable | |
| | Bi-Direction | Enable | Setting Valid/Invalid of bi-direction of parallel interface. |
| | | Disable | |
| | ECP | Enable | Setting Valid/Invalid of ECP mode. |
| | | Disable | |
| | Ack Width | Narrow | Setting the ACK width when receiving the compatible data. NARROW = 0.5 μs MEDIUM = 1.0 μs WIDE = 3.0 μs |
| Medium | | | |
| Wide | | | |
| Ack/Busy Timing | Ack in Busy | Setting order of outputting the BUSY signal and the ACK signal when receiving the compatible data. | |
| | Ack while Busy | | |
| I-Prime | 3 microseconds 50 microseconds | Setting Valid time/Invalid of the I- PRIME signal | |
| | Disable | | |
| Offline Receive | Enable | Setting Valid/Invalid of the function that enables to keep the signal reception possible without changing I/F signal even when an alarm is issued. | |
| | Disable | | |

| Category | Item | Setting value | Function |
|-------------------------|---------------------|---|---|
| USB Setup | USB | Enable | Setting Valid/Invalid of USB interface. |
| | | Disable | |
| | Speed | 480Mbps | Setting the maximum transfer speed of USB interface. |
| | | 12Mbps | |
| | Soft Reset | Enable | Setting Valid/Invalid of Soft Reset. |
| | | Disable | |
| Offline Receive | Enable | Setting Valid/Invalid of the function that enables to keep the signal reception possible without changing I/F signal even when an alarm is issued. | |
| | Disable | | |
| Serial Number | Enable | Setting Valid/Invalid of USB serial number. | |
| | Disable | | |
| Security Setup | Job Limitation | Off | Limits the job to accept. The encrypted authentication print only is accepted. It is displayed when the optional internal hard disk is installed. |
| | | Encrypted Job | |
| | Reset Cipher Key | Execute | Re-generates the encryption key that is used in the encrypted hard disk. It is displayed when the optional internal hard disk is installed, and the encrypted hard disk function is made valid. |
| Storage Setup | Check File System | Execute | Resolves the un-match between the actual (free) space and displayed free space of file system, and recovers the control data (FAT information.) |
| | Check All Sectors | Execute | Recovers the HDD sector information defect and un-match of the above file system. |
| | Enable HDD | No | A printer can start up even if HDD cannot start as it is damaged when it is installed, by setting "No" regardless of the HDD installation as a printer recognizes that HDD is not installed. |
| | | Yes | |
| | Erase HDD | Execute | Deletes all data stored in a hard disk so that the data cannot be recovered. It is displayed when the optional internal hard disk is installed. |
| Enable Initialization * | No Yes | The internal hard disk and flash memory are set so that they cannot be changed including initialization. *: It is displayed when [Function set] – [Print tabulation]– [Tabulation function] is set to [Valid] . | |
| Power Setup | Power Save | Enable | Setting Valid/Invalid of the save power mode. |
| | | Disable | |
| Language Setup | Language Initialize | Execute | Deletes the message file in a flash memory. |

6. Periodic Maintenance

| | |
|---|-----|
| 6.1 Cleaning | 119 |
| 6.2 How to clean the LED lens array | 120 |
| 6.3 How to clean the pickup roller | 122 |
| 6.4 How to clean inside of printer | 123 |

6.1 Cleaning


Clean inside and outside of the printer with clean dry cleaning cloth and small vacuum cleaner (hand cleaner) as required.

Note! Be careful not to touch the image drum terminals, the LED lens array and the LED head connectors.

6.2 How to clean the LED lens array

If the white banding, white stripe (white drop-out, light printing) in the vertical direction occurs on the print surface, clean the LED lens array.


White banding, white stripe
(white drop-out, light printing)




Perform cleaning of the LED head.

If any light print or white banding is recognized or if print character becomes blurred, clean the LED head as described below.


- (1) Turn off the power of the printer.



- (2) Press down the OPEN button to open the top cover.




The fuser unit gets very hot. Do not touch the fuser unit.




- (3) Wipe the lens surface (at the four positions) of the LED head with soft tissue paper gently and lightly.

Note! Do not use the solvents such as methyl alcohol or thinner for cleaning the LED head lens because they can damage the LED head.



- (4) Close the top cover.



6.3 How to clean the pickup roller


If the vertical banding in the vertical direction occurs on the print surface, clean the pickup roller.

Note! Be sure to use a soft cloth or the like for cleaning the pickup roller. Otherwise, the roller surface can be damaged.


Perform cleaning of the feed roller and the separation roller.

Perform this cleaning when the error code [391: Paper jam] occurs frequently.

- (1) Draw out the paper tray.
- (2) Clean the 2 feed rollers with a clean cloth stringently wrung out of clean water.



- (3) Clean the separation roller of the paper tray with a clean cloth wrung out stringently of clean water.




- Note!**
- Clean the second tray (option) in the same manner when the error code [392: Paper jam] occurs frequently.
 - Clean the feeder roller of the multi-purpose tray in the same manner when the error code [390: Check MP tray] occurs frequently.

6.4 How to clean inside of printer


Clean inside of the printer.

Toner can adhere to the metal shaft located in between the fuser and the cyan image drum cartridge depending on the print patten. Perform cleaning of inside of the printer if toner has adhered to the metal shaft.


- (1) Turn off the power of the printer.



- (2) Press down the OPEN to open the top cover.




The fuser unit gets very hot. Do not touch the fuser unit.




- (3) Remove the image drum cartridge.

1. Remove the four image drum cartridges and place them on a flat workbench.
2. Cover the removed image drum cartridge with a black paper.

- Note!**
- The image drum (green tubular portion) is highly inherently-brittle. Be very careful when handling it.
 - Be very careful not to expose the image drum to direct sun light or intense light (light of approx. 1500 lux or more). Do not leave it under the normal illumination even indoor for 5 minutes or longer.)




- (4) Remove the fuser unit.




The fuser unit gets very hot. Be very careful not to touch the fuser unit with your hands.

If it got hot, stop the work and wait until it cools down. After it has cooled down, start the following steps.

1. Raise the fuser unit lock levers (two levers shown in blue) in the direction shown by the arrow.
2. Hold the handle of the fuser unit and remove it.




- (5) Clean the metal shaft with soft clean cloth or soft tissue paper.



- (6) Install the fuser unit.

For the detailed procedure, refer to the User's Manual – Setup Guide "Replacing fuser unit".

- (7) Return the four image drum cartridges to the printer gently and carefully.
- (8) Close the top cover.



7. Troubleshooting and repair procedure

| | |
|---|-----|
| 7.1 Before starting the repair work | 126 |
| 7.2 Confirmation items before taking corrective action against abnormalities | 126 |
| 7.3 Precautions when taking corrective action against abnormality .. | 126 |
| 7.4 Preparation for troubleshooting | 126 |
| 7.5 Troubleshooting method | 127 |
| 7.6 Fuse check | 199 |
| 7.7 Paper cassette switches versus Paper size correspondence table | 200 |
| 7.8 Data protection kit-A1 | 201 |

7.1 Before starting the repair work

- (1) Confirm the basic check/inspection points described in User's Manual.
- (2) Get the information/status from client at the time when the trouble has occurred as much in details as possible
- (3) Create the status close to the user's status when the trouble has occurred, and inspect a printer in that status.

7.2 Confirmation items before taking corrective action against abnormalities

- (1) Is the usage environment of a printer normal?
- (2) Are the consumable items (toner, drum cartridge) replaced normally?
- (3) Is the print media (paper) normal? Refer to Specifications – Paper in User's Manual.
- (4) Is the drum cartridge installed normally?

7.3 Precautions when taking corrective action against abnormality


- (1) Do not touch the OPC drum surface with your hand or any foreign materials.
- (2) Do not expose the OPC drum to the direct sunlight.
- (3) The fuser unit will be hot. Do not touch.
- (4) Do not expose the image drum to any light for 5 minutes or longer under the normal room temperature.

7.4 Preparation for troubleshooting

- (1) Display on the Operator Panel
Error status of this printer is displayed on the LCD (Liquid crystal display) of the Operator Panel.
Take appropriate troubleshooting action in accordance with the message displayed on the LCD.

7.5 Troubleshooting method

When a trouble occurs in this printer, perform troubleshooting by following the steps described below.



7.5.1 LCD message list

Initializing

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details |
|---|--------------|-----------------|---|
| PLEASE WAIT | Off | Off | It is displayed until the RAM expansion of the CU program is in progress. |
| Initializing | Off | Off | Indicates initialization of the controller side is in progress. |
| EEPROM Reset | Off | Off | Indicates the controller side EEPROM is reset. The conditions for resetting the EEPROM are shown below. <ul style="list-style-type: none"> • CU ROM is changed (Unmatch of the CU F/W version is detected.) • Destination is changed. • Forced initialization of EEPROM (System Maintenance Menu) • Setting OEM by the PjL command. |
| RAM Check ***** | Off | Off | Indicates that RAM check is in progress. Percentage of the checked capacity against the total capacity is shown in the second line. |
| Wait a Moment Network Initializing | Off | Off | Indicates the network initialization is in progress. |
| Flash Memory Check | Off | Off | Indicates that the flash memory contents are being checked. If a resident/option flash memory that is not formatted yet is detected, it is displayed when the menu item [FLASH FORMAT] is selected from [MAINTENANCE MENU] of the System Maintenance Menu. Because the above menu item is internally use only and is not disclosed to user, this status does not occur in the user environment. |
| Flash Memory Format | Off | Off | Indicates that the flash memory formatting is in progress. If a resident/option flash memory that is not formatted yet is detected, it is displayed when the menu item [FLASH FORMAT] is selected from [MAINTENANCE MENU] of the System Maintenance Menu. Because the above menu item is internally use only and is not disclosed to user, this status does not occur in the user environment. |

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details |
|---|--------------|-----------------|---|
| Program Update Mode | Off | Off | Indicates that the printer has entered in the dedicated mode for upgrading the NIC program (controller firmware) version. |
| Wait a Moment Program Data Received | Off | Blink | Indicates that reception of the NIC program data for upgrading is in progress. |
| Wait a Moment Program Data Received OK | Off | Off | Indicates that reception of the NIC program data for upgrading is complete. |
| Check Data Program Data Receive Error <nnn> | Off | On | Indicates that an error has occurred during reception of the NIC program data for upgrading. %DLCODE% 1 : Size error 2 : Checksum error 3 : Printer model number error 4 : Module I/F version error 5 : FAT version error |
| Wait a Moment Program Data Writing | Off | Blink | Indicates that writing of the NIC program data for upgrading is in progress. |
| Power Off/On Program Data Writing OK | Off | Off | Indicates that writing of the NIC program data for upgrading is in complete. |
| Check Data Program Data Write Error <nnn> | Off | On | Indicates that an error has occurred during writing of the NIC program data for upgrading. %DLCODE% 1 : Memory allocation error 2 : Download file error 3 : Device free space acquisition error 4 : Device insufficient free space error 5 : File write error 6 : CU-F/W mismatch error |
| PU Flash Error | Off | Off | Indicates that the PU firmware has started up in the Loader mode. It is indicated when the PU firmware has returned "00.00.00" against the Leisus command "VERSIONR 01H" requesting (PU) firmware version information supplied from the CU firmware at power-on. When initialization is finished, it is switched to the Priority 251 status. This error can occur in the user environment. If this error occurs, maintenance by a maintenance engineer is required. (Same as S/C) |

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details |
|---|--------------|-----------------|--|
| Communication Error | Off | Off | Indicates that communication with the PU firmware has failed. This error can occur in the user environment. If this error occurs, maintenance by a maintenance engineer is required. (Same as S/C) |
| Status Mode | Off | Off | Indicates that the printer has started in the ON LINE mode always. When a printer starts up in this mode, it processes the data (job) from outside (host) even when an error occurs if a printer has entered the ON LINE mode once. Error and warning are displayed on the panel. A printer can enter in this mode if the power of a printer is turned on while pressing the switches of <Enter> + <Back> + <Down> all simultaneously. Because this pattern of pressing the multiple switches at the same time at power-on is not disclosed to user, this status will not occur in the user environment. |

Normal

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details | Remedial measure |
|---|--------------|-----------------|--|--|
| Ready to start printing. | On | Off | Indicates that a printer is in the ON LINE status. | - |
| OFF LINE | Off | Off | Indicates that a printer is in the OFF LINE status. * The Ready LED is turned off all the time during OFF LINE. | To start printing from a PC, press the ON LINE button to enter the ON LINE state. |
| File access in progress | Varies | Varies | Indicates that access to a file system (HDD/FLASH) is under way. | - |
| Receiving data | Varies | Varies | Indicates that the data reception is in progress, and processing has not started yet. This error indicates during the period of P.JL processing without character print, or during job through mainly. | - |
| Processing in progress | Blink | Varies | Indicates that data reception or output processing is progress. | - |
| There exists remaining data. | Varies | Varies | Indicates that the un-printed data remains in buffer. A printer is in the state of waiting for the data to receive | If a printer is stopped while indicating the state of "Remaining data exists", print the data forcibly by pressing the ON LINE button, or delete the remaining data by pressing the CANCEL button. |

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details | Remedial measure |
|---|--------------|-----------------|--|------------------|
| Printing from %TRAY% in progress | Varies | Varies | Indicates that a printer is in the midst of printing job. | - |
| Printing demo page | Varies | Varies | Indicates that a printer is in the midst of printing demo page. | - |
| Printing setup contents | Varies | Varies | Indicates that a printer is in the midst of printing menu map. | - |
| Printing the network setting | Varies | Varies | Indicates that a printer is in the midst of printing the network setting. When the menu [Information Menu] – [Network] is selected, printing of the network setting starts. | - |
| <input type="checkbox"/> <input type="checkbox"/> Gathering print iii/jjj | Varies | Varies | Indicates that a printer is in the midst of gather print. iii indicates number of copies in progress, and jjj indicates total number of printed copies. When total number of copies is 1, the normal indication of PRINTING is displayed. | - |
| <input type="checkbox"/> <input type="checkbox"/> Copy print kkk/lll | Varies | Varies | Indicates that a printer is in the midst of Copy printing. kkk indicates number of copies in progress, and lll indicates total number of printed copies. When total number of copies is 1, the normal indication of PRINTING is displayed. | - |
| Deleting data | Blink | Varies | Cancel of the job is indicated. A printer is discarding the data until end of the job. | - |
| Deleting data (Jam) | Blink | Varies | This message is displayed when a jam occurs during jam recovery off. Cancel of the job is indicated. A printer is discarding the data until end of the job. | - |
| Deleting data (without print permit) | Blink | Varies | Indicates that canceling of a printing without permission is in progress. (Job Account related) 1. When a job is received from a user that is not authorized to print. 2. When a color job is received from a user that is not authorized to make a color print. | - |

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details | Remedial measure |
|---|--------------|-----------------|---|------------------|
| Deleting data (Buffer full) | Blink | Varies | Indicates that canceling a job is in progress because the log storage area inside a printer has run out of memory space, and the operation "Cancel the job" is specified at log full. (JobAccount) | - |
| <input type="checkbox"/> Adjusting the fuse temperature. | Varies | Varies | Indicates that a printer is in the midst of cooling down. Note that (period) is added at the end of message "Adjusting the fuse temperature." | - |
| <input type="checkbox"/> Adjusting the fuse temperature. | Varies | Varies | Indicates that a printer is in the midst of warming up. During this period, #0 of the Leisus I/F: STSENG bit is "0". | - |
| <input type="checkbox"/> Adjusting temperature | Varies | Varies | Indicates that printing is stopped temporarily due to high temperature of a drum. Alternately, this message indicates that a printer is in the standby state waiting for the thermal cooling down when switching paper size from narrow to wide. | - |
| <input type="checkbox"/> In the power save mode | Varies | Varies | Indicates that a printer is in the power save status. When a printer enters the power save mode, the LCD backlight turns off. When it exits the power save mode, the LCD backlight turns on. If the switch is pressed while the backlight is off (in the power save mode), the backlight turns on, and then turns off in 30 seconds. However, the power save mode is not canceled. The backlight turns on during shut-down (Priority 365). | - |
| <input type="checkbox"/> Adjusting color | Varies | Varies | Indicates that the automatic color registration correction is in progress. | - |
| <input type="checkbox"/> Adjusting density | Varies | Varies | Indicates that the automatic density correction is in progress. The status code 10988 corresponds to the density read-out (Leisus – STSDEN #1) and 10994 corresponds to the density correction (Leisus – STSDEN #0). | - |

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details | Remedial measure |
|---|--------------|-----------------|---|------------------|
| Flash Downloar | Varies | Varies | Indicates that downloading of the PU firmware program data is in progress. Since downloading of the PU firmware is opened internally only and not disclosed to user, the status will not occur in the user environment. | - |

Warning

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details | Remedial measure |
|---|--------------|------------------------|---|------------------|
| <input type="checkbox"/> %COLOR% Amount of toner becomes scarce. | Varies | On (Blink) (Off) | <p>Indicates that amount of toner becomes scarce. If the menu has been set as follows: "System Configuration Menu – "LOW TONER – PRINT CONTINUE" = Stop , the inspection LED flashes and a printer moves to the OFF LINE state.</p> <p>When the ON LINE switch is pressed, or when an arbitrary error has occurred and the error is released, the print is continued by canceling the OFF LINE status, until TONER EMPTY is detected.</p> <p>An arbitrary error is any of the errors of Priority 301 through 361.</p> <p>When the TONER LOW status has occurred when the power is turned on, and when the menu has been set as follows: "System Configuration Menu" – "LOW TONER – PRINT CONTINUE" = Stop, the inspection LED flashes and a printer moves to the OFF LINE state at the timing when initialization has ended.</p> <p>When the ON LINE switch is pressed, the printing can be continued until TONER EMPTY. If the menu has been set as follows: ADMIN MENU "CONFIG MENU" – "NEAR LIFE LED = DISABLE", the inspection LED turns off.</p> <p>%COLOR%</p> <p>Y M C K</p> | – |

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details | Remedial measure |
|---|--------------|-----------------|---|--|
| <input type="checkbox"/> %COLOR% Waste toner is full. Replace the toner. | Varies | On | <p>This warning is displayed when the cover is Opened/Closed or the power is turned OFF and back ON after the Waste Toner Full error (priority 321.8) has been issued. (Black does not occur.) This warning is displayed in combination with the other message. While this warning is being issued, the Waste Toner Full error is issued every approx. 50 copies of printing and then the printer enters the OFF LINE stop.</p> <p>%COLOR%</p> <p>M C</p> | Replace the toner cartridge of the indicated color. |
| <input type="checkbox"/> NON. OEM.%COLOR%. Toner | Varies | On | <p>Indicates the toner cartridge is not for use in the printer.</p> <p>%COLOR%</p> <p>Y M C K</p> | Prompt user to use the appropriate toner cartridge. |
| <input type="checkbox"/> %COLOR% Illegal Toner | Varies | On | <p>Indicates the toner cartridge is not for use in the printer.</p> <p>%COLOR%</p> <p>Y M C K</p> | Prompt user to use the appropriate toner cartridge. |
| <input type="checkbox"/> %COLOR% Cannot recognize the toner cartridge. | Varies | On | <p>Indicates the toner cartridge is not for use in the printer.</p> <p>%COLOR%</p> <p>Y M C K</p> | Tell user that the trouble caused by usage of the inappropriate toner cartridge is outside the range of free repair by warranty to prompt user to use the appropriate toner cartridge. |

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details | Remedial measure |
|---|--------------|-----------------|---|---------------------------------------|
| <input type="checkbox"/> %COLOR% Image drum is reaching near life end. | Varies | On (Off) | Indicates that the image drum is reaching near life end. Print can be continued until the image drum reaches end of life. When the menu has been set as follows: ADMIN MENU [CONFIG MENU] – [NEAR LIFE LED] = DISABLE, the inspection LED is turned off. %COLOR% Y M C K | – |
| <input type="checkbox"/> Fuser is reaching near life end. | Varies | On (Off) | Indicates that the fuser is reaching near life end. If the menu has been set as follows: ADMIN MENU "CONFIG MENU" – "NEAR LIFE LED = DISABLE", the inspection LED is turned off. | – |
| <input type="checkbox"/> Belt is reaching near life end. | Varies | On (Off) | Indicates that the transfer belt is reaching near life end. Because it is warning only, print is not stopped. If the menu has been set as follows: ADMIN MENU "CONFIG MENU" – "NEAR LIFE LED = DISABLE", the inspection LED is turned off. | – |
| <input type="checkbox"/> Replace the fuser. | Varies | On | Indicates that the fuser had reaching end of life (warning). It is warning only. (Life end error is not issued.) This status is displayed when the cover is Opened/Closed after the Fuser Life error has been issued. If the Print CONTINUE mode at fuser life end (not disclosed to user) has been set to ON, this warning is displayed instead of the fuser life end error. | Replace the fuser with the new fuser. |

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details | Remedial measure |
|---|--------------|-----------------|--|---|
| <input type="checkbox"/> Replace the belt. | Varies | On | Indicates that the transfer belt has reached end of life (warning). Warning only. (Life end error is not issued.) This status is displayed when the cover is Opened/Closed after the transfer belt has reached end of life. If the mode of Print CONTINUE at the transfer belt life end (not disclosed to user) has been set to ON, this status is issued instead of the transfer belt life end error. | Replace the belt unit with the new belt unit. |
| <input type="checkbox"/> %COLOR% The printer runs out of toner. | Varies | On | Indicates that the printer runs out of toner. This status (warning) is issued when the cover is Opened/Closed once after the error is issued to recover the printer once. If the mode of Print CONTINUE at the toner run-out (not disclosed to user) has been set to ON, this status is issued instead of the toner run-out error. %COLOR% Y M C K | Replace the toner cartridge with the new toner cartridge. |
| <input type="checkbox"/> %COLOR% The toner cartridge is not installed in the printer. | Varies | On | Indicates that the toner cartridge is not installed. This status is warning only. %COLOR% Y M C K | Install the toner cartridge. Be careful that the toner cartridge supplied with the product cannot be used if the toner cartridge of other supply is used. |

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details | Remedial measure |
|---|--------------|-----------------|--|--|
| <input type="checkbox"/> %COLOR% Replace the image drum. | Varies | On | Indicates that the image drum has reached end of life. This status (warning) is issued when the cover is Opened/Closed once after the Image Drum Life end error is issued to recover the printer once. %COLOR% Y M C K | Replace the image drum of the indicated color. |
| <input type="checkbox"/> Belt Reflex Error | Varies | On | Belt reflectance check error Because the PU firmware does not notice this status to the CU firmware in the Shipping Mode even when the PU firmware has detected this status, this error does not occur in the user environment. | - |
| <input type="checkbox"/> Density Shutter Error2 | Varies | Varies | Density correction shutter error 2 Because the PU firmware does not notice this status to the CU firmware in the Shipping Mode even when the PU firmware has detected this status, this error does not occur in the user environment. | - |
| <input type="checkbox"/> Density Shutter Error1 | Varies | Varies | Density correction shutter error 1 Because the PU firmware does not notice this status to the CU firmware in the Shipping Mode even when the PU firmware has detected this status, this error does not occur in the user environment. | - |
| <input type="checkbox"/> Density Color Calibration Error | Varies | Varies | Density correction color calibration error Because the PU firmware does not notice this status to the CU firmware in the Shipping Mode even when the PU firmware has detected this status, this error does not occur in the user environment. | - |
| <input type="checkbox"/> Density Color Sensor Error | Varies | Varies | Density correction color sensor error Because the PU firmware does not notice this status to the CU firmware in the Shipping Mode even when the PU firmware has detected this status, this error does not occur in the user environment. | - |

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details | Remedial measure |
|---|--------------|-----------------|--|------------------|
| <input type="checkbox"/> Density Black Calibration Error | Varies | Varies | Density correction black calibration error. Because the PU firmware does not notice this status to the CU firmware in the Shipping Mode even when the PU firmware has detected this status, this error does not occur in the user environment. | - |
| <input type="checkbox"/> Density Black Sensor Error | Varies | Varies | Density correction black sensor error. Because the PU firmware does not notice this status to the CU firmware in the Shipping Mode even when the PU firmware has detected this status, this error does not occur in the user environment. | - |
| <input type="checkbox"/> %COLOR% Image Drum Smear Error | Varies | Varies | Density correction ID ERROR 2. This error occurs when abnormal density due to the LED head focus error is detected. (Extremely stained LED head) Because the PU firmware does not notice this status to the CU firmware in the Shipping Mode even when the PU firmware has detected this status, this error does not occur in the user environment. %COLOR% Y M C K | - |
| <input type="checkbox"/> %COLOR% Low Density Error | Varies | On | Density correction ID ERROR. This error occurs when abnormal density is detected when stain has occurred in print due to ID error. (Extremely out of focus). Because the PU firmware does not notice this status to the CU firmware in the Shipping Mode even when the PU firmware has detected this status, this error does not occur in the user environment. %COLOR% Y M C K | - |

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details | Remedial measure |
|---|--------------|-----------------|--|------------------|
| <input type="checkbox"/> Density Calibration Error | Varies | On | Sensor adjustment error Because the PU firmware does not notice this status to the CU firmware in the Shipping Mode even when the PU firmware has detected this status, this error does not occur in the user environment | - |
| <input type="checkbox"/> Registration Error <n> | Varies | On | Color registration correction error. Indicates that an error has occurred during the coarse adjustment or in the main scanning line correction. Because the PU firmware does not notice this status to the CU firmware in the Shipping Mode even when the PU firmware has detected this status, this error does not occur in the user environment. n 2=Y 3=M 4=C 5= | - |
| <input type="checkbox"/> Registration Sensor Error <n> | Varies | On | Color registration correction sensor error Because the PU firmware does not notice this status to the CU firmware in the Shipping Mode even when the PU firmware has detected this status, this error does not occur in the user environment. n 2=Y 3=M 4=C 5= | - |

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details | Remedial measure |
|---|--------------|-----------------|--|--|
| <input type="checkbox"/> %COLOR% Head Data Error | Varies | On | Cannot fine the correction data for the LED head. Alternately, the correction data for the LED head is illegal. Because the PU firmware does not notice this status to the CU firmware in the Shipping Mode even when the PU firmware has detected this status, this error does not occur in the user environment. %COLOR% Y M C K | - |
| <input type="checkbox"/> %TRAY% runs out of paper. | Varies | On | Indicates that the tray runs out of paper. Warning only is issued until the tray that runs out paper is specified for print. %TRAY% Tray 1 Tray 2 Tray 3 MP tray | Feed paper to the indicated tray. |
| <input type="checkbox"/> The file system is full. | Varies | On | Indicates that the file system that has been constructed on the recording device (HDD/FLASH) runs out of free space. Because this is a temporary warning, this warning is indicated until the job is complete. It disappears at the completion of the job. | Explain user that no remedial measure is required. |
| <input type="checkbox"/> Writing in the file system is prohibited. | Varies | Varies | Indicates that an attempt is made to write data in the file system that has been constructed on the recording device (HDD/FLASH), and is prohibited of writing data. Because this is a temporary warning, this warning is indicated until the job is complete. It disappears at the completion of the job. | Explain user that no remedial measure is required. |

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details | Remedial measure |
|---|--------------|-----------------|--|---|
| <input type="checkbox"/> ***Flash Error | Varies | Varies | PU flash error (Error has occurred during re-writing of the PU firmware.) %PUFLASH% is described below. PU TRAY2 DUPLEX | - |
| <input type="checkbox"/> Gathering print error Press the ON LINE button. | Varies | On | Indicates that the MOPY memory is data full. This error is kept displayed until the ON LINE key is pressed. | Reduce the number of pages that are going to be printed at once. |
| <input type="checkbox"/> Because print restriction has been set, the data is deleted. Press the ON LINE button. | Varies | On | Notify user that the job is canceled because the print permission is not set. (Job Account related). This error is kept displayed until the ON LINE key is pressed. | <ul style="list-style-type: none"> • Set the user ID of the job account in the printer driver. • If the user ID has been set in the driver, confirm the user ID and its setting with the job account administrator. |
| <input type="checkbox"/> Because the log buffer is full, the data is deleted. Press the ON LINE button. | Varies | On | Notify user that the job is canceled because the log buffer is full. (Job Account related) This error is kept displayed until the ON LINE key is pressed. | Executeto [Acquire immediately] on the server PC of the print job accounting. |

| Panel display (The <input type="checkbox"/> mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details | Remedial measure |
|---|--------------|-----------------|--|--|
| <input type="checkbox"/> File system access error <nnn> Press the ON LINE button. | Varies | On | Indicates that a file system error other than the above-described file system related status error, has occurred. The processing that does not used the file system can be operated. %FS_ERR% =0.... GENERAL ERROR =1.... VOLUME NOT AVAILABLE =3.... FILE NOT FOUND =4....NO FREE FILE DESCRIPTORS =5.... INVALID NUMBER OF BYTES =6.... FILE ALREADY EXISTS =7.... ILLEGAL NAME =8.... CANT DEL ROOT- =9.... NOT FILE =10.. NOT DIRECTORY =11.. NOT SAME VOLUME =12.. READ ONLY =13.. ROOT DIR FULL =14.. DIR NOT EMPTY =15.. BAD DISK =16.. NO LABL =17.. INVALID PARAMETER =18.. NO CONTIG SPACE =19.. CANTCHANGE ROOT =20.. FD OBSOLETE =21.. DELETED =22.. NO BLOCK DEVICE =23.. BAD SEEK =24.. INTERNAL ERROR =25.. WRITE ONLY | Replace the HDD. No remedial action is required when print such as authentication print is not used. |
| The has received invalid data. Press the ON LINE button. | Varies | Varies | Prompt user to press the ON LINE switch to disappear the warning because the printer has received an invalid data. This error is displayed when a printer has received the unsupported PDL command. | Press the ON LINE switch. |

| Panel display (The □ mark indicates no message in the upper row.) | ON LINE lamp | Inspection lamp | Details | Remedial measure |
|---|--------------|-----------------|--|---|
| Feed paper. Multipurpose tray %MEDIA_SIZE% Press the ON LINE button. | On | Off | Indicates that the print request of manual paper feed is issued. Prompt user to feed manually the paper that is indicated by %MEDIA_SIZE%. Unit of paper size in the Custom mode follows the unit specified display unit (menu setting) of the MP tray unless otherwise specified by driver. If unit of paper size is specified by driver, it is displayed in units specified by driver. Paper size in the Custom mode is displayed as "<width> x <length> <unit>" ex: 210 x 297 mm 8.5 x 11.0 inch | Press the ON LINE switch. * The data will be deleted unless the ON LINE switch is pressed within the time set by [Manual Timeout]. |

If a printer detects an un-recoverable error, the following service call error is displayed on the LCD.

Service call

nnn: error

Note! nnn indicates an error code.

When a service call is displayed, the error code and the associated error information are displayed in the lower row of the LCD display at the same time.

Be sure to take note of this error information (numerals indicating address and others) and inform it to the related departments because the information is used for trouble analysis and solution. Meaning of error codes and remedial measures are shown in Tables 7-1-1 and 7-1-2.

Table 7-1-1 Operator alarm

| Display on operator panel | ON LINE lamp | Inspection lamp | Contents | Code nnn |
|--|--------------|-----------------|--|-------------------------|
| Change paper of the %TRAY% Insert the %MEDIA_SIZE% %MEDIA_TYPE% and press the ON LINE switch. For details, see on-line help. | Off | Blink | Indicates unmatched between the media type in the tray and the print data occurs. Prompt user to insert paper in the tray. Error-661: Tray-1 Error-662: Tray-2 Error 461: Tray 1 Error 462: Tray 2 Unit of paper size in the Custom mode follows the unit specified display unit (menu setting) of the MP tray unless otherwise specified by driver. If unit of paper size is specified by driver, it is displayed in units specified by driver. Paper size in the Custom mode is indicated as follows: "<Width> x <Length> <unit>" ex : 210 x 297 mm 8.5 x 11.0 inch User is requested to change paper of the tray and press the ON LINE key. | Error 461 462 |

| Display on operator panel | ON LINE lamp | Inspection lamp | Contents | Code nnn |
|---|--------------|-----------------|--|--------------------------------|
| Change paper of the multipurpose tray. Insert the %MEDIA_SIZE% %MEDIA_TYPE% and press the ON LINE switch. For details, see on-line help. | Off | Blink | Indicates unmatched media type in the tray and the print data occurs. Prompt user to insert paper in the tray. Error-660: Multipurpose tray Error 460: Multipurpose tray Unit of paper size in the Custom mode follows the unit specified display unit (menu setting) of the MP tray unless otherwise specified by driver. If unit of paper size is specified by driver, it is displayed in units specified by driver. ex: 210 x 297mm 8.5 x 11.0 inch User is requested to change paper of the tray and press the ON LINE key. | Error 460 |
| Change paper of the %TRAY%. Insert the %MEDIA_SIZE% %MEDIA_TYPE% and press the ON LINE switch. For details, see on-line help. | Off | Blink | Indicates that the paper size of the tray or the paper size, and the media type do not match the print data. Prompt user to insert paper in the tray. Error 461: Tray 1 Error 462: Tray 2 Error 462: Tray 3 Unit of paper size in the Custom mode follows the unit specified display unit (menu setting) of the MP tray unless otherwise specified by driver. If unit of paper size is specified by driver, it is displayed in units specified by driver. ex: 210 x 297mm 8.5 x 11.0 inch User is requested to change paper of the tray and press the ON LINE key. | Error 461 462 463 |

| Display on operator panel | ON LINE lamp | Inspection lamp | Contents | Code nnn |
|---|--------------|-----------------|---|------------------|
| Change paper of the multipurpose tray. Insert the %MEDIA_SIZE% %MEDIA_TYPE% and press the ON LINE switch. For details, see on-line help. | Off | Blink | Indicates that the paper size of the tray or the paper size, and the media type do not match the print data. Prompt user to insert paper in the tray. Error 460: Multipurpose tray Unit of paper size in the Custom mode follows the unit specified display unit (menu setting) of the MP tray unless otherwise specified by driver. If unit of paper size is specified by driver, it is displayed in units specified by driver. ex: 210 x 297mm 8.5 x 11.0 inch User is requested to change paper of the tray and press the ON LINE key. | Error 460 |
| Processing of download message is in progress | Varies | Varies | Indicates that processing of the message data for upgrade is in progress. | Error (ONLINE) |
| Writing of download message is in progress | Varies | Varies | Indicates that writing of the message data for upgrading is in progress. | Error (ONLINE) |
| Writing of download message is complete | Varies | Varies | Indicates that writing of the message data for upgrading has completed with success. | Error (ONLINE) |
| Failed to write the download message %CODE% | Varies | Varies | Indicates that writing of the message data for upgrading has failed. %CODE% is a decimal value (single digit) indicating cause of the writing failure. =1 FAIL Cause of the failure is unknown. =2 DATA_ERROR Hash check error during data read/write. FLASH error =3 OVERFLOW Download failure because the FLASH capacity became full during writing or reading the language file. =4 MEMORY FULL Failed to secure memory space. =5 UNSUPPORTED_DATA Download of the data that is not supported by the printer. | Error (ONLINE) |
| Writing of the network setting contents is in progress | Varies | Varies | When the network related setting items are updated, contents of them are saved in the flash memory. | Error (ONLINE) |

| Display on operator panel | ON LINE lamp | Inspection lamp | Contents | Code nnn |
|--|--------------|-----------------|--|---------------------|
| Wait for a while. Network initialization is in progress. | Varies | Varies | Indicates the network initialization is in progress. | Error (ONLINE) |
| Insert %MEDIA_SIZE% %ERRCODE%: The %TRAY% runs out of paper. | Off | Blink | Indicates that a print request is issued to the tray that has run out of paper. Prompting user to refill paper. Error 491: Tray 1 Error 492: Tray 2 Unit of paper size in the Custom mode follows the unit specified by menu unless otherwise specified by driver. If unit of paper size is specified by driver, it is displayed in units specified by driver. | Error 491 492 |
| Insert the %MEDIA_SIZE% and press the ON LINE switch. %ERRCODE%: The MP tray runs out of paper. | Off | Blink | Indicates that a print request is issued to the multipurpose tray that has run out of paper. Paper feed restarts when user pressed the ON LINE switch. Error 490: Multipurpose tray Unit of paper size in the Custom mode follows the unit specified by driver. If unit of paper size is specified by driver, it is displayed in units specified by driver. This error occurs when the tray is in the home position, and the sensor "PE SENS 2" cannot detect paper. | Error 490 |
| Insert a cassette. %ERRCODE%: Tray 1 is left blank. | Off | Blink | Indicates that cassette is removed from the tray 1 that is located in the path when a print from tray 2 is attempted. | Error 440 |
| Insert a cassette. %ERRCODE%: The %TRAY% is not installed. | Off | Blink | Indicates that paper feeding is not possible because cassette has been removed from the corresponding tray when a print from the tray is attempted. | Error 430 |

| Display on operator panel | ON LINE lamp | Inspection lamp | Contents | Code nnn |
|--|--------------|-----------------|---|-----------------------------------|
| Add memory. %ERRCODE%: Memory overflow | Off | Blink | Indicates the data overflow exceeding the memory free space due to the following reasons. The processing is continued when the ON LINE switch is pressed. Install the add-on RAM or decrease amount of data. Cause of the trouble is that the following phenomenon has occurred. Amount of print data within a single page is too many. | Error 420 |
| Change the toner. %ERRCODE%: The %COLOR% waste toner is full. | Off | Blink | Indicates that the waster toner of %COLOR% is full requiring replacement of toner. Error 414: Y Error 415: M Error 416: C (This error does not occur in the black toner.) When the cover is opened/closed, it changes to the warning status making possible to perform printing of approx 50 copies. | Error 414 415 416 |
| Replace the toner. %ERRCODE%: The %COLOR% runs out of toner | Off | Blink | Indicates that the printer runs out of toner. When the cover is opened/closed, it changes to the warning status. Error 410: Y Error 411: M Error 412: C Error 413: K | Error 410 411 412 413 |
| Replace the toner. %ERRCODE%: The %COLOR% toner is illegal. | Off | Blink | Indicates the toner cartridge is not for use in the printer. The printer recovers from the error after replacement of the toner cartridge with a toner cartridge for the printer. Error 554: Y Error 555: M Error 556: C Error 557: K | Error 554 555 556 557 |

| Display on operator panel | ON LINE lamp | Inspection lamp | Contents | Code nnn |
|---|--------------|-----------------|--|---------------------------------------|
| Replace the toner. %ERRCODE%: The %COLOR% toner is for printer of another manufacturer. | Off | Blink | Indicates the toner cartridge is not for use in the printer. The printer recovers from the error after replacement of the toner cartridge with a toner cartridge for the printer. Error 614: Y Error 615: M Error 616: C Error 617: K | Error 614 615 616 617 |
| Replace the toner. %ERRCODE%: The %COLOR% toner is for printer of another manufacturer. | Off | Blink | Indicates the toner cartridge is not for use in the printer. The printer recovers from the error after replacement of the toner cartridge with a toner cartridge for the printer. Error 620: Y Error 621: M Error 622: C Error 623: K | Error 620 621 622 623 |
| Use of the genuine toner is recommended. %ERRCODE%: The %COLOR% toner is not the OKI Data genuine toner. | Off | Blink | Indicates the toner cartridge is not for use in the printer. The printer recovers from the error after replacement of the toner cartridge with a toner cartridge for the printer. Error 550: Y Error 551: M Error 552: C Error 553: K | Error 550 551 552 553 |
| Set the toner. %ERRCODE%: The %COLOR% toner is not installed. | Off | Blink | Indicates that toner cartridge is not installed. Error 610: Y Error 611: M Error 612: C Error 613: K | Error 610 611 612 613 |

| Display on operator panel | ON LINE lamp | Inspection lamp | Contents | Code nnn |
|---|--------------|-----------------|---|--|
| Check toner cartridge %ERRCODE%: %COLOR% toner sensor error. | Off | Blink | Indicates that the toner sensor has detected the error. Error 540: Yellow Error 541: Magenta Error 542: Cyan Error 543: Black | Error 540 541 542 543 |
| Open the front cover. %ERRCODE%: Paper size error | Off | Blink | Informs that a paper of illegal size is fed from the tray. Check paper in the tray, or check if multiple sheets of paper are transported simultaneously by mistake or not. The recovery print is executed when the cover is Opened/Closed | Error 400 |
| Open the top cover. %ERRCODE%: Multiple sheets of paper are transported simultaneously by mistake. | Off | Blink | Informs that a paper having illegally long size is fed from the tray. Check if multiple sheets of paper are transported simultaneously by mistake or not. The recovery print is executed when the cover is Opened/Closed. | Error 401 |
| Check the MP tray. %ERRCODE%: Paper jam | Off | Blink | Indicates that jam has occurred during feeding paper from the MP tray. Error 390: MP Tray | Error 390 |
| Open the front cover. %ERRCODE%: Paper jam | Off | Blink | Indicates that jam has occurred during feeding paper from the this tray. Error 391: Tray 1 Error 392: Tray 2 Error 393: Tray 3 | Error 391 392 393 |
| Open the front cover. %ERRCODE%: Paper jam | Off | Blink | Indicates that jam has occurred in the paper path. Error 380: Feed | Error 380 |
| Open the door cover. %ERRCODE%: Paper jam | Off | Blink | Indicates that jam has occurred in the paper path. Error 381: Transport Error 382: Exit Error 383: Duplex Entry Error 385: Around Fuser Unit Error 389: Printing Page Lost | Error 381 382 383 385 389 |

| Display on operator panel | ON LINE lamp | Inspection lamp | Contents | Code nnn |
|---|--------------|-----------------|---|-----------------------------------|
| Open the rear cover. %ERRCODE%: Paper jam | Off | Blink | Indicates that jam has occurred in the vicinity of Duplex unit. Error 370: Duplex Reversal Error 371: Duplex Input Error 373: Duplex Multifeed | Error 370 371 373 |
| Open the front cover. %ERRCODE%: Paper jam | Off | Blink | Indicates that jam has occurred in the vicinity of Duplex unit. Error 372: Duplex misfeed | Error 372 |
| Install the Duplex unit. %ERRCODE%: Duplex unit is not installed. | Off | Blink | Indicates that the Duplex unit is removed. If this error is detected, printing is stopped. | Error 360 |
| Replace the drum. %ERRCODE%: The %COLOR% drum has reached end of life. | Off | Blink | Informs the image drum has reached end of line (alarm). When the cover is opened/closed, it changes to the warning status. Error 350: Y Error 351: M Error 352: C Error 353: K | Error 350 351 352 353 |
| Replace the drum. %ERRCODE%: The %COLOR% drum has reached end of life. | Off | Blink | Informs the image drum has reached end of line (alarm). It is displayed until the image drum is replaced. Error 560: Y Error 561: M Error 562: C Error 563: K | Error 560 561 562 563 |
| Replace the fuser. %ERRCODE%: The fuser has reached end of life. | Off | Blink | Informs the image drum has reached end of line. This error is issued when the counter detects that the fuser has reached end of life. Print is stopped. When the cover is opened/closed, it changes to the warning status. | Error 354 |
| Replace the belt. %ERRCODE%: The belt has reached end of life. | Off | Blink | Informs that the transfer has reached end of line. This error is issued when the counter detects that the belt has reached end of life. Print is stopped. When the cover is opened/closed, it changes to the warning status. | Error 355 |

| Display on operator panel | ON LINE lamp | Inspection lamp | Contents | Code nnn |
|---|--------------|-----------------|--|-----------------------------------|
| Re-set the fuser. %ERRCODE%: Fuser error | Off | Blink | Indicates that an error is issued in the release position sensor of the fuser. The printer recovers from this error if the release position sensor has read out the data after the cover is closed. If the printer still cannot recover from this error, replacement of the fuser is required. | Error 348 |
| Replace the belt. %ERRCODE%: The belt has reached end of life. | Off | Blink | Indicates that the waster toner is full. It changes to the warning status after the cover is opened and closed only once. This error is issued again after 500 copies are printed. | Error 356 |
| Check the toner cartridge. %ERRCODE%: %COLOR%. The lock lever position is incorrect. | Off | Blink | Indicates that the lever of the toner cartridge is left unlocked. Error 544: Y Error 545: M Error 546: C Error 547: K | Error 544 545 546 547 |
| Re-set the drum. %ERRCODE% :%COLOR%. Drum error | Off | Blink | Indicates that the image drum is not installed normally. Error 340: Y Error 341: M Error 342: C Error 343: K | Error 340 341 342 343 |
| Re-set the fuser. %ERRCODE% : Fuser error | Off | Blink | Indicates that the fuser is not installed normally. (This error can occur when the printer temperature is below 0 degree C. Turn on the power again after the printer temperature has increased.) | Error 320 |
| Re-set the belt. %ERRCODE%: Belt error | Off | Blink | Indicates that the belt is not installed normally. | Error 330 |
| Turn off the power and wait for a while. %ERRCODE%: MOTOR. OVERHEAT | Off | Blink | Indicates the overheating of the ID motor. | Error 321 |
| Close the cover. %ERRCODE%: Cover is open. | Off | Blink | Indicates that the cover is open. Error 310: Top cover Error 311: Front cover | Error 310 311 |

| Display on operator panel | ON LINE lamp | Inspection lamp | Contents | Code nnn |
|--|--------------|-----------------|--|-----------|
| Close the cover. %ERRCODE%: Rear cover is open. | Off | Blink | Indicates that the cover is open. Error 316: Duplex unit cover. | Error 316 |
| Wait for a while. Data processing is in progress. | Off | Blink | Indicates that reception of the NIC program data for upgrading is in progress. | Error |
| Wait for a while. Data reception processing is in progress. | Off | Off | Indicates that reception of the NIC program data for upgrading is complete. | Error |
| Check the data. Received data error <%DLCODE%> | Off | On | Indicates that an error has occurred during reception of the NIC program data for upgrading. %DLCODE% 1: Size error 2: Checksum error 3: Printer model number error 4: Module I/F version error 5: FAT version error | Error |
| Wait for a while. Data write is in progress. | Off | Blink | Indicates that writing of the NIC program data for upgrading is in progress. | Error |
| Restart the printer. Data write is in progress. | Off | Off | Indicates that writing of the NIC program data for upgrading is in complete. | Error |
| Check the data. Data write error<%DLCODE%> | Off | On | Indicates that an error has occurred during writing of the NIC program data for upgrading. %DLCODE% 1: Memory allocation error 2: Download file error 3: Device free space acquisition error 4: Device insufficient free space error 5: File write error 6: CU-F/W mismatch error | Error |

| Display on operator panel | ON LINE lamp | Inspection lamp | Contents | Code nnn |
|--|--------------|-----------------|---|-------------|
| Printer restart is in progress %CODE%. | Off | On | Indicates the reboot of the controller unit is progress. %CODE% is a decimal value (single digit) indicating cause of the reboot. =0....Reboot that is resulted from a cause other than the below. =1....Reboot by the PjL command =2....Reboot caused by the menu change =4....Reboot caused by the network utilities (including web) | Error |
| Printer shut-down is in progress. | Off | Off | Indicates that a printer is shutting down. The shut-down process is started by pressing the BACK button for more than 4 seconds upon completion of printer initialization process. | Error |
| SHUTDOWN | Off | Off | Indicates that the shut-down process of a printer is complete. | Error |
| PLEASE POW OFF SHUTDOWN COMP | Off | Off | Indicates that the shut-down process of a printer is complete. (The LCD backlight turns off.) | Error |
| POWER OFF AND WAIT FOR A WHILE %ERRCODE%: CONDENSING ERROR | Off | Blink | Dew condensation error (This error is handled in the same way as the service call error though display only is different.) *The Fatal Errors are not supported by the various languages. | Fatal 126 |
| POWER OFF/ON %ERRCODE%:FATAL ERROR | Off | Blink | Indicates that a fatal error has occurred. For detailed contents, refer to "Service Calls List". *The Fatal Errors are not supported by the various languages. | Fatal <nnn> |
| SERVICE CALL %ERRCODE%:FATAL ERROR | Off | Blink | Indicates that a fatal error has occurred. For detailed contents, refer to "Service Calls List". *The Fatal Errors are not supported by the various languages. | Fatal <nnn> |

| Display on operator panel | ON LINE lamp | Inspection lamp | Contents | Code nnn |
|---|--------------|-----------------|---|--|
| SERVICE CALL %ERRCODE%:FATAL ERROR * | Off | Blink | Indicates that a fatal error has occurred. For detailed contents, refer to "Service Calls List". The asterisk mark "*" indicates the detailed information. *The Fatal Errors are not supported by the various languages. | Fatal 096 231 128 168 |
| POWER OFF/ON %ERRCODE%: FATAL_ERROR nnnnnnnn nnnnnnnn nnnnnnnn | Off | Blink | Indicates that a fatal error has occurred. For detailed contents, refer to "Service Calls List". "nnnnnnnn" indicates the detailed information. *The Fatal Errors are not supported by the various languages. | Fatal 002 011, F0C F0D FFE FFF |
| POWER OFF/ON %ERRCODE%: DOWNLOAD ERROR | Off | Blink | Indicates failure of the Media table downloading to PU. (Custom Media Type related) *The Fatal Errors are not supported by the various languages. | Fatal 209 |

Table 7-1-2 Service Call Error List

| Display | Cause | Error details | | Remedial measure |
|---|--|---|-------------------------------|--|
| Restart the printer. 002: Error~ 005: Error | CPU Exception | | Does the error display recur? | If the RAM DIMM is installed, remove it and turn off the power of the printer and back on. Replace the CU board. Re-install the RAM DIMM. Replace the RAM DIMM. |
| | | | Yes | |
| | | | No | |
| Service call 020: Error | CU ROM Hash Check Error | | Does the error display recur? | Turn off the power of the printer and back on. Replace the CU board. |
| | | | Yes | |
| Service call 030: Error | CU RAM Check Error | | Does the error display recur? | Turn off the power of the printer and back on. Replace the CU board. |
| | | | Yes | |
| Service call 031: Error | CU Optional RAM Check Error | Is installation of the RAM DIMM normal? Does the printer recover from the error when the RAM DIMM is replaced? | No Yes No | Re-install the RAM DIMM. Replace the RAM DIMM. Replace the CU board. |
| Service call 040: Error | CU EEPROM Error | | Does the error display recur? | Turn off the power of the printer and back on. Replace the CU board. |
| | | | Yes | |
| Service call 041: Error | CU Flash Error. Flash ROM Error on the CU board | | Does the error display recur? | Turn off the power of the printer and back on. Replace the CU board. |
| | | | Yes | |
| Service call 042: Error~ 043: Error 045: Error | Flash File System Error | Failed to access to the Flash ROM that is directly soldered to the CU board. | | Turn off the power of the printer and back on. Replace the CU board. |

| Display | Cause | Error details | | Remedial measure |
|--|--|--|-----|--|
| Restart the printer. 072: Error. Xx | Engine I/F Error. I/F error between PU and CU | Is the CU assembly installed normally? | No | Re-install the CU assembly normally. Replace the CU board. Replace the PU board. |
| | | Does the printer recover from the error when the CU board is replaced? | No | |
| Restart the printer. 073: Error xxxxxxxx | Video Error Error is detected when expanding the video data. (Illegal data is received.) | Is the CU assembly installed normally? | No | Re-install the CU assembly normally. Change the PC with another PC having high specifications, or alternately reduce resolution power and execute the print again. Replace the CU board. |
| | | Does this error recur? | Yes | |
| | | | | Replace the interface cable. Re-install the PC printer driver. |
| | | Is the CU assembly installed normally? | No | Re-install the CU assembly normally. Execute the print again. Print any other data. Replace the CU board. Send the data to design division and request analysis of the data. |
| | | Does this error recur? | Yes | |
| Does the error depend on print data? | No | | | |
| Restart the printer. 074: Error xxxxxxxx 075: Error xxxxxxxx | Video Error Error is detected when expanding the video data. | Is the CU assembly installed normally? | No | Re-install the CU assembly normally. Replace the CU board. |
| | | | Yes | |

| Display | Cause | Error details | | Remedial measure |
|----------------------------|--|---|------------------------|--|
| Service call 081: Error | Parameter integrity check | Either EEPROM or Flash ROM cannot read/write normally. | | Turn the printer power off and then back on. If the error symptom remains unchanged, replace the CU board. |
| Service call 104: Error | Read/write error of the engine EEPROM is detected. | Does this error recur? | Yes | Turn off the power of the printer and back on. Replace the PU board. |
| Service call 106: Error | Engine control logic has an error. | Does this error recur? | Yes | Turn off the power of the printer and back on. Replace the PU board. |
| Service call 111: Error | Duplex unit for other model is detected. | Is the duplex unit for that specific model installed? | No | Install the correct duplex unit. |
| Service call 112: Error | 2nd tray for other model is detected. | Is the 2nd tray for that specific model installed? | No | Install the correct 2nd tray. |
| Service call 121: Error | High voltage power supply interface error. | Is the cable connecting the PU board to the high voltage unit connected normally? Have you checked defective contact of contactor points? Note) | No Yes No | Re-connect them normally. Check for defective contact of the high voltage system. Replace the high voltage power supply. |
| Service call 122: Error | Low voltage power supply fan error | Is the fan (bottom right of the front) of the low voltage power supply block working? Is the fan connector connected normally? | No Yes No Yes | Check for sure connection of the fan connector. Replace the PU board. Replace the fan motor. Replace the PU board. |

| Display | Cause | Error details | | Remedial measure |
|---|--|--|-------------------------------|--|
| Service call 123: Error | Environment humidity is abnormal./ Humidity sensor is not connected. | Does this error recur? | Yes | Turn off the power of the printer and back on. Replace the control panel board. |
| Service call 124: Error | Environment temperature is abnormal. | Does this error recur? | Yes | Turn off the power of the printer and back on. Replace the control panel board. |
| Service call 126: Error | Dew condensation of the printer is detected. | This error can easily occur when a printer is brought in to indoor from outdoor. Leave the printer for 2 hours or half day under room temperature, and turn on the power again. Does this error recur? | Yes | After leaving a printer under room temperature, turn on the power again. Replace the control panel board. |
| Service call 127: Error | Fuser exhaust fan error | Is the fan connector connected normally? Does this error recur? | No Yes No | Re-connect it normally. Replace the fan motor. Replace the PU board. |
| Service call 128: Error | ID cooling fan error | Is the fan connector connected normally? Does this error recur? | No Yes No | Re-connect it normally. Replace the fan motor. Replace the PU board. |
| Service call 131: Error~ 134: Error | LED head detection error (131=Y, 132=M, 133=C, 134=K) | Is the LED head connected normally? Is the LED HEAD fuse brown? Does this error recur? | No Yes Yes No Yes | Install the LED head unit normally. Check the LED HEAD fuse. After checking fuse Turn on the power again. For the method of checking the LED head unit fuse, refer to section 7.6. |

| Display | Cause | Error details | | Remedial measure |
|---|--|--|------------------------|--|
| Service call 142: Error | ID Up/Down position detection error | Is the ID unit caught by anything when it is removed and re-installed? Does this error recur? | Yes No Yes | Re-install the ID unit. Turn on the power again. Replace the ID UP/DOWN sensor. |
| Service call 150: Error~ 153: Error | The ID unit fuse has blown out. (150=Y, 151=M, 152=C, 153=K) | Is the ID unit installed normally? Does this error recur? Does the printer recover from the error when the PU/PRZ board is replaced? | No Yes Yes No | Re-install the ID unit. Turn on the power again. After checking for the sure connection of the cable between PRZ board and PU board, replace the PRZ board. Replace the PU board. |
| Service call 154: Error | The belt unit fuse has blown out. | Is the belt unit connected normally? Does this error recur? | No Yes Yes | Re-install the belt unit. Turn on the power again. After checking for the sure cable connection, replace the PU board. |
| Service call 155: Error | The fuser unit fuse has blown out. | Is the fuser unit installed normally? Does this error recur? | No Yes Yes | After cleaning the connecting connector of the fuser unit, re-install the fuser unit. Turn on the power again. After checking for the sure cable connection, replace the PU board. |

| Display | Cause | Error details | | Remedial measure |
|---|---|--|-----|---|
| Service call 160: Error~ 163: Error | Toner sensor detection error. (160=Y, 161=M, 162=C, 163=K) This error does not occur with the default settings. | Is the toner cartridge installed? | No | Install the toner cartridge. Rotate the lock lever of toner to the lock position. Turn on the power again. Replace the toner sensor assembly. |
| | | Is the lock lever of the toner set? | No | |
| | | Does this error recur? | Yes | |
| Service call 167: Error | Thermistor Slope Error | Is the error message displayed? Does this error recur? | Yes | Turn on the power again. After leaving a printer for 30 minutes, turn on the power again. |
| Service call 168: Error Note) | Compensation Thermistor Error | Is the error message displayed? Does this error recur? | Yes | Turn on the power again. After leaving a printer for 30 minutes, turn on the power again. |
| Service call 170: Error 171: Error Note) | Short-circuit or open-circuit of fuser thermistor is detected. | Does this error recur? | Yes | Turn on the power again. Replace the fuser unit. |
| Service call 172: error 173: error | The fuser thermistor has detected an abnormal temperature (high temperature or low temperature.) | Does this error recur? | Yes | Turn on the power again. Replace the fuser unit. Replace the low voltage power supply unit. |
| | | Does this error recur? | Yes | |
| Service call 174: error | The backup roller thermistor is detected of its short-circuit. (At high temperature) | Does this error recur? | Yes | Turn on the power again. Replace the fuser unit. |

| Display | Cause | Error details | | Remedial measure |
|--|---|--|-----|---|
| Service call 175: error Note) | The backup roller thermistor is detected of its open- circuit. (At low temperature) | Does this error recur? | Yes | Turn on the power again. Replace the fuser unit. |
| Service call 176: error 177: error | The backup roller thermistor has detected an abnormal temperature (high temperature or low temperature.) | Does this error recur? | Yes | Turn on the power again. Replace the fuser unit. Replace the low voltage power supply unit. |
| | | Does this error recur? | Yes | |
| Service call 181: error 182: error | Option unit I/F error (181=Duplex Unit, 182=Option Tray) | Does this error recur? | Yes | Turn on the power again. Check for sure connection of the connectors. Replace the option unit. |
| | | Does this error recur? | Yes | |
| Re-start the printer. 190: error | System memory overflow | Does this error recur? | Yes | Turn on the power again. Increase the add- on RAM DIMM. |
| Service call 200: error~ 202: error | PU Firmware Download Error | Error has occurred during re- writing of the PU firmware. | | After turning on the power again, perform downloading again. (This error does not occur during the normal operation because this processing is not carried out.) |
| Re-start the printer. 209: Download error | Custom Media Type table downloading has failed. | Custom Media Type table downloading has failed. | | After turning on the power again, perform downloading again. (This error does not occur during the normal operation because this processing is not carried out.) |

| Display | Cause | Error details | | Remedial measure |
|---|--|--|---------------------|--|
| Re-start the printer. 203: error 204: error 207: error 208: error 214: error FOC: error FFF: error | CU program error (The error numbers 203 through 214 do not occur under the normal operation.) | Illegal processing is executed by the CU program. | | After turning off the power, check for the normal connection between the CU board and the PU board. Then, turn on the power again. |
| Service call 230: error | RFID Reader not Installed | RFID read device error Does this error recur? | Yes Yes | Check for normal connection of the RFID R/W board. Replace the RFID R/W. Replace the P6 X board. |
| Service call 231: error | RFID reader I/F error | Interface error with the RFID reader is detected. 01: Communication error between the RFID reader and the engine circuit boards. 02: Error in the wireless circuit of the RFID reader 03: Communication error between the RFID reader and the toner cartridge. 04: Error is detected in the RFID toner cartridge. (In more than 4) | | 01: Same as the error no. 230 02: Replace the RFID R/W board. 03: Check for normal connection of the antenna cable. 04: Check if quantity of the toner cartridge is correct or not. |
| Re-start the printer. 901: error~ 904: error (Note) | Abnormal temperature of belt 901: Short-circuit 902: Open circuit 903: High temperature 904: Low temperature | Is the cable from belt thermistor to the high voltage board connected normally? Does this error recur? | No Yes No | Re-connect the cables normally. Turn on the power again. Replace the belt thermistor. |

| Display | Cause | Error details | | Remedial measure |
|-------------------------------------|--|---|----------------|--|
| Re-start the printer. 918: error | Duplex FAN Alarm Caution | Fan error inside the duplex unit. Does the error recur when the power is turned off once and back on? Does the error recur when the power is turned off once and back on? | Yes Yes | Check if the Duplex unit is installed normally or not. Check if the fans are installed normally or not. Replace the fan. |
| Re-start the printer. 923: error | Black image drum lock error | The K ID does not rotate normally. Does the error display recur when the power is turned off once and back on? | Yes Yes | Check if the K ID is installed normally or not. Replace the K ID unit. Replace the K ID motor. |
| Service call 928: error | Fuser motor lock error | Fuser does not rotate normally. Does this error recur? | Yes Yes | Check if the fuser is installed normally or not. Replace the fuser. Replace the fuser motor. |
| Service call 980: error | Media wrapped around the fuser error | Media has wrapped around the fuser. | | Turn off the power. Replace the fuser. |
| Service call 982: error | 4th tray detection error | The 4th tray is installed. | | Remove the 4th tray. |
| Service call 983: error | Error due to detection of the toner cartridges of the same color | Two or more toner cartridges of the same color are detected. | | Install the cartridge of the specified in the specified position. |
| SDRAM ERROR | CU board (CU) DCON access error | Does this error recur? | Yes | Turn on the power again. Replace the CU board. |

| Display | Cause | Error details | | Remedial measure |
|--------------------------------------|---|---|-------------------------|--|
| xxxxxxxxxxxxxxxx CRC CHECK NG () | CRC check error of the PU downloaded data | The CRC check error is detected upon completion of the PU data downloading (PU firmware, Custom media data) | | After turning on the power again, perform downloading again. (This error does not occur during the normal operation because this processing is not carried out.) |
| LOADER VERSION xx xx | PU board Flash ROM hash check error | Does this error recur? | Yes | Turn on the power again. Replace the PU board. |
| WDT ERROR R14=xxxxxxxx | PU firmware runaway | Does this error recur? | Yes | Turn on the power again. Replace the PU board. |
| COMMUNICATION ERROR | I/F error between PU and CU | Is the CU assembly installed normally? Does this error recur? | No Yes No | Re-install the CU assembly normally. Replace the CU board. Replace the PU board. |
| ASIC ERROR | DCON access error | Does this error recur? | Yes | Replace the CU board. |

Note! Service calls 168 error, 171 error, 175 error, 903 error and 904 error; These errors can occur when the printer temperature is below 0 °C. Turn on the power again after the printer temperature has increased.

7.5.2 Preparation for troubleshooting

| | | | |
|--|-----|---|-----|
| (1) LCD display error | 149 | (8-4) Two-sided printing jam occurs during transporting paper inside the Duplex unit..... | 170 |
| (1-1) LCD does not display anything. | 149 | (8-5) Paper is not supplied from the Duplex unit to the regist roller..... | 170 |
| (1-2) PLEASE WAIT | 150 | (9) Paper size error (error code 400) | 170 |
| (1-3) Error messages related to Operator Panel are displayed. | 150 | (9-1) Jam occurs when paper end is located near the IN1 sensor. | 170 |
| (1-4) "RAM check in progress" or "Initializing" display is kept appearing. | 150 | (10) ID unit Up/Down error (Service call 140 to 143)..... | 171 |
| (2) Abnormal operations of printer after the power is turned on | 151 | (10-1) Error occurs during the Up movement of the ID unit | 171 |
| (2-1) Any operation does not start at all. | 151 | (10-2) Error occurs during the Down movement of the ID unit..... | 171 |
| (2-2) Abnormal sound is heard..... | 151 | (11) Fuser unit error (error 170 to 177)..... | 172 |
| (2-3) Bad odors are generated. | 152 | (11-1) Error occurs immediately after the power is turned on. | 172 |
| (2-4) Rise-up time is slow. | 152 | (11-2) Error occurs approx. 1 minute after the power is turned on. | 172 |
| (3) Paper feed jam (error code 391: 1st tray)..... | 159 | (12) Motor fan error (error code 122, 127, 128, 918, 051)..... | 173 |
| (3-1) Jam occurs immediately after the power is turned on. (1st tray)..... | 159 | (12-1) The low voltage power supply fan does not rotate immediately after the power is turned on. | 173 |
| (3-2) Jam occurs immediately after the paper feed is started. (1st tray) | 159 | (12-2) Duplex fan does not rotate during the Duplex printing..... | 173 |
| (4) Feed jam (error code 380) | 161 | (12-3) All fans of the printer do not rotate..... | 173 |
| (4-1) Jam occurs immediately after the power is turned on..... | 161 | (13) Print speed is slow. (Performance is low.) | 174 |
| (4-2) Jam occurs immediately after the paper feed is started. | 161 | (13-1) Print speed decreases. | 174 |
| (5) Paper feed jam (error code 390: Multipurpose tray)..... | 162 | (14) Option unit cannot be recognized..... | 174 |
| (5-1) Jam occurs immediately after the power is turned on. (Multipurpose tray)..... | 162 | (14-1) Duplex unit cannot be recognized..... | 174 |
| (5-2) Jam occurs immediately after paper feed is started. (Multipurpose tray)..... | 163 | (14-2) Option try unit cannot be recognized. | 174 |
| (6) Paper running jam (error code 381:) | 164 | (15) LED head cannot be recognized. (error code 131, 132, 133, 134) | 175 |
| (6-1) Jam occurs immediately after the power is turned on..... | 164 | (15-1) Service call 131 to 134 (LED HEAD Missing)..... | 175 |
| (6-2) Jam occurs immediately after a paper is taken into printer..... | 164 | (16) Toner cartridge cannot be recognized. (error code 540, 541, 542, 543) | 176 |
| (6-3) Jam occurs in the middle of paper running path..... | 165 | (16-1) Error caused by the consumable items..... | 176 |
| (6-4) Jam occurs immediately after paper has reached the fuser. | 166 | (16-2) Error caused by the toner sensor | 176 |
| (7) Paper unloading jam (error code 382)..... | 166 | (16-3) Error caused by the defective mechanism..... | 177 |
| (7-1) Paper unloading jam occurs immediately after the power is turned on. ... | 166 | (17) Fuse cut error (error codes 150 to 155) | 177 |
| (7-2) Paper unloading jam occurs after a paper is taken into printer..... | 167 | (17-1) Fuse cut error | 177 |
| (7-3) Paper unloading jam occurs in the middle of paper running path. | 168 | (18) Humidity sensor error (error code 123) | 178 |
| (8) Two-sided printing jam (error code: 370, 371, 372, 373, 383)..... | 168 | (18-1) Humidity sensor error | 178 |
| (8-1) Two-sided printing jam occurs immediately after the power is turned on.. | 168 | (19) Wiring diagram..... | 179 |
| (8-2) Two-sided printing jam occurs during taking in the paper into Duplex unit. | 169 | | |
| (8-3) Two-sided printing jam occurs in the process of reversing paper..... | 169 | | |

Note! When replacing the PU board, read the EEPROM chip contents of the old board first, and copy them to the new board upon completion of the replacement. (Refer to section 5.4.1 Precautions when replacing the engine control board.)

7.5.2. (1) LCD display error


Memo For the numbers from 1 through 26 after name of the respective connectors, refer to section 7.5.2 (19) "Wiring diagram".

(1-1) LCD does not display anything.

| Check item | Check work | Action to be taken at NG |
|---|--|--|
| (1-1-1) Check the fuse. | | |
| F2 (fuse) of the PU board | Check if F2 has blown out or not. | Replace F2 or the PU board. |
| (1-1-2) Check the system connection | | |
| Connection between the low voltage power supply unit and the PU or CU board. | Check if the cable from the low voltage power supply to the POWER connector ⑩ of the PU board is normally connected or not. Check if the connector is connected only in the half-way or not, and check if the connector is inserted in slanted angle or not. | Re-connect the cable normally. |
| Cable assembly connecting the low voltage power supply unit and the PU board. | Check if the cable is half-open circuit. Check if sheath of the cable has not peeled off or not. Check if the cable assembly is defective such as internal wires are disconnected or not. | Replace the cable with the normal cable. Note! |
| Connection between the PU board and Operator Panel | Check if the 10-conductor FFC is connected to the OPE connector ⑰ of the PU board normally or not. Check if the 10-conductor FFC is connected to the OPE connector ⑱ of the PU board normally or not. Check if the connector is connected in the half-way only or not, and check if the connector is inserted in a slanted angle or not. | Re-connect the cable normally. |
| FFC connecting the PU board and the Operator Panel board | Check if the cable has open circuit or not with VOM. Check if sheath of the cable has not peeled off or not by visual inspection. | Replace the FFC with the normal FFC. |
| FFC connecting the PU board and the CU board | Check if the 16-conductor FFC is connected to the CU IF connector ⑨ of the PU board normally or not. Check the CU board side in the same way. | Replace the low voltage power supply. Note! |

| Check item | Check work | Action to be taken at NG |
|--|---|---|
| (1-1-3) Check the peripherals of the power supplies | | |
| Primary AC power source that is connected to the printer. | Check the supplied voltage of the AC power source. | Supply the AC power. |
| Voltage setting of the lower voltage power supply unit (100V system/230V system) | Measure the AC voltage supplied. Check the power voltage setting of the equipment in use. (Check the shorting plug that is used for selection of the voltage power supplies.) Shorting plug is Used/Not used = 100V system/230V system. | Set the low voltage power supply setting. |
| 5V power that is supplied to the PU board. | Check for the 5V power supply at pin-7 of the POWER connector ⑩ of the PU board. | Replace the low voltage power supply. |
| 3.3V power that is supplied to the Operator Panel. | Check for the 3.3V power supply at pin-10 of the CN connector ⑲ of the Operator Panel board. | Replace F2 or the PU board. |
| (1-1-4) Check that power supply circuit has no short-circuit. | | |
| 5V power and 24V power that are supplied to the PU board. | Check that power supply circuit has no short-circuit at the POWER connector no. 10 of the PU board. The follow voltage must appear respectively. pins-4, 5 and 6: 24V pin-7: 5V pin-8: 0VL pins-1, 2 and 3: 0VP If any voltage does not appear and short-circuit is detected, locate the source of the short-circuit as follows: Disconnect the cables that are connected to the PU board one cable after another until location of the short-circuit is found out. | Replace the part causing short-circuit. |

Note! If the PU board, the CU board and the low voltage power unit are connected one another differently from the picture given below, it is regarded as an abnormal, and the output from the low voltage power unit stops.
When the output from the low voltage power unit stops, turn off the power switch, wait about one minute, and then turn on the power switch, otherwise, the alarm condition of the stoppage of the power output is not cleared.



| Check item | Check work | Action to be taken at NG |
|--|--|-----------------------------------|
| (1-1-5) LSI operation check | | |
| I/F signal supplied from the PU board to the Operator Panel board. | Check if the signal is output to the OPE connector ⑰ of the PU board or not. Pin-7: Send data (Sending data from the PU board) Pin-9: CLR If it is normal, the signal is output always. | Replace the PU board. |
| I/F signal supplied from the PU board to the Operator Panel board. | Check if the signal is output to the OPE connector ⑰ of the PU board or not. Pin-6: Send data (Sending data from the PU board) If it is normal, the signal is output always. | Replace the Operator Panel board. |

Note! However, for the Data Protection Kit –A1, refer to section 7.8.

(1-2) PLEASE WAIT

(If the message is left attended, the error number changes to "COMMUNICATION ERROR".)

| Check item | Check work | Action to be taken at NG |
|---|--|---|
| (1-2-1) Check installation condition of printed circuit board | | |
| Connection condition of the PU board and CU board | Check the connection condition of the CU IF connector ⑨ of the PU board, and check that of the FFC connector of the CU board. | Connect the FFC normally. |
| (1-2-3) Implement version upgrade of the PU firmware | | |
| Version upgrade of the PU firmware | When the PU firmware version upgrade is completed, this display appears. Check the PU firmware version number by using the menu print or the maintenance function. | If the message reappears after the power is restarted again, implement the confirmations of sections (1-3-1) and (1-3-2). |

(1-3) Error messages related to Operator Panel are displayed.

| Check item | Check work | Action to be taken at NG |
|-----------------------|--|--------------------------|
| (1-3-1) Error message | | |
| Error message | Check the error contents by referring to the Error Message List. | Follow the instruction. |

(1-4) "RAM check in progress" or "Initializing" display is kept appearing.

| Check item | Check work | Action to be taken at NG |
|---|--|---|
| (1-4-1) Operator Panel display freezes. | | |
| Operator Panel display | "RAM check in progress" or "Initializing" display is kept appearing. | Replace the ROM DIMM of CU, or replace the CU board. Remove the optional RAM and HDD. Then perform the check. If the check result shows NG, replace the CU board. Note! |

7.5.2. (2) Abnormal operations of printer after the power is turned on

(2-1) Any operation does not start at all.

| Check item | Check work | Action to be taken at NG |
|--|---|---|
| (2-1-1) Check the peripherals of the power supplies | | |
| Primary AC power source that is connected to the printer. | Check the supplied voltage of the AC power source. | Supply the AC power. |
| Voltage setting of the lower voltage power supply unit (100V system/230V system) | Measure the AC voltage supplied. Check the power voltage setting of the equipment in use. (Check the shorting plug that is used for selection of the voltage power supplies. [CN6]) Shorting plug is Used/Not used = 100V system/230V system. | Set the low voltage power supply setting. |
| 5V power and 24V power that are supplied to the PU board. | Check the power supply voltages at the POWER connector no. 10 of the PU board. The follow voltage must appear respectively. Pins-4, 5 and 6: 24V Pin-7: 5V Pin-8: 0VL Pins-1, 2 and 3: 0VP | Replace the low voltage power supply. |
| (2-1-2) Check the system connection | | |
| Connection condition of Operator Panel | Check contents of (1-1). Any operation of a printer will not start until the Operator Panel is detected and is started of its operation. | Follow the contents of (1-1). |

(2-2) Abnormal sound is heard.

| Check item | Check work | Action to be taken at NG |
|--|---|--|
| (2-2-1) Check loss of synchronization of motor (Driver error) | | |
| Operating conditions of the respective motors | Check if operations of the respective motors are normal or not by using the self-diagnostic mode. Check if any load exists or not. "Buzzer" sound when an error occurs. | Replace the PU board. |
| Condition of the motor cable | Check for normal wiring conditions of the respective motors. Perform the visual check and measure resistance at open circuit with VOM as follows. Remove the motor cable at the board end. Measure resistance between the respective pins of the removed cable and FG with VOM. | Replace the motor cable. Re-connect the cable for normal conditions. |
| (2-2-2) Check loss of synchronization of motor (Abnormal load of the consumable item) | | |
| Operating conditions of the respective motors | Check if operations of the respective motors are normal or not by using the self-diagnostic mode. Check if any load exists or not. "Buzzer" sound when an error occurs. | Replace the corresponding consumable item. If any attempt of using new part as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |

| Check item | Check work | Action to be taken at NG |
|---|---|--|
| (2-2-3) Check the jumping phenomena of gear tooth. (Abnormal load of the consumable item) | | |
| Operating conditions of the respective motors | Check if operations of the respective motors are normal or not by using the self-diagnostic mode. Check if any load exists or not. "Buzz buzz" sound is generated when an error occurs. | Replace the corresponding consumable item. If any attempt of using new part as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |
| Installation condition of each consumable item | Check by visual inspection if the respective consumable items are installed in their normal positions in which gears of the consumable items engage accurately or not. | Replace an appropriate mechanical part as required, or adjust or repair |
| (2-2-4) Check the wiring conditions of cables | | |
| Wiring conditions of the cables in the vicinity of the respective cooling fans | Check if the cable contacts with the fan blade because wiring conditions of the cables near fan is poor or not. "Clap, clap" sound is generated when an error occurs. | Correct the wiring conditions of the cable. |
| (2-2-5) Check installation condition of mechanical parts | | |
| Check the installation conditions of the partition plate under the CU and PU boards. | Remove the CU and PU board, and inspect the installation conditions of the partition plate by visual inspection. | If they are not hooked on the normal specified positions, correct them. |

(2-3) Bad odors are generated.

| Check item | Check work | Action to be taken at NG |
|--|---|--|
| (2-3-1) Locating the exact position of generating bad odor | | |
| Fuser unit | Remove the fuser unit and check the odor. | Implement section (2-3-2). |
| Low voltage power supply unit | Remove the low voltage power supply unit and check the odor. | Replace the low voltage power supply unit |
| (2-3-2) Check conditions of the fuser unit | | |
| Life count of fuser unit | Check the life count of the fuser unit by using the self-diagnostic mode. | The fuser close to the new fuser unit smells some odors. |
| Check that no foreign material exists in fuser unit. | Check that no foreign materials such as paper are stuck inside of the fuser unit. | Remove the foreign material. |

(2-4) Rise-up time is slow.

| Check item | Check work | Action to be taken at NG |
|--|---|----------------------------|
| (2-4-1) Check the fuser unit | | |
| Halogen lamp | Check that 100V is shown on the label on the rear of the fuser unit. | Replace the fuser unit. |
| (2-4-2) Check the optional parts Note: | | |
| Add-on memory | Install the optional parts (add-on memory) again and re-check the operations. | Replace the optional part. |
| HDD | Install the optional part (HDD) again and re-check the operations. | Replace the optional part. |
| Data Protection Kit -A1 | Refer to section 7.8. | |


Note! If any troubles such as printer does not start up normally occurs, remove the CU options (RAM, HDD) and check if the trouble symptom changes or not.

(3) Paper Jams

When paper jams occur or paper remains in the printer, "Paper Jam", or "Paper Remain" is displayed on the operation panel.

By pressing the Help button, a method to remove the paper is displayed, remove the paper in the printer according to [Handling].


In addition, A method to remove paper is also described in the reference page at the right table.



By pressing this button, a method to remove paper is displayed.

| Message to be displayed | Reference page |
|--|----------------|
| Pull the tray. Paper Jam [Tray Name] | Page 181 |
| Pull the tray. Paper Remains. [Tray Name] | |
| Open the Cover. Paper Jam Front Cover | Page 182 |
| Open the Cover. Paper Remains. Front Cover | |
| Open the Cover. Paper Jam Top Cover | Page 183 |
| Open the Cover. Paper Remains. Top Cover | |
| Check the duplex print unit. Paper Jam | Page 185 |
| Check the duplex print unit. Paper Remains. | |

JAM location of occurrence outline chart




Pull the tray.
Paper Jam
[Tray Name]


Pull the tray.
Paper Remains.
[Tray Name]

When the above messages are displayed.
Tray1 is applied here as an example.


(1) Pull the displayed tray.




(2) Remove paper.



(3) Return the tray to the printer.



(4) Open and close the top cover.




Open the Cover.
Paper Jam
Front Cover


Open the Cover.
Paper Remains.
Front Cover

When the above messages are displayed.

- (1) Open the multipurpose tray.





- (2) Push up the center handle (blue), to open the front cover.




- (3) Slowly pull out the jammed paper.


- ① If you see the top edge of paper
- ② If you do not see the top edge of paper



- (4) Close the front cover.



- (5) Close the multipurpose tray.




Open the Cover.
Paper Jam
Top Cover


Open the Cover.
Paper Remains.
Top Cover

When the above messages are displayed.


- (1) Open the top cover.




- (2) Touch the screw with a hand to discharge static.




- (3) 2Uninstall the four image drum cartridges and put them on a flat table.



- (4) Cover the uninstalled image drum cartridges with black paper.




- (5) (a) If you see the top edge of paper
Pull up the jammed paper slowly.




(b) If you do not see the top edge of paper

Pull up the jammed paper slowly while pushing the jam release lever of the fuser unit.




(c) If paper is jammed in the fuser unit

Pull the lock levers (2 levers) of the fuser unit to remove the fuser unit.




Pull the jammed paper to the front side while pressing the jam release lever.




Set the fuser unit in the printer body and fold backward the lock lever (2 levers).


Lock lever of the fuser unit (Blue)



(6) Set four image drums in the printer.



(7) Close the top cover.




Check the duplex unit.
Paper Jam

Check the duplex unit.
Paper Remains.


When the above messages are displayed.

- (1) Hold and press down the jam release lever of the duplex print unit to open the duplex print unit cover.




- (2) Release jammed paper.

If you do not see the paper, by closing the duplex print unit cover, the paper is automatically outputted.



- (3) Close the duplex print unit cover.



7.5.2. (3) Paper feed jam (error code 391: 1st tray)

(3-1) Jam occurs immediately after the power is turned on. (1st tray)

| Check item | Check work | Action to be taken at NG |
|---|--|--|
| (3-1-1) Check condition of the paper running path | | |
| Paper running path of the front unit | Open the front cover check if paper is not jammed in the paper running path. | Remove the jammed paper. |
| (3-1-2) Check condition of the mechanical parts | | |
| Check the sensor levers of the paper entrance sensor 1 and the paper entrance sensor 2. | Check if shape and movement of the sensor levers have any abnormality or not. | Replace the sensor lever with the good sensor lever. |
| (3-1-3) Check condition of electrical parts | | |
| Check the detection condition of the sensor signal. | Confirm that the sensor signals are normally detected by using the Maintenance Menu SWITCH SCAN function. | Replace either the PU board or the front sensor board (RSF PCB) or connection cable. |
| Check output signal level of the paper entrance sensor 1 and that of the paper entrance sensor 2. | Check for the following signals at the FSNS connector ⑩ of the PU board. Pin-4: Paper entrance sensor 1 Pin-3: Paper entrance sensor 2 Confirm that the above signal levels change when the sensor lever is operated. | Replace the front sensor board (RSF PCB) |
| Check the power voltages supplied to the front sensor board (RSF PCB) | Check the 5V power at the FSNS connector ⑩ of the front sensor board (RSF PCB). Pin-1: 5V power supply Pin-5: 0VL | Replace the connection cable. |

(3-2) Jam occurs immediately after the paper feed is started. (1st tray)

| Check item | Check work | Action to be taken at NG |
|---|--|--|
| (3-2-1) Check condition of the paper running path | | |
| Paper running path of the front unit | Check if paper is jammed or not in the paper running path. | Remove the jammed paper. |
| (3-2-2) Check condition of the mechanical parts | | |
| Check the sensor levers of the paper entrance sensor 1 and the paper entrance sensor 2. | Check if shape and movement of the sensor levers have any abnormality or not. | Replace the sensor with the good sensor lever. |
| Check the separator assemblies of the feed roller, the pickup roller and the tray. | Check if any foreign materials such as paper dust on the surface of the feed roller or of the pickup roller or not. | Remove the foreign material. |
| | Check if the feed roller or the pickup roller has worn out or not. | Replace the separator assemblies of the feed roller, pickup roller and tray. |
| (3-2-3) Motor operation check | | |
| Paper feed motor | Confirm that the paper feed motor works normally by using the Motor & Clutch Test of the self-diagnostic mode. | Replace the PU board or the paper feed motor. |
| Paper feed motor driver | Remove the HOPSIZE connector ① of the PU board and check the followings at the connector side. Several MΩ between pin-1 – FG. Several MΩ between pin-2 – FG. Several MΩ between pin-3 – FG. Several MΩ between pin-4 – FG. | Replace the PU board. |

| Check item | Check work | Action to be taken at NG |
|--|---|---|
| (3-2-4) Check the system connection | | |
| Paper feed motor drive cable | Check the connection condition of the cable. Check if the connector is connected in the half-way only or not, and check if the connector is inserted in a slanted angle or not. Check also that cables are assembled without any abnormality. | Replace the cable with the good cable that normalizes the connection condition. |
| Paper feed motor drive cable | Check that any cable is not pinched during assembling of the printer. Remove the HOPSIZE connector ① of the PU board and check the followings at the cable side. Short circuit between pin-1 – FG Short circuit between pin-2 – FG Short circuit between pin-3 – FG Short circuit between pin-4 – FG | Replace the cable with the good cable that normalizes the connection condition. |
| Paper feed motor | Remove the HOPSIZE connector ① of the PU board and check that approx. 3.4Ω can be measured between pin-1 -pin-2 at the cable end, and that approx. 5Ω can be measured between pin-3 -pin-4 respectively. | Replace the paper feed motor. |
| (3-2-5) Solenoid operation check | | |
| Paper feed solenoid | Confirm that the paper feed solenoid works normally by using the Motor & Clutch Test of the self-diagnostic mode. Remove the metal plate from the right side of a printer so that the solenoid becomes visible. Then, check operation of the solenoid. | Replace the PU board, or replace the paper feed solenoid. |
| Paper feed solenoid | Check that any obstacle does not exist that hampers smooth operation of the movable portion of the solenoid. (Obstacles such as cable and others) | Normalize the assembled condition of a printer. |

| Check item | Check work | Action to be taken at NG |
|--|---|---|
| (3-2-6) Check the system connection | | |
| Paper feed solenoid cable | Check the connection condition of the cable. Check if the connector is connected in the half-way only or not, and check if the connector is inserted in a slanted angle or not. Check also that cables are assembled without any abnormality. | Replace the cable with the good cable that normalizes the connection condition. |
| Paper feed solenoid cable | Check that any cable is not pinched during assembling of the printer. Remove the HSOL connector ⑭ of the PU board and check the followings at the cable side. Short circuit between pin-1 – FG Remove the HSOL connector ⑭ of the PU board and check that approx. 89Ω can be measured between pin-1 and pin-2. | Replace the solenoid assembly and re-assemble the printer correctly. |

7.5.2. (4) Feed jam (error code 380)

(4-1) Jam occurs immediately after the power is turned on.

| Check item | Check work | Action to be taken at NG |
|---|--|--|
| (4-1-1) Check condition of the paper running path | | |
| Paper running path of the front unit | Open the front cover check if paper is not jammed in the paper running path. | Remove the jammed paper. |
| (4-1-2) Check condition of the mechanical parts | | |
| Check the sensor levers of the paper entrance sensor 1, that of the paper entrance sensor 2 and that of the WR sensor. | Check if shape and movement of the sensor levers have any abnormality or not. | Replace the sensor with the good sensor lever. |
| (4-1-3) Check condition of electrical parts | | |
| Check the detection condition of the sensor signal. | Confirm that the sensor signals are normally detected by using the Maintenance Menu SWITCH SCAN function. | Replace either the PU board or the front sensor board (RSF PCB) or connection cable. |
| Check the output signal levels of the paper entrance sensor 1, that of the paper entrance sensor 2 and that of the WR sensor. | Check for the following signals at the FSNS connector ⑩ of the PU board. Pin-4: Paper entrance sensor 1 Pin-3: Paper entrance sensor 2 Pin-2: WR sensor Confirm that the above signal levels change when the sensor lever is operated. | Replace the front sensor board (RSF PCB) |
| Check the power voltages supplied to the front sensor board (RSF PCB) | Check the 5V power at the FSNS connector ⑩ of the front sensor board (RSF PCB). Pin-1: 5V power supply Pin-5: 0VL | Replace the connection cable. |

(4-2) Jam occurs immediately after the paper feed is started.

| Check item | Check work | Action to be taken at NG |
|--|--|--|
| (4-2-1) Check condition of the paper running path | | |
| Paper running path of the front unit | Check if paper is jammed or not in the paper running path. | Remove the jammed paper. |
| (4-2-2) Check condition of the mechanical parts | | |
| Check the sensor levers of the paper entrance sensor 1, that of the paper entrance sensor 2 and that of the WR sensor. | Check if shape and movement of the sensor levers have any abnormality or not. | Replace the sensor with the good sensor lever. |
| (4-2-3) Motor operation check | | |
| Paper feed motor | Confirm that the paper feed motor works normally by using the Motor & Clutch Test of the self-diagnostic mode. | Replace the PU board, or replace the paper feed motor. |
| Paper feed motor driver | Remove the HOPSIZE connector ① of the PU board and check the followings at the connector side. Several MΩ between pin-1 – FG Several MΩ between pin-2 – FG Several MΩ between pin-3 – FG Several MΩ between pin-4 – FG | Replace the PU board. |

| Check item | Check work | Action to be taken at NG |
|-------------------------------------|--|---|
| (4-2-4) Check the system connection | | |
| Paper feed motor drive cable | Check the connection condition of the cable. Check if the connector is connected in the half-way only or not, and check if the connector is inserted in a slanted angle or not. Check also that cables are assembled without any abnormality. | Replace the cable with the good cable that normalizes the connection condition. |
| Paper feed motor drive cable | Check that any cable is not pinched during assembling of the printer. Remove the HOPSIZE connector no. 1 of the PU board and check the followings at the cable side. Short circuit between pin-1 – FG Short circuit between pin-2 – FG Short circuit between pin-3 – FG Short circuit between pin-4 – FG | Replace the cable with the good cable that normalizes the connection condition. |
| Paper feed motor | Remove the HOPSIZE connector ① of the PU board and check that approx. 3.4Ω can be measured between pin-1 -pin-2 at the cable end, and that approx. 5Ω can be measured between pin-3 -pin-4 respectively. | Replace the paper feed motor. |

7.5.2. (5) Paper feed jam (error code 390: Multipurpose tray)

(5-1) Jam occurs immediately after the power is turned on. (Multipurpose tray)

| Check item | Check work | Action to be taken at NG |
|--|--|--|
| (5-1-1) Check condition of the paper running path | | |
| Paper running path of the multipurpose tray | Check if paper is jammed or not in the paper running path. | Remove the jammed paper. |
| (5-1-2) Check condition of the mechanical parts | | |
| Check the sensor levers of the paper entrance sensor 2 and the WR sensor. | Check if shape and movement of the sensor levers have any abnormality or not. | Replace the sensor with the good sensor lever. |
| (5-1-3) Check condition of electrical parts | | |
| Check the detection condition of the sensor signal. | Confirm that the sensor signals are normally detected by using the SWITCH SCAN function of the self-diagnostic mode. | Replace either the PU board or the front sensor board (RSF PCB) or connection cable. |
| Check the sensor output signal level of the paper entrance sensor 2 and the WR sensor. | Check for the following signals at the FSNS connector ⑩ of the PU board. Pin-2: WR sensor Pin-3: Paper entrance sensor 2 Confirm that the above signal levels change when the sensor lever is operated. | Replace the front sensor board (RSF PCB) |
| Check the power voltages supplied to the front sensor board (RSF PCB) | Check the 5V power at the CN connector ㉕ of the front sensor board (RSF PCB). Pin-1: 5V power supply Pin-5: 0V | Replace the connection cable. |

(5-2) Jam occurs immediately after paper feed is started. (Multipurpose tray)

| Check item | Check work | Action to be taken at NG |
|---|---|--|
| (5-2-1) Check condition of the paper running path | | |
| Paper running path of the multipurpose tray | Check if paper is jammed or not in the paper running path. | Remove the jammed paper. |
| Sheet Receive of the multipurpose tray | Confirm that the Sheet Receive has moved up normally. Confirm that the support spindle and spring of the Sheet Receive have been installed in the specified positions normally. | Correct installation of the above parts so that the Sheet Receive moves up to the specified position normally. |
| (5-2-2) Check condition of the mechanical parts | | |
| Check the sensor levers of the paper entrance sensor 2 and the WR sensor. | Check if shape and movement of the sensor levers have any abnormality or not. | Replace the sensor with the good sensor lever. |
| Planetary gear for paper feed control | Rotate the paper feed motor (FRONT MOTOR) using the Motor & Clutch Test of the self-diagnostic mode, and confirm that both of the two planetary gears rotate at the bottom position. (The planetary gear box can be located because it is the white molded block that is located on the right side when the front cover is opened.) | Replace the planetary gear box |
| Front cover | Confirm that the locks in the right and left of the front cover are locked normally. | Replace the front cover assembly |
| Check the feed roller and the pickup roller. | Check if any foreign materials such as paper dust on the surface of the feed roller or of the pickup roller or not. | Remove the foreign material. |
| | Check if the feed roller has worn out or not. | Replace the feed roller. |

| Check item | Check work | Action to be taken at NG |
|--|--|---|
| (5-2-3) Motor operation check | | |
| Paper feed motor | Confirm that the paper feed motor works normally by using the Motor & Clutch Test of the self-diagnostic mode. | Replace the PU board, or replace the paper feed motor. |
| Paper feed motor driver | Remove the HOPSIZE connector ① of the PU board and check the followings at the connector side. Several MΩ between pin-1 – FG Several MΩ between pin-2 – FG Several MΩ between pin-3 – FG Several MΩ between pin-4 – FG | Replace the PU board. |
| (5-2-4) Check the system connection | | |
| Paper feed motor drive cable | Check the connection condition of the cable. Check if the connector is connected in the half-way only or not, and check if the connector is inserted in a slanted angle or not. Check also that cables are assembled without any abnormality. | Replace the cable with the good cable that normalizes the connection condition. |
| Paper feed motor drive cable | Check that any cable is not pinched during assembling of the printer. Remove the HOPSIZE connector no. 1 of the PU board and check the followings at the cable side. Short circuit between pin-1 – FG Short circuit between pin-2 – FG Short circuit between pin-3 – FG Short circuit between pin-4 – FG | Replace the cable with the good cable that normalizes the connection condition. |
| Paper feed motor | Remove the HOPSIZE connector ① of the PU board and check that approx. 3.4Ω can be measured between pin-1 -pin-2, and that approx. 5Ω can be measured between pin-3 -pin-4 respectively. | Replace the paper feed motor. |

7.5.2. (6) Paper running jam (error code 381:)

(6-1) Jam occurs immediately after the power is turned on.

| Check item | Check work | Action to be taken at NG |
|---|---|--|
| (6-1-1) Check condition of the running path. | | |
| Paper running path of the front unit | Check if paper is jammed or not in the paper running path. | Remove the jammed paper. |
| (6-1-2) Check condition of the mechanical parts | | |
| Check the sensor lever of the WR sensor. | Check if shape and movement of the sensor levers have any abnormality or not. | Replace the sensor lever with the good sensor lever. |
| (6-1-3) Check condition of electrical parts | | |
| Check the detection condition of the sensor signal. | Confirm that the sensor signals are normally detected by using the SWITCH SCAN function of the self-diagnostic mode. | Replace either the PU board or the front sensor board (RSF PCB) or connection cable. |
| Check the sensor lever of the WR sensor. | Check for the following signals at the FSNS connector no. 16 of the PU board. Pin-2: WR sensor Confirm that the above signal levels change when the sensor lever is operated. | Replace the front sensor board (RSF PCB) |
| Check the power voltages supplied to the front sensor board (RSF PCB) | Check the 5V power at the CN connector no. 25 of the front sensor board (RSF PCB). Pin-1: 5V power supply Pin-5: 0VL | Replace the connection cable. |

(6-2) Jam occurs immediately after a paper is taken into printer.

| Check item | Check work | Action to be taken at NG |
|---|---|--|
| (6-2-1) Check condition of the paper running path | | |
| Paper running path on the belt. | Remove the ID unit and check if paper is jammed or not in the paper running path. | Remove the jammed paper. |
| (6-2-2) Check condition of the mechanical parts | | |
| Check the sensor lever of the WR sensor. | Check if shape and movement of the sensor levers have any abnormality or not. | Replace the sensor lever with the good sensor lever. |
| (6-2-3) Motor operation check | | |
| Paper feed motor driver, belt motor driver and ID motor | Confirm that the paper feed motor, belt motor and ID motor work normally by using the Motor & Clutch Test of the self-diagnostic mode. Check if any load exists or not. | Replace the PU board, or replace the defective motor among paper feed motor, belt motor and ID motor, or replace the ID unit or belt unit. If any attempt of using new ID unit or new belt unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |
| Paper feed motor, belt motor | Remove the BELT ID UP connector ① of the PU board and check the followings at the connector side. Several MΩ between pin-5 – FG Several MΩ between pin-6 – FG Several MΩ between pin-7 – FG Several MΩ between pin-8 – FG Remove the HOPSIZE connector ③ of the PU board and check the followings at the connector side. Several MΩ between pin-1 – FG Several MΩ between pin-2 – FG Several MΩ between pin-3 – FG Several MΩ between pin-4 – FG | Replace either paper feed motor, belt motor or PU board. |

| Check item | Check work | Action to be taken at NG |
|--|---|---|
| (6-2-4) Check the system connection | | |
| Paper feed motor drive cable, ID motor drive cable, belt motor drive cable, ID Up motor drive cable, fuser motor drive cable | Check the connection condition of the cables. PU board HOPSIZE connector ⑫, DC ID connector ②, DCHEAT connector ④, BELT ID UP connector ③, RELAY connector ⑧. Check if the connector is connected in the half-way only or not, and check if the connector is inserted in a slanted angle or not. Check also that cables are assembled without any abnormality. | Normalize the connection condition. Replace the cable with the normal cable. |
| Paper feed motor drive cable, ID motor drive cable, belt motor drive cable, ID Up motor drive cable | Check that any cable is not pinched during assembling of the printer. Remove the BELT ID UP connector ③ of the PU board and check the followings at the connector side. Short circuit between pin-1 – FG Short circuit between pin-2 – FG Short circuit between pin-3 – FG Short circuit between pin-4 – FG Short circuit between pin-5 – FG Short circuit between pin-6 – FG Short circuit between pin-7 – FG Short circuit between pin-8 – FG Remove the HOPSIZE connector ⑫ of the PU board and check the followings at the cable side. Short circuit between pin-1 – FG Short circuit between pin-2 – FG Short circuit between pin-3 – FG Short circuit between pin-4 – FG | Replace the cable with the good cable that normalizes the connection condition. |
| Paper feed motor, belt motor, ID Up motor | Remove the respective connectors from the board, and confirm that the following resistance exists between the corresponding pins, at the cable side. PU board HOPSIZE connector 1 Between pin-1 - pin-2 Approx. 3.4Ω or approx. 5Ω. Between pin-3 - pin-4 Approx. 3.4Ω or approx. 5Ω. PU board BELT ID UP connector 3 Between pin-1 - pin-2 Approx. 6.1Ω or approx. 3.5Ω. Between pin-3 - pin-4 Approx. 6.1Ω or approx. 3.5Ω. Between pin-5 - pin-6 Approx. 3.4Ω or approx. 5Ω. Between pin-7 - pin-8 Approx. 3.4Ω or approx. 5Ω. | Replace paper feed motor, belt motor, ID Up motor. |

(6-3) Jam occurs in the middle of paper running path.

| Check item | Check work | Action to be taken at NG |
|---|---|--|
| (6-3-1) Motor operation check | | |
| Paper feed motor driver, belt motor driver and ID motor | Confirm that the paper feed motor, belt motor and ID motor work normally by using the Motor & Clutch Test of the self-diagnostic mode. Check if any load exists or not. | Replace the PU board, or replace the defective motor among paper feed motor, belt motor and ID motor, or replace the ID unit or belt unit. If any attempt of using new ID unit or new belt unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |
| Paper feed motor, belt motor | Remove the BELT ID UP connector ① of the PU board and check the followings at the connector side. Several MΩ between pin-5 – FG Several MΩ between pin-6 – FG Several MΩ between pin-7 – FG Several MΩ between pin-8 – FG Remove the HOPSIZE connector ③ of the PU board and check the followings at the connector side. Several MΩ between pin-1 – FG Several MΩ between pin-2 – FG Several MΩ between pin-3 – FG Several MΩ between pin-4 – FG | Replace either paper feed motor, belt motor or PU board. |

(6-4) Jam occurs immediately after paper has reached the fuser.

| Check item | Check work | Action to be taken at NG |
|---|--|---|
| (6-4-1) Motor operation check | | |
| Fuser motor | Confirm that the fuser motor works normally by using the Motor & Clutch Test of the self-diagnostic mode. Check if any load exists or not. | Replace the PU board. Replace the fuser motor. Replace the fuser unit. If any attempt of using new fuser unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |
| (6-4-2) Temperature control of the roller rotation speed | | |
| Heat roller detected temperature | Check the detected temperature of the heat roller using the self-diagnostic mode. Is abnormally high temperature or abnormally temperature detected? | Replace fuser unit, or relay board (PRY PCB) or the PU board. If any attempt of using new fuser unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |
| (6-4-3) Check the installation condition of fuser unit | | |
| Fuser unit | Check that the fuser unit is installed normally. (Is it pushed in down to the bottom-most point?) | Install the fuser unit correctly in a printer. |

7.5.2. (7) Paper unloading jam (error code 382)

(7-1) Paper unloading jam occurs immediately after the power is turned on.

| Check item | Check work | Action to be taken at NG |
|--|---|---|
| (7-1-1) Check condition of the paper running path | | |
| Paper running path of the paper unloading unit | Check if paper is jammed or not in the paper running path. | Remove the jammed paper. |
| (7-1-2) Check condition of the mechanical parts | | |
| Check the sensor lever of the paper exit sensor. | Check if shape and movement of the sensor levers have any abnormality or not. | Replace the sensor lever with the good sensor lever. |
| (7-1-3) Check condition of electrical parts | | |
| Check the detection condition of the sensor signal. | Confirm that the sensor signals are normally detected by using the SWITCH SCAN function of the self-diagnostic mode. | Replace the PU board or EXIT sensor or its cable or its connection cable. |
| Check the output signal level of the EXIT sensor. | Check for the following signals at the RELAY connector ③ of the PU board. Pin-9: EXIT sensor Confirm that the above signal levels change when the sensor lever is operated. | Replace the EXIT sensor. |
| Check the power voltages supplied to the relay board. | Check the 5V power voltage at the EXIT connector ⑥ of the relay board. Pin-1: 5V power supply Pin-3: 0VL | Replace the connection cable. |

| Check item | Check work | Action to be taken at NG |
|---|--|---|
| (7-1-4) Check the system connection | | |
| Signal cable for relay board, EXIT sensor cable | Check that FFC is normally inserted at the RELAY connector ⑧ of the PU board and at the PU IF connector ②. Check that the relay board and the EXIT sensor are normally connected. | Normalize the connection condition. |
| Signal cable for relay board, EXIT sensor cable | Confirm that the cables are not pinched, sheathes are not peeled off, and they are assembled normally. | Replace the connecting cable and normalize the assembled condition. |

(7-2) Paper unloading jam occurs after a paper is taken into printer.

| Check item | Check work | Action to be taken at NG |
|---|--|--|
| (7-2-1) Check condition of the paper running path | | |
| Face Up Stacker Cover | Confirm that it is either fully opened or fully closed | Eliminate any in-between condition of the cover between the fully open position and fully closed position. |
| Duplex pull-in gate | Confirm that the Duplex pull-in gate works normally by using the Motor & Clutch Test of the self-diagnostic mode. Is it set to the paper unloading side normally? | Replace the Duplex pull-in gate or the Duplex solenoid |
| Rear panel | Check that the installation condition of the rear panel hampers smooth movement of a paper in the paper running path, or not. | Remove the rear panel and re-install it. |
| Paper running path of unloading unit | Check that any mechanical load does not exist that hampers the smooth movement of paper in the paper running path of the paper unloading unit, by the visual inspection. Check if the paper unloading motor becomes difficult to rotate or not. | Correct the portion that becomes mechanical load. |

| Check item | Check work | Action to be taken at NG |
|---|---|---|
| (7-2-2) Check condition of the mechanical parts | | |
| Sensor lever of the paper exit sensor | Check if shape and movement of the sensor levers have any abnormality or not. | Replace the sensor lever with the good sensor lever. |
| (7-2-3) Motor operation check | | |
| Fuser motor | Confirm that the fuser motor works normally by using the Motor & Clutch Test of the self-diagnostic mode. Check if any load exists or not. | Replace the PU board or fuser motor or fuser unit. If any attempt of using new fuser unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |
| (7-2-4) Check the system connection | | |
| Fuser motor drive cable | Check the connection condition of the cables. PU board DCHEAT connector ④, Check if the connector is connected in the half-way only or not, and check if the connector is inserted in a slanted angle or not. Check also that cables are assembled without any abnormality. | Replace the cable with the good cable that normalizes the connection condition. |
| Fuser motor | | Replace the fuser motor. |

(7-3) Paper unloading jam occurs in the middle of paper running path.

| Check item | Check work | Action to be taken at NG |
|-------------------------------|---|---|
| (7-3-1) Motor operation check | | |
| Fuser motor | Confirm that the fuser motor works normally by using the Motor & Clutch Test of the self-diagnostic mode. Check if any load exists or not. | Replace the PU board or fuser motor or fuser unit. If any attempt of using new fuser unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |

7.5.2. (8) Two-sided printing jam (error code: 370, 371, 372, 373, 383)

(8-1) Two-sided printing jam occurs immediately after the power is turned on.

| Check item | Check work | Action to be taken at NG |
|---|--|--|
| (8-1-1) Check condition of the paper running path | | |
| Paper running path of the Duplex unit | Check if paper is jammed or not in the paper running path. Open the front cover and check if any paper remains in the Duplex feeder or not. Open the rear cover and check if any paper remains in the paper reversing path or not. Remove the Duplex unit. Check if any paper exists in the Duplex insertion slot or not. Open the cover of the Duplex paper running path and check if any paper remains inside of the Duplex unit. | Remove the jammed paper. |
| (8-1-2) Check condition of the mechanical parts | | |
| Check the sensor levers of the respective sensors of the Duplex unit. | Check if shape and movement of the sensor levers have any abnormality or not. | Replace the sensor lever with the good sensor lever. |
| (8-1-3) Check condition of electrical parts | | |
| Check the detection condition of the sensor signal. | Confirm that the sensor signals are normally detected by using the SWITCH SCAN function of the self-diagnostic mode. For all sensors except the Dup-IN sensor, check the detection condition of the respective sensor in the two status: One is the status in which paper remains inside the Duplex unit. The other is the status in which paper is removed from the Duplex unit. | Replace the Duplex board (V7Y PCB), or replace the defective sensor or connection cable. |

(8-2) Two-sided printing jam occurs during taking in the paper into Duplex unit.

| Check item | Check work | Action to be taken at NG |
|--|--|--|
| (8-2-1) Solenoid operation check | | |
| Duplex solenoid | Confirm that the Duplex solenoid works normally by using the Motor & Clutch Test of the self-diagnostic mode. | Replace the V7Y board or solenoid. |
| Separator DUP (Paper unloading/ DUP paper taking-in switching gate located immediately after the fuser unit) | Check visually movement of the gate by using the Motor & Clutch Test of the self-diagnostic mode. (EXIT SOLENOID) Check if movement is unsmooth or not, if amount of open/close is abnormal or not. | Replace the separator DUP. |
| ON/OFF timing of the Duplex solenoid | While the cover is in the opened state, perform the test print and confirm if the timing to open the separator DUP is correct or not. | Replace the WR sensor lever or solenoid. |
| (8-2-2) Sensor lever operation check | | |
| Dup-IN sensor lever | Open the rear cover. Touch the Dup-IN sensor lever to check if its movement is unsmooth or not. | Replace the Dup-IN sensor lever |
| DUP-IN sensor | Confirm that the sensor signals are normally detected by using the SWITCH SCAN function of the self-diagnostic mode. | Replace the Duplex board (V7Y PCB), or replace the defective sensor or connection cable. |
| (8-2-3) Check condition of the paper running path | | |
| Paper inverting transport path | Check that any foreign materials such as paper chip or blue do not exist that hampers the smooth movement of paper in the paper inverting transport path. | Remove the foreign material. |

| Check item | Check work | Action to be taken at NG |
|--|--|---------------------------------|
| (8-2-4) Motor operation check | | |
| Duplex motor | Confirm that the Duplex solenoid works normally by using the Motor & Clutch Test of the self-diagnostic mode. Open the rear cover and check rotation of the roller. | Replace the V7Y board or motor. |
| Duplex pull-in/reversing roller and its pinch roller | Check if the pull-in/reversing roller of the Duplex unit contacts or not with the pinch roller of the cover side when the Duplex rear cover is closed. (Does the pinch roller rotate when the roller is rotating?) | Replace the rear cover. |

(8-3) Two-sided printing jam occurs in the process of reversing paper.

| Check item | Check work | Action to be taken at NG |
|---|---|--|
| (8-3-1) Sensor lever operation check | | |
| Dup-IN sensor lever | Open the rear cover. Touch the Dup-IN sensor lever to check if its movement is unsmooth or not. | Replace the Dup-IN sensor lever |
| DUP-IN sensor | Confirm that the sensor signals are normally detected by using the SWITCH SCAN function of the self-diagnostic mode. | Replace the Duplex board (V7Y PCB), or replace the defective sensor or connection cable. |
| (8-3-2) Motor operation check | | |
| Duplex motor | Check if the paper reversing operation is started or not by visual inspection when viewing through slit of the rear cover. If the paper reversing operation is not started, check if movement of the planetary gear inside the Duplex unit is unsmooth or not. | Replace the planetary gear. |

(8-4) Two-sided printing jam occurs during transporting paper inside the Duplex unit.

| Check item | Check work | Action to be taken at NG |
|--|--|--|
| (8-4-1) Sensor lever operation check | | |
| Dup-R, Dup-F sensor lever | Remove the Duplex unit and check movement of the sensor lever. | Replace the sensor lever. |
| (8-4-2) Sensor check | | |
| Check the detection condition of the sensor signal | Confirm that the sensor signals are normally detected by using the SWITCH SCAN function of the self-diagnostic mode. For all sensors except the Dup-IN sensor, check the detection condition of the respective sensor in the two status: One is the status in which paper remains inside the Duplex unit. The other is the status in which paper is removed from the Duplex unit. | Replace the Duplex board (V7Y PCB), or replace the defective sensor or connection cable. |

(8-5) Paper is not supplied from the Duplex unit to the regist roller.

| Check item | Check work | Action to be taken at NG |
|--------------------------------|---|----------------------------------|
| (8-5-1) Clutch operation check | | |
| Duplex clutch | Confirm that the Duplex clutch works normally by using the Motor & Clutch Test of the self-diagnostic mode. Confirm it by listening to the sound. | Replace the V7Y board or clutch. |

7.5.2. (9) Paper size error (error code 400)

(9-1) Jam occurs when paper end is located near the IN1 sensor.

| Check item | Check work | Action to be taken at NG |
|------------------------------------|--|---|
| (9-1-1) Check paper feed condition | | |
| Multifeed of papers | Open the front cover and check if multifeed of papers occurs or not. | If the multifeed occurs again after the jammed paper is removed, replace the flap of the tray in use. |
| Paper size | Does the paper size specified for print match the paper size of paper stuck in the tray. | Change the specified paper size or size of paper inside the tray. |
| Paper entrance sensor 1 | Check if shape and movement of the sensor levers have any abnormality or not. | Replace the sensor lever with the good sensor lever. |

7.5.2. (10) ID unit Up/Down error (Service call 140 to 143)

(10-1) Error occurs during the Up movement of the ID unit

| Check item | Check work | Action to be taken at NG |
|---|--|--|
| (10-1-1) Check the mechanical load during the Up movement | | |
| Mechanical load during installation and removal of the ID unit | Check if abnormal heavy load is applied when removing the ID unit. | Replace the ID unit, or replace the right/left side plate. If any attempt of using new ID unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |
| Greasing to the right and left Up/Down link levers | Check if the slant surface of the link lever is coated by grease or not. | Apply grease. |
| Assembled condition of the right and left Up/Down link levers | Check if any part exists or not in the vicinity of link lever, that hampers movement of the link lever. | Assemble them correctly. |
| (10-1-2) Up/Down mechanism | | |
| Assembled condition of the peripheral mechanism of the link lever | Is the mechanism assembled so that the link lever is connected to the planetary driving gear? | Assemble them correctly. |
| Right and left link levers | Check if the link lever is set in the correct position that enables the specified engagement of gears. (Check if the link lever is set in the wrong position that results in the wrong engagement of gears by several teeth.) | Assemble them correctly. |

| Check item | Check work | Action to be taken at NG |
|---|---|---------------------------------|
| (10-1-3) Sensor check | | |
| Up/Down sensor lever (unified structure with the left link lever) | Check if shape and movement of the sensor levers have any abnormality or not. | Replace the left link lever. |
| Up/Down sensor | Confirm that the sensor signals are normally detected by using the SWITCH SCAN function of the self-diagnostic mode. Check if the SCAN state changes or not when the incoming light is interrupted/passed by using a piece of paper or the like for the transparent type sensor. | Replace the high voltage board. |

(10-2) Error occurs during the Down movement of the ID unit

| Check item | Check work | Action to be taken at NG |
|--|---|--|
| (10-2-1) Check the mechanical load during the Down movement | | |
| Mechanical load during installation and removal of the ID unit | Check if abnormal heavy load is applied when removing the ID unit. | Replace the ID unit, or replace the right/left side plate. |
| Greasing to the right and left Up/Down link levers | Check if the slant surface of the link lever is coated by grease or not. | Apply grease. |
| Assembled condition of the right and left Up/Down link levers | Check if any part exists or not in the vicinity of link lever, that hampers movement of the link lever. | Assemble them correctly. |

7.5.2. (11) Fuser unit error (error 170 to 177)

(11-1) Error occurs immediately after the power is turned on.

| Check item | Check work | Action to be taken at NG |
|--|--|---|
| (11-1-1) Thermistor is defective Note) | | |
| Upper thermistor, lower thermistor, frame thermistor | Check the respective thermistors if they are shorted or opened internally. Check the resistance value at the connector pins in the bottom of the fuser unit. (Refer to section 8.1 Resistance check (fuser unit).) | Replace the fuser unit. If any attempt of using new fuser unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |
| Installed condition of fuser unit. | Check if the fuser nit is pressed in until the connector in the bottom of the fuser unit is surely connected. | Re-set the fuser unit. |

Note! Service calls 171 error and 171 error can occur when the printer temperature is below 0°C. Turn on the power again after the printer temperature has increased.

(11-2) Error occurs approx. 1 minute after the power is turned on.

| Check item | Check work | Action to be taken at NG |
|---|--|---|
| (11-2-1) Temperature increase of fuser unit | | |
| Thermostat, halogen lamp | Heater of the fuser unit is controlled of its temperature. Check if the fuser unit gets hot or not by touching it with hands. If the fuser unit temperature does not increase and remains cold, check that the resistance between pin-1 and pin-2, and that in between pin-3 and pin-4 of the two connectors is in the range of several ohms to several ten ohms respectively. (Refer to section 8.1 Resistance value (fuser unit).) | Replace the fuser unit. If any attempt of using new fuser unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |

| Check item | Check work | Action to be taken at NG |
|---|--|---|
| (11-2-2) Temperature increase of fuser unit | | |
| Installation position of the upper thermistor | Check if the upper thermistor is installed in the far position from the specified position or not causing detection of the lower temperature than the actual temperature of fuser unit. Remove the heater cover, and check warpage of sensor by visual inspection. | Replace the fuser unit. If any attempt of using new fuser unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |
| Installation position of the lower thermistor | The lower thermister must be installed while contacting with the fuser unit. Check if the lower thermister is installed in the far position from the specified position or not causing detection of the lower temperature than the actual temperature of fuser unit. | Replace the fuser unit. If any attempt of using new fuser unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |
| (11-2-3) AC power input to the halogen lamp | | |
| AC power voltage from the low voltage power supply | Check if the AC voltage for heater is normally supplied or not. Power supply CN2 connector ②④, between pin-1 and pin-2, and between pin-3 and pin-4. | Replace the low voltage power supply. |
| Heater ON signal that is output from PU to the low voltage power supply | Check that the heater ON signal goes active at the warming up timing, or not. "L" active while ON. Power connector ⑩ of the PU board, between pin-11 and pin-12. | Replace the PU board. |

7.5.2. (12) Motor fan error (error code 122, 127, 128, 918, 051)

(12-1) The low voltage power supply fan does not rotate immediately after the power is turned on.

| Check item | Check work | Action to be taken at NG |
|--|--|--|
| (12-1-1) Cable connection condition and wiring condition | | |
| Cable connection condition and wiring condition of the low voltage power supply fan and those of the fuser fan | Check if the connectors are connected normally or not. Check if extra length of the cables does not touch the fan blade or not. | Correct the connection condition of the connectors. Correct the cable wiring route. Replace the fan. |

(12-2) Duplex fan does not rotate during the Duplex printing.

| Check item | Check work | Action to be taken at NG |
|---|--|---|
| (12-1-2) Cable connection condition and wiring condition | | |
| Cable connection condition and wiring condition of the Duplex fan | Check if the connectors are connected normally or not. Check if extra length of the cables does not touch the fan blade or not. | Correct the connection condition of the connectors. Correct the cable wiring route. Replace the fan. Replace the fan. |
| 24V fuse F501 of the Duplex board (V7Y PCB) | Check if the fuse F501 has blown out or not. | Replace the Duplex board (V7Y PCB). |
| 24V power supplied to the Duplex board (V7Y PCB). | Check if the fuse F1 of the PU board has blown out or not. | Replace the PU board. |

(12-3) All fans of the printer do not rotate.

| Check item | Check work | Action to be taken at NG |
|---|--|---------------------------------------|
| (12-3-1) 24V power supply | | |
| PU board fuses F4, F5 | Check if the fuses F4 and F5 are not open-circuit or not. | Replace the PU board. |
| 24V power that is supplied to the PU board. | Check the power supply voltages at the POWER connector ⑩ of the PU board. The follow voltage must appear respectively. Pins-4, 5 and 6: 24V Pin-8: 0VL Pins-1, 2 and 3: 0VP | Replace the low voltage power supply. |

7.5.2. (13) Print speed is slow. (Performance is low.)

(13-1) Print speed decreases.

| Check item | Check work | Action to be taken at NG |
|--|--|---------------------------|
| (13-1-2) Media Weight setting | | |
| Media Weight that is specified for the print | Check if the wrong Media Weight has been specified or not. | Correct the Media Weight. |

7.5.2. (14) Option unit cannot be recognized.

(14-1) Duplex unit cannot be recognized.

| Check item | Check work | Action to be taken at NG |
|--|---|------------------------------|
| (14-1-1) Duplex board | | |
| Duplex unit | Check if the Duplex unit of C710dn specification is being used or not. | Replace the Duplex unit. |
| (14-1-2) Check the system connection | | |
| Check the system connection from the PU board to the Duplex board (V7Y PCB). | Check that the cable between the PU board option connector ⑬ to the Duplex board is normally connected. | Correct the connections. |
| Square connector connecting the Duplex unit to the printer. | Check if any foreign material exists in the connecting portion of the square connector. | Remove the foreign material. |
| Square connector connecting the Duplex unit to the printer. | Is the terminals of the square connector damaged? | Replace the connector. |
| (14-1-3) Check the control signals. | | |
| Check the control signal that is output from the PU board to the Duplex board (V7Y PCB). | Check the control signal that is output from the PU board option connector ⑬. Pin-6: TXD (PU → DUP) Pin-4: RXD (DUP → PU) | Replace the PU board. |

(14-2) Option try unit cannot be recognized.

| Check item | Check work | Action to be taken at NG |
|---------------------------|--|-------------------------------|
| (14-2-1) Option try board | | |
| Option try unit | Check if the option try unit of C710dn specification is being used or not. | Replace the option tray unit. |

| Check item | Check work | Action to be taken at NG |
|---|---|------------------------------|
| (14-1-2) Check the system connection | | |
| Check the system connection from the PU board to the option tray board (V7Y PCB). | Check that the cable between the PU board option connector ⑬ to the option tray board is normally connected. | Correct the connections. |
| Square connector connecting the option tray unit to the printer. | Check if any foreign material exists in the connecting portion of the square connector. | Remove the foreign material. |
| Square connector connecting the option tray unit to the printer. | Is the terminals of the square connector damaged? | Replace the connector. |
| (14-2-3) Check the control signals. | | |
| Check the control signal that is output from the PU board to the option tray board (V7Y PCB). | Check the control signal that is output from the PU board option connector ⑬. Pin-5: TXD (PU → 2nd) Pin-3: RXD (2nd → PU) | Replace the PU board. |

7.5.2. (15) LED head cannot be recognized. (error code 131, 132, 133, 134)

(15-1) Service call 131 to 134 (LED HEAD Missing)

| Check item | Check work | Action to be taken at NG |
|---|--|--|
| (15-1-1) Check the system connection | | |
| Connecting condition at the CU board connector and at the head connector. | Check the connecting condition of the FFC by the visual inspection. | Correct the connection to the normal connecting condition. |
| Head FFC | Remove the head FFC from the printer. Check if any open-circuit or peeling-off of sheath has occurred or not throughout the cable. | Replace the head FFC or the CU board. |
| Conduction of the fuse on the CU board. | Check that 5V appears across the capacitors CP7 and CP8. (Refer to section 7.6.) | Replace F504, F506 or replace the CU board. |

7.5.2. (16) Toner cartridge cannot be recognized. (error code 540, 541, 542, 543)

(16-1) Error caused by the consumable items.

| Check item | Check work | Action to be taken at NG |
|--|---|--|
| (16-1-1) Consumable items installation condition | | |
| ID unit and toner cartridge | Check that the ID unit is installed in the normal position. Check that the lock lever of the toner cartridge is locked. | Correct the installation to the normal installation condition. |

(16-2) Error caused by the toner sensor

| Check item | Check work | Action to be taken at NG |
|---------------------------------|---|--|
| (16-2-1) Toner sensor condition | | |
| Toner sensor | Is the receptor of the toner sensor stained? | Wipe off the stain from the toner sensor. |
| Toner sensor | Confirm that the toner sensor works normally by using the SWITCH SCAN function of the self-diagnostic mode. Place a white paper in front of the toner sensor, and check if the SCAN state changes or not. | Replace the toner sensor board, or the PU board, or the FFC between the toner sensor board and the PU board. |

Note! Toner sensor operation check method using the SWITCH SCAN function of the self-diagnostic mode.

(1) How to check operation of the toner sensor at the printer side.

- Status change of the toner sensor can be checked from the Operator Panel using the self-diagnostic mode. First, switch the display to the Operator Panel display. For the method of switching the display to the Operator Panel display, refer to section 5.3.2.3 Switch Scan Test
- Remove the ID unit and the toner cartridge (TC) from a printer. There is a window inside a printer opposing the ID side when viewed from the front of a printer. The toner sensor is located inside the window.
- Place a white paper 3 mm away from the sensor window. The white paper should be placed in the manner of opposing the toner sensor.
- When light is reflected by a white paper so that incident light falls on the toner sensor, the Operator Panel display shows "L". When the paper is moved so that any light is not reflected by the paper so that the incident light does not reach the toner sensor, "H" is displayed on the Operator Panel.
- If the Operator Panel display toggles between "H" <-> "L" as a paper is flipped in front of the toner sensor, it indicates that the toner sensor and the related system of the printer are working normally.

Action to be taken at NG

- Clean surface of the toner sensor to remove the stains due to residual toner and paper dust.
- Check the connection condition of the FFC cable at the PU main board (PU) and at the toner sensor board (PRZ).
- Perform the operation check again. If the situation is not improved and remains unchanged, replace the PU main board (PU) or the toner sensor board (PRZ).

(2) How to check operation of the toner sensor at the toner cartridge (TC) side

- To the position where the toner sensor is confirmed to be operating normally in the printer itself by the above paragraph (1), install the TC and the ID unit to check operations by observing display on the Operator Panel.
- If the ID unit works normally, the display on the Operator Panel will toggle between "H" <-> "L" in synchronism with movement of the silver reflector plate that is located on the side of the ID.

Action to be taken at NG

- Check operation condition of the respective ID motors by using the Motor & Clutch Test of the self-diagnostic mode.
- Clean surface of the silver reflector plate on the side of ID to remove stains. (Stain due to toner or paper dust)
- Replace the TC of different color and the ID unit as a pair.
If a satisfactory operation is attained by using the a pair of TC of different color and the ID unit, replace the TC or replace the ID unit.

(16-3) Error caused by the defective mechanism

| Check item | Check work | Action to be taken at NG |
|--|--|--|
| (16-3-1) Mechanical load applied to the ID unit | | |
| ID unit | Check if a heavy mechanical load is being applied to the ID unit due to breakage of the waster toner belt, or not. | Replace the ID unit. If any attempt of using new ID unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |
| (16-3-2) Motor operating condition | | |
| ID motor | Confirm that the respective ID motors work normally or not by using the Motor & Clutch Test of the self-diagnostic mode. Check if any extra load exists or not. | Replace the PU board or the ID motor. |

7.5.2. (17) Fuse cut error (error codes 150 to 155)

(17-1) Fuse cut error

| Check item | Check work | Action to be taken at NG |
|--|---|--|
| (17-1-1) Check the system connection | | |
| FFC connecting the PU board and the toner sensor board (PRZ PCB) | Check if the connector is connected in the half-way only or not, and is inserted in a slanted angle or not at the SSNS connector ⑮ of the PU board, and at the SSNS connector ⑳ of the toner sensor board (PRZ PCB). Check if FFC has open-circuit of sheath of the FFC has not peeled off or not. | Connect the FFC normally. Alternately, replace the FFC. |
| (17-1-2) Fuse cut circuit | | |
| PU board | Upon completion of the system connection check, turn off the power once and back on. The, check if the error occurs or not. | Replace the PU board. |


7.5.2. (18) Humidity sensor error (error code 123)

(18-1) Humidity sensor error

| Check item | Check work | Action to be taken at NG |
|--|--|--------------------------------------|
| (18-1-1) Check the system connection | | |
| Connection between the PU board and Operator Panel | Check if the 10-conductor FFC is connected to the OPE connector ⑰ of the PU board normally or not. Check if the 10-conductor FFC is connected to the CN1 connector ⑱ of the Operator Panel board normally or not. Check if the connector is connected in the half-way only or not, and check if the connector is inserted in a slanted angle or not. | Re-connect the cable normally. |
| FFC connecting the PU board and the Operator Panel board | Check for open-circuit with VOM. Check that peeling off of sheath does not occur in any cables by visual inspection. | Replace the FFC with the normal FFC. |

| Check item | Check work | Action to be taken at NG |
|---------------------------------------|--|--|
| (18-1-2) Environment condition | | |
| Sharp change of environment condition | Is the environment condition changed sharply from a low temperature environment to a high environment condition within a short time? (Example is such a case that a printer is moved from storage condition of a cold area in winter to an office environment.) | Leave a printer for around one hour in the new environment to get used to the new environment. After that, turn on the power again. Before turn on the power, touch the metal panel of the controller panel and the metal plate inside a printer to feel temperature increase inside a printer with human hands. After confirmation that the printer temperature has increased close to the room temperature, turn on the power again. |

7.5.2 (19) Wiring diagram



7.5.3 Troubleshooting the abnormal images

| | |
|---|-----|
| (1) Color has faded-out and blurred entirely. (Refer to Figure 7-2A.)..... | 181 |
| (1-1) Color are faded-out and blurred. | 181 |
| (2) Stain on white print (Refer to Figure 7-2B.)..... | 182 |
| (2-1) Stain on white print (Partial stain)..... | 182 |
| (2-2) Stain on white print (overall stain)..... | 182 |
| (3) White print (Refer to Figure 7-2C.)..... | 183 |
| (3-1) White print over entire page..... | 183 |
| (4) Black banding/black streaking in vertical direction..... | 184 |
| (4-1) Thin vertical line (with color) (Refer to Figure 7-2D.) | 184 |
| (4-2) Thin vertical line (without color) (Refer to Figure 7-2F.)..... | 184 |
| (5) Cyclic abnormality (Refer to Figure 7-2E.)..... | 184 |
| (5-1) Cyclic abnormality occurs in vertical direction | 184 |
| (6) Heavy color registration error..... | 185 |
| (6-1) Display of the message "Color adjustment is in progress" appears only short time. | 185 |
| (6-2) Though REG ADJUST TEST of engine maintenance function is ok, color blur occurs | 185 |
| (7) Entirely black print..... | 185 |
| (7-1) All black print over entire page..... | 185 |

Note! When an attempt is going to be made to replace the PU board, read data contents of the EEPROM chip from the old PU board beforehand, and copy the data contents into the new board after the new PU board is installed.




Figure 7-2

7.5.3.(1) Color has faded-out and blurred entirely. (Refer to Figure 7-2A.)

(1-1) Color are faded-out and blurred.

| Check item | Check work | Action to be taken at NG |
|---|---|---|
| (1-1-1) Toner | | |
| Remaining amount of toner | Check if the message "Prepare toner replacement." or "Replace the toner." appears or not. | Replace toner cartridge with new one. |
| Tape attached to the toner cartridge opening slot | Check to see that the tape attached to the toner cartridge opening slot has been peeled off. | Move the toner cartridge lever to CLOSE position and remove tape from opening slot. |
| (1-1-2) LED head | | |
| Lens of the LED head | Check if surface of the lens of the LED head is stained or not by toner and paper dust. | Clean the lens with soft tissue paper. |
| Mounting condition of LED head | Check that the LED head is mounted on the LED head holder correctly. Check that the right and left tension springs are normally installed. | Correct for normal condition. |
| (1-1-3) Print media | | |
| Media type | Check to see that the print media which is used for printing is not a specially thick media | Use the normal paper. |
| (1-1-4) High voltage terminal | | |
| ID unit terminal | Check that the high voltage terminal of the ID unit is contacting with the Contact Assembly normally by visual inspection. (Refer to Figure 7-3.) | Replace the ID unit or correct the high voltage terminal. If any attempt of using new ID unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |

| Check item | Check work | Action to be taken at NG |
|---|---|--|
| (1-1-5) ID unit installation condition | | |
| ID unit DOWN position (Defective transfer) | Move the ID unit in and out with hand to confirm that any abnormal mechanical load does not exist, and the ID unit can be moved down to the DOWN position normally. If a piece of paper is inserted in between drum and belt, if top end of the paper can enter easily, it is NG (No Good). | Check the U-shaped groove of the side plate for any abnormality. If repair is found impossible, replace the equipment. |

7.5.3.(2) Stain on white print (Refer to Figure 7-2B.)

(2-1) Stain on white print (Partial stain)

| Check item | Check work | Action to be taken at NG |
|--------------------------------|--|---|
| (2-1-1) ID unit | | |
| Exposure of drum to light | Is the drum left in a circumstance in which drum surface is exposed to direct light for a long time? | Replace the ID unit. If any attempt of using new ID unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |
| Leakage of toner | Does toner leak out from either ID unit or from toner cartridge? | Replace the ID unit or toner cartridge. If any attempt of using new ID unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |
| (2-1-2) Fuser unit | | |
| Offset toner of the fuser unit | Check if the offset toner of the previous printing is left adhered on the fuser unit or not, by visual inspection. | Repeat blind printing using unwanted media until offset toner is created on print media. Alternately replace the fuser unit. If any attempt of using new fuser unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |

(2-2) Stain on white print (overall stain)

| Check item | Check work | Action to be taken at NG |
|--------------------------------------|---|---|
| (2-2-1) Print media | | |
| Type of print media | Check to see that the print media which is used for printing is not a specially thin media. | Use the normal paper. |
| (2-2-2) High voltage terminal | | |
| ID unit terminal | Check that the high voltage terminal of the ID unit is contacting with the Contact Assembly normally by visual inspection. (Refer to Figure 7-3.) | Replace the ID unit or correct the high voltage terminal. If any attempt of using new ID unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |

7.5.3.(3) White print (Refer to Figure 7-2C.)

(3-1) White print over entire page

| Check item | Check work | Action to be taken at NG |
|--------------------------------------|---|--|
| (3-1-1) Toner condition | | |
| Remaining amount of toner | Confirm that sufficient amount of toner remains inside the toner cartridge. | Replace the toner cartridge. |
| (3-1-2) Exposure condition to light | | |
| LED head | Confirm that the LED head is positioned in the normal position where the LED head opposes again the drum when the cover is closed. Check that no obstacle exists in front of the LED head, that hampers light emission from the illuminating surface of the LED head. | Correct the installation condition of the LED head. |
| Connecting condition of the LED head | Check that the LED head is normally connected. | Replace the LED head. |
| Drum shaft | Check that the drum shaft keeps contacting with the right and left side plates normally. | Replace the ID unit. If any attempt of using new ID unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |
| F506, fuse on the CU board | Measure resistance of F506. 1 ohm or less: Normal Higher than 1 ohm: NG | Replace the CU board |

| Check item | Check work | Action to be taken at NG |
|-------------------------------|---|---|
| (3-1-3) High voltage terminal | | |
| ID unit terminal | Check that the high voltage terminal of the ID unit is contacting with the Contact Assembly normally by visual inspection. (Refer to Figure 7-3.) | Replace the ID unit or correct the high voltage terminal. If any attempt of using new ID unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |

7.5.3.(4) Black banding/black streaking in vertical direction

(4-1) Thin vertical line (with color) (Refer to Figure 7-2D.)

| Check item | Check work | Action to be taken at NG |
|----------------------------------|-----------------------------------|--|
| (4-1-1) ID unit condition | | |
| Filming of the ID unit | Is print attempted without toner? | Replace toner cartridge with new one. If replacement does not solve the problem, replace the ID unit. If any attempt of using new ID unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |

(4-2) Thin vertical line (without color) (Refer to Figure 7-2F.)

| Check item | Check work | Action to be taken at NG |
|--|--|------------------------------|
| (4-2-1) LED head condition | | |
| LED head | Is any foreign material attached on the light emitting surface of the cell fox lens of the LED head? | Remove the foreign material. |
| (4-2-2) Condition of paper running path | | |
| Paper running path | Check that any burr that may scatter the unfused toner on the paper running path does not exist. | Remove the burr. |

7.5.3.(5) Cyclic abnormality (Refer to Figure 7-2E.)

(5-1) Cyclic abnormality occurs in vertical direction

| Check item | Check work | Action to be taken at NG |
|------------------------|-----------------------------------|--|
| (5-1-1) Cycle | | |
| Image drum | Check that the cycle is 94.3 mm. | Replace the ID unit |
| Developing roller | Check that the cycle is 39.7 mm. | Replace the ID unit |
| Toner feed roller | Check that the cycle is 58.4 mm. | Replace the ID unit |
| Charge roller | Check that the cycle is 37.7 mm. | Replace the ID unit |
| Roller on top of fuser | Check that the cycle is 87.7 mm. | Replace the fuser unit. |
| Fuser belt | Check that the cycle is 125.5 mm. | Replace the fuser unit. |
| Transfer roller | Check that the cycle is 50.3 mm. | Replace the belt unit. |
| | | If any attempt of using new consumable item as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |

7.5.3.(6) Heavy color registration error

(6-1) Display of the message "Color adjustment is in progress" appears only short time.

| Check item | Check work | Action to be taken at NG |
|--|--|--|
| (6-1-1) Result of color registration error correction | | |
| Color registration error correction time (If a printer is normal, it is approx. 40 seconds.) | Use the self-diagnostic mode and execute the REG ADJUST TEST. Check the result. Error is issued but is not displayed on the ON LINE display. | Replace the sensor that causes the error. Clean the sensor to remove stain. Replace the shutter. Replace the PU board. |
| (6-1-2) Toner | | |
| Remaining amount of toner | Check if the message "Prepare toner replacement." or "Replace the toner." appears or not. | Replace toner cartridge with new one. |
| (6-1-3) Color registration error detection sensor | | |
| Sensor is dirty | Is toner or paper dust attached to the sensor? | Clean the sensor to remove stain |
| (6-1-4) Color registration error detection sensor shutter | | |
| Shutter operation is faulty | Check the shutter operation by the self-diagnostic mode | Replace the shutter or tune the mechanism |

(6-2) Though REG ADJUST TEST of engine maintenance function is ok, color blur occurs

| Check item | Check work | Action to be taken at NG |
|---|--|--------------------------|
| (6-2-1) Paper feed system | | |
| Paper feed system of the paper running path | Check if any obstacle exists in the paper feeding path, that hampers smooth paper run. | Remove the obstacle |

7.5.3.(7) Entirely black print

(7-1) All black print over entire page

| Check item | Check work | Action to be taken at NG |
|---|---|---|
| (7-1-1) High voltage contacting condition | | |
| CH terminal | Check that the terminal coming from the printer body contacts with the high voltage terminal that is located on the left side of the ID unit when viewed from the top by visual inspection. | Replace the terminal of printer side. |
| CH terminal | Check that the high voltage terminal keeps the normal contacting condition on the high voltage board. Open the left cover and remove the high voltage board. Then, check that the terminal is not installed in the abnormal installation condition. | Correct the installation condition of the terminal to the normal condition. |
| ID unit terminal | Check that the high voltage terminal of the ID unit is contacting with the Contact Assembly normally by visual inspection. (Refer to Figure 7-3.) | Replace the ID unit or replace the high voltage board or correct the high voltage terminal. If any attempt of using new ID unit as a trial is going to be made, be sure to use the System Maintenance Menu FUSE KEEP MODE. |
| (7-1-2) High voltage output condition | | |
| CH output | If high voltage probe is available as a maintenance tool, open the left cover, and check the CH output with the high voltage probe from the soldering side of the high voltage board. (The high voltage probe is not an ordinary maintenance tool.) | Replace the high voltage board. |




Figure 7-3

7.5.4 Network troubleshooting

(1) Print cannot be activated from Utilities.

| Check item | Check work | Action to be taken at NG |
|--|--|---|
| (1) Check the LINK lamp | | |
| Check if the LINK lamp (green) is illuminating or not. | Check if the HUB and a printer are connected normally. (Check that the network cable is connected normally.) | Re-connect the network cable normally. |
| | Confirm that the straight network cable is being used. | Replace the cable with the straight cable. |
| | Make an attempt to change connection of the network cable to other port of a HUB. | Try to change the HUB. |
| (2) Check the network information | | |
| Check if the network information can be printed normally or not. | Press the Push switch of the NIC card to print the network information. | Re-write the NIC-F/W by using Utilities. |
| (3) Check contents of the network information. | | |
| Confirm the IP address, SUB net mask and gateway address. | Confirm the IP address, SUB net mask and gateway address that are printed on the network information. | Set the IP address, SUB net mask and gateway address normally. |
| (4) Check if communication is possible or not through network | | |
| Confirm if the Ping command can be sent or not from a PC to a printer. | Confirm if correct reply is returned from a printer to a PC when the PC sends the Ping to a printer. | Set the IP address, SUB net mask and gateway address normally. |
| (5) Check the Utilities. | | |
| Check setting of the OKI LPR Utilities. | Check the setting items of the OKI LPR Utilities. | Set the OKI LPR Utilities setting items correctly. |
| (6) Check the following from an OS standard port | | |
| Confirm the standard LPR port of the WINDOWS standard (NT, 2000, XP). | Set the standard LPR port of the WINDOWS standard (NT, 2000, XP), and confirm if printing can be performed or not. | Set the standard LPR port of the WINDOWS standard (NT, 2000, XP) correctly. |

7.5.4.1 Connection error occurs with the Web browser

If the printer setting page cannot be displayed by the web browser "https://<printer IP address>", check the followings.

Establish connection by "https://<printer IP address>".

- 1) If the printer setting page is displayed, the followings are probable.
 - Take an appropriate measure by referring to the following items.
 - * Certificate is not created yet. (Or failed to create certificate.)
 - Refer to section "7.5.4.1.1 Is the certificate created?".
 - * Certificate has been created but the SSL/TLS setting is turned off.
 - Refer to section "7.5.4.1.2 Is the SSL/TLS setting set to [ON]?".
- 2) If the printer setting page is not displayed, the followings are probable.
 - * Version number of the browser is old.
 - Refer to section "7.5.4.1.3 Check version number of the Web browser".
 - * Encryption strength has been set to Strong.
 - Refer to section "7.5.4.1.3 Check encryption strength of a printer".
 - * The key exchange system of a printer is not supported by the browser. (Compatibility problem)
 - Refer to section "7.5.4.1.5 Check the key exchange type of the certificate".

7.5.4.1.1 Is the certificate created?

Log-on in as the administrator, and select "Security" → "Encryption (SSL/TLS)".

If the following screen is displayed, certificate of the printer is not created yet. (The same screen is displayed when failed to create certificate.)

Solution: Create certificate by referring to the User's Manual (Advanced edition).




Before creating certificate (default state)

7.5.4.1.2 Is the SSL/TLS setting set to [ON]?

Log-on in as the administrator, and select "Security" → "Encryption (SSL/TLS)".

If the following screen is displayed, certificate has already been created, but the SSL/TLS setting is turned [OFF].

Solution: Set the SSL/TLS setting to [ON].



7.5.4.1.3 Check version number of the Web browser

Check version number of the Web browser in use.

How to check version number.


For Internet Explorer

Launch the browser and select "HELP" → "Version information".

Recommended version is Internet Explorer 5.5 and higher.

Solution : Install the newest web browser. Alternately, install the high encryption pack.

If any version that is older than the recommended version is used, communication can become possible sometimes when the encryption strength is set to "Weak". If the encryption strength is set to "Weak", security level lowers. To change the encryption strength, refer to section "7.5.4.1.4 Confirm encryption strength of a printer".




For Netscape

Launch the web browser and select "HELP" → "Netscape".

Recommended version is Netscape 6 and higher.

Solution : Install the newest web browser.


If any version that is older than the recommended version is used, communication can become possible sometimes when the encryption strength is set to "Weak". If the encryption strength is set to "Weak", security level lowers. To change the encryption strength, refer to section "7.5.4.1.4 Confirm encryption strength of a printer".



7.5.4.1.4 Confirm encryption strength of a printer


Version display of the browser that is confirmed by section "7.5.4.1.3 Check version number of the Web browser" has description on encryption strength of the browser. The browser in which the encryption strength is not set to 128 bits, the browser cannot establish communication with the printer in which the encryption strength is not set to "Standard".

Either, upgrade the browser until it supports 128 bits (high encryption) or set the printer encryption strength to "Weak".




Change encryption strength with AdminManager


1. Launch AdminManager and select (by highlighting) a desired printer from the printer list.




2. Press the "Oki Device Setup" button, or alternately select "Setup" → "Oki Device Setup", and open the setup screen.




3. Input the administrator password and open the setup screen as an administrator.




4. Select the "SSL/TLS" tab.



5. Check the "Encryption Strength".




6. Set the "Encryption Strength" to "Weak" and press the "Apply" button.




7. Check the setup contents, and press "OK".



8. A message prompting your confirmation will be displayed. Click "Yes".
(NIC reboots in order to reflect the setup value.)



9. If the printer is displayed in the printer list, the setup is complete with success.




Solution: Set the encryption strength to "Weak".

How to change encryption strength with Telnet

Note! Telnet cannot be used if it remains in the default setting. To change the encryption strength, Telnet must be set to Enable.


Select the command prompt (DOS prompt) and enter "Telnet <printer IP address>", and press Return.

Establish connected using administrator user name and password



```
Telnet 169.254.74.39
Please select (1 - 99): 4
No.  M E N U (level,2)
-----
1 : Protocol ON/OFF
2 : Protocol Port
3 : IP Filtering
4 : MAC Address Filtering
5 : Cipher(SSL/TLS)
6 : Password
99 : Back to prior menu
Please select (1 - 99): 5
No.  M E N U (level,3)
-----
1 : Cipher(SSL/TLS)           : OFF
2 : Cipher Strength          : Standard
99 : Back to prior menu
Please select (1 - 99): 2
Cipher Strength
1 : Strong
2 : Standard
3 : Weak
Please select (1 - 3):
```

Select the menus in this order: [4: Security Config] → [5: Cipher (SSL/TLS)] → [2: Cipher Strength]. Then, change the cipher strength as desired (1: Strong, 2: Standard, 3: Weak).



```
Telnet 169.254.74.39
Please select (1 - 99): 4
No.  M E N U (level,2)
-----
1 : Protocol ON/OFF
2 : Protocol Port
3 : IP Filtering
4 : MAC Address Filtering
5 : Cipher(SSL/TLS)
6 : Password
99 : Back to prior menu
Please select (1 - 99): 5
No.  M E N U (level,3)
-----
1 : Cipher(SSL/TLS)           : OFF
2 : Cipher Strength          : Standard
99 : Back to prior menu
Please select (1 - 99): 2
Cipher Strength
1 : Strong
2 : Standard
3 : Weak
Please select (1 - 3):
```

7.5.4.2 Print operation is not possible

If print operation is not possible by using the encrypted IPP printer, check the followings.

Establish connection by "https://<printer IP address>".

- 1) If the printer setting page is displayed, the followings are probable.
Take an appropriate measure by referring to the following items.
 - * Certificate is not created yet. (Or failed to create certificate.)
→ Refer to section "7.5.4.1.1 Is the certificate created?".
 - * Certificate has been created but the SSL/TLS setting is turned off.
→ Refer to section "7.5.4.1.2 Is the SSL/TLS setting set to [ON]?".
- 2) If the printer setting page is not displayed, the followings are probable.
Take an appropriate measure by referring to the following items.
 - * Version number of the browser is old.
→ Refer to section "7.5.4.1.3 Check version number of the Web browser".
 - * Encryption strength has been set to Strong.
→ Refer to section "7.5.4.1.4 Check encryption strength of a printer".
 - * The key exchange system of a printer is not supported by the browser. (Compatibility problem)
 - * The OS does not support the IPP (encrypted) printing.
→ Refer to section "7.5.4.2.1 Check OS (Operating System)".
 - * IPP (encrypted) printer is not created yet.
→ Refer to section "7.5.4.2.2 Is the Printer created?".
 - * IPP setup of the Printer is not Enabled.
→ Refer to section "7.5.4.2.3 Is the IPP setting set to Enabled?".

7.5.4.2.1 Check OS (Operating System)

The IPP print (encryption) function is supported by Windows 2000, Windows XP, Windows 2003 Server and Windows Vista only.

It is not supported by other operating systems.

7.5.4.2.2 Is the Printer created?

Printer may not be created normally.

To use the IPP print (encryption) function, the Printer must have been created by setting port to URL" [HYPERLINK "https://< printer IP address>/ipp"](https://< printer IP address>/ipp) when creating the Printer.

For more details of Printer creation method, refer to the User's Manual (Advanced edition).

7.5.4.2.3 Is the IPP setup Enabled?

The IPP setup may not be set to Enable.

As the default setting of printer, IPP has been set to Disable.

To use the IPP print (encryption) function, the IPP setup must have been set to Enable.

For the method of changing the IPP setup, refer to the User's Manual (Advanced edition).

7.5.4.3 Cannot create Certificate

When Certificate cannot be created, the following causes are probable. Take an appropriate measure by referring to the following items.

- * Required input items are not fully entered
 - Refer to section "7.5.4.3.1 Required input items are not fully entered".
- * The printer is printing.
 - Refer to section "7.5.4.3.2 The printer is printing".

7.5.4.3.1 Required input items are not fully entered

Unless all of the required input items are fully entered, Certificate cannot be created.

When creating Certificate, entry into the items of Common Name, Organization, Locality, State/Province, Country/Region is the must item. (Entry into Organizational Unit can be omitted.)

Solution : Enter the appropriate value into all of the required input items, and execute creation of Certificate.

For more details of the input items, refer to the User's Manual (Advanced edition).

7.5.4.3.2 The printer is printing.

Certificate cannot be created while printing is in progress. (Print operation has priority.)

Solution: Create Certificate when all other operations are complete.

During creation of self-sign certification, during creation of CSR for Certificate of certifying authority, and during installation of Certificate, the printer must not perform any other operations (such as printing) until the operation is complete (creation of self-sign certification is complete, creation of CSR is complete, and installation of Certificate is complete).

7.5.4.4 Installation of Certificate is not possible

When installation of Certificate fails, the following causes are probable.

Take an appropriate measure by referring to the following items.

- * User has changed the IP address of a printer to other IP address than the "IP address during creation of CSR".
 - Refer to section "7.5.4.4.1 IP address of the printer has been changed".
- * "Network card is initialized" while user is applying issuance of certification to certifying authority (i.e., in the state of Waiting for Installation of Certificate).
 - Refer to section "7.5.4.4.2 "Network card is initialized".
- * "Deletion of CSR" was executed while user is applying issuance of certification to certifying authority (i.e., in the state of Waiting for Installation of Certificate).
 - Refer to section "7.5.4.4.3 "Deletion of CSR" is executed.
- * Intermediate Certificate is installed.
 - Refer to section "7.5.4.4.4 "Installation of intermediate Certificate" is desired.

7.5.4.4.1 User has changed the IP address of a printer

If IP address of a printer is changed to other IP address than the "IP address during creation of CSR", error is issued and installation of Certificate become impossible.

If the changed setup is only the "IP address of printer", error will not be issued if the IP address is returned to the original address.

Solution: Return the IP address of printer back to the "IP address during creation of CSR", and then install Certificate.

Note! Do not change any setup of printer while creation of Certificate of certifying authority is in progress (during the period starting from creation of CSR up until installation of Certificate). If changed, the already issued Certificates become invalid necessitating re-setup starting from the very beginning. If printer setup is changed after Certificate is obtained, the "Security warning" is displayed on the web browser.

If IP address of printer is changed, the Certificate becomes invalid. In the case of Certificate of certifying authority requiring some charge for issuance, another charge may be required for creating Certificate once again. For details, contact certifying authority.)

7.5.4.4.2 "Network card is initialized"

If network card is initialized (to default setup) while creation of Certificate of certifying authority is in progress (during the period starting from creation of CSR up until installation of Certificate), the setup information of the Certificate is deleted. If information is deleted once, the information cannot be recovered by any means. (Even when the same information as before is entered, the same Certificate cannot be created.)

Solution : Repeat all the steps from the very beginning. (Certificate under application is already invalid.)

7.5.4.4.3 "CSR is deleted"

If CSR is deleted (if Certificate is deleted) while creation of Certificate of certifying authority is in progress (during the period starting from creation of CSR up until installation of Certificate), the setup information of the Certificate is deleted. If information is deleted once, the information cannot be recovered by any means. (Even when the same information as before is entered, the same Certificate cannot be created.)

Solution : Repeat all the steps from the very beginning. (Certificate under application is already invalid.)

7.5.4.4.4 Installation of intermediate Certificate is desired

Some certification authorities use the procedure of installing the SSL server Certificate (printer Certificate) and the intermediate Certificate into printer as the same time.

However, printer of this model supports installation of only a single Certificate, intermediate Certificate cannot be installed in printer. Be sure to install the SSL server Certificate in printer.

When installation of intermediate Certificate is required, install the intermediate Certificate not in printer, but in client PC (browser).

For the method of installing the intermediate Certificate in client PC (browser), refer to the following.


Installing the intermediate Certificate (or CA certificate) in client PC (browser).

[Procedure]



1. Double-click the intermediate Certificate (or CA certificate) that is issued by certifying authority, on a client PC to display the intermediate Certificate (or CA certificate).
 - ex.) For an example, the intermediate Certificate of Comodo has the text (PEM) format: ComodoJapanCA.Crt, and the binary format: ComodoJapanCA.cer. Either one of these formats can be opened. (Same result can be obtained.)

Open either ComodoJapanCA.crt or ComodoJapanCA.cer.

2. Press the "General" tab of the displayed Certificate information, and press "Install Certificate" button.



3. The "Certificate Import Wizard" is displayed. Install Certificate in accordance with the displayed procedure. Select "Automatically select the certificate store based on the types of certificate". Then, the Certificate will be installed automatically.



7.5.4.5 Other questionnaires

Other probable questionnaires are described below.

7.5.4.5.1 Time required for creation of Certificate

It takes several ten seconds for creation of Certificate.

7.5.4.5.2 Communication time when the encryption function is enabled

A time longer than the ordinary communication time is required for communication when the encryption function is used.

7.5.4.5.3 Can the encrypted printing be performed by any printer other than IPP?

Answer : Any printer other than IPP cannot encrypt printing.
Only the IPP printing can encrypt printing.

7.5.4.5.4 What will happen if SSL/TLS is turned OFF after Certificate has been created (or installed)?

Answer : Certificate will be kept saved as it is.
If SSL/TLS is turned ON again, the Certificate becomes usable.

7.5.4.5.5 Want to change the port number

Answer : The port number during the SSL/TLS communication is fixed to 443.
It cannot be changed.

7.5.4.5.6 The error message "The security certificate was issued by a company you have not chosen to trust. View the certificate to determine whether you want to trust the certifying authority" is displayed.

If this error is indicated, it means that the certificate which is installed in a printer is self-sign certificate.

In the case of self-sign certificate, error (security warning) will not be displayed if the self-sign certificate of printer is installed in the client PC.

In the case of certificate of certifying authority, error (security warning) will not be displayed if the CA certificate of certifying authority is installed in the client PC.


Solution : Install certificate in the client PC (browser).

[Procedure]


1. Click the "View Certificate" button on the error (security warning) screen.



- Press the "General" tab of the displayed Certificate information, and press "Install Certificate" button.



- The "Certificate Import Wizard" is displayed. Install Certificate in accordance with the displayed procedure. Select "Automatically select the certificate store based on the types of certificate". Then, the Certificate will be installed automatically.



7.5.4.5.7 The error message "Name of security certificate is invalid or does not match the site name" is displayed.

It means that the IP address of printer is different from the IP address that is described on certificate, or from the IP address when the certificate is created.


Solution : Return the IP address of printer back to the address when self-sign certificate is created, or to the address when CSR is created.

7.5.4.6 Restrictions when using Internet Explore 7

Several restrictions are imposed when using Internet Explore 7. This is because security restriction became more severe in IE7.

7.5.4.6.1 Warning indication when SSL is made valid by self-sign certificate

When SSL is made valid by self-sign certificate, the following picture is obtained when web page is accessed, and page will not be displayed.



Web display when SSL is made valid by self-sign certificate

Solution : When "Continue browsing this site (not recommended)" is clicked on the warning screen, the web page will be displayed.

However, it has no effect on the web page function. It can be used for browsing or to change setting of printer setup.



Web page display when "Continue browsing this site (not recommended)" is clicked.

7.6 Fuse check

If the following error is issued, check the corresponding fuse of the CU control board, PU control board and high voltage power supply board.

(Refer to Table 7-6.)

Table 7-6 Fuse error

| Fuse Name | Error Description | Insert Point | Resistance |
|---------------------------------|-------------------|---|--|
| PU board | F1 | Service call 918 (However, if the Duplex unit is not installed, it is the 2nd/3rd hopping error.) | Duplex, 2nd/3rd 24V |
| | F2 | Power supply shut-down | PU board 5V |
| | F3 | ID UP/DOWN error. Service call 142 | Belt motor, ID UP/DOWN motor 24V |
| | F4 | Cover open | High voltage power supply board, ID cooling fan, fuser fan 24V |
| | F5 | Service call 122 | Power supply fan, feed solenoid, feed motor 24V |
| High voltage power supply board | IP901 | Cover open | High voltage 24V |
| | IP902 | Service call 121 | High voltage 5V |
| CU board | F506 | <ul style="list-style-type: none"> Service call 131 to 134 error All white page print | LED HEAD 5V |
| | F505 | Service call 131 to 134 error | LED HEAD 3.3V |
| | F501 | HDD error | HDD 5V |
| | F503 | CENTRONIX interface error | CENTRONIX interface 5V |
| | F502 | CENTRONIX interface error | CENTRONIX interface 3.3V |
| | F507 | Host USB error | PCI 5V |

Less than
1 ohm

7.7 Paper cassette switches versus Paper size correspondence table

| Dial display size | Bit No. | | | |
|-------------------|---------|---|---|---|
| | 1 | 2 | 3 | 4 |
| TRAY1~3 | 1 | 2 | 3 | 4 |
| Cassette: none | H | H | H | H |
| Legal 14" | H | L | H | L |
| Legal 13.5" | H | L | H | H |
| Legal 13" | L | L | L | H |
| Letter | L | L | L | L |
| Executive | L | L | H | L |
| Blank | L | L | L | L |
| Blank | H | H | L | L |
| A4 | L | H | L | L |
| B5 | L | H | H | L |
| A5 | H | H | H | L |
| Not used | L | L | H | H |
| Not used | L | H | L | H |
| Not used | H | H | L | H |
| Not used | H | L | L | H |
| Not used | L | H | H | H |
| Not used | H | L | L | L |

* When switch is pressed: Low

7.8 Data protection kit-A1

7.8.1 Data protection kit-A1 (DPK-A1) overview


Purpose:

By encrypting data to be stored in HDD, data is protected from eavesdropping even when HDD is stolen.

Method:

The conversion board in which encryption chip is installed is inserted in between the CU board and HDD.

Connected chart:



Assembled state of Data protection kit-A1

Shape of metal plate is different from HDD unit of C5900. Thickness and others are different.


HDD in which board is installed

<Top panel>



Connector for connecting HDD

<Rear panel>



Connector to which CU is going to be connected

Sealed encryption chip

Connector for connecting HDD

Specification for safety:

- If the data protection kit-A1 is removed from printer or swapped by others, it is informed to user as a warning. (Error processing)
- Program download and EEPROM read-out are prohibited so that the data protection kit-A1 works safely.
Consequently, restrictions that have not been applied are newly added after the data protection kit-A1 is installed in C710dn.
- Normal operation can be performed when the CU board including EEPROM and the data protection kit-A1 are installed as a pair. (Combination with the PU board and with engine is not restricted.)

Normal configuration (HDD is not used. Normal HDD is installed)

| | |
|-------------------------------------|--|
| When the CU board becomes faulty: | Replace the CU board (User's EEPROM should be used.) |
| When the normal HDD becomes faulty: | Replace the HDD only. |

After the data protection kit-A1 is installed

| | |
|---|--|
| When the CU board becomes faulty: | Replace the CU board (EEPROM of the maintenance board should be used.) |
| | Replacement of the data protection kit-A1 is not required, but internal data are deleted. |
| When the data protection kit-A1 became fault: | Replace both of the data protection kit-A1 and the CU board. (EEPROM of the maintenance board should be used.) |

- After the data protection kit-A1 is installed, the CU board is linked to a specific HDD. Therefore, the printer cannot be used without the specific HDD> As the CC authentication condition, the link can be cancelled by the Takasaki Design Department only.
- After the data protection kit-A1 is installed, some of the PjL functions cannot be used.
 - Downloading of all of the F/W (including NIC F/W and PU F/W)
 - Read and write of the EEPROM (CU and PU)

Upgrading of PU F/W and read/write of PU EEPROM after the data protection kit-A1 is installed:

Replace the CU board once with the new CU board in which the data protection kit-A1 has not been installed before.

Upgrading of CU F/W

Replace the CU board with new CU board in which the CU F/W is already upgraded. Data in the data protection kit-A1 will be deleted.

Error processing flow when the error 001-073, -254 has occurred (CU board related error)

| | | | |
|--------|--|-------|---|
| Step 1 | Does the printer work normally when the CU board is replaced by the maintenance CU board ①? (Be sure to use EEPROM of the maintenance board. Note 1) (Do not install the data protection kit-A1) ↓ Yes | → No | (Analysis is not possible.) Replace the printer. |
| Step 2 | Does the printer start up normally when the user's data protection kit-A1 is installed? ↓ No | → Yes | Maintenance is complete. (CU board failure) Re-setting of IP address and others are required: Note 1 and Note 4 |
| Step 3 | Does the printer start up normally when the data protection kit-A1 ① of maintenance use is installed? ↓ No (Error 253 occurs) Note 2 | → Yes | Maintenance is complete. (CU board failure, and data protection kit-A1 failure) Re-setting of IP address and others are required: Note 1, 3 and 4 |
| Step 4 | Does the printer work normally when the maintenance CU board ② and the data protection kit-A1 ① for maintenance use are installed instead of original boards? No. Replace the printer. (Analysis is not possible.) ↓ No Replace the printer. (Analysis is not possible.) | → Yes | Maintenance is complete. (CU board failure, and data protection kit-A1 failure) Re-setting of IP address and others are required: Note 1, 3 and 4 |

Note1 : When EEPROM of user's board is used, error 253 (HDD unmatched) occurs. Re-set the user environment such as IP address by using the EEPROM of maintenance board.

Note2 : If a part of the functions of the data protection kit-A1 that user is using became faulty, the system can be recovered by using Step 3 if user's data protection kit-A1 is completely faulty because there is no restriction on combination in this case. If Step 2 is used, there is a restriction in combination of the maintenance CU board and user's data protection kit-A1. Therefore, if different HDD is connected afterwards, error 253 will be issued.

Note3 : Data protection kit A1 after replacing should be collected by either of the following methods

1. Disassemble the kit, and deliver only HDD storing user secret data to a user.
2. Take any measures to prevent information leak.

Note4 : When the CU board is replaced, the printer cannot be used without the specified HDD because the user's CU board has been linked to the specific HDD. Until the link is cancelled by design department, it cannot be used. (Situation should be reported to design department.)

Error processing flow when error 252, 253, 256 has occurred (HDD related error -①)

| Error display | Error contents |
|---------------|---|
| Error 252 | Data protection kit-A1 does not exist. |
| Error 253 | User's data protection kit-A1 does not exist, but different data protection kit-A1 is installed with the HDD. |
| Error 256 | Invalid HDD is installed. |

| | | | |
|--------|---|----------|--|
| Step 1 | Re-connect the printer to the user's data protection kit-A1 that is connected to the printer in the very beginning when user starts using the system. ↓ No (If user's data protection kit-A1 that is connected in the very beginning does not exist) | → Yes | Maintenance is complete. (User HDD has been removed.) |
| Step 2 | Does the printer work normally when the maintenance CU board and the data protection kit-A1 for maintenance use are installed instead of original boards? ↓ No | → Yes | Maintenance is complete. (User HDD has been removed.) Re-setting of IP address and others are required: Note 1, 3 and 4 |
| Step 3 | Replace the printer. (Analysis is not possible.) | | |

Note1 : When EEPROM of user's board is used, error 253 (HDD unmatched) occurs.
Re-set the user environment such as IP address by using the EEPROM of maintenance board.

Note3 : Data protection kit A1 after replacing should be collected by either of the following methods
1. Disassemble the kit, and deliver only HDD storing user secret data to a user.
2. Take any measures to prevent information leak.

Note4 : When the CU board is replaced, the printer cannot be used without the specified HDD because the user's CU board has been linked to the specific HDD.

Error processing flow when error 251, 253 has occurred (HDD related error -②)

| Error display | Error contents |
|---------------|--------------------------|
| Error 251 | HDD hardware failure ① |
| Error 255 | HDD kit hardware failure |

| | | | |
|--------|--|----------|---|
| Step 1 | Does the printer work normally when the maintenance CU board ① and the data protection kit-A1② for maintenance use are installed instead of original boards? ↓ No | → Yes | Maintenance is complete. (HDD failure) Re-setting of IP address and others are required: Note 1, 3 and 4 |
| Step 2 | Replace the printer. (Analysis is not possible.) | | |

Note1 : When EEPROM of user's board is used, error 253 (HDD unmatched) occurs.
Re-set the user environment such as IP address by using the EEPROM of maintenance board.

Note3 : Data protection kit A1 after replacing should be collected by either of the following methods
1. Disassemble the kit, and deliver only HDD storing user secret data to a user.
2. Take any measures to prevent information leak.

Note4 : When the CU board is replaced, the printer cannot be used without the specified HDD because the user's CU board has been linked to the specific HDD.

Error processing flow when error 250, 257 has occurred (HDD related error -③)

| Error display | Error contents |
|---------------|-------------------------------------|
| Error 250 | HDD data damage or hardware failure |
| Error 257 | HDD data damage or hardware failure |

| | | | |
|--------|--|----------|---|
| Step 1 | 250: Does the printer start up normally when the Admin menu – Disk erase is executed? 257: Does the printer start up normally when the Admin menu – Check Disk is executed? ↓ No (If user's data protection kit-A1 that is connected in the very beginning does not exist) | → Yes | Maintenance is complete. (Data stored in HDD is partly damaged.) |
| Step 2 | Does the printer work normally when the maintenance CU board ① and the data protection kit-A1 ① for maintenance use are installed instead of original boards? ↓ No | → Yes | Maintenance is complete. (HDD failure) Re-setting of IP address and others are required: Note 1, 3 and 4 |
| Step 3 | Replace the printer. (Analysis is not possible.) | | |

Note1 : When EEPROM of user's board is used, error 253 (HDD unmatched) occurs.
Re-set the user environment such as IP address by using the EEPROM of maintenance board.

Note3 : Data protection kit A1 after replacing should be collected by either of the following methods

1. Disassemble the kit, and deliver only HDD storing user secret data to a user.
2. Take any measures to prevent information leak.

Note4 : When the CU board is replaced, the printer cannot be used without the specified HDD because the user's CU board has been linked to the specific HDD.

If the printer does not start up normally while showing communication error and LCD does not show any display.





| | | | |
|--------|---|----------|---|
| Step 1 | Perform processing in accordance with the usual M/M. ↓ If the trouble cannot be solved. | | |
| Step 2 | Does the error 252 occur when the user's protection kit-A1 is removed? ↓ Yes (Data protection kit-A1 is partly damaged so that printer does not start up normally.) | → No | Implement the error 001-073.254 sheet processing. |
| Step 3 | Can the user's data protection kit-A1 be connected and can the Admin menu be started up? ↓ Yes (Data protection kit-A1 is partly damaged so that printer does not start up normally.) | → No | Implement the error 001-073.254 sheet processing. |
| Step 4 | Does the printer recover by executing the Admin menu – Check all sector? ↓ No | → Yes | Maintenance is complete. (Data stored in HDD is partly damaged.) |
| Step 5 | Does the printer recover by executing the Admin menu – HDD Format? Note 1 ↓ No Implement the error 001-073.254 sheet processing. | → Yes | Maintenance is complete. (Data stored in HDD is partly damaged.) |







Note1 : The Admin menu "HDD INITIALIZE" is not displayed unless the Admin menu "INITIAL LOCK" is set to "NO". (Default setting is "YES".)







8. Connection diagrams



| | |
|---------------------------------|-----|
| 8.1 Resistance value check..... | 206 |
| 8.2 Parts location..... | 210 |
| 8.3 F/W version number | 221 |

8.1 Resistance value check

| Unit | Electrical circuit diagram, connection | Part outside view | Resistance value |
|-----------------------------|--|--|--|
| <p>Transport belt motor</p> |  |  | <p>Between pin-1 and pin-2: 3.4Ω Between pin-3 and pin-4: 3.4Ω</p> |
| <p>ID motor</p> |  |  | <p>Across both ends of F1: 1Ω or less</p> |

| Unit | Electrical circuit diagram, connection | Part outside view | Resistance value |
|------------------|---|---|--|
| ID up/down motor |  |  | <p>Between pin-1 and pin-2: 6.1Ω Between pin-3 and pin-4: 6.1Ω</p> |
| Fuser unit motor |  |  | <p>Across both ends of IP1: 1Ω or less</p> |
| |  |  | |


| Unit | Electrical circuit diagram, connection | Part outside view | Resistance value |
|---------------------------|---|---|---|
| Feed motor |  |  | <p>Between pin-1 and pin-2: 3.4Ω Between pin-3 and pin-4: 3.4Ω</p> |
| Both-sided print motor |  |  | <p>Between pin-1 and pin-2: 2.4Ω Between pin-3 and pin-4: 2.4Ω</p> |
| 2nd / 3rd tray feed motor |  |  | <p>Between pin-1 and pin-2: 3.4Ω Between pin-3 and pin-4: 3.4Ω</p> |


| Unit | Electrical circuit diagram, connection | Part outside view | Resistance value |
|------------|--|---|--|
| Fuser unit |  |  | <p>Between pins Ⓐ-1 and Ⓐ-6: Several ohms to several ten ohms Between pins Ⓑ-1 and Ⓑ-6: Several ohms to several ten ohms Between pins Ⓑ-4 and Ⓑ-5: Approx. 590kΩ to 5338kΩ (0 to 93°C) Between pins Ⓐ-2 and Ⓐ-3: Approx. 104.5kΩ to 806.5kΩ (0 to 43°C) Between pins Ⓑ-2 and Ⓑ-3: Approx. 104.5kΩ to 806.5kΩ (0 to 43°C) Between pins Ⓐ-4 and Ⓐ-5: Open</p> |

8.2 Parts location

(1) Print Engine Controller PCB (PU PCB)


Component side






(3) Host USB PCB(TBI PCB)

Component side




Soldering side




(4) Relay PCB

Component side




Soldering side




(7) Second Tray Control PCB


Component side




Soldering side




(8) Control Panel PCB




(9) Toner Low Sensor PCB



(10) Entrance Sensor PCB




(11) Color Adjustment Sensor PCB




(12) High-Voltage Power Supply PCB

C710dn





(13) Low-Voltage Power Supply PCB




Note: 100V system shorting plug is mounted. 230V system shorting plug is not mounted.

(14) ID unit



(15) Transfer belt unit



8.3 F/W version number


8.3.1 ROM control number

| ROM nameplate version number fill-out version | Date | CU F/W 43965201FY01 | | NIC F/W 43965201FY02 | | | Loader 43436808FY01 * | | Remarks |
|---|------------|---------------------|-----------|----------------------|----------|-----------|-----------------------|-----------|---------|
| | | Rev. | File Rev. | NIC F/W | Web Page | File Rev. | Rev. | File Rev. | |
| 1 | 2007.11.12 | A0.14 | 1 | b0.61 | 0.07 | 1 | 1.00 | 1 | β2 |
| 2 | 2007.12.21 | A1.00 | 2 | 08.A1 | W8.A1 | 2 | 1.00 | 1 | - |
| 3 | 2008.01.15 | A1.02 | 3 | 0.8A1 | W8.A1 | 2 | 1.00 | 1 | PSU~ |
| | | | | | | | | | |
| | | | | | | | | | |


* Loader cannot be rewritten.

8.3.2 ROM version check and display

- (1) Perform the menu map printing and confirm that the F/W version number has been upgraded.
- (2) Fill out the ROM label that is attached to the location shown below in accordance with the downloaded F/W version number.




Revision number label details



8.3.3 PCB Maintenance Indication Stamp

The specified article numbers are stamped in the PCB Maintenance Indication column on the CU PCB in accordance with the table shown below.



| Article number | Seal | Board TB2(YU) Series No. | Use |
|----------------|------|-----------------------------|--------------|
| 43793721 | 21 | TB2-3 (43778803) | ODA PX741 |
| 43793723 | 23 | TB2-3 (43778803) | OEL PX741 |
| 43793724 | 24 | TB2-3 (43778803) | AOS PX741 |
| 43793725 | 25 | TB2-3 (43778803) | Japan PX741 |
| 43793726 | 26 | TB2-3 (43778803) | TAIWAN PX741 |
| 43793727 | 27 | TB2-3 (43778803) | KOREA PX741 |