

MP 6503SP/MP 7503SP/MP 9003SP
Machine Code: D223/D224/D225

Field Service Manual

May, 2016

Important Safety Notices

Warnings, Cautions, Notes

In this manual, the following important symbols and notations are used.

WARNING

- Indicates a potentially hazardous situation. Failure to obey a Warning could result in death or serious injury.

CAUTION

- Indicates a potentially hazardous situation. Failure to obey a Caution could result in minor or moderate injury or damage to the machine or other property.

Important

- **Obey these guidelines to avoid problems such as misfeeds, damage to originals, loss of valuable data and to prevent damage to the machine.**

Note

- This information provides tips and advice about how to best service the machine.

General Safety Instructions

For your safety, please read this manual carefully before you use this product. Keep this manual handy for future reference.

Safety Information

Always obey the following safety precautions when using this product.

Switches and Symbols

Where symbols are used on or near switches on machines for Europe and other areas, the meaning of each symbol conforms with IEC60417.

Responsibilities of the Customer Engineer

Customer Engineer

Maintenance shall be done only by trained customer engineers who have completed service training for the machine and all optional devices designed for use with the machine.




Reference Material for Maintenance

- Maintenance shall be done using the special tools and procedures prescribed for maintenance of the machine described in the reference materials (service manuals, technical bulletins, operating instructions, and safety guidelines for customer engineers).
- In regard to other safety issues not described in this document, all customer engineers shall strictly obey procedures and recommendations described in the "CE Safety Guide".
- Use only consumable supplies and replacement parts designed for use with the machine.

Before Installation, Maintenance

Warning Label

The following symbols are used in warning labels attached inside the machine. Understand the symbols on these labels, and obey their instructions.

Label			
Description	Use Caution!	High temperature!	Do not touch!

Shipping and Moving the Machine

CAUTION

- Work carefully when lifting or moving the machine.
- If the machine is heavy, two or more customer engineers may be required to prevent injuries (muscle strains, spinal injuries, etc.) or damage to the machine if it is dropped or tipped over.
- Personnel moving or working around the machine should always wear proper clothing and footwear.
- Never wear loose fitting clothing or accessories (neckties, loose sweaters, bracelets, etc.) or casual footwear (slippers, sandals, etc.) when lifting or moving the machine.
- Always unplug the power cord from the power source before you move the machine.
- Before you move the machine, or one of its peripheral units, stow the power cord so it will not fall under the machine.

Power

WARNING

- Always disconnect the power plug before doing any maintenance procedure. After switching off the machine, power is still supplied to the main machine and other devices.
- To prevent electrical shock, switch the machine off, wait for a few seconds, then unplug the machine from the power source.
- Before you do any checks or adjustments after turning the machine off, work carefully to avoid injury.
- After removing covers or opening the machine to do checks or adjustments, never touch electrical components or moving parts (gears, timing belts, etc.).
- After turning the machine on with any cover removed, keep your hands away from electrical components and moving parts. Never touch the cover of the fusing unit, gears, timing belts, etc.

Important

- **The work area where the machine is installed must have the required breaker switch for the power line. (North America: Listed circuit breaker, rating 240V 20A, double pole)**

Installation, Disassembly, and Adjustments

CAUTION

- After installation, maintenance, or adjustment, always check the operation of the machine to make sure that it is operating normally. This ensures that all shipping materials, protective materials, wires and tags, metal brackets, etc., removed for installation, have been removed and that no tools remain inside the machine. This also ensures that all release interlock switches have been restored to normal operation.
- Never use your fingers to check moving parts causing spurious noise. Never use your fingers to lubricate moving parts while the machine is operating.

Special Tools

CAUTION

- Use only standard tools approved for machine maintenance.
- For special adjustments, use only the special tools and lubricants described in the service manual. Using tools incorrectly, or using tools that could damage parts, could damage the machine or cause injuries.

During Maintenance

General

CAUTION

- Before you begin a maintenance procedure: 1) Switch the machine off, 2) Disconnect the power plug from the power source, 3) Allow the machine to cool for at least 10 minutes.
- Avoid touching the components inside the machine that are labeled as hot surfaces.

Safety Devices

WARNING

- Never remove any safety device unless it requires replacement. Always replace safety devices immediately.
- Never do any procedure that defeats the function of any safety device. Modification or removal of a safety device (fuses, switches, etc.) could lead to a fire and personal injury. Always test the operation of the machine to ensure that it is operating normally and safely after removal and replacement of any safety device.
- For replacements use only the correct fuses or circuit breakers rated for use with the machine. Using replacement devices not designed for use with the machine could lead to a fire and personal injuries.

Organic Cleaners

CAUTION

- During preventive maintenance, never use any organic cleaners (alcohol, etc.) other than those described in the service manual.
- Make sure the room is well ventilated before using any organic cleaner. Use organic solvents in small amounts to avoid breathing the fumes and becoming nauseous.
- Switch the machine off, unplug it, and allow it to cool before doing preventive maintenance. To avoid fire or explosion, never use an organic cleaner near any part that generates heat.
- Wash your hands thoroughly after cleaning parts with an organic cleaner to prevent contamination of food, drinks, etc. which could cause illness.
- Clean the floor completely after accidental spillage of silicone oil or other materials to prevent slippery surfaces that could cause accidents leading to hand or leg injuries. Use "My Ace" Silicone Oil Remover (or dry rags) to soak up spills.

Lithium Batteries

WARNING

- Always replace a lithium battery on a PCB with the same type of battery prescribed for use on that board. Replacing a lithium battery with any type other than the one prescribed for use on the board could lead to an explosion or damage to the PCB.
- Never discard used batteries by mixing them with other trash. Remove them from the work site and dispose of them in accordance with local laws and regulations regarding the disposal of such items.

Ozone Filters

CAUTION

- Always replace ozone filters as soon as their service life expires (as described in the service manual).
- An excessive amount of ozone can build up around machines that use ozone filters if they are not replaced at the prescribed time. Excessive ozone could cause personnel working around the machine to feel unwell.
- To avoid possible accumulation of ozone in the work area, locate the machine in a large well ventilated room that has an air turnover rate of more than 50 m³/hr/person.

Power Plug and Power Cord

WARNING

- Before servicing the machine (especially when responding to a service call), always make sure that the power plug has been inserted completely into the power source. A partially inserted plug could lead to heat generation (due to a power surge caused by high resistance) and cause a fire or other problems.
- Always check the power plug and make sure that it is free of dust and lint. Clean it if necessary. A dirty plug can generate heat which could cause a fire.
- Inspect the length of the power cord for cuts or other damage. Replace the power cord if necessary. A frayed or otherwise damaged power cord can cause a short circuit which could lead to a fire or personal injury from electrical shock.
- Check the length of the power cord between the machine and power supply. Make sure the power cord is not coiled or wrapped around any object such as a table leg. Coiling the power cord can cause excessive heat to build up and could cause a fire.
- Make sure that the area around the power source is free of obstacles so the power cord can be removed quickly in case of an emergency.

-
- Make sure that the power cord is grounded (earthed) at the power source with the ground wire on the plug.
 - Connect the power cord directly into the power source. Never use an extension cord.
 - When you disconnect the power plug from the power source, always pull on the plug, not the cable.

After Installation, Servicing

Disposal of Used Items

WARNING

- Never incinerate used toner, toner cartridges, or toner bottles.
- Toner, toner cartridges, or toner bottles thrown into a fire can ignite or explode and cause serious injury. At the work site always carefully wrap used toner and toner cartridges with plastic bags to avoid spillage before disposal or removal.

CAUTION

- Always dispose of used items (developer, toner, toner cartridges, OPC drums, etc.) in accordance with the local laws and regulations regarding the disposal of such items.
- To protect the environment, never dispose of this product or any kind of waste from consumables at a household waste collection point. Dispose of these items at one of our dealers or at an authorized collection site.
- Return used selenium drums to the service center for handling in accordance with company policy regarding the recycling or disposal of such items.

Points to Confirm with Operators

At the end of installation or a service call, instruct the user about use of the machine. Emphasize the following points.

- Show operators how to remove jammed paper and troubleshoot other minor problems by following the procedures described in the operating instructions.
- Point out the parts inside the machine that they should never touch or attempt to remove.
- Confirm that operators know how to store and dispose of consumables.
- Make sure that all operators have access to an operating instruction manual for the machine.
- Confirm that operators have read and understand all the safety instructions described in the operating instructions.
- Demonstrate how to turn the machine off with the power button on the left front corner of the machine. A message alerts the operator that there will be a slight delay until the machine shuts

down. This gives the hard disk time to stop rotating and shut down normally before the machine loses power.

- Demonstrate how to disconnect the power plug quickly (by pulling the plug, not the cord) if any of the following events occur: 1) something has spilled into the product, 2) service or repair of the product is necessary, 3) the product cover has been damaged.
- Caution operators about removing paper fasteners around the machine. They should never allow paper clips, staples, or any other small metallic objects to fall into the machine.

Special Safety Instructions for Toner

Accidental Physical Exposure

CAUTION

- Work carefully when removing paper jams or replacing toner bottles or cartridges to avoid spilling toner on clothing or the hands.
- If toner is inhaled, immediately gargle with large amounts of cold water and move to a well ventilated location. If there are signs of irritation or other problems, seek medical attention.
- If toner gets on the skin, wash immediately with soap and cold running water.
- If toner gets into the eyes, flush the eyes with cold running water or eye wash. If there are signs of irritation or other problems, seek medical attention.
- If toner is swallowed, drink a large amount of cold water to dilute the ingested toner. If there are signs of any problem, seek medical attention.
- If toner spills on clothing, wash the affected area immediately with soap and cold water. Never use hot water! Hot water can cause toner to set and permanently stain fabric.

Handling and Storing Toner

WARNING

- Toner, used toner, and developer are extremely flammable.
- Never store toner, developer, toner cartridges, or toner bottles (including empty toner bottles or cartridges) in a location where they will be exposed to high temperature or an open flame.

CAUTION

- Always store toner and developer supplies such as toner and developer packages, cartridges, and bottles (including used toner and empty bottles and cartridges) out of the reach of children.
- Always store fresh toner supplies or empty bottles or cartridges in a cool, dry location that is not exposed to direct sunlight.

Toner Disposal

WARNING

- Never attempt to incinerate toner, used toner, or empty toner containers (bottles or cartridges). Burning toner can explode and scatter, causing serious burns.
- Always wrap used toner and empty toner bottles and cartridges in plastic bags to avoid spillage. Follow the local laws and regulations regarding the disposal of such items.
- Dispose of used toner and toner cartridges at one of our dealers or at an authorized collection site. Always dispose of used toner cartridges and toner bottles in accordance with the local laws and regulations regarding the disposal of such items.

Safety Instructions for this Machine

Prevention of Physical Injury

1. Before disassembling or assembling parts of the machine and peripherals, make sure that the machine and peripheral power cords are unplugged.
2. The power outlet should be near the machine and easily accessible.
3. Note that some components of the machine and the paper tray unit are supplied with electrical voltage even if the main power switch is turned off.
4. If any adjustment or operation check has to be made with exterior covers off or open while the main switch is turned on, keep hands away from electrified or mechanically driven components.
5. If the [Start] key is pressed before the machine completes the warm-up period (the [Start] key starts blinking red and green), keep hands away from the mechanical and the electrical components as the machine starts making copies as soon as the warm-up period is completed.
6. The inside and the metal parts of the fusing unit become extremely hot while the machine is operating. Be careful to avoid touching those components with your bare hands.
7. To avoid the danger of fire or explosion, keep the machine away from flammable liquids, gases, and aerosols.

Health Safety Conditions

CAUTION

- Never operate the machine without the ozone filters installed.
1. Always replace the ozone filters with the specified types at the proper intervals.
 2. Toner and developer are non-toxic, but if you get either of them in your eyes by accident, it may cause temporary eye discomfort. Try to remove with eye drops or flush with water as first aid. If unsuccessful, get medical attention.

-
3. To avoid possible accumulation of ozone in the work area, locate the machine in a large well ventilated room that has an air turnover rate of more than 50 m³/hr/person.

Observance of Electrical Safety Standards

1. The machine and its peripherals must be installed and maintained by a customer service representative who has completed the training course on those models.
2. The NVRAM on the system control board has a lithium battery which can explode if replaced incorrectly. Replace the NVRAM only with an identical one. The manufacturer recommends replacing the entire NVRAM. Do not recharge or burn this battery. Used NVRAM must be handled in accordance with local regulations.
3. Test the breaker switches on the main machine and all peripheral devices at least once a year.


Safety and Ecological Notes for Disposal

1. Never incinerate toner bottles or used toner. Toner dust may ignite suddenly when exposed to an open flame.
2. Dispose of used toner, developer, and organic photoconductors in accordance with local regulations. (These are non-toxic supplies.)
3. Dispose of replaced parts in accordance with local regulations.
4. When keeping used lithium batteries in order to dispose of them later, do not put more than 100 batteries per sealed box. Storing larger numbers or not sealing them apart may lead to chemical reactions and heat build-up.

CAUTION

- The danger of explosion exists if a battery of this type is incorrectly replaced.
- Replace only with the same or an equivalent type recommended by the manufacturer. Discard used batteries in accordance with the manufacturer's instructions.

Laser Safety



d223c0002





















1. Laser safety labels are attached to the top of the laser unit.
Note: The Center for Devices and Radiological Health (CDRH) prohibits the repair of laser-based optical units in the field.
2. The optical housing unit can only be repaired in a factory or at a location with the requisite equipment.
3. The laser subsystem is replaceable in the field by a qualified Customer Engineer.
4. The laser chassis is not repairable in the field.
5. Customer engineers are therefore directed to return all chassis and laser subsystems to the factory or service depot when replacement of the optical subsystem is required.






WARNING

- Use of controls, or adjustment, or performance of procedures other than those specified in this manual may result in hazardous radiation exposure.
- Turn off the main switch before attempting any of the procedures in the Laser Unit section. Laser beams can seriously damage your eyes.


Symbols and Trademarks

Symbols Used in Text


Symbol	What it means
	Bushing
	C-ring
	Clip
	Connector
	E-ring
	FFC (Flat Film Connector)
	FFC (Flat Film Connector)
	FFC (Flat Film Connector)
	Gear
	Harness clamp
	Harness clamp: metal: fusing unit
	Hook (sensors)
	Screw: binding screw (round flathead)
	Screw: binding screw (shoulder, hex head)
	Screw: black screw (TCRU, fusing unit)
	Screw: blue
	Screw: common silver screw
	Screw: pivot screw
	Screw: tapping, for plastic
	Screw: shoulder screw

Symbol	What it means
	Spring
	Standoff
	Stud screw
	Timing belt
	Washer

The notations "SEF" and "LEF" describe the direction of paper feed. The arrows indicate the direction of paper feed.



In this manual "Main Scan" means "Horizontal" and "Sub Scan" means "Vertical", both relative to the direction of paper feed.



Trademarks

- PCL® is a registered trademark of Hewlett-Packard Company.
- Ethernet® is a registered trademark of Xerox Corporation.
- PowerPC® is a registered trademark of International Business Machines Corporation.

-
- Fiery is a registered trademark of Electronics for Imaging (EFI), Inc.
 - Adobe, Acrobat, Flash, PageMaker, PostScript, PostScript 3, and Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.
 - Firefox and Thunderbird are registered trademarks of the Mozilla Foundation.
 - Google and Chrome™ browser are trademarks of Google Inc.
 - Java is a registered trademark of Oracle and/or its affiliates.
 - JAWS® is a registered trademark of Freedom Scientific, Inc., St. Petersburg, Florida and/or other countries.
 - Linux is a registered trademark of Linus Torvalds.
 - Macintosh, Mac OS, Bonjour, Safari, and TrueType are trademarks of Apple Inc., registered in the U.S. and other countries.
 - Microsoft, Windows, Windows Server, Windows Vista, Internet Explorer, and Outlook are either registered trademarks or trademarks of Microsoft Corp. in the United States and/or other countries.
 - NetWare is a registered trademark of Novell, Inc. in the United States and other countries.
 - IPX, IPX/SPX, and NCP are trademarks of Novell, Inc.
 - "Red Hat" is a registered trademark of Red Hat, Inc.
 - The SD and SD logo are trademarks of SD-3C, LLC.
 - UNIX is a registered trademark of The Open Group.
 - UPnP is a trademark of UPnP Implementers Corporation.



This product includes RSA BSAFER Cryptographic software of EMC Corporation. RSA and BSAFE are registered trademarks or trademarks of EMC Corporation in the United States and other countries.

The proper names of Internet Explorer 8, 9, 10 and 11 are as follows:

- Windows® Internet Explorer® 8
- Windows® Internet Explorer® 9
- Internet Explorer® 10
- Internet Explorer® 11

The proper names of the Windows operating systems are as follows:

- The product names of Windows XP are as follows:

Microsoft® Windows® XP Professional

Microsoft® Windows® XP Home Edition

Microsoft® Windows® XP Professional x64 Edition

- The product names of Windows Vista are as follows:

Microsoft® Windows Vista® Ultimate

Microsoft® Windows Vista® Business

Microsoft® Windows Vista® Home Premium

Microsoft® Windows Vista® Home Basic

Microsoft® Windows Vista® Enterprise

- The product names of Windows 7 are as follows:

Microsoft® Windows® 7 Home Premium

Microsoft® Windows® 7 Professional

Microsoft® Windows® 7 Ultimate

Microsoft® Windows® 7 Enterprise

- The product names of Windows 8 are as follows:

Microsoft® Windows® 8

Microsoft® Windows® 8 Pro

Microsoft® Windows® 8 Enterprise

- The product names of Windows 8.1 are as follows:

Microsoft® Windows® 8.1

Microsoft® Windows® 8.1 Pro

Microsoft® Windows® 8.1 Enterprise

- The product names of Windows Server 2003 are as follows:

Microsoft® Windows Server® 2003 Standard Edition

Microsoft® Windows Server® 2003 Enterprise Edition

- The product names of Windows Server 2003 R2 are as follows:

Microsoft® Windows Server® 2003 R2 Standard Edition

Microsoft® Windows Server® 2003 R2 Enterprise Edition

- The product names of Windows Server 2008 are as follows:

Microsoft® Windows Server® 2008 Standard

Microsoft® Windows Server® 2008 Enterprise

- The product names of Windows Server 2008 R2 are as follows:

Microsoft® Windows Server® 2008 R2 Standard

Microsoft® Windows Server® 2008 R2 Enterprise

- The product names of Windows Server 2012 are as follows:

Microsoft® Windows Server® 2012 Foundation

Microsoft® Windows Server® 2012 Essentials

Microsoft® Windows Server® 2012 Standard

- The product names of Windows Server 2012 R2 are as follows:

Microsoft® Windows Server® 2012 R2 Foundation

Microsoft® Windows Server® 2012 R2 Essentials

Microsoft® Windows Server® 2012 R2 Standard

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights to those marks.

Microsoft product screen shots reprinted with permission from Microsoft Corporation.

TABLE OF CONTENTS

- Important Safety Notices..... 1
 - Warnings, Cautions, Notes..... 1
 - General Safety Instructions..... 1
 - Responsibilities of the Customer Engineer..... 1
 - Customer Engineer..... 1
 - Reference Material for Maintenance..... 2
- Before Installation, Maintenance..... 2
 - Warning Label..... 2
 - Shipping and Moving the Machine..... 2
 - Power..... 3
 - Installation, Disassembly, and Adjustments..... 3
 - Special Tools..... 3
- During Maintenance..... 4
 - General..... 4
 - Safety Devices..... 4
 - Organic Cleaners..... 4
 - Lithium Batteries..... 5
 - Ozone Filters..... 5
 - Power Plug and Power Cord..... 5
- After Installation, Servicing..... 6
 - Disposal of Used Items..... 6
 - Points to Confirm with Operators..... 6
- Special Safety Instructions for Toner..... 7
 - Accidental Physical Exposure..... 7
 - Handling and Storing Toner..... 7
 - Toner Disposal..... 8
- Safety Instructions for this Machine..... 8
 - Prevention of Physical Injury..... 8
 - Health Safety Conditions..... 8
 - Observance of Electrical Safety Standards..... 9
 - Safety and Ecological Notes for Disposal..... 9
 - Laser Safety..... 10
- Symbols and Trademarks 11

Symbols Used in Text.....	11
Trademarks.....	12
1. Product Information	
Machine Configuration.....	49
Component Layout.....	49
Paper Path (With Cover Interposer Tray).....	51
Paper Path (With 9-Bin Mailbox).....	52
Drive Layout.....	53
Machine Codes and Peripherals.....	55
Peripheral Units.....	55
Other Options.....	56
Mainframe Options: External.....	56
Mainframe Options: Internal.....	57
Controller Options: I/F Slots.....	57
Controller Options.....	57
Fax Options.....	58
Specifications.....	59
Guidance for Those Familiar with Predecessor Products.....	60
Differences from Predecessor Products.....	60
General.....	60
Basic Specifications.....	60
Important Changes.....	61
Unit and Option Name and Number Changes.....	76
Main Machine and Peripheral Units.....	76
Mainframe Options: External.....	78
Mainframe Options: Internal.....	78
Controller Options.....	78
Controller Options: I/F Slots.....	78
Controller Options: SD Cards, Built-in.....	79
HDD.....	80
Fax Options.....	80
2. Installation	
Installation Requirements.....	81

Operating Environment.....	81
Machine Level.....	82
Minimum Space Requirements.....	82
Dimensions.....	83
Power Requirements.....	83
Main Machine.....	85
Accessory Check.....	85
Installation Flow.....	86
Installation Procedure.....	87
Remove Tapes and Shipping Materials.....	87
Attach Power Cord to Machine.....	98
Remove Development Unit.....	99
Load Developer.....	104
Re-install Development Unit.....	107
Set Toner Bottle.....	111
Set Tandem Tray for LT or A4 Paper.....	112
Level the Machine.....	123
Attach Cleaning Cloth Holder.....	125
Connect Drum Heater, Tray Heater (Optional).....	126
Load Paper, Attach Decals.....	130
Attach Name Plate.....	131
Initialize Toner and Process Control Settings.....	132
Check Image Quality and Settings.....	133
Checking the copy image with the test chart.....	133
Date/Time Setting and Other SP Settings.....	133
Important Notice on Security Issues.....	134
Overview.....	134
Canceling Password Setup.....	134
Password Setting Procedure.....	135
Auto Remote Firmware Update Settings.....	136
Security Settings.....	141
Moving the Machine.....	141
Transporting the Machine.....	142

Important SP Codes: Installation.....	142
Drum Heater (Option).....	144
Accessories.....	144
Installation.....	144
Install Drum Heater.....	144
Connect the Drum Heater.....	149
Scanner Heater (Option).....	151
Accessories.....	151
Installation.....	151
Install Scanner Heater.....	151
Connect the Scanner Heater.....	155
A3/11"x17" Tray Type 9001 (D482).....	157
Accessory Check.....	157
Installation Procedure.....	157
LCIT RT4040 (D3D6).....	161
Accessory Check.....	161
Installation.....	162
Removing Tape.....	162
Preparing the Main Machine.....	164
Docking the LCIT.....	165
Paper Size Adjust and Setting.....	169
LCIT Heater (Option).....	175
Accessories.....	175
Installation.....	176
8 1/2"x14" Paper Size Tray Type 9002 (B474).....	197
Accessory Check.....	197
Installation Procedure.....	198
Multi-Folding Unit FD4000 (D615).....	202
Accessories.....	202
Installation.....	203
Tapes.....	203
Paper Guide, Sponge Strips.....	204
Ground Plate.....	205

Docking.....	205
Power Cord.....	207
Finishing the Installation.....	208
Proof Tray Auxiliary Plate.....	208
Finisher SR4080 (D610).....	210
Accessory Check.....	210
Installation.....	211
Auxiliary Trays.....	221
Punch Units (B531/A812)	223
Accessory Check.....	223
Installation.....	224
Output Jogger Unit Type 9002B (B513)	230
Accessory Check.....	230
Installation Procedure.....	230
Cover Interposer Tray CI4030 (D3D7).....	233
Accessories.....	233
Installation.....	234
Finisher SR4080 Already Installed?.....	234
Remove Tapes and Retainers.....	238
Prepare the Finisher.....	239
Install Tray.....	243
Attach Corner Plates and Gaskets.....	245
Attach Sponge Strips.....	247
Re-attach Paper Entrance Guide.....	248
Dock the Finisher.....	249
Finishers SR4120/SR4130 (D3CG/D3CH).....	250
Accessory Check.....	250
Installation Procedure.....	251
Tapes and Retainers.....	251
Preparing the Finisher.....	253
Preparing the Main Machine.....	255
Docking the Finisher.....	257
Checking the Installation.....	261

Auxiliary Trays.....	262
Using Auxiliary Trays.....	263
Punch Units (D706).....	267
Accessory Check.....	267
Installation Procedure.....	268
Output Jogger Unit Type M25 (D3CJ).....	291
Accessories.....	291
Installation.....	292
Cover Interposer Tray CI4040 (DC3N).....	304
Accessories.....	304
Installation.....	305
Finisher Already Installed?.....	305
Prepare the Finisher.....	307
Shipping Tapes and Retainers.....	308
Prepare the Main Machine.....	309
Cover Interposer Tray.....	310
Extensions.....	315
Sponge Strip.....	323
Main Machine.....	324
Docking the Finisher.....	326
Finish the Installation.....	328
Mailbox CS4010 (D708).....	329
Accessories.....	329
Installation.....	330
Copy Tray Type 9002 (B756).....	336
Accessories.....	336
Installation.....	337
Tab Sheet Holder Type 9002 (B499).....	339
Accessories.....	339
Installation.....	339
NFC Card Reader Type M19 (D3BS).....	342
Accessories.....	342
Installation.....	343

Card Reader Bracket Type 3352 (D593).....	351
Accessories.....	351
Installation.....	352
Optional Counter Interface Type M12 (B870).....	358
Accessories.....	358
Installation.....	359
Copy Connector Type M25(D3D3).....	361
Accessories.....	361
Installation.....	361
External Keyboard Bracket Type M3 (D3DH).....	363
Accessories.....	363
Installation.....	363
External Keyboard Only.....	363
External Keyboard with Card Reader.....	366
Internal Options.....	374
List of Slots.....	374
Inserting Cards.....	375
IEEE 1284 Interface Board Type M19.....	377
Accessories.....	377
Installation.....	377
IEEE 802.11 a/g/n Interface Unit M19.....	379
Accessories.....	379
Before You Begin.....	379
Installation.....	380
User Tool Settings for Wireless LAN.....	386
SP Mode and UP Mode Settings for IEEE 802.11 a/g Wireless LAN.....	387
File Format Converter Type M19.....	389
Accessory Check.....	389
Installation.....	389
USB Device Server Option Type M19.....	392
Accessories.....	392
Interface Board.....	393
Installation	393

Ethernet Port LEDs.....	397
Notes for Energy Save Mode Setting.....	398
IP Address Setting.....	398
Extended USB Board Type M19.....	401
Accessories.....	401
Installation.....	401
SD Card Options.....	403
Overview.....	403
Options Available on SD Cards.....	403
Inserting SD Cards.....	404
Move Exec: Merging Applications	405
Undo Exec: Unmerging Applications.....	407
Storing Original SD Cards	408
OCR Type M13.....	410
What is Searchable PDF?.....	410
Accessories.....	410
Installation.....	411
Restoration.....	413
When the original SD card exists.....	413
If Original SD Card is Lost.....	413
PostScript3 Unit Type M25.....	415
Accessories.....	415
Installation.....	415
IPDS Unit Type M25.....	418
Accessories.....	418
Installation.....	418
XPS Direct Print Option Type M25 D3D4.....	420
Accessories.....	420
Installation.....	420
Data Overwrite Security Unit Type M19 (D3BS).....	423
Overview.....	423
Component List.....	423
Before You Begin the Procedure.....	423

Seal Check and Removal.....	424
Installation Procedure.....	425
After Installation Check.....	427
Safety Check.....	427
Check List.....	427
Security Setting.....	429
Security Function Installation.....	429
Data Overwrite Security.....	429
Using Auto Erase Memory.....	429
HDD Encryption.....	431
Before You Begin the Procedure:.....	431
Enable Encryption Setting.....	431
Backing Up the Encryption Key.....	433
Encryption Key Restoration.....	434
@Remote Settings.....	437
User Instructions.....	441
Operation Guidance for Users.....	441

3. Preventive Maintenance

PM Tables.....	443
Main Machine.....	443
Scanner Optics.....	443
Around the Drum.....	444
Drum Cleaning.....	445
Development Unit.....	445
Paper Feed: Main Paper Path.....	446
Paper Feed: Paper Trays.....	446
Transfer Belt Unit.....	447
Fusing Unit and Paper Exit.....	448
Fusing Unit Paper Exit.....	449
Duplex.....	449
ADF.....	450
Optional Peripheral Devices.....	451
LCIT 4040 (D3A6-17, -27).....	451

Cover Interposer Tray CI4040 (DC3N) (for 2K/3K Finishers).....	451
Cover Interposer Tray CI4030 (D3D7).....	451
Finisher SR4080 (D610).....	452
Finisher SR4120 (D3CG), Booklet Finisher SR4130 (D3CH).....	452
Punch Unit Type PU3060 (D706).....	453
Multi Folding Unit FD4000 (D615).....	453
Related SP Codes.....	454
Image Quality Tables.....	455
Checking Image Quality.....	455
Resolution.....	455
Even Density.....	455
Magnification Errors.....	456
Magnification Error Variation.....	456
Paper Transfer Quality Standards.....	458
Registration.....	458
Skew.....	459
LCIT.....	461
Cover Interposer Tray.....	461
PM Parts Settings.....	462
Before Removing Old PM Parts.....	462
After Installing New PM Parts.....	462
4. Replacement and Adjustment	
Power Switch.....	463
Push Switch.....	463
Characteristics of the Push Switch (DC Switch).....	463
Shutdown Method.....	464
Forced Shutdown	465
Before You Begin.....	466
General Precautions.....	466
Drum.....	466
Drum Unit.....	466
Transfer Belt Unit.....	467
Scanner Unit.....	467

Laser Unit.....	467
Charge Corona.....	467
Development.....	468
Cleaning.....	468
Fusing Unit.....	469
Paper Feed.....	469
Used Toner.....	469
Precautions for This Machine.....	469
Inner Covers.....	469
Proximity Sensor.....	470
PSU Precautions.....	471
Important SP Codes: Machine Information, Servicing.....	473
Special Tools and Lubricants.....	476
Special Tools.....	476
Lubricants.....	476
Covers.....	477
Front Door	477
Right Covers	478
Right Upper Cover	478
Right Lower Cover	481
Rear Covers	482
Rear Upper Cover	482
Rear Lower Cover	483
Left Covers	484
Left Upper Cover	484
Left Lower Cover	487
Controller Box Cover Plate	488
Controller Box	490
IOB Bracket	492
Operation Panel.....	496
Operation Panel Removal	496
LCD, Touch Panel Replacement.....	500
CPU Board.....	500

Microcomputer Board.....	503
LCD and Touch Panel.....	504
Scanner Unit.....	507
Before You Begin.....	507
Scanner Unit Removal	507
Exposure Glass	516
Contact Glass.....	519
Contact Glass Removal and Reinstallation.....	519
Convert from Non-Contact to Contact Scanning Configuration.....	523
Contact Glass Cleaning.....	525
Lens Block Cover	525
Original Width Sensors.....	527
Lens Block.....	529
Exposure LEDs (Exposure Lamp).....	533
Scanner Motor.....	540
Scanner HP Sensor.....	545
ADF Open Sensor.....	547
Scanner Wire.....	549
Scanner Wire Removal.....	549
Scanner Wire Reinstallation and Scanner Position Adjustment.....	550
Important SP Codes: Scanner Unit.....	552
Laser Unit.....	553
Warning Decal Locations.....	553
Polygon Motor, Polygon Motor Drive Board, LD Unit	553
Polygon Motor Cover.....	553
Polygon Motor.....	555
Polygon Motor Drive Board.....	556
Laser Diode Unit.....	556
Laser Synchronization Detector.....	557
Laser Unit Alignment	560
Toner Shield Glass	562
Laser Unit Removal.....	564
LD Safety Switches.....	573

Important SP Codes: Laser Unit.....	573
Drum Unit.....	574
Corona Unit	574
Corona Grid.....	574
Charge Wire.....	575
Cleaning Pad.....	576
Corona Wire Cleaning Motor.....	577
Corona Power Pack.....	579
Drum.....	582
Drum Unit Removal.....	582
Drum Removal.....	583
PTL (Pre-Transfer Lamp).....	587
QL (Quenching Lamp).....	589
Potential Sensor.....	591
Cleaning Filter.....	595
Drum Cleaning Blade	596
Cleaning Brush.....	597
Pick-off Pawls.....	600
ID Sensor.....	601
Toner Collection Bottle.....	602
Ozone Filters.....	603
Optics Dust Filter.....	604
Internal Dust Filter.....	605
Toner Bottle Fan.....	607
Drum Motor.....	612
Important SP Codes: Drum Unit.....	620
Development Unit.....	623
Development Unit Removal and Re-Installation	623
Removing the Development Unit.....	623
Separating the Development Unit and Toner Hopper.....	627
Re-installing the Development Unit.....	628
Just Replaced Developer?.....	633
Replacement with a Used Development Unit.....	633

Developer Replacement.....	633
Replacing the Developer.....	633
Re-installing the Development Unit.....	638
Initializing the Developer.....	638
Entrance Seal, Side Seals.....	638
Development Filter.....	641
TD Sensor.....	644
Toner End Sensor.....	646
Toner Separation Unit.....	649
Toner Bottle Motor.....	651
Development Motor.....	656
Development Unit Power Pack.....	660
Used Toner Collection Unit	664
Used Toner Collection Unit Removal.....	664
Toner Collection Motor Sensor.....	667
Used Toner Collection Motor.....	669
Toner Bottle Set Switch, Toner Bottle Full Switch.....	669
Important SP Codes: Development Unit.....	673
Transfer Belt Unit.....	674
Transfer Belt Unit Removal	674
Transfer Belt, Transfer Roller Cleaning Blade	675
Transfer Belt Assembly Removal.....	675
Transfer Roller Cleaning Blade.....	676
Transfer Belt Replacement.....	676
Re-assembly.....	677
Transfer Power Pack.....	680
Re-installation.....	683
Discharge Plate.....	685
Important SP Codes: Transfer Belt Unit.....	686
Fusing Unit.....	688
Fusing Unit Removal	688
Thermostats, Thermistor, NC Sensor.....	689
End Thermistor (D223/D224).....	690

End Thermistor (D225).....	693
Thermostats.....	695
Reinstallation.....	697
Center Thermistor (NC Sensor) (D223/D224).....	698
Center Thermistor (NC Sensor) (D225).....	700
Web Cleaning Roller.....	702
Web Unit Disassembly.....	702
Re-assembly.....	703
Web Unit Re-assembly.....	704
Web Motor, Web End Sensor.....	705
Reinstallation.....	707
Pressure Roller Cleaning Unit, Cleaning Rollers	707
Pressure Roller Cleaning Unit.....	707
Pressure Roller Cleaning Roller (D223/D224).....	708
Pressure Roller Cleaning Roller (D225).....	709
Re-assembly.....	709
Fusing Lamps, Hot Roller, and Pressure Roller.....	710
Fusing Lamps (x3) D223, D224.....	710
Fusing Lamps (x2) D225.....	717
Hot Roller, Pressure Roller.....	723
Pressure Roller Only.....	725
Checking the Fusing Nip.....	726
Stripper Pawls.....	727
Nip Band Width Adjustment.....	729
Fusing Unit Exit Sensor.....	729
Fusing/Exit Motor.....	730
Fusing Exit Sensor, Exit Unit Entrance Sensors.....	737
Turn Sensor.....	738
Fusing Pressure Release Sensor.....	740
Fusing Pressure Motor.....	741
Temperature Sensor.....	742
Important SP Codes: Fusing Unit.....	744
Duplex Unit.....	746

Duplex Unit Removal	746
Re-installation.....	746
Adjustments.....	746
Duplex Unit Side-to-Side Adjustment	746
Jogger Fence Adjustment.....	747
Duplex Motors.....	747
Duplex Unit Front Cover	747
Duplex Inverter Motor.....	748
Duplex Jogger Motor.....	751
Duplex Transport Motor.....	754
Duplex Sensors.....	756
Jogger Fence HP Sensor.....	756
Duplex Entrance Sensor.....	757
Duplex Transport Sensor 3.....	758
Inverter Exit Sensor, Transport Sensors 1, 2.....	758
Duplex Jogger Belt Adjustment.....	760
Important SP Codes: Duplex Unit.....	761
Paper Feed Units.....	762
Paper Trays.....	762
Tandem Tray	762
Universal Trays.....	764
Rear Fence Return Sensor.....	765
Rear Fence HP Sensor.....	765
Tandem Right Tray Paper Sensor.....	766
Bottom Plate Lift Wire.....	768
Re-assembly.....	769
Tandem Tray Paper Size Change.....	770
Tandem Tray Side Registration.....	773
Pick-up, Feed, Separation Roller.....	774
Paper Tray Lift Motors, Tray 1 Lock Solenoids.....	775
Tray Motor, Solenoid Access	775
Tray 1 Lift Motor.....	781
Tray 2 Lift Motor.....	782

Tray 3 Lift Motor.....	783
Right Tray Lock Solenoid.....	784
Left Tray Lock Solenoid.....	785
Paper Feed Unit Removal	787
Paper Feed Motors.....	792
Relay Motor.....	795
Separation Roller Pressure Adjustment.....	800
Lift Sensor, Paper End Sensor.....	801
Feed Sensor, Vertical Transport Sensor.....	803
Pick-up Solenoid.....	806
Reverse Release Solenoid.....	811
Relay Sensor.....	815
Registration Motor.....	816
By-Pass Tray.....	819
By-Pass Tray Removal	819
By-Pass Tray Disassembly	821
By-Pass Paper Size Detection Board.....	822
Re-assembly.....	824
By-Pass Paper Length Sensor.....	824
By-Pass Tray Rollers.....	827
By-Pass Separation Roller Pressure Adjustment.....	828
Registration Sensor.....	829
By-Pass Unit.....	833
By-Pass Unit Removal.....	833
Re-installation.....	839
By-Pass Motor.....	840
Guide Plate Sensor.....	843
Paper Path LEDs.....	845
LED Locations.....	845
Jam LED A: Vertical Inner Cover.....	846
Jam LEDs C2, B2, B1	848
Jam LED C1 Inner Cover.....	848
Jam LED E3/Z: Inverter Duplex Inner Cover.....	849

Jam LED D1/E1: Fusing Unit Inner Cover.....	850
Paper Feed Adjustments.....	854
Paper Registration.....	854
Buckle Adjustment.....	855
Important SP Codes: Paper Feed.....	856
PCBs, HDD.....	858
Before You Begin.....	858
Board Locations.....	858
Controller Board Replacement	860
Before You Begin.....	860
Controller Board.....	861
Controller Board NVRAM.....	866
HDD.....	869
HDD Removal.....	869
Re-installation.....	871
After HDD Replacement.....	872
BICU.....	872
BICU NVRAM.....	877
RYB (Relay Board).....	878
PSU.....	880
DHB.....	884
AC Drive Board.....	885
IOB.....	890
Important SP Codes: PCBs, HDD.....	893
ADF.....	895
ADF Removal	895
After ADF Replacement.....	898
CIS RGB Adjustment	898
Checking the vertical registration.....	898
Checking the horizontal registration.....	899
Checking skew.....	899
Checking magnification.....	900
Platen Adjustment.....	900

ADF Covers	901
ADF Front Cover page 901	901
ADF Rear Cover	903
Feed Cover	904
Original Feed Unit	905
Pick-up Roller, Transport Belt.....	906
ADF Separation Roller	908
Original Registration Sensor.....	909
Original Exit Sensor.....	910
ADF Control Board	912
Separation Sensor, Skew Correction Sensor.....	913
Original Width Sensor, Interval Sensor.....	914
Original Length Sensors.....	915
APS Feeler.....	916
ADF Lift Interlock Switch, Lift Sensor.....	917
Original Set Sensor.....	918
A4 LEF, LT LEF Sensor.....	919
Bottom Plate HP Sensor.....	919
Bottom Plate Position Sensor.....	920
ADF Feed Cover Interlock SW, Pick-up Roller HP Sensor.....	921
ADF Entrance Motor	922
ADF Scanning Motor.....	923
ADF Exit Motor.....	924
ADF Bottom Plate Lift Motor.....	926
ADF Pick-up Roller Lift Motor, ADF Transport Motor.....	926
ADF Feed Motor.....	928
CIS Unit.....	930
CIS White Roller Cleaning.....	934
Important SP Codes: ADF.....	935
Fans, Switches.....	937
Fans.....	937
Quick Reference.....	937
Drum Fan.....	938

Development Unit Fan 1, 2.....	940
Duplex Fan.....	943
PCU Fan.....	945
Toner Bottle Fan.....	947
Fusing Inner Cover Fan.....	952
PSU Fan 1, 2.....	955
AC Drive Board Fan.....	959
Controller Fan.....	961
PFU Fan 1, 3, 4.....	962
Main Intake Fan.....	967
Main Exhaust Fan.....	969
Heat Exhaust Fan.....	971
Switches.....	974
Power Switch.....	974
Front Door Safety Switch.....	975
Human Detection (Proximity) Sensor Switch.....	977
Important SP Codes: Fans, Switches.....	984
Copy Image Adjustments: Printing/Scanning.....	985
Image Adjustments: Printing	985
Preparation.....	985
Registration - Leading Edge/Side-to-Side	985
Blank Margin	986
Registration Buckle Adjustment.....	988
Image Adjustments: Scanning.....	988
Registration: Platen Mode	989
Magnification.....	989
ADF Scanning Adjustments.....	990
Vertical Black Lines.....	990
DIP Switch Settings (ADF Main Board).....	990
ADF Skew Correction.....	991
LCD, Touch Screen Check and Calibration.....	994
Smart Panel Maintenance Mode.....	994
Checks and Calibrations.....	996

LCD Check.....	996
Touch Panel Check.....	997
Touch Panel Calibration.....	998
Multi Touch Calibration.....	999

5. Detailed Descriptions

Overview.....	1003
General Layout.....	1003
Component Layout.....	1005
Bypass Unit.....	1005
Optics.....	1006
Paper Feed Unit (PFU).....	1006
Electrical Components.....	1008
Tandem Tray.....	1009
Around the Drum.....	1010
Sensors, Switches.....	1011
Motors, Fans.....	1012
Transfer, Fusing, Exit Units.....	1013
Duplex Unit.....	1015
ADF Unit.....	1016
Paper Path.....	1017
Motors.....	1019
Scanner.....	1021
Overview.....	1021
Block Diagram.....	1021
Cross Section.....	1022
Configuration.....	1022
Mechanism.....	1023
Scanner.....	1023
Scanner drive.....	1023
Original Size Detection.....	1024
Sensor States.....	1024
Original Feed from ADF.....	1027
Dust Detection.....	1027

Overview.....	1027
Shifting the Scanning Position.....	1029
Scanner Anti-Condensation Heater.....	1030
Image Processing.....	1031
Image Data Flow.....	1031
Image Processing.....	1032
Image Processing Flow.....	1032
Manual Gamma Adjustment.....	1033
SP Codes Related to Gamma Adjustments.....	1033
Print Process (Main Engine Components).....	1035
Laser Unit.....	1035
Block Diagram of Laser Unit.....	1035
Laser Unit Components.....	1036
Laser Unit.....	1037
APC (Auto Power Control).....	1038
LD Safety Switch (Front Door Interlock Switch).....	1038
Laser Unit Control.....	1038
Line scan mechanism.....	1039
Multi-beam Scanning.....	1039
Drum Unit.....	1040
Cross Section of Drum Unit.....	1040
OPC Drum	1041
Charge.....	1042
Charge Wire Cleaning.....	1043
PTL (Pre-Transfer Lamp).....	1043
Paper separation pawls.....	1044
Drum Cleaning mechanism.....	1045
Drum Cleaning Drive.....	1046
Ozone Filters and Drum Cooling.....	1047
Toner recycling mechanism.....	1048
Reusable and Unreusable Toner Separation Mechanism.....	1049
Used Toner Bottle.....	1051
Process Control.....	1053

Automatic Setting Operation.....	1054
Automatic Process Control.....	1056
Development Unit.....	1056
Development Unit Cross Section.....	1056
Toner Supply Unit.....	1058
Development Mechanism.....	1059
Inside the Development Unit.....	1059
Development Bias.....	1060
Development Unit Pressure Release (D225 only).....	1061
Toner Supply.....	1061
Development Unit Drive and Cooling.....	1062
Toner Transport.....	1063
Toner End Detection.....	1064
Shutter Mechanism.....	1065
Toner Bottle Supply, Toner Bottle Cooling.....	1065
Toner Supply Control.....	1066
Sensor Control Mode.....	1067
Pixel Count Mode.....	1067
TD Sensor Reference Voltage.....	1068
Abnormal TD Sensor Output.....	1068
ID Sensor Control.....	1068
Both TD Sensor and ID Sensor Abnormal.....	1069
Toner Near-End Control.....	1069
Toner End Recovery.....	1071
Transfer Belt Unit.....	1073
Overview.....	1073
Transfer Separation Mechanism.....	1074
Image Transfer Mechanism.....	1075
Transfer Bias Charge Mechanism.....	1076
Transfer Belt Lift.....	1077
Transfer Belt Drive and Paper Transport Mechanism.....	1077
Transfer Belt Cleaning Mechanism.....	1078
Transfer Belt Release Mechanism.....	1079

Anti-Condensation Heater (Option).....	1080
Image Transfer Current Settings.....	1080
Fusing Unit.....	1081
Overview.....	1081
More About the Fusing Unit.....	1084
Fusing Pressure Mechanism.....	1086
Pressure Application (D223/D224 Only).....	1087
Fusing Safety Devices.....	1088
Entrance Guide Height Adjustment.....	1089
Fusing Drive Mechanism	1090
Temperature Control for Special Paper.....	1090
Fusing Temperature Control.....	1090
CPM Down Mode.....	1091
Important Related SP Codes.....	1091
Temperature Sensor Fan Control.....	1092
Fans Controlled by Temperature Sensor.....	1092
Fan Speed Control by Temperature Sensor.....	1094
Relate SP Codes.....	1096
Paper Transport.....	1097
Paper Feed Units (PFU).....	1097
Overview.....	1097
Tray Paper Feed Drive.....	1099
Paper Feed From Tray 1.....	1099
Paper Feed From Tray 2.....	1101
Paper Feed From Tray 3.....	1102
PFU and Tray Details.....	1103
Paper Feed and Separation.....	1103
Separation Roller Release.....	1104
Tray Raising and Lowering.....	1105
Tray Upper Limit Detection	1106
Paper End Detection.....	1107
Paper Size Detection.....	1108
Tray Set Mechanism.....	1110

Vertical Paper Feed.....	1111
Tray 1 (Tandem Tray)	1112
Paper Size Detection.....	1112
Tray Movement Mechanism.....	1112
Paper Height Detection.....	1113
Right Tray Fence Movement Mechanism.....	1114
Left Tray Movement	1115
Left Tray Lock Mechanism.....	1116
Right Tray Lock Mechanism.....	1117
Bypass Tray.....	1119
Bypass Feed Tray Mechanism.....	1119
Bypass Tray Feed and Separation Mechanism.....	1119
Paper Stopper Mechanism.....	1120
Bypass Tray Paper End Detection Mechanism.....	1121
Paper Size Detection.....	1122
Paper Registration and Transport in Bypass Unit.....	1123
Invert, Duplex Unit.....	1127
Overview.....	1127
Motors.....	1128
Invert Duplex Entrance.....	1128
Jogging Operation.....	1129
Invert Operation	1130
Duplex Transport Mechanism	1132
Paper Jam Release and Reset Mechanism.....	1132
Exit Unit.....	1134
Overview.....	1134
Decurl Mechanism.....	1134
Exit Junction Gate Mechanism.....	1135
Duplex Interleave Feed Sequence.....	1136
Electronic Components.....	1140
Boards.....	1140
Board Layout.....	1140
Board Functions.....	1140

ADF Unit.....	1143
Overview.....	1143
Specifications.....	1143
Original Size.....	1144
Cross-Section of ADF Unit.....	1145
Scanning Sequence.....	1146
ADF Components.....	1146
Motors.....	1146
Original Pick-up.....	1147
Bottom Plate Lift.....	1148
Original Feed and Separation Mechanism.....	1149
Skew Correction Mechanism.....	1150
Original Size Detection.....	1151
Original Transport.....	1153
Original Scanning.....	1156
Jam Detection Sensors.....	1158
ADF SC Errors.....	1160
New Features.....	1163
Human Detection (Proximity) Sensor.....	1163
Overview.....	1163
Sensor Operation.....	1164
Operation Modes.....	1164
User Tool.....	1164
Related SC Codes.....	1165
Related SP Code.....	1165
Operation Panel.....	1165
Shutdown Feature.....	1166
Specification	1166
The Shutdown Screen.....	1166
Automatic Delete Memory Function (HDD Security).....	1167
Specification	1167
Data Encryption.....	1169
Overview.....	1169

Handling Data Encryption.....	1170
Data Targeted for Encryption.....	1170
Precautions About Encryption.....	1170
Preferences Function (SMC Data Media Storage).....	1171
Function Details.....	1171

6. System Maintenance

Service Program Mode.....	1175
Enabling and Disabling Service Program Mode.....	1175
Entering SP Mode.....	1175
Exiting SP Mode.....	1175
Types of SP Modes.....	1175
SP Mode Button Summary.....	1176
Switching Between SP Mode and Copy Mode for Test Printing.....	1177
Selecting the Program Number.....	1177
Exiting Service Mode.....	1178
Service Mode Lock/Unlock.....	1178
PM Counter/ Firmware Update.....	1179
Checking the PM Counter.....	1179
Executing Firmware Update.....	1181
Remarks.....	1181
Others.....	1182
Service Program Mode Tables.....	1183
SP Tables.....	1183
Test Pattern Printing.....	1184
Printing Test Pattern: SP2902.....	1184
Test Pattern Table.....	1184
Firmware Update.....	1186
Software Update.....	1186
Software Update Procedure.....	1186
Doing the Software Update Procedure.....	1186
Errors During Firmware Update.....	1189
Updating the LCD/DC for the Operation Panel.....	1190
Downloading Stamp Data.....	1191

Uploading/Downloading NVRAM Data.....	1191
Uploading Content of NVRAM to an SD card.....	1191
Downloading an SD Card to NVRAM.....	1192
Updating JavaVM.....	1193
Creating an SD Card for Updating.....	1193
Updating Procedure.....	1193
List of Error Messages.....	1194
NVRAM Upload/Download.....	1197
Uploading NVRAM Data to an SD Card.....	1197
Downloading NVRAM Data from an SD Card.....	1197
UP/SP Data Import/Export.....	1199
Overview.....	1199
Import/export conditions.....	1199
UP Data Import/Export.....	1199
Data that can be imported and exported.....	1199
Data that cannot be imported or exported.....	1199
Exporting Device Information.....	1200
Importing Device Information.....	1202
SP Data Import/Export.....	1203
Data that can be imported and exported.....	1203
Exporting Device Information.....	1203
Importing Device Information.....	1204
Possible solutions for import/export problems.....	1205
Address Book Upload/Download.....	1208
Information List.....	1208
Download Address Book.....	1208
Upload Address Book.....	1209
RFU Firmware Update.....	1210
RFU Conditions.....	1210
Firmware Update (Auto Remote Firmware Update).....	1211
Overview.....	1211
Downloading and Updating Process.....	1212
Downloads the latest package.....	1213

Judgement of ARFU.....	1213
Update Process.....	1215
Related SP.....	1218
Package Firmware Update.....	1222
Overview.....	1222
Immediate Update.....	1223
Update at the Next Visit (Reserve).....	1226
How to Set the Machine to Download Firmware Later (RESERVE).....	1226
How to Check if the Firmware Downloaded with RESERVE.....	1228
How to Install Firmware Downloaded with RESERVE.....	1230
Update via SD card.....	1233
Capturing Debug Logs.....	1236
Overview.....	1236
Types of debug logs that can be saved.....	1236
Operation Log Security.....	1237
Retrieving Debug Logs.....	1238
Procedure for Retrieving the Debug Log.....	1238

7. Troubleshooting

Self-Diagnostic Mode.....	1241
Service Call Codes.....	1241
Service Call Conditions	1241
SC Logging.....	1241
SC Automatic Reboot.....	1242
Service Call Conditions.....	1245
Service Mode Lock/Unlock.....	1245
Service Call Conditions	1245
Before You Use the Tables.....	1246
SC100: Scanning.....	1248
SC100.....	1248
SC200: Exposure.....	1255
SC200.....	1255
SC300: Image Development 1.....	1260
SC300.....	1260

SC400: Image Development 2.....	1269
SC400.....	1269
SC500: Feed, Transport, Duplex, and Fusing.....	1273
SC500.....	1273
SC600: Data Communication.....	1308
SC600.....	1308
SC700: Peripherals.....	1343
SC700: Peripherals.....	1343
SC800: Overall System.....	1402
SC800.....	1402
SC900: Miscellaneous.....	1457
SC900.....	1457
SC540 to SC545.....	1459
Before You Begin.....	1459
SC540 Fusing web motor error.....	1459
① Confirm failure to feed.....	1459
② Web drive gears	1460
③ Web motor.....	1461
④ IOB connections.....	1462
⑤ IOB.....	1462
⑥ Web motor harnesses.....	1463
⑦ Paper exit unit harnesses.....	1463
SC542 Fusing warm-up error 1: Center thermistor.....	1463
① Error duplication.....	1464
② Power supply voltage level.....	1464
③ Center NC sensor position.....	1464
④ Thermostats.....	1465
⑤ Fusing lamp connections.....	1466
⑥ Fusing lamp filaments.....	1466
⑦ AC control board connections.....	1467
⑧ AC control board.....	1467
⑨ IOB connections.....	1468
⑩ IOB.....	1468

⑪ Harnesses.....	1468
SC543 Fusing lamp overhear error 1 (software).....	1469
① Error duplication.....	1469
② End thermistor alignment.....	1469
③ End thermistor damage.....	1470
④ AC control board connections.....	1471
⑤ AC control board.....	1471
⑥ IOB connection.....	1472
⑦ IOB.....	1472
⑧ Harnesses.....	1472
SC544 Fusing lamp overhear error 1: Hardware.....	1473
① Error duplication.....	1473
② End thermistor alignment.....	1473
③ End thermistor damage check.....	1474
④ Center NC sensor position.....	1474
⑤ AC control board connections.....	1475
⑥ AC control board.....	1475
⑦ IOB Connections.....	1476
⑧ IOB.....	1476
⑨ Harnesses.....	1476
SC545 Fusing lamp overhear error 2: Center lamp.....	1477
① Duplication of the error.....	1477
② Power supply voltage level.....	1477
③ Center NC sensor position.....	1477
④ Thermostats.....	1478
⑤ Fusing lamp connections.....	1479
⑥ Fusing lamp filaments.....	1479
⑦ AC control board connections.....	1480
⑧ AC control board.....	1480
⑨ IOB connections.....	1481
⑩ IOB.....	1481
⑪ Harnesses.....	1481
Jam Detection.....	1482

Paper Jam Code Display.....	1482
Jam Codes and Display Codes.....	1482
Main Unit and LCIT: Paper Jam Errors.....	1482
ADF: Paper Jam Errors.....	1484
Finisher SR4120 Paper Jam Errors.....	1485
Finisher SR4130 Paper Jam Errors.....	1487
Finisher SR4080 Paper Jam Errors.....	1489
Mail Box CS4010 Paper Jam Errors.....	1490
Cover Interposer Tray CI4030/CI4040 Paper Jam Errors.....	1490
Multi Folding Unit FD4000 Paper Jam Errors.....	1491
Paper Size codes.....	1492
Main Machine Sensor Locations.....	1493
Frequent Paper Jams.....	1493
Peripheral Units.....	1496
Height and Level Adjustment.....	1496
Before you begin:.....	1496
Setting the Leveling Shoes.....	1496
Skew and Side-to-Side Registration	1498
Overview.....	1498
Checking Side-to-Side Registration.....	1501
Correcting Side-to-Side Registration.....	1501
Detecting Paper Skew.....	1502
Correcting Skew.....	1503
Booklet Finisher Center Fold Correction	1505
Slant in the direction of paper feed.....	1505
Slant opposite the direction of paper feed.....	1505
How to Correct Misaligned Center Folding.....	1506
Finisher SR4080 (D610): Z-Folded Paper Output.....	1509
Finishers SR4120/SR4130 (D3CG/D3CH).....	1510
Using Auxiliary Trays.....	1510
Thin or soft paper does not exit completely.....	1511
Z-folded paper, Curled paper interfere with tray full sensor.....	1511
Problems with Z-folded paper from the Multi Folding Unit.....	1512


Output Jogger Units.....	1513
Jogger Width Adjustment Procedure.....	1513
Other Problems.....	1515
Common Problems.....	1515
Checking Image Quality.....	1515
Resolution.....	1515
Even Density.....	1516
Magnification Errors.....	1516
Magnification Error Variation.....	1517
Reinstalling OCR Unit Type M2.....	1518
Fuses.....	1520
AC Drive Board.....	1520
DHB.....	1521
PSU.....	1521

1. Product Information

Machine Configuration

1


Component Layout



b246d850


No.	Part	No.	Part
1	Entrance Roller (ADF)	18	Feed Roller (Paper Tray)
2	Feed Belt (ADF)	19	Separation Roller (Paper Tray)
3	Separation Roller (ADF)	20	Pick-up Roller (Paper Tray)
4	Pick-up Roller (ADF)	21	Universal Tray (Tray 3)
5	CIS (Contact Image Sensor)	22	Universal Tray (Tray 2)
6	Original Feed-in Tray	23	Tandem Tray (Tray 1)
7	Exposure Glass	24	Duplex Unit
8	Fusing Unit	25	Inverter
9	Lens Block	26	Inverter Exit Roller
10	OPC Drum	27	Inverter Entrance Roller
11	Development Unit	28	Duplex Junction Gate
12	Development Roller	29	Reverse Trigger Roller
13	Registration Sensor	30	Exit Unit
14	By-pass Tray	31	Pressure Roller
15	Relay Sensor	32	Hot Roller
16	Grip Roller	33	Contact Glass (ADF)
17	Feed Sensor (Paper Tray)		

Paper Path (With Cover Interposer Tray)



No.	Part
1	Proof Exit Tray
2	Cover Sheet Path
3	Original Path
4	By-pass Tray
5	LCT Feed
6	Vertical Transport Path
7	Finisher Exit Tray 2
8	Finisher Exit Tray 1

Paper Path (With 9-Bin Mailbox)




b246d852

No.	Part
1	Original Paper Path
2	Vertical Transport Path
3	LCT Feed
4	Selected Trays
5	Turn Gates
6	Mailbox Paper Path

No.	Part
7	Junction Gate
8	Junction Gates

Drive Layout




b246d801

No.	Part
1	Scanner Motor
2	Drum Motor
3	Fusing/Exit Motor

No.	Part
4	Registration Motor
5	Toner Collection Motor
6	Tray 3 Paper Feed Motor
7	Tray 2 Paper Feed Motor
8	Lower Relay Motor
9	Tray 1 Paper Feed Motor
10	By-pass Motor
11	Development Motor

Machine Codes and Peripherals

Peripheral Units



	Unit	No.
1	Mainframe	D223/D224/D225
2	A3/11" x 17" Tray Type 9001* ¹	D482
3	Tab Sheet Holder 9002* ¹	B499
4	LCIT 4040	D3D6
5	8 1/2" x 11" Paper Size Tray Type 9002	B474
6	Copy Tray 9002	B756
7	Multi-Folding Unit FD4000	D615
8	Finisher SR4080	D610
9	Punch Unit Type 850 S4* ²	A812
	Punch Unit Type 1075 NA 3/2* ²	B531
	Punch Unit Type 1075 EU 2/4* ²	B531

	Unit	No.
10	Output Jogger Unit Type 9002B	B513
11	Cover Interposer Tray CI4030	D3D7
12	Finisher SR4120	D3CG
13	Punch Unit PU3060 SC*2	D706
	Punch Unit PU3060 EU*2	D706
	Punch Unit PU3060 NA*2	D706
14	Booklet Finisher SR4130	D3CH
15	Cover Interposer Tray CI4040	DC3N
16	Mail Box CS4010	D708
17	Output Jogger Unit Type M25	D3CJ

*1: Installed inside the main machine

*2: Installed inside the finishers (only one can be installed)

Other Options

Mainframe Options: External

Unit	No.	Connection
ADF Handle Type C	D593	On mainframe
Card Reader Bracket Type 3352	D593	On mainframe
External Keyboard Bracket Type M25	D3DH	On mainframe
Key Counter Bracket 1027	B452	On mainframe
NFC Card Reader Type M19	D3BS	On mainframe

Mainframe Options: Internal

Unit	No	Connection
Optional Counter Interface Unit Type M12	B870	Main machine

1

Controller Options: I/F Slots

Unit	No	Connection
Copy Connector Type M25	D3D3	Controller Box I/F Slot
Extended USB Board Type M19	D3BS	Controller Box I/F Slot
File Format Converter Type M19	D3BR	Controller Box I/F Slot
IEEE 1284 Interface Board Type M19	D3C0	Controller Box I/F Slot
IEEE 802.11 a/g/n Interface Unit M19	B3BR	Controller Box I/F Slot
Extended USB Board Type M19	D3BS	Controller Box I/F Slot
USB Device Server Option Type M19	D3BC	Controller Box I/F Slot

Controller Options

Unit	No	Connection
Data Overwrite Security Unit Type M19	D3BS	SD Card
Enhanced Security HDD Option Type M10	D792	HDD
IPDS Unit Type M25	D3D4	SD Card
OCR Unit Type M13	D3AC	SD Card
PostScript3 Type M25	D3D4	SD Card
SD Card for Fonts Type D	D641	SD Card
Unicode Font Package for SAP(R)	B869	SD Card
XPS Direct Print Option Type M25	D3D4	SD Card

Fax Options

Unit	No	Connection
Fax Option Type M25	D3D5	Controller Board
G3 Interface Unit Type M25	D3D5	Controller Board
Fax Connection Type M25	D3D4	SD Card
Fax Memory Unit Type M25 64MB	D3D5	Fax Board

Specifications

See "Appendices" for the following information:

- General Specifications
- Supported Paper Sizes
- Software Accessories
- Optional Equipment Specifications

Guidance for Those Familiar with Predecessor Products

1

The D223/D224/D225 succeeds the D131/D132/D133 series. If you have experience with the previous products, the following information will be of help when you read this manual.

Differences from Predecessor Products

General

	D131/D132/D133	D223/D224/D225
Developer	Same	
Toner	Same	
SD Slot	2	2
I/F Slot	2	2
Model Line Up	Three Models	
	D131 60 ppm	D223 65 ppm
	D132 75 ppm	D224 75 ppm
	D133 90 ppm	D225 90 ppm
Approx. Service Life	9,000K	9,000K

Basic Specifications


	Previous Machine	This Machine	Comment
1st copy time	30/30/300 sec.	10/20/300 sec.	Faster
Sleep mode recover	30 s	20 s	Faster
Single side scanning	90 ipm	120 ipm	Faster
Duplex scanning	178 ipm	220 ipm	Faster
Paper thickness			

Bank	52 to 169 g/m ²	52 to 256 g/m ²	Heavier paper
Duplex	64 to 169 g/m ²	52 to 256 g/m ²	Heavier paper
Bypass	52 to 216 g/m ²	52 to 300 to g/m ²	Heavier paper
Sleep mode	7W	1.1 W	Less power
Jam location indicator (LEDs)	---	Cover LEDs	Indicate jam location

Important Changes


ADF

The ADF adopts a CIS unit that scans the reverse side of a page as the front side is scanned below. During one straight-through feed, both sides of the original are scanned. There is no need to reverse feed the original in order to scan the other side. There is no bending the original in the straight-through paper path, so this means this machine can handle thicker original sheets, up to 256 g/m². In one pass, the CIS [A] below the original feed path scans the front side, and then the CIS [B] above the path scans the back side.



d223c0060


A vinyl plate covers the front end of the CIS. A stiff mylar inside the ADF covers the length of the CIS.



d223c0059


Bypass

The bypass tray has a new paper length sensor used to detect the length of the paper loaded in the bypass tray.



d223c0076


The bypass motor (a stepper motor in the previous machine) has been replaced with a DC motor. Also, the motor can no longer be serviced from the back of the machine. The bypass unit must be removed to service this motor.




d223c0077

Controller

The controller is new. The faceplate of the previous machine [A] is on the right, the faceplate of this machine [B] is on the left. Both machines have the same number of SD cards slots (2) and I/F slots (2). The I/F slots of this machine are clearly labeled "Tandem" and "Option". SD card Slot 2 is the service slot for both machines.



The controller box has a cover like the previous model, but there are fewer screws to take off in order to remove the controller box cover. There are only two screws on the face and two on the side. The controller box cover is much easier to remove.



d223c0075

Cover Interposer Trays.

The Cover Interposer Tray CI4030 (D3D7) is new and designed for the Finisher 4080 (D610). The other tray, Cover Interposer Tray CI4040 (DC3N) can be used with either the Finisher SR4120 (D3CG) or Booklet Finisher SR4130 (D3CH). With the previous machine there was only one cover interposer tray available for all three finishers. The installation procedures for both new Cover Interposer Trays is almost the same.



d223c0078

Drum heater.


The drum heater was provided as standard for the previous machine. However, the drum heater for this machine is an option and requires installation.



d223c1148

Drum unit


The gear train of the D223/D224 has two black gears. These same gears in the D225 are white.



d223c0071

Duplex unit.


The junction gate solenoid [A] has been reinforced to reduce junction gate chatter that can occur when heavy paper is being used. Also, the transport motor, a stepper motor in the previous machine, has been replaced with a DC motor [B].



d223c0080

Fans

About 10 fans have been added to lower the internal temperature of the machine. The arrangement of fans on the back of the machine has changed.



d223c0063

[1]	Drum fan. This was the main intake fan on the previous machine.
[2]	Main intake fan. This was the drum fan on the previous machine.
[3]	Main exhaust fan. This fan and duct are new.
[4]	Main heat exhaust fan. This fan and duct are new.
[5]	Controller fan. This is a new exhaust fan, mounted on top of the controller box to draw heated air up from the controller box.

Human detection (proximity) sensor


This is a new sensor that detects the presence of the operator. It is installed at the upper left corner of the machine above the power switch. As soon as this sensor detects the operator within 1.8 meters from the front of the main machine, the machine will prepare the machine to recover more rapidly from Energy Save mode.



d223c0072

LCIT heater (option)

The previous LCIT heater [A] was held in place by an adhesive strip. The new heater [B] is held in place with two screws. The installation procedure for the new heater is different.



d223c0068

LD unit


With the previous machine, a label was attached to the new LD unit with SP settings (**SP2115-001 to 005**) that had to be entered manually from the operation panel. However, with this machine, you need only execute **SP2110-005** once to automatically download all the settings from the machine for the new LD unit.



d223c0042

Laser synchronization detector

Removing the laser synchronization detector is much easier because there is nothing blocking it. With the previous machine, the development unit cooling fan bracket had to be removed in order to reach the detector.



d223c1114

Laser unit


The scanner unit must be removed in order to service the laser unit below it.



d223c0034

NC sensor

The fusing unit has a new NC sensor. The NC sensor [1] is mounted above the heating roller [2] to monitor the temperature of the roller. The sensor employs two precision thermistors with infrared technology. Unlike a metal thermistor, an NC sensor is remote (it does not touch the component that it is monitoring).



Operation panel


This machine has adopted the new Smart Operation Panel.



d223c0069

PCB layout.


The layout of the main boards on the back of the machine has changed. In this machine the BICU (formerly BCU) and IOB have swapped positions. The BICU is in the controller box next to the controller board. The IOB is behind the controller box. The RYB and AC drive board are new boards. Several boards of the previous machine have been discarded (IPU, CTL-PSU, CNB, and DRB). The IPU functions have been taken over by the BICU.



d223c0061

PFU motors


The paper feed motor of the D225 is no longer an external motor. It is encased in the PFU unit, just like the D223/D224. Also, the STM (stepper motor) has been replaced with a DCM (DC motor).



d223c0074


Paper jam handling

New LEDs are provided on the inner covers on the paper path. An LED will light when a jam occurs at its location. This makes it much easier to locate and remove jammed sheets. You must pay attention to these LED harnesses when removing a cover. The LED must be disconnected before a cover can be completely removed.



d223c1112

Every inner cover over the paper path, like the fusing unit cover [A] and vertical inner cover [B], has an LED harness that must be carefully disconnected before the cover can be removed. Inner covers must be removed with care in order to prevent damage to these connectors and harnesses.



d223c0073

Potential sensor.


The new potential sensor is encased in a shield casing and is fastened over the top of the drum where it can read the drum potential, potential control gradation patterns, and ID sensor patterns between sheets immediately after the drum has been charged and the patterns have been written on the drum before they are developed with toner. The potential sensor [1] and the potential sensor power pack [2] are attached to the same bracket mounted above the surface of the drum.



d223c0058

Power cord.


The power cord is new. It is not permanently attached to the machine, so it must be connected and locked in place with a bracket held by one screw.



d223c1115

Rotation count sensor

A knob rotation count sensor has been added at the front left corner of the fusing unit. When a jam occurs in the fusing unit, the operator rotates the **D1/E1** knob until the LED goes out. Once the LED goes out the operator knows the jam can be removed at **D1** or **E1**. (The operator no longer has to count the number of knob rotations before trying to remove the jam.) A decal on the front of the fusing unit cover describes how to use this new feature.



d223c0067

STM to DCM


Most of the STM motors (Stepper Motors) of the previous machine have been replaced with DCM motors (DC Motors).



d223c0079

Scanner SIOB

There is no SIOB (Scanner Interface Board) in the scanner unit, the driver that controlled the sensors and scanner motor in the previous machine. These functions are controlled directly by the BICU. Both harnesses from the scanner unit connect directly to the BICU inside the controller box on the back of the machine.



d223c3103

Scanner unit

The exposure lamp has been replaced with a pair of exposure LEDs [1] and [2]. The 2nd LED doubles the intensity of the light so the CMOS element can pick up and produce a better image.



d223c0064

TD sensor

A new 24V TD sensor in the development unit is mounted on a longer bracket provided with bracket clamps for the sensor harness.



d223c3274

Temperature sensor

A temperature sensor near the drum unit monitors the internal temperature of the machine to ensure cool and efficient operation.



d223c0070

Unit and Option Name and Number Changes

The main peripherals and other options are essentially the same as the same items for the predecessor machines. However, some of the item names and codes have changed due to changes in the shapes of external covers, cover colors, etc.

Main Machine and Peripheral Units

↓ Note

- Changes are marked in **bold** in the right column.
- Make sure that you use the correct names and numbers when ordering peripheral units and options for this machine.

D131/D132/D133	D223/D224/D225
Mainframe (D131/D132/D133)	Mainframe (D223/D224/D225)
8 1/2"x14" Paper Size Tray Type 9002 (B474)	8 1/2" x 11" Paper Size Tray M25 (B474)
A3/11" x 17" Tray Type 9001 (D482)	A3/11" x 17" Tray Type M25 (D615)
Copy Tray Type 9002 (B756)	
Cover Interposer Tray CI4000 (D614)	Cover Interposer Tray CI4040 (DC3N)
---	Cover Interposer Tray CI4030 (D3D7)
Finisher SR4060 (D611)	Finisher SR4120 (D3CG)
Finisher SR4070 (D612)	Booklet Finisher SR4130 (D3CH)
Finisher SR4080 (D610)	Finisher SR4080 (D610)
LCIT RT4010 (D613)	LCIT 4040 (D3A6)
Mailbox CS4000 (D616)	Mail Box CS4010 (D708)
Multi Folding Unit FD4000 (D615)	Multi-Folding Unit FD4000 (D615)
Output Jogger Unit Type 9002A (B703)	Output Jogger Unit Type M25 (D3CJ)
Output Jogger Unit Type 9002B (B513)	Output Jogger Unit Type 9002B (B513)
Punch Unit Type 1075 3/2 (B531)	Punch Unit Type 1075 NA 3/2 (B531)
Punch Unit Type 1075 EU 2/4 (B531)	Punch Unit Type 1075 EU 2/4 (B531)
Punch Unit Type 3260 2/4 EU (B702)	Punch Unit PU3060 EU (D706)
Punch Unit Type 3260 NA 3/2 (B702)	Punch Unit PU3060 NA (D706)
Punch Unit Type 3260 SC (B702)	Punch Unit PU3060 SC (D706)
Punch Unit Type 850 SC (A812)	Punch Unit Type 850 SC (A812)
Tab Sheet Holder 9002 (B499)	

Mainframe Options: External

D131/D132/D133	D223/D224/D225
---	ADF Handle (D593)
Card Reader Bracket (B498)	
Key Counter Bracket Type 1027 (B452)	Key Counter Bracket 1027 (B452)
---	NFC Card Reader Type M19 (D3BS)
USB2.0/SD Slot Type C (D464)	Discontinued * ¹
* ¹ USB slot built into new operation panel	

Mainframe Options: Internal

D131/D132/D133	D223/D224/D225
Copy Connector Type 3260 (B328)	Copy Connector Type M25 (D3D3)
Copy Data Security Unit Type F (B829)	---
Gigabit Ethernet Type B (D377)	---
Opt. Counter Interface Unit Type A (B879)	Opt. Counter Interface Unit Type M12 (B870)

Controller Options

↓ Note

- Changes are marked in **bold** in the right column.

Controller Options: I/F Slots

↓ Note

- Changes are marked in **bold** in the right column.
- These options are boards inserted into I/F slots on the faceplate of the controller board.

D131/D132/D133	D223/D224/D225
File Format Converter Type E (D377)	File Format Converter Type M19 (D3BR)

D131/D132/D133	D223/D224/D225
IEEE1284 Interface Board Type A (B679)	IEEE 1284 Interface Board Type M19 (D3C0)
IEEE802.11 a/g Interface Unit Type J (D377)	IEEE 802.11 a/g/n Interface Unit M19 (B3BR)
IEEE802.11g Interface Unit Type K (D377)	---
---	Extended USB Board Type M19 (D3BS)

Controller Options: SD Cards, Built-in

↓ Note

- Changes are marked in **bold** in the right column.
- These options are on SD cards inserted into the SD card slot on the faceplate of the controller board.
- The SD cards have been discontinued for some options, but the option has been built into the machine firmware (the SD card is no longer required).

SD Cards

D131/D132/D133	D223/D224/D225
Data Overwrite Security Unit Type H (D377)	Data Overwrite Security Unit Type M19 (D3BS)
PostScript3 Unit Type 9002 (D620)	PostScript3 Type M25
HDD Encryption Unit Type A (D377)	Built-in
Printer/Scanner Unit Type 9002 (D620)	Built-in
VM Card Type U (D640)	Built-in
---	IPDS Unit Type M25
---	OCR Unit Type M13 (D3AC)
---	SD Card for Fonts Type D (D641)
---	USB Device Server Option Type M19 (D3BC)
---	XPS Direct Print Option Type M25 (D3D4)

HDD

The Enhanced Security HDD Option Type M10 (D792) is an HDD.

1

Fax Options

↓ Note

- Changes are marked in **bold** in the right column.

Fax Options


D131/D132/D133	D223/D224/D225
Fax Option Type 9002 (D619)	Fax Option Type M25 (D3D5)
G3 Interface Unit Type 9002 (D619)	G3 Interface Unit Type M25 (D3D5)
Fax Connection Unit Type E (D621)	Fax Connection Type M25
---	SAF Memory Option (D3D5)

2. Installation

Installation Requirements

Operating Environment

1. Temperature Range
 - Recommended: 15°C to 25°C (59°F to 77°F)
 - Possible: 10°C to 32°C (50°F to 90°F)
2. Humidity Range:
 - Recommended: 30% to 70 %RH
 - Possible: 15% to 80% RH (27 °C 80%, 32 °C 54%)
3. Ambient Illumination: Less than 1,500 lux (do not expose to direct sunlight or strong light.)
4. Ventilation: Room air should turn over at least 3 times per hour
5. Ambient Dust: Less than 0.10 mg/m³
6. The optimum operation range is shown in the shaded area of the illustration below. Performance of the machine outside this range cannot be guaranteed.



d223c1001

7. If the work site is air-conditioned or heated, do not place the machine where it will be:
 - Subjected to sudden temperature changes
 - Directly exposed to cool air from an air-conditioner

- Directly exposed to heat from a heater
8. Do not place the machine where it will be exposed to corrosive gases.
 9. Do not install the machine at any location over 2,000 m (6,500 feet) above sea level.
 10. Place the copier on a strong and level base with the front and back of the machine within ± 5 mm (0.2") of level.
 11. Do not place the machine where it may be subjected to strong vibrations.
 12. Do not connect the machine to a power source shared with another electrical appliance.
 13. The machine can generate an electromagnetic field which could interfere with radio or television reception.

Machine Level


Front to back: Within ± 5 mm (0.2") of level

Right to left: Within ± 5 mm (0.2") of level


The machine legs may be screwed up or down in order to level the machine. Set a carpenter's level on the exposure glass.

Minimum Space Requirements

Place the machine near the power source with minimum clearance as shown below. The same amount of clearance is necessary when optional peripheral devices are installed.



Dimensions



d223d2001

Power Requirements

⚠ CAUTION

- Make sure that the wall outlet is near the main machine and easily accessible so it can be unplugged in an emergency.
- Make sure the plug is firmly inserted in the outlet.
- Avoid multi-wiring.
- Be sure to ground the machine.

- Never place anything on the power cord.

Input voltage level	North America 120 V, 60 Hz: 20 A or more
	Europe/Asia 220 V to 240 V, 50 Hz/60 Hz: 10 A or more
	Taiwan 110V, 60 Hz, 20A or more
Permissible voltage fluctuation	±10%

CAUTION

- Never turn off the power switch when the power LED on the operation panel is lit or flashing.

The Main Power LED lights or flashes:

- While the platen cover or ADF is open
- While the main machine is communicating with the network server
- While the machine is accessing the hard disk or memory when reading or writing data.
- There is only one power switch at the upper left corner of the machine. There is no power switch on the operation panel.
- When you turn the machine off, a message will appear and tell you that it may take as long as 2 minutes for the machine to switch off. Wait for this message to go off.
- Never unplug the machine from its power source until the message power off screen on the operation panel goes off.

Main Machine

Accessory Check

Check the accessories and their quantities against this list:

No.	Description	Q'ty
1.	Model Name Decal (-29 Only)	1
2.	Operation Instructions (-17, -19, -21, -29, -57 Only)	2
3.	Leveling Shoes (Front)	2
4.	Decal – Paper Size	1
5.	Decal: Caution Chart: Paper Set: Direction	1
6.	Leveling Shoe	2
7.	Decal – Cleaning - Multiple	1
8.	Cloth – Exposure Glass	1
9.	Cloth Holder	1
10.	Decal – Toner Supply - Multiple	1
11.	Decal: Power Source: Off	1
12.	Decal Exposure Glass: Multiple	1
13.	Decal – D1/E1 Multiple	1
14.	EU Safety Sheet (-27, -67 only)	1
15.	Ferrite Core (GRFC-13)	1
16.	EULA Sheet: 18 languages (-28, -57, -67 only)	1
17.	Decal: License Agreement 18 Languages (-28, -57, -67 only)	1
18.	TEL Name Sheet (-21 only)	1


Installation Flow

No.	Step
	Before Power On
1	Remove Tapes and Shipping Materials
2	Attach Power Cord to Machine
3	Remove Development Unit
4	Load Developer
5	Re-install Development Unit
6	Set Toner Bottle
7	Set Tandem Tray for A4 or LT Paper
8	Level the Machine
9	Attach Cleaning Cloth Holder
10	Connect Drum Heater, Tray Heater (Optional)
11	Load Paper, Attach Decals
12	Attach Nameplate
	After Power On
13	Initialize Toner and Process Control Settings
14	Check Image Quality and Settings
15	Important Notice on Security Issues
16	Auto Remote Firmware Update Settings
17	@Remote Settings
18	Security Settings


Installation Procedure

Remove Tapes and Shipping Materials

1. Remove the cover [A].
2. With four people, one person at each corner of the machine, lift the machine slightly while a 5th person slides the pallet [B] from under the machine.




3. Remove visible orange tape and cardboard strips from the front [A] and right side [B] of the main machine.




d223c1005

4. Remove tape and cardboard strips from rear [A] and left side [B].




d223c1006

5. Remove tapes from the surface of ADF [A].
6. Open ADF [B].




d223c1007

7. Remove all tape and packing material inside the ADF [A].
8. Close ADF [B].




d223c1008

9. Remove tapes under original output tray [A].
10. Remove accessory decals [B].




d223c1009

11. Raise the ADF, and then remove cover sheet [A].



d223c1010

- 12. Raise the ADF and remove tape [A].
- 13. Pull the sheet [B] out from behind the white plate. The sheet is white and difficult to see. The tape is a reminder to pull this sheet.



d223c1013

- 14. Remove tape [A] above rear scale.



d223c1102

15. Remove tape [A] from left scale of the exposure glass.




d223c1014

16. Remove protective sheet from operation panel display.




d223c1015

17. Open the front door.
18. Remove tape and sheets at [1], [2], [3], [4].



d223c1016


19. Swing open the toner bottle holder [A].




d223c1018

20. Disconnect PCU inner cover [A].


21. Rotate lever C1 [B] down. This lowers the transfer belt unit.




22. Disconnect PCU inner cover at [1], and then disengage its corner tab at [2].




23. Raise PCU inner cover [A] and then remove it.




24. Remove bracket, wire, red tag [A].



25. Remove plug, wire, red tag [A].




26. Open the bottom tray.



d223c1091


- 30. Inside the tandem tray [A], remove tape and spacer [1].
- 31. Remove tape and cushion [2].
- 32. Remove red tag, wire, and bracket [3].



 x1


d223c1024

- 33. Remove tape and packing from the face of right tray [A].



d223c1025

34. Open Tray 2 [A], and then remove tape and red tag on the corner.



d223c1026

35. Remove packing on the right, and then unpack it. This is the power cord, bracket, and bracket screw.



d223c1027

36. Remove packing on the left, and then unpack it. These are [1] Front leveling shoes, [2] rear leveling shoes, [3] glass cleaning cloth and cloth holder.



d223c1028


Attach Power Cord to Machine

1. Locate the power connection point [A] on the left rear corner of the main machine.
2. Attach the safety bracket [B] near the end of the power plug.



d223c1029

3. Set bracket [A] into the slot.
4. Plug the cord [B] into the machine, and then fasten the bracket.



⚠ WARNING

- Do not connect the power cord until you are instructed to do so.


Remove Development Unit

1. If the LCIT is connected to the right side of the machine, disconnect it and pull it away.
2. Prepare a clean, flat surface for the development unit.
3. Open the developer kit box and take out the protective sheet [A] and developer pack [B].
4. Unwrap the sheet and spread it on a flat clean surface [C].



d223c1103

5. Disconnect shuttle cover [A].



★ Important


- A washer is attached to the shuttle cover screw in order to prevent the screw from falling into the machine. Turn the screw counter-clockwise only enough turns to remove it. If you loosen the screw too much the washer will fall into the machine.

1. Remove shuttle cover.



2. Remove lock screw [A].

3. The toner bottle holder [B] springs open slightly as soon as the screw is removed.




4. Push the front door slightly to the right, and then swing the holder out as far as it will go.




★ Important

- The door must be completely open. If it is not, then it will block removal of the development unit.
 - The LCIT must be disconnected from the right side of the machine to allow the front door to open completely.
5. Remove knob [A]. (This is a reverse thread. Turn it **clockwise** to remove it).
6. Disconnect development unit faceplate [B].




d223c1035




 x2

7. Remove development unit faceplate.




d223c1036

8. Raise the toner supply pipe shutter to close the pipe.



d223c1037


9. On the right [A] disconnect the development unit.



x2

d223c1038

10. Slip the development unit [A] to the right.
11. Push the development unit [A] slightly to the right, and then pull the unit [B] straight out of the machine.



d223c1039

12. Lay the development unit on the prepared surface.




d223c1104

Load Developer


1. At the front end of the unit, disconnect the pressure release tube.

★ Important

- Only the D225 Model has this pressure release tube. This step is not required for the D223/D224 models.




2. Disconnect the toner hopper.



3. Rotate the toner hopper slightly as you lift it.
4. Remove the toner hopper and set it aside.



5. Shake the developer pack to loosen the developer inside.
6. Cut off the top of the pack.




d223c1105

7. Save the top with the lot number embossed on it. You will need to enter this number later with SP2963-002.



d223c1106

8. While turning the knob slowly in the direction of the arrow as shown below, move the open end of the pack side to side as you continuously pour developer into the open slot of the development unit.




d223c1044

Re-install Development Unit


Pay attention to these important points as you re-install the development unit.

- To re-assemble the top and bottom half of the development unit, first allow the bottom half [A] to tip slightly forward.
- Hold the top half [B] (toner hopper) over the bottom half, set the cutouts on the ends of the shaft below, and then slowly rock the top half forward [C] so the holes are aligned.



d223c1107

- Make sure that the holes are aligned at the rear [A] and front [B], and then fasten the screws.




d223c1108

- If you are installing a D225, be sure to re-connect the pressure release tube at the front of the development unit.




d223c1045

- Slip slightly to the right as you push it slowly back into the machine.



d223c1047

- Push the development unit in until it stops, and then push it to the left.
- You should see the pin through the oval hole as shown below. This means the unit is locked in the correct position.



d223c1049


- The horizontal pin must be through the hole and overlapping the plate as shown below on the left.



d223c1050

↓ Note

- If the pin does not slide over the plate as shown above, turn the front gear of the development unit counter-clockwise and try again.
- Be sure to re-connect the development unit [A].



 x2

d223c1038


- You must remember to lower the supply pipe shutter so the pipe is open.



d223c1052

★ Important


- The shutter must be down. If it remains up, you will not be able to close the toner bottle holder and the front door.
- Be sure to raise lever C1 before you close the door. (The front door will not close if C1 is down.)



d223c1053


Set Toner Bottle

1. Rotate the bottle at least 10 times to make sure that the toner inside is loose.



d223c1116

2. Remove toner bottle cap.
3. Swing out the toner bottle holder as shown [1]
4. Set the toner bottle in the holder [2], push it in until you hear a click, and then turn it clockwise [3] to lock it in place.



d223c1109

5. Swing the toner bottle and holder to the left against the front of the machine.



d223c1110

Set Tandem Tray for LT or A4 Paper

Before You Begin

The tandem tray (Tray 1) can accommodate either letter (LT) or A4-size paper, depending on how the side fences are set. The tray is set for either LT or A4 paper before the machine leaves the factory, depending on the destination of the machine.

1. Open Tray 1 and pull it out completely.
2. Check the position of the screw on the upper right corner of the left tray. The position of the screw tells you how the tandem tray is set (LT or A4).
3. In the illustration:
 - [1] Tray is set for LT (letter-size) paper.
 - [2] Tray is set for A4-size paper.




d223c1055

2

There are two trays in the tandem tray, a left tray [A] and a right tray [B]. If you want to change the setting to LT or A4, you need to do five adjustments.

- Change the positions of the front side fences [1] in both the left and right tray.
- Change the positions of the rear side fences [2] in both the left and right tray.
- Change the position of the left tray sensor [3] in the left tray.




d223c1056

★ Important


- The following procedures show you how to switch the tandem tray from LT to A4 size paper.

Right Tray Side Fences

1. Push right tray to the rear.
2. Remove the right tray faceplate [A] (🔩 x2).
3. Remove the screw of the right tray front fence [B].




 x2




d223c1057

4. Lift the front fence [A] out of the rear slot (LT) and then insert it in the front slot (A4).
5. Fasten the front fence[B].



 x1




d223c1058

6. Remove the screw of the right tray rear fence [A].
7. Lift the rear fence [B] out of the front slot (LT) and then insert it in the rear slot (A4).
8. Fasten the rear fence.



 x1



d223c1059

9. Re-attach the faceplate of the right tray.




 x1

d223c1060

Left Tray Side Fences

1. Disconnect Tray 1 faceplate [A].



 x3

d223c1061


2. Remove the Tray 1 faceplate.



d223c1062

3. Disconnect the motor cover:


- Right [A].
- Left [B].



 x5


d223c1063

4. Remove motor cover [A].




d223c1064


5. Pull the left tray out until it stops.
6. Disconnect the left tray from the left rail [A].
7. Pull left tray [B] slightly more until it stops.



8. Disconnect
 - Left [A] of rear side fence.
 - Left [B] of rear side fence.




9. Disconnect right end [A] of rear side fence.




10. Lift the rear side fence out of the front slot (LT), and then set it in the rear slot (A4).



d223c1068

11. Re-attach the screw at the left end of the side fence, and then re-attach the screws at the right end of the side fence ( x4).
12. Disconnect the marker plate at LT, and then reset the screw at A4. This serves as a reminder for the paper setting of the tandem tray.



d223c1069


13. Re-attach the left side of the tray to the left rail.




 x2

d223c1070

- 14. Disconnect left side [A] of the left tray front fence.
- 15. Disconnect the base of the front fence from the base of the tray [B].




 x4





d223c1071

- 16. Lift the front side fence out of the rear slot (LT), and then set it in the front slot (A4).




d223c1072


17. Re-fasten the front fence ( x4).
18. Set the motor cover over the front side fence, and then re-attach the left side [A] of the cover.
19. Re-attach right side of the cover [B].


 x2

 x3

d223c1073

20. Set the base of Tray 1 faceplate [A], and then re-attach it to the tray [B] ( x3).




Adjust Left Tray Paper Position for LT/A4


1. The left tray paper sensor is below the rear plate [A] in the left tray.



2. Remove rear plate [A].



3. Remove the screw of the sensor bracket, and then slide the bracket from the left (LT) to the right (A4).
4. Re-attach and tighten the screw.



2

Level the Machine

1. There are two pairs of shoes for leveling the machine, the front shoes [1] (attached brackets) and rear shoes [2].



d223c1078

2. Open the bottom drawer and remove the paper cassette.



d223c1079

3. Position the front shoes (with the brackets) under the front of the machine.
4. Run the brackets down with your fingers, and then tighten with the accessory wrench.



d223c1080


5. At each rear corner, run the hex screw down with your fingers, and then slide a shoe under the screw.
6. Tighten the screw with the accessory wrench.



d223c1081

7. Raise the ADF.

8. Place a level on the front edge of the exposure glass [A], and then on the right edge of the exposure glass [B].




d223c1082

9. The machine should be level:
- Front to back: Within ± 5 mm (0.2") of level
 - Right to left: Within ± 5 mm (0.2") of level
10. If necessary, use the accessory wrench to adjust the height of the machine at each corner.

Attach Cleaning Cloth Holder

1. Clean the upper, right front corner of the machine [A] above the bypass tray with a clean damp cloth.
2. Peel the tape from the back of the cleaning cloth holder [B]



d223c1089

3. Attach the holder at the upper right corner of the machine, and then put the cleaning cloth in the holder.



d223c1090


Connect Drum Heater, Tray Heater (Optional)

The drum heater and tray heater prevent moisture from gathering on the surface of the drum and in the paper feed trays. Connect these heaters where humidity is extremely high or where there are wide and rapid changes in temperature that could form condensation inside the machine.

1. Loosen (do not remove!) the bottom screws of the rear upper cover [A].



2. Disconnect the rear upper cover at the right rear corner [A] and left rear corner [B].



3. Remove rear upper cover



d223c0020

4. Now, remove the rear lower cover.



d223c1083


5. At the right, lower corner [A]:

- Loosen shoulder screw [1].


- Remove screw [2].

6. At the left, lower corner [B]:


- Loosen shoulder screw [3].
- Remove screw [4].



7. Remove the rear lower tray.




8. At the left lower corner [A], locate the heater connectors [1] and [2].




d223c1086

9. Free the heater connectors [1] and [2] [A], and then locate their connection points on the corner of PSU [B].




d223c1087

10. Connect both harnesses.



d223c1088

11. If you want the anti-condensation heaters to remain on at all times, detach the third harness from the bundle, then connect to the same PCB at **CN930**.




 x1

d223c1117

Load Paper, Attach Decals

Paper Size Decals

1. Load the paper trays.
2. At the upper right corner of each tray [A], clean the area below the tray number.
3. Peel the appropriate decal [B] from the accessory sheet and attach it to the tray.



d223c1092


Original Decals

1. Use a damp clean cloth to wipe clean the surface of the original feeder.
2. Attach the precautions decal to the feeder cover




2

3. Attach the 'load originals face-up' reminder to the original output tray.



Attach Name Plate

1. Attach the nameplate to the center of the front door.



Initialize Toner and Process Control Settings

1. Make sure that the power cord is attached to the right lower corner of the main machine.
2. Plug the power cord into the power source.

Note

- There is no power switch on the operation panel of this machine.

3. Open the front door.

Important

- The front door must remain open until you are instructed to close it.
- The open front door prevents the machine from doing automatic process control normally executed every time the machine is turned on.

4. Make sure that the front door is open.
5. Press the power switch [A] on the front left corner of the machine to turn the machine on.



d223c1096

You will see "Please Wait" until the Program/Change Administrator screen appears.



d223c1097

- The machine is waiting for entry of the Supervisor and Administrator passwords.
 - It is the responsibility of the site supervisor and system administrator to set these passwords.
 - The Home menu will not display until these passwords have been set. However, you can bypass this screen to complete the installation.
6. Enter the SP mode.
 7. Close the front door.
 8. Do **SP5755-002**. This cancels the password request screen and allows you to continue with the machine installation as long as the machine remains on.

 **Note**



- For more information about setting the passwords, see "Important Notice on Security Issues" in this section.
9. While still in the SP mode, open **SP2963-002**
 10. Enter the lot number of the developer. (This is the number embossed on the edge of the developer pack.)
 11. Open **SP2963-001** and then touch [Execute]. This initializes toner supply and sets up the auto process control settings. This will require about 4 min.
 12. When you see the "Completed" message, touch [Exit].
 13. Press [Exit] twice to exit the SP mode.

Check Image Quality and Settings

Checking the copy image with the test chart

Check the copy image with the test chart.

Date/Time Setting and Other SP Settings

1. On the operation panel press  >  > User Tools
2. Touch [Machine Features].
3. On the operation panel, press the User Tools.
4. On the touch-panel, press "System Settings".
5. Press the "Timer Setting" tab.
6. Press "Set Date" to enter the date.
7. Press "Set Time" to enter the time.
8. You may also need to do the following SP code settings.


SP5812-001	Service Telephone Number Settings. Enter the contact number of the customer engineer. This is the number displayed when a service call is issued.
SP5841-001	Supply Name Setting – Toner Name Setting:

Important Notice on Security Issues

In order to increase the security of the MFP, and to ensure that the customer sets the administrator password, an administrator set/change prompt display appears the first time the machine is turned on.

Overview

The Program/Change Administrator screen appears when the machine is turned on if the passwords have not been set. This is a new security feature.



d223c1097

- After the customers set the administrator/supervisor login password, the Home display every time the machine is turned on.
- However, setting these passwords is not mandatory. The customer disable the Program/Change Administrator screen if they choose not to set passwords

Canceling Password Setup

1. On the Program/Change Administrator screen, press [Change] next to Supervisor and then touch [OK] without inputting any password.
2. Touch [OK] again when the Confirm password display shows up.
3. For Administrator 1, do the same procedure as steps 1 and 2.
4. Press the [OK] button. The Home display appears.

- SP5-755-002 allows the service technician to skip this screen temporarily and continue the installation procedure without setting an administrator password.
- However, the Program/Change Administrator screen appears every time the machine is cycles off/on if the password has not been set.

Password Setting Procedure

2

Follow this procedure to set the passwords.

- If the Supervisor/Administrator passwords (up to four passwords) are set up through the network, the "Change Supervisor login password" window will not appear.
 - The passwords for Supervisor or Administrator can be set with "System Settings", but the Program/Change Administrator screen appears every time the power switch is turned on if the passwords are set up this way.
 - Therefore, we recommend that customers set passwords through the network or with the Program/Change Administrator screen.
1. Install the main machine.
 2. Turn the main power switch on
 3. Change the Supervisor login password.



4. Input the password.
5. Press [OK].
6. Confirm the Password.
7. Press [OK].
8. Change the Administrator 1 login password.



d223c1099

1. Input the password.
2. Press [OK].
3. Confirm the password.
4. Press [OK].
5. Cycle the machine off/on.

Auto Remote Firmware Update Settings

Specify ARFU settings as required.

Operating Conditions:

- Use the machine in an environment where it can be connected to the Internet.

↓ Note

- Auto Remote Firmware Update (ARFU) requires connection to an external network. Be sure to get permission from the customer before setting ARFU up.
- The connection is one-way, so the user's data will not be accessed from the global server.

Pre-Operation Set Up and Checks

1. Check the network settings (IP address, Subnetmask, Gateway, and DNS).
2. Check the proxy settings.
3. In the environment to execute ARFU, check that the machine's main power is always turned on and it is always connected to the Internet.
4. This condition is required for downloading the firmware package in the background and also for updating the firmware by ARFU when the machine is turned ON for the first time at machine installation.
5. Check the time (day of the week and time) to prohibit the execution of ARFU.

★ Important

- If the access to the external server is restricted, request the network administrator (customer) to permit the following FQDN name for communication:
- - FQDN: p-rfu-ds2.support.ricoh.com

Configuration Procedure

1. In **User Tools > Machine Features > System Settings > Interface Settings**, specify the IP address, Subnet, Gateway, and DNS settings according to the user's network environment.

★ Important

- Make sure to specify the DNS settings. To acquire the firmware data, it is necessary to have the host name resolved so that access to the global server is possible using the host name.
1. Check the user's network environment and, as required, specify the proxy server settings in the following SPs:
 - SP5-819-062 (Use Proxy DFU(SSP))
 - 1: Use / 0: Not use
 - SP5-816-063 (Use Proxy DFU(SSP))
 - SP5-816-064 (Proxy Port Number)
 - SP5-816-065 (Proxy User Name)
 - SP5-816-066 (Proxy Password)

↓ Note

- They can be specified also via Web Image Monitor, from Device Management>Configuration>Device Setting>Auto Firmware Update. (However, "Auto Firmware Update" appears on Web Image Monitor only if the ARFU function is set to "ON".)

1. Set SP5-886-111 (AutoUpdateSetting) to "1(ON)"**↓ Note**

- To download the firmware only using SFU, and not by ARFU, specify the settings as follows:
 - SP5-886-111 (AutoUpdateSetting) to "0 (OFF)"
 - Set SP5-886-115 (SfuAutoDownloadSetting) to "1 (ON)"

1. When setting the prohibited day, time and so on of the auto firmware update, set them with following SPs, or Web Image Monitor.

- SP5-886-112 (AutoUpdateProhibitTermSetting)
- 0: OFF, 1: ON (Default)
- SP5-886-113 (AutoUpdateProhibitStartHour)
- Default: 9

- SP5-886-114 (AutoUpdateProhibitEndHour)
- Default: 17
- SP5-886-120 (AutoUpdateProhibitDayOfWeekSetting)

Default: 0x00

Set the bits for the days of the week to prohibit updating.

Prohibited (Monday - Sunday): Bit 7

Monday: bit 6

Tuesday: bit 5

Wednesday: bit 4

Thursday: bit 3

Friday: bit 2

Saturday: bit 1


Sunday: bit 0

e.g.) Prohibited on Mon., Fri., Sat., and Sun.: 0x47 (01000111)

1. Use the machine with its main power on and connected to the Internet.


Specifying the Times, Days of the Week to Prohibit Updating by Web Image Monitor

1. Start the Web Image Monitor.
2. Log in as the machine administrator.
3. Point to [Device Management], and then click [Configuration].




d238m0983e

4. Click "Auto Firmware Update".



d238m0984j


5. In the applicable items, specify the times and days of the week to prohibit updating. Select the check boxes of the applicable days of the week to prohibit updating on that day



d238m0985e

Checking the ARFU Connection

1. Enter the SP mode.
2. Press [Firmware update].
3. Press [Update].
4. Press [Execute update].



d238m0986e

- "Execute update" appears even if @Remote connection has not been established.
- If an error code appears when you click "Execute update", the machine is in the following status.

Error code	Status
E51	The machine in operation for printing, etc.
E71	Network connection error

1. Check if one of the following messages appears: "Will you download the latest package Ver *** and update?" or "The installed package is the latest version."
 - If the message appears, it is possible to execute ARFU: Press "No" and close SP mode to complete the configuration.
 - If the message does not appear, it is not possible to execute ARFU: Check the network settings again.

↓ Note

- SP5-886-116 (Auto Update Prohibit Term Setting) displays the scheduled date and time of the next ARFU.
- If the scheduled date and time of the next ARFU coincides with a time and day of the week when ARFU is prohibited, the machine sends an inquiry to the server to check if there is a new firmware package at this time. If there is a new firmware package, it is downloaded in the background, but the package updating is cancelled and executed on the next occasion, 76 hours later, to update the package.

Checking the Result from the Firmware Update Setting

1. Enter the SP mode.
2. Press [Firmware update].
3. Press [Update].
4. Press [Update Package Information].
5. If the firmware package is the same as the one on the global server, the update was completed successfully. Otherwise, check the result using the logging data.

Note

- In SP7-520-041 to -045 (Update Log: Auto:Version), you can check the versions of the packages updated by ARFU. (-041 displays the latest result. It is also printed on the SMC sheet.)

Checking the Result Using the Logging Data

1. Enter the SP mode.
2. Press [System/Copy].
3. Check the results for ARFU by SP7-520-051 to 060 (Update Log: Auto:Result) "-051" is the latest update result.

Security Settings

The machine has two security functions built into the controller board: Data Overwrite Security and HDD Encryption. However, these features must be activated at completion of installation if the client wants to use them. page 429

Moving the Machine

Important

- When moving the machine, never push on the ADF.
- Pushing on the ADF could damage it or throw it out of alignment, causing problems with scanning and copying.

Do the procedure below before moving the machine from one floor to another. See "Transporting the Machine" in the next section if you have to pack the machine and move it to a distant location.

1. Turn the main power OFF and disconnect the power plug.
2. Close all the covers and trays.
3. Disconnect peripheral units connected to the main machine: LCIT, Finishers, etc.
4. Keep the machine horizontal and move it slowly.

5. To avoid damage to the machine, avoid tipping and excess vibrations.

Transporting the Machine

★ Important

- When moving the machine, never push on the ADF.
 - Pushing on the ADF could damage it or throw it out of alignment, causing problems with scanning and copying.
1. Do SP4-806-001 to move the scanner carriage from the home position. This prevents dust from falling into the machine during transportation.
 2. Remove the toner cartridge. This prevents toner leakage caused by vibration during transport.
 3. Remove all paper from the paper trays.
 4. Attach a sheet of paper to the bottom plates of the tray to hold them in place during transport.
 5. Take out the scanner stay from inside the front cover and install the scanner stay.
 6. Fasten the front door and covers with shipping tape, and then shrink-wrap the machine tightly.

Important SP Codes: Installation

Here is a summary of important SP codes that you will need for installation of the main machine.

Item	SP No.	Function
Data Overwrite Security	5878-1	Enables/disables the Data Overwrite Security feature. Check this setting to confirm whether this feature is turned on or off. Cycle the machine off/on after changing this setting.
Developer lot number	2963-2	Enter the lot number embossed at the top edge of the developer package. Enter the lot number with SP2963-2 before you initialize developer with SP2963-1
HDD Encryption	5878-2	Enables/disables data encryption. Cycle the machine off/on after changing this setting.
Initialize developer	2963-1	Initializes fresh developer at installation. Enter the lot number with SP2963-2 before you initialize developer with SP2963-1

Item	SP No.	Function
Password request cancel	5755-2	Cancels the password request screen and allows you to continue with the machine installation as long as the machine remains on
Service tel. number	5812-1	Enter the contact number of the customer engineer. This is the number displayed when a service call is issued.
Supply name setting	5841-1	This name appears when the user presses the Inquiry on the User Tools screen.
Transport	4806-1	Move the scanner carriage from the home position. This prevents dust from falling into the machine during transportation.

Drum Heater (Option)

Accessories

The drum heater is an option for the main machine. Check the accessories and their quantities against this list.

No.	Description	Q"ty
1.	Drum Heater	1
2.	Screws M3x6	2




d223c1131

Installation

Install Drum Heater

1. Open the front door, and then swing the toner bottle holder to the right.
2. Remove development unit [A]. page 623
3. Remove charge corona unit [B]. page 574




d223c1132

4. Remove drum unit [A]. page 582
5. Remove transfer belt unit [B]. page 674




d223c1133

6. The drum heater harness [A], shown here on the back of the machine behind the IOB, is pre-installed at the factory before shipping.
7. At the front, drum heater harness connector [B] at the back of the machine can be seen where the transfer belt unit was removed.




d223c1134

8. If lever C1 is down to the left, turn it to the right.



d223c1135


9. Unfasten stay [A].



 x1


d223c1136

10. Remove the stay. **Keep this screw.**



d223c1137


11. Lay the stay on a flat, clean surface as shown with rear end [A] to the right.
12. Set the drum heater next to the stay with the connector [B] to the right.
13. Set the heater on the stay, and fasten it with screws.



 x2


d223c1138

14. Inside the machine, locate the cutout [A] where the rear end of the stay with the connector will be inserted.
15. The heater will be connected at [B] with the hook lever up.



d223c1141

- 16. Insert the rear end of stay [A] into the cutout inside the machine.
- 17. At the front [B] fasten the stay.



 x1

d223c1142

- 18. Connect the heater at the rear



 x1

d223c1143


19. Re-install:

- Transfer belt unit
- Drum unit
- Charge corona unit
- Development unit

Connect the Drum Heater

The harness for the drum heater is installed at the factory before shipping.


1. Remove the rear lower cover. page 483
2. At the left rear corner of the machine, locate the DHB [A] below the AC control board.
3. Plug connector [B] into the open connector of the DHB.



 x1

d223c1149

If the connector is already plugged into the DHB as shown below, you are finished.



d223c1150

- This dual connector shared by both the drum heater harness and scanner harness.
- If the scanner heater has been installed, this connector will already be connected to the DHB.
- When the single connector is plugged in, both the drum heater and scanner heater are connected.


Scanner Heater (Option)

Accessories

The scanner heater is an option for the main machine. Check the accessories and their quantities against this list.

2

No.	Description	Q'ty
1.	Scanner Heater	1
2.	Screws M3x6	2



d223c1120

Installation

Install Scanner Heater


1. Raise the ADF.
2. Disconnect the rear end of the right edge cover [1].
3. Slide the cover to the rear [2].
4. Remove the cover [3].



 x1

d223c1121


5. Remove the rear scale.



 x3

d223c1122


6. Remove the left exposure glass edge cover.



 x2


d223c1123

7. Remove the exposure glass.




d223c1124

8. At the right front corner of the machine [A] turn the scanner motor belt and move the 1st scanner unit to the left edge of lens cover [B].




d223c1125

9. With the harness on the left, slide scanner heater [A] under the 2nd carriage, and then arrange it parallel to the back of the scanner unit [B].




d223c1126

10. Pull the heater harness through the left side of the scanner unit.




d223c1127

11. Disconnect the left edge cover [A], and then remove it, so you can see cut-out [B].




d223c1128

12. Insert a screwdriver into the cut-out [A], and then **loosely** fasten the left end of the heater.
13. Attach the right end of the heater [B].
14. Tighten both screws.




15. On the left side of the scanner unit, clamp the heater harness, and then connect it to the harness pre-installed on the side of the machine.




Connect the Scanner Heater

1. Remove the rear lower cover. page 483
2. At the left rear corner of the machine, locate the DHB [A] below the AC control board.
3. Plug connector [B] into the open connector of the DHB.



d223c1149

If the connector is already plugged into the DHB as shown below, you are finished.



d223c1150


- This dual connector shared by both the drum heater harness and scanner harness.
- If the drum heater has been installed, this connector will already be connected to the DHB.
- When the single connector is plugged in, both the drum heater and scanner heater are connected.

A3/11"x17" Tray Type 9001 (D482)

Accessory Check

Check the accessories and their quantities against this list:

No.	Description	Q'ty
1.	A3/DLT Tray	1
2.	Short connector	1
3.	Page size decals	1




b475i001

Installation Procedure


⚠ CAUTION

- Switch the machine off and unplug the machine before starting the following procedure.


1. Remove the stay [A] (⊗ x 2).
2. Remove the retainers [B] [C].




3. Draw out the tandem tray [A] completely to separate the left and right sides of the tray.
4. Push in the right tandem tray [B].




5. Remove the left tandem tray [A]. **Keep these screws.**




6. Remove the front cover [A].



7. Remove the right tandem tray [A] ( x 2). **Keep these screws.**




8. Connect the short connector [A] to the left tandem tray terminal [B].



d482i201

9. Install the A3/DLT tray [A] on the right rail [B], center rail [C], and left rail [D]. Use the screws that you removed earlier.



Note

- You must use the short, silver screws on the left and right rails. If you use one of the longer screws, it will stop the movement of the tray on the rails.


10. Re-install the front cover.
11. Switch the machine on, enter the SP mode and select the paper size for Tray 1 with **SP5959-001** (Paper Size – Tray 1). For details, see SP5959 in "Service Tables".
12. Attach the appropriate decal for the selected paper size.

LCIT RT4040 (D3D6)

Accessory Check

Check the accessories and their quantities against this list:

No.	Description	Q'ty
1.	Upper docking pins (grooved)	2
2.	Lower docking pin (not grooved)	1
3.	Flat-head shoulder screw - M4 x 6	1
4.	Paper Set Decal	1
-	Installation Instructions	1



d3a6c1001

★ Important


- Handle the LCIT unit carefully, especially when you are pushing it around the floor. The LCIT is unbalanced and tips easily because it has only three wheels.
- Never attempt to move the machine with the LCIT attached to the right side of the machine. Separate the main machine and LCIT before moving to a new location.

Installation

Removing Tape


1. Remove all tape and packing material on front [A] and right side [B].

2



d3a6c1002

2. Remove tape and cardboard from [A] and right side [B]. Be sure to retrieve the accessories packed in the plastic bag taped to the rear panel.



d3a6c1003

3. Open the unit.
4. Remove tape from around the lift plate [A] and under the top cover [B].



d3a6c1004

5. Inspect the unit outside, inside [A], and under the cover [B] to confirm that there is no tape, cardboard, or scraps remaining in the LCIT.



d3a6c1005

Preparing the Main Machine

⚠ CAUTION

- Switch the machine off and unplug the machine before starting the following procedure.

1. On the right side of the main machine, remove the LCIT installation cover.



 x2


d3a6c1006

2. Remove the LCIT connector cover.




d3a6c1007

3. On the same side of the machine, remove the three docking pin hole covers [1], [2], [3].



d3a6c1008

4. Select the two grooved docking pins [A], and then attach them at [B].
5. Attach the remaining docking pin at [C].



d3a6c1009

Docking the LCIT

1. Slowly, push the left side of the LCIT against the side of the main machine.



d3a6c1010

2. If you need to release the LCIT and try again, push the release button and then pull the LCIT away from the side of the main machine.




d3a6c1011

3. Open the top cover of the LCIT.



d3a6c1012

4. Remove the right panel [A].



 x4

d3a6c1013

5. Look inside the LCIT and locate the hole for the shoulder screw.




d3a6c1014

6. Set the flat-head shoulder screw [A] on the tip of a screwdriver, and then fasten in the hole behind panel [B].



 x1



d3a6c1015

★ Important

- This screw locks the release button on the front of the LCIT.
 - In order to separate the LCIT from the main machine, you will need to first remove this screw.
 - After you have removed the screw you can press the release button, and then pull the LCIT away from the main machine.
7. If the screw falls, press the release button [A] of the front of the LCIT. Pull the LCIT away from the main machine. You should see the screw at [B] near the ground plate.



d3a6c1016

8. Plug the LCIT power cord into the connector.




d3a6c1017

Paper Size Adjust and Setting

The side fences [A] and [B] can be adjusted for different paper sizes:

- A4 LEF
- B5 LEF
- LT LEF




d3a6c3009

1. Open the top cover of the LCIT.



d3a6c2017

2. Remove the right panel of the LCIT.



 x4

d3a6c2018


3. If the LCIT is connected to the main machine, remove the lock screw.



 x1

d3a6c2019

4. Press the release button on the front of the LCIT [A], and then pull the LCIT slightly away from the side of the main machine, but do not disconnect the LCIT I/F cable.




d3a6c2020

5. If the LCIT is disconnected, connect the I/F cable to the main machine [A], and then turn the machine on.
6. You must disconnect front fence [1] and rear fence [2], but these fences cannot be removed with tray plate [B] in the up position.



d3a6c2041

7. Confirm that the main machine is on, and that the LCIT is connected to the main machine.
8. To lower the tray plate, cover photosensor [1] with your left hand, and then press and hold down button [2].




d3a6c2042

9. Keep the sensor covered and the button depressed until the tray plate reaches bottom and the motor switches off. You can now remove the fences.




d3a6c2043

10. Unfasten and remove rear fence [A].




 x1



d3a6c2044

11. Unfasten and remove front fence [A].



12. Set the bottom edge of each side fence into the slot for the paper size that you want you load into the LCIT
13. Set the notches at the top of each side fence at the name of the paper size.
14. Fasten the side fences at the top, and then re-assemble the LCIT.
15. Load some paper in the LCIT.
16. Turn the machine on.
17. Open **SP5959-005** (Paper Type - Tray 4), and then select the paper size you have selected with the side fences.

LCIT Heater (Option)


Accessories

Check the accessories and their quantities against this list:

No.	Description	Q'ty
1.	LCIT Heater	1
2.	Bracket	1
3.	Clamps	6
4.	Screws M3x6	4
5.	Ground Wire	1
6.	Ground Screws – Pan Head	2

No.	Description	Q'ty
7.	Flat Clamps	2
8.	LCIT Heater Harness	1

2



d3a6c2001

Installation


LCIT Side

1. Turn the machine off.
2. Open the top cover of the LCIT.



d3a6c2017

3. Remove the right panel of the LCIT.



 x4

d3a6c2018


4. If the LCIT is connected to the main machine, remove the lock screw.



 x1


d3a6c2019

5. Press the release button on the front of the LCIT [A], then then pull the LCIT slightly away from the side of the main machine, but do not disconnect the LCIT I/F cable.




d3a6c2020

6. If the LCIT is disconnected, connect the I/F cable to the main machine [A], and then turn the machine on.
7. You must remove front fence [1] and rear fence [2], but these fences cannot be removed with tray plate [B] in the up position.



d3a6c2041

8. Turn the machine on, and confirm that the LCIT is connected to the main machine.
9. To lower the tray plate, cover photosensor [1] with your left hand, and then press and hold down button [2].




d3a6c2042

10. Keep the sensor covered and the button depressed until the tray plate reaches bottom and the motor switches off. You can now remove the fences.




d3a6c2043

11. Unfasten and remove rear fence [A].




 x1




d3a6c2044

12. Unfasten and remove front fence [A].



13. After both fences have been removed, close the top cover [A].

14. The lift motor will switch on and raise the tray plate to the up position [B]. This will take about 30 sec.




15. At the left bottom edge of the LCIT, remove the stay.




16. Remove left screws [A] of the positioning plate inside the LCIT.

17. Inside the LCIT [B] unfasten the positioning plate.




 x2



 x3


d3a6c2022

18. Remove the positioning plate.



d3a6c2023


19. Attach the clamps to the bottom of the LCIT.



20. Set the LCIT heater, and then pass the heater harness under the rear side of the shaft.



21. Set accessory bracket [A], position the bracket [B] over the harness, and then fasten it.



22. Fasten the heater with the accessory screws.



23. Insert the bayonet connector [1] into the cut-out in the frame.

24. Lay the harness in the open clamps [2] and then close the clamps.



25. Re-assemble the LCIT in reverse order. This completes preparation on the LCIT side.




d3a6c2008

2

Main Machine Side

↓ Note

- The machine is shipped from the factory with main machine upper and lower paper bank heaters (standard) disconnected.
 - These heaters are pre-installed but may or may not be connected in your machine. However, the procedure below starts with the main machine tray heaters connected.
1. Remove the rear covers. page 482
 2. Unfasten the IOB mounting bracket, and then swing it open.




d3a6c2031

3. Open the clamps at the top and right edge of the AC drive board [A].
4. Pull out the upper heater harness [B] of the main machine.

Note

- The upper heater harness has the box receptacle [1] at the top and bayonet connector [2] at the bottom.



x4 d3a6c2024

5. One end of the LCIT harness has two connectors: box receptacle [1] and bayonet connector [2].




d3a6c2025

6. Disconnect the main machine upper heater harness.




d3a6c2026

7. Insert the bayonet connector [1] of the connector pair on the end of the LCIT heater harness to the box receptacle [2] of the upper heater harness.
8. Insert the bayonet connector [3] of the upper heater harness into the box receptacle [4] of the LCIT heater harness pair.




d3a6c2027


9. At the bottom right corner of the AC drive board [A], confirm that the heater harness (Blue) is connected to the DHB (Drum Heater Board).
10. If the other connector (White) for the drum/scanner heater harness is disconnected (not being used), clamp this harness at [B].




- 11. Clamp the connectors [A] as shown.
- 12. Raise the heater harness and clamp it [B].




- 13. Raise the LCIT heater harness, and clamp it at the top edge of the AC drive board [A].
- 14. Raise the LCIT heater harness through the hole in the frame [B].



15. Clamp the LCIT heater harness behind the IOB.




16. Behind the IOB, push the LCIT heater harness behind the stay [A], and then pull it out under flywheel [B].



d3a6c2033

17. Pull the LCIT harness below the flywheel [A] and then clamp it [B].




 x3

d3a6c2034


18. Disconnect stopper [A] on the base of the toner collection pump.

19. Pass the harness under arm [B] of the base, and then re-fasten the stopper.



d3a6c2035

20. Clamp the harness at [A], and then push it out the right side of the main machine [B].




21. Pull the harness out of the main machine, and then clamp it.



This completes preparation on the main machine side.

Docking

1. Before you dock the LCIT to the main machine, make sure that you have completed the procedures above to prepare the main machine side [A] and LCIT side [B].




d3a6c2009

2. Hold the ground wire straight up, and then fasten it tightly.



d3a6c2010

3. Measure the positions for the flat clamps on the left side of the LCIT.
4. Attach the flat clamps to the left face of the LCIT.



d3a6c2039

5. Remove the left upper plate from the LCIT.




 x2




d3a6c2038

6. Pass the end of the harness through saddle clamp [A] and then clamp it.

7. Re-attach the left upper plate [B].



 x1



 x2

d3a6c2040


8. Connect the harness from the main machine to LCIT heater.

9. Clamp the harness to the left side of the LCIT.




d3a6c2012

10. Connect the ground wire to the side of the main machine near the joint connector, at about a 45 degree angle as shown.




d3a6c2013

11. Push the LCIT [A] close to the side of the main machine.
12. If there is any slack in the harness pull it down [B].




d3a6c2014

13. Push the LCIT [A] onto the joint pins on the side of the main machine.
14. Connect the LCIT [B] to the main machine.



d3a6c2015

15. Set the flat-head shoulder screw [A] on the tip of a screwdriver, and then fasten in the hole behind panel [B] to lock the LCIT against the side of the main machine.



 x1

d3a6c1015


16. Re-attach the right panel of the LCIT.
This completes installation of the LCIT heater.

8 1/2"x14" Paper Size Tray Type 9002 (B474)

Accessory Check

Check the accessories and their quantities against this list:

No.	Description	Q'ty
1.	Cover	1
2.	B4/LG frame	1
3.	Bottom plate extension	1
4.	Rear bracket	1
5.	Front bracket	1
6.	Harness clamp	1
7.	Tapping hex screws - M4 x 8	6
8.	Tapping screws - M4 x 8	4




b474i001a

Installation Procedure

1. If the LCT is connected to the machine, open the cover and remove the paper.
2. To lower the LCT tray, cover the near end sensor [A] with one hand, and then press the tray down button [B].

2




b474i507

CAUTION

- Switch the machine off and unplug the machine before starting the following procedure.

3. Disconnect the LCT from the machine.
4. Remove the LCT cover [A].
5. Remove the right cover [B].
6. Remove the right stay [C] at ❶ and re-attach it below at ❷.




7. Attach the front bracket [A] with the beveled corner down.

Note

- If the brackets are difficult to install, raise the bottom plate with your hand.


8. Attach the rear bracket [B] with the beveled corner down.

9. Attach the bottom plate extension [C] with the hex nuts.




10. Align the positioning pin [A].

11. Attach the B4/LG frame [B] with the hex nuts.




★ Important


- The kit is set for B4. If you need to change the paper size to LG, do the following steps.
12. Move the front side fence [A] to the LG position and fasten.
 13. Move the rear side fence [B] to the LG position and fasten.



14. Change the position of the lower limit sensor [A].



15. Attach the harness (not shown) to the back of the plate and secure the sensor connector wire.
16. Attach the LCT cover [A] provided with the kit.
17. Re-attach the right cover [B].




18. Connect the LCT to the machine.
19. Switch the machine on, enter the SP mode, then use **SP5959 005** (Paper Size – Tray 4 (LCT)) to select the new paper size. For details, see **SP5959** in "Service Tables".

Multi-Folding Unit FD4000 (D615)

Accessories

Check the quantity and condition of the accessories in the box against the following illustration and list.



No.	Description	Q'ty
1.	Joint Bracket	1
2.	Paper Guide – Long	1
3.	Paper Guide – Short (D131/D132/D133)	1
4.	Proof Tray Auxiliary Plate - Bottom	1
5.	Ground Plate	1
6.	Screws M3x6	2
7.	Screws M3x6	2
8.	Screws M4x20	4
9.	Screws M4x14	4
10.	Leveling Shoes	5

No.	Description	Q'ty
11.	Power Cord* 1	1
12.	Sponge Strip	1

*1: In China, do not use the power cord provided with this unit. Contact your supervisor and use the power cord specified for use in China.

2


Installation

⚠ CAUTION

- The unit must be connected to a power source that is close to the unit and easily accessible.
- Make sure that the main machine is switched off and that its power cord is disconnected before doing the following procedures.


Tapes

1. Remove all tape and packing material from the front, left, rear, and right sides.




d615i108

2. Open the front door [A].
3. Grip handle [B] and slowly pull the fold unit out of the machine.



d521i102


4. Remove all tape and packing material from inside.
5. Remove the tape from the bottom of the door [A].
6. Pull out the folding unit [B] and remove the tapes.



d521i103


Paper Guide, Sponge Strips

1. Select the short paper guide [A] and attach it.
2. Peel the tape from the sponge strip [B] and attach the strip to the top right edge of the unit.




Ground Plate

1. Attach the ground plate [A] to the lower right edge of the unit.



Docking


1. Fasten the joint bracket [A] to the left side of the upstream unit.



2. Open the front door [A].
3. At the front right corner, remove the screw of the lock bar [B]. **Keep this screw.**
4. Pull out the lock bar.


Note

- If you are docking to the main machine, you must first remove the plastic cap at the I/F cable connection point.
5. Slowly push the unit [C] against the left side of the upstream unit (or main machine) so that the lock bar is directly and squarely under the arms of the joint bracket.
 6. Push in the lock bar so it slides up into the notches in the arms on both ends of the joint bracket [D].
 7. Fasten the lock bar by re-attaching the screw removed in **Step 3**.
 8. Connect I/F cable [E] to the upstream unit (or main machine).



Power Cord

1. Insert the power cord socket [A] into the power connection point.




★ Important

- In China, do not use this power cord provided with this unit. Contact your supervisor and use the power cord specified for use in China.

2. Connect the power supply cord plug to a power outlet.

Finishing the Installation


1. Set the leveling shoes and adjust the height of the unit.



2. Load some B4 paper in the 2nd tray of the main machine, and make several copies.
3. Check paper skew and side-to-side registration and correct if necessary.

Proof Tray Auxiliary Plate

1. Install the proof tray auxiliary plate.
 - Set the plate [A] in the center aligned with the diagonal groove.
 - The back should be flat against the end fence.
2. When the plate is not being used, open the front door and store the plate at [B] inside the inner cover.



- The plate should be used when Z-folded paper (all sizes) is output to the proof tray.
- If the plate is not used with Z-folded output, the pages could mix and overlap.


Finisher SR4080 (D610)

Accessory Check

Check the accessories and their quantities against this list:

2

No.	Description	Q ^{ty}
1.	Cushion	1
2.	Table Extension	1
3.	Leveling Shoes	1
4.	Rear Joint Bracket	1
5.	Front Joint Bracket	1
6.	Entrance Guide Plate	1
7.	Grounding Plate	1
8.	Auxiliary Tray Holder	2
9.	Auxiliary Tray - Proof	2
10.	Auxiliary Tray - Shift	2
11.	Tapping Screws - M4 x 8	2
12.	Tapping Screws - M3 x 6	4
13.	Tapping Screws - M3 x 8	4
14.	Phillips Screws with washer - M4 x 14	4
15.	Shift Tray	4



Installation


⚠ CAUTION

- Turn the machine off and unplug the power cord.
1. Unpack the finisher and remove all tapes and shipping retainers from the exterior of the finisher.




d610c1001

3. Remove tape and cardboard from behind and on the stacker unit [A].
4. Remove tape and shipping material [B] below the stacker unit.




d610c1002

5. Remove the three shipping brackets marked with wired red tags ( x6).




6. Pull the stacker unit out as far as it will go, and then remove the tape and cardboard from behind the stacker unit [A].
7. If the material [B] is difficult to remove from the front, on the right side of the finisher pull it down to remove it.




d610c1003

8. Check the exterior of finisher for remaining tape, and then remove it.



d610c1004

9. On the left side of the main machine, use the long screws to attach the joint brackets [A],[B] (🔩 x4) (M4 x 14).



d610c1005

10. Remove the connector cover on the left side of the main machine.




d610c1006

11. Skip this step if you are going to install the Cover Interposer Tray. (You will attach the ground plate later at another location during the Cover Interposer installation.)

-or-

If you are not going to install the Cover Interposer Tray, install the grounding plate [A] now (🔩 x 2) (M3 x 6).




b478i004

12. Set the screws and then push against the plate [A] so it is completely flat against the frame [B], and then tighten the screws. This ensures full contact for the ground.



d610c1007


13. Set the screws in the side of the tray, and then set the keyholes of the table extension [A] over the screws (Ⓜ x 2) (M4 x 8).




b478i005

14. With the extension slightly loose against the edge of the tray, align the end of the table extension with the edge of the finisher.
15. Tighten the screws.
16. Skip this step if you are going to install the Cover Interposer Tray. (You will attach the cushion later at another location during the Cover Interposer installation.)
-or-
If you are not going to install the Cover Interposer Tray, attach the cushion [A] to the right side of the upper cover.
17. Skip this step if you are going to install the Cover Interposer Tray. (You will attach the entrance guide plate later at another location during the Cover Interposer installation.)
-or-

If you are not going to install the Cover Interposer Tray, attach the entrance guide plate [B].



18. Attach the shift tray.




X4 M3x8

19. Open the front door of the finisher.


20. Push the finisher [A] close to the left side of the main machine [B].

21. Remove the lock lever screw [1], and then pull out the lock lever [2]. **Keep this screw.**



d610c1009

22. Align the finisher with the joint brackets on the left side of the main machine, and then push the finisher slowly against the main machine.
23. Make sure that the top right edge of the finisher is parallel to the top left edge of the main machine.



d610c1010

24. Push in the lock lever [1] until it stops, and then re-attach the screw [2].




d610c1009

- 25. Close the front door.
- 26. Connect the finisher I/F cable to the main machine.



d610c1012

- 27. Set the leveling shoes under the feet and level the finisher.



Auxiliary Trays

1. Set the shift auxiliary tray [A] on the shift tray when you expect folded paper from the Multi Folding unit to be output to the shift tray.




d610c1014

2. Set the proof auxiliary tray in the proof tray when you expect Z-folded paper from the Multi Folding unit to be output to the proof tray.



d610c1015

3. Peel the tape from the tray holder [A].
4. Attach the tray holder to the back of the finisher [B].



d610c1016

5. Store the auxiliary trays in the holder if they are not needed.

Punch Units (B531/A812)

This procedure describes installation of these punch units in the Finisher SR4080.:

- Punch Unit Type 1075 3/2 (B531)
- Punch Unit Type 1075 EU 2/4 (B531)
- Punch Unit Type 850 SC (A812)


★ Important

- These punch units can be installed and used with the Finisher SR4080 only.

Accessory Check

Check the accessories and their quantities against this list:


No.	Description	Q'ty
1.	Punch unit	1
2.	Harness Connector Cable - PCB	1
3.	Harness Connector Cable - HP Sensor 2	1
4.	Harness Connector Cable - HP Sensor 1, Hopper Full	1
5.	Sensor Arm and Sensor	1
6.	Spacer (2 mm)	1
7.	Spacer (1 mm)	2
8.	Spring	1
9.	Step Screw (large) (M4 x 11)	1
10.	Tapping Screw (M4 x 10)	2
11.	Step Screw (small) (M3 x 4)	1
12.	Machine Screw, Washer (M4 x 6)	1
13.	Knob	1
14.	Punch Waste Hopper	1




Installation

⚠ CAUTION


- Switch the machine off and unplug the machine before starting the following procedure.
1. If the finisher is connected to the machine, disconnect it.
 2. Open the front door and remove the rear cover.
 3. Unpack the punch unit and remove the motor protector plate [A] and the cam lock plate [B].
 4. Reattach the cover bracket [C] and [D].



5. Remove the inner cover [A].
6. Behind the inner cover at [B] and [C], press the lock tab to the right to release the inner cover from the frame.
7. Remove the plastic knockouts [D].



8. Remove the paper guide [A].




9. Install the sensor arm [A].


Note

- Make sure that the sensor arm swings freely on the step screw.

10. Attach the spring [B].




11. At the rear, position the 2 mm spacer [A] and attach the punch unit [B].



★ Important


- At the hole just above the lock lever, use one of the screws from the paper guide removed above to fasten the remaining two spacers to the frame.
- These extra spacers are used to adjust the horizontal position of the punch holes.

12. At the front, secure the punch unit [A] with the large step screw.
13. Attach the punch unit knob [B].



14. Connect the PCB harness connector [A] to CN129 of the finisher PCB and to CN600 of the punch unit PCB.
15. Connect the HP Sensor 2 harness connector [B] to CN130 of the finisher PCB and to HP Sensor 2.


16. Connect the single end of the hopper full sensor connector cable [C] to the hopper full sensor on the arm, and then connect the other two connectors to HP Sensor 1 [D] and CN620 [E] of the punch PCB.



Note

- No special DIP switch settings are required for this punch unit. The punch unit sends an identification signal to the machine, so it knows what type of punch unit has been installed.

17. Slide the hopper [A] into the finisher.



b531i008

18. Re-attach the inner cover and rear cover.
19. Close the front door and re-connect the finisher to the machine.

Output Jogger Unit Type 9002B (B513)

Accessory Check

Check the accessories and their quantities against this list:

No.	Description	Q'ty
1.	Jogger Unit B513	1
2.	Tapping Screws - M3 x 6	2
3.	Installation Procedure	1




b513c1001


Installation Procedure

★ Important


- This jogger unit for the Finisher SR4080 only.
1. Turn the main machine switch off and disconnect the finisher from the main frame.
 2. Use the flat head of a screwdriver to remove the left upper cover [A] from the finisher and then discard it.



3. Remove the cover plate [A] from the jogger unit. **Keep these screws.**



4. With the jogger unit harness and connector on the left, hook the frame of the jogger unit [A] into the holes on the left and right side of the finisher frame.
5. On the left, fasten the connector [B] to the socket.
6. On the left and right, attach the jogger unit frame to the side of the finisher with the accessory screws [C] (short screws).



7. Re-attach the jogger unit cover to its frame with the screws removed in Step 3.

Cover Interposer Tray CI4030 (D3D7)


This Cover Interposer Tray is designed to be installed and used with Finisher SR4070.

Accessories

2

Check the quantity and condition of the accessories in the box against the following list.

No.	Description	Q'ty
1.	Front door extension (top) * 1	1
2.	Rear cover extension (bottom)* 1	1
3.	Shoulder screws	3
4.	Tapping screws – M4 x 8	9
5.	Tapping screws – M3 x 8	2
6.	Machine screws – M3 x 6	5
7.	Plate Extension (bottom)	1
8.	Right Rear Cover Plate	1
9.	Gasket Seals	2
10.	Right front corner plate	2
11.	Anti-Static Brush	1
12.	Sponge Strip	1
13.	Auxiliary Tray Holder	1
14.	Front door extension (bottom) * 1	1




Installation

Finisher SR4080 Already Installed?



Do these procedures if the finisher is already installed on the main machine.

1. Turn the main machine off, and then disconnect it from the power source.
2. Unplug the finisher I/F cable at the rear right corner of the main machine [A].



d3d7c1003

- 3. Open the finisher door.
- 4. Remove screw [1], and then pull out the lock bar [2].




d3d7c1002

- 5. Pull the finisher away from the side of the main machine.




d3d7c1004

6. Remove the paper entrance guide from the right side of the finisher.



d3d7c1009

7. Set the paper entrance guide aside. You will install it at another location later.




d3d7c1010

8. Remove the sponge strip from the top right edge of the finisher, and then attach it to the top left edge of the main machine.



d3d7c1031


9. Remove the ground plate from the bottom right edge of the finisher [A], and keep the screws.



 x2

d3d7c1012



10. Set the ground plate and screws aside. You will install them at another location later.



d3d7c1013


Remove Tapes and Retainers

1. Remove all tapes and retainers from the exterior of the tray [A].
2. Remove tape and cardboard from the collar of connector [B].



d3d7c1005

3. Open the cover.
4. Remove all shipping material from inside.
5. Be sure to remove the small pieces of cardboard [A] at both ends of the cover.



d3d7c1006


Prepare the Finisher

1. On top of the finisher, remove the cover of the relay connector.



d3d7c1007


2. Remove the connector bracket.



 x1

d3d7c1008


3. Attach the shoulder screws to the frame on the right side of the finisher.



 x3


d3d7c1011

- 4. Open the finisher door [A].
- 5. Set the bottom plate [B].



d3d7c1014

6. Attach the bottom plate at the front [A] and rear [B].



 x2 M3x6

d3d7c1015


7. Attach the ground plate (a finisher accessory) to the right edge of the bottom plate.



 x2

d3d7c1016


8. Set two screws in the holes provided on the bottom half of the finisher front door [A]. Do not tighten these screws yet.
9. Set the keyholes of the hinges [B] on the bottom extension over the set screws, and then slide the extension down.



 x2 M4x8

d3d7c1017

10. Tighten both screws.
11. Set two screws in the holes provided on the top half of the finisher front door [A]. Do not tighten these screws yet.
12. Set the keyholes of the hinges [B] on the top extension over the set screws, and then slide the extension down.




 x2 M4x8

d3d7c1018

13. Check the top of the door and extension.
 - If the top of the door and extension are not even [A], slide the extension up slightly [B].


- Tighten the screws.



dc3nc1045

2

14. Set two screws in the holes provided on the rear metal frame [A]. Do not tighten these screws yet.
15. Set the keyholes of the hinges [B] on the rear extension over the set screws, and then slide the extension down.



 x2 M3x6

d3d7c1019

Install Tray

↓ Note

- The shoulder screws [A] (attached in a previous step) slide into the cutouts [B] in the frame of the cover interposer tray and fasten to the side of the finisher.




d3d7c1020

1. Pick up the cover interposer tray, align the keyholes with the shoulder screws, and then slide the cover interposer down onto the screws.




d3d7c1021

2. Check under the finisher and confirm that the shoulder screws [A] are engaged correctly with the cutouts.
3. At the front, fasten screw [B] to lock the cover interposer tray to the finisher frame.



Attach Corner Plates and Gaskets


1. At the right rear corner of the finisher, temporarily attach two screws with about two turns.
2. The holes are not visible because they are covered with tape. Just punch the screws through the holes.
3. Attach the plate by sliding the cutouts over the heads of the screws, and then tighten the screws with a long screwdriver.



4. At the right front corner [A], temporarily attach one screw with about two turns.
5. The hole is not visible because it is covered with tape. Just punch the screw through the hole.
6. Snap the plate into position while sliding the cutout over the head of the screw, and then tighten the screw with a long screwdriver [B].





 x1




d3d7c1024

7. On the left side of the main machine, attach the joint brackets at the rear [A] and front [B]. (If the finisher was installed previously, the brackets are already attached.)



d3d7c1025

8. Remove the tape from both gasket seals. (These are Cover Interposer Tray accessories.)



d3d7c1026

- Attach one gasket on the rear joint bracket [A] and one gasket on the front joint bracket [B].



d3d7c1026

2

Attach Sponge Strips

- Raise the cover [A] of the Cover Interposer Tray on top of the finisher.
- Attach the wide sponge strip [B] supplied with the Cover Interposer Tray.
- Make sure that the strip is not sticking to the cover, and then close the cover.



d3d7c1028

- Attach the finisher sponge strip to the top right edge of the main machine. (This is a finisher accessory, or you may have already removed it from the previously installed finisher and attached it already.)



d3d7c1031


Re-attach Paper Entrance Guide

1. Discard the machine screws you removed with the paper entrance guide.
2. Replace them with the small tapping screws provided with the interposer tray.



d3d7c1029


3. Attach the paper entrance guide at the front right corner of the finisher [A].
4. Attach the paper guide with the small anti-static brush at the right rear corner of the finisher [B].




d3d7c1030

Dock the Finisher

1. With the finisher door open, push the finisher against the side of the main machine [A].
2. Push the lock bar [B] in completely, and then fasten it with the screw.



3. Connect the finisher I/F cable at the left rear corner of the main machine [A].



Finishers SR4120/SR4130 (D3CG/D3CH)

Accessory Check

Check the quantity and condition of the accessories against the following list.

2

No	Description	Q'ty	
		SR4120	SR4130
1	Lower Output Tray	-	1
2	Shift Auxiliary Tray	1	1
3	Proof Auxiliary Tray	1	1
4	Sponge Strip	1	1
5	Docking Bracket	1	1
6	Upper Output Tray	1	1
7	Screws M3 x 6	6	6
8	Tapping Screws	2	2
9	Screws M4 x 20	4	4
10	Screws M3 x 8	1	1
11	Ground Plate	1	1
12	Joint Bracket	1	1
13	End Fence	-	1
14	Proof Support Tray	1	1
15	Tray Holder	-	1
16	Right Upper Cover	1	1
17	Coupling Seal	1	1
18	Shoes	4	4
19	Hopper	1	1

No	Description	Q'ty	
		SR4120	SR4130
20	Cushion	1	1



d3cgc1000

Installation Procedure

⚠ CAUTION

- Always switch the machine off and unplug the machine before doing the following procedure.

Tapes and Retainers

1. Unpack the finisher and remove all tapes and packing materials from the finisher.



d1351186

2. Open the front door and remove all visible tapes and retainers.

3. Remove the upper bracket with the red tag attached [A].



d3cgc3129

4. Pull out the jogger unit, and then remove all remaining tapes and retainers.



d3cgc1187

5. Remove the lower bracket with the red tag attached [A].




 x2

d3cgc0107

Preparing the Finisher

1. Install the paper entrance guide [A] on the right side of the finisher.



 x2 M3x6




d3cgc1188

2. Do not attach the right upper cover if you are going to install Cover Interposer Tray CI4040 (DC3N).

-or-


Set the tabs of the right upper cover [A] at the right rear corner of the finisher, and then attach the cover at the front [B].




 x2

d3cgc9952


3. Hook the ground plate [A] onto the right bottom edge of the finisher, and then attach it [B] with the screws.



4. Peel the tape from the large sponge strip.



5. Attach the strip to the right top edge of the finisher so it is 0 to 1 mm from the top edge.




Preparing the Main Machine

1. Use the long screws to **loosely** attach the rear end [A] and front end [B] of the joint bracket to the left side of the main machine. Do not tighten these screws.




 x4 M4x20 d3cgc0108

2. With the joint bracket [A] floating freely on the loose screws, move the bracket to position screw [B] so it is centered exactly below the long line on the scale, and then tighten the four screws.



d3cgc0109

3. Peel the tape from coupling seal, and then attach it to the left side of the main machine between the exit rollers.



d3cgc4041

4. Remove the connector cover on the rear left side of the main machine.



d3cgc1192


5. Push the finisher close to the left side of the main machine.



d3cgc1651


Docking the Finisher

1. Disconnect the lock bar by removing the screw [1], and then pull the lock bar [2] out until it stops.




d3cgc1193

2. Push the finisher [A] against the side of the main machine.
3. Confirm that the gap between finisher and main machine is tight and perfectly even.



d3cgc1194

4. Firmly, push the lock bar [1] in until it stops, and then fasten screw [2].




5. Connect the finisher connector to the machine.




6. Close the front door of the finisher.


7. Set the upper output tray [A], and then attach screw [B] under the tray.



8. If you are installing Booklet Finisher CI4040, raise feeler arm [A], and then set the back edge of the tray [B] into the slots. (No screws.)



9. Install the hopper.



10. If the floor is uneven, you may want to use the four accessory shoes to level the machine with the four bolts and locknuts under the finisher.




d3cgc1007

Checking the Installation

1. Turn on the main machine.
2. Print out five A3 or DLT sheets to the proof tray and check the side-to-side registration.
3. For **DLT** paper watch the scale above the rear exit roller.

-or-

For **A3** paper watch the scale above the front exit roller.




d3cgc3121

- If you see the edge of the paper at the center mark on the scale, the paper is aligned correctly.
- If you see the edge of the paper at any mark to the right of center, the paper is shifting toward the front of the machine..
- If you see the paper at a mark to the left of center, the paper is shifting toward the rear of the machine.

4. If side-to-side registration is still shifting to either the rear or front of the machine, correct it.
page 1498
5. Print out some sheets with center-folding and make sure that the sheets are folded evenly into equal halves.
6. If the center folding not aligned, correct it. page 1505


Auxiliary Trays

1. Choose one of the three pairs of holes on the back of the finisher for installation of the auxiliary tray holder.



d3cgc1002

2. Position the holder at the selected holes, and then push in the plastic rivets.



d3cgc1003


3. Set the trays in the holder.



d3cgc1004

Using Auxiliary Trays

The trailing edges of excessively curled or Z-folded paper can activate the tray full sensors before the tray is actually full. Once this occurs and the "Exit Tray Full" message appears, the job stops and cannot continue until some sheets are removed from the tray which is only partially full. The auxiliary trays, number [1], [2], and [3] on their undersides are designed to prevent this problem.



d3cgc1005

Proof Support Tray (No. 1)

Set auxiliary Tray 1 on the proof tray when using thin or soft paper that may not exit completely and interfere with the tray full sensor.



d3cgc1199

Proof Auxiliary Tray (No. 2)

Z-folded paper or paper with curled edges can interfere with the tray full sensor by signaling tray full before the tray is actually full.



d223c8210

Set auxiliary Tray 2 on the proof tray when Z-folding paper or excessively curled is output.




d3cgc1650

Shift Auxiliary Tray (No. 3)


Set auxiliary Tray 3 only when the Multi-Folding Unit is installed, especially when working with Z-folded paper.

1. The pegs [A] on the bottom of this tray fit into the holes on the shift tray [B].



d223c8207


2. When you set the tray, position feeler [1] and [2] on top of the tray.



d223c8208

3. Confirm that the tray is perfectly flat on the shift tray below. There should be no gap between the trays.

2



d223c8209

Punch Units (D706)

These instructions describe installation of the following punch units for the Finisher SR4060/SR4070:

- Punch Unit PU3060 SC (D706)
- Punch Unit PU3060 2/4 EU (D706)
- Punch Unit PU3060 NA 3/2 (D706)


★ Important

- These punch units can be installed and used with the Finishers SR4120 and SR4130 only.

Accessory Check

Check the quantity and condition of the accessories against the following list.

No	Description	Qty
1	Chad Guide	1
2	Hopper Bracket	1
3	Punch Unit Slide Stay	1
4	Registration Guide Plate	1
5	Registration Sensor Bracket	1
6	Punch Unit	1
7	Punch Waste Hopper	1
8	Stepper Motor Bracket	1
9	Harness Connector Cable-PCB	1
10	Tapping Screw (M3 x 6)	14
11	E-ring	1




d1351675

Installation Procedure


⚠ CAUTION

- Always switch the machine off and unplug the machine before doing the following procedure.
1. If the finisher is installed, disconnect it and pull it out of the line.
 2. Remove the rear upper cover [A] of the finisher.




d1351253


3. Remove the rear lower cover [A] of the finisher.




4. Open the front door [A], and then remove the punch hopper bracket [B].



5. Pull out the stapling unit [A]. (Booklet Finisher only)




6. Remove the inner upper cover [A] from the Front of the finisher.




Note

- Disconnect the harness from the back side of the inner upper cover when you remove the inner upper cover.




7. Remove screw [A] of the transport guide plate from the rear of the finisher.




8. Remove the transport guide plate [A].




9. Install the punch unit slide stay [A] from the rear of the finisher.




10. Fasten the punch unit slide stay at the front [A]




11. Fasten the punch unit slide stay at the rear [A]




12. Insert the paper chad guide [A] into the finisher as shown below.




13. First, hook the chad guide to the front [A]



14. Second, hook the chad guide to the rear [A]




15. At the rear, fasten the paper chad guide.



Note

- When fastening the paper chad guide with the snap ring, make sure the Front of the paper chad guide is hooked onto the small-diameter slot [A].




d1351689

16. Insert the hopper bracket [A] into the finisher as shown below.



d1351690


17. Hook the hopper bracket onto the frame [A] [B] of the finisher.



d1351691


Note

- Make sure the hooks [A] and [B] of the hopper bracket are also hooked onto the finisher.



d1351693


18. Fasten the hopper bracket [A].



 x2


d1351692

19. Route the harness of the hopper bracket [A] inside the finisher as shown.



d1351694


20. Route the harness of the hopper bracket to the rear of the finisher.



 x4

d1351695


21. Insert the registration guide plate [A] from the rear of the finisher.



d1351696


 **Note**

- Hook [A] and [B] of the registration guide plate onto the slotted holes of the finisher.




22. Fasten the registration guide plate.


Front



Rear




23. Insert the registration sensor bracket [A] from the rear of the finisher.




Note


- Hook [A] of the registration sensor bracket into the slotted holes of the finisher.



24. Fasten the registration sensor bracket.




25. Insert the punch unit [A] from the rear of the finisher.



 **Note**


- Make sure the shaft [A] on the finisher is inserted into the punch unit [B].



d1351704


Note

- When inserting the punch unit, make sure the bracket [A] of the punch unit is in the right position as shown below.




d1351916

26. Fasten the punch unit.




↓ Note


- Make sure the bracket of the punch unit fits the embossed parts [A] on the finisher.




27. Install the stepper motor bracket [A] from the rear of the finisher.



28. Insert the hole [A] in the stepper motor bracket over the shaft [B] on the rear of the finisher.




29. Make sure the rack [A] of the punch unit is engaging with the pinion [B] of the stepper motor bracket when you insert the stepper motor bracket.




d1351709

30. Fasten the stepper motor bracket.




d1351710


31. Connect the harness [A] of the registration sensor bracket to the harness [B] from the hopper bracket.



32. Connect the harness [A] of the registration sensor bracket to the harness [B] from the punch unit.




33. Connect the harness connector cable provided with the punch unit to the main board [A] of the finisher.



↓ **Note**


- The end that is split into two connectors must be connected to the main board.

34. Route the harness connector cable as shown below.




↓ **Note**


- Route the harness inside the I/F bracket [A] as shown below.




35. Connect the harness connector cable to the PCB [A] on the punch unit.




36. Connect the harness [A] of the stepper motor bracket to the PCB [B] in the punch unit.




37. Connect the harness [A] of the registration sensor bracket to the PCB [B] in the punch unit.



38. Gather the harnesses of steps 32-34 [A] with your hands, and then fasten them with the clamps as shown below.




39. When you clamp the harness in clamp [A], clamp the harness between the two binds [B].



40. Route the harness [A] of the punch unit over the PCB as shown below.



41. Slide the punch waste hopper [A] into the finisher from the rear.



d1351721

42. Pull back the stapling unit.
43. Re-attach the covers, and then re-install the finisher on the main machine.
44. Connect the finisher connector to the main machine.
45. Turn on the main power switch of the machine.
46. Check the finisher operation.

Output Jogger Unit Type M25 (D3CJ)

★ Important


- This jogger unit is installed and used with the Finishers SR4120/SR4130 only

Accessories

2

Check the quantity and condition of the accessories against the following list.

No	Description	Qty
1	Jogger Unit Cover	1
2	Jogger Unit	1
3	Rear End Cover	1
4	Front End Cover	1
5	Cushions	5
6	Shoulder Screws	2
7	Screws (Blue) M3x6	2
8	Screws (Silver) M3x8	5



d3cjc1001

Installation

⚠ CAUTION

- Always switch the machine off and unplug the machine before doing the following procedure.
1. Disconnect the finisher from the main frame.
 2. Remove the rear cover.



 x2



d3cjc1002


3. Remove the shift tray.



 x1


d3cjc1003

4. Push the paper guides to the center.



d3cjc1004


5. Remove the rear paper guide cover.



 x2

d3cjc1005

6. Remove the front paper guide cover.



 x2

d3cjc1006


7. Disconnect the main paper guide cover.



 x2


d3cjc1007

8. Carefully, separate the front tabs at [A], and then remove the main paper guide cover [B].



d3cjc1008

9. Disconnect the cover installation bracket.



 x2


d3cjc1009

10. Slowly, disconnect the bracket from the rail above, and then remove it.



d3cjc1010


11. At the rear [A], set one shoulder screw.



 x1

d3cjc1011


12. At the front [A], set the other shoulder screw.



13. Spread the paper guides to the maximum width.




14. Move the jogger arms on the jogger unit to the center.



15. Hold the jogger unit so the hooks [A] on both ends of the unit are in line with the installed shoulder screws [B].

16. Rotate the jogger unit slightly up under the output tray so the motors on both ends of the unit go under the tray, and then hang the hooks on the shoulder screws at the front and rear.




d3cjc1015

17. Confirm that the rear bracket [A] is on the shoulder screw.
18. Confirm that the rear motor [B] is up under the tray.




d3cjc1016

19. Confirm that the front bracket [A] is on the shoulder screw.
20. Confirm that the front motor [B] is up under the tray.



d3cjc1017

21. Fasten the jogger unit at the rear [A] and front [B].



 x2

d3cjc1018

22. Connect the jogger unit at the rear.




 x1

 x1


d3cjc1019

23. Peel the back off the two accessory cushions.

24. Attach the cushions to the front [A] and rear [B] of the lower arms of the output tray.




25. Set the front end cover [A]. Do not attach the screw yet.




d3cjc1020


26. Set the rear end cover [A], and then fasten it [B].



27. Look at the jogger cover. Note the tabs and slots on the rear end [A], center arm covers [B], and front end [C].




28. Slowly, set the jogger cover [A] on the jogger unit.




29. At the rear [A] confirm that the tab inserts correctly.

30. At the front [B] confirm that both tabs set correctly.




d3cjc1024

31. In the center under the jogger unit, make sure the rear arm cover [A] and front arm cover [B] fit over the edge of the plate as shown.



d3cjc1025


32. After making sure that all tabs are set correctly, fasten the cover to the jogger unit.



 x3


d3cjc1026

33. Re-install the shift tray.



34. Check the center of the shift tray.

If the jogger arms are touching the surface of the shift tray as shown, this will cause a jam when the machine is turned on because the arms will move and hit the tray.




d3cj1027

35. To avoid a jam at power on, before you turn the machine on you can:

Raise the jogger arms [A] slightly so they are not touching the shift tray below.

-or-

You can spread the jogger arms [B] away from the center so they are not touching the surface of the tray.



d3cjc1028

Cover Interposer Tray CI4040 (DC3N)

Accessories


★ Important

- This Cover Interposer Tray is designed for use with the Finisher SR4120 and Booklet Finisher SR4130 only.

Check the accessories and their quantities against this list.

No.	Description	Q'ty
1	Front Door Top Extension	1
2	Front Door Bottom Extension	1
3	Rear Cover Extension	1
4	Tray Mounting Bracket: Rear	1
5	Tray Mounting Bracket: Front	1
6	Gaskets	2
7	Rear Joint Bracket	1
8	Front Joint Bracket	1
9	Decals	2
10	Right Front Corner Plate	1
11	Right Rear Corner Plate	1
12	Sponge Strip	1
13	Paper Guide (Not used for this machine)	1
14	Ground Plate Extension	1
15	Tapping Screws M4x16	3
16	Screws M4x14	4
17	Tapping Screw M4x8	4
18	Screws (Blue) M3x6	6

No.	Description	Q'ty
19	Screws (Silver) M3x6	4
20	Shoulder Screws (Blue)	2




2

Installation

Finisher Already Installed?


If the finisher is installed, it must be separated from the main machine.

1. At the left rear corner of the machine [A], disconnect the finisher cable.



dc3nc1002

2. Open the finisher door.
3. Remove screw [A] from the lock bar. Keep this screw.
4. Pull out lock bar [B] completely.



dc3nc1003


5. Pull the finisher away from the side of the machine.



dc3nc1004

Prepare the Finisher



1. Remove the paper guide on the right side of the finisher.



dc3nc1005

2. If the finisher is the Booklet Finisher SR4130, remove the upper right plate [A]. (The Finisher SR4120 does not have this plate.)



 x2 M3x6  x2 dc3nc1006


3. Remove the sponge strip [A] from the upper right edge of the finisher.



dc3nc1007


Shipping Tapes and Retainers

1. Remove tape from the top [A] of the tray.
2. Under the tray, remove the tape and cardboard on connector [B].



dc3nc1008


3. Open the tray and remove all tape and pieces of cardboard.



dc3nc1009

Prepare the Main Machine

1. On the left side of the main machine, unfasten rear end [A] and front end [B] of the joint bracket.



dc3nc1010



2. Remove the bracket.



dc3nc1011

Cover Interposer Tray

1. On top of the finisher, remove the connector cover [A].
2. Remove metal cover [B].




 x1

dc3nc1012

3. On the right rear inside panel of the finisher [A], fasten one shoulder screw.




4. On the right front post of the finisher [A], fasten the other shoulder screw.



 x1


dc3nc1014

5. To avoid damaging the guides on the right side of the unit, elevate the unit with some blocks, boxes, etc. so it is not flat on the floor.




dc3nc1046

6. Select the rear tray mounting bracket [A], and then locate its screw holes between the keyholes on the rear frame.




 X2 M3x6 dc3nc1015

7. Align the holes, and then fasten the tray mounting bracket to the frame.



 x2 M3x6 dc3nc1016

8. Fasten the other mounting bracket to the front frame at [A] and [B].




 x2 M3x6 dc3nc1017

9. On the right side of the finisher, hold the tray unit over the finisher, and then align the hooks of the mounting brackets with the installed shoulder screws in the finisher.
10. Slowly, lower the tray unit hooks onto the shoulder screws inside the finisher.




dc3nc1018

11. Look inside the finisher to confirm that the hook of the rear bracket is seated correctly on the shoulder screw.



dc3nc1019

12. Fasten one screw below the **Q2** lever to fasten the tray to the frame.



 x1 M3x6


dc3nc1020

13. Raise Q2.



dc3nc1021

14. Fasten one screw to fasten the tray to the frame at the rear.




 x1 M3x6

dc3nc1022

Extensions


1. Set two screws in the bottom half of the finisher front door [A].
2. Do not tighten these screws [B].




 x2 M4x8

dc3nc1023

3. Set two screws in the top half of the finisher front door [A].
4. Do not tighten these screws [B].




5. Select the front door bottom extension.
6. Set the keyholes of the hinges [1] over the heads of the screws, and then slide the extension [2] down so the heads of the screws slide into the cutouts.
7. Tighten both screws.



 x2 M4x8

dc3nc1025


8. Select the front door top extension.
9. Set the keyholes of the hinges [1] over the heads of the screws, and then slide the extension [2] down so the heads of the screws slide into the cutouts.



dc3nc1026


10. Check the top of the door and extension.

- If the top the door and extension are not even [A], slide the extension up slightly [B].
- Tighten the screws.



dc3nc1045


11. Attach the rear cover extension [A].



 x0

dc3nc1027

12. Remove ground plate [A] from the bottom right edge of the finisher.




 x2 M3x6

dc3nc1028

13. Set the tab [1] and boss [2] of the ground plate extension on the bottom edge, and then fasten it with the screws.



 x2 M3x6

dc3nc1029

14. Hook the ground plate to the right edge of the extension.



dc3nc1030

 x1

15. Fasten the ground plate to the extension.



 x2 M3x6 dc3nc1031

16. At the right front corner of the finisher [A], peel off the tape.

17. Set one screw [B]. Do not tighten it.




 x1 M4x16 dc3nc1032

18. Select the right front corner plate (the smaller plate).

19. Attach to the right edge [A], and then lower its cutout over the gap of the set screw [B].


20. Use a long screwdriver inserted through the hole at [C] to tighten the screw and fasten the plate.




dc3nc1033

21. At the right rear corner of the finisher [A], peel off the tape.

22. Set two screws [B]. Do not tighten them.
23. When you attach the plate [C], lower the cutouts under the plate over the set screws.




24. Use a long screwdriver inserted through the cutouts under the plate [A] to tighten the screws and fasten the plate.




Sponge Strip

1. Open the tray [A].
2. Peel the cover [B] from the tape on the sponge.



dc3nc1036

3. Attach the sponge to the bare plate.




dc3nc1037

4. Raise and lower the tray a few times to make sure that the strip is not sticking to the tray.

Main Machine


1. On the left side of the main machine, attach the front joint bracket (marked "R") on the right side of the paper exit [A].
2. Remove the tape [B] from one gasket.



 x2 M4x14

dc3nc1038


Attach gasket [A] to the front joint bracket.



 x2 M4x14

dc3nc1044

3. Attach the rear joint bracket (marked "L") on the left side of the paper exit [A], and then attach the other gasket [B] to this bracket.



 x2 M4x14

dc3nc1039


Docking the Finisher

1. Push the finisher close to the left side of the main machine.
2. Confirm that the lock bar is pulled out completely.



dc3nc1041

3. Push in the lock bar, and then fasten it with its screw.




dc3nc1042

★ Important

- After docking the finisher, lower and raise guide Q2 to confirm that it opens and closes smoothly.
- If it does not operate smoothly, make sure that the right side of the finisher is straight against the left side of the machine (or upstream unit).
- Also, check the guide Q2 and the paper guide above to see if either is bent or loose.

4. Connect the finisher cable at the right rear corner of the machine [A].



dc3nc1043

Finish the Installation

1. Plug in the machine and switch the machine on.
2. Enter the [System Settings].
3. Select Cover Sheet Tray > Front Cover Sheet Tray > Back Cover Sheet Tray > Tray Paper Settings > Designation Sheet 2 Tray.

Mailbox CS4010 (D708)

★ Important


- The Mail Box can be installed on the SR4120/SR4130 only. The Mail Box cannot be installed on the SR4080.
- The Mail Box and Cover Interposer tray cannot be installed together. (Only one will fit on top of the finisher.)

2

Accessories

Check the accessories and their quantities against this list.

No.	Description	Qty
1.	Trays	9
2.	Guide plate	1
3.	Screws - M3x8	6
4.	Decals (bin display)	1



d708c1001

Installation


⚠ WARNING

- Turn the machine off and disconnect the machine power cord before you start this procedure.

1. Remove the filament tape [A].

★ Important

- Move the mailbox carefully. The soft corner leaf [B] can be damaged easily.




d708c1002

2. At the rear left corner of the main machine, disconnect the finisher cable [A].



d708c1003

3. Open the front door of the finisher.
4. Remove lock screw [A]. Keep this screw.
5. Pull out lock bar [B] until it stops.



d708c1004

6. Pull the finisher away from the machine.




d708c1005

★ Important

- If the Cover Interposer Tray is installed on the Finisher, it must be removed. Do this now.


7. Remove top cover [A] of the finisher.



🔩 x2

d708c1006


8. Open the finisher door, and make sure that the lock bar is pulled out completely.
9. With the finisher door open, slowly, push the finisher against the left side of the machine.
10. Push the lock lever [A] into the finisher, and then fasten it with the screw [B].



🔩 x1


d708c1008

11. At the left rear corner of the main machine, connect finisher cable [A].



d708c1009

12. Attach guide plate [A] to the top of the finisher.




d708c1010

 x3 M3x8

13. Attach the mailbox [A] to the top of the finisher.

14. Attach the 9 trays [B] to the mailbox.

15. Give the decals [C] to the customer. The operator will fill out the decals and attach them at the desired locations.



16. Turn the machine on.
17. Check the finisher operation.


Copy Tray Type 9002 (B756)

Accessories

Check the accessories and their quantities against the following list.

2

No.	Description	Q'ty
1.	Copy Tray	1
2.	Actuator Arm and Bracket (not used)	1
3.	Tapping Screw (not used)	2
4.	Large Cap	1
5.	Small Cap	4
6.	Paper Height Sensor (Black Connector)	1
7.	Paper Height Sensor (White Connector) Not Used	1




b756c0000

Installation


⚠ CAUTION

- To avoid the hazard of electrical shock, before doing this procedure turn the machine off and unplug the machine from the power source.


1. Remove the left upper cover [A].



2. Select the paper height sensor with the **black** connector. (The sensor with the white connector is not used for this machine.)
3. Attach the paper height sensor [A] to the actuator.
4. Free the harness [B] in the machine, and then connect it to the sensor.
5. Attach the actuator [C] with connected sensor to the machine.



6. Reattach the left upper cover to the machine.
7. Attach the tray [A].
8. Insert the small caps into the small holes.
9. Fasten the square cap as shown.



Tab Sheet Holder Type 9002 (B499)


The tab sheet holder can be installed in trays 2 and 3, and allows the user to load tab stock.

Accessories

2


Check the quantity and condition of the accessories in the box against the following list.

No.	Description	Q'ty
1	Tab Sheet Holder	1
2	Decal	1




Installation

1. Attach the decal [B] to the tab sheet holder [A].




d1351749

2. Check that the paper tray is not being used, and then pull the tray carefully out until it stops.



d1351733

3. Install the tab sheet holder on the end fence of the paper tray.




d1351734

4. When the tab sheet holder is installed correctly, you can hear a clicking noise.


[A]: End fence

[B]: Tab sheet holder




d1351731

5. Load tab stock in the paper tray so the side with the tab faces the tab sheet holder.
6. Adjust the end fence position so that the tab sheet holder will fit the tab stock.



d1351735

7. Carefully slide the paper tray fully in.
8. When removing the tab stock holder, spread the hook [A] of the tab sheet holder and then remove it as shown below.



d1351732

NFC Card Reader Type M19 (D3BS)

Accessories

2

Check the quantity and condition of the accessories in the box against the following list and diagram.

No.	Description	Q'ty
1	Corner Cover (Not used)	1
2	Reader Bracket	1
3	Reader Cover	1
4	Reader	1
5	Sponge Cushions	2
6	Ferrite Core (Black)	1
7	Interface Cable	1




d3bsc1001


Installation

1. Turn the machine off.
2. Disconnect the machine from its power source.
3. Open the ADF.
4. Cover the exposure glass.
5. Disconnect the front edge cover of the scanner unit.


2



6. Remove the front edge cover.



7. Disconnect the upper left corner [A] and upper right corner [B] of the operation panel.



 x2


d3bsc1004

8. Raise the operation panel [A] and then lay it face down on the exposure glass.



d3bsc1005

9. On the right, disconnect the blank cover.



 x4

d3bsc1006


10. Turn the operation panel face up.

11. Remove the cover so you can see the panel bracket below.



d3bsc1007

12. The reader bracket has two large tabs under it.



d3bsc1008

13. Set these tabs into the holes in the panel bracket, and then slide the reader bracket toward the rear to lock the reader bracket in place.




x2

d3bsc1009

14. Attach the black ferrite core to the accessory interface cable so the core is about 25 mm (1") from the base of the connector.


Note

- Attach the ferrite core to either end of the interface cable. The connectors are identical.



d3bsc1010

15. Lift the operation panel and lay it face down.
16. Locate the connection point for the interface cable.




d3bsc1011

17. Connect the free end (no ferrite core) of the interface cable to the PCB.

 x1

d3bsc1012

18. Set the cable in the notch of the frame [A].




d3bsc1014

19. Lift the operation panel and turn it face up.
20. Raise the end of the cable with the ferrite core through the hole.



d3bsc1015

21. Peel the tape from each side of the sponge cushions, and attach the cushions to the frame bracket.



d3bsc1016

22. Connect the card reader and the cable.



 x1 d3bsc1017

23. Set the card reader on the sponge cushions attached to the reader bracket.



d3bsc1018

24. Hold the card reader cover with both tabs down.



d3bsc1019

- 25. Set both tabs at the front edge of the reader bracket [A], and then lower the rear edge.
- 26. Press down until the rear edge [B] snaps into place.



- 27. This completes the installation. Re-attach the operation panel.




Card Reader Bracket Type 3352 (D593)

Accessories


Check the accessories and their quantities against this list.

No.	Description	Qty
1.	Table Top	1
2.	Table Frame	1
3.	Table Bottom	1
4.	Screw M4x35	2
5.	Screw M3x6	2
6.	Screw M3x8	2



Installation

1. At the right rear corner, remove the I/F harness connector cover.



b498c0002


2. On the right side of the machine, lower bypass tray [1], remove screw [2], and then remove right upper cover [3].



 x1


b498c0003

3. Lay the cover down with the inner surface of the rear upper corner facing up.
4. Use a punch or the tip of a screw driver, to punch out the knockouts.



b498c0004

5. Clean the holes so they are smooth.



b498c0005


6. Reattach the right upper cover to the machine (🔩 x1).
7. Fasten the long accessory screws in the holes and leave about 2.5 cm (1") of the screw heads protruding.



 x2


b498c0006

8. Bring the flat side of the table frame to the side of the machine.
9. Align the knockout in the side of the frame with the harness connector port [1], and then hang the keyholes on the side of the frame over the heads of the screws [2] and [3].




b498c0007


10. Fasten the left front corner of the table [A].
11. Fasten the left rear corner of the table [B].



12. Set the hooks on the left edge of the table top [A] into the holes in the table frame, and then lower the top onto the frame.
13. Run the card reader I/F harness [B] through the center of the table.



14. Below the table, connect the card reader harness.



 x1

b498c0009


15. Attach the table bottom under the table frame.



b498c0011

16. Fasten the front left corner of the table [A].

17. Fasten the rear left corner of the table [B].



 x2

b498c0012

18. Fasten the front right corner of the table [A].

19. Fasten the rear right corner of the table [B].



 x2

b498c0013

20. This completes installation of the card reader table.



b498c0014


Optional Counter Interface Type M12 (B870)

Accessories

Check the accessories and their quantities against this list.

2

No.	Description	Qty
1.	PCB: MKB	1
2.	Harness (MKB to IOB) Not Used	1
3.	Harness (MB to MKB) Not Used	1
4.	Screws M3x6	4
5.	Standoffs	4
6.	Clam	1
7.	Lock Band	1
8.	Relay Harness Not Used	1




d135d1748

Installation


⚠ CAUTION

- Before doing this procedure, to prevent electrical shock always switch the machine off and then disconnect it from the power source.
1. Switch the machine off.
 2. Disconnect the machine from the power source.
 3. Remove the rear upper cover. page 482
 4. Use a pair of nippers to remove knockout [A].




d223d8902

5. Open the controller box cover. page 488
6. Attach the standoffs to four holes [A].




d223d8901

7. Locate the free harness in front of the frame where you just attached to standoffs.
8. Remove relay cap [A] from the end of the harness [B].



d223d8926

- 9. Attach the PCB [A] to the standoffs on the frame.
- 10. Connect harness [B] to the PCB.




 x1

d223d8903a

Copy Connector Type M25(D3D3)

With this option you can connect two machines to perform simultaneous copying for the same job.



d223d8708

2

Accessories

Check the accessories and their quantities against this list:


No.	Description	Q'ty
1.	PCB D3D3	2
2.	LAN Cable	1

Installation

⚠ CAUTION

- Before doing this procedure, turn the machine off and disconnect its power cord from the power source.
- Before you handle the boards, touch a metal surface to discharge accumulated static charge from your hands. A static discharge could damage the boards.
- Handle the boards carefully to avoid damaging them.

1. Remove the cover [A] from the right I/F slot (marked "Tandem").



 x2

d223d8701a

2. Insert one of the boards in the slot.
3. Tighten the knob screws with your fingers.

★ Important

- To avoid damage to the board, never tighten these knob screws with a screwdriver.
4. In the same way, install the other board in the right slot of the other machine.
 5. Connect the provided LAN cable to both boards.

External Keyboard Bracket Type M3 (D3DH)

Accessories

No.	Description	Q'ty
1	Cover (for card reader)	1
2	Cover (no card reader)	1
3	Keyboard Holder	1
4	Screws	2

2



d3dhc1001

Installation

The external keyboard can be installed with or without a card reader. Do the first procedure below to install only the keyboard. Do the second procedure to install the keyboard with the card reader.

External Keyboard Only

Do this procedure to install the external keyboard without a card reader.

1. Turn the machine off.
2. Disconnect the machine from its power source.

- 3. Open the ADF.
- 4. Remove the square cover on the right side of the operation panel.



▶ x4

d3dhc1002

- 5. Remove a USB port cover on the right edge of the operation panel.



d3dhc1003

- 6. Set and fasten the keyboard holder



⚙ x2


d3dhc1004

- Remove the tape from the holder.



d3dhc1005

- Connect the USB cable to the right edge of the operation panel [A] and then set the keyboard [B] in the holder.

 x1

d3dhc1006

- Attach the cover without the cut-out.




d3dhc1007

External Keyboard with Card Reader

Do this procedure to install the external keyboard together with a card reader.

1. Turn the machine off.
2. Disconnect the machine from its power source.
3. Open the ADF.
4. Cover the exposure glass.
5. Disconnect the front edge cover of the scanner unit.


2



 x2


d3bsc1002

6. Remove the front edge cover.



d3bsc1003

7. Disconnect the upper left corner [A] and upper right corner [B] of the operation panel.



 x2

d3bsc1004

8. Remove a USB port cover on the right edge of the operation panel.




d3dhc1003

9. Raise the operation panel [A] and then lay it face down on the exposure glass.



d3bsc1005


10. Remove the left edge cover.



 x1

d3bsc1023

11. Remove left upper cover [A] and rear upper cover [B].




 x2

 x2

d3bsc1024

12. With the operation panel turned face down, disconnect the blank cover and remove it.



 x4

d3bsc1006

13. Turn the operation panel face up.


14. Set the rear upper cover.
15. Pass the card reader cable through the cover cut-out, and then connect the cable to one of the USB ports.



 x1



d3dhc1008


16. Pass the cable over the left, rear corner [A], and then clamp it to the left side of the frame [B].



 x2


d3dhc1009

17. Fasten the rear upper cover. ( x2)
18. Re-attach the left upper cover ( x2).
19. At the left front corner [A], set the cable in the groove




d3dhc1010

- 20. Pass the cable behind the I/F cable and ground wire [A]
- 21. Set the cable on support [B].
- 22. Pass the end of the cable through the cover [C].




d3dhc1011

- 23. Turn the cover face up, set it, and then fasten left side [A] and right side [B].




d3dhc1012

24. Set the keyboard holder [A] and then fasten it.
25. Set the tabs [B] on the bottom of the card reader bracket (provided with card reader accessories) into the holes on the keyboard holder, and then slide it to the left to lock it.




d3dhc1013

26. Connect the cable to the card reader [A], and then set the card on its bracket.
27. Remove the tape at [B] and [C].



28. Connect the keyboard USB cable to the right edge of the operation panel [A] and then set the keyboard [B] in the holder.



29. Attach the cover with the cut-out for the card reader



d3dhc1016


Internal Options

List of Slots

2

The internal options are the options that are available on I/F cards inserted into the controller board.

- **Tandem I/F Card.** The left slot is used exclusively for the I/F card used to slave one machine to another.
- **Option Slot.** The right slot is used for other options. As the I/F must reside in the slot, this means only one option can be used at a time. For example, you will not be able to use the File Format Converter if you have installed a wireless LAN.



d223c2011

No.	Name	Item
1	USB A	Standard
2	USB B	USB Device Server Option Type M19

No.	Name	Item
3	Ethernet	Standard
4	SD Card Slots	Slot 1 Controller options on SD cards Slot 2 Service slot (firmware updates, etc.)
5	Option (I/F Slot)	File Format Converter Type M19 IEEE 1284 Interface Board Type M19 IEEE 802.11 a/g/n Interface Unit M19 Extended USB Board Type M19 USB Device Server Option Type M19
6	Tandem (I/F Slot)	Copy Connector Type M25
7	LINE 2	G3 Interface Unit Type M25 (1 Channel)
8	LINE 3	G3 Interface Unit Type M25 (2 Channel)
9	ISDN	G3 Interface Unit Type M25 (3 Channel)
10	LINE	Fax Connection Type M25
11	TEL	

↓ Note

- Only one board can be installed for No. 5 because only one slot is available.

Inserting Cards

1. Remove the cover on the controller board faceplate.



 x2



d3b4c0001

2. Insert the edge of the board into the groove at the top and bottom of the right side of the slot.
3. Slowly push the board into the slot until you feel it connect with the controller board.
4. Fasten the board by tightening the knob screws with your fingers.



d3b4c0002

★ Important

- Tighten these knob screws with your fingers.
- Never use a screwdriver to tighten these screws.
- If a screw is tightened with too much pressure, this could damage the I/F board or the edged connectors between the I/F card and the controller board.

IEEE 1284 Interface Board Type M19

Accessories

No.	Description	Q'ty
1.	IEEE 1284 Centronics Board	1

2



d3c0c1001

Only one I/F slot (labeled "Option") is available for one of these options:

- Centronics 1284
- IEEE 802.11 a/g/n (Wireless LAN)
- File Format Converter

★ Important

- If another card is installed in the "Option" slot on the right, you must remove it before installing this card.

Installation

1. Switch the machine off.
2. Remove the cover of the "Option Slot" on the right.



 x2




d3b4c0001

3. Insert the board [A] into the slot.
4. Tighten the knob screws [B] with your fingers.

★ Important

- To avoid damage to the board, never tighten these knob screws with a screwdriver.




d3b4c0002

IEEE 802.11 a/g/n Interface Unit M19

Accessories

Check the quantity and condition of the accessories in the box against the following list and diagram.

No.	Description	Q'ty
1.	IEEE802.11 a/g/n	1
2.	Velcro Fasteners	2
3.	Clamps	8



d3brc1020

Before You Begin

Observe the following points when installing and using this unit:

- Never attempt to disassemble the IEEE802.11 a/g/n Unit.
- If you need to replace any part, replace the entire unit.
- Give the Cautions chart to the customer.
- It is illegal to disassemble or modify this product. If illegal modifications are done to this product, we shall not assume any responsibility.

- Depending where you use this product, or the access point you select, restrictions may be imposed on the use of some channels. If wireless LAN communications are not possible, check the environment or access point.

★ Important

- **You cannot use this option if you use Ethernet.**

Check the markings on the antenna brackets and the ferrite cores of the antenna cables.

- **ANT1.** The ferrite core on the Antenna 1 cable is **black**. Antenna 1 transmits and receives. It must be installed in the middle of the rear edge of the main machine.
- **ANT2.** The ferrite core on Antenna 2 cable is **white**. Antenna 2 only receives. It is installed on the rear right corner of the machine. .

The illustration below shows both antennas installed on the back of the machine with Antenna 1 (black ferrite core) on the rear cover and antenna 2 (white ferrite core) on the controller box cover.



d3brc1029

- The PCB is installed in the controller box.
- Both antennas are held in place by easily installed and removed Velcro fasteners. (The antennas and cables will need to be removed before the covers can be removed to service the machine.)
- The seven clamps are fastened to the machine by double-sided tapes.
- The clamps can be easily opened to free the cables and then closed to once again clamp the cables.

Installation

⚠ WARNING

- Unplug the main machine power cord before you do the following procedure.

⚠ CAUTION

- To prevent damage to the controller box, always work carefully.

- Never put your hand or a tool into the box when you remove the controller box or install an option.
 - To prevent damage to the circuits on the boards, always touch a metal surface to discharge static charge from your hands before you handle a board.
 - The usable frequency range of this product may be used by products (industrial, scientific, or medical devices) of other companies.
 - Outdoor use of wireless devices may be restricted. Pay attention to where you use this product.
1. Find the best location of the machine.
 - Make sure that the machine is not located near an appliance or any type of equipment that generates strong magnetic fields.
 - Put the machine as close as possible to the access point.
 2. Switch the machine off.
 3. Remove the cover of the "Option Slot".



 x2




d3b4c0001

4. Touch a metal surface to discharge any static electricity from your hands.
5. Insert the board [A] into the slot.
6. Tighten the knob screws [B] with your fingers.

★ Important

- To avoid damage to the board, never tighten these knob screws with a screwdriver.




d3brc1023

7. Pull the antennas away from machine and make sure that they are not tangled.
8. Look at the markings on the antenna bracket.
 - **ANT1**. Antenna 1 transmits and receives. The ferrite core on the Antenna 1 cable is **black**. It must be installed at the top center of the rear cover [1].
 - **ANT2**. Antenna 2 only receives. The ferrite core on the Antenna 2 cable is **white**. It is installed on the right rear corner of the machine [2].




d3brc1021

9. Peel the tapes from the backs of the two Velcro fasteners, and then attach them to the rear cover of the main machine.



d3brc1022


10. Select Antenna 1, with the black ferrite core [A] on its cable, and then attach it to the center [B].



d3brc1024

★ Important

- The tips of the antennas should not be above the edge of the rear cover.
- They must be straight and not slanted to one side.




d3brc1025

11. Attach the other antenna [A] behind the right rear corner of the machine.

★ Important

- Like the other antenna, the tip of this antenna should be perfectly vertical and not above the rear edge of the cover.



d3brc1026

12. Attach two clamps to the left of the controller box faceplate, set both harnesses in the clamps, and then close the clamps.



d3brc1027

13. Attach two clamps to the rear cover as shown, set both harnesses in the clamps, and then close the clamps.



d3brc1028

14. Keep the unused clamps, or you can attach additional clamps to the harnesses.



d3brc1029

15. Turn on the main machine.
16. Confirm that the machine can recognize the unit:
🏠 > 🗄️ > User Tools > Printer Features > List/Test Print > Configuration Page
17. If reception is poor, you may need to move the machine.

User Tool Settings for Wireless LAN

Do the procedure below to perform the initial interface settings for IEEE 802.11 a/g.

⬇️ Note

- You cannot use the wireless LAN if you use Ethernet.
- The Bluetooth interface unit and the Wireless LAN interface unit can not be used simultaneously.

1. 🏠 > 🗄️ > User Tools > Machine Features
2. On the touch panel, press "System Settings".

⬇️ Note

- The Network I/F (default: Ethernet) must be set for either Ethernet or wireless LAN.

3. Select "Interface Settings".
4. Press "Wireless LAN". Only the wireless LAN options show.
5. Communication Mode. Select either "802.11 Ad hoc" or "Infrastructure".
6. SSID Setting. Enter the SSID setting. (The setting is case sensitive.)
7. Channel. You need this setting when Ad Hoc Mode is selected.

Region A (mainly Europe and Asia)

Range: 1-13, 36, 40, 44 and 48 channels (default: 11)

Region B (mainly North America)

Range: 1-11, 36, 40, 44 and 48 channels (default: 11)

- Range: 1-11 channels (default: 11)
- In some countries, only the following channels are available:

Note

- The allowed range for the channel settings may vary for different countries.

8. WEP (Encryption) Setting. The WEP (Wired Equivalent Privacy) setting is designed to protect wireless data transmission. The same WEP key is required on the receiving side in order to unlock encoded data. There are 64 bit and 128 bit WEP keys.

WEP:

Selects "Active" or "Inactive" ("Inactive" is default.).

Range of Allowed Settings:

- 64 bit: 10 characters
- 128 bit: 26 characters

9. Press "Return to Default" to initialize the wireless LAN settings.

Press "Yes" to initialize the following settings:

- Transmission mode
- Channel
- Transmission Speed
- WEP
- SSID
- WEP Key

SP Mode and UP Mode Settings for IEEE 802.11 a/g Wireless LAN

The following SP commands and UP modes can be set for IEEE 802.11 a/g.

SP No.	Name	Function
5840-008	Transmission speed	Sets the transmission speed Auto, 54 Mbps, 48 Mbps, 36 Mbps, 24 Mbps, 18 Mbps, 12 Mbps, 9 Mbps, 6 Mbps, 11 Mbps, 5.5 Mbps, 2 Mbps, 1 Mbps (default: Auto)
5840-011	WEP Key Select	Used to select the WEP key (Default: 00).
UP mode	Name	Function
	SSID	Used to confirm the current SSID setting.

SP No.	Name	Function
	WEP Key	Used to confirm the current WEP key setting.
	WEP Mode	Used to show the maximum length of the string that can be used for the WEP Key entry.

File Format Converter Type M19

Accessory Check

Check the accessories and their quantities against this list:

No.	Description	Q'ty
1.	File Format Converter (MLB: Media Link Board)	1



d3brc1001

Installation

1. Switch the machine off.
2. Remove the cover of the "Option Slot" on the right.



 x2




d3b4c001

3. Insert the board into the slot.
4. Tighten the knob screws with your fingers.

★ Important

- To avoid damage to the board, never tighten these knob screws with a screwdriver.



d3b4c0002

5. Switch the machine on.
6. Set **SP5836-3** to "1" to enable the print backup feature.
7. Confirm or set the following SP codes with the values in the table listed below.

SP No.	Setting	SP No.	Setting
5-836-1	1	5-836-73	0

SP No.	Setting	SP No.	Setting
5-836-2	0	5-836-85	1
5-836-3	1	5-836-86	2
5-836-72	0	5-836-91	50


8. Set the following SP codes according to the customer's needs.

SP No.	Setting	Comment
SP5-836-94	2	Selects JPEG2000 file format for documents copied from the document server to Palm2. Note: Files backed up to Palm2 in J2K format cannot be edited by other software applications.
	0	Selects the TIFF file format for documents copied from the document server to Palm2. Note: Select this so the backed up files can be used with other software applications (editing, OCR, etc.) with only slight loss in image quality.
SP-5836-98	1	Applies dot correction and eliminates ghost images transferred from the back sides of double-sided originals when files are copied to Palm2. This selection also reduces the size of the file. Note: This function is applied to both J2K and TIFF files and is particularly useful for copying large J2K documents quickly with only a slight loss in image quality.
	0	Does not apply the features of the "1" setting when files are copied to Palm2. Note: This setting preserves the quality of the original image, especially with J2K files, but also requires more time for copying and requires more disk space to store the larger files.

USB Device Server Option Type M19

Accessories

2




d3bc1001

No	Items	Q'ty
1	Interface Board	1
2	USB Cable	1
3	Ferrite Core	2
4	Bands (Not Used)	2

Note

- An Ethernet cable is not provided with this option.

Interface Board



d3bcc1002

Note

- Take moment to see what is on the interface board faceplate before you install it because after installation it may be upside down.

No.	Item	Description
1	Switch	Pressure switch used to reset to the factory settings.
2	Ethernet port	Used to connect the network Ethernet cable.
3	USB port	Flat USB connector for the accessory USB used to connect the interface board to the main machine. Never use this port for any other purpose.
4	Upper LEDs	LEDs (2)
5	Lower LEDs	LED (1)

Installation

CAUTION

- Turn off the main power and disconnect the power supply cord.

★ Important

- When you install this option on the main machine for the first time, the interface board must be connected directly to your PC to set up the IP address and other network settings.
1. Turn off the main power of the machine, and unplug the power cord from the wall socket.
 2. Remove the slot cover.

2



 x2

d3b4c0001

3. Install the interface board in the interface slot.
4. Tighten the knob screws with your fingers.



d3bc1003

★ Important

- Tighten these knob screws with your fingers.
- Never use a screwdriver to tighten these screws.
- If a screw is tightened with too much pressure, this could damage the I/F board or the edged connectors between the I/F card and the controller board.

5. Remove the cover over USB-B slot [A].




d223d8709

6. Insert the flat connector of the accessory USB cable [A] into the **USB-A** connector on the interface board.
7. Insert the D-connector [B] into the **USB-B** port.




x2




d223d8710

8. Attach a ferrite core to each end of the network Ethernet cable so there is about 3 cm (1.2") between the core and head of the connector.



d3bcc1005

9. Insert one end of the Ethernet cable into the **Ethernet** connector of the interface board.





 x1

d3bcc1006


10. Insert the other end of the Ethernet cable to a PC for the network setup.
11. Plug the power cord into the wall socket and turn on the main power of the machine.

Note

- Do not unplug the USB cable while the machine is initializing this option (this may take 30-60 sec.)
 - The LEDs on the Ethernet port of the interface board will light after initialization is complete.
 - If the machine is accidentally unplugged, connect the cable again.
12. Print out the "Configuration Page".
 13. Confirm that the machine has recognized this option:  >  > User Tools > Printer Features > List/Test Page > Configuration Page
 14. Enter the SP mode.
 15. Open SP5985-002 (On Board USB) and set "0" to "1".

Ethernet Port LEDs

After this option is installed and initialized by the main machine, the LED indicators light up under the following conditions.



No.	LED Color	Indicates:
1	Green and Yellow	1000BASE-T
2	Green	10BASE-T
3	Yellow	100BASE-TX

~~Notes for Energy Save Mode Setting~~

~~If the machine which has this option enters into the Energy Save Mode, you cannot print because this will cause a communication error. Follow the procedure below to disable the Energy Save Mode function.~~

- ~~1. Press [Features Settings] on the operation panel.~~
- ~~2. Press [Administrator Tools] in [System Settings].~~
- ~~3. Press [Energy Saver Mode to Disable Print Server].~~
- ~~4. Press [Disable Mode].~~
- ~~5. Press [OK].~~
- ~~6. Press [Features Settings].~~

~~This section is deleted
RTB 24~~


IP Address Setting

This section describes how to set an IP address for this option manually.

You can set an IP address which is not only on the same network segment, but also on a different network segment to share a single printer with devices in multiple networks.

★ Important

- You cannot change the IP address for this option from the operation panel of the main machine. The setting must be done from a web browser on your PC.
 - The network setting of this option is initially assigned as follows:
IP address: 192.168.100.100 / Subnet mask: 255.255.255.0
 - The network setting of your PC must be in the same network segment to change the network setting of this option.
1. Make a note of the current network settings of your PC.
 2. Change the IP address on your PC to [192.168.100.xxx (0 - 255)].
 3. Change the subnet mask on your PC to [255.255.255.0].
 4. Open a Web Browser.
 5. Input **http://192.168.100.100/** in the address bar, and then press [Enter]. The setting screen for this option appears.
 6. Click [Network Setting].



d197f0134

7. Type [root] in the user name textbox and click [OK].
8. Input [IP Address], [Subnet Mask] and [Default Gateway].

IPv4	
Item	Value
IPv4	ENABLE ▾
DHCPv4	DISABLE ▾
IPv4 address	192.168.100.100
Subnet Mask	255.255.255.0
Default Gateway	0.0.0.0

d197f0135a

9. Set other items if required.
10. Press [Set]
11. Close the Web Browser.
12. Disconnect the Ethernet cable from the PC.
13. Connect the Ethernet cable to a network device (e.g. switching hub).
14. Set the IP address of this option in the printer driver which you use.

Extended USB Board Type M19

Accessories

No.	Description	Q'ty
1.	Extended USB Board M19	1

2



d223c1145

Only one I/F slot (labeled "Option") is available for one of these options:


- Centronics 1284
- IEEE 802.11 a/g/n (Wireless LAN)
- File Format Converter
- Extended USB Board Type M19

★ Important

- If another card is installed in the "Option" slot on the right, you must remove it before installing this option.

Installation

1. Switch the machine off.
2. Remove the cover of the "Option Slot" on the right.




 x2

d223c1146

3. Insert the board into the slot.
4. Tighten the knob screws with your fingers.

★ Important

- To avoid damage to the board, never tighten these knob screws with a screwdriver.




 x2

d223c1147

SD Card Options

Overview



2

Two SD card slots are provided on the controller box.

- **Slot 1.** Slot 1 is where most SD cards with applications on them are inserted for either use or downloading. When merging (copying) applications from one SD card to another, Slot 1 holds the target SD card (the application is moved to this card from the SD card in Slot 2.)
- **Slot 2.** Slot 2 is the service slot. This is where the SD card with the new firmware is inserted for the firmware update procedure. When merging (moving) applications from one SD card to another, Slot 2 holds the source SD card (the application is moved from this card to the SD card in Slot 1.)

Options Available on SD Cards

Here is a list the available options for this machine provided on SD cards.

- IPDS Unit Type M25 (D3D4)
- OCR Unit Type M13 (D3AC)
- PostScript3 Type M25 (D3D4-05)
- SD Card for Fonts Type D (D641)
- XPS Direct Print Option Type M25 (D3D4)

Note


- If the customer wants to use more than one application on SD cards, applications must be merged on the same SD card.

Important

- The data necessary for authentication is transferred with the application program to the target SD card. This is described below.
- Do not use an SD card if it has previously been used with a computer. Correct operation is not guaranteed if this type of SD card is used.
- The SD card is the only evidence that the customer is licensed to use the application program. The service technician may also occasionally need to check the SD card and its data to solve problems. For these reasons SD cards must be stored with the machine. The storage location is described at the end of this section.
- After an SD card has been used to move other applications onto that card, that SD card cannot be used for a different function.
- Before copying and application to an SD card, always make sure that the write-protect switch is OFF. It is very easy to accidentally turn on the write-protect switch when inserting or removing an SD card.

Inserting SD Cards


1. Turn the machine off.
2. Remove the SD card slot cover.



 x1

sdcc0001

3. With its corner notch down and label facing the front of the machine, insert the SD card into Slot 2.
4. Push the SD card in until it clicks and locks in place.



sdcc0003

Note

- Pushing in the SD Card also releases it for removal.
 - Make sure the SD Card is inserted and locked in place. If it is partially out of the slot, push it in gently until it locks in place.
5. Turn the machine on, and then proceed with the installation of the option.

Move Exec: Merging Applications


Do this procedure to put more than one application on one SD card.

★ Important

- Due to copyright restrictions, some applications may not allow you to copy the application to another SD card with Move Exec.
- In this case, just use the SD with the restricted application as the target SD card for Move Exec.

1. Turn the main machine off.
2. Remove the SD card slot cover.

2



 x1


sdcc0001

3. Insert the Source SD card [1] in Slot 2 (Service slot). This card contains the application that you want to move.
4. Check the target SD card and confirm that its write-protect switch is OFF.
5. Insert the Target SD card [2] into the SD card Slot 1.



sdcc0005

6. Open the front door.

7. Turn the main machine on.
8. Do **SP5873-001**.
9. Touch "Execute".
10. Follow the instructions on the display to complete the procedure.
11. Turn the machine off.
12. Remove the Source SD card from Slot 2. Leave the target SD card in Slot 1.
13. Turn the main machine on.
14. Go into the User Tools mode and confirm that all the applications on the SD card in Slot 1 are enabled:
 > **User Tools** > **System Settings** > **Administrator Tools** > **Firmware Version**
15. Turn the main machine off again.
16. Remove the SD card in Slot 1.
17. Reattach the SD card slot cover.
18. Store the copied SD cards in the machine. (See below.)


Important

- **Never remove copied SD cards from the machine site. The copied original SD cards are the only proof that the customer has purchased the options.**
- **After an SD card has been copied, it can no longer be used. However, it must be stored in the machine to serve as proof of purchase by the customer.**
- **The original SD card can also be restored to its original condition with the Undo Exec procedure (SP5873-002) described below.**
- **Before you store an SD card, label it carefully so it can be identified easily if you need to do the Undo Exec procedure.**

Undo Exec: Unmerging Applications

Do this procedure if you moved an option from the original SD card to another card by mistake and you need to restore the original SD card.

1. Turn the machine off.
2. Insert the SD card holding the merged applications in SD Card Slot 1 [A].
3. Put the original destination SD card (the one removed from storage) into Slot 2 [B].



d223c2006

↓ Note

- The SD card in Slot 2 must be the original SD card of the application you want to move from Slot 1 to Slot 2. You cannot use any blank SD card in Slot 1.

4. Turn the main switch ON.
5. Do **SP5873-002** (Undo Exec).
6. Follow the instructions on the operation panel to complete the procedure..
7. Turn the machine off.
8. Remove the SD cards from the slots.
9. Replace the SD card slot cover (🔑 x1).
10. Turn the main switch ON.

Storing Original SD Cards

SD cards must be stored at the site to server as proof of purchase by the customer. Do not remove copied SD cards from the machine site. Store the SD cards inside the machine for safekeeping.


1. Turn off the machine and disconnect the power cord.
2. Raise the platen.
3. Disconnect the front edge cover (🔑 x2).



4. Bend the ends of the cover toward you slightly to disengage the tabs on the ends, and then remove the front edge cover.



5. Locate the slots at the upper right corner of the operation panel display [A].



6. Up to three SD cards can be stored here.

OCR Type M13

What is Searchable PDF?

2

- Searchable PDF embeds the text information in the scanned document without processing the data on a computer.
- If this option is installed:
 1. You can search the text in the scanned document.
 2. You can add extra text to the file name.
 3. The orientation of the originals is detected, and the document is automatically rotated.
- The OCR unit is provided on an SD card. By installing the SD card on the main machine, a function key is added to the operation panel. The OCR application does not need to be installed on the computer.
- After OCR installation, you can specify the settings of the searchable PDF function.
- The machine embeds the text information of the scanned document after scanning the originals (after the originals are ejected from the ADF). Therefore, you can remove the originals from the exposure glass or ADF.
- You can use other applications such as copy and printer while the machine embeds the text information of the scanned document.

Accessories

Check the quantity and condition of the accessories in the box against the following list.

No.	Description	Q'ty
1.	SD Card	1




d1791230

Installation

⚠ WARNING


- Unplug the main machine power cord before you do the following procedure.
1. Remove the SD card slot cover.



⚙ x1

sdcc0001

2. Insert the OCR SD card in Slot 2 with its label facing the front of the machine.



sdcc0003

3. Turn on the machine.
4. Go into the SP mode and do **SP5-878-004**.
 - This records the content of the SD card in NVRAM
 - The machine ID of the main machine is recorded on the SD card.
5. When the display tells you that the execution is completed, touch [Exit].

- If the machine returns the “Failed” alert, check if the SD card to determine if it has already been used.
- Turn off the machine and then steps 1 to 5 again.

6. Cycle the machine off/on.

7. Go in the SP mode and do **SP5-878-004** (Option Setup: OCR) and then press [EXECUTE]. The OCR dictionary is copied to the HDD from the SD card.

- In the first execution, the SD card and the machine are linked.
- In the second execution, the OCR dictionary is copied onto the HDD.


8. Turn off the machine, and then remove the SD card.

★ Important

- **Store the SD card in a safe location.**
- **You will need the original SD card in case the HDD unit ever fails.**


9. Turn on the main power switch.

10. On the “Scanner” screen touch [Send File Type / Name].



d1791220

11. Check to see if [OCR Settings] is displayed on the [Send File Type / Name] screen.



d1791221

- The searchable PDF function can be switched on/off on the [OCR Settings] screen after installing the OCR unit.
- If you want to use the searchable PDF function, select [On] for [OCR Settings]. (Default: [Off])

Restoration

After installation of the OCR Unit:

- The searchable PDF function is saved on the HDD and the SD card ID is saved in NVRAM.
- After replacement of either the HDD unit or the NVRAM, OCR Unit Type M2 must be installed again.

When the original SD card exists

- **If you replace the HDD.**
Re-install the OCR Unit Type M2 from the original SD card.
- **If you replace the NVRAM.**
If you upload / download the NVRAM data, re-install the OCR Unit Type M2 from the original SD card. If you don't upload / download the NVRAM data, order a new SD card (service part) of the OCR Unit Type M2. Then re-install the OCR Unit Type M2 from the new SD card.
- **When you replace the HDD and NVRAM at the same time.**
Re-install the OCR Unit Type M2 from the original SD card.

If Original SD Card is Lost

- Order a new SD card (service part) of the OCR Unit Type M2, and then re-install from the new SD card.


- When you re-install the OCR Unit Type M2, do the same procedure as the original installation procedure.

PostScript3 Unit Type M25

Accessories

No.	Description	Q'ty
1.	PostScript3 Emulation SD Card	1
2.	Decal	1

2




d1791212

★ Important

- Only Slot 1 is available for applications on SD cards. If more than one application will be used, the applications must be merged onto one SD card with SP5873 -1.

Installation


1. Switch the machine off.
2. Remove the SD card slot cover.



 x1


sdcc0001

3. Set the SD card with its label facing the front of the machine, and then push it in until it clicks.



sdcc0002

4. Switch the machine on.
5. Print an SMC report to confirm that the machine recognizes the option.
6. Re-attach the SD card slot cover.
7. Attach the Adobe PostScript3 decal to the front of the machine.
8. If application has been moved to another SD card, store the original card under the operation panel at [A]. (The original SD card is the client's only proof of purchase.) page 408



d223c2001


IPDS Unit Type M25

Check the quantity and condition of the accessories in the box against the following list and diagram.

Accessories

2

No	Description	Q'ty
1	IPDS Emulation SD Card	1
2	Decal	1




d1791212

Installation

⚠ WARNING


- Unplug the main machine power cord before you do the following procedure.
1. Remove the SD card slot cover.



 x1

sdcc0001

2. Insert the target SD card into Slot 1 [1] with its label facing the front of the machine.
3. Insert the IPDS SD card into Slot 2 [2] with its label facing the front of the machine.



sdcc0006

4. Perform the SD Card Appli Move with **SP5873-001**.
5. After the application move is finished, remove the SD card from Slot 2
6. Turn on the machine.
7. Make sure that the machine recognizes the option:
[User Tools] > Printer Features > List/Test Print > Configuration Page
8. Attach the decal to the left side of the Adobe PDF decal on the right door.


XPS Direct Print Option Type M25 D3D4

Check the quantity and condition of the accessories in the box against the following list and diagram.

2

Accessories


No	Description	Q'ty
1	SD Card	1




d595i900b

Installation

1. Remove SD card slot cover [A].



2. Insert the XPS card in Slot 1.




sdcc0002

Note

- If another card is in Slot 1, do Move Execute to move the content of the XPS card to the card in Slot 1. page 405

3. After doing the merge, remove the SD card from Slot 2 and store it. page 408



d223d8705

2

4. The card in Slot 1 must remain in Slot 1.

Data Overwrite Security Unit Type M19 (D3BS)

Overview


This option should be installed only for the customer who requires the CC certified Data Overwrite Security function. The function of this option is completely the same as the Data Overwrite Security in Security Functions, which is standard on this machine.

2

Component List

Check the quantity and condition of the accessories in the box against the following list.

No.	Description	Q'ty
1.	SD Card	1



d1791217

Before You Begin the Procedure

1. Confirm that the Data Overwrite Security unit SD card is the correct type for the machine. The correct type for this machine is "Type M19".

★ Important

- If you install any version other than "Type M19", you have to replace the NVRAM and do this installation procedure again.
2. Make sure that the following settings are not at their factory default values:
 - Supervisor login password
 - Administrator login name
 - Administrator login password

If any of these settings is at a factory default value, tell the customer these settings must be changed before you do the installation procedure.

3. Make sure that "Admin. Authentication" is ON.

[System Settings] > [Administrator Tools] > [Administrator Authentication Management] > [Admin. Authentication]

If this setting is OFF, tell the customer this setting must be ON before you do the installation procedure.

4. Make sure that "Administrator Tools" is enabled (selected).


[System Settings] > [Administrator Tools] > [Administrator Authentication Management] > [Available Settings]

If this setting is disabled (not selected), tell the customer this setting must be enabled (selected) before you do the installation procedure.

Seal Check and Removal

CAUTION


- Before doing the installation, you must check the box seals to make sure that they have not been removed after the items were sealed in the box at the factory.
1. Check the box seals [A] on each corner of the box.
 - Make sure that a tape is attached to each corner.
 - The surfaces of the tapes must be blank.
 - If you see "VOID" on the tapes, do not install the components in the box.
 2. If the surfaces of the tapes do not show "VOID", remove them from the corners of the box.
 3. You can see the "VOID" marks [B] when you remove each seal. After removal they cannot be attached to the box again.



d377i951

Installation Procedure

1. Turn the main power OFF.
2. Remove the SD card slot cover (🔩 × 1)




🔩 x1

sdcc0001

3. Insert the SD card into SD Slot 1 with its label facing the front of the machine.
4. Push it slowly until you hear a click.

2



sdcc0003

5. Do **SP5-878-001** to install the application.

After Installation Check

Safety Check

Check the following points after installing the machine, or after moving or transporting it to a new location. Consult with the operator before making or scheduling any changes. Determine which changes should be done by the client and those that should be done by the service technician.

2

Check List

The answer should be "Yes" for each item in the table. As each task is accomplished initial the "Client" or "CE" for whoever confirmed the point.

No.	Item	Done by:	
		Client	CE
	Excessive Vibration		
1	Floor strong enough to prevent vibration?		
2	Machine located away from vibrating floors, machinery?		
	Power		
3	Power supply point dedicated for the machine and not shared with other devices?		
4	Cable and connection point capacity rated correctly for the requirements of the machine?		
5	Power cable connection point stable and not loose?		
6	Power connection point clean, free of dust?		
7	Power cord connection point close to the machine so it can be reached quickly in an emergency?		
8	Power cord away from foot traffic, not bundled or under other equipment?		
9	Power cord slack and free (not taut or bundled) and free of damage?		

No.	Item	Done by:	
		Client	CE
10	Power source rated correctly for machine specifications, and initial display does not flicker after power on?		
11	Is machine grounded properly?		
	Setup Location		
12	Machine located away from space heaters, heating ducts, humidifiers?		
13	Ambient temperature stable and not subject to wide range of low/high temperatures which could cause condensation in the machine?		
14	Machine located away from direct sunlight and open windows (protected from dust, rain)?		
15	No televisions, radios near the machine which could cause noise interference?		
16	Area around machine and power point free of dust?		
17	Bulk of machine located away from heavy foot traffic at the work site?		
	Ventilation		
18	Is the machine in a well-ventilated area?		
19	Is there sufficient space behind the machine for ventilation, away from personnel?		
	Other		
20	Are the exposure glass and contact glass free of nicks and scratches?		
21	Are the areas around moving parts of finishers (shift trays, etc.) free of obstacles that could interfere with their operation?		

Security Setting

Security Function Installation

The machine contains two security functions: Data Overwrite Security and HDD Encryption. Both are built-into the firmware on the controller board.

- If you are installing a new machine, and the user wants to use these security functions, you must log in as the System Administrator and activate Data Overwrite Security and HDD Encryption by selecting "**Format All Data**" from "System Settings" on the operation panel. Formatting the HDD is recommended because there is no user data on the hard drive yet (Address Book data, image data, etc.).
- If the customer needs to activate the Data Overwrite Security and HDD Encryption unit on a machine that is already running (valuable data is already on the HDD), activate the unit by selecting "**All Data**" from "System Settings" on the operation panel. Selecting "**All Data**" will preserve the data that has already been saved to the HDD. If there is data on the HDD and "**Format All Data**" is selected, all user data saved to the HDD up to that point will be erased.

Please keep these points in mind when setting up these security features:

- Encryption setup will take several minutes to complete.
- If encryption is enabled after data has been stored on the HDD, or if the encryption key is changed, this process can take up to three and a half hours or more.
- The machine cannot be operated while data is being encrypted.
- Once the encryption process begins, it cannot be stopped.
- Never allow the machine to shut down while the encryption setup is in progress.
- If the machine loses power while the encryption setup is in progress, the HDD will be damaged and all data on it will be unusable.

★ Important



- **Print the encryption key and then store it in a safe place. If the encryption key is lost, the controller board, HDD and NVRAM on the controller board must all be replaced at the same time.**

Data Overwrite Security

Using Auto Erase Memory

The Auto Erase Memory function can be enabled by the following procedure.

1. Log in as the machine administrator from the control panel.

	Icon 1	This icon is lit when there is temporary data to be overwritten, and blinks during overwriting.
	Icon 2	This icon is lit when there is no temporary data to be overwritten.

HDD Encryption

Before You Begin the Procedure:

1. Make sure that the following settings (1) to (3) are not at the factory default settings.

(1) Supervisor login password

(2) Administrator login name



(3) Administrator login password

If any of these settings is at a factory default value, tell the customer these settings must be changed before you do the installation procedure.

2. Confirm that "Admin. Authentication" is on:  >  > User Tools > Machine Features > System Settings > Administrator Tools > Administrator Authentication Management > Admin. Authentication > On

If this setting is off, tell the customer that this setting must be on before you can do the installation procedure.

3. Confirm that "Administrator Tools" is selected and enabled.

 >  > User Tools > Machine Features > System Settings > Administrator Tools > Administrator Authentication Management > Available Settings

"Available Settings" is not displayed until step 2 is done.

If this setting is not selected, tell the customer that this setting must be selected before you can do the installation procedure.


Enable Encryption Setting

Machine Data Encryption Settings can be enabled by the following procedure.

Important


- When setting up encryption, specify whether to start encryption after deleting data (initialize) or encrypt and retain existing data. If data is retained, it may take some time to encrypt it.

1. Turn on the main power.
2. Log in as the machine administrator from the control panel.
3. Press [System Settings].
4. Press [Administrator Tools].
5. Press [Next] three times.
6. Press [Machine Data Encryption Settings].



w_d1822518

7. Press [Encrypt].



w_d1822519



8. Select the data to be carried over to the HDD and not be reset.
 To carry all of the data over to the HDD, select [All Data].
 To carry over only the machine settings data, select [File System Data Only].
 To reset all of the data, select [Format All Data].
9. Select the backup method.
 If you have selected [Save to SD Card], load an SD card into the media slot on the side of the control panel and press [OK] to back up the machine's data encryption key.


If you have selected [Print on Paper], press the [Start] key. Print out the machine's data encryption key.

10. Press [OK].
11. Press [Exit].
12. Press [Exit].
13. Log out.
14. Turn off the main power, and then turn the main power back on.

The machine will start to convert the data on the memory after you turn on the machine. Wait until the message "Memory conversion complete. Turn the main power switch off." appears, and then turn the main power off again.

Check the Encryption Settings

1.  >  > User Tools > Machine Features
2. Press [System Settings].
3. Press [Administrator Tools].
4. Press [Machine Data Encryption Settings].
5. Confirm whether the encryption has been completed or not on this display.



w_d1822520

Backing Up the Encryption Key

The encryption key can be backed up. Select whether to save it to an SD card or to print it.

★ Important

- The encryption key is required for data recovery if the machine malfunctions. Be sure to store the encryption key safely for retrieving backup data.

1. Log in as the machine administrator from the control panel.

2. Press [System Settings].
3. Press [Administrator Tools].
4. Press [Next] three times.
5. Press [Machine Data Encryption Settings].
6. Press [Print Encryption Key].



w_d1822515

7. Select the backup method.

If you have selected [Save to SD Card], load an SD card into the media slot on the side of the control panel and press [OK]; once the machine's data encryption key is backed up, press [Exit].


If you have selected [Print on Paper], press the [Start] key. Print out the machine's data encryption key.

8. Press [Exit].
9. Log out.

Encryption Key Restoration

How to restore the old encryption key to the machine

The following message appears after the controller board is replaced. In such a case, it is necessary to restore the encryption key to the new controller board.



d1420101

To do this, follow the procedure below.

1. Prepare an SD card that has been initialized in FAT16 format.
2. Using a PC, create a folder in the SD card and name it "restore_key".

3. Create a folder in the "restore_key" folder and name it the same as machine's serial number, "xxxxxxxxxxx" (11 digits).
4. Create a text file called "key_xxxxxxxxxx.txt" and save it in the "xxxxxxxxxxx" folder. Write the encryption key in the text file.

```
/restore_key/xxxxxxxxxxx/key_xxxxxxxxxx.txt
```

↓ Note

- Ask an Administrator to enter the encryption key. The key has already been printed out by the user and may have been saved in the "key_xxxxxxxxxx.txt" file. (The function of back-up the encryption key to the SD card directly is provided 11A products or later.)

5. Turn on the machine's main power.
6. Confirm that a message is displayed on the LCD telling to insert the SD card that contains the encryption key.
7. Turn off the main power.
8. Insert the SD card that contains the encryption key into SD card slot 2 (the lower slot).
9. Turn on the main power.

↓ Note

- The machine will automatically restore the encryption key to the flash memory on the controller board.

10. Turn off the main power when the machine has returned to normal status.
11. Remove the SD card from SD card slot 2.

How to do a forced start up with no encryption key

If the encryption key back-up has been lost, follow the procedure below to do a forced start-up.

★ Important

- **The HDD will be formatted after the forced start-up.**
- **Encrypted data will be deleted.**
- **User settings will be cleared.**

1. Prepare an SD card.
2. Create a directory named "restore_key" inside the root directory of the SD card. Then, save the "nvram_key.txt" file using the following name:

```
/restore_key/nvram_key.txt
```

3. Create a text file and write "nvclear".

★ Important

- **Write this string at the head of the file.**
- **Use all lower-case letters.**

- Do not use quotation marks or blank spaces.
- It is judged that a forced start has been selected when the content of "nvclear" is executed and the machine shifts to the alternate system (forced start).

4. Confirm that a message is displayed on the LCD telling to insert the SD card that contains the encryption key.
5. Turn off the main power.
6. Insert the SD card that contains the encryption key into SD card slot 2 (the lower slot).
7. ~~Turn on the main power.~~
8. Turn on the main power switch, the machine automatically clear the HDD encryption.
9. Turn off the main power when the machine has returned to normal status.
10. Remove the SD card from SD card Slot 2.
11. Turn on the main power.
12. Memory clear SP5-801-xx (Exclude SP-5-801-001: All Clear and SP-5-801-002: Engine), and clear SP5-846-046: address book.
13. Set necessary user settings in User Tools menus.

@Remote Settings

Note

- Prepare and check the following check points before you visit the customer site. For details, ask the @Remote key person.

Check points before making @Remote settings

1. The setting of SP5816-201 in the mainframe must be "0".
2. Print the SMC with SP5990-002 and then check if a device ID2 (SP5811-003) must be correctly programmed.
 - 6 spaces must be put between the 3-digit prefix and the following 8-digit number (e.g. xxx____xxxxxxxx).
 - ID2 (SP5811-003) and the serial number (SP5811-001) must be the same (e.g. ID2: A01____23456789 = serial No. A0123456789)
3. The following settings must be correctly programmed.
 - Proxy server IP address (SP5816-063)
 - Proxy server Port number (SP5816-064)
 - Proxy User ID (SP5816-065)
 - Proxy Password (SP5816-066)

4. Get a Request Number

Execute the @Remote Settings

1. Enter the SP mode.
2. Input the Request number which you have obtained from @Remote Center GUI, and then enter [OK] with SP5816-202.
3. Confirm the Request number, and then click [EXECUTE] with SP5816-203.
4. Check the confirmation result with SP5816-204.

Value	Meaning	Solution/ Workaround
0	Succeeded	-
3	Communication error (proxy enabled)	Check the network condition.
4	Communication error (proxy disabled)	Check the network condition.
5	Proxy error (authentication error)	Check Proxy user name and password.
6	Communication error	Check the network condition.
8	Other error	See "SP5816-208 Error Codes" below this.

Value	Meaning	Solution/ Workaround
9	Request number confirmation executing	Processing... Please wait.
11	Already registered	-
12	Parameter error	-
20	Dial-up authentication error	These errors occur only in the modems that support @Remote.
21	Answer tone detection error	
22	Carrier detection error	
23	Invalid setting value (modem)	
24	Low power supply current	
25	unplugged modem	
26	Busy line	

5. Make sure that the screen displays the Location Information with SP5816-205 only when it has been input at the Center GUI.
6. Click [EXECUTE] to execute the registration with SP5816-206.
7. Check the registration result with SP5816-207.

Value	Meaning	Solution/ Workaround
0	Succeeded	-
1	Request number error	Check the request number again.
2	Already registered	Check the registration status.
3	Communication error (proxy enabled)	Check the network condition.
4	Communication error (proxy disabled)	Check the network condition.
5	Proxy error (Authentication error)	Check Proxy user name and password.
8	Other error	See "SP5816-208 Error Codes" below this.
9	Request number confirmation executing	Processing... Please wait.
11	Already registered	-
12	Parameter error	-

Value	Meaning	Solution/ Workaround
20	Dial-up authentication error	These errors occur only in the modems that support @Remote.
21	Answer tone detection error	
22	Carrier detection error	
23	Invalid setting value (modem)	
24	Low power supply current	
25	unplugged modem	
26	Busy line	

8. Exit the SP mode.

SP5816-208 Error Codes: Caused by Operation Error, Incorrect Setting

Code	Meaning	Solution/ Workaround
-12002	Inquiry, registration attempted without acquiring Request No.	Obtain a Request Number before attempting the Inquiry or Registration.
-12003	Attempted registration without execution of a confirmation and no previous registration.	Perform Confirmation before attempting the Registration.
-12004	Attempted setting with illegal entries for certification and ID2.	Check ID2 of the mainframe.
-12005	@Remote communication is prohibited. The device has an Embedded RC gate-related problem.	Make sure that "Remote Service" in User Tools is set to "Do not prohibit".
-12006	A confirmation request was made after the confirmation had been already completed.	Execute registration.
-12007	The request number used at registration was different from the one used at confirmation.	Check Request No.
-12008	Update certification failed because mainframe was in use.	Check the mainframe condition. If the mainframe is in use, try again later.

Code	Meaning	Solution/ Workaround
-12009	The ID2 in the NVRAM does not match the ID2 in the individual certification.	Check ID2 of the mainframe.
-12010	The certification area is not initialized.	Initialize the certification area.

Error Caused by Response from GW URL

Code	Meaning	Solution/ Workaround
-2385	Other error	
-2387	Not supported at the Service Center	
-2389	Database out of service	
-2390	Program out of service	
-2391	Two registrations for the same mainframe	Check the registration condition of the mainframe
-2392	Parameter error	
-2393	External RCG not managed	
-2394	Mainframe not managed	
-2395	Box ID for external RCG is illegal.	
-2396	Mainframe ID for external RCG is illegal.	
-2397	Incorrect ID2 format	Check the ID2 of the mainframe.
-2398	Incorrect request number format	Check the Request No.

User Instructions

Operation Guidance for Users

2

Function/Operation	Instruction to provide
Basic machine functions, operations	<ul style="list-style-type: none"> • How to load the toner bottle • How to load paper and other consumables/supplies • How to turn the main power switch ON/OFF • How to clear paper jams • How to program, modify, and delete Address Book entries • How to customize the UI and home screen • Overview of machine options/peripherals • How to take the proper action for SC errors (clearing the error, contacting service and support, etc.), how to interpret @Remote notifications • Setting up ARFU (Auto Remote Firmware Update). • Important notes to keep in mind whenever moving the machine • Product limitations
Copier	<ul style="list-style-type: none"> • Basic Copier operations • How to load an original in the ARDF or place it on the exposure glass for scanning • How to use thick paper and other specialized paper/media • How to configure the Copier main screen (duplex/simplex, auto color selection, User Codes, etc.) • Basic Document Server operations
Fax (when installed)	<ul style="list-style-type: none"> • How to send a fax (Memory Transmission, Direct Transmission)
Printer (when installed)	<ul style="list-style-type: none"> • How to install printer drivers (using the recommended method) • How to connect to a PC (performing the port settings) • How to print out a test page • Overview of various settings inside each tab in the printer driver (e.g. duplex printing)

Function/Operation	Instruction to provide
Scanner (when installed)	<ul style="list-style-type: none">• How to install printer drivers (using the recommended method)• How to connect to a PC and perform a test scan

3. Preventive Maintenance

PM Tables

The amounts mentioned (K=1,000) as the PM interval indicate the number of prints or copies unless stated otherwise. These numbers are based on the PM counter.

Symbol Key

Letter	Meaning
AN	As Necessary, or at scheduled maintenance
C	Clean
EM	Emergency Maintenance
Exp	Expected service life
I	Inspect
L	Lubricate
R	Replace

WARNING

- Turn off the power switch and unplug the power cord before performing any procedure in this section. Laser beams can seriously damage the eyes.

Main Machine

Scanner Optics

Item	300K	AN	Note
1st, 2nd, 3rd Mirror		C	Optics cloth
Contact Glass	C	C	Damp cloth
Dust Filters		C	Blower brush
Exposure Glass	C	C	Damp cloth

Item	300K	AN	Note
Reflectors		C	Optics cloth
Scanner Guide Rails (both sides)		CL	After cleaning with alcohol, lubricate with Launa Oil.
Toner Shield Glass		C	Optics cloth

3

Around the Drum

Item	300K	450K	AN	Exp.	Note
Charge Corona Casing	C		C		Damp cloth
Charge Corona Grid	R			450K	Blower brush
Charge Corona Wire	R	R	C	450K	Alcohol cloth
Charge Wire Cleaning Pad	R	R		450K	
Cleaning Filter	R				Blower brush
Drum				1200K	Dirty background, distorted images. Always apply setting powder to new drum.
Dust Filter (intake)			C		Blower brush
ID Sensor	C		C		Blower brush. Do SP 3001-2 after cleaning.
Ozone Filter				450K	Blower brush
PTL	C		C		Dry cloth, PTL case
Pick-off Pawl Brackets	IC		IC		Dry cloth
Pick-off Pawls	IC		IC		Replace if damaged.
Potential Sensor	C		C		Blower brush
Quenching Lamp	C		C		Dry cloth
Transfer Entrance Stay	C		C		Damp cloth

Drum Cleaning

Item	300K	AN	Exp.	Note
Cleaning Blade	R		500K	Dry cloth
Cleaning Brush	R			Poor blade cleaning causes distorted images.
Cleaning Entrance Seal		IC		Inspect for cracks, fissures. Dry cloth
Cleaning Unit Casing	C	C		Dry cloth
Internal Dust Filter		C		Blower brush
Side Seals		C		Dry cloth
Toner Collection Bottle		C	1500K	Empty at bottle full prompt or at 1500K
Toner Pan	C	C		Dry cloth

3

Development Unit

Item	300K	AN	Note
Developer	R		Initialize new developer with SP2801-1 PM cycle is 350K.
Development Filter	R	I	Inspect the gaps between filter and casing after cleaning or replacement and confirm that they are tight.
Development Roller	C		Dry cloth on roller, and sleeve when developer is replaced.
Development Roller Drive Shaft	C	C	Clean with blower brush and dry cloth every time the developer is replaced.
Development Unit Casing	C	C	Dry cloth
Entrance Seal	C	C	Blower brush, dry cloth
Paddle Roller Shaft*1	C	C	Blower brush, dry cloth.
Pressure Release Duct	IC		Remove toner collected inside duct

Item	300K	AN	Note
Side Seals	C	C	Blower brush, dry cloth
Toner Bottle Gear	C	C	Blower brush
Toner Bottle Holder	C	C	Dry cloth
Toner Hopper	C	C	Dry cloth
Toner Trap	C	C	Dry cloth
Used Toner Separation Unit	I		

*1	Remove front knob and rear gear of development unit and inspect the shaft. After 3000K inspect every 300K. Replace shaft if toner is leaking.
----	---

Paper Feed: Main Paper Path

Item	300K	AN	Note
Registration Rollers	C		Alcohol damp cloth
Relay Rollers	C		Alcohol damp cloth
Paper Dust Mylar	C	C	Dry cloth
Registration Sensor	C		Blower brush
Relay Sensor	C		Blower brush
Bypass Paper End Sensor	C		Blower brush
Bypass Paper End Sensor	C		Blower brush
Bypass Paper Length Sensor	C		Blower brush

Paper Feed: Paper Trays

Item	300K	600K	AN	Note
Feed Rollers 1, 2, 3				See Notes below this table.
Grip Drive Rollers, Idle Rollers	C			Dry cloth, blower brush

Item	300K	600K	AN	Note
Paper End Sensors 1, 2, 3	C	C		Blower brush
Paper Feed Guide Plate	C			Dry cloth
Paper Feed Sensors 1, 2, 3	C			Blower brush
Pick-up Rollers 1, 2, 3			R	See Notes below this table.
Separation Rollers			R	
Vertical Guide Plate	C			Dry cloth
Vertical Path Relay Sensor	C			Blower brush
Vertical Transport Rollers	C	C		Alcohol

Notes:

- Always replace pick-up, feed and separation rollers as a set.
- Increasing frequency of paper jams and double-feeds indicates that the rollers need to be replaced.

Transfer Belt Unit

	300K	450K	Exp.	Note
Discharge Plate *1	R			Dry cloth
Slide Rail Bracket *2	C			Dry cloth
Transfer Belt Unit Casing *2	C			Dry cloth
Transfer Belt *2		R	750K	Dry cloth
Transfer Bias Roller	C			Dry cloth
Transfer Cleaning Roller	R			Dry cloth
Transfer Drive Roller	C			Dry cloth
Transfer Entrance Guide Plate	C			Dry cloth
Transfer Exit Guide Plate	C			Dry cloth
Transfer Idle Roller	C			Dry cloth

	300K	450K	Exp.	Note
Transfer Roller Cleaning Blade		R	750K	Dry cloth

*
1 Always clean the transfer belt unit casing before replacing the discharge plate.

*
2 Dirty backside printing and poor paper separation from the drum are signs that the transfer belt and transfer roller cleaning blade need replacement. Always replace transfer belt and transfer roller cleaning blade together.

3

Fusing Unit and Paper Exit

Item	By	360K	AN	Exp.	Note
Cleaning Web	S	R	R		Replace at near-end alert.
Cleaning Web Pressure Roller Bearings*1	S	R			Replace if fissures, deformations evident
Cleaning Web Pressure Roller*1	S	R			Replace roller and bushings together.
Fusing Entrance Guide Plate		C	C		Dry cloth
Fusing Exit Guide Plate		C			Dry cloth
Fusing Lamps		I			Inspect wires, connections carefully
Hot Roller		R		450K	
Hot Roller Bearings	S	R		450K	
Hot Roller Strippers*2	S	R		IC	
Pressure Cleaning Roller Bearings*3	S	R		450K	
Pressure Roller		R		450K	
Pressure Roller Bearings				450K	
Pressure Roller Cleaning Roller*3	S	R			

Item	By	360K	AN	Exp.	Note
Thermistors x2 *4		R			Inspect and clean with blower brush every 200K.

*1	Always replace cleaning web pressure roller and roller bearings together.
*2	Frequent fusing unit jams, excessive toner on prints, and pawl tracks on paper edges indicate the strippers should be replaced.
*3	Always replace pressure roller bearings when pressure roller cleaning roller is replaced.
*4	Always replace thermistors when hot roller is replaced.

3

Fusing Unit Paper Exit

Item	300K	AN	Note
De-Curler Rollers	C		Alcohol damp cloth
Exit Static Discharge Brush	C	R	Replace if deformed, broken
Exit Rollers	C		Alcohol damp cloth
Transport Rollers	C		Alcohol damp cloth

Duplex

Item	300K	AN	Note
Entrance Sensor	C	C	Blower brush
Inverter Exit Rollers	C		Alcohol
Reverse Trigger Rollers	C		Dry cloth
Transport Rollers	C		Dry cloth
Inverter Entrance Roller	C		Dry cloth
Entrance Anti-Static Brush	C		Dry cloth
Reverse Junction Gate	C		Dry cloth

ADF

The PM interval is for the number of originals that have been fed.

Item	120K	AN	Note
CIS exit roller		C	Alcohol damp cloth, then water damp cloth
CIS glass		C	Wipe with clean cloth and Ricoh contact glass cleaner (A1939310).
Driver rollers		C	Alcohol damp cloth, then water damp cloth
Exit roller		C	Alcohol damp cloth, then water damp cloth
Exit sensor		C	Blower brush
Feed belt* ¹	R	C	Damp cloth, water or alcohol
Interval sensor		C	Blower brush
Original size sensors		C	Blower brush
Paper drive gear		C	Blower brush
Pick-up roller* ¹	R	C	Damp cloth
Platen		C	Blower brush
Registration sensor		C	Blower brush
Relay roller		C	Lubricate with EM-50L grease for resin base material.
Scan entrance roller		C	Alcohol damp cloth, then water damp cloth
Scan exit roller		C	Alcohol damp cloth, then water damp cloth
Scan reverse side roller		C	Alcohol damp cloth, then water damp cloth
Separation roller* ¹	R	C	Damp cloth
Separation sensor		C	Blower brush
Skew correction sensor		C	Blower brush
Transport roller		C	Alcohol damp cloth, then water damp cloth
White guide plate		C	Alcohol damp cloth, then water damp cloth

*1	Pick-up roller, feed roller, and separation roller should always be replaced together as a set.
----	---

Optional Peripheral Devices

LCIT 4040 (D3A6-17, -27)

	300K	450K	1000K	Exp.	Note
Pick-up Roller			R	1000	Always replace these rollers as a set. The target service life of the feed, pick-up, and separation rollers is 1000 K. However, they should be replaced sooner if the machine begins to jam or double-feed
Feed Roller			R	1000	
Separation Roller			R	1000	

3

Cover Interposer Tray CI4040 (DC3N) (for 2K/3K Finishers)

The cover interposer tray can be used with the Finisher SR4120 (D3CG), or Booklet Finisher SR4130 (D3CH). The interposer tray is installed between the main machine and the finisher.

Note: The PM interval is for the number of sheets that have been fed.

	60K	120K	180K	Exp.	Note
Feed Belt	R	R	R		Replace as a set.
Pick-up Roller	R	R	R		
Separation Roller	R	R	R		
Driver Rollers	C	C	C		Damp clean cloth.
Idle Rollers	C	C	C		Damp clean cloth.
Discharge Brush	C	C	C		Damp clean cloth.
Sensors	C	C	C		Blower brush.

Cover Interposer Tray CI4030 (D3D7)

The cover interposer tray is used with the Finisher SR4080 (D610). The interposer tray is installed between the main machine and the finisher.

Note: The PM interval is for the number of sheets that have been fed.

	60K	120K	180K	Exp.	Note
Feed Belt	R	R	R		Replace as a set.
Pick-up Roller	R	R	R		
Separation Roller	R	R	R		
Driver Rollers	C	C	C		Damp clean cloth.
Idle Rollers	C	C	C		Damp clean cloth.
Discharge Brush	C	C	C		Damp clean cloth.
Sensors	C	C	C		Blower brush.

Finisher SR4080 (D610)

	350K	700K	1050K	Exp.	Note
Drive rollers	I	I	I		Alcohol
Idle rollers	I	I	I		
Discharge brush	I	I	I		
Bushings	I	I	I		Lubricate with silicone oil if noisy.
Sensors	I	I	I		Blow brush.
Jogger fences	I	I	I		Make sure screws are tight.
Staple waste hopper	C	C	C		Empty staple waste.

Finisher SR4120 (D3CG), Booklet Finisher SR4130 (D3CH)

	300K	500K	1000K	3000K	Exp.	Note
Drive Rollers		C				Damp cloth, dry cloth
Idle Rollers		C				Damp cloth, dry cloth
Anti-Static Brush		C				Dry cloth

	300K	500K	1000 K	3000 K	Exp.	Note
Roller Shafts		C				Lubricate bushings with silicone oil, other bushings with Launa oil.
Sensors		C				Blower brush
Corner Stapler				R	3000K	Print an SMC report with SP5990. Replace the unit if the staple count is 500K.
Booklet Stapler			R		1000K	Print an SMC report with SP5990. Replace the unit if the staple count is 200K.
Positioning Roller				R	3000K	This is a sponge roller.

Punch Unit Type PU3060 (D706)

This punch unit is installed in the Finisher SR4120 (D3CG), Booklet Finisher SR4130 (D3CH).

	2400K	3000K	4000K	EM	Note
Punch Waste Hopper	I	I	I	I	Remove and empty
Punch Unit				C	Replace after 1000k punches.

Multi Folding Unit FD4000 (D615)

Part	PM Visit	Notes
Rollers (drive, idle rollers)	I/C	Alcohol, clean cloth
Anti-static brush	I/C	
Shafts	I/C	Lubricate with silicone oil if noisy.
Sensors	I/C	Blower brush
Positioning roller	I/C	Inspect for scratches or nicks

Part	PM Visit	Notes
Fold rollers (1st, 2nd, 3rd)	I/C	Alcohol, clean cloth
Crease rollers (drive, idle roller)	I/C	

Related SP Codes

This is a list of the PM related SP codes.


3

SP7803	PM Counter Display	Displays the PM count since the last PM.
SP7804	PM Counter Reset	Resets the PM count.

Image Quality Tables


Checking Image Quality

Resolution


Standard	1:1/Enlargement:	4.5 lines/mm or more
	Reduction:	4.5 x M or more mag.
What You Need	S-2-1 Chart	
Method	 <p>d1791421</p> <p>Resolution measured after copying in Text Mode at AE5 notch with Normal Paper</p>	

3

Even Density

Standard	Left, right grayscale within 0.1 at 0.2 to 0.6	
What You Need	S-2-1 Chart	
Method	 <p>d1791422</p> <p>Right, left density measured after copying in Text Mode at AE5 notch with Normal Paper.</p>	


Magnification Errors

Standards	1:1	Main scan: $<\pm 0.5\%$, Sub scan: $<\pm 0.8\%$
	Magnification	Main scan: $<\pm 1.0\%$, Sub scan: $<\pm 1.0\%$
What You Need	150 mm scale	
Method	<div style="text-align: center;">  <p>d1791423</p> </div> <ol style="list-style-type: none"> 1. Set two scales on the exposure glass, and then copy them. 2. Wait at least 10 min. after the paper exits. 3. Measure 100 mm on the copied images with the actual scale. 	

3

Magnification Error Variation

Standard	1:1/Mag.: Sub scan (horizontal, vertical) less than 1.0%
What You Need	150 mm scale

Method

d1791424

1. Place three 150 mm scales on the exposure glass, and then copy them.
2. Wait at least 3 min. after the paper exits.
3. Use a scale to measure 100 mm against each scale image (x1, x2, x3) on the paper.
4. Determine the maximum and minimum deviation (%) from the standard.
5. Calculate the difference between the maximum and minimum deviation.

Notes

- For example, if the three measurements of the scales are 100.4 mm, 99.5 mm, 100.2 mm, then the difference between the maximum and minimum values is 0.9 mm (100.4 – 99.5).
- Set the scales in the main scan direction (horizontal), copy them, and then use the same method to determine the variation
- For best results, using at least three scales is recommended.
- If you have only one scale, then you can make three copies with the scale at different positions.
- Please remember that line speed may vary slightly depending on the number of copies in a job.

Paper Transfer Quality Standards

Registration


Standard: Main Machine

Simplex	Engine	Sub scan 0 ± 0.5 mm
	Copy	Sub scan 0 ± 1.5 mm
Duplex	Engine	Sub scan 0 ± 0.5 mm
	Copy	Sub scan 0 ± 1.5 mm

Standard: Main Machine + ADF

		Copy Paper (40 to 128 g/m ²)	
		Front Side	Reverse Side
Plotter		0 ± 0.5 mm	0 ± 0.5 mm
With ADF			
Front A3 to A5	Main scan 0 ± 1.0 mm	0 ± 2.5 mm	0 ± 2.5 mm
	Sub scan 0 ± 2.0 mm	0 ± 1.5 mm	0 ± 1.5 mm
Reverse A3 to A5	Main scan 0 ± 3.0 mm	0 ± 3.5 mm	0 ± 3.5 mm
	Sub scan 0 ± 1.0 mm	0 ± 1.5 mm	0 ± 1.5 mm

What You Need	S-2-1 Chart, 150 mm scale
----------------------	---------------------------

Method	<div style="text-align: center;">  </div> <ol style="list-style-type: none"> 1. Make a 1:1 copy of the S-2-1 chart with normal paper. 2. Use the scale to measure the registration marks at the leading edge. 3. The range is vertical registration A: 5 mm, and horizontal registration B: 4 mm for the front side.
--------	---

Skew

Standard: Main Machine

	Function	Specification	Feed Length
Simplex	Engine	Less than 0 ± 0.5 mm/200 mm	More than 270 mm
		Less than 0 ± 0.5 mm/100 mm	Up to 279 mm
	Copy	Less than 0 ± 1.0 mm/200 mm	More than 270 mm
		Less than 0 ± 1.0 mm/100 mm	Up to 279 mm
Duplex	Engine	Less than 0 ± 0.5 mm/200 mm	More than 270 mm
		Less than 0 ± 0.5 mm/100 mm	Up to 279 mm
	Copy	Less than 0 ± 1.0 mm/200 mm	More than 270 mm
		Less than 0 ± 1.0 mm/100 mm	Up to 279 mm

Standard: Main Machine + ADF

Plotter Copy Paper (40 to 128 g/m²)


Front Side (mm)		Reverse Side (mm)	
More than 279	Up to 279	More than 279	Up to 279
±0.5 mm/200	±0.5 mm/100	±0.5 mm/200	±0.5 mm/100

3

ADF: Copy Paper (40 to 128 g/m²)

	Front Side (mm)			Reverse Side (mm)	
Front	Main scan: ±1.5 mm/200 mm	±2.0/200	±2.5/200	±2.0/200	±2.5/200
	Sub scan: ±1.0 mm/200 mm	±1.5/200	±2.0/200	±1.5/200	±2.0/200
Reverse	Main scan: ±2.0 mm/200 mm	2.5/200	3.0/200	2.5/200	3.0/200

What You Need	S-2-1 Chart, 150 mm scale
----------------------	---------------------------

Method	 <p>d1791426</p> <ol style="list-style-type: none"> 1. Make a 1:1 copy of the S-2-1 chart with normal paper. 2. Use the scale to measure the left and right registration marks at the leading edge.
--------	---

LCIT

Registration	Leading edge registration	0 ± 2 mm (± 1 mm variation per job)
	Horizontal registration	0 ± 2 mm
Skew	A4 SEF, LT SEF and larger	$0 \pm 1/200$ mm
	B5 SEF and smaller	$0 \pm 1/100$ mm

Cover Interposer Tray

Horizontal registration	0 ± 2 mm	
Skew	A4 LEF, B5 LEF	$0 \pm 0.63/100$ mm
	A3, B4	$0 \pm 0.83/100$ mm

PM Parts Settings

Before Removing Old PM Parts

1. Enter the SP mode.
2. Output the SMC logging data with **SP5990-004**.
3. Press the PM parts counter reset button in the PM Parts display before you turn the power off.
4. Exit the SP mode.

Important

- After the PM count for the fusing cleaning web and the drum lubricant bar expire, the machine stops automatically.
- After replacing developer, the count is cleared by executing SP3024-001 (Developer Filling), so there is no need to perform a counter clear.

After Installing New PM Parts

1. Turn on the main power switch. The machine will reset the PM counts automatically and initialize default SP code settings.
2. Check the "Initial Adjustment SP Lists". Refer to this list if any SP must be set manually after a part replacement.
3. Output the SMC logging data with **SP5990-004** and check the counter values.
4. Make sure that the PM counters for the replaced parts are "0" in the PM parts display. If the PM counter for a unit has not been reset to zero, reset that counter again.

4. Replacement and Adjustment

Power Switch

Push Switch

The power button of this machine has been changed to a push-button switch from the conventional rocker switch. The push switch has characteristics and specifications different from the rocker switch. Care must be taken when replacing and adjusting parts.

Characteristics of the Push Switch (DC Switch)

1. **Power is supplied to the machine even when the main power switch is turned OFF.**

The push switch in this machine uses DC (direct current). Therefore, if the AC power cord is connected to an electrical outlet, power is supplied to the controller board, the operation unit and other modules even when the main power is turned OFF. When replacing the controller board and the operation unit in this state, not only these boards, it will damage other electrical components.

In 100V models, only one of the AC lines for the fusing unit is shut off when you turn off the main power; the other line carries current even when you turn off the main power switch.

So, when performing maintenance work such as replacing parts, in addition to turning off the main power with the push switch, always unplug the AC power cord.

2. **When you disconnect the power cord from the AC wall outlet, inside the machine there is still residual charge.**

When you disconnect the power cord from the AC wall outlet, inside the machine for a while there is still residual charge. Therefore, if you remove boards in this state, it can cause a blown fuse or memory failure.

In order to discharge this residual charge inside the machine after you unplug the power cord from the AC wall outlet, press the main power switch. The residual charge in the machine is discharged, so it is safe to remove the boards.

3. **When you reconnect the AC power cord into an AC wall outlet, the machine will start automatically.**

In order to remove the residual charge, push the main power switch while you disconnect the AC power cord. At that time, the power ON flag inside the machine is set. Therefore, after you finish work on the machine and reconnect the power cord to the AC, even if you do not press the main power switch, the machine will start automatically and the moving parts will begin to move.

CAUTION

- When working on moving parts, be careful that fingers or clothes do not get caught.

Note

- Automatic restart deals with cases when you accidentally unplugged the AC power cord or unexpected power outages. By keeping the power flag ON, after the resumption of power, the machine will start up automatically.

In rare cases, when you reconnect the AC power cord to a power outlet, the machine does not start automatically. In this case, the machine has not failed. The cause is due to the timing of releasing the residual charge. If you press the main power switch while the residual charge was already released, the power ON flag will not be set. At this time, start the machine manually by pressing the main power switch.

4

Shutdown Method

1. Press the main power switch [A] on the front of the machine.



d223c1096

2. Take out the power cord
3. Wait 3 minutes (this is the time required if you will remove the rear cover and access the interior of the machine, to take out the controller board for example).
4. After you remove the rear covers, if you see any PCB LEDs flashing, this means there is residual current on the boards, wait until the LEDs go off.

When the shutdown is complete:

Main power LED: Off

Operation panel LED: Off

Important

- **How to start from shutdown**

- To start the machine, press the main power switch. However, if you press the main power switch between the beginning and the end of a shutdown, the machine will not start.

Forced Shutdown

In case normal shutdown does not complete for some reason, the machine has a forced shutdown function.

To execute a forced shutdown, press and hold the main power switch for 6 seconds.

Important

- Forced shutdown may damage the hard disk and memory, and can cause damage to the machine.
- Do forced shutdown only if it is unavoidable.

Before You Begin

WARNING

- Before servicing the machine, always turn the machine off and disconnect the power cord.
- After replacing parts, make sure that all removed harnesses are connected again and secured in their clamps.

CAUTION

- Never turn off the machine while the machine is operating.
- If the machine is switched off during operation, the transfer belt, drum, or development unit could be damaged when it is removed or reinstalled.

4

General Precautions

Drum

An organic photoconductor (OPC) drum is more sensitive to light and ammonia gas than a selenium drum. Follow the cautions below when handling an OPC drum.

1. Never expose the drum to direct sunlight.
2. Never expose the drum to direct light of more than 1,000 Lux for more than a minute.
3. Never touch the drum surface with bare hands. When the drum surface is touched with a finger or becomes dirty, wipe it with a dry cloth or clean it with wet cotton. Wipe with a dry cloth after cleaning with wet cotton.
4. Never use alcohol to clean the drum; alcohol dissolves the drum surface.
5. Store the drum in a cool, dry place away from heat.
6. Take care not to scratch the drum as the drum layer is thin and is easily damaged.
7. Never expose the drum to corrosive gases such as ammonia gas.
8. Always keep the drum in the protective sheet when keeping the drum unit, or the drum itself, out of the machine. Doing so avoids exposing it to bright light or direct sunlight, and will protect it from light fatigue.
9. Dispose of used drums in accordance with local regulations.
10. When installing a new drum, execute SP2962 (Adjustment of Drum Conditions).

Drum Unit

1. Before pulling out the drum unit, place a sheet of paper under the drum unit to catch any spilt toner.

2. Make sure that the drum unit is set in position and the drum stay is secured with the screw before the main switch is turned on.
3. If the drum unit is loose, poor contact of the drum connectors may cause electrical noise, resulting in unexpected malfunctions (RAM data change is the worst case).
4. To avoid scratching the drum, always remove the development unit before removing the drum unit.

Transfer Belt Unit

1. Never touch the transfer belt surface with bare hands.
2. Take care not to scratch the transfer belt, as the surface is easily damaged.
3. Before installing the new transfer belt, clean all the rollers and the inner part of the transfer belt with a dry cloth to prevent the belt from slipping.

4

Scanner Unit

1. When installing the exposure glass, make sure that the white dot is at the rear upper left corner.
2. Clean the exposure glass with alcohol or glass cleaner to reduce the amount of static electricity on the glass surface.
3. Use a cotton pad with water or a blower brush to clean the mirrors and lens.
4. Never bend or crease an exposure lamp cable.
5. Never disassemble the lens unit. Doing so will throw the lens and the copy image out of focus.
6. Never adjust any of the CCD positioning screws. These screws are paint-locked and should never be removed.

Laser Unit

1. Never loosen the screws that secure the LD drive board to the laser diode casing. Doing so would throw the LD unit out of adjustment.
2. Never adjust the variable resistors on the LD unit, as they are adjusted in the factory.
3. Never open the optical housing unit. The polygon mirror and F-theta lenses are very sensitive to dust.
4. Never touch the glass surface of the polygon mirror motor unit with bare hands.
5. After replacing the LD unit, do the laser beam pitch adjustment. Otherwise, an SC condition will be generated.

Charge Corona

1. Clean the corona wires with a dry cloth. Never use sandpaper or an organic solvent.

2. Clean the charge corona casing with water first to remove NOx based compounds. Then clean it with alcohol if any toner still remains on the casing.
3. Clean the end block with a blower brush first to remove toner and paper dust. Then clean with alcohol if any toner still remains.
4. Never touch the corona wires with bare hands. Oil stains from fingers can cause uneven image density on copies.
5. Confirm that the wires are correctly installed between the cleaner pads and that there is no foreign material (iron filings, etc.) on the casing.
6. When installing new corona wires, never bend or scratch the wire surface. Doing so may cause uneven charge. Also be sure that the corona wires are correctly positioned in the end blocks.
7. Clean the grid plate with a blower brush (not with a dry cloth).
8. Never touch the charge grid plate with bare hands. Also, do not bend the charge grid plate or make any dent in it. Doing so may cause uneven charge.

Development

1. Work carefully to avoid nicking or scratching the development roller.
2. Place the development unit on a sheet of paper after removing it from the machine.
3. Never disassemble the development roller assembly. The position of the doctor plate is set with special tools and instruments at the factory to ensure the proper gap between the doctor blade and the development roller.
4. Clean the drive gears after removing used developer.
5. Dispose of used developer in accordance with local environmental laws and regulations.
6. Never load types of developer and toner into the development unit other than specified for this model. Doing so will cause poor copy quality and toner scatter.
7. Immediately after **installing new developer**, the TD sensor initial setting procedure should be done with **SP2801** (TD Sensor Initialization) to avoid damage to the machine.
8. Never do the TD sensor initial setting with used developer. Do not make any copies before doing the TD sensor initial setting.
9. When using a vacuum cleaner to clean the development unit casing, always ground the casing with your fingers to avoid damaging the toner density sensor with static electricity.
10. When replacing the TD sensor, replace the developer, then execute **SP2801** (TD Sensor Initialization) and **SP2962** (Adjustment of Drum Conditions).

Cleaning

1. When servicing the cleaning section, be careful not to damage the edge of the cleaning blade.
2. Do not touch the cleaning blade with bare hands.

3. Before disassembling the cleaning section, place a sheet of paper under it to catch any toner falling from it.

Fusing Unit

1. After installing the end thermistor, make sure that it is in contact with the hot roller.
2. Be careful not to damage the edges of the hot roller strippers or their tension springs.
3. Never touch a fusing lamp or fusing roller with bare hands.
4. Make sure that the fusing lamp is positioned correctly and that it does not touch the inner surface of the hot roller.

Paper Feed

1. Avoid touching the surfaces of the pick-up, feed, and separation rollers when replacing them.
2. To avoid paper misfeeds, the side fences and end fence of the paper tray must be positioned correctly to align with the actual paper size.


Used Toner

1. We recommend checking the amount of used toner at every EM.
2. Always dispose of used toner in accordance with local environmental laws and regulations.
3. Used toner is flammable. Never incinerate used toner.

Precautions for This Machine


Inner Covers

1. Each inner cover has one or more LEDs at critical locations in the paper path. An LED lights when a paper jam occurs at that location.



d223c1112

2. To avoid breaking LED connectors or harnesses, be careful about inner cover removal.
3. After the screws are removed, the cover should be pulled away partially so the LED can be disconnected before the cover is pulled away completely.



d223c3752

Proximity Sensor

1. As soon as the new proximity sensor detects the presence of the operator in front of the machine, it will prepare the machine to accelerate the recovery from low power mode..




d223c0072

2. This sensor works on the principle of detection of body heat. The sensitivity of the detection device is affected by both ambient temperature and the amount and type of clothing worn by the operator.

4

PSU Precautions

1. The heat sinks and condensers on the PSU are live and labeled with warnings on the PCB not to touch them.
2. A heat sink can retain a considerable electrical charge for hours, even after the machine has been turned off.



d223c3753


⚠ DANGER

- To avoid electrical shocks, never touch **any** component on the PSU with your bare hand or a tool, especially one of the heat sinks or capacitors.
- Always keep the rear covers on the machine.

- Never leave the covers off during machine testing, or while the machine is idle during servicing.

⚠ CAUTION

- To avoid personal injury, always handle the PSU by its edges.
- Never touch the back of the board.
- Some of the soldered contacts are extremely sharp and can cut or puncture your fingers if you grip the back of the board.



d223c3480

Here is a summary of the amount of residual voltage on the PSU condensers after the machine is switched off and unplugged from the power source. The residual charge is designed to make the machine recover faster from the Energy Save Mode.

100V PSU

Address	Power Off	5 min.	10 min.	1 hr.
C9	308V	307V	307V	304V
C75	146V	146V	145V	144V


200V PSU

Address	Power Off	5 min.	10 min.	1 hr.
C9	287V	285V	284V	280V
C27	287V	285V	284V	280V

The photo below shows the danger zone, and the location and address of each condenser where residual charge remains.

100V PSU

200V PSU



d223c3754

4

Important SP Codes: Machine Information, Servicing

Here are quick summaries of SP codes that give you useful information about the machine, and some common SP codes you will need during maintenance.

Machine Information

Item	SP No.	Function
Auto process control	3901	Displays whether auto process control is switched on or off (Default: On)
CIS ID	4700	Reads and displays the ID of the CIS board at power on.
Drum potential after quenching (Vq)	3902-7	Displays the drum potential after quenching.
Firmware version	7801	Displays ROM number and firmware information for main machine and all other connected devices.
Fusing temperature display	1106	Displays the fusing temperature at the center and end of the hot roller, and temperature of the pressure roller.
ID sensor pattern potential	3902-6	Displays Vid, the latest drum surface voltage measured on the ID sensor pattern.
LD level	3902-5	Displays the LD power correction value as a result of the latest Vh adjustment.

Item	SP No.	Function
Machine serial number	5811	Use this SP to display the serial number for the machine and BICU.
ROM number	7801	Displays ROM number and firmware information for main machine and all other connected devices.
SC history	7403	Displays the following information about the most recently issued SC code: Source file name, SC number, Result
SMC report, print	5990	The SMC report can display all the current settings in the machine, as well as logged SC codes that do not show on the operation panel.
SMC report, text file	5992	Writes the SMC report to an SD card inserted into the SD card slot on the side of the operation panel.
Self-diagnostic	7832	Displays a list of error codes, if errors have occurred. Otherwise, nothing is displayed.
Temperature, fusing	1106	Displays the hot roller temperature at center and ends, and pressure roller temperature.
Temperature, machine	2913	Displays the internal temperature of the machine.
Vd	3902-2	Displays drum dark potential, the standard potential, electrical potential of the black areas after exposure.
Vg	3902-4	Displays the charge grid voltage resulting from the latest Vd adjustment.
Vh	3902-3	Displays standard halftone drum potential, used for laser power adjustment. Creation of the Vh pattern is turned on/off with SP2950.
VI	3902-7	Shows the standard electrical potential of white areas on the drum after exposure.

Commonly Used During Servicing

Item	SP No.	Function
Forced toner supply	2207	Rotates the toner bottle to supply toner to the toner supply unit. Use to determine if toner supply is operating correctly. If forcing toner supply with this SP does not darken the image, then toner supply is not operating correctly.
Free run	5802	Forces the base engine to run in free run mode for testing.
Fusing SC clear	5810	Fusing unit SC errors disable the machine until the problem is corrected. Do this SP to release the machine interface for servicing.
Input check	5803	Displays the signals received from sensors and switches.
Output check	5804	Switches electrical components on/off one by one for testing.
Scanner free run	4802	Executes a scanner free run with and without the LEDs on
Test pattern printing	2902	Produces the printer test patterns.

Special Tools and Lubricants

Special Tools

Part No.	Description
A0069104	Scanner Positioning Pin (4 pcs./set)
A2929500	Test Chart – S5S (10 pcs./set)
A0299387	Digital Multi-meter – FLUKE 87
VSST9500	Test Chart – S5S – DF (10 Sheets/Set)
G0219350	Loop Back Connector
B6455010	SD (Secure Digital) Card – 64 MB


Lubricants

Part No.	Description
A2579300	Grease Barrierta – JFE 5 5/2
52039502	Silicon Grease G-501
54429101	Setting Powder

Covers


Front Door

1. Open the front door.
2. At [A] locate the hinge bracket plunger [B].



d223c3016

3. While supporting the door with one hand, press the hinge plunger [A] down to release the door, and then pull the door [B] slightly away from the corner of the machine.



4. Disconnect the brackets at the bottom of the door and pull it away from the machine.




Right Covers

Right Upper Cover

1. Remove the LCIT entrance guide cover [A].

2. Disconnect the right upper cover [B].



3. Open bypass tray [A].
4. Pull the right upper cover [B] down and away from the machine.



5. Close the bypass tray.





d223c3021

4


To re-attach right upper cover

1. First, insert the tabs at the front edge [A] and rear edge [B] of the tray into the slots of the frame.



d223c3022


2. Open the bypass tray [A].
3. Position the cover over the bypass tray.
4. Slide the top edge of the cover [B] under the edges of the covers [C] above.



d223c3023

Right Lower Cover


1. Disconnect the cover.



 x4

d223c3024


2. Lift the cover slightly and pull it away.



d223c3025

To re-attach the right lower cover

1. Insert the front tab [1] and rear tab [2] into the holes of the cross-stay, and then set the cover.



d223c3026

4

Rear Covers

Rear Upper Cover


1. Locate the three shoulder screws at the bottom edge of the cover.
2. Loosen these screws slightly. Do not remove them.




 x3

d223c3027

1. Disconnect the cover at the right upper corner [A] and left upper corner [B]. Remove these screws.




x2



d223c3028

2. Pull the cover up slightly and pull it away.




d223c3029

Rear Lower Cover

1. Locate the two shoulder screws at the bottom edge of the cover.
2. Loosen these screws slightly. Do not remove them.


4



3. Remove the screws at each upper corner of the cover.



4. Remove the cover.



Left Covers

Left Upper Cover


1. Remove the cover.



 x2


d223c3033

2. On the rear edge of the cover [A] disconnect the tab from its post.



d223c3035

3. Disconnect the tabs on the side.



d223c3034

4


4. Remove the cover.



d223c3036


To re-attach the left upper cover:

1. First, engage the tab and post [A] at the rear edge of the cover.




d223c3037

- At the front, set the cover so it will slide up under the edge [A] of the covers above.



d223c3038

- Set the tabs into knockouts on the cross-stay [A].




d223c3039

- Re-attach the screws.

Left Lower Cover

- Disconnect the cover.
- Lift the bottom edge slightly.


 x4

d223c3040

- Pull the cover away.




d223c3041

Controller Box Cover Plate

Many procedures require that you open the controller box plate so you can access the BICU, controller board, and HDD.

1. Remove the rear upper cover. page 482
2. Disconnect the controller box plate.




 x2

 x2


d223c3139

3. Slide the cover to the right to remove it.



d223c3140


4. With the plate removed, you can see [1] BICU, [2] controller board, and [3] HDD.



d223c3141


Re-assembly

1. Set the bottom edge of the cover plate on the front bottom edge of the controller box.
2. Make sure that all the metal tabs line up with their holes on the frame.



d223c3142

3. Press the plate against the box, and then slide it to the left.




d224c3142

4. Check the tabs and make sure that they are inserted in their holes.

Controller Box

Many procedures require that you open the controller box so you can access the back of the machine.

1. Remove the rear upper covers. page 482
2. Disconnect left bracket [A], and then remove bracket with I/F cable attached.
3. Disconnect harness [B] connector and clamp.
4. Free harness [C] from its clamps.



d223c3125


5. Disconnect the edge of the controller box.



 x3

d223c3129

6. Lift the handle [A] off of its hook on top of the box, and then pull it toward you.



d223c3130

7. Swing the controller box open.




d223c3131

IOB Bracket

Some procedures require that you access the components behind the IOB. You do not have to remove the IOB. The IOB support bracket is set on hinges so it can swing open to the left.

1. Remove the rear upper covers. page 482
2. Disconnect the IOB bracket.



 x4


d223c3132

3. Swing the bracket open.




d223c3133

4. If you need more space to work, disconnect the left upper corner of the IOB.



d223c3134

5. The bracket can swing open farther.



d223c3135

6. If you need still more space to work, lift the IOB bracket off its hinges at the top [1] and bottom [2].
7. Check the bottom corner and confirm that the bottom hinge [2] is out of the hole.

★ Important

- The metal of the IOB bracket is soft. If the bracket is lowered with the bottom peg still in its hole, the metal will bend.




d223c3136

8. Slowly, lower the IOB bracket and allow it to hang free.



d223c3137

9. With the controller box open and the IOB bracket lowered, you now have full access to all the components on the back of the machine.



d223c3138

Operation Panel

Operation Panel Removal

Follow this procedure to replace the operation panel unit.

1. Turn off the machine and disconnect the power cord.
2. Disconnect the front edge cover.



 x2


d223c3001

3. Bend the ends of the cover toward you slightly to disengage the tabs on the ends, and then remove the cover.



d223c3002


4. Disconnect the operation panel.



 x2

d223c3003

5. Cover the exposure glass [A] to protect it.



d223c3004

6. Lift the disconnected operation panel.




d223c3005

7. Lay the operation panel on the machine upside down.



d223c3006

8. Disconnect the cable and ground wire.



9. Disconnect operation panel cover.



10. Lift the operation panel cover up and remove it.



11. Before you replace the operation panel unit, first look in the window of the old unit and check the DIP SW settings.




d223c3015

12. Turn the unit so you can read the numbers of the DIP SW.

★ Important

- The DIP SW settings are different, depending on the machine.
- The DIP SW settings of the new unit must match the settings of the old unit.
- If the settings do not match, the machine will issue SC672.

For example, the photo below shows DIP SW 3 and 7 set to ON. This is the default setting.



d223c3014

13. If the settings the unit you are replacing are different, use a sharp instrument to set the DIP SW on the new unit so the.

★ Important

- The DIP SW settings must be identical before the new unit is installed. If the DIP SW settings of the new unit are not the same as the old unit, the machine will issue SC672.

14. Before handling the new operation panel, touch a metal surface with your bare hands and your screwdriver to discharge any static electrical charge.

★ Important

- Keep the screwdriver and any other metal tools away from the boards of the new operation panel unit.
15. After replacing the operation panel, make sure that the latest version of the Smart Operation Panel firmware has been installed. For details, refer to "Updating the Smart Operation Panel" in the Smart Operation Panel manual.

LCD, Touch Panel Replacement

4

Follow this procedure to replace the touch panel, LCD, or both. In order to replace the LCD, you must first remove the operation panel (described in the previous section), and then you must:

- Remove CPU Board
- Remove Microcomputer Board
- Disconnect LCD
- Separate LCD and Touch Panel

CPU Board

1. Remove the operation panel unit. page 496

⚠ CAUTION


- The machine must be turned off and the power cord disconnected from the power source before doing this procedure.
2. Disconnect bottom cover.



 x4


d223c3011

3. There are small tabs on the cover at [1] and [2]. Separate the cover and remove it,




d223c3012

4. Rotate the operation panel [A] as shown. This orients the unit for the remainder of the procedure.



d223c3013


5. Remove base bracket [A].



 x9

d196z0103

6. Disconnect the CPU.



 x4



d196z0105


4

7. Remove CPU board from microcomputer board.




d196z0105a

8. Raise the fastener on the connector at the CPU.



d196z0115

9. Disconnect CPU board [A].




d196z0139

Microcomputer Board


4

1. Slide out the black collar to unlock the flat connector, and then disconnect the FFC.




d196z0108

2. Remove microcomputer board [A].



 x1  x2




d196c0140

4

LCD and Touch Panel


1. Remove speaker [A] (x2).



 x2


d196z0109

2. Raise the fastener of the LCD I/F cable




4

3. Disconnect the LCD I/F cable.



 x1

4. Undo the tapes holding the microphone harness.




d196z0142

4

- 5. Disconnect the LCD.
- 6. Separate the touch panel [A] and LCD [B].



 x4




d196c0117

- 7. After reassembly, do the LCD panel check and calibration procedures. LCD, Touch Screen Check and Calibration

Scanner Unit

Before You Begin

There is no SIOB (Scanner Interface Board) in this machine. The functions of the SIOB of the previous machine are controlled by the BICU. Both harnesses of the scanner unit connect directly to the BICU in the controller box on the back of the machine.




d223c3103

4


Scanner Unit Removal

1. Prepare a clean, flat location to lay the scanner unit.
2. Raise the ADF.



d223c0003

3. At the right side [A] remove the right edge plate.




4

4. At the left side [A] remove the left edge plate.




5. At the back of the scanner unit, remove the rear edge plate (no screws).




6. At the front, remove the front edge plate.




7. Disconnect the operation panel cover but do not remove it.




8. Slide the panel forward slightly and then stop.




9. Loosen (do not remove!) the bottom screws of the rear upper cover [A].



10. Disconnect the rear upper cover at the right rear corner [A] and left rear corner [B].



11. Remove rear upper cover



d223c0020

12. Disconnect the rear cover plate.


4


 x2

 x2



d223c3139

13. Slide the cover off in the direction of the arrow.




d223c3140

14. Disconnect the base of the scanner unit at each corner.




4

15. At the back of the machine, you must disconnect the triple-harness cable [1] and the I/F cable [2].



d223c0024

16. Disconnect the I/F cable [B] from the rear panel.



 x2  x1

d223c0025

17. Disconnect the I/F cable.




 x1

d223c0026

18. Disconnect the triple harness [A] from the frame.

19. Disconnect the three harnesses [B].




 x3

 x3

d223c0027


20. At the right rear upper corner, free the triple-harness [A] and I/F cable [B].




 x1

d223c0028

21. Below rear right corner [A], open the clamp, and then pull out the I/F cable.




 x1



d223c0029


22. Next, free the I/F cable above rear right corner [A].



 x1

d223c0030


23. Pull the triple harness out through the corner [A].



d223c0032

24. Lay the triple harness and I/F cable across the exposure glass [A].

25. On the left edge of the scanner unit [B], raise the elastic handle.



d223c0033

26. Grip the scanner unit by the handle on each side, and then lift it out and remove it.

27. Lay the scanner unit on a flat, clean surface.




d223c0034

4

Reassembly


1. When you re-attach the PCB cover plate [A], first set the tabs on the rail below. Make sure each tab is engaged with the rail.
2. When you re-attach the rear, upper cover [B], make sure the I/F cables are in the knockouts [1] and that the top edge of the cover is **under** the rear edge [2].



d223c0052


Exposure Glass

1. Prepare a clean, flat location to lay the exposure glass.
2. Raise the ADF.



d223c0003

3. On the right [A], remove the right edge plate.


 x1


d223c0004

4. At [A] near the rear edge of the exposure glass, remove rear scale.



 x3

d223c0005

5. At the top left side of the machine [A] remove the u-bracket.




 x2



d223c0006

4


6. Remove the exposure glass, and then lay it on a flat, clean surface.
7. Lift out the exposure glass and left scale together.



d223c0007


 **Note**

- The left scale is attached to the exposure glass with double-sided tape. Do not separate the left scale and the exposure glass unless you are going to replace a broken glass.
8. The >PS< notation and arrow [A] of the left scale mark the upper left corner of the exposure glass.
 9. If you are replacing the exposure glass, the left scale [A] must be attached to the corner of the new glass so that the corner marked with two dots [B] is under the >PS< notation and the down arrow.



d223c0008

10. Hold the exposure glass so the >PS< notation is at the upper left corner, and then set the glass in the machine.
11. Make sure the >PS< notation [A] is at the upper left corner, and that the hole on the end is snug over the boss.
12. At the lower left corner of the glass [B], make sure that the hole is snug over the boss.




d223c0009

Contact Glass

Contact Glass Removal and Reinstallation


1. Remove the exposure glass. page 516



d223c3778


2. Remove the contact glass.

- Step strip [A] is attached to the top of the contact glass.
- The right side of the contact glass [B] is fastened by double-sided tape below its right edge.




d223d4125

3. Use a clean cloth dampened with alcohol to clean the area where the double-sided tape will be attached.




d223c3779

4. Peel the back from the double-sided tape strip.
5. Set the one end of the tape at the rear [A] aligned with the line marker, and then set the other end of the tape at the front [B] at its line marker.




d223c3780

6. Press the tape down so it is perfectly smooth along its length, and then peel off the remaining strip from the tape.
7. Identify the corner of the contact glass with the orange dot.
8. With the dotted corner pointing to the left, set this end of the contact glass at the rear [A] against the rear and right stud.
9. Set the other end of the glass at the front [B] against the left stud.



4

10. Press down gently on the right edge of the glass onto the tape below it.
11. Re-install the exposure glass, rear scale, and left edge cover.
12. Locate the notch [A] on the rear end of the right edge cover.
13. Peel the tape from the back of the step strip.
14. Align the rear corner of the strip [B] with notch [A], and then align the left edge of the step strip against the right edge of the cover.




15. Press down on the step strip so it is perfectly flat and parallel with the right edge of the edge cover.



Convert from Non-Contact to Contact Scanning Configuration

The step strip mounted to the left of the contact glass keeps the surface of the original out of contact from the glass. This is the standard configuration. However, with the replacement of two parts this configuration can be modified to revert to the old method with the surface of the original in contact with the glass as it passes.

1. Raise the ADF.
2. Remove entrance guide unit [A].



1. Note that the lower part of the non-contact guide unit [A] (just removed) is black, and the same part of the contact-type [B] (replacement) is colorless, and transparent.



d1352723

2. Remove scanning guide [A]



▼ x1


d1352718

3. Note that the tabs [A] on the ends of the non-contact scanning guide plate (just removed) are black, and the tabs [B] (replacement) of the contact-type are white.



d1352721

4. Attach the contact-type scanning guide plate [A] (white tabs).
5. Attach contact-type guide unit [B] (colorless, transparent strip).



▼ x1


⚙ x2

d1352722

6. Enter the SP mode, open SP4688-002 (Scan Image Density Adjustment – 1-Pass DF), and then enter "96" as the setting.

Contact Glass Cleaning

1. Carefully, peel the black step strip [A] away from the contact glass.



d223d4131

2. Dampen a clean cloth with alcohol and clean the contact glass.


Lens Block Cover

1. Remove exposure glass. page 516
2. The lens block cover is on the right side of the scanner unit.




d223c3042

3. Disconnect the lens block cover.



4. Raise the lens block cover and remove it.




d223c3044

Under the lens block cover:

[A]	Original Width Sensors
[B]	Lens
[C]	SBU

★ Important

- Never remove a paint-locked screw [1] on the lens block.




d223c3045

4


Original Width Sensors

1. Remove the exposure glass. page 516
2. Remove the lens block cover. page 525
3. Free the harness of the left sensor.




d223c3046

4. Press the back of left sensor [A] to release it, and then disconnect it.



▶ x1



▶ x1

d223c3047


4

5. Lay the sensor on a flat, clean surface.



d223c3048

6. Press the back right sensor [A] to release it, and then disconnect it.



 x1

d223c3049


7. The original width sensors are identical and interchangeable.



d223c3050

Lens Block


1. Remove the exposure glass. page 516
2. Remove the lens block cover. page 525
3. Disconnect original sensors [A].
4. Disconnect SBU [B].



 x4


d223c3051

5. The FFC at the front edge of the SBU is locked in place by a sliding collar [A].
6. Slide the collar [B] out to release the FFC.



d223c3052

7. Disconnect the FFC.



d223c3053

8. Disconnect the lens block.



d223c3054

★ Important

- Never loosen or attempt to remove a paint-locked screw on the lens block.



d223c3056

9. Remove the lens block, and then lay it on a flat, clean surface.



d223c3057


★ Important

- The lens block is replaced as a set. Do not remove the SBU.

Re-installation

↓ Note

- Reattach the FFC to the SBU before you re-install the lens block.
1. First, slide the collar lock [1] away from the SBU.
 2. Insert the edge of the FFC [2].
 3. Push the collar in [3] to lock the FFC in place.



d223c3081

4. Confirm that the FFC is locked and straight.
5. After reassembly, do the scanner and printer adjustments. page 985


4

Exposure LEDs (Exposure Lamp)

Note

- The Exposure LEDs (exposure lamps) are comprised of a pair of LED arrays mounted on separate brackets. Either bracket can be removed separately.

1. Remove the exposure glass. page 516
2. Remove the front edge plate.




3. Slowly, pull the Exposure LED pair toward the center of the scanner unit until both ends are even with the cutouts in the frame at the front and back.



d223c3061

Left Exposure LED

1. You may need to move the Exposure LED bracket slightly so you can see the FFC of the left bracket at the rear.
2. Disconnect FFC at the rear end of the left Exposure LED.



 x1

d223c3062


3. Disconnect the rear end of the left FFC bracket.



 x1

d223c3063

4. At the front, push the mylar [A] aside so you can see the front end of the left FFC bracket.
5. Detach mylar sheet [A], and then disconnect the front end of the left Exposure LED bracket [B].



 x1

d223c3064

4

Note

- Never touch the window surface of the Exposure LED with bare fingers.

6. Remove the left Exposure LED bracket with LED attached.



d223c3065

7. Lay the left Exposure LED bracket on a flat, clean surface.




d223c3066


8. Turn the bracket over, and disconnect the LED PCB.



9. Separate the LED PCB and bracket.



10. Lay the LED PCB flat with the LEDs facing up.




Right Exposure LED

1. You may need to move the Exposure LED bracket [A] slightly so you can see the FFC of the right bracket at the front [B].



2. Disconnect the rear end [A] of the right Exposure LED bracket.


3. Disconnect the front end [B] of the right Exposure LED bracket.



Note

- Never touch the window surface of the Exposure LED with bare fingers.

4. Remove the right Exposure LED bracket with LED attached.



d223c3072

5. Lay the right Exposure LED on a flat, clean surface.



d223c3073


6. Turn the bracket over, and disconnect the LED PCB.



 x3

d223c3074

7. Separate the bracket and LED PCB.



d223c3075

8. Lay the LED PCB flat with the LEDs facing up.




d223c3076

Reassembly

1. Inspect replacement Exposure LEDs for dust or other particles and clean with a blower brush before installation.


★ Important

- Handle Exposure LEDs with care. Never touch the LED window [A] or LEDs [B] with bare hands.




d223c3077

2. Before installation, make sure the LED PCB is perfectly flat against the bracket.



d223c3078

3. To install the bracket, hold the bracket up at a slight angle [A] and then lower it [B] so it locks against the frame..



d223c3079

4. Be sure to re-attach the mylar completely over the cutout if you detached it.



d223c3080

4

Scanner Motor

1. Remove the exposure glass. page 516
2. The scanner motor is at the right front corner of the scanner unit.



d223c3082


3. Remove the front edge plate.



 x2

d223c3083


4. Remove the lens block cover [A] so you can reach the timing belt and scanner drive gear [B]




5. Remove the right upper cover.



6. On the right side of the machine, disconnect the development unit fans.




7. Disconnect the development unit fan bracket [A].




8. Remove the development unit fan bracket with fans attached.




9. Disconnect the cross-stay.



10. Lower the cross-stay and let it hang. It is not necessary to remove it.




11. Disconnect the scanner motor bracket.



 x3 d223c3091


12. Inside the scanner unit, disconnect the left end [A] of the drive belt.

13. Disconnect the right end [B] of the drive belt from the motor.



 x1 d223c3092

14. Disconnect motor [A] and then remove the bracket with motor attached.



 x1  x1 d223c3093


15. Disconnect motor bracket.



 x2

d223c3094


16. Separate motor and bracket.



d223c3095

To re-attach the cross-stay

1. Set the front hook [A] and rear hook [B] into the holes provided so the stay is perfectly straight.



d223c3096

Scanner HP Sensor

4

1. Remove the scanner unit and set it on the frame of the machine. page 507



d223d4121

★ Important


- It is not necessary to disconnect the ADF I/F cables at the back of the machine.
- Just remove the exposure glass and the four base screws that secure the scanner unit, raise the scanner out of the well, and then set on the frame of the machine.

2. The scanner HP sensor [A] is at the left rear corner of the scanner unit.




d223d4121a

3. Remove the sensor hook plate stopper [A].



d223d4122


4. Disconnect the sensor [A] from the frame.



▼ x3

d223d4123


5. Lay the sensor on a flat, clean surface.




d223d4124

ADF Open Sensor

1. Remove the ADF. page 895
2. Disconnect rear flat plate.



3. Remove left edge plate [A].



4. Remove right top plate.



 x1

d223c3099


4

5. Remove rear flat plate.



d223c3100


6. Disconnect scanner HP sensor.



 x1  x1  x1

d223c3101

7. Remove the sensor.




d223c3102

Scanner Wire

4

Scanner Wire Removal


1. Remove the scanner unit. page 507
2. Disconnect ground wire [1] (🔩 x1)
3. Disconnect the head of the wire [2] from tension bracket 1.
4. Remove spring [3].
5. Loosen the screw [4] of tension bracket 1.
6. Disconnect the end of the wire at [A].
7. Remove lock bracket [B] of the 1st scanner (🔩 x1).
8. Disconnect the wire from the pulley [C] (🔩 x1).
9. Remove the wire from the scanner.



B132R137.WMF


Scanner Wire Reinstallation and Scanner Position Adjustment

1. Place the beads [A] on the middle of the wire in the openings in the pulley.
2. Wind the ball end of the wire [B] 4 times.
3. Wind the other end of the wire [C] 5 times.
4. Attach tape [D] across the pulley to temporarily hold the wires in place.



B132R136

5. Position the 1st scanner [A] so that the holes are aligned, and insert the positioning pins [B] (x4).
6. Position the 2nd scanner [C] so that its holes are aligned, and insert the positioning pins [D].
7. Attach the lock bracket [E] to fasten the wire to the 1st scanner.



B132R138

8. Tighten the screw of the tension bracket.
9. Attach the pulley and tighten its lock screw.
10. Remove the positioning pins (x4).
11. Remove the tape from the pulley.

12. Slowly push the scanner left and right to confirm that the wires are engaged correctly. The 1st and 2nd scanners should move smoothly.

Important SP Codes: Scanner Unit

Here is a list of SP codes related to testing and servicing the scanner unit.

Item	SP No.	Function
APS size detection	4305	Adjusts APS size detection for SEF/LEF in order to detect 8K/16K paper.
CIS ID	4700	Displays the ID of the CIS board at power on.
Magnification, sub scan	4008	Fine adjusts the magnification in the sub scan direction for scanning by changing the speed of the scanner motor.
Registration, main scan	4011	Adjusts the side-to-side registration for scanning in the main scan direction across the page.
Registration, sub scan	4010	Adjusts the registration of the leading edge for scanning in the sub scan direction.
Scan NVRAM version	1001	This is a Scanner SP Code. Displays the scanner firmware version stored in NVRAM in a 9-digit format: Func. Name_Model Name_History No.
Scanner free run	4013	Executes a free run for testing with the LEDs either on or off.

Laser Unit

⚠️ WARNING

- Turn off the machine and unplug its power cord before performing any procedure in this section. Laser beams can seriously damage the eyes.
- This laser unit uses four laser beams produced by a Class IIIb LDA with a wavelength of 653 to 665 nm and intensity of 15 mW. Direct exposure to the eyes could cause permanent blindness.
- Before performing any replacement or adjustment of the laser unit, push the machine power switch to switch the machine off. Then unplug the machine from the power source.
- Do not touch the machine for 10 minutes. This allows enough time for the fusing unit to cool and for the polygon motor to stop rotating.
- Never power on the machine with any of these components removed: LD unit, polygon motor cover, synchronization detector.
- To avoid serious eye injury, always confirm that the machine has been completely re-assembled before you turn the machine on.

4

Warning Decal Locations

Two caution decals are attached to the top of the laser unit.



d223c0002

Polygon Motor, Polygon Motor Drive Board, LD Unit


Polygon Motor Cover

★ Important


- An accidental static discharge could damage the LDB (Laser Diode Board) in the LD unit.

- Touch a metal surface to discharge any static electricity from your hands.
- The polygon motor rotates at extremely high speed and continues to rotate after switching the machine off.
- To avoid damaging the motor, never remove the polygon motor within three minutes of switching off the machine and disconnecting its power plug.

1. Remove the scanner unit. page 507
2. Remove polygon motor cover [A].



3. There are three components in the well under the cover.



1	Polygon motor
2	Polygon motor drive board
3	Laser diode (LD) unit

⚠ CAUTION

- An accidental static discharge could damage the laser diode board or other boards under the polygon motor cover.
- To prevent damage to a PCB, always touch a metal surface to discharge any static electricity from your hands before you remove a component.

Polygon Motor

1. Remove scanner unit. page 507
2. Remove polygon motor cover. page 553
3. Touch a metal surface to discharge any static charge from your hands.
4. Remove the polygon motor.

4




🔩 x3 📦 x1

d223c0037

★ Important


- Handle the motor carefully.
- Keep tools and your fingers away from the mirror port [A] on the side of the motor.



d223c0038

Polygon Motor Drive Board

1. Remove scanner unit. page 507
2. Remove polygon motor cover. page 553
3. Disconnect the polygon motor drive board.



 x3  x2 d223c0039


4. Touch a metal surface to discharge any static charge from your hands.
5. Remove the drive board.



d223c0040

Laser Diode Unit

1. Remove scanner unit. page 507
2. Remove polygon motor cover. page 553
3. Disconnect the LD unit [A].
4. Touch a metal surface to discharge any static charge from your hands.
5. Pull the unit out partially [B], and then disconnect the harness on the left edge.



d223c0041

6. Remove the LD unit.



d223c0042

After Reassembly

Do this procedure if you replaced the LD unit.

1. Reconnect the machine.
2. Make sure the front door is closed, and then turn the machine on.
3. Go into the SP mode and execute **SP21 10-005**. This automatically downloads the settings to the machine for the new LD unit.
4. If execution of **SP21 10-005** fails on the first attempt, just do it again.
5. Perform the printer adjustments. Copy Image Adjustment: Printer/Scanner

Laser Synchronization Detector

1. If the LCIT is installed, disconnect it and pull it away from the right side of the main machine.
2. Disconnect the right upper cover [A].
3. Remove cover plate [B], and then remove the right upper cover.




 x3

d223c0015

4. The laser synchronization detector [A] is inside the right front corner of the machine.

4




d223c0044

 **Note**


- You do not need to remove the development unit fans next to the laser synchronization detector.

5. Loosen the single screw of the laser synchronization detector [A] (do not remove it!).
6. Pull the detector out partially and disconnect it [B].




7. Remove the detector.

4



Re-installation

1. Connect the harness to the detector.
2. Slide the cutout on the right edge of the detector behind the screw head [1].
3. Set the hole [2] onto the point of the boss on the left, and then tighten the screw.




d223c0047

4. After replacement of the laser synchronization detector, set **SP1002-1** to **-7** (Side-to-Side Registration) to their default settings.

Laser Unit Alignment


This adjustment corrects the parallelogram pattern to the desired rectangular pattern for printing. It does not correct the skew of scanned images.

1. Execute **SP2902-3** (Test Pattern - Printing Test Pattern #18) to print the A4 LEF pattern.
2. Check the printed patterns and estimate the angle of adjustment required.
3. Remove the scanner unit. Scanner Unit Removal
4. Loosen both screws on the right side of the laser unit [A].




d223c0048

5. On the left [A], loosen the adjustment screw.



d223c0049

6. While watching at the scale [1], use a flathead screwdriver at [2] to move the laser exposure unit left or right on the scale until it is centered on the scale.




d223c0050

Note

- The scale is set for increments of 1 mm.

7. Refer to the illustration below:

- If the pattern is skewed at the corner of the leading edge [A], move the unit so it moves the pointer on the scale toward the **rear** of the machine.
- If the pattern is skewed at the trailing edge [B], move the unit so it moves the pointer on the scale toward the **front** of the machine.



- After adjustment, tighten the screws on the laser unit (⚙️ x3).
- Re-assemble the machine.
- Print the pattern again with **SP2902-3** Pattern #18.
- Check the pattern. Repeat the procedure if more adjustment is required.

Toner Shield Glass


The toner shield glass must be inspected and cleaned at regular intervals.

- Prepare a clean, flat location to lay the toner shield glass.
- Open front door [1], and then swing out toner bottle [2].




d223c0053

3. Locate and remove the metal bracket.



d223c0054

4. Slowly, pull the toner shield glass straight out to remove it.



d223c0055

4


5. Lay the glass on a flat, clean surface.



d223c0056


Laser Unit Removal

1. Remove the toner shield glass. page 562
2. Remove the scanner unit. page 507
3. First, you must remove top cover [A],



d223c3760


4. Disconnect the left side [A] of the top cover.



 x2

d223c3761


5. Disconnect the front edge [A] of the top cover.



 x1

d223c3762


6. Disconnect right side [A] of the top cover.



 x1

d223c3763


7. Disconnect right rear corner [A] of top cover.



⚙️ x1 🛠️ x1

d223c3764


8. Release the harnesses attached to the back of the cover [A].



🛠️ x4

d223c3765


9. Remove the top cover.



d223c3766

4


10. At the front, right corner [A] of the laser unit disconnect the laser synchronization unit.



x1

d223c3767


11. Disconnect the left side of the unit at [A] and [B].




x2

d223c3768


12. The shielded cable is fastened to the unit frame with a metal clamp [1].
13. Remove the clamp [2] and free the shielded cable.
14. Disconnect the LD unit [3].




15. Disconnect the left side of the laser unit [A].



16. Disconnect the right side of the laser unit.




17. Remove the laser unit and lay it on a flat, clean surface.




Reinstallation

1. When you install the laser unit in the machine, first set the front right corner under support [A].




d223c3773

2. On the left, before you re-attach the screw at [1], shift the notch on the left side of the unit [2] so it is aligned with the middle line of the scale below.
3. Insert a screwdriver [3] into the plate to hold the unit in place as you re-attach the screws.




d223c3774

4. Set the right front corner of the plate under the support [A] and then lay the plate on top of the laser unit.



d223c3776

5. After you set the top plate on the unit, make sure that the harnesses on the left are not pinched under the plate.




d223c3775

6. Reconnect the machine.
7. Make sure the front door is closed, and then turn the machine on.
8. If you have replaced the laser unit, go into the SP mode and execute **SP2110-005**. This automatically downloads the settings to the machine for the new LD unit.
9. If execution of **SP2110-005** fails on the first attempt, just do it again.
10. Print the alignment pattern with **SP2902-3** Pattern #18 and check the alignment of the pattern.
11. If there is a problem, you will need to realign the laser unit. page 560

LD Safety Switches

In this machine the mechanism that makes the laser unit operational is a 24V1 line interrupted using a 5VS relay and then 24VS is dropped to +5VS1 using a regulator.

To ensure the safety of the machine operators and service technicians, one switch prevents the laser beams from switching on accidentally. When the front door is opened, the +5VS1 line connecting the LD driver on the LD control board is disconnected to disable the laser units.



Important SP Codes: Laser Unit

Here is a list of SP codes related to testing and servicing the laser unit.

Item	SP No.	Function
Download LD settings	2110-5	Automatically downloads the settings to the machine for the new LD unit after replacement. It is no longer necessary to read the settings from a label and enter them manually.
Laser synchronization detector	1002	After replacement of the laser synchronization detector, set 001 to 007 (Side-to-Side Registration) to their default settings.
Test pattern	2902-3	Use this pattern for testing after LD unit replacement.


Drum Unit

Corona Unit

Corona Grid

1. Open the front door.
2. Pull the toner bottle holder out and swing the bottle to the right.
3. Disconnect the charge corona unit.


4



d223c3143

 x1  x1

4. Without touching the wire mesh on top of the unit, pull the charge corona unit out of the machine.




d223c3144

5. Lay the unit on a flat, clean surface.


★ Important

- Always lay the unit down with the wire grid facing up.
- Never lay the unit down with the grid facing down.



d223c3145

6. Remove grid [A].




d224c3146

4

Charge Wire

1. Remove the corona grid. (See procedure above.)
2. Remove terminal plate [A].
3. Rear grid fastening bracket [B].
4. Remove front and back end covers [C].
5. Remove charge wire [D].
6. Remove wire cushions [E].




d223c3147

★ Important

- Never touch the charge corona wire with bare hands. Always protect it from dust, oil, etc.
- Never bend or knot the wire. Charge will not distribute evenly on a bent wire.

Cleaning Pad

1. Remove the charge wire. page 574
2. Remove cleaning pad [A].



d224c3148


Re-assembly

1. At the front and back, make sure that the wire is threaded correctly into the grooves in the end blocks.

2. After replacing the charge corona wire, make sure that the wire cleaner pads are engaged correctly with the wires.


Corona Wire Cleaning Motor

1. Open the front door.
2. Swing the toner bottle holder to the right.
3. Disconnect the charge corona unit.



d223c3673

4. Remove the charge corona unit from the machine.



d223c3674

5. Lay the unit on a flat, clean surface with the grid side facing up.
6. The wire cleaning motor [A] is enclosed in the front end of the unit.




d223c3675

★ Important

- Always lay the unit down with the wire grid facing up.
- Never lay the unit down with the grid facing down.

4


7. Disconnect the front plate [A].
8. Free the snap plate [B].



 x2

d223c3676

9. Remove the motor.
10. If the motor is being replaced, apply a small amount of grease to the worm gear of the motor before you install it.



d223c3677


Corona Power Pack

1. Remove the rear upper and rear lower cover. page 482
2. Open the controller box. page 490
3. The corona power pack is located behind the flywheel.




d223c3678

4. Remove the flywheel and rear center stay.

 x3

d223c3679


5. Clear the ADF cables away from the center stay.



 x1

d223c3680


6. Disconnect the center stay.



 x4

d223c3681

7. Slowly and carefully, lower the center stay [A] away from the corner plate [B] of the IOB bracket below.




d223c3682

4

★ Important

- The bracket on the bottom of the center stay provides the pivot point for the hinge at the upper left corner of the IOB bracket. The arm of the IOB bracket is soft and bends easily.


8. Disconnect the power pack.



d223c3683

 x3

9. Disconnect the power pack bracket, and then remove it with the power pack attached.



 x2

d223c3684

10. Separate the power pack from the bracket.

4



 x3

d223c3685

Drum

Drum Unit Removal

1. Remove the development unit. page 623
2. Remove the corona unit. page 574



 x1  x1

d223c3149

3. Grasp the front of the drum unit by the small handle, and then pull the drum unit out of the machine.



d223c3150

4. Lay the drum unit on a flat, clean surface.



d223c3151

Drum Removal

1. Remove the drum unit. page 623
2. Remove front screw and bracket.



 x1

d223c3152


3. Remove rear screw.



 x1


d223c3153

4. Open the drum unit.



d223c3154

5. Without touching the surface of the drum, grasp the drum by each end and lift it out of the unit.




d223c3155

6. For reassembly, note the shape of the rear end of the drum.



d223c3156

7. Cover the drum with some paper to protect its surface from strong light.



d223c3157


★ Important

- Never touch the surface of the drum.
 - Never attempt to clean the surface of the drum with alcohol or any other type of organic solvent.
 - Never place the drum where it would be exposed to strong light, or sunlight.
8. Before installing a new drum, dust the surface of the OPC drum carefully with setting powder.
 - The surface of a new drum is dry, so you must apply Drum Setting Powder (P/N: 54429101) to the drum surface before installation.
 - Without the drum powder which acts as a lubricant, the drum cleaning blade could scour the drum surface.
 - If setting powder is not available, use some used toner. However, this could cause dirty backgrounds on the first several copies.
 9. Apply the setting powder by tapping the powder bag across the surface of the drum.



d223c3158

10. Cover the entire length of the drum over a 45-90 degree portion [A] (about 1/4 of the total drum surface). Apply enough powder so the area turns white.
11. Install the new drum in the OPC unit so that the forward edge of the powdered surface [B] faces the cleaning blade [C].
12. Manually rotate the drum once clockwise [D] until it stops again at the position where you started.





13. After replacing the drum, do **SP2962** (Adjustment of Drum Conditions).


PTL (Pre-Transfer Lamp)

4

1. Remove the drum unit and drum. page 582
2. The PTL bracket is held in place by two screws [A] and [B]. Screw [B] is a shoulder screw. This screw must be installed at the same position.



3. At the front [A] pass the end of the screwdriver under the shaft arm to remove the screw.
4. Do not place the screwdriver on top of the arm [B] to remove the screw. 
5. At the rear [A] pass the screwdriver under the unit to remove the screw.
6. Do not place the screwdriver on top of the plate [B] to remove the screw.



 x1

d223c3162


4

7. At the center, disconnect the PTL.



d223c3163

8. Roll the PTL bracket out from under the edge of the frame.



d223c3164

9. Separate the PTL from its bracket.



d223c3165

10. Lay the PTL on a flat, clean surface.



Re-assembly

1. Set the PTL in its bracket.
2. Rock the edge of the bracket up under the edge of the frame.




d223c3168

★ Important

- If the edge of the bracket is not under the edge of the frame, the PTL and its bracket will not be perfectly flat against the frame, and you will not be able to re-attach the screws and the connector.

QL (Quenching Lamp)


1. Remove the drum unit and drum. page 582
2. With the drum removed, you can see the green QL [A].



d223c3169


3. At the center, disconnect the QL [A].

4



d223c3170

4. At the center, push back the hook [A] to release the quenching lamp, and then slide out the end of the QL [B].



d223c3171

5. Lift out the QL.




d223c3172

6. Use only a blower brush to clean the quenching lamp.


Potential Sensor

1. Remove the drum unit. page 582
2. Disconnect the potential sensor bracket.




d223c3173

3. Pull the bracket forward [A] to detach the rear end of the bracket from the machine, and then pull it out [B].




d223c3174

4. Lay the potential sensor bracket on a flat, clean surface.
5. The potential sensor power pack [A] is on the end of the bracket, and the potential sensor [B] is on the opposite side.




d223c3175

6. Free the black harness.



d223c3176

7. Push the harness [A] through the bracket, and then pull the connector [B] through the hole.



d223c3177

8. Disconnect the potential sensor.




 x2

d223c3178

4

9. On the other end of the bracket, disconnect the power pack cover.



 x1  x3

d223c3179

10. Remove cover [A] and power pack [B].



d223c3180


11. The potential sensor and power pack are always replaced together.



d223c3181

Re-assembly

1. The end of the potential sensor bracket [A] is inserted into the cut-out [B] on the rear panel.




d223c3182

2. After replacing the drum potential sensor, go into the SP mode and make sure that **SP3901** is on, and then do **SP2962** (Adjustment of Drum Conditions).

Cleaning Filter

1. Remove the drum unit and drum. page 582
2. You can easily see the cleaning filter with the drum removed.



d223c3183

4

3. Lift out the filter.



d223c3184

4. After replacing the filter, make sure that its edges are perfectly flat against the unit.

Drum Cleaning Blade


1. Remove the drum unit and drum. page 582
2. Disconnect the blade.



 x1

d223c3185

3. Remove the blade.



d223c3186


4. Clean the blade edge carefully with only a soft, clean cloth.

★ Important

- Handle the blade carefully to avoid nicking its edge.
 - New blades are treated with special setting powder, so avoid touching the edge of a new cleaning blade. If the edge of a new blade is accidentally wiped clean, dust it lightly with some toner before installing it.
5. Before installing a new blade:
 - Clean the entrance seal, side seals, and cleaning brush.
 - Make sure that the blade side seals are not pinched by the blade.

Cleaning Brush

1. Remove the drum unit and drum. page 582
2. Remove the drum cleaning blade. page 596
3. Insert the tip of a small screwdriver into cutout [1] (this keeps the gears from turning), and then remove the coupling [2].




 x1

d223c3187

4

4. Remove the inner bushing.



 x1

d223c3188

5. Pull the shaft of the cleaning brush toward the rear to disengage the coupling on the end of the shaft from its pin, and then pull the brush out.

★ Important


- Avoid touching the cleaning brush with bare hands.



d223c3189


Re-assembly

1. The pin [A] fits into the slot of the coupling [B] on the end of the cleaning brush.



d223c3190

2. After replacing the cleaning brush, use a blower brush and clean the ID sensor to make sure that it is free of toner.




d223c3191a

3. Check the entrance seals and confirm that they are not bent.

Pick-off Pawls


1. Remove the drum unit and drum. page 582
2. Remove the pick-off pawl bracket with the pawls attached.



 x2

d223c3192

3. Disconnect the pick-off pawls.



 x1

d223c3193

Re-assembly

1. Each pawl must be positioned as shown.




d223c3194

4


ID Sensor

1. Remove the drum unit and drum. page 582
2. Remove the pick-off pawl bracket.
3. Raise the drum unit [A] slightly so you can see the sensor [B].



d223c3195

4. Disconnect the sensor.



 x1
  x2

d223c3196

5. Remove the sensor.



d223c3197

6. Re-assemble the machine.
7. Connect the machine, turn it on, and go into the SP mode.
8. Do **SP3901** and make sure that it is on (default), and then do **SP2962** (Adjustment of Drum Conditions).
9. Do **SP3001-002** (ID Sensor Initialization Setting).

Toner Collection Bottle

1. Open the front door.
2. Remove the lock pin




d223c3198

3. Pull out the toner collection bottle on its base.



d223c3199


4. Detach the bottle from the base clamp and replace it with an empty bottle.



d223c3200

Ozone Filters

1. On the back of the machine, remove the cover of the ozone filter box.


 x1

d223c3206

- Slide the cover off.



d223c3207

- Remove the ozone filters and replace them with new ones.



d223c3208

4

Optics Dust Filter

- At the right rear corner of the machine [A] remove the cover bracket with filter attached.



d223c3209


- Separate the filter and cover bracket.



d223c3210

Reinstallation

1. Set the tabs on the bottom edge of the filter into the notches provided on the bottom of the filter frame.




d223c3782

2. Make sure that the edges of the filter are flat and even with the edges of the frame.

Internal Dust Filter

1. Open the front door.
2. Pull the toner bottle holder out and swing the toner bottle holder to the right.
3. Remove the PCU inner cover [A] so you can see the dust filter [B].




 x2  x2  x1

d223c3211

4

4. Remove the filter.



d223c3212

5. Lay the filter on a clean, flat surface.






d223c3213

6. Clean the filter with a vacuum cleaner.

Toner Bottle Fan


1. Open the front door.
2. Remove the left upper inner cover.



 x2  x1


d223c3214

3. With the cover removed you can see the duct of the toner bottle fan.



d223c3215

4. Remove the scanner unit. page 507
5. Disconnect the left edge [A] of the laser unit cover.
6. Disconnect the front edge [B] of the laser unit cover.




 x3

d223c3216


7. Disconnect the right edge [A] of the cover.
8. Disconnect the right rear corner [B] of the cover.

★ Important

- Do not loosen either screw [C] below. These screws are used to adjust the position of the scanner unit.




 x1



 x1

d223c3217


9. Free the harness along the rear edge of the cover.



x4


d223c3218

10. Pull the cover [A] away from the front edge of the machine [B]. (You do not need to remove.)




d223c3219

11. Disconnect the toner bottle motor.




 x1  x1 d223c3220

- 12. Push in the tab release [A] on the right side of the motor bracket.
- 13. Rotate the motor [B] straight up, and then remove the motor bracket.




 x1 d223c3221

- 14. Disconnect the motor bracket.



 x2 d223c3222

15. Separate the motor and bracket.




d223c3223

4


Re-assembly

1. Hold the motor [A] over the position where you removed it, and then rotate it straight down.
2. Check the front of the machine under the operation panel, and confirm that the duct [B] is aligned straight with its cutout.




d223c3224

3. On the right side of the motor [A], insert the lap into its slot to position the motor.
4. Press the tab release [B] on the left side of the bracket to lock bracket and motor in place.



d223c3225

5. Once again, check the alignment of the duct at the front of the machine and confirm that it is straight.





d223c3226

6. Reassemble the machine.


Drum Motor

1. Remove rear covers. page 478
2. Open the controller box [A]. page 490



d223c3227

3. Disconnect the IOB bracket [A], page 492



d223c3228

4. Remove the flywheel.




 x3



d223c3229

5. Remove the flywheel sprocket.



 x1

d223c3230



4

6. Remove the small gear. (This gear is black in the D223/D224, and white in the D225.)




 x1

d223c3231



7. Remove the lower gear (This gear is black in the D223/D224 and white in the D225.)




 x1

d223c3232




8. Remove the large gear.



d223c3233

4


9. Note the configuration of the 2-direction timing belt.
- Swinging pulley arm [1] is up.
 - Tan side of the belt is facing out at [2].
 - Back side of the belt is facing out at [3].




d223c3234

10. Remove the drive belt [A].
11. Leave the belt hanging free and straight [B]. (You do not need to remove it.)

4




 x1




d223c3235

12. On the face of the motor bracket, remove spring [A].

13. Loosen screw [B] to release tension on the drive belt.




 x1




 x1

d223c3236

14. Remove drive belt.




 x1



d223c3237


15. Disconnect right upper arm [A] of the motor bracket.

16. Disconnect right edge [B] of the bracket.




17. Disconnect lower left arm [A] of the motor bracket.

18. Disconnect top edge [B] of the bracket.



19. Remove bracket [A] with motor attached.

20. Lay the bracket and motor [B] on a flat, clean surface.



d223c3240

4


21. Disconnect the support bracket.



 x3


d223c3241

22. Pull shaft and coupling through the bracket.




d223c3242

23. Disconnect motor at [A] and [B].



24. Separate the motor and base motor bracket.



Re-assembly

Follow this procedure to re-set the 2-direction drive belt.

1. Pick up the hanging belt [1] and pull it straight out.
2. Push swinging pulley [2] up.
3. Thread the black side of the upper half of the belt [3] to the raised pulley



d223c3245

4

4. Check the configuration of the belt and pulleys.



d223c3246

Important SP Codes: Drum Unit

Here is a list of SP codes related to testing and servicing the drum and components around the drum.

Item	SP No.	Function
Drum condition display (LD level)	3902-5	Displays the LD power correction value as a result of the latest Vh adjustment.

Item	SP No.	Function
Drum condition display (Vd)	3902-2	Displays drum dark potential, the standard potential, electrical potential of the black areas after exposure.
Drum condition display (Vg)	3902-4	Displays the charge grid voltage resulting from the latest Vd adjustment.
Drum condition display (Vh)	3902-3	Displays standard halftone drum potential, used for laser power adjustment.
Drum condition display (Vid)	3902-6	Displays ID sensor pattern potential, the latest drum surface voltage measured on the ID sensor pattern.
Drum condition display (Vql)	3902-7	Displays the drum potential after quenching.
Drum replacement	3901	After replacement, check this SP code and confirm that auto process control is on and operating.
Drum replacement	2962	After replacement, do SP3901 to confirm that auto process control is on and operating, and then do SP2962 to execute process control manually for the new drum. This SP2962 executes only if SP3901 is on (enabled).
Forced toner supply	2207	Rotates the toner bottle to supply toner to the toner supply unit. Use to determine if toner supply is operating correctly. If forcing toner supply with this SP does not darken the image, then toner supply is not operating correctly.
ID sensor replacement	2962	After replacement, do SP3901 to confirm that auto process control is on and operating, and then do SP2962 to execute process control manually for the new sensor. SP2962 executes only if SP3901 is on (enabled).
ID sensor replacement	3901	After replacement, check this SP code and confirm auto process control is on and operating.


Item	SP No.	Function
Potential sensor replacement	2962	After replacement, do SP3901 to confirm that auto process control is on and operating, and then do SP2962 to execute process control manually for the new sensor. This SP2962 executes only if SP3901 is on (enabled).
Potential sensor replacement	3901	After replacement, check this SP code and confirm auto process control is on and operating.
Print margins	2101	Do this SP to adjust the margins (erase, blank space) at the top, bottom, and sides of the paper.

Development Unit

Development Unit Removal and Re-Installation

Removing the Development Unit

1. If the LCIT is connected to the right side of the machine, disconnect it and pull it away.
2. Prepare a clean, flat surface for the development unit.
3. Disconnect shuttle cover [A].



★ Important


- A washer is attached to the shuttle cover screw in order to prevent the screw from falling into the machine. Turn the screw counter-clockwise only enough turns to remove it. If you loosen the screw too much the washer will fall into the machine.

4. Remove shuttle cover.



d223c1032

- 5. Remove lock screw [A].
- 6. The toner bottle holder [B] springs open slightly as soon as the screw is removed.



x1

d223c1033

- 7. Push the front door slightly to the right, and then swing the holder out as far as it will go.




d223c1034

★ Important


- The door must be completely open. If it is not, then it will block removal of the development unit.
- The LCIT must be disconnected from the right side of the machine to allow the front door to open completely.

8. Remove knob [A]. (This is a reverse thread. Turn it **clockwise** to remove it).
9. Disconnect development unit faceplate [B].




 x2

10. Remove development unit faceplate.




11. Raise the toner supply pipe shutter to close the pipe.



d223c1037


- 12. On the right [A] disconnect the development unit [A].



 x2


d223c1038

- 13. Slip the development unit [A] to the right.
- 14. Push the development unit [A] slightly to the right, and then pull the unit [B] straight out of the machine.



d223c1039

15. Lay the development unit on the prepared surface.




d223c1104

Separating the Development Unit and Toner Hopper

1. At the front end of the unit, disconnect the pressure release tube.

★ Important


- Only the D225 Model has this pressure release tube. This step is not required for the D223/D224 models.



d223c1041


4

2. Disconnect the toner hopper.



d223c1042

3. Rotate the toner hopper slightly as you lift it.
4. Remove the toner hopper and set it aside.




d223c1043

Re-installing the Development Unit


Pay attention to these important points as you re-install the development unit.

1. Hold the hopper perfectly level when re-attaching it, to prevent toner from entering the rails of the development filter.
2. To re-assemble the top and bottom half of the development unit, first allow the bottom half [A] to tip slightly forward.
3. Hold the top half [B] (toner hopper) over the bottom half, set the cutouts on the ends of the shaft below, and then slowly rock the top half forward [C] so the holes are aligned.



d223c1107

4. Make sure that the holes are aligned at the rear [A] and front [B], and then fasten the screws.




d223c1108

5. If you are installing a D225, be sure to re-connect the pressure release tube at the front of the development unit.



d223c1045

6. Slip the unit slightly to the right as you push it slowly back into the machine.



d223c1047

7. Push the development unit in until it stops, and then push it to the left.
8. You should see the pin through the oval hole as shown below. This means the unit is locked in the correct position.



d223c1049

9. The horizontal pin must be through the hole and lapped over the plate as shown below on the left.




d223c1050

Note

- If the pin does not slide over the plate as shown above on the left, turn the front gear of the development unit counter-clockwise and try again.

10. Be sure to re-connect the development unit [A].



 x2

d223c1038

11. You must remember to **lower** the supply pipe shutter so the pipe is open.




d223c1052

★ Important

- The shutter must be down. If it remains up, you will not be able to close the toner bottle holder and the front door.

12. Re-install the PCU inner cover [A].

13. Be sure to raise lever C1. (The front door will not close if C1 is down.)



d223c1053

Just Replaced Developer?

If you have just replaced the developer, you must initialize the developer immediately after re-installing the development unit. See "Initializing Developer" below.

Replacement with a Used Development Unit

Do the following procedure if you need to replace the development unit with a unit from another machine for testing.

1. Do **SP2220** (Vref Manual Setting) and **SP2906** (TD Sensor Control Voltage) on the loan machine and note the settings.
2. Remove the development unit from the loan machine and then install it in the other machine.
3. Do **SP2220** and **SP2906** on the machine where you just installed the loan development unit and enter the values from the loan machine.
4. After the test, reinstall the old development unit and restore the original settings of both SP codes.

Developer Replacement

Replacing the Developer

1. Gather what you need.
 - One developer packet
 - Plastic disposal bag [A]
 - Plastic cover sheet [B]



d223c3247

4

2. Place the development unit [A] on the plastic sheet.
3. Have the disposal bag [B] for the old developer close at hand.



d223c3248


4. Disconnect the hose. (This is necessary only for the D225.)



D225

d223c3249

5. Disconnect the toner hopper.



 x2

d223c3250

6. While holding the hopper perfectly level as you remove it to prevent toner spill, rotate the toner hopper very slightly (10° to 20°) and remove it.

4



d223c3251

7. Set the toner hopper aside.
8. Spread a sheet of paper on the table.
9. Slowly, turn the development unit upside down onto the paper.
10. Turn the knob through several complete rotations to empty all the developer in the development unit.



d223c3252

11. Set the development unit aside, and then gather the dumped toner and paper.
12. Dump them in the disposal bag and seal it.



d223c3253

4


13. Vacuum clean these areas:

- Rear side seal [A]
- Front side seal [B]
- Development roller sleeve and shaft [C] with clean, dry cloth and blower brush



d223c3254

14. Shake the developer packet several times to loosen the developer.
15. Cut off the top edge of the packet.




d223c3255

16. Keep the cut edge with the lot number embossed on it. You will need this number to register the developer lot number on the machine.



d223c3256

17. While turning the knob slowly, pour in one pack of developer from one end of the development unit to the other.



d223c3257

18. Make sure that the developer is evenly distributed across the length of the roller.
19. Continue to turn the knob several times to prevent clumping in the developer.

Re-installing the Development Unit

Re-assemble the developer unit and toner hopper, and then re-install the unit in the machine. page 623

Initializing the Developer

Follow the procedure below precisely to enter the developer lot number, and to initialize the new developer.

★ Important

- You must open the door and leave it open before you switch the machine on. This prevents the machine from executing automatic process control. (It does this every time the machine is turned on.)
- The TD sensor must be initialized with the new developer SP2801-001 before automatic process control executes for the first time with the new developer.

1. Connect the power cord to the power source.
2. Open the front door.
3. Turn the machine on.
4. Enter the SP mode.
5. Close the front door
6. Do **SP2801-002** and enter the Lot No. (This is the number written on the edge of the packet you cut from the developer packet.)
7. Do **SP2801-001** to initialize the TD sensor.
8. Exit the SP mode and resume normal operation.

Entrance Seal, Side Seals

1. Remove the development unit. page 623
2. Separate the development unit and toner hopper. See "Separating the Development Unit and Toner Hopper" in this section.



x1


d223c3258

3. Press in the catches on either end to release the entrance seal bracket, then remove it.




d223c3259

4. Remove the side seals from both ends [A] and [B].



d223c3260

5. Vacuum clean the area, and then attach new seals as shown below.




d223c3263

4

6. Make sure that the seals are attached correctly.


- The bottoms of the seals [A] should be fully visible.
- The bottom of a seal [B] **should not** be in the slit.



d223c3264


Re-assembly

1. Clean the entrance seal bracket before re-installing it.



d223c3261

2. When you re-install the entrance seal bracket, make sure the tabs and bosses are engaged at four locations (both end tabs, and two bosses on the bracket).



Development Filter

4

1. Remove the development unit. page 623
2. Separate the development unit and toner hopper. See "Separating the Development Unit and Toner Hopper" in this section.
3. Lift out the filter bracket base.

↓ Note

- There are some minor differences in the shape and size of the development filters for the D223/D224 and D225. The procedure below shows filter replacement for the D225.



D223/D224

There is no hose attached to the filter bracket.



d223c3304

4. Remove first filter bracket [1].



d223c3266

5. Remove second filter bracket [2].



d223c3267

6. Remove rear filter [1].



d223c3268


D223/D224

The filter bracket is one piece.



d223c3305

7. This photo shows the filter bracket base [1], filters [2], and filter brackets [3] removed from the D225.



d223c3269


This photo shows the [1] filter bracket base, [2] filters, and [3] filter brackets removed from the D223/D224.

**D223/D224**

d223c3306


Re-assembly

1. Inspect the rails on both ends of the bracket case and make sure they are clean.



d223c3307

2. If there is any toner in the rails, wipe them clean before re-installing the bracket case.
3. When installing a new filter, set the filter [A] snug inside the filter case, and then place the case [B] over the top of the filter bracket.




d223c3270

4. Vacuum clean, and then check the gaps at the ends of the filters to make sure that they are flat and sealed.


TD Sensor

1. Remove the development unit. page 623
2. You can see the TD sensor on the side of the development unit.



d223c3271

3. First, free the harness [A].
4. Disconnect TD sensor [B].



 x3

 x2


d223c3272

1. Remove the TD sensor.
2. Clean the port now before you re-attach the TD sensor.



d223c3273


3. Lay the sensor on a flat, clean surface.



d223c3274

Re-assembly

1. Be sure to run the harness through the frame as it was originally.



d223c3275

2. If you have just replaced the TD sensor, go into the SP mode.
3. Do **SP3901** (Auto Process Control) and make sure that it is on (default).
4. Do **SP2801** (TD Sensor Initial Setting)
5. Do **SP2962** (Auto Process Control) to execute auto process control.

Toner End Sensor


1. Remove the development unit. page 623
2. Disconnect and remove the toner end sensor cover.



🔑 x1


d223c3277

3. On the other side of the toner hopper, free the harness.




d223c3278

4. While removing the screws carefully to avoid stripping the holes, disconnect the toner end sensor [A].
5. Clean the port now before you re-attach the sensor [B].



 x1



d223c3279

4



6. Lay the sensor on a flat, clean surface.



d223c3280

Re-assembly


1. Pass the harness through the cutout [A] on the edge of the cover.
2. Make sure the harness **is not** pinched between the side of the toner hopper and the edge of the cover as shown [B].




d223c3281

Toner Separation Unit


1. Remove the development unit. page 623
2. Disconnect toner separation unit [A].
3. Disconnect hose [B] (D225 development unit only)



4. Remove the toner end sensor cover.



5. On the back of the toner hopper, release the long tab of the toner separation unit cover [A], and then remove the toner separation unit [B].



d223c3203

6. Lay the toner separation unit on a flat, clean surface.


4



d223c3204

Reassembly

1. Pass the harness through the cutout [A] on the edge of the toner end sensor cover.
2. Make sure the harness is not pinched between the side of the toner hopper and the edge of the cover as shown [B].



d223c3281


Toner Bottle Motor

1. Spread some paper on a flat, clean surface.



d223c3282

2. Open the front door, and then remove the toner bottle.
3. Disconnect the shuttle cover.




d223c3283

★ Important


- A washer is attached to the shuttle cover screw in order to prevent the screw from falling into the machine. Turn the screw counter-clockwise only enough turns to remove it. If you loosen the screw too much the washer will fall into the machine.

4. Remove the shuttle cover.



d223c3284


5. Remove lock screw [A] so the toner bottle holder [B] can swing freely.



 x1


d223c3285

6. Locate the C-clamp under the base of the toner bottle holder, and then remove it.




4

7. Locate the small motor harness between the door and toner bottle holder on the right, and then disconnect it.




8. Lift the toner bottle unit off its hinges and lay it on the paper to catch toner spill.



d223c3288

9. Disconnect the cover.




 x1


d223c3289

10. Disconnect bottom plate [A].

11. Disconnect toner pan [B], and then remove it.



🔩 x2





🔩 x1

d223c3290

⬇️ **Note**

- The toner pan must be cleaned at every PM interval (300 K).


12. Separate the bottom plate so you can see the motor [A].
13. Disconnect motor bracket [B]




🔩 x2

d223c3291

14. Remove the motor bracket with motor attached [A], and then lay it on a flat, clean surface.
15. Disconnect motor bracket [B].



[A]



[B]

🔩 x2

d223c3292

16. Separate the motor and bracket.



d223c3293

Development Motor


1. Remove the rear covers. page 482
2. Open the controller box. page 490



 x1


d223c3294



3. The used toner pump tube assembly and drive rod [A] block the removal of the motor [B].



d223c3295


4. Disconnect top of used toner pump assembly [A].



 x1
  x1


d223c3296

5. Pull out the stopper on the tube base [A].



6. Pull the bottom of the tube [A] up, and then remove the tube pump assembly [B].

4




7. Disconnect the motor drive board.




8. Disconnect motor bracket top [A].

9. Disconnect lower right corner of bracket [B].



10. Disconnect lower right corner of bracket [A].
11. Pull out the motor bracket [B] with the motor attached.




12. Lay the motor on a flat, clean surface.



d223c3302

Re-assembly


1. To hang the motor correctly, insert the hook [1] on the motor bracket into the hole [2] in the frame inside the machine.



d223c3303



Development Unit Power Pack

1. Remove the rear upper and lower covers. page 482
2. Open the controller box. page 490
3. Remove the flywheel.
4. The development unit power pack is located next to the registration motor.



d223c3687


5. Free harness [A].
6. Disconnect bayonet connectors [B].


 x1

 x2

d223c3688

7. Disconnect the bottom edge of the power pack.


4



 x1

d223c3791


8. Disconnect the top [A] and bottom [B] of the bracket.



 x2


d223c3689

9. Unhook the bracket with the power pack attached and remove it.




d223c3690

10. Lay the bracket on a flat, clean surface.
11. Remove the cover bracket.




🔑 x1




d223c3792

12. Free the connector harnesses.




🔑 x2



d223c3793


13. Separate the power pack and bracket.



Used Toner Collection Unit

Used Toner Collection Unit Removal


1. Remove the rear upper and rear lower covers. page 482
2. Open the controller box. page 490
3. The used toner collection unit [A] is located at the right, rear edge of the main machine. The unit contains three components.



d223c3692


1	Used Toner Collection Motor
2	Bottle Set Sensor
3	Bottle Full Sensor

4. Open the front door, and then remove the used toner bottle [B].



4

5. Spread a drop cloth or some paper on a flat clean surface to hold the unit after it is removed from the machine.
6. Disconnect the top [A] and bottom [B] of the toner pump assembly.




1. Grasp the tube [1], drive shaft [2], and base bracket [3] and then remove them together.



d223c3694


2. Lay the tube on a flat, clean surface that has been covered with a drop cloth or paper to catch loose toner from the coils.
3. Disconnect the bracket.



 x1  x2


d223c3695

4. Pull the unit straight out the back of the machine, and then twist it down and to the right to remove it.



d223c3696


5. Set the unit on a flat, clean surface.



d223c3697

Toner Collection Motor Sensor

1. Remove the used toner collection unit. page 664
2. The toner collection motor sensor [A] is on top of the toner pump assembly.
3. Disconnect gear shaft [B].




 x1

d223c3698

4


4. Open the release tabs on the face of both gears [A], then remove them.
5. Remove shaft [B].



 X2

d223c3699

6. Disconnect the sensor, and then remove it.




 X4

d223c3700

Used Toner Collection Motor


1. Remove the used toner collection unit. page 664
2. The used toner collection motor [A] is at the rear of the used toner collection unit.
3. Disconnect the motor [B].



 X1

d223c3701

4. Disconnect the motor from the bracket, and then remove it.




 X2

d223c3702

Toner Bottle Set Switch, Toner Bottle Full Switch

1. Remove the used toner collection unit. page 664
2. The bottle set sensor [1] is at the front of the unit, and the bottle full sensor [2] is at the rear. Both are press switches.




d223c3703


4

Toner Bottle Set Switch

1. Use the tip of a very small screw driver to release the tab at the front bottom edge [A].
2. Release the tab at the rear top edge [B].




▼ X2



d223c3704

3. Pull out the switch and disconnect it.




 x1

d223c3705

4

Toner Bottle Full Sensor

1. Remove the top of the unit [A].
2. Pinch together the side tabs [B] to release the top, and then remove it.




 x1

 x2


d223c3706

1. Pull the gear and coil [A] out partially. Do not try to remove it.
2. Use the tip of a small screwdriver to disconnect the sensor [B].




4

3. Remove screw [A].
4. Use the tip of a small screwdriver to release the tabs on sensor [B].



5. Use a pair of small radio pliers to remove the switch.



Important SP Codes: Development Unit

Here is a list of SP codes related to testing and servicing the development unit.

Item	SP No.	Function
Developer adjustment mode	2967	Determines whether the amount of toner is checked during auto process control with only the TD sensor. With this feature on, the machine uses the TD sensor only. During auto process control execution after the main switch is turned on, the toner amount in the development unit is normally checked and adjusted using the ID sensor. However, in some environments, such as where there could be traces ammonia in the air, copies could appear dirty or too dark because the ID sensor reading is not reliable. In such a case, SP2967 should be enabled so only the TD sensor is used.
New developer, TD sensor	2801-1	In this order: Enter the lot number (SP2801-2), initialize the new toner (SP2801-21).
New developer, initialize	2801-1	Enter the lot number with SP2801-2 before you initialize developer with SP2801-1.
New developer, lot number	2801-2	Enter the lot number embossed at the top edge of the developer package. Enter the lot number with SP2801-2 before you initialize developer with SP2801-1
TD sensor replacement	2801-1	After replacement, do SP3901 to confirm that process control is on and operating, do 2801-1 to initialize the TD sensor, and then do SP2962 to execute auto process control manually.
Toner supply mode	2208	Selects the toner supply mode: Sensor Control or Image Pixel Count. Select Image Pixel Count only if the TD sensor has failed and cannot be replaced immediately, so that the customer can use the machine. Return the setting to Sensor Control after replacing the sensor.

Transfer Belt Unit

Transfer Belt Unit Removal

1. Prepare a place to lay the unit by spreading some clean paper or a drop cloth on a flat, clean surface.
2. Remove the drum unit. page 582


★ Important

- Removal of the drum unit is recommended to prevent scratching the surface of the belt on the as it is removed.

3. Disconnect transfer belt unit [A].
4. Remove transfer belt unit stay [B].
5. Lower C1 [C] and then pull the transfer belt unit out of the machine.

★ Important

- Avoid touching the surface of the belt with bare hands.




Transfer Belt, Transfer Roller Cleaning Blade

Transfer Belt Assembly Removal

1. Remove the transfer belt unit. page 674
2. Raise the transfer belt partially by its knob [A].
3. At the front, disconnect terminal [B].
4. At the rear, disconnect terminal [C].
5. Raise the belt until it is perpendicular, and then remove it.

Note

- To avoid scratching the belt on the guide, never rotate the belt unit up more than 90 degrees.
6. Raise and stand the belt perpendicular to the unit and remove it.



7. Lay the belt assembly on a flat, clean surface.
8. Replace the transfer roller cleaning blade before you replace the belt.

Important

- The transfer belt and transfer roller cleaning blade should be replaced together. (See next section.)

Transfer Roller Cleaning Blade


★ Important

- Never touch the edge of a new transfer roller cleaning blade.
- The edge of the blade is dusted with setting powder.
- If the setting powder is removed accidentally, dust the edge of the blade with some toner.
- To avoid damage from static electricity, always work carefully around the exposed transfer power pack, especially when cleaning with a vacuum cleaner.

1. Remove the transfer belt assembly. (See previous section.)
2. Remove transfer roller cleaning blade [A].

★ Important

- Never remove or loosen the paint locked screws on the blade [B].



d224c0981

3. After replacing the blade, clean the area around the rollers thoroughly before you attach the new belt.


Transfer Belt Replacement

1. Replace the transfer roller cleaning blade. (See previous section.)

2. Remove the screws from the ends of the driver roller bracket at the front [A] and rear [B].
3. While holding the belt assembly level, raise the drive roller [C] to collapse the unit and release tension on the belt.
4. Slowly remove the belt [D] and then replace it with a new one.

★ Important

- Avoid touching the surface of the new belt with your bare hands.



Re-assembly

★ Important


- Never touch the surface of the belt with bare hands and never apply alcohol to the surface of the belt.
1. Before re-assembling the transfer belt unit, use a clean cloth and alcohol to clean the surfaces the [1] drive roller, [2] transfer roller, and idle [3] idle roller. Make sure these areas are clean and free from toner, paper dust, etc.

See RTB 35




d223c3308

2. Clean the surface and underside of the transfer belt with a blower brush.



d223c3309


3. When you position the new the transfer belt unit over the rollers, make sure that the belt is centered between the triangular marks on front and rear side of the unit.



4

d224c0980

4. Confirm that all harnesses are connected and securely fastened in their hook clamps.




d223c3310

5. After re-installing the transfer belt unit, turn the belt and confirm that the toner collection coil turns.
6. Raise and lower the belt with lever C1 to make sure that the belt raises and lowers smoothly.

Transfer Power Pack


1. Remove the transfer belt unit. page 674
2. Remove the transfer belt assembly. page 675
3. Disconnect ground wire and free its harness across the width of the unit.



 x1  x7

d223c3310

4. Free the ground harness at the rear



▼ x1

d223c3312


5. Free the terminal wire at the front.



▼ x1

d223c3313

6. Remove the top screw [A] of the solenoid bracket, and then loosen the two left screws [B]. (This allows you to free the front terminal harness below the bracket at [A].)



 x3

d223c3314


4

7. Free the front terminal wire from under the loosened solenoid bracket.



d223c3315


8. Free the rear current terminal wire [A] at the rear.




 x2

d223c3316

9. Disconnect the power pack [A], and then unfasten the right edge of the power pack [B].



10. Lift the right edge of the power, remove it, and then lay it on a flat, clean surface.





Re-installation

★ Important

- The power pack must be locked correctly in place, and all the harnesses must be secured in their clamps. A loose harness could interfere with the rotation of the transfer belt.



Do these checks before you re-install the transfer belt assembly.

1. Before you re-connect the power pack, confirm that the left edge [A] of the power pack is below the tabs on the left.
2. Confirm that the transfer current terminal wire [B] is below the wire guides on the right.




4

3. Pass the ground terminal wire under the top arm of the solenoid bracket [A] and then tighten the bracket screws [B] on the left.



4. After you connect the ground wire, make sure the wire is below all the wire guides at the top.



Discharge Plate

1. Remove the transfer belt unit Transfer page 674


↓ Note

- It is not necessary to remove the transfer belt assembly. However, work carefully to avoid scratching the surface of the belt.

2. Remove the shoulder screw and spring [A].
3. Rotate the discharge unit [B] up, and then raise it off.
4. Disconnect three tabs [1], [2], [3].
5. Remove small bracket [C].
6. Open the case [D].
7. Remove discharge plate [E].

★ Important

- At re-installation make sure that the discharge plate is perfectly flat before you re-assemble the case.



Important SP Codes: Transfer Belt Unit

Here is a list of SP codes related to testing and servicing the development unit.

Item	SP No.	Function
Transfer belt, resistance	2970	Displays the resistance of the surface of the transfer belt.
Transfer current timing, LCIT	2931	These SP codes adjust the on/off timing for copying on paper from the LCIT.
Transfer current timing, Tray 1	2932	These SP codes adjust the on/off timing for copying on paper from Tray 1.
Transfer current timing, Tray 2	2933	These SP codes adjust the on/off timing for copying on paper from Tray 1.
Transfer current timing, Tray 3	2934	These SP codes adjust the on/off timing for copying on paper from Tray 3.
Transfer current timing, bypass tray	2936	These SP codes adjust the on/off timing for copying on paper from the bypass tray.

Item	SP No.	Function
Transfer current, adjusting	2301	Adjusts the current applied to the transfer belt during copying. Many selections are available for both the area of the belt where the current is applied, and the type of paper in used.

Fusing Unit


⚠ CAUTION

- Switch off the machine, disconnect the plug from the power source, and then wait a few minutes to allow the fusing unit to cool before you remove it from the machine.

Fusing Unit Removal

↓ Note

- Before you begin, spread a mat or some clean paper on the floor or a table where you intend to set the fusing unit.
1. Open the front door.
 2. Pull out the transfer unit.
 3. Open **D2** and **D3** until you can see the hole [A] in the shaft where the knob is attached
 4. Insert the tip of a screwdriver into the hole so the shaft cannot move when you turn the knob screw.
 5. Remove knob [B].
 6. Disconnect the other cover screws.
 7. Slowly, pull the cover away partially, and then disconnect the LED [C].
 8. Remove the inner cover [D].




9. Open **D3** [A].
10. Remove stopper bracket [B].

11. Close D3.
12. Disconnect the unit at [C].

★ Important

- At [C] the D223/D224 has one clamp and two connectors (🔌x1, 📦x2), and the D225 has two clamps and three connectors (🔌x2, 📦x3).

13. Remove fusing unit [D].



★ Important


- Support the bottom of the fusing unit with your hand as you remove it.

↓ Note

- At reassembly, make sure that the two harnesses of the web unit are not pinched between the inner cover and frame of the fusing unit.

Thermostats, Thermistor, NC Sensor


The end thermistor [1], center thermistor (NC Sensor) [2], and thermostats [3] are arrayed across the top of the fusing unit and protected by the fusing unit upper cover.



d223c3329

End Thermistor (D223/D224)


1. Remove the fusing unit. page 688
2. Remove harness cover [A].



 x3


d223d4513

3. Remove upper cover [A].




d224c0989

1. Raise metal harness clamp [A].
2. Disconnect thermistor harness [B].



d223d4525


3. Disconnect spring [A], and then disconnect first bracket [B].



 x1  x1

d223d4526

4. Disconnect second bracket [A].




 x1

d223d4527

5. Remove the bracket with thermistor attached.


6. Separate the thermistor and bracket.



End Thermistor (D225)



1. Open the front door.
2. Pull out the fusing unit until it stops.
3. Remove upper cover [A].

4



4. At the rear, open metal clamp [A], and then disconnect end thermistor harness [B].

4





 x2

 x1

d223d4502

- 5. Disconnect spring [A].
- 6. Remove bracket [B] with thermistor and harness attached.



 x1  x1

d223c3332

- 7. Separate thermistor and bracket.




 x1

d223c3333


Thermostats

The D223/D224 has three thermostats, the D225 has only two thermostats.



d223c3335

1. Open the front door.
2. Pull out the fusing unit until it stops.
3. Remove upper cover [A].



d224c0989


D223/D224

1. Disconnect the thermostat bracket.



 x4 d223d4504

2. Lay the bracket on a flat, clean surface.
3. Separate the thermostats from the bracket.



 x4



d223d4506

D225

1. Disconnect the thermostat bracket.



 x4 d223d4505

2. Lay the bracket on a flat, clean surface.
3. Separate the thermostats from the bracket.



 x2



d223d4507

4

CAUTION

- To prevent a fire, never attempt to reset a blown thermostat by manipulating the exposed edges of the black cover with a screwdriver, or by hitting it on a table.
- A thermostat that has been reset manually could fail and cause a fire.
- Always replace a blown thermostat with a new one.




d223c3745

Reinstallation

Important

- To prevent damage to a thermostat, never touch its detection surface.
1. Place the end of the thermostat harness that has the round lead [A] in between the two ribs [1], [2] in the bracket.

2. Tighten the screw for the round lead [A] as tight as possible without damaging the screw or screw hole.




3. Check the harness.

- The harness should be straight [A]. This is correct.
- If the harness is not straight between [1], [2] as [B], this is incorrect. This could cause error SC542 or SC545.


4

Center Thermistor (NC Sensor) (D223/D224)

1. Remove the fusing unit. page 688
2. Remove harness cover [A].





3. Remove top cover [A].




d224c0989

4. At the front, raise metal harness clamps [A].
5. Disconnect thermistor harness [B].


 x3

 x1

d223d4529


6. Disconnect center thermistor harness bracket [A].



 x2

d223d4530

7. Remove the bracket with thermistor attached, and then separate bracket and thermistor [A].




 x2


d223d4531

Center Thermistor (NC Sensor) (D225)

1. Remove fusing unit upper cover.
2. At the rear [A], free the NC sensor harness.
3. Disconnect harness [B].



[A]
x2




[B]
x1


d223c3338

4. Free harness [A] on top of the fusing unit.

5. Disconnect NC sensor bracket [B].



[A]
x4



[B]
x1


d223c3339

6. Remove bracket with NC sensor and harness attached.



d223c3340

7. Separate bracket and harness.




Web Cleaning Roller

4

Web Unit Disassembly


Note

- The web unit can be removed without removing the fusing unit from the machine.
1. Open the front door and pull out the fusing unit on its support rails.
 2. Remove web unit [A].




d224c0993

1. Rotate the upper cover [A], down slightly, and then remove it. Also remove the end cover [B]



2. Remove web shafts [A].
3. Remove the web cleaning rollers from shaft driver pins [B].
4. Remove web bushing [C].
5. Remove cleaning roller [D].




Re-assembly

1. After replacing the web, you must execute **SP1902-001** (Fusing Web Used Area Display/Setting) to reset the web consumption count to zero. This SP code must be executed to release **SC550**.
2. Be sure to print an SMC report before executing Memory All Clear (**SP5801**).
3. After executing **SP5801**, be sure to re-enter the value recorded for **SP1902-001** in the SMC report.


Web Unit Re-assembly

1. Insert the end of the web into the slot **1**, and attach the cleaning roller [A]
2. Insert the drive pins [B] into the web shaft **2**.
3. After installing bushing [C], rotate the shaft right to lock it, then attach the lock screw **3**.



d224c0995

4. Set the web [A] under the feeler [B] of the web end sensor **4**.
5. Attach bushing 2 [C] **5**.
6. Attach the new web roll [D] and wind it tight **6**.




★ Important

- Before you re-assemble the machine, make sure there is no slack in the web roll, and confirm that the web is below the feeler of the web end sensor.

7. Attach the upper cover.
8. After installing a new web roll, do SP1902-001 to reset the web count to zero.


Web Motor, Web End Sensor

1. Remove the web unit and end cover [A]. Web Unit Disassembly




2. Remove bracket [A] and web motor positioning bracket [B]

3. Remove web motor [C]



4. Remove web motor/sensor mount [A].

5. Disconnect web end sensor [B].



Reinstallation

1. Set the motor in its bracket with the red dot facing toward the front end of the fusing unit.




d223c3342

2. Make sure that the harness of the web driver motor is not pinched by the fusing inner cover

Pressure Roller Cleaning Unit, Cleaning Rollers


Pressure Roller Cleaning Unit

1. Remove the fusing unit. Fusing Unit Removal
2. Remove cover [A] (🔑 x 1)
3. Cleaning roller assembly [B] (🔑 x 1)



Pressure Roller Cleaning Roller (D223/D224)

1. Remove the pressure roller cleaning unit. page 707
2. Disconnect the springs [A] on each end of the roller shaft [B].




3. Separate the roller and bracket.



Pressure Roller Cleaning Roller (D225)

1. Remove the pressure roller cleaning unit. page 707
2. Remove a screw on one end of the roller.




3. Disconnect roller from its bracket.



Re-assembly

1. When attaching the lower cover of the pressure roller cleaning roller, make sure that the tab engages with the groove.



d223c3345

4

2. If the bushings are noisy after replacement, lubricate them on both ends and the holes where the bushings are attached with Barrierta Grease S522R.


Fusing Lamps, Hot Roller, and Pressure Roller

Note

- If you wish to remove the pressure roller only, without removing the hot roller and fusing lamps, please do not use this procedure. Use the procedure in the next section.

Fusing Lamps (x3) D223, D224


1. Remove the fusing unit. page 688
2. Remove harness cover [A].



 x3


d223d4513

3. Remove top cover [A].



d224c0989


1. At the rear, open the metal clamp, and then disconnect the harnesses.



x4

d223d4514

2. Remove top cover plate [A] of the drawer connector.




 x1

d223d4515

4


3. Disconnect bracket connector, and then remove screw.



 x1  x1


d223d4516

4. Unhook and then remove bracket [A].




d223c3351

5. Disconnect lamp harnesses [A] (Blue) and [B] (Green) from the back of the drawer connector.

 x2


d223d4517

6. Open the bracket and then pull it away from the fusing unit.



d223d4518



7. Remove lamp holder [A], and then slowly pull the lamps out of the fusing unit.



 x1

d223d4519

8. Disconnect the connector cover at the front.




⚙️ x1

d223c3325

4


9. Disconnect the fusing lamps at the front.




📦 x3

d223d4534

10. Remove the fusing lamp holder from the front.




11. Slowly, remove the fusing lamps.



Re-assembly

Each fusing lamp is rated for a different voltage and must be re-installed at its original location.

- The rear lamp connectors are color coded (White, Green, Blue).
- The rear lamp bracket is embossed with the letters W, G, B show your where each lamp with its White, Green, or Blue connector should be installed.
- The front lamp bracket is also embossed with these letters, but the front connectors are all white.
- Use the rear lamp bracket as a guide for re-installing the lamps correctly.




b140r205

Fusing Lamps (x2) D225

4


1. Remove the fusing unit Fusing Unit Removal
2. In order to disconnect the fusing lamps, you must first remove the terminal plate on the rear end of the fusing unit.




d223c3346

3. At the rear [A] open the metal clamps to free the harnesses and then remove the screw at the top of the bracket.
4. Disconnect both harnesses [B].

4



 x1  x3




 x2

d223c3347

5. At the lower rear corner, disconnect the harness, and then remove the bracket screw.




d223c3348




 x2  x1  x1

6. Remove the cover plate.





x1



d223c3349


7. Fusing lamp harnesses are blocking removal of bracket [A] so push them aside [B].

4




d223c3350

8. At the lower left, lift the bracket [A] and pull it away from the rear of the fusing unit.



d223c3351


9. Disconnect the fusing lamps.



 x6

d223c3352


10. Lay the terminal bracket aside on a flat, clean surface.



d223c3353

11. Remove the rear fusing lamp holder.


4



 x1

d223c3324


12. At the front, remove the plate.



 x1

d223c3325


13. Disconnect two harnesses.



 x1

d223c3326


14. Remove front fusing holder.



 x1

d223c3327

15. Remove the two fusing lamps.



 x1

d223c3328

Note

- Never touch the surface of a fusing lamp with bare hands.
- The fusing lamps are fragile so handle them with care.

Re-assembly

Each fusing lamp is rated for a different voltage and must be re-installed at its original location.


- The rear lamp connectors are color coded.
- The rear lamp bracket is embossed with the letters G, B show you where each lamp with its Green, or Blue connector should be installed.
- The front lamp bracket is also embossed with these letters, but the front connectors are all white.
- Use the rear lamp bracket as a guide for re-installing the lamps correctly.

4

Hot Roller, Pressure Roller


Do this procedure when you want to remove both rollers.

1. Remove the web unit Web Cleaning Roller
2. Insert the tips of two screwdrivers and press down to release the pressure arm.




d224c1008

3. Disassemble:
 - [A] C-clamps (both ends)
 - [B] Drive gear
 - [C] Bushings front and rear
 - [D] Bearings front and rear
4. Remove hot roller [E]



d224c1009

5. Disconnect entrance guide plate [A].
6. Remove pressure roller [B].




d224c1010

Note

- The pressure roller and pressure roller bearing should always be replaced together.

7. Lubricate the inner and outer surfaces of the bushings with Barrierta S552R.



d224c1011

4


Note

- If the bushings are warm, allow them to cool before applying the Barrierta grease. Applying the grease while the bushings are hot could generate gas.

Pressure Roller Only

Do this procedure if you need to remove only the pressure roller.

1. Remove the fusing unit. Fusing Unit Removal
2. Turn the fusing unit upside down.
3. Remove lower cover [A].
4. Remove pressure roller cleaning unit [B].
5. Release the pressure arms [C]
6. Use two screwdrivers to lower the pressure arms on both ends of the pressure roller.
7. Remove pressure roller springs [D]
8. Finally, remove pressure roller [E]



★ Important

- The fusing lamps are fragile. Work carefully to avoid breaking them.
- During assembly, handle the roller carefully to avoid scratching it on the bracket.
- Make sure the tabs and grooves of the lower cover are engaged correctly before tightening the screw.

Checking the Fusing Nip

There are two ways to check the width of the nip between the pressure roller and hot roller.

Method 1

1. Open SP1109-001, set it to "1".
2. Click the button in the upper right corner of the screen to switch from the SP Screen to the Copy Screen.
3. Make a copy. The sheet of paper will stop in the nip of the pressure roller and hot roller for the prescribed time, and then exit.
4. Measure the width of the nip.

Method 1

1. Open SP1109-01 and set it to "1".
2. Open SP2902 and select the Black Band Test Pattern.

3. Click the button in the upper right corner of the screen to switch from the SP Screen to the Copy Screen.
4. Make a copy and then measure the width of the nip.


↓ Note

- The optimum width for the D223/D224 is 5.5 ± 0.5 mm
- The optimum width for the D225 is 7.5 ± 0.5 mm.

Manual Nip Adjustment

The size of the nip is adjusted by increasing or decreasing the amount of pressure exerted by the pressure roller on the hot roller.


- When fusing is performed poorly, you can adjust the nip width [A].
- Two holes are provided on each pressure arm for the springs [B]. Normally the springs should be attached to the lower holes.
- Attaching the springs to the upper holes exerts less pressure on the hot roller. Attach the springs to the upper holes only for especially thin paper, or when fusing is performing poorly (wrinkling, excessive curl, etc.)



Stripper Pawls


1. Remove the fusing unit. Fusing Unit Removal
2. Remove top cover [A].
3. Remove bracket [B].

4



d224c1017

4. Stripper pawl [A].




d224c1019

Nip Band Width Adjustment

1. After the machine is turned on, make an A4/LT LEF copy, then stop the machine while the paper is still in the fusing unit by switching the machine off.

Note

- This is easier with an OHP sheet. Use an OHP sheet if you have one available.
2. Open the front door, then turn the fusing knob to feed out the copy.
 3. Measure the width of the band on the part of the image where it is particularly black. The band, called the nip band [A], should be 9.0 ± 0.7 mm at the center.
 - When the fusing is incorrect (wrinkles, offset, curl), measure the nip band width.
 - The nip band width can be adjusted by changing the position of the springs [B] on the ends of the pressure roller.
 - The fusing temperature can also be adjusted with SP1 105 (Fusing Temperature Adjustment) for Normal, OHP, and Thick Paper.




d224c1030

Fusing Unit Exit Sensor

1. Remove the fusing unit. Fusing Unit Removal
2. Open the hot roller stripper pawl unit [A]
3. Remove:
 - [B] Exit guide plate
 - [C] Fusing exit sensor holder
 - [D] Plate spring

[E] Fusing exit sensor




Fusing/Exit Motor

1. Remove rear upper cover Rear Upper Cover
2. Open the IOB Bracket
3. The fusing/exit motor is behind the fusing/exit motor bracket.




d223c3354


4. Disconnect the harnesses in front of the fusing/exit motor bracket.



5. Disconnect the bracket screws at the upper right [A] and lower right [B].




6. Disconnect bracket screw at lower left [A], and then pull the bracket [B] away from the frame.



 X1


d223c3357

7. Move the frame out from behind harnesses [A].
8. Remove the freed frame [B].



d223c3358


9. Free the harness at the upper right corner of the motor bracket [A].



 x1

d223c3790


- 10. Press down pulley arm [A] to release tension on the belt.
- 11. Disconnect drive belt [B] from pulleys.



 X1

d223c3359

- 12. Disconnect ground plate at top and bottom.



13. Remove ground plate and drive belt.

Note

- The top arm of the ground plate bracket has the "U" cutout.




14. Disconnect motor:

[A] Top

[B] Lower right

[C] Lower left




 X3

d223c3363

15. Remove the bracket with motor attached.


16. Lay the bracket and motor on a flat, clean surface.



d223c3364


17. Turn the bracket over.

18. Remove the screws, and then separate the bracket and motor.




Fusing Exit Sensor, Exit Unit Entrance Sensors

1. Open the front door and pull out the exit/inverter unit.
2. Disconnect fusing exit sensor bracket [A].
3. Remove fusing exit sensor [B].
4. Disconnect exit unit entrance sensor bracket [C].
5. Remove exit unit entrance sensor [D].




Turn Sensor

1. Remove the fusing unit cover. page 688
2. The sensor is on the left front corner of the fusing unit tray.




3. Disconnect and free harnesses [A].

4. Disconnect sensor bracket [B].




 x4  x2



 x1

d223c3367


5. Remove bracket with sensor attached, and then disconnect sensor.



 x1

d223c3368

6. Separate sensor from bracket.




✚ x4

d223c3369

4

Fusing Pressure Release Sensor


1. Remove the fusing unit. page 688
2. Remove fusing pressure release sensor bracket [A]



✚ x2

d223d4520

3. Separate bracket and sensor.




▶ x4

d223d4521

4

Fusing Pressure Motor


1. Remove the fusing unit. page 688
2. Remove fusing pressure motor cover [A].



⚙ x1

d223d4522

3. Remove fusing pressure motor [A].



 x2

d223d4523

4


4. Lay the motor on a flat, clean surface.



d223d4524

Temperature Sensor

1. Open the front door.
2. Move the toner bottle holder to the right.
3. Remove the inner cover next to the power switch.




🔧 x2 ▼ x1

d223c3651

4


4. Disconnect the sensor harness and sensor bracket.



🔧 x2 📡 x1 🔧 x1


d223c3652

5. Remove the sensor bracket with sensor attached.



d223c3653

6. Separate the sensor and bracket.



 x1

d223c3654

Important SP Codes: Fusing Unit

Here is a list of SP codes related to testing and servicing the fusing unit.


Item	SP No.	Function
Fusing idling on/off	1907	This SP switches pre-fusing idling on/off. Pre-fusing idling can be switched on and adjusted for heavier, thick paper to improve fusing.
Fusing idling time	1103	Adjusts the length of time the hot roller is allowed to idle in order to raise the fusing temperature.
Fusing jam SC settings	1159	This SP determines what the machine does when paper jams occur three consecutive times in the fusing unit. (A jam alert is shown on the screen, and the operator can remove the jam, the machine issues SC559, the machine stops and cannot be used until the CE corrects the problem.
Fusing temperature adjustment	1105	Adjust temperature for Normal, OHP, Thick Paper
Fusing temperature display	1106	Displays the fusing temperature at the center and end of the hot roller, and temperature of the pressure roller.

Item	SP No.	Function
Nip band measuring	1109-001	Open SP1109-001, set it to "1". Click the button in the upper right corner of the screen to switch from the SP Screen to the Copy Screen. Make a copy. The sheet of paper will stop in the nip of the pressure roller and hot roller for the prescribed time, and then exit. Measure the width of the nip.
Web count	1902-001	After the web has been replaced, this SP code must be reset to zero.

Duplex Unit

Duplex Unit Removal

1. Open the front door and pull out the duplex unit.
2. Remove the slide rail roller on the left [A] and on the right [B].
3. Lift out the duplex unit [C].



d224c1036

Re-installation

To re-install the duplex unit:


1. Insert the duplex unit partially, only until it enters the black guide rail, and then re-attach each slide rail roller.
2. Next, push the duplex unit into the machine completely. This method prevents interference from the guide plate.

Adjustments

Duplex Unit Side-to-Side Adjustment

1. Remove the duplex unit front cover screws [A].
2. Pull the cover away partially, disconnect the LED sensor connector [B], and then remove the cover.

3. Move the handle lock screw [C] from the right to the center.
4. Loosen the left lock screw [D], then adjust the position of the duplex unit.




Jogger Fence Adjustment

SP1008	Duplex Fence Adjustment
	<p>Execute this SP to adjust the distance between the jogger fences.</p> <p>A smaller value shortens the distance. If the fences are too far apart, skewing may occur in the duplex tray. If the fences are too close, the paper may be creased in the duplex unit.</p>


Duplex Motors

Duplex Unit Front Cover

1. Remove the duplex unit front cover screws [A].
2. Pull the cover away partially, disconnect the LED sensor connector [B], and then remove the cover.



There are three motors in the duplex unit.




d223c3370


1	Duplex inverter motor
2	Duplex Jogger motor
3	Duplex Transport motor

Duplex Inverter Motor


1. Open the front door, and then pull out the duplex unit.
2. Remove the duplex unit front cover. page 747
3. Disconnect the duplex inverter motor bracket.



4. Unhook the motor bracket [A], and then remove the bracket with motor attached [B].



5. Remove screws at [A] and [B].



 X2

d223c3374


6. Separate motor and bracket.



d223c3375

Re-assembly


1. Reattach the timing belt to the smaller gear marked with the green dot.



d223c3376

4


2. After re-attaching the motor, turn the motor gears [A] manually, and confirm that all the gears on the right [B] are turning.




d223c3377

Duplex Jogger Motor

1. Open the front door, and then pull out the duplex unit.
2. Remove the duplex unit front cover. page 747
3. Free and raise harness [A] in front of the motor bracket.
4. Disconnect jogger motor [B].




 x2




 x1

d223c3417

5. Open clamp [A] at right rear of bracket.
6. Open clamp [B] on left side of bracket.




 x1



 x1

d223c3418


7. Disconnect transport motor [A] on the right.
8. Clear freed harnesses around jogger motor [B].



 x1

d223c3419

9. Disconnect jogger motor bracket.



 x3

d223c3420


10. Remove bracket with motor attached.

4



d223c3421

11. Separate motor and bracket.




 x2

d223c3422


Duplex Transport Motor

1. Open the front door, and then pull out the duplex unit.
2. Remove the duplex unit front cover. page 747
3. Disconnect motor.



d223c3380


4. Disconnect motor bracket: [A] top, [B] lower right, [C] lower left.



X3

d223c3381

5. Remove bracket [A] with motor attached.
 6. Lay the bracket and motor [B] on a flat, clean surface.




d223c3382

7. Re-install and remove the motor with bracket attached. There is no need to separate motor and bracket.

Duplex Sensors


Jogger Fence HP Sensor

1. Disconnect duplex unit release lever [A].
2. Remove jogger HP sensor [B].



Duplex Entrance Sensor

1. Disconnect bracket [A]
2. Remove duplex entrance sensor [B].




Duplex Transport Sensor 3

1. Disassemble right half of table [A].


★ Important

- The front screw is a shoulder screw.
2. Remove screw [B] to release the sensor bracket below.
 3. Remove transport sensor 3 [C].




Inverter Exit Sensor, Transport Sensors 1, 2

1. Remove cross-stay [A].
2. Remove reverse trigger roller shaft [B].



d224c1046




3. Disconnect jogger fences [A].
4. Disassemble left half of table [B].

★ Important

- The front screw is a shoulder screw.
- To avoid breaking the tabs under the left edge of the table, pull the table to the right to disengage the tabs before you remove it.

5. Remove:
 - [C] Inverter exit sensor
 - [D] Transport sensor 1
 - [E] Transport sensor 2




Duplex Jogger Belt Adjustment

1. Remove cross stay Inverter. (See previous section.)
2. Remove reverse trigger roller shaft Inverter. (See previous section.)
3. Remove the left half of the table and the jogger motor bracket.
 - Slip the one end of the belt around the gear below the jogger motor.
 - Slip the other end of the belt around the gear at the other side of the duplex unit.
4. If you are replacing the belt, set both jogger fence brackets at the center of the belt and tighten the screw [A].

-or-

If you are adjusting the belt, loosen the screw and slide the plastic piece [B] on the belt to the left or right to adjust the position of the front fence, then tighten the screw.



d224c1049

4

Important SP Codes: Duplex Unit

Here is a list of SP codes related to testing and servicing the duplex unit.


Item	SP No.	Function
Duplex fence adjustment	1008	Adjusts the distance between the jogger fences in the duplexer. A smaller value shortens the distance. If the fences are too far apart, skewing may occur in the duplex tray. If the fences are too close, the paper may be creased in the duplex unit.
Page numbering	5212	Positions horizontally and vertically the page numbers printed on both sides during duplexing.

Paper Feed Units


Paper Trays

Tandem Tray


1. Open the front door.
2. Pull out the Tray 1 [A] completely to separate the left [B] and right [C] sides of the tandem tray.



3. Remove the left tandem tray [A] (⚙️ x 5).




4. Right tandem tray [A].



Re-assembly


When re-installing the right tandem tray:

1. Make sure that the wheels [A] ride on the slide rail [B].
2. Make sure that the tandem tray stopper [C] is set behind the stopper [D] on the frame.




Universal Trays

1. Pull out Tray 2 or Tray 3 [A].
2. Lift the tray [B] out of the drawer.



Rear Fence Return Sensor


1. Turn off the machine.
2. Pull out Tray 1, the tandem feed tray.
3. Remove rear bottom plate [A].
4. Remove return sensor [B].



4


Rear Fence HP Sensor

1. Turn the machine off.
2. Pull out Tray 1, the tandem feed tray.
3. Remove rear bottom plate [A].
4. Remove back fence transport gear [B].
5. Push the back fence [C] to the right.
6. Remove rear HP sensor [D].




Tandem Right Tray Paper Sensor

1. Turn off the machine.
2. Remove the right tandem tray page 762
3. Remove cover [A].
4. Side fences [B].




5. Remove bottom plate [A]
6. Disconnect sensor [B].
7. Remove sensor [C].




Bottom Plate Lift Wire

Before replacing the rear bottom plate lift wire, remove the front bottom plate lift wire. The shaft must be removed to replace the lift wire of the bottom plate.

1. Remove Tray 1, tandem tray. page 762
2. Remove the inner cover [A].



3. Remove the left stay [A].
4. Lift the front bottom plate slightly, and then unhook the wire stoppers [B]
5. Remove:
 - [C] Wire covers
 - [D] Bracket
 - [E] Gear
 - [F] Bottom plate lift wire




Re-assembly

1. Set positioning pin [A] in hole [B].
2. Set projection [C] in hole [D].
3. Position wire [E] as shown.

★ Important

- Do not cross the wires.




d224c1060

Tandem Tray Paper Size Change

At the factory, this tray is set up for A4 or LT LEF. Only A4 or LT LEF paper can be used for tandem feed.


1. Open the front cover.
2. Pull out the Tray 1 [A] completely to separate the left [B] and right [C] sides of the tandem tray.




3. Remove the right tandem cover [A].
4. Re-position the side fences [B].

Note


- The outer slots for A4, the inner slots for LT.



5. Re-install the right tandem inner cover.
6. Remove tray cover [A].
7. Remove the DC motor cover [B].




8. Remove the rear side fence [A].
9. Re-position rear cover [B].



d224c1065

10. Re-position the side fences [A], [B].


- A4: Outer slot position
- LT: Inner slot position



d224c1064

11. Re-install the DC motor cover and tray cover.
12. Remove the rear bottom plate [A].
13. Re-position the return position sensor bracket [B].

- To use the paper tray for A4 size, set the screw in the left hole as shown.
- For LT size, the screw should be placed on the right.




14. Reinstall the rear bottom plate.
15. Enter the new paper size with **SP5959-001** (Paper Size – Tray 1).
16. Do the printer adjustments. page 985

Tandem Tray Side Registration

Normally the side registration of the image can be adjusted in the SP mode.

- If the punch hole positions are not aligned from a particular feed station, however, you can manually adjust the side registration by changing the tray cover position for that tray.
 - Next, you can adjust the side registration of the image. page 985
1. Pull out the tray and remove the right inner cover [A] (⊗ x 2).
 2. Loosen the screws and adjust the position of the plate [B].
 - Adjustment range: 0 ± 2.0 mm adjustment step: 1.0 mm/step





Pick-up, Feed, Separation Roller

1. Remove the tray.
2. Remove the clip for each roller to replace it.

[1] Feed roller

[2] Pick-up roller

[3] Separation roller



d224c0114

↓ Note

- The same FRR mechanism is used in all the trays, so the rollers are interchangeable between the trays.
- Avoid touching the surface of new rollers during replacement.

Paper Tray Lift Motors, Tray 1 Lock Solenoids

Tray Motor, Solenoid Access

1. Turn the machine off and disconnect it from its power source.
2. Remove the rear upper and lower covers. page 482
3. Open the controller box. page 490

↓ Note


- The tray motors and solenoids are located behind the plate where the RYB, PSU, and AC drive board are mounted.



d223c3716

⚠ CAUTION


- While you are doing the procedures below, never touch any component on the PSU, especially a heat sink.
 - These heat sinks are live and labeled with warnings not to touch them.
 - These heat sinks can retain a considerable electrical charge for hours after the machine has been turned off and unplugged.
4. As a safety precaution, disconnect the power cord from the main machine.




 x1

d223c3717

5. Disconnect the left rear corner plate.




6. Pull the plate away from the corner of the machine. Do not remove it.




d223c3719

7. Disconnect all harnesses from the RYB, and then open the clamps above the RYB to free the harnesses.



d223c3720

8. Check the insulated harness on the right side of the RYB [A] and confirm that it is disconnected and free.



d223c3721


4

- 9. At the top of the AC drive board, open the clamp and free the large harnesses.




d223c3744

- 10. Near the left edge of the RYB, disconnect the harness guide bracket [A] by removing screws [1], [2], [3], and edge clamp [4].
- 11. Push the guide bracket and harnesses [B] to the left away from the board.




4

12. Disconnect the mounting plate at on the left side of the RYB [1], on the right side of the RYB [2], and near the lower right corner of the AC drive board [3].



13. Continue to disconnect the mounting plate near fan [1] and then fan [2].




14. Slowly, disconnect the left edge of the mounting plate [A], and then swing it open [B].



d223c3725

4

15. With the mounting plate open, you can see the hidden components.



d223c3726

1	Tray 1 Lift Motor
2	Tray 2 Lift Motor
3	Tray 3 Lift Motor
4	Right Tray Lock Solenoid (in Tray 1)
5	Left Tray Lock Solenoid (in Tray 1)

Note

- Before you service any of these components, be sure to open the trays at the front so the motor drives and solenoid arms are disengaged.




d223c3727

4

Tray 1 Lift Motor

1. Open the board mounting plate. page 775
2. Disconnect the motor bracket.



d223c3728


3. Unhook the motor and remove it.



d223c3729


Tray 2 Lift Motor

1. Open the board mounting plate. page 775
2. Disconnect the motor bracket.



d223c3730

3. Unhook the motor and remove it.




d223c3731

4


Tray 3 Lift Motor

1. Open the board mounting plate. page 775
2. Disconnect the motor bracket.



d223c3732

3. Unhook the motor and remove it.






d223c3733

4

Right Tray Lock Solenoid



1. Open the board mounting plate. page 775
2. The right tray lock solenoid locks the right half of the tandem tray (Tray 1) during machine operation. It is located above Tray 2 lift motor [A].
3. Disconnect the solenoid.



 x1  x1

d223c3734



4. Unhook the solenoid from the frame, and then lay it on a flat, clean surface.
5. Disconnect the spring.



 x1

d223c3735



6. Disconnect the extension arm.



 x1

d223c3736

7. Disconnect and then remove the mounting plate.




 x2



d223c3737

Left Tray Lock Solenoid

1. Open the board mounting plate. page 775
2. The left tray lock solenoid locks the left half of the tandem tray (Tray 1) during machine operation. It is located to the right of the right tray lock solenoid.
3. Disconnect the solenoid.

4



 x1  x1

d223c3738


4. Lay the solenoid on a flat, clean surface, and then remove the extension arm.



 x1  x1  x1

d223c3739


5. Disconnect and then remove the mounting plate.



Paper Feed Unit Removal

There are three paper feed units, one for each tray.

1. Take off the front door. page 477
2. Remove the right covers. page 478
3. If the LCIT is connected, disconnect it and pull it away from the machine.
4. Pull out all three trays completely but do not remove them.
5. Pull peg [A] and remove toner bottle [B] with its base.




6. Open the vertical transport guide.



d223c3385

4

- 7. Disconnect vertical cover [A].
- 8. Pull it away slightly, and then disconnect the LED harness [B].



d223c3386

 x2  x1

- 9. At the rear, disconnect the fan harness at the rear right corner of the vertical transport guide plate.



 x1

d223c3387

4

10. Lift the vertical guide to disconnect it, and then pull it out of the machine.



d223c3388


Tray 1 PFU

Note

- This procedure is for Tray 1 only. If you are servicing Tray 2 or Tray 3, just go to the next section below.

There is a guide plate above the PFU of Tray 1 that must be removed before you can remove the Tray 1 PFU.


1. At the front [A] remove the guide plate screw.
2. Swing the front of the plate [B] slightly to the right.



 x1

d223c3389

3. Disconnect the rear end of the machine, and then pull it out.




d223c3390

Tray 1, 2, 3 PFU

The remaining steps for PFU removal are basically the same for all PFUs. Each PFU has three connectors and one lock screw at the front.

1. Free the harnesses in front of the PFU that you want to remove.
2. Disconnect the PFU.




 x2  x2

d223c3391

4


3. Remove the lock screw.
4. Remove the PFU through the side of the machine.



 x1

d223c3392

5. Lay the PFU on a flat, clean surface.




d223c3393

Paper Feed Motors

One paper feed motor is encased in each PFU unit.


1. Remove the feed unit, and then lay it on a flat, clean surface. Feed Unit Removal
2. Disconnect the corner bracket [A].
3. Remove the ground plate [B].




★ Important

- The lowest screw [1] is a machine screw. The other two screws are tapping screws.

4. Disconnect the motor.



5. Disconnect the motor cover plate at the front [A] and at the rear [B].




4

 x1

 x1


d223c3396



1. Remove the motor bracket [A] with motor attached.
2. Lay the motor and bracket [B] on a clean, flat surface.



d223c3397

3. Disconnect the bracket [A], and then separate motor and bracket [B].




 x2  x1

d223c3398

4. Disconnect the motor from the second bracket.



 x2



d223c3399


5. Remove the motor.



d223c3400

Relay Motor

1. Take off the front door. page 477
2. Remove the right covers. page 478
3. If the LCIT is connected, disconnect it and pull it away from the machine.
4. Pull out all three trays completely but do not remove them.
5. Pull peg [A] and remove toner bottle [B] with its base.




6. Open the vertical transport guide.



7. Disconnect vertical cover [A].

8. Pull it away slightly, and then disconnect the LED harness [B].



 x2  x1

d223c3386

9. At the rear, disconnect the fan harness at the rear right corner of the vertical transport guide plate.



 x1

d223c3387

10. Lift the vertical guide to disconnect it, and then pull it out of the machine.

4




d223c3388

11. Locate the relay motor unit [1] directly below PFU 1 [2].




d223c3785

12. Disconnect the front end of the relay motor unit plate.



d223c3786


13. Remove the unit and lay it on a flat, clean surface.



d223c3787

14. Disconnect the motor from bracket [A].

15. Disconnect motor [B].




x2

x1 x1

d223c3788

16. Connect the motor [A] before you re-attach it to the bracket with screws.




4

Separation Roller Pressure Adjustment

The position of the drive gear for the separation roller can be changed to adjust the amount of pressure exerted by the separation roller. This adjustment can be done:

- When feeding special paper (thick paper)
 - When the customer is experiencing feed problems
1. Remove the feed unit where you want to do the adjustment. page 787
 2. Loosen the hex screw [A].
 3. The separation roller gear [B] is positioned at the groove before shipping.




d224c1079

4. To adjust for thick paper, move the separation roller gear to the left to decrease the pressure.
-or-
To correct misfeeds, move the separation roller gear to the right to increase the pressure.


Lift Sensor, Paper End Sensor

1. Remove the PFU. page 787
2. Locate the lift sensor [A] and paper end sensor [B].



d223d4701


3. Remove separation roller [A].
4. Remove torque limiter [B].



 x1

d623z0001


5. Remove lift sensor, paper end sensor bracket [A] with sensors attached.



 x1  x1  x2

d623z0002a



6. Remove lift sensor [A], paper end sensor [B] from the bracket.



d223d4702


Feed Sensor, Vertical Transport Sensor

1. Remove the PFU. page 787
2. Locate the feed sensor [A] and vertical transport sensor [B].



d223d4703

1. Open the two clamps on the back of the feed unit, free the harness, and then remove gear cover [A].




 x2  x2

d223d4704

2. Remove top cover [A] from the PFU.

 **Note**

- The blue-circled screws in the photo are tapping screws.




 x5  x2

d223d4705

- Open clamp [A], free the harness, separate the top of the PFU, and then lay the separated parts on a flat, clean surface.


Note

- You do not need to disconnect the harness.



d223d4706

- Remove feed sensor bracket [A].



 x1  x1

d223d4707

- Remove feed sensor from the bracket.




▼ x4

d223d4708

6. Remove vertical transport sensor [A].

4





🔧 x1 🛠️ x1

▼ x4

d223d4709


Pick-up Solenoid

1. Remove the PFU. page 787
2. Remove the top cover of the PFU.
3. Locate the pick-up solenoid [A].




d223d4710

1. Disconnect springs [A], [B].




Note

- The longer spring [A] is the rear spring and must be re-attached at the same location.




d223d4712

2. At the rear end of the PFU, remove gear [A] and gear shaft [B].




 x2  x1 d223d4713

3. Remove feed roller [A] and feed roller collar [B].




 x1  x1  x1 d223d4714

4. Remove feed roller shaft assembly [A].




d223d4715



d223d4716


5. Turn the PFU 90 degrees, and then remove solenoid screws at the back.



 x2

d223d4717


6. Remove spring [A], and then disconnect the harness.



 x1  x1  x1


d223d4719

7. Remove pick-up solenoid [A] at its back end, pull out the plunger, and then remove the solenoid.




d223d4718

8. Disconnect the plunger at each arm [A].



d223d4720


9. Lay the parts on a flat, clean surface.



d223d4721

Re-assembly

1. Make sure that the connector is inside sheet [A] so it cannot interfere with other parts.




d223d4722

Reverse Release Solenoid

1. Remove the PFU. page 787
2. Remove the top cover of the PFU.
3. Locate the reverse release solenoid [A].


- 4. Remove lift sensor, paper end sensor bracket.
- 1. Remove gear cover [A] from the rear end of the PFU.



 x2  x3

d623z0003


- 2. Remove timing belt [A].



 x1

d623z0007


- 3. Push in coupling [A] to detach the e-ring, and then remove the coupling.



 x1

d623z0004

4. Use a small, precision screwdriver to release the tab, and then remove coupling [A] to the outside.




▼ x1

d623z0005

4


5. Remove gears [A], [B], [C].



▧ x1

d623z0006


6. Remove gears [A], [B], [C], [D].



🌀 x3

d623z0008


7. Remove bracket [A].



 x6  x1  x1 d623z0009

4


8. Disconnect reverse release solenoid bracket [A] and then remove it with solenoid attached.



 x3  x2  x2


d623z0010

9. Remove reverse release solenoid [A] from the bracket.




Relay Sensor

1. Remove the right upper cover. Right Upper Cover.
2. Disconnect relay sensor bracket [A].
3. Remove relay sensor [B].



Registration Motor


1. Remove the rear upper and lower covers. page 482
2. Remove the controller box. page 490
3. Remove the flywheel.



4. Disconnect the motor and motor bracket.

Note


- The bracket screws to be removed have hex-heads, not round heads.



5. Unhook the bracket with motor attached, and then lay it on a flat, clean surface.



6. Disconnect motor bracket [A].
7. Raise the bracket and motor [B], and then disconnect the drive belt.



4

8. Disconnect the motor.



d223c3714

9. Separate motor and bracket.



d223c3715

4

By-Pass Tray

By-Pass Tray Removal


The by-pass paper size detection board and paper length sensor (photosensor) are inside the by-pass tray.

1. Remove the bypass tray cover.


 x2


d223c3401

2. Disconnect the ground wire.


 x1  x1

d223c3402

- Free the harnesses at [A] and [B].




 x1

 x2

d223c3403

- Disconnect the bypass tray on the front side [A].
- Disconnect the tray on the rear side [B], and then remove the tray.



d223c3404

- Lay the removed tray on a flat, clean surface.



d223c3405

7. When you re-install the tray, tuck the harnesses into the corner slot of the bypass tray before you re-install it.



d223c3406

By-Pass Tray Disassembly

1. Remove the By-Pass Tray. By-Pass Tray Removal
2. Disconnect the two halves of the tray.




 x2

d223c3407

3. Push the top away from the bottom to separate the two halves of the tray.

4



d223c3408

4. Separate the top and bottom of the tray.




d223c3409

By-Pass Paper Size Detection Board

1. Remove the By-Pass Tray. page 819
2. Disassemble the By-Pass Tray. page 821
3. Disconnect the two halves of the tray.

- 4. Disconnect the paper size detection board




 x1

d223c3410


4

- 5. Carefully, detach the board from the tray.



d223c3411

- 6. Lay the board on a flat, clean surface.



d223c3412

Re-assembly


Go into the SP mode and do SP1904 to calibrate the maximum and minimum paper sizes for the side fences:

1. **SP1904-001** By-pass Tray Paper Size Detection – Minimum Size: Move the side fences to the minimum size, then execute this SP.
2. **SP1904-002** By-pass Tray Paper Size Detection – Maximum Size: Move the side fences to the maximum size, then execute this SP.

By-Pass Paper Length Sensor

4


1. Remove the By-Pass Tray. page 819
2. Disassemble the By-Pass Tray. page 821
3. Free the sensor harness.



▼ x3

d223c3423

4. Remove the tray extension [A] from the by-pass tray.




d223c3424

5. Disassemble the tray extension.


 x2


d223c3425

6. Free the sensor harness.




d223c3426

7. Turn the tray over, and then remove sensor cover [A].
8. Disconnect the sensor hooks [B].




9. Disconnect sensor.

4



Re-assembly

1. Before you re-assemble the tray extension, make sure that he sensor harness is fixed securely at the notches.



d223c3429

4

By-Pass Tray Rollers

1. Remove right covers. page 478
2. Remove the By-Pass Tray page 819
3. Disconnect the by-pass cover [A]


 x2


d223c3413

4. Remove the by-pass cover.



d223c3414

5. With the cover removed, you can access the rollers.



d223c3415

4

[1]	Pick-up roller
[2]	Feed roller
[3]	Separation (reverse) roller


6. Remove each roller and replace it.

★ Important

- During replacement, try to avoid touching the surfaces of the rollers with bare hands.



d223c3416




↓ Note

- The FRR mechanisms for Tray 1 (tandem tray), Tray 2, Tray 3 (universal trays), By-Pass Tray, and ADF are similar, but the rollers are interchangeable only between Trays 1,2,3 (not By-Pass, ADF).

By-Pass Separation Roller Pressure Adjustment

The position of the drive gear of the separation roller can be changed to adjust the amount of pressure exerted by the separation roller. This adjustment can be done:

- When feeding special paper, especially thick paper
 - When the customer experiences feed problems
1. Use an Allen key to loosen the separation roller gear [A].




↓ Note

- The separation roller gear is positioned at the groove before shipping.
2. Loosen and move the separation roller gear to adjust pressure.
 - Move left to lessen pressure and correct double feeding.
 - Move right to increase pressure and correct failure to feed.

Registration Sensor


1. Remove cover [A] (⊗ x 4)



2. Remove these components'

- Development unit page 623
- Charge corona unit page 574
- OPC drum unit page 582

3. Remove paper dust collection unit [A] (🔩 x 1, 📦 x 1)



d224c1095


4. Separate the unit.



d223c3500


5. Turn the top over and note the position of the mylar over the registration sensor. The mylar must remain on top of the sensor as shown.


4



d223c3501


6. Disconnect sensor and harness from the unit.



 x2 **1**x4

d223c3502

7. Disconnect sensor.



 x1

d223c3503

By-Pass Unit

By-Pass Unit Removal


★ Important

- Work carefully to avoid catching any harnesses on the unit while removing and re-installing it.

Preparation

- Remove the front door. page 477
- Remove the development unit. page 623
- Remove by-pass tray. page 819
- Remove right upper cover. page 478
- Remove rear covers. page 482
- Open the controller box. page 490

1. Remove inner cover C2.




 x4
  x1

d223c3430

2. Disconnect the cover LED.


4



 x1  x1

d223c3783


3. Disconnect the harnesses at the front right corner.
4. Note the color sequence of the connectors at [A] ([1] Blue, [2] Black, [3] White).



 x3  x4


d223c3431

5. At the right front corner, pull the harnesses [A] through the frame so they will not block removal of the bypass unit.




d223c3432

6. At the right rear corner [A], disconnect the large connectors.
7. Below the position where you just removed the large connectors, remove the two harnesses with the small connectors [B].




x2



x2


d223c3433

8. Pull the loose harnesses away from rear corner of the machine so they cannot interfere with removal of the bypass unit.




d223c3434

9. The used toner pump tube assembly and drive rod [A] block the access to the bypass unit motor and sensor connectors [B].




d223c3435

10. Disconnect top of used toner pump assembly [A].




d223c3296


11. Pull out the stopper on the tube base [A].



12. Pull the bottom of the tube [A] up, and then remove the tube pump assembly [B].



13. Disconnect the bypass motor and sensors.



14. On the right side of the machine, disconnect the frame of the bypass unit.




d223c3437

 x4

4

15. Pull the duplex unit [A] out of the machine far enough so you can see the pin [B] disengage from the frame of the duplex unit (about 10 cm or 4 in.)




d223c3438

★ Important

- If the duplex unit remains closed, you cannot remove or re-install the bypass unit. The duplex unit must be pulled out so the pin is free before you can remove the unit or re-install it.


16. Slowly, pull the bypass unit [A] straight out until it stops.
17. Lift and twist the left side of the unit [B] until the three shafts clear the post, and then remove the unit.



d223c3784

18. Set the unit on a flat, clean surface.

4




d223c3504

Re-installation

1. Pull out the duplex unit [A] before you re-install the bypass unit, and then confirm that pin [B] is out of its hole.

★ Important

- If the duplex unit is in the machine, you will not be able to re-install the bypass unit. Make sure the duplex unit is pulled out completely.



d223c3438

4

2. After you have re-installed the bypass unit and re-connected the motor and sensors, check this sensor to the right and make sure that it is securely connected.




d223c3440

3. Work carefully to avoid catching any harnesses on the unit while moving it.
4. After re-installing the bypass unit, make sure no harnesses are pinched between the bypass unit and the frame.


By-Pass Motor

1. Remove the by-pass unit. By-pass Unit Removal
2. The by-pass motor is on the back of the by-pass unit.



d223c3505

3. Unfasten the motor bracket.



 x2



 x1

d223c3506


4. Loosen the tension screw to create some slack in the drive belt.

4




d223c3507

5. Remove the bracket with motor attached, and then disconnect the motor from the bracket.




 x1



 x2

d223c3508

6. Separate the motor and drive belt.




 x1

d223c3509

4


7. After you re-install the motor, move the tension screw to put more tension on the belt, and then tighten the screw.



d223c3510

Guide Plate Sensor


1. Remove the by-pass unit. By-pass Unit Removal
2. The guide plate sensor is on the inside of the rear plate.



d223c3511


4

- 3. On the other side of the plate, raise the guide plate away from the sensor.



d223c3512

- 4. Free the harness [A].
- 5. Unfasten the sensor [B].



 x2

 x4

d223c3513

- 6. Disconnect sensor and harness.



x1


d223c3514

Paper Path LEDs

LED Locations

4

The paper feed path LEDs are mounted inside the inner covers on the front of the main machine. An LED lights when a paper jam occurs at that location.




d223c3655

No.	Name
1	Jam LED A
2	Jam LED B1
3	Jam LED B2

No.	Name
4	Jam LED C2
5	Jam LED C1
6	Jam LED D1/E1
7	Jam LED D2/D3
8	Jam LED E2/Z


4

Each LED assembly is comprised of a plate held by one screw [1], an easily detachable lens [2], a small harness and connector [3] and the LED [4].




Jam LED A: Vertical Inner Cover

1. Open the front door.
2. Pull out the trays [A] (do not remove them.)
3. Disconnect the vertical inner cover [B].
4. Pull the cover away slightly [C], and then disconnect harness [D].




5. Lay the inner cover on a flat, clean surface.
6. Remove plate [1], remove LED and lens, and then disconnect the LED [2].
7. Separate the LED and lens [3].




Jam LEDs C2, B2, B1

1. Open the front door.
2. Disconnect the inner cover [A].
3. Pull the cover away slightly, and then disconnect harness [B].




4. Lay the inner cover on a flat, clean surface.
5. Remove plate, and then disconnect the LED [1].
6. Separate the LED and lens [2].




Jam LED C1 Inner Cover

1. Open the front door.
2. Disconnect the inner cover [A].
3. Pull the cover away slightly, and then disconnect harness [B].




4. Lay the inner cover on a flat, clean surface.
5. Remove plate, and then disconnect the LED [1].
6. Separate the LED and lens [2].




Jam LED E3/Z: Inverter Duplex Inner Cover

1. Open the front door.
2. Pull out the duplex unit.
3. Disconnect the duplex unit front cover [A].
4. Pull the cover away slightly, and then disconnect harness [B].




4

5. Lay the duplex unit front cover on a flat, clean surface.
6. Remove plate, and then disconnect the LED [1].
7. Separate the LED and lens [2].



Jam LED D1/E1: Fusing Unit Inner Cover


1. Open the front door.
2. Pull out the fusing unit [A].
3. Open the top of the fusing unit [B].



d223c3665


4. Locate the hole [A] in the shaft of the large knob on the front of the fusing unit.
5. If you cannot see the hole, turn the knob until the hole is visible.
6. Insert a small screwdriver [B] into hole to keep the shaft from turning when you remove the large knob.

4




d223c3666

7. Remove large knob [A].
8. Disconnect top left corner [B] of the cover.




4

9. Disconnect right side [A] and left side [B] of the cover.




10. Pull the cover away slightly, and then disconnect harness [A].




d223c3669

11. Lay the cover on a flat, clean surface.
12. Remove plate [1].
13. Disconnect the LED, and then separate the LED and lens [2].



d223c3670


14. Remove plate [1].
15. Disconnect the LED, and then separate the LED and lens [2].



4

Re-assembly

1. Be sure to remove the screwdriver and close the top of the fusing unit before you push the fusing unit into the machine.



d223c3672

Paper Feed Adjustments

Paper Registration

The position of image on paper can be adjusted with SP codes in the main scan and sub scan directions. Before doing any of these adjustments you should always first check the alignment of the laser unit.
page 560

Main Scan (Side-to-Side) Registration

- **SP1002-001 to 007** (Side-to-Side Registration). Use this SP code to correct paper registration problems for each paper feed station (Tray 1, Tray 2, Tray 3, Bypass Tray, LCIT, and Duplex Tray (during duplex printing). These settings correct printing position.
- **SP4011** (Main Scan Registration Adj). This SP adjusts the side-to-side registration for scanning in the main scan direction across the page. [-2.5 to 2.5/0.1 mm]. Setting a negative value shifts the image toward the left edge, and setting a positive value shifts the image toward the right edge.

Sub Scan (Vertical) Registration

This SP codes are used for sub scan adjustments.

- SP1001 (Printer Sub Scan Registration – Main Tray Feed, LCIT Duplex)
- SP1002 (Printer Sub Scan Registration – Thick Paper Main Tray, LCIT Duplex)
- SP1003 (Printer Sub Scan Registration – Bypass)
- SP1004 (Printer Sub Scan Registration – Thick Paper Bypass)
- SP4010 (Scanner Sub Scan Registration)

Buckle Adjustment

During paper feed, the registration roller stops but the paper keeps moving for a very short time so its leading edge can buckle against the roller to correct paper skew. The amount of buckle at the registration roller can be adjusted for special paper.

- Too much buckle can cause the paper to wrinkle, crease, or jam when feeding Z-folded paper because the interval between the sheets is too small.
- Too little buckle can cause lag jams and lead to more skew in the paper path.

SP1003 adjusts the amount of buckled by adjusting the timing of the registration motor (a higher setting creates more buckle).

1. Enter the SP mode.
2. Open SP1003. [0 to 9/0/1 mm]
 - Enter a smaller setting to correct paper wrinkling, creasing, or jams with Z-folded sheets.
 - Enter a larger setting to correct lag jams and skew.

1003	Registration Buckle Adjustment
	Adjusts the registration motor timing. This timing determines the amount of paper buckle at registration. (A higher setting causes more buckling.) [-9 to +9/0/1 mm]
1	Tray LCIT
2	Duplex Tray

1003	Registration Buckle Adjustment
3	By-pass Tray
4	Thick Paper Tray
5	Thick Paper Duplex Tray

Important SP Codes: Paper Feed

Here is a list of SP codes related to testing and servicing paper feed components.

4

Item	SP No.	Function
Image registration: Main scan	4011	Adjusts the side-to-side registration for scanning in the main scan direction across the page. Setting a negative value shifts the image toward the left edge, and setting a positive value shifts the image toward the right edge.
Leading edge registration	1001	Adjusts the printing leading edge registration using the trimming area pattern.
Paper registration	1003	Adjusts the registration motor timing. This timing determines the amount of paper buckle at registration. (A higher setting causes more buckling.) The buckling straightens the paper in the paper path.
Paper registration: Printing	1002-1 to 7	Use this SP to adjust printing side-to-side paper registration for each feed station. These SP's should be adjusted after replacing the laser synchronization detector or the laser optical unit.
Paper size set	5959	The paper sizes must be selected with this SP code for Tray 1 (tandem tray), the LCIT, and Cover Interposer Tray. Tray 2 and Tray 3 can detect their paper sizes automatically with switches.

Item	SP No.	Function
Registration, sub scan	4010	Adjusts the registration of the leading edge for scanning in the sub scan direction.

PCBs, HDD

Before You Begin

Board Locations


The number of boards has been reduced for the machines of this series. These boards have been eliminated:

- IPU (Functions moved to the BICU)
- CTL PSU (Controller PSU)
- CNB
- DRB
- PFB

These boards were not in the previous machines:

- RYB (Relay Board)
- AC drive board
- DHB

Inside the Controller Box




d223c3441

[1]	BICU
[2]	Controller board
[3]	HDD

- The BCU of the previous machines has been renamed "BICU" for these machines.
- In the previous machines the BCU was behind the controller box.

Below the Controller Box




d223c3442

[1]	RYB
[2]	PSU
[3]	AC drive board
[4]	DHB

Behind the Controller Box

The controller box must be opened to access this board.



d223c3443

[1]	IOB
-----	-----


⚠ CAUTION

- Before you touch a board, touch a metal surface to discharge accumulated static from your hands.
- Remove screws carefully so the tip of the screwdriver does not touch any part of the board.
- Handle boards carefully by their edges to avoid sharp edges and points on the backs of the boards.
- To avoid electrical shock, never touch a component on the PSU or AC drive board. Some of these parts retain an electric charge long after the machine has been turned off.

Controller Board Replacement

Before You Begin

- The photo below shows rear of the machine with the controller box cover removed.
- The controller board [A] is on the right, connected to the BICU [B] on the left.
- Each model in this series (D223, D224, D225) has a different controller board.
- If you install the wrong controller board, the machine will return SC955-03. The machine will not operate until the correct controller board has been installed.



d223c3444

Controller Board

1. Remove the rear upper cover. page 482
2. Remove controller box cover plate. page 488
3. If there are any option I/F boards in the controller box remove them.



d223c3446

4. Disconnect the bottom of the controller board.



 x2

d223c3447

5. Unfasten board from the machine.

4



 x7

d223c3448


6. Unfasten the controller faceplate.



 x5


d223c3449

7. Slowly, with one hand on the board and one hand on the faceplate, disconnect the edge connector on the left, remove the board and faceplate together, and then lay them on a flat, clean surface.



d223c3450

8. Remove the port cover [A] of the USB-B port from the controller board guide plate.



4

 x1


d223d4819

9. Separate the controller board and controller board guide plate.



d223d4820

10. Remove both NVRAMs from the old controller board and install them on the new controller board.



d223c3452

★ Important

- The controller board has two NVRAMs, 2M-1 and 2M-2.
- These NVRAMs are always replaced as a set.
- Each NVRAM must be installed at the correct location as shown above.
- If their positions are reversed, this will cause a short circuit and damage the board and NVRAMs.

11. Fasten the controller board guide plate to the controller board.


★ Important

- The plate is soft metal so install it carefully to prevent bending it out of shape.



d223d4821

12. Connect the left edge of the controller board to the right edge of the BICU on the other side of the partition.




d223c3454

Controller Board NVRAM

1. Locate the SMC printout from the factory provided with the main machine.
2. Do **SP5990-001** (All – Data List) to print out all the current machine settings.
3. Turn the machine off.
4. Remove the SD slot cover, insert an SD card into Slot 2 (the lower slot), and then turn the machine on.
5. Do **SP5824** (NVRAM Data Upload) to copy the NVRAM data onto the SD card.
6. Turn the machine off and unplug the machine from the power source.
7. Remove the SD card from SD Card Slot 2.
8. Insert another SD card into SD Card Slot 2, reconnect the machine to the power source, and then turn the machine on.
9. Do **SP5846-051** (UCS Settings) to copy all address book data from NVRAM to the SD card.
10. If the fax option is installed, go into the User Tools and make a note of the following settings:
 - F Code Box List: Fax Initial Setting > Main Setting > F Code Box Setting: List Print > Print

- Special Destination List: Fax Initial Setting > Receive Setting > Special Destination Setting: List Print > Print
- Fax Initial Setting > Receive Settings > Onscreen items and settings
- Fax Initial Setting > Send Settings > Onscreen items and settings

11. Turn the machine off and then disconnect it from its power source.
12. Remove the SD card with the Address Book data from SD Card Slot 2.
13. Remove the controller board and lay it on a flat clean surface.
14. Remove both NVRAMs from the old controller board and replace them with the new NVRAMs.



d223c3452

★ Important

- The controller board has two NVRAMs, 2M-1 and 2M-2.
- These NVRAMs are always replaced as a set.
- Each NVRAM must be installed at the correct location as shown above.
- If their positions are reversed, this will cause a short circuit and damage the board and NVRAMs.

15. Reinstall the controller board in the machine.
16. Reconnect the machine, confirm that there are no SD cards in the machine, and then turn the machine on.

↓ Note

- If the machine issues SC995-02 (CPM Setting Error 2), do not turn the machine off. Ignore this message and continue this procedure.

17. Insert into SD Card Slot 2 the SD card with the NVRAM data that you copied earlier with **SP5824**.
18. Do **SP5825** (NVRAM Data Download) to copy the data from the SD card to the new NVRAM on the controller board.

↓ Note

- The download will take about 2 or 3 min.

- Wait for the message that tells you the download has finished and to cycle the machine off/on, but do not turn the machine off. Touch the Close button.
 - If the machine issues SC870-11 (Address Book Data Error), just ignore this message and continue with this procedure.
19. Turn the machine off, and then remove the SD card from SD Card Slot 2.
 20. Turn the machine on.
 21. Insert into SD Card Slot 2 the SD card with the Address Book data you copied earlier.
 22. Do **SP5846-052** (UCS Settings – Restore Directory Info.) to restore the address data.
 23. Turn the machine off, and then remove the SD card from SD Card Slot 2.
 24. Turn the machine on.
 25. If the Fax unit is installed, do the same settings you performed earlier to confirm that the settings have not changed:
 - F Code Box List: Fax Initial Setting > Main Setting > F Code Box Setting: List Print > Print
 - Special Destination List: Fax Initial Setting > Receive Setting > Special Destination Setting: List Print > Print
 - Fax Initial Setting > Receive Settings > Onscreen items and settings
 - Fax Initial Setting > Send Settings > Onscreen items and settings
 26. Do **SP5990-001** to print another SMC report, compare this printout with the earlier printout to confirm that the settings are the same, and then correct any settings that are different. After NVRAM has been replaced the following counts are reset

Item	Count
Total Count	0
Other Counts	0

27. Cycle the machine off/on.


★ Important

- If either **SP5824 (NVRAM Data Upload)** or **SP5825 (NVRAM Data Download)** fails to execute, you will have to restore the settings manually with the data on the SMC report provided with the machine.
- Re-install the Data Overwrite Security function and HDD Encryption feature.
- If the machine displays “SD cards for restoration required” after the NVRAM has been replaced, then restoration of the Data Encryption key is required.

HDD

HDD Removal

1. Remove the rear upper cover. Rear Upper Cover
2. Remove controller box cover plate. Controller Box Cover Plate
3. The single HDD (320 MB) is located below the controller board [A] on the right.



d223c3455

4. Disconnect the HDD from the controller board.


 x2

d223c3456

5. Unfasten the HDD bracket.

4. Replacement and Adjustment



 x3

d223c3457

6. Unhook the HDD bracket from the machine frame.

4



d223c3458


7. Lay the bracket with HDD attached on a flat, clean surface.



 x2

d223c3459

- Remove the screws from the bracket front [A] and rear [B].



 x4

d223c3460

- Separate the HDD from the bracket.



d223c3461

Re-installation

- Hook the HDD bracket to the frame on the right so the bracket is flat against the frame.

★ Important

- If the bracket is not flat against the frame you will not be able to re-attach the screws.



d223c3462

2. After restoring the machine for normal operation, execute **SP5832-011** (HDD Format – All) to format the hard disk.

After HDD Replacement

Explain to the operator that after a faulty HDD has been replaced the following data is lost and cannot be recovered'

- Document server documents
- Custom-made stamps
- Document server address book.

The address book and document server documents must be input again.

If the customer is using the Data Overwrite Security feature, the DOS function must be set enabled again with **SP5878-001**.

BICU


The BICU is connected to the controller board on the right.



d223c3463

4


1. Remove the rear upper cover. page 482
2. Remove controller box cover plate. page 488
3. Disconnect the top right corner [A] and bottom right corner [B] of the BICU.




d223c3464

 x6
  x2

4. Disconnect the top right corner [A] and left side [B] of the BICU.



5. Unfasten the board from the machine frame, and the slowly pull the board to the left to remove it.




4

 x8


d223c3466

6. Remove the NVRAM from the old BICU and install it on the new BICU.



d223c3467

7. Connect the right edge of the BICU to the left edge of the controller board [A].



d223c3468

8. Re-install the rear covers, and then turn the machine on.

9. Open SP5811-004, and then enter the BICU number (displayed at SP5811-005).
10. Cycle the machine off/on.
11. Do the SP/UP settings as needed.
12. Cycle the machine off/on again to execute the initial process control cycle.

BICU NVRAM

1. Refer to the SMC report provided with the machine at installation.
2. Do **SP5990-001** to print out a complete, current SMC report.
3. Turn the machine off.
4. Remove the SD card slot cover, insert an SD card in SD Card Slot 2, and then turn the machine on.
5. Do **SP5824-001** (NVRAM Data Upload) to copy the data from NVRAM onto the SD card.
6. Turn the machine off, and then unplug the machine from its power source.
7. Remove the upper rear cover and controller box cover. page 488
8. Remove the BICU. page 872
9. Replace the old NVRAM on the BICU with the new NVRAM.



d223c3467

10. Connect the machine to its power source, and then turn the machine on.
11. Open **SP5131**, and then select your location.
12. Enter the ID number for the new NVRAM.

Note


- This is not the same number entered for the NVRAM with SP5811-04 (Machine Serial Number Set – Set BCU).
- Contact your supervisor for instructions on how to procure and enter this number. If this number is not entered correctly, the machine will return SC195-00 or display “Fusing Unit Setting Error.”

13. Cycle the machine off/on.
14. Insert into SD Card Slot 2 the SD card with the data you copied earlier with **SP5824**, and then do **SP5825** (NVRAM Download) to download (copy) the data to the new NVRAM.
15. Turn the machine off and remove the SD card from SD Card Slot 2.
16. Turn the machine on.
17. Do the User Tools and SP code settings as needed.
18. Cycle the machine off/on to enable the settings.

4


RYB (Relay Board)

1. Remove both rear covers. page 482
2. Open the controller box. page 490
3. The RYB (Relay Board) is below the controller box.



d223c3469

4. Disconnect the board.




 x15

d223c3470

4

5. Unfasten the top edge of the board.



 x3

d223c3471

6. Unfasten the bottom edge of the board.



 x3

d223c3472

7. Remove the board.



d223c3473

8. Lay the board on a flat, clean surface.



d223c3474

9. When you re-install the board, carefully check around the edges to make sure that there are no connectors or harnesses caught below the board.



d223c3475

PSU


⚠ CAUTION

- Work carefully around the PSU.
- Never touch any component on the PSU with your hand or a tool, especially one of the heat sinks.

- The heat sinks [A] are live and labeled with warnings not to touch them.
- A heat sink can retain a considerable electrical charge for hours, even after the machine has been turned off.




1. Remove both rear covers. Rear covers.
2. Open the controller box. Controller Box
3. The PSU is below the green RYB and to the left of the vertical AC drive board.



4. Disconnect the PSU.

4



 x5

d223c3477

5. Unfasten the left side and right side of the PSU.



 x3



 x5

d223c3478


⚠ CAUTION

- Handle the PSU carefully by its edges.
- Never touch any component on the PSU with your hand or a tool, especially one of the heat sinks.
- The heat sinks are live and labeled with warnings not to touch them.
- A heat sink can retain a considerable electrical charge for hours, even after the machine has been turned off.





⚠ CAUTION

- To avoid personal injury, never touch the back of the board.
- Some of the soldered contacts are extremely sharp and can cut or puncture your fingers if you grip the back of the board.




6. While carefully handling the board by its edges, lay the PSU on a flat clean surface.
7. Note the location of glass fuses FU3, FU4, FU5 and FU7.



d223c3481


DHB

1. Remove both rear covers. Rear covers.
2. Open the controller box. Controller Box
3. The DHB is the small board below the vertical AC drive board on the right.



d223c3482

4. Disconnect the three visible connectors [A].
5. Free the large harnesses on the right so you can disconnect the connector [B] behind them.



6. Unfasten the board, and then remove it.




7. Lay the DHB on a flat, clean surface.



AC Drive Board


1. Remove both rear covers. Rear covers.
2. Open the controller box. Controller Box
3. The AC drive board is the large vertical board on the right.





d223c3486

4

4. Disconnect the board.



d223c3487

 x8  x2


5. Unfasten the top of the board.



 x2

d223c3488

6. Unfasten the left side of the board [A] and the right side of the board [B].




 x2

 x2


d223c3489

7. Slowly, work the board out from behind the large harnesses, and then remove it.




d223c3490

8. Lay the board on a flat, clean surface.
9. Note the position of fuses FU101, FU102.
10. Obey the warning to replace these fuses with fuses of the same type and rating.



d223c3491

11. The bayonet connectors at the lower left corner of the board must be installed with the black connector on the left and white connector on the right.
12. The connector blades are clearly marked "BLACK" and "WHITE" to indicate the correct connection point.



d223c3492

IOB

1. Remove the rear upper cover. Rear upper cover
2. Open the controller box. Controller Box
3. The IOB is on the back of the main machine.



d223c3493


4. Disconnect the top edge of the board.



 x3  x3

d223c3494


5. Disconnect the right edge of the board.
6. Allow the harness bundle to hang down as shown.



 x3  x5

d223c3495


7. Disconnect the bottom edge of the board.



 x10

d223c3496


8. Disconnect the left edge of the board.



 x7

d223c3497

9. Unfasten the board from the frame, and then remove it.



 x8

d223c3498

10. Lay the board on a flat clean surface.



d223c3499

Important SP Codes: PCBs, HDD

Here is a list of SP codes related to testing and servicing the main boards and the HDD.


Item	SP No.	Function
Data Overwrite Security: Enable	5878-1	Enables the Data Overwrite Security feature.
Format HDD	5832-1	Formats the entire HDD. The HDD can also be formatted by selecting the partition to format. A new HDD should always be formatted after it has been installed.

Item	SP No.	Function
HDD encryption	5878-2	Enables the HDD encryption feature.
NVRAM data download	5825	Downloads data from an SD card to the NVRAM in the machine. After downloading is completed, remove the SD card and cycle the machine off/on.
NVRAM data upload	5824	Uploads the UP and SP mode data (except for counters and the serial number) from NVRAM on the control board to an SD card. While using this SP mode, always keep the front cover open. This prevents a software module accessing the NVRAM during the upload.
SMC Report, print all	5990-1	Prints a complete SMC report with all the current machine settings.
SMC report, text file	5992	Writes the SMC report to an SD card inserted into the SD card slot on the side of the operation panel.
UCS settings	5846	Provides all the options for the UCS settings.


ADF

ADF Removal


1. Remove the rear upper cover. page 482
2. Remove the controller box cover. page 488
3. Disconnect cable brackets [A] and [B].
4. Disconnect ground wire [C].
5. Pull away both brackets with harnesses connected.



6. Free harnesses [A] and [B] on top of the controller box.




7. Set the cables up behind the ADF.



d223c3517

4

8. Disconnect the cable inside the controller box.



d223c3518




9. Remove the screws on the ADF base on the left and right.



 x2

d223c3519


10. Slowly and carefully (the ADF is heavy) lift the ADF [A] off the machine.
11. Set the ADF on its edge on the floor, and then lean it against a wall [B].



d223c3520

★ Important

- To prevent damage to the fragile feelers [A] of the ADF position sensor, never lay the ADF on a flat surface as shown below.



d223c3521

★ Important

- If the ADF is being replaced, do SP4-730-002 after the new ADF has been installed.

4

After ADF Replacement

CIS RGB Adjustment


1. The correct RGB settings for the ADF are listed in the specifications sheet that comes with the machine.
2. Enter the settings with these SP codes:
 - R: SP4-712-001 (CIS GB Adj Value: R)
 - G: SP4-713-001 (CIS GB Adj Value: G)
 - B: SP4-714-001 (CIS GB Adj Value: B)

Checking the vertical registration

SP6-006-001 (ADF Adjustment Side-to-Side Regist: Front)

SP6-006-002 (ADF Adjustment Side-to-Side Regist: Rear)

1. Create an original as shown in the following picture.



The large arrow indicates the direction of feed.

2. Copy the original and make sure that the position of the line [A] is within 0 ± 1 mm
3. If not within the standard, adjust with the SP modes.

Checking the horizontal registration


SP6-006-010 (ADF Adjustment L-Edge Regist (1-Pass): Front)

SP6-006-011 (ADF Adjustment L-Edge Regist (1-Pass): Rear)

1. Copy the original and make sure that the position of the line [B] is within 0 ± 2 mm.
2. If not within the standard, adjust with the SP modes.

Checking skew

1. Make sure that the difference between both end positions of the line [A] is within 0 ± 2 mm.
2. If not within the standard, change the position of the fixing screw [A] to the long hole [B] at the right hinge.



4

Checking magnification

SP6-017-001 (DF Magnification Adj.)


1. Copy the original and make sure that the length of the line [B] is within 100 ± 1 mm.
2. If not within the standard, adjust with the SP mode.

Platen Adjustment

1. Open the ADF and remove the white cover [A].




2. Put the white cover [A] in the correct position on the exposure glass, aligning it with the glass cover [B] and the rear scale [C].



d1352783

3. Close the ADF [A] slowly and paste the ADF and the white cover [B] with the magic tapes.

4




d1352784

ADF Covers

ADF Front Cover page 901

1. Open the feed cover [A].



d1352047

4

2. Slide the ADF front cover [A] to the left.




d224c2048

⚙️ x2 ▾ x2


⬇️ **Note**

- Check the position of the hooks in the photo below before removing.



ADF Rear Cover


1. Open the feed cover [A].
2. Cover [A].



 x1

d224c2050

3. Lift off the rear cover [A].




🔑 x2 ▾ x4

d224c2051

⬇️ **Note**


- Check the position of the hooks before removing.



d1352052

Feed Cover

1. ADF front cover ADF page 901
2. ADF rear cover ADF page 903
3. Feed cover [A].




⚙️ x3 📦 x1


4

Original Feed Unit

1. Open the feed cover.
2. Remove the snap-fit [A].




3. Original feed unit [A] (Pull the original feed unit, remove the back side of the shaft. Then, remove the bushing in the foreground.)



4


Pick-up Roller, Transport Belt

1. Remove original feed unit. page 905
2. Slide bushing [A], and then remove the pick-up roller unit [B].




Note

- At re-assembly, make sure that the tab on the front guide plate [A] is above the pick-up roller [B].




3. Pick-up roller cover [A] and pick-up roller [B].




4

4. Lift the left and right sides of the feed belt holder [A], then remove it.



5. Remove the feed belt [B] from the feed belt holder [A].




d1352061

4


ADF Separation Roller

1. Open the feed cover.
2. Original feed unit page 905
3. ADF separation roller cover [A].



d1352056

4. ADF separation roller [A] and torque limiter clutch [B] (snaps off)




d1352057

4

Original Registration Sensor

1. Entrance lower guide [A].



d224c2717

x2


2. Scanning guide plate [A].




x1

d224c2718

3. Original registration sensor [A] along with the bracket.




4. Original Registration Sensor [A].



Original Exit Sensor


1. Entrance lower guide [A].




2. Scanning guide plate [A].




3. Open the white cover [A].



4. Remove the original exit sensor [B], which is mounted on the upper guide [A].




5. Remove the original exit sensor [B] from the upper guide [A].




ADF Control Board

1. ADF rear cover ADF page 903
2. ADF control board [A].




Separation Sensor, Skew Correction Sensor


1. Feed upper guide [A] in the feed cover.



2. Remove the sensors along with the bracket [A].




3. Separation Sensor [A] and Skew Correction Sensor [B].




Original Width Sensor, Interval Sensor

1. Feed cover Feed Cover
2. Guide plate [A].




3. Interval sensor [A].




4. Remove the original width sensor guide plate [A].

5. Remove the five original width sensors [B].



Original Length Sensors

1. Raise the document tray [A], then remove the lower cover [B].




2. Original Length Sensors

[A] B5


[B] A4

[C] LG



APS Feeler


1. ADF rear cover ADF page 903
2. APS Feeler [A].



ADF Lift Interlock Switch, Lift Sensor

4

1. ADF Control Board page 912
2. ADF lift-up interlock SW [A] along with the bracket (🔩 x 3, 📦 x 2)



3. Lift-Up Sensor [A] along with the bracket.




 x1  x1

4


Original Set Sensor

1. ADF front cover page 901
2. Remove the screw and raise the original tray [A].



d1352073

3. Original set sensor [A].




d224c2074

 x1  x1


A4 LEF, LT LEF Sensor

1. ADF front cover page 901
2. Remove the screw and raise the original tray [A].



d1352073

3. A4 LEF/LT LEF Sensor [A].




d224c2608

1x1  x1

Bottom Plate HP Sensor


1. Original feed unit page 905
2. ADF front cover page 901
3. Remove the screw and raise the original tray [A].



d1352075

4

4. Bottom plate HP sensor [A].




d224c2076

 x1

Bottom Plate Position Sensor

1. ADF rear cover page 903
2. Original feed unit page 905
3. Bottom plate position sensor [A].




d224c2081


 x1

ADF Feed Cover Interlock SW, Pick-up Roller HP Sensor


1. ADF rear cover page 903
2. Remove the ADF feed cover interlock SW [A] from the retaining bracket.



3. ADF feed cover interlock SW [A].



4. Pick-up roller HP sensor [A] along with the bracket.




- ⚙️ x1
- 🔩 x1
- 📦 x1

4


ADF Entrance Motor

1. ADF rear cover page 903
2. ADF entrance motor [A] along with the frame.




- ⚙️ x1
- 🔩 x1
- 🌀 x1
- ⚙️ x2
- 📦 x2

3. ADF entrance motor [A].




ADF Scanning Motor

1. ADF entrance motor along with the frame page 922
2. ADF scanning motor [A] along with the bracket.



3. ADF scanning motor [A].




 x2

d224c2089

4

ADF Exit Motor




1. Remove the rear cover. page 903
2. The exit motor is on the back of the machine behind the vertical stay.



d223c3746

3. Remove the ADF control board.




 x1  x15  x4

d223c3747

4. Remove the anti-static plate.




5. Unfasten the motor.



6. Disconnect the drive belt.



7. Disconnect the motor and remove it.



 x1

d223c3751

4

ADF Bottom Plate Lift Motor

1. ADF entrance motor along with the frame page 922
2. ADF bottom plate lift motor [A].




d224c2090


 x2  x1

ADF Pick-up Roller Lift Motor, ADF Transport Motor


1. ADF rear cover page 901
2. Frame (black) [A].



3. ADF pick-up roller lift motor [A].




4. ADF transport motor [A] along with the bracket.



4




5. ADF transport motor [A].




d224c2088

ADF Feed Motor


1. ADF rear cover page 903
2. Remove the fixing screws of the frame (black) [A].



3. ADF entrance motor along with the frame ADF Entrance Motor
4. ADF feed motor [A] along with the bracket.



5. ADF feed motor [A].




 x2

d224c2089

4


CIS Unit

1. Original Feed Unit page 905
2. ADF Separation Roller page 908
3. ADF front cover page 901
4. Raise the ADF.
5. Push the P release to the left to release white plate [A]. This will prevent scratching the CIS glass when the unit is removed.



d1352676

6. Guide plate (large) [A]




7. Guide plate (small) [A].




8. Unfasten guide plate [A].

9. Remove guide plate with mylar [B] attached.



10. At the front, disconnect timing belt.

11. Unfasten mylar plate and then remove it.




 x1  x2

d223c3523

4

12. Disconnect CIS unit [A].
13. Slowly, pull the CIS unit [B] out of the ADF.



 x2

d223c3524

14. Lay the CIS unit on a flat, clean surface, with the glass side facing up.



d223c3525


Reinstallation

1. Before reinstallation, clean the surface of the CIS lens with a lens cloth.

★ Important

- Never clean the surface of the CIS with tissue or any type of organic solvent.

2. Two pegs on the rear end of the CIS [A] fit into two holes [B] at the back of the ADF unit.



d223c3526

3. To re-install the CIS, set the CIS in its channel so it is perfectly flat.
4. Slowly, push it to the rear until the pegs slide into the holes.

4



d223c3528

5. Follow the correct arrangement of the drive belt when you re-attach it.



d223c3527

6. If you have replaced the CIS unit, do these SP three codes in the following order:
 - SP4-730-001
 - SP4-730-004

- SP4-730-002

CIS White Roller Cleaning


Frequently inspect the CIS white roller. A dirty or incorrectly installed white roller will cause the machine to issue SC152-00 (White Level Error: Back Side).

1. Open the ADF.
2. At the upper left corner, release the white plate.



d223c3741

3. Swing the roller assembly away from the ADF [A].
4. White rotating the white roller [B] by its gear, use a dry, clean cloth to wipe the surface of the roller clean.



d223c3742

Important SP Codes: ADF

Here is a list of SP codes related to testing and servicing the ADF. For more details about procedures to be done after ADF replacement, see "Adjustment after ADF Replacement" at the beginning of this section.

After ADF Replacement

Item	SP No.	Function
Leading edge registration: Front	6006-1 0	After ADF replacement, copy the original and make sure that the position of the line is within 0 ± 2 mm. If not within the standard, adjust with the SP modes.
Leading edge registration: Rear	6006-1 1	After ADF replacement, copy the original and make sure that the position of the line is within 0 ± 2 mm. If not within the standard, adjust with the SP modes.
Magnification	6017-1	After ADF replacement, copy the original and make sure that the length of the line [B] is within 100 ± 1 mm. If not within the standard, adjust with the SP mode.
RGB adjustment	4712 4713 4714	Adjust RGB settings after ADF replacement. The correct RGB settings for the ADF are listed in the specifications sheet that comes with the machine. Enter the RGB settings with these SP codes: <ul style="list-style-type: none"> • SP4-712-001 (CIS GB Adj Value: R) • SP4-713-001 (CIS GB Adj Value: G) • SP4-714-001 (CIS GB Adj Value: B)
Vertical registration, front	6006-1	After ADF replacement, lines on the original should be within 0 ± 1 mm, else adjustment is required.
Vertical registration, rear	6006-2	After ADF replacement, lines on the original should be within 0 ± 1 mm, else adjustment is required.

After CIS Replacement

After CIS replacement, you must do these SP codes in the following order:

- SP4-730-001
- SP4-730-004
- SP4-730-002

Fans, Switches

Fans

Quick Reference

Here is a list of the fans described in this section and the corresponding SC code issued by the machine in case of a failure.


SC Code	Fan
SC530-01	Drum Fan* ¹
SC530-02	Development Unit Fan 1
SC530-02	Development Unit Fan 2
SC530-04	Duplex Fan
SC530-04	PCU Fan
SC530-06	Toner Bottle Fan* ²
SC530-07	Fusing Inner Cover Fan* ²
SC530-08	PSU Fan 1
SC530-09	PSU Fan 2
SC530-10	AC Drive Board Fan* ²
SC530-11	Controller Fan* ²
SC530-13	PFU Fan 1* ²
SC530-15	PFU Fan 3* ²
SC530-16	PFU Fan 4* ²
SC531-01	Main Intake Fan* ³
SC531-02	Main Exhaust Fan* ²
SC531-03	Heat Exhaust Fan* ²

*¹ "Main intake fan" in previous machine.

SC Code	Fan
*2	New fan for this machine.
*3	"Drum fan" in previous machine.


Drum Fan

1. Remove rear upper cover. page 482
2. The drum fan is at the rear right corner of the machine above the flywheel.



d223c3529


3. Disconnect the duct bracket.



 x2

d223c3530

4. Pull the duct and fan out slightly, and then disconnect the fan.



 x1


d223c3531

5. Pull the duct with fan attached out of the machine.



d223c3532

6. Unfasten the fan, and then separate it from the duct bracket.



 x2  x1

d223c3533

Development Unit Fan 1, 2

1. Remove the right upper cover. page 478
2. There are two development unit fans, Fan 1 [1] and Fan 2 [2].



d223c3534

3. Disconnect the fan bracket.



 x1  x3

d223c3535

4. Pull the bracket with fans attached out of the machine, and then lay it on a flat, clean surface.



d223c3536

5. Disconnect the front of the fan cover [A] and rear of the fan cover [B].



 x1

 x1

d223c3537


6. Remove the fan cover.




d223c3538

Fan 1

1. Disconnect Fan 1 from the bracket.



 x1



 x2

d223c3539

4

2. Remove the fan from the bracket.




d223c3540

Fan 2

1. Disconnect Fan 2 from bracket.




 x1



 x2

d223c3632

2. Remove the fan from the bracket.




d223c3633

4

Duplex Fan

1. Remove front door. page 477
2. Remove Tray 1. page 762
3. Remove duplex unit. page 746
4. Remove left lower cover. page 487
5. Pull out fusing unit.
6. The duplex fan is in the center of the machine, below the duplex unit.



d223c3541

7. From the left side of the machine, disconnect the fan.




 x1  x1



d223c3542

4


8. From the front of the machine [A], disconnect the fan bracket.




 x1

d223c3543

9. From the left side of the machine, disconnect the fan bracket [A], and then remove the bracket with fan attached from the machine [B].




 x1



d223c3544

10. Disconnect the plate.




 x2

d223c3545

4


11. Separate plate and fan.





d223c3546

PCU Fan


1. Open the front door.
2. Swing open the toner bottle holder.
3. Disconnect inner cover C1.



 x2  x2



d223c3547

4. Lower handle C1 [A].
5. Remove cover [B], and then lay it on a flat, clean surface.



d223c3548

6. Disconnect and remove plastic cover [A].



 x2  x2

d223c3549

7. Slide the fan out of its bracket. There are no screws.




d223c3550

★ Important

- The fan must be re-installed with the label side up.

Toner Bottle Fan


1. Open the front door.
2. Remove inner cover [A].
3. Duct [B] is the duct of the toner bottle fan inside the machine.



⚙️ x1 ▾ x1

d223c3551

4. Remove the scanner unit. Scanner Unit Removal
5. The toner bottle fan is below the front edge of the laser unit [A].




d223c3552

- 6. Disconnect left side [A] of the laser unit cover.
- 7. Disconnect center of the cover [B].




 x2



 x1

d223c3553

- 8. Disconnect front right corner of cover [A].
- 9. Disconnect rear right corner of cover [B].



 x1


 x1

d223c3554

4

10. Free harness [A] behind cover.

11. Pull cover [B] slightly to the rear. You do not need to remove the cover.




 x4

d223c3555

12. Disconnect the fan.

4



 x1

d223c3556


- 13. Release tab [A] on the left side of the duct.
- 14. Pull duct with fan attached [B] out of the machine.



 x1

d223c3557

- 15. Separate the fan and duct.




 x2

d223c3558


Re-installation

1. When you re-install the fan, first, set tab [A] into the slot on the right.
2. Next, set and lock tab [B] on the left.



d223c3559

3. Check the front of the machine.
4. Confirm that the fan duct is flat and parallel to the frame as shown.



d223c3560

5. If the duct is not straight, set the fan again.


Fusing Inner Cover Fan

1. Open the front door, and then pull out the fusing unit.
2. The fan is inside the cover at the upper right corner.




d223c3561

3. Raise D2 [A].
4. Locate the hole in the shaft [B]. If you cannot see the hole, turn the large knob until you can see it.



d223c3562

5. Insert a small screwdriver [A] into the hole to prevent the shaft from rotating.
6. Remove the large knob [B].




 x1

d223c3563

4

7. Disconnect the fusing unit cover.




 x1

 x1

 x1

d223c3564

8. Pull the cover slightly away, and then disconnect the LED harness.




d223c3565

9. Remove the cover and lay it on a flat, clean surface.

10. At [A] disconnect the fan and free the LED harness.

11. Unfasten the duct cover [B].




4


12. Remove the duct with fan attached.



13. Unfasten the fan from the duct.



14. Separate the fan from the duct.




d223c3569

4

PSU Fan 1, 2

1. Remove the rear covers. page 482
2. Open the controller box. page 490
3. The PSU fans [1] and [2] are located directly below the PSU.




d223c3570

⚠ DANGER

- Never attempt to remove either fan without first removing the PSU.
- There are three heat sinks on the board that can hold an electrical charge after the machine has been turned off and disconnected from the power supply.
- Never touch any component on the front of the PSU and do not touch the soldering points on the back of the PSU.

- Always handle the PSU by its edges.

4. Remove the PSU.



 x5  x8

d223c3571


PSU Fan 1

1. PSU Fan 1 is on the left.



d223c3572

2. Disconnect and unfasten the fan, and then remove it.



 x3  x1  x2

d223c3573

3. There is no fan bracket.

4



d223c3574

PSU Fan 2


1. PSU Fan 2 is on the right.



d223c3575

4


2. Disconnect and unfasten the fan.



 x4  x1  x2

d223c3576


3. Remove the fan. There is no bracket.



d223c3577


AC Drive Board Fan

1. Remove the rear covers. page 482
2. Open the controller box. page 490
3. The fan [1] is directly below the AC drive board [2].




d223c3578

4. Disconnect the power cord.


 x1

d223c3579

5. Unfasten the corner plate [A] and ground wire.
6. Unhook the corner plate at [B].




 x3

d223c3580

4

- 7. Disconnect the fan harness [A] in the corner of the machine.
- 8. Disconnect harness [B] above the fan.



 x2  x1

 x1

d223c3581

- 9. Release the tabs at the left rear corner and front right corner of the fan.



 x2

d223c3582

- 10. Remove the fan. There is no bracket.




d223c3583

Controller Fan


4

1. Remove the rear upper cover. page 482
2. The controller fan is on top of the controller box.



d223c3584


3. Disconnect and unfasten the fan.



 x1
  x1
  x2

d223c3585

4. Remove the fan. There is no bracket.




d223c3586

4

PFU Fan 1, 3, 4

1. Remove the right lower cover. page 481
2. Open the front door.
3. Remove the used toner bottle.
4. Push button **A** to open the vertical plate.



d223c3591

5. Remove the vertical inner cover.



 x2  x1

d223c3592


6. Disconnect the harness at the back of the vertical plate.



 x1  x1

d223c3593

7. Lift the vertical plate [A] off its hinge pegs, and then remove it.
8. Lay the vertical plate [B] on a flat clean surface.
9. The upper fan [1] is the PFU fan 1, and the lower fan [2] is PFU fan 3.




d223c3594

4

PFU Fan 1


1. Free the fan harness and disconnect it.



 x3  x1

d223c3595

2. Remove the fan.




 x2

d223c3596

PFU Fan 3



1. Free the fan harness and disconnect it.



 x3  x1

d223c3597

2. Remove the fan.




 x2

d223c3598

PFU Fan 4

1. PFU Fan 4 is below the bottom paper feed unit.




d223c3599

★ Important

- The right lower cover, used toner bottle, vertical inner cover, and vertical plate must first be removed, the same as in the procedure to remove Fan 1 and Fan 3.

2. Disconnect the front of PFU 3 [A].
3. Remove bracket lock screw [B].




 x1  x3

 x1


d223c3600

4. Push the front of the PFU [A] to the right to disconnect it.
5. Remove the PFU [B] through the side of the machine.



d223c3601

6. Disconnect the fan harness and then unfasten the fan.




 x1

 x2

d223c3602

7. Remove the fan.

4




d223c3603

Main Intake Fan

1. Remove the rear upper cover. page 482
2. The main intake fan is at the rear right corner of the machine.

4




d223c3604

3. Disconnect fan duct [A].
4. Slowly, pull the duct partially out of the machine so you can see connector [B], and then disconnect it.




 x1



 x1


d223c3605

5. Separate the fan and duct.




Main Exhaust Fan

1. Remove the rear upper cover. page 482
2. The main exhaust fan is at the rear left corner of the machine.



d223c3607

3. Disconnect fan bracket [A] on the left.
4. Disconnect the clamps and harness at [B] so they do not block removal of the fan bracket and duct.
5. Disconnect the duct [C] on the right.




⚙️ X2 📏 x2 🛠️ x2

⚙️ X1

d223c3608


4

6. Remove the bracket and duct with fan attached.



d223c3609

- 7. Disconnect the duct [A].
- 8. Separate the duct [B] from the fan.
- 9. Unfasten fan [C].




⚙️ X2 📏 X1

⚙️ X2

d223c3610

- Separate fan and bracket.




d223c3611

4

Heat Exhaust Fan

- Remove the rear upper cover. page 482
- The heat exhaust fan [1] is located below the main exhaust fan [2].



d223c3612

- Remove main exhaust fan. (See procedure above. The main exhaust fan must be removed before the heat exhaust fan can be removed.)
- Disconnect the duct at [A].




 x1


d223c3613

4

- 5. Disconnect bracket at [A].
- 6. Disconnect bracket at [B] (left screw).




 x1



 x1

d223c3614

- 7. Lift the duct and bracket [A] to unhook the front and rear.
- 8. Remove the bracket and duct [B] with fan attached.




d223c3615

9. Lay the unit on a flat, clean surface.



d223c3616

10. Disconnect the duct.




 x1  x1



 x1


d223c3617

11. Separate duct [A] from the fan.
12. Unfasten fan [B].



4


13. Separate fan from bracket.



Switches

Power Switch

1. Open the front door.
2. Remove the power switch cover.




 x1

d223c3620

4

3. Disconnect and remove the power switch board.




 x1

 x1

d223c3648

Front Door Safety Switch

1. Open the front door.
2. Remove the power switch cover.




4

 x1

d223c3620


3. Unfasten the door switch.



 x2

d223c3621

4. Disconnect the door switch bayonet connector.



 x1

d223c3622

5. Remove the switch.



d223c3623

Human Detection (Proximity) Sensor Switch

This sensor, mounted in the front, detects the presence of the operator as soon as he or she approaches within 1.8 meters of the front of the machine.


- The sensor uses infrared so the maximum distance at which the operator's presence can be detected may vary with ambient temperature.
- The standard is for the sensor to detect the operator at 1.8 meters away from the front of the machine at ambient 28C (82F). However, this can vary with changes in ambient temperature.
- At lower ambient temperature, this distance may increase and the operator can be detected farther away. At higher ambient temperature, the distance may decrease and the operator will have to be closer to the front of the machine for the sensor to detect.
- The sensor monitors the space from the floor to the approximate height of the operator's knees. The sensitivity of the sensor detection can also be affected by the operator's clothing.

- If the sensor fails to switch off, this will cause SC869-01. If the sensor fails to switch on, this will cause SC869-02.

Test the Switch


Do this procedure in order to identify the problem with the sensor.

1. Go into the SP mode.
2. Open **SP5-102** (this is the sensor input check).
3. While keeping your hand away from the sensor, cover the sensor at the front of the machine with a stack of about 10 sheets of paper, and then see if the value on the display resets to "0" (no detection).



d223c3650

4. Take the paper away from the sensor to see if the value resets to "1" (detect).
 - If the value resets to "0" and "1", this means the sensor is functioning but a heating source or a failed fan in the machine could be causing a rise in temperature that is interfering with operation of the sensor.
 - If the values fail to reset to "0" and "1" correctly, switch off the machine, and then replace the three PCBs (MSENS1 x2, MSENS2 x1). This is described below.
5. Turn the machine on, and then do Steps 1, 2, 3 to test the operation of the sensor.
6. If the test fails again, turn the machine off, and then replace the harness between MENS1 and MENS2.
7. Turn the machine on, and then do Steps 1, 2, 3 again.
8. If the sensor fails the test again, the harness between MSENS-2 and the BiCU, or the controller board may need replacement.



d223c3649

4

Switch Disassembly

1. Open the front door.
2. Remove the power switch cover.



 x1



d223c3620


3. Open the ADF.
4. Remove the front edge plate of the scanner unit.



 x2

d223c3624

5. Disconnect the operation panel on the left [A] and on the right [B].



 x2


d223c3625

6. Slowly, turn the operation panel upside down, and then lay it on the scanner unit.




d223c3626

7. This detection device [1] and PCB [2] comprise the sensor.



4

8. Remove the PCB (MSENS2).



9. Unfasten the detection device bracket, and then pull it out partially.




 x1

d223c3628

4


10. Open clamp [A] to free the harness, and then remove the bracket with harness attached [B].



 x1


d223c3630

11. The MENS1 PCBs are in the bracket [1]. The PCB [2] is MENS2.




d223c3631

12. Disconnect the MENS1 PCBs [A], and then remove the top half of the bracket [B].




13. Remove both MENS1 PCBs from the bracket.



[1]	MENS1 PCB pair
[2]	MENS2 PCB
[3]	Harness

Re-assembly


1. Set the MENS1 PCB pair in the bracket at the correct angle [A].
2. The boss and screw holes will align correctly [B] only when the PCBs are set at the correct angle.



d223c3646

3. Clamp the harness between the two permanent binders on the harness.

4



 x1

d223c3647

Important SP Codes: Fans, Switches

Here is a list of SP codes related to testing and servicing the large number of fans and switches.

Item	SP No.	Function
Input check	5803	Displays the signals received from fans.
Output check	5804	Switches fans on/off one by one for testing.
Proximity sensor check	5102	This SP returns a "1" if the sensor on the front of the machine detects the presence of the operator.

Copy Image Adjustments: Printing/Scanning

These adjustments must be performed after replacing any of the following parts:

- Scanner wires
- Lens block
- Scanner motor
- Polygon motor
- Tandem tray side fences
- Memory All Clear

4


Image Adjustments: Printing

Preparation

1. Make sure paper is installed correctly in each paper tray before you start these adjustments.
2. Use the Trimming Area Pattern (SP2-902-3, No. 18 to print the test pattern for the following procedures.
3. After completing these printing adjustments, be sure to set SP 2-902-3 to 0 again.

Registration - Leading Edge/Side-to-Side

1. Check the leading edge registration, and adjust it using SP1-001.
Specification: $4\pm 2\text{mm}$.
2. Check side-to-side registration for each paper feed station, and adjust with the following SP modes.



B140r887


4

	SP mode	Specification
Tray 1 (Tandem Tray)	SP1002-001	0 ±1.5
Tray 2 (Universal Tray)	SP1002-002	
Tray 3 (Universal Tray)	SP1002-003	
Tray 4	SP1002-004	Japan Only
LCT	SP1002-006	0±1.5
Duplex Tray	SP1002-007	0±1.5

Blank Margin

If the leading edge/side-to-side registration cannot be adjusted within specifications, adjust the leading/left side edge blank margin.

1. Check the trailing edge and right edge blank margins, and adjust them with the following SP modes.



B140R888

Letter	What It Means
A	Trailing edge blank margin
B	Right edge blank margin
C	Leading edge blank margin
D	Left edge blank margin

SP2101 Print Erase Margin

	SP mode	Specification
Leading Edge	SP2101-001	2.5±2 mm
Trailing Edge	SP2101-002	
Left edge	SP2101-003	2±1.5 mm
Right edge	SP2101-004	

Registration Buckle Adjustment

When the customer is using special paper, buckle adjustment may be required if paper feed problems arise.

- If the buckle is too large, this can cause wrinkling, creasing, or jams caused by sheets overtaking the sheets ahead of them in the paper path.
- If the buckle is too small, this can cause jams at the registration roller or skew during paper feed.

1. Enter the SP mode.

2. Open SP1003.

- To prevent wrinkling, creasing, or jams, set a smaller value.
- To prevent jams at the registration roller or to eliminate skew, set a larger value.

SP1003-001	Registration Buckle Adjustment – Tray, LCT
SP1003-002	Registration Buckle Adjustment – Duplex Tray
SP1003-003	Registration Buckle Adjustment – Bypass Tray
Adjustment range	-9 mm -> +9 mm (small -> large buckle)
Initial value	0 mm (Buckle = 10 mm)


Image Adjustments: Scanning

Before doing the following scanner adjustments, perform or check the printing registration/side-to-side adjustment and the blank margin adjustment.

↓ Note

- Use an S-5-S test chart to perform the following adjustments.

Registration: Platen Mode



b140r889


1. Place the test chart on the exposure glass and make a copy from one of the feed stations.
2. Check the leading edge and side-to-side registration, and adjust them with the following SP modes if necessary.

SP No.	Name	Initial	Comment
SP4010	Scanner Leading Edge Registration	0	A positive value shifts the image away from the leading edge, a negative value shifts it toward the leading edge.
SP4011	Scanner Side-to-Side Registration	0	A positive value shifts the image toward the right edge, a negative value shifts it toward the left edge.

Magnification

Use an S-5-S test chart to perform the following adjustment.

Main Scan Magnification



b140r890

1. Place the test chart on the exposure glass and make a copy from one of the feed stations.

2. Check magnification, and then SP2909-001 (Main Scan Magnification - Copy) to adjust magnification if required. Specification: $\pm 2\%$.

Sub Scan Magnification

1. Place the test chart on the exposure glass and make a copy from one of the feed stations.
2. Check the magnification ratio. Use SP4008 (Scanner Sub Scan Magnification) to adjust if necessary. Specification: $\pm 0.9\%$.

ADF Scanning Adjustments

4

Vertical Black Lines

Vertical black lines in scanned images may be caused by dust or scratches on the ADF exposure glass. If the problem cannot be solved by cleaning the ADF exposure glass, do SP4020 (Dust Check).

1. Open SP4020-001 and then select "1" (On).
2. Make a test copy.
3. If vertical lines still appear, set the detection level higher with SP4020-002.

Note

- The correction level is set with SP4020-003 (0:Off, 1: Lowest, 4: Highest).

DIP Switch Settings (ADF Main Board)


SW 101				Operation Mode
1	2	3	4	
OFF	OFF	OFF	OFF	I/F Operation
ON	OFF	OFF	OFF	Free run (Simplex: each sheet stopped for registration)
OFF	ON	OFF	OFF	Free run (Simplex: continuous scanning)
ON	ON	OFF	OFF	Free run (Duplex: no registration) SP6009 (ADF Free Run)
ON	OFF	ON	OFF	Not used.
OFF	ON	ON	OFF	
ON	ON	ON	OFF	
OFF	OFF	OFF	ON	

SW 101				Operation Mode
ON	OFF	OFF	ON	Free run (Entrance mode * 1, simplex, no registration)
OFF	ON	OFF	ON	Free run (Entrance mode, simplex, continuous scanning)
OFF	ON	ON	ON	Motor test (feed, transport, exit motors)

* 1: The entrance mode disregards paper size. Skew correction is performed at the scanning roller.

ADF Skew Correction

If the skew with A4 SEF paper is more than 0.5/200 mm in the main scan direction, you can adjust the position of the ADF hinge [A] or adjust the appropriate SP codes below.



b246r891

6006*	ADF Registration Adjustment
001	ADF Horizontal Registration (Front) Adjusts the side-to-side registration for the front in ADF mode. [-3 to +3/0.1 mm]
002	ADF Horizontal Registration (Back) Adjusts the side-to-side registration for the back in ADF mode. [-3 to +3/0.1 mm]

003	<p>ADF Vertical Registration (Front)</p> <p>Adjusts the vertical registration for the front in ADF mode.</p> <p>[-30 to +24/1 mm]</p> <p>-30 = -5.1 mm</p> <p>+24 = +4.1 mm</p>
004	<p>ADF Vertical Registration (Back)</p> <p>Adjusts the vertical registration for the back in ADF mode.</p> <p>[-30 to +30/1 mm]</p> <p>-30 = -5.1 mm</p> <p>+30 = +5.1 mm</p>
005	<p>ADF Buckle Adjustment 1</p> <p>Adjusts the roller timing at the skew correction sensor/entrance roller. A larger setting causes more buckling.</p> <p>[-12.0 to +12/1 mm]</p> <p>-12 = -3.0 mm</p> <p>+12 = +3.0 mm</p>
006	<p>ADF Buckle Adjustment 2</p> <p>Adjusts the roller timing at the interval sensor/scanning roller. A larger setting causes more buckling.</p> <p>[-8.0 to +8/1 mm]</p> <p>-8 = -2 mm</p> <p>+8 = +2 mm</p>
007	<p>ADF Trailing Edge Erase Margin (Front)</p> <p>These settings adjust the erase margin for the trailing edges for the front.</p> <p>[-20 to +20/1 mm]</p> <p>-20 = -10 mm</p> <p>+20 = +10 mm</p>
008	<p>ADF Trailing Edge Erase Margin (Back)</p> <p>These settings adjust the erase margin for the trailing edges for the back.</p> <p>[-20 to +20/1 mm]</p> <p>-20 = -10 mm</p> <p>+20 = +10 mm</p>

Note

- Normally, the interval sensor detects the leading edge of small originals (B6, A5, HLT), or originals for duplex copying, and delays the start of the scanning roller for the prescribed number of pulses to buckle the paper and correct skew. This feature can be switched on for all paper sizes with SP6020 (ADF Contact Mode In/Out). However, switching this feature on for all sizes reduces scanning speed slightly.


LCD, Touch Screen Check and Calibration

Smart Panel Maintenance Mode

You should perform the following checks and calibrations:


- After replacing the operation panel or operation panel touch screen.
 - After clearing the memory
 - If the touch screen detection function is not working correctly
1. First, remove the cover plate on the left side of the operation panel so you can see the EX buttons.

4




d223c3104

2. These buttons are not labeled but reading from left to right, they are EX1, EX2, and EX3.




01 EX Keys

3. Next, enter the numbers to enter the Smart Panel maintenance mode, and display the Service Screen. (Contact your supervisor if you do not know how to do this.)



d223c3106



- On the Service Screen, touch "System Device Settings" at the bottom of the menu. The Self Check screen opens.



d223c3108

- There are two checks and two calibrations you will need to execute:

1	LCD Check
2	Touch Panel Check
3	Touch Panel Calibration
4	Multi Touch Calibration

- Follow the procedures below to do each check and calibration.
- To continue with the next check, touch  to return to the Self Check menu, and then select the next check or calibration.
- When you are finished, touch  to return to the Service Screen.
- Touch "Logout" in the upper right corner of the Service Screen to log out and return to normal operation.


Checks and Calibrations

LCD Check

The LCD Check allows you to visually check the color reproduction of the LCD.

The colors are displayed on screens in sequence: White > Back > Red > Green > Blue (RGB).

1. Touch "LCD Check" on the Self Check menu.




d223c3109

White is the first color displayed.



d223c3110

2. Touch "Press to Next Color" in the center of the screen to display each color.




After the last color (blue) is displayed, the Self Check menu opens again.

Touch Panel Check

This simple check opens one screen.

1. Touch "Touch Panel Check" on the Self Check menu.




The detected position and nearest reference point is displayed for each of nine reference points on LCD screen.



d223c3113

The detected position and nearest reference point is displayed for each of nine reference points on LCD screen.


4

2. Touch  to return to the Self Check menu.

Touch Panel Calibration

Calibrate the touch panel by touching the center of each plus sign (+) as it appears on the LCD screen.

1. Touch "Touch Panel Calibration" on the Self Check menu.



d223c3114

The first plus sign appears at the top left corner of the screen.




d223c3115

2. After you touch the plus sign in the upper left corner, the next sign appears at the bottom right.



d223c3116

3. As you touch each plus sign, the next appears and waits for you to touch it.



d223c3117

After you touch the last sign (upper right), the message in the center of the screen prompts you to confirm the correct completion of the calibration, or to try again.

4. Press EX3 on the side of the operation panel to confirm and return to the Self Check menu.

-or-

Press EX1 to do the 5-point calibration again.




d223c3118

Multi Touch Calibration

Calibrate the touch panel for multiple tap entry such as "pinch-in" and "pinch-out".


1. Touch "Multi Touch Calibration" on the Self Check menu.



d223c3119

4


2. Touch the plus sign at the top left corner.



d223c3120


- The values of EVR_X, EVR_Y, X_MAX, and Y_MAX are for internal processing.
- These values do not indicate any positions or distances between touched points.
- There is no problem unless there is a large difference between the values of the first calibration pair and the second calibration pair.

1. Touch the plus sign at the bottom right corner.




d223c3121

2. Next, touch the plus sign at the top right corner again.



d223c3122

3. Now touch the plus sign at the bottom left corner again.



d223c3123

After you touch the last sign (lower right), a message at the bottom of the screen prompts you to confirm the correct completion of the calibration, or to try again.

↓ Note

- In the displayed prompt, the **Back** key is **EX1**, and the **Menu** key is **EX3**.

4. Press EX3 on the side of the operation panel to confirm and return to the Self Check menu.


-or-

Press EX1 to do the calibration again.

5. Detailed Descriptions

Overview

General Layout




d223c6002

No.	Part Name	No.	Part Name
1	Original Transport Unit	15	Relay Transport Unit
2	CIS Unit	16	Used Toner Unit
3	Original Feed Unit	17	Tray 3 PFU
4	Original Exit Unit	18	Tray 2 PFU
5	Drum Cleaning Unit	19	Tray 1 Unit (Tandem Tray)

No.	Part Name	No.	Part Name
6	Charge Corona Unit	20	Duplex Transport Unit
7	Laser Unit	21	Duplex Unit
8	Drum Unit	22	Inverter Unit
9	Toner Supply Unit	23	Exit Unit
10	Development Unit	24	Invert/Exit, Duplex/Transport Unit
11	Bypass Unit	25	Fusing Unit
12	Bypass Separation Roller	26	Fusing Cleaning Unit
13	Separation/Transport Unit	27	Scanner Unit
14	Vertical Paper Path		

Component Layout


Bypass Unit



d223d7000

No.	Part Name	No.	Part Name
1	Registration Sensor	6	Paper Length Sensor
2	Bypass Paper End Sensor	7	Bypass Size Sensor
3	Guide Plate Release Sensor	8	Guide Plate Release Solenoid
4	Bypass Pick-up Solenoid	9	Relay Sensor
5	Bypass Feed Clutch		

Optics




d223d7006

No.	Part Name	No.	Part Name
1	Scanner HP Sensor	8	Scanner Motor
2	Scanner LED (x2)	9	Synchronization Detection Board
3	ADF Open Sensor	10	Polygon Motor
4	Original Size Sensor (Length)	11	LD Unit
5	SBU	12	Polygon Motor Control Board
6	Development Unit Fan 2	13	Anti-Condensation Heater (Option)
7	Development Unit Fan 1		

Paper Feed Unit (PFU)

Each tray in the paper bank (Tray 1, 2, and 3) has an identical paper feed unit.




5

d223c6125

No.	Part Name	No.	Part Name
1	Feed Motor	5	Lift Sensor
2	Feed Sensor	6	Pick-up Solenoid
3	Vertical Transport Sensor	7	Reverse Release Solenoid
4	Paper End Sensor		


Electrical Components



d223d7007

No.	Part Name	No.	Part Name
1	Internal Temperature Sensor	8	Humidity Sensor
2	IOB	9	PSU Fan 1
3	Charge Power Pack	10	PSU Fan 2
4	AC Control Drive Board	11	AC Control Drive Board Fan
5	Development Power Pack	12	Paper Bank Lower Heater (Standard)
6	RYB (Relay Board)	13	Paper Bank Upper Heater (Standard)
7	PSU	14	Drum Heater (Option)


Tandem Tray



d223d7003

No.	Part Name	No.	Part Name
1	Left Tray Paper End Sensor	10	Tandem Left Tray Lock Solenoid
2	Front/Back Fence Release Sensor	11	Tandem Right Tray Lock Solenoid
3	Front/Back Fence Open Sensor	12	Left Tray Paper Sensor
4	Side Fence HP Sensor	13	Tray 1 Paper Height Sensor 1
5	Tray 1 Near End Sensor	14	Tray 1 Paper Height Sensor 2
6	Pressure Sensor	15	Tandem Tray Down Sensor
7	Side Fence Close Sensor	16	Tray 1 Paper Height Sensor 3
8	Side Fence Open Sensor	17	Front/Back Fence Open Solenoid
9	Side Fence Open Solenoid	18	Side Fence Motor

Around the Drum




d223d7008

5

No.	Part Name:	No.	Part Name:
1	Toner Bottle Motor	5	PTL (Pre-Transfer Lamp)
2	TD Sensor (Toner Density)	6	ID sensor
3	Toner End Sensor	7	QL (Quenching Lamp)
4	Charge Cleaning Motor	8	Potential Sensor


Sensors, Switches



d223c6127

No.	Part Name	No.	Part Name
1	Used Toner Lock Sensor	7	Tray 2 Paper Size Detection Switch
2	Used Toner Motor Sensor	8	Front Door Switch
3	Used Toner Motor	9	DC Switch
4	Used Toner Bottle Full Sensor	10	Proximity Sensor Control Board
5	Used Toner Bottle Set Sensor	11	Proximity Sensor
6	Tray 3 Paper Size Switch		

Motors, Fans




5

No.	Part Name	No.	Part Name
1	Heat Exhaust Fan	11	Tray 2 Lift Motor
2	Main Exhaust Fan	12	Tray 3 Lift Motor
3	Controller Fan	13	PFU Fan 1
4	Main Intake Fan	14	PFU Fan 3
5	Drum Fan	15	PFU Fan 4
6	Drum Motor	16	Duplex Fan
7	Development Motor	17	PCU fan
8	Registration Motor	18	Fusing Inner Cover Fan
9	Bypass Motor	19	Toner Bottle Fan


No.	Part Name	No.	Part Name
10	Tray 1 Lift Motor	20	Fusing Exit Motor

Transfer, Fusing, Exit Units



d223d7011

No.	Part Name	No.	Part Name
1	Transfer Power Pack	5	Fusing Exit Sensor
2	Transfer Separation Solenoid	6	Paper Exit Sensor
3	Paper Exit Junction Gate Solenoid	7	Exit Unit Entrance Sensor
4	Fusing Exit Knob Turn Sensor	-	-



d223d7012

D225


No.	Part Name	No.	Part Name
1	Fusing Thermistor - End (Contact Type)	5	Web Motor
2	Fusing Thermistor - Center (NC Sensor)	6	Web End Sensor
3	Fusing Thermostat (193°C)	7	Fusing Lamps (x2)
4	Fusing Thermostat (190°C)	-	-

D223/D224

No.	Part Name:	No.	Part Name:
8	Fusing Thermistor - End (Contact)	13	Web Motor
9	Fusing Thermistor - Center (NC Sensor)	14	Web End Sensor
10	Fusing Thermostat (192°C)	15	Fusing Pressure Release Sensor
11	Fusing Thermostat (200°C)	16	Fusing Pressure Release Motor
12	Fusing Thermostat (192°C)	17	Fusing Lamps (x3)

Duplex Unit

5




d223d7013

No.	Part Name	No.	Part Name
1	Duplex Transport Sensor 1	7	Duplex Invert Motor
2	Duplex Junction Gate Solenoid	8	Duplex Invert Solenoid
3	Duplex Transport Sensor 2	9	Duplex Jogger HP Sensor

No.	Part Name	No.	Part Name
4	Duplex Transport Sensor 3	10	Duplex Invert Exit Sensor
5	Duplex Horizontal Transport Motor	11	Duplex Entrance Sensor
6	Duplex Jogger Motor	-	-

ADF Unit




d223d7014


No.	Part Name	No.	Part Name
1	Feed Belt	13	CIS
2	Bottom Plate Position Sensor	14	Exit Sensor
3	Pick-up Roller	15	White Plate
4	Original Set Sensor	16	CIS Glass
5	Original Tray Lower Plate	17	Registration Sensor
6	Original Size Sensor	18	Scanning Entrance Roller
7	Output Tray	19	Interval Sensor
8	Lift Sensor	20	Original Width Sensor
9	Bottom Plate HP Sensor	21	Skew Correction Sensor

No.	Part Name	No.	Part Name
10	Exposure Glass	22	Separation Sensor
11	Exit Roller	23	Separation Roller
12	White Roller	24	Lift Interlock Switch

Paper Path




No.	Name	No.	Name
1	Proof Tray Exit	5	LCIT Paper Path
2	Cover Tray Path	6	Main Feed Path
3	Original Path (1 Pass Duplex)	7	Booklet Tray
4	Bypass Paper Path	8	Shift Tray



d223c6129

No.	Name	No.	Name
1	Original Path (1 Pass Duplex)	6	Booklet Tray Path
2	Bypass Paper Path	7	Shift Tray Exit
3	LCIT Paper Path	8	Proof Tray Exit
4	Main Feed Path	9	Mailbox Exit
5	Invert Exit Path	-	-

Motors




No.	Part Name	No.	Part Name
1	Scanner Motor	7	Tray 1 Feed Motor
2	Drum Motor	8	Used Toner Motor

No.	Part Name	No.	Part Name
3	Fusing/Exit Motor	9	Bypass Motor
4	Tray 3 Feed Motor	10	Bypass Feed Clutch
5	Tray 2 Feed Motor	11	Development Motor
6	Relay Transport Motor	12	Toner Supply Clutch

Scanner


Overview

Block Diagram



d223c6005

Cross Section



d223d7106

5

No.	Part Name	No.	Part Name
1	Scanner HP Sensor	8	SBU
2	2nd Mirror	9	Scanner Motor
3	3rd Mirror	10	Development Unit Fan 1
4	1st Carriage	11	1st Mirror
5	Scanner LED	12	2nd Carriage
6	Original Size Sensor (Length)	13	Anti-Condensation Heater (Option)
7	Lens Block		

Configuration


Scanner	Light source: LED (x2)
Scanner drive	SBU (3-line C-MOS image sensor, 600 dpi)
	Scanner motor (2-phase STM)
Original size detection	Length: One original size sensor Width: Line sensor (C-MOS image sensor)
	APS (Length sensor x1, Width sensors x2)
Other	Anti-condensation heater (option)

Mechanism

Scanner

The scanner unit uses LEDs as the light source. The lower power scanner LEDs [A] produce little heat, making them a cost effective, superior light source. Two LEDs are used to ensure there is enough stable light for the C-MOS image sensor to scan images. The LEDs illuminate the original, and then the light is reflected from the original to the 1st mirror [B] > 2nd mirror > 3rd mirror > scanner lens > C-MOS image sensor.

1st Mirror > 2nd Mirror > 3rd Mirror > Scanner Lens > C-MOS Image Sensor



- **Scanner LED**

The unit employs two high-intensity LEDs as the exposure lamp.

- **C-MOS Image Sensor**

The C-MOS image sensor converts the contrast of the light and shade of the original to three colors (RGB). This produces a high-resolution 600-dpi C-MOS image.

- **Shading Correction**


At power on, the exposure LED moves to the white plate for shading correction located behind the rear scale, switches on, and then determines the white peak level for the job. Regardless of whether the original image is monochrome or color, with this machine shading correction is done for every page during scanning. However, for continuous copy jobs the machine switches to shading correction at intervals (not every page) in order to maintain high production speed.

Scanner drive

A single scanner motor drives the timing belt, gears, pulleys, and wires that drive the scanner unit.

Original Size Detection

- Original size detection is triggered by the APS [A] when lowering the ADF switches the sensor from off to on.
- Original length is detected using one original size sensor [B].
- At the same time, pre-scanning is done so the C-MOS image sensor can detect the original width. At this time the scanner LED lights only one-third of the detection area near the front.
- If the Start key is pressed with the ADF (platen) is up (APS: OFF), the size of the previous original is used.




Sensor States

The combinations of the sensor states are used to determine the original size, and this data can be confirmed with **SP4-301-001**. The data for each detected size is displayed by **SP4-301-001** as shown below. Due to the layout of the sensors, paper sizes smaller than B5 cannot be detected, so in this case all zeroes are displayed (0000 0000).

Original Size Detection

[A] A4 SEF

[B] A4 LEF



5

A: A4 SEF

B: A4 LEF

Size	L1	SP4-301-001 Display
A3	On	00000001
B4	On	00000001
A4 SEF	On	00000001
A4 LEF	Off	00000000
B5 SEF	On	00000001
B5 LEF	Off	00000000
A5 SEF	Off	00000000
A5 LEF	Off	00000000


If the value detected by the C-MOS image sensor is more than "18" in the width direction as displayed by SP4-310-001 to 009, then the machine determines that an original is on the exposure glass. However, the value displayed is the result of the most recent reading.

SP4-310-001: Scanned value of R at S1 during original size detection.	Even if only one reading is more than 18 , it is judged that an original is at S1 .
SP4-310-002: Scanned value of G at S1 during original size detection.	
SP4-310-003: Scanned value of B at S1 during original size detection.	
SP4-310-004: Scanned value of R at S2 during original size detection.	Even if only one reading is more than 18 , it is judged that an original is at S2 .
SP4-310-005: Scanned value of G at S2 during original size detection.	
SP4-310-006: Scanned value of B at S2 during original size detection.	
SP4-310-007: Scanned value of R at S3 during original size detection.	Even if only one reading is more than 18 , it is judged that an original is at S3 .
SP4-310-008: Scanned value of G at S3 during original size detection.	
SP4-310-009: Scanned value of B at S3 during original size detection.	

Size	Feed	Size (LxW)	S1	S2	S3
A3	SEF	297x420	ON	ON	ON
B4	SEF	257x364	ON	ON	OFF
A4	SEF	210x297	ON	OFF	OFF
A4	LEF	297x210	ON	ON	ON
B5	SEF	182x257	OFF	OFF	OFF
B5	LEF	257x182	ON	ON	OFF
A5	SEF	148x210	OFF	OFF	OFF
A5	LEF	210x148	ON	OFF	OFF
B6	SEF	128x182	OFF	OFF	OFF
B6	LEF	182x128	OFF	OFF	OFF

Original Feed from ADF

With this new machine, there are some changes in the configuration of the original feed path from the ADF.



On this machine a step at [A] keeps the original separated from the contact glass as it feeds, while in the previous machine, shown on the right, the original touched the surface of the glass.

- In the new configuration because the original passes over the glass without touching it, there is less transfer of paper dust and other material from the original to the glass. This makes it more difficult for streaking due to transfer to appear in copies.
- In the previous configuration, because the original touched the surface of the glass as it passed, this cleaned material from the surface of the glass and prevented free-floating dust from collecting on the glass. This makes it more difficult for streaking due to free-floating dust to appear in copies.
- The incidence of streaking caused by transfer of dust from original to glass was thought to be greater in the old configuration than any streaking caused by free-floating dust in the new configuration, so the new configuration was adopted as standard for the new machine.

There are some important points to keep in mind about this new configuration:

- This new step strip which keeps the original above the glass must be attached correctly when the contact glass is replaced.
- When the step strip is installed, it must be aligned perfectly parallel with and attached to the left scale on the left side of the exposure glass.
- The new step strip can be removed to discard the non-contact feature if the operator prefers the older configuration with the original touch and sweeping the contact glass as it passes.

Dust Detection

Overview

Setting an original in the ADF and pressing the Start key triggers Dust Detection processing at the ADF scanning position.


Dust detection processing starts when the first page of the original starts to scan, and the scanned data is processed by the MACARON module where it is determined whether there is spotting or streaking in the image.

The operational flow is different depending on how the SP codes are set.

However, this is not done when in the large original mode, or when originals are feed into the ADF without pause while a long scanning job is in progress..

Related SP Codes


SP	Name
4-020-001	Dust Detect: On/Off: Front
4-020-002	Detection Level: Front
4-020-003	Correction Level: Front
4-020-001	Detect Level: Rear
4-020-012	Correction Level: Rear
7-852-001	DF Glass Dust Check: Dust Detection Counter
7-852-002	DF Glass Dust Check: Dust Counter Clear Counter
7-852-003	DF Glass Dust Check: Dust Detection Counter: Back



Shifting the Scanning Position

The scanning position can be shifted toward the front from the home position (default) at 0.7 mm, and then 1.4 mm (a total of three positions counting the home position). In the illustration below, the direction of shift is:

$a > b > c > a > b$.



w_d223c6007_eng

Scanner Anti-Condensation Heater

Condensation on the optics inside the scanner unit (specially the mirrors) caused by a rapid rise in temperature when the scanner unit is cold can cause images to blur, or turn black or gray. The scanner unit heater (option) is designed to eliminate these problems.



d223c6130

Every time the main machine is switched off, the scanner heater switches on.

Image Processing

Image Data Flow




Image Processing

Image Processing Flow

Image processing is done on the BICU and follows the direction of flow described below. However, unlike previous machines the image processing in this machine has been changed slightly so it is more suited for the content of the image. This greatly improves the quality of the image:

- Selective filter processing, based on the amount of image edge, results in sharper text characters and less moire in fill areas.
- There is also smoother texture with less granulation in flat areas of images.

Shading Correction	Corrects the dispersion of the scanning lens and C-MOS	
↓		
Gamma Correction	Background erase	
↓		
Auto Select	Determines if an image is text or raster image data and processes the data accordingly.	
↓		
Filtering	MTF and smoothing. Either of two filters is selected by Auto Select above.	
↓		
Independent Dot Erase	Removes isolated pixels.	
↓		
Line Width Correction		
↓		
Main Scan Magnification		
↓		
Video Path	Application (printer)	
↓		

Density Control	Employs one of two gamma tables, selected by Auto Select above
↓	
Grayscale Processing	Error diffusion, dithering, or binary picture processing. Black-and-white digitization or dithering is selected by Auto Select above.
↓	
LD Unit	

Manual Gamma Adjustment

Two adjustment settings are provided for each of these four IDmax categories:

- Text
- Gamma curves with independent highlights (H)
- Middle (M)
- Shadow (S).

Offset (H). Adjusts the density of bright areas of the original (highlights). A lower setting lowers density to create lighter image, a larger setting increases density to create darker image.

Offset (M). Adjusts the density in the middle of the original (middle). A lower setting lowers density to create lighter image, a larger setting increases density to create darker image.

Offset (S). Adjusts the density of dark areas of the original (shadows). A lower setting lowers density to create lighter image, and a larger setting raises density to create darker image.

Offset: IDmax . Adjusts the development density for the entire image. Adjusts density. A lower setting lowers density to create lighter image, and a larger setting raises density to create darker image.

Option (H). Adjusts the texture of image background. A lower setting subdues the background, and a larger setting enhances the background.

Option (M). Adjusts the contrast of the original. A lower setting reduces the contrast, and a larger setting increases contrast.

Option (S). Not Used.

Option (IDmax). Not Used.

SP Codes Related to Gamma Adjustments


The table below summarizes the settings of **SP4-918-009** (Manual Gamma Adjustment).

Item	Range/Default/Step
Copy: Photo 1-Color K Offset (Highlight)	0 to 30/15/1
Copy: Photo 1-Color K Offset (Middle)	0 to 30/15/1
Copy: Photo 1-Color K Offset (Shadow)	0 to 30/15/1
Copy: Photo 1-Color K Offset (IDmax)	0 to 30/15/1
Copy: Photo 1-Color K Option (Highlight)	0 to 255/0/1
Copy: Photo 1-Color K Option (Middle)	0 to 12/0/1
Copy: Photo 1-Color K Option (Shadow)	0 to 255/01/1
Copy: Photo 1-Color K Option (IDmax)	0 to 255/0/1
Copy: Text 1-Color K Offset (Highlight)	0 to 30/15/1
Copy: Text 1-Color K Offset (Middle)	0 to 30/15/1
Copy: Text 1-Color K Offset (Shadow)	0 to 30/15/1
Copy: Text 1-Color K Offset (IDmax)	0 to 30/15/1
Copy: Text 1-Color K Option (Highlight)	0 to 255/0/1
Copy: Text 1-Color K Option (Middle)	0 to 12/0/
Copy: Text 1-Color K Option (Shadow)	0 to 255/0/1
Copy: Text 1-Color K Option (IDmax)	0 to 255/0/1

Print Process (Main Engine Components)


Laser Unit

Block Diagram of Laser Unit



d223c6009

Laser Unit Components



d223c6010

No.	Name
1	Laser Unit
2	Polygon Motor
3	L1 Lens
4	L2 Lens
5	2nd Mirror
6	Main Scan Line
7	Drum (OPC)
8	Laser Synchronization Detector
9	Dust Prevention Glass
10	1st Mirror
11	L0 Lens
12	LD Unit

The laser unit is comprised of the LD unit and the line scan mechanism.

LD Unit

- Aluminum die-cast bracket.
- Semi-conductor laser.
- Wavelength: 659 nm output, 15 mW/ch
- Image writes with multi-beam (4 beam) laser.
- APC (Auto Power Control)
- Digital control.

Line scan mechanism


- Aluminum die-cast housing
- Line scanning by polygon mirror in Main Scan (horizontal) direction.
- Dot position enhancement by L1 lens.
- Laser beam angle adjustment by WTL

5

Laser Unit

The laser unit uses two 2-beam laser diodes that write four lines simultaneously.

The diodes are fixed at 1200 dpi so beam pitch adjustment is not required.



No.	Name
1	Photo Diode
2	LD Array
3	Aperture

No.	Name
4	Collimating Lens


APC (Auto Power Control)

A built-in PD (Photo Diode) detects the light emitted by the LD (Laser Diode). When the PD detects the light emitted from the LD, the PD sends an output signal to the LD control board, and then the feedback from this signal is used to fix the standard value for the strength of the laser. The LD unit is also non-adjustable so there are no LD power adjustments required after the LD unit has been replaced.

LD Safety Switch (Front Door Interlock Switch)

The front door is provided with a single interlock switch that disables the laser unit when the front door is opened. When the interlock switch opens, this cuts the 5V circuit to the LDB and disables it.

5



Laser Unit Control

The 600 dpi 10-bit scan data is converted to either 1200 dpi, 1-bit digital data, or 600 dpi/1-bit digitized data in the IPU on the BICU and then input to the laser control module of the ASIC. The converted data is then digitized through 35 levels of Pulse Width Modulation (PWM) to determine the strength of light exposure.

Line scan mechanism

The six facets of a polygon mirror, driven by a polygon motor, are used to expose the drum in the main scan direction. The polygon motor rotates constantly and stops only when the machine is off or in low power mode.

Multi-beam Scanning


The LD unit emits four beams simultaneously. There are three advantages to this multi-beam method.

- The service life of the polygon motor is extended because the rotation speed is reduced.
- There is less noise from operation of the polygon motor because the number of rotations is reduced.
- The modulation frequency of the LD unit is reduced.

The speed of the rotation of the polygon motor is different for each mode and line speed:

- Polygon motor rotations (D223/D224: 31,890 rpm 1200 dpi) **thick paper** line speed
- Polygon motor rotations (D223/D224: 42,756 rpm 1200 dpi) **normal paper** line speed
- Polygon motor rotations (D225: 49,606 rpm 1200 dpi)


The diagonal arrangement of the LD four beams from CH0 and CH2 at the front, and CH1 and CH3 at the rear achieves 1200 dpi resolution.



w_d223c6013_eng

Drum Unit

Cross Section of Drum Unit



d223c6014

No.	Name
1	Quenching Lamp
2	Drum Charge Unit
3	Toner Recycling Pipe
4	Potential Sensor
5	Development Sleeve
6	PTL
7	Drum (OPC)
8	Stripper Pawls
9	ID Sensor
10	Stripper Spurs
11	Toner Collection Coil

No.	Name
12	Brush Cleaning Roller
13	Pressure Release Filter
14	Cleaning Blade


Here is a summary of the main components and features of the drum unit:

- **OPC Drum.** Durable OPC Drum (100 mm dia.)
- **Quenching.** 16 red LEDs quench the charge from the surface of the drum.
- **Drum charge mechanism.** Scorotron grid charge wire charging and cleaning system.
- **Paper separation pawls.** Paper separation with pick-off spurs.
- **Cleaning mechanism.** Counter blade method.
- **ID sensor, Potential sensor.** Used for process control.
- **Drive unit.** A single drum motor drives both drum and drum cleaning mechanism.
- **Toner recycling mechanism.** Toner is retrieved and recycled in the development unit by suction through a recycling tube.

5

OPC Drum

The OPC drum has an open flange with large holes to permit air to flow through to cool the drum. The drum is also grounded with a brush at the back of the machine. Quenching is done with an array of 16 red LEDs.




d223c6015

No.	Name
1	Brush Ground
2	Drum (OPC)

Charge

The Scorotron method, a charge wire and grid, applies an even charge over the surface of the drum, Applying the same electrical potential to the grid and casing also ensures a uniform charge on the drum.




No.	Name
1	Drum Charge Unit
2	Drum Charge Power Pack (CG PP)
3	PTL
4	Drum (OPC)

In order to prevent poor quality images caused by a dirty corona wire, the charge unit is equipped with a wire cleaning mechanism. When the wire cleaner motor switches on, this moves the wire cleaning pad forward to clean the wire and then back to the home position.

Charge Wire Cleaning

The wire is cleaned every 5,000 prints.




No.	Name
1	Forward stroke – Cleaning
2	Rear stroke – Return without cleaning
3	Cleaner Pad
4	Charge Wire Cleaner Motor

PTL (Pre-Transfer Lamp)

The PTL improves paper separation and reduces the appearance of pawl marks on the leading edges of paper. In order to improve paper separation from the drum, the PTL switches on at the leading edge of the paper only when printing with normal or translucent paper in simple mode. The PTL does not illuminate for jobs that use OHP, index tab, thick paper or postcards.

- **On Timing.** Synchronized with registration motor on timing.
- **Off Timing.** Goes off when the leading edge of the paper has advanced 3 mm. However, this distance can be adjusted in the range 30 mm in 1 mm steps with an SP code.




d223c6018 :

No.	Name
1	PTL
2	Drum (OPC)

Paper separation pawls

The separation pawls are always in contact with the drum surface to separate paper that clings to the drum. The drum spurs of this machine are an improved design and are more efficient in separating paper from the drum. In order to prevent damage to the drum from the separation pawls as a result of constant contact, a small vibrating cam operates while the drum rotates to keep the pawls vibrating slightly and free on the drum surface.




d223c6019

No.	Name
1	Paper Separation Pawls
2	Vibrating Cam

Drum Cleaning mechanism

The cleaning blade skims toner from the surface of the drum, and then the drum cleaning roller brushes the loose toner into the toner collection unit, as both brush roller and drum rotate forward (clockwise). The toner collected from the drum is sent into the toner collection coil and then into the recycle pipe.




d223c6020

No.	Name
1	Cleaning Blade
2	Drum Cleaning Roller (Brush)
3	Toner Collection Coil
4	Agitator

A small cam vibrates the cleaning blade slightly to keep the blade loose on the surface of the drum so it does snag on the drum surface. At the end of every job, the drum motor stops and reverse rotates the drum briefly to remove any toner that has stuck to the edge of the cleaning blade. The arc of this reverse rotation is about 5 mm.

5



d223c6021


No.	Name
1	Rotating Cam
2	Cleaning Blade

Drum Cleaning Drive

The drum motor rotates the drum and drives the cleaning mechanism through a single gear train. A large flywheel on the shaft of the drum reduces jitter during drum rotation. The drum speeds are different for each model of this series:

- D223/D224 (Thick Paper 3, 4): 270 mm/sec.
- D223/D224 (Normal Paper, Thick Paper 3, 4): 362 mm/sec.

- D225: 420 mm/sec.




d223c6022

No.	Name
1	Drum Cleaning Coupling
2	Drum Motor
3	Flywheel
4	Drum Drive Coupling

Ozone Filters and Drum Cooling

As shown below, the machine is provided with fans that draw air through the flange of the drum and into the center to cool the drum as well as expel ozone from inside the machine.

- In order to reduce the amount of noise from the fans, the fans switch on when the machine is turned on, and then the fan operation and speed are synchronized with the operation level of the machine.
- The PCU fans are switched on and off when the machine is switched on and off to draw off the heat from the fusing unit and drum.
- The main intake fan also cycles on/off when the machine is switched on/off.



d223d7202


No.	Name
1	Main Intake Fan
2	Drum Fan
3	OPC Drum
4	PCU fan
5	Charge Corona Unit
6	Dust Filter

Toner recycling mechanism

The toner collected by the drum cleaning mechanism is sent through the recycling pipe to the toner separation unit in the hopper of the development unit.

- Reusable toner and waste toner are separated in the toner separation unit.

- The toner separation unit is driven by the toner transport coil.




d223c6023

No.	Name
1	Used Toner Transport Coil
2	Toner Separation Unit

Reusable and Unreusable Toner Separation Mechanism

Toner that can pass through the mesh inside the toner separation unit can be reused.

- A brush outside the mesh brushes away toner that collects on the mesh to prevent the mesh from clogging.
- Another brush roller inside the mesh pushes out the reusable toner from the collected toner.




d223c6024

5

No.	Name
1	Toner Recycle Pipe
2	Toner Separation Mesh
3	Reusable Toner

Clumps of toner that cannot pass through the mesh go into the toner collection unit. The used toner transport coil then carries them away and dumps them into the used toner bottle.



d223c6025


5

No.	Name
1	Used Toner

Used Toner Bottle

After toner from the transfer unit is moved by the transport coil, it is sent to the used toner bottle through the toner exit coil driven by the used toner motor.

- The toner in the toner separation unit that cannot be reused is also sent to the used toner bottle.
- If the used toner lock sensor detects that the used toner coil has become overloaded and cannot rotate, the drum motor continues to rotate for 3 sec., stops, and then the machine issues **SC495-00** (Toner Transport Unit Lock).
- The used toner motor rotation sensor monitors the rotation of the used toner motor, and if the motor stops rotation for more than 3 sec. then the machine issues **SC590-00** (Toner Motor Lock).
- The used toner motor and drum motor switch on at the same time. However, when the used toner bottle full sensor switches on, this means the torque on the rotation of the used toner motor has increased.
- When the used toner bottle full sensor signals that the toner bottle is full, the pressure on the toner exit coil shuts off the toner collection motor, and a message alerts the operator that the machine will shut down after 100 more copies.




d223c6026

No.	Name
1	Used Toner Motor Sensor
2	Used Toner Lock Sensor
3	Transport Coil (from Belt Transfer Unit)
4	Used Toner Motor
5	Used Toner Bottle
6	Transport Coil (from Toner Separation Unit)

The used toner bottle full alert is released when the full toner bottle is replaced by an empty bottle that activates the toner bottle set switch.

- If the used toner bottle is not installed correctly, the machine will issue SC496-00 (Used Toner Bottle Not Set).
- The capacity of the used toner bottle is 5,000 cc, equivalent to about 1,000K copies (A4 at 6% coverage).



No.	Name
1	Used Toner Bottle
2	Used Toner Bottle Set Sensor

Process Control

The machine uses process control to make adjustments to compensate for changes over time around the drum that can be caused by dirty optics, changes in the output of the charge corona unit, and deterioration of the drum sensitivity. Here is a description of what happens when the machine is turned on with the fusing temperature below 50°C (122F) (when process control is switched on with **SP3901**).

Settings Adjusted Around the Drum Automatically at Power On

Main SW ON (Fusing Temp. < 50C)	
V	
Pre-rotation starts (Until fusing temperature > 140C)	
V	

Potential sensor (Vb, Vg, LD control)	
V	
Adjust ID sensor Vsg	
V	
Adjust image density (Vref update, toner density control)	
V	
Pre-rotation cycle end	

5

Here are some important points to remember'


- Vref is raised by image density control, but toner density control is also performed to update toner density.
- These adjustments are used to determine toner supply, so it is very important that the developer be initialized with **SP2963** at machine installation and initialized with **SP2801** every time developer is replaced.

Automatic Setting Operation

ID sensor Vsg is adjusted (automatic adjustment) and Vref is updated for image density control. This controls the amount of light emitted by the ID sensor LED, and it is adjusted automatically in the range of $4.0 \pm 0.2V$. An SC is logged if the amount of light emitted by the LED cannot be set between the max./min. range after ID sensor calibration has started.

- After the development bias, drum charge grid, and laser diode (LD) power have been adjusted based on the readings of the potential sensor, the ID sensor reading is used to update the standard Vref for the TD sensor.
- The ID sensor pattern density is calculated (V_{sp}/V_{sg}), and based on this result, the value of Vref is retrieved from a lookup table and used to adjust the amount of shift for the standard Vref setting for the TD sensor.
- By adjusting the Vref setting, this sets the correct setting according to the reading of the current ID sensor pattern with reference to the toner supply to the development unit.
- However, if the ID sensor is not functioning correctly, Vref is not updated and the previous Vref is used to control toner supply.

This flowchart shows how potential sensor readings are used to adjust development bias, drum charge, and LD power.



- The development bias (Vb), charge grid voltage (Vg) and LD power are determined based on the potential sensor readings in the process shown in the flowchart above.
- In a case where the LD power cannot be determined, if the setting cannot be done after 25 attempts, then the value at initialization is restored (-127 and +127).

- LD power is adjusted for the sensitivity of the drum, which can be affected by ambient temperature and humidity, as well as long term weather changes, so it must be adjusted and controlled within a maximum and minimum range.
- If grid voltage (Vg) adjustment fails, the machine issues **SC411-01** and **SC411-02**.

Automatic Process Control


Automatic process control can be switched off/on with **SP3901** (Auto Process Control).

- Normally, automatic process control should be on (the default setting for **SP3901**)
- If automatic process control is switched off then the next time the machine is cycled off/on, the LD power will not be adjusted.
- If **SP3901** is switched on again then the machine once again enters the automatic process control mode with **SP2962** where the machine is automatically calibrated for the conditions around the drum.

5

Development Unit

Development Unit Cross Section




No.	Name
1	Development Filter

No.	Name
2	Toner Transport Coil
3	Agitator
4	TD Sensor
5	Paddle Roller
6	Development Sleeve
7	Back-spill Plate

Here is a summary of the development unit mechanisms and features.

- **Development Mechanism.** Dual, small diameter granulated components for dry electrostatic development.
- **Developer auger mechanism.** A paddle roller, developer agitator, separator, and transport coil mix and transport the developer and toner.
- **Development bias mechanism.** The development power pack supplies bias to the development unit.
- **Toner density control.** Toner density is monitored and controlled by the ID sensor and TD sensor.
- **Development Unit Drive Mechanism.** A single, dedicated motor drives the development unit.
- **Development Unit Pressure Release (D225 only).** A pressure release tube ensures air flow.

Toner Supply Unit



d223c6030

No.	Name
1	Toner Bottle
2	Shutter Lever
3	Shutter
4	Agitator
5	Toner Supply Roller
6	Toner End Sensor
7	Toner Bottle Motor

Here is a summary of the toner supply mechanisms and features.


- **Toner Transport Mechanism.** Toner inside the toner hopper on top of the development unit is moved from the front to the rear on the toner supply roller.
- **Toner end detection.** The toner end sensor (a pressure sensor) detects when there is no toner in the hopper.

- **Toner bottle shutter.** The toner bottle shutter prevents toner from spilling when the toner bottle holder is opened during toner bottle replacement.
- **Toner bottle supply mechanism.** A small toner bottle motor rotates the toner bottle.
- **Toner separation.** The toner separation mechanism separates paper dust and clumps from recycled toner.

Development Mechanism

In order to improve the quality of images, the development unit employs a single development roller sleeve, and a concentrated magnetic band inside the sleeve.

- The small diameter, pulverized toner is comprised of two components.
- The toner collected during cleaning can be recycled and used again, greatly reducing toner consumption.




d223c6031

No.	Name
1	Development Sleeve

Inside the Development Unit

The thickness of toner on the sleeve is controlled by the doctor blade. Excess toner flows to the back-spill plate on top of the development unit. From there, the Toner Transport Coil distributes the toner evenly from front to rear.

- The toner at the rear of the separator falls into the mixing vanes which move the toner from rear to front.
- New toner supplied to the development agitator is agitated by the paddle roller while it is being mixed with the developer.




d223c6032

5

No.	Name
1	Transport Coil
2	Development Agitator
3	Paddle Roller
4	Doctor Blade
5	Separator

Development Bias

The development power pack above the drum applies a negative charge (-550V) to the development unit which in turn passes this negative charge to the toner for its part in the development process. (-550 V). When bias is applied to the development sleeve roller, it is also applied to the lower casing and doctor blade to prevent toner back spill from the drum.




d223c6033

No.	Name
1	Development Sleeve
2	Development Bias Terminal

Development Unit Pressure Release (D225 only)

In order to relieve the build up of pressure inside the development unit, the development unit of the D225 is provided with pressure release tube [A].




d223d7205

Toner Supply

The readings of the ID sensor and TD sensor are used to control toner density by telling the machine when to switch the toner supply clutch on and off to control the supply of toner to the toner supply roller.

The toner supply roller has 8 grooves that catch the toner and then dump it into the development unit as the roller rotates.




d223c6034

5

No.	Name
1	Toner Supply Clutch
2	Toner Supply Roller

Development Unit Drive and Cooling


The development motor drives the development unit, toner supply mechanism, and toner separation mechanism. The knob attached to the paddle roller rotates in one direction only.



d223c6035

No.	Name
1	Toner Supply Drive
2	Manual Turn Knob
3	Development Coupling
4	Development Motor

Two large fans on the right side of the machine cool the development unit. These fans are set to switch on/off when the machine is switched on/off (the fans remain on for 10 sec. after the machine is switched off).




d223c6036

No.	Name
1	Development Unit
2	Development Unit Fan 1
3	Development Unit Fan 2

Toner Transport

Fresh toner from the toner bottle and reusable toner collected during drum cleaning are sent to the agitator where they are mixed with developer. A gear train operates the paddle drive when the toner supply clutch is on.




d223c6037

5

No.	Name
1	Toner Bottle
2	Agitator
3	Toner Supply Roller

Toner End Detection

The toner end sensor (a piezoelectric sensor sensitive to changes in pressure) at the front end of the development unit detects toner end. The machine is released from the toner end state by opening and closing the front door of the machine.




d223c6038

No.	Name
1	Toner End Sensor

Shutter Mechanism

When the toner holder is opened and the toner bottle is removed for maintenance, a self-sealing shutter closes automatically to prevent toner spillage. The top of the shutter has a semi-circular opening that normally allows toner to flow into the toner hopper.




d223c6039

No.	Name
1	Toner Shutter
2	Toner Hopper
3	Toner Port
4	Toner Bottle

Toner Bottle Supply, Toner Bottle Cooling

The toner bottle motor (DC motor) drives the gear that rotates the toner bottle.

- The operation of the toner bottle motor is controlled by the toner end sensor; when the sensor detects no toner in the hopper twice, it signals the motor to rotate the bottle for 1.1 sec.



5

No.	Name
1	Toner Bottle
2	Toner Bottle Motor
3	Toner Hopper

- In order to prevent toner from clumping in the toner bottle, the toner bottle cooling fan behind the toner bottle switches on/off when the polygon motor in the laser switches on/off.



d223c6131

Toner Supply Control

There are two toner supply control modes:

- Sensor Control
- Pixel Count

Either can be selected with **SP2208** with Sensor Control as the default, or normal operation mode).

Sensor Control Mode

In sensor control mode the machine uses the input of the ID sensor and the TD sensor: the TD sensor reads the toner density during development and the ID sensor reads the density of the toner on the drum. The purpose of monitoring the toner density is to keep a fixed amount of toner in the developer while keeping the density level suitable for the images being printed.

Here is a brief overview of toner density control:

1. The TD sensor reads the density of the toner in the developer for every copy. This reading is output by the TD sensor as V_t . V_t (the TD sensor reading) and V_{ref} (the targeted control reference voltage for the TD sensor) are used to calculate the value of the GAIN. (0, 1, 2, 3, 4).
2. The equation below is used to calculate the clutch ON time.

$$\text{Toner supply clutch} = \frac{(\text{GAIN} \times \text{Image pixel count} \times \text{Target density})}{\text{Toner supply rate}}$$

w_d223c6133_eng

Where, if GAIN = 0, startup time of 16 ms is reset to 0.

- Image pixel count: The density for every dot in the output data for the page is calculated (Example: 255 for A3).
 - Target density: 0.7 mg/cm²
 - Toner supply: 850 mg/s (This default setting can be adjusted with SP2209).
 - Clutch startup time: 16 ms (The actual time required for the toner to reach the hopper after the clutch turns on.)
3. At 10-copy intervals (adjustable with SP2210) and at job end the ID sensor measures V_{sg} , V_{sp} .
 4. V_{ref} (target reference voltage) from the TD sensor is updated with the new readings of V_{sp} , V_{sg} .

Pixel Count Mode

The ON time is calculated with the same formula described above, but the GAIN value is fixed at 0.7.

TD Sensor Reference Voltage

The TD sensor reference voltage must be initialized the first time the development unit is filled with developer at machine installation and every time the developer is replaced. The sensor control voltage is adjusted until the output is $3.0 \pm 0.1V$, and after the control voltage is set, V_t is sampled 100 times, and then these samplings are averaged and used to set the standard reference value for V_t .

Here are some important points to remember:

- After the developer has been replaced, it must be initialized with **SP2801**.
- After the TD sensor has been replaced, it must be initialized with **SP2801**.
- If a partially used development unit from another machine is installed, open **SP2220** (Vref Manual Setting) on the loan machine to display the Vref value of the TD sensor, and then enter this value in the other machine with the same SP. Next, open **SP2906** (TD Sensor Control Voltage Setting) to display the setting, and then enter this setting on the other machine with the same SP.
- These initial settings are stored in NVRAM. Before replacing an NVRAM, always print an SMC report so you can read the settings off the report and enter them manually after NVRAM has been replaced.

5

Abnormal TD Sensor Output

If a problem occurs with the TD when developer is initialized:

- SC codes are issued and the machine will display the immediately previous value of **SP2906** (TD Sensor Control Voltage Setting).
- If V_t is "0" then the machine returns **SC360-01**.
- After the start of adjustment, if the TD sensor output does not enter the target range of $V_t = 3.0 \pm 0.1V$ within 20 sec., the machine returns **SC360-11**.

If a problem occurs with the TD sensor during a print job, one of the following conditions has been detected:

- TD sensor output V_t is 0.5V or lower (**SC362-00**).
- TD sensor output V_t is 4V or higher (**SC361-00**).

The SC code is logged, and the toner supply moves into the ID Sensor Supply Mode + Pixel Count Mode, or the Pixel Count Mode (using ID sensor reading as reference).

ID Sensor Control

At power on, or after the specified number of prints (Default: 10) and at job end, the ID sensor reads the ID sensor pattern on the drum. The purpose of the ID sensor reading is to calculate the ID sensor pattern density (V_{sp}/V_{sg}) and then use this result to determine the target reference voltage of the TD sensor. The timing of when these ID sensor patterns are created on the drum is controlled by turning process control on/off in the SP mode.

When process control is on and the potential sensor output is normal:

- Drum charge grid voltage is set automatically, based on conditions around the drum.
- LD power is set automatically, based on conditions around the drum, and on the reading of a Vh pattern (reading of half-tone) on the drum.
- The potential sensor checks the development bias voltage when the ID sensor pattern is created (Target: -240V set by **SP2201-004**).

If process control is off, or if the potential sensor is defective:

- Charge corona grid voltage is set to the previous successful process control value
- LD power is set to the previous successful process control value.
- Development bias is set to the previous successful process control value.

↓ Note

- For operators who are concerned about changes in toner density during long, continuous copy jobs, the machine can be set to create ID sensor patterns during long jobs by switching on **SP2507-001**, and then setting the interval for pattern creations with **SP2507-002**. However, if an interval is set for ID sensor pattern creation and sampling during long jobs, this could cause delays at 2 or 3 sec. intervals and lower productivity of the machine.

5

Both TD Sensor and ID Sensor Abnormal


If the output of both of these sensors is abnormal during toner supply, toner supply mode will change.

- When the TD sensor and ID sensor are both operating normally, both sensors are used during toner supply control.
- If only the TD sensor fails, then ID sensor output is used with Pixel Count.
- If only the ID sensor fails, then TD sensor output is used.
- If TD sensor and ID sensor both fail, then only Pixel Count is used.

SC codes are issued with the failure of either the TD sensor or ID sensor.

Toner Near-End Control


The toner end detection and control sequence is described in the flowchart below. The machine can continue to print up to 1,000 sheets (A4 at 6% coverage) after the toner near-end alert is issued.



Toner End Recovery

At toner near-end the toner bottle is nearly empty and can be replaced.


- When the front door is opened and closed, the machine attempts to recover on the assumption that the bottle has been replaced.
- The description below is based on the assumption that front door has been opened and closed after the toner near-end or toner end alert appeared.



w_d223c6043_eng

Transfer Belt Unit

Overview



5

No.	Name
1	Transfer Belt
2	Transfer Bias Roller
3	Belt Idle Roller
4	Separation Lever
5	Agitator
6	Toner Collection Coil
7	Cleaning Blade
8	Belt Drive Roller
9	Cleaning Bias Roller

Here is a summary of the transfer belt unit mechanisms and features:

- **Image Transfer and Paper Separation Mechanism.** A system wherein a bias roller applies an electrostatic charge to a transfer belt of moderately low resistance. A wide transfer belt compatible with many types of paper and that generates no ozone is used.
- **Transfer Belt Lift Mechanism.** Job timing controls the DC solenoid that raises and lowers the transfer belt unit.


- **Drive and Paper Transport Mechanism.** The drum motor rotates the gear and roller that drives the transport belt that carries the paper.
- **Transfer Belt Cleaning Mechanism.** A counter blade, cleaning bias roller, and bias roller cleaning blade comprise the transfer belt cleaning mechanism.
- **Transfer Belt Release Mechanism.** The easy-to-operate belt release makes paper jam removal easy.
- **Transfer Belt Anti-Slip Mechanism.** Roller ends are tapered to prevent belt slippage.
- **Anti-Condensation Mechanism.** A single heater (option) installed below the belt unit.

Transfer Separation Mechanism

Each sheet of paper is fed as far as the registration roller. This is timed so that the leading edge of the sheet reaches the leading edge of the image on the surface of the drum above.

5

- Normally, the transfer belt remains separated from the drum.
- The transfer separation solenoid switches on and raises the transfer belt when the registration sensor detects the leading edge of the first sheet, and then the belt remains up until the end of the job.




d223c6045

No.	Name
1	Transfer Belt
2	Drum (OPC)
3	Registration Roller

- When the paper approaches the point where the leading edge of the paper on the belt will come into contact with the drum above, the transfer belt lift solenoid raises the separation lever so the belt comes into contact with the drum above.

- This creates a nip between the belt and drum about 8 mm wide.




d223c6046

No.	Name
1	Separation Lever

Image Transfer Mechanism

When the paper enters the nip between belt and drum, the transfer bias roller applies a negative bias charge to the belt. This pulls the toner with a positive charge from the drum onto the paper.

- The transfer belt is of moderately low resistance, so the belt and electrical charge on the belt is neutralized with the movement of toner from drum to belt.
- The transfer power pack inside the transfer belt unit applies the high bias charge to the transfer bias roller.
- This transfer system is controlled with a constant voltage system that ensures stable image transfer and paper separation for a variety of paper in variable ambient conditions which can cause changes on the surface of the low resistance belt.




d223c6047

No.	Name
1	Transfer Bias Roller
2	Transfer Power Pack

Transfer Bias Charge Mechanism

The transfer power pack inside the transfer belt unit applies the charge (Max. +7.0 KV) to the bias roller.

- The power pack divides the charge and also applies a charge (Max. 1000V) to the terminal of the cleaning bias roller.
- The belt drive roller and idle roller are grounded to improve the efficiency of cleaning.



No.	Name
1	Transfer Bias Roller
2	Transfer Bias Terminal
3	Transfer Power Pack
4	Transfer Belt Idle Roller
5	Ground Terminal
6	Cleaning Bias Terminal
7	Transfer Belt Drive Roller

No.	Name
8	Cleaning Bias Roller


Transfer Belt Lift

The transfer belt lift solenoid inside the transfer belt unit is switched on by job timing to raise the belt against the drum. Springs are attached to the front of the solenoid to apply pressure in the direction of lift to reduce the load placed on the solenoid.

Normally, the transfer belt remains separated from the drum for the following reasons:

- The transfer belt would rub the ID sensor patterns off the surface of the drum.
- Cleaning ID sensor patterns from the surface of the belt would put an extra load on the belt cleaning mechanism.
- If the transfer belt and drum were in constant contact this would cause the materials from the belt to stick to the drum and increase wear on both drum and belt.

5




No.	Name
1	Transfer Separation Lever (Rear)
2	Separation Lever
3	Transfer Separation Lever (Front)
4	Transfer Separation Solenoid

Transfer Belt Drive and Paper Transport Mechanism

The drum motor drives the belt and gears that rotate the transfer belt drive roller.

- The electrostatic charge on the belt holds the paper on the belt while the drive roller drives the belt.

- The electrical charge on the belt is discharged, to make the separation of paper from the belt at the drive roller much easier.



d223c6050


5

No.	Name
1	Transfer Belt Driver Roller
2	Center Connecting Gear

Transfer Belt Cleaning Mechanism

While the job timing keeps the transfer belt and drum in contact as paper passes between them, paper dust and toner from blank areas on the paper can adhere to the surface of the drum above and then pass on to the transfer belt below.


- The positive charge applied to the cleaning bias roller can pull the negatively charged toner and paper dust away from the belt and onto the bias roller blade.
- The cleaning blade in direct contact with the belt also scrapes away toner and paper dust, the collected toner and dust are dumped into the toner collection coil and transported to the rear of the machine, and then are sent to the used toner bottle.



No.	Name
1	Drive Roller
2	Cleaning Blade
3	Cleaning Bias Roller
4	Idle Roller
5	Toner Collection Coil
6	Agitator

Transfer Belt Release Mechanism

Rotating the C1 release lever to the left lowers the drive roller clockwise to release the belt. Lowering the transfer belt lets the operator easily remove paper jams, and allows the service technician to service the machine much easier, especially when removing and reinstalling the drum unit.




No.	Name
1	Transfer Pressure Arm

No.	Name
2	Separation Lever

Anti-Condensation Heater (Option)

If the drum heater (option) is installed below the transfer belt unit and drum, it will switch on every time the main unit is switched off to prevent condensation from forming around the transfer belt and drum while the machine is idle.



d223c6054

No.	Name
1	Drum Heater

Image Transfer Current Settings

Here is a list of the default electrical current settings for optimal image transfer to paper from each paper station.

Optimal Transfer Current Settings

Conditions	Transfer Current (Default)	SP No.
Tray 1 (Front Side)	D223/D224, 75uA D225 85uA	2-301-001
Tray 2 (Back Side)	D223/D224 75uA, D225 85uA	2-301-002
Bypass Tray (Front Side)	D223/D224 80uA, D225 90uA	2-301-003

Conditions	Transfer Current (Default)	SP No.
Postcard (Back Side)	165 μ A	2-301-004
Paper Interval	15 μ A	2-301-005

Paper Line Speed Mode Transfer Current Settings (D223/D224 Only)

Conditions	Transfer Current (Default)	SP No.
Thick 3 (Front Side)	D223/D224:100 μ A	2-301-145
Thick 3 (Back Side)	D223/D224:100 μ A	2-301-146
Thick 4 (Back Side) Japan only	D223/D224:100 μ A	2-301-149


- In order for the machine to recognize postcard size, the bypass side fences must be set to A6 width.
- Bias is applied to the intervals between paper edges to improve the efficiency of belt cleaning.
- Not done at job end, or when process control is executing to automatically compensate for ambient conditions around the drum.

The transfer output is set for 2.6 KV (constant voltage) while the main motor is on, and the cleaning bias is set for 1000V for transfer belt cleaning.

Fusing Unit

Overview


D223/D224 (Three Fusing Lamps)



d223c6056

No.	Part Name:	No.	Part Name:
1	Paper Exit Sensor	10	Cleaning Web
2	Exit Unit Entrance Sensor	11	Pressure Spring
3	Pickoff pawls	12	Entrance Guide Plate
4	Hot Roller	13	Pressure Roller
5	Thermostats (190C/200C)	14	Pressure Arm
6	Thermistor (Contact x1, NC x)	15	Pressure Roller Cleaning Roller
7	Fusing Lamp (100V 700W)	16	Fusing Unit Paper Sensor
8	Fusing Lamp (50V 750W)	17	Exit Junction Gate
9	Fusing Lamp (100V 550W)	-	-

D225 (Two Fusing Lamps)



d223c6055

No.	Part Name:	No.	Part Name:
1	Paper Exit Sensor	10	Cleaning Web
2	Exit Unit Entrance Sensor	11	Pressure Spring
3	Pickoff pawls	12	Entrance Guide Plate
4	Hot Roller	13	Pressure Roller
5	Thermistor (Non-Contact Type)	14	Pressure Arm
6	Thermostats (190C/193C)	15	Pressure Roller Cleaning Roller
7	Thermistor (Contact Type)	16	Fusing Unit Paper Sensor
8	Fusing Lamp (100V 400W)	17	Exit Junction Gate
9	Fusing Lamp (100V 800W)		

Here is summary of the mechanisms and features of these fusing units.

- **Fusing.** Finely lubricated heat roller system.
- **Fusing Pressure.** Pressure roller and spring mechanism
- **Pressure Application Method (D223/D224 Only).** A pressure release mechanism prevents the pressure roller from being permanently warped.
- **Fusing Unit Drive.** Fusing exit motor and drive belt
- **Fusing Pressure.** Spring mounted on cleaning roller

- **Temperature Control.** Hot roller center fusing lamp, hot roller end fusing lamp heated by DC fusing lamp. (The DC fusing lamp is provided on the D22/D224 only.)
- **Hot Roller Cleaning Web.** Web roller applies a thin coat of oil for lubrication and cleaning.

More About the Fusing Unit


The fusing unit employs two fusing lamps inside the hot roller, an end fusing lamp (D223/D224 700W, D225 400W) and a center fusing lamp (D223/D224 550W, D225 800). The D223/D224, however, are provided with an additional auxiliary fusing DC lamp (750W) to prevent a drop in fusing temperature during long jobs for a total of three lamps.

D223/D224

- The surface of the roller is thin (0.7 mm) so it can reach standby temperature within 10 sec. of startup.
- The pressure roller surface is a soft, pliable bubble like material that creates a nip of optimal width against the hot roller.
- The center thermistor is a non-contact thermistor, but the end thermistors contact the hot roller to achieve more precise fusing temperature control.
- The end thermistors are located far enough away from the ends of the roller so as to not interfere with image fusing.
- The stripper pawls are the same as those on the D225, making it easier to service all models with the same replacement pawls.

D225

- In order to maintain fusing ability, the hot roller coating is 5 mm thick and the diameter of the roller is 50 mm.
- In order to achieve standby temperature within 300 sec. after startup, the center thermistor is a non-contact type.
- The end thermistors are contact type.




d223d7302

No.	Part Name
1	Fusing Thermostat (190C)
2	Fusing Thermostat (193C)
3	Fusing Center Thermistor (Non-Contact Sensor)
4	Fusing End Thermistor (Contact)

D223/D224

- The surface of the hot roller coating is thin (0.7 mm) so it can reach standby temperature within 10 sec. of startup.
- The pressure roller surface is a soft, pliable bubble like material that creates a nip of optimal width.



d223d7301


5

No.	Part Name
1	Fusing Thermostat (192C)
2	Fusing Thermostat (200C)
3	Fusing Thermostat (192C)
4	Fusing Center Thermistor (Non-Contact Sensor)
5	Fusing End Thermistor (Contact)

Fusing Pressure Mechanism

Large springs apply pressure to the front and rear ends of the pressure roller to create the fusing pressure between pressure roller and hot roller.

- The springs are attached to the pressure arms below both ends of the pressure roller, pulling the pressure roller up against the hot roller.
- The pressure exerted by the pressure roller can be released easily in order to service the fusing unit.
- There are two holes on each pressure arm, and normally the springs should be attached to the lower holes, but the ends of the springs can be set in the upper holes for printing on extremely thin paper.




No.	Name
1	Hot Roller
2	Pressure Roller
3	Pressure Arm

5

Pressure Application (D223/D224 Only)

This mechanism ensures that the shape of the pressure roller does not become distorted:

- At power on, the pressure roller HP sensor activates and keeps the pressure roller at rest away from the surface of the hot roller.
- At the start of a job, the pressure roller moves up against the hot roller.
- After the last sheet exits at the end of a job, the pressure roller pulls away from the hot roller.
- If there is no next job, the pressure roller remains away from the hot roller.
- If a paper jam or SC error occurs during a job, the hot roller and pressure roller stop, and then the pressure roller pulls away from the hot roller.



d223c6060


5

No.	Name
1	Hot Roller
2	Pressure Roller
3	Pressure Roller Spring
4	Pressure Arm
5	Fusing Pressure Release Sensor
6	Fusing Pressure Release Motor

Fusing Safety Devices

The fusing units are provided with thermostats that trip the power supply to the fusing unit if the unit overheats. Always pay attention to the placement of thermostats when they are replaced.

The D225 has two thermostats, and the D223/D224 has three thermostats.




d223c3335

Entrance Guide Height Adjustment

The height of the entrance guide can be adjusted with screws.

- Remove the screws and move them to the inner holes to lower the guide for paper smaller than A4 or thin paper that wrinkles easily.
- For sheets larger than A4 that wrinkles easily, move the screws to the outer positions.
- The screws are set at the outer holes before the machine leaves the factory (default positions).




d223c6061

No.	Name
1	Entrance Guide

Fusing Drive Mechanism

The fusing exit motor drives the drive belt that rotates the fusing unit drive coupling.

This coupling on the rear end of the fusing unit engages automatically when the unit is pushed into the machine.



d223c6062

No.	Name
1	Fusing Exit Motor
2	Fusing Unit

Temperature Control for Special Paper

The method of fusing temperature control for special paper is determined by the type of paper (OHP, thick paper, etc.) selected on the operation panel by the operator.

- For OHP sheets fed from the bypass tray, the initial setting is 210°C, and 220°C for Thick Paper. This can be adjusted with **SP1105-001**.
- CPM Down Mode (CPM=Copies per Minute) adjusts the speed for Thick Paper in long print jobs. The fusing temperate for CPM Down Mode can be adjusted with **SP1901-001**.

Fusing Temperature Control

When the machine is switched on, the fusing lamps are switched on and off to heat the hot roller (on/off control). During printing or copying, however, the hot roller is heated using phase control.

- Copying/printing will be possible within 30 sec. as soon as an ambient temperature of 15°C (59°F) or higher is detected, but at less than 15°C it will take 20 sec. for the D225 to reach standby temperature and 300 sec. for the D223/D225.
- These temperature readings are done by the temperature/humidity sensor located in the center of the machine, near the laser unit.

CPM Down Mode

At low ambient temperature (less than 15°C (59°F)):

- CPM is reduced 80% (Example: 65 CPM to 52 CPM)
- CPM is restored to 100% when hot roller temperature rises to 160°C +3°C.

At temperature below 165°C during a job at normal ambient temperature:

- CPM is reduced 80% (Example: 65 CPM to 52 CPM)
- CPM is restored to 100% when hot roller temperature rises to 160°C +3°C.

5

Important Related SP Codes

To Reduce Back Side Paper Curl During Duplex Printing

- **SP1102-001** Fusing Temperature Adjustment - Duplex Actual Temperature (Default: None). The temperature for fusing control is calculated based on the values of **SP1102-2** (Center) and **SP1102-002** (End) in order to reduce back curl (paper curl toward back side of the paper).


To Improve Fusibility

- **SP1901-001** CPM Down Setting for Special Paper - Thick Paper 1, 2 (Default: 40 cpm)
- **SP1901-005** CPM Down Setting for Special paper - Thick Paper 3 or More (Default: 40 cpm). If fusibility is low, CPM can be lowered to 35 or 25. At this time **SP1907-001** (Thick Paper 1, 2) or **SP1907-009** (Thick Paper 3 or More), the "Pre-Fusing Idling Time" setting can be switched on to improve fusibility. However, this setting increases the amount of time to reach standby temperature and will slow down the line speed.
- **SP1901-002** CPM Down Setting for Special Paper - Tab Sheet (Default: 25 cpm). Turning "Pre-Fusing Idling Time" on can significantly improve fusibility.
- **SP1901-003** CPM Down Setting for Special Paper - Label CPM (Default: 25 cpm). Turning "Pre-Fusing Idling Time" of **SP1907-007** on can also significantly improve fusibility.
- **SP1925-001 to 004** Idling Setting (001 Medium Thick "On", 002 Thick "Off", 003 Normal 1 "Off", 004 Normal 2 "Off"). The pre-fusing idling time done immediately after the machine is turned on at the start of the work day can improve fusibility. The machine enters fusing idling mode if the center thermistor returns a reading lower than 60°C (140°F) at startup. If the reading is more than 60°C, pre-fusing idling is not done. However, the maximum wait is 60 sec.

Temperature Sensor Fan Control

The readings of a new temperature center mounted near the center of the machine are used to control the cooling fans and operation of the machine. Also, these temperature readings are used to control the speed of rotation of the main intake fan, main exhaust fan, and heat exhaust fan.


Fans Controlled by Temperature Sensor



d223d7010b

No.	Part	No.	Part
1	Heat Exhaust Fan	6	Duplex Fan
2	Main Exhaust Fan	7	PCU Fan
3	Controller Fan	8	Fusing Inner Cover Fan


No.	Part	No.	Part
4	Main Intake Fan	9	Toner Bottle Fan
5	Drum Fan		



5

d223d7007a

No.	Part
10	PSU Fan 1
11	PSU Fan 2
12	AC Drive Board Fan



d223d7006a

5

No.	Part
13	Development Unit Fan 1
14	Development Unit Fan 2

Fan Speed Control by Temperature Sensor

Main Exhaust Fan

Critical Temp.	Operation Parameters (SP Codes)
Up to 20°C (68°F)	SP1956-001 Exhaust Fan Duty Adj. Silent [0 to 100/ 20 /1%]
20°C to 35°C (68°F to 95°F)	SP1956-002 Exhaust Fan Duty Adj. Low Speed [0 to 100/ 20 /1%]
35°C to 37°C (95°F to 98.6°F)	SP1956-003 Exhaust Fan Duty Adj. Mid Speed [0 to 100/ 20 /1%]
Above 37°C (98.6°F)	SP1956-004 Exhaust Fan Duty Adj. High Speed [0 to 100/ 20 /1%]

Critical Temp.	Operation Parameters (SP Codes)
Print Status	SP1956-005 Exhaust Fan Duty Adj. Printing [0 to 100/ 35 /1%]

Main Intake Fan

Critical Temp.	Operation Parameters (SP Codes)
Up to 20°C (68°F)	SP1957-001 Intake Fan Duty Adj. Silent [0 to 100/ 30 /1%]
20°C to 35°C (68°F to 95°F)	SP1957-002 Intake Fan Duty Adj. Low Speed [0 to 100/ 50 /1%]
35°C to 37°C (95°F to 98.6°F)	SP1957-003 Intake Fan Duty Adj. Mid Speed [0 to 100/ 60 /1%]
Above 37°C (98.6°F)	SP1957-004 Intake Fan Duty Adj. High Speed [0 to 100/ 70 /1%]

5

Heat Exhaust Fan

Critical Temp.	Operation Parameters (SP Codes)
Up to 20°C (68°F)	SP1958-001 Heat Exhaust Fan Duty Adj. Silent [0 to 100/ 30 /1%]
20°C to 35°C (68°F to 95°F)	SP1958-002 Heat Exhaust Fan Duty Adj. Low Speed [0 to 100/ 30 /1%]
35°C to 37°C (95°F to 98.6°F)	SP1958-003 Heat Exhaust Fan Duty Adj. Mid Speed [0 to 100/ 40 /1%]
Above 37°C (98.6°F)	SP1958-004 Heat Exhaust Fan Duty Adj. High Speed [0 to 100/ 45 /1%]

Relate SP Codes

SP	Name, Function	Settings
2972-001	Toner Bottle Fan Setting – Force Operation Switches toner bottle fan control off/on	[0 to 1/0/1 Step] 0: Operates fan based on engine operation and temperature sensor readings. 1: Fan always operates regardless of machine mode when it would normally be off (standby, low power mode, etc.)
2974-001	Drum Fan Setting – Force Operation Switches drum fan control off/on	0 to 1/0/1 Step] 0: Operates fan based on engine operation and temperature sensor readings. 1: Fan always operates regardless of machine mode when it would normally be off (standby, low power mode, etc.)
2976-001	Development Unit Fan 1, 2 – Force Operation Switches development unit fan control off/on.	0 to 1/0/1 Step] 0: Operates fans based on engine operation and temperature sensor readings. 1: Fans always operates regardless of machine mode when they would normally be off (standby, low power mode, etc.)
2978-001	Fan Time Extension Setting Extends fan operation time at job end.	[0 to 255/0/1 min.] Fans normally turn off at job end, but the length time the fans remain on after job end can be extended with this SP.
9540-001	Temperature Control Switch Setting – Sensor Detection DFU (for Design and Factory Use only). Normally not adjusted in the field.	[0 to 4/0/1] Sets fans to always operate within a fixed temperature ranged, defined by the operator. 0: Normal 1: Up to x°C 2: x°C to y°C 3: y°C to z°C 4: Above z°C


Paper Transport

Paper Feed Units (PFU)

Overview

Each paper bank has an independent, identical paper feed unit (PFU). The universal paper trays also have identical components.

- The PFUs are also provided with two grip rollers for handling thick paper.
- The bypass paper feed unit also employs the FRR (Feed and Reverse Roller) paper feed mechanism.



d223d7409

No.	Part Name
1	Tray 1 (Tandem Tray)
2	Grip Roller
3	Lower Grip Roller

No.	Part Name
4	Feed Roller
5	Separation Roller
6	Pick-up Roller
7	Tray 2 (Universal Tray)
8	Tray 3 (Universal Tray)

Here is a summary of the PFU mechanisms and features.

Paper Bank

- **Paper Separation and Feed.** The FRR system employs a maintenance free, nip release torque limiter in the separation roller. Driven by the feed motor.
- **Tray Movement.** A lift motor raises and lowers the bottom plate. Pulling out a paper tray disengages a coupling at the back of the tray and this lowers the bottom tray automatically.
- **Paper Stack Height Detection.** The lift motor can detect paper near-end and trigger a paper near-end alert.
- **Paper End Detection.** A reflective photo-interrupter sensor detects paper end (paper out).
- **Paper Size Detection.** For Tray 1 (tandem tray) SP5959-001 must be set for the size of the paper loaded in the tray. The universal trays have actuators connected to the side fences that will activate switches in a 5-switch array, indicating the size of the loaded paper.
- **Vertical Paper Feed.** Each PFU has a grip roller that pulls the paper fed out of the tray by the feed roller and sends it into the vertical paper path.
- **Tray Set Mechanism.** Each tray locks in place automatically when pushed into the machine.
- **Anti-Condensation.** Two paper bank heaters are provided as standard equipment with the machine.
- **Tandem Tray.** The left tray of Tray 1 has a mechanism that can move a stack of paper into the right tray.

Bypass Feed

- **Bypass Feed Tray.** The bypass feed tray which can be opened and closed against the right side of the machine can hold up to 100 sheets of paper.
- **Paper Separation and Feed and Separation.** A maintenance free torque limiter (slip clutch) is employed in an FRR (Feed and Reverse Roller) system. Driven by bypass feed motor and bypass feed clutch.
- **Paper End Detection.** A drop feeler and photo-interrupt sensor comprise the paper end detection mechanism.

- **Paper Size Detection.** Side fences set against the side of the stack detect paper size. A new paper length sensor detects paper length as it feeds.


Paper Registration and Transport

- **Registration and Transport Mechanism.** Paper from each of four paper feed stations (paper banks, bypass feed tray, duplex unit, LCIT) is guided to the same paper registration unit. In order to make it easier to remove paper jams, jammed sheets can be removed from the area between the registration rollers and the entrance to the duplex unit.
- **Paper Dust Collection.** A mylar sheet extends below the registration roller to collect paper dust.
- **Paper Transport Drive Layout.** Each PFU is equipped with its own paper feed motor (DC motor).

Tray Paper Feed Drive

Paper Feed From Tray 1

- There are two paper feed motors in Tray 1 (tandem tray).
- In Tray 1 and Tray 2, both motors work together when feeding from either tray.
- This change was implemented to provide more drive power during paper feed.



d223c6064


Tray 1 (Rear View)

No.	Part
1	Tray 1 Grip Roller
2	Tray 1 Feed Roller
3	Tray 1 Reverse Roller
4	Belt
5	Tray 1 Lower Motor
6	Tray 1 Upper Motor

Tray 1 Paper Feed

- The upper motor turns clockwise and rotates the pick-up and feed rollers.
- The reverse roller does not turn at this time because it has a one-way clutch.
- The lower motor turns counter-clockwise, and the belt drives the grip roller and reverse roller.

Paper Feed From Tray 2



d223c6065

5

Tray 2, Tray 3 (Rear View)


No.	Part
1	Tray 2 Grip Roller
2	Tray 2 Feed Roller
3	Tray 2 Reverse Roller
4	Belt
5	Tray 3 Motor
6	Tray 2 Motor

Tray 2 Paper Feed

- Tray 2 motor turns clockwise and rotates the pick-up and feed rollers.
- The reverse roller does not turn at this time because it has a one-way clutch.

- Tray 3 motor turns counterclockwise, and the belt drives the grip roller and reverse rollers in Tray 2.

Paper Feed From Tray 3



d223c60666

Tray 1 (Rear View)

No.	Part
1	Tray 2 Grip Roller
2	Tray 2 Feed Roller
3	Tray 2 Reverse Roller
4	Tray 3 Reverse Roller
5	Tray 3 Motor
6	Tray 3 Grip Roller
7	Tray 2 Motor

Tray 3 Paper Feed


- Tray 3 motor turns clockwise and rotates the pick-up and feed rollers.
- The reverse roller does not turn at this time because it has a one-way clutch.
- Tray 2 motor turns counterclockwise, and the belt drives the grip roller and reverse rollers in Tray 2 and Tray 3.
- The grip roller in Tray 2 must rotate in order to feed the paper up from Tray 3 into the machine.

PFU and Tray Details

Paper Feed and Separation

During Standby


- The adjacent feed motor [A] rotates, grip roller [B] also rotates, and the shaft of separation roller [C] rotates in the direction of the arrow.
- The reverse roller rotates freely in either direction because the separation solenoid is off.



Paper Feed and Separation

- Separation solenoid [A] turns on, and then the adjacent feed motor [B] turns on. Next, pick-up solenoid [C] turns on, and at the same time, the PFU feed motor turns on. The shaft of feed roller [D] rotates, and the feed roller turns with the rotation of the one-way clutch. Next, pick-up roller [E] (driven by relay gears) feeds the first sheet from the top of the stack.
- Separation roller [F], with its internal torque limiter that allows the roller to rotate in either direction depending on the coefficient of friction with the paper above, also rotates with the feed roller.

- If two or more sheets of paper feed at the same time the extra friction will lock the torque limiter and reverse the direction of rotation of the separation roller, and then force the lower sheets back into the tray.
- Next, feed sensor [G] (a reflective sensor) detects the paper, the pick-up solenoid turns off, and the pick-up roller lifts and releases the paper. The paper is then fed to the registration unit.




- The table below shows the rotation of each roller when the feed motor is rotating forward or reverse.

Name	Forward	Reverse
Pick-up Roller	Rotate	Stop
Feed Roller	Rotate	Stop
Separation Roller	Stop	Rotate
Grip Roller	Stop	Rotate
Lower Grip Roller	Stop	Rotate

Separation Roller Release

When the machine is idle, the separation roller [A] and feed roller [B] are separated, but during paper feed the separation roller [C] is pushed up by the separation roller solenoid [D] against the feed roller.



d223d7401


These mechanisms have the following advantages:

- Pressure is on the separation roller only when the feed station is selected for paper feed, so this reduces wear on the rollers and extends their service lives.
- Paper is easier to remove from separated rollers if a paper jam occurs.

Tray Raising and Lowering

The tray lift motor behind the tray is coupled by a socket and pin to the arm of a bottom plate that holds the stack. The stack is raised and lowered when the motor operates.

- This mechanism raises and lowers the bottom tray and the paper stack. The socket and pin of the coupling and the plate lift arm automatically disengage and engage again smoothly when the paper tray is opened and closed.
- The rotation angle of the tray lift motor is adjusted for the amount of paper remaining in the tray.



d223c6067


5

No.	Name
1	Bottom Plate Lift Motor
2	Plate Lift Arm Shaft
3	Bottom Plate
4	Plate Lift Arm

Tray Upper Limit Detection

As soon as the tray is closed, the pick-up solenoid turns on and lowers the pick-up roller.


- At this time the tray lift motor lifts the tray, and the top of the stack raises the pick-up roller until the actuator on the pick-up roller arm activates the tray lift sensor which turns off the lift motor.
- Next, in order to verify that the top of the stack is at the feed position, the lift motor reverses, the tray lift sensor deactivates, the motor turns forward, this activates the lift sensor, and then this stops the motor.
- Once printing begins, the pick-up roller arm gradually descends as more and more paper leaves the tray. When the arm is low enough the actuator deactivates the sensor, which turns on the tray lift motor, and this raises the bottom plate and the paper stack.



No.	Name
1	Pick-up Solenoid
2	Pick-up Roller
3	Lift Sensor

Paper End Detection


A reflective sensor below bottom plate activates and signals paper end when the last sheet leaves the tray.



No.	Name
1	Paper End Sensor

Paper Size Detection

- **Tandem Tray (Fixed Tray).** Side fences are adjusted to the size of the paper (A4 or LT), and then the selected paper size must be input with SP5959-001.
- **Universal Trays.** The operator can adjust the side fences to the sides of the stack in the tray, and the machine automatically detects the paper size based on the settings of the side fences. An array of 5 switches is used to detect the positions of the end fence and side fence, and the combination of these settings is used to detect the size of the setting that will be displayed for the tray on the operation panel.



d223c6070

No.	Name
1	Front Side Fence
2	Rear Side Fence Sensor
3	Rear Fence
4	Front Side Fence


0: Switch OFF (Sensor output: H)

1: Switch ON (Sensor output: L)

Paper Size	Feed Edge	Width	A	B	C	D	E
A3	420	297	1	1	0	0	1

Paper Size	Feed Edge	Width	A	B	C	D	E
B4	364	257	1	0	0	1	1
A4 SEF	297	210	0	1	0	0	1
A4 LEF	210	297	1	1	0	0	0
B5 SEF	257	182	1	0	1	0	1
B5 LEF	182	257	0	0	0	1	1
A5 SEF	210	148	1	1	1	0	1
A5 LEF	148	210	0	1	1	0	1
DLT (11"x17")	431.8	279.4	1	1	1	0	0
LG(8.5"x14")	355.6	215.9	1	0	1	1	0
LT(8.5"x11")	279.4	215.9	1	1	0	1	0
LT LEF	215.9	279.4	0	1	1	0	0
HTL SEF	215.9	139.7	0	1	1	1	0
HLT SEF	139.7	215.9	1	1	1	1	0
F4(8.5"x13")	330.2	215.9	1	1	0	1	1
Folio(8.25"x13")	330.2	209.55	0	1	0	1	1
F4(8"x13")	330.2	203.2	0	1	1	1	1
Executive(7.25"x10.5")SEF	266.7	184.2	1	0	1	0	0
Executive(7.25"x10.5")LEF	184.2	266.7	0	0	1	1	1
8-kai SEF	390	267	0	0	1	1	0
16-kai SEF	267	195	1	0	0	1	0
16-kai LEF	195	267	1	0	1	1	1

Settings for custom paper sizes can also be specified in the User Tools menus. The entered paper sizes are displayed on the operation panel.



5


Size	Sensor
A3 SEF	0 1 1 1 1
B4 SEF	0 0 1 1 1
A4 SEF	1 0 0 1 1
A4 LEF	0 1 0 0 1
B5 SEF	0 0 1 0 0
B5 LEF	0 0 0 1 0
A5 SEF	0 0 0 0 1
A5 LEF	1 0 0 0 0
LT LEF	1 1 0 0 0
210x170, x182	1 1 1 0 0
*	1 1 1 1 0

Tray Set Mechanism

To set the position of the tray when the tray is pushed into the machine, a stopper [A] mounted on the bank frame drops behind a lock roller [B] on the tray cover.

- A spring comprises the mechanism that locks the tray lock roller and the lock arm for each tray. Each tray has a rail stopper that prevents the tray from moving.

- When a tray is pushed into the machine, the stopper pushes against the lock roller, and locks the tray once it is pushed in completely.




No.	Part Name
[A]	Stopper
[B]	Lock Roller
[C]	Lock Arm
[D]	Pressure Spring
[E]	Stopper Arm

Vertical Paper Feed

Each PFU is provided with a grip roller [A] and these three rollers (one in each PFU) comprise part of the vertical transport paper path.

- The shaft of each grip roller is driven by the paper feed motor [B] of each PFU. This arrangement allows more efficient paper feed (CPM: Copies per Minute) for optimum image development.
- The bank paper feed motors drive the rollers of the vertical transport unit, and the main unit vertical transport drive is provided by the bypass motor.
- Transport guide [C] (held in place by a lock pin) opens and closes the vertical transport feed path.
- Each grip roller is provided with a vertical drive belt [D] held in place by a pressure spring.
- Relay sensor [E] triggers image development and also detects jams at the top of the vertical path.



d223d7403

5

Tray 1 (Tandem Tray)


Paper Size Detection

The tandem tray (Tray 1) has no mechanism to automatically detect paper size, so in order to switch the paper size the service technician must move the rear and front side fences, and then enter the new setting into **SP5959-001**.

Tray Movement Mechanism

- A pin on the end of the tray lift motor drive shaft behind the tray meshes with the coupling on the end of the arm of the bottom tray where the paper sits, and the rotation of the coupled shaft raises the bottom tray and paper stack.
- The rotation of the coupled shaft drives wires on pulleys at the front and rear of the tray raises the bottom tray.

- The pin on the end of the bottom tray lift arm and the socket of the tray lift motor drive shaft disengage easily when the tray is opened, and then the bottom tray descends slowly under its own weight.
- Dampers ensure that the tray descends slowly and quietly and prevent the tray from falling too rapidly.
- The right tray paper sensor (a light reflective sensor) detects the presence of paper in the right tray.
- The capacity of the right tray is 1,550 sheets, and the paper sensor is provided for immediate detection of paper in the right tray to avoid having to raise the bottom plate to detect paper end and wasting several seconds.
- A lower limit sensor is positioned below the bottom tray to detect the lower limit of bottom plate movement.




No.	Name
1	Bottom Plate Lift Motor
2	Right Tray Paper Sensor
3	Tray Down Sensor

Paper Height Detection

Three sensors at the front of the right tray detect the amount of paper remaining in the tray.

- Every time the tray lift motor stops, and detects which sensor has been actuated (blocked by the actuator): tray end sensor, sensor 1 (25% remains), sensor 2 (50% remains), sensor 3 (75% remains), and then this reading is displayed on the operation panel.
- If no sensor has been actuated (blocked by the actuator), then the reading is 100%.




d223c6079

No.	Name
1	Near-end Sensor
2	Paper Height Sensor 1
3	Paper Height Sensor 2
4	Paper Height Sensor 3

Right Tray Fence Movement Mechanism

- The tandem tray is equipped with two fence solenoids, one for the front side fence and one for the rear fence.
- When paper runs out in the right tray, the front and rear fence solenoids turn on, open the front and rear fence, and then remain on until the fence open sensor goes on.
- When the paper stack is pushed into the right tray from the left tray, the rear fence return sensor detects the stack now in the right tray, and then switches the fence solenoids off which closes the front side fence and rear side fence.

- The fence closed sensor detects the fences at the closed position, switches on, and then signals that the fences are closed.
- If the fences are not closed, the machine will prompt the operator to manually correct the setting of the stack in right tray.




d223c6080

No.	Name
1	Front Side Fence
2	Rear Side Fence
3	Rear Side Fence Closed Sensor
4	Rear Side Fence Open Sensor
5	Rear Side Fence Solenoid
6	Front Side Fence Solenoid

Left Tray Movement

- When left tray paper sensor detects paper in the left tray and the right tray paper end sensor detects paper end, the rear fence motor (DCM) switches on and pushes the rear fence against the stack in the left tray to move it into the right tray.
- When the rear fence return sensor of the left tray detects that the stack is no longer in the left tray it will signal the rear fence motor to reverse rotate (counter-clockwise) and bring the rear fence back to its home position, and then the motor will turn off once the rear fence return sensor detects the rear fence at its home position.

- For the left tray to move paper into the right tray, the left tray paper end sensor must detect 10 sheets of paper or more in the left tray.




5

No.	Name
1	Rear Side Fence HP Sensor
2	Rear Tray Return Sensor
3	Rear Side Fence Motor
4	Left Tray Paper End Sensor
5	Rear Side Fence

Left Tray Lock Mechanism

- The left tray is locked and cannot be opened while paper is moving from the left tray into the right tray.
- When the stack in the left tray starts to move into the right tray, the left tray lock solenoid turns on and locks a pawl into the bottom plate of the left tray.
- After the stack has moved into the right tray and the side fence of the left tray has returned to its home position, the left tray lock solenoid goes off and releases the pawl from the bottom of the left tray.
- This mechanism prevents opening the left tray while the stack is moving from left to right.




No.	Name
1	Left Tray Lock Solenoid
2	Lock Pawl

5



Right Tray Lock Mechanism

- When the lock release solenoid turns on, a lock lever opens.
- There is a lock lever on the left tray that latches to a shaft in the right tray, and this allows only the left tray to open when Tray 1 drawer is opened.
- While the release lock solenoid is off, the lock lever is engaged with the shaft of the right tray and both trays will come out when Tray 1 is opened.



No.	Name
1	Lock Release Solenoid
2	Lock Lever
3	Shaft

- When Tray 1 is opened completely, the lock lever is pushed up by a bracket and the left and right trays separate. The separation of the trays allows easier loading of paper.




d223c6084

No.	Name
1	Lock Lever
2	Bracket

Bypass Tray

Bypass Feed Tray Mechanism

The bypass tray, which opens and closes against the right side of the machine, becomes the selected paper feed station once paper is loaded in the tray. The bypass tray has a capacity of 100 sheets.




d223c6086

No.	Name
1	Bypass Tray

Bypass Tray Feed and Separation Mechanism

The bypass feed unit uses the same FRR feed mechanisms as those in the PFUs of the main machine.


- At the start of a job, the pick-up solenoid turns on and lowers the pick-up roller [A] to the top of the stack.
- Next, the bypass feed motor [B] and bypass feed clutch [C] switch on and paper feed starts.
- The diameter and size of the feed roller [D] is different to prevent it from being installed in the incorrect position (the hubs of the bypass rollers are blue).



Paper Stopper Mechanism

The feed slot of the bypass paper tray is provided with a paper stopper [A] that prevents the paper from sliding into the the bypass unit when it is set on the tray.


- At the start of the job, the pawl of the stopper attached to the arm of the pick-up roller [A] releases when the roller is lowered so the edge of the stack is no longer blocked and can feed.



d223d7402

Bypass Tray Paper End Detection Mechanism

- When paper is set in the bypass tray, the top of the stack pushes up the paper feeler that switches on the paper end sensor mounted next to the pick-up roller (this detects paper in the tray).
- After the last sheet of the stack feeds, the feeler drops into a slot in the tray, the paper end sensor goes off and signals paper end.




No.	Name
1	Paper Feeler
2	Bypass Paper End Sensor
3	Bypass Pick-up Solenoid

Paper Size Detection

When paper is set in the bypass tray, the operator manually adjusts the front and rear paper guides to the sides of the stack.

- The size guides are attached inside the tray to a rack and pinion mechanism that activates an array of switches registered with the bypass paper width sensor that detects the size of the paper based on the positioning of the paper guides.
- As soon as the first sheet feeds, the paper length sensor starts a pulse count. After the trailing edge of the paper passes over the sensor, the machine can estimate the length of the paper based on the pulse count (amount of time it took for the paper to pass over the sensor).




d223c6088

No.	Name
1	Front Paper Guide
2	Rear Paper Guide
3	Bypass Paper Width Sensor
4	Bypass Paper Length Sensor

5

- The operator can also specify custom paper sizes (non-standard) with User Tool settings.




d223c6089

Paper Registration and Transport in Bypass Unit

Every sheet of paper fed into the machine must pass the paper registration rollers.

- Paper comes to the paper registration roller from four feed stations.

- All paper fed from the PFUs through the vertical transport path is fed to the registration unit by the upper relay roller.
- Paper fed from the bypass tray (or LCIT option) goes directly to the registration rollers
- Paper from the duplex unit or paper bank is fed from below, into the vertical feed path, and then fed to registration rollers by the relay roller.




d223c6090

No.	Name
1	Registration Sensor
2	Bypass Tray
3	Relay Sensor
4	LCIT (Option)
5	Paper Bank
6	Grip Roller
7	Duplex Unit
8	Upper Relay Roller


- The bypass feed motor switches off when the registration sensor detects the leading edge of the paper, and then the paper is stopped briefly at the registration roller to correct skew.

- Next, registration motor [B] rotates the registration roller so the paper can start moving again in the paper path.
- The machine is equipped with an independent registration motor, which eliminates the shock and jitter caused by a registration clutch turning on and off.
- A mylar sheet [C] in contact with the top of the registration roller (and covering the registration sensor) scavenges paper dust that may have accumulated on the feed and reverse rollers and passed on to the paper at paper feed. This arrangement greatly reduces the amount of paper dust in the paper path downstream of the registration roller.



d223d7405

- The registration guide plate is at the end of the registration roller at the front of the machine.
- In order to make jam removal easier, if a paper jam occurs at the registration roller, the guide plate solenoid turns on and opens the guide plate.
- After a jam has occurred, this action guides the following sheets into the duplex tray and stacks them.
- As soon as the guide plate opens, at the front an actuator on the guide plate actuates the guide plate position sensor.
- After the jammed paper has been removed from the jam point and from the duplex tray, the guide plate must be closed.
- If the plate is not closed the guide plate position sensor will trigger a prompt on the operation panel for the operator to close the plate at **B2** (the Start key will be disabled until the guide plate is closed).




d223c6091

5

No.	Name
1	Guide Plate Lock Pawl
2	Normal Paper Feed Direction
3	Guide Plate Set Lever
4	Guide Plate
5	Jam Removal Direction
6	Guide Plate Sensor
7	Guide Plate Solenoid

Invert, Duplex Unit

Overview



d223c6092

No.	Part Name	No.	Part Name
1	Duplex Entrance Sensor	11	Duplex Transport Sensor 1
2	Invert Entrance Roller	12	Transport Roller 1
3	Invert Positioning Roller	13	Reverse Roller
4	Jogger Fence	14	Duplex Transport Sensor 2
5	Duplex Right Table	15	Transport Roller 2
6	Right Table Guide	16	Horizontal Transport Guide Plate
7	Invert Junction Gate	17	Transport Roller 3
8	Duplex Junction Gate	18	Duplex Transport Sensor 3
9	Duplex Turn Roller	19	Transport Roller 4
10	Invert Exit Sensor	-	-


Here is a summary of the mechanisms and features of the invert duplex unit.

- **Invert Mechanism.** The invert entrance roller transports the copied sheet into the invert unit. The invert positioning roller inverts the printed sheet.

- **Exit/Duplex Junction Gate Mechanism.** The invert/duplex exit roller sends the printed paper out of the machine. The duplex junction gate opens and closes to guide the paper into the duplex or exit path.
- **Duplex Transport Mechanism.** The invert/duplex exit roller sends the paper to transport rollers 1, 2, 3, 4. Feeding A5 LEF is also possible. Pulling out the unit drops the edge guide plate to the horizontal, making it easier to remove paper.

Motors


In the duplex unit the single invert/entrance roller [A] is driven by the fusing exit motor [B], and the other rollers are driven by the duplex invert motor [C] and the duplex transport motor [D].



d223d7504

Invert Duplex Entrance

The invert duplex roller feeds the printed sheet transported from the exit unit into the invert duplex unit. The invert junction gate mounted in the invert duplex unit lowers under pressure of the printed sheet and guides the sheet into the jogger unit.



d223c6093


5

No.	Name
1	Duplex Entrance Sensor
2	Invert Entrance Roller
3	Invert Junction Gate Pawl

Jogging Operation

After the trailing edge of the printed sheet fed by the transport roller passes the invert junction gate into the jogger unit.

- The jogger unit front and rear fence align each sheet.
- The actual timing for the start of jogging is 83 ms after the trailing edge of the paper switches off the invert/duplex entrance sensor when it passes.
- After the Start key is pressed to start the job, the front and rear jogger fences are moved to the standby position 12 mm away from the sides of the selected paper size.
- As each sheet comes into the jogger unit, both fences move to the sides of the sheet to align it.
- After the edges of the sheet are aligned, both jogger fences return to the standby position 12 mm away from the sides of the selected paper size and wait for the next sheet.




d223c6094

5

No.	Name
1	Jogger Fences
2	Duplex Jogger Motor
3	Duplex Jogger HP Sensor
4	Invert Positioning Roller

Invert Operation


After the jogging operation finishes, the invert positioning roller [A], activated by the duplex invert solenoid [B], contacts the sheet and grips it with the reverse roller [C] to invert the sheet, and then the paper is fed by the duplex turn roller [D].



d223d7503

5

The duplex invert exit sensor [1] detects the leading edge and trailing edge of the paper as it passes out of the unit and triggers a jam if the paper stops.




d223c6095

No.	Name
1	Duplex Invert Exit Sensor

Duplex Transport Mechanism


- If the job is set for printing on the back side of the paper, the duplex junction gate solenoid [A] turns on and opens the junction gate [B] which guides the paper into the duplex feed path.
- The jogger fences do not reset to the standby position and the positioning step is skipped if image processing requires much time.
- The paper passes through the duplex unit past transport roller 1 [C], transport roller 2 [D], transport roller 3 [E], and finally transport roller 4 [F], all driven by the duplex transport motor.
- If the paper is to exit from the duplex unit, then it exits according to the timing of the bypass feed motor as it feeds straight through.



Paper Jam Release and Reset Mechanism


In the previous machine when there was a jam at the fusing exit, the adjacent knob had to be turned 11 to 12 times (with the operator keeping the count mentally) to feed the jammed sheet manually far enough so it could be removed.

- This machine is equipped with a turn sensor [A] and actuator [B] that will turn off the LED to signal when the paper has been fed manually far enough so that it can be removed.



d223d7501


- The turn sensor at the fusing unit exit counts the 12 turns and switches off the sensor after the 12th turn.
- This also switches off the duplex entrance sensor at the exit sensor. (Paper trailing edge pulled out)
- Instructions for this procedure are written on the fusing inner cover.



d223c6134

Exit Unit

Overview



d223c6096

No.	Name
1	Fusing Exit Motor
2	Decurl Roller
3	Exit Roller


Here is a summary of the exit unit mechanisms and features.

- **Decurl Mechanism.** The decurl roller removes back curl from the printed sheets.
- **Exit Junction Gate Mechanism.** Face-up, Face-down Exit. Normally, printed sheets feed straight through the fusing unit and exit the machine face-up.

Decurl Mechanism

A paper decurl unit has been added to the exit unit entrance in order to improve paper transport through the duplex unit and finishers.

- Three rollers comprise the decurl unit that depresses each sheet as it exits the fusing unit in order to correct back curl.




d223c6097

No.	Name
1	Decurl Roller

Exit Junction Gate Mechanism

The exit junction gate at the entrance to the exit unit guides each sheet directly to the exit for face-up delivery or down into the invert unit for face-down delivery.

- The position of the junction gate is switched with the exit junction gate solenoid (solenoid is on for exit and face-up delivery).
- The junction gate solenoid is at the rear of the duplex unit.



d223c6098

5

No.	Name
1	Exit Junction Gate Solenoid
2	Invert/Duplex Paper Feed Direction
3	Exit Junction Gate Pawl
4	Face-up Feed Direction

Duplex Interleave Feed Sequence


This machine employs interleave processing.

- This avoids having to print first the front and then the back side of each sheet which would be extremely slow.
- Interleave processing allows the machine to print the front and back sides out of sequence while keeping several sheets in the paper path.
- For example, the machine can handle up to three sheets in the paper path when duplex printing paper A4/LT SEF sizes or smaller.
- For other sizes like A4 LEF or larger, the machine can handle two pages at once.
- Duplex interleave printing always starts from the first page.
- This operation is described below.

In the illustrated example below:

- Original: 14 pages
- Scanning Mode: Duplex (both sides scanned simultaneously)


- Printed copies: Sheets (14 pages)



	Order of Page Processing													
Scan Order	1	2	3	4	5	6	7	8	9	10	11	12	13	14
Only 1	1	3	5	2	7	4	9	6	11	8	13	10	12	14
Smaller than A4/LT LEF	1	3	5	2	7	4	9	6	11	8	13	10	12	14
A3, etc.	1	3	2	5	4	7	6	9	8	11	10	13	12	14

- Original scan: Original scan order
- With A4 LEF and smaller, 3 pages can be handled at once
- With A3 and larger sizes, only 2 sheets can be handled at once.
- Sequence is the same for one document.

Interleave processing with first 3 sheets



d223c6100


1. After 3 pages feed, 1st sheet front page printed (page 1), 2nd sheet front printed (page 3), 3rd sheet printed (page 5)
2. 1st, 2nd, 3rd sheets fed to duplex tray, inverter table and inverted
3. 4th sheet feeds
4. 1st sheet back page prints (page 2)
5. 4th sheet feeds, front page prints (page 7)
6. 1st sheet exits (pages 1, 2)
7. 4th sheet feeds to duplex unit
8. 2nd sheet back page prints (page 4)
9. 5th sheet feeds
10. 2nd sheet exits
11. 5th sheet back page prints (page 9), feeds to duplex tray
12. 3rd sheet back page prints (page 6)
13. 6th sheet back page prints (page 11)

14. 4th sheet back page (page 8), 7th sheet front page (page 13) copied in order, the above process repeats

Electronic Components

Boards

Board Layout



w_d223c6101_eng

Board Functions

This machine employs a controller designed with GW (Grand Workware) architecture that supports MFP devices.

BICU. The BICU (formerly "BCU") is the main board that controls the main machine, maintains overall system control, and image processing. This machine does not have separate boards for an IPU and an SIO. These functions have been mounted on the BICU. Some of its specific functions of the BICU are:

- Engine sequence timing control
- Timing of peripheral devices
- Original scanning control
- Laser control (image writing)

- C-MOS image sensor scanning and image processing with a CIS

Controller Board. The controller board (with the exception of the engine functions controlled by the BICU) controls the system. This includes:

- Power supply monitoring (shutdown, Energy Save Mode)
- Network monitoring
- Printing, scanning control
- Memory control (includes HDD)
- Operation panel control

SBU (Sensor Board Unit). The SBU takes the analog signals of the image scanned with the C-MOS image sensor and does the A/D (analog-to-digital) conversion.

IOB (I/O Board). The IOB handles the input and output of all motors, solenoids, clutches, and sensors.

RYB (Relay Board). The RYB distributes DC current.

HDD (Hard Disk Drive). The HDD stores image data.

- Capacity: 320 GB.
- Document server capacity: 96,750 MB
- Document server max. capacity: 10,000 pages, SP expansion 45,000 pages (SP182-001).

PSU (Power Supply Unit). The PSU supplies DC power to the entire system.

PSU Fuse Table

Fuse	Rating	Blown Fuse
FU1	2A/250V	SC664-01 (SC log 664-21, Soft Error 991-00)
FU2	5A/250V	The copy and initial settings icons are not displayed on the Home screen. Machine returns SC670-01 about 4 min. after power on. (Soft error 899-00 logged.)
FU3	10A/250V	SC272-10 (SC log 547-02, Soft Error 515-00)
FU4	10A/250V	Detected connection of LCIT but cannot detect paper, or finisher not recognized. Copy jam
FU5	10A/250V	M223/M224: SC547-02. (SC log 202-00, 647-02, 120-00.) M225: No power code. (SC log 202-00, 531-01, 530-05, 581-00, 120-00)
FU7	---	Not used

AC Drive Board

The AC Drive board distributes AC power to the PSU, and also distributes power to the fusing unit and anti-condensation heaters. This board also holds the protection circuits for the PSU.

AC Drive Board Fuses for M223/M224

Fuse	Rating	Blown Fuse
FU101	15A/250V	SC547-02
FU102	15A/250V	Machine does not boot.
FU103	15A/250V	No SP display, no abnormal operation
FU105	2A/250V	Machine does not operate after more than 30 sec. have elapsed at machine start up, or while the fusing unit is cooling (recovery).

5

AC Drive Board Fuses for M225

Fuse	Rating: 100V	Blown Fuse
FU101	15A/250V	SC547-02
FU102	15A/250V	No power code display. (SC log 581-00)
FU103	15A/250V	No SP display, no abnormal operation
FU105	15A/250V	No power code display. (SC log 581-00)
FU106	15A/250V	Machine does not boot.

LDB. This is the laser drive board that holds the laser diode (LD) that creates images on the drum.

Power Packs. Supplies the voltage requested by process control to perform adjustments for conditions around the drum. There are three power packs. The transfer coronal power pack applies charge to the drum, the development power pack supplies the bias charge to the development unit, and the transfer power pack supplies the charge for the transfer unit to transfer the image from drum to paper (and also for paper separation from transfer belt).

Operation panel boards. For more information about the operation opanel boards, please refer to "Smart Operation Panel Second Generation" manual.

ADF Unit

Overview

Specifications

Item	Specification
Configuration	Automatic document feed duplex scanner (one pass two-side scanning)
Original size	Duplex: A3, A4, A5, B4, B5, B6, DLT, LG, LT, HLT, Long (up to 1260 mm)
	Single side: A3, A4, A5, B4, B5, B6, DLT, LG, LT, HLT
Scanning origin point	Origin at rear upper left corner
Original setting	Face-up on original tray
Original feed	Feeds from top of stack on original tray
Original separation	Feed belt and reverse roller separation by friction
Original scanning method	Through-sheet method (Front: White platen plate, Back: Color CIS and white roller)
Original tray capacity	220 sheets (81.4 g/mm ²)(stack height < 25 mm (1 in.))
Line Speed	500 mm/sec. (Monochrome)
Scanning productivity	
	Simplex
	Copying 90 ipm: LT LEF, A4 LEF 1 to 1 (Monochrome/color) Scanning 120 ipm (200/300 dpi), LT LEF, A4 LEF 1-to-1 (color)
	Duplex
	Copying 90 ipm: LT LEF, A4 LEF 1 to 1 (Monochrome/color) Scanning 220 ipm (200/300dpi), LT LEF, A4 LEF 1-to-1 (color)
ADF magnification	Front/Back 6.7% (750 mm/sec.) (system rate: 25 to 400%)
Dimensions (w x d x h)	587 x 520 x 175 mm (23 x 20 x 7 in.)
Weight	Less than 13.9 kg (30.5 lb.)

Item	Specification
Power Supply	DC 24V, DC 12V, DC 5V (supplied from main machine)
Power consumption	Less than 72.2 W

Original Size

Paper Weight	40.7 g/m ²	46.5 g/m ²	52.8 g/m ²	64 g/m ²	81.4 g/m ²	105 g/m ²	128 g/m ²	Translucent
Sheets	250	250	250	250	220	150	125	1
A3/A4	○	○	⊙	⊙	⊙	⊙	⊙	△
A5	○	○	⊙	⊙	⊙	⊙	⊙	---
B4/B5	○	○	⊙	⊙	⊙	⊙	⊙	△
B6P	-	-	○	○	○	○	○	---
DLT	○	○	⊙	⊙	⊙	⊙	⊙	---
LT	○	○	⊙	⊙	⊙	⊙	⊙	---
HLT	○	○	⊙	⊙	⊙	⊙	⊙	---
Folio	○	○	⊙	⊙	⊙	⊙	⊙	---


⊙ Simplex/duplex

○ Simplex only

△ SADF Simplex only

--- No compatible paper

Cross-Section of ADF Unit



d223d7014

5

No,	Part	No.	Part
1	Feed Belt	13	CIS
2	Bottom Plate Position Sensor	14	Original Exit Sensor
3	Pick-up Roller	15	Scanning guide plate
4	Original Set Sensor	16	CIS Glass
5	Original Tray	17	Original Registration Sensor
6	Original Length Sensors	18	Scanning Entrance Roller
7	Output Tray	19	Interval Sensor
8	Lift Sensor	20	Original Width Sensors
9	Bottom Plate HP Sensor	21	Skew Correction Sensor
10	Exposure Glass	22	Separation Sensor
11	Exit Roller	23	ADF Separation Roller
12	CIS White Roller	24	ADF Lift Interlock Switch


Scanning Sequence

- **Original Pick-up.** Pick-up roller picks up leading edge of original.
- **Original Feed and Separation.** Feed belt and reverse roller combination feed originals and separate double-feeds.
- **Original size detection.** 9 original size sensors, 5 for width and 4 for length, detect original stack size on the original tray.
- **Original Scanning.** A color CIS unit scans the reverse side of originals (both sides scanned in one pass).

ADF Components

5

Motors



No.	Part
1	Relay Motor
2	Entrance Motor
3	Feed Motor
4	Pick-up Motor

No.	Part
5	Tray Lift Motor
6	Exit Motor
7	Transport Motor


Original Pick-up

Paper Feed

When an original is placed on the original tray, its leading edge raises the feeler of the original set sensor to detect the original.

Pick-up Roller

- When there is no original on the original tray, the pick-up roller [C] swings up to the limit of its vertical movement.
- To lower the pick-up roller, the pick-up roller motor [A] switches and rotates lift cam [E] which lowers pick-up arm [D] and the pick-up roller.
- When the pick-up roller is lowered, the pick-up roller motor [A] switches on.
- When the actuator switches off the bottom plate position sensor [B], the pick-up roller motor goes off, and then the lift cam [E] holds the roller up.



d1359003

Pick-up Roller Down Timing

The pick-up roller lowers:

- When an original (or stack of originals) is set on the original table.

- When the trailing edge of the original passes the sensor (but, it does not lower for the last original).
- For A4/LT LEF when the leading edge reaches the registration sensor.

Pick-up Motor On/Off Timing

The pick-up motor switches on:

- When the original set sensor detects the leading edge of the original.
- When the machine is turned on


The pick-up motor switches off:

- When the original feed cover open.
- When an original jams in the ADF paper path.

Bottom Plate Lift

5

- When an original is set on the original tray, after the pick-up roller drops, the bottom plate position sensor goes off, and then the plate lift motor [A] goes on and raises lift lever [B] and raises the bottom plate.
- The actuator above the pick-roller holder switches on the bottom plate position sensor [C] and this turns the plate lift motor [A] off so the stack is positioned at the correct feed position.
- During scanning with the ADF, when the top of the stack becomes too low, the pick-up roller drops low enough to turn the bottom plate position sensor [C] off, which switches the lift motor [A] on again and raises the stack until once again it is at the paper feed position.
- This mechanism performs continuously and keeps the top of the stack at the correct feed height for original stacks of up to 220 sheets (81.4 g/m²).
- At the end of the job the original table descends under its own weight as far as the bottom plate HP sensor.




d1359004

5

Original Feed and Separation Mechanism

- A feed belt [A] and ADF separation roller [C] comprise the FRR original separation mechanism.
- If more than one original feeds between the nip of the feed roller and ADF separation roller, when pick-up roller [B] picks up the front edge of the original, the rotation of the ADF separation roller [C] reverses immediately.
- This sends the bottom sheet back into the tray while the sheet above continues to feed normally.




d1359005

- When more than one original feeds this increases torque above the limit of the spring loaded torque limiter which reverses the rotation of the ADF separation roller against the rotation the feed belt above.
- The bottom sheet reverse feeds while the sheet above continues to feed into the paper path.

Skew Correction Mechanism

- After the original feeds, the skew correction sensor detects its leading edge, and stops the rotation of the feed motor for the prescribed number of pulses.
- The leading edge hits and straightens against the stationary roller to correct skew.
- If the original is small (B6, A5, B5, HLT) (or when duplex scanning regardless of paper size), when the interval sensor [E] detects the leading edge of the original, it stops the pre-scanning roller [D] for a prescribed number of pulses, long enough for the original to buckle against the stationary roller and correct skew.




No.	Part
[A]	Original Width Sensors
[B]	Skew Correction Sensor
[C]	Entrance Roller
[D]	Scanning Entrance Roller
[E]	Interval Sensor

- You can turn on **SP6020-001** (ADF Contact Mode In/Out) to enable skew correction at both the entrance roller above as well as the pre-scanning roller below for all paper sizes but this may slow down the speed of original feeding.

Original Size Detection

- When the leading edge of the original reaches the interval sensor, the machine determines the width from the readings of the 5 original width sensors.
- The length of the original is determined by the readings of the 3 original length sensors under the original table and one sensor on the bottom plate.
- These two arrays of sensors are used to determine the size of the originals.



d1359006

5

No.	Part
1	Original Length Sensor A4/LT LEF
2	Original Length Sensor B5
3	Original Length Sensor A4
4	Original Length Sensor LG
5	Original Width Sensor 5
6	Original Width Sensor 4
7	Original Width Sensor 3
8	Original Width Sensor 2
9	Original Width Sensor 1

	Width Sensors					Length Sensors			
	1	2	3	4	5	A4 LEF	B5	A4	LG
A3(297x420)	ON	ON	ON	ON	ON	ON	ON	ON	ON
B4(257x364)	ON	ON	ON	---	---	ON	ON	ON	ON
A4 SEF (210x297)	ON	ON	---	---	---	ON	ON	ON	-
A4 LEF (297x210)	ON	ON	ON	ON	ON	---	---	---	---


	Width Sensors					Length Sensors			
	1	2	3	4	5	A4 LEF	B5	A4	LG
A4 SEF (210x297)	ON	---	---	---	---	ON	ON	---	---
A4 LEF (297x210)	ON	ON	ON	---	---	---	---	---	---
A4 SEF (210x297)	---	---	---	---	---	---	---	---	---
A4 LEF (297x210)	ON	---	---	---	---	---	---	---	---
DLT SEF (11"x17")	ON	ON	ON	ON	---	ON	ON	ON	ON
DLT SEF (11"x17")	ON	ON	ON	ON	---	ON	ON	ON	ON
8 1/2"x11" SEF (LT)	ON	ON	---	---	---	ON	ON	---	---
11"x8 1/2" LEF (LT)	ON	ON	ON	ON	---	---	---	---	---

↓ Note

- 11"x17", 11"x15" are detected as the same size, so you need to select one or the other with **SP6016-001** (Original Size Determination Priority) to choose whichever are using.

Original Transport

- At the beginning of the job, the original feed motor switches on and rotates the pick-up roller, feed belt, and reverse roller to feed the original into the original feed path.
- The original is fed to the entrance roller as it leaves the original tray. Original skew is corrected at the entrance roller.




d1359007

5


No.	Part
[A]	Feed Motor
[B]	Feed Belt
[C]	Pick-up Roller
[D]	ADF Separation Roller
[E]	Entrance Roller
[F]	Separation Sensor

- After skew is corrected at the entrance roller, the entrance motor [G] and transport motor [H] rotate the rollers in the original path and feed the original to the scanning section below.




No.	Part
[G]	Entrance Motor
[H]	Relay Motor
[I]	Transport Roller

- When the interval sensor [M] detects the original, the transport motor [K] turns on and rotates the white roller [J] and feeds the original through the scan unit.
- After rotation of the entrance roller, the entrance motor speeds up slightly to reduce the gap between the trailing edge of the original in the scanning unit and the leading edge of the next original in the path.
- If this were allowed to continue, the differences in roller rotation speed could cause the originals to bend or buckle in the original path around the pre-scanning roller.
- To avoid this, when the interval sensor detects the leading edge of an original it slows the rotation of the scanning belt and the speed of the original in the nip of the pre-scanning roller slows.




5

- When original exit sensor [Q] detects the leading edge of the original, the exit motor [P] switches on and rotates the exit roller [O] which feeds the original out onto the original output tray.



Original Scanning

This machine is provided with a color CIS (Contact Image Sensor) to improve its scanning ability with its ability to scan both sides of an original at the same time.




d1359011

5

No.	Part
[A]	ADF
[B]	White Roller
[C]	Scanner LEDs (Exposure Lamps)


Jam Detection Sensors



d1355207t

No.	Part
[1]	Skew Correction Sensor
[2]	Separation Sensor
[3]	Original Exit Sensor
[4]	Registration Sensor
[5]	Interval Sensor

Jams are detected by the 5 sensors listed above. The detection conditions are shown in the table below.



d223c6132

Jam Display	Jam Name	Detection Condition
-------------	----------	---------------------

P1	Separation sensor late jam		Feed motor on but leading edge failed to arrive after motor on long enough to feed 224 mm.		
P1	Skew correction sensor late jam		Leading edge failed to arrive after separation sensor detection and enough time elapsed for the original to feed 46 mm.		
P1	Interval sensor late jam		Leading edge failed to arrive after entrance motor started and remained on long enough for the original to feed 172 mm.		
P1	Registration sensor late jam		Original failed to arrive after it was detected by the interval sensor and enough time elapsed for the original to feed 96 mm.		
P2	Original exit sensor late jam		Original failed to arrive after it was detected by the registration sensor and enough time elapsed for it to feed 130 mm.		
P1	Separation sensor lag jam		After the entrance roller started to pull the original out of the original tray after initial feeding, the original failed to move based on the calculations below.		
	A4/LT	L1	L2	L3	Std.
	Not	Not	Not	Not	226.8
	Detected	Not	Not	Not	253.8
	-	Detected	Not	Not	291
	-	-	Detected	Not	320
-	-	-	Detected	432	
However, in some cases the operator may have specified another length longer than the standard value and that value will be used as standard (Std.).					

P1	Skew correction sensor lag jam	After the separation sensor detected the trailing edge, the trailing edge was still detected after enough time had elapsed for the original to feed 46 mm.
P1	Interval sensor lag jam	After the transport motor turned on, the trailing edge of the original was not detected after enough time had elapsed for the original to feed 82 mm.
P2	Registration sensor lag jam	After the interval sensor detected the trailing edge, the trailing edge was still detected after enough time had elapsed for the original to feed 93 mm.
P2	Original exit sensor late lag	After the registration sensor detected the trailing edge, the trailing edge was still detected after enough time had elapsed for the original to feed 130 mm.

ADF SC Errors

SC	Error Name	Probable Cause
700-01 *	ADF bottom plate lift motor error	<ul style="list-style-type: none"> • No output from bottom plate position sensor • No output from bottom plate HP sensor • Bottom plate motor not operating • ADF main board problem

SC	Error Name	Probable Cause
700-02*	ADF original pick-up motor error	<ul style="list-style-type: none"> • No signal from the pickup HP sensor because sensor harness, connector loose, broken, defective. • Pick-up HP sensor defective • Pick-up motor harness, connector, is loose, broken, defective. • Pick-up motor defective. • ADF main defective
700-04*	ADF feed motor error	<ul style="list-style-type: none"> • Paper jammed in paper path • Motor overload due to blockage • Motor harness loose, broken, defective • Motor bracket, motor installed incorrectly • Feed motor defective
700-05*	ADF entrance motor error	<ul style="list-style-type: none"> • Paper jammed in paper path • Motor overload due to blockage • Motor harness loose, broken, defective • Motor bracket, motor installed incorrectly • Entrance motor defective
700-06*	ADF transport motor error	<ul style="list-style-type: none"> • Paper jammed in paper path • Motor overload due to blockage • Motor harness loose, broken, defective • Motor bracket, motor installed incorrectly • Transport motor defective
700-07*	ADF scan motor error	<ul style="list-style-type: none"> • Paper jammed in paper path • Motor overload due to blockage • Motor harness loose, broken, defective • Motor bracket, motor installed incorrectly • Scan motor defective

SC	Error Name	Probable Cause
700-09*	ADF exit motor error	<ul style="list-style-type: none"> • Paper jammed in paper path • Motor overload due to blockage • Motor harness loose, broken, defective • Motor bracket, motor installed incorrectly • Exit motor defective
702-04	ADF protection circuit error 4	<ul style="list-style-type: none"> • Defective motor or harness on the interlock circuit.
702-05	ADF protection circuit error 5	<ul style="list-style-type: none"> • Interlock power circuit harness, switch is loose, broken, defective. • Motor harness, connector is loose, broken, or defective. • Motor is defective.
151-00	Black level error: Back side	<ul style="list-style-type: none"> • CIS defective
152-00	White level error: Back side	<ul style="list-style-type: none"> • ADF CIS device defective • CIS white roller background or white plate damaged • CIS dirty or installed incorrectly
154-00	Scanner communication error: Back side	<ul style="list-style-type: none"> • Harness between the ADF PCB and CIS is loose, broken, defective • ASIC in CIS is defective • FROM in CIS is defective

* Machine issues jam alert for first two occurrences, and then issues the SC code at the third occurrence. To recover, cycle the machine off/on.

New Features

Human Detection (Proximity) Sensor


Overview

The new sensor is located above the power switch on the left upper corner of the main machine.



d223c0072

When the machine has been idle for a long period and the sensor detects the presence of anyone in front of the machine, it signals the machine to prepare itself for quick recovery to operation status by shortening the time required for the machine to recover full operation (pre-recovery mode) before the operator even touches the machine or operation panel. This sensor employs infrared and can detect the presence of the operator within an arc of 150° out to 1.8 m (6 ft.) away from the front of the machine.



d223c7701

Sensor Operation

There are three phases in the operation of the this sensor:

- First, the sensor detects the presence of the operator within the arc in front of the machine, and then signals the machine to leave the STR mode (or Engine OFF mode) and enter the Pre-recovery mode.
- Second, as soon as the machine enters the Pre-recovery mode it resets the Engine Off mode timer for 5 min. If the operator does not touch the machine for 5 minutes, the machine slips back into the Engine Off mode. If the operator touches the LCD, or opens and closes the ADF or front door, etc., the machine shifts to Standby mode.
- Third, once the machine enters Standby mode, if the operator does nothing to start operation, the machine will gradually step down from Standby mode to Lower Energy mode, Quiet mode, Engine Off mode, and then finally to STR mode.

5

Operation Modes

Here are more details about these operation mode levels.

- **STR mode.** Suspend-to-RAM mode. The power supply to the CPU, adjacent chips, and the clock on the controller board is shut down.
- **Engine Off mode.** The fusing lamps and other engine components remain off. The operation panel backlight is off, but there is power supplied to the operation panel and the controller boards.
- **Pre-recovery mode.** The operation panel and HDD are on but the engine components remain off (Energy Save mode). However, the operation backlight still remains off, so there is no change on the operation panel to indicate that the machine has shifted from STR mode, through Engine Off mode, and into Pre-recovery mode.
- **Quiet mode.** Fusing lamps still remain off, but the HDD and SD cards are accessible so the machine can receive jobs (Data In) and incoming faxes.
- **Lower Power mode.** Finally, power is restored to the fusing lamps but maintained at low temperature.
- **Standby mode.** The machine is ready to operate.

User Tool

The operation of the sensor can be switched off and on with a User Tool setting.

1. Touch "User Tools" on the operation panel.
2. Select System Settings > Basic Settings > Proximity Sensor
3. You can switch the sensor off/on by selected Disabled/Enabled. The default setting is "Enabled".

Related SC Codes

One of two SC codes is issued if the sensor fails.

SC869-01 Human detection (proximity) sensor failure: Error 1.

The sensor remained on for over 24 hours.

- Cycling the machine off/on does not cancel this error.
- When this error occurs the machine enters sensor failure mode and ignores subsequent input from the sensor.
- Even though the sensor is on, the machine does not enter Pre-recovery mode, and the Engine Off timer setting is not affected and continues to operate normally.
- To cancel the error, switch off the sensor with the User Tool setting described above.
- The sensor and its components require replacement.

SC869-02 Human detection (proximity) sensor failure: Error 2

The sensor remained off, even after the operator performed 20 actions with the machine operation panel, opening and closing the front door, ADF, etc. The machine will issue this error code after every 20 events in operation of the machine.

- Cycling the machine off/on does not cancel this error.
- To cancel the error, switch off the sensor with the User Tool setting described above.
- The sensor and its components require replacement.

Related SP Code

There is one human detection sensor related SP code: SP5102-203 Auto Detect: Human Detection Sensor Check. This is an on/off check.

- Enter "0" to switch the sensor off.
- Enter "1" to switch the sensor on.

This SP is used to check the operation of the sensor. It confirms that the sensor can be switched off and on normally. (Default: On). This check can be used regardless of the User Tool setting. Even if the sensor is switched off with the User Tool setting, a check can be done with this SP code.

Operation Panel

This machine employs the Smart Operation Panel. For more details, refer to the "Smart Operation Panel 2nd Generation" field service manual.

Shutdown Feature

Specification

A new shutdown feature is provided to prevent possible damage to the machine or the loss of valuable data due to turning the machine off while it is printing, scanning, or saving data to the HDD.


The following conditions are met before power to the machine actually cuts off after the operator presses the power switch to turn off the machine.

- There can be no damage caused to any part of the system: HDD, NAND, SD and USB devices.
- The machine should not be shut down with paper in any part of the paper path. (Excluding cases when a jam occurs prior to shutting down the machine.)
- Job log, access log are all saved.

5

The Shutdown Screen

The screen below appears after the operator presses the power button to turn off the machine as a notice that the shutdown procedure is in progress.



d223c6104

The shutdown screen does not appear in the following cases.

- When the time to power off is very short.
- When the machine is turned off with the controller off.
- When the operator presses the power switch to turn off the machine in special modes (global delete, during firmware update, auto encryption mode).
- If the power switch is turned off while the machine is rebooting.

The machine should not be switched off immediately after the machine enters standby mode. When you see the "Turn main Power Switch off" prompt, wait for at least 10 sec. with the machine in Standby mode before you press the power switch to turn the machine off.

Automatic Delete Memory Function (HDD Security)

Specification

The function deletes the temporary data that is created on the HDD during job processing. There are functions to automatically overwrite the temporary data on the HDD created by every job (memory auto delete) as it is created, and to overwrite all such temporary data in one sweep (memory global delete).

These functions reside on the controller board. This DOS option (Data Overwrite Security) is switched on with SP5878-001 (Option Setup) before the machine leaves the factory. Function Details

Option Setup

- The option is set up at the factory before the machine is shipped.
- This option must be set up again after the controller board has been replaced.
- Related SP Codes
- **SP5878-001** (Option Setup - Data Overwrite Security)

When you execute this SP code to set up DOS after replacing the controller board, be sure to print a self-diagnostic report with SP5990-005 (SP Print Mode Diagnostic Report) to confirm that DOS is installed correctly. In the installed program column you should see a notation like:

GW4a_zoffyxstd/D3775912A

"Zoffy" is the data overwrite security program.

Automatic Delete Function Setup (for Operators)

The operator can set up the automatic delete function.

- The operator must log in as a supervisor with a supervisor password in order to access these settings.
 - The operator must log in as an administrator with a login password in order to access these settings.
1. Log in on the operation panel as the Administrator.
 2. Touch [System Initial Settings].
 3. Touch [Administrator Settings].
 4. Touch [Next] twice.
 5. Touch [Memory Auto Delete Settings].




d223c6105

6. Touch [Yes]. If the operator does not want to automatically overwrite the temporary data on the HDD, touch [No] and then [Set].

7. Select one of the options: [NSA Method], [DOD Method], [Random Method].

For [NSA Method], [DOD Method] "10" is recommended, and for [Random Method] "8" is recommended.

5



d223c6106

8. Touch [Update].



9. Enter the number for the number of repetitions, and then touch [#].

The number you enter is the number of times the data is overwritten with the Random Method. You can set a number in the range 1 to 9 (Default: 3).

10. Touch [Set].

11. Confirm that the "Overwrite Delete Icon" appears on the operation panel touch screen.

12. Make one copy, and then confirm that the data overwrite icon changes from the "Data Remains" appears and then starts flashing, and then the "No Data Remains" icon appears.

Icon	Icon Name
 <p data-bbox="289 501 353 517">d223c6107</p>	<p data-bbox="417 309 1181 374">Data remains display. The "Data Remains" icon flashes as the data is being overwritten and deleted.</p>
 <p data-bbox="289 736 353 752">d223c6108</p>	<p data-bbox="417 550 673 584">No data remains display.</p>

- If the display does not change to the "No data remains" icon, check and see if there is any background print or test print data on the disk.
- Output the background print and test print data (these are the first targets for overwrite and delete).
- If an HDD continues to be used with the [Memory Auto Delete Setting] off and then suddenly this setting is turned on, up to 10 hours may be required to pass before the disk can be used.


Data Encryption

Overview

This function encrypts recorded address book data, certification data, and stored documents as they are stored in this machine to prevent the threats of data loss through either electronic or physical theft.

- These functions reside on the controller board.
- This data encryption option is switched on with **SP5878-002** (Option Setup - HDD Encryption) before the machine leaves the factory.
- If the customer (with Administrator rights) turns this feature on with the default settings, the data encryption key is printed out. (The customer has the responsibility of safeguarding this key.)
- If the controller board is replaced, the data encryption key must be entered onto an SD card and then this card used to recover the HDD.
- If the data encryption key sheet has been lost, then the HDD data cannot be recovered after the controller board has been replaced.

Handling Data Encryption



Data Targeted for Encryption

The following data in the machine memory and HDD are encrypted when encryption is turned on.


- Address book
- User certification data
- Stored document data
- Temporary document data
- Log data
- Network I/F setting information
- Device setting information data

Precautions About Encryption

Data on the HDD is lost after the HDD is replaced (data automatically encrypted after replacement)

- After NVRAM replacement, data are automatically encrypted.
- After controller board replacement, the restore key is required.
- If the restore key is available, then the HDD can continue to be used.
- If the restore key is not available, boot the machine with an SD card holding the encryption key initialization settings, and then clear NVRAM and initialize the HDD (data on the HDD is lost).
- Replacing Controller Board and NVRAM

If the encryption key data has been lost then the HDD data is also lost.



Preferences Function (SMC Data Media Storage)

Function Details

This function saves SMC in CSV file format to an SD card. The data is saved to an SD card inserted into the media slot on the side of the operation panel, or inserted into Slot 2 (service slot) on the controller board faceplate on the back of the main machine. To save this data, go into the SP mode, open SP5992 (SP Text Mode) and then touch [EXECUTE].

SP992 Sub Groups

When you do **SP5992** you can select the data that you want to save by selecting the number of one of the sub groups.


No.	Data to Save
001	All (Data List)
002	SP (Mode Data List)
003	User Program Data
004	Logging Data
005	Diagnostic Report
006	Non-Default (SP codes not set to default)
007	NIB Summary
008	Capture Log
021	Copier User Program
022	Scanner SP Mode
023	Scanner User Program

No.	Data to Save
024	SDK/J Summary
025	SDK/J Application Information
026	Printer SP Mode

Data Saved on SD Card

When **SP5992** (SP Text Mode) is executed, a folder is created automatically on the SD card, and then the text data is saved in CSV format directly below this folder.

- Folder Name: Machine model number
- Filename Example



[A]	Machine model number
[B]	Shows number of the SP code executed First four digits (5992) is SP5992. The remaining digits denote the number of the sub group. The "0" prefix is reserved for the sub group numbers.
[C]	File creation date: YYYY/MM/DD. If the month, day is a single digit, then only one digit is used.
[D]	File creation time: HH/MM/SS. If the hour, minute, second is a single digit, then only one digit is used.

- Text Data Example

[A]	* RICOH imagio MP 7502			
	* Serial No of Machine	D223-010005		
	* Part Number	D22315572		
	* Firmware Version	0.8		
	* 2015 03 14 13:59			
	* SP Mode Data			
	* langId CHAR_CODE_SJIS			
[B]	<<No.>>	<<SP Name>>	<<Default>>	<<Setting>>
		SP1001-001 Leading Edge Registration		+0.0* 0.8
		SP1002-001 Side-to-Side Registration	Tray 1	+0.0* -2.3
		-2	Tray 2	+0.0* -0.6
		-3	Tray 3	+0.0* -0.7
		-4	Tray 4	+0.0* -1.5
		-5	Bypass Tray	+0.0* -0.7
		-6	LCIT	0 0
		-7	Duplex Tray	+0.0* -0.4
		SP1003-001 Registration Buckle Adjustment	LCT Tray	0 0
		-2	Duplex Tray	0 0
		-3	Bypass Tray	0 0

w_d223c6112_eng

[A]	Base information (Model name, number, code, firmware version, date of file creation, etc.)
[B]	SMC List (SP5992 selection branches selected for listing)

Import and Export Headings

1. The machine could freeze if the SD card is removed while data is being exported.
2. You can confirm data access (reading/writing) by watching the SD card slot LED.
3. Always confirm that the access LED of the slot is off before you remove the SD card from the slot.
4. If the machine stalls, just cycle the machine off/on to recover.
5. If less than 182mm is specified for [Custom Size Data], when the the preferences information is exported or imported, the information under the [Custom Size Data] heading may fail to be imported.
6. The settings for small paper sizes specified for the trays may not display for each application screen, even if they are updated.

6. System Maintenance

Service Program Mode

CAUTION

- Make sure that the data-in LED on the operation panel is not on before you go into the SP mode. This LED indicates that some data is coming to the machine. When the LED is on, wait for the copier to process the data.

Enabling and Disabling Service Program Mode

Note

- The Service Program Mode is for use by service representatives only. If this mode is used by anyone other than service representatives for any reason, data might be deleted or settings might be changed. In such a case, product quality cannot be guaranteed.

Entering SP Mode

For details, ask your supervisor.

Exiting SP Mode

- Press "Exit" on the LCD twice to return to the copy window.

Types of SP Modes

- System SP: SP modes related to the engine functions
- Printer SP: SP modes related to the controller functions
- Scanner SP: SP modes related to the scanner functions
- Fax SP: SP modes related to the fax functions


Select one of the Service Program modes (System, Printer, Scanner, or Fax) from the touch panel as shown in the diagram below after you access the SP mode. This section explains the functions of the System/Printer/Scanner SP modes. Refer to the Fax service manual for the Fax SP modes.



6

SP Mode Button Summary

Here is a short summary of the touch-panel buttons.



1	Opens all SP groups and sublevels.
2	Closes all open groups and sublevels and restores the initial SP mode display.
3	Opens the copy window (copy mode) so you can make test copies. Press SP Mode (highlighted) in the copy window to return to the SP mode screen,

4	Enter the SP code directly with the number keys if you know the SP number. Then press [#]. The required SP Mode number will be highlighted when pressing [#]. If not, just press the required SP Mode number.)
5	Press two times to leave the SP mode and return to the copy window to resume normal operation.
6	Press any Class 1 number to open a list of Class 2 SP modes.
7	Press to scroll the show to the previous or next group.
8	Press to scroll to the previous or next display in segments the size of the screen display (page).
9	Press to scroll the show the previous or next line (line by line).
10	Press to move the highlight on the left to the previous or next selection in the list.


Switching Between SP Mode and Copy Mode for Test Printing

1. In the SP mode, select the test print. Then press "Copy Window".
2. Use the copy window (copier mode), to select the appropriate settings (paper size, etc.) for the test print.
3. Press [Start] key to start the test print.
4. Press SP Mode (highlighted) to return to the SP mode screen and repeat from step 1.

Selecting the Program Number

Program numbers have two or three levels.

1. Refer to the Service Tables to find the SP that you want to adjust before you begin.
2. Press the Group number on the left side SP Mode window that contains the SP that you want to adjust.
3. Use the scrolling buttons in the center of the SP mode window to show the SP number that you want to open. Then press that number to expand the list.
4. Use the center touch-panel buttons to scroll to the number and title of the item that you want to set and press it. The small entry box on the right activates and shows the below default or the current settings.



Note

- Refer to the Service Tables for the range of allowed settings.
- Do this procedure to enter a setting:
 - Press \pm/m to toggle between plus and minus and use the keypad to enter the appropriate number. The number you enter writes over the previous setting.
 - Press [#] to enter the setting. (The value is not registered if you enter a number that is out of range.)
 - Press "Yes" when you are prompted to complete the selection.
 - If you need to perform a test print, press Copy Window to open the copy window and select the settings for the test print. Press [Start] key and then press SP Mode (highlighted) in the copy window to return to the SP mode display.
 - Press Exit two times to return to the copy window when you are finished.

Exiting Service Mode

Press the Exit key on the touch-panel.

Service Mode Lock/Unlock

At locations where the machine contains sensitive data, the customer engineer cannot operate the machine until the Administrator turns the service mode lock off. This function makes sure that work on the machine is always done with the permission of the Administrator.

- If you cannot go into the SP mode, ask the Administrator to log in with the User Tool and then set "Service Mode Lock" to OFF after he or she logs in:

> > User Tools > Machine Features > System Settings > Administrator Tools > Service Mode Lock

- This unlocks the machine and lets you get access to all the SP codes.

- The CE can service the machine and turn the machine power switch off and on. It is not necessary to ask the Administrator to log in again each time the main power switch is turned on.
2. Go into the SP mode and set **SP5-169** to "1" if you must use the printer bit switches.
 3. After machine servicing is completed:
 - Change **SP5-169** from "1" to "0".
 - Turn the machine power switch off and on. Tell the administrator that you have completed servicing the machine.
 - The Administrator will then set the "Service Mode Lock" to ON.

PM Counter/ Firmware Update

PM Counter and Firmware Update can be entered in the SP mode main screen.

- PM Counter: PM counters for each PM part
- Firmware Update: Immediate remote update and remote update at next visit.




Checking the PM Counter

1. Enter the SP mode, and then press [PM Counter].



2. Press [Estimated Usage Rate/Estimated Remain Days].

6



3. You can see the "Remaining Days for each part".

SP Mode(PM Parts)					Prev. Menu	Exit
Estimated UsageRate/RemainDays Select parts						
No	Description	Exceed	Usage Rate	Remain Days		
002	#PCU	000		255	Clear	01/01 ▲Prev ▼Next
023	#Dev Unit	000		255	Clear	
108	#Paper Transfer Roller Unit	000		255	Clear	
115	#Fusing Unit	000		255	Clear	
206	#ADF Pick-up Roller	000		255	Clear	
207	#ADF Paper Supply Belt	000		255	Clear	
208	#ADF Reverse Roller	000		255	Clear	
						20 MAR 2014 7:29

d197z3004

Executing Firmware Update

For details about how to use the Firmware Update, refer to Package Firmware Update.

Remarks

The maximum number of characters which can show on the control panel screen is limited to 30 characters. For this reason, some of the SP modes shown on the screen need to be abbreviated. The following are abbreviations used for the SP modes for which the full description is over 20 characters.

Item	Description
Paper Weight	Thin paper: 52-59 g/m ² , 13.9-15.7lb. Plain Paper1: 60-74 g/m ² , 16-19.7lb. Plain Paper2: 75-81 g/m ² , 20-21.6lb. Middle Thick: 82-105 g/m ² , 21.9-28lb. Thick Paper1: 106-157 g/m ² , 28.3-41.9lb.
Paper Type	N: Normal paper MTH: Middle thick paper TH: Thick paper

Item	Description
Paper Feed Station	P: Paper tray B: By-pass table
Print Mode	S: Simplex D: Duplex

Others

The settings of each SP mode are explained in the right-hand column of the SP table in the following way.

[Adjustable range / **Default setting** / Step] Alphanumeric

Note

- If "Alphanumeric" is written to the right of the bracket as shown above, the setting of the SP mode shows on the screen using alphanumeric characters instead of only numbers. However, the settings in the bracket in the SP mode table are explained by using only the numbers.

The following symbols are used in the SP mode tables.

Notation	What it means
ENG	Engine SP
CTL	Controller SP
FA	Factory setting: Data may be adjusted from the default setting at the factory. Refer to the factory setting sheets enclosed. You can find it in the front cover.
DFU	Design/Factory Use only: Do not touch these SP modes in the field.
*	An asterisk (*) to the left side of ENG/CTL column means that this mode is stored in the NVRAM. If you do a RAM clear, this SP mode will be reset to the default value. "ENG" and "CTL" show which NVRAM contains the data. <ul style="list-style-type: none"> • *ENG: NVRAM on the BCU board • *CTL: NVRAM on the controller board
SSP	This denotes a "Special Service Program" mode setting.

Service Program Mode Tables

SP Tables

See "Appendices" for the following information:

- System SP Tables
- Printer SP Tables
- Scanner SP Tables

Test Pattern Printing

Printing Test Pattern: SP2902

Some of these test patterns are used for copy image adjustments but most are used primarily for design testing. These test patterns do not use the IPU.

Note

- Do not operate the machine until the test pattern is printed out completely. Otherwise, an SC may occur.
1. Enter the SP mode and select **SP2902**.
 2. Enter the number for the test pattern that you want to print and press [#]. (See the table below.)
 3. When you are prompted to confirm your selection, press Yes to select the test pattern for printing.
 4. Press Copy Window to open the copy window, then select the settings for the test print (paper size, etc.)
 5. Press [Start] twice (ignore the "Place Original" messages) to start the test print.
 6. After checking the test pattern, press SP Mode (highlighted) to return to the SP mode display.
 7. Exit the SP mode.

Test Pattern Table

These patterns can be selected.

No.	Test Pattern
0	None
1	Alternating Dot Pattern (1-dot)
2	Alternating Dot Pattern (2-dot)
3	Alternating Dot Pattern (4-dot)
4	Alternating Dot Pattern (1024-dot)
5	Grid Pattern (1-dot): 0ch
6	Grid Pattern (1-dot): 1ch
7	Grid Pattern (1-dot): 2ch
8	Grid Pattern (1-dot): 3ch

No.	Test Pattern
9	Grid Pattern (1-dot pair)
10	Checker Flag Pattern
11	Horizontal Line (2-dot)
12	Vertical Line (2-dot)
13	Horizontal Line (1-dot)
14	Vertical Line (1-dot)
15	Cross Stitch (Vertical)
16	Cross Stitch (Horizontal)
17	Argyle Pattern
18	Trimming Area
19	Full Dot Pattern
20	Black Band (Vertical)
21	Black Band (Horizontal)
22	Blank Image
23	Grid (1 dot: Och with Outside Data)
24	Trimming Area (with external data)
25	Argyle Pattern (with external data)

Firmware Update

Software Update

Software Update Procedure

SD cards are used to update the software and to back up important data. Here is a list of the firmware modules that can be updated or restored from an SD card:

- GW controller software
- BCU software
- LCDC (operation panel) software
- Network Sys (network) software
- Web Sys (Web Image Monitor)
- Document Server software
- NFA (Net File) software
- Printer application software
- Scanner application software
- DESS (encryption module) software

Important

- **Never connect or remove an SD card with the machine power turned on.**
- **Never turn the power off while the machine is downloading data from an SD card.**
- **Never store SD cards in a location where they are exposed to high temperature, high humidity, or direct sunlight.**
- **Never bend an SD card, scratch it, or expose it to strong vibration.**
- **Before uploading data to an SD card, always confirm that its write-protect switch is off.**


Doing the Software Update Procedure

Before you do this procedure you must have the most recent version of the firmware downloaded to an SC card.

1. Turn the main switch off.
2. Remove the SD card slot cover.
3. Insert the SD card into SD card Slot 2. Make sure that the SD card has clicked and locked in place.
4. Turn the machine on.


5. The machine will prompt you "Please Wait" as the firmware update program boots. This requires about 35 sec.
6. Wait for the version update screen to appear.

If the SD card contains more than one software application, the screen will be almost the same as the one below. The screen below shows that the SC card contains two applications: "Engine" and "Printer".



b246s903


7. To select the item for upgrade, touch the selection on the touch panel, or push the corresponding key on the 10-key pad (1 to 5) of the operation panel. The number in parentheses tells you which key to push. When you make a selection, the [Verify(./*)] and [Update(#)] buttons come on the screen.



b246s904


- If you push [Exit] (or the [0] key), you go back to the usual operation screen.
 - Push the [Start] key on the operation panel to select and download all the options shown on the screen.
 - Push the [Clear] key on the operation panel if you want to cancel your selections and make new ones.
 - "ROM": This is the number and other version information of the ROM firmware installed in the machine at this time.
 - "NEW": This is the number and other version information of the firmware on the SD card.
8. With the selected items shown in reverse color, push the [Update] button or the [#] key on the operation panel to start the update.

After you push [Update]:



b246s905


- The middle bar shows the name of the module that the machine updates at this time. (The example above shows that the machine updates the "Printer" module at this time.)
- The bottom bar is a progress bar. The "_" marks in the progress bar are replaced by "*" marks. This progress bar cannot be displayed during the firmware update for the operation panel. But, the LED of the [Start] key on the operation panel changes from red to green to show that the update of the operation panel firmware continues.
- When the update is completed, you will see this screen.



b246s906

After the firmware update, you will see "Update Done" in the first bar. The name of the module in the bottom bar is the name of the last module that was updated (only the name of the last module is shown, if several modules were been updated).

9. Turn the power off and on. Then, select the items that you updated, and then push the [Verify] button. This is to check that the modules were updated correctly.
10. If you see "Verify Error" in the first bar on the screen, then you must do the procedure again for the module shown in the bottom bar.




b246s907

Note

- The "Verify" procedure is not necessary but it is strongly recommended.
11. After the firmware is correctly updated, turn the main power switch off.
 12. Push the SD card in a small distance to release it, then pull it out of the slot.
 13. Turn the main power switch on, and check that the machine operates correctly.

Errors During Firmware Update



b246s908

If an error occurs during a download, an error message will appear. The error code consists of the letter "E" and a number ("E20", for example).

Error Message Table

No.	Meaning	Solution
20	Cannot map logical address	Make sure the SD card is installed correctly, or use a different SD card.
21	Cannot access memory	HDD connection not correct, or replace hard disk.
22	Cannot decompress compressed data	The ROM data on the SD card is not correct, or data is damaged.
23	Error occurred when ROM update program started	Controller program defective. If the second attempt fails, replace the controller board.
24	SD card access error	Make sure the SD card is installed correctly, or use a different SD card.
30	No HDD available for stamp data download	HDD connection not correct or replace hard disks.
31	Data incorrect for continuous download	Install the SD card with the remaining data necessary for the download, then re-start the procedure.

No.	Meaning	Solution
32	Data incorrect after download interrupted	Do the recovery procedure for the module, then repeat the installation procedure.
33	Incorrect SD card version	The ROM data on the SD card is not correct, or data is damaged.
34	Module mismatch - Correct module is not on the SD card	The data on the SD is not correct. Get the correct data (Japan, Overseas, OEM, etc.) then install again.
35	Module mismatch – Module on SD card is not for this machine	SD update data is not correct. The data on the SD card is for a different machine. Get the correct data then install again.
36	Cannot write module – Cause other than E34, E35	SD update data is not correct. The data on the SD card is for a different machine. Get the correct data then install again.
40	Engine module download failed	Replace the data for the module on the SD card and try again, or replace the BCU board.
42	Operation panel module download failed	Replace the data for the module on the SD card and try again, or replace the LCDC.
43	Stamp data module download failed	Replace the data for the module on the SD card and try again, or replace the hard disk.
44	Controller module download failed	Replace the data for the module on the SD card and tray again, or replace the controller board.
50	Electronic confirmation check failed	SD update data is not correct. The data on the SD card is for a different machine. Get the correct data then install again.
143	Clear/Stop	

Updating the LCDC for the Operation Panel

1. Use this procedure to update the LCDC (LCD Control Board).
2. Turn the copier main switch off.
3. Put the SD card into slot 2.
4. Turn the copier main switch on.
5. Stop until the card utility screen is displayed.

After approximately 10 seconds, the initial screen opens in English.

6. Touch [Op-panel.DOM].
7. Touch [UpDate(#)] to start the update.

While the data downloads, the operation panel goes off.

The LED on the [Start] key flashes red at 1/2 second intervals for approximately 6 minutes.

When the update is completed, the [Start] key starts to flash at 1-second intervals.

8. Turn the copier main power switch off, remove the SD card, then turn the copier on again.

Downloading Stamp Data

After you replace or format the HDD, download the stamp data from the controller firmware to the hard disk.

1. Go into the SP mode.
2. Select **SP5853** then press "Execute".
3. Obey the instructions on the screen to complete the procedure.

Uploading/Downloading NVRAM Data

Uploading Content of NVRAM to an SD card

Do this procedure to upload SP code settings from NVRAM to an SD card.

↓ Note

- Always upload this data to an SD card before you replace the NVRAM.
1. Before you turn the machine off, do SP5990 001 (SMC Print). This gives you a record of the NVRAM settings if the upload fails.
 2. Turn the copier main power switch off.
 3. Put the SD card into slot 2, then turn the copier on.
 4. Do **SP5824 001** (NVRAM Data Upload) then push the "Execute" key

When uploading is completed, a file is copied to the NVRAM folder on the SD card. The file is saved to this path and filename:

NVRAM\

5. To prevent an error during the download, write the serial number of the machine on the SD card.

↓ Note

- This is necessary because NVRAM data from more than one machine can be uploaded to the same SD card.

Downloading an SD Card to NVRAM

Do this procedure to download SP data from an SD card to the NVRAM in the machine.

- If the SD card with the NVRAM data is damaged, or if the connection between the controller and BCU is defective, the NVRAM data download will not complete correctly.
- If the download does not complete correctly, do the download procedure again.
- If this does not complete correctly, input the NVRAM data manually from the SMC print that you made before you uploaded the NVRAM data.

1. Turn the copier main power switch off.
2. Put the SD card with the NVRAM data into slot 2.
3. Turn the copier main power switch on.
4. Do SP5825-001 (NVRAM Data Download) and push the "Execute" key.

 **Note**

- This procedure also downloads the C/O, P/O Count data to the NVRAM:
- The serial number of the file on the SD card must match the serial number of the machine. If the serial numbers do not match, the download will not complete correctly.

Updating JavaVM

Creating an SD Card for Updating

1. Download the update modules from Firmware Download Center. As one of the model modules, "Java VM v11 UpdateTool" is available for download. (The version differs depending on the model.)
2. Unzip the downloaded file. Copy the whole "sdk" folder to the root of the SD card directly below.

Note

- When unzipping the downloaded file, two subfolders ("update" and "sdk") exist in the "sdk" folder. Rather than just copying the subfolder "sdk", copy the whole folder "sdk".

Updating Procedure

CAUTION

- SD card can be inserted with the machine power off.
 - During the updating process, do not turn off the power.
 - If you turn off the power during the updating, the machine performance is not guaranteed. (There is a possibility that an SC and boot failure occurs.)
 - If you accidentally turn off the power during the updating, retry the updating procedure from the beginning. (If the update fails again, you will need to replace the controller board.)
1. If the boot priority application is set to the ESA application, switch to the copy application. ([System Settings]-[General Features]-[Function Priority])
 2. Insert the SD card you created into the service slot, and then turn ON the main power switch.
 3. After booting Java VM, update of the application is started. "Updating SDK/J" appears in the banner message of the touch panel display. (Estimated time: about 2 minutes)



4. When the update is complete, "Update SDK / J done SUCCESS" will appear in the banner message of the touch panel display. After turning off the power, remove the SD card from the slot. When you fail to update, "Update SDK/J done FAIL" is displayed. You can confirm the cause of the error message below.
5. Reconfigure the Heap size. ([Extended Feature Settings]-[Administrator Tools]-[Heap/Stack Size Settings]).
See the manual for the ESA application to know what value to set for the heap size.
6. Return to the previous setting for the boot priority application.

List of Error Messages

Update results are output as a text file on the SD card called "sdkjversionup.log" in the "\sdk \update" folder.

Result	File contents	Description of the output
Success	script file = /mnt/sd0/sdk/update/ bootscript 2012/08/22 17:57:47 start 2012/08/22 17:59:47 end SUCCESS	Boot script path Boot scripts processing start time End time boot script processing, the results
Failure	script file = /mnt/sd0/sdk/update/ bootscript 2012/08/22 17:57:47 start XXXX Error 2012/08/22 17:57:57 end FAIL	Boot script path Boot scripts processing start time Error message (Possibly multiple) End time boot script processing, the results

Error Message	Cause	Remedy
PIECEMARK Error,machine=XXXXX	Applied the wrong updating tool (Using the updating tool of a different model)	Use the correct updating tool for this model.
pasePut() - error : The file of the copy origin is not found Put Error!	Inadequacy with the SD card for updating (Files are missing in the updating tool)	Re-create the SD card for updating.
paseCopy() - error : The file of the copy origin is not found. Copy Error!	Inadequacy SD card for updating (Files in the updating tool are missing)	Inadequacy SD card for updating (Files in the updating tool are missing)
[file name: XX] error,No space left on device pasePut() - error : The destination directory cannot be made. pasePut() - error : fileCopy Error. Put Error!	Writing destination is full. (The NAND flash memory on the controller board is full.)	Uninstall the unnecessary SDK applications. If you can not uninstall it, implement escalation, stating the "model name, application configuration, SMC sheet (SP5-990-006/024/025), and error file."
[file name: XX] error,No space left on device paseCopy() - error : The destination directory cannot be made. paseCopy() - error : fileCopy Error. Copy Error!	Writing destination is full. (The NAND flash memory on the controller board is full.)	Uninstall the unnecessary SDK applications. If you can not uninstall it, implement escalation stating the "model name, application configuration, SMC sheet (SP5-990-006/024/025), and error file."

Error Message	Cause	Remedy
Put Error! * 1	Error, not normally expected to occur	If you cannot uninstall it, implement escalation stating the "model name, application configuration, SMC sheet (SP5-990-006/024/025), and error file." * 1 Without the foregoing error message, only "Put Error / Copy Error" will be displayed
Copy Error! * 1		
Delete Error!		
[XXXXX] is an unsupported command.		
Version Error		

NVRAM Upload/Download

Uploading NVRAM Data to an SD Card

Before you begin, please note:

- Uploading NVRAM contents to an SD card will fail if the machine serial number of the machine is not registered with **SP5811**.
 - The machine serial number is set at the factory before shipping.
 - NVRAM data can be uploaded from several machines and stored on the same SD card because a unique filename is created automatically for each machine.
1. Enter the SP mode and do **SP5990-2** to print an SMC report.
 - Always print an SMC report before uploading NVRAM data, just in case the download of the NVRAM data fails.
 - If the download fails, you can use the report to re-enter the SP and UP settings manually.
 2. Turn the machine off.
 3. Remove the SD slot cover.
 4. Insert the SD card into SD Card Slot 2 (lower slot).
 5. Turn the machine on.
 6. Enter the SP mode and do **SP5824** (NVRAM Data Upload).
 7. Touch [EXECUTE] on the operation panel to start the upload.
 - Data uploaded from NVRAM is stored in a file in the NVRAM folder created on the on the card: NVRAM folder> D224*.nv
where D224*.nv is the number of the machine entered at the factory before shipping. The number will be unique for each machine.
 - If this upload is done with the NVRAM folder and file from a previous upload is stored on the SD card, the folder and file will be overwritten. (A new directory and file are not created.)

Downloading NVRAM Data from an SD Card

Before you begin, please note:

- Downloading NVRAM data from an SD card may fail if the SD card is defective.
- If downloading NVRAM data from an SD card fails, just repeat the procedure.
- If the second attempt to download from the SD card fails, then you must enter the SP and UP settings manually from the SMC report you printed before uploading the NVRAM data to the SD card.

1. Turn the machine off.
2. Remove the SD slot cover.
3. Insert the SD card that holds the NVRAM data into SD Card Slot 2 (lower slot).

 **Important**

- **The machine number included in the filename of the file on the SD card must match the number of the machine.**

4. Turn the machine on.
5. Enter the SP mode and open **SP5825**.
6. Touch [EXECUTE]. The download executes.
7. When the prompt that tells you that the operation has completed and that the machine must be re-booted, touch [Exit].
8. Exit the SP mode and remove the SD card.
9. Cycle the machine off/on.

UP/SP Data Import/Export

Overview

Import/export conditions

Import/export is possible between devices only if their model type, region of use, and the following device configurations match.

- Input Tray
- Output Tray
- ARDF
- Whether or not equipped with a hard disk
- Whether or not equipped with a finisher and the type of finisher

UP Data Import/Export

6

Data that can be imported and exported

- Copier / Document Server Features
- Printer Features
- Scanner Features
- Facsimile Features
- Browser Features
- Extended Feature Settings
- Program (Document Server)
- Program (Copier)
- Program (Scanner)
- Web Image Monitor Setting
- Web Service Settings
- System Settings

Data that cannot be imported or exported

- Some System Settings *1 *2

* 1 The setting for the date, settings that require the device certificate, and settings that need to be adjusted for each machine (for example, image adjustment settings) cannot be imported or exported.



* 2 Settings only for executing functions and settings only for viewing cannot be imported or exported.


- Extended Feature Settings
- Address book
- Programs (fax function)
- Programs (printer function)
- User stamp in Copier / Document Server Features
- Settings that can be specified via telnet
- @Remote-related data
- Counters
- EFI printer unit settings
- Settings that can only be specified via Web Image Monitor or Web Service (for example, Bonjour, SSDP setting)

Exporting Device Information

This can be exported / imported by an administrator with all privileges.


When exporting SP device information from the control panel, the data is saved on an SD card.

1. Insert an SD card into the media slot on the side of the control panel.
2. Log in from the control panel as an administrator with all privileges.
3.  >  > User Tools > Machine Features
4. Press [System Settings].
5. Press [Administrator Tools].
6. Press [Next] four times.
7. Press [Device Setting Information: Export (Memory Storage Device)].



w_d1825501

8. Set the export conditions.



w_d1825502

- Specify whether to [Include] or [Exclude] the "Device Unique Information". "Device Unique Information" includes the IP address, host name, fax number, etc.
- Specify an encryption key.

9. Press [Run Export].

10. Press [OK].

11. Press [Exit].

12. Log out.



⬇ Note


- If data export fails, the details of the error can be viewed in the log.
- When device Information is periodically imported, it is necessary to create the device setting information file with special software and store it on the web server.

Importing Device Information

This can be exported / imported by an administrator with all privileges.

Import device information saved on an SD card.

1. Insert an SD card into the media slot on the side of the control panel.
2. Log in from the control panel as an administrator with all privileges.
3.  >  > User Tools > Machine Features
4. Press [System Settings].
5. Press [Administrator Tools].
6. Press [Next] four times.
7. Press [Device Setting Information: Import (Memory Storage Device)].
8. Configure the import conditions.



w_d1825503

- Press [Select] of the "Device Setting Info. File" to select the file(s) to import.
- When inserting a file into a home screen, press [Select] for the Image for Home screen and select the file. You cannot use this setting when using the Smart Operation Panel.
- Specify whether to [Include] or [Exclude] the "Device Unique Information". "Device Unique Information" includes the IP address, host name, fax number, etc.
- Enter the encryption key that was specified when the file was exported.

9. Press [Run Import].
10. Press [OK].
11. Press [Exit].

The machine restarts.

Note

- If data export fails, the details of the error can be viewed in the log.

SP Data Import/Export

Data that can be imported and exported

- System SP
- Printer SP
- Fax SP
- Scanner SP

Exporting Device Information

When exporting SP device information from the control panel, the data is saved on an SD card.

1. Insert an SD card into the media slot on the side of the control panel.
2. Enter SP mode.
3. Open **SP5-749-001** (Import/Export: Export)
4. Select "Target" SP settings (System, Printer, Scanner, Fax, Smart Operation Panel) to be exported.
5. Select "Option" settings (Unique/Secret).

Item	Specification	Note
Unique	Unique information of the machine is included in the exported file if you select "Unique" setting.	<p>Unique information that can be updated</p> <p>#1. Items that are to be used to identify the machine. Example: Network Information/ Host name / Information related to fax number /Mail address assigned to the machine</p> <p>#2. Items for specifying the options equipped on the machine. Example: Lot number for developer</p> <p>Unique information that cannot be updated</p> <p>#1. Items that may cause a problem if imported Example: Serial number / Information related to @Remote</p> <p>#2. Items for managing the history of the machine Example: Time and date / Counter information / Installation date</p> <p>#3. Setting values for the Engine</p>

Item	Specification	Note
Secret	Secret information is exported if you select "Secret" setting.	<p>Secret information</p> <p>#1. Data that cannot be exported without being encrypted. (Exported data is encrypted.) Example: Password / Encryption key / PIN code</p> <p>#2. Confidential information for the customer Example: User name / User ID / Department code / Mail address / Phone number</p> <p>#3. Personal information Example: Document name / Image data</p> <p>#4. Sensitive information for the customer Example: MAC address / Network parameters</p>

* The IP address is exported when both 'Unique' and 'Secret' are selected.

6

6. Select "Crpt config" setting (Encryption).

Encryption	<p>Select whether to encrypt or not when exporting.</p> <p>If you push the "Encryption" key, you can export secret information.</p>	<p>If the encryption function is used, setting of an encryption key is required by direct input.</p> <ul style="list-style-type: none"> Type the arbitrary password using the soft keyboard Can enter up to 32 characters
------------	---	---

7. Press [Execute].

8. Press [OK].

↓ Note

- If data export fails, the details of the error can be viewed in the log.

Importing Device Information

Import device information saved on an SD card.

1. Insert an SD card into the media slot on the side of the control panel.
2. Enter SP mode.
3. Press **SP5-749-101** (Import/Export: Import)
4. Select a unique setting.

5. Press [Encryption Key], if the encryption key was created when the file was exported.
6. Select an encryption setting.

Unique	If you want to apply the unique information to the target machine, select the "Unique" key.	Refer to the above information.
Encryption	If an encrypted file is selected as the import file, this setting is required.	

7. Press [Execute].
8. Press [OK].

↓ Note

- If data export fails, the details of the error can be viewed in the log.

Possible solutions for import/export problems

The access log file is created when export/import is executed. The file is stored in the same location as the exported device setting information file.

If an error occurs, check the log's result code in the access log file first. Values other than 0 indicate that an error occurred.

The result code will appear in the circled area illustrated below.

- Example of a log file

```
*1.0.0*
*ExecType*, *Date*, *SerialNo*, *PnP*, *Model*, *Destination*, *IP*, *Host*, *Storage*, *FileName*, *FileID*, *TotalItem*, *NumOfOkItem*, *ResultCode*, *ResultName*, *Identifier*
*IMPORT*
*2012-07-05T15:29:16+09:00*
*3C35-7M0014*
*Brand Name*
*Product Name*
*0*
*10*
*10.250.155.125*
*RNP00267332582D*
*SD*
*201207051519563C35-710220.csv*
*201207051519563C35-710220*
* 0*
* 2*
*...ID REQUEST*
*TargetID*, *ModuleID*, *PrefixID*, *Item*, *NgCode*, *NgName*
```

w_d1825500

If you cannot solve the problem or do not know how to solve it after checking the code, note down the error log entry, then contact your supervisor.

2 (INVALID REQUEST)

- **Cause:** A file import was attempted between different models or machines with different device configurations.
- **Solution:** Import files exported from the same model with the same device configurations.

4 (INVALID OUTPUT DIR)

- **Cause:** Failed to write the device information to the destination device.
- **Solution:** Check whether the destination device is operating normally.

7 (MODULE ERROR)

- **Cause:** An unexpected error occurred during import or export.
- **Solution:** Switch the power off and then back on, and then try the operation again. If the error persists, contact your supervisor.

8 (DISK FULL)

- **Cause:** The available storage space on the external medium is insufficient.
- **Solution:** Execute the operation again after making sure there is enough storage space.

9 (DEVICE ERROR)

- **Cause:** Failed to write or read the log file.
- **Solution:** Check whether the path to the folder for storing the file or the folder in which the file is stored is missing.

10 (LOG ERROR)

- **Cause:** The hard disk is faulty.
- **Solution:** Contact your supervisor.

20 (PART FAILED)

- **Cause:** Failed to import some settings.
- **Solution:** The reason for the failure is logged in "NgCode". Check the code.

Reason for the Error (Ng-Name)

2. INVALID VALUE

The specified value exceeds the allowable range.

3. PERMISSION ERROR

The permission to edit the setting is missing.

4. NOT EXIST

The setting does not exist in the system.

5. INTERLOCK ERROR

The setting cannot be changed because of the system status or interlocking with other specified settings.

6. OTHER ERROR

The setting cannot be changed for some other reason.

21 (INVALID FILE)

- **Cause:** Failed to import the file because it is in the wrong format in the external medium.
- **Solution:** Check whether the file format is correct. The import file should be a CSV file.

22 (INVALID KEY)

- **Cause:** The encryption key is not valid.
- **Solution:** Use the correct encryption key.

Note

- When exporting device information from the control panel, the data can be saved only on an SD card. The file format for exports is CSV.

Address Book Upload/Download

Information List

The following information is possible to be uploaded and downloaded.

- Registration No.
- User Code
- E-mail
- Protection Code
- Group Name
- Key Display
- Select Title
- Folder
- Local Authentication
- Folder Authentication
- Account ACL
- New Document Initial ACL
- LDAP Authentication


Download Address Book

1. Prepare a formatted SD card.
2. Make sure that the write-protection on the SD card is off.
3. Turn off the main power switch of the main machine.
4. Remove the SD slot cover.
5. Insert an SD card into Slot 2.
6. Turn the machine on.
7. Enter the SP mode.
8. Do **SP5846-051** (Backup All Addr Book).
9. Exit the SP mode, and then turn the machine off.
10. Remove the SD card form Slot 2.
11. Re-attach the SD card slot cover.

Note

- If the capacity of SD card is not enough to store the address book data, an error message is displayed.
- Handle the SD card with care.
- Never remove an SD card with address book information from the work site.

Upload Address Book


1. Turn the machine off.
2. Remove the SD slot cover [A] ( x 1).
3. Insert the SD card that holds the address book data into Slot 2.
4. Turn the machine on.
5. Enter the SP mode.
6. Do **SP5846-052** (Restore All Addr Book).
7. Exit the SP mode, and then turn the machine off.
8. Remove the SD card from Slot 2.
9. Re-attach the SD slot cover.

★ Important

- **The counter in the user code information is initialized after uploading.**
- **Administrator and supervisor related information can be neither downloaded nor uploaded.**
- **If there is no address book data on the SD card, the machine will return an error message.**

RFU Firmware Update

In this machine, software can be updated by remote control using @Remote.



w_d1463115_eng

RFU Conditions

RFU can be done with a device which meets the following conditions:

There are two conditions for RFU:

1. First, the customer must consent to the use of RFU.
2. Second, the device must be connected to a network via TCP/IP for @Remote.

Firmware Update (Auto Remote Firmware Update)


Note

- Auto remote firmware update (ARFU) requires connection to an external network. Be sure to get permission from the customer before setting.
- Internet connection is needed.

Overview

By Auto Remote Firmware Update (ARFU), the firmware is updated by checking the global server every 76 hours and downloading the latest package if it is newer than the one installed on the machine.

Function Overview



(3) Automatic firmware update

w_d238z5023e

Types of firmware update files, supported update methods:

	SFU	SD Card	RFU	ARFU
Individual firmware	N/A	Available	Available	N/A
Package firmware	Available	Available	Available	Available

What is Included in the Firmware Package


Modules included in the firmware package are indicated by ticks (✓).

Firmware not included in the package requires updating by SD cards, etc.

Included	Firmware
-	aics
✓	animation

Included	Firmware
✓	Application Site
✓	BluetoothService
✓	CheetahSystem
-	CSPF
-	Data Erase Onb
-	EcoInfoWidget
✓	Engine
-	External Auth
✓	Fax
-	FaxInfoWidget
✓	GWFCU3.8-9(WW)

Downloading and Updating Process



w_d238z5024e

Downloads the latest package

The machine checks the server for the latest package version.

If the version of the package on the global server is later than that of the package installed on the machine, or if the machine has not downloaded the firmware package, the machine downloads the latest package in the background even when the customer is using the machine.

If download fails, the machine will retry downloading 76 hours later.

The downloaded package can also be used with SFU (Smart Firmware Update). A package downloaded with SFU (Smart Firmware Update) can be used with ARFU (Auto Remote Firmware Update) and vice versa.

When replacing the hard disk, information concerning the current firmware package becomes lost from the hard disk. So, even if the latest firmware is on the new hard disk, be sure to download the latest package data.


When the machine connects to the server where the package files are stored, the DNS settings and the name solution by DNS are needed. The machine will still try to download the package even if the name cannot be resolved, but will fail as the name is not resolved.

The time and date to send the next inquiry to the global server can be checked with SP5-886-1 16 (Farm Update Setting: Auto Update Next Date).

The auto remote firmware update is executed every 76 hours.


Judgement of ARFU

Update judgement is done when the latest update package is successfully downloaded, or the package has already been downloaded.




w_d238m0998e

If the judgement timing is in the range of the update prohibited time or day set with SP or WIM, the machine will retry the update after 76 hours.



If the machine is in use when the judgement process runs, the process is retried. Retry is done up to three times every hour (can be changed with SP) and if the machine is in use for all three retries, the machine will retry the update after 76 hours

6




Situations judged as machine in use

No.	Situations judged as machine in use
1	When the control panel is used within 30 seconds
2	During firmware update
3	While firmware update is disabled
4	While printing (copy, printer, fax, re-printing via network)

No.	Situations judged as machine in use
5	While scanning (copy, scanner, fax)
6	Retrieving image data via network
7	While initial setting (User Tools settings) or SP is being set
8	While fax is transferring data
9	During on hook / on handset
10	During the PC-FAX process (from PC to machine data transfer to the end of the job)
11	While shifting to/from the energy server mode
12	When not being able to run firmware update due to the modules that are running e.g.) Waiting for DCS transfer (refer to appendix), accessing devices such as HDD/SD card, etc.
13	While displaying a preview
14	While the document server function is in use
15	Connecting to TWAIN
16	During the interrupt copy process
17	While displaying the printer menu
18	While updating the display for the document server function via WIM or for stored fax documents
19	While writing log information
20	While accessing the address book
21	During SC

Update Process

When the machine has decided to run the auto firmware update, the following message is displayed.



d238m2106

The popup will have "Cancel" and "OK" buttons and the update process will start either when the "OK" button is selected or 30 seconds has passed.

When the "Cancel" button is selected, the machine will run the "Retry update" process.

When the device update and three retries in recovery mode both fail, it is determined as a device defect and will display an SC for the defective device. If such an SC appears, replace the indicated board. In the case of SC845, the SC cannot be reported to the call center.



6

Device and corresponding SC number.

Device name	SC number
Engine board	SC845-01
Controller board	SC845-02
Operation panel (normal panel)	SC845-03
Operation panel (smart panel)	SC845-04
FCU	SC845-05

Canceling the update

It is possible to cancel the Auto Remote Firmware Update (ARFU) or update in recovery mode from the operation panel.



d238m2107

But this is not possible while updating the operation panel itself. On the other hand, the update for the operation panel will run at the final stage of the update. Thus canceling the update at that stage has no real effect.

When the update is cancelled, the machine will reboot when updates for all modules of one of the following devices is done.

1. Engine Board
2. FCU
3. Controller Board
4. Operation Panel

For example, when the update process is cancelled while updating the first module of the operation panel, the machine will reboot when all modules in the operation panel have been updated.

The firmware contents included in the package can be referred to in the release note in SERES release of the package.

The next update will run 76 hours after the cancellation. The old (cancelled) package will be discarded if the package downloaded 76 hours later is the latest.

Related SP

SP Number	Selection Def.	Overview
SP5-886-111	0: OFF 1: ON	Sets auto update ON/OFF by ARFU.
SP5-886-112	0: OFF 1: ON	Will not run the update when update prohibited time setting is ON and the current time is in the range of the time set. <ul style="list-style-type: none"> Start time < End time: Prohibited time is from the start time to the end time on the same day. Start time > End time: Prohibited time is from the start time to the end time on the next day. Start time == End time: Prohibited time setting is disabled. (Update will not be prohibited.)
SP5-886-113	0 to 23 9	
SP5-886-114	0 to 23 17	
SP5-886-115	0: OFF 1: ON	Even when the update function is disabled, downloading the package is allowed. The downloaded package can be used with SFU.
SP5-886-116	Display only	Displays when the latest package check will run.
SP5-886-117	1 to 24 1	Set time for the next version check after retry.
SP5-886-120	0x00	Update will not run if the corresponding bit for each day below is set to 1. <ul style="list-style-type: none"> prohibited:bit7 Monday: bit 6 Tuesday: bit 5 Wednesday: bit 4 Thursday: bit 3 Friday: bit 2 Saturday: bit 1 Sunday: bit 0 This setting is not affected by the prohibited time setting. e.g.) Prohibited on Mon., Fri., Sat., and Sun. : 0x47 (01000111)

SP Number	Selection Def.	Overview
SP7-520-011 to 015	Display only	History of date and time when update has started. The five most recent are recorded, the lowest number being most recent. If the last update failed, this is not recorded.
SP7-520-021 to 025	Display only	History of date and time when update has finished. The five most recent are recorded, the lowest number being most recent. The record is created when the update has successfully finished. When the update is cancelled, no record is created.
SP7-520-031 to 035	Display only	History of the package number (including suffix) for which update has completed. The five most recent are recorded, the lowest number being most recent. The record is created when the update has successfully finished. When the update is cancelled, no record is created.
SP7-520-041 to 045	Display only	History of the package version for which update has completed. The five most recent are recorded, the lowest number being most recent. The record is created when the update has successfully finished. When the update is cancelled, no record is created.
SP7-520-051 to 060	Display only	History of the result of the download and the update. Refer below for the numbers set.

Numbers set for the result history for SP7-520-051 to 060

No.	Result	Description
1	Downloading with SFU	Cannot download or update as the machine is now downloading the package for SFU.
2	HDD uninstalled	Cannot download or update as the machine has no HDD.
3	Updating with SFU	Cannot download or update as the machine is being updated with SFU.

No.	Result	Description
4	HDD error	Cannot download or update as the HDD cannot be used.
5	Version information obtain error	Cannot download or update as the version information cannot be obtained.
6	Update download error	Cannot download or update as the update download failed. In non @Remote method, this shows that the download failed because there was no proxy set.
7	Name resolution error	Cannot download or update as the name cannot be resolved upon downloading the update.
8	Auto update setting disabled	The package has been downloaded but will not run the update as SP5-886-111 (auto update setting) is disabled and SP5-886-115 (auto download setting for SFU) is enabled.
9	Update prohibited time	Cannot start to update as the auto update prohibited time setting (SP5-886-112) is enabled and the time update initiated was in the range of prohibited time (SP5-886-113 to 114). Or the day which update was initiated was a day for which update was prohibited (SP5-886-120).
10	Update postponed due to machine in use	Cannot start update due to the following conditions when update was initiated. <ul style="list-style-type: none"> • The machine is in use by a user (the panel was used within 30 seconds) • Machine offline for other reasons • Operation prohibited • Displaying SP/UP menu • Firmware update is running with another method • Configuration change prohibited • Verifying the operation panel (smart panel)
11	Update cancelled by user	Update was cancelled because a user selected "Cancel" in the popup shown before starting the update.

No.	Result	Description
12	Offline failed	Cannot start to update as the machine is offline for other reasons.
13	Update successful	Update was started and successfully completed.
14	Update failed	Update was started but failed.
15	Update cancelled by user after update initiated	Update was cancelled after the process initiated because a user selected "Cancel" during the update.
16	Update deemed completed	Update was cancelled after the process was initiated because a user selected "Cancel". There is no need to resume the update due to one of the following reasons: <ul style="list-style-type: none"> • A newer update has been released and received. • When retrying ARFU, the update has already been completed by another method.
17	Version information obtain error (proxy verification failure)	Cannot download or update as the proxy verification failed with proxy settings when obtaining version information.
18	Version information obtain error (other than proxy verification failure when proxy is set)	Cannot download or update as an error other than proxy verification with proxy settings occurred when obtaining version information.
19	Update download error (proxy verification failure)	Cannot download or update as the proxy verification failed with proxy settings when downloading the package.
20	Update download error (other than proxy verification failure when proxy is set)	Cannot download or update as an error other than proxy verification with proxy settings occurred when downloading the package.
22	Update by retry successful	After power failure, unsuccessful update, or rebooting, update by retry is executed successfully. However, this does not apply to the case where the update was cancelled after the process was initiated because a user selected "Cancel". In this case, the update is "successful" if the retry is not executed between the start and completion of the next update (76 hours after the cancellation).

Package Firmware Update

⚠ CAUTION


- The HDD unit must be installed on the machine to enable the SFU or the package firmware update via SD card.

Overview

Each firmware module (such as System/Copy, Engine, etc) used to be updated individually. However, an all-inclusive firmware package (package_ALL) is now available.

There are two ways to update using the firmware package.

- Package Firmware Update via a network: SFU (Smart Firmware Update)
- Package Firmware Update with an SD card



w_d176f2130

Package Firmware Update via a network: SFU (Smart Firmware Update)

- There are two methods for SFU.
 - Immediate Update: To update the firmware when visiting
 - Update at the next visit: To set the date and time for downloading. The firmware will be automatically downloaded beforehand and updated at the following visit.
- “Update at the next visit” is recommended since firmware download may take some minutes due to the network condition.

↓ Note

- SFU requires the connection to @Remote via a device which has the embedded @Remote communicating function. When a machine is connected to @Remote via an intermediate device (RC Gate), the SFU function is disabled.

Package Firmware Update via an SD Card

Package firmware update can also be performed using the conventional SD card method by writing the package firmware directly to the SD card.

Types of firmware update files, supported update methods:

	SFU	SD	RFU
Individual firmware	N/A	Available	Available
Package firmware	Available	Available	N/A


Immediate Update

Enter the [Firmware Update] menu in the SP mode and update the package firmware.

Note


- The [Firmware Update] button will appear even when a machine is connected to @Remote with a device which does not have an embedded @Remote communicating function.
- If an error code is displayed, refer to Errors During Firmware Update (page 1186).

1. Enter the SP mode.
2. Touch [Firmware Update].




d197f0507

3. Touch [Update].




d197f0508


4. Touch [Execute Update].



5. Touch [YES].



6. The following display will be displayed.




Note


- If the error code E66, which indicates that the download of the firmware has failed, is displayed, implement this procedure from step 1.

- Update will be started automatically after the download is finished.
- When the machine is in the update mode, the automatic update is suspended if a print job is implemented.

After the print job is finished, touch [YES] on the display shown with the following picture to restart updating.



7. [Update done] is displayed. The machine will automatically reboot itself.



Note

- The numbers in the lower right corner of the screen indicate “Number of updated items/ All items to be updated”.

Update at the Next Visit (Reserve)

It is possible to set the machine to download the package firmware which is necessary for SFU in advance, and then perform the actual installation at the next service visit. This saves waiting time for the firmware to download at the service visit.


How to Set the Machine to Download Firmware Later (RESERVE)

Enter the [Firmware Update] menu in the SP mode and update the package firmware.

Note


- The [Firmware Update] button will appear even when a machine is connected to @Remote with a device which does not have an embedded @Remote communicating function. If an error code is displayed, refer to Errors During Firmware Update (page 1186).

1. Enter the SP mode.
2. Touch [Firmware Update].




d197f0507

3. Touch [Reserve].




4. Touch [Reservation setting].



6


5. Enter the dates and times of next visit and start of receiving data.

- "Next time to visit this customer": The package firmware will be automatically downloaded by this time/date.
- "When to receive? (1-7)": The download of the package firmware will begin this number of days before the next visit.



Successful Download


In the two diagrams below, the firmware is set to be downloaded by the day before the next scheduled visit. In the first diagram, the download is successful on the first try. In the second diagram, the download fails three times and is successful on the fourth try.



- If the firmware download fails or cannot be completed due to the network settings/condition, no power to the machine, or other reason, the machine will continue retrying every six hours until the scheduled deadline (up to a maximum of four tries). For example, if the download is set for the day before the next visit, the machine will attempt the download at 24 hours before the visit, and then continue trying every six hours (max. four tries total).
- The retry is only performed in cases when the firmware download has failed.
- If the machine is in Energy Saver mode when the download is scheduled to begin, the download will be performed in the background and the machine/panel will stay in Energy Saver mode.
- The download will continue uninterrupted even if the customer initiates a print job, copy job, fax receiving or other operation while the download is in progress.
- The download will be terminated if the customer turns the power off while the download is in progress.
- If the download cannot be completed successfully by the time of the next scheduled visit, the machine will stop trying to download the firmware.


How to Check if the Firmware Downloaded with RESERVE

1. Enter the SP mode.
2. Touch [Firmware Update].




d197f0507

3. Touch [Reserve].



d197f0508


4. Touch [Reserve and received package information].



d197f0510

5. Check the information displayed.

When the package firmware is downloaded successfully, the details of the download result are displayed as the following picture shows.



d197f0511


Note

- This information will only be displayed if the reserved firmware has already been downloaded. If not, all the data items are indicated with "-".

How to Install Firmware Downloaded with RESERVE


6

1. Enter the SP mode.
2. Touch [Firmware Update].




d197f0507

3. Touch [Update].




d197f0508

4. Touch [Execute Update].




d197f0509

5. Check the version of the received package firmware, and then touch [YES].
Update is started.



d197f0516

If the version of the reserved package in the HDD is older than the latest version, the messages shown in the following picture are displayed.




d197f0517

- If you wish to download the latest version, touch [Execute] beside the message "Download and update the latest package." Then update of the package firmware will be started.
- If you wish to update using the firmware in the HDD (old version), touch [Execute] beside the message "Update to the received package."

6. [Update done] message is displayed. The machine will automatically reboot.

6



d197f0518

↓ Note


- The numbers in the lower right corner of the screen indicate “Number of updated items/ All items to be updated”.

Update via SD card

Update with an SD card, which is the conventional method, is available if you write the package firmware to the SD card.

↓ Note


- If an error code is displayed, refer Errors During Firmware Update (page 1186).
1. Create a new folder in the SD card, and then name it “package”.
 2. Copy the package firmware (xxxxxxx.pkg) to this folder.



d197f0504


★ Important

- If you copy the package firmware into the conventional “romdata” folder, the update will not work.
 - Only one version of the package firmware should be copied into the folder.
 - If you copy multiple versions of package firmware to the SD card, the machine will select only one version of the firmware randomly.
3. Turn the power OFF.
 4. Insert the SD card which contains the package into SD card slot 2 (for service).
 5. Turn the machine on and touch [Update].




d176f2127

When the SD card contains both a firmware package and one or more modules, the following display may show up. Select [Package] and touch [OK] to move to step 4 above.



d176f2128

6. Update is started automatically after the package firmware download to the HDD has been completed.
7. When update is completed, "Update done" is displayed.



Note

- The numbers in the lower right corner of the screen indicate "Number of updated items/ All items to be updated".

8. Turn the main power switch OFF, and then pull out the SD card from SD card slot 2.
9. Turn the machine on.

Capturing Debug Logs

Overview

With this feature, you can save debug logs that are stored in the machine (HDD or operation panel) on an SD card. This function allows the Customer Engineer to save and retrieve error information for analysis. The Capturing Log feature saves debug logs for:

- Controller
- Engine
- Operation panel

★ Important

- In older models, a technician enabled the logging tool after a problem occurred. After that, when the problem had been reproduced, the technician was able to retrieve the debug log.
- However, this new feature saves the debug logs whenever a problem occurs, and then this log can be saved to an SD card.
- You can retrieve the debug logs with an SD card without a network.
- Analysis of the debug log is effective for problems caused by the software. Analysis of the debug log is not valid for the selection of defective parts or problems caused by hardware.

Types of debug logs that can be saved

Type	Storage Timing	Destination (maximum storage capacity)
Controller debug log (GW debug log)	<ul style="list-style-type: none"> • Saved at all times 	HDD (4 GB). Compressed when written to an SD card from the HDD (from 4 GB to about 300 MB)
Engine debug log	<ul style="list-style-type: none"> • When an engine SC occurs • When paper feeding/output stop by jams • When the machine doors are opened during normal operation 	HDD (up to 300 times)

Type	Storage Timing	Destination (maximum storage capacity)
Operation panel debug log	<ul style="list-style-type: none"> • When a controller SC occurs • When saving by manual operation with the Number keys and the Reset key (Press "Reset", "0", "1" and "C" (hold for 3 seconds)) • When the operation unit detects an error • When the operation panel detects an error 	<p>Operation panel (400 MB /Up to 30 times)</p> <p>When updating the firmware for the operation panel, the debug logs are erased.</p>

Debug logs are not saved when:

- Memory is being erased
- Data encryption equipment is being installed
- Firmware configuration is being changed
- There is a power outage (power cord disconnected accidentally)
- The machine is shutdown normally with the power switch and data write to the HDD cannot be completed. For example, when shutdown starts immediately after a paper jam occurs or the front door is opened or closed, the machine needs about 5 sec. to save the debug log after the machine stops completely.
- Power supply to the HDD is off because of energy saving (engine OFF mode /STR mode)

Operation Log Security

The following operation logs related to security are never saved.

- User ID
- Password
- IP address
- Telephone number
- Encryption key
- Transition to SP mode

The following operation logs are never saved.

- Number keys (0 to 9) on the operation panel
- Soft keyboard on the touch panel display
- External keyboard

Retrieving Debug Logs

Retrieve debug logs to identify the date of occurrence and details about problems.

- Analysis of the debug log is effective for problems caused by the software.
- Analysis of the debug log cannot identify defects in parts or problems caused by hardware.

Procedure for Retrieving the Debug Log

1. Insert the SD card into the slot on the left side of the operation panel.



d223c3777

2. Enter SP mode.
3. Set the start date of the log with **SP5857-101**.
 - Enter the date in the format `yyyymmdd` where `yyyy` is the year, `mm` the month, and `dd` the day.
 - For example, for March 28, 2013 you would enter "20130328"
 - Enter a date 72 hours before the problem occurred.
4. Set the end date of the log with **SP5857-102**.
 - Use the same format (`yyyymmdd`) that you used to enter the start date.
 - For example, for March 31, 2013 you would enter "20130331".
5. Next, do **SP5-857-103** to retrieve the debug log data and store it onto the SD card.

SP	Function
5857-103	All debug log
5857-104	Controller debug log
5857-105	Engine debug log

SP	Function
5857-107	Operation panel log

6. When the transfer is finished, the machine will display "Completed" on the operation panel.

★ Important

- The length of time needed to transfer the debug log data can be affected by the type and format of the SD card. Formatting the SD card with Panasonic SD Formatter (freeware) is recommended.

The approximate time required for the transfer of the following debug logs are:

- Controller (GW): 2 to 20 min.
- Engine debug log: 2 min.
- Operation: 2 to 20 min.

1. Make sure that the SD card access LED is off, then remove the SD card.

If you see the "Failed" message, remove the SD card, cycle the machine off/on, and then repeat this procedure from Step 2.

Debug logs are saved with the following file names.

Debug Log	Filename Format
Controller(GW)	/LogTrace/machine no./watching/yyyymmdd_hhmmss_unique ID.gz
Engine	/LogTrace/machine number/engine/yyyymmdd_hhmmss.gz
Operation Panel	/LogTrace/machine no./opepanel/yyyymmdd_hhmmss.tar.gz

7. Troubleshooting

Self-Diagnostic Mode

Service Call Codes

Service Call Conditions

Level	Display	How to reset
A	Fatal error. The SC is displayed on the operation panel, and the machine cannot be used (safety-related SC).	Execute CE reset with SP5810 , and then cycle the machine off/on..
B	When a function is selected, the SC is displayed on the operation panel, and the machine cannot be used.	Cycle the machine off/on.
C	No display on the operation panel, and the machine can be used.	Count only logging.
D	The SC is displayed on the operation panel, and the machine cannot be used (machine-error SC).	Cycle the machine off/on.

- When a Level D code is returned, an automatic reboot is performed.
- When an event is reported by the customer support system, even in the event of an ordinary SC, reboot is not performed. During automatic reboot, a confirmation screen is displayed after the reboot.
- When automatic reboot occurs twice, an SC is displayed without rebooting, and logging count is performed. Also, when an SMC print is output, an asterisk (*) is attached to the SC number
- Automatic reboot can be enabled or disabled with **SP5875-001** (SC automatic reboot setting) (default value: ON).

SC Logging

When an SC is generated, the "total count value when the SC is generated" and the "SC code" are logged. However, if the total count value during the SC is the same as last time, logging is not performed.

Logged data can be checked by printing and SMC report. The SC history is logged up to the last 10 entries, and if there are more than 10 entries, data are progressively deleted starting from the oldest.

SC Automatic Reboot

When a Level D SC is returned, the machine reboots automatically.

- Automatic reboot or reboot by the operator can be set by SP5-875-001 (SC automatic reboot setting out) (default value: 0 "Automatic reboot").
- When a Level D error occurs, automatic reboot is done or the machine display asks the customer if it can reboot. However, when the SC occurs twice in succession, the machine sends a report to the @Remote server without rebooting.
- This is because just rebooting may not be a good solution if an SC occurs twice.
- When an automatic reboot is performed, a confirmation screen is displayed after reboot. The confirmation screen can be cancelled by pressing the [OK] key (display is not cancelled only when the main power switch is switched OFF to ON).

Screen display during reboot

- Status display on the current screen
 - Post-processing Post-processing during printing, etc.



- Automatic reboot ... After operation end



- Reset key (Reboot key)
Key to perform reboot
Cancel key is not displayed.
- Turn on spanner LED (same as when an SC is generated).

Operation during SC reboot

- Timing of SC reboot

When @Remote is enabled, and when a NRS alarm* 1 is not generated, the corresponding SC is the object of an automatic reboot.

* 1 NRS alarm: Issued when an ordinary SC (type D) is generated twice while the total counter counts 10 times.


- Time to automatic reboot

Reboot is performed 30 seconds after an engine reboot is possible, after the end of post-processing during printing, etc.

At that time, a reboot is performed even if the MFP is operating. The engine does not start process control when a reboot is possible.

- Automatic reboot

See the flowchart below.



Service Call Conditions

Service Mode Lock/Unlock

At locations where the machine contains sensitive data, the customer engineer cannot operate the machine until the Administrator turns the service mode lock off. This function ensures that work on the machine is always done with the permission of the Administrator.

1. If you cannot go into the SP mode, ask the Administrator to log in with the User Tool and then set "Service Mode Lock" to OFF. After he or she logs in:
 - User Tools > System Settings > Administrator Tools > Service Mode Lock > OFF
 - This unlocks the machine and lets you get access to all the SP codes.
 - The customer engineer can do servicing on the machine and turn the machine off and on. It is not necessary to ask the Administrator to log in again each time the machine is turned on.
2. If you must use the printer bit switches, go into the SP mode and set SP 5169 to "1".
3. After machine servicing is completed:
 - Change SP5169 from "1" to "0".
 - Cycle the machine off/on.
 - Tell the administrator that you completed servicing the machine.
 - The Administrator will then set the "Service Mode Lock" to ON.

Service Call Conditions

There are 4 levels of service call conditions.

Level	Definition	Reset Procedure
A	Fusing unit SCs displayed on the operation panel. The machine is disabled. The user cannot reset the SC.	This is a fatal error. The machine cannot be used until the service technician releases it for servicing with SP5810 , solves the problem, and then cycles the machine off/on.
B	SCs that disable only the features that use the defective item. Although these SCs are not shown to the user under normal conditions, they are displayed on the operation panel only when the defective feature is selected.	Turn the main power switch off/on.

Level	Definition	Reset Procedure
C	SCs that are not shown on the operation panel. They are internally logged.	Logging only. The SC code is logged but not displayed.
D	Cycling the machine off/on resets SCs displayed on the operation panel. These are re-displayed if the error occurs again.	Cycle the machine off/on with the power switch.

Before You Use the Tables

The following notations are used to identify which finisher the SC codes refer to.

Notation	Finisher
D610	Finisher SR4080 (D610)
3K Finisher	Finisher SR4120 (D3CG) (Max. tray capacity: 3,000 sheets)
2K Finisher	Finisher SR4130 (D3CH) (Max. tray capacity: 2,000 booklets)
D615	Multi Folding Unit FD4000 (D615)

Only one of these finishers can be installed in the system. Many of the SC codes apply to more than one finisher because they have nearly identical parts and part names.

Example

SC725	B	Exit guide motor (D610/D3CG/D3CH)
		The status of the exit guide sensor did not change at the prescribed time during operation of the exit guide.
		<ul style="list-style-type: none"> Exit guide open sensor loose, broken, defective. Exit guide motor defective Finisher main board defective
		<ul style="list-style-type: none"> Inspect exit guide open sensor, and reconnect it. Replace exit guide open sensor Replace exit guide motor Replace finisher main board

SC725 applies to the exit guide motor of whichever finisher is installed: The SR4080, the Finisher SR4120, or the Booklet Finisher SR4130.

 **Important**

- If a problem concerns electrical circuit boards, always disconnect then reconnect the connectors before replacing the PCBs.
- If a motor lock error occurs, first check the mechanical load (obstacles like waste paper, tools, etc. that are interfering with operation of the motor) before replacing motors or sensors.
- When a Level "A" or "B" SC occurs while in an SP mode, the display does not display the SC number. If this occurs, check the SC number after leaving the SP mode.

SC100: Scanning

SC100

7

SC101-01	D	Exposure lamp error: Front side scan
		The peak detection level reading on the reference white plate is too low.
		<ul style="list-style-type: none"> • Defective exposure lamp LED • SBU (LED driver) on lens block defective • BICU defective • Power source, signal harness loose, broken, defective • Condensation in scanner unit • Scanner mirror or lens out of position or dirty • Reference white plate out of position or dirty
		<ul style="list-style-type: none"> • Check harness connections of exposure lamp, SBU, BICU • Inspect scanner unit for moisture. If moisture detected, install scanner heater. • Remove exposure glass and inspect scanner mirror, lenses and clean. • Raise ADF and check condition of white plate. Clean and re-position. • Replace exposure lamp. • Replace lens block with new SBU • Replace BICU.
SC101-02	D	Exposure lamp error: Front side (LR) scan initialization
		One or more of the elements in the LEDs on either side failed to light.
		<ul style="list-style-type: none"> • LED (both sides) defective • SBU (LED driver) on lens block defective • Power source, signal harness loose, broken, defective

		<ul style="list-style-type: none"> • Cycle the machine off/on • If that does not solve the problem, inspect the exposure lamp harnesses for loose, broken, defective connection. • Reset the harnesses. • Replace exposure lamp LED PCBs. • Replace lens block (SBU LED driver)
SC101-05	D	Exposure lamp error: Front side (L) scan initialization
		One or more of the elements of the left LED failed to light.
		<ul style="list-style-type: none"> • Left LED defective • SBU (LED driver) on lens block defective • Power source, signal harness loose, broken, defective
		<ul style="list-style-type: none"> • Cycle the machine off/on • If that does not solve the problem, inspect the exposure lamp harnesses for loose, broken, defective connection. • Reset the harnesses. • Replace exposure lamp LED PCBs. • Replace lens block (SBU LED driver)
SC101-06	C	Exposure lamp error: Front side (R) scan initialization
		One or more of the elements of the right LED failed to light.
		<ul style="list-style-type: none"> • Right LED defective • SBU (LED driver) defective • Power source, signal harness loose, broken, defective
		<ul style="list-style-type: none"> • Cycle the machine off/on • If that does not solve the problem, inspect the LED harnesses for loose, broken, defective connection. • Reset the harnesses. • Replace right LED PCB. • Replace lens block (SBU LED driver)
SC102-00	D	Exposure lamp error: Front side

		The reading of the reference white plate within the specified number of pulses returned a value that was too high.
		<ul style="list-style-type: none"> • LED defective • SBU (LED driver) defective • SBU defective • BICU defective • Power source harness, or signal harness loose, broken, defective
		<ul style="list-style-type: none"> • Cycle the machine off/on • Inspect and reset power harness, signal harness • Replace exposure LED PCBs • Replace lens block (SBU LED driver).
SC120-00	D	Scanner home position error 1
		The scanner HP sensor does not detect the OFF condition during initialization or copying.
		<ul style="list-style-type: none"> • BICU defective • Scanner motor defective • Scanner HP sensor defective. • Harness between BICU, SIOB, scanner motor disconnected. • Harness between scanner HP sensor and BICU disconnected. • Scanner wire, timing belt, pulley, or carriage installed incorrectly.
		<ul style="list-style-type: none"> • Inspect installation of scanner wire, timing belt, pulley, carriage. • Inspect the harness between scanner HP sensor and BICU. • Check function of scanner HP sensor (input/output check) and replace sensor if defective. • Check operation of scanner motor (input/output check) and replace motor if defective. • Replace BICU.

SC121-00	D	Scanner home position error 2
		The scanner HP sensor does not detect the ON condition during initialization or copying.
		<ul style="list-style-type: none"> • BICU defective • Scanner motor defective • Scanner HP sensor defective • Harness between BICU, SIOB, scanner motor disconnected • Harness between scanner HP sensor and BICU disconnected • Scanner wire, timing belt, pulley or carriage installed incorrectly.
		<ul style="list-style-type: none"> • Inspect installation of scanner wire, timing belt, pulley, carriage. • Inspect the HP sensor harness • Inspect harnesses to BICU • Check function of scanner HP sensor (input/output check) and replace sensor if defective. • Check operation of scanner motor (input/output check) and replace motor if defective. • Replace BICU.
SC141-00	D	Black level detection error
		The black level cannot be adjusted within the target during auto gain control.
		<ul style="list-style-type: none"> • Harness to BICU loose, broken, defective • Defective SBU • Defective BICU
		<ul style="list-style-type: none"> • Check the harness connections from scanner unit to BICU • Replace the lens block (new SBU) • Replace the BICU

SC142-00	D	White level detection error
		The white level cannot be adjusted to the second target level within the target during auto gain control.
	-	<ul style="list-style-type: none"> • Dirty exposure lamp or optics section • SBU board defective • BICU board defective • Harnesses are disconnected. • Exposure LED (lamp) defective • Lamp stabilizer defective • Scanner motor defective
		<ul style="list-style-type: none"> • Clean the exposure glass, white plate, mirrors, and lens. • Check if the exposure LEDs light during initialization • Check the harness connections • Replace the exposure LED lamps. • Replace the scanner motor. • Replace the lens block (SBU), BICU
SC144-00	D	SBU transmission error
		<p>After the SBU switches on, the BICU detects one of the following conditions on the SBU:</p> <ul style="list-style-type: none"> • 1 s after power on, the SYDO signal does not go high, even after 1 retry. • 1 s after power on, the SYDO signal goes high, but the SBU ID could not be read after 3 attempts.
		<ul style="list-style-type: none"> • SBU defective • BICU defective
		<ul style="list-style-type: none"> • Inspect harness between scanner unit and BICU • Replace lens block (new SBU) • Replace BICU.
SC151-00	D	Black level error: Back side

		Not even one pixel was within permitted range when the black level was created.
		<ul style="list-style-type: none"> • CIS defective
		<ul style="list-style-type: none"> • Replace CIS

SC152-00	D	White level error: Back side
		The value of the shading peak data return from the CIS device was defective.
		<ul style="list-style-type: none"> • ADF CIS device defective • CIS white roller background or white plate damaged • CIS dirty or installed incorrectly
		<ul style="list-style-type: none"> • Inspect CIS harnesses and connections. • Check CIS background roller for damage, clean dirt, check installation • Replace CIS.

SC154-00	D	Scanner communication error: Back side
		The read operation of the ASIC registry in the CIS returned an unexpected value.
		<ul style="list-style-type: none"> • Harness between the ADF PCB and CIS is loose, broken, defective • ASIC in CIS is defective • FROM in CIS is defective
		<ul style="list-style-type: none"> • Inspect and reset power harness, signal harness. • Replace CIS signal harness • Replace CIS • Replace ADF main board.

SC195-00	D	Machine serial number error
		The number registered for the machine serial number does not match.
	-	<ul style="list-style-type: none"> • The correct 11-digit serial number must be registered in the main machine.

		<ul style="list-style-type: none">• Confirm the correct serial number.• The correct serial number must be entered with SP5811-001.
--	--	---

SC200: Exposure

SC200

SC202-00	D	Polygon mirror motor error 1: Timeout at ON
		The polygon mirror motor unit did not enter "Ready" status within 20 sec. after the motor was turned on,
		<ul style="list-style-type: none"> • The polygon mirror motor PCB connector is loose, broken, or defective • Polygon mirror motor PCB defective • Polygon mirror motor defective • BICU defective
		<ul style="list-style-type: none"> • Inspect polygon mirror motor harness, replace if damaged • Replace polygon mirror motor • Replace BICU
SC203-00	D	Polygon mirror motor error 2: Timeout at OFF
		The polygon mirror motor did not leave "Ready" within 3 sec. after the motor was switched off. (The XSCRDY signal did not go HIGH (inactive) within 3 sec.)
		<ul style="list-style-type: none"> • The polygon mirror motor PCB connector is loose, broken, or defective • Polygon mirror motor PCB defective • Polygon mirror motor defective
		<ul style="list-style-type: none"> • Inspect polygon mirror motor harness, replace if damaged • Replace polygon mirror motor

SC204-00	D	Polygon mirror motor error 3: XSCRDY signal error
		The polygon mirror motor "Ready" signal goes inactive (HIGH) while images are being produced or the synchronization signal is being output.
		<ul style="list-style-type: none"> • Polygon mirror motor PCB connector loose, broken, defective • Polygon mirror motor PCB defective • Polygon mirror motor defective
		<ul style="list-style-type: none"> • Inspect motor PCB connection • Replace polygon mirror motor

SC220-00	D	Laser synchronization detection error
		The laser synchronization detection unit could not detect the line synchronization signal (DETPO) within 500 ms while the polygon mirror motor was operating at normal speed. Note: The unit polls for the signal every 50 ms. This SC is issued after the 10th attempt fails to detect the signal.
		<ul style="list-style-type: none"> • Laser synchronization board connector loose, broken, defective • Laser synchronization detection board is not installed correctly (out of alignment) • Laser synchronization board defective
		<ul style="list-style-type: none"> • Inspect, reset laser synchronization detector harness • Replace laser synchronization detector

SC221-00	D	Laser Synchronization Detector Error: K Leading Edge (LD1)
		While the polygon motor is rotating normally, no synchronizing detection signal is output for black, leading edge for any LD other than LD0.
		<ul style="list-style-type: none"> • Laser synchronization detector harness is loose, broken, defective • LD unit defective • Laser diode board defective • BICU defective
		<ul style="list-style-type: none"> • Check LD unit, laser diode board connections • Replace LD unit • Replace laser diode board • Replace BICU
SC230-00	D	FGATE ON error: K
		The PFGATE ON signal does not assert within 5 seconds after processing the image in normal job or MUSIC for start position [K].
		<ul style="list-style-type: none"> • Defective ASIC • Poor connection between controller board and BICU. • Defective BICU
		<ul style="list-style-type: none"> • Check the connection between the controller board and the BICU. • Replace the BICU. • Replace the controller board.
SC231-00	D	FGATE OFF Error: K
		<ul style="list-style-type: none"> • The PFGATE ON signal still asserts within 5 seconds after processing the image in normal job or MUSIC for end position [K]. • The PFGATE ON signal still asserts when the next job starts.
		<ul style="list-style-type: none"> • Defective ASIC • Poor connection between controller board and BICU. • Defective BICU

		<ul style="list-style-type: none"> • Check the connection between the controller board and the BICU. • Replace the BICU. • Replace the controller board.
SC240-00	C	LD unit error
		The BICU detects laser diode board (LDB) error a few times consecutively when LDB unit turns on after LDB initialization.
		<ul style="list-style-type: none"> • Worn-out LD • LD unit harnesses loose, broken, defective • BICU defective
		<ul style="list-style-type: none"> • Replace LD unit harness • Replace LD unit • Replace the BICU.
SC270-00	D	GAVD communication error
		A problem occurred in the GAVD or eSOC.
		<ul style="list-style-type: none"> • BICU defective • LD unit effective
		<ul style="list-style-type: none"> • Check connection points on the BICU for loose, broken, or defective harness or connector • Replace LD unit • Replace BICU
SC272-01	D	LD driver communication error
		The read/write values were compared twice but there was not match. A parity check failed after three re-tries.
		<ul style="list-style-type: none"> • LDB harness loose, broken, defective • LDB defective • BICU defective

		<ul style="list-style-type: none"> • Cycle the machine off/on • Replace LDB harness • Replace LD unit • Replace BICU
SC272-10		LD driver communication error
		There was an door open interrupt (LD5V OFF) with the door closed.
		<ul style="list-style-type: none"> • BICU/RYP defective (+5VS error) • LDB defective • LDB harness loose, broken, defective • BICU-RYP harness loose, broken, defective
		<ul style="list-style-type: none"> • Cycle the machine off/on • Replace BICU-RYP harness • Replace LDB harness • Replace BICU/RYP • Replace LD unit

SC300: Image Development 1

SC300

SC300-00	D	Charge corona output error
		The feedback voltage from the charge corona unit is detected too high 9 times.
		<ul style="list-style-type: none"> • Charge corona unit connection loose, broken, defective • Charge corona power pack defective
		<ul style="list-style-type: none"> • Inspect charge corona unit harness • Replace charge corona power pack
SC305-00	D	Charge corona wire cleaner error 1
		The charge cleaner pad did not arrive at the home position: <ul style="list-style-type: none"> • Motor locked within 4 s after switching on, or does not lock within 30 s. • Motor locked within 10 s after reversing, or does not lock within 30 s.
		<ul style="list-style-type: none"> • Charge corona wire cleaner motor harness loose, broken, defective • Charge corona wire cleaner motor defective
		<ul style="list-style-type: none"> • Inspect motor harness • Replace charge corona wire cleaner motor
SC306-00	C	Charge corona wire cleaner error 2
		Charge corona motor is not operating. The current at the charge corona motor was detected less than 83 mA.
		<ul style="list-style-type: none"> • Charge corona wire cleaner motor connector is defective or disconnected • Motor defective
		<ul style="list-style-type: none"> • Inspect motor harness • Replace charge corona wire cleaner motor

SC307-00	D	Charge grid circuit open
		When high voltage went to the corona grid, feedback voltage was detected more than the set value 9 times. This feedback voltage is used to update PWM for output control.
		<ul style="list-style-type: none"> • Charge corona harness defective • Charge corona unit defective or disconnected • Charge corona power pack is defective.
		<ul style="list-style-type: none"> • Inspect charge corona harness • Replace charge corona unit • Replace charge corona power pack
SC320-01	D	Development output abnormal
		The high voltage applied to the development unit is detected 10 times higher than the upper limit (45%) of PWM.
		<ul style="list-style-type: none"> • Development bias leak due to poor connection, defective connector • Development power pack defective
		<ul style="list-style-type: none"> • Inspect development unit terminals for damage • Replace development unit • Replace development unit power pack
SC324-01	D	Development motor lock
		The development motor lock signal remained high for 2 sec. while the development motor was on.
		<ul style="list-style-type: none"> • Drive mechanism overloaded due to toner clumping in the used toner path • Motor drive board defective
		<ul style="list-style-type: none"> • Inspect the toner supply unit coil. • If the gear is not damaged, replace the coil. • If the gear is damaged, replace the entire unit • Replace development motor

<p>SC360-01</p>	<p>D</p>	<p>TD sensor adjustment error: Adjustment output abnormal</p>
		<p>During the TD sensor auto adjustment, the TD sensor output voltage (Vt) is 2.5 volts or higher even though the control voltage is set to the minimum value (PWM = 0). When this error occurs, SP2-906-1 reads 0.00V.</p>
		<p>Note:</p> <ul style="list-style-type: none"> • This SC is released only after correct adjustment of the TD sensor has been achieved. • Cycling the machine off/on will cancel the SC display, but does not release ID sensor toner supply. • When the TD sensor is defective, the toner supply is controlled using pixel count and the ID sensor.
		<ul style="list-style-type: none"> • TD harness, connector loose, broken, defective • Toner bottle motor harness loose, broken, defective • TD sensor defective • IOB defective • Toner bottle motor defective
<ul style="list-style-type: none"> • Remove the development unit and inspect the TD sensor harness • Inspect the toner bottle motor harness • Replace TD sensor • Replace toner bottle motor • Replace IOB 		

SC360-11	D	<p>TD sensor adjustment error: Timeout Error</p> <p>During the TD sensor auto adjustment, the TD sensor output voltage (Vt) does not enter the target range ($3.0 \pm 0.1V$) within 20 s. When this error occurs, the display of SP2-906-1 reads 0.00V.</p> <p>Note:</p> <ul style="list-style-type: none"> • This SC is released only after correct adjustment of the TD sensor has been achieved. • Cycling the machine off/on will cancel the SC display, but does not release ID sensor toner supply. <hr/> <ul style="list-style-type: none"> • TD sensor harness loose, broken, defective • TD sensor defective • IOB defective <hr/> <ul style="list-style-type: none"> • Remove development unit and inspect TD sensor harness • Replace TD sensor • Replace IOB
SC361-00	C	<p>TD sensor output error: Upper Limit</p> <p>TD sensor output voltage (Vt), measured during each copy cycle, is detected higher than 4V for 10 prints.</p> <ul style="list-style-type: none"> • TD sensor harness loose, broken defective • Toner bottle motor harness loose, broken, defective • TD sensor defective • IOB defective • Toner bottle motor defective <p>Note: When the TD sensor is defective, the toner supply is controlled using pixel count and the ID sensor.</p> <hr/> <ul style="list-style-type: none"> • Remove the development unit and inspect the TD sensor harness • Inspect the toner bottle motor harness • Replace TD sensor • Replace toner bottle motor • Replace IOB

<p>SC362-00</p>	<p>C</p>	<p>TD sensor output error: Lower limit</p>
		<p>TD sensor output voltage (Vt), measured during each copy cycle, is detected 10 times lower than 0.5V.</p>
		<ul style="list-style-type: none"> • TD sensor harness loose, broken defective • Toner bottle motor harness loose, broken, defective • TD sensor defective • IOB defective • Toner bottle motor defective <p>Note: When the TD sensor is defective, the toner supply is controlled using pixel count and the ID sensor.</p>
<p>SC370-01</p>	<p>C</p>	<p>ID sensor adjustment error: LED output abnormal</p>
		<p>One of the following ID sensor output voltages is detected at ID sensor initialization.</p> <ul style="list-style-type: none"> • Vsg less than 4.0V when the maximum PWM input (255) is applied to the ID sensor. • Vsg greater than or equal to 4.0V when the minimum PWM input (0) is applied to the ID sensor.
		<ul style="list-style-type: none"> • ID sensor dirty (ID sensor pattern defective) • ID sensor harness, connector loose, broken, defective • ID sensor defective • IOB defective
		<ul style="list-style-type: none"> • Remove the drum unit and inspect ID sensor harness • Clean ID sensor • Replace ID sensor • Replace IOB

SC370-11	C	<p>ID sensor adjustment error: Timeout error</p> <p>Vsg falls out of the adjustment target ($4.0 \pm 0.2V$) during Vsg checking within 20 sec.</p> <ul style="list-style-type: none"> • ID sensor dirty (ID sensor pattern defective) • ID sensor harness, connector loose, broken, defective • ID sensor defective • IOB defective <ul style="list-style-type: none"> • Remove the drum unit and inspect ID sensor harness • Clean ID sensor • Replace ID sensor • Replace IOB
SC375-00	C	<p>ID sensor error: Drum surface voltage error</p> <p>The ID sensor output voltage is 5.0V and the PWM signal input to the ID sensor is 0 when checking the ID sensor pattern.</p> <ul style="list-style-type: none"> • ID sensor dirty (ID sensor pattern defective) • ID sensor harness, connector loose, broken, defective • Charge power pack harness loose, broken defective • Charge power pack defective • ID sensor defective • IOB defective <ul style="list-style-type: none"> • Remove the drum unit and inspect ID sensor harness • Clean ID sensor • Replace ID sensor • Replace charge power pack • Replace IOB

SC376-00	C	ID sensor error: Pattern edge detection failed
		For 2 s during the ID sensor pattern check, the ID sensor pattern edge voltage is not 2.5V or the pattern edge is not detected within 800 ms.
		<ul style="list-style-type: none"> • ID sensor dirty (ID sensor pattern defective) • ID sensor harness, connector loose, broken, defective • Charge power pack harness loose, broken defective • Charge power pack defective • ID sensor defective • IOB defective
		<ul style="list-style-type: none"> • Remove the drum unit and inspect ID sensor harness • Clean ID sensor • Replace ID sensor • Replace charge power pack • Replace IOB

SC377-00	C	ID sensor error: Potential surface reading error
		The Vp value, which measures the reflectivity of the ID sensor pattern, was not in the range of -70V to -400V.
		<ul style="list-style-type: none"> • ID sensor dirty • Potential sensor harness, connector loose, broken, defective • Drum unit disconnected at the front • Charge corona unit disconnected • Potential sensor defective • IOB defective • Charge corona wire dirty, broken
		<ul style="list-style-type: none"> • Clean ID sensor • Inspect potential sensor harness • Inspect drum unit connection • Inspect charge corona unit harness • Replace potential sensor • Check, clean, replace charge corona unit • Replace IOB

SC378-00	C	<p>ID sensor pattern error</p> <p>One of the following ID sensor output voltages was detected twice consecutively when checking the ID sensor pattern.</p> <ul style="list-style-type: none"> • V_{sp} greater than or equals 2.5V • V_{sg} less than 2.5 • V_{sp} = 0V • V_{sg} = 0 <ul style="list-style-type: none"> • ID sensor dirty (poor ID sensor pattern image, image density incorrect) • ID sensor harness, connector loose, broken, defective • Charge power pack harness loose, broken, defective • ID sensor defective • IOB defective • Charge power pack defective <ul style="list-style-type: none"> • Remove drum unit, inspect clean ID sensor • Inspect ID sensor harness • Inspect charge power pack harness • Replace ID sensor • Replace charge power pack • Replace IOB
----------	---	---

<p>SC380-51</p>	<p>C</p>	<p>Potential sensor calibration (VL)</p>
		<p>During drum potential sensor calibration, when VL was adjusted, the pattern surface potential VL pattern was not within range 0V to -400V. (VL is the potential after exposing a white pattern.)</p>
		<ul style="list-style-type: none"> • Potential sensor harness, connector loose, broken, defective • Drum unit connection harness loose, broken, defective • Charge corona unit harness loose, broken, defective • Development power pack harness loose, broken, defective • Potential sensor defective • Charge corona unit defective • Development power pack defective • IOB defective
<p>SC396-01</p>	<p>D</p>	<p>Drum motor error</p>
		<p>The drum motor lock signal remains low for 2 seconds while the main motor is on.</p>
		<ul style="list-style-type: none"> • Drive mechanism overloaded • Motor drive board defective <ul style="list-style-type: none"> • Inspect the area around the motor and make sure no obstacles are blocking operation of the motor • Check the motor for loose or broken drive belts • Replace drum motor

SC400: Image Development 2

SC400

SC410-00	C	<p>Quenching lamp error</p> <p>At the completion of auto process control initialization, the potential of the drum surface detected by the potential sensor was more than -400V, the prescribed value.</p> <ul style="list-style-type: none"> • Quenching lamp, connector loose, broken, defective • Quenching lamp defective <ul style="list-style-type: none"> • Remove the drum unit and inspect the quenching lamp harness and connector • Replace quenching lamp
SC411-01	C	<p>Charge potential: VD (1) adjustment error</p> <p>The is SC code is logged by the machine if it detects either event below:</p> <ul style="list-style-type: none"> • Adjustment of VD (1) = VD default +/-20 V failed within the 5 prescribed attempts. • Adjustment of the drum surface potential for VD (1), achieved a result of VD (1) for VG (1) with VD (1) > than VG (1). <p>The machine stops and the SC is logged without displaying the SC number. Also, when SP3901 (Automatic Process Control On/Off) is set to "On", the problem is detected only when control is enabled for the potential sensor.</p> <ul style="list-style-type: none"> • Potential sensor harness, connector loose, broken, defective • Drum unit harness, connector loose, broken, defective • Drum unit installed incorrectly • Charge corona power pack harness loose, broken, defective • Charge corona grid damaged, dirty • Potential sensor defective • Charge corona power pack defective • Drum quenching lamp defective • IOB defective

		<ul style="list-style-type: none"> • Check the drum harness, connector at the front of the machine • Confirm that the drum unit is installed correctly • Remove the drum unit and inspect the potential sensor • Inspect the harnesses of the charge corona power pack • Remove the charge corona unit and inspect the grid for damage, dirt, dust • Replace potential sensor • Replace charge corona power pack • Replace drum quenching lamp • Replace IOB
--	--	---

SC411-02	C	Charge potential: VD (2) adjustment error
		<p>The is SC code is logged by the machine if it detects either event below:</p> <ul style="list-style-type: none"> • Adjustment of VD (2) failed within the 5 prescribed attempts. • Adjustment of the drum surface potential for VD (2), achieved a result of VD (2) for VG with VD (2) > than VG. <p>The machine stops and the SC is logged without displaying the SC number. Also, when SP3901 (Automatic Process Control On/Off) is set to "On", the problem is detected only when control is enabled for the potential sensor.</p>
		<ul style="list-style-type: none"> • Potential sensor harness, connector loose, broken, defective • Drum unit harness, connector loose, broken, defective • Drum unit installed incorrectly • Charge corona power pack harness loose, broken, defective • Charge corona grid damaged, dirty • Potential sensor defective • Charge corona power pack defective • Drum quenching lamp defective • IOB defective

		<ul style="list-style-type: none"> • Check the drum harness, connector at the front of the machine • Confirm that the drum unit is installed correctly • Remove the drum unit and inspect the potential sensor • Inspect the harnesses of the charge corona power pack • Remove the charge corona unit and inspect the grid for damage, dirt, dust • Replace potential sensor • Replace charge corona power pack • Replace drum quenching lamp • Replace IOB
--	--	---

SC440-01	D	Transfer output abnormal (voltage leak detected)
		When the transfer voltage was output, the feedback voltage remained higher than 4V for 60 ms.
		<ul style="list-style-type: none"> • Transfer current terminal, transfer power pack disconnected, damaged connector • Transfer power pack defective
		<ul style="list-style-type: none"> • Remove the transfer unit • Inspect the terminals at the front and rear • Replace transfer power pack

SC440-02	D	Transfer output abnormal release detection
		When the transfer is output, there is hardly any feedback voltage within 60 ms even with application of 24% PWM.
		<ul style="list-style-type: none"> • Transfer connector loose, defective • Transfer unit harness disconnected • Transfer power pack defective
		<ul style="list-style-type: none"> • Remove transfer unit • Inspect harnesses and connectors • Replace transfer power pack

SC495-00	D	Toner recycling unit error
		Encoder pulse does not change for 3 s after the drum motor switched on.
		<ul style="list-style-type: none"> • Waste toner transport has stopped due to drum motor overload • Toner end sensor defective, disconnected
		<ul style="list-style-type: none"> • Inspect the area around the drum motor • Remove any obstacles that could interfere with motor operation • Inspect the transport coils and check for clogging • Remove the development unit and inspect the toner end sensor harness and connector • Replace toner end sensor
SC496-00	D	Toner collection bottle error
		The toner collection bottle set switch remained off when the front door is closed.
		<ul style="list-style-type: none"> • No toner collection bottle is in the machine • Toner collection bottle set switch harness loose, broken, defective • Toner collection bottle set switch defective
		<ul style="list-style-type: none"> • Confirm that there is a used toner collection bottle in the machine • Inspect the harness of the toner collection bottle set switch • Replace toner bottle collection set switch

SC500: Feed, Transport, Duplex, and Fusing

SC500

SC501-01	B	<p>Tray 1 lift malfunction</p> <ul style="list-style-type: none"> • The lift sensor is not activated within 10 s after the tray lift motor starts lifting the bottom plate. • When the tray lowers, the tray lift sensor does not go off within 1.5 s. • Tray overload detected when the tray is set. • The lower limit sensor of the LCIT does not detect the lower limit within 10 s. <ul style="list-style-type: none"> • Tray lift motor defective, disconnected • Paper or other obstacle trapped between tray and motor • Pick-up solenoid disconnected, blocked by an obstacle • Too much paper loaded in tray <p>Note</p> <ul style="list-style-type: none"> • At first, the machine displays a message asking the operator to reset the tray. • This SC will not display until the operator has pulled the tray out and pushed it in 3 times. • If the operator turns the machine off/on before the 3rd opening and closing of the tray, the 3-count is reset. <ul style="list-style-type: none"> • Make sure Tray 1 is not overloaded. • Check for obstacles (paper scraps, etc.) around the tray and motor. • Check tray lift motor connection • Check around pick-up solenoid for obstacles. • Check solenoid connection.
----------	---	--

<p>SC502-00</p>	<p>B</p>	<p>Tray 2 lift malfunction</p>
		<ul style="list-style-type: none"> • The lift sensor is not activated within 10 s after the tray lift motor starts lifting the bottom plate. • When the tray lowers, the tray lift sensor does not go off within 1.5 s. • Tray overload detected when the tray is set.
		<ul style="list-style-type: none"> • Tray lift motor defective or disconnected • Paper or other obstacle trapped between tray and motor • Pick-up solenoid disconnected or blocked by an obstacle • Too much paper loaded in tray <p>Note</p> <ul style="list-style-type: none"> • At first, the machine displays a message asking the operator to reset the tray. • This SC will not display until the operator has pulled the tray out and pushed it in 3 times. • If the operator turns the machine off/on before the 3rd opening and closing of the tray, the 3-count is reset.
		<ul style="list-style-type: none"> • Make sure Tray 2 is not overloaded. • Check for obstacles (paper scraps, etc.) around the tray and motor. • Check tray lift motor connection • Check around pick-up solenoid for obstacles. • Check solenoid connection.

SC503-00	B	<p data-bbox="401 250 622 280">Tray 3 lift malfunction</p> <ul data-bbox="426 309 1157 472" style="list-style-type: none"> <li data-bbox="426 309 1157 378">• The lift sensor is not activated within 10 s after the tray lift motor starts lifting the bottom plate. <li data-bbox="426 393 1157 423">• When the tray lowers, the tray lift sensor does not go off within 1.5 s. <li data-bbox="426 439 900 468">• Tray overload detected when the tray is set. <ul data-bbox="426 501 1039 672" style="list-style-type: none"> <li data-bbox="426 501 862 531">• Tray lift motor defective or disconnected <li data-bbox="426 546 1039 576">• Paper or other obstacle trapped between tray and motor <li data-bbox="426 591 1039 621">• Pick-up solenoid disconnected or blocked by an obstacle <li data-bbox="426 637 773 666">• Too much paper loaded in tray <p data-bbox="401 687 456 717">Note</p> <ul data-bbox="426 736 1185 966" style="list-style-type: none"> <li data-bbox="426 736 1185 805">• At first, the machine displays a message asking the operator to reset the tray. <li data-bbox="426 821 1153 889">• This SC will not display until the operator has pulled the tray out and pushed it in 3 times. <li data-bbox="426 905 1153 974">• If the operator turns the machine off/on before the 3rd opening and closing of the tray, the 3-count is reset. <ul data-bbox="426 995 1144 1211" style="list-style-type: none"> <li data-bbox="426 995 828 1025">• Make sure Tray 3 is not overloaded. <li data-bbox="426 1040 1144 1070">• Check for obstacles (paper scraps, etc.) around the tray and motor. <li data-bbox="426 1085 779 1115">• Check tray lift motor connection <li data-bbox="426 1130 917 1160">• Check around pick-up solenoid for obstacles. <li data-bbox="426 1176 738 1205">• Check solenoid connection.
----------	---	---

SC504-00	B	Tray 4 lift malfunction Japan Only
		<ul style="list-style-type: none"> • The lift sensor is not activated within 10 s after the tray lift motor starts lifting the bottom plate. • When the tray lowers, the tray lift sensor does not go off within 1.5 s. • Tray overload detected when the tray is set.
		<ul style="list-style-type: none"> • Tray lift motor defective or disconnected • Paper or other obstacle trapped between tray and motor • Pick-up solenoid disconnected or blocked by an obstacle • Too much paper loaded in tray <p>Note</p> <ul style="list-style-type: none"> • At first, the machine displays a message asking the operator to reset the tray. • This SC will not display until the operator has pulled the tray out and pushed it in 3 times. • If the operator turns the machine off/on before the 3rd opening and closing of the tray, the 3-count is reset.
		<ul style="list-style-type: none"> • Make sure Tray 4 is not overloaded. • Check for obstacles (paper scraps, etc.) around the tray and motor. • Check tray lift motor connection • Check around pick-up solenoid for obstacles. • Check solenoid connection.

SC505-01	B	LCIT error: Lift error
		Before the pickup solenoid went ON at tray initialization, the machine failed to detect the tray lift sensor OFF after 5 attempts.
		<ul style="list-style-type: none"> • Pick-up solenoid harness connector loose, broken, defective • Pickup solenoid defective • Lift sensor harness connector loose, broken, defective • Lift sensor defective • LCIT main board defective

		<ul style="list-style-type: none"> • Check pick-up solenoid harness, connector, and replace if damaged. • Check lift sensor harness, connector, and replace if damaged. • Replace pickup solenoid • Replace lift sensor • Replace LCIT main board
SC505-02	B	LCIT error: Lift time-out error
		At tray initialization the tray bottom plate was not detected at the up position within the prescribed time (30 s).
		<ul style="list-style-type: none"> • Lift motor harness connector loose, broken, defective • Lift sensor harness connector loose, broken, defective • Lift motor defective • Lift sensor defective • LCIT main board defective
		<ul style="list-style-type: none"> • Inspect lift motor harness connector, and replace if damaged. • Inspect lift sensor harness connector and replace if damaged. • Replace lift sensor • Replace lift motor • Replace LCIT main board
SC505-03	B	LCIT error: Lower time-out error
		<p>At initialization, the bottom plate was lowered to check it at the down position, but the upper limit sensor was still ON after the prescribed 30 s, and the lower limit sensor and four paper height sensors remained OFF.</p> <p>-or-</p> <p>At paper end, or after the down switch went ON, the machine lowered the bottom plate, but the paper detect sensor or the lower limit sensor did not go ON within the prescribed time (remained OFF for more than 30 s).</p>

		<ul style="list-style-type: none"> • Lift motor harness connector loose, broken, defective • Lift sensor harness connector loose, broken, defective • Paper sensor harness connector loose, broken, defective • Lower limit sensor harness connector loose, broken, defective • Paper height sensor harness connector loose, broken, defective • Lift motor defective • Lift sensor defective • Paper sensor defective • Lower limit sensor defective • Paper height sensor defective • LCIT main board defective
		<ul style="list-style-type: none"> • Inspect lift motor harness, connector and replace if defective • Inspect lift sensor harness, connector and replace if defective. • Inspect paper sensor harness, connector and replace if defective. • Inspect lower limit sensor harness, connector and replace if defective. • Inspect paper height sensor harness, connector and replace if defective. • Replace lift motor. • Replace lift sensor. • Replace paper sensor. • Replace lower limit sensor. • Replace paper height sensor. • Replace LCIT main board

SC505-04	B	LCIT error: Paper overload error
		At initialization the machine detected both the lift sensor and lower limit sensor ON.
		<ul style="list-style-type: none"> • Paper tray overload • Lift sensor harness, connector loose, broken, defective • Lower limit sensor harness, connector loose, broken, defective • Lift sensor defective • Lower limit sensor defective • LCIT main board defective

		<ul style="list-style-type: none"> • Check the load limit mark on the paper tray. • Inspect the lift sensor harness, connector loose, and replace if defective. • Inspect the lower limit sensor harness, connector and replace if defective. • Replace lift sensor. • Replace lower limit sensor. • Replace LCIT main board
SC515-00	C	Duplex jogger motor error 1
		When the jogger fence moves to the home position, the jogger HP sensor does not turn on even if the jogger fence motor has moved the jogger fence 153.5 mm.
		<ul style="list-style-type: none"> • Paper or other obstacle has jammed jogger fence mechanism • Jogger HP sensor connector disconnected or defective • Jogger HP sensor defective
		<ul style="list-style-type: none"> • Inspect jogger fence mechanism for obstacles (paper scraps, etc.) • Inspect jogger HP sensor connector, harness and replace if damaged. • Replace jogger HP sensor.
SC516-00	C	Duplex jogger motor error 2
		When the jogger fence moves from the home position, the jogger fence HP sensor does not turn off even if the jogger motor has moved the jogger fence 153.5 mm.
		<ul style="list-style-type: none"> • Paper or other obstacle has jammed mechanism • Jogger fence HP sensor connector disconnected or defective • Jogger fence HP sensor defective
		<ul style="list-style-type: none"> • Inspect jogger fence mechanism for obstacles (paper scraps, etc.) • Inspect jogger HP sensor connector, harness and replace if damaged. • Replace jogger HP sensor.
SC520-01	C	Tray 1 paper feed motor error: Lock

		<p>An error was detected in the motor register (VODKA: Transport DCM) within 100 ms after the motor turned on, or the error was detected in the register 5 successive times, and the machine determined that the motor was not rotating correctly.</p> <p>Note: VODKA is a component of the IOB.</p>
		<ul style="list-style-type: none"> • Motor harness, connector loose, broken, defective • Motor torque too high, due to blockage, obstacle • Motor defective • IOB defective
		<ul style="list-style-type: none"> • Inspect motor harness, connector, and replace if damaged. • Inspect motor and area around the motor for obstacles. • Replace Tray 1 paper feed motor • Replace IOB.

7

SC520-02		Tray2 paper feed motor error: Lock
		<p>An error was detected in the motor register (VODKA: Transport DCM) within 100 ms after the motor turned on, or the error was detected in the register 5 successive times, and the machine determined that the motor was not rotating correctly.</p> <p>Note: VODKA is a component of the IOB.</p>
		<ul style="list-style-type: none"> • Motor harness, connector loose, broken, defective • Motor torque too high, due to blockage, obstacle • Motor defective • IOB defective
		<ul style="list-style-type: none"> • Inspect motor harness, connector, and replace if damaged. • Inspect motor and area around the motor for obstacles. • Replace Tray 2 paper feed motor • Replace IOB.

SC520-03	C	Tray 3 paper feed motor error: Lock
----------	---	-------------------------------------

		<p>An error was detected in the motor register (VODKA: Transport DCM) within 100 ms after the motor turned on, or the error was detected in the register 5 successive times, and the machine determined that the motor was not rotating correctly.</p> <p>Note: VODKA is a component of the IOB.</p>
		<ul style="list-style-type: none"> • Motor harness, connector loose, broken, defective • Motor torque too high, due to blockage, obstacle • Motor defective • IOB defective
		<ul style="list-style-type: none"> • Inspect motor harness, connector, and replace if damaged. • Inspect motor and area around the motor for obstacles. • Replace Tray 3 paper feed motor • Replace IOB.

SC520-04	C	Tray 4 paper feed motor error: Lock Japan Only
		<p>An error was detected in the motor register (VODKA: Transport DCM) within 100 ms after the motor turned on, or the error was detected in the register 5 successive times, and the machine determined that the motor was not rotating correctly.</p> <p>Note: VODKA is a component of the IOB.</p>
		<ul style="list-style-type: none"> • Motor harness, connector loose, broken, defective • Motor torque too high, due to blockage, obstacle • Motor defective • IOB defective
		<ul style="list-style-type: none"> • Inspect motor harness, connector, and replace if damaged. • Inspect motor and area around the motor for obstacles. • Replace Tray 4 paper feed motor • Replace IOB.

SC521-01	C	Main relay motor lock error
----------	---	-----------------------------

		<p>An error was detected in the motor register (VODKA: Transport DCM) within 100 ms after the motor turned on, or the error was detected in the register 5 successive times, and the machine determined that the motor was not rotating correctly.</p> <p>Note: VODKA is a component of the IOB.</p>
		<ul style="list-style-type: none"> • Motor harness, connector loose, broken, defective • Motor torque too high, due to blockage, obstacle • Motor defective • IOB defective
		<ul style="list-style-type: none"> • Inspect motor harness, connector, and replace if damaged. • Inspect motor and area around the motor for obstacles. • Replace main relay motor • Replace IOB.

7

SC521-02	C	Registration motor lock error
		<p>An error was detected in the motor register (VODKA: Transport DCM) within 100 ms after the motor turned on, or the error was detected in the register 5 successive times, and the machine determined that the motor was not rotating correctly.</p> <p>Note: VODKA is a component of the IOB.</p>
		<ul style="list-style-type: none"> • Motor harness, connector loose, broken, defective • Motor torque too high, due to blockage, obstacle • Motor defective • IOB defective
		<ul style="list-style-type: none"> • Inspect motor harness, connector, and replace if damaged. • Inspect motor and area around the motor for obstacles. • Replace registration motor • Replace IOB.

SC522-01	C	Invert duplex motor lock error
----------	---	--------------------------------

		<p>An error was detected in the motor register (VODKA: Transport DCM) within 100 ms after the motor turned on, or the error was detected in the register 5 successive times, and the machine determined that the motor was not rotating correctly.</p> <p>Note: VODKA is a component of the IOB.</p>
		<ul style="list-style-type: none"> • Motor harness, connector loose, broken, defective • Motor torque too high, due to blockage, obstacle • Motor defective • IOB defective
		<ul style="list-style-type: none"> • Inspect motor harness, connector, and replace if damaged. • Inspect motor and area around the motor for obstacles. • Replace invert duplex motor • Replace IOB.

SC522-02	C	Duplex transport motor lock error
		<p>An error was detected in the motor register (VODKA: Transport DCM) within 100 ms after the motor turned on, or the error was detected in the register 5 successive times, and the machine determined that the motor was not rotating correctly.</p> <p>Note: VODKA is a component of the IOB.</p>
		<ul style="list-style-type: none"> • Motor harness, connector loose, broken, defective • Motor torque too high, due to blockage, obstacle • Motor defective • IOB defective
		<ul style="list-style-type: none"> • Inspect motor harness, connector, and replace if damaged. • Inspect motor and area around the motor for obstacles. • Replace duplex transport motor • Replace IOB.

SC530-01		Drum fan error
----------	--	----------------

		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace the drum fan.

7

SC530-02		Development unit fan 1 error
		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace development unit fan 1.

SC530-03		Development unit fan 2 error
----------	--	------------------------------

		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace development unit fan 2.

SC530-04		Duplex fan error
		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace duplex fan.

SC530-05		PCU fan error
----------	--	---------------

		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace the PCU fan.

7

SC530-06		Toner bottle fan error
		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace the toner bottle fan.

SC530-07		Fusing inner cover fan error
----------	--	------------------------------

		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace the fusing inner cover fan.

SC530-08		PSU fan 1 error
		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace PSU fan 1.

SC530-09		PSU fan 2 error
----------	--	-----------------

		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace PSU fan 2.

7

SC530-10		AC drive board fan
		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace the AC drive board fan.

SC530-11		Controller fan 2 (top: exhaust)
----------	--	---------------------------------

		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace controller fan 2.

SC530-12	B	Capacitor fan error Japan Only
		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace the capacitor fan.

SC530-13		PFU fan 1 error
----------	--	-----------------

		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace PFU fan 1.

SC530-14		Paper feed unit fan 2 error
		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace PFU fan 2.

SC530-15		Paper feed unit fan 3 error
----------	--	-----------------------------

		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace PFU fan 3.

SC530-16		Paper feed unit fan 4 error Japan Only
		<p>Note: The machines of this series have four trays in Japan, and machines in areas outside Japan have three trays. Tray 1 is a tandem tray, but Tray 1 in Japan is smaller.</p> <p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace PFU fan 4.

SC531-01	D	Main intake fan
----------	---	-----------------

		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace the main intake fan.

7

SC531-02		Main exhaust fan
		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace the main exhaust fan.

SC531-03		Heat exhaust fan error
----------	--	------------------------

		<p>After the fan turns on, the fan lock signal is checked at 1 sec. intervals.</p> <ul style="list-style-type: none"> • Due to an obstruction or other problem, the lock signal went HIGH 1.5 s after the fan turned on and remained HIGH for 6 consecutive counts. • The lock signal should remain LOW during normal operation. • The fan stopped and then the machine stopped.
		<ul style="list-style-type: none"> • Fan motor overload due to an obstruction. • Fan motor connector, harness loose, broken, defective. • Fan motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the fan for obstructions that could interfere with the rotation of the fan blades. • Inspect harness, connector and replace if damaged. • Replace the heat exhaust fan.
SC540-01	D	Fusing web motor error 1
		The amount of current detected during operation of the web motor exceeded 350 mA in 5 successive samples.
		<ul style="list-style-type: none"> • Web motor connection loose, broken, defective • Web motor disconnected • Harness loose, broken, defective
		<ul style="list-style-type: none"> • Inspect harness connection at CN252 on the IOB • Inspect web motor connector, harness, and replace if damaged. • Inspect paper exit harnesses from the point where web motor connects under the fusing unit. • Replace web motor • Replace IOB

SC540-03	A	Fusing web motor error 2
		SC540-02 has occurred three times and the machine has shut down automatically due to failure of the web motor.
		<ul style="list-style-type: none"> • Web motor harness loose, broken, defective • Web motor disconnected • Web motor defective
		<ul style="list-style-type: none"> • Inspect harness connection • Inspect motor harness, connector, and replace if damaged. • Replace motor
SC540-04	A	Fusing web motor error 3
		SC540-02 has occurred at total of 10 times and the machine has shut down automatically due to failure of the web motor.
		<ul style="list-style-type: none"> • Web motor harness loose, broken, defective • Web motor disconnected • Web motor defective
		<ul style="list-style-type: none"> • Inspect harness connection • Inspect motor harness, connector, and replace if damaged. • Replace motor
SC541-00	A	Fusing center thermistor error
		The fusing temperature detected by the center NC sensor (thermistor) was below 0°C for 7 s.
		<ul style="list-style-type: none"> • Thermistor connector defective • Thermistor damaged, or out of position
		<ul style="list-style-type: none"> • Pull fusing unit out of machine. • At the front of the fusing unit, inspect the connection of the NC thermistor. • Inspect the installation of the NC thermistor and confirm that it is not out of position. • Replace NC thermistor.

SC542-01	A	Fusing temperature warm-up error 1: Center thermistor
		The center NC sensor (thermistor) above the hot roller determined that the hot roller failed to reach the warm-up temperature within the prescribed time.
		<ul style="list-style-type: none"> • Fusing lamp disconnected • Center thermistor out of position
		<ul style="list-style-type: none"> • Pull the fusing unit out of the machine. • Inspect the fusing lamp connections at front and rear. • Inspect center NC sensor and confirm that it is installed correctly.
SC542-02	A	Fusing temperature warm-up error 2: Center thermistor
		The center NC sensor (thermistor) above the hot roller determined that the hot roller failed to reach the 100°C within the prescribed time.
		<ul style="list-style-type: none"> • Fusing lamp disconnected • Center thermistor out of position
		<ul style="list-style-type: none"> • Pull the fusing unit out of the machine. • Inspect the fusing lamp connections at front and rear. • Inspect center NC sensor and confirm that it is installed correctly.
SC542-03	A	Fusing temperature warm-up error 3: Center thermistor
		The center NC sensor (thermistor) above the hot roller determined that the hot roller failed to reach the reload temperature within the prescribed time.
		<ul style="list-style-type: none"> • Fusing lamp disconnected • Center thermistor out of position
		<ul style="list-style-type: none"> • Pull the fusing unit out of the machine. • Inspect the fusing lamp connections at front and rear. • Inspect center NC sensor and confirm that it is installed correctly.

SC543-00	A	Fusing lamp overheat error 1 (software)
		The center thermistor (NC sensor) detected a temperature of 240°C at the center of the hot roller. Fusing temperature control software error
		<ul style="list-style-type: none"> • PSU defective • IOB defective • BICU defective
		<ul style="list-style-type: none"> • Replace PSU • Replace IOB • Replace BICU
SC544-00	A	Fusing lamp overheat error 1: Hardware
		The center thermistor (NC sensor) or an end thermistor detected a temperature of 250°C on the hot roller.
		<ul style="list-style-type: none"> • PSU defective • IOB defective • BICU defective
		<ul style="list-style-type: none"> • Replace PSU • Replace IOB • Replace BICU
SC545-00	A	Fusing lamp overheat error 2: Center lamp
		After the hot roller reached warm-up temperature, the fusing lamps remained on at full capacity for 11 samplings (1.8 s. duration) while the hot roller was not rotating.
		<ul style="list-style-type: none"> • Thermistor damaged, or out of position • Fusing lamp disconnected
		<ul style="list-style-type: none"> • Pull the fusing unit out of the machine. • Inspect all thermistor connections, harnesses. • Inspect fusing lamp connections, harnesses.

SC547-01	D	<p data-bbox="417 250 806 282">Zero cross signal error 1: Fusing relay</p> <p data-bbox="417 309 1204 376">At power on and with the fusing relay off, 3 samplings detected that the zero cross was not normal.</p> <ul data-bbox="444 407 817 486" style="list-style-type: none"> <li data-bbox="444 407 653 439">• Fusing relay short <li data-bbox="444 454 817 486">• Fusing relay drive circuit defective <ul data-bbox="444 517 1179 768" style="list-style-type: none"> <li data-bbox="444 517 740 548">• Cycle the machine off/on. <li data-bbox="444 564 1179 631">• If the problem persists, check the harnesses and connections between the AC drive board and the IOB. <li data-bbox="444 646 894 678">• Replace damaged harnesses, connectors <li data-bbox="444 693 729 725">• Replace AC drive board. <li data-bbox="444 740 603 772">• Replace IOB
SC547-02	D	<p data-bbox="417 825 806 856">Zero cross signal error 2: Fusing relay</p> <p data-bbox="417 883 1146 950">No zero cross signal was detected within 3 sec. after power on or after closing the front door.</p> <ul data-bbox="444 981 817 1060" style="list-style-type: none"> <li data-bbox="444 981 653 1013">• Fusing relay short <li data-bbox="444 1029 817 1060">• Fusing relay drive circuit defective <ul data-bbox="444 1091 1179 1389" style="list-style-type: none"> <li data-bbox="444 1091 740 1123">• Cycle the machine off/on. <li data-bbox="444 1138 1179 1205">• If the problem persists, check the harnesses and connections between the AC drive board and the IOB. <li data-bbox="444 1221 894 1252">• Replace damaged harnesses, connectors <li data-bbox="444 1268 867 1299">• Inspect and replace PSU fuses (24VS). <li data-bbox="444 1315 729 1346">• Replace AC drive board. <li data-bbox="444 1362 603 1393">• Replace IOB

SC547-03	D	Zero cross signal error 2: Unstable power supply
		After 11 samplings the power supply was not within 50 to 60 Hz, indicating that the power supply is not stable.
		<ul style="list-style-type: none"> • Power supply unstable.
		<ul style="list-style-type: none"> • First, cycle the machine off/on. • Consult with power supply company to confirm that the power supply is stable. • Check harnesses, connections between the AC drive board and the IOB. • Replace AC drive board. • Replace IOB.
SC551-00	A	Fusing thermistor error 1: End thermistor
		The end thermistor (contact type) was less than 0C (32F) for more than 7 seconds.
		<ul style="list-style-type: none"> • Thermistor connector loose, broken, defective • Thermistor incorrectly installed or loose, and floating out of position.
		<ul style="list-style-type: none"> • Pull the fusing unit out. • Inspect all thermistor harnesses, connectors • Confirm that thermistors are installed correctly.

SC552-01	A	<p>Fusing reload temperature error 1: End thermistor</p> <p>The end thermistor (contact type) could not detect:</p> <ul style="list-style-type: none"> • 100°C 25 seconds after the start of the warm-up cycle. • A change in temperature more than 16 degrees for 5 seconds. • The reload temperature with 56 seconds after the start of the fusing temperature control cycle. <ul style="list-style-type: none"> • Fusing lamp disconnected • End thermistor connector loose, broken, defective • End thermistor out of position, installed incorrectly • Thermostat open <ul style="list-style-type: none"> • Pull out the fusing unit. • Inspect the fusing lamp harnesses, connections. • Check end thermistor harnesses, connector • Inspect end thermistor and make sure that it is installed correctly and not floating free. • Replace thermostats.
SC552-02	A	<p>Fusing reload temperature error 2: End thermistor</p> <p>The hot roller did not reach 100°C within the prescribed time.</p> <ul style="list-style-type: none"> • Fusing lamp disconnected • Thermistor connector loose, broken, defective • Thermistor out of position, installed incorrectly • Thermostat open <ul style="list-style-type: none"> • Pull out the fusing unit. • Inspect the fusing lamp harnesses, connections. • Check end thermistor harnesses, connector • Inspect end thermistor and make sure that it is installed correctly and not floating free. • Replace thermostats.

SC552-03	A	Fusing reload temperature error 3: End thermistor
		The hot roller did not reach the prescribed temperature within 3 sec, after the start of the fusing temperature control cycle.
		<ul style="list-style-type: none"> • Fusing lamp disconnected • Thermistor connector loose, broken, defective • Thermistor out of position, installed incorrectly • Thermostat open
		<ul style="list-style-type: none"> • Pull out the fusing unit. • Inspect the fusing lamp harnesses, connections. • Check end thermistor harnesses, connector • Inspect end thermistor and make sure that it is installed correctly and not floating free. • Replace thermostats.

SC553-00	A	Fusing thermistor error 4: End thermistor (software)
		The end thermistor (contact type) was at 240°C (464°F) for more than 1 second. The temperature is read 10 times every second. (at 0.1 s intervals).
		<ul style="list-style-type: none"> • PSU defective • IOB control board defective • BICU control board defective
		<ul style="list-style-type: none"> • Replace PSU • Replace IOB • Replace BICU

SC555-00	A	Fusing lamp error
		After the start of the warmup cycle, a fusing lamp was at full power for 1.8 s but the hot roller did not turn.
		<ul style="list-style-type: none"> • Thermistor bent, out of position • Fusing lamp disconnected
		<ul style="list-style-type: none"> • Pull out fusing unit. • Inspect thermistor harnesses, connectors • Inspect fusing lamp harnesses, connectors • Inspect thermistors and make sure they are installed correctly and not floating free.
SC557-00	C	Zero cross signal error
		High frequency noise was detected on the power line.
		The SC code is logged and the operation of the machine is not affected.
		<ul style="list-style-type: none"> • No action required.
SC559-00	A	Fusing jam: 3 counts
		At the fusing exit sensor the paper was detected late for three pulse counts (lag error), and SP1159 was on.
		<ul style="list-style-type: none"> • If this SC occurs, the machine cannot be used until the service technician cancels the SC code. • This SC occurs only if SP1159 has been set to "1" (On). (Default: 0 (Off)).
		<ul style="list-style-type: none"> • Enter the SP mode • Cycle the machine off/on.

SC569-00	D	Fusing pressure release motor error
		During copying, the HP sensor could not detect the actuator, tried again 3 times and could not detect.
		<ul style="list-style-type: none"> • Motor lock due to overload • Motor drive board defective • HP sensor defective, disconnected, connector defective, harness damaged
		<ul style="list-style-type: none"> • Pull out the fusing unit. • Inspect the area around the pressure motor for obstacles that could interfere with the motor. • Inspect pressure release sensor harness, connector, and replace if damaged. • Replace pressure release sensor. • Replace motor.

7

SC570-00	B	Capacitor discharge error 1 Japan Only
		<p>An error code was output from the capacitor control board (CAPCNT). At discharge the capacitor unit could not boost:</p> <ul style="list-style-type: none"> • After the capacitor discharged the charge/discharge device issued an error code to signal that an error had occurred. • When the error was issued, a message appeared on the operation panel display: "V Parts Maintenance Required". • The capacitor unit ceased charging and discharging. • The machine set charge/discharge control to the OFF state, but the machine can continue operations that do not use the capacitor.
		<ul style="list-style-type: none"> • Capacitor control board (CAPCNT) damaged • Charge/discharge device damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on twice. • If the problem persists, replace the capacitor control board (CAPCNT) • Replace the capacitor unit V Parts. • The original charge output data done before shipping must also be restored.

SC571-00	B	Capacitor discharge error 3 Japan Only
		<p>An error code was output from the capacitor control board (CAPCNT). When discharge was halted, the discharge from the capacitor unit did not stop:</p> <ul style="list-style-type: none"> • After the capacitor discharged the charge/discharge device issued an error code to signal that an error had occurred. • When the error was issued, a message appeared on the operation panel display: "V Parts Maintenance Required". • The capacitor unit ceased charging and discharging. • The machine set charge/discharge control to the OFF state, but the machine can continue operations that do not use the capacitor.
		<ul style="list-style-type: none"> • Capacitor control board (CAPCNT) damaged • Charge/discharge device damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on twice. • If the problem persists, replace the capacitor control board (CAPCNT) • Replace the capacitor unit V Parts. • The original charge output data done before shipping must also be restored.

SC572-00	B	Capacitor discharge error 2 Japan Only
		<p>An error code was output from the capacitor control board (CAPCNT). When discharge started, the capacitor unit could not discharge:</p> <ul style="list-style-type: none"> • After the capacitor discharged the charge/discharge device issued an error code to signal that an error had occurred. • When the error was issued, a message appeared on the operation panel display: "V Parts Maintenance Required". • The capacitor unit ceased charging and discharging. • The machine set charge/discharge control to the OFF state, but the machine can continue operations that do not use the capacitor.

		<ul style="list-style-type: none"> • Discharge FED damaged • Capacitor control board (CAPCNT) damaged • Charge/discharge device damaged • Discharge device harness loose, broken, defective • Connector loose • DC heater disconnected
		<ul style="list-style-type: none"> • Cycle the machine off/on twice. • If the problem persists, replace the capacitor control board (CAPCNT) • Replace the capacitor unit V Parts. • The original charge output data done before shipping must also be restored.

SC573-00	B	Discharge device error Japan Only
		<p>An error code was output from the capacitor control board (CAPCNT). At charge the capacitor unit could not charge:</p> <ul style="list-style-type: none"> • While the capacitor boosted with an abnormal voltage when it started to charge, or the machine detected that the capacitor voltage did not rise and signaled an error. • When the error was issued, a message appeared on the operation panel display: "V Parts Maintenance Required". • The capacitor unit ceased charging and discharging. • The machine set charge/discharge control to the OFF state, but the machine can continue operations that do not use the capacitor.
		<ul style="list-style-type: none"> • Charge device harness loose, broken, defective • Connector loose, damaged • Capacitor control board (CAPCNT) damaged • Charge/discharge device damaged • There was a drop in the power supply voltage (lower than AC78V).
		<ul style="list-style-type: none"> • Cycle the machine off/on twice. • If the problem persists, replace the capacitor control board (CAPCNT) • Replace the capacitor unit V Parts. • The original charge output data done before shipping must also be restored.

SC574-00	B	Capacitor deterioration error Japan Only
		<p>The capacity of the capacitor has dropped and the machine has entered CPM down mode:</p> <ul style="list-style-type: none"> • The capacity of the capacitor calculated by CAPCNT from the result of a measurement at the start of charging was determined to be below standard, and the error was issued because the number exceeded the specification for CPM down. • When the error was issued, a message appeared on the operation panel display: "V Parts Maintenance Required". • Normal operation continues without shutting down the capacitor or the engine.
		<ul style="list-style-type: none"> • Capacity is too low due to deterioration of the capacitor • Capacitor control board (CAPCNT) damaged • Charge/discharge device damaged
		<ul style="list-style-type: none"> • Replace the capacitor control board (CAPCNT) • Replace the capacitor unit V Parts. • The original charge output data done before shipping must also be restored.

SC575-00	B	Capacitor unit installation error Japan Only
		<p>The machine was not able to detect that the capacitor unit was set.</p> <ul style="list-style-type: none"> • When the error was issued, a message appeared on the operation panel display: "V Parts Maintenance Required". • The capacitor unit ceased charging and discharging. • The machine set charge/discharge control to the OFF state, but the machine can continue operations that do not use the capacitor.
		<ul style="list-style-type: none"> • IOB-CAPCNT harness loose, broken, defective • Capacitor unit damaged, not installed correctly • Capacitor control board (CAPCNT) damaged

		<ul style="list-style-type: none"> • Confirm that the capacitor unit is installed correctly. • Cycle the machine off/on twice. • If the problem persists, first check IOB-CAPCNT harness and replace if damaged • Replace the capacitor control board (CAPCNT) • Replace the capacitor unit V Parts. • The original charge output data done before shipping must also be restored.
--	--	--

SC581-00	D	Power cord not connected properly.
		<p>According to the control specification for this machine "Power Cord Connection Detection (DOM 90 cpm)", a message on the operation panel (not an SC code) alerts the operator that the power cord is disconnected. This message display is: "Power cord disconnected. Turn machine off, and then connect power cord to power source."</p> <p>The following fusing unit SC codes are provided, listed here in order of importance:</p> <ul style="list-style-type: none"> • High temperature: SC543, SC544, SC553 • Thermistor SC codes: SC541, SC551 • Fusing lamp on alert SC codes (reload temperature failure): SC542, SC552, SC545, SC555 <p>Note the following:</p> <ul style="list-style-type: none"> • If the power cord is not detected as disconnected, a reload temperature failure SC code is issued. • If the power cord is detected disconnected, then the power cord connection failure takes priority. • In this case, the reload temperature failure SC (fusing lamp on SC) SC flag is cleared.
		<ul style="list-style-type: none"> • Power cord on the fusing unit side is disconnected.
		<ul style="list-style-type: none"> • Turn the machine OFF. • Connect the power cord to the power source. • Turn the machine ON.

SC585-00	C	Temperature sensor error
----------	---	--------------------------

		<p>Machine issues this SC code after 3 consecutive abnormal temperature readings.</p> <ul style="list-style-type: none"> • Temperature reading below -10°C • Temperature reading above 100°C
		<ul style="list-style-type: none"> • Temperature sensor harness connector loose, broken, defective • Thermistor damaged
		<ul style="list-style-type: none"> • Inspect temperature sensor harness, connector. • Reset the temperature sensor • Replace temperature sensor.

SC590-00	D	Toner collection motor error
		The toner collection motor sensor output does not change for 3 s while the toner collection motor is on.
		<ul style="list-style-type: none"> • Vertical drive shaft missing, not installed correctly. • Motor lock due to obstruction • Motor harness, connector loose, broken, defective • Toner collection motor sensor harness, connector loose, broken, defective. • Toner collection motor sensor defective • Motor defective
		<ul style="list-style-type: none"> • Make sure that the vertical drive shaft is installed, and installed correctly at the bottom end of the shaft where it connects to the motor. • Check the area around the motor for obstacles that could interfere with motor operation. • Inspect the motor harness, connector and replace if damaged. • Inspect toner collection motor sensor harness, connector and replace if damaged. • Replace toner collection motor sensor. • Replace toner collection motor.

SC600: Data Communication

SC600

SC620-01	D	ADF communication error 1
		<p>There was a communication error between the main machine and the ADF connected via the ASAP. The break was detected after normal connection. One of the following occurred:</p> <ul style="list-style-type: none"> • This SC occurred after a problem was detected after the ADF connection was recognized at startup. • There was no reply even with the ADF not connected at startup, but the machine can still be used (no SC code was issued) without ADF function (scanning, copying originals on the original tray).
		<ul style="list-style-type: none"> • Poor ADF connection • Electrical noise on the power line • ADF damaged • IPU damaged (IPU resides on BICU).
		<ul style="list-style-type: none"> • Check ADF connection • Check ADF-BICU connection • Replace ADF • Replace BICU

SC620-02	D	ADF communication error 2
		<p>There was a communication error between the main machine and the ADF connected via ASAP. A retry was triggered by the communication error after normal connection. One of the following occurred:</p> <ul style="list-style-type: none"> • The SC occurred after a problem was detected when the ADF connection was recognized at startup. • There was no reply even with the ADF not connected at startup, but the machine can still be used (no SC code was issued) without ADF function (scanning, copying originals on the original tray). • The SC was issued when connection of an incompatible ADF was detected (the ADF cord specifications did not match).

		<ul style="list-style-type: none"> • Incompatible ADF connection (ADF cable specifications do not match) • Electrical noise on the power line • Poor ADF connection at BICU • ADF damaged • IPU damaged (IPU resides on BICU)
		<ul style="list-style-type: none"> • Confirm that the ADF is the correct device for the machine. • Replace ADF with compatible ADF • Determine if there is electrical noise on the power line. • Check ADF cable connection at the BICU. • Replace ADF. • Replace BICU.
SC620-03	D	ADP communication error 3
		<p>No signal received within the time prescribed for receipt of the CIS initialization end command.</p> <ul style="list-style-type: none"> • Nothing was received within 3 sec. after the machine was turned on or recovered from Energy Save mode. • If the machine does not receive the CIS initialization end command, it determines there is a problem with the ADF and issues this SC code.
		<ul style="list-style-type: none"> • Electrical noise on the power line. • Poor ADF connection. • ADF damaged. • IPU damaged (IPU resides on the BICU).
		<ul style="list-style-type: none"> • Determine if there is electrical noise on the power line. • Check ADF cable connection to BICU. • Replace ADF • Replace BICU

SC621-01	D	BICU > Finisher communication error: Break error
		During communication with the finisher MBX, the BICU received a break (LOW) signal from the finisher.
		<ul style="list-style-type: none"> • I/F cable connection to main machine or upstream finisher and loose, broken, defective • Breaker switch defective • Power cord loose, broken, defective • Peripheral unit control board defective
		<ul style="list-style-type: none"> • Inspect I/F cable connections of finishers to the main machine or to upstream unit. • If the peripheral unit has a breaker switch, test it. • Check power cord of peripheral unit if it has separate power cord. • Replace peripheral unit control board.

SC621-02	D	BICU> Finisher communication error: Timeout error
		During communication between the finisher MBX and the BICU, no ACK signal was detected for 100 ms after three attempts.
		<ul style="list-style-type: none"> • Serial line level unstable, external noise on the line • I/F cable connection to main machine or upstream finisher and loose, broken, defective • Breaker switch defective • Power cord loose, broken, defective • Peripheral unit control board defective • BICU defective
		<ul style="list-style-type: none"> • Determine if there is electrical noise on the power line or around the machine. • Inspect I/F cable connections of finishers to the main machine or to upstream unit. • If the peripheral unit has a breaker switch, test it. • Check power cord of peripheral unit if it has separate power cord. • Replace peripheral unit control board. • Replace BICU

SC626-01	D	BICU, LCIT communication error: Break reception error
		During communication with the LCIT, the BICU received a break (Low) signal.
		<ul style="list-style-type: none"> • Serial line connection unstable • External noise on the line • LCIT connection to main machine loose, broken, defective • LCIT control board defective • BICU defective
		<ul style="list-style-type: none"> • Determine if there is electrical noise on the power line or around the machine. • Check I/F cable connection of the LCIT on the right side of the main machine. • Inspect the cable connector for damage. • Make sure the connector is locked and connected. • Replace LCIT control board. • Replace BICU.

SC626-02	D	BICU, LCIT communication error: Timeout error
		After 1 data frame is sent to the LCIT, an ACK signal is not received within 100 ms, and is not received after 3 retries.
		<ul style="list-style-type: none"> • Serial line connection unstable • External noise on the line • LCIT connection to main machine loose, broken, defective • LCIT control board defective • BICU defective
		<ul style="list-style-type: none"> • Determine if there is electrical noise on the power line or around the machine. • Check I/F cable connection of the LCIT on the right side of the main machine. • Inspect the cable connector for damage. • Make sure the connector is locked and connected. • Replace LCIT control board. • Replace BICU.

SC628-01	B	IOB-CAPCNT communication break error Japan Only
		<p>When the error was issued, a message appeared on the operation panel display: "V Parts Maintenance Required". The capacitor unit ceased charging and discharging.</p> <ul style="list-style-type: none"> • A break (LOW signal) did not release at startup, or a break (LOW signal) was received while the communication circuit was connected to CAPCNT. • The machine set charge/discharge control to the OFF state, but the machine can continue operations that do not use the capacitor.
		<ul style="list-style-type: none"> • The serial line is unstable • External electrical noise on power line or around the machine. • Electrical short in the IOB-CAPCNT harness • Capacitor control board (CAPCNT) damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the problem persists, inspect the IOB-CAPCNT harness, connectors, and replace if damaged. • Replace the capacitor control board (CAPCNT).

SC628-02	B	IOB-CAPCNT communication timeout error Japan Only
		<p>There was no ACK returned within 100 ms after one frame of data was sent to CAPCNT.</p>
		<ul style="list-style-type: none"> • The serial line is unstable • External electrical noise on power line or around the machine. • Electrical short in the IOB-CAPCNT harness • Capacitor control board (CAPCNT) damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the problem persists, inspect the IOB-CAPCNT harness, connectors, and replace if damaged. • Replace the capacitor control board (CAPCNT).

SC641-00	D	Communication error between BICU and controller	CTL
----------	---	---	-----

		The RAPI protocol issued a frame from the controller to the BICU but the BICU did not respond. Three attempts were done at 100 ms intervals with no response. The RAPI driver failed to open at startup, or a retry error was issued four times during operation. Three attempts at 100 ms intervals failed to get a response from the engine.
		<ul style="list-style-type: none"> • Faulty connection between BICU and controller board. • Controller board or controller software error • BICU defective • Controller board defective
		<ul style="list-style-type: none"> • Check the harnesses and connectors that connect the BICU and controller boards for loose, broken, connectors or harness damage. • Cycle the machine off/on. • Replace BICU. • Replace controller board.

SC664-01		VODKA 1 SRAM access permission error (no write permission)
		When the machine was turned on, or recovered from the Energy Save mode, there was an error detected in the connection signal between VODKA (resides on IOB) and SRAM.
		<ul style="list-style-type: none"> • IOB, BICU harness, connectors loose, broken, defective. • IOB defective • BICU defective
		<ul style="list-style-type: none"> • Cycle the main power switch off/on. • If the problem persists, inspect the harnesses, connectors between BICU and IOB, and replace if damaged. • Replace IOB. • Replace BICU.

SC664-02		VODKA 1 SRAM write error (write result abnormal)
		When the machine was turned on, or recovered from the Energy Save mode, there was an error detected in the connection signal between VODKA (resides on IOB) and SRAM.

		<ul style="list-style-type: none"> • IOB, BICU harness, connectors loose, broken, defective. • IOB defective • BICU defective
		<ul style="list-style-type: none"> • Cycle the main power switch off/on. • If the problem persists, inspect the harnesses, connectors between BICU and IOB, and replace if damaged. • Replace IOB. • Replace BICU.

SC664-03		VODKA 1 program start error
		When the machine was turned, on or recovered from the Energy Save mode, there was an error detected in the connection signal between VODKA (resides on IOB) and SRAM.
		<ul style="list-style-type: none"> • IOB, BICU harness, connectors loose, broken, defective. • IOB defective • BICU defective
		<ul style="list-style-type: none"> • Cycle the main power switch off/on. • If the problem persists, inspect the harnesses, connectors between BICU and IOB, and replace if damaged. • Replace IOB. • Replace BICU.

SC664-11		VODKA 2 SRAM access permission error (no write permission)
		When the machine was turned on, or recovered from the Energy Save mode, there was an error detected in the connection signal between VODKA 2 (resides on IOB) and SRAM.
		<ul style="list-style-type: none"> • IOB, BICU harness, connectors loose, broken, defective. • IOB defective • BICU defective

		<ul style="list-style-type: none"> • Cycle the main power switch off/on. • If the problem persists, inspect the harnesses, connectors between BICU and IOB, and replace if damaged. • Replace IOB. • Replace BICU.
--	--	--

SC664-12		VODKA 2 SRAM write error (write result abnormal)
		When the machine was turned, on or recovered from the Energy Save mode, there was an error detected in the connection signal between VODKA 2 (resides on IOB) and SRAM.
		<ul style="list-style-type: none"> • IOB, BICU harness, connectors loose, broken, defective. • IOB defective • BICU defective
		<ul style="list-style-type: none"> • Cycle the main power switch off/on. • If the problem persists, inspect the harnesses, connectors between BICU and IOB, and replace if damaged. • Replace IOB. • Replace BICU.

SC664-13		VODKA 2 program start error
		When the machine was turned on, or recovered from the Energy Save mode, there was an error detected in the connection signal between VODKA 2 (resides on IOB) and SRAM.
		<ul style="list-style-type: none"> • IOB, BICU harness, connectors loose, broken, defective. • IOB defective • BICU defective
		<ul style="list-style-type: none"> • Cycle the main power switch off/on. • If the problem persists, inspect the harnesses, connectors between BICU and IOB, and replace if damaged. • Replace IOB. • Replace BICU.

SC664-21		VODKA 3 SRAM access permission error (no write permission)
----------	--	--

		When the machine was turned on, or recovered from the Energy Save mode, there was an error detected in the connection signal between VODKA 3 (resides on IOB) and SRAM.
		<ul style="list-style-type: none"> • IOB, BICU harness, connectors loose, broken, defective. • IOB defective • BICU defective
		<ul style="list-style-type: none"> • Cycle the main power switch off/on. • If the problem persists, inspect the harnesses, connectors between BICU and IOB, and replace if damaged. • Replace IOB. • Replace BICU.

SC664-22		VODKA 3 SRAM write error (write result abnormal)
		When the machine was turned on, or recovered from the Energy Save mode, there was an error detected in the connection signal between VODKA 3 (resides on IOB) and SRAM.
		<ul style="list-style-type: none"> • IOB, BICU harness, connectors loose, broken, defective. • IOB defective • BICU defective
		<ul style="list-style-type: none"> • Cycle the main power switch off/on. • If the problem persists, inspect the harnesses, connectors between BICU and IOB, and replace if damaged. • Replace IOB. • Replace BICU.

SC664-23		VODKA 3 program start error
		When the machine was turned on, or recovered from the Energy Save mode, there was an error detected in the connection signal between VODKA 3 (resides on IOB) and SRAM.
		<ul style="list-style-type: none"> • IOB, BICU harness, connectors loose, broken, defective. • IOB defective • BICU defective

		<ul style="list-style-type: none"> • Cycle the main power switch off/on. • If the problem persists, inspect the harnesses, connectors between BICU and IOB, and replace if damaged. • Replace IOB. • Replace BICU.
--	--	--

SC665-04	D	IOB failure to start error
		<p>There was a problem with the IOB_WAKE signal:</p> <ul style="list-style-type: none"> • The IOB_WAKE signal was detected abnormal when out of the WAKE status. This occurred when the three VODKA modules on the IOB were reset. • There were IOB_WAKE signals detected from the 3 VODKA modules on the IOB, but there were not released from WAKE status. • IOB_WAKE status will not be released if the machine detects an IOB_WAKE signal from even one of the three VODKA modules on the IOB.
		<ul style="list-style-type: none"> • BICU-IOB harnesses, connectors, loose, broken, defective • PSU 5V not output • IOB damaged • RYB damaged • BICU damaged
		<ul style="list-style-type: none"> • Inspect BICU-IOB harnesses, connectors and replace if damaged. • Replace PSU. • Replace IOB. • Replace RYB. • Replace BICU.

SC669-01		ID Error at NVRAM OPEN
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.

		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-02		Channel Error at NVRAM OPEN
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-03		Device Error at NVRAM OPEN
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-04		Communication interrupt error at NVRAM OPEN
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged

		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.
--	--	--

SC669-05		Communication timeout error at NVRAM OPEN
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-06		Operation interrupt error at NVRAM OPEN
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.

		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-07		Buffer Full Error at NVRAM OPEN
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-08		No error code at NVRAM OPEN
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-09		ID error at NVRAM CLOSE
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged

		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.
SC669-10		No error code at NVRAM CLOSE
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.
SC669-11		ID Error When Writing Data to NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.

		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

7

SC669-12		Channel error when writing data to NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-13		Device error when writing data to NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-14		Communication interrupt error when writing data to NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged

		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.
--	--	--

SC669-15		Communication timeout error when writing data to NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-16		Operation interrupt error when writing data to NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.

		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-17		Buffer full error when writing data to NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-18		No error code when writing data to NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-19		ID error when reading data from NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged

		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.
--	--	--

SC669-20		Channel error when reading data from NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-21		Device error when reading data from NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.

		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

7

SC669-22		Communication error when reading data from NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-23		Communication timeout error when reading data from NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-24		Operation error when reading data from NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged

		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.
--	--	--

SC669-25		Buffer full error when reading data from NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-26		No error code when reading data from NVRAM
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.

		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-27		ID error at NVRAM device detection
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-28		Channel error at NVRAM device detection
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-29		Device error at NVRAM device detection
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged

		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.
--	--	--

SC669-30		Communication interrupt error at NVRAM device detection
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-31		Communication timeout error at NVRAM device detection
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.

		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

7

SC669-32		Operation interrupt error at NVRAM device detection
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-33		Buffer full error at NVRAM device detection
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged
		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.

SC669-34		No error code at NVRAM device detection
		An error occurred during communication with the NVRAM on the BICU. Three attempts to communicate with NVRAM failed.
		<ul style="list-style-type: none"> • Electronic noise • NVRAM missing, not mounted on BICU • NVRAM not installed correctly • NVRAM damaged • BICU damaged

		<ul style="list-style-type: none"> • Cycle the machine off/on. • If the error persists, first determine if there is any electronic noise on the power line or around the machine. • Remove the rear upper cover and inspect the NVRAM on the BICU. • Confirm that the NVRAM is installed, undamaged, and installed correctly. • Make sure that the pins of the NVRAM are seated correctly (not bent out of place). • Replace NVRAM. • Replace BICU.
--	--	--

SC670-01	D	Engine startup error	CTL
		The BICU failed to respond within the prescribed time when the machine was turned on.	
		<ul style="list-style-type: none"> • Connections between BICU and controller board are loose, disconnected, or damaged • BICU defective • Controller board defective 	
		<ul style="list-style-type: none"> • Inspect the harness connections between the BICU and controller board. • Inspect the harnesses and replace if damaged. • Replace BICU. • Replace controller board. 	

SC670-02	D	Engine shutdown after startup	CTL
		An unexpected condition (hardware damage, faulty software, electrical noise) forced a CPU reset, or VODKA reset on the BICU.	
		<ul style="list-style-type: none"> • After the ENGRDY signal was asserted, there was an unexpected problem. The machine shifted to Engine Off mode. • However, when the machine was turned off instability in the electrical circuit the controller shut the controller board down first, so the error detection was delayed 10 sec. 	

		<ul style="list-style-type: none"> • Cycle the machine off/on. • Check the connectors and harnesses that connect the BICU and controller board for damage, loose or broken connections. • Update the firmware • If these measures fail, replace the boards in this order: • Replace BICU • Replace PSU • Replace controller board
--	--	--

SC672-10	D	Controller start up error	CTL
		After the machine was powered on, communication between the controller and the operation panel was not established.	
		<ul style="list-style-type: none"> • Controller stalled • Board installed incorrectly • Controller board defective • Operation panel connector loose, broken, or defective • Controller late 	
		<ul style="list-style-type: none"> • Turn the main power off/on. • Check the connection of the controller board. • Replace the controller board. • Check the control panel harness. 	

SC672-11	D	Controller start up error	CTL
		After the machine was powered on, communication between the controller and the operation panel was not established, or communication with controller was interrupted after a normal startup.	
		<ul style="list-style-type: none"> • Controller stalled • Board installed incorrectly • Controller board defective • Operation panel connector loose, broken, or defective • Controller late 	
		<ul style="list-style-type: none"> • Turn the main power off/on. • Check the connection of the controller board. • Replace the controller board. • Check the control panel harness. 	

7

SC672-12	D	Controller start up error	CTL
		Communication with controller was interrupted after a normal startup.	
		<ul style="list-style-type: none"> • Controller stalled • Board installed incorrectly • Controller board defective • Operation panel connector loose, broken, or defective • Controller late 	
		<ul style="list-style-type: none"> • Turn the main power off/on. • Check the connection of the controller board. • Replace the controller board. • Check the control panel harness. 	

SC672-13	D	Controller start up error	CTL
		The operation panel detected that the controller is down.	
		<ul style="list-style-type: none"> • Controller stalled • Board installed incorrectly • Controller board defective • Operation panel connector loose, broken, or defective • Controller late 	
		<ul style="list-style-type: none"> • Turn the main power off/on. • Check the connection of the controller board. • Replace the controller board. • Check the control panel harness. 	

SC672-99	D	Controller start up error	CTL
		The operation panel software ended abnormally.	
		<ul style="list-style-type: none"> • Controller stalled • Board installed incorrectly • Controller board defective • Operation panel connector loose, broken, or defective • Controller late 	
		<ul style="list-style-type: none"> • Turn the main power off/on. • Check the connection of the controller board. • Replace the controller board. • Check the control panel harness. 	

SC689-01	C	Proximity sensor failure: Error 1
		The proximity sensor has remained on (operator presence detected) for longer than 24 hours and it is not functioning.
		<ul style="list-style-type: none"> • Sensor remains on because it is damaged.
		<ul style="list-style-type: none"> • Enter the User Tools mode and set the sensor to "Disabled". (Default: Enabled) so the message will not appear while waiting for replacement. • Replace the sensor and its components.

SC689-02	C	Proximity sensor failure: Error 2
		The proximity sensor will not detect the presence of the operator (remains off), even after 20 occurrences of activity on the machine: using the operation panel, opening/closing the ADF, setting an original, opening/closing the front door, opening/closing a paper tray. The operator can continue to use the machine (only the sensor function is disabled.)
		<ul style="list-style-type: none">• The sensor remains off because it is damaged.
		<ul style="list-style-type: none">• Enter the User Tools mode and set the sensor to "Disabled". (Default: Enabled) so the message will not appear while waiting for replacement.• Replace the sensor and its components.

SC700: Peripherals

SC700: Peripherals

SC700-01	D	ADF bottom plate lift motor error
		<p>The bottom plate position sensor did not go on after the bottom plate lift motor switched on to raise or lower the bottom plate.</p> <p>-or-</p> <p>The bottom plate HP sensor did not go off after the bottom plate lift motor switched on to lower the bottom plate.</p> <ul style="list-style-type: none"> • The bottom plate lift motor raises and lowers the bottom plate that holds the originals. • If the output of the bottom plate position sensor does not change after the bottom plate is raised or lowered, at the first occurrence the ADF signals the main machine that a problem has occurred in the operation of the ADF. • At the second occurrence the ADF signals a jam error.
		<ul style="list-style-type: none"> • No output from bottom plate position sensor • No output from bottom plate HP sensor • Bottom plate motor not operating • ADF main board problem
		<ul style="list-style-type: none"> • Inspect the harnesses, connectors of the bottom plate position sensor and the bottom plate HP sensor. • Check the harness, connector of the bottom plate lift motor. • Replace bottom plate position sensor. • Replace bottom plate HP sensor. • Replace bottom plate lift motor. • Replace ADF main board.
SC700-02	D	ADF original pick-up motor error

		<p>The pick-up motor is operating but the status of the pickup HP sensor does not change.</p> <ul style="list-style-type: none"> • Normally, the rotation of the pick-up motor lowers the pickup roller onto the surface of the original on top of the raised stack to separate it and feed it. • The pickup roller HP sensor detects when the pickup roller is raised and lowered, but if there is no output from this sensor, the ADF signals the main machine that a problem has occurred with the original pickup operation. • At the second occurrence the ADF signals a jam.
		<ul style="list-style-type: none"> • No signal from the pickup HP sensor because sensor harness, connector loose, broken, defective. • Pick-up HP sensor defective • Pick-up motor harness, connector, is loose, broken, defective. • Pick-up motor defective. • ADF main defective
		<ul style="list-style-type: none"> • Inspect the pick-up HP sensor harness, connector for damage and replace. • Inspect pick-up motor sensor harness, connector for damage and replace. • Inspect ADF main board harnesses, connectors. • Replace pick-up HP sensor. • Replace pick-up motor. • Replace ADF main board.

SC700-04	D	ADF feed motor error
		<p>The machine detected an error signal during operation of the feed motor.</p> <ul style="list-style-type: none"> • A problem is detected when an error is detected in register of the feed motor encoder, in encoder channel A (B), or when the overload signal is detected. • However, at the second occurrence the ADF signals a jam. • A problem occurs in the encoder channel when there is no change in the encoder pulse even after a drive command is sent. • An overload error occurs when the PWM duty continues high after the prescribed has elapsed.

		<ul style="list-style-type: none"> • Paper jammed in paper path • Motor overload due to blockage • Motor harness loose, broken, defective • Motor bracket, motor installed incorrectly • Feed motor defective
		<ul style="list-style-type: none"> • Inspect the paper path for jammed paper, paper scraps, etc. • Inspect the area around the feed motor and remove any obstacles that could interfere with motor operation. • Check feed motor harness, connector for damage and replace. • Inspect the feed motor bracket and motor and confirm that they are installed correctly. • Replace feed motor.
SC700-05	D	ADF entrance motor error
		<p>The machine detected an error signal during operation of the motor.</p> <ul style="list-style-type: none"> • A problem is detected when an error is detected in register of the entrance motor encoder, in encoder channel A (B), or when the overload signal is detected. • However, at the second occurrence the ADF signals a jam. • A problem occurs in the encoder channel when there is no change in the encoder pulse even after a drive command is sent. • An overload error occurs when the PWM duty continues high after the prescribed has elapsed.
		<ul style="list-style-type: none"> • Paper jammed in paper path • Motor overload due to blockage • Motor harness loose, broken, defective • Motor bracket, motor installed incorrectly • Entrance motor defective

		<ul style="list-style-type: none"> • Inspect the paper path for jammed paper, paper scraps, etc. • Inspect the area around the entrance motor and remove any obstacles that could interfere with motor operation. • Check entrance motor harness, connector for damage and replace. • Inspect the entrance motor bracket and motor and confirm that they are installed correctly. • Replace feed motor.
--	--	--

SC700-06	D	ADF transport motor error
		<p>The machine detected an error signal during operation of the motor.</p> <ul style="list-style-type: none"> • A problem is detected when an error is detected in register of the transport motor encoder, in encoder channel A (B), or when the overload signal is detected. • However, at the second occurrence the ADF signals a jam. • A problem occurs in the encoder channel when there is no change in the encoder pulse even after a drive command is sent. • An overload error occurs when the PWM duty continues high after the prescribed has elapsed.
		<ul style="list-style-type: none"> • Paper jammed in paper path • Motor overload due to blockage • Motor harness loose, broken, defective • Motor bracket, motor installed incorrectly • Transport motor defective
		<ul style="list-style-type: none"> • Inspect the paper path for jammed paper, paper scraps, etc. • Inspect the area around the transport motor and remove any obstacles that could interfere with motor operation. • Check relay motor harness, connector for damage and replace. • Inspect the transport motor bracket and motor and confirm that they are installed correctly. • Replace transport motor.

SC700-07	D	ADF scan motor error
----------	---	----------------------

		<p>The machine detected an error signal during operation of the motor.</p> <ul style="list-style-type: none"> • A problem is detected when an error is detected in register of the scan motor encoder, in encoder channel A (B), or when the overload signal is detected. • However, at the second occurrence the ADF signals a jam. • A problem occurs in the encoder channel when there is no change in the encoder pulse even after a drive command is sent. • An overload error occurs when the PWM duty continues high after the prescribed has elapsed.
		<ul style="list-style-type: none"> • Paper jammed in paper path • Motor overload due to blockage • Motor harness loose, broken, defective • Motor bracket, motor installed incorrectly • Scan motor defective
		<ul style="list-style-type: none"> • Inspect the paper path for jammed paper, paper scraps, etc. • Inspect the area around the scan motor and remove any obstacles that could interfere with motor operation. • Check scan motor harness, connector for damage and replace. • Inspect the relay motor bracket and motor and confirm that they are installed correctly. • Replace scan motor.

SC700-09	D	ADF exit motor error
		<p>The machine detected an error signal during operation of the motor.</p> <ul style="list-style-type: none"> • A problem is detected when an error is detected in register of the exit motor encoder, in encoder channel A (B), or when the overload signal is detected. • However, at the second occurrence the ADF signals a jam. • A problem occurs in the encoder channel when there is no change in the encoder pulse even after a drive command is sent. • An overload error occurs when the PWM duty continues high after the prescribed has elapsed.

		<ul style="list-style-type: none"> • Paper jammed in paper path • Motor overload due to blockage • Motor harness loose, broken, defective • Motor bracket, motor installed incorrectly • Exit motor defective
		<ul style="list-style-type: none"> • Inspect the paper path for jammed paper, paper scraps, etc. • Inspect the area around the exit motor and remove any obstacles that could interfere with motor operation. • Check exit motor harness, connector for damage and replace. • Inspect the exit motor bracket and motor and confirm that they are installed correctly. • Replace exit motor.

7

SC702-04	D	ADF protection circuit error 4
		A problem occurred on the interlock power protection circuit while the main 24V power was on. A problem with the pick-up motor, bottom plate lift motor, or a short circuit in a harness, tripped an interrupt on the interlock power protection circuit.
		<ul style="list-style-type: none"> • Defective motor or harness on the interlock circuit.
		<ul style="list-style-type: none"> • Inspect the interlock power protection circuit harness, switch. • Inspect all harnesses, connectors of motors ADF main board and replace if damaged. • Replace main board.

SC702-05		ADF protection circuit error 5
		A problem occurred on the interlock power protection circuit while the main 24V power was on.
		<ul style="list-style-type: none"> • Interlock power circuit harness, switch is loose, broken, defective. • Motor harness, connector is loose, broken, or defective. • Motor is defective.

		<ul style="list-style-type: none"> • Inspect the interlock power protection circuit harness, connector, and confirm that switch is installed correctly. • Inspect all motor harnesses, connectors and replace if damaged. • Use SP6007 (ADF Input Check) and SP6008 (ADF Output Check) to check the operation of all ADF harnesses and motors and replace if defective. • Inspect ADF main board harnesses, connectors. • Replace ADF main board
SC720-01	D	Downstream unit error (3K/2K Finisher)
		Three signals to the downstream unit to establish communication were not answered.
		<ul style="list-style-type: none"> • Downstream I/F cable harness, connector is loose, broken, or defective. • Downstream unit main board defective • Main machine controller board defective
		<ul style="list-style-type: none"> • Inspect the connection of I/F cable for loose connection or damage. • Replace downstream unit main board. • Replace main machine controller board.
SC720-03	D	Overload protection short circuit 1 (3K/2K Finisher)
		A blown fuse interrupted the overload protection circuit. If the machine does not reboot automatically, this means a fuse has blown.
		<ul style="list-style-type: none"> • Motor overload • Motor harness, connector is loose, broken, defective • Motor defective • Solenoid defective
		<ul style="list-style-type: none"> • Inspect the areas around the motors and solenoids and remove any obstructions. • Inspect motor and solenoid harnesses, connectors, and replace if damaged. • Use SP6007 (ADF Input Check) and SP6008 (ADF Output Check) to check the operation of all ADF harnesses and motors and replace if defective.

SC720-04	D	Overload protection short circuit 2 (Mailbox)
		A blown fuse interrupted the overload protection circuit. Mail box failure disabled finisher operation.
		<ul style="list-style-type: none"> • Motor overload • Motor harness, connector is loose, broken, defective • Motor defective • Solenoid defective
		<ul style="list-style-type: none"> • Check Mailbox main motor, main board, and solenoid harnesses, connectors and replace if damaged. • Replace main motor • Replace solenoid • Replace main board.

SC720-06	C	NVRAM access error (3K/2K Finisher)
		An error occurred when NVRAM memory of the finisher was accessed.
		<ul style="list-style-type: none"> • NVRAM memory defective, damaged
		<ul style="list-style-type: none"> • Replace finisher main board

SC720-10	D	Entrance motor error (3K/2K Finisher)
		A problem was detected with the motor drive board that controls this DC motor. The first detection issues a jam alert, and the second detection issues this SC code.
		<ul style="list-style-type: none"> • Motor harness, connector is loose, broken, or defective. • Motor or drive board defective.
		<ul style="list-style-type: none"> • Inspect motor harness, connector and replace if damaged. • Replace entrance motor. • Replace Finisher main board.

SC720-11	D	Horizontal transport motor error (3K/2K Finisher)
----------	---	---

		A problem was detected with the motor drive board that controls this DC motor. The first detection issues a jam alert, and the second detection issues this SC code.
		<ul style="list-style-type: none"> • Motor harness, connector is loose, broken, or defective. • Motor or drive board defective.
		<ul style="list-style-type: none"> • Inspect motor harness, connector and replace if damaged. • Replace horizontal transport motor. • Replace Finisher main board.

SC720-13	B	Relay motor error (3K/2K Finisher)
		A problem was detected with the motor drive board that controls this DC motor. The first detection issues a jam alert, and the second detection issues this SC code.
		<ul style="list-style-type: none"> • Motor harness, connector is loose, broken, or defective. • Motor or drive board defective.
		<ul style="list-style-type: none"> • Inspect motor harness, connector and replace if damaged. • Replace relay motor. • Replace Finisher main board.

SC720-15	B	Pre-stack transport motor error (3K/2K Finisher)
		A problem was detected with the motor drive board that controls this DC motor. The first detection issues a jam alert, and the second detection issues this SC code.
		<ul style="list-style-type: none"> • Motor harness, connector is loose, broken, or defective. • Motor or drive board defective.
		<ul style="list-style-type: none"> • Inspect motor harness, connector and replace if damaged. • Replace pre-stack transport motor. • Replace Finisher main board.

SC720-17	B	Exit motor error (3K/2K Finisher)
----------	---	-----------------------------------

		A problem was detected with the motor drive board that controls this DC motor. The first detection issues a jam alert, and the second detection issues this SC code.
		<ul style="list-style-type: none"> • Motor harness, connector is loose, broken, or defective. • Motor or drive board defective.
		<ul style="list-style-type: none"> • Inspect motor harness, connector and replace if damaged. • Replace exit motor. • Replace Finisher main board.

SC720-20	B	Lower junction gate motor error (3K/2K Finisher)
		The lower junction gate did not return to its home position within the prescribed number of pulses (p0), or the number of pulses exceeded the limit when the junction gate moved out of the home position. The first occurrence of this error signals a jam alert, the second occurrence issues this SC code.
		<ul style="list-style-type: none"> • Motor overload. • Motor harness, connector is loose, broken, or defective. • Junction gate HP sensor harness, connector is loose, broken, or defective. • Motor defective. • Junction gate HP sensor defective.
		<ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with motor operation. • Inspect lower junction gate motor harness, connector and replace if damaged. • Inspect junction gate HP sensor harness, connector and replace if damaged. • Replace lower junction gate motor. • Replace lower junction gate HP sensor. • Replace Finisher main board.

SC720-24	B	<p data-bbox="399 250 806 282">Exit guide motor error (3K/2K Finisher)</p> <p data-bbox="399 311 1211 413">The exit guide did not return to its home position within the prescribed number of pulses (p0), or the number of pulses exceeded the limit when it moved out of the home position.</p> <ul data-bbox="423 446 1171 658" style="list-style-type: none"> <li data-bbox="423 446 622 472">• Motor overload. <li data-bbox="423 491 1026 517">• Motor harness, connector is loose, broken, or defective. <li data-bbox="423 537 1171 562">• Exit guide HP sensor harness, connector is loose, broken, or defective. <li data-bbox="423 582 622 607">• Motor defective. <li data-bbox="423 627 766 652">• Exit guide HP sensor defective. <ul data-bbox="423 691 1204 987" style="list-style-type: none"> <li data-bbox="423 691 1185 756">• Inspect the area around the motor for obstacles that could interfere with motor operation. <li data-bbox="423 776 1163 801">• Inspect exit guide motor harness, connector and replace if damaged. <li data-bbox="423 821 1204 846">• Inspect exit guide HP sensor harness, connector and replace if damaged. <li data-bbox="423 866 714 891">• Replace exit guide motor. <li data-bbox="423 911 760 936">• Replace exit guide HP sensor. <li data-bbox="423 956 753 981">• Replace Finisher main board.
----------	---	---

<p>SC720-25</p>	<p>D</p>	<p>Punch drive motor error (3K/2K Finisher)</p> <p>The punch unit did not return to its home position within the prescribed number of pulses (p0), or the number of pulses exceeded the limit when it moved out of the home position. The first occurrence of this error issues a jam alert, the second occurrence issues this SC code.</p> <ul style="list-style-type: none"> • Motor overload. • Motor harness, connector is loose, broken, or defective. • Punch unit HP sensor harness, connector is loose, broken, or defective. • Motor defective. • Punch unit HP sensor defective. <ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with motor operation. • Inspect punch motor harness, connector and replace if damaged. • Inspect punch unit HP sensor harness, connector and replace if damaged. • Replace punch drive motor. • Replace punch unit HP sensor. • Replace Finisher main board.
-----------------	----------	--

SC720-27	D	<p data-bbox="401 250 879 280">Punch movement motor error (3K/2K Finisher)</p> <p data-bbox="401 309 1199 446">Did not return to its home position within the prescribed number of pulses (p0), or the number of pulses exceeded the limit when moved out of the home position. The first occurrence of this error issues a jam alert, the second occurrence issues this SC code.</p> <ul data-bbox="426 482 1174 691" style="list-style-type: none"> • Motor overload. • Motor harness, connector is loose, broken, or defective. • Punch unit HP sensor harness, connector is loose, broken, or defective. • Motor defective. • Punch unit HP sensor defective. <ul data-bbox="426 727 1185 1093" style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with motor operation. • Inspect punch movement motor harness, connector and replace if damaged. • Inspect punch unit HP sensor harness, connector and replace if damaged. • Replace punch movement motor. • Replace punch unit HP sensor. • Replace Finisher main board.
----------	---	---

<p>SC720-28</p>	<p>D</p>	<p>Paper position sensor error (3K/2K Finisher)</p> <p>The punch unit not return to its home position within the prescribed number of pulses (p0), or the number of pulses exceeded the limit when it moved out of the home position.</p> <p>The first occurrence of this error issues a jam alert, the second occurrence issues this SC code.</p> <ul style="list-style-type: none"> • Motor overload. • Motor harness, connector is loose, broken, or defective. • Paper position (CIS) sensor harness, connector is loose, broken, or defective. • Motor defective. • Sensor defective. <ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with motor operation. • Inspect punch movement motor harness, connector and replace if damaged. • Inspect punch unit HP sensor harness, connector and replace if damaged. • Replace punch movement motor. • Replace punch unit HP sensor. • Replace Finisher main board.
-----------------	----------	--

SC720-30	B	<p data-bbox="399 250 776 282">Jogger motor error (3K/2K Finisher)</p> <p data-bbox="399 311 1190 446">The front or rear jogger fence did not return to its home position within the prescribed number of pulses (p0), or the number of pulses exceeded the limit when the fence moved out of the home position. The first occurrence of this error issues a jam alert, and the second occurrence issues this SC code.</p> <ul data-bbox="426 482 989 648" style="list-style-type: none"> <li data-bbox="426 482 622 511">• Motor overload. <li data-bbox="426 527 989 556">• Motor harness, sensor is loose, broken, or defective. <li data-bbox="426 572 847 601">• Front or rear jogger motor is defective. <li data-bbox="426 617 952 648">• Front or rear jogger fence HP sensor is defective. <ul data-bbox="426 682 1188 1050" style="list-style-type: none"> <li data-bbox="426 682 1188 746">• Inspect the area around the motor for obstacles that could interfere with operation of the motor. <li data-bbox="426 762 1174 827">• Inspect harnesses, connectors of the front and rear jogger motors, and replace if damaged. <li data-bbox="426 842 1188 907">• Inspect harnesses, connectors of front and rear jogger fence HP sensors and replace if damaged. <li data-bbox="426 923 710 952">• Replace defective motor. <li data-bbox="426 968 714 997">• Replace defective sensor. <li data-bbox="426 1013 755 1042">• Replace Finisher main board.
----------	---	--

SC720-33	B	<p data-bbox="399 1111 902 1142">Positioning roller lift motor error (3K/2K Finisher)</p> <p data-bbox="399 1172 1149 1272">The positioning roller not return to its home position within the prescribed number of pulses (p0), or the number of pulses exceeded the limit when it moved out of the home position.</p> <p data-bbox="399 1287 1195 1352">The first occurrence of this error issues a jam alert, and the second occurrence issues this SC code.</p> <ul data-bbox="426 1385 989 1552" style="list-style-type: none"> <li data-bbox="426 1385 622 1415">• Motor overload. <li data-bbox="426 1430 989 1460">• Motor harness, sensor is loose, broken, or defective. <li data-bbox="426 1475 847 1505">• Positioning roller lift motor is defective. <li data-bbox="426 1520 858 1550">• Positioning roller HP sensor is defective.
----------	---	--

		<ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect harnesses, connectors of the positioning roller motor. • Inspect harnesses, connectors of the positioning roller HP sensor and replace if damaged. • Replace positioning roller lift motor. • Replace positioning roller HP sensor. • Replace Finisher main board.
--	--	---

SC720-34	B	Positioning roller drive motor error (3K/2K Finisher)
		An error was detected on the motor drive board that controls operation of this DC motor. The first occurrence of this error signals a jam alert, the second occurrence issues this SC code.
		<ul style="list-style-type: none"> • Motor overload • Motor harness, connector is loose, broken, or defective. • Motor, motor drive board defective
		<ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Replace positioning roller drive motor. • Replace Finisher main board.

SC720-35	B	TE press motor error (3K/2K Finisher)
		An error occurred in the motor drive board that controls operation of this DC motor. The TE (trailing edge) press plate was not detected at the home position within the prescribed time, or the plate did not move away from the home position within the prescribed time.
		<ul style="list-style-type: none"> • Motor overload. • Motor harness, connector is loose, broken, or defective. • TE press plate HP sensor harness, connector is loose, broken, or defective. • HP sensor defective • Motor, motor drive board defective.

		<ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect HP sensor harness, connector and replace if damaged. • Replace TE press plate HP sensor. • Replace TE press motor. • Replace Finisher main board.
SC720-41	B	<p data-bbox="399 609 842 642">Feed-out belt motor error (3K/2K Finisher)</p> <p data-bbox="399 672 1195 844">An error occurred on the motor drive board that controls the operation of this DC motor, and the feed-out belt was not detected at the home position within the number of prescribed pulses, or the belt pawl not leave the home position within the number of prescribed pulses. The first occurrence of this error issues a jam alert, the second occurrence issues this SC code.</p> <ul style="list-style-type: none"> • Motor overload. • Motor harness, connector is loose, broken, or defective. • Feed-out belt HP sensor harness, connector is loose, broken, or defective. • HP sensor defective • Motor, motor drive board defective. <ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect feed-out belt HP sensor harness, connector and replace if damaged. • Replace feed-out belt HP sensor. • Replace feed-out belt motor. • Replace Finisher main board.

SC720-42	B	<p>Corner stapler movement motor error (3K/2K Finisher)</p> <p>The stapler did not return to its home position within the prescribed number of pulses, or did not leave the home position within the prescribed number of pulses. The first occurrence issues a jam alert, the second issues this SC code.</p> <ul style="list-style-type: none"> • Motor overload. • Motor harness, connector is loose, broken, or defective. • Stapler HP sensor harness, connector is loose, broken, or defective. • HP sensor defective • Motor, motor drive board defective. <ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect stapler HP sensor harness, connector and replace if damaged. • Replace corner stapler HP sensor. • Replace corner stapler movement motor. • Replace Finisher main board.
----------	---	---

SC720-44	B	Corner stapler motor error (3K/2K Finisher)
		The corner stapler not move out of the home position with the prescribed time. The first occurrence of this error signals a jam, the second occurrence issues this SC code.
		<ul style="list-style-type: none"> • Motor overload (too many sheets for stapling). • Motor harness, connector is loose, broken, or defective. • Corner stapler HP sensor harness, connector is loose, broken, or defective. • HP sensor defective • Motor, motor drive board defective.
		<ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect corner stapler HP sensor harness, connector and replace if damaged. • Replace corner stapler HP sensor. • Replace corner stapler motor. • Replace Finisher main board.

SC720-50	B	Stapler side fence motor error (2K Finisher)
		<p>The side fences did not return to their home positions within the prescribed number of pulses, or the number of pulses exceeded the limit when they moved out of the home position.</p> <p>The first occurrence issues a jam alert, the second occurrence issues this SC code.</p>
		<ul style="list-style-type: none"> • Motor overload • Side fence motors harnesses, connectors are loose, broken, or defective. • Side fence HP sensors harnesses, connectors are loose, broken, or defective. • Front or rear side fence motor defective. • Front or rear side fence HP sensor defective.

		<ul style="list-style-type: none"> • Inspect the areas around the motors for obstacles that could interfere with operation of the motors. • Inspect the harnesses, connectors of the front and rear stapler side fence motors and replace if damaged. • Inspect the harnesses, connectors of the front and rear side fence HP sensors, and replace if damaged. • Replace front or rear side fence motor. • Replace front or rear side fence HP sensor.
SC720-51	B	Bottom fence motor error (2K Finisher)
		The bottom fence did not return to its home position within the prescribed number of pulses, or it did not leave the home position within the prescribed number of pulses. The first occurrence issues a jam alert, and the second occurrence issues this SC code.
		<ul style="list-style-type: none"> • Motor overload • Bottom fence motor harness, connector is loose, broken, or defective. • Bottom fence HP sensor, connector is loose, broken, or defective. • Booklet bottom fence motor defective. • Booklet bottom fence HP sensor defective.
		<ul style="list-style-type: none"> • Inspect the areas around the motor for obstacles that could interfere with operation of the motors. • Inspect the harness, connector of the bottom fence motor and replace if damaged. • Inspect the harnesses, connectors of the bottom fence HP sensor, and replace if damaged. • Replace bottom fence motor. • Replace bottom fence HP sensor.

SC720-52	B	<p data-bbox="401 250 806 280">Fold plate motor error (3K/2K Finisher)</p> <p data-bbox="401 309 1204 446">The fold plate did not return to its home position within the prescribed number of pulses, or it did not leave the home position within the prescribed number of pulses. The first occurrence of this error signals a jam, the second occurrence issues this SC code.</p> <ul data-bbox="426 482 1174 691" style="list-style-type: none"> • Motor overload. • Motor harness, connector is loose, broken, or defective. • Fold plate HP sensor harness, connector is loose, broken, or defective. • HP sensor defective • Motor defective.
		<ul data-bbox="426 727 1201 1021" style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect fold plate HP sensor harness, connector and replace if damaged. • Replace fold plate HP sensor. • Replace fold plate motor. • Replace Finisher main board.

SC720-53	B	Booklet bottom fence motor error (2K Finisher)
		The bottom fence not return to its home position within the prescribed number of pulses, or the number of pulses exceeded the limit when it moved out of the home position. The first occurrence issues a jam alert, the second occurrence issues this SC code.
		<ul style="list-style-type: none"> • Motor overload. • Motor harness, connector is loose, broken, or defective. • Bottom fence HP sensor harness, connector is loose, broken, or defective. • HP sensor defective • Motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect bottom fence HP sensor harness, connector and replace if damaged. • Replace bottom HP sensor. • Replace bottom fence motor. • Replace Finisher main board.

SC720-54	B	Stack transport motor error (2K Finisher)
		When a problem like a short or overheating is detected with the motor drive board that controls this DC motor, the first detection issues a jam alert and the second detection issues this SC code.
		<ul style="list-style-type: none"> • Motor overload. • Motor harness, connector is loose, broken, or defective. • Motor defective.
		<ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Replace motor • Replace Finisher main board.

SC720-60	B	<p data-bbox="422 250 834 280">Booklet stapler motor error (2K Finisher)</p> <p data-bbox="422 309 1140 446">The booklet stapler unit did not return to its home position within the prescribed time (t0sec), or did not leave the home position within the prescribed time (t1 sec). The first occurrence issues a jam alert, and the second occurrence issues this SC code.</p> <ul data-bbox="447 482 1140 727" style="list-style-type: none"> • Motor overloaded. • Motor harness, connector is loose, broken, or defective. • Booklet stapler HP sensor harness, connector is loose, broken, or defective. • Booklet stapler motor defective. • Booklet stapler HP sensor defective. <ul data-bbox="447 766 1204 1054" style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect the HP sensor harness, connector and replace if damaged. • Replace booklet stapler HP sensor. • Replace booklet stapler motor. • Replace Finisher main board.
----------	---	--

SC720-70	B	Finisher tray lift motor error (3K/2K Finisher)
		<p>A problem was detected with the motor controller (overload) but the status of the shift tray paper height sensor did not change.</p> <ul style="list-style-type: none"> • It remained on, detecting the top of the stack, even after the prescribed time elapsed for when the tray was lowered. • Or, the sensor did not detect the top of the tray within the prescribed time when the tray was raised. • The first occurrence issues a jam alert, and the second occurrence issues this SC code.
		<ul style="list-style-type: none"> • Motor overloaded. • Motor harness, connector is loose, broken, or defective. • Lift tray HP sensor harness, connector is loose, broken, or defective. • Tray lift motor defective. • Tray HP sensor defective.
		<ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect the HP sensor harness, connector and replace if damaged. • Replace tray HP sensor. • Replace tray lift motor. • Replace Finisher main board.

SC720-71	D	<p data-bbox="422 250 769 282">Shift motor error (3K/2K Finisher)</p> <p data-bbox="422 311 1163 413">Did not return to its home position within the prescribed number of pulses (p0), or did not leave the home position within the prescribed number of pulses.</p> <p data-bbox="422 433 1190 495">The first occurrence issues a jam alert, the second occurrence issues this SC code.</p> <ul data-bbox="447 527 1181 740" style="list-style-type: none"> • Motor overloaded. • Motor harness, connector is loose, broken, or defective. • Shift tray HP sensor harness, connector is loose, broken, or defective. • Shift exit motor defective. • Shift tray HP sensor defective. <ul data-bbox="447 776 1204 1070" style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect the HP sensor harness, connector and replace if damaged. • Replace shift tray HP sensor. • Replace shift exit motor. • Replace Finisher main board.
----------	---	---

<p>SC720-72</p>	<p>B</p>	<p>Front shift jogger motor error (3K/2K Finisher)</p>
		<p>The front shift jogger fence did not return to its home position within the prescribed number of pulses, or it did not leave the home position within the prescribed number of pulses. The first occurrence issues a jam alert, and the second occurrence issues this SC code.</p>
		<ul style="list-style-type: none"> • Motor overloaded. • Motor harness, connector is loose, broken, or defective. • Shift tray jogger HP sensor harness, connector is loose, broken, or defective. • Front shift jogger motor defective. • Shift tray jogger HP sensor defective.
		<ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect the shift tray exit sensor harness, connector and replace if damaged. • Replace shift tray jogger HP sensor. • Replace shift tray jogger motor. • Replace Finisher main board.

SC720-73	B	<p data-bbox="415 250 975 282">Shift jogger fence retract motor error (3K/2K Finisher)</p> <p data-bbox="415 311 1201 446">Jogger fences did not return to home position within the prescribed number of pulses, or did not leave the home position within the prescribed number of pulses. The first occurrence issues a jam alert, and the second occurrence issues this SC code.</p> <ul data-bbox="440 482 1171 731" style="list-style-type: none"> • Motor overloaded. • Motor harness, connector is loose, broken, or defective. • Shift jogger retract HP sensor harness, connector is loose, broken, or defective. • Shift jogger fence retract motor defective. • Shift jogger retract HP sensor defective. <ul data-bbox="440 766 1201 1054" style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect the HP sensor harness, connector and replace if damaged. • Replace shift jogger retract HP sensor. • Replace shift jogger fence retract motor. • Replace Finisher main board.
----------	---	---

<p>SC720-74</p>	<p>B</p>	<p>Drag roller retraction motor error (3K/2K Finisher)</p>
		<p>The drag roller not return to its home position within the prescribed number of pulses, or it did not leave the home position within the prescribed number of pulses. The first occurrence issues a jam alert, the second occurrence issues this SC code.</p>
		<ul style="list-style-type: none"> • Motor overloaded. • Motor harness, connector is loose, broken, or defective. • Shift jogger retract HP sensor harness, connector is loose, broken, or defective. • Drag roller retraction motor defective. • Shift jogger retract HP sensor defective.
		<ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect the HP sensor harness, connector and replace if damaged. • Replace shift jogger retract HP sensor. • Replace drag roller retraction motor. • Replace Finisher main board.

SC720-75	B	<p data-bbox="422 250 897 282">Drag roller drive motor error (3K/2K Finisher)</p> <p data-bbox="422 309 1204 486">An error occurred in the motor drive board that controls operation of this DC motor, and the roller moving to the home position was not detected within the prescribed time, or the roller did not move away from the home position within the prescribed time. The first occurrence of this error signals a jam, and the second occurrence issues this SC code.</p> <ul data-bbox="447 517 1204 733" style="list-style-type: none"> • Motor overloaded. • Motor harness, connector is loose, broken, or defective. • Drag roller HP sensor harness, connector is loose, broken, or defective. • Motor defective. • Shift jogger retract HP sensor defective. <ul data-bbox="447 764 1204 1058" style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect the HP sensor harness, connector and replace if damaged. • Replace shift jogger retract HP sensor. • Replace drag roller drive motor. • Replace Finisher main board.
----------	---	---

SC720-80	D	Overload protection circuit error 3 (3K/2K Finisher)
		A blown fuse interrupted the overload protection circuit.
		<ul style="list-style-type: none"> • Interlock power circuit harness, switch is loose, broken, defective. • Motor harness, connector is loose, broken, or defective. • Solenoid harness, connector is loose, broken, or defective. • Solenoid defective. • Motor defective.
		<ul style="list-style-type: none"> • Inspect the interlock power protection circuit harness, connector, and confirm that switch is installed correctly. • Inspect all motor, solenoid harnesses, connectors and replace if damaged. • Use SP6007 (ADF Input Check) and SP6008 (ADF Output Check) to check the operation of all finisher motors, solenoids and replace if defective. • Inspect main board harnesses, connectors. • Replace ADF main board

SC720-81	D	Fold roller motor error (3K/2K Finisher)
		An error was detected on the motor drive board that controls operation of this DC motor. The first occurrence of this error signals a jam alert, and the second occurrence issues this SC code.
		<ul style="list-style-type: none"> • Motor overload • Motor harness loose, broken, or defective. • Motor, motor drive board defective.
		<ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Replace motor • Replace finisher main board.

SC720-82	B	Leading edge stopper motor error (3K/2K Finisher)
----------	---	---

		The leading edge stopper did not return to its home position within the prescribed number of pulses, or it did not leave the home position within the prescribed number of pulses. The first occurrence of this error signals a jam, the second occurrence issues this SC code.
		<ul style="list-style-type: none"> • Leading edge stopper motor overloaded. • Motor harness, connector is loose, broken, or defective. • Leading edge stopper HP sensor harness, connector is loose, broken, or defective. • Motor defective. • HP sensor defective.
		<ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect the HP sensor harness, connector and replace if damaged. • Replace leading edge stopper HP sensor. • Replace leading edge stopper motor. • Replace Finisher main board.

SC720-83	B	Junction gate motor error (3K/2K Finisher)
		The proof/shift junction gate not return to its home position within the prescribed number of pulses (p0), or did not leave the home position within the prescribed number of pulses. The first occurrence of this error signals a jam, and the second occurrence issues this SC code.
		<ul style="list-style-type: none"> • Junction gate motor overloaded. • Motor harness, connector is loose, broken, or defective. • Proof JG HP sensor harness, connector is loose, broken, or defective. • Motor defective. • HP sensor defective.

		<ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect the HP sensor harness, connector and replace if damaged. • Replace proof JG HP sensor. • Replace junction gate motor. • Replace Finisher main board.
--	--	--

SC720-84	D	Overload protection circuit error 2 (3K/2K Finisher: Mailbox)
		A blown fuse interrupted the overload protection circuit. If the machine does not reboot automatically, this means a fuse has blown.
		<ul style="list-style-type: none"> • Motor overload • Motor damage • Solenoid damage
		<ul style="list-style-type: none"> • Inspect the areas around the finisher motors for obstacles that could interfere with operation of the motors. • Check motor harnesses, connectors and replace if damaged. • Inspect Mailbox main motor, solenoids for obstacles that could interfere with motor operation. • Check Mailbox main motor, solenoid harness, connect and replace if damaged. • Use SP6121 and SP6124 to do the input/output checks for the Finisher and then replace defective components. • Replace finisher main board.

SC720-87	D	<p data-bbox="422 250 790 280">Finisher punch motor error (3K/2K)</p> <p data-bbox="422 309 1195 413">The punch HP sensor was not activated within the specified time after the punch motor turned on. The first detection failure issues a jam error, and the second failure issues this SC code.</p> <ul data-bbox="447 446 893 570" style="list-style-type: none"> <li data-bbox="447 446 893 476">• Punch motor overload due to obstruction <li data-bbox="447 491 893 521">• Punch HP sensor disconnected, defective <li data-bbox="447 537 893 566">• Punch motor disconnected, defective <ul data-bbox="447 599 1204 848" style="list-style-type: none"> <li data-bbox="447 599 1204 664">• Inspect the area around the punch motor for obstacles that could interfere with operation of the motor. <li data-bbox="447 680 1204 709">• Inspect harness, connector of punch motor and replace if damaged. <li data-bbox="447 725 1204 754">• Inspect harness, connector of punch HP sensor and replace if defective. <li data-bbox="447 770 701 799">• Replace punch motor. <li data-bbox="447 815 742 844">• Replace punch HP sensor.
SC722-01	D	<p data-bbox="422 907 1012 936">Downstream finisher communication error (Finisher D610)</p> <p data-bbox="422 966 1136 1030">No response signal was received from the downstream finisher after 3 attempts</p> <ul data-bbox="447 1064 900 1187" style="list-style-type: none"> <li data-bbox="447 1064 900 1093">• Finisher I/F cable loose, broken defective <li data-bbox="447 1109 797 1138">• Finisher control board defective <li data-bbox="447 1154 797 1183">• Main controller board defective <ul data-bbox="447 1217 1174 1340" style="list-style-type: none"> <li data-bbox="447 1217 1174 1246">• Inspect the connection of I/F cable for loose connection or damage. <li data-bbox="447 1262 861 1291">• Replace downstream unit main board. <li data-bbox="447 1307 883 1336">• Replace main machine controller board.

SC722-10	B	Transport motor error (Finisher D610)
		A pulse signal from the transport motor could not be detected within the prescribed time. The first detection triggers a jam code, and the second detection triggers this SC.
		<ul style="list-style-type: none"> • Motor overload due to an obstruction • Motor harness connector loose, broken, defective • Motor defective
		<ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect harness, connector of punch motor and replace if damaged. • Replace transport motor

SC722-24	B	Exit guide motor (Finisher D610)
		The status of the exit guide sensor did not change at the prescribed time during operation of the exit guide.
		<ul style="list-style-type: none"> • Exit guide open sensor harness, connector is loose, broken, defective. • Exit guide motor harness, sensor is loose, broken, defective. • Exit guide sensor defective • Exit guide motor defective • Finisher main board defective
		<ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect harness, connector of exit open sensor and replace if damaged. • Replace exit guide open sensor. • Replace exit guide motor.

SC722-25		<p>Punch motor error (Finisher D610)</p> <p>After the punch operation, the punch HP sensor did not detect the punch unit at the home position.</p> <ul style="list-style-type: none"> • Punch motor connection loose, broken, or defective. • Punch overload (blocked by obstruction) • HP sensor connection loose, broken, or defective • Punch HP sensor defective <ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect punch HP sensor harness, connector and replace if damaged. • Replace punch HP sensor. • Replace punch motor
----------	--	---

SC722-30	B	<p>Finisher jogger motor error (Finisher D610)</p> <ul style="list-style-type: none"> • The finisher jogger HP sensor remained off for more than 1,000 pulses when the jogger fence returned to home position. • The finisher jogger HP sensor remained on for more than 1,000 pulses when the fence away from home position. <ul style="list-style-type: none"> • Jogger mechanism overload • Jogger fence HP sensor harness disconnected or defective • Jogger fence motor harness, connector is loose, broken, or defective. • Jogger fence HP sensor defective • Jogger motor defective • Finisher main board defective <ul style="list-style-type: none"> • Inspect the area around the motor for obstacles that could interfere with operation of the motor. • Inspect motor harness, connector and replace if damaged. • Inspect HP sensor harness, connector and replace if damaged. • Replace jogger motor. • Replace jogger fence HP sensor. • Replace Finisher main board.
----------	---	---

SC722-33	B	Finisher staple hammer motor error (Finisher D610)
		The staple hammer motor did not return to the home position within the prescribed time (340 ms).
		<ul style="list-style-type: none">• Electrical overload on the stapler drive PCB• Staple hammer HP sensor loose, broken, defective• Staple hammer motor defective• Finisher main board defective
		<ul style="list-style-type: none">• Reduce the number of sheets in the stack for stapling.• Inspect the hammer HP sensor harness, connector and replace if damaged.• Replace staple hammer motor• Replace Finisher main board.

SC722-35	D	<p>Stack Plate Motor Error 1: Front Motor(Finisher D610)</p> <p>The stack plate HP sensor (front) did not activate within 500 ms after the motor turned on. The first detection failure causes a jam error, and the second failure causes this SC code.</p> <p>If the motor is operating:</p> <ul style="list-style-type: none"> • Front stack plate HP sensor harness loose, broken, defective • Front stack plate HP sensor defective <p>If the motor is not operating:</p> <ul style="list-style-type: none"> • Motor blocked by an obstruction • Motor harness loose, broken, defective • Motor defective • Finisher main board defective <p>If the motor is operating:</p> <ul style="list-style-type: none"> • Inspect stack plate HP sensor harness, connector and replace if damaged. • Replace front stack plate HP sensor. <p>If the motor is not operating:</p> <ul style="list-style-type: none"> • Inspect area around the motor and remove any obstacles that could interfere with motor operation. • Inspect motor harness, connector and replace if damaged. • Replace motor • Replace finisher main board
----------	---	--

<p>SC722-36</p>	<p>D</p>	<p>Stack Plate Motor Error 2: Center Motor (Finisher D610)</p>
		<p>The stack plate HP sensor (center) did not activate within 500 ms after the motor turned on. The 1st detection failure causes a jam error, and the 2nd failure causes this SC code.</p>
		<p>If the motor is operating</p> <ul style="list-style-type: none"> • Center stack plate HP sensor harness loose, broken, defective • Center stack plate HP sensor defective <p>If the motor is not operating:</p> <ul style="list-style-type: none"> • Motor blocked by an obstruction • Motor harness loose, broken, defective • Motor defective • Finisher main board defective
		<p>If the motor is operating</p> <ul style="list-style-type: none"> • Inspect center stack plate HP sensor harness and replace if damaged. • Replace center stack plate HP sensor. <p>If the motor is not operating:</p> <ul style="list-style-type: none"> • Inspect the area around the motor, and remove any obstacle to motor operation. • Inspect motor harness, connector and replace if damaged. • Replace stack plate motor • Replace finisher main board.

SC722-37	D	<p data-bbox="422 250 982 280">Stack Plate Motor Error 3: Rear Motor (Finisher D610)</p> <p data-bbox="422 309 1171 413">The stack plate HP sensor (rear) does not activate within 500 ms after the motor turns on. The 1st detection failure causes a jam error, and the 2nd failure causes this SC code.</p> <p data-bbox="422 442 666 472">If the motor is operating</p> <ul data-bbox="447 491 1085 564" style="list-style-type: none"> <li data-bbox="447 491 1085 521">• Rear stack plate HP sensor harness loose, broken, defective <li data-bbox="447 537 845 564">• Rear stack plate HP sensor defective <p data-bbox="422 584 710 613">If the motor is not operating:</p> <ul data-bbox="447 633 875 799" style="list-style-type: none"> <li data-bbox="447 633 810 662">• Motor blocked by an obstruction <li data-bbox="447 678 875 707">• Motor harness loose, broken, defective <li data-bbox="447 723 639 752">• Motor defective <li data-bbox="447 768 856 799">• Booklet finisher main board defective <p data-bbox="422 829 666 858">If the motor is operating</p> <ul data-bbox="447 878 1167 950" style="list-style-type: none"> <li data-bbox="447 878 1167 907">• Inspect rear stack plate HP sensor harness and replace if damaged. <li data-bbox="447 923 831 950">• Replace rear stack plate HP sensor <p data-bbox="422 970 710 999">If the motor is not operating:</p> <ul data-bbox="447 1019 1190 1221" style="list-style-type: none"> <li data-bbox="447 1019 1190 1083">• Inspect the area around the motor, and remove any obstacle to motor operation. <li data-bbox="447 1099 1075 1128">• Inspect motor harness, connector and replace if damaged. <li data-bbox="447 1144 673 1174">• Replace rear motor <li data-bbox="447 1189 769 1221">• Replace finisher main board.
----------	---	---

<p>SC722-39</p>	<p>B</p>	<p>Jogger Top Fence Motor (Finisher D610)</p> <p>The top fence HP sensor detected that: The top fence did not arrive at the home position within the specified number of pulses.</p> <p>-or-</p> <p>The top fence failed to leave the home position within the specified number of pulses.</p> <p>If the jogger top fence motor is operating:</p> <ul style="list-style-type: none"> • Top fence HP sensor harness loose, broken, defective • Top fence HP sensor defective <p>If the jogger top fence motor is not operating:</p> <ul style="list-style-type: none"> • Motor blocked by an obstruction • Motor harness loose, broken, defective • Motor defective • Finisher main board defective <p>If the motor is operating</p> <ul style="list-style-type: none"> • Inspect rear top fence HP sensor harness and replace if damaged. • Replace top fence HP sensor <p>If the motor is not operating:</p> <ul style="list-style-type: none"> • Inspect the area around the motor, and remove any obstacle to motor operation. • Inspect motor harness, connector and replace if damaged. • Replace jogger top fence motor • Replace finisher main board.
-----------------	----------	--

SC722-40	B	<p>Jogger Bottom Fence Motor (Finisher D610)</p> <p>The bottom fence HP sensor detected that: The bottom fence did not arrive at the home position at the specified time. -or- The bottom fence failed to leave the home position at the specified time.</p> <p>If the jogger bottom fence motor is operating:</p> <ul style="list-style-type: none"> • Bottom fence HP sensor harness loose, broken, defective • Bottom fence HP sensor defective <p>If the jogger bottom fence motor is not operating:</p> <ul style="list-style-type: none"> • Motor blocked by an obstruction • Motor harness loose, broken, defective • Motor defective • Finisher main board defective <p>If the motor is operating</p> <ul style="list-style-type: none"> • Inspect rear bottom fence HP sensor harness and replace if damaged. • Replace bottom fence HP sensor <p>If the motor is not operating:</p> <ul style="list-style-type: none"> • Inspect the area around the motor, and remove any obstacle to motor operation. • Inspect motor harness, connector and replace if damaged. • Replace jogger bottom fence motor • Replace finisher main board.
----------	---	---

SC722-41	D	Feed-Out Belt Motor Error (Finisher D610)
		<p>The stack feed-out belt HP sensor does not activate within the specified time after the stack feed-out belt motor turns on. The 1st detection failure causes a jam error, and the 2nd failure causes this SC code.</p>
		<p>If the motor is operating</p> <ul style="list-style-type: none"> • Stack feed-out HP sensor harness loose, broken, defective • Stack feed-out HP sensor defective <p>If the motor is not operating:</p> <ul style="list-style-type: none"> • Feed-out motor blocked by an obstruction • Feed-out motor harness loose, broken, defective • Feed-out motor defective • Booklet finisher main board defective
		<p>If the motor is operating</p> <ul style="list-style-type: none"> • Inspect stack feed-out HP sensor harness and replace if damaged. • Replace stack feed-out HP sensor <p>If the motor is not operating:</p> <ul style="list-style-type: none"> • Inspect the area around the motor, and remove any obstacle to motor operation. • Inspect motor harness, connector and replace if damaged. • Replace feed-out belt motor • Replace finisher main board.

SC722-42	B	Finisher stapler movement motor error (Finisher D610)
		The stapler HP sensor is not activated within the specified time after the stapler motor turned on. The 1st detection failure issues a jam error, and the 2nd failure issues this SC code.
		<ul style="list-style-type: none"> • Stapler movement motor overloaded due to obstruction • Stapler HP sensor harness, connector loose, broken, defective. • Stapler HP sensor defective • Stapler movement motor harness, connector loose, broken, defective. • Stapler movement motor defective.
SC722-43	B	Finisher corner stapler rotation motor error (Finisher D610)
		The stapler does not return to its home position within the specified time after stapling. The 1st detection failure issues a jam error, and the 2nd failure issues this SC code.
		<ul style="list-style-type: none"> • Stapler rotation motor overloaded due to obstruction • Motor disconnected. • Motor defective. • Stapler rotation HP sensor harness, connector loose, broken, defective. • Sensor defective.
<ul style="list-style-type: none"> • Inspect the area around the stapler rotation motor and remove any obstructions. • Inspect motor harness, connector and replace if damaged. • Inspect stapler rotation HP sensor harness, connector and replace if damaged. • Replace sensor. 		

SC722-44	B	Finisher corner stapler motor error (Finisher D610)
		The stapler motor does not switch off within the prescribed time after operating. The 1st detection failure issues a jam error, and the 2nd failure issues this SC code.
		<ul style="list-style-type: none"> • Staple jam • Number of sheets in the stack exceeds the limit for stapling • Stapler motor harness, connector loose, broken, defective. • Motor defective.
		<ul style="list-style-type: none"> • Remove staple jam. • Inspect, empty staple hopper. • Check the number of sheets being stapled. • Inspect stapler motor harness, connector and replace if damaged. • Replace motor.

SC722-70	B	Finisher tray 1 (upper tray lift) motor error (Finisher D610)
		The upper tray paper height sensor does not change its status with the specified time after the tray raises or lowers. The 1st detection failure issues a jam error, and the 2nd failure issues this SC code.
		<ul style="list-style-type: none"> • Tray lift motor harness, connector loose, broken, defective. • Motor defective. • Upper tray paper height sensor harness, connector loose, broken, defective. • Sensor defective • Finisher main board connection to motor loose, broken, defective. • Finisher main board defective
		<ul style="list-style-type: none"> • Inspect the tray lift motor harness, connector and replace if damaged. • Inspect motor harness connect at the finisher main board. • Replace motor • Inspect upper tray paper height sensor harness, connector and replace if damaged. • Replace sensor • Replace finisher main board.

SC722-71	D	<p>Shift Motor Error (Finisher D610)</p> <p>The shift tray half-turn sensors: Failed twice to detect the shift tray at the home position at the specified time. -or- Failed twice to detect that the shift tray had left the home position.</p> <p>If the motor is operating</p> <ul style="list-style-type: none"> • Half-turn sensor 1, 2 harnesses loose, broken, defective • One of the half-turn sensors is defective <p>If the motor is not operating:</p> <ul style="list-style-type: none"> • Shift motor blocked by an obstruction • Motor harness loose, broken, defective • Motor defective • Finisher main board defective <p>If the motor is operating</p> <ul style="list-style-type: none"> • Inspect the half-turn sensor 1, 2 harnesses, connectors and replace if damaged. • Replace one or both half-turn sensors. <p>If the motor is not operating:</p> <ul style="list-style-type: none"> • Inspect the area around the shift motor and remove any obstructions. • Inspect motor harness, connector and replace if damaged. • Replace motor. • Replace finisher main board.
----------	---	--

<p>SC722-72</p>	<p>B</p>	<p>Front shift jogger motor error (Finisher D610)</p>
		<p>The sides fences do not retract within the prescribed time after the shift jogger motor switches on. The 1st detection failure issues a jam error, and the 2nd failure issues this SC code.</p>
		<ul style="list-style-type: none"> • Front shift jogger motor overloaded due to obstruction. • Motor harness, connector loose, broken, defective. • Motor defective • Front shift jogger HP sensor harness, connector loose, broken, defective. • Sensor defective
<p>SC722-74</p>	<p>B</p>	<p>Shift jogger retraction motor error (Finisher D610)</p>
		<p>The side fences do not retract within the prescribed time after the retraction motor switches on. The 1st detection failure issues a jam error, and the 2nd failure issues this SC code.</p>
		<ul style="list-style-type: none"> • Motor overload • Motor harness disconnected, loose, defective • Motor defective • HP sensor defective
		<ul style="list-style-type: none"> • Inspect the area around the shift jogger retraction motor and remove any obstruction. • Inspect motor harness and replace if damaged. • Inspect home position sensor harness and replace if damaged. • Replace sensor. • Replace motor.

SC722-75	B	Return roller motor error (Finisher D610)
		Occurs during the operation of the lower tray pressure motor.
		<ul style="list-style-type: none"> • Motor overloaded • Motor harness disconnected, loose, defective • Home position sensor harness disconnected, loose, defective • HP sensor defective
		<ul style="list-style-type: none"> • Inspect the area around the return roller motor and remove any obstruction. • Inspect motor harness and replace if damaged. • Inspect home position sensor harness and replace if damaged. • Replace sensor. • Replace motor.
SC722-80	B	Finisher staple trimming hopper full (Finisher D610)
		The staple waste hopper is full of cut staples.
		<ul style="list-style-type: none"> • If the hopper is not full, the hopper full sensor is disconnected • Sensor defective
		<ul style="list-style-type: none"> • Empty the hopper. • Inspect the hopper full sensor harness and replace if damaged. • Replace sensor.
SC722-81	D	Finisher transport motor error (Finisher D610)
		The encoder pulse of the finisher transport motor does not change state (high/low) within 600 ms and does not change after 2 retries.
		<ul style="list-style-type: none"> • Transport motor harness disconnected, or defective • Finisher transport motor defective • Finisher main board defective
		<ul style="list-style-type: none"> • Inspect transport motor harness and replace if damaged. • Replace motor. • Replace finisher main board.

SC722-83	D	Finisher punch motor error (Finisher D610)
		The punch HP sensor is not activated within the specified time after the punch motor turned on. The 1st detection failure issues a jam error, and the 2nd failure issues this SC code.
		<ul style="list-style-type: none"> • Punch motor overload due to obstruction • Punch HP sensor disconnected, defective • Punch motor disconnected, defective
		<ul style="list-style-type: none"> • Inspect the area around the punch motor and remove any obstructions. • Inspect the punch HP sensor harness and replace if damaged. • Replace punch motor.

SC724-03	D	Overload protection circuit error 1 (1-Bin Tray Japan Only)
		When a protective element interrupt (blown 24V fuse) is detected:
		<ul style="list-style-type: none"> • Short circuit due to motor overload • Harness connector loose, broken, defective • Motor defective.
		<ul style="list-style-type: none"> • Inspect the area round the motor and remove any obstructions. • Inspect the harness and replace if damaged. • Replace the motor.

SC724-71	B	Shift roller motor 1 error (1-Bin Tray Japan Only)
		<p>This SC is issued with one detection of an error in motor drive output or a short circuit.</p> <ul style="list-style-type: none"> • The roller home position sensor was not detected within the prescribed time when roller moved to home position. • During normal operation the time interval for returning and leaving the home position is calculated and measured. For normal operation this is 1.5 to 2 times the prescribed times t0 and t1. • Done only during paper shift.

		<ul style="list-style-type: none"> • Motor overload. • Motor damaged, defective • Motor connector loose, broken, defective • Roller HP sensor harness disconnected or defective • Roller HP sensor defective
		<ul style="list-style-type: none"> • Inspect the area around the motor and remove any obstructions. • Inspect the motor harness and replace if damaged. • Inspect roller HP sensor harness and replace if damaged. • Replace sensor. • Replace motor.

SC724-80	D	Tray lift motor error (1-Bin Tray Japan Only)
		<p>When the tray was raised, the status of the shift tray paper height sensor did not change within the prescribed time (t_0sec).</p> <p>-or-</p> <p>When the tray was lowered, the shift tray paper height sensor failed to detect the top of the stack within the prescribed time (t_1sec).</p> <ul style="list-style-type: none"> • The first occurrence of this error signals a jam, the second occurrence issues this SC code. • During normal operation the detection time of the paper stack is calculated and measured. • For normal operation this is 2 to 3 times the prescribed times t_0 and t_1.
		<ul style="list-style-type: none"> • Motor overload. • Motor disconnected. • Motor damaged, defective • Paper height sensor disconnected. • Paper height sensor defective.
		<ul style="list-style-type: none"> • Inspect the area around the motor and remove any obstructions. • Inspect the motor harness and replace if damaged. • Inspect the paper height sensor harness and replace if damaged. • Replace paper height sensor. • Replace tray lift motor.

SC725-01	D	Finisher communication error	(Multi Folder D615)
		No response signal was received from the downstream finisher (D615) after 3 attempts	
		<ul style="list-style-type: none"> • Finisher I/F cable loose, broken defective • Finisher main board defective 	
		<ul style="list-style-type: none"> • Confirm that the finisher is connected to the upstream unit. • Inspect the finisher I/F cable harness, connector and replace if damaged. • Replace finisher main board. 	
SC725-12	B	Reg. roller transport motor error	(Multi Folder D615)
		The motor drive PCB detected an error at the motor.	
		<ul style="list-style-type: none"> • Motor harness or connector loose, broken, defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Inspect the motor harness and replace if damaged. • Replace the motor. 	
SC725-13	B	Dynamic roller transport motor error (Multi Folder D615)	
		The motor drive PCB detected an error at the motor.	
		<ul style="list-style-type: none"> • Motor harness or connector loose, broken, defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Inspect the motor harness and replace if damaged. • Replace the motor. 	
SC725-14	B	Z-fold top tray exit motor error (Multi Folder D615)	
		The motor driver detects an error.	
		<ul style="list-style-type: none"> • Motor over current • Motor driver overheat 	
		<ul style="list-style-type: none"> • Inspect the motor harness and replace if damaged. • Replace the motor. 	

SC725-30	B	Z-fold stopper 1 motor error (Multi Folder D615)	
		The bottom fence HP sensor detected that: The bottom fence did not arrive at the home position at the specified time.	
		-or- The bottom fence failed to leave the home position at the specified time.	
		<ul style="list-style-type: none"> • Motor overload. • Motor driver overheat • Motor harness loose 	
		<ul style="list-style-type: none"> • Inspect the area around the motor and remove any obstructions. • Inspect the motor harness and replace if damaged. • Replace the motor. 	

SC725-31	B	2nd Stopper motor error	(Multi Folder D615)
		The 2nd stopper HP sensor did not detect the 2nd stopper in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.	
		<ul style="list-style-type: none"> • 2nd stopper HP sensor dirty • Sensor harness or connector loose, broken, defective • 2nd stopper motor harness or connector loose, broken, defective • Sensor defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Clean 2nd stopper HP sensor. • Inspect sensor harness and replace if defective. • Inspect 2nd stopper motor harness and replace if damaged. • Replace 2nd stopper HP sensor. • Replace 2nd stopper motor. 	

SC725-32	B	3rd Stopper motor error	(Multi Folder D615)
		The 3rd stopper HP sensor did not detect the 3rd stopper in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.	
		<ul style="list-style-type: none"> • 3rd stopper HP sensor dirty • Sensor harness or connector loose, broken, defective • 3rd stopper motor harness or connector loose, broken, defective • Sensor defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Clean 3rd stopper HP sensor. • Inspect sensor harness and replace if defective. • Inspect 3rd stopper motor harness and replace if damaged. • Replace 3rd stopper HP sensor. • Replace 3rd stopper motor. 	

SC725-33	B	Jogger Fence Motor	(Multi Folder D615)
		The jogger fence HP sensor did not detect the jogger fence in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.	
		<ul style="list-style-type: none"> • Jogger fence HP sensor dirty • Sensor harness or connector loose, broken, defective • Jogger fence motor harness or connector loose, broken, defective • Sensor defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Clean jogger fence HP sensor. • Inspect sensor harness and replace if defective. • Inspect jogger fence motor harness and replace if damaged. • Replace jogger fence HP sensor. • Replace jogger fence motor. 	

SC725-34	B	Dynamic Roller Lift Motor Error	(Multi Folder D615)
		<p>The dynamic roller HP sensor did not detect the dynamic roller in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.</p>	
		<ul style="list-style-type: none"> • Dynamic roller HP sensor dirty • Sensor harness or connector loose, broken, defective • Dynamic roller lift motor harness or connector loose, broken, defective • Sensor defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Clean dynamic roller HP sensor. • Inspect sensor harness and replace if defective. • Inspect dynamic roller lift motor harness and replace if damaged. • Replace dynamic roller HP sensor. • Replace dynamic roller lift motor. 	
SC725-35	B	Registration Roller Release Motor Error	(Multi Folder D615)
		<p>The registration roller HP sensor did not detect the registration roller in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.</p>	
		<ul style="list-style-type: none"> • Registration roller HP sensor dirty • Sensor harness or connector loose, broken, defective • Registration roller release motor harness or connector loose, broken, defective • Sensor defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Clean registration roller HP sensor. • Inspect sensor harness and replace if defective. • Inspect registration roller release motor harness and replace if damaged. • Replace registration roller HP sensor. • Replace registration roller release motor. 	

SC725-36	B	FM2 Direct-Send JG Motor	(Multi Folder D615)
		The direct-send JG HP sensor did not detect the direct-send JG in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.	
		<ul style="list-style-type: none"> • FM2 direct-send JG HP sensor dirty • Sensor harness or connector loose, broken, defective • FM2 direct-send JG motor harness or connector loose, broken, defective • Sensor defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Clean FM2 direct-send JG HP sensor. • Inspect sensor harness and replace if defective. • Inspect FM2 direct-send JG motor harness and replace if damaged. • Replace FM2 direct-send JG HP sensor. • Replace FM2 direct-send JG motor. 	
SC725-37	B	FM6 Pawl Motor	(Multi Folder D615)
		The FM6 pawl HP sensor did not detect the FM6 pawl in (or out of) its home position. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.	
		<ul style="list-style-type: none"> • FM6 pawl HP sensor dirty • Sensor harness or connector loose, broken, defective • FM6 pawl motor harness or connector loose, broken, defective • Sensor defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Clean FM6 pawl HP sensor. • Inspect sensor harness and replace if defective. • Inspect FM6 pawl motor harness and replace if damaged. • Replace FM6 pawl HP sensor. • Replace FM6 pawl motor. 	

SC725-38	B	Fold Plate Motor Error	(Multi Folder D615)
		The fold plate HP sensor did not detect the fold plate in (or out of) its home position within the prescribed time. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.	
		<ul style="list-style-type: none"> • Fold plate HP sensor dirty • Sensor harness or connector loose, broken, defective • Fold plate motor harness or connector loose, broken, defective • Sensor defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Clean Fold plate HP sensor. • Inspect sensor harness and replace if defective. • Inspect fold plate motor harness and replace if damaged. • Replace Fold plate HP sensor. • Replace fold plate motor. 	
SC725-39	B	1st Fold Motor Error	(Multi Folder D615)
		The motor drive PCB detected an error at the motor.	
		<ul style="list-style-type: none"> • Motor harness or connector loose, broken, defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Inspect 1st fold motor harness and replace if damaged. • Replace motor. 	
SC725-40	B	2nd Fold Motor Error	(Multi Folder D615)
		The motor drive PCB detected an error at the motor.	
		<ul style="list-style-type: none"> • Motor harness or connector loose, broken, defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Inspect 2nd fold motor harness and replace if damaged. • Replace motor. 	

SC725-41	B	Crease Motor Error	(Multi Folder D615)
		The motor drive PCB detected an error at the motor.	
		<ul style="list-style-type: none"> • Motor harness or connector loose, broken, defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Inspect crease motor harness and replace if damaged. • Replace motor. 	

SC725-71	D	Horizontal Transport Motor Error	(Multi Folder D615)
		The motor drive PCB detected an error at the motor.	
		<ul style="list-style-type: none"> • Motor harness or connector loose, broken, defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Inspect horizontal transport motor harness and replace if damaged. • Replace motor. 	

SC725-72	D	Horizontal exit motor error	
		An error occurred on the motor drive board.	
		<ul style="list-style-type: none"> • Motor current overload • Motor drive board defective (replace motor) 	
		<ul style="list-style-type: none"> • Inspect horizontal exit motor harness and replace if damaged. • Replace motor. 	

SC725-73	D	Top Tray Exit Motor	(Multi Folder D615)
		The motor drive PCB detected an error at the motor.	
		<ul style="list-style-type: none"> • Motor harness or connector loose, broken, defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Inspect top tray exit motor harness and replace if damaged. • Replace motor. 	

SC725-74	D	Entrance JG Motor	(Multi Folder D615)
		The entrance junction gate HP sensor did not detect the entrance junction gate at (or out of) its home position. The 1st occurrence causes a jam, and the 2nd occurrence causes this SC code.	
		<ul style="list-style-type: none"> • Entrance JG HP sensor dirty • Sensor harness or connector loose, broken, defective • Entrance JG motor harness or connector loose, broken, defective • Sensor defective • Motor or motor drive board defective 	
		<ul style="list-style-type: none"> • Clean entrance JG HP sensor. • Inspect sensor harness and replace if defective. • Inspect entrance JG motor harness and replace if damaged. • Replace entrance JG HP sensor. • Replace entrance JG motor. 	

SC740-03	D	Cover feeder protection circuit error 1 – Blow Fuse (CIT)	
		A fuse (24V) has blown on a circuit for a motor or sensor.	
		<ul style="list-style-type: none"> • Short circuit caused by overload • Connector harness loose, broken, defective • Motor, sensor defective 	
		<ul style="list-style-type: none"> • Cycle machine off/on • After each corrective step, try to cycle the machine off/on. If the machine does not reboot automatically, this means there is a blown fuse. • Check the connector harnesses of motors and sensors for loose connections, damage, broken insulation • Inspect areas around motors to confirm there are no obstacles interfering with operation • Inspect motors for damage, and replace damaged motor • Inspect PCBs for damage or evidence of a blown fuse • Replace PCB with blown fuse (the board must be replaced, not just the fuse). 	

SC740-10	B	Cover interposer tray bottom plate motor error (CIT)
		<p>One of the following occurred:</p> <p>The lift sensor did not go ON within the prescribed time after the machine tried to lift the bottom plate.</p> <p>The lower limit sensor did not go ON within the prescribed time after the machine tried to lower the bottom plate.</p> <p>In either case, the first occurrence of the error issues a JAM alert. The second occurrence issues this SC code, and the Cover Interposer Tray cannot be used.</p>
		<ul style="list-style-type: none"> • Motor connector harness loose, broken, defective • Motor overload • Motor defective • Sensor connector harness loose, broken, defective • Sensor defective • PCB defective
		<ul style="list-style-type: none"> • Cycle the machine off/on after each corrective step. • Inspect the motor for obstructions that could interfere with operation of the motor • Inspect motor and sensor harness for poor connections, damage, poor insulation, and then reset or replace harness • Be sure to inspect connector harnesses at the PCBs • Do SP6451 and do an INPUT check for the motor and sensors to make sure that they are functioning correctly. • Replace defective motor or sensors. • Replace PCB where motor and harnesses are connected.
SC745-03	D	Mail box protection circuit error 1 (CIT)
		A blown fuse interrupted the overload protection circuit.
		<ul style="list-style-type: none"> • Short circuit due to overload • Motor harness loose, broken, defective. • Motor defective • Solenoid damaged

		<ul style="list-style-type: none">• Inspect the area around the main motor and remove any obstructions.• Inspect the motor harness and replace if damaged.• Inspect the solenoid harnesses and replace if damaged.• Replace the defective solenoid.
--	--	--

SC800: Overall System

SC800

SC816	[0x0000]	Energy save I/O subsystem error
SC816-01	D	Subsystem error
SC816-02	D	Sysarch (LPUX_GET_PORT_INFO) error
SC816-03	D	Transition to STR was denied.
SC816-04	D	Interrupt in kernel communication driver
SC816-05	D	Preparation for transition to STR failed.
SC816-07	D	Sysarch (LPUX_GET_PORT_INFO) error
SC816-08	D	Sysarch (LPUX_ENGINE_TIMERCTRL) error
SC816-09	D	Sysarch (LPUX_RETURN_FACTOR_STR) error
SC816-10	D	Sysarch (LPUX_GET_PORT_INFO) error
SC816-11	D	Sysarch (LPUX_GET_PORT_INFO) error
SC816-12	D	Sysarch (LPUX_GET_PORT_INFO) error
SC816-13	D	open() error
SC816-14	D	Memory address error
SC816-15	D	open() error
SC816-16	D	open() error
SC816-17	D	open() error
SC816-18	D	open() error
SC816-19	D	Double open() error
SC816-20	D	open() error
SC816-22	D	Parameter error
SC816-23	D	read() error

SC816-24	D	read() error
SC816-25	D	read() error
SC816-26	D	write() communication retry error
SC816-27	D	write() communication retry error
SC816-28	D	write() communication retry error
SC816-29	D	write() communication retry error
SC816-30	D	write() communication retry error
SC816-35	D	read() error
SC816-36	D	Subsystem error
SC816-37	D	Subsystem error
SC816-38	D	Subsystem error
SC816-39	D	Subsystem error
SC816-40	D	Subsystem error
SC816-41	D	Subsystem error
SC816-42	D	Subsystem error
SC816-43	D	Subsystem error
SC816-44	D	Subsystem error
SC816-45	D	Subsystem error
SC816-46	D	Subsystem error
SC816-47	D	Subsystem error
SC816-48	D	Subsystem error
SC816-49	D	Subsystem error
SC816-50	D	Subsystem error
SC816-51	D	Subsystem error
SC816-52	D	Subsystem error
SC816-53	D	Subsystem error

SC816-54	D	Subsystem error
SC816-55	D	Subsystem error
SC816-56	D	Subsystem error
SC816-57	D	Subsystem error
SC816-58	D	Subsystem error
SC816-59	D	Subsystem error
SC816-60	D	Subsystem error
SC816-61	D	Subsystem error
SC816-62	D	Subsystem error
SC816-63	D	Subsystem error
SC816-64	D	Subsystem error
SC816-65	D	Subsystem error
SC816-66	D	Subsystem error
SC816-67	D	Subsystem error
SC816-68	D	Subsystem error
SC816-69	D	Subsystem error
SC816-70	D	Subsystem error
SC816-71	D	Subsystem error
SC816-72	D	Subsystem error
SC816-73	D	Subsystem error
SC816-74	D	Subsystem error
SC816-75	D	Subsystem error
SC816-76	D	Subsystem error
SC816-77	D	Subsystem error
SC816-78	D	Subsystem error
SC816-79	D	Subsystem error

SC816-80	D	Subsystem error
SC816-81	D	Subsystem error
SC816-82	D	Subsystem error
SC816-83	D	Subsystem error
SC816-84	D	Subsystem error
SC816-85	D	Subsystem error
SC816-86	D	Subsystem error
SC816-87	D	Subsystem error
SC816-88	D	Subsystem error
SC816-89	D	Subsystem error
SC816-90	D	Subsystem error
SC816-91	D	Subsystem error
SC816-92	D	Subsystem error
SC816-93	D	Subsystem error
SC816-94	D	Subsystem error
		Energy save I/O subsystem detected some abnormality.
		<ul style="list-style-type: none"> • Energy save I/O subsystem defective • Energy save I/O subsystem detected a controller board error (non-response). • Error was detected during preparation for transition to STR.
		<ul style="list-style-type: none"> • Cycle the machine off/on. • Replace the controller board.

SC816-96	D	Energy save I/O subsystem error 1	CTL
		An error was detected in the energy save I/O subsystem.	

		<ul style="list-style-type: none"> • Energy save subsystem defective • There was no response to the energy save subsystem from the controller board. • A problem was detected before the machine shifted to STR mode (Suspend-to-RAM).
		<ul style="list-style-type: none"> • Cycle the machine off/on. • Update the firmware. • Execute SP5191-001 and disable machine shift to STR mode. • Replace the controller board.

SC816-98	D	Energy save I/O subsystem error 2	CTL
		An error was detected in the energy save I/O subsystem.	
		<ul style="list-style-type: none"> • Energy save subsystem defective • There was no response to the energy save subsystem from the controller board. • A problem was detected before the machine shifted to STR mode (Suspend-to-RAM). 	
		<ul style="list-style-type: none"> • Cycle the machine off/on. • Update the firmware. • Execute SP5191-001 and disable machine shift to STR mode. • Replace the controller board. 	

SC817-00	D	Monitor error: file detection/digital signature error	CTL
		<ul style="list-style-type: none"> • The bootloader cannot read any of diagnostic module, kernel, or root file system. • In a bootloader SD card, the digital signature checking for any of diagnostic module, kernel, or root file system failed. 	
		<ul style="list-style-type: none"> • One or more of the following does not exist or is corrupted: OS flash ROM, diagnostic module on SD card, kernel, root file system • One or more of the following has been updated incorrectly: diagnostic module in SD card, kernel, root file system 	
		<ul style="list-style-type: none"> • Update controller ROM • Use an SD boot card with a valid digital signature. 	

SC819-00	D	Fatal kernel error	CTL
		Due to a control error, a RAM overflow occurred during system processing. One of the following messages was displayed on the operation panel.	
		0x5032	HAIC-P2 error
		0x5245	Link-up fail
		0x5355	L2 Status Time Out
		0x696e	gwinit died
		0x766d	Vm_pageout: VM is full
		554C	USB loader defect
		Other	Other error
	<ul style="list-style-type: none"> • System program defective • Controller board defective • Optional board defective • Replace controller firmware 		
SC840-00	D	EEPROM access error	CTL
		An error occurred during I/O processing. <ul style="list-style-type: none"> • A read error occurred and 3 retries failed. • A write error occurred. 	
		EEPROM defective or end-of-life	
		-	
SC841-00	D	EEPROM read data error	CTL
		Compared the data from 3 areas of the EEPROM mirror data with the original data and all 3 of them were different from the original data.	
		Data in the specific area of the EEPROM has been modified.	
		-	

SC842-00	C	Nand-Flash updating verification error	CTL
		During remote ROM update or ROM update, the SCS detected a write error (verify error) regarding the data written to the Nand-Flash.	
		Nand-Flash damaged	
		Cycle the machine off/on.	

SC842-01	B	Nand-Flash block number exceeded threshold	CTL
		When the status of the Nand-Flash was checked at power-on or when returning from energy saver mode, the number of bad blocks exceeded the threshold.	
		Nand-Flash bad block number exceeding the threshold	
		Replace the controller board.	

SC842-02	B	Nand-Flash block erase exceeded threshold	CTL
		When the status of the Nand-Flash was checked at power-on or when returning from energy saver mode, the number of times the block was erased exceeded the threshold.	
		Number of times of Nand-Flash block erase exceeding the threshold	
		Replace the controller board.	

SC845-01	D	HW 1: Detected during automatic firmware update	CTL
SC845-02		HW 2: Detected during automatic firmware update	CTL
SC845-03		HW 3: Detected during automatic firmware update	CTL
SC845-04		HW 4: Detected during automatic firmware update	CTL
SC845-05		HW 5: Detected during automatic firmware update	CTL
		Due to a sudden loss of power during firmware update, reading and writing data was interrupted and suspended. If there was no damage to the main machine or finisher, the operation should resume automatically but the machine did not recover after three failed attempts.	

		<ul style="list-style-type: none"> • One or more of the following boards is defective: • BICU • Controller board • Operation panel control board • FCU
		<ul style="list-style-type: none"> • Replace BICU • Replace controller board • Replace operation panel control board • Replace FCU • If replacing the controller board fails to solve the problem replace the HDD and memory board. (Firmware update must be done if the HDD is replaced.)

SC855-01	B	Wireless LAN board error	CTL
		Wireless LAN board error (wireless LAN card: 802.11 is covered)	
		<ul style="list-style-type: none"> • Defective wireless LAN board • Loose connection 	
		<ul style="list-style-type: none"> • Cycle the machine off/on. • Replace wireless LAN board 	

SC855-02	B	Wireless LAN board error (initialization failed)	CTL
		Wireless LAN board error (wireless LAN card: 802.11 is covered)	
		<ul style="list-style-type: none"> • Defective wireless LAN board • Loose connection 	
		<ul style="list-style-type: none"> • Cycle the machine off/on. • Replace wireless LAN board 	

SC857-00	B	USB I/F Error	CTL
		The USB interface is unusable because of a driver error.	
		USB driver error (There are three causes of USB error: RX error/CRC error/STALL. SC is issued only in the case of STALL.)	
		<ul style="list-style-type: none"> • Check USB connection. • Replace the controller board. 	
SC858-00	A	Data encryption conversion error 1	CTL
		A serious error occurred during an attempt to update the encryption key.	
		<ul style="list-style-type: none"> • Data in the USB Flash etc. corrupted • Communication error because of electromagnetic interference etc. • Controller board defective 	
		Replace the board.	
SC858-01	A	Data encryption conversion error 1	CTL
		A serious error occurred during an attempt to update the encryption key.	
		<ul style="list-style-type: none"> • Data in the USB Flash etc. corrupted • Communication error because of electromagnetic interference etc. • Controller board defective 	
		Replace the board.	
SC858-02	A	Data encryption conversion error 2	CTL
		A serious error occurred after data conversion during an attempt to update the encryption key.	
		NVRAM defective	
		Replace controller board.	

SC858-30	A	Data encryption conversion error 3	CTL
		A serious error occurred after data conversion during an attempt to update the encryption key.	
		Software error such as conversion parameters being invalid.	
		Replace controller board.	
SC858-31	A	Data encryption conversion error 4	CTL
		A serious error occurred after data conversion during an attempt to update the encryption key.	
		Controller board defective	
		Replace the board.	
SC859-00	B	HDD data encryption conversion error 1	CTL
		HDD data was converted incorrectly when the data encryption key was updated. Image is displayed at conversion (SC code does not appear), but SC code appears after the machine is cycled off/on.	
		<ul style="list-style-type: none"> • HDD conversion was set with the data encryption key update function, but the HDD was removed. • Machine lost power during data encryption key update. • Electrostatic noise, or an HDD error occurred, during data encryption key update, and data was not encrypted. 	
		<ul style="list-style-type: none"> • Check HDD connection. • Format the HDD. • Replace. 	

SC859-01	B	HDD Data encryption conversion error 2	CTL
		HDD was not converted correctly during an attempt to update the encryption key. Only an error screen is displayed and no SC is issued during conversion. This SC is issued after machine restart.	
		<ul style="list-style-type: none"> • HDD conversion was selected in the Encryption key update function but the machine was turned on with the HDD removed. • Power failure occurred during encryption key update. • HDD was not successfully converted during encryption key update due to HDD errors or cable noises. 	
		<ul style="list-style-type: none"> • Check HDD connection. • Format the HDD. • If there is a problem with the HDD, it has to be replaced. 	
SC859-02	B	HDD data encryption conversion error 3	CTL
		HDD was not converted correctly during an attempt to update the encryption key.	
		Only an error screen is displayed and no SC is issued during conversion. This SC is issued after machine restart.	
		Details: NVRAM/HDD conversion is incomplete.	
		Power failure occurred during encryption key update.	
		None	
		The display after restart instructs the user to format the HDD.	

SC859-10	B	HDD data encryption conversion error 4	CTL
		<p>HDD was not converted correctly during an attempt to update the encryption key.</p> <p>Only an error screen is displayed and no SC is issued during conversion. This SC is issued after machine restart.</p> <p>Details:</p> <p>Abnormal DMAC return value has been received two or more times (DMAC timeout, serial communication error etc.)</p> <hr/> <p>HDD was not successfully converted during encryption key update due to HDD errors or cable noises.</p> <hr/> <ul style="list-style-type: none"> • Check HDD connection. • Format the HDD. • If there is a problem with the HDD, it has to be replaced. 	

SC860-00	B	HDD startup error at power on	CTL
		<p>The HDD is connected but the driver detected the following errors.</p> <ul style="list-style-type: none"> • SS_NOT_READY:/* (-2)HDD does not become READY*/ • SS_BAD_LABEL:/* (-4)Wrong partition type*/ • SS_READ_ERROR:/* (-5)Error occurred while reading or checking the label*/ • SS_WRITE_ERROR:/* (-6)Error occurred while writing or checking the label*/ • SS_FS_ERROR:/* (-7)Failed to repair the filesystem*/ • SS_MOUNT_ERROR:/* (-8)Failed to mount the filesystem*/ • SS_COMMAND_ERROR:/* (-9)Drive not responding to command*/ • SS_KERNEL_ERROR:/* (-10)Internal kernel error*/ • SS_SIZE_ERROR:/* (-11)Drive size too small*/ • SS_NO_PARTITION:/* (-12)The specified partition does not exist*/ • SS_NO_FILE:/* (-13)Device file does not exist*/ <p>Attempted to acquire HDD status through the driver but there has been no response for 30 seconds or more.</p>	

		<ul style="list-style-type: none"> • Unformatted HDD • Label data corrupted • HDD defective
		Format the HDD through SP mode.

SC862-00	D	Number of bad sectors exceeded maximum	CTL
		The number of bad sections in the area on the disk where images are stored exceeded 100.	
		The number of bad sectors reached 101 during image read operation.	
		<ul style="list-style-type: none"> • Up to 100 bad sectors are allowed where images are stored. 	
		<ul style="list-style-type: none"> • Format HDD with SP4911-002 • If the problem persists, replace HDD. 	

SC863-00	D	HDD data read failure 1	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in an area that does not belong to a partition, such as the disk label area.)	
		If one or more of the following problems persist, the HDD may be defective: <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-01	D	HDD data read failure 2	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in an area that does not belong to a partition, such as the disklabel area.)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-02	D	HDD data read failure 3	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "a".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-03	D	HDD data read failure 4	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "b".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-04	D	HDD data read failure 5	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "c".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-05	D	HDD data read failure 6	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "d".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-06	D	HDD data read failure 7	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "e".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-07	D	HDD data read failure 8	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "f".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

7

SC863-08	D	HDD data read failure 9	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "g".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-09	D	HDD data read failure 10	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "h".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-10	D	HDD data read failure 11	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "i".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-11	D	HDD data read failure 12	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "j".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-12	D	HDD data read failure 13	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "k".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-13	D	HDD data read failure 14	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "l".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-14	D	HDD data read failure 15	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "m".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-15	D	HDD data read failure 16	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "n".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-16	D	HDD data read failure 17	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "o".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-17	D	HDD data read failure 18	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "p".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-18	D	HDD data read failure 19	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "q".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-19	D	HDD data read failure 20	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "r.")	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-20	D	HDD data read failure 21	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "r.")	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-21	D	HDD data read failure 22	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "t")	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-22	D	HDD data read failure 23	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "u".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC863-23	D	HDD data read failure 24	CTL
		The data written to the HDD cannot be read normally.	
		Bad sectors were generated during operation. (An error occurred in partition "y".)	
		<p>If one or more of the following problems persist, the HDD may be defective:</p> <ul style="list-style-type: none"> • This SC code has occurred ten times or more at short intervals. • This SC occurred repeatedly at the same time (power-on, etc.). • Startup takes too long (20 sec. or longer) when the main power is turned on. Normal HDD access time after main power on is about 5 seconds. • HDD-related SCs such as SC860* and SC863*. Print and check the SC logs. 	
		<ul style="list-style-type: none"> • Replace the HDD 	

SC864-01	D	HDD data CRC error 1	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in an area that does not belong to a partition, such as the disk label area.)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	

SC864-02	D	HDD data CRC error 2	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "a".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	

SC864-03	D	HDD data CRC error 3	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "b".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC864-04	D	HDD data CRC error 4	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "c".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC864-05	D	HDD data CRC error 5	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "d".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC864-06	D	HDD data CRC error 6	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "e".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	

SC864-07	D	HDD data CRC error 7	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "f".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC864-08	D	HDD data CRC error 8	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "g".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC864-09	D	HDD data CRC error 9	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "h".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC864-10	D	HDD data CRC error 10	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "i".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	

SC864-11	D	HDD data CRC error 11	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "j".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC864-12	D	HDD data CRC error 12	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "k".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC864-13	D	HDD data CRC error 13	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "l".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC864-14	D	HDD data CRC error 14	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "m".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	

SC864-15	D	HDD data CRC error 15	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "n".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC864-16	D	HDD data CRC error 16	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "o".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC864-17	D	HDD data CRC error 17	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "p".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC864-18	D	HDD data CRC error 18	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "q".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	

SC864-19	D	HDD data CRC error 19	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "r".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC864-20	D	HDD data CRC error 20	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "s".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC864-21	D	HDD data CRC error 21	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "t".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC864-22	D	HDD data CRC error 22	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "u".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	

SC864-23	D	HDD data CRC error 23	CTL
		During HDD operation, the HDD returned a CRC error.	
		Bad sectors were generated during operation. (An error occurred in partition "v".)	
		<ul style="list-style-type: none"> • Format the HDD. • Replace the HDD. 	
SC865-00	D	HDD access error 1	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error).	
		Replace the HDD.	
SC865-01	D	HDD access error 2	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in an area that does not belong to a partition, such as the disklabel area.)	
		Replace the HDD.	
SC865-02	D	HDD access error 3	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "a".)	
		Replace the HDD.	

SC865-03	D	HDD access error 4	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "b".)	
		Replace the HDD.	
SC865-03	D	HDD access error 5	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "c".)	
		Replace the HDD.	
SC865-05	D	HDD access error 6	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "d".)	
		Replace the HDD.	
SC865-06	D	HDD access error 7	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "e".)	
		Replace the HDD.	

SC865-07	D	HDD access error 8	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "f".)	
		Replace the HDD.	

SC865-08	D	HDD access error 9	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "g".)	
		Replace the HDD.	

SC865-09	D	HDD access error 10	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "h".)	
		Replace the HDD.	

SC865-10	D	HDD access error 11	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "i".)	
		Replace the HDD.	

SC865-11	D	HDD access error 12	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "j".)	
		Replace the HDD.	
SC865-12	D	HDD access error 13	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "k".)	
		Replace the HDD.	
SC865-13	D	HDD access error 14	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "l".)	
		Replace the HDD.	
SC865-14	D	HDD access error 15	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "m".)	
		Replace the HDD.	

SC865-15	D	HDD access error 16	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "n".)	
		Replace the HDD.	

SC865-16	D	HDD access error 17	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "o".)	
		Replace the HDD.	

SC865-17	D	HDD access error 18	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "p".)	
		Replace the HDD.	

SC865-18	D	HDD access error 19	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "q".)	
		Replace the HDD.	

SC865-19	D	HDD access error 20	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "r".)	
		Replace the HDD.	
SC865-20	D	HDD access error 21	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "s".)	
		Replace the HDD.	
SC865-21	D	HDD access error 22	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "t".)	
		Replace the HDD.	
SC865-22	D	HDD access error 23	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "u".)	
		Replace the HDD.	

SC865-23	D	HDD access error 24	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "v".)	
		Replace the HDD.	

SC865-50	D	HDD access time-out error 1	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine.	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	

SC865-51	D	HDD access time-out error 1	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine.	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	

SC865-52	D	HDD access time-out error 2	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "a".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	

SC865-53	D	HDD access time-out error 3	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "b".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	
SC865-54	D	HDD access time-out error 4	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "c".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	
SC865-55	D	HDD access time-out error 5	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "d".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	

SC865-56	D	HDD access time-out error 6	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "e".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	

SC865-57	D	HDD access time-out error 7	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "f".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	

SC865-58	D	HDD access time-out error 8	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "g".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	

SC865-59	D	HDD access time-out error 9	CTL
		During HDD operation, the HDD returned an error.	
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "h".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	
SC865-60	D	HDD access time-out error 10	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "i".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	
SC865-61	D	HDD access time-out error 11	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "j".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	

SC865-62	D	HDD access time-out error 12	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "k".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	

SC865-63	D	HDD access time-out error 13	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "l".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	

SC865-64	D	HDD access time-out error 14	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "m".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	

SC865-65	D	HDD access time-out error 15	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "n".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	
SC865-66	D	HDD access time-out error 16	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "o".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	
SC865-67	D	HDD access time-out error 17	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "p".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	

SC865-68	D	HDD access time-out error 18	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "q".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	

SC865-69	D	HDD access time-out error 19	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "r".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	

SC865-70	D	HDD access time-out error 20	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "s".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	

SC865-71	D	HDD access time-out error 21	CTL
		During HDD operation, the HDD returned an error.	
		The HDD returned an error that does not constitute SC863 (bad sector) or SC864 (CRC error). (An error occurred in partition "r".)	
		Replace the HDD.	
SC865-72	D	HDD access time-out error 22	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "u".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	
SC865-73	D	HDD access time-out error 23	CTL
		During HDD operation, the machine did not detect a reply from the HDD (timeout).	
		The HDD did not respond to a read/write command from the machine in sector "v".	
		<ul style="list-style-type: none"> • Check harness connections between the controller board and the HDD. • Replace the HDD. 	
SC866-00	B	SD card authentication error	CTL
		A license error of an application that is started from the SD card was detected.	
		Invalid program data is stored on the SD card.	
		Store a valid program data on the SD card.	

SC867-00	D	SD card removed 1	CTL
		The SD card that starts an application was removed from the slot.	
		The SD card that starts an application was removed from the slot (mount point of /mnt/sd0).	
		Cycle the machine off/on.	
SC867-01	D	SD card removed 2	CTL
		The SD card that starts an application was removed from the slot.	
		The SD card that starts an application was removed from the slot (mount point of /mnt/sd1).	
		Cycle the machine off/on.	
SC867-02	D	SD card removed 3	CTL
		The SD card that starts an application was removed from the slot.	
		The SD card that starts an application was removed from the slot (mount point of /mnt/sd2).	
		Cycle the machine off/on.	
SC868-00	D	SD card access error 1	CTL
		The SD controller returned an error during operation. (Error occurred at the mount point of /mnt/sd0)	
		<ul style="list-style-type: none"> • SD card defective • SD controller defective 	
		<ul style="list-style-type: none"> • Reformat the SD card (using the "SD Formatter" made by Panasonic).* • Check the SD card insertion status. • Replace the SD card. • Replace the controller board. 	

* Do not format an SD card supplied with the main machine or sold as an option. You may only format SD cards used for Firmware Update by a Customer Engineer.

SC868-01	D	SD card access error 2	CTL
		<p>The SD controller returned an error during operation. (Error occurred at the mount point of /mnt/sd1)</p>	
		<ul style="list-style-type: none"> • SD card defective • SD controller defective 	
		<p>SD card that starts an application</p> <ul style="list-style-type: none"> • Turn the main power off and check the SD card insertion status. <ul style="list-style-type: none"> • If no problem is found, insert the SD card and turn the main power on. • If an error occurs, replace the SD card. • SD card for users <ul style="list-style-type: none"> • In case of a file system error, reformat the SD card (using the "SD Formatter" made by Panasonic).* • In case of a device access error, turn the main power off and check the SD card insertion status. • If no problem is found, insert the SD card and turn the main power on. • If an error occurs, use another SD card. 	

* Do not format an SD card supplied with the main machine or sold as an option. You may only format SD cards used for Firmware Update by a Customer Engineer.

SC868-02	D	SD card access error 3	CTL
		The SD controller returned an error during operation. (Error occurred at the mount point of /mnt/sd1)	
		<ul style="list-style-type: none"> • SD card defective • SD controller defective 	
		<p>SD card that starts an application</p> <p>Turn the main power off and check the SD card insertion status.</p> <ul style="list-style-type: none"> • If no problem is found, insert the SD card and turn the main power on. • If an error occurs, replace the SD card. <p>SD card for users</p> <ul style="list-style-type: none"> • In case of a file system error, reformat the SD card (using the "SD Formatter" made by Panasonic).* • In case of a device access error, turn the main power off and check the SD card insertion status. • If no problem is found, insert the SD card and turn the main power on. • If an error occurs, use another SD card. 	

* Do not format an SD card supplied with the main machine or sold as an option. You may only format SD cards used for Firmware Update by a Customer Engineer.

SC869-01	C	Human detection (proximity) sensor error 1	CTL
		The sensor detected a presence near the machine for longer than 24 hours.	
		Due to malfunction, the sensor remained on for longer than 24 hours. This SC code has no effect on printing or other operation of the machine. Once this SC appears, the sensor no longer functions.	
		<ul style="list-style-type: none"> • Replace the sensor unit 	

SC869-01	C	Human detection (proximity) sensor error 2	CTL
		<p>The sensor remains off after 20 of the following actions:</p> <ul style="list-style-type: none"> • Touching the Energy Save key • Opening/closing the ADF • Setting an original • Opening/closing the front door • Opening/closing a paper tray 	
		<p>One or more of the above actions normally triggers the machine to leave low energy mode and return to full operation, but the sensor remained to detect the presence of the operator. This SC code has no effect on printing or other operation of the machine. Once this SC appears, the sensor no longer functions.</p>	
		<ul style="list-style-type: none"> • Replace the sensor unit 	

SC870-00	B	Address Book data error (Anytime: Address Book Error.)
SC870-01	B	Address Book data error (On startup: Media required for storing the Address Book is missing.)
SC870-02	B	Address Book data error (On startup: encryption is configured but the module required for encryption (DESS) is missing.)
SC870-03	B	Address Book data error (Initialization: Failed to generate a file to store internal Address Book.)
SC870-04	B	Address Book data error (Initialization: Failed to generate a file to store delivery sender.)
SC870-05	B	Address Book data error (Initialization: Failed to generate a file to store delivery destination.)
SC870-06	B	Address Book data error (Initialization: Failed to generate a file to store information required for LDAP search.)
SC870-07	B	Address Book data error (Initialization: Failed to initialize entries required for machine operation.)
SC870-08	B	Address Book data error (Machine configuration: HDD is present but the space for storing the Address Book is unusable.)

SC870-10	B	Address Book data error (Machine configuration: Cannot make a directory for storing the Address Book in the SD/USB FlashROM.)
SC870-11	B	Address Book data error (On startup: Inconsistency in Address Book entry number.)
SC870-20	B	Address Book data error (File I/O: Failed to initialize file.)
SC870-21	B	Address Book data error (File I/O: Failed to generate file.)
SC870-22	B	Address Book data error (File I/O: Failed to open file.)
SC870-23	B	Address Book data error (File I/O: Failed to write to file.)
SC870-24	B	Address Book data error (File I/O: Failed to read file.)
SC870-25	B	Address Book data error (File I/O: Failed to check file size.)
SC870-26	B	Address Book data error (File I/O: Failed to delete data.)
SC870-27	B	Address Book data error (File I/O: Failed to add data.)
SC870-30	B	Address Book data error (Search: Failed to obtain data from cache when searching in the machine Address Book. delivery destination/sender.)
SC870-31	B	Address Book data error (Search: Failed to obtain data from cache during LDAP search.)
SC870-32	B	Address Book data error (Search: Failed to obtain data from cache while searching the WS-Scanner Address Book.)
SC870-41	B	Address Book data error (Cache: failed to obtain data from cache.)
SC870-50	B	Address Book data error (On startup: Detected abnormality of the Address Book encryption status.)
SC870-51	B	Address Book data error (Encryption settings: Failed to create directory required for conversion between plaintext and encrypted text.)
SC870-52	B	Address Book data error (Encryption settings: Failed to convert from plaintext to encrypted text.)
SC870-53	B	Address Book data error (Encryption settings: Failed to convert from encrypted text to plaintext.)
SC870-54	B	Address Book data error (Encryption settings: Detected data inconsistency when reading the encrypted Address Book.)

SC870-55	B	Address Book data error (Encryption settings: Failed to delete file when changing encryption setting.)
SC870-56	B	Address Book data error (Encryption settings: Failed to erase the file that records the encryption key during an attempt to change the encryption setting.)
SC870-57	B	Address Book data error (Encryption settings: Failed to move a file during an attempt to change the encryption setting.)
SC870-58	B	Address Book data error (Encryption settings: Failed to delete a directory during an attempt to change the encryption setting.)
SC870-59	B	Address Book data error (Encryption settings: Detected a resource shortage during an attempt to change the encryption setting.)

SC872-00	B	HDD mail reception error 1	CTL
		An error was detected on the HDD immediately after the machine was turned on.	
		<ul style="list-style-type: none"> • HDD defective • Power was turned of while the machine used the HDD. 	
		<ul style="list-style-type: none"> • Format the HDD (SP5-832-007). • Replace the HDD. <p>When you do the above, the following information will be initialized.</p> <ul style="list-style-type: none"> • Partly received partial mail messages. • Already-read statuses of POP3-received messages (All messages on the mail server are handled as new messages). 	

SC873-00	B	HDD mail reception error 2	CTL
		An error was detected on the HDD immediately after the machine was turned on.	
		<ul style="list-style-type: none"> • HDD defective • Power was turned of while the machine used the HDD. 	
		<ul style="list-style-type: none"> • Format the HDD (SP5-832-007). • Replace the HDD. <p>When you do the above, the following information will be initialized.</p> <ul style="list-style-type: none"> • Default sender name/password (SMB/FTP/NCP) • Administrator mail address • Scanner delivery history 	

SC874-05	D	All delete - Read error
SC874-06	D	All delete - Write error
SC874-09	D	All delete - No response from drive to command
SC874-10	D	All delete - Kernel internal error
SC874-12	D	All delete - Specified partition does not exist
SC874-13	D	All delete - No device file
SC874-14	D	All delete - Error in startup option
SC874-15	D	All delete - No number for specified sector
SC874-16	D	All delete - Execution of "hdderase" failed
SC874-41	D	All delete - Other fatal error
SC874-42	D	All delete - Halt command ended operation
SC874-61	D	All delete - Failed library recovery: hde_can_use()
SC874-62	D	All delete - Failed library recovery: hde_start()
SC874-63	D	All delete - Failed library recovery: hde_end()
SC874-64	D	All delete - Failed library recovery: hde_abort()
SC874-65	D	All delete - Failed library recovery: hde_get_stat()

SC874-66	D	All delete - Cannot use
SC874-67	D	All delete - Delete end unfinished
SC874-68	D	All delete - HDD format failure (normal)
SC874-69	D	All delete - HDD format failure (abnormal)
SC874-70	D	All delete - Library illegal recovery
SC874-99	D	All delete - Unexpected error
		An error was detected during HDD or NVRAM all delete operation after the option was executed.
		<ul style="list-style-type: none"> • There was an error in the HDD delete program, or the NVRAM all delete program. An alert is not issued for the SC error by @Remote and is not displayed with network devices.
		<ul style="list-style-type: none"> • Cycle the machine off/on • Reset the option SD card. • Execute HDD All Delete again.

SC875-01	D	Delete all error on HDD (hddchack -i error)	CTL
SC875-02	D	Delete all error (HDD erasure) (Data deletion failure)	
		An error was detected before HDD/data erasure starts. (Failed to erase data/failed to logically format HDD)	
		<ul style="list-style-type: none"> • HDD logical formatting failed. • The modules failed to erase data. 	
		Cycle the machine off/on.	

SC877-00	B	Data Overwrite Security card error	CTL
		The "Auto Erase Memory" function of the Data Overwrite Security is set to on but it cannot be done.	
		<ul style="list-style-type: none"> Data Overwrite Security option SD card is broken. Data Overwrite Security option SD card has been removed. 	
		<ul style="list-style-type: none"> If the SD card is broken, prepare a new Data Overwrite Security option SD card and replace the NVRAM. If the SD card has been removed, turn the main power off and reinstall a working Data Overwrite Security option SD card. 	
SC878-00	D	TPM electronic authentication error	CTL
		The machine failed TPM electronic authentication. System hash registered in the TPM did not match the data on the USB flash.	
		<ul style="list-style-type: none"> System module was updated in an unauthorized manner. USB flash is not working correctly. 	
		<ul style="list-style-type: none"> Replace controller board. 	
SC878-01	D	USB Flash error	CTL
		USB Flash file system error	
		USB Flash file system has been destroyed.	
		<ul style="list-style-type: none"> Replace controller board. 	
SC878-02	D	TPM error	CTL
		Error occurred in the TPM or TPM driver.	
		TPM defective	
		<ul style="list-style-type: none"> Replace controller board. 	

SC878-03	D	TCSD error	CTL
		Error occurred in TPM software stack.	
		<ul style="list-style-type: none"> • Unable to start TPM • Necessary files missing from the TPM. 	
		<ul style="list-style-type: none"> • Replace controller board. 	

SC878-20	D	Random number test error	CTL
		An error was detected when a random number table was generated during a self-test. The random number table is generated by TPM (Trusted Platform Module). The table generated by TPM failed the test.	
		<p>Note: TPM (Trusted Platform Module) is a computer chip that can securely store information used to authenticate the platform. This information can include passwords, certificates, and encryption keys.</p>	
		TPM is defective	
		<ul style="list-style-type: none"> • Cycle the machine off/on. • Replace the controller board. 	

SC878-21	D	DESS self-test error	CTL
		The power-on self-test for TPM failed at startup when the controller encryption software was tested, due to random number test failure (SC878-20) or other problem.	
		TPM firmware or CPU is defective.	
		<p>Note: TPM (Trusted Platform Module) is a computer chip that can securely store information used to authenticate the platform. This information can include passwords, certificates, and encryption keys.</p>	
		<ul style="list-style-type: none"> • Cycle the machine on. • If the problem persists, replace the controller board. 	

SC880-00	D	MLB error	CTL
		Reply to MLB access was not returned within a specified time. The MLB (Media Link Board) is the File Format Converter.	
		MLB defective	
		<ul style="list-style-type: none"> • Replace the MLB. • Remove the MLB. 	

SC899-00	D	Software error: Signal reception end	CTL
		Occurs when an internal program behaves abnormally.	
		In case of a hardware defect <ul style="list-style-type: none"> • Replace the hardware. 	
		In case of a software error <ul style="list-style-type: none"> • Cycle the machine off/on. • Try updating the firmware. 	

SC900: Miscellaneous

SC900

RTB 31: SC codes added

SC990-00	D	Software operation error	CTL
		Software attempted an unexpected operation.	
		<ul style="list-style-type: none"> Parameter error Internal parameter error Insufficient work memory Operation error caused by abnormalities that are normally undetectable. 	
		<ul style="list-style-type: none"> Cycle the machine off/on. Reinstall the software of the controller and BICU board. 	
SC991-00	C	Recoverable software operation error	CTL
		Software attempted an unexpected operation. SC991 covers recoverable errors as opposed to CS990.	
		<ul style="list-style-type: none"> Parameter error Internal parameter error Insufficient work memory Operation error caused by abnormalities that are normally undetectable. 	
		<ul style="list-style-type: none"> Logging only 	
SC992-00	D	Undefined SC issued.	CTL
		An error not controlled by the system, occurred.	
		<ul style="list-style-type: none"> An SC for the previous model was used mistakenly, etc. Basically a software bug. 	
		<ul style="list-style-type: none"> Cycle the machine off/on. 	

SC997-00	D	Application function selection error	CTL
		The application selected by the operation panel key operated abnormally (No response, abnormal ending).	
		<ul style="list-style-type: none"> • Software bug (mainly the application) 	
		<ul style="list-style-type: none"> • Check the optional RAM, DIMM, boards required by the application program. • Check if the combination of downloaded programs are correct. 	
SC998-00	D	Application start error	CTL
		<ul style="list-style-type: none"> • No application was registered to system within a specified time after the main power was turned on. (No application starts/All applications have been terminated abnormally) • Application started but cannot be drawn now for some reason. 	
		<ul style="list-style-type: none"> • Software bug (mainly the application) • The optional RAM, DIMM, boards required by the application program. Are not installed correctly. 	
		<ul style="list-style-type: none"> • Cycle the machine off/on. • Check the optional RAM, DIMM, boards • Check the combination of programs • Replace the controller board. 	

SC540 to SC545

Before You Begin

This section is a summary of some of the most common fusing unit SC codes that require your attention.

- These are fatal fusing unit errors. Once one of these SC codes appears, the machine cannot be used until the service technician releases it for servicing with **SP5810**, solves the problem, and then cycles the machine off/on.
- There are three machines in this series (D223, D224, and D225). Make sure all replacement parts are the correct ones for the machine you are servicing.

⚠ CAUTION

- To prevent a fire, never attempt to reset a blown thermostat by manipulating the exposed edges of the black cover with a screwdriver, or by hitting it on a table.
- A thermostat that has been reset manually could fail and cause a fire.
- Always replace a blown thermostat with a new one.



d223c3745

SC540 Fusing web motor error


Please follow the steps in order as presented below.

① Confirm failure to feed

1. Cycle the machine off/on.
2. Paper fails to feed continuously for 1 min., and SC error recurs?

3. If the SC error does not recur > End.
4. If the SC error recurs, go to ②.


② Web drive gears



d223c4008

1. Check the web drive gears [1] for paper scraps, paper dust, or any other stray materials jammed into the gears.
2. Remove any foreign material.
3. Any gears damaged or broken? > Replace the web unit.
4. Cycle the machine off/on.
5. Determine if paper feed has resumed, and then see if the SC error recurs.
6. If the SC error does not recur > End.
7. If the SC error recurs, go to ③.


③ Web motor



d223c4009

1. Replace web motor [1].
2. Cycle the machine off/on.
3. Determine if paper feed has resumed, and then see if the SC error recurs.
4. If the SC error does not recur > End.
5. If the SC error recurs, go to ④.

④ IOB connections



d223c4007


7

1. Reset the connection of the harness at CN252, cycle the machine off/on, and then see if the SC error recurs.
2. If the SC error does not recur > End.
3. If the SC error recurs, go to ⑤.

⑤ IOB

1. Replace IOB, cycle the machine off/on, and then see if the SC code recurs.
2. If the SC error does not recur > End.
3. If the SC error recurs, go to ⑥.

⑥ Web motor harnesses



d223c4010

1. Check the harnesses between the web motor and the paper exit drawer connectors.
2. Check the harness insulation for signs of damage.
3. Before you replace a harness, confirm that the replacement is the correct type for the machine. The harnesses are slightly different for the D223, D224, D225.
4. Cycle the machine off/on, and then see if the SC code recurs.
5. If the SC error does not recur > End.
6. If the SC error recurs, go to ⑦.

⑦ Paper exit unit harnesses

1. Check the harnesses between the paper exit unit drawer connector and the IOB for disconnections or damaged insulation
2. Replace damaged harnesses.
3. Before you replace a harness, confirm that the replacement is the correct type for the machine. The harnesses are slightly different for the D223, D224, D225.
4. Cycle the machine off/on, and then see if the SC error recurs.
5. If the SC error does not recur > End.

SC542 Fusing warm-up error 1: Center thermistor

Please follow the steps in order as presented below.

① Error duplication


For your safety and to prevent damage to the machine, once the SC occurs start to troubleshoot the problem immediately with the power supply check below (do not attempt to duplicate the error).

Go to ②.

② Power supply voltage level

1. Do SP1913-002 and check the displayed value to determine if it deviates from the voltage rated for the machine.
2. If the voltage is lower than rated voltage, investigate the power supply at the client work site.
3. If the power supply is not higher than the rated voltage > Got to ③

③ Center NC sensor position




d223c4001

1. Make sure that the center NC sensor [1] is installed correctly, and that the area around the sensor is free of paper dust and other material.
2. If the NC sensor is not aligned correctly, re-install it at the correct position.
3. Clean the sensor and the area around the sensor.
4. Next, cycle the machine off/on to see if the SC error recurs.
5. If the SC error does not recur > End.

6. If the SC error recurs, go to ④.


④ Thermostats



d223c4002

1. Check the condition of the thermostats.
2. Surface of a thermostat is blackened and bowed outward, or has pushed in? These are signs that the thermostat is blown and cannot conduct current.
3. Replace the thermostat.
4. Next, cycle the machine off/on to see if the SC error recurs.
5. If the SC error does not recur > End.
6. If the SC error recurs, go to ⑤.


⑤ Fusing lamp connections



d223c4003

1. Inspect the fusing lamp connections at the front [1] and rear [2] of the fusing unit and make sure that they are set correctly.
2. Harness disconnected, or only half connected? Re-connect the loose harness.
3. Next, cycle the machine off/on to see if the SC error recurs.
4. If the SC error does not recur > End.
5. If the SC error recurs, go to ⑥.

⑥ Fusing lamp filaments



d223c4004

1. Remove the lamps [1] and inspect each fusing lamp for broken filaments inside the lamp.
2. Any filaments broken? Replace the fusing lamp.
3. Next, cycle the machine off/on to see if the SC error recurs.
4. If the SC error does not recur > End.
5. If the SC error recurs, go to ⑦.

⑦ AC control board connections




d223c4005

1. Reset the connections of the harnesses at CN983, CN985, CN994.
2. Cycle the machine off/on to see if the SC error recurs.
3. If the SC error does not recur > End.
4. If the SC error recurs, go to ⑧.

⑧ AC control board

1. Replace AC control board.
2. Cycle the machine off/on, and then see if the SC code recurs.
3. If the SC error does not recur > End.
4. If the SC error recurs, go to ⑨.

⑨ IOB connections



d223c4006

1. Reset the connections of the harnesses at CN270, CN281.
2. Cycle the machine off/on, and then see if the SC error recurs.
3. If the SC error does not recur > End.
4. If the SC error recurs, go to ⑩.

7

⑩ IOB

1. Replace IOB, cycle the machine off/on, and then see if the SC code recurs.
2. If the SC error does not recur > End.
3. If the SC error recurs, go to ⑪.

⑪ Harnesses

Harnesses in poor condition (broken or insulation damaged and causing short circuits).

1. Check the harnesses between the fusing unit and AC control board and IOB, and replace them if you see any damage.
2. Make sure that the harnesses are correct for the machine. For example, the harnesses for the D223 are not the same as those for the D225.
3. After replacing the harnesses, cycle the machine off to see if the error recurs.
4. If the SC error does not recur > End.

SC543 Fusing lamp overheat error 1 (software)


Please follow the steps in order as presented below.

① Error duplication

For your safety and to prevent damage to the machine, once the SC occurs start to troubleshoot the problem immediately (do not attempt to duplicate the error).

Go to ②.

② End thermistor alignment



d223c4011

1. Check the area between the end thermistor [1] and the hot roller for paper dust or other dirt.
2. Area around the thermistor dirty? > Clean the thermistor and surrounding area.
3. Make sure that the thermistor is securely fastened and not floating free.
4. Cycle the machine off/on to see if the SC error recurs.
5. If the SC error does not recur > End.
6. If the SC error recurs, go to ③.

③ End thermistor damage



d223c4011

7

1. Check the end thermistor [1] for bending, warping, etc.
2. If the thermistor is bent out of alignment and not in contact with the roller, replace the thermistor.
3. Cycle the machine off/on, and then see if the SC error recurs.
4. If the SC error does not recur > End.
5. If the SC error recurs, go to ④.

④ AC control board connections




d223c4005

1. Reset the connections of the harnesses at CN983, CN985, CN994
2. Cycle the machine off/on to see if the SC error recurs.
3. If the SC error does not recur > End.
4. If the SC error recurs, go to ⑤.

⑤ AC control board

1. Replace AC control board.
2. Cycle the machine off/on, and then see if the SC code recurs.
3. If the SC error does not recur > End.
4. If the SC error recurs, go to ⑥.

⑥ IOB connection



d223c4006

1. Reset the connections of the harnesses at CN270, CN281.
2. Cycle the machine off/on, and then see if the SC error recurs.
3. If the SC error does not recur > End.
4. If the SC error recurs, go to ⑦.

7

⑦ IOB

1. Replace IOB, cycle the machine off/on, and then see if the SC code recurs.
2. If the SC error does not recur > End.
3. If the SC error recurs, go to ⑧.

⑧ Harnesses

1. Check the condition of the harnesses between the fusing unit and AC control board and IOB (broken wires, worn insulation can cause short circuits)
2. Replace the harnesses if you see any damage.
3. Make sure that the replacement harnesses are correct for the machine. For example, the harnesses for the D223 are not the same as those for the D225.
4. After replacing the harnesses, cycle the machine off to see if the error recurs.
5. If the SC error does not recur > End.

SC544 Fusing lamp overheat error 1: Hardware


Please follow the steps in order as presented below.

① Error duplication

For your safety and to prevent damage to the machine, once the SC occurs start to troubleshoot the problem immediately (do not attempt to duplicate the error).

Go to ②.

② End thermistor alignment



d223c4011

1. Check the area between the end thermistor [1] and the fusing roller for paper dust or other dirt.
2. Area around the thermistor dirty? > Clean the thermistor and surrounding area.
3. Make sure that the thermistor is securely fastened and not floating free.
4. Next, cycle the machine off/on to see if the SC error recurs.
5. If the SC error does not recur > End.
6. If the SC error recurs, go to ③.

③ End thermistor damage check

1. Check the end thermistor for bending, warping, etc.
2. If the thermistor is bent out of alignment and not in contact with the roller, replace the thermistor.
3. Cycle the machine off/on, and then see if the SC error recurs.
4. If the SC error does not recur > End.
5. If the SC error recurs, go to ④.

④ Center NC sensor position



d223c4001

1. In the center of the fusing unit, check the NC sensor [1] for misalignment.
2. If the NC sensor is not aligned correctly, re-install it at the correct position.
3. Cycle the machine off/on to see if the SC error recurs.
4. If the SC error does not recur > End.
5. If the SC error recurs, go to ⑤.

⑤ AC control board connections




d223c4005

1. Reset the connections of the harnesses at CN983, CN985, CN994.
2. Cycle the machine off/on to see if the SC error recurs.
3. If the SC error does not recur > End.
4. If the SC error recurs, go to ⑥.

⑥ AC control board

1. Replace AC control board, cycle the machine off/on, and then see if the SC code recurs.
2. If the SC error does not recur > End.
3. If the SC error recurs, go to ⑦.
4. IOB check

⑦ IOB Connections



d223c4006

1. Reset the connections of the harnesses at CN270, CN281.
2. Cycle the machine off/on, and then see if the SC error recurs.
3. If the SC error does not recur > End.
4. If the SC error recurs, go to ⑧.

7

⑧ IOB

1. Replace IOB.
2. Cycle the machine off/on, and then see if the SC code recurs.
3. If the SC error does not recur > End.
4. If the SC error recurs, go to ⑨.

⑨ Harnesses

1. Check the condition of the harnesses between the fusing unit and AC control board and IOB (broken wires, worn insulation can cause short circuits)
2. Replace the harnesses if you see any damage.
3. Make sure that the replacement harnesses are correct for the machine. For example, the harnesses for the D223 are not the same as those for the D225.
4. After replacing the harnesses, cycle the machine off to see if the error recurs.
5. If the SC error does not recur > End.

SC545 Fusing lamp overheat error 2: Center lamp

Please follow the steps in order as presented below.

① Duplication of the error


For your safety and to prevent damage to the machine, once the SC occurs start to troubleshoot the problem immediately with the power supply check below (do not attempt to duplicate the error).

Go top ②.

② Power supply voltage level

1. Do SP1913-002 and check the displayed value to determine if it deviates from the voltage rated for the machine.
2. If the voltage is lower than rated voltage, investigate the power supply at the client work site.
3. If the power supply is not higher than the rated voltage > Got to ③

③ Center NC sensor position




d223c4001

1. Make sure that the center NC sensor [1] is installed correctly, and that the area around the sensor is free of paper dust and other material.

2. If the NC sensor is not aligned correctly, re-install it at the correct position.
3. Clean the sensor and the area around the sensor.
4. Next, cycle the machine off/on to see if the SC error recurs.
5. If the SC error does not recur > End.
6. If the SC error recurs, go to ④.


④ Thermostats



d223c4002

1. Check the condition of the thermostats.
2. Surface of a thermostat is blackened and bowed outward, or has pushed in? These are signs that the thermostat is blown and cannot conduct current.
3. Replace the thermostat.
4. Next, cycle the machine off/on to see if the SC error recurs.
5. If the SC error does not recur > End.
6. If the SC error recurs, go to ⑤.

⑤ Fusing lamp connections




d223c4003

1. Inspect the fusing lamp connections at the front [1] and rear [2] of the fusing unit and make sure that they are set correctly.
2. Harness disconnected, or only half connected? > Re-connect the loose harness.
3. Cycle the machine off/on to see if the SC error recurs.
4. If the SC error does not recur > End.
5. If the SC error recurs, go to ⑥.

7

⑥ Fusing lamp filaments



d223c4004

1. Inspect each fusing lamp [1] for broken filaments inside the lamp.
2. Any filaments broken? Replace the fusing lamp.
3. Cycle the machine off/on to see if the SC error recurs.
4. If the SC error does not recur > End.
5. If the SC error recurs, go to ⑦.

⑦ AC control board connections




d223c4005

1. Reset the connections of the harnesses at CN983, CN985, CN994.
2. Cycle the machine off/on to see if the SC error recurs.
3. If the SC error does not recur > End.
4. If the SC error recurs, go to ⑧.

⑧ AC control board

1. Replace AC control board.
2. Cycle the machine off/on, and then see if the SC code recurs.
3. If the SC error does not recur > End.
4. If the SC error recurs, go to ⑨.

⑨ IOB connections



d223c4006

1. Reset the connections of the harnesses at CN270, CN281.
2. Cycle the machine off/on, and then see if the SC error recurs.
3. If the SC error does not recur > End.
4. If the SC error recurs, go to ⑩.

7

⑩ IOB

1. Replace IOB, cycle the machine off/on, and then see if the SC code recurs.
2. If the SC error does not recur > End.
3. If the SC error recurs, go to ⑪.


⑪ Harnesses

1. Check the condition of the harnesses between the fusing unit and AC control board and IOB (broken wires, worn insulation can cause short circuits)
2. Replace the harnesses if you see any damage.
3. Make sure that the replacement harnesses are correct for the machine. For example, the harnesses for the D223 are not the same as those for the D225.
4. After replacing the harnesses, cycle the machine off to see if the error recurs.
5. If the SC error does not recur > End.

Jam Detection

Paper Jam Code Display

A jam code letter and number indicates the location of the jam as shown below.



d223c6200

Jam Codes and Display Codes

Here are lists of SC codes that are printed in the SMC report; they do not appear on the operation panel display.

Main Unit and LCIT: Paper Jam Errors

No.	Location	Position Code
	Paper Late Jams	
003	1st Paper Feed SN: Late	A1
004	2nd Paper Feed SN: Late	A1

No.	Location	Position Code
005	3rd Paper Feed SN: Late	A1
006	4th Paper Feed SN: Late (Japan Only)	A1
007	LCT Feed SN: Late	U
008	1st Vertical Transport SN: Late	A1
009	2nd Vertical Transport SN: Late	A1
010	3rd Vertical Transport SN: Late	A1
011	4th Vertical Transport SN: Late	B
012	Relay SN: Late	B
013	Registration SN: Late	D
014	Fusing Exit SN: Late	D
015	Exit Unit Entrance SN: Late	E
016	Exit Unit Exit SN: Late	E
019	Duplex Entrance SN: Late	E
020	Duplex Transport SN 1: Late	E
021	Duplex Transport SN 2: Late	Z
022	Duplex Transport SN 3: Late	Z
023	Duplex Exit SN: Late	E
024	LCT Relay SN: Late	B/U
034	By-pass Paper Feed SN: Late	A2
045	Transport SN: Late/Lag	R
046	Shift Tray Lift Motor	R
047	Shift Tray Motor	R
	Paper Lag Jams	
053	1st Paper Feed SN: Lag	A1
054	2nd Paper Feed SN: Lag	A1

No.	Location	Position Code
055	3rd Paper Feed SN: Lag	A1
056	4th Paper Feed SN: Lag (Japan Only)	A1
057	LCT Feed SN: Lag	U
058	1st Vertical Transport SN: Lag	A1
059	2nd Vertical Transport SN: Lag	A1
060	3rd Vertical Transport SN: Lag	A1
061	4th Vertical Transport SN: Lag (Japan Only)	A1
062	Relay SN: Lag	B
063	Registration SN: Lag	B/C
066	Paper Exit SN: Lag	E
069	Duplex Entrance SN: Lag	E
071	Duplex Transport SN 2: Lag	Z
072	Duplex Transport SN 3: Lag	Z
074	LCT Relay SN: Lag	B/U

ADF: Paper Jam Errors

No.	Jam Location	Position Code
013	Separation SN: Late	P1
063	Separation SN: Lag	P1
014	Interval SN: Late	P1
064	Interval SN: Lag	P1
015	Scan Entrance SN: Late	P1
065	Scan Entrance SN: Lag	P1
016	Registration SN: Late	P2

No.	Jam Location	Position Code
066	Registration SN: Lag	P2
017	Exit SN: Late	P2
067	Exit SN: Lag	P2
239	Original Remove	P1
001	Initial Feed Jam	P1
001	Original Tray Overload	P1

Finisher SR4120 Paper Jam Errors

No.	Location	Code
101	Entrance SN: Late	R1 to 5
102	Entrance SN: Lag	R1 to 5
103	Horizontal Transport SN: Late	R1 to 5
104	Horizontal Transport SN: Lag	R1 to 5
105	Switchback Transport SN: Late	R1 to 5
106	Switchback Transport SN: Lag	R1 to 5
107	Proof Tray Exit SN: Late	R1 to 5
108	Proof Tray Exit SN: Lag	R1 to 5
109	Shift Tray Exit SN: Late	R1 to 5
110	Shift Tray Exit SN: Lag	R1 to 5
111	Entrance Motor Jam	R1 to 5
112	Horizontal Transport Motor Jam	R1 to 5
113	Pre-stack Transport Motor Jam	R1 to 5
114	Relay Transport Motor Jam	R1 to 5
115	Exit Motor Jam	R1 to 5

No.	Location	Code
116	Trailing Edge Press Motor Jam	R1 to 5
117	Paper Exit Guide Plate Jam	R1 to 5
118	Punch Motor Jam	R1 to 5
119	Punch Movement Motor Jam	R1 to 5
120	Paper Position Movement Motor Jam	R1 to 5
121	Lower Junction Gate Motor Jam	R1 to 5
122	Jogger Motor Jam	R1 to 5
123	Positioning Roller Drive Motor Jam	R1 to 5
124	Stack Feed-out Motor Jam	R1 to 5
125	Booklet Stapler Movement Motor Jam	R1 to 5
126	Booklet Stapler Motor Jam	R1 to 5
130	Tray Lift Motor Jam	R1 to 5
131	Shift Motor Jam	R1 to 5
132	Shift Jogger Front Motor	R1 to 5
133	Shift Jogger Rear Motor	R1 to 5
134	Shift Tray Jogger Retraction Motor Jam	R1 to 5
135	Drag Roller Motor Jam	R1 to 5
136	Leading Edge Guide Motor Jam	R1 to 5
140	Positioning Roller Driver Motor Jam	R1 to 5
141	Paper Guide Motor Jam	R1 to 5
149	Main Machine Command Error Jam	R1 to 5

Finisher SR4130 Paper Jam Errors

No.	Location	Code
151	Entrance SN: Late	R1 to 5
152	Entrance SN: Lag	R1 to 5
153	Horizontal Transport SN: Late	R1 to 5
154	Horizontal Transport SN: Lag	R1 to 5
155	Switchback Transport SN: Late	R1 to 5
156	Switchback Transport SN: Lag	R1 to 5
157	Proof Tray Exit SN: Late	R1 to 5
158	Proof Tray Exit SN: Lag	R1 to 5
159	Shift Tray Exit SN: Late	R1 to 5
160	Shift Tray Exit SN: Lag	R1 to 5
161	Booklet Exit SN: Late	R6 to 11
162	Booklet Exit SN: Lag	R6 to 11
163	Entrance Motor Jam	R1 to 5
164	Horizontal Transport Motor Jam	R1 to 5
165	Pre-stack Transport Motor Jam	R1 to 5
166	Relay Transport Motor Jam	R1 to 5
167	Exit Motor Jam	R1 to 5
168	Trailing Edge Press Motor Jam	R1 to 5
169	Paper Exit Guide Plate Jam	R1 to 5
170	Punch Motor Jam	R1 to 5
171	Punch Movement Motor Jam	R1 to 5
172	Paper Position Movement Motor Jam	R1 to 5
173	Lower Junction Gate Motor Jam	R1 to 5

No.	Location	Code
174	Jogger Motor Jam	R1 to 5
175	Positioning Roller Drive Motor Jam	R1 to 5
176	Stack Feed-out Motor Jam	R1 to 5
177	Booklet Stapler Movement Motor Jam	R1 to 5
178	Booklet Stapler Motor Jam	R1 to 5
179	Booklet Jogger Motor Jam	R6 to 11
180	Booklet Jogger Pawl Movement Motor Jam	R6 to 11
181	Booklet Bottom Fence Motor Jam	R6 to 11
182	Booklet Stapler Motor Jam	R6 to 11
183	Dynamic Roller Motor Jam	R6 to 11
184	Fold Transport Motor Jam	R6 to 11
185	Square Fold Motor Jam	R6 to 11
186	Tray Lift Motor Jam	R1 to 5
187	Shift Motor Jam	R1 to 5
188	Front Shift Jogger Motor Jam	R1 to 5
189	Rear Shift Jogger Motor Jam	R1 to 5
190	Shift Jogger Retraction Motor Jam	R1 to 5
191	Drag Roller Motor Jam	R1 to 5
192	Leading Edge Guide Motor Jam	R1 to 5
196	Position Roller Motor Jam	R1 to 5
197	Paper Guide Motor Jam	R1 to 5
199	Main Machine Command Error Jam	R1 to 5

Finisher SR4080 Paper Jam Errors

No.	Location	Code
201	Entrance Jam	R1 to 3
202	Proof Tray Exit Jam	R1 to 3
203	Shift Tray Exit Jam	R1 to 3
204	Stapled Stack Exit Jam	R4 to 7
205	Pre-Stack Unit Jam	R4 to 7
206	Stack Output Jam	R4 to 7
208	Transport Motor Jam	R1 to 3
209	Tray Lift Motor Jam	R1 to 3
210	Positioning Roller Motor Jam	R4 to 7
211	Jogger Motor Jam	R4 to 7
212	Press Plate Center Motor Jam	R4 to 7
213	Press Plate Front Motor Jam	R4 to 7
214	Press Plate Rear Motor Jam	R4 to 7
215	Shift Motor Jam	R1 to 3
216	Drag Drive Motor Jam	R1 to 3
217	Shift Jogger Motor Jam	R1 to 3
218	Shift Jogger Retraction Motor Jam	R1 to 3
219	Exit Motor Jam	R4 to 7
220	Stapler Motor Jam	Staples
221	Stapler Movement Motor Jam	R4 to 7
222	Stapler Lift Motor Jam	R4 to 7
223	Output Motor Jam	R4 to 7
224	Punch Motor Jam	R1 to 3

No.	Location	Code
225	Leading Edge Stop Motor Jam	R4 to 7
226	Bottom Fence Motor Jam	R4 to 7
247	Main Machine Command Error Jam	R1 to 3,R4 to 7

Mail Box CS4010 Paper Jam Errors

No.	Location	Code
251	Vertical Transport SN 1: Late	W
252	Vertical Transport SN 1: Lag	W
253	Vertical Transport SN 2: Late	W
254	Vertical Transport SN 2: Lag	W
255	Vertical Transport SN 3: Late	W
256	Vertical Transport SN 3: Lag	W
257	Vertical Transport SN 4: Late	W
258	Vertical Transport SN 4: Lag	W
259	Vertical Transport SN 5: Late	W
260	Vertical Transport SN 5: Lag	W
299	Main Machine Command Error Jam	W

Cover Interposer Tray CI4030/CI4040 Paper Jam Errors

No.	Location	Position Code
301	Paper Feed Sensor	Q
302	Vertical Transport Path	Q
303	Bottom Plate Position Sensor	Q

Multi Folding Unit FD4000 Paper Jam Errors

No.	Location	Position Code
401	Entrance SN: Late	N1 to N5
402	Entrance SN: Lag	N1 to N5
403	Top Tray Exit SN: Late	N1 to N5
404	Top Tray Exit SN: Lag	N1 to N5
405	Horizontal Path Exit SN: Late	N1 to N5
406	Horizontal Path Exit SN: Lag	N1 to N5
407	1st Stopper HP SN: Late	N6 to N22
408	1st Stopper HP SN: Lag	N6 to N22
409	2nd Stopper HP SN: Late	N6 to N22
410	2nd Stopper HP SN: Lag	N6 to N22
411	3rd Stopper HP SN: Late	N6 to N22
412	3rd Stopper HP SN: Lag	N6 to N22
413	Skew Correction Jam	N6 to N22
414	Folded Paper Path Jam	N1 to N5
417	Entrance JG Motor Jam	N1 to N5
418	1st Stopper Motor Jam	N6 to N22
419	2nd Stopper Motor Jam	N6 to N22
420	3rd Stopper Motor Jam	N6 to N22
421	Dynamic Roller Trans. Motor Jam	N6 to N22
422	Registration Roller Release Motor Jam	N6 to N22
423	Fold Plate Motor Jam	N6 to N22
424	Jogger Fence Motor Jam	N6 to N22
426	Direct-Send JG Motor Jam	N6 to N22

No.	Location	Position Code
427	FM6 Pawl Motor Jam	N6 to N22
449	Main Machine Set. Incorrect	N1 to N5, N6 to N22


Paper Size codes

The table below lists the paper size codes. Measurements in the right columns (Main Scan/Sub Scan Lengths) are 0.1 mm

Size Code	Paper Size	Orientation	Main Scan	Sub Scan
005(05H)	A4	LEF	2970	2100
006(06H)	A5	LEF	2100	1480
014(0EH)	B5	LEF	2570	1820
038(26H)	8 ¹ / ₂ ×11(LT)	LEF	2794	2159
044(2CH)	5 ¹ / ₂ ×8 ¹ / ₂ (HLT)	LEF	2159	1397
132(84H)	A3	SEF	2970	4200
133(85H)	A4	SEF	2100	2970
134(86H)	A5	SEF	1480	2100
141(8DH)	B4	SEF	2570	3640
142(8EH)	B5	SEF	1820	2570
160(A0H)	11×17(DLT)	SEF	2794	4318
164(A4H)	8 ¹ / ₂ ×14(LG)	SEF	2159	3556
166(A6H)	8 ¹ / ₂ ×11(LT)	SEF	2159	2794
172(ACH)	5 ¹ / ₂ ×8 ¹ / ₂ (HLT)	SEF	1397	2159
072(48H)	8.5"×13.4"(Oficio)	LEF	3404	2159
200(C8H)	8.5"×13.4"(Oficio)	SEF	2159	3404
255(FFH)	Other	-	-	-

Main Machine Sensor Locations

The illustration below shows the locations of the jam sensors in the main machine.



w_b246t901_eng

Frequent Paper Jams

If there are frequent paper jams, check SP7504 in "Service Tables". If these locations have frequent jams, do the procedures described below.

Symptom 1: Jams when paper is fed from a by-pass tray that is not used frequently

If the customer does not use the by-pass tray frequently, the rollers can become worn.


1. Visually check the by-pass tray pick-up, feed, and separation rollers.
2. If these rollers are paler than the rollers in paper trays that are more frequently used, replace the rollers in the by-pass tray.

Note

- For more details, see Replacement and Adjustment - By-Pass Tray Rollers.

Symptom 2: Jams with noise from the paper feed unit

1. Remove the paper feed unit.
2. Loosen screw [A].
3. Push the motor [B] toward the tray side, then tighten the screw [A].
4. Loosen screws [C] and [D], let the spring move the unit to the correct position, then tighten the screws.



B246T905

Symptom 3: Other


If none of the two symptoms 1 or 2 applies, do this procedure.

1. Use SP7504 to check the jam counts and find which SPs have high counts.
2. From the table and illustration below, find which gears must be replaced.
Example: For tray 1, if SP7504-012 is high, replace gear A, or if SP7504-008 is high, replace gear B.

Tray	SP7504 12	SP7504 8	SP7504 9	SP7504 10	SP7504 11
Tray 1	Gear [A]	Gear [B]			
Tray 2		Gear [A]	Gear [B]		

Tray	SP7504 12	SP7504 8	SP7504 9	SP7504 10	SP7504 11
Tray 3			Gear [A]	Gear [B]	
Tray 4				Gear [A]	Gear [B]

1. Clean the shafts and replace the necessary gears.
2. Replace a gear if its cutout and arrow are not in the same position.
3. When you replace Gear [A] or Gear [B], be sure to put the metal face on the outer side, and the arrow must be in view.




4. If a replacement gear is not available, do this as a temporary procedure:
 - Remove the paper feed unit.
 - Remove the gear.
 - Clean the gear shaft and inside the gear.
 - Attach the gear.
 - Install the paper feed unit.

Peripheral Units

Height and Level Adjustment

Before you begin:

- The main machine should be installed first and adjusted to level front-to-back, and side-to-side.
 - Note the settings on the leveling gauge. Due to the length of the paper path with several optional peripheral units installed, it is extremely important that every unit be leveled to match the front-to-back and side-to-side measurements of the main machine.
 - The height and level of each peripheral unit must be adjusted at installation.
 - The height and level of each unit must be adjusted before testing for the presence of skew and checking that side-to-side registration is correct.
 - If an accessory wrench is provided with the machine, use the large end [A] to adjust the front and rear feet of the main machine.
 - The small end of the wrench [B] is for the feet of the peripheral units.
1. If an accessory wrench is provided with the machine, use the large end [A] to adjust the front and rear feet of the main machine.
 2. The small end of the wrench [B] is for the feet of the peripheral units.



d1790999

Setting the Leveling Shoes

★ Important

- Do this procedure near each caster where an adjustable bolt is provided.

- The number of leveling shoes will differ, depending on which unit you are leveling.



d1795700

1. Turn the lower nut to lower the bolt.

Note


- The upper bolt is spot-welded to the frame and does not move.

2. Set a leveling shoe below the bolt.



d1795701

3. Continue to turn the lower nut until it stops against the shoe.
4. Set a level on the front, rear, and side edges to determine if the unit is level.
5. Adjust the height at each corner until the unit is level.



d223c5702

6. Check the results of the adjustments.

- The top of the first peripheral unit on the left must be at the same height as the left side of the main machine.
- The tops of the other peripheral units on the left where the units are joined must be at the same height.
- The top of the LCIT on the right must be at the same height as the right side of the main machine.



d1795703

- Make sure that the plate at the paper exit on the left side of the main machine [A] moves freely and is not bent. It must be able to move to handle thick paper.
- Between the right side of the main machine and the LCIT, make sure that the LCIT guide plate moves freely and does not interfere with the main machine guide plate.


Skew and Side-to-Side Registration

Overview

The paper feed path is long when more than one peripheral unit is installed. In a longer path, the cumulative effect of paper skew or deviation in side-to-side registration may require adjustment.


- Skew [A] occurs when the trailing edge of the paper rotates away from the direction of paper feed.

- If side-to-side registration shift [B] occurs, the sheet remains straight but shifts left or right away from center of the paper path.



↓ Note

- Before adjusting skew manually, be sure to enter the SP mode and set **SP1206** to "2" (OFF). This disables side-to-side registration in the main machine's registration unit.




Scales

- Skew and side-to-side registration can be checked with graduated scales where paper exits.
- The scales are provided so that you can visually check and measure the amount of skew or deviation in side-to-side registration.
- Correction for both skew and side-to-side registration are possible on peripheral units provided with the graduated scale.


Use either the rear scale or front scale, depending on the type of paper used in your area:

- Rear [A]: **DLT SEF**
- Front [B]: **A3 SEF**



d1795706

Here is a photo that shows the actual scales. It shows the scale on the left side of the Booklet Finisher Tray. [A] is for DLT, and [B] is for A3.



d1795707


Here are some general rules for testing and adjusting for paper skew or a shift in side-to-side registration.

1. After installation of each peripheral device, do some test prints and check for the presence of skew, and check that side-to-side registration is correct.
2. When you detect a problem with skew or side-to-side registration, do the adjustment on the joint bracket attached to the peripheral unit **upstream of the unit where the problem occurred**.
3. Side-to-side registration is corrected by shifting the upstream joint bracket left or right. (See the next procedure.)
4. Skew is eliminated by inserting shims under the rear or front end of the joint bracket. These are attached by screws to the peripheral units before they leave the factory.

Checking Side-to-Side Registration

Do this procedure to confirm that the paper is centered in the paper path.

1. Make sure that the I/F cable of the unit is connected to the upstream unit.
2. Disconnect the unit to the left of the unit to be tested.
3. Execute a run by feeding paper from Tray 2 of the host machine.
4. When each sheet exits, check the position of the paper on the scale to see if the paper is centered.
 - Read the **rear scale** for **DLT**-size paper.
 - Read the **front scale** for **A3**-size paper.
 - The scale graduations are at 2 mm apart.
5. The paper must not deviate more than ± 2 mm on the scale.



[A]	Leading/trailing edges centered. No adjustment necessary.
[B]	Leading/trailing edges offset to the rear by more than 2 mm. Adjustment required.
[C]	Leading/trailing edges offset to the front by more than 2 mm. Adjustment required.

If the edge of the paper is on the scale at the center [A], no adjustment is required.

-or-


If the edge of the paper is ± 2 mm off the center line on the scale, adjustment is required. Do the procedure in the next section.

Correcting Side-to-Side Registration

Each peripheral unit has a single-piece connection bracket. This adjustment can be done for every unit on the connection bracket attached to the upstream unit

1. Enter the SP mode and set SP1206 to "2" (OFF).
2. Disconnect the peripheral unit from the upstream unit.

3. On the joint bracket attached to the upstream unit, loosen screws [1], [2], [3], [4].
4. Remove bracket [A] (⌀ x1), rotate it 90 degrees, and then re-fasten the screw. Changing the position of this bracket aligns the oval cut-out horizontally and frees the joint bracket so it can slide from side to side.
5. Look at scale [B].
6. Slide the bracket to the left or right and tighten the screw.
7. If the deviation from center was toward the front, slide the bracket to the rear and tighten screw [1].
-or-
If the deviation from center was toward the rear, side the bracket to the front and tighten screw [1].
8. Tighten screws [2], [3], and [4].




9. Do another test run, so that you can check the results
10. When you are finished, enter the SP mode and re-set **SP1206** to "1".

Detecting Paper Skew

Do this check to detect the presence of skew.

1. Make sure that the I/F cable of the unit is connected to the upstream unit.
2. If a peripheral unit is connected on the left side, disconnect it and pull it away.

3. Execute a straight-through run.
4. Check the scale where each sheet exits.
 - The **rear scale** is for **DLT**-size paper.
 - The **front scale** [2] is for **A3**-size paper.
 - Be sure to read the correct scale for the paper size in use.



[A]	Centered. No adjustment necessary.
[B]	Trailing edge skew to the front, total skew more than ± 2 mm. Adjustment required.
[C]	Trailing edge skew to the rear, total skew more than ± 2 mm. Adjustment required.

Correcting Skew

1. Enter the SP mode and set SP1206 to "2" (OFF).
2. Disconnect the peripheral unit from the upstream unit.
3. Locate and remove the shims from the peripheral unit where the problem occurred.
4. If the peripheral unit is provided with shims, open the front door you will find them attached to the lower right corner. For example, here is the location for the shims attached to the Multi Fold Unit.




d1795712

5. Open the front door.
6. Remove the shims.

Inserting Shims

7



d1795714

1. Loosen the screws of the joint bracket attached to the peripheral upstream of the unit where the problem occurred.
2. Insert a shim and tighten the screws.
3. If the trailing edge of the paper is **skewing toward the front** of the machine, insert a shim [A] under the **rear end of the bracket** and tighten the screws.

-or-

If the trailing edge is **skewing toward the rear** of the machine, insert a shim [B] under the **front end of the bracket** and tighten the screws.


4. Do another run to check the adjustment. If skew is still present, insert another shim.
 - Each shim is 2 mm thick.
 - Only two shims are provided, so the maximum adjustment is 4 mm (using two shims).
5. Enter the SP mode and re-set SP1206 to "1".

Booklet Finisher Center Fold Correction

If the angle between the bottom fence and fold plate is not correct, this can cause the bottom of the fold line to slant out of alignment in the direction of paper feed or opposite the direction of paper feed.


Slant in the direction of paper feed

When sheets are center-folded, the fold line [B] can slant in the direction of paper feed, causing the front side [C] to be longer than the rear side [D] and cause misalignment [A].



Slant opposite the direction of paper feed

The fold line [B] can also slant opposite the direction of paper feed, causing the front side [C] to be shorter than the rear side [D] and cause misalignment [A].




These problems occur if the angle between the bottom fence [1] and fold plate [2] is not correct.



d224c0083


How to Correct Misaligned Center Folding

1. Pull out the jogger unit and loosen bottom fence lock screw.




d224c0084

2. Turn the bottom fence adjustment screw to adjust the angle between the bottom fence and the folding plate.
 - If the center line is slanting in the direction of paper feed, turn the bottom fence adjustment screw clockwise to raise the bottom fence.
 - If the center line is slanting away from the direction of paper feed, turn the bottom fence adjustment screw counter-clockwise to lower the bottom fence.



d224c0085


To adjust [a]:



d224c3010


Paper size	Clockwise	Counterclockwise
B5	0.56 mm	0.55 mm
A4	0.64 mm	0.64 mm
B4	0.79 mm	0.78 mm
A3	0.91 mm	0.90 mm

3. Tighten the bottom fence lock screw.



d224c0086

4. If the adjustment has caused the folding position to shift to left or right, make corrections with **SP6-113**.
5. For example, if there is a 3mm gap between the edges as shown below, shift the folding line "-1.5mm" in the (-) direction.



Finisher SR4080 (D610): Z-Folded Paper Output

1. Set the shift auxiliary tray on the shift tray when you expect folded paper from the Multi Folding unit to be output to the shift tray.




2. Set the proof auxiliary tray in the proof tray when you expect Z-folded paper from the Multi Folding unit to be output to the proof tray.



d610c1015

3. Peel the tape from the tray holder [A].
4. Attach the tray holder to the back of the finisher [B].




d610c1016

5. Store the auxiliary trays in the holder if they are not needed.

Finishers SR4120/SR4130 (D3CG/D3CH)

Using Auxiliary Trays


The trailing edges of excessively curled or Z-folded paper can activate the tray full sensors before the tray is actually full. Once this occurs and the "Exit Tray Full" message appears, the job stops and cannot continue until some sheets are removed from the tray which is only partially full. The auxiliary trays, number [1], [2], and [3] on their undersides are designed to prevent this problem.



d3cgc1005

Thin or soft paper does not exit completely

Set auxiliary Tray 1 on the proof tray when using thin or soft paper that may not exit completely and interfere with the tray full sensor.



d3cgc1199

7

Z-folded paper, Curled paper interfere with tray full sensor

Z-folded paper or paper with curled edges can interfere with the tray full sensor by signaling tray full before the tray is actually full.



d223c8210

Set auxiliary Tray 2 on the proof tray when Z-folding paper or excessively curled is output.




d3cgc1650

Problems with Z-folded paper from the Multi Folding Unit


Set auxiliary Tray 3 only when the Multi-Folding Unit is installed, especially when working with Z-folded paper.

1. The pegs [A] on the bottom of this tray fit into the holes in the shift tray [B].




d223c8207

2. When you set the tray, position feelers [1] and [2] on top of the tray.



d223c8208

3. Confirm that the tray is perfectly flat on the shift tray below. There should be no gap between the trays.




d223c8209

Output Jogger Units


Jogger Width Adjustment Procedure

If a paper alignment problem occurs as below, do the following procedure to adjust the jogger width.



d146z0091

1. Place an A4 original (SEF) on the exposure glass.
2. Select [Staple] on the operation panel (you can select any staple location: top or bottom.)
3. Press [Start].
4. A copy is put out on the staple tray, and is stopped with the jogger not holding the sheet.
5. Check the jogger operation visually in the previous step, and then check the position and distance of jogger width and sheet.



6. Press the [#] button.
7. Adjust the jogger width with **SP6143-004** (Range: -1.5 to +1.5 mm for each paper size).
8. Repeat step 3 through step 6 to complete the adjustment.
9. Adjust the jogger width to be slightly narrower (approximately -0.5 mm) than the paper width.

Other Problems


Common Problems

Problem	Check	Inspect, Clean, Replace
Dirty Copies	Fusing Unit	Pressure roller
Jam – Fusing Unit	Fusing Unit	Hot roller
Jam – Fusing Unit	Fusing Unit	Hot roller strippers
Jam – Original	ADF	Pick-up, paper feed, separation rollers
Lines (black or white)	Around the Drum	Cleaning blade, cleaning brush
Misfeed – Fusing Unit	Fusing Unit	Hot roller
Offset	Fusing Unit	Hot roller
Poor separation	Transfer Belt Unit	Transfer belt, transfer belt cleaning blade
SC300 ~ SC306	Around the Drum	Charge corona wire, charge corona grid, charge corona wire cleaner.
Skew – Original	ADF	Pick-up, paper feed, separation rollers
Toner on transfer belt	Transfer Belt Unit	Transfer belt, transfer belt cleaning blade
Wrinkling	Fusing Unit	Pressure roller


Checking Image Quality

Resolution

Standard	1:1/Enlargement:	4.5 lines/mm or more
	Reduction:	4.5 x M or more mag.
What You Need	S-2-1 Chart	


<p>Method</p>	 <p style="text-align: center;">d1791421</p> <p>Resolution measured after copying in Text Mode at AE5 notch with Normal Paper</p>
----------------------	--

Even Density

<p>Standard</p>	<p>Left, right grayscale within 0.1 at 0.2 to 0.6</p>	
<p>What You Need</p>	<p>S-2-1 Chart</p>	
<p>Method</p>	 <p style="text-align: center;">d1791422</p> <p>Right, left density measured after copying in Text Mode at AE5 notch with Normal Paper.</p>	

Magnification Errors


<p>Standards</p>	<p>1:1</p>	<p>Main scan: $<\pm 0.5\%$, Sub scan: $<\pm 0.8\%$</p>
	<p>Magnification</p>	<p>Main scan: $<\pm 1.0\%$, Sub scan: $<\pm 1.0\%$</p>
<p>What You Need</p>	<p>150 mm scale</p>	

<p>Method</p>	<div style="text-align: center;">  <p>d1791423</p> </div> <ol style="list-style-type: none"> 1. Set two scales on the exposure glass, and then copy them. 2. Wait at least 10 min. after the paper exits. 3. Measure 100 mm on the copied images with the actual scale.
----------------------	---

Magnification Error Variation

Standard	1:1/Mag.: Sub scan (horizontal, vertical) less than 1.0%
What You Need	150 mm scale

Method



d1791424

1. Place three 150 mm scales on the exposure glass, and then copy them.
2. Wait at least 3 min. after the paper exits.
3. Use a scale to measure 100 mm against each scale image (x1, x2, x3) on the paper.
4. Determine the maximum and minimum deviation (%) from the standard.
5. Calculate the difference between the maximum and minimum deviation.

Notes

- For example, if the three measurements of the scales are 100.4 mm, 99.5 mm, 100.2 mm, then the difference between the maximum and minimum values is 0.9 mm (100.4 – 99.5).
- Set the scales in the main scan direction (horizontal), copy them, and then use the same method to determine the variation
- For best results, using at least three scales is recommended.
- If you have only one scale, then you can make three copies with the scale at different positions.
- Please remember that line speed may vary slightly depending on the number of copies in a job.

Reinstalling OCR Unit Type M2

When the OCR unit is installed, its function is stored in the HDD, and its ID information in the SD card is stored in the NVRAM. So the OCR unit must be installed again when you replace the HDD and/or NVRAM.

If you have the original SD card and when you replaced:

- Only HDD
- Re-install the unit with the original SD card.
- Only NVRAM

- Re-install with the original SD card if you upload/download of the NVRAM data.
- Order a new SD card and Re-install with the new SD card if you do not upload/download of the NVRAM data.
- Both the HDD and NVRAM at the same time
- Re-install the original SD card.

If you do not have the original SD card, order a new SD card and Re-install with the new SD card.

 **Note**


- Re-installation procedure is the same as the installation procedure.

Fuses

AC Drive Board

Fuse	Rating		Blown Fuse
	NA	EU	
FU101	15A/250VAC	8A/250VAC	SC547-02
FU102	15A/250VAC	8A/250VAC	Power switch does not operate.
FU103	Japan only	Japan only	
FU105	2A/250VAC	2A/250VAC	SC547-02
FU106	Japan only	Japan only	

7



d223c3755

DHB



Fuse	Rating		Blown Fuse
	NA	EU	
FU110	2A/250VAC	2A/250VAC	Heater does not operate.



d223c3485

PSU

Fuse	Rating		Blown Fuse
	NA	EU	
FU1	15A/250VAC	15A/250VAC	SC664-01 (SC log SC664-21, SC991-00)
FU2	15A/250VAC	15A/250VAC	No copy icon, SC670-01 at power on, SC log SC899-00
FU3	10A/250VAC	10A/250VAC	SC272-10 (SC log SC547-02, SC515-00)
FU4	10A/250VAC	10A/250VAC	LCIT, Finisher do not operate, paper jam
FU5	10A/250VAC	10A/250VAC	SC530 (SC log SC531-02, SC531-03, SC531-01, SC202-00, SC530-07, SC530-05, SC120-00)
FU7	10A/250VAC	10A/250VAC	Not used. No SC code returned, no abnormal operation.



d223c3481

MP 6503SP/MP 7503SP/MP9003SP
Machine Code: D223/D224/D225
Appendices

May 2016
Subject to change

TABLE OF CONTENTS

1. Machine Specifications

- General Specifications.....5
- Copier.....5
 - Engine.....5
 - ADF.....9
 - Power Consumption9
 - Noise Emission.....11
- Printer Specifications.....11
- Scanner Specifications.....13
- Supported Paper Sizes.....16
 - Original Size Detection.....16
 - Book Mode (Exposure Glass) Original Size Detection.....16
 - Sensor States.....16
 - ADF Original Size Detection.....18
 - Paper Feed.....20
 - Main Machine.....22
 - Feed Station Options: A3/DLT Kit, LCIT, Cover Interposer Trays.....23
 - Paper Exit.....26
 - Exit Tray (Main Machine), Mail Box CS4010.....28
 - Finisher SR4080 (3K Finisher Corner Stapling Only).....29
 - 3K/2K Finishers.....32
 - Multi-Folding Unit FD4000.....37
 - Cover Interposer Trays.....42
- Software Accessories.....45
 - Printer Drivers.....45
 - Windows Environment.....45
 - Mac OS and UNIX Environment.....49
 - Scanner and LAN Fax Drivers.....49
- Optional Equipment Specifications.....51
 - 8 1/2"x14" Paper Size Tray Type M25 (B474).....51
 - A3/11" x 17" Tray Type M25 (D615).....51
 - LCIT RT4040 (D3A6).....51
 - Finisher SR4080 (D610).....52

Upper Tray.....	52
Shift Tray.....	52
Stapler.....	52
Punch Unit Type 1075 (B531)	53
Punch Unit Type 850 SC (A812).....	54
Output Jogger Unit Type 9002B (B513).....	56
Output Jogger Unit Type M25 (D3CJ).....	56
Finisher SR4120 (D3CG).....	57
Finisher.....	57
Stapler.....	58
Booklet Finisher SR4130 (D3CH).....	59
Finisher.....	59
Stapler.....	60
SR4120/SR4130 Paper Specifications.....	62
Punch Unit Type 3060 (B706).....	63
Mail Box CS4010 (D708).....	64
Cover Interposer Tray CI4040 (DC3N).....	65
Cover Interposer Tray CI4030 (D3D7).....	65
Multi Folding Unit FD4000 (D615).....	66
General.....	66
Tray Capacity.....	69

2. Engine SP Mode Tables

Engine SP Tables-1	75
SP1-XXX (Feed).....	75
Engine SP Tables-2.....	97
SP2-XXX (Drum).....	97
Engine SP Tables-3.....	136
SP3-XXX (Process).....	136
Engine SP Tables-4.....	139
SP4-XXX (Scanner).....	139
Engine SP Tables-5.....	152
SP5-XXX (Mode).....	152
Engine SP Tables-6.....	155

SP6-XXX (Peripherals).....	155
Engine SP Tables-7.....	185
SP7-XXX (Data Log).....	185
Input and Output Check.....	214
Input Check Table.....	214
Main Machine, LTC.....	214
ADF.....	227
2K/3K Finisher	228
Finisher.....	232
Slide Sort Tray.....	233
Multi Folder.....	234
Print Post.....	235
1-Tray CIT.....	236
Output Check Table.....	237
Main Machine, LTC.....	237
ADF.....	241
2K/3K Finisher.....	241
Finisher.....	243
Slide Sort Tray.....	244
Multi Folder.....	245
Print Post.....	246

3. Controller SP Mode Tables

Controller SP Tables-5.....	247
SP5-XXX (Mode).....	247
Controller SP Tables-6.....	324
SP6-XXX (Data Log).....	324
Controller SP Tables-7.....	325
SP7-XXX (Data Log).....	325
Controller SP Tables-8.....	362
SP8-XXX (Data Log2).....	362
Printer Service Menu.....	414
SP1-XXX (Service Mode).....	414
Scanner Service Menu.....	431

SP1-XXX (System and Others).....	431
SP2-XXX (Scanning-image quality).....	433

1. Machine Specifications

General Specifications

Copier

Engine

Configuration	Console
	Original: Sheet/Book/Objects Original Size Max. A3/11" x 17" Min. B6 SEF/5.5" x 8.5" (using ADF) Original Alignment: Rear left corner
Copy Method	Dry static conduction
Development Method	Dual component developer/toner, electromagnetic brush method with 1-step sleeve
Fusing Method	Heating roller with fusing belt and pressure roller
Original Feed	Book scanning, ADF standard multiple feed
Scanning Method	Simultaneous dual side scanning
	Front Color CMOS element (3-line CMOS color linear image sensor with two LEDs as exposure lamps)
	Back Color CIS element
Original Size	Simplex: A3/11" x 17" – B6/5.5" x 8.5" Duplex: A3/11" x 17" – B5/5.5" x 8.5" Max. size: 12"x17" platen mode.

Copy Paper Size	Paper tray, Duplex	A3/11" x 17" – A5/ 5.5" x 8.5"
	Bypass tray	A3/11" x 17" – A6 SEF/5.5" x 8.5"
	Non-standard sizes	Width: 139.7 – 297 mm (5.5" x 11.7") Length: 139.7 – 432 mm (5.5" x 17")
Copy Paper Weight	Paper Tray	52.3 to 127.9 g/m ² (14 to 34 lb.)
	Duplex	64 to 127.9 g/m ² (17 to 34 lb.)
		By-pass <ul style="list-style-type: none"> • Standard: 52.3 to 157 g/m² (14 to 43 lb.) • Thick Paper mode: 52.3 to 216 g/m² (14 to 58 lb.)
Paper Weight		
D223/D224	Tray 1	52-256g/m ² (45-220kg)
	Tray 2, 3	52-256g/m ² (45-220kg)
	Bypass (std. Thick 1 to 3)	52-256g/m ² (45-220kg)
	Bypass(Tracing paper)	52-128g/m ² (45-110kg)
	Bypass(Labels)	52-128g/m ² (45-110kg)
D225	Tray 1	52-256g/m ² (45-220kg)
	Tray 2 to 3	52-256g/m ² (45-220kg)
	Bypass (Std. Thick 1 to 3)	52-256g/m ² (45-220kg)
	Bypass(Tracing paper)	52-128g/m ² (45-110kg)
	Bypass (Labels)	52-128g/m ² (45-110kg)

Reproduction Ratios	7 reduction ratios, 5 enlargement ratios Metric (%): 400, 200, 141, 122, 115, 93, 82, 75, 71, 65, 50, 25 Inch (%): 400, 200, 155, 129, 121, 93, 85, 78, 73, 65, 50, 25 Std. adjustment: Horizontal/vertical < $\pm 1.0\%$ Free adjustment: Horizontal/vertical < $\pm 1.0\%$		
Zoom	25% to 400% (1% units selectable)		
Margins (White Space)	Leading margin	4.2 \pm 1.5mm	
	Left margin	0.5 \pm 4.0mm	
	Right margin	0.5 \pm 4.0mm	
	Trailing margin	0.5 \pm 6.0mm	
Continuous Copying Speed	D223: 65 ppm (A4, LT LEF) D224: 75 ppm (A4, LT LEF) D225: 90 ppm (A4, LT LEF)		
Max. Original Size	A3 (297x420 mm), 11x17 LEF (279x432 mm)		
First Copy Time	D223	3.2 s	(Tray 1, A4/LT LEF face-up, contact glass mode, APS off)
	D224	3.2 s	
	D225	2.9 s	
Warm-up Time	D223: < 20 seconds D224: < 20 seconds D225: < 300 seconds From power on at 20°C (68°F)		
	< 30 sec. at return from power off mode		
Continuous Copying	1 to 999 (Operation panel entry)		
Paper Type	Standard (normal) bond, tracing paper (including translucent), OHP, labels, color papers, postcards, index tab		

Paper Capacity	Tray 1	3100 sheets (1550 x2)	
	Tray 2	550 sheets	
	Tray 3	550 sheets	
	Bypass tray	100 sheets (80 g/m ² , 20 lb.)	
Paper Output	A4/8.5" x 11" and smaller	500 sheets	
	B4 and larger	250 sheets	
Power Source	North America	D224: 120-127V, 60Hz, 20A D225: 208-240, 60Hz, 12A	
	Europe/Asia/China	220-240V/10A 50/60Hz	
	Taiwan	D224: 110V/14A+110V/4A 60Hz D225: 220V/10A 60Hz	
Power Consumption	Full System	NA	D223/D224: <1.8 KW D225: <1.9 KW
		EU	D223/D224: < 1.9 KW D225: < 1.9 KW
Energy Start	Implemented		
Memory	4 GB		
HDD Capacity	320 GB		
Semi-conductor	OPC drum		
Allowed voltage fluctuation	10%		
Dimensions (wxdxh)	690 x 803 x 1161 mm (27.2 x 31.6 x 45.7 in.)		
Space required (wxd)	1175 x 821 mm (46.3 x 32.3 in.)		
Weight	M223/M224	Approx. 200 kg (440 lb.)	
	M225	Approx. 208 kg (458 lb.)	
Resolution	Scanning	600 dpi 89-bit	
	Printing	1200 dpi 1-bit	

Gradation	256 levels (scanning and printing)
Toner Replenishment	Cartridge exchange (1100 g)
Total Counter	Electric Counter

ADF

Original Size	Simplex: A3/11" x 17" – B6/5.5" x 8.5" Duplex: A3/11" x 17" – B5/5.5" x 8.5" Note: Dual side scanning is not possible with B6 LEF/SEF.
Original Weight	Simplex: 40 to 128 g/m ² (11 to 34 lb.) Duplex: 52 to 128 g/m ² (14 to 34 lb.)
Table Capacity	250 sheets: 69g/m ² (150 sheets: 80g/m ² , 20 lb. Bond)
Original Standard Position	Rear left corner (platen mode/ADF mode)
Separation	Feed belt and separation roller
Original Transport	Roller transport
Original Feed Order	From top original
Reproduction Range	100%
Power Source	DC 24 V from the main machine
Power Consumption	< 110 W
Rated Voltage of Output Connector	Max. DC 24 V
Permissible voltage fluctuation	±10%
Dimensions (w x d x h)	680 x 560 x 180 mm (26.8" x 22.0" x 7.1")
Weight	18 kg (39.6 lb.)

Power Consumption

NA

Operation Mode	D223	D224	D225
Main unit only			
Warm Up	1380W	1400W	1720W
Stand-by	269W	269W	299W
During printing	1230W	1250W	1480W
Maximum	1620W	1640W	1750W
Complete system *1			
Warm Up	1410W	1420W	1740W
Stand-by	289W	289W	320W
During printing	1330W	1350W	1610W
Maximum	1720W	1740W	1880W
*1 Main Machine + Finisher + Cover Interposer Tray + LCT			

EU/AA

Operation Mode	D223	D224	D225
Main unit only			
Warm Up	1500W	1510W	1730W
Stand-by	279W	279W	299W
During printing	1260W	1280W	1490W
Maximum	1730W	1760W	1790W
Complete system *1			
Warm Up	1520W	1530W	1740W
Stand-by	310W	310W	320W
During printing	1330W	1360W	1540W
Maximum	1800W	1830W	1840W
*1 Main Machine + Finisher + Cover Interposer Tray + LCT			

Noise Emission

No.	Test Mode dB (A)	Noise Power Level	Operator Position	Bystander Position Max.
D223	Standby OFF Mode: MFP, CTL FAN ON	49.3	37.5	36.6
	Book Mode	67.0	51.9	53.9
	System: LCT Feed DF Simplex, Punch Sort	74.3	62.4	59.8
	System: Standby Engine OFF	50.1	35.7	37.5
D224	Standby OFF Mode: MFP, CTL FAN ON	49.4	37.7	36.9
	Book Mode	69.7	55.2	58.8
	System: LCT Feed DF Simplex, Punch Sort	74.3	62.1	59.9
	System: Standby Engine OFF	50.0	35.7	37.5
D225	Standby OFF Mode: MFP, CTL FAN ON	50.4	38.2	37.7
	Book Mode	71.0	56.4	58.3
	System: LCT Feed DF Simplex, Punch Sort	75.0	62.4	60.5
	System: Standby Engine OFF	52.3	36.9	39.5

* 1 System: Main Machine + Finisher + Multi Folder +LCT

Note

- The above measurements were made in accordance with ISO 7779. Full system measurements include the Mainframe + Finisher + LCT + Cover Interposer + Punch.

Printer Specifications

Print Size	Standard	Max.A3SEF(297×420mm), 11×17SEF(279.4×431.8mm)
------------	----------	--

	Custom	Max. 305×600mm(Bypass Tray: Std.)Max. 305×1260mm(Bypass Tray: Long)
Print Speed	M225: 90 ppm M224: 75 ppm M223: 65 ppm	
Resolution	200 dpi, 300 dpi/, 400 dpi, 600 dpi, 1200 dpi	
Printer Languages	Standard	RPCS, RPD, PDF
	Option	Adobe PostScript 3, PCL6(PCL XL/PCL 5e)
Emulation (option)	Adobe PostScript 3, R55(IBM5577, RTIFF, XPS)	
Interface	Standard	Cover Interposer Tray (1000BASE-T/100BASE-TX/ 10BASE-T) Operation Panel USB2.0 port(A type) USB2.0 port(B type) Operation Panel SD Card Slot
	Option	IEEE1284 standard bi-directional parallel IEEE 802.11a/b/g/h(Wireless LAN)
Protocols	TCP/IP(IPv4, IPv6, LPD, DIPRINT, FTP, SFTP, IPP, SMB, IPP-SSL, RHPP, WSD(Printer, Port9100)	
USB Interface	<ul style="list-style-type: none"> • Compatible OS: Windows Vista, Windows 7, Windows 8, Windows 8.1, Windows 10, Windows Server 2003, Windows Server 2003 R2, Windows Server 2008, Windows Server 2008 R2, Windows Server 2012, Windows Server 2012R2, OSX 10.7 and after • Communication Method USB2.0 Standard Compatible • Connection Method USB2.0 Standard Compatible Device 	
Compatible OS	Windows Vista, Windows 7, Windows 8, Windows 8.1, Windows 10, Windows Server 2003, Windows Server 2003 R2, Windows Server 2008, Windows Server 2008 R2, Windows Server 2012, Windows Server 2012R2, Option OSX 10.7and after (option)	

Built-in Fonts	Standard	Courier 10, Prestige Elite 12, Letter Gothic 15, Bold Face PS, Courier 4, Arial 4, Times New Roman 4, Wingdings, Century, Symbol, OCR-B
	Option	MBBB(PostScript3, for direct printing to PDF), European 45, International font 13(for PCL)
Bar Codes		2 of 5(Industrial, 2 of 5(ITF, 2 of 5(Matrix, CODE128(B, CODE39, CUSTOMER, JAN(Compressed, JAN(Std., NW-7, UPC(A, UPC(E
Reduction Rate		25 to 400%

↓ Note

- The RPD L printer driver is not provided.
- With a Macintosh only the standard USB port is compatible.
- When the Cover Interposer Tray is installed (1000BASE-T, 100BASE-TX, 10BASE-T) the interface cable cannot be longer than 100.

Scanner Specifications

Configuration	Full color scanner
Scanning Method	Fixed platen and ADF dual-side scanning
Image Sensors	Front side: CMOS image sensor Back side: CCD image sensor
Original	Cut sheet, platen book mode
Original Size	SEF: 10 to 297 mm (0.4 to 11.7 in.) LEF: 10 to 432 mm (0.4 to 17 in.)
Paper Size	A3 SEF, B4 SEF, A4 LEF/SEF, B5 LEF/SEF, A5 LEF/SEF, B6 LEF/SEF, 11x17 SEF, 8.5x11 LEF/SEF Note: These sizes are detected automatically when placed on the exposure glass.

Scanning Speed	Mail TX/Folder TX/WSD Scanner(Push)DSM Scanner(Original Size: A4LEF, Resolution: 200dpi/300dpi) <ul style="list-style-type: none"> • 1-Side B&W: 120 ppm (Text/Drawing, MMH compression, ITU-T Chart No. 1) • 2-Side B&W: 220 ppm (Text/Drawing, MMH compression, ITU-T Chart No. 1) • 1-Side FC: 120 ppm (Text/Drawing, Grayscale/FC), JPEG standard compression, Ricoh Test Chart) • 2-Side FC: 220ppm (Text/Photo, Grayscale/FC, JPEG standard compression, Ricoh Test Chart) <p>Note: Speed could vary depending on ambient conditions, content of the document, and computer environment.</p>	
Gradation	B&W: 2-Step FC/Grayscale: 256-Step	
Scan Resolution	200 dpi (standard)	
Compression	B&W: TIFF (MH, MR, MMR, JBIG2) Grayscale/FC: JPEG	
Interface	Standard	Cover Interposer Tray(1000BASE-T, 100BASE-TX, 10BASE-T) Operation Panel USB2.0 Port(A-type) Operation Panel SD Card Slot
	Option	IEEE802.11a/b/g/h (Wireless LAN)
Network I/F	TCP/IP	
Mail TX		
Resolution	100 dpi, 200 dpi, 300 dpi, 400 dpi, 600 dpi	
Protocol	SMTP	
Output Format	TIFF, JPEG, PDF, Clear Write PDF, PDF/A	
Folder TX		

Resolution	100 dpi, 200 dpi, 300 dpi, 400 dpi, 600 dpi
Protocol	SMB, FTP, NCP
Output Format	TIFF, JPEG, PDF, Clear Write PDF, PDF/A
TWAIN Driver	
Resolution	100 to 1200dpi
Protocol	TCP/IP
Compatible OS	Windows Vista, Windows 7, Windows 8.1, Windows 10, Windows Server 2003, Windows Server 2003 R2, Windows Server 2008, Windows Server 2008 R2, Windows Server 2012, Windows Server 2012R2 Note: Networked TWAIN driver is compatible with 64-bit OS in 32-bit compatible mode.
Network Resolution	100 dpi, 200 dpi, 300 dpi, 400 dpi, 600 dpi
WIA Scanner	
Resolution	100 to 1200dpi
Protocol	TCP/IP
Compatible OS	Windows Vista(SP1 and after, Windows 7, Windows 8, Windows 8.1, Windows 10, Windows Server 2008, Windows 2008 R2, Windows 2012, Windows 2012R2 Note: A WIA scanner is also compatible with 64-bit OS.

Supported Paper Sizes

1

Original Size Detection

Book Mode (Exposure Glass) Original Size Detection

- Original size detection is triggered by the APS when the ADF is lowered.
- Original length is detected using one original size sensor.
- At the same time, pre-scanning is done so the C-MOS image sensor can detect the original width. At this time the scanner LED lights only one-third of the detection area near the front.
- If the Start key is pressed with the ADF unit up (APS: OFF), the size of the previous original is used.


Sensor States

The combinations of the sensor states are used to determine the original size, and this data can be confirmed with **SP4-301-001**. The data for each detected size is displayed by **SP4-301-001** as shown below. Due to the layout of the sensors, paper sizes smaller than B5 cannot be detected, so in this case all zeroes are displayed (0000 0000).

Original Size Detection

[A] A4 SEF

[B] A4 LEF



A: A4 SEF

B: A4 LEF

Size	L1	SP4-301-001 Display
A3	On	00000001
B4	On	00000001
A4 SEF	On	00000001
A4 LEF	Off	00000000
B5 SEF	On	00000001
B5 LEF	Off	00000000
A5 SEF	Off	00000000
A5 LEF	Off	00000000

If the value detected by the C-MOS image sensor is more than "18" in the width direction as displayed by **SP4-310-001** to **009**, then the machine determines that an original is on the exposure glass. However, the value displayed is the result of the most recent reading.


SP4-310-001 : Scanned value of R at S1 during original size detection.	Even if only one reading is more than 18 , it is judged that an original is at S1 .
SP4-310-002 : Scanned value of G at S1 during original size detection.	
SP4-310-003 : Scanned value of B at S1 during original size detection.	
SP4-310-004 : Scanned value of R at S2 during original size detection.	Even if only one reading is more than 18 , it is judged that an original is at S2 .
SP4-310-005 : Scanned value of G at S2 during original size detection.	
SP4-310-006 : Scanned value of B at S2 during original size detection.	

SP4-310-007: Scanned value of R at S3 during original size detection.	Even if only one reading is more than 18 , it is judged that an original is at S3 .
SP4-310-008: Scanned value of G at S3 during original size detection.	
SP4-310-009: Scanned value of B at S3 during original size detection.	

Size	Feed	Size (LxW)	S1	S2	S3
A3	SEF	297x420	ON	ON	ON
B4	SEF	257x364	ON	ON	OFF
A4	SEF	210x297	ON	OFF	OFF
A4	LEF	297x210	ON	ON	ON
B5	SEF	182x257	OFF	OFF	OFF
B5	LEF	257x182	ON	ON	OFF
A5	SEF	148x210	OFF	OFF	OFF
A5	LEF	210x148	ON	OFF	OFF
B6	SEF	128x182	OFF	OFF	OFF
B6	LEF	182x128	OFF	OFF	OFF

ADF Original Size Detection

- When the leading edge of the original reaches the interval sensor, the machine determines the width from the readings of the 5 original width sensors.
- The length of the original is determined by the readings of the 3 original length sensors under the original table and one sensor on the bottom plate.
- These two arrays of sensors are used to determine the size of the originals.



d1359006

No.	Part
1	Original Length Sensor A4/LT LEF
2	Original Length Sensor B5
3	Original Length Sensor A4
4	Original Length Sensor LG
5	Original Width Sensor 5
6	Original Width Sensor 4
7	Original Width Sensor 3
8	Original Width Sensor 2
9	Original Width Sensor 1

	Width Sensors					Length Sensors			
	1	2	3	4	5	A4 LEF	B5	A4	LG
A3(297x420)	ON	ON	ON	ON	ON	ON	ON	ON	ON
B4(257x364)	ON	ON	ON	---	---	ON	ON	ON	ON
A4 SEF (210x297)	ON	ON	---	---	---	ON	ON	ON	-
A4 LEF (297x210)	ON	ON	ON	ON	ON	---	---	---	---

	Width Sensors					Length Sensors			
	1	2	3	4	5	A4 LEF	B5	A4	LG
A4 SEF (210x297)	ON	---	---	---	---	ON	ON	---	---
A4 LEF (297x210)	ON	ON	ON	---	---	---	---	---	---
A4 SEF (210x297)	---	---	---	---	---	---	---	---	---
A4 LEF (297x210)	ON	---	---	---	---	---	---	---	---
DLT SEF (11"x17")	ON	ON	ON	ON	---	ON	ON	ON	ON
DLT SEF (11"x17")	ON	ON	ON	ON	---	ON	ON	ON	ON
8 1/2"x11" SEF (LT)	ON	ON	---	---	---	ON	ON	---	---
11"x8 1/2" LEF (LT)	ON	ON	ON	ON	---	---	---	---	---

↓ Note

- 11"x17", 11"x15" are detected as the same size, so you need to select one or the other with **SP6016-001** (Original Size Determination Priority) to choose whichever are using.

Paper Feed

Remarks

A	Auto detectable. Also can be selected with size button of initial setting.
B	Can be selected with size button from initial setting.
C	Select this size by setting the dial.
D	Set dial to "*", then select with size button from initial setting.
E	Bypass setting. Copy window/Bypass/Standard size/Size select or select with the print bypass paper size/size button from initial setting.
F	Select with SP from preset paper sizes. Cannot be selected from printer driver.

G	<p>Switches which size to set as auto detect with SP.</p> <p>*Example: The combination of A1-G1.</p> <p>G (When not auto detectable) will be as same as B.</p> <p>Combinations are only made from same region same tray.</p> <p>*Example: The combination of G1 and J1.</p> <p>G (When not auto detectable) will be as same as E.</p> <p>Combinations are only made from same region same tray.</p>
H	Size fixed when shipping.
I	Bypass setting. With bypass tray, after 1st sheet trailing edge goes through, auto detects size, then fixed to size detected from the 2nd sheet.
J	Bypass setting. Auto detect of Copy window/Bypass/Standard size/Select with size button.
K	Select with SP from preset paper sizes. Can be selected from printer driver.
---	Not available

Notes

0	Paper without designated size code can pass through the peripheral as a custom size.
1	Sizes that can be used in Tray 1 (Tandem Tray).
2	Long paper up to 432 mm long can be effectively fed from the bypass tray.
3	The paper size can be set with an SP code.
4	Paper lengths up to 150 mm (Thick 1, 2, 3) are not within specification.
5	When duplex printing with paper fed from the bypass tray, settings can be done (front sheet, back sheet, etc.), or the default settings (paper type, paper size, thickness) can be used.

Examples

Combinations of letters and numbers direct your attention to the **Remarks** and **Notes** table above.

- "E4" Refers to Remark "E and Note "4".
- "K1" Refers to Remark K and Note 1.
- Do not confuse these notations with paper sizes (A4, etc.) The paper sizes are listed only in the left column.

Main Machine

	Bypass (100)		Tray 1 (Tandem) (1550+1550)		Tray 2, 3 (Universal) (550 ea.)	
	NA	EU/Asia	NA	EU/Asia	NA	EU/Asia
A3 SEF (297x420 mm)	J	J	---	---	A	A
A4 SEF (210x297 mm)	E	J	---	---	A	A
A4 LEF (297x210 mm)	J	J	K1	H1	A	A
A5 SEF (148x210 mm)	E	J	---	---	A	A
A5 LEF (210x148 mm)	E4	J4	---	---	A4	A4
A6 SEF (105x148 mm)	E	E	---	---	---	---
B4 SEF (257x364 mm)	E	E	---	---	A	A
B5 SEF (182x257 mm)	E	E	---	---	A	A
B5 LEF (257x182 mm)	E	E	---	---	A	A
B6 SEF (128x182 mm)	E	E	---	---	---	---
DLT SEF (11x17 in.)	J	E	---	---	A	A
Legal SEF (8.5x14 in.)	A1	E	---	---	A	A
Foolscap SEF (8.5x13 in.)	E	E	---	---	A	A
Letter SEF (8.5x11 in.)	G1	E	---	---	A1	A1
Letter LEF (11x8.5 in.)	J	E	H1	K1	A	A
Govt LG SEF (8.25x14 in.)	E	E	---	---	B	B
Folio SEF (8.25x13 in.)	E	E	---	---	A	A
F/GL SEF (8x13 in.)	E	E	---	---	A	A
Eng Quatro SEF (8x10 in.)	E	E	---	---	---	---
Eng Quatro LEF 10x8 in.)	E	E	---	---	---	---
Executive SEF (7.25x10.5 in.)	E	E	---	---	A	A

	Bypass (100)		Tray 1 (Tandem) (1550+1550)		Tray 2, 3 (Universal) (550 ea.)	
	NA	EU/Asia	NA	EU/Asia	NA	EU/Asia
Executive LEF (10.5x7.25 in.)	E	E	---	---	A	A
Half Letter SEF (5.5x8.5 in.)	J	E	---	---	A	A
Half Letter LEF (8.5x5.5 in.)	J4	E4	---	---	A4	A4
8K SEF (267x390 mm)	---	---	---	---	A	A
16K SEF (195x267 mm)	---	---	---	---	A	A
16K LEF (267x195 mm)	---	---	---	---	A	A
11x15 SEF (11x15 in.)	E	E	---	---	B	B
11x14 SEF (11x14 in.)	E	E	---	---	B	B
10x15 SEF (10x15 in.)	E	E	---	---	B	B
10x14 SEF (10x14 in.)	E	E	---	---	---	---
8 $\frac{1}{2}$ x 13 $\frac{2}{5}$ SEF (8.5x13.4 in.)	G1	E	---	---	G1	G1

Feed Station Options: A3/DLT Kit, LCIT, Cover Interposer Trays

Tray 1 A3/DLT Kit, LCIT

	Tray 1 A3/DLT Kit (1000)		LCIT (4000)	
	NA	EU/Asia	NA	EU/Asia
A3 SEF (297x420 mm)	K	K	---	---
A4 SEF (210x297 mm)	K	K	---	---
A4 LEF (297x210 mm)	K	H	K	H
A5 SEF (148x210 mm)	---	---	---	---
A5 LEF (210x148 mm)	---	---	---	---

	Tray 1 A3/DLT Kit (1000)		LCIT (4000)	
	NA	EU/Asia	NA	EU/Asia
A6 SEF (105x148 mm)	---	---	---	---
B4 SEF (257x364 mm)	K	K	---	---
B5 SEF (182x257 mm)	---	---	---	---
B5 LEF (257x182 mm)	---	---	K	K
B6 SEF (128x182 mm)	---	---	---	---
DLT SEF (11x17 in.)	K	K	---	---
Legal SEF (8.5x14 in.)	K	K	---	---
Foolscap SEF (8.5x13 in.)	---	---	---	---
Letter SEF (8.5x11 in.)	K	K	---	---
Letter LEF (11x8.5 in.)	H	K	H	K
Govt LG SEF (8.25x14 in.)	---	---	---	---
Folio SEF (8.25x13 in.)	---	---	---	---
F/GL SEF (8x13 in.)	---	---	---	---
Eng Quatro (SEF 8x10 in.)	---	---	---	---
Eng Quatro LEF (10x8 in.)	---	---	---	---
Executive SEF (7.25x10.5 in.)	---	---	---	---
Executive LEF (10.5x7.25 in.)	---	---	---	---
Half Letter SEF (5.5x8.5 in.)	---	---	---	---
Half Letter LEF (8.5x5.5 in.)	---	---	---	---
8K SEF (267x390 mm)	---	---	---	---
16K SEF (195x267 mm)	---	---	---	---
16K LEF (267x195 mm)	---	---	---	---
11x15 SEF (11x15 in.)	---	---	---	---

	Tray 1 A3/DLT Kit (1000)		LCIT (4000)	
	NA	EU/Asia	NA	EU/Asia
11x14 SEF (11x14 in.)	---	---	---	---
10x15 SEF (10x15 in.)	---	---	---	---
10x14 SEF (10x14 in.)	---	---	---	---
8 1/2 x 13 2/5 SEF (8.5x13.4 in.)	K	K	---	---

Cover Interposer Trays

	Cover Interposer Trays (200)		
	NA	EU	Asia
A3 SEF (297x420 mm)	A	A	A
A4 SEF (210x297 mm)	A	A	A
A4 LEF (297x210 mm)	A	A	A
A5 SEF (148x210 mm)	A	---	A
A5 LEF (210x148 mm)	A	---	A
A6 SEF (105x148 mm)	---	---	---
B4 SEF (257x364 mm)	A	---	A
B5 SEF (182x257 mm)	A	---	A
B5 LEF (257x182 mm)	A	---	A
B6 SEF (128x182 mm)	---	---	---
DLT SEF (11x17 in.)	A	A	G4
Legal SEF (8.5x14 in.)	---	A1	---
Foolscap SEF (8.5x13 in.)	---	G1	A7
Letter SEF (8.5x11 in.)	A	A2	G6
Letter LEF (11x8.5 in.)	A	A3	G5

	Cover Interposer Trays (200)		
	NA	EU	Asia
Govt LG SEF (8.25x14 in.)	---	---	---
Folio SEF (8.25x13 in.)	---	---	G7
F/GL SEF (8x13 in.)	---	---	G7
Eng Quatro (SEF 8x10 in.)	---	G2	---
Eng Quatro LEF (10x8 in.)	---	---	---
Executive SEF (7.25x10.5 in.)	---	A	---
Executive LEF (10.5x7.25 in.)	---	G3	---
Half Letter SEF (5.5x8.5 in.)	---	A	---
Half Letter LEF (8.5x5.5 in.)	---	A	---
8K SEF (267x390 mm)	---	---	A4
16K SEF (195x267 mm)	---	---	A6
16K LEF (267x195 mm)	---	---	A5
11x15 SEF (11x15 in.)	---	---	---
11x14 SEF (11x14 in.)	---	---	---
10x15 SEF (10x15 in.)	---	---	---
10x14 SEF (10x14 in.)	---	A	---
8 1/2 x 13 2/5 SEF (8.5x13.4 in.)	---	A	---

Paper Exit

Remarks:

A	Paper exit is available and paper will pass.
B	Paper exit is available but passage is not guaranteed as the paper is not with specifications.
---	Not available.

Notes

0	Paper without designated size code can pass through the peripheral as a custom size.
1	Folding is possible with Multi Folder with thick paper in the range 64 to 80 g/m ² .
2	Main machine controls stapling.
3	Not used.
4	Not used.
5	Paper longer than 432 mm is not within specification
6	Paper lengths up to 150 mm (Thick 1, 2, 3) are not within specification.
7	There are limitations on FM 3 Letter Fold-out, FM 4 Letter Fold-in, FM6 Gate Folding with A3, B4, DLT and LG size paper due to the possibility of wrinkling.
8	There are limitations on FM6 Gate Folding with A3, B4, DLT and LG size paper due to the possibility of creasing.
9	Out of specification for stack alignment by jogger operation on the 2K/3K Finishers.
10	Estimated eight Z-folded sheets for 52 to 80 g/m ² . Estimated thirteen Z-folded sheets for 80.1 to 105 g/m ² .
11	Up to 5 multi-folded sheets allowed with 2K/3K Finishers.
12	Range of paper size that can be shifted with the 2K/3K Finishers Width: 125.0 to 304.8 mm Length: 139.7 to 457.2 mm
13	Range of paper size that can be corner stapled with the 2K/3K Finishers Width: 182.0 to 297 mm Length: 182.0 to 457.2 mm
14	Range of paper size that can be booklet stapled with the 2K/3K Finishers Width: 182.0 to 330.2 mm Length: 257.0 to 457.2 mm However, the width is further restricted to 182 mm, 207 to 225 mm, 250 to 257 mm, 279.4 to 306 mm
15	Can exit if folded with Multi Folder unit. Cannot exit if not folded.

Examples

Combinations of letters and numbers direct your attention to the **Remarks** and **Notes** table above.

- "A6" Refers to Remark "A" and Note "6".
- "A(3)1 Refers to Remark "A" (3 sheets), Note "1".
- Do not confuse these notations with paper sizes (A6, etc.) The paper sizes are listed only in the left column.

Exit Tray (Main Machine), Mail Box CS4010

	Exit Tray	Mail Box
A3 SEF (297x420 mm)	A	A
A4 SEF (210x297 mm)	A	A
A4 LEF (297x210 mm)	A	A
A5 SEF (148x210 mm)	A	A
A5 LEF (210x148 mm)	A6	A6
A6 SEF (105x148 mm)	A	---
B4 SEF (257x364 mm)	A	A
B5 SEF (182x257 mm)	A	A
B5 LEF (257x182 mm)	A	A
B6 SEF (128x182 mm)	A	---
DLT SEF (11x17 in.)	A	A
Legal SEF (8.5x14 in.)	A	A
Foolscap SEF (8.5x13 in.)	A	A
Letter SEF (8.5x11 in.)	A	A
Letter LEF (11x8.5 in.)	A	A
Govt LG SEF (8.25x14 in.)	A	A
Folio SEF (8.25x13 in.)	A	A
F/GL SEF (8x13 in.)	A	A
G LT SEF (8x10.5 in.)	A	A

	Exit Tray	Mail Box
G LT LEF (10.5x8 in.)	A	A
Eng Quatro SEF (8x10 in.)	A	A
Eng Quatro LEF (10x8 in.)	A	A
Executive SEF (7.25x10.5 in.)	A	A
Executive LEF (10.5x7.25 in.)	A	A
Half Letter SEF (5.5x8.5 in.)	A	A
Half Letter LEF (8.5x5.5 in.)	A6	A6
8K SEF (267x390 mm)	A	A
16K SEF (195x267 mm)	A	A
16K LEF (267x195 mm)	A	A
11x15 SEF (11x15 in.)	A	A
11x14 SEF (11x14 in.)	A	A
10x15 SEF (10x15 in.)	A	A
10x14 SEF (10x14 in.)	A	A
8.5 x 13.4 SEF (8.5x13.4 in.)	A	A

Finisher SR4080 (3K Finisher Corner Stapling Only)

	Exit			Stapling		
	Proof	Shift	Shifting	Corner	Booklet	Sheets
A3 SEF (297x420 mm)	A	A	A	A	A	50 (2)
A4 SEF (210x297 mm)	A	A	A	A	A	100
A4 LEF (297x210 mm)	A	A	A	A	A	100
A5 SEF (148x210 mm)	A	A	A	---	1. ---	
A5 LEF (210x148 mm)	A6	A6	A6	---	---	

	Exit			Stapling		
	Proof	Shift	Shifting	Corner	Booklet	Sheets
A6 SEF (105x148 mm)	A	---	---	---	---	
B4 SEF (257x364 mm)	A	A	A	A	A	50 (2)
B5 SEF (182x257 mm)	A	A	A	A	A	100
B5 LEF (257x182 mm)	A	A	A	A	A	100
B6 SEF (128x182 mm)	A	---	---	---	---	
DLT SEF (11x17 in.)	A	A	A	A	A	50 (2)
Legal SEF (8.5x14 in.)	A	A	A	A	A	50 (2)
Foolscap SEF (8.5x13 in.)	A	A	A	A	A	50 (2)
Letter SEF (8.5x11 in.)	A	A	A	A	A	100
Letter LEF (11x8.5 in.)	A	A	A	A	A	100
Govt LG SEF (8.25x14 in.)	A	A	A	A	A	50 (2)
Folio SEF (8.25x13 in.)	A	A	A	A	A	50 (2)
F/GL SEF (8x13 in.)	A	A	A	A	A	50 (2)
G LT SEF (8x10.5 in.)	A	A	A	A	A	50 (2)
G LT LEF (10.5x8 in.)	A	A	A	A	A	50 (2)
Eng Quatro SEF (8x10 in.)	A	A	A	A	A	50 (2)
Eng Quatro LEF (10x8 in.)	A	A	A	A	A	50 (2)
Executive SEF (7.25x10.5 in.)	A	A	A	A	A	50 (2)
Executive LEF (10.5x7.25 in.)	A	A	A	A	A	50 (2)
Half Letter SEF (5.5x8.5 in.)	A	A	A	---	---	---
Half Letter LEF (8.5x5.5 in.)	A6	A6	A	---	---	---
8K SEF (267x390 mm)	A	A	A	A	A	50 (2)
16K SEF (195x267 mm)	A	A	A	A	A	50 (2)
16K LEF (267x195 mm)	A	A	A	A	A	50 (2)

	Exit			Stapling		
	Proof	Shift	Shifting	Corner	Booklet	Sheets
11x15 SEF (11x15 in.)	A	A	A	A	A	50 (2)
11x14 SEF (11x14 in.)	A	A	A	A	A	50 (2)
10x15 SEF (10x15 in.)	A	A	A	A	A	50 (2)
10x14 SEF (10x14 in.)	A	A	A	A	A	50 (2)
8.5 x 13.4 SEF (8.5x13.4 in.)	A	A	A	A	A	50 (2)

In the table below “EU-2” means European 2-hole punch, “NA-2”, “NA-3” means North American 2-hole, 3-hole punch, and “SC4” means Scandinavian 4-hole punch.

	Punching				
	EU-2	NA-2	NA-3	EU-4	SC-4
A3 SEF (297x420 mm)	A	A	A	A	A
A4 SEF (210x297 mm)	A	A	---	---	A
A4 LEF (297x210 mm)	A	A	A	A	A
A5 SEF (148x210 mm)	A	A	---	---	A
A5 LEF (210x148 mm)	A6	A6	---	---	A6
A6 SEF (105x148 mm)	A	A	---	---	---
B4 SEF (257x364 mm)	A	A	A	A	A
B5 SEF (182x257 mm)	A	A	---	---	A
B5 LEF (257x182 mm)	A	A	A	A	A
B6 SEF (128x182 mm)	A	A	---	---	---
DLT SEF (11x17 in.)	A	A	A	A	A
Legal SEF (8.5x14 in.)	A	A	---	---	A
Foolscap SEF (8.5x13 in.)	A	A	---	---	A
Letter SEF (8.5x11 in.)	A	A	---	---	A

	Punching				
	EU-2	NA-2	NA-3	EU-4	SC-4
Letter LEF (11x8.5 in.)	A	A	A	A	A
Govt LG SEF (8.25x14 in.)	A	A	---	---	A
Folio SEF (8.25x13 in.)	A	A	---	---	A
F/GL SEF (8x13 in.)	A	A	---	---	A
G LT SEF (8x10.5 in.)	A	A	---	---	A
G LT LEF (10.5x8 in.)	A	A	A	A	A
Eng Quatro SEF (8x10 in.)	A	A	---	---	A
Eng Quatro LEF (10x8 in.)	A	A	A	---	A
Executive SEF (7.25x10.5 in.)	A	A	---	---	A
Executive LEF (10.5x7.25 in.)	A	A	A	A	A
Half Letter SEF (5.5x8.5 in.)	A	A	---	---	A
Half Letter LEF (8.5x5.5 in.)	A6	A6	---	---	A6
8K SEF (267x390 mm)	A	A	A	A	A
16K SEF (195x267 mm)	A	A	---	---	A
16K LEF (267x195 mm)	A	A	A	A	A
11x15 SEF (11x15 in.)	A	A	A	A	A
11x14 SEF (11x14 in.)	A	A	A	A	A
10x15 SEF (10x15 in.)	A	A	A	---	A
10x14 SEF (10x14 in.)	A	A	A	---	A
8.5 x 13.4 SEF (8.5x13.4 in.)	A	A	---	---	A

3K/2K Finishers

The 3K finisher is the Finisher SR4120 (Corner Stapling Only), and the 2K finisher is the Booklet Finisher SR4130 (Corner and Booklet Stapling).

Exit, Folded

	Exit				Folded
	Proof	Shift	Shifting	Booklet	Booklet
A3 SEF (297x420 mm)	A	A	A	A	A11
A4 SEF (210x297 mm)	A	A	A	A	A11
A4 LEF (297x210 mm)	A	A	A	---	---
A5 SEF (148x210 mm)	A	A	A	---	---
A5 LEF (210x148 mm)	A6	A6	A6	---	---
A6 SEF (105x148 mm)	A	B	---	---	---
B4 SEF (257x364 mm)	A	A	A	A	A11
B5 SEF (182x257 mm)	A	A	A	A	A11
B5 LEF (257x182 mm)	A	A	A	---	---
B6 SEF (128x182 mm)	A	A	B	---	---
DLT SEF (11x17 in.)	A	A	A	A	A11
Legal SEF (8.5x14 in.)	A	A	A	A	A11
Foolscap SEF (8.5x13 in.)	A	A	A	---	---
Letter SEF (8.5x11 in.)	A	A	A	A	A11
Letter LEF (11x8.5 in.)	A	A	A	---	---
Govt LG SEF (8.25x14 in.)	A	A	A	A	A11
Folio SEF (8.25x13 in.)	A	A	A	A	A11
F/GL SEF (8x13 in.)	A	A	A	---	---
G LT SEF (8x10.5 in.)	A	A	A	---	---
G LT LEF (10.5x8 in.)	A	A	A	---	---
Eng Quatro SEF (8x10 in.)	A	A	A	---	---
Eng Quatro LEF (10x8 in.)	A	A	A	---	---
Executive SEF (7.25x10.5 in.)	A	A	A	---	---
Executive LEF (10.5x7.25 in.)	A	A	A	---	---

	Exit				Folded
	Proof	Shift	Shifting	Booklet	Booklet
Half Letter SEF (5.5x8.5 in.)	A	A	A	---	---
Half Letter LEF (8.5x5.5 in.)	A6	A6	A6	---	---
8K SEF (267x390 mm)	A	A	A	---	---
16K SEF (195x267 mm)	A	A	A	---	---
16K LEF (267x195 mm)	A	A	A	---	---
11x15 SEF (11x15 in.)	A	A	A	A	A11
11x14 SEF (11x14 in.)	A	A	A	A	A11
10x15 SEF (10x15 in.)	A	A	A	A	A11
10x14 SEF (10x14 in.)	A	A	A	A	A11
8.5 x 13.4 SEF (8.5x13.4 in.)	A	A	A	A	A11

Stapling

	Stapled				
	Corner	Double	Sheets	Booklet	Sheets
A3 SEF (297x420 mm)	A	A	65	A	20
A4 SEF (210x297 mm)	A	A	65	A	20
A4 LEF (297x210 mm)	A	A	65	---	---
A5 SEF (148x210 mm)	---	---	---	---	---
A5 LEF (210x148 mm)	---	---	---	---	---
A6 SEF (105x148 mm)	---	---	---	---	---
B4 SEF (257x364 mm)	A	A	65	A	20
B5 SEF (182x257 mm)	A	A	65	A	20
B5 LEF (257x182 mm)	A	A	65	---	---
B6 SEF (128x182 mm)	---	---	---	---	---

	Stapled				
	Corner	Double	Sheets	Booklet	Sheets
DLT SEF (11x17 in.)	A	A	65	A	20
Legal SEF (8.5x14 in.)	A	A	65	A	20
Foolscap SEF (8.5x13 in.)	A	A	65	---	---
Letter SEF (8.5x11 in.)	A	A	65	A	20
Letter LEF (11x8.5 in.)	A	A	65	---	---
Govt LG SEF (8.25x14 in.)	A	A	65	A	20
Folio SEF (8.25x13 in.)	A	A	65	A	20
F/GL SEF (8x13 in.)	A	A	65	---	---
G LT SEF (8x10.5 in.)	---	---	---	---	---
G LT LEF (10.5x8 in.)	---	---	---	---	---
Eng Quatro SEF (8x10 in.)	---	---	---	---	---
Eng Quatro LEF (10x8 in.)	---	---	---	---	---
Executive SEF (7.25x10.5 in.)	A	A	65	---	---
Executive LEF (10.5x7.25 in.)	A	A	65	---	---
Half Letter SEF (5.5x8.5 in.)	---	---	---	---	---
Half Letter LEF (8.5x5.5 in.)	---	---	---	---	---
8K SEF (267x390 mm)	A	A	65	---	---
16K SEF (195x267 mm)	A	A	65	---	---
16K LEF (267x195 mm)	A	A	65	---	---
11x15 SEF (11x15 in.)	A	A	65	A	20
11x14 SEF (11x14 in.)	A	A	65	A	20
10x15 SEF (10x15 in.)	A	A	65	A	20
10x14 SEF (10x14 in.)	A	A	65	A	20
8.5 x 13.4 SEF (8.5x13.4 in.)	A	A	65	A	20

Punching

In the table below “EU-2” means European 2-hole punch, “NA-2”, “NA-3” means North American 2-hole, 3-hole punch, and “SC4” means Scandinavian 4-hole punch.

	Punch				
	EU-2	NA-2	NA-3	EU-4	SC-4
A3 SEF (297x420 mm)	A	A	A	A	A
A4 SEF (210x297 mm)	A	B	---	---	A
A4 LEF (297x210 mm)	A	A	A	A	A
A5 SEF (148x210 mm)	A	A	---	---	A
A5 LEF (210x148 mm)	A6	B	---	---	A6
A6 SEF (105x148 mm)	---	---	---	---	---
B4 SEF (257x364 mm)	A	A	A	A	A
B5 SEF (182x257 mm)	A	A	---	---	A
B5 LEF (257x182 mm)	A	A	A	A	A
B6 SEF (128x182 mm)	---	---	---	---	---
DLT SEF (11x17 in.)	A	A	A	A	A
Legal SEF (8.5x14 in.)	A	A	---	---	A
Foolscap SEF (8.5x13 in.)	A	A	---	---	A
Letter SEF (8.5x11 in.)	A	A	---	---	A
Letter LEF (11x8.5 in.)	A	A	A	A	A
Govt LG SEF (8.25x14 in.)	A	A	---	---	A
Folio SEF (8.25x13 in.)	A	A	---	---	A
F/GL SEF (8x13 in.)	A	A	---	---	A
G LT SEF (8x10.5 in.)	A	A	---	---	A
G LT LEF (10.5x8 in.)	A	A	A	A	A
Eng Quatro SEF (8x10 in.)	A	A	---	---	A

	Punch				
	EU-2	NA-2	NA-3	EU-4	SC-4
Eng Quatro LEF (10x8 in.)	A	A	A	A	A
Executive SEF (7.25x10.5 in.)	A	A	---	---	A
Executive LEF (10.5x7.25 in.)	A	A	A	A	A
Half Letter SEF (5.5x8.5 in.)	A	A	---	---	A
Half Letter LEF (8.5x5.5 in.)	A6	A6	---	---	A6
8K SEF (267x390 mm)	A	A	A	A	A
16K SEF (195x267 mm)	A	A	---	---	A
16K LEF (267x195 mm)	A	A	A	A	A
11x15 SEF (11x15 in.)	A	A	A	A	A
11x14 SEF (11x14 in.)	A	A	A	A	A
10x15 SEF (10x15 in.)	A	A	A	---	A
10x14 SEF (10x14 in.)	A	A	A	---	A
8.5 x 13.4 SEF (8.5x13.4 in.)	A	A	---	---	A

Multi-Folding Unit FD4000

	Exit	Straight Through
	Fold Tray	Downstream
A3 SEF (297x420 mm)	A15	A
A4 SEF (210x297 mm)	A15	A
A4 LEF (297x210 mm)	A	A
A5 SEF (148x210 mm)	A	A
A5 LEF (210x148 mm)	A6	A6
A6 SEF (105x148 mm)	A	A

	Exit	Straight Through
	Fold Tray	Downstream
B4 SEF (257x364 mm)	A15	A
B5 SEF (182x257 mm)	A	A
B5 LEF (257x182 mm)	A	A
B6 SEF (128x182 mm)	A	A
DLT SEF (11x17 in.)	A15	A
Legal SEF (8.5x14 in.)	A15	A
Foolscap SEF (8.5x13 in.)	---	A
Letter SEF (8.5x11 in.)	A15	A
Letter LEF (11x8.5 in.)	A	A
Govt LG SEF (8.25x14 in.)	---	A
Folio SEF (8.25x13 in.)	---	A
F/GL SEF (8x13 in.)	---	A
G LT SEF (8x10.5 in.)	---	A
G LT LEF (10.5x8 in.)	A	A
Eng Quatro SEF (8x10 in.)	A	A
Eng Quatro LEF (10x8 in.)	A	A
Executive SEF (7.25x10.5 in.)	---	A
Executive LEF (10.5x7.25 in.)	A	A
Half Letter SEF (5.5x8.5 in.)	A	A
Half Letter LEF (8.5x5.5 in.)	A6	A6
8K SEF (267x390 mm)	A15	A
16K SEF (195x267 mm)	---	A
16K LEF (267x195 mm)	A	A
11x15 SEF (11x15 in.)	---	A

	Exit	Straight Through
	Fold Tray	Downstream
11x14 SEF (11x14 in.)	---	A
10x15 SEF (10x15 in.)	---	A
10x14 SEF (10x14 in.)	---	A
8.5 x 13.4 SEF (8.5x13.4 in.)	A15	A

	FM1 Z-Fold	FM2 Half-Fold		FM3 Letter Out	
	Single	Single	Multi	Single	Multi
A3 SEF (297x420 mm)	A	A	A(3)1	A7	---
A4 SEF (210x297 mm)	A	A	A(3)1	A	A(3)1
A4 LEF (297x210 mm)	---	---	---	---	---
A5 SEF (148x210 mm)	---	---	---	---	---
A5 LEF (210x148 mm)	---	---	---	---	---
A6 SEF (105x148 mm)	---	---	---	---	---
B4 SEF (257x364 mm)	A	A	A(3)1	A7	A(3)1
B5 SEF (182x257 mm)	---	A	A(3)1	A	A(3)1
B5 LEF (257x182 mm)	---	---	---	---	---
B6 SEF (128x182 mm)	---	---	---	---	---
DLT SEF (11x17 in.)	A	A	A(3)1	A7	---
Legal SEF (8.5x14 in.)	A	A	A(3)1	A7	A(3)1
Foolscap SEF (8.5x13 in.)	---	---	---	---	---
Letter SEF (8.5x11 in.)	A	A	A(3)1	A	A(3)1
Letter LEF (11x8.5 in.)	---	---	---	---	---
Govt LG SEF (8.25x14 in.)	---	---	---	---	---

	FM1	FM2		FM3	
	Z-Fold	Half-Fold		Letter Out	
	Single	Single	Multi	Single	Multi
Folio SEF (8.25x13 in.)	---	---	---	---	---
F/GL SEF (8x13 in.)	---	---	---	---	---
G LT SEF (8x10.5 in.)	---	---	---	---	---
G LT LEF (10.5x8 in.)	---	---	---	---	---
Eng Quatro SEF (8x10 in.)	---	---	---	---	---
Eng Quatro LEF (10x8 in.)	---	---	---	---	---
Executive SEF (7.25x10.5 in.)	---	---	---	---	---
Executive LEF (10.5x7.25 in.)	---	---	---	---	---
Half Letter SEF (5.5x8.5 in.)	---	---	---	---	---
Half Letter LEF (8.5x5.5 in.)	---	---	---	---	---
8K SEF (267x390 mm)	A	A	A(3)1	A	---
16K SEF (195x267 mm)	---	---	---	---	---
16K LEF (267x195 mm)	---	---	---	---	---
11x15 SEF (11x15 in.)	---	---	---	---	---
11x14 SEF (11x14 in.)	---	---	---	---	---
10x15 SEF (10x15 in.)	---	---	---	---	---
10x14 SEF (10x14 in.)	---	---	---	---	---
8.5 x 13.4 SEF (8.5x13.4 in.)	A	A	A(3)1	A	A(3)1

	FM4		FM5	FM6
	Letter In		Dbl Parallel	Gate
	Single	Multi	Single	Single
A3 SEF (297x420 mm)	A7	A(3)1,7	A	A7,8

	FM4 Letter In		FM5 Dbl Parallel	FM6 Gate
	Single	Multi	Single	Single
A4 SEF (210x297 mm)	A	A(3)1	A	A
A4 LEF (297x210 mm)	---	---	---	---
A5 SEF (148x210 mm)	---	---	---	---
A5 LEF (210x148 mm)	---	---	---	---
A6 SEF (105x148 mm)	---	---	---	---
B4 SEF (257x364 mm)	A7	A(3)1,7	A	A7,8
B5 SEF (182x257 mm)	A	A(3)1	A	A
B5 LEF (257x182 mm)	---	---	---	---
B6 SEF (128x182 mm)	---	---	---	---
DLT SEF (11x17 in.)	A7	A(3)1,7	A	A7,8
Legal SEF (8.5x14 in.)	A7	A(3)1,7	A	A7,8
Foolscap SEF (8.5x13 in.)	---	---	---	---
Letter SEF (8.5x11 in.)	A	A(3)1	A	A
Letter LEF (11x8.5 in.)	---	---	---	---
Govt LG SEF (8.25x14 in.)	---	---	---	---
Folio SEF (8.25x13 in.)	---	---	---	---
F/GL SEF (8x13 in.)	---	---	---	---
G LT SEF (8x10.5 in.)	---	---	---	---
G LT LEF (10.5x8 in.)	---	---	---	---
Eng Quatro SEF (8x10 in.)	---	---	---	---
Eng Quatro LEF (10x8 in.)	---	---	---	---
Executive SEF (7.25x10.5 in.)	---	---	---	---
Executive LEF (10.5x7.25 in.)	---	---	---	---

	FM4 Letter In		FM5 Dbl Parallel	FM6 Gate
	Single	Multi	Single	Single
Half Letter SEF (5.5x8.5 in.)	---	---	---	---
Half Letter LEF (8.5x5.5 in.)	---	---	---	---
8K SEF (267x390 mm)	A	A(3)1	A	A
16K SEF (195x267 mm)	---	---	---	---
16K LEF (267x195 mm)	---	---	---	---
11x15 SEF (11x15 in.)	---	---	---	---
11x14 SEF (11x14 in.)	---	---	---	---
10x15 SEF (10x15 in.)	---	---	---	---
10x14 SEF (10x14 in.)	---	---	---	---
8.5 x 13.4 SEF (8.5x13.4 in.)	A	A(3)1	A	A

Cover Interposer Trays

The Cover Interposer Tray CI4030 (E-Type) is for the 3K Finisher, the Cover Interposer Tray CI4040 (F-type) is for 3K/2K Finisher.

	Straight Through
A3 SEF (297x420 mm)	A
A4 SEF (210x297 mm)	A
A4 LEF (297x210 mm)	A
A5 SEF (148x210 mm)	A
A5 LEF (210x148 mm)	A6
A6 SEF (105x148 mm)	A
B4 SEF (257x364 mm)	A
B5 SEF (182x257 mm)	A

	Straight Through
B5 LEF (257x182 mm)	A
B6 SEF (128x182 mm)	A
DLT SEF (11x17 in.)	A
Legal SEF (8.5x14 in.)	A
Foolscap SEF (8.5x13 in.)	A
Letter SEF (8.5x11 in.)	A
Letter LEF (11x8.5 in.)	A
Govt LG SEF (8.25x14 in.)	A
Folio SEF (8.25x13 in.)	A
F/GL SEF (8x13 in.)	A
G LT SEF (8x10.5 in.)	A
G LT LEF (10.5x8 in.)	A
Eng Quatro SEF (8x10 in.)	A
Eng Quatro LEF (10x8 in.)	A
Executive SEF (7.25x10.5 in.)	A
Executive LEF (10.5x7.25 in.)	A
Half Letter SEF (5.5x8.5 in.)	A
Half Letter LEF (8.5x5.5 in.)	A6
8K SEF (267x390 mm)	A
16K SEF (195x267 mm)	A
16K LEF (267x195 mm)	A
11x15 SEF (11x15 in.)	A
11x14 SEF (11x14 in.)	A
10x15 SEF (10x15 in.)	A
10x14 SEF (10x14 in.)	A

	Straight Through
8.5 x 13.4 SEF (8.5x13.4 in.)	A

Software Accessories

The printer drivers and utility software are provided on one CD-ROM. An auto-run installer allows you to select which components to install.

Y = Supported; N = Not Supported

Printer Drivers

Windows Environment

OS	Type	PCL5e	PCL6	PostScript3
Windows Vista	Starter	N	N	N
	Home Basic	Y	Y	Y
	Home Premium	Y	Y	Y
	Business	Y	Y	Y
	Ultimate	Y	Y	Y
	Enterprise	Y	Y	Y
Windows 7	Starter	N	N	N
	Home Basic	N	N	N
	Home Premium	Y	Y	Y
	Professional	Y	Y	Y
	Ultimate	Y	Y	Y
	Enterprise	Y	Y	Y
Windows 8	Windows 8	Y	Y	Y
	Pro	Y	Y	Y
	Enterprise	Y	Y	Y
	RT	N	N	N

OS	Type	PCL5e	PCL6	PostScript3
Windows 8.1	Windows 8.1	Y	Y	Y
	Pro	Y	Y	Y
	Enterprise	Y	Y	Y
Windows Server 2003	Standard Edition	Y*3	Y	Y
	Enterprise Edition	Y*3	Y	Y
	Datacenter Edition	N	N	N
	Web Edition	N	N	N
Windows Server 2003 R2	Standard Edition	Y*3	Y	Y
	Enterprise Edition	Y*3	Y	Y
	Datacenter Edition	N	N	N
Windows Server 2008	Standard Edition	Y	Y	Y
	Enterprise Edition	Y	Y	Y
	Datacenter Edition	N	N	N
	Web Edition	N	N	N
Windows Server 2008R2	Standard Edition	Y	Y	Y
	Enterprise Edition	Y	Y	Y
	Datacenter Edition	N	N	N
	Web Edition	N	N	N
Windows Server 2012	Foundation	Y	Y	Y
	Essentials	Y	Y	Y
	Standard	Y	Y	Y
	Datacenter	N	N	N

*RPCS driver has been discontinued.

Point and Print

Windows OS		Drivers		
Server	Client(Push to)	PCL5e	PCL6	PostScript3
Windows Server 2003 /2003 R2	7	Y	Y	Y
	8	Y	Y	Y
	Vista	Y	Y	Y
	XP	Y	Y	Y
	W2K Pro	N	N	N
Windows Server 2008	7	Y	Y	Y
	8	Y	Y	Y
	Vista	Y	Y	Y
	XP	Y	Y	Y
	W2K Pro	N	N	N
Windows Server 2008R2	7	Y	Y	Y
	8	Y	Y	Y
	Vista	Y	Y	Y
	XP	Y	Y	Y
	W2K Pro	N	N	N
Windows 2000 Professional Server & Advanced Server	7	N	N	N
	8	N	N	N
	Vista	N	N	N
	XP	N	N	N
	W2K Pro	N	N	N

Windows OS		Drivers		
Server	Client(Push to)	PCL5e	PCL6	PostScript3
Windows XP Professional	7	Y	Y	Y
	8	Y	Y	Y
	Vista	Y	Y	Y
	XP	Y	Y	Y
	W2K Pro	N	N	N
Windows Vista	7	Y	Y	Y
	8	Y	Y	Y
	Vista	Y	Y	Y
	XP	Y	Y	Y
	W2K Pro	N	N	N
Windows 7	7	Y	Y	Y
	8	Y	Y	Y
	Vista	Y	Y	Y
	XP	Y	Y	Y
	W2K Pro	N	N	N
Windows 8	7	Y	Y	Y
	8	Y	Y	Y
	Vista	Y	Y	Y
	XP	Y	Y	Y
	W2K Pro	N	N	N
Windows Server 2012	7	Y	Y	Y
	8	Y	Y	Y
	Vista	Y	Y	Y
	XP	Y	Y	Y

Mac OS and UNIX Environment

Mac OS

OS	PostScript3	Printer Utility for Mac
Mac OS 8.6 or later, Mac OS X classic	N	N
Mac OS X Native: v.10.7 or later	Y	N

Supported platforms for Unix filter

Platforms	Version
Sun Solaris	9, 10
HP-UX	11.x, 11i v2, 11i v3
Red Hat Linux	Enterprise V4, V5, V6
SCO OpenServer	5.0.7, 6.0
IBM AIX	V 5L, V5.3, V6.1, V7.1

Scanner and LAN Fax Drivers

Operating System	Driver	
	TWAIN* ⁹	LAN-FAX
Windows Vista* ^{1*5}	Y	Y
Windows 7* ^{2*5}	Y	Y
Windows 8* ^{5*6}	Y	Y
Windows 8.1	Y	Y
Windows Server 2003* ^{3*5}	Y	Y
Windows Server 2008* ^{4*5}	Y	Y
Windows Server 2012* ⁷	Y	Y
Macintosh	N	N

* 1 Microsoft Windows Vista Ultimate / Enterprise / Business / Home Premium / Home Basic

*2 Microsoft Windows 7 Home Premium / Professional / Ultimate / Enterprise

*3 Microsoft Windows Server 2003 Standard Edition / Enterprise Edition / Microsoft Windows Server 2003 R2 Standard Edition / Enterprise Edition

*4 Microsoft Windows Server 2008 Standard / Enterprise / Microsoft Windows Server 2008 R2 Standard / Enterprise

*5 Supports both 32bit, 64bit (Scanner driver works on 32bit compatible mode)

*6 Microsoft Windows 8 (Core Edition) / Pro / Enterprise

*7 Microsoft Windows Server 2012 Standard / Datacenter / Essentials

*8 TWAIN scanner runs on a 64-bit operating system, but is not compatible with 64-bit applications. Use it with 32-bit applications.

 **Note**

- With LAN-FAX driver, sending documents directly from PC will be available.
- Also Address Book Editor and Cover Sheet Editor will installed along.
- Network TWAIN driver will be provided on the scanner driver CD-ROM.

Optional Equipment Specifications

8 1/2"x14" Paper Size Tray Type M25 (B474)

Paper Size	B4, 8.5" x 14", A4 SEF, 8.5" x 11" SEF
Paper Weight	52 to 128 g/m ² (14 to 34 lb)
Tray Capacity	1,000 sheets (80 g/m ² , 20lb)

A3/11" x 17" Tray Type M25 (D615)

Paper Size	A3, B4, 11" x 17", 8.5" x 14", A4 SEF, A4 LEF, 8.5" x 11" SEF, 11" x 8.5" LEF
Paper Weight	52 to 163 g/m ² 16 to 40 lb. Bond 50 to 60 lb. Cover 90 lb. Index (no Tab)
Tray Capacity	1,000 sheets (80 g/m ² , 20lb)

LCIT RT4040 (D3A6)

Paper capacity	4,000 sheets
Paper Sizes	A4 LEF, B5 LEF, 8.5" x 11" LEF *1
Paper Weight	52 to 128 g/m ² (14 to 34 lb)
Pick-up and Feed	FRR (Feed and Reverse Roller)
Power Consumption	Less than 50 W (Max.)
Power Supply	DC24 V, 5V (powered by the main unit)
Rated Voltage of Output Connector	Max. DC 24 V
Dimensions (W x D x H)	314 x 458 x 659 mm (12.4" x 18.1" x 25.9")
Weight	20.0 kg (44 lb.)

* 1: In platen mode, APS (Auto Paper Select) with the original length and original width sensors are not used.

Finisher SR4080 (D610)

Upper Tray

Paper Capacity (80 g/m ²)	500 sheets (A4, 8.5" x 11" and smaller)
	250 sheets (B4, 8.5" x 14" and larger)
Paper Size	A3 to A6 SEF, 11" x 17" to 5.5" x 8.5", 12" x 18"
Paper Weight	52 to 216 g/m ² (14 to 58 lb)
Upper Tray Full Detection	Provided

Shift Tray

Paper Capacity (80 g/m ²)	3000 sheets (A4 LEF, B5 LEF, 8.5" x 11" LEF)
	1500 sheets (A3, A4 SEF, B4 and B5 SEF, 11" x 17", 8.5" x 14", 8.5" x 11" SEF, 12" x 18")
	500 sheets (A5 LEF, 5.5" x 8.5" LEF)
	100 sheets (A5 SEF, 5.5" x 8.5" SEF)
Paper Size	A3 to A5, 11" x 17" to 5.5" x 8.5", 12" x 18" (including tab paper)
Paper Weight	52 to 216 g/m ² (14 to 58 lb)
Shift Tray Full Detection	Provided

Stapler

Stapling Stack Size	A4, B5, 8.5" x 11" (Max. 100 Sheets)
	A3, B4, 11" x 17", 8.5" x 14" (Max. 50 sheets)
Stapling Paper Size	A3 to B5 11" x 17" to 8.5" x 11"

Stapling Paper Weight	64 to 80 g/m ² (17 to 20 lb)		
Staple Position	4 Modes <ul style="list-style-type: none"> • 1 Staple: Front, Rear, Rear-Oblique • 2 Staples: 2 locations 		
Staple Capacity	5000 staples/cartridge		
Staple Supply	Cartridge or Staple Replacement		
Stapled Stack Size	Sheets	Sets	Sizes
	10 to 100	200 to 30	A4 SEF, B5 SEF, 8.5" x 11" SEF
	2 to 9	150	A4 LEF, B5 LEF, 8.5" x 11" LEF
	10 to 50	150 to 30	A3, B4, 11" x 17", 8.5" x 14"
	2 to 9	150	
Trim Waste Staple Capacity	30,000 or more		
Waste Staple Hopper Full Detection	Provided		
Power Consumption	Less than 100 W		
Power Source	DC 24 V (From Mainframe)		
Size (W x D x H)	800 x 730 x 980 mm (31.5" x 28.7" x 38.6")		
Weight	Less than 65 kg (143 lb.)		

Punch Unit Type 1075 (B531)

This punch unit is installed in the Finisher SR4080.

Punch Hole Positions	2/3-hole (North America) 2/4-hole (Europe)
Punch Paper Size	
2-Hole (NA)	A5 to A3 SEF, 11" x 17" to 5.5" x 8.5" SEF A5 to A4 LEF, 8.5" x 11" LEF, 5.5" x 8.5" LEF

3-Hole (NA)	A3 SEF, B4 SEF, 11" x 17" SEF A4 LEF, B5 LEF, 8.5" x 11" LEF
4-Hole (EUR/A)	A3 SEF, 11" x 17" SEF A4 LEF, 8.5" x 11" LEF
Paper Weight	
2-Hole (NA)	52 g/m ² to 163 g/m ² (14 to 43 lb)
3-Hole (NA)	52 g/m ² to 163 g/m ² (14 to 43 lb)
4-Hole (EUR/A)	52 g/m ² to 128 g/m ² (14 to 34 lb)
Punch Waste Hopper Capacity	
2-Hole (NA)	10K
3-Hole (NA)	15K
4-Hole (EUR/A)	15K
Operation Modes	All (Shift, Proof, Staple)

DIP SW Settings

The correct DIP SW settings of the Punch Unit 531 are provided in the table below for your reference only. The DIP switches of these punch units do not need to be changed at installation, or adjusted for operation.

Punch Unit	Unit No.	DIP SW Settings			
		1	2	3	4
2/3-Hole (NA)	B531-17	1	0	1	0
2/4-Hole (EUR/A)	B531-27	1	0	0	1

0: OFF, 1: ON

Punch Unit Type 850 SC (A812)

This punch unit is installed in the Finisher SR4080..

Punch Hole Positions	2-hole, 3-hole (NA) 4-hole (EUR/A) 4-hole (North Europe)
Punch Paper Size	
2-Hole	A5 to A3 SEF, 11" x 17" to 8.5" x 11" SEF A5 to A4 LEF, 8.5" x 11" LEF
3-Hole (NA)	A3 SEF, B4 SEF, 11" x 17" SEF A4 LEF, B5 LEF, 8.5" x 11" LEF
4-Hole (EUR/A)	A3 SEF, 11" x 17" SEF A4 LEF, 11" x 17" LEF
4-Hole (North Europe)	B5 to A3 SEF, 8.5" x 11" to 11" x 17" SEF A5 to A4 LEF, 8.5" x 11" LEF, 5.5" x 8.5" LEF
Paper Weight	
2-Hole, 3-Hole (NA)	52 g/m ² to 163 g/m ² (14 to 43 lb)
4-Hole (Europe/North Europe)	52 g/m ² to 128 g/m ² (14 to 34 lb)
Punch Waste Hopper Capacity	
2-Hole	40K
3-Hole (NA)	15K
4-Hole (EUR/A)	15K
4-Hole (North Europe)	15K
Power Supply	DC 24 V (From Finisher)
Power Consumption	60 W
Weight	Less than 2.4 K (5.3 lb.)
Operation Modes	All (Shift, Proof, Staple)

DIP SW Settings

The correct DIP SW settings of the Punch Unit A812 are provided in the table below for your reference only. The DIP switches of these punch units do not need to be changed at installation, or adjusted for operation.

Punch Unit	Unit No.	DIP SW Settings			
		1	2	3	4
2-Hole (EUR/A)	A812-40/A812-67	0	0	0	0
3-Hole (NA)	A812-57	1	0	0	0
4-Hole EUR/A)	A812-30	0	1	0	0
4-Hole (North Europe)	A812-31	0	0	1	0
2-Hole (NA)	A812-32	0	0	0	1

0: OFF, 1: ON

Output Jogger Unit Type 9002B (B513)

This jogger unit is installed above the shift tray of the Finisher SR4080.

Paper Size	A3 SEF, B4 SEF, 11" x 17" SEF A4 LEF, B5 LEF, 8.5" x 11" LEF
Paper Weight	52 g/m ² to 216 g/m ² (14 to 58 lb)
Weight	Less than 1.7 kg (3.7 lb.)
Dimensions (W x D x H)	125 mm x 450 mm x 100 mm (5" x 17.7" x 4")
Power Supply	DC 24 V, DC 5V (From Finisher)
Power Consumption	24 W

Output Jogger Unit Type M25 (D3CJ)

This option is installed on the Booklet Finisher SR4130 or Finisher SR4120.

Paper Size	A3 SEF, B4 SEF, A4 LEF, B5 LEF, 11"×17" SEF, 8 1/2"×11" LEF
Power Supply	From main machine
Power Consumption	Less than 15W
Power Source	DC24V

Dimensions (W x D x H)	125×450×100 mm (5 x 18 x 4 in.)
Weight	1.7 kg (3.7 lb.)

Finisher SR4120 (D3CG)

This finisher provides corner stapling only.

Finisher

Dimensions (W x D x H)	657 x 613 x 960 mm		
Weight	Less than 54 kg Less than 56 kg with Punch Unit		
Power Consumption	Less than 96 W		
Noise	Less than 75 db		
Configuration	Console type attached base-unit		
Power Source	From base-unit		
Proof Tray	Stack Capacity*	250 sheets	A4, 8.5"x11" or smaller
		50 sheets	B4, 8.5"x14" or larger
	Paper Size	A5-A3 SEF, A6 SEF, A6 SEF 5.5"x8.5"-11"x17"SEF, 12"x18" SEF	
	Paper Weight	52 g/m ² -163 g/m ² 14 lb Bond- 43 lb Bond / 90 lb Index / 60 lb Cover	

Shift Tray	Stack Capacity*	3,000 sheets	A4 LEF, 1/2" x 11" LEF
		1,500 sheets	A3 SEF, A4 SEF, B4 SEF, B5, 11"x17" SEF, 8 1/2" x 14" SEF, 8 1/2" x 11" SEF, 12"x18" SEF
		500 sheets	A5 LEF**
		100 sheets	A5 SEF, B6 SEF, A6 SEF, 5 1/2" x 8 1/2", SEF
	Paper Size	A5 - A3 SEF, A6 SEF, B6 SEF, 5 1/2" x 8 1/2" - 11"x17" SEF, 12" x 18" SEF	
	Paper Weight	52 g/m ² -256 g/m ² 14 lb Bond- 68 lb Bond / 140 lb Index / 90 lb Cover	

Stapler

Paper Size	B5-A3 8.5"x11"-11"x17", 12"x18"		
Paper Weight	64 g/m ² -90 g/m ² 17 lb Bond-28 lb Bond		
Staple Position	Top, Bottom, 2 Staple, Top-slant		
Stapling Capacity	Same Paper Size	50 sheets	A4, 1/2" x 11" or smaller
		30 sheets	B4, 1/2" x 14" or larger
	Mixed Paper Size	30 sheets	A4 LEF + A3 SEF, B5 LEF + B4 SEF, 8 1/2" x 11" LEF + 11" x 17" SEF
Staple Replenishment	Cartridge exchange / 5000 pins per cartridge		

Stapled Stack Capacity (same size)	Paper Size	Pages/Set	Sets
	A4 LEF, 8.5"x11" LEF	20-50 pages	150-60 sets
		2-19 pages	150 sets
	A4 SEF, B5, 8.5"x11" SEF	15-50 pages	100-30 sets
		2-14 pages	100 sets
	Others	15-30 pages	100-33 sets
2-14 pages		100 sets	
Stapled Stack Capacity (mixed sizes)	A4 LEF & A3 SEF, B5 LEF & B4 SEF, 8.5"x11" LEF, 11" x17" SEF	2-30 pages	50 set

Booklet Finisher SR4130 (D3CH)

This finisher provides booklet as well as corner stapling. Equipped with two trays, the upper tray holds stapled and shifted copies, and the lower tray holds booklet stapled and folded copies.

Finisher

Dimensions (W x D x H)	657 x 613 x 960 mm (25.9 x 24.1 x 37.8")
Weight	Less than 63 kg (138.6 lb.) (no punch unit) Less than 65 kg (143 lb.) (with punch unit)
Power Consumption	Less than 96 W
Noise	Less than 75 db
Configuration	Console type attached base-unit
Power Source	From base-unit

Proof Tray	Stack Capacity*	250 sheets A4, 8.5"x11" or smaller 50 sheets B4, 8.5"x14 or larger	
	Paper Size	A5-A3 SEF, A6 SEF, A6 LEF 5 1/2" x 8 1/2" to 11" x 17" SEF, 12"x18" SEF	
	Paper Weight	52 g/m ² -163 g/m ² 14 lb Bond- 43 lb Bond / 90 lb Index / 60 lb Cover	
Shift Tray	Stack Capacity*	2,000 sheets	A4 LEF, 8.5"x11" LEF
		1,000 sheets	A3 SEF, A4 SEF, B4 SEF, B5 11"x17" SEF, 8 1/2" x 14" SEF, 8 1/2" x 11" SEF, 12"x18" SEF
		500 sheets	A5 LEF
		100 sheets	A5 SEF, B6 SEF, A6 SEF, 5 1/2" x 8 1/2" SEF
	Paper Size	A5 - A3 SEF, A6 SEF, B6 SEF 5 1/2" x 8 1/2" to 11" x 17" SEF, 12" x 18" SEF	
	Paper Weight	52 g/m ² -256 g/m ² 14 lb Bond- 68 lb Bond / 140 lb Index / 90 lb Cover	

Stapler

Paper Size	B5-A3, 8.5"x11"-11"x17", 12"x18"
Paper Weight	64 g/m ² -90 g/m ² , 17 lb Bond-28 lb Bond
Staple Position	Top, Bottom, 2 Staple, Top-slant

Staples Capacity*	Same Paper Size	50 sheets	A4, 8 1/2" x 11" or smaller
		30 sheets	B4, 8 1/2" x 14" or larger
	Mixed Paper Size	30 sheets	A4 LEF & A3 SEF, B5 LEF & B4 SEF, 8 1/2"x11" LEF & 11" x17" SEF
	Booklet Stapling	15 sheets	A4 SEF, A3 SEF, B5 SEF, B4 SEF, 8.5"x11" SEF, 8.5"x14" SEF, 11"x17" SEF, 12"x18" SEF
Staple Replenishment	Corner staple	5,000 staples per cartridge	
	Booklet staple	2,000 staples per cartridge	
Corner Staple Capacity	Same Size	A4 LEF, 8.5"x11" LEF	13-50 pages 2-12 pages
		A4 SEF, B5, 8.5"x11" SEF	10-50 pages 2-9 pages
		Others	10-30 pages 2-9 pages
	Mixed Size	A4 LEF + A3 SEF B5 LEF + B4 SEF 8.5"x11" LEF + 11" x17" SEF	2-30 pages
Booklet Staple Capacity	A4 SEF, A3 SEF, B5 SEF, B4 SEF 8.5"x11" SEF, 8.5"x14" SEF, 11"x17" SEF 12"x18" SEF	2-5 pages 6-10 pages 11-15 pages	

SR4120/SR4130 Paper Specifications

Paper Size	Plain Paper			Paper Type	
	Copier PPC	Used Paper	Recycled Paper	Colored Paper	Translucent Blueprint
A3 SEF	●	—	●	●	▲
B4 SEF	●	▲	●	●	▲
A4 SEF	●	▲	●	●	▲
A4 LEF	◆	▲	◆	◆	▲
B5 SEF	●	▲	●	●	▲
B5 LEF	◆	▲	◆	◆	▲
A5 SEF	○	—	—	—	—
A5 LEF	○	—	—	—	—
B6 SEF	▲	—	—	—	—
B6 LEF	▲	—	—	—	—
12" x 18" SEF	●	—	●	●	—
11" x 17" SEF	●	—	●	●	▲
8 1/2" x 14"	●	—	●	●	▲
8 1/2" x 11" SEF	●	—	●	●	▲
8 1/2" x 11" LEF	◆	▲	◆	◆	▲
5 1/2" x 8 1/2"	○	—	—	○	—
5 1/2" x 8 1/2"	○	—	—	○	—

- ◆: Corner stapling, Shift, YES
- : Booklet stapling/folding, Shift, YES
- : Shift ONLY
- ▲: Shift NO
- : Not available

Punch Unit Type 3060 (B706)

This punch unit is designed for use with the Finisher SR4060 and Finisher SR4070. There are three variations of this punch unit:

- Punch Unit Type 3060 SC (B706)
- Punch Unit Type 3060 2/4 EU (B706)
- Punch Unit Type 3060 NA 3/2 (B706)

Available Punch Units	NA	2/3 hole switchable
	EU	2/4 holes switchable
	Scandinavia	4 holes
Punch Waste Replenishment	NA 2-hole	Up to 5,000 sheets
	NA 3-hole	Up to 5,000 sheets
	EU 2-hole	Up to 14,000 sheets
	EU 4-hole	Up to 7,000 sheets
	Scandinavia 4-hole	Up to 7,000 sheets
Paper Weight	52 g/m ² -163 g/m ² , 14 lb Bond to 43 lb Bond / 90 lb Index / 60 lb Cover	

Paper Sizes	NA 2-hole	SEF	A5 to A3, 5 $\frac{1}{2}$ " x 8 $\frac{1}{2}$ " to 11" x 17"
		LEF	A5 - A4, 5 $\frac{1}{2}$ " x 8 $\frac{1}{2}$ ", 8 $\frac{1}{2}$ " x 11"
	NA 3-hole	SEF	A3, B4, 11" x 17"
		LEF	A4, B5, 8 $\frac{1}{2}$ " x 11"
	EU 2-hole	SEF	A5 - A3, 5 $\frac{1}{2}$ " x 8 $\frac{1}{2}$ " to 11" x 17"
		LEF	A5 to A4, 5 $\frac{1}{2}$ " x 8 $\frac{1}{2}$ ", 8 $\frac{1}{2}$ " x 11"
	EU 4-hole	SEF	A3, B4, 11" x 17"
		LEF	A4, B5, 8 $\frac{1}{2}$ " x 11"
	Scandinavia 4-hole	SEF	A5 to A3, 5 $\frac{1}{2}$ " x 8 $\frac{1}{2}$ " to 11" x 17"
		LEF	A5 - A4, 5 $\frac{1}{2}$ " x 8 $\frac{1}{2}$ ", 8 $\frac{1}{2}$ " x 11"

Mail Box CS4010 (D708)

The mailbox can be installed on top of the Finisher SR4060, SR4070, or SR4080.

Dimensions (w x d x h)	540 x 600 x 660 mm (21.3 x 23.6 x 26 in.)
Weight	Less than 15 kg (33 lb.)
Power Consumption	Less than 48 W
Noise	Less than 74 dB
Number of Bins	9 bins
Stack Capacity of each Bin	100 sheets*
Paper Size	A5, A4, A3 5 $\frac{1}{2}$ " x 8 $\frac{1}{2}$ ", 8 $\frac{1}{2}$ " x 11", 8 $\frac{1}{2}$ " x 14", 11" x 17"

Paper Weight	52 - 128g/m ²
	14 lb – 34 lb Bond

Cover Interposer Tray CI4040 (DC3N)

Dimension (W x D x H)	500 x 600 x 600 mm (19.7 x 23.6 x 23.6 in.)	
Weight	Less than 12 Kg (26.4 lb.)	
Power Consumption	Less than 43 W	
Noise	Less than 65 db	
Stack Capability*	200 Sheets	
Paper Size	A5-A3, 5 1/2" x 8 1/2" - 11" x 17"	
Paper Weight	64 g/m ² -216 g/m ² 17 lb. Bond- 80 lb. b Cover	
Original Set Position	Center	
Original Set	Normal Feed	Face-up
	Booklet Feed	Face-down

Cover Interposer Tray CI4030 (D3D7)


Configuration	Stack cover inserter for finisher
Paper Separation at Feed	Standard FRR
Feed Mechanism	Feed Rollers
Paper Weight	64 to 216 g/m ²
Paper Size	A3 SEF, B4 SEF, A4 LEF/SEF, B5 LEF/SEF, A5 LEF/SEF, 11×17 SEF, 8 1/2"×11 LEF/SEF
Allowed Curl	H: Less than 5 mm
Stack Size	200 sheets
Paper Detection	None

Power Consumption	Less than 43W
Power Supply	Main Machine
Dimension (W x D x H)	500×600×600 mm (20 x 23.5 x 23.5 in.)
Weight	12 kg (35.2 lb.)

Multi Folding Unit FD4000 (D615)

General

Dimensions (W × D × H)	470 × 980 × 730 mm (18.6 × 38.6 × 28.8 in.)	
Weight	Approx. 92 kg (202.9 lb.)	
Power Consumption	Maximum 270 W (A separate power source is required.)	
Power Source	220 - 240 V, 50/60 Hz, 1.2 A	
Operating Environment	Temperature and humidity ranges: Same as main machine.	
Paper Weight	Single sheet mode: 64 to 103 g/m ² (17 lb. Bond - 28 lb. Bond) Multiple sheets mode: 64 to 80 g/m ² (17 lb. Bond - 20 lb. Bond)	
Folding Methods	6 (see below)	
Speed	Straight-Through	100 to 700 mm/s
	Folding	270 to 700 mm/s
Straight-Through Feed	Size	Postcard to 13x19.2"
	Type	Used paper: A3, A4, B4, B5 OHP: A4, B5 Tap paper: A4 LEF, LT LEF
Folding Methods	6 (FM1 to FM6)	



FM1: Z-Folding
 FM2: Half Fold
 FM3: Letter Fold-out
 FM4: Letter Fold-in
 FM5: Double Parallel Fold
 FM6: Gate Fold

d454v900

Paper Sizes (Folding)	FM1	A3, B4, DLT, LG, A4, LT, 12x18", 8-kai
	FM2	A3, B4, DLT, LG, A4, B5, LT 12x18", 12.6x18.5", 12.6x19.2", 13x18", 13x19", 13x19.2", 226x310 mm, 310x432 mm, SRA3, SRA4, 8-kai
	FM3	A3, B4, DLT, LG, A4, LT, B5, 12x18", 8-kai
	FM4	
	FM5	
	FM6	
Paper Weights (Folding)	FM1	64 to 105 g/m ²
	FM2	
	FM3	
	FM4	
	FM5	
	FM6	
Multiple Folding	FM1	Not allowed
	FM2	Max. 3 (64 to 80 g/m ² only)
	FM3	Max. 3 (64 to 80 g/m ² only)

	FM4	Max. 3 (64 to 80 g/m ² , B4, A4, LT, B5 only)
	FM5	Not allowed
	FM6	
Line Speed (Only FM1 Z-Folded paper can exit downstream)		
No Fold	350 mm/sec. to top tray To downstream: Same as main machine.	
FM1	700 mm/sec. to top tray (paper \leq 355.6 mm long) 450 mm/sec. to top tray (paper < 355.6 mm long) To downstream: Same as main machine.	
FM2	1 Sheet: Same as main machine 2-3 Sheets: 454 mm/sec. 700 mm/sec. to top tray (paper \leq 355.6 mm long) 350 mm/sec. to top tray (paper \leq 279.4 < 355.6 mm long) 250 mm/sec. to top tray (paper < 279.4 mm long)	
FM3 FM4	1 Sheet: Same as main machine 2-3 Sheets: 454 mm/sec. to top tray 350 mm/sec. to top tray (paper \leq 420 mm long) 250 mm/sec. to top tray (paper < 420 mm long)	
FM5	1 Sheet: Same as main machine 350 mm/sec. to top tray (paper \leq 420 mm long) 250 mm/sec. to top tray (paper < 420 mm long)	
FM6	1 Sheet: Same as main machine as far as 3rd Stopper. At 3rd stopper feeds 50 mm at 100 mm/sec. 350 mm/sec. to top tray (paper \leq 420 mm long) 250 mm/sec. to top tray (paper < 420 mm long)	
Power Supply	NA	AC 120V 60 Hz, 15A
	EU	AC 220 to 240V, 50/60 Hz 10A
Power Consumption	270 W	
Size (w x d x h)	466 x 980 x 730 mm (18.4 x 38.6 x 28.7 in.)	


Level	Less than 5 mm deviation at front/back, left/right		
Weight	92 kg (203 lb)		
Noise Level (dB A)	Mode	Alone	System
	No Folding	< 76 dB	---
	Folding	< 78 dB	< 83 dB

Tray Capacity

The capacity of the tray on top of the unit for folded paper is determined by these variables:


- Folding Methods (FM1 to FM6)
- Paper size
- Paper weight

Folding Mode FM1




Size	Weight (Standard) 64 to 80 g/m ²	Weight (Heavy) 64 to 80 g/m ²
8-kai	35	20
12x18"	35	20
A3 SEF	35	20
DLT	35	20
B4 SEF	35	20
LG SEF	35	20
A4 SEF	30	20
LT SEF	30	20

Folding Mode FM2




Size	Weight (Standard) 64 to 80 g/m ²	Weight (Heavy) 64 to 80 g/m ²
13x19.2"	40	25
13x19"	40	25
12.6x19.2"	40	25
12.6x18.5"	40	25
13x18"	40	25
SRA3 (320x450 mm)	40	25
SRA4 (225x320 mm)	40	25
226x310 mm	40	25
310x432 mm	40	25
8-kai	40	25
12x18"	40	25
A3 SEF	40	25
DLT	40	25
B4 SEF	40	25
LG SEF	40	25
A4 SEF	50	50
LT SEF	50	50
B5 SEF	50	50

Folding Mode FM3



Size	Weight (Standard) 64 to 80 g/m ²	Weight (Heavy) 64 to 80 g/m ²
8-kai	30	20
12x18"	30	20
A3 SEF	30	20
DLT	30	20
B4 SEF	30	20
LG SEF	30	20
A4 SEF	40	30
LT SEF	40	30
B5 SEF	40	30


Folding Mode FM4



Size	Weight (Standard) 64 to 80 g/m ²	Weight (Heavy) 64 to 80 g/m ²
8-kai	40	20
12x18"	40	20
A3 SEF	40	20
DLT	40	20
B4 SEF	40	20


Size	Weight (Standard) 64 to 80 g/m ²	Weight (Heavy) 64 to 80 g/m ²
LG SEF	40	20
A4 SEF	50	40
LT SEF	50	40
B5 SEF	50	40

Folding Mode FM5



Size	Weight (Standard) 64 to 80 g/m ²	Weight (Heavy) 64 to 80 g/m ²
8-kai	30	20
12x18"	30	20
A3 SEF	30	20
DLT	30	20
B4 SEF	30	20
LG SEF	30	20
A4 SEF	30	30
LT SEF	30	30
B5 SEF	30	30

Folding Mode FM6



Size	Weight (Standard) 64 to 80 g/m ²	Weight (Heavy) 64 to 80 g/m ²
8-kai	50	20
12x18"	50	20
A3 SEF	50	20
DLT	50	20
B4 SEF	50	20
LG SEF	50	20
A4 SEF	30	30
LT SEF	30	30
B5 SEF	30	30

2. Engine SP Mode Tables

Engine SP Tables-1

SP1-XXX (Feed)

2

1001	[Leading Edge Registration]		
1-001-001	Std Tray: Feed LCT: Duplex	ENG	[-9.0 to 9.0 / 0 / 0.1 mm / step]
1-001-002	By-pass	ENG	[-9.0 to 9.0 / 0 / 0.1 mm / step]
1-001-003	Thick Paper: Std Tray: Feed LCT: Duplex	ENG	[-9.0 to 9.0 / 0 / 0.1 mm / step]
1-001-004	Thick Paper: By-pass	ENG	[-9.0 to 9.0 / 0 / 0.1 mm / step]

1002	[Side-to-Side Registration]		
1-002-001	Tray-1	ENG	[-9.0 to 9.0 / 0 / 0.1 mm / step]
1-002-002	Tray-2	ENG	[-9.0 to 9.0 / 0 / 0.1 mm / step]
1-002-003	Tray-3	ENG	[-9.0 to 9.0 / 0 / 0.1 mm / step]
1-002-004	Tray-4	ENG	[-9.0 to 9.0 / 0 / 0.1 mm / step]
1-002-005	By-pass Tray	ENG	[-9.0 to 9.0 / 0 / 0.1 mm / step]
1-002-006	LCT	ENG	[-9.0 to 9.0 / 0 / 0.1 mm / step]
1-002-007	Duplex Tray	ENG	[-9.0 to 9.0 / 0 / 0.1 mm / step]

1003	[Registration Buckle Adjustment]		
1-003-001	Tray LCT	ENG	[-9 to 9 / 0 / 1 mm / step]
1-003-002	Duplex Tray	ENG	[-9 to 9 / 0 / 1 mm / step]
1-003-003	By-pass Tray	ENG	[-9 to 9 / 0 / 1 mm / step]
1-003-004	ThickPaper Tray	ENG	[-9 to 9 / 0 / 1 mm / step]

1-003-005	ThickPaper Duplex Tray	ENG	[-9 to 9 / 0 / 1 mm / step]
-----------	------------------------	-----	-----------------------------

1007	[By-pass FeedPaper Size Display]		
1-007-001	-	ENG	[0x00 to 0xFF / 0x00 / 1 / step]

1008	[Duplex Fence Adjustment]		
1-008-001	-	ENG	[-5.0 to 5.0 / 0 / 0.1 mm / step]

1016	[Fine Adjust Reg Roller Speed]		
1-016-001	Normal Paper:Front Side	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-002	Normal Paper:Back Side	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-003	Med Thick:Front Side	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-004	Med Thick:Back Side	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-005	Thick Paper1:Front Side	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-006	Thick Paper1:Back Side	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-007	Thick Paper2:Front Side	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-008	Thick Paper2:Back Side	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-009	Thick Paper3:Front Side	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-010	Thick Paper3:Back Side	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-011	Thick Paper4:Back Side	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-012	Cardstock	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]

1-016-013	OHP	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-014	Tracing Paper	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-015	Envelope	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-016	Label	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-017	Postcard	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-101	Normal Paper:Front Side: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-102	Normal Paper:Back Side: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-103	Med Thick:Front Side: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-104	Med Thick:Back Side: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-105	Thick Paper1:Front Side: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-106	Thick Paper1:Back Side: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-107	Thick Paper2:Front Side: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-108	Thick Paper2:Back Side: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-109	Thick Paper3:Front Side: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-110	Thick Paper3:Back Side: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-111	Thick Paper4:Front Side: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-112	Cardstock: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-113	OHP: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]

1-016-114	Tracing Paper: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-115	Envelope: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-116	Label: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]
1-016-117	Postcard: Low Speed	ENG	[-3.0 to 3.0 / 0 / 0.1% / step]

1102	[Fusing Temperature Adjustment]		
1-102-001	Duplex Actual Temperature	ENG*	[0 or 1 / 0 / 1 / step]
1-102-002	Duplex Balance Temp (Center Thermistor)	ENG*	[-30 to 0 / -15 / 1 deg / step]
1-102-003	Duplex Balance Temp (End Thermistor)	ENG*	[-30 to 0 / -15 / 1 deg / step]

1103	[Fusing Idling]		
1-103-001	IdlingTime(Nomal)	ENG*	MP 6503 SP/7503 SP: [0 to 300 / 6 / 1 sec / step] MP 9003 SP: [0 to 300 / 160 / 1 sec / step]
1-103-002	IdlingTime(Low)	ENG*	MP 6503 SP/7503 SP: [0 to 300 / 66 / 1 sec / step] MP 9003 SP: [0 to 300 / 200 / 1 sec / step]
1-103-003	IdlingTime(LowPower)	ENG*	[0 to 300 / 0 / 1 sec / step]
1-103-004	IdlingTime(LowVoltage)	ENG*	MP 6503 SP/7503 SP: [0 to 300 / 8 / 1 sec / step] MP 9003 SP: [0 to 300 / 260 / 1 sec / step]
1-103-005	IdlingTime(CapacitorLowVoltage)	ENG*	[0 to 300 / 90 / 1 sec / step]
1-103-006	IdlingTime: 20s	ENG*	[0 to 300 / 0 / 1 sec / step]

1-103-007	IdlingTime: Warm	ENG *	[0 to 300 / 0 / 1 sec / step]
-----------	------------------	-------	-------------------------------

1105	[Fusing Temperature Adjustment]		
1-105-001	Normal Time (Center Thermistor)	ENG *	MP 6503 SP/7503 SP: [130 to 220 / 205 / 1 deg / step] MP 9003 SP: [130 to 220 / 205 / 1 deg / step]
1-105-002	Normal Time (End Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 180 / 1 deg / step] MP 9003 SP: [100 to 220 / 150 / 1 deg / step]
1-105-003	OHP (Center Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 210 / 1 deg / step] MP 9003 SP: [100 to 220 / 1700 / 1 deg / step]
1-105-004	OHP (End Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 195 / 1 deg / step] MP 9003 SP: [100 to 220 / 170 / 1 deg / step]
1-105-005	Thick Paper 1,2 (Center Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 220 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-105-006	Thick Paper 1,2 (End Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 205 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-105-007	Normal Paper (Center Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 215 / 1 deg / step] MP 9003 SP: [100 to 220 / 185 / 1 deg / step]

1-105-008	Normal Paper (End Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 200 / 1 deg / step] MP 9003 SP: [100 to 220 / 185 / 1 deg / step]
1-105-009	Small Size Normal Paper (Center Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 210 / 1 deg / step] MP 9003 SP: [100 to 220 / 185 / 1 deg / step]
1-105-010	Small Size Thick Paper 1,2 (Center Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 210 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-105-011	Label (Center Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 220 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-105-012	Label (End Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 205 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-105-013	Tab Sheet (Center Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 220 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-105-014	Tab Sheet (End Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 205 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]

1-105-015	Thick Paper 3 (Center Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 220 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-105-016	Thick Paper 3 (End Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 205 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-105-017	Small Size Thick Paper 3 (Center Thermistor)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 210 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-105-018	Temp: Ready2: Thermistor: Center	ENG *	MP 6503 SP/7503 SP: [130 to 220 / 190 / 1 deg / step] MP 9003 SP: [100 to 220 / 170 / 1 deg / step]
1-105-019	Time: Ready2: Thermistor: Center	ENG *	MP 6503 SP/7503 SP: [20 to 300 / 20 / 1 sec / step] MP 9003 SP: [20 to 300 / 60 / 1 sec / step]
1-105-020	Temp: Ready2: Thermistor: End	ENG *	MP 6503 SP/7503 SP: [130 to 220 / 165 / 1 deg / step] MP 9003 SP: [130 to 220 / 150 / 1 deg / step]
1-105-021	Time: Ready2: Thermistor: End	ENG *	MP 6503 SP/7503 SP: [20 to 300 / 20 / 1 sec / step] MP 9003 SP: [20 to 300 / 60 / 1 sec / step]

1106	[Fusing Temperature Display]		
1-106-001	Center Temperature	ENG	[0 to 0 / 0 / 0 deg / step]

1-106-002	End Temperature	ENG	[0 to 0 / 0 / 0 deg / step]
1-106-003	Pressure Roller Temperature	ENG	[0 to 0 / 0 / 0 deg / step]

1107	[Start Fusing Temp. Time Adj.]		
1-107-001	Center Lamp Temperature	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 220 / 1 deg / step] MP 9003 SP: [100 to 220 / 190 / 1 deg / step]
1-107-002	End Lamp Temperature	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 210 / 1 deg / step] MP 9003 SP: [100 to 220 / 190 / 1 deg / step]
1-107-003	Center Lamp Actual Time	ENG *	MP 6503 SP/7503 SP: [0 to 120 / 60 / 1 sec / step] MP 9003 SP: [0 to 120 / 10 / 1 sec / step]
1-107-004	End Lamp Actual Time	ENG *	MP 6503 SP/7503 SP: [0 to 120 / 55 / 1 sec / step] MP 9003 SP: [0 to 120 / 10 / 1 sec / step]
1-107-005	Center Lamp Temp (Small Size Paper)	ENG *	MP 6503 SP/7503 SP: [140 to 220 / 220 / 1 deg / step] MP 9003 SP: [140 to 220 / 190 / 1 deg / step]
1-107-006	Center Lamp Actual Time (Small Size Paper)	ENG *	MP 6503 SP/7503 SP: [0 to 120 / 60 / 1 sec / step] MP 9003 SP: [0 to 120 / 10 / 1 sec / step]

1-107-007	Center Lamp Temp (Thick Paper 1,2)	ENG*	MP 6503 SP/7503 SP: [140 to 220 / 220 / 1 deg / step] MP 9003 SP: [140 to 220 / 200 / 1 deg / step]
1-107-008	Center Lamp Actual Time (Thick Paper 1,2)	ENG*	MP 6503 SP: [0 to 120 / 0 / 1 sec / step] MP 7503 SP: [0 to 120 / 5 / 1 sec / step] MP 9003 SP: [0 to 120 / 10 / 1 sec / step]
1-107-009	Capacitor Heater Temperature	ENG*	[120 to 220 / 200 / 1 deg / step]
1-107-010	Capacitor Heater Actual Time	ENG*	MP 6503 SP/MP 9003 SP: [0 to 120 / 0 / 1 sec / step] MP 7503 SP: [0 to 120 / 60 / 1 sec / step]
1-107-011	Center Lamp Temp (Label)	ENG*	MP 6503 SP/7503 SP: [100 to 220 / 220 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-107-012	Center Lamp Actual Time (Label)	ENG*	[0 to 120 / 0 / 1 sec / step]
1-107-013	End Lamp Temp (Label)	ENG*	MP 6503 SP/7503 SP: [100 to 220 / 205 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-107-014	Center Lamp Actual Time (Label)	ENG*	[0 to 120 / 0 / 1 sec / step]

1-107-015	Center Lamp Temp (Tab Sheet)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 220 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-107-016	Center Lamp Actual Time (Tab Sheet)	ENG *	[0 to 120 / 0 / 1 sec / step]
1-107-017	End Lamp Temp (Tab Sheet)	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 205 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-107-018	End Lamp Actual Time (Tab Sheet)	ENG *	[0 to 120 / 0 / 1 sec / step]
1-107-019	Center Lamp Temperature	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 205 / 1 deg / step] MP 9003 SP: [100 to 220 / 190 / 1 deg / step]
1-107-020	End Lamp Temperature	ENG *	MP 6503 SP/7503 SP: [100 to 220 / 205 / 1 deg / step] MP 9003 SP: [100 to 220 / 190 / 1 deg / step]
1-107-021	Center Lamp Actual Time	ENG *	MP 6503 SP/7503 SP: [0 to 120 / 60 / 1 sec / step] MP 9003 SP: [0 to 120 / 10 / 1 sec / step]
1-107-022	End Lamp Actual Time	ENG *	MP 6503 SP/7503 SP: [0 to 120 / 55 / 1 sec / step] MP 9003 SP: [0 to 120 / 10 / 1 sec / step]

1-107-023	Capacitor Heater Temperature	ENG *	MP 6503 SP/9003 SP: [140 to 220 / 200 / 1 deg / step] MP 7503 SP: [140 to 220 / 195 / 1 deg / step]
1-107-024	Capacitor Heater Actual Time	ENG *	MP 6503 SP/9003 SP: [0 to 120 / 0 / 1 sec / step] MP 7503 SP: [0 to 120 / 17 / 1 sec / step]
1-107-025	Center Lamp Temperature (Warm Paper 1)	ENG *	[100 to 220 / 205 / 1 deg / step]
1-107-026	End Lamp Temperature (Warm Paper 1)	ENG *	[100 to 220 / 205 / 1 deg / step]
1-107-027	Center Lamp Actual Time (Warm Paper 1)	ENG *	MP 6503 SP/7503 SP: [0 to 120 / 60 / 1 sec / step] MP 9003 SP: [0 to 120 / 10 / 1 sec / step]
1-107-028	End Lamp Actual Time (Warm Paper 1)	ENG *	MP 6503 SP/7503 SP: [0 to 120 / 55 / 1 sec / step] MP 9003 SP: [0 to 120 / 10 / 1 sec / step]
1-107-029	Center Lamp Temp (Thick Paper 3)	ENG *	MP 6503 SP/7503 SP: [140 to 220 / 220 / 1 deg / step] MP 9003 SP: [140 to 220 / 200 / 1 deg / step]
1-107-030	Center Lamp Actual Time (Thick Paper 3)	ENG *	MP 6503 SP: [0 to 120 / 0 / 1 sec / step] MP 7503 SP: [0 to 120 / 5 / 1 sec / step] MP 9003 SP: [0 to 120 / 10 / 1 sec / step]

1-107-031	Capacitor Heater Temperature (Warm Paper 1)	ENG*	MP 6503 SP: [120 to 220 / 205 / 1 deg / step] MP 7503 SP: [120 to 220 / 200 / 1 deg / step] MP 9003 SP: [120 to 220 / 190 / 1 deg / step]
1-107-032	Capacitor Heater Actual Time (Warm Paper 1)	ENG*	MP 6503 SP/9003 SP: [0 to 120 / 0 / 1 sec / step] MP 7503 SP: [0 to 120 / 17 / 1 sec / step]
1-107-033	Temp: Thick Paper1, 2: Heater: Center	ENG*	MP 6503 SP/7503 SP: [100 to 220 / 205 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-107-034	Time: Thick Paper1, 2: Heater: Center	ENG*	[0 to 120 / 0 / 1 sec / step]
1-107-035	Temp: Thick Paper1, 2: Heater: End	ENG*	MP 6503 SP/7503 SP: [100 to 220 / 205 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-107-036	Time: Thick Paper1, 2: Heater: End	ENG*	[0 to 120 / 0 / 1 sec / step]
1-107-037	Temp: Thick Paper3: Heater: Center	ENG*	MP 6503 SP/7503 SP: [100 to 220 / 205 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-107-038	Time: Thick Paper3: Heater: Center	ENG*	[0 to 120 / 0 / 1 sec / step]

1-107-039	Temp: Thick Paper3: Heater: End	ENG*	MP 6503 SP/7503 SP: [100 to 220 / 205 / 1 deg / step] MP 9003 SP: [100 to 220 / 195 / 1 deg / step]
1-107-040	Time: Thick Paper3: Heater: End	ENG*	[0 to 120 / 0 / 1 sec / step]

1108	[Environment Correction]		
1-108-001	Corr Temp: Low Temp: Start-up	ENG*	[0 to 20 / 0 / 1 deg / step]
1-108-002	Corr Temp: Low Temp (PI1)	ENG*	[0 to 20 / 0 / 1 deg / step]
1-108-003	Corr Temp: Low Temp (PI2)	ENG*	[0 to 20 / 0 / 1 deg / step]
1-108-004	Corr Temp: Low Temp (TH1,2)	ENG*	[0 to 20 / 0 / 1 deg / step]
1-108-005	Corr Temp: Low Temp (TH3)	ENG*	[0 to 20 / 0 / 1 deg / step]
1-108-006	Corr Temp: Low Temp (OHP)	ENG*	[0 to 20 / 0 / 1 deg / step]
1-108-007	Corr Temp: Low Temp (LbI)	ENG*	[0 to 20 / 0 / 1 deg / step]
1-108-008	Corr Temp: Low Temp (Indx)	ENG*	[0 to 20 / 0 / 1 deg / step]
1-108-009	Corr Temp Cap: Low Temp (PI1)	ENG*	[0 to 20 / 0 / 1 deg / step]
1-108-010	Corr Temp Cap: Low Temp (PI2)	ENG*	[0 to 20 / 0 / 1 deg / step]
1-108-011	Corr Temp Cap: Low Temp (TH1,2)	ENG*	[0 to 20 / 0 / 1 deg / step]
1-108-012	Corr Temp Cap: Low Temp (TH3)	ENG*	[0 to 20 / 0 / 1 deg / step]

1-108-013	Corr Temp Cap: Low Temp (OHP)	ENG *	[0 to 20 / 0 / 1 deg / step]
1-108-014	Corr Temp Cap: Low Temp (Lbl)	ENG *	[0 to 20 / 0 / 1 deg / step]
1-108-015	Corr Temp Cap: Low Temp (Indx)	ENG *	[0 to 20 / 0 / 1 deg / step]

1109	[Measure Nip Width]		
1-109-001	Execute	ENG	[0 or 1 / 0 / 1 / step]
1-109-002	Nip Width (Adjust Value)	ENG *	[200 to 400 / 300 / 10 mm / step]

1112	[Auto Process Co]		
1-112-001	-	ENG *	[70 to 150 / 140 / 1 deg / step]

1159	[Fusing Jam SC Setting]		
1-159-001	-	ENG *	[0 or 1 / 0 / 1 / step]

1901	[CPM Down for Special Paper]		
1-901-001	Thick Paper CPM (0:25/1:35/2:40/3:45/4:55)	ENG *	MP 6503 SP/7503 SP: [0 to 4 / 2 / 1 / step] MP 9003 SP: [0 to 4 / 3 / 1 / step]
1-901-002	Tab Sheet CPM (0:25/1:35/2:40/3:45/4:55)	ENG *	[0 to 4 / 0 / 1 / step]
1-901-003	Label CPM (0:25/1:35/2:40/3:45/4:55)	ENG *	[0 to 4 / 0 / 1 / step]
1-901-004	Special Paper CPM (0:25/1:35/2:40/3:45/4:55)	ENG *	[0 to 4 / 0 / 1 / step]

1-901-005	Thick Paper 3 CPM (0:25/1:35/2:40/3:45/4:55)	ENG*	MP 6503 SP/7503 SP: [0 to 4 / 2 / 1 / step] MP 9003 SP: [0 to 4 / 3 / 1 / step]
-----------	---	------	--

1902	[Fusing Web Motor Control]		
1-902-001	Fusing Web Used Area Display/Setting	ENG*	[0 to 120 / 0 / 1 / step]
1-902-002	Fusing Web Motor Operation Interval	ENG*	MP 6503 SP: [5 to 50 / 17 / 1 / step] MP 7503 SP: [5 to 50 / 16 / 1 / step] MP 9003 SP: [5 to 50 / 14 / 1 / step]
1-902-004	Web Near End Value	ENG*	[0 to 100 / 80 / 1 / step]
1-902-005	Web Roll Coefficient	ENG*	[5 to 30 / 18 / 1 / step]
1-902-006	Web Length (0: 20m 1: 22.7m)	ENG*	MP 6503 SP/7503 SP: [0 to 3 / 3 / 1 / step] MP 9003 SP: [0 to 3 / 2 / 1 / step]
1-902-007	Web Motor Counter:Continuous	ENG*	[0 to 255 / 0 / 1 / step]
1-902-008	Web Motor Counter:Total	ENG*	[0 to 255 / 0 / 1 / step]

1903	[Web Job End]		
1-903-001	Yes/No	ENG*	[0 or 1 / 0 / 1 / step]
1-903-002	Job End Condition (Continous PPC Time)	ENG*	[1 to 99 / 7 / 1 / step]
1-903-003	Job End Frequency	ENG*	[1 to 5 / 2 / 1 / step]

1904	[By-passTrayPaperSizeCorrection]		
1-904-001	Minimum Size	ENG	[0 to 0 / 0 / 0 / step]
1-904-002	Maximum Size	ENG	[0 to 0 / 0 / 0 / step]

1905	[By-pass Adj.]		
1-905-001	Thick Paper - By-pass Tray	ENG	[0 or 1 / 1 / 1 / step]
1-905-002	Size Setting: Priority Detecting	ENG	[0 or 1 / 0 / 1 / step]
1-905-003	Adj. Size Determining Time	ENG	[0 to 3 / 3 / 1 sec / step]

1906	[Temp/humid Sensor]		
1-906-001	Temp/humid Sensor	ENG*	[0 or 1 / 1 / 1 / step]

1907	[Pre-Fusing Idling]		
1-907-001	Thick 1,2 (1:ON/0:OFF)	ENG*	[0 or 1 / 0 / 1 / step]
1-907-002	Thick 1,2: Small Paper Size (1:ON/0:OFF)	ENG*	[0 or 1 / 0 / 1 / step]
1-907-003	Normal Mode (1:ON/0:OFF)	ENG*	[0 or 1 / 0 / 1 / step]
1-907-004	Normal Mode: Small Paper Size (1:ON/0:OFF)	ENG*	[0 or 1 / 0 / 1 / step]
1-907-005	Middle Thick (1:ON/0:OFF)	ENG*	[0 or 1 / 0 / 1 / step]
1-907-006	Middle Thick: S-size (1:ON/0:OFF)	ENG*	[0 or 1 / 0 / 1 / step]
1-907-007	Label (1:ON/0:OFF)	ENG*	[0 or 1 / 0 / 1 / step]

1-907-008	Envelope (1:ON/ 0:OFF)	ENG *	[0 or 1 / 0 / 1 / step]
1-907-009	Thick 3 Mode (1:ON/ 0:OFF)	ENG *	[0 or 1 / 0 / 1 / step]
1-907-010	Thick 3 Mode: Small Paper Size (1:ON/ 0:OFF)	ENG *	[0 or 1 / 0 / 1 / step]

1908	[Pre-Fusing Idling]		
1-908-001	1:ON/0:OFF	ENG *	[0 or 1 / 1 / 1 / step]

1908	[Pre-Fusing Idling: Low Temp.]		
1-908-002	Standby (Pre-Idling)	ENG *	[0 to 180 / 0 / 1 sec / step]
1-908-003	Sleep Mode (Pre- Idling)	ENG *	[0 to 180 / 60 / 1 sec / step]

1909	[LowSpeedMode]		
1-909-001	Enable/Disable	ENG *	MP 6503 SP/7503 SP: [0 or 1 / 1 / 1 / step] MP 9003 SP: [0 or 1 / 0 / 1 / step]
1-909-002	Previous Paper: Speed	ENG *	[0 or 1 / 0 / 1 / step]
1-909-003	LowSpeedMode (Tab Sheet)	ENG *	[0 or 1 / 0 / 1 / step]
1-909-004	LowSpeedMode (Label)	ENG *	[0 or 1 / 0 / 1 / step]
1-909-005	LowSpeedMode (Special Paper)	ENG *	[0 or 1 / 0 / 1 / step]
1-909-006	LowSpeedMode ProcessControl	ENG *	[0 to 2 / 0 / 1 / step]
1-909-007	ProcessControl Action Print Distance(Adj2)	ENG *	[0 to 9999999 / 1050 / 1 cm / step]

1910	[Capacitor Status Display]		
1-910-001	Latest Capacity	ENG*	[0 to 200 / 0 / 1 F / step]
1-910-002	Current Voltage	ENG	[0 to 5000 / 0 / 0.01 V / step]
1-910-003	Charge Time	ENG	[0 to 600000 / 0 / 1 ms / step]
1-910-004	Worn-out Counter	ENG*	[0 to 255 / 0 / 1 / step]
1-910-005	Charged Power	ENG*	[0 to 500 / 285 / 1 W / step]

1911	[Capacitor Discharge Stop Volt]		
1-911-001	-	ENG*	[1 to 20 / 7 / 1 V / step]

1912	[Capacitor Worn-out Detection]		
1-912-002	Worn-out Counter	ENG*	[30 to 255 / 30 / 1 / step]
1-912-003	AC Input Voltage	ENG*	[80 to 100 / 99 / 1 V / step]
1-912-004	Capacitor Capacity	ENG*	[50 to 150 / 100 / 1 F / step]

1913	[AC Input Voltage Display]		
1-913-001	AC Input Voltage initial value	ENG	NA: MP 6503 SP/7503 SP: [0 to 200 / 120 / 1 V / step] NA: MP 9003 SP: [0 to 200 / 240 / 1 V / step] EU/Asia [0 to 200 / 240 / 1 V / step] CN: [0 to 200 / 220 / 1 V / step] TW: MP 6503 SP/7503 SP: [0 to 200 / 110 / 1 V / step] TW: MP 9003 SP: [0 to 200 / 240 / 1 V / step]
1-913-002	AC Input Voltage measured value	ENG	[0 to 300 / 0 / 1 / step]

1920	[Capacitor Charge Setting]		
1-920-001	0:ON/1:OFF	ENG *	[0 or 1 / 0 / 1 / step]

1921	[Job End Idlling]		
1-921-001	Idlling Time	ENG *	[0 to 30 / 0 / 1 sec / step]
1-921-002	Target Temperature	ENG *	[190 to 205 / 200 / 1 deg / step]

1922	[Not Used]		
1-922-001	0:OFF 1:ON	ENG *	[0 or 1 / 1 / 1 / step]

1923	[HV Fusing Temp Cont]		
1-923-001	0:OFF 1:ON	ENG *	[0 or 1 / 1 / 1 / step]

1924	[10 Sec. Recovery Temperature]		
1-924-001	Temperature Sensor	ENG *	[16 to 25 / 20 / 1 / step]

1925	[Idlling Setting:Power On]		
1-925-001	Middle Thick (1:ON/ 0:OFF)	ENG *	[0 or 1 / 1 / 1 / step]
1-925-002	Thick 1,2 (1:ON/ 0:OFF)	ENG *	[0 or 1 / 0 / 1 / step]
1-925-003	Nomal Paper1 (1:ON/ 0:OFF)	ENG *	[0 or 1 / 0 / 1 / step]
1-925-004	Nomal Paper2 (1:ON/ 0:OFF)	ENG *	[0 or 1 / 0 / 1 / step]
1-925-005	Thick 3 (1:ON/0:OFF)	ENG *	[0 or 1 / 0 / 1 / step]

1926	[Capacitor Discharge: S-Size]		
1-926-001	End Thermistor	ENG *	[135 to 220 / 190 / 1 deg / step]

1927	[Capacitor Discharge Setting]		
1-927-001	Capacitor Discharge Time	ENG *	[12 to 120 / 30 / 1 sec / step]

1928	[Heater OFF during Feeding]		
1-928-001	Heater OFF Time	ENG *	MP 6503 SP/7503 SP: [5 to 60 / 5 / 1 deg / step] MP 9003 SP: [5 to 60 / 10 / 1 deg / step]

1929	[Capacitor OFF: Feeding]		
1-929-001	1:ON/0:OFF	ENG *	[0 or 1 / 1 / 1 / step]

1930	[Web Operation: Fusing Idling]		
1-930-001	1:ON/0:OFF	ENG *	[0 or 1 / 0 / 1 / step]
1-930-002	Operation Times	ENG *	[1 to 5 / 2 / 1 / step]

1931	[Normal Paper Setting 1 control]		
1-931-001	1:ON/0:OFF	ENG *	[0 or 1 / 0 / 1 / step]
1-931-002	Capacitor Voltage	ENG *	[15 to 25 / 22 / 1 V / step]

1933	[Not Used]		
1-933-001	Not Used	ENG *	[0 or 1 / 0 / 1 / step]
1-933-002	Not Used	ENG *	[7 to 8 / 0 / 1 sec / step]
1-933-003	Not Used	ENG *	[0 to 200 / 50 / 1 deg / step]

1933	[20sec Recover Reload]		
1-933-004	Forced Reload (1: Enable/0: Disable)	ENG *	[0 or 1 / 1 / 1 / step]
1-933-005	Forced Reload Time	ENG *	[7 to 10 / 8 / 1 sec / step]

1-933-006	Forced Reload Permit Temp	ENG *	[0 to 200 / 50 / 1 deg / step]
-----------	---------------------------	-------	---------------------------------------

1951	[Dsp Inside Machine Temperature]		
1-951-001	Temperature	ENG	[-128 to 127 / 0 / 1 deg / step]

1952	[Switching Temp: Fan Operation]		
1-952-001	Operation Switch Temp: Silent Mode	ENG *	[0 to 100 / 25 / 1 deg / step]
1-952-002	Operation Switch Temp: Normal Mode	ENG *	[0 to 100 / 40 / 1 deg / step]
1-952-003	Operation Switch Temp: High Temp Mode	ENG *	[0 to 100 / 42 / 1 deg / step]

1953	[DevUnitFan: Forced Enable Set]		
1-953-001	Forced Enable	ENG *	[0 or 1 / 0 / 1 / step]

1954	[Extra Operation]		
1-954-001	Determining Temp	ENG *	[0 to 100 / 50 / 1 deg / step]

1955	[Switching Temperature]		
1-955-001	Threshold Temperature	ENG	[0 to 20 / 2 / 1 deg / step]

1956	[Exhaust Fan DUTY Ad.]		
1-956-001	Silent	ENG *	[0 to 100 / 20 / 1 % / step]
1-956-002	Low Speed	ENG *	[0 to 100 / 20 / 1 % / step]
1-956-003	Mid Speed	ENG *	[0 to 100 / 20 / 1 % / step]
1-956-004	High Speed	ENG *	[0 to 100 / 20 / 1 % / step]
1-956-005	Printing	ENG *	[0 to 100 / 35 / 1 % / step]

1957	[Intake Fan DUTY Adj.]		
1-957-001	Silent	ENG *	[0 to 100 / 30 / 1 % / step]
1-957-002	Low Speed	ENG *	[0 to 100 / 50 / 1 % / step]
1-957-003	Mid Speed	ENG *	[0 to 100 / 60 / 1 % / step]
1-957-004	High Speed	ENG *	[0 to 100 / 70 / 1 % / step]

1958	[Fusing Exhaust Fan DUTY Adj.]		
1-958-001	Silent	ENG *	[0 to 100 / 30 / 1 % / step]
1-958-002	Low Speed	ENG *	[0 to 100 / 30 / 1 % / step]
1-958-003	Mid Speed	ENG *	[0 to 100 / 40 / 1 % / step]
1-958-004	High Speed	ENG *	[0 to 100 / 45 / 1 % / step]

Engine SP Tables-2

SP2-XXX (Drum)

2001	[Charge Roller Bias Adjustment]		
2-001-002	ID Sensor Pattern: Adj. of Applied Voltage	ENG	[600 to 1500 / 800 / 10 V / step]
2-001-003	Setting for Total Bias Current	ENG*	[900 to 1500 / 900 / 10 uA / step]
2-001-004	Setting for Total Bias Current of Grid	ENG*	[600 to 1500 / 900 / 10 V / step]
2-001-005	Total Bias Grid Voltage: OHP Total	ENG	[600 to 1500 / 650 / 10 V / step]
2-001-006	Total Bias Grid Current: Photo Mode Total	ENG	[1400 to 1500 / 1500 / 10 uA / step]
2-001-007	Set for Total Bias Current of Grid(LowSpeed)	ENG*	[600 to 1500 / 900 / 10 V / step]

2101	[Printing Erase Margin]		
2-101-001	Leading Edge	ENG	[0 to 9.0 / 2.5 / 0.1 mm / step]
2-101-002	Trailing Edge	ENG	[0 to 9.0 / 2.0 / 0.1 mm / step]
2-101-003	Left edge	ENG	[0 to 9.0 / 2.0 / 0.1 mm / step]
2-101-004	Right edge	ENG	[0 to 9.0 / 2.0 / 0.1 mm / step]

2104	[Small Pitch Band]		
2-104-001	Reduction Mode O	ENG*	[0 or 1 / 1 / 1 - / step]
2-104-002	Reduction Mode O	ENG*	[-20 to 10 / 0 / 1 - / step]
2-104-003	Reduction Mode O	ENG*	[0 or 1 / 0 / 1 - / step]
2-104-004	Reduction Mode O	ENG*	[-20 to 10 / 0 / 1 - / step]

2107	[Image Parameter]		
2-107-001	Image Gamma Flag	ENG	[0 or 1 / 1 / 1 / step]
2-107-002	Shading Correction Flag	ENG*	[0 or 1 / 1 / 1 / step]

2110	[LD Driver]		
2-110-001	Error Flag	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
2-110-005	Writing Unit Adj. Transfer	ENG	[0 or 1 / 0 / 1 / step]

2114	[Binary Edge Pro]		
2-114-001	Leading Edge Pixe	ENG	[2 to 15 / 8 / 1 - / step]
2-114-002	Trailing Edge Pix	ENG	[2 to 15 / 15 / 1 - / step]
2-114-004	Independent Dot P	ENG	[2 to 15 / 8 / 1 - / step]
2-114-005	Leading Edge Pixe	ENG	[2 to 15 / 7 / 1 - / step]
2-114-006	Trailing Edge Pix	ENG	[2 to 15 / 15 / 1 - / step]
2-114-008	Independent Dot P	ENG	[2 to 15 / 15 / 1 - / step]

2115	[Main Scan Beam Pitch Adj.]		
2-115-001	Pitch Adj. Between LD0 and LD2	ENG*	[-100 to 100 / 0 / 1 um / step]
2-115-002	Pitch Adj. Between LD1 and LD3	ENG*	[-100 to 100 / 0 / 1 um / step]
2-115-003	Pitch Adj. Between LD0 and LD1	ENG*	[-999 to 999 / 0 / 1 um / step]

2115	[Main Scan Mag. Adj.]		
2-115-004	Main Scan:Front Between LDO and LD1	ENG*	[-100 to 100 / 0 / 1 um / step]
2-115-005	Main Scan:Rear Between LDO and LD1	ENG*	[-100 to 100 / 0 / 1 um / step]

2201	[Development Bia]		
2-201-001	Dev. Bias (Image)	ENG*	[100 to 800 / 550 / 10 V / step]
2-201-002	ID Sensor Pattern	ENG*	[100 to 800 / 360 / 10 V / step]
2-201-003	OHP	ENG	[100 to 800 / 300 / 10 V / step]
2-201-004	ID Sensor Pattern	ENG*	[140 to 380 / 240 / 10 V / step]
2-201-005	Vb Scale Voltage	ENG*	[100 to 800 / 550 / 1 V / step]
2-201-006	Dev. Bias (Image) (LowSpeed)	ENG*	[100 to 800 / 550 / 10 V / step]

2207	[Forced Toner Su]		
2-207-001	-	ENG	[0 to 0 / 0 / 0 - / step]

2208	[Toner Supply Mode]		
2-208-001	(0:Sensor 1:Pixel Count)	ENG*	[0 or 1 / 0 / 1 / step]

2209	[Toner Supply Rate]		
2-209-001	-	ENG*	[50 to 2000 / 850 / 5 mgpsec / step]

2210	[ID Sensor Patter]		
2-210-001	-	ENG	[0 to 200 / 10 / 1 - / step]

2220	[Vref Manual Setting]		
2-220-001	-	ENG*	[100 to 400 / 250 / 0.01 V / step]

2223	[Vt Display]		
2-223-001	-	ENG	[0 to 500 / 400 / 0.02 V / step]

2224	[Tnr Remains: Disp]		
2-224-001	Tnr mg(NewBtl)	ENG	[0 to 999999990 / 11000000 / 0.1 mg / step]

2-224-002	mg Remains	ENG	[0 to 999999990 / 11000000 / 0.1 mg / step]
2-224-003	% Remains	ENG*	[0.0 to 100 / 100 / 1 % / step]
2-224-004	TnrRemainsCoef	ENG	[0 to 3000 / 100 / 0.01 / step]
2-224-006	Coverage date	ENG	[0 to 99999999 / 0 / 1 / step]

2301	[Trans. Curr. Adj.]		
2-301-001	Main Unit Image Area: Front Side	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-002	Main Unit Image Area: Back Side	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-003	By-pass Image Area: Front Side	ENG	MP 6503 SP/7503 SP: [10 to 200 / 75 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-004	Postcard	ENG	[10 to 200 / 165 / 1 uA / step]
2-301-005	Paper Interval	ENG	[10 to 200 / 15 / 1 uA / step]
2-301-006	Tab Paper	ENG	MP 6503 SP/7503 SP: [10 to 200 / 75 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-009	OHP: Front Side	ENG	MP 6503 SP/7503 SP: [10 to 200 / 75 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]

2-301-010	Tracing Paper: Front Side	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-011	Image Leading Edge: Front	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-012	Image Trailing Edge: Front	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-013	Image Leading Edge: Back	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-014	Image Trailing Edge: Back	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-015	Bypass: Image Leading Edge	ENG	MP 6503 SP/7503 SP: [10 to 200 / 75 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-016	Bypass: Image Trailing Edge	ENG	MP 6503 SP/7503 SP: [10 to 200 / 75 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-017	Image Leading Edge: Postcard	ENG	[10 to 200 / 165 / 1 uA / step]
2-301-018	Image Trailing Edge: Postcard	ENG	[10 to 200 / 165 / 1 uA / step]

2-301-019	Image Leading Edge:Tab Paper	ENG	MP 6503 SP/7503 SP: [10 to 200 / 75 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-020	Image Trailing Edge:Tab Paper	ENG	MP 6503 SP/7503 SP: [10 to 200 / 75 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-023	Image Leading Edge:OHP	ENG	MP 6503 SP/7503 SP: [10 to 200 / 75 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-024	Image Trailing Edge:OHP	ENG	MP 6503 SP/7503 SP: [10 to 200 / 75 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-025	Image Leading Edge:Tracing Paper	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-026	Image Trailing Edge:Tracing Paper	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-027	Label	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-028	Image Leading Edge:Label	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]

2-301-029	Image Trailing Edge:Label	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-030	envelope	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-031	Image Leading Edge:envelope	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-032	Image Trailing Edge:envelope	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-033	Med Thick Paper: Front Side Side	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-034	Med Thick Paper: Back Side	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-035	Image Leading Edge:Med Thick Paper	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]

2-301-036	Image Trailing Edge:Med Thick Paper	ENG	MP 6503 SP/7503 SP: [10 to 200 / 65 / 1 uA / step] MP 9003 SP: [10 to 200 / 80 / 1 uA / step]
2-301-037	Thick Paper1: Front Side	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-038	Thick Paper1: Back Side	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-039	Image Leading Edge:Thick Paper1	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-040	Image Trailing Edge:Thick Paper1	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-041	Thick Paper2: Front Side	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-042	Thick Paper2: Back Side	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-043	Image Leading Edge:Thick Paper2	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-044	Image Trailing Edge:Thick Paper2	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-045	Thick Paper3: Front Side	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-046	Thick Paper3: Back Side	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-047	Image Leading Edge:Thick Paper3	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-048	Image Trailing Edge:Thick Paper3	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-049	Thick Paper4: Front Side	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-050	Image Leading Edge:Thick Paper4	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-051	Image Trailing Edge:Thick Paper4	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-101	Main Unit Image Area: Front Side: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]

2-301-102	Main Unit Image Area: Back Side: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]
2-301-103	By-pass Image Area: Front Side: Low Speed	ENG	[10 to 200 / 75 / 1 uA / step]
2-301-104	Postcard: Low Speed	ENG	[10 to 200 / 165 / 1 uA / step]
2-301-105	Paper Interval: Low Speed	ENG	[10 to 200 / 15 / 1 uA / step]
2-301-106	Tab Paper: Low Speed	ENG	[10 to 200 / 75 / 1 uA / step]
2-301-109	OHP: Front Side: Low Speed	ENG	[10 to 200 / 75 / 1 uA / step]
2-301-110	Tracing Paper: Front Side: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-111	Image Leading Edge: Front: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]
2-301-112	Image Trailing Edge: Front: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]
2-301-113	Image Leading Edge: Back: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]
2-301-114	Image Trailing Edge: Back: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]
2-301-115	Image Leading Edge:Low Speed	ENG	[10 to 200 / 75 / 1 uA / step]
2-301-116	Image Trailing Edge:Low Speed	ENG	[10 to 200 / 75 / 1 uA / step]
2-301-117	Image Leading Edge: Postcard: Low Speed	ENG	[10 to 200 / 165 / 1 uA / step]
2-301-118	Image Trailing Edge: Postcard: Low Speed	ENG	[10 to 200 / 165 / 1 uA / step]
2-301-119	Image Leading Edge:Tab Paper: Low Speed	ENG	[10 to 200 / 75 / 1 uA / step]

2-301-120	Image Trailing Edge:Tab Paper: Low Speed	ENG	[10 to 200 / 75 / 1 uA / step]
2-301-123	Image Leading Edge:OHP: Low Speed	ENG	[10 to 200 / 75 / 1 uA / step]
2-301-124	Image Trailing Edge:OHP: Low Speed	ENG	[10 to 200 / 75 / 1 uA / step]
2-301-125	Image Leading Edge:Tracing Paper: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-126	Image Trailing Edge:Tracing Paper: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-127	Label: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]
2-301-128	Image Leading Edge:Label: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]
2-301-129	Image Trailing Edge:Label: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]
2-301-130	envelope: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]
2-301-131	Image Leading Edge:envelope: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]
2-301-132	Image Trailing Edge:envelope: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]
2-301-133	Med Thick Paper: Front: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]
2-301-134	Med Thick Paper: Back: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]
2-301-135	Img Leading Edge:Med Thick Paper: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]
2-301-136	Img Trailing Edge:Med Thick Paper: Low Speed	ENG	[10 to 200 / 50 / 1 uA / step]

2-301-137	Thick Paper1: Front Side: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-138	Thick Paper1: Back Side: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-139	Image Leading Edge:Thick Paper1: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-140	Image Trailing Edge:Thick Paper1: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-141	Thick Paper2: Front Side: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-142	Thick Paper2: Back Side: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-143	Image Leading Edge:Thick Paper2: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-144	Image Trailing Edge:Thick Paper2: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-145	Thick Paper3: Front Side: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-146	Thick Paper3: Back Side: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-147	Image Leading Edge:Thick Paper3: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-148	Image Trailing Edge:Thick Paper3: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-149	Thick Paper4: Front Side: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]

2-301-150	Image Leading Edge:Thick Paper4: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]
2-301-151	Image Trailing Edge:Thick Paper4: Low Speed	ENG	[10 to 200 / 120 / 1 uA / step]

2506	[Cont. Op.Time Cleaning Setting]		
2-506-001	Operation Setting	ENG	[0 or 1 / 1 / 1 / step]
2-506-002	Time Setting	ENG	[1 to 100 / 15 / 1 min / step]

2507	[ID Sen. Patt. Du]		
2-507-001	Operation Setting	ENG	[0 or 1 / 0 / 1 - / step]
2-507-002	No. of Sheets	ENG	[1 to 10000 / 100 / 1 - / step]

2602	[PTL Setting]		
2-602-001	1st Side: ON/OFF Setting	ENG	[0 or 1 / 1 / 1 / step]
2-602-002	1st Side: OFF Timing	ENG	[-10 to 20 / 3 / 1 mm / step]
2-602-003	2nd Side: ON/OFF Setting	ENG	[0 or 1 / 0 / 1 / step]
2-602-004	2nd Side: OFF Timing	ENG	[-10 to 20 / 3 / 1 mm / step]
2-602-101	1st Side: ON/OFF Setting: Low Speed	ENG	[0 or 1 / 1 / 1 / step]
2-602-102	1st Side: OFF Timing: Low Speed	ENG	[-10 to 20 / 3 / 1 mm / step]
2-602-103	2nd Side: ON/OFF Setting: Low Speed	ENG	[0 or 1 / 0 / 1 / step]
2-602-104	2nd Side: OFF Timing: Low Speed	ENG	[-10 to 20 / 3 / 1 mm / step]

2801	[TD Sensor Initial Setting]		
2-801-001	-	ENG	[0 to 0 / 0 / 0 / step]
2-801-002	Developer Lot Number Input	ENG	[0 to 0 / 0 / 0 / step]

2803	[Charge Cleaner Start Time]		
2-803-001	-	ENG	[0 to 0 / 0 / 0 / step]

2804	[Charge Cleaner]		
2-804-001	Operation Mode	ENG*	[0 or 1 / 1 / 1 / step]
2-804-002	Number of Sheets	ENG*	[100 to 10000 / 5000 / 1 / step]

2901	[HumidityControl]		
2-901-001	(0:OFF 1:ON)	ENG*	[0 or 1 / 0 / 1 / step]
2-901-002	Humidity Thresh: Trans. Bias	ENG*	[0 to 100 / 70 / 1 % / step]

2902	[Test Pattern]		
2-902-003	Printing Test Pattern	ENG	[0 to 25 / 0 / 1 / step]

2906	[TD Sensor Ctrl Voltage & Check]		
2-906-001	TD Sensor Ctrl Voltage Setting	ENG	[0 to 240 / 97 / 0.1 V / step]
2-906-002	Automatic Adjustment Setting	ENG	[0 to 240 / 97 / 0.1 V / step]

2909	[Writing Main Scan Mag.]		
2-909-001	-	ENG*	[-2.0 to 2.0 / 0 / 0.1 % / step]

2910	[Writing Sub Scan Mag.]		
-------------	--------------------------------	--	--

2-910-001	-	ENG*	[-1.0 to 1.0 / 0 / 0.1 % / step]
-----------	---	------	----------------------------------

2912	[Drum Reverse Rotation Interval]		
2-912-001	-	ENG*	[0 to 6 / 0 / 0 / step]

2913	[Temp/humid Display]		
2-913-001	Internal Temperature	ENG	[-128 to 127 / 0 / 1 deg / step]

2920	[LD Off Check]		
2-920-001	0:ON 1:OFF	ENG	[0 or 1 / 0 / 0 / step]

2930	[Transfer Idle Cleaning]		
2-930-001	-	ENG	[0 or 1 / 0 / 0 / step]

2931	[Trans.Cur. On/OffTiming:LCT]		
2-931-001	On Timing: La1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-931-002	La1f(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-003	Lc1r(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-004	Off Timing: Lc1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-931-005	On Timing: La2(Back)	ENG	[-30 to 30 / 0 / 1 mm / step]
2-931-006	Leading Edge: La2f(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-007	Trailing Edge: Lc2r(Back)	ENG	[0 to -20 / 0 / 1 mm / step]
2-931-008	On Timing: Lc2(Back)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-931-013	On Timing: M-Thick	ENG	[-30 to 30 / 0 / 1 mm / step]
2-931-014	Leading Edge: M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-015	Trailing Edge:M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-016	Off Timing: M-Thick	ENG	[-30 to 30 / 15 / 1 mm / step]

2-931-017	On Timing: After Punch	ENG	[-30 to 30 / 20 / 1 mm / step]
2-931-018	Leading Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-019	Trailing Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-020	Off Timing: After Punch	ENG	MP 6503 SP/7503 SP: [-30 to 30 / -22 / 1 mm / step] MP 9003 SP: [-30 to 30 / -25 / 1 mm / step]
2-931-021	On Timing: Thick Paper1	ENG	[-30 to 30 / 0 / 1 mm / step]
2-931-022	Leading Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-023	Trailing Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-024	Off Timing: Thick Paper1	ENG	[-30 to 30 / 15 / 1 mm / step]
2-931-025	On Timing: Thick Paper2	ENG	[-30 to 30 / 0 / 1 mm / step]
2-931-026	Leading Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-027	Trailing Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-028	Off Timing: Thick Paper2	ENG	[-30 to 30 / 15 / 1 mm / step]
2-931-029	On Timing: Thick Paper3	ENG	[-30 to 30 / 0 / 1 mm / step]
2-931-030	Leading Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-031	Trailing Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]

2-931-032	Off Timing: Thick Paper3	ENG	[-30 to 30 / 15 / 1 mm / step]
2-931-033	On Timing: Thick Paper4	ENG	[-30 to 30 / 0 / 1 mm / step]
2-931-034	Leading Edge: Thick Paper4	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-035	Trailing Edge: Thick Paper4	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-036	Off Timing: Thick Paper4	ENG	[-30 to 30 / 15 / 1 mm / step]
2-931-101	Low Speed: On Timing: La1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-931-102	Low Speed: La1f(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-103	Low Speed: Lc1r(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-104	Low Speed: Off Timing: Lc1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-931-105	Low Speed: On Timing: La2(Back)	ENG	[-30 to 30 / 0 / 1 mm / step]
2-931-106	Low Speed: Leading Edge: La2f(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-107	Low Speed: Trailing Edge: Lc2r(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-108	Low Speed: On Timing: Lc2(Back)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-931-113	Low Speed: On Timing: M-Thick	ENG	[-30 to 30 / 0 / 1 mm / step]
2-931-114	Low Speed: Leading Edge: M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-115	Low Speed: Trailing Edge:M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-116	Low Speed: Off Timing: M-Thick	ENG	[-30 to 30 / 15 / 1 mm / step]

2-931-117	Low Speed: On Timing: After Punch	ENG	[-30 to 30 / 20 / 1 mm / step]
2-931-118	Low Speed: Leading Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-119	Low Speed: Trailing Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-120	Low Speed: Off Timing: After Punch	ENG	[-30 to 30 / -16 / 1 mm / step]
2-931-121	Low Speed: On Timing: Thick Paper1	ENG	[-30 to 30 / 0 / 1 mm / step]
2-931-122	Low Speed: Leading Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-123	Low Speed: Trailing Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-124	Low Speed: Off Timing: Thick Paper1	ENG	[-30 to 30 / 15 / 1 mm / step]
2-931-125	Low Speed: On Timing: Thick Paper2	ENG	[-30 to 30 / 0 / 1 mm / step]
2-931-126	Low Speed: Leading Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-127	Low Speed: Trailing Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-128	Low Speed: Off Timing: Thick Paper2	ENG	[-30 to 30 / 15 / 1 mm / step]
2-931-129	Low Speed: On Timing: Thick Paper3	ENG	[-30 to 30 / 0 / 1 mm / step]
2-931-130	Low Speed: Leading Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-131	Low Speed: Trailing Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-132	Low Speed: Off Timing: Thick Paper3	ENG	[-30 to 30 / 15 / 1 mm / step]

2-931-133	Low Speed: On Timing: Thick Paper4	ENG	[-30 to 30 / 0 / 1 mm / step]
2-931-134	Low Speed: Leading Edge: Thick Paper4	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-135	Low Speed: Trailing Edge: Thick Paper4	ENG	[0 to 20 / 0 / 1 mm / step]
2-931-136	Low Speed: Off Timing: Thick Paper4	ENG	[-30 to 30 / 15 / 1 mm / step]

2932	[Trans.Cur. On/OffTiming:Tray1]		
2-932-001	On Timing: La1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-932-002	La1f(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-003	Lc1r(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-004	Off Timing: Lc1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-932-005	On Timing: La2(Back)	ENG	[-30 to 30 / 0 / 1 mm / step]
2-932-006	Leading Edge: La2f(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-007	Trailing Edge: Lc2r(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-008	On Timing: Lc2(Back)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-932-013	On Timing: M-Thick	ENG	[-30 to 30 / 0 / 1 mm / step]
2-932-014	Leading Edge: M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-015	Trailing Edge:M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-016	Off Timing: M-Thick	ENG	[-30 to 30 / 15 / 1 mm / step]
2-932-017	On Timing: After Punch	ENG	[-30 to 30 / 20 / 1 mm / step]
2-932-018	Leading Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-019	Trailing Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]

2-932-020	Off Timing: After Punch	ENG	MP 6503 SP/7503 SP: [-30 to 30 / -22 / 1 mm / step] MP 9003 SP: [-30 to 30 / -25 / 1 mm / step]
2-932-021	On Timing: Thick Paper1	ENG	[-30 to 30 / 0 / 1 mm / step]
2-932-022	Leading Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-023	Trailing Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-024	Off Timing: Thick Paper1	ENG	[-30 to 30 / 15 / 1 mm / step]
2-932-025	On Timing: Thick Paper2	ENG	[-30 to 30 / 0 / 1 mm / step]
2-932-026	Leading Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-027	Trailing Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-028	Off Timing: Thick Paper2	ENG	[-30 to 30 / 15 / 1 mm / step]
2-932-029	On Timing: Thick Paper3	ENG	[-30 to 30 / 0 / 1 mm / step]
2-932-030	Leading Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-031	Trailing Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-032	Off Timing: Thick Paper3	ENG	[-30 to 30 / 15 / 1 mm / step]
2-932-101	Low Speed: On Timing: La1 (Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-932-102	Low Speed: La1f (Front)	ENG	[0 to 20 / 0 / 1 mm / step]

2-932-103	Low Speed: Lc1r(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-104	Low Speed: Off Timing: Lc1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-932-105	Low Speed: On Timing: La2(Back)	ENG	[-30 to 30 / 0 / 1 mm / step]
2-932-106	Low Speed: Leading Edge: La2f(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-107	Low Speed: Trailing Edge: Lc2r(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-108	Low Speed: On Timing: Lc2(Back)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-932-113	Low Speed: On Timing: M-Thick	ENG	[-30 to 30 / 0 / 1 mm / step]
2-932-114	Low Speed: Leading Edge: M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-115	Low Speed: Trailing Edge:M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-116	Low Speed: Off Timing: M-Thick	ENG	[-30 to 30 / 15 / 1 mm / step]
2-932-117	Low Speed: On Timing: After Punch	ENG	[-30 to 30 / 20 / 1 mm / step]
2-932-118	Low Speed: Leading Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-119	Low Speed: Trailing Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-120	Low Speed: Off Timing: After Punch	ENG	[-30 to 30 / -16 / 1 mm / step]
2-932-121	Low Speed: On Timing: Thick Paper1	ENG	[-30 to 30 / 0 / 1 mm / step]
2-932-122	Low Speed: Leading Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]

2-932-123	Low Speed: Trailing Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-124	Low Speed: Off Timing: Thick Paper1	ENG	[-30 to 30 / 15 / 1 mm / step]
2-932-125	Low Speed: On Timing: Thick Paper2	ENG	[-30 to 30 / 0 / 1 mm / step]
2-932-126	Low Speed: Leading Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-127	Low Speed: Trailing Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-128	Low Speed: Off Timing: Thick Paper2	ENG	[-30 to 30 / 15 / 1 mm / step]
2-932-129	Low Speed: On Timing: Thick Paper3	ENG	[-30 to 30 / 0 / 1 mm / step]
2-932-130	Low Speed: Leading Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-131	Low Speed: Trailing Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-932-132	Low Speed: Off Timing: Thick Paper3	ENG	[-30 to 30 / 15 / 1 mm / step]

2933	[Trans.Cur. On/OffTiming:Tray2]		
2-933-001	On Timing: La1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-933-002	La1f(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-003	Lc1r(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-004	Off Timing: Lc1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-933-005	On Timing: La2(Back)	ENG	[-30 to 30 / 0 / 1 mm / step]
2-933-006	Leading Edge: La2f(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-007	Trailing Edge: Lc2r(Back)	ENG	[0 to 20 / 0 / 1 mm / step]

2-933-008	On Timing: Lc2(Back)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-933-013	On Timing: M-Thick	ENG	[-30 to 30 / 0 / 1 mm / step]
2-933-014	Leading Edge: M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-015	Trailing Edge:M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-016	Off Timing: M-Thick	ENG	[-30 to 30 / 15 / 1 mm / step]
2-933-017	On Timing: After Punch	ENG	[-30 to 30 / 20 / 1 mm / step]
2-933-018	Leading Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-019	Trailing Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-020	Off Timing: After Punch	ENG	MP 6503 SP/7503 SP: [-30 to 30 / -22 / 1 mm / step] MP 9003 SP: [-30 to 30 / -25 / 1 mm / step]
2-933-021	On Timing: Thick Paper1	ENG	[-30 to 30 / 0 / 1 mm / step]
2-933-022	Leading Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-023	Trailing Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-024	Off Timing: Thick Paper1	ENG	[-30 to 30 / 15 / 1 mm / step]
2-933-025	On Timing: Thick Paper2	ENG	[-30 to 30 / 0 / 1 mm / step]
2-933-026	Leading Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-027	Trailing Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-028	Off Timing: Thick Paper2	ENG	[-30 to 30 / 15 / 1 mm / step]

2-933-029	On Timing: Thick Paper3	ENG	[-30 to 30 / 0 / 1 mm / step]
2-933-030	Leading Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-031	Trailing Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-032	Off Timing: Thick Paper3	ENG	[-30 to 30 / 15 / 1 mm / step]
2-933-101	Low Speed: On Timing: La1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-933-102	Low Speed: La1f(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-103	Low Speed: Lc1r(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-104	Low Speed: Off Timing: Lc1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-933-105	Low Speed: On Timing: La2(Back)	ENG	[-30 to 30 / 0 / 1 mm / step]
2-933-106	Low Speed: Leading Edge: La2f(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-107	Low Speed: Trailing Edge: Lc2r(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-108	Low Speed: On Timing: Lc2(Back)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-933-113	Low Speed: On Timing: M-Thick	ENG	[-30 to 30 / 0 / 1 mm / step]
2-933-114	Low Speed: Leading Edge: M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-115	Low Speed: Trailing Edge:M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-116	Low Speed: Off Timing: M-Thick	ENG	[-30 to 30 / 15 / 1 mm / step]
2-933-117	Low Speed: On Timing: After Punch	ENG	[-30 to 30 / 20 / 1 mm / step]

2-933-118	Low Speed: Leading Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-119	Low Speed: Trailing Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-120	Low Speed: Off Timing: After Punch	ENG	[-30 to 30 / -16 / 1 mm / step]
2-933-121	Low Speed: On Timing: Thick Paper1	ENG	[-30 to 30 / 0 / 1 mm / step]
2-933-122	Low Speed: Leading Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-123	Low Speed: Trailing Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-124	Low Speed: Off Timing: Thick Paper1	ENG	[-30 to 30 / 15 / 1 mm / step]
2-933-125	Low Speed: On Timing: Thick Paper2	ENG	[-30 to 30 / 0 / 1 mm / step]
2-933-126	Low Speed: Leading Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-127	Low Speed: Trailing Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-128	Low Speed: Off Timing: Thick Paper2	ENG	[-30 to 30 / 15 / 1 mm / step]
2-933-129	Low Speed: On Timing: Thick Paper3	ENG	[-30 to 30 / 0 / 1 mm / step]
2-933-130	Low Speed: Leading Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-131	Low Speed: Trailing Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-933-132	Low Speed: Off Timing: Thick Paper3	ENG	[-30 to 30 / 15 / 1 mm / step]

2934	[Trans.Cur. On/OffTiming:Tray3]
-------------	---------------------------------

2-934-001	On Timing: La1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-934-002	La1f(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-003	Lc1r(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-004	Off Timing: Lc1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-934-005	On Timing: La2(Back)	ENG	[-30 to 30 / 0 / 1 mm / step]
2-934-006	Leading Edge: La2f(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-007	Trailing Edge: Lc2r(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-008	On Timing: Lc2(Back)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-934-013	On Timing: M-Thick	ENG	[-30 to 30 / 0 / 1 mm / step]
2-934-014	Leading Edge: M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-015	Trailing Edge:M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-016	Off Timing: M-Thick	ENG	[-30 to 30 / 15 / 1 mm / step]
2-934-017	On Timing: After Punch	ENG	[-30 to 30 / 20 / 1 mm / step]
2-934-018	Leading Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-019	Trailing Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-020	Off Timing: After Punch	ENG	MP 6503 SP/7503 SP: [-30 to 30 / -22 / 1 mm / step] MP 9003 SP: [-30 to 30 / -25 / 1 mm / step]
2-934-021	On Timing: Thick Paper1	ENG	[-30 to 30 / 0 / 1 mm / step]
2-934-022	Leading Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-023	Trailing Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]

2-934-024	Off Timing: Thick Paper1	ENG	[-30 to 30 / 15 / 1 mm / step]
2-934-025	On Timing: Thick Paper2	ENG	[-30 to 30 / 0 / 1 mm / step]
2-934-026	Leading Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-027	Trailing Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-028	Off Timing: Thick Paper2	ENG	[-30 to 30 / 15 / 1 mm / step]
2-934-029	On Timing: Thick Paper3	ENG	[-30 to 30 / 0 / 1 mm / step]
2-934-030	Leading Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-031	Trailing Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-032	Off Timing: Thick Paper3	ENG	[-30 to 30 / 15 / 1 mm / step]
2-934-101	Low Speed: On Timing: La1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-934-102	Low Speed: La1f(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-103	Low Speed: Lc1r(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-104	Low Speed: Off Timing: Lc1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-934-105	Low Speed: On Timing: La2(Back)	ENG	[-30 to 30 / 0 / 1 mm / step]
2-934-106	Low Speed: Leading Edge: La2f(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-107	Low Speed: Trailing Edge: Lc2r(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-108	Low Speed: On Timing: Lc2(Back)	ENG	[-30 to 30 / 20 / 1 mm / step]

2-934-113	Low Speed: On Timing: M-Thick	ENG	[-30 to 30 / 0 / 1 mm / step]
2-934-114	Low Speed: Leading Edge: M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-115	Low Speed: Trailing Edge:M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-116	Low Speed: Off Timing: M-Thick	ENG	[-30 to 30 / 15 / 1 mm / step]
2-934-117	Low Speed: On Timing: After Punch	ENG	[-30 to 30 / 20 / 1 mm / step]
2-934-118	Low Speed: Leading Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-119	Low Speed: Trailing Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-120	Low Speed: Off Timing: After Punch	ENG	[-30 to 30 / -16 / 1 mm / step]
2-934-121	Low Speed: On Timing: Thick Paper1	ENG	[-30 to 30 / 0 / 1 mm / step]
2-934-122	Low Speed: Leading Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-123	Low Speed: Trailing Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-124	Low Speed: Off Timing: Thick Paper1	ENG	[-30 to 30 / 15 / 1 mm / step]
2-934-125	Low Speed: On Timing: Thick Paper2	ENG	[-30 to 30 / 0 / 1 mm / step]
2-934-126	Low Speed: Leading Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-127	Low Speed: Trailing Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-128	Low Speed: Off Timing: Thick Paper2	ENG	[-30 to 30 / 15 / 1 mm / step]

2-934-129	Low Speed: On Timing: Thick Paper3	ENG	[-30 to 30 / 0 / 1 mm / step]
2-934-130	Low Speed: Leading Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-131	Low Speed: Trailing Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-934-132	Low Speed: Off Timing: Thick Paper3	ENG	[-30 to 30 / 15 / 1 mm / step]

2935	[Trans.Cur. On/OffTiming:Tray4]		
2-935-001	On Timing: La1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-935-002	La1f(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-003	Lc1r(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-004	Off Timing: Lc1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-935-005	On Timing: La2(Back)	ENG	[-30 to 30 / 0 / 1 mm / step]
2-935-006	Leading Edge: La2f(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-007	Trailing Edge: Lc2r(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-008	On Timing: Lc2(Back)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-935-013	On Timing: M-Thick	ENG	[-30 to 30 / 0 / 1 mm / step]
2-935-014	Leading Edge: M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-015	Trailing Edge:M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-016	Off Timing: M-Thick	ENG	[-30 to 30 / 15 / 1 mm / step]
2-935-017	On Timing: After Punch	ENG	[-30 to 30 / 20 / 1 mm / step]
2-935-018	Leading Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-019	Trailing Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]

2-935-020	Off Timing: After Punch	ENG	MP 6503 SP/7503 SP: [-30 to 30 / -22 / 1 mm / step] MP 9003 SP: [-30 to 30 / -25 / 1 mm / step]
2-935-021	On Timing: Thick Paper1	ENG	[-30 to 30 / 0 / 1 mm / step]
2-935-022	Leading Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-023	Trailing Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-024	Off Timing: Thick Paper1	ENG	[-30 to 30 / 15 / 1 mm / step]
2-935-025	On Timing: Thick Paper2	ENG	[-30 to 30 / 0 / 1 mm / step]
2-935-026	Leading Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-027	Trailing Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-028	Off Timing: Thick Paper2	ENG	[-30 to 30 / 15 / 1 mm / step]
2-935-029	On Timing: Thick Paper3	ENG	[-30 to 30 / 0 / 1 mm / step]
2-935-030	Leading Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-031	Trailing Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-032	Off Timing: Thick Paper3	ENG	[-30 to 30 / 15 / 1 mm / step]
2-935-101	Low Speed: On Timing: La1 (Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-935-102	Low Speed: La1f (Front)	ENG	[0 to 20 / 0 / 1 mm / step]

2-935-103	Low Speed: Lc1r(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-104	Low Speed: Off Timing: Lc1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-935-105	Low Speed: On Timing: La2(Back)	ENG	[-30 to 30 / 0 / 1 mm / step]
2-935-106	Low Speed: Leading Edge: La2f(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-107	Low Speed: Trailing Edge: Lc2r(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-108	Low Speed: On Timing: Lc2(Back)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-935-113	Low Speed: On Timing: M-Thick	ENG	[-30 to 30 / 0 / 1 mm / step]
2-935-114	Low Speed: Leading Edge: M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-115	Low Speed: Trailing Edge:M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-116	Low Speed: Off Timing: M-Thick	ENG	[-30 to 30 / 15 / 1 mm / step]
2-935-117	Low Speed: On Timing: After Punch	ENG	[-30 to 30 / 20 / 1 mm / step]
2-935-118	Low Speed: Leading Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-119	Low Speed: Trailing Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-120	Low Speed: Off Timing: After Punch	ENG	[-30 to 30 / -16 / 1 mm / step]
2-935-121	Low Speed: On Timing: Thick Paper1	ENG	[-30 to 30 / 0 / 1 mm / step]
2-935-122	Low Speed: Leading Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]

2-935-123	Low Speed: Trailing Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-124	Low Speed: Off Timing: Thick Paper1	ENG	[-30 to 30 / 15 / 1 mm / step]
2-935-125	Low Speed: On Timing: Thick Paper2	ENG	[-30 to 30 / 0 / 1 mm / step]
2-935-126	Low Speed: Leading Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-127	Low Speed: Trailing Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-128	Low Speed: Off Timing: Thick Paper2	ENG	[-30 to 30 / 15 / 1 mm / step]
2-935-129	Low Speed: On Timing: Thick Paper3	ENG	[-30 to 30 / 0 / 1 mm / step]
2-935-130	Low Speed: Leading Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-131	Low Speed: Trailing Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-935-132	Low Speed: Off Timing: Thick Paper3	ENG	[-30 to 30 / 15 / 1 mm / step]

2936	[Trans.Cur. On/OffTiming:Bypass]		
2-936-001	On Timing: La1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-002	La1f(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-003	Lc1r(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-004	Off Timing: Lc1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-005	On Timing: La2(Back)	ENG	[-30 to 30 / 0 / 1 mm / step]
2-936-006	Leading Edge: La2f(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-007	Trailing Edge: Lc2r(Back)	ENG	[0 to 20 / 0 / 1 mm / step]

2-936-008	On Timing: Lc2(Back)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-013	On Timing: OHP	ENG	[-30 to 30 / 0 / 1 mm / step]
2-936-014	Leading Edge: OHP	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-015	Trailing Edge: OHP	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-016	Off Timing: OHP	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-017	On Timing: M-Thick	ENG	[-30 to 30 / 0 / 1 mm / step]
2-936-018	Leading Edge: M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-019	Trailing Edge: M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-020	Off Timing: M-Thick	ENG	[-30 to 30 / 15 / 1 mm / step]
2-936-021	On Timing: After Punch	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-022	Leading Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-023	Trailing Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-024	Off Timing: After Punch	ENG	MP 6503 SP/7503 SP: [-30 to 30 / -22 / 1 mm / step] MP 9003 SP: [-30 to 30 / -25 / 1 mm / step]
2-936-025	ON Timing:Label La1	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-026	Label La1	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-027	Label Lc1	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-028	OFF Timing:Label Lc1	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-029	ON Timing:envelope La1	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-030	envelope La1	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-031	envelope Lc1	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-032	OFF Timing:envelope Lc1	ENG	[-30 to 30 / 20 / 1 mm / step]

2-936-033	On Timing: Thick Paper1	ENG	[-30 to 30 / 0 / 1 mm / step]
2-936-034	Leading Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-035	Trailing Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-036	Off Timing: Thick Paper1	ENG	[-30 to 30 / 15 / 1 mm / step]
2-936-037	On Timing: Thick Paper2	ENG	[-30 to 30 / 0 / 1 mm / step]
2-936-038	Leading Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-039	Trailing Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-040	Off Timing: Thick Paper2	ENG	[-30 to 30 / 15 / 1 mm / step]
2-936-041	On Timing: Thick Paper3	ENG	[-30 to 30 / 0 / 1 mm / step]
2-936-042	Leading Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-043	Trailing Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-044	Off Timing: Thick Paper3	ENG	[-30 to 30 / 15 / 1 mm / step]
2-936-045	On Timing: Thick Paper4	ENG	[-30 to 30 / 0 / 1 mm / step]
2-936-046	Leading Edge: Thick Paper4	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-047	Trailing Edge: Thick Paper4	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-048	Off Timing: Thick Paper4	ENG	[-30 to 30 / 15 / 1 mm / step]

2-936-101	Low Speed: On Timing: La1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-102	Low Speed: La1f(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-103	Low Speed: Lc1r(Front)	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-104	Low Speed: Off Timing: Lc1(Front)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-105	Low Speed: On Timing: La2(Back)	ENG	[-30 to 30 / 0 / 1 mm / step]
2-936-106	Low Speed: Leading Edge: La2f(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-107	Low Speed: Trailing Edge: Lc2r(Back)	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-108	Low Speed: On Timing: Lc2(Back)	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-113	Low Speed: On Timing: OHP	ENG	[-30 to 30 / 0 / 1 mm / step]
2-936-114	Low Speed: Leading Edge: OHP	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-115	Low Speed: Trailing Edge:OHP	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-116	Low Speed: Off Timing: OHP	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-117	Low Speed: On Timing: M-Thick	ENG	[-30 to 30 / 0 / 1 mm / step]
2-936-118	Low Speed: Leading Edge: M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-119	Low Speed: Trailing Edge:M-Thick	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-120	Low Speed: Off Timing: M-Thick	ENG	[-30 to 30 / 15 / 1 mm / step]
2-936-121	Low Speed: On Timing: After Punch	ENG	[-30 to 30 / 20 / 1 mm / step]

2-936-122	Low Speed: Leading Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-123	Low Speed: Trailing Edge: After Punch	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-124	Low Speed: Off Timing: After Punch	ENG	[-30 to 30 / -16 / 1 mm / step]
2-936-125	Low Speed: On Timing: Label	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-126	Low Speed: Leading Edge: Label	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-127	Low Speed: Trailing Edge: Label	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-128	Low Speed: Off Timing: Label	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-129	Low Speed: On Timing: envelope	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-130	Low Speed: Leading Edge: envelope	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-131	Low Speed: Trailing Edge: envelope	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-132	Low Speed: Off Timing: envelope	ENG	[-30 to 30 / 20 / 1 mm / step]
2-936-133	Low Speed: On Timing: Thick Paper1	ENG	[-30 to 30 / 0 / 1 mm / step]
2-936-134	Low Speed: Leading Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-135	Low Speed: Trailing Edge: Thick Paper1	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-136	Low Speed: Off Timing: Thick Paper1	ENG	[-30 to 30 / 15 / 1 mm / step]
2-936-137	Low Speed: On Timing: Thick Paper2	ENG	[-30 to 30 / 0 / 1 mm / step]

2-936-138	Low Speed: Leading Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-139	Low Speed: Trailing Edge: Thick Paper2	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-140	Low Speed: Off Timing: Thick Paper2	ENG	[-30 to 30 / 15 / 1 mm / step]
2-936-141	Low Speed: On Timing: Thick Paper3	ENG	[-30 to 30 / 0 / 1 mm / step]
2-936-142	Low Speed: Leading Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-143	Low Speed: Trailing Edge: Thick Paper3	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-144	Low Speed: Off Timing: Thick Paper3	ENG	[-30 to 30 / 15 / 1 mm / step]
2-936-145	Low Speed: On Timing: Thick Paper4	ENG	[-30 to 30 / 0 / 1 mm / step]
2-936-146	Low Speed: Leading Edge: Thick Paper4	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-147	Low Speed: Trailing Edge: Thick Paper4	ENG	[0 to 20 / 0 / 1 mm / step]
2-936-148	Low Speed: Off Timing: Thick Paper4	ENG	[-30 to 30 / 15 / 1 mm / step]

2940	[Reface Mode]		
2-940-001	Pattern Count	ENG*	[0 to 100 / 0 / 1 / step]

2950	[Vh Pattern Creation Setting]		
2-950-001	Exposure Level	ENG*	[0 to 15 / 8 / 1 - / step]
2-950-002	Offset Light Amount	ENG*	[-100 to 0 / -45 / 1 - / step]

2960	[Process Interval]		
-------------	---------------------------	--	--

2-960-001	Additional Time	ENG	[0 to 7 / 0 / 1 sec / step]
2961	[Developer Adjust Mode]		
2-961-001	-	ENG	[0 to 0 / 0 / 0 / step]
2962	[AutomaticAdj of DrumConditions]		
2-962-001	-	ENG	[0 to 0 / 0 / 0 - / step]
2963	[Installation Mode]		
2-963-001	-	ENG	[0 to 0 / 0 / 0 - / step]
2-963-002	Developer Lot Number Input	ENG	[0 to 0 / 0 / 0 / step]
2966	[Drum Conditions: Periodic Adj]		
2-966-002	Interval Setting	ENG*	[1 to 24 / 24 / 1 hour / step]
2967	[Developer Density Adj Mode]		
2-967-001	-	ENG*	[0 or 1 / 0 / 1 - / step]
2968	[Toner Exit Mode]		
2-968-001	-	ENG	[0 to 0 / 0 / 0 / step]
2969	[Toner Bottle Revolution Count]		
2-969-001	Copy Count Setting	ENG*	[50 to 112 / 100 / 1 Mai / step]
2-969-002	Count Reset	ENG	[0 to 0 / 0 / 0 / step]
2-969-003	Copy Count Display	ENG	[0 to 0xFFFF / 0 / 0 Kai / step]
2970	[Trans. Belt Resistance:Display]		
2-970-001	-	ENG	[0 to 0xFFFF / 0 / 0 Mohm / step]

2971	[Trans. Interval Output]		
2-971-001	Voltage	ENG	[0 to 0xFFFF / 0 / 0 V / step]
2-971-002	Current	ENG	[0 to 0xFFFF / 0 / 0 uA / step]

2972	[New Toner Bottle Fan Setting]		
2-972-001	NewTonerBottle Cooling Fan Forced Operation	ENG	[0 or 1 / 0 / 1 / step]

2973	[Development motor speed change]		
2-973-001	Development motor speed setting	ENG*	[0 to 3 / 0 / 1 / step]

2974	[Drum Cooling Fan Setting]		
2-974-001	Drum Cooling Fan Forced Operation	ENG	[0 or 1 / 0 / 1 / step]

2975	[Main Intake FanDriveCtrl]		
2-975-001	-	ENG	[0 or 1 / 0 / 1 / step]

2976	[Dev. Cooling Fan 1/2 Setting]		
2-976-001	Development Cooling Fan1, 2 Forced Operation	ENG	[0 to 1 / 0 / 1 / step]

2977	[Main Exhaust Fan Drive Setting]		
2-977-001	-	ENG	[0 to 2 / 1 / 1 / step]

2978	[Fan Extension Time Setting]		
2-978-001	Extension Time Setting	ENG*	[0 to 255 / 0 / 1 min / step]

2980	[PaperIntervalTransCur.OnTiming]		
-------------	---	--	--

2-980-001	-	ENG*	[80 to 500 / 170 / 10 msec / step]
-----------	---	------	---

2986	[Refresh Mode]		
2-986-001	Interval	ENG	[0 to 25 / 0 / 1 Kmai / step]
2-986-002	Level	ENG	[0 to 4 / 2 / 1 / step]
2-986-003	Repetitions	ENG	[1 to 3 / 2 / 1 / step]
2-986-004	Execution Mode	ENG	[0 to 0 / 0 / 0 / step]

Engine SP Tables-3

SP3-XXX (Process)

3001	[ID Sensor Initial Setting]		
3-001-001	ID Sensor PWM Setting	ENG*	[0 to 255 / 70 / 1 - / step]
3-001-002	ID Sensor Initialization	ENG	[0 to 0 / 0 / 0 - / step]

3103	[ID Sensor Output Display]		
3-103-001	Vsg	ENG	[0 to 500 / 408 / 0.01 V / step]
3-103-002	Vsp	ENG	[0 to 500 / 0 / 0.01 V / step]
3-103-003	Vpdp	ENG	[0 to 500 / 408 / 0.01 V / step]

3901	[Auto Process Control On/OffSet]		
3-901-001	-	ENG*	[0 or 1 / 1 / 1 - / step]

3902	[Drum Condition Display]		
3-902-001	Auto Process Control On/Off	ENG	[0 or 1 / 0 / 1 - / step]
3-902-002	Vd	ENG*	[100 to 970 / 800 / 1 - / step]
3-902-003	Vh	ENG*	[100 to 500 / 300 / 3 - / step]
3-902-004	Vg	ENG*	[0 to 0xFFFF / 0 / 1 - / step]
3-902-005	LD Level	ENG*	[-127 to 127 / 0 / 3 - / step]
3-902-006	ID Sensor Pattern Potential	ENG*	[0 to 0xFFFF / 0 / 1 - / step]
3-902-007	VqI	ENG*	[0 to 0xFFFF / 0 / 1 - / step]
3-902-008	VI	ENG*	[-32768 to 32767 / 0 / 1 - / step]
3-902-009	LD Level(LowSpeed)	ENG*	[-127 to 127 / 0 / 3 - / step]

3903	[Drum Rotate Time ExtensionMode]		
3-903-001	(0:OFF, 1:ON)	ENG*	[0 or 1 / 0 / 1 / step]
3-903-002	Drum Rotation Time	ENG*	[120 to 600 / 240 / 1 sec / step]
3-903-003	Interval	ENG*	[30 to 360 / 120 / 1 min / step]
3-903-004	Pattern Count	ENG*	[50 to 100 / 100 / 1 set / step]
3-903-005	Start Time	ENG	[0 to 0 / 0 / 0 / step]

3904	[Warm Up Short Mode]		
3-904-001	Action Level	ENG*	MP 6503 SP/7503 SP: [0 to 3 / 0 / 1 - / step] MP 9003 SP: [0 to 3 / 2 / 1 - / step]

3905	[exclusion time(90cpm)]		
3-905-001	Interval Setting	ENG*	[0 to 24 / 2 / 1 hour / step]

3930	[Total Bias Current]		
3-930-001	Change Control On/Off Set	ENG*	[0 or 1 / 1 / 1 - / step]
3-930-002	Change Control Threshold	ENG*	[0 to 500 / 180 / 1 V / step]
3-930-003	Average VG - VD	ENG*	[0 to 1000 / 0 / 1 V / step]

3940	[VG - VD History]		
3-940-001	Latest 1	ENG*	[0 to 1000 / 0 / 1 V / step]
3-940-002	Latest 2	ENG*	[0 to 1000 / 0 / 1 V / step]
3-940-003	Latest 3	ENG*	[0 to 1000 / 0 / 1 V / step]
3-940-004	Latest 4	ENG*	[0 to 1000 / 0 / 1 V / step]
3-940-005	Latest 5	ENG*	[0 to 1000 / 0 / 1 V / step]

3-940-006	Latest 6	ENG*	[0 to 1000 / 0 / 1 V / step]
3-940-007	Latest 7	ENG*	[0 to 1000 / 0 / 1 V / step]
3-940-008	Latest 8	ENG*	[0 to 1000 / 0 / 1 V / step]
3-940-009	Latest 9	ENG*	[0 to 1000 / 0 / 1 V / step]
3-940-010	Latest 10	ENG*	[0 to 1000 / 0 / 1 V / step]

3990	[Engine Process Adjust 1]		
3-990-001		ENG	[-32768 to 32767 / 0 / 1 / step]

3990	[Engine Process Adjust 2]		
3-990-002	-	ENG*	[-32768 to 32767 / 0 / 1 / step]

3990	[Engine Process Adjust 3]		
3-990-003	-	ENG*	[-32768 to 32767 / 0 / 1 / step]

3990	[Engine Process Adjust 4]		
3-990-004	-	ENG*	[-32768 to 32767 / 0 / 1 / step]

3990	[Toner Supply Execution Count]		
3-990-005	Count Value Setting	ENG*	[0 to 2 / 0 / 1 / step]

Engine SP Tables-4

SP4-XXX (Scanner)

4008	[Sub Scan Magnification Adj]		
4-008-001	-	ENG	[-1.0 to 1.0 / 0 / 0.1 % / step]

4010	[Sub Scan Registration Adj]		
4-010-001	-	ENG	[-2.0 to 2.0 / 0 / 0.1 mm / step]

4011	[Main Scan Reg]		
4-011-001	-	ENG*	[-2.5 to 2.5 / 0 / 0.1 mm / step]

4012	[Set Scale Mask]		
4-012-001	Book:Sub LEdge	ENG	[0 to 3.0 / 1.0 / 0.1 mm / step]
4-012-002	Book:Sub TEdge	ENG	[0 to 3.0 / 0 / 0.1 mm / step]
4-012-003	Book:Main:LEdge	ENG	[0 to 3.0 / 1.0 / 0.1 mm / step]
4-012-004	Book:Main:TEdge	ENG	[0 to 3.0 / 0 / 0.1 mm / step]
4-012-005	ADF: Leading Edge	ENG*	[0 to 3.0 / 0 / 0.1 mm / step]
4-012-007	ADF: Right	ENG*	[0 to 3.0 / 0 / 0.1 mm / step]
4-012-008	ADF: left	ENG*	[0 to 3.0 / 0 / 0.1 mm / step]

4013	[Scanner Free run]		
4-013-001	Book mode :Lamp Off	ENG	[0 or 1 / 0 / 1 / step]
4-013-002	Book mode :Lamp On	ENG	[0 or 1 / 0 / 1 / step]

4020	[Dust Check]		
4-020-001	Dust Detect:On/Off	ENG*	[0 or 1 / 0 / 1 / step]
4-020-002	Dust Detect:Lvl	ENG*	[0 to 8 / 4 / 1 / step]

4020	[Dust Check Lvl]		
4-020-003	Dust Reject:Lvl	ENG *	[0 to 4 / 0 / 1 / step]

4020	[DF Dust Check]		
4-020-011	Dust Detect Level:Rear	ENG *	[0 or 1 / 0 / 1 / step]
4-020-012	Correction Level:Rear	ENG *	[0 to 8 / 4 / 1 / step]

4201	[LoCPP edge level:K]		
4-201-001	600dpi 2bit edge1	ENG *	[0 to 15 / 15 / 1 / step]
4-201-002	600dpi 2bit edge23	ENG *	[0 to 15 / 15 / 1 / step]
4-201-003	600dpi 4bit edge1	ENG *	[0 to 15 / 15 / 1 / step]
4-201-004	600dpi 4bit edge23	ENG *	[0 to 15 / 15 / 1 / step]

4201	[LoCPP edge off/on:K]		
4-201-011	1200dpi 1bit edge12	ENG *	[0 or 1 / 0 / 1 / step]
4-201-012	1200dpi 1bit edge345	ENG *	[0 or 1 / 0 / 1 / step]

4301	[Operation Check APS Sensor]		
4-301-001	-	ENG	[0x00 to 0xFF / 0x00 / 1 / step]

4303	[Min Size for APS]		
4-303-001	-	ENG *	[0 or 1 / 0 / 1 / step]

4305	[8K/16K Detection]		
4-305-001	-	ENG *	[0 to 3 / 0 / 1 / step]

4308	[Scan Size Detection]		
4-308-001	Detection ON/OFF	ENG *	[0 to 2 / 1 / 1 / step]

4309	[Scan Size Detect:Setting]		
4-309-001	Original Density Thresh	ENG *	[0 to 255 / 28 / 1 digit / step]
4-309-002	Detection Time	ENG *	[20 to 100 / 60 / 20 msec / step]
4-309-003	Lamp ON:Delay Time	ENG *	[40 to 200 / 40 / 10 msec / step]
4-309-004	LED PWM Duty	ENG *	[0 to 100 / 15 / 1 / step]

4310	[Scan Size Detect Value]		
4-310-001	S1:R	ENG	[0 to 255 / 0 / 1 digit / step]
4-310-002	S1:G	ENG	[0 to 255 / 0 / 1 digit / step]
4-310-003	S1:B	ENG	[0 to 255 / 0 / 1 digit / step]
4-310-004	S2:R	ENG	[0 to 255 / 0 / 1 digit / step]
4-310-005	S2:G	ENG	[0 to 255 / 0 / 1 digit / step]
4-310-006	S2:B	ENG	[0 to 255 / 0 / 1 digit / step]
4-310-007	S3:R	ENG	[0 to 255 / 0 / 1 digit / step]
4-310-008	S3:G	ENG	[0 to 255 / 0 / 1 digit / step]
4-310-009	S3:B	ENG	[0 to 255 / 0 / 1 digit / step]

4400	[Org Edge Mask]		
4-400-001	Book:Sub LEdge	ENG	[0 to 3.0 / 1.0 / 0.1 mm / step]
4-400-002	Book:Sub:TEdge	ENG	[0 to 3.0 / 0 / 0.1 mm / step]
4-400-003	Book:Main:LEdge	ENG	[0 to 3.0 / 1.0 / 0.1 mm / step]
4-400-004	Book:Main:Tedge	ENG	[0 to 3.0 / 0 / 0.1 mm / step]
4-400-005	ADF: Leading Edge	ENG *	[0 to 3.0 / 0 / 0.1 mm / step]
4-400-007	ADF: Right	ENG *	[0 to 3.0 / 0 / 0.1 mm / step]
4-400-008	ADF: left	ENG *	[0 to 3.0 / 0 / 0.1 mm / step]

4417	[IPU Test Pattern]		
-------------	---------------------------	--	--

4-417-001	Test Pattern	ENG	[0 to 8 / 0 / 1 / step]
-----------	--------------	-----	-------------------------

4429	[Select Copy Data Security]		
4-429-001	Copying	ENG*	[0 to 3 / 3 / 1 / step]
4-429-002	Scanning	ENG*	[0 to 3 / 3 / 1 / step]
4-429-003	Fax Operation	ENG	[0 to 3 / 3 / 1 / step]

4460	[Digital AE]		
4-460-001	Low Limit Value	ENG*	[0 to 1023 / 364 / 1 / step]
4-460-002	Background level	ENG*	[512 to 1535 / 932 / 1 / step]

4550	[Scan Apli:Txt/Print]		
4-550-005	MTF: 0(Off) 1-15 (Weak-Strong)	ENG*	[0 to 15 / 8 / 1 / step]
4-550-006	Smoothing: 0(x1) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 4 / 1 / step]
4-550-007	Brightness: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-550-008	Contrast: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-550-009	Ind Dot Erase: 0(Off) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 0 / 1 / step]

4551	[Scan Apli:Txt]		
4-551-005	MTF: 0(Off) 1-15 (Weak-Strong)	ENG*	[0 to 15 / 8 / 1 / step]
4-551-006	Smoothing: 0(x1) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 4 / 1 / step]
4-551-007	Brightness: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-551-008	Contrast: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-551-009	Ind Dot Erase: 0(Off) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 0 / 1 / step]

4552	[Scan Apli:Txt Dropout]		
4-552-005	MTF: 0(Off) 1-15 (Weak-Strong)	ENG*	[0 to 15 / 8 / 1 / step]
4-552-006	Smoothing: 0(x1) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 4 / 1 / step]
4-552-007	Brightness: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-552-008	Contrast: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-552-009	Ind Dot Erase: 0(Off) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 0 / 1 / step]

4553	[Scan Apli:Txt/Photo]		
4-553-005	MTF: 0(Off) 1-15 (Weak-Strong)	ENG*	[0 to 15 / 8 / 1 / step]
4-553-006	Smoothing: 0(x1) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 4 / 1 / step]
4-553-007	Brightness: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-553-008	Contrast: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-553-009	Ind Dot Erase: 0(Off) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 0 / 1 / step]

4554	[Scan Apli:Photo]		
4-554-005	MTF: 0(Off) 1-15 (Weak-Strong)	ENG*	[0 to 15 / 8 / 1 / step]
4-554-006	Smoothing: 0(x1) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 4 / 1 / step]
4-554-007	Brightness: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-554-008	Contrast: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-554-009	Ind Dot Erase: 0(Off) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 0 / 1 / step]

4565	[Scan Apli:GrayScale]		
-------------	------------------------------	--	--

4-565-005	MTF: 0(Off) 1-15 (Weak-Strong)	ENG*	[0 to 15 / 8 / 1 / step]
4-565-006	Smoothing: 0(x1) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 4 / 1 / step]
4-565-007	Brightness: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-565-008	Contrast: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-565-009	Ind Dot Erase: 0(Off) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 0 / 1 / step]

4570	[Scan Apli:Col Txt/Photo]		
4-570-005	MTF: 0(Off) 1-15 (Weak-Strong)	ENG*	[0 to 15 / 8 / 1 / step]
4-570-006	Smoothing: 0(x1) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 4 / 1 / step]
4-570-007	Brightness: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-570-008	Contrast: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-570-009	Ind Dot Erase: 0(Off) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 0 / 1 / step]

4571	[Scan Apli:Col Gloss Photo]		
4-571-005	MTF: 0(Off) 1-15 (Weak-Strong)	ENG*	[0 to 15 / 8 / 1 / step]
4-571-006	Smoothing: 0(x1) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 4 / 1 / step]
4-571-007	Brightness: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-571-008	Contrast: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-571-009	Ind Dot Erase: 0(Off) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 0 / 1 / step]

4572	[Scan Apli:AutoCol]		
-------------	----------------------------	--	--

4-572-005	MTF: 0(Off) 1-15 (Weak-Strong)	ENG*	[0 to 15 / 8 / 1 / step]
4-572-006	Smoothing: 0(x1) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 4 / 1 / step]
4-572-007	Brightness: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-572-008	Contrast: 1-255	ENG*	[1 to 255 / 128 / 1 / step]
4-572-009	Ind Dot Erase: 0(Off) 1-7 (Weak-Strong)	ENG*	[0 to 7 / 0 / 1 / step]

4580	[Fax Apli:Txt/Chart]		
4-580-005	MTF: 0(Off) 1-15 (Weak-Strong)	ENG	[0 to 15 / 8 / 1 / step]
4-580-006	Smoothing: 0(x1) 1-7 (Weak-Strong)	ENG	[0 to 7 / 4 / 1 / step]
4-580-007	Brightness: 1-255	ENG	[1 to 255 / 128 / 1 / step]
4-580-008	Contrast: 1-255	ENG	[1 to 255 / 128 / 1 / step]
4-580-009	Ind Dot Erase: 0(Off) 1-7 (Weak-Strong)	ENG	[0 to 7 / 0 / 1 / step]
4-580-010	Texture Erase: 0	ENG	[0 to 2 / 0 / 1 / step]

4581	[Fax Apli:Txt]		
4-581-005	MTF: 0(Off) 1-15 (Weak-Strong)	ENG	[0 to 15 / 8 / 1 / step]
4-581-006	Smoothing: 0(x1) 1-7 (Weak-Strong)	ENG	[0 to 7 / 4 / 1 / step]
4-581-007	Brightness: 1-255	ENG	[1 to 255 / 128 / 1 / step]
4-581-008	Contrast: 1-255	ENG	[1 to 255 / 128 / 1 / step]
4-581-009	Ind Dot Erase: 0(Off) 1-7 (Weak-Strong)	ENG	[0 to 7 / 0 / 1 / step]

4582	[Fax Apli:Txt/Photo]		
-------------	-----------------------------	--	--

4-582-005	MTF: 0(Off) 1-15 (Weak-Strong)	ENG	[0 to 15 / 8 / 1 / step]
4-582-006	Smoothing: 0(x1) 1-7 (Weak-Strong)	ENG	[0 to 7 / 4 / 1 / step]
4-582-007	Brightness: 1-255	ENG	[1 to 255 / 128 / 1 / step]
4-582-008	Contrast: 1-255	ENG	[1 to 255 / 128 / 1 / step]
4-582-009	Ind Dot Erase: 0(Off) 1-7 (Weak-Strong)	ENG	[0 to 7 / 0 / 1 / step]
4-582-010	Texture Erase: 0	ENG	[0 to 2 / 0 / 1 / step]

4583	[Fax Apli:Photo]		
4-583-005	MTF: 0(Off) 1-15 (Weak-Strong)	ENG	[0 to 15 / 8 / 1 / step]
4-583-006	Smoothing: 0(x1) 1-7 (Weak-Strong)	ENG	[0 to 7 / 4 / 1 / step]
4-583-007	Brightness: 1-255	ENG	[1 to 255 / 128 / 1 / step]
4-583-008	Contrast: 1-255	ENG	[1 to 255 / 128 / 1 / step]
4-583-009	Ind Dot Erase: 0(Off) 1-7 (Weak-Strong)	ENG	[0 to 7 / 0 / 1 / step]
4-583-010	Texture Erase: 0	ENG	[0 to 2 / 0 / 1 / step]

4584	[Fax Apli:Original 1]		
4-584-005	MTF: 0(Off) 1-15 (Weak-Strong)	ENG	[0 to 15 / 8 / 1 / step]
4-584-006	Smoothing: 0(x1) 1-7 (Weak-Strong)	ENG	[0 to 7 / 4 / 1 / step]
4-584-007	Brightness: 1-255	ENG	[1 to 255 / 128 / 1 / step]
4-584-008	Contrast: 1-255	ENG	[1 to 255 / 128 / 1 / step]
4-584-009	Ind Dot Erase: 0(Off) 1-7 (Weak-Strong)	ENG	[0 to 7 / 0 / 1 / step]

4585	[Fax Apli:Original 2]		
4-585-005	MTF: 0(Off) 1-15 (Weak-Strong)	ENG	[0 to 15 / 8 / 1 / step]
4-585-006	Smoothing: 0(x1) 1-7 (Weak-Strong)	ENG	[0 to 7 / 4 / 1 / step]
4-585-007	Brightness: 1-255	ENG	[1 to 255 / 128 / 1 / step]
4-585-008	Contrast: 1-255	ENG	[1 to 255 / 128 / 1 / step]
4-585-009	Independent Dot Erase (0)/ 1-7 (Strong)	ENG	[0 to 7 / 0 / 1 / step]

4600	[SBU Version Display]		
4-600-001	SBU_ID	ENG	[0x0000 to 0xFFFF / 0 / 1 / step]

4609	[Gray Balance Set: R]		
4-609-001	Book Scan	ENG*	[-384 to 255 / -100 / 1 digit / step]
4-609-002	DF Scan	ENG*	[-384 to 255 / -100 / 1 digit / step]

4610	[Gray Balance Set: G]		
4-610-001	Book Scan	ENG*	[-384 to 255 / -100 / 1 digit / step]
4-610-002	DF Scan	ENG*	[-384 to 255 / -100 / 1 digit / step]

4611	[Gray Balance Set: B]		
4-611-001	Book Scan	ENG*	[-384 to 255 / -100 / 1 digit / step]
4-611-002	DF Scan	ENG*	[-384 to 255 / -100 / 1 digit / step]

4646	[Scan Adjust Error]		
4-646-001	White level	ENG*	[0 to 65535 / 0 / 1 / step]
4-646-002	Black level	ENG*	[0 to 65535 / 0 / 1 / step]

4647	[Scanner Hard Error]		
-------------	-----------------------------	--	--

4-647-001	Power-ON	ENG	[0 to 65535 / 0 / 1 / step]
4688	[Scan Image Density Adjustment]		
4-688-002	1-pass DF	ENG*	[80 to 120 / 103 / 1 % / step]
4699	[SBU Test Pattern Change]		
4-699-001	-	ENG	[0 to 255 / 0 / 1 / step]
4700	[CIS ID Display]		
4-700-001	-	ENG	[0x00 to 0xFF / 0 / 1 / step]
4712	[CIS GB Adj. Value: R]		
4-712-001	-	ENG*	[0 to 2048 / 1023 / 1 digit / step]
4713	[CIS GB Adj. Value: G]		
4-713-001	-	ENG*	[0 to 2048 / 1023 / 1 digit / step]
4714	[CIS GB Adj. Value: B]		
4-714-001	-	ENG*	[0 to 2048 / 1023 / 1 digit / step]
4730	[FROM ADF Factory Setting]		
4-730-001	CIS Parameter	ENG	[0 or 1 / 0 / 0 / step]
4730	[FROM Factory Setting]		
4-730-002	Execution ON/OFF	ENG	[0 or 1 / 0 / 0 / step]
4-730-003	Execution Flag	ENG*	[0 or 1 / 0 / 1 / step]
4730	[FROM Data Update]		
4-730-004	-	ENG	[0 or 1 / 0 / 0 / step]

4745	[CIS Image Level Error Flag]		
4-745-001		ENG	[0 to 65535 / 0 / 1 / step]
4746	[CIS GB Adj Error Flag]		
4-746-001	-	ENG	[0 to 7 / 0 / 1 / step]
4747	[CIS Hard Error Flag]		
4-747-001	-	ENG	[0 to 15 / 0 / 1 / step]
4796	[Low Density Color Correction]		
4-796-001	Front Side	ENG*	[0 to 3 / 0 / 1 / step]
4-796-002	Rear Side	ENG*	[0 to 3 / 0 / 1 / step]
4797	[Rear Side: Digital AE]		
4-797-001	Low Limit Setting	ENG*	[0 to 1023 / 364 / 1 / step]
4-797-002	Background Erase Level	ENG*	[512 to 1535 / 932 / 1 / step]
4799	[CIS TEST Pattern]		
4-799-001	select	ENG	[0 to 5 / 0 / 1 / step]
4-799-002	Even Output Level Setting	ENG	[0 to 1023 / 0 / 1 digit / step]
4-799-003	Odd Output Level Setting	ENG	[0 to 1023 / 0 / 1 digit / step]
4803	[Home Position Adj Value]		
4-803-001	-	ENG*	[-2.0 to 2.0 / 0 / 0.1 mm / step]
4813	[ALC Selection]		
4-813-001	FC	ENG*	[0 to 1 / 1 / 1 / step]
4-813-002	BW	ENG*	[0 to 1 / 1 / 1 / step]

4850	[PWM]		
4-850-001	Latest	ENG*	[0 to 8416 / 0 / 1 digit / step]
4-850-002	Factory Setting	ENG*	[0 to 8416 / 0 / 1 digit / step]

4853	[Partial LED ON]		
4-853-001	ON/OFF(Scan)	ENG*	[0 to 1 / 1 / 1 / step]
4-853-002	ON/OFF(Size Detection)	ENG*	[0 to 1 / 1 / 1 / step]

4901	[Background Erase]		
4-901-020	Blue Original (Lighter)	ENG*	[-128 to 127 / 0 / 1 / step]
4-901-021	Blue Original (Normal)	ENG*	[-128 to 127 / 0 / 1 / step]
4-901-022	Blue Original (Darker)	ENG*	[-128 to 127 / 0 / 1 / step]

4903	[Filter Setting]		
4-903-001	Ind Dot Erase: Text	ENG*	[0 to 7 / 0 / 1 / step]
4-903-002	Ind Dot Erase: Generation Copy	ENG*	[0 to 7 / 0 / 1 / step]

4905	[Select Gradation Level]		
4-905-001	-	ENG*	[0 to 255 / 0 / 1 / step]

4918	[Man Gamma Adj]		
4-918-009	-	ENG	[0 to 0 / 0 / 0 / step]

4938	[ACS:Edge Mask]		
4-938-005	Scan:Sub LEdge	ENG*	[0 to 31 / 15 / 1 / step]
4-938-006	Scan:Sub TEdge	ENG*	[0 to 31 / 15 / 1 / step]
4-938-007	Scan:Main LEdge	ENG*	[0 to 31 / 15 / 1 / step]

4-938-008	Scan:Main TEdge	ENG *	[0 to 31 / 15 / 1 / step]
4939	[ACS:Color Range]		
4-939-001	-	ENG *	[-2 to 2 / 0 / 1 / step]
4954	[Standard Chart: Restore]		
4-954-005	Standard Chart Chromaticity Rank	ENG *	[0 to 255 / 0 / 1 / step]
4958	[Standard Chart: Back: Restore]		
4-958-005	Standard Chart Chromaticity Rank	ENG *	[0 to 255 / 0 / 1 / step]
4993	[High Light Correction]		
4-993-001	Sensitivity Selection	ENG *	[0 to 9 / 4 / 1 / step]
4-993-002	Range Selection	ENG *	[0 to 9 / 4 / 1 / step]
4994	[Adj Txt/Photo Recog Level]		
4-994-001	High Compression PDF	ENG *	[0 to 2 / 1 / 1 / step]
4996	[White Paper Detection Level]		
4-996-001		ENG *	[0 to 6 / 3 / 1 / step]

Engine SP Tables-5

SP5-XXX (Mode)

5126	[Set F-size Document]		
5-126-001	-	ENG*	[0 to 2 / 0 / 1 / step]
5129	[F Paper Size Selection]		
5-129-001	-	ENG	[0 to 2 / 0 / 1 / step]
5131	[Paper Size Type Selection]		
5-131-001	Paper Size Destination Selection	ENG*	NA: [0 to 3 / 1 / 1 / step] Others: [0 to 3 / 2 / 1 / step]
5-131-002	Bypass Automatic Size Detection ON/OFF	ENG*	[0 or 1 / 1 / 1 / step]
5135	[Oficio Priority Detection Set]		
5-135-001	-	ENG*	[0 or 1 / 0 / 1 / step]
5179	[By-pass PaperSize ErrorDisplay]		
5-179-001	0: OFF/1: ON	ENG	[0 or 1 / 0 / 1 / step]
5801	[Memory Clear]		
5-801-002	Engine	ENG	[0 or 1 / 0 / 1 / step]
5802	[Printer Free Run]		
5-802-001		ENG*	[0 or 1 / 0 / 1 / step]

5803	[INPUTCHECK]		
	page 214 "Main Machine, LTC"		

5804	[Output Check]		
	page 237 "Main Machine, LTC"		

5811	[MachineSerial]		
	5-811-002	Display	ENG* [0 to 255 / 0 / 1 / step]

5811	[Machine Serial Number]		
	5-811-004	Set:BICU	ENG [0 to 255 / 0 / 1 / step]
	5-811-023	Previous	ENG* [0 to 255 / 0 / 1 / step]
	5-811-026	Previous (BICU)	ENG* [0 to 255 / 0 / 1 / step]

5811	[Machine Serial Update Date]		
	5-811-021	Latest	ENG* [0 or 1 / 0 / 1 / step]
	5-811-022	Previous	ENG* [0 or 1 / 0 / 1 / step]
	5-811-024	Latest (BICU)	ENG* [0 or 1 / 0 / 1 / step]
	5-811-025	Previous (BICU)	ENG* [0 or 1 / 0 / 1 / step]

5894	[External Charge Unit Setting]		
	5-894-001	Switch Charge Mode	ENG [0 to 2 / 0 / 1 / step]

5899	[PM Double Count]		
	5-899-001	-	ENG [0 or 1 / 0 / 1 / step]

5900	[Engine Log Upload]		
	5-900-001	Pattern	ENG* [0 to 4 / 0 / 1 / step]

5915	[Mechanical Counter Detection]		
5-915-001	(1:Detect)	ENG	[0 to 0 / 0 / 0 / step]

5952	[Fact Adjust Mode]		
5-952-001	-	ENG	[0 or 1 / 0 / 1 / step]

5957	[Front/Right Door Config. SW]		
5-957-001	-	ENG	[0 or 1 / 1 / 1 / step]

5959	[Paper Size]		
5-959-001	Tray 1	ENG *	NA: [0 to 11 / 1 / 1 / step] Others: [0 to 11 / 0 / 1 / step]
5-959-005	LCT	ENG *	NA: [0 to 11 / 1 / 1 / step] Others: [0 to 11 / 0 / 1 / step]
5-959-006	Cover Sheet	ENG	[0 to 255 / 0 / 1 / step]

Engine SP Tables-6

SP6-XXX (Peripherals)

2

6006	[ADF Adjustment]		
6-006-001	Side-to-Side Regist: Front	ENG*	[-3.0 to 3.0 / 0 / 0.1 mm / step]
6-006-002	Side-to-Side Regist: Rear	ENG*	[-3.0 to 3.0 / 0 / 0.1 mm / step]
6-006-010	L-Edge Regist (1-Pass): Front	ENG*	[-5.0 to 5.0 / 0 / 0.1 mm / step]
6-006-011	L-Edge Regist (1-Pass): Rear	ENG*	[-5.0 to 5.0 / 0 / 0.1 mm / step]
6-006-012	1st Buckle (1-Pass)	ENG*	[-3.0 to 3.0 / 0 / 0.1 mm / step]
6-006-013	2nd Buckle (1-Pass)	ENG*	[-2.0 to 3.0 / 0 / 0.1 mm / step]
6-006-014	T-Edge Erase (1-Pass): Front	ENG*	[-5.0 to 5.0 / -3.0 / 0.1 mm / step]
6-006-015	T-Edge Erase (1-Pass): Rear	ENG*	[-5.0 to 5.0 / -2.5 / 0.1 mm / step]

6009	[ADF FreeRun]		
6-009-001	Free Run Simplex Motion	ENG	[0 or 1 / 0 / 1 / step]
6-009-002	Free Run Duplex Motion	ENG	[0 or 1 / 0 / 1 / step]
6-009-003	Free Run Stamp Motion	ENG	[0 or 1 / 0 / 1 / step]

6010	[Stamp Position Adj.]		
6-010-001	-	ENG*	[-5.0 to 5.0 / 0 / 0.1 mm / step]

6011	[1-Pass ADF INPUT Check]		
	page 227 "ADF"		

6012	[1-Pass ADF OUTPUT Check]		
	page 241 "ADF"		

6016	[Original Size Detect Setting]		
6-016-001	-	ENG*	[0x00 to 0xFF / 0x00 / 1 / step]

6017	[DF Magnification Adj.]		
6-017-001	-	ENG*	[-5.0 to 5.0 / 0 / 0.1 % / step]

6020	[Skew Correction Moving Setting]		
6-020-001	-	ENG*	[0 or 1 / 0 / 1 / step]

6100	[Sub-scanPunchPosAdj;2K/3K FIN]		
6-100-001	JPN/EU: 2-Hole	ENG	[-75 to 75 / 0 / 0.5 mm / step]
6-100-002	NA: 3-Hole	ENG	[-75 to 75 / 0 / 0.5 mm / step]
6-100-003	Europe: 4-Hole	ENG	[-75 to 75 / 0 / 0.5 mm / step]
6-100-004	NEU: 4-Hole	ENG	[-75 to 75 / 0 / 0.5 mm / step]
6-100-005	NA: 2-Hole	ENG	[-75 to 75 / 0 / 0.5 mm / step]
6-100-006	JPN: 1-Hole	ENG	[-75 to 75 / 0 / 0.5 mm / step]

6101	[Main-scanPunchPosAdj;2K/3K FIN]		
6-101-001	JPN/EU: 2-Hole	ENG	[-20 to 20 / 0 / 0.4 mm / step]
6-101-002	NA: 3-Hole	ENG	[-20 to 20 / 0 / 0.4 mm / step]
6-101-003	Europe: 4-Hole	ENG	[-20 to 20 / 0 / 0.4 mm / step]
6-101-004	NEU: 4-Hole	ENG	[-20 to 20 / 0 / 0.4 mm / step]
6-101-005	NA: 2-Hole	ENG	[-20 to 20 / 0 / 0.4 mm / step]
6-101-006	JPN:1-1Hole	ENG	[-20 to 20 / 0 / 0.5 mm / step]

6102	[SkewCorrectBuckleAdj;2K/3K FIN]		
6-102-001	A3 SEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-002	B4 SEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]

6-102-003	A4 SEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-004	A4 LEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-005	B5 SEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-006	B5 LEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-007	A5 LEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-008	DLT SEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-009	LG SEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-010	Oficio SEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-011	LT SEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-012	LT LEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-013	HLT LEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-014	12"x18"	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-015	8K SEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-016	16K SEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-017	16K LEF	ENG	[-50 to 50 / 0 / 0.2 mm / step]
6-102-018	Other	ENG	[-50 to 50 / 0 / 0.2 mm / step]

6103	[SkewCorrectCtrlSW:2K/3K FIN]		
6-103-001	A3 SEF	ENG	[0 or 1 / 0 / 1 / step]
6-103-002	B4 SEF	ENG	[0 or 1 / 0 / 1 / step]
6-103-003	A4 SEF	ENG	[0 or 1 / 0 / 1 / step]
6-103-004	A4 LEF	ENG	[0 or 1 / 0 / 1 / step]
6-103-005	B5 SEF	ENG	[0 or 1 / 0 / 1 / step]
6-103-006	B5 LEF	ENG	[0 or 1 / 0 / 1 / step]
6-103-007	A5 LEF	ENG	[0 or 1 / 0 / 1 / step]
6-103-008	DLT SEF	ENG	[0 or 1 / 0 / 1 / step]

6-103-009	LG SEF	ENG	[0 or 1 / 0 / 1 / step]
6-103-010	Oficio SEF	ENG	[0 or 1 / 0 / 1 / step]
6-103-011	LT SEF	ENG	[0 or 1 / 0 / 1 / step]
6-103-012	LT LEF	ENG	[0 or 1 / 0 / 1 / step]
6-103-013	HLT LEF	ENG	[0 or 1 / 0 / 1 / step]
6-103-014	12"x18"	ENG	[0 or 1 / 0 / 1 / step]
6-103-015	8K SEF	ENG	[0 or 1 / 0 / 1 / step]
6-103-016	16K SEF	ENG	[0 or 1 / 0 / 1 / step]
6-103-017	16K LEF	ENG	[0 or 1 / 0 / 1 / step]
6-103-018	Other	ENG	[0 or 1 / 0 / 1 / step]

6104	[ShiftTrayJogPosAdj:2K/3K FIN]		
6-104-001	A3 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-104-002	B4 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-104-003	A4 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-104-004	A4 LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-104-005	B5 LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-104-006	A5 LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-104-007	DLT SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-104-008	LG SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-104-009	Oficio SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-104-010	LT SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-104-011	LT LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-104-012	HLT LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-104-013	8K SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-104-014	16K LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]

6-104-015	Other	ENG	[-15 to 15 / 0 / 0.5 mm / step]
-----------	-------	-----	---------------------------------

6105	[ShftJogRtrctAngAdj:2K/3K FIN]		
6-105-001	A3 SEF	ENG	[-10 to 10 / 0 / 5 deg / step]
6-105-002	B4 SEF	ENG	[-10 to 10 / 0 / 5 deg / step]
6-105-003	A4 SEF	ENG	[-10 to 10 / 0 / 5 deg / step]
6-105-004	DLT SEF	ENG	[-10 to 10 / 0 / 5 deg / step]
6-105-005	LG SEF	ENG	[-10 to 10 / 0 / 5 deg / step]
6-105-006	Oficio SEF	ENG	[-10 to 10 / 0 / 5 deg / step]
6-105-007	LT SEF	ENG	[-10 to 10 / 0 / 5 deg / step]
6-105-008	8K SEF	ENG	[-10 to 10 / 0 / 5 deg / step]
6-105-009	Other	ENG	[-10 to 10 / 0 / 5 deg / step]

6106	[Use Paper Jogger: 2K/3K FIN]		
6-106-001	A3 SEF	ENG	[0 or 1 / 0 / 1 / step]
6-106-002	B4 SEF	ENG	[0 or 1 / 0 / 1 / step]
6-106-003	A4 SEF	ENG	[0 or 1 / 0 / 1 / step]
6-106-004	A4 LEF	ENG	[0 or 1 / 0 / 1 / step]
6-106-005	B5 LEF	ENG	[0 or 1 / 0 / 1 / step]
6-106-006	A5 LEF	ENG	[0 or 1 / 0 / 1 / step]
6-106-007	DLT SEF	ENG	[0 or 1 / 0 / 1 / step]
6-106-008	LG SEF	ENG	[0 or 1 / 0 / 1 / step]
6-106-009	Oficio SEF	ENG	[0 or 1 / 0 / 1 / step]
6-106-010	LT SEF	ENG	[0 or 1 / 0 / 1 / step]
6-106-011	LT LEF	ENG	[0 or 1 / 0 / 1 / step]
6-106-012	HLT LEF	ENG	[0 or 1 / 0 / 1 / step]
6-106-013	8K SEF	ENG	[0 or 1 / 0 / 1 / step]

6-106-014	16K LEF	ENG	[0 or 1 / 0 / 1 / step]
6-106-015	Other	ENG	[0 or 1 / 0 / 1 / step]

6107	[JogPosAdj(CmrStplr):2K/3K FIN]		
6-107-001	A3 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-107-002	B4 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-107-003	A4 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-107-004	A4 LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-107-005	B5 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-107-006	B5 LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-107-007	DLT SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-107-008	LG SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-107-009	Oficio SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-107-010	LT SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-107-011	LT LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-107-012	8K SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-107-013	16K SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-107-014	16K LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-107-015	Other	ENG	[-15 to 15 / 0 / 0.5 mm / step]

6108	[JogPosAdj(BookStplr):2K/3K FIN]		
6-108-001	A3 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-108-002	B4 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-108-003	A4 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-108-004	B5 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-108-005	DLT SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-108-006	LG SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]

6-108-007	Oficio SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-108-008	LT SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-108-009	12"x18"	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-108-010	8K SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-108-011	Other	ENG	[-15 to 15 / 0 / 0.5 mm / step]

6109	[CnrrStplrJogTimeAdj:2K/3K FIN]		
6-109-001	A3 SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-109-002	B4 SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-109-003	A4 SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-109-004	A4 LEF	ENG	[0 to 2 / 0 / 1 times / step]
6-109-005	B5 SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-109-006	B5 LEF	ENG	[0 to 2 / 0 / 1 times / step]
6-109-007	DLT SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-109-008	LG SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-109-009	Oficio SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-109-010	LT SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-109-011	LT LEF	ENG	[0 to 2 / 0 / 1 times / step]
6-109-012	8K SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-109-013	16K SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-109-014	16K LEF	ENG	[0 to 2 / 0 / 1 times / step]
6-109-015	Other	ENG	[0 to 2 / 0 / 1 times / step]

6110	[BookStplrJogTimeAdj:2K/3K FIN]		
6-110-001	A3 SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-110-002	B4 SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-110-003	A4 SEF	ENG	[0 to 2 / 0 / 1 times / step]

6-110-004	B5 SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-110-005	DLT SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-110-006	LG SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-110-007	Oficio SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-110-008	LT SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-110-009	12"x18"	ENG	[0 to 2 / 0 / 1 times / step]
6-110-010	8K SEF	ENG	[0 to 2 / 0 / 1 times / step]
6-110-011	Other	ENG	[0 to 2 / 0 / 1 times / step]

6111	[Staple Position Adj: 2K/3K FIN]		
6-111-001	A3 SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-111-002	B4 SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-111-003	A4 SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-111-004	A4 LEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-111-005	B5 SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-111-006	B5 LEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-111-007	DLT SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-111-008	LG SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-111-009	Oficio SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-111-010	LT SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-111-011	LT LEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-111-012	8K SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-111-013	16K SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-111-014	16K LEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-111-015	Other	ENG	[-35 to 35 / 0 / 0.5 mm / step]

6112	[BookletStaplerPosAdj:2K/3K FIN]		
-------------	---	--	--

6-112-001	A3 SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-112-002	B4 SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-112-003	A4 SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-112-004	B5 SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-112-005	DLT SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-112-006	LG SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-112-007	Oficio SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-112-008	LT SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-112-009	12"x18"	ENG	[-18 to 18 / 0 / 0.2 mm / step]
6-112-010	8K SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-112-011	Other	ENG	[-18 to 18 / 0 / 0.2 mm / step]

6113	[BookletFolderPosAdj:2K/3K FIN]		
6-113-001	A3 SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-002	B4 SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-003	A4 SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-004	B5 SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-005	DLT SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-006	LG SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-007	Oficio SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-008	LT SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-009	12"* 18"	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-010	8-Kai SEF	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-011	Other	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-012	A3 SEF(1-5)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-013	A3 SEF(6-10)	ENG	[-30 to 30 / 0 / 0.2 mm / step]

6-113-014	A3 SEF(11-15)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-015	A3 SEF(16-over)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-016	B4 SEF(1-5)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-017	B4 SEF(6-10)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-018	B4 SEF(11-15)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-019	B4 SEF(16-over)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-020	A4 SEF(1-5)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-021	A4 SEF(6-10)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-022	A4 SEF(11-15)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-023	A4 SEF(16-over)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-024	B5 SEF(1-5)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-025	B5 SEF(6-10)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-026	B5 SEF(11-15)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-027	B5 SEF(16-over)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-028	DLT SEF(1-5)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-029	DLT SEF(6-10)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-030	DLT SEF(11-15)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-031	DLT SEF(16-over)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-032	LG SEF(1-5)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-033	LG SEF(6-10)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-034	LG SEF(11-15)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-035	LG SEF(16-over)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-036	Oficio SEF(1-5)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-037	Oficio SEF(6-10)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-038	Oficio SEF(11-15)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-039	Oficio SEF(16-over)	ENG	[-30 to 30 / 0 / 0.2 mm / step]

6-113-040	LT SEF(1-5)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-041	LT SEF(6-10)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-042	LT SEF(11-15)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-043	LT SEF(16-over)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-044	12"x18"(1-5)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-045	12"x18"(6-10)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-046	12"x18"(11-15)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-047	12"x18"(16-over)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-048	8K SEF(1-5)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-049	8K SEF(6-10)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-050	8K SEF(11-15)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-051	8K SEF(16-over)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-052	Other(1-5)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-053	Other(6-10)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-054	Other(11-15)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-113-055	Other(16-over)	ENG	[-30 to 30 / 0 / 0.2 mm / step]

6114	[Fold Speed Adj.: 2K/3K FIN]		
6-114-001	A3 SEF	ENG	[0 to 2 / 0 / 1 / step]
6-114-002	B4 SEF	ENG	[0 to 2 / 0 / 1 / step]
6-114-003	A4 SEF	ENG	[0 to 2 / 0 / 1 / step]
6-114-004	B5 SEF	ENG	[0 to 2 / 0 / 1 / step]
6-114-005	DLT SEF	ENG	[0 to 2 / 0 / 1 / step]
6-114-006	LG SEF	ENG	[0 to 2 / 0 / 1 / step]
6-114-007	Oficio SEF	ENG	[0 to 2 / 0 / 1 / step]
6-114-008	LT SEF	ENG	[0 to 2 / 0 / 1 / step]

6-114-009	12"x18"	ENG	[0 to 2 / 0 / 1 / step]
6-114-010	8K SEF	ENG	[0 to 2 / 0 / 1 / step]
6-114-011	Other	ENG	[0 to 2 / 0 / 1 / step]

2

6115	[Finisher Free Run: 2K/3K FIN]		
6-115-001	Free Run 1	ENG	[0 or 1 / 0 / 1 / step]
6-115-002	Free Run 2	ENG	[0 or 1 / 0 / 1 / step]
6-115-003	Free Run 3	ENG	[0 or 1 / 0 / 1 / step]
6-115-004	Free Run 4	ENG	[0 or 1 / 0 / 1 / step]
6-115-005	Service Parts Pstion Shift Free Run	ENG	[0 or 1 / 0 / 1 / step]

6116	[CmnrStplrMxPrstkShAdj:2K/3KFIN]		
6-116-001	A3 SEF	ENG	[-1 to 0 / 0 / 1 sheets / step]
6-116-002	B4 SEF	ENG	[-1 to 0 / 0 / 1 sheets / step]
6-116-003	A4 SEF	ENG	[-1 to 0 / 0 / 1 sheets / step]
6-116-004	A4 LEF	ENG	[-1 to 0 / 0 / 1 sheets / step]
6-116-005	B5 SEF	ENG	[-1 to 0 / 0 / 1 sheets / step]
6-116-006	B5 LEF	ENG	[-1 to 0 / 0 / 1 sheets / step]
6-116-007	DLT SEF	ENG	[-1 to 0 / 0 / 1 sheets / step]
6-116-008	LG SEF	ENG	[-1 to 0 / 0 / 1 sheets / step]
6-116-009	Oficio SEF	ENG	[-1 to 0 / 0 / 1 sheets / step]
6-116-010	LT SEF	ENG	[-1 to 0 / 0 / 1 sheets / step]
6-116-011	LT LEF	ENG	[-1 to 0 / 0 / 1 sheets / step]
6-116-012	8K SEF	ENG	[-1 to 0 / 0 / 1 sheets / step]
6-116-013	16K SEF	ENG	[-1 to 0 / 0 / 1 sheets / step]
6-116-014	16K LEF	ENG	[-1 to 0 / 0 / 1 sheets / step]

6-116-015	Other	ENG	[-1 to 0 / 0 / 1 sheets / step]
-----------	-------	-----	---------------------------------

6117	[BookStplrMxPrstkShAdj:2K/3KFIN]		
6-117-001	A3 SEF	ENG	[-2 to 0 / 0 / 1 sheets / step]
6-117-002	B4 SEF	ENG	[-2 to 0 / 0 / 1 sheets / step]
6-117-003	A4 SEF	ENG	[-2 to 0 / 0 / 1 sheets / step]
6-117-004	B5 SEF	ENG	[-2 to 0 / 0 / 1 sheets / step]
6-117-005	DLT SEF	ENG	[-2 to 0 / 0 / 1 sheets / step]
6-117-006	LG SEF	ENG	[-2 to 0 / 0 / 1 sheets / step]
6-117-007	Oficio SEF	ENG	[-2 to 0 / 0 / 1 sheets / step]
6-117-008	LT SEF	ENG	[-2 to 0 / 0 / 1 sheets / step]
6-117-009	12"x18"	ENG	[-2 to 0 / 0 / 1 sheets / step]
6-117-010	8K SEF	ENG	[-2 to 0 / 0 / 1 sheets / step]
6-117-011	Other	ENG	[-2 to 0 / 0 / 1 sheets / step]

6118	[CnrStplrPrstkOffsAdj:2K/3KFIN]		
6-118-001	A3 SEF	ENG	[-16 to 16 / 0 / 2 mm / step]
6-118-002	B4 SEF	ENG	[-16 to 16 / 0 / 2 mm / step]
6-118-003	A4 SEF	ENG	[-16 to 16 / 0 / 2 mm / step]
6-118-004	A4 LEF	ENG	[-16 to 16 / 0 / 2 mm / step]
6-118-005	B5 SEF	ENG	[-16 to 16 / 0 / 2 mm / step]
6-118-006	B5 LEF	ENG	[-16 to 16 / 0 / 2 mm / step]
6-118-007	DLT SEF	ENG	[-16 to 16 / 0 / 2 mm / step]
6-118-008	LG SEF	ENG	[-16 to 16 / 0 / 2 mm / step]
6-118-009	Oficio SEF	ENG	[-16 to 16 / 0 / 2 mm / step]
6-118-010	LT SEF	ENG	[-16 to 16 / 0 / 2 mm / step]
6-118-011	LT LEF	ENG	[-16 to 16 / 0 / 2 mm / step]

6-118-012	8K SEF	ENG	[-16 to 16 / 0 / 2 mm / step]
6-118-013	16K SEF	ENG	[-16 to 16 / 0 / 2 mm / step]
6-118-014	16K LEF	ENG	[-16 to 16 / 0 / 2 mm / step]
6-118-015	Other	ENG	[-16 to 16 / 0 / 2 mm / step]

6119	[BookStplrMxPrstkShAdj:2K/3KFIN]		
6-119-001	A3 SEF	ENG	[-30 to 30 / 0 / 2 mm / step]
6-119-002	B4 SEF	ENG	[-30 to 30 / 0 / 2 mm / step]
6-119-003	A4 SEF	ENG	[-30 to 30 / 0 / 2 mm / step]
6-119-004	B5 SEF	ENG	[-30 to 30 / 0 / 2 mm / step]
6-119-005	DLT SEF	ENG	[-30 to 30 / 0 / 2 mm / step]
6-119-006	LG SEF	ENG	[-30 to 30 / 0 / 2 mm / step]
6-119-007	Oficio SEF	ENG	[-30 to 30 / 0 / 2 mm / step]
6-119-008	LT SEF	ENG	[-30 to 30 / 0 / 2 mm / step]
6-119-009	12"x18"	ENG	[-30 to 30 / 0 / 2 mm / step]
6-119-010	8K SEF	ENG	[-30 to 30 / 0 / 2 mm / step]
6-119-011	Other	ENG	[-30 to 30 / 0 / 2 mm / step]

6120	[CrnStpPosExFeedAmtAdj:2K/3KFIN]		
6-120-001	A3 SEF	ENG	[0 to 30 / 0 / 10 mm / step]
6-120-002	B4 SEF	ENG	[0 to 30 / 0 / 10 mm / step]
6-120-003	A4 SEF	ENG	[0 to 30 / 0 / 10 mm / step]
6-120-004	A4 LEF	ENG	[0 to 30 / 0 / 10 mm / step]
6-120-005	B5 SEF	ENG	[0 to 30 / 0 / 10 mm / step]
6-120-006	B5 LEF	ENG	[0 to 30 / 0 / 10 mm / step]
6-120-007	DLT SEF	ENG	[0 to 30 / 0 / 10 mm / step]
6-120-008	LG SEF	ENG	[0 to 30 / 0 / 10 mm / step]

6-120-009	Oficio SEF	ENG	[0 to 30 / 0 / 10 mm / step]
6-120-010	LT SEF	ENG	[0 to 30 / 0 / 10 mm / step]
6-120-011	LT LEF	ENG	[0 to 30 / 0 / 10 mm / step]
6-120-012	8K SEF	ENG	[0 to 30 / 0 / 10 mm / step]
6-120-013	16K SEF	ENG	[0 to 30 / 0 / 10 mm / step]
6-120-014	16K LEF	ENG	[0 to 30 / 0 / 10 mm / step]
6-120-015	Other	ENG	[0 to 30 / 0 / 10 mm / step]

6121	[NV Adjustment Data Rewrite]		
6-121-001	Jogger Position Factory Adj.	ENG	[-30 to 30 / 0 / 0.5 mm / step]
6-121-002	Folding Position Factory Adj.	ENG	[-14 to 14 / 0 / 0.2 mm / step]

6122	[BkFoldJogSolMovAmtAdj:2K/3KFIN]		
6-122-001	A3 SEF	ENG	[-5 to 5 / 0 / 1 mm / step]
6-122-002	B4 SEF	ENG	[-5 to 5 / 0 / 1 mm / step]
6-122-003	A4 SEF	ENG	[-5 to 5 / 0 / 1 mm / step]
6-122-004	B5 SEF	ENG	[-5 to 5 / 0 / 1 mm / step]
6-122-005	DLT SEF	ENG	[-5 to 5 / 0 / 1 mm / step]
6-122-006	LG SEF	ENG	[-5 to 5 / 0 / 1 mm / step]
6-122-007	Oficio SEF	ENG	[-5 to 5 / 0 / 1 mm / step]
6-122-008	LT SEF	ENG	[-5 to 5 / 0 / 1 mm / step]
6-122-009	12"x18"	ENG	[-5 to 5 / 0 / 1 mm / step]
6-122-010	8K SEF	ENG	[-5 to 5 / 0 / 1 mm / step]
6-122-011	Other	ENG	[-5 to 5 / 0 / 1 mm / step]

6123	[INPUT Check: 2K/3K FIN]		
	page 228 "2K/3K Finisher"		
6124	[OUTPUT Check: 2K/3K FIN]		
	page 241 "2K/3K Finisher"		
6125	[Use Paper Guide(Big Size)]		
6-125-001	All Size	ENG	[0 or 1 / 1 / 1 / step]
6126	[Use Paper Guide(Small Size)]		
6-126-001	All Size	ENG	[0 or 1 / 0 / 1 / step]
6127	[Paper Guide PossAdj:2K/3K FIN]		
6-127-001	All Size	ENG	[-10 to 10 / 0 / 1 mm / step]
6128	[Paper Guide RetraAdj:2K/3K FIN]		
6-128-001	All Size	ENG	[-50 to 50 / 0 / 5 mm / step]
6129	[Paper Guide AceptAdj:2K/3K FIN]		
6-129-001	All Size	ENG	[-50 to 50 / 0 / 5 msec / step]
6140	[Punch Hole Position Adjustment]		
6-140-001	JPN/EU: 2-Hole	ENG	[-75 to 75 / 0 / 0.5 mm / step]
6-140-002	JPN/NA: 3-Hole	ENG	[-75 to 75 / 0 / 0.5 mm / step]
6-140-003	EU: 4-Hole	ENG	[-75 to 75 / 0 / 0.5 mm / step]
6-140-004	NEU: 4-Hole	ENG	[-75 to 75 / 0 / 0.5 mm / step]
6-140-005	NA: 2-Hole	ENG	[-75 to 75 / 0 / 0.5 mm / step]
6-140-006	JPN: 1-1Hole	ENG	[-75 to 75 / 0 / 0.5 mm / step]

6141	[Jogger Fence Fine Adj.]		
6-141-001	A3 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-141-002	B4 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-141-003	A4 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-141-004	A4 LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-141-005	B5 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-141-006	B5 LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-141-007	DLT SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-141-008	LG SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-141-009	LT SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-141-010	LT LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-141-011	Oficio SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-141-012	Other	ENG	[-15 to 15 / 0 / 0.5 mm / step]

6142	[Staple Position Adjustment]		
6-142-001	A3 SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-142-002	B4 SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-142-003	A4 SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-142-004	A4 LEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-142-005	B5 SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-142-006	B5 LEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-142-007	DLT SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-142-008	LG SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-142-009	LT SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-142-010	LT LEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]
6-142-011	Oficio SEF	ENG	[-35 to 35 / 0 / 0.5 mm / step]

6-142-012	Other	ENG	[-35 to 35 / 0 / 0.5 mm / step]
-----------	-------	-----	---------------------------------

6143	[Adjust Output Jog Position]		
6-143-001	A3 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-143-002	B4 SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-143-004	A4 LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-143-006	B5 LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-143-009	DLT SEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-143-012	LT LEF	ENG	[-15 to 15 / 0 / 0.5 mm / step]
6-143-016	Other	ENG	[-15 to 15 / 0 / 0.5 mm / step]

6146	[Staple Jogging Times Fin 2]		
6-146-001	A3 SEF	ENG	[0 or 1 / 0 / 1 / step]
6-146-002	B4 SEF	ENG	[0 or 1 / 0 / 1 / step]
6-146-003	A4 SEF	ENG	[0 or 1 / 0 / 1 / step]
6-146-004	A4 LEF	ENG	[0 or 1 / 0 / 1 / step]
6-146-005	B5 SEF	ENG	[0 or 1 / 0 / 1 / step]
6-146-006	B5 LEF	ENG	[0 or 1 / 0 / 1 / step]
6-146-007	DLT SEF	ENG	[0 or 1 / 0 / 1 / step]
6-146-008	LG SEF	ENG	[0 or 1 / 0 / 1 / step]
6-146-009	LT SEF	ENG	[0 or 1 / 0 / 1 / step]
6-146-010	LT LEF	ENG	[0 or 1 / 0 / 1 / step]
6-146-011	Oficio SEF	ENG	[0 or 1 / 0 / 1 / step]
6-146-012	Other	ENG	[0 or 1 / 0 / 1 / step]

6147	[Finisher Input Check: Fin 2]		
	page 232 "Finisher"		

6148	[Finisher Output Check: Fin 2]		
	page 243 "Finisher"		

6149	[Finisher Free Run: Fin 2]		
	6-149-001	Free Run 1	ENG [0 or 1 / 0 / 1 / step]
	6-149-002	Free Run 2	ENG [0 or 1 / 0 / 1 / step]
	6-149-003	Free Run 3	ENG [0 or 1 / 0 / 1 / step]

6250	[INPUT Check Slide Sort Tray]		
	page 233 "Slide Sort Tray"		

6251	[OUTPUT Check Slide Sort Tray]		
	page 244 "Slide Sort Tray"		

6252	[Free Run Slide Sort Tray]		
	6-252-001	-	ENG [0 or 1 / 0 / 1 / step]

6301	[Fine Adjust Z-Fold 1]		
	6-301-001	1st Fold: A3 SEF	ENG [-40 to 40 / 0 / 0.2 mm / step]
	6-301-002	1st Fold: B4 SEF	ENG [-40 to 40 / 0 / 0.2 mm / step]
	6-301-003	1st Fold: A4 SEF	ENG [-40 to 40 / 0 / 0.2 mm / step]
	6-301-004	1st Fold: DLT SEF	ENG [-40 to 40 / 0 / 0.2 mm / step]
	6-301-005	1st Fold: LG SEF	ENG [-40 to 40 / 0 / 0.2 mm / step]
	6-301-006	1st Fold: LT SEF	ENG [-40 to 40 / 0 / 0.2 mm / step]
	6-301-007	1st Fold: 12"x18"	ENG [-40 to 40 / 0 / 0.2 mm / step]
	6-301-008	1st Fold: Other	ENG [-40 to 40 / 0 / 0.2 mm / step]
	6-301-009	2nd Fold: A3 SEF	ENG [-40 to 40 / 0 / 0.2 mm / step]
	6-301-010	2nd Fold: B4 SEF	ENG [-40 to 40 / 0 / 0.2 mm / step]

6-301-011	2nd Fold: A4 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-301-012	2nd Fold: DLT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-301-013	2nd Fold: LG SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-301-014	2nd Fold: LT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-301-015	2nd Fold: 12"x18"	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-301-016	2nd Fold: Other	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6309	[INPUT Check Multi Folder]		
	page 234 "Multi Folder"		

6310	[Output Check Multi Folder]		
	page 245 "Multi Folder"		

6311	[Free Run Multi Folder]		
6-311-001	Free Run 1	ENG	[0 or 1 / 0 / 1 / step]
6-311-002	Free Run 2	ENG	[0 or 1 / 0 / 1 / step]
6-311-003	Free Run 3	ENG	[0 or 1 / 0 / 1 / step]
6-311-004	Free Run 4	ENG	[0 or 1 / 0 / 1 / step]

6312	[FM1 Z-Fld: Fine Adj 1st Fld]		
6-312-001	A3 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-312-002	B4 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-312-003	A4 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-312-004	DLT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-312-005	LG SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-312-006	LT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-312-007	12"* 18"	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6-312-008	8-kai	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-312-019	Oficio SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-312-020	Other	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6313	[FM1 Z-Fld: Fine Adj 2nd Fld]		
6-313-001	A3 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-313-002	B4 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-313-003	A4 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-313-004	DLT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-313-005	LG SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-313-006	LT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-313-007	12"* 18"	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-313-008	8-kai	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-313-019	Oficio SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-313-020	Other	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6314	[FM2 Equal 1/2:FineAdjFld]		
6-314-001	A3 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-002	B4 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-003	A4 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-004	DLT SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-005	LG SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-006	LT SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-007	12"* 18" (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-008	8-kai (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-009	B5 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-011	13"* 19" (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6-314-019	Oficio SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-020	Custom (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-021	A3 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-022	B4 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-023	A4 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-024	DLT SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-025	LG SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-026	LT SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-027	12"*18" (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-028	8-kai (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-029	B5 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-031	13"*19" (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-039	Oficio SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-314-040	Custom (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6315	[FM3 Equal 3rds:Fine Adj 1st]		
6-315-001	A3 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-315-002	B4 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-315-003	A4 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-315-004	DLT SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-315-005	LG SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-315-006	LT SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-315-007	12"*18" (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-315-008	8-kai (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-315-009	B5 SEF (Single Sheet)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-315-019	Oficio SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6-315-020	Custom (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-315-022	B4 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-315-023	A4 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-315-025	LG SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-315-026	LT SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-315-029	B5 SEF (Multi Sheet)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-315-039	Oficio SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-315-040	Custom (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6316	[FM3 Equal 3rds:Fine Adj 2nd]		
6-316-001	A3 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-316-002	B4 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-316-003	A4 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-316-004	DLT SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-316-005	LG SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-316-006	LT SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-316-007	12"*18" (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-316-008	8-kai (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-316-009	B5 SEF (Single Sheet)	ENG	[-30 to 30 / 0 / 0.2 mm / step]
6-316-019	Oficio SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-316-020	Custom (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-316-022	B4 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-316-023	A4 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-316-025	LG SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-316-026	LT SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-316-029	B5 SEF (Multi Sheet)	ENG	[-30 to 30 / 0 / 0.2 mm / step]

6-316-039	Oficio SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-316-040	Custom (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6317	[FM4 3rds 1 Flap:Fine Adj 1st]		
6-317-001	A3 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-002	B4 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-003	A4 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-004	DLT SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-005	LG SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-006	LT SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-007	12"* 18" (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-008	8-kai (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-009	B5 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-019	Oficio SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-020	Custom (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-021	A3 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-022	B4 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-023	A4 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-024	DLT SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-025	LG SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-026	LT SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-027	12"* 18" (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-028	8-kai (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-029	B5 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-039	Oficio SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-317-040	Custom (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6318	[FM4 3rds 1 Flap:Fine Adj 2nd]		
6-318-001	A3 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-002	B4 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-003	A4 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-004	DLT SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-005	LG SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-006	LT SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-007	12"* 18" (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-008	8-kai (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-009	B5 SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-019	Oficio SEF (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-020	Custom (Single Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-021	A3 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-022	B4 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-023	A4 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-024	DLT SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-025	LG SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-026	LT SEF (Multi Sheet)	ENG	[0 to 40 / 0 / 0.2 mm / step]
6-318-027	12"* 18" (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-028	8-kai (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-029	B5 SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-039	Oficio SEF (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-318-040	Custom (Multi Sheet)	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6319	[FM5 4ths "V": Fine Adjust 1st]		
6-319-001	A3 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6-319-002	B4 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-319-003	A4 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-319-003	DLT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-319-004	LG SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-319-005	LT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-319-006	12"* 18"	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-319-007	8-kai	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-319-009	B5 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-319-019	Oficio SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-319-020	Other	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6320	[FM5 4ths "V": Fine Adjust 2nd]		
6-320-001	A3 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-320-002	B4 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-320-003	A4 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-320-003	DLT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-320-004	LG SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-320-005	LT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-320-006	12"* 18"	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-320-007	8-kai	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-320-009	B5 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-320-019	Oficio SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-320-020	Other	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6321	[FM6 4ths 2 Flap:Fine Adj 1st]		
6-321-001	A3 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-321-002	B4 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6-321-003	A4 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-321-004	DLT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-321-005	LG SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-321-006	LT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-321-008	8-kai	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-321-009	B5 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-321-019	Oficio SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-321-020	Other	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6322	[FM6 4ths 2 Flap:Fine Adj 2nd]		
6-322-001	A3 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-322-002	B4 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-322-003	A4 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-322-004	DLT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-322-005	LG SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-322-006	LT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-322-008	8-kai	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-322-009	B5 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-322-019	Oficio SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-322-020	Other	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6323	[FM6 4ths 2 Flap:Fine Adj 3rd]		
6-323-001	A3 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-323-002	B4 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-323-003	A4 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-323-004	DLT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-323-005	LG SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6-323-006	LT SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-323-007	12"*18"	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-323-008	8-kai	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-323-009	B5 SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-323-019	Oficio SEF	ENG	[-40 to 40 / 0 / 0.2 mm / step]
6-323-020	Other	ENG	[-40 to 40 / 0 / 0.2 mm / step]

6324	[Jogger Fence Position Adjust]		
6-324-001	A3 SEF	ENG	[-20 to 20 / 0 / 0.5 mm / step]
6-324-002	B4 SEF	ENG	[-20 to 20 / 0 / 0.5 mm / step]
6-324-003	A4 SEF	ENG	[-20 to 20 / 0 / 0.5 mm / step]
6-324-004	DLT SEF	ENG	[-20 to 20 / 0 / 0.5 mm / step]
6-324-005	LG SEF	ENG	[-20 to 20 / 0 / 0.5 mm / step]
6-324-006	LT SEF	ENG	[-20 to 20 / 0 / 0.5 mm / step]
6-324-007	12"*18"	ENG	[-20 to 20 / 0 / 0.5 mm / step]
6-324-008	8-Kai	ENG	[-20 to 20 / 0 / 0.5 mm / step]
6-324-009	B5 SEF	ENG	[-20 to 20 / 0 / 0.5 mm / step]
6-324-019	Oficio SEF	ENG	[-20 to 20 / 0 / 0.5 mm / step]
6-324-020	Other	ENG	[-20 to 20 / 0 / 0.5 mm / step]

6325	[Registration Buckle Adjust]		
6-325-001	A3 SEF	ENG	[-4 to 2 / 0 / 1 mm / step]
6-325-002	B4 SEF	ENG	[-4 to 2 / 0 / 1 mm / step]
6-325-003	A4 SEF	ENG	[-4 to 2 / 0 / 1 mm / step]
6-325-004	DLT SEF	ENG	[-4 to 2 / 0 / 1 mm / step]
6-325-005	LG SEF	ENG	[-4 to 2 / 0 / 1 mm / step]
6-325-006	LT SEF	ENG	[-4 to 2 / 0 / 1 mm / step]

6-325-007	12"*18"	ENG	[-4 to 2 / 0 / 1 mm / step]
6-325-008	8-Kai	ENG	[-4 to 2 / 0 / 1 mm / step]
6-325-009	B5 SEF	ENG	[-4 to 2 / 0 / 1 mm / step]
6-325-019	Oficio SEF	ENG	[-4 to 2 / 0 / 1 mm / step]
6-325-020	Other	ENG	[-4 to 2 / 0 / 1 mm / step]

6326	[Reg Buckle Adjust Select]		
6-326-001	-	ENG	[0 or 1 / 0 / 1 / step]

6327	[Top Tray Full Set: Enable]		
6-327-001	-	ENG	[0 or 1 / 0 / 1 / step]

6328	[TopTray Full Set:Limit Output]		
6-328-001	-	ENG	[0 to 250 / 0 / 1 / step]

6350	[Input Check Print Post]		
	page 235 "Print Post"		

6351	[Output Check Print Post]		
	page 246 "Print Post"		

6352	[Free Run Print Post]		
6-352-001	-	ENG	[0 or 1 / 0 / 1 / step]

6450	[PrioritySizeSetting: 1-TrayCIT]		
6-450-001	A3SEF/12"*18"	ENG	[0 or 1 / 0 / 1 / step]
6-450-002	EU,CHN,Taiwan:8.5"*13"	ENG	[0 or 2 / 0 / 1 / step]
6-450-003	NA:8.5"*14"	ENG	[0 or 1 / 0 / 1 / step]
6-450-004	NA:11"*8.5"	ENG	[0 or 1 / 0 / 1 / step]

6-450-005	NA:8.5"*11"	ENG	[0 or 1 / 0 / 1 / step]
6-450-006	EU,CHN,Taiwan:8K	ENG	[0 or 1 / 0 / 1 / step]
6-450-007	EU,CHN,Taiwan:16K(267*195)	ENG	[0 or 1 / 0 / 1 / step]
6-450-008	EU,CHN,Taiwan:16K(195*267)	ENG	[0 or 1 / 0 / 1 / step]

6451	[INPUT Check: 1-Tray CIT]		
	page 236 "1-Tray CIT"		

6801	[1-pass Stamp Unit]		
6-801-001	-	ENG*	[0 or 1 / 0 / 1 / step]

6900	[ADF Bottom Plate Setting]		
6-900-001	-	ENG*	[0 or 1 / 0 / 1 / step]

6901	[ADF Operation Setting]		
6-901-001	-	ENG	[0 or 1 / 0 / 1 / step]

Engine SP Tables-7

SP7-XXX (Data Log)

7001	[Main Motor Operation Time]		
7-001-001	-	ENG*	[0 to 9999999 / 0 / 0 / step]

7621	[Display PM Count]		
7-621-001	Developer	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-002	Hot Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-003	Pressure Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-004	Hot Roller Bearings	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-005	Pressure Roller Bearings	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-006	Hot Roller Strippers	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-007	Cleaning Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-008	Cleaning Roller Bearings	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-009	Web Roll	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-010	Web Cleaning Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-011	Development Filter	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-012	Toner Recycling Unit	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-013	Pressure Release Filter	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-014	Charge Corona Wire	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-015	Grid Plate	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-016	Cleaning Pad	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-017	Cleaning Blade	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-018	Cleaning Brush	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-019	Transfer Belt	ENG	[0 to 99999999 / 0 / 1 / step]

7-621-020	Transfer Belt Cleaning Blade	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-022	ADF Pick-up Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-023	ADF Feed Belt	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-024	ADF Separation Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-025	Feed Roller-Tray1	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-026	Pick-up Roller-Tray1	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-027	Separation Roller-Tray1	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-028	Feed Roller-Tray2	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-029	Pick-up Roller-Tray2	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-030	Separation Roller-Tray2	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-031	Feed Roller-Tray3	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-032	Pick-up Roller-Tray3	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-033	Separation Roller-Tray3	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-034	Feed Roller-Tray4	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-035	Pick-up Roller-Tray4	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-036	Separation Roller-Tray4	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-037	Feed Roller-LCT	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-038	Pick-up Roller-LCT	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-039	Separation Roller-LCT	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-040	Feed Belt Cover feeder	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-041	Pick-up Roller Cover feeder	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-042	Separation Roller Cover feeder	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-044	Fusing unit:Thermistor(Back)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-045	Fusing unit:Thermistor(Center)	ENG	[0 to 99999999 / 0 / 1 / step]

7-621-046	Dust Filter(Main)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-047	Main Tray(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-048	Main Tray(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-049	Main Tray(Custom 3)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-050	Main Tray(Custom 4)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-051	Paper Tray1(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-052	Paper Tray1(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-053	Paper Tray2(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-054	Paper Tray2(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-055	Paper Tray3(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-056	Paper Tray3(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-057	Paper Tray4(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-058	Paper Tray4(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-059	LCT(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-060	LCT(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-063	Interposer(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-064	Interposer(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-621-066	Ozon Filter(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]

7622	[Clear PM Count]		
7-622-001	Developer	ENG	[0 to 0 / 0 / 0 / step]
7-622-002	Hot Roller	ENG	[0 to 0 / 0 / 0 / step]
7-622-003	Pressure Roller	ENG	[0 to 0 / 0 / 0 / step]
7-622-004	Hot Roller Bearings	ENG	[0 to 0 / 0 / 0 / step]
7-622-005	Pressure Roller Bearings	ENG	[0 to 0 / 0 / 0 / step]
7-622-006	Hot Roller Strippers	ENG	[0 to 0 / 0 / 0 / step]

7-622-007	Cleaning Roller	ENG	[0 to 0 / 0 / 0 / step]
7-622-008	Cleaning Roller Bearings	ENG	[0 to 0 / 0 / 0 / step]
7-622-009	Web Roll	ENG	[0 to 0 / 0 / 0 / step]
7-622-010	Web Cleaning Roller	ENG	[0 to 0 / 0 / 0 / step]
7-622-011	Development Filter	ENG	[0 to 0 / 0 / 0 / step]
7-622-012	Toner Recycling Unit	ENG	[0 to 0 / 0 / 0 / step]
7-622-013	Pressure Release Filter	ENG	[0 to 0 / 0 / 0 / step]
7-622-014	Charge Corona Wire	ENG	[0 to 0 / 0 / 0 / step]
7-622-015	Grid Plate	ENG	[0 to 0 / 0 / 0 / step]
7-622-016	Cleaning Pad	ENG	[0 to 0 / 0 / 0 / step]
7-622-017	Cleaning Blade	ENG	[0 to 0 / 0 / 0 / step]
7-622-018	Cleaning Brush	ENG	[0 to 0 / 0 / 0 / step]
7-622-019	Transfer Belt	ENG	[0 to 0 / 0 / 0 / step]
7-622-020	Transfer Belt Cleaning Blade	ENG	[0 to 0 / 0 / 0 / step]
7-622-022	ADF Pick-up Roller	ENG	[0 to 0 / 0 / 0 / step]
7-622-023	ADF Feed Belt	ENG	[0 to 0 / 0 / 0 / step]
7-622-024	ADF Separation Roller	ENG	[0 to 0 / 0 / 0 / step]
7-622-025	Feed Roller-Tray1	ENG	[0 to 0 / 0 / 0 / step]
7-622-026	Pick-up Roller-Tray1	ENG	[0 to 0 / 0 / 0 / step]
7-622-027	Separation Roller-Tray1	ENG	[0 to 0 / 0 / 0 / step]
7-622-028	Feed Roller-Tray2	ENG	[0 to 0 / 0 / 0 / step]
7-622-029	Pick-up Roller-Tray2	ENG	[0 to 0 / 0 / 0 / step]
7-622-030	Separation Roller-Tray2	ENG	[0 to 0 / 0 / 0 / step]
7-622-031	Feed Roller-Tray3	ENG	[0 to 0 / 0 / 0 / step]
7-622-032	Pick-up Roller-Tray3	ENG	[0 to 0 / 0 / 0 / step]
7-622-033	Separation Roller-Tray3	ENG	[0 to 0 / 0 / 0 / step]

7-622-034	Feed Roller-Tray4	ENG	[0 to 0 / 0 / 0 / step]
7-622-035	Pick-up Roller-Tray4	ENG	[0 to 0 / 0 / 0 / step]
7-622-036	Separation Roller-Tray4	ENG	[0 to 0 / 0 / 0 / step]
7-622-037	Feed Roller-LCT	ENG	[0 to 0 / 0 / 0 / step]
7-622-038	Pick-up Roller-LCT	ENG	[0 to 0 / 0 / 0 / step]
7-622-039	Separation Roller-LCT	ENG	[0 to 0 / 0 / 0 / step]
7-622-040	Feed Belt Cover feeder	ENG	[0 to 0 / 0 / 0 / step]
7-622-041	Pick-up Roller Cover feeder	ENG	[0 to 0 / 0 / 0 / step]
7-622-042	Separation Roller Cover feeder	ENG	[0 to 0 / 0 / 0 / step]
7-622-044	Fusing unit:Thermistor(Back)	ENG	[0 to 0 / 0 / 0 / step]
7-622-045	Fusing unit:Thermistor(Center)	ENG	[0 to 0 / 0 / 0 / step]
7-622-046	Dust Filter(Main)	ENG	[0 to 0 / 0 / 0 / step]
7-622-047	Main Tray(Custom 1)	ENG	[0 to 0 / 0 / 0 / step]
7-622-048	Main Tray(Custom 2)	ENG	[0 to 0 / 0 / 0 / step]
7-622-049	Main Tray(Custom 3)	ENG	[0 to 0 / 0 / 0 / step]
7-622-050	Main Tray(Custom 4)	ENG	[0 to 0 / 0 / 0 / step]
7-622-051	Paper Tray1(Custom 1)	ENG	[0 to 0 / 0 / 0 / step]
7-622-052	Paper Tray1(Custom 2)	ENG	[0 to 0 / 0 / 0 / step]
7-622-053	Paper Tray2(Custom 1)	ENG	[0 to 0 / 0 / 0 / step]
7-622-054	Paper Tray2(Custom 2)	ENG	[0 to 0 / 0 / 0 / step]
7-622-055	Paper Tray3(Custom 1)	ENG	[0 to 0 / 0 / 0 / step]
7-622-056	Paper Tray3(Custom 2)	ENG	[0 to 0 / 0 / 0 / step]
7-622-057	Paper Tray4(Custom 1)	ENG	[0 to 0 / 0 / 0 / step]
7-622-058	Paper Tray4(Custom 2)	ENG	[0 to 0 / 0 / 0 / step]

7-622-059	LCT(Custom 1)	ENG	[0 to 0 / 0 / 0 / step]
7-622-060	LCT(Custom 2)	ENG	[0 to 0 / 0 / 0 / step]
7-622-063	Interposer(Custom 1)	ENG	[0 to 0 / 0 / 0 / step]
7-622-064	Interposer(Custom 2)	ENG	[0 to 0 / 0 / 0 / step]
7-622-066	Ozon Filter(Custom 1)	ENG	[0 to 0 / 0 / 0 / step]

7623	[Unit PM Target]		
7-623-001	Developer	ENG	[0 to 99999999 / 350000 / 1 / step]
7-623-002	Hot Roller	ENG	[0 to 99999999 / 450000 / 1 / step]
7-623-003	Pressure Roller	ENG	[0 to 99999999 / 450000 / 1 / step]
7-623-004	Hot Roller Bearings	ENG	[0 to 99999999 / 450000 / 1 / step]
7-623-005	Pressure Roller Bearings	ENG	[0 to 99999999 / 450000 / 1 / step]
7-623-006	Hot Roller Strippers	ENG	[0 to 99999999 / 450000 / 1 / step]
7-623-007	Cleaning Roller	ENG	[0 to 99999999 / 450000 / 1 / step]
7-623-008	Cleaning Roller Bearings	ENG	[0 to 99999999 / 450000 / 1 / step]
7-623-009	Web Roll	ENG	[0 to 99999999 / 450000 / 1 / step]
7-623-010	Web Cleaning Roller	ENG	[0 to 99999999 / 450000 / 1 / step]
7-623-011	Development Filter	ENG	[0 to 99999999 / 300000 / 1 / step]
7-623-012	Toner Recycling Unit	ENG	[0 to 99999999 / 600000 / 1 / step]
7-623-013	Pressure Release Filter	ENG	[0 to 99999999 / 300000 / 1 / step]
7-623-014	Charge Corona Wire	ENG	[0 to 99999999 / 300000 / 1 / step]
7-623-015	Grid Plate	ENG	[0 to 99999999 / 300000 / 1 / step]
7-623-016	Cleaning Pad	ENG	[0 to 99999999 / 300000 / 1 / step]
7-623-017	Cleaning Blade	ENG	[0 to 99999999 / 300000 / 1 / step]
7-623-018	Cleaning Brush	ENG	[0 to 99999999 / 300000 / 1 / step]
7-623-019	Transfer Belt	ENG	[0 to 99999999 / 600000 / 1 / step]

7-623-020	Transfer Belt Cleaning Blade	ENG	[0 to 99999999 / 600000 / 1 / step]
7-623-022	ADF Pick-up Roller	ENG	[0 to 99999999 / 120000 / 1 / step]
7-623-023	ADF Feed Belt	ENG	[0 to 99999999 / 120000 / 1 / step]
7-623-024	ADF Separation Roller	ENG	[0 to 99999999 / 120000 / 1 / step]
7-623-025	Feed Roller-Tray1	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-026	Pick-up Roller-Tray1	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-027	Separation Roller-Tray1	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-028	Feed Roller-Tray2	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-029	Pick-up Roller-Tray2	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-030	Separation Roller-Tray2	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-031	Feed Roller-Tray3	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-032	Pick-up Roller-Tray3	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-033	Separation Roller-Tray3	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-034	Feed Roller-Tray4	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-035	Pick-up Roller-Tray4	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-036	Separation Roller-Tray4	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-037	Feed Roller-LCT	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-038	Pick-up Roller-LCT	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-039	Separation Roller-LCT	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-040	Feed Belt Cover feeder	ENG	[0 to 99999999 / 60000 / 1 / step]
7-623-041	Pick-up Roller Cover feeder	ENG	[0 to 99999999 / 60000 / 1 / step]
7-623-042	Separation Roller Cover feeder	ENG	[0 to 99999999 / 60000 / 1 / step]
7-623-044	Fusing unit:Thermistor(Back)	ENG	[0 to 99999999 / 450000 / 1 / step]
7-623-045	Fusing unit:Thermistor(Center)	ENG	[0 to 99999999 / 450000 / 1 / step]

7-623-046	Dust Filter(Main)	ENG	[0 to 99999999 / 300000 / 1 / step]
7-623-047	Main Tray(Custom 1)	ENG	[0 to 99999999 / 300000 / 1 / step]
7-623-048	Main Tray(Custom 2)	ENG	[0 to 99999999 / 300000 / 1 / step]
7-623-049	Main Tray(Custom 3)	ENG	[0 to 99999999 / 300000 / 1 / step]
7-623-050	Main Tray(Custom 4)	ENG	[0 to 99999999 / 300000 / 1 / step]
7-623-051	Paper Tray1(Custom 1)	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-052	Paper Tray1(Custom 2)	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-053	Paper Tray2(Custom 1)	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-054	Paper Tray2(Custom 2)	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-055	Paper Tray3(Custom 1)	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-056	Paper Tray3(Custom 2)	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-057	Paper Tray4(Custom 1)	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-058	Paper Tray4(Custom 2)	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-059	LCT(Custom 1)	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-060	LCT(Custom 2)	ENG	[0 to 99999999 / 1000000 / 1 / step]
7-623-063	Interposer(Custom 1)	ENG	[0 to 99999999 / 60000 / 1 / step]
7-623-064	Interposer(Custom 2)	ENG	[0 to 99999999 / 60000 / 1 / step]
7-623-066	Ozon Filter(Custom 1)	ENG	[0 to 99999999 / 300000 / 1 / step]

7625	[Pg Count History:Latest 1]		
7-625-001	Developer	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-002	Hot Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-003	Pressure Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-004	Hot Roller Bearings	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-005	Pressure Roller Bearings	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-006	Hot Roller Strippers	ENG	[0 to 99999999 / 0 / 1 / step]

7-625-007	Cleaning Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-008	Cleaning Roller Bearings	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-009	Web Roll	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-010	Web Cleaning Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-011	Development Filter	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-012	Toner Recycling Unit	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-013	Pressure Release Filter	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-014	Charge Corona Wire	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-015	Grid Plate	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-016	Cleaning Pad	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-017	Cleaning Blade	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-018	Cleaning Brush	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-019	Transfer Belt	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-020	Transfer Belt Cleaning Blade	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-022	ADF Pick-up Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-023	ADF Feed Belt	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-024	ADF Separation Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-025	Feed Roller-Tray1	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-026	Pick-up Roller-Tray1	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-027	Separation Roller-Tray1	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-028	Feed Roller-Tray2	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-029	Pick-up Roller-Tray2	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-030	Separation Roller-Tray2	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-031	Feed Roller-Tray3	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-032	Pick-up Roller-Tray3	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-033	Separation Roller-Tray3	ENG	[0 to 99999999 / 0 / 1 / step]

7-625-034	Feed Roller-Tray4	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-035	Pick-up Roller-Tray4	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-036	Separation Roller-Tray4	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-037	Feed Roller-LCT	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-038	Pick-up Roller-LCT	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-039	Separation Roller-LCT	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-040	Feed Belt Cover feeder	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-041	Pick-up Roller Cover feeder	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-042	Separation Roller Cover feeder	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-044	Fusing unit:Thermistor(Back)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-045	Fusing unit:Thermistor(Center)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-046	Dust Filter(Main)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-047	Main Tray(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-048	Main Tray(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-049	Main Tray(Custom 3)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-050	Main Tray(Custom 4)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-051	Paper Tray1(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-052	Paper Tray1(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-053	Paper Tray2(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-054	Paper Tray2(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-055	Paper Tray3(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-056	Paper Tray3(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-057	Paper Tray4(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-058	Paper Tray4(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]

7-625-059	LCT(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-060	LCT(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-063	Interposer(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-064	Interposer(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-625-066	Ozon Filter(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]

7626	[Pg Count History:Latest 2]		
7-626-001	Developer	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-002	Hot Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-003	Pressure Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-004	Hot Roller Bearings	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-005	Pressure Roller Bearings	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-006	Hot Roller Strippers	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-007	Cleaning Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-008	Cleaning Roller Bearings	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-009	Web Roll	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-010	Web Cleaning Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-011	Development Filter	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-012	Toner Recycling Unit	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-013	Pressure Release Filter	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-014	Charge Corona Wire	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-015	Grid Plate	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-016	Cleaning Pad	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-017	Cleaning Blade	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-018	Cleaning Brush	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-019	Transfer Belt	ENG	[0 to 99999999 / 0 / 1 / step]

7-626-020	Transfer Belt Cleaning Blade	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-022	ADF Pick-up Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-023	ADF Feed Belt	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-024	ADF Separation Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-025	Feed Roller-Tray1	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-026	Pick-up Roller-Tray1	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-027	Separation Roller-Tray1	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-028	Feed Roller-Tray2	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-029	Pick-up Roller-Tray2	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-030	Separation Roller-Tray2	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-031	Feed Roller-Tray3	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-032	Pick-up Roller-Tray3	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-033	Separation Roller-Tray3	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-034	Feed Roller-Tray4	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-035	Pick-up Roller-Tray4	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-036	Separation Roller-Tray4	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-037	Feed Roller-LCT	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-038	Pick-up Roller-LCT	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-039	Separation Roller-LCT	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-040	Feed Belt Cover feeder	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-041	Pick-up Roller Cover feeder	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-042	Separation Roller Cover feeder	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-044	Fusing unit:Thermistor(Back)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-045	Fusing unit:Thermistor(Center)	ENG	[0 to 99999999 / 0 / 1 / step]

7-626-046	Dust Filter(Main)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-047	Main Tray(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-048	Main Tray(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-049	Main Tray(Custom 3)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-050	Main Tray(Custom 4)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-051	Paper Tray1(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-052	Paper Tray1(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-053	Paper Tray2(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-054	Paper Tray2(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-055	Paper Tray3(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-056	Paper Tray3(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-057	Paper Tray4(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-058	Paper Tray4(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-059	LCT(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-060	LCT(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-063	Interposer(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-064	Interposer(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-626-066	Ozon Filter(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]

7627	[Pg Count History:Latest 3]		
7-627-001	Developer	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-002	Hot Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-003	Pressure Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-004	Hot Roller Bearings	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-005	Pressure Roller Bearings	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-006	Hot Roller Strippers	ENG	[0 to 99999999 / 0 / 1 / step]

7-627-007	Cleaning Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-008	Cleaning Roller Bearings	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-009	Web Roll	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-010	Web Cleaning Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-011	Development Filter	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-012	Toner Recycling Unit	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-013	Pressure Release Filter	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-014	Charge Corona Wire	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-015	Grid Plate	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-016	Cleaning Pad	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-017	Cleaning Blade	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-018	Cleaning Brush	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-019	Transfer Belt	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-020	Transfer Belt Cleaning Blade	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-022	ADF Pick-up Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-023	ADF Feed Belt	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-024	ADF Separation Roller	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-025	Feed Roller-Tray1	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-026	Pick-up Roller-Tray1	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-027	Separation Roller-Tray1	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-028	Feed Roller-Tray2	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-029	Pick-up Roller-Tray2	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-030	Separation Roller-Tray2	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-031	Feed Roller-Tray3	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-032	Pick-up Roller-Tray3	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-033	Separation Roller-Tray3	ENG	[0 to 99999999 / 0 / 1 / step]

7-627-034	Feed Roller-Tray4	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-035	Pick-up Roller-Tray4	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-036	Separation Roller-Tray4	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-037	Feed Roller-LCT	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-038	Pick-up Roller-LCT	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-039	Separation Roller-LCT	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-040	Feed Belt Cover feeder	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-041	Pick-up Roller Cover feeder	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-042	Separation Roller Cover feeder	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-044	Fusing unit:Thermistor(Back)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-045	Fusing unit:Thermistor(Center)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-046	Dust Filter(Main)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-047	Main Tray(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-048	Main Tray(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-049	Main Tray(Custom 3)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-050	Main Tray(Custom 4)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-051	Paper Tray1(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-052	Paper Tray1(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-053	Paper Tray2(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-054	Paper Tray2(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-055	Paper Tray3(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-056	Paper Tray3(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-057	Paper Tray4(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-058	Paper Tray4(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]

7-627-059	LCT(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-060	LCT(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-063	Interposer(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-064	Interposer(Custom 2)	ENG	[0 to 99999999 / 0 / 1 / step]
7-627-066	Ozon Filter(Custom 1)	ENG	[0 to 99999999 / 0 / 1 / step]

7628	[Clear PM Counter]		
7-628-001	Clear Exceeded Counts	ENG	[0 to 0 / 0 / 0 / step]
7-628-002	Reset All Counts	ENG	[0 to 0 / 0 / 0 / step]

7801	[ROM No.]		
7-801-002	Engine	ENG	[0 to 0 / 0 / 0 / step]
7-801-005	ADF	ENG	[0 to 0 / 0 / 0 / step]
7-801-007	Finisher	ENG	[0 to 0 / 0 / 0 / step]
7-801-009	Bank	ENG	[0 to 0 / 0 / 0 / step]
7-801-010	LCT	ENG	[0 to 0 / 0 / 0 / step]
7-801-011	Mail Box	ENG	[0 to 0 / 0 / 0 / step]
7-801-020	Cover Interposer	ENG	[0 to 0 / 0 / 0 / step]
7-801-024	Capacitor	ENG	[0 to 0 / 0 / 0 / step]
7-801-025	Holding Unit	ENG	[0 to 0 / 0 / 0 / step]

7801	[Firmware Version]		
7-801-102	Engine	ENG	[0 to 0 / 0 / 0 / step]
7-801-105	ADF	ENG	[0 to 0 / 0 / 0 / step]
7-801-107	Finisher	ENG	[0 to 0 / 0 / 0 / step]
7-801-109	Bank	ENG	[0 to 0 / 0 / 0 / step]
7-801-110	LCT	ENG	[0 to 0 / 0 / 0 / step]

7-801-111	Mail Box	ENG	[0 to 0 / 0 / 0 / step]
7-801-120	Cover Interposer	ENG	[0 to 0 / 0 / 0 / step]
7-801-124	Capacitor	ENG	[0 to 0 / 0 / 0 / step]
7-801-125	Holding Unit	ENG	[0 to 0 / 0 / 0 / step]

7834	[Clear Pixel Coverage Data]		
7-834-001	Last & Average	ENG	[0 to 0 / 0 / 0 / step]
7-834-002	Toner Bottles In Use	ENG	[0 to 0 / 0 / 0 / step]
7-834-003	Page Counts (2 Prev. Toner Bottles)	ENG	[0 to 0 / 0 / 0 / step]
7-834-004	Pixel Coverage Clear	ENG	[0 to 0 / 0 / 0 / step]
7-834-255	All Clear	ENG	[0 to 0 / 0 / 0 / step]

7852	[DF Glass Dust Check]		
7-852-001	Dust Detection Counter	ENG*	[0 to 65535 / 0 / 1 / step]
7-852-002	Dust Counter Clear Counter	ENG*	[0 to 65535 / 0 / 1 / step]
7-852-003	Dust Detection Counter: Back	ENG*	[0 to 65535 / 0 / 1 / step]

7940	[Drive Distance:End Std Value]		
7-940-001	Developer	ENG	MP 6503 SP: [0 to 99999999 / 170200 / 1 m / step] MP 7503 SP: [0 to 99999999 / 160900 / 1 m / step] MP 9003 SP: [0 to 99999999 / 137400 / 1 m / step]

7-940-002	Hot Roller	ENG	MP 6503 SP: [0 to 99999999 / 193100 / 1 m / step] MP 7503 SP: [0 to 99999999 / 171000 / 1 m / step] MP 9003 SP: [0 to 99999999 / 146800 / 1 m / step]
7-940-003	Pressure Roller	ENG	MP 6503 SP: [0 to 99999999 / 193100 / 1 m / step] MP 7503 SP: [0 to 99999999 / 171000 / 1 m / step] MP 9003 SP: [0 to 99999999 / 146800 / 1 m / step]
7-940-004	Hot Roller Bearings	ENG	MP 6503 SP: [0 to 99999999 / 193100 / 1 m / step] MP 7503 SP: [0 to 99999999 / 171000 / 1 m / step] MP 9003 SP: [0 to 99999999 / 146800 / 1 m / step]
7-940-005	Pressure Roller Bearings	ENG	MP 6503 SP: [0 to 99999999 / 193100 / 1 m / step] MP 7503 SP: [0 to 99999999 / 171000 / 1 m / step] MP 9003 SP: [0 to 99999999 / 146800 / 1 m / step]
7-940-006	Hot Roller Strippers	ENG	MP 6503 SP: [0 to 99999999 / 193100 / 1 m / step] MP 7503 SP: [0 to 99999999 / 171000 / 1 m / step] MP 9003 SP: [0 to 99999999 / 146800 / 1 m / step]

7-940-007	Cleaning Roller	ENG	MP 6503 SP: [0 to 99999999 / 193100 / 1 m / step] MP 7503 SP: [0 to 99999999 / 171000 / 1 m / step] MP 9003 SP: [0 to 99999999 / 146800 / 1 m / step]
7-940-008	Cleaning Roller Bearings	ENG	MP 6503 SP: [0 to 99999999 / 193100 / 1 m / step] MP 7503 SP: [0 to 99999999 / 171000 / 1 m / step] MP 9003 SP: [0 to 99999999 / 146800 / 1 m / step]
7-940-009	Web Roll	ENG	MP 6503 SP: [0 to 99999999 / 193100 / 1 m / step] MP 7503 SP: [0 to 99999999 / 171000 / 1 m / step] MP 9003 SP: [0 to 99999999 / 146800 / 1 m / step]
7-940-010	Web Cleaning Roller	ENG	MP 6503 SP: [0 to 99999999 / 193100 / 1 m / step] MP 7503 SP: [0 to 99999999 / 171000 / 1 m / step] MP 9003 SP: [0 to 99999999 / 146800 / 1 m / step]
7-940-011	Development Filter	ENG	MP 6503 SP: [0 to 99999999 / 145900 / 1 m / step] MP 7503 SP: [0 to 99999999 / 137900 / 1 m / step] MP 9003 SP: [0 to 99999999 / 117800 / 1 m / step]

7-940-012	Toner Recycling Unit	ENG	MP 6503 SP: [0 to 99999999 / 291900 / 1 m / step] MP 7503 SP: [0 to 99999999 / 275800 / 1 m / step] MP 9003 SP: [0 to 99999999 / 235600 / 1 m / step]
7-940-013	Pressure Release Filter	ENG	MP 6503 SP: [0 to 99999999 / 167400 / 1 m / step] MP 7503 SP: [0 to 99999999 / 160500 / 1 m / step] MP 9003 SP: [0 to 99999999 / 129400 / 1 m / step]
7-940-014	Charge Corona Wire	ENG	MP 6503 SP: [0 to 99999999 / 167400 / 1 m / step] MP 7503 SP: [0 to 99999999 / 160500 / 1 m / step] MP 9003 SP: [0 to 99999999 / 129400 / 1 m / step]
7-940-015	Grid Plate	ENG	MP 6503 SP: [0 to 99999999 / 167400 / 1 m / step] MP 7503 SP: [0 to 99999999 / 160500 / 1 m / step] MP 9003 SP: [0 to 99999999 / 129400 / 1 m / step]
7-940-016	Cleaning Pad	ENG	MP 6503 SP: [0 to 99999999 / 167400 / 1 m / step] MP 7503 SP: [0 to 99999999 / 160500 / 1 m / step] MP 9003 SP: [0 to 99999999 / 129400 / 1 m / step]

7-940-017	Cleaning Blade	ENG	MP 6503 SP: [0 to 99999999 / 167400 / 1 m / step] MP 7503 SP: [0 to 99999999 / 160500 / 1 m / step] MP 9003 SP: [0 to 99999999 / 129400 / 1 m / step]
7-940-018	Cleaning Brush	ENG	MP 6503 SP: [0 to 99999999 / 167400 / 1 m / step] MP 7503 SP: [0 to 99999999 / 160500 / 1 m / step] MP 9003 SP: [0 to 99999999 / 129400 / 1 m / step]
7-940-019	Transfer Belt	ENG	MP 6503 SP: [0 to 99999999 / 334900 / 1 m / step] MP 7503 SP: [0 to 99999999 / 321000 / 1 m / step] MP 9003 SP: [0 to 99999999 / 258800 / 1 m / step]
7-940-020	Transfer Belt Cleaning Blade	ENG	MP 6503 SP: [0 to 99999999 / 334900 / 1 m / step] MP 7503 SP: [0 to 99999999 / 321000 / 1 m / step] MP 9003 SP: [0 to 99999999 / 258800 / 1 m / step]
7-940-044	Fusing unit:Thermistor(Back)	ENG	MP 6503 SP: [0 to 99999999 / 199300 / 1 m / step] MP 7503 SP: [0 to 99999999 / 171000 / 1 m / step] MP 9003 SP: [0 to 99999999 / 146800 / 1 m / step]

7-940-045	Fusing unit:Thermistor(Center)	ENG	MP 6503 SP: [0 to 99999999 / 199300 / 1 m / step] MP 7503 SP: [0 to 99999999 / 171000 / 1 m / step] MP 9003 SP: [0 to 99999999 / 146800 / 1 m / step]
-----------	--------------------------------	-----	---

7942	[Drive Distance % Counter]		
7-942-001	Developer	ENG	[0 to 255 / 0 / 1 % / step]
7-942-002	Hot Roller	ENG	[0 to 255 / 0 / 1 % / step]
7-942-003	Pressure Roller	ENG	[0 to 255 / 0 / 1 % / step]
7-942-004	Hot Roller Bearings	ENG	[0 to 255 / 0 / 1 % / step]
7-942-005	Pressure Roller Bearings	ENG	[0 to 255 / 0 / 1 % / step]
7-942-006	Hot Roller Strippers	ENG	[0 to 255 / 0 / 1 % / step]
7-942-007	Cleaning Roller	ENG	[0 to 255 / 0 / 1 % / step]
7-942-008	Cleaning Roller Bearings	ENG	[0 to 255 / 0 / 1 % / step]
7-942-009	Web Roll	ENG	[0 to 255 / 0 / 1 % / step]
7-942-010	Web Cleaning Roller	ENG	[0 to 255 / 0 / 1 % / step]
7-942-011	Development Filter	ENG	[0 to 255 / 0 / 1 % / step]
7-942-012	Toner Recycling Unit	ENG	[0 to 255 / 0 / 1 % / step]
7-942-013	Pressure Release Filter	ENG	[0 to 255 / 0 / 1 % / step]
7-942-014	Charge Corona Wire	ENG	[0 to 255 / 0 / 1 % / step]
7-942-015	Grid Plate	ENG	[0 to 255 / 0 / 1 % / step]
7-942-016	Cleaning Pad	ENG	[0 to 255 / 0 / 1 % / step]
7-942-017	Cleaning Blade	ENG	[0 to 255 / 0 / 1 % / step]
7-942-018	Cleaning Brush	ENG	[0 to 255 / 0 / 1 % / step]
7-942-019	Transfer Belt	ENG	[0 to 255 / 0 / 1 % / step]

7-942-020	Transfer Belt Cleaning Blade	ENG	[0 to 255 / 0 / 1 % / step]
7-942-044	Fusing unit:Thermistor(Back)	ENG	[0 to 255 / 0 / 1 % / step]
7-942-045	Fusing unit:Thermistor(Center)	ENG	[0 to 255 / 0 / 1 % / step]

7944	[Drive Distance Counter]		
7-944-001	Developer	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-002	Hot Roller	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-003	Pressure Roller	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-004	Hot Roller Bearings	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-005	Pressure Roller Bearings	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-006	Hot Roller Strippers	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-007	Cleaning Roller	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-008	Cleaning Roller Bearings	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-009	Web Roll	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-010	Web Cleaning Roller	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-011	Development Filter	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-012	Toner Recycling Unit	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-013	Pressure Release Filter	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-014	Charge Corona Wire	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-015	Grid Plate	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-016	Cleaning Pad	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-017	Cleaning Blade	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-018	Cleaning Brush	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-019	Transfer Belt	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-020	Transfer Belt Cleaning Blade	ENG	[0 to 99999999 / 0 / 1 m / step]

7-944-044	Fusing unit:Thermistor(Back)	ENG	[0 to 99999999 / 0 / 1 m / step]
7-944-045	Fusing unit:Thermistor(Center)	ENG	[0 to 99999999 / 0 / 1 m / step]

7954	[Pg Counter (%)]		
7-954-001	Developer	ENG	[0 to 255 / 0 / 1 % / step]
7-954-002	Hot Roller	ENG	[0 to 255 / 0 / 1 % / step]
7-954-003	Pressure Roller	ENG	[0 to 255 / 0 / 1 % / step]
7-954-004	Hot Roller Bearings	ENG	[0 to 255 / 0 / 1 % / step]
7-954-005	Pressure Roller Bearings	ENG	[0 to 255 / 0 / 1 % / step]
7-954-006	Hot Roller Strippers	ENG	[0 to 255 / 0 / 1 % / step]
7-954-007	Cleaning Roller	ENG	[0 to 255 / 0 / 1 % / step]
7-954-008	Cleaning Roller Bearings	ENG	[0 to 255 / 0 / 1 % / step]
7-954-009	Web Roll	ENG	[0 to 255 / 0 / 1 % / step]
7-954-010	Web Cleaning Roller	ENG	[0 to 255 / 0 / 1 % / step]
7-954-011	Development Filter	ENG	[0 to 255 / 0 / 1 % / step]
7-954-012	Toner Recycling Unit	ENG	[0 to 255 / 0 / 1 % / step]
7-954-013	Pressure Release Filter	ENG	[0 to 255 / 0 / 1 % / step]
7-954-014	Charge Corona Wire	ENG	[0 to 255 / 0 / 1 % / step]
7-954-015	Grid Plate	ENG	[0 to 255 / 0 / 1 % / step]
7-954-016	Cleaning Pad	ENG	[0 to 255 / 0 / 1 % / step]
7-954-017	Cleaning Blade	ENG	[0 to 255 / 0 / 1 % / step]
7-954-018	Cleaning Brush	ENG	[0 to 255 / 0 / 1 % / step]
7-954-019	Transfer Belt	ENG	[0 to 255 / 0 / 1 % / step]
7-954-020	Transfer Belt Cleaning Blade	ENG	[0 to 255 / 0 / 1 % / step]
7-954-022	ADF Pick-up Roller	ENG	[0 to 255 / 0 / 1 % / step]

7-954-023	ADF Feed Belt	ENG	[0 to 255 / 0 / 1 % / step]
7-954-024	ADF Separation Roller	ENG	[0 to 255 / 0 / 1 % / step]
7-954-025	Feed Roller-Tray1	ENG	[0 to 255 / 0 / 1 % / step]
7-954-026	Pick-up Roller-Tray1	ENG	[0 to 255 / 0 / 1 % / step]
7-954-027	Separation Roller-Tray1	ENG	[0 to 255 / 0 / 1 % / step]
7-954-028	Feed Roller-Tray2	ENG	[0 to 255 / 0 / 1 % / step]
7-954-029	Pick-up Roller-Tray2	ENG	[0 to 255 / 0 / 1 % / step]
7-954-030	Separation Roller-Tray2	ENG	[0 to 255 / 0 / 1 % / step]
7-954-031	Feed Roller-Tray3	ENG	[0 to 255 / 0 / 1 % / step]
7-954-032	Pick-up Roller-Tray3	ENG	[0 to 255 / 0 / 1 % / step]
7-954-033	Separation Roller-Tray3	ENG	[0 to 255 / 0 / 1 % / step]
7-954-034	Feed Roller-Tray4	ENG	[0 to 255 / 0 / 1 % / step]
7-954-035	Pick-up Roller-Tray4	ENG	[0 to 255 / 0 / 1 % / step]
7-954-036	Separation Roller-Tray4	ENG	[0 to 255 / 0 / 1 % / step]
7-954-037	Feed Roller-LCT	ENG	[0 to 255 / 0 / 1 % / step]
7-954-038	Pick-up Roller-LCT	ENG	[0 to 255 / 0 / 1 % / step]
7-954-039	Separation Roller-LCT	ENG	[0 to 255 / 0 / 1 % / step]
7-954-040	Feed Belt Cover feeder	ENG	[0 to 255 / 0 / 1 % / step]
7-954-041	Pick-up Roller Cover feeder	ENG	[0 to 255 / 0 / 1 % / step]
7-954-042	Separation Roller Cover feeder	ENG	[0 to 255 / 0 / 1 % / step]
7-954-044	Fusing unit:Thermistor(Back)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-045	Fusing unit:Thermistor(Center)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-046	Dust Filter(Main)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-047	Main Tray(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-048	Main Tray(Custom 2)	ENG	[0 to 255 / 0 / 1 % / step]

7-954-049	Main Tray(Custom 3)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-050	Main Tray(Custom 4)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-051	Paper Tray1(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-052	Paper Tray1(Custom 2)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-053	Paper Tray2(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-054	Paper Tray2(Custom 2)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-055	Paper Tray3(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-056	Paper Tray3(Custom 2)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-057	Paper Tray4(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-058	Paper Tray4(Custom 2)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-059	LCT(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-060	LCT(Custom 2)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-063	Interposer(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-064	Interposer(Custom 2)	ENG	[0 to 255 / 0 / 1 % / step]
7-954-066	Ozon Filter(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]

7960	[Estimated Usage Rate]		
7-960-001	Developer	ENG	[0 to 255 / 0 / 1 % / step]
7-960-002	Hot Roller	ENG	[0 to 255 / 0 / 1 % / step]
7-960-003	Pressure Roller	ENG	[0 to 255 / 0 / 1 % / step]
7-960-004	Hot Roller Bearings	ENG	[0 to 255 / 0 / 1 % / step]
7-960-005	Pressure Roller Bearings	ENG	[0 to 255 / 0 / 1 % / step]
7-960-006	Hot Roller Strippers	ENG	[0 to 255 / 0 / 1 % / step]
7-960-007	Cleaning Roller	ENG	[0 to 255 / 0 / 1 % / step]
7-960-008	Cleaning Roller Bearings	ENG	[0 to 255 / 0 / 1 % / step]
7-960-009	Web Roll	ENG	[0 to 255 / 0 / 1 % / step]

7-960-010	Web Cleaning Roller	ENG	[0 to 255 / 0 / 1 % / step]
7-960-011	Development Filter	ENG	[0 to 255 / 0 / 1 % / step]
7-960-012	Toner Recycling Unit	ENG	[0 to 255 / 0 / 1 % / step]
7-960-013	Pressure Release Filter	ENG	[0 to 255 / 0 / 1 % / step]
7-960-014	Charge Corona Wire	ENG	[0 to 255 / 0 / 1 % / step]
7-960-015	Grid Plate	ENG	[0 to 255 / 0 / 1 % / step]
7-960-016	Cleaning Pad	ENG	[0 to 255 / 0 / 1 % / step]
7-960-017	Cleaning Blade	ENG	[0 to 255 / 0 / 1 % / step]
7-960-018	Cleaning Brush	ENG	[0 to 255 / 0 / 1 % / step]
7-960-019	Transfer Belt	ENG	[0 to 255 / 0 / 1 % / step]
7-960-020	Transfer Belt Cleaning Blade	ENG	[0 to 255 / 0 / 1 % / step]
7-960-022	ADF Pick-up Roller	ENG	[0 to 255 / 0 / 1 % / step]
7-960-023	ADF Feed Belt	ENG	[0 to 255 / 0 / 1 % / step]
7-960-024	ADF Separation Roller	ENG	[0 to 255 / 0 / 1 % / step]
7-960-025	Feed Roller-Tray1	ENG	[0 to 255 / 0 / 1 % / step]
7-960-026	Pick-up Roller-Tray1	ENG	[0 to 255 / 0 / 1 % / step]
7-960-027	Separation Roller-Tray1	ENG	[0 to 255 / 0 / 1 % / step]
7-960-028	Feed Roller-Tray2	ENG	[0 to 255 / 0 / 1 % / step]
7-960-029	Pick-up Roller-Tray2	ENG	[0 to 255 / 0 / 1 % / step]
7-960-030	Separation Roller-Tray2	ENG	[0 to 255 / 0 / 1 % / step]
7-960-031	Feed Roller-Tray3	ENG	[0 to 255 / 0 / 1 % / step]
7-960-032	Pick-up Roller-Tray3	ENG	[0 to 255 / 0 / 1 % / step]
7-960-033	Separation Roller-Tray3	ENG	[0 to 255 / 0 / 1 % / step]
7-960-034	Feed Roller-Tray4	ENG	[0 to 255 / 0 / 1 % / step]
7-960-035	Pick-up Roller-Tray4	ENG	[0 to 255 / 0 / 1 % / step]
7-960-036	Separation Roller-Tray4	ENG	[0 to 255 / 0 / 1 % / step]

7-960-037	Feed Roller-LCT	ENG	[0 to 255 / 0 / 1 % / step]
7-960-038	Pick-up Roller-LCT	ENG	[0 to 255 / 0 / 1 % / step]
7-960-039	Separation Roller-LCT	ENG	[0 to 255 / 0 / 1 % / step]
7-960-040	Feed Belt Cover feeder	ENG	[0 to 255 / 0 / 1 % / step]
7-960-041	Pick-up Roller Cover feeder	ENG	[0 to 255 / 0 / 1 % / step]
7-960-042	Separation Roller Cover feeder	ENG	[0 to 255 / 0 / 1 % / step]
7-960-044	Fusing unit:Thermistor(Back)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-045	Fusing unit:Thermistor(Center)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-046	Dust Filter(Main)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-047	Main Tray(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-048	Main Tray(Custom 2)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-049	Main Tray(Custom 3)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-050	Main Tray(Custom 4)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-051	Paper Tray1(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-052	Paper Tray1(Custom 2)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-053	Paper Tray2(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-054	Paper Tray2(Custom 2)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-055	Paper Tray3(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-056	Paper Tray3(Custom 2)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-057	Paper Tray4(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-058	Paper Tray4(Custom 2)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-059	LCT(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-060	LCT(Custom 2)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-063	Interposer(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]
7-960-064	Interposer(Custom 2)	ENG	[0 to 255 / 0 / 1 % / step]

7-960-066	Ozon Filter(Custom 1)	ENG	[0 to 255 / 0 / 1 % / step]
-----------	-----------------------	-----	-----------------------------

7979	[ENG Reset Log]		
7-979-001	Data1	ENG*	[0x00 to 0xFF / 0x00 / 1 / step]
7-979-002	Data2	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-003	Data3	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-004	Data4	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-005	Data5	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-006	Data6	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-007	Data7	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-008	Data8	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-009	Data9	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-010	Data10	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-011	Data11	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-012	Data12	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-013	Data13	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-014	Data14	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-015	Data15	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-016	Data16	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-017	Data17	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-018	Data18	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-019	Data19	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-020	Data20	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]
7-979-021	Data21	ENG*	[0x0000 to 0xFFFF / 0x0000 / 1 / step]

Input and Output Check

Input Check Table

2

When entering the Input Check mode, 8 digits display the result for a section. Each digit corresponds to a different device as shown in the table.

Bit No.	7	6	5	4	3	2	1	0
Result	0 or 1	0 or 1	0 or 1	0 or 1	0 or 1	0 or 1	0 or 1	0 or 1

Main Machine, LTC

5-803-001 IOB-VODKA1-GPIO3

Bit	Description	1	0
0	PCB version detection 4	Combination 1	Combination 1
1	PCB version detection 3	Combination 1	Combination 1
2	PCB version detection 2	Combination 1	Combination 1
3	PCB version detection 1	Combination 1	Combination 1
4	-	-	-
5	-	-	-
6	-	-	-
7	-	-	-

5-803-002 IOB-VODKA1-GPIO9

Bit	Description	1	0
0	-	-	-
1	-	-	-
2	-	-	-
3	-	-	-

Bit	Description	1	0
4	Front fence open sensor	Open	Closed
5	Front fence release sensor	Closed	Open
6	Back fence open sensor	Open	Closed
7	Back fence release sensor	Closed	Open

5-803-003 IOB-VODKA1-GPIO10

Bit	Description	1	0
0	-	-	-
1	-	-	-
2	-	-	-
3	-	-	-
4	-	-	-
5	-	-	-
6	Controller exhaust fan		Locked
7	-	-	-

5-803-004 IOB-VODKA1-GPIO13

Bit	Description	1	0
0	-	-	-
1	Tandem right tray set detection	Not set	Set
2	Tandem tray down sensor	Down	
3	Right tray paper sensor	No paper	Paper
4	Tray 1 paper height sensor 3	Detect	Not detect
5	Tray 1 paper height sensor 2	Detect	Not detect
6	Tray 1 paper height sensor 1	Detect	Not detect
7	Tandem 1 near end sensor	-	-

5-803-005 IOB-VODKA1-GPIO17

Bit	Description	1	0
0	-	-	-
1	Tandem left tray set detect	Not set	Set
2	Side fence HP sensor	HP	
3	Pressure sensor	Pressed	
4	Left tray paper end sensor	No paper	Paper
5	Tray type detect	3 trays	4 trays
6	Back fence open/close sensor	Closed	Open
7	Back fence HP sensor		HP

5-803-006 IOB-VODKA1-GPIO18

Bit	Description	1	0
0	-	-	-
1	CPM detection	90 cpm	65/75 cpm
2	3 trays/ 4 trays detection	3 trays	4 trays
3	Tray 2 paper size detection switch 5	Off	On
4	Tray 2 paper size detection switch 4	Off	On
5	Tray 2 paper size detection switch 3	Off	On
6	Tray 2 paper size detection switch 2	Off	On
7	Tray 2 paper size detection switch 1	Off	On

5-803-007 IOB-VODKA1-GPIO19

Bit	Description	1	0
0	Paper feed sensor 1	No paper	Paper
1	Paper feed sensor 2	No paper	Paper
2	Paper feed sensor 3	No paper	Paper

Bit	Description	1	0
3	Paper feed sensor 4	No paper	Paper
4	Vertical Transport Sensor 1	No paper	Paper
5	Vertical Transport Sensor 2	No paper	Paper
6	Vertical Transport Sensor 3	No paper	Paper
7	Vertical Transport Sensor 4	No paper	Paper

5-803-008 IOB-VODKA1-GPIO21

Bit	Description	1	0
0	Paper end sensor 1	No paper	Paper
1	Paper end sensor 2	No paper	Paper
2	Paper end sensor 3	No paper	Paper
3	Paper end sensor 4	No paper	Paper
4	Tray 1 paper height sensor 1	Paper	No paper
5	Tray 2 paper height sensor 1	Paper	No paper
6	Tray 3 paper height sensor 1	Paper	No paper
7	Tray 4 paper height sensor 1	Paper	No paper

5-803-009 IOB-VODKA1-GPIO22

Bit	Description	1	0
0	Tray 1 paper height sensor 2	Paper	Near end
1	Tray 2 paper height sensor 2	Paper	Near end
2	Tray 3 paper height sensor 2	Paper	Near end
3	Tray 4 paper height sensor 2	Paper	Near end
4	-	-	-
5	-	-	-
6	-	-	-

Bit	Description	1	0
7	-	-	-

5-803-010 IOB-VODKA1-GPIO24

Bit	Description	1	0
0	-	-	-
1	-	-	-
2	-	-	-
3	Tray 3 paper size detection switch 5	Off	On
4	Tray 3 paper size detection switch 4	Off	On
5	Tray 3 paper size detection switch 3	Off	On
6	Tray 3 paper size detection switch 2	Off	On
7	Tray 3 paper size detection switch 1	Off	On

5-803-011 IOB-VODKA1-GPIO25

Bit	Description	1	0
0	Tray 4 paper size detection switch 5	Off	On
1	Tray 4 paper size detection switch 4	Off	On
2	Tray 4 paper size detection switch 3	Off	On
3	Tray 4 paper size detection switch 2	Off	On
4	Tray 4 paper size detection switch 1	Off	On
5	-	-	-
6	-	-	-
7	PFU fan 4		Locked

5-803-012 IOB-VODKA1-GPIO30

Bit	Description	1	0
0	PFU fan 1		Locked
1	PFU fan 2		Locked
2	-	-	-
3	PFU fan 3		Locked
4	Lift sensor 1	-	Up
5	Lift sensor 2	-	Up
6	Lift sensor 3	-	Up
7	Lift sensor 4	-	Up

5-803-013 IOB-VODKA2-GPIO23

Bit	Description	1	0
0	Key card		Copy allowed
1	Hardware high temperature detection 2	Normal	
2	-	-	-
3	-	-	-
4	-	-	-
5	-	-	-
6	-	-	-
7	-	-	-

5-803-014 IOB-VODKA2-GPIO26

Bit	Description	1	0
0	Reserve fan		Locked
1	Fusing exit sensor	Paper	No paper
2	Fusing unit set detection	Not set	Set

Bit	Description	1	0
3	Key counter set detection 2	Set	Not set
4	Duplex unit set detection	Not set	Set
5	-	-	-
6	-	-	-
7	-	-	-

5-803-015 IOB-VODKA2-GPIO27

Bit	Description	1	0
0	-	-	-
1	Duplex entrance sensor	No paper	Paper
2	Inverter exit sensor	No paper	Paper
3	-	-	-
4	Jogger HP sensor	Feeler	No feeler
5	Transport sensors 1	No paper	Paper
6	Transport sensors 2	No paper	Paper
7	Transport sensors 3	No paper	Paper

5-803-016 IOB-VODKA2-GPIO29

Bit	Description	1	0
0	-	-	-
1	-	-	-
2	-	-	-
3	-	-	-
4	Key counter set detection	Not set	Set
5	Grid PP leak detection		Normal
6	Charge PP leak detection		Normal

Bit	Description	1	0
7	Toner collection motor sensor	Detect	Not detect

5-803-017 IOB-VODKA2-GPIO30

Bit	Description	1	0
0	Drum fan		Locked
1	Development unit fan 2		Locked
2	Development unit fan 1		Locked
3	Main intake fan	Locked	
4	Main intake fan	Locked	
5	Main exhaust fan	Locked	
6	PCU fan		Locked
7	Toner bottle fan		Locked

2

5-803-018 IOB-VODKA3-GPIO1

Bit	Description	1	0
0	DIP SW 8	Off	On
1	DIP SW 7	Off	On
2	DIP SW 6	Off	On
3	DIP SW 5	Off	On
4	DIP SW 4	Off	On
5	DIP SW 3	Off	On
6	DIP SW 2	Off	On
7	DIP SW 1	Off	On

5803	[Input Check]		
5-803-019	LD0 lop Monitor	ENG	[0 to 999 / 0 / 0.1 mA / step]

5-803-020	LD1 lop Monitor	ENG	[0 to 999 / 0 / 0.1 mA / step]
5-803-021	LD2 lop Monitor	ENG	[0 to 999 / 0 / 0.1 mA / step]
5-803-022	LD3 lop Monitor	ENG	[0 to 999 / 0 / 0.1 mA / step]
5-803-023	Capacitor Port 1	ENG	[0x00 to 0xFF / 0x00 / 1 / step]
5-803-024	Capacitor Port 5	ENG	[0x00 to 0xFF / 0x00 / 1 / step]
5-803-025	Capacitor Port 7	ENG	[0x00 to 0xFF / 0x00 / 1 / step]

5-803-026 IOB-VODKA3-GPIO12

Bit	Description	1	0
0	PCU fan 1		Locked
1	PCU fan 2		Locked
2	-	-	-
3	Used toner bottle set sensor	Not set	Set
4	Drum motor		Rated rotation
5	-	-	-
6	Development motor		Rated rotation
7	-	-	-

5-803-027 IOB-VODKA3-GPIO13

Bit	Description	1	0
0	-	-	-
1	Exit unit entrance sensor	No paper	Paper
2	Paper exit sensor	No paper	Paper
3	Turn sensor	Detect	Not detect
4	Fusing inner cover fan		Locked
5	Fusing pressure release sensor	Pressure released	
6	Exit unit set detection	Not set	Set

Bit	Description	1	0
7	Web end sensor	Web end	

5-803-028 IOB-VODKA3-GPIO19

Bit	Description	1	0
0	-	-	-
1	Development PP error detection		Normal
2	Lever C1 open/close sensor	Open	Closed
3	CAPCNT: WAKEUP	Sleep	Boot
4	CAPCNT set detection	Not set	Set
5	65CPM unit set detection	Not set	Set
6	-	-	-
7	Used toner lock sensor	Detect	Not detect

2

5-803-029 IOB-VODKA3-GPIO22

Bit	Description	1	0
0	-	-	-
1	-	-	-
2	-	-	-
3	-	-	-
4	AC drive board fan		Locked
5	Used toner bottle full sensor	Full	Not full
6	Toner end sensor	Toner	No toner
7	Front door open/close detection	Open	Closed

5-803-030 IOB-VODKA3-GPIO26

Bit	Description	1	0
0	Total counter set detection	Set	Not set
1	Reserved	-	-
2	Reserved	-	-
3	Reserved	-	-
4	-	-	-
5	Hardware high temperature detection 1	Normal	
6	NC sensor high temperature detection	Normal	
7	-	-	-

5-803-031 IOB-VODKA3-GPIO30

Bit	Description	1	0
0	-	-	-
1	-	-	-
2	-	-	-
3	Bypass paper end sensor	No paper	Paper
4	Duplex fan		Locked
5	Guide open/close sensor	Open	Closed
6	Exit full sensor	Full	Not full
7	Bypass paper length sensor	No paper	Paper

5-803-032 IOB-VODKA2-EIMON1

Bit	Description	1	0
0	-	-	-
1	-	-	-
2	-	-	-

Bit	Description	1	0
3	-	-	-
4	Relay sensor	No paper	Paper
5	-	-	-
6	Registration sensor	No paper	Paper
7	-	-	-

5-803-033 IOB-VODKA2-GPIO7

Bit	Description	1	0
0	-	-	-
1	-	-	-
2	Fusing exit motor	Rated rotation	-
3	-	-	-
4	-	-	-
5	-	-	-
6	-	-	-
7	-	-	-

5-803-050 LCT Port1

Bit	Description	1	0
0	Paper feed motor	Normal	
1	-	-	-
2	-	-	-
3	-	-	-
4	-	-	-
5	-	-	-
6	-	-	-

Bit	Description	1	0
7	-	-	-

5-803-051 LCT Port2

Bit	Description	1	0
0	Paper supply cover open/close sensor	Open	Closed
1	Tray falling SW	Off	On
2	Paper detection	Not detect	Detect
3	Paper jam release open/close SW	Open	Closed
4	-	-	-
5	-	-	-
6	-	-	-
7	-	-	-

5-803-052 LCT Port3

Bit	Description	1	0
0	Lower limit detection	Lower limit	
1	Paper end detection	No paper	Paper
2	Upper limit detection	Upper limit	
3	-	-	-
4	-	-	-
5	Paper feed sensor	No paper	Paper
6	-	-	-
7	-	-	-

5-803-053 LCT Port4

Bit	Description	1	0
0	Paper stack height detection 1 (near end)	Detect	Not detect
1	Paper stack height detection 2 (1500 pages)	Detect	Not detect
2	Paper stack height detection 3 (2500 pages)	Detect	Not detect
3	Paper stack height detection 4 (3500 pages)	Detect	Not detect
4	-	-	-
5	Blown fuse detection	Blown	Normal
6	-	-	-
7	-	-	-

5803	[Input Check]		
5-803-200	HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
5-803-201	Platen ADF Sensor	ENG	[0 or 1 / 0 / 1 / step]
5-803-202	Scanner fan lock signal	ENG	[0 to 3 / 0 / 1 / step]

ADF

6011	[1-Pass ADF INPUT Check]		
6-011-001	Original Length 1 (B5 Sensor)	ENG	[0 or 1 / 0 / 1 / step]
6-011-002	Original Length 2 (A4 Sensor)	ENG	[0 or 1 / 0 / 1 / step]
6-011-003	Original Length 3 (LG Sensor)	ENG	[0 or 1 / 0 / 1 / step]
6-011-004	Original Width 1	ENG	[0 or 1 / 0 / 1 / step]
6-011-005	Original Width 2	ENG	[0 or 1 / 0 / 1 / step]

6-011-006	Original Width 3	ENG	[0 or 1 / 0 / 1 / step]
6-011-007	Original Width 4	ENG	[0 or 1 / 0 / 1 / step]
6-011-008	Original Width 5	ENG	[0 or 1 / 0 / 1 / step]
6-011-009	Original Detection	ENG	[0 or 1 / 0 / 1 / step]
6-011-010	Separation Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-011-011	Skew Correction	ENG	[0 or 1 / 0 / 1 / step]
6-011-012	Scan Entrance Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-011-013	Registration Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-011-014	Exit Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-011-015	Feed Cover Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-011-016	Lift Up Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-011-018	Pick-Up Roller HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-011-021	Bottom Plate HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-011-022	Bottom Plate Position Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-011-023	Original Length 4 (LT/A4 Tail Sensor)	ENG	[0 or 1 / 0 / 1 / step]

2K/3K Finisher

6123	[INPUT Check: 2K/3K FIN]		
6-123-001	Entrance Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-002	Horizontal Transport Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-003	Switchback Transport Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-004	Proof Tray Exit Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-005	Shift Tray Exit Sensor	ENG	[0 or 1 / 0 / 1 / step]

6-123-006	Booklet Stapler Exit Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-007	Paper Exit Open/Close Guide HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-008	Punch HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-009	Punch Move HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-010	S-to-S Registration Detection HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-011	Lower Junction Solenoid HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-012	Jogger HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-013	Positioning Roller HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-014	Feed-out HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-015	Stapler Moving HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-016	Booklet Stapler HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-017	Booklet Jogger HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-018	Booklet Jog Solenoid HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-019	Booklet Standard Fence HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-020	Booklet Stapler HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-022	Folder Blade Cam HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-023	Folder Blade HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-024	Shift Roller HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-028	Drag Roller Vibrating HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-029	LE Guide HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-030	TE Stack Plate HP Sensor	ENG	[0 or 1 / 0 / 1 / step]

6-123-031	Staple Tray Paper Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-032	ITB Paper Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-033	Booklet Stapler Transport Paper Sn: Upper	ENG	[0 or 1 / 0 / 1 / step]
6-123-034	Booklet Stapler Transport Paper Sn: Lower	ENG	[0 or 1 / 0 / 1 / step]
6-123-035	Paper Height Sensor: Shift	ENG	[0 or 1 / 0 / 1 / step]
6-123-036	Corner Stapler Paper Height Sensor 1	ENG	[0 or 1 / 0 / 1 / step]
6-123-037	Corner Stapler Paper Height Sensor 2	ENG	[0 or 1 / 0 / 1 / step]
6-123-038	Proof Tray Full Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-039	Booklet Stapler Full Sensor 1	ENG	[0 or 1 / 0 / 1 / step]
6-123-040	Booklet Stapler Full Sensor 2	ENG	[0 or 1 / 0 / 1 / step]
6-123-041	S-to-S Registration Detection Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-042	Punch RPS Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-043	Corner Stapler Leading Edge Detection Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-044	Corner Stapler Staple End Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-045	Booklet Stapler Staple End Sensor: Front	ENG	[0 or 1 / 0 / 1 / step]
6-123-046	Booklet Stapler Staple End Sensor: Rear	ENG	[0 or 1 / 0 / 1 / step]
6-123-047	Shift Tray Lower Limit Sensor 1	ENG	[0 or 1 / 0 / 1 / step]
6-123-048	Shift Tray Lower Limit Sensor 2	ENG	[0 or 1 / 0 / 1 / step]

6-123-049	Shift Tray Lower Limit Sensor 3	ENG	[0 or 1 / 0 / 1 / step]
6-123-050	Shift Tray Lower Limit Sensor 4	ENG	[0 or 1 / 0 / 1 / step]
6-123-051	Shift Tray Lower Limit Sensor 5	ENG	[0 or 1 / 0 / 1 / step]
6-123-052	Punch Chad Full Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-053	Punch Set Detection	ENG	[0 or 1 / 0 / 1 / step]
6-123-054	Shift Jogger Set Detection	ENG	[0 or 1 / 0 / 1 / step]
6-123-055	Booklet Stapler Set Detection	ENG	[0 or 1 / 0 / 1 / step]
6-123-056	Front Door SW	ENG	[0 or 1 / 0 / 1 / step]
6-123-057	Dynamic Roller Open/Close Guide Plate Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-058	Tray Upper Limit SW	ENG	[0 or 1 / 0 / 1 / step]
6-123-059	Paper Exit Open/Close Guide Plate Limit SW	ENG	[0 or 1 / 0 / 1 / step]
6-123-060	Punch Selection DIPSW 1	ENG	[0 or 1 / 0 / 1 / step]
6-123-061	Punch Selection DIPSW 2	ENG	[0 or 1 / 0 / 1 / step]
6-123-065	Paper Guide HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-123-066	Shift Jogger HP Sensor: Front	ENG	[0 or 1 / 0 / 1 / step]
6-123-067	Shift Jogger HP Sensor: Rear	ENG	[0 or 1 / 0 / 1 / step]
6-123-068	Shift Jogger Retraction HP Sensor: Upper	ENG	[0 or 1 / 0 / 1 / step]
6-123-069	Shift Jogger Retraction HP Sensor: Lower	ENG	[0 or 1 / 0 / 1 / step]

Finisher

6147	[Finisher Input Check: Fin 2]		
6-147-001	Entrance Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-002	Proof Exit Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-003	Shift Exit Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-004	Staple Exit Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-005	Tray Lower Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-006	Tray Near Lower Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-007	Stack Feed-out HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-008	Jogger HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-009	Shift HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-010	Stapler Moving HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-011	Staple HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-012	Staple Cartridge Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-013	Staple Tray Paper Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-014	Door Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-015	Punch Unit Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-016	Punch HP1 Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-017	Punch Chad Full Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-018	Paper Detection Sensor: Staple	ENG	[0 or 1 / 0 / 1 / step]
6-147-019	Paper Detection Sensor: Shift	ENG	[0 or 1 / 0 / 1 / step]
6-147-021	Proof Full Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-022	Stapler Moving HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-023	Staple Waste Hopper Sensor	ENG	[0 or 1 / 0 / 1 / step]

6-147-024	Pre-stack Tray Paper Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-025	Hold HP Snsor	ENG	[0 or 1 / 0 / 1 / step]
6-147-026	Exit Guide HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-027	Stapler Reverse Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-028	Staper Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-029	Front Hold HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-030	Rear Hold HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-031	Knock Hold HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-032	Reverse Drive HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-033	Paper Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-034	Tray Lower Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-035	Punch HP 2 Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-036	Shift Jogger Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-037	Shift Jogger HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-038	Shift Jogger Release HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-039	Front Door Safty Switch	ENG	[0 or 1 / 0 / 1 / step]
6-147-040	Top Fence HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-041	Bottom Fence HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-147-042	Lower Tray Full Sn (Z-Folded Paper)	ENG	[0 or 1 / 0 / 1 / step]
6-147-051	Staple Cartridge Set Sensor	ENG	[0 or 1 / 0 / 1 / step]

Slide Sort Tray

6250	[INPUT Check Slide Sort Tray]		
6-250-001	Transport Sensor	ENG	[0 or 1 / 0 / 1 / step]

6-250-002	Shift Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-250-003	Lower Limit Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-250-004	Paper Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-250-005	Door Switch	ENG	[0 or 1 / 0 / 1 / step]

Multi Folder

6309	[INPUT Check Multi Folder]		
6-309-001	Entrance Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-002	Entrance JG HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-004	Registration Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-005	Dynamic Roller HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-006	Registration Roller HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-007	Fold Plate HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-008	Jogger Fence HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-010	1st Stopper Paper Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-011	1st Stopper HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-012	2nd Stopper Paper Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-013	2nd Stopper HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-014	3rd Stopper Paper Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-015	3rd Stopper HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-016	Direct-Send JG HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-017	FM6 Pawl HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-018	Top Tray Paper Path Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-019	Top Tray Exit Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-020	Horizontal Path Exit Sensor	ENG	[0 or 1 / 0 / 1 / step]

6-309-021	Top Tray Full Sensor (E)	ENG	[0 or 1 / 0 / 1 / step]
6-309-023	Front Door Switch (SW1)	ENG	[0 or 1 / 0 / 1 / step]
6-309-024	Horizontal Path Paper Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-025	Vertical Path Paper Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-026	Bypass Entrance Paper Sensor	ENG	[0 or 1 / 0 / 1 / step]
6-309-027	Bypass Exit Paper Sensor	ENG	[0 or 1 / 0 / 1 / step]

Print Post

6350	[Input Check Print Post]		
6-350-001	Paper Detect Sn 1	ENG	[0 or 1 / 0 / 1 / step]
6-350-002	Vert Transport Sn1:Bin1	ENG	[0 or 1 / 0 / 1 / step]
6-350-003	Paper Overflow Sn 1	ENG	[0 or 1 / 0 / 1 / step]
6-350-004	Paper Detect Sn 2	ENG	[0 or 1 / 0 / 1 / step]
6-350-005	Vert Transport Sn2:Bin3	ENG	[0 or 1 / 0 / 1 / step]
6-350-006	Paper Overflow Sn 2	ENG	[0 or 1 / 0 / 1 / step]
6-350-007	Paper Detect Sn 3	ENG	[0 or 1 / 0 / 1 / step]
6-350-008	Paper Overflow Sn 3	ENG	[0 or 1 / 0 / 1 / step]
6-350-009	Paper Detect Sn 4	ENG	[0 or 1 / 0 / 1 / step]
6-350-010	Vert Transport Sn3:Bin5	ENG	[0 or 1 / 0 / 1 / step]
6-350-011	Paper Overflow Sn 4	ENG	[0 or 1 / 0 / 1 / step]
6-350-012	Paper Detect Sn 5	ENG	[0 or 1 / 0 / 1 / step]
6-350-013	Paper Overflow Sn 5	ENG	[0 or 1 / 0 / 1 / step]
6-350-014	Paper Detect Sn 6	ENG	[0 or 1 / 0 / 1 / step]
6-350-015	Vert Transport Sn4:Bin7	ENG	[0 or 1 / 0 / 1 / step]

6-350-016	Paper Overflow Sn 6	ENG	[0 or 1 / 0 / 1 / step]
6-350-017	Paper Detect Sn 7	ENG	[0 or 1 / 0 / 1 / step]
6-350-018	Paper Overflow Sn 7	ENG	[0 or 1 / 0 / 1 / step]
6-350-019	Paper Detect Sn 8	ENG	[0 or 1 / 0 / 1 / step]
6-350-020	Vert Transport Sn5:Bin9	ENG	[0 or 1 / 0 / 1 / step]
6-350-021	Paper Overflow Sn 8	ENG	[0 or 1 / 0 / 1 / step]
6-350-022	Paper Detect Sn 9	ENG	[0 or 1 / 0 / 1 / step]
6-350-023	Paper Overflow Sn 9	ENG	[0 or 1 / 0 / 1 / step]
6-350-024	Door Open Switch	ENG	[0 or 1 / 0 / 1 / step]

1-Tray CIT

6451	[INPUT Check: 1-Tray CIT]		
6451001	Paper Feed Cover Sensor	ENG	[0 or 1 / 0 / 1 / step]
6451002	Bottom Plate HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6451003	Paper Near End Sensor	ENG	[0 or 1 / 0 / 1 / step]
6451004	Paper Set Sensor	ENG	[0 or 1 / 0 / 1 / step]
6451005	Bottom Plate HP Sensor	ENG	[0 or 1 / 0 / 1 / step]
6451006	Grip Sensor	ENG	[0 or 1 / 0 / 1 / step]
6451007	Guide Plate Set Sensor	ENG	[0 or 1 / 0 / 1 / step]
6451008	Exit Sensor	ENG	[0 or 1 / 0 / 1 / step]
6451009	Paper Set Sensor	ENG	[0 or 1 / 0 / 1 / step]
6451010	Width Sensor 1	ENG	[0 or 1 / 0 / 1 / step]
6451011	Width Sensor 2	ENG	[0 or 1 / 0 / 1 / step]
6451012	Width Sensor 3	ENG	[0 or 1 / 0 / 1 / step]
6451013	Length Sensor 1	ENG	[0 or 1 / 0 / 1 / step]

6451014	Length Sensor 2	ENG	[0 or 1 / 0 / 1 / step]
6451015	Length Sensor 3	ENG	[0 or 1 / 0 / 1 / step]

Output Check Table

Activates the electrical components for functional check.

It is not possible to activate more than one component at the same time.

Main Machine, LTC

5804	[Output Check]		
5-804-001	Feed Motor 1	ENG	[0 or 1 / 0 / 0 / step]
5-804-002	Feed Motor 2	ENG	[0 or 1 / 0 / 0 / step]
5-804-003	Feed Motor 3	ENG	[0 or 1 / 0 / 0 / step]
5-804-004	Feed Motor 4	ENG	[0 or 1 / 0 / 0 / step]
5-804-005	By-pass Feed Clutch	ENG	[0 or 1 / 0 / 0 / step]
5-804-006	LCT Feed Motor	ENG	[0 or 1 / 0 / 1 / step]
5-804-009	Pick-up SOL 1	ENG	[0 or 1 / 0 / 0 / step]
5-804-010	Pick-up SOL 2	ENG	[0 or 1 / 0 / 0 / step]
5-804-011	Pick-up SOL 3	ENG	[0 or 1 / 0 / 0 / step]
5-804-012	Pick-up SOL 4	ENG	[0 or 1 / 0 / 0 / step]
5-804-013	By-pass Pick-up SOL	ENG	[0 or 1 / 0 / 0 / step]
5-804-014	LCT Pick-up SOL	ENG	[0 or 1 / 0 / 1 / step]
5-804-017	Reverse Release SOL 1	ENG	[0 or 1 / 0 / 0 / step]
5-804-018	Reverse Release SOL 2	ENG	[0 or 1 / 0 / 0 / step]
5-804-019	Reverse Release SOL 3	ENG	[0 or 1 / 0 / 0 / step]
5-804-020	Reverse Release SOL 4	ENG	[0 or 1 / 0 / 0 / step]

5-804-022	Tandem Connection Release SOL	ENG	[0 or 1 / 0 / 0 / step]
5-804-023	Left Tandem Lock SOL	ENG	[0 or 1 / 0 / 0 / step]
5-804-024	Tandem Transport Motor	ENG	[0 or 1 / 0 / 0 / step]
5-804-027	Relay Motor	ENG	[0 or 1 / 0 / 0 / step]
5-804-028	Main Motor	ENG	[0 or 1 / 0 / 0 / step]
5-804-031	Fusing Discharge Motor	ENG	[0 or 1 / 0 / 0 / step]
5-804-032	Fusing Removal Motor	ENG	[0 or 1 / 0 / 1 / step]
5-804-039	Registration Motor	ENG	[0 or 1 / 0 / 0 / step]
5-804-040	Guide Plate Release SOL	ENG	[0 or 1 / 0 / 0 / step]
5-804-041	Exit Junction SOL	ENG	[0 or 1 / 0 / 1 / step]
5-804-043	Inverter Duplex Motor	ENG	[0 or 1 / 0 / 0 / step]
5-804-044	Duplex Transport Motor	ENG	[0 or 1 / 0 / 0 / step]
5-804-045	Duplex Entrance Gate SOL	ENG	[0 or 1 / 0 / 0 / step]
5-804-046	Inverter Jogger SOL	ENG	[0 or 1 / 0 / 0 / step]
5-804-048	Duplex Jogger	ENG	[0 or 1 / 0 / 0 / step]
5-804-052	Toner Supply CL	ENG	[0 or 1 / 0 / 0 / step]
5-804-053	Development Motor	ENG	[0 or 1 / 0 / 0 / step]
5-804-054	Used Toner Motor	ENG	[0 or 1 / 0 / 0 / step]
5-804-055	Web Motor	ENG	[0 or 1 / 0 / 1 / step]
5-804-056	Toner Bottle Motor	ENG	[0 or 1 / 0 / 0 / step]
5-804-057	Transfer/Separation SOL	ENG	[0 or 1 / 0 / 0 / step]
5-804-062	Quenching Lamp	ENG	[0 or 1 / 0 / 0 / step]
5-804-063	Charge Corona	ENG	[0 or 1 / 0 / 0 / step]
5-804-064	Grid Wire	ENG	[0 or 1 / 0 / 0 / step]

5-804-067	Development Bias	ENG	[0 or 1 / 0 / 0 / step]
5-804-069	Transfer Bias	ENG	[0 or 1 / 0 / 0 / step]
5-804-070	ID Sensor LED	ENG	[0 or 1 / 0 / 0 / step]
5-804-073	New Toner Bottle Cooling Fan	ENG	[0 or 1 / 0 / 0 / step]
5-804-074	Development Unit Fan 1	ENG	[0 or 1 / 0 / 0 / step]
5-804-075	Duplex Unit Fan	ENG	[0 or 1 / 0 / 0 / step]
5-804-076	Main Ventilation Fan	ENG	[0 or 1 / 0 / 0 / step]
5-804-077	Main Suction Fan	ENG	[0 or 1 / 0 / 0 / step]
5-804-078	Drum Cooling Fan	ENG	[0 or 1 / 0 / 0 / step]
5-804-079	OPC Fan	ENG	[0 or 1 / 0 / 0 / step]
5-804-084	Total Counter	ENG	[0 or 1 / 0 / 0 / step]
5-804-098	Status Lamp (Green)	ENG	[0 or 1 / 0 / 0 / step]
5-804-099	Status Lamp (Red)	ENG	[0 or 1 / 0 / 0 / step]
5-804-100	PTL	ENG	[0 or 1 / 0 / 0 / step]
5-804-101	LD0 DC Lamp	ENG	[0 or 1 / 0 / 0 / step]
5-804-102	LD1 DC Lamp	ENG	[0 or 1 / 0 / 0 / step]
5-804-103	LD2 DC Lamp	ENG	[0 or 1 / 0 / 0 / step]
5-804-104	LD3 DC Lamp	ENG	[0 or 1 / 0 / 0 / step]
5-804-111	Development Unit Fan 2	ENG	[0 or 1 / 0 / 0 / step]
5-804-112	Fusing Exit Inner Cover Fan	ENG	[0 or 1 / 0 / 0 / step]
5-804-113	PSU Cooling Fan 1	ENG	[0 or 1 / 0 / 0 / step]
5-804-114	PSU Cooling Fan 2	ENG	[0 or 1 / 0 / 0 / step]
5-804-115	AC Cooling Fan	ENG	[0 or 1 / 0 / 0 / step]
5-804-116	Controller Exhaust Fan	ENG	[0 or 1 / 0 / 0 / step]

5-804-117	Capacitor Cooling Fan	ENG	[0 or 1 / 0 / 0 / step]
5-804-118	Exhaust Heat Fan	ENG	[0 or 1 / 0 / 0 / step]
5-804-120	Paper Feeding Fan 1	ENG	[0 or 1 / 0 / 0 / step]
5-804-121	Paper Feeding Fan 2	ENG	[0 or 1 / 0 / 0 / step]
5-804-122	Paper Feeding Fan 3	ENG	[0 or 1 / 0 / 0 / step]
5-804-123	Paper Feeding Fan 4	ENG	[0 or 1 / 0 / 0 / step]
5-804-150	LED A	ENG	[0 or 1 / 0 / 0 / step]
5-804-151	LED B1	ENG	[0 or 1 / 0 / 0 / step]
5-804-152	LED B2	ENG	[0 or 1 / 0 / 0 / step]
5-804-153	LED C1	ENG	[0 or 1 / 0 / 0 / step]
5-804-154	LED C2	ENG	[0 or 1 / 0 / 0 / step]
5-804-155	LED D1/E1	ENG	[0 or 1 / 0 / 0 / step]
5-804-156	LED D2/D3	ENG	[0 or 1 / 0 / 0 / step]
5-804-157	LED E2/Z	ENG	[0 or 1 / 0 / 0 / step]
5-804-158	LED Front Cover	ENG	[0 or 1 / 0 / 0 / step]
5-804-159	LED ALL	ENG	[0 or 1 / 0 / 0 / step]
5-804-161	Tray 1 Lift Motor (Up: 1sec)	ENG	[0 or 1 / 0 / 0 / step]
5-804-162	Tray 1 Lift Motor (Down: 1sec)	ENG	[0 or 1 / 0 / 0 / step]
5-804-163	Tray 2 Lift Motor (Up: 1sec)	ENG	[0 or 1 / 0 / 0 / step]
5-804-164	Tray 2 Lift Motor (Down: 1sec)	ENG	[0 or 1 / 0 / 0 / step]
5-804-165	Tray 3 Lift Motor (Up: 1sec)	ENG	[0 or 1 / 0 / 0 / step]
5-804-166	Tray 3 Lift Motor (Down: 1sec)	ENG	[0 or 1 / 0 / 0 / step]

5-804-167	Tray 4 Lift Motor (Up: 1sec)	ENG	[0 or 1 / 0 / 0 / step]
5-804-168	Tray 4 Lift Motor (Down: 1sec)	ENG	[0 or 1 / 0 / 0 / step]
5-804-169	Front End Fence SOL	ENG	[0 or 1 / 0 / 0 / step]
5-804-170	Rear End Fence SOL	ENG	[0 or 1 / 0 / 0 / step]
5-804-171	Back Fence Open/Close Motor	ENG	[0 or 1 / 0 / 0 / step]
5-804-200	Scanner fanmotor	ENG	[0 to 2 / 1 / 1 / step]
5-804-202	Scanner Lamp	ENG	[0 or 1 / 0 / 1 / step]
5-804-203	Scanner Motor	ENG	[0 or 1 / 1 / 1 / step]

ADF

6012	[1-Pass ADF OUTPUT Check]		
6-012-001	Pick-Up Motor Forward	ENG	[0 or 1 / 0 / 1 / step]
6-012-003	Feed Motor Forward	ENG	[0 or 1 / 0 / 1 / step]
6-012-005	Relay Motor Forward	ENG	[0 or 1 / 0 / 1 / step]
6-012-009	Exit Motor Forward	ENG	[0 or 1 / 0 / 1 / step]
6-012-010	Bottom Plate Motor For/Rev	ENG	[0 or 1 / 0 / 1 / step]
6-012-012	Stamp	ENG	[0 or 1 / 0 / 1 / step]
6-012-015	Pull-Out Motor Forward	ENG	[0 or 1 / 0 / 1 / step]
6-012-016	Middle Motor Forward	ENG	[0 or 1 / 0 / 1 / step]

2K/3K Finisher

6124	[OUTPUT Check: 2K/3K FIN]		
6-124-001	Entrance Transport Motor	ENG	[0 or 1 / 0 / 1 / step]

6-124-002	Horizontal Transport Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-003	Pre-Stack Transport Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-004	ITB Transport Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-005	Paper Exit Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-006	Upper Junction Solenoid	ENG	[0 or 1 / 0 / 1 / step]
6-124-007	TE Stack Plate Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-008	Paper Exit Open/Close Guide Plate Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-009	Punching Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-010	Punch Move Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-011	S-to-S Registration Detection Move Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-012	Lower Junction Solenoid Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-013	Jogger Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-014	Positioning Roller Rotation Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-015	Feed-out Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-016	Booklet Stapler Move Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-017	Corner Stapler Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-018	Booklet Stapler Jogger Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-019	Booklet Stapler Jog Solenoid Move Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-020	Booklet Stapler Standard Fence Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-021	Booklet Stapler Motor	ENG	[0 or 1 / 0 / 1 / step]

6-124-022	Dynamic Roller Transport Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-023	Folder Transport Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-025	Square-fold Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-026	Tray Lift Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-027	Shift Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-028	Front Shift Jogger Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-029	Rear Shift Jogger Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-030	Shift Jogger Retraction Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-031	Drag Roller Vibrating Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-032	LE Guide Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-033	Navigation LED (All)	ENG	[0 or 1 / 0 / 1 / step]
6-124-037	Positioning Roller Transport Motor	ENG	[0 or 1 / 0 / 1 / step]
6-124-038	Paper Guide Motor	ENG	[0 or 1 / 0 / 1 / step]

Finisher

6148	[Finisher Output Check: Fin 2]		
6-148-001	Main Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-002	Shift Tray Exit Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-003	Proof Junction Gate SOL	ENG	[0 or 1 / 0 / 1 / step]
6-148-004	Shift Relay Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-005	Jogger Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-006	Stapler Moving Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-007	Stapler Motor	ENG	[0 or 1 / 0 / 1 / step]

6-148-008	Punch Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-009	Stapler Solenoid	ENG	[0 or 1 / 0 / 1 / step]
6-148-010	Knock Roller Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-011	Stack Feed-out Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-012	Shift Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-013	Staple Lift Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-014	Staple Exit Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-015	Exit Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-016	Hold Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-017	Pre-stack Solenoid	ENG	[0 or 1 / 0 / 1 / step]
6-148-018	Guide Solenoid	ENG	[0 or 1 / 0 / 1 / step]
6-148-019	Front Hold Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-020	Rear Hold Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-021	Reverse Drive Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-022	Reverse Feed Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-023	Exit Jogger Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-024	Exit Jogger Release Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-025	Jogger Top Fence Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-026	Jogger Bottom Fence Motor	ENG	[0 or 1 / 0 / 1 / step]
6-148-032	Stapler Release Solenoid	ENG	[0 or 1 / 0 / 1 / step]

Slide Sort Tray

6251	[OUTPUT Check Slide Sort Tray]		
6-251-001	Transport Motor:Continuous	ENG	[0 or 1 / 0 / 1 / step]

6-251-002	Transport Moter:1 Op	ENG	[0 or 1 / 0 / 1 / step]
6-251-003	Shift Moter:1 Op	ENG	[0 or 1 / 0 / 1 / step]
6-251-004	Tray Lift Motor:Up	ENG	[0 or 1 / 0 / 1 / step]
6-251-005	Tray Lift Motor:Down	ENG	[0 or 1 / 0 / 1 / step]
6-251-006	Tray Lift Moter:1 Op	ENG	[0 or 1 / 0 / 1 / step]

Multi Folder

6310	[Output Check Multi Folder]		
6-310-001	Horizontal Transport Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-002	Top Tray Transport Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-003	Top Tray Exit Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-004	Dynamic Roller Transport Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-005	Registration Roller Transport Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-007	Entrance JG Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-008	1st Stopper Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-009	2nd Stopper Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-010	3rd Stopper Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-011	Dynamic Roller Lift Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-012	Registration Roller Release Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-013	Fold Plate Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-014	Jogger Fence Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-016	Direct-Send JG Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-017	FM6 Pawl Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-018	1st Fold Motor	ENG	[0 or 1 / 0 / 1 / step]

6-310-019	2nd Fold Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-020	Crease Motor	ENG	[0 or 1 / 0 / 1 / step]
6-310-021	Bypass JG Solenoid	ENG	[0 or 1 / 0 / 1 / step]
6-310-022	Exit JG Solenoid	ENG	[0 or 1 / 0 / 1 / step]
6-310-023	Top Tray JG Solenoid	ENG	[0 or 1 / 0 / 1 / step]
6-310-024	LE Stop Pawl Solenoid	ENG	[0 or 1 / 0 / 1 / step]
6-310-025	Reverse JG Solenoid	ENG	[0 or 1 / 0 / 1 / step]
6-310-026	Horizontal Exit Motor	ENG	[0 or 1 / 0 / 1 / step]

Print Post

6351	[Output Check Print Post]		
6-351-001	Vert Transport Motor	ENG	[0 or 1 / 0 / 1 / step]
6-351-002	Junction Gate SOL1	ENG	[0 or 1 / 0 / 1 / step]
6-351-003	Turn Gate SOL1	ENG	[0 or 1 / 0 / 1 / step]
6-351-004	Turn Gate SOL2	ENG	[0 or 1 / 0 / 1 / step]
6-351-005	Turn Gate SOL3	ENG	[0 or 1 / 0 / 1 / step]
6-351-006	Turn Gate SOL4	ENG	[0 or 1 / 0 / 1 / step]
6-351-007	Turn Gate SOL5	ENG	[0 or 1 / 0 / 1 / step]
6-351-008	Turn Gate SOL6	ENG	[0 or 1 / 0 / 1 / step]
6-351-009	Turn Gate SOL7	ENG	[0 or 1 / 0 / 1 / step]
6-351-010	Turn Gate SOL8	ENG	[0 or 1 / 0 / 1 / step]

3. Controller SP Mode Tables

Controller SP Tables-5

SP5-XXX (Mode)

5009	[Add Display Language]		
	<p>Adds language available in user choice. (Only the languages registered in the machine)</p> <p>Refer to the displayed language list to set in the way showed below.</p> <p>List Number Assigned Bit Switch</p> <p>No.1 to 8 BIT1 to 8 (SP5009-201)</p> <p>No.9 to 16BIT1 to 8 (SP5009-202)</p> <p>No.17 to 24BIT1 to 8 (SP5009-203)</p> <p>No.25 to 32BIT1 to 8 (SP5009-204)</p> <p>No.33 to 40BIT1 to 8 (SP5009-205)</p> <p>No.41 to 48BIT1 to 8 (SP5009-206)</p> <p>No.49 to 56BIT1 to 8 (SP5009-207)</p> <p>Example: To add American(No.3 in the list) or Czech (No.15)</p> <p>Turn Bit 3 of "SP5009-201" 0 to 1 for American.</p> <p>Turn Bit 7 of "SP5009-202" 0 to 1 for Czech.</p> <p>After setting, turn the main power switch off and on to make the setting valid.</p>		
5-009-201	1-8	*CTL	[0 to 255 / 0 / 1]
5-009-202	9-16	*CTL	[0 to 255 / 0 / 1]
5-009-203	17-24	*CTL	[0 to 255 / 0 / 1]
5-009-204	25-32	*CTL	[0 to 255 / 0 / 1]
5-009-205	33-40	*CTL	[0 to 255 / 0 / 1]
5-009-206	41-48	*CTL	[0 to 255 / 0 / 1]
5-009-207	49-56	*CTL	[0 to 255 / 0 / 1]

5024	[mm/inch Display Selection]		
	Display units (mm or inch) for custom paper sizes.		
5-024-001	0:mm 1:inch	*CTL	[0 or 1 / 1(NA), 0(Others) / 1] 0: mm 1: inch

5045	[Accounting counter]		
	5-045-001	Counter Method	*CTL

5047	[Paper Display]		
	5-047-001	Backing Paper	*CTL

5055	[Display IP Address]		
	5-055-001	-	*CTL

5062	[Parts Replacement Alert Display]			
	5-062-001	Developer	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
	5-062-002	Fuser Unit:Fusing Roller	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display

5-062-003	Fuser Unit:Pressure Roller	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-004	Fuser Unit:FusingR:Bearings	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-005	Fuser Unit:PressR:Bearings	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-006	Hot Roller Strippers	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-007	Cleaning Roller	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-008	Cleaning Roller Bearings	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-009	Web Roll	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-010	Web Cleaning Roller	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-011	Development Filter	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-012	Toner Recycling Unit	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display

5-062-013	Pressure Release Filter	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-014	Charge Corona Wire	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-015	Grid Plate	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-016	Cleaning Pad	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-017	Cleaning Blead	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-018	Cleaning Brush	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-019	Transfer Belt	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-020	Transfer Belt Cleaning Blade	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-022	ADF Pick-up Roller	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-023	ADF Feed Belt	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display

5-062-024	ADF Separation Roller	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-025	Tray1:Pickup Roller	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-026	Tray1:Feed Roller	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-027	Tray1:Separate Roller	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-028	Tray2:Pickup Roller	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-029	Tray2:Feed Roller	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-030	Tray2:Separate Roller	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-031	Feed Roller-Tray3	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-032	Pick-up Roller-Tray3	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-033	Separation Roller-Tray3	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display

5-062-034	Feed Roller-Tray4	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-035	Pick-up Roller-Tray4	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-036	Separation Roller-Tray4	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-037	Feed Roller-LCT	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-038	Pick-up Roller-LCT	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-039	Separation Roller-LCT	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-040	Feed Belt Cover feeder	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-041	Pick-up Roller Cover feeder	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-042	Separation Roller Cover feeder	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-044	Thermistor Fusing unit Rearr	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display

5-062-045	Thermistor Fusing unit Center	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-046	Dust Filter	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-047	Main Tray(Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-048	Main Tray(Custom 2)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-049	Main Tray(Custom 3)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-050	Main Tray(Custom 4)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-051	Paper Tray1 (Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-052	Paper Tray1 (Custom 2)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-053	Paper Tray2 (Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-054	Paper Tray2 (Custom 2)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display

5-062-055	Paper Tray3 (Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-056	Paper Tray3 (Custom 2)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-057	Paper Tray4 (Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-058	Paper Tray4 (Custom 2)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-059	LCT(Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-060	LCT(Custom 2)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-063	Interposer(Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-064	Interposer(Custom 2)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-065	Wast Toner Bottle	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display
5-062-066	Ozon Filter (Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display

5066	[PM Parts Display]		
5-066-001	-	*CTL	[0 or 1 / 0 / 1] 0: Not display 1: Display

5067	[Part Replacement Operation Type]		
5-067-001	Developer	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-002	Fuser Unit:Fusing Roller	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-003	Fuser Unit:Pressure Roller	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-004	Fuser Unit:FusingR:Bearings	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-005	Fuser Unit:PressR:Bearings	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-006	Hot Roller Strippers	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-007	Cleaning Roller	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-008	Cleaning Roller Bearings	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User

5-067-009	Web Roll	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-010	Web Cleaning Roller	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-011	Development Filter	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-012	Toner Recycling Unit	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-013	Pressure Release Filter	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-014	Charge Corona Wire	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-015	Grid Plate	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-016	Cleaning Pad	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-017	Cleaning Bleed	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-018	Cleaning Brush	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User

5-067-019	Transfer Belt	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-020	Transfer Belt Cleaning Blade	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-022	ADF Pick-up Roller	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-023	ADF Feed Belt	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-024	ADF Separation Roller	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-025	Tray1:Pickup Roller	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-026	Tray1:Feed Roller	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-027	Tray1:Separate Roller	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-028	Tray2:Pickup Roller	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-029	Tray2:Feed Roller	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User

5-067-030	Tray2:Separate Roller	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-031	Feed Roller-Tray3	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-032	Pick-up Roller-Tray3	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-033	Separation Roller-Tray3	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-034	Feed Roller-Tray4	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-035	Pick-up Roller-Tray4	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-036	Separation Roller-Tray4	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-037	Feed Roller-LCT	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-038	Pick-up Roller-LCT	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-039	Separation Roller-LCT	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User

5-067-040	Feed Belt Cover feeder	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-041	Pick-up Roller Cover feeder	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-042	Separation Roller Cover feeder	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-044	Thermistor Fusing unit Rearr	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-045	Thermistor Fusing unit Center	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-046	Dust Filter	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-047	Main Tray(Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-048	Main Tray(Custom 2)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-049	Main Tray(Custom 3)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-050	Main Tray(Custom 4)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User

5-067-051	Paper Tray1 (Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-052	Paper Tray1 (Custom 2)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-053	Paper Tray2 (Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-054	Paper Tray2 (Custom 2)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-055	Paper Tray3 (Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-056	Paper Tray3 (Custom 2)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-057	Paper Tray4 (Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-058	Paper Tray4 (Custom 2)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-059	LCT(Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-060	LCT(Custom 2)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User

5-067-063	Interposer(Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-064	Interposer(Custom 2)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-065	Wast Toner Bottle	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User
5-067-066	Ozon Filter (Custom 1)	*CTL	[0 or 1 / 0 / 1] 0: Service 1: User

5071	[Set Bypass Paper Size Display]		
5-071-001	-	CTL	[0 or 1 / 0 / 1] 0: Off 1: On

5074	[Home Screen Login]		
5-074-002	Login Setting	*CTL	[0 to 255 / 0 / 1]
5-074-050	Show Home Edit Menu	*CTL	[0 to 2 / 0 / 1]
5-074-091	Function Setting	*CTL	[0 to 2 / 0 / 1] 0: Function disable 1: SDK application 2: Legacy application (reserved)
5-074-092	Product ID	*CTL	[0x00000000 to 0xffffffff / 0 / 1]
5-074-093	Application Screen ID	*CTL	[0 to 255 / 0 / 1]

5075	[USB Keyboard]		
-------------	-----------------------	--	--

5-075-003	Display setting	*CTL	[0 or 1 / 0 / 1] 0: Disable 1: Enable
-----------	-----------------	------	---

5081	[ServiceSP Entry Code Setting]		
	DFU		
5-081-001	-	-	-

5083	[LED Light Switch Setting]		
5-083-001	Toner Near End	*CTL	[0 or 1 / 0 / 1] 0: OFF 1: ON
5-083-002	Waste Toner Near End	*CTL	[0 or 1 / 0 / 1]

5101	[Copy Auto Clear Setting]		
5-101-20 2	Auto Clear Timer Setting (0:ON 1:OFF)	*CTL	[0 or 1 / 0 / 1]

5102	[AutoDetect]		
5-102-20 3	HumanDetectSetting	*CTL	[0 or 1 / 0 / 1]

5112	[Non-Std. Paper Sel.]		
5-112-001	(0:OFF 1:ON)	*CTL	[0 or 1 / 0 / 1] 0: Not installed 1: Installed (scanning accounting)

5113	[Optional Counter Type]		
5-113-001	Default Optional Counter Type	*CTL	[0 to 12 / 0 / 1] 0: Not installed 1: Installed (scanning accounting)

5-113-002	External Optional Counter Type	*CTL	[0 to 3 / 0 / 1] 0: Not installed 1: Installed (scanning accounting)
5114	[Optional Counter I/F]		
5-114-001	MF Key Card Extension	*CTL	[0 or 1 / 0 / 1] 0: Not installed 1: Installed (scanning accounting)
5118	[Disable Copying]		
5-118-001	-	*CTL	[0 or 1 / 0 / 1] 0: Not disabled 1: Disabled
5120	[Mode Clear Opt. Counter Removal]		
5-120-001	0:Yes 1:StandBy 2:No	*CTL	[0 to 2 / 0 / 1] 0: Yes (removed) 1: Standby (installed but not used) 2: No (not removed)
5121	[Counter Up Timing]		
5-121-001	0:Feed 1:Exit	*CTL	[0 or 1 / 0 / 1] 0: Feed 1: Exit
5127	[APS OFF Mode]		
5-127-001	-	*CTL	[0 or 1 / 0 / 1] 0: Not disabled 1: Disabled
5150	[Length Setting]		

5-150-001	Bypass(0:OFF 1:Long)	CTL	[0 or 1 / 0 / 1] 0: OFF 1: ON
-----------	----------------------	-----	-------------------------------------

5162	[App. Switch Method]		
5-162-001	-	*CTL	[0 or 1 / 0 / 1] 0: Soft Key Set 1: Hard Key Set

5167	[Fax Printing Mode at Optional Counter Off]		
5-167-001	-	*CTL	[0 or 1 / 0 / 1] 0: Automatic printing 1: No automatic printing

5169	[CE Login]		
5-169-001	-	*CTL	[0 or 1 / 0 / 1] 0: Disabled 1: Enabled

5182	[HDD Pages Mgmt]		
5-182-001	Release LS Limit	*CTL	[0 or 1 / 0 / 0]

5188	[Copy Nv Version]		
5-188-001	-	*CTL	[- / - / -]

5191	[Mode Set]		
5-191-001	Power Str Set	*CTL	[0 or 1 / 1 / 1] 0: OFF 1: ON

5195	[Limitless SW]		
-------------	-----------------------	--	--

5-195-001	-	*CTL	[0 or 1 / 0 / 1] 0: Productivity Precede 1: Use paper up
-----------	---	------	--

5199	[Paper Exit After Staple End]		
5-199-001	Staple(1:Without 2:After 0:Auto)	CTL	[0 to 2 / 0 / 1]
5-199-002	Saddle(1:Without 2:After 0:Auto)	CTL	[0 or 1 / 0 / 1]

5212	[Page Numbering]		
5-212-003	Duplex Printout Left/Right Position of Left/Right Facing	*CTL	[-1000 to 1000 / 0 / 0.01mm/ step]
5-212-004	Duplex Printout Top/Bottom Position of Left/Right Facing	*CTL	[-1000 to 1000 / 0 / 0.01mm/ step]
5-212-018	Duplex Printout Left/Right Position of Top/Bottom Facing	*CTL	[-1000 to 1000 / 0 / 0.01mm/ step]
5-212-019	Duplex Printout Top/Bottom Position of Top/Bottom Facing	*CTL	[-1000 to 1000 / 0 / 0.01mm/ step]

5227	[Page numbering]		
5-227-201	Allow Page No. Entry	*CTL	[2 to 9 / 9 / 1]
5-227-202	Zero Surplus Stting	*CTL	[0 or 1 / 0 / 1] 0:OFF 1:ON

5302	[Set Time]		
	<p>Adjusts the RTC (real time clock) time setting for the local time zone. Examples: For Japan (+9 GMT), enter 540 (9 hours x 60 min.) DOM: +540 (Tokyo) NA: -300 (New York) EU: + 60 (Paris) CH: +480 (Beijing) TW: +480 (Taipei) AS: +480 (Hong Kong)</p>		
5-302-002	Time Difference	*CTL	[-1440 to 1440 / - / 1 min / step]
5305	[Auto Off Set]		
	5-305-101	Auto Off Limit Set	*CTL [0 or 1 / 0 / 1]
5307	[Daylight Saving Time]		
	5-307-001	Setting	*CTL [0 or 1 / - / 1] 0: Disabled 1: Enabled (Default) 1: NA and EUR 0: ASIA and others
<p>Enables or disables the summer time mode.</p> <p>Note</p> <ul style="list-style-type: none"> Make sure that both SP5-307-3 and -4 are correctly set. Otherwise, this SP is not activated even if this SP is set to "1". 			

5-307-00 3	Rule Set(Start)	*CTL	[0 to 0xffffffff / - / 1] (Default) NA: 0x03200210 EUR: 0x03500010 ASIA: 0x10500010 Other: 0x00000000
<p>Specifies the start setting for the summer time mode.</p> <p>There are 8 digits in this SP. For months 1 to 9, the "0" cannot be input in the first digit, so the eight-digit setting for -2 or -3 becomes a seven-digit setting.</p> <p>1st and 2nd digits: The month. [1 to 12] 3rd digit: The week of the month. [1 to 5] 4th digit: The day of the week. [0 to 6 = Sunday to Saturday] 5th and 6th digits: The hour. [00 to 23] 7th digit: The length of the advanced time. [0 to 9 / 1 hour] 8th digit: The length of the advanced time. [0 to 5 / 10 minutes]</p> <ul style="list-style-type: none"> • The digits are counted from the left. • Make sure that SP5-307-1 is set to "1". 			
5-307-00 4	Rule Set (End)	-	[0 to 0xffffffff / - / 1] (Default) NA: 0x11100200 EUR: 0x10500100 ASIA: 0x03100000 Other: 0x00000000
<p>Specifies the end setting for the summer time mode.</p> <p>There are 8 digits in this SP.</p> <p>1st and 2nd digits: The month. [1 to 12] 3rd digit: The week of the month. [0 to 5] 4th digit: The day of the week. [0 to 7 = Sunday to Saturday] 5th and 6th digits: The hour. [00 to 23] The 7th and 8 digits must be set to "00".</p> <ul style="list-style-type: none"> • The digits are counted from the left. • Make sure that SP5-307-1 is set to "1". 			

5401	[Access Control]		
5-401-10 3	Default Document ACL	CTL	[0 to 3 / 0 / 1]
5-401-10 4	Authentication Time	CTL	[0 to 255 / 0 / 1 sec / step]
5-401-16 2	Extend Certification Detail	CTL	[0 to 0xff / 0 / 1]
5-401-20 0	SDK1 UniqueID	CTL	[0 to 0xFFFFFFFF / 0 / 1]
5-401-20 1	SDK1 Certification Method	CTL	[0 to 0xFF / 0 / 1]
5-401-21 0	SDK2 UniqueID	CTL	[0 to 0xFFFFFFFF / 0 / 1]
5-401-21 1	SDK2 Certification Method	CTL	[0 to 0xFF / 0 / 1]
5-401-22 0	SDK3 UniqueID	CTL	[0 to 0xFFFFFFFF / 0 / 1]
5-401-22 1	SDK3 Certification Method	CTL	[0 to 0xFF / 0 / 1]
5-401-23 0	SDK Certification Device	*CTL	[0 to 0xFF / 0 / 1] 0-1: SDK authentication available 0-0: Disable all functions 1-1: SKB Display 1-0: Disable 2-1: Administrator login 2-0: Disable 3 to 7-0: Reserved (set "0" only)

5-401-24 0	Detail Option	*CTL	[0 to 0xFF / 0 / 1]
	0: Logout confirm option -1: ON, 0: OFF 2 to 1: Auto-logout timer(retry timer) -11: 30sec, 10: 20sec, 01: 10sec, 00: 60sec 3: personal authority / Group authority and operation -1: ON, 0: OFF		

3

5402	[Access Control]		
5-402-101 to 5-402-130	SDKJ1 Limit Setting - SDKJ30 Limit Setting	CTL	[0 to 0xFF / 0 / 1] Bit0: SDKJ Authentication 0: Panel Type 1: Remote Type Bit1: Using user code setup 0: OFF, 1: ON Bit2: Using key-counter setup 0: OFF, 1: ON Bit3: Using external billing device setup 0: OFF, 1: ON Bit4: Using extended external billing devicesetup 0: OFF, 1: ON Bit5, Bit6: Not used Bit7: Using extended function J limit users 0: OFF, 1: ON
5-402-131 to 5-402-170	SDKJ1 ProductID – SDKJ30 ProductID	CTL	[0 to 0xFFFFFFFF / 0 / 1]

5404	[User Code Count Clear]		
-------------	--------------------------------	--	--

5-404-001	User Code Count Clear	*CTL	[- / - / -] [Execute]
5-404-101	User Code Count Clear Permit Setting	*CTL	[0 or 1 / 0 / 1]

5411	[LDAP-Certification]		
5-411-004	Easy Certification	*CTL	[0 or 1 / 1 / 1] 1: On 0: Off
5-411-005	Password Null Not Permit	*CTL	[0 or 1 / 1 / 1] 0: Password NULL not permitted. 1: Password NULL permitted.
5-411-006	Detail Option	*CTL	[0 to 0xff / 0 / 1] 0: OFF 1: ON

5412	[Krb-Certification]		
5-412-100	Encrypt Mode	CTL	[0 to 0xFF / 0x1F / 1]

5413	[Lockout Setting]		
5-413-001	Lockout On/Off	*CTL	[0 or 1 / 0 / 1] 0: Off 1: On
5-413-002	Lockout Threshold	*CTL	[1 to 10 / 5 / 1]
5-413-003	Cancellation On/Off	*CTL	[0 or 1 / 0 / 1] 0: Off (no wait time, lockout not cancelled) 1: On (system waits, cancels lockout if correct user ID and password are entered).
5-413-004	Cancellation Time	*CTL	[1 to 9999 / 60 / 1 min]

5414	[Access Mitigation]		
5-414-001	Mitigation On/Off	*CTL	[0 or 1 / 0 / 1] 0: OFF 1: ON
5-414-002	Mitigation Time	*CTL	[0 to 60 / 15 / 1 min / step]

5415	[Password Attack]		
5-415-001	Permissible Number	*CTL	[0 to 100 / 30 / 1 / step]
5-415-002	Detect Time	*CTL	[1 to 10 / 5 / 1 / step]

5416	[Access Information]		
5-416-001	Access User Max Num	*CTL	[50 to 200 / 200 / 1 / step]
5-416-002	Access Password Max Num	*CTL	[50 to 200 / 200 / 1 / step]
5-416-003	Monitor Interval	*CTL	[1 to 10 / 3 / 1 / step]

5417	[Access Attack]		
5-417-001	Access Permissible Number	*CTL	[0 to 500 / 100 / 1 / step]
5-417-002	Attack Detect Time	*CTL	[10 to 30 / 10 / 1 sec / step]
5-417-003	Productivity Fall Wait	*CTL	[0 to 9 / 3 / 1 sec / step]
5-417-004	Attack Max Num	*CTL	[50 to 200 / 200 / 1 / step]

5420	[User Authentication]		
5-420-001	Copy	*CTL	[0 or 1 / 0 / 1] 0: On 1: Off
5-420-011	DocumentServer	*CTL	[0 or 1 / 0 / 1] 0: On 1: Off

5-420-021	Fax	*CTL	[0 or 1 / 0 / 1] 0: On 1: Off
5-420-031	Scanner	*CTL	[0 or 1 / 0 / 1] 0: On 1: Off
5-420-041	Printer	*CTL	[0 or 1 / 0 / 1] 0: On 1: Off
5-420-051	SDK1	*CTL	[0 or 1 / 0 / 1] 0: ON 1: OFF
5-420-061	SDK2	*CTL	
5-420-071	SDK3	*CTL	
5-420-081	Browser	*CTL	[0 or 1 / 0 / 1] 0: ON 1: OFF

5430	[Auth Dialog Message Change]		
5-430-001	Message Change On/Off	CTL	[0 or 1 / 1 / 1]
5-430-002	Message Text Download	CTL	[0 or 1 / 1 / 1]
5-430-003	Message Text ID	CTL	[0 or 1 / 1 / 1]

5431	[External Auth User Preset]		
5-431-010	Tag	CTL	[0 or 1 / 1 / 1]
5-431-011	Entry	CTL	[0 or 1 / 1 / 1]
5-431-012	Group	CTL	[0 or 1 / 1 / 1]
5-431-020	Mail	CTL	[0 or 1 / 1 / 1]
5-431-030	Fax	CTL	[0 or 1 / 1 / 1]
5-431-031	FaxSub	CTL	[0 or 1 / 1 / 1]

5-431-032	Folder	CTL	[0 or 1 / 1 / 1]
5-431-033	ProtectCode	CTL	[0 or 1 / 1 / 1]
5-431-034	SmtplAuth	CTL	[0 or 1 / 1 / 1]
5-431-035	LdapAuth	CTL	[0 or 1 / 1 / 1]
5-431-036	Smb Ftp Fldr Auth	CTL	[0 or 1 / 1 / 1]
5-431-037	AcntAcl	CTL	[0 or 1 / 1 / 1]
5-431-038	DocumentAcl	CTL	[0 or 1 / 1 / 1]
5-431-040	CertCrypt	CTL	[0 or 1 / 0 / 1]
5-431-050	UserLimitCount	CTL	[0 or 1 / 1 / 1]

5481	[Authentication Error Code]		
5-481-001	System Log Disp	*CTL	[0 or 1 / 0 / 1] 0: Off 1: On
5-481-002	Panel Disp	*CTL	[0 or 1 / 1 / 1] 1: On 0: Off

5490	[MF KeyCard (Japan only)]		
5-490-001	Job Permit Setting	*CTL	[0 or 1 / 0 / 1] 0: Disabled. Cancels operation without a user code. 1: Enabled. Allows operation without a user code.

5491	[Optional Counter]		
5-491-001	Detail Option	*CTL	[0 to 0xff / 0 / 1]

5501	[PM Alarm]		
-------------	-------------------	--	--

5-501-001	PM Alarm Level	*CTL	[0 to 9999 / 0 / 1] 0: Alarm off 1 to 9999: Alarm goes off when Value (1 to 9999) x 1000 > PM counter
-----------	----------------	------	---

5504	[Jam Alarm]		
5-504-001	-	*CTL	[0 to 3 / 3 / 1] 0: Z 1: L 2: M 3: H
5-504-002	Threshold	*CTL	[1 to 99 / 10 / 1]

5505	[Error Alarm]		
5-505-001	-	*CTL	MP 6503 SP: [0 to 255 / 10 / 1K] MP 7503 SP: [0 to 255 / 14 / 1K] MP 9003 SP: [0 to 255 / 17 / 1K] 0: Alarm Off
5-505-002	Threshold	*CTL	[1 to 99 / 7 / 1]

5507	[Supply/CC Alarm]		
5-507-001	Paper Supply Alarm	*CTL	[0 or 1 / 0 / 1] 0: OFF 1: ON
5-507-002	Staple Supply Alarm	*CTL	[0 or 1 / 0 (Japan), 1 (Others) / 1] 0: OFF 1: ON

5-507-003	Toner Supply Alarm	*CTL	[0 or 1 / 0 (Japan), 1 (Others) / 1] 0: OFF 1: ON
5-507-080	Toner Call Timing	*CTL	[0 or 1 / 0 / 1] 0: Toner bottle replacement 1: Less than toner threshold
5-507-081	Toner Call Threshold:Bk	CTL	[10 to 90 / 50 / 10 % / step]
5-507-128	Interval :Others	*CTL	[250 to 10000 / 1000 / 1]
5-507-132	Interval :A3	*CTL	[250 to 10000 / 1000 / 1]
5-507-133	Interval :A4	*CTL	[250 to 10000 / 1000 / 1]
5-507-134	Interval :A5	*CTL	[250 to 10000 / 1000 / 1]
5-507-141	Interval :B4	*CTL	[250 to 10000 / 1000 / 1]
5-507-142	Interval :B5	*CTL	[250 to 10000 / 1000 / 1]
5-507-160	Interval :DLT	*CTL	[250 to 10000 / 1000 / 1]
5-507-164	Interval: LG	*CTL	[250 to 10000 / 1000 / 1]
5-507-166	Interval :LT	*CTL	[250 to 10000 / 1000 / 1]
5-507-172	Interval :HLT	*CTL	[250 to 10000 / 1000 / 1]

5508	[CC Call]		
5-508-001	Jam Remains	*CTL	[0 or 1 / 1 / 1] 0: Disable 1: Enable
5-508-002	Continuous Jams	*CTL	[0 or 1 / 1 / 1] 0: Disable 1: Enable
5-508-003	Continuous Door Open	*CTL	[0 or 1 / 1 / 1] 0: Disable 1: Enable

5-508-011	Jam Detection: Time Length	*CTL	[3 to 30 / 10 / 1]
5-508-012	Jam Detection: Continuous Count	*CTL	[2 to 10 / 5 / 1]
5-508-013	Door Open: Time Length	*CTL	[3 to 30 / 10 / 1]

5513	[PartsAlarmlevelCount]		
5-513-001	Normal	*CTL	[1 to 9999 / 300 / 1]
5-513-002	Df	*CTL	[1 to 9999 / 300 / 1]

5514	[PartsAlarmlev]		
5-514-001	Normal	*CTL	[0 or 1 / 1 / 1]
5-514-002	Df	*CTL	[0 or 1 / 0 / 1]

5515	[SC/Alarm Setting]		
5-515-001	SC Call	*CTL	[0 or 1 / 1 / 1] 0: OFF 1: ON
5-515-002	Service Parts Near End Call	*CTL	
5-515-003	Service Parts End Call	*CTL	
5-515-004	User Call	*CTL	
5-515-006	Communication Test Call	*CTL	
5-515-007	Machine Information Notice	*CTL	
5-515-008	Alarm Notice	*CTL	
5-515-009	Non Genuine Tonner Ararm	*CTL	
5-515-010	Supply Automatic Ordering Call	*CTL	
5-515-011	Supply Management Report Call	*CTL	
5-515-012	Jam/Door Open Call	*CTL	
5-515-050	Timeout:Manual Call	*CTL	

5-515-051	Timeout:Other Call	*CTL	[1 to 255 / 10 / 1 min / step]
-----------	--------------------	------	--------------------------------

5517	[Get Machine Information]		
5-517-061	AutoDiscovery Execution Setting	*CTL	[0 or 1 / 0 / 1]
5-517-062	AutoDiscovery Execution Interval	*CTL	[0 or 1 / 0 / 1]
5-517-063	AutoDiscovery Execution Weekday	*CTL	[0 to 6 / 0 / 1]
5-517-064	AutoDiscovery Execution Hour	*CTL	[0 to 23 / 0 / 1]
5-517-065	AutoDiscovery Execution Minute	*CTL	[0 to 59 / 0 / 1]
5-517-066	AutoDiscovery SNMP Community Name	*CTL	[- / - / -]

5728	[Network Setting]		
5-728-001	NAT Machine Port1	CTL	[1 to 65535 / 49101 / 1]
5-728-002	NAT UI Port1	CTL	[1 to 65535 / 55101 / 1]
5-728-003	NAT Machine Port2	CTL	[1 to 65535 / 49102 / 1]
5-728-004	NAT UI Port2	CTL	[1 to 65535 / 55102 / 1]
5-728-005	NAT Machine Port3	CTL	[1 to 65535 / 49103 / 1]
5-728-006	NAT UI Port3	CTL	[1 to 65535 / 55103 / 1]
5-728-007	NAT Machine Port4	CTL	[1 to 65535 / 49104 / 1]
5-728-008	NAT UI Port4	CTL	[1 to 65535 / 55104 / 1]
5-728-009	NAT Machine Port5	CTL	[1 to 65535 / 49105 / 1]
5-728-010	NAT UI Port5	CTL	[1 to 65535 / 55105 / 1]
5-728-011	NAT Machine Port6	CTL	[1 to 65535 / 49106 / 1]
5-728-012	NAT UI Port6	CTL	[1 to 65535 / 55106 / 1]

5-728-013	NAT Machine Port7	CTL	[1 to 65535 / 49107 / 1]
5-728-014	NAT UI Port7	CTL	[1 to 65535 / 55107 / 1]
5-728-015	NAT Machine Port8	CTL	[1 to 65535 / 49108 / 1]
5-728-016	NAT UI Port8	CTL	[1 to 65535 / 55108 / 1]
5-728-017	NAT Machine Port9	CTL	[1 to 65535 / 49109 / 1]
5-728-018	NAT UI Port9	CTL	[1 to 65535 / 55109 / 1]
5-728-019	NAT Machine Port10	CTL	[1 to 65535 / 49110 / 1]
5-728-020	NAT UI Port10	CTL	[1 to 65535 / 55110 / 1]
5-728-101	PacketCapture	CTL	[0 to 1 / 0 / 1]
5-728-102	PacketCapture:mode	CTL	[0 to 1 / 0 / 1]
5-728-103	PacketCapture:interface	CTL	[0 to 1 / 0 / 1]
5-728-104	PacketCapture:length	CTL	[54 to 65535 / 128 / 1]
5-728-105	PacketCapture:broadcast	CTL	[0 to 1 / 0 / 1]
5-728-106	PacketCapture:specify port	CTL	[0 to 1 / 0 / 1]
5-728-107	PacketCapture:portnumber	CTL	[0 to 65535 / 0 / 1]
5-728-108	PacketCapture:time	CTL	[0 to 0xffffffff / 0 / 1]

5730	[Extended Function Setting]		
	-		
5-730-001	JavaTM Platform setting	*CTL	[0 or 1 / 0 (Japan), 1 (Others) / 1] 0: Disable, 1: Enable
5-730-010	Expiration Prior Alarm Set	*CTL	[0 to 999 / 20 / 1 day / step]

5731	[Counter Effect]		
	This SP is used only for DOM machines.		
5-731-001	Change MK1 Cnt (Paper->Combine)	*CTL	[0 or 1 / 0 / 1]

5734	[PDF Setting]		
5-734-001	PDF/A Fixed	*CTL	[0 or 1 / 0 / 1]

5741	[Node Authentication Timeout]		
5-741-001	-	*CTL	[1 to 255 / 60 / 1 sec / step]

5745	[DeemedPowerConsumption]		
5-745-211	Controller Standby	*CTL	[0 to 9999 / 0 / 1]
5-745-212	STR	*CTL	[0 to 9999 / 0 / 1]
5-745-213	Main Power Off	*CTL	[0 to 9999 / 0 / 1]
5-745-214	Scanning and Printing	*CTL	[0 to 9999 / 0 / 1]
5-745-215	Printing	*CTL	[0 to 9999 / 0 / 1]
5-745-216	Scanning	*CTL	[0 to 9999 / 0 / 1]
5-745-217	Engine Standby	*CTL	[0 to 9999 / 0 / 1]
5-745-218	Low Power Consumption	*CTL	[0 to 9999 / 0 / 1]
5-745-219	Silent condition	*CTL	[0 to 9999 / 0 / 1]
5-745-220	Heater Off	*CTL	[0 to 9999 / 0 / 1]

5748	[OpePanel Setting]		
5-748-101	Op Type Action Setting	CTL	[0 to 255 / 0 / 1] • bit0 0: Normal operation panel 1: Smart operation panel
5-748-201	Cheetah Panel Connect Setting	CTL	[0 or 1 / 0 / 0] 0: OFF 1: ON

5749	[Import/Export]		
-------------	------------------------	--	--

5-749-001	Export	CTL	[- / - / -] Target: System, Printer, Fax, Scanner Option: Unique, Secret Copy config: Encryption, Encryption key(if selected) [Execute]
5-749-101	Import	CTL	[- / - / -] Option: Unique Copy config: Encryption, Encryption key(if selected) [Execute]

5751	[Key Event Encryption Setting]		
5-751-001	Password	CTL	[0 to 255 / 0 / 1]

5752	[Copy:WebAPI Setting]			
5-752-001	Copy FlairAPI Setting	*CTL	* see BitSwitch below:	
Bit	Setting	meanings		Description
		0	1	
bit 0	Start of FlairAPI Server	Off (Do not Start)	On (Start)	Sets whether to start exclusive FlairAPI http server. If it is 0, scanning FlairAPI function and simple UI function will be disabled. The machine installed Android operating panel option, set "1", others set "0".
bit 1	Access permission of FlairAPI from outside of the machine	Disabled	Enabled	If it is "0", accessing is limited from the machine only, such as operating panel, SDK/J, MFP browsers etc... If it is "1", accessing is allowed from outside of FlairAPI such as PC, Remote UI, IT-Box etc...

bit 2	Reserved	-	-	-
bit 3	Reserved	-	-	-
bit 4	Simple UI Function	Disabled	Enabled	If it is "1", the machine can be used Scanner Simple UI. If it is "0", requesting URL of Simple UI returns "404 Not Found"
bit 5	Accessing permission of Simple UI from outside of the machine	Disabled	Enabled	If it is "0", accessing is limited from the machine only (operating panel and MFP browser). If it is "1", accessing is allowed from outside of Simple UI such as PC, mobile devices, and so on.
bit 6	Reserved	-	-	-
bit 7	Reserved	-	-	-

5755	[Display Setting]			
5-755-001	Disp Administrator Password Change Scrn	CTL	[- / - / -]	
5-755-002	Hide Administrator Password Change Scrn	CTL	[- / - / -]	

5758	[RemoteUI Setting]			
5-758-001	Authentication	*CTL	[0 or 1 / 0 / 1]	

5759	[Machine Limit Count]			
5-759-001	Machine Limit Count Setting	*CTL	[0 or 1 / 0 / 1]	
5-759-051	Limit Count	*CTL	[0 to 999999999 / 0 / 1]	

5761	[SmartOperationPanel Setting]			
5-761-001	Restore the default Home screen	*CTL	[0 to 255 / 0 / 1]	

5801	[Memory Clear]		
5-801-001	All Clear	CTL	[- / - / -] [Execute]
5-801-003	SCS	CTL	[- / - / -] [Execute]
5-801-004	IMH Memory Clr	CTL	[- / - / -] [Execute]
5-801-005	Mcs	CTL	[- / - / -] [Execute]
5-801-006	Copier Application	CTL	[- / - / -] [Execute]
5-801-007	Fax Application	CTL	[- / - / -] [Execute]
5-801-008	Printer Application	CTL	[- / - / -] [Execute]
	The following service settings: <ul style="list-style-type: none"> • Bit switches • Gamma settings (User & Service) • Toner Limit The following user settings: <ul style="list-style-type: none"> • Tray Priority • Menu Protect • System Setting except for setting of Energy Saver • I/F Setup (I/O Buffer and I/O Timeout) • PCL Menu 		
5-801-009	Scanner Application	CTL	[- / - / -] [Execute]
5-801-010	Web Service	CTL	[- / - / -] [Execute]

5-801-011	NCS	CTL	[- / - / -] [Execute]
5-801-012	R-Fax	CTL	[- / - / -] [Execute]
5-801-014	Clear DCS Setting	CTL	[- / - / -] [Execute]
5-801-015	Clear UCS Setting	CTL	[- / - / -] [Execute]
5-801-016	MIRS Memory Clr	CTL	[- / - / -] [Execute]
5-801-017	CCS	CTL	[- / - / -] [Execute]
5-801-018	SRM Memory Clr	CTL	[- / - / -] [Execute]
5-801-019	LCS Memory Clr	CTL	[- / - / -] [Execute]
5-801-020	Web Uapli	CTL	[- / - / -] [Execute]
5-801-021	ECS	CTL	[- / - / -] [Execute]
5-801-023	AICS	CTL	[- / - / -] [Execute]
5-801-025	Websys	CTL	[- / - / -] [Execute]
5-801-026	PLN	CTL	[- / - / -] [Execute]
5-801-027	SAS	CTL	[- / - / -] [Execute]

5-801-028	Rest WebService	CTL	[- / - / -] [Execute]
-----------	-----------------	-----	--------------------------

5812	[Service Tel. No. Setting]		
5-812-001	Service	*CTL	[up to 20 / - / 0]
5-812-002	Facsimile	*CTL	[up to 20 / - / 0]
5-812-003	Supply	*CTL	[up to 20 / - / 0]
5-812-004	Operation	*CTL	[up to 20 / - / 0]

5816	[Remote Service]		
5-816-001	I/F Setting	*CTL	[0 to 2 / 2 / 1] 0: Remote service off 1: CSS remote service on 2: NRS remote service on
5-816-002	CE Call	*CTL	[0 or 1 / 0 / 1] 0: Start of the service 1: End of the service
5-816-003	Function Flag	*CTL	[0 or 1 / 0 / 1] 0: Disabled 1: Enabled
5-816-007	SSL Disable	*CTL	[0 or 1 / 0 / 1] 0: Yes. SSL not used. 1: No. SSL used.
5-816-008	RCG Connect Timeout	*CTL	[1 to 90 / 30 / 1 second / step]
5-816-009	RCG Write Timeout	*CTL	[0 to 100 / 60 / 1 second / step]
5-816-010	RCG Read Timeout	*CTL	[0 to 100 / 60 / 1 second / step]
5-816-011	Port 80 Enable	*CTL	[0 or 1 / 0 / 1] 0: No. Access denied 1: Yes. Access granted.

5-816-013	RFU Timing	*CTL	[0 or 1 / 1 / 1] 0: Any status of a target machine 1: Sleep or panel off mode only
5-816-014	RCG Error Cause	CTL	[0 to 2 / 0 / 1] 0: Initial state, normal condition 1: Error
5-816-021	RCG-C Registered	*CTL	[0 or 1 / 0 / 1] 0: Installation not completed 1: Installation completed
5-816-023	Connect Type(N/M/3G)	*CTL	[0 to 2 / 0 / 1] 0: internet connection 1: Dial-up connection
5-816-061	Cert Expire Timing	*CTL	[0 to 0 / 0 / 1]
5-816-062	Use Proxy	*CTL	[0 or 1 / 0 / 1] 0: Not use 1: Use
5-816-063	Proxy Host	*CTL	[- / - / -]
5-816-064	Proxy PortNumber	*CTL	[0 to 0xffff / 0 / 1]
5-816-065	Proxy User Name	*CTL	[up to 32 / - / 0]
5-816-066	Proxy Password	*CTL	[up to 32 / - / 0]

5-816-067	CERT:Up State	*CTL	[0 to 255 / 0 / 1]
<p>Displays status of the certification used for Cumin.</p> <p>If it is not installed as Cumin, the value of this SP will be set when it installed, after checking the certification status.</p>			
0	The certification adequately set on the machine.		
1	Request for certification update in progress.		
2	Certification Update completed and notification of the success status to the G/W in progress.		
3	Certification Update failed and notification of the result to the G/W in progress.		
4	Certification expiration date will be coming soon. Notifying the G/W to request for certification update.		
11	Rescue certification setting for connecting to the rescue G/W in progress because update for rescue certification needed.		
12	Setting for rescue certification has completed. Requesting to the rescue G/W for updating certification.		
13	Notification for certification updating request has completed. Waiting for the certification update request from the rescue G/W.		
14	Received the notification for certification updating request from the rescue G/W. Writing the certification.		
15	Writing the certification has completed. Notifying the result of certification update to the G/W.		
16	Writing the certification has failed. Notifying the result of certification update to the G/W.		
17	Writing a rescue certification because received a certification error again after completed the certification update request from the G/W and noticed the result of certification update with the updated certification.		
18	The writing operation mentioned in #17 has completed. Notifying the result of certification update to the rescue G/W.		

5-816-068	CERT: Error	*CTL	[0 to 255 / 0 / 1]
	Displays a number code that describes the reason for the request for update of the certification.		
	0	Normal. There is no request for certification update in progress.	
	1	Request for certification update in progress. The current certification has expired.	
	2	An SSL error notification has been issued. Issued after the certification has expired.	
	3	Notification of shift from a common authentication to an individual certification.	
	4	Notification of a common certification without ID2.	
	5	Notification that no certification was issued.	
5-816-069	CERT: Up ID	*CTL	[- / - / -]
	-		
5-816-083	Firm Up Status	*CTL	[0 or 1 / 0 / 1] 0: Waiting for accepting firm update 1: Waiting for firm update start schedule 2: Waiting for user confirmation 3: In preparation for the machine firm update 4: processing the machine firm update 5: processing the closing operation of the machine firm update
5-816-085	Firm Up User Check	CTL	[0 or 1 / 0 / 1]
5-816-086	Firmware Size	CTL	[0 to 0xffffffff / 0 / 1]
5-816-087	CERT:Macro Ver.	CTL	[8 digits / - / 0]
5-816-088	CERT:PAC Ver.	CTL	[16 digits / - / 0]
5-816-089	CERT:ID2Code	CTL	[17 digits / - / 0]
5-816-090	CERT:Subject	CTL	[17 digits / - / 0]
5-816-091	CERT:Serial No.	CTL	[16 digits / - / 0]

5-816-092	CERT:Issuer	CTL	[30 digits / - / 0]
5-816-093	CERT:Valid Start	CTL	[10 digits / - / 0]
5-816-094	CERT:Valid End	CTL	[10 digits / - / 0]
5-816-102	CERT:Encrypt Level	*CTL	[1 to 2 / 1 / 1]
5-816-103	Client Communication Method	CTL	[0 to 3 / 0 / 1]
5-816-104	Client Communication Limit	CTL	[1 to 7 / 7 / 1]
5-816-115	Network Information Waiting timer	CTL	[5 to 255 / 5 / 1 sec / step]
5-816-150	Selection Country	CTL	[0 to 10 / 1 / 1] 0: Others 1: NA 3: Europe
	<p>Select the country where embedded RCG-M is installed in the machine. After selecting the country, you must also set the following SP codes for embedded RCG-M:</p> <ul style="list-style-type: none"> • SP5816-153 • SP5816-154 • SP5816-161 		
5-816-151	Line Type AutomaticJudgment	CTL	[0 or 1 / 0 / 1] [Execute]

5-816-152	Line Type Judgment Result	CTL	[0 to 255 / 0 / 0]
<p>Displays a number to show the result of the execution of SP5816151. Here is a list of what the numbers mean.</p> <p>0: Success</p> <p>1: In progress (no result yet). Please wait.</p> <p>2: Line abnormal</p> <p>3: Cannot detect dial tone automatically</p> <p>4: Line is disconnected</p> <p>5: Insufficient electrical power supply</p> <p>6: Line classification not supported</p> <p>7: Error because fax transmission in progress – ioctl() occurred.</p> <p>8: Other error occurred</p> <p>9: Line classification still in progress. Please wait.</p>			
5-816-153	Selection Dial / Push	CTL	<p>[0 to 1 (NA, Europe), 2 (Others) / 0 / 0]</p> <p>0: Tone Dialing Phone</p> <p>1: Pulse Dialing Phone</p> <p>Inside Japan "2" may also be displayed:</p> <p>0: Tone Dialing Phone</p> <p>1: Pulse Dialing Phone 10PPS</p> <p>2: Pulse Dialing Phone 20PPS</p>
5-816-154	Outside Line Outgoing Number	CTL	[- / - / -]
5-816-156	Dial Up User Name	CTL	[up to 32 / - / 0]
5-816-157	Dial Up Password	CTL	[up to 32 / - / 0]
5-816-161	Local Phone Number	CTL	[up to 24 / - / 0]
5-816-162	Connection Timing Adjustment Incoming	CTL	[0 to 24 / 1 / 1]
5-816-163	Access Point	CTL	[- / - / -]

5-816-164	Line Connecting	CTL	[0 to 1 / 0 / 1] 0: Sharing Fax 1: No Sharing Fax
5-816-173	Modem Serial No.	CTL	[- / - / -]
5-816-174	Retransmission Limit	CTL	[0 or 1 / 0 / 1]
5-816-187	FAX TX Priority	CTL	[0 or 1 / 0 / 1] 0: Disable 1: Enable
5-816-190	3G DongleID	CTL	[0 to 0 / 0 / 0]
5-816-199	ppp Connect Timer	CTL	[15 to 30 / 15 / 1 min / step]
5-816-200	Manual Polling	CTL	[0 or 1 / 0 / 1] [Execute]
5-816-201	Regist Status	CTL	[0 to 255 / 0 / 1] [Execute]
	Displays the installation status as the target of NRS services.		
	0	Not installed as NRS machines or Cumin.	
	1	Installing as Cumin. Box enrollment has completed. Unable to response for the machine serching from Basil at this status.	
	2	Installation has completed. Unable to response for the machine serching from Basil at this status.	
	3	As a NRS machine, installation has completed. It cannot install as Cumin.	
4	NRS modules is not being launched.		
5-816-202	Letter Number	*CTL	[- / - / -]
5-816-203	Confirm Ececute	*CTL	[0 or 1 / 0 / 1] [Execute]

5-816-204	Confirm Result	CTL	<p>[0 to 255 / 0 / 1]</p> <p>0: Success Inquiry</p> <p>1: Request number error</p> <p>3: Communication error (Enabled Proxy)</p> <p>4: Communication error (Disabled Proxy)</p> <p>5: Proxy error (failed auth.)</p> <p>6: Communication error</p> <p>8: Other error (See SP5-816-208 for detail)</p> <p>9: Processing inquiry</p> <p>20: Failed Dial-up auth.</p> <p>21: Failed answer tone detection</p> <p>22: Failed career detection</p> <p>23: Invalid modem value</p> <p>24: Shortage of electrical current</p> <p>25: Cable disconnected</p> <p>26: Line occupied</p>
Displays the result of SP5-816-203.			

5-816-205	Confirm Place	CTL	<p>[0 or 1 / 0 / 1]</p> <p>0: Success registration</p> <p>1: Request number error</p> <p>3: Communication error (Enabled Proxy)</p> <p>4: Communication error (Disabled Proxy)</p> <p>5: Proxy error (failed auth.)</p> <p>6: Communication error</p> <p>8: Other error (See SP5-816-208 for detail)</p> <p>9: Processing registration</p> <p>20: Failed Dial-up auth.</p> <p>21: Failed answer tone detection</p> <p>22: Failed career detection</p> <p>23: Invalid modem value</p> <p>24: Shortage of electrical current</p> <p>25: Cable disconnected</p> <p>26: Line occupied</p>
	Displays the installed section informed from G/W for response of request number inquiry if the section is enrolled on the G/W.		
5-816-206	Register Execute	CTL	<p>[0 to 1 / 0 / 1]</p> <p>[Execute]</p>
	Executes the registration of Cumin.		
5-816-207	Register Result	CTL	[0 to 255 / 0 / 1]
	Displays the registration result. Shows the executed status of SP5-816-206.		
5-816-208	Error Code	CTL	[-2147483647 to 2147483647 / 0 / -]
	Displays the registration result of SP5-816-204.		

5-816-208	Invalid modem parameter	
	-11001	Chat parameter error.
	-11002	Chat execution error.
	-11003	Unexpected error
	-11004	Disconnect operation occurred during modem communication,
	-11005	NCS reboot occurred during modem communication.
5-816-208	Errors with invalid procedure or settings	
	-12002	Attempted to inquiry or registration without obtaining the installation status.
	-12003	Attempted to registrate without inquiry despite un-registered status.
	-12004	Attempted to install with invalid certification, ID2, and without input the machine number.
	-12005	Executed inquiry/ registration in a invalid Cumin function and prohibited @Remote communication.
5-816-208	-12006	Attempted to inquiry in BOX registration completed.
	-12007	Registration attempted with the different request number from the number used for the last inquiry.
	-12008	Certificaton update failed because Job processing etc.
	-12009	Mismatched between ID2 in NR-RAM and ID2 in the individual certification.
	-12010	Not initialized the certification area.
5-816-208	Error with error response from G/W	
	-2385	Inappropriate international dialing prefix
	-2387	Not supported in the center.
	-2389	DB failure
	-2390	Program failure
	-2391	Double registration of the machine

5-816-208	-2392	Parameter error	
	-2393	Not managed Basil	
	-2394	Not managed machine	
	-2395	Invalid BOX ID of Basil	
	-2396	Invalid Devic ID of Basil	
	-2397	Different format of ID2 (includes invalid ID2)	
	-2398	Different format of request number	
5-816-209	Instl Clear	CTL	[0 or 1 / 0 / 1]
5-816-240	CommErrorTime	CTL	[0 to 0 / 0 / 1]
5-816-241	CommErrorCode 1	CTL	[0 to 0xffffffff / 0x00000000 / 1]
5-816-242	CommErrorCode 2	CTL	[0 to 0xffffffff / 0x00000000 / 1]
5-816-243	CommErrorCode 3	CTL	[0 to 0xffffffff / 0x00000000 / 1]
5-816-244	CommErrorState 1	CTL	[0 to 0xffff / 0x0000 / 1]
5-816-245	CommErrorState 2	CTL	[0 to 0xffff / 0x0000 / 1]
5-816-246	CommErrorState 3	CTL	[0 to 0xffff / 0x0000 / 1]
5-816-247	SSL Error Count	CTL	[0 to 255 / 0 / 0]
5-816-248	Other Err Count	CTL	[0 to 255 / 0 / 1]
5-816-250	CommLog Print	CTL	[0 to 255 / 0 / 0]

5821	[Remote Service RCG Setting]		
5-821-002	RCG IP Address	*CTL	[0 to 0xffffffff / 0 / 1]
5-821-003	RCG Port Number	*CTL	[0 to 65535 / 443 / 1]
5-821-004	RCG IPv4 URL Path	*CTL	[0 to 0 / 0 / 0]
5-821-005	RCG IPv6 Address	*CTL	[0 to 0 / 0 / 0]
5-821-006	RCG IPv6 URL Path	*CTL	[0 to 0 / 0 / 0]
5-821-007	RCG Host Name	*CTL	[0 to 0 / 0 / 0]

5-821-008	RCG Host URL Path	*CTL	[0 to 0 / 0 / 0]
-----------	-------------------	------	------------------

5824	[NV-RAM Data Upload]		
5-824-001	-	CTL	[- / - / -] [Execute]

5825	[NV-RAM Data Download]		
5-825-001	-	CTL	[- / - / -] [Execute]

5828	[Network Setting]		
5-828-039	User Class	CTL	[0 to 0 / 0 / 0]
5-828-040	Class Id	CTL	[0 to 0 / 0 / 0]
5-828-050	1284 Compatibility (Centro)	*CTL	[0 or 1 / 1 / 1] 0: Disabled 1: Enabled
5-828-052	ECP (Centro)	*CTL	[0 or 1 / 1 / 1] 0: Disabled 1: Enabled
	Enables or disables ECP Compatibility.		
5-828-065	Job Spooling	*CTL	[0 or 1 / 0 / 1] 0: Disabled 1: Enabled
5-828-066	Job Spooling Clear: Start Time	*CTL	[0 or 1 / 1 / 1] 0: ON (Data is cleared) 1: OFF (Automatically printed)

5-828-069	Job Spooling (Protocol)	* CTL	[0x00 to 0xff / 0x7f / 0] 0: Validates 1: Invalidates bit0: LPR bit1: FTP bit2: IPP bit3: SMB bit4: BMLinkS bit5: DIPRINT bit6: sftp bit7: (Reserved)
5-828-087	Protocol usage	* CTL	[0x00000000 to 0xffffffff / 0x00000000 / 1]
Shows which protocols have been used with the network. 0: Off (Not used the network with the protocol.) 1: On (Used the network with the protocol once or more.) bit0: IPsec, bit1: IPv6, bit2: IEEE 802. 1X, bit3: Wireless LAN, bit4: Security mode level setting, bit5: Appletalk, bit6: DHCP, bit7: DHCPv6, bit8: telnet, bit9: SSL, bit10: HTTPS, bit11: BMLinkS printing, bit12: diprint printing, bit13: LPR printing, bit14: ftp printing, bit15: rsh printing, bit16: SMB printing, bit17: WSD-Printer, bit18: WSD-Scanner, bit19: Scan to SMB, bit20: Scan to NCP, bit21: Reserve, bit22: Bluetooth, bit23: IEEE 1284, bit24: USB printing, bit25: Dynamic DNS, bit26: Netware printing, bit27: LLTD, bit28: IPP printing, bit29: IPP printing (SSL), bit30: ssh, bit31: sftp			
5-828-090	TELNET (0: OFF 1: ON)	* CTL	[0 or 1 / 1 / 1] 0: Disable 1: Enable
5-828-091	Web (0: OFF 1: ON)	* CTL	[0 or 1 / 1 / 1] 0: Disable 1: Enable

5-828-145	Active IPv6 Link Local Address	CTL	[- / - / -]
5-828-147	Active IPv6 Stateless Address 1	CTL	[- / - / -] These SPs are the IPv6 status addresses (1 to 5) referenced on the Ethernet or wireless LAN (802.11b) in the format:
5-828-149	Active IPv6 Stateless Address 2	CTL	
5-828-151	Active IPv6 Stateless Address 3	CTL	
5-828-153	Active IPv6 Stateless Address 4	CTL	[- / - / -] These SPs are the IPv6 status addresses (1 to 5) referenced on the Ethernet or wireless LAN (802.11b) in the format:
5-828-155	Active IPv6 Stateless Address 5	CTL	
5-828-156	IPv6 Manual Address	*CTL	"Status Address" + "Prefix Length" The IPv6 address consists of a total 128 bits configured in 8 blocks of 16 bits each.
5-828-158	IPv6 Gateway Address	*CTL	[- / - / -]
5-828-161	IPv6 Stateless Auto Setting	*CTL	[0 or 1 / 1 / 1] 0: Disable 1: Enable
5-828-219	IPsec Aggressive Mode Setting	CTL	[0 or 1 / 0 / 1]
5-828-236	Web Item visible	*CTL	[0x0000 to 0xffff / 0xffff / 1]
	Displays or does not display the Web system items. bit0: Net RICOH bit1: Consumable Supplier bit2-15: Reserved (all)		

5-828-237	Web shopping link visible	*CTL	[0 or 1 / 1 / 1] 0: Not display 1:Display
5-828-238	Web supplies Link visible	*CTL	[0 or 1 / 1 / 1] 0: Not display 1: Display
5-828-239	Web Link1 Name	*CTL	[Up to 31char / 0 / 0]
5-828-240	Web Link1 URL	*CTL	[Up to 127char / 0 / 0]
5-828-241	Web Link1 visible	*CTL	[0 or 1 / 1 / 1] 0: Not display 1: Display
5-828-242	Web Link2 Name	*CTL	[- / - / -]
5-828-243	Web Link2 URL	*CTL	[- / - / -]
5-828-244	Web Link2 visible	*CTL	[0 or 1 / 1 / 1]
5-828-249	DHCPv6 DUID	CTL	[- / - / -]

5832	[HDD]		
5-832-00 1	HDD Formatting (ALL)	CTL	[- / - / -] [Execute]
5-832-00 2	HDD Formatting (IMH)	CTL	[- / - / -] [Execute]
5-832-00 3	HDD Formatting (Thumbnail)	CTL	[- / - / -] [Execute]
5-832-00 4	HDD Formatting (Job Log)	CTL	[- / - / -] [Execute]
5-832-00 5	HDD Formatting (Printer Fonts)	CTL	[- / - / -] [Execute]
5-832-00 6	HDD Formatting (User Info 1)	CTL	[- / - / -] [Execute]

5-832-00 7	Mail RX Data	CTL	[- / - / -] [Execute]
5-832-00 8	Mail TX Data	CTL	[- / - / -] [Execute]
5-832-00 9	HDD Formatting (Data for a Design)	CTL	[- / - / -] [Execute]
5-832-01 0	HDD Formatting (Log)	CTL	[- / - / -] [Execute]
5-832-01 1	HDD Formatting (Ridoc I/F)	CTL	[- / - / -] [Execute]
5-832-01 2	HDD Formatting (Thumbnail)	CTL	[- / - / -] [Execute]

5836	[Capture Setting]		
5-836-001	Capture Function (0:Off 1:On)	* CTL	[0 or 1 / 0 / 1] 0: Disable 1: Enable
5-836-011	Capture Setting: Copy	* CTL	[0 or 1 / 0 / 1]
5-836-012	Capture Setting: Doc. Svr.	* CTL	[0 or 1 / 0 / 1]
5-836-013	Capture Setting: Fax RX Printer	* CTL	[0 or 1 / 0 / 1]
5-836-014	Capture Setting: Fax TX	* CTL	[0 or 1 / 0 / 1]
5-836-015	Capture Setting: Printer	* CTL	[0 or 1 / 0 / 1]
5-836-016	Capture Setting: Scanner	* CTL	[0 or 1 / 0 / 1]
5-836-017	Capture Setting: SDK	* CTL	[0 or 1 / 0 / 1]
5-836-061	Captured File Resend (0:Off 1:On)	* CTL	[0 or 1 / 0 / 1]

5836	[Capture Setting]		
-------------	--------------------------	--	--

5-836-071	Reduction for Copy Color	*CTL	[0 to 3 / 2 / 1] 0: 1to-1 1: 1/2 2: 1/3 3: 1/4
5-836-072	Reduction for Copy B&W Text	*CTL	[0 to 6 / 0 / 1] 0: 1to-1 1: 1/2 2: 1/3 3: 1/4 6: 2/3
5-836-073	Reduction for Copy B&W Other	*CTL	[0 to 6 / 0 / 1] 0: 1to-1 1: 1/2 2: 1/3 3: 1/4 6: 2/3
5-836-074	Reduction for Printer Color	*CTL	[0 to 3 / 2 / 1] 0: 1to-1 1: 1/2 2: 1/3 3: 1/4
5-836-075	Reduction for Printer B&W	*CTL	[0 to 6 / 0 / 1] 0: 1to-1 1: 1/2 2: 1/3 3: 1/4 6: 2/3

5-836-077	Reduction for Printer Color 1200dpi	*CTL	[1 to 5 / 4 / 1] 1: 1/2 3: 1/4 4: 1/6 5: 1/8
5-836-078	Reduction for Printer B&W 1200dpi	*CTL	[1 to 5 / 1 / 1] 0: 1 1: 1/2 2: 1/3 3: 1/4 4: 1/6 5: 1/8
5-836-081	Format for Copy Color	*CTL	[0 / 0 / 1] 0: JFIF/JPEG 1: TIFF/MMR 2: TIFF/MH 3: TIFF/MR
5-836-082	Format for Copy B&W Text	*CTL	[0 to 3 / 1 / 1] 0: JFIF/JPEG 1: TIFF/MMR 2: TIFF/MH 3: TIFF/MR
5-836-083	Format for Copy B&W Other	*CTL	[0 to 3 / 1 / 1] 0: JFIF/JPEG 1: TIFF/MMR 2: TIFF/MH 3: TIFF/MR
5-836-084	Format for Printer Color	*CTL	[0 / 0 / 1]

5-836-085	Format for Printer B&W	*CTL	[0 to 3 / 1 / 1] 0: JFIF/JPEG 1: TIFF/MMR 2: TIFF/MH 3: TIFF/MR
5-836-091	Default for JPEG	*CTL	[5 to 95 / 50 / 1]
5-836-101	Primary srv IP address	*CTL	[000.000.000.000 to 255.255.255.255 / - / 0]
5-836-102	Primary srv scheme	*CTL	[0 / NULL / -]
5-836-103	Primary srv port number	*CTL	[1 to 65535 / 80 / 1]
5-836-104	Primary srv URL path	*CTL	[0 / - / 0]
5-836-111	Secondary srv IP address	*CTL	[000.000.000.000 to 255.255.255.255 / - / 1]
5-836-112	Secondary srv scheme	*CTL	[0 / NULL / -]
5-836-113	Secondary srv port number	*CTL	[1 to 65535 / 80 / 1]
5-836-114	Secondary srv URL path	*CTL	[0 / - / 0]
5-836-120	Default Reso Rate Switch	*CTL	[0 or 1 / 0 / 1]
5-836-122	Reso: Copy(Mono)	*CTL	[0 to 255 / 3 / 1] 0: 600dpi/ 1: 400dpi/ 2: 300dpi/ 3: 200dpi/ 4: 150dpi/ 5: 100dpi/ 6: 75dpi

5-836-124	Reso: Print(Mono)	*CTL	[0 to 255 / 3 / 1] 0:600DPi 1:400DPi 2:300DPi 3:200DPi 4:150DPi 5:100DPi 6:75DPi
5-836-125	Reso: Fax(Color)	*CTL	[0 to 255 / 4 / 1] 0:600DPi 1:400DPi 2:300DPi 3:200DPi 4:150DPi 5:100DPi 6:75DPi
5-836-126	Reso: Fax(Mono)	*CTL	[0 to 255 / 3 / 1] 0:600DPi 1:400DPi 2:300DPi 3:200DPi 4:150DPi 5:100DPi 6:75DPi
5-836-127	Reso: Scanner(Color)	*CTL	[0 to 255 / 4 / 1] 0:600DPi 1:400DPi 2:300DPi 3:200DPi 4:150DPi 5:100DPi 6:75DPi

5-836-128	Reso: Scanner(Mono)	*CTL	[0 to 255 / 3 / 1] 0:600DPi 1:400DPi 2:300DPi 3:200DPi 4:150DPi 5:100DPi 6:75DPi
5-836-129	Reso: SDK(Color)	*CTL	[0 to 255 / 4 / 1]
5-836-130	Reso: SDK(Mono)	*CTL	[0 to 255 / 3 / 1]
5-836-141	All Addr Info Switch	*CTL	[0 or 1 / 1 / 1]
5-836-142	Stand-by Doc Max Number	*CTL	[10 to 10000 / 2000 / 1]
5-836-143	ClearLightPDF Switch	*CTL	[0 or 1 / 0 / 1]

5840	[IEEE 802.11]		
5-840-006	Channel Max	*CTL	[1 to 14 / 14 / 1] Europe/Asia: 1 to 13 NA/ Asia: 1 to 11
	DFU		
5-840-007	Channel Min	*CTL	[1 to 14 / 1 / 1] Europe: 1 to 13 NA/ Asia: 1 to 11
	DFU		
5-840-011	WEP key Select	*CTL	[0x00 to 0x11 / 0x00 / 0] 00: Key #1 01: Key #2 (Reserved) 10: Key #3 (Reserved) 11: Key #4 (Reserved)

5-840-045	WPA Debug Lvl	*CTL	[1 to 3 / 3 / 1] 1: Info 2: wArning 3: error
5-840-046	11w	*CTL	[0 to 2 / 0 / 1]
5-840-047	PSK Set Type	*CTL	[0 or 1 / 0 / 1]

5841	[Supply Name Setting]		
5-841-001	Toner Name Setting:Black	*CTL	[- / - / -]
5-841-011	Staple Std1	*CTL	Specifies supply names. These appear on the screen when the user presses the Inquiry button in the user tools screen. [- / - / -]
5-841-012	Staple Std2	*CTL	
5-841-013	Staple Std3	*CTL	
5-841-014	Staple Std4	*CTL	
5-841-021	Staple Bind 1	*CTL	
5-841-022	Staple Bind 2	*CTL	
5-841-023	Staple Bind 3	*CTL	

5842	[GWWS Analysis]		
-------------	------------------------	--	--

5-842-001	Setting 1	*CTL	[0x00 to 0xFF / 0 / 1] 0bit[LSB]: system, other group 1bit: capture related group 2bit: authentication related group 3bit: address book related group 4bit: device management related group 5bit: output related(print, FAX, and delivery) group 6bit: repository, F0,etc. document related group 7bit: debug log level suppression
	Default: 00000000 – do not change Netfiles: Jobs to be printed from the document server using a PC and the DeskTopBinder software		
5-842-002	Setting 2	*CTL	[0x00 to 0xFF / 0 / 1] 0~6bit: unused 7bit: time stamp setting for 5682mmsg log. (1: min./sec/msec, 0: day/hour/min./sec)

5844	[USB]		
5-844-001	Transfer Rate	*CTL	[1 to 4 / 4 / 0] 0x01: Full speed 0x04: Auto Change
5-844-002	Vendor ID	*CTL	[0x0000 to 0xffff / 0x05ca / 0]
	DFU		
5-844-003	Product ID	*CTL	[0x0000 to 0xffff / 0x0403 / 0]
	DFU		
5-844-004	Device Release Number	*CTL	[0 to 9999 / 100 / 1]
	DFU		

5-844-005	Fixed USB Port	*CTL	[0 to 2 / 0 / 1]
5-844-006	PnP Model Name	*CTL	[0 to 0 / 0 / 0]
5-844-007	PnP Serial Number	*CTL	[0 to 0 / 0 / 0]
5-844-008	Mac Supply Level	*CTL	[0 or 1 / 1 / 1]
5-844-009	USB Toggle Clear Mode	*CTL	[0 or 1 / 0 / 1]
5-844-100	Notify Unsupport	*CTL	[0 or 1 / 1 / 1]

5845	[Delivery Server Setting]		
5-845-001	FTP Port No.	*CTL	[0 to 65535 / 3670 / 1]
5-845-002	IP Address (Primary)	*CTL	[000.000.000.000 to 255.255.255.255 / 000.000.000.000 / -]
5-845-006	Delivery Error Display Time	*CTL	[0 to 999 / 300 / 1 second]
5-845-008	IP Address (Secondary)	*CTL	[000.000.000.000 to 255.255.255.255 / 000.000.000.000 / -]
5-845-009	Delivery Server Model	*CTL	[0 to 4 / 0 / 1] 0: Unknown 1: SG1 Provided 2: SG1 Package 3: SG2 Provided 4: SG2 Package

5-845-010	Delivery Svr. Capability	*CTL	[0 to 255 / - / 1]
	Bit7	1 Comment information exists	
	Bit6	1 Direct specification of mail address possible	
	Bit5	1 Mail RX confirmation setting possible	
	Bit4	1 Address book automatic update function exists	
	Bit3	1 Fax RX delivery function exists	
	Bit2	1 Sender password function exists	
	Bit1	1 Function to link MK-1 user and Sender exists	
	Bit0	1 Sender specification required (if set to 1, Bit6 is set to "0")	
5-845-011	Delivery Svr Capability (Ext)	*CTL	[0 to 255 / - / 1]
	Bit7 = 1 Address book usage limitation (Limitation for each authorized user) Bit6 = 1 RDH authorization link Bit5 to 0: Not used		
5-845-013	Server Scheme (Primary)	*CTL	[Up to 6 char / - / -]
5-845-014	Server Port Number (Primary)	*CTL	[1 to 65535 / 80 / 1]
5-845-015	Server URL Path (Primary)	*CTL	[- / - / -]
5-845-016	Server Scheme (Secondary)	*CTL	[Up to 6 char / - / -]
5-845-017	Server Port Number (Secondary)	*CTL	[1 to 65535 / 80 / 1]
5-845-018	Server URL Path (Secondary)	*CTL	[Up to 16 byte / - / -]
5-845-022	Rapid Sending Control	*CTL	[0 or 1 / 1 / 1] 0: Control disabled 1: Control enabled

5846	[UCS Setting]		
5-846-001	Machine ID (for Delivery Server)	*CTL	[- / - / -]

5-846-002	Machine ID Clear(for Delivery Server)	*CTL	[- / - / -] [Execute]
5-846-003	Maximum Entries	*CTL	[2000 to 20000 / 2000 / 1]
5-846-006	Delivery Server Retry Timer	*CTL	[0 to 255 / 0 / 1]
5-846-007	Delivery Server Retry Times	*CTL	[0 to 255 / 0 / 1]
5-846-008	Delivery Server Maximum Entries	*CTL	[2000 to 20000 / 2000 / 1]
5-846-010	LDAP Search Timeout	*CTL	[1 to 255 / 60 / 1]
5-846-020	WSD Maximum Entries	*CTL	[50 to 250 / 250 / 1]
5-846-021	Folder Auth Change	*CTL	[0 or 1 / 0 / 1] 0: Login User, 1: Destination
5-846-040	Addr Book Migration(USB->HDD)	*CTL	[- / - / -] [Execute]
5-846-041	Fill Addr Acl Info	*CTL	[- / - / -] [Execute]
5-846-043	Addr Book Media	*CTL	[0 to 30 / 0 / 1] 0: Unconfirmed 1: SD Slot 1 2: SD Slot 2 3: SD Slot 3 4: USB Flash ROM 10: SD Slot 10 20: HDD 30: Nothing
5-846-047	Initialize Local Address Book	CTL	[- / - / -] [Execute]
5-846-048	Initialize Delivery Addr Book	CTL	[- / - / -] [Execute]

5-846-049	Initialize LDAP Addr Book	CTL	[- / - / -] [Execute]
5-846-050	Initialize All Addr Book	CTL	[- / - / -] [Execute]
5-846-051	Backup All Addr Book	CTL	[- / - / -] [Execute]
5-846-052	Restore All Addr Book	CTL	[- / - / -] [Execute]
5-846-053	Clear Backup Info	CTL	[- / - / -] [Execute]
5-846-060	Search Option	*CTL	[0x00 to 0xff / 0x0f / 1]
	<p>This SP uses bit switches to set up the fuzzy search options for the UCS local address book.</p> <p>Bit: Meaning</p> <p>0: Checks both upper/lower case characters</p> <p>1: Japan Only</p> <p>2: Japan Only</p> <p>3: Japan Only</p> <p>4 to 7: Not Used</p>		
5-846-062	Complexity Option 1	*CTL	[0 to 32 / 0 / 1]
5-846-063	Complexity Option 2	*CTL	[0 to 32 / 0 / 1]
5-846-064	Complexity Option 3	*CTL	[0 to 32 / 0 / 1]
5-846-065	Complexity Option 4	*CTL	[0 to 32 / 0 / 1]
5-846-091	FTP Auth Port Setting	*CTL	[0 to 65535 / 3671 / 1]
5-846-094	Encryption Stat	*CTL	[0 to 255 / - / 0]
5847	[Rep Resolution Reduction]		

5-847-002	Rate for Copy B&W Text	*CTL	[0 to 6 / 0 / 1]
5-847-003	Rate for Copy B&W Other	*CTL	0: 1x 1: 1/2x 2: 1/3x 3: 1/4x 4: 1/6x 5: 1/8x 6: 2/3x
5-847-005	Rate for Printer B&W	*CTL	[0 to 6 / 0 / 1] 0: 1x 1: 1/2x 2: 1/3x 3: 1/4x 4: 1/6x 5: 1/8x 6: 2/3x
5-847-007	Rate for Printer B&W 1200dpi	*CTL	[0 to 6 / 1 / 1] 0: 1x 1: 1/2x 2: 1/3x 3: 1/4x 4: 1/6x 5: 1/8x 6: 2/3x
5-847-021	Network Quality Default for JPEG	*CTL	[5 to 95 / 50 / 1]

5848	[Web Service]
------	---------------

5-848-002	Access Ctrl: Repository (only Lower 4 bits)	*CTL	[0x00 to 0xFF / 0x02 / 0] 0000: No access control 0001: Denies access to DeskTop Binder. 0010: No writing control
5-848-003	Access Control: Doc. Svr. Print (Lower 4 bits)	*CTL	[0x00 to 0xFF / 0x00 / 0] 0000: No access control 0001: Denies access to DeskTop Binder.
5-848-004	Access Control: uirectory (Lower 4 bits)	*CTL	[0x00 to 0xFF / 0x00 / 0] 0000: No access control 0001: Denies access to DeskTop Binder.
5-848-007	Access Ctrl: Comm. Log Fax (Lower 4 bits)	*CTL	[0x00 to 0xFF / 0x00 / 0] 0000: No access control 0001: Denies access to DeskTop Binder.
5-848-009	Access Ctrl: Job Ctrl (Lower 4 bits)	*CTL	[0x00 to 0xFF / 0x00 / 0] 0000: No access control 0001: Denies access to DeskTop Binder.
5-848-011	Access Ctrl: Devicemanagement (Lower 4bits)	*CTL	[0x00 to 0xFF / 0x00 / 0] 0000: No access control 0001: Denies access to DeskTop Binder.
5-848-021	Access Ctrl: Delivery (Lower 4 bits)	*CTL	[0x00 to 0xFF / 0x00 / 0] 0000: No access control 0001: Denies access to DeskTop Binder.
5-848-022	Access Ctrl: uadministration (Lower 4bits)	*CTL	[0x00 to 0xFF / 0x00 / 0] 0000: No access control 0001: Denies access to DeskTop Binder.

5-848-024	Access Ctrl: Log Service (Lower 4bits)	*CTL	[0x00 to 0xFF / 0x00 / 0] 0000: No access control 0001: Denies access to DeskTop Binder.
5-848-025	Access Ctrl: Rest WebService (Lower 4bits)	*CTL	[0x00 to 0xFF / 0x00 / 0] 0000: No access control 0001: Denies access to DeskTop Binder.
5-848-099	Repository: Download Image Setting	*CTL	[0x00 to 0xFF / 0x00 / 1] DFU
5-848-100	Repository: Download Image Max. Size	*CTL	[1 to 2048 / 2048 / 1]
5-848-150	Log Operation Mode	*CTL	[0 to 9 / 0 / 1]
5-848-217	Setting: Timing	*CTL	[0 to 2 / 0 / 1] NIA

5849	[Installation Date]		
5-849-001	Display	*CTL	[- / - / -]
5-849-002	Switch to Print	*CTL	[0 or 1 / 0 (Japan), 1 (Others) / 1] 0: OFF (No Print) 1: ON (Print)
5-849-003	Setup Count	*CTL	[0 to 99999999 / 0 / 1]

5850	[Address Book Function]		
-------------	--------------------------------	--	--

5-850-003	Replacement of Circuit Classifications	*CTL	[- / - / -] 1: G3 2: EXT 3: G3-1 4: G3-1- EXT 5: G3-2 6: G3-2- EXT 7: G3-3 8: G3-3-EXT 9: G3-idle-EXT 10: idle-EXT 11: I-G3 12: I-G3-EXT 13: G4
-----------	--	------	--

5851	[Bluetooth]		
5-851-001	mode	*CTL	[0x00 to 0x01 / 0x00 / 1]

5853	[Stamp Date Download]		
5-853-001	-	CTL	[- / - / -]

5856	[Remote ROM Update]		
Allows the technician to upgrade the firmware using a local port (IEEE1284) when updating the remote ROM.			
5-856-002	Local Port	*CTL	[0 or 1 / 0 / 1] 0: Disable 1: Enable

5858	[Collect Machine Info]		
5-858-001	0:OFF 1:ON	CTL	[0 or 1 / 1 / 1]
5-858-002	Save To (0:HDD 1:SD)	CTL	[0 or 1 / 0 / 1]

5-858-003	Make Log Trace Dir	CTL	[0 or 1 / 0 / 0]
5-858-101	Failure Occuring Date	CTL	[0 to 20371212 / 0 / 1]
5-858-102	Tracing Days	CTL	[1 to 180 / 2 / 1 day / step]
5-858-103	Acquire Fax Address(0:OFF 1:ON)	CTL	[0 or 1 / 0 / 1]
5-858-111	Acquire All Info & Logs	CTL	[0 or 1 / 0 / 0]
5-858-121	Acquire Configuration Page	CTL	[0 or 1 / 0 / 0]
5-858-122	Acquire Font Page	CTL	[0 or 1 / 0 / 0]
5-858-123	Acquire Print Setting List	CTL	[0 or 1 / 0 / 0]
5-858-124	Acquire Error Log	CTL	[0 or 1 / 0 / 0]
5-858-131	Acquire Fax Info	CTL	[0 or 1 / 0 / 0]
5-858-141	Acquire All Debug Logs	CTL	[0 or 1 / 0 / 0]
5-858-142	Acquire Controller Debug Logs Only	CTL	[0 or 1 / 0 / 0]
5-858-143	Acquire Engine Debug Logs Only	CTL	[0 or 1 / 0 / 0]
5-858-144	Acquire Opepanel Debug Logs Only	CTL	[0 or 1 / 0 / 0]
5-858-145	Acquire FCU Debug Logs Only	CTL	[0 or 1 / 0 / 0]
5-858-146	Acquire Only Network Packets	CTL	[0 or 1 / 0 / 0]

5860	[SMTP/POP3/IMAP4]		
5-860-020	Partial Mail Receive Timeout	*CTL	[1 to 168 / 72 / 1 hour / step]
5-860-021	MDN Response RFC2298 Compliance	*CTL	[0 or 1 / 1 / 1] 0: No 1: Yes

5-860-022	SMTP Auth. From Field Replacement	*CTL	[0 to 1 / 0 / 1] 0: No. "From" item not switched. 1: Yes. "From item switched.
5-860-025	SMTP Auth. Direct Setting	*CTL	[0 to 0xff / 0x00 / 1]
Selects the authentication method for SMTP. Bit switch: Bit 0: LOGIN Bit 1: PLAIN Bit 2: CRAM MD5 Bit 3: DIGEST MD5 Bit 4 to 7: Not used <div style="border: 1px solid blue; border-radius: 10px; padding: 2px; display: inline-block;"> Note </div> <ul style="list-style-type: none"> This SP is activated only when SMTP authorization is enabled by UP mode. 			
5-860-026	S/MIME:MIME Header Setting	*CTL	[0 to 2 / 0 / 1] 0: Microsoft Outlook Express standard 1: Internet Draft standard 2: RFC standard
5-860-028	S/MIME: Authentication Check	*CTL	[0 or 1 / 0 / 1] 0: No (not check) 1: Yes (check)

5866	[Email Report]		
5-866-001	Report Validity	CTL	[0 or 1 / 0 / 1] 0: Enabled 1: Disabled
5-866-005	Add Date Field	CTL	[0 or 1 / 0 / 1] 0: Enabled 1: Disabled
5-866-110	CounterE-Mail:Validity	CTL	[0 or 1 / 0 / 1]
5-866-111	CounterE-Mail:Destination Registration	CTL	[0 to 0 / 0 / 0]

5-866-112	CounterE-Mail:Send Test	CTL	[0 to 0 / 0 / 0]
5-866-113	CounterE-Mail:Next Send Date	CTL	[0 to 0 / 0 / 0]
5-866-114	CounterE-Mail:Send Date Setting	CTL	[0 to 31 / 0 / 1]
5-866-115	CounterE-Mail:Send Time Setting	CTL	[0 to 2359 / 0 / 1]
5-866-121	CounterE-Mail:Destination 1	CTL	[0 to 0 / 0 / 0]
5-866-122	CounterE-Mail:Destination 2	CTL	[0 to 0 / 0 / 0]
5-866-123	CounterE-Mail:Destination 3	CTL	[0 to 0 / 0 / 0]

5870	[Common Key Info Writing]		
5-870-001	Writing	CTL	[0 or 1 / 0 / 1] [Execute]
5-870-003	Initialize	CTL	[0 or 1 / 0 / 1] [Execute]
5-870-004	Writing: 2048bit	CTL	[0 or 1 / 0 / 1] [Execute]

5873	[SD Card Appli Move]		
5-873-001	Move Exec	CTL	[- / - / -] [Execute]
5-873-002	Undo Exec	CTL	[- / - / -] [Execute]

5875	[SC Auto Reboot]		
	-		
5-875-001	Reboot Setting	* CTL	[0 or 1 / 0 / 1]
5-875-002	Reboot Type	*CTL	[0 or 1 / 0 (Japan), 1 (Others) / 1] 0: Manual reboot 1: Automatic reboot

5878	[Option Setup]		
5-878-001	Data Overwrite Security	CTL	[- / - / -] [Execute]
5-878-002	HDD Encryption	CTL	[- / - / -] [Execute]
5-878-004	OCR Dictionary	CTL	[- / - / -] [Execute]

5881	[Fixed Phrase Block Erasing]		
5-881-001	-	CTL	[- / - / -]
	Delete the fixed phrase.		

5885	[Set WIM Function] Web Image Monitor Settings		
5-885-020	DocSvr Acc Ctrl	*CTL	[0x00 or 0xFF / 0x00 / 0] 0: OFF 1: ON Bit Meaning 0: Forbid all document server access (1) 1: Forbid user mode access (1) 2: Forbid print function (1) 3: Forbid fax TX (1) 4: Forbid scan sending (1) 5: Forbid downloading (1) 6: Forbid delete (1) 7: Reserved
5-885-050	DocSvr Format	*CTL	[0 to 2 / 0 / 1] 0: Thumbnail, 1: Icon, 2: Details
5-885-051	DocSvr Trans	*CTL	[5 to 20 / 10 / 1]

5-885-100	Set Signature	*CTL	[0 to 2 / 0 / 1] 0: Setting for each e-mail 1: Signature for all 2: No signature
5-885-101	Set Encrypsion	*CTL	[0 or 1 / 0 / 1] 0: Not encrypted 1: Encryption
5-885-200	Detect Mem Leak	*CTL	[0x00 to 0xFF / 0x00 / 0]

5886	[Farm Update Setting]		
5-886-100	Skip Version Check	CTL	[0 or 1 / 0 / 1]
5-886-101	Skip LR Check	CTL	[0 or 1 / 0 / 1]
5-886-111	Auto Update Setting	CTL	[0 or 1 / 0 / 1]
5-886-112	Auto Update Prohibit Term Setting	CTL	[0 or 1 / 1 / 1]
5-886-113	Auto Update Prohibit Start hour	CTL	[0 to 23 / 9 / 1 hour / step]
5-886-114	Auto Update Prohibit End hour	CTL	[0 to 23 / 17 / 1 hour / step]
5-886-115	SFU Auto Download Setting	CTL	[0 or 1 / 0 / 1]
5-886-116	Auto Update Next Date	CTL	[0 to 0 / 0 / 0]
5-886-117	Auto Update Retry Interval Hour	CTL	[1 to 24 / 1 / 1 hour / step]
5-886-119	Auto Update @Remote Using Setting	CTL	[0 or 1 / 0 / 1]
5-886-120	Auto Update Prohibit Day of Week Setting	CTL	[0 to 255 / 0 / 1]
5-886-151	Permit SubId Update	CTL	[0 or 1 / 0 / 1]
5-886-201	Restore Date	CTL	[0 to 0 / 0 / 0]
5-886-202	Save Old Version List	CTL	[0 to 0 / 0 / 0]

5887	[SD GetCounter]		
5-887-001		CTL	[- / - / -] [Execute]

5888	[Personal Information Protect]		
5-888-001	-	*CTL	[0 or 1 / 0 / 1]
	Selects the protection level for logs. 0: No authentication, No protection for logs 1: No authentication, Protected logs (only an administrator can see the logs)		

5893	[SDK Apli Cnt Name]		
5-893-001	SDK-1	CTL	[- / - / -] [Display text]
5-893-002	SDK-2	CTL	[- / - / -] [Display text]
5-893-003	SDK-3	CTL	[- / - / -] [Display text]
5-893-004	SDK-4	CTL	[- / - / -] [Display text]
5-893-005	SDK-5	CTL	[- / - / -] [Display text]
5-893-006	SDK-6	CTL	[- / - / -] [Display text]
5-893-007	SDK-7	CTL	[- / - / -] [Display text]
5-893-008	SDK-8	CTL	[- / - / -] [Display text]
5-893-009	SDK-9	CTL	[- / - / -] [Display text]

5-893-010	SDK-10	CTL	[- / - / -] [Display text]
5-893-011	SDK-11	CTL	[- / - / -] [Display text]
5-893-012	SDK-12	CTL	[- / - / -] [Display text]

5895	[Application invalidation]		
5-895-001	Printer	CTL	[0 or 1 / 0 / 0]
5-895-002	Scanner	CTL	[0 or 1 / 0 / 0]

5907	[Plug & Play Maker/Model Name]		
5-907-001	-	*CTL	[0 to 255 / 0 / 1]

5913	[Switchover Permission Time]		
5-913-002	Print Application Timer	*CTL	[0 to 30 / 3 / 1]

5967	[Copy Server: Set Function]		
5-967-001	(0: ON 1: OFF)	*CTL	[0 or 1 / 0 / 1] 0: ON 1: OFF

5973	[User Stamp Registration]		
5-973-101	Frame deletion setting	CTL	[0 to 3 / 0 / 1]

5985	[Device Setting]		
5-985-001	On Board NIC	CTL	[0 to 2 / 0 / 1] 0: Disable 1: Enable 2: Function limitation

5-985-002	On Board USB	CTL	[0 or 1 / 0 / 1]
-----------	--------------	-----	------------------

5990	[SP Print Mode]		
5-990-001	All (Data List)	CTL	[0 to 255 / 0 / 0]
5-990-002	SP (Mode Data List)	CTL	[0 to 255 / 0 / 0]
5-990-003	User Program	CTL	[0 to 255 / 0 / 0]
5-990-004	Logging Data	CTL	[0 to 255 / 0 / 0]
5-990-005	Diagnostic Report	CTL	[0 to 255 / 0 / 0]
5-990-006	Non-Default	CTL	[0 to 255 / 0 / 0]
5-990-007	NIB Summary	CTL	[- / - / -]
5-990-008	Capture Log	CTL	[0 to 255 / 0 / 1]
5-990-021	Copier User Program	CTL	[- / - / -]
5-990-022	Scanner SP	CTL	[0 to 255 / 0 / 0]
5-990-023	Scanner User Program	CTL	[0 to 255 / 0 / 0]
5-990-024	SDK/J Summary	CTL	[- / - / -]
5-990-025	SDK/J Application Info	CTL	[- / - / -]
5-990-026	Printer SP	CTL	[0 to 255 / 0 / 0]
5-990-027	SmartOperationPanel SP	CTL	[0 to 255 / 0 / 0]
5-990-028	SmartOperationPanel UP	CTL	[0 to 255 / 0 / 0]

5992	[SP Text mode]		
5-992-001	All (Data List)	CTL	[0 to 255 / 0 / 0]
5-992-002	SP (Mode Data List)	CTL	[0 to 255 / 0 / 0] [Execute]
5-992-003	User Program	CTL	[0 to 255 / 0 / 0] [Execute]

5-992-004	Logging Data	CTL	[0 to 255 / 0 / 0] [Execute]
5-992-005	Diagnostic Report	CTL	[0 to 255 / 0 / 0] [Execute]
5-992-006	Non-Default	CTL	[0 to 255 / 0 / 0] [Execute]
5-992-007	NIB Summary	CTL	[- / - / -] [Execute]
5-992-008	Capture Log	CTL	[0 to 255 / 0 / 0] [Execute]
5-992-021	Copier User Program	CTL	[- / - / -] [Execute]
5-992-022	Scanner SP	CTL	[0 to 255 / 0 / 0] [Execute]
5-992-023	Scanner User Program	CTL	[0 to 255 / 0 / 0] [Execute]
5-992-024	SDK/J Summary	CTL	[- / - / -] [Execute]
5-992-025	SDK/J Application Info	CTL	[- / - / -] [Execute]
5-992-026	Printer SP mode	CTL	[0 to 255 / 0 / 0] [Execute]
5-992-027	SmartOperationPanel SP	CTL	[0 to 255 / 0 / 0] [Execute]
5-992-028	SmartOperationPanel UP	CTL	[0 to 255 / 0 / 0] [Execute]

Controller SP Tables-6

SP6-XXX (Data Log)

3

6830	[Extra]		
6-830-001	Staples 0 to 50 (Initial:0)	CTL	[0 to 50 / 0 / 1]
6-830-002	Saddles 0 to 50 (Initial:0)	CTL	[0 to 50 / 0 / 1]
6-830-003	Half-Fold 0 to 50 (Initial:0)	CTL	[0 to 50 / 0 / 1]
6890	[Function Enabled]		
6-890-001	Z-Fold 0:No Punch 1:Punching OK	CTL	[0 or 1 / 0 / 1]

Controller SP Tables-7

SP7-XXX (Data Log)

7401	[Total SC]		
	Stores total SC occurring count. If the same SC codes are detected continuously and total counter is not increasing, it only logs once in case of deleting other SC code logs.		
7-401-001	SC Counter	*CTL	[0 to 65535 / - / 0]
7-401-002	Total SC Counter	*CTL	[0 to 65535 / - / 0]

7403	[SC History]		
	Logs and displays the SC codes detected. The 10 most recently detected SC Codes are displayed on the screen, and also can be seen on the SMC (logging) outputs. Note <ul style="list-style-type: none"> If the same SC codes are detected continuously and total counter is not increasing, it only logs once in case of deleting other SC code logs. 		
7-403-001	Latest	*CTL	[- / - / -]
7-403-002	Latest 1	*CTL	
7-403-003	Latest 2	*CTL	
7-403-004	Latest 3	*CTL	
7-403-005	Latest 4	*CTL	
7-403-006	Latest 5	*CTL	
7-403-007	Latest 6	*CTL	
7-403-008	Latest 7	*CTL	
7-403-009	Latest 8	*CTL	
7-403-010	Latest 9	*CTL	

7404		[Software Error History]	
7-404-001	Latest	* CTL	[- / - / -]
7-404-002	Latest 1	* CTL	
7-404-003	Latest 2	* CTL	
7-404-004	Latest 3	* CTL	
7-404-005	Latest 4	* CTL	
7-404-006	Latest 5	* CTL	
7-404-007	Latest 6	* CTL	
7-404-008	Latest 7	* CTL	
7-404-009	Latest 8	* CTL	
7-404-010	Latest 9	* CTL	

7502		[Total Paper Jam]	
7-502-001	Jam Counter	* CTL	[0 to 65535 / - / 0]
7-502-002	Total Jam Counter	* CTL	[0 to 65535 / - / 0]

7503		[Total Original Jam Counter]	
7-503-001		* CTL	[0 to 65535 / - / 0]
7503		[Total Original Jam]	
7-503-002	Total Original Counter	* CTL	[0 to 65535 / - / 0]

7504		[Paper Jam Location]	
7-504-001	At Power On	* CTL	Paper is not fed at power on. [0 to 65535 / 0 / 0]
7-504-003	1st Paper Feed SN: Late	* CTL	[0 to 65535 / 0 / 0]
7-504-004	2nd Paper Feed SN: Late	* CTL	[0 to 65535 / 0 / 0]
7-504-005	3rd Paper Feed SN: Late	* CTL	[0 to 65535 / 0 / 0]

7-504-006	4th Paper Feed SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-007	LCT Paper Feed SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-008	1st Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-009	2nd Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-010	3rd Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-011	4th Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-012	Relay SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-013	Registration SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-014	Fusing Exit SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-015	Exit Unit Entrance SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-016	Paper Exit SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-019	Duplex Entrance SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-020	Duplex Transport SN 1: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-021	Duplex Transport SN 2: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-022	Duplex Transport SN 3: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-023	Duplex Exit SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-024	LCT Relay SN: Late3	*CTL	[0 to 65535 / 0 / 0]
7-504-034	Bypass Paper Feed SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-045	Sort Tray: Paper Exit SN: Late	*CTL	[0 to 65535 / 0 / 0]

7-504-046	Sort Tray: Tray Lift Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-047	Sort Tray: Shift Tray Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-053	1st Paper Feed SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-054	2nd Paper Feed SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-055	3rd Paper Feed SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-056	4th Paper Feed SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-057	LCT Paper Feed SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-058	1st Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-059	2nd Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-060	3rd Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-061	4th Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-062	Relay SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-063	Registration SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-066	Paper Exit SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-069	Duplex Entrance SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-071	Duplex Transport SN 2: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-072	Duplex Transport SN 3: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-074	Relay SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-101	Entrance SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-102	Entrance SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-103	Horizontal Trans. SN: Late	*CTL	[0 to 65535 / 0 / 0]

7-504-104	Horizontal Trans. SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-105	Switchback Trans. SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-106	Switchback Trans. SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-107	Top Tray Exit SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-108	Top Tray Exit SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-109	Shift Tray Exit: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-110	Shift Tray Exit: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-111	Entrance Trans. Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-112	Horizontal Trans. Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-113	Pre-stack Transport Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-114	Relay Transport Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-115	Paper Exit Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-116	Trailing Edge Pressure Plate Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-117	Paper Exit Gate Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-118	Punching Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-119	Punch Shift Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-120	S-to-S Regist. Move Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-121	Lower Junction Gate Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-122	Jogger Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-123	Positioning Roller Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-124	Feed Out Motor	*CTL	[0 to 65535 / 0 / 0]

7-504-125	Corner Stapler Shift Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-126	Corner Stapler Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-130	Output Tray Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-131	Shift Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-132	Shift Tray Jogger Front Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-133	Shift Tray Jogger Rear Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-134	Shift Tray Jogger Retraction Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-135	Stacking Roller Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-136	Leading Edge Guide Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-140	Positioning Roller Transport Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-141	Paper Guide Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-149	Main Machine Setting Incorrect	*CTL	[0 to 65535 / 0 / 0]
7-504-151	Booklet Entrance SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-152	Booklet Duplex Entrance SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-153	Booklet Horizontal Trans. SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-154	Booklet Horizontal Trans. SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-155	Booklet Switchback Trans. SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-156	Booklet Switchback Trans. SN: Lag	*CTL	[0 to 65535 / 0 / 0]

7-504-157	Booklet Top Tray Exit SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-158	Booklet Top Tray Exit SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-159	Booklet Shift Tray Exit: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-160	Booklet Shift Tray Exit: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-161	Booklet Stapler Exit Sn: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-162	Booklet Stapler Exit Sn: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-163	Booklet Entrance Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-164	Booklet Horizontal Trans. Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-165	Booklet Pre-stack Transport Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-166	Booklet Relay Transport Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-167	Booklet Paper Exit Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-168	Booklet Trailing Edge Pressure Plate Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-169	Booklet Paper Exit Gate Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-170	Booklet Punching Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-171	Booklet Punch Shift Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-172	Booklet S-to-S Regist. Move Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-173	Booklet Lower Junction Gate Motor	*CTL	[0 to 65535 / 0 / 0]

7-504-174	Booklet Jogger Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-175	Booklet Positioning Roller Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-176	Booklet Stack Feed-Out Belt Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-177	Booklet Corner Stapler Shift Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-178	Booklet Corner Stapler Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-179	Booklet Jogger Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-180	Booklet Guide Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-181	Booklet Fence Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-182	Booklet Stapler Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-183	Movement Roller Transport Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-184	Folding Transport Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-185	Flat Fold Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-186	Booklet Output Tray Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-187	Booklet Shift Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-188	Booklet Shift Jogger Front Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-189	Booklet Shift Jogger Rear Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-190	Booklet Shift Tray Jogger Retraction Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-191	Booklet Stacking Roller Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-192	Booklet Leading Edge Guide Motor	*CTL	[0 to 65535 / 0 / 0]

7-504-196	Booklet Positioning Roller Transport Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-197	Booklet Paper Guide Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-199	Booklet Main Machine Setting Incorrect	*CTL	[0 to 65535 / 0 / 0]
7-504-201	Entrance Sensor	*CTL	[0 to 65535 / 0 / 0]
7-504-202	Proof Tray Exit	*CTL	[0 to 65535 / 0 / 0]
7-504-203	Shift Tray Exit	*CTL	[0 to 65535 / 0 / 0]
7-504-204	Staple Tray Exit	*CTL	[0 to 65535 / 0 / 0]
7-504-205	Pre-Stack	*CTL	[0 to 65535 / 0 / 0]
7-504-206	Exit After Jogging	*CTL	[0 to 65535 / 0 / 0]
7-504-208	Upper Trans Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-209	Shift Tray Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-210	Positioning Roller Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-211	Jogger Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-212	Stack Plate Motor (Center)	*CTL	[0 to 65535 / 0 / 0]
7-504-213	Stack Plate Motor (Front)	*CTL	[0 to 65535 / 0 / 0]
7-504-214	Stack Plate Motor (Rear)	*CTL	[0 to 65535 / 0 / 0]
7-504-215	Shift Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-216	Drag Drive Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-217	Shift Tray Jogger Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-218	Shift Tray Jogger Retraction Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-219	Exit Guide Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-220	Staple Hammer Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-221	Stapler Movement Motor	*CTL	[0 to 65535 / 0 / 0]

7-504-222	Stapler Rotation Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-223	Stack Feed-Out Belt Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-224	Punch Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-225	Top Fence Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-226	Bottom Fence Motor	*CTL	[0 to 65535 / 0 / 0]
7-504-247	Main Machine Setting Incorrect	*CTL	[0 to 65535 / 0 / 0]
7-504-249	GBC Jam	*CTL	[0 to 65535 / 0 / 0]
7-504-251	1st Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-252	1st Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-253	2nd Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-504-254	2nd Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-504-255	3rd Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]

7505	[Original Jam Detection]		
7-505-001	At Power On	*CTL	[0 to 65535 / 0 / 0]
7-505-013	Separation Sensor: Late	*CTL	[0 to 65535 / 0 / 0]
7-505-014	Skew Correction Sn: Late	*CTL	[0 to 65535 / 0 / 0]
7-505-015	Scanning Entrance Sn: Late	*CTL	[0 to 65535 / 0 / 0]
7-505-016	Registration Sensor: Late	*CTL	[0 to 65535 / 0 / 0]
7-505-017	Original Exit Sensor: Late	*CTL	[0 to 65535 / 0 / 0]
7-505-063	Separation Sensor: Lag	*CTL	[0 to 65535 / 0 / 0]
7-505-064	Skew Correction Sn: Lag	*CTL	[0 to 65535 / 0 / 0]

7-505-065	Scanning Entrance Sn: Lag	*CTL	[0 to 65535 / 0 / 0]
7-505-066	Registration Sensor: Lag	*CTL	[0 to 65535 / 0 / 0]
7-505-067	Original Exit Sensor: Lag	*CTL	[0 to 65535 / 0 / 0]
7-505-239	Original Pull	*CTL	[0 to 65535 / 0 / 0]

7506	[Jam Count by Paper Size]		
7-506-005	A4 LEF	*CTL	[0 to 65535 / 0 / 0]
7-506-006	A5 LEF	*CTL	
7-506-014	B5 LEF	*CTL	
7-506-038	LT LEF	*CTL	
7-506-044	HLT LEF	*CTL	
7-506-132	A3 SEF	*CTL	
7-506-133	A4 SEF	*CTL	
7-506-134	A5 SEF	*CTL	
7-506-141	B4 SEF	*CTL	
7-506-142	B5 SEF	*CTL	
7-506-160	DLT SEF	*CTL	
7-506-164	LG SEF	*CTL	
7-506-166	LT SEF	*CTL	
7-506-172	HLT SEF	*CTL	
7-506-255	Others	*CTL	

7507	[Plotter Jam History]		
-------------	------------------------------	--	--

7-507-001	Latest	*CTL	[- / - / -]
7-507-002	Latest 1	*CTL	
7-507-003	Latest 2	*CTL	
7-507-004	Latest 3	*CTL	
7-507-005	Latest 4	*CTL	
7-507-006	Latest 5	*CTL	
7-507-007	Latest 6	*CTL	
7-507-008	Latest 7	*CTL	
7-507-009	Latest 8	*CTL	
7-507-010	Latest 9	*CTL	

7508	[Original Jam History]		
7-508-001	Latest	*CTL	[- / - / -]
7-508-002	Latest 1	*CTL	
7-508-003	Latest 2	*CTL	
7-508-004	Latest 3	*CTL	
7-508-005	Latest 4	*CTL	
7-508-006	Latest 5	*CTL	
7-508-007	Latest 6	*CTL	
7-508-008	Latest 7	*CTL	
7-508-009	Latest 8	*CTL	
7-508-010	Latest 9	*CTL	

7509	[Paper Jam Location]		
7-509-001	3rd Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]

7-509-002	4th Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-509-003	4th Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-509-004	5th Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-509-005	5th Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-509-044	Main Machine Setting Incorrect	*CTL	[0 to 65535 / 0 / 0]
7-509-046	Cover Feeder: Paper Feed SN: Late or Lag	*CTL	[0 to 65535 / 0 / 0]
7-509-047	Cover Feeder: Paper Exit SN: Late or Lag	*CTL	[0 to 65535 / 0 / 0]
7-509-048	Cover Feeder: Bottom Plate Mtr: Late or Lag	*CTL	[0 to 65535 / 0 / 0]
7-509-096	Paper Feed: Late	*CTL	[0 to 65535 / 0 / 0]
7-509-097	Paper Feed: Lag	*CTL	[0 to 65535 / 0 / 0]
7-509-098	Pressure Timing SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-509-099	Pressure Timing SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-509-100	Contact Timing SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-509-101	Contact Timing SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-509-102	2nd Stopper Motor: Late	*CTL	[0 to 65535 / 0 / 0]
7-509-103	2nd Stopper Motor: Lag	*CTL	[0 to 65535 / 0 / 0]
7-509-104	Paper Exit Sensor 1: Late	*CTL	[0 to 65535 / 0 / 0]

7-509-105	Paper Exit Sensor 1: Lag	*CTL	[0 to 65535 / 0 / 0]
7-509-108	Paper Exit Sensor 3: Late	*CTL	[0 to 65535 / 0 / 0]
7-509-109	Paper Exit Sensor 3: Lag	*CTL	[0 to 65535 / 0 / 0]
7-509-110	Brushless Motor	*CTL	[0 to 65535 / 0 / 0]
7-509-111	Lower Stopper Motor Jam	*CTL	[0 to 65535 / 0 / 0]
7-509-112	Upper Stopper Motor Jam	*CTL	[0 to 65535 / 0 / 0]
7-509-144	Main Machine Setting Incorrect	*CTL	[0 to 65535 / 0 / 0]
7-509-146	Entrance SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-509-147	Entrance SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-509-148	Folder:Top Tray Exit Sn (Late)	*CTL	[0 to 65535 / 0 / 0]
7-509-149	Folder:Top Tray Exit Sn (Stay on)	*CTL	[0 to 65535 / 0 / 0]
7-509-150	Folder:Horizontal Path Exit Sn (Late)	*CTL	[0 to 65535 / 0 / 0]
7-509-151	Folder:Horizontal Path Exit Sn (Stay on)	*CTL	[0 to 65535 / 0 / 0]
7-509-152	HP SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-509-153	1st Stopper HP SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-509-154	2nd Stopper HP SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-509-155	2nd Stopper HP SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-509-156	3rd Stopper HP SN: Late	*CTL	[0 to 65535 / 0 / 0]

7-509-157	3rd Stopper HP SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-509-158	Registration Sensor	*CTL	[0 to 65535 / 0 / 0]
7-509-159	Folder:Top Tray Paper Path Sensor	*CTL	[0 to 65535 / 0 / 0]
7-509-162	Entrance Junction Solenoid Motor	*CTL	[0 to 65535 / 0 / 0]
7-509-163	1st Stopper Motor Error	*CTL	[0 to 65535 / 0 / 0]
7-509-164	2nd Stopper Motor Error	*CTL	[0 to 65535 / 0 / 0]
7-509-165	3rd Stopper Motor Error	*CTL	[0 to 65535 / 0 / 0]
7-509-166	Movement Roller Up/ Down M Jam	*CTL	[0 to 65535 / 0 / 0]
7-509-167	Regist. Roller Release M Jam	*CTL	[0 to 65535 / 0 / 0]
7-509-168	Fold Plate Motor Jam	*CTL	[0 to 65535 / 0 / 0]
7-509-169	Jogger Fence Motor Jam	*CTL	[0 to 65535 / 0 / 0]
7-509-171	Direct-Send JG Motor Jam	*CTL	[0 to 65535 / 0 / 0]
7-509-172	FM6 Pawl Motor Jam	*CTL	[0 to 65535 / 0 / 0]
7-509-194	Main Machine Setting Incorrect	*CTL	[0 to 65535 / 0 / 0]

7514	[Paper Jam Count by Location]		
7-514-001	At Power On	*CTL	Paper is not fed at power on. [0 to 65535 / 0 / 0]
7-514-003	1st Paper Feed SN: Late	*CTL	[0 to 65535 / 0 / 0]

7-514-004	2nd Paper Feed SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-005	3rd Paper Feed SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-006	4th Paper Feed SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-007	LCT Paper Feed SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-008	1st Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-009	2nd Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-010	3rd Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-011	4th Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-012	Relay SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-013	Registration SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-014	Fusing Exit SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-015	Exit Unit Entrance SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-016	Paper Exit SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-019	Duplex Entrance SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-020	Duplex Transport SN 1: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-021	Duplex Transport SN 2: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-022	Duplex Transport SN 3: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-023	Duplex Exit SN: Late	*CTL	[0 to 65535 / 0 / 0]

7-514-024	LCT Relay SN: Late3	*CTL	[0 to 65535 / 0 / 0]
7-514-034	Bypass Paper Feed SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-045	Sort Tray: Paper Exit SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-046	Sort Tray: Tray Lift Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-047	Sort Tray: Shift Tray Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-053	1st Paper Feed SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-054	2nd Paper Feed SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-055	3rd Paper Feed SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-056	4th Paper Feed SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-057	LCT Paper Feed SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-058	1st Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-059	2nd Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-060	3rd Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-061	4th Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-062	Relay SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-063	Registration SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-066	Paper Exit SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-069	Duplex Entrance SN: Lag	*CTL	[0 to 65535 / 0 / 0]

7-514-071	Duplex Transport SN 2: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-072	Duplex Transport SN 3: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-074	Relay SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-101	Entrance SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-102	Entrance SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-103	Horizontal Trans. SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-104	Horizontal Trans. SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-105	Switchback Trans. SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-106	Switchback Trans. SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-107	Top Tray Exit SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-108	Top Tray Exit SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-109	Shift Tray Exit: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-110	Shift Tray Exit: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-111	Entrance Trans. Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-112	Horizontal Trans. Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-113	Pre-stack Transport Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-114	Relay Transport Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-115	Paper Exit Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-116	Trailing Edge Pressure Plate Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-117	Paper Exit Gate Motor	*CTL	[0 to 65535 / 0 / 0]

7-514-118	Punching Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-119	Punch Shift Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-120	S-to-S Regist. Move Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-121	Lower Junction Gate Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-122	Jogger Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-123	Positioning Roller Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-124	Feed Out Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-125	Corner Stapler Shift Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-126	Corner Stapler Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-130	Output Tray Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-131	Shift Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-132	Shift Tray Jogger Front Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-133	Shift Tray Jogger Rear Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-134	Shift Tray Jogger Retraction Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-135	Stacking Roller Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-136	Leading Edge Guide Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-140	Positioning Roller Transport Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-141	Paper Guide Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-149	Main Machine Setting Incorrect	*CTL	[0 to 65535 / 0 / 0]

7-514-151	Booklet Entrance SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-152	Booklet Duplex Entrance SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-153	Booklet Horizontal Trans. SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-154	Booklet Horizontal Trans. SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-155	Booklet Switchback Trans. SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-156	Booklet Switchback Trans. SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-157	Booklet Top Tray Exit SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-158	Booklet Top Tray Exit SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-159	Booklet Shift Tray Exit: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-160	Booklet Shift Tray Exit: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-161	Booklet Stapler Exit Sn: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-162	Booklet Stapler Exit Sn: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-163	Booklet Entrance Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-164	Booklet Horizontal Trans. Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-165	Booklet Pre-stack Transport Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-166	Booklet Relay Transport Motor	*CTL	[0 to 65535 / 0 / 0]

7-514-167	Booklet Paper Exit Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-168	Booklet Trailing Edge Pressure Plate Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-169	Booklet Paper Exit Gate Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-170	Booklet Punching Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-171	Booklet Punch Shift Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-172	Booklet S-to-S Regist. Move Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-173	Booklet Lower Junction Gate Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-174	Booklet Jogger Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-175	Booklet Positioning Roller Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-176	Booklet Stack Feed-Out Belt Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-177	Booklet Corner Stapler Shift Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-178	Booklet Corner Stapler Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-179	Booklet Jogger Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-180	Booklet Guide Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-181	Booklet Fence Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-182	Booklet Stapler Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-183	Movement Roller Transport Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-184	Folding Transport Motor	*CTL	[0 to 65535 / 0 / 0]

7-514-185	Flat Fold Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-186	Booklet Output Tray Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-187	Booklet Shift Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-188	Booklet Shift Jogger Front Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-189	Booklet Shift Jogger Rear Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-190	Booklet Shift Tray Jogger Retraction Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-191	Booklet Stacking Roller Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-192	Booklet Leading Edge Guide Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-196	Booklet Positioning Roller Transport Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-197	Booklet Paper Guide Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-199	Booklet Main Machine Setting Incorrect	*CTL	[0 to 65535 / 0 / 0]
7-514-201	Entrance Sensor	*CTL	[0 to 65535 / 0 / 0]
7-514-202	Proof Tray Exit	*CTL	[0 to 65535 / 0 / 0]
7-514-203	Shift Tray Exit	*CTL	[0 to 65535 / 0 / 0]
7-514-204	Staple Tray Exit	*CTL	[0 to 65535 / 0 / 0]
7-514-205	Pre-Stack	*CTL	[0 to 65535 / 0 / 0]
7-514-206	Exit After Jogging	*CTL	[0 to 65535 / 0 / 0]
7-514-208	Upper Trans Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-209	Shift Tray Motor	*CTL	[0 to 65535 / 0 / 0]

7-514-210	Positioning Roller Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-211	Jogger Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-212	Stack Plate Motor (Center)	*CTL	[0 to 65535 / 0 / 0]
7-514-213	Stack Plate Motor (Front)	*CTL	[0 to 65535 / 0 / 0]
7-514-214	Stack Plate Motor (Rear)	*CTL	[0 to 65535 / 0 / 0]
7-514-215	Shift Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-216	Drag Drive Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-217	Shift Tray Jogger Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-218	Shift Tray Jogger Retraction Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-219	Exit Guide Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-220	Staple Hammer Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-221	Stapler Movement Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-222	Stapler Rotation Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-223	Stack Feed-Out Belt Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-224	Punch Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-225	Top Fence Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-226	Bottom Fence Motor	*CTL	[0 to 65535 / 0 / 0]
7-514-247	Main Machine Setting Incorrect	*CTL	[0 to 65535 / 0 / 0]
7-514-249	GBC Jam	*CTL	[0 to 65535 / 0 / 0]
7-514-251	1st Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]

7-514-252	1st Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-253	2nd Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-514-254	2nd Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-514-255	3rd Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]

7515	[Original Jam Count by Detection]		
7-515-001	At Power On	*CTL	[0 to 65535 / 0 / 0]
7-515-013	Separation Sensor: Late	*CTL	[0 to 65535 / 0 / 0]
7-515-014	Skew Correction Sn: Late	*CTL	[0 to 65535 / 0 / 0]
7-515-015	Scanning Entrance Sn: Late	*CTL	[0 to 65535 / 0 / 0]
7-515-016	Registration Sensor: Late	*CTL	[0 to 65535 / 0 / 0]
7-515-017	Original Exit Sensor: Late	*CTL	[0 to 65535 / 0 / 0]
7-515-063	Separation Sensor: Lag	*CTL	[0 to 65535 / 0 / 0]
7-515-064	Skew Correction Sn: Lag	*CTL	[0 to 65535 / 0 / 0]
7-515-065	Scanning Entrance Sn: Lag	*CTL	[0 to 65535 / 0 / 0]
7-515-066	Registration Sensor: Lag	*CTL	[0 to 65535 / 0 / 0]
7-515-067	Original Exit Sensor: Lag	*CTL	[0 to 65535 / 0 / 0]
7-515-239	Original Pull	*CTL	[0 to 65535 / 0 / 0]

7516	[Jam Paper Size Cnt]		
	Displays occurring count of transfer paper jams by each paper size.		

7-516-005	A4 LEF	*CTL	[0 to 65535 / 0 / 0]
7-516-006	A5 LEF	*CTL	
7-516-014	B5 LEF	*CTL	
7-516-038	LT LEF	*CTL	
7-516-044	HLT LEF	*CTL	
7-516-132	A3 SEF	*CTL	[0 to 65535 / 0 / 0]
7-516-133	A4 SEF	*CTL	
7-516-134	A5 SEF	*CTL	
7-516-141	B4 SEF	*CTL	
7-516-142	B5 SEF	*CTL	
7-516-160	DLT SEF	*CTL	[0 to 65535 / 0 / 0]
7-516-164	LG SEF	*CTL	
7-516-166	LT SEF	*CTL	
7-516-172	HLT SEF	*CTL	
7-516-255	Others	*CTL	

7519	[Paper Jam Count by Location]		
7-519-001	3rd Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-519-002	4th Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-519-003	4th Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-519-004	5th Vertical Transport SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-519-005	5th Vertical Transport SN: Lag	*CTL	[0 to 65535 / 0 / 0]

7-519-044	Main Machine Setting Incorrect	*CTL	[0 to 65535 / 0 / 0]
7-519-046	Cover Feeder: Paper Feed SN: Late or Lag	*CTL	[0 to 65535 / 0 / 0]
7-519-047	Cover Feeder: Paper Exit SN: Late or Lag	*CTL	[0 to 65535 / 0 / 0]
7-519-048	Cover Feeder: Bottom Plate Mtr: Late or Lag	*CTL	[0 to 65535 / 0 / 0]
7-519-096	Paper Feed: Late	*CTL	[0 to 65535 / 0 / 0]
7-519-097	Paper Feed: Lag	*CTL	[0 to 65535 / 0 / 0]
7-519-098	Pressure Timing SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-519-099	Pressure Timing SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-519-100	Contact Timing SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-519-101	Contact Timing SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-519-102	2nd Stopper Motor: Late	*CTL	[0 to 65535 / 0 / 0]
7-519-103	2nd Stopper Motor: Lag	*CTL	[0 to 65535 / 0 / 0]
7-519-104	Paper Exit Sensor 1: Late	*CTL	[0 to 65535 / 0 / 0]
7-519-105	Paper Exit Sensor 1: Lag	*CTL	[0 to 65535 / 0 / 0]
7-519-108	Paper Exit Sensor 3: Late	*CTL	[0 to 65535 / 0 / 0]
7-519-109	Paper Exit Sensor 3: Lag	*CTL	[0 to 65535 / 0 / 0]
7-519-110	Brushless Motor	*CTL	[0 to 65535 / 0 / 0]
7-519-111	Lower Stopper Motor Jam	*CTL	[0 to 65535 / 0 / 0]
7-519-112	Upper Stopper Motor Jam	*CTL	[0 to 65535 / 0 / 0]
7-519-144	Main Machine Setting Incorrect	*CTL	[0 to 65535 / 0 / 0]
7-519-146	Entrance SN: Late	*CTL	[0 to 65535 / 0 / 0]

7-519-147	Entrance SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-519-148	Folder:Top Tray Exit Sn (Late)	*CTL	[0 to 65535 / 0 / 0]
7-519-149	Folder:Top Tray Exit Sn (Stay on)	*CTL	[0 to 65535 / 0 / 0]
7-519-150	Folder:Horizontal Path Exit Sn (Late)	*CTL	[0 to 65535 / 0 / 0]
7-519-151	Folder:Horizontal Path Exit Sn (Stay on)	*CTL	[0 to 65535 / 0 / 0]
7-519-152	HP SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-519-153	1st Stopper HP SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-519-154	2nd Stopper HP SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-519-155	2nd Stopper HP SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-519-156	3rd Stopper HP SN: Late	*CTL	[0 to 65535 / 0 / 0]
7-519-157	3rd Stopper HP SN: Lag	*CTL	[0 to 65535 / 0 / 0]
7-519-158	Registration Sensor	*CTL	[0 to 65535 / 0 / 0]
7-519-159	Folder:Top Tray Paper Path Sensor	*CTL	[0 to 65535 / 0 / 0]
7-519-162	Entrance Junction Solenoid Motor	*CTL	[0 to 65535 / 0 / 0]
7-519-163	1st Stopper Motor Error	*CTL	[0 to 65535 / 0 / 0]
7-519-164	2nd Stopper Motor Error	*CTL	[0 to 65535 / 0 / 0]
7-519-165	3rd Stopper Motor Error	*CTL	[0 to 65535 / 0 / 0]
7-519-166	Movement Roller Up/Down M Jam	*CTL	[0 to 65535 / 0 / 0]
7-519-167	Regist. Roller Release M Jam	*CTL	[0 to 65535 / 0 / 0]
7-519-168	Fold Plate Motor Jam	*CTL	[0 to 65535 / 0 / 0]
7-519-169	Jogger Fence Motor Jam	*CTL	[0 to 65535 / 0 / 0]

7-519-171	Direct-Send JG Motor Jam	* CTL	[0 to 65535 / 0 / 0]
7-519-172	FM6 Pawl Motor Jam	* CTL	[0 to 65535 / 0 / 0]
7-519-194	Main Machine Setting Incorrect	* CTL	[0 to 65535 / 0 / 0]

7520	[Update Log]		
7-520-001	ErrorRecord1	* CTL	[0 to 255 / 0 / 1]
7-520-002	ErrorRecord2	* CTL	[0 to 255 / 0 / 1]
7-520-003	ErrorRecord3	* CTL	[0 to 255 / 0 / 1]
7-520-004	ErrorRecord4	* CTL	[0 to 255 / 0 / 1]
7-520-005	ErrorRecord5	* CTL	[0 to 255 / 0 / 1]
7-520-006	ErrorRecord6	* CTL	[0 to 255 / 0 / 1]
7-520-007	ErrorRecord7	* CTL	[0 to 255 / 0 / 1]
7-520-008	ErrorRecord8	* CTL	[0 to 255 / 0 / 1]
7-520-009	ErrorRecord9	* CTL	[0 to 255 / 0 / 1]
7-520-010	ErrorRecord10	* CTL	[0 to 255 / 0 / 1]
7-520-011	Auto:StartDate1	* CTL	[0 to 0 / 0 / 0]
7-520-012	Auto:StartDate2	* CTL	[0 to 0 / 0 / 0]
7-520-013	Auto:StartDate3	* CTL	[0 to 0 / 0 / 0]
7-520-014	Auto:StartDate4	* CTL	[0 to 0 / 0 / 0]
7-520-015	Auto:StartDate5	* CTL	[0 to 0 / 0 / 0]
7-520-021	Auto:EndDate1	* CTL	[0 to 0 / 0 / 0]
7-520-022	Auto:EndDate2	* CTL	[0 to 0 / 0 / 0]
7-520-023	Auto:EndDate3	* CTL	[0 to 0 / 0 / 0]
7-520-024	Auto:EndDate4	* CTL	[0 to 0 / 0 / 0]
7-520-025	Auto:EndDate5	* CTL	[0 to 0 / 0 / 0]

7-520-031	Auto:Piecemark1	*CTL	[0 to 0 / 0 / 0]
7-520-032	Auto:Piecemark2	*CTL	[0 to 0 / 0 / 0]
7-520-033	Auto:Piecemark3	*CTL	[0 to 0 / 0 / 0]
7-520-034	Auto:Piecemark4	*CTL	[0 to 0 / 0 / 0]
7-520-035	Auto:Piecemark5	*CTL	[0 to 0 / 0 / 0]
7-520-041	Auto:Version1	*CTL	[0 to 0 / 0 / 0]
7-520-042	Auto:Version2	*CTL	[0 to 0 / 0 / 0]
7-520-043	Auto:Version3	*CTL	[0 to 0 / 0 / 0]
7-520-044	Auto:Version4	*CTL	[0 to 0 / 0 / 0]
7-520-045	Auto:Version5	*CTL	[0 to 0 / 0 / 0]
7-520-051	Auto:Result1	*CTL	[0 to 255 / 0 / 1]
7-520-052	Auto:Result2	*CTL	[0 to 255 / 0 / 1]
7-520-053	Auto:Result3	*CTL	[0 to 255 / 0 / 1]
7-520-054	Auto:Result4	*CTL	[0 to 255 / 0 / 1]
7-520-055	Auto:Result5	*CTL	[0 to 255 / 0 / 1]
7-520-056	Auto:Result6	*CTL	[0 to 255 / 0 / 1]
7-520-057	Auto:Result7	*CTL	[0 to 255 / 0 / 1]
7-520-058	Auto:Result8	*CTL	[0 to 255 / 0 / 1]
7-520-059	Auto:Result9	*CTL	[0 to 255 / 0 / 1]
7-520-060	Auto:Result10	*CTL	[0 to 255 / 0 / 1]

7624	[Parts Replacement Operation ON/OFF]		
7-624-001	Developer	*CTL	[0 or 1 / 1 / 1]
7-624-002	Fuser Unit:Fusing Roller	*CTL	[0 or 1 / 1 / 1]
7-624-003	Fuser Unit:Pressure Roller	*CTL	[0 or 1 / 1 / 1]

7-624-004	Fuser Unit:FusingR:Bearings	*CTL	[0 or 1 / 1 / 1]
7-624-005	Fuser Unit:PressR:Bearings	*CTL	[0 or 1 / 1 / 1]
7-624-006	Hot Roller Strippers	*CTL	[0 or 1 / 1 / 1]
7-624-007	Cleaning Roller	*CTL	[0 or 1 / 1 / 1]
7-624-008	Cleaning Roller Bearings	*CTL	[0 or 1 / 1 / 1]
7-624-009	Web Roll	*CTL	[0 or 1 / 1 / 1]
7-624-010	Web Cleaning Roller	*CTL	[0 or 1 / 1 / 1]
7-624-011	Development Filter	*CTL	[0 or 1 / 1 / 1]
7-624-012	Toner Recycling Unit	*CTL	[0 or 1 / 1 / 1]
7-624-013	Pressure Release Filter	*CTL	[0 or 1 / 1 / 1]
7-624-014	Charge Corona Wire	*CTL	[0 or 1 / 1 / 1]
7-624-015	Grid Plate	*CTL	[0 or 1 / 1 / 1]
7-624-016	Cleaning Pad	*CTL	[0 or 1 / 1 / 1]
7-624-017	Clearing Bleed	*CTL	[0 or 1 / 1 / 1]
7-624-018	Cleaning Brush	*CTL	[0 or 1 / 1 / 1]
7-624-019	Transfer Belt	*CTL	[0 or 1 / 1 / 1]
7-624-020	Transfer Belt Cleaning Blade	*CTL	[0 or 1 / 1 / 1]
7-624-022	ADF Pick-up Roller	*CTL	[0 or 1 / 1 / 1]
7-624-023	ADF Feed Belt	*CTL	[0 or 1 / 1 / 1]
7-624-024	ADF Separation Roller	*CTL	[0 or 1 / 1 / 1]
7-624-025	Tray1:Pickup Roller	*CTL	[0 or 1 / 1 / 1]
7-624-026	Tray1:Feed Roller	*CTL	[0 or 1 / 1 / 1]
7-624-027	Tray1:Separate Roller	*CTL	[0 or 1 / 1 / 1]
7-624-028	Tray2:Pickup Roller	*CTL	[0 or 1 / 1 / 1]

7-624-029	Tray2:Feed Roller	*CTL	[0 or 1 / 1 / 1]
7-624-030	Tray2:Separate Roller	*CTL	[0 or 1 / 1 / 1]
7-624-031	Feed Roller-Tray3	*CTL	[0 or 1 / 1 / 1]
7-624-032	Pick-up Roller-Tray3	*CTL	[0 or 1 / 1 / 1]
7-624-033	Separation Roller-Tray3	*CTL	[0 or 1 / 1 / 1]
7-624-034	Feed Roller-Tray4	*CTL	[0 or 1 / 1 / 1]
7-624-035	Pick-up Roller-Tray4	*CTL	[0 or 1 / 1 / 1]
7-624-036	Separation Roller-Tray4	*CTL	[0 or 1 / 1 / 1]
7-624-037	Feed Roller-LCT	*CTL	[0 or 1 / 1 / 1]
7-624-038	Pick-up Roller-LCT	*CTL	[0 or 1 / 1 / 1]
7-624-039	Separation Roller-LCT	*CTL	[0 or 1 / 1 / 1]
7-624-040	Feed Belt Cover feeder	*CTL	[0 or 1 / 1 / 1]
7-624-041	Pick-up Roller Cover feeder	*CTL	[0 or 1 / 1 / 1]
7-624-042	Separation Roller Cover feeder	*CTL	[0 or 1 / 1 / 1]
7-624-044	Thermistor Fusing unit Rearr	*CTL	[0 or 1 / 1 / 1]
7-624-045	Thermistor Fusing unit Center	*CTL	[0 or 1 / 1 / 1]
7-624-046	Dust Filter	*CTL	[0 or 1 / 1 / 1]
7-624-047	Main Tray (Custom 1)	*CTL	[0 or 1 / 1 / 1]
7-624-048	Main Tray (Custom 2)	*CTL	[0 or 1 / 1 / 1]
7-624-049	Main Tray (Custom 3)	*CTL	[0 or 1 / 1 / 1]
7-624-050	Main Tray (Custom 4)	*CTL	[0 or 1 / 1 / 1]
7-624-051	Paper Tray1 (Custom 1)	*CTL	[0 or 1 / 1 / 1]
7-624-052	Paper Tray1 (Custom 2)	*CTL	[0 or 1 / 1 / 1]

7-624-053	Paper Tray2 (Custom 1)	*CTL	[0 or 1 / 1 / 1]
7-624-054	Paper Tray2 (Custom 2)	*CTL	[0 or 1 / 1 / 1]
7-624-055	Paper Tray3 (Custom 1)	*CTL	[0 or 1 / 1 / 1]
7-624-056	Paper Tray3 (Custom 2)	*CTL	[0 or 1 / 1 / 1]
7-624-057	Paper Tray4 (Custom 1)	*CTL	[0 or 1 / 1 / 1]
7-624-058	Paper Tray4 (Custom 2)	*CTL	[0 or 1 / 1 / 1]
7-624-059	LCT (Custom 1)	*CTL	[0 or 1 / 1 / 1]
7-624-060	LCT (Custom 2)	*CTL	[0 or 1 / 1 / 1]
7-624-063	Interposer (Custom 1)	*CTL	[0 or 1 / 1 / 1]
7-624-064	Interposer (Custom 2)	*CTL	[0 or 1 / 1 / 1]
7-624-065	Wast Toner Bottle	*CTL	[0 or 1 / 1 / 1]
7-624-066	Ozon Filter (Custom 1)	*CTL	[0 or 1 / 1 / 1]

7801	[ROM No./ Firmware Version]		
7-801-255	-	CTL	-

7803	[PM Counter Display]		
7-803-001	Paper	*CTL	[0 to 999999 / 0 / 1/step]

7804	[PM Counter Reset]		
7-804-001	Paper	CTL	[- / - / -] [Execute]

7807	[SC/Jam Counter Reset]		
7-807-001	-	*CTL	[- / - / -] [Execute]

7826	[MF Error Counter]		
-------------	---------------------------	--	--

7-826-001	Error Total	*CTL	[0 to 99999999 / - / 0]
7-826-002	Error Staple	*CTL	[0 to 99999999 / - / 0]

7827	[MF Error Counter Clear]		
7-827-001	-	*CTL	[- / - / -] [Execute]

7832	[Self-Diagnose Result Display]		
7-832-001	-	CTL	[- / - / -] [Execute]

7836	[Total Memory Size]		
Displays the memory capacity of the controller system.			
7-836-001	Total Memory Size	CTL	[0 to 0xffffffff / 0 / 0 MB / step]

7840	[Service SP Entry Code Chg Hist]		
7-840-001	Change Time :Latest	*CTL	[- / - / -]
7-840-002	Change Time : Last1	*CTL	[- / - / -]
7-840-101	Initialize Time : Latest	*CTL	[- / - / -]
7-840-102	Initialize Time : Last1	*CTL	[- / - / -]

7901	[Assert Info.]		
7-901-001	File Name	*CTL	[- / - / -]
7-901-002	Number of Lines	*CTL	[- / - / -]
7-901-003	Location	*CTL	[- / - / -]

7910	[ROM No]		
7-910-001	System/Copy	CTL	[0 to 0 / 0 / 0]
7-910-002	Engine	CTL	[0 to 0 / 0 / 0]

7-910-003	Lcdc	CTL	[0 to 0 / 0 / 0]
7-910-005	ADF	CTL	[0 to 0 / 0 / 0]
7-910-007	Finisher1	CTL	[0 to 0 / 0 / 0]
7-910-009	Bank	CTL	[0 to 0 / 0 / 0]
7-910-010	LCT	CTL	[0 to 0 / 0 / 0]
7-910-011	Mail Box	CTL	[0 to 0 / 0 / 0]
7-910-012	FCU	CTL	[0 to 0 / 0 / 0]
7-910-018	NetworkSupport	CTL	[0 to 0 / 0 / 0]
7-910-020	Cover Interposer	CTL	[0 to 0 / 0 / 0]
7-910-022	BIOS	CTL	[0 to 0 / 0 / 0]
7-910-023	HDD Format Option	CTL	[0 to 0 / 0 / 0]
7-910-024	Capacitor	CTL	[0 to 0 / 0 / 0]
7-910-025	Folding Unit	CTL	[0 to 0 / 0 / 0]
7-910-150	RPCS	CTL	[0 to 0 / 0 / 0]
7-910-151	PS	CTL	[0 to 0 / 0 / 0]
7-910-152	RPDL	CTL	[0 to 0 / 0 / 0]
7-910-156	R55	CTL	[0 to 0 / 0 / 0]
7-910-157	RTIFF	CTL	[0 to 0 / 0 / 0]
7-910-158	PCL	CTL	[0 to 0 / 0 / 0]
7-910-159	PCLXL	CTL	[0 to 0 / 0 / 0]
7-910-160	MSIS	CTL	[0 to 0 / 0 / 0]
7-910-162	PDF	CTL	[0 to 0 / 0 / 0]
7-910-165	PJL	CTL	[0 to 0 / 0 / 0]
7-910-166	IPDS	CTL	[0 to 0 / 0 / 0]
7-910-167	MediaPrint:JPEG	CTL	[0 to 0 / 0 / 0]
7-910-168	MediaPrint:TIFF	CTL	[0 to 0 / 0 / 0]

7-910-169	XPS	CTL	[0 to 0 / 0 / 0]
7-910-180	FONT	CTL	[0 to 0 / 0 / 0]
7-910-181	FONT1	CTL	[0 to 0 / 0 / 0]
7-910-182	FONT2	CTL	[0 to 0 / 0 / 0]
7-910-183	FONT3	CTL	[0 to 0 / 0 / 0]
7-910-184	FONT4	CTL	[0 to 0 / 0 / 0]
7-910-185	FONT5	CTL	[0 to 0 / 0 / 0]
7-910-200	Factory	CTL	[0 to 0 / 0 / 0]
7-910-201	Copy	CTL	[0 to 0 / 0 / 0]
7-910-202	NetworkDocBox	CTL	[0 to 0 / 0 / 0]
7-910-203	Fax	CTL	[0 to 0 / 0 / 0]
7-910-204	Printer	CTL	[0 to 0 / 0 / 0]
7-910-205	Scanner	CTL	[0 to 0 / 0 / 0]
7-910-206	RFax	CTL	[0 to 0 / 0 / 0]
7-910-210	MIB	CTL	[0 to 0 / 0 / 0]
7-910-211	Websupport	CTL	[0 to 0 / 0 / 0]
7-910-212	WebUapl	CTL	[0 to 0 / 0 / 0]
7-910-213	SDK1	CTL	[0 to 0 / 0 / 0]
7-910-214	SDK2	CTL	[0 to 0 / 0 / 0]
7-910-215	SDK3	CTL	[0 to 0 / 0 / 0]
7-910-250	Package	CTL	[0 to 0 / 0 / 0]

7911	[Firmware Version]		
7-911-001	System/Copy	CTL	[0 to 0 / 0 / 0]
7-911-002	Engine	CTL	[0 to 0 / 0 / 0]
7-911-003	Lcdc	CTL	[0 to 0 / 0 / 0]

7-911-005	ADF	CTL	[0 to 0 / 0 / 0]
7-911-007	Finisher1	CTL	[0 to 0 / 0 / 0]
7-911-009	Bank	CTL	[0 to 0 / 0 / 0]
7-911-010	LCT	CTL	[0 to 0 / 0 / 0]
7-911-011	Mail Box	CTL	[0 to 0 / 0 / 0]
7-911-012	FCU	CTL	[0 to 0 / 0 / 0]
7-911-018	NetworkSupport	CTL	[0 to 0 / 0 / 0]
7-911-020	Cover Interposer	CTL	[0 to 0 / 0 / 0]
7-911-022	BIOS	CTL	[0 to 0 / 0 / 0]
7-911-023	HDD Format Option	CTL	[0 to 0 / 0 / 0]
7-911-024	Capacitor	CTL	[0 to 0 / 0 / 0]
7-911-025	Folding Unit	CTL	[0 to 0 / 0 / 0]
7-911-150	RPCS	CTL	[0 to 0 / 0 / 0]
7-911-151	PS	CTL	[0 to 0 / 0 / 0]
7-911-152	RPDL	CTL	[0 to 0 / 0 / 0]
7-911-156	R55	CTL	[0 to 0 / 0 / 0]
7-911-157	RTIFF	CTL	[0 to 0 / 0 / 0]
7-911-158	PCL	CTL	[0 to 0 / 0 / 0]
7-911-159	PCLXL	CTL	[0 to 0 / 0 / 0]
7-911-160	MSIS	CTL	[0 to 0 / 0 / 0]
7-911-162	PDF	CTL	[0 to 0 / 0 / 0]
7-911-165	PJL	CTL	[0 to 0 / 0 / 0]
7-911-166	IPDS	CTL	[0 to 0 / 0 / 0]
7-911-167	MediaPrint:JPEG	CTL	[0 to 0 / 0 / 0]
7-911-168	MediaPrint:TIFF	CTL	[0 to 0 / 0 / 0]
7-911-169	XPS	CTL	[0 to 0 / 0 / 0]

7-911-180	FONT	CTL	[0 to 0 / 0 / 0]
7-911-181	FONT1	CTL	[0 to 0 / 0 / 0]
7-911-182	FONT2	CTL	[0 to 0 / 0 / 0]
7-911-183	FONT3	CTL	[0 to 0 / 0 / 0]
7-911-184	FONT4	CTL	[0 to 0 / 0 / 0]
7-911-185	FONT5	CTL	[0 to 0 / 0 / 0]
7-911-200	Factory	CTL	[0 to 0 / 0 / 0]
7-911-201	Copy	CTL	[0 to 0 / 0 / 0]
7-911-202	NetworkDocBox	CTL	[0 to 0 / 0 / 0]
7-911-203	Fax	CTL	[0 to 0 / 0 / 0]
7-911-204	Printer	CTL	[0 to 0 / 0 / 0]
7-911-205	Scanner	CTL	[0 to 0 / 0 / 0]
7-911-206	RFax	CTL	[0 to 0 / 0 / 0]
7-911-210	MIB	CTL	[0 to 0 / 0 / 0]
7-911-211	Websupport	CTL	[0 to 0 / 0 / 0]
7-911-212	WebUapl	CTL	[0 to 0 / 0 / 0]
7-911-213	SDK1	CTL	[0 to 0 / 0 / 0]
7-911-214	SDK2	CTL	[0 to 0 / 0 / 0]
7-911-215	SDK3	CTL	[0 to 0 / 0 / 0]
7-911-250	Package	CTL	[0 to 0 / 0 / 0]

Controller SP Tables-8

SP8-XXX (Data Log2)

Many of these counters are provided for features that are currently not available, such as sending color faxes, and so on. However, here are some Group 8 codes that when used in combination with others, can provide useful information.

3

SP Numbers	What They Do
SP8211 to SP8216	The number of pages scanned to the document server.
SP8401 to SP8406	The number of pages printed from the document server.
SP8691 to SP8696	The number of pages sent from the document server.

Specifically, the following questions can be answered:

- How is the document server actually being used?
- What application is using the document server most frequently?
- What data in the document server is being reused?

Most of the SPs in this group are prefixed with a letter that indicates the mode of operation (the mode of operation is referred to as an "application"). Before reading the Group 8 Service Table, make sure that you understand what these prefixes mean.

Prefixes	What it means	
T:	Total: (Grand Total).	Grand total of the items counted for all applications (C, F, P, etc.).
C:	Copy application.	Totals (pages, jobs, etc.) executed for each application when the job was not stored on the document server.
F:	Fax application.	
P:	Print application.	
S:	Scan application.	

Prefixes	What it means	
L:	Local storage (document server)	Totals (jobs, pages, etc.) for the document server. The L: counters work differently case by case. Sometimes, they count jobs/pages stored on the document server; this can be in document server mode (from the document server window), or from another mode, such as from a printer driver or by pressing the Store File button in the Copy mode window. Sometimes, they include occasions when the user uses a file that is already on the document server. Each counter will be discussed case by case.
O:	Other applications (external network applications, for example)	Refers to network applications such as Web Image Monitor. Utilities developed with the SDK (Software Development Kit) will also be counted with this group in the future.

The Group 8 SP codes are limited to 17 characters, forced by the necessity of displaying them on the small LCDs of printers and faxes that also use these SPs. Read over the list of abbreviations below and refer to it again if you see the name of an SP that you do not understand.

Key for Abbreviations

Abbreviation	What it means
/	"By", e.g. "T:Jobs/Apl" = Total Jobs "by" Application
>	More (2> "2 or more", 4> "4 or more")
AddBook	Address Book
Apl	Application
B/W	Black & White
Bk	Black
C	Cyan
ColCr	Color Create
ColMode	Color Mode
Comb	Combine
Comp	Compression
Deliv	Delivery

Abbreviation	What it means
DesApl	Designated Application. The application (Copy, Fax, Scan, Print) used to store the job on the document server, for example.
Dev Counter	Development Count, no. of pages developed.
Dup, Duplex	Duplex, printing on both sides
Emul	Emulation
FC	Full Color
FIN	Post-print processing, i.e. finishing (punching, stapling, etc.)
Full Bleed	No Margins
GenCopy	Generation Copy Mode
GPC	Get Print Counter. For jobs 10 pages or less, this counter does not count up. For jobs larger than 10 pages, this counter counts up by the number that is in excess of 10 (e.g., for an 11-page job, the counter counts up $11-10=1$)
IFax	Internet Fax
ImgEdt	Image Edit performed on the original with the copier GUI, e.g. border removal, adding stamps, page numbers, etc.
K	Black (YMCK)
LS	Local Storage. Refers to the document server.
LSize	Large (paper) Size
Mag	Magnification
MC	One color (monochrome)
NRS	New Remote Service, which allows a service center to monitor machines remotely. "NRS" is used overseas, "CSS" is used in Japan.
Org	Original for scanning
OrgJam	Original Jam

Abbreviation	What it means
Palm 2	Print Job Manager/Desk Top Editor: A pair of utilities that allows print jobs to be distributed evenly among the printers on the network, and allows files to moved around, combined, and converted to different formats.
PC	Personal Computer
PGS	Pages. A page is the total scanned surface of the original. Duplex pages count as two pages, and A3 simplex count as two pages if the A3/DLT counter SP is switched ON.
PJob	Print Jobs
Ppr	Paper
PrtJam	Printer (plotter) Jam
PrtPGS	Print Pages
R	Red (Toner Remaining). Applies to the wide format model A2 only. This machine is under development and currently not available.
Rez	Resolution
SC	Service Code (Error SC code displayed)
Scn	Scan
Sim, Simplex	Simplex, printing on 1 side.
S-to-Email	Scan-to-E-mail
SMC	SMC report printed with SP5990. All of the Group 8 counters are recorded in the SMC report.
Svr	Server
TonEnd	Toner End
TonSave	Toner Save
TXJob	Send, Transmission
YMC	Yellow, Magenta, Cyan
YMCK	Yellow, Magenta, Cyan, Black

 **Note**

- All of the Group 8 SPs are reset with SP5 801 1 Memory All Clear.

8001	T:Total Jobs	*CTL	<p>These SPs count the number of times each application is used to do a job.</p> <p>[0 to 99999999 / 0 / 1/step]</p> <p>Note: The L: counter is the total number of times the other applications are used to send a job to the document server, plus the number of times a file already on the document server is used.</p>
8002	C:Total Jobs	*CTL	
8003	F:Total Jobs	*CTL	
8004	P:Total Jobs	*CTL	
8005	S:Total Jobs	*CTL	
8006	L:Total Jobs	*CTL	

- These SPs reveal the number of times an application is used, not the number of pages processed.
- When an application is opened for image input or output, this counts as one job.
- Interrupted jobs (paper jams, etc.) are counted, even though they do not finish.
- Only jobs executed by the customer are counted. Jobs executed by the customer engineer using the SP modes are not counted.
- When using secure printing (when a password is required to start the print job), the job is counted at the time when either "Delete Data" or "Specify Output" is specified.
- A job is counted as a fax job when the job is stored for sending.
- When a fax is received to fax memory, the F: counter increments but the L: counter does not (the document server is not used).
- A fax broadcast counts as one job for the F: counter (the fax destinations in the broadcast are not counted separately).
- A fax broadcast is counted only after all the faxes have been sent to their destinations. If one transmission generates an error, then the broadcast will not be counted until the transmission has been completed.
- A printed fax report counts as one job for the F: counter.
- The F: counter does not distinguish between fax sending or receiving.
- When a copy job on the document server is printed, SP8022 also increments, and when a print job stored on the document server is printed, SP8024 also increments.
- When an original is both copied and stored on the document server, the C: and L: counters both increment.
- When a print job is stored on the document server, only the L: counter increments.
- When the user presses the Document Server button to store the job on the document server, only the L: counter increments.

- When the user enters document server mode and prints data stored on the document server, only the L: counter increments.
- When an image received from Palm 2 is received and stored, the L: counter increments.
- When the customer prints a report (user code list, for example), the O: counter increments. However, for fax reports and reports executed from the fax application, the F: counter increments.

8011	T:Jobs/LS	*CTL	These SPs count the number of jobs stored to the document server by each application, to reveal how local storage is being used for input. [0 to 99999999 / 0 / 1/step] The L: counter counts the number of jobs stored from within the document server mode screen at the operation panel.
8012	C:Jobs/LS	*CTL	
8013	F:Jobs/LS	*CTL	
8014	P:Jobs/LS	*CTL	
8015	S:Jobs/LS	*CTL	
8016	L:Jobs/LS	*CTL	
8017	O:Jobs/LS	*CTL	

- When a scan job is sent to the document server, the S: counter increments. When you enter document server mode and then scan an original, the L: counter increments.
- When a print job is sent to the document server, the P: counter increments.
- When a network application sends data to the document server, the O: counter increments.
- When an image from Palm 2 is stored on the document server, the O: counter increments.
- When a fax is sent to the document server, the F: counter increments.

8021	T:Pjob/LS	*CTL	These SPs reveal how files printed from the document server were stored on the document server originally. [0 to 99999999 / 0 / 1/step] The L: counter counts the number of jobs stored from within the document server mode screen at the operation panel.
8022	C:Pjob/LS	*CTL	
8023	F:Pjob/LS	*CTL	
8024	P:Pjob/LS	*CTL	
8025	S:Pjob/LS	*CTL	
8026	L:Pjob/LS	*CTL	
8027	O:Pjob/LS	*CTL	

- When a copy job stored on the document server is printed with another application, the C: counter increments.

- When an application like DeskTopBinder merges a copy job that was stored on the document server with a print job that was stored on the document server, the C: and P: counters both increment.
- When a job already on the document server is printed with another application, the L: counter increments.
- When a scanner job stored on the document server is printed with another application, the S: counter increments. If the original was scanned from within document server mode, then the L: counter increments.
- When images stored on the document server by a network application (including Palm 2), are printed with another application, the O: counter increments.
- When a copy job stored on the document server is printed with a network application (Web Image Monitor, for example), the C: counter increments.
- When a fax on the document server is printed, the F: counter increments.

8031	T:Pjob/DesApl	*CTL	These SPs reveal what applications were used to output documents from the document server. [0 to 99999999 / 0 / 1/step] The L: counter counts the number of jobs printed from within the document server mode screen at the operation panel.
8032	C:Pjob/DesApl	*CTL	
8033	F:Pjob/DesApl	*CTL	
8034	P:Pjob/DesApl	*CTL	
8035	S:Pjob/DesApl	*CTL	
8036	L:Pjob/DesApl	*CTL	
8037	O:Pjob/DesApl	*CTL	

- When documents already stored on the document server are printed, the count for the application that started the print job is incremented.
- When the print job is started from a network application (Desk Top Binder, Web Image Monitor, etc.) the L: counter increments.

8041	T:TX Jobs/LS	* CTL	These SPs count the applications that stored files on the document server that were later accessed for transmission over the telephone line or over a network (attached to an e-mail, or as a fax image by I-Fax). [0 to 99999999/ 0 / 1/step] Note: Jobs merged for sending are counted separately. The L: counter counts the number of jobs scanned from within the document server mode screen at the operation panel.
8042	C:TX Jobs/LS	* CTL	
8043	F:TX Jobs/LS	* CTL	
8044	P:TX Jobs/LS	* CTL	
8045	S:TX Jobs/LS	* CTL	
8046	L:TX Jobs/LS	* CTL	
8047	O:TX Jobs/LS	* CTL	

- When a stored copy job is sent from the document server, the C: counter increments.
- When images stored on the document server by a network application or Palm2 are sent as an e-mail, the O: counter increments.

8051	T:TX Jobs/DesApl	* CTL	These SPs count the applications used to send files from the document server over the telephone line or over a network (attached to an e-mail, or as a fax image by I-Fax). Jobs merged for sending are counted separately. [0 to 99999999/ 0 / 1/step] The L: counter counts the number of jobs sent from within the document server mode screen at the operation panel.
8052	C:TX Jobs/DesApl	* CTL	
8053	F:TX Jobs/DesApl	* CTL	
8054	P:TX Jobs/DesApl	* CTL	
8055	S:TX Jobs/DesApl	* CTL	
8056	L:TX Jobs/DesApl	* CTL	
8057	O:TX Jobs/DesApl	* CTL	

- If the send is started from Desk Top Binder or Web Image Monitor, for example, then the O: counter increments.

8061	T:FIN Jobs	* CTL	[0 to 99999999/ 0 / 1/step]
	These SPs total the finishing methods. The finishing method is specified by the application.		
8062	C:FIN Jobs	* CTL	[0 to 99999999/ 0 / 1/step]
	These SPs total finishing methods for copy jobs only. The finishing method is specified by the application.		

8063	F:FIN Jobs	*CTL	[0 to 99999999/ 0 / 1/step]
	<p>These SPs total finishing methods for fax jobs only. The finishing method is specified by the application.</p> <p>Note: Finishing features for fax jobs are not available at this time.</p>		
8064	P:FIN Jobs	*CTL	[0 to 99999999/ 0 / 1/step]
	<p>These SPs total finishing methods for print jobs only. The finishing method is specified by the application.</p>		
8065	S:FIN Jobs	*CTL	[0 to 99999999/ 0 / 1/step]
	<p>These SPs total finishing methods for scan jobs only. The finishing method is specified by the application.</p> <p>Note: Finishing features for scan jobs are not available at this time.</p>		
8066	L:FIN Jobs	*CTL	[0 to 99999999/ 0 / 1/step]
	<p>These SPs total finishing methods for jobs output from within the document server mode screen at the operation panel. The finishing method is specified from the print window within document server mode.</p>		
8067	O:FIN Jobs	*CTL	[0 to 99999999/ 0 / 1/step]
	<p>These SPs total finishing methods for jobs executed by an external application, over the network. The finishing method is specified by the application.</p>		

Last three digits for SP8 061 to 067

806x-001	Sort	Number of jobs started in Sort mode. When a stored copy job is set for Sort and then stored on the document server, the L: counter increments. (See SP8 066 1)
806x-002	Stack	Number of jobs started out of Sort mode.
806x-003	Staple	Number of jobs started in Staple mode.
806x-004	Booklet	Number of jobs started in Booklet mode. If the machine is in staple mode, the Staple counter also increments.
806x-005	Z-Fold	Number of jobs started In any mode other than the Booklet mode and set for folding (Z-fold).
806x-006	Punch	Number of jobs started in Punch mode. When Punch is set for a print job, the P: counter increments. (See SP8 064 6.)

806x-007	Other	Reserved. Not used.
806x-008	Inside-Fold	Not used
806x-009	Three-IN-Fold	Not used
806x-010	Three-OUT-Fold	Not used
806x-011	Four-Fold	Not used
806x-012	KANNON-Fold	Not used
806x-013	Perfect-Bind	Not used
806x-014	Ring-Bind	Not used
806x-015	3rd Vendor	

8071	T:Jobs/PGS	* CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count the number of jobs broken down by the number of pages in the job, regardless of which application was used.		
8072	C:Jobs/PGS	* CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count and calculate the number of copy jobs by size based on the number of pages in the job.		
8073	F:Jobs/PGS	* CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count and calculate the number of fax jobs by size based on the number of pages in the job.		
8074	P:Jobs/PGS	* CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count and calculate the number of print jobs by size based on the number of pages in the job.		
8075	S:Jobs/PGS	* CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count and calculate the number of scan jobs by size based on the number of pages in the job.		
8076	L:Jobs/PGS	* CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count and calculate the number of jobs printed from within the document server mode window at the operation panel, by the number of pages in the job.		

8077	O:Jobs/PGS	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count and calculate the number of "Other" application jobs (Web Image Monitor, Palm 2, etc.) by size based on the number of pages in the job.		

Last three digits for SP8 071 to 077

807x-001	1 Page	8 07x 8	21 to 50 Pages
807x-002	2 Pages	8 07x 9	51 to 100 Pages
807x-003	3 Pages	8 07x 10	101 to 300 Pages
807x-004	4 Pages	8 07x 11	301 to 500 Pages
807x-005	5 Pages	8 07x 12	501 to 700 Pages
807x-006	6 to 10 Pages	8 07x 13	701 to 1000 Pages
807x-007	11 to 20 Pages	8 07x 14	More than 1001 Pages

- For example: When a copy job stored on the document server is printed in document server mode, the appropriate L: counter (SP8076 0xx) increments.
- Printing a fax report counts as a job and increments the F: counter (SP 8073).
- Interrupted jobs (paper jam, etc.) are counted, even though they do not finish.
- If a job is paused and re-started, it counts as one job.
- If the finisher runs out of staples during a print and staple job, then the job is counted at the time the error occurs.
- For copy jobs (SP 8072) and scan jobs (SP 8075), the total is calculated by multiplying the number of sets of copies by the number of pages scanned. (One duplex page counts as 2.)
- The first test print and subsequent test prints to adjust settings are added to the number of pages of the copy job (SP 8072).
- When printing the first page of a job from within the document server screen, the page is counted.

8111	T:FAX TX Jobs	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count the total number of jobs (color or black-and-white) sent by fax, either directly or using a file stored on the document server, on a telephone line. Note: Color fax sending is not available at this time.		

8113	F: FAX TX Jobs	*CTL	[0 to 99999999/ 0 / 1/step]
	<p>These SPs count the total number of jobs (color or black-and-white) sent by fax directly on a telephone line.</p> <p>Note: Color fax sending is not available at this time.</p>		
811x-001	B/W		
811x-002	Color		

- These counters count jobs, not pages.
- This SP counts fax jobs sent over a telephone line with a fax application, including documents stored on the document server.
- If the mode is changed during the job, the job will count with the mode set when the job started.
- If the same document is faxed to both a public fax line and an I-Fax at a destination where both are available, then this counter increments, and the I-Fax counter (8 12x) also increments.
- The fax job is counted when the job is scanned for sending, not when the job is sent.

8121	T:IFAX TX Jobs	*CTL	[0 to 99999999/ 0 / 1/step]
	<p>These SPs count the total number of jobs (color or black-and-white) sent, either directly or using a file stored on the document server, as fax images using I-Fax.</p> <p>Note: Color fax sending is not available at this time.</p>		
8123	F: IFAX TX Jobs	*CTL	[0 to 99999999/ 0 / 1/step]
	<p>These SPs count the number of jobs (color or black-and-white) sent (not stored on the document server), as fax images using I-Fax.</p> <p>Note: Color fax sending is not available at this time.</p>		
812x-001	B/W		
812x-002	Color		

- These counters count jobs, not pages.
- The counters for color are provided for future use; the color fax feature is not available at this time.
- The fax job is counted when the job is scanned for sending, not when the job is sent.

8131	T:S-to-Email Jobs	*CTL	[0 to 99999999/ 0 / 1/step]
	<p>These SPs count the total number of jobs (color or black-and-white) scanned and attached to an e-mail, regardless of whether the document server was used or not.</p>		

8135	S:S-to-Email Jobs	* CTL	[0 to 999999999 / 0 / 1/step]
	These SPs count the number of jobs (color or black-and-white) scanned and attached to e-mail, without storing the original on the document server.		
813x-001	B/W		
813x-002	Color		
813x-003	ACS		

- These counters count jobs, not pages.
- If the job is stored on the document server, after the job is stored it is determined to be color or black-and-white then counted.
- If the job is cancelled during scanning, or if the job is cancelled while the document is waiting to be sent, the job is not counted.
- If the job is cancelled during sending, it may or may not be counted, depending on what stage of the process had been reached when the job was cancelled.
- If several jobs are combined for sending to the Scan Router, Scan-to-Email, or Scan-to-PC, or if one job is sent to more than one destination. each send is counted separately. For example, if the same document is sent by Scan-to-Email as well as Scan-to-PC, then it is counted twice (once for Scan-to-Email and once for Scan-to-PC).

8141	T:Deliv Jobs/Svr	* CTL	[0 to 999999999 / 0 / 1/step]
	These SPs count the total number of jobs (color or black-and-white) scanned and sent to a Scan Router server.		
8145	S: Deliv Jobs/Svr	* CTL	[0 to 999999999 / 0 / 1/step]
	These SPs count the number of jobs (color or black-and-white) scanned in scanner mode and sent to a Scan Router server.		
814x-001	B/W		
814x-002	Color		
814x-003	ACS		

- These counters count jobs, not pages.
- The jobs are counted even though the arrival and reception of the jobs at the Scan Router server cannot be confirmed.
- If even one color image is mixed with black-and-white images, then the job is counted as a "Color" job.

- If the job is cancelled during scanning, or if the job is cancelled while the document is waiting to be delivered, the job is not counted.
- If the job is cancelled during sending, it may or may not be counted, depending on what stage of the process had been reached when the job was cancelled.
- Even if several files are combined for sending, the transmission counts as one job.

8151	T:Deliv Jobs/PC	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count the total number of jobs (color or black-and-white) scanned and sent to a folder on a PC (Scan-to-PC). Note: At the present time, 8 151 and 8 155 perform identical counts.		
8155	S:Deliv Jobs/PC	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count the total number of jobs (color or black-and-white) scanned and sent with Scan-to-PC.		
815x-001	B/W		
815x-002	Color		
815x-003	ACS		

- These counters count jobs, not pages.
- If the job is cancelled during scanning, it is not counted.
- If the job is cancelled while it is waiting to be sent, the job is not counted.
- If the job is cancelled during sending, it may or may not be counted, depending on what stage of the process had been reached when the job was cancelled.
- Even if several files are combined for sending, the transmission counts as one job.

8161	T:PCFAX TX Jobs	*CTL	These SPs count the number of PC Fax transmission jobs. A job is counted from when it is registered for sending, not when it is sent. [0 to 99999999/ 0 / 1/step] Note: At the present time, these counters perform identical counts.
8163	F:PCFAX TX Jobs	*CTL	

- This counts fax jobs started from a PC using a PC fax application, and sending the data out to the destination from the PC through the copier.

8171	T:Deliv Jobs/WSD	*CTL	These SPs count the pages scanned by WS. [0 to 99999999/ 0 / 1/step]
8175	S:Deliv Jobs/WSD	*CTL	
001	B/W		
002	Color		
003	ACS		

8181	T:Scan to Media Jobs	*CTL	These SPs count the scanned pages in a media by the scanner application. [0 to 99999999/ 0 / 1/step]
8185	S:Scan to Media Jobs	*CTL	
001	B/W		
002	Color		
003	ACS		

8191	T:Total Scan PGS	*CTL	These SPs count the pages scanned by each application that uses the scanner to scan images. [0 to 99999999/ 0 / 1/step]
8192	C:Total Scan PGS	*CTL	
8193	F:Total Scan PGS	*CTL	
8195	S:Total Scan PGS	*CTL	
8196	L:Total Scan PGS	*CTL	

- SP 8 191 to 8 196 count the number of scanned sides of pages, not the number of physical pages.
- These counters do not count reading user stamp data, or reading color charts to adjust color.
- Previews done with a scanner driver are not counted.
- A count is done only after all images of a job have been scanned.
- Scans made in SP mode are not counted.

Examples

- If both sides of 3 A4 sheets are copied and stored to the document server using the Store File button in the Copy mode window, the C: count is 6 and the L: count is 6.
- If both sides of 3 A4 sheets are copied but not stored, the C: count is 6.
- If you enter document server mode then scan 6 pages, the L: count is 6.

8201	T:LSize Scan PGS A3/DLT, Larger	* CTL	[0 to 99999999 / 0 / 1/step]
	<p>These SPs count the total number of large pages input with the scanner for scan and copy jobs. Large size paper scanned for fax transmission is not counted.</p> <p>Note: These counters are displayed in the SMC Report, and in the User Tools display.</p>		
8203	F: LSize Scan PGS A3/DLT, Larger	* CTL	[0 to 99999999 / 0 / 1/step]
	<p>These SPs count the total number of large pages input with the scanner for fax transmission.</p> <p>Note: These counters are displayed in the SMC Report, and in the User Tools display.</p>		
8205	S:LSize Scan PGS A3/DLT, Larger	* CTL	[0 to 99999999 / 0 / 1/step]
	<p>These SPs count the total number of large pages input with the scanner for scan jobs only. Large size paper scanned for fax transmission is not counted.</p> <p>Note: These counters are displayed in the SMC Report, and in the User Tools display.</p>		

8211	T:Scan PGS/LS	* CTL	<p>These SPs count the number of pages scanned into the document server</p> <p>[0 to 99999999 / 0 / 1/step]</p> <p>The L: counter counts the number of pages stored from within the document server mode screen at the operation panel, and with the Store File button from within the Copy mode screen.</p>
8212	C:Scan PGS/LS	* CTL	
8213	F:Scan PGS/LS	* CTL	
8215	S:Scan PGS/LS	* CTL	
8216	L:Scan PGS/LS	* CTL	

- Reading user stamp data is not counted.
- If a job is cancelled, the pages output as far as the cancellation are counted.
- If the scanner application scans and stores 3 B5 sheets and 1 A4 sheet, the S: count is 4.
- If pages are copied but not stored on the document server, these counters do not change.
- If both sides of 3 A4 sheets are copied and stored to the document server, the C: count is 6 and the L: count is 6.
- If you enter document server mode then scan 6 pages, the L: count is 6.

8221	ADF Org Feeds	*CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count the number of pages fed through the ADF for front and back side scanning.		
001	Front Number of front sides fed for scanning: With an ADF that can scan both sides simultaneously, the Front side count is the same as the number of pages fed for either simplex or duplex scanning. With an ADF that cannot scan both sides simultaneously, the Front side count is the same as the number of pages fed for duplex front side scanning. (The front side is determined by which side the user loads face up.)		
002	Back Number of rear sides fed for scanning: With an ADF that can scan both sides simultaneously, the Back count is the same as the number of pages fed for duplex scanning. With an ADF that cannot scan both sides simultaneously, the Back count is the same as the number of pages fed for duplex rear-side scanning.		

- When 1 sheet is fed for duplex scanning the Front count is 1 and the Back count is 1.
- If a jam occurs during the job, recovery processing is not counted to avoid double counting. Also, the pages are not counted if the jam occurs before the first sheet is output.

8231	Scan PGS/Mode	*CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count the number of pages scanned by each ADF mode to determine the work load on the ADF.		
001	Large Volume	Selectable. Large copy jobs that cannot be loaded in the ADF at one time.	
002	SADF	Selectable. Feeding pages one by one through the ADF.	
003	Mixed Size	Selectable. Select "Mixed Sizes" on the operation panel.	
004	Custom Size	Selectable. Originals of non-standard size.	
005	Platen	Book mode. Raising the ADF and placing the original directly on the platen.	
006	Mixed 1side/2side	Simplex and Duplex mode.	

- If the scan mode is changed during the job, for example, if the user switches from ADF to Platen mode, the count is done for the last selected mode.
- The user cannot select mixed sizes or non-standard sizes with the fax application so if the original's page sizes are mixed or non-standard, these are not counted.
- If the user selects "Mixed Sizes" for copying in the platen mode, the Mixed Size count is enabled.
- In the SADF mode if the user copies 1 page in platen mode and then copies 2 pages with SADF, the Platen count is 1 and the SADF count is 3.

8241	T:Scan PGS/Org	*CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count the total number of scanned pages by original type for all jobs, regardless of which application was used.		
8242	C:Scan PGS/Org	*CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count the number of pages scanned by original type for Copy jobs.		
8243	F:Scan PGS/Org	*CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count the number of pages scanned by original type for Fax jobs.		
8245	S:Scan PGS/Org	*CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count the number of pages scanned by original type for Scan jobs.		
8246	L:Scan PGS/Org	*CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count the number of pages scanned and stored from within the document server mode screen at the operation panel, and with the Store File button from within the Copy mode screen		

Last three digits for SP8 241 to 246

	8 241	8 242	8 243	8 245	8 246
824x-001: Text	Yes	Yes	Yes	Yes	Yes
824x-002: Text/Photo	Yes	Yes	Yes	Yes	Yes
824x-003: Photo	Yes	Yes	Yes	Yes	Yes
824x-004: GenCopy, Pale	Yes	Yes	No	Yes	Yes
824x-005: Map	Yes	Yes	No	No	Yes
824x-006: Normal/Detail	Yes	No	Yes	No	No
824x-007: Fine/Super Fine	Yes	No	Yes	No	No

824x-008: Binary	Yes	No	No	Yes	No
824x-009: Grayscale	Yes	No	No	Yes	No
824x-010: Color	Yes	No	No	Yes	No
824x-011: Other	Yes	Yes	Yes	Yes	Yes

- If the scan mode is changed during the job, for example, if the user switches from ADF to Platen mode, the count is done for the last selected mode.

3

8251	T:Scan PGS/ImgEdt	*CTL	These SPs show how many times Image Edit features have been selected at the operation panel for each application. Some examples of these editing features are: <ul style="list-style-type: none"> • Erase → Border • Erase → Center • Image Repeat • Centering • Positive/Negative [0 to 99999999 / 0 / 1/step] Note: The count totals the number of times the edit features have been used. A detailed breakdown of exactly which features have been used is not given.
8252	C:Scan PGS/ImgEdt	*CTL	
8255	S : Scan PGS/ImgEdr	*CTL	
8256	L:Scan PGS/ImgEdt	*CTL	
8257	O:Scan PGS/ImgEdt	*CTL	

The L: counter counts the number of pages stored from within the document server mode screen at the operation panel, and with the Store File button from within the Copy mode screen.

8261	T:Scn PGS/ ColCr	*CTL	-
8262	C:Scn PGS/ ColCr	*CTL	-
8265	S:Scn PGS/Color	*CTL	-
8266	L:Scn PGS/ColCr	*CTL	-

Last three digits for SP8 261, 262, 265 and 266

826x-001	Color Conversion	These SPs show how many times color creation features have been selected at the operation panel.
826x-002	Color Erase	
826x-003	Background	
826x-004	Other	

8281	T:Scan PGS/TWAIN	*CTL	These SPs count the number of pages scanned using a TWAIN driver. These counters reveal how the TWAIN driver is used for delivery functions. [0 to 99999999/ 0 / 1/step] Note: At the present time, these counters perform identical counts.
8285	S:Scan PGS/TWAIN	*CTL	

8291	T:Scan PGS/Stamp	*CTL	These SPs count the number of pages stamped with the stamp in the ADF unit. [0 to 99999999/ 0 / 1/step] The L: counter counts the number of pages stored from within the document server mode screen at the operation panel, and with the Store File button from within the Copy mode screen
8293	F:Scan PGS/Stamp	*CTL	
8295	S:Scan PGS/Stamp	*CTL	

8301	T:Scan PGS/Size	*CTL	[0 to 99999999/ 0 / 1/step]
These SPs count by size the total number of pages scanned by all applications. Use these totals to compare original page size (scanning) and output (printing) page size [SP 8-441].			
8302	C:Scan PGS/Size	*CTL	[0 to 99999999/ 0 / 1/step]
These SPs count by size the total number of pages scanned by the Copy application. Use these totals to compare original page size (scanning) and output (printing) page size [SP 8-442].			
8303	F:Scan PGS/Size	*CTL	[0 to 99999999/ 0 / 1/step]
These SPs count by size the total number of pages scanned by the Fax application. Use these totals to compare original page size (scanning) and output page size [SP 8-443].			

8305	S:Scan PGS/Size	* CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by size the total number of pages scanned by the Scan application. Use these totals to compare original page size (scanning) and output page size [SP 8-445].		
8306	L:Scan PGS/Size	* CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by size the total number of pages scanned and stored from within the document server mode screen at the operation panel, and with the Store File button from within the Copy mode screen. Use these totals to compare original page size (scanning) and output page size [SP 8-446].		

Last three digits for SP8 301 to 306

830x-001	A3	830x-007	LG
830x-002	A4	830x-008	LT
830x-003	A5	830x-009	HLT
830x-004	B4	830x-010	Full Bleed
830x-005	B5	830x-254	Other (Standard)
830x-006	DLT	830x-255	Other (Custom)

8311	T:Scan PGS/Rez	* CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by resolution setting the total number of pages scanned by applications that can specify resolution settings.		
8315	S: Scan PGS/Rez	* CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by resolution setting the total number of pages scanned by applications that can specify resolution settings. Note: At the present time, SP8-311 and SP8-315 perform identical counts.		

Last three digits for SP8 311 and 315

831x-001	1200 dpi
831x-002	600 dpi to 1199 dpi
831x-003	400 dpi to 599 dpi
831x-004	200 dpi to 399 dpi

831x-005	199 dpi or less
----------	-----------------

- Copy resolution settings are fixed so they are not counted.
- The Fax application does not allow finely-adjusted resolution settings so no count is done for the Fax application.

8321	T:Saen Poster	* CTL	[0 to 999999999 / 0 / 1/step]
8322	C:Saen Poster	* CTL	[0 to 999999999 / 0 / 1/step]
8326	L:Saen Poster	* CTL	[0 to 999999999 / 0 / 1/step]

832x-001	2 Sheet
832x-002	4 Sheet
832x-003	9 Sheet

8381	T:Total PrtPGS	* CTL	These SPs count the number of pages printed by the customer. The counter for the application used for storing the pages increments. [0 to 999999999 / 0 / 1/step] The L: counter counts the number of pages stored from within the document server mode screen at the operation panel. Pages stored with the Store File button from within the Copy mode screen go to the C: counter.
8382	C:Total PrtPGS	* CTL	
8383	F:Total PrtPGS	* CTL	
8384	P:Total PrtPGS	* CTL	
8385	S:Total PrtPGS	* CTL	
8386	L:Total PrtPGS	* CTL	
8387	O:Total PrtPGS	* CTL	

- When several documents are merged for a print job, the number of pages stored is counted for the application that stored them.
- These counters are used primarily to calculate charges on use of the machine, so the following pages are not counted as printed pages:
 - Blank pages in a duplex printing job.
 - Blank pages inserted as document covers, chapter title sheets, and slip sheets.
 - Reports printed to confirm counts.
 - All reports done in the service mode (service summaries, engine maintenance reports, etc.)

- Test prints for machine image adjustment.
- Error notification reports.
- Partially printed pages as the result of a copier jam.

8391	LSize PrtPGS		
	These SPs count pages printed on paper sizes A4/LT and larger. Note: In addition to being displayed in the SMC Report, these counters are also displayed in the User Tools display on the copy machine.		
001	A3/DLT, Larger	* CTL	[0 to 99999999 / 0 / 1/step]
003	BannaerPaper	* CTL	[0 to 99999999 / 0 / 1/step]

8401	T:PrtPGS/LS	* CTL	These SPs count the number of pages printed from the document server. The counter for the application used to print the pages is incremented. The L: counter counts the number of jobs stored from within the document server mode screen at the operation panel. [0 to 99999999 / 0 / 1/step]
8402	C:PrtPGS/LS	* CTL	
8403	F:PrtPGS/LS	* CTL	
8404	P:PrtPGS/LS	* CTL	
8405	S:PrtPGS/LS	* CTL	
8406	L:PrtPGS/LS	* CTL	

- Print jobs done with Web Image Monitor and Desk Top Binder are added to the L: count.
- Fax jobs done with Web Image Monitor and Desk Top Binder are added to the F: count.

8411	Prints/Duplex	* CTL	This SP counts the amount of paper (front/back counted as 1 page) used for duplex printing. Last pages printed only on one side are not counted. [0 to 99999999 / 0 / 1/step]
------	---------------	-------	--

8421	T:PrtPGS/Dup Comb	* CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by binding and combine, and n-Up settings the number of pages processed for printing. This is the total for all applications.		
8422	C:PrtPGS/Dup Comb	* CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by binding and combine, and n-Up settings the number of pages processed for printing by the copier application.		

8423	F:PrtPGS/Dup Comb	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by binding and combine, and n-Up settings the number of pages processed for printing by the fax application.		
8424	P:PrtPGS/Dup Comb	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by binding and combine, and n-Up settings the number of pages processed for printing by the printer application.		
8425	S:PrtPGS/Dup Comb	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by binding and combine, and n-Up settings the number of pages processed for printing by the scanner application.		
8426	L:PrtPGS/Dup Comb	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by binding and combine, and n-Up settings the number of pages processed for printing from within the document server mode window at the operation panel.		
8427	O:PrtPGS/Dup Comb	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by binding and combine, and n-Up settings the number of pages processed for printing by Other applications		

Last three digits for SP8 421 to 427

842x-001	Simplex> Duplex	-
842x-002	Duplex> Duplex	-
842x-003	Book> Duplex	-
842x-004	Simplex Combine	-
842x-005	Duplex Combine	-
842x-006	2in1	2 pages on 1 side (2-Up)
842x-007	4in1	4 pages on 1 side (4-Up)
842x-008	6in1	6 pages on 1 side (6-Up)
842x-009	8in1	8 pages on 1 side (8-Up)
842x-010	9in1	9 pages on 1 side (9-Up)
842x-011	16in1	16 pages on 1 side (16-Up)

842x-012	Booklet	-
842x-013	Magazine	-
842x-014	2in1 + Booklet	-
842x-015	4in1 + Booklet	-
842x-016	6in1 + Booklet	-
842x-017	8in1 + Booklet	-
842x-018	9in1 + Booklet	-
842x-019	2in1 + Magazine	-
842x-020	4in1 + Magazine	-
842x-021	6in1 + Magazine	-
842x-022	8in1 + Magazine	-
842x-023	9in1 + Magazine	-
842x-024	16in1 + Magazine	-

- These counts (SP8 421 to SP8 427) are especially useful for customers who need to improve their compliance with ISO standards for the reduction of paper consumption.
- Pages that are only partially printed with the n-Up functions are counted as 1 page.
- Here is a summary of how the counters work for Booklet and Magazine modes:

Booklet		Magazine	
Original Pages	Count	Original Pages	Count
1	1	1	1
2	2	2	2
3	2	3	2
4	2	4	2
5	3	5	4
6	4	6	4
7	4	7	4

Booklet		Magazine	
Original Pages	Count	Original Pages	Count
8	4	8	4

8431	T:PrtPGS/ImgEdt	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count the total number of pages output with the three features below, regardless of which application was used.		
8432	C:PrtPGS/ImgEdt	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count the total number of pages output with the three features below with the copy application.		
8434	P:PrtPGS/ImgEdt	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count the total number of pages output with the three features below with the print application.		
8436	L:PrtPGS/ImgEdt	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count the total number of pages output from within the document server mode window at the operation panel with the three features below.		
8437	O:PrtPGS/ImgEdt	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count the total number of pages output with the three features below with Other applications.		

Last three digits for SP8 431 to 437

843x-001	Cover/Slip Sheet	Total number of covers or slip sheets inserted. The count for a cover printed on both sides counts 2.
843x-002	Series/Book	The number of pages printed in series (one side) or printed as a book with booklet right/left pagination.
843x-003	User Stamp	The number of pages printed where stamps were applied, including page numbering and date stamping.

8441	T:PrtPGS/Ppr Size	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by print paper size the number of pages printed by all applications.		

8442	C:PrtPGS/Ppr Size	* CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by print paper size the number of pages printed by the copy application.		
8443	F:PrtPGS/Ppr Size	* CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by print paper size the number of pages printed by the fax application.		
8444	P:PrtPGS/Ppr Size	* CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by print paper size the number of pages printed by the printer application.		
8445	S:PrtPGS/Ppr Size	* CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by print paper size the number of pages printed by the scanner application.		
8446	L:PrtPGS/Ppr Size	* CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by print paper size the number of pages printed from within the document server mode window at the operation panel.		
8447	O:PrtPGS/Ppr Size	* CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by print paper size the number of pages printed by Other applications.		

Last three digits for SP8 441 to 447

844x-001	A3
844x-002	A4
844x-003	A5
844x-004	B4
844x-005	B5
844x-006	DLT
844x-007	LG
844x-008	LT
844x-009	HLT
844x-010	Full Bleed
844x-254	Other (Standard)

844x-255	Other (Custom)
----------	----------------

- These counters do not distinguish between LEF and SEF.

8451	PrtPGS/Ppr Tray	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count the number of sheets fed from each paper feed station.		
001	Bypass Tray	Bypass Tray	
002	Tray 1	Machine	
003	Tray 2	Paper Tray Unit (Option)	
004	Tray 3	Paper Tray Unit (Option)	
005	Tray 4	Paper Tray Unit (Option)	
006	Tray 5	Not used	
007	Tray 6	Not used	
008	Tray 7	Not used	
009	Tray 8	Not used	
010	Tray 9	Not used	
011	Tray10	Not used	
012	Tray11	Not used	
013	Tray12	Not used	
014	Tray13	Not used	
015	Tray14	Not used	
016	Tray15	Not used	

8461	T:PrtPGS/Ppr Type	*CTL	[0 to 99999999/ 0 / 1/step]
	<p>These SPs count by paper type the number pages printed by all applications.</p> <ul style="list-style-type: none"> • These counters are not the same as the PM counter. The PM counter is based on feed timing to accurately measure the service life of the feed rollers. However, these counts are based on output timing. • Blank sheets (covers, chapter covers, slip sheets) are also counted. • During duplex printing, pages printed on both sides count as 1, and a page printed on one side counts as 1. 		
8462	C:PrtPGS/Ppr Type	*CTL	[0 to 99999999/ 0 / 1/step]
	<p>These SPs count by paper type the number pages printed by the copy application.</p>		
8463	F:PrtPGS/Ppr Type	*CTL	[0 to 99999999/ 0 / 1/step]
	<p>These SPs count by paper type the number pages printed by the fax application.</p>		
8464	P:PrtPGS/Ppr Type	*CTL	[0 to 99999999/ 0 / 1/step]
	<p>These SPs count by paper type the number pages printed by the printer application.</p>		
8466	L:PrtPGS/Ppr Type	*CTL	[0 to 99999999/ 0 / 1/step]
	<p>These SPs count by paper type the number pages printed from within the document server mode window at the operation panel.</p>		

Last three digits for SP8 461 to 466

846x-001	Normal
846x-002	Recycled
846x-003	Special
846x-004	Thick
846x-005	Normal (Back)
846x-006	Thick (Back)
846x-007	OHP
846x-008	Other

8471	PrtPGS/Mag	* CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by magnification rate the number of pages printed.		
001	49% or less		
002	50% to 99%		
003	100%		
004	101% to 200%		
005	201% or more		

- Counts are done for magnification adjusted for pages, not only on the operation panel but performed remotely with an external network application capable of performing magnification adjustment as well.
- Magnification adjustments done with printer drivers with PC applications such as Excel are also counted.
- Magnification adjustments done for adjustments after they have been stored on the document server are not counted.
- Magnification adjustments performed automatically during Auto Reduce/Enlarge copying are counted.
- The magnification rates of blank cover sheets, slip sheets, etc. are automatically assigned a rate of 100%.

8481	T:PrtPGS/TonSave	* CTL	[0 to 99999999 / 0 / 1/step]
8484	P:PrtPGS/TonSave	* CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count the number of pages printed with the Toner Save feature switched on. Note: These SPs return the same results as this SP is limited to the Print application.		

8491	T:PrtPGS/Col Mode	* CTL	These SPs count the number of pages printed in the Color Mode by each application.
8492	C:PrtPGS/Col Mode	* CTL	
8493	F:PrtPGS/Col Mode	* CTL	
8496	L:PrtPGS/Col Mode	* CTL	
8497	O:PrtPGS/Col Mode	* CTL	

Last three digits for SP8 491 to 493, 496 and 497

849x-001	B/W
849x-002	Single Color
849x-003	Two Color
849x-004	Full Color
849x-051	B/W(Banner)
849x-052	Single Color(Banner)
849x-053	Two Color(Banner)
849x-054	Full Color(Banner)

8501	T:PrtPGS/Col Mode	* CTL	These SPs count the number of pages printed in the Color Mode by the print application.
8504	P:PrtPGS/Col Mode	* CTL	
8507	O:PrtPGS/Col Mode	* CTL	

Last three digits for SP8 501, 504 and 507

850x-001	B/W
850x-002	Mono Color
850x-003	Full Color
850x-004	Single Color
850x-005	Two Color
850x-051	B/W(Banner)
850x-052	Full Color(Banner)
850x-053	Single Color(Banner)
850x-054	Two Color(Banner)

8511	T:PrtPGS/Emul	* CTL	[0 to 999999999 / 0 / 1/step]
	These SPs count by printer emulation mode the total number of pages printed.		

8514	P:PrtPGS/Emul	*CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by printer emulation mode the total number of pages printed.		

Last three digits for SP8 511 and 514

851x-001	RPCS	-
851x-002	RPDL	-
851x-003	PS3	-
851x-004	R98	-
851x-005	R16	-
851x-006	GL/GL2	-
851x-007	R55	-
851x-008	RTIFF	-
851x-009	PDF	-
851x-010	PCL5e/5c	-
851x-011	PCL XL	-
851x-012	IPDL-C	-
851x-013	BM-Links	Japan Only
851x-014	Other	-
851x-015	IPDS	-
851x-016	XPS	-

- SP8 511 and SP8 514 return the same results as they are both limited to the Print application.
- Print jobs output to the document server are not counted.

8521	T:PrtPGS/FIN	*CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by finishing mode the total number of pages printed by all applications.		

8522	C:PrtPGS/FIN	*CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by finishing mode the total number of pages printed by the Copy application.		
8523	F:PrtPGS/FIN	*CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by finishing mode the total number of pages printed by the Fax application. Note: Print finishing options for received faxes are currently not available.		
8524	P:PrtPGS/FIN	*CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by finishing mode the total number of pages printed by the Print application.		
8525	S:PrtPGS/FIN	*CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by finishing mode the total number of pages printed by the Scanner application.		
8526	L:PrtPGS/FIN	*CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count by finishing mode the total number of pages printed from within the document server mode window at the operation panel.		

Last three digits for SP8 521 to 526

852x-001	Sort	852x-009	Three-IN-Fold
852x-002	Stack	852x-010	Three-OUT-Fold
852x-003	Staple	852x-011	Four-Fold
852x-004	Booklet	852x-012	KANNON-Fold
852x-005	Z-Fold	852x-013	Perfect-Bind
852x-006	Punch	852x-014	Ring-Bind
852x-007	Other	852x-015	3rd Vendor
852x-008	Inside-Fold		

Note

- If stapling is selected for finishing and the stack is too large for stapling, the unstapled pages are still counted.

- The counts for staple finishing are based on output to the staple tray, so jam recoveries are counted.

8531	Staple		
	This SP counts the amount of staples used (-001) or count stapled (-002) by the machine.		
001	Staples	*CTL	[0 to 99999999 / 0 / 1]
002	Stapless	*CTL	[0 to 99999999 / 0 / 1]

3

8551	T:PrtBooks/FIN	*CTL	-
8552	C:PrtBooks/FIN	*CTL	-
8554	P:PrtBooks/FIN	*CTL	-
8556	L:PrtBooks/FIN	*CTL	-
855x-001	Perfect-Bind	Not used	
855x-002	Ring-Bind	Not used	

8561	T:A Sheet Of Paper	*CTL	[0 to 99999999 / 0 / 1/step]
8562	C:A Sheet Of Paper	*CTL	[0 to 99999999 / 0 / 1/step]
8563	F:A Sheet Of Paper	*CTL	[0 to 99999999 / 0 / 1/step]
8564	P:A Sheet Of Paper	*CTL	[0 to 99999999 / 0 / 1/step]
8566	L:A Sheet Of Paper	*CTL	[0 to 99999999 / 0 / 1/step]
8567	O:A Sheet Of Paper	*CTL	[0 to 99999999 / 0 / 1/step]

Last three digits for SP8 561 to 567

856x-001	Total: Over A3/DLT
856x-002	Total: Under A3/DLT
856x-003	Duplex: Over A3/DLT
856x-004	Duplex: Under A3/DLT

8581	T:Counter	*CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count the total output broken down by color output, regardless of the application used. In addition to being displayed in the SMC Report, these counters are also displayed in the User Tools display on the copy machine.		
001	Total		
002	Total: Full Color		
003	B&W/Single Color		
004	Development: CMY		
005	Development: K		
006	Copy: Color		
007	Copy: B/W		
008	Print: Color		
009	Print: B/W		
010	Total: Color		
011	Total: B/W		
012	Full Color: A3		
013	Full Color: B4 JIS or Smaller		
014	Full Color Print		
015	Mono Color Print		
016	Full Color GPC		
017	Twin Color Mode Print		
018	Full Color Print(Twin)		
019	Mono Color Print(Twin)		
020	Full Color Total(CV)		
021	Mono Color Total(CV)		
022	Full Color Print(CV)		

028	Development: CMY(A3)
029	Development: K(A3)
030	Total: Color(A3)
031	Total: B/W(A3)
032	Total: B/W(A3)

8582	C:Counter	*CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count the total output of the copy application broken down by color output.		
001	B/W		
002	Single Color		
003	Two Color		
004	Full Color		

8583	F:Counter	*CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count the total output of the fax application broken down by color output.		
001	B/W		
002	Single Color		

8584	P:Counter	*CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count the total output of the print application broken down by color output.		
001	B/W		
002	Mono Color		
003	Full Color		
004	Single Color		
005	Two Color		

8586	L:Counter	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count the total output of the local storage broken down by color output.		
001	B/W		
002	Single Color		
003	Two Color		
004	Full Color		

8591	O:Counter	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count the totals for A3/DLT paper use, number of duplex pages printed, and the number of staples used. These totals are for Other (O:) applications only.		
001	A3/DLT		
002	Duplex		
005	Banner		

8601	T:Coverage Counter	*CTL	[0 to 2147483647/ 0 / 1%/step]
	These SPs count the total coverage for each color and the total printout pages for each printing mode.		
001	B/W		
002	Color		
011	B/W Printing Pages		
012	Color Printing Pages		
021	Coverage Counter 1		
022	Coverage Counter 2		
023	Coverage Counter 3		
031	Coverage Counter 1 (YMC)		
032	Coverage Counter 2 (YMC)		
033	Coverage Counter 3 (YMC)		

8602	C:Coverage Counter	*CTL	[0 to 2147483647/ 0 / 1%/step]
	These SPs count the total coverage for each color and the total printout pages for each printing mode.		
8603	F:Coverage Counter	*CTL	[0 to 2147483647/ 0 / 1%/step]
	These SPs count the total coverage for each color and the total printout pages for each printing mode.		
8604	P:Coverage Counter	*CTL	[0 to 2147483647/ 0 / 1%/step]
	These SPs count the total coverage for each color and the total printout pages for each printing mode.		
8606	L:Coverage Counter	*CTL	[0 to 2147483647/ 0 / 1%/step]
	These SPs count the total coverage for each color and the total printout pages for each printing mode.		

Last three digits for SP8 602 to 606

	8 602	8 603	8 604	8 606
860x-001: B/W	Yes	Yes	Yes	Yes
860x-002: Single Color	Yes	Yes	Yes	Yes
860x-003: Two Color	Yes	No	Yes	Yes
860x-004: Full Color	Yes	No	Yes	Yes

8617	SDK Apli Counter	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count the total printout pages for each SDK applicaion.		
001	SDK-1		
002	SDK-2		
003	SDK-3		
004	SDK-4		
005	SDK-5		
006	SDK-6		
007	SDK-7		

008	SDK-8
009	SDK-9
010	SDK-10
011	SDK-11
012	SDK-12

8621	Func Use Counter DFU
001 to 064	Function 001 to Function 064

8631	T:FAX TX PGS	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by color mode the number of pages sent by fax to a telephone number.		
8633	F:FAX TX PGS	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by color mode the number of pages sent by fax to a telephone number.		
863x-001	B/W		
863x-002	Color		

- If a document has color and black-and-white pages mixed, the pages are counted separately as B/W or Color.
- At the present time, this feature is provided for the Fax application only so SP8631 and SP8633 are the same.
- The counts include error pages.
- If a document is sent to more than one destination with a Group transmission, the count is done for each destination.
- Polling transmissions are counted but polling RX are not.
- Relay, memory, and confidential mailbox transmissions and are counted for each destination.

8641	T:IFAX TX PGS	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by color mode the number of pages sent by fax to as fax images using I-Fax.		

8643	F:IFAX TX PGS	*CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count by color mode the number of pages sent by Fax as fax images using I-Fax.		
864x-001	B/W		
864x-002	Color		

- If a document has color and black-and-white pages mixed, the pages are counted separately as B/W or Color.
- At the present time, this feature is provided for the Fax application only so SP8641 and SP8643 are the same.
- The counts include error pages.
- If a document is sent to more than one destination with a Group transmission, the count is done for each destination.
- Polling transmissions are counted but polling RX are not.
- Relay, memory, and confidential mailbox transmissions and are counted for each destination.

8651	T:S-to-Email PGS	*CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count by color mode the total number of pages attached to an e-mail for both the Scan and document server applications.		
8655	S:S-to-Email PGS	*CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count by color mode the total number of pages attached to an e-mail for the Scan application only.		
865x-001	B/W		
865x-002	Color		

↓ Note

- The count for B/W and Color pages is done after the document is stored on the HDD. If the job is cancelled before it is stored, the pages are not counted.
- If Scan-to-Email is used to send a 10-page document to 5 addresses, the count is 10 (the pages are sent to the same SMTP server together).
- If Scan-to-PC is used to send a 10-page document to 5 folders, the count is 50 (the document is sent to each destination of the SMB/FTP server).
- Due to restrictions on some devices, if Scan-to-Email is used to send a 10-page document to a large number of destinations, the count may be divided and counted separately. For example, if a

10-page document is sent to 200 addresses, the count is 10 for the first 100 destinations and the count is also 10 for the second 100 destinations, for a total of 20.).

8661	T:Deliv PGS/Svr	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by color mode the total number of pages sent to a Scan Router server by both Scan and LS applications.		
8665	S:Deliv PGS/Svr	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by color mode the total number of pages sent to a Scan Router server by the Scan application.		
866x-001	B/W		
866x-002	Color		

Note

- The B/W and Color counts are done after the document is stored on the HDD of the Scan Router server.
- If the job is canceled before storage on the Scan Router server finishes, the counts are not done.
- The count is executed even if regardless of confirmation of the arrival at the Scan Router server.

8671	T:Deliv PGS/PC	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by color mode the total number of pages sent to a folder on a PC (Scan-to-PC) with the Scan and LS applications.		
8675	S: Deliv PGS/PC	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs count by color mode the total number of pages sent with Scan-to-PC with the Scan application.		
867x-001	B/W		
867x-002	Color		

8681	T:PCFAX TXPGS	*CTL	These SPs count the number of pages sent by PC Fax. These SPs are provided for the Fax application only, so the counts for SP8 681 and SP8 683 are the same. [0 to 99999999/ 0 / 1/step]
8683	F:PCFAX TXPGS	*CTL	

- This counts pages sent from a PC using a PC fax application, from the PC through the copier to the destination.

- When sending the same message to more than one place using broadcasting, the pages are only counted once. (For example, a 10-page fax is sent to location A and location B. The counter goes up by 10, not 20.)

8691	T:TX PGS/LS	* CTL	These SPs count the number of pages sent from the document server. The counter for the application that was used to store the pages is incremented. [0 to 99999999 / 0 / 1/step] The L: counter counts the number of pages stored from within the document server mode screen at the operation panel. Pages stored with the Store File button from within the Copy mode screen go to the C: counter.
8692	C:TX PGS/LS	* CTL	
8693	F:TX PGS/LS	* CTL	
8694	P:TX PGS/LS	* CTL	
8695	S:TX PGS/LS	* CTL	
8696	L:TX PGS/LS	* CTL	

Note

- Print jobs done with Web Image Monitor and Desk Top Binder are added to the count.
- If several documents are merged for sending, the number of pages stored are counted for the application that stored them.
- When several documents are sent by a Fax broadcast, the F: count is done for the number of pages sent to each destination.

8701	TX PGS/Port	* CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count the number of pages sent by the physical port used to send them. For example, if a 3-page original is sent to 4 destinations via ISDN G4, the count for ISDN (G3, G4) is 12.		
001	PSTN-1		
002	PSTN-2		
003	PSTN-3		
004	ISDN (G3,G4)		
005	Network		

8711	T:Scan PGS/Comp	* CTL	[0 to 99999999 / 0 / 1/step]
8715	S:Scan PGS/Comp	* CTL	[0 to 99999999 / 0 / 1/step]
	These SPs count the number of pages sent by each compression mode.		

871x-001	JPEG/JPEG2000
871x-002	TIFF(Multi/Single)
871x-003	PDF
871x-004	Other
871x-005	PDF/Comp
871x-006	PDF/A
871x-007	PDF(OCR)
871x-008	PDF/Comp(OCR)
871x-009	PDF/A(OCR)

8721	T: Deliv PGS/WSD	*CTL	[0 to 999999999/ 0 / 1/step]
8725	S: Deliv PGS/WSD	*CTL	
	These SPs count the number of pages scanned by each scanner mode.		
872x-001	B/W		
872x-002	Color		

8731	T:Scan PGS/Media	*CTL	[0 to 999999999/ 0 / 1/step]
8735	S:Scan PGS/Media	*CTL	
	These SPs count the number of pages scanned and saved in a media by each scanner mode.		
873x-001	B/W		
873x-002	Color		

8741	RX PGS/Port	*CTL	[0 to 999999999/ 0 / 1/step]
	These SPs count the number of pages received by the physical port used to receive them.		
001	PSTN-1		
002	PSTN-2		

003	PSTN-3
004	ISDN (G3,G4)
005	Network

8771	Dev Counter	*CTL	[0 to 999999999 / 0 / 1/step]
	These SPs count the frequency of use (number of rotations of the development rollers) for black and other color toners.		
001	Total		
002	K		
003	Y		
004	M		
005	C		

8781	Toner_BotoI_Info.	*CTL	[0 to 999999999 / 0 / 1/step]
	These SPs display the number of already replaced toner bottles. Note: Currently, the data in SP7-833-011 through 014 and the data in SP8-781-001 through 004 are the same.		
001	BK	The number of black-toner bottles	
002	Y	The number of yellow-toner bottles	
003	M	The number of magenta-toner bottles	
004	C	The number of cyan-toner bottles	

8791	LS Memory Remain	*CTL	[0 to 100 / 0 / 1/%]
	This SP displays the percent of space available on the document server for storing documents.		
001	BK	The number of black-toner bottles	

8801	Toner Remain	*CTL	[0 to 100/ 0 / 1/%]
	<p>These SPs display the percent of toner remaining for each color. This SP allows the user to check the toner supply at any time.</p> <p>Note: This precise method of measuring remaining toner supply (1% steps) is better than other machines in the market that can only measure in increments of 10 (10% steps).</p>		
001	K		
002	Y		
003	M		
004	C		

8811	Eco Counter		
001	Eco Total	*CTL	[0 to 99999999 / 0 / 1/step]
	<p>Displays the number of pages reduced by using the color, full color, duplex and combine function.</p>		
004	Duplex	*CTL	[0 to 99999999 / 0 / 1/step]
	<p>Displays the number of pages reduced by using the duplex function.</p>		
005	Combine	*CTL	[0 to 99999999 / 0 / 1/step]
	<p>Displays the number of pages reduced by using the combine function.</p>		
008	Duplex(%)	*CTL	[0 to 100 / 0 / 1/%]
	<p>Displays the utilization ratio of the duplex function.</p>		
009	Combine(%)	*CTL	[0 to 100 / 0 / 1/%]
	<p>Displays the utilization ratio of the combine function.</p>		
010	Paper Cut(%)	*CTL	[0 to 100/ 0 / 1/%]
	<p>Displays the paper reduction ratio.</p>		
051	Sync Eco Total	*CTL	[0 to 99999999/ 0 / 1/step]
054	Sync Duplex	*CTL	[0 to 99999999/ 0 / 1/step]
055	Sync Combine	*CTL	[0 to 99999999/ 0 / 1/step]

058	Sync Duplex(%)	* CTL	[0 to 100/ 0 / 1/%]
059	Sync Combine(%)	* CTL	[0 to 100/ 0 / 1/%]
060	Sync Paper Cut(%)	* CTL	[0 to 100/ 0 / 1/%]
101	Eco Totalr>Last	* CTL	[0 to 99999999/ 0 / 1/step]
104	Duplex>Last	* CTL	[0 to 99999999/ 0 / 1/step]
105	Combine>Last	* CTL	[0 to 99999999/ 0 / 1/step]
108	Duplex(%):Last	* CTL	[0 to 100/ 0 / 1/%]
109	Combine(%):Last	* CTL	[0 to 100/ 0 / 1/%]
110	Paper Cut(%):Last	* CTL	[0 to 100/ 0 / 1/%]
151	Sync Eco Totalr>Last	* CTL	[0 to 99999999 / 0 / 1/step]
154	Sync Duplex>Last	* CTL	[0 to 99999999 / 0 / 1/step]
155	Sync Combine>Last	* CTL	[0 to 99999999 / 0 / 1/step]
158	Sync Duplex(%):Last	* CTL	[0 to 100/ 0 / 1/%]
159	Sync Combine(%):Last	* CTL	[0 to 100/ 0 / 1/%]
160	Sync Paper Cut(%):Last	* CTL	[0 to 100/ 0 / 1/%]

8851	CVr Cnt: 0-10%	* CTL	[0 to 99999999/ 0 / 1/step]
	These SPs display the number of scanned sheets on which the coverage of each color is from 0% to 10%.		
011	0 to 2%: BK	031	5 to 7%: BK
012	0 to 2%: Y	032	5 to 7%: Y
013	0 to 2%: M	033	5 to 7%: M
014	0 to 2%: C	034	5 to 7%: C
021	3 to 4%: BK	041	8 to 10%: BK
022	3 to 4%: Y	042	8 to 10%: Y
023	3 to 4%: M	043	8 to 10%: M

024	3 to 4%: C	044	8 to 10%: C
-----	------------	-----	-------------

8861	CVr Cnt: 11-20%	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs display the number of scanned sheets on which the coverage of each color is from 11% to 20%.		
001	BK		
002	Y		
003	M		
004	C		

8871	CVr Cnt: 21-30%	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs display the number of scanned sheets on which the coverage of each color is from 21% to 30%.		
001	BK		
002	Y		
003	M		
004	C		

8881	CVr Cnt: 31%-	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs display the number of scanned sheets on which the coverage of each color is 31% or higher.		
001	BK		
002	Y		
003	M		
004	C		

8891	Page/Toner Bottle	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs display the amount of the remaining current toner for each color.		
001	BK		

002	Y
003	M
004	C

8901	Page/Toner_Prev1	*CTL	[0 to 99999999/ 0 / 1/step]
	These SPs display the amount of the remaining previous toner for each color.		
001	BK		
002	Y		
003	M		
004	C		

8911	Page/Toner_Prev2	*CTL	[0 to 999999999/ 0 / 1/step]
	These SPs display the amount of the remaining 2nd previous toner for each color.		
001	BK		
002	Y		
003	M		
004	C		

8921	Cvr Cnt/Total	*CTL	[0 to 2147483647/ 0 / 1/%]
	Displays the total coverage and total printout number for each color.		
001	Coverage(%):BK		
002	Coverage (%) Y		
003	Coverage (%) M		
004	Coverage (%) C		
8921	Cvr Cnt/Total	*CTL	[0 to 999999999/ 0 / 1/step]
011	Coverage /P: BK		
012	Coverage /P: Y		

013	Coverage /P: M
014	Coverage /P: C

8941	Machine Status	*CTL	[0 to 999999999 / 0 / 1/step]
	<p>These SPs count the amount of time the machine spends in each operation mode. These SPs are useful for customers who need to investigate machine operation for improvement in their compliance with ISO Standards.</p>		
001	Operation Time	Engine operation time. Does not include time while controller is saving data to HDD (while engine is not operating).	
002	Standby Time	Engine not operating. Includes time while controller saves data to HDD. Does not include time spent in Energy Save, Low Power, or Off modes.	
003	Energy Save Time	Includes time while the machine is performing background printing.	
004	Low Power Time	Includes time in Energy Save mode with Engine on. Includes time while machine is performing background printing.	
005	Off Mode Time	Includes time while machine is performing background printing. Does not include time machine remains powered off with the power switches.	
006	SC	Total time when SC errors have been staying.	
007	PrtJam	Total time when paper jams have been staying during printing.	
008	OrgJam	Total time when original jams have been staying during scanning.	
009	Supply PM Unit End	Total time when toner end has been staying.	

8951	AddBook Register	*CTL	-
	<p>These SPs count the number of events when the machine manages data registration.</p>		

001	User Code /User ID	User code registrations.	[0 to 99999 / 0 / 1/step]
002	Mail Address	Mail address registrations.	
003	Fax Destination	Fax destination registrations.	
004	Group	Group destination registrations.	
005	Transfer Request	Fax relay destination registrations for relay TX.	
006	F-Code	F-Code box registrations.	
007	Copy Program	Copy application registrations with the Program (job settings) feature.	[0 to 255 / 0 / 1/step]
008	Fax Program	Fax application registrations with the Program (job settings) feature.	
009	Printer Program	Printer application registrations with the Program (job settings) feature.	
010	Scanner Program	Scanner application registrations with the Program (job settings) feature.	

8961	Electricity Status	*CTL	[0 to 99999999 / 0 / 1/step]
	-		
001	Ctrl Standby Time		
002	STR Time		
003	Main Power Off Time		
004	Reading and Printing Time		
005	Printing Time		
006	Reading Time		
007	Eng Waiting Time		
008	Low Power State Time		

009	Silent State Time
010	Heater Off State Time
011	LCD on Time
101	Silent Print

8971	Unit Control	*CTL	[0 to 999999999/ 0 / 1/step]
	-		
001	Engine Off Recovery Count		
002	Power Off Count		
003	Force Power Off Count		

8999	Admin. Counter List		
	Displays the total coverage and total printout number for each color.		
001	Total	*CTL	[0 to 999999999/ 0 / 1]
002	Copy: Full Color	*CTL	[0 to 999999999/ 0 / 1]
003	Copy: BW	*CTL	[0 to 999999999/ 0 / 1]
004	Copy: Single Color	*CTL	[0 to 999999999/ 0 / 1]
005	Copy: Two Color	*CTL	[0 to 999999999/ 0 / 1]
006	Printer Full Color	*CTL	[0 to 999999999/ 0 / 1]
007	Printer BW	*CTL	[0 to 999999999/ 0 / 1]
008	Printer Single Color	*CTL	[0 to 999999999/ 0 / 1]
009	Printer Two Color	*CTL	[0 to 999999999/ 0 / 1]
010	Fax Print: BW	*CTL	[0 to 999999999/ 0 / 1]
011	Fax Print: Single Color	*CTL	[0 to 999999999/ 0 / 1]
013	Duplex	*CTL	[0 to 999999999/ 0 / 1]
022	Copy: Full Color(%)	*CTL	[0 to 2147483647/ 0 / 1]
023	Copy: BW(%)	*CTL	[0 to 2147483647/ 0 / 1]

024	Copy: Single Color(%)	*CTL	[0 to 2147483647/ 0 / 1]
025	Copy: Two Color(%)	*CTL	[0 to 2147483647/ 0 / 1]
026	Printer: Full Color(%)	*CTL	[0 to 2147483647/ 0 / 1]
027	Printer: BW(%)	*CTL	[0 to 2147483647/ 0 / 1]
028	Printer: Single Color(%)	*CTL	[0 to 2147483647/ 0 / 1]
029	Printer: Two Color(%)	*CTL	[0 to 2147483647/ 0 / 1]
030	Fax Print: BW(%)	*CTL	[0 to 2147483647/ 0 / 1]
031	Fax Print: Single Color(%)	*CTL	[0 to 2147483647/ 0 / 1]
101	Transmission Total: Color	*CTL	[0 to 999999999/ 0 / 1]
102	Transmission Total: BW	*CTL	[0 to 999999999/ 0 / 1]
103	FAX Transmission	*CTL	[0 to 999999999/ 0 / 1]
104	Scanner Transmission: Color	*CTL	[0 to 999999999/ 0 / 1]
105	Scanner Transmission: BW	*CTL	[0 to 999999999/ 0 / 1]

Printer Service Menu

SP1-XXX (Service Mode)

1001	[Bit Switch]
------	--------------

1-001-00 1	Bit Switch 1		0	1
	bit 0	DFU	-	-
	bit 1	Responding with the hostname as the sysName	Model name (PnP name)	Hostname
		<p>This BitSwitch can change the value of the sysName.</p> <p>0 (default): Model name (PnP name) such as "MP C401SP"</p> <p>1: Host name</p>		
	bit 2	DFU	-	-
	bit 3	No I/O Timeout	Disabled	Enabled
		Enables/Disables MFP I/O Timeouts. If enabled, the MFP I/O Timeout setting will have no affect. I/O Timeouts will never occur.		
	bit 4	SD Card Save Mode	Disabled	Enabled
		If this bit switch is enabled, print jobs will be saved to the GW SD slot and not output to paper.		
	bit 5	[PS and PDF] Paper size error margin	±5pt	±10pt
When a PS job is printed by using a custom paper size, the job might not be printed because of a paper size mismatch caused by a calculation error. By default, the error margin for matching to a paper size is ±5 points. By enabling this BitSwitch, the error margin for matching to a paper size can be extended to ±10 points.				
bit 6	DFU	-	-	
bit 7	[RPCS,PCL]: Printable area frame border	Disabled	Enabled	
	Prints all RPCS and PCL jobs with a border around the printable area.			

1001

[Bit Switch]

1-001-00 2	Bit Switch 2		0	1
	bit 0	DFU	-	-
	bit 1	DFU	-	-
	bit 2	Applying a Collate Type	Shift Collate	Normal Collate
		<p>A collate type (shift or normal) will be applied to all jobs that do not explicitly define a collate type.</p> <p>Note: If #5-0 is enabled, this BitSwitch has no effect.</p>		
	bit 3	[PCL5e/c,PS]: PDL Auto Switching	Enabled	Disabled
		<p>Enables/Disables the MFPs ability to change the PDL processor mid-job.</p> <p>Some host systems submit jobs that contain both PS and PCL5e/c. If Auto PDL switching is disabled, these jobs will not be printed properly.</p>		
	bit 4	Color balance switching	Disabled	Enabled
		<p>This BitSwitch can be used to restore the color balance to match that of previous models. If this BitSwitch is set to "1" (Enabled), the color balance from 09A and Extended 09A models will be used.</p>		
bit 5	DFU	-	-	
bit 6	DFU	-	-	
bit 7	DFU	-	-	
1001	[Bit Switch]			

1-001-00 3	Bit Switch 3		0	1
	bit 0	DFU	-	-
	bit 1	DFU	-	-
	bit 2	[PCL5e/c]: Legacy HP compatibility	Disabled	Enabled
		Uses the same left margin as older HP models such as HP4000/HP8000. In other words, the left margin defined in the job (usually "<ESC>*r0A") will be changed to "<ESC>*r1A".		
	bit 3	DFU	-	-
	bit 4	DFU	-	-
	bit 5	DFU	-	-
	bit 6	DFU	-	-
	bit 7	DFU	-	-

1001	[Bit Switch]			
1-001-00 4	Bit Switch 4		0	1
	bit 0	DFU	-	-
	bit 1	DFU	-	-
	bit 2	DFU	-	-
	bit 3	DFU	-	-
	bit 4	DFU	-	-
	bit 5	DFU	-	-
	bit 6	DFU	-	-
	bit 7	DFU	-	-

1001	[Bit Switch]		
1-001-00 5	Bit Switch 5	0	1

	bit 0	Show "Collate Type", "Staple Type" and "Punch Type" buttons on the operation panel.	Disabled	Enabled
		<p>If enabled, users will be able to configure a Collate Type, Staple Type, and Punch Type from the operation panel. The available Types will depend on the device and configured options.</p> <p>After enabling this BitSw, the settings will appear under: "User Tools > Printer Features > System"</p>		
	bit 1	Multiple copies if a paper size or type mismatch occurs	Disabled (single copy)	Enabled (multiple)
		<p>If a paper size or type mismatch occurs during the printing of multiple copies, only a single copy is output by default. Using this BitSw, the device can be configured to print all copies even if a paper mismatch occurs.</p>		
	bit 2	Prevent SDK applications from altering the contents of a job.	Disabled	Enabled
		<p>If this BitSw is enabled, SDK applications will not be able to alter print data. This is achieved by preventing SDK applications from accessing a module called the "GPS Filter".</p> <p>Note: The main purpose of this BitSw is for troubleshooting the effects of SDK applications on data.</p>		
	bit 3	[PS] PS Criteria	Pattern3	Pattern 1
		<p>Change the number of PS criterion used by the PS interpreter to determine whether a job is PS data or not.</p>		
	bit 4	Increase max. number of stored jobs.	Disabled (100)	Enabled (750)
		<p>Changes the maximum number of jobs that can be stored on the HDD. The default (disabled) is 100. If this is enabled, the max. will be raised to 750 or 1000 depending on the model.</p>		
	bit 5	Face-up output	Disabled	Enabled (Face-up)

	bit 6	Method for determining the image rotation for the edge to bind on.	Disabled	Enabled
		<p>If enabled, the image rotation will be performed as they were in the specifications of older models for the binding of pages of mixed orientation jobs.</p> <p>The old models are below:</p> <ul style="list-style-type: none"> - PCL: Pre-04A models - PS/PDF/RPCS:Pre-05S models 		
	bit 7	DFU	-	-

1001	[Bit Switch]			
1-001-006	Bit Switch 6		0	1
	bit 0	DFU	-	-
	bit 1	DFU	-	-
	bit 2	DFU	-	-
	bit 3	DFU	-	-
	bit 4	DFU	-	-
	bit 5	DFU	-	-
	bit 6	DFU	-	-
	bit 7	DFU	-	-

1001	[Bit Switch]		
------	--------------	--	--

1-001-00 7	Bit Switch 7		0	1
		Print path	Disabled	Enabled
	bit 0	If enabled, simplex pages (in mixed simplex/duplex PS/PCL5 jobs only) and the last page of an odd paged duplex job (PS, PCL5, PCL6), are always routed through the duplex unit. Not having to switch paper paths increases the print speed slightly.		
	bit 1	DFU	-	-
	bit 2	DFU	-	-
	bit 3	DFU	-	-
	bit 4	DFU	-	-
	bit 5	DFU	-	-
	bit 6	DFU	-	-
	bit 7	DFU	-	-
1001	[Bit Switch]			

1-001-00 8	Bit Switch 8		0	1
	bit 0	DFU	-	-
	bit 1	DFU	-	-
	bit 2	DFU	-	-
	bit 3	DFU	-	-
	bit 4	DFU	-	-
	bit 5	DFU	-	-
	bit 6	DFU	-	-
	bit 7	[PDF]: Orientation Auto Detect Function	Enabled	Disabled
Automatically chooses page orientations of PDF jobs (Landscape or Portrait) based on the content.				

1001	[Bit Switch]			
1-001-00 9	Bit Switch 9		0	1
	bit 0	PDL Auto Detection timeout of jobs submitted via USB or Parallel Port (IEEE 1284).	Disabled (Immediately)	Enabled (10 seconds)
To be used if PDL auto-detection fails. A failure of PDL auto detection doesn't necessarily mean that the job can't be printed. This bit switch tells the device whether to time-out immediately (default) upon failure or to wait 10 seconds.				

	bit 1	DFU	-	-
	bit 2	Job Cancel	Disabled (Not cancelled)	Enabled (Cancelled)
		<p>If this bit switch, all jobs will be cancelled after a jam occurs.</p> <p>Note: If this bitsw is enabled, printing under the following conditions might result in problems:</p> <ul style="list-style-type: none"> - Job submission via USB or Parallel Port - Spool printing (WIM >Configuration > Device Settings > System) 		
	bit 3	DFU	-	-
	bit 4	Timing of the PjL Status ReadBack (JOB END) when printing multiple collated copies.	Disable	Enable
		<p>This bitsw determines the timing of the PjL USTATUS JOB END sent when multiple collated copies are being printed.</p> <p>0 (default): JOB END is sent by the device to the client after the first copy has completed printing. This causes the page counter to be incremented after the first copy and then again at the end of the job.</p> <p>1: JOB END is sent by the device to the client after the last copy has finished printing. This causes the page counter to be incremented at the end of each job.</p>		
	bit 5	Display UTF-8 text in the operation panel	Enabled	Disabled
		<p>Enabled (=0): Text composed of UTF-8 characters can be displayed in the operation panel.</p> <p>Disabled (=1): UTF-8 characters cannot be displayed in the operation panel.</p> <p>For example, job names are sometimes stored in the MIB using UTF-8 encoded characters. When these are displayed on the operation panel, they will be garbled unless this BitSw is enabled (=0).</p>		
	bit 6	Disable super option	Enabled	Disabled
		<p>Switches super option disable on / off. If this is On, multiple jobs are grouped at LPR port. PjL settings are enabled even jobs that are specified queue names are sent.</p>		

	bit 7	Enable/Disable Print from USB/SD's Preview function	Enabled	Disabled
		<p>Determines whether Print from USB/SD will have the Preview function.</p> <p>Enabled (=0): Print from USB/SD will have the Preview function.</p> <p>Disabled (=1): Print from USB/SD will not have the Preview function.</p>		

1001	[Bit Switch]			
1-001-010	Bit Switch A		0	1
	bit 0	DFU	-	-
	bit 1	DFU	-	-
	bit 2	DFU	-	-
	bit 3	DFU	-	-
	bit 4	DFU	-	-
	bit 5	Store and Skip Errored Job locks the queue	Queue is not locked after SSEJ	Queue locked after SSEJ
		<p>If this is 1, then after a job is stored using Store and Skip Errored Job (SSEJ), new jobs cannot be added to the queue until the stored job has been completely printed.</p>		
	bit 6	Allow use of Store and Skip Errored Job if connected to an external charge device.	Does not allow SSEJ with ECD	Allows SSEJ with ECD
		<p>If this is 0, Store and Skip Errored Job (SSEJ) will be automatically disabled if an external charge device is connected.</p> <p>Note: We do not officially support enabling this bitsw (1). Use it at your own risk.</p>		

	bit 7	Job cancels remaining pages when the paid-for pages have been printed on an external charge device	Job does not cancel	Job cancels
	<p>When setting 1 is enabled, after printing the paid-for pages on an external charge device, the job that includes any remaining pages will be canceled.</p> <p>This setting will prevent the next user from printing the unnecessary pages from the previous user's print job.</p>			

3

1001	[Bit Switch]			
1-001-011	Bit Switch B		0	1
	bit 0	Show Menu List	Hide Menu List	Show Menu List
	If this is 0, the Menu List button will be removed from Printer Features.			
	bit 1	Print job interruption	Does not allow interruption	Allow interruption
	<p>0 (default): Print jobs are not interrupted. If a job is promoted to the top of the print queue, it will wait for the currently printing job to finish.</p> <p>1: If a job is promoted to the top of the queue, it will interrupt the currently printing job and start printing immediately.</p>			
	bit 2	DFU	-	-
	bit 3	Not Used	-	-

	bit 4	Add "Apply Auto Paper Select" is the condition that decides if the device's paper size or paper type should be overwritten.	Disabled	Enabled-
		<p>If this BitSwitch is set to "1" (enabled), the "Apply Auto Paper Select" setting will decide if the paper size or paper type that is specified in the device settings should be overwritten by the job's commands when "Tray Setting Priority" is set to "Driver/Command" or "Any Type".</p> <p>- Apply Auto Paper Select = OFF: Overwritten (priority is given to the job's commands)</p> <p>- Apply Auto Paper Select = ON: Not overwritten (priority is given to the device settings)</p>		
	bit 5	DFU	-	-
	bit 6	DFU	-	-
	bit 7	DFU	-	-

1001	[Bit Switch]
------	--------------

1-001-012	Bit Switch C		0	1
	bit 0	DFU	-	-
	bit 1	DFU	-	-
	bit 2	DFU	-	-
	bit 3	DFU	-	-
	bit 4	DFU	-	-
	bit 5	Change the user ID type displayed on the operation panel	Login User Name	User ID
	As of 15S models, the Login User Name can be displayed on the operation panel. The user ID type displayed on the operation panel can be changed by configuring BitSwitch #12-5 as follows: - 0 (default): Login User Name - 1: User ID. If this is enabled, User ID will be displayed, which is equivalent to the behavior exhibited in 14A and earlier models.			
	bit 6	DFU	-	-
bit 7	DFU	-	-	

1003	[Clear Setting]		
1-003-001	Initialize System	*CTL	[- / - / -] [Execute]
Initializes settings in the "System" menu of the user mode.			
1-003-003	Delete Program	*CTL	[- / - / -] [Execute]

1004	[Print Summary]		
	Prints the service summary sheet (a summary of all the controller settings).		
1-004-001	Print Summary	*CTL	[- / - / -] [Execute]
1-004-002	Print Summary2	*CTL	[- / - / -] [Execute]

1005	[Display Version]		
	1-005-002	Printer Version	*CTL [- / - / -]
Displays the version of the controller firmware.			

1006	[Sample / Proof Print]		
	1-006-001	Sample / Proof Print	*CTL [0 or 1 / 1 / 1 / step] 0: Linked, 1: On
Enables and disables the document server. When you select "0," the document server is enabled or disabled in accordance with Copy Service Mode SP5-967. When you select "1," the document server is enabled regardless of Copy Service Mode SP5-967.			

1101	[Data Recall]		
	Recalls a set of gamma settings. This can be either a) the factory setting, b) the previous setting, or c) the current setting.		
1-101-001	Factory	*CTL	[- / - / -]
1-101-002	Previous	*CTL	[Execute]
1-101-003	Current	*CTL	
1-101-004	ACC	*CTL	

1102	[Resolution Setting]		
	Selects the printing mode (resolution) for the printer gamma adjustment.		

1-102-001	Tone Control Mode Selection	CTL	[0 to 8 / 0 / 1/step] 0: 1200x1200 Photo 1: 2400x600 Photo 2: 1800x600 Photo 3: 00x600 Photo 4: 1200x1200 Text 5: 2400x600 Text 6: 1800x600 Text 7: 600x600 Text
-----------	-----------------------------	-----	--

1103	[Test Page]		
	Prints the test page to check the color balance before and after the gamma adjustment.		
1-103-001	Color Gray Scale	CTL	[- / - / -]
1-103-002	Color Pattern	CTL	[Execute]

1104	[Gamma Adjustment]		
	Adjusts the printer gamma for the mode selected in the "Mode Selection" menu.		

1-104-001	Black: Highlight	CTL	[0 to 30 / 00 / 1/step]
1-104-002	Black: Shadow	CTL	
1-104-003	Black: Middle	CTL	
1-104-004	Black: IDmax	CTL	
1-104-021	Cyan: Highlight	CTL	
1-104-022	Cyan: Shadow	CTL	
1-104-023	Cyan: Middle	CTL	
1-104-024	Cyan: IDmax	CTL	
1-104-041	Magenta: Highlight	CTL	
1-104-042	Magenta: Shadow	CTL	
1-104-043	Magenta: Middle	CTL	
1-104-044	Magenta: IDmax	CTL	
1-104-061	Yellow: Highlight	CTL	
1-104-062	Yellow: Shadow	CTL	
1-104-063	Yellow: Middle	CTL	
1-104-064	Yellow: IDmax	CTL	

1105	[Save Tone Control Value]		
	Stores the print gamma adjusted with the "Gamma Adj." menu item as the current setting. Before the machine stores the new "current setting", it moves the data currently stored as the "current setting" to the "previous setting" memory storage location.		
1-105-001	Save Tone Control Value	*CTL	[- / - / -] [Execute]

1106	[Toner Limit]		
	Adjusts the maximum toner amount for image development.		
1-106-001	Toner Limit Value	*CTL	[0 to 400 / 0 / 1 %/step]

1110	[Media Print Device Setting]		
	Selects the setting for the media print device.		
1-110-002	0: Disable 1: Enable	*CTL	[0 or 1 / 1 / 1 / step]
1111	[All Job Delete Mode]		
	1-111-001	-	*CTL [0 or 1 / 0 / 1 / step] 0: Excluding New Job 1: Including New Job
Selects whether to include an image processing job in jobs subject to full cancellation from the SCS job list.			
1113	[IBACC Exec]		
	Sets IBACC correction execution (calculation IBACC gamma) on / off. 0: Not calculate IBACC gamma. (Sets IBACC gamma linear) 1: Calculate IBACC gamma		
1-113-001	0:Off 1:On	*CTL	[0 or 1 / 1 / 1/step]
1114	[IBACC ToneCtlSet]		
	Sets back to the previous value of IBACC gamma correction for all resolutions. If there is no previous value, sets to the factory default values.		
1-114-001	Tone (Prev.)	CTL	-
1-114-002	Tone (Factory)	CTL	-
1115	[IBACC Exec Time]		
	Displays the time when IBACC is executed or sets back to the previous / initial value.		
1-115-001	Time	CTL	-

Scanner Service Menu

SP1-XXX (System and Others)

1001	[Scan Nv Version]		
1-001-005	-	*CTL	[- / - / -]
1005	[Erase Margin(Remote scan)]		
1-005-001	Range from 0 to 5 mm	*CTL	[0 to 5 / 0 / 1 / step]
1009	[Remote scan disable]		
1-009-001	0:Enable 1:Disable	*CTL	[0 or 1 / 0 / 1 / step] 0: ON (enabled) 1: OFF (disabled)
1010	[Non Display Clear Light PDF]		
1-010-001	0:Display 1:Nondisplay	*CTL	[0 or 1 / 0 / 1 / step] 0: Display, 1: No display
1011	[Org Count Display]		
1-011-001	0:ON 1:OFF	*CTL	[0 or 1 / 0 / 1 / step] 0: OFF (no display) 1: ON (count displays)
1012	[User Info Release]		
1-012-001	0:No 1:Yes	*CTL	[0 or 1 / 1 / 1 / step] 1: Release 0: Do not release
1013	[Multi Media Function]		

1-013-002	0:OFF 1:ON	*CTL	[0 or 1 / 1 / 1 / step] 0: Disable 1: Enable
-----------	------------	------	--

1014	[Scan to Folder Pass Input Set]		
1-014-001	0: OFF 1: ON	*CTL	[0 or 1 / 0 / 1 / step] 0: OFF 1: ON

1041	[Scan:FlairAPI Setting]			
1-041-001	0x00 – 0xff	*CTL	* see BitSwitch below:	
Sets Scanner FlairAPI Function enable / disable. This SP is set by BitSwitch and needs to reboot the machine after making changes.				
bit	Setting	meanings		Description
		0	1	
bit 0	Start of FlairAPI Server	Off (Do not Start)	On (Start)	Sets whether to start exclusive FlairAPI http server. If it is 0, scanning FlairAPI function and simple UI function will be disabled.
bit 1	Access permission of FlairAPI from outside of the machine	Disabled	Enabled	If it is "0", accessing is limited from the machine only, such as operating panel, SDK/J, MFP browsers etc... If it is "1", accessing is allowed from outside of FlairAPI such as PC, Remote UI, IT-Box etc...

bit 2	IPv6 (Exclusive) / IPv4 (Priority) Switching	IPv6 (Exclusive)	IPv4 (Priority)	If this bit is "0", only IPv6 accessing is permitted. If this bit is "1" and IPv4 is enabled, the machine uses IPv4 accessing. If this bit is "1" and IPv4 is disabled, the machine uses IPv6 accessing. In this case, it is unable to access through Smart Operation Panel if IPv4 address is enabled.
bit 3	Remote UI Function	Not Used	Use	Sets use of Remote UI for scanner function.
bit 4	Reserved	-	-	-
bit 5	Reserved	-	-	-
bit 6	Reserved	-	-	-
bit 7	Reserved	-	-	-

SP2-XXX (Scanning-image quality)

2021	[Compression Level (Gray-scale)]		
2-021-001	Comp1:5-95	*CTL	[5 to 95 / 20 / 1 / step]
2-021-002	Comp2:5-95	*CTL	[5 to 95 / 40 / 1 / step]
2-021-003	Comp3:5-95	*CTL	[5 to 95 / 65 / 1 / step]
2-021-004	Comp4:5-95	*CTL	[5 to 95 / 80 / 1 / step]
2-021-005	Comp5:5-95	*CTL	[5 to 95 / 95 / 1 / step]

2023	[ClearLightPDF:ACS Setting]		
This SP code enables/disables the ACS function.			
2-023-001	0:OFF 1:ON	*CTL	[0 or 1 / 1 / 1 / step] 0: Disable 1: Enable

2024	[Compression ratio of ClearLight PDF]		
2-024-001	Compression Ratio (Normal)	*CTL	[5 to 95 / 20 / 1 / step]
2-024-002	Compression Ratio (High)	*CTL	[5 to 95 / 20 / 1 / step]

2025	[Compression ratio of ClearLightPDF JPEG2000]		
2-025-001	Compression Ratio (Normal) JPEG2000	*CTL	[5 to 95 / 25 / 1 / step]
2-025-002	Compression Ratio (High) JPEG2000	*CTL	[5 to 95 / 15 / 1 / step]

2030	[OCR PDF DetectSens]		
2-030-001	White Lumi Value: 0 - 255	*CTL	[0 to 255 / 250 / 1 / step]
2-030-002	White Pix Ratio: 0 - 100	*CTL	[0 to 100 / 80 / 1 / step]
2-030-003	White Tile Ratio: 0 - 100	*CTL	[0 to 100 / 80 / 1 / step]

2031	[Vertical Judgment Setting]		
2-031-001	Function Setting: 0 - 1	*CTL	[0 to 255 / 250 / 1 / step]
2-031-002	Algorithm Setting: 0 - 2	*CTL	[0 to 100 / 80 / 1 / step]