

imageCLASS MF515dw

SERVICE MANUAL



Canon

**March 4, 2016
Rev. 1**

Introduction

Important Notices

Application

This manual has been issued by Canon Inc. for qualified persons to learn technical theory, installation, maintenance, and repair of products.

This manual covers all localities where the products are sold. For this reason, there may be information in this manual that does not apply to your locality.

Corrections

This manual may contain technical inaccuracies or typographical errors due to improvements or changes in products. When changes occur in applicable products or in the contents of this manual, Canon will release technical information as the need arises. In the event of major changes in the contents of this manual over a long or short period, Canon will issue a new edition of this manual.

The following paragraph does not apply to any countries where such provisions are inconsistent with local law.

Trademarks

The product names and company names used in this manual are the registered trademarks of the individual companies.

Copyright

This manual is copyrighted with all rights reserved. Under the copyright laws, this manual may not be copied, reproduced or translated into another language, in whole or in part, without the consent of Canon Inc.







Copyright CANON INC. 2016















Caution

Use of this manual should be strictly supervised to avoid disclosure of confidential information.



Explanation of Symbols

The following symbols are used throughout this Service Manual.

Symbols	Explanation	Symbols	Explanation
	Check.		Remove the claw.
	Check visually.		Insert the claw.
	Check a sound.		Push the part.

Symbols	Explanation	Symbols	Explanation
	Disconnect the connector.		Connect the power cable.
	Connect the connector.		Disconnect the power cable.
	Remove the cable/wire from the cable guide or wire saddle.		Turn on the power.
	Install the cable/wire to the cable guide or wire saddle.		Turn off the power.
	Remove the screw.		Loosen the screw.
	Install the screw.		Tighten the screw.
	Cleaning is needed.		Measurement is needed.

The following rules apply throughout this Service Manual:

- Each chapter contains sections explaining the purpose of specific functions and the relationship between electrical and mechanical systems with reference to the timing of operation.
In the diagrams,  represents the path of mechanical drive; where a signal name accompanies the symbol, the arrow  indicates the direction of the electric signal.
The expression "turn on the power" means flipping on the power switch, closing the front door, and closing the delivery unit door, which results in supplying the machine with power.
- In the digital circuits, '1' is used to indicate that the voltage level of a given signal is "High", while '0' is used to indicate "Low". (The voltage value, however, differs from circuit to circuit.) In addition, the asterisk (*) as in "DRMD*" indicates that the DRMD signal goes on when '0'.
In practically all cases, the internal mechanisms of a microprocessor cannot be checked in the field. Therefore, the operations of the microprocessors used in the machines are not discussed: they are explained in terms of from sensors to the input of the DC controller PCB and from the output of the DC controller PCB to the loads.

The descriptions in this Service Manual are subject to change without notice for product improvement or other purposes, and major changes will be communicated in the form of Service Information bulletins.

All service persons are expected to have a good understanding of the contents of this Service Manual and all relevant Service Information bulletins and be able to identify and isolate faults in the machine.

Contents

Safety Precautions.....	1
Laser Safety.....	2
How to Handle the Laser Scanner Unit.....	2
Toner Safety.....	2
About Toner.....	2
Handling Adhered Toner.....	2
Notes When Handling a Lithium Battery.....	3
Notes on Assembly/Disassembly.....	3
1. Product Overview.....	4
Product Lineups.....	5
Host machine.....	5
Options.....	5
Product Features.....	7
Specifications.....	8
Product Specifications.....	8
ADF Specifications.....	9
Wireless LAN Specifications.....	10
Specification of SEND.....	10
FAX specification (supported models only).....	10
Print speed.....	11
Paper type.....	11
Paper size.....	11
Parts Name.....	13
External View.....	13
Cross Sectional View.....	16
Control Panel.....	17
2. Technical Explanation (Device).....	19
Basic Configuration.....	20
Configuration Function.....	20
Basic Sequence.....	21
Basic Operational Sequence.....	21
Document Exposure / Delivery System.....	22
Document Exposure System.....	22
Document Feeder System.....	22
Controller System.....	26
Outline.....	26
Controls.....	26
Low-voltage Power Supply.....	28
Laser Exposure System.....	30
Outline.....	30
Optical Unit Failure Detection.....	30
Image Formation System.....	31

Outline.....	31
Image Formation Process.....	31
High-voltage Power Supply.....	34
Fixing System.....	36
Outline.....	36
Controls.....	36
Pickup / Feed System.....	39
Outline.....	39
Drive Configuration.....	39
Jam Detection.....	40
3. Technical Explanation (System).....	42
Technical Explanation (System).....	43
Overview of System Management.....	43
Version Upgrade.....	43
Setting Information Export/Import Function (DCM).....	49
Monitoring Function (e-Maintenance/imageWARE Remote).....	80
4. Periodical Service.....	84
Periodically Replaced Parts.....	85
Consumable Parts.....	86
Periodical Service.....	87
Cleaning.....	88
5. Disassembly/Assembly.....	89
External Cover.....	90
Major Units.....	95
Electrical Components Layout Drawing.....	97
Motor/Fan.....	97
Solenoid.....	98
Others.....	98
Sensor/Switch.....	99
PCB.....	100
List of Connectors.....	102
Disassembled Parts.....	105
External Cover System.....	105
Original Exposure/Feed System.....	110
Controller System.....	111
Laser Exposure System.....	113
Image Formation System.....	113
Fixing System.....	114
Pickup Feed System.....	114
External Cover System.....	115
Removing the Right Cover.....	115
Removing the Left Cover.....	115
Removing the Rear Cover Unit.....	118
Removing the Rear Right Cover.....	119
Removing the Multi-purpose Tray Auxiliary Tray Unit.....	120

Removing the Front Cover Unit.....	121
Removing the Right Front Inner Cover.....	122
Removing the Right Lower Cover.....	123
Removing the Upper Cover.....	124
Original Exposure/Feed System.....	126
Removing the ADF + Reader Unit.....	126
Removing the ADF Roller Unit.....	127
Removing the ADF Pickup Roller.....	128
Removing the ADF Separation Roller.....	128
Removing the ADF Separation Pad.....	129
Removing the ADF Pickup Feed Unit.....	130
Removing the ADF Pickup Motor Unit.....	131
Removing the ADF Delivery Solenoid Unit.....	132
Removing the Reader Unit Upper Cover.....	132
Removing the CIS Unit.....	133
Controller System.....	135
Removing the Main Controller PCB.....	135
Removing the Wireless LAN PCB (except for D1520/MF412dn).....	135
Removing the Fax PCB (MF515x/MF515dw).....	136
Removing the OFF Hook PCB (MF515x/MF515dw).....	137
Removing the Speaker (MF515x/MF515dw).....	137
Removing the Arrestor PCB (230 V only).....	137
Removing the AC Relay PCB.....	138
Removing the All-night Power Supply PCB.....	138
Removing the PCB Unit.....	138
Removing the Power Switch.....	139
Removing the Cartridge Door Switch.....	140
Removing the Cassette Sensing Switch.....	140
Removing the Environment Sensor.....	140
Removing the Main Fan.....	141
Removing the Engine Controller Unit.....	141
Removing the Main Motor.....	144
Removing the Fixing Motor.....	146
Removing the Sub Fan.....	147
Removing the Multi-purpose Tray Pickup Solenoid.....	149
Removing the Cassette Pickup Solenoid.....	150
Removing the High Voltage Power Supply Unit.....	152
Removing the USB PCB.....	155
Removing the Control Panel Unit.....	156
Removing the Control Panel PCB.....	157
Laser Exposure System.....	159
Removing the Laser Scanner Unit.....	159
Image Formation System.....	160
Removing the Transfer Roller.....	160
Removing the Registration Unit.....	160
Fixing System.....	161
Removing the Fixing Assembly.....	161
Pickup Feed System.....	162
Removing the Multi-purpose Tray Pickup Roller.....	162
Removing the Cassette Separation Pad.....	162
Removing the Cassette Pickup Roller Unit.....	162

Removing the Cassette Separation Pad.....	164
Removing the Duplex Feed Unit.....	164
Removing the Pickup Unit.....	165
6. Adjustment.....	167
Overview.....	168
Actions after Replacement Parts.....	169
Document Exposure / Delivery System.....	169
Controller System.....	181
7. Troubleshooting.....	183
Test Print.....	184
Test Pages.....	184
Trouble Shooting Items.....	186
Special Mode.....	186
Debug Log.....	188
Function Overview.....	188
Conditions for collecting logs.....	188
Collection procedure.....	188
8. Error/Jam/Alarm.....	190
Overview.....	191
Jam Code.....	191
Error codes.....	192
Jam code.....	195
Alarm Code.....	198
9. Service Mode.....	199
Overview.....	200
Service Mode Menu.....	200
Backing up Service Mode.....	200
Screen flow of Service mode.....	201
Remote UI Service Mode.....	201
COPIER.....	204
DISPLAY.....	204
ADJUST.....	206
FUNCTION.....	218
OPTION.....	230
COUNTER.....	240
FEEDER.....	245
ADJUST.....	245
FUNCTION.....	246
FAX.....	248
List of SSSW.....	248
List of MENU.....	249
List of NUM.....	249
Setting of NCU Parameters.....	250
TESTMODE.....	254

PRINT..... 254
 FAX..... 256
 MODEM..... 256
 FACULTY..... 258

10. Installation..... 260

Copy Card Reader-F1 (Counter meter-installed models only)..... 261
 Points to Note at Installation..... 261
 Installation Outline Drawing..... 261
 Checking the Contents..... 261
 Check Items When Turning OFF the Main Power..... 261
 Installation Procedure..... 262
 Setting after Installation..... 265
 MiCARD Attachment Kit-B1 (Counter meter-installed models only)..... 267
 Points to Note at Installation..... 267
 Installation Outline Drawing..... 267
 Checking the Contents..... 267
 Check Items When Turning OFF the Main Power..... 267
 Installation Procedure..... 268
 Control Interface Kit-C1 (Counter meter-installed models only)..... 270
 Points to Note at Installation..... 270
 Installation Outline Drawing..... 270
 Checking the Contents..... 270
 Check Items When Turning OFF the Main Power..... 270
 Installation Procedure..... 271

APPENDICES..... 273

Service Tools..... 274
 Special Tools..... 274
 Solvents and Oils..... 274
 General Timing Chart..... 275
 General Circuit Diagram..... 276
 General Circuit Diagram(1/1)..... 276
 Backup Data..... 277
 Soft Counter Specifications..... 279

Safety Precautions

Laser Safety.....	2
How to Handle the Laser Scanner Unit	2
Toner Safety.....	2
Notes When Handling a Lithium Battery.....	3
Notes on Assembly/Disassembly.....	3

Laser Safety

Since radiation emitted inside the machine is completely confined within protective housings and external covers, the laser beam cannot escape from the machine during any phase of user operation.

Therefore this machine is classified in Class 1 laser products that are regarded as safe during normal use according to International Standard IEC60825-1.

How to Handle the Laser Scanner Unit

This machine is classified in Class 1 laser products.

However, inside the scanner unit, there is source of Class 3B laser beam and the laser beam is hazardous when entered into an eye. So, be sure not to disassemble the laser scanner unit. No adjustment can be made to the laser scanner unit in this machine in the field.


The label show in the following figure is attached on the laser scanner unit.

The following warnings are given to comply with Safety Principles (EN60950-1).

Diese Maschine ist der Klasse 1 der Laserprodukte zugeordnet.

Innerhalb der Scannereinheit befindet sich jedoch die Laserstrahlquelle der Klasse 3B und es ist gefährlich, wenn dieser Strahl in die Augen gerät. Die Laserscannereinheit darf unter keinen Umständen entfernt werden. Es dürfen in diesem Umfeld der Maschine keine Justagen an der Laserscannereinheit vorgenommen werden.

Das Etikett in folgendem Bild ist auf der Laserscannereinheit angebracht.



Toner Safety

About Toner

Toner is a nontoxic matter composed of plastic, iron and a trace of pigments.

CAUTION:

Never throw toner in flames to avoid explosion.

Handling Adhered Toner

- Use dry tissue paper to wipe off toner adhered to skin or clothes and wash in water.

- Never use warm water for cleaning up toner to prevent toner particles from being gelated to soak into fibers permanently.
- Toner particles are reactive with vinyl polymers. Avoid contacting these materials.

Notes When Handling a Lithium Battery

⚠ CAUTION:
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

The following warnings are given to comply with Safety Principles (EN60950-1).

⚠ CAUTION:
Wenn mit dem falschen Typ ausgewechselt, besteht Explosionsgefahr.
Gebrauchte Batterien gemäß der Anleitung beseitigen.

警告
如果更換不正確之電池型式會有爆炸的風險
請依製造商說明書處理用過之電池

Notes on Assembly/Disassembly

Follow the items below to assemble/disassemble the device.

1. Disconnect the power plug to avoid any potential dangers during assembling/disassembling works.
2. If not specially instructed, reverse the order of disassembly to reinstall.
3. Ensure to use the right screw type (length, diameter, etc.) at the right position when assembling.
4. To keep electric conduction, binding screws with washers are used to attach the grounding wire and the varistor. Ensure to use the right screw type when assembling.
5. Unless it is specially needed, do not operate the device with some parts removed.
6. Never remove the paint-locked screws when disassembling.

CAUTION:
Double pole/neutral fusing

CAUTION
DOUBLE POLE/NEUTRAL FUSING

ACHTUNG
Zweipolige bzw. Neutralleiter-Sicherung




Product Overview


Product Lineups.....	5
Product Features.....	7
Specifications.....	8
Parts Name.....	13

Product Lineups

Host machine


Function	MF515x/ MF515dw	MF512x
External		
Copy	Yes	Yes
Print	Yes	Yes
Fax	Yes	-
Scan to USB	Yes	Yes
SEND	Yes	Yes
Remote UI	Yes	Yes
DADF	Yes	Yes
2-sided printing (only paper of 60 to 120 g/m ²)	Yes	Yes
Secured Print	Yes	Yes
MEAP	-	-
Network	Yes	Yes
Wireless LAN	Yes	Yes
Direct mode	Yes	Yes
NFC	-	-

Options



No.	Name	Description	Remarks
[1]	Paper Feeder Unit PF-45	Approx. 500 sheets (Plain paper 60 to 90 g/m ²)	
[2]	HANDSET-J1	Addition of phone	MF515x/ MF515dw
[3]	Copy Control Interface Kit-C1	Connector for connecting the coin vendor (CC-VI) <ul style="list-style-type: none"> • Cannot be installed with the Copy Card Reader Attachment-J1 	
[4]	Copy Card Reader-F1	Copy Card Reader <ul style="list-style-type: none"> • Copy Card Reader Attachment-J1 is required • Cannot be installed with the MiCARD Attachment Kit-B1 	
[5]	Copy Card Reader Attachment-J1	A base for installing the Copy Card Reader <ul style="list-style-type: none"> • It is required when installing the Copy Card Reader-F1 • Cannot be installed with the Copy Control Interface Kit-C1 	
[6]	MiCARD Attachment Kit-B1	A base for installing the MiCARD <ul style="list-style-type: none"> • Cannot be installed with the Copy Card Reader-F1 	

Product Features



Improved Control Panel operability

A 3.5-inch color Touch Panel is installed. Support for touch and flick has realized the operability like a smartphone.

Support for direct mode (supported models only)

Direct communication between the host machine and smartphone, tablet, PC, etc. has been realized.

Improved productivity

High printing speed has been realized: 40 ppm for A4 paper and 42 ppm for LTR.

Specifications

Product Specifications

Item	Specifications/Function	
Copyboard type	Fixed Copyboard	
Machine installation method	Desktop (DADF equipped as standard)	
Light source	LED (RGB)	
Photosensitive medium	OPC Drum (30 mm dia.)	
Image reading method	CIS (color)	
Exposure method	Laser beam exposure	
Charging method	Roller charging	
Developing method	Toner projection development (one-component magnetic toner)	
Transfer method	Roller transfer method	
Separation method	Curvature separation	
Pickup	Cassette: Pad separation method Multi-purpose Tray: Pad separation method	
Drum cleaning method	Cleaning Blade	
Fixing method	On-demand fixing	
Toner level detection function	Yes	
Toner type	One-component magnetic toner	
Toner supplying method	Replacement of all-in-one cartridge (drum + toner)	
Toner saving mode	Yes	
Document type	Copyboard Glass: Plain paper, heavy paper, photo, small document (such as a name card), special paper (such as tracing paper and OHP film), book (up to 20 mm in width) Feeder: Plain paper (one sheet of document, or multiple sheets of document of the same size, width and weight)	
Max. size of document that can be read	215.9 mm x 355.6 mm	
Warm-up time*1 (Duration from power-on to standby)	16 sec. or less	
Reading resolution	<Text/Photo> : 300 dpi x 600 dpi (default) <Text>, <Photo>, <Text/Photo (high image quality)>: 600 dpi x 600 dpi	
Print resolution	600 x 600 dpi	
First copy time	Copyboard Glass: 7.9 sec. or less (A4), 7.8 sec. or less (LTR) Feeder: 9.7 sec. or less (A4), 9.6 sec. or less (LTR)	
First print time	7.6 sec. or less (A4), 7.5 sec. or less (LTR)	
Print speed	40 sheets/min (A4), 42 sheets/min (LTR)	
Paper type	Cassette	Plain paper, Recycled paper, Color paper, Heavy paper (91 to 120 g/m ²)
	Multi-Purpose Tray	Plain paper, Recycled paper, Color paper, Heavy paper (91 to 199 g/m ²), Label paper, Envelope
Paper size	Cassette	A4, B5, A5, LGL, LTR, STMT, EXEC, OFFICIO, B-OFFICIO, M-OFFICIO, G-LTR, G-LGL, FLS, A-FLS, I-LGL, Custom (width: 105.0 to 216.0 mm, length: 148.0 to 356.0 mm)
	Multi-Purpose Tray	A4, B5, A5, LGL, LTR, STMT, EXEC, OFFICIO, B-OFFICIO, M-OFFICIO, G-LTR, G-LGL, FLS, A-FLS, I-LGL, 76.2 x 127.0 mm (3"x5"), Envelope (No.10 (COM10), Monarch, C5, DL), Custom (width: 76.2 to 216.0 mm, length: 127.0 to 356.0 mm)
Cassette paper capacity	Approx. 500 sheets (60 to 90 g/m ²)	
Multi-purpose Tray pickup capacity	Approx. 100 sheets (60 to 90 g/m ²)	
Delivery Tray capacity	Delivery tray: Approx. 250 sheets (A4/LTR) Sub-delivery tray: Approx. 50 sheets (A4/LTR)	
Continuous reproduction	1 to 999 sheets	
Auto 2-sided printing	Yes (auto 2-sided printing is available only for LTR, A4, LGL, OFFICIO, B-OFFICIO, M-OFFICIO, FLS, I-LGL and Custom (width: 210.0 to 216.0 mm, length: 279.4 to 356.0 mm) that weighs between 60 g to 120 g/m ²)	
Memory capacity	1 GB	
Sleep mode	Yes	
Range of use environment temperature	10 to 30 deg C	

Item		Specifications/Function
Environment humidity range		20 to 80% (Relative humidity; without dew condensation)
Operation noise (Measured based on ISO7779, Declared noise emission value based on ISO9296)		LwAd (declared A-weighted sound power level (1 B = 10 dB)) At standby: No noise*3 At printing: 6.9 B or less (1-sided) At printing: 6.7 B or less (2-sided) LpAm (mean A-weighted emission sound-pressure level (bystander position)) At standby: No noise*3 At printing : Approx. 54 dB (1-sided) At printing : Approx. 52 dB (2-sided)
Rated power supply		120 to 127 V, 60 Hz 220 to 240 V, 50/60 Hz
Power consumption (Reference value)	Maximum	1450 W or less (120 V), 1470 W or less (230 V)
	At standby	USB connection: Average of approx. 11.2 W (120V), approx. 12.2 W (230V) Wired LAN connection: Average of approx. 11.3 W (120V), approx. 12.4 W (230V) Wireless LAN connection: Average of approx. 11.8 W (120V), approx. 12.9 W (230V)
	During sleep mode	USB connection: Average of approx. 0.7 W (120V), approx. 0.8 W (230V) Wired LAN connection: Average of approx. 0.8 W (120V), approx. 0.9 W (230V) Wireless LAN connection: Average of approx. 1.4 W (120V), approx. 1.5 W (230V)
	At turn-OFF of the main power switch	0.1 W or less
Dimensions (W x D x H)		453 × 477 × 503 mm (without options)
Weight*2		Approx. 24.3 kg
Interface		1000BASE-T 100BASE-TX 10BASE-T Hi-Speed USB USB IEEE 802.11 b/g/n (infrastructure mode)
Network		Yes
SEND		Yes

*1: It may vary depending on the usage conditions and environment of this machine.

*2: Including the Toner Cartridge

*3: Indicates that the sound pressure level of each bystander position is below the ISO 7779 absolute criteria for the background noise level.

ADF Specifications

Item	Specification/Function
Position to set a document	Center reference
Document processing mode	1-sided document -> 1-sided copy/2-sided copy 2-sided document -> 1-sided copy/2-sided copy
Document reading method	Stream reading
Basis weight of document	Reading of 1-sided document: 50 g to 105 g Reading of 2-sided document: 64 g to 105 g
Document stack capacity	A4/LTR: 50 sheets (80 g/m ²), LGL: 30 sheets (80 g/m ²)
Document processing speed	A4 1-sided document: 33 sheets/min LTR 1-sided document: 34.2 sheets/min A4/LTR 2-sided document: Approx. 12 sheets/min (Reference value)
Stacking of mixed-size paper	Yes (Paper of AB configuration and inch configuration cannot be mixed)
Function to automatically detect document density	None
Function to detect document size	None
Stamp function	None
Use environment	Depends on the host machine

Wireless LAN Specifications

Item	Specification/Function
Standard	IEEE 802.11g / IEEE 802.11b / IEEE 802.11n
Transmission system	DS-SS system / OFDM system
Frequency range	2412 to 2472 MHz
Communication mode	Infrastructure mode / Access point mode
Security	WEP, WPA-PSK (TKIP/AES-CCMP), WPA2-PSK (TKIP/AES-CCMP)
Setting method	WPS (Wi-Fi Protected Setup), Manual setup

Specification of SEND

Item	Specification/Function		
	File server transmission	E-Mail transmission	I-Fax
Communication protocol	SMB (TCP/IP), FTP	SMTP, POP3 *1	
Data format	PDF, PDF (high compression), PDF (high compression/OCR), PDF(OCR), JPEG, TIFF		TIFF
Resolution	JPEG: 300 dpi TIFF: 300 dpi (MMR compression) PDF/PDF (OCR) (B&W): 300 dpi (MMR compression) PDF/PDF (OCR) (Color): 200 dpi (JPEG compression) PDF (Compact)/PDF (compact/OCR): Text 300 dpi, background 150 dpi		200 dpi (MH compression)
System environment	<ul style="list-style-type: none"> Windows Vista/7/8/Server 2003/Server 2008/Server 2012 Solaris Version 2.6 or later (and Samba 2.2 or later) Mac OS X Red Hat Linux 7.2 or later (and Samba 2.2 or later) 		
Interface	1000BASE-T, 100BASE-TX, 10BASE-T		
Input image	Text, Text/Photo, Photo		
Color mode	Color, B&W		B&W
Original size	AB configuration: A4 / A5 / B5 Inch configuration: Legal (LGL), Letter (LTR), Statement (STMT)		

*1; In the case of E-mail transmission, POP3 can also be used only at authentication before transmission.

FAX specification (supported models only)

Item	Specifications/Function
Line used	Public Switched Telephone Network (PSTN) *1
Communication mode	Super G3, G3
Data compression method	MH, MR, MMR, JBIG
Modem speed	Super G3: 33.6 Kbps, G3: 14.4 Kbps (With automatic fallback function)
Transmission speed	Approx. 3 sec. per page*2 (ECM-JBIG, sent from memory at 33.6 kbps)
Send/Receive memory	Total number of sent/received pages: Approx. 512 pages *2 (Max. number of memory transmissions: 30, Max. number of memory receptions: 90)
Fax resolution	Normal: 200 x 100 dpi Fine: 200 x 200 dpi Photo: 200 x 200 dpi Super fine: 200 x 400 dpi Ultra fine: 400 x 400 dpi

Item	Specifications/Function
Dial method	Favorites (19) Coded dial (281) Group dial (299) Address book dial Normal dial (entry by numeric keypad) Auto redial Manual redial Sequential broadcast (310)
Reception method	Auto RX Manual RX Remote reception by a telephone (initial setting ID: 25)
Report Output	TX Report Communication Management Report (to be output automatically for every 40 communications by default) RX Result Report
Number Display	Not supported
Phones that can be connected	Handset (option) / External phone / Answering machine / Data modem

*1: Communication may not be available depending on the conditions of telephone lines and regions.

*2: On ITU-T Test Chart No.1, by JBIG standard mode.

Print speed

(Unit: sheets/min)

Paper size	1-sided	2-sided
A4	40	10
LTR	42	10

* The above values are the speed in the case of continuous printing of the same data on plain paper. Note that they may vary depending on the usage conditions and environment of this machine.

Paper type

(Yes: Pickup possible, -: Pickup not possible)

Paper type	Printer driver settings	Cassette	Multi-purpose Tray
Plain paper	60 to 90 g/m ²	Yes	Yes
	60 to 70 g/m ²	Yes	Yes
Color paper	60 to 90 g/m ²	Yes	Yes
Recycled paper	60 to 90 g/m ²	Yes	Yes
Heavy paper	91 to 105 g/m ²	Yes	Yes
	106 to 120 g/m ²	-	Yes
	121 to 199 g/m ²	-	Yes
Label paper	Labels	-	Yes
Envelope	Envelope	-	Yes

* Auto 2-sided printing is available only for LTR, A4 and LGL

Paper size

(Yes: Pickup possible, -: Pickup not possible)

Paper size	Cassette	Multi-purpose Tray
A4	Yes	Yes
B5	Yes	Yes

Paper size		Cassette	Multi-purpose Tray
A5	148.0 mm × 210.0 mm	Yes	Yes
Legal (LGL)	215.9 mm × 355.6 mm	Yes	Yes
Letter (LTR)	215.9 mm × 279.4 mm	Yes	Yes
Statement (STMT)	139.7 mm × 215.9 mm	Yes	Yes
Executive (EXEC)	184.1 mm × 266.7 mm	Yes	Yes
Oficio	215.9 mm × 317.5 mm	Yes	Yes
Oficio (Brazil)	215.9 mm × 355.0 mm	Yes	Yes
Oficio (Mexico)	215.9 mm × 341.0 mm	Yes	Yes
Letter (Government)	203.2 mm × 266.7 mm	Yes	Yes
Legal (Government)	203.2 mm × 330.2 mm	Yes	Yes
Foolscap	215.9 mm × 330.2 mm	Yes	Yes
Foolscap (Australia)	206.0 mm × 337.0 mm	Yes	Yes
Legal (India)	215.0 mm × 345.0 mm	Yes	Yes
3"×5"	76.2 mm × 127.0 mm	-	Yes
Envelope No.10 (COM10)	104.7 mm x 241.3 mm	-	Yes
Envelope Monarch	98.4 mm x 190.5 mm	-	Yes
Envelope C5	162.0 mm x 229.0 mm	-	Yes
Envelope DL	110.0 mm x 220.0 mm	-	Yes
Custom paper	-	Yes*1	Yes*2


*1: Custom paper whose width is between 105.0 mm and 216.0 mm and length between 148.0 mm and 356.0 mm can be loaded.

*2: Custom paper whose width is between 76.2 mm and 216.0 mm and length between 127.0 mm and 356.0 mm can be loaded.

Parts Name


External View

Front Side




Key	Name	Key	Name
1	Feeder	8	Multi-purpose tray
2	Ventilation slots	9	Scanning area
3	Lift handles	10	Output tray
4	Operation panel	11	Paper stopper
5	USB port (for USB device connection)	12	Platen glass
6	Front cover	13	Speaker
7	Paper drawer	14	Power switch

■ Back Side




Key	Name	Key	Name
1	USB port (for USB device connection)	6	Telephone line jack (supported models only)
2	USB port (for computer connection)	7	Sub-output tray
3	LAN port	8	Rating label
4	Handset jack (supported models only)	9	Power socket
5	External telephone jack (supported models only)		

■ Interior




Key	Name
1	Transport guide
2	Lock release switch

■ Multi-Purpose Tray



Key	Name
1	Paper guides
2	Paper tray
3	Tray extension


■ Paper Drawer



Key	Name
1	Paper guides
2	Paper level indicator


Cross Sectional View

■ ADF/Reader Unit




Key	Name
[1]	ADF Paper Feed Roller
[2]	ADF Separation Roller
[3]	ADF Pickup Roller
[4]	ADF Delivery roller
[5]	ADF Separation Pad

■ Host machine



Key	Name	Key	Name
[1]	Delivery Roller	[10]	Cassette Separation Pad
[2]	Fixing Film Unit	[11]	Cassette Pickup Roller
[3]	Laser Scanner Unit	[12]	Duplex Re-pickup Roller
[4]	Photosensitive Drum	[13]	Registration Roller
[5]	Cartridge	[14]	Transfer Roller
[6]	Registration Shutter	[15]	Duplex Feed Roller
[7]	Multi-purpose Pickup Roller	[16]	Pressure Roller
[8]	Multi-purpose Separation Pad	[17]	Fixing Delivery Roller
[9]	Feed Roller		

● Control Panel



Key	Name	Function
[1]	Home key	Press to return to the home screen.
[2]	Back key	Press to return to the screen one layer above.

Key	Name	Function
[3]	Quick Guide key	Press to view the operation methods and the causes/remedies of errors.
[4]	Status Monitor key	Press to check the job status or device status.
[5]	Energy Saver key	Press to manually enter/recover from energy saver mode.
[6]	Numeric keys	Press to enter the number of copies, zoom value and the names and numbers of address book.
[7]	Tone key	Press to send the tone signal from the dial line.
[8]	SYMBOLS key	Press to enter symbols.
[9]	Reset key	Press to reset the settings (to change the settings of copy/scan/fax/media print to standard mode).
[10]	ID key	Press after entering the ID and PIN to log on when Department ID Management is enabled. After using the machine, press again to log off.
[11]	Clear key	Press to clear numbers such as number of copies, or text.
[12]	Counter key	Press to display the counter status.
[13]	Start key	Press to start a job.
[14]	Stop key	Press to stop a job.
[15]	Touch Panel	Displays a message or operation status. Displays menu, selected item, texts, numbers and other information when changing settings. Tap or flick the panel when performing the operation.
[16]	Sound Volume key	Press to adjust the volume.

Key	LED	LED status	Condition
[21]	Start LED	Yellow and green are lit	When the machine can be started
		Unlit	When the machine cannot be started
[22]	Processing Data LED	Yellow and green are blinking	Job is being operated
		Yellow and green are lit	<ul style="list-style-type: none"> • When the memory has accumulated data • When received memory is waiting for processing * Lighting has priority when lighting and blinking simultaneously occur.
[23]	Wireless LAN LED	Blue is lit	Wireless LAN is connected
		Blue is blinking	Wireless LAN connection is being established
		Unlit	Wireless LAN is not connected
[24]	Error LED	Red is blinking	When an error that can be recovered by the user (such as paper jam, no paper/toner, etc.) occurs
		Red is lit	When an error that cannot be recovered by the user (service call) occurs * Lighting has priority when lighting and blinking simultaneously occur.
[25]	Energy Saver LED	Yellow and green are lit	During energy saver mode/low power mode/sleep mode
		Unlit	During standbys



Technical Explanation (Device)


Basic Configuration.....	20
Basic Sequence.....	21
Document Exposure / Delivery System.....	22
Controller System.....	26
Laser Exposure System.....	30
Image Formation System.....	31
Fixing System.....	36
Pickup / Feed System.....	39

Basic Configuration

Configuration Function

This device is roughly composed of the 6 functional blocks as shown in the figure below

• Document Exposure/Delivery System	• Image Formation System
• Controller System	• Fixing System
• Laser Exposure System	• Pickup / Feed System



Basic Sequence

Basic Operational Sequence

The CPU on the Engine Controller PCB controls the operational sequence. The table below shows the operation and the purposes in each status from start-up of the device and to last rotation after print job completion.

Status		Operation
WAIT (Wait)	Interval from power-ON or reactivation from sleep mode upon shutting the door(s) to entering the print-ready status	Activate the printer to be ready for printing. During WAIT time, the following operations are done: pressure is applied to the pressure roller of the Fixing Unit; check cartridges and units being in place; move the developing unit to the home position; and, clean the ITB. When needed, color displacement is corrected and the image is stabilized.
STBY (STBY)	Interval from the wait time or the last rotation to issuance of a print command from the main controller or power-OFF.	Maintain the print-ready status. The printer enters the sleep mode upon receiving a "sleep" command from the main controller during the stand-by status. The printer executes color displacement correction or image stabilization upon receiving corresponding commands from the main controller.
INTR (IINTR)	Interval from issuance of a print command from the main controller during the stand-by status to warming up the Fixing Unit to the target temperature.	To make the printer ready for print jobs, activate high-voltage bias PCBs, the Laser Scanner Unit and the Fixing Unit.
PRINT (Print)	Interval from the initial rotation to completion of last page fixation.	Based on the video signals input from the main controller, form the static latent image on the photosensitive drum to transfer and fix the toner image on paper. When a certain pages are printed after power-ON, the device undergoes color displacement correction and/or image stabilization.
LSTR (Last rotation)	Interval from print job completion to Motor deactivation.	The last page of the print job is completely delivered. In this status, the Laser Scanner Unit and high-voltage bias PCBs are inactive. The printer starts the initial rotation upon receiving a print command from the main controller during this status.

■ Print Mode

Printer driver setting	Print Mode	Media Type	Feeding Speed
Plain Paper	Nomal	Plain Paper : 60 to 90g/m ²	1/1 Speed
Light	Light1	Plain Paper L : 60 to 70g/m ²	
Label	Nomal	Label	1/2 Speed
At Paper Wrinkle Correction Mode 2 enabled	Nomal Harf Speed	Heavy Paper 1 : 90 to 106g/m ²	
		Bond Paper : 60 to 90g/m ²	
Heavy 2	Heavy2	Heavy Paper 2 : 106 to 121g/m ²	
		Bond Paper : 90 to 199g/m ²	
Heavy 3		Heavy Paper 3 : 121 to 199g/m ²	

Document Exposure / Delivery System

Document Exposure System

■ Outline

Specifications / Control / Function List


item	Function / Method
Document Exposure	LED
Document Scan	Book mode: scan by the shift of the contact Book mode: scan by the shift of the contact image sensor (CIS)
Scanning Resolution	300 or 600 dpi (horizontal scanner) X 600 dpi (vertical scanner)
Number Of Gradations	256 gradations
Magnification	50% to 200% Horizontal: image processing by Main Controller PCB Vertical: change of carriage shift speed, image processing by Main Controller PCB
Lens	Rod lens array
CMOS Sensor	Number of lines: 1 line Number of pixels: 5184 pixels as total pixels (5107 pixels as effective pixels) Maximum document scanning width: 216 mm
CS HP Detection	Drive control by Reader Motor (M4)
CS HP Detection	Yes
Document Size Detection	None
Dirt Sensor Detection	None

■ Major Components

Followings are the major components for Document Exposure System.

- The Contact Sensor to scan document
- The Reader Motor (M4), the Drive Pulley, the Drive Belt, to shift the Contact Sensor

In image scanning control, the Contact Image Sensor is shifted by rotating the Reader Motor based on the drive signal from the Engine Controller PCB and scan the original on the Copyboard Glass. When ADF is in use, image is scanned by feeding the originals by ADF instead of shifting the Contact Image Sensor.



Document Feeder System


■ Outline

Pickup/Feed/Delivery Operation

The Auto Document Feeder (ADF) mounted onto this host machine is dedicated to stream-reading.


1 Motor (ADF Motor: M5) is engaged in pickup/feeding/delivery.

At the start of copy/fax/scan, the DADF Motor (M5) is driven by the drive command from the Main Controller PCB to pickup/feed the originals set face up on the original tray one by one in order from the top. The original is scanned by the Contact Image Sensor when moving through the Copyboard Glass, and then delivered face down to the original delivery assembly.




Operation at Duplex Reading


- In order to read from the back side, the paper is temporarily reversed.



- The paper is reversed, and the back side is read.



- The paper is reversed once more, and the front side is read.



■ Controls

● Original Detection

There are two types of Original Detection in this Equipment.

1. Original Presence / Absence Detection

Detected by DS (Document Sensor: PS10)

Setting the original onto the original tray pushes up the actuator, activating (light shielded =>light transmitted) the DS (PS10), and resulting in detection of the presence of original.

2. Detection of the End of the Original


Detected by the DES (Document End Sensor: PS9)

The leading edge of the original that is fed pushes up the actuator, activating the DES (PS9) (light shielded =>light transmitted) and resulting in detection of the reach of the leading edge of original. Furthermore, when the trailing edge of the original passes the actuator position, the actuator returns to the original position, inactivating the DES (PS9) (light transmitted => light shielded). The trailing edge of the original is detected by this mechanism.

The original length that can be scanned with this equipment is less than 400 mm. Passing of the original longer than this results in jam stop. The original length is calculated by the time it takes from detection of the leading edge of the original to detection of the trailing edge of the original.

NOTE:

There is no function to detect the original size (original width, length) in this equipment.



● Jam Detection

The following cases are judged as jam.

1. In case of delay in reaching DS/DES or stationary during scanning of original
2. In case DS/DES is detected as ON at power-on (residual paper jam)
3. In case of detecting original of which length is 400 mm or longer

- Operation after Detection of Jam
The host machine stops scanning operation and displays "CHECK DOCUMENT" on the control panel.
In case of the model equipped with fax function (with built-in speaker), the warning beep occurs at the detection of jam.
- How to release Jam.
Remove the jammed paper and open / close the ADF upper cover

Controller System


Outline

The Engine Control System controls all the other systems according to commands from the Main Controller.

The Engine Control System contains the following components:

- DC Controller
- Low-voltage Power Supply
- High-voltage Power Supply

Block diagram of the Engine Control System is shown below.




Controls

■ Outline

The Engine Controller controls the operational sequence of the printer.


Block diagram of the Engine Controller and table of the electrical components are shown below.



■ Motor / Fan Control

This machine has 2 motors in original exposure/feed system, 3 motors for paper feeding and image formation, and 2 fans to control temperature increase inside the printer.

Arrangement of Motor and the specifications are shown below.



Symbol	Description	Function	Failure detection
M1	Fixing Motor	To drive the Fixing and Delivery Rollers	No
M2	Main Motor	To drive the rollers of the printer and the rollers of the Paper Feeder	Yes
M3	Laser Scanner Motor	To drive the Scanner Mirror	Yes
M4	Reader Motor	To drive the Contact Image Sensor (CIS)	Yes
M5	ADF Motor	To drive rollers in the ADF	No
FM1	Main Fan	To cool the Controller Assembly	Yes
FM2	Sub Fan	To cool inside the printer	Yes

■ Failure Detection

No.	Failure Point	Error code	Cause of Failure
M2	Main Motor	E014	In the case that the speed of Motor does not reach the specified speed after the specified time has passed since the startup of the Main Motor.
M3	Laser Scanner Motor	E110	Scanner Motor initial operation failure
M4	Reader Motor	E202	CIS Unit HP error
FM1	Main Fan	E806	The Main Fan was locked for a specified consecutive period of time.
FM2	Sub Fan	E805	The Sub Fan was locked for a specified consecutive period of time.

Low-voltage Power Supply

■ Outline

The Low-voltage power supply converts AC Power from the power receptacle into DC Power to cover the DC loads.

■ Protective Function

The Low-voltage Power Supply has a protective function against overcurrent and overvoltage to prevent failures in the power supply circuit. If there flows an overcurrent or an overvoltage, the system automatically cuts off the output voltage. If the DC Power is not being supplied from the Low-voltage Power Supply, the protective function may be running. In such case, turn off the power switch and unplug the power cord. Do not plug in the power cord or turn the power switch on again until the root cause is found.

In addition, one fuses in the Low-voltage Power Supply protect against overcurrent. If overcurrent flows into the AC line, the fuse blows and cuts off the power distribution.

■ Safety

For user and service technician's safety, the printer has a function to interrupt 24V power supply.

The door switch is turned off and 24V power supply to the Fixing Assembly and the High-voltage Power Supply Unit stops under the following condition:

- If the cartridge door is opened (SW4 is turned off)

As this machine has a Power Switch on the DC line, power is supplied to the AC line even when the Power Switch is turned OFF. Therefore, be sure to disconnect the Power Supply Cord from the inlet when assembling this machine.

■ Low-voltage Power Supply Unit Failure Detection

The Engine Controller determines a Low-voltage power supply unit failure and stops +24V output. Once 24V output is stopped, 3.3V of the engine CPU stops, so notification is not made. Likely, 3.3V of the controller stops, so the machine seems power-off.

- +24V is higher than a specified voltage
- +3.3V is higher than a specified voltage
- +5V is higher than a specified voltage


■ Power-Saving Mode

This is the function to save power consumed by the printer.

The table below lists various power-saving modes.

Power-Saving Mode		Status
Stand-by		at power-OFF on the reader
Power-saving		at power-OFF on the reader The control panel enters the power-saving mode.
Sleep	Sleep1 A / 1B	at power-OFF on the reader and the engine The control panel enters the power-saving mode.
	Sleep2	at power-OFF on the reader and the engine
	Sleep3	at power-OFF on the reader and the engine The control panel and main controller enters the power-saving mode.

* The reader is turned ON only when it is used.




Laser Exposure System

Outline

The Laser Exposure System forms a latent image on the photosensitive drum according to the VIDEO signals sent from the Main Controller.

The main components of the Laser Scanner are the Laser Unit and the Scanner Motor Unit, which are controlled by the signals sent from the Engine Controller.

Diagram of the Laser Scanner Unit is shown below.



Optical Unit Failure Detection

The Optical Unit failure detection manages the Laser Scanner failure detection functions.

The Engine Controller determines an Optical Unit failure and notifies the Main Controller if the Laser Scanner encounters the following conditions:

- After the drive of Scanner Motor, BD within a specified period is not detected.
- If the Scanner Motor does not reach a specified rotation within a specified period of start-up.
- If an out of specified BD interval is detected during a print operation.

Image Formation System

Outline

The Image-Formation System forms a toner image on print media.

The following are the main components of the Image-Formation system:

- Cartridge
- Transfer Roller
- Fixing Unit
- Laser Scanner

The Engine Controller controls the Laser Scanner and High-voltage power supply to form the toner image on the photosensitive drum. The image is transferred to the print media and fixed.

Diagram of the image formation system is shown below.




Image Formation Process

Outline

The Image-Formation process consists of the following seven steps divided among five functional blocks:

Latent Image Formation Block

Step 1: Primary charging

Step 2: Laser-beam exposure

Developing Block

Step 3: Developing

Transfer Block

Step 4: Transfer


Step 5: Separation

Fixing Block

Step 6: Fixing

Drum Cleaning Block

Step 7: Drum cleaning




■ Latent Image Formation Block

During the two steps that comprise this block, an invisible latent image is formed on the photosensitive drum.


Step 1: Primary Charging

To prepare for latent image formation, the surface of the photosensitive drum is charged with a uniform negative potential. The primary charging bias is applied to the primary charging roller and the roller charges the drum directly.



Step 2: Laser-beam Exposure

The laser beam scans the photosensitive drum to neutralize the negative charge on portions of the drum surface. An electrostatic latent image forms where the negative charge was neutralized.




■ Developing Block

Toner adheres to the electrostatic latent image on the photosensitive drum, which becomes visible.

Step 3: Developing

Toner acquires a negative charge from the friction that occurs when the developing roller rotates against the developing blade. The negatively charged toner is attracted to the latent image on the photosensitive drum surface because the drum surface has a higher potential. The developing bias is applied to the developing roller.




■ Transfer Block

During the two steps that comprise this block, a toner image on the photosensitive drum is transferred to the print media.


Step 4: Transfer

The transfer bias is applied to the transfer roller to charge the print media positive. The positively charged media attracts the negatively charged toner from the photosensitive drum surface.



Step 5: Separation

The elasticity of the print media and the curvature of the photosensitive drum cause the media to separate from the drum surface. The static charge eliminator reduces back side static discharge of the media for stable media feed and image quality.




■ Fixing Block

The toner image is fixed onto the print media.

Step 6: Fixing

The printer uses an on-demand Fixing method.

The toner image is permanently affixed to the print media by heat and pressure. The Fixing bias is applied to the Fixing Film to improve image quality.




■ Drum Cleaning Block

The residual toner is cleared from the photosensitive drum surface.

Step 7: Drum Cleaning

The cleaning blade scrapes the residual toner off the surface of the photosensitive drum. The residual toner is deposited in the toner collection box.



● High-voltage Power Supply


■ Outline

The High-voltage Power Supply applies biases to the following components:

- Primary Charging Roller
- Developing Roller
- Transfer Roller
- Fixing Film

The DC controller controls the high-voltage power supply to generate biases.

The Figure below shows the configuration of the High-voltage Power Supply.




Fixing System

Outline

The Fixing control circuit controls the temperature in the Fixing Assembly.

The printer uses an on-demand Fixing method.

The figure below shows the configuration of the Fixing control circuit.



- Fixing heater (H1) : Heats the fixing film
- Thermistor (TH1,TH2) : Detects fixing temperature (Contact type)
- Thermoswitch (TP1) : Prevents an abnormal temperature rise of the fixing heater (Contact type)


These temperature controls in the fixing unit are performed by the fixing heater control circuit and the fixing heater safety circuit according to the commands from the DC controller.

Controls

■ Fixing Temperature Control

The Fixing temperature control maintains the temperature of the Fixing Heater at its targeted temperature.

Block diagram of this control is shown below.



The DC Controller monitors the FIXING TEMPERATURE (FSRTH1,FSRTH2) signal and sends the FIXING HEATER CONTROL (FSRD) signal according to the detected temperature. The Fixing Heater control circuit controls the Fixing Heater depending on the signal so that the heater remains at the targeted temperature.

■ Protective Function

The protective function detects an abnormal temperature rise in the Fixing Assembly and interrupts power supply to the Fixing Heater.

The following three protective components prevent an abnormal temperature rise of the Fixing Heater:

- DC Controller
- Fixing Heater safety circuit
- Thermoswitch

1. DC Controller

The DC Controller monitors the detected temperature of the thermistor. The DC Controller makes the FIXING HEATER CONTROL signal inactive and releases the relay to interrupt power supply to the Fixing Heater under the following condition:

2. Fixing Heater safety circuit

The Fixing Heater safety circuit monitors the detected temperature of the thermistor.

The Fixing Heater safety circuit releases the relay control circuit to interrupt power supply to the Fixing Heater under the following condition:

3. Thermoswitch

The contact of the thermoswitch is broken to interrupt power supply to the Fixing Heater under the following condition:

■ Failure Detection

The DC Controller determines a Fixing Assembly failure, makes the FIXING HEATER CONTROL signal inactive, releases the relay to interrupt power supply to the Fixing Heater and notifies the formatter of a failure state when it encounters the following conditions:

1. Start-up failure (E000)


- If the main thermistor does not detect a specified temperature during the start-up process of the heater in the wait period.
- If the main thermistor does not detect a specified temperature during the heater temperature control in the initial rotation period.

2. Abnormal high temperature (E001)
 - If the main thermistor detects an abnormal high temperature of the fixing unit.
 - If the sub thermistor detects an abnormal high temperature of the fixing unit.
3. Abnormal low temperature (E003)
 - If the main thermistor detects an abnormal low temperature of the fixing unit during the printing operation.
 - If the sub thermistor detects an abnormal low temperature of the fixing unit during the printing operation.
4. Drive circuit failure (E004)
 - If a specified frequency of the ZERO CROSSING signal is not detected within a specified period after the printer is turned on.

Pickup / Feed System


Outline

The Media Feed System picks up, feeds and delivers the print media. It consists of several types of rollers. The Duplex Feed Unit in the Duplex model reverses and Refeeds the print media to print on both sides of media. The media path is shown below.



Drive Configuration

Diagram and table of the electrical components are shown below.



Electrical component	Symbol	Signal
Main Motor	M2	Main Motor Control Signal
Fixing Motor	M1	Fixing Motor Control Signal
Multi-purpose Tray Pickup Solenoid	SL1	Multi-purpose Tray Pickup Solenoid Control Signal
Cassette Pickup Solenoid	SL2	Cassette Pickup Solenoid Control Signal
Fixing Delivery Sennsor	PS2	Fixing Delivery Signal (120V)
Fixing Delivery Sennsor	PS3	Fixing Delivery Signal (230V)
Rear Cover Sensor	PS4	Rear Cover Open Detection Signal


Electrical component	Symbol	Signal
Cassette Paper Sensor	PS5	Cassette Paper Signal
Face-up Sensor	PS6	Face-up Signal
Face-Down Tray Paper Full Sensor	PS7	Face-Down Tray Paper Full Sensor Signal
Multi-purpose Tray Media Presence Sensor	PS205	Multi-purpose Tray Media Presence Signal
TOP Sensor	PS215	TOP Signal
Media Width Sensor	PS225	Media Width Signal
Duplex Feede Sensor	PS502	Duplex Feede Signal
Cassette Presence Switch	SW235	Cassette Presence Signal
Cartridge Door Switch	SW4	Cartridge Door Open Detection Signal

Jam Detection

■ Outline

The printer uses the following sensors to detect the presence of media and to check whether media is being fed correctly or has jammed:

- Face-down Tray Media Full Sensor (PS7)
- Fixing Delivery Sensor (PS2,PS3)
- Media Width Sensor (PS225)
- TOP Sensor (PS215)
- Duplex Feede Sensor (PS502)
- PF Feed Sensor (PS8008)



■ Pickup delay jam

In case of picking up paper from the Multi-purpose Tray or Cassette or feeding the 2nd side of paper at duplex print, when the leading edge of paper is not detected within the specified period of time by the TOP Sensor(PS215), it is judged as a pickup delay jam.

■ Pickup stationary jam

When the trailing edge of paper is not detected by the TOP Sensor (PS215) even if the specified period of time is elapsed after the leading edge of paper is detected by the TOP Sensor (PS215), it is judged as a pickup stationary jam.

■ Delivery delay jam

When the leading edge of paper is not detected within the specified period of time by the Fixing Delivery Sensor(PS2,3) after the leading edge of paper is detected by the TOP Sensor(PS215), it is judged as a delivery delay jam

■ Delivery stationary jam

When the trailing edge of paper is not detected within the specified period of time by the Fixing Delivery Sensor(PS2,3) after the trailing edge of paper is detected by the TOP Sensor(PS215), it is judged as a delivery stationary jam.

■ Fixing paper wrapping jam

When absence of paper is detected by the Fixing Delivery Sensor(PS2,3) while the area between 20mm from the leading edge and 20mm from the trailing edge passes the Fixing Delivery Sensor(PS2,3), it is judged as a fixing paper wrapping jam.

■ Fixing delivery delay jam

When ON of the Face-down Tray Full Sensor (PS7) is never detected within the specified period of time after the leading edge of paper is detected by the Fixing Delivery Sensor (PS2,3) at face-down delivery, it is judged as a delivery delay jam.

■ Duplex re-pickup jam

When the leading edge of paper is not detected within the specified period of time by the Duplex Sensor (PS502) after the paper starts to be reversed, it is judged as a duplex re-pickup jam.

■ Internal stationary jam 1

When either TOP Sensor(PS215), Fixing Delivery Sensor(PS2,3), Paper Width Sensor(PS225), Duplex Feed Sensor(PS502) or PF Media Feed Sensor (PS8008) detects presence of paper at the time of warm-up rotation, it is judged as a internal stationary jam 1.

■ Internal stationary jam 2

When either of the sensors (TOP Sensor (PS215), Paper Width Sensor (PS225), Fixing Delivery Sensor (PS2,3), Duplex Sensor (PS502) or PF Paper Feed Sensor (PS8008)) on the paper delivery path detects presence of paper at the completion of printing, it is judged as a internal stationary jam 2.

■ Door Open Jam

When a door-open is detected while feeding papers, it is judged as a door open jam.



Technical Explanation (System)

Technical Explanation (System).....43

Technical Explanation (System)

Overview of System Management

This chapter describes information for service technicians on the system of this machine.

Although this chapter contains some information described in the User's Guide, for details on the functions for users, refer to the e-Manual.

Version Upgrade

Function Overview

The following firmware upgrade methods are available with this device.

Version upgrade using User Support Tool (UST)

Upgrade the firmware of the device using UST.

Open the file for UST version upgrade on a PC connected with the device and upgrade the firmware.

Since the work is performed by connecting the host machine and the PC using a USB Cable, version upgrade can be performed also in an environment where network is not available.

Version upgrade via Internet

Access the dedicated server, and download and update the firmware.

Provided that Internet connection is available, the system automatically configures the connection destination setting and executes processing such as download and version upgrade.

Version upgrade by replacing the PCB

Version upgrade by replacing the existing PCB with a PCB where the latest firmware is installed

Version upgrade using Local CDS

Use iW EMC/iW MC and DFU plug-in to download firmware from Local CDS and upgrade the host machine.

NOTE:

When using Local CDS to upgrade it, refer to the manual/material of iW EMC/iW MC DFU plug-in.

CAUTION:

A message appears when an attempt is made to upgrade a host machine to which specified firmware has been applied.

This is a precaution not to use wrong firmware to upgrade a host machine to which specified firmware has been applied.


See the following regarding the combination of whether the message will be displayed:

Function Overview

Type of firmware applied to the host machine	Firmware to upgrade	
	General firmware	Specified firmware
General firmware	No message	No message
Specified firmware	Message displayed	Message displayed

Version Upgrade Using UST

This section describes the procedure of [Version Upgrade Using UST] by directly connecting the host machine and the PC using a USB Cable and upgrading the firmware.



• Required System Environment

PC (All the following conditions must be met.)

One of the following OS should be running.

- Microsoft Windows Server 2003
- Microsoft Windows Vista
- Microsoft Windows Server 2008
- Microsoft Windows 7
- Microsoft Windows Server 2012
- Microsoft Windows 8

All the following hardware requirements must be met.

- Memory (RAM): 128 MB or more
- Hard disk: Free space of 100 MB or more
- Display: resolution of 640 x 480 pixels or more, 256 colors or more
- A USB port must be installed.


Others

UST file of the device**1


USB Cable (USB 1.1/2.0)

• Procedure for Upgrading the Firmware Using UST

1. Start a PC and connect it with the host machine using a USB Cable.
2. Turn ON the power of the machine and let it enter standby mode.
3. Select the key/menu shown below to enter download mode.
 - Select the home key or [Menu] key > [System Management Settings] > [Update Firmware] > [Via PC] > select [Yes].




4. Open the UST file (file for version upgrade) on the connected PC side.





*1. Available on system CD distributed by the sales company or by download from the release service website.

5. Write down the version of the firmware to be updated, and then click "Next".



6. Check the displayed contents, and then click [Next].




7. Select [USB connected device], and click [Next].

The screenshot shows the 'Canon User Support Tool' dialog box. It has a title bar and a main area with the following text: 'Select device', 'Select a printer name from the following list, or enter the IP address to select the device to update.', and two radio buttons: 'Specify by printer name' (which is selected) and 'Specify by IP address'. Below the 'Specify by printer name' radio button is a table with two columns: 'Printer name' and 'Port name'. The first row of the table is highlighted in blue and contains the text '(USB connected device)' and 'USB002'. Below the table is an empty text input field. At the bottom of the dialog box are three buttons: '< Back', 'Next >', and 'Cancel'. The 'Next >' button is highlighted with an orange border.

Printer name	Port name
(USB connected device)	USB002


NOTE:

If you connect the host machine and the PC using a LAN Cable for this work, select [Specify by IP address], and enter the IP address of the device.

8. Check the displayed contents, and then click [Start].

The screenshot shows the 'Canon User Support Tool' dialog box. It has a title bar and a main area with the following text: 'Confirm update details', 'This software program will update the firmware of the selected device with the following details. Check the details.', and two lines of text: 'Target device: MF410/MF510/D1500' and 'Port name: USB002'. Below this text is the instruction 'Click [Start] to update.'. At the bottom of the dialog box are three buttons: '< Back', 'Start', and 'Cancel'. The 'Start' button is highlighted with an orange border.


9. A warning screen will appear. Click "Yes".



Download will start.



10. When the download is completed, click "OK" and restart the host machine.




CAUTION:

When the Control Panel still shows the download screen even after the host machine is restarted, the internal firmware update has not been completed. Leave it as is for 10 minutes or more and press the Stop button.

11. Select the following menu, and check that the firmware has been correctly upgraded:

- [System Management Settings] > [Update Firmware] > [Version Information]



■ Version Upgrade via Internet

Connect to the Internet using the network function of the device, and download and upgrade the latest firmware from the server. If the device is in an environment where Internet connection is available, firmware versions can be upgraded only by operation from the menu without using PC.

● Prerequisite


In order to perform version upgrade of the device via Internet, the following conditions must be met.

There should be no other jobs being executed.

Firmware cannot be upgraded while there is a job being executed. If there is a job being executed, wait for completion of the job and then perform the work.

The device should be able to be connected to the external network.

If connection is not available because, for example, there is a proxy server, follow the e-Manual to configure the proxy server settings and enable connection to the external network.




The serial number of the host machine should be shown on the Main Controller PCB.

Whether or not the serial number of the host machine is shown on the Main Controller PCB can be checked from the Control Panel or SPEC REPORT.


Procedure to check from the Control Panel

1. Press the counter key, and select [Check Device Configuration].




Procedure to check from SPEC REPORT

1. Execute the following service mode to print SPEC REPORT.
 - COPIER > FUNCTION > MISC-P> SPEC
2. Check if the serial number (3 alphabetical characters + 5-digit number) is shown in [BODY No.] of the printed SPEC REPORT.



• Procedure for Upgrading the Firmware via Internet


1. Select the following menu to upgrade the firmware via Internet:
 - [System Management Settings] > [Update Firmware] > [Via Internet] > [Yes]



When the upgrading of firmware is completed, the machine automatically restarts.

2. Select the following menu, and check that the firmware has been correctly upgraded:

- [System Management Settings] > [Update Firmware] > [Version Information]



CAUTION:

This function does not support the operations from remote UI. ([System Management Settings] menu of remote UI does not have the item of [Update Firmware].)

• Messages

The message displayed on the device operation panel is as follows.

No.	Error message	The timing of occurrence	Remedy
1	Job in progress... Wait a moment, then try again.	If there is a job being executed:	1. Wait until the job is completed. 2. Cancel the job.
2	Cannot check the firmware version. (Server communication error.)	Network error	1. Check whether the device can be connected to the external network. 2. Check whether the proxy setting has been made (in case of access via a proxy server).
3	Cannot download the firmware. (Error during download.)		1. Check whether the device can be connected to the external network. 2. Check whether the proxy setting has been made (in case of access via a proxy server). 3. Check that the serial number of the host machine is shown on the Main Controller PCB.
4	***DOWNLOAD MODE*** NETWORK AVAILABLE IP ADDRESS IP address of the machine PRESS STOP KEY TO EXIT	If update (writing) of the firmware has ended in failure:	1. Update the firmware again using UST.
5	***DOWNLOAD MODE*** FAILED TO UPDATE		
6	***DOWNLOAD MODE*** UPDATE IS COMPLETE	If the update of the firmware is successful	-

● Setting Information Export/Import Function (DCM)

■ Overview

Various data is stored in the storage inside the device.

Depending on the works to be done such as replacing parts, this data needs to be backed up and restored.

There are some ways to back up and restore data, and the appropriate one should be used depending on the purpose and storage destination.

This section describes the procedure for backing up and restoring service mode setting values.

For the procedure for backing up and restoring other information, refer to the backup data list in the Appendix.

● Function Overview

This machine has a setting information export/import function (hereinafter referred to as DCM (Device Configuration Management) function) which exports/imports the machine's setting value information as a file. The file exported/imported using the DCM function is called a DCM file, and the target setting information is as follows:

- Setting information of [Settings/ Registration]
- Setting information of service mode
- Address Book


The DCM file is exported to a USB flash drive or PC local disk from the Control Panel or remote UI.

The exported DCM file can be returned to the original device or imported to a different device.

When the file is returned to the original device, this can be used as a setting backup function, and when the file is imported to a different device, this can be used as a setting information migration function.

Data can also be imported to or exported from an iR-ADV machine by using iW EMC/MC DCM Plug-in.

In the case of the setting value backup function before DCM, an exported file could be imported to the same device, but the DCM function enables import of an exported file to a different device.



Image

NOTE:

In order to export or import setting information using DCM, it is necessary that the device supports DCM.

● Backup/Restoration for Service Technicians

Backup and Restoration from the [Settings/Registration] Menu

Setting information can be backed up and restored from the Control Panel of the device or from the [Settings/Registration] menu of remote UI.

Although the [Settings/Registration] menu is for users, the service mode settings information can be backed up and restored from the Import/Export function by changing the service mode setting.

In order to back up and restore the service mode setting information from the [Settings/Registration] menu, it is necessary to access from remote UI.

Backup/Restoration Using Service Mode

Some of the functions in service mode can be used to backup and restore data.

DC-CON/R-CON setting value information and service counter (DC-CON) values can be backed up and restored.

● Combination of Information Exported/Imported by DCM, Means, and Storage Locations

A DCM file is exported and imported using the Control Panel, remote UI, or the iW EMC server, depending on the situation of the site.

The information exported/imported differs depending on the means.

Combinations of them are shown in the following table.

Menu used	Operation	Information exported			Save destination
		Setting values of menu options	Address book**1	Service mode setting values	
[Settings/Registration] menu	Control panel	Yes (fixed)*2	Yes (fixed)*2	No	USB flash drive
	Remote UI	Yes	Yes	With conditions*3	USB flash drive
Service mode	Control panel	No	No	Yes	USB flash drive / Storage in the host machine
	Remote UI	No	No	Yes	PC local disk

• Compatibility of Data

The following table shows compatibility of data in the case where the device from which the data is exported and the device to which the data is imported differ in model and/or serial number.

For items that are imported in Cases A, B, and C, refer to “List of Items Which Can Be Imported” on page 58.


Model	Serial number	Import process
Same	Same	Items corresponding to Case A are imported.*4
Same	Different*5	Items corresponding to Case B are imported.*4
Different	Different*5	Items corresponding to Case C are imported.*6
Different	Same	The file is judged to be invalid, and the process ends with an error.

• Replacement Mode

When this function is used for migrating the setting data upon replacement of a device, some of the data cannot be migrated depending on the model to which the data is migrated.

When this function is used in normal mode, data that is applicable to either Case A (of different serial number) or Case B (of different mode) cannot be imported.

When replacement mode is enabled, data can be forcibly migrated even to a device of a different serial number or even between different models.



The following shows the procedure to turn ON/OFF replacement mode:

1. Set the following service mode setting value to "1":

- COPIER > OPTION > USER > RPL-IMP

*1. Models without address books are excluded. In the case of a fax option model without SEND function, address books are exported only if a fax option is connected with the device.

*2. When the [Settings/ Registration] menu is used from the Control Panel, both the setting menu information and the address book are imported/exported. It is not possible to export/import only either of them. Information which is not included in the data to be imported is not imported.

*3. Service mode is added to the data to be exported only when service mode level 1 > COPIER > OPTION > USER > SMD-EXPT is set.

For information on items that are imported, refer to “List of Items Which Can Be Imported” on page 58.

*4. If the firmware version at the time of import differs from that at the time of export, predetermined corrective processing may be performed.

*5. If a serial number is missing, the serial numbers are judged to be mismatched.

*6. Predetermined corrective processing may be performed.

NOTE:

Refer to "List of Items Which Can Be Imported" on page 58 for the target data of replacement mode.

CAUTION:

Since replacement mode does not automatically return to OFF, be sure to change the above service mode setting value back to "0".

■ Import/Export Procedure from [Settings/Registration] of Remote UI

This section describes the procedure for backing up and restoring service mode setting information by using the [Import/Export] function in the [Settings/Registration] menu of Remote UI.

CAUTION:

- The service mode setting information can be backed up and restored only from the [Settings/Registration] menu on Remote UI, and the operation cannot be performed from the [Settings/Registration] menu on the Control Panel.
- In the case of backing up and restoring only the setting information of the [Settings/Registration] menu or the address book, refer to the procedure described in the e-Manual.

● Limitations

The following limitations exist when backing up and restoring the service mode settings information from the [Settings/Registrations] menu of remote UI.

A job must not be accepted during an import/export processing.

Except for the calibration requested by the engine, a job is not allowed to be accepted during a processing. In addition, import/export must not be performed during execution of a job.

Firmware must not be updated during an import/export processing.

Fax cannot be received while firmware is updated during a processing. In addition, import/export must not be performed also during firmware update.

Power must not be turned off during an import/export processing.

If power discontinuity occurs during an import processing, a rollback processing is not performed, therefore the settings imported up to that point are reflected while the rest of the settings remain as-is.

When power discontinuity occurs during an export processing, export is not executed.

● Procedure for Export Using Remote UI ([System Management Settings] Menu)

Service mode setting information can be exported from the [System Management Settings] menu by setting the following service mode setting value to "1".

1. Enter service mode, and set the following item to "1".

- COPIER > OPRION > USER > SMD-EXPT

TNRB-SW	: 0
SCALL-SW	: 0
SCALLCMP	: 0
PS-MODE	: 0
SMD-EXPT	: 1
ALL-SLP	: 1
RPL-IMP	: 0


SERVICE MODE	
COPIER	COPIER > OPTION > USER
FEEDER	USER
FAX	COUNTER1 113
TESTMODE	COUNTER2 501
SERVICE REPORT	COUNTER3 301
	COUNTER4 0
	COUNTER5 0
	COUNTER6 0
	CNT-SW 0
	SMD-EXPT 1
	ACC-SLP 1
	DRMRP-SW 0

NOTE:


The [SMD-EXPT] setting can be specified either from the Control Panel or from the remote UI.

2. Exit service mode, start remote UI, log in as a system administrator, and then select the following item:

- [Settings/Registration] > [Import/Export] > [Export]



3. After confirming that [Service Mode] is displayed/selected in [Select Item to Export], enter the password and click [Start Exporting].



Address Book

Select the check box to export the Address Book data.

Settings/ Registration

Select the check box to export the setting data of the menu options.

Encryption Password

Enter 32 or less numeric characters set when the file was exported.

4. The File Download dialog box will appear. Save the file to any location.

5. Enter service mode, and set the following item to "0".

- COPIER > OPRION > USER > SMD-EXPT

⚠ CAUTION:


Since the screen of export function can also be accessed by the user, be sure to disable the [SMD-EXPT] setting (setting value: 0).

• Procedure for Import Using Remote UI ([System Management Settings] Menu)

Import the service mode setting information file that was exported in the previous procedure.

1. Enter service mode, and set the following item to "1".

- COPIER > OPRION > USER > SMD-EXPT




NOTE:

The [SMD-EXPT] setting can be specified either from the Control Panel or from the remote UI.


2. Exit service mode, start remote UI, log in as a system administrator, and then select the following item:

- [Settings/Registration] > [Import/Export] > [Import]



3. Configure the import setting, and click [Start Importing].

Entering the encryption password and clicking [Start Importing] imports the menu option data.



[Browse..]button

Click to select the file to import.

Decryption Password

Enter up to 32 alphanumeric characters for the password that was set when the file was exported.


Address Book

Select the check box to import the Address Book data.


Settings/Registration

Select the check box to import the setting data of the menu options.

4. A dialog box asking whether the user wants to execute import will appear. Click [OK].



5. A message will appear to indicate that the process has been completed. Click the [OK] button.



6. Restart the host machine, enter service mode, and then check that the setting information is reflected. This completes the procedure for importing a setting information file.
7. Enter service mode, and set the following item to "0".
- COPIER > OPRION > USER > SMD-EXPT

⚠ CAUTION:

The [SMD-EXPT] setting can be specified either from the Control Panel or from the remote UI.

■ Procedure for Exporting/Importing Service Mode Setting Information

Service mode setting information can be backed up and restored by using service mode functions. The backup file can be saved to a USB flash drive or a storage in the machine.

Backup/restoration to a USB flash drive

```
COPIER > FUNCTION >SYSTEM > EXPORT
COPIER > FUNCTION >SYSTEM > IMPORT
```

Backup/restoration to a storage in the machine

```
COPIER > FUNCTION >SYSTEM > SAVE-SM
COPIER > FUNCTION >SYSTEM > RSTR-SM
```

	Backup/restoration to a USB flash drive	Backup/restoration to a storage in the machine
Storage destination	USB flash drive	Storage in the machine
Number of files saved	Depends on the capacity of the USB flash drive	One
Duplication of the setting values for other machines	Possible	Not possible

● Procedure for Exporting to a USB Flash Drive

Use the service mode function to save the service mode setting information to a USB flash drive.


With this model, service mode can be used from the Remote UI.

The following USB flash drives can be used for export/import.

- USB flash drive in FAT 16 format (storage capacity: 2 GB)
- USB flash drive in FAT 32 format (storage capacity: 32 GB)


Note that the descriptions in parenthesis in the procedure are the descriptions in the case of remote UI.

1. Connect a USB memory device to the USB memory port.



2. Enter service mode, and execute the following service mode.


- COPIER > FUNCTION > SYSTEM > EXPORT



CAUTION:

When it is executed without connecting USB flash drive, the error message is not displayed. Processing doesn't export anywhere of any though it seems to have completed it correctly. Confirm USB memory device has been connected before it executes it from the above-mentioned reason without fail.

3. The message shown below which is displayed during the process will disappear. When the display has returned to the original state, remove the USB flash drive.




4. Check that a setting information file (service.dcm) exists in the directory directly under the root of the USB flash drive.

This completes the procedure for exporting a setting information file.

● Procedure for Import from USB Flash Drive


1. To the directory directly under the root of the USB flash drive, save a setting information file (service.dcm) to be imported.

2. Connect a USB memory device to the USB memory port.




3. Enter service mode, and execute the following service mode.

- COPIER > FUNCTION > SYSTEM > IMPORT



4. The message shown below which is displayed during the process will disappear. When the display has returned to the original state, remove the USB flash drive.



5. Start the host machine, enter service mode, and then check that the setting information is reflected.


This completes the procedure for importing a setting information file.

• Backup Procedure to the Storage in the Machine


Use the service mode function to back up the service mode setting information to the storage in the machine. This operation can be performed both from the Control Panel and remote UI. The setting information that can be saved in the machine's storage is only one.

1. Enter service mode, and execute the following service mode:

Access service mode, select COPIER > FUNCTION > SYSTEM > SAVE-SM, and click [OK (EXEC)].



2. The following screen is displayed during the processing:




3. Finish the operation after checking that the screen returns to the previous display.

● Procedure for Restoration from Internal Storage


Restore the service mode setting information that has been backed up to the storage in the machine in the previous procedure.

1. Enter service mode, and execute the following service mode.

- COPIER > FUNCTION > SYSTEM > RSTR-SM



2. The following screen is displayed during the processing:



3. The operation is complete after checking that the screen returns to the previous display.

■ List of Items Which Can Be Imported

The following shows the items to be imported for this model.

Note that the setting values are not imported in cases such as below:

- Items which are originally not included in a DCM file (e.g.: "Settings/Registration Basic Information" of a DCM file exported using service mode)
- Not included in the import coverage (Cases A to C)
- There are no options and functions related to setting values

The import coverage shown in the table below is as shown below. Those that are not described here cannot be imported.

Import coverage	Description
Case A: The same machine	Import to the same machine (for backup and restoration, etc.)
Case B: The same model	Import to a different machine of the same model (the same series)
Case C: Different model	Import to a different machine of a different model (a different series)

● Service Mode

Initial screen	Large	Middle	Small	Case A	Case B	Case C
COPIER	ADJUST	FEED-ADJ	ADJ-C1	Yes	-	-
COPIER	ADJUST	FEED-ADJ	ADJ-C2	Yes	-	-
COPIER	ADJUST	FEED-ADJ	ADJ-MF	Yes	-	-
COPIER	ADJUST	FEED-ADJ	ADJ-REFE	Yes	-	-

Initial screen	Large	Middle	Small	Case A	Case B	Case C
COPIER	FUNCTION	SPLMAN	SPL14159	Yes	Yes	Yes
COPIER	FUNCTION	SPLMAN	SPL65677	Yes	-	-
COPIER	FUNCTION	SPLMAN	SPL68676	Yes	-	-
COPIER	FUNCTION	SPLMAN	SPL68677	Yes	-	-
COPIER	FUNCTION	SPLMAN	SPL25607	Yes	-	-
COPIER	FUNCTION	SPLMAN	SPL93822	Yes	Yes	Yes
COPIER	FUNCTION	SPLMAN	SPL78788	Yes	Yes	Yes
COPIER	FUNCTION	SPLMAN	SPL71100	Yes	-	-
COPIER	FUNCTION	SPLMAN	SPL00171	Yes	Yes	Yes
COPIER	FUNCTION	SPLMAN	SPL80100	Yes	Yes	Yes
COPIER	FUNCTION	SPLMAN	SPL84194	Yes	Yes	Yes
COPIER	FUNCTION	INSTALL	ERDS	Yes	Yes	Yes
COPIER	FUNCTION	INSTALL	RGW-PORT	Yes	Yes	Yes
COPIER	OPTION	BODY	MIBCOUNT	Yes	Yes	Yes
COPIER	OPTION	BODY	NS-CMD5	Yes	-	-
COPIER	OPTION	BODY	NS-PLN	Yes	-	-
COPIER	OPTION	BODY	NS-LGN	Yes	-	-
COPIER	OPTION	BODY	SLPMODE	Yes	Yes	Yes
COPIER	OPTION	BODY	SDTM-DSP	Yes	Yes	Yes
COPIER	OPTION	FNC-SW	LCDSFLG	Yes	Yes	Yes
COPIER	OPTION	FNC-SW	CRG-PROC	Yes	Yes	-
COPIER	OPTION	FNC-SW	CRGLF-K	Yes	Yes	-
COPIER	OPTION	DSPLY-SW	CRGLW-LV	Yes	Yes	Yes
COPIER	OPTION	IMG-MCON	REGM-SEL	Yes	-	-
COPIER	OPTION	USER	COUNTER1	Yes	-	-
COPIER	OPTION	USER	COUNTER2	Yes	-	-
COPIER	OPTION	USER	COUNTER3	Yes	-	-
COPIER	OPTION	USER	COUNTER4	Yes	-	-
COPIER	OPTION	USER	COUNTER5	Yes	-	-
COPIER	OPTION	USER	COUNTER6	Yes	-	-
COPIER	OPTION	USER	CNT-SW	Yes	-	-
COPIER	OPTION	USER	CONTROL	Yes	-	-
COPIER	OPTION	USER	CTCHKDSP	Yes	-	-
COPIER	OPTION	USER	TNRB-SW	Yes	-	-
COPIER	OPTION	USER	SCALL-SW	Yes	Yes	Yes
COPIER	OPTION	USER	SMD-EXPT	Yes	-	-
COPIER	OPTION	USER	ACC-SLP	Yes	Yes	Yes
COPIER	OPTION	ACC	CARD-SW	Yes	-	-
COPIER	OPTION	ACC	CC-SPSW	Yes	-	-
FAX	SSSW	SW01 *1	-	Yes	-	-
FAX	SSSW	SW02 *1	-	Yes	-	-
FAX	SSSW	SW03 *1	-	Yes	-	-
FAX	SSSW	SW04 *1	-	Yes	-	-
FAX	SSSW	SW05 *1	-	Yes	-	-
FAX	SSSW	SW06 *1	-	Yes	-	-
FAX	SSSW	SW07 *1	-	Yes	-	-
FAX	SSSW	SW08 *1	-	Yes	-	-
FAX	SSSW	SW09 *1	-	Yes	-	-
FAX	SSSW	SW10 *1	-	Yes	-	-
FAX	SSSW	SW11 *1	-	Yes	-	-
FAX	SSSW	SW12 *1	-	Yes	-	-

*1. FAX model only

Initial screen	Large	Middle	Small	Case A	Case B	Case C
FAX	SSSW	SW13 *1	-	Yes	-	-
FAX	SSSW	SW14 *1	-	Yes	-	-
FAX	SSSW	SW15 *1	-	Yes	-	-
FAX	SSSW	SW16 *1	-	Yes	-	-
FAX	SSSW	SW17 *1	-	Yes	-	-
FAX	SSSW	SW18 *1	-	Yes	-	-
FAX	SSSW	SW19 *1	-	Yes	-	-
FAX	SSSW	SW20 *1	-	Yes	-	-
FAX	SSSW	SW21 *1	-	Yes	-	-
FAX	SSSW	SW22 *1	-	Yes	-	-
FAX	SSSW	SW23 *1	-	Yes	-	-
FAX	SSSW	SW24 *1	-	Yes	-	-
FAX	SSSW	SW25 *1	-	Yes	-	-
FAX	SSSW	SW26 *1	-	Yes	-	-
FAX	SSSW	SW27 *1	-	Yes	-	-
FAX	SSSW	SW28 *1	-	Yes	-	-
FAX	SSSW	SW29 *1	-	Yes	-	-
FAX	SSSW	SW30 *1	-	Yes	-	-
FAX	SSSW	SW31 *1	-	Yes	-	-
FAX	SSSW	SW32 *1	-	Yes	-	-
FAX	MENU	005 *1	-	Yes	-	-
FAX	MENU	006 *1	-	Yes	-	-
FAX	MENU	007 *1	-	Yes	-	-
FAX	MENU	008 *1	-	Yes	-	-
FAX	MENU	009 *1	-	Yes	-	-
FAX	MENU	010 *1	-	Yes	-	-
FAX	NUM	002 *1	-	Yes	-	-
FAX	NUM	003 *1	-	Yes	-	-
FAX	NUM	004 *1	-	Yes	-	-
FAX	NUM	005 *1	-	Yes	-	-
FAX	NUM	006 *1	-	Yes	-	-
FAX	NUM	008 *1	-	Yes	-	-
FAX	NUM	010 *1	-	Yes	-	-
FAX	NUM	011 *1	-	Yes	-	-
FAX	NUM	012 *1	-	Yes	-	-
FAX	NUM	013 *1	-	Yes	-	-
FAX	NUM	015 *1	-	Yes	-	-
FAX	NUM	016 *1	-	Yes	-	-
FAX	NUM	017 *1	-	Yes	-	-
FAX	NUM	018 *1	-	Yes	-	-
FAX	NUM	019 *1	-	Yes	-	-
FAX	NUM	020 *1	-	Yes	-	-
FAX	NUM	021 *1	-	Yes	-	-
FAX	NUM	022 *1	-	Yes	-	-
FAX	NUM	023 *1	-	Yes	-	-
FAX	NUM	024 *1	-	Yes	-	-
FAX	NUM	025 *1	-	Yes	-	-
FAX	NUM	026 *1	-	Yes	-	-

*1. FAX model only

Initial screen	Large	Middle	Small	Case A	Case B	Case C
FAX	NUM	027 *1	-	Yes	-	-
FAX	NUM	029 *1	-	Yes	-	-
FAX	NUM	049 *1	-	Yes	-	-
FAX	NUM	051 *1	-	Yes	-	-
FAX	NUM	053 *1	-	Yes	-	-
FAX	NUM	054 *1	-	Yes	-	-
FAX	NCU	TONE	001 *1	Yes	-	-
FAX	NCU	TONE	002 *1	Yes	-	-
FAX	NCU	PULSE	FORM *1	Yes	-	-
FAX	NCU	PULSE	001 *1	Yes	-	-
FAX	NCU	PULSE	002 *1	Yes	-	-
FAX	NCU	PULSE	003 *1	Yes	-	-
FAX	NCU	PULSE	004 *1	Yes	-	-
FAX	NCU	DIALTONE	BIT *1	Yes	-	-
FAX	NCU	DIALTONE	001 *1	Yes	-	-
FAX	NCU	DIALTONE	002 *1	Yes	-	-
FAX	NCU	DIALTONE	003 *1	Yes	-	-
FAX	NCU	DIALTONE	004 *1	Yes	-	-
FAX	NCU	DIALTONE	005 *1	Yes	-	-
FAX	NCU	DIALTONE	006 *1	Yes	-	-
FAX	NCU	DIALTONE	007 *1	Yes	-	-
FAX	NCU	DIALTONE	008 *1	Yes	-	-
FAX	NCU	3rd DLTN	BIT *1	Yes	-	-
FAX	NCU	4th DLTN	001 *1	Yes	-	-
FAX	NCU	5th DLTN	002 *1	Yes	-	-
FAX	NCU	6th DLTN	003 *1	Yes	-	-
FAX	NCU	7th DLTN	004 *1	Yes	-	-
FAX	NCU	8th DLTN	005 *1	Yes	-	-
FAX	NCU	9th DLTN	006 *1	Yes	-	-
FAX	NCU	10th DLTN	007 *1	Yes	-	-
FAX	NCU	11th DLTN	008 *1	Yes	-	-
FAX	NCU	BUSTONE1	BIT *1	Yes	-	-
FAX	NCU	BUSTONE2	001 *1	Yes	-	-
FAX	NCU	BUSTONE3	002 *1	Yes	-	-
FAX	NCU	BUSTONE4	003 *1	Yes	-	-
FAX	NCU	BUSTONE5	004 *1	Yes	-	-
FAX	NCU	BUSTONE6	005 *1	Yes	-	-
FAX	NCU	BUSTONE7	006 *1	Yes	-	-
FAX	NCU	BUSTONE8	007 *1	Yes	-	-
FAX	NCU	BUSTONE9	008 *1	Yes	-	-
FAX	NCU	BUSTONE2	BIT *1	Yes	-	-
FAX	NCU	BUSTONE3	001 *1	Yes	-	-
FAX	NCU	BUSTONE4	002 *1	Yes	-	-
FAX	NCU	BUSTONE5	003 *1	Yes	-	-
FAX	NCU	BUSTONE6	004 *1	Yes	-	-
FAX	NCU	BUSTONE7	005 *1	Yes	-	-
FAX	NCU	BUSTONE8	006 *1	Yes	-	-
FAX	NCU	BUSTONE9	007 *1	Yes	-	-

*1. FAX model only

Initial screen	Large	Middle	Small	Case A	Case B	Case C
FAX	NCU	BUSTONE10	008 *1	Yes	-	-
FAX	NCU	REORDRTN	BIT *1	Yes	-	-
FAX	NCU	REORDRTN	001 *1	Yes	-	-
FAX	NCU	REORDRTN	002 *1	Yes	-	-
FAX	NCU	REORDRTN	003 *1	Yes	-	-
FAX	NCU	REORDRTN	004 *1	Yes	-	-
FAX	NCU	REORDRTN	005 *1	Yes	-	-
FAX	NCU	REORDRTN	006 *1	Yes	-	-
FAX	NCU	REORDRTN	007 *1	Yes	-	-
FAX	NCU	REORDRTN	008 *1	Yes	-	-
FAX	NCU	AUTO RX	001 *1	Yes	-	-
FAX	NCU	AUTO RX	002 *1	Yes	-	-
FAX	NCU	AUTO RX	003 *1	Yes	-	-
FAX	NCU	AUTO RX	004 *1	Yes	-	-
FAX	NCU	AUTO RX	005 *1	Yes	-	-
FAX	NCU	AUTO RX	006 *1	Yes	-	-
FAX	NCU	AUTO RX	007 *1	Yes	-	-
FAX	NCU	AUTO RX	008 *1	Yes	-	-
FAX	NCU	AUTO RX	009 *1	Yes	-	-
FAX	NCU	CNGDTCT	001 *1	Yes	-	-
FAX	NCU	CNGDTCT	002 *1	Yes	-	-
FAX	NCU	CNGDTCT	006 *1	Yes	-	-
FAX	NCU	CNGDTCT	007 *1	Yes	-	-
FAX	NCU	CNGDTCT	008 *1	Yes	-	-
FAX	NCU	CNGDTCT	009 *1	Yes	-	-
FAX	NCU	CNGDTCT	011 *1	Yes	-	-
FAX	NCU	CNGDTCT	012 *1	Yes	-	-
FAX	NCU	SPECIALB	SW01 *1	Yes	-	-
FAX	NCU	SPECIALB	SW02 *1	Yes	-	-
FAX	NCU	SPECIALB	SW03 *1	Yes	-	-
FAX	NCU	SPECIALB	SW04 *1	Yes	-	-
FAX	NCU	SPECIALB	SW05 *1	Yes	-	-
FAX	NCU	SPECIALB	SW06 *1	Yes	-	-
FAX	NCU	SPECIALB	SW07 *1	Yes	-	-
FAX	NCU	SPECIALB	SW08 *1	Yes	-	-
FAX	NCU	SPECIALB	SW09 *1	Yes	-	-
FAX	NCU	SPECIALB	SW10 *1	Yes	-	-
FAX	NCU	SPECIALB	SW11 *1	Yes	-	-
FAX	NCU	SPECIALB	SW12 *1	Yes	-	-
FAX	NCU	SPECIALB	SW13 *1	Yes	-	-
FAX	NCU	SPECIALB	SW14 *1	Yes	-	-
FAX	NCU	SPECIALB	SW15 *1	Yes	-	-
FAX	NCU	SPECIALB	SW16 *1	Yes	-	-
FAX	NCU	SPECIALB	SW17 *1	Yes	-	-
FAX	NCU	SPECIALB	SW18 *1	Yes	-	-
FAX	NCU	SPECIALB	SW19 *1	Yes	-	-
FAX	NCU	SPECIALB	SW20 *1	Yes	-	-
FAX	NCU	SPECIALB	SW21 *1	Yes	-	-

*1. FAX model only

Initial screen	Large	Middle	Small	Case A	Case B	Case C
FAX	NCU	SPECIALB	SW22 *1	Yes	-	-
FAX	NCU	SPECIALB	SW23 *1	Yes	-	-
FAX	NCU	SPECIALB	SW24 *1	Yes	-	-
FAX	NCU	SPECIALB	SW25 *1	Yes	-	-
FAX	NCU	SPECIALB	SW26 *1	Yes	-	-
FAX	NCU	SPECIALB	SW27 *1	Yes	-	-
FAX	NCU	SPECIALB	SW28 *1	Yes	-	-
FAX	NCU	SPECIALB	SW29 *1	Yes	-	-
FAX	NCU	SPECIALB	SW30 *1	Yes	-	-
FAX	NCU	SPECIALN	004 *1	Yes	-	-
FAX	NCU	SPECIALN	005 *1	Yes	-	-
FAX	NCU	SPECIALN	006 *1	Yes	-	-
FAX	NCU	SPECIALN	007 *1	Yes	-	-
FAX	NCU	SPECIALN	008 *1	Yes	-	-
FAX	NCU	SPECIALN	009 *1	Yes	-	-
FAX	NCU	SPECIALN	011 *1	Yes	-	-
FAX	NCU	SPECIALN	012 *1	Yes	-	-
FAX	NCU	SPECIALN	013 *1	Yes	-	-
FAX	NCU	SPECIALN	014 *1	Yes	-	-
FAX	NCU	SPECIALN	015 *1	Yes	-	-
FAX	NCU	SPECIALN	016 *1	Yes	-	-
FAX	NCU	SPECIALN	017 *1	Yes	-	-
FAX	NCU	SPECIALN	019 *1	Yes	-	-
FAX	NCU	SPECIALN	020 *1	Yes	-	-
FAX	NCU	SPECIALN	024 *1	Yes	-	-
FAX	NCU	SPECIALN	025 *1	Yes	-	-
FAX	NCU	SPECIALN	026 *1	Yes	-	-
FAX	NCU	SPECIALN	027 *1	Yes	-	-
FAX	NCU	SPECIALN	030 *1	Yes	-	-
FAX	NCU	SPECIALN	040 *1	Yes	-	-
FAX	NCU	SPECIALN	041 *1	Yes	-	-
FAX	NCU	SPECIALN	042 *1	Yes	-	-
FAX	NCU	SPECIALN	044 *1	Yes	-	-
FAX	NCU	SPECIALN	045 *1	Yes	-	-
FAX	NCU	SPECIALN	046 *1	Yes	-	-
FAX	NCU	SPECIALN	047 *1	Yes	-	-
FAX	NCU	SPECIALN	048 *1	Yes	-	-
FAX	NCU	SPECIALN	065 *1	Yes	-	-
FAX	NCU	SPECIALN	066 *1	Yes	-	-
FAX	NCU	RKEY	001 *1	Yes	-	-
FAX	NCU	RKEY	002 *1	Yes	-	-
FAX	NCU	PBXDIALT	BIT *1	Yes	-	-
FAX	NCU	PBXDIALT	001 *1	Yes	-	-
FAX	NCU	PBXDIALT	002 *1	Yes	-	-
FAX	NCU	PBXDIALT	003 *1	Yes	-	-
FAX	NCU	PBXDIALT	004 *1	Yes	-	-
FAX	NCU	PBXDIALT	005 *1	Yes	-	-
FAX	NCU	PBXDIALT	006 *1	Yes	-	-

*1. FAX model only

Initial screen	Large	Middle	Small	Case A	Case B	Case C
FAX	NCU	PBXDIALT	007 *1	Yes	-	-
FAX	NCU	PBXDIALT	008 *1	Yes	-	-
FAX	NCU	PBXBUSYT	BIT *1	Yes	-	-
FAX	NCU	PBXBUSYT	001 *1	Yes	-	-
FAX	NCU	PBXBUSYT	002 *1	Yes	-	-
FAX	NCU	PBXBUSYT	003 *1	Yes	-	-
FAX	NCU	PBXBUSYT	004 *1	Yes	-	-
FAX	NCU	PBXBUSYT	005 *1	Yes	-	-
FAX	NCU	PBXBUSYT	006 *1	Yes	-	-
FAX	NCU	PBXBUSYT	007 *1	Yes	-	-
FAX	NCU	PBXBUSYT	008 *1	Yes	-	-

• [Setting/Registration] menu

System Management Settings

System Management Settings

User mode setting items	Setting description	Case A	Case B	Case C
System Manager Information Settings				
System Manager ID	Up to 7 digits	Yes	Yes	Yes
System Manager PIN	Set (7 digits)	Yes	Yes	Yes
System Manager Name	32 characters	Yes	Yes	Yes
Contact Information	32 characters	Yes	Yes	Yes
E-mail Address	64 characters	Yes	Yes	Yes
System Manager Comment	32 characters	Yes	Yes	Yes
Device Information Settings				
Device Name	32 characters; Model name is displayed as an initial value	Yes		
Location	32 characters	Yes		
Support Link	128 characters	Yes	Yes	Yes
Information for Purchasing Consumables				
Purchase From	32 characters	Yes	Yes	Yes
E-mail Address	64 characters	Yes	Yes	Yes
URL	256 characters	Yes	Yes	Yes
Display Consumables Purchase Button	On/Off	Yes	Yes	Yes
Toner Status Settings				
Use Toner Status	On/Off	Yes	Yes	Yes
Display Consumables Purchase Button	On/Off	Yes	Yes	Yes

Department ID Management

The * marks in [Setting description] indicates the default setting values.

User mode setting items	Setting description	Case A	Case B	Case C
Department ID Management (not displayed for models without N/W)	Off*/On	Yes	Yes	Yes
Register New Department (can be set from remote UI)		Yes	Yes	Yes
Department ID	Up to 7 digits	Yes	Yes	Yes
Set PIN	7 digits	Yes	Yes	Yes
Restrict Functions		Yes	Yes	Yes
Black & White Copy	Off*/On	Yes	Yes	Yes
Black & White Print	Off*/On	Yes	Yes	Yes

*1. FAX model only

User mode setting items		Setting description	Case A	Case B	Case C
	Scan	Off*/On	Yes	Yes	Yes
	Fax	Off*/On	Yes	Yes	Yes
Department ID Page Total (can be set from remote UI)					
	Allow Printer Jobs with Unknown IDs (can be set from remote UI)	Allow*/Reject	Yes	Yes	Yes
	Allow Scan Jobs W/ Unknown IDs (can be set from remote UI)	Allow*/Reject	Yes	Yes	Yes

Network Settings

The * marks in [Setting description] indicates the default setting values.

User mode setting items		Setting description	Case A	Case B	Case C
TCP/IP settings					
IPv4 Settings					
	Auto Acquire	Off/On*	Yes	Yes	Yes
	AutoIP	Off/On*	Yes	Yes	Yes
	Select Protocol	DHCP*/BOOTP/RARP/OFF	Yes	Yes	Yes
	IP Address	IP address 0.0.0.0*	Yes		
	Subnet Mask	IP address 0.0.0.0*	Yes	Yes	Yes
	Gateway Address	IP address 0.0.0.0*	Yes	Yes	Yes
DNS Settings					
	Primary DNS Server	Enter the server address	Yes	Yes	Yes
	Secondary DNS Server	Enter the server address	Yes	Yes	Yes
	DNS Host Name/Domain Name Settings		Yes		
	Host Name	Enter the host name	Yes		
	Domain Name	Enter the domain name	Yes		
	DNS Dynamic Update Settings		Yes	Yes	Yes
	DNS Dynamic Update	Off*/On	Yes	Yes	Yes
	DNS Dynamic Update Interval	0 to 48 hr. (*24 hr.)	Yes	Yes	Yes
mDNS Settings					
	mDNS Settings	Off/On*	Yes		
	mDNS Name	Enter the mDNS name	Yes		
DHCP Option Settings					
	Acquire Host Name (option12)	Off/On*	Yes	Yes	Yes
	DNS Dynamic Update (option81)	Off*/On	Yes	Yes	Yes
	Acquire DNS Server Address (option6)	Off/On*	Yes	Yes	Yes
	Acquire Domain Name (option15)	Off/On*	Yes	Yes	Yes
	Acquire WINS Server Address (option44)	Off/On*	Yes	Yes	Yes
	Acquire SMTP Server Address (option69)	Off*/On	Yes	Yes	Yes
	Acquire POP3 Server Address (option70)	Off*/On	Yes	Yes	Yes
IPv6 Settings					
Use IPv6					
	(Use IPv6)	Off*/On The Link-Local Address is displayed	Yes	Yes	Yes
Stateless Address Settings					
	Use Stateless Address	Off/On* The Stateless Address and the Prefix Length are displayed (max 6 addresses)	Yes	Yes	Yes
Manual Address Settings					
	Use Manual Address	Off*/On	Yes		
	Manual Address	IP address entry screen	Yes		
	Prefix Length	(0 to *64 to 128)	Yes		
	Default Router Address	Router address entry screen	Yes		

User mode setting items		Setting description	Case A	Case B	Case C
	Use DHCPv6				
	Use DHCPv6	Off*/On The Stateful Address and the Prefix Length are displayed.	Yes	Yes	Yes
	DNS Settings				
	DNS Server Settings		Yes	Yes	Yes
	Primary DNS Server	Enter the server address	Yes	Yes	Yes
	Secondary DNS Server	Enter the server address	Yes	Yes	Yes
	DNS Host Name/Domain Name Settings		Yes		
	Use Same Host Name/Domain Name as IPv4	Off/On*	Yes		
	Host Name	Enter the host name	Yes		
	Domain Name	Enter the domain name	Yes		
	DNS Dynamic Update Settings		Yes	Yes	Yes
	DNS Dynamic Update	Off*/On	Yes	Yes	Yes
	Register Manual Address	Off*/On	Yes	Yes	Yes
	Register Stateful Address	Off*/On	Yes	Yes	Yes
	Register Stateless Address	Off*/On	Yes	Yes	Yes
	DNS Dynamic Update Interval	0 to 48 hr. (*24 hr.)	Yes	Yes	Yes
	mDNS Settings				
	mDNS Settings	Off/On*	Yes		
	Use Same mDNS Name as IPv4	Off/On*	Yes		
	mDNS Name	Enter the mDNS name	Yes		
	DHCPv6 Option Settings				
	Acquire DNS Server Address (option23)	Off/On*	Yes	Yes	Yes
	Acquire Domain Name (option24)	Off/On*	Yes	Yes	Yes
	WINS Settings				
	WINS Resolution	Off*/On	Yes	Yes	Yes
	WINS Server Address	WINS server's IP address (only in the case of WINS resolution) Initial value: 0.0.0.0	Yes	Yes	Yes
	LPD Settings				
	LPD Print Settings	Off/On*	Yes	Yes	Yes
	Period Before Timeout	1 to 60 (*5)	Yes	Yes	Yes
	RAW Settings				
	RAW Print Settings	Off/On*	Yes	Yes	Yes
	Period Before Timeout	1 to 60 (*5)	Yes	Yes	Yes
	WSD Settings				
	WSD Print Settings				
	Use WSD Print	Off/On*	Yes	Yes	Yes
	Use WSD Browsing	Off/On*	Yes	Yes	Yes
	WSD Scan Settings				
	Use WSD Scan	Off*/On	Yes	Yes	Yes
	Use Computer Scan	Off*/On	Yes	Yes	Yes
	Use Multicast Discovery	Off/On*	Yes	Yes	Yes
	Use FTP PASV Mode	Off*/On	Yes	Yes	Yes
	Use HTTP	Off/On*	Yes	Yes	Yes
	Port Number Settings				
	LPD	1 to 65535 (*515)	Yes	Yes	Yes
	RAW	1 to 65535 (*9100)	Yes	Yes	Yes
	HTTP	1 to 65535 (*80)	Yes	Yes	Yes
	POP3	1 to 65535 (*110)	Yes	Yes	Yes
	FTP	1 to 65535 (*21)	Yes	Yes	Yes
	SMTP	1 to 65535 (*25)	Yes	Yes	Yes
	SNMP	1 to 65535 (*161)	Yes	Yes	Yes
	WSD Multicast Discovery	1 to 65535 (*3702)	Yes	Yes	Yes

User mode setting items		Setting description	Case A	Case B	Case C
	Multicast Discovery	1 to 65535 (*427)	Yes	Yes	Yes
	MTU Size	1300/1400/*1500	Yes	Yes	Yes
IPP Print Settings					
	Use IPP Printing	Off/On*	Yes	Yes	Yes
	Use TLS	Off*/On	Yes	Yes	Yes
Network Link Scan Settings					
	Use Network Link Scan	Off/On*	Yes	Yes	Yes
SNTP Settings					
	Use SNTP	Off*/On	Yes	Yes	Yes
	Polling Interval	1 to 48 (*24)	Yes	Yes	Yes
	NTP Server Address	(up to 255 characters) *NULL	Yes	Yes	Yes
Multicast Discovery Settings					
	Respond to Discovery	Off/On*	Yes	Yes	Yes
	Scope Name	(up to 32 characters) *default	Yes	Yes	Yes
Sleep Mode Notification Settings					
	Sleep Mode Notification	Off/On*	Yes	Yes	Yes
	Port Number	1 to 65535 (*11427)	Yes	Yes	Yes
	Number of Routers to Traverse	0 to 254 (*3)	Yes	Yes	Yes
	Notification Interval	60 to 65535 (*600)	Yes	Yes	Yes
Proxy Settings					
	Use Proxy	Off*/On	Yes	Yes	Yes
	HTTP Proxy Server Address	IP address or character strings (max. 128 bytes+ Null)	Yes	Yes	Yes
	HTTP Proxy Server Port Number	1 to 65535 80*	Yes	Yes	Yes
	Use Proxy within Same Domain	Off*/On	Yes	Yes	Yes
	Use Proxy Authentication	Off*/On	Yes	Yes	Yes
	User Name	(up to 24 characters)	Yes	Yes	Yes
	Password	(up to 24 characters)	Yes	Yes	Yes
E-Mail/I-Fax Settings					
	SMTP Server	Enter the server address	Yes	Yes	Yes
	E-mail Address	Enter an e-mail address (max. 120 bytes)	Yes	Yes	Yes
	POP Server	Enter the server address	Yes	Yes	Yes
	User Name	Enter a user name	Yes	Yes	Yes
	Password	Enter a password	Yes	Yes	Yes
	POP RX	Off*/On	Yes	Yes	Yes
	Pop Interval	* up to 99 (0=Off)	Yes	Yes	Yes
Authentication/Encryption Settings					
	Use POP Auth. Before Sending	Off*/On	Yes	Yes	Yes
	APOP	Off*/On	Yes	Yes	Yes
	SMTP Authentication	Off*/On	Yes	Yes	Yes
	User Name	Enter a user name	Yes	Yes	Yes
	Allow TLS (SMTP)	Off*/On	Yes	Yes	Yes
	Verify Certificate	On/Off*	Yes	Yes	Yes
	Verify CN	On/Off*	Yes	Yes	Yes
	Allow TLS (POP)	Off*/On	Yes	Yes	Yes
	Verify Certificate	On/Off*	Yes	Yes	Yes
	Verify CN	On/Off*	Yes	Yes	Yes
SMB Settings					
	NetBIOS Name	NetBIOS name of own machine (15 bytes)	Yes		
	Workgroup Name	Workgroup name (15 bytes) to which the user belongs	Yes		
SNMP Settings					
SNMPv1 Settings					
	Use SNMPv1 Settings	Off/On*	Yes	Yes	Yes

User mode setting items		Setting description	Case A	Case B	Case C
	Use Community Name 1	Off/On*	Yes	Yes	Yes
	Community Name 1	Character strings; Public*	Yes	Yes	Yes
	Use Community Name 2	Off*/On	Yes	Yes	Yes
	Community Name 2	Character strings	Yes	Yes	Yes
	MIB Access Permission 1	Read Only*/Read/Write	Yes	Yes	Yes
	MIB Access Permission 2	Read Only*/Read/Write	Yes	Yes	Yes
	Use Dedicated Community	Off/On*	Yes	Yes	Yes
	Dedicated Community Settings	RW/RO*/Off; The value of DB: RW (0x00)/RO(0x01)/Off(0x02)	Yes	Yes	Yes
SNMPv3 Settings					
	Use SNMPv3 Settings	Off*/On	Yes	Yes	Yes
	Context Settings				
	Acquire Printer Management Information from Host	Off*/On	Yes	Yes	Yes
AirPrint Settings					
	Use AirPrint	Off/On*	Yes	Yes	Yes
	Printer Name	Enter the mDNS name	Yes		
	Location	32 characters	Yes		
	Latitude	N*/S, 0* to 90°, 0* to 59', 0* to 59.999"	Yes		
	Longitude	E*/W, 0* to 180°, 0* to 59', 0* to 59.999"	Yes		
Mopria Settings					
	Use Mopria	Off/On*	Yes	Yes	Yes
Dedicated Port Settings					
	(Dedicated Port Settings)	Off/On*	Yes	Yes	Yes
	Waiting Time for Connection at Startup	(0 to 300) sec *0 sec (NCA)	Yes	Yes	Yes
Ethernet Driver Settings					
	Auto Detect	Off/On*	Yes	Yes	Yes
	Communication Mode	Half Duplex*/Full Duplex	Yes	Yes	Yes
	Ethernet Type	10 Base-T*/100 Base-TX /1000 Base-T	Yes	Yes	Yes
Wireless LAN Settings					
Wireless LAN Manual Settings					
SSID Settings					
	SSID Manual Settings	Character strings (ASCII: 1-32 characters)	Yes	Yes	Yes
Security Settings					
	Security	WPA/WPA2 PSK*/WEP/None	Yes	Yes	Yes
WPA/WPA2 PSK Settings					
	WPA/WPA2 Encryption Method	Auto (AES-CCMP or TKIP) */ AES-CCMP	Yes	Yes	Yes
	Entry Format	ASCII (8 to 63 characters)/ Hex number (64 digits)	Yes	Yes	Yes
	WPA/WPA2 PSK	Character strings (ASCII: 8 to 63 characters, Hex number: 64 digits)	Yes	Yes	Yes
WEP Settings					
	WEP Key Length	40bit WEP key* / 104bit WEP key	Yes	Yes	Yes
	Entry Format	40-bit ASCII (5 characters)/104-bit ASCII (13 characters)/40-bit hex number (10 digits)//104-bit hex number (26 digits)	Yes	Yes	Yes
	WEP Key 1	Character strings (ASCII: 5 characters/13 characters, Hex number: 10 digits/26 digits)	Yes	Yes	Yes
	WEP Key 2	Character strings (ASCII: 5 characters/13 characters, Hex number: 10 digits/26 digits)	Yes	Yes	Yes
	WEP Key 3	Character strings (ASCII: 5 characters/13 characters, Hex number: 10 digits/26 digits)	Yes	Yes	Yes
	WEP Key 4	Character strings (ASCII: 5 characters/13 characters, Hex number: 10 digits/26 digits)	Yes	Yes	Yes
	Select WEP Key	1 to 4 (*1)	Yes	Yes	Yes
	802.11 Authentication	Open System*/Shared Key	Yes	Yes	Yes

User mode setting items		Setting description	Case A	Case B	Case C
Power Save Mode					
	Power Save Mode	On/Off*	Yes	Yes	Yes
Select Wired/Wireless LAN					
	Select Wired/Wireless LAN	Wired LAN*/Wireless LAN	Yes	Yes	Yes
Settings for Device Settings Management					
	Use Device Settings Management	On*/Off	Yes	Yes	Yes
Firmware Update Management Settings					
	Use TLS	On*/Off	Yes	Yes	Yes
	L-CDS URL	Character strings (512 bytes) ; Alphanumeric characters and the following symbols can be used: ; / ? : @ & = + \$, - _ . ! ~ * () % # []	Yes	Yes	Yes

Security Settings

The * marks in [Setting description] indicates the default setting values.

User mode setting items		Setting description	Case A	Case B	Case C
IPv4 Address Filter					
Outbound Filter					
	Use Filter	Off*/On	Yes	Yes	Yes
	Default Policy	Reject/Allow*	Yes	Yes	Yes
	Exception Addresses	Up to 16 send exception IPv4 addresses	Yes	Yes	Yes
Inbound Filter					
	Use Filter	Off*/On	Yes	Yes	Yes
	Default Policy	Reject/Allow*	Yes	Yes	Yes
	Exception Addresses	Up to 16 reception exception IPv4 addresses	Yes	Yes	Yes
IPv6 Address Filter					
Outbound Filter					
	Use Filter	Off*/On	Yes	Yes	Yes
	Default Policy	Reject/Allow*	Yes	Yes	Yes
	Exception Addresses	Up to 16 send exception IPv6 addresses	Yes	Yes	Yes
Inbound Filter					
	Use Filter	Off*/On	Yes	Yes	Yes
	Default Policy	Reject/Allow*	Yes	Yes	Yes
	Exception Addresses	Up to 16 reception exception IPv6 addresses	Yes	Yes	Yes
MAC Address Filter					
Outbound Filter					
	Use Filter	Off*/On	Yes	Yes	Yes
	Default Policy	Reject/Allow*	Yes	Yes	Yes
	Exception Addresses	Up to 32 MAC addresses	Yes	Yes	Yes
Inbound Filter					
	Use Filter	Off*/On	Yes	Yes	Yes
	Default Policy	Reject/Allow*	Yes	Yes	Yes
	Exception Addresses	Up to 32 MAC addresses	Yes	Yes	Yes

Restrict TX Function

The * marks in [Setting description] indicates the default setting values.

User mode setting items		Setting description	Case A	Case B	Case C
Address Book PIN		7 digits	Yes	Yes	Yes
Restrict New Destinations		Off*/On	Yes	Yes	Yes
Restrict Sending from Log		Off*/On	Yes	Yes	Yes
One-Touch/Coded Dial TX Confirmation		Off*/On	Yes	Yes	Yes

Register LDAP Server

The * marks in [Setting description] indicates the default setting values.

User mode setting items		Setting description	Case A	Case B	Case C
Register New LDAP Server (For Search)					
	Server Name	Character strings (UTF-8 in 24 characters, max. 96 bytes)	Yes	Yes	Yes
	Server Address	IP address or character strings (47 bytes)	Yes	Yes	Yes
	Position to Start Search	Specify the part of the tree of the directory server where search is started (120bytes)	Yes	Yes	Yes
	Use TLS	On/Off*	Yes	Yes	Yes
	Port Number	The communication port number of LDAP used by the LDAP server (1 to 65535); Initial value: 389	Yes	Yes	Yes
	Search Timeout	Response time from the LDAP server (30 to 300 sec); Initial value: 60	Yes	Yes	Yes
	Login Information	Do Not Use*/Use/Use (Security Authentication)	Yes	Yes	Yes
	User Name	User name that can be authenticated for LADP server (120 bytes)	Yes	Yes	Yes
	Domain Name	120byte	Yes	Yes	Yes
	Display Authentication Screen When Searching	On/Off*	Yes	Yes	Yes
	Use Auth. Info. at Send Start	On*/Off	Yes	Yes	Yes
Register New LDAP Server (For Authentication)					
	Server Name	Character strings (UTF-8 in 24 characters, max. 96 bytes)	Yes	Yes	Yes
	Server Address	IP address or character strings (47 bytes)	Yes	Yes	Yes
	Position to Start Search	Specify the part of the tree of the directory server where search is started (120bytes).	Yes	Yes	Yes
	Use TLS	On/Off*	Yes	Yes	Yes
	Port Number	The communication port number of LDAP used by the LDAP server (1 to 65535); Initial value: 389	Yes	Yes	Yes
	Auth/Attrib Acquisition Timeout	Response time from the LDAP server (15 to 150 sec); Initial value: 30	Yes	Yes	Yes
	User Name Attribute	Attribute name used to obtain the user name from the authentication server (64 bytes)	Yes	Yes	Yes
	E-Mail Address Attribute	Attribute name used to obtain the e-mail address from the authentication server (64 bytes)	Yes	Yes	Yes
	Login Information	Use*/Use (Security Authentication)	Yes	Yes	Yes
	Use System Manager ID	On/Off*	Yes	Yes	Yes
	User Name	User name that can be authenticated for LADP server (120 bytes)	Yes	Yes	Yes
	Domain Name	120bytes	Yes	Yes	Yes

Authentication Settings for Send Function

The * marks in [Setting description] indicates the default setting values.

User mode setting items		Setting description	Case A	Case B	Case C
	Display Authentication Screen When Sending Operation Starts	On/Off*	Yes	Yes	Yes
	Display Confirmation Screen When Logging Out	On/Off*	Yes	Yes	Yes
E-Mail/I-Fax Sending Settings					
	E-Mail/I-Fax Sending:	Do Not Allow/Allow*/Only Allow Sending to Myself	Yes	Yes	Yes
	Authentication Method	Display the authentication screen using the same user name as when the sending operation started/Display the authentication screen without any authentication information/Use device-specific authentication information and do not display the authentication screen*	Yes	Yes	Yes
	Specify Authentication User Destination as Sender	On*/Off	Yes	Yes	Yes
File Sending Settings					

User mode setting items		Setting description	Case A	Case B	Case C
	File Sending	Do Not Allow/Allow*/Only Allow Sending to Myself or Specified Folder	Yes	Yes	Yes
	When Sending File to Destination Registered in Address Book				
	Authentication Method	Display the authentication screen using the same authentication information as when the sending operation started/Display the authentication screen without any authentication information/Use the authentication information from the address book and do not display the authentication screen*	Yes	Yes	Yes
	When Sending File to Myself				
	Authentication Method	Use Same Authentication Information as When Send Operation Started/Display the authentication screen without any authentication information	Yes	Yes	Yes
	Display Authentication Screen	On/Off*	Yes	Yes	Yes
	Specify Destination Folder	On/Off*	Yes	Yes	Yes
	Host Name	120 bytes	Yes	Yes	Yes
	Folder Path	120 bytes	Yes	Yes	Yes
	Add User Name	On*/Off	Yes	Yes	Yes
	Fax Sending Settings				
	Fax Sending	Do Not Allow/Allow*	Yes	Yes	Yes

Others

The * marks in [Setting description] indicates the default setting values.

User mode setting items		Setting description	Case A	Case B	Case C
	Display Job Log				
	(Display Job Log)	Off/On*	Yes	Yes	Yes
	USB Device Settings				
	(Use as USB Device)	Off/On*	Yes	Yes	Yes
	Memory Media Settings				
	(Store to Memory Media)	<Dealer machines> Off*/On <Shop machines> Off/On*	Yes	Yes	Yes
	Memory Media Print On/Off				
	(Memory Media Print)	<Dealer machines> Off*/On <Shop machines> Off/On*	Yes	Yes	Yes
	Enable Product Extended Survey Program				
	Use Product Extended Survey Program	Off/On*	Yes	Yes	Yes
	Enable Canon Mobile Scanning				
	(Enable Canon Mobile Scanning)	Off/On*	Yes	Yes	Yes
	Notify to Check Paper Settings				
	(Notify to Check Paper Settings)	Off/On*	Yes	Yes	Yes
	Secure Print Settings				
	Secure Print	Off/On*	Yes	Yes	Yes
	Secure Print Deletion Time	10 to 240 min (Default: 30 min)	Yes	Yes	Yes
	PDL Selection (Plug and Play)				
	USB	-	Yes	Yes	

Other than System Management Settings

Preferences

The * marks in [Setting description] indicates the initial setting values.

User mode setting items		Setting description	Case A	Case B	Case C
	Sound Volume Control				
	Fax Tone	Off/On* (1-3) 1*	Yes	Yes	Yes
	Ring Tone	Off/On* (1-3) 1*	Yes	Yes	Yes

User mode setting items	Setting description	Case A	Case B	Case C
TX Done Tone	Off/On* (1-3) 1* /Only When Error Occurs (1-3) 1*	Yes	Yes	Yes
RX Done Tone	Off/On* (1-3) 1* /Only When Error Occurs (1-3) 1*	Yes	Yes	Yes
Scanning Done Tone	Off/On* (1-3) 1* /Only When Error Occurs (1-3) 1*	Yes	Yes	Yes
Entry Tone	Off/On*	Yes	Yes	Yes
Invalid Entry Tone	Off*/On	Yes	Yes	Yes
Restock Supplies Tone	Off*/On	Yes	Yes	Yes
Warning Tone	Off/On*	Yes	Yes	Yes
Job Done Tone	Off/On*	Yes	Yes	Yes
Energy Saver Alert	Off*/On	Yes	Yes	Yes
Original in Feeder Detection Tone	Off/On*	Yes	Yes	Yes
Display Settings				
Default Screen after Startup/Restoration	Home ^{*1} /Copy ^{*2} / Scan / Fax / Memory Media Print / Status Monitor/ Cancel	Yes	Yes	Yes
Language	Select the display language	Yes	Yes	Yes
Remote UI Language	Select the display language	Yes	Yes	Yes
Brightness	-4 to 0*	Yes	Yes	Yes
Invert Screen Colors	Off*/On	Yes	Yes	Yes
Millimeter/Inch Entry	Millimeter*/Inch (* Inch: Only when the country/region is set to USA)	Yes	Yes	Yes
Gram/Pound Switch	Gram/Pound*	Yes	Yes	Yes
Message Display Time	1-5 2*	Yes	Yes	Yes
Scrolling Speed	Slow/Standard*/Fast	Yes	Yes	Yes
Cursor Movement	Auto*/Manual	Yes	Yes	Yes
English Keyboard Layout	USA Layout/UK Layout	Yes	Yes	Yes

Timer Settings

The * marks in [Setting description] indicates the initial setting values.

User mode setting items	Setting description	Case A	Case B	Case C
Date/Time Settings	Time zone			
Date Format	"MM/DD/YYYY", "DD/MM YYYY", "YYYY MM/DD"	Yes	Yes	Yes
Time Format	12 Hour (AM/PM) / 24 Hour	Yes	Yes	Yes
Time Zone	UTC-12:00 to UTC+14:00 + City name	Yes	Yes	
Daylight Saving Time	Off*/On, When On: Start, End	Yes	Yes	Yes
Start	Month/Week/Day	Yes	Yes	Yes
End	Month/Week/Day	Yes	Yes	Yes
Auto Sleep Time	xxx to xxx min Default: xxx	Yes	Yes	Yes
Auto Reset Time	0=None, 1...2*...9 min. (1-minute increment)	Yes	Yes	Yes
Function After Auto Reset	Default Function*/Selected Function	Yes	Yes	Yes
Auto Offline Time	0=None, 1 to 60 min. (1-minute increment) Default: 5	Yes	Yes	Yes
Auto Shutdown Time	0=None, 1 to 8 hours (1-hour increment) Default: 4 (Europe), 0 (Other than Europe)	Yes	Yes	Yes

Common Settings

The * marks in [Setting description] indicates the initial setting values.

User mode setting items	Setting description	Case A	Case B	Case C
Paper Drawer Auto Selection	Copy/Printer/RX or Fax/Other (Multi-Purpose Tray:*Off/On+Each Cassette:*Off/On)			
Copy				
Multi-purpose Tray	Off*/On	Yes	Yes	Yes
Drawer 1	Off/On*	Yes	Yes	Yes

*1. Not displayed on models without Touch Panel.

*2. Default of models without Touch Panel.

User mode setting items		Setting description	Case A	Case B	Case C
	Drawer 2	Off/On*	Yes	Yes	Yes
	Drawer 3	Off/On*	Yes	Yes	Yes
Printer					
	Drawer 1	Off/On*	Yes	Yes	Yes
	Drawer 2	Off/On*	Yes	Yes	Yes
	Drawer 3	Off/On*	Yes	Yes	Yes
Fax/Receive		(Fax for Fax-only models, Receive for others)			
	Multi-purpose Tray	Off*/On	Yes	Yes	Yes
	Drawer 1	Off/On*	Yes	Yes	Yes
	Drawer 2	Off/On*	Yes	Yes	Yes
	Drawer 3	Off/On*	Yes	Yes	Yes
Other					
	Multi-purpose Tray	Off*/On	Yes	Yes	Yes
	Drawer 1	Off/On*	Yes	Yes	Yes
	Drawer 2	Off/On*	Yes	Yes	Yes
	Drawer 3	Off/On*	Yes	Yes	Yes
Switch Paper Feed Method					
	Multi-purpose Tray	Speed Priority*/Print Side Priority	Yes	Yes	
	Drawer 1	Speed Priority*/Print Side Priority	Yes	Yes	
	Drawer 2	Speed Priority*/Print Side Priority	Yes	Yes	
	Drawer 3	Speed Priority*/Print Side Priority	Yes	Yes	

Copy Settings

User mode setting items	Setting description	Case A	Case B	Case C
Change Default Settings	Register	Yes	Yes	

Fax Settings

The * marks in [Setting description] indicates the initial setting values.

User mode setting items		Setting description	Case A	Case B	Case C
Basic Settings					
Unit Telephone Number					
	Telephone number	Max. 20 digits	Yes	Yes	
Select Line Type		Auto/Manual*	Yes	Yes	Yes
	Manual	120V, 230V: Tone*/Pulse(10PPS); 100V: Dial 20 PPS/ Dial 10 PPS/Tone*	Yes	Yes	Yes
Off-Hook Alarm		Off*/On (1-3)	Yes	Yes	Yes
Communication Management Settings					
	TX Start Speed	33600*/14400/9600/7200/4800/2400 bps	Yes	Yes	Yes
	RX Start Speed	33600*/14400/9600/7200/4800/2400 bps	Yes	Yes	Yes
R-Key Setting		PSTN*/PBX	Yes	Yes	Yes
	PBX	HOOKING/PREFIX	Yes	Yes	Yes
	Prefix Code	> Prefix Code	Yes	Yes	Yes
TX Function Settings					
Change Default Settings		Register	Yes	Yes	Yes
	2-Sided Original	Off*/On	Yes	Yes	Yes
	Resolution	standard*/fine/photo/sfine/ufine	Yes	Yes	Yes
	Density	-4 to +4(0*)	Yes	Yes	Yes
	Sharpness	-3 to +3(0*)	Yes	Yes	Yes
Register Unit Name (Fax)		Enter the unit name	Yes	Yes	Yes
ECM TX		Off/On*	Yes	Yes	Yes
Set Pause Time		1 to 15(sec)/4 to 11(sec)/3 to 6(sec) (2*)	Yes	Yes	Yes
Auto Redial		Off/On*	Yes	Yes	Yes

User mode setting items		Setting description	Case A	Case B	Case C
	Number of Times to Redial	1-N	Yes	Yes	Yes
	Redial Interval (min)	2-99(2*)	Yes	Yes	Yes
	Redial When Err Occurs	Off/On*	Yes	Yes	Yes
	Add TX Terminal ID	Off/On*	Yes	Yes	Yes
	Print Position	Inside Image Area/Outside Image Area*	Yes	Yes	Yes
	Mark Number as: TEL/FAX	FAX*/TEL	Yes	Yes	Yes
	Check Dial Tone Before Sending	Off*/On	Yes	Yes	Yes
	Allow Fax Driver TX	Off*/On	Yes	Yes	Yes
	Confirm Entered Fax Number	Off*/On	Yes	Yes	Yes
	Restrict Sequential Broadcast	Confirm Sequential Broadcast/Reject Sequential Broadcast/Off*	Yes	Yes	Yes
RX Function Settings					
	ECM RX	Off/On*	Yes	Yes	Yes
	Use Incoming Ring	Off/On*	Yes	Yes	Yes
	Number of Rings	1 to N times *2 times	Yes	Yes	Yes
	Remote RX	Off/On*	Yes	Yes	Yes
	Remote RX ID	(Remote RX ID: 00 to 99, 25*)	Yes	Yes	Yes
	Switch to Auto RX	Off*/On	Yes	Yes	Yes
	Ring Time Until Auto RX	1 to 99 sec *15 sec	Yes	Yes	Yes
Memory Lock Setting					
	PIN	Register a PIN (7 digits)	Yes	Yes	Yes
	Use Memory Lock	Off*/On	Yes	Yes	Yes
	Print Report	Off/On*	Yes	Yes	Yes
	Specify Memory Lock Time	On/Off*	Yes	Yes	Yes
	Memory Lock Start Time (hr.)	Set the time	Yes	Yes	Yes
	Memory Lock Start Time (min.)	Set the time	Yes	Yes	Yes
	Memory Lock End Time (hr.)	Set the time	Yes	Yes	Yes
	Memory Lock End Time (min.)	Set the time	Yes	Yes	Yes
RX Print Settings					
	Print on Both Sides	Off*/On	Yes	Yes	Yes
	Reduce RX Size	Off/On*	Yes	Yes	Yes
	Reduction Mode	Auto*/Fixed	Yes	Yes	Yes
	Reduction Ratio	97/95/90*/75(%)	Yes	Yes	Yes
	Reduction Direction	Vertical/Horizontal / Vertical Only*	Yes	Yes	Yes
	Add RX Page Footer	Off*/On	Yes	Yes	Yes
	Use K-Paper	Off*/On	Yes	Yes	Yes
	Continue Printing When Amount in Cartridge Is Low	Off/On	Yes	Yes	Yes
Forwarding Settings					
	Print Images	Off / Only When Error Occurs / On*	Yes	Yes	Yes
	Store Images in Memory	Do Not Store* / Only When Error Occurs	Yes	Yes	Yes

Scan Settings

The * marks in [Setting description] indicates the initial setting values.

User mode setting items		Setting description	Case A	Case B	Case C
USB Memory Settings					
	Change Default Settings	Register	Yes	Yes	Yes
	Scan Size	Refer to the list of supported paper sizes	Yes	Yes	Yes
	Color Mode	Color*/Black & White	Yes	Yes	Yes
	File Format	PDF (Compact)/PDF*/PDF (Compact/OCR)/PDF (OCR)/JPEG/TIFF	Yes	Yes	Yes
	Encrypted PDF	None*/Acrobat7.0 or later/Acrobat9.0 or equivalent/Acrobat10.0 or equivalent	Yes	Yes	Yes
	Digital Signatures	None*/OK	Yes	Yes	Yes

User mode setting items		Setting description	Case A	Case B	Case C
	Density	-4 to +4(0*)	Yes	Yes	Yes
	Original Orientation	Portrait*/Landscape	Yes	Yes	Yes
	Original Type	Text/ Text/Photo* / Photo	Yes	Yes	Yes
	2-Sided Original	Off*/On	Yes	Yes	Yes
	Sharpness	-3 to +3(0*)	Yes	Yes	Yes
	Data Size	Memory Priority/Standard*/Image Quality Priority	Yes	Yes	Yes
E-mail Settings					
	Register Default Settings	Register	Yes	Yes	Yes
	Scan Size	Refer to the list of supported paper sizes	Yes	Yes	Yes
	Color Mode	Color*/Black & White	Yes	Yes	Yes
	File Format	PDF (Compact)/PDF*/PDF (Compact/OCR)/PDF (OCR)/JPEG/TIFF	Yes	Yes	Yes
	Encrypted PDF	None*/Acrobat7.0 or later/Acrobat9.0 or equivalent/Acrobat10.0 or equivalent	Yes	Yes	Yes
	Digital Signatures	None*/OK	Yes	Yes	Yes
	Density	-4 to +4(0*)	Yes	Yes	Yes
	Original Orientation	Portrait*/Landscape	Yes	Yes	Yes
	Original Type	Text/ Text/Photo* / Photo	Yes	Yes	Yes
	2-Sided Original	Off*/On	Yes	Yes	Yes
	Sharpness	-3 to +3(0*)	Yes	Yes	Yes
	Data size	Memory Priority/Standard*/Image Quality Priority	Yes	Yes	Yes
	Subject	Enter the subject	Yes	Yes	Yes
	Message	Enter the message	Yes	Yes	Yes
	Reply-to	Specify from Address Book...	Yes	Yes	Yes
	Priority	Low/Standard*/High	Yes	Yes	Yes
I-Fax Settings					
TX Function Settings					
	Change Default Settings	Register	Yes	Yes	Yes
	Scan Size	Refer to the list of supported paper sizes	Yes	Yes	Yes
	Density	-4 to +4(0*)	Yes	Yes	Yes
	Original Type	Text*/ Text/Photo / Photo	Yes	Yes	Yes
	2-Sided Original	Off*/On	Yes	Yes	Yes
	Sharpness	-3 to +3(0*)	Yes	Yes	Yes
	Subject	Enter the subject	Yes	Yes	Yes
	Message	Enter the message	Yes	Yes	Yes
	Reply-to	Specify from Address Book...	Yes	Yes	Yes
	Add TX Terminal ID	Off/On*	Yes	Yes	Yes
	Print Position	Inside Image Area/Outside Image Area*	Yes	Yes	Yes
RX Print Settings					
	Print on Both Sides	Off*/On	Yes	Yes	Yes
	RX Print Size	Refer to the list of supported paper sizes. Default: AB configuration=>A4, AB/Inch configuration=>A4, Inch configuration=>LTR	Yes	Yes	Yes
	Continue Printing When Amount in Cartridge Is Low	Off*/No	Yes	Yes	Yes
File Settings					
Change/Register Default Settings					
	File	Register	Yes	Yes	Yes
	Scan Size	Refer to the list of supported paper sizes	Yes	Yes	Yes
	Color Mode	Color*/Black & White	Yes	Yes	Yes
	File Format	PDF (Compact)/PDF*/PDF (Compact/OCR)/PDF (OCR)/JPEG/TIFF	Yes	Yes	Yes
	Encrypted PDF	None*/Acrobat7.0 or later/Acrobat9.0 or equivalent/Acrobat10.0 or equivalent	Yes	Yes	Yes
	Digital Signatures	None*/OK	Yes	Yes	Yes

User mode setting items		Setting description	Case A	Case B	Case C
	Density	-4 to +4(0*)	Yes	Yes	Yes
	Original Orientation	Portrait*/Landscape	Yes	Yes	Yes
	Original Type	Text/ Text/Photo* / Photo	Yes	Yes	Yes
	2-Sided Original	Off*/On	Yes	Yes	Yes
	Sharpness	-3 to +3(0*)	Yes	Yes	Yes
	Data size	Memory Priority/Standard*/Image Quality Priority	Yes	Yes	Yes
Common Settings					
	Unit Name (E-Mail/I-Fax)	Enter the unit name	Yes	Yes	Yes
Output File Image Settings					
	YCbCr Tx Gamma Value	γ1.0/γ1.4/γ1.8*/γ2.2	Yes	Yes	
OCR (Text Searchable) Settings					
	Smart Scan	Off/On*	Yes	Yes	

Memory Media Print Settings

The * marks in [Setting description] indicates the initial setting values.

User mode setting items	Setting description	Case A	Case B	Case C
Change Default Settings	Register	Yes	Yes	Yes
File Sort Default Settings	Name (Ascending)*/Name (Descending), Date/Time (Ascending) / Date/Time (Descending)	Yes	Yes	Yes
File Name Display Format	Short File Name/Long File Name*	Yes	Yes	Yes
Default Display Settings	Details*/Images	Yes	Yes	Yes

Printer Settings

The * marks in [Setting description] indicates the initial setting values.

User mode setting items	Setting description	Case A	Case B	Case C
Custom Settings				
	Prioritize Driver Settings When Printing	Yes	Yes	Yes
	Multi-purpose Tray	*Off/On	Yes	Yes
		*Force Output/Display Error (displayed only when set to On)	Yes	Yes
	Drawer 1	*Off/On	Yes	Yes
		*Force Output/Display Error (displayed only when set to On)	Yes	Yes
	Drawer 2	*Off/On	Yes	Yes
		*Force Output/Display Error (displayed only when set to On)	Yes	Yes
	Drawer 3	*Off/On	Yes	Yes
		*Force Output/Display Error (displayed only when set to On)	Yes	Yes
	Copies	1* to 99	Yes	Yes
	2-Sided Printing	Off*/On	Yes	Yes
	Paper		Yes	Yes
	Default Paper Size	-	Yes	Yes
	Default Paper Type	-	Yes	Yes
	Paper Size Override	Off*/On	Yes	Yes
	Print Quality		Yes	Yes
	Density	-8 to +8 0*	Yes	Yes
	Fine Adjust	High: -8 to +8 0*	Yes	Yes
		Medium: -8 to +8 0*	Yes	Yes
		Low: -8 to +8 0*	Yes	Yes
	Toner Save	Off*/On	Yes	Yes
	Resolution	600dpi*/1200dpi	Yes	Yes
	Barcode Adjustment Mode	Off*/Mode 1/Mode 2/Mode 3	Yes	Yes

User mode setting items		Setting description	Case A	Case B	Case C
Layout					
	Binding Location	Long Edge*/Short Edge	Yes	Yes	Yes
	Gutter	mm/in; For mm:-50.0 to 50.0, Default: 0, in 0.5-mm increment; For inch:-1.90 to 1.90, Default: 0, in 0.01-inch increment	Yes	Yes	Yes
	Offset Short Edge (Front)	mm/in; For mm:-50.0 to 50.0, Default: 0, in 0.5-mm increment; For inch:-2.00 to 2.00, Default: 0, in 0.01-inch increment	Yes	Yes	Yes
	Offset Long Edge (Front)	Same as above	Yes	Yes	Yes
	Offset Short Edge (Back)	Same as above	Yes	Yes	Yes
	Offset Long Edge (Back)	Same as above	Yes	Yes	Yes
	Auto Error Skip	Off*/On	Yes	Yes	Yes
	Timeout	Timeout (Timeout: 5 to 300 sec) 15*	Yes	Yes	Yes
	Personality	*Auto/PS/PCL/PDF/XPS	Yes	Yes	Yes
LIPSLX or UFR II					
Halftones					
	Text	ColorResolution*/GradationBWResolution*/Color Tone/Gradation/High Resolution	Yes	Yes	Yes
	Graphics	ColorResolution/Gradation*BWResolution/Color Tone*/Gradation/High Resolution	Yes	Yes	Yes
	Image	ColorResolution/Gradation*BWResolution/Color Tone*/Gradation/High Resolution	Yes	Yes	Yes
PCL					
	Paper Save	Off*/On	Yes	Yes	Yes
	Orientation	Vertical*/Portrait	Yes	Yes	Yes
	Font Number	0 to max. number of fonts	Yes	Yes	Yes
	Point Size	Point : 4 to 999.75, Default: 12, in 0.25 increment; The value multiplied by 100 is retained as an internal value	Yes	Yes	Yes
	Pitch	dpi : 0.44 to 99.99, Default: 10, in 0.01 increment; The value multiplied by 100 is retained as an internal value	Yes	Yes	Yes
	Form Lines	Line: 5 to 128, Default: 60 (US), 64 (other than US)	Yes	Yes	Yes
	Character Code	Default PC8	Yes	Yes	Yes
	Set Custom Paper	Off*/On	Yes	Yes	Yes
	Unit of Measure	For countries other than US: Millimeters*/Inch; For US; Millimeters/Inch*	Yes	Yes	Yes
	X dimension	-	Yes	Yes	Yes
	Y dimension	-	Yes	Yes	Yes
	Append CR to LF	Yes/No*	Yes	Yes	Yes
	Enlarge A4 Print Width	Off*/On	Yes	Yes	Yes
Halftones					
	Text	Color:Resolution*/GradationBW:Resolution*/Color Tone/Gradation/High Resolution	Yes	Yes	Yes
	Graphics	Color:Resolution/Gradation*BW:Resolution/Color Tone*/Gradation/High Resolution	Yes	Yes	Yes
	Image	Color:Resolution/Gradation*BW:Resolution/Color Tone*/Gradation/High Resolution	Yes	Yes	Yes
	BarDIMM	Disable*/Enable	Yes	Yes	Yes
	FreeScape	Off, ~, ", #, \$, /, \, ?, {, }, Initial value~	Yes	Yes	Yes
PS					
	Job timeout	0 to 3600[sec], Default: 0[sec]	Yes	Yes	Yes
	Print PS Error	On/Off*	Yes	Yes	Yes
Halftones					
	Text	Color:Resolution*/GradationBW:Resolution*/Gradation/High Resolution	Yes	Yes	Yes
	Graphics	Color:Resolution/Gradation*BW:Resolution*/Gradation/High Resolution	Yes	Yes	Yes

User mode setting items	Setting description	Case A	Case B	Case C
Image	Color:Resolution/Gradation*BW:Resolution*/Gradation/High Resolution	Yes	Yes	Yes
Grayscale Conversion	sRGB/NTSC*/Uniform RGB	Yes	Yes	Yes
PDF				
Enlarge/Reduce to Fit Size	On/*Off	Yes	Yes	Yes
Enlarge Print Area	On/*Off	Yes	Yes	Yes
N on 1	*Off/2 on 1/4 on 1/6 on 1/8 on 1/9 on 1/16 on 1	Yes	Yes	Yes
Comment Print	Off/Auto*	Yes	Yes	Yes
Halftones				
Text	Color:Resolution*/GradationBW:Resolution*/Gradatio/High Resolution	Yes	Yes	Yes
Graphics	Color:Resolution/Gradation*BW:Resolution*/Gradatio/High Resolution	Yes	Yes	Yes
Image	Color:Resolution/Gradation*BW:Resolution*/Gradatio/High Resolution	Yes	Yes	Yes
Grayscale Conversion	sRGB/NTSC*/Uniform RGB	Yes	Yes	Yes
XPS				
Halftones				
Text	Color:Resolution*/GradationBW:Resolution*/Gradatio/High Resolution	Yes	Yes	Yes
Graphics	Color:Resolution/Gradation*BW:Resolution*/Gradatio/High Resolution	Yes	Yes	Yes
Image	Color:Resolution/Gradation*BW:Resolution*/Gradatio/High Resolution	Yes	Yes	Yes
Grayscale Conversion				
Text	sRGB/NTSC*/Uniform RGB	Yes	Yes	Yes
Graphics	sRGB/NTSC*/Uniform RGB	Yes	Yes	Yes
Image	sRGB/NTSC*/Uniform RGB	Yes	Yes	Yes
Compressed Image Output	Output*/Display Error	Yes	Yes	Yes
Imaging				
Halftones	Error Diffusion/Gradation*	Yes	Yes	Yes

Adjustment/Maintenance

The * marks in [Setting description] indicates the initial setting values.

User mode setting items	Setting description	Case A	Case B	Case C
Printer Density	-4 to +4 0*	Yes	Yes	
Toner Saver Mode	Off*/On	Yes	Yes	
Display Timing for Cartridge Preparation				
Auto		Yes	Yes	
Custom	1%-99%, *20%	Yes	Yes	
Special Processing				
Special Paper Processing	Off*/MODE1/MODE2	Yes	Yes	
Paper Wrinkle Correction	Off*/MODE1/MODE2	Yes	Yes	
Paper Curl Correction	Off*/On	Yes	Yes	
Speed Priority for Plain L Paper	Off*/MODE1/MODE2	Yes	Yes	
High-Resistance Paper Mode	Off*/On	Yes	Yes	
Smudge Reduction Mode				
Special Mode A	Off/MODE1*/MODE2/MODE3/MODE4	Yes	Yes	
Special Mode Z	Off/MODE1*/MODE2/MODE3	Yes	Yes	
Special Mode B	Off*/MODE1/MODE2/MODE3	Yes	Yes	
Special Mode D	Off*/On	Yes	Yes	

Report Output

Displayed when Report key is pressed. Not displayed in the Settings/Registration menu.

The * marks in [Setting description] indicates the initial setting values.

User mode setting items		Setting description	Case A	Case B	Case C
Output Report Settings					
	Fax TX Result Report	Off / On / Only When Error Occurs*	Yes	Yes	
	TX Image Report	Off/On*	Yes	Yes	
	E-Mail/I-Fax/File TX Result Report	Off / On / Only When Error Occurs*	Yes	Yes	
Communication Management Report					
	Auto Print After 40 Transmissions	Off/On*	Yes	Yes	
	Separate TX/RX	Off*/On	Yes	Yes	
	RX Result Report	Off* / On / Only When Error Occurs	Yes	Yes	

Common settings

User mode setting items		Case A	Case B	Case C
Paper Settings				
	Multi-purpose Tray			
	Specify When Loading Paper	Yes	Yes	
	Paper Size	Yes	Yes	
	Paper Type	Yes	Yes	
Drawer 1				
	Paper Size	Yes	Yes	
	Paper Type	Yes	Yes	
Drawer 2				
	Paper Size	Yes	Yes	
	Paper Type	Yes	Yes	
Drawer 3				
	Paper Size	Yes	Yes	
	Paper Type	Yes	Yes	
	Register Custom Paper	Yes	Yes	
Select Frequently Used Paper Sizes				
	Multi-purpose Tray	Yes	Yes	
	Drawer1	Yes	Yes	
	Drawer2	Yes	Yes	
	Drawer3	Yes	Yes	
Address Book Settings (Model with FAX and/or SEND)				
One-touch Dial				
	Fax	Yes	Yes	Yes
	Fax Number	Yes	Yes	Yes
	Name	Yes	Yes	Yes
	Set Details	Yes	Yes	Yes
	Long Distance	Yes	Yes	Yes
	TX Speed	Yes	Yes	Yes
	ECM TX	Yes	Yes	Yes
E-mail				
	E-mail Address	Yes	Yes	Yes
	Name	Yes	Yes	Yes
File: SMB				
	Host Name	Yes	Yes	Yes
	Name	Yes	Yes	Yes
	Folder Path	Yes	Yes	Yes
	User Name	Yes	Yes	Yes
	PAssword	Yes	Yes	Yes
File : FTP				
	Host Name	Yes	Yes	Yes

User mode setting items		Case A	Case B	Case C
	Name	Yes	Yes	Yes
	Folder Path	Yes	Yes	Yes
	User Name	Yes	Yes	Yes
	Password	Yes	Yes	Yes
	I-Fax			
	I-Fax Address	Yes	Yes	Yes
	Name	Yes	Yes	Yes

Monitoring Function (e-Maintenance/imageWARE Remote)

Overview of System


Function Overview

Embedded RDS (hereinafter referred to as E-RDS) is a monitoring program that runs on the host machine. When the monitoring option is enabled by making the setting on this machine, information such as the status change of the machine, counter information, and failure information are collected. The collected device information is sent to a remote maintenance server called UGW (Universal Gateway Server) via Internet, thus allowing for e-Maintenance/ imageWARE Remote (Remote Diagnosis System).

The following device information/ status can be monitored.

- Billing counts
- Parts counter
- Firmware info
- Service call error log
- Jam log
- Alarm log
- Status changes (Toner low/ out, etc.)

Since high confidentiality is required for the information shown above, it performs communication between this machine and the UGW using HTTPS/ SOAP protocol.



Features

E-RDS is embedded in the network module of the device, and the front-end module of the e-Maintenance/ imageWARE Remote system is realized without requiring hardware besides the device.

Main Functions

Functional category	Sub category	Description
Communication test	COM-TEST	Execute service mode to communicate with the server, retrieve schedule information, and establish communication.
Transmission of counters	Billing/all resources/parts/mode-by-mode counters	Periodically send billing/all resources/parts/mode-by-mode counters to the server.
Transmission of event logs	Alerts	Each time the status of the device is changed, the status information is sent to the server.
	Service call/alarm/jam log	Each time a service call, alarm, or jam log occurs, the error log is sent to the server.
Data transmission	ROM version	Periodically send firmware information of the device.
	Schedule	Periodically send schedule information of the device.

Functional category	Sub category	Description
Data transmission	Debug log	Send debug information of E-RDS which exceeds a specific size to the server.
	Sublog transmission	Send data such as device Sublogs and DCON logs to the server.
Operation instruction	Operation check	Contact the server to check if there is processing to be executed, and receive the following instructions if any. <ul style="list-style-type: none"> • Change the schedule • Change the alarm level • Change the alert filter

■ Service cautions

- After clearing the Main Controller PCB, initialization of the E-RDS setting (ERDS-DAT) and a communication test (COMTEST) need to be performed. Failure to do so will result that the counter transmitting value to the UGW may become unusual. Also, after replacing the main controller board, all settings must be reprogrammed.
- The following settings in service mode must not be change unless there are specific instructions to do so. Changing these values will cause error in communication with UGW.
 - Port number of UGW
[COPIER] > [FUNCTION] > [INSTALL] > [RGW-PORT]
Default : 443
- If the e-Maintenance/ imageWARE Remote contract of the device is invalid, be sure to turn OFF the E-RDS setting (E-RDS : 0).
- When the E-RDS function is enabled, a communication test can be performed from [Check Counter] of the machine's Control Panel. *1
When conducting a communication test from [Check Counter], pay attention to the following points:
 - During a communication test, do not take any actions such as pressing a key. Actions are not accepted until the communication test is completed (actions are ignored).
 - When a communication test is being conducted from service mode or from [Check Counter], do not conduct a communication test from the other. Such operation is not guaranteed.

■ Setting Procedure

● Preparation


Since this function communicates with the UGW server, it is necessary to connect to the external network. Check the following items, and make the settings if not yet set.

- IP address settings
- DNS server settings
- Proxy server settings*2
- Installation of CA certificate (arbitrary *3)

CAUTION:

- Obtain the information on the network environment from the system administrator of the user.
- When having changed the network settings, turn OF and then ON the main power of the machine.

*1. The user can perform a communication test or browse the result of communication test.



If the communication results in failure, an error code (hexadecimal number, 8 digit) is displayed on the Control Panel.

*2. If authentication is necessary, make the settings of the authentication information as well.

*3. When using a certificate other than those pre-installed in the device

● Procedure for Setting E-RDS

1. In the following service mode, select the following service mode to initialize the E-RDS setting values:

- COPIER > Function > CLEAR > ERDS-DAT

NOTE:

This operation initializes the E-RDS settings to factory setting values.
For the setting values to be initialized, see the section of "Setting values and data to be initialized" on page 82 .

2. Enable the E-RDS function in the following service mode, and perform a communication test.

1. Select the following item:
 - [COPIER] > [FUNCTION] > [INSTALL] > [ERDS]
2. Enter [1] from the keyboard, and press [Apply].

CAUTION:

The following settings i.e. RGW-PORT in Service mode must not be change unless there are specific instructions to do so. Changing these values will cause error in communication with UGW.

When the E-RDS function is enabled, the function to communicate with UGW is enabled.

3. Select [COM-TEST] and then touch [Yes].

If the communication is successful, "OK" is displayed. If "NG" is displayed, check the network settings and USW server address (URL).

CAUTION:

The communication results with UGW can be distinguished by referring to the COM-LOG. By performing the communication test with UGW, E-RDS acquires schedule information and starts monitoring and meter reads operation.

■ Maintenance

● Initializing E-RDS settings

It is possible to clear the FLASH data of E-RDS and change the E-RDS setting back to the default value.

Initialization procedure

Follow the procedure shown below to initialize E-RDS.

1. Enter service mode as a system administrator user.
2. Select the following service mode, and press [OK] to execute.
 - COPIER > Function > CLEAR > ERDS-DAT

Setting values and data to be initialized

The following E-RDS settings, internal data, and Alarm filtering information are initialized.

- [COPIER] > [FUNCTION] > [INSTALL] > [ERDS]
- [COPIER] > [FUNCTION] > [INSTALL] > [RGW-PORT]
- [COPIER] > [FUNCTION] > [INSTALL] > [COM-LOG]

CAUTION:

If a certificate other than the CA certificate at the time of shipment has been installed, initializing the E-RDS setting will not change the settings back to those at the time of shipment. To change the certificate back to the CA certificate at the time of shipment, delete the certificate (install the CA certificate at the time of shipment) after initializing the E-RDS settings. For the detailed procedure, refer to "Procedure for Setting E-RDS" on page 82.

● Report Output of Communication Error Log (COM-LOG)

A report of communication error log information on five affairs can be output.

Report output procedure

1. Select the following service mode, and press [Yes].

- [COPIER] > [Function] > [MISC-P] > [ERDS-LOG]

```
12/09 2015 10:14AM
*****
*** E-RDS-COM-LOG***
*****
No.01  DATE    12/09 2015      TIME 03:21 AM   CODE 05000003
Information  SUSPEND: Communication test is not performed.
No.02  DATE    12/09 2015      TIME 03:21 AM   CODE 00000000
Information  SUSPEND: mode changed.
No.03  DATE    12/09 2015      TIME 03:18 AM   CODE 05000003
Information  SUSPEND: Communication test is not performed.
No.04  DATE    12/09 2015      TIME 03:18 AM   CODE 00000000
Information  SUSPEND: mode changed.
No.05  DATE    12/09 2015      TIME 01:56 AM   CODE 05000003
Information  SUSPEND: Communication test is not performed.
```

Output sample



Periodical Service

Periodically Replaced Parts.....	85
Consumable Parts.....	86
Periodical Service.....	87
Cleaning.....	88

Periodically Replaced Parts

No periodically replaced parts is set for this product.

Consumable Parts

Parts name	Product No.	Q'ty	Interval	Remarks
ADF Separation Pad	FC7-6297	1	50,000 sheets	
ADF Separation Roller	FL2-6637	1	50,000 sheets	

Periodical Service


No periodically replaced parts is set for this product.

Cleaning

Component	Cleaning method
Scanning Area	Clean with Oil Glass Cleaner (FY9-6020) and lint-free paper.
Copy board glass	Wipe With A Lint-free Cloth.
Multi-purpose Pickup Roller	
Multi-purpose Separation Pad	
Cassette Pickup Roller	
Cassette Separation Pad	
PF Pickup Roller	
PF Separation Pad	
Registration Roller	
Media Feed Guide Unit	
Transfer Guide Unit	Wipe With A Soft and Dry Flannel Cloth.
Fixing Inlet Guide	Wipe With Alcohol Dampened Flannel Cloth.

Do not clean the following components:

- Photosensitive drum
- Transfer roller



No.	Name	No.	Name
[1]	Fixing Inlet Guide	[7]	Multi-purpose Pickup Roller
[2]	Media Feed Guide	[8]	Multi-purpose Separation Pad
[3]	Photosensitive Drum	[9]	Cassette Pickup Roller
[4]	Transfer Roller	[10]	Cassette Separation Pad
[5]	Transfer Guide Unit	[11]	PF Pickup Roller
[6]	Registration Roller Unit	[12]	PF Separation Pad




5


Disassembly/ Assembly

External Cover.....	90
Major Units.....	95
Electrical Components Layout Drawing.....	97
List of Connectors.....	102
Disassembled Parts.....	105
External Cover System.....	115
Original Exposure/Feed System.....	126
Controller System.....	135
Laser Exposure System.....	159
Image Formation System.....	160
Fixing System.....	161
Pickup Feed System.....	162


External Cover




Key No.	Name	Remarks	Reference
[1]	Multi-purpose Tray		
[2]	Cassette		
[3]	Left Cover		"Removing the Left Cover" on page 115
[4]	ADF Front Cover		
[5]	ADF Front Upper Cover		
[6]	ADF Rear Cover		
[7]	Feeder Cover		
[8]	Side Guide		
[9]	Document Tray		
[10]	ADF Frame		
[11]	Control Panel Unit		" Removing the Control Panel Unit" on page 156




Key No.	Name	Remarks	Reference
[1]	Upper Cover		"Removing the Upper Cover" on page 124
[2]	Right Cover		" Removing the Right Cover" on page 115
[3]	Right Lower Cover		" Removing the Right Lower Cover" on page 123
[4]	Right Front Inner Cover		" Removing the Right Front Inner Cover" on page 122
[5]	Front Cover Switch		
[6]	Delivery Auxiliary Tray		
[7]	Front Cover		"Removing the Front Cover Unit" on page 121



Key No.	Name	Remarks	Reference
[1]	Reader Upper Cover		
[2]	Reader Frame		




Key No.	Name	Remarks	Reference
[1]	Rear Cover Unit		"Removing the Rear Cover Unit" on page 118
[2]	Rear Lower Cover		
[3]	Rear Right Cover		"Removing the Rear Right Cover" on page 119
[4]	Face Cover		




Key No.	Name	Remarks	Reference
[1]	USB Port (F)		
[2]	Power Switch		"Removing the Power Switch" on page 139
[3]	USB Port (H)		
[4]	USB Port (D)		
[5]	LAN Port		
[6]	Handset Terminal		
[7]	External Telephone Terminal		
[8]	Telephone Line Terminal		
[9]	Power Socket		

Major Units



Key No	Name	Remarks	Reference
[1]	Registration Unit		"Removing the Registration Unit" on page 160
[2]	Pickup Unit		" Removing the Pickup Unit" on page 165
[3]	Duplex Feed Unit		" Removing the Duplex Feed Unit" on page 164
[4]	Fixing Assembly		"Removing the Fixing Assembly " on page 161
[5]	Laser Scanner Unit		"Removing the Laser Scanner Unit" on page 159




Key No	Name	Remarks	Reference
[6]	Contact Image Sensor		
[7]	ADF Pickup Feed Unit.		"Removing the ADF Pickup Feed Unit" on page 130
[8]	Reader Unit		"Removing the ADF + Reader Unit" on page 126

Key No	Name	Remarks	Reference
[9]	ADF Unit		"Removing the ADF + Reader Unit" on page 126
[10]	Control Panel Unit		" Removing the Control Panel Unit" on page 156


Electrical Components Layout Drawing

Motor/Fan




No.	Name	Major Units	Remarks	Reference
FM1	Main Fan	Machine Configuration		"Removing the Main Fan" on page 141
FM2	Sub Fan	Machine Configuration		"Removing the Sub Fan" on page 147
M3	Laser Scanner Motor	Laser Scanner Unit		
M1	Fixing Motor	Machine Configuration		"Removing the Fixing Motor" on page 146
M2	Main Motor	Machine Configuration		"Removing the Main Motor" on page 144
M4	Reader Motor	Reader Unit		
M5	ADF Motor	ADF Unit		

Solenoid



No.	Name	Major Units	Remarks	Reference
SL1	Multi-purpose Tray Pickup Solenoid	Machine Configuration		“Removing the Multi-purpose Tray Pickup Solenoid” on page 149
SL2	Cassette Pickup Solenoid	Machine Configuration		“Removing the Cassette Pickup Solenoid” on page 150
SL3	ADF Delivery Solenoid	ADF Unit		


Others



No.	Name	Main Unit	Remarks	Reference
H2	Fixing Heater	Fixing Assembly	120V	
H3	Fixing Heater	Fixing Assembly	230V	


No.	Name	Main Unit	Remarks	Reference
TH4	Fixing Sub Thermistor	Fixing Assembly	120V	
TH5	Fixing Main Thermistor	Fixing Assembly	120V	
TH6	Fixing Sub Thermistor	Fixing Assembly	230V	
TH7	Fixing Main Thermistor	Fixing Assembly	230V	
TP2	Thermoswitch	Fixing Assembly	120V	
TP3	Thermoswitch	Fixing Assembly	230V	
SP1	Speaker	Product Configuration	MF515x/ MF515dw	" Removing the Speaker (MF515x/ MF515dw)" on page 137

Sensor/Switch



No.	Name	Main Unit	Remarks	Reference
PS6	Face-up Sensor	Product Configuration		
PS2	Fixing Delivery Sensor	Fixing Assembly	120V	
PS3	Fixing Delivery Sensor	Fixing Assembly	230V	
PS5	Cassette Paper Sensor	Pickup Unit		
PS7	Face-Down Tray Paper Full Sensor	Product Configuration		
PS205	Multi-purpose Tray Paper Sensor	Product Configuration		
PS215	Top Sensor	Product Configuration		
PS225	Paper Width Sensor	Product Configuration		
PS502	Duplex Feede Sensor	Product Configuration		
PS8	CIS HP Sensor	Reader Unit		
PS9	Document End Sensor	ADF Unit		
PS10	Document Sensor	ADF Unit		
PS4	Rear Cover Sensor	Product Configuration		
SW235	Cassette Paper Switch	Product Configuration		" Removing the Cassette Sensing Switch" on page 140
SW4	Cartridge Door Switch	Product Configuration		" Removing the Cartridge Door Switch" on page 140
SW1	Power Switch	Product Configuration	Other than US, EUR	" Removing the Power Switch" on page 139
SW2	Power Switch	Product Configuration	EUR	" Removing the Power Switch" on page 139
SW3	Power Switch	Product Configuration	US	" Removing the Power Switch" on page 139


No.	Name	Main Unit	Remarks	Reference
TH3	Environment Sensor	Product Configuration		"Removing the Environment Sensor" on page 140



No.	Name	Main Unit	Remarks	Reference
UNIT6	BD PCB	Laser Scanner Unit		
UNIT25	Control Panel PCB	Control Panel Unit		"Removing the Control Panel PCB" on page 157
UNIT16	Main Controller PCB	Product Configuration		"Removing the Main Controller PCB" on page 135
UNIT14	AC Relay PCB	Product Configuration		"Removing the AC Relay PCB" on page 138
UNIT12	Arrestor PCB	Product Configuration	Only for 230V	"Removing the Arrestor PCB (230 V only)" on page 137


No.	Name	Main Unit	Remarks	Reference
UNIT4	Engine Controller PCB	Product Configuration		"Removing the Engine Controller Unit" on page 141
UNIT5	High Voltage Power Supply Unit	Product Configuration		"Removing the High Voltage Power Supply Unit" on page 152
UNIT15	All-night Power Supply PCB	Product Configuration		"Removing the All-night Power Supply PCB" on page 138
UNIT17	FAX PCB	Product Configuration	MF515x/ MF515dw	"Removing the Fax PCB (MF515x/MF515dw)" on page 136
UNIT18	OFF Hook PCB	Product Configuration	MF515x/ MF515dw	"Removing the OFF Hook PCB (MF515x/ MF515dw)" on page 137
UNIT20	USB PCB	Product Configuration		
UNIT23	Wireless LAN PCB	Product Configuration		"Removing the Wireless LAN PCB (except for D1520/MF412dn)" on page 135

List of Connectors



J No.	Symbol	Name	Relay Connector	J No.	Symbol	Name	Remarks
J1002	UNIT4	Engine Controller PCB		J15	H2	Fixing Heater	120V
J1608	UNIT4	Engine Controller PCB	J24	INL1	PS2	Fixing Delivery Sensor	120V
J1608	UNIT4	Engine Controller PCB	J18	J17	TH4	Fixing Sub Thermistor	120V
J1608	UNIT4	Engine Controller PCB	J18	J17	TH5	Fixing Main Thermistor	120V
J1002	UNIT4	Engine Controller PCB		J15	H3	Fixing Heater	230V
J1608	UNIT4	Engine Controller PCB	J24	INL2	PS3	Fixing Delivery Sensor	230V
J1608	UNIT4	Engine Controller PCB	J18	J21	TH6	Fixing Sub Thermistor	230V
J1608	UNIT4	Engine Controller PCB	J18	J21	TH7	Fixing Main Thermistor	230V
J1504	UNIT4	Engine Controller PCB		J8002	M1	Fixing Motor	
J1503	UNIT4	Engine Controller PCB		J8003	M2	Main Motor	
J1505	UNIT4	Engine Controller PCB	J8010	J8010	FM2	Sub Fan	
J1505	UNIT4	Engine Controller PCB		J8001	PS4	Rear Cover Sensor	
J1505	UNIT4	Engine Controller PCB		J12	M3	Laser Scanner Motor	
J1702	UNIT4	Engine Controller PCB		J100	UNIT6	BD PCB	
J1501	UNIT4	Engine Controller PCB	J9999	-	-	-	
J921	UNIT4	Engine Controller PCB		J921	UNIT16	Main Controller PCB	
J1701	UNIT4	Engine Controller PCB		J929	UNIT16	Main Controller PCB	
J1610	UNIT4	Engine Controller PCB		J501	UNIT5	High Voltage Power Supply Unit	

J No.	Symbol	Name	Relay Connector	J No.	Symbol	Name	Remarks
J507	UNIT5	High Voltage Power Supply Unit		J507	PS215	Top Sensor	
J513	UNIT5	High Voltage Power Supply Unit		J513	PS225	Paper Width Sensor	
J1606	UNIT4	Engine Controller PCB		J1606	FM1	Main Fan	
J1803	UNIT4	Engine Controller PCB		J1803	TH3	Environment Sensor	
J1801	UNIT4	Engine Controller PCB	J8007	J401	-	Paper Feeder Unit PF-45	
J1802	UNIT4	Engine Controller PCB		-	-	-	
J1612	UNIT4	Engine Controller PCB		J1612	SW235	Cassette Paper Switch	
J1605	UNIT4	Engine Controller PCB		J4	PS7	Face-Down Tray Paper Full Sensor	
J1605	UNIT4	Engine Controller PCB		J3	PS6	Face-up Sensor	
J1603	UNIT4	Engine Controller PCB		J6	PS5	Cassette Paper Sensor	
J1703	UNIT4	Engine Controller PCB		J1703	TAG1	Cartridge Sensor	
J1604	UNIT4	Engine Controller PCB		J1604	PS205	Multi-purpose Tray Paper Sensor	
J1601	UNIT4	Engine Controller PCB		J1601	SL2	Cassette Pickup Solenoid	
J1602	UNIT4	Engine Controller PCB		J1602	SL1	Multi-purpose Tray Pickup Solenoid	
J681	UNIT14	AC Relay PCB		J681	UNIT15	All-night Power Supply PCB	
J1104	UNIT14	AC Relay PCB		J1104	UNIT4	Engine Controller PCB	
J1101	UNIT14	AC Relay PCB		J12	UNIT12	Arrestor PCB	230V
J1101	UNIT14	AC Relay PCB		J1000	-	Inlet	120V
J918	UNIT16	Main Controller PCB		J10	SW2	Power Switch	EUR
J11	UNIT12	Arrestor PCB		J11	-	Inlet	230V
J934	UNIT16	Main Controller PCB		J934	-	Copy Control Interface Kit-C1	
J933	UNIT16	Main Controller PCB		J28	-	Copy Card Reader-F1	




J No.	Symbol	Name	Relay Connector	J No.	Symbol	Name	Remarks
J930	UNIT16	Main Controller PCB		J941	UNIT17	FAX PCB	MF515x/ MF515dw
J931	UNIT16	Main Controller PCB		J2000	UNIT18	OFF Hook PCB	MF515x/ MF515dw


J No.	Symbol	Name	Relay Connector	J No.	Symbol	Name	Remarks
J942	UNIT17	FAX PCB		J2001	UNIT18	OFF Hook PCB	MF515x/ MF515dw
J945	UNIT17	FAX PCB		-	-	-	HANDSET MF515x/ MF515dw
J944	UNIT17	FAX PCB		-	-	-	TEL MF515x/ MF515dw
J943	UNIT17	FAX PCB		-	-	-	LINE MF515x/ MF515dw
J908	UNIT16	Main Controller PCB		J1	UNIT23	Wireless LAN PCB	
J914	UNIT16	Main Controller PCB		J1	UNIT22	Memory PCB	
J905	UNIT16	Main Controller PCB		J1	UNIT21	Serial Number PCB	
J932	UNIT16	Main Controller PCB		J932	SP1	Speaker	MF515x/ MF515dw
J904	UNIT16	Main Controller PCB		J972	UNIT20	USB PCB	
J971	UNIT20	USB PCB		-	-	-	USB Port (F)
J920	UNIT16	Main Controller PCB		J691	UNIT15	All-night Power Supply PCB	
J919	UNIT16	Main Controller PCB		J1211	UNIT14	AC Relay PCB	
J909	UNIT16	Main Controller PCB		J1	UNIT24	eMMC PCB	
J925	UNIT16	Main Controller PCB		J951	UNIT25	Control Panel PCB	
J953	UNIT25	Control Panel PCB		J1	DSP1	LCD	
J954	UNIT25	Control Panel PCB		J1	UNIT26	Touch Panel	
J956	UNIT25	Control Panel PCB		-	-	-	
J926	UNIT16	Main Controller PCB		J1302	PS10	Document Sensor	
J926	UNIT16	Main Controller PCB	J1310	J1312	PS9	Document End Sensor	
J926	UNIT16	Main Controller PCB	J1303	J1303	SL3	ADF Delivery Sorenoid	
J926	UNIT16	Main Controller PCB		J1301	M5	ADF Motor	
J928	UNIT16	Main Controller PCB		J16	UNIT27	Contact Image Sensor	
J927	UNIT16	Main Controller PCB		J1502	PS8	CIS HP Sensor	
J927	UNIT16	Main Controller PCB	J1501	J1501	M4	Scanner Motor	
J906	UNIT16	Main Controller PCB		-	-	-	USB Port (H)
J910	UNIT16	Main Controller PCB		-	-	-	USB Port (D)
J911	UNIT16	Main Controller PCB		-	-	-	LAN Port

Disassembled Parts


External Cover System




Key No.	Name	Remarks	Reference
[1]	Multi-purpose Tray		
[2]	Cassette		
[3]	Left Cover		"Removing the Left Cover" on page 115
[4]	ADF Front Cover		
[5]	ADF Front Upper Cover		
[6]	ADF Rear Cover		
[7]	Feeder Cover		
[8]	Side Guide		
[9]	Document Tray		
[10]	ADF Frame		
[11]	Control Panel Unit		" Removing the Control Panel Unit" on page 156




Key No.	Name	Remarks	Reference
[1]	Upper Cover		"Removing the Upper Cover" on page 124
[2]	Right Cover		" Removing the Right Cover" on page 115
[3]	Right Lower Cover		" Removing the Right Lower Cover" on page 123
[4]	Right Front Inner Cover		" Removing the Right Front Inner Cover" on page 122
[5]	Front Cover Switch		
[6]	Delivery Auxiliary Tray		
[7]	Front Cover		"Removing the Front Cover Unit" on page 121



Key No.	Name	Remarks	Reference
[1]	Reader Upper Cover		
[2]	Reader Frame		




Key No.	Name	Remarks	Reference
[1]	Rear Cover Unit		"Removing the Rear Cover Unit" on page 118
[2]	Rear Lower Cover		
[3]	Rear Right Cover		"Removing the Rear Right Cover" on page 119
[4]	Face Cover		




Key No.	Name	Remarks	Reference
[1]	USB Port (F)		
[2]	Power Switch		"Removing the Power Switch" on page 139
[3]	USB Port (H)		
[4]	USB Port (D)		
[5]	LAN Port		
[6]	Handset Terminal		
[7]	External Telephone Terminal		
[8]	Telephone Line Terminal		
[9]	Power Socket		

Original Exposure/Feed System




Key No.	Name	Remarks	Reference
[1]	ADF Unit		"Removing the ADF + Reader Unit" on page 126
[2]	ADF Roller Unit		"Removing the ADF Roller Unit" on page 127
[3]	ADF Pickup Roller		"Removing the ADF Pickup Roller" on page 128
[4]	ADF Separation Roller		"Removing the ADF Separation Roller" on page 128
[5]	ADF Separation Pad		"Removing the ADF Separation Pad" on page 129
[6]	ADF Pickup Feed Unit		"Removing the ADF Pickup Feed Unit" on page 130
[7]	ADF Pickup Motor Unit		"Removing the ADF Pickup Motor Unit" on page 131
[8]	ADF Pickup Feed Solenoid Unit		"Removing the ADF Delivery Solenoid Unit" on page 132
[9]	Reader Unit		"Removing the ADF + Reader Unit" on page 126
[10]	Reader Unit Upper Cover		"Removing the Reader Unit Upper Cover" on page 132
[11]	CIS Unit		"Removing the CIS Unit" on page 133

Controller System




Key No.	Name	Remarks	Reference
[1]	High Voltage Power Supply Unit		"Removing the High Voltage Power Supply Unit" on page 152
[2]	Engine Controller PCB		"Removing the Engine Controller Unit" on page 141
[3]	Control Panel Unit		"Removing the Control Panel Unit" on page 156
[4]	Cartridge Door Switch		"Removing the Cartridge Door Switch" on page 140
[5]	Main Controller PCB		"Removing the Main Controller PCB" on page 135
[6]	Wireless LAN PCB		"Removing the Wireless LAN PCB (except for D1520/MF412dn)" on page 135
[7]	OFF Hook PCB	MF515x/ MF515dw	"Removing the OFF Hook PCB (MF515x/MF515dw)" on page 137

Key No.	Name	Remarks	Reference
[8]	Speaker	MF515x/ MF515dw	"Removing the Speaker (MF515x/MF515dw)" on page 137
[9]	USB PCB		"Removing the USB PCB" on page 155
[10]	Environment Sensor		"Removing the Environment Sensor" on page 140
[11]	Multi-purpose Tray Pickup Solenoid		"Removing the Multi-purpose Tray Pickup Solenoid" on page 149
[12]	Cassette Sensing Switch		"Removing the Cassette Sensing Switch" on page 140
[13]	Cassette Pickup Solenoid		"Removing the Cassette Pickup Solenoid" on page 150
[14]	Low-voltage Power Supply PCB		"Removing the All-night Power Supply PCB" on page 138
[15]	AC Relay PCB		"Removing the AC Relay PCB" on page 138
[16]	Power Switch		"Removing the Power Switch" on page 139
[17]	All-night Power Supply PCB	Only for 230V	"Removing the Arrestor PCB (230 V only)" on page 137
[18]	FAX PCB	MF515x/ MF515dw	"Removing the Fax PCB (MF515x/MF515dw)" on page 136
[19]	PCB Unit		"Removing the PCB Unit" on page 138




Key No.	Name	Remarks	Reference
[20]	Fixing Motor		"Removing the Fixing Motor" on page 146
[21]	Control Panel PCB		"Removing the Control Panel Unit" on page 156
[22]	Main Fan		"Removing the Main Fan" on page 141
[23]	Main Motor		"Removing the Main Motor" on page 144
[24]	Sub Fan		"Removing the Sub Fan" on page 147

Laser Exposure System




Key No.	Name	Remarks	Reference
[1]	Laser Scanner Unit		"Removing the Laser Scanner Unit" on page 159

Image Formation System




Key No.	Name	Remarks	Reference
[1]	Transfer Roller		"Removing the Transfer Roller" on page 160
[2]	Registration Unit		"Removing the Registration Unit" on page 160

Fixing System



Key No.	Name	Remarks	Reference
[1]	Fixing Assembly		"Removing the Fixing Assembly" on page 161

Pickup Feed System




Key No.	Name	Remarks	Reference
[1]	Duplex Feed Unit		"Removing the Duplex Feed Unit" on page 164
[2]	Multi-purpose Tray Pickup Roller		"Removing the Multi-purpose Tray Pickup Roller" on page 162
[3]	Pickup Unit		"Removing the Pickup Unit" on page 165
[4]	Multi-purpose Tray Separation Pad		"Removing the Cassette Separation Pad" on page 162
[5]	Cassette Pickup Roller Unit		"Removing the Cassette Pickup Roller Unit" on page 162
[6]	Cassette Separation Pad		"Removing the Cassette Separation Pad" on page 164

External Cover System


Removing the Right Cover

■ Procedure

1. Open the ADF [1].




2. Remove the Right Cover [1] by sliding it.
 - 2 Screws [2]
 - 11 Hooks [3]




Removing the Left Cover

■ Procedure


1. Remove the cassette [1].





2. Open the Front Cover [1] and the ADF + Reader Unit [2].



3. Open the Rear Cover Unit [1].





4. Remove the claw [1], and remove the Arm Cover [2].




5. Disconnect the arm [1], and turn it to the rear side.

CAUTION:


When opening/closing the ADF+Reader Unit after releasing the arm, be sure to perform the work while supporting the ADF+Reader Unit. Be careful not to get your hand caught.




6. Extend the Rear Cover [1], and remove the 2 screws [2] from the Left Cover.



7. Open the ADF + Reader Unit, and release the 3 claws [1].




8. Release the 2 claws [1], and remove the boss [2].




9. Remove the Left Cover [1].

- 3 Hooks [2]



NOTE:


The following shows the claws [1] of the Left Cover and the hooks [2].





Removing the Rear Cover Unit

■ Procedure




1. Remove the cassette [1].




2. Open the Rear Cover Unit [1], and remove the Link Arm [2].




3. Remove the 2 stoppers [1] of the Rear Cover, and further open the Rear Cover Unit.




4. Remove the screw (TP) [1] and the screw (Tapping) [2].



6. Remove the Rear Cover Unit [1].
• 2 Hooks [2]



5. Open the Rear Lower Cover [1], and release the 2 claws [2].




Removing the Rear Right Cover

■ Preparation

1. Remove the Right Cover. “[Removing the Right Cover](#)” on page 115
2. Remove the Rear Cover Unit. “[Removing the Rear Cover Unit](#)” on page 118


■ Procedure

1. Remove the Face Cover [1].
• 2 Claws [2]



2. Remove the Rear Right Cover [1].

- 2 Hooks [2]
- 1 Boss [3]



Removing the Multi-purpose Tray Auxiliary Tray Unit


■ Procedure

1. Open the Multi-purpose Tray Auxiliary Tray Unit [1] and release the 2 Hinge Arms [2].




2. Remove the Multi-purpose Tray Auxiliary Tray Unit [1].

- 4 Shafts [2]





■ Procedure

1. While holding the Multi-purpose Tray [1], close the Front Cover Unit [2].



2. Remove the Hinge Arm Holder [1].

- 1 Screw [2]




● Removing the Front Cover Unit

■ Preparation

1. Remove the Left Cover. "Removing the Left Cover" on page 115
2. Remove the Multi-purpose Tray Auxiliary Tray Unit. "Removing the Multi-purpose Tray Auxiliary Tray Unit" on page 120


3. Release the Hinge Arm [1] from the Link Arm [2].

- 2 Claws [3]



4. Remove the Front Cover Unit [1] by opening it.

- 1 Hinge Arm [2]
- 4 Protrusions [3]




Removing the Right Front Inner Cover

■ Preparation

1. Remove the Multi-purpose Tray Auxiliary Tray Unit. "Removing the Multi-purpose Tray Auxiliary Tray Unit" on page 120
2. Remove the Right Cover. "Removing the Right Cover" on page 115


■ Procedure

1. Remove the cassette [1].
2. Open the Front Cover Unit [2].



3. Remove the Right Front Inner Cover [1] by lifting its lower part.


- 3 Screws (TP) [2]
- 1 Screw (Tapping) [3]
- 2 Protrusions [4]



■ Procedure

1. Remove the Switch Unit [1].

- 1 Screw [2]
- 2 Claws [3]



2. Place the host machine [1] while shifting its right side approx. 10cm from the working table to release the claw on the lower side of the Right Lower Cover.

CAUTION:

Be careful not to drop the host machine when shifting it.




● Removing the Right Lower Cover

■ Preparation

1. Remove the Right Cover. “[Removing the Right Cover](#)” on page 115

3. Remove the Right Lower Cover [1].


- 6 Holes [2]
- 6 Hooks [3]



■ Procedure

1. Free the harness of the speaker and the harness of the USB PCB.

- 2 Connectors [1]
- 2 Harness Guides [2]




● Removing the Upper Cover

■ Preparation


1. Remove the Right Cover. “[Removing the Right Cover](#)” on page 115
2. Remove the Left Cover. “[Removing the Left Cover](#)” on page 115
3. Remove the Multi-purpose Tray Auxiliary Tray Unit. “[Removing the Multi-purpose Tray Auxiliary Tray Unit](#)” on page 120
4. Remove the Right Front Inner Cover. “[Removing the Right Front Inner Cover](#)” on page 122
5. Remove the ADF + Reader Unit. “[Removing the ADF + Reader Unit](#)” on page 126

2. Remove the 3 screws (TP) [1] and the screw (Tapping) [2].



3. Remove the Upper Cover [1].

- 2 Claws [2]
- 2 Hooks [3]



Original Exposure/Feed System

Removing the ADF + Reader Unit


Preparation

1. Remove the Right Cover. “Removing the Right Cover” on page 115


Procedure

1. Disconnect the harnesses from the Main Controller PCB.


- 2 Flat Cables [1]
- 2 Connectors [2]
- 2 Grounding Wires [3]
- 2 Screws [4]



2. Free the harnesses from the Harness Guide [A].
 - 1 Ferrite Core [1]




3. Lift the ADF + Reader Unit [1] in the direction of the arrow and remove them.



Removing the ADF Roller Unit


Procedure

1. Open the ADF Upper Cover [1].




2. Remove the gear [1] and the bushing [2].

- 1 Claw [3]




3. Remove the resin E-ring [1].


- 1 Bushing [2]



4. Remove the resin E-ring [1] and the bushing [2].




5. Remove the ADF Roller Unit [1].



CAUTION:

When removing the ADF Roller Unit, be careful not to lose the spring [1] on the back side.



Removing the ADF Pickup Roller

Preparation


1. Remove the ADF Roller Unit. "Removing the ADF Roller Unit" on page 127

Procedure


CAUTION:

Do not touch the surface of the roller or pad.

1. Remove the Pickup Roller [1] with the shaft using a flat-blade screwdriver.



2. Remove the ADF Pickup Roller [1].



Removing the ADF Separation Roller

Preparation

1. Remove the ADF Roller Unit. "Removing the ADF Roller Unit" on page 127

Procedure


CAUTION:

Do not touch the surface of the roller or pad.


1. Remove the bushing [1].



2. Remove the 2 resin E-rings [1].




3. Pull out the Roller Shaft [1] in the direction of the arrow, and remove the Parallel Pin [2] and the bushing [3].




CAUTION:

Do not lose the Parallel Pin as it is a small part.

4. Rotate the shaft [1] in the direction of the arrow, and pull it out by aligning the hole of the Roller Holder with the protrusion [2].



5. Remove the ADF Separation Roller [1].




● Removing the ADF Separation Pad

■ Procedure

CAUTION:




Do not touch the surface of the roller or pad.

1. Open the ADF Upper Cover [1].




2. Remove the Feed Guide [1].

- 2 Bosses [2]




3. Remove the Retainer Plate [1] from the back side of the Feed Guide.




- 2 Screws [2]
- 2 Protrusions [3] of the Separation Pad Holder



4. Remove the Separation Pad Holder [1].




3. Slightly lift the ADF Tray [1], release the claw [2], lift the tray to the angle of 90 degrees, and then remove it.



● Removing the ADF Pickup Feed Unit


■ Procedure

1. Open the ADF Upper Cover [1].




2. Remove the ADF Front Cover [1].

- 4 Claws [2]




4. Remove the ADF Rear Cover [1].

- 1 Boss [2]
- 4 Claws [3]




5. Disconnect the Grounding Wire [1].

- 1 Screw [2]




6. Free the harness [1].

- 4 Connectors [2]
- 2 Wire Saddles [3]




7. Remove the ADF Pickup Feed Unit [1].

- 5 Screws [2]



8. Remove the ADF Upper Cover Unit [1].

- 2 Bosses [2]




Removing the ADF Pickup Motor Unit

■ Preparation

1. Remove the ADF Pickup Feed Unit. [“Removing the ADF Pickup Feed Unit” on page 130](#)


■ Procedure

1. Remove the Harness Guide [1] from the Edge Saddle [2].




2. Remove the ADF Motor Unit [1].

- 2 Screws [2]



CAUTION:

The gear [1] of the ADF Motor Unit and the gear [2] on the frame of the Pickup Feed Unit are not secured in place, so be careful not to lose them.




● Removing the ADF Delivery Solenoid Unit

■ Preparation

1. Remove the ADF Pickup Feed Unit. [“Removing the ADF Pickup Feed Unit” on page 130](#)


■ Procedure

1. Remove the E-ring [1].



2. Remove the ADF Pickup Feed Solenoid Unit [1].

- 2 Screws [2]




● Removing the Reader Unit Upper Cover

■ Preparation

1. Remove the Right Cover. [“Removing the Right Cover” on page 115](#)


■ Procedure

1. Remove the 2 screws [1] from the bottom of the Reader Unit.



2. Remove the Reader Unit Upper Cover [1].

- 2 Screws [2]
- 7 Claws [3]



● Removing the CIS Unit


■ Preparation

1. Remove the Right Cover. “[Removing the Right Cover](#)” on page 115


■ Procedure

1. Remove the Drive Pulley [1].

- 1 Claw [2]




2. Remove the CIS Mount [1] in the direction of the arrow, and disconnect the Flat Cable [2].




CAUTION:

When removing the CIS Mount, be careful not to lose the CIS Spacer [1].



3. Lift the CIS Unit [1], and remove it in the direction of the arrow.



Controller System

Removing the Main Controller PCB

Preparation

CAUTION:

Actions before Replacement:

- “Actions before Replacement” on page 181

Actions after Replacement:


- “After replacing main controller PCB” on page 182

1. Remove the Right Cover. “Removing the Right Cover” on page 115

Procedure


1. Disconnect the Flat Cables, the connectors, and the Grounding Wire from the Main Controller PCB.

- 8 Connectors [1]
- 2 Connectors [A] (MF515x/MF515dw)
- 1 Connector [B] (EUR only)
- 4 Flat Cables [2]
- 1 Flat Cable [C] (MF515x/MF515dw)
- 2 Screws [3]




2. Remove the Main Controller PCB [1].

- 6 Screws (W Sems) [2]
- 2 Screws (Binding) [3]



CAUTION:

Do not remove the eMMC PCB.



Removing the Wireless LAN PCB (except for D1520/MF412dn)


Preparation

1. Remove the Right Cover. “Removing the Right Cover” on page 115

■ Procedure

1. Remove the Wireless LAN PCB [1].

- 1 Screw [2]
- 1 Hook [3]
- 1 Flat Cable [4]



● Removing the Fax PCB (MF515x/MF515dw)


■ Preparation

1. Remove the Right Cover. “[Removing the Right Cover](#)” on page 115

■ Procedure


1. Disconnect the Flat Cable [1], and free the harness from the Harness [A].

- 2 Connectors [2]
- 1 Connector [B] (EUR only)




2. Remove the Harness Guide [1] from the Fax PCB.

- 3 Hooks [2]



3. Remove the Fax PCB [1].

- 3 Screws (W Sems) [2]
- 1 Screw (Tapping) [3]




Removing the OFF Hook PCB (MF515x/MF515dw)

Preparation

1. Remove the Right Cover. “ Removing the Right Cover” on page 115

Procedure

1. Remove the OFF Hook PCB [1].
 - 2 Connectors [2]
 - 2 Screws [3]
 - 1 Hook [4]




Removing the Speaker (MF515x/MF515dw)

Preparation

1. Remove the Right Cover. “ Removing the Right Cover” on page 115

Procedure

1. Remove the Speaker [1].
 - 2 Claws [2]
 - 1 Connector [3]
 - 1 Harness Guide [4]




Removing the Arrestor PCB (230 V only)

Preparation

1. Remove the Right Cover. “ Removing the Right Cover” on page 115

Procedure

1. Remove the Arrestor PCB [1].
 - 2 Connectors [2]
 - 1 Screw (W Sems) [3]
 - 2 Screws (Tapping) [4]
 - 1 Hook [5]




Removing the AC Relay PCB

Preparation


1. Remove the Right Cover. “ Removing the Right Cover” on page 115

Procedure

1. Free the Flat Cable [1], and remove the harness from the harness guide [A].
 - 2 Connectors [2]
 - 1 Connector [B] (EUR only)



2. Remove the AC Relay PCB [1].
 - 3 Connectors [2]
 - 2 Screws [3]
 - 1 Hook [4]




Removing the All-night Power Supply PCB

Preparation

1. Remove the Right Cover. “ Removing the Right Cover” on page 115

Procedure

1. Remove the All-night Power Supply PCB [1].
 - 2 Connectors [2]
 - 3 Screws [3]
 - 3 Hooks [4]



Removing the PCB Unit


Preparation

1. Remove the Right Cover. “ Removing the Right Cover” on page 115

■ Procedure


1. Remove the harness [1] between the Memory PCB and the Serial Number PCB.

- 2 Connectors [2]
- 1 Harness Guide [3]
- 1 Wire Saddle [4]



2. Remove the PCB Unit [1].

- 1 Screw (black TP) [2]
- 1 Screw (Tapping) [3]
- 2 Hooks [4]



● Removing the Power Switch


■ Preparation

1. Remove the Right Cover. "Removing the Right Cover" on page 115

■ Procedure



1. Disconnect the connector of the Power Switch.

- 1 Connector [1]
- 1 Connector [A] (230 V)
- 1 Connector [B] (120 V)
- 1 Connector [C] (EUR only)



2. Remove the Power Switch [1].

- 1 Screw [2]
- 2 Claws [3]




Removing the Cartridge Door Switch

Preparation

1. Remove the Right Cover. “Removing the Right Cover” on page 115
2. Remove the Multi-purpose Tray Auxiliary Tray Unit. “Removing the Multi-purpose Tray Auxiliary Tray Unit” on page 120
3. Remove the Right Front Inner Cover. “Removing the Right Front Inner Cover” on page 122

Procedure

1. Remove the Cartridge Door Switch [1].
 - 2 Fasten Terminals [2]
 - 2 Claws [3]



Removing the Cassette Sensing Switch


Preparation

1. Remove the Right Cover. “Removing the Right Cover” on page 115
2. Remove the Multi-purpose Tray Auxiliary Tray Unit. “Removing the Multi-purpose Tray Auxiliary Tray Unit” on page 120

3. Remove the Right Front Inner Cover. “Removing the Right Front Inner Cover” on page 122
4. Remove the PCB Unit. “Removing the PCB Unit” on page 138

Procedure

1. Remove the Cassette Sensing Switch [1].
 - 1 Connector [2]
 - 1 Harness Guide [3]
 - 1 Claw [4]



Removing the Environment Sensor




Preparation

1. Remove the Right Cover. “Removing the Right Cover” on page 115
2. Remove the Multi-purpose Tray Auxiliary Tray Unit. “Removing the Multi-purpose Tray Auxiliary Tray Unit” on page 120
3. Remove the Right Front Inner Cover. “Removing the Right Front Inner Cover” on page 122
4. Remove the PCB Unit. “Removing the PCB Unit” on page 138

■ Procedure

1. Remove the Environment Sensor [1].

- 1 Connector [2]
- 1 Harness Guide [3]
- 1 Claw [4]



● Removing the Main Fan

■ Preparation

1. Remove the Right Cover. “Removing the Right Cover” on page 115
2. Remove the Multi-purpose Tray Auxiliary Tray Unit. “Removing the Multi-purpose Tray Auxiliary Tray Unit” on page 120
3. Remove the Right Front Inner Cover. “Removing the Right Front Inner Cover” on page 122


4. Remove the PCB Unit. “Removing the PCB Unit” on page 138

5. Remove the Environment Sensor. “Removing the Environment Sensor” on page 140

■ Procedure


1. Remove the Main Fan [1].

- 1 Connector [2]
- 3 Claws [3]



CAUTION:

When installing the Main Fan, be sure that the label [1] of the fan comes to the inside and the harness [2] comes to the lower left.



● Removing the Engine Controller Unit

■ Preparation

CAUTION:

Actions after Replacement:
When the Engine Controller PCB has been replaced with a new one, the firmware needs to be installed again.


1. Remove the Right Cover. “Removing the Right Cover” on page 115

2. Remove the Left Cover. “Removing the Left Cover” on page 115
3. Remove the Multi-purpose Tray Auxiliary Tray Unit. “Removing the Multi-purpose Tray Auxiliary Tray Unit” on page 120
4. Remove the Right Front Inner Cover. “Removing the Right Front Inner Cover” on page 122
5. Remove the Right Lower Cover. “Removing the Right Lower Cover” on page 123
6. Remove the Rear Cover Unit. “Removing the Rear Cover Unit” on page 118
7. Remove the Rear Right Cover. “Removing the Rear Right Cover” on page 119
8. Remove the ADF + Reader Unit. “Removing the ADF + Reader Unit” on page 126
9. Remove the Upper Cover. “Removing the Upper Cover” on page 124
10. Remove the Main Controller PCB. “Removing the Main Controller PCB” on page 135
11. Remove the Wireless LAN PCB. “Removing the Wireless LAN PCB (except for D1520/MF412dn)” on page 135
12. Remove the Fax PCB. (MF515x/MF515dw)
“Removing the Fax PCB (MF515x/MF515dw)” on page 136
13. Remove the OFF Hook PCB. (MF515x/MF515dw)
“Removing the OFF Hook PCB (MF515x/MF515dw)” on page 137
14. Remove the Arrestor PCB. (230V only) “Removing the Arrestor PCB (230 V only)” on page 137
15. Remove the AC Relay PCB. “Removing the AC Relay PCB” on page 138
16. Remove the All-night Power Supply PCB.
“Removing the All-night Power Supply PCB” on page 138
17. Remove the PCB Unit. “Removing the PCB Unit” on page 138
18. Remove the Power Switch. “Removing the Power Switch” on page 139

■ Procedure


1. Remove the 5 Harness Guides.

- Harness Guide [1], 1 Claw [6], 1 Hook [7]
- Harness Guide [2], 1 Claw [6], 2 Hooks [7]
- Harness Guide [3], 1 Claw [6], 2 Hooks [7]
- Harness Guide [4], 1 Boss [8], 2 Hooks [7]
- Harness Guide [5], 1 Screw (W Sems) [9], 2 Hooks [7]




2. Remove the Main Fan Unit [1].

- 2 Connectors [2]
- Harness Guide [A]
- Harness Guide [B]
- 1 Screw (TP) [3]
- 1 Screw (Tapping) [4]




3. Remove the PCB Mounting Plate [1].

- 1 Wire Saddle [2]
- 2 Screws (black) [3]





4. Remove the Scanner Cover [1].

- 1 Claw [2]
- 1 Hook [3]




5. Disconnect the Flat Cable [1] and 3 connectors [2], and remove the 2 Harness Guides [3] and 3 screws (black) [4].




6. Remove the plate [1].


- 1 Screw [2]
- 2 Hooks [3]

**7. Open the Engine Controller PCB [1].**


- 11 Connectors [2]
- 2 Fasten Terminals [3]
- 1 Harness Guide [A]
- 1 Harness Guide [B]
- 3 Screws (black) [4]
- 1 Boss [5]
- 3 Hooks [6]

**8. Remove the Engine Controller PCB [1].**

- 3 Flat Cables [2]
- 1 Harness Guide [A]
- 1 Harness Guide [B]

**CAUTION:**

When installing the Laser Scanner Flat Cable [1], be sure to install it to the connector [2], Guide [3], hole [4] on the Right Side Plate, and Ferrite Core [5], in that order.



● Removing the Main Motor

■ Preparation


1. Remove the Right Cover. “[Removing the Right Cover](#)” on page 115
2. Remove the Left Cover. “[Removing the Left Cover](#)” on page 115
3. Remove the Multi-purpose Tray Auxiliary Tray Unit. “[Removing the Multi-purpose Tray Auxiliary Tray Unit](#)” on page 120
4. Remove the Right Front Inner Cover. “[Removing the Right Front Inner Cover](#)” on page 122

5. Remove the Right Lower Cover. “Removing the Right Lower Cover” on page 123
6. Remove the Rear Cover Unit. “Removing the Rear Cover Unit” on page 118
7. Remove the Rear Right Cover. “Removing the Rear Right Cover” on page 119
8. Remove the ADF + Reader Unit. “Removing the ADF + Reader Unit” on page 126
9. Remove the Upper Cover. “Removing the Upper Cover” on page 124
10. Remove the Main Controller PCB. “Removing the Main Controller PCB” on page 135
11. Remove the Wireless LAN PCB. “Removing the Wireless LAN PCB (except for D1520/MF412dn)” on page 135
12. Remove the Fax PCB. (MF515x/MF515dw)
“Removing the Fax PCB (MF515x/MF515dw)” on page 136
13. Remove the OFF Hook PCB. (MF515x/MF515dw)
“Removing the OFF Hook PCB (MF515x/MF515dw)” on page 137
14. Remove the Arrestor PCB. (230V only) “Removing the Arrestor PCB (230 V only)” on page 137
15. Remove the AC Relay PCB. “Removing the AC Relay PCB” on page 138
16. Remove the All-night Power Supply PCB.
“Removing the All-night Power Supply PCB” on page 138
17. Remove the PCB Unit. “Removing the PCB Unit” on page 138
18. Remove the Power Switch. “Removing the Power Switch” on page 139
19. Remove the Engine Controller PCB. “Removing the Engine Controller Unit” on page 141

■ Procedure


1. Remove the Gear Cover [1].

- 3 Harness Guides [A]
- 3 Screws [2]




CAUTION:

- When assembling the Gear Cover, be sure to align the shaft with the 5 Shaft Holes [2] of the Gear Cover [1].
- When assembling the Gear Cover, be sure to route the harness [3] of the Multi-purpose Tray Pickup Solenoid around the guide section of the Gear Cover [1] one and a half times in a clockwise direction.




2. Move the Harness Guide [1] to the left.


- 1 Harness Guide [2]
- 1 Claw [3]

**3. Remove the Main Gear Cover [1].**


- 4 Screws [2]
- 1 Edge Saddle [3]

**4. Remove the Main Gear [1].**


- 1 Parallel Pin [2]

5. Remove the gear [3].**6. Remove the Main Motor Unit [1].**

- 1 Gear [2]
- 6 Screws [3]

**7. Remove the Main Motor [1] from the Main Motor Unit.**

- 1 Edge Saddle [2]
- 1 Connector [3]
- 3 Screws [4]



● Removing the Fixing Motor

■ Preparation


1. Remove the Right Cover. "[Removing the Right Cover](#)" on page 115
2. Remove the Left Cover. "[Removing the Left Cover](#)" on page 115
3. Remove the Multi-purpose Tray Auxiliary Tray Unit. "[Removing the Multi-purpose Tray Auxiliary Tray Unit](#)" on page 120
4. Remove the Right Front Inner Cover. "[Removing the Right Front Inner Cover](#)" on page 122
5. Remove the Right Lower Cover. "[Removing the Right Lower Cover](#)" on page 123
6. Remove the Rear Cover Unit. "[Removing the Rear Cover Unit](#)" on page 118

7. Remove the Rear Right Cover. “Removing the Rear Right Cover” on page 119
8. Remove the ADF + Reader Unit. “Removing the ADF + Reader Unit” on page 126
9. Remove the Upper Cover. “Removing the Upper Cover” on page 124
10. Remove the Main Controller PCB. “Removing the Main Controller PCB” on page 135
11. Remove the Wireless LAN PCB. “Removing the Wireless LAN PCB (except for D1520/MF412dn)” on page 135
12. Remove the Fax PCB. (MF515x/MF515dw)
“Removing the Fax PCB (MF515x/MF515dw)” on page 136
13. Remove the OFF Hook PCB. (MF515x/MF515dw)
“Removing the OFF Hook PCB (MF515x/MF515dw)” on page 137
14. Remove the Arrestor PCB. (230 V only) “Removing the Arrestor PCB (230 V only)” on page 137
15. Remove the AC Relay PCB. “Removing the AC Relay PCB” on page 138
16. Remove the All-night Power Supply PCB.
“Removing the All-night Power Supply PCB” on page 138
17. Remove the PCB Unit. “Removing the PCB Unit” on page 138
18. Remove the Power Switch. “Removing the Power Switch” on page 139
19. Remove the Engine Controller PCB. “Removing the Engine Controller Unit” on page 141

■ Procedure

1. Remove the Fixing Motor [1].

- 1 Connector [2]
- 3 Screws [3]



● Removing the Sub Fan


■ Preparation

1. Remove the Right Cover. “Removing the Right Cover” on page 115
2. Remove the Left Cover. “Removing the Left Cover” on page 115
3. Remove the Multi-purpose Tray Auxiliary Tray Unit.
“Removing the Multi-purpose Tray Auxiliary Tray Unit” on page 120
4. Remove the Right Front Inner Cover. “Removing the Right Front Inner Cover” on page 122
5. Remove the Right Lower Cover. “Removing the Right Lower Cover” on page 123
6. Remove the Rear Cover Unit. “Removing the Rear Cover Unit” on page 118
7. Remove the Rear Right Cover. “Removing the Rear Right Cover” on page 119
8. Remove the ADF + Reader Unit. “Removing the ADF + Reader Unit” on page 126
9. Remove the Upper Cover. “Removing the Upper Cover” on page 124
10. Remove the Main Controller PCB. “Removing the Main Controller PCB” on page 135
11. Remove the Wireless LAN PCB. “Removing the Wireless LAN PCB (except for D1520/MF412dn)” on page 135
12. Remove the Fax PCB. (MF515x/ MF515dw)
“Removing the Fax PCB (MF515x/MF515dw)” on page 136
13. Remove the OFF Hook PCB. (MF515x/ MF515dw)
“Removing the OFF Hook PCB (MF515x/MF515dw)” on page 137
14. Remove the Arrestor PCB. (230 V only) “Removing the Arrestor PCB (230 V only)” on page 137
15. Remove the AC Relay PCB. “Removing the AC Relay PCB” on page 138
16. Remove the All-night Power Supply PCB.
“Removing the All-night Power Supply PCB” on page 138
17. Remove the PCB Unit. “Removing the PCB Unit” on page 138
18. Remove the Power Switch. “Removing the Power Switch” on page 139
19. Remove the Engine Controller PCB. “Removing the Engine Controller Unit” on page 141



■ Procedure

1. Remove the Scanner Duct [1].


- 1 Claw [2]
- 1 Hook [3]



2. Disconnect the connector [1] of the Sub Fan from the Relay Connector.






3. Pass the connector [1] of the Sub Fan through the hole [A] of the Right Side Plate.




4. Free the harness [1] of the Sub Fan, and pass it through the hole [B] of the Left Side Plate.


- 3 Wire Saddles [2]
- 5 Harness Guides [3]



5. Free the harness [1] of the Sub Fan from the Harness Guide [A].




6. Loosen the screw [1] on the left side, and remove the Fan Rod [2].




7. Remove the Sub Fan [1].

- 2 Claws [2]



CAUTION:

When assembling the Sub Fan, be sure that the label [1] of the fan comes to the inside and the harness [2] comes to the upper right.



Removing the Multi-purpose Tray Pickup Solenoid

■ Preparation


1. Remove the Right Cover. “Removing the Right Cover” on page 115
2. Remove the Left Cover. “Removing the Left Cover” on page 115
3. Remove the Multi-purpose Tray Auxiliary Tray Unit. “Removing the Multi-purpose Tray Auxiliary Tray Unit” on page 120
4. Remove the Right Front Inner Cover. “Removing the Right Front Inner Cover” on page 122
5. Remove the Right Lower Cover. “Removing the Right Lower Cover” on page 123
6. Remove the Rear Cover Unit. “Removing the Rear Cover Unit” on page 118
7. Remove the Rear Right Cover. “Removing the Rear Right Cover” on page 119
8. Remove the ADF + Reader Unit. “Removing the ADF + Reader Unit” on page 126
9. Remove the Upper Cover. “Removing the Upper Cover” on page 124
10. Remove the Main Controller PCB. “Removing the Main Controller PCB” on page 135
11. Remove the Wireless LAN PCB. “Removing the Wireless LAN PCB (except for D1520/MF412dn)” on page 135
12. Remove the Fax PCB. (MF515x/MF515dw) “Removing the Fax PCB (MF515x/MF515dw)” on page 136

13. Remove the OFF Hook PCB. (MF515x/MF515dw)
“Removing the OFF Hook PCB (MF515x/MF515dw)”
on page 137
14. Remove the Arrestor PCB. (230 V only) “ Removing
the Arrestor PCB (230 V only)” on page 137
15. Remove the AC Relay PCB.“Removing the AC Relay
PCB” on page 138
16. Remove the All-night Power Supply PCB.
“ Removing the All-night Power Supply PCB” on
page 138
17. Remove the PCB Unit. “Removing the PCB Unit” on
page 138
18. Remove the Power Switch.“ Removing the Power
Switch” on page 139
19. Remove the Engine Controller PCB.“Removing the
Engine Controller Unit” on page 141

■ Procedure


1. Remove the Gear Cover [1].

- 3 Harness Guides [A]
- 3 Screws [2]




CAUTION:

- When assembling the Gear Cover, be sure to align the shaft with the 5 Shaft Holes [2] of the Gear Cover [1].
- When assembling the Gear Cover, be sure to route the harness [3] of the Multi-purpose Tray Pickup Solenoid around the guide section of the Gear Cover [1] one and a half times in a clockwise direction.



2. Remove the Multi-purpose Tray Pickup Solenoid [1].

- 1 Screw [2]



● Removing the Cassette Pickup Solenoid

■ Preparation


1. Remove the Right Cover. “ Removing the Right
Cover” on page 115
2. Remove the Left Cover. “Removing the Left Cover”
on page 115
3. Remove the Multi-purpose Tray Auxiliary Tray Unit.
“ Removing the Multi-purpose Tray Auxiliary Tray
Unit” on page 120
4. Remove the Right Front Inner Cover. “ Removing the
Right Front Inner Cover” on page 122

5. Remove the Right Lower Cover. “Removing the Right Lower Cover” on page 123
6. Remove the Rear Cover Unit. “Removing the Rear Cover Unit” on page 118
7. Remove the Rear Right Cover. “Removing the Rear Right Cover” on page 119
8. Remove the ADF + Reader Unit. “Removing the ADF + Reader Unit” on page 126
9. Remove the Upper Cover. “Removing the Upper Cover” on page 124
10. Remove the Main Controller PCB. “Removing the Main Controller PCB” on page 135
11. Remove the Wireless LAN PCB. “Removing the Wireless LAN PCB (except for D1520/MF412dn)” on page 135
12. Remove the Fax PCB. (MF515x/ MF515dw)
“Removing the Fax PCB (MF515x/MF515dw)” on page 136
13. Remove the OFF Hook PCB. (MF515x/ MF515dw)
“Removing the OFF Hook PCB (MF515x/MF515dw)” on page 137
14. Remove the Arrestor PCB. (230 V only) “Removing the Arrestor PCB (230 V only)” on page 137
15. Remove the AC Relay PCB. “Removing the AC Relay PCB” on page 138
16. Remove the All-night Power Supply PCB.
“Removing the All-night Power Supply PCB” on page 138
17. Remove the PCB Unit. “Removing the PCB Unit” on page 138
18. Remove the Power Switch. “Removing the Power Switch” on page 139
19. Remove the Engine Controller PCB. “Removing the Engine Controller Unit” on page 141

■ Procedure


1. Remove the Gear Cover [1].

- 3 Harness Guides [A]
- 3 Screws [2]




CAUTION:

- When assembling the Gear Cover, be sure to align the shaft with the 5 Shaft Holes [2] of the Gear Cover [1].
- When assembling the Gear Cover, be sure to route the harness [3] of the Multi-purpose Tray Pickup Solenoid around the guide section of the Gear Cover [1] one and a half times in a clockwise direction.




2. Remove the Cassette Pickup Solenoid [1].

- 1 Screw [2]

**CAUTION:**

When assembling the Cassette Pickup Solenoid, be sure to install the Fixation Plate [2] of the Pickup Solenoid under the plate [1] of the Right Side Plate.



● Removing the High Voltage Power Supply Unit

■ Preparation


1. Remove the Right Cover. “Removing the Right Cover” on page 115
2. Remove the Left Cover. “Removing the Left Cover” on page 115
3. Remove the Multi-purpose Tray Auxiliary Tray Unit. “Removing the Multi-purpose Tray Auxiliary Tray Unit” on page 120

4. Remove the Right Front Inner Cover. “Removing the Right Front Inner Cover” on page 122
5. Remove the Right Lower Cover. “Removing the Right Lower Cover” on page 123
6. Remove the Rear Cover Unit. “Removing the Rear Cover Unit” on page 118
7. Remove the Rear Right Cover. “Removing the Rear Right Cover” on page 119
8. Remove the ADF + Reader Unit. “Removing the ADF + Reader Unit” on page 126
9. Remove the Upper Cover. “Removing the Upper Cover” on page 124
10. Remove the Main Controller PCB. “Removing the Main Controller PCB” on page 135
11. Remove the Wireless LAN PCB. “Removing the Wireless LAN PCB (except for D1520/MF412dn)” on page 135
12. Remove the Fax PCB. (MF515x/MF515dw) “Removing the Fax PCB (MF515x/MF515dw)” on page 136
13. Remove the OFF Hook PCB. (MF515x/MF515dw) “Removing the OFF Hook PCB (MF515x/MF515dw)” on page 137
14. Remove the Arrestor PCB. (230 V only) “Removing the Arrestor PCB (230 V only)” on page 137
15. Remove the AC Relay PCB. “Removing the AC Relay PCB” on page 138
16. Remove the All-night Power Supply PCB. “Removing the All-night Power Supply PCB” on page 138
17. Remove the PCB Unit. “Removing the PCB Unit” on page 138
18. Remove the Power Switch. “Removing the Power Switch” on page 139
19. Remove the Engine Controller PCB. “Removing the Engine Controller Unit” on page 141
20. Remove the Fixing Assembly. “Removing the Fixing Assembly” on page 161
21. Remove the Duplex Feed Unit. “Removing the Duplex Feed Unit” on page 164
22. Remove the Sub Fan. “Removing the Sub Fan” on page 147

■ Procedure


1. Close the Front Cover Unit.

2. Remove the Fasten Terminal [1] and the 2 screws [2].




CAUTION:

When assembling, be sure to make the Fasten Terminal [1] and the Grounding Spring [2] come in contact to install.




3. Turn the machine so that it is placed with its rear side down.




4. Remove the Lower Front Reinforcing Plate [1].

- 2 Screws [2]
- 4 Hooks [3]




5. Remove the Cassette Guide [1].

- 1 Screw [2]
- 2 Hooks [3]




6. Remove the Reference Guide Unit [1].

- 2 Screws [2]





NOTE:

When assembling the Reference Guide Unit, be sure to align the shaft [1] with the Shaft Hole [2].





7. Remove the Cable Guide Plate [1].

- 2 Screws (black) [2]
- 1 Screw (silver) [3]




8. Open the High Voltage Power Supply Unit [1].

- 3 Screws [2]




9. Remove the High Voltage Power Supply Unit [1].

- 2 Connectors [2]
- 1 Fasten Terminal [3]



CAUTION:

- When disassembling/assembling the High Voltage Power Supply Unit, be careful not to lose the spring [1] on the Main Frame.
- When assembling the High Voltage Power Supply Unit, pass the Flat Cable [2] through the hole [3] on the Right Side Plate.



Removing the USB PCB


Preparation

1. Remove the Right Cover. “[Removing the Right Cover](#)” on page 115
2. Remove the Left Cover. “[Removing the Left Cover](#)” on page 115
3. Remove the Multi-purpose Tray Auxiliary Tray Unit. “[Removing the Multi-purpose Tray Auxiliary Tray Unit](#)” on page 120
4. Remove the Right Front Inner Cover. “[Removing the Right Front Inner Cover](#)” on page 122
5. Remove the Right Lower Cover. “[Removing the Right Lower Cover](#)” on page 123
6. Remove the Rear Cover Unit. “[Removing the Rear Cover Unit](#)” on page 118
7. Remove the Rear Right Cover. “[Removing the Rear Right Cover](#)” on page 119
8. Remove the ADF + Reader Unit. “[Removing the ADF + Reader Unit](#)” on page 126
9. Remove the Upper Cover. “[Removing the Upper Cover](#)” on page 124

Procedure


1. Turn the Upper Cover over, and remove the Harness Guide [1].

- 1 Screw (black TP) [2]




2. Remove the USB PCB Unit [1].

- 2 Screws (Tapping) [2]




3. Remove the USB Cover [1].




4. Remove the screw (black TP) [1] securing the Grounding Plate, and remove the USB PCB [2].

- 1 Screw (W Sems) [3]
- 1 Hook [4]



5. Remove the Grounding Plate [1].


- 2 Hooks [2]



Removing the Control Panel Unit

■ Procedure


1. Remove the 5 screws [1] from the lower side of the Reader Unit.




NOTE:

When removing the screws on the lower side of the Reader Unit, release the claw [1], and remove the Arm Cover [2].

Disconnecting the arm can make the work easier.

**2. Remove the Control Panel [1].**

- 9 Claws [2]
- 1 Flat Cable [3]
- 1 Terminal [4]



● Removing the Control Panel PCB


■ Preparation

1. Remove the Control Panel Unit. “Removing the Control Panel Unit” on page 156

■ Procedure

1. Remove the Control Panel PCB [1].

- 7 Screws [2]
- 2 Flat Cables [3]



Laser Exposure System

Removing the Laser Scanner Unit

Preparation

1. Remove the Right Cover. "Removing the Right Cover" on page 115
2. Remove the Left Cover. "Removing the Left Cover" on page 115
3. Remove the Multi-purpose Tray Auxiliary Tray Unit. "Removing the Multi-purpose Tray Auxiliary Tray Unit" on page 120
4. Remove the Right Front Inner Cover. "Removing the Right Front Inner Cover" on page 122
5. Remove the ADF + Reader Unit. "Removing the ADF + Reader Unit" on page 126
6. Remove the Upper Cover. "Removing the Upper Cover" on page 124


Procedure

CAUTION:

Do not disassemble the Laser Scanner Unit because it requires adjustment.

1. Remove the Fan Duct [1].

- 1 Claw [2]
- 1 Hook [3]



2. Remove the Laser Scanner Unit [1].

- 1 Flat Cable [2]
- 1 Sponge Cover [3]
- 1 Connector [4]
- 1 Harness Guide [A]
- 4 Screws [5]
- 2 Bosses [6]




Image Formation System


Removing the Transfer Roller

Procedure


CAUTION:

Do not touch the surface of the roller when disassembling/assembling.

1. Open the Front Cover Unit.
2. Remove the Transfer Roller Unit [1].
 - 2 Claws [2]



3. Remove the gear [2], bushing [3], and spring [4] from the Transfer Roller Unit [1].




Removing the Registration Unit

Preparation


1. Remove the Left Cover. [“Removing the Left Cover”](#) on page 115

Procedure

1. Remove the gear [1].
 - 1 Claw [2]



2. Remove the Registration Unit [1].
 - 4 Screws [2]



Fixing System

Removing the Fixing Assembly

Preparation

1. Remove the Right Cover. “ Removing the Right Cover” on page 115
2. Remove the Rear Cover Unit. “Removing the Rear Cover Unit” on page 118
3. Remove the Rear Right Cover. “ Removing the Rear Right Cover” on page 119

Procedure


CAUTION:

Be sure not to disassemble the Fixing Assembly because it requires adjustment.

CAUTION:


Points to Note when Disassembling/Assembling

- If the Front Cover Unit is open, close it.
- If the link [1] is not stored inside the machine, push it in.




1. Remove the Duplex Feed Guide [1].

- 2 Claws [2]



2. Remove the Fixing Assembly [1].

- 3 Connectors [2]
- 1 Edge Saddle [3]
- 4 Screws [4]



Pickup Feed System


Removing the Multi-purpose Tray Pickup Roller

■ Procedure


CAUTION:

Do not touch the surface of the roller when disassembling/assembling.

1. Open the Front Cover Unit.
2. Remove the Multi-purpose Tray Pickup Roller [1].
 - 2 Claws [2]



1. Remove the Multi-purpose Tray Pickup Separation Pad [1].
 - 2 Claws [2]



Removing the Cassette Pickup Roller Unit

■ Procedure

CAUTION:

Be sure not to touch the surface of the roller when disassembling/assembling.

Removing the Cassette Separation Pad

■ Preparation

1. Remove the Multi-purpose Tray Pickup Roller.
 - “ Removing the Multi-purpose Tray Pickup Roller” on page 162

■ Procedure



CAUTION:

Do not touch the surface of the pad when disassembling/assembling.


1. Remove the Cassette.

CAUTION:


- When installing/removing the Cassette Pickup Roller Unit [1], be sure to push the side [A] of the Cassette Pickup Roller Shaft Holder (white). If the side [B] of the Cassette Pickup Roller Holder (left) is pushed, the unit may be separated into the Cassette Pickup Roller Holder (left) [2] and the Cassette Pickup Roller Holder (black) [3]. When the Cassette Pickup Roller Unit [1] is separated, it can no longer be installed to / removed from the host machine.

**CAUTION:**

- When the Cassette Pickup Roller Unit [1] is separated, push the side [A] of the Cassette Pickup Roller Holder (right), and fit the hole [B] of the Cassette Pickup Roller Holder (black) to the claw [2] of the Cassette Pickup Roller Shaft Holder (white). Be sure to assemble the Cassette Pickup Roller Unit [1] before installing/removing it to/from the host machine.



- Remove the Cassette Pickup Roller Unit [1] while pushing the side [A] of the Cassette Pickup Roller Shaft Holder (white).
 - 2 Shafts [2]




Removing the Cassette Separation Pad

Procedure

CAUTION:

Do not touch the surface of the pad when disassembling/assembling.

- Remove the Cassette.
- Remove the Cassette Separation Pad [1].
 - 2 Screws [2]




Removing the Duplex Feed Unit

Preparation


- Remove the Right Cover. “Removing the Right Cover” on page 115
- Remove the Rear Cover Unit. “Removing the Rear Cover Unit” on page 118
- Remove the Rear Right Cover. “Removing the Rear Right Cover” on page 119
- Remove the Fixing Assembly. “Removing the Fixing Assembly” on page 161

Procedure

- Press the jam removal button [1]. Open the Duplex Feed Unit [2].



- Remove the Duplex Feed Unit [3] from the boss [1] and then the boss [2].



Removing the Pickup Unit

Preparation


1. Remove the Right Cover. “Removing the Right Cover” on page 115
2. Remove the Left Cover. “Removing the Left Cover” on page 115
3. Remove the Multi-purpose Tray Auxiliary Tray Unit. “Removing the Multi-purpose Tray Auxiliary Tray Unit” on page 120
4. Remove the Right Front Inner Cover. “Removing the Right Front Inner Cover” on page 122
5. Remove the Right Lower Cover. “Removing the Right Lower Cover” on page 123
6. Remove the Rear Cover Unit. “Removing the Rear Cover Unit” on page 118
7. Remove the Rear Right Cover. “Removing the Rear Right Cover” on page 119
8. Remove the ADF + Reader Unit. “Removing the ADF + Reader Unit” on page 126
9. Remove the Upper Cover. “Removing the Upper Cover” on page 124
10. Remove the Main Controller PCB. “Removing the Main Controller PCB” on page 135
11. Remove the Wireless LAN PCB. “Removing the Wireless LAN PCB (except for D1520/MF412dn)” on page 135
12. Remove the Fax PCB. (MF515x/MF515dw)
“Removing the Fax PCB (MF515x/MF515dw)” on page 136
13. Remove the OFF Hook PCB. (MF515x/MF515dw)
“Removing the OFF Hook PCB (MF515x/MF515dw)” on page 137
14. Remove the Arrestor PCB. (230V only) “Removing the Arrestor PCB (230 V only)” on page 137
15. Remove the AC Relay PCB. “Removing the AC Relay PCB” on page 138
16. Remove the All-night Power Supply PCB.
“Removing the All-night Power Supply PCB” on page 138
17. Remove the PCB Unit. “Removing the PCB Unit” on page 138
18. Remove the Power Switch. “Removing the Power Switch” on page 139
19. Remove the Engine Controller PCB. “Removing the Engine Controller Unit” on page 141
20. Remove the Cassette Pickup Solenoid. “Removing the Cassette Pickup Solenoid” on page 150

Procedure


1. Close the Front Cover Unit.
2. Remove the Gear Unit [1].
 - 1 Claw [2]

CAUTION:


Never disassemble the Gear Unit because it is difficult to assemble it.



3. Turn the machine so that it is placed with its rear side down.




4. Remove the Lower Right Guide [1].
 - 1 Screw [2]




5. Remove the Lower Left Guide [1].

- 1 Screw [2]




6. Remove the Lower Front Reinforcing Plate [1].

- 2 Screws [2]
- 4 Hooks [3]




7. Remove the Feed Roller Unit [1].

- 2 Screws [2]




8. Press the jam removal button [1]. Open the Duplex Feed Unit [2].




9. Remove the Pickup Unit [1].

- 4 Screws [2]



CAUTION:

When assembling, be sure to pass the connector [2] through the hole [1] on the Right Side Plate.





Adjustment

Overview.....	168
Actions after Replacement Parts.....	169

Overview

Adjustment required in the field service works when following parts are replaced. The parts are classified by 2 function blocks.

Category	Parts	Reference
Document Exposure / Feed System	Scanner Unit (CIS)	" After Replacing the Scanner Unit (CIS) " on page 169
	Reader Unit	"After Replacing the Reader Unit" on page 173
	Reader Upper Cover Unit	" After Replacing the Reader Upper Cover Unit " on page 175
	Scoopup Sheet Holder	" After Replacing the Scoopup Sheet Holder " on page 180
Controller System	Main Controller PCB	"After Replacing the Main Controller PCB" on page 181

Actions after Replacement Parts

Document Exposure / Delivery System

■ After Replacing the Scanner Unit (CIS)

1. CIS light intensity adjustment

1. Enter a provisional value.

Change all the adjustment values of the LED lighting time for RGB colors to "0".

- COPIER > ADJUST > CCD > LED-BW-R
- COPIER > ADJUST > CCD > LED-BW-G
- COPIER > ADJUST > CCD > LED-BW-B
- COPIER > ADJUST > CCD > LED-CL-R
- COPIER > ADJUST > CCD > LED-CL-G
- COPIER > ADJUST > CCD > LED-CL-B

2. Execute light intensity adjustment for the Scanner Unit (CIS) at ADF reading. (Be sure to close the ADF)

- COPIER > FUNCTION > CCD > BW-AGC
- COPIER > FUNCTION > CCD > CL-AGC

3. Check the adjustment result.

Whether the operation was successful or failed is not shown on the UI, so perform the following procedure to judge if the operation was successful or failed.

If the values entered in step 1 have been changed, the operation result is judged to be "successful" (end of adjustment).

If all the values entered in step 1 remain "0", turn OFF and then ON the power and perform step 2 again.

2. Automatic adjustment of the stream reading position

1. Enter a provisional value.

Change the adjustment value of the reading position at ADF stream reading to "-20".

- COPIER > ADJUST > ADJ-XY > STRD-POS

2. Execute automatic detection of CIS reading position at ADF stream reading.

- COPIER > FUNCTION > INSTALL > STRD-POS

3. Check the adjustment result.

Whether the operation was successful or failed is not shown on the UI, so perform the following procedure to judge if the operation was successful or failed.

If the value entered in step 1 has been changed, the operation result is judged to be "successful" (end of adjustment).

Write the new adjustment value on the service label.

If the value entered in step 1 remains "-20", turn OFF and then ON the power and perform step 2 again.

3. Adjustment of the white level

1. Enter a provisional value.

Change all the shading target values at ADF reading to "0".

- COPIER > ADJUST > CCD > DFTAR-R
- COPIER > ADJUST > CCD > DFTAR-G
- COPIER > ADJUST > CCD > DFTAR-B
- COPIER > ADJUST > CCD > DFTAR-BW

2. Place a sheet of A4 or LTR blank paper (paper recommended by Canon: GF-C081) on the Copyboard Glass of the reader, and execute white level adjustment (color) at copyboard reading

- COPIER > FUNCTION > CCD > DF-WLVL1

3. Place the same blank paper on the ADF, and execute white level adjustment (color) at ADF reading.

- COPIER > FUNCTION > CCD > DF-WLVL2

4. Place a sheet of A4 or LTR blank paper (paper recommended by Canon: GF-C081) on the Copyboard Glass of the reader again, and execute white level adjustment (B&W) at copyboard reading.

- COPIER > FUNCTION > CCD > DF-WLVL3

5. Place the same blank paper on the ADF again, and execute white level adjustment (B&W) at ADF reading.

- COPIER > FUNCTION > CCD > DF-WLVL4

6. Check the adjustment result.

Whether the operation was successful or failed is not shown on the UI, so perform the following procedure to judge if the operation was successful or failed.


If the values entered in step 1 have been changed, the operation result is judged to be "successful" (end of adjustment).

Write the new adjustment values on the service label.

If the values entered in step 1 remain "0", turn OFF and then ON the power and perform steps 2 to 5 again.

4. Adjustment of the image position (horizontal scanning direction) at ADF reading

1. Place a test chart on the ADF, and make one single-sided copy.
2. Compare the side registration of the test chart with that of the copied paper, and perform adjustment if necessary.




Execute the following service mode.

- COPIER > ADJUST > ADJ-XY > ADJ-Y-DF

Enter the value and adjust the image position. (Adjustment value: in increments of 0.1 mm)

- If the image is displaced toward the rear side => Decrease the value.
- If the image is displaced toward the front side => Increase the value.

< When a copied image moves to the rear > < When a copied image moves to the front >




3. Write the new adjustment value on the service label.

5. Adjustment of the image position (horizontal scanning direction) at copyboard reading

1. Place a test chart on the Copyboard Glass, and make one single-sided copy.

2. Compare the side registration of the test chart with that of the copied paper, and perform adjustment if necessary.




Execute the following service mode.

- COPIER > ADJUST > ADJ-XY > ADJ-Y

Enter the value and adjust the image position. (Adjustment value: in increments of 0.1 mm)

- If the image is displaced toward the rear side => Decrease the value.
- If the image is displaced toward the front side => Increase the value.

< When a copied image moves to the rear > < When a copied image moves to the front >




3. Write the new adjustment value on the service label.

6. Adjustment of the image position (vertical scanning direction) at copyboard reading

1. Place a test chart on the Copyboard Glass, and make one single-sided copy.

2. Compare the image leading edge of the test chart with that of the copied paper, and perform adjustment if necessary.




Execute the following service mode.

- COPIER > ADJUST > ADJ-XY > ADJ-X


Enter the value and adjust the image position. (Adjustment value: in increments of 0.1 mm)

- If the image is displaced toward the trailing edge => Decrease the value.
- If the image is displaced toward the leading edge => Increase the value.

< When a copied image moves to the trailing edge >



< When a copied image moves to the leading edge >



3. Write the new adjustment value on the service label.

7. Fine adjustment of image magnification ratio (vertical scanning direction) at copyboard reading

1. Place a test chart on the Copyboard Glass with the front side facing upward, and make one single-sided copy.

- Compare the length of the image in the feed direction of the test chart with that of the copied paper, and perform adjustment if necessary.


Execute the following service mode.

- COPIER > ADJUST > ADJ-XY > ADJ-X-MG


Enter the value and adjust the image position. (Adjustment value: in increments of 0.01%)

- To enlarge the copied image => Increase the value.
- To reduce the copied image => Decrease the value.

< When a copied image is long >



< When a copied image is short >




- Write the new adjustment value on the service label.

- Make one copy of the image, and check the copied image.

■ After Replacing the Reader Unit

- Enter the values of the Standard White Plate signal data (X, Y, Z) written on the label affixed at the upper left of the Copyboard Glass, and write the entered values on the service label.



- COPIER > ADJUST > CCD > W-PLT-X
- COPIER > ADJUST > CCD > W-PLT-Y
- COPIER > ADJUST > CCD > W-PLT-Z

2. CIS light intensity adjustment

1. Enter a provisional value.

Change all the adjustment values of the LED lighting time for RGB colors to "0".

- COPIER > ADJUST > CCD > LED-BW-R
- COPIER > ADJUST > CCD > LED-BW-G
- COPIER > ADJUST > CCD > LED-BW-B
- COPIER > ADJUST > CCD > LED-CL-R
- COPIER > ADJUST > CCD > LED-CL-G
- COPIER > ADJUST > CCD > LED-CL-B

2. Execute light intensity adjustment for the Scanner Unit (CIS) at ADF reading. (Be sure to close the ADF.)

- COPIER > FUNCTION > CCD > BW-AGC
- COPIER > FUNCTION > CCD > CL-AGC

3. Check the adjustment result.

Whether the operation was successful or failed is not shown on the UI, so perform the following procedure to judge if the operation was successful or failed.

If the values entered in step 1 have been changed, the operation result is judged to be "successful" (end of adjustment).

If all the values entered in step 1 remain "0", turn OFF and then ON the power and perform step 2 again.

3. Automatic adjustment of the stream reading position

1. Enter a provisional value.

Change the adjustment value of the reading position at ADF stream reading to "-20".

- COPIER > ADJUST > ADJ-XY > STRD-POS

2. Execute automatic detection of CIS reading position at ADF stream reading.

- COPIER > FUNCTION > INSTALL > STRD-POS

3. Check the adjustment result.

Whether the operation was successful or failed is not shown on the UI, so perform the following procedure to judge if the operation was successful or failed.

If the value entered in step 1 has been changed, the operation result is judged to be "successful" (end of adjustment).

Write the new adjustment value on the service label.

If the value entered in step 1 remains "-20", turn OFF and then ON the power and perform step 2 again.

4. Adjustment of the white level

1. Enter a provisional value.

Change all the shading target values at ADF reading to "0".

- COPIER > ADJUST > CCD > DFTAR-R
- COPIER > ADJUST > CCD > DFTAR-G
- COPIER > ADJUST > CCD > DFTAR-B
- COPIER > ADJUST > CCD > DFTAR-BW

2. Place a sheet of A4 or LTR blank paper (paper recommended by Canon: GF-C081) on the Copyboard Glass of the reader, and execute white level adjustment (color) at copyboard reading.

- COPIER > FUNCTION > CCD > DF-WLVL1

3. Place the same blank paper on the ADF, and execute white level adjustment (color) at ADF reading.

- COPIER > FUNCTION > CCD > DF-WLVL2

4. Place a sheet of A4 or LTR blank paper (paper recommended by Canon: GF-C081) on the Copyboard Glass of the reader again, and execute white level adjustment (B&W) at copyboard reading.

- COPIER > FUNCTION > CCD > DF-WLVL3

5. Place the same blank paper on the ADF again, and execute white level adjustment (B&W) at ADF reading.

- COPIER > FUNCTION > CCD > DF-WLVL4

6. Check the adjustment result.


Whether the operation was successful or failed is not shown on the UI, so perform the following procedure to judge if the operation was successful or failed.

If the values entered in step 1 have been changed, the operation result is judged to be "successful" (end of adjustment).

Write the new adjustment values on the service label.

If the values entered in step 1 remain "0", turn OFF and then ON the power and perform steps 2 to 5 again.


5. Enter the parameter values written on the "D15xx/MF41x/MF51x Reader Adjustment Sheet" included with the Reader Unit in service mode, and write the entered values on the service label.



- COPIER > ADJUST > ADJ-XY > ADJ-X
- COPIER > ADJUST > ADJ-XY > ADJ-Y
- COPIER > ADJUST > ADJ-XY > ADF-X-MG
- COPIER > ADJUST > CCD > 50-RG
- COPIER > ADJUST > CCD > 50-GB
- COPIER > ADJUST > CCD > 100-RG
- COPIER > ADJUST > CCD > 100-GB
- COPIER > ADJUST > PASCAL > OFST-P-K

■ After Replacing the Reader Upper Cover Unit

1. Enter the values of the Standard White Plate signal data (X, Y, Z) written on the label affixed at the upper left of the Copyboard Glass, and write the entered values on the service label.



- COPIER > ADJUST > CCD > W-PLT-X
- COPIER > ADJUST > CCD > W-PLT-Y
- COPIER > ADJUST > CCD > W-PLT-Z

2. CIS light intensity adjustment

1. Enter a provisional value.

Change all the adjustment values of the LED lighting time for RGB colors to "0".

- COPIER > ADJUST > CCD > LED-BW-R
- COPIER > ADJUST > CCD > LED-BW-G
- COPIER > ADJUST > CCD > LED-BW-B
- COPIER > ADJUST > CCD > LED-CL-R
- COPIER > ADJUST > CCD > LED-CL-G
- COPIER > ADJUST > CCD > LED-CL-B

2. Execute light intensity adjustment for the Scanner Unit (CIS) at ADF reading. (Be sure to close the ADF.)
 - COPIER > FUNCTION > CCD > BW-AGC
 - COPIER > FUNCTION > CCD > CL-AGC
3. Check the adjustment result.
Whether the operation was successful or failed is not shown on the UI, so perform the following procedure to judge if the operation was successful or failed.
If the values entered in step 1 have been changed, the operation result is judged to be "successful" (end of adjustment).
If all the values entered in step 1 remain "0", turn OFF and then ON the power and perform step 2 again.

3. Automatic adjustment of the stream reading position

1. Enter a provisional value.
Change the adjustment value of the reading position at ADF stream reading to "-20".
 - COPIER > ADJUST > ADJ-XY > STRD-POS
2. Execute automatic detection of CIS reading position at ADF stream reading.
 - COPIER > FUNCTION > INSTALL > STRD-POS
3. Check the adjustment result.
Whether the operation was successful or failed is not shown on the UI, so perform the following procedure to judge if the operation was successful or failed.
If the value entered in step 1 has been changed, the operation result is judged to be "successful" (end of adjustment).
Write the new adjustment value on the service label.
If the value entered in step 1 remains "-20", turn OFF and then ON the power and perform step 2 again.


4. Adjustment of the white level

1. Enter a provisional value.
Change all the shading target values at ADF reading to "0".
 - COPIER > ADJUST > CCD > DFTAR-R
 - COPIER > ADJUST > CCD > DFTAR-G
 - COPIER > ADJUST > CCD > DFTAR-B
 - COPIER > ADJUST > CCD > DFTAR-BW
2. Place a sheet of A4 or LTR blank paper (paper recommended by Canon: GF-C081) on the Copyboard Glass of the reader, and execute white level adjustment (color) at copyboard reading.
 - COPIER > FUNCTION > CCD > DF-WLVL1
3. A Place the same blank paper on the ADF, and execute white level adjustment (color) at ADF reading.
 - COPIER > FUNCTION > CCD > DF-WLVL2
4. Place a sheet of A4 or LTR blank paper (paper recommended by Canon: GF-C081) on the Copyboard Glass of the reader again, and execute white level adjustment (B&W) at copyboard reading.
 - COPIER > FUNCTION > CCD > DF-WLVL3
5. Place the same blank paper on the ADF again, and execute white level adjustment (B&W) at ADF reading.
 - COPIER > FUNCTION > CCD > DF-WLVL4
6. Check the adjustment result.
Whether the operation was successful or failed is not shown on the UI, so perform the following procedure to judge if the operation was successful or failed.
If the values entered in step 1 have been changed, the operation result is judged to be "successful" (end of adjustment).
Write the new adjustment values on the service label.
If the values entered in step 1 remain "0", turn OFF and then ON the power and perform steps 2 to 5 again.

5. Adjustment of the image position (horizontal scanning direction) at ADF reading

1. Place a test chart on the ADF, and make one single-sided copy.

2. Compare the side registration of the test chart with that of the copied paper, and perform adjustment if necessary.




Execute the following service mode.

- COPIER > ADJUST > ADJ-XY > ADJ-Y-DF

Enter the value and adjust the image position. (Adjustment value: in increments of 0.1 mm)

- If the image is displaced toward the rear side => Decrease the value.
- If the image is displaced toward the front side => Increase the value.

< When a copied image moves to the rear > < When a copied image moves to the front >




3. Write the new adjustment value on the service label.

6. Adjustment of the image position (horizontal scanning direction) at copyboard reading

1. Place a test chart on the Copyboard Glass, and make one single-sided copy.

2. Compare the side registration of the test chart with that of the copied paper, and perform adjustment if necessary.




Execute the following service mode.

- COPIER > ADJUST > ADJ-XY > ADJ-Y

Enter the value and adjust the image position. (Adjustment value: in increments of 0.1 mm)

- If the image is displaced toward the rear side => Decrease the value.
- If the image is displaced toward the front side => Increase the value.

< When a copied image moves to the rear > < When a copied image moves to the front >




3. Write the new adjustment value on the service label.

7. Adjustment of the image position (vertical scanning direction) at copyboard reading

1. Place a test chart on the Copyboard Glass, and make one single-sided copy.

2. Compare the image leading edge of the test chart with that of the copied paper, and perform adjustment if necessary.




Execute the following service mode.

- COPIER > ADJUST > ADJ-XY > ADJ-X


Enter the value and adjust the image position. (Adjustment value: in increments of 0.1 mm)

- If the image is displaced toward the trailing edge => Decrease the value.
- If the image is displaced toward the leading edge => Increase the value.

< When a copied image moves to the trailing edge >



< When a copied image moves to the leading edge >



3. Write the new adjustment value on the service label.

8. Fine adjustment of image magnification ratio (vertical scanning direction) at copyboard reading

1. Place a test chart on the Copyboard Glass with the front side facing upward, and make one single-sided copy.

- Compare the length of the image in the feed direction of the test chart with that of the copied paper, and perform adjustment if necessary.


Execute the following service mode.

- COPIER > ADJUST > ADJ-XY > ADJ-X-MG


Enter the value and adjust the image position. (Adjustment value: in increments of 0.01%)

- To enlarge the copied image => Increase the value.
- To reduce the copied image => Decrease the value.

< When a copied image is long >



< When a copied image is short >



- Write the new adjustment value on the service label.

9. Make one copy of the image, and check the copied image.

■ After Replacing the Scoopup Sheet Holder



[1]: Scoopup Sheet Holder

1. Automatic adjustment of the stream reading position

- Enter a provisional value.

Change the adjustment value of the reading position at ADF stream reading to "-20".

- COPIER > ADJUST > ADJ-XY > STRD-POS

- Execute automatic detection of CIS reading position at ADF stream reading.

- COPIER > FUNCTION > INSTALL > STRD-POS

- Check the adjustment result.

Whether the operation was successful or failed is not shown on the UI, so perform the following procedure to judge if the operation was successful or failed.

If the value entered in step 1 has been changed, the operation result is judged to be "successful" (end of adjustment).

Write the new adjustment value on the service label.

If the value entered in step 1 remains "-20", turn OFF and then ON the power and perform step 2 again.

2. Adjustment of the white level

1. Enter a provisional value.

Change all the shading target values at ADF reading to "0".

- COPIER > ADJUST > CCD > DFTAR-R
- COPIER > ADJUST > CCD > DFTAR-G
- COPIER > ADJUST > CCD > DFTAR-B
- COPIER > ADJUST > CCD > DFTAR-BW

2. Place a sheet of A4 or LTR blank paper (paper recommended by Canon: GF-C081) on the Copyboard Glass of the reader, and execute white level adjustment (color) at copyboard reading.

- COPIER > FUNCTION > CCD > DF-WLVL1

3. Place the same blank paper on the ADF, and execute white level adjustment (color) at ADF reading.

- COPIER > FUNCTION > CCD > DF-WLVL2

4. Place a sheet of A4 or LTR blank paper (paper recommended by Canon: GF-C081) on the Copyboard Glass of the reader again, and execute white level adjustment (B&W) at copyboard reading.

- COPIER > FUNCTION > CCD > DF-WLVL3

5. Place the same blank paper on the ADF again, and execute white level adjustment (B&W) at ADF reading.

- COPIER > FUNCTION > CCD > DF-WLVL4

6. Check the adjustment result.

Whether the operation was successful or failed is not shown on the UI, so perform the following procedure to judge if the operation was successful or failed.

If the values entered in step 1 have been changed, the operation result is judged to be "successful" (end of adjustment).

Write the new adjustment values on the service label.

If the values entered in step 1 remain "0", turn OFF and then ON the power and perform steps 2 to 5 again.

Controller System

■ After Replacing the Main Controller PCB

● Actions before Replacement

CAUTION:

- Back up user data (settings, registered data, etc.) and service mode data for setting and registration after PCB replacement.

*Take notes if data is unable to back up.

Backup Procedure

Perform backup of user data (such as Settings/Registration data) and service mode data in preparation to set/register them again after replacing the PCB. Write down the data which cannot be backed up.

1. Write down the data of Menu > System Settings > Device Information > Location.
2. Export user data using remote UI.
3. Insert the USB memory into the host machine, and execute COPIER > FUNCTION > SYSTEM > EXPORT to write the setting values of the service mode to the USB memory.
4. Write down the each factory adjustment value written on the service label. (Enter them after replacement.)

Reference: The data recorded on the Main Controller can be backed up and restored by the following procedure.

Storage destination	Backup target	Backup procedure
USB flash drive	Settings of [Menu]	Connect the USB flash drive . (The USB port on the rear side of the host machine cannot be used.) <ul style="list-style-type: none"> • Home key > Menu > System Management Settings > Import/Export of Settings > Export Remove the USB flash drive. <ul style="list-style-type: none"> • [Status Monitor] key > Device Status > Remove Memory Media
USB flash drive	Service mode setting values	Connect the USB flash drive . (The USB port on the rear side of the host machine cannot be used.) <ul style="list-style-type: none"> • COPIER > FUNCTION > SYSTEM > EXPORT Remove the USB flash drive. <ul style="list-style-type: none"> • [Status Monitor] key > Device Status > Remove Memory Media

Storage destination	Backup target	Backup procedure
PC	Settings of [Menu] , Service mode setting values	<ul style="list-style-type: none"> • COPIER > OPTION > USER > SMD-EXPT > 1 Save the backup file to any location. <ul style="list-style-type: none"> • Remote UI: Menu > Import/Export > Export > Start Exporting

• After replacing main controller PCB

1. Setting of destination/paper size group

COPIER > OPTION > BODY > LOCALE

- [Settings] 1: Japan, 2: North America, 3: Korea, 4: China, 5: Taiwan, 6: Europe, 7: Asia, 8: Oceania

COPIER > OPTION > BODY > SIZE-LC

- [Settings] 1: AB series, 2: Inch series, 3: A series, 4: AB/Inch series

2. Clearing Setting/Registration data

COPIER > FUNCTION > CLEAR > ALL

Once executed, the following data are cleared according to the values of LOCALE and SIZE-LC set in step 1

- Setting/Registration data (Change the settings back to the initial settings)
- Service Mode data. (Change the settings back to the initial settings)
- Job IDs
- Log data
- Dates

Following data is not cleared.

- Service counter
- Reader/ADF Adjustment data

3. Turn OFF and then ON the main power.

4. Operate according to the instruction on the screen since the initial installation mode is activated. (Setting the date/time)

5. Execute COPIER > FUNCTION > MISC-P > SPEC to output the spec report to check the serial number (Body.No.).

6. Enter the data backed up earlier in Menu > System Settings > Device Information > Location.

7. Import the service mode data backed up before replacement.

Insert the USB flash drive into the host machine, and execute COPIER > FUNCTION > SYSTEM > IMPORT.

8. Import user data using remote UI.

9. Uninstall the drivers on the user's PC.

*For the procedure, refer to the MF Driver Installation Guide.

10. Reinstall the drivers which were uninstalled.

*For the procedure, refer to the MF Driver Installation Guide.

11. Execute COPIER > FUNCTION > CLEAR > COUNTER to clear the service counter.

12. Correction of coordinate position of Touch Panel in the following service mode.

COPIER > ADJUST > PANEL > TOUCHCHK



Troubleshooting

Test Print.....	184
Trouble Shooting Items.....	186
Debug Log.....	188

Test Print

Test Pages

Printing test pages helps determine if the printer is functioning.

CAUTION:

There are two types of test pages: engine-test page and formatter-test page. Print a test page to make sure the printer engine and the formatter are functioning.

■ Engine-test page

This machine has an engine test print function to check whether the printer engine is operating normally.

NOTE:


The engine test print is a method that enables to perform a test print by using only the Engine Controller.

a. Simplex print

Turn ON the power with the Sub-output tray opened.

Close the Sub-output tray until it reaches the Sub-output delivery position within 5 sec. after turning ON the power.


The engine-test page should have a test print pattern on both sides of media as shown below.




b. Duplex print

Turn ON the power with the Sub-output tray opened.

Close the Sub-output tray within 5 sec. after turning ON the power.



The engine-test page should have a test print pattern on both sides of media as shown below.



■ Controller Test Print

This product provides the following 8 test chart types to determine causes of faulty images. The data for test charts are created in the main controller. If no problem is found on the output test charts, the cause may lie in the PDL input or the reader.

TYPE No. can be selected in TESTMODE > PRINT > PG-TYPE.

TYPE No.	pattern	image check item
0	Grid chart	Right angle accuracy Straight line accuracy
1	Halftone	Transfer failure, Black line, White line, Margin
2	Solid black	Transfer failure, White line, Margin
3	Solid white	Fogging
4	17 gradations	Gradation, Black line, White line
5	Thin horizontal line	Black line, White line, Parallelism
6	PASCAL correction chart	-
7	Chart 128	-

Trouble Shooting Items

Special Mode

This product has settings called Special Mode to solve print quality troubles. This function can be executed in the following user mode.

- Menu> Adjustment / Maintenance > Special Processing

Special Paper Processing

Special mode	Options	Details
Paper Wrinkle Correction	OFF Mode 1 Mode 2	If paper with damp edge is used, the printout may crease. In this case, setting this item may solve the problem. The improvement effect is increased in the following order. (Effect: Weak) <Off> -> <Mode 1> -> <Mode 2> (Effect: Strong) <ul style="list-style-type: none"> • By changing the paper type or use environment, wrinkle may be alleviated without changing the settings. • If the improvement effect becomes stronger, it may take some time to start printing.
Paper Curl Correction	OFF Mode 1 Mode 2	If the printed paper curls, set this item. In this case, setting this item may solve the problem. The improvement effect is increased in the following order. (Effect: Weak) <Off> -> <Mode 1> -> <Mode 2> (Effect: Strong) <ul style="list-style-type: none"> • By changing the paper type or use environment, paper curl may be alleviated without changing the settings. • If the improvement effect becomes stronger, it may take some time to start printing. • Printing speed may become slower depending on the paper size.
Speed Priority for Plain L Paper	OFF ON	This item reduces the time before start of printing when the paper type is set to <Plain L>. <ul style="list-style-type: none"> • If paper creases after you set this item to <On>, return it to <Off>.
High-Resistance Paper Mode	OFF Mode 1 Mode 2	Toner smudges and splatters may appear on printouts depending on the paper type or the environmental conditions. In this case, setting this item may solve the problem. The improvement effect is increased in the following order. (Effect: Weak) <Off> -> <Mode 1> -> <Mode 2> (Effect: Strong) <ul style="list-style-type: none"> • When you select stronger improvement, print quality may be lower depending on the paper type or the operating environment (more specifically when you print on thin paper or use the machine in an environment with high humidity).
Smudge Reduction Mode	OFF ON	Streaks may appear on printouts depending on the paper type or the environmental conditions. In this case, setting this item to <On> may solve the problem. <ul style="list-style-type: none"> • If printouts crease after you set this item to <On>, return it to <Off>.

Special mode	Options	Details
Special Printing Mode A	OFF Mode 1 Mode 2 Mode 3 Mode 4	Streaks may appear on printouts depending on the paper type or the environmental conditions. In this case, setting this item may solve the problem. The improvement effect is increased in the following order. (Effect: Weak) <Off> -> <Mode 1> -> <Mode 2> -> <Mode 3> -> <Mode 4>(Effect: Strong) <ul style="list-style-type: none"> • Streaks can be minimized by changing the paper type or usage conditions, without needing to change the setting. • When printing from the computer, the setting in the printer driver takes precedence. When the setting of [Graphics Mode] in the printer driver is changed to [UFR II Mode], the setting in the operation panel takes precedence. • This item cannot be set when <Barcode Adjustment Mode> is set to one of <Mode 1> to <Mode 3>. • Print density will be lighter when you select stronger improvement. It may also result in less sharp edges and rougher details. • If the problem cannot be solved in spite of this item having been set, set <Special Printing Mode D> to <On>.

Special mode	Options	Details
Special Printing Mode Z (only for copying)	OFF Mode 1 Mode 2 Mode 3	Blurred smudges may appear on copied paper depending on the paper type or the environmental conditions. In this case, setting this item may solve the problem. The improvement effect is increased in the following order. (Effect: Weak) <Off> -> <Mode 1> -> <Mode 2> -> <Mode 3> (Effect: Strong) <ul style="list-style-type: none"> • Streaks can be minimized by changing the paper type or usage conditions, without needing to change the setting. • Print density will be lighter when you select stronger improvement. It may also result in less sharp edges and rougher details. • If the problem cannot be solved in spite of this item having been set, set <Special Printing Mode D> to <On>.
Special Printing Mode B	OFF Mode 1 Mode 2 Mode 3	Streaks may appear on printouts immediately after you replace the toner cartridge or when you print for the first time after a long time. In this case, setting this item may solve the problem. The improvement effect is increased in the following order. (Effect: Weak) <Off> -> <Mode 1> -> <Mode 2> -> <Mode 3> (Effect: Strong) <ul style="list-style-type: none"> • If you change the paper type or the printing environment, liner stains may not appear on the printed paper without any setting. • Printing speed becomes slower when you select stronger improvement.
Special Printing Mode D	OFF ON	Streaks may appear on printouts depending on the paper type or the environmental conditions. In this case, setting this item to <On> may solve the problem. Also, setting this item to <On> will reduce the operating noise during printing. <ul style="list-style-type: none"> • Streaks can be minimized by changing the paper type or usage conditions, without needing to change the setting. • If you set this item to <On>, the printing speed becomes slower.

Debug Log

Function Overview

The debug log is a log that analyzes the program behavior of the machine to enable developers to identify problems. This machine is embedded with a function that compiles the log of the behavior of each software module as debug log and outputs it as integrated log for analyzing problems.

Be sure to collect the debug log when the Support Dept. of sales company so instructs.

Note that there is no need for service technicians to check the content of collected debug log.

■ Cases in which collection of debug log is effective

Collection of debug log is effective in the following cases:

- Neither the Support Dept. of sales company nor CINC can reproduce the trouble that occurred at the customer site
- When the error frequency is low
- When the failure is suspected to be due to firmware rather than a mechanical/electrical failure.

CAUTION:

If the procedure for reproducing the failure is clear and the Support Dept. of sales company and CINC can reproduce it, collection of debug log is not necessary.

Conditions for collecting logs

■ Conditions for not being able to collect logs

In the following cases, the procedure for obtaining logs is not required because logs cannot be obtained.

- Service mode screen cannot be accessed
- The machine cannot recognize a USB flash drive
- No USB port is installed in the machine (when the model has only a copy function)

■ What is necessary to collect logs


A USB flash drive that satisfies the following conditions is required to obtain the debug logs of the machine:

- Formatted in FAT 16/FAT32
- There is a free space of approx. 100MB.
- Can be recognized by the machine

Collection procedure

The following shows the procedure for collecting the debug log from the Control Panel.


1. Connect a USB flash drive to the machine. In the case of a model having a USB connector on a side of the Control Panel, be sure to connect the USB flash drive to the Control Panel. In the case of a model having a USB connector only on the rear side, connect the USB flash drive to the USB connector on the rear side.

**CAUTION:**

In the case of a model having a USB connector on the Control Panel, if the USB flash drive is connected to the USB connector on the rear side, debug logs are not transferred to the USB flash drive.

2. Execute the following service mode from the Control Panel or Remote UI.


- COPIER > FUNCTION > SYSTEM > LOGWRITE



"Executing..." is displayed while log collection is executed. When it is completed, the screen shows the service mode screen again.

3. Execute the following service mode from the Control Panel or Remote UI.

- COPIER > FUNCTION > SYSTEM > LOG2USB



"Executing..." is displayed while log collection is executed. When it is completed, the screen shows the service mode screen again.

4. Remove the USB flash drive by the correct procedure.

Connect the USB flash drive to the PC, and check that the log file shown below has been saved.

- Output by LOGWRITE : SUBLOG.TXT
- Output by LOG2USB : SUBLOG_yyyyymmdd.HHMMSS_xxx.gz (the file may be divided into multiple files)



Error/Jam/Alarm


Overview.....	191
Error codes.....	192
Jam code.....	195
Alarm Code.....	198

Overview

This section describes codes shown in case any problem is occurred.

Code type	Explanation	Reference
Error code	This code is displayed when an error occurs on the machine.	"Error codes" on page 192
Jam code	This code is displayed when a jam occurs inside the machine.	"Jam code" on page 195
Alarm code	This code is displayed when a part of function is lost.	"Alarm Code" on page 198

Jam Code



■ Location code

Location information is displayed as 1-digit number as follows.

Device	Location code
Host machine	3
ADF	4

■ Position code

When jam occurs, pickup location is indicated with the following pickup position code.

Device	Position code
ADF	0
MP Tray	0
Cassette 1	1
Option Cassette (Paper Feeder Unit PF-45)	2
Duplex	7

Error codes

If an error occurs, turn OFF and then ON the power first to check whether the same error occurs. (In the case of controller-related errors, the machine may recover by turning OFF and then ON the power.)


*: Supported by model with FAX only

E Code	Title	Detection description	Remedy
E000 - 0000	Error in temperature rising of Fixing Assembly	Temperature of the Fixing Assembly did not reach a certain temperature within the specified period of time.	<ol style="list-style-type: none"> 1. Check the connector connection between the Fixing Assembly and the Engine Controller PCB. 2. Replace the Fixing Assembly. 3. Replace the Engine Controller PCB.
E001 - 0000	Abnormal high temperature of Fixing Assembly	It was detected that the temperature of the Fixing Assembly was abnormally high.	<ol style="list-style-type: none"> 1. Check the connector connection between the Fixing Assembly and the Engine Controller PCB. 2. Replace the Fixing Assembly. 3. Replace the Engine Controller PCB.
E001 - 0001	Abnormal high temperature of Fixing Assembly	It was detected that the temperature of the Fixing Assembly (Sub Thermistor) was abnormally high.	<ol style="list-style-type: none"> 1. Check the connector connection between the Fixing Assembly and the Engine Controller PCB. 2. Replace the Fixing Assembly. 3. Replace the Engine Controller PCB.
E003 - 0000	Abnormal low temperature of Fixing Assembly	It was detected that the temperature of the Fixing Assembly was abnormally low.	<ol style="list-style-type: none"> 1. Check the connector connection between the Fixing Assembly and the Engine Controller PCB. 2. Replace the Fixing Assembly. 3. Replace the Engine Controller PCB.
E003 - 0001	Abnormal low temperature of Fixing Assembly	It was detected that the temperature of the Fixing Assembly (Sub Thermistor) was abnormally low.	<ol style="list-style-type: none"> 1. Check the connector connection between the Fixing Assembly and the Engine Controller PCB. 2. Replace the Fixing Assembly. 3. Replace the Engine Controller PCB.
E004 - 0000	Error in fixing power supply drive circuit	The zero cross signal was not detected for the specified period of time or more.	<ol style="list-style-type: none"> 1. Check the connector connection between the Fixing Assembly and the Engine Controller PCB. 2. Replace the Fixing Assembly. 3. Replace the Engine Controller PCB.
E012 - 0000	Black Drum Motor error	An error in the initial operation of the Drum Motor was detected.	<ol style="list-style-type: none"> 1. Reconnect the connector of the Main Motor. 2. Replace the Engine Controller PCB.
E012 - 0001	Black Drum Motor error	Rotation error of the Drum Motor was detected.	<ol style="list-style-type: none"> 1. Reconnect the connector of the Main Motor. 2. Replace the Engine Controller PCB.
E014 - 0000	Error in startup of the Main Motor	Revolution of the Main Motor did not reach the specified value.	<ol style="list-style-type: none"> 1. Check the connector connection between the Main Motor and the Engine Controller PCB. 2. Replace the Main Motor. 3. Replace the Engine Controller PCB.
E014 - 0001	Error in startup of the Main Motor	Revolution of the Main Motor was out of the specified range.	<ol style="list-style-type: none"> 1. Check the connector connection between the Main Motor and the Engine Controller PCB. 2. Replace the Main Motor. 3. Replace the Engine Controller PCB.
E052 - 0000	Duplex Feed Unit absent error	Connection of the Duplex Feed Unit was not correct.	<ol style="list-style-type: none"> 1. Reinstall the Duplex Feed Unit.
E100 - 0000	Laser Scanner Assembly error	BD cycle of the Laser Scanner Unit was not within the specified range.	<ol style="list-style-type: none"> 1. Check the connector connection between the Main Controller PCB and the Laser Scanner Unit. 2. Check the connector connection between the Relay PCB and the Laser Scanner Unit. 3. Replace the Laser Scanner Unit.
E110 - 0000	Laser Scanner Assembly error	An error in the initial operation of the Scanner Motor in the Laser Scanner Unit was detected.	<ol style="list-style-type: none"> 1. Check the connector connection between the Main Controller PCB and the Laser Scanner Unit. 2. Check the connector connection between the Relay PCB and the Laser Scanner Unit. 3. Replace the Laser Scanner Unit.
E196 - 0000	DCON error	Update of the DCON was failed. (RFU mode right after the startup)	<ol style="list-style-type: none"> 1. Replace the Engine Controller PCB.

E Code	Title	Detection description	Remedy
E196 - 2000	Main Controller PCB writing/reading error	Error in writing/reading of the setting values storage area in the Main Controller PCB	<ol style="list-style-type: none"> 1. Install the set of the controller firmware. 2. Replace the Main Controller PCB.
E196 - 3000	ROM writing/reading error (eMMC)	An error occurred when writing/reading data to/from the ROM.	<ol style="list-style-type: none"> 1. Install the set of the controller firmware. 2. Replace the Main Controller PCB.
E196 - 3001	ROM-ID mismatch (eMMC)	An error occurred when writing/reading data to/from the ROM.	<ol style="list-style-type: none"> 1. Install the set of the controller firmware. 2. Replace the Main Controller PCB.
E202 - 0001	CIS Unit HP error (outward)	The CIS Unit did not move to HP even it moved backward. Reader HP Sensor error, Reader Motor error, CIS Unit error	<ol style="list-style-type: none"> 1. Replace the Reader HP Sensor. 2. Replace the Reader Motor. 3. Replace the CIS Unit. 4. Replace the Reader Unit.
E202 - 0002	CIS Unit HP error (homeward)	The CIS Unit did not move to HP even it moved forward. Reader HP Sensor error, Reader Motor error, CIS Unit error	<ol style="list-style-type: none"> 1. Replace the Reader HP Sensor. 2. Replace the Reader Motor. 3. Replace the CIS Unit. 4. Replace the Reader Unit.
E246 - 0000	System error	System error	Contact the sales company.
E247 - 0000	System error	System error	Contact the sales company.
E302 - 0001	Light intensity of the CIS Unit below the reference level	When the light intensity is below the reference level at shading	<ol style="list-style-type: none"> 1. Disconnect and then connect the Flexible Cable. 2. Replace the Flexible Cable. 3. Replace the CIS Unit. 4. Replace the Main Controller PCB (PCB2).
E350 - 0000	System error	System error	Contact the sales company.
E354 - 0000	System error	System error	Contact the sales company.
E355 - 0000	System error	System error	Contact the sales company.
E355 - 0004	System error	System error	Contact the sales company.
E355 - 0005	System error	System error	Contact the sales company.
E719 - 0000	Card Reader communication error (serial communication)	Communication with the Card Reader could not be started at startup.	<ol style="list-style-type: none"> 1. After tuning OFF the power, check the connection of the Card Reader-F1 and the short connector [A], and turn ON the power. 2. After turning OFF the power, replace the cable included in the package of the Card Reader-F1 or the Copy Card Reader Attachment-J1, and turn ON the power.
E732 - 0000	Scanner communication error	Scanner communication error	<ol style="list-style-type: none"> 1. Install the set of the controller firmware. 2. Replace the Main Controller PCB.
E733 - 0000	Printer communication error	Communication error between the Engine Controller PCB and the Main Controller PCB occurred.	<ol style="list-style-type: none"> 1. Check the connector connection between the Engine Controller PCB and the Main Controller PCB. 2. Install the set of the controller firmware. 3. Replace the Main Controller PCB. 4. Replace the Engine Controller PCB.
E736* - 0000	Communication error with CCU/modem	Communication error with CCU/modem, NCU PCB type error	<ol style="list-style-type: none"> 1. Install the set of the controller firmware. 2. Replace the NCU PCB. 3. Replace the Main Controller PCB.
E736* - 0001	Error in ROM for backing up fax data	An error occurred in ROM for backing up fax data	<ol style="list-style-type: none"> 1. Install the set of the controller firmware. 2. Replace the NCU PCB. 3. Replace the Main Controller PCB.
E744 - 4000	Engine ID error	Invalid engine connection was detected.	<ol style="list-style-type: none"> 1. Turn OFF and then ON the main power. 2. Check the Engine Controller PCB. 3. Install the Engine Controller PCB. 4. Install the set of the controller firmware. 5. Check the model code. (When the model code and the engine code are mismatched, E744-4000 occurs.)
E744 - 5000	Error in the Control Panel PCB	Error in the Control Panel PCB (microcomputer)	<ol style="list-style-type: none"> 1. Check the Control Panel PCB, and install the firmware (PANEL). 2. Install the set of the controller firmware. 3. Replace the Main Controller PCB.

E Code	Title	Detection description	Remedy
E744 - 6000	Communication error with Wireless LAN PCB	Communication with the Wireless LAN PCB could not be established.	<ol style="list-style-type: none"> 1. Turn OFF and then ON the main power. 2. Check the connection of the Wireless LAN PCB. 3. Install the set of the controller firmware. 4. Replace the Wireless LAN PCB. 5. Replace the Main Controller PCB.
E805 - 0005	Sub Fan error	The Sub Fan was locked for a specified consecutive period of time.	<ol style="list-style-type: none"> 1. Check the connection of the Sub Fan. 2. Replace the Sub Fan.
E806 - 0000	Main Fan error	The Main Fan was locked for a specified consecutive period of time.	<ol style="list-style-type: none"> 1. Check the connection of the Main Fan. 2. Replace the Main Fan.
E808 - 0000	Low-voltage power supply failure detection	Printer detected low-voltage power supply failure.	<ol style="list-style-type: none"> 1. Replace the Engine Controller PCB.

Jam code



Location	Jam code	Types of Jam	Sensor name/Detection description	Sensor number
04	0001	Delay Jam	Paper Edge Sensor	PS9
04	0002	Stationary Jam	Paper Edge Sensor	PS9
04	0004	Delay Jam	Paper Edge Sensor (2nd side)	PS9
04	0005	Stationary Jam	Paper Edge Sensor (2nd side)	PS9
04	0071	Sequence Jam	Timing error	-
04	0094	Power-on Jam	Paper Edge Sensor	PS9
03	0104	Pick Up Delay Jam1	Top Sensor	PS215
03	0105	Pick Up Delay Jam2	Top Sensor	PS215
03	0106	Pick Up Delay Jam3	PF Feed Sensor	PS8008
03	010C	Fixing Delivery Delay Jam1	Fixing Delivery Sensor	PS2,PS3
03	010D	Fixing Delivery Delay Jam2	Face-down Tray Media Full Sensor	PS7
03	0144	Pick Up Delay Jam1	Top Sensor	PS215
03	0145	Pick Up Delay Jam2	PF Feed Sensor	PS8008
03	0146	Pick Up Delay Jam3	PF Feed Sensor	PS8008
03	014C	Fixing Delivery Delay Jam1	Fixing Delivery Sensor	PS2,PS3
03	014D	Fixing Delivery Delay Jam2	Face-down Tray Media Full Sensor	PS7

Location	Jam code	Types of Jam	Sensor name/Detection description	Sensor number
03	0184	Pick Up Delay Jam1	Top Sensor	PS215
03	0185	Pick Up Delay Jam2	PF Feed Sensor	PS8008
03	0186	Pick Up Delay Jam3	PF Feed Sensor	PS8008
03	018C	Fixing Delivery Delay Jam1	Fixing Delivery Sensor	PS2,PS3
03	018D	Fixing Delivery Delay Jam2	Face-down Tray Media Full Sensor	PS7
03	01C4	Pick Up Delay Jam1	Top Sensor	PS215
03	01C5	Pick Up Delay Jam2	PF Feed Sensor	PS8008
03	01C6	Pick Up Delay Jam3	PF Feed Sensor	PS8008
03	01CC	Fixing Delivery Delay Jam1	Fixing Delivery Sensor	PS2,PS3
03	01CD	Fixing Delivery Delay Jam2	Face-down Tray Media Full Sensor	PS7
03	0208	Pick Up Stationary Jam1	Top Sensor	PS215
03	0210	Fixing Delivery Stationary Jam1	Fixing Delivery Sensor	PS2,PS3
03	021C	Fixing Paper Wrapping Jam1	Fixing Delivery Sensor	PS2,PS3
03	0224	Duplex Re-Pickup Jam1	Duplex Feede Sensor	PS502
03	0248	Pick Up Stationary Jam1	Top Sensor/Media Width Sensor /Fixing Delivery Sensor	PS215/PS225/ PS2,PS3
03	0250	Fixing Delivery Stationary Jam1	Fixing Delivery Sensor	PS2,PS3
03	025C	Fixing Paper Wrapping Jam1	Fixing Delivery Sensor	PS2,PS3
03	0264	Duplex Re-Pickup Jam1	Duplex Feede Sensor	PS502
03	0288	Pick Up Stationary Jam1	Top Sensor/Media Width Sensor /Fixing Delivery Sensor	PS215/PS225/ PS2,PS3
03	0290	Fixing Delivery Stationary Jam1	Fixing Delivery Sensor	PS2,PS3
03	029C	Fixing Paper Wrapping Jam1	Fixing Delivery Sensor	PS2,PS3
03	02A4	Duplex Re-Pickup Jam1	Duplex Feede Sensor	PS502
03	02C8	Pick Up Stationary Jam1	Top Sensor/Media Width Sensor /Fixing Delivery Sensor	PS215/PS225/ PS2,PS3
03	02D0	Fixing Delivery Stationary Jam1	Fixing Delivery Sensor	PS2,PS3
03	02DC	Fixing Paper Wrapping Jam1	Fixing Delivery Sensor	PS2,PS3
03	02E4	Duplex Re-Pickup Jam1	Duplex Feede Sensor	PS502
03	1014	Internal Stationary Jam 1	Top Sensor/Media Width Sensor /Fixing Delivery Sensor/ Duplex Feede Sensor/PF Feed Sensor	PS215/PS225/ PS2,PS3/PS502/ PS8008
03	1015	Internal Stationary Jam 2	Top Sensor/Media Width Sensor /Fixing Delivery Sensor/ Duplex Feede Sensor/PF Feed Sensor	PS215/PS225/ PS2,PS3/PS502/ PS8008
03	1054	Internal Stationary Jam 1	Top Sensor/Media Width Sensor /Fixing Delivery Sensor/ Duplex Feede Sensor/PF Feed Sensor	PS215/PS225/ PS2,PS3/PS502/ PS8008
03	1055	Internal Stationary Jam 2	Top Sensor/Media Width Sensor /Fixing Delivery Sensor/ Duplex Feede Sensor/PF Feed Sensor	PS215/PS225/ PS2,PS3/PS502/ PS8008
03	1094	Internal Stationary Jam 1	Top Sensor/Media Width Sensor /Fixing Delivery Sensor/ Duplex Feede Sensor/PF Feed Sensor	PS215/PS225/ PS2,PS3/PS502/ PS8008

Location	Jam code	Types of Jam	Sensor name/Detection description	Sensor number
03	1095	Internal Stationary Jam 2	Top Sensor/Media Width Sensor /Fixing Delivery Sensor/ Duplex Feede Sensor/PF Feed Sensor	PS215/PS225/ PS2,PS3/PS502/ PS8008
03	10D4	Internal Stationary Jam 1	Top Sensor/Media Width Sensor /Fixing Delivery Sensor/ Duplex Feede Sensor/PF Feed Sensor	PS215/PS225/ PS2,PS3/PS502/ PS8008
03	10D5	Internal Stationary Jam 2	Top Sensor/Media Width Sensor /Fixing Delivery Sensor/ Duplex Feede Sensor/PF Feed Sensor	PS215/PS225/ PS2,PS3/PS502/ PS8008
03	1118	Door Open Jam1	Top Sensor/Media Width Sensor /Fixing Delivery Sensor/ Duplex Feede Sensor/PF Feed Sensor	PS215/PS225/ PS2,PS3/PS502/ PS8008
03	1158		Top Sensor/Media Width Sensor /Fixing Delivery Sensor/ Duplex Feede Sensor/PF Feed Sensor	PS215/PS225/ PS2,PS3/PS502/ PS8008
03	1198		Top Sensor/Media Width Sensor /Fixing Delivery Sensor/ Duplex Feede Sensor/PF Feed Sensor	PS215/PS225/ PS2,PS3/PS502/ PS8008
03	11D8		Top Sensor/Media Width Sensor /Fixing Delivery Sensor/ Duplex Feede Sensor/PF Feed Sensor	PS215/PS225/ PS2,PS3/PS502/ PS8008

Alarm Code

Alarm Code	Title	A. Operation / B. Cause / C. Action
85-0001	System error	Contact the sales company.
85-0002	System error	Contact the sales company.
85-0003	System error	Contact the sales company.
85-0004	System error	Auto recovery due to replacement with a new Main Controller PCB, which is a service part.
85-0005	System error	Auto recovery due to replacement with a used Main Controller PCB.




Service Mode

Overview.....	200
COPIER.....	204
FEEDER.....	245
FAX.....	248
TESTMODE.....	254
FAX.....	256

Overview

Service Mode Menu



Backing up Service Mode

Each device is tuned at the time of shipment and the tuned values are written on the service label.

Because setting values and management data of the host machine are stored in the eMMC of the Main Controller PCB, they need to be backed up before replacing the Main Controller PCB. (Do not remove the eMMC PCB from Main Controller PCB.)

Also, restoration of the backup data is necessary after replacing the Main Controller PCB.

- Backup: Connect a USB memory device to the USB memory port.
FUNCTION > SYSTEM > EXPORT
- Restore: Restore backup data of the USB memory
FUNCTION > SYSTEM > IMPORT

Reference:


Saving Registered Data: Remote UI > Settings/Registration > Import/Export > Export

Loading Registered Data: Remote UI > Settings/Registration > Import/Export > Import

Screen flow of Service mode

• Initial screen

- Scroll the screen. : Flick the screen.
 Go to Category / Sub category selection screen : Tap the screen.
 Go to Up category screen : Return key




• Category / Sub category selection screen

- Scroll the screen. : Flick the screen.
 Go to Item selection screen : Tap the screen.
 Go to Initial screen : Return key




• Item selection screen

- Select the item : Flick the screen.
 Go to Numeric value entry screen : Tap the screen.
 Go to Category / Sub category selection screen : Return key



• Numeric value entry screen

- Enter the setting value. : numeric keypad
 Switch the sign (+/-) of the value : [*] Key
 Increment the setting value one by one : [▲] (Tap the screen)
 Decrease the setting value one by one : [▼] (Tap the screen)
 Change the setting : [Apply] Key (Tap the screen)
 Change no settings : Return key




• Method to display the setting value of switch

- On decimal display format, display is left aligned. (Comma is put every 3 digits.)
- On binary display format, the most significant bit is placed at the leftmost position and the least significant bit is placed at the rightmost position.

Remote UI Service Mode

■ Function Overview


It is possible to display, configure, and execute various service mode modes as well as restart the host machine by using remote UI.




■ Operating conditions

In order to operate service mode using Remote UI, the following conditions must be met.

- Service mode is not used on the Control Panel.
If service mode is accessed from the Control Panel of the host machine, "Log-in user exists already." is displayed when service mode is accessed from Remote UI.



- When Remote UI service mode (this function) is not being logged in by other users
When service mode is being accessed from Remote UI, "Remote service mode" is displayed on the UI of the host machine.



- When Remote UI is enabled in the setting on the Control Panel
[Settings/Registration] > [System Settings] > [Remote UI Settings] > [Use Remote UI] > [ON]
- When the following setting is enabled (setting value: 1) in service mode
COPIER > OPTION > BODY > RMT-SW (Remote UI service mode function)
0:OFF(default), 1:ON

■ How to Use

1. Activate the Web browser, and access the following URL:

<http://<Host machine's IP address or host name>/servicemode.html>

2. Enter the password, and click [LOGIN].

Password required for authentication differs depending on the following service mode setting:
COPIER > OPTION > BODY > PSWD-SW

PSWD-SW value	Password required for authentication
0	<ul style="list-style-type: none"> • Password of RUI service mode
1	<ul style="list-style-type: none"> • Password of RUI service mode • Service mode password
2	<ul style="list-style-type: none"> • Password of RUI service mode • User's system administrator ID • Password of system administrator • Service mode password

* Password of service mode can be changed in COPIER > OPTION > BODY > SM-PSWD.


3. When finishing the operation, click [Log Out].

NOTE:

If you logged in and then closed the browser without "logging out", you are recognized as "logged in". Therefore, when logging in service mode again, wait for a fixed time (3 minutes) from the last access to let the session time out, or turn OFF and then ON the power.

• Authentication screen

- PSWD-SW : 0




A rectangular form with a light gray background. It contains a single text input field on the left and a button labeled "LOGIN" on the right.

- PSWD-SW : 1



A rectangular form with a light gray background. It contains two text input fields stacked vertically. The top field is empty, and the bottom field is preceded by the label "Service Mode PIN:". A button labeled "LOGIN" is located at the bottom right.

- PSWD-SW : 2



A rectangular form with a light gray background. It contains three text input fields stacked vertically. The top field is empty, the middle field is preceded by the label "System Manager ID:", and the bottom field is preceded by the label "Service Mode PIN:". A button labeled "LOGIN" is located at the bottom right.

COPIER

DISPLAY

VERSION

COPIER > DISPLAY > VERSION

MAIN	Display of MAIN (main program) version
Detail	To display the firmware version of Main Controller PCB.
Use Case	When upgrading the firmware
Adj/Set/Operate Method	N/A (Display only)
Display/Adj/Set Range	00.00 to 99.99
BOOT	Boot ROM version
Detail	To display the version of Boot ROM (BOOT program).
Use Case	When upgrading the firmware
Adj/Set/Operate Method	N/A (Display only)
Display/Adj/Set Range	00.01 to 99.99
LANG	Language pack version
Detail	To display the version of language pack.
Use Case	When upgrading the firmware
Adj/Set/Operate Method	N/A (Display only)
Display/Adj/Set Range	00.00 to 99.99
DEMODATA	Demo print data version
Detail	To display the version of demo print data. Since this machine does not have demo print function, "FF.FF" is displayed.
Use Case	When upgrading the firmware
Adj/Set/Operate Method	N/A (Display only)
Display/Adj/Set Range	00.01 to 99.99
ECONT	ECONT version
Detail	To display the version of Engine Controller PCB.
Use Case	When upgrading the firmware
Adj/Set/Operate Method	N/A (Display only)
Display/Adj/Set Range	00.01 to 99.99
PANEL	Dspl of Control Panel CPU PCB ROM ver
Detail	To display the ROM version of Control Panel CPU PCB.
Use Case	When upgrading the firmware
Adj/Set/Operate Method	N/A (Display only)
Display/Adj/Set Range	00.00 to 99.99
Related Service Mode	COPIER > FUNCTION > SYSTEM > PANEL-UP

USER

COPIER > DISPLAY > USER

SPDTYPE	To display the engine speed type (ppm) of Controller Board.
Detail	To display the engine speed type (ppm) of Controller Board.
Use Case	When checking the engine speed type
Adj/Set/Operate Method	None (display only)
Display/Adj/Set Range	00 to 99

■ CCD

COPIER > DISPLAY > CCD

TARGET-B		Shading target value (B)
Detail	To display the shading target value of Blue. Continuous display of 0 (minimum) or 2048 (maximum) is considered a failure of the CIS Unit.	
Use Case	At scanned image failure	
Adj/Set/Operate Method	N/A (Display only)	
Display/Adj/Set Range	0 to 2048	
Default Value	1202	
Related Service Mode	COPIER > ADJUST > CCD > DFTAR-B	
TARGET-G		Shading target value (G)
Detail	To display the shading target value of Green. Continuous display of 0 (minimum) or 2048 (maximum) is considered a failure of the CIS Unit.	
Use Case	At scanned image failure	
Adj/Set/Operate Method	N/A (Display only)	
Display/Adj/Set Range	0 to 2048	
Default Value	1163	
Related Service Mode	COPIER > ADJUST > CCD > DFTAR-G	
TARGET-R		Shading target value (R)
Detail	To display the shading target value of Red. Continuous display of 0 (minimum) or 2048 (maximum) is considered a failure of the CIS Unit.	
Use Case	At scanned image failure	
Adj/Set/Operate Method	N/A (Display only)	
Display/Adj/Set Range	0 to 2048	
Default Value	1135	
Related Service Mode	COPIER > ADJUST > CCD > DFTAR-R	
TARGETBW		Shading target value (BW)
Detail	To display the shading target value at B&W jobs. Continuous display of 0 (minimum) or 2048 (maximum) is considered a failure of the Main Controller PCB.	
Use Case	At scanned image failure	
Adj/Set/Operate Method	N/A (Display only)	
Display/Adj/Set Range	0 to 2048	
Default Value	1072	
Related Service Mode	COPIER > ADJUST > CCD > DFTAR-BW	

■ ERR

Error code display screen

Up to 20 E codes and detailed codes for system errors can be shown.

■ JAM

Jam code display screen

Up to 20 Jam codes and detailed codes for system errors can be shown.



■ ADJ-XY

COPIER > ADJUST > ADJ-XY

ADJ-X		Adj of img pstn in book mode: vert scan
Detail		To adjust the image reading start position (image leading edge position) in the vertical scanning direction at copyboard reading. When replacing the Main Controller PCB, enter the value of service label. When the non-image width is larger than the standard value, set the smaller value. When out of original area is copied, set the larger value. As the value is incremented by 1, the image position moves to the trailing edge side by 0.1mm.
Use Case		- When replacing the Reader Unit - When replacing the CIS Unit (Scanner Unit) - When replacing the Main Controller PCB
Adj/Set/Operate Method		Enter the setting value (switch negative / positive by * key) and press Apply key.
Caution		After the setting value is changed, write the changed value in the service label.
Display/Adj/Set Range		-30 to 30
Unit		0.1 mm
Default Value		0
ADJ-Y		Adjustment of image position at copyboard reading (horizontal scanning direction)
Detail		To adjust the image reading start position in the horizontal scanning direction at copyboard reading. When replacing the Main Controller PCB, enter the value of service label. When the non-image width is larger than the standard value, set the smaller value. When out of original area is copied, set the larger value. As the value is incremented by 1, the image position moves to the front by 0.1mm.
Use Case		- When replacing the Reader Unit - When replacing the CIS Unit (Scanner Unit) - When replacing the Main Controller PCB
Adj/Set/Operate Method		Enter the setting value (switch negative / positive by * key) and press Apply key.
Caution		After the setting value is changed, write the changed value in the service label.
Display/Adj/Set Range		-15 to 15
Unit		0.1 mm
Default Value		0
ADJ-Y-DF		Adj img pstn in ADF mode:horz scan
Detail		To adjust the image reading start position in the horizontal scanning direction at ADF reading. When replacing the Main Controller PCB, enter the value of service label. As the value is incremented by 1, the image position moves to the front by 0.1mm.
Use Case		- When replacing the ADF - When replacing the CIS Unit (Scanner Unit) - When replacing the Main Controller PCB
Adj/Set/Operate Method		Enter the setting value (switch negative / positive by * key) and press Apply key.
Caution		After the setting value is changed, write the changed value in the service label.
Display/Adj/Set Range		-15 to 15
Unit		0.1 mm
Default Value		0

COPIER > ADJUST > ADJ-XY

ADJ-X-MG		Fine adj image ratio: vertical scanning
Detail	To make a fine adjustment of image magnification ratio in the vertical scanning direction by changing the reading cycle of CIS When replacing the Engine Controller PCB / clearing the RAM data, enter the value of service label. As the value is changed by 1, the image magnification ratio is changed by 0.01%. +: Reduce -: Enlarge	
Use Case	Enter the setting value (switch negative / positive by * key) and press Apply key.	
Adj/Set/Operate Method	After the setting value is changed, write the changed value in the service label.	
Caution	-200 to 200	
Display/Adj/Set Range	0.01%	
Appropriate Target Value	0	
STRD-POS		Adjustment of reading position at ADF stream reading
Detail	To adjust the reading position at ADF stream reading. When replacing the Main Controller PCB, enter the value of service label.	
Use Case	- When replacing the ADF - When replacing the CIS Unit (Scanner Unit) - When replacing the Main Controller PCB	
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.	
Caution	After the setting value is changed, write the changed value in the service label.	
Display/Adj/Set Range	-20 to 20	
Unit	0.1 mm	
Default Value	0	
Related Service Mode	COPIER > FUNCTION > INSTALL > STRD-POS	
ADJ-S		Adj image read start position: horz scan
Detail	To adjust the image reading start position in horizontal scanning direction when black line/white line occurs. When replacing the CCD Unit/clearing the RAM data of the Reader Unit, enter the value of service label. As the value is incremented by 1, the image position moves to the trailing edge side by 0.1 mm.	
Use Case	When clearing the Reader-related RAM data	
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.	
Caution	When COPIER> FUNCTION> INSTALL> RDSHDPOS is executed, the value of this item may change. If the value is changed, write the value in the service label.	
Display/Adj/Set Range	-20 to 20	
Unit	0.1 mm	
Default Value	0	
Related Service Mode	COPIER> FUNCTION> INSTALL> RDSHDPOS	
Supplement/Memo	The shading position can be adjusted automatically by COPIER> FUNCTION> INSTALL> RDSHDPOS.	

■ CCD

COPIER > ADJUST > CCD

W-PLT-X	White level data (X) entry of white plate
Detail	To enter the white level data (X) for the Standard White Plate. Enter the value (XXXXYYYYZZZZ) shown on the Barcode Label affixed at the upper left of the Copyboard Glass when replacing the ADF / Reader Unit, Reader Upper Cover Unit, and Main Controller PCB.
Use Case	- When replacing the ADF / Reader Unit - When replacing the Reader Upper Cover Unit - When replacing the Main Controller PCB
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Caution	After the setting value is changed, write the changed value in the service label.
Display/Adj/Set Range	7000 to 9999
Default Value	8273
Related Service Mode	COPIER. > ADJUST > CCD > W-PLT-Y, W-PLT-Z
W-PLT-Y	White level data (Y) entry of white plate
Detail	To enter the white level data (Y) for the Standard White Plate. When replacing the Main Controller PCB / clearing RAM data, enter the value of service label. When replacing the Copyboard Glass, enter the value of barcode label which is affixed on the glass.
Use Case	- When replacing the ADF / Reader Unit - When replacing the Reader Upper Cover Unit - When replacing the Main Controller PCB
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Caution	After the setting value is changed, write the changed value in the service label.
Display/Adj/Set Range	7000 to 9999
Default Value	8737
Related Service Mode	COPIER.> ADJUST > CCD > W-PLT-X, W-PLT-Z
W-PLT-Z	White level data (Z) entry of white plate
Detail	To enter the white level data (Z) for the Standard White Plate. When replacing the Main Controller PCB / clearing RAM data, enter the value of service label. When replacing the Copyboard Glass, enter the value of barcode label which is affixed on the glass.
Use Case	- When replacing the ADF / Reader Unit - When replacing the Reader Upper Cover Unit - When replacing the Main Controller PCB
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Caution	After the setting value is changed, write the changed value in the service label.
Display/Adj/Set Range	7000 to 9999
Default Value	9427
Related Service Mode	COPIER.> ADJUST > CCD > W-PLT-X, W-PLT-Y

COPIER > ADJUST > CCD

DFTAR-R Adjustment of shading target value (R) at ADF reading	
Detail	To adjust the shading target value of Red at ADF reading. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label. When replacing the Copyboard Glass / Scanner Unit (for front side), execute COPIER > FUNCTION > CCD > DF-WLVL1, DF-WLVL2 and write the value which is automatically set in the service label.
Use Case	- When replacing the ADF / Reader Unit - When replacing the Scanner (CIS) Unit - When replacing the Reader Upper Cover Unit - When replacing the Main Controller PCB
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 2048
Default Value	1105
Related Service Mode	COPIER > DISPLAY > CCD > TARGET-R COPIER > FUNCTION > CCD > DF-WLVL1, DF-WLVL2
DFTAR-G Adjustment of shading target value (G) at ADF reading	
Detail	To adjust the shading target value of Green at ADF reading. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label. When replacing the Copyboard Glass / Scanner Unit (for front side), execute COPIER > FUNCTION > CCD > DF-WLVL1, DF-WLVL2 and write the value which is automatically set in the service label.
Use Case	- When replacing the ADF / Reader Unit - When replacing the Scanner (CIS) Unit - When replacing the Reader Upper Cover Unit - When replacing the Main Controller PCB
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 2048
Default Value	1129
Related Service Mode	COPIER > DISPLAY > CCD > TARGET-G COPIER > FUNCTION > CCD > DF-WLVL1, DF-WLVL2
DFTAR-B Adjustment of shading target value (B) at ADF reading	
Detail	To adjust the shading target value of Blue at ADF reading. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label. When replacing the Copyboard Glass / Scanner Unit (for front side), execute COPIER > FUNCTION > CCD > DF-WLVL1, DF-WLVL2 and write the value which is automatically set in the service label.
Use Case	- When replacing the ADF / Reader Unit - When replacing the Scanner (CIS) Unit - When replacing the Reader Upper Cover Unit - When replacing the Main Controller PCB
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 2048
Default Value	1151
Related Service Mode	COPIER > DISPLAY > CCD > TARGET-B COPIER > FUNCTION > CCD > DF-WLVL1, DF-WLVL2

COPIER > ADJUST > CCD

DFTAR-BW	Adjustment of shading target value (B&W) at ADF reading
Detail	When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label. When replacing the Copyboard Glass / Scanner Unit (for front side), execute COPIER > FUNCTION > CCD > DF-WLVL3, DF-WLVL4 and write the value which is automatically set in the service label.
Use Case	- When replacing the ADF / Reader Unit - When replacing the Scanner (CIS) Unit - When replacing the Reader Upper Cover Unit - When replacing the Main Controller PCB
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 2048
Default Value	1072
Related Service Mode	COPIER > DISPLAY > CCD > TARGETBW COPIER > FUNCTION > CCD > DF-WLVL3, DF-WLVL4
50-RG	Color displacement (R and G lines) correction value in the vertical scanning direction (50%)
Detail	To correct the color displacement between R and G lines in vertical scanning direction at 50% copyboard reading When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Caution	After the setting value is changed, write the changed value in the service label.
Display/Adj/Set Range	-512 to 512
Unit	0.001 line
Default Value	-333
Supplement/Memo	50% reading: 300 dpi in horizontal scanning direction x 600 dpi in vertical scanning direction reading mode.
50-GB	Color displacement (G and B lines) correction value in the vertical scanning direction (50%)
Detail	To correct the color displacement between G and R lines in vertical scanning direction at 50% copyboard reading When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Caution	After the setting value is changed, write the changed value in the service label.
Display/Adj/Set Range	-512 to 512
Unit	0.001 line
Default Value	333
Supplement/Memo	50% reading: 300 dpi in horizontal scanning direction x 600 dpi in vertical scanning direction reading mode.

COPIER > ADJUST > CCD

100-RG	Color displacement (R and G lines) correction value in the vertical scanning direction (100%)
Detail	To correct the color displacement between R and G lines in vertical scanning direction at 100% copyboard reading When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Caution	After the setting value is changed, write the changed value in the service label.
Display/Adj/Set Range	-512 to 512
Unit	0.001 line
Default Value	-333
Supplement/Memo	100% reading: 600 dpi in horizontal scanning direction x 600 dpi in vertical scanning direction reading mode.
100-GB	Color displacement (G and B lines) correction value in the vertical scanning direction (100%)
Detail	To correct the color displacement between G and B lines in vertical scanning direction at 100% copyboard reading When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Caution	After the setting value is changed, write the changed value in the service label.
Display/Adj/Set Range	-512 to 512
Unit	0.001 line
Default Value	333
Supplement/Memo	100% reading: 600 dpi in horizontal scanning direction x 600 dpi in vertical scanning direction reading mode.
50DF-RG	Color displacement (R and G lines) correction value in the vertical scanning direction at ADF reading (50%)
Detail	To correct the color displacement between R and G lines in vertical scanning direction at 50% ADF reading When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Caution	After the setting value is changed, write the changed value in the service label.
Display/Adj/Set Range	-512 to 512
Unit	0.001 line
Default Value	-333
Supplement/Memo	50% reading: 300 dpi in horizontal scanning direction x 600 dpi in vertical scanning direction reading mode.

COPIER > ADJUST > CCD

50DF-GB	Color displacement (G and B lines) correction value in the vertical scanning direction at ADF reading (50%)
Detail	To correct the color displacement between G and B lines in vertical scanning direction at 50% ADF reading When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Caution	After the setting value is changed, write the changed value in the service label.
Display/Adj/Set Range	-512 to 512
Unit	0.001 line
Default Value	333
Supplement/Memo	50% reading: 300 dpi in horizontal scanning direction x 600 dpi in vertical scanning direction reading mode.
100DF-RG	Color displacement (R and G lines) correction value in the vertical scanning direction at ADF reading (100%)
Detail	To correct the color displacement between R and G lines in vertical scanning direction at 100% ADF reading When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Caution	After the setting value is changed, write the changed value in the service label.
Display/Adj/Set Range	-512 to 512
Unit	0.001 line
Default Value	-333
Supplement/Memo	100% reading: 600 dpi in horizontal scanning direction x 600 dpi in vertical scanning direction reading mode.
100DF-GB	Color displacement (G and B lines) correction value in the vertical scanning direction at ADF reading (100%)
Detail	To correct the color displacement between G and B lines in vertical scanning direction at 100% ADF reading When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Caution	After the setting value is changed, write the changed value in the service label.
Display/Adj/Set Range	-512 to 512
Unit	0.001 line
Default Value	333
Supplement/Memo	100% reading: 600 dpi in horizontal scanning direction x 600 dpi in vertical scanning direction reading mode.
OFST-BW0	Adjustment of CIS (Rear) at B&W reading
Detail	To adjust the offset of the CIS (Rear) when reading B&W original. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	-128 to 127
Default Value	0
Related Service Mode	COPIER > FUNCTION > CCD > BW-AGC

COPIER > ADJUST > CCD

OFST-BW1	Adjustment of CIS (Center) at B&W reading
Detail	To adjust the offset of the CIS (Center) when reading B&W original. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	-128 to 127
Default Value	0
Related Service Mode	COPIER > FUNCTION > CCD > BW-AGC
OFST-BW2	Adjustment of CIS (Front) at B&W reading
Detail	To adjust the offset of the CIS (Front) when reading B&W original. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	-128 to 127
Default Value	0
Related Service Mode	COPIER > FUNCTION > CCD > BW-AGC
OFST-CL0	Adjustment of CIS (Rear) at color reading
Detail	To adjust the offset of the CIS (Rear) when reading color original. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	-128 to 127
Default Value	0
Related Service Mode	COPIER > FUNCTION > CCD > CL-AGC
OFST-CL1	Adjustment of CIS (Center) at color reading
Detail	To adjust the offset of the CIS (Center) when reading color original. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	-128 to 127
Default Value	0
Related Service Mode	COPIER > FUNCTION > CCD > CL-AGC
OFST-CL2	Adjustment of CIS (Front) at color reading
Detail	To adjust the offset of the CIS (Front) when reading color original. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	-128 to 127
Default Value	0
Related Service Mode	COPIER > FUNCTION > CCD > CL-AGC

COPIER > ADJUST > CCD

OFST2CL0	Adj CIS-ch0 offset: color mode, 600 dpi
Detail	To adjust the offset (black level) of the Scanner Unit on channel 0 in color mode with 600 dpi.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 255
Default Value	0
Related Service Mode	COPIER > FUNCTION > CCD > CL-AGC
Supplement/Memo	It is updated automatically when the value of CL-AGC is changed.
OFST2CL1	Adj CIS-ch1 offset: color mode, 600 dpi
Detail	To adjust the offset (black level) of the Scanner Unit on channel 1 in color mode with 600 dpi.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 255
Default Value	0
Related Service Mode	COPIER > FUNCTION > CCD > CL-AGC
Supplement/Memo	It is updated automatically when the value of CL-AGC is changed.
OFST2CL2	Adj CIS-ch2 offset: color mode, 600 dpi
Detail	To adjust the offset (black level) of the Scanner Unit on channel 2 in color mode with 600 dpi.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 255
Default Value	0
Related Service Mode	COPIER > FUNCTION > CCD > CL-AGC
Supplement/Memo	It is updated automatically when the value of CL-AGC is changed.
GAIN-BW0	Adjustment of gain at B&W 300 dpi reading
Detail	To adjust the gain when reading B&W 300 dpi original. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 255
Default Value	0
Related Service Mode	COPIER > FUNCTION > CCD > BW-AGC
GAIN2BW0	Adjustment of gain at B&W 600 dpi reading
Detail	To adjust the gain when reading B&W 600 dpi original. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 255
Default Value	0
Related Service Mode	COPIER > FUNCTION > CCD > BW-AGC

COPIER > ADJUST > CCD

GAIN-CL0	Adjustment of gain at color 300 dpi reading
Detail	To adjust the gain when reading color 300 dpi original. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 255
Default Value	0
Related Service Mode	COPIER > FUNCTION > CCD > CL-AGC
GAIN2CL0	Adjustment of gain at color 600 dpi reading
Detail	To adjust the gain when reading color 600 dpi original. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 255
Default Value	0
Related Service Mode	COPIER > FUNCTION > CCD > CL-AGC
LED-BW-R	Adjustment of LED light-up time (R) at B&W reading
Detail	To adjust the red color LED lighting time when reading B&W original. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 2432
Default Value	1000
Related Service Mode	COPIER > FUNCTION > CCD > CL-AGC
LED-BW-G	Adjustment of LED light-up time (G) at B&W reading
Detail	To adjust the green color LED lighting time when reading B&W original. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 2432
Default Value	1000
Related Service Mode	COPIER > FUNCTION > CCD > BW-AGC
LED-BW-B	Adjustment of LED light-up time (B) at B&W reading
Detail	To adjust the blue color LED lighting time when reading B&W original. When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 2432
Default Value	1000
Related Service Mode	COPIER > FUNCTION > CCD > BW-AGC

COPIER > ADJUST > CCD

LED-CL-R	Adjustment of R color LED lighting time at reading color 300 dpi (primary light source)
Detail	To adjust the lighting time of the red color LED which is a primary light source of the Scanner Unit in color mode with 300 dpi.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 8192
Default Value	2818
Related Service Mode	COPIER> FUNCTION> CCD> CL-AGC
LED-CL-G	Adjustment of G color LED lighting time at reading color 300 dpi (primary light source)
Detail	To adjust the lighting time of the green color LED which is a primary light source of the Scanner Unit in color mode with 300 dpi.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 8192
Default Value	896
Related Service Mode	COPIER> FUNCTION> CCD> CL-AGC
LED-CL-B	Adjustment of B color LED lighting time at reading color 300 dpi (primary light source)
Detail	To adjust the lighting time of the blue color LED which is a primary light source of the Scanner Unit in color mode with 300 dpi.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 8192
Default Value	1721
Related Service Mode	COPIER> FUNCTION> CCD> CL-AGC
LED2CL-R	Adjustment of R color LED lighting time at reading color 600 dpi (primary light source)
Detail	To adjust the lighting time of the red color LED which is a primary light source of the Scanner Unit in color mode with 600 dpi.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 8192
Default Value	3826
Related Service Mode	COPIER> FUNCTION> CCD> CL-AGC
LED2CL-G	Adjustment of G color LED lighting time at reading color 600 dpi (primary light source)
Detail	To adjust the lighting time of the green color LED which is a primary light source of the Scanner Unit in color mode with 600 dpi.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 8192
Default Value	1792
Related Service Mode	COPIER> FUNCTION> CCD> CL-AGC

COPIER > ADJUST > CCD

LED2CL-B	Adjustment of B color LED lighting time at reading color 600 dpi (primary light source)
Detail	To adjust the lighting time of the blue color LED which is a primary light source of the Scanner Unit in color mode with 600 dpi.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 8192
Default Value	5924
Related Service Mode	COPIER> FUNCTION> CCD> CL-AGC

■ PASCAL

COPIER > ADJUST > PASCAL

OFST-P-K	Bk density adj at test print reading
Detail	To adjust the offset of Bk color test print reading signal at Auto Adjust Gradation (Full Adjust). When replacing the Main Controller PCB / clearing the RAM data, enter the value of service label. As the greater value is set, the image after adjustment gets darker.
Use Case	When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Caution	After the setting value is changed, write the changed value in the service label.
Display/Adj/Set Range	-32 to 32
Default Value	0

■ FEED-ADJ

COPIER > ADJUST > FEED-ADJ

ADJ-C1	Adjustment of the image write start position in the horizontal scanning direction at pickup from the standard cassette
Detail	To adjust the image write start position in the horizontal scanning direction when picking up paper from the standard cassette.
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Display/Adj/Set Range	-12 to 12
Default Value	0 (According to the setting at shipment)
ADJ-C2	Adjustment of the image write start position in the horizontal scanning direction at pickup from the option cassette
Detail	To adjust the image write start position in the horizontal scanning direction when picking up paper from the option cassette.
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Display/Adj/Set Range	-12 to 12
Default Value	0 (According to the setting at shipment)
ADJ-MF	Adjustment of the image write start position in the horizontal scanning direction at pickup from the Multi-purpose Tray
Detail	To adjust the image write start position in the horizontal scanning direction when picking up paper from the Multi-purpose Tray.
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Display/Adj/Set Range	-12 to 12
Default Value	0 (According to the setting at shipment)

COPIER > ADJUST > FEED-ADJ

ADJ-REFE	Adjustment of the image write start position in the horizontal scanning direction at 2-sided pickup
Detail	To adjust the image write start position in the horizontal scanning direction at 2-sided pickup.
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Display/Adj/Set Range	-12 to 12
Default Value	0 (According to the setting at shipment)

■ PANEL

COPIER > ADJUST > PANEL

TOUCHCHK	Correction of coordinate position of Touch Panel
Detail	To correct the coordinate on the Touch Panel.
Use Case	When a problem occurs to the coordinate position in such a way that a position different from the one that was touched reacts.
Adj/Set/Operate Method	Touch the "+" (plus)" mark displayed on the Touch Panel with something with a sharp tip such as a pen.
TOUCH_R	Flag to check whether the correction of coordinates on the Touch Panel was properly executed
Detail	To check whether the correction of coordinates on the Touch Panel was properly executed. 1 is displayed when the correction of coordinates is properly executed. 0 is displayed when it fails.
Use Case	When executing the correction of coordinates after replacing the Touch Panel with a new one
Display/Adj/Set Range	0 to 1 0: Not executed 1: Executed
Default Value	0

FUNCTION

■ CCD

COPIER > FUNCTION > CCD

DF-WLVL1	White level adj in book mode: color
Detail	To adjust the white level for copyboard scanning automatically by setting the paper which is usually used by the user on the Copyboard Glass.
Use Case	- When replacing the Copyboard Glass - When replacing the CIS Unit - When replacing the ADF / Reader Unit
Adj/Set/Operate Method	1) Set paper on the Copyboard Glass. 2) Select the item, and then press Yes key.
Caution	Be sure to execute DF-WLVL2 in a row.
Related Service Mode	COPIER > ADJUST > CCD > DFTAR-R, DFTAR-G, DFTAR-B COPIER > FUNCTION > CCD > DF-WLVL2

COPIER > FUNCTION > CCD

DF-WLVL2	White level adj in ADF mode: color
Detail	To adjust the white level for ADF scanning automatically by setting the paper which is usually used by the user on the ADF.
Use Case	- When replacing the Copyboard Glass - When replacing the CIS Unit - When replacing the ADF / Reader Unit
Adj/Set/Operate Method	1) Set paper on the ADF. 2) Select the item, and then press Yes key.
Caution	Be sure to execute this item after DF-WLVL1.
Related Service Mode	COPIER > ADJUST > CCD > DFTAR-R, DFTAR-G, DFTAR-B COPIER > FUNCTION > CCD > DF-WLVL1
DF-WLVL3	White level adj in book mode (B&W)
Detail	To adjust the white level for copyboard scanning automatically by setting the paper which is usually used by the user on the Copyboard Glass.
Use Case	- When replacing the Copyboard Glass - When replacing the CIS Unit - When replacing the ADF / Reader Unit
Adj/Set/Operate Method	1) Set paper on the Copyboard Glass. 2) Select the item, and then press Yes key.
Caution	Be sure to execute DF-WLVL4 in a row.
Related Service Mode	COPIER > ADJUST > CCD > DFTAR-BW COPIER > FUNCTION > CCD > DF-WLVL4
DF-WLVL4	White level adj in ADF mode (B&W)
Detail	To adjust the white level for ADF scanning automatically by setting the paper which is usually used by the user on the DADF.
Use Case	- When replacing the Copyboard Glass - When replacing the CIS Unit - When replacing the ADF / Reader Unit
Adj/Set/Operate Method	1) Set paper on the ADF. 2) Select the item, and then press Yes key.
Caution	Be sure to execute this item after DF-WLVL3.
Related Service Mode	COPIER > ADJUST > CCD > DFTAR-BW COPIER > FUNCTION > CCD > DF-WLVL3
CL-AGC	CIS intensity adjustment in ADF (color)
Detail	To adjust the black/white level of the CIS for ADF scanning automatically by setting the paper which is usually used by the user on the ADF. (For color scanning)
Use Case	- When replacing the Reader Unit - When replacing the CIS Unit
Adj/Set/Operate Method	1) Set paper on the ADF. 2) Select the item, and then press Yes key.
Related Service Mode	COPIER > FUNCTION > CCD > BW-AGC

COPIER > FUNCTION > CCD

BW-AGC	CIS intensity adjustment in ADF (B&W)
Detail	To adjust the black/white level of the CIS for ADF scanning automatically by setting the paper which is usually used by the user on the ADF. (For B&W scanning) Setting values of the following service modes are automatically calculated: COPIER > ADJUST > CCD > OFST-BW0/1/2, GAIN-BW0, LED-BW-R/G/B.
Use Case	- When replacing the Reader Unit - When replacing the CIS Unit
Related Service Mode	COPIER > FUNCTION > CCD > CL-AGC COPIER > ADJUST > CCD > OFST-BW0 COPIER > ADJUST > CCD > OFST-BW1 COPIER > ADJUST > CCD > OFST-BW2 COPIER > ADJUST > CCD > GAIN-BW0 COPIER > ADJUST > CCD > LED-BW-R COPIER > ADJUST > CCD > LED-BW-G COPIER > ADJUST > CCD > LED-BW-B

■ CLEAR

COPIER > FUNCTION > CLEAR

R-CON	Initialization of Reader / ADF
Detail	To initialize the factory adjustment values of the Reader / ADF.
Use Case	When clearing RAM data of the Main Controller PCB
Adj/Set/Operate Method	Press Yes key.
SRVC-DAT	Clearing of service mode setting values
Detail	To clear the service mode setting values. The user mode setting values are not cleared. The factory adjustment values of the Reader / ADF are not initialized.
Adj/Set/Operate Method	1) Press Yes key. 2) Turn OFF / ON the main power switch.
COUNTER	Clearing of service counter
Detail	To clear the counter by maintenance / part/mode. The numerator printed on a system dump list becomes 0.
Adj/Set/Operate Method	1) Press Yes key. 2) Turn OFF / ON the main power switch.
HIST	Clear of logs
Detail	To clear the communication management / print / jam / error log.
Use Case	When clearing logs
Adj/Set/Operate Method	1) Press Yes key. 2) Turn OFF / ON the main power switch.

COPIER > FUNCTION > CLEAR

CARD		Clearing of Card Reader connection info
Detail		To clear the information on connection of the Copy Card Reader-F1. The data related to the card ID (department) is cleared, and the ID and password of the system administrator are initialized.
Use Case		When removing the Card Reader-F1
Adj/Set/Operate Method		When removing the Card Reader-F1 1) Disable the department ID management. 2) Select the item, and then press Yes key. 3) In COPIER > FUNCTION > CLEAR > CARD, clear the information on connection of the Copy Card Reader-F1. 4) Execute COPIER > FUNCTION > CLEAR > E719-CLR. 5) Turn OFF the main power. 6) Remove the Card Reader-F1. 7) Turn ON the main power.
Caution		- Execute this item after disabling the department ID management via LUI or RUI - Then, clear the information on connection of the Copy Card Reader-F1 and execute E719-CLR (clear E71)
Related Service Mode		COPIER > FUNCTION > CLEAR > E719-CLR
E719-CLR		Clearing of E719 error
Detail		To clear E719 error (communication error with the Card Reader).
Use Case		When removing the Card Reader-F1
Adj/Set/Operate Method		1) Press Yes key. 2) Turn OFF / ON the main power switch.
Related Service Mode		COPIER > FUNCTION > CLEAR > CARD
ALL		Clearing of setting information
Detail		Clear/initialize the following setting information according to the location set in COPIER > OPTION > BODY > LOCALE, SIZE-LC: - User mode setting values - Service mode setting values (excluding service counter) - ID and password of the system administrator - Communication management / printing / jam / error history - E719-CLR The following is not initialized: - Service counter - Factory adjustment values of the Reader / ADF
Use Case		At installation
Adj/Set/Operate Method		1) Press Yes key. 2) Turn OFF / ON the main power switch.
Related Service Mode		COPIER > OPTION > BODY > LOCALE, SIZE-LC
ERDS-DAT		Initialization of Embedded-RDS setting value
Detail		To initialize the Embedded-RDS setting values. ON / OFF of Embedded-RDS, UGW (remote monitoring service system) port number, and communication error log set in service mode are initialized.
Use Case		When upgrading the version of Bootable in the Embedded-RDS environment
Adj/Set/Operate Method		Select the item, and then press Yes key.
Caution		Use of the SRAM in Embedded-RDS differs depending on the Bootable version. Therefore, unless initialization is executed at the time of version upgrade, data inconsistency occurs.
Related Service Mode		COPIER > FUNCTION > INSTALL > E-RDS, RGW-PORT, COM-LOG
Supplement/Memo		Embedded-RDS: Function to send device information such as the device counter, failure, and consumables to UGW via SOAP protocol UGW (Universal Gate Way): Remote monitoring service system

■ MISC-R

COPIER > FUNCTION > MISC-R

SCANLAMP		Lighting check of CIS Unit LED
Detail	To light up CIS Unit LED for 3 seconds. It lights up in the order of R, G, B, R, G and B.	
Use Case	When replacing the CIS Unit LED	
Adj/Set/Operate Method	Select the item, and then press Yes key.	
Display/Adj/Set Range	0 to 1	
Default Value	0	
Required Time	3 seconds	
SCAN-ON		Execution of copyboard reading
Detail	To execute reading of the original on the Copyboard Glass.	
Adj/Set/Operate Method	1. Place paper on the Copyboard Glass. 2. Select the item, and then press Yes key.	
Display/Adj/Set Range	0 to 1	
Default Value	0	

■ MISC-P

COPIER > FUNCTION > MISC-P

SRVC-DAT		Output of system data list/system dump list
Detail	To execute report output of the system data list and the system dump list. System data list: The service software switches and parameters used in FAX function System dump list: The number of sends/receives, the number of pages sent/received, the number of sheets printed / read, the number of errors, etc.	
Adj/Set/Operate Method	Select the item, and then press Yes key.	
Supplement/Memo	FAX model only	
SYS-DAT		Output of system data list
Detail	To execute report output of the system data list. The service software switches and parameters used in FAX function are output.	
Adj/Set/Operate Method	Select the item, and then press Yes key.	
Supplement/Memo	FAX model only	
SYS-DMP		Output of system dump list
Detail	To execute report output of the system dump list. The number of sends/receives, the number of pages sent/received, the number of sheets printed/read, the number of errors, etc. are output.	
Adj/Set/Operate Method	Select the item, and then press Yes key.	
Supplement/Memo	FAX model only	
CNTR		Output of counter report
Detail	To output the counter report. The usage of functions (reading, recording, communication and copy) is output.	
Adj/Set/Operate Method	Select the item, and then press Yes key.	
ERR-LOG		Output of error log report
Detail	To output the error log report.	
Adj/Set/Operate Method	Select the item, and then press Yes key.	
SPEC		Output of spec report
Detail	To output the spec report. The current device specifications such as the location, model information, and ROM version are output.	
Adj/Set/Operate Method	Select the item, and then press Yes key.	

COPIER > FUNCTION > MISC-P

ERDS-LOG		Output of Embedded-RDS log
Detail	To execute report output of the log relating to Embedded-RDS. The date, time, code, and details (up to 130 characters) of each error that occurred are output.	
Use Case	When using Embedded-RDS	
Adj/Set/Operate Method	Select the item, and then press Yes key.	
Related Service Mode	COPIER> FUNCTION> INSTALL> COM-LOG	
Supplement/Memo	Embedded-RDS: Function to send device information such as the device counter, failure, and consumables to UGW via SOAP protocol UGW (Universal Gate Way): Remote monitoring service system	
KEY-HIST		Output of key log report
Detail	To output the key log report. The key log up to the time the FAX transmission task was input (the [START] key was pressed) is output.	
Adj/Set/Operate Method	Select the item, and then press Yes key.	
Supplement/Memo	FAX model only	

■ SYSTEM

COPIER > FUNCTION > SYSTEM

PANEL-UP		Download from USB memory (PANEL)
Detail	To perform downloading when PANEL exists in the root directory of the USB memory.	
Use Case	At upgrade	
Adj/Set/Operate Method	1) Install the USB memory. 2) Select the item, and then select Yes. 3) Turn OFF and the ON the main power.	
Caution	Do not turn OFF / ON the power before "Executing..." disappears.	
Display/Adj/Set Range	Yes / No	
Related Service Mode	COPIER > FUNCTION > SYSTEM > DOWNLOAD, BKUP-UP	
LOGWRITE		Writing sublog to USB memory
Detail	To write sublog that includes the following information to the USB memory. - Job list (job name, user name, address book) - Communications log (address book, user name) - Job log (user name, job name)	
Use Case	When analyzing the cause of a problem	
Adj/Set/Operate Method	1) Install the USB memory. 2) Select the item, and then select Yes. 3) Turn OFF and the ON the main power.	
Caution	Do not turn OFF / ON the power before "Executing..." disappears.	
Display/Adj/Set Range	Yes / No	
IMPORT		Reading of service mode setting value from USB memory
Detail	To write the service mode setting values (excluding those related to Reader / ADF) to the USB memory.	
Use Case	After replacing the Main Controller PCB	
Adj/Set/Operate Method	1) Install the USB memory. 2) Select the item, and then press Yes. 3) Turn OFF and the ON the main power.	
Caution	Do not turn OFF / ON the power before "Executing..." disappears.	

COPIER > FUNCTION > SYSTEM

EXPORT	Writing of service mode setting value to USB memory
Detail	To write the service mode setting values (excluding those related to Reader/ADF) to the USB memory.
Use Case	When replacing the Main Controller PCB as a measure against failures
Adj/Set/Operate Method	1) Install the USB memory. 2) Select the item, and then press Yes.
Caution	"Executing..." disappears when writing is completed.
SAVE-SM	Backup of service mode
Detail	To record the backup of service mode in the device using DCM.
Use Case	When saving the state of the device before changing the service mode setting values.
RSTR-SM	Restoration of service mode
Detail	To restore the backup data in the device.
Use Case	When returning the state of the device to a previous one after having changed the service mode setting values.
LOG2USB	Output of log saved in eMMC to a USB
Detail	Output of log saved in eMMC to a USB
Use Case	When collecting debug log.
Adj/Set/Operate Method	1) Install the USB memory. 2) Select the item, and then press Yes.
LOG-DEL	Deletion of log saved in eMMC
Detail	Deletion of log saved in eMMC
Use Case	When deleting log that has become unnecessary

■ SPLMAN

COPIER > FUNCTION > SPLMAN

SPL14159	Fixing of USB device ID
Detail	To fix the USB device ID to "000000000000". Driver for each machine is installed to a PC. However, by fixing the serial number, the PC considers that any connected machine to be the same machine; thus, there will be no need to install the drivers many times.
Adj/Set/Operate Method	1) Enter the value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range	0 to 1 0 : OFF 1 : ON
Default Value	0
SPL65677	Increase of paper leading edge margin
Detail	To increase the margin on the leading edge of paper. As the value is incremented by 1, the margin is increased by 0.1 mm. The value obtained by adding this value and SPL68676 (decrease of the margin) is applied.
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range	0 to 20
Unit	0.1 mm
Default Value	0
Related Service Mode	COPIER > FUNCTION > SPLMAN > SPL68676

COPIER > FUNCTION > SPLMAN

SPL68676	Decrease of paper leading edge margin
Detail	To decrease the margin on the leading edge of paper. As the value is incremented by 1, the margin is decreased by 0.1 mm. The value obtained by adding this value and SPL65677 (increase of the margin) is applied.
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range	0 to 20
Unit	0.1 mm
Default Value	0
Related Service Mode	COPIER > FUNCTION > SPLMAN > SPL65677
SPL68677	Increase of paper right and left margins
Detail	To increase the margin on the right and left of paper. As the value is incremented by 1, the margin is increased by 0.1 mm. The value obtained by adding this value and SPL25607 (decrease of the margin) is applied.
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range	0 to 20
Unit	0.1 mm
Default Value	0
Related Service Mode	COPIER > FUNCTION > SPLMAN > SPL25607
SPL25607	Decrease of paper right and left margins
Detail	To decrease the margin on the right and left of paper. As the value is incremented by 1, the margin is decreased by 0.1 mm. The value obtained by adding this value and SPL68677 (increase of the margin) is applied.
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range	0 to 20
Unit	0.1 mm
Default Value	0
Related Service Mode	COPIER > FUNCTION > SPLMAN > SPL68677
SPL93822	Setting of department ID count all clear
Detail	To set whether to disable clearing of all department ID counts.
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Caution	Be sure to perform this mode after consulting with the system administrator at user's site.
Display/Adj/Set Range	0 to 1 0: Disabled, 1: Enabled
Default Value	0
Related Service Mode	COPIER > FUNCTION > SPLMAN > SPL78788
SPL78788	Setting of department ID count clear
Detail	To set whether to disable clearing of department ID count.
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Caution	Be sure to perform this mode after consulting with the system administrator at user's site.
Display/Adj/Set Range	0 to 1 0: Disabled, 1: Enabled
Default Value	0
Related Service Mode	COPIER > FUNCTION > SPLMAN > SPL93822

COPIER > FUNCTION > SPLMAN

SPL71100	Setting of the duty of Off-hook PCB
Detail	This is the mode to make handsets of particular manufacturers to ring when fax reception mode is set to "Fax / Tel (Auto Switch)".
Use Case	When fax reception mode is set to FAX/TEL switching
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range	1 to 99
Default Value	50
Supplement/Memo	FAX model only
SPL00171	To change the maximum auto sleep shift time.
Detail	To change the maximum value of auto sleep shift time in Settings/Registration> Timer Settings> Auto Sleep Time.
Use Case	When changing the setting time to shift to auto sleep mode
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range	From 0 (Default for Europe) to 60 min From 1 (Default for locations other than Europe) to Maximum value for each model
Default Value	1
SPL80100	Mask setting at copyboard scanning
Detail	To cancel the image mask occurs on the left edge at copyboard scanning.
Use Case	Upon request from user who does not satisfy with the mask on the left edge
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range	0: Mask value according to the specifications of each job 1: No mask (0 mm)
Default Value	0
SPL27354	PC-less update, RMDS environment setting
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range	0: Production environment / Release environment 1: Production environment / Staging environment 2: Maintenance environment 1 / Release environment 3: Maintenance environment 1 / Staging environment 4: Maintenance environment 2 / Release environment 5: Maintenance environment 2 / Staging environment
Default Value	0
SPL84194	ON / OFF of E-RDS function
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range	0 to 1
Default Value	0

COPIER > FUNCTION > SPLMAN

SPL32620		Switching to enable / disable PC-less update
Detail	To switch whether to enable the PC-less update function.	
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.	
Display/Adj/Set Range	0 to 1 0: Disabled 1: Enabled (default)	
Default Value	1	
SPL60061		Switching to display the connection destination URL setting of GoogleCloudPrint on the remote UI
Detail	To display the connection destination URL setting of GoogleCloudPrint on the remote UI.	
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.	
Display/Adj/Set Range	0 to 1 0: Do not display 1: Display	
Default Value	0	
SPL71700		Saving of Sublog stored in eMMC to a USB memory
Detail	To save Sublog stored in eMMC to a USB memory.	
Display/Adj/Set Range	0 to 1	
Default Value	0	
SPL01734		ON/OFF of RUI service mode function
Detail	To turn ON/OFF the RUI service mode function. (linked with OPTION>BODY>RMT-SW) 0: OFF* 1: ON This should be supported together with OPTION>BODY>RMT-SW as a set.	
Display/Adj/Set Range	0 to 1	
Default Value	0	

■ INSTALL

COPIER > FUNCTION > INSTALL

STRD-POS		Scan position auto adj in ADF mode
Detail	To adjust the ADF scanning position automatically.	
Use Case	At ADF installation/uninstallation	
Adj/Set/Operate Method	1) Set a paper for stream reading position adjustment, and then close the ADF. 2) Select the item, and then press Yes key. The operation automatically stops after the adjustment. 3) Write the value displayed by COPIER > ADJUST > ADJ-XY > STRD-POS in the service label.	
Caution	Write the adjusted value in the service label.	
Related Service Mode	COPIER > ADJUST > ADJ-XY > STRD-POS	
CARD-NUM		Card first number setting
Detail	To set the card first number to be used for Copy Card Reader-F1.	
Use Case	- At installation of the Card Reader-F1	
Adj/Set/Operate Method	Enter the value, and then press Apply key.	
Display/Adj/Set Range	1 to 2701	
Default Value	1	
Related Service Mode	COPIER > FUNCTION > INSTALL > CARD	

COPIER > FUNCTION > INSTALL

CARD		Set Card Reader management information
Detail		To set the following management information at installation of the Card Reader-F1. - Register numbers of 300 cards from the number set in CARD-NUM to the department ID. - Initialize ID and password of the system administrator.
Use Case		- At installation of the Card Reader-F1
Adj/Set/Operate Method		1) Select the item, and then press Yes key. 2) Turn OFF / ON the main power switch.
Related Service Mode		COPIER > FUNCTION > INSTALL > CARD-NUM
E-RDS		ON / OFF of Embedded-RDS
Detail		To set ON / OFF of Embedded-RDS function.
Use Case		When using Embedded-RDS
Adj/Set/Operate Method		1) Enter the value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Caution		Be sure to use ERDS, RGW-PORT, COM-TEST, COM-RSLT, and COM-LOG as a set.
Display/Adj/Set Range		0 to 1 0 : OFF 1 : ON
Default Value		0
Related Service Mode		COPIER > FUNCTION > INSTALL > RGW-PORT, COM-TEST, COM-RSLT, COM-LOG
Supplement/Memo		Embedded-RDS: Function to send device information such as the device counter, failure, and consumables to UGW via SOAP protocol UGW (Universal Gate Way): Remote monitoring service system
RGW-PORT		Setting of UGW port number when using Embedded-RDS
Detail		To set the port number of UGW to be used for Embedded-RDS.
Use Case		When using Embedded-RDS
Adj/Set/Operate Method		1) Enter the value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Caution		Be sure to use ERDS, RGW-PORT, COM-TEST, COM-RSLT, and COM-LOG as a set.
Display/Adj/Set Range		1 to 65535
Default Value		443
Related Service Mode		COPIER > FUNCTION > INSTALL > ERDS, COM-TEST, COM-RSLT, COM-LOG
Supplement/Memo		Embedded-RDS: Function to send device information such as the device counter, failure, and consumables to UGW via SOAP protocol UGW (Universal Gate Way): Remote monitoring service system
COM-TEST		Execution of Embedded-RDS communication test
Detail		To execute Embedded-RDS communication test. If the connection fails, the information is added to the communication error log.
Use Case		When using E-RDS
Adj/Set/Operate Method		Select the item, and then press Yes key.
Caution		Be sure to use ERDS, RGW-PORT, COM-TEST, COM-RSLT, and COM-LOG as a set.
Display/Adj/Set Range		0 to 1
Default Value		0
Related Service Mode		COPIER > FUNCTION > INSTALL > ERDS, RGW-PORT, COM-RSLT, COM-LOG
Supplement/Memo		Embedded-RDS: Function to send device information such as the device counter, failure, and consumables to UGW via SOAP protocol UGW (Universal Gate Way): Remote monitoring service system

COPIER > FUNCTION > INSTALL

COM-RSLT	Embedded-RDS communication test result
Detail	To display the Embedded-RDS communication test result.
Use Case	When using E-RDS
Adj/Set/Operate Method	N/A (Display only)
Caution	Be sure to use ERDS, RGW-PORT, COM-TEST, COM-RSLT, and COM-LOG as a set.
Display/Adj/Set Range	When not in execution : Unknown, When connection is completed : OK, When connection is failed : NG
Default Value	Unknown
Related Service Mode	COPIER > FUNCTION > INSTALL > ERDS, RGW-PORT, COM-TEST, COM-LOG
Supplement/Memo	Embedded-RDS: Function to send device information such as the device counter, failure, and consumables to UGW via SOAP protocol UGW (Universal Gate Way): Remote monitoring service system
COM-LOG	Embedded-RDS communication error log
Detail	To display the Embedded-RDS communication error log. The dates, times, and error codes of the latest 5 errors that occurred are displayed. As for the error detail information, the report can be output by executing COPIER > FUNCTION > MISC-P > ERDS-LOG.
Use Case	When using Embedded-RDS
Caution	Be sure to use ERDS, RGW-PORT, COM-TEST, COM-RSLT, and COM-LOG as a set.
Display/Adj/Set Range	Date : 6 digits Time : 4 digits Error code : 8 digits
Related Service Mode	COPIER > FUNCTION > INSTALL > ERDS, RGW-PORT, COM-TEST, COM-RSLT COPIER > FUNCTION > MISC-P > ERDS-LOG
Supplement/Memo	Embedded-RDS: Function to send device information such as the device counter, failure, and consumables to UGW via SOAP protocol UGW (Universal Gate Way): Remote monitoring service system



■ BODY

COPIER > OPTION > BODY

LOCALE	Setting of location
Detail	To set the location. At installation in areas other than Japan, perform the following procedure to match the setting information with that of the location.
Use Case	- At installation - When changing the location information
Adj/Set/Operate Method	1) Enter the setting value under LOCALE, and then press Apply key. 2) Set the paper size configuration under SIZE-LC. 3) Execute COPIER > FUNCTION > CLEAR > ALL. 4) Turn OFF/ON the main power switch.
Caution	Since COPIER> FUNCTION> CLEAR> ALL is executed when changing the location, the setting information of user mode, service mode, etc. is initialized. The setting information of this item is not initialized.
Display/Adj/Set Range	1 to 10 1 : Japan 2 : North America 3 : Korea 4 : China 5 : Taiwan 6 : Europe 7 : Asia 8 : Oceania 9 : Brazil 10 : Latin
Default Value	1
Related Service Mode	COPIER> FUNCTION> CLEAR> ALL COPIER> OPTION> BODY> SIZE-LC
SIZE-LC	Setting of paper size configuration
Detail	To set the paper size configuration. At installation in areas other than Japan, perform the following procedure to match the setting information with that of the location.
Use Case	- At installation - Upon user's request
Adj/Set/Operate Method	1) Set the location under LOCALE. 2) Set the paper size configuration under SIZE-LC, and then press Apply key. 3) Execute COPIER > FUNCTION > CLEAR > ALL. 4) Turn OFF / ON the main power switch.
Caution	Since COPIER > FUNCTION > CLEAR > ALL is executed when changing the location, the setting information of user mode, service mode, etc. is initialized. The setting information of this item is not initialized.
Display/Adj/Set Range	1 to 4 1 : AB configuration 2 : Inch configuration 3 : A configuration 4 : AB / Inch configuration
Related Service Mode	COPIER > FUNCTION > CLEAR > ALL COPIER > OPTION > BODY > LOCALE

COPIER > OPTION > BODY

MIBCOUNT		Setting of MIB collection charge counter
Detail		To set the range of charge counter information that can obtain MIB (Management Information Base).
Use Case		When preventing the Charge Counter MIB from being used by a third party
Adj/Set/Operate Method		1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range		0 to 2 0: All charge counters are obtained, 1: Only the displayed counter* is obtained, 2: All charge counters are not obtained *: Counter specified by the following: COPIER > OPTION > USER > COUNTER 1 to 6
Default Value		0
Related Service Mode		COPIER > OPTION > USER > COUNTER1 to 6
NS-CMD5		Setting of CRAM-MD5 authentication method at SMTP authentication
Detail		Restriction of the use of CRAM-MD5 authentication method at SMTP authentication When 1 is set, CRAM-MD5 authentication method is not used.
Use Case		Upon user's request
Adj/Set/Operate Method		1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range		0 to 1 0 : Used (SMTP server-dependent), 1 : Not used
Default Value		0
Supplement/Memo		SMTP authentication: Protocol in which user authentication function is added to SMTP, which is the protocol to be used for e-mail transmission. At the time of e-mail transmission, this protocol executes authentication of the user account and the password between the SMTP server and the user to approve e-mail transmission only when it's authenticated.
NS-PLN		Setting of plaintext authentication at SMTP authentication
Detail		To restrict use of PLAIN / LOGIN authentication, which is plaintext authentication, at the time of SMTP authentication under the environment where the communication packet is not encrypted. When 1 is set, plaintext authentication is not used.
Use Case		Upon user's request
Adj/Set/Operate Method		1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range		0 to 1 0 : Used (SMTP server-dependent) 1 : Not used
Default Value		0
Supplement/Memo		SMTP authentication: Protocol in which user authentication function is added to SMTP, which is the protocol to be used for e-mail transmission. At the time of e-mail transmission, this protocol executes authentication of the user account and the password between the SMTP server and the user to approve e-mail transmission only when it's authenticated.

COPIER > OPTION > BODY

NS-LGN		Setting of LOGIN authentication at SMTP authentication
Detail		Restriction of the use of LOGIN authentication method at SMTP authentication When 1 is set, LOGIN authentication method is not used.
Use Case		Upon user's request
Adj/Set/Operate Method		1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range		0 to 1 0 : Used (SMTP server-dependent) 1 : Not used
Default Value		0
Supplement/Memo		SMTP authentication: Protocol in which user authentication function is added to SMTP, which is the protocol to be used for e-mail transmission. At the time of e-mail transmission, this protocol executes authentication of the user account and the password between the SMTP server and the user to approve e-mail transmission only when it's authenticated.
SLPMODE		Setting of shift to sleep mode
Detail		To restrict shift to sleep mode 1/sleep mode 3. When 1 is set, the machine does not shift to sleep mode.
Use Case		When sleep failure occurs
Adj/Set/Operate Method		1) Enter the setting value, and then press Apply key. 2) Turn OFF/ON the main power switch.
Display/Adj/Set Range		0 to 1 0 : Shift is available. 1 : Shift is not available.
Default Value		0
SDTM-DSP		Setting of automatic shutdown menu display
Detail		It is a new function added to support LOT6. To display the auto shutdown menu in the machine supporting LOT6.
Adj/Set/Operate Method		1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Caution		Even the models not supporting auto shutdown function display the service mode item (In such case, the menu will not be displayed even 1 is set).
Display/Adj/Set Range		0 to 1 0 : Hide the menu 1 : Display the menu
Default Value		0
RMT-SW		ON/OFF of RUI service mode function
Detail		To set whether to enable the service mode function that can be used on remote UI.
Adj/Set/Operate Method		1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range		0 to 1 0 : OFF 1 : ON
Default Value		0

COPIER > OPTION > BODY

PSWD-SW		Service mode password level
Detail	To change the service mode password level.	
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.	
Display/Adj/Set Range	0 to 2 0: Password is not required 1: Password for service engineer is required 2: Passwords for service engineer and system administrator at user's site are required	
Default Value	0	
SM-PSWD		Password for service engineer
Detail	To set the password for service technician in 8-digit decimal number.	
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.	
Display/Adj/Set Range	1 to 99999999	
Default Value	11111111	

■ FNC-SW

COPIER > OPTION > FNC-SW

LCDSFLG		Flag to enable LOCAL CDS
Detail	To enable Local CDS.	
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.	
Display/Adj/Set Range	0 to 1 0 : Disabled 1 : Enabled	
Default Value	0	
CRG-PROC		Setting of the operation at the end of CRG life
Detail	To set the following 3 kinds of operations at the end of CRG life: Not stopped / Stopped once/ Completely stopped.	
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.	
Display/Adj/Set Range	0 to 2 0 : Not stopped (default of B&W machine) 1 : Stopped once (default for color machine) 2 : Completely stopped	
Default Value	0	
CRGLF-K		Reference value of components other than toner included in the CRG life (for K)
Detail	Reference value of the life of the components other than toner (Drum / Developing Assembly / waste toner) included in the life of CRG (for K)	
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.	
Display/Adj/Set Range	100 to 200	
Default Value	100	

■ DSPLY-SW

COPIER > OPTION > DSPLY-SW

CRGLW-LV		SW to display / hide the setting menu (user mode) of toner low threshold value
Detail	To switch whether to display the menu to set the threshold value in user mode which generates toner low.	
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.	
Display/Adj/Set Range	0 to 1	
Default Value	1	

■ IMG-MCON

COPIER > OPTION > IMG-MCON

REGM-SEL	Adjustment of fine density correction
Detail	To adjust fine density correction.
Use Case	When the density of fine line or text is dark of light at 1200 dpi printing.
Adj/Set/Operate Method	Set +1 to make the density of fine line or text darker, and -1 to make it lighter at 1200 dpi printing.
Display/Adj/Set Range	-1, 0, +1
Default Value	0

■ USER

COPIER > OPTION > USER

COUNTER1	Display of counter 1 type
Detail	To display counter type for counter 1 on the Counter Check screen.
Use Case	Upon user / dealer's request
Adj/Set/Operate Method	N/A (Display only)
Caution	No change is available.
Display/Adj/Set Range	0 to 999 0 : No registration
Default Value	It differs according to the location.
COUNTER2	Display of counter 2 type
Detail	To display counter type for counter 2 on the Counter Check screen.
Use Case	Upon user / dealer's request
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF/ON the main power switch.
Display/Adj/Set Range	0 to 999 0 : No registration
Default Value	It differs according to the location.
COUNTER3	Display of counter 3 type
Detail	To display counter type for counter 3 on the Counter Check screen.
Use Case	Upon user/dealer's request
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range	0 to 999 0 : No registration
Default Value	It differs according to the location.
COUNTER4	Display of counter 4 type
Detail	To display counter type for counter 4 on the Counter Check screen.
Use Case	Upon user/dealer's request
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range	0 to 999 0 : No registration
Default Value	0

COPIER > OPTION > USER

COUNTER5		Display of counter 5 type
Detail	To display counter type for counter 5 on the Counter Check screen.	
Use Case	Upon user / dealer's request	
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.	
Display/Adj/Set Range	0 to 999 0 : No registration	
Default Value	0	
COUNTER6		Display of counter 6 type
Detail	To display counter type for counter 6 on the Counter Check screen.	
Use Case	Upon user / dealer's request	
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.	
Display/Adj/Set Range	0 to 999 0 : No registration	
Default Value	0	
CNT-SW		Setting of charge counter display method
Detail	To set display method of the charge counter on the Counter Check screen. Set 1 to 3 to select a new method.	
Use Case	Upon user's request	
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.	
Display/Adj/Set Range	0 to 3 0 : Conventional method (type 1), 1: New method (type 2), 2: New method (type 3), 3: New method (type 4)	
Default Value	0	
CONTROL		Setting of PDL job charge method by CC-VI
Detail	To set charge method for PDL job by the control card interface "CC-VI" When outputting at insertion of the control card, set 1 (not counted) / 2 (counted)	
Use Case	Upon user's request	
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.	
Display/Adj/Set Range	0 to 2 0 : Output is available without control card. Not counted. 1 : Output is available at insertion of the card. Counted. 2 : Output is available at insertion of the card. Not counted.	
Default Value	0	
CTCHKDSP		ON/OFF of charge counter print
Detail	To set whether to print the charge counter on the Counter Check screen in the System Manager Data List. When 1 is set, the charge counter is printed.	
Use Case	Upon user's request	
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.	
Display/Adj/Set Range	0 to 1 0 : OFF 1 : ON	
Default Value	1	

COPIER > OPTION > USER

TNRB-SW	ON/OFF of toner replacement counter display
Detail	To set whether to display the toner replacement counter on the Counter Check screen. When 1 is set, the user can check the toner replacement counter.
Use Case	Upon user's request
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range	0 to 3 0 : Hide the Toner Cartridge replacement counter 1 : Display the Toner Cartridge replacement counter (No. 19x) 2 : Not used (same as the setting value of 0) 3 : Not used (same as the setting value of 0)
Default Value	0
SCALL-SW	ON/OFF of Service Call button display
Detail	To set whether to display or hide the Service Call button on the Touch Panel. When 1 is set, the button is displayed.
Use Case	When the sales company supports service initiated by the Service Call button
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 1 0 : OFF 1 : ON
Default Value	0
SCALLCMP	Setting of Service Call complete notice
Detail	To set whether to notify the completion of Service Call. With this setting enabled, a notification of repair completion is sent to UGW to clear the Service Call status that is retained internally.
Use Case	When service technician uses this mode after completing repair
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Caution	After executing "1: Notified", the setting value becomes 0 immediately.
Display/Adj/Set Range	0 to 1 0 : Not notified 1 : Notified
Default Value	0
PS-MODE	Setting of compatible mode at PS usage
Detail	To set for compatibility with existing machine regarding image process or print specification with PS print. Setting of a value other than the setting values means that multiple settings are combined. (Example: 7=1+2+4)
Use Case	At replacement
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range	0 to 63 8 : Change of default value of StrokeAdjust
Default Value	0
SMD-EXPT	Export of service mode
Detail	To enable the export of service mode setting values from RUI.
Display/Adj/Set Range	0 to 1 0: Disabled 1: Enabled
Default Value	0

COPIER > OPTION > USER

ACC-SLP		Switching of the restriction to shift to sleep mode 3 when the card is connected
Detail		To switch whether to restrict the shift to sleep 3 when the card is connected.
Adj/Set/Operate Method		Enter the setting value, and then press Apply key.
Display/Adj/Set Range		0 to 1 0 : The machine does not shift to sleep mode 3. 1 : The machine shifts to sleep mode 3.
Default Value		1
RPL-IMP		Turning ON/OFF at replacement mode
Detail		To be able to import the settings values (which are exported by DCM and can only be imported to host machine) unique to the model such as IPv4 addresses to a different machine by turning ON the replacement mode.
Use Case		When migrating the settings at replacement of a host machine with a different one of the same model.
Display/Adj/Set Range		0 to 1
Default Value		0

■ ACC

COPIER > OPTION > ACC

CARD-SW		Setting of the screen display when the Coin Manager is connected
Detail		To set the screen display when the Coin Manager is connected.
Adj/Set/Operate Method		Enter the setting value, and then press Apply key.
Display/Adj/Set Range		0 to 2 0 : "Insert the card." 1 : "Use external device for authentication." 2 : "Use the external device for payment."
CC-SPSW		Setting of Control Interface Kit-C1
Detail		To set whether to support the Control Interface Kit-C1.
Use Case		At installation of Coin Manager
Adj/Set/Operate Method		1) Enter the setting value, and then press Apply key. 2) Turn OFF/ON the main power switch.
Caution		Parallel use with Card Reader-F1 is not available.
Display/Adj/Set Range		0 to 1 0 : Not supported 1 : Supported
Default Value		0
WLAN		Presence/absence of the wireless LAN function
Detail		To set whether to enable the wireless LAN function.
Adj/Set/Operate Method		1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range		0 to 1 0 : Disabled 1 : Enabled
Default Value		0 (Model where wireless LAN is provided as an option), 1 (Wireless LAN model)

COPIER > OPTION > ACC

WLANMODE	Setting of IEEE802.11n
Detail	To set whether to enable IEEE802.11n which is the wireless LAN standard.
Use Case	Upon user's request
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Display/Adj/Set Range	0 to 1 0 : Disabled 1 : Enabled
Default Value	1 (All models)

UNIF-OF	Forcible deactivation of the uniFLOW function
Detail	If this switch is set to 1 and the device power is turned OFF and then ON while the uniFLOW function is in active state, the uniFLOW function is forcibly deactivated. In addition, when this switch is set to 1, Activate/Deactivate request from the server is ignored.
Use Case	Avoidance operation performed by a service engineer in the event of a uniFLOW failure. Used when, for example, connection to the uniFLOW server fails due to an error in the device.
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF/ON the main power switch.
Caution	Use only when necessary. After the work is completed, set the value back to 0.
Display/Adj/Set Range	0 to 1 0: Disabled, 1: Enabled
Default Value	0

■ LCNS-TR

COPIER > OPTION > LCNS-TR

ST-BRDIM	Disabling and transfer of the license of barcode reading (BarDIMM) function
Detail	To disable and then transfer the license of barcode reading (BarDIMM) function. The function is turned OFF by changing the setting value from 1 to 0 and then turning OFF and then ON the power.device is displayed under TR-BRDIM. Once 0 is set, the function is not turned ON even if returning the setting value to 1. The license key needs to be reissued from LMS to use the function again.
Use Case	- When transferring the license to another device - When checking the installation status
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.
Caution	The function is turned OFF after changing the setting value from 1 to 0 and turning OFF / ON the power.
Display/Adj/Set Range	0 to 1 0 : OFF 1 : ON
Default Value	0
Supplement/Memo	LMS (License Management Server): Server which issues licenses

COPIER > OPTION > LCNS-TR

TR-BRDIM		Transfer license key display of BarDIMM function
Detail	To display the transfer license key issued when disabling and then transferring the BarDIMM function. When the setting value is changed from 1 to 0 and then the power is turned OFF and then ON, the function is turned OFF, but the transfer license key is not issued. (The license is not transferred to other devices.) The transfer license key is used to transfer the license from this device to another one to use the function in the device.	
Use Case	- When replacing the device	
Adj/Set/Operate Method	1) Select ST-BRDIM. 2) Enter 0, and then press Apply key. The transfer license key is displayed under TR-BRDIM.	
Display/Adj/Set Range	24 digits	
Default Value	0	
ST-U-RDS		Disabling and transfer of the license of ERDS function
Detail	To disable and then transfer the license of ERDS function The function is turned OFF by changing the setting value from 1 to 0 and then turning OFF and then ON the power. device is displayed under TR-BRDIM. Once 0 is set, the function is not turned ON even if returning the setting value to 1. The license key needs to be reissued from LMS to use the function again.	
Use Case	- When transferring the license to another device - When checking the installation status	
Adj/Set/Operate Method	1) Enter the setting value, and then press Apply key. 2) Turn OFF / ON the main power switch.	
Caution	The function is turned OFF after changing the setting value from 1 to 0 and turning OFF / ON the power.	
Display/Adj/Set Range	0 to 1 0 : OFF 1 : ON	
Default Value	0	
Supplement/Memo	LMS (License Management Server): Server which issues licenses	
TR-U-RDS		Transfer license key display of ERDS function
Detail	To display the transfer license key issued when disabling and then transferring the ERDS function The transfer license key is used to transfer the license from this device to another one to use the function in the device.	
Use Case	- When replacing the device	
Adj/Set/Operate Method	1) Select ST-U-RDS. 2) Enter 0, and then press Apply key. The transfer license key is displayed under TR-U-RDS.	
Display/Adj/Set Range	24 digits	
Default Value	0	

■ LCNS-OF

COPIER > OPTION > LCNS-OF

ST-BRDIM		Disabling and non-transfer of the license of barcode reading (BarDIMM) function
Detail		To disable and then not transfer the license of barcode reading (BarDIMM) function. The function is turned OFF when changing the setting value from 1 to 0, but the transfer license key is not issued. (The license is not transferred to other devices.) When 1 is set, the function is turned ON since the license key in use is enabled.
Use Case		- When the function is turned OFF - When checking the installation status
Adj/Set/Operate Method		1) Enter the setting value, and then press Apply key. 2) Turn OFF/ON the main power switch.
Caution		The function is turned OFF after changing the setting value from 1 to 0 and turning OFF/ON the power. The function is not turned ON even if changing the setting from 0 to 1. (Reregistration of the license key is required.)
Display/Adj/Set Range		0 to 1 0 : OFF 1 : ON
Default Value		0
ST-U-RDS		Disabling and non-transfer of the license of Setting of ERDS function
Detail		To disable and then not transfer the license of ERDS function. The function is turned OFF when changing the setting value from 1 to 0, but the transfer license key is not issued. (The license is not transferred to other devices.) When 1 is set, the function is turned ON since the license key in use is enabled.
Use Case		- When the function is turned OFF - When checking the installation status
Adj/Set/Operate Method		1) Enter the setting value, and then press Apply key. 2) Turn OFF/ON the main power switch.
Caution		The function is turned OFF after changing the setting value from 1 to 0 and turning OFF/ON the power. The function is not turned ON even if changing the setting from 0 to 1. (Reregistration of the license key is required.)
Display/Adj/Set Range		0 to 1 0 : OFF 1 : ON
Default Value		0

COUNTER

■ TOTAL

COPIER > COUNTER > TOTAL

SERVICE1		Service-purposed total counter 1
Detail		To advance the counter when a paper is delivered outside the printer. The counter is advanced regardless of the original size. The counter is not advanced by delivery in service mode.
Display/Adj/Set Range		0 to 99999999
Unit		Number of sheets
Default Value		0

COPIER > COUNTER > TOTAL

SERVICE2	Service-purposed total counter 2
Detail	To advance the counter when a paper is delivered outside the printer. The counter is advanced regardless of the original size. The counter is not advanced by delivery in service mode.
Display/Adj/Set Range	0 to 99999999
Unit	Number of sheets
Default Value	0
TTL	Total counter
Detail	To display the total of counters of COPY, PDL-PRT, FAX-PRT, RPT-PRT, and MD-PRT.
Display/Adj/Set Range	0 to 99999999
Unit	Number of sheets
Default Value	0
Related Service Mode	COPIER > COUNTER > TOTAL > COPY, PDL-PRT, FAX-PRT, RPT-PRT, MD-PRT
COPY	Total copy counter
Detail	To advance the counter when a paper is delivered outside the printer. The counter is advanced regardless of the original size. The counter is not advanced by delivery in service mode.
Display/Adj/Set Range	0 to 99999999
Unit	Number of sheets
Default Value	0
Related Service Mode	COPIER > COUNTER > TOTAL > TTL
PDL-PRT	PDL print counter
Detail	To count up when the PDL print is delivered outside the machine/2-sided printout is stacked. The counter is advanced regardless of the original size. The counter is not advanced by blank paper or delivery in service mode.
Display/Adj/Set Range	0 to 99999999
Unit	Number of sheets
Default Value	0
Related Service Mode	COPIER > COUNTER > TOTAL > TTL
FAX-PRT	FAX reception print counter
Detail	To count up when the FAX reception print is delivered outside the machine/2-sided printout is stacked. The counter is advanced regardless of the original size. The counter is not advanced by blank paper or delivery in service mode.
Display/Adj/Set Range	0 to 99999999
Unit	Number of sheets
Default Value	0
Related Service Mode	COPIER > COUNTER > TOTAL > TTL
Supplement/Memo	FAX model only
RPT-PRT	Report print counter
Detail	To count up when the report print is delivered outside the machine/2-sided printout is stacked. The counter is advanced regardless of the original size. The counter is not advanced by blank paper or delivery in service mode.
Display/Adj/Set Range	0 to 99999999
Unit	Number of sheets
Related Service Mode	COPIER > COUNTER > TOTAL > TTL

COPIER > COUNTER > TOTAL

MD-PRT		Media print counter
Detail	To count up when the media print is delivered outside the machine. The counter is advanced regardless of the original size. The counter is not advanced by blank paper or delivery in service mode.	
Display/Adj/Set Range	0 to 99999999	
Unit	Number of sheets	
Default Value	0	
Related Service Mode	COPIER > COUNTER > TOTAL > TTL	

2-SIDE		2-sided copy/print counter
Detail	To count up the number of 2-sided copies/prints when the copy/printout is delivered outside the machine/2-sided copy/printout is stacked. The counter is advanced regardless of the original size. The counter is not advanced by blank paper or delivery in service mode.	
Display/Adj/Set Range	0 to 99999999	
Unit	Number of times	
Default Value	0	

SCAN		Scan counter
Detail	To count up the number of scan operations when the scanning operation is complete. The counter is advanced regardless of the original size. The counter is not advanced by delivery in service mode.	
Display/Adj/Set Range	0 to 99999999	
Unit	Number of times	
Default Value	0	

■ PICK-UP

COPIER > COUNTER > PICK-UP

C1		Cassette 1 pickup total counter
Detail	To count up the number of sheets picked up from the Cassette 1 (standard Pickup Cassette). The counter is advanced regardless of the original size. The counter is advanced by printout in service mode.	
Display/Adj/Set Range	0 to 99999999	
Unit	Number of sheets	
Default Value	0	

C2		Cassette 2 pickup total counter
Detail	To count up the number of sheets picked up from the Cassette 2 (option Pickup Cassette). The counter is advanced regardless of the original size. The counter is advanced by printout in service mode.	
Display/Adj/Set Range	0 to 99999999	
Unit	Number of sheets	
Default Value	0	

C3		Cassette 3 pickup total counter
Detail	To count up the number of sheets picked up from the Cassette 3 (option Pickup Cassette). The counter is advanced regardless of the original size. The counter is advanced by printout in service mode.	
Display/Adj/Set Range	0 to 99999999	
Unit	Number of sheets	
Default Value	0	

COPIER > COUNTER > PICK-UP

MF	Multi-purpose Tray pickup total counter
Detail	To count up the number of sheets picked up from the Multi-purpose Tray Pickup Unit. The counter is advanced regardless of the original size. The counter is advanced by printout in service mode.
Display/Adj/Set Range	0 to 99999999
Unit	Number of sheets
Default Value	0
2-SIDE	2-sided pickup total counter
Detail	To count up the number of sheets picked up in duplex mode. The counter is advanced regardless of the original size. The counter is advanced by printout in service mode.
Display/Adj/Set Range	0 to 99999999
Unit	Number of sheets
Default Value	0

■ FEEDER

COPIER > COUNTER > FEEDER

FEED	ADF original pickup total counter
Detail	To count up the number of originals picked up from the ADF. The counter is advanced regardless of the original size.
Use Case	When checking the total counter of original pickup by ADF
Display/Adj/Set Range	0 to 99999999
Unit	Number of sheets
Default Value	0

■ JAM

COPIER > COUNTER > JAM

TOTAL	Printer total jam counter
Detail	To count up the number of total jam occurrences.
Use Case	When checking the total jam counter of printer
Display/Adj/Set Range	0 to 99999999
Unit	Number of times
Default Value	0
FEEDER	ADF total jam counter
Detail	When checking the total jam counter of ADF
Display/Adj/Set Range	0 to 99999999
Unit	Number of times
Default Value	0
2-SIDE	Duplex Unit jam counter
Detail	To count up the number of jam occurrences in the Duplex Unit.
Use Case	When checking the jam counter of Duplex Unit
Display/Adj/Set Range	0 to 99999999
Unit	Number of times
Default Value	0

COPIER > COUNTER > JAM

MF		Multi-purpose Pickup Tray jam counter
Detail		To count up the number of jam occurrences in the Multi-purpose Tray Pickup Unit. The counter is advanced by paper size mismatch or misprint.
Use Case		When checking the jam counter of Multi-purpose Pickup Tray
Display/Adj/Set Range		0 to 99999999
Unit		Number of times
Default Value		0
C1		Cassette 1 pickup jam counter
Detail		To count up the number of jam occurrences in the Cassette 1 (standard Pickup Cassette). The counter is advanced by paper size mismatch or misprint.
Display/Adj/Set Range		0 to 99999999
Unit		Number of times
Default Value		0
C2		Cassette 2 pickup jam counter
Detail		To count up the number of jam occurrences in the Cassette 2 (option Pickup Cassette). The counter is advanced by paper size mismatch or misprint.
Display/Adj/Set Range		0 to 99999999
Unit		Number of times
Default Value		0
C3		Cassette 3 pickup jam counter
Detail		To count up the number of jam occurrences in the Cassette 3 (option Pickup Cassette). The counter is advanced by paper size mismatch or misprint.
Display/Adj/Set Range		0 to 99999999
Unit		Number of times
Default Value		0

■ **DRBL-2**

COPIER > COUNTER > DRBL-2

DF-SP-PD		Separation Pad parts counter: ADF
Detail		When counting the number of sheets fed, a sheet of paper whose length in the vertical scanning direction exceeds 324 mm is counted as 2, and a sheet of paper other than that is counted as 1. Accumulated counter value
Use Case		When checking the consumption level of parts/replacing the parts
Adj/Set/Operate Method		To clear the counter value: Select the item, and then enter 0. Press Apply key.
Caution		Clear the counter value after replacement.
Display/Adj/Set Range		0 to 99999999
Unit		Number of sheets
Default Value		0
DF-SP-RL		ADF Pickup Roller parts counter
Detail		When counting the number of sheets fed, a sheet of paper whose length in the vertical scanning direction exceeds 324 mm is counted as 2, and a sheet of paper other than that is counted as 1. Accumulated counter value
Use Case		When checking the consumption level of parts/replacing the parts
Adj/Set/Operate Method		To clear the counter value: Select the item, and then enter 0. Press Apply key.
Caution		Clear the counter value after replacement.
Display/Adj/Set Range		0 to 99999999
Unit		Number of sheets
Default Value		0

FEEDER

ADJUST

FEEDER > ADJUST

DOCST	Fine adjustment of VSYNC timing at ADF reading [front side]
Detail	To make a fine adjustment of the VSYNC timing when reading the front side of original with ADF. Execute this item when the output image after ADF installation is displaced. When replacing the Main Controller PCB / clearing RAM, enter the value of service label. As the value is incremented by 1, the margin at the leadgin edge of image is reduced by 0.1%. (The image moves in the direction of the leading edge of the sheet.)
Use Case	- When installing the ADF - When replacing the Main Contoroller PCB/ clearing RAM data
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Display/Adj/Set Range	-30 to 30
Unit	0.1 mm
Default Value	0
LA-SPD	Fine adjustment of magnification ratio in vertical scanning direction at ADF stream reading [front side]
Detail	To make a fine adjustment of the image magnification ratio in vertical scanning direction when stream reading the front side of original with ADF. As the value is incremented by 1, the image is reduced by 0.01% in vertical scanning direction. (The feeding speed increases, and the image is reduced.)
Use Case	- When installing the ADF - When replacing the Main Controller PCB/ clearing RAM data
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Display/Adj/Set Range	-200 to 200
Unit	0.01%
Default Value	0
DOCST2	Fine adjustment of VSYNC timing at ADF reading [back side]
Detail	To make a fine adjustment of the VSYNC timing when reading the back side of original with ADF. Execute this item when the output image after ADF installation is displaced. When replacing the Main Controller PCB / clearing RAM, enter the value of service label. As the value is incremented by 1, the margin at the leading edge of the image is decreased by 0.1mm. (The image moves in the direction of the leading edge of the sheet.)
Use Case	- When installing the ADF - When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Display/Adj/Set Range	-30 to 30
Unit	0.1 mm
Default Value	0

FEEDER > ADJUST

LA-SPD2	Fine adjustment of magnification ratio in vertical scanning direction at ADF stream reading [back side]
Detail	To make a fine adjustment of the image magnification ratio in vertical scanning direction when stream reading the back side of original with ADF. As the value is incremented by 1, the image is reduced by 0.01% in vertical scanning direction. (The feeding speed increases, and the image is reduced.)
Use Case	- When installing the ADF - When replacing the Main Controller PCB / clearing RAM data
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Display/Adj/Set Range	-200 to 200
Unit	0.01%
Default Value	0
DOCSTDUP	DADF img lead edge margin:front, 2-sided
Detail	To adjust the margin at the leading edge of the image on the front side at DADF 2-sided reading. As the value is incremented by 1, the margin at the leading edge of the image is decreased by 0.1mm. (The image moves in the direction of the leading edge of the sheet.) Execute this item when the output image after DADF installation is displaced. When replacing the Scanner Unit or Controller PCB/clearing the Reader-related RAM data, enter the value of service label.
Use Case	- When installing DADF - When replacing the Scanner Unit - When clearing the Reader-related RAM data
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Caution	Be sure to use DOCST at the time of 1-sided reading.
Display/Adj/Set Range	-30 to 30
Unit	0.1 mm
Default Value	0
Related Service Mode	FEEDER> ADJUST> DOCST, DOCST2
Supplement/Memo	Since the front side reading operation differs between 1-sided and 2-sided reading, separate service modes have been prepared to improve the accuracy.

 **FUNCTION**

FEEDER > FUNCTION

MTR-ON	Operation check of ADF Motor
Detail	To start operation check of ADF Motor (M702).
Use Case	At operation check
Adj/Set/Operate Method	1) Select the item, and then press Yes key. It is driven for approximately 5 seconds and is automatically stopped. 2) Press Yes key. The operation check is completed.
Required Time	5 seconds
FEED-ON	Operation check of ADF individual feed
Detail	To start operation check of the ADF individual feed in the mode specified by FEED-CHK.
Use Case	At operation check
Adj/Set/Operate Method	Select the item, and then press Yes key.
Related Service Mode	FEEDER > FUNCTION > FEED-CHK

FEEDER > FUNCTION

FEED-CHK		Setting of ADF individual feed mode
Detail	To set the ADF feed mode. Feed operation is activated in the specified feed mode by executing FEED-ON.	
Use Case	At operation check	
Adj/Set/Operate Method	Enter the value, and then press Apply key.	
Display/Adj/Set Range	0 to 1 0 : One-sided 1 : 2-sided	
Default Value	0	
Related Service Mode	FEEDER > FUNCTION > FEED-ON	

FAX

 Lis of SSSW

SSSW No.	Bit No.	Function
SW 01		(Switch relating to error and copy)
	Bit 0	Output of error code for service technician
	Bit 1	Error memory dump
SW 02		(Switch relating to settings for network connection condition)
	Bit 7	Connect the terminal as F network type 2
SW 03		(Switch relating to echo prevention)
	Bit 0	TCF EQM check
	Bit 7	Output 1080Hz before CED
SW 04		(Switch relating to prevention of communication problems)
	Bit 1	Frequency check of CI signal
	Bit 3	Prohibit T.30 node F kept by both parties
	Bit 4	T.30 node F echo timer
	Bit 5	Frequency check of CI signal at PBX settings
	Bit 6	No CNG transmission at the time of manual transmission
	Bit 7	No CED transmission at the time of manual transmission
SW 05		(Switch relating to standard functions and DIS signal settings)
	Bit 2	mm/inch conversion (text/photo mode / photo mode)
	Bit 3	Prohibition of bit transmission after DIS bit 33
	Bit 4	Declaration of cut paper
SW 06		(Switch relating to settings for reading condition)
	Bit 4	Scan width 0: A4, 1: LTR
SW 07 to 11		Not in use
SW 12		(Switch relating to settings for page timer)
	Bit 0	Timeout period for 1 page (transmission)
	Bit 1	Timeout period for 1 page (transmission)
	Bit 2	Timeout period for 1 page (Halftone transmission)
	Bit 3	Timeout period for 1 page (Halftone transmission)
	Bit 4	Timeout period for 1 page (Reception)
	Bit 5	Timeout period for 1 page (Reception)
Bit 7	Timeout period for 1 page	
SW 13	Bit 2	Execution of mm/inch conversion when sending the received image
SW 14	Bit 2	Setting whether to execute inch to mm conversion in horizontal and vertical scanning directions or in vertical scanning direction only
	Bit 4	Declaration of inch-configuration resolution
SW 16		Not in use
SW 17	Bit 1	Range of selection of transmission level of modem (0 : 8 to 15, 1 : 0 to 15)
SW 18	Bit 0	Detection of carrier disconnection between DCS and TCF
	Bit 1	Time to wait for carrier disconnection between DCS and TCF
	Bit 2	Prohibition of communication control for IP network
SW 19 to 21		Not in use
SW 22	Bit 3	Prohibition of manual polling operation
SW 23 to 24		Not in use
SW 25		(Setting for report display function)
	Bit 0	Prioritize the received abbreviated name to the dialed abbreviated name
SW 26 to 27		Not in use

SSSW No.	Bit No.	Function
SW 28	Bit 0	Prohibit calling party for V8 procedure
	Bit 1	Prohibit called party from V8 procedure
	Bit 2	Prohibit calling party from V8 late-start
	Bit 3	Prohibit called party from V8 late-start
	Bit 4	Prohibit V.34 called party from starting fallback
	Bit 5	Prohibit V.34 calling party from starting fallback
SW 29 to 35		Not in use

List of MENU

No.	Parameter	Selection
01 to 05	Not in use	
06	Telephone line monitor	0 to 3 0: DIAL 1: SERVICEMAN1 2: SERVICEMAN2 3: OFF
07	Transmission level (ATT)	0 to 15
08	Upper limit of V.34 modulation speed	0 to 5 0: 3429 BAUD 1: 3200 BAUD 2: 3000 BAUD 3: 2800 BAUD 4: 2743 BAUD 5: 2400 BAUD
09	Upper limit of V.34 data speed	0 to 13 0: 33.6 kbps 1: 31.2 kbps 2: 28.8 kbps 3: 26.4 kbps 4: 24.0 kbps 5: 21.6 kbps 6: 19.2 kbps 7: 16.8 kbps 8: 14.4 kbps 9: 12.0 kbps 10: 9.6 kbps 11: 7.2 kbps 12: 4.8 kbps 13: 2.4 kbps
10	OFF Hook signal frequency	0 to 2 0: 50 Hz 1: 25 Hz 2: 17 Hz
11 to 20	Not in use	

List of NUM

Numeric parameter setting mode		
No.	Parameter	Allowable setting range
01	Not in use	
02	RTN transmission criteria X	1 to 99 %
03	RTN transmission criteria n	2 to 99 times
04	RTN transmission criteria m	1 to 99 lines
05	NCC pause (before ID code)	1 to 60 sec
06	NCC pause (after ID code)	1 to 60 sec

Numeric parameter setting mode		
No.	Parameter	Allowable setting range
07	Spare	
08	STORED_DIAL_MODE wait timer	0 to 65 sec
09	Not in use	
10	T.30 T0 timer	55 sec principally
11	T.30 T1 timer (for incoming transmission)	0 to 9999 (France: 3500, Others: 3000)
12	Maximum incoming lines	0 to 65535 (line)0: without limitation
13	T.30 EOL timer	500 to 3000 (set to 55 sec by default)
14	Not in use	
15	Threshold between hooking nad on-hook	0 to 999
16	Lead time to the first response when switching between FAX and TEL	0 to 9
17	Duration to activate pseudo-RBT cadence	0 to 999
18	Duration to deactivate pseudo-RBT cadence (short)	0 to 999
19	Duration to deactivate pseudo-RBT cadence (long)	0 to 999
20	Duration to activate pseudo-ring cadence	0 to 999
21	Duration to deactivate OFF Hook cadence (short)	0 to 999
22	Duration to deactivate OFF Hook cadence (long)	0 to 7
23 to 24	Not in use	
25	CNG monitor duration while the answering device is activated	0 to 999
26 to 28	Not in use	
29	Off-hook PCB duty settings(For NAC, setting can be made with SPL71100 in special management mode.)	20 (*10ms)
30 to 48	Not in use	
49	NSX MODEL ID	0 to 4095
50	Not in use	
51	Threshold to detect hook	10 to 9999
52	Not in use	
53	Set DTMF calling counts when receiving FAX remotely	10 to 9999 (default 25)
54	Set Busy Tone outgoing duration when using handset	
55 to 80	Not in use	

Setting of NCU Parameters

■ TONE/PULSE

Operation Method

1. Setting of Tone Parameters

Operate as follows, and change to the parameter setting mode.

1. While "#NCU" is displayed, press "OK" key
2. Press "#TONE" key
3. Press "OK" key

2. Setting of Pulse Parameters

Operate as follows, and change to the pulse setting mode.

1. While "#NCU" is displayed, press "OK" key
2. Press "#PULSE" key
3. press "OK" key

Item		Function	Setting range
TONE	01;	Tone signal sending time (PSTN)	10 to 9999 (msec)
	02;	Minimum pause time (PSTN)	10 to 9999 (msec)
PULSE	PULSE FORM	Pulse digit format	0 to DP (N)
			1 to DP (N+1)
			2 to DP (10-N)
	PULSE NUM	01;	Not in use
02;		Not in use	
03;		Pulse dial make ratio	10 to 90 (%)

Item			Function	Setting range
PULSE	PULSE NUM	04;	Minimum pause time	10 to 9999 (msec)

■ DIAL TONE

● Bit Switch

Bit No.	Function	1	0
Bit 0	-	-	-
Bit 1	Cadence pattern check	Not detected	Detected
Bit 2	Signal frequency	Changed	Not changed
Bit 3	-	-	-
Bit 4	Judgment of intermittent signal	start from valid ON signal	start from either valid ON signal or OFF signal
Bit 5	-	-	-
Bit 6	Signal form	Continuous	Intermittent
Bit 7	Signal detection	Detected	Not detected

● Numeric value parameter

Parameter No.	Function	Setting range
01;	T0 timer	0 to 9999 (x 10 msec)
02;	T1 timer	0 to 9999 (x 10 msec)
03;	T2 timer	0 to 9999 (x 10 msec)
04;	T3 timer	0 to 9999 (x 10 msec)
05;	T4 timer	0 to 9999 (x 10 msec)
06;	Signal detection table	0 to 16
07;	Signal detection level	0 to 7
08;	Number of signal frequency	0 to 9999

■ 2nd DIAL TONE

Not in use

■ BUSY TONE 0

● Bit Switch

Bit No.	Function	1	0
Bit 0	-	-	-
Bit 1	-	-	-
Bit 2	-	-	-
Bit 3	-	-	-
Bit 4	-	-	-
Bit 5	-	-	-
Bit 6	-	-	-
Bit 7	Signal detection	Detected	Not detected

● Numeric value parameter

Not in use

■ BUSY TONE 1

● Bit Switch

Bit No.	Function	1	0
Bit 0	-	-	-

Bit No.	Function	1	0
Bit 1	-	-	-
Bit 2	-	-	-
Bit 3	-	-	-
Bit 4	-	-	-
Bit 5	-	-	-
Bit 6	-	-	-
Bit 7	Signal detection	Detected	Not detected

• Numeric value parameter

Parameter No.	Function	Setting range
01;	-	-
02;	T1 timer	0 to 9999 (x 10 msec)
03;	T2 timer	0 to 9999 (x 10 msec)
04;	T3 timer	0 to 9999 (x 10 msec)
05;	T4 timer	0 to 9999 (x 10 msec)
06;	Signal detection table	0 to 16
07;	Signal detection level	0 to 7
08;	Number of signal frequency	0 to 9999

■ REORDER TONE

• Bit Switch

Bit No.	Function	1	0
Bit 0	-	-	-
Bit 1	-	-	-
Bit 2	Signal frequency	Changed	Not changed
Bit 3	-	-	-
Bit 4	Judgment of intermittent signal	start from valid ON signal	start from either valid ON signal or OFF signal
Bit 5	-	-	-
Bit 6	Signal form	Continuous	Intermittent
Bit 7	Signal detection	Detected	Not detected

• Numeric value parameter

Parameter No.	Function	Setting range
01;	-	-
02;	T1 timer	0 to 9999 (x 10 msec)
03;	T2 timer	0 to 9999 (x 10 msec)
04;	T3 timer	0 to 9999 (x 10 msec)
05;	T4 timer	0 to 9999 (x 10 msec)
06;	Signal detection table	0 to 16
07;	Signal detection level	0 to 7
08;	Number of signal frequency	0 to 9999

■ MULTI

Not in use

■ AUTO RX

● Numeric value parameter

Parameter No.	Function	Setting range
01;	CI ON time	0 to 9999 (x 10 msec)
02;	CI LONG ON time	0 to 9999 (x 10 msec)
03;	CI OFF time	0 to 9999 (x 10 msec)
04;	CI LONG OFF time	0 to 9999 (x 10 msec)
05;	CI MAX OFF time	0 to 9999 (x 10 msec)
06;	CI WAIT time	0 to 9999 (x 10 msec)
07;	CI frequency	0 to 9999 (cycle)
08;	CI frequency lower limit	0 to 9999 (Hz)
09;	CI frequency upper limit	0 to 9999 (Hz)

■ CNG DETECT

● Numeric value parameter

Parameter No.	Description		Setting range
01;	At F/T switching	CNG MIN ON time	0 to 9999 (x10 msec)
02;		CNG MAX ON time	0 to 9999 (x 10 msec)
03;		-	-
04;		-	-
05;		-	-
06;		-	-
07;	At direct connecting to answering phone	CNG MIN ON time	0 to 9999 (x 10 msec)
08;		CNG MAX ON time	0 to 9999 (x 10 msec)
09;		Tolerable time of instantaneous interruption	0 to 9999 (x 10 msec)
10;		-	-
11;		Number of detection	0 to 9999 (times)
12;		Hit ratio	0 to 9999 (%)

■ RKEY

● Numeric value parameter

Parameter No.	Function	Setting range
01;	Connection time of flash	0 to 9999 (x 10 msec)
02;	Connection time of grounding wire	0 to 9999 (x 10 msec)

■ PBX DIAL TONE 1

Not in use

■ PBX BUSY TONE

Not in use

TESTMODE

PRINT

TESTMODE > PRINT

PG-TYPE	Setting of PG number
Detail	To set the PG number of the test print.
Use Case	At trouble analysis
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 7 0: Grid Bk 1: HT 2: Solid black 3: Solid white 4: 17 gradations 5: Thin horizontal line 6: Pascal correction chart 7: Chart128
Default Value	0
COUNT	Setting of PG output quantity
Detail	To set the number of sheets for PG output.
Use Case	At trouble analysis
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	1 to 99
Unit	1 sheet
Default Value	1
PHASE	Setting of PG 2-sided mode
Detail	To set 1-sided/2-sided print for PG output. Even if 2-sided print is set for a machine that only supports 1-sided print, the setting is disabled.
Use Case	At trouble analysis
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 1 0 : 1-sided, 1 : 2-sided
Default Value	0
MODE	Setting of test print image formation method
Detail	To set the image formation method for the test print. If PG-TYPE is 0/1, this setting is disabled because a specific image formation method is applied.
Use Case	At trouble analysis
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 4 0: TBIC 1: Resolution dithering 2: Gradation dithering 3: Color tone dithering 4: High-resolution dithering
Default Value	0

TESTMODE > PRINT

THRU	Setting of image correction table at test print
Detail	It is possible to check the density characteristics due to the density correction process when normal gamma LUT is used, and the density characteristics of the engine when the linear gamma LUT is used.
Use Case	At trouble analysis
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 1 0 : Normal gamma LUT 1 : Through (linear) gamma LUT
Default Value	0
Supplement/Memo	Gamma LUT: Density gradation characteristic table
DENS	Adjustment of test print engine F value
Detail	This setting is used to adjust the F value of the engine of test print. The density increases as the value increases.
Use Case	At trouble analysis
Adj/Set/Operate Method	Enter the setting value (switch negative / positive by * key) and press Apply key.
Display/Adj/Set Range	-4 to 4 -4: Light +4: Dark
Default Value	0
MABK	Set toner thinning process at test print
Detail	To execute the thinning process to alleviate the toner scattering at test print. The thinning amount of toner increases in accordance with Mode 1 to Mode 4.
Use Case	Print Test print
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 3 0: OFF 1: Mode1 2: Mode2 3: Mode3
Default Value	0
FEED	Setting of paper source at test print
Detail	To set the paper source at the time of test print output. If this mode is set when there is no Cassette 2 (option Pickup Cassette), the output is made from Cassette 1 (standard Pickup Cassette).
Use Case	At trouble analysis
Adj/Set/Operate Method	Enter the setting value, and then press Apply key.
Display/Adj/Set Range	0 to 4 0 : MP Tray 1 : Cassette1 2 : Cassette2 3 : Cassette3 4 : Cassette4
Default Value	1
START	Output of test print
Detail	To output a test print with the PG pattern set in PG-TYPE, MODE, etc.
Use Case	At trouble analysis
Adj/Set/Operate Method	Press Apply key.
Display/Adj/Set Range	0 to 1
Default Value	0

FAX

MODEM

FAX model only

TESTMODE > FAX > MODEM	
Item	Description
RELAY-1	
Title	NCU relay test 1
Details	N To test ON/OFF of relay and port switch of NCU. This mode is disabled for an NCU with no relay and port switch.
Use case	When analyzing the cause of a problem
Adj/set/operate method	Enter the setting value, and then press Apply key.
Caution	Be sure to set the value back to 0 after the test.
Display/adj/set range	0 to 6 0: All OFF 1: CML ON/OFF 2: P ON/OFF 3: S ON/OFF 4: H ON/OFF 5: HD ON/OFF 6: R ON/OFF
Default value	0
Related service mode	TESTMODE > FAX > MODEM > RELAY-2
RELAY-2	
Title	NCU relay test 2
Details	To test ON/OFF of relay and port switch of NCU. This mode is disabled for an NCU with no relay and port switch.
Use case	When analyzing the cause of a problem
Adj/set/operate method	Enter the setting value, and then press Apply key.
Caution	Be sure to set the value back to 0 after the test.
Display/adj/set range	0 to 7 0: All OFF 1: CIST2 ON/OFF 2: C1 ON/OFF 3: NORG ON/OFF 4: DCSEL ON/OFF 5: DCLIM ON/OFF 6: IPSEL1 ON/OFF 7: IPSEL2 ON/OFF
Default value	0
Related service mode	TESTMODE > FAX > MODEM > RELAY-1
FREQ	
Title	To test whether the specified frequency is oscillated. By closing or opening the DC circuit in accordance with the setting value, the specified frequency is oscillated by the tone transmission function of the modem. Check this with the speaker.
Details	When analyzing the cause of a problem
Adj/set/operate method	Enter the setting value, and then press Apply key.
Caution	Be sure to set the value back to 0 after the test.
Display/adj/set range	0 to 7 0: OFF 1: 462 Hz 2: 1100 Hz 3: 1300 Hz 4: 1500 Hz 5: 1650 Hz 6: 1850 Hz, 7: 2100 Hz

TESTMODE > FAX > MODEM	
Item	Description
Default value	0
G3TX	
Title	G3 signal transmission test
Details	To test whether the specified G3 signal is transmitted. By closing or opening the DC circuit in accordance with the setting value, the specific G3 signal pattern is transmitted at the specified transmission speed by the G3 signal transmission function of the modem. Check this with the speaker.
Adj/set/operate method	Enter the setting value, and then press Apply key.
Caution	Be sure to set the value back to 0 after the test.
Display/adj/set range	0 to 9 0: OFF 1: 300 bps 2: 2400 bps 3: 4800 bps 4: 7200 bps 5: 9600 bps 6: TC7200 bps 7: TC9600 bps 8: 12000 bps 9: 14400 bps
Default value	0
DTMFTX	
Title	DTMF transmission test
Details	To test whether the specified DTMF signal is transmitted. By closing or opening the DC circuit in accordance with the setting value, the specified DTMF signal is transmitted by the DTMF transmission function of the modem. Check this with the speaker.
Adj/set/operate method	Enter the setting value, and then press Apply key.
Caution	Be sure to set the value back to 0 after the test.
Display/adj/set range	0 to 12 0: OFF 1: 1 2: 2 3: 3 4: 4 5: 5 6: 6 7: 7 8: 8 9: 9 10: 0 11: * 12: #
Default value	0
Supplement/memo	DTMF (Dual Tone Multi Frequency): Signal method combining two specific frequencies like a push-tone phone.
V34G3TX	
Title	V.34 G3 signal transmission test
Details	To test whether the specified V.34 G3 signal is transmitted. By closing or opening the DC circuit in accordance with the setting value, the specific G3 signal pattern is transmitted at the specified transmission speed and modulation speed by the G3 signal transmission function (V.34) of the modem. Check this with the speaker. A setting value other than 0 is indicated as a 3-digit integer (1st digit: modulation speed, last 2 digits: transmission speed). A value other than the specified numerical value is invalid.
Adj/set/operate method	Enter the setting value, and then press Apply key.
Caution	Be sure to set the value back to 0 after the test.

TESTMODE > FAX > MODEM	
Item	Description
Display/adj/set range	0 to 614 0: OFF <ul style="list-style-type: none"> • First digit (Modulation speed/ baud rate) <ul style="list-style-type: none"> 1: 2400 baud 2: 2743 baud 3: 2800 baud 4: 3000 baud 5: 3200 baud 6: 3429 baud • Last 2 digits (Transmission speed) <ul style="list-style-type: none"> 01: 2400 bps 02: 4800 bps 03: 7200 bps 04: 9600 bps 05: 12000 bps 06: 14400 bps 07: 16800 bps 08: 19200 bps 09: 21600 bps 10: 24000 bps 11: 26400 bps 12: 28800 bps 13: 31200 bps 14: 33600 bps
Default value	0



FAX model only

TESTMODE > FAX > FACULTY	
Item	Description
G34800TX	
Title	G3 4800 bps signal transmission test
Details	To test whether the G3 signal is transmitted at 4800 bps. By closing or opening the DC circuit, the specific G3 signal pattern is transmitted at 4800 bps by the G3 signal transmission function. Check this with the speaker.
Adj/set/operate method	Enter the setting value, and then press Apply key.
Caution	Be sure to set the value back to 0 after the test.
Display/adj/set range	0 to 1 0: OFF 1: ON
Default value	0
DETECT1	
Title	Ring detection
Details	To check the ON/OFF state of CI, FC, and hook from the line. The detection results are displayed on the console (UART).
Adj/set/operate method	Enter the setting value, and then press Apply key.
Caution	Be sure to set the value back to 0 after the test.
Display/adj/set range	0 to 1 0: OFF 1: ON
Default value	0
Supplement/memo	CI (Calling Identification): Ring signal UART (Universal Asynchronous Receiver Transmitter): Console
DETECT2	
Title	Calling tone detection test 1

TESTMODE > FAX > FACULTY	
Item	Description
Details	To check calling tone signal and FED. Set the CML relay to ON and detect the calling tone. The detection results are displayed on the console (UART).
Adj/set/operate method	Enter the setting value, and then press Apply key.
Caution	Be sure to set the value back to 0 after the test.
Display/adj/set range	0 to 1 0: OFF 1: ON
Default value	0
Supplement/memo	CML (Connect Modem to Line) relay: Relay installed at the NCU (Network Control Unit) Board to switch between the telephone and fax.
DETECT3	
Title	Calling tone detection test 2
Details	To check calling tone signal and FED. Set the CML relay to OFF and detect the calling tone. The detection results are displayed on the console (UART).
Adj/set/operate method	Enter the setting value, and then press Apply key.
Caution	Be sure to set the value back to 0 after the test.
Display/adj/set range	0 to 1 0: OFF 1: ON
Default value	0
Supplement/memo	CML (Connect Modem to Line) relay: Relay installed at the NCU (Network Control Unit) Board to switch between the telephone and fax.



Installation

Copy Card Reader-F1 (Counter meter- installed models only).....	261
MiCARD Attachment Kit-B1 (Counter meter-installed models only).....	267
Control Interface Kit-C1 (Counter meter-installed models only).....	270

Copy Card Reader-F1 (Counter meter-installed models only)

Points to Note at Installation

The Copy Card Reader Attachment is required for the installation of the equipment.
The following options cannot be used in combination with this equipment.


- MiCARD Attachment Kit-B1 + IC-Card Reader that is a sales company's option
- Copy Control Interface Kit-C1

Installation Outline Drawing




Checking the Contents

<Copy Card Reader-F1>



<Copy Card Reader Attachment-J1>



Check Items When Turning OFF the Main Power

Check that the main power switch is OFF.


1. Turn OFF the main power switch of the host machine.
2. Be sure that Control Panel Display and Main Power Lamp are both turned OFF, and then disconnect the power plug.

Installation Procedure



□ 1





□ 2




□ 3




□ 4





□ 5



□ 6



□ 7




□ 8



9

CAUTION:


When installing the Connector Cover, be sure to place the 2 Harness Bands [A] inside the Connector Cover.



10

CAUTION:


Do not disconnect the short connector [A].




11

CAUTION:

- When installing the Connector Case, be sure to place the 3 Harness Bands [A] inside the groove of the Connector Case.
- Be careful not to trap cables.





12






□ 13

NOTE:

The removed Cover will be used in step 15.




□ 14



□ 15

NOTE:

Use the Cover removed in step 13.



□ 16

Connect the power plug to the outlet.

□ 17

Turn ON the main power switch.

● Setting after Installation

Configure the card management information settings in service mode.

□

1. **COPIER > FUNCTION > INSTALL > CARD-NUM**, and enter the first number of the card to be used.
Enter the smallest card number to be used by the user.
2. **Sequence numbers beginning with the number specified in COPIER > FUNCTION > INSTALL > CARD are automatically registered.**
From the entered card number, 300 cards can be used.

3. Select ON for the Dept ID control.**NOTE:**

How to enter System Manager Settings

1. Enter the Manager ID: 7654321. (Default values)
2. Enter the PIN: 7654321. (Default values)
3. Press the "ID" key.

[Menu] > [System Management Settings] > [Department ID Management ON/OFF] > [ON]

- 4. Turn OFF and then ON the main power switch to enable the setting values.**
- 5. Check that a message [Insert the card.] appears.**

MiCARD Attachment Kit-B1 (Counter meter-installed models only)

Points to Note at Installation

Prepare a Card Reader (sales company's option) in advance. Although the shape of the Card Reader may differ, the installation procedure is the same. Use the short-type Card Reader Cable.

The following options cannot be used in combination with this equipment.

- Copy Card Reader-F1
- Copy Control Interface Kit-C1

Installation Outline Drawing



Checking the Contents





1x



1x



1x

TP; M4x16
1x

1x




Check Items When Turning OFF the Main Power

Check that the main power switch is OFF.

1. Turn OFF the main power switch of the host machine.
2. Be sure that Control Panel Display and Main Power Lamp are both turned OFF, and then disconnect the power plug.

Installation Procedure


□ 1



□ 2




□ 3




□ 4

NOTE:
The removed Cover will be used in step 6.



□ 5




□ 7



□ 6

NOTE:
Use the Cover removed in step 4.



□ 8

Connect the power plug to the outlet.

□ 9

Turn ON the main power switch.


Control Interface Kit-C1 (Counter meter-installed models only)

Points to Note at Installation


The following options cannot be used in combination with this equipment.

- Copy Card Reader-F1
- MiCARD Attachment Kit-B1 + IC-Card Reader that is a sales company's option

Installation Outline Drawing



Checking the Contents




Check Items When Turning OFF the Main Power

Check that the main power switch is OFF.


1. Turn OFF the main power switch of the host machine.
2. Be sure that Control Panel Display and Main Power Lamp are both turned OFF, and then disconnect the power plug.

Installation Procedure



□ 1






□ 2





□ 3




□ 4




□ 5




□ 7



□ 6






APPENDICES

Service Tools.....	274
General Timing Chart.....	275
General Circuit Diagram.....	276
Backup Data.....	277
Soft Counter Specifications.....	279

Service Tools

Special Tools

In addition to the standard tools set, the following special tools are required when servicing the machine:

Name of Tool	Parts.No	Use
Digital Multimeter	FY9-2002	Used as a probe extension when making electrical checks. 

Solvents and Oils

No.	Name of Tool	Use	Remarks
1	Alcohol	Cleaning: <ul style="list-style-type: none"> • Plastic • Rubber • Metal part • Oil stain • Toner stain 	<ul style="list-style-type: none"> • Keep away from flame • Purchase locally
2	Lubricant	Apply between gear and shaft	<ul style="list-style-type: none"> • SHELL TELLUS 68 (Showa Shell Sekiyu K.K.) Tool No : CK-8003
3	Lubricant	Apply to gear	<ul style="list-style-type: none"> • MOLYCOTE EM-50L (Dow Corning Corporation) Tool No : HY9-0007
4	Lubricant	Apply to ADF scanning area	<ul style="list-style-type: none"> • Oil glass cleaner Tool No : FY9-6020

General Timing Chart


Timing chart two consecutive prints on LTR paper

Power ON
▽

		WAIT	STBY	INTR	PRINT	LSTR	STBY
1	Print start command (EEC12)						
2	Cassette pickup solenoid (SL2)						
3	TOP sensor (PS215)						
4	Fixing delivery sensor (PS2,3)						
5	BD signal						
6	VIDEO signal						
7	Scanner motor (M3)						
8	Main motor (M2)						
9	Fixing motor (M1)						
10	Fixing heater						
11	Primary charging bias						
12	Developing bias						
13	Transfer charging bias						
14	Fixing bias						
15	Main fan (FM1)						
16	Sub fan (FM2)						
17							
18							
19							
20							
21							
22							
23							

General Circuit Diagram

General Circuit Diagram(1/1)



Backup Data

Data	Location	Replace		Delete										Backup by User			Backup by Service			
				Menu > System Management Settings					COPIER > FUNCTION > CLEAR					Yes/No	Method	Location to be stored	Yes/No	Method	Location to be stored	
		Engine Controller PCB	Main Controller PCB	Initialize All Data / Settings	Initializing Key and Certificate	Initializing Address Book	Initializing Menu > Initialize All	System Management Settings	R-CON *2	SRVC-DAT *3	COUNTER	HIST *4	ALL *5							ERDS-DAT
Address Book	Main Controller PCB	-	Clear	-	-	Clear	-	-	-	-	-	-	Clear	-	Yes	Remote UI *9 LUI *10	PC, USB memory	No	-	-
Settings Menu																				
Paper Settings	Main Controller PCB	-	Clear	Clear	-	-	-	-	-	-	-	-	Clear	-	Yes	Remote UI *9 LUI *10	PC, USB memory	No	-	-
Network Settings	Main Controller PCB	-	Clear	Clear	-	-	Clear	Clear	-	-	-	-	Clear	-	Yes	Remote UI *9 LUI *10	PC, USB memory	No	-	-
Preferences	Main Controller PCB	-	Clear	Clear	-	-	Clear	-	-	-	-	-	Clear	-	Yes	Remote UI *9 LUI *10	PC, USB memory	No	-	-
Timer Settings	Main Controller PCB	-	Clear	Clear	-	-	Clear	-	-	-	-	-	Clear	-	Yes	Remote UI *9 LUI *10	PC, USB memory	No	-	-
Common Settings	Main Controller PCB	-	Clear	Clear	-	-	Clear	-	-	-	-	-	Clear	-	Yes	Remote UI *9 LUI *10	PC, USB memory	No	-	-
Copy Settings	Main Controller PCB	-	Clear	Clear	-	-	Clear	-	-	-	-	-	Clear	-	Yes	Remote UI *9 LUI *10	PC, USB memory	No	-	-
Fax Settings	Main Controller PCB	-	Clear	Clear	-	-	Clear	-	-	-	-	-	Clear	-	Yes *6	Remote UI *9 LUI *10	PC, USB memory	No	-	-
Scan Settings	Main Controller PCB	-	Clear	Clear	-	-	Clear	-	-	-	-	-	Clear	-	Yes *7	Remote UI *9 LUI *10	PC, USB memory	No	-	-
Memory Media Print Settings	Main Controller PCB	-	Clear	Clear	-	-	Clear	-	-	-	-	-	Clear	-	Yes	Remote UI *9 LUI *10	PC, USB memory	No	-	-
Printer Settings	Main Controller PCB	-	Clear	Clear	-	-	Clear	-	-	-	-	-	Clear	-	Yes	Remote UI *9 LUI *10	PC, USB memory	No	-	-
Adjustment / Maintenance	Main Controller PCB	-	Clear	Clear	-	-	-	-	-	-	-	-	Clear	-	Yes	Remote UI *9 LUI *10	PC, USB memory	No	-	-
System Management Settings	Main Controller PCB	-	Clear	Clear	-	-	Clear	Clear	-	-	-	-	Clear *12	-	Yes *13	Remote UI *9 LUI *10	PC, USB memory	No	-	-
Key and Certificate	Main Controller PCB	-	Clear	Clear	Clear *11	-	-	-	-	-	-	-	Clear	-	No	-	-	No	-	-
eRDS	Main Controller PCB	-	Clear	Clear	-	-	-	-	-	-	-	-	Clear	Clear	No	-	-	No	-	-
Serial Number	EE-PROM(PCB Unit) / On-Board-Fram / Fram(PCBU nit)	-	-	-	-	-	-	-	-	-	-	-	-	-	No	-	-	No	-	-
Job History	Main Controller PCB	-	Clear	Clear	-	-	-	-	-	-	-	Clear	Clear	-	No	-	-	No	-	-
Page counter	Main Controller PCB / OnBoard-Fram / Fram(PCB Unit)	-	-	-	-	-	-	-	-	-	-	-	-	-	No	-	-	No	-	-
Part counter	None	-	Clear	-	-	-	-	-	-	-	Clear	-	-	-	No	-	-	No	-	-
Service mode																				

Data	Location	Replace		Delete										Backup by User			Backup by Service			
		Engine Controller PCB	Main Controller PCB	Menu > System Management Settings					COPIER > FUNCTION > CLEAR					Yes/No	Method	Location to be stored	Yes/No	Method	Location to be stored	
				Initialize All Data / Settings	Initializing Key and Certificate	Initializing Address Book	Initializing Menu > Initialize All	System Management Settings	R-CON *2	SRVC-DAT *3	COUNTER	HIST *4	ALL *5							ERDS-DAT
Service mode setting values (Reader)	Main Controller PCB	-	Clear	-	-	-	-	-	Clear	-	-	-	-	-	No	-	-	No	-	-
Service mode setting values(Main Controller)	Main Controller PCB	-	Clear	-	-	-	-	-	-	Clear	-	-	Clear	-	No	Remote UI *9	PC, USB memory	Yes	Service mode *8	PC, USB memory
Service mode setting values (Engine Controller)	Main Controller PCB	-	Clear	-	-	-	-	-	-	-	-	-	-	-	No	Remote UI *9	PC, USB memory	Yes	Service mode *8	PC, USB memory

*1 Log data such as Mac address, USB serial number, printer-related setting values, scanner-related setting values, user data, and logs are initialized.

*2. The factory adjustment values of the Reader and ADF are initialized.

*3. Service data is cleared. User data is not cleared. The factory adjustment values of the Reader and ADF are not initialized.

*4. The logs (communication management, print, jam, error, and alarm) are cleared.

*5. The user data, service data, logs, and system administrator are initialized. (The system manager ID and password are changed back to the default values.) The factory adjustment values of the Reader and ADF are not initialized.

*6. Excluding Fax Setup Guide

*7. Excluding the shortcut key

*8. FUNCTION > SYSTEM > IMPORT / FUNCTION > SYSTEM > EXPORT

*9. Settings/Registration > Import/Export

*10. Setting Menu List > System Management Settings > Import/Export of Settings.

*11. When the key and certificate are initialized, TLS authentication of IEEE802.1X and the SSL setting are changed to "OFF".

*12. The system administrator ID and the password are changed back to the default values. ID: 7654321 / PWD: 7654321.

*13. Excluding [Forwarding Settings], [Remote UI On/Off], [Update Firmware], [Initialize Key and Certificate], [Initialize Address Book], and [Initialize System Management Settings]

Soft Counter Specifications

The numbers entered for software counters are classified as follows

No.	Counter Details	No.	Counter Details
000 to 099	Toner Bottle	500 to 599	Scan
100 to 199	Total	600 to 699	Memory Media Print
200 to 299	Copy	700 to 799	Receive Print
300 to 399	Print	800 to 899	Report Print
400 to 499	Copy + Print	900 to 999	Transmission

Meanings of symbols in tables

- Numbers 1, 2 indicated under "Counter Details": Number of counts for large size paper
 - Copy: Local copy
 - Copy A: Local copy
 - Print: PDL print + report print
 - Print A: PDL print + report print
 - Scan: Black and white scan + color scan
- *This product does not have the function of "Remote Copy" and "Box Print".

000 to 099

No.	Counter Details	No.	Counter Details
071	Toner Bottle (Black)		

100 to 199

No.	Counter Details	No.	Counter Details
101	Total 1	138	Total A1 (2-Sided)
102	Total 2	139	Total A2 (2-Sided)
104	Total (Small)	141	Small A (2-Sided)
108	Total (Black1)	150	Total B1
109	Total (Black2)	151	Total B2
113	Total (Black / Small)	153	Total B (Small)
114	Total 1 (2-Sided)	156	Total B (Black1)
115	Total 2 (2-Sided)	157	Total B (Black2)
117	Small (2-Sided)	161	Total B (Black / Small)
126	Total A1	162	Total B1 (2-Sided)
127	Total A2	163	Total B2 (2-Sided)
129	Total A (Small)	165	Small B (2-Sided)
132	Total A (Black1)	181	Toner (Black)
133	Total A (Black2)	194	Toner replacement / Black *1
137	Total A (Black / Small)		

200 to 299

No.	Counter Details	No.	Counter Details
201	Copy (Total 1)	228	Copy (Black / Small)
202	Copy (Total 2)	238	Copy (Black / Small / 2-Sided)
204	Copy (Small)	249	Copy A (Black1)
205	Copy A (Total 1)	250	Copy A (Black2)
206	Copy A (Total 2)	256	Copy A (Black / Small)
208	Copy A (Small)	266	Copy A (Black / Small / 2-Sided)
209	Local Copy (Total 1)	277	Local Copy (Black1)
210	Local Copy (Total 2)	278	Local Copy (Black2)
212	Local Copy (Small)	284	Local Copy (Black / Small)
221	Copy (Black1)	294	Local Copy (Black / Small / 2-Sided)

No.	Counter Details	No.	Counter Details
222	Copy (Black2)		

300 to 399

No.	Counter Details	No.	Counter Details
301	Print (Total 1)	330	Print (Black / Small / 2-Sided)
302	Print (Total 2)	331	PDL Print (Total 1)
304	Print (Small)	332	PDL Print (Total 2)
305	Print A (Total 1)	334	PDL Print (Small)
306	Print A (Total 2)	339	PDL Print (Black1)
308	Print A (Small)	340	PDL Print (Black2)
313	Print (Black1)	346	PDL Print (Black / Small)
314	Print (Black2)	356	PDL Print (Black / Small / 2-Sided)
320	Print (Black / Small)		

400 to 499

No.	Counter Details	No.	Counter Details
404	Copy + Print (Black / Small)	413	Copy + Print (2)
405	Copy + Print (Black2)	414	Copy + Print (1)
406	Copy + Print (Black1)	422	Copy + Print (Black / Small / 2-Sided)
412	Copy + Print (Small)		

500 to 599

No.	Counter Details	No.	Counter Details
501	Scan (Total 1)	509	Color Scan (Total 1)
505	Black Scan (Total 1)	510	Color Scan (Total 2)
506	Black Scan (Total 2)	512	Color Scan (Small)
508	Black Scan (Small)		

600 to 699

No.	Counter Details	No.	Counter Details
631	Memory Media Print (Total 1)	640	Memory Media Print (Black2)
632	Memory Media Print (Total 2)	646	Memory Media Print (Black / Small)
634	Memory Media Print (Small)	656	Memory Media Print (Black / Small / 2-Sided)
639	Memory Media Print (Black1)		

700 to 799

No.	Counter Details	No.	Counter Details
701	Receive Print (Total 1)	710	Receive Print (Black2)
702	Receive Print (Total 2)	716	Receive Print (Black / Small)
704	Receive Print (Small)	726	Receive Print (Black / Small / 2-Sided)
709	Receive Print (Black1)		

800 to 899

No.	Counter Details	No.	Counter Details
801	Report Print (Total 1)	809	Report Print (Black1)
802	Report Print (Total 2)	810	Report Print (Black2)
804	Report Print (Small)	816	Report Print (Black / Small)

900 to 999

No.	Counter Details	No.	Counter Details
921	TX Scan Total5 (Color)	945	TX Scan / E-Mail (Color)
922	TX Scan Total5 (Black)	946	TX Scan / E-Mail (Black)
939	Remote Scan (Color)	959	Memory Media Scan (Color)
940	Remote Scan (Black)	960	Memory Media Scan (Black)

The counter can be displayed in COPIER > OPTION > USER > TNRB-SW.
Settings of Counter 2 to 6 which are service mode items are not supported.