

iR-ADV 715/615/525 Series

Service Manual

Important Notices

Application

This manual has been issued by Canon Inc. for qualified persons to learn technical theory, installation, maintenance, and repair of products.

This manual covers all localities where the products are sold. For this reason, there may be information in this manual that does not apply to your locality.

Corrections

This manual may contain technical inaccuracies or typographical errors due to improvements or changes in products. When changes occur in applicable products or in the contents of this manual, Canon will release technical information as the need arises. In the event of major changes in the contents of this manual over a long or short period, Canon will issue a new edition of this manual.

The following paragraph does not apply to any countries where such provisions are inconsistent with local law.

Trademarks

The product names and company names used in this manual are the registered trademarks of the individual companies.

Copyright

The copyright of this document belongs to Canon Inc. This document may not be copied, reproduced or translated into another language, in whole or in part, without the prior consent of Canon Inc.





Copyright CANON INC. 2018

















Caution

Use of this manual should be strictly supervised to avoid disclosure of confidential information.



Explanation of Symbols

The following symbols are used throughout this Service Manual.

| Symbols | Explanation | Symbols | Explanation |
|---|-----------------|--|------------------|
|  | Check. |  | Remove the claw. |
|  | Check visually. |  | Insert the claw. |

| Symbols | Explanation | Symbols | Explanation |
|---|--|--|-----------------------------|
|  | Check a sound. |  | Push the part. |
|  | Disconnect the connector. |  | Connect the power cable. |
|  | Connect the connector. |  | Disconnect the power cable. |
|  | Remove the cable/wire from the cable guide or wire saddle. |  | Turn on the power. |
|  | Install the cable/wire to the cable guide or wire saddle. |  | Turn off the power. |
|  | Remove the screw. |  | Loosen the screw. |
|  | Install the screw. |  | Tighten the screw. |
|  | Cleaning is needed. |  | Measurement is needed. |

The following rules apply throughout this Service Manual:

- Each chapter contains sections explaining the purpose of specific functions and the relationship between electrical and mechanical systems with reference to the timing of operation.
In the diagrams,  represents the path of mechanical drive; where a signal name accompanies the symbol, the arrow  indicates the direction of the electric signal.
The expression "turn on the power" means flipping on the power switch, closing the front door, and closing the delivery unit door, which results in supplying the machine with power.
- In the digital circuits, '1' is used to indicate that the voltage level of a given signal is "High", while '0' is used to indicate "Low". (The voltage value, however, differs from circuit to circuit.) In addition, the asterisk (*) as in "DRMD*" indicates that the DRMD signal goes on when '0'.
In practically all cases, the internal mechanisms of a microprocessor cannot be checked in the field. Therefore, the operations of the microprocessors used in the machines are not discussed: they are explained in terms of from sensors to the input of the DC controller PCB and from the output of the DC controller PCB to the loads.

The descriptions in this Service Manual are subject to change without notice for product improvement or other purposes, and major changes will be communicated in the form of Service Information bulletins.

All service persons are expected to have a good understanding of the contents of this Service Manual and all relevant Service Information bulletins and be able to identify and isolate faults in the machine.

Contents

| | |
|--|-----------|
| Safety Precautions | 1 |
| Laser Safety..... | 2 |
| How to Handle the Laser Scanner Unit..... | 2 |
| Power Supply..... | 2 |
| Toner Safety..... | 3 |
| About Toner..... | 3 |
| Handling Adhered Toner..... | 3 |
| Notes When Handling a Lithium Battery..... | 3 |
| Notes Before it Works Serving..... | 3 |
| Points to Note at Cleaning..... | 4 |
| Notes on Assembly/Disassembly..... | 4 |
| | |
| 1. Product Overview | 5 |
| Product Lineup..... | 6 |
| Host Machine..... | 6 |
| Pickup/Delivery / Image Reading System Options..... | 7 |
| Function expansion system options..... | 8 |
| Specifications..... | 9 |
| Host machine..... | 9 |
| Weight and Size..... | 10 |
| Paper Type..... | 10 |
| Available Paper Types..... | 10 |
| Parts Name..... | 14 |
| Cross Section View..... | 14 |
| Control Panel..... | 15 |
| | |
| 2. Technology | 16 |
| Functional Configuration..... | 17 |
| Original Exposure System..... | 18 |
| Features..... | 18 |
| Specifications..... | 18 |
| Basic Configuration..... | 19 |
| Dust Detection Control..... | 23 |
| Image Processing..... | 24 |
| Outline of Electric Circuits..... | 30 |
| Scanner Unit..... | 30 |
| Pickup Feed System..... | 32 |
| ADF Scan Operation Sequence (Common to 2-sided/1-sided)..... | 36 |
| Controller System..... | 38 |
| Overview..... | 38 |
| Startup Sequence..... | 39 |
| Shutdown Sequence..... | 40 |
| Motion Sensor..... | 40 |
| Laser Exposure System..... | 42 |

| | |
|--|-----------|
| Overview..... | 42 |
| Laser ON/OFF Control..... | 42 |
| Scanner Motor Control..... | 43 |
| APC (Auto Power Control)..... | 43 |
| BD Detection Correction Control..... | 44 |
| Image Formation System..... | 45 |
| Overview..... | 45 |
| Cartridge..... | 46 |
| Transfer..... | 48 |
| Image Stabilization Control..... | 49 |
| Fixing System..... | 51 |
| Features..... | 51 |
| Fixing temperature control..... | 53 |
| Standby Temperature Control..... | 54 |
| Print Temperature Control..... | 54 |
| Down Sequence Control..... | 55 |
| Pre-fixing Arch Control..... | 55 |
| Fixing Film Unit engagement/disengagement control..... | 56 |
| Fixing Assembly detection..... | 57 |
| Fixing Assembly Life Detection..... | 58 |
| Protection Function..... | 58 |
| Pickup Feed System..... | 60 |
| Overview..... | 60 |
| Cassette Pickup Assembly..... | 66 |
| Multi-purpose Tray Pickup Assembly..... | 69 |
| Registration Assembly..... | 70 |
| Process Tray Assembly (Model with Built-in Finisher Only)..... | 70 |
| Stack Tray Assembly (Model with Built-in Finisher Only)..... | 73 |
| Delivery Assembly..... | 75 |
| Reverse/Duplex Assembly..... | 75 |
| Jam Detection..... | 76 |
| External Auxiliary System..... | 78 |
| Software Counter Control..... | 78 |
| Location of Fans..... | 80 |
| Power supply..... | 81 |
| Power-saving Function..... | 81 |
| Quick Startup..... | 83 |
| 3. Periodical Service..... | 85 |
| Periodically Replaced Parts..... | 86 |
| Consumable Parts List..... | 87 |
| Host Machine..... | 87 |
| Cassette Module-AG..... | 87 |
| Envelope Cassette Module-A1..... | 87 |
| High Capacity Cassette Feeding Unit-D1..... | 88 |
| Cassette Feeding Unit-AR1..... | 88 |
| 4. Parts Replacement and Cleaning..... | 89 |
| Preface..... | 90 |
| Outline..... | 90 |

| | |
|--|-----|
| Parts List..... | 91 |
| List of Cover (with Finisher)..... | 91 |
| List of Cover (without Finisher)..... | 93 |
| Main Unit..... | 95 |
| ADF..... | 97 |
| Reader..... | 98 |
| PCB..... | 99 |
| Switch..... | 101 |
| Fan..... | 103 |
| Motor..... | 104 |
| Sensor..... | 105 |
| Motor (with Finisher)..... | 106 |
| Sensor (Finisher)..... | 107 |
| Others (Finisher)..... | 108 |
| External Cover/Interior System..... | 109 |
| Removing the Rear Cover..... | 109 |
| Removing the Left Rear Cover..... | 109 |
| Removing the Front Cover..... | 110 |
| Removing the Inlet Cover..... | 111 |
| Removing the Right Lower Cover..... | 111 |
| Removing the Cartridge Door Unit..... | 113 |
| Removing the Control Panel..... | 115 |
| External / Internal Cover System (Finisher)..... | 119 |
| Removing the Finisher Rear Cover..... | 119 |
| Removing the Finisher Right Upper Cover..... | 119 |
| Removing the Finisher Left Rear Cover..... | 121 |
| Removing the Finisher Right Rear Cover..... | 121 |
| Removing the Finisher Right Lower Cover..... | 122 |
| Removing the Staple Cover..... | 122 |
| Removing the Staple Inner Cover..... | 123 |
| Removing the Delivery Tray..... | 124 |
| Removing the Inner Delivery Rear Cover..... | 124 |
| Removing the Finisher Inner Rear Cover..... | 125 |
| Original Exposure/Feed System..... | 127 |
| Removing the ADF Unit..... | 127 |
| Removing the ADF Pickup Unit..... | 135 |
| Removing the ADF Separation Unit..... | 136 |
| Removing the Scanner Unit (Back)..... | 137 |
| Removing the Copyboard Glass Unit..... | 144 |
| Removing the Scanner Unit (Front)..... | 145 |
| Removing the Reader Motor..... | 149 |
| Removing the ADF Feed Frame..... | 149 |
| Removing the CIS Holder..... | 181 |
| Controller System..... | 192 |
| Removing the Main Controller Sub Cover /Main Controller Cover..... | 192 |
| Removing the HDD..... | 193 |
| Removing the Main Controller PCB..... | 193 |
| Removing the Low-Voltage Power Supply PCB..... | 195 |
| Removing the Inlet Unit..... | 196 |
| Removing the DC Controller PCB..... | 198 |
| Removing the High-Voltage Power Supply PCB..... | 198 |

| | |
|---|------------|
| Removing the FAX Unit..... | 199 |
| Controller System (Finisher)..... | 203 |
| Removing the Finisher Controller PCB..... | 203 |
| Laser Exposure System..... | 204 |
| Removing the Laser Scanner Unit..... | 204 |
| Image Formation System..... | 205 |
| Removing the Transfer Unit..... | 205 |
| Removing the Developing Drive Unit..... | 206 |
| Removing the Lifter Drive Unit..... | 209 |
| Removing the Drum Motor Unit..... | 210 |
| Fixing System..... | 212 |
| Removing the Fixing Assembly..... | 212 |
| Removing the Fixing Drive Unit..... | 212 |
| Pickup Feed System..... | 214 |
| Removing the Paper Delivery Unit..... | 214 |
| Removing the Main Drive Unit..... | 215 |
| Removing the Paper Pickup Unit..... | 219 |
| Removing the Multi-purpose Tray Feed Roller..... | 222 |
| Removing the Multi-purpose Tray Separation Roller..... | 223 |
| Pickup Feed System (Finisher)..... | 225 |
| Removing the Jogger Unit..... | 225 |
| Removing the Staple Unit..... | 225 |
| Removing the Finisher Fan..... | 226 |
| Removing the Finisher Motor..... | 227 |
| Upper Paper Feed Unit..... | 227 |
| Lower Paper Feed Unit..... | 229 |
| 5. Adjustment..... | 232 |
| Pickup Feed System..... | 233 |
| Image Position Adjustment..... | 233 |
| Actions at Parts Replacement..... | 235 |
| Hard Disc..... | 235 |
| Main Controller PCB..... | 237 |
| DC Controller PCB..... | 237 |
| After Replacing the Copyboard Glass..... | 238 |
| After Replacing the Scanner Unit (Front)..... | 238 |
| After Replacing the Scanner Unit (Back)..... | 239 |
| After Replacing Touch Panel/Control Panel CPU PCB/LCD Unit..... | 240 |
| 6. Troubleshooting..... | 241 |
| Initial Check..... | 242 |
| Initial check items list..... | 242 |
| Test Print..... | 243 |
| Overview..... | 243 |
| How to use the test print..... | 244 |
| Debug Log..... | 248 |
| Function Overview..... | 248 |
| Saving and Collecting Debug Logs..... | 252 |
| Service Mode Relating to Debug Logs..... | 265 |

| | |
|---|------------|
| 7. Error/Jam/Alarm..... | 267 |
| Overview..... | 268 |
| Location Code..... | 268 |
| Pickup Position Code..... | 268 |
| Pickup size..... | 268 |
| Points to Note When Clearing MN-CON | 269 |
| Points to Note When Clearing HDD..... | 270 |
| Error Code..... | 271 |
| Error Code Details..... | 271 |
| Error Code (FAX)..... | 324 |
| How to View Fax Error Codes..... | 324 |
| User error codes..... | 324 |
| Service Error Code..... | 324 |
| Alarm Code..... | 327 |
| Alarm Code Details..... | 327 |
| Jam Code..... | 336 |
| Jam Type..... | 336 |
| Jam screen display specification..... | 337 |
| Main Unit..... | 337 |
| ADF / Reader..... | 338 |
| Option Cassette..... | 339 |
| Inner Finisher..... | 341 |
| 8. Service Mode..... | 342 |
| Overview..... | 343 |
| Basic Operations..... | 343 |
| SITUATION Mode..... | 346 |
| Security Support..... | 351 |
| Service Mode Backup..... | 355 |
| Output of Service Print Data..... | 355 |
| COPIER (Service mode for printer)..... | 360 |
| DISPLAY (State display mode)..... | 360 |
| I/O..... | 376 |
| ADJUST (Adjustment mode)..... | 376 |
| FUNCTION (Operation / inspection mode)..... | 427 |
| OPTION (Specification setting mode)..... | 446 |
| TEST (Print test mode)..... | 531 |
| COUNTER (Counter mode)..... | 535 |
| FEEDER (ADF service mode)..... | 548 |
| DISPLAY (State display mode)..... | 548 |
| ADJUST (Adjustment mode)..... | 548 |
| FUNCTION (Operation / inspection mode)..... | 550 |
| OPTION (Specification setting mode)..... | 551 |
| BOARD (Option board setting mode)..... | 553 |
| OPTION (Specification setting mode)..... | 553 |
| FAX (Service Mode for FAX)..... | 554 |
| Overview..... | 554 |
| Setting of Bit Switch (SSSW)..... | 557 |
| Setting of Menu Switch (MENU)..... | 568 |

| | |
|--|-----|
| Setting of Numeric Parameter (NUMERIC Param.)..... | 569 |
| Setting of Destination (TYPE)..... | 571 |
| Setting of Printer Functions (PRINTER)..... | 572 |
| IPFAX Setting..... | 574 |
| Initialization of Set Value (CLEAR)..... | 575 |
| Test Mode (TEST)..... | 575 |
| Service Report (REPORT)..... | 579 |

9. Installation..... 583

| | |
|--|-----|
| How to Utilize This Installation Procedure..... | 584 |
| Symbols..... | 584 |
| Host Mashine Installation..... | 585 |
| Setting the Dehumidification Switch..... | 585 |
| Operation when using uniFLOW Online..... | 585 |
| IC Card Reader Attachment-A1..... | 586 |
| Points to Note at Installation | 586 |
| Installation Outline Drawing | 586 |
| Checking the Contents..... | 586 |
| Essential Items to Be Performed Before Installation..... | 586 |
| Installation Procedure | 587 |
| NFC Kit-C1 | 591 |
| Points to Note when Installing | 591 |
| Installation Outline Drawing | 591 |
| Checking the Contents | 591 |
| Essential Items to Be Performed Before Installation..... | 591 |
| Installation procedure | 591 |
| Setting after Installation..... | 600 |
| Copy Card Reader-F1/Copy Card Reader Attachment-B5..... | 601 |
| Points to Note when Installing | 601 |
| Installation Outline Drawing | 601 |
| Checking the Contents | 601 |
| Essential Items to Be Performed Before Installation..... | 602 |
| Installation | 602 |
| Checking after Installation | 610 |
| Copy Control Interface Kit-A1 | 612 |
| Installation Outline Drawing | 612 |
| Checking the Contents | 612 |
| Essential Items to Be Performed Before Installation..... | 612 |
| Installation Procedure..... | 613 |
| Connection Kit-A1 for Bluetooth LE..... | 616 |
| Points to Note at Installation | 616 |
| Installation Outline Drawing..... | 616 |
| Essential Items to Be Performed Before Installation..... | 616 |
| Checking the Contents..... | 616 |
| Installation Procedure | 616 |
| Setting after Installation..... | 619 |
| Super G3 FAX Board-AY1..... | 620 |
| Checking before Installation..... | 620 |
| Installation Procedure..... | 621 |
| Checking the Operation..... | 627 |

APPENDICES..... 628

- Service Tools..... 629
 - Special Tools..... 629
 - Solvents and Oils..... 629
- General Circuit Diagram..... 630
 - Host machine 1/5..... 630
 - Host machine 2/5..... 631
 - Host machine 3/5..... 632
 - Host machine 4/5..... 633
 - Host machine 5/5..... 634
- Soft counter specifications..... 635
 - Software Counter Specifications..... 635
- Removal..... 639
 - Overview..... 639
 - Work Procedure..... 639

Safety Precautions

| | |
|---|---|
| Laser Safety..... | 2 |
| How to Handle the Laser Scanner Unit | 2 |
| Power Supply..... | 2 |
| Toner Safety..... | 3 |
| Notes When Handling a Lithium Battery..... | 3 |
| Notes Before it Works Serving..... | 3 |
| Points to Note at Cleaning..... | 4 |
| Notes on Assembly/Disassembly..... | 4 |

Laser Safety

Since radiation emitted inside this machine is completely confined with protective housings and external covers, the laser beam cannot escape from the machine during any phase of normal use by users.

Therefore, this machine is classified as a Class 1 laser product under the international standard IEC60825-1 that is regarded as safe during normal use.

How to Handle the Laser Scanner Unit

This machine is classified as a Class 1 laser product.

However, the laser scanner unit contains source of Class 3B laser beam and exposure to the beam may cause eye injuries.

Therefore, be sure not to disassemble the laser scanner unit. No adjustment can be made to the laser scanner unit in the machine in the field.


The mark or the warning label shown in the following figure is affixed on the laser scanner unit.

Dieses Gerät ist der Klasse 1 der Laserprodukte zugeordnet.

Allerdings enthält die Laserscannereinheit eine Laserstrahlquelle der Klasse 3B, die Augenschäden verursachen kann, wenn man in diesen Strahl blickt.

Deshalb darf die Laserscannereinheit nicht zerlegt werden. An der Laserscannereinheit kann keine Justage vor Ort vorgenommen werden.

Das in dem folgenden Bild dargestellte Kennzeichen bzw. der Warmaufkleber ist auf der Laserscannereinheit angebracht.



Power Supply

- As a general rule, do not use extension cords.

If an extension cord must be used, however, use one for local rated voltage and over, untie the cord binding, and insert the power plug completely into the extension cord outlet to ensure a firm connection between the power cord and the extension cord.

⚠ CAUTION:

Do not plug multiple cords together to an extension cord. It may cause a fire or electrical shock.

- The socket-outlet shall be installed near the equipment and shall be easily accessible.

Toner Safety

About Toner

Toner is a nontoxic matter composed of plastic, iron and a trace of pigments.

⚠ CAUTION:

Never throw toner in flames to avoid explosion.

Handling Adhered Toner

- Use dry tissue paper to wipe off toner adhered to skin or clothes and wash in water.
- Never use warm water for cleaning up toner to prevent toner particles from being gelated to soak into fibers permanently.
- Toner particles are reactive with vinyl polymers. Avoid contacting these materials.

Notes When Handling a Lithium Battery

Dispose of used batteries according to the instructions.

⚠ CAUTION:

Risk of explosion if battery is replaced by an incorrect type.

The following warnings are given to comply with Safety Principles (EN60950-1).

⚠ CAUTION:

Wenn mit dem falschen Typ ausgewechselt, besteht Explosionsgefahr.
Gebrauchte Batterien gemäß der Anleitung beseitigen.

警告

如果更換不正確之電池型式會有爆炸的風險
請依製造商說明書處理用過之電池

Notes Before it Works Serving

- At servicing, be sure to turn OFF the power source according to the specified steps and disconnect the power plug.
- Be sure to disconnect the power plug on a regular basis and remove dust and dirt accumulated around the outlet with dry cloth.

⚠ CAUTION:

Leaving the power plug connected for a long time in an environment having a lot of dust, moisture, or oily smoke will cause a fire. (Because dust accumulated in the surrounding area will absorb moisture and cause an insulation failure)

Points to Note at Cleaning

When performing cleaning using organic solvent such as alcohol, be sure to check that the component of solvent is vaporized completely before assembling.

Notes on Assembly/Disassembly

Follow the items below to assemble/disassemble the device.

1. Disconnect the power plug to avoid any potential dangers during assembling/disassembling works.
2. If not specially instructed, reverse the order of disassembly to reinstall.
3. Ensure to use the right screw type (length, diameter, etc.) at the right position when assembling.
4. To keep electric conduction, binding screws with washers are used to attach the grounding wire and the varistor. Ensure to use the right screw type when assembling.
5. Unless it is specially needed, do not operate the device with some parts removed.
6. Never remove the paint-locked screws when disassembling.

CAUTION:

English

CAUTION

The fuse may be in the neutral, and that the mains shall be disconnected to de-energize the phase conductors.

German

VORSICHT

Die Sicherung kann sich im Nulleiter befinden und das Hauptnetz muss abgetrennt werden, um die Phasenleiter stromlos zu machen.



Product Overview

| | |
|---------------------|----|
| Product Lineup..... | 6 |
| Specifications..... | 9 |
| Parts Name..... | 14 |

Product Lineup

Host Machine

Product name

imageRUNNER ADVANCE 715 / 615 / 525


The underlined numerical value indicates the print speed (ppm: page per minute).

| Model | 715I / 615I / 525I | 715IF / 615IF / 525IF | 715IFZ / 615IFZ / 525IFZ | 715IZ / 615IZ / 525IZ |
|----------------|--|-----------------------|--------------------------|-----------------------|
| Print speed | 71 ppm , 61 ppm , 52 ppm | | | |
| Reader | Equipped as standard | | | |
| ADF | Equipped as standard | | | |
| Inner Finisher | - | | Equipped as standard | |
| Cassette | Equipped as standard (Cassette 1), Optional (Cassette 2/3/4) | | | |
| HDD | Equipped as standard | | | |
| 1-line FAX | - | Equipped as standard | | - |

F : with FAX model


Z : with Inner Finisher model

Pickup/Delivery / Image Reading System Options



| No. | Product name |
|-----|--|
| 1 | ADF Access Handle-A1 |
| 2 | Cassette Module-AG1 |
| 3 | Envelope Cassette Module-A1 |
| 4 | High Capacity Cassette Feeding Unit-D1 |
| 5 | Cassette Feeding Unit-AR1 |

Function expansion system options



| No. | Product name |
|-----|--|
| 1 | NFC Kit-C1 |
| 2 | Copy Card Reader Attachment-B5 |
| 3 | Copy Card Reader-F1 |
| 4 | Copy Control Interface Kit-A1 |
| 5 | IC Card Reader Box-D1 |
| 6 | IC Card Reader Attachment-A1 |
| 7 | Super G3 FAX Board-AY1 |
| 8 | Connection Kit-A1 for Bluetooth LE |
| 9 | Power Supply Cable-V1 |
| 10 | Remote Fax Kit-A1 |
| | IP FAX Expansion Kit-B1 |
| | PCL International Font Set-A1 |
| | Picture Login-A1 |
| | Barcode Printing Kit-D1 |
| | Universal Send Trace & Smooth PDF Kit-A1 |
| | Universal Send Advanced Feature Set-H1 |
| | Universal Send Digital User Signature Kit-C1 |

Specifications

Host machine

| Item | Specifications |
|---|--|
| Machine installation method | Desk-top |
| Photosensitive medium | φ30mm, OPC |
| Exposure method | Semiconductor 4Beam Laser |
| Charging method | DC Roller Charging |
| Developing method | Dry, 1-component toner projection development |
| Transfer method | Roller Transfer |
| Separation method | Retard separation method without driving source |
| Pickup method | Stack bypass : Retard separation method Cassette : Retard separation method |
| Fixing method | On demand fixing |
| Drum cleaning method | Cleaning Blade |
| Toner type | 1-component |
| oner supplying method | ALL in one Cartridge |
| Toner level detection function | Yes |
| Leading edge image margin | 5.0mm +/-2.0mm |
| Left image margin | Left Side : 2.5 +/- 1.5 (duplex : 2.5 +/- 2.0) |
| Image gradations | 256 Gradation Levels |
| Print resolution | 9600 dpi (equivalent) x 600 dpi (at 600dpi mode) T.B.D. 1200 dpi x 1200 dpi (equivalent) (at 1200dpi mode) T.B.D. |
| Maximum image guarantee area | 205.9 x 345.6 mm T.B.D. |
| Maximum printable area | 209.4 x 348.1 mm T.B.D. |
| Warm-up time (Time from device power on, until copy ready) | After Powering ON : [Quick Startup Settings for Main Power] OFF: 30 sec. or less [Quick Startup Settings for Main Power] ON: 4 sec. or less (This may vary depending on the usage environment and usage conditions.) Returning from the Sleep mode : [Sleep Mode Eco Exit] OFF (default): 10 sec. or less [Sleep Mode Eco Exit] ON: 15 sec. or less (reference value) |
| First copy time | 5.0 sec (20 deg C to 30 deg C Environment) |
| Paper type / Paper Size | Refer to "Available Paper Types" on page 10 |
| Pickup capacity | Stack bypass : 100 sheets(75/80 g/m ²) 10 sheets(Envelope) Cassette : 550 sheets (75/80 g/m ²) |
| Memory capacity | RAM : 3GB Main CPU Side : 2GB Image Processing CPU Side : 1GB |
| Hard disk capacity | HDD : more than 250GB (Aavailable disk space 250GB. A different hard disc drive may be used.) |
| Rated power supply | 120 to 127V 60Hz T.B.D. A 110 to 127V 60Hz T.B.D. A 220 to 240V 50/60Hz T.B.D. A |

| Item | Specifications |
|-------------------------------------|---|
| Power consumption (reference value) | Max. power consumption :1500W or less Average power consumption while copying/printing (measured only one machine (Reference) while ADF copying) : T.B.D. Wh Average power consumption at standby mode (measured only one machine (Reference)) : T.B.D. Wh Power consumption at sleep mode : <ul style="list-style-type: none"> • Low energy consumption during sleep mode : TBD Wh • High energy consumption during sleep mode : TBD Wh Low energy consumption during sleep mode + Network connection is considered (measured only one machine (reference value)) 120V: TBD W 230V: TBD W |
| Dimensions / Weight | Refer to "Weight and Size" on page 10 |

Weight and Size

| Product name | Width (mm) | Depth (mm) | Height (mm) | Weight: Approx. (kg) |
|---|---------------------|--------------------------|-------------|----------------------|
| imageRUNNER ADVANCE 715 I / 615 I / 525 I | 513 | 601 (with Control Panel) | 617 | 33.5 *1 |
| imageRUNNER ADVANCE 715 IF / 615 IF / 525 IF | | | | 34.0 *1 |
| imageRUNNER ADVANCE 715 IFZ / 615IFZ / 525IFZ | 515 (with Finisher) | | 814 | 43.0 *1 |
| imageRUNNER ADVANCE 715 IZ / 615IZ / 525IZ | | | | 42.5 *1 |
| Cassette Feeding Unit-AR1 | 642 | 657 | 479 | 19 |
| High Capacity Cassette Feeding Unit-D1 | 642 | 657 | 479 | 25 |
| Cassette Module-AG1 | 484 | 450 | 150 | 7 |
| Envelope Cassette Module-A1 | 484 | 450 | 150 | 7 |

*1 : Including Toner Cartridge

Paper Type

Available paper types are shown below.
See the table below for the custom paper size.

| Product name | Feeding direction (mm) | Width direction (mm) |
|----------------------|------------------------|----------------------|
| Custom paper size 1 | 127.0 to 148.0 | 76.2 to 215.9 |
| Custom paper size 2 | 148.0 to 355.6 | 76.2 to 99.0 |
| Custom paper size 3 | 148.0 to 210.0 | 99.0 to 215.9 |
| Custom paper size 4 | 210.0 to 297.0 | 99.0 to 148.0 |
| Custom paper size 5 | 297.0 to 355.6 | 99.0 to 148.0 |
| Custom paper size 6 | 210.0 to 297.0 | 148.0 to 210.0 |
| Custom paper size 7 | 297.0 to 355.6 | 148.0 to 210.0 |
| Custom paper size 8 | 210.0 to 279.4 | 210.0 to 215.9 |
| Custom paper size 9 | 279.4 to 297.0 | 210.0 to 215.9 |
| Custom paper size 10 | 297.0 to 355.6 | 210.0 to 215.9 |

Available Paper Types

| Type (paper weight: g/m ²) | Size | Pickup position | | | | | | |
|--|------|--------------------|------------|--------------|--------------|------------------|-------|-------------|
| | | Multi-purpose Tray | Cassette 1 | Cassette AG1 | Cassette AR1 | High Capacity D1 | | Envelope A1 |
| | | | | | | CST 1 | CST 2 | |
| Thin Paper (60 g/m ²) | A4R | Yes | Yes | Yes | Yes | Yes | Yes | - |
| Plain Paper 1 (61 to 74 g/m ²) | B5R | Yes | Yes | Yes | Yes | Yes | - | - |
| | A5 | Yes | Yes | Yes | Yes | Yes | - | - |
| | A5R | Yes | Yes | Yes | Yes | Yes | - | - |


| Type (paper weight: g/m ²) | Size | Pickup position | | | | | | |
|--|------------------------|-------------------------|------------|-----------------|-----------------|------------------|-------|----------------|
| | | Multi-pur- pose Tray | Cassette 1 | Cassette AG1 | Cassette AR1 | High Capacity D1 | | Envelope A1 |
| | | | | | | CST 1 | CST 2 | |
| Plain Paper 2 (75 to 89 g/m ²) Plain Paper 3 (90 to 105 g/ m ²) Heavy Paper 1 (106 to 120 g/m ²) Color Paper (75 to 89 g/m ²) Recycled Paper (75 to 89 g/m ²) Bond Paper (75 to 90 g/m ²) | A6R | Yes | Yes | Yes | Yes | Yes | - | - |
| | LGL | Yes | - | Yes | Yes | Yes | Yes | - |
| | LTRR | Yes | Yes | Yes | Yes | Yes | Yes | - |
| | STMTR | Yes | Yes | Yes | Yes | Yes | - | - |
| | EXEC-R | Yes | Yes | Yes | Yes | Yes | - | - |
| | OFFICIO | Yes | - | Yes | Yes | Yes | - | - |
| | GLTR-R | Yes | Yes | Yes | Yes | Yes | - | - |
| | GLGL | Yes | - | Yes | Yes | Yes | - | - |
| | AFLS | Yes | - | Yes | Yes | Yes | - | - |
| | FLS | Yes | - | Yes | Yes | Yes | - | - |
| | K16R | Yes | Yes | Yes | Yes | Yes | - | - |
| | F4A | Yes | - | Yes | Yes | Yes | - | - |
| | I-LGL | Yes | - | Yes | Yes | Yes | - | - |
| | Custom paper size 1 | Yes | - | - | - | - | - | - |
| | Custom paper size 2 | Yes | - | - | - | - | - | - |
| | Custom paper size 3 | Yes | Yes | Yes | Yes | Yes | - | - |
| | Custom paper size 4 | Yes | Yes | Yes | Yes | Yes | - | - |
| | Custom paper size 5 | Yes | - | Yes | Yes | Yes | - | - |
| | Custom paper size 6 | Yes | Yes | Yes | Yes | Yes | - | - |
| | Custom paper size 7 | Yes | - | Yes | Yes | Yes | - | - |
| Custom paper size 8 | Yes | Yes | Yes | Yes | Yes | - | - | |
| Custom paper size 9 | Yes | Yes | Yes | Yes | Yes | - | - | |
| Custom paper size 10 | Yes | - | Yes | Yes | Yes | - | - | |
| Heavy Paper 2 (121 to 135 g/m ²) | A4R | Yes | Yes | Yes | Yes | Yes | Yes | - |
| | B5R | Yes | Yes | Yes | Yes | Yes | - | - |
| | A5 | Yes | Yes | Yes | Yes | Yes | - | - |
| | A5R | Yes | Yes | Yes | Yes | Yes | - | - |
| | A6R | Yes | Yes | Yes | Yes | Yes | - | - |
| | LGL | Yes | - | Yes | Yes | Yes | Yes | - |
| | LTRR | Yes | Yes | Yes | Yes | Yes | Yes | - |
| | STMTR | Yes | Yes | Yes | Yes | Yes | - | - |
| | EXEC-R | Yes | Yes | Yes | Yes | Yes | - | - |
| | OFFICIO | Yes | - | Yes | Yes | Yes | - | - |
| | GLTR-R | Yes | Yes | Yes | Yes | Yes | - | - |
| | GLGL | Yes | - | Yes | Yes | Yes | - | - |
| | AFLS | Yes | - | Yes | Yes | Yes | - | - |
| | FLS | Yes | - | Yes | Yes | Yes | - | - |
| | K16R | Yes | Yes | Yes | Yes | Yes | - | - |
| | F4A | Yes | - | Yes | Yes | Yes | - | - |
| | I-LGL | Yes | - | Yes | Yes | Yes | - | - |
| | Custom paper size 1 | Yes | - | - | - | - | - | - |
| | Custom paper size 2 | Yes | - | - | - | - | - | - |

| Type (paper weight: g/m ²) | Size | Pickup position | | | | | | |
|---|-------------------------|-------------------------|------------|-----------------|-----------------|------------------|-------|----------------|
| | | Multi-pur- pose Tray | Cassette 1 | Cassette AG1 | Cassette AR1 | High Capacity D1 | | Envelope A1 |
| | | | | | | CST 1 | CST 2 | |
| Heavy Paper 2 (121 to 135 g/m ²) | Custom paper size 3 | Yes | Yes | Yes | Yes | Yes | - | - |
| | Custom paper size 4 | Yes | Yes | Yes | Yes | Yes | - | - |
| | Custom paper size 5 | Yes | - | Yes | Yes | Yes | - | - |
| | Custom paper size 6 | Yes | Yes | Yes | Yes | Yes | - | - |
| | Custom paper size 7 | Yes | - | Yes | Yes | Yes | - | - |
| | Custom paper size 8 | Yes | Yes | Yes | Yes | Yes | - | - |
| | Custom paper size 9 | Yes | Yes | Yes | Yes | Yes | - | - |
| | Custom paper size 10 | Yes | - | Yes | Yes | Yes | - | - |
| Heavy Paper 3 (136 to 163 g/m ²) | A4R | Yes | - | - | - | - | - | - |
| | B5R | Yes | - | - | - | - | - | - |
| | A5 | Yes | - | - | - | - | - | - |
| | A5R | Yes | - | - | - | - | - | - |
| | A6R | Yes | - | - | - | - | - | - |
| | LGL | Yes | - | - | - | - | - | - |
| | LTRR | Yes | - | - | - | - | - | - |
| | STMTR | Yes | - | - | - | - | - | - |
| | EXEC-R | Yes | - | - | - | - | - | - |
| | OFFICIO | Yes | - | - | - | - | - | - |
| | GLTR-R | Yes | - | - | - | - | - | - |
| | GLGL | Yes | - | - | - | - | - | - |
| | AFLS | Yes | - | - | - | - | - | - |
| | FLS | Yes | - | - | - | - | - | - |
| | K16R | Yes | - | - | - | - | - | - |
| | F4A | Yes | - | - | - | - | - | - |
| | I-LGL | Yes | - | - | - | - | - | - |
| | Custom paper size 1 | Yes | - | - | - | - | - | - |
| | Custom paper size 2 | Yes | - | - | - | - | - | - |
| | Custom paper size 3 | Yes | - | - | - | - | - | - |
| | Custom paper size 4 | Yes | - | - | - | - | - | - |
| | Custom paper size 5 | Yes | - | - | - | - | - | - |
| Custom paper size 6 | Yes | - | - | - | - | - | - | |
| Custom paper size 7 | Yes | - | - | - | - | - | - | |
| Custom paper size 8 | Yes | - | - | - | - | - | - | |
| Custom paper size 9 | Yes | - | - | - | - | - | - | |
| Custom paper size 10 | Yes | - | - | - | - | - | - | |
| Heavy Paper 4 (164 to 199 g/m ²) | A4R | Yes | - | - | - | - | - | - |
| | B5R | Yes | - | - | - | - | - | - |

| Type (paper weight: g/m ²) | Size | Pickup position | | | | | | |
|---|------------------------|-------------------------|------------|-----------------|-----------------|------------------|-------|----------------|
| | | Multi-pur- pose Tray | Cassette 1 | Cassette AG1 | Cassette AR1 | High Capacity D1 | | Envelope A1 |
| | | | | | | CST 1 | CST 2 | |
| Heavy Paper 4 (164 to 199 g/m ²) | A5 | Yes | - | - | - | - | - | - |
| | A5R | Yes | - | - | - | - | - | - |
| | A6R | Yes | - | - | - | - | - | - |
| | LGL | Yes | - | - | - | - | - | - |
| | LTRR | Yes | - | - | - | - | - | - |
| | STMTR | Yes | - | - | - | - | - | - |
| | EXEC-R | Yes | - | - | - | - | - | - |
| | OFFICIO | Yes | - | - | - | - | - | - |
| | GLTR-R | Yes | - | - | - | - | - | - |
| | GLGL | Yes | - | - | - | - | - | - |
| | AFLS | Yes | - | - | - | - | - | - |
| | FLS | Yes | - | - | - | - | - | - |
| | K16R | Yes | - | - | - | - | - | - |
| | F4A | Yes | - | - | - | - | - | - |
| | I-LGL | Yes | - | - | - | - | - | - |
| | Custom paper size 1 | Yes | - | - | - | - | - | - |
| | Custom paper size 2 | Yes | - | - | - | - | - | - |
| | Custom paper size 3 | Yes | - | - | - | - | - | - |
| | Custom paper size 4 | Yes | - | - | - | - | - | - |
| | Custom paper size 5 | Yes | - | - | - | - | - | - |
| | Custom paper size 6 | Yes | - | - | - | - | - | - |
| Custom paper size 7 | Yes | - | - | - | - | - | - | |
| Custom paper size 8 | Yes | - | - | - | - | - | - | |
| Custom paper size 9 | Yes | - | - | - | - | - | - | |
| Custom paper size 10 | Yes | - | - | - | - | - | - | |
| Transparency (100 to 179 g/m ²) | A4R | Yes | - | - | - | - | - | - |
| | LTRR | Yes | - | - | - | - | - | - |
| Labels (130 g/m ²) | A4R | - | Yes | Yes | Yes | Yes | - | - |
| | LTRR | - | Yes | Yes | Yes | Yes | - | - |
| Pre-Punched Paper (75 to 80 g/m ²) | A4R | - | Yes | Yes | Yes | Yes | Yes | - |
| | LTRR | - | Yes | Yes | Yes | Yes | Yes | - |
| Envelope (80 to 100 g/m ²) | COM10_R | Yes | - | - | - | - | - | Yes |
| | Monarch_R | Yes | - | - | - | - | - | Yes |
| | ISO-C5_R | Yes | - | - | - | - | - | Yes |
| | DL_R | Yes | - | - | - | - | - | Yes |


Parts Name

Cross Section View



| No. | Name |
|-----|--------------------------------|
| 1 | ADF Unit |
| 2 | Scanner Unit (Back Side) |
| 3 | Reader Unit |
| 4 | Scanner Unit (Front Side) |
| 5 | Jogger Unit |
| 6 | Upper Paper Feed Unit |
| 7 | Staple Unit |
| 8 | Lower Paper Feed Unit |
| 9 | Duplex Paper Delivery Unit |
| 10 | Fixing Unit |
| 11 | Transfer Unit |
| 12 | Registration Unit |
| 13 | Right Door Unit |
| 14 | Multi-purpose Tray Pickup Unit |
| 15 | Feeding Unit |
| 16 | Laser Scanner Unit |
| 17 | Cassette 1 Pickup Unit |
| 18 | Cassette 1 |

Control Panel



| No. | Name |
|-----|-----------------------------------|
| 1 | [Settings/Registration] key |
| 2 | Numeric keys |
| 3 | [Energy Saver] key |
| 4 | [Counter/Device Information] key |
| 5 | Brightness Adjustment key |
| 6 | Settings key |
| 7 | [Clear] key |
| 8 | [Stop] key |
| 9 | [Start] key |
| 10 | Main Power indicator |
| 11 | Error indicator |
| 12 | Processing/Data indicator |
| 13 | [Reset] key |
| 14 | ID (Log In/Out) key |
| 15 | NFC (If equipped with NFC Kit-B1) |
| 16 | Touch panel display |




Technology

| | |
|--------------------------------|----|
| Functional Configuration..... | 17 |
| Original Exposure System..... | 18 |
| Controller System..... | 38 |
| Laser Exposure System..... | 42 |
| Image Formation System..... | 45 |
| Fixing System..... | 51 |
| Pickup Feed System..... | 60 |
| External Auxiliary System..... | 78 |

Functional Configuration

This machine consists of 6 major blocks: Original Exposure and Feed System, Controller System, Laser Exposure System, Image Formation System, Fixing System, and Pickup Feed System.



Original Exposure System


Features

Reader Assembly

- Color reproducibility has been improved by adopting a scanner unit with 3-line CIS installed, as compared with the conventional models.

ADF

- Addition of supported paper size
- Increased delivery stacking capacity
- Faster stream reading by using a 1-path ADF
- Increase in the supported original basis weight



Specifications

Reader Assembly

| Item | Specification/Function |
|--|--|
| Original exposure Photo conductor | LED |
| Reading resolution | 300 dpi x 600 dpi 600 dpi x 600 dpi |
| Number of gradations | 256 gradation |
| Magnification ratio | 25% to 400% (in 1% increment) |
| Original reading sensor Number of lines of the Reading Sensor | 3 lines (R, G, B) |
| Original size detection | Reader (At copyboard reading) No ADF Main scanning direction: No Sub scanning direction: by original feeding length |


■ ADF

| Item | Specification/Function |
|----------------------------------|---|
| Original separation method | Retard separation |
| Document scanning method | Stream reading |
| Original basis weight | 1-sided: 50 g/m ² to 128 g/m ² 2-sided: 50 g/m ² to 128 g/m ² Color original: 64 g/m ² to 128 g/m ² Black and White/Color mixed: 64 g/m ² to 128 g/m ² |
| Original size | A4, B5, A5, A6, LGL, LTRS, STMT, 16K Feed direction: 148 to 355.6 mm, Width direction 105.0 to 216.0 mm |
| Original Tray stacking capacity | 100sheets (50 g/m ² to 80 g/m ²) |
| Original size detection function | No |
| Mixed paper functions | Mix of the same configuration: Yes Mix of different configurations: No |
| Finished stamp function | No |
| Maximum document size | At copyboard reading: 216.0 mm x 355.6 mm When using the ADF: 216.0 mm x 355.6 mm |
| Document processing speed | Stream reading <ul style="list-style-type: none"> • Copy <ul style="list-style-type: none"> • 1-sided: 50 ipm (300 dpi x 600 dpi) • 2-sided: 100 ipm (300 dpi x 600 dpi) • 1-sided / BW : 50 ipm (600 dpi x 600 dpi) • 1-sided / Color : 30 ipm (600 dpi x 600 dpi) • 2-sided / BW: 100 ipm (600 dpi x 600 dpi) • 2-sided / Color : 50 ipm (600 dpi x 600 dpi) • Scan <ul style="list-style-type: none"> • 1-sided: 50 ipm • 2-sided: 100 ipm |

● Basic Configuration

■ Reader Unit

● Parts Configuration




| No. | Name |
|-----|------------------------|
| 1 | Guide Shaft |
| 2 | Drive Pulley |
| 3 | Drive Belt |
| 4 | Wireless LAN PCB |
| 5 | Motion Sensor |
| 6 | CIS HP Sensor |
| 7 | Reader Motor |
| 8 | ADF Open/Closed Sensor |
| 9 | Scanner Unit (Front) |


■ ADF Unit

● Functional Configuration

Functional configuration of the ADF in this equipment is shown below.



• **Parts Configuration**




| No. | Symbol | Name |
|-----|----------|---------------------------|
| 1 | LED_EXIT | Delivery Display LED |
| 2 | LED_DS | Original Display LED |
| 3 | - | Scanner Unit (Paper Back) |
| 4 | CL4201 | ADF Registration Clutch |
| 5 | CL4200 | ADF Pickup Clutch |
| 6 | M4201 | ADF Motor |
| 7 | - | ADF Cooling Fan |

• **Drive Configuration List**

The drive assembly of the ADF consists of a drive motor (ADF Motor), and 2 clutches (ADF Pickup Clutch and ADF Registration Clutch).


The drive configuration is indicated below.



| Code | Name | Role |
|-------|-----------|--------------------------------|
| M4201 | ADF Motor | Operate the rollers in the ADF |


| Code | Name | Role |
|--------|-------------------------|---|
| CL4200 | ADF Pickup Clutch | ON/OFF of lifting operation of the Pickup Roller |
| CL4201 | ADF Registration Clutch | ON/OFF of lifting operation of the Registration Roller Unit |

• List of Rollers



| No. | Name |
|-----|---------------------|
| 1 | Pickup Roller |
| 2 | Feed Roller |
| 3 | Separation Roller |
| 4 | Registration Roller |
| 5 | Registration Roller |
| 6 | Lead Roller 1 |
| 7 | Lead Roller 1 |
| 8 | Lead Roller 2 |
| 9 | Lead Roller 2 |
| 10 | Delivery Roller |
| 11 | Delivery Roller |

• List of Sensors



| No. | Code | Name |
|-----|----------|---|
| 1 | PS12 | Delivery Sensor |
| 2 | JUSO (R) | Double Feeding Detection PCB (Transmission) |
| 3 | JUSO (T) | Double Feeding Detection PCB (Reception) |
| 4 | SR4206 | Document End Sensor |
| 5 | REG | Registration Sensor |
| 6 | SR5 | ADF Cover Sensor |
| 7 | SR4204 | Document Sensor |

Dust Detection Control

When reading an original, the original reading position is changed according to the presence/absence of dust on the Stream Reading Glass or the Guide Plate of the ADF, or image correction is performed to prevent the dust from being printed on the image.


Control timing

Dust detection

- At job completion

Dust evasion


- When a job starts



Control description

At job completion (dust detection)

The Reading Sensor performs dust detection at a reading position. When it detects any dust, the sensor is moved to the position B if the sensor position is A, or to the position C if the position is B. This position will be the reading position for the next job.



At the start of a job and paper interval (dust evasion)

The Scanner Unit does not move.

Reading is performed at the position determined by the control performed at job completion or at the start of a job, and image correction is performed if dust is detected at that position.

Related service mode

- Adj dust detect level: ppr intvl, DADF:
Service mode > COPIER > OPTION > IMG-RDR > DFDST-L1
- Adj dust dtct level:strem, ppr int, back:
Service mode > COPIER > OPTION > IMG-RDR > DF2DSTL1

Image Processing

The functions of the PCB related to image processing are shown below:

- Main Controller PCB
 - Shading correction (executed per job)
 - Color displacement correction in vertical scanning direction
- Scanner Unit PCB
 - Scanner Unit drive, analog image processing, A/D conversion


Image processing is performed by the Main Controller PCB for each line of the images. The main functions are indicated below.

Main Controller PCB

- Shading correction
- Color displacement correction in vertical scanning direction

Scanner Unit PCB (in the Scanner Unit)

- Scanner Unit Drive
- Gain correction of the Reading Sensor output, Offset correction



■ Shading Correction

● Overview

Even if the original density is even, output of the CIS Reading Sensor in the Scanner Unit may not become even. A control that corrects variations in the output is shading correction.

Main causes of uneven output of the Reading Sensor are shown below.

- Variation in sensitivity of pixel of the Reading Sensor
- Uneven light intensity of the lens
- Uneven light intensity of the LED and light guide plate
- Deterioration of the LED
- Variations in luminance between at the position of the Standard White Plate and at the reading position

To correct unevenness of the Reading Sensor output, shading correction is performed.


In shading correction, there is a type of shading correction that is executed per job.

● Shading Correction (Common to Reader and ADF)

Shading correction is performed for each scanning of original.

With this operation, light of LED Lamp is emitted to the Standard White Plate, and the reflected light is converted into digital data at the analog image processing part of the Scanner Unit PCB. The amount of digitized reflected light is input to the shading correction circuit in the Main Controller PCB as the shading coefficient. In the shading correction circuit, the stored target value and the shading coefficient are compared, and the difference is determined as the shading correction value.

With this shading correction value, variation of pixel of the Reading Sensor of each scan is corrected to make the image density level even.




Shading correction (ADF side)

Positional relationship between the CIS Reading Sensor and the Standard White Plate differs between at the Reader side and at the ADF side. Therefore, when performing shading correction to the Reading Sensor at ADF side, the correction value stored in advance needs to be taken into consideration. This corrects difference in image density caused by positional relationship.

■ Color Displacement Correction Processing in Vertical Scanning Direction

Color displacement correction control in the vertical scanning direction is used to correct displacement of R, G, and B by shifting the pixels in the vertical scanning direction (by less than 1 pixel) to align the red (R) and blue (B) images with green (G) when the scanned R, G, and B images are not accurately overlapped at color scanning.

Example: A scanned image of a black line where red (R) is displaced upward and blue (B) is displaced downward with respect to green (G)



As for the color displacement correction value in the vertical scanning direction, there are two types of reader scans as shown below. These correction values have been adjusted at the time of shipment, and stored as service mode values. (In COPIER > ADJUST > CCD)

100-RG, 100-BG, 100DF-RG, 100DF-GB, 100DF2GB, 100DF2RG

When a job is started, color displacement correction processing is performed based on the saved color displacement correction values.

Service Mode

- RG clr displc correct: front, vert scan :
COPIER > ADJUST > CCD > 100-RG
- GB clr displc correct: front, vert scan :
COPIER > ADJUST > CCD > 100-BG
- RG clr displc crct:DADF,front,vert scan :
COPIER > ADJUST > CCD > 100DF-RG
- GB clr displc crct:DADF,front,vert scan :
COPIER > ADJUST > CCD > 100DF-GB
- GB clr displc correct: back, vert scan (Lv.2) :
COPIER > ADJUST > CCD > 100DF2GB
- RG clr displc correct: back, vert scan (Lv.2) :
COPIER > ADJUST > CCD > 100DF2RG

■ Gain Correction of the Reading Sensor Output, Offset Correction

The analog video signal output from the Reading Sensor has its amplification ratio aligned with a fixed value (gain correction) and has its output voltage when there is no incident light aligned with a fixed value (offset correction).

Service mode


- Stdrd White Plt white lvl data (X/Y/Z) entry
 COPIER > ADJUST > CCD > W-PLT-X : X
 COPIER > ADJUST > CCD > W-PLT-Y : Y
 COPIER > ADJUST > CCD > W-PLT-Z : Z
- RG/GB clr dispcl correct: front, vert scan
 COPIER > ADJUST > CCD > 100-RG :RG
 COPIER > ADJUST > CCD > 100-GB : GB
- RG/GB clr dispcl crrect:DADF,front,vert scan
 COPIER > ADJUST > CCD > 100DF-RG :RG
 COPIER > ADJUST > CCD > 100DF-GB :GB
- Enter shading target VL (R/G/B): front, 1st
 COPIER > ADJUST > CCD > DFTAR-R
 COPIER > ADJUST > CCD > DFTAR-G
 COPIER > ADJUST > CCD > DFTAR-B
- Enter shading target VL (R/G/B): front, 2nd
 COPIER > ADJUST > CCD > DFTAR2-R : R
 COPIER > ADJUST > CCD > DFTAR2-G : G
 COPIER > ADJUST > CCD > DFTAR2-B : B
- MTF value entry:DADF, front, horz scan
 COPIER > ADJUST > CCD > MTF2-M1 : MTF value 1
 COPIER > ADJUST > CCD > MTF2-M2 : MTF value 2
 COPIER > ADJUST > CCD > MTF2-M3 : MTF value 3
 COPIER > ADJUST > CCD > MTF2-M4 : MTF value 4
 COPIER > ADJUST > CCD > MTF2-M5 : MTF value 5
 COPIER > ADJUST > CCD > MTF2-M6 : MTF value 6
 COPIER > ADJUST > CCD > MTF2-M7 : MTF value 7
 COPIER > ADJUST > CCD > MTF2-M8 : MTF value 8
 COPIER > ADJUST > CCD > MTF2-M9 : MTF value 9
- MTF value 1 entry:DADF, front, vert scan
 COPIER > ADJUST > CCD > MTF2-S1 : MTF value 1
 COPIER > ADJUST > CCD > MTF2-S2 : MTF value 2
 COPIER > ADJUST > CCD > MTF2-S3 : MTF value 3
 COPIER > ADJUST > CCD > MTF2-S4 : MTF value 4
 COPIER > ADJUST > CCD > MTF2-S5 : MTF value 5
 COPIER > ADJUST > CCD > MTF2-S6 : MTF value 6
 COPIER > ADJUST > CCD > MTF2-S7 : MTF value 7
 COPIER > ADJUST > CCD > MTF2-S8 : MTF value 8
 COPIER > ADJUST > CCD > MTF2-S9 : MTF value 9
- GB/RG clr dispcl correct: back, vert scan
 COPIER > ADJUST > CCD > 100DF2GB : GB
 COPIER > ADJUST > CCD > 100DF2RG : RG
- Complex chart No.2 data (R/G/B) entry: front
 COPIER > ADJUST > CCD > DFCH2R2 : Complex chart No.2 data (R)
 COPIER > ADJUST > CCD > DFCH2R10 : Complex chart No.10 data (R)
 COPIER > ADJUST > CCD > DFCH2B2 : Complex chart No.2 data (B)
 COPIER > ADJUST > CCD > DFCH2B10 : Complex chart No.10 data (B)
 COPIER > ADJUST > CCD > DFCH2G2 : Complex chart No.2 data (G)
 COPIER > ADJUST > CCD > DFCH2G10 : Complex chart No.10 data (G)
- Complex chart No.2 data (R/G/B) entry: back
 COPIER > ADJUST > CCD > DFCH-R2 : Complex chart No.2 data (R)
 COPIER > ADJUST > CCD > DFCH-R10 : Complex chart No.10 data (R)
 COPIER > ADJUST > CCD > DFCH-B2 : Complex chart No.2 data (B)
 COPIER > ADJUST > CCD > DFCH-B10 : Complex chart No.10 data (B)
 COPIER > ADJUST > CCD > DFCH-G2 : Complex chart No.2 data (G)
 COPIER > ADJUST > CCD > DFCH-G10 : Complex chart No.10 data (G)

- MTF value entry: Copyboard, horz scan
 - COPIER > ADJUST > CCD > MTF-M1 : MTF value 1
 - COPIER > ADJUST > CCD > MTF-M2 : MTF value 2
 - COPIER > ADJUST > CCD > MTF-M3 : MTF value 3
 - COPIER > ADJUST > CCD > MTF-M4 : MTF value 4
 - COPIER > ADJUST > CCD > MTF-M5 : MTF value 5
 - COPIER > ADJUST > CCD > MTF-M6 : MTF value 6
 - COPIER > ADJUST > CCD > MTF-M7 : MTF value 7
 - COPIER > ADJUST > CCD > MTF-M8 : MTF value 8
 - COPIER > ADJUST > CCD > MTF-M9 : MTF value 9
- MTF value entry: Copyboard, vert scan
 - COPIER > ADJUST > CCD > MTF-S1 : MTF value 1
 - COPIER > ADJUST > CCD > MTF-S2 : MTF value 2
 - COPIER > ADJUST > CCD > MTF-S3 : MTF value 3
 - COPIER > ADJUST > CCD > MTF-S4 : MTF value 4
 - COPIER > ADJUST > CCD > MTF-S5 : MTF value 5
 - COPIER > ADJUST > CCD > MTF-S6 : MTF value 6
 - COPIER > ADJUST > CCD > MTF-S7 : MTF value 7
 - COPIER > ADJUST > CCD > MTF-S8 : MTF value 8
 - COPIER > ADJUST > CCD > MTF-S9 : MTF value 9
- MTF value entry: DADF, back, horz scan
 - COPIER > ADJUST > CCD > MTF3-M1 : MTF value 1
 - COPIER > ADJUST > CCD > MTF3-M2 : MTF value 2
 - COPIER > ADJUST > CCD > MTF3-M3 : MTF value 3
 - COPIER > ADJUST > CCD > MTF3-M4 : MTF value 4
 - COPIER > ADJUST > CCD > MTF3-M5 : MTF value 5
 - COPIER > ADJUST > CCD > MTF3-M6 : MTF value 6
 - COPIER > ADJUST > CCD > MTF3-M7 : MTF value 7
 - COPIER > ADJUST > CCD > MTF3-M8 : MTF value 8
 - COPIER > ADJUST > CCD > MTF3-M9 : MTF value 9
- MTF value entry: DADF, back, vert scan
 - COPIER > ADJUST > CCD > MTF3-S1 : MTF value 1
 - COPIER > ADJUST > CCD > MTF3-S2 : MTF value 2
 - COPIER > ADJUST > CCD > MTF3-S3 : MTF value 3
 - COPIER > ADJUST > CCD > MTF3-S4 : MTF value 4
 - COPIER > ADJUST > CCD > MTF3-S5 : MTF value 5
 - COPIER > ADJUST > CCD > MTF3-S6 : MTF value 6
 - COPIER > ADJUST > CCD > MTF3-S7 : MTF value 7
 - COPIER > ADJUST > CCD > MTF3-S8 : MTF value 8
 - COPIER > ADJUST > CCD > MTF3-S9 : MTF value 9
- Enter shading target VL (R/G/B): back side
 - COPIER > ADJUST > CCD > DFTBK-G : G
 - COPIER > ADJUST > CCD > DFTBK-B : B
 - COPIER > ADJUST > CCD > DFTBK-R : R
- Enter shading target VL (R/G/B): front, 3rd
 - COPIER > ADJUST > CCD > DFTAR3-R : R
 - COPIER > ADJUST > CCD > DFTAR3-G : G
 - COPIER > ADJUST > CCD > DFTAR3-B : B
- Adj CIS-ch offset:front,B&W mode,600dpi
 - COPIER > ADJUST > CCD > OFST-BW0 : ch0
 - COPIER > ADJUST > CCD > OFST-BW1 : ch1
 - COPIER > ADJUST > CCD > OFST-BW2 : ch2
 - COPIER > ADJUST > CCD > OFST-BW3 : ch3
 - COPIER > ADJUST > CCD > OFST-BW4 : ch4
 - COPIER > ADJUST > CCD > OFST-BW5 : ch5
- Adj CIS-ch offset:front,clr mode,300dpi
 - COPIER > ADJUST > CCD > OFST-CL0 : ch0
 - COPIER > ADJUST > CCD > OFST-CL1 : ch1
 - COPIER > ADJUST > CCD > OFST-CL2 : ch2
 - COPIER > ADJUST > CCD > OFST-CL3 : ch3
 - COPIER > ADJUST > CCD > OFST-CL4 : ch4
 - COPIER > ADJUST > CCD > OFST-CL5 : ch5

- Adj CIS-ch offset:front,clr mode,600dpi
 COPIER > ADJUST > CCD > OFST2CL0 : ch0
 COPIER > ADJUST > CCD > OFST2CL1 : ch1
 COPIER > ADJUST > CCD > OFST2CL2 : ch2
 COPIER > ADJUST > CCD > OFST2CL3 : ch3
 COPIER > ADJUST > CCD > OFST2CL4 : ch4
 COPIER > ADJUST > CCD > OFST2CL5 : ch5
- Adj CIS gain level:front,clr mode,300dpi/600dpi
 COPIER > ADJUST > CCD > GAIN-CL0 : 300dpi
 COPIER > ADJUST > CCD > GAIN2CL0 : 600dpi
- Adj pry lgt src lgt time: frt,clr,300dpi/600dpi
 COPIER > ADJUST > CCD > LED-CL-R : The primary light source(for 300dpi)
 COPIER > ADJUST > CCD > LED2CL-R : The primary light source(for 600dpi)
 COPIER > ADJUST > CCD > LED-CLR2 : The secondary light source(for 300dpi)
 COPIER > ADJUST > CCD > LED2CLR2 : The secondary light source(for 600dpi)
- Adj CIS-ch offset: back,clr mode,300dpi
 COPIER > ADJUST > CCD > OFST3CL0 : ch0
 COPIER > ADJUST > CCD > OFST3CL1 : ch1
 COPIER > ADJUST > CCD > OFST3CL2 : ch2
 COPIER > ADJUST > CCD > OFST3CL3 : ch3
 COPIER > ADJUST > CCD > OFST3CL4 : ch4
 COPIER > ADJUST > CCD > OFST3CL5 : ch5
- Adj CIS-ch offset: back,clr mode,600dpi
 COPIER > ADJUST > CCD > OFST4CL0 : ch0
 COPIER > ADJUST > CCD > OFST4CL1 : ch1
 COPIER > ADJUST > CCD > OFST4CL2 : ch2
 COPIER > ADJUST > CCD > OFST4CL3 : ch3
 COPIER > ADJUST > CCD > OFST4CL4 : ch4
 COPIER > ADJUST > CCD > OFST4CL5 : ch5
- Adj CIS gain level: back,clr mode,300dpi/600dpi
 COPIER > ADJUST > CCD > GAIN3CL0 : 300dpi
 COPIER > ADJUST > CCD > GAIN4CL0 : 600dpi
- Adj pry lgt src lgt time:back,clr,300dpi/600dpi
 COPIER > ADJUST > CCD > LED3CL : The primary light source (for 300dpi)
 COPIER > ADJUST > CCD > LED3CL2 : The secondary light source (for 300dpi)
 COPIER > ADJUST > CCD > LED4CL : The primary light source (for 600dpi)
 COPIER > ADJUST > CCD > LED4CL2 : The secondary light source (for 600dpi)
- Adj pry lgt src lgt time: frt,B&W,600dpi
 COPIER > ADJUST > CCD > LED-BW-1 : The primary light source (for 600dpi)
 COPIER > ADJUST > CCD > LED-BW-2 : The secondary light source (for 600dpi)
 COPIER > ADJUST > CCD > LED2BW-1 : The primary light source (for 600dpi)
 COPIER > ADJUST > CCD > LED2BW-2 : The secondary light source (for 600dpi)
- Adj CIS gain level:front/bck,B&W mode,600dpi
 COPIER > ADJUST > CCD > GAIN-BW1 : front
 COPIER > ADJUST > CCD > GAIN-BW2 : back
- Adj CIS-ch offset:back,B&W mode,600dpi
 COPIER > ADJUST > CCD > OFST2BW0 :ch0
 COPIER > ADJUST > CCD > OFST2BW1 :ch1
 COPIER > ADJUST > CCD > OFST2BW2 :ch2
 COPIER > ADJUST > CCD > OFST2BW3 :ch3
 COPIER > ADJUST > CCD > OFST2BW4 :ch4
 COPIER > ADJUST > CCD > OFST2BW5 :ch5

Outline of Electric Circuits

The relations of the electrical components are shown below.



Related error code

Scanner Unit communication error

- E280 - 0001
- E280 - 0002
- E280 - 0101
- E280 - 0102


Scanner Unit

■ Configuration of the Scanner Unit

The Scanner Unit has the same mechanism as that of the reader. This equipment uses a Scanner Unit that integrates an LED, mirror, lens, and Reading Sensor to perform original exposure and reading.

Light emitted from LED is reflected by the original and reaches the Reading Sensor through the Reflection Mirror and the Lens Unit.

Note that there is a difference in externals of the unit for the ADF and that for the reader due to the shapes of the locations where they are installed; therefore, they cannot be exchanged.



The Reading Sensor consists of 3 lines (R, G, and B) and all lines are used at reading.

Related error codes

E302 - 000x: Error in paper front shading

- E302 - 0001: Error in paper front white shading
- E302 - 0002: Error in paper front black shading
- E302 - 0003: Error in paper front shading


E302 - 010x: Error in paper back shading

- E302 - 0101: Error in paper back white shading
- E302 - 0102: Error in paper back black shading
- E302 - 0103: Error in paper back shading

• Scanner Unit

This equipment uses a Scanner Unit that integrates an LED, mirror, and Reading Sensor to perform original exposure and reading.

Light emitted from LED is reflected by the original and reaches the Reading Sensor through the Lens Unit.



The Reading Sensor consists of 3 lines (R, G, and B) and all lines are used at B&W and color reading.

Related error code

E280- 000x: Scanner Unit communication error

- E280- 0001: Scanner Unit communication error
- E280- 0002: Scanner Unit communication error

E280- 010x: Scanner Unit communication error

- E280- 0101: Scanner Unit communication error
- E280- 0102: Scanner Unit communication error

E302- 000x: Error in paper front shading

- E302 - 0001: Error in paper front white shading
- E302 - 0002: Error in paper front black shading
- E302 - 0003: Error in paper front shading


E302 - 010x: Error in paper back shading

- E302 - 0101: Error in paper back white shading
- E302 - 0102: Error in paper back black shading
- E302 - 0103: Error in paper back shading

■ Duplex Reading Control

2-sided originals are read using simultaneous duplex reading.


With one feed, the Scanner Unit of the Reader Unit reads the front side and the Scanner Unit of the ADF reads the back side so that both sides can be read without reversing the paper.



Pickup Feed System

Original size detection

This equipment calculates the original size in the feed direction using detection signals of the Document End Sensor (SR4206) and the Registration Sensor.




Original Detection

As the actuator is pushed up by placing an original on the Original Tray, the Document Sensor (SR4204) detects that light is blocked and judges as original present.

Pickup Operation

The pickup operation is performed by the Pickup Roller, Separation Roller, and Feed Roller. The Pickup Roller and Feed Roller are driven by the ADF Motor (M4201). By turning ON the ADF Pickup Clutch (CL4200) after completion of the pickup operation, the Pickup Roller Unit is lifted up.




| No. | Name |
|-------|-------------------|
| 1 | Pickup Roller |
| 2 | Feed Roller |
| 3 | Separation Roller |
| M4201 | ADF Motor |

| No. | Name |
|--------|-------------------|
| CL4200 | ADF Pickup Clutch |

■ Original Feed Control

With this machine, an arch is formed at the location where the Registration Roller is allocated in order to correct skew and increase the feed accuracy.




| No. | Name |
|-----|---------------------|
| 1 | Registration Roller |
| 2 | Registration Sensor |

■ Jam Detection

This equipment detects original jam using the sensors shown in the figure below.

When a jam occurs, the machine stores the information by the code.

This equipment's jam code can be checked in service mode of the host machine or by outputting a jam/error log report from service mode.




| No. | Name |
|-----|------------------------------|
| 1 | Registration Sensor |
| 2 | Double Feeding Detection PCB |
| 3 | Document End Sensor |
| 4 | Delivery Sensor |

■ Double Feed Detection Control

This machine has the Double Feed Detection PCBs (Transmission/Reception) (USO (T) / JUSO (R)) to detect double feeding of paper.

The Double Feed Detection PCBs (Transmission/Reception) (JUSO (T) / JUSO (R)) using ultrasonic method that are located between the Registration Roller and the Lead Roller perform double feed detection. Once it is judged that double feed has occurred, the machine stops operation due to a jam.


At the start of a job, the sensor level is checked while there is no original, and the threshold value for double feed detection is calculated. During a job, the Document End Sensor (SR4206) detects the leading edge and trailing edge of each sheet of the original and compares them with the threshold values at the start of the job to judge whether double feed occurs.



| No. | Symbol | Name |
|-----|----------|---|
| 1 | REG | Registration Sensor |
| 2 | - | Registration Roller |
| 3 | JUSO (R) | Double Feeding Detection PCB (Reception) |
| 4 | JUSO (T) | Double Feeding Detection PCB (Transmission) |
| 5 | - | Lead Roller 1/2 |
| 6 | SR4206 | Document End Sensor |

NOTE:

The Double Feed Detection PCB uses an ultrasonic sensor. With the ultrasonic method, the oscillation portion emits ultrasonic wave to the paper surface. In the result, new ultrasonic wave is generated as the paper vibrates, and the reception side reads the ultrasonic wave. A double feed is detected when the oscillation is smaller due to the second sheet of paper.



■ Types of jam

● Feed System

| Location | Jam code | Jam type | Sensor name | Sensor number |
|----------|----------|------------|---------------------|---------------|
| 01 | 0001 | Delay | Registration Sensor | REG |
| | 0002 | Stationary | | |

| Location | Jam code | Jam type | Sensor name | Sensor number |
|----------|----------|------------|---------------------|---------------|
| 01 | 0042 | Stationary | Registration Sensor | REG |
| | 0009 | Delay | Document End Sensor | SR4206 |
| | 0049 | Delay | | |
| | 0010 | Stationary | | |
| | 0050 | Stationary | Delivery Sensor | SR2 |
| | 0013 | Delay | | |
| | 0014 | Stationary | | |
| | 0053 | Delay | | |
| | 0054 | Stationary | | |

• Double Feed Detection

| Location | Jam code | Jam type | Sensor name | Sensor number |
|----------|----------|---|--------------------------|---------------|
| 01 | 0020 | Double feed jam (during a job) | Double Feeding Detection | JUSO (T) |
| | 0021 | Sensor communication error (during a job) | PCB (Transmission) | JUSO (R) |
| | 0060 | Double feed jam (during a job, first sheet) | Double Feeding Detection | |
| | 0061 | Sensor communication error (during a job, first sheet) | PCB (Reception) | |
| | 0062 | Sensor adjustment reception level error (at the start of a job) | | |
| | 0063 | Sensor adjustment communication error (at the start of a job) | | |

• Others

| Location | Jam code | Jam type | Sensor name | Sensor number |
|----------|----------|-------------------------|------------------------|---------------|
| 01 | 0071 | Software timing error*1 | - | - |
| | 0090 | DADF open | ADF Open/Closed Sensor | SR4 |
| | 0091 | DADF opened by user | | |
| | 0092 | Cover open | ADF Cover Sensor | SR5 |
| | 0093 | Cover opened by user | | |
| | 0094 | Initial stationary jam | - | - |
| | 0095 | Pickup error | Document Sensor | SR4204 |
| | 0096 | Limited functions jam*2 | - | - |

*1:It occurs when a software sequence error has occurred for some reasons. The machine is recovered by opening and then closing the cover to remove jammed paper.


*2: Limited functions jam is a jam for preventing an original to be left inside the machine when a problem which requires the machine moves to limited functions mode occurs. If an error occurs for some reasons, a jam message is displayed to prompt the user to perform jam removal. After that, an error is displayed, and the device enters limited functions mode. The machine recovers when the cause of the error is solved.

If this jam occurs, refer to the error log, and perform the remedy for the error code which has occurred at the same time.


ADF Scan Operation Sequence (Common to 2-sided/1-sided)

The operation sequence of original scan by the ADF is shown below.


Setting the original




1st sheet pickup & separation




1st sheet arch creation



1st sheet scanning
2nd sheet Preparing




1st sheet trailing edge detection
2nd sheet pickup & separation




1st sheet delivery

2nd sheet arch creation




1st sheet end


2nd sheet scanning




2nd sheet trailing edge detection



2nd sheet delivery




2nd sheet end



Controller System


Overview

■ Configuration/Function




| No. | Item | Function |
|-----|---------------------|---|
| [1] | Main Controller PCB | System Control/Memory Control/Printer Output Image Processing Control, Reader Image Input Processing, Card Reader Connection I/F, Fax Image Processing, USB Extension HUB Connection I/F RAM Temporary storage of image data: Capacity of 2 GB (for controller control) + 1 GB (for image processing) USB port USB2.0 Device I/F, USB3.0 Host I/F |
| [2] | TPM PCB | This PCB generates and stores encryption keys. Only when Management Settings > Data Management > TPM Settings is "On". * Not to be installed for China |
| [3] | Flash PCB | Storage of system software: 1 GB |
| [4] | HDD | 2.5 inch SATA I/F Standard: 250 GB Storing address book, security information (passwords, certificates), image data, environment settings |

■ Main Controller PCB



● Startup Sequence



Screen sequence and internal processing sequence

NOTE:

To achieve faster startup, the progress bar and the active PCB are not synchronized. For this reason, the progress bar cannot be utilized for troubleshooting. For information about troubleshooting, refer to "Related error codes (major error codes)" shown below.

Related error codes (major error codes):

- E602-0001: HDD detection error
- E614-0001: Flash PCB detection error
- E614-0002: Error in file system on the Flash PCB
- E614-4001: Error in file system on the Flash PCB
- E614-4002: Error in file system on the Flash PCB
- E748-2010: Flash PCB error / HDD error

NOTE:

When the following errors occur, the system of the host machine has not been started normally. Therefore the error code is not recorded in the log.
E602-XX01, E614-XX01, E748-2010

Shutdown Sequence

Before shutting down the power supply, it is necessary to perform the HDD completion process (Purpose: to prevent damage on the HDD) and execute the fixing disengagement operation. This sequential process is called "shutdown sequence". The shutdown sequence has been manually executed with the legacy (existing) models (by holding down the power supply switch on the Control Panel for a specific duration).

With this machine, the Main Controller PCB detects turning OFF the Main Power Supply Switch, and the shutdown sequence is started and executed automatically.

Note that the maximum shutdown time with this equipment is 110 seconds.

NOTE:

When the power supply is stopped without advance shutdown of the equipment, or the complete deletion process of the HDD (deletion of the primary file) failed to be completed within the shutdown time (max. 110 sec.), data matching is checked at startup. The progress bar is displayed during the data checking.

Motion Sensor

Function

Automatic recovery from sleep mode

- The machine automatically recovers from sleep mode by staying in the designated area for more than a certain period of time. The time spent in the area varies based on the setting of sensitivity (4 levels).
- The sensor determines whether a person approaches the above mentioned area is a user. If a person approaches the machine from the front side, it starts the operation to recover from sleep mode early. If a person approaches the machine from the side, the sensor judges whether he/she is just a passer to prevent recovery by mistake.

CAUTION:

Recovery time depends on the time for recovery from sleep mode of the host machine. The Motion Sensor outputs the trigger for recovery from sleep mode. Operation of the Motion Sensor is the same for recovery from Deep Sleep and from Sleep 1, but time for recovery differs depending on the recovery process of the host machine.

The machine is not recovered by a passer.

- Reduce unnecessary power consumption
- The machine may recover from sleep mode if walking speed is slow. However, if no operation is performed for a certain period of time, it moves to sleep mode again.


CAUTION:

Since the detection is performed by outputting a certain frequency from the output part and receiving the reflection wave by the reception part; thus, do not block the sensor area.

Settings / Registration

Preferences > Timer / Energy Settings > Use Motion Sensor

In Settings / Registration, you can disable the sensor and select the sensor sensitivity.

**CAUTION:**


- The motion sensor detects people or objects that approach the sensor on the front side of the machine. Operation may become unstable if objects are left near the sensor or the machine is placed in a location where there is heavy human traffic.
- The motion sensor uses ultrasonic waves, and thus may encounter problems due to other sources of ultrasonic waves in its environment.
- If you feel that something is wrong with the motion sensor, change the sensitivity setting or turn the motion sensor off in [Settings / Registration] > [Preferences] > [Timer/Energy Settings] > [Use Motion Sensor] > [Sensor Sensitivity].

Laser Exposure System

Overview

The laser exposure system forms a static latent image on the Photosensitive Drum by laser exposure.

The Laser Scanner Unit consists of the Laser Assembly and the Scanner Motor, and is controlled by the signal input from the DC Controller PCB.



Laser ON/OFF Control

Purpose


Turns the laser beam ON and OFF according to the combination of laser control signals.

Execution timing

After turning ON the power

Control description

The DC Controller performs the register setting of the Laser Polygon Control ASIC on the Laser Driver PCB. This Laser Polygon Control ASIC switches between four modes (Forced OFF mode, APC mode, Print mode, and Standby mode).



| Mode | Laser status | Remarks |
|-----------------|--------------|---|
| Forced OFF mode | OFF | Clears the light intensity setting determined by the APC. |
| APC mode | ON | Adjusts laser light intensity |
| Print mode | ON/OFF | Emits the laser according to the video signal |
| Stanby mode | OFF | The machine is in standby mode |

Scanner Motor Control

Purpose

Rotates the Scanner Motor at a specific speed.


Execution timing

At power-on, and at printing

Control description

The Scanner Motor rotation speed is controlled by the DC Controller PCB.

1. The DC Controller PCB outputs Scanner Motor control signals (acceleration signals and deceleration signals) to the Scanner Motor to rotate the Polygon Mirror.
2. The DC Controller PCB stabilizes the Scanner Motor rotation speed, referring to the motor's rotation speed signals. (From when the Scanner Motor starts rotation until it reaches the target revolutions and the machine starts image formation process)
3. When laser beams are emitted at image formation, the DC Controller PCB detects the BD signal.
4. The DC Controller PCB controls the Scanner Motor control signals (acceleration signals and deceleration signals) based on the input timing of the BD signal to control the Scanner Motor rotation speed.



Related error codes

- E110-0001
Laser Scanner Motor startup error
- E110-0002
Laser Scanner Motor rotation error

APC (Auto Power Control)

Purpose

Ensures constant laser beam light intensity for each line.


Execution timing

For each line (before writing the image)

Control description

1. The Main Controller PCB outputs the APC signal to the Laser Driver IC in the Laser Driver PCB.

- The APC mode is set for the Laser Driver PCB's IC, and the laser diode of each color is forcibly activated. The photo diode (PD) monitors the laser diode (LD), and the Laser Driver IC adjusts the output of laser diode until the laser light intensity reaches a specified level.



Related error codes

- E100-0004:Laser Scanner error

BD Detection Correction Control

Purpose

Corrects the displacement of each color's laser write start position due to Polygon Mirror accuracy and Polygon Motor rotation accuracy.

Execution timing

At power-on, and at printing

Control description


- The DC Controller PCB measures the BD interval after the completion of constant speed rotation control of the Scanner Motor.
- The DC Controller PCB calculates the correction value from the displacement of the BD interval.
- The write start position is corrected by adjusting the write start timing based on the above correction value.

Image Formation System


Overview

The image formation system forms a toner image on the paper.

The DC Controller controls the Laser Scanner Unit and High-Voltage Power Supply to form the toner image on the Photosensitive Drum, and transfers and fixes this to the paper.



Print Process



| No. | Block name | Process name | Description |
|-----|-------------------------------------|------------------|--|
| 1 | Static latent image formation block | Pre-exposure | To prevent uneven density with the print image, residual charge on the Photosensitive Drum is removed before the primary charging. |
| 2 | | Primary charging | The surface of the Photosensitive Drum is uniformly charged with negative potential. |

| No. | Block name | Process name | Description |
|-----|-------------------------------------|---------------------|--|
| 3 | Static latent image formation block | Laser beam exposure | With irradiation of laser beam, a static latent image is formed on the surface of the Photosensitive Drum. (Image exposure: Area exposed by laser is the image area) |
| 4 | Developing block | Development | With the dry, 2-component AC developing method, toner that has been negatively charged by the Developing Cylinder is attached to the Photosensitive Drum. |
| 5 | Transfer block | Transfer | Toner on the Photosensitive Drum is transferred to a paper. |
| 6 | | Separation | With the curvature separation method, the paper is separated from the ITB. Thin paper's elastic force is small, so the electric charge of the paper surface at the back is weakened with the Static Eliminator to be separated easier. |
| 7 | Fixing block | Fixing | Toner on the paper is fixed on the paper using heat and pressure. |
| 8 | Drum cleaning block | Drum cleaning | The Cleaning Blade removes the residual toner attached on the Photosensitive Drum. |

Cartridge

Configuration


Parts Configuration

The cartridge of this machine is drum integrated type and forms a visible image on the Photosensitive Drum with toner.

- Photosensitive Drum
- Developing Assembly
- Primary Charging Roller
- Memory tag
- Toner level sensor

Drive Configuration

DC Controller drives the Drum Motor (M2) to rotate the Photosensitive Drum and the Developing Roller. The Primary Charging Roller is driven and rotated by the Photosensitive Drum.



Cartridge State Detection

Purpose

DC Controller detects and memorizes the state of the cartridge by reading/writing the data saved in the Cartridge Memory. When the Cartridge Memory cannot be detected or non-genuine/incorrect cartridge is detected, the DC Controller notifies the Main Controller and displays a warning message.

Overview

The cartridge of this machine is equipped with the Cartridge Memory, and the status of a cartridge can be detected by reading the information on it.

Execution Condition/Timing

- When the door is closed after replacement of the cartridge.
- At power-on (excluding high-speed start mode)

Description

This machine reads information on the Cartridge Memory and obtains the following status.

- Toner color in the cartridge
- Cartridge model
- Cartridge malfunctions
- Detection of incorrect cartridge

The description is displayed on the control panel.



■ Cartridge Life Detection

Purpose

This detects the toner level in the cartridge and grasp the life of cartridge (replacement timing).

Overview




When the toner level in the cartridge reaches the specified value, the DC Controller notifies the Main Controller. Upon receipt of the notification, the Main Controller displays codes and messages.

Execution Condition/Timing

- At power-on (excluding high-speed start mode)
- At completion of the initial rotation after closing the Cartridge Door
- At completion of printing
- When the reference value of cartridge life is changed

Description

When the toner level reaches the specified value, the DC Controller notifies the Main Controller. Upon receipt of the notification, the Main Controller displays codes and messages.

| Detection description | Low toner | Empty toner | Replacement completion |
|------------------------|---|---|--|
| Toner level*1 |  0 to 40% * 2 |  0 % |  |
| Detected to (location) | Cartridge memory | | |
| Alarm code | Prior delivery alarm 10-0020 *3 | - | 10-0404 Replacement completion alarm 10-0100 (0000071) 10-0100 (00000181) |
| Message | - | Prepare the toner. * 4 | No toner. Replace the toner cartridge. - |

*1: Remaining toner can be checked in the following item:

Status Monitor/Cancel > Consumables/Others > Other Information > Remaining Toner

*2: It can be changed in the following service mode (Lv. 1).

COPIER > OPTION > FNC-SW > T-DLV-BK

*3: This alarm is generated only once per cartridge. It will not be generated again for the same cartridge once this has been generated.

*4: It can be changed in the following service mode (Lv. 1).

COPIER > OPTION > DSPLY-SW > T-LW-BK

COPIER > OPTION > DSPLY-SW > TNR-WARN

Alarm Code

- Prior delivery alarm (K)
10-0020
- Toner Bottle (Bk) empty alarm
10-0404
- New Toner Bottle replacement detection (Bk)
10-0100 (00000071)
- Unidentified Toner Bottle replacement detection (Bk)
10-0100 (00000181)
- Toner memory detection error (Bk)
10-0094


Service Mode

- To set the timing to generate prior delivery alarm:
COPIER > OPTION > FNC-SW > T-DLV-BK
- To set the timing to display the message:
COPIER > OPTION > DSPLY-SW > T-LW-BK
- Display/hidden of the message display
COPIER > OPTION > DSPLY-SW > TNR-WARN

Transfer

■ Overview

The transfer block consists of 2 steps, and transfers the toner image on the Photosensitive Drum surface to the paper.




| No. | Name |
|-----|-------------------------|
| 1 | Photosensitive Drum |
| 2 | Transfer Roller |
| 3 | Pre-transfer Guide |
| 4 | Static Eliminator |
| 5 | Preprinting Paper |
| 6 | Pre-transfer Guide Bias |
| 7 | Transfer Bias |

| No. | Name |
|-----|------------------------|
| 8 | Static Eliminator Bias |

■ Transfer Bias Control

To transfer toner on the Photosensitive Drum to paper, the transfer bias generated by the High-Voltage Power Supply PCB (HVT_PCA) is applied to the Transfer Roller.


The bias value is determined by the environment, paper type and other factors.



■ Separation

On this machine, the paper is separated from the Photosensitive Drum by the elasticity of the paper and the curvature of the drum.

Furthermore, the Static Eliminator reduces potential on the back side of paper for stability of paper feed and image quality.



Service Mode

- Invalidate setting of the static elimination control
COPIER > OPTION > FEED-SW > SP-SW

● Image Stabilization Control

■ Overview

Image failure due to change of the environment or deterioration of the Photosensitive Drum is prevented to ensure stabilized print.

■ PASCAL control

To stabilize the gradation density characteristics of the image.

This control is executed at auto adjust gradation. Gradation density of the patch pattern on the test print is scanned by the Reader to create an image density correction table.

Based on the table, image gradation density characteristics that vary due to environmental change or deterioration of the Photosensitive Drum are corrected.

Control timing

Execution of auto adjust gradation ([Settings/Registration]) > [Auto Adjust Gradation]

Control description

1. When the specified conditions are satisfied, the Main Controller PCB prints memorized patch patterns.
2. Set the test print on the reader.
3. The reader scans the gradation density of the patch patterns from the test prints.
4. The Main Controller creates an image density correction table from the data of gradation density of the patch pattern scanned by the Reader.


Related service mode

- Default display setting of auto adjust gradation
COPIER > OPTION > USER > DFLT-ADJ
- Setting of gradation adjustment data:
COPIER > OPTION > IMG-MCON > PASCAL
- Setting of the paper type to be used for auto adjust gradation:
COPIER > OPTION > IMG-MCON > PASCL-TY

Fixing System

Features

This machine uses the on-demand fixing method for fixing.



Replaceability of the Fixing Assembly

- Easy replacement without screws or tools and can be replaced by users.
- Replace the whole Fixing Assembly since the Fixing Film Unit or Pressure Roller etc. are not set as sub parts.


Detection of whether the Fixing Assembly is new

- Whether the Fixing Assembly is new can be detected.
- The parts counter of the Fixing Assembly is automatically initialized when the Fixing Assembly is replaced.

Intervals of failed images


- Fixing Film: Approximately 77mm
- Fixing Pressure Roller: Approximately 79mm

■ Major Components



| Symbol | Part name | Function/Method |
|---------|------------------------|---|
| [1] | Fixing Film Unit | A toner image on paper is fixed by applying heat and pressure. |
| [2] | Pressure Roller | |
| H1/H7 | Fixing Heater | Ceramic Heater |
| MAIN TH | Main Thermistor | This is engaged with Heater. Temperature control and abnormal temperature rise detection |
| SUB TH2 | Sub Thermistor (Front) | This is engaged with Heater. Temperature control, abnormal temperature rising detection, edge temperature-rising/cooling control |
| SYB TH1 | Sub Thermistor (Rear) | This is engaged with Heater. Temperature control, abnormal temperature rising detection, edge temperature-rising/cooling control |
| PS4650 | Fixing Delivery Sensor | Jam Detection |

Fixing temperature control



Standby Temperature Control

This is a control to pre-heat the Fixing Assembly to reduce time to start printing.

- Flying Start

Print Temperature Control

This is a control to increase fixing temperature to the target level and keep it during printing.

- Startup (initial rotation) temperature control
- Print temperature control
- Paper interval temperature control

Down Sequence Control


This is a control to prevent fixing failure due to temperature increase at the edge or temperature decrease. Productivity (throughput) decreases.

- Down Sequence due to Cartridge Temperature Rise

Related error codes

- E000-0001
Error in temperature rising of Fixing Assembly
- E001-0001
Fixing Assembly: Abnormally high temperature 1
- E001-0002
Fixing Assembly: Abnormally high temperature 2
- E001-0004
Fixing Assembly: Abnormally high temperature 3
- E003-0001
Fixing Assembly: Abnormally low temperature 1

Standby Temperature Control



Flying Start

Purpose

To reduce time to print the first sheet.


Execution condition/timing

- When using the Numeric Keypad on the Control Panel/Touch Panel
- At power-on of the Main Power
- When recovering to standby mode
- At completion of jam removal

Control description

The temperature control target is set, and start the Fixing Heater.

Print Temperature Control



Startup (initial rotation) temperature control

A fixing temperature is increased to a printable temperature after receiving a command to start printing.

Print Temperature Control

This is a control to set an optimal target temperature to prevent fixing error or high temperature offset. Temperature is controlled to keep the specified target temperature during printing.

Setting the target temperature

A target temperature is determined according to the paper type/size, time which elapsed from when the last job finished, and fixing temperature when startup control started.

Down Sequence Control

■ Down Sequence due to the Cartridge Temperature Rise

Purpose

To prevent the Drum Cleaning Blade from flipping when cartridge temperature rises during continuous paper feed by estimating the temperature of the cartridge and enter down sequence.

Startup conditions

Enter down sequence stepwise according to the environment temperature and number of continuously printed sheets.

At 1-sided printing

| Environment temperature*1 | 1/2 speed |
|---------------------------|---------------------|
| 32.5 deg C or more | 601 images or more |
| 28 to 32.5 deg C | 2251 images or more |
| Lower than 8.5 deg C | - |

At 2-sided printing

| Environment temperature*1 | 1/2 speed | (1/2 speed) |
|---------------------------|--------------------|---------------------|
| 32.5 deg C or more | 251 to 500 images | 501 images or more |
| 28 to 32.5 deg C | 501 to 1060 images | 1061 images or more |
| Lower than 28 deg C | - | 1001 images or more |

*1: It can be checked in the following service mode.

COPIER > DISPLAY > ANALOG > TEMP

*2: Not entering down sequence

*3: Inactive time is approximately 2 minutes


Operation

Prevent temperature rise of cartridge by reducing the speed to 1/2 speed or inactive+1/2 speed

Pre-fixing Arch Control

Purpose

To prevent the image on the drum to be affected from a shock which occurs when the trailing edge of the paper pulled by the Fixing Drive passes through the Registration Roller by constantly creating an optimal arch between the transfer and fixing areas.



Startup conditions

This control is performed every time the paper is fed.

Operation

The Arch Sensor detects a paper arch between the transfer nip and fixing nip, and changes the drive speed of the Fixing Motor.


Related service mode

- Setting of the fixing speed when feeding envelopes
COPIER > OPTION > FEED-SW > EVLP-FS

Fixing Film Unit engagement/disengagement control

Control description

The Fixing Film Unit is disengaged from the Fixing Pressure Roller under a specific condition in order to prevent deformation of the Fixing Film/Fixing Pressure Roller due to heat and pressure that arise when the drive of the Fixing Pressure Roller stops, and to improve jam removability.



| No. | Name |
|--------|--------------------------------|
| [1] | Pressure Release Gear |
| [2] | Cam Gear |
| [3] | Fixing Film |
| [4] | Fixing Pressure Roller |
| PS4800 | Fixing Pressure Release Sensor |

Execution condition/timing

Engagement operation

- When the Fixing Pressure Roller is in a disengaged position at the start of a job

Disengagement operation

- When the Power Switch is OFF
- At occurrence of a jam
- At occurrence of an error
- When the specified period of time has passed since printing is finished.


Related error codes

- E840-0001: Pressure release mechanism error

Fixing Assembly detection

Presence of the Fixing Assembly is judged by a Fixing Assembly detection signal, which is input to the DC Controller at warm-up rotation (at power-on/recovery from sleep mode/closing of the cover).

When it is judged that the Fixing Assembly is absent, the machine displays the message "Set the Fixing Assembly." on the Control Panel and stops operation.




Fixing Assembly Life Detection

Purpose

The life of the Fixing Assembly is detected to prevent fixing errors due to the Fixing Assembly having reached the end of life.

Control description

The life of the Fixing Assembly is judged according to the life value (COPIER > COUNTER > LF > FX-LF). The message shown below is displayed when the life reaches the end.



Related service mode

- ON/OFF of the Fixing Assembly replacement message (Lv.2):
COPIER > OPTION > DSPLY-SW > FIX-WRN1
 - Fixing Assembly LF setting value reaching alarm (Lv.1):
COPIER> OPTION> FNC-SW> FIX-DLV
- * The life detection is not performed by default because the default value of FIX-WRN1 is "0".


Protection Function

This machine is equipped with protection functions that result in error occurrences when activated. The following errors do not need to be cleared.

| Code | De-tails | Title | Description |
|------|----------|---|--|
| E000 | 0001 | Fixing temperature rising error | Fixing temperature did not become a certain temperature although the specified time had passed after cold start. |
| E001 | 0001 | Fixing Assembly: Abnormally high temperature | Temperature of the Main Thermistor reached or exceeded specified value. |
| | 0002 | | Temperature of the Sub Thermistor 1 reached or exceeded specified value. |
| | 0004 | | Temperature of the Sub Thermistor 2 reached or exceeded specified value. |
| E003 | 0001 | Abnormal low temperature of the Fixing Assembly | Temperature of the Main Thermistor reached or fallen below the specified value. |
| E004 | 0004 | Mismatch of Fixing Assembly type | - Absent of the Fixing Assembly was detected according to the Fixing Assembly connection judged result - Temperature of the Main Thermistor and Sub Thermistor reached or fallen below the specified value. |
| E014 | 0001 | Fixing Motor rotation error | Startup has not been completed after a specified period of time has passed from the start of the Fixing Motor. |
| | 0002 | | Number of rotation of the Fixing Motor has become the same or less than the specified value |


Pickup Feed System

Overview



Parts Configuration

Layout Drawing of Rollers




| Symbol | Parts name |
|--------|------------------------|
| 1 | Delivery Roller |
| 2 | Inlet Feed Roller |
| 3 | Duplex Reverse Roller |
| 4 | Fixing Delivery Roller |
| 5 | Fixing Film |
| 6 | Pressure Roller |
| 7 | Photosensitive Drum |

| Symbol | Parts name |
|--------|--------------------------------------|
| 8 | Pressure Roller |
| 9 | Duplex Feed Roller |
| 10 | Registration Shutter |
| 11 | Registration Roller |
| 12 | Cassette 1 Pickup Roller |
| 13 | Cassette 1 Feed Roller |
| 14 | Cassette 1 Retard Roller |
| 15 | Multi-purpose Tray Pickup Roller |
| 16 | Multi-purpose Tray Separation Roller |
| 17 | Feed Roller |

• Sensors Layout Drawing


Model with Built-in Finisher



| Symbol | Parts name |
|--------|-----------------------------------|
| PS201 | Delivery Bin 1 Paper Sensor |
| PS202 | SS Outlet Sensor |
| PS203 | Staple Inlet Sensor |
| PS204 | Y Alignment Home Position Sensor |
| PS205 | Delivery Bin 1 Full Sensor |
| PS206 | Alienation Home Position Sensor |
| PS207 | Jogger Home Position Sensor |
| PS208 | Delivery Bin 2 Paper Sensor |
| PS209 | Delivery Bin 2 Full Sensor |
| PS210 | SS Inlet Sensor |
| PS211 | Delivery Bin 1 Upper Limit Sensor |
| PS212 | Delivery Bin 1 Lower Limit Sensor |
| PS4300 | Cassette 1 Paper Sensor |

| Symbol | Parts name |
|--------|---|
| PS4350 | Multi-purpose Tray Paper Sensor |
| PS4400 | Cassette 1 Lifter Sensor |
| PS4450 | Delivery Paper Full Sensor |
| PS4500 | Fixing Arch Sensor |
| PS4550 | Registration Sensor |
| PS4600 | Retard Roller Rotation Detection Sensor |
| PS4650 | Fixing Delivery Sensor |
| PS4700 | Duplex Feed Sensor |


Model without Built-in Finisher



| Symbol | Parts name |
|--------|---|
| PS4300 | Cassette 1 Paper Sensor |
| PS4350 | Multi-purpose Tray Paper Sensor |
| PS4400 | Cassette 1 Lifter Sensor |
| PS4450 | Delivery Paper Full Sensor |
| PS4500 | Fixing Arch Sensor |
| PS4550 | Registration Sensor |
| PS4600 | Retard Roller Rotation Detection Sensor |
| PS4650 | Fixing Delivery Sensor |
| PS4700 | Duplex Feed Sensor |

• Route of Drive


Model with Built-in Finisher



Route of Drive for Model with Built-in Finisher

| Symbol | Parts name |
|--------|---------------------------------|
| M01 | Fixing Motor |
| M02 | Drum Motor |
| M03 | Lifter Motor |
| M21 | Staple Stacker Delivery Motor |
| M22 | Staple Stacker Feed Motor |
| M24 | Jogger Motor |
| M25 | Y Alignment Motor |
| CL01 | Cassette 1 Feed Clutch |
| CL02 | Duplex Feed Clutch |
| CL03 | Cassette 1 Pickup Clutch |
| CL04 | Duplex Reverse Clutch |
| SL01 | Multi-purpose Pickup Solenoid |
| SL21 | Inlet Flapper Solenoid |
| SL22 | Stamp Solenoid |
| SL23 | Delivery Bin 2 Flapper Solenoid |

Model without Built-in Finisher



Route of Drive for Model without Built-in Finisher

| Symbol | Parts name |
|--------|-------------------------------|
| M01 | Fixing Motor |
| M02 | Drum Motor |
| M03 | Lifter Motor |
| CL01 | Cassette 1 Feed Clutch |
| CL02 | Duplex Feed Clutch |
| CL03 | Cassette 1 Pickup Clutch |
| CL04 | Duplex Reverse Clutch |
| SL01 | Multi-purpose Pickup Solenoid |


■ Paper Path

Model with Built-in Finisher



Paper Path (Model with Built-in Finisher)


Model without Built-in Finisher



Paper Path (Model without Built-in Finisher)

Cassette Pickup Assembly

■ **Parts / Drive Configuration**




| Symbol | Parts name |
|--------|------------------------------|
| 1 | Lifter Plate |
| 2 | Cassette 1 Pickup Roller |
| 3 | Cassette 1 Separation Roller |
| 4 | Cassette 1 Feed Roller |
| 5 | Registration Roller |
| M02 | Drum Motor |
| M03 | Lifter Motor |
| CL03 | Cassette 1 Pickup Clutch |

■ Paper Size Detection Control

With the sliding of the Guide Plate, the Cassette Size Dial shifts between its peaks and valleys in accordance with the cassette's paper size.


Paper size is detected according to the combination of ONs and OFFs of the Cassette 1 Paper Size Switch-A and -B (SW04/SW05).



| Symbol | Parts name |
|--------|---------------------------|
| 1 | Side Guide Plate |
| 2 | Link Arm |
| 3 | Trailing Edge Guide Plate |
| 4 | Link Arm |
| SW4 | Cassette 1 Size Switch A |
| SW5 | Cassette 1 Size Switch B |



■ Paper Level/ Presence Detection Control

The Cassette 1 Paper Sensor (PS4300) detects whether there is paper.




| Symbol | Parts name |
|--------|------------------------------|
| 1 | Lifter Plate |
| 2 | Paper Detection Flag |
| 3 | Paper Surface Detection Flag |
| 4 | Lifter Gear |
| M3 | Lifter Motor |
| PS4300 | Cassette 1 Paper Sensor |
| PS4400 | Cassette 1 Lifter Sensor |

Because paper level is not detected by a software, it is shown in 2 levels on UI.

| Level Display | Level | Paper Sensor |
|---|-----------|--------------|
|  | 100 - 1 % | ON |
|  | 0 % | OFF |

In addition, paper level is mechanically indicated.

The position of the lever, as shown in the figure below, indicates paper level.



■ Lifter Control

With the rotation of the Lifter Motor (M3), the Lifter Plate is raised until the Cassette 1 Lifter Sensor (PS4400) detects the paper surface.

Related Error Codes


- E015-0001: Cassette 1 Lifter Motor error
- E015-0002: Cassette 2 Lifter Motor error
- E015-0003: Cassette 3 Lifter Motor error

- E015-0004: Cassette 4 Lifter Motor error

Multi-purpose Tray Pickup Assembly

Parts / Drive Configuration


With the rotation of the Multi-Purpose Tray Pickup Solenoid (SL1) and the Drum Motor (M02), paper is picked up from the Multi-Purpose Tray of the Multi-Purpose Tray Pickup Unit.



| Symbol | Parts name |
|--------|--------------------------------------|
| 1 | Multi-purpose Tray Pickup Roller |
| 2 | Multi-purpose Tray Separation Roller |
| SL1 | Multi-purpose Tray Pickup Solenoid |
| M02 | Drum Motor |

Paper Detection

The Multi-purpose Tray Paper Sensor (PS4350) detects whether there is paper.



| Symbol | Parts name |
|--------|---|
| 1 | Multi-purpose Tray Pickup Roller |
| 2 | Multi-purpose Tray Separation Roller |
| 3 | Multi-purpose Tray Paper Detection Flag |
| PS4350 | Multi-purpose Tray Paper Detection Sensor |


Paper Size Detection

This machine does not have a function for detecting paper size. The user has to specify the paper size in the Multi-purpose Tray using the Control Panel. Or, the user has to register the fixed size in the Settings/Registration menu.

Registration Assembly

Registration Control

This control corrects paper skew and aligns the leading edge of the paper with that of the image.



| Symbol | Parts name |
|--------|---------------------|
| 1 | Registration Roller |
| 2 | Paper |
| 3 | Slack |
| PS4550 | Registration Sensor |
| M02 | Drum Motor |

Skew Correction Control

The paper leading edge runs into the stopped Registration Roller, thereby forming a slack (arch) in order to correct the skew.

Registration Control

This control stops paper at the registration position, aligns the image on the Drum with the paper at a specified timing, and then performs paper feed.

Related Service Mode

- Adjustment of registration start timing (Plain paper)
COPIER > ADJUST > FEED-ADJ > REGIST
- Adjustment of registration start timing (Heavy paper)
COPIER > ADJUST > FEED-ADJ > RG-HF-SP
- Adjustment of registration start timing (Plain paper 2nd side)
COPIER > ADJUST > FEED-ADJ > REG-DUP1
- Adjustment of registration start timing (MP Tray, plain paper)
COPIER > ADJUST > FEED-ADJ > REG-MF

Process Tray Assembly (Model with Built-in Finisher Only)


After aligning, shifting and stapling fed paper, the Process Tray Assembly ejects the paper onto the Output Tray. The name and role of each of the Process Tray Assembly parts are as follows.

| Name | Role |
|--------------------|---|
| Jogger Unit | Performs alignment along the leading edge of paper. |
| Top Feed Feed Unit | Performs alignment along the left edge of paper. |
| Staple Unit | Performs stapling. |

■ Alignment Operation

With a paper stack on the Holding Tray, the Y Alignment Motor (M25) performs alignment along the leading edge while the Jogger Motor (M24) performs one along the left edge.

The Y Alignment Home Position Sensor (PS204) and the Jogger Home Position Sensor (PS207) detect the home position of the alignment member.



When Offset and Collate is enabled, paper stacked on the Process Tray is sorted into bundles, aligned along the near or the far side to the host machine.


Related Error Codes

- E530-8001: Jogger error
- E577-8001: Y Alignment Motor error

■ Stapling

Overview

Stapling is to staple the specified number of sheets of paper together.



Staple Unit

The Staple Motor drives the cam to perform stapling.

The Staple Home Position Sensor detects the cam's home position.

The Staple Alert Sensor detects whether a Staple Cartridge is placed inside the Staple Unit.

The Staple Ready Sensor detects whether there are staples inside the Staple Cartridge and whether the Staple Unit is operational.

Paper sizes available for stapling

A4; LTR; LGL; user-specified size (210 × 279.4mm - 215.9 × 355.6mm)

Weight/ maximum number of sheets available for stapling

60 to 89 g/m2: 30 sheets

90 to 120 g/m2: 20 sheets

Related Error Codes


- E531-8001: Staple Repositioning error
- E531-8002: Stapler error

■ Stack Delivery

After aligned, a paper stack is ejected from the Holding Tray to the Output Tray.

The Alignment Motor (M25) performs disengagement/engagement of the Stack Delivery Roller, while the Alienation Home Position Sensor (PS206) detects its status.

The Delivery Motor (M21) ejects paper onto the Output Tray.



Related Error Code

- E568-8001: Stack Delivery Roller disengagement error


Stack Tray Assembly (Model with Built-in Finisher Only)

Tray Lifting

The Tray Lifting Motor (M27) operates the lifting/lowering of Tray 1.


After paper is delivered, Tray 1 descends by defined range. Then, Tray 1 ascends until the Output Tray 1 Upper Limit Detection Sensor (PS211) detects the surface of stacked paper.

The Output Tray 1 Lower Limit Sensor (PS212) detects the tray's lower limit.



■ Paper in Tray Full Detection

The Delivery Tray Full Sensors (PS205/PS209) detect a paper stack in the Output Tray as full.




Delivery Assembly

Delivery Paper Full Detection

The Delivery Paper Full Sensor (PS4450) detects delivered paper as full after detecting paper delivery for a certain period of time.

Printing stops once detected as full.




| Symbol | Parts name |
|--------|----------------------------|
| 1 | Delivery Full Flag |
| 2 | Delivery Roller |
| PS4450 | Delivery Paper Full Sensor |

Reverse/Duplex Assembly


Duplex Reverse Control

With the Reverse Flapper, the feed path is switched from the Delivery Mouth to the Reverse Mouth to perform the reverse operation.

The Reverse Flapper [1] is operated by the Duplex Reverse Clutch (CL4).




Paper stops at the Duplex Reverse Stop Position and receives the reverse operation.



| Symbol | Parts name |
|--------|------------------------------|
| 1 | Duplex Reverse Stop Position |
| M01 | Fixing Motor |
| CL04 | Duplex Reverse Clutch |
| PS4650 | Fixing Delivery Sensor |

Jam Detection

This equipment performs jam detection with the use of the sensors listed in the figure.



Sensors Used to Detect Jams

| Symbol | Parts name |
|--------|----------------------------|
| PS202 | Staple Stacker Exit Sensor |

| Symbol | Parts name |
|--------|-----------------------------|
| PS203 | Staple Inlet Sensor |
| PS210 | Staple Stacker Inlet Sensor |
| - | Stapler HP Sensor |
| PS4400 | Cassette 1 Lifter Sensor |
| PS4450 | Delivery Paper Full Sensor |
| PS4500 | Fixing Arch Sensor |
| PS4550 | Registration Sensor |
| PS4650 | Fixing Delivery Sensor |
| PS4700 | Duplex Feed Sensor |

External Auxiliary System

Software Counter Control

This machine has software counters that count the number of prints/copies per job type. Various counters are displayed by pressing the Check Counter key on the Control Panel. The default counters for each country (model) are listed below.

| Target | Display number of each counter (in service mode) / item | | | | Target country code |
|-------------------------|---|---------------------|-----------------|----------------|--|
| | Counter 1 | Counter 2 | Counter 3 | Counter 4 to 8 | |
| Japan model Type 1 | Total 1 | *1 | *1 | *1 | JP |
| | 101 | 000 | 000 | 000 | |
| Japan model Type 2 | Total 2 | Copy (Total 2) | Total A2 | *1 | JP |
| | 102 | 231 | 148 | 000 | |
| Taiwan model | Total 1 | Copy (Total 1) | *1 | *1 | TW |
| | 101 | 201 | 000 | 000 | |
| UL model Type 1 | Total 1 | Copy (Total 1) | *1 | *1 | US |
| | 101 | 201 | 000 | 000 | |
| UL model Type 2 | Total 2 | Copy (Total 2) | *1 | *1 | US |
| | 102 | 202 | 000 | 000 | |
| General model | Total 1 | Copy (Total 1) | *1 | *1 | SG/KR/TH/VN/AR/IN |
| | 101 | 201 | 000 | 000 | |
| UK model Type 1 | Total (Black/ Small) | Scan (Total 1) | Print (Total 1) | *1 | GB |
| | 112 | 501 | 301 | 000 | |
| 240V UK model Type 2 | Total 1 | *1 | *1 | *1 | GB |
| | 101 | 000 | 000 | 000 | |
| CA model | Total 1 | Copy (Total 1) | *1 | *1 | AU |
| | 101 | 108 | 000 | 000 | |
| FRN model Type 1 | Total (Black/ Small) | Scan (Total 1) | Print (Total 1) | *1 | FR |
| | 113 | 501 | 301 | 000 | |
| FRN model Type 2 | Total 1 | *1 | *1 | *1 | FR |
| | 101 | 000 | 000 | 000 | |
| GER model Type 1 | Total (Black/ Small) | Scan (Total 1) | Print (Total 1) | *1 | DE |
| | 113 | 501 | 301 | 000 | |
| GER model Type 2 | Total 1 | *1 | *1 | *1 | DE |
| | 101 | 000 | 000 | 000 | |
| AMS model Type 1 | Total (Black/ Small) | Scan (Total 1) | Print (Total 1) | *1 | ES/SE/PT/NO/DK/FI/PL/HU/CZ/ SI/GR/EE/RU/NL/SK/RO/HR/B G/TR |
| | 113 | 501 | 301 | 000 | |
| AMS model Type 2 | Total 1 | *1 | *1 | *1 | ES/SE/PT/NO/DK/FI/PL/HU/CZ/ SI/GR/EE/RU/NL/SK/RO/HR/B G/TR |
| | 101 | 000 | 000 | 000 | |
| ITA model Type 1 | Total (Black/ Small) | Scan (Total 1) | Print (Total 1) | *1 | IT |
| | 113 | 501 | 301 | 000 | |
| ITA model Type 2 | Total 1 | *1 | *1 | *1 | IT |
| | 101 | 000 | 000 | 000 | |
| China | Total 1 | Total (Black/Small) | *1 | *1 | CN |
| | 101 | 113 | 000 | 000 | |

*1: Hidden by default. Changeable in Service Mode

<Explanation of the list>

- Large: Large size paper (when paper length exceeds 364 mm in paper feed direction)
- Small: Small size paper (when paper length is 364 mm or less in paper feed direction)

- Total: When a sheet of paper is delivered, the counter is advanced by 1
- 2-Sided: The counter is advanced by 1 for paper delivered in 2-sided mode
- To change the CONFIG country code: COPIER > Option > FNC-SW > CONFIG
- Three-digit number in the counter column shows the setting value of the following service mode items (COUNTER1 TO COUNTER8).
COPIER > OPTION > USER > COUNTER 1 to 8
- COUNTER 2 to 8 can be changed from the service mode (COPIER>OPTION>USER).
- The type of counter display can be switched between the former and new methods in service mode (CNT-SW).
COPIER > OPTION > USER > CNT-SW

| Country code | Country | Country code | Country | Country code | Country |
|--------------|----------------|--------------|----------------|--------------|-----------|
| JP | Japan | ES | Spain | RU | Russia |
| US | United States | SE | Sweden | SK | Slovakia |
| GB | United Kingdom | PT | Portugal | RO | Romania |
| FR | France | NO | Norway | HR | Croatia |
| DE | Germany | DK | Denmark | BG | Bulgaria |
| IT | Italy | FI | Finland | TR | Turkey |
| AU | Australia | PL | Poland | TH | Thailand |
| SG | Singapore | HU | Hungary | VN | Vietnam |
| NL | Netherlands | CZ | Czech Republic | AR | Argentine |
| KR | Korea | SI | Slovenia | IN | India |
| CN | China | GR | Greece | | |
| TW | Taiwan | EE | Estonia | | |


■ Count-up timing

Count-up timing differs according to the following:

- Print mode (1-sided print/2nd side of 2-sided print, 1st side of 2-sided print)
- Delivery position

| No. | Delivery position | | Print mode | |
|-----|-------------------|---------------------|--|-----------------------------|
| | | | 1-sided print/2nd side of 2-sided print | 1st side of 2-sided print |
| | | | Count-up timing | |
| 1 | Host machine | First Delivery Tray | Fixing Delivery Sensor (PS4650) | Duplex Left Sensor (PS4700) |
| 2 | | Inner Finisher Tray | Finisher: Staple Stacker Outlet Sensor (PS202) | |


Location of Fans



| No. | Name |
|-----|---------------------|
| FM1 | Laser Scanner Fan |
| FM2 | Duplex Fan |
| FM3 | Cartridge Upper Fan |
| FM4 | Cartridge Lower Fan |
| [1] | Controller Fan |

Power supply


Internal power supply



Power-saving Function

Overview

There are "Standby" and "Sleep" as the power supply mode of this machine. Further, "Sleep" is divided into the following 3 modes: "Sleep Standby", "Sleep 1", "Deep Sleep".



* The time specified in Settings/Registration> Preferences> Timer/Energy Settings> Auto Sleep Time

Standby

The mode that the machine is running or can start operation immediately and all power is supplied in this mode.

Sleep Standby

The state that only the Control Panel is off while the power is supplied to all other parts.

Sleep 1

The state that the controller's all-night and non-all-night power is supplied while the Control Panel is off.

Deep Sleep

In this state, the Control Panel is off while only all-night power is supplied.

When any of the following "Conditions for Not Entering Deep Sleep" applies, transition to this mode does not occur.

■ Conditions for Not Entering Deep Sleep Mode (Check Items)

Settings of Settings/Registration

When the following settings are enabled in the [Settings/Registration] menu, the machine does not enter Deep Sleep mode. The corresponding items are shown below.

Preferences > Timer/Energy Settings

- Sleep Mode Energy Use > High
- Sleep Mode Energy Use > Low > Compensate for Network Comm.
- Within the time specified in Auto Sleep Time

Preferences > Network

- NetWare Settings > Use NetWare > ON
- AppleTalk Settings > Use AppleTalk > ON
- TCP/IP Settings > BMLinkS Settings > Use BMLinkS > ON (*1)
- IEEE 802.1X Settings > Use IEEE 802.1X > ON
- TCP/IP Settings > IPv4 Settings > IP Address Settings > Auto IP > ON
- TCP/IP Settings > DNS Settings > mDNS Settings > Use mDNS > ON
- Google Cloud Print Settings > Use Google Cloud Print > ON (*2)
- TCP/IP Settings > SIP Settings > NGN Settings > Use NGN > ON (*1)
- Direct Connection Settings > Use Direct Connection > ON

Function Settings > Receive/Forward

- Fax Settings > Select RX Mode > Fax/Tel (Auto Switch) (*1)
- Fax Settings > Remote RX > ON (*1)
- Fax Settings > Set Number Display > ON (*1)

Function Settings > Send

- Fax Settings > Modem Dial-in Settings > ON (*1)

Other Settings

- Volume Settings key > Fax Volume Settings > Incoming Fax Ring > ON (*1)

*1: This may not be displayed depending on the country, model, and configuration of the options.

*2: This must be already registered on Google Cloud Print in advance.

Hardware status

- It is connected to the coin vendor.

System Performance Status

- The system is running/communicating.

CAUTION:

The system is in a running/communicating state for approx. 10 minutes after startup in many cases.

Quick Start

To realize faster startup, power configuration has been changed to always supply power to the Low Voltage Power Supply PCB and Main Controller PCB. Consequently, the Touch Panel can be operated 4 seconds after turning ON the Main Power Switch. Even when the Main Power Supply Switch is OFF, power is supplied to the following PCBs:

| | Quick startup setting ON | Quick startup setting OFF |
|------------------------------|--------------------------|---------------------------|
| Low-Voltage Power Supply PCB | Power is supplied | Power is supplied |
| Main Controller PCB | Power is supplied | OFF |

NOTE:

The quick startup function can be set from "Settings/Registration".

- Settings/Registration > Preferences > Timer/Energy Settings > Quick Startup Settings for Main Power
[On]: Quick startup is executed (default)
[Off]: Quick startup is not executed

Disconnect the power plug when performing work with the possibility to come in contact with the PCBs above. If a conductive material comes in contact with the PCB, short circuit may occur in the PCB, and may cause damage on it. The following label is used at the place where attention is required.

**Conditions for not executing quick startup**

This machine does not execute quick startup if the following conditions are met at first startup after the power plug is connected to the outlet.

Connection status of the hardware

- The coin vendor is connected.

Either of the following network settings is set to "ON":

- Settings/Registration > Preferences > Network
- AppleTalk Settings > Use AppleTalk > ON

- Select Wired/Wireless LAN > Wireless LAN
- Bluetooth Settings > ON

When the machine starts up right after it is shut down under any of the following conditions

- During operation/communication of the system

Others

- 110 hours or more have elapsed after quick startup.
- The power of this product is turned ON again within 20 seconds after turning it OFF
- Startup after 8 hours or more have passed since the power of this product was turned OFF
- The next time the power is turned ON after turning OFF the power of this product from remote UI
- The next time the power is turned ON after occurrence of the error code
- The next time the power is turned ON after shifting to the service mode screen



Periodical Service

| | |
|----------------------------------|----|
| Periodically Replaced Parts..... | 86 |
| Consumable Parts List..... | 87 |

Periodically Replaced Parts

Periodic replacement parts are not required in this machine.

Consumable Parts List

Host Machine

| No. | Name | Parts number *1 | Quantity | Estimated life *2 | Work description | Parts counter (service mode) | | Alarm code at counter clear | Remarks |
|-----|--------------------------------------|------------------------------------|----------|-------------------|------------------|------------------------------|----------|-----------------------------|-----------------------|
| | | | | | | Inter-mediate item | Sub item | | |
| 1 | Fixing Assembly | 120V : FM1-U027 200V : FM1-U028 | 1 | 225,000 pages | Replacement | DRBL-1 | FX-UNIT | 43-0076 | |
| 2 | Transfer Roller | FM1-U032 | 1 | 225,000 pages | Replacement | DRBL-1 | TR-ROLL | 43-0013 | |
| 3 | Roller Kit | FM1-U030 | 1 | 225,000 sheets | Replacement | DRBL-1 | C1-FD-RL | 43-0080 | |
| 5 | Multi-purpose Tray Pick-up Roller | RL2-1566 | 1 | 200,000 sheets | Replacement | DRBL-1 | M-FD-RL | - | |
| 6 | Multi-purpose Tray Separation Roller | RL2-0079 | 1 | 200,000 sheets | Replacement | DRBL-1 | M-SP-RL | - | |
| 7 | ADF Maintenance Kit | FM1-P720 | 1 | 50,000 sheets | Replacement | DRBL-2 | DF-PU-RL | 43-0091 | ADF Separation Roller |

*1: The parts number may be changed due to engineering change.

*2: All the values described in this column are estimated replacement timing in A4 size. The replacement timing is a reference value in the case of usage in general offices, and the actual value differs depending on the customer environment, operation conditions in the field, etc.

Cassette Module-AG

| No. | Name | Parts number *1 | Quantity | Estimated life *2 | Work description | Parts counter (service mode) | | Alarm code at counter clear |
|-----|------------|-----------------|----------|-------------------|------------------|------------------------------|----------|-------------------------------|
| | | | | | | Inter-mediate item | Sub item | |
| 1 | Roller Kit | FM1-U030 | 1 | 225,000 sheets | Replacement | DRBL-2 | C2-FD-RL | 43-0083 43-0086 43-0089 |

*1: The parts number may be changed due to engineering change.

*2: All the values described in this column are estimated replacement timing in A4 size. The replacement timing is a reference value in the case of usage in general offices, and the actual value differs depending on the customer environment, operation conditions in the field, etc.

Envelope Cassette Module-A1

Periodic replacement parts are not required in this machine.

High Capacity Cassette Feeding Unit-D1

| No | Name | Parts number *1 | Quantity | Estimated life *2 | Work description | Parts counter (service mode) | | Alarm code at counter clear |
|----|------------|-----------------|----------|-------------------|------------------|------------------------------|----------|-----------------------------|
| | | | | | | Intermediate item | Sub item | |
| 1 | Roller Kit | FM1-U030 | 1 | 225,000 sheets | Replacement | DRBL-2 | C2-FD-RL | 43-0083 43-0086 |

*1: The parts number may be changed due to engineering change.

*2: All the values described in this column are estimated replacement timing in A4 size. The replacement timing is a reference value in the case of usage in general offices, and the actual value differs depending on the customer environment, operation conditions in the field, etc.

Cassette Feeding Unit-AR1

| No | Name | Parts number *1 | Quantity | Estimated life *2 | Work description | Parts counter (service mode) | | Alarm code at counter clear |
|----|------------|-----------------|----------|-------------------|------------------|------------------------------|----------|-----------------------------|
| | | | | | | Intermediate item | Sub item | |
| 1 | Roller Kit | FM1-U030 | 1 | 225,000 sheets | Replacement | DRBL-2 | C2-FD-RL | 43-0083 |

*1: The parts number may be changed due to engineering change.

*2: All the values described in this column are estimated replacement timing in A4 size. The replacement timing is a reference value in the case of usage in general offices, and the actual value differs depending on the customer environment, operation conditions in the field, etc.



4

Parts Replacement and Cleaning

| | |
|---|-----|
| Preface..... | 90 |
| Parts List..... | 91 |
| External Cover/Interior System..... | 109 |
| External / Internal Cover System (Finisher)..... | 119 |
| Original Exposure/Feed System..... | 127 |
| Controller System..... | 192 |
| Controller System (Finisher)..... | 203 |
| Laser Exposure System..... | 204 |
| Image Formation System..... | 205 |
| Fixing System..... | 212 |
| Pickup Feed System..... | 214 |
| Pickup Feed System (Finisher)..... | 225 |

Preface


Outline

This chapter describes disassembly and assembly procedures of the host machine. The service technician is to identify the cause of host machine failures according to follow the disassembly procedures of each part to replace the defective parts or the consumable parts.


- Before disassembling or assembling the host machine, be sure to disconnect the power cord from the outlet.
- When the Drum Cartridge is removed from the host machine before disassembling and assembling, be sure to put the Photosensitive Drum in a protective bag even in a short period to prevent the adverse effect of light.
- Assembling procedures are followed by the reverse of disassembly unless any specification.
- Note the length, diameters and positions of screws when assembling the host machine. Be sure to use the screws in the original position.
- Do not run the host machine with any parts removed as a general rule.
- Ground yourself by touching the metal part of the host machine before handling the PCB to reduce the possibility of damage caused by static electricity.
- When replacing the part that the rating plate or the product code label is attached, be sure to remove the rating plate or the product code label and attach it to the replacing part.

Parts List

List of Cover (with Finisher)




| No. | Name |
|------|----------------------------|
| [1] | Front Cover |
| [2] | Cassette1 |
| [3] | Right Lower Cover |
| [4] | Right Door Unit |
| [5] | Inlet Cover |
| [6] | Control Panel Upper Cover |
| [7] | Staple Cover |
| [8] | Finisher Right Upper Cover |
| [9] | Finisher Right Rear Cover |
| [10] | Finisher Right Door |
| [11] | Finisher Right Lower Cover |
| [12] | Staple Inner Cover |




| No. | Name |
|------|---------------------------|
| [1] | Cartridge Door Unit |
| [2] | Left Lower Cover |
| [3] | Left Rear Cover |
| [4] | Rear Cover |
| [5] | Finisher Rear Cover |
| [6] | Finisher Left Rear Cover |
| [7] | Delivery Tray |
| [8] | Inner Delivery Rear Cover |
| [9] | 2 Bin Rear Cover |
| [10] | Finisher Inner Rear Cover |
| [11] | StackingWall Unit |
| [12] | Jogger Cover Unit |
| [13] | 2 Bin Front Cover |
| [14] | Finisher Tray |
| [15] | Finisher Bin Tray |

List of Cover (without Finisher)




| No. | Name |
|-----|---------------------------|
| [1] | Front Cover |
| [2] | Cassette 1 |
| [3] | Right Lower Cover |
| [4] | Right Door Unit |
| [5] | Inlet Cover |
| [6] | Right Upper Cover |
| [7] | Control Panel Upper Cover |
| [8] | Control Panel Lower Cover |




| No. | Name |
|-----|----------------------------|
| [1] | Cartridge Door Unit |
| [2] | Left Lower Cover |
| [3] | Left Rear Cover |
| [4] | Rear Cover |
| [5] | Delivery Tray |
| [6] | Inner Delivery Rear Cover |
| [7] | Inner Delivery Right Cover |


Main Unit




| No. | Name |
|------|-----------------------|
| [1] | Control Panel |
| [2] | Duplex Delivery Unit |
| [3] | Fixing Assembly |
| [4] | Registration Unit |
| [5] | Cassette1 Pickup Unit |
| [6] | Feed Unit |
| [7] | Transfer Unit |
| [8] | Fixing Drive Unit |
| [9] | Developing Drive Unit |
| [10] | Main Drive Unit |
| [11] | Lifter Drive Unit |
| [12] | Laser Scanner Unit |




| No. | Name |
|-----|-----------------------|
| [1] | Jogger Unit |
| [2] | Upper Paper Feed Unit |
| [3] | Staple Unit |
| [4] | Lower Paper Feed Unit |




| No. | Name |
|----------|--|
| CL4200 | ADF Separation Clutch |
| CL4201 | ADF Registration Clutch |
| FM5 | ADF Cooling Fan |
| M4201 | ADF Motor |
| SR2 | Delivery Sensor |
| SR5 | ADF Cover Sensor |
| REG | Registration Sensor |
| SR4204 | Document Sensor |
| SR4206 | Document End Sensor |
| ADF_CIS | CIS Unit (Back) |
| JUSO(T) | Double Feed Detection PCB (Transmission) |
| JUSO(R) | Double Feed Detection PCB (Reception) |
| LED DS | Original Display LED |
| LED EXIT | Delivery Display LED |




| No. | Name |
|--------|------------------|
| M4100 | Reader Motor |
| SR3 | CIS HP Sensor |
| SR4 | Read Sensor 1 |
| RD_CIS | CIS Unit (Front) |
| [1] | Motion Sensor |
| [2] | Wireless LAN PCB |




| No. | Name |
|-----------|-------------------------------|
| TH4200 | Environment Sensor |
| LASER_PCA | BD PCB |
| DCON_PCA | DC Controller PCB |
| HVT_PCA | High-Voltage Power Supply PCB |
| [1] | Main Controller PCB |
| [2] | Fax PCB |
| [3] | Modular PCB |




| No. | Name |
|---------|----------------------------------|
| EPU_PCA | Low-Voltage Power Supply PCB |
| LED4950 | Pre-exposure LED |
| UN84 | LCD |
| UN93 | Control Panel Numeric Keypad PCB |
| UN95 | Touch Panel |
| [1] | Control Panel CPU PCB |
| [2] | Detection of new Fixing Unit PCB |




| No. | Name |
|---------|---------------------------|
| MAIN SW | Main Power Switch |
| SW1 | 24V Interlock Switch |
| SW2 | Front Door Switch |
| SW6 | Right Door Switch (Front) |
| SW7 | Right Door Switch (Rear) |
| HEATER | Fixing Heater |
| MAIN TH | Main Thermistor |
| SUB TH1 | Sub Thermistor 1 |
| SUB TH2 | Sub Thermistor 2 |




| No. | Name |
|-----|--------------------------------|
| SW4 | Cassette 1 Paper Size Switch-A |
| SW5 | Cassette 1 Paper Size Switch-B |
| SP1 | Fax Speaker |
| SP2 | Control Panel Speaker |



| No. | Name |
|-----|---------------------|
| FM1 | Laser Scanner Fan |
| FM2 | Duplex Fan |
| FM3 | Cartridge Upper Fan |
| FM4 | Cartridge Lower Fan |
| [1] | Controller Fan |




| No. | Name |
|-----|-------------------------------|
| M1 | Fixing Motor |
| M2 | Drum Motor |
| M3 | Lifter Motor |
| M4 | Laser Scanner Motor |
| CL2 | Duplex Feed Clutch |
| CL3 | Cassette 1 Pickup Clutch |
| CL4 | Duplex Switchback Clutch |
| SL1 | Multi-purpose Pickup Solenoid |
| SL2 | Multi-purpose Pickup Solenoid |




| No. | Name |
|--------|--------------------------------|
| PS4300 | Cassette 1 Paper Sensor |
| PS4350 | Multi-purpose Paper Sensor |
| PS4400 | Cassette 1 Lifter Sensor |
| PS4450 | Delivery Paper Full Sensor |
| PS4500 | Fixing Loop Sensor |
| PS4550 | Registration Sensor |
| PS4600 | Retard Roller Rotation Sensor |
| PS4650 | Fixing Output Sensor |
| PS4700 | Duplex Feed Sensor |
| PS4800 | Fixing Pressure Release Sensor |
| PS4850 | Developer Alienation Sensor |

Motor (with Finisher)




| No. | Name |
|------|----------------------|
| M21 | SS Output Motor |
| M22 | SS Feed Motor |
| M24 | Jogger Motor |
| M25 | Y Alignment Motor |
| M27 | Lifter Motor |
| SL21 | Output Solenoid |
| SL22 | Stamp Solenoid |
| SL23 | 2Bin Output Solenoid |

Sensor (Finisher)



| No. | Name |
|-------|---------------------------------------|
| PS201 | Finisher Tray Paper Sensor |
| PS202 | Staple Stacker Outlet Sensor |
| PS203 | Staple Inlet Sensor |
| PS204 | Y Alignment HP Sensor |
| PS205 | Finisher Tray Paper Full Sensor |
| PS206 | Alienation HP Sensor |
| PS207 | Jogger HP Sensor |
| PS208 | Finisher 2 Bin Tray Paper Sensor |
| PS209 | Finisher 2 Bin Tray Paper Full Sensor |
| PS210 | Staple Stacker Inlet Sensor |
| PS211 | Finisher Tray Upper Limit Sensor |
| PS212 | Finisher Tray Lower Limit Sensor |

Others (Finisher)



| No. | Name |
|------------------|---------------------------|
| FAN21 | Finisher Fan |
| SW3 | Finisher Door Switch |
| SW21 | Finisher Interlock Switch |
| FIN_PCA | Finisher Controller PCB |
| READER_RELAY_PCA | Reader Relay PCB |
| STAPLE UNIT | Staple Unit |

External Cover/Interior System



● Removing the Rear Cover

■ Procedure

1.

NOTE:

Remove the cord cover for the 120V host machine when removing the Rear Cover.




● Removing the Left Rear Cover

■ Preparation

1. "Removing the Rear Cover" on page 109

■ Procedure

1.



● Removing the Front Cover

■ Procedure

1.



2.




● Removing the Inlet Cover

■ Preparation

1. "Removing the Rear Cover" on page 109

■ Procedure

1.



● Removing the Right Lower Cover

■ Preparation


1. Pull out the Cassette1.
2. "Removing the Rear Cover" on page 109
3. "Removing the Inlet Cover" on page 111

■ Procedure


1.




2.




3.



4.



5.




● Removing the Cartridge Door Unit

■ Preparation


1. Pull out the Cassette1.
2. “ Removing the Rear Cover” on page 109
3. “ Removing the Left Rear Cover” on page 109

■ Procedure

1.



2.



3.




4.



● Removing the Control Panel

■ Procedure


1.





2.




3.



4.



5.




6.


CAUTION:
Do not drop the Control Panel while turning over it.



7.



8.




External / Internal Cover System (Finisher)


● Removing the Finisher Rear Cover

■ Procedure

1.



2.



● Removing the Finisher Right Upper Cover

■ Procedure

1.




2.



3.



4.




● Removing the Finisher Left Rear Cover

■ Preparation

1. “Removing the Finisher Rear Cover” on page 119

■ Procedure

1.




● Removing the Finisher Right Rear Cover

■ Preparation

1. “Removing the Finisher Rear Cover” on page 119
2. “Removing the Finisher Right Upper Cover” on page 119

■ Procedure

1.




● Removing the Finisher Right Lower Cover

■ Preparation

1. “ Removing the Staple Cover” on page 122
2. “ Removing the Finisher Rear Cover” on page 119
3. “ Removing the Finisher Right Upper Cover” on page 119
4. “ Removing the Staple Inner Cover” on page 123
5. “ Removing the Finisher Right Rear Cover” on page 121

■ Procedure


1.



● Removing the Staple Cover

■ Procedure

1.




● Removing the Staple Inner Cover

■ Preparation

1. "Removing the Staple Cover" on page 122

■ Procedure

1.




● Removing the Delivery Tray

■ Procedure

1.



2.




● Removing the Inner Delivery Rear Cover

■ Preparation

1. “ Removing the Rear Cover” on page 109
2. “ Removing the Left Rear Cover” on page 109
3. “ Removing the Finisher Rear Cover” on page 119
4. “ Removing the Finisher Left Rear Cover” on page 121
5. “ Removing the Delivery Tray” on page 124


■ Procedure

1.



NOTE:

Check the position of the claw in the figure




● Removing the Finisher Inner Rear Cover

■ Preparation



1. "Removing the Rear Cover" on page 109
2. "Removing the Left Rear Cover" on page 109
3. "Removing the Finisher Rear Cover" on page 119
4. "Removing the Finisher Left Rear Cover" on page 121
5. "Removing the Delivery Tray" on page 124
6. "Removing the Inner Delivery Rear Cover" on page 124

■ Procedure

1.



2.



NOTE:

Check the position of the claw in the figure



Original Exposure/Feed System

● Removing the ADF Unit


■ Preparation (With Finisher Model)

1. “Removing the Finisher Rear Cover” on page 119
2. “Removing the Rear Cover” on page 109
3. “Removing the Main Controller Sub Cover /Main Controller Cover” on page 192


■ Procedure (With Finisher Model)

CAUTION:

Be careful not to damage the white sheets [1] and [2] of the ADF Unit when disassembling/assembling.




1. Open the Feeder Cover [1].




2. Remove the Original Tray [1].

- 2 Shafts [2]




3. Remove the Rear Upper Cover [1].

- 2 Screws [2]
- 2 Bosses [3]




4. Remove the Cable [1] from the Harness Guide Part [3].

- 1 Connector [2]
- 1 Harness Guide [3]




5. Remove the Cable [1] from the Harness Guide Part [2]. Remove the Harness Guide Part [2].

- 1 Harness Guide [2]




6. Remove the Cable [1] from the Guide Part [2]. Remove the USB Cable [3].

- 7 Harness Guides [2]
- 1 USB Cable [3]
- 3 Connectors [4]




7. Remove the Screw [1] and the Grounding Wire [2].


- 1 Screw [1]
- 1 Grounding Wire [2]
- 1 Harness Guide [3]



8. Close the Feeder Cover [1].



9. Remove the ADF Unit [1] while removing the Harness Cover [2].



CAUTION:

When installing the ADF Unit [1], be sure to insert the rib [A] of the Harness Cover into the guide [B] of the Reader Unit.




■ Preparation (Without Finisher Model)

1. “Removing the Rear Cover” on page 109


■ Procedure (Without Finisher Model)

CAUTION:

Be careful not to damage the white sheets [1] and [2] of the ADF Unit when disassembling/assembling.




1. Open the Feeder Cover [1].




2. Remove the Original Tray [1].

- 2 Shafts [2]




3. Remove the Rear Upper Cover [1].

- 2 Screws [2]
- 2 Bosses [3]




4. Remove the Flat Cable [2] from the Main Controller PCB [1].

- 1 Flat Cable [2]
- 1 Harness Guide [3]




5. Remove the Cable [1] from the Harness Guide [2].

- 1 Harness Guide [2]
- 5 Connectors [3]




6. Remove the Screw [1] and the Grounding Wire [2].


- 1 Screw [1]
- 1 Grounding Wire [2]
- 1 Harness Guide [3]



7. Close the Feeder Cover [1].



8. Remove the ADF Unit [1] while removing the Harness Cover [2].



CAUTION:

When installing the ADF Unit [1], be sure to insert the rib [A] of the Harness Cover into the guide [B] of the Reader Unit.




● Removing the ADF Pickup Unit


■ Procedure

CAUTION:

Be sure not to touch the surface [A] of the roller when disassembling/assembling.





1. Open the Feeder Cover [1].



2. Remove the ADF Pickup Unit [2] while pressing the lever [1].

- 1 Claw [3]
- 1 Shaft [4]




● Removing the ADF Separation Unit


■ Procedure

CAUTION:

Be sure not to touch the surface [A] of the roller when disassembling/assembling.




1. Open the Feeder Cover [1].



2. Remove the ADF Separation Unit [1].

- 1 Claw [2]
- 1 Shaft [3]




● Removing the Scanner Unit (Back)


■ Procedure

CAUTION:

Be careful not to touch the [A] part of the sensor of the Scanner Unit (Back) when disassembling/assembling. Be sure to hold the side surface [B].




1. Open the Feeder Cover [1].




2. Remove the Original Tray [1].

- 2 Shafts [2]





3. Remove the ADF Rear Cover [1].

- 2 Screws [2]
- 2 Bosses [3]
- 2 Hooks [4]




CAUTION:

- Be careful not to trap the harness [2] with the ADF Rear Cover [1].
- Close the Harness Connection Cover [3] first, and then install the ADF Rear Cover [1].

**4. Remove the Link Arm [1].**


5. Remove the Separation Guide Unit [1].

- 1 Screw [2]
- 1 Grounding Wire [3]
- 1 Connector [4]
- 4 Screws [5]
- 2 Bosses [6]



6. Remove the Lead 1 Sensor Unit [1].

- 1 Screw [2]
- 1 Boss [3]
- 1 Hook [4]
- 1 Flag [5]




NOTE:

When installing the Lead 1 Sensor Unit [1], pass the shaft [A] under the flag [5].


7. Remove the harness [1].

- 1 Reuse Band [2]
- 1 Connector [3]




8. Remove the CIS Cover [1].

- 3 Screws [2]



9. Disconnect the Flat Cable [1].

- 1 Flat Cable [1]





10. Turn the Scanner Unit (Back) [1] 90 degrees.


- 1 Boss [2]

CAUTION:

Be careful not to touch the [A] part of the sensor of the Scanner Unit (Back) when disassembling/assembling. Be sure to hold the side surface [B].




11. Remove the Scanner Unit (Back) [1].




CAUTION:

When replacing the CIS Unit [1], be sure to replace the CIS Unit [1] and the CIS Spacers [2], which are included in the package of the service part, at the same time. If different spacers are used, image reading error may occur.



- If the Spacers are mixed or lost, be sure to check the Scanner Unit (Back) Rank Label [3] being used and use the Spacers appropriate for the rank of the Scanner Unit (Back).
- There are three ranks available for the Scanner Unit (Back), and there are spacers suitable for each rank.

| Rank | Color of spacer | Height of spacer |
|------|-----------------|------------------|
| A | Gray | 3.17 mm |
| B | Titanium white | 3.27 mm |
| C | Standard black | 3.37 mm |



12. Actions after Parts Replacement


[“Works After Replacement” on page 239](#)

● Removing the Copyboard Glass Unit

■ Procedure

CAUTION:

- When removing the Copyboard Glass, be careful not to touch the 2 glass surfaces [A].
- If the surface becomes dirty, clean it with the Glass Cleaning Sheet.




1. Open the ADF [1].




2. Remove the Wifi Cover [1].

- 1 Screw [2]
- 1 Claw [3]
- 1 Hook [4]



3. Remove the Copyboard Glass Unit [1].

- 4 Screws [2]
- 2 Bosses [3]



4. Actions after Parts Replacement

“After Replacing” on page 238

● Removing the Scanner Unit (Front)


■ Preparation

1. “Removing the Copyboard Glass Unit” on page 144


■ Procedure

CAUTION:


Be careful not to touch the [A] part of the sensor of the Scanner Unit (Front) when disassembling/assembling.




1. Move the Scanner Unit (Front) [1] to the center.



2. Remove the 2 spacers [1].




3. Place a sheet of paper [2] to prevent the rail [1] from being damaged.




4. Place the Scanner Unit (Front) [1] on the paper.

- 2 Shafts [2]




5. Remove the Scanner Unit (Front) [1].

- 1 Flat Cable [2]




CAUTION:

When replacing the Scanner Unit (Front) [1], be sure to replace the Scanner Unit (Front) [1] and the CIS Spacers [2], which are included in the package of the service part, at the same time. If different spacers are used, image reading error may occur.




- If the CIS Spacers are mixed or lost, be sure to check the CIS Rank Label [3] being used and use the CIS Spacers appropriate for the rank of the Scanner Unit (Front).
- There are three ranks available for the Scanner Unit (Front), and there are spacers suitable for each rank.

| Rank | Color of spacer | Height of spacer |
|------|-----------------|------------------|
| A | Gray | 1.13 mm |
| B | White | 1.23 mm |
| C | Brown | 1.33 mm |



CAUTION:

Be sure that the groove [1] of the CIS Unit Holder is hooked on the belt [2] when assembling.



6. Actions after Parts Replacement

“Works After Replacement” on page 238

● Removing the Reader Motor


■ Procedure

1. Open the Control Panel [1].




2. Remove the Reader Motor Cover [1].

- 2 Screws [2]



3. Remove the Reader Motor [1].

- 1 Connector [2]
- 1 Wire Saddle [3]
- 2 Screws [4]



● Removing the ADF Feed Frame


■ Preparation (With Finisher Model)

1. “Removing the Finisher Rear Cover” on page 119

2. "Removing the Rear Cover" on page 109
3. "Removing the Main Controller Sub Cover /Main Controller Cover" on page 192


■ Procedure (With Finisher Model)

1. Open the Feeder Cover [1].




2. Remove the Original Tray [1].

- 2 Shafts [2]




3. Remove the Rear Upper Cover [1].

- 2 Screws [2]
- 2 Bosses [3]




4. Remove the Cable [1] from the Harness Guide Part [3].

- 1 Connector [2]
- 1 Harness Guide [3]




5. Remove the Cable [1] from the Harness Guide Part [2]. Remove the Harness Guide Part [2].

- 1 Harness Guide [2]




6. Remove the Cable [1] from the Guide Part [2]. Remove the USB Cable [3].

- 7 Harness Guides [2]
- 1 USB Cable [3]
- 3 Connectors [4]




7. Remove the Screw [1] and the Grounding Wire [2].

- 1 Screw [1]
- 1 Grounding Wire [2]
- 1 Harness Guide [3]




8. Remove the ADF Rear Cover.

- 2 Screws [1]
- 2 Bosses [2]
- 2 Hooks [3]




CAUTION:

- Be careful not to trap the harness [1] with the ADF Rear Cover.
- Close the Harness Connection Cover [2] first, and then install the ADF Rear Cover.




9. Remove the Link Arm [1].




10. Remove the Separation Guide Unit [1].

- 1 Screw [2]
- 1 Grounding Wire [3]
- 1 Connector [4]
- 4 Screws [5]
- 2 Bosses [6]




11. Free the harness from the Harness Guide.

- 1 Connector [1]
- 2 Screws [2]
- 2 Round Shape Terminals [3]
- 1 Reuse Band [4]




12. Remove the Pickup Cover Unit.

- 2 Shafts [1]




13. Free the harness from the Harness Guide.

- 5 Connectors [1]
- 1 Screw [2]
- 1 Round Shape Terminal [3]




14. Free the harness from the Harness Guide, and then remove the Harness Guide.

- 2 Screws [1]




15. Remove the fan.


- 1 Connector [1]
- 1 Screw [2]
- 1 Boss [3]




16. Pass the Flat Cable through the Harness Cover [1], and free the cable from the Harness Guides [2].




17. Open the ADF, and place 5 sheets of paper on the Reader.




18. Remove the screws on the back side and remove the Bottom Cover.




19. Remove the White Plate and close the ADF.




20. Remove the screws.



21. Place the Flat Cable onto the Feed Frame Unit.




22. Secure the Base Frame Unit and the Reader in place with tapes.




CAUTION:
By removing the Feed Frame Unit, the Base Frame Unit opens abruptly.

23. Press the A part and remove the Feed Frame Unit.




CAUTION:


- Because the glass of the CIS Holder locates under the Feed Frame Unit, be careful not to hit the Feed Frame Unit against the Base Frame Unit.



- Be careful not to drop the Feed Frame Unit onto the Reader Glass.



- Be sure to place the Feed Frame Unit on a sheet of paper.




■ Preparation (Without Finisher Model)

1. “Removing the Rear Cover” on page 109


■ Procedure (Without Finisher Model)

1. Open the Feeder Cover [1].




2. Remove the Original Tray [1].

- 2 Shafts [2]




3. Remove the Rear Upper Cover [1].

- 2 Screws [2]
- 2 Bosses [3]




4. Remove the Flat Cable [2] from the Main Controller PCB [1].

- 1 Flat Cable [2]
- 1 Harness Guide [3]




5. Remove the Cable [1] from the Harness Guide [2].

- 1 Harness Guide [2]
- 5 Conners [3]




6. Remove the Screw [1] and the Grounding Wire [2].

- 1 Screw [1]
- 1 Grounding Wire [2]
- 1 Harness Guide [3]




7. Remove the ADF Rear Cover.

- 2 Screws [1]
- 2 Bosses [2]
- 2 Hooks [3]




CAUTION:

- Be careful not to trap the harness [1] with the ADF Rear Cover.
- Close the Harness Connection Cover [2] first, and then install the ADF Rear Cover.




8. Remove the Link Arm [1].




9. Remove the Separation Guide Unit [1].

- 1 Screw [2]
- 1 Grounding Wire [3]
- 1 Connector [4]
- 4 Screws [5]
- 2 Bosses [6]




10. Free the harness from the Harness Guide.

- 1 Connector [1]
- 2 Screws [2]
- 2 Round Shape Terminals [3]
- 1 Reuse Band [4]




11. Remove the Pickup Cover Unit.

- 2 Shafts [1]




12. Free the harness from the Harness Guide.

- 5 Connectors [1]
- 1 Screw [2]
- 1 Round Shape Terminal [3]




13. Free the harness from the Harness Guide, and then remove the Harness Guide.

- 2 Screws [1]




14. Remove the fan.


- 1 Connector [1]
- 1 Screw [2]
- 1 Boss [3]




15. Pass the Flat Cable through the Harness Cover [1], and free the cable from the Harness Guides [2].




16. Open the ADF, and place 5 sheets of paper on the Reader.




17. Remove the screws on the back side and remove the Bottom Cover.




18. Remove the White Plate and close the ADF.




19. Remove the screws.



20. Place the Flat Cable onto the Feed Frame Unit.




21. Secure the Base Frame Unit and the Reader in place with tapes.




CAUTION:
By removing the Feed Frame Unit, the Base Frame Unit opens abruptly.

22. Press the A part and remove the Feed Frame Unit.




CAUTION:


- Because the glass of the CIS Holder locates under the Feed Frame Unit, be careful not to hit the Feed Frame Unit against the Base Frame Unit.



- Be careful not to drop the Feed Frame Unit onto the Reader Glass.




- Be sure to place the Feed Frame Unit on a sheet of paper.




■ Procedure

1. Open the Feeder Cover [1].




2. Remove the Original Tray [1].

- 2 Shafts [2]




3. Remove the Rear Upper Cover [1].

- 2 Screws [2]
- 2 Bosses [3]




4. Disconnect the Flat Cable.

- 1 Guide [A]




5. Free the Flat Cable from the guide [B].




6. Remove the ADF Rear Cover.

- 2 Screws [1]
- 2 Bosses [2]
- 2 Hooks [3]




CAUTION:

- Be careful not to trap the harness [1] with the ADF Rear Cover.
- Close the Harness Connection Cover [2] first, and then install the ADF Rear Cover.




7. Remove the Link Arm [1].




8. Remove the Separation Guide Unit [1].

- 1 Screw [2]
- 1 Grounding Wire [3]
- 1 Connector [4]
- 4 Screws [5]
- 2 Bosses [6]




9. Free the harness from the Harness Guide.

- 1 Connector [1]
- 2 Screws [2]
- 2 Round Shape Terminals [3]
- 1 Reuse Band [4]




10. Remove the Pickup Cover Unit.

- 2 Shafts [1]




11. Free the harness from the Harness Guide.

- 5 Connectors [1]
- 1 Screw [2]
- 1 Round Shape Terminal [3]




12. Free the harness from the Harness Guide, and then remove the Harness Guide.

- 2 Screws [1]




13. Remove the fan.


- 1 Connector [1]
- 1 Screw [2]
- 1 Boss [3]




14. Pass the Flat Cable through the Harness Cover [1], and free the cable from the Harness Guides [2].




15. Open the ADF, and place 5 sheets of paper on the Reader.




16. Remove the screws on the back side and remove the Bottom Cover.




17. Remove the White Plate and close the ADF.




18. Remove the screws.



19. Place the Flat Cable onto the Feed Frame Unit.




20. Secure the Base Frame Unit and the Reader in place with tapes.




CAUTION:
By removing the Feed Frame Unit, the Base Frame Unit opens abruptly.

21. Press the A part and remove the Feed Frame Unit.




CAUTION:


- Because the glass of the CIS Holder locates under the Feed Frame Unit, be careful not to hit the Feed Frame Unit against the Base Frame Unit.



- Be careful not to drop the Feed Frame Unit onto the Reader Glass.



- Be sure to place the Feed Frame Unit on a sheet of paper.



Removing the CIS Holder


■ Preparation

1. “Removing the Rear Cover” on page 109
2. “Removing the Main Controller Sub Cover /Main Controller Cover” on page 192
3. “Removing the ADF Feed Frame” on page 149

■ Procedure


1. Remove the 2 screws and 1 spring.

- 2 Hooks [1]



2. Remove the Drive Support Plate.

- 2 Belts [1]
- 3 Shaft Supports [2]




3. Actions after Parts Replacement

[“Installing the Drive Support Plate” on page 188](#)


4. Remove the Lead Roller (1).

- 2 Clips [1]
- 1 Bushing [2]
- 1 Gear [3]
- 1 E-ring [4]
- 1 Shaft Support [5]



5. Remove the Lead Sensor Unit.


- 1 Screw [1]
- 1 Boss [2]
- 1 Hook [3]
- 1 Flag [4]

**NOTE:**

When installing the Lead Sensor Unit, be sure to pass the shaft [A] under the flag [4].

6. Remove the Delivery Sensor Holder.


- 1 Reuse Band [1]
- 1 Connector [2]
- 2 Screws [3]

**NOTE:**

When installing the Delivery Sensor Holder, be sure to pass the shaft [A] under the flag [4].


7. Remove the CIS Adjustment Holder.

- 1 Screw [1]




CAUTION:

When installing the CIS Adjustment Holder, be sure to install the screw so that it is aligned with the center of marking lines.




8. Remove the CIS Cover.


- 3 Screws [1]



9. Remove the 5 CIS Fixation Screws.




10. Disconnect the Flat Cable.




11. Remove the CIS Holder.




1.



2.




3.




NOTE:

Points of the CIS Holder Installation


- Raise the Drive Frame.



- Fit the CIS Adjustment Holder Retainer into the place.




- Be sure that the bosses are fit into the holes on the CIS Holder.



CAUTION:

Points of the CIS Holder Installation


- Be sure that the Compression Spring is in contact with the side of the CIS Holder.



■ Installing the Drive Support Plate


● Procedure

1. Remove the Drive Release Coupling.




2. Remove the 2 shafts.

- 2 Clips [1]
- 1 Clutch Rotation Stopper [2]
- 1 Bushing [3]




3. Install the 3 Shaft Supports.




4. Install the 2 shafts.

- 2 Belts [1]



NOTE:


Be sure that the Electromagnetic Clutch is oriented in the direction as shown in the figure to make the installation of the Drive Support Plate easier.



5. Install the Drive Support Plate.


NOTE:

- Pass the harness of the clutch through the hole on the Drive Support Plate.
- Be sure to align the shaft with the Shaft Support.




6. Install the Clutch Rotation Stopper [1] and the bushing [2].


- 2 Clips [3]

**CAUTION:**


Be sure that the Clutch Rotation Stopper is inserted into the [A] part.



7. Install the screws.




8. Install the Drive Release Coupling while let the Drive Release Lever avoid contact with the coupling.



9. Set the spring.

- 2 Hooks [1]



Controller System


● Removing the Main Controller Sub Cover /Main Controller Cover

■ Preparation

1. "Removing the Rear Cover" on page 109

■ Procedure


1.



2.

CAUTION:

Be sure not to drop off or shake the HDD while handling it.




● Removing the HDD

■ Preparation

1. “Removing the Rear Cover” on page 109
2. “Removing the Main Controller Sub Cover /Main Controller Cover” on page 192

■ Procedure

1.




● Removing the Main Controller PCB

■ Preparation


1. “Removing the Rear Cover” on page 109
2. “Removing the Left Rear Cover” on page 109
3. “Removing the Main Controller Sub Cover /Main Controller Cover” on page 192
4. “Removing the FAX Unit” on page 199

■ Procedure


1.




2.




3.




4.



5.



6.



● Removing the Low-Voltage Power Supply PCB


■ Preparation

1. “ Removing the Fixing Assembly” on page 212
2. “ Removing the Rear Cover” on page 109
3. “ Removing the Left Rear Cover” on page 109


- 4. "Removing the Inlet Cover" on page 111
- 5. " Removing the Main Controller PCB" on page 193

■ Procedure


1.



2.



3.



● Removing the Inlet Unit


■ Preparation

- 1. " Removing the Rear Cover" on page 109


2. "Removing the Left Rear Cover" on page 109
3. "Removing the Main Controller PCB" on page 193
4. "Removing the Inlet Cover" on page 111
5. "Removing the FAX Unit" on page 199

■ Procedure


1.



2.



3.




● Removing the DC Controller PCB

■ Preparation


1. “Removing the Rear Cover” on page 109
2. “Removing the Left Rear Cover” on page 109

■ Procedure

1.



2.




● Removing the High-Voltage Power Supply PCB

■ Preparation

1. Pull out the Cassette1.
2. “Removing the Front Cover” on page 110

■ Procedure

1.





● Removing the FAX Unit

■ Preparation


1. "Removing the Rear Cover" on page 109
2. "Removing the Left Rear Cover" on page 109
3. "Removing the Main Controller Sub Cover /Main Controller Cover" on page 192

■ Procedure

1.





2.



3.

CAUTION:

Do not touch the speaker part[A] of the Fax unit.



Controller System (Finisher)


● Removing the Finisher Controller PCB

■ Preparation

1. “Removing the Rear Cover” on page 109
2. “Removing the Finisher Rear Cover” on page 119

■ Procedure

1.



Laser Exposure System

● Removing the Laser Scanner Unit

■ Preparation

1. "Removing the Delivery Tray" on page 124

■ Procedure

1.




Image Formation System


● Removing the Transfer Unit

■ Procedure


1.




2.



3.



4.




● Removing the Developing Drive Unit

■ Preparation


1. “ Removing the Rear Cover” on page 109
2. “ Removing the Left Rear Cover” on page 109
3. “ Removing the Main Controller PCB” on page 193
4. “ Removing the Fixing Assembly” on page 212
5. “Removing the Inlet Cover” on page 111
6. “ Removing the Low-Voltage Power Supply PCB” on page 195

■ Procedure

1.





2.



3.


CAUTION:

When removing this unit, do not hold it flat as such parts as the gear may fall off.



CAUTION:

Install the sensor part onto the position as shown in the figure.




● Removing the Lifter Drive Unit

■ Preparation


1. Pull out the Cassette1.
2. “ Removing the Rear Cover” on page 109
3. “ Removing the Left Rear Cover” on page 109
4. “ Removing the Main Controller PCB” on page 193
5. “Removing the Inlet Cover” on page 111
6. “ Removing the Low-Voltage Power Supply PCB” on page 195

■ Procedure


1.




2.



3.



4.



● Removing the Drum Motor Unit


■ Preparation

1. "Removing the Rear Cover" on page 109
2. "Removing the Left Rear Cover" on page 109
3. "Removing the Main Controller PCB" on page 193
4. "Removing the Inlet Cover" on page 111

5. "Removing the Low-Voltage Power Supply PCB" on page 195

■ Procedure

1.




Fixing System

● Removing the Fixing Assembly

■ Procedure

1.




● Removing the Fixing Drive Unit

■ Preparation


1. “ Removing the Fixing Assembly” on page 212
2. “ Removing the Rear Cover” on page 109
3. “ Removing the Left Rear Cover” on page 109
4. “Removing the Inlet Cover” on page 111
5. “ Removing the Main Controller PCB” on page 193
6. “ Removing the Low-Voltage Power Supply PCB” on page 195

■ Procedure


1.




2.



3.



4.



Pickup Feed System


● Removing the Paper Delivery Unit

■ Preparation


1. “ Removing the Finisher Rear Cover” on page 119
2. “ Removing the Finisher Left Rear Cover” on page 121
3. “ Removing the Staple Cover” on page 122
4. “ Removing the Staple Unit” on page 225
5. “Removing the Jogger Unit” on page 225
6. “ Removing the Finisher Right Upper Cover” on page 119
7. “ Removing the Staple Inner Cover” on page 123
8. “ Removing the Finisher Right Rear Cover” on page 121
9. “ Removing the Finisher Right Lower Cover” on page 122
10. “Upper Paper Feed Unit” on page 227
11. “ Removing the Rear Cover” on page 109
12. “ Removing the Left Rear Cover” on page 109
13. “Removing the Finisher Fan” on page 226
14. “ Removing the Fixing Assembly” on page 212
15. “ Removing the Front Cover” on page 110
16. “ Removing the Delivery Tray” on page 124
17. “ Removing the Inner Delivery Rear Cover” on page 124
18. “ Removing the Finisher Inner Rear Cover” on page 125
19. “Lower Paper Feed Unit” on page 229

■ Procedure


1.



2.



3.




● Removing the Main Drive Unit

■ Preparation


1. "Removing the Rear Cover" on page 109
2. "Removing the Left Rear Cover" on page 109
3. "Removing the Main Controller PCB" on page 193
4. "Removing the Inlet Cover" on page 111
5. "Removing the Low-Voltage Power Supply PCB" on page 195
6. "Removing the Fixing Drive Unit" on page 212
7. "Removing the Inlet Unit" on page 196
8. "Removing the Drum Motor Unit" on page 210

■ Procedure


1.




2.




3.




4.




5.





6.




7.




8.



9.

**CAUTION:**

- Do not hit the gear on bottom of the Main Drive Unit to the host machine.
- Check that the spring is installed at the position as shown in the figure.



● Removing the Paper Pickup Unit

■ Preparation



1. "Removing the Rear Cover" on page 109
2. Remove the Drum Unit.
3. Pull out the Cassette1.
4. "Removing the Fixing Assembly" on page 212
5. "Removing the Left Rear Cover" on page 109
6. "Removing the Main Controller PCB" on page 193
7. "Removing the Inlet Cover" on page 111
8. "Removing the Low-Voltage Power Supply PCB" on page 195
9. "Removing the Fixing Drive Unit" on page 212
10. "Removing the Inlet Unit" on page 196
11. "Removing the Drum Motor Unit" on page 210
12. "Removing the Main Drive Unit" on page 215

13. "Removing the Transfer Unit" on page 205



14. "Removing the Right Lower Cover" on page 111

■ Procedure



1.




2.



3.




4.




NOTE:

Installation Procedure

1. Put the cable through the hole as shown in the figure.



2. Push the lever while installing the Pickup Unit.




● Removing the Multi-purpose Tray Feed Roller

■ Procedure

NOTE:

Do not touch the roller in the dirt fingers to prevent paper conveying performance from being deteriorated while replacing the part.

1.



2.



NOTE:

Initialize the part counter on the following user mode when replacing consumable part.




- COPIER > COUNTER > DRBL-1 > M-FD-RL

● Removing the Multi-purpose Tray Separation Roller

■ Procedure

NOTE:

Do not touch the roller in the dirt fingers to prevent paper conveying performance from being deteriorated while replacing the part.

1.**2.****3.**

4.



NOTE:

Initialize the part counter on the following user mode when replacing consumable part.

- COPIER > COUNTER > DRBL-1 > M-SP-RL

Pickup Feed System (Finisher)


Removing the Jogger Unit

Preparation



1. “Removing the Staple Cover” on page 122
2. “Removing the Finisher Rear Cover” on page 119

Procedure

1.



2.
3.




Removing the Staple Unit

Preparation

1. “Removing the Staple Cover” on page 122

■ Procedure

1.




● Removing the Finisher Fan

■ Preparation


1. “ Removing the Rear Cover” on page 109
2. “ Removing the Finisher Rear Cover” on page 119

■ Procedure

1.



2.




Removing the Finisher Motor

Preparation

1. “ Removing the Rear Cover” on page 109
2. “ Removing the Finisher Rear Cover” on page 119
3. “Removing the Finisher Fan” on page 226

Procedure

1.




Upper Paper Feed Unit

Preparation


1. “ Removing the Finisher Rear Cover” on page 119
2. “ Removing the Finisher Left Rear Cover” on page 121
3. “ Removing the Staple Cover” on page 122
4. “ Removing the Staple Unit” on page 225
5. “Removing the Jogger Unit” on page 225
6. “ Removing the Finisher Right Upper Cover” on page 119
7. “ Removing the Staple Inner Cover” on page 123
8. “ Removing the Finisher Right Rear Cover” on page 121
9. “ Removing the Finisher Right Lower Cover” on page 122

■ Procedure


1.



2.



3.




● Lower Paper Feed Unit

■ Preparation


1. "Removing the Finisher Rear Cover" on page 119
2. "Removing the Finisher Left Rear Cover" on page 121
3. "Removing the Staple Cover" on page 122
4. "Removing the Staple Unit" on page 225
5. "Removing the Jogger Unit" on page 225
6. "Removing the Finisher Right Upper Cover" on page 119
7. "Removing the Staple Inner Cover" on page 123
8. "Removing the Finisher Right Rear Cover" on page 121
9. "Removing the Finisher Right Lower Cover" on page 122
10. "Upper Paper Feed Unit" on page 227
11. "Removing the Rear Cover" on page 109
12. "Removing the Finisher Fan" on page 226
13. "Removing the Front Cover" on page 110
14. "Removing the Left Rear Cover" on page 109
15. "Removing the Delivery Tray" on page 124
16. "Removing the Inner Delivery Rear Cover" on page 124
17. "Removing the Finisher Inner Rear Cover" on page 125

■ Procedure


1.




2.




3.



4.



5.





Adjustment

| | |
|-----------------------------------|-----|
| Pickup Feed System..... | 233 |
| Actions at Parts Replacement..... | 235 |

Pickup Feed System


Image Position Adjustment

■ Cassette Left Edge Margin Adjustment (1st Side)

CAUTION:

- Check the left edge margin with TYPE=5, black halftone.
- When printing duplicate copies, 1st side is printed to the front of paper and 2nd side is printed to the back of paper.

Copy from the cassette, and check that the left edge margin (L1) is within 2.5 +/- 1.5mm (for LTR/LGL: 4.2 +/- 1.5 mm). When it is out of the specified range, perform the following procedure.



1. Change the left edge margin (L1) for the 1st side of paper in the following service mode.

- Service mode > COPIER > ADJUST > FEED-ADJ > ADJ-C1

When the value is increased by 1, the left edge margin (L1) is increased by 0.1 mm (the image moves to the right).

2. Copy from the cassette, and check that the left edge margin (L1) is within 2.5mm +/- 1.5mm (for LTR/LGL: 4.2 +/- 1.5 mm).

3. Write the adjusted value on the service label.


- ADJ-C1

■ Cassette Left Edge Margin Adjustment (2nd Side)

CAUTION:

- Check the left edge margin with TYPE=5, black halftone.
- When printing duplicate copies, 1st side is printed to the front of paper and 2nd side is printed to the back of paper.

Copy from the cassette, and check that the left edge margin (L1) is within 2.5 +/- 2.0mm (for LTR/LGL: 4.2 +/- 2.0mm). When it is out of the specified range, perform the following procedure.



1. Change the left edge margin (L1) for the 2nd side of paper in the following service mode.

- Service mode > COPIER > ADJUST > FEED-ADJ > ADJ-C1RE

When the value is increased by 1, the left edge margin (L1) is increased by 0.1mm (the image moves to the right).

2. Copy from the cassette, and check that the left edge margin (L1) is within 2.5mm +/- 2.0mm (for LTR/LGL: 4.2 +/- 2.0mm).

3. Write the adjusted value on the service label.


- ADJ-C1RE

■ Leading Edge Margin Adjustment (1st Side)

CAUTION:

- Check the left edge margin with TYPE=5, black halftone.
- When printing duplicate copies, 1st side is printed to the front of paper and 2nd side is printed to the back of paper.

Copy from the cassette, and check that the left edge margin (L1) is within 4.0 +/- 2.0mm. When it is out of the specified range, perform the following procedure.



1. Change the left edge margin (L1) for the 1st side of the paper in the following service mode.

- Service mode > COPIER > ADJUST > FEED-ADJ > REGIST

When the value is increased by 1, the left edge margin (L1) is increased by 0.1mm (the image moves to the right).

2. Copy from the cassette, and check that the left edge margin (L1) is within 4.0 +/- 2.0mm.

3. Write the adjusted value on the service label.


- REGIST

■ Leading Edge Margin Adjustment (2nd Side)

CAUTION:

- Check the left edge margin with TYPE=5, black halftone.
- When printing duplicate copies, 1st side is printed to the front of paper and 2nd side is printed to the back of paper.

Copy from the cassette, and check that the left edge margin (L1) is within 4.0 +/- 2.0mm. When it is out of the specified range, perform the following procedure.



1. Change the left edge margin (L1) for the 2nd side of the paper in the following service mode.

- Service mode > COPIER > ADJUST > FEED-ADJ > REG-DUP1

When the value is increased by 1, the left edge margin (L1) is increased by 0.1mm (the image moves to the right).

2. Copy from the cassette, and check that the left edge margin (L1) is within 4.0 +/- 2.0mm.

3. Write the adjusted value on the service label.

- REG-DUP1

Actions at Parts Replacement

Hard Disc

Overview

The following describes the tasks when replacing the HDD.

Note that procedures to backup/restore the data in the HDD is required when replacing the HDD.

Perform backup/restoration based on the following.

Backup List

| Backup target data | Backup Method | | | |
|---|-----------------|---------|-------|-----------|
| | User | Service | DCM | Power OFF |
| | (excluding DCM) | | | |
| Address List | Yes*1 | - | Yes*9 | - |
| Forwarding Settings | Yes*1 | - | Yes*9 | - |
| Settings / Registration | | | | |
| Preferences (Except for Paper Type Management Settings) | - | - | Yes*9 | Yes*10 |
| Adjustment/Maintenance | - | - | Yes*9 | Yes*10 |
| Function Settings (Except for Printer Custom Settings, Forwarding Settings) | - | - | Yes*9 | Yes*10 |
| Set Destination (Except for Address List) | - | - | Yes*9 | Yes*10 |
| Management Settings (Except for Address List) | - | - | Yes*9 | Yes*10 |
| User authentication information used for local device authentication of UA (User Authentication) | Yes*2 | - | Yes*9 | - |
| Printer Settings | Yes*1 | - | Yes*9 | Yes*10 |
| Set Paper Information | Yes*1 | - | Yes*9 | - |
| Setting items for each menu in Main Menu (Copy, Scan and Send, Fax, Scan and Store, Access Stored Files, Fax/I-Fax Inbox) | | | | |
| Favorite Settings | Yes*1 | Yes*8 | Yes*9 | - |
| Default Settings | - | Yes*8 | Yes*9 | - |
| Shortcut settings for "Options" | - | Yes*8 | Yes*9 | - |
| Previous Settings | - | Yes*8 | - | - |
| Setting items for Quick Menu | | | | |
| Button Size information | - | - | Yes*9 | - |
| Wallpaper Setting | - | - | Yes*9 | - |
| Button information in Quick Menu | - | - | Yes*9 | - |
| Restrict Quick Menu | - | - | Yes*9 | - |
| Setting items for Main Menu | | | | |
| Button settings in Main Menu | - | - | Yes*9 | - |
| Button settings on the top of the screen | - | - | Yes*9 | - |
| Wallpaper Setting for Main Menu | - | - | Yes*9 | - |
| Other settings for Main Menu | - | - | Yes*9 | - |
| Function Settings > Store/Access Files | | | | |
| Mail Box Settings (Register Box Name, PIN, Time Until File Auto Delete, Printer upon Storing from Printer Driver) | Yes*4 | - | Yes*9 | - |
| Image data in Mail Box, Fax Inbox, and Memory RX Inbox | Yes*4 | - | - | - |
| Network Place Settings | - | - | Yes*9 | Yes*10 |
| Web browser settings | | | | |
| Web Access setting information | - | Yes*8 | Yes*9 | - |
| MEAP settings | | | | |
| MEAP application | - | Yes*8 | - | - |
| License files for MEAP applications | Yes*5 | - | - | - |
| Data saved using MEAP applications | Yes*5 | △*8 | Yes*9 | - |
| SMS (Service Management Service) password | - | Yes*8 | - | - |
| Universal data settings | | | | |

| Backup target data | Backup Method | | | |
|--|-----------------|---------|--------|-----------|
| | User | Service | DCM | Power OFF |
| | (excluding DCM) | | | |
| Unsent documents (documents waiting to be sent with the Delayed Send mode) | - | - | - | - |
| Job logs | - | - | - | - |
| Audit Log | Yes*6 | - | - | - |
| Key Pair and Server Certificate in Certificate Settings in TCP/IP Settings in Network Settings in System Settings (from the Additional Functions screen) | - | - | Yes*9 | - |
| Auto Adjust Gradation setting values | - | - | - | - |
| PS font | - | - | - | - |
| Key information to be used for encryption when TPM is OFF | - | - | - | - |
| Key and settings information to be used for encryption when TPM is ON | Yes*7 | - | - | - |
| Personal Settings | | | | |
| Display Language | - | - | Yes *9 | - |
| Accessibility Settings | - | - | Yes *9 | - |
| Default Screen | - | - | Yes *9 | - |
| Default Job Settings | - | - | Yes *9 | - |
| Quick Menu (Personal, layout of the Personal tab, and background of the Personal tab) | - | - | Yes *9 | - |
| Address Book (Personal/Group) | Yes *1 | - | Yes *9 | - |
| Key ring (for host machine functions) | - | - | Yes *9 | - |
| Personal settings of MEAP | Yes *11 | Yes *8 | Yes *9 | - |
| Service Mode | | | | |
| Service Mode setting values (MN-CON) | - | - | △*9 | Yes*10 |

*1: Remote UI > Settings/Registration > Management Settings > Data Management > Import or Export

*2: Remote UI > Settings/Registration > Management Settings > User Management > Authentication Management > User Management

*3: Remote UI > Quick Menu > Export

*4: Remote UI > Settings/Registration > Management Settings > Data Management > Back Up or Restore

*5: Remote UI > Service Management Service

*6: Remote UI > Settings/Registration > Management Settings > Device Management > Save Audit Log

Audit log that was exported cannot be put back to the device from which the log was exported.

*7: Settings/Registration > Management Settings > Data Management > TPM Settings

*8: Download mode > [5]: Backup/Restore > [3] : MEAP Backup > Meapback.bin

Backup is possible using SST or USB memory

The data saved using a MEAP application can be backed up only when the MEAP application has a backup function.

*9: Backup Method using DCM When You set it in COPIER> OPTION> USER> SMD-EXPT> ON, a backup/restore is possible in Service Mode Settings from the Remote UI.

There is a backup button on the TOP page of the service mode.

- Remote UI > Settings/Registration > Management Settings > Data Management > Import/Export All
- Remote UI > Settings/Registration > Management Settings > Data Management > Import/Export
- Service mode top screen > BACKUP
- Web Service

*10: The setting value that was set when the main power was turned OFF the last time is automatically backed up to the Flash PCB. When a HDD is replaced with a new one, the setting value is automatically inherited from the Flash PCB at the time of HDD formatting.

*11: iWEMC DAM plug-in

■ Actions before Parts Replacement

1. Backup the required data based on the “Table: Backup List” on page 235.

2. Execute the following service mode and printout the setting data to be ready in case of failing to restore the data.

- COPIER > FUNCTION > MISC-P > USER-PRT
- COPIER > FUNCTION > MISC-P > P-PRINT

■ Actions after Parts Replacement

1. HDD format

Start the machine in safe mode, and format all partitions using SST or a USB memory.

2. Turning OFF and ON the main power switch.

3. Restoring the backup data

4. Resetting/registering the data

While referring to the list which was printed before replacement, reset/register the data.

5. When the user generates and adds the encryption key, certificate and/or CA certificate, request the user to generate them again.

6. Execute auto gradation adjustment.

- Execute auto gradation adjustment. Settings/Registration > Adjustment/Maintenance > Adjust Image Quality > Auto Adjust Gradation > Full Adjust

● Main Controller PCB

1. Remove the following parts from the main controller PCB and install them onto the replacing main controller PCB.

- Memory PCB
- FLASH PCB
- TPM PCB

CAUTION:

Do not transfer the following parts to another model (which has a different serial number). The Main Body does not activate normally and this might cause to fail the restoration.

- Main Controller PCB
- Memory PCB
- FLASH PCB
- TPM PCB

● DC Controller PCB

1. Backup the Service Mode setting data of DC Controller on the following service mode (Lv.2).

- Service Mode > COPIER > FUNCTION > SYSTEM > DSRAMBUP

2. Turn OFF the main power switch.

3. Restore of the Service Mode data on the following service mode (Lv.2) after replacing the DC Controller PCB.

- Service Mode > COPIER > FUNCTION > SYSTEM > DSRAMRES

NOTE:

If uploading of backup data fails before replacement due to the damage to the DC Controller PCB, enter the service setting values recorded on the service label or P-PRINT.

After Replacing the Copyboard Glass

After Replacing

1. Enter the value (XXXXYYYYZZZZ) shown on the Barcode Label affixed at the upper right of the Copyboard.


COPIER > ADJUST > CCD > W-PLT-X

COPIER > ADJUST > CCD > W-PLT-Y

COPIER > ADJUST > CCD > W-PLT-Z

CAUTION:

Be sure to make the white plate data adjustment before ADF white level adjustment.



2. Scanner Unit white level adjustment

COPIER > FUNCTION > CCD > CL-AGC

3. ADF white level adjustment

1. Place an A4 or LTR size paper on the Copyboard Glass and execute the service mode.

COPIER > FUNCTION > CCD > DF-WLVL1

2. Place an A4 or LTR size paper on the ADF and execute the service mode.

COPIER > FUNCTION > CCD > DF-WLVL2

4. Write the values on the service label for the Reader (back side of the Front door).

COPIER > ADJUST > CCD > W-PLT-X

COPIER > ADJUST > CCD > W-PLT-Y

COPIER > ADJUST > CCD > W-PLT-Z

After Replacing the Scanner Unit (Front)

Works After Replacement

1. Execute the following service mode to perform automatic adjustment of the reader shading position.

COPIER > FUNCTION > INSTALL > RDSHDPOS

2. Execute the following service mode to perform the black and white reference level adjustment for the Scanner Unit.

COPIER > FUNCTION > CCD > CL-AGC

3. Execute the following service mode to perform automatic adjustment of the reading position during DADF reading.

COPIER > FUNCTION > INSTALL > STRD-POS

4. Follow the steps shown below to adjust the ADF white level.

1. Place an A4 or LTR size paper on the Copyboard Glass and execute the following service mode.

COPIER > FUNCTION > CCD > DF-WLVL1

2. Place an A4 or LTR size paper on the ADF and execute the following service mode.

COPIER > FUNCTION > CCD > DF-WLVL2

5. In the following service modes, enter the values shown on the label included with the Scanner Unit.

COPIER > ADJUST > CCD > MTF-xxx

COPIER > ADJUST > CCD > MTF2-xxx

6. In the following service mode, calculate the MTF filter coefficient.

COPIER > FUNCTION > CCD > MTF-CLC

7. From the following menu, execute the auto gradation adjustment.

Settings/Registration > Adjustment > Adjustment/Maintenance > Adjust Image Quality > Auto Adjust Gradation > Full Adjust

- 8. Write down the following service mode values on the service label for the Reader (on the Front Door of the host machine).**

COPIER > ADJUST > CCD > MTF-xxx
 COPIER > ADJUST > CCD > MTF2-xxx

- 9. In the following service mode, perform the reading start position adjustment as needed.**

1. Copyboard reading
 COPIER > ADJUST > ADJ-XY > ADJ-X
 COPIER > ADJUST > ADJ-XY > ADJ-Y
2. ADF stream reading
 COPIER > ADJUST > ADJ-XY > ADJ-S
 COPIER > ADJUST > ADJ-XY > ADJ-Y-DF
 COPIER > ADJUST > ADJ-XY > ADJY-DF2

After Replacing the Scanner Unit (Back)

■ Works After Replacement

- 1. Execute the following service mode to adjust the Scanner Unit white level.**

COPIER > FUNCTION > CCD > CL-AGC

- 2. Follow the steps shown below to adjust the ADF white level.**

1. Place an A4 or LTR size paper on the Copyboard Glass and execute the following service mode.
 COPIER > FUNCTION > CCD > DF-WLVL1
2. Place an A4 or LTR size paper on the ADF and execute the following service mode.
 COPIER > FUNCTION > CCD > DF-WLVL2

- 3. Follow the steps shown below to perform the paper back shading correction.**

1. Cleaning the reading side 1
 Locations for cleaning: Stream Reading Glass for front side, Stream Reading Glass for back side
 Cleaning method: Clean with the light-blue cloth stored in the Reader Assembly.
2. Paper back shading correction 1
 Close the ADF, and execute the following service mode.
 COPIER > FUNCTION > CCD > BK-SHD1
3. Paper back shading correction 2
 Place the White Plate included with the package by aligning it with the jumping platform, close the ADF, and execute the following service mode.
 COPIER > FUNCTION > CCD > BK-SHD2
4. Cleaning the reading side 2
 Remove the White Plate and perform the cleaning again.
 Locations for cleaning: Stream Reading Glass for front side, Stream Reading Glass for back side
 Cleaning method: Clean with the light-blue cloth stored in the Reader Assembly.
5. Paper back shading correction 3
 Close the ADF, and execute the following service mode.
 COPIER > FUNCTION > CCD > BK-SHD3

- 4. In the following service modes, enter the values shown on the label included with the Scanner Unit.**

COPIER > ADJUST > CCD > MTF3-xxx

- 5. Execute the following service mode to calculate the MTF filter coefficient.**

COPIER > FUNCTION > CCD > MTF-CLC

- 6. In the following menu, execute the auto gradation adjustment.**

Settings/Registration > Adjustment > Adjustment/Maintenance > Adjust Image Quality > Auto Adjust Gradation > Full Adjust

- 7. Write down the following service mode values on the service label for the Reader (on the Front Door of the host machine).**

COPIER > ADJUST > CCD > MTF3-xxx

8. Execute the following service modes to adjust the reading start position as needed.

COPIER > ADJUST > ADJ-XY > ADJ-S: Adjustment of the Reader shading position

COPIER > ADJUST > ADJ-XY > ADJ-Y-DF: Adjustment of the reading start position (DADF, front side, horizontal scanning direction)

COPIER > ADJUST > ADJ-XY > ADJY-DF2: Adjustment of the reading start position (DADF, back side, horizontal scanning direction)

After Replacing Touch Panel/Control Panel CPU PCB/LCD Unit

Works After Replacement



Execute the following service mode to adjust the Touch Panel only when replacing a single part.

COPIER > FUNCTION > PANEL > TOUCHCHK

CAUTION:

If the coordinate on the Touch Panel is not correct, adjustment of the Touch Panel may not be performed. In that case, the Touch Panel can be adjusted by performing the following menu operation using hardware keys.

- Press the [Settings/Registration] button on the service mode top screen, and then press [5] key 3 times.





Troubleshooting

| | |
|--------------------|-----|
| Initial Check..... | 242 |
| Test Print..... | 243 |
| Debug Log..... | 248 |

Initial Check

Initial check items list

| Item | No. | Detail | Check |
|--|-----|---|-------|
| Site Environment | 1 | The voltage of the power supply is as rated ($\pm 10\%$). | |
| | 2 | The site is not a high temperature / humidity environment (near a water faucet, water boiler, humidifier), and it is not in a cold place. The machine is not near a source of fire or dust. | |
| | 3 | The site is not subject to ammonium gas. | |
| | 4 | The site is not exposed to direct rays of the sun. (Otherwise, provide curtains.) | |
| | 5 | The site is well ventilated, and the floor keeps the machine level. | |
| | 6 | The machine's power plug remains connected to the power outlet. | |
| Checking the Paper | 7 | The paper is of a recommended type. | |
| | 8 | The paper is not moist. Try paper fresh out of package. | |
| Checking the Placement of Paper | 9 | Check the cassette and the manual feed tray to see if the paper is not in excess of a specific level. | |
| | 10 | If a transparency is used, check to make sure that it is placed in the correct orientation in the manual feed tray. | |
| Checking the Durables | 11 | Check the table of durables to see if any has reached the end of its life. | |
| Checking the Periodically Replaced Parts | 12 | Check the scheduled servicing table and the periodically replaced parts table, and replace any part that has reached the time of replacement. | |

Test Print


Overview

| PG TYPE | Pattern | Image check item | | | | | | | | | | |
|---------|---|------------------|----------|--------------------|------------|------------|--------------|-----------------------------|---|--------------------|-------|----------------------|
| | | Grada-tion | Fog-ging | Trans-fer fail-ure | Black line | White line | Uneven pitch | Uneven density (rear/front) | Right angle accura-cy Straigh t line accura-cy | Side regis-tration | Shock | Magnifi-cation ratio |
| 0 | Normal copy/print | | | | | | | | | | | |
| 1 | Grid | | | | | | | | Yes | Yes | | Yes |
| 2 | 17 grada-tions Tbic rank 2 | Yes | | | Yes | Yes | | | | | | |
| 3 | 17 grada-tions 600dpi (134-line screen or 141-line screen) | Yes | | | Yes | Yes | | | | | | |
| 4 | Solid white | | Yes | | | | | | | | | |
| 5 | Halftone (density: 80H, Tbic rank 2, without im-age correc-tion) | | | Yes | Yes | Yes | Yes | Yes | | | Yes | |
| 6 | Halftone (density: 80H, 134-line screen or 141-line screen, without im-age correc-tion) | | | Yes | Yes | Yes | Yes | Yes | | | Yes | |
| 7 | Solid black | | | Yes | | Yes | Yes | Yes | | | | |
| 8 | Horizontal line (4 dots, 27 spaces) | | | | Yes | Yes | Yes | Yes | | | | |
| 9 | Horizontal line (6 dots, 50 spaces) | | | | Yes | Yes | Yes | Yes | | | | |
| 10 | Horizontal line (2 dots, 3 spaces) | | | | Yes | Yes | Yes | Yes | | | | |
| 11 | Halftone (density: 60H, Tbic rank 2, without im-age correc-tion) | | | Yes | Yes | Yes | Yes | Yes | | Yes | Yes | |

| PG TYPE | Pattern | Image check item | | | | | | | | | | |
|---------|--|------------------|--------------|----------------------------|---------------|---------------|-----------------|---------------------------------------|---|---------------------------|-------|-----------------------------|
| | | Grada- tion | Fog- ging | Trans- fer fail- ure | Black line | White line | Uneven pitch | Uneven density (rear/ front) | Right angle accura- cy Straigh t line accura- cy | Side regis- tration | Shock | Magnifi- cation ratio |
| 12 | Halftone (density: 60H, 134- line screen or 141-line screen, without im- age correc- tion) | | | Yes | Yes | Yes | Yes | Yes | | | Yes | |
| 13 | Halftone (density: 30H, Tbic rank 2, without im- age correc- tion) | | | Yes | Yes | Yes | Yes | Yes | | | Yes | |
| 14 | Halftone (density: 30H, 134- line screen or 141-line screen, without im- age correc- tion) | | | Yes | Yes | Yes | Yes | Yes | | | Yes | |
| 15 | 15 to 50: For devel- opment | | | | | | | | | | | |


How to use the test print

■ Grid (TYPE=1)




| Check item | Check method | Assumed cause |
|---|--|--|
| Right angle accuracy/Straight line accuracy | Check whether lines in the horizontal/vertical scanning directions are paralleled to the paper and these lines are at right angles to one another. | Feed system failure or Laser Scanner Unit failure is considered. |
| Side registration | Check the left margin. | Floor at the installation site is extremely distorted, or the feed system failure is considered. |
| Magnification ratio | Check whether the grid is printed at 9.99mm intervals. (Check the image on the second side at duplex printing.) | Rollers' feed system failure or laser exposure system failure (drum, Laser Scanner) is considered. |

■ 17 gradations (TYPE=2/3)



| Check item | Check method | Assumed cause |
|------------|---|--|
| Gradation | Check whether gradation in density is made appropriately. | Drum failure, laser exposure system failure or developing system failure is considered. |
| Black line | Check whether black lines appear on the image. | Laser light path failure, developing system failure, cleaning (drum) failure or transfer roller failure is considered. |
| White line | Check whether white lines appear on the image. | Developing system failure is considered. |

■ Solid white (TYPE=4)



| Check item | Check method | Assumed cause |
|------------|--|---|
| Fogging | Check whether foggy image appears in the blank area. | Drum failure, laser exposure system failure or developing system failure is considered. |

■ Halftone (TYPE=5/6/11/12/13/14)



NOTE:


When outputting a halftone test print, be sure to use PG TYPE:6 except in the following cases.

1. When checking the image of side registration adjustment, use PG TYPE:11.
2. When the setting value of the following service mode is "2" (TBIC is used for both the photo part and the text part), use PG TYPE:5.

COPIER > OPTION > USER > PH-D-SL2

| Check item | Check method | Assumed cause |
|----------------------------|--|--|
| Transfer failure | Check the evenness of halftone density. Check whether uneven image or foggy image appears. | Transfer system failure or transfer roller failure is considered. |
| Black line | Check whether black lines appear on the image. | Laser light path failure, grid failure, developing system failure, cleaning (drum) failure or transfer roller failure is considered. |
| White line | Check whether white lines appear on the image. | Developing system failure is considered. |
| Uneven pitch | Check whether lines appear on the image in the horizontal scanning direction. | Drum failure, developing system failure, laser exposure system failure or drive-related failure is considered. |
| Uneven density(rear/front) | Check the density difference between the front and rear sides. | Drum failure or developing system failure is considered. |
| Side registration | Check the left margin. | Floor at the installation site is extremely distorted, or the feed system failure is considered. |
| Shock | Check whether horizontal lines appear on the image. | Rollers' feed system failure or laser exposure system failure (drum, Laser Scanner) is considered. |

■ Solid black (TYPE=7)



| Check item | Check method | Assumed cause |
|----------------------------|--|--|
| Transfer failure | Check the evenness of halftone density. Check whether uneven image or foggy image appears. | Transfer system failure is considered. |
| Uneven pitch | Check whether lines appear on the image in the horizontal scanning direction. | Drum failure, developing system failure, laser exposure system failure or drive-related failure is considered. |
| Uneven density(rear/front) | Check the density difference between the front and rear sides. | Drum failure or developing system failure is considered. |

■ Horizontal line (TYPE=8/9/10)




| Check item | Check method | Assumed cause |
|----------------------------|---|--|
| Black line | Check whether black lines appear on the image. | Laser light path failure, developing system failure, cleaning (drum) failure or transfer roller failure is considered. |
| White line | Check whether white lines appear on the image. | Developing system failure is considered. |
| Uneven pitch | Check whether lines appear on the image in the horizontal scanning direction. | Drum failure, developing system failure, laser exposure system failure or drive-related failure is considered. |
| Uneven density(rear/front) | Check the density difference between the front and rear sides. | Drum failure or developing system failure is considered. |

Debug Log

Function Overview

As for debug log, following logs are available: continuous log that saves the operation log, automatic log that is saved when an event occurs, manual log which is collected and saved each time at log saving, packet log, and key operation log.



NOTE:

Debug logs are used for analysis of program operations of the machine and identification of the problem by the developer. This machine has a function for compiling operation history of each software module as debug logs and outputting them as unified logs for analyzing problems. Since the frequency of outputting debug logs and the type of logs can be changed by the settings, the settings need to be changed according to the trouble that occurs and the situation.

Types of Debug Logs

| Types of Debug Logs | Description |
|---------------------|---|
| Sublogs | <p>Manual logs Logs collected in each module and controller are archived and can be collected when log saving is executed. Logs of the Main Controller, RCON, and DCON are saved together with automatic logs as up to 10 logs in total.</p> <p>Automatic logs Logs that are automatically saved to the machine when an event (exceptional behavior, error code, or reboot) occurs. Logs of the Main Controller, RCON, and DCON are saved together with manual logs as up to 10 logs in total.</p> <p>Continuous logs Logs that are continuously saved while the machine is running. Up to 100 logs of only the Main Controller can be stored.</p> |
| Key operation logs | History of key operations. Log collection starts by enabling the setting and starting the function. Logs that are archived and can be collected when log saving is executed. |
| Network packet logs | Logs of network packet data sent from or received by the host machine. Log collection starts by enabling the setting and starting the function. Logs that are archived and can be collected when log saving is executed. |

Storage location and types of Sublogs

The locations where Sublogs are stored and the types of logs are shown below. Logs may be stored in controllers and parts other than those shown below.

| Type | Automatic logs | Manual logs | Continuous logs |
|-----------------|--|--|-----------------|
| Main Controller | Yes (more detailed than continuous logs) | Yes (more detailed than continuous logs) | Yes |
| DCON | Yes | Yes | No |
| RCON | Yes | Yes | No |

Cases Where Debug Logs Need to Be Collected

- When the result of identification of the cause shows that the trouble was caused by the iR-ADV machine (firmware, hardware-related controller)
- When the failure occurs only at the customer's site and cannot be reproduced by the department in charge of quality management or Canon Inc.

■ Sublogs

Sublog is the general term for the unified logs for analyzing problem in which operation histories of software modules are compiled as debug logs.

When a problem relating to the host machine occurs in the field and it is difficult to identify the cause of it at the user site, collecting Sublogs and sending them to Design Dept./R&D can improve the efficiency of analyzing the problem and reduce the time it takes to deal with the problem.

CAUTION:

- Since Sublogs are basically stored in volatile memory, almost all information will be lost by turning OFF and then ON the power. Therefore, be sure to collect logs without turning OFF and then ON the power.
- In order to prevent failure of collecting necessary information because the log is overwritten with the succeeding process, be sure to collect the Sublog while the symptom has occurred or immediately after the occurrence.
- Once the Sublog files are collected, they are deleted from the machine. In the case of collecting Sublogs consecutively, the number of continuous log files may be fewer than usual.

■ Key Operation Logs

The key operation log function is used to collect user's key operation logs in order to distinguish between a host machine failure and a user's operation mistake when, for example, a fax transmission error occurred.

If it cannot be denied the possibility that the user operation caused the error, collect the key operation logs.

Key operation logs are not recorded by default, therefore, the function needs to be enabled.

In order to save key operation logs, configure the setting of the following Settings/Registration menu to ON (enabled).

[Management Settings] > [Device Management] > [Store Key Operation Log]

Only when the foregoing setting is enabled, it is judged that user's permission has been obtained, and user operation logs start to be recorded.

User operation logs are saved together with Sublogs and collected as logs contained in Sublog files.

Among the saved user operation logs, the confidential information shown below is masked.

- Password entered from the software keyboard
- PIN, PIN code, etc. entered from the Numeric Keypad
- Information that is hidden by turned letters on the UI screen

CAUTION:

Be sure to obtain user's permission in advance to record key operation logs for analyzing problems.

NOTE:

- When logs are output, passwords, PIN, and turned letters are masked, and these confidential information never leak out.
- Collect this log when it is determined that analysis of the debug log is required.

■ Network Packet Logs

With this function, network packet data sent from or received by the host machine is collected (captured) in the HDD without the need for special equipment.

When it is expected that the trouble was caused by network, collect network packet logs.

Note that this function is not a standard function because packet data on the network contains customer information.

To use this function, it needs to be activated in the following menu and then enabled in service mode.

[Settings/Registration] > Management Settings > License/Other > Register License

NOTE:

To register a license, it is necessary to request the Support Dept. of the sales company to issue a license.

CAUTION:


When collecting network packet logs using this function, be sure to obtain user's permission in advance by explaining about it.

CAUTION:

In the case of a heavy-load network environment, some of the packets may be left uncollected.

■ Flow of Determining the Procedure for Collecting Logs

Check the following flow to determine the procedure for collecting logs according to the type of problem.



When the user's operation such as wrong fax transmission may be the cause of the problem, enable [Store Key Operation Log].

Procedure for Collecting Logs

Log Collection Procedure List

| Problem Case | Details of Problem | DEBUG SRAM PCB ASS'Y Board | Procedure for Obtaining Logs |
|--------------|---|----------------------------|---|
| Case A | Problem that repeats restart | Necessary | <ol style="list-style-type: none"> 1. Refer to "Preparation" on page 254 and make the preparations such as installing the DEBUG SRAM PCB ASS'Y Board or change the settings. 2. Execute log saving by referring to "Saving of Manual Logs, Network Packet Logs and Key Operation Logs" on page 257 immediately after restart. 3. Save and collect reports by referring to "Saving and Collecting Reports" on page 258. 4. Collect debug logs by referring to "Collection of Log" on page 259. |
| Case B | Problem causing the Control Panel to be locked | Necessary | <ol style="list-style-type: none"> 1. Refer to "Preparation" on page 254 and make the preparations such as installing the DEBUG SRAM PCB ASS'Y Board or change the settings. 2. Turn OFF and then ON the power immediately after the Control Panel is locked. 3. Execute log saving by referring to "Saving of Manual Logs, Network Packet Logs and Key Operation Logs" on page 257 after startup. 4. Save and collect reports by referring to "Saving and Collecting Reports" on page 258. 5. Collect debug logs by referring to "Collection of Log" on page 259. |
| Case C | Problem related to the sleep mode | Necessary | <ol style="list-style-type: none"> 1. Refer to "Preparation" on page 254 and make the preparations such as installing the DEBUG SRAM PCB ASS'Y Board or change the settings. 2. After the problem occurs, turn OFF and then ON the power if necessary, and execute log saving by referring to "Saving of Manual Logs, Network Packet Logs and Key Operation Logs" on page 257. 3. Save and collect reports by referring to "Saving and Collecting Reports" on page 258. 4. Collect debug logs by referring to "Collection of Log" on page 259. |
| Case D | Problem when executing a job (Example: Printing is not performed, etc.) | Not necessary | <ol style="list-style-type: none"> 1. Execute log saving while the problem is occurring by referring to "Saving of Manual Logs, Network Packet Logs and Key Operation Logs" on page 257. 2. Execute log saving by referring to "Saving of Manual Logs, Network Packet Logs and Key Operation Logs" on page 257. 3. Collect debug logs by referring to "Collection of Log" on page 259. |
| | When an E code error has occurred | Not necessary | Execute log saving by referring to "Saving of Manual Logs, Network Packet Logs and Key Operation Logs" on page 257 . However, if the background of the Control Panel is blank and an error code is displayed in text, logs cannot be obtained. |
| Case E | Problems other than above | Not necessary | Execute log saving by referring to "Saving of Manual Logs, Network Packet Logs and Key Operation Logs" on page 257 . Check with the user on the date and time when the problem occurred and the procedure. |

Saving and Collecting Debug Logs

■ Tools Required

The following tools are necessary to save/collect debug logs of the machine.

Exporting to a USB Device

- USB device

When exporting debug logs to a USB device, use a USB device in which the system software for the machine is registered using SST.

Since the size and number of log files to collect varies according to the device status and the logs that have been saved, the size of the collected files may be several hundred MB. Therefore, it is recommended to use a USB device with 1 GB or more of free space.

The USB device must be formatted with the FAT file system.

CAUTION:

Be sure to check that the USB device has 1 GB or more of free space before collecting a log.

If capacity of the USB device is insufficient, logs that failed to be saved will be deleted so that analysis of the symptom cannot be performed.

Exporting to a PC

- PC with SST installed
- Network connection cable

When exporting debug logs to a PC, a PC with SST installed and a network connection cable are required.


Common (When Exporting to a USB Device, or When Exporting to a PC)

- DEBUG SRAM PCB ASS'Y Board

In the following conditions, debug logs cannot be saved, therefore the DEBUG SRAM PCB ASS'Y Board is required.

- When restart is repeated
- When all the operations of the device are frozen and manual logs cannot be collected.
- When the machine would not recover from sleep mode

Refer to the following regarding installation on to the Controller PCB.



Reference example of installation

■ Work Flow

The flow of saving/collecting Sublogs is shown below.

1. Preparation

Refer to “[Flow of Determining the Procedure for Collecting Logs](#)” on page 251, and make the preparation as needed according to a situation where an event has occurred.

2. Reproduction of the symptom

Reproduce the symptom.

3. Saving of manual logs

Save manual logs that require manual operation.

4. Output of reports

Output reports necessary for escalation.

5. Collecting log files

Start the machine in download mode, and save (collect) the log files to a USB device or a PC.

CAUTION:

In the case of analysis using Sublog, the following information needs to be obtained together with the Sublog.

- Symptom that has occurred (from service technician's viewpoint as far as possible)
- Date and time of the event (from an hour before the event to an hour after the event)
- Reports (P-Print, HIST-PRT, job logs, communication management report, etc.)
- Printed data and original at the time of reproduction (depends on the trouble that has occurred)

Besides Sublog, the above-mentioned information is required due to the following reasons:


- Failures such as a process being stopped due to an error or an unintended behavior are easy to find, but failures such as "the behavior is slow" are difficult to analyze based on operation logs only.
- Since the number and size of the files are huge, the information helps to find the operation log where the problem occurred.
- When R&D reproduces the failure, it is necessary to use information such as the procedure used by the customer, frequency of use, and job data at the time of occurrence of the failure.

6. Remove the board installed in step 1 and return the settings back to the original values.

■ Preparation

Follow the procedure shown below to make preparations for collecting debug logs.

1. Refer to **"Flow of Determining the Procedure for Collecting Logs"** on page 251 and when it is judged that **DEBUG SRAM PCB ASS'Y Board** is required, install the board.



2. Refer to **"Flow of Determining the Procedure for Collecting Logs"** on page 251 and when it is judged that collection of the key operation logs is required, enable **[Store Key Operation Log]** by following the procedure shown below.
 1. Select [Settings/Registration] > [Management Settings] > [Device Management] > [Store Key Operation Log].
 2. Select [ON] and press [OK] to start saving key operation logs.

CAUTION:

When collecting the key operation logs, be sure to obtain user's permission in advance.

3. Refer to **“Flow of Determining the Procedure for Collecting Logs”** on page 251 and when it is judged that collection of the network packet logs is required, enable the network packet log collection function by following the procedure shown below and start the function.

1. Enter a license in the following menu to enable network packet capture.
[Settings/Registration] > [Management Settings] > [License/Other] > [Register License]

NOTE:

Use the license issued by the Support Dept. of the sales company to activate it.

2. Enable the setting (ON) in the following menu.
[Settings/Registration] > [Preferences] > [Network] > [Store Network Packet Log]
3. Set "1" in the following service mode (Lv.2).
Service mode > COPIER > TEST > NET-CAP > CAPOFFON
4. Refer to **“Initial setting of the network packet log collection function”** on page 256, and configure the required option settings.
5. Set "0" or "1" in the following service mode (Lv.2) to start capture of network packets.
Service mode > COPIER > TEST > NET-CAP > STT-STP
 - 0: Not automatically collect at startup (factory default setting)
 - 1: Automatically collects at startup
6. Execute the following service mode (Lv.2) to check the status of the capture.
Service mode > COPIER > TEST > NET-CAP > CAPSTATE
The following types of status are displayed.
 - RUNNING: Packets are being captured.
 - STOP: Packet capturing is stopped.
 - HDDFULL: The maximum amount of 1 GB of packets has been captured.

4. When an instruction to change the automatic log settings is given by the Support Dept. of the sales company, change the settings by referring to **“Automatic Log Settings”** on page 255.

• Automatic Log Settings

Automatic log is collected triggered by "occurrence of an unexpected error", "occurrence of an error code" or "restart of the machine".

If you want to change the triggers, change the setting in the following service mode.

COPIER > Function > DBG-LOG > LOG-TRIG

However, there is no need to change the setting unless otherwise instructed by the Support Dept. of the sales company. The events that trigger collection of automatic logs and their setting values are shown below.

List of conditions for automatic saving of logs and setting values

| Setting value | Event condition for saving automatic log |
|-----------------------|---|
| 101 (Default setting) | When an unexpected error occurs, an error code occurs, or the machine is restarted |
| 111 | Only when an unexpected error occurs |
| 121 | Only when an error code occurs |
| 131 | Only when the machine is restarted |
| 201 | When an unexpected error occurs, an error code occurs, the machine is restarted, or an alarm occurs |
| 211 | When an unexpected error occurs or an alarm occurs |
| 221 | When an error code occurs or an alarm occurs |
| 231 | When the machine is restarted or an alarm occurs |
| 291 | Only when an alarm occurs |
| 301 | When an unexpected error occurs, an error code occurs, the machine is restarted, or a jam occurs |
| 311 | When an unexpected error occurs or a jam occurs |
| 321 | When an error code occurs or a jam occurs |
| 331 | When the machine is restarted or a jam occurs |
| 391 | Only when a jam occurs |

The procedure for changing the log auto save conditions with LOG-TRIG is indicated below.

1. Press [LOG-TRIG], enter the value for the conditions you want to set, and press [OK].
"ACTIVE!" flashes in the display column, and the log settings in the machine are changed.
2. When [OK!] is displayed in the display column, the work is complete.
If the processing fails, "NG" is displayed. It is not necessary to restart the device.

NOTE:

- A value between 0 and 99999 can be set, but make sure to set the value instructed by the Support Dept. of your sales company. Operations are not guaranteed when value other than the above is set.
- The displayed setting is not changed simply by changing the setting or pressing [DEFAULT]. It is necessary to exit the DBG-LOG screen once by pressing the [Reset] key, etc. and then display it again, after performing these operations.

Executing Auto Saving (Reference Example)

An example of executing auto saving using LOG-TRIG is shown below so that you can experience the log collection work. It is an example of log collection in the event of jam in the Delivery Assembly during copy operation.

1. Connect a USB device to the machine while the machine is ready for operation.
2. Set "301" in the following service mode (Lv.2).
 - COPIER > Function > DBG-LOG > LOG-TRIG
3. Make a copy. Open the Delivery Feed Assembly before paper is delivered from the Delivery Assembly to generate a jam.
4. When a jam occurs, confirm "Storing System Information..." is displayed at the bottom of the Control Panel.

• Initial setting of the network packet log collection function

When collecting the network packet logs, configure the initial settings as needed.

Setting the overwrite function

1. To enable this function, set "1" in the following service mode (Lv.2).

Service mode > COPIER > TEST > NET-CAP > OVERWRIT

NOTE:

When this setting is enabled, old logs will be overwritten. If the symptom cannot be reproduced, disable this setting (setting value: 0) and secure logs (save them using SST or USB). After securing the logs, enable the setting (setting value: 1) again.

Behavior when HDD reaches the limit

When this setting is enabled (setting value: 1), the following behaviors will occur when the HDD reaches the limit.

- When overwrite setting is ON
 - The oldest packet file is deleted. This "oldest file" is judged not by the date and time allocated to the file but by the last update time of the file.
 - If the HDD reaches the maximum size while retrieving packets, the oldest file will be deleted, and CAPSTATE of the capture, which continues the retrieval process for the file which is being saved, remains "RUNNING".
- When overwrite setting is OFF
 - The capture is stopped.
 - The CAPSTATE of the capture will be "HDDFULL". However, STT-STP will remain as Start (1) status. By changing STT-STP (0) to STTSTP (1), the capture resumes.
 - When the capture resumes, the capture starts if HDDFULL has been solved.
 - The CAPSTATE of the capture will be "RUNNING".
 - If HDDFULL has not been solved, an error is generated as the result of resuming the capture.
 - The CAPSTATE of the capture remains "HDDFULL".
 - If the capture is stopped while the CAPSTATE is "HDDFULL", the CAPSTATE of the capture remains "STOP".

Setting the encryption function

1. To enable this function, set "2" in the following service mode (Lv.2).

COPIER > TEST > NET-CAP > ENCDATA

- 0: Encrypted when data is extracted (factory default setting).
- 1: Not encrypted when data is extracted.
- 2: When data is extracted, a ciphertext file and a plaintext file are extracted.

The extension of extracted packet data will be "XXX.can" when encryption settings are enabled.

The extension of extracted packet data will be "XXX.cap" when encryption settings are disabled.

This setting only applies when extracting data by the USB flash drive.

NOTE:

When SST is used to collect data, both plaintext data and ciphertext data are extracted, and this setting is ignored.

Setting the payload drop function

- To enable this setting, set "1" in the following service mode (Lv.2).


COPIER > TEST > NET-CAP > PAYLOAD

- 0: Not drop the payload (factory default settings)
- 1: Drop the payload

The obtained packet data includes a header part and data part. The header part includes data such as the TCP header and IP header. The data part includes the actual data.

Enabling this function discards the actual payload data and extracts only the data from the header part, which has the following effects.

- Can be used when customer data is not allowed to be extracted
- Can be used in an environment where traffic is highly overloaded



Packet data structure image

Setting the filter function

- To enable this function, set "1" in the following service mode (Lv.2).

COPIER > TEST > NET-CAP > SIMPFILT

- 0: All data is collected without being filtered (factory default setting).
- 1: Data is filtered.

If this function is enabled, only packet data that includes the machine's MAC address in the packet header is captured.

Setting the startup collection function

- To enable this function, set "1" in the following service mode (Lv.2).

COPIER > TEST > NET-CAP > PONSTART

- 0: Not automatically collect at startup (factory default setting)
- 1: Data is filtered.

If this function is enabled, only packet data that includes the machine's MAC address in the packet header is captured.


■ Saving of Manual Logs, Network Packet Logs and Key Operation Logs

Follow the steps shown below to save debug logs (manual logs, network packet logs, and key operation logs) to the save area of the host machine that require manual operation.

- After the symptom has reproduced, hold down the Counter key on the Control Panel for approx. 10 seconds, and then press 1, 2, and 3 in that order on the Numeric Keypad.

CAUTION:

If power is turned OFF during the period from when the symptom occurs to when the manual log is saved (hold down the Counter key and press numeric keys 1, 2, and 3), necessary log data will be deleted so that analysis cannot be performed.




2. Check that "Storing System Information..." is displayed on the Control Panel.

- For platform version 3.7 or later, following screen is displayed.



Save screen for platform version 3.7 or later

- For the platform version 3.6 or earlier, following message is displayed.



Message during saving logs for platform version 3.6 or earlier

CAUTION:

- While logs are being saved, other operations cannot be performed.
- If above screen or message does not appear, press the Reset button and then try again.

NOTE:

When network packet logs have been collected and necessary network packets have been captured, stop the capture from the following menu.

[Settings/Registration] > [Preferences] > [Network] > [Store Network Packet Log]

When this setting is disabled, all the service mode settings configured in step 3 are initialized.


After completion of analysis of the network trouble, be sure to disable the network capture function. It is therefore necessary to disable and then transfer the license, but it is not necessary to transfer the LMS license after that.

■ Saving and Collecting Reports

Follow the procedure shown below to save reports to the HDD in the host machine and collect them using a USB device.


1. Execute the following service mode to save report files to the HDD.

COPIER > Function > MISC-P > RPT-FILE



2. Execute the following service mode with the USB device connected to the host machine to collect the report stored in the HDD into the USB device.

COPIER > Function > MISC-P > RPT2USB



■ Collection of Log

Save the Sublogs stored in the host machine to a USB device or a PC with SST installed.

The procedure for storing Sublogs to a USB device differs from that for storing Sublogs to a PC

● Collecting into a USB Device

To save (collect) Sublogs to a USB device, perform the procedure shown below to collect the logs.

If SST is used to save (collect) Sublogs to a PC, this work is not necessary.

CAUTION:

If the log is stored multiple times to the USB flash drive on the host machine with the platform version 3.6 or earlier, make sure to move the stored log file to a different location each time.

Log files are stored in the root directory of USB flash drive. If multiple files are stored, the file, "LOGLIST.txt" is overwritten. Note that on the host machine with the platform version 3.7 later, specifications are changed and this file is not overwritten.

1. Connect the USB flash drive to the machine.

2. Execute the following service mode.

COPIER > Function > SYSTEM > DOWNLOAD



3. The host machine will enter download mode. Press [8] on the Numeric Keypad.

```

[[[[[[[[ Root Menu (USB <v25.12> ]]]]]]]] (v25.12)
-----
[ 1 ] : Select Version
[ 4 ] : Clear/Format
[ 5 ] : Backup/Restore
[ 8 ] : Download File
[ 9 ] : Version Information
[ Reset ] : Start shutdown sequence
  
```

4. [Download File Menu] will appear. Press a numeric key for the file to download.

```

[[[[[[[[ Download File Menu (USB <v25.12> ]]]]]]]] (v25.12)
-----
[ 1 ] : SUBLOG Download
[ 4 ] : ServicePrint Download
[ 5 ] : NetCap Download
[ C ] : Return to Menu
  
```

- Press [1] key to download Sublog.
- Press [5] to download network packet log.

5. The files to be downloaded and the number of files are displayed. Check the following items and press [0] on the Numeric Keypad.

- Whether the manual log that was saved at the time of reproduction of the symptom is displayed under Event Logs
- Whether the date and time at which the symptom was reproduced is within the period of Continuous Log
Example: When the symptom was reproduced at 9:40 on April 14, 2017 and a manual log was saved
Check that the manual log that was generated at 9:40 on April 14, 2017 is displayed under Event Logs.
Check whether 9:40 on April 14, 2017 is included in the logged period(from 8:03:33 on March 22, 2017 to 9:45:14 April 14, 2017) of the ContinuousLog.

```

[[[[[[[[ Sublog Download (EventLog + ContinuousLog) ]]]]]]]]
-----
Event Logs ( latest 10 files ) :
20170414_09-40-UPN00003-V2512_Debuglog@Cnt123
20170404_16-02-ZZZ00000-V0254_ServiceCall-E719-0001
20170328_08-22-ZZZ00000-V0254_exception

ContinuousLog :
Period : 20170322_0803-33 to 20170414_0945-14

Total : 102files
/ Execute ? /
-(OK) : 0 / (CANCEL) : Any other keys -
  
```

Automatic (event) log / manual log:
Check that the manual logs that have been saved when the symptom occurs.

Continuous log:
Check that the date and time at which the symptom occurred are included within the collection period of continuous logs.

6. When downloading the log files is complete, the following message will appear. Press any key.

--- Please press any keys ---

```
[68/102]20170405_0949-57-ZZZ00000-2512-clog.bin
[69/102]20170405_0908-19-ZZZ00000-2512-clog.bin
[70/102]20170404_1822-52-ZZZ00000-2512-clog.bin
[71/102]20170404_1702-57-ZZZ00000-2512-clog.bin

[97/102]20170322_1324-37-ZZZ00000-2512-clog.bin
[98/102]20170322_1204-56-ZZZ00000-2512-clog.bin
[99/102]20170322_1102-52-ZZZ00000-2512-clog.bin
[100/102]20170322_0954-48-ZZZ00000-2512-clog.bin
[101/102]20170322_0848-16-ZZZ00000-2512-clog.bin
[102/102]20170322_0803-33-ZZZ00000-2512-clog.bin
Sub log full Download OK.
---Please press any keys---
```


Do not turn OFF the power without.....

● **Saving to a PC with SST installed**


Follow the procedure shown below to save (collect) Sublogs to a PC using SST.

If a USB device is used to save (collect) Sublogs, this work is not necessary.

1. Connect a PC with SST installed to the network where the host machine is connected.
2. Start SST, and select the model name of the machine from Model List. Press the Start button.




3. Click [Upload Data].



4. Check that continuous logs are stored in the device.

When connection with the device is completed, the screen shown below will appear. Select [Upload Data].


The set of data stored in the device is shown on the right. Click "+" at "Log" to expand the tree, and check that there are continuous logs (date_model number_clog.bin).




5. Select the data to upload, and click [Start].

Select the check box on the left of "Log", and click the "Start" button.

It is not necessary to select MeapBack.bin and SramImg.bin because they are not necessary for analysis.



6. Enter a file name (arbitrary), and click the SAVE button to save the file to the PC.



• Checking the Saved Files

NOTE:


If log files are stored in the USB flash drive, the path to the storage destination is different by the platform version.

Platform version prior to 3.7

They are stored in the root directory of USB flash drive.

Platform version 3.7 or later

Folders of "iA_sublog" and "model name + serial number + date (year, month, day + hour, minute, second)" are automatically created in the root directory of USB flash drive and files are stored in the latter folder.



Sublog files

Check the saved log files whether the necessary log has been collected.

- Whether it is a log file of the target model (It contains the serial number of the target machine.)
- Whether the time and date the symptom occurred is included in the logged period. (Date and time in the log file name represent those of when the log collection is started. There are files with dates before the symptom occurs.)

Storage locations of log files

Storage locations of log files are shown below.

When using USB device: Root folder of the USB device


When using SST: PC's C:\ServData\\serial number folder

How to check the continuous log files

The continuous log files are stored in the log file storage location.

Check the names (date and time) of the files that end with "clog.bin" to see whether the date and time the symptom was reproduced is included.

In the case of the following figure, the oldest continuous log is 08:03:33 on March 22, 2017 and the latest file is 08:43:44 on April 14, 2017. The date and time the symptom was reproduced should be included within the period.



20161013_1733-36_ZZZ99999_1406_clog.bin

Data and time when a file was archived (year, month, day, hour, minute, second). Serial Number Firmware Version Identification indicating that it is a continuous log

File name of continuous log

How to check the manual log files and automatic (event) log files

The manual log files and automatic (event) log files are stored in the log file storage location. At the time of collection, these logs will be archived as a one binary file (the name of the file ends with "_SAFE.bin").

20161013_19-34-ZZZ99999-V1406_SAFE.bin


YYYYMMDD_HH-MM Serial Number Firmware Version

Which logs have been stored in this binary file is described in LOGLIST.TXT stored in the log file storage location. Open this file to check the manual logs and automatic (event) logs.

CAUTION:

If a manual log was saved when the symptom was reproduced, check that a log with the date and time immediately after the reproduction is included.

If there is no log file collected immediately after the symptom was reproduced, the file may have been overwritten and lost.



20161013_10-10_ZZZ99999_V 1308_Debuglog@Cnt123

Data and time when key operation was performed (year, month, day, hour, minute, second). Serial Number Firmware Version Identification indicating that a key operation was performed

File name of manual log

20161012_14-48_ZZZ99999_V1406_Fatal00-exception

Data and time when an even occurred (year, month, day, hour, minute, second) Serial Number Firmware Version Cause of occurrence

20161012_14-48_ZZZ99999_V1406_ServiceCall-E719-0031

Data and time when an even occurred (year, month, day, hour, minute, second) Serial Number Firmware Version Cause of occurrence

File name of automatic log

How to check the network packet log files

The network packet log file is stored in the "NC + date" folder created in the log file storage location.


Open the folder and check that two types of files have been saved: a plaintext file which file name starts with "NC" and ends with ".cap", and a ciphertext file which file name starts with "NC" and ends with ".can".

| Name | Date modified | Type |
|------------------|--------------------|----------|
| NC0110041155.can | 1/22/2015 11:34 AM | CAN File |
| NC0110041155.cap | 1/22/2015 11:34 AM | CAP File |
| NC0110044539.can | 1/22/2015 11:34 AM | CAN File |
| NC0110044539.cap | 1/22/2015 11:34 AM | CAP File |
| NC0110051028.can | 1/22/2015 11:34 AM | CAN File |
| NC0110051028.cap | 1/22/2015 11:34 AM | CAP File |
| NC0110051243.can | 1/22/2015 11:34 AM | CAN File |
| NC0110051243.cap | 1/22/2015 11:34 AM | CAP File |
| NC0110053134.can | 1/22/2015 11:34 AM | CAN File |
| NC0110053134.cap | 1/22/2015 11:34 AM | CAP File |
| NC1222190910.can | 1/22/2015 11:34 AM | CAN File |
| NC1222190910.cap | 1/22/2015 11:34 AM | CAP File |
| NC1226153347.can | 1/22/2015 11:34 AM | CAN File |
| NC1226153347.cap | 1/22/2015 11:34 AM | CAP File |

Report files

Report files saved to the USB device are stored in the folder under the name shown below where the firmware is stored.

- [Serial No.] > SP [Date (year, month, day, hour, minute (12 digits))] L



Service Mode Relating to Debug Logs

Although the procedure for collecting debug logs of this equipment is as indicated above, there are other service modes related to debug logs.

Use the following service modes (Lv.2) as needed.

- COPIER > Function > DBG-LOG > HIT-STS
- COPIER > Function > DBG-LOG > DEFAULT
- COPIER > Function > DBG-LOG > LOG-DEL

NOTE:

If log collection is continued or setting change is repeated when an abnormality is found in operation of the function related to debug logs, temporary files or log files may be remained in the machine. In that case, execute "DEFAULT" in service mode to clear the settings related to debug logs and repeat the operation again.

Confirming the Existence of Debug Logs (HIT-STS)

This service mode confirms whether debug logs exist in the auto save area.

"OK!" is displayed if logs exist in the auto save area.

NOTE:

"OK!" is displayed even after pressing the Counter key + numeric keys 1, 2, and 3.

Initializing the Debug Log Settings (DEFAULT)

This service mode changes all the settings related to debug logs back to the default (settings at the time of shipment).

- Be sure to perform when returning the device to the customer after completion of trouble investigation. (Operations required)
- Execute this service mode when resetting the settings related to debug logs during investigation of log collection and perform the operation again.

However, note that the log files automatically saved to the debug log save area in the controller are kept within the range not exceeding the upper limit.

If you want to delete the saved logs (want to use HIT-STS), use "LOG-DEL" indicated later.

Deleting the Automatically Saved Log Files (LOG-DEL)

This service mode deletes the automatically saved and stored log files. The settings of log operation such as trigger for saving log are not cleared.

Although it is not used normally (the upper limit of the number of saved logs is automatically controlled by firmware), it is necessary to delete logs with LOG-DEL once when judging whether logs are collected using HIT-STS after changing the trigger for saving log.

(It is because OK is displayed in HIT-STS as long as the saved logs exist.)



Error/Jam/Alarm

| | |
|-----------------------|-----|
| Overview..... | 268 |
| Error Code..... | 271 |
| Error Code (FAX)..... | 324 |
| Alarm Code..... | 327 |
| Jam Code..... | 336 |

Overview

This section describes the error codes that are displayed when failure has occurred. The codes are divided into three categories.

| Code types | Description | Reference |
|-------------|--|--------------------------|
| Error Codes | This code is displayed when a failure caused by the host machine has occurred. | "Error Code" on page 271 |
| Jam code | This code is displayed when a jam occurs inside the machine. | "Jam Code" on page 336 |
| Alarm code | This code is displayed when some functions are disabled. | "Alarm Code" on page 327 |

Display of error codes

The 7-digit "E000XXX" error code is displayed on the display of the Control Panel. However, since "000" of the 2nd to 4th digits is not used, the 5th to 7th digits are described as "EXXX" in the Service Manual. (Example: E012 -> E000012)

Location Code

The error codes, jam codes, and alarm codes of this machine contain information on the location.

The location is displayed in 2 digits and has the meaning shown below: (In the jam display screen, the "L" row corresponds to the location code.)

| Device | JAM | ERR | ALARM |
|--|-----|---|------------------------|
| Host machine | 00 | Main Controller: 00 Printer engine: 05 | Other than those below |
| Reader/ADF | 01 | 04 | 02, 50 |
| Cassette Module-AG1 | 00 | 05 | 04 |
| Envelope Cassette Module-A1 | 00 | 05 | 04 |
| Cassette Feeding Unit-AR1 | 00 | 05 | 04 |
| High Capacity Cassette Feeding Unit-D1 | 00 | 05 | 04 |
| Inner Finisher | 02 | 02 | 61 |
| FAX Board | - | 07 | - |

Pickup Position Code

When jam occurs, pickup location is indicated with the following pickup position code. (In the jam display screen, the "P" row corresponds to the pickup position code.)

| Pickup position | Pickup position code |
|---|----------------------|
| At Finisher jam/At error avoidance jam/At ADF jam without pickup operation (at SEND, BOX, etc.) | 00 |
| Cassette 1 | 01 |
| Cassette 2 | 02 |
| Cassette 3 | 03 |
| Cassette 4 | 04 |
| Multi-purpose Tray Pickup Assembly | 05 |
| Duplex (At duplex printing, jam occurs after paper passes through the Duplex Feed Sensor.) | F0 |

Pickup size

When a jam occurs, a paper size is displayed. (The row displaying "SIZE" on the jam screen refers to the paper size.)

Due to the limitation of displayable number of characters, some paper size names are omitted. The following is the list of displayed row of texts and corresponding paper sizes.

* The following is based on the display specification and not all paper sizes can actually be used.

| Display | Paper Size | Display | Paper Size |
|---------|------------|---------|-----------------|
| A0 | A0 | LDR | LEDGER |
| A1 | A1 | LDRFB | LEDGERFULLBLEED |

| Display | Paper Size | Display | Paper Size |
|---------|-----------------|----------|-----------------------|
| A2 | A2 | LGL | LEGAL |
| A3 | A3 | LTR | LETTER |
| A3FB | A3FULLBLEED | EXE | EXECUTIVE |
| A4 | A4 | STMT | STATEMENT |
| A5 | A5 | 10x8 | 10x8 |
| A6 | A6 | 12x18 | 12x18 |
| A7 | A7 | 13x19 | 13x19 |
| I-B0 | ISOB0 | 15x11 | 15x11 |
| I-B1 | ISOB1 | 17x22 | 17x22 |
| I-B2 | ISOB2 | 18x24 | 18x24 |
| I-B3 | ISOB3 | A-FLS | Australian-FOOLSCAP |
| I-B4 | ISOB4 | ALGL | Argentina-LEGAL |
| I-B5 | ISOB5 | ALTR | Argentina-LETTER |
| I-B6 | ISOB6 | OFI | OFICIO |
| I-B7 | ISOB7 | A-OFI | Argentina-OFICIO |
| I-C0 | ISOC0 | B-OFI | Bolivia-OFICIO |
| I-C1 | ISOC1 | E-OFI | Ecuador-OFICIO |
| I-C2 | ISOC2 | M-OFI | Mexico-OFICIO |
| I-C3 | ISOC3 | KLGL | Korea-LEGAL |
| I-C4 | ISOC4 | GLGL | Government-LEGAL |
| I-C5 | ISOC5 | GLTR | Government-LETTER |
| I-C6 | ISOC6 | IND-LGL | India-LEGAL |
| I-C7 | ISOC7 | COM10 | COM10 |
| I-SRA3 | SRA3 | DL | DL |
| J-B0 | JISB0 | E_C2 | Nagagata 2 |
| J-B1 | JISB1 | E_C3 | Nagagata 3 |
| J-B2 | JISB2 | E_C4 | Nagagata 4 |
| J-B3 | JISB3 | E_C5 | Nagagata 5 |
| J-B4 | JISB4 | E-K2 | Kakugata 2 |
| J-B5 | JISB5 | E_K3 | Kakugata 3 |
| J-B6 | JISB6 | E_K4 | Kakugata 4 |
| J-B7 | JISB7 | E_K5 | Kakugata 5 |
| K16 | K16 | E_K6 | Kakugata 6 |
| K8 | K8 | E_K7 | Kakugata 7 |
| ND-PCD | Newdry Postcard | E_K8 | Kakugata 8 |
| OTHER | OTHER | E_Y1 | Yougata 1 |
| PCARD | Postcard | E-Y2 | Yougata 2 |
| PCARD4 | 4 on 1 Postcard | E_Y3 | Yougata 3 |
| F4A | F4A | E-Y4 | Yougata 4 |
| F4B | F4B | E_Y5 | Yougata 5 |
| FLSC | FOOLCAP | E_Y6 | Yougata 6 |
| FOLIO | FLIO | E_Y7 | Yougata 7 |
| FREE | FREE SIZE | EVLP_YN3 | Yougatanaga 3 |
| ICARD | INDEXCARD | E-B5 | B5 Envelope |
| USER | Custom | E-C5 | C5 Envelope |
| | | MONA | MONARCH |
| | | EVLP | Unknown size envelope |

Points to Note When Clearing MN-CON

- Execution of clearing MN-COM deletes all data in Address Book, Forwarding Settings, Settings/Registration (Adjustment/Maintenance, Function Settings, Set Destination, Management Settings, TPM Settings), etc. Before execution of this operation, ask user to back up the data and get approval for this operation.

- Clearing MN-CON will clear the service mode setting values. Be sure to enter the service mode setting values again in accordance with the configuration of the options of the host machine and requests from the user.
- When clearing MN-CON while any login application other than User Authentication is, error such as not displayed login screen occurred. In this case, access SMS once and switch login application to User Authentication to recover to the normal status.

Points to Note When Clearing HDD

As a remedy for error codes (E602-XXXX, E611-0000), HDD partition is selected and the target partition may be cleared. When clearing partition, be sure to check which data will be deleted by referring Detail of HDD partition1-26 and explain to the user before starting work.

Error Code

Error Code Details

| | |
|------------------------------|---|
| E000-0001-05 | Fixing Assembly: Temperature rise failure |
| Detection Description | The Fixing Assembly does not reach the specified temperature within the specified time after cold starting. |
| Remedy | <p>[Related parts]</p> <ul style="list-style-type: none"> - Fixing Assembly - Harness between the DC Controller PCB and the Drawer Connector - DC Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts. [Reference] This symptom may occur also when the device is used in an environment where room temperature is too low.</p> |
| E001-0001-05 | Fixing Assembly: Abnormally high temperature 1 |
| Detection Description | The Main Thermistor temperature raise to more than the specified level. |
| Remedy | <p>[Related parts]</p> <ul style="list-style-type: none"> - Fixing Assembly - Harness between the DC Controller PCB and the Drawer Connector - DC Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> |
| E001-0002-05 | Fixing Assembly: Abnormally high temperature 2 |
| Detection Description | The Sub Thermistor 1 temperature raise to more than the specified level. |
| Remedy | <p>[Related parts]</p> <ul style="list-style-type: none"> - Fixing Assembly - Harness between the DC Controller PCB and the Drawer Connector - DC Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> |
| E001-0004-05 | Fixing Assembly: Abnormally high temperature 3 |
| Detection Description | The Sub Thermistor 2 temperature raise to more than the specified level. |
| Remedy | <p>[Related parts]</p> <ul style="list-style-type: none"> - Fixing Assembly - Harness between the DC Controller PCB and the Drawer Connector - DC Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> |
| E003-0001-05 | Fixing Assembly: Abnormally low temperature |
| Detection Description | The Main Thermistor temperature remained lower than the specified level. |
| Remedy | <p>[Related parts]</p> <ul style="list-style-type: none"> - Fixing Assembly - Harness between the DC Controller PCB and the Drawer Connector - DC Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> |
| E004-0001-05 | Drive Circuit Unit error |
| Detection Description | Drive Circuit Unit error |
| Remedy | <p>[Related parts]</p> <ul style="list-style-type: none"> - Fixing Assembly - Harness between the DC Controller PCB and the Drawer Connector - DC Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> |

| | |
|------------------------------|--|
| E004-0004-05 | Mismatching Fixing Type |
| Detection Description | - "Fixing Assembly Absence" was detected as a result of the Fixing Assembly Connection Determination - The temperature of the Main Thermistor and the Sub Thermistor was lower than the specified level. |
| Remedy | [Related parts] - Fixing Assembly - Harness between the DC Controller PCB and the Drawer Connector - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E004-0005-05 | Low Voltage Power Supply Unit |
| Detection Description | When an error occurred in the communication with the effective value detection IC. |
| Remedy | [Related parts] - Low Voltage Power Supply PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E012-0001-05 | Drum Motor startup error |
| Detection Description | The startup of Drum Motor does not complete within the specified period of time after start. |
| Remedy | [Related parts] - Drum Motor (M2) - Harness between the Drum Motor and the DC Controller PCB - DC Controller PCB - Main Drive Unit [Remedy] Check/replace the related harness/cable, connector and parts. |
| E012-0002-05 | Drum Motor Rotation error |
| Detection Description | The number of rotations of the Drum Motor decreased to less than the specified value during operation. |
| Remedy | [Related parts] - Drum Motor (M2) - Harness between the Drum Motor and the DC Controller PCB - DC Controller PCB - Main Drive Unit [Remedy] Check/replace the related harness/cable, connector and parts. |
| E014-0001-05 | Fixing Motor startup error |
| Detection Description | The startup of the Fixing Motor does not complete within the specified period of time after start. |
| Remedy | [Related parts] - Fixing Motor (M1) - Harness between the Fixing Motor and the DC Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E014-0002-05 | Fixing Motor rotation error |
| Detection Description | The number of rotations of the Fixing Motor decreased to less than the specified value during operation. |
| Remedy | [Related parts] - Fixing Motor (M1) - Harness between the Fixing Motor and the DC Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |

| E015-0001-05 | Cassette 1 Lifter Motor error |
|------------------------------|---|
| Detection Description | The paper surface could not be detected by the Paper Surface Sensor after the Lifter Motor was driven. |
| Remedy | <p>[Related parts]</p> <ul style="list-style-type: none"> - Cassette 1 Lifter Motor (M3) - DC Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> <ol style="list-style-type: none"> 1. Remove the paper in the cassette and open/close the cassette. 2. Check the operation of the Lifter Motor in light of whether the Paper Level Lever can be lowered. <ol style="list-style-type: none"> a. When the motor is operated: <ol style="list-style-type: none"> 1. Check the installation condition of the Cassette 1 Paper Surface Sensor (PS4400) 2. Check the harness/connector between the DC Controller PCB (J14) and the Cassette 1 Paper Surface Sensor (PS4400/J4400) 3. Check the Cassette 1 Paper Surface Sensor (PS4400) 4. Replace the DC Controller PCB b. When the motor is not operated, take the following steps: <ol style="list-style-type: none"> 1. Check the harness/connector between the DC Controller PCB (J301) and the Cassette 1 Lifter Motor (M3) 2. Check the condition of the gear on the side of the host machine (if there is any cut or if it swings) 3. Replace the Cassette 1 Lifter Motor (M3) 4. Replace the DC Controller PCB |
| E015-0002-05 | Cassette 2 Lifter Motor error |
| Detection Description | The paper surface could not be detected by the Paper Surface Sensor after the Lifter Motor was driven. |
| Remedy | <p>[Related parts]</p> <ul style="list-style-type: none"> - Cassette 2 Lifter Motor - DC Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> <ol style="list-style-type: none"> 1. Remove the paper in the cassette and open/close the cassette. 2. Check the operation of the Lifter Motor in light of whether the Paper Level Lever can be lowered. <ol style="list-style-type: none"> a. When the motor is operated: <ol style="list-style-type: none"> 1. Check the installation condition of the Cassette 2 Paper Surface Sensor 2. Check the harness/connector between the DC Controller PCB and the Cassette 2 Paper Surface Sensor 3. Check the Cassette 2 Paper Surface Sensor 4. Replace the DC Controller PCB b. When the motor is not operated, take the following steps: <ol style="list-style-type: none"> 1. Check the harness/connector between the DC Controller PCB (J301) and the Cassette 2 Lifter Motor 2. Check the condition of the gear on the side of the host machine (if there is any cut or if it swings) 3. Replace the Cassette 2 Lifter Motor 4. Replace the DC Controller PCB |

| | |
|------------------------------|---|
| E015-0003-05 | Cassette 3 Lifter Motor error |
| Detection Description | The paper surface could not be detected by the Paper Surface Sensor after the Lifter Motor was driven. |
| Remedy | <p>[Related parts]</p> <ul style="list-style-type: none"> - Cassette 3 Lifter Motor - DC Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> <ol style="list-style-type: none"> 1. Remove the paper in the cassette and open/close the cassette. 2. Check the operation of the Lifter Motor in light of whether the Paper Level Lever can be lowered. <ol style="list-style-type: none"> a. When the motor is operated: <ol style="list-style-type: none"> 1. Check the installation condition of the Cassette 3 Paper Surface Sensor 2. Check the harness/connector between the DC Controller PCB and the Cassette 3 Paper Surface Sensor 3. Check the Cassette 3 Paper Surface Sensor 4. Replace the DC Controller PCB b. When the motor is not operated, take the following steps: <ol style="list-style-type: none"> 1. Check the harness/connector between the DC Controller PCB (J301) and the Cassette 3 Lifter Motor 2. Check the condition of the gear on the side of the host machine (if there is any cut or if it swings) 3. Replace the Cassette 3 Lifter Motor 4. Replace the DC Controller PCB |
| E015-0004-05 | Cassette 4 Lifter Motor error |
| Detection Description | The paper surface could not be detected by the Paper Surface Sensor after the Lifter Motor was driven. |
| Remedy | <p>[Related parts]</p> <ul style="list-style-type: none"> - Cassette 4 Lifter Motor - DC Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> <ol style="list-style-type: none"> 1. Remove the paper in the cassette and open/close the cassette. 2. Check the operation of the Lifter Motor in light of whether the Paper Level Lever can be lowered. <ol style="list-style-type: none"> a. When the motor is operated: <ol style="list-style-type: none"> 1. Check the installation condition of the Cassette 4 Paper Surface Sensor 2. Check the harness/connector between the DC Controller PCB and the Cassette 4 Paper Surface Sensor 3. Check the Cassette 4 Paper Surface Sensor 4. Replace the DC Controller PCB b. When the motor is not operated, take the following steps: <ol style="list-style-type: none"> 1. Check the harness/connector between the DC Controller PCB (J301) and the Cassette 4 Lifter Motor 2. Check the condition of the gear on the side of the host machine (if there is any cut or if it swings) 3. Replace the Cassette 4 Lifter Motor 4. Replace the DC Controller PCB |
| E020-04C0-05 | Detection of Cartridge Shipping Lock |
| Detection Description | A shipping lock was detected during the detection of presence/absence of cartridge. |
| Remedy | <p>[Related parts]</p> <ul style="list-style-type: none"> - Toner cartridge <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> <ol style="list-style-type: none"> 1. Remove the shipping lock of the toner cartridge. 2. Replace the toner cartridge. |
| E021-0001-05 | Drum Motor error |
| Detection Description | No changes are made in the Developing Disengagement Sensor within the specified period of time after the operation of the Developing Disengagement Solenoid. |
| Remedy | <p>[Related parts]</p> <ul style="list-style-type: none"> - Drum Motor (M2) - Developing Disengagement Solenoid (SL2) - Toner cartridge <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> |

| | |
|------------------------------|---|
| E066-0001-05 | Environment Sensor Abnormal Warning |
| Detection Description | When the Environment Sensor detects an AD value of 0 to 60 or 220 to 225 |
| Remedy | [Related parts] - Environment Sensor (TH4200) |
| E100-0004-05 | Laser Scanner error |
| Detection Description | The light intensity settings to the Laser Driver failed. |
| Remedy | [Related parts] - Laser Scanner Unit - Harness between the Laser Scanner Unit and the DC Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E110-0001-05 | Laser Scanner Motor startup error |
| Detection Description | The startup of the Laser Scanner Motor does not complete. |
| Remedy | [Related parts] - Laser Scanner Unit - Harness between the Laser Scanner Unit and the DC Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E110-0002-05 | Laser Scanner Motor rotation error |
| Detection Description | A BD Detection error occurs during the operation of the Laser Scanner Motor. |
| Remedy | [Related parts] - Laser Scanner Unit - Harness between the Laser Scanner Unit and the DC Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E196-0001-05 | Main ROM Write/Read error |
| Detection Description | A Main ROM Write/Read error occurs at startup. |
| Remedy | [Related parts] - DC Controller PCB [Remedy] 1. Install firmware 2. Check/replace the related harness/cable, connector and parts. |
| E196-0002-05 | Option ROM Write/Read error |
| Detection Description | An Option ROM Write/Read error occurs at startup. |
| Remedy | [Related parts] - Harness between the DC Controller PCB and the Finisher Controller PCB - Harness between the DC Controller PCB and the OP Cassette Controller PCB - Finisher Controller PCB - OP Cassette Controller PCB - DC Controller PCB [Remedy] 1. Install firmware 2. Check/replace the related harness/cable, connector and parts. |
| E197-0001-05 | Internal communication error |
| Detection Description | A communication error occurred between CPU and ASIC. |
| Remedy | [Related parts] - Laser Scanner Unit - Harness between the Laser Scanner Unit and the DC Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E197-0002-05 | Engine Firmware Error |
| Detection Description | An engine firmware different from this product was detected. |
| Remedy | Installation of a proper PW. |

| | |
|------------------------------|--|
| E202-0001-04 | Scanner Unit HP error |
| Detection Description | The HP of the Scanner Unit could not be detected when starting scanning operation. |
| Remedy | <p>[Related parts] R1.00</p> <ul style="list-style-type: none"> - Harness between the CIS HP Sensor (J4205) and the Main Controller PCB (UN81/J4005) - Harness between the Reader Motor (J4305) and the Main Controller PCB (UN81/J4005) - Harness between the Main Controller PCB (J4507) and the Low-voltage Power Supply PCB - CIS HP Sensor - Reader Motor - Low-voltage Power Supply PCB (UN01) - Reader Assembly - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. At initial operation of the Reader startup after the main power is turned ON, check if the Reader Motor operates (whether the Scanner Unit moves or operation sound is heard). If it operates, check whether load on the Timing Belt for moving CIS is appropriate. <ol style="list-style-type: none"> a. If it is appropriate, replace the CIS HP Sensor. b. If it is not appropriate (overloaded), check/replace the Timing Belt, Drive Gear and pulley. 2. Check/replace the CIS Holder (soiling or damage on the surface). 3. Check/replace the related harness/cable, connector and parts. |
| E202-0002-04 | Scanner Unit HP error |
| Detection Description | The HP of the Scanner Unit could not be detected when completing scanning operation. |
| Remedy | <p>[Related parts] R1.00</p> <ul style="list-style-type: none"> - Harness between the CIS HP Sensor (J4205) and the Main Controller PCB (UN81/J4005) - Harness between the Reader Motor (J4305) and the Main Controller PCB (UN81/J4005) - Harness between the Main Controller PCB (J4507) and the Low-voltage Power Supply PCB - CIS HP Sensor - Reader Motor - Low-voltage Power Supply PCB (UN01) - Reader Assembly - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. At initial operation of the Reader startup after the main power is turned ON, check if the Reader Motor operates (whether the Scanner Unit moves or operation sound is heard). If it operates, check whether load on the Timing Belt for moving CIS is appropriate. <ol style="list-style-type: none"> a. If it is appropriate, replace the CIS HP Sensor. b. If it is not appropriate (overloaded), check/replace the Timing Belt, Drive Gear and pulley. 2. Check/replace the CIS Holder (soiling or damage on the surface). 3. Check/replace the related harness/cable, connector and parts. |
| E227-0001-04 | Power supply error |
| Detection Description | The Main Controller PCB did not detect 24 V when the main power was turned ON. |
| Remedy | <p>[Related parts]</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB (J4507) and the Low-voltage Power Supply PCB - Low-voltage Power Supply PCB (UN01) - Main Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> |
| E246-0001-00 | System error |
| Detection Description | System error |
| Remedy | Contact the service company office |
| E246-0002-00 | System error |
| Detection Description | System error |
| Remedy | Contact to the sales company. |
| E246-0003-00 | System error |
| Detection Description | System error |
| Remedy | Contact to the sales company. |

| | |
|------------------------------|--|
| E246-0005-00 | System error |
| Detection Description | System error |
| Remedy | Contact to the sales company. |
| E247-0001-00 | System error |
| Detection Description | System error |
| Remedy | Contact the service company office |
| E247-0002-00 | System error |
| Detection Description | System error |
| Remedy | Contact to the sales company. |
| E247-0003-00 | System error |
| Detection Description | System error |
| Remedy | Contact to the sales company. |
| E247-0004-00 | System error |
| Detection Description | System error |
| Remedy | Contact to the sales company. |
| E248-0001-04 | Reader backup error |
| Detection Description | Reading error was detected when the Controller IC of the Main Controller PCB read the Reader backup value in the Flash PCB. |
| Remedy | [Related parts] R1.00 - Flash PCB (UN91) - Main Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. After performing the remedy, enter the value of the service label again. 1. After executing "COPIER> FUNCTION> CLEAR> R-CON", turn OFF and then ON the main power, and check whether the error is cleared. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 3. Replace the Main Controller PCB. |
| E248-0002-04 | Reader backup error |
| Detection Description | The Controller IC of the Main Controller PCB failed to rewrite the Reader backup value in the Flash PCB. |
| Remedy | [Related parts] R1.00 - Flash PCB (UN91) - Main Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. After performing the remedy, enter the value of the service label again. 1. After executing "COPIER> FUNCTION> CLEAR> R-CON", turn OFF and then ON the main power, and check whether the error is cleared. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 3. Replace the Main Controller PCB. |
| E280-0001-04 | Scanner Unit communication error |
| Detection Description | Communication between the Main Controller and the Scanner Unit (front) was not started within the specified period of time. |
| Remedy | [Related parts] R1.00 - Harness between the Scanner Unit (front) and the Main Controller PCB - Scanner Unit (front) - Main Controller PCB [Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally. |

| | |
|------------------------------|--|
| E280-0002-04 | Scanner Unit communication error |
| Detection Description | Disconnection of FFC between the Main Controller and the Scanner Unit (front) was detected. |
| Remedy | [Related parts] R1.00 - Harness between the Scanner Unit (front) and the Main Controller PCB - Scanner Unit (front) - Main Controller PCB [Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally. |
| E280-0101-04 | Scanner Unit communication error |
| Detection Description | Communication between the Main Controller and the Scanner Unit (back) was not started within the specified period of time. |
| Remedy | [Related parts] R1.00 - Harness between the Scanner Unit (back) and the Main Controller PCB - Scanner Unit (back) - ADF UNIT - Main Controller PCB [Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally. |
| E280-0102-04 | Scanner Unit communication error |
| Detection Description | Disconnection of FFC between the Main Controller and the Scanner Unit (back) was detected. |
| Remedy | [Related parts] R1.00 - Harness between the Scanner Unit (back) and the Main Controller PCB - Scanner Unit (back) - ADF UNIT - Main Controller PCB [Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally. |
| E302-0001-04 | Error in paper front white shading |
| Detection Description | An error in the shading value was detected at white shading. |
| Remedy | [Related parts] R1.00 - Harness between the Scanner Unit (front) and the Main Controller PCB - Scanner Unit (front) - Main Controller PCB [Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally. |
| E302-0002-04 | Error in paper front black shading |
| Detection Description | An error in the shading value was detected at black shading. |
| Remedy | [Related parts] R1.00 - Harness between the Scanner Unit (front) and the Main Controller PCB - Scanner Unit (front) - Main Controller PCB [Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally. |
| E302-0003-04 | Error in paper front shading |
| Detection Description | Image sampling for shading was not completed. |
| Remedy | [Related parts] R1.00 - Harness between the Scanner Unit (front) and the Main Controller PCB - Scanner Unit (front) - Main Controller PCB [Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally. |

| | |
|------------------------------|---|
| E302-0101-04 | Error in paper back white shading |
| Detection Description | An error in the shading value was detected at white shading. |
| Remedy | [Related parts] R1.00 - Harness between the Scanner Unit (back) and the Main Controller PCB - Scanner Unit (back) - ADF UNIT - Main Controller PCB [Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally. |
| E302-0102-04 | Error in paper back black shading |
| Detection Description | An error in the shading value was detected at black shading. |
| Remedy | [Related parts] R1.00 - Harness between the Scanner Unit (back) and the Main Controller PCB - Scanner Unit (back) - ADF UNIT - Main Controller PCB [Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally. |
| E302-0103-04 | Error in paper back shading |
| Detection Description | Image sampling for shading was not completed. |
| Remedy | [Related parts] R1.00 - Harness between the Scanner Unit (back) and the Main Controller PCB - Scanner Unit (back) - ADF UNIT - Main Controller PCB [Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally. |
| E315-0007-00 | Image process device timeout error |
| Detection Description | Image compression process was not completed within the specified period of time (120 sec) at scanning. |
| Remedy | [Related parts] - Harness between the CIS Unit and Main Controller PCB - Main Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. 1. Reinstall the latest system software using SST or a USB flash drive. 2. Check/replace the related harness/cable, connector and parts. |
| E315-000D-00 | Image process device timeout error |
| Detection Description | Processing of a JBIG-compressed data was not completed within the specified period of time (120 sec) at printing or SEND. |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. Reinstall the latest system software using SST or a USB flash drive. 2. Check/replace the Main Controller PCB. |
| E315-000F-00 | Image process device timeout error |
| Detection Description | Duplication of image data in the memory was not completed within the specified period of time (120 sec). |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. Reinstall the latest system software using SST or a USB flash drive. 2. Check/replace the Main Controller PCB. |
| E315-0027-00 | Image process device timeout error |
| Detection Description | Image processing (change in magnification ratio, rotating, and shifting) was not completed normally within the specified period of time (120 sec). |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. Reinstall the latest system software using SST or a USB flash drive. 2. Check/replace the Main Controller PCB. |

| | |
|------------------------------|---|
| E315-0033-00 | Image process device timeout error |
| Detection Description | Processing to clear image data in the memory was not completed normally within the specified period of time (120 sec). |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. Reinstall the latest system software using SST or a USB flash drive. 2. Check/replace the Main Controller PCB. |
| E315-0035-00 | Image process device timeout error |
| Detection Description | Processing to clear image data in the memory was not completed normally within the specified period of time (120 sec). |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. Reinstall the latest system software using SST or a USB flash drive. 2. Check/replace the Main Controller PCB. |
| E315-0500-00 | Image process device timeout error |
| Detection Description | Transfer of image signal was not completed within the specified period of time (120 sec) at scanning. |
| Remedy | [Related parts] - Harness between the CIS Unit and Main Controller PCB - Main Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. 1. Reinstall the latest system software using SST or a USB flash drive. 2. Check/replace the related harness/cable, connector and parts. |
| E315-0510-00 | Image process device timeout error |
| Detection Description | Image processing was not completed within the specified period of time (30 sec) at scanning. |
| Remedy | [Related parts] - Harness between the CIS Unit and Main Controller PCB - Main Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. 1. Reinstall the latest system software using SST or a USB flash drive. 2. Check/replace the related harness/cable, connector and parts. |
| E315-0520-00 | Image process device timeout error |
| Detection Description | Image processing was not completed within the specified period of time (120 sec) at scanning. |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. Reinstall the latest system software using SST or a USB flash drive. 2. Check/replace the Main Controller PCB. |
| E315-0530-00 | Image process device error |
| Detection Description | Compression processing of the scanned image into JPEG was terminated abnormally. |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. Reinstall the latest system software using SST or a USB flash drive. 2. Check/replace the Main Controller PCB. |
| E315-0531-00 | Image process device timeout error |
| Detection Description | Compression processing of the scanned image into JPEG was not completed within the specified period of time (120 sec). |
| Remedy | [Related parts] - Harness between the Reader Controller PCB and Main Controller PCB - Main Controller PCB - Reader Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. 1. Reinstall the latest system software using SST or a USB flash drive. 2. Check/replace the related harness/cable, connector and parts. |

| | |
|------------------------------|---|
| E315-0540-00 | Image process device error |
| Detection Description | An error occurred during decompression of JPEG. |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. Reinstall the latest system software using SST or a USB flash drive. 2. Check/replace the Main Controller PCB. |
| E315-0541-00 | Image process device timeout error |
| Detection Description | Decompression of JPEG was not completed within the specified period of time (120 sec). |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. Reinstall the latest system software using SST or a USB flash drive. 2. Check/replace the Main Controller PCB. |
| E315-0561-00 | Image process device timeout error |
| Detection Description | Image transfer was not completed within the specified period of time (60 sec) after the start of printing. |
| Remedy | [Related parts] - Harness between the Reader Controller PCB and Main Controller PCB - Main Controller PCB - Reader Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. 1. Reinstall the latest system software using SST or a USB flash drive. 2. Check/replace the related harness/cable, connector and parts. |
| E350-0000-00 | System error |
| Detection Description | System error |
| Remedy | Contact the service company office |
| E350-0001-00 | System error |
| Detection Description | System error |
| Remedy | Contact to the sales company. |
| E350-0002-00 | System error |
| Detection Description | System error |
| Remedy | Contact to the sales company. |
| E350-0003-00 | System error |
| Detection Description | System error |
| Remedy | Contact to the sales company. |
| E350-3000-00 | System error |
| Detection Description | System error |
| Remedy | Contact to the sales company. |
| E351-0000-00 | System error |
| Detection Description | Main Controller PCB communication error. |
| Remedy | Check/replace the Main Controller PCB |
| E354-0001-00 | System error |
| Detection Description | System error |
| Remedy | Contact the service company office |
| E354-0002-00 | System error |
| Detection Description | System error |
| Remedy | Contact to the sales company. |
| E355-0001-00 | System error |
| Detection Description | System error |
| Remedy | Contact the service company office |

| | |
|------------------------------|---|
| E355-0002-00 | System error |
| Detection Description | System error |
| Remedy | Contact to the sales company. |
| E355-0003-00 | System error |
| Detection Description | System error |
| Remedy | Contact to the sales company. |
| E355-0004-00 | System error |
| Detection Description | System error |
| Remedy | Contact to the sales company. |
| E412-0005-04 | Fan error |
| Detection Description | Stop of fan was detected after rotation signal for the ADF Cooling Fan was transmitted. |
| Remedy | [Related parts] R1.00 - ADF Cooling Fan - Main Controller PCB [Remedy] Check/replace the related parts. |
| E412-0006-04 | Fan error |
| Detection Description | Rotation of fan was detected after the stop signal for the ADF Cooling Fan was transmitted. |
| Remedy | [Related parts] R1.00 - ADF Cooling Fan - Main Controller PCB [Remedy] Check/replace the related parts. |
| E423-0001-04 | ADF error |
| Detection Description | An access error to SDRAM for controlling ADF that is installed on the Main Controller PCB was detected. |
| Remedy | Check/replace the Main Controller PCB |
| E503-0062-02 | Internal communication error |
| Detection Description | CAN-CPU detected an internal communication error. |
| Remedy | [Related parts] - Finisher Controller PCB - Harness between the DC Controller PCB and the Finisher Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E530-8001-02 | Jogger failure |
| Detection Description | A change of the Jogger HP Sensor cannot be detected after the start of jogger control. |
| Remedy | [Related parts] - Jogger Unit - Finisher Controller PCB - Harness between the Finisher Controller PCB and the DC Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E531-8001-02 | Staple Ready error |
| Detection Description | The Staple Unit does not turn to the "Ready" state. |
| Remedy | [Related parts] - Jogger Unit - Finisher Controller PCB - Harness between the Finisher Controller PCB and the DC Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |

| | |
|------------------------------|--|
| E531-8002-02 | Staple failure |
| Detection Description | The Staple Unit does not return to the HP within the specified period of time from the operation start of the Staple Motor. |
| Remedy | [Related parts] - Jogger Unit - Finisher Controller PCB - Harness between the Finisher Controller PCB and the DC Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E540-8001-02 | Bin 1 Upper Limit Detection error |
| Detection Description | The Bin 1 Upper Limit Sensor does not react within the specified period of time after start of lift-up. |
| Remedy | [Related parts] - Delivery Lifter Unit - Finisher Controller PCB - Harness between the Finisher Controller PCB and the DC Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E540-8002-02 | Bin 1 Lower Limit Detection error |
| Detection Description | The Bin 1 Lower Limit Sensor does not react even after the specified period of time after start of lift-up. |
| Remedy | [Related parts] - Delivery Lifter Unit - Finisher Controller PCB - Harness between the Finisher Controller PCB and the DC Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E540-8003-02 | Bin 1 Lifter Sensor failure |
| Detection Description | Both the Bin 1 Upper Limit Sensor and the Bin 1 Lower Limit Sensor detected ON during tray initialization. |
| Remedy | [Related parts] - Delivery Lifter Unit - Finisher Controller PCB - Harness between the Finisher Controller PCB and the DC Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E551-8001-02 | Finisher Fan failure |
| Detection Description | Finisher Fan Lock is detected. |
| Remedy | [Related parts] - Jogger Unit - Finisher Controller PCB - Harness between the Finisher Controller PCB and the DC Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E568-8001-02 | Stack Delivery Roller disengagement failure |
| Detection Description | When Y Alignment Motor is operated, the Stack Delivery Roller HP Sensor does not change. |
| Remedy | [Related parts] - Upper Feed Unit - Finisher Controller PCB - Harness between the Finisher Controller PCB and the DC Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |

| | |
|------------------------------|--|
| E577-8001-02 | Y Alignment Motor failure |
| Detection Description | When Y Alignment Motor is operated, the Y Alignment Motor HP Sensor does not change. |
| Remedy | <p>[Related parts]</p> <ul style="list-style-type: none"> - Upper Feed Unit - Finisher Controller PCB - Harness between the Finisher Controller PCB and the DC Controller PCB - DC Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> |
| E602-0001-00 | HDD error |
| Detection Description | <p>HDD failed to be Ready, or HDD was not formatted.</p> <p>When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 3. Reinstall the system software using SST or a USB flash drive. 4. Check/replace the related parts. |
| E602-0020-00 | HDD error |
| Detection Description | Corruption of database managing user mode/service mode data was detected. |
| Remedy | <p>While this error occurs, backup of the setting values is disabled.</p> <p>In addition, it may not be recorded in the error log.</p> <p>Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. Turn OFF and then ON the main power. 2. Enter safe mode using (2+8) startup, and format the HDD using a USB flash drive. 3. Replace the HDD. |
| E602-0101-00 | HDD error |
| Detection Description | <p>An error was detected in the PDL-related file storage area. (Initialization failed at startup or I/O error at startup)</p> <p>When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "1", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "1", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| E602-0111-00 | HDD error |
|------------------------------|--|
| Detection Description | An error was detected in the PDL-related file storage area. (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "1", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "1", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-0201-00 | HDD error |
| Detection Description | <p>An error was detected in the storage area of image data after startup. (Initialization failed at startup or I/O error at startup)</p> <p>When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "2", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "2", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| E602-0211-00 | HDD error |
|------------------------------|--|
| Detection Description | An error was detected in the storage area of image data after startup. (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "2", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "2", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-0301-00 | HDD error |
| Detection Description | <p>An error was detected in the MEAP-related area. (Initialization failed at startup or I/O error at startup)</p> <p>When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "3", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "3", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| E602-0311-00 | HDD error |
|------------------------------|--|
| Detection Description | An error was detected in the MEAP-related area. (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "3", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "3", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-0401-00 | HDD error |
| Detection Description | Logical partition error was detected. (Initialization failed at startup or I/O error at startup) When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "4", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "4", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to the error, enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| E602-0411-00 | HDD error |
|------------------------------|--|
| Detection Description | Logical partition error was detected. (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "4", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "4", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to the error, enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-0501-00 | HDD error |
| Detection Description | <p>An error was detected in the storage area of image data after startup. (Initialization failed at startup or I/O error at startup)</p> <p>When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "5", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "5", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| E602-0511-00 | HDD error |
|------------------------------|--|
| Detection Description | An error was detected in the storage area of image data after startup. (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "5", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "5", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-0601-00 | HDD error |
| Detection Description | <p>An error was detected in the storage area of image data after startup. (Initialization failed at startup or I/O error at startup)</p> <p>When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "6", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "6", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| E602-0611-00 | HDD error |
|------------------------------|--|
| Detection Description | An error was detected in the storage area of image data after startup. (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "6", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "6", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-0701-00 | HDD error |
| Detection Description | <p>An error was detected in general application temporary area (temporary file). (Initialization failed at startup or I/O error at startup)</p> <p>When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "7", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "7", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| E602-0711-00 | HDD error |
|------------------------------|--|
| Detection Description | An error was detected in general application temporary area (temporary file). (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "7", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "7", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-0801-00 | HDD error |
| Detection Description | <p>An error was detected in the general application-related area. (Initialization failed at startup or I/O error at startup)</p> <p>When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "8", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "8", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| E602-0811-00 | HDD error |
|------------------------------|---|
| Detection Description | An error was detected in the general application-related area. (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p data-bbox="443 237 675 268">[Related parts] R2.00</p> <ul data-bbox="443 271 1061 360" style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p data-bbox="443 362 1471 430">[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p data-bbox="443 432 1471 488">Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol data-bbox="443 490 1471 801" style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "8", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "8", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p data-bbox="443 804 1471 875">[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-0901-00 | HDD error |
| Detection Description | <p data-bbox="443 940 1471 996">An error was detected in PDL spool data (temporary file). (Initialization failed at startup or I/O error at startup)</p> <p data-bbox="443 999 1471 1061">When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p data-bbox="443 1068 675 1099">[Related parts] R2.00</p> <ul data-bbox="443 1102 1061 1191" style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p data-bbox="443 1193 1471 1261">[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p data-bbox="443 1263 1471 1319">Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol data-bbox="443 1321 1471 1632" style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "9", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "9", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p data-bbox="443 1635 1471 1704">[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| E602-0911-00 | HDD error |
|------------------------------|---|
| Detection Description | An error was detected in PDL spool data (temporary file). (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p data-bbox="443 237 675 268">[Related parts] R2.00</p> <ul data-bbox="443 271 1062 360" style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p data-bbox="443 362 1469 430">[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p data-bbox="443 432 1469 488">Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol data-bbox="443 490 1469 779" style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "9", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "9", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p data-bbox="443 808 1469 875">[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-1001-00 | HDD error |
| Detection Description | <p data-bbox="443 940 1469 996">An error was detected in the SEND-related area. (Initialization failed at startup or I/O error at startup)</p> <p data-bbox="443 999 1469 1061">When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p data-bbox="443 1068 675 1099">[Related parts] R2.00</p> <ul data-bbox="443 1102 1062 1191" style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p data-bbox="443 1193 1469 1261">[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p data-bbox="443 1263 1469 1319">Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol data-bbox="443 1321 1469 1610" style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "10", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "10", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p data-bbox="443 1639 1469 1706">[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| E602-1011-00 | HDD error |
|------------------------------|---|
| Detection Description | An error was detected in the SEND-related area. (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p data-bbox="443 237 675 268">[Related parts] R2.00</p> <ul data-bbox="443 271 1061 360" style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p data-bbox="443 362 1471 430">[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p data-bbox="443 432 1471 488">Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol data-bbox="443 490 1471 779" style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "10", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "10", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p data-bbox="443 808 1471 875">[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-1101-00 | HDD error |
| Detection Description | <p data-bbox="443 940 1471 996">An error was detected in the update-related area. (Initialization failed at startup or I/O error at startup)</p> <p data-bbox="443 999 1471 1061">When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p data-bbox="443 1068 675 1099">[Related parts] R2.00</p> <ul data-bbox="443 1102 1061 1191" style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p data-bbox="443 1193 1471 1261">[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p data-bbox="443 1263 1471 1319">Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol data-bbox="443 1321 1471 1610" style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "11", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "11", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p data-bbox="443 1639 1471 1706">[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| E602-1111-00 | HDD error |
|------------------------------|---|
| Detection Description | An error was detected in the update-related area. (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p data-bbox="443 237 671 268">[Related parts] R2.00</p> <ul data-bbox="443 271 1059 360" style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p data-bbox="443 362 1469 430">[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p data-bbox="443 432 1469 488">Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol data-bbox="443 490 1469 779" style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "11", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "11", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p data-bbox="443 808 1469 875">[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-1201-00 | HDD error |
| Detection Description | <p data-bbox="443 940 1469 996">An error was detected in the license-related area. (Initialization failed at startup or I/O error at startup)</p> <p data-bbox="443 999 1469 1061">When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p data-bbox="443 1068 671 1099">[Related parts] R2.00</p> <ul data-bbox="443 1102 1059 1191" style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p data-bbox="443 1193 1469 1261">[Remedy] Perform the following in the order while checking whether the error is cleared. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 5.</p> <ol data-bbox="443 1263 1469 1518" style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Turn OFF and then ON the main power, and check whether the error is cleared. 3. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "12", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 4. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 5. Enter safe mode using (2+8) startup, and format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p data-bbox="443 1520 1469 1576">[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| | |
|------------------------------|---|
| E602-1211-00 | HDD error |
| Detection Description | An error was detected in the license-related area. (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 5.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Turn OFF and then ON the main power, and check whether the error is cleared. 3. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "12", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 4. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 5. Enter safe mode using (2+8) startup, and format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-1301-00 | HDD error |
| Detection Description | An error was detected in the system area. (Initialization failed at startup or I/O error at startup) When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 5.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Turn OFF and then ON the main power, and check whether the error is cleared. 3. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "13", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 4. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 5. Enter safe mode using (2+8) startup, and format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-1311-00 | HDD error |
| Detection Description | An error was detected in the system area. (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 5.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Turn OFF and then ON the main power, and check whether the error is cleared. 3. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "13", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 4. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 5. Enter safe mode using (2+8) startup, and format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| | |
|------------------------------|--|
| E602-1371-00 | System verification error |
| Detection Description | At startup, a verification error occurred due to invalid data of a MEAP login application. |
| Remedy | <p>[Remedy]</p> <ol style="list-style-type: none"> 1. Set the following service mode setting value to 1: COPIIER > OPTION > USER > MEAPSAFE 2. Turn OFF and then ON the main power. 3. Reinstall the corresponding MEAP application from RUI. <p>[Caution]</p> <p>After performing the remedy work, return the MEAPSAFE value to 0 and turn OFF and then ON the main power.</p> |
| E602-1401-00 | HDD error |
| Detection Description | <p>An error was detected in SWAP (temporary file/alternative memory area). (Initialization failed at startup or I/O error at startup)</p> <p>When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "14", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "14", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-1411-00 | HDD error |
| Detection Description | An error was detected in SWAP (temporary file/alternative memory area). (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "14", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "14", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| E602-1701-00 | HDD error |
|------------------------------|---|
| Detection Description | An error was detected in the debug log area. (Initialization failed at startup or I/O error at startup) When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "17", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "17", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. Enter safe mode using (2+8) startup, and format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-1711-00 | HDD error |
| Detection Description | An error was detected in the debug log area. (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "17", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "17", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| E602-1801-00 | HDD error |
|------------------------------|---|
| Detection Description | <p>An error was detected in the image data storage area in Advanced Box. (Initialization failed at startup or I/O error at startup)</p> <p>When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "18", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "18", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. Enter safe mode using (2+8) startup, and format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-1811-00 | HDD error |
| Detection Description | <p>An error was detected in the image data storage area in Advanced Box. (File could not be written in the HDD after startup or I/O error after startup)</p> |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "18", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "18", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. Enter safe mode using (2+8) startup, and format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| | |
|------------------------------|---|
| E602-1901-00 | HDD error |
| Detection Description | An error was detected in the storage area of data for printing. (Initialization failed at startup or I/O error at startup) When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "19", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "19", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. Enter safe mode using (2+8) startup, and format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-1911-00 | HDD error |
| Detection Description | An error was detected in the storage area of data for printing. (File could not be written in the HDD after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "19", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "19", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. If the above-mentioned service mode cannot be executed due to an error, etc., enter safe mode using (2+8) startup. Then format the HDD using SST or a USB flash drive. 6. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E602-2000-00 | HDD error |
| Detection Description | I/O error was detected in the file system after startup. |
| Remedy | <p>Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. Check that the HDD optional board is properly installed. 2. Turn ON the main power, and check whether the error is cleared. 3. Execute the key clear using SST (to make an unformatted disk). <p>[CAUTION] E602-0001 will be indicated if activating the machine with the unformatted disk. Therefore, be sure to format the HDD.</p> <ol style="list-style-type: none"> 4. Enter safe mode using (2+8) startup, and format the HDD using SST or a USB flash drive. |

| | |
|------------------------------|--|
| E602-2001-00 | HDD error |
| Detection Description | Mismatch on encryption operation |
| Remedy | <p>Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. Check that the Main Controller PCB is installed properly. 2. Turn ON the main power, and check whether the error is cleared. 3. Execute the key clear using SST (to make an unformatted disk). <p>[CAUTION] E602-0001 will be indicated if activating the machine with the unformatted disk. Therefore, be sure to format the HDD.</p> <ol style="list-style-type: none"> 4. Enter safe mode using (2+8) startup, and format the HDD using SST or a USB flash drive. |
| E602-2002-00 | HDD error |
| Detection Description | Failure of encryption board and others |
| Remedy | <p>Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. Turn ON the main power, and check whether the error is cleared. 2. Execute the key clear using SST (to make an unformatted disk). <p>[CAUTION] E602-0001 will be indicated if activating the machine with the unformatted disk. Therefore, be sure to format the HDD.</p> <ol style="list-style-type: none"> 3. Enter safe mode using (2+8) startup, and format the HDD using SST or a USB flash drive. 4. Replace the Main Controller PCB. |
| E602-5001-00 | Encryption Chip error |
| Detection Description | Error of the encryption chip on the Main Controller |
| Remedy | <p>[Related parts] Main Controller PCB [Remedy] Replace the Main Controller PCB</p> |
| E602-5002-00 | HDD error |
| Detection Description | A non-genuine HDD was detected. |
| Remedy | <ol style="list-style-type: none"> 1. Replace the HDD with a genuine one. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> <ol style="list-style-type: none"> 2. Format the HDD using SST or a USB flash drive. |
| E602-FF01-00 | HDD error |
| Detection Description | <p>An unidentified HDD error was detected at startup.</p> <p>When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p>[Related parts] R2.00 - Main Controller PCB - HDD</p> <p>[Reference] For backup and restoration, refer to "Appendix> Backup Data List" in the System Service Manual.</p> <p>[Remedy] Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Format the HDD using SST or a USB flash drive. 3. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |

| | |
|------------------------------|---|
| E602-FF11-00 | HDD error |
| Detection Description | An unidentified HDD error was detected after startup. |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Main Controller PCB - HDD <p>[Reference] For backup and restoration, refer to "Appendix> Backup Data List" in the System Service Manual.</p> <p>[Remedy] Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Format the HDD using SST or a USB flash drive. 3. Check/replace the related parts. <p>[Reference] When replacing the HDD, back up the setting values by referring to "Chapter 5. Adjustment> Actions when Replacing the Parts> HDD" in the Service Manual.</p> |
| E604-0512-00 | Faulty/insufficient image memory (Main Controller PCB1) |
| Detection Description | No necessary memory at Main Controller PCB 1 |
| Remedy | Make the Memory capacity at Main Controller PCB 1 as indicated by 0512. |
| E604-1024-00 | Faulty/insufficient image memory (Main Controller PCB1) |
| Detection Description | No necessary memory at Main Controller PCB 1 |
| Remedy | Make the Memory capacity at Main Controller PCB 1 as indicated by 1024. |
| E604-1536-00 | Faulty/insufficient image memory (Main Controller PCB1) |
| Detection Description | No necessary memory at Main Controller PCB 1 |
| Remedy | Make the Memory capacity at Main Controller PCB 1 as indicated by 1536. |
| E613-0512-00 | Faulty/insufficient image memory |
| Detection Description | No necessary memory at Main Controller PCB |
| Remedy | Make the Memory capacity at Main Controller PC as indicated by 0512. |
| E613-1024-00 | Faulty/insufficient image memory |
| Detection Description | No necessary memory at Main Controller PCB |
| Remedy | Make the Memory capacity at Main Controller PCB as indicated by 1024. |
| E613-1536-00 | Faulty/insufficient image memory |
| Detection Description | No necessary memory at Main Controller PCB |
| Remedy | Make the Memory capacity at Main Controller PCB as indicated by 1536. |
| E613-2048-00 | Memory error |
| Detection Description | Memory of the Main Controller PCB is faulty. |
| Remedy | Make the Memory capacity at Main Controller PCB as indicated by 2048. |
| E614-0001-00 | Flash PCB error |
| Detection Description | The Flash PCB could not be recognized, or the Flash PCB was not formatted. |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Flash PCB - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared.</p> <ul style="list-style-type: none"> - Reinstall the necessary application software once the error is cleared. <ol style="list-style-type: none"> 1. After turning OFF the main power, remove and then install the Flash PCB again to check that it is installed properly. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 3. Replace the Main Controller PCB. |

| | |
|------------------------------|---|
| E614-0002-00 | Error in system on the Flash PCB |
| Detection Description | The file system could not be initialized normally at startup. When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | [Related parts] R2.00 - Flash PCB - Main Controller PCB [Reference] For backup and restoration, refer to "Appendix> Backup Data List" in the System Service Manual. [Remedy] Perform the following in the order while checking whether the error is cleared. - Reinstall the necessary application software once the error is cleared. 1. After turning OFF the main power, remove and then install the Flash PCB to check that it is installed properly. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 3. Replace the Main Controller PCB. |
| E614-0006-00 | Error in system on the Flash PCB |
| Detection Description | Bootable was not found on the Flash PCB. |
| Remedy | [Related parts] R2.00 - Flash PCB - Main Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. - Reinstall the necessary application software once the error is cleared. 1. After turning OFF the main power, remove and then install the Flash PCB again to check that it is installed properly. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 3. Replace the Main Controller PCB. |
| E614-0071-00 | System verification error |
| Detection Description | At normal startup, an error may occur due to invalid data of the firmware for startup. When this error occurs, the system has not been started normally. Therefore, it is not recorded in the error log. |
| Remedy | [Related parts] - Flash PCB [Remedy] Perform the following in the order while checking whether the error is cleared. 1. Start the machine in safe mode, and reinstall the system using SST or a USB flash drive. * [2]: Select Update (Overwrite all) to update the system. 2. Replace the FLASH PCB, and reinstall the system software using SST or a USB flash drive. |
| E614-0072-00 | System verification error |
| Detection Description | At normal startup, an error may occur due to invalid data of the firmware for safe mode startup. When this error occurs, the system has not been started normally. Therefore, it is not recorded in the error log. |
| Remedy | [Related parts] - Flash PCB [Remedy] 1. Replace the Flash PCB and reinstall the system using SST or a USB flash drive. |
| E614-0073-00 | System verification error |
| Detection Description | At startup in safe mode, an error may occur due to invalid data of the startup firmware. When this error occurs, the system has not been started normally. Therefore, it is not recorded in the error log. |
| Remedy | [Related parts] - Flash PCB [Remedy] 1. Replace the Flash PCB and reinstall the system using SST or a USB flash drive. |

| | |
|------------------------------|---|
| E614-0074-00 | Start system verification function error |
| Detection Description | At startup in safe mode, an error may occur due to invalid data of the firmware for safe mode startup. When this error occurs, the system has not been started normally. Therefore, it is not recorded in the error log. |
| Remedy | [Related parts] - Flash PCB [Remedy] 1. Replace the Flash PCB and reinstall the system using SST or a USB flash drive. |
| E614-0101-00 | Error in system on the Flash PCB |
| Detection Description | An error was detected in the system area. (Initialization failed at startup or I/O error at startup) When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | [Related parts] R2.00 - Flash PCB - Main Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4. 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "0", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 5. Replace the Main Controller PCB. |
| E614-0111-00 | Error in system on the Flash PCB |
| Detection Description | An error was detected in the system area. (File could not be written in the Flash PCB after startup or I/O error after startup) |
| Remedy | [Related parts] R2.00 - Flash PCB - Main Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4. 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "0", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 5. Replace the Main Controller PCB. |
| E614-0201-00 | Error in system on the Flash PCB |
| Detection Description | An error was detected in the system area. (Initialization failed at startup or I/O error at startup) When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | [Related parts] R2.00 - Flash PCB - Main Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4. 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "0", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 5. Replace the Main Controller PCB. |

| | |
|------------------------------|---|
| E614-0211-00 | Error in system on the Flash PCB |
| Detection Description | An error was detected in the system area. (File could not be written in the Flash PCB after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Flash PCB - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "0", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 5. Replace the Main Controller PCB. |
| E614-0301-00 | Error in system on the Flash PCB |
| Detection Description | An error was detected in the system area. (Initialization failed at startup or I/O error at startup) When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Flash PCB - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "0", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 5. Replace the Main Controller PCB. |
| E614-0311-00 | Error in system on the Flash PCB |
| Detection Description | An error was detected in the system area. (File could not be written in the Flash PCB after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Flash PCB - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "0", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 5. Replace the Main Controller PCB. |
| E614-0401-00 | Error in system on the Flash PCB |
| Detection Description | Logical partition error was detected. (Initialization failed at startup or I/O error at startup) When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Flash PCB - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 3. Replace the Main Controller PCB. |

| | |
|------------------------------|---|
| E614-0411-00 | Error in system on the Flash PCB |
| Detection Description | Logical partition error was detected. (File could not be written in the Flash PCB after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Flash PCB - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 3. Replace the Main Controller PCB. |
| E614-0501-00 | Error in file system on the Flash PCB |
| Detection Description | <p>An error was detected in the general application-related area. (Initialization failed at startup or I/O error at startup)</p> <p>When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Flash PCB - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "8", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "8", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. Enter safe mode using (2+8) startup, and reinstall the system software using SST or a USB flash drive. 6. Check/replace the related parts. |
| E614-0511-00 | Error in file system on the Flash PCB |
| Detection Description | An error was detected in the general application-related area. (File could not be written in the Flash PCB after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Flash PCB - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "8", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "8", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. Enter safe mode using (2+8) startup, and reinstall the system software using SST or a USB flash drive. 6. Check/replace the related parts. |

| | |
|------------------------------|--|
| E614-0601-00 | Error in system on the Flash PCB |
| Detection Description | An error was detected in the license-related area. (Initialization failed at startup or I/O error at startup) When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | [Related parts] R2.00 - Flash PCB - Main Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. 1. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 3. Replace the Main Controller PCB. |
| E614-0611-00 | Error in system on the Flash PCB |
| Detection Description | An error was detected in the license-related area. (File could not be written in the Flash PCB after startup or I/O error after startup) |
| Remedy | [Related parts] R2.00 - Flash PCB - Main Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. 1. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 3. Replace the Main Controller PCB. |
| E614-0701-00 | Error in file system on the Flash PCB |
| Detection Description | An error was detected in system setting value (service mode, etc.) storage area. (Initialization failed at startup or I/O error at startup) When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | [Related parts] R2.00 - Flash PCB - Main Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4. 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "8", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "8", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. Check/replace the related parts. |

| | |
|------------------------------|--|
| E614-0711-00 | Error in file system on the Flash PCB |
| Detection Description | An error was detected in system setting value (service mode, etc.) storage area. (File could not be written in the Flash PCB after startup or I/O error after startup) |
| Remedy | <p>[Related parts] R2.00</p> <ul style="list-style-type: none"> - Flash PCB - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared. When prioritizing clearing of the error, skip Remedies 2 and 3.</p> <p>Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 4.</p> <ol style="list-style-type: none"> 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "8", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "8", and execute "HD-CLEAR". Then, turn OFF and then ON the main power to delete the data in the corresponding partition. 5. Check/replace the related parts. |
| E614-4000-00 | Error in system on the Flash PCB |
| Detection Description | <p>The OS could not be recognized.</p> <p>When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p>Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. After turning OFF the main power, remove and then install the Flash PCB again to check that it is installed properly. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 3. Check that the HDD and the cables are properly installed. 4. Enter safe mode using (2+8) startup, and format the HDD using SST or a USB flash drive. 5. If another error occurs, clear the error by performing the remedy for it. 6. Replace the Main Controller PCB. |
| E614-4001-00 | Error in system on the Flash PCB |
| Detection Description | <p>The OS boot file was not found.</p> <p>When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p>Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. After turning OFF the main power, remove and then install the Flash PCB again to check that it is installed properly. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 3. Check that the HDD and the cables are properly installed. 4. Enter safe mode using (2+8) startup, and format the HDD using SST or a USB flash drive. 5. If another error occurs, clear the error by performing the remedy for it. 6. Replace the Main Controller PCB. |
| E614-4002-00 | Error in system on the Flash PCB |
| Detection Description | <p>The OS kernel was not found.</p> <p>When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log.</p> |
| Remedy | <p>Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. After turning OFF the main power, remove and then install the Flash PCB again to check that it is installed properly. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 3. Check that the HDD and the cables are properly installed. 4. Enter safe mode using (2+8) startup, and format the HDD using SST or a USB flash drive. 5. If another error occurs, clear the error by performing the remedy for it. 6. Replace the Main Controller PCB. |

| | |
|------------------------------|---|
| E614-4003-00 | Error in system on the Flash PCB |
| Detection Description | The OS boot loader was not found. When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. After turning OFF the main power, remove and then install the Flash PCB again to check that it is installed properly. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 3. Check that the HDD and the cables are properly installed. 4. Enter safe mode using (2+8) startup, and format the HDD using SST or a USB flash drive. 5. If another error occurs, clear the error by performing the remedy for it. 6. Replace the Main Controller PCB. |
| E614-4010-00 | Error in system on the Flash PCB |
| Detection Description | The OS in safe mode could not be recognized. When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. After turning OFF the main power, remove and then install the Flash PCB again to check that it is installed properly. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. |
| E614-4011-00 | Error in system on the Flash PCB |
| Detection Description | The file for booting the OS in safe mode was not found. When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. After turning OFF the main power, remove and then install the Flash PCB again to check that it is installed properly. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. |
| E614-4012-00 | Error in system on the Flash PCB |
| Detection Description | The kernel in safe mode was not found. When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. After turning OFF the main power, remove and then install the Flash PCB again to check that it is installed properly. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. |
| E614-9000-00 | Error in system on the Flash PCB |
| Detection Description | SRAM device access-related error (at startup) When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. After turning OFF the main power, remove and then install the Flash PCB again to check that it is installed properly. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. |
| E614-9001-00 | Error in system on the Flash PCB |
| Detection Description | Error in memory allocation/invalid memory (at startup) When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. After turning OFF the main power, remove and then install the Flash PCB again to check that it is installed properly. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. |

| | |
|------------------------------|---|
| E614-9002-00 | Error in system on the Flash PCB |
| Detection Description | Setting file error was detected at startup. When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. After turning OFF the main power, remove and then install the Flash PCB again to check that it is installed properly. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. |
| E614-9003-00 | Error in system on the Flash PCB |
| Detection Description | Parameter error was detected at startup. When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. After turning OFF the main power, remove and then install the Flash PCB again to check that it is installed properly. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. |
| E614-9004-00 | Error in system on the Flash PCB |
| Detection Description | Startup error was detected. When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. After turning OFF the main power, remove and then install the Flash PCB again to check that it is installed properly. 2. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. |
| E614-FF01-00 | Error in system on the Flash PCB |
| Detection Description | An unidentified Flash error was detected at startup. (Initialization failed at startup or I/O error at startup) When this error occurs, the system has not been started normally. Therefore, it may not be recorded in the error log. |
| Remedy | [Related parts] R2.00 - Flash PCB - Main Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 5. 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "0", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 5. Replace the Main Controller PCB. |
| E614-FF11-00 | Error in system on the Flash PCB |
| Detection Description | An unidentified Flash error was detected at startup. (File could not be written in the Flash PCB after startup or I/O error after startup) |
| Remedy | [Related parts] R2.00 - Flash PCB - Main Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. Although the error is cleared by "HD-CHECK", it may occur again. Thus, perform Remedies 1 to 5. 1. Check the related harness/cable and connector. 2. Select COPIER> FUNCTION> SYSTEM> CHK-TYPE> "0", and execute "HD-CHECK". Then, turn OFF and then ON the main power. 3. Obtain the necessary backup data by referring to "Appendix> Backup Data List" in the System Service Manual. 4. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 5. Replace the Main Controller PCB. |

| | |
|------------------------------|---|
| E615-0001-00 | Error in self-diagnosis of the encryption module |
| Detection Description | An error was detected in self-diagnosis of the encryption library. |
| Remedy | <p>[Remedy] Perform the following in the order while checking whether the error is cleared.</p> <ul style="list-style-type: none"> - Reinstall the necessary application software and restore the backup data once the error is cleared. <ol style="list-style-type: none"> 1. After reinstalling the system software using SST or a USB memory, turn OFF and then ON the main power. 2. Obtain the necessary backup data by referring to the backup data list. 3. Enter safe mode using (2+8) startup, and execute [4] Clear/Format> [2] Flash Format (Flash format) using a USB memory. 4. After replacing the Flash PCB, reinstall the system software using SST or a USB memory. <p>[Reference] For backup and restoration, refer to "Adjustment> Main Controller System" and "Appendix> Backup Data List" in the Service Manual.</p> |
| E674-0001-07 | Fax Board communication error |
| Detection Description | An error was detected for the specified number of times in communication with the Fax Board. |
| Remedy | <p>[Related parts] R1.00</p> <ul style="list-style-type: none"> - Harness between the Fax Board and the Main Controller PCB - Fax Board - Main Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> |
| E674-0002-07 | Fax Board communication error |
| Detection Description | An error was detected for the specified number of times in communication with the Fax Board. |
| Remedy | <p>[Related parts] R1.00</p> <ul style="list-style-type: none"> - Harness between the Fax Board and the Main Controller PCB - Fax Board - Main Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> |
| E674-0004-07 | Fax Board communication error |
| Detection Description | A communication error occurred when accessing the modem IC used for fax. |
| Remedy | <p>[Related parts] R1.00</p> <ul style="list-style-type: none"> - Harness between the Fax Board and the Main Controller PCB - Fax Board - Main Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> |
| E674-0008-07 | Fax Board communication error |
| Detection Description | A communication error occurred when accessing the port IC used for fax. |
| Remedy | <p>[Related parts] R1.00</p> <ul style="list-style-type: none"> - Harness between the Fax Board and the Main Controller PCB - Fax Board - Main Controller PCB <p>[Remedy] Check/replace the related harness/cable, connector and parts.</p> |
| E674-0010-07 | Fax Board communication error |
| Detection Description | A communication error occurred when opening the Timer Device used for fax. |
| Remedy | Check/replace the Main Controller PCB |
| E674-0011-07 | Fax Board communication error |
| Detection Description | A communication error occurred when starting the Timer Device used for fax. |
| Remedy | Check/replace the Main Controller PCB |

| | |
|------------------------------|---|
| E674-0020-07 | Fax Board communication error |
| Detection Description | An error occurred in the modem IC used for fax. |
| Remedy | [Related parts] R1.00 - Harness between the Fax Board and the Main Controller PCB - Fax Board - Main Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E674-0021-07 | Fax Board communication error |
| Detection Description | A Fax Board for non-supported modem has been connected. |
| Remedy | Replace it with a genuine Fax Board. |
| E674-0030-07 | Fax Board communication error |
| Detection Description | Check sum error |
| Remedy | System software download for 2 line FAX |
| E674-0100-07 | Fax Board communication error |
| Detection Description | After completion of fax communication, writing of the communication information (log) failed, and the log could not be read. |
| Remedy | Turn OFF and then ON the main power. If it occurs when the power is turned OFF and then ON after executing FAX > Clear > ALL, execute FAX > Clear > ALL and turn OFF and then ON the power again. [CAUTION] The previous communication information (log) will be cleared by turning OFF and then ON the main power. |
| E674-0300-07 | Fax configuration error |
| Detection Description | It was detected that there was a Fax Board for multiple lines installed while the IP Fax license was enabled. |
| Remedy | 1. Remove the Fax Board for multiple lines to use the machine as an IP Fax model. 2. Uninstall the IP Fax license to use the machine as a G3 Fax model. |
| E674-0301-07 | Fax configuration error |
| Detection Description | It was detected that there was no 1-line Fax Board installed while the IP Fax license was enabled. |
| Remedy | 1. Install the Fax Board (1-line) to use the machine as an IP Fax model. 2. Uninstall the IP Fax license and install the G3 Fax Board to use the machine as a G3 Fax model.S15 |
| E677-0001-00 | Print server error |
| Detection Description | Abnormality detected on the exhaust fan operation of printer server |
| Remedy | 1. Check supplying power to the exhaust fan 2. Exhaust fan replacement |
| E677-0003-00 | Print server error |
| Detection Description | An error in the fan of the Print Server was detected. |
| Remedy | [Related parts] R1.00 - Print Server Fan - Main Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E677-0004-00 | Print server error |
| Detection Description | Abnormality detected on the CPU fan operation of printer server |
| Remedy | 1. Check supplying power to the CPU fan 2. CPU fan replacement |
| E677-0010-00 | Print server error |
| Detection Description | Failure was detected in operation of the CPU fan on the print server. |
| Remedy | 1. Replace the board of the print server. 2. Reinstall the Print Server (For details, refer to "Service Manual image PASS P2.") |

| | |
|------------------------------|---|
| E677-0080-00 | Print server error |
| Detection Description | Error is detected at the Mother Board check when print server is started. |
| Remedy | 1. Check the cable connection and turn OFF and then ON the power. 2. Reinstall the print server (For details, refer to "Service Manual image PASS P2.") |
| E713-0000-02 | UFDI communication error. |
| Detection Description | Communication error with the Finisher. |
| Remedy | [Related parts] - Finisher Controller PCB - Harness between the Finisher Controller PCB and the DC Controller PCB - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E719-0001-00 | Error in Coin Vendor. |
| Detection Description | Error in starting of the CoinVendor - The Coin Vendor, which should have been connected before the power was turned OFF, is not connected when the power is turned ON. |
| Remedy | Check the connection between charging management equipment and machine, and check that the Cable is not open-circuit. Clear the error while the charging management equipment is connected to operate and when switching to the operation without charging management equipment. (To prevent the misuse by removing the charging management equipment, this error code is displayed.) |
| E719-0002-00 | Error in Coin Vendor. |
| Detection Description | Error in IPC when CoinVendor is running. - In the case of disconnection of IPC or an error in which IPC communication failed to be recovered. - When disconnection of the pickup delivery signal is detected. - When illegal connection is detected (short-circuit with Tx and Rx of IPC) |
| Remedy | Check the connection between charging management equipment and machine, and check that the Cable is not open-circuit. Clear the error while the charging management equipment is connected to operate and when switching to the operation without charging management equipment. (To prevent the misuse by removing the charging management equipment, this error code is displayed.) |
| E719-0003-00 | Error in Coin Vendor. |
| Detection Description | - In the case of communication error with the coin vendor while obtaining the unit price at start-up. |
| Remedy | Check the connection between charging management equipment and machine, and check that the Cable is not open-circuit. Clear the error while the charging management equipment is connected to operate and when switching to the operation without charging management equipment. (To prevent the misuse by removing the charging management equipment, this error code is displayed.) |
| E719-0004-00 | Coin vendor error |
| Detection Description | The coin vendor was connected to a model that does not support the coin vendor |
| Remedy | 1. Disconnect the coin vendor |
| E719-0031-00 | Error in serial communication at the start of the New Card Reader |
| Detection Description | Failure in communication with the serial New Card Reader at start-up. |
| Remedy | - Check if the cable of the serial New Card Reader is disconnected. - Take out the serial New Card Reader. - COPIER > Function > CLEAR > CARD - COPIER > Function > CLEAR > ERR |
| E719-0032-00 | Error in serial communication at the start of the New Card Reader |
| Detection Description | Communication failed in the middle of the operation although communication with the serial New Card Reader was successful at start-up. |
| Remedy | - Check if the cable of the serial New Card Reader is disconnected. |

| | |
|------------------------------|---|
| E719-0041-00 | Coin vendor error |
| Detection Description | Communication with the coin vendor could not be established at startup of the host machine. (Charge mode (COIN = 6) has been set.) |
| Remedy | <ol style="list-style-type: none"> If it operates in charge mode (COIN = 6) <ul style="list-style-type: none"> - Check that it is the supported charging management equipment. - Check the cable to be connected. - Check the power of the charging management equipment. If charge mode is canceled <ul style="list-style-type: none"> - Select COPIER> OPTION> ACC> COIN> "0", and turn OFF and then ON the main power. |
| E719-0042-00 | Coin vendor error |
| Detection Description | Communication with the coin vendor could not be established at startup of the host machine. (Charge mode (COIN = 6) has been set.) |
| Remedy | <ol style="list-style-type: none"> If it operates in charge mode (COIN = 6) <ul style="list-style-type: none"> - Check that it is the supported charging management equipment. - Check the cable to be connected. - Check the power of the charging management equipment. If charge mode is canceled <ul style="list-style-type: none"> - Select COPIER> OPTION> ACC> COIN> "0", and turn OFF and then ON the main power. |
| E720-0001-00 | Error due to non-compatible Finisher |
| Detection Description | Non-compatible Finisher was connected. |
| Remedy | Connect either the Staple Finisher-Y1 or Saddle Stitch Finisher-Y1. |
| E730-C001-00 | Error in HDD access |
| Detection Description | An error occurred when accessing the HDD. |
| Remedy | <p>[Related parts] R1.00</p> <ul style="list-style-type: none"> - Harness between the Main Controller PCB and the HDD - HDD - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> Format the HDD and reinstall the system software using SST or a USB flash drive. Check/replace the related harness/cable, connector and parts. |
| E731-3000-00 | Main Controller PCB error |
| Detection Description | Unable to recognize the SURF Board. |
| Remedy | Check/replace the Main Controller PCB |
| E731-3001-00 | Main Controller PCB error |
| Detection Description | Failure of SURF initialization. |
| Remedy | Check/replace the Main Controller PCB |
| E731-3002-00 | Main Controller PCB error |
| Detection Description | Failure of SURF initialization. |
| Remedy | Check/replace the Main Controller PCB |
| E731-3015-00 | Main Controller PCB error |
| Detection Description | Video data is not transmitted to CL1-G even though there is no problem in the software. |
| Remedy | Check/replace the Main Controller PCB |
| E732-0001-04 | Communication error |
| Detection Description | DDI-S communication error. |
| Remedy | <p>[Related parts] R1.00</p> <ul style="list-style-type: none"> - Harness between the READER ADF UNIT (J6, J5) and the Main Controller PCB (J4001, 4002) - READER ADF UNIT - Main Controller PCB <p>[Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally.</p> |

| | |
|------------------------------|---|
| E732-0010-00 | Communication error |
| Detection Description | A signal to start image transfer could not be detected at scanning although the specified period of time (120 sec) has passed. |
| Remedy | [Related parts] R1.00 - Harness between the READER ADF UNIT (J6, J5) and the Main Controller PCB (J4001, 4002) - READER ADF UNIT - Main Controller PCB [Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally. |
| E732-0020-00 | Communication error |
| Detection Description | A communication error of the Main Controller PCB was detected. |
| Remedy | [Related parts] R1.00 - Harness between the READER ADF UNIT (J6, J5) and the Main Controller PCB (J4001, 4002) - READER ADF UNIT - Main Controller PCB [Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally. |
| E732-0021-00 | Communication error |
| Detection Description | A communication error between the Reader Controller PCB and the Main Controller PCB was detected. |
| Remedy | [Related parts] R1.00 - Harness between the READER ADF UNIT (J6, J5) and the Main Controller PCB (J4001, 4002) - READER ADF UNIT - Main Controller PCB [Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally. |
| E732-0022-00 | Communication error |
| Detection Description | A communication error between the Reader Controller PCB and the Main Controller PCB was detected. |
| Remedy | [Related parts] R1.00 - Harness between the READER ADF UNIT (J6, J5) and the Main Controller PCB (J4001, 4002) - READER ADF UNIT - Main Controller PCB [Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally. |
| E732-0023-04 | Communication error |
| Detection Description | DDI-S communication error (SPRDY-S detection error) |
| Remedy | [Related parts] R1.00 - Harness between the READER ADF UNIT (J6, J5) and the Main Controller PCB (J4001, 4002) - READER ADF UNIT - Main Controller PCB [Remedy] Check/replace the related parts. After performing the remedy, check that the copy image is output normally. |
| E732-0F01-04 | Communication error |
| Detection Description | Communication error that can be recovered by reboot If it is detected again immediately after reboot, E732-0001 is generated. |
| Remedy | It is not necessary to perform a remedy because the machine is automatically rebooted after log collection. |
| E732-0F20-00 | Communication error |
| Detection Description | Communication error that can be recovered by reboot If it is detected again immediately after reboot, E732-0020 is generated. |
| Remedy | It is not necessary to perform a remedy because the machine is automatically rebooted after log collection. |

| | |
|------------------------------|---|
| E732-0F21-00 | Communication error |
| Detection Description | Communication error that can be recovered by reboot If it is detected again immediately after reboot, E732-0021 is generated. |
| Remedy | It is not necessary to perform a remedy because the machine is automatically rebooted after log collection. |
| E732-0F22-00 | Communication error |
| Detection Description | Communication error that can be recovered by reboot If it is detected again immediately after reboot, E732-0022 is generated. |
| Remedy | It is not necessary to perform a remedy because the machine is automatically rebooted after log collection. |
| E732-0F23-04 | Communication error |
| Detection Description | Communication error that can be recovered by reboot If it is detected again immediately after reboot, E732-0023 is generated. |
| Remedy | It is not necessary to perform a remedy because the machine is automatically rebooted after log collection. |
| E732-8888-00 | Communication error |
| Detection Description | Scanner for a different model was detected at communication with the Reader. |
| Remedy | Replace the Reader Unit with the one for this model. |
| E733-0000-05 | Printer communication error |
| Detection Description | A communication error between the DC Controller PCB and the Main Controller PCB was detected at startup. |
| Remedy | [Related parts] R1.00 - Harnesses between the DC Controller PCB and the Main Controller PCB - DC Controller PCB - Main Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. [Reference] Before replacing the DC Controller PCB, back up the service mode data (approx. 2 min) and restore the backup data after the replacement so the data may be able to be protected. - Backup: COPIER (LEVEL2)> FUNCTION> SYSTEM> DSRAMBUP - Restoration: COPIER (LEVEL2)> FUNCTION> SYSTEM> DSRAMRES |
| E733-0001-05 | Printer communication error |
| Detection Description | A communication error between the DC Controller PCB and the Main Controller PCB was detected. |
| Remedy | [Related parts] R1.00 - Harnesses between the DC Controller PCB and the Main Controller PCB - DC Controller PCB - Main Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. [Reference] Before replacing the DC Controller PCB, back up the service mode data (approx. 2 min) and restore the backup data after the replacement so the data may be able to be protected. - Backup: COPIER (LEVEL2)> FUNCTION> SYSTEM> DSRAMBUP - Restoration: COPIER (LEVEL2)> FUNCTION> SYSTEM> DSRAMRES |
| E733-0002-05 | Printer communication error |
| Detection Description | Signal error was detected after establishment of communication between the DC Controller PCB and the Main Controller PCB. |
| Remedy | [Related parts] R1.00 - Harnesses between the DC Controller PCB and the Main Controller PCB - DC Controller PCB - Main Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. [Reference] Before replacing the DC Controller PCB, back up the service mode data (approx. 2 min) and restore the backup data after the replacement so the data may be able to be protected. - Backup: COPIER (LEVEL2)> FUNCTION> SYSTEM> DSRAMBUP - Restoration: COPIER (LEVEL2)> FUNCTION> SYSTEM> DSRAMRES |

| | |
|------------------------------|---|
| E733-0010-05 | Printer communication error |
| Detection Description | A communication error between the DC Controller PCB and the Main Controller PCB was detected. |
| Remedy | [Related parts] R1.00 - Harnesses between the DC Controller PCB and the Main Controller PCB - DC Controller PCB - Main Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. [Reference] Before replacing the DC Controller PCB, back up the service mode data (approx. 2 min) and restore the backup data after the replacement so the data may be able to be protected. - Backup: COPIER (LEVEL2)> FUNCTION> SYSTEM> DSRAMBUP - Restoration: COPIER (LEVEL2)> FUNCTION> SYSTEM> DSRAMRES |
| E733-0F00-05 | Printer communication error |
| Detection Description | Communication error that can be recovered by reboot If it is detected again immediately after reboot, E733-0000 is generated. |
| Remedy | It is not necessary to perform a remedy because the machine is automatically rebooted after log collection. |
| E733-0F01-05 | Printer communication error |
| Detection Description | Communication error that can be recovered by reboot If it is detected again immediately after reboot, E733-0001 is generated. |
| Remedy | It is not necessary to perform a remedy because the machine is automatically rebooted after log collection. |
| E733-0F02-05 | Printer communication error |
| Detection Description | Communication error that can be recovered by reboot If it is detected again immediately after reboot, E733-0002 is generated. |
| Remedy | It is not necessary to perform a remedy because the machine is automatically rebooted after log collection. |
| E733-F000-05 | Printer communication error |
| Detection Description | Disconnection of a cable between the Main Controller PCB and the DC Controller PCB was detected. |
| Remedy | [Remedy] Check/replace the harness between the DC Controller PCB and the Main Controller PCB. |
| E733-F001-05 | Printer communication error |
| Detection Description | Disconnection of a cable between the Main Controller PCB and the DC Controller PCB was detected. |
| Remedy | [Remedy] Check/replace the harness between the DC Controller PCB and the Main Controller PCB. |
| E733-F002-05 | Printer communication error |
| Detection Description | Disconnection of a cable between the Main Controller PCB and the DC Controller PCB was detected. |
| Remedy | [Remedy] Check/replace the harness between the DC Controller PCB and the Main Controller PCB. |
| E743-0000-04 | DDI communication error |
| Detection Description | Software sequence error |
| Remedy | [Remedy] Collect debug log and contact to the sales company. |
| E744-0001-00 | Language file error |
| Detection Description | The language file in HDD was not supported by the version of Bootable. |
| Remedy | Reinstall the correct language file using SST or USB memory reinstall the entire software. |
| E744-0003-00 | Language file error |
| Detection Description | The language file to be switched to that was described in the Config.txt in HDD was not found. |
| Remedy | Reinstall the correct language file using SST or USB memory reinstall the entire software. |

| | |
|------------------------------|--|
| E744-0004-00 | Language file error |
| Detection Description | Switching to the language file in the HDD failed. |
| Remedy | Reinstall the correct language file using SST or USB memory reinstall the entire software. |
| E744-2000-00 | Controller firmware mismatch |
| Detection Description | Invalid controller firmware was detected. |
| Remedy | Replace the ECO-ID PCB with the one for this model. |
| E744-5000-07 | Mismatch of software version for fax |
| Detection Description | After the Fax Board (option) has been installed, mismatch of version of software in the Fax Board was detected at transmission and reception. |
| Remedy | Upgrade the system software version to the latest one. |
| E746-0011-00 | Voice Board error |
| Detection Description | Because both the voice composition board and the composition recognition board are inserted. |
| Remedy | Insert only 1 board of the appropriate voice board. |
| E746-0021-00 | Image Analysis Board error |
| Detection Description | Self-check NG of Image Analysis Board |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. Remove and then install the Image Analysis Board. 2. If the error is not cleared, replace the Image Analysis Board. 3. After replacing the Image Analysis Board, reinstall the firmware of the Image Analysis Board or the system software which version is supported by this model using SST or a USB flash drive. |
| E746-0022-00 | Image Analysis Board error |
| Detection Description | Different version of Image Analysis Board (PCB used for PCAM) |
| Remedy | Reinstall the firmware of the Image Analysis Board or the system software which version is supported by this model using SST or a USB flash drive. |
| E746-0023-00 | Image Analysis Board error |
| Detection Description | No response from Image Analysis Board (PCB used for PCAM) |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. Remove and then install the Image Analysis Board. 2. If the error is not cleared, replace the Image Analysis Board. 3. After replacing the Image Analysis Board, reinstall the firmware of the Image Analysis Board or the system software which version is supported by this model using SST or a USB flash drive. |
| E746-0024-00 | Image Analysis Board error |
| Detection Description | Failure in behavior of Image Analysis Board (PCB used for PCAM) |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. Remove and then install the Image Analysis Board. 2. If the error is not cleared, replace the Image Analysis Board. 3. After replacing the Image Analysis Board, reinstall the firmware of the Image Analysis Board or the system software which version is supported by this model using SST or a USB flash drive. |
| E746-0031-00 | TPM error |
| Detection Description | A communication error has occurred between the Main Controller PCB and the TPM PCB at startup. |
| Remedy | Check/replace the TPM PCB. [Reference] After replacing the TPM PCB, if the TPM key was backed up, restore the key. 1. Connect the USB memory which stores the TPM key. 2. Execute "Settings/Registration> Log In> Management Settings> Data Management> TPM Settings> Restore TPM Key". [CAUTION] Ask the customer to enter "System Manager ID" and "System Manager PIN" when logging in. 3. Enter the password set at backup operation. 4. When the restoration completion screen is displayed, click "OK". Remove the USB memory, and turn OFF and then ON the main power. |

| | |
|------------------------------|--|
| E746-0032-00 | TPM error |
| Detection Description | Mismatch of the TPM key was detected. |
| Remedy | <p>Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. Format the HDD and reinstall the system software using SST or a USB flash drive. 2. Replace the TPM PCB. <p>[Reference] After replacing the TPM PCB, if the TPM key was backed up, restore the key.</p> <ol style="list-style-type: none"> 1. Connect the USB memory which stores the TPM key. 2. Execute "Settings/Registration> Log In> Management Settings> Data Management> TPM Settings> Restore TPM Key". <p>[CAUTION] Ask the customer to enter "System Manager ID" and "System Manager PIN" when logging in.</p> <ol style="list-style-type: none"> 3. Enter the password set at backup operation. 4. When the restoration completion screen is displayed, click "OK". Remove the USB memory, and turn OFF and then ON the main power. |
| E746-0033-00 | TPM error |
| Detection Description | It was detected that data in TPM was inconsistent. |
| Remedy | <p>If the TPM key was backed up,</p> <ul style="list-style-type: none"> - Restore the TPM key. <ol style="list-style-type: none"> 1. Connect the USB memory which stores the TPM key. 2. Execute "Settings/Registration> Log In> Management Settings> Data Management> TPM Settings> Restore TPM Key". <p>[CAUTION] Ask the customer to enter "System Manager ID" and "System Manager PIN" when logging in.</p> <ol style="list-style-type: none"> 3. Enter the password set at backup operation. 4. When the restoration completion screen is displayed, click "OK". Remove the USB memory, and turn OFF and then ON the main power. <p>If the TPM key was not backed up,</p> <ul style="list-style-type: none"> - Format the HDD and reinstall the system software using SST or a USB flash drive. |
| E746-0034-00 | TPM auto recovery error |
| Detection Description | The error occurred when clearing HDD while TPM setting was ON. |
| Remedy | <p>It is recovered by turning OFF and then ON the power.</p> <p>If the error is not cleared, format the HDD and reinstall the system software using SST or a USB flash drive.</p> |
| E746-0035-00 | TPM version error |
| Detection Description | TPM PCB which cannot be used in this machine was installed. |
| Remedy | Install the TPM PCB for this model. |
| E748-2000-00 | Main Controller PCB access error |
| Detection Description | Main Controller PCB Chip access error. |
| Remedy | Check/replace the Main Controller PCB |
| E748-2001-00 | Main Controller PCB access error |
| Detection Description | Main Controller PCB memory access error. |
| Remedy | Check/replace the Main Controller PCB |

| | |
|------------------------------|---|
| E748-2010-00 | Flash PCB error / HDD error |
| Detection Description | IPL (startup program) was not found, or the HDD could not be recognized. |
| Remedy | <p>[Related parts] R1.00</p> <ul style="list-style-type: none"> - Harnesses between the Main Controller PCB and the HDD - HDD - Flash PCB - Main Controller PCB <p>[Remedy] Perform the following in the order while checking whether the error is cleared.</p> <ol style="list-style-type: none"> 1. Disconnect the cable between the Main Controller PCB and the HDD, and turn ON the main power. <ol style="list-style-type: none"> a. When the error code has not been changed: <ol style="list-style-type: none"> 1. Obtain the necessary backup data by referring to the backup data list. 2. Enter safe mode using (2+8) startup, and execute [4] Clear/Format> [2] Flash Format (Flash format) using a USB flash drive. 3. After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. 4. Restore the backup data. b. When the error code has been changed to another one, see the remedy for the corresponding code. <p>[Reference] For backup and restoration, refer to "Adjustment> Main Controller System" and "Appendix> Backup Data List" in the Service Manual.</p> |
| E748-2011-00 | Flash PCB error |
| Detection Description | OS was not found at startup. |
| Remedy | After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. |
| E748-2012-00 | Flash PCB error |
| Detection Description | Cannot mount the OS in safe mode startup or No OS startup script |
| Remedy | After replacing the Flash PCB, reinstall the system software using SST or a USB flash drive. |
| E748-2021-00 | Main Controller PCB access error |
| Detection Description | Main controller board access errors |
| Remedy | Check/replace the Main Controller PCB |
| E748-2023-00 | Main Controller PCB access error |
| Detection Description | Main controller board access errors |
| Remedy | Check/replace the Main Controller PCB |
| E748-2024-00 | Main Controller PCB access error |
| Detection Description | Main controller board access errors |
| Remedy | Check/replace the Main Controller PCB |
| E748-2025-00 | Main Controller PCB access error |
| Detection Description | Main controller board access errors |
| Remedy | <p>[Related parts] R1.00</p> <ul style="list-style-type: none"> - Main Controller PCB <p>[Remedy] Check/replace the related connector and parts.</p> |
| E748-2026-00 | Main Controller PCB access error |
| Detection Description | Main controller board access errors |
| Remedy | Check/replace the Main Controller PCB |
| E748-4910-00 | Main Controller PCB access error |
| Detection Description | Main controller board access errors |
| Remedy | Check/replace the Main Controller PCB |

| | |
|------------------------------|---|
| E748-7011-00 | Start system verification function error |
| Detection Description | At startup, an error may occur due to invalid data of the OS boot loader on the flash PCB. When this error occurs, the system has not been started normally. Therefore, it is not recorded in the error log. |
| Remedy | [Related parts] - Flash PCB [Remedy] 1. Replace the Flash PCB and reinstall the system using SST or a USB flash drive. |
| E748-7021-00 | Start system verification function error |
| Detection Description | At startup, an error may occur due to invalid data of the OS kernel on the flash PCB. When this error occurs, the system has not been started normally. Therefore, it is not recorded in the error log. |
| Remedy | [Related parts] - Flash PCB [Remedy] 1. Replace the Flash PCB and reinstall the system using SST or a USB flash drive. |
| E748-7022-00 | Start system verification function error |
| Detection Description | At startup, an error may occur due to invalid data of the OS kernel on the flash PCB. When this error occurs, the system has not been started normally. Therefore, it is not recorded in the error log. |
| Remedy | [Related parts] - Flash PCB [Remedy] 1. Replace the Flash PCB and reinstall the system using SST or a USB flash drive. |
| E748-9000-00 | System error |
| Detection Description | System error |
| Remedy | Contact to the sales company. |
| E753-0001-00 | Download Error |
| Detection Description | Update of the system software failed. |
| Remedy | Perform the following in the order while checking whether the error is cleared. 1. Turn OFF and then ON the main power. 2. Reinstall the system software using SST or a USB flash drive. 3. Replace the FLASH PCB, and reinstall the system software. 4. Collect debug log and contact the sales company. |
| E760-0001-00 | Main Controller PCB internal error |
| Detection Description | An error was detected in the Main Controller PCB. |
| Remedy | Check/replace the Main Controller PCB |
| E804-0000-00 | Power Supply Fan error |
| Detection Description | It was detected that the Supply Fan was locked. |
| Remedy | [Related parts] R1.00 - Harness between the AC Driver PCB (UN30/J117) and the Power Supply Cooling Fan (FM5/J712) - Power Supply Cooling Fan (FM5) - AC Driver PCB (UN30) [Remedy] Check/replace the related harness/cable, connector and parts. |
| E805-0001-05 | Cartridge Upper Fan error. |
| Detection Description | It was detected that the Cartridge Upper Fan was locked. |
| Remedy | Replacement of Cartridge Upper Fan. |
| E805-0002-05 | Cartridge Lower Fan error. |
| Detection Description | It was detected that the Cartridge lower Fan was locked. |
| Remedy | Replacement of the Cartridge Lower Fan. |

| | |
|------------------------------|---|
| E805-0008-05 | Duplex Fan error. |
| Detection Description | It was detected that the Finisher Fan was locked. |
| Remedy | Replacement of the Duplex Fan. |
| E805-0009-05 | Laser Scanner Fan error. |
| Detection Description | It was detected that the Laser Scanner Fan was locked. |
| Remedy | Replacement of the Laser Scanner Fan. |
| E808-0001-05 | Low Voltage Power Supply Failure |
| Detection Description | - 24V Power Supply error |
| Remedy | [Related parts] - Low Voltage Power Supply Unit [Remedy] Check/replace the related harness/cable, connector and parts. |
| E840-0001-05 | Pressure Release Mechanism error |
| Detection Description | An error was detected at the pressure/separation operation. |
| Remedy | [Related parts] - Fixing Assembly - DC Controller PCB [Remedy] Check/replace the related harness/cable, connector and parts. |
| E880-0001-00 | Controller Fan error |
| Detection Description | It was detected that the Controller Fan was locked. |
| Remedy | [Related parts] R1.00 - Cable between the Main Controller PCB (UN25/J15) and the Controller Fan (FM12) - Controller Fan (FM12) - Main Controller PCB (UN25) [Remedy] Perform the following in the order while checking whether the error is cleared. - Check the connectors of the Controller Fan. - Visually check rotation of the Controller Fan. a. If it is not rotated, replace the Controller Fan. b. If it is rotated, replace the Main Controller PCB. |
| E880-0003-00 | Controller Fan error |
| Detection Description | It was detected that the Controller Fan was locked. |
| Remedy | [Related parts] R1.00 - Cable between the Main Controller PCB and the Controller Fan - Controller Fan - Main Controller PCB [Remedy] Perform the following in the order while checking whether the error is cleared. - Check the connectors of the Controller Fan. - Visually check rotation of the Controller Fan. a. If it is not rotated, replace the Controller Fan. b. If it is rotated, replace the Main Controller PCB. |
| E880-0005-00 | Error in Controller Fan |
| Detection Description | Fan lock of the HDD Cooling Fan was detected |
| Remedy | Check if the connector is connected. If the connection is OK, replace the HDD Cooling Fan. |
| E881-0001-00 | Board over heat error |
| Detection Description | Abnormal temperature of the Main Controller CPU was detected. |
| Remedy | [Remedy] Perform the following in the order while checking whether the error is cleared. a. If the error occurred during a service visit and then occurred again, replace the Main Controller PCB. b. If the error does not occur during a service visit but is found in the log: 1. Clean the inlet on the side where the fan is installed and remove dust. 2. Remove dust from the Controller fan. 3. If the space on the side where the fan is installed is less than 10 cm, ask the customer to secure enough space. |

| | |
|------------------------------|--|
| E996-0001-05 | Error for collecting sequence jam log (Printer) |
| Detection Description | Error for collecting jam log (Printer) |
| Remedy | [Remedy] Collect debug log and contact to the sales company. [Reference] By setting "COPIER (LEVEL2)> OPTION> FNC-SW> JM-ERR-R" to "1", it is handled as an error instead of a jam from the first occurrence. |
| E996-0071-04 | Error for collecting sequence jam log (ADF) |
| Detection Description | Error for collecting jam log (ADF) |
| Remedy | [Remedy] Collect debug log and contact to the sales company. [Reference] By setting "COPIER (LEVEL2)> OPTION> FNC-SW> JM-ERR-R" to "1", it is handled as an error instead of a jam from the first occurrence. |


Error Code (FAX)

How to View Fax Error Codes

When the service mode #1 SSSW SW01 Bit0 is set to "1" after installing the Fax Board, service error code is output on the communication management report, reception result report, and error transmission report in the event that the communication is resulted in an error.

Moreover, when an error occurs, the error code can be checked by performing the following procedure.

Status Monitor/Cancel > Send > Job Log > Details



The error codes displayed on the screen are shown in a list in "User Error Codes" and "Service Error Codes".

For remedies for user error codes, refer to the User's Guide. For remedies for service error codes, refer to "G3/G4 Facsimile Error Code List (REVISION 2)" (document number: HY8-23A0-020) provided as a separate volume.

User error codes

Regarding the user error codes, refer to Top > Troubleshooting > A Message or a Number Starting with "#" (an Error Code) Is Displayed > Countermeasures for Each Error Code.

Service Error Code

| Code | Cause | Remedy |
|--------|--|--------------------------------|
| ##3016 | [T/R] An instruction of disconnection (BYE) was received from the network at an unexpected time. | Perform a communication again. |

*1: G3FAX

*2: IPFAX

| No.*1 | No.*2 | T/R | Description |
|-------|--------|-------|---|
| ##100 | ##3100 | [T] | at time of transmission, the procedural signal has been transmitted more than specified. |
| ##101 | ##3101 | [T/R] | the modem speed does not match that of the other party. |
| ##102 | ##3102 | [T] | at time of transmission, fall-back cannot be used. |
| ##103 | ##3103 | [R] | at time of reception, EOL cannot be detected for 5 sec (15 sec if CBT). |
| ##104 | ##3104 | [T] | at time of transmission, RTN or PIN is received. |
| ##106 | ##3106 | [R] | at time of reception, the procedural signal is received for 6 sec while in wait for the signal. |
| ##107 | ##3107 | [R] | at time of reception, the transmitting party cannot use fall-back. |
| ##109 | ##3109 | [T] | at time of transmission, a signal other than DIS, DTC, FTT, CFR, or CRP is received, and the procedural signal has been sent more than specified. |
| ##111 | ##3111 | [T/R] | memory error has occurred. |

| No.*1 | No.*2 | T/R | Description |
|-------|--------|-------|--|
| ##114 | ##3114 | [R] | at time of reception, RTN is transmitted. |
| ##116 | ##3116 | [T/R] | Disconnection of loop current was detected during communication. |
| ##200 | ##3200 | [R] | at time of reception, no image carrier is detected for 5 sec. |
| ##201 | ##3201 | [T/R] | DCN is received outside the normal parity procedure. |
| ##204 | ##3204 | [T] | DTC without transmission data is received. |
| ##220 | ##3220 | [T/R] | system error (main program out of control) has occurred. |
| ##223 | ##3223 | [T/R] | while a communication is under way, the line is cut. |
| ##224 | ##3224 | [T/R] | in communication, an error has occurred in the procedural signal. |
| ##226 | ##3226 | [T/R] | the stack printer has fallen outside the RAM area. |
| ##227 | ##3227 | [R] | An attempt was made to record a file without image. |
| ##229 | ##3229 | [R] | the recording unit has remained locked for 1 min. |
| ##230 | ##3230 | [T/R] | A unit for controlling the display has malfunctioned. |
| ##231 | ##3231 | [T/R] | A unit for controlling the Control Panel buttons has malfunctioned. |
| ##232 | ##3232 | [T] | encoding error has occurred. |
| ##237 | ##3237 | [R] | decoding error has occurred. |
| ##238 | ##3238 | [R] | the print control unit is out of order. |
| ##261 | ##3261 | [T/R] | system error has occurred. |
| ##280 | ##3280 | [T] | at time of transmission, the procedural signal has been transmitted more than specified. |
| ##281 | ##3281 | [T] | at time of transmission, the procedural signal has been transmitted more than specified. |
| ##282 | ##3282 | [T] | at time of transmission, the procedural signal has been transmitted more than specified. |
| ##283 | ##3283 | [T] | at time of transmission, the procedural signal has been transmitted more than specified. |
| ##284 | ##3284 | [T] | at time of transmission, DCN is received after transmission of TCF. |
| ##285 | ##3285 | [T] | at time of transmission, DCN is received after transmission of EOP. |
| ##286 | ##3286 | [T] | at time of transmission, DCN is received after transmission of EOM. |
| ##287 | ##3287 | [T] | at time of transmission DCN is received after transmission of MPS. |
| ##288 | ##3288 | [T] | after transmission of EOP, a signal other than PIN, PIP, MCF, RTP, or RTN has been received. |
| ##289 | ##3289 | [T] | after transmission of EOM, a signal other than PIN, PIP, MCF, RTP, or RTN has been received. |
| ##290 | ##3290 | [T] | after transmission of MPS, a signal other than PIN, PIP, MCF, RTP, or RTN has been received. |
| ##670 | ##3670 | [T] | at time of V.8 late start, the V.8 ability of DIS front the receiving party is expected to be detected, and the CI signal is expected to be transmitted in response; however, the procedure fails to advance, and the line is released because of T1 time-out. |
| ##671 | ##3671 | [R] | at time of V.8 arrival, procedure fails to move to phase 2 after detection of CM signal from caller, causing T1 time-out and releasing line. |
| ##672 | ##3672 | [T] | at time of V.34 transmission, a shift in procedure from phase 2 to phase 3 and thereafter stops, causing the machine to release the line and suffer T1 timeout. |
| ##673 | ##3673 | [R] | at time of V.34 reception, a shift in procedure from phase 2 to phase 3 and thereafter stops, causing the machine to release the line and suffer T1 timeout. |
| ##674 | ##3674 | [T] | at time of V.34 transmission, a shift in procedure from phase 3 and phase 4 to the control channel and thereafter stops, causing the machine to release the line and suffer T1 timeout. |
| ##675 | ##3675 | [R] | at time of V.34 reception, a shift in procedure from phase 3 and phase 4 to the control channel and thereafter stops, causing the machine to release the line and suffer T1 timeout. |
| ##750 | ##3750 | [T] | at time of ECM transmission, no meaningful signal is received after transmission of PPS-NULL, causing the procedural signal to be transmitted more than specified. |
| ##752 | ##3752 | [T] | at time of ECM transmission, DCN is received after transmission of PPS-NULL. |
| ##753 | ##3753 | [T] | at time of ECM transmission, the procedural signal has been transmitted more than specified after transmission of PPS-NULL, or T5 time-out (60 sec) has occurred. |
| ##754 | ##3754 | [T] | at time of ECM transmission, the procedural signal has been transmitted more than specified after transmission of PPS-NULL. |

| No.*1 | No.*2 | T/R | Description |
|-------|--------|-------|--|
| ##755 | ##3755 | [T] | at time of ECM transmission, no meaningful signal is received after transmission of PPS-MPS, causing the procedural signal to be transmitted more than specified. |
| ##757 | ##3757 | [T] | at time of ECM transmission, DCN is received after retransmission of PPS-MPS. |
| ##758 | ##3758 | [T] | at time of ECM transmission, the procedural signal has been transmitted more than specified after transmission of PPS-MPS, or T5 time-out (60 sec) has occurred. |
| ##759 | ##3759 | [T] | at time of ECM transmission, the procedural signal has been transmitted more than specified after transmission of PPS-MPS. |
| ##760 | ##3760 | [T] | at time of ECM transmission, no meaningful signal is received after transmission of PPS-EOM, causing the procedural signal to be transmitted more than specified. |
| ##762 | ##3762 | [T] | at time of ECM transmission, DCN is received after transmission of PPS-EOM. |
| ##763 | ##3763 | [T] | at time of ECM transmission, the procedural signal has been transmitted more than specified after transmission of PPS-MPS, or T5 time-out (60 sec) has occurred. |
| ##764 | ##3764 | [T] | at time of ECM transmission, the procedural signal has been transmitted more than specified after transmission of PPS-EOM. |
| ##765 | ##3765 | [T] | at time of ECM transmission, no meaningful signal is received after transmission of PPS-EOP, causing the procedural signal to be transmitted more than specified. |
| ##767 | ##3767 | [T] | at time of ECM transmission, DCN is received after transmission of PPS-EOP. |
| ##768 | ##3768 | [T] | at time of ECM transmission, the procedural signal has been transmitted more than specified after transmission of PPS-EOP, or T5 time-out (60 sec) has occurred. |
| ##769 | ##3769 | [T] | at time of ECM transmission, the procedural signal has been transmitted more than specified after transmission of PPS-EOP. |
| ##770 | ##3770 | [T] | at time of ECM transmission, no meaningful signal is received after transmission of EOR-NULL, causing the procedural signal to be transmitted more than specified. |
| ##772 | ##3772 | [T] | at time of ECM transmission, DCN is received after transmission of EOR-NULL. |
| ##773 | ##3773 | [T] | at time of ECM transmission, the procedural signal has been transmitted more than specified after transmission of EOR-NULL, or T5 time-out (60 sec) has occurred. |
| ##774 | ##3774 | [T] | at time of ECM transmission, ERR is received after transmission of EOR-NULL. |
| ##775 | ##3775 | [T] | at time of ECM transmission, no meaningful signal is received after transmission of EOR-MPS, causing the procedural signal to be transmitted more than specified. |
| ##777 | ##3777 | [T] | at time of ECM transmission, DCN is received after transmission of EOR-MPS. |
| ##778 | ##3778 | [T] | at time of ECM transmission, the procedural signal has been transmitted more than specified after transmission EOR-MPS, or T5 time-out (60 sec) has occurred. |
| ##779 | ##3779 | [T] | at time of ECM transmission, ERR is received after transmission of EOR-MPS. |
| ##780 | ##3780 | [T] | at time of ECM transmission, no meaningful signal is received after transmission of EOR-EOM, causing the procedural signal to be transmitted more than specified. |
| ##782 | ##3782 | [T] | at time of ECM transmission, DCN is received after transmission of EOR-EOM. |
| ##783 | ##3783 | [T] | at time of ECM transmission, the procedural signal has been transmitted more than specified after transmission of EOR-EOM, or T5 time-out (60 sec) has occurred. |
| ##784 | ##3784 | [T] | at time of ECM transmission, ERR is received after transmission of EOR-EOM. |
| ##785 | ##3785 | [T] | at time of ECM transmission, no meaningful signal is received after transmission of EOR-EOP, causing the procedural signal to be transmitted more than specified. |
| ##787 | ##3787 | [T] | at time of ECM transmission, DCN is received after transmission of EOR-EOP. |
| ##788 | ##3788 | [T] | at time of ECM transmission, the procedural signal has been transmitted more than specified after transmission of EOR-EOP, or T5 time-out (60 sec) has occurred. |
| ##789 | ##3789 | [T] | at time of ECM transmission, ERR is received after transmission of EOR-EOP. |
| ##790 | ##3790 | [R] | at time of ECM reception, ERR is transmitted after transmission of EOR-Q. |
| ##791 | ##3791 | [T/R] | while ECM mode procedure is under way, a signal other than a meaningful signal is received. |
| ##792 | ##3792 | [R] | at time of ECM reception, PPS-NULL cannot be detected over partial page processing. |
| ##793 | ##3793 | [R] | at time of ECM reception, no effective frame is received while high-speed signal reception is under way, thus causing time-out. |
| ##794 | ##3794 | [T] | at time of ECM reception, PPR with all 0s is received. |
| ##795 | ##3795 | [T/R] | a fault has occurred in code processing for communication. |
| ##796 | ##3796 | [T/R] | a fault has occurred in code processing for communication. |

Alarm Code

Alarm Code Details

| | |
|--|--|
| 00-0085 | A notice of stat |
| A. Operation / B. Cause / C. Remedy | - |
| 00-0246 | Error code display (4-digit) |
| A. Operation / B. Cause / C. Remedy | Soft counter PCB cannot write normally |
| 00-0247 | Error code display (4-digit) |
| A. Operation / B. Cause / C. Remedy | Soft counter PCB cannot restore data |
| 01-0002 | No change in device status after specified period of time has passed (RDS server creates) |
| A. Operation / B. Cause / C. Remedy | - |
| 04-0076 | OP Cassette 2 Memory Error |
| A. Operation / B. Cause / C. Remedy | Cause: Communications cannot be made with the Control PCB of OP Cassette 2 or data error occurs. Remedy: 1. Check on the connection of OP Cassette 2 2. Check on the connector of the Control PCB of OP Cassette 2 3. Replacement of the Control PCB of OP Cassette 2 4. Replacement of the DC Controller PCB |
| 04-0077 | OP Cassette 3 Memory Error |
| A. Operation / B. Cause / C. Remedy | Cause: Communications cannot be made with the Control PCB of OP Cassette 3 or data error occurs. Remedy: 1. Check on the connection of OP Cassette 3 2. Check on the connector of the Control PCB of OP Cassette 3 3. Replacement of the Control PCB of OP Cassette 3 4. Replacement of the DC Controller PCB |
| 04-0078 | OP Cassette 4 Memory Error |
| A. Operation / B. Cause / C. Remedy | Cause: Communications cannot be made with the Control PCB of OP Cassette 4 or data error occurs. Remedy: 1. Check on the connection of OP Cassette 4 2. Check on the connector of the Control PCB of OP Cassette 4 3. Replacement of the Control PCB of OP Cassette 4 4. Replacement of DC Controller PCB |
| 10-0020 | Cartridge prior delivery alarm |
| A. Operation / B. Cause / C. Remedy | An alarm for requesting a prior delivery is sent to UGW as the value of Cartridge level detect value has reached the value set in COPIER > OPTION > FNC-SW > T-DLV-BK. |
| 10-0094 | Cartridge memory detection alarm |
| A. Operation / B. Cause / C. Remedy | Cause: Memory of cartridge could not be detected. Measures: 1. Remove and then install the Cartridge. 2. Check for any scar or soiling on the memory area of the Cartridge. 3. Replace the Cartridge. |

| | |
|--|---|
| 10-0098 | Cartridge memory detection alarm |
| A. Operation / B. Cause / C. Remedy | Cause: Memory of cartridge could not be detected. Measures: 1. Remove and then install the Cartridge. 2. Check for any scar or soiling on the memory area of the Cartridge. 3. Replace the Cartridge. |
| 10-0100 | Cartridge replace notice |
| A. Operation / B. Cause / C. Remedy | The replacement of the Cartridge was detected. |
| 10-0404 | Cartridge empty alarm |
| A. Operation / B. Cause / C. Remedy | When the cartridge empty was detected |
| 13-0FFC | For R&D |
| A. Operation / B. Cause / C. Remedy | |
| 13-0FFE | For R&D |
| A. Operation / B. Cause / C. Remedy | |
| 14-0002 | For R&D |
| A. Operation / B. Cause / C. Remedy | |
| 31-0006 | HDD failure when equipped with the mirroring function |
| A. Operation / B. Cause / C. Remedy | HDD failure when equipped with the mirroring function |
| 31-0008 | HDD failure prediction alarm |
| A. Operation / B. Cause / C. Remedy | Movement: HDD failure is expected to occur in a short time due to occurrence of physical error in HDD. It does not occur in the HDD of mirroring configuration. Cause: Error in the S.M.A.R.T. value of HDD Measures: 1. Back up the data stored in HDD. 2. Replace the HDD. 3. Restore the data. S.M.A.R.T. (Self-Monitoring Analysis and Reporting Technology): Self-diagnosis function built in the HDD. The occurrence rate of reading error, reading and writing speed, the total number of Motor start-up and stop times, the total length of power-on time, etc. are monitored. |
| 31-0009 | FLASH failure prediction alarm |
| A. Operation / B. Cause / C. Remedy | Cause: Error in the S.M.A.R.T. value of FLASH memory It indicates a physical error of the FLASH memory, which is expected to soon lead to a failure. *: S.M.A.R.T. (Self-Monitoring Analysis and Reporting Technology) = It is a self-diagnosis function built in the FLASH memory, and monitors the occurrence rate of reading errors, reading/writing speed, total number of times of motor start-up/stop, total length of power-on time, etc. Continuously using the machine without taking any measures may lead to E614. Measures: Back up the data stored in the FLASH memory, and restore the data after replacing the FLASH memory. |
| 31-0060 | Warning in accessing the NVRAM |
| A. Operation / B. Cause / C. Remedy | Communication with EEPROM in the DCON PCB was not available. Remedy: Replace the DCON PCB. |
| 31-0061 | Warning in accessing the NVRAM |
| A. Operation / B. Cause / C. Remedy | Communication with EEPROM in the DCON PCB was not available. Remedy: Replace the DCON PCB. |

| | |
|--|--|
| 31-0106 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 31-0116 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 31-0126 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 31-0136 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 31-01F1 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 31-01F2 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 31-01F3 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 31-01F4 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 31-01F5 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 31-01F6 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 34-0050 | Laser Scanner EEPROM checksum alarm |
| A. Operation / B. Cause / C. Remedy | An error in data in the EEPROM installed in the Laser Scanner PCB was detected. Detection condition/timing: When the DCON is started, data in the EEPROM of the Laser Scanner is retrieved. [Related parts] - Laser Driver PCB - Harness between the DC Controller PCB and the Laser Driver PCB Remedy: [Remedy] Check/replace the related parts. |
| 37-0001 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 37-0002 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 37-0003 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |

| | |
|--|--|
| 37-0004 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 37-0005 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 37-0006 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 37-0007 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 37-1000 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 37-2000 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 38-0001 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 38-0002 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 40-0013 | Transfer Roller life value reaching alarm |
| A. Operation / B. Cause / C. Remedy | It is notified that the value of COPIER > COUNTER > LF > TR-ROLL has reached the value set in COPIER > OPTION > FNC-SW > TRR-DLV. |
| 40-0076 | Fixing Ass'y life value reaching alarm |
| A. Operation / B. Cause / C. Remedy | It is notified that the value of COPIER > COUNTER > LF > FX-LF has reached the value set in COPIER > OPTION > FNC-SW > FIX-DLV. |
| 40-0080 | CST1 Feed Roller life value reaching alarm |
| A. Operation / B. Cause / C. Remedy | It is notified that the value of COPIER > COUNTER > LF > C1-FD-RL has reached the value set in COPIER > OPTION > FNC-SW > C1F-DLV. |
| 40-0083 | CST2 Feed Roller life value reaching alarm |
| A. Operation / B. Cause / C. Remedy | It is notified that the value of COPIER > COUNTER > LF > C2-FD-RL has reached the value set in COPIER > OPTION > FNC-SW > C2F-DLV. |
| 40-0086 | CST3 Feed Roller life value reaching alarm |
| A. Operation / B. Cause / C. Remedy | It is notified that the value of COPIER > COUNTER > LF > C3-FD-RL has reached the value set in COPIER > OPTION > FNC-SW > C3F-DLV. |
| 40-0089 | CST4 Feed Roller life value reaching alarm |
| A. Operation / B. Cause / C. Remedy | It is notified that the value of COPIER > COUNTER > LF > C4-FD-RL has reached the value set in COPIER > OPTION > FNC-SW > C4F-DLV. |
| 40-0125 | ADF Pickup Roller life value reaching alarm |
| A. Operation / B. Cause / C. Remedy | It is notified that the value of COPIER > COUNTER > LF > DF-PU-RL has reached the value set in COPIER > OPTION > FNC-SW > DFP-DLV. |
| 43-0013 | Transfer Roller replacement completion alarm |
| A. Operation / B. Cause / C. Remedy | The counter of the Transfer Roller was cleared. |

| | |
|--|--|
| 43-0076 | Fixing Assembly replacement completion alarm |
| A. Operation / B. Cause / C. Remedy | The counter of the Fixing Assembly was cleared. |
| 43-0080 | CST1 Pickup/Feeding Roller replacement completion alarm |
| A. Operation / B. Cause / C. Remedy | The counter of the CST1 Pickup/Feeding Roller was cleared. |
| 43-0083 | CST2 Pickup/Feeding Roller replacement completion alarm |
| A. Operation / B. Cause / C. Remedy | The counter of the CST2 Pickup/Feeding Roller was cleared. |
| 43-0086 | CST3 Pickup/Feeding Roller replacement completion alarm |
| A. Operation / B. Cause / C. Remedy | The counter of the CST3 Pickup/Feeding Roller was cleared. |
| 43-0089 | CST4 Pickup/Feeding Roller replacement completion alarm |
| A. Operation / B. Cause / C. Remedy | The counter of the CST4 Pickup/Feeding Roller was cleared. |
| 43-0092 | ADF Separation Roller replacement completion alarm |
| A. Operation / B. Cause / C. Remedy | Pushed was a replacement completion button of ADF Separation Roller Counter was cleared. |
| 43-0125 | ADF Pickup Roller replacement completion alarm |
| A. Operation / B. Cause / C. Remedy | Pushed was a replacement completion button of ADF Pickup Roller Counter was cleared. |
| 50-0010 | Alarm due to original separation failure |
| A. Operation / B. Cause / C. Remedy | Movement: Nothing in particular. Cause: Condition unable to separate 1st sheet of original from the ADF occurs 3 times. Measures: Check the rotation of the Delivery Reversal Motor (M12) -> Check the operation of the Pickup Solenoid (SL5) -> Check the life of the Pickup and Feed Rollers and Separation Pad -> Check if the paper lint is at the pickup slot. |
| 50-0015 | Failure of the ADF Double Feed Sensor |
| A. Operation / B. Cause / C. Remedy | Cause: Failure of the Double Feed Sensor installed in the ADF Detection condition/timing: - When a paper feed error of the Double Feed Sensor was detected at power-on - When an error of the output value of the Double Feed Sensor was detected during ADF job (While an ADF job is being executed, it is handled as a jam once and retry is performed.) Clearing condition: - When communication and the sensor output value are normal at power-on Movement/symptom: "Check area where multi. sheet feed was detected. (Call serv. rep.)" is displayed in the status line. Although reading from the ADF is possible, double feed cannot be detected when it occurs. Measures: Check for any foreign matter, clean paper lint, disconnect and then connect the connectors, replace the Double Feed Detection PCB, replace the RCON/DF Driver PCB, replace the harnesses |
| 60-0001 | Shift Tray alarm |
| A. Operation / B. Cause / C. Remedy | Movement: Shift Tray operation is stopped. Cause: Home position at startup of the host machine cannot be detected. Measure: Check connector disconnection of the HP Sensor (Front) (PS101) and the HP Sensor (Rear) (PS102) -> Replace the HP Sensor (Front) (PS101) and the HP Sensor (Rear) (PS102). |
| 70-0086 | For R&D |
| A. Operation / B. Cause / C. Remedy | |

| | |
|--|---|
| 70-0087 | Firmware combination mismatch |
| A. Operation / B. Cause / C. Remedy | <p>Cause: An option with the firmware which version is newer than that of the firmware installed in the host machine was detected. It is an alarm when the automatic update cancellation message is displayed on the Control Panel.</p> <p>Detection condition: When the following two conditions are satisfied:</p> <ol style="list-style-type: none"> 1. "1" is set in COPIER>Option>FNC-SW>VER-CHNG. 2. The version of the firmware installed in the option that has been installed to the host machine is newer than that of the firmware in the host machine. <p>Timing: At startup Movement/symptom: Cancel the automatic update. Measures: Update the firmware of the host machine.</p> |
| 73-0006 | LIPS |
| A. Operation / B. Cause / C. Remedy | Error in configuration acquisition/management |
| 73-0007 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 73-0008 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 73-0009 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 73-0011 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 73-0014 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 73-0015 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 73-0017 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 73-0021 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 73-0024 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 73-0026 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 75-0001 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |

| | |
|--|--|
| 75-0002 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 76-0001 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 76-0002 | Font |
| A. Operation / B. Cause / C. Remedy | Fails to secure the work area to analyze the font that is downloaded at "Resource Download". |
| 76-0003 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 76-0004 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 76-0005 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 76-0006 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 76-0007 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 76-0008 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 78-0003 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 78-0005 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 79-0001 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 79-0002 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 79-0003 | Canon-made PCL |
| A. Operation / B. Cause / C. Remedy | Overflow of work memory for translator |
| 79-0004 | Canon-made PCL |
| A. Operation / B. Cause / C. Remedy | Download overflow |
| 80-0001 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |

| | |
|--|---|
| 80-0003 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 80-0004 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 80-0007 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 80-0008 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 80-0009 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 80-0010 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 80-0011 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 80-0012 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 80-0013 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 80-0015 | BDL |
| A. Operation / B. Cause / C. Remedy | Print data cannot process this version. |
| 80-0016 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 80-0019 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 81-0001 | Imaging |
| A. Operation / B. Cause / C. Remedy | Fails to allocate the memory. |
| 81-0002 | Imaging |
| A. Operation / B. Cause / C. Remedy | Rendering error |
| 81-0003 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 81-0004 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |

| | |
|--|------------------------------------|
| 81-0005 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 81-0006 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 81-0007 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 83-0005 | PDF |
| A. Operation / B. Cause / C. Remedy | PDF memory full |
| 83-0015 | PDF |
| A. Operation / B. Cause / C. Remedy | PDF data decoding error |
| 83-0016 | PDF |
| A. Operation / B. Cause / C. Remedy | Page range error |
| 83-0017 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 84-0001 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 84-0002 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 84-0003 | XPS print range error |
| A. Operation / B. Cause / C. Remedy | - |
| 84-0004 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 84-0005 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 84-0006 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 84-0007 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |
| 84-0008 | XPS non-support image error |
| A. Operation / B. Cause / C. Remedy | - |
| 84-0009 | For R&D |
| A. Operation / B. Cause / C. Remedy | - |


Jam Code

Jam Type


| Type | Overview of detection | Check items (in arbitrary order) |
|----------|---|---|
| DELAY | A delay jam occurs when a sensor was not turned ON although a specified period of time had passed after the start of detection by the sensor. | <ul style="list-style-type: none"> • Remaining paper at the upstream of the target sensor • Soiling on the target sensor • Displacement of the target sensor position • Failure of the target sensor • Soiling (grease)/deterioration/failure of a drive motor located upstream of the target sensor • Soiling (paper dust)/deterioration/failure of a drive roller located upstream of the target sensor |
| STNRY | A stationary jam occurs when a sensor was not turned OFF although a specified period of time had passed after the sensor was turned ON. | <ul style="list-style-type: none"> • Remaining paper near the target sensor • Soiling on the target sensor • Displacement of the target sensor position • Failure of the target sensor • Soiling (grease)/deterioration/failure of a drive motor located upstream of the target sensor • Soiling (paper dust)/deterioration/failure of a drive roller located upstream of the target sensor |
| DOOR OP | A door open jam occurs when a sensor detected door open during printing operation. | <ul style="list-style-type: none"> • Door open during printing |
| COVER OP | A door open jam occurs when a sensor detected cover open during printing operation. | <ul style="list-style-type: none"> • Cover open during printing |
| ADF OPEN | A door open jam occurs when a sensor detected ADF open during printing operation. | <ul style="list-style-type: none"> • ADF open during printing |
| SEQUENCE | <p>A sequence jam occurs when there was an error in sensor detection signal at printing operation sequence.</p> <p>Since the jam may occur due to sporadic noise with software of each equipment or communication line (interruption of communication), failure of the part is not the cause of the jam. After the jam is removed, the machine works.</p> | <ul style="list-style-type: none"> • Opening/closing of the door • Turning OFF and then ON the power • Error near the target sensor (soiling/displacement/failure of the sensor, error in harness/open circuit of harness, soiling (grease)/deterioration/failure of a drive motor, or soiling (paper dust)/deterioration/failure of a drive roller) |
| POWER ON | A power-on jam occurs when a sensor detected ON state at power-on. | <ul style="list-style-type: none"> • Remaining paper in the machine • Soiling on the target sensor • Failure of the target sensor • Foreign matter on the target sensor (paper dust, paper lint) |
| ERROR | <p>An error avoidance jam occurs when an error in the machine (excluding parts failure) was detected. Printing operation is suspended to avoid error occurrence by error code; therefore, parts failure is not the cause of the jam.</p> <p>After the jam is removed, the machine works.</p> <p>If it is due to parts failure, an error code instead of the error avoidance jam is displayed on UI and printing operation is suspended. In such case, service technician should perform remedial work for the error code.</p> | <ul style="list-style-type: none"> • Opening/closing of the door after jam removal • Turning OFF and then ON the power after jam removal |
| SIZE ERR | A size error jam occurs when the difference between the paper length detected by the Cassette Guide Plate/specified on the Control Panel and the length measured by the Registration Sensor is out of the specified range. | <ul style="list-style-type: none"> • Difference in paper size • Wrong paper size setting • Error in the Document Size Sensor (soiling/displacement/failure of the sensor) • Error in the Paper Size Detection Unit (failure of mechanical structure for size detection, failure of the Guide Plate, or failure of the Cassette Size Switch) |
| P-STOP | <p>Forcible stop of paper feed</p> <p>It occurs when a sheet of paper stops at the position specified in service mode.</p> | <ul style="list-style-type: none"> • Using at problem analysis. |

Jam screen display specification

Due to one jam code being used for multiple options, the illustration for the different option may be displayed on the jam screen. In this case, "1/2" or similar information is displayed on top left side of the screen and this area can be pushed. This operation can be used to switch information on the screen.




Main Unit



| ACC ID | Jam Code | Type | Sensor Name / Description | Sensor ID |
|--------|----------|----------|----------------------------|-----------|
| 00 | 0101 | DELAY | Registration Sensor | PS4550 |
| 00 | 0106 | DELAY | Fixing Output Sensor | PS4650 |
| 00 | 0107 | DELAY | Delivery Paper Full Sensor | PS4450 |
| 00 | 0108 | DELAY | Duplex Feed Sensor | PS4700 |
| 00 | 0109 | DELAY | Registration Sensor | PS4550 |
| 00 | 0201 | STNRY | Registration Sensor | PS4550 |
| 00 | 0206 | STNRY | Fixing Output Sensor | PS4650 |
| 00 | 0706 | WRAP | Fixing Output Sensor | PS4650 |
| 00 | 0A01 | POWER ON | Registration Sensor | PS4550 |
| 00 | 0A05 | POWER ON | Fixing Arch Sensor | PS4500 |
| 00 | 0A06 | POWER ON | Fixing Output Sensor | PS4650 |
| 00 | 0A07 | POWER ON | Delivery Paper Full Sensor | PS4450 |
| 00 | 0A08 | POWER ON | Duplex Feed Sensor | PS4700 |
| 00 | 0A09 | POWER ON | Registration Sensor | PS4550 |


| ACC ID | Jam Code | Type | Sensor Name / Description | Sensor ID |
|--------|----------|---------|---------------------------|-----------|
| 00 | 0B00 | DOOR OP | Door Open | - |
| 00 | 0CF1 | ERROR | Error Avoidance Jam | - |
| 00 | 0D00 | OTHER | Size Error | - |

ADF / Reader




| ACC ID | Jam Code | Type | Sensor Name | Sensor ID |
|--------|----------|----------|------------------------|-----------|
| 01 | 0001 | DELAY | Registration Sensor | REG |
| 01 | 0002 | STNRY | Registration Sensor | REG |
| 01 | 0009 | DELAY | Document End Sensor | SR4206 |
| 01 | 0010 | STNRY | Document End Sensor | SR4206 |
| 01 | 0013 | DELAY | Delivery Sensor | SR2 |
| 01 | 0014 | STNRY | Delivery Sensor | SR2 |
| 01 | 0020 | OTHER | - | - |
| 01 | 0021 | OTHER | - | - |
| 01 | 0042 | DELAY | Registration Sensor | REG |
| 01 | 0049 | DELAY | Document End Sensor | SR4206 |
| 01 | 0050 | STNRY | Document End Sensor | SR4206 |
| 01 | 0053 | DELAY | Delivery Sensor | SR2 |
| 01 | 0054 | STNRY | Delivery Sensor | SR2 |
| 01 | 0060 | OTHER | - | - |
| 01 | 0061 | OTHER | - | - |
| 01 | 0062 | OTHER | - | - |
| 01 | 0063 | OTHER | - | - |
| 01 | 0071 | OTHER | - | - |
| 01 | 0090 | DOOR OP | ADF Open/Closed Sensor | SR4 |
| 01 | 0091 | DOOR OP | ADF Open/Closed Sensor | SR4 |
| 01 | 0092 | DOOR OP | ADF Cover Sensor | SR5 |
| 01 | 0093 | DOOR OP | ADF Cover Sensor | SR5 |
| 01 | 0094 | OTHER | - | - |
| 01 | 0095 | OTHER | - | - |
| 01 | 0096 | OTHER | - | - |
| 01 | 00A1 | POWER ON | Registration Sensor | REG |
| 01 | 00A4 | POWER ON | Document End Sensor | SR4206 |
| 01 | 00A6 | POWER ON | Delivery Sensor | SR2 |


Option Cassette



Cassette Module-AG/Envelope Cassette Module-A1




Cassette Feeding Unit-AR1



High Capacity Cassette Feeding Unit-D1

| ACC ID | Jam Code | Type | Sensor Name / Description | Sensor ID |
|--------|----------|----------|----------------------------|-----------------|
| 00 | 0102 | DELAY | CST 2 Vertical Path Sensor | PS602/PS3/PS101 |
| 00 | 0103 | DELAY | CST 3 Vertical Path Sensor | PS602/PS101 |
| 00 | 0104 | DELAY | CST 4 Vertical Path Sensor | PS602 |
| 00 | 0A02 | POWER ON | CST 2 Vertical Path Sensor | PS602/PS3/PS101 |
| 00 | 0A03 | POWER ON | CST 3 Vertical Path Sensor | PS602/PS101 |
| 00 | 0A04 | POWER ON | CST 4 Vertical Path Sensor | PS602 |

Inner Finisher



| ACC ID | Jam Code | Type | Sensor Name / Description | Sensor ID |
|--------|----------|----------|-----------------------------|-----------|
| 02 | 0A0A | POWER ON | Staple Stacker Inlet Sensor | PS210 |
| 02 | 0A0B | POWER ON | Staple Inlet Sensor | PS203 |
| 02 | 0A0C | POWER ON | Staple Stacker Exit Sensor | PS202 |
| 02 | 100A | DELAY | Staple Stacker Inlet Sensor | PS210 |
| 02 | 100B | DELAY | Staple Inlet Sensor | PS203 |
| 02 | 100C | DELAY | Staple Stacker Exit Sensor | PS202 |
| 02 | 110A | STNRY | Staple Stacker Inlet Sensor | PS210 |
| 02 | 110B | STNRY | Staple Inlet Sensor | PS203 |
| 02 | 110C | STNRY | Staple Stacker Exit Sensor | PS202 |
| 02 | 1200 | OTHER | - | - |
| 02 | 130A | POWER ON | Staple Stacker Inlet Sensor | PS210 |
| 02 | 130B | POWER ON | Staple Inlet Sensor | PS203 |
| 02 | 130C | POWER ON | Staple Stacker Exit Sensor | PS202 |
| 02 | 1400 | DOOR OP | Door Open | - |
| 02 | 1500 | STAPLE | Stapler | PS215 |
| 02 | 1F00 | OTHER | - | - |



Service Mode

| | |
|--|-----|
| Overview..... | 343 |
| COPIER (Service mode for printer)... | 360 |
| FEEDER (ADF service mode)..... | 548 |
| BOARD (Option board setting mode) | 553 |
| FAX (Service Mode for FAX)..... | 554 |

Overview

It is possible to see each item of service mode so that those who access to service mode can understand how to use them. The main types of this machine's service mode are shown below.

Basic Operations


This section describes the basic operation of service mode.

■ Entering Service Mode

For information on how to enter service mode, contact the Support Dept. of the sales company.

■ Service Mode Menu

Press the button in the service mode menu to display the initial screen of each mode. The differences between these modes are described below.



Top Screen

MODELIST

In this mode, functions for referring to each item in service mode, etc. are available.

Updater

This button is used to access the CDS and UGW servers and update system software.

BACKUP

This button is used to back up the service mode setting values.

RESTORE

This button is used to restore the service mode setting values backed up by [BACKUP].

SITUATION

This function displays service mode items according to the situation.

LUI MASK

This button is used to display a mask screen to prevent operations from being performed from the Control Panel while the service mode is being accessed from a remote PC.

NOTE:

For the detailed information on how to use Updater, BACKUP, and RESTORE, refer to the imageRUNNER ADVANCE System Service Manual.

■ Description of Service Mode Items


The description of the initial screen, the main items, the intermediate items and the sub items can be displayed. After selecting any item of the initial screen, main item, the intermediate item or the sub item, pressing "i" (Information Button) displays the description of the selected item (hereinafter referred to as the service mode contents).

CAUTION:


- Displayed language of the service mode contents can be selected from J/E/F/I/G/S/C/K/T.
- The service mode contents can be upgraded using SST or a USB flash drive just like other system software.

Example: COPIER > DISPLAY > VERSION screen

1. Press the [i] button.




2. The title of each sub item is displayed.



To check the details of each item, select the relevant item and press the [i] button.


3. A detailed description of the sub item (specifications and use methods, setting screen, etc.) is displayed.



■ Switching the Screen Display (Level 1 <->2)

Switching of screens between Level 1 and Level 2 becomes easier.

By pressing <LEVEL 1> at the upper right of the screen while Level 1 screen is displayed, the screen is switched to Level 2 screen.


**NOTE:**

This key combination can be used to enter the Level 2 screen.

- Mode List screen > [Settings/Registration] > [2]

SITUATION Mode

Situation mode has been implemented in this machine to improve workability and searchability at the site. This mode makes it possible to easily use the service mode appropriate for the scene at the site.




The following items are available in situation mode.

- Install:
To be referred at installation of the machine.
- Troubleshooting:
To be referred at problem solving.
- Parts Replacement:
To be referred at parts replacement.
- Major Adjustment:
To be referred at installation of the machine.
- Sensor Check:
To be referred at checking of the sensor.
- Part Check:
To be referred at operation check of the part.

The following three points are made available depending on each situation:

- Display of related service mode that requires adjustment
- Display of causes and remedies
- Display of related images




■ How to Use Sensor Check


In the Sensor Check of situation mode, the target electrical component can be searched. The operation procedure is shown below.

1. Start service mode.

2. Select "SITUATION".




3. On the "SITUATION MODE" screen, select "Sensor Check".




4. Press a button according to the type of electrical component and the corresponding device type.


Example: In the case of the Registration Sensor of the host machine, press the button (red dotted frame) at "COPIER"/"P-SENSOR".




5. A list of electrical component types for the selected device is displayed.



6. Select an electrical component to display the details in the frame (red dotted frame) at the bottom of the screen.



7. Press the [i] button to display the screen showing the locations of electrical components.



■ How to Use Parts Check

In the Parts Check of situation mode, among electrical components used (motors, fans, solenoids, and clutches), those that can operate alone can be operated from the screen and the operations can be checked. The operation procedure is shown below.


NOTE:

The service mode used below utilizes the system where electrical components used are operated by control signals sent from the DC Controller. If a control signal is sent but the electrical component does not operate, a failure of the electrical component, open circuit of the cable for transmitting control signals, or poor contact of the connector is suspected.


1. Select **SERVICE MODE > SITUATION > Parts Check**.

2. Press a button according to the type of electrical component and the corresponding device type.


Example: In the case of a motor of the host machine, press the button (red dotted frame) at "COPIER"/"MOTOR".





3. A list of electrical component types for the selected device whose operation can be checked is displayed.




4. Select the electrical component you want to operate and then press the Start button to send a signal for driving the selected electrical component for a specified period of time from the DC Controller.




5. "ACTIVE" is displayed while the electrical component is driven. After the electrical component has been driven for a specified period of time, "OK!" is displayed if transmission of the drive signal succeeded, or "NG !" is displayed if failed.



Press the [i] button to display the screen showing the locations of electrical components.



6. The screen showing the locations of electrical components is displayed.



Security Support

A password can be specified to prevent unauthorized access to the service mode.

Related Service Mode:

Setting password type when the screen is switched to the service mode

- COPIER > OPTION > FNC-SW > PSWD-SW (Level 1)

The password for service engineer when the screen is switched to the service mode

- (Level 2) COPIER > OPTION > FNC-SW > SM-PSWD

■ Procedure for Setting Password

1. Set "1" or "2" in the following service mode.


- COPIER > OPTION > FNC-SW > PSWD-SW
<Setting range>
0: No password [Default]
1: Service technician
2: System administrator + Service technician

CAUTION:


- This setting is enabled without restarting the host machine.
- After setting the password, the following screen will be displayed by accessing service mode.
- Therefore, when the PSWD-SW is set to "2" (system administrator + service technician), enter the system administrator password ([System Manager ID] and [System Manager PIN] in [Settings/Registrations] > [Management Settings] > [User Management] > [System Manager Information Settings]), and then press the [OK] button.

2. Follow the following procedure to check that you can login to service mode.

1. When setting PSWD-SW to "1" (system administrator) or "2" (ServiceMode_070Backup) in step 1, the system administrator password entry screen will be displayed, so enter the system administrator ID in [Sys Manager ID] (1) and system administrator password in [Password] (2), and then press the [OK] button.




2. When setting PSWD-SW to "2" (system administrator + service technician) in step 1, the service technician password entry screen will be displayed after step 2. Enter the service technician password in [Password] (1), and then press the [OK] button.



CAUTION:

- The service technician password is the password set in COPIER > OPTION > FNC-SW > SM-PSWD.
- If you forget the password for service technician, disable the password function using the Service Support Tool (SST).

Check that you can access service mode and finish the work.




■ Function to Mask the Screen during Remote Access

This function ensures security during servicing work using remote connection.


The machine has an option called Remote Operation Viewer for remote control via a network. This option enables a service technician to perform maintenance on the machine from a remote location.

However, the same screen is displayed on the Remote Operation Viewer screen and the Control Panel during the work, which carries the following risks.

- The screen being operated can be seen by the user.
- During remote operation, the user may perform an operation on the Control Panel and an unexpected processing may be executed.



To solve these security problems, a function has been added to display a message on the Control Panel screen when the machine is being operated remotely using Remote Operation Viewer in order to prevent the user from performing unexpected operations. As shown in the figure below, the mask screen is displayed when this function is enabled.



Examples of Screen Display

Functional Specification

The specifications of this function are shown below.

- When this function is enabled, a mask screen is displayed on the Control Panel. When the function is disabled, the original screen is displayed again.




Example of the displayed mask screen

- This function is disabled when the following operations are performed.
 - Press [LUI MASK] on the service mode top screen.
 - Exit Remote Operation Viewer.
 - The remote access is disconnected due to a network failure, etc.
 - The machine is shut down (power down) or restarted.
- If this function is disabled while the service mode is being operated, the service mode is forcibly exited, and the previous screen is displayed. (However, the service mode is not forcibly terminated if the Updater screen has been accessed from service mode.)
- When this function is enabled, all operations (operations from the Touch Panel or hardware keys) other than screen brightness adjustment and operation on the Energy Saver key are disabled.

● Procedure for Enabling This Function

The procedure for enabling this function is shown below.


- Use the Remote Operation Viewer to access the machine, and start service mode.
- Press [LUI MASK], and check that the button is enabled (has turned light blue).



● Procedure for Disabling This Function

The procedure for disabling this function is shown below.


- Perform one of the following operations.
 - Access the service mode, press [LUI MASK], and check that the button is disabled (has turned gray).



- Exit the Remote Operation Viewer.
- Disconnect the network (disconnect the network cable, disable the network function, etc.).
- Shut down or restart the machine.

Service Mode Backup

Adjustment is made to every machine at the time of shipment to write the adjustment value in the service label. When replacing the DC Controller PCB or clearing RAM, the adjusted values of ADJUST and OPTION return to the default; therefore, be sure to adjust the value in the field, and in the case of changing the service mode value, be sure to write down the changed value in the service label. When the corresponding item is not found on the service label, write the value in blank field.



Place of service label

Output of Service Print Data

- The service print data such as P-PRINT can be output as a file.
- By executing the following service mode, data at the time can be saved in the HDD.
Service Mode Level 1 > Copier > Function > MISC-P > RPT-FILE
- The saved data will be deleted from the HDD when it is exported to SST or a USB flash drive.
- When multiple service data such as P-PRINT and HIST-PRINT is saved in the HDD of the host machine, it is collectively exported to SST or a USB flash drive.
- It can be exported to SST or a USB flash drive by entering download mode even when the host machine has stopped because of no paper.

NOTE:

- Service print data cannot be output when an error has occurred.
- When connecting a USB flash drive that runs on external power, start the machine with the power is turned ON in advance. A USB flash drive connected after the machine has been started cannot be recognized.

| How to obtain the report data | Location |
|--|-----------------|
| "Moving the file in service mode" on page 356 | USB flash drive |
| "Moving the file in download mode" on page 357 | USB flash drive |
| "How to Export Service Print File to a PC Using SST" on page 358 | PC |

Service Prints and Data File Names That Support File Output

| Service Mode | Content |
|--------------------------------------|--------------------------------------|
| COPIER > Function > MISC-P > P-PRINT | Output of service mode setting value |

| Service Mode | Content |
|---------------------------------------|--|
| COPIER > Function > MISC-P > HIST-PRT | Output of jam and error history |
| COPIER > Function > MISC-P > USER-PRT | Output of UI menu list |
| COPIER > Function > MISC-P > D-PRINT | Output of service mode (DISPLAY) |
| COPIER > Function > MISC-P > ENV-PRT | Inside temp/hmdy & fix roller temp log |
| COPIER > Function > MISC-P > PJH-P-1 | Detail info of print job history:100 job |
| COPIER > Function > MISC-P > PJH-P-2 | Detail info of print job history:all job |
| COPIER > Function > MISC-P > USBH-PRT | Output of USB device information report |
| COPIER > Function > MISC-P > TNRB-RPT | Output of Toner Container ID report |

NOTE:

When each service mode is individually executed, the report corresponding to the service mode as of the time of execution is output.

■ Moving the file in service mode

Preparation

The following item needs to be prepared to export the service print file to a USB flash drive.

- USB flash drive (FAT32 format file system that is not locked with a password. To display the USB menu, the said model's firmware must already be registered.)


Overall flow

1. Selecting RPT-FILE
Select service mode > Copier > Function > MISC-P > RPT-FILE; and then press OK.
2. Generating report file
After the "ACTIVE" blinks for 3 to 4 minutes, generation of a report file is complete as "OK!" is displayed.



3. Connect the USB flash drive storage device to the USB port.

4. Select service mode > Copier > Function > MISC-P > RPT2USB; and then press OK.



NOTE:

- If the downloaded file is opened as plain text, the paragraphs are misaligned, which makes it difficult to read the data.
- When the file is dragged to WordPad, an image similar to the image output on paper may be displayed in some cases.

■ Moving the file in download mode

Preparation

The following item needs to be prepared to export the service print file to a USB flash drive.

- USB flash drive (FAT32 format file system that is not locked with a password. To display the USB menu, the said model's firmware must already be registered.)

Overall flow

1. Selecting RPT-FILE
Select service mode > Copier > Function > MISC-P > RPT-FILE; and then press OK.
2. Generating report file
After the "ACTIVE" blinks for 3 to 4 minutes, generation of a report file is complete as "OK!" is displayed.



3. Execute Download mode > [5]: Download File > [4]: ServicePrint Download.

```

[[[[[[[ Download File Menu (USB) ]]]]]]]
-----
[1]: SUBLOG Download
[4]: ServicePrint Download
[C]: Return to Main Menu

[Reset]: Start shutdown sequence

/[4] has been selected. Execute?/
- (OK) : 0 / (CANCEL) : Any other keys -

```




リムーバブルディスク (F:) > iAC3330 > QUC00005 > SP201505211916L

| 名前 | 更新日時 | 種類 | サイズ |
|------------------|------------------|-------------|-------|
| D-PRINT-RPT.TXT | 2015/05/21 19:16 | テキスト ドキュ... | 12 KB |
| ENV-PRT-RPT.TXT | 2015/05/21 19:16 | テキスト ドキュ... | 3 KB |
| HIST-PRT-RPT.TXT | 2015/05/21 19:16 | テキスト ドキュ... | 13 KB |
| KEY-HIST-RPT.TXT | 2015/05/21 19:16 | テキスト ドキュ... | 1 KB |
| PJH-P-1-RPT.TXT | 2015/05/21 19:16 | テキスト ドキュ... | 1 KB |
| PJH-P-2-RPT.TXT | 2015/05/21 19:16 | テキスト ドキュ... | 1 KB |
| P-PRINT-RPT.TXT | 2015/05/21 19:16 | テキスト ドキュ... | 85 KB |
| TNRB-RPT.TXT | 2015/05/21 19:16 | テキスト ドキュ... | 1 KB |
| USBH_PRT-RPT.TXT | 2015/05/21 19:16 | テキスト ドキュ... | 1 KB |
| USER-PRT-RPT.TXT | 2015/05/21 19:16 | テキスト ドキュ... | 7 KB |


■ How to Export Service Print File to a PC Using SST

The procedure for exporting the service print file to a PC using SST will now be described. (SST described in the procedure is Ver 4.72.)


1. Start the SST.
2. Select the model [1] to be connected and the information file for separate download [2] ([Single]). Then, check the network settings and click the "Start" button.




3. Click the [Upload Data] button.



4. Select [Report] and click the [Start] button.



5. Specify the folder name to be saved and enter comments if necessary. Then click the [Store] button.



6. Click the [OK] button.

COPIER (Service mode for printer)

DISPLAY (State display mode)

VERSION

COPIER (Service mode for printer) > DISPLAY (State display mode) > VERSION

| | | |
|-------------------------------|----------|--|
| DC-CON | 1 | Display of DCON firmware version |
| Detail | | To display the firmware version of DC Controller PCB. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| R-CON | 1 | Display of RCON firmware version |
| Detail | | To display the firmware version of RCON. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| PANEL | 1 | Dspl of Control Panel CPU PCB ROM ver |
| Detail | | To display the ROM version of Control Panel CPU PCB. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| SORTER | 1 | Dspl of FIN-CONT (Main) firmware version |
| Detail | | To display the firmware version of Finisher Controller PCB (Main). |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| NIB | 1 | Display of network software version |
| Detail | | To display the version of the network software. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MN-CONT | 1 | Display of MNCON firmware version |
| Detail | | To display the firmware version of Main Controller PCB. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-FR | 1 | Display of French language file version |
| Detail | | To display the version of French language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |

COPIER (Service mode for printer) > DISPLAY (State display mode) > VERSION

| | | |
|-------------------------------|----------|--|
| LANG-DE | 1 | Display of German language file version |
| Detail | | To display the version of German language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-IT | 1 | Display of Italian language file version |
| Detail | | To display the version of Italian language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-CS | 2 | Display of Czech language file version |
| Detail | | To display the version of Czech language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-DA | 2 | Display of Danish language file version |
| Detail | | To display the version of Danish language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-EL | 2 | Display of Greek language file version |
| Detail | | To display the version of Greek language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-ES | 1 | Display of Spanish language file version |
| Detail | | To display the version of Spanish language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-ET | 2 | Display of Estonian language file ver |
| Detail | | To display the version of Estonian language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-FI | 2 | Display of Finnish language file version |
| Detail | | To display the version of Finnish language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-HU | 2 | Display of Hungarian language file ver |
| Detail | | To display the version of Hungarian language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |

COPIER (Service mode for printer) > DISPLAY (State display mode) > VERSION

| | | |
|-------------------------------|----------|--|
| LANG-KO | 2 | Display of Korean language file version |
| Detail | | To display the version of Korean language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-NL | 2 | Display of Dutch language file version |
| Detail | | To display the version of Dutch language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-NO | 2 | Display of Norwegian language file ver |
| Detail | | To display the version of Norwegian language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-PL | 2 | Display of Polish language file version |
| Detail | | To display the version of Polish language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-PT | 2 | Display of Portuguese language file ver |
| Detail | | To display the version of Portuguese language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-RU | 2 | Display of Russian language file version |
| Detail | | To display the version of Russian language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-SL | 2 | Display of Slovenian language file ver |
| Detail | | To display the version of Slovenian language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-SV | 2 | Display of Swedish language file version |
| Detail | | To display the version of Swedish language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-TW | 2 | Display of Chinese language file ver: trad |
| Detail | | To display the version of Chinese language file (traditional). |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |

COPIER (Service mode for printer) > DISPLAY (State display mode) > VERSION

| | | |
|-------------------------------|----------|---|
| LANG-ZH | 2 | Dspl of Chinese language file ver: simpl |
| Detail | | To display the version of Chinese language file (simplified). |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-BU | 2 | Display of Bulgarian language file ver |
| Detail | | To display the version of Bulgarian language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-CR | 2 | Display of Croatian language file ver |
| Detail | | To display the version of Croatian language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-RM | 2 | Display of Romanian language file ver |
| Detail | | To display the version of Romanian language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-SK | 2 | Display of Slovak language file version |
| Detail | | To display the version of Slovak language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-TK | 2 | Display of Turkish language file version |
| Detail | | To display the version of Turkish language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| LANG-CA | 2 | Display of Catalan language file version |
| Detail | | To display the version of Catalan language file. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-JA | 2 | Dspl of Japanese media information ver |
| Detail | | To display the version of Japanese media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-EN | 2 | Dspl of English media information ver |
| Detail | | To display the version of English media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |

COPIER (Service mode for printer) > DISPLAY (State display mode) > VERSION

| | | |
|-------------------------------|----------|---|
| MEDIA-DE | 2 | Dspl of German media information version |
| Detail | | To display the version of German media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-IT | 2 | Dspl of Italian media information ver |
| Detail | | To display the version of Italian media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-FR | 2 | Dspl of French media information version |
| Detail | | To display the version of French media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-ZH | 2 | Dspl of Chinese media info ver: simpl |
| Detail | | To display the version of Chinese media information (simplified). |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-SK | 2 | Dspl of Slovak media information version |
| Detail | | To display the version of Slovak media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-TK | 2 | Dspl of Turkish media information ver |
| Detail | | To display the version of Turkish media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-CS | 2 | Dspl of Czech media information version |
| Detail | | To display the version of Czech media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-EL | 2 | Dspl of Greek media information version |
| Detail | | To display the version of Greek media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-ES | 2 | Dspl of Spanish media information ver |
| Detail | | To display the version of Spanish media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |

COPIER (Service mode for printer) > DISPLAY (State display mode) > VERSION

| | | |
|-------------------------------|----------|---|
| MEDIA-ET | 2 | Dspl of Estonian media information ver |
| Detail | | To display the version of Estonian media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-FI | 2 | Dspl of Finnish media information ver |
| Detail | | To display the version of Finnish media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-HU | 2 | Dspl of Hungarian media information ver |
| Detail | | To display the version of Hungarian media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-KO | 2 | Dspl of Korean media information version |
| Detail | | To display the version of Korean media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-NL | 2 | Dspl of Dutch media information version |
| Detail | | To display the version of Dutch media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-NO | 2 | Dspl of Norwegian media information ver |
| Detail | | To display the version of Norwegian media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-PL | 2 | Dspl of Polish media information version |
| Detail | | To display the version of Polish media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-PT | 2 | Dspl of Portuguese media information ver |
| Detail | | To display the version of Portuguese media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-RU | 2 | Dspl of Russian media information ver |
| Detail | | To display the version of Russian media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |

COPIER (Service mode for printer) > DISPLAY (State display mode) > VERSION

| | | |
|-------------------------------|----------|--|
| MEDIA-SL | 2 | Dspl of Slovenian media information ver |
| Detail | | To display the version of Slovenian media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-SV | 2 | Dspl of Swedish media information ver |
| Detail | | To display the version of Swedish media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-TW | 2 | Dspl of Chinese media info version:trad |
| Detail | | To display the version of Chinese media information (traditional). |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-BU | 2 | Dspl of Bulgarian media information ver |
| Detail | | To display the version of Bulgarian media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-CR | 2 | Dspl of Croatian media information ver |
| Detail | | To display the version of Croatian media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-RM | 2 | Dspl of Romanian media information ver |
| Detail | | To display the version of Romanian media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| MEDIA-CA | 2 | Dspl of Catalan media information ver |
| Detail | | To display the version of Catalan media information. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| FAX1 | 1 | Display of 1-line FAX PCB ROM version |
| Detail | | To display the ROM version of 1-line FAX PCB. Nothing is displayed if the PCB is not connected. |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | ASCII character string (21 digits) |

COPIER (Service mode for printer) > DISPLAY (State display mode) > VERSION

| | | |
|-----------------|-------------------------------|--|
| FAX2/3/4 | 1 | Dspl of 2/3/4-line FAX PCB ROM version |
| | Detail | To display the ROM version of 2/3/4-line FAX PCB. Nothing is displayed if the PCB is not connected. |
| | Use Case | When checking the version |
| | Adj/Set/Operate Method | N/A (Display only) |
| | Display/Adj/Set Range | ASCII character string (21 digits) |
| IOCS | 1 | Display of BIOS version |
| | Detail | To display the BIOS version. |
| | Use Case | When upgrading the firmware |
| | Adj/Set/Operate Method | N/A (Display only) |
| | Display/Adj/Set Range | 00.01 to 99.99 |
| S-LNG-JP | 1 | Dspl of service mode Japanese file ver |
| | Detail | To display the version of Japanese language file in service mode. |
| | Use Case | When upgrading the firmware |
| | Adj/Set/Operate Method | N/A (Display only) |
| | Display/Adj/Set Range | 00.01 to 99.99 |
| S-LNG-EN | 1 | Dspl of service mode English file ver |
| | Detail | To display the version of English language file in service mode. |
| | Use Case | When upgrading the firmware |
| | Adj/Set/Operate Method | N/A (Display only) |
| | Display/Adj/Set Range | 00.01 to 99.99 |
| S-LNG-FR | 1 | Dspl of service mode French file version |
| | Detail | To display the version of French language file in service mode. |
| | Use Case | When upgrading the firmware |
| | Adj/Set/Operate Method | N/A (Display only) |
| | Display/Adj/Set Range | 00.01 to 99.99 |
| S-LNG-IT | 1 | Dspl of service mode Italian file ver |
| | Detail | To display the version of Italian language file in service mode. |
| | Use Case | When upgrading the firmware |
| | Adj/Set/Operate Method | N/A (Display only) |
| | Display/Adj/Set Range | 00.01 to 99.99 |
| S-LNG-GR | 1 | Dspl of service mode German file version |
| | Detail | To display the version of German language file in service mode. |
| | Use Case | When upgrading the firmware |
| | Adj/Set/Operate Method | N/A (Display only) |
| | Display/Adj/Set Range | 00.01 to 99.99 |
| S-LNG-SP | 1 | Dspl of service mode Spanish file ver |
| | Detail | To display the version of Spanish language file in service mode. |
| | Use Case | When upgrading the firmware |
| | Adj/Set/Operate Method | N/A (Display only) |
| | Display/Adj/Set Range | 00.01 to 99.99 |
| BCT | 1 | Display of self diagnosis tool version |
| | Detail | To display the version of self diagnosis tool. |
| | Use Case | When upgrading the firmware |
| | Adj/Set/Operate Method | N/A (Display only) |
| | Display/Adj/Set Range | 00.01 to 99.99 |

COPIER (Service mode for printer) > DISPLAY (State display mode) > VERSION

| | | |
|-------------------------------|---|---|
| LANG-TH | 2 | Display of Thai language file version |
| Detail | To display the version of Thai language file. | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| LANG-VN | 2 | Display of Vietnamese language file ver |
| Detail | To display the version of Vietnamese language file. | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| LANG-AR | 2 | Dsplt of Arabic language file ver |
| Detail | To display the version of Arabic language file. | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| LANG-MS | 2 | Dsplt of Malay language file ver |
| Detail | To display the version of Malay language file. | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| LANG-HI | 2 | Dsplt of Hindi language file ver |
| Detail | To display the version of Hindi language file. | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| LANG-EU | 2 | Dsplt of Euskera language file ver |
| Detail | To display the version of Euskera language file. | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| OPT-CAS1 | 1 | Dsplt option Cassette 1 firmware version |
| Detail | To display the firmware version of option Cassette 1. | |
| Use Case | When checking the firmware version | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.00 to 99.99 | |
| Default Value | 0 | |
| OPT-CAS2 | 1 | Dsplt option Cassette 2 firmware version |
| Detail | To display the firmware version of option Cassette 2. | |
| Use Case | When checking the firmware version | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.00 to 99.99 | |
| Default Value | 0 | |

COPIER (Service mode for printer) > DISPLAY (State display mode) > VERSION

| | | |
|-------------------------------|----------|--|
| OPT-CAS3 | 1 | Dspl option Cassette 3 firmware version |
| Detail | | To display the firmware version of option Cassette 3. |
| Use Case | | When checking the firmware version |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.00 to 99.99 |
| Default Value | | 0 |
| RPTL-CS | 2 | Dspl RUI Portal Czech file version |
| Detail | | To display the version of Czech language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| RPTL-DA | 2 | Dspl RUI Portal Danish file version |
| Detail | | To display the version of Danish language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| RPTL-EL | 2 | Dspl RUI Portal Greek file version |
| Detail | | To display the version of Greek language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| RPTL-ET | 2 | Dspl RUI Portal Estonian file version |
| Detail | | To display the version of Estonian language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| RPTL-FI | 2 | Dspl RUI Portal Finnish file version |
| Detail | | To display the version of Finnish language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| RPTL-HU | 2 | Dspl RUI Portal Hungarian file version |
| Detail | | To display the version of Hungarian language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| RPTL-NL | 2 | Dspl RUI Portal Dutch file version |
| Detail | | To display the version of Dutch language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |

COPIER (Service mode for printer) > DISPLAY (State display mode) > VERSION

| | | |
|-------------------------------|----------|---|
| RPTL-NO | 2 | Dspl RUI Portal Norwegian file version |
| Detail | | To display the version of Norwegian language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| RPTL-PL | 2 | Dspl RUI Portal Polish file version |
| Detail | | To display the version of Polish language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| RPTL-PT | 2 | Dspl RUI Portal Portuguese file version |
| Detail | | To display the version of Portuguese language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| RPTL-RU | 2 | Dspl RUI Portal Russian file version |
| Detail | | To display the version of Russian language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| RPTL-SL | 2 | Dspl RUI Portal Slovenian file version |
| Detail | | To display the version of Slovenian language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| RPTL-SV | 2 | Dspl RUI Portal Swedish file version |
| Detail | | To display the version of Swedish language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| RPTL-ID | 2 | Dspl RUI Portal Indonesian file version |
| Detail | | To display the version of Indonesian language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| RPTL-BU | 2 | Dspl RUI Portal Bulgarian file version |
| Detail | | To display the version of Bulgarian language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |
| RPTL-CR | 2 | Dspl RUI Portal Croatian file version |
| Detail | | To display the version of Croatian language file for "Remote UI: Portal". |
| Use Case | | When upgrading the firmware |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 00.01 to 99.99 |

COPIER (Service mode for printer) > DISPLAY (State display mode) > VERSION

| | | |
|-------------------------------|---|--|
| RPTL-RM | 2 | Dspl RUI Portal Romanian file version |
| Detail | To display the version of Romanian language file for "Remote UI: Portal". | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| RPTL-SK | 2 | Dspl RUI Portal Slovak file version |
| Detail | To display the version of Slovak language file for "Remote UI: Portal". | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| RPTL-TK | 2 | Dspl RUI Portal Turkish file version |
| Detail | To display the version of Turkish language file for "Remote UI: Portal". | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| RPTL-CA | 2 | Dspl RUI Portal Catalan file version |
| Detail | To display the version of Catalan language file for "Remote UI: Portal". | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| RPTL-TH | 2 | Dspl RUI Portal Thai file version |
| Detail | To display the version of Thai language file for "Remote UI: Portal". | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| RPTL-VN | 2 | Dspl RUI Portal Vietnamese file version |
| Detail | To display the version of Vietnamese language file for "Remote UI: Portal". | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| SORT-SLV | 1 | Dspl of FIN-CONT (Sub) firmware version |
| Detail | To display the firmware version of Finisher Controller PCB (Sub). | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| CONT-PF | 1 | Display of Controller firmware version |
| Detail | To display the platform version of the controller. | |
| Use Case | When checking the platform version at upgrade/problem occurrence | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| LANG-HE | 2 | Display of Hebrew language file version |
| Detail | To display the version of Hebrew language file. | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |

COPIER (Service mode for printer) > DISPLAY (State display mode) > VERSION

| | | |
|-------------------------------|--|---|
| LANG-LT | 2 | Dspl of Lithuanian language file version |
| Detail | To display the version of Lithuanian language file. | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| LANG-LV | 2 | Display of Latvian language file version |
| Detail | To display the version of Latvian language file. | |
| Use Case | When upgrading the firmware | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.01 to 99.99 | |
| OPT-ENV1 | 1 | Dspl Env. Cassette 2 firmware version |
| Detail | To display the firmware version of option Cassette 2 (envelope option) | |
| Use Case | When checking the firmware version | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.00 to 99.99 | |
| Default Value | 0 | |
| OPT-ENV2 | 1 | Dspl Env. Cassette 3 firmware version |
| Detail | To display the firmware version of option Cassette 3 (envelope option) | |
| Use Case | When checking the firmware version | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 00.00 to 99.99 | |
| Default Value | 0 | |

■ USER

COPIER (Service mode for printer) > DISPLAY (State display mode) > USER

| | | |
|-------------------------------|---|-------------------------------------|
| SPDTYPE | 1 | Display of engine speed type |
| Detail | To display the engine speed type of this machine. | |
| Use Case | When checking the engine speed type | |
| Adj/Set/Operate Method | N/A (Display only) | |
| ADFTYPE | 1 | Display of DADF type |
| Detail | To display the type of the DADF currently installed. | |
| Use Case | When replacing the DADF | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 2 0: Reverse type, 1: 1-path type, 2: Not installed (Copyboard model) | |
| Related Service Mode | COPIER> OPTION> CUSTOM> SCANTYPE | |

■ ACC-ST5

COPIER (Service mode for printer) > DISPLAY (State display mode) > ACC-ST5

| | | |
|-------------------------------|---|---|
| FEEDER | 1 | Display of DADF connection state |
| Detail | To display the connecting state of DADF. | |
| Use Case | When checking the connection between the machine and DADF | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 1 0: Not connected, 1: Connected | |

COPIER (Service mode for printer) > DISPLAY (State display mode) > ACC-ST5

| | | |
|----------------------------------|----------|---|
| SORTER | 1 | Connect state of Finisher-related option |
| Detail | | To display the connection state of Finisher-related options. |
| Use Case | | When checking the connection of Finisher-related options |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | Left column (connection state of Finisher-related options): 1 to 5 1: Without Saddle 2: With Saddle, without Folding Unit 3: With Saddle and Inserter, without Folding Unit 4: With Saddle and Folding Unit, without Inserter 5: With Saddle, Inserter and Folding Unit Right column (connection state of Finisher-belonged Puncher): 0 to 4 0: No hole, 1: 2-hole, 2/4-hole switching, 2: 3-hole, 2/3-hole, 2/3-hole switching, 3: 4-hole, 4: 4-hole (SW) |
| DECK | 1 | Display of Paper Deck connection state |
| Detail | | To display the connecting state of the Paper Deck. |
| Use Case | | When checking the connection between the machine and the Paper Decks |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 0 to 5 0: Not connected, 1: Connected, 2 to 4: Not used, 5: Multi-purpose Tray only |
| CARD | 1 | Dspl of connection state of Card Reader |
| Detail | | To display the connecting state of Card Reader. |
| Use Case | | When checking the connection between the machine and the Card Reader |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 0 to 1 0: No card is inserted while the Card Reader is connected. (Copy is not available.) 1: Card Reader is not connected, or card is inserted while the Card Reader is connected. (Copy is available.) |
| RAM | 1 | Display of MNCON PCB memory capacity |
| Detail | | To display the memory capacity of the Main Controller PCB. |
| Use Case | | When checking the memory capacity of the machine |
| Adj/Set/Operate Method | | N/A (Display only) |
| Unit | | MB |
| Amount of Change per Unit | | 1 |
| COINROBO | 1 | Dspl of Coin Manager connection state |
| Detail | | To display the connecting state of the Coin Manager. |
| Use Case | | When checking the connection between the machine and the Coin Manager |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 0 to 1 0: Not connected, 1: Connected |
| HDD | 1 | Display of HDD model name |
| Detail | | To display the model name of HDD. |
| Use Case | | When checking the model name of HDD used on the machine |
| Adj/Set/Operate Method | | N/A (Display only) |

COPIER (Service mode for printer) > DISPLAY (State display mode) > ACC-ST5

| | | |
|----------------------------------|----------|---|
| IA-RAM | 1 | Dspl of MNCON PCB 1 DDR2-SDRAM capacity |
| Detail | | To display the memory (DDR2-SDRAM) capacity of the Main Controller PCB 1. |
| Use Case | | When checking the memory capacity of the Main Controller PCB |
| Adj/Set/Operate Method | | N/A (Display only) |
| Unit | | MB |
| Amount of Change per Unit | | 1 |

■ ANALOG

COPIER (Service mode for printer) > DISPLAY (State display mode) > ANALOG

| | | |
|------------------------------|----------|--|
| TEMP | 1 | Display of inside temperature |
| Detail | | To display the temperature inside the machine detected by Environment Sensor. |
| Use Case | | When checking the temperature inside the machine |
| Display/Adj/Set Range | | 0 to 60 |
| Default Value | | 0 |
| HUM | 1 | Display of inside humidity |
| Detail | | To display the humidity inside the machine detected by Environment Sensor. |
| Use Case | | When checking the humidity inside the machine |
| Display/Adj/Set Range | | 0 to 100 |
| Default Value | | 0 |
| FIX-C | 1 | Dspl of Fixing Roller center temperature |
| Detail | | To display the center temperature of the Fixing Roller detected by the Fixing Main Thermistor. |
| Use Case | | When checking the temperature at the center of Fixing Roller |
| Display/Adj/Set Range | | 0 to 999 |
| Unit | | deg C |
| Default Value | | 0 |
| FIX-E | 1 | Dspl of Fixing Roller edge temperature |
| Detail | | To display the edge temperature of the Fixing Roller detected by the Fixing Sub Thermistor 1. Fixing Sub Thermistor 1 is located in the drive side of Fixing Roller. |
| Use Case | | When checking the edge temperature of the Fixing Roller |
| Display/Adj/Set Range | | 0 to 999 |
| Unit | | deg C |
| Default Value | | 0 |
| FIX-E2 | 1 | Dspl of Fixing Roller edge temperature |
| Detail | | To display the edge temperature of the Fixing Roller detected by the Fixing Sub Thermistor 2. Fixing Sub Thermistor 2 is located in the non-drive side of Fixing Roller. |
| Use Case | | When checking the edge temperature of the Fixing Roller |
| Display/Adj/Set Range | | 0 to 999 |
| Default Value | | 0 |

■ CST-ST5

COPIER (Service mode for printer) > DISPLAY (State display mode) > CST-ST5

| TARGET-B | 2 | Shading target value (B) |
|---------------------------------|---|--|
| Detail | | To display the shading target value of Blue. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - At scanned image failure |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 0 to 2047 |
| Appropriate Target Value | | 512 - 2047 |
| TARGET-G | 2 | Shading target value (G) |
| Detail | | To display the target value of Green. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - At scanned image failure |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 0 to 2047 |
| Appropriate Target Value | | 512 - 2047 |
| TARGET-R | 2 | Shading target value (R) |
| Detail | | To display the shading target value of Red. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - At scanned image failure |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 0 to 2047 |
| Appropriate Target Value | | 512 - 2047 |

■ CCD

COPIER (Service mode for printer) > DISPLAY (State display mode) > CCD

| TARGET-B | 2 | Shading target value (B) |
|---------------------------------|---|--|
| Detail | | To display the shading target value of Blue. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - At scanned image failure |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 0 to 2047 |
| Appropriate Target Value | | 512 - 2047 |
| TARGET-G | 2 | Shading target value (G) |
| Detail | | To display the target value of Green. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - At scanned image failure |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 0 to 2047 |
| Appropriate Target Value | | 512 - 2047 |
| TARGET-R | 2 | Shading target value (R) |
| Detail | | To display the shading target value of Red. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - At scanned image failure |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 0 to 2047 |
| Appropriate Target Value | | 512 - 2047 |

■ MISC

COPIER (Service mode for printer) > DISPLAY (State display mode) > MISC

| | | |
|-------------------------------|----------|--|
| TNRB-IDK | 1 | Display of Bk-color Toner Container ID |
| Detail | | To display the ID of Bk-color Toner Container that is installed to the machine |
| Use Case | | When checking whether the barcode ID on the Toner Container is read correctly |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 28-digit decimal number |
| SD-INFO | 2 | For R&D |

● I/O

This item is not used because it is intended for R&D.

The I/O information can be found in service mode > SITUATION > Sensor Check.

● ADJUST (Adjustment mode)

■ AE

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > AE

| | | |
|-------------------------------|----------|---|
| AE-TBL | 1 | Adj of text density at image density adj |
| Detail | | To adjust text density according to the adjusted image density. As the greater value is set, text gets darker. |
| Use Case | | When clearing the RAM data of the Reader |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | When clearing the RAM data of the Reader, enter the value of service label. |
| Display/Adj/Set Range | | 1 to 9 |
| Default Value | | 5 |

■ ADJ-XY

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > ADJ-XY

| | | |
|----------------------------------|----------|---|
| ADJ-X | 1 | Adj read start pstn: Copyboard,vert scan |
| Detail | | To adjust the image reading start position (image leading edge position) in the vertical scanning direction at copyboard reading. As the value is incremented by 1, the image position is moved to the trailing edge side by 0.1 mm. Decrease the value when the non-image width is larger than the standard value. Increase the value when out of original area is copied. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. |
| Use Case | | When clearing the Reader-related RAM data/replacing the SATA Flash PCB |
| Adj/Set/Operate Method | | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | -30 to 30 |
| Unit | | mm |
| Default Value | | 0 |
| Amount of Change per Unit | | 0.1 |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > ADJ-XY

| | | |
|----------------------------------|--|---|
| ADJ-Y | 1 | Adj read start pstn: Copyboard,horz scan |
| Detail | To adjust the image reading start position in the horizontal scanning direction at copyboard reading. As the value is incremented by 1, the image position is moved to the rear side by 0.1 mm. Decrease the value when the non-image width is larger than the standard value. Increase the value when out of original area is copied. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | After the setting value is changed, write the changed value in the service label. | |
| Display/Adj/Set Range | -15 to 15 | |
| Unit | mm | |
| Default Value | 0 | |
| Amount of Change per Unit | 0.1 | |
| ADJ-S | 1 | Adjustment of Reader shading position |
| Detail | To adjust the Scanner Unit (Front) position in feed direction when reading the White Plate on the left edge of the Copyboard Glass. When replacing the Scanner Unit, execute RDSHDPOS and write the value of this item in the service label. When clearing the Reader-related RAM data, enter the value of service label. As the value is incremented by 1, the reading position moves to the trailing edge side by 0.1 mm. | |
| Use Case | - When black lines/white lines appear - When replacing the Scanner Unit (Front) - When clearing the Reader-related RAM data | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | After the setting value is changed, write the changed value in the service label. | |
| Display/Adj/Set Range | -20 to 20 | |
| Unit | mm | |
| Default Value | 0 | |
| Related Service Mode | COPIER> FUNCTION> INSTALL> RDSHDPOS | |
| Amount of Change per Unit | 0.1 | |
| ADJ-Y-DF | 1 | Adj read start pstn:DADF,front,horz scan |
| Detail | To adjust the front side image reading start position in horizontal scanning direction at DADF reading. As the value is incremented by 1, the image position is moved to the rear side by 0.1 mm. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | After the setting value is changed, write the changed value in the service label. | |
| Display/Adj/Set Range | -15 to 15 | |
| Unit | mm | |
| Default Value | 0 | |
| Amount of Change per Unit | 0.1 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > ADJ-XY

| | | |
|----------------------------------|---|---|
| STRD-POS | 1 | Adj frt side read pstn: DADF stream read |
| Detail | To adjust the Scanner Unit (Front) position in feed direction at DADF stream reading. As the value is changed by 1, the position moves by 0.1 mm. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | After the setting value is changed, write the changed value in the service label. | |
| Display/Adj/Set Range | -40 to 20 | |
| Unit | mm | |
| Default Value | 0 | |
| Related Service Mode | COPIER> FUNCTION> INSTALL> STRD-POS | |
| Amount of Change per Unit | 0.1 | |
| ADJ-X-MG | 1 | Fine adj img ratio: book mode, vert scan |
| Detail | To make a fine adjustment of image magnification ratio in vertical scanning direction at copyboard reading. As the value is changed by 1, the image magnification ratio is changed by 0.01%. +: Reduce -: Enlarge When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | After the setting value is changed, write the changed value in the service label. | |
| Display/Adj/Set Range | -200 to 200 | |
| Unit | % | |
| Default Value | 0 | |
| Amount of Change per Unit | 0.01 | |
| ADJY-DF2 | 1 | Adj read start pstn:DADF,back,horz scan |
| Detail | To adjust the back side image reading start position in horizontal scanning direction at DADF reading. As the value is incremented by 1, the image position is moved to the rear side by 0.1 mm. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | After the setting value is changed, write the changed value in the service label. | |
| Display/Adj/Set Range | -15 to 15 | |
| Unit | mm | |
| Default Value | 0 | |
| Amount of Change per Unit | 0.1 | |

■ CCD

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|--|---|
| W-PLT-X | 1 | Stdrd White Plt white lvl data (X) entry |
| Detail | To enter the white level data (X) for the Standard White Plate. When clearing the Reader-related RAM data/replacing the SATA Flash PCB/replacing the Copyboard Glass, enter the value of barcode label which is affixed on the glass. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Copyboard Glass | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 7000 to 9999 | |
| Default Value | 8273 | |
| Related Service Mode | COPIER> ADJUST> CCD> W-PLT-Y/Z | |
| Amount of Change per Unit | 1 | |
| W-PLT-Y | 1 | Stdrd White Plt white lvl data (Y) entry |
| Detail | To enter the white level data (Y) for the Standard White Plate. When clearing the Reader-related RAM data/replacing the SATA Flash PCB/replacing the Copyboard Glass, enter the value of barcode label which is affixed on the glass. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Copyboard Glass | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 7000 to 9999 | |
| Default Value | 8737 | |
| Related Service Mode | COPIER> ADJUST> CCD> W-PLT-X/Z | |
| Amount of Change per Unit | 1 | |
| W-PLT-Z | 1 | Stdrd White Plt white lvl data (Z) entry |
| Detail | To enter the white level data (Z) for the Standard White Plate. When clearing the Reader-related RAM data/replacing the SATA Flash PCB/replacing the Copyboard Glass, enter the value of barcode label which is affixed on the glass. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Copyboard Glass | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 7000 to 9999 | |
| Default Value | 9427 | |
| Related Service Mode | COPIER> ADJUST> CCD> W-PLT-X/Y | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|---|--|
| 100-RG | 1 | RG clr displc correct: front, vert scan |
| Detail | To correct the color displacement between R and G lines in vertical scanning direction due to the Scanner Unit (Front). When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | After the setting value is changed, write the changed value in the service label. | |
| Display/Adj/Set Range | -256 to 256 | |
| Unit | line | |
| Default Value | 0 | |
| Amount of Change per Unit | 0.001 | |
| 100-GB | 1 | GB clr displc correct: front, vert scan |
| Detail | To correct the color displacement between G and B lines in vertical scanning direction due to the Scanner Unit (Front). When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | After the setting value is changed, write the changed value in the service label. | |
| Display/Adj/Set Range | -256 to 256 | |
| Unit | line | |
| Default Value | 0 | |
| Amount of Change per Unit | 0.001 | |
| 100DF-RG | 1 | RG clr displc crrect:DADF,front,vert scan |
| Detail | To correct the color displacement between R and G lines in vertical scanning direction due to the Scanner Unit (Front) that occurs at DADF reading with 600 dpi. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | After the setting value is changed, write the changed value in the service label. | |
| Display/Adj/Set Range | -256 to 256 | |
| Unit | line | |
| Default Value | 0 | |
| Amount of Change per Unit | 0.001 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|--|--|
| 100DF-GB | 1 | GB clr displc crct:DADF,front,vert scan |
| Detail | To correct the color displacement between G and B lines in vertical scanning direction due to the Scanner Unit (Front) that occurs at DADF reading with 600 dpi. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | After the setting value is changed, write the changed value in the service label. | |
| Display/Adj/Set Range | -256 to 256 | |
| Unit | line | |
| Default Value | 0 | |
| Amount of Change per Unit | 0.001 | |
| DFTAR-R | 1 | Enter shading target VL (R): front, 1st |
| Detail | To enter the shading target value of Red on the front side at the first reading position at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Copyboard Glass/Scanner Unit (Front), execute DF-WLVL1 and DF-WLVL2 and write the value which is automatically set in the service label. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Copyboard Glass/Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2047 | |
| Default Value | 1103 | |
| Related Service Mode | COPIER> FUNCTION> CCD> DF-WLVL1/WLVL2 | |
| Amount of Change per Unit | 1 | |
| DFTAR-G | 1 | Enter shading target VL (G): front, 1st |
| Detail | To enter the shading target value of Green on the front side at the first reading position at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Copyboard Glass/Scanner Unit (Front), execute DF-WLVL1 and DF-WLVL2 and write the value which is automatically set in the service label. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Copyboard Glass/Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2047 | |
| Default Value | 1111 | |
| Related Service Mode | COPIER> FUNCTION> CCD> DF-WLVL1/WLVL2 | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|--|--|
| DFTAR-B | 1 | Enter shading target VL (B): front, 1st |
| Detail | <p>To enter the shading target value of Blue on the front side at the first reading position at DADF stream reading.</p> <p>When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader.</p> <p>When replacing the Copyboard Glass/Scanner Unit (Front), execute DF-WLVL1 and DF-WLVL2 and write the value which is automatically set in the service label.</p> | |
| Use Case | <ul style="list-style-type: none"> - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Copyboard Glass/Scanner Unit (Front) | |
| Adj/Set/Operate Method | <ol style="list-style-type: none"> 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2047 | |
| Default Value | 1164 | |
| Related Service Mode | COPIER> FUNCTION> CCD> DF-WLVL1/WLVL2 | |
| Amount of Change per Unit | 1 | |
| DFTAR2-R | 1 | Enter shading target VL (R): front, 2nd |
| Detail | <p>To enter the shading target value of Red on the front side at the second reading position at DADF stream reading.</p> <p>When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader.</p> <p>When replacing the Copyboard Glass/Scanner Unit (Front), execute DF-WLVL1 and DF-WLVL2 and write the value which is automatically set in the service label.</p> | |
| Use Case | <ul style="list-style-type: none"> - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Copyboard Glass/Scanner Unit (Front) | |
| Adj/Set/Operate Method | <ol style="list-style-type: none"> 1) Enter the setting value and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2047 | |
| Default Value | 1103 | |
| Related Service Mode | COPIER> FUNCTION> CCD> DF-WLVL1/WLVL2 | |
| DFTAR2-G | 1 | Enter shading target VL (G): front, 2nd |
| Detail | <p>To enter the shading target value of Green on the front side at the second reading position at DADF stream reading.</p> <p>When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader.</p> <p>When replacing the Copyboard Glass/Scanner Unit (Front), execute DF-WLVL1 and DF-WLVL2 and write the value which is automatically set in the service label.</p> | |
| Use Case | <ul style="list-style-type: none"> - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Copyboard Glass/Scanner Unit (Front) | |
| Adj/Set/Operate Method | <ol style="list-style-type: none"> 1) Enter the setting value and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2047 | |
| Default Value | 1111 | |
| Related Service Mode | COPIER> FUNCTION> CCD> DF-WLVL1/WLVL2 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|--|---|
| DFTAR2-B | 1 | Enter shading target VL (B): front, 2nd |
| Detail | To enter the shading target value of Blue on the front side at the second reading position at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Copyboard Glass/Scanner Unit (Front), execute DF-WLVL1 and DF-WLVL2 and write the value which is automatically set in the service label. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Copyboard Glass/Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2047 | |
| Default Value | 1164 | |
| Related Service Mode | COPIER> FUNCTION> CCD> DF-WLVL1/WLVL2 | |
| MTF2-M1 | 1 | MTF value 1 entry:DADF, front, horz scan |
| Detail | To enter the setting value 1 for calculating MTF filter coefficient in horizontal scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |
| MTF2-M2 | 1 | MTF value 2 entry:DADF, front, horz scan |
| Detail | To enter the setting value 2 for calculating MTF filter coefficient in horizontal scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|---|---|
| MTF2-M3 | 1 | MTF value 3 entry:DADF, front, horz scan |
| Detail | To enter the setting value 3 for calculating MTF filter coefficient in horizontal scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |
| MTF2-M4 | 1 | MTF value 4 entry:DADF, front, horz scan |
| Detail | To enter the setting value 4 for calculating MTF filter coefficient in horizontal scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |
| MTF2-M5 | 1 | MTF value 5 entry:DADF, front, horz scan |
| Detail | To enter the setting value 5 for calculating MTF filter coefficient in horizontal scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|---|---|
| MTF2-M6 | 1 | MTF value 6 entry:DADF, front, horz scan |
| Detail | To enter the setting value 6 for calculating MTF filter coefficient in horizontal scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |
| MTF2-M7 | 1 | MTF value 7 entry:DADF, front, horz scan |
| Detail | To enter the setting value 7 for calculating MTF filter coefficient in horizontal scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |
| MTF2-M8 | 1 | MTF value 8 entry:DADF, front, horz scan |
| Detail | To enter the setting value 8 for calculating MTF filter coefficient in horizontal scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|---|---|
| MTF2-M9 | 1 | MTF value 9 entry:DADF, front, horz scan |
| Detail | To enter the setting value 9 for calculating MTF filter coefficient in horizontal scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |
| MTF2-S1 | 1 | MTF value 1 entry:DADF, front, vert scan |
| Detail | To enter the setting value 1 for calculating MTF filter coefficient in vertical scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |
| MTF2-S2 | 1 | MTF value 2 entry:DADF, front, vert scan |
| Detail | To enter the setting value 2 for calculating MTF filter coefficient in vertical scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|---|---|
| MTF2-S3 | 1 | MTF value 3 entry:DADF, front, vert scan |
| Detail | To enter the setting value 3 for calculating MTF filter coefficient in vertical scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |
| MTF2-S4 | 1 | MTF value 4 entry:DADF, front, vert scan |
| Detail | To enter the setting value 4 for calculating MTF filter coefficient in vertical scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |
| MTF2-S5 | 1 | MTF value 5 entry:DADF, front, vert scan |
| Detail | To enter the setting value 5 for calculating MTF filter coefficient in vertical scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|---|---|
| MTF2-S6 | 1 | MTF value 6 entry:DADF, front, vert scan |
| Detail | To enter the setting value 6 for calculating MTF filter coefficient in vertical scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |
| MTF2-S7 | 1 | MTF value 7 entry:DADF, front, vert scan |
| Detail | To enter the setting value 7 for calculating MTF filter coefficient in vertical scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |
| MTF2-S8 | 1 | MTF value 8 entry:DADF, front, vert scan |
| Detail | To enter the setting value 8 for calculating MTF filter coefficient in vertical scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|---|---|
| MTF2-S9 | 1 | MTF value 9 entry:DADF, front, vert scan |
| Detail | To enter the setting value 9 for calculating MTF filter coefficient in vertical scanning direction on the front side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |
| 100DF2GB | 2 | GB clr displc correct: back, vert scan |
| Detail | To correct the color displacement between G and B lines in vertical scanning direction due to the Scanner Unit (Back). When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | -256 to 256 | |
| Unit | line | |
| Default Value | 0 | |
| Amount of Change per Unit | 0.001 | |
| 100DF2RG | 2 | RG clr displc correct: back, vert scan |
| Detail | To correct the color displacement between R and G lines in vertical scanning direction due to the Scanner Unit (Back). When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | -256 to 256 | |
| Unit | line | |
| Default Value | 0 | |
| Amount of Change per Unit | 0.001 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|---|---|
| DFCH2R2 | 1 | Complex chart No.2 data (R) entry: front |
| Detail | To derive the front/back side linearity, enter the Red data on the front side of No.2 image in DADF complex chart. Enter the value of service label on the Reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 1 to 2550 | |
| Default Value | 2000 | |
| Related Service Mode | COPIER> ADJUST> CCD> DFCH2R10, DFCH2B2/10, DFCH2G2/10 | |
| Amount of Change per Unit | 1 | |
| DFCH2R10 | 1 | Complex chart No.10 data (R) entry:front |
| Detail | To derive the front/back side linearity, enter the Red data on the front side of No.10 image in DADF complex chart. Enter the value of service label on the Reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2550 | |
| Default Value | 0 | |
| Related Service Mode | COPIER> ADJUST> CCD> DFCH2R2, DFCH2B2/10, DFCH2G2/10 | |
| Amount of Change per Unit | 1 | |
| DFCH2B2 | 1 | Complex chart No.2 data (B) entry: front |
| Detail | To derive the front/back side linearity, enter the Blue data on the front side of No.2 image in DADF complex chart. Enter the value of service label on the Reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 1 to 2550 | |
| Default Value | 2000 | |
| Related Service Mode | COPIER> ADJUST> CCD> DFCH2R2/10, DFCH2B10, DFCH2G2/10 | |
| Amount of Change per Unit | 1 | |
| DFCH2B10 | 1 | Complex chart No.10 data (B) entry:front |
| Detail | To derive the front/back side linearity, enter the Blue data on the front side of No.10 image in DADF complex chart. Enter the value of service label on the Reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2550 | |
| Default Value | 0 | |
| Related Service Mode | COPIER> ADJUST> CCD> DFCH2R2/10, DFCH2B2, DFCH2G2/10 | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|---|---|
| DFCH2G2 | 1 | Complex chart No.2 data (G) entry: front |
| Detail | To derive the front/back side linearity, enter the Green data on the front side of No.2 image in DADF complex chart. Enter the value of service label on the Reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 1 to 2550 | |
| Default Value | 2000 | |
| Related Service Mode | COPIER> ADJUST> CCD> DFCH2R2/10, DFCH2B2/10, DFCH2G10 | |
| Amount of Change per Unit | 1 | |
| DFCH2G10 | 1 | Complex chart No.10 data (G) entry:front |
| Detail | To derive the front/back side linearity, enter the Green data on the front side of No.10 image in DADF complex chart. Enter the value of service label on the Reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2550 | |
| Default Value | 0 | |
| Related Service Mode | COPIER> ADJUST> CCD> DFCH2R2/10, DFCH2B2/10, DFCH2G2 | |
| Amount of Change per Unit | 1 | |
| MTF-M1 | 1 | MTF value 1 entry: Copyboard, horz scan |
| Detail | To enter the setting value 1 for calculating MTF filter coefficient in horizontal scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|----------|---|
| MTF-M2 | 1 | MTF value 2 entry: Copyboard, horz scan |
| Detail | | To enter the setting value 2 for calculating MTF filter coefficient in horizontal scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 20 to 85 |
| Default Value | | 50 |
| Related Service Mode | | COPIER> FUNCTION> CCD> MTF-CLC |
| Amount of Change per Unit | | 1 |
| MTF-M3 | 1 | MTF value 3 entry: Copyboard, horz scan |
| Detail | | To enter the setting value 3 for calculating MTF filter coefficient in horizontal scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 20 to 85 |
| Default Value | | 50 |
| Related Service Mode | | COPIER> FUNCTION> CCD> MTF-CLC |
| Amount of Change per Unit | | 1 |
| MTF-M4 | 1 | MTF value 4 entry: Copyboard, horz scan |
| Detail | | To enter the setting value 4 for calculating MTF filter coefficient in horizontal scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 20 to 85 |
| Default Value | | 50 |
| Related Service Mode | | COPIER> FUNCTION> CCD> MTF-CLC |
| Amount of Change per Unit | | 1 |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|----------|---|
| MTF-M5 | 1 | MTF value 5 entry: Copyboard, horz scan |
| Detail | | To enter the setting value 5 for calculating MTF filter coefficient in horizontal scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 20 to 85 |
| Default Value | | 50 |
| Related Service Mode | | COPIER> FUNCTION> CCD> MTF-CLC |
| Amount of Change per Unit | | 1 |
| MTF-M6 | 1 | MTF value 6 entry: Copyboard, horz scan |
| Detail | | To enter the setting value 6 for calculating MTF filter coefficient in horizontal scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 20 to 85 |
| Default Value | | 50 |
| Related Service Mode | | COPIER> FUNCTION> CCD> MTF-CLC |
| Amount of Change per Unit | | 1 |
| MTF-M7 | 1 | MTF value 7 entry: Copyboard, horz scan |
| Detail | | To enter the setting value 7 for calculating MTF filter coefficient in horizontal scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 20 to 85 |
| Default Value | | 50 |
| Related Service Mode | | COPIER> FUNCTION> CCD> MTF-CLC |
| Amount of Change per Unit | | 1 |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|---|--|
| MTF-M8 | 1 | MTF value 8 entry: Copyboard, horz scan |
| Detail | To enter the setting value 8 for calculating MTF filter coefficient in horizontal scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |
| MTF-M9 | 1 | MTF value 9 entry: Copyboard, horz scan |
| Detail | To enter the setting value 9 for calculating MTF filter coefficient in horizontal scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |
| MTF-S1 | 1 | MTF value 1 entry: Copyboard, vert scan |
| Detail | To enter the setting value 1 for calculating MTF filter coefficient in vertical scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|----------|---|
| MTF-S2 | 1 | MTF value 2 entry: Copyboard, vert scan |
| Detail | | To enter the setting value 2 for calculating MTF filter coefficient in vertical scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 20 to 85 |
| Default Value | | 50 |
| Related Service Mode | | COPIER> FUNCTION> CCD> MTF-CLC |
| Amount of Change per Unit | | 1 |
| MTF-S3 | 1 | MTF value 3 entry: Copyboard, vert scan |
| Detail | | To enter the setting value 3 for calculating MTF filter coefficient in vertical scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 20 to 85 |
| Default Value | | 50 |
| Related Service Mode | | COPIER> FUNCTION> CCD> MTF-CLC |
| Amount of Change per Unit | | 1 |
| MTF-S4 | 1 | MTF value 4 entry: Copyboard, vert scan |
| Detail | | To enter the setting value 4 for calculating MTF filter coefficient in vertical scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 20 to 85 |
| Default Value | | 50 |
| Related Service Mode | | COPIER> FUNCTION> CCD> MTF-CLC |
| Amount of Change per Unit | | 1 |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|----------|---|
| MTF-S5 | 1 | MTF value 5 entry: Copyboard, vert scan |
| Detail | | To enter the setting value 5 for calculating MTF filter coefficient in vertical scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 20 to 85 |
| Default Value | | 50 |
| Related Service Mode | | COPIER> FUNCTION> CCD> MTF-CLC |
| Amount of Change per Unit | | 1 |
| MTF-S6 | 1 | MTF value 6 entry: Copyboard, vert scan |
| Detail | | To enter the setting value 6 for calculating MTF filter coefficient in vertical scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 20 to 85 |
| Default Value | | 50 |
| Related Service Mode | | COPIER> FUNCTION> CCD> MTF-CLC |
| Amount of Change per Unit | | 1 |
| MTF-S7 | 1 | MTF value 7 entry: Copyboard, vert scan |
| Detail | | To enter the setting value 7 for calculating MTF filter coefficient in vertical scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 20 to 85 |
| Default Value | | 50 |
| Related Service Mode | | COPIER> FUNCTION> CCD> MTF-CLC |
| Amount of Change per Unit | | 1 |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|----------|---|
| MTF-S8 | 1 | MTF value 8 entry: Copyboard, vert scan |
| Detail | | To enter the setting value 8 for calculating MTF filter coefficient in vertical scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 20 to 85 |
| Default Value | | 50 |
| Related Service Mode | | COPIER> FUNCTION> CCD> MTF-CLC |
| Amount of Change per Unit | | 1 |
| MTF-S9 | 1 | MTF value 9 entry: Copyboard, vert scan |
| Detail | | To enter the setting value 9 for calculating MTF filter coefficient in vertical scanning direction at copyboard reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Front), enter the value of service label on a new unit. |
| Use Case | | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 20 to 85 |
| Default Value | | 50 |
| Related Service Mode | | COPIER> FUNCTION> CCD> MTF-CLC |
| Amount of Change per Unit | | 1 |
| DFCH-R2 | 1 | Complex chart No.2 data (R) entry: back |
| Detail | | To derive the front/back side linearity, enter the Red data on the back side of No.2 image in DADF complex chart. Enter the value of service label on the Reader. |
| Use Case | | When clearing the Reader-related RAM data/replacing the SATA Flash PCB |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 1 to 2550 |
| Default Value | | 2000 |
| Related Service Mode | | COPIER> ADJUST> CCD> DFCH-R10, DFCH-B2/10, DFCH-G2/10 |
| Amount of Change per Unit | | 1 |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|--|---|
| DFCH-R10 | 1 | Complex chart No.10 data (R) entry: back |
| Detail | To derive the front/back side linearity, enter the Red data on the back side of No.10 image in DADF complex chart. Enter the value of service label on the Reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2550 | |
| Default Value | 0 | |
| Related Service Mode | COPIER> ADJUST> CCD> DFCH-R2, DFCH-B2/10, DFCH-G2/10 | |
| Amount of Change per Unit | 1 | |
| DFCH-B2 | 1 | Complex chart No.2 data (B) entry: back |
| Detail | To derive the front/back side linearity, enter the Blue data on the back side of No.2 image in DADF complex chart. Enter the value of service label on the Reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 1 to 2550 | |
| Default Value | 2000 | |
| Related Service Mode | COPIER> ADJUST> CCD> DFCH-R2/10, DFCH-B10, DFCH-G/10 | |
| Amount of Change per Unit | 1 | |
| DFCH-B10 | 1 | Complex chart No.10 data (B) entry: back |
| Detail | To derive the front/back side linearity, enter the Blue data on the back side of No.10 image in DADF complex chart. Enter the value of service label on the Reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2550 | |
| Default Value | 0 | |
| Related Service Mode | COPIER> ADJUST> CCD> DFCH-R2/10, DFCH-B2, DFCH-G2/10 | |
| Amount of Change per Unit | 1 | |
| DFCH-G2 | 1 | Complex chart No.2 data (G) entry: back |
| Detail | To derive the front/back side linearity, enter the Green data on the back side of No.2 image in DADF complex chart. Enter the value of service label on the Reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 1 to 2550 | |
| Default Value | 2000 | |
| Related Service Mode | COPIER> ADJUST> CCD> DFCH-R2/10, DFCH-B2/10, DFCH-G10 | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|---|---|
| DFCH-G10 | 1 | Complex chart No.10 data (G) entry: back |
| Detail | To derive the front/back side linearity, enter the Green data on the back side of No.10 image in DADF complex chart. Enter the value of service label on the Reader. | |
| Use Case | When clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2550 | |
| Default Value | 0 | |
| Related Service Mode | COPIER> ADJUST> CCD> DFCH-R2/10, DFCH-B2/10, DFCH-G2 | |
| Amount of Change per Unit | 1 | |
| MTF3-M1 | 1 | MTF value 1 entry: DADF, back, horz scan |
| Detail | To enter the setting value 1 for calculating MTF filter coefficient in horizontal scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| Amount of Change per Unit | 0 | |
| MTF3-M2 | 1 | MTF value 2 entry: DADF, back, horz scan |
| Detail | To enter the setting value 2 for calculating MTF filter coefficient in horizontal scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|---|---|
| MTF3-M3 | 1 | MTF value 3 entry: DADF, back, horz scan |
| Detail | To enter the setting value 3 for calculating MTF filter coefficient in horizontal scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| MTF3-M4 | 1 | MTF value 4 entry: DADF, back, horz scan |
| Detail | To enter the setting value 4 for calculating MTF filter coefficient in horizontal scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| MTF3-M5 | 1 | MTF value 5 entry: DADF, back, horz scan |
| Detail | To enter the setting value 5 for calculating MTF filter coefficient in horizontal scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| MTF3-M6 | 1 | MTF value 6 entry: DADF, back, horz scan |
| Detail | To enter the setting value 6 for calculating MTF filter coefficient in horizontal scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|---|---|
| MTF3-M7 | 1 | MTF value 7 entry: DADF, back, horz scan |
| Detail | To enter the setting value 7 for calculating MTF filter coefficient in horizontal scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| MTF3-M8 | 1 | MTF value 8 entry: DADF, back, horz scan |
| Detail | To enter the setting value 8 for calculating MTF filter coefficient in horizontal scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| MTF3-M9 | 1 | MTF value 9 entry: DADF, back, horz scan |
| Detail | To enter the setting value 9 for calculating MTF filter coefficient in horizontal scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| MTF3-S1 | 1 | MTF value 1 entry: DADF, back, vert scan |
| Detail | To enter the setting value 1 for calculating MTF filter coefficient in vertical scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|---|---|
| MTF3-S2 | 1 | MTF value 2 entry: DADF, back, vert scan |
| Detail | To enter the setting value 2 for calculating MTF filter coefficient in vertical scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| MTF3-S3 | 1 | MTF value 3 entry: DADF, back, vert scan |
| Detail | To enter the setting value 3 for calculating MTF filter coefficient in vertical scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| MTF3-S4 | 1 | MTF value 4 entry: DADF, back, vert scan |
| Detail | To enter the setting value 4 for calculating MTF filter coefficient in vertical scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| MTF3-S5 | 1 | MTF value 5 entry: DADF, back, vert scan |
| Detail | To enter the setting value 5 for calculating MTF filter coefficient in vertical scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|---|---|
| MTF3-S6 | 1 | MTF value 6 entry: DADF, back, vert scan |
| Detail | To enter the setting value 6 for calculating MTF filter coefficient in vertical scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| MTF3-S7 | 1 | MTF value 7 entry: DADF, back, vert scan |
| Detail | To enter the setting value 7 for calculating MTF filter coefficient in vertical scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| MTF3-S8 | 1 | MTF value 8 entry: DADF, back, vert scan |
| Detail | To enter the setting value 8 for calculating MTF filter coefficient in vertical scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |
| MTF3-S9 | 1 | MTF value 9 entry: DADF, back, vert scan |
| Detail | To enter the setting value 9 for calculating MTF filter coefficient in vertical scanning direction on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), enter the value of service label on a new unit. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 20 to 85 | |
| Default Value | 50 | |
| Related Service Mode | COPIER> FUNCTION> CCD> MTF-CLC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|----------------------------------|--|---|
| DFTBK-G | 1 | Enter shading target VL (G): back side |
| Detail | To enter the shading target value of Green on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), execute DF-WLVL1 and DF-WLVL2 and write the value which is automatically set in the service label. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | When the Copyboard or DADF (reverse model) is installed, the setting of this item is disabled. | |
| Display/Adj/Set Range | 0 to 2047 | |
| Default Value | 1111 | |
| Related Service Mode | COPIER> FUNCTION> CCD> DF-WLVL1/WLVL2 | |
| Amount of Change per Unit | 1 | |
| DFTBK-B | 1 | Enter shading target VL (B): back side |
| Detail | To enter the shading target value of Blue on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), execute DF-WLVL1 and DF-WLVL2 and write the value which is automatically set in the service label. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | When the Copyboard or DADF (reverse model) is installed, the setting of this item is disabled. | |
| Display/Adj/Set Range | 0 to 2047 | |
| Default Value | 1164 | |
| Related Service Mode | COPIER> FUNCTION> CCD> DF-WLVL1/WLVL2 | |
| Amount of Change per Unit | 1 | |
| DFTBK-R | 1 | Enter shading target VL (R): back side |
| Detail | To enter the shading target value of Red on the back side at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Scanner Unit (Back), execute DF-WLVL1 and DF-WLVL2 and write the value which is automatically set in the service label. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | When the Copyboard or DADF (reverse model) is installed, the setting of this item is disabled. | |
| Display/Adj/Set Range | 0 to 2047 | |
| Default Value | 1103 | |
| Related Service Mode | COPIER> FUNCTION> CCD> DF-WLVL1/WLVL2 | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|--|--|
| DFTAR3-R | 1 | Enter shading target VL (R): front, 3rd |
| Detail | To enter the shading target value of Red on the front side at the third reading position at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Copyboard Glass/Scanner Unit (Front), execute DF-WLVL1 and DF-WLVL2 and write the value which is automatically set in the service label. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Copyboard Glass/Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2047 | |
| Default Value | 1103 | |
| Related Service Mode | COPIER> FUNCTION> CCD> DF-WLVL1/WLVL2 | |
| DFTAR3-G | 1 | Enter shading target VL (G): front, 3rd |
| Detail | To enter the shading target value of Green on the front side at the third reading position at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Copyboard Glass/Scanner Unit (Front), execute DF-WLVL1 and DF-WLVL2 and write the value which is automatically set in the service label. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Copyboard Glass/Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2047 | |
| Default Value | 1111 | |
| Related Service Mode | COPIER> FUNCTION> CCD> DF-WLVL1/WLVL2 | |
| DFTAR3-B | 1 | Enter shading target VL (B): front, 3rd |
| Detail | To enter the shading target value of Blue on the front side at the third reading position at DADF stream reading. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. When replacing the Copyboard Glass/Scanner Unit (Front), execute DF-WLVL1 and DF-WLVL2 and write the value which is automatically set in the service label. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Copyboard Glass/Scanner Unit (Front) | |
| Adj/Set/Operate Method | 1) Enter the setting value and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2047 | |
| Default Value | 1164 | |
| Related Service Mode | COPIER> FUNCTION> CCD> DF-WLVL1/WLVL2 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|--|---|
| OFST-BW0 | 1 | Adj CIS-ch0 offset:front,B&W mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (for front side) on channel 0 in Black & White mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for front side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST-BW1 | 1 | Adj CIS-ch1 offset:front,B&W mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (for front side) on channel 1 in Black & White mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for front side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST-BW2 | 1 | Adj CIS-ch2 offset:front,B&W mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (for front side) on channel 2 in Black & White mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for front side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|--|---|
| OFST-BW3 | 1 | Adj CIS-ch3 offset:front,B&W mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (for front side) on channel 3 in Black & White mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for front side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST-BW4 | 1 | Adj CIS-ch4 offset:front,B&W mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (for front side) on channel 4 in Black & White mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for front side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST-BW5 | 1 | Adj CIS-ch5 offset:front,B&W mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (for front side) on channel 5 in Black & White mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for front side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST-CL0 | 1 | Adj CIS-ch0 offset:front,clr mode,300dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Front) on channel 0 in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|--|---|
| OFST-CL1 | 1 | Adj CIS-ch1 offset:front,clr mode,300dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Front) on channel 1 in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST-CL2 | 1 | Adj CIS-ch2 offset:front,clr mode,300dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Front) on channel 2 in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST-CL3 | 1 | Adj CIS-ch3 offset:front,clr mode,300dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Front) on channel 3 in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST-CL4 | 1 | Adj CIS-ch4 offset:front,clr mode,300dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Front) on channel 4 in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST-CL5 | 1 | Adj CIS-ch5 offset:front,clr mode,300dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Front) on channel 5 in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|--|---|
| OFST2CL0 | 1 | Adj CIS-ch0 offset:front,clr mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Front) on channel 0 in color mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST2CL1 | 1 | Adj CIS-ch1 offset:front,clr mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Front) on channel 1 in color mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST2CL2 | 1 | Adj CIS-ch2 offset:front,clr mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Front) on channel 2 in color mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST2CL3 | 1 | Adj CIS-ch3 offset:front,clr mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Front) on channel 3 in color mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST2CL4 | 1 | Adj CIS-ch4 offset:front,clr mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Front) on channel 4 in color mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|---|---|
| OFST2CL5 | 1 | Adj CIS-ch5 offset:front,clr mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Front) on channel 5 in color mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| GAIN-CL0 | 1 | Adj CIS gain level:front,clr mode,300dpi |
| Detail | To adjust the detection level (gain level) of the Scanner Unit (Front) in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 0 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| GAIN2CL0 | 1 | Adj CIS gain level:front,clr mode,600dpi |
| Detail | To adjust the detection level (gain level) of the Scanner Unit (Front) in color mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 0 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| LED-CL-R | 1 | Adj pry lgt src lgt time: frt,clr,300dpi |
| Detail | To adjust the lighting time of the LED which is the primary light source of the Scanner Unit (Front) in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 2928 | |
| Default Value | 1648 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| LED2CL-R | 1 | Adj pry lgt src lgt time: frt,clr,600dpi |
| Detail | To adjust the lighting time of the LED which is the primary light source of the Scanner Unit (Front) in color mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 2928 | |
| Default Value | 2816 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|---|---|
| LED-CLR2 | 1 | Adj sec lgt src lgt time: frt,clr,300dpi |
| Detail | To adjust the lighting time of the LED which is the secondary light source of the Scanner Unit (Front) in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 2928 | |
| Default Value | 1648 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| LED2CLR2 | 1 | Adj sec lgt src lgt time: frt,clr,600dpi |
| Detail | To adjust the lighting time of the LED which is the secondary light source of the Scanner Unit (Front) in color mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 2928 | |
| Default Value | 2816 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST3CL0 | 1 | Adj CIS-ch0 offset: back,clr mode,300dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Back) on channel 0 in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST3CL1 | 1 | Adj CIS-ch1 offset: back,clr mode,300dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Back) on channel 1 in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST3CL2 | 1 | Adj CIS-ch2 offset: back,clr mode,300dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Back) on channel 2 in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|---|---|
| OFST3CL3 | 1 | Adj CIS-ch3 offset: back,clr mode,300dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Back) on channel 3 in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST3CL4 | 1 | Adj CIS-ch4 offset: back,clr mode,300dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Back) on channel 4 in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST3CL5 | 1 | Adj CIS-ch5 offset: back,clr mode,300dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Back) on channel 5 in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST4CL0 | 1 | Adj CIS-ch0 offset: back,clr mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Back) on channel 0 in color mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST4CL1 | 1 | Adj CIS-ch1 offset: back,clr mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Back) on channel 1 in color mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|---|---|
| OFST4CL2 | 1 | Adj CIS-ch2 offset: back,clr mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Back) on channel 2 in color mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST4CL3 | 1 | Adj CIS-ch3 offset: back,clr mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Back) on channel 3 in color mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST4CL4 | 1 | Adj CIS-ch4 offset: back,clr mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Back) on channel 4 in color mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST4CL5 | 1 | Adj CIS-ch5 offset: back,clr mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (Back) on channel 5 in color mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| GAIN3CL0 | 1 | Adj CIS gain level: back,clr mode,300dpi |
| Detail | To adjust the detection level (gain level) of the Scanner Unit (Back) in color mode with 300 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 0 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|----------|---|
| GAIN4CL0 | 1 | Adj CIS gain level: back,clr mode,600dpi |
| Detail | | To adjust the detection level (gain level) of the Scanner Unit (Back) in color mode with 600 dpi. The value is updated by executing CL-AGC. |
| Use Case | | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 255 |
| Default Value | | 0 |
| Related Service Mode | | COPIER> FUNCTION> CCD> CL-AGC |
| LED3CL | 1 | Adj pry lgt src lgt time:back,clr,300dpi |
| Detail | | To adjust the lighting time of the LED which is the primary light source of the Scanner Unit (Back) in color mode with 300 dpi. The value is updated by executing CL-AGC. |
| Use Case | | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 2928 |
| Default Value | | 1648 |
| Related Service Mode | | COPIER> FUNCTION> CCD> CL-AGC |
| LED3CL2 | 1 | Adj sec lgt src lgt time:back,clr,300dpi |
| Detail | | To adjust the lighting time of the LED which is the secondary light source of the Scanner Unit (Back) in color mode with 300 dpi. The value is updated by executing CL-AGC. |
| Use Case | | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 2928 |
| Default Value | | 1648 |
| Related Service Mode | | COPIER> FUNCTION> CCD> CL-AGC |
| LED4CL | 1 | Adj pry lgt src lgt time:back,clr,600dpi |
| Detail | | To adjust the lighting time of the LED which is the primary light source of the Scanner Unit (Back) in color mode with 600 dpi. The value is updated by executing CL-AGC. |
| Use Case | | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 2928 |
| Default Value | | 2816 |
| Related Service Mode | | COPIER> FUNCTION> CCD> CL-AGC |
| LED4CL2 | 1 | Adj sec lgt src lgt time:back,clr,600dpi |
| Detail | | To adjust the lighting time of the LED which is the secondary light source of the Scanner Unit (Back) in color mode with 600 dpi. The value is updated by executing CL-AGC. |
| Use Case | | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 2928 |
| Default Value | | 2816 |
| Related Service Mode | | COPIER> FUNCTION> CCD> CL-AGC |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|---|---|
| LED-BW-1 | 1 | Adj pry lgt src lgt time: frt,B&W,600dpi |
| Detail | To adjust the lighting time of the LED which is the primary light source of the Scanner Unit (for front side) in B&W mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for front side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 2928 | |
| Default Value | 1312 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| LED-BW-2 | 1 | Adj pry lgt src lgt time2 frt,B&W,600dpi |
| Detail | To adjust the lighting time of the LED which is the secondary light source of the Scanner Unit (for front side) in B&W mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for front side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 2928 | |
| Default Value | 1312 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| LED2BW-1 | 1 | Adj pry lgt src lgt time: bck,B&W,600dpi |
| Detail | To adjust the lighting time of the LED which is the primary light source of the Scanner Unit (for back side) in B&W mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for back side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 2928 | |
| Default Value | 1312 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|--|---|
| LED2BW-2 | 1 | Adj sec lgt src lgt time: bck,B&W,600dpi |
| Detail | To adjust the lighting time of the LED which is the secondary light source of the Scanner Unit (for back side) in B&W mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for back side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 2928 | |
| Default Value | 1312 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| GAIN-BW1 | 1 | Adj CIS gain level:front,B&W mode,600dpi |
| Detail | To adjust the detection level (gain level) of the Scanner Unit (for front side) in Black & White mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for front side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 0 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| GAIN-BW2 | 1 | Adj CIS gain level:bck,B&W mode,600dpi |
| Detail | To adjust the detection level (gain level) of the Scanner Unit (for back side) in Black & White mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for back side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 0 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|---|--|
| OFST2BW0 | 1 | Adj CIS-ch0 offset:back,B&W mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (for back side) on channel 0 in Black & White mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for back side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST2BW1 | 1 | Adj CIS-ch1 offset:back,B&W mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (for back side) on channel 1 in Black & White mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for back side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST2BW2 | 1 | Adj CIS-ch2 offset:back,B&W mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (for back side) on channel 2 in Black & White mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for back side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > CCD

| | | |
|-------------------------------|---|--|
| OFST2BW3 | 1 | Adj CIS-ch3 offset:back,B&W mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (for back side) on channel 3 in Black & White mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for back side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST2BW4 | 1 | Adj CIS-ch4 offset:back,B&W mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (for back side) on channel 4 in Black & White mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for back side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |
| OFST2BW5 | 1 | Adj CIS-ch5 offset:back,B&W mode,600dpi |
| Detail | To adjust the offset value (black level) of the Scanner Unit (for back side) on channel 5 in Black & White mode with 600 dpi. The value is updated by executing CL-AGC. | |
| Use Case | - When clearing the Reader-related RAM data/replacing the SATA Flash PCB - When replacing the Scanner Unit (for back side) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When replacing the CIS, rewrite the value on the label by displaying this item after executing COPIER>FUNCTION>CCD>CL-AGC. | |
| Display/Adj/Set Range | 0 to 255 | |
| Default Value | 216 | |
| Related Service Mode | COPIER> FUNCTION> CCD> CL-AGC | |

■ DENS

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > DENS

| DENS-ADJ | 1 | Density correction of copy image |
|-------------------------------|----------|--|
| Detail | | To correct the density of copy image by changing the F-value table. When replacing the DC Controller PCB/clearing RAM data, enter the value of service label. Blurring is alleviated when the value is increased, and fogging is alleviated when the value is decreased. |
| Use Case | | When fogging or blurring at high density area occurs with a copy image |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Caution | | Density of printer output image cannot be corrected. |
| Display/Adj/Set Range | | 1 to 9 |
| Default Value | | 5 |
| Supplement/Memo | | F-value table: shows the relationship between original density and image density. |

■ BLANK

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > BLANK

| BLANK-T | 1 | Adjustment of leading edge margin |
|----------------------------------|----------|--|
| Detail | | To adjust the margin on the leading edge of paper. As the value is increased by 1, the margin is increased toward the center of the paper by 1 pixel (0.0212 mm). |
| Use Case | | - When reducing the margin upon user's request - When enlarging the margin for transfer separation/fixing separation |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Caution | | After the setting value is changed, write the changed value in the service label. |
| Display/Adj/Set Range | | 0 to 1000 |
| Unit | | pixel |
| Default Value | | 118 |
| Amount of Change per Unit | | 0.0212 |

| BLANK-L | 1 | Adjustment of left edge margin |
|----------------------------------|----------|---|
| Detail | | To adjust the margin on the left edge of paper. As the value is increased by 1, the margin is increased toward the center of the paper by 1 pixel (0.0212 mm). |
| Use Case | | When reducing the margin upon user's request |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 1000 |
| Unit | | pixel |
| Default Value | | 59 |
| Amount of Change per Unit | | 0.0212 |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > BLANK

| BLANK-R | 1 | Adjustment of right edge margin |
|----------------------------------|----------|--|
| Detail | | To adjust the margin on the right edge of paper. As the value is increased by 1, the margin is increased toward the center of the paper by 1 pixel (0.0212 mm). |
| Use Case | | When reducing the margin upon user's request |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 1000 |
| Unit | | pixel |
| Default Value | | 59 |
| Amount of Change per Unit | | 0.0212 |

| BLANK-B | 1 | Adjustment of trailing edge margin |
|----------------------------------|----------|---|
| Detail | | To adjust the margin on the trailing edge of paper. As the value is increased by 1, the margin is increased toward the center of the paper by 1 pixel (0.0212 mm). |
| Use Case | | - When reducing the margin upon user's request - When enlarging the margin for transfer separation/fixing separation |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Caution | | After the setting value is changed, write the changed value in the service label. |
| Display/Adj/Set Range | | 0 to 1000 |
| Unit | | pixel |
| Default Value | | 94 |
| Amount of Change per Unit | | 0.0212 |

■ PASCAL

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > PASCAL

| OFST-P-K | 1 | Bk density adj at test print reading |
|----------------------------------|----------|--|
| Detail | | To adjust the offset of Bk-color test print reading signal at auto gradation adjustment (full adjustment). When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of the service label on the reader. As the value is larger, the image after adjustment gets darker. |
| Use Case | | When clearing the Reader-related RAM data/replacing the SATA Flash PCB |
| Adj/Set/Operate Method | | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | After the setting value is changed, write the changed value in the service label. |
| Display/Adj/Set Range | | -128 to 128 |
| Default Value | | According to the adjustment value of the Reader at factory shipment |
| Amount of Change per Unit | | 1 |

■ FEED-ADJ

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > FEED-ADJ

| | | |
|-------------------------------|--|--|
| REGIST | 1 | Adj of registration start timing: Plain |
| Detail | <p>To adjust the timing to turn ON the Registration Roller in the case of plain paper. As the value is incremented by 1, the margin on the leading edge of paper is increased by 0.1 mm. +: Leading edge margin becomes larger. -: Leading edge margin becomes smaller. When replacing the DC Controller PCB/clearing RAM data, enter the value of service label.</p> | |
| Use Case | <p>When changing the edge margin When replacing the DC Controller PCB/clearing RAM data</p> | |
| Adj/Set/Operate Method | <p>Enter the setting value (switch positive/negative by +/- key) and press OK key.</p> | |
| Caution | <p>Be sure to enter the adjustment value on the service label after adjustment.</p> | |
| Display/Adj/Set Range | <p>-50 to 50</p> | |
| Default Value | <p>9</p> | |
| ADJ-C1 | 1 | Cassette1 write start pstn in horz scan |
| Detail | <p>To adjust the image write start position in the horizontal scanning direction when feeding paper from the Cassette 1. As the value is changed by 1, the left margin is changed by 0.1 mm. +: Left margin becomes larger. (An image moves to the right.) -: Left margin becomes smaller. (An image moves to the left.) When clearing RAM data, enter the value of service label.</p> | |
| Use Case | <p>When clearing RAM data</p> | |
| Adj/Set/Operate Method | <p>Enter the setting value (switch negative/positive by -/+ key) and press OK key.</p> | |
| Caution | <p>If write start position cannot be adjusted in service mode, execute mechanical adjustment.</p> | |
| Display/Adj/Set Range | <p>-25 to 50</p> | |
| Unit | <p>mm</p> | |
| Default Value | <p>0</p> | |
| ADJ-C2 | 1 | Cassette2 write start pstn in horz scan |
| Detail | <p>To adjust the image write start position in the horizontal scanning direction when feeding paper from the Cassette 2. As the value is changed by 1, the left margin is changed by 0.1 mm. +: Left margin becomes larger. (An image moves to the right.) -: Left margin becomes smaller. (An image moves to the left.) When clearing RAM data, enter the value of service label.</p> | |
| Use Case | <p>When clearing RAM data</p> | |
| Adj/Set/Operate Method | <p>Enter the setting value (switch negative/positive by -/+ key) and press OK key.</p> | |
| Caution | <p>If write start position cannot be adjusted in service mode, execute mechanical adjustment.</p> | |
| Display/Adj/Set Range | <p>-25 to 50</p> | |
| Unit | <p>mm</p> | |
| Default Value | <p>0</p> | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > FEED-ADJ

| | | |
|-------------------------------|--|---|
| ADJ-C3 | 1 | Cassette 3 write start pstn in horz scan |
| Detail | To adjust the image write start position in the horizontal scanning direction when feeding paper from the Cassette 3. As the value is incremented by 1, the margin on the left edge of paper is increased by 0.1 mm. +: Left margin becomes larger. (An image moves to the right.) -: Left margin becomes smaller. (An image moves to the left.) When clearing RAM data, enter the value of service label. | |
| Use Case | When clearing RAM data | |
| Adj/Set/Operate Method | Enter the setting value (switch negative/positive by -/+ key) and press OK key. | |
| Caution | If write start position cannot be adjusted in service mode, execute mechanical adjustment. | |
| Display/Adj/Set Range | -25 to 50 | |
| Unit | mm | |
| Default Value | 0 | |
| ADJ-C4 | 1 | Cassette 4 write start pstn in horz scan |
| Detail | To adjust the image write start position in the horizontal scanning direction when feeding paper from the Cassette 4. As the value is incremented by 1, the margin on the left edge of paper is increased by 0.1 mm. +: Left margin becomes larger. (An image moves to the right.) -: Left margin becomes smaller. (An image moves to the left.) When clearing RAM data, enter the value of service label. | |
| Use Case | When clearing RAM data | |
| Adj/Set/Operate Method | Enter the setting value (switch negative/positive by -/+ key) and press OK key. | |
| Caution | If write start position cannot be adjusted in service mode, execute mechanical adjustment. | |
| Display/Adj/Set Range | -25 to 50 | |
| Unit | mm | |
| Default Value | 0 | |
| ADJ-MF | 1 | Write start pstn in horz scan: MP Tray |
| Detail | To adjust the image write start position in the horizontal scanning direction when feeding paper from the Multi-purpose Tray. As the value is incremented by 1, the margin on the left edge of paper is increased by 0.1 mm. +: Left margin becomes larger. (An image moves to the right.) -: Left margin becomes smaller. (An image moves to the left.) When clearing RAM data, enter the value of service label. | |
| Use Case | When clearing RAM data | |
| Adj/Set/Operate Method | Enter the setting value (switch negative/positive by -/+ key) and press OK key. | |
| Caution | If write start position cannot be adjusted in service mode, execute mechanical adjustment. | |
| Display/Adj/Set Range | -25 to 50 | |
| Unit | mm | |
| Default Value | 0 | |
| ADJ-C1RE | 1 | Write start pstn in horz scan:Cst1 2nd |
| Detail | To adjust the image write start position on the second side in the horizontal scanning direction when feeding paper from the Cassette 1. As the value is changed by 1, the left margin is changed by 0.1 mm. +: Left margin becomes larger. (An image moves to the right.) -: Left margin becomes smaller. (An image moves to the left.) When clearing RAM data, enter the value of service label. | |
| Use Case | When clearing RAM data | |
| Adj/Set/Operate Method | Enter the setting value (switch negative/positive by -/+ key) and press OK key. | |
| Display/Adj/Set Range | -25 to 50 | |
| Unit | mm | |
| Default Value | 0 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > FEED-ADJ

| | | |
|-------------------------------|--|---|
| ADJ-C2RE | 1 | Write start pstn in horz scan:Cst2 2nd |
| Detail | To adjust the image write start position on the second side in the horizontal scanning direction when feeding paper from the Cassette 2. As the value is changed by 1, the left margin is changed by 0.1 mm. +: Left margin becomes larger. (An image moves to the right.) -: Left margin becomes smaller. (An image moves to the left.) When clearing RAM data, enter the value of service label. | |
| Use Case | When clearing RAM data | |
| Adj/Set/Operate Method | Enter the setting value (switch negative/positive by -/+ key) and press OK key. | |
| Display/Adj/Set Range | -25 to 50 | |
| Unit | mm | |
| Default Value | 0 | |
| ADJ-C3RE | 1 | Write start pstn in horz scan:Cst3 2nd |
| Detail | To adjust the image write start position on the second side in the horizontal scanning direction when feeding paper from the Cassette 3. As the value is changed by 1, the left margin is changed by 0.1 mm. +: Left margin becomes larger. (An image moves to the right.) -: Left margin becomes smaller. (An image moves to the left.) When clearing RAM data, enter the value of service label. | |
| Use Case | When clearing RAM data | |
| Adj/Set/Operate Method | Enter the setting value (switch negative/positive by -/+ key) and press OK key. | |
| Display/Adj/Set Range | -25 to 50 | |
| Unit | mm | |
| Default Value | 0 | |
| ADJ-C4RE | 1 | Write start pstn in horz scan:Cst4 2nd |
| Detail | To adjust the image write start position on the second side in the horizontal scanning direction when feeding paper from the Cassette 4. As the value is changed by 1, the left margin is changed by 0.1 mm. +: Left margin becomes larger. (An image moves to the right.) -: Left margin becomes smaller. (An image moves to the left.) When clearing RAM data, enter the value of service label. | |
| Use Case | When clearing RAM data | |
| Adj/Set/Operate Method | Enter the setting value (switch negative/positive by -/+ key) and press OK key. | |
| Display/Adj/Set Range | -25 to 50 | |
| Unit | mm | |
| Default Value | 0 | |
| ADJ-MFRE | 1 | Write start pstn in horz scan:MPTray 2nd |
| Detail | To adjust the image write start position on the second side in the horizontal scanning direction when feeding paper from the Multi-purpose Tray. As the value is changed by 1, the left margin is changed by 0.1 mm. +: Left margin becomes larger. (An image moves to the right.) -: Left margin becomes smaller. (An image moves to the left.) When clearing RAM data, enter the value of service label. | |
| Use Case | When clearing RAM data | |
| Adj/Set/Operate Method | Enter the setting value (switch negative/positive by -/+ key) and press OK key. | |
| Display/Adj/Set Range | -25 to 50 | |
| Unit | mm | |
| Default Value | 0 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > FEED-ADJ

| | | |
|-------------------------------|--|--|
| RG-HF-SP | 1 | Adj of registration start timing: Heavy |
| Detail | To adjust the timing to turn ON the Registration Roller in the case of heavy paper. As the value is incremented by 1, the margin on the leading edge of paper is increased by 0.1 mm. +: Leading edge margin becomes larger. -: Leading edge margin becomes smaller. When replacing the DC Controller PCB/clearing RAM data, enter the value of service label. | |
| Use Case | When changing the edge margin When replacing the DC Controller PCB/clearing RAM data | |
| Adj/Set/Operate Method | Enter the setting value (switch positive/negative by +/- key) and press OK key. | |
| Caution | Be sure to enter the adjustment value on the service label after adjustment. | |
| Display/Adj/Set Range | -50 to 50 | |
| Default Value | 9 | |
| REG-DUP1 | 1 | Rgst start timing adj: Plain, 2nd side |
| Detail | To adjust the leading edge margin by changing the timing to form image when feeding the second side of plain paper. As the value is changed by 1, the leading edge margin is changed by 0.1 mm. +: Leading edge margin becomes larger. (An image moves downward.) -: Leading edge margin becomes smaller. (An image moves upward.) | |
| Use Case | - When replacing the DC Controller PCB/clearing RAM data - When replacing the DC Controller PCB/clearing RAM data | |
| Adj/Set/Operate Method | Enter the setting value (switch positive/negative by +/- key) and press OK key. | |
| Caution | When replacing the DC Controller PCB/clearing RAM data, restore the backup data if data is backed up or enter the value of service label if data is not backed up. | |
| Display/Adj/Set Range | -50 to 50 | |
| Default Value | 9 | |
| REG-MF | 1 | Rgst start timing adj: MP Tray, Plain |
| Detail | To adjust the leading edge margin by changing the timing to form image when feeding the, of plain paper 1/2, recycled paper, and thin paper. As the value is changed by 1, the leading edge margin is changed by 0.1 mm. +: Leading edge margin becomes larger. (An image moves downward.) -: Leading edge margin becomes smaller. (An image moves upward.) | |
| Use Case | - When replacing the DC Controller PCB/clearing RAM data - When replacing the DC Controller PCB/clearing RAM data | |
| Adj/Set/Operate Method | Enter the setting value (switch positive/negative by +/- key) and press OK key. | |
| Caution | When replacing the DC Controller PCB/clearing RAM data, restore the backup data if data is backed up or enter the value of service label if data is not backed up. | |
| Display/Adj/Set Range | -50 to 50 | |
| Default Value | 5 | |

■ MISC

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > MISC

| | | |
|-------------------------------|--|--|
| SEG-ADJ | 1 | Set criteria for text/photo: front side |
| Detail | To set the judgment level of text/photo original in Text/Photo/Map mode. As the value is increased, the original tends to be detected as a photo document, and as the value is decreased, the original tends to be detected as a text document. | |
| Use Case | When adjusting the classification level of text and photo in Text/Photo/Map mode | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | -4 to 4 | |
| Default Value | 0 | |
| K-ADJ | 1 | Set criteria for black text: front side |
| Detail | To set the judgment level of black characters at text processing. As the value is increased, the text tends to be detected as black. | |
| Use Case | When preferring the text to be judged as black | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | -3 to 3 | |
| Default Value | 0 | |
| ACS-ADJ | 1 | Set criteria for B&W/color in ACS:front |
| Detail | To set the judgment level of B&W/color original in ACS mode. As the value is increased, the original tends to be detected as a B&W document, and as the value is decreased, the original tends to be detected as a color document. | |
| Use Case | When adjusting the color detection level in ACS mode | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | -3 to 3 | |
| Default Value | 0 | |
| ACS-EN | 2 | Set judgment area in ACS mode:front side |
| Detail | To set the judgment area in ACS mode. As the greater value is set, the judgment area is widened. | |
| Use Case | When adjusting the judgment area in ACS mode | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | -2 to 2 | |
| Default Value | 1 | |
| ACS-CNT | 2 | Set jdgmt pixel count area in ACS:front |
| Detail | To set the area which counts the pixel to judge the color presence in ACS mode. As the greater value is set, the judgment area is widened. | |
| Use Case | When adjusting the area which counts the pixel to judge the color presence in ACS mode | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | -2 to 2 | |
| Default Value | 0 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > MISC

| | | |
|-------------------------------|--|--|
| ACS-EN2 | 2 | Set ACS mode jdgmt area in DADF mode |
| Detail | To set the judgment area in ACS mode at DADF reading. As the greater value is set, the judgment area is widened. | |
| Use Case | When adjusting the judgment area in ACS mode at DADF reading | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | -2 to 2 | |
| Default Value | 1 | |
| ACS-CNT2 | 2 | Set ACS jdgmt pixel count area in DADF |
| Detail | To set the area which counts the pixel to judge the color presence in ACS mode at DADF reading. As the greater value is set, the judgment area is widened. | |
| Use Case | When adjusting the area which counts the pixel to judge the color presence in ACS mode at DADF reading | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | -2 to 2 | |
| Default Value | 0 | |
| SEG-ADJ3 | 1 | Set criteria for text/photo: back side |
| Detail | To set the judgment level of text/photo original in Text/Photo/Map mode (back side at duplex reading with 1 path). As the value is increased, the original tends to be detected as a photo document, and as the value is decreased, the original tends to be detected as a text document. | |
| Use Case | When adjusting the classification level of text and photo in Text/Photo/Map mode (back side at duplex reading with 1 path) | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | -4 to 4 | |
| Default Value | 0 | |
| K-ADJ3 | 1 | Set criteria for black text: back side |
| Detail | To set the judgment level of black characters at text processing (back side at duplex reading with 1 path). As the value is increased, the text tends to be detected as black. | |
| Use Case | When preferring the text to be judged as black (back side at duplex reading with 1 path) | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | -3 to 3 | |
| Default Value | 0 | |
| ACS-ADJ3 | 1 | Set ACS B&W/color jdgmt stdrd:back side |
| Detail | To set the judgment level of B&W/color original in ACS mode (back side at duplex reading with 1 path). As the value is increased, the original tends to be detected as a B&W document, and as the value is decreased, the original tends to be detected as a color document. | |
| Use Case | When adjusting the color detection level in ACS mode (back side at duplex reading with 1 path) | |
| Adj/Set/Operate Method | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | -3 to 3 | |
| Default Value | 0 | |

COPIER (Service mode for printer) > ADJUST (Adjustment mode) > MISC

| ACS-EN3 | 2 | Set of ACS mode judgment area: back side |
|-------------------------------|---|---|
| Detail | | To set the judgment area in ACS mode (back side at duplex reading with 1 path). As the greater value is set, the judgment area is widened. |
| Use Case | | When adjusting the judgment area in ACS mode (back side at duplex reading with 1 path) |
| Adj/Set/Operate Method | | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | -2 to 2 |
| Default Value | | 1 |
| ACS-CNT3 | 2 | ACS mode judgment pixel count area: back |
| Detail | | To set the area which counts the pixel to judge the color presence in ACS mode (back side at duplex reading with 1 path). As the greater value is set, the judgment area is widen. |
| Use Case | | When adjusting the area which counts the pixel to judge the color presence in ACS mode (back side at duplex reading with 1 path) |
| Adj/Set/Operate Method | | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | -2 to 2 |
| Default Value | | 0 |

FUNCTION (Operation / inspection mode)

■ INSTALL

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > INSTALL

| STRD-POS | 1 | Scan position auto adj in DADF mode |
|-------------------------------|---|---|
| Detail | | To adjust the DADF scanning position automatically. |
| Use Case | | At DADF installation/uninstallation |
| Adj/Set/Operate Method | | 1) Close the DADF. 2) Select the item, and then press OK key. The operation automatically stops after the adjustment. 3) Write the value displayed by COPIER> ADJUST> ADJ-XY> STRD-POS in the service label. |
| Caution | | Write the adjusted value in the service label. |
| Display/Adj/Set Range | | At normal termination: OK, At abnormal termination: NG |
| Related Service Mode | | COPIER> ADJUST> ADJ-XY> STRD-POS |
| CARD | 1 | Card number setting |
| Detail | | To set the card number to be used for Card Reader. A series of numbers from the entered number to the number of cards specified by CARD-RNG can be used. |
| Use Case | | - At installation of the Card Reader - After replacement of the HDD |
| Adj/Set/Operate Method | | 1) Enter the number, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | The card management information (department ID and password) is initialized. |
| Display/Adj/Set Range | | 1 to 2001 |
| Default Value | | 1 |
| Related Service Mode | | COPIER> OPTION> FNC-SW> CARD-RNG |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > INSTALL

| | | |
|-------------------------------|----------|--|
| E-RDS | 1 | ON/OFF of Embedded-RDS |
| Detail | | To set whether to use the E-RDS. |
| Use Case | | When using Embedded-RDS |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | Be sure to use E-RDS, RGW-PORT, COM-TEST, COM-LOG and RGW-ADR as a set. |
| Display/Adj/Set Range | | 0 to 1 0: Not used, 1: Used (All the counter information is sent.) |
| Default Value | | It differs according to the location. |
| Related Service Mode | | COPIER> FUNCTION> INSTALL> RGW-PORT, COM-TEST, COM-LOG, RGW-ADR COPIER> FUNCTION> CLEAR> ERDS-DAT |
| Supplement/Memo | | Embedded-RDS: Function to send device information such as the device counter, failure, and consumables to the sales company's server via SOAP protocol |
| RGW-PORT | 1 | Set port number of Sales Co's server |
| Detail | | To set the port number of the sales company's server to be used for Embedded-RDS. |
| Use Case | | When using Embedded-RDS |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | Be sure to use E-RDS, RGW-PORT, COM-TEST, COM-LOG and RGW-ADR as a set. |
| Display/Adj/Set Range | | 1 to 65535 |
| Default Value | | 443 |
| Related Service Mode | | COPIER> FUNCTION> INSTALL> E-RDS, COM-TEST, COM-LOG, RGW-ADR |
| Supplement/Memo | | Embedded-RDS: Function to send device information such as the device counter, failure, and consumables to the sales company's server via SOAP protocol |
| COM-TEST | 1 | Dspl connect result w/ Sales Co's server |
| Detail | | To display the result of the connection test with the sales company's server. |
| Use Case | | When using Embedded-RDS |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Caution | | Be sure to use E-RDS, RGW-PORT, COM-TEST, COM-LOG and RGW-ADR as a set. |
| Display/Adj/Set Range | | During operation: ACTIVE, When connection is completed: OK, When connection is failed: NG |
| Related Service Mode | | COPIER> FUNCTION> INSTALL> E-RDS, RGW-PORT, COM-LOG, RGW-ADR |
| Supplement/Memo | | Embedded-RDS: Function to send device information such as the device counter, failure, and consumables to the sales company's server via SOAP protocol |
| COM-LOG | 1 | Dspl connect error w/ Sales Co's server |
| Detail | | To display error information when the connection with the sales company's server failed. |
| Use Case | | When using Embedded-RDS |
| Adj/Set/Operate Method | | N/A (Display only) |
| Caution | | Be sure to use E-RDS, RGW-PORT, COM-TEST, COM-LOG and RGW-ADR as a set. |
| Display/Adj/Set Range | | Year, date, time, error code, error detail information (maximum 128 characters) |
| Related Service Mode | | COPIER> FUNCTION> INSTALL> E-RDS, RGW-PORT, COM-TEST, RGW-ADR |
| Supplement/Memo | | Embedded-RDS: Function to send device information such as the device counter, failure, and consumables to the sales company's server via SOAP protocol |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > INSTALL

| | | |
|----------------------------------|----------|--|
| RGW-ADR | 1 | URL setting of Sales Company's server |
| Detail | | To set the URL of the sales company's server to be used for Embedded-RDS. |
| Use Case | | When using Embedded-RDS |
| Adj/Set/Operate Method | | 1) Select the URL. 2) Enter the URL, and then press OK key. 3) Turn OFF/ON the main power switch. |
| Caution | | - Do not use Shift-JIS character strings. - Be sure to use E-RDS, RGW-PORT, COM-TEST, COM-LOG and RGW-ADR as a set. |
| Display/Adj/Set Range | | URL |
| Default Value | | https://b01.ugwdevice.net/ugw/agentif010 |
| Related Service Mode | | COPIER> FUNCTION> INSTALL> E-RDS, RGW-PORT, COM-TEST, COM-LOG |
| Supplement/Memo | | Embedded-RDS: Function to send device information such as the device counter, failure, and consumables to the sales company's server via SOAP protocol |
| CNT-DATE | 1 | Set counter send start date to SC server |
| Detail | | To set the year, month, date, hour and minute to send counter information to the sales company's server. This is displayed only when the Embedded-RDS third-party extended function is available. |
| Use Case | | When the non-Canon-made extension function of the Embedded-RDS is available |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | YYYYMMDDHHMM (12 digits) YYYY: Year, MM: Month, DD: Date, HH: Hour, MM: Minute |
| Default Value | | 000000000000 |
| Supplement/Memo | | Embedded-RDS: Function to send device information such as the device counter, failure, and consumables to the sales company's server via SOAP protocol |
| CNT-INTV | 1 | Set counter send interval to SC server |
| Detail | | To set the interval of sending counter information to the sales company's server in a unit of one hour. This is displayed only when the Embedded-RDS third-party extended function is available. |
| Use Case | | When using the Embedded-RDS third-party extended function |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 1 to 168 (=1 week) |
| Unit | | hour |
| Default Value | | 24 |
| Supplement/Memo | | Embedded-RDS: Function to send device information such as the device counter, failure, and consumables to the sales company's server via SOAP protocol |
| Amount of Change per Unit | | 1 |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > INSTALL

| | | |
|----------------------------------|--|--|
| CDS-CTL | 1 | Set country/area when using CDS |
| Detail | To set country/region to enable CDS. In principle, the default value is the same as that of CONFIG. If the value differs from the country/region of the vice-company of sales, change the setting. | |
| Use Case | When enabling CDS | |
| Adj/Set/Operate Method | 1) Select the item, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | If the setting value is not configured to be the same as the country/region of the vice-company of sales, the necessary firmware may not be able to be downloaded. | |
| Display/Adj/Set Range | JP: Japan, US: USA, GB: Great Britain, FR: France, DE: Germany, IT: Italy, AU: Australia, SG: Singapore, NL: Netherlands, KR: Korea, CN: China, TW: Taiwan, ES: Spain, SE: Sweden, PT: Portugal, NO: Norway, DK: Denmark, FI: Finland, PL: Poland, HU: Hungary, CZ: Czech Republic, SI: Slovenia, GR: Greece, EE: Estonia, RU: Russia, SK: Slovakia, RO: Romania, HR: Croatia, BG: Bulgaria, TR: Turkey, TH: Thailand, VN: Vietnam, AR: Argentina, IN: India, CA: Canada, LA: Latin America, HK: Hong Kong | |
| Default Value | It differs according to the location. | |
| Related Service Mode | COPIER> OPTION> FNC-SW> CONFIG | |
| Supplement/Memo | CDS: Contents Delivery System | |
| RDSHDPOS | 1 | Auto adj of Reader shading position |
| Detail | To automatically adjust the Scanner Unit (Front) position in feed direction when reading the White Plate on the left edge of the Copyboard Glass. The adjustment result is reflected to ADJ-S. | |
| Use Case | When replacing the Scanner Unit (Front) | |
| Adj/Set/Operate Method | Select the item, and then press OK key. | |
| Display/Adj/Set Range | At start of operation: START, During operation: ACTIVE, When operation finished normally: OK! | |
| Required Time | 10 sec | |
| Related Service Mode | COPIER> ADJUST> ADJ-XY> ADJ-S | |
| Supplement/Memo | Shading: It determines the white color reference by reading the White Plate. | |
| BIT-SVC | 1 | OFF/ON of Web service of E-RDS |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set ON/OFF of Web service function of E-RDS. When OFF is selected, authentication information cannot be obtained from E-RDS. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 1 | |
| NFC-USE | 1 | ON/OFF of NFC option |
| Detail | To set whether to enable the installed NFC option. Set 1 when using the NFC option. [Use NFC Card Emulation] is displayed in [Settings/Registration]. | |
| Use Case | When installing the NFC option | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 0 | |
| Additional Functions Mode | Management Settings> Device Management> Use NFC Card Emulation | |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > INSTALL

| | | |
|-------------------------------|--|--|
| BLE-USE | 1 | ON/OFF of BLE module option |
| Detail | To set whether to enable the installed BLE module option. Set 1 when using the BLE module option. The BLE setting screen is displayed in [Settings/Registration]. | |
| Use Case | When installing the BLE module option | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | Do not set 1 when the BLE module option is not installed. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 0 | |
| INSTDTST | 1 | Batch set installation date info: YMDHN |
| Detail | Information on the current date and time is entered collectively in YMDHN of INSTDT by pressing INSTDTST. | |
| Use Case | At installation | |
| Adj/Set/Operate Method | Select the item, and then press OK key. | |
| Related Service Mode | COPIER>OPTION>USER>INSTDT-Y COPIER>OPTION>USER>INSTDT-M COPIER>OPTION>USER>INSTDT-D COPIER>OPTION>USER>INSTDT-H COPIER>OPTION>USER>INSTDT-N | |

■ CCD

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > CCD

| | | |
|-------------------------------|---|--|
| DF-WLVL1 | 1 | White level adj in book mode: color |
| Detail | To adjust the white level for copyboard scanning automatically by setting the paper which is usually used by the user on the Copyboard Glass. | |
| Use Case | - When replacing the Copyboard Glass - When replacing the Scanner Unit (Front) - When replacing the SATA Flash PCB - When clearing the Reader-related RAM data | |
| Adj/Set/Operate Method | 1) Set a paper on the Copyboard Glass. 2) Select the item, and then press OK key. | |
| Caution | Be sure to execute DF-WLVL2 in a row. | |
| Display/Adj/Set Range | During operation: ACTIVE, When operation finished normally: OK! | |
| Related Service Mode | COPIER> FUNCTION> CCD> DF-WLVL2 | |
| DF-WLVL2 | 1 | White level adj in DADF mode: color |
| Detail | To adjust the white level for DADF scanning automatically by setting the paper which is usually used by the user on the DADF. | |
| Use Case | - When replacing the Copyboard Glass - When replacing the Scanner Unit (Front) - When replacing the SATA Flash PCB - When clearing the Reader-related RAM data | |
| Adj/Set/Operate Method | 1) Set paper on the DADF. 2) Select the item, and then press OK key. | |
| Caution | Be sure to execute this item after DF-WLVL1. | |
| Display/Adj/Set Range | During operation: ACTIVE, When operation finished normally: OK! | |
| Related Service Mode | COPIER> FUNCTION> CCD> DF-WLVL1 | |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > CCD

| | | |
|-------------------------------|----------|--|
| DF-LNR | 1 | Deriving of DADF front/back linearity |
| Detail | | To derive the front/back side linearity in DADF mode based on the scanning data which has been backed up at factory. |
| Use Case | | When clearing the Reader-related RAM data/replacing the SATA Flash PCB |
| Adj/Set/Operate Method | | 1) Enter the value of the reader's service label. COPIER> ADJUST> CCD> DFCH-R2, DFCH-G2, DFCH-B2, DFCH-K2, DFCH-R10, DFCH-G10, DFCH-B10, DFCH-K10, DFCH2R2, DFCH2G2, DFCH2B2, DFCH2K2, DFCH2R10, DFCH2G10, DFCH2B10, DFCH2K10 2) Select the item, and then press OK key. |
| Display/Adj/Set Range | | During operation: ACTIVE, When operation finished normally: OK! |
| Related Service Mode | | COPIER> ADJUST> CCD> DFCH-R2/G2/B2/K2/R10/G10/B10/K10, DFCH2R2, DFCH2G2, DFCH2B2, DFCH2K2, DFCH2R10, DFCH2G10, DFCH2B10, DFCH2K10 |
| MTF-CLC | 1 | Deriving of MTF filter coefficient |
| Detail | | To derive the MTF filter coefficient to be set for ASIC based on the MTF value which has been backed up. |
| Use Case | | When clearing the Reader-related RAM data/replacing the SATA Flash PCB |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Caution | | Be sure to enter the MTF values for the Scanner Unit (Front/Back) in MTF-M1 to 12/S1 to 12 and MTF2-M1 to 12/S1 to 12 in advance. |
| Display/Adj/Set Range | | During operation: ACTIVE, When operation finished normally: OK! |
| Related Service Mode | | COPIER> ADJUST> CCD> MTF-M1 - M12, MTF-S1 - S12, MTF2-M1 - M12, MTF2-S1 - S12 |
| Supplement/Memo | | MTF values are written on the label of the Scanner Unit (Front/Back). |
| CL-AGC | 1 | Adj Scan Unit white/black ref level: AGC |
| Detail | | To adjust the black/white reference level of the Scanner Unit automatically (automatic gain control). To make the adjustment with both resolutions 300 dpi and 600 dpi. |
| Use Case | | - When replacing the Copyboard Glass - When replacing the Scanner Unit |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. 2) After "OK!" is displayed, turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | During operation: ACTIVE, When operation finished normally: OK! |
| Related Service Mode | | COPIER> ADJUST> CCD> OFST-CL0 - OFST-CL5, OFST2CL0 - OFST2CL5, GAIN-CL0, GAIN2CL0, LED-CL-R/G/B, LED2CL-R/G/B, LED-CLR2, LED-CLG2, LED-CLB2, LED2CLR2, LED2CLG2, LED2CLB2 |
| BK-SHD1 | 1 | Paper back shading correction 1 |
| Detail | | To generate the paper back shading correction data by scanning the Standard White Plate of the Paper Back Reading Glass with the Scanner Unit (Back). |
| Use Case | | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) |
| Adj/Set/Operate Method | | 1) Clean the glass of the Scanner Unit (Back) and the Reading Glass. 2) Close the DADF. 3) Select the item, and then press OK key. |
| Caution | | Execute the correction in the following order: BK-SHD1, BK-SHD2 and then BK-SHD3. |
| Display/Adj/Set Range | | During operation: ACTIVE, At normal termination: OK, At abnormal termination: NG |
| Related Service Mode | | COPIER> FUNCTION> CCD> BK-SHD2/3 |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > CCD

| | | |
|-------------------------------|----------|---|
| BK-SHD2 | 1 | Paper back shading correction 2 |
| Detail | | To generate the paper back shading correction data by scanning the white sheet with the Scanner Unit (Paper Back) after affixing the sheet to the Paper Back Reading Glass. |
| Use Case | | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) |
| Adj/Set/Operate Method | | 1) Affix the white sheet to the Reading Glass. 2) Select the item, and then press OK key. |
| Caution | | - Remove the white sheet after execution. - Execute the correction in the following order: BK-SHD1, BK-SHD2 and then BK-SHD3. |
| Display/Adj/Set Range | | During operation: ACTIVE, At normal termination: OK, At abnormal termination: NG |
| Related Service Mode | | COPIER> FUNCTION> CCD> BK-SHD1/3 |
| BK-SHD3 | 1 | Paper back shading correction 3 |
| Detail | | To generate the paper back shading correction data by scanning the Standard White Plate of the Paper Back Reading Glass with the Scanner Unit (Back). |
| Use Case | | - When replacing the SATA Flash PCB - When replacing the Scanner Unit (Back) |
| Adj/Set/Operate Method | | 1) Clean the glass of the Scanner Unit (Back) and the Reading Glass. 2) Close the DADF. 3) Select the item, and then press OK key. |
| Caution | | Execute the correction in the following order: BK-SHD1, BK-SHD2 and then BK-SHD3. |
| Display/Adj/Set Range | | During operation: ACTIVE, At normal termination: OK, At abnormal termination: NG |
| Related Service Mode | | COPIER> FUNCTION> CCD> BK-SHD1/2 |

■ PANEL

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > PANEL

| | | |
|-------------------------------|----------|--|
| LCD-CHK | 1 | Check of LCD Panel dot missing |
| Detail | | To check whether there is a missing dot on the LCD Panel of the Control Panel. |
| Use Case | | When replacing the LCD Panel |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. 2) Check that the LCD Panel lights up in the order of white, black, red, green and blue. 3) Press STOP key to terminate checking. |
| LED-CHK | 1 | Check of Control Panel LED |
| Detail | | To check whether the LED on the Control Panel lights up. |
| Use Case | | When replacing the LCD Panel |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. 2) Check that the LED lights up in the order. 3) Use LED-OFF to terminate checking. |
| Related Service Mode | | COPIER> FUNCTION> PANEL> LED-OFF |
| LED-OFF | 1 | End check of Control Panel LED |
| Detail | | To terminate the check of LED on the Control Panel. |
| Use Case | | During execution of LED-CHK |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Related Service Mode | | COPIER> FUNCTION> PANEL> LED-CHK |
| KEY-CHK | 1 | Check of key entry |
| Detail | | To check the key input on the Control Panel. |
| Use Case | | When replacing the LCD Panel |
| Adj/Set/Operate Method | | 1) Select the item and press the key on the Control Panel. 2) Check that the input value is displayed. 3) Cancel the selection to terminate checking. |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > PANEL

| | | |
|-------------------------------|---|--|
| TOUCHCHK | 1 | Adj of coordinate pstn of Touch Panel |
| Detail | To adjust the coordinate position on the Touch Panel of the Control Panel. | |
| Use Case | When replacing the LCD Panel | |
| Adj/Set/Operate Method | 1) Select the item, and then press OK key. 2) Press the nine "+" keys in sequence. | |

■ PART-CHK

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > PART-CHK

| | | |
|-------------------------------|--|--|
| CL | 1 | Specification of operation clutch |
| Detail | To specify the clutch to operate. | |
| Use Case | When replacing the clutch/checking the operation | |
| Adj/Set/Operate Method | Enter the value, and then press OK key. | |
| Display/Adj/Set Range | 6 to 9 6: Not used 7: Cassette 2 Feed Clutch (CL602) 8: Duplex Feed Clutch (CL2) 9: Duplex Reverse Clutch (CL4) | |
| Default Value | 6 | |
| Related Service Mode | COPIER> FUNCTION> PART-CHK> CL-ON | |
| CL-ON | 1 | Operation check of Clutch |
| Detail | To start operation check of the clutch specified by CL. The operation automatically stops after operation of 10 seconds. | |
| Use Case | When replacing the Clutch/checking the operation | |
| Adj/Set/Operate Method | Select the item, and then press OK key. | |
| Display/Adj/Set Range | During operation: ACTIVE, When operation finished normally: OK! | |
| Related Service Mode | COPIER> FUNCTION> PART-CHK> CL | |
| MTR | 1 | Specification of operation motor |
| Detail | To specify the motor to operate. | |
| Use Case | When replacing the motor/checking the operation | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 4 0: Scanner Motor (M4) 1: Drum Motor (M2) 2: Developing Drive Unit (M2+SL2) 3: Fixing Motor (M1) 4: Fixing pressure release drive test (M1) | |
| Default Value | 0 | |
| Related Service Mode | COPIER> FUNCTION> PART-CHK> MTR-ON | |
| MTR-ON | 1 | Operation check of Motor |
| Detail | To start operation check of the Motor specified by MTR. The operation automatically stops after operation of 10 seconds. | |
| Use Case | When replacing the Motor/checking the operation | |
| Adj/Set/Operate Method | Select the item, and then press OK key. | |
| Display/Adj/Set Range | During operation: ACTIVE, When operation finished normally: OK! | |
| Related Service Mode | COPIER> FUNCTION> PART-CHK> MTR | |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > PART-CHK

| SL | 1 | Specification of operation solenoid |
|-------------------------------|---|--|
| Detail | | To specify the solenoid to operate. |
| Use Case | | When replacing the solenoid/checking the operation |
| Adj/Set/Operate Method | | Enter the value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 5 0: Multi-purpose Tray Pickup Solenoid (SL1) 1: Cassette 1 Pickup Clutch (CL3) 2: Option Cassette 2 Pickup Clutch (CL601/CL15/CL5) 3: Option Cassette 3 Pickup Clutch (CL601/CL7) 4: Option Cassette 4 Pickup Clutch (CL601) 5: Not used |
| Default Value | | 0 |
| Related Service Mode | | COPIER> FUNCTION> PART-CHK> SL-ON |
| SL-ON | 1 | Operation check of Solenoid |
| Detail | | To start operation check for the Solenoid specified by SL. The operation automatically stops after operation of 10 seconds. |
| Use Case | | When replacing the Solenoid/checking the operation |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Display/Adj/Set Range | | During operation: ACTIVE, When operation finished normally: OK! |
| Related Service Mode | | COPIER> FUNCTION> PART-CHK> SL |

■ CLEAR

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > CLEAR

| ERR | 1 | Clear of error code |
|-------------------------------|---|---|
| Detail | | To clear the specific error code. |
| Use Case | | At error occurrence |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. 2) Turn OFF/ON the main power switch. |
| R-CON | 1 | Clearing of Reader-related setting data |
| Detail | | To clear the Reader-related setting data. |
| Use Case | | When clearing the Reader-related setting data |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | - Output the service mode setting values by P-PRINT before execution. After execution, enter necessary setting values. - The RAM data is cleared after the main power switch is turned OFF/ON. |
| Related Service Mode | | COPIER> FUNCTION> MISC-P> P-PRINT |
| JAM-HIST | 1 | Clear of jam history |
| Detail | | To clear the jam history. |
| Use Case | | When clearing the jam history |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Related Service Mode | | COPIER> DISPLAY> JAM |
| ERR-HIST | 1 | Clear of error code history |
| Detail | | To clear the error code history. |
| Use Case | | When clearing the error code history |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Related Service Mode | | COPIER> DISPLAY> ERR |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > CLEAR

| | | |
|-------------------------------|----------|---|
| PWD-CLR | 1 | Clear of system administrator password |
| Detail | | * Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To clear the password of the system administrator set in [Settings/Registration]. |
| Use Case | | When clearing the password of the system administrator |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| ADRS-BK | 1 | Clear of address book |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To clear the address book data. |
| Use Case | | When clearing the address book data |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | The address book data is cleared after the main power switch is turned OFF/ON. |
| CNT-MCON | 1 | Clear of Main Controller service counter |
| Detail | | To clear the service counter counted by the Main Controller PCB. |
| Use Case | | When clearing the service counter counted by the Main Controller PCB |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Related Service Mode | | COPIER> COUNTER |
| Supplement/Memo | | See COUNTER for the target counter. |
| CNT-DCON | 1 | Clear of DC Controller service counter |
| Detail | | To clear the service counter counted by the DC Controller PCB. |
| Use Case | | When clearing the service counter counted by the DC Controller PCB |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Related Service Mode | | COPIER> COUNTER |
| MMI | 1 | Clear Settings/Registration setting VL |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To clear the Settings/Registration setting values. - Preferences (excluding values for Paper Type Management Settings) - Adjustment/Maintenance - Function Settings - Set Destination (excluding Address Lists) - Management Settings (excluding Department ID Management) |
| Use Case | | When clearing various setting values of [Settings/Registration] |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | - The setting value is cleared after the main power switch is turned OFF/ON. - If this item is executed while a login application other than User Authentication is running, it switched to User Authentication after reboot. Set the login application using SMS as needed. |
| Supplement/Memo | | SMS (Service Management Service): An application for management which can be used on remote UI. |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > CLEAR

| | | |
|-------------------------------|----------|--|
| MN-CON | 1 | Deletion of setting values |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To delete the setting values of address lists, forwarding settings, Settings/Registration and service mode. For details, refer to "Backup Data List" in the Service Manual. |
| Use Case | | When initializing the setting values |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. The machine is automatically rebooted. 2) Turn OFF/ON the main power switch. |
| Caution | | - Output the service mode setting values by P-PRINT before execution. After execution, enter necessary setting value. - RAM data is cleared after the main power switch is turned OFF/ON. |
| Related Service Mode | | COPIER> FUNCTION> MISC-P> P-PRINT |
| CARD | 1 | Clear of card ID-related data |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To clear the data related to the card ID (department). |
| Use Case | | When clearing the data related to the card ID |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | The value is cleared after the main power switch is turned OFF/ON. |
| ALARM | 1 | Clear of alarm log |
| Detail | | To clear alarm log. |
| Use Case | | When clearing alarm log |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | The alarm log is cleared after the main power switch is turned OFF/ON. |
| Related Service Mode | | COPIER> DISPLAY> ALARM-2 |
| CA-KEY | 2 | Deletion of CA certificate and key pair |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To simultaneously delete the CA certificate and key pair which are additionally registered by the user. |
| Use Case | | When a service person replaces/discards the device |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. 2) Check that OK is displayed. 3) Turn OFF/ON the main power switch. |
| Caution | | - Unless this item is executed at the time of replacement/discard of the device, the CA certificate and key pair which are additionally registered by the user remain in the HDD, which is a problem in terms of security. - Do not execute this item carelessly because the CA certificate and key pair which are additionally registered are deleted when it is executed. If they are deleted mistakenly, they need to be again registered by the user. If no CA certificate and key pair are additionally registered, the machine condition becomes the same as the one at the time of factory shipment. - When NG is displayed in 2), there is a possibility that deletion was not executed. In this case, surely execute the deletion by initializing the HDD, etc. |
| Display/Adj/Set Range | | At normal termination: OK!, At abnormal termination: NG! |
| Supplement/Memo | | - The CA certificate is used in the MEAP application with E-RDS and SSL client connection, and the key pair is used in the SSL function of IPP, RUI and MEAP. - When the main power switch is turned OFF/ON, the CA certificate and key pair which were registered at the time of factory shipment are decompressed from the archive , and become available in the E-RDS/SSL function. |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > CLEAR

| | | |
|----------------------------------|----------|--|
| ERDS-DAT | 1 | Initialization of E-RDS SRAM data |
| Detail | | To initialize the SCM value of the Embedded-RDS stored in the SRAM. SCM values are ON/OFF of E-RDS, server's port number, server's SOAP URL, and communication schedule with the server (how often the data is acquired), etc. The values set in E-RDS, RGW-PORT, RGW-ADR, and COM-LOG are cleared. |
| Use Case | | When upgrading the Bootable in the E-RDS environment |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Caution | | Use of the SRAM in E-RDS differs depending on the Bootable version. Therefore, unless the SRAM data is cleared at the time of version upgrade, data inconsistency occurs. |
| Display/Adj/Set Range | | At normal termination: OK!, At abnormal termination: NG! |
| Related Service Mode | | COPIER> FUNCTION> INSTALL> E-RDS, RGW-PORT, RGW-ADR, COM-LOG |
| USBM-CLR | 1 | Initialize USB MEAP priority rgst info |
| Detail | | To initialize the registered ID data retained in the OS field by calling the API provided by the OS. |
| Use Case | | When a failure occurs in USB MEAP priority registration |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| JV-CACHE | 1 | Cache clear of JAVA application |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To clear the cache information used by JAVA application. |
| Use Case | | When initializing the JAVA application |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| LANG-CLR | 2 | Uninstallation of language files |
| Detail | | To uninstall the language files other than Japanese and English files installed in HDD. When installing a new language file while the maximum number of language files (11 files) have been already installed, an existing language file needs to be uninstalled. |
| Use Case | | When deleting/switching language files |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. 2) Download the firmware in which the necessary language files are included using SST or a USB flash drive. |
| Caution | | A language file is not uninstalled unless the downloaded language files are installed by SST or a USB flash drive after the execution of this item. If installation is not executed, uninstallation will be canceled. (Status of the machine remains the same as it was before execution.) |
| Supplement/Memo | | - After the execution, language displayed on the screen becomes English. Switch the language as needed. - There are 9 language files (JEFIGSCKT) installed at the time of shipment. |
| FIN-MCON | 1 | Clearing Finisher delvry destination set |
| Detail | | To clear the setting of Delivery Tray of the Finisher specified in [Settings/Registration] (Function Settings> Common> Paper Output Settings> Output Tray Settings). Since the delivery destination settings are stored in the DC Controller PCB in the machine, malfunction occurs when replacing the Finisher with another type of it without clearing the settings. If the type of Finishers is the same, there is no need to clear the settings. |
| Use Case | | When the Finisher is replaced with a different model in the field |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Additional Functions Mode | | Function Settings> Common> Paper Output Settings> Output Tray Settings |
| PLPW-CLR | 2 | Clear security policy setting password |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To clear the password of the security administrator set in the security policy settings. |
| Use Case | | When clearing the password of the security administrator |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > CLEAR

| | | |
|-------------------------------|----------|--|
| JV-TYPE | 1 | Specification of MEAP cache clear target |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To specify the MEAP cache area to be cleared. The target area is divided into the 4 parts: - A jar file of MEAP application bundled as standard - Data of the application mentioned above - A jar file of MEAP application installed additionally - Data of the application mentioned above When JV-CACHE is executed, the area specified with this item is cleared. For details, refer to the Service Manual. |
| Use Case | | When analyzing the cause of a problem due to MEAP application |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 4 0: Entire MEAP cache area 1: A jar file of MEAP application bundled as standard 2: A jar file and data of MEAP application bundled as standard 3: Data of MEAP application which has been installed additionally 4: A jar file and data of MEAP application which has been installed additionally |
| Related Service Mode | | COPIER> FUNCTION> CLEAR> JV-CACHE |
| Supplement/Memo | | MEAP applications bundled as standard: system application, built-in login application MEAP applications installed additionally: non-Canon-made login application, general application, etc. |

| | | |
|-------------------------------|----------|---|
| CUSTOM2 | 2 | [For customization] |
| DUTL-CLR | 2 | For R&D |
| CNT-RCON | 1 | Clear of RCON service counter |
| Detail | | To clear the service counter counted by the RCON management software. |
| Use Case | | When clearing the service counter counted by the RCON |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |

■ MISC-R

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > MISC-R

| | | |
|-------------------------------|----------|--|
| SCANLAMP | 1 | Lighting check of Scanner Unit (Frt) LED |
| Detail | | To light up the Scanning Lamp for 3 seconds under the White Plate and the Copyboard Glass respectively. |
| Use Case | | When replacing the LED of the Scanner Unit |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Display/Adj/Set Range | | During operation: ACTIVE, When operation finished normally: OK! |
| SCANLMP2 | 1 | Lighting check of Scanner Unit (Bck) LED |
| Detail | | To light up the LED of the Scanner Unit (Back) for 3 sec. Check whether there is a missing block or no lighting in LED. |
| Use Case | | When replacing the LED of the Scanner Unit |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Display/Adj/Set Range | | During operation: ACTIVE, When operation finished normally: OK! |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > MISC-R

| | | |
|-------------------------------|--|---|
| RD-SHPOS | 2 | Moving to Reader Scanner Unit fix pstn |
| Detail | To move the Reader Scanner Unit to the position where it is secured in when moving. When moving the Reader after installation, the Reader Scanner Unit may move and get damage. By moving the Scanner Unit to the specified position and securing it in place with a screw before moving, damage can be prevented. | |
| Use Case | When moving the Reader after installation | |
| Adj/Set/Operate Method | Select the item, and then press OK key. | |
| Caution | Be sure to move the Scanner Unit to the fixing position and secure it in place with a screw when moving the Reader after installation. Otherwise, the Scanner Unit may get damage. | |
| Display/Adj/Set Range | During operation: ACTIVE, When operation finished normally: OK! | |
| SCAN-ON | 1 | Execution of copyboard reading operation |
| Detail | To execute the reading operation with the Copyboard. | |
| Use Case | When checking the operation of the motor of the Reader | |
| Adj/Set/Operate Method | Select the item, and then press OK key. | |
| Display/Adj/Set Range | During operation: ACTIVE, When operation finished normally: OK! | |

■ MISC-P

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > MISC-P

| | | |
|----------------------------------|--|--|
| P-PRINT | 1 | Output of service mode setting values |
| Detail | To output the service mode setting values. Text data is saved in HDD as a file (P-PRINT-RPT.TXT). | |
| Use Case | Before executing the CLEAR service mode, etc. | |
| Adj/Set/Operate Method | Select the item, and then press OK key. | |
| Caution | Be sure to use A4/LTR size plain paper/recycled paper. | |
| Display/Adj/Set Range | During operation: ACTIVE, When operation finished normally: OK! | |
| Related Service Mode | COPIER> FUNCTION> MISC-P> RPT-FILE | |
| HIST-PRT | 1 | Output of jam and error logs |
| Detail | To output the jam log and error log. Text data is saved in HDD as a file (HIST-PRT-RPT.TXT). | |
| Use Case | When outputting the jam/error log | |
| Adj/Set/Operate Method | Select the item, and then press OK key. | |
| Caution | Be sure to use A4/LTR size plain paper/recycled paper. | |
| Display/Adj/Set Range | During operation: ACTIVE, When operation finished normally: OK! | |
| Related Service Mode | COPIER> FUNCTION> MISC-P> RPT-FILE | |
| TRS-DATA | 2 | Moving memory reception data to Inbox |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To move the data received in memory to Inbox. | |
| Use Case | When moving the data received in memory to Inbox | |
| Adj/Set/Operate Method | 1) Select the item, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Additional Functions Mode | Fax/I-Fax Inbox> Memory RX Inbox | |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > MISC-P

| | | |
|-------------------------------|----------|---|
| USER-PRT | 1 | Settings/Registration menu list output |
| Detail | | To output Settings/Registration menu list. Text data is saved in HDD as a file (USER-PRT-RPT.TXT). |
| Use Case | | When outputting Settings/Registration menu list. |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Display/Adj/Set Range | | During operation: ACTIVE, When operation finished normally: OK! |
| Related Service Mode | | COPIER> FUNCTION> MISC-P> RPT-FILE |
| Supplement/Memo | | It takes approximately 3 seconds before output starts. |
| LBL-PRNT | 1 | Output of service label |
| Detail | | To print the service label. |
| Use Case | | When printing the service label |
| Adj/Set/Operate Method | | 1) Place A4/LTR paper in Cassette 1. 2) Select the item, and then press OK key. |
| Caution | | Be sure to use A4/LTR size plain paper/recycled paper. |
| ENV-PRT | 1 | Outpt inside temp&hmdy/Fix Rol temp log |
| Detail | | To output data of the temperature and humidity inside the machine/surface temperature of the Fixing Roller as a log. Text data is saved in HDD as a file (ENV-PRT-RPT.TXT). |
| Use Case | | When figuring out the past temperature inside the machine/fixing temperature information at problem analysis |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Display/Adj/Set Range | | During operation: ACTIVE, When operation finished normally: OK! |
| Related Service Mode | | COPIER> FUNCTION> MISC-P> RPT-FILE |
| PJH-P-1 | 1 | Outpt print job log detail info:100 jobs |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To output the print job logs of the latest 100 jobs with detailed information. In the case of less than 100 jobs, the logs of all print jobs are output. Text data is saved in HDD as a file (PJH-P-1-RPT.TXT). |
| Use Case | | When outputting the print job logs with detailed information |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Caution | | Be sure to use A4/LTR size plain paper/recycled paper. |
| Display/Adj/Set Range | | During operation: ACTIVE, When operation finished normally: OK! |
| Related Service Mode | | COPIER> FUNCTION> MISC-P> RPT-FILE |
| Supplement/Memo | | Output the print job logs with detailed information which are not displayed/output in the job log screen under "System Monitor>Print>Log>Printer" and in the report of the print job log. |
| PJH-P-2 | 1 | Outpt print job log detail info:all jobs |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To output all print job logs stored in the machine with detailed information (for maximum 5000 jobs). The difference between PJH-P-1 and this item is only the number of jobs output. Text data is saved in HDD as a file (PJH-P-2-RPT.TXT). |
| Use Case | | When printing the print job history with detailed information |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Caution | | Be sure to use A4/LTR size plain paper/recycled paper. |
| Display/Adj/Set Range | | During operation: ACTIVE, When operation finished normally: OK! |
| Related Service Mode | | COPIER> FUNCTION> MISC-P> RPT-FILE |
| Supplement/Memo | | Output the print job logs with detailed information which are not displayed/output in the job log screen under "System Monitor>Print>Log>Printer" and in the report of the print job log. |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > MISC-P

| | | |
|-------------------------------|----------|--|
| USBH-PRT | 1 | Output of USB device information report |
| Detail | | To output information of the connected USB device in the form of a report. Text data is saved in HDD as a file (USBH-PRT-RPT.TXT). |
| Use Case | | When outputting information of the USB device in the form of a report |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Caution | | Be sure to use A4/LTR size plain paper/recycled paper. |
| Display/Adj/Set Range | | During operation: ACTIVE, When operation finished normally: OK! |
| Related Service Mode | | COPIER> FUNCTION> MISC-P> RPT-FILE |
| RPT-FILE | 1 | Output of report print file |
| Detail | | To save various service reports in HDD as a file. The files can be obtained using PC to which SST has been installed or USB memory device after starting the machine in download mode. |
| Use Case | | When obtaining the service report as a file instead of printing the report out |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Supplement/Memo | | File size: Approx. 1 MB at a maximum |
| RPT2USB | 1 | Write serv rpt file to USB flash drive |
| Detail | | To store the report file of service mode saved in HDD by RPT-FILE to a USB flash drive. |
| Use Case | | When storing the report file of service mode to a USB flash drive |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Related Service Mode | | COPIER> FUNCTION> MISC-P> RPT-FILE |
| TNRB-PRT | 1 | Output of Toner Container ID report |
| Detail | | To output the ID of the Toner Container in the form of a report. Text data is saved in HDD as a file (TNRB-PRT-RPT.TXT). |
| Use Case | | When checking the ID of the Toner Container |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Display/Adj/Set Range | | 12-digit alphanumeric |
| Related Service Mode | | COPIER> FUNCTION> MISC-P> RPT-FILE |

■ SYSTEM

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > SYSTEM

| | | |
|-------------------------------|----------|--|
| DOWNLOAD | 1 | Shift to download mode |
| Detail | | To make the machine enter the download mode and wait for a command. Perform downloading by SST or a USB flash drive. |
| Use Case | | At upgrade |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. 2) Perform downloading by SST or a USB flash drive. |
| Caution | | Do not turn OFF/ON the power during downloading. |
| Supplement/Memo | | SST: Service Support Tool |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > SYSTEM

| | | |
|-------------------------------|----------|--|
| CHK-TYPE | 1 | Spec HD-CLEAR/HD-CHECK exe partition No. |
| Detail | | To specify the partition number of the HDD to execute HD-CLEAR/HD-CHECK. |
| Use Case | | When executing HD-CLEAR/HD-CHECK |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 65535 0: All partitions (only the areas where the operation can be executed) 1: PDL-related file storage area 2: Image data storage area 3: MEAP-related area 4: Not used 5 and 6: Image data storage area 7: General application temporary area (temporary file) 8: General application-related area 9: PDL spool data (temporary file) 10: SEND-related area 11: Update-related area 12: License-related area 13: System area 14: SWAP (temporary file/memory alternative area) 15 to 16: Not used 17: Debug log area 18: Advanced Box image data storage area 19: Print data storage area 20 to 65535: Not used * When 4, 12, 13, 15 or 16 is set, nothing is cleared even if HD-CLEAR is executed. * For 2, 5 and 6, HD-CLEAR/HD-CHECK is executed to all of the areas by selecting one of them. * By selecting 8, HD-CLEAR/HD-CHECK is also executed to 7, 9, 11 and 17. |
| Default Value | | 0 |
| Related Service Mode | | COPIER> FUNCTION> SYSTEM> HD-CLEAR, HD-CHECK |
| HD-CHECK | 1 | File system check of specified partition |
| Detail | | To execute system check of the partition specified by CHK-TYPE at the next startup. |
| Use Case | | When E602/E614 error (file corruption, etc.) occurs |
| Adj/Set/Operate Method | | Enter 1, and then press OK key. |
| Caution | | Be sure to execute this item after CHK-TYPE. |
| Display/Adj/Set Range | | 0 to 1 0: Not executed, 1: Executed at next startup |
| Default Value | | 0 |
| Related Service Mode | | COPIER> FUNCTION> SYSTEM> CHK-TYPE |
| HD-CLEAR | 1 | Initialization of specified partition |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To initialize the partition specified by CHK-TYPE at next startup. |
| Use Case | | When E602/E614 error (file corruption, etc.) occurs |
| Adj/Set/Operate Method | | Enter 1, and then press OK key. |
| Caution | | Be sure to execute this item after CHK-TYPE. |
| Display/Adj/Set Range | | 0 to 1 0: Not executed, 1: Executed at next startup |
| Related Service Mode | | COPIER> FUNCTION> SYSTEM> CHK-TYPE |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > SYSTEM

| | | |
|-------------------------------|--|---|
| DSRAMBUP | 2 | Backup of DC Controller PCB SRAM |
| Detail | To back up the setting data in SRAM of the DC Controller PCB. | |
| Use Case | When replacing the DC Controller PCB for troubleshooting at the time of trouble occurrence | |
| Adj/Set/Operate Method | Select the item, and then press OK key. | |
| Caution | During operation, the setting data changes by manual or automatic adjustment. When backup data which has been left for a long period of time is restored, it is overwritten with new setting data and the old data is deleted. | |
| Related Service Mode | COPIER> FUNCTION> SYSTEM> DSRAMRES | |
| DSRAMRES | 2 | Restore of DC Controller PCB SRAM |
| Detail | To restore the setting data which has been backed up in SRAM of the DC Controller PCB. | |
| Use Case | When replacing the DC Controller PCB for troubleshooting at the time of trouble occurrence | |
| Adj/Set/Operate Method | Select the item, and then press OK key. | |
| Caution | During operation, the setting data changes by manual or automatic adjustment. When backup data which has been left for a long period of time is restored, it is overwritten with new setting data and the old data is deleted. | |
| Related Service Mode | COPIER> FUNCTION> SYSTEM> DSRAMBUP | |
| RSRAMBUP | 2 | Backup of Reader-related setting data |
| Detail | To back up the Reader-related setting data retained in the SATA Flash PCB on the Main Controller PCB. | |
| Use Case | When replacing the Main Controller PCB/clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | Select the item, and then press OK key. | |
| Caution | During operation, the setting data changes by manual or automatic adjustment. When backup data which has been left for a long period of time is restored, it is overwritten with new setting data and the old data is deleted. | |
| Related Service Mode | COPIER> FUNCTION> SYSTEM> RSRAMRES | |
| RSRAMRES | 2 | Restoration of Reader-related set data |
| Detail | To restore the Reader-related setting data which has been backed up to the SATA Flash PCB on the Main Controller PCB. | |
| Use Case | When replacing the Main Controller PCB/clearing the Reader-related RAM data/replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | 1) Select the item, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | During operation, the setting data changes by manual or automatic adjustment. When backup data which has been left for a long period of time is restored, it is overwritten with new setting data and the old data is deleted. | |
| Related Service Mode | COPIER> FUNCTION> SYSTEM> RSRAMBUP | |
| R-REBOOT | 1 | Reboot of host machine (Remote) |
| Detail | To reboot the host machine. | |
| Use Case | When the reboot is carried out with the remote control by VNC | |
| Adj/Set/Operate Method | Select the item, and then press OK key. | |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > SYSTEM

| | | |
|-------------------------------|---|-------------------------------|
| FIXIP | 1 | Start of fixed IP mode |
| Detail | <p>IP address is set to "172.16.1.100".</p> <p>In an environment where wired LAN (main) and wireless LAN (sub) are used, the IP address of wired LAN becomes the fixed IP.</p> <p>During the fixed IP mode, "FIXIP" is displayed on the upper left of the screen.</p> | |
| Use Case | When preferring to use the network settings with the fixed IP address "172.16.1.100" | |
| Adj/Set/Operate Method | Select the item, and then press OK key. | |
| Caution | <p>- It is necessary to turn OFF/ON the power to recover from the fixed IP mode.</p> <p>- Whether to use RUI or not when the fixed IP mode is enabled follows the setting of "Management Settings> License/Other> Remote UI."</p> | |

■ DBG-LOG

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > DBG-LOG

| | | |
|-------------------------------|--|---|
| LOG2USB | 2 | Storage of debug log to USB memory |
| Detail | <p>To store a set of debug logs to the USB flash drive at the error occurrence.</p> <p>A type of log to be collected is set in LOG-TRIG.</p> <p>If there is a debug log which has been automatically saved, it is archived at this time.</p> <p>Required time differs according to the device conditions and volume of log data.</p> | |
| Use Case | When analyzing the cause of a problem | |
| Adj/Set/Operate Method | <p>1) Install the USB flash drive.</p> <p>2) Select the item, and then press OK key.</p> | |
| Caution | <p>- Wait until the machine recognizes the USB memory (approx. 10 sec.).</p> <p>- During the data transfer ("ACTIVE" display), do not turn OFF the power/remove the USB memory/use the screen for operations.</p> | |
| Display/Adj/Set Range | During operation: ACTIVE, At normal termination: OK, At abnormal termination: NG | |
| Related Service Mode | COPIER> FUNCTION> DBG-LOG> LOG-TRIG | |
| LOG2SRVR | 2 | For R&D |
| LOG-TRIG | 2 | Set of debug log storage condition |
| Detail | <p>To set the conditions (timing, types, etc.) to automatically store the debug logs (stored as an archive file).</p> <p>By reading the operation setting file of the setting value from the Main Controller, the conditions written in the file are set.</p> <p>When setting a new condition is necessary, read the operation setting file provided by R&D from the USB memory.</p> | |
| Use Case | <p>- When changing the conditions of debug log to automatically store</p> <p>- When setting a new condition</p> | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 99999 | |
| Related Service Mode | COPIER> FUNCTION> DBG-LOG> LOG2USB, LOG2SRVR | |
| HIT-STS | 2 | Display of debug log state |
| Detail | To display whether archive file of the debug log which is matched with the conditions set in LOG-TRIG exists or not. | |
| Use Case | When checking the debug log automatically saved | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | <p>0 to 1</p> <p>0: No log is available, 1: Log is available</p> | |
| Related Service Mode | COPIER> FUNCTION> DBG-LOG> LOG-TRIG | |
| SYSLOG | 2 | For R&D |

COPIER (Service mode for printer) > FUNCTION (Operation / inspection mode) > DBG-LOG

| | | |
|-------------------------------|----------|--|
| DEFAULT | 2 | Reset of debug log setting |
| Detail | | To clear all debug log settings and return to the state before debug log collection operation. |
| Use Case | | - When returning the device in which analyzing the cause of a problem was completed - When resetting the debug log settings |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| LOG-DEL | 2 | Clearing of debug logs |
| Detail | | To delete the debug log file. The debug log setting is not reset. |
| Use Case | | When clearing the debug log |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| HIT-STS2 | 2 | For R&D |

OPTION (Specification setting mode)

■ FNC-SW

COPIER (Service mode for printer) > OPTION (Specification setting mode) > FNC-SW

| | | |
|-------------------------------|----------|---|
| MODEL-SZ | 1 | Fixed magnifictn & DADF orgnl dtct size |
| Detail | | To set the fixed magnification ratio display and the original detection size with DADF. It is set automatically at the time of installation of the Reader according to the location. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 3 0: AB configuration (6R5E) for Japan, 1: Inch configuration (5R4E) for North/Middle/South America, 2: A configuration (3R3E) for Europe, 3: AB/Inch configuration (6R5E) for Asia, Oceania, South America |
| Default Value | | It differs according to the location. |
| SCANSLCT | 2 | ON/OFF of scan area calculate function |
| Detail | | To set ON/OFF of the function to calculate scanning area from the specified paper size. When the paper size is larger than the original size, selecting ON reduces productivity because the scanning area gets larger. |
| Use Case | | When matching the scanning area with the paper size |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: OFF (calculated from the detected original size) 1: ON (calculated from the specified paper size) |
| Default Value | | 0 |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > FNC-SW

| | | |
|-------------------------------|----------|---|
| CONFIG | 1 | Set country/area/lang/location/ppr size |
| Detail | | To set the country/region, language, location, paper size configuration for multiple system software in HDD. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Select the setting item. 2) Switch with +/- key, and then press OK key. 3) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | XX YY.ZZ.AA XX: Country/region JP: Japan, US: USA, GB: Great Britain, FR: France, DE: Germany, IT: Italy, AU: Australia, SG: Singapore, NL: Netherlands, KR: Korea, CN: China, TW: Taiwan, ES: Spain, SE: Sweden, PT: Portugal, NO: Norway, DK: Denmark, FI: Finland, PL: Poland, HU: Hungary, CZ: Czech Republic, SI: Slovenia, GR: Greece, EE: Estonia, RU: Russia, SK: Slovakia, RO: Romania, HR: Croatia, BG: Bulgaria, TR: Turkey, TH: Thailand, VN: Vietnam, AR: Argentina, IN: India YY: Language (Fixed; e.g. ja: Japanese) ZZ: Location (Fixed; e.g. 00: CANON) AA: Paper size configuration (00: AB configuration, 01: Inch configuration, 02: A configuration, 03: Inch/AB configuration) |
| Default Value | | It differs according to the location. |
| Related Service Mode | | COPIER> OPTION> FNC-SW> MODEL-SZ |
| W/SCNR | 1 | Setting of Reader Unit installation |
| Detail | | To set installation of the Reader Unit. When the Reader Unit is detected at startup of the machine, "1: Installed" is set automatically. |
| Use Case | | When installing/removing the Reader Unit |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Not installed, 1: Installed |
| Default Value | | 0 (Printer model)/1 (Copier model) |
| SVMD-ENT | 2 | Setting of entry method to service mode |
| Detail | | To set the way to get in service mode to prevent information leak. |
| Use Case | | As needed |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Factory default 1: [Settings/Registration] - Pressing [4] and [9] at the same time - [Settings/Registration] |
| Default Value | | 0 |
| KSIZE-SW | 2 | Setting of K-size paper support |
| Detail | | To set detection/display of K-size paper (for China). When MODEL-SZ is 0, this setting is enabled. |
| Use Case | | When using K size paper |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Not supported, 1: Supported |
| Default Value | | It differs according to the location. |
| Related Service Mode | | COPIER> OPTION> FNC-SW> MODEL-SZ |
| Supplement/Memo | | 8K paper: 270 x 390 mm, 16K paper: 270 x 195 mm |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > FNC-SW

| | | |
|-------------------------------|----------|---|
| PDF-RDCT | 2 | PDF reduction set at forwarding |
| Detail | | To set whether to reduce the image for transmission when converting the image received by I-Fax into PDF for e-mail/file transmission. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Following the current setting, 1: Image reduction |
| Default Value | | 0 |
| SJB-UNW | 2 | Reserve upper limit of secured print job |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the upper limit for the number of reserved jobs in secured print job. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 2 0: 50 jobs, 1: 90 jobs, 2: No limit |
| Default Value | | 1 |
| CARD-RNG | 2 | Card number setting (department number) |
| Detail | | To set the number of cards (departments) that can be used with the Card Reader. |
| Use Case | | When setting the number of cards (departments) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 1 to 1000 |
| Default Value | | 1000 |
| SJOB-CL | 1 | Set of scan job canceling by logout |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to cancel the scan job in operation by logout of the user. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | The job with scanning completed cannot be canceled. |
| Display/Adj/Set Range | | 0 to 2 0: Cancel only scan job in waiting state, 1: Cancel all scan jobs, 2: Not canceled |
| Default Value | | 0 |
| Supplement/Memo | | Scan job: A job after the scanning operation is completed. |
| MIBCOUNT | 2 | Scope range set of Charge Counter MIB |
| Detail | | To set the range of counter information that can be obtained as MIB (Management Information Base). |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 2 0: All charge counters are obtained, 1: Only displayed counter* is obtained, 2: All charge counters are not obtained *: Counter specified by the following: COPIER> OPTION> USER> COUNTER 1 to 6 |
| Default Value | | 0 |
| Related Service Mode | | COPIER> OPTION> USER> COUNTER1 - COUNTER6 |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > FNC-SW

| | | |
|-------------------------------|----------|--|
| CNTR-SW | 1 | Init of parts counter replacement timing |
| Detail | | To return the estimated life of parts counter to the initial value. If either "00000000" or a value before the specification change is displayed in the estimated life value of the parts counter, set 0 after upgrading of the firmware. |
| Use Case | | - When either "00000000" or a value before the specification change is displayed in the estimated life value of the parts counter - When changing the state back to the initial state after entering the estimated life value manually |
| Adj/Set/Operate Method | | 1) Enter 0, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0: Returned to the initial value |
| Default Value | | 0 |
| PSWD-SW | 1 | Password type set to enter service mode |
| Detail | | To set the type of password that is required to enter when getting into service mode. 2 types are available: one for "service technician" and the other for "system administrator + service technician". When selecting the type for "system administrator + service technician", enter the password for service technician after the password entry by the user's system administrator. |
| Use Case | | Upon request from the user who concerns security |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 2 0: No password, 1: Service technician, 2: System administrator + service technician |
| Default Value | | 0 |
| SM-PSWD | 2 | Password setting for service technician |
| Detail | | To set password for service technician that is used when getting into service mode. |
| Use Case | | When password is required to get into service mode |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | Be sure to select 1 or 2 with PSWD-SW in advance. |
| Display/Adj/Set Range | | 1 to 99999999 |
| Default Value | | 11111111 |
| Related Service Mode | | COPIER> OPTION> FNC-SW> PSWD-SW |
| RPT2SIDE | 1 | Set of report 1-sided/2-sided output |
| Detail | | To set whether to use 1-sided or 2-sided for report output of service mode. |
| Use Case | | When making 1-sided report output |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: 1-sided, 1: 2-sided |
| Default Value | | 1 |
| Related Service Mode | | COPIER> FUNCTION> MISC-P> P-PRINT |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > FNC-SW

| | | |
|----------------------------------|--|--|
| INVALPDL | 1 | Disable of PDL license |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To disable the registered PDL license. When "1: Disabled" is set, PDL is disabled even if a PDL license is registered. This is set to the machines installed at convenience stores, which do not allow PDL to be used. | |
| Use Case | When prohibiting the use of PDL | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Registered PDL license is enabled, 1: Disabled | |
| Default Value | 0 | |
| CDS-FIRM | 1 | Set to allow firmware update by admin |
| Detail | * Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to allow the user (administrator) to perform firmware update linked with CDS and collection of log files. When 1 is set, [Distribution Update] is added to remote UI, and [Firmware Update] is added to [Register/Update Software] of local UI. Log files can be collected from remote UI. | |
| Use Case | When allowing the administrator to update the firmware | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | Do not use it for purposes other than collecting log files. Be sure to return the value to 0 after use. | |
| Display/Adj/Set Range | 0 to 1 0: Disabled, 1: Enabled | |
| Default Value | It differs according to the location. | |
| Related Service Mode | COPIER> OPTION> FNC-SW> LCDSFLG | |
| Additional Functions Mode | Management Settings> License/Other> Register/Update Software | |
| Supplement/Memo | CDS: Contents Delivery System | |
| CDS-MEAP | 1 | Set to allow MEAP installation by admin |
| Detail | * Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to allow the user (administrator) to install MEAP applications from CDS and enable iR options. When 1 is set, Updater can be activated from [Settings/Registration]. | |
| Use Case | When allowing the administrator to install MEAP applications and enable iR options from CDS | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Disabled, 1: Enabled | |
| Default Value | 1 | |
| Supplement/Memo | CDS: Contents Delivery System | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > FNC-SW

| | | |
|-------------------------------|---|---|
| CDS-UGW | 1 | Set to allow firmware update from UGW |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to permit update of the firmware from the UGW server. When "1: Enabled" is set, Updater accepts the operation from the UGW server in cooperation with CDS. | |
| Use Case | When allowing update of the firmware from the UGW server | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Disabled, 1: Enabled | |
| Default Value | It differs according to the location. | |
| Supplement/Memo | CDS: Contents Delivery System | |
| LOCLFIRM | 1 | Set to allow firmware update by file |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to permit the user (administrator) to update the firmware from the remote UI using a local file. This update is executed as a measure for vulnerability in emergency situations. | |
| Use Case | When allowing the administrator to update the firmware using a file | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Disabled, 1: Enabled | |
| Default Value | 1 | |
| SDLMTWRN | 1 | [For customization] |
| FAX-INT | 2 | Set FAX RX print interruption oprtn mode |
| Detail | To set the mode performing interruption operation of FAX reception print automatically. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | - Do not set this item while charge management (charging by Coin Manager, a device alone, etc.) is used. - During an ongoing job for which delivery setting (offset, stapling, etc.) is made, interruption operation is performed between sets. | |
| Display/Adj/Set Range | 0 to 1 0: Normal, 1: Interruption operation mode | |
| Default Value | 0 | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > FNC-SW

| | | |
|----------------------------------|--|---|
| CDS-LVUP | 1 | Set to allow CDS periodical update |
| Detail | <p>*Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to allow the user (administrator) to perform periodical update linked with CDS. When 1 is set, setting of periodical update can be made in Settings/Registration menu/via remote UI.</p> <p>When 2 is set, setting of periodical update can be made on the Updater screen in service mode.</p> | |
| Use Case | When allowing the user/service technician to perform periodical update | |
| Adj/Set/Operate Method | <p>1) Enter the setting value, and then press OK key.</p> <p>2) Turn OFF/ON the main power switch.</p> | |
| Display/Adj/Set Range | <p>0 to 2</p> <p>0: Prohibited periodical update</p> <p>1: Display the periodical update setting screen in Settings/Registration menu/on remote UI</p> <p>2: Display the periodical update setting screen on the Updater in service mode</p> | |
| Default Value | It differs according to the location. | |
| Related Service Mode | Updater | |
| Additional Functions Mode | Management Settings> License/Other> Register/Update Software> Periodical Update | |
| Supplement/Memo | CDS: Contents Delivery System | |
| AMSOFFSW | 1 | Enabling of AMS mode |
| Detail | <p>*Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To enable the AMS mode.</p> <p>When 0 is set, the AMS mode is enabled. The AMS mode is automatically enabled when the following 2 conditions are satisfied.</p> <ul style="list-style-type: none"> - AMS license for an iR option is installed. - AMS-supported Login application (User Authentication, etc.) is activated. | |
| Use Case | When enabling AMS mode | |
| Adj/Set/Operate Method | <p>1) Check that AMS-supported Login application is activated.</p> <p>2) Enter 0, and then press OK key.</p> <p>3) Turn OFF/ON the main power switch.</p> <p>4) Check that [Role Management] is displayed on remote UI.</p> | |
| Display/Adj/Set Range | <p>0 to 1</p> <p>0: AMS mode enabled, 1: AMS mode disabled</p> | |
| Default Value | 1 | |
| Related Service Mode | COPIER> OPTION> LCNS-TR> ST-AMS | |
| Additional Functions Mode | (Remote UI) User Management> Authentication Management> Role Management | |
| Supplement/Memo | <p>AMS: Access Management System</p> <p>In AMS mode, [Role Management] is displayed on remote UI.</p> | |
| UA-OFFSW | 1 | ON/OFF of unified auth function |
| Detail | <p>*Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set ON/OFF of the Unified Authentication function.</p> <p>Set 0 when not preferring to use the Unified Authentication function because of security concern.</p> | |
| Use Case | Upon user's request (not to use the Unified Authentication function) | |
| Adj/Set/Operate Method | <p>1) Enter the setting value, and then press OK key.</p> <p>2) Turn OFF/ON the main power switch.</p> | |
| Display/Adj/Set Range | <p>0 to 1</p> <p>0: ON, 1: OFF</p> | |
| Default Value | 0 | |
| Supplement/Memo | Unified Authentication: A function with which it is considered that login authentication under it is performed by logging in it using SSO-H. | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > FNC-SW

| | | |
|----------------------------------|---|--|
| MIB-NVTA | 1 | RFC-compatible character string MIB write |
| Detail | As default, MIB object which NVT-ASCII can be written exists in order to link with local UI entry value. This violates RFC order, so a problem like garbled 2-byte characters may occur in the SNMP monitoring system, such as other vendor's MPS. Whether to allow writing of non-RFC-compatible character strings in MIB can be set using this item. When 1 is set, only the character strings which are strictly compatible with RFC are written. (Writing operation is executed from the SNMP manager.) It is not linked with local UI. | |
| Use Case | Upon user's request (operation with RFC-compatible system) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 3 0: Compatible in a conventional manner, 1: RFC-compatible, 2 to 3: Not used | |
| Default Value | 0 | |
| Supplement/Memo | RFC: Document of internet-related technical standards NVT-ASCII: Network Virtual Terminal-ASCII | |
| MIB-EXT | 1 | For R&D |
| SVC-RUI | 1 | Enabling of remote UI func for servicing |
| Detail | To set whether to enable the remote UI function for servicing (not provided to end users). When 0 is set, the remote UI function is disabled. When setting a value other than 0, the remote UI function is enabled and its value will be used as the password to use the function. | |
| Use Case | When preferring to use the import function of background image file of main menu/custom menu | |
| Adj/Set/Operate Method | Enter the setting value (other than 0), and then press OK key. | |
| Display/Adj/Set Range | 0 to 65535 | |
| Default Value | 0 | |
| LCDSFLG | 1 | Enabling of local CDS server |
| Detail | To set whether to use the local CDS server. When CDS-FIRM is 1, this setting is enabled. | |
| Use Case | When using the local CDS server | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: Disabled, 1: Enabled | |
| Default Value | 0 | |
| Related Service Mode | COPIER> OPTION> FNC-SW> CDS-FIRM | |
| Additional Functions Mode | Management Settings> License/Other> Register/Update Software> Software Management Setting> Setting | |
| Supplement/Memo | When local CDS is used, iW EMC/MC device firmware update plug-in is required. | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > FNC-SW

| | | |
|-------------------------------|--|---|
| BXSHIFT | 1 | Setting of binding at 0mm binding margin |
| Detail | To set whether to judge the job as a job "without binding" when storing a PDL job in Inbox while the binding margin is set to "0". By setting the binding margin to 0 mm while "0" is set, the job is processed as "without binding". "Booklet" in "Options" on the Inbox screen can be also used. When "1" is set, it is judged as "with binding" even the binding margin is 0 mm so "Booklet", which has an exclusive relationship with "binding", cannot be used. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | When storing a PDL job in Mail Box while 1 is set, "Booklet" in "Options" on the Mail Box screen cannot be used. | |
| Display/Adj/Set Range | 0 to 1 0: Without binding, 1: With binding | |
| Default Value | 0 | |
| HOME-SW | 1 | Set screen displayed with Main Menu key |
| Detail | To set whether to display the main menu screen or the screen registered as the startup screen when pressing Main Menu key. | |
| Use Case | Upon user's request (to change the startup screen) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Main Menu screen, 1: Screen registered as the startup screen | |
| Default Value | 0 | |
| NO-LGOUT | 1 | ON/OFF of Logout button display |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to display or hide [Logout] button. When 0 is set, [Logout] button is displayed on the screen, and logout with the ID key is enabled. (Normal) When 1 is set, [Logout] button is not displayed, and logout with the ID key is disabled. | |
| Use Case | Upon user's request (for customization, etc.) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Display, 1: Hide | |
| Default Value | 0 | |
| T-DLV-BK | 1 | Set of toner level to send the alarm |
| Detail | To set toner level to send the pre-toner low alarm. | |
| Use Case | When changing the timing to notify the end of life according to the usage status | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | Since toner level is calculated based on the developing supply count, some errors may occur. | |
| Display/Adj/Set Range | 0 to 40 | |
| Unit | % | |
| Default Value | It differs according to the location. | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > FNC-SW

| | | |
|-------------------------------|---|--|
| JM-ERR-R | 2 | Set of error display of 0071 jam (RCON) |
| Detail | To set whether to display 0071 jam as the error "E996-0071". In the case of a jam, a log may not be able to be obtained depending on the timing. By selecting 1 when the 0071 jam occurs, it is displayed as an error so that a log can be obtained. | |
| Use Case | When obtaining a log at the occurrence of 0071 jam | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: Display as a jam, 1: Display as an error | |
| Default Value | 0 | |
| Related Service Mode | COPIER> OPTION> FNC-SW> JM-ERR-D | |
| ASLPMAX | 1 | Set auto sleep shift time maximum value |
| Detail | Set auto sleep shift time maximum value. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: 4 hours, 1: 60 minutes | |
| Default Value | It differs according to the location. | |
| SEND-SPD | 2 | ON/OFF of SEND operation speed-up |
| Detail | To set whether to speed up the SEND operation. Usually, speed of SEND/XBOX is increased by performing image conversion during SEND and Scan. Reading speed may decrease when scanning large size color original at high resolution or when competing operation occurs with another job during scanning. Set 1 to keep the speed. When failure with MEAP application occurs, set 1. | |
| Use Case | - When reading speed is decreased during SEND and Scan - When failure with MEAP application occurs | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: ON, 1: OFF | |
| Default Value | 0 | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > FNC-SW

| | | |
|----------------------------------|--|---|
| VER-CHNG | 2 | Setting of firmware update operation |
| Detail | <p>To set how to update firmware of PCB/option which has been installed/replaced by comparing the version of it with the version stored in the Flash PCB of the Main Controller.</p> <p>If combination of firmware versions of PCB/option stored in the Main Controller and the version in PCB/option after installation/replacement is not appropriate (operation with the combination of firmware versions has not yet been checked), failure where analysis is difficult may occur.</p> <p>It is possible to check the firmware versions at the start of the machine, and automatically write the firmware stored in the Main Controller in PCB/option collectively as needed.</p> <p>When 0 is set, versions are not checked and firmware update is not performed. Therefore, it is necessary to manually update the versions using a USB memory/SST.</p> <p>When 1 is set, firmware is updated if the version in PCB/option is old. However, it is not updated if the version is new or old and new versions are mixed.</p> <p>When 2 is set, a compatible firmware (the version where operation has been checked) is written from the Main Controller regardless of whether the version in PCB/option is old or new.</p> | |
| Use Case | When installing/replacing PCB/option having firmware | |
| Adj/Set/Operate Method | <p>1) Enter the setting value, and then press OK key.</p> <p>2) Turn OFF/ON the main power switch.</p> | |
| Display/Adj/Set Range | <p>0 to 2</p> <p>0: Keep the current firmware version.</p> <p>1: Update the firmware if the version in PCB/option is older than that stored in the Main controller. If the version is new or old and new versions are mixed, firmware is not updated.</p> <p>2: Update the firmware regardless of whether the version is old or new if the version in PCB/option differs from that stored in the Main Controller.</p> | |
| Default Value | 1 | |
| Supplement/Memo | <p>When updating the firmware, the main menu is displayed on the Control Panel at startup and then a message prompting to update firmware is displayed.</p> <p>By pressing [Update], the machine reboots immediately and firmware is updated.</p> <p>By pressing [Skip], it returns to the main menu. The message is displayed again at next startup.</p> | |
| CE-SW | 1 | [Reserve] |
| PICLOGIN | 1 | ON/OFF of Picture Login display |
| Detail | To set whether to display [Picture Login] in [Settings/Registration]. | |
| Use Case | When switching the Picture Login function | |
| Adj/Set/Operate Method | <p>1) Enter the setting value, and then press OK key.</p> <p>2) Turn OFF/ON the main power switch.</p> | |
| Display/Adj/Set Range | <p>0 to 1</p> <p>0: OFF, 1: ON</p> | |
| Default Value | 1 | |
| Additional Functions Mode | Management Settings> User Management> Authentication Management> Use User Authentication> Picture Login | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > FNC-SW

| | | |
|-------------------------------|--|---|
| DCONTRY | 2 | Set of retry at DCON comctn error occur |
| Detail | To set whether to perform retry processing when communication error occurs between the Main Controller and the DC Controller. Set 1 to 3 when E733 occurs. Communication error may be avoided by retry. (It is effective especially when E733-0001/0002/0005 occurs.) If communication error occurs during finishing job while 3 is set, duplicated pages may be output due to retry. In such case, set 0 to 2. Since retry is not performed during finishing job, duplication of pages does not occur, but E733 occurs. | |
| Use Case | When E733 occurs | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | When 3 is set, duplication of pages may occur during finishing job. | |
| Display/Adj/Set Range | 0 to 3 0: OFF 1: OFF during job, ON in other states 2: OFF during finishing job, ON in other states 3: ON | |
| Default Value | 1 | |
| Supplement/Memo | Finishing job: Job that 2-sided print, binding and/or collate set in "Finishing" of the printer driver. | |
| FL-START | 2 | [For customization] |
| FIX-DLV | 1 | Set arr alm thrshld of Fixing Ass'y |
| Detail | To set the timing to notify the Fixing Assembly LF setting value arrival alarm. | |
| Use Case | When changing the timing to notify the end of life according to the usage status | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 50 to 1000 | |
| Default Value | 100 | |
| 3RDP-MSG | 2 | ON/OFF pop-up screen dspl after upgrade |
| Detail | To set whether to display the screen to prompt the user to "Third-Party Software" at the first startup after upgrading due to change in the platform version. | |
| Use Case | There will be no occasion to use this item intentionally. | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | Even if 0 is set, the screen is displayed if CDS-LVUP is set to 0. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | 0 | |
| Related Service Mode | COPIER> OPTION> FNC-SW> CDS-LVUP | |
| TRR-DLV | 1 | Set Trn Rol LF set VL arr alm notice tmg |
| Detail | To set the timing to notify the transfer roller LF setting value arrival alarm. | |
| Use Case | When changing the timing to notify the end of life according to the usage status | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 50 to 1000 | |
| Default Value | 100 | |
| C1F-DLV | 1 | Set arr alm thrshld of CST1 Feed Roller |
| Detail | To set the timing to notify the Cassette 1 Transfer Roller LF setting value arrival alarm. | |
| Use Case | When changing the timing to notify the end of life according to the usage status | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 50 to 1000 | |
| Default Value | 100 | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > FNC-SW

| | | |
|-------------------------------|----------|--|
| C2F-DLV | 1 | Set arr alm thrshld of CST2 Feed Roller |
| Detail | | To set the timing to notify the Cassette 2 Transfer Roller LF setting value arrival alarm. |
| Use Case | | When changing the timing to notify the end of life according to the usage status |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 50 to 1000 |
| Default Value | | 100 |
| C3F-DLV | 1 | Set arr alm thrshld of CST3 Feed Roller |
| Detail | | To set the timing to notify the Cassette 3 Transfer Roller LF setting value arrival alarm. |
| Use Case | | When changing the timing to notify the end of life according to the usage status |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 50 to 1000 |
| Default Value | | 100 |
| C4F-DLV | 1 | Set arr alm thrshld of CST4 Feed Roller |
| Detail | | To set the timing to notify the Cassette 4 Transfer Roller LF setting value arrival alarm. |
| Use Case | | When changing the timing to notify the end of life according to the usage status |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 50 to 1000 |
| Default Value | | 100 |
| DFP-DLV | 1 | Set arr alm thrshld of ADF Pickup Roller |
| Detail | | To set the timing to notify the ADF Pickup roller LF setting value arrival alarm. |
| Use Case | | When changing the timing to notify the end of life according to the usage status |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 50 to 1000 |
| Default Value | | 100 |

■ DSPLY-SW

COPIER (Service mode for printer) > OPTION (Specification setting mode) > DSPLY-SW

| | | |
|-------------------------------|----------|---|
| UI-COPY | 2 | ON/OFF of copy screen display |
| Detail | | To set whether to display or hide the copy function. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Hide, 1: Display |
| Default Value | | 1 |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > DSPLY-SW

| | | |
|----------------------------------|---|--|
| UI-BOX | 2 | ON/OFF of Inbox screen display |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to display the Inbox function. The setting values "1" and "2" of this item are linked with the values "ON" and "OFF" of [Mail Box] in [Settings/Registration] respectively. The setting is reflected after turning OFF/ON the power. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 1 to 2 1: Inbox function is active 2: Inbox function is active (with limitation; Storing is available with PDL to Inbox despite no display on the Control Panel/remote UI) | |
| Default Value | 1 | |
| Additional Functions Mode | Preferences> Display Settings> Store Location Display Settings> Mail Box | |
| UI-SEND | 2 | ON/OFF of Send screen display |
| Detail | To set whether to display or hide the SEND function. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | 1 | |
| UI-FAX | 2 | ON/OFF of fax screen display |
| Detail | To set whether to display or hide the FAX function. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | 1 | |
| NWERR-SW | 2 | OFF/ON of network-related error display |
| Detail | To set OFF/ON of network-related error message display. When setting "0: OFF" while the machine is not connected to network, the error message "Check the network connection." is not displayed. | |
| Use Case | When using the machine as a copy machine | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 1 | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > DSPLY-SW

| | | |
|----------------------------------|---|---|
| UI-PRINT | 2 | Set of secured print-related UI display |
| Detail | To set whether to display UI related to secured print. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2 0: Hide all UIs related to secured print 1: Display all UIs related to secured print 2: Hide Secured Print button in the main menu and the simple authentication settings in [Settings/Registration] | |
| Default Value | 0 | |
| IMGC-ADJ | 1 | ON/OFF of img adj item dspl in [Set/Reg] |
| Detail | To set whether to display the item relating to image adjustment in [Settings/Registration]. When 1 is set, detailed image adjustment procedure will be displayed only for the paper duplicated in Preferences> Paper Settings> Paper Type Management Settings. | |
| Use Case | As needed | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | 0 | |
| Additional Functions Mode | Preferences> Paper Settings> Set Paper Type Management | |
| UI-RSCAN | 2 | ON/OFF of remote scan screen display |
| Detail | To set whether to display the remote scan screen on the Control Panel. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 1 | |
| UI-WEB | 2 | ON/OFF of Web browser screen display |
| Detail | To set whether to display or hide the Web browser screen. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | 1 | |
| TNR-WARN | 1 | ON/OFF of toner warning display |
| Detail | To set whether to display the toner level warning. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: ON, 1: OFF | |
| Default Value | It differs according to the location. | |
| Related Service Mode | COPIER> OPTION> DSPLY-SW> T-LW-BK | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > DSPLY-SW

| | | |
|----------------------------------|---|--|
| RMT-CNSL | 1 | Allow console application connection |
| Detail | To set whether to allow connection from a console application (RemoteConsole). When 1 is set, logs of MEAP application can be collected via the console application activated on a PC. | |
| Use Case | When collecting logs of MEAP application | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 0 | |
| UI-SBOX | 2 | ON/OFF of Advanced Box screen display |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set ON/OFF of the Advanced Box screen on the Control Panel. The setting values 0 (OFF) and 1 (ON) are linked with OFF and ON of [Advanced Box/Network] in [Settings/Registration] respectively. The setting is reflected after turning OFF/ON the power. | |
| Use Case | When not displaying the Advanced Box screen on the Control Panel | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | It differs according to the location. | |
| Additional Functions Mode | Preferences> Display Settings> Store Location Display Settings> Advanced Box/Network | |
| UI-MEM | 2 | ON/OFF of memory media screen display |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set ON/OFF of the memory media screen display on the Control Panel. The setting values 0 (OFF) and 1 (ON) are linked with OFF and ON of [Memory Media] in [Settings/Registration] respectively. The setting is reflected after turning OFF/ON the power. | |
| Use Case | When not displaying the memory media screen on the Control Panel | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 1 | |
| Additional Functions Mode | Preferences> Display Settings> Store Location Display Settings> Memory Media | |
| UI-NAVI | 2 | ON/OFF of Tutorial display |
| Detail | To set whether to display or hide "Introduction to Useful Features" in the main menu. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | 1 | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > DSPLY-SW

| | | |
|----------------------------------|---|---|
| UI-CUSTM | 2 | ON/OFF of custom menu screen display |
| Detail | To set ON/OFF of the custom menu screen display on the Control Panel. | |
| Use Case | When not displaying the custom menu screen on the Control Panel | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 1 | |
| SDTM-DSP | 1 | ON/OFF of auto shutdown shift time dspl |
| Detail | To set whether to display [Auto Shutdown Time] in [Settings/Registration]. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When 0 is set, automatic shutdown is not executed. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | It differs according to the location. | |
| Additional Functions Mode | Preferences> Timer/Energy Settings> Auto Shutdown Time | |
| DF-DSP | 1 | ON/OFF ADF Maintenance Kit cntr ini scrn |
| Detail | To set whether to display "ADF Maintenance Kit" on the counter initialization screen in [Settings/Registration]. | |
| Use Case | When the user does not replace the parts | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | 0 | |
| Additional Functions Mode | Adjustment/Maintenance> Maintenance> Initialize After Replacing Parts> ADF Maintenance Kit | |
| PRCLNSW | 2 | Fixing Pressure Roll clean mssg dspl |
| Detail | To set whether to display the message prompting to clean the Fixing Pressure Roller. The timing to display the message can be adjusted in PR-CLN. | |
| Use Case | When a soiled image occurs because toner adheres to the Fixing Pressure Roller | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | 0 | |
| Related Service Mode | COPIER> OPTION> CLEANING> PR-CLN | |
| UI-PPA | 2 | ON/OFF of PPA screen display |
| Detail | To set whether to display PPA-related information on the Control Panel or remote UI. The setting is linked with LGCY-SCP. When LGCY-SCP is set to 0, the setting of this item becomes 1. When LGCY-SCP is set to 1, the setting of this item becomes 0. | |
| Use Case | When not displaying PPA-related information on the screen | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 0 (non PPA-installed machine)/1 (PPA-installed machine) | |
| Related Service Mode | COPIER> OPTION> USER> LGCY-SCP | |
| Supplement/Memo | PPA (Personal Print Application): A function to hold print job. It contains the secured print function. | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > DSPLY-SW

| | | |
|----------------------------------|---|---|
| CE-DSP | 2 | [Reserve] |
| LOCAL-SZ | 1 | ON/OFF area-spec stdrd size ppr set scrn |
| Detail | To set whether to display the area-specific standard size paper on the paper settings screen in [Settings/Registration]. When 1 is set, paper type (FOOLSCAP, OFFICIO, etc.) can be set on the paper settings screen for each paper source. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | It differs according to the location. | |
| Additional Functions Mode | Preferences> Paper Settings> Paper Settings | |
| T-LW-BK | 1 | Set toner level warning mssg dspl timing |
| Detail | To set the threshold value for the toner level in the Toner Container. When the toner level becomes below the threshold value while TNR-WARN is 0, a toner level warning message "Toner is low. Replacement not yet needed." is displayed on the Control Panel. As the value is incremented by 1, the threshold value is increased by 1%. As the value is larger, the timing to display the message becomes earlier. | |
| Use Case | When changing the timing to display the toner level warning message for the user to whom toner is not delivered automatically | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 40 | |
| Unit | % | |
| Default Value | It differs according to the location. | |
| Related Service Mode | COPIER> OPTION> DSPLY-SW> TNR-WARN | |
| Supplement/Memo | It is not linked with COPIER> OPTION> FNC-SW> T-DLV-BK. | |
| SND-NAME | 1 | Setting of [Scan and Send] button name |
| Detail | To set the name of [Scan and Send] button displayed in the main menu. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2 0: [Scan and Send], 1: [Scan], 2: [Scan] | |
| Default Value | 0 | |
| PCMP-DSP | 1 | Set copy cmpl scrn dspl:chg w/devc alone |
| Detail | To set whether to display the screen indicating completion of copying at the time of charging with a device alone. When 0 is set, a message "Copying is complete. Do you want to start the job again with the same settings?" is not displayed in a pop-up screen. When COIN is 4, this setting is enabled. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 1 | |
| Related Service Mode | COPIER> OPTION> ACC> COIN | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > DSPLY-SW

| | | |
|----------------------------------|---|--|
| FIX-WRN1 | 1 | ON/OFF Fixing Ass'y replacement message |
| Detail | To set whether to display the message prompting to replace the Fixing Assembly on the Control Panel when the LF for life judgment reaches the Setting value (FIX-DLV) | |
| | . | |
| | When FIX-WRN1 is 1 and COPIER> OPTION> FNC-SW> FIX-DLV value is reached, the Fixing Assembly life detection is performed. | |
| | When the Fixing Assembly reaches its life, the Fixing Assembly replacement message "Fixing assembly needs to be replaced." is displayed. | |
| | When the message is displayed, perform the following procedure. | |
| | 1) | |
| | Replace the Fixing Assembly counter. | |
| | 2) | |
| | Clear the Fixing Assembly counter. | |
| Use Case | When displaying the Fixing Assembly replacement message | |
| Adj/Set/Operate Method | 1) | |
| | Enter the setting value, and then press OK key. | |
| | 2) | |
| | Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 | |
| | 0: OFF, 1: ON | |
| Default Value | 0 | |
| ERR-DISP | 2 | [For customization] |
| SVC-ACA | 1 | Display of ACA installation button |
| Detail | To set whether to display the [Install Auto Configuration Agent] button on the CDS Updater screen (user mode/service mode). | |
| Use Case | When switching to install/not to install the ACA via network | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 2 | |
| | 0: Hide (Hide user mode/service mode) | |
| | 1: Display only service mode (Hide user mode) | |
| | 2: Display all (Display user mode/service mode) | |
| Default Value | It differs according to the location. | |
| Related Service Mode | Service Mode > Updater | |
| Additional Functions Mode | Management Settings> License/Other> Register/Update Software | |
| Supplement/Memo | ACA : Auto Configuration Agent | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > DSPLY-SW

| TRR-WRN1 | 1 | ON/OFF Trn Roller replacement message |
|-------------------------------|--|---|
| Detail | To set whether to display the message prompting to replace the Transfer Roller on the Control Panel when the LF for life judgment reaches the Setting value (TRR-DLV) | |
| | . | |
| | When TRR-WRN1 is 1 and COPIER> OPTION> FNC-SW> TRR-DLV value is reached, the Transfer Roller life detection is performed. When the Transfer Roller reaches its life, the Transfer Roller replacement message "Transfer Roller needs to be replaced." is displayed. | |
| | When the message is displayed, perform the following procedure. | |
| | 1) | Replace the Transfer Roller. |
| | 2) | Clear the transfer roller counter. |
| Use Case | When displaying the Transfer Roller replacement message | |
| Adj/Set/Operate Method | 1) | Enter the setting value, and then press OK key. |
| | 2) | Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | 0 to 1 | 0: OFF, 1: ON |
| Default Value | 0 | |
| C1F-WRN1 | 1 | CST1 Fd Rol Replacement 1 dspl switch |
| Detail | To set whether to display the message prompting to replace the Cassette Roller on the Control Panel when the LF for life judgment reaches the Setting value (xxF-DLV) | |
| | . | |
| | When C1F-WRN1 is 1 and COPIER> OPTION> FNC-SW> C1F-DLV value is reached, the Cassette Feed Roller life detection is performed. When the Cassette Transfer Roller for the target paper source reaches its life, the Cassette Roller replacement message for the target paper source "Cassette Roller needs to be replaced." is displayed. | |
| | When the message is displayed, perform the following procedure. | |
| | 1) | Replace the Cassette Roller for the target paper source. |
| | 2) | Clear the Cassette Transfer Roller Counter for the target paper source. |
| Use Case | When displaying the Cassette Roller replacement message | |
| Adj/Set/Operate Method | 1) | Enter the setting value, and then press OK key. |
| | 2) | Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | 0 to 1 | 0: OFF, 1: ON |
| Default Value | 0 | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > DSPLY-SW

| SVC-SRA | 1 | Display/hide of DBS installation button |
|----------------------------------|----------|---|
| Detail | | To set whether to display the [Install Data Backup Service] button on the CDS Updater screen (user mode/service mode). |
| Use Case | | When switching to install/not to install the Data Backup Service via network |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | Depending on the setting value, display when entering from Settings/Registration and that from service mode differ. |
| Display/Adj/Set Range | | 0 to 2 0: Hide (Hide user mode/service mode) 1: Display only service mode (Hide user mode) 2: Display all (Display user mode/service mode) |
| Default Value | | It differs according to the location. |
| Related Service Mode | | Service Mode> Updater> Install Data Backup Service |
| Additional Functions Mode | | Management Settings> License/Other> Register/Update Software> Install Data Backup Service |
| UFOS-DSP | 1 | Display/hide of uniFLOW Setup |
| Detail | | Service mode to switch to display or hide [uniFLOW Setup]. |
| Use Case | | When to switch to display or hide [uniFLOW Setup] |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Hide, 1: Display |
| Default Value | | It differs according to the location. |
| Additional Functions Mode | | Main Menu > uniFLOW Setup |
| Supplement/Memo | | uniFLOW : The name of the product destined for China is "mdsFLOW". |

■ NETWORK

COPIER (Service mode for printer) > OPTION (Specification setting mode) > NETWORK

| RAW-DATA | 2 | Setting of received data print mode |
|-------------------------------|----------|--|
| Detail | | To set print mode for the received image data. This item is used to identify the cause whether it's due to image data or image processing in the case of trouble with received image. |
| Use Case | | When received image trouble occurs |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | Be sure to change the value back to 0 after recovering from the problem. |
| Display/Adj/Set Range | | 0 to 1 0: Normal print operation, 1: Print with original data without image processing |
| Default Value | | 0 |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > NETWORK

| | | |
|-------------------------------|---|---|
| IFAX-LIM | 2 | No. of max print lines at IFAX reception |
| Detail | To set the maximum number of lines for e-mail text to be printed when receiving IFAX. Setting of this item can prevent endless printing of the attached file data in the case of receiving an error e-mail or failure in interpretation of the context. Selecting 0 prints the header/footer in 1 sheet when receiving e-mail text without attached file. | |
| Use Case | When preventing endless print in the case of failure in reception | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 999 0: E-mail text not printed, 999: Unlimited | |
| Default Value | 500 | |
| SMTPTXPN | 2 | Setting of SMTP TX port number |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set SMTP transmission port number. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 65535 | |
| Default Value | 25 | |
| SMTPRXPN | 2 | Setting of SMTP reception port number |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set SMTP reception port number. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 65535 | |
| Default Value | 25 | |
| POP3PN | 2 | Setting of POP3 reception port number |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set POP3 reception port number. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 65535 | |
| Default Value | 110 | |
| FTPTXPN | 1 | Specification of SEND port (FTP) number |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To specify address port (FTP) number for SEND. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 65535 | |
| Default Value | 21 | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > NETWORK

| | | |
|-------------------------------|--|--|
| NS-CMD5 | 2 | Limit CRAM-MD5 auth method at SMTP auth |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To restrict use of CRAM-MD5 authentication method at the time of SMTP authentication. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: SMTP server-dependent, 1: Not used | |
| Default Value | 0 | |
| Supplement/Memo | SMTP authentication: Protocol in which user authentication function is added to SMTP, which is the protocol to be used for e-mail transmission. At the time of e-mail transmission, this protocol executes authentication of the user account and the password between the SMTP server and the user to approve e-mail transmission only when it's authenticated. | |
| NS-GSAPI | 2 | Limit GSSAPI auth method at SMTP auth |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To restrict use of GSSAPI authentication method at the time of SMTP authentication. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: SMTP server-dependent, 1: Not used | |
| Default Value | 0 | |
| Supplement/Memo | SMTP authentication: Protocol in which user authentication function is added to SMTP, which is the protocol to be used for e-mail transmission. At the time of e-mail transmission, this protocol executes authentication of the user account and the password between the SMTP server and the user to approve e-mail transmission only when it's authenticated. | |
| NS-NTLM | 2 | Limit NTLM auth method at SMTP auth |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To restrict use of NTLM authentication method at the time of SMTP authentication. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: SMTP server-dependent, 1: Not used | |
| Default Value | 0 | |
| Supplement/Memo | SMTP authentication: Protocol in which user authentication function is added to SMTP, which is the protocol to be used for e-mail transmission. At the time of e-mail transmission, this protocol executes authentication of the user account and the password between the SMTP server and the user to approve e-mail transmission only when it's authenticated. | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > NETWORK

| | | |
|-------------------------------|--|---|
| NS-PLNWS | 2 | Limit plaintext auth at SMTP auth encry |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To restrict use of PLAIN/LOGIN authentication, which is plaintext, at the time of SMTP authentication under the environment where the communication packet is encrypted. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: SMTP server-dependent, 1: Not used | |
| Default Value | 0 | |
| Supplement/Memo | SMTP authentication: Protocol in which user authentication function is added to SMTP, which is the protocol to be used for e-mail transmission. At the time of e-mail transmission, this protocol executes authentication of the user account and the password between the SMTP server and the user to approve e-mail transmission only when it's authenticated. | |
| NS-PLN | 2 | Limit plaintext auth at SMTPauth noency |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To restrict use of PLAIN/LOGIN authentication, which is plaintext, at the time of SMTP authentication under the environment where the communication packet is not encrypted. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: SMTP server-dependent, 1: Not used | |
| Default Value | 0 | |
| Supplement/Memo | SMTP authentication: Protocol in which user authentication function is added to SMTP, which is the protocol to be used for e-mail transmission. At the time of e-mail transmission, this protocol executes authentication of the user account and the password between the SMTP server and the user to approve e-mail transmission only when it's authenticated. | |
| NS-LGN | 2 | Limit LOGIN authentication at SMTP auth |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To restrict use of LOGIN authentication at the time of SMTP authentication. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: SMTP server-dependent, 1: Not used | |
| Default Value | 0 | |
| Supplement/Memo | SMTP authentication: Protocol in which user authentication function is added to SMTP, which is the protocol to be used for e-mail transmission. At the time of e-mail transmission, this protocol executes authentication of the user account and the password between the SMTP server and the user to approve e-mail transmission only when it's authenticated. | |
| MEAP-PN | 2 | HTTP port No.setting of MEAP application |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set HTTP port number of MEAP application. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | Do not specify port 8080 when the Print Server is connected. Otherwise, you cannot browse the device RUI in which MEAP authentication application is running (Port 8080 is reserved for redirection of EFI Controller to the iR side.) | |
| Display/Adj/Set Range | 1 to 65535 | |
| Default Value | 8000 | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > NETWORK

| | | |
|-------------------------------|---|---|
| RMT-LGIN | 2 | For R&D |
| MEAP-SSL | 2 | HTTPS port setting of MEAP |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the port of HTTPS server in the case of using SSL with HTTP of MEAP. | |
| Use Case | When specifying the setting of HTTPS port for MEAP | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 65535 | |
| Default Value | 8443 | |
| LPD-PORT | 2 | Setting of LPD port number |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the LPD port number. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 1 to 65535 | |
| Default Value | 515 | |
| Supplement/Memo | LPD port: Network port for TCP/IP communication when making prints through network. | |
| WUEN-LIV | 2 | Recovery time setting after sleep notice |
| Detail | To set the time from the sleep start from network without job assignment until the mode is shifted to the sleep mode. | |
| Use Case | When setting the startup time after sleep notification | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 10 to 600 | |
| Unit | sec | |
| Default Value | 15 | |
| IFX-CHIG | 1 | Set operation by IFAX recv mail content |
| Detail | To set the number of characters for the IFAX received mail content, so that the mail is not printed/forwarded when the characters in the text is less than the number of specified characters. This machine can output blank paper because some senders send e-mail text consists of linefeed codes only. In such case, specify 2 (number of characters) so that there will be no output of blank paper. In the case of specifying any number other than 0, header/footer is printed/forwarded in 1 sheet only if the e-mail (body) text is less than the specified value while no TIFF file is attached. As the value is incremented by 1, the number of target characters in e-mail body text is increased by 1 character. | |
| Use Case | When reducing print of blank paper due to e-mail received by IFAX | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | Be sure to get approval from the user by telling that there will be no print of e-mail (body) text if the number of characters is less than the specified value. | |
| Display/Adj/Set Range | 0 to 999 0: E-mail (body) text is not ignored. | |
| Unit | char | |
| Default Value | 0 | |
| Supplement/Memo | 1 Japanese Kanji character is calculated as 2 bytes, and the control codes (such as linefeed code, etc) are included in the number of characters. | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > NETWORK

| | | |
|-------------------------------|--|---|
| DNSTRANS | 1 | Setting of DNS query priority protocol |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set priority of the protocol (IPv4/IPv6) for DNS query. In the case of using both IPv6 and IPv4 while the DNS server supports IPv4, it takes time because of timeout when executing DNS query with priority on IPv6. Giving priority on query by IPv4 can shorten the time. | |
| Use Case | When it takes time to execute DNS query with priority on IPv6 because the DNS server supports IPv4 | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: IPv4, 1: IPv6 | |
| Default Value | 1 | |
| PROXYRES | 2 | Setting of proxy response to Windows |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to provide proxy response or return the device status when an inquiry is received via Windows while the device is in sleep mode. | |
| Use Case | When executing status response for query from Windows correctly | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: No proxy response, 1: Proxy response | |
| Default Value | 1 | |
| WOLTRANS | 1 | ON/OFF sleep recover by packet reception |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to recover from deep sleep when receiving unicast packets to the machine (excluding proxy response). | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 1 to 2 1: ON, 2: OFF | |
| Default Value | 1 | |
| 802XTOUT | 1 | Set of IEEE802.1X authentication timeout |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set timeout value for IEEE802.1X authentication. If the device executes 802.1X authentication, change the wait time for response from the authentication server. | |
| Use Case | When response from the authentication server is slow/fast | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 10 to 120 | |
| Unit | sec | |
| Default Value | 30 | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > NETWORK

| | | |
|-------------------------------|----------|---|
| SPDALDEL | 2 | Initialization of SPD value |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To initialize all the SPD values that are under management. SPD values can be initialized without clearing SRAM. |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: OFF, 1: ON |
| Default Value | | 0 |
| Supplement/Memo | | SPD: Database that manages SA (Security Association). SPD value is managed when IPSec Board is used. Normally, SRAM needs to be cleared in the case of mismatch in SPD value. |
| NCONF-SW | 1 | ON/OFF of Network Configurator function |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set ON/OFF of Network Configurator function. If the user does not use the function, select OFF to prevent remote attack through network. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: OFF, 1: ON |
| Default Value | | 1 |
| Supplement/Memo | | Network Configurator function is a function to be used for communication with NetSpot Device Installer, etc., and the network setting can be changed from the remote. |
| AFS-JOB | 1 | Set of FAX server job reception port |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the reception port of the fax server to which a fax client sends jobs. |
| Use Case | | When changing the job reception port of the fax server |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 65535 |
| Default Value | | 20317 |
| Related Service Mode | | COPIER> OPTION> NETWORK> AFC-EVNT |
| AFC-EVNT | 1 | Set of FAX client event reception port |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the event notification reception port of a fax client. |
| Use Case | | When changing the event notification reception port of a fax client |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 65535 |
| Default Value | | 29400 |
| Related Service Mode | | COPIER> OPTION> NETWORK> AFS-JOB |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > NETWORK

| | | |
|-------------------------------|--|--|
| ILOGMODE | 1 | Setting of filter log target packet |
| Detail | <p>*Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the target packet to be recorded in the filter log. Usually, only the unicast packets to the machine are recorded in the filter log by PFW (personal firewall). When 1 is set, address filter is enabled for all protocols so all packets are recorded in the filter log. However, logs of multicast/broadcast packets sent from a harmless device or an address that are subject to rejection and have no direct relation to the machine are also recorded, and consequently the number of logs is increased.</p> | |
| Use Case | Upon user's request (to collect all filter logs) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | When 1 is set, the number of logs is increased because logs of packets which have no direct relation to the machine are recorded. | |
| Display/Adj/Set Range | 0 to 1 0: Unicast packets to the machine only, 1: All packets | |
| Default Value | 0 | |
| ILOGKEEP | 1 | Set of IP address block log hold time |
| Detail | <p>*Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the retention time from the log time of IP block. When access is made again from a same IP address which was blocked before, if it is within the retention time of the previous log, its log is not recorded. If access is frequently made from a same IP address, the log record of the UI might be filled with its logs. If the user considers that a single log for a same IP address is enough, set the longer retention time.</p> | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 48 0: 1 minute (special mode) 1 to 48: 1 hour to 48 hours | |
| Default Value | 1 | |
| IPTBROAD | 1 | Set to allow broad/multicast TX |
| Detail | <p>*Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to permit transmission of broadcast packets and multicast packets. Transmission of broadcast packets and multicast packets is permitted without specifying an exception address. It is permitted within the device even if it is rejected in the default setting of the IPv4/v6 transmission filter. Set "1: Disabled" when the user does not want to send them.</p> | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 5 0: Enabled, 1: Disabled, 2 to 5: Not used | |
| Default Value | 0 | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > NETWORK

| | | |
|-------------------------------|---|---|
| PFWFTPRT | 1 | Set of RST reply at IP filter FTP SEND |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. When FTP SEND is executed using an IP filter by which packets from a specific remote PC are rejected, SYN is returned to the port 113 if the PC supports authentication of the FTP port 113. However, since the IP filter blocks the packets, the block logs are increased and the performance is lowered. When 1 is set, RST is returned to the port 113 without blocking packets. | |
| Use Case | When executing FTP SEND against the OS which supports authentication of the FTP port 113 while the IP filter is enabled | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 0 | |
| DDNSINTV | 1 | Set of DDNS periodical update interval |
| Detail | DNS registration is executed only once at start-up with the current iR, so the registered contents are deleted in an environment where the DNS server settings are deleted at intervals. To set the interval of DDNS periodical update for not deleting the registered contents. | |
| Use Case | When the DNS server settings are deleted at intervals | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 48 0: No periodical update, 1: 1-hour interval, 2: 2-hour interval, ..., 47: 47-hour interval, 48: 48-hour interval | |
| Unit | hour | |
| Default Value | 24 | |
| SIPAUDIO | 2 | Set of SIP session establishment order |
| Detail | To set whether to establish audio session or T.38 session first with SIP. Usually, audio session followed by T.38 session is established when using IPFAX in an intranet environment. However, this order is not specified by the standard. Set 1 when connecting the SIP server or terminal where the session starts with T.38 session. | |
| Use Case | When connecting the SIP server or terminal where the session starts with T.38 session | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | When 1 is set, IPFAX fails with the destination where the session starts with audio session. | |
| Display/Adj/Set Range | 0 to 1 0: audio, 1: T.38 | |
| Default Value | 0 | |
| Supplement/Memo | SIP: Session Initiation Protocol | |
| SIPINOUT | 2 | Set of internal/external number to URI |
| Detail | To set whether to store the external number or the internal number in From URI when using NGN. | |
| Use Case | When a call cannot be made with external number while using NGN | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: External number, 1: Internal number | |
| Default Value | 0 | |
| Supplement/Memo | NGN: Next Generation Network URI: Uniform Resource Identifier | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > NETWORK

| | | |
|----------------------------------|--|---|
| SIPREGPR | 2 | Setting of registrar server use protocol |
| Detail | To set the protocol used for communication with registrar server. Although the protocol that is the same as the one for proxy server is usually used, another protocol can be used in accordance with user and environment. | |
| Use Case | Upon user's request (to use a protocol different from the one for proxy server) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 3 0: Protocol set in Settings/Registration menu, 1: UDP, 2: TCP, 3: SSL | |
| Default Value | 0 | |
| Additional Functions Mode | Preferences> Network> TCP/IP Settings> SIP Settings> Intranet Settings | |
| VLAN-SW | 2 | ON/OFF VLAN participation packets send |
| Detail | To set whether to send packets for participating in dynamic VLAN at link-up. | |
| Use Case | When participating in dynamic VLAN | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 0 | |
| Supplement/Memo | - VLAN (Virtual LAN): A method for realizing grouping of terminals depending on the hub, switch connection port, MAC address, protocol, etc. - At link-up: At startup, when LAN cable is connected, when recovering from deep sleep, when pressing the button to reflect the setting (dynamic update) - If IP address of the machine has not been set, an IP address is assigned after participating in VLAN. | |
| FTPMODE | 1 | Set of FTP print default operation mode |
| Detail | To set the default operation mode of FTP print. Switch the default operation mode between ASCII mode and BIN mode in accordance with user's environment. | |
| Use Case | At installation | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: ASCII mode, 1: BIN mode | |
| Default Value | 0 | |
| SSLMODE | 2 | Setting of HTTP/HTTPS port open/close |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to open or close HTTP/HTTPS port. When 1 is set while [Use HTTP] is ON and [Use TLS] is OFF in Settings/Registration menu, HTTP port is opened whereas HTTPS port is closed. When 2 is set while both [Use HTTP] and [Use TLS] are ON in Settings/Registration menu, HTTP port is closed whereas HTTPS port is opened. | |
| Use Case | When limiting the port to open because of security concern | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2 0: Normal, 1: Open HTTP port (80/8000) only, 2: Open HTTPS port (443/8443) only | |
| Default Value | 0 | |
| Additional Functions Mode | Preferences> Network> TCP/IP Settings> Use HTTP Management Settings> License/Other> MEAP Settings> Use TLS | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > NETWORK

| | | |
|----------------------------------|---|--|
| SSLSTRNG | 2 | Allow weak encryption algorithm for SSL |
| Detail | To set whether to allow using weak encryption algorithm for SSL. When 1 is set, weak encryption algorithm cannot be used. | |
| Use Case | When prohibiting weak encryption algorithm because of security concern | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Normal mode, 1: Secure mode (Not used TLS_RSA_WITH_RC4_128_SHA, TLS_RSA_WITH_RC4_128_MD5) | |
| Default Value | 1 | |
| NW-WAIT | 2 | Set connect wait at deep sleep recovery |
| Detail | To set whether to send wakeup notice after the time set in Settings/Registration menu has elapsed when recovering from deep sleep. When 0 is set, wakeup notice is sent after "Waiting Time for Connection at Startup" has elapsed. When 1 is set, wakeup notice is sent when the machine becomes ready for communication. | |
| Use Case | When a failure of the device management tool occurs | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Wait, 1: Not wait | |
| Default Value | 0 | |
| Additional Functions Mode | Preferences> Network> Waiting Time for Connection at Startup | |
| WLAN-USE | 2 | Setting of wireless LAN invalidation |
| Detail | To set whether to disable the wireless LAN. Bringing in and installation of the wireless LAN equipment may be prohibited depending on user. In such case, set 0 to prevent the wireless LAN to be used. When 0 is set, [Wireless Connection Settings] is not displayed in [Settings/Registration]. | |
| Use Case | When bringing in and installation of the wireless LAN equipment is prohibited | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Disabled, 1: Enabled | |
| Default Value | 1 | |
| Additional Functions Mode | Preferences> Network> Wireless Connection Settings | |
| WLANPORT | 2 | Set of port filter at wireless LAN side |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to open all ports at the wireless LAN side. When 0 is set, only the specific port is opened (filter is enabled). Set 1 when using an application which uses a port other than the specific port. All ports are opened (filter is disabled). | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Open the specific port, 1: Open all ports | |
| Default Value | 0 | |
| RAW-PORT | 2 | [For customization] |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > NETWORK

| | | |
|-------------------------------|----------|--|
| LINKWAKE | 2 | Set of deep sleep recovery at link-up |
| Detail | | To set whether to recover from deep sleep when link-up (disconnection and then connection of LAN cable) is detected. Set 0 if the closest hub or switch chatters at link-up. It can prevent recovery from deep sleep triggered by chattering. |
| Use Case | | When the machine recovers from deep sleep due to chattering of the closest hub or switch |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Not recovered, 1: Recovered |
| Default Value | | 1 |
| WIFIRFCH | 2 | For R&D |
| BLEPOWER | 2 | Set of Bluetooth radio field strength |
| Detail | | To set the radio field strength for transmission over BLE (Bluetooth Low Energy). As the value is changed by 1, the radio field strength is changed by 1 dBm. |
| Use Case | | When radio field strength of BLE is not appropriate |
| Adj/Set/Operate Method | | 1) Enter the setting value (switch negative/positive by +/- key) and press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | Do not change the setting in Singapore. It is prohibited by law. |
| Display/Adj/Set Range | | -10 to -1 (-10 to -1 dBm) |
| Default Value | | -5 |
| WSMC-USE | 2 | [Not used] |
| WSMC-RST | 2 | [Not used] |
| INTENT | 2 | For R&D |

■ ENV-SET

COPIER (Service mode for printer) > OPTION (Specification setting mode) > ENV-SET

| | | |
|----------------------------------|----------|--|
| ENVP-INT | 1 | Temp, humid/Fix Roll temp log get cycle |
| Detail | | To set the cycle to obtain log of the temperature and humidity inside the machine or the surface temperature of the Fixing Roller. As the value is incremented by 1, the cycle is increased by 1 minute. Obtained log can be displayed by selecting the following: COPIER> DISPLAY> ENVRNT |
| Use Case | | At problem analysis |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | Be sure to set "High" for [Sleep Mode Energy Use] before collecting logs, and change the value back to its original setting after log collection. |
| Display/Adj/Set Range | | 0 to 480 |
| Unit | | min |
| Default Value | | 60 |
| Related Service Mode | | COPIER> DISPLAY> ENVRNT |
| Additional Functions Mode | | Preferences> Timer/Energy Settings> Sleep Mode Energy Use |
| Amount of Change per Unit | | 1 |

■ CLEANING

COPIER (Service mode for printer) > OPTION (Specification setting mode) > CLEANING

| PR-CLN | 2 | Set Fix Pressure Roll clean dspl condtn |
|-------------------------------|---|--|
| Detail | | To set the conditions to display the message prompting to clean the Fixing Pressure Roller. When the number of continuous 1-sided prints exceeds the setting value while PRCLNSW is set to 1, the message is displayed. By executing a 2-sided job or cleaning, the Counter for this mode is reset. |
| Use Case | | When a soiled image occurs because toner adheres to the Fixing Pressure Roller |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Caution | | If the value is too large, image soiling may occur. |
| Display/Adj/Set Range | | 1 to 50 1: 1000 sheets 2: 2000 sheets 3: 3000 sheets ... 50: 50000 sheets |
| Default Value | | 2 |
| Related Service Mode | | COPIER> OPTION> DSPLY-SW> PRCLNSW |

■ FEED-SW

COPIER (Service mode for printer) > OPTION (Specification setting mode) > FEED-SW

| EVLP-FS | 1 | Set of fix speed when feeding envlp |
|-------------------------------|---|---|
| Detail | | To set the stop and the fixing speed of arch control when feeding envelope. The fixing speed can be set by 0.5% increments. Decrease the value when fine line displacement occurs on trailing edge of envelope, and increase the value when wrinkles occur. |
| Use Case | | When fine line displacement or wrinkles occur on trailing edge while feeding envelope |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Caution | | Be sure to set the value a little at a time. Otherwise, fixing offset/fixing failure occurs when setting an extreme value. |
| Display/Adj/Set Range | | -4 to 3 -4: No arch control/fixing speed-2.0% -3: No arch control/fixing speed-1.5% -2: No arch control/fixing speed-1.0% -1: No arch control/fixing speed-0.5% 0: OFF (Default) 1: No arch control/fixing speed+0.0% 2: No arch control/fixing speed+0.5% 3: No arch control/fixing speed+1.0% |
| Default Value | | 0 |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > FEED-SW

| | | |
|----------------------------------|---|---|
| TFL-RTC | 1 | Set delvry dest at rcvry after tray full |
| Detail | To select the delivery destination for a job with multiple pages after recovering the Delivery Tray that reaches the full level. When 0 is set, a job is output from the delivery destination again from which the last job was delivered. When 1 is set, a job is output from the delivery destination which priority is set as high at "Output Tray Settings" in [Settings/Registration]. | |
| Use Case | When changing the delivery tray | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Output from the tray from which the last job was output, 1: Output from the delivery destination which priority is high among the delivery trays | |
| Default Value | 0 | |
| Additional Functions Mode | Function Settings> Common> Paper Output Settings> Output Tray Settings | |
| SP-SW | 1 | Disable static elimination control |
| Detail | To set the value to 1 to change the static eliminator bias value to 0V. | |
| Use Case | When white spots are generated on thin/moist paper in high humidity environment due to excessive static elimination bias | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: Static elimination bias ON, 1: static elimination bias OFF | |
| Default Value | 0 | |

■ IMG-RDR

COPIER (Service mode for printer) > OPTION (Specification setting mode) > IMG-RDR

| | | |
|-------------------------------|--|---|
| DFDST-L1 | 1 | Adj dust detect level: ppr intvl, DADF |
| Detail | To adjust dust detection level with dust detection correction control that is executed at paper interval in DADF mode. Reduce the value in the case of frequent display of cleaning instruction at the time of dust detection. As the value is smaller, the dust is less detected. Increase the value when black lines appear. As the value is larger, the small dust is more likely detected. | |
| Use Case | - When black line occurs due to dust - Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | When increasing the value too much, the cleaning instruction screen may appear too often since even small dust that will not be appeared on the image can be detected. When decreasing the value too much, black lines may appear. | |
| Display/Adj/Set Range | 1 to 255 | |
| Default Value | 200 | |
| Related Service Mode | COPIER> OPTION> IMG-RDR> DFDST-L2 | |
| Supplement/Memo | Black lines may appear on the image if there is dust. With dust detection correction control, the image is corrected to prevent black lines once dust is detected. | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > IMG-RDR

| DF2DSTL1 | 1 | Adj dust dtct level:strem, ppr int, back |
|-------------------------------|----------|---|
| Detail | | To adjust dust detection level that is executed in the Scanner Unit (Paper Back) at paper interval at the stream reading with DADF (1-path model). Reduce the value in the case of frequent display of cleaning instruction at the time of dust detection. As the value is smaller, dust is less likely to be detected. Increase the value when black lines appear. As the value is larger, the small dust is more likely to be detected. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | If the value is too large, the cleaning instruction screen may appear too often since even small dust that will not appear on the image can be detected. If the value is too small, black lines may appear. |
| Display/Adj/Set Range | | 1 to 255 1 to 84: Weakest, 85 to 169: Weak, 170 to 254: Moderate, 255: Strong |
| Default Value | | 200 |
| Supplement/Memo | | Black lines may appear on the image if there is dust. With dust detection correction control, the image is corrected to prevent black lines once dust is detected. |

■ IMG-MCON

COPIER (Service mode for printer) > OPTION (Specification setting mode) > IMG-MCON

| SHARP | 2 | Setting of sharpness level of image |
|-------------------------------|----------|---|
| Detail | | To set the setting level (center value) of sharpness of image. As the value is increased, the image tends to be sharp, and as the value is decreased, image tends to be soft. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 1 to 5 |
| Default Value | | 3 |
| VP-ART | 2 | Setting of line art processing |
| Detail | | To set outline processing for line art on scalable PDF. In the outline processing, a binary image outline is extracted in the field which is recognized as line art, and is converted into vector data. Specify whether to convert the binary image outline into vector data or to recognize it as one line (as a thin line). For the thin line, the line width can be specified. Change this value when you want to obtain an output of a wide-width line as one line rather than as an outline (when you want to prioritize edit operation as a line rather than image quality). |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 99 |
| Default Value | | 1 |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > IMG-MCON

| | | |
|-------------------------------|--|--|
| VP-TXT | 2 | Setting of character vectorization |
| Detail | To set vector conversion processing for text on scalable PDF. In the vector conversion processing, a binary image outline is extracted in the field which is recognized as text, and is converted into vector data. In regular vector conversion, function approximation is not used for small text because the image quality is not changed. When the value is changed, function approximation processing is executed for small text, which realizes smooth text although the image quality is changed. Change this value when you want to prioritize smoothness in small text. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 99 | |
| Default Value | 1 | |
| C-PDL-T | 2 | Setting of PDL gradation reference |
| Detail | To set whether gradation or density to be prioritized as the gradation reference for PDL. With priority on gradation (% of halftone dots), gradation is matched with original on the shadow area although the maximum density decreases. With priority on density, density is always matched with original. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: Priority on gradation (% of halftone dots), 1: Priority on density | |
| Default Value | 0 | |
| Supplement/Memo | Abbreviation of CAL_PDL_Target | |
| C-S-P-D | 2 | High dens end edge crrect: PDL dens prpty |
| Detail | To set ON/OFF of high density trailing edge correction function at PDL. By selecting CAL (priority on density) in C-PDL-T, high density trailing edge correction function is ON in normal operation; however, set OFF as needed. | |
| Use Case | ON: When reducing jagged line and jagged outline of text OFF: When matching density with original on high density area, or when prioritizing density and gradation | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 1 | |
| Related Service Mode | COPIER> OPTION> IMG-MCON> C-PDL-T | |
| Supplement/Memo | Abbreviation of CAL_Shadow_PDL_Density | |
| C-S-C-D | 2 | High density end edge crrect ON/OFF: copy |
| Detail | To set ON/OFF of high density trailing edge correction function at copy. With CAL of COPY, high density trailing edge correction function is ON in normal operation; however, set OFF as needed. | |
| Use Case | ON: When reducing jagged line and jagged outline of text OFF: When matching density with original on high density area, or when prioritizing density and gradation | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 1 | |
| Supplement/Memo | Abbreviation of CAL_Shadow_COPY_Density. When adjusting the input signal 255 to low in the case that the density of solid area is too high, jaggy (jagged effect of halftone) may occur to text, etc. By entering the input signal 255 as solid, occurrence of jaggy can be prevented. | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > IMG-MCON

| | | |
|-------------------------------|---|---|
| DOTSCT | 2 | Set high dens area white dot reduct mode |
| Detail | To set the mode to reduce white dots occur in the high density area with 600 dpi. Set 1 when white dots occur at regular intervals in the high density area. If it is not alleviated, set 2. Set 0 when degree of gradation in the high density area is decreased due to parts life or environment. | |
| Use Case | - When white dots occur at regular intervals in the high density area - When the degree of gradation is decreased because colors in the high density area become darker | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Caution | - It is enabled only for PDL job. - When 0 is set, white dots may be significant. - When 2 is set, gradation in the high density area may become not noticeable. | |
| Display/Adj/Set Range | 0 to 2 0: OFF, 1: ON (Weak), 2: ON (Strong) | |
| Default Value | 0 | |
| SP-GRAD | 2 | ON/OFF of special gradation processing |
| Detail | To set whether to make the density gradation characteristics of halftone the same as that of conventional machines. | |
| Use Case | When making the density gradation characteristic the same as that of conventional machines | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: ON, 1: OFF | |
| Default Value | 1 | |
| BIN-SEL | 2 | For R&D |

■ IMG-FIX

COPIER (Service mode for printer) > OPTION (Specification setting mode) > IMG-FIX

| | | |
|-------------------------------|---|--|
| RAG-CONT | 1 | Set fix smeared image ctrl mode level |
| Detail | To set level of the mode (skipping) to control smeared image caused by fixing area. | |
| Use Case | When a smeared image occurs | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | Set RAG-SW to 1 to 3 to enable skipping. | |
| Display/Adj/Set Range | 0 to 3 0: No skipping, 1: Small skipping, 2: Medium skipping, 3: Large skipping | |
| Default Value | 1 | |
| Supplement/Memo | When this mode is ineffective, use COPIER> ADJUST> DEVELOP> DE-OFS together. | |

■ CUSTOM

COPIER (Service mode for printer) > OPTION (Specification setting mode) > CUSTOM

| | | |
|-----------------|----------|-------------------|
| SCANTYPE | 1 | [Not used] |
|-----------------|----------|-------------------|

COPIER (Service mode for printer) > OPTION (Specification setting mode) > CUSTOM

| | | |
|-------------------------------|---|---|
| PDLEVCT1 | 2 | Set event skipping at continuous PDL job |
| Detail | To set event skipping at continuous PDL job. During continuous operation, processing performance may be decreased due to other events generated by the event in operation. In this case, decrease of processing performance can be prevented by skipping the amount of event. Processing performance: No event skipping < Subject of skipping 1 | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: No event skipping, 1: Subject of skipping 1 | |
| Default Value | 1 | |
| ABK-TOOL | 1 | Allow access from address book mntc tool |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to accept import from the address book maintenance tool. | |
| Use Case | When executing import from the address book maintenance tool | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Disabled, 1: Enabled | |
| Default Value | 0 | |
| Supplement/Memo | Address book maintenance tool: Tool provided from CMJ. | |
| DFEJCLED | 1 | ON/OFF of DADF Delivery Display LED |
| Detail | To set whether to light up the Delivery Display LED of DADF. | |
| Use Case | Upon user's request (The Delivery Display LED is too bright) | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: ON, 1: OFF | |
| Default Value | 0 | |
| RDEV-SP1 | 2 | RCON device special settings 1 |
| Detail | To execute the device special setting. | |
| Use Case | For customization | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | Use this mode only when specific instructions are given. | |
| Display/Adj/Set Range | 00000000 to 11111111 | |
| Default Value | 0 | |
| RDEV-SP2 | 2 | RCON device special settings 2 |
| Detail | To execute the device special setting. | |
| Use Case | For customization | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | Use this mode only when specific instructions are given. | |
| Display/Adj/Set Range | 00000000 to 11111111 | |
| Default Value | 0 | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > CUSTOM

| | | |
|-------------------------------|----------|---|
| RDEV-SP3 | 2 | RCON device special settings 3 |
| Detail | | To execute the device special setting. |
| Use Case | | For customization |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | Use this mode only when specific instructions are given. |
| Display/Adj/Set Range | | 00000000 to 11111111 |
| Default Value | | 0 |
| RDEV-SP4 | 2 | RCON device special settings 4 |
| Detail | | To execute the device special setting. |
| Use Case | | For customization |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | Use this mode only when specific instructions are given. |
| Display/Adj/Set Range | | 00000000 to 11111111 |
| Default Value | | 0 |
| RDEV-SP5 | 2 | RCON device special settings 5 |
| Detail | | To execute the device special setting. |
| Use Case | | For customization |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | Use this mode only when specific instructions are given. |
| Display/Adj/Set Range | | 00000000 to 11111111 |
| Default Value | | 0 |
| RDEV-SP6 | 2 | RCON device special settings 6 |
| Detail | | To execute the device special setting. |
| Use Case | | For customization |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | Use this mode only when specific instructions are given. |
| Display/Adj/Set Range | | 00000000 to 11111111 |
| Default Value | | 0 |
| RDEV-SP7 | 2 | RCON device special settings 7 |
| Detail | | To execute the device special setting. |
| Use Case | | For customization |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | Use this mode only when specific instructions are given. |
| Display/Adj/Set Range | | 00000000 to 11111111 |
| Default Value | | 0 |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > CUSTOM

| | | |
|-------------------------------|----------|---|
| RDEV-SP8 | 2 | RCON device special settings 8 |
| Detail | | To execute the device special setting. |
| Use Case | | For customization |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | Use this mode only when specific instructions are given. |
| Display/Adj/Set Range | | 00000000 to 11111111 |
| Default Value | | 0 |
| TIFFJPEG | 2 | [For customization] |
| DCM-EXCL | 1 | [For customization] |
| FPOt-MD | 2 | [For customization] |

■ USER

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|----------------------------------|----------|---|
| COPY-LIM | 1 | Setting of upper limit for copy |
| Detail | | To set the upper limit value for copy. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 1 to 9999 |
| Default Value | | 9999 |
| SLEEP | 1 | Setting of auto sleep function |
| Detail | | To set ON/OFF of auto sleep function. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: OFF, 1: ON |
| Default Value | | 1 |
| Additional Functions Mode | | Preferences> Timer/Energy Settings> Auto Sleep Time |
| Supplement/Memo | | The time to shift to the sleep mode can be set in Settings/Registration> Preferences> Timer/Energy Settings> Auto Sleep Time. |
| COUNTER1 | 1 | Display of software counter 1 |
| Detail | | To display counter type for software counter 1 on the Counter Check screen. |
| Use Case | | Upon user/dealer's request |
| Adj/Set/Operate Method | | N/A (Display only) |
| Caution | | Display only. No change is available. |
| Default Value | | It differs according to the location. |
| COUNTER2 | 1 | Setting of software counter 2 |
| Detail | | To set counter type for software counter 2 on the Counter Check screen. |
| Use Case | | Upon user/dealer's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 999 0: No registration |
| Default Value | | It differs according to the location. |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| COUNTER3 | 1 | Setting of software counter 3 |
|----------------------------------|----------|---|
| Detail | | To set counter type for software counter 3 on the Counter Check screen. |
| Use Case | | Upon user/dealer's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 999 0: No registration |
| Default Value | | It differs according to the location. |
| COUNTER4 | 1 | Setting of software counter 4 |
| Detail | | To set counter type for software counter 4 on the Counter Check screen. |
| Use Case | | Upon user/dealer's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 999 0: No registration |
| Default Value | | It differs according to the location. |
| COUNTER5 | 1 | Setting of software counter 5 |
| Detail | | To set counter type for software counter 5 on the Counter Check screen. |
| Use Case | | Upon user/dealer's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 999 0: No registration |
| Default Value | | It differs according to the location. |
| COUNTER6 | 1 | Setting of software counter 6 |
| Detail | | To set counter type for software counter 6 on the Counter Check screen. |
| Use Case | | Upon user/dealer's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 999 0: No registration |
| Default Value | | 0 |
| DATE-DSP | 2 | Setting of data/time display format |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set date/time display format according to the country or region. After the display format is set with this mode, the order of date is reflected to the followings: Preferences> Timer/Energy Settings> Date/Time Settings, and report output. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 2 0: YYMM/DD, 1: DD/MMYY, 2: MM/DD/YY |
| Default Value | | It differs according to the location. |
| Additional Functions Mode | | Preferences> Timer/Energy Settings> Date/Time Settings |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|-------------------------------|---|---|
| MB-CCV | 2 | Control card usage limit for Mail Box |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To restrict use of control card for Mail Box. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Unlimited, 1: Limited | |
| Default Value | 1 | |
| CONTROL | 1 | Charge setting of PDL job |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set charge count transmission of PDL job to the connecting charging management device (Coin Manager or non-Canon-made control card). | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: No charge, 1: Charge | |
| Default Value | 0 | |
| Related Service Mode | COPIER> OPTION> ACC> COIN | |
| CNT-DISP | 2 | Display/hide of serial No. |
| Detail | To set whether to display or hide the serial No. on the Counter Check screen. | |
| Use Case | When setting to display/hide serial No. on the Counter Check screen. | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 0 | |
| PH-D-SEL | 2 | Set dither matrix at screen processing |
| Detail | To set the screen dither matrix to be used for halftoning processing at the time of copy output, B&W Inbox scan output and B&W SEND output. When moire occurs frequently, set to 1. When the setting is changed, the number of PG lines to be output at PASCAL control is also changed. | |
| Use Case | When moire frequently occurs at the time of copy output, B&W Inbox scan output and B&W SEND output. Especially when moire frequently occurs in the halftone density area of photo and image gradation areas | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: 134 lines, 1: 141 lines | |
| Default Value | 0 | |
| Related Service Mode | COPIER> OPTION> USER> PH-D-SL2 | |
| COPY-JOB | 1 | Setting of copy job reservation |
| Detail | To set to enable/disable copy job reservation when the Card Reader/Coin Manager is used. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Enabled, 1: Disabled | |
| Default Value | 0 | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|-------------------------------|--|---|
| JOB-INVL | 2 | Job intvl setting at interruption copy |
| Detail | To set output interval between jobs at the time of interruption copy. Sorting is difficult after interruption copy because of the continuous output of the next job. Paper interval becomes longer when starting pickup for the next job after the last sheet of the previous job is delivered. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 2 0: Continuous output of the interruption copy and the next job 1: Starting pickup for the next job after the interruption copy is delivered all. 2: Starting pickup for the next job after the previous job is delivered all. (For all jobs) | |
| Default Value | 0 | |
| TAB-ROT | 1 | Set of landscape img rotn at PDL:tab ppr |
| Detail | To set whether to rotate landscape image by 180 degrees when PDL print is made on tab paper. When 1 is set, image is rotated. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Not rotated, 1: Rotated | |
| Default Value | 0 | |
| PR-PSESW | 1 | ON/OFF Pause All Print Jobs button dsp |
| Detail | To set whether to display [Pause All Print Jobs] button on the Status Monitor/Cancel screen. | |
| Use Case | - Upon user's request - When preferring to promptly stop the print job in operation or under reservation | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 0 | |
| IDPRN-SW | 1 | Charge target job set of dept mngm cntr |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the job type that advances the department management counter. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: PRINT category: Inbox Print, Report Print, PDL Print COPY category: COPY 1: PRINT category: Report Print, PDL Print COPY category: COPY, Inbox Print | |
| Default Value | 0 | |
| CPRT-DSP | 1 | [For customization] |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|-------------------------------|--|---|
| PCL-COPY | 2 | Set of PCL COPIES command control method |
| Detail | To set the binder control method of COPIES command with PCL. Select whether to use the control method of Canon-made PCL or use the same control method of non-Canon-made PCL. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 65535 0: Control method of Canon-made PCL (following the value of COPIES command that is specified for each page to control on a page basis) 1: Control method of non-Canon-made PCL (handling the value of COPIES command, which is specified for page 1 at the time of Collate mode, as bind figure while the value of COPIES command for the next page or later is invalid. Same control applies as Canon-made PCL at the time of non-sorted mode) 2 to 65535: For future use | |
| Default Value | 0 | |
| CNT-SW | 1 | Set default dspl items on charge counter |
| Detail | To set default display items of the charge counter on the Counter Check screen. For details of each type, refer to the Service Manual. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Type1, 1: Type2 | |
| Default Value | 0 | |
| BCNT-AST | 1 | Set of box print charge target job |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the job type that advances the count in box print with NE Controller (ASSIST). | |
| Use Case | When switching the job type that is subject to counting of the box print with NE Controller | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: PDL job, 1: Copy job | |
| Default Value | 0 | |
| PRJOB-CP | 2 | Set count TX at RX/report print |
| Detail | To set to enable/disable a page-basis count pulse transmission to the charging management device at the time of reception print or report print. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: No transmission, 1: Transmission | |
| Default Value | 0 | |
| Supplement/Memo | Charging management device: Coin Manager, Non-Canon-made control card | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|----------------------------------|---|---|
| DPT-ID-7 | 2 | Password entry set at dept ID reg/auth |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to require a password entry at the time of registration/authentication of department ID. With the setting to require entry, entry of 7-digit password is required as well as entry of department ID. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Department ID only, 1: 7-digit (password) entry | |
| Default Value | 0 | |
| RUI-RJT | 2 | Connct set at invalid auth from remoteUI |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set to disconnect HTTP port when the machine receives invalid authentication from remote UI 3 times. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Continued connection, 1: Disconnected | |
| Default Value | 0 | |
| SND-RATE | 2 | Set compress ratio at SEND high compress |
| Detail | To set the compression ratio when the data compression ratio for SEND (transmission) is set to "High Rati". As the value is larger, the compression ratio is higher (the file size becomes small). | |
| Use Case | When making the transmission file size smaller | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | As the value is larger, image quality is decreased. | |
| Display/Adj/Set Range | 0 to 2 0: Compression ratio 1/16, 1: Compression ratio 1/20, 2: Compression ratio 1/24 | |
| Default Value | 0 | |
| Additional Functions Mode | Function Settings> Send> Common Settings> Data Compression Ratio | |
| FREG-SW | 2 | For R&D |
| IFAX-SZL | 2 | Set of I-Fax transmission size limit |
| Detail | To set for restricting data size at the time of I-Fax transmission that does not go through the server. With the setting to restrict the data size, it is to be #830 error in the case of sending data that exceeds the upper limit value. In the case that the data goes through the server, the size of transmission data is always restricted. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Limited, 1: Not limited (Restriction applies when data goes through the server.) | |
| Default Value | 1 | |
| Additional Functions Mode | Function Settings> Send> E-Mail/I-Fax Settings> Maximum Data Size for Sending | |
| Supplement/Memo | Set the upper limit value for transmission data size in Settings/Registration menu. | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|----------------------------------|----------|--|
| IFAX-PGD | 2 | Set page split TX at IFax Simple mode TX |
| Detail | | To set whether to perform split-data transmission on a page basis in the case that the transmission size in I-Fax Simple mode exceeds the upper limit value. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | In the case to enable split-data transmission, be sure to get approval from the user by explaining the following: - No guarantee for page order on the reception side - There is a possibility of interruption of other received jobs between pages. |
| Display/Adj/Set Range | | 0 to 1 0: Disabled, 1: Enabled |
| Default Value | | 0 |
| Additional Functions Mode | | Function Settings> Send> E-Mail/I-Fax Settings> Maximum Data Size for Sending |
| Supplement/Memo | | Set the upper limit value for transmission data size in Settings/Registration menu. |
| MEAPSAFE | 2 | Setting of MEAP safe mode |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set safe mode for MEAP platform. MPSF is displayed on the Control Panel in safe mode. In safe mode, MEAP application is stopped while just the system application, which starts with initial state, is activated. Logs for cause analysis of MEAP failure can be obtained. |
| Use Case | | Perform system recovery processing when MEAP platform fails to be activated due to resource confliction between MEAP applications, service registration or use order. |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Normal mode, 1: Safe mode |
| Default Value | | 0 |
| PRNT-POS | 2 | ON/OFF of all pauses at error job cancel |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to pause the print operation of following jobs when a job is canceled due to an error inside the machine (#037, etc.) except service calls during PDL print. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: OFF, 1: ON |
| Default Value | | 0 |
| AFN-PSWD | 2 | Setting of Set/Reg menu access limit |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set restriction on accessing Settings/Registration menu by entering password. With the setting to enable this mode, password entry of system administrator is required after pressing Settings/Registration key. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Password is not required, 1: Password is required |
| Default Value | | 0 |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|-------------------------------|---|---|
| PTJAM-RC | 2 | Auto reprint setting at PDL print jam |
| Detail | To set to automatically restart printing after jam recovery that occurs with PDL print. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Not automatically reprinted, 1: Automatically reprinted | |
| Default Value | 1 | |
| PDL-NCSW | 2 | Card mngm setting for PDL print job |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set to make PDL print job to be subject to card management by the Card Reader. With the setting to enable this mode, PDL print is available only when the card ID of the card inserted to the Card Reader matches the department ID. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: PDL print is available with no card inserted. 1: PDL print is available only when the card ID matches the department ID in the case that the card is inserted. | |
| Default Value | 0 | |
| PS-MODE | 2 | Setting of PS print line drawing |
| Detail | To set the image processing at PS print. Set 8 when line width differs depending on the drawing position although the same line width is set. | |
| Use Case | Use case When right and left ruled lines are different in width | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 65535 0 to 7: Spare 8: Strokeadjustment is enabled. 9 to 65535: Spare | |
| Default Value | 0 | |
| CNCT-RLZ | 2 | Setting of connection serialize function |
| Detail | Connection serialize is a function to assure job grouping function of imageWARE Output Manager Select Edition V1.0. The setting to enable this mode can avoid job rearrangement because the machine does not receive job data from other connection until it completes job data reception from the current connection. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 0 | |
| Supplement/Memo | Connection: Connection to be established through network between multiple hosts (PC, etc). Job grouping function: A function of imageWARE Output Manager Select Edition V1.0. This is to prevent job interruption from other PC by group job (sending multiple jobs in 1 session at job transmission). | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|-------------------------------|--|---|
| COUNTER7 | 1 | Setting of software counter 7 |
| Detail | To set counter type for software counter 7 on the Counter Check screen. | |
| Use Case | Upon user/dealer's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 999 0: No registration | |
| Default Value | 0 | |
| COUNTER8 | 1 | Setting of software counter 8 |
| Detail | To set counter type for software counter 8 on the Counter Check screen. | |
| Use Case | Upon user/dealer's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 999 0: No registration | |
| Default Value | 0 | |
| 2C-CT-SW | 2 | Set of color counter at 2-color mode |
| Detail | To set whether to use the single color counter or full color counter for count-up in 2-color mode. | |
| Use Case | When supporting 2-color mode | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Single color counter, 1: Full color counter | |
| Default Value | It differs according to the location. | |
| JA-FUNC | 2 | Display of job archive function ON/OFF |
| Detail | To display ON/OFF of job archive function. Make the setting with the MEAP program which supports job archiving. | |
| Use Case | When using the job archive function | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Caution | Setting cannot be made with this item. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 0 | |
| JA-JOB | 2 | Display of job archive target job |
| Detail | To display the job type subject to job archive. When the job archive function is ON, archive operation is executed when executing the target job. Make the setting with the MEAP program which supports job archiving. | |
| Use Case | When using the job archive function | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Caution | Setting cannot be made with this item. | |
| Display/Adj/Set Range | 0: N/A, 3: Limited to FAX/IFAX, 0xFFFFFFFF: All jobs | |
| Default Value | 0 | |
| Related Service Mode | COPIER> OPTION> USER> JA-FUNC | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|-------------------------------|----------|---|
| LDAP-SW | 1 | Retrieval condition set for LDAP server |
| Detail | | To set the condition to search e-mail address, etc. from LDAP server. |
| Use Case | | When specifying condition to search e-mail address, etc. from LDAP server |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 5 0: Includes the next, 1: Not include the next, 2: Equivalent to the next, 3: Not equivalent to the next, 4: Starts with the next, 5: Finishes with the next |
| Default Value | | 4 |
| Supplement/Memo | | LDAP (Lightweight Directory Access Protocol): Registering LDAP server enables to search e-mail address, etc. from LDAP server and the result can be registered in the Address Book, etc. Registration is available by the following: Set Destination > Register LDAP Server |
| FROM-OF | 1 | Deletion of mail sender's address |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to delete the sender's address (From) at the time of e-mail transmission. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Retained, 1: Deleted |
| Default Value | | 0 |
| FILE-OF | 1 | Set file transmission to entered address |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to allow file transmission to a newly entered address. When 1 is set, file transmission is not available by entering the address because "File" is not displayed on the transmission screen. The addresses already registered in the Address Book can be used. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | To restrict addresses for transmission, be sure to manually delete them because the addresses registered in the Address Book can be used. |
| Display/Adj/Set Range | | 0 to 1 0: Enabled, 1: Disabled |
| Default Value | | 0 |
| MAIL-OF | 1 | Setting of e-mail TX to entered address |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to allow e-mail transmission to a newly entered address. When 1 is set, e-mail transmission is not available by entering the address because "E-mail" is not displayed on the transmission screen. The addresses already registered in the Address Book can be used. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | To restrict addresses for transmission, be sure to manually delete them because the addresses registered in the Address Book can be used. |
| Display/Adj/Set Range | | 0 to 1 0: Allowed, 1: Prohibited |
| Default Value | | 0 |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|----------------------------------|----------|---|
| IFAX-OF | 1 | Setting of I-Fax TX to entered address |
| Detail | | * Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to allow I-Fax transmission to a newly entered address. When 1 is set, I-Fax transmission is not available by entering the address because "I-Fax" is not displayed on the transmission screen. The addresses already registered in the Address Book can be used. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | To restrict addresses for transmission, be sure to manually delete them because the addresses registered in the Address Book can be used. |
| Display/Adj/Set Range | | 0 to 1 0: Allowed, 1: Prohibited |
| Default Value | | 0 |
| LDAP-DEF | 1 | Initial condtn set of LDAP server search |
| Detail | | To set initial condition for search target attribute that is specified at the time of LDAP server Details search. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 6 0: Name, 1: E-mail, 2: FAX, 3: Organization, 4: Organization unit, 5: No registration 1 (any setting), 6: No registration 2 (any setting) |
| Default Value | | 0 |
| Related Service Mode | | COPIER> OPTION> USER> LDAP-SW |
| FREE-DSP | 2 | ON/OFF of charge disable screen |
| Detail | | To set whether to display or hide the "Use Charge Management" screen for switching between charge and no charge. The hardware switch for switching charge/no charge in the Coin Manager enables the mode in which all the services are available for free (store manager mode) by temporarily canceling the charging system. Even without the hardware switch, the mode can be switched with the software switch when it is set to display the "Use Charge Management" screen in [Settings/Registration]. |
| Use Case | | When enabling all the services to be provided for free by temporarily canceling the charging system |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Hide, 1: Display |
| Default Value | | 0 |
| Additional Functions Mode | | Management Settings> Charge Management> Use Charge Management |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|----------------------------------|--|---|
| TNRB-SW | 2 | Display/hide of Toner Container counter |
| Detail | To set whether to display the Toner Container counter on the Counter Check screen. | |
| Use Case | When showing the Toner Container counter to the user | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 4 0: Hide, 1: Display (70s only), 2: Not used, 3: Display (70s/180s), 4: Display (60s/70s/180s) | |
| Default Value | It differs according to the location. | |
| Supplement/Memo | 60s: The number of premature replacements of the Toner Container 70s: The number of installations of a new Toner Container 80s: The number of installations of a new Toner Container + the number of premature replacements 180s: The number of installations of unidentified Toner Container | |
| USBH-DSP | 2 | ON/OFF of USB host use display |
| Detail | To set whether to display "Preferences> External Interface> USB Settings> Use USB Host". By selecting "1: Display", whether to use USB host on USB Settings screen can be selected. | |
| Use Case | When switching to display or hide "Use USB Host" on USB Settings screen | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | 0 | |
| Additional Functions Mode | Preferences> External Interface> USB Settings> Use USB Host | |
| USBM-DSP | 2 | ON/OFF USB ex-mem device MEAP driver use |
| Detail | To set whether to display [Use MEAP Driver for USB Storage Device] in [Settings/Registration]. When 0 is set, the item is not displayed so that the user administrator cannot change the setting. | |
| Use Case | When not allowing the user administrator to select whether to use the MEAP driver | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | When setting 0, be sure to make the setting after the specified setting is completed. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 1 | |
| Additional Functions Mode | Preferences> External Interface> USB Settings> Use MEAP Driver for USB External Device | |
| USBI-DSP | 2 | ON/OFF USB input device MEAP driver use |
| Detail | To set whether to display [Use MEAP Driver for USB Input Device] in [Settings/Registration]. When 0 is set, the item is not displayed so that the user administrator cannot change the setting. | |
| Use Case | When not allowing the user administrator to select whether to use the MEAP driver | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | When setting 0, be sure to make the setting after the specified setting is completed. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 1 | |
| Additional Functions Mode | Preferences> External Interface> USB Settings> Use MEAP Driver for USB Input Device | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|----------------------------------|--|---|
| CTCHKDSP | 1 | Display/hide of counter print |
| Detail | To set whether to display or hide "Print List" on the Counter Check screen. Model name, model number information, counter check date and counter information can be output as a total count management report. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | 1 | |
| DFLT-ADJ | 1 | Tgt Auto Adj Gradation initial dspl set |
| Detail | To set the initial display of the target full adjustment/quick adjustment items on [Auto Adjust Gradation] in [Settings/Registration]. This setting is enabled when EFI Controller is connected or only on the copy model which Adobe PS/PDF is available. When 0 is set, the target adjustment item is not displayed. When 1 to 3 is set, the target adjustment items (Copy/Printer/Both) are displayed and one of them is selected. | |
| Use Case | When switching the initial display at the time of Auto Adjust Gradation | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 3 0: Adjustment item is not displayed. 1 to 3: Adjustment item is displayed. | |
| Default Value | 0 | |
| Additional Functions Mode | Adjustment/Maintenance> Adjust Image Quality> Auto Adjust Gradation | |
| USBR-DSP | 2 | ON/OFF USB infrared devc MEAP driver use |
| Detail | To set whether to display "Use MEAP Driver for USB Infrared Device" in [Settings/Registration]. When 1 is set, whether to use MEAP driver can be selected on USB Settings screen. | |
| Use Case | When allowing the user administrator to select whether to use the MEAP driver | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 0 | |
| Additional Functions Mode | Preferences> External Interface> USB Settings> Use MEAP Driver for USB Infrared Device | |
| POL-SCAN | 1 | ON/OFF Rights Management Server set dspl |
| Detail | When "1: Display" is set, the Rights Management Server function screen is displayed. While the Rights Management Server function is a standard feature, it is possible to hide if not necessary. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | It differs according to the location. | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|-------------------------------|--|--|
| PH-D-SL2 | 2 | Set halftone process in text/photo mode |
| Detail | <p>When copying or B&W scanning to Inbox in text/photo mode, halftone processing of the image which reproduces gradation of text and photo judgment areas can be specified with this setting. Set to 1 when jaggy occurs or request to use the same halftoning method (text area) as conventional one is raised.</p> <p>Set to 2 when moire occurs frequently or request to use the same halftoning method as conventional B&W MFP method is raised.</p> <p>Even 0 is set, TBIC is used for text judgment area and low screen ruling for photo judgment area at the time of B&W Inbox scan.</p> <p>The setting is disabled when the B&W Inbox scanning density is set to auto.</p> | |
| Use Case | <p>- When jaggy occurs on the edge of text or thin lines at copy output. Especially when jaggy occurs in the text or thin lines (text in halftone dots) of the area where gradation in the halftone density is expressed like photo, graphics, etc.</p> <p>- When moire occurs frequently at the time of copy or B&W Inbox scan Especially when moire frequently occurs in the area where gradation in the halftone density is expressed like photo, graphics, etc. and this symptom is not alleviated with PH-D-SEL or sharpness adjustment</p> <p>- When receiving a request to use the same halftoning method (text area) as the conventional one (model with image area separation method) at copy output</p> <p>- When receiving a request to use the same halftoning method (both text and photo areas) as the conventional B&W MFP method at the time of copy or B&W Inbox output</p> | |
| Adj/Set/Operate Method | <p>1) Enter the setting value, and then press OK key.</p> <p>2) Turn OFF/ON the main power switch.</p> | |
| Display/Adj/Set Range | <p>0 to 2</p> <p>0: Low screen ruling (134 lines) is used for photo judgment area and high screen ruling (141 lines) for text judgment area.</p> <p>1: Low screen ruling is used for photo judgment area and TBIC for text judgment area.</p> <p>2: TBIC is used for both photo and text judgment areas.</p> | |
| Default Value | 0 | |
| Related Service Mode | COPIER> OPTION> USER> PH-D-SEL | |
| JA-SBOX | 2 | Setting of linking with Advanced Box: SAM |
| Detail | <p>*Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the link with Advanced Box when iW SAM is enabled.</p> <p>When 1 is set, linking with Advanced Box is enabled.</p> | |
| Use Case | When the operation restriction is cleared at the time of iW SAM | |
| Adj/Set/Operate Method | <p>1) Enter the setting value, and then press OK key.</p> <p>2) Turn OFF/ON the main power switch.</p> | |
| Display/Adj/Set Range | <p>0 to 1</p> <p>0: Disabled, 1: Enabled</p> | |
| Default Value | 0 | |
| JA-DFAX | 2 | Setting of direct fax transmission: SAM |
| Detail | <p>*Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the direct fax transmission when iW SAM is enabled.</p> <p>When 1 is set, the direct fax transmission is enabled.</p> | |
| Use Case | When the operation restriction is cleared at the time of iW SAM | |
| Adj/Set/Operate Method | <p>1) Enter the setting value, and then press OK key.</p> <p>2) Turn OFF/ON the main power switch.</p> | |
| Display/Adj/Set Range | <p>0 to 1</p> <p>0: Disabled, 1: Enabled</p> | |
| Default Value | 0 | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|-------------------------------|---|---|
| JA-REP | 2 | Setting of TX Report with image: SAM |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the TX Report with image when iW SAM is enabled. When 1 is set, the TX Report with image is enabled. | |
| Use Case | When the operation restriction is cleared at the time of iW SAM | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Disabled, 1: Enabled | |
| Default Value | 0 | |
| JA-FREP | 2 | Setting of Fax TX Report with image: SAM |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the Fax TX Report with image when iW SAM is enabled. When 1 is set, the Fax TX Report with image is enabled. | |
| Use Case | When the operation restriction is cleared at the time of iW SAM | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Disabled, 1: Enabled | |
| Default Value | 0 | |
| JA-BOX | 2 | Setting of Inbox document operation: SAM |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the operation for Inbox document at the time of iW SAM. When 1 is set, the Inbox document can be operated. | |
| Use Case | When the operation restriction is cleared at the time of iW SAM | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Disabled, 1: Enabled | |
| Default Value | 0 | |
| JA-FORM | 2 | Setting of image composition: SAM |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the image composition when iW SAM is enabled. When 1 is set, the image composition is enabled. | |
| Use Case | When the operation restriction is cleared at the time of iW SAM | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Disabled, 1: Enabled | |
| Default Value | 0 | |
| JA-PREV | 2 | Setting of preview page deletion: SAM |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether a page is deleted from the scan preview screen at the time of iW SAM. When 1 is set, a page is deleted from the scan preview screen. | |
| Use Case | When the operation restriction is cleared at the time of iW SAM | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Disabled, 1: Enabled | |
| Default Value | 0 | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|-------------------------------|----------|--|
| JA-PULL | 2 | Setting of network scan: SAM |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the network scan when iW SAM is enabled. When 1 is set, the network scan is enabled. |
| Use Case | | When the operation restriction is cleared at the time of iW SAM |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Disabled, 1: Enabled |
| Default Value | | 0 |
| JA-PDLB | 2 | Set of printer driver multi box save: SAM |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether a document can be simultaneously saved to multiple Inboxes from the printer driver at the time of iW SAM. When 1 is set, a document can be saved to multiple Inboxes from the printer driver. |
| Use Case | | When the operation restriction is cleared at the time of iW SAM |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Disabled, 1: Enabled |
| Default Value | | 0 |
| JA-JOBK | 2 | Setting of job merge allowance: SAM |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether merging jobs is allowed when iW SAM is enabled. When 1 is set, jobs can be merged. |
| Use Case | | When the operation restriction is cleared at the time of iW SAM |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Disabled, 1: Enabled |
| Default Value | | 0 |
| JA-JDF | 2 | Setting of JDF: SAM |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the use of JDF when iW SAM is enabled. When 1 is set, JDF can be used. |
| Use Case | | When the operation restriction is cleared at the time of iW SAM |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Disabled, 1: Enabled |
| Default Value | | 0 |
| JA-RUI | 2 | Setting of Inbox document access: SAM |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the Inbox document access from remote UI at the time of iW SAM When 1 is set, accessing to the Inbox document from remote UI is enabled. |
| Use Case | | When the operation restriction is cleared at the time of iW SAM |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Disabled, 1: Enabled |
| Default Value | | 0 |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|-------------------------------|--|--|
| JA-WEB | 2 | Setting of Inbox document upload: SAM |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the Inbox document upload with the Web browser at the time of iW SAM. When 1 is set uploading to the Inbox document with the Web Browser is enabled. | |
| Use Case | When the operation restriction is cleared at the time of iW SAM | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Disabled, 1: Enabled | |
| Default Value | 0 | |
| EXP-CRYP | 1 | Confndtial encrypt ON/OFF:add book expprt |
| Detail | * Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to encrypt the confidential part (password part) in the Address Book when exporting the address book and device settings via remote UI. When 0 is set, the confidential part in the address book is exported without encryption. | |
| Use Case | When there is a need to export password without encryption because of operation and tool | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | Be sure not to allow the user to execute export without encryption because of security concern. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 1 | |
| SMD-EXPT | 1 | Setting of export target data: remote UI |
| Detail | To set whether to export "service mode data" from remote UI. When 1 is set, "service mode data" is displayed as the target data of export on remote UI. When installing more than 1 machine at the same time, the same service mode data can be registered. | |
| Use Case | When installing more than 1 machine at the same time | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | 0 | |
| Supplement/Memo | If selecting "service mode data" as the target data of export on remote UI after setting SMD-EXPT to 1, service mode data can be exported. | |
| SNDSTREN | 1 | Set of setting delete aftr scan and send |
| Detail | To set whether to delete the transmission settings except for the address after transmission from the "Scan and Send" screen. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 3 0: Deleted, 1: Retained only the transmission setting, 2: Retained the transmission setting and address, 3: Retained only address | |
| Default Value | It differs according to the location. | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|-------------------------------|----------|--|
| FAXSTREN | 1 | Set of setting delete aftr fax transmit |
| Detail | | To set whether to delete the transmission settings except for the address after transmission from the "Fax" screen. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Delete, 1: Retain |
| Default Value | | It differs according to the location. |
| SJ-UNMSK | 2 | ON/OFF secured job masking cancellation |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to mask other people's secured jobs. When 0 is set, operation of other people's secured jobs is not possible because they are masked. When COIN is set to 6 or 7 (charge mode: Type-C), set 1. Masking is canceled and other people's secured jobs can be operated. It is enabled at MEAP authentication. |
| Use Case | | When operating secured jobs in charge mode Type-C |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: OFF (Masking enabled), 1: ON (Masking canceled) |
| Default Value | | 0 |
| Related Service Mode | | COPIER> OPTION> ACC> COIN |
| SJ-CLMSK | 2 | ON/OFF secured job stop button display |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to display the button to stop a secured job. When 0 is set, the stop button is displayed. When COIN is set to 6 or 7 (charge mode: Type-C), set 1. Since the stop button is not displayed, the secured job cannot be stopped. |
| Use Case | | When prohibiting to stop the secured job in charge mode Type-C |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: OFF (Display), 1: ON (Hide) |
| Default Value | | 0 |
| Related Service Mode | | COPIER> OPTION> ACC> COIN |
| PDFD-MSW | 2 | Set output paper size: direct print PDF |
| Detail | | To set output paper size at direct print PDF. Usually, the region defined by MediaBox is output. However, in some cases, the region defined (trimmed) by CropBox is judged as output paper size depending on PDF file. Set 1 when output result differs from what is defined at direct print PDF. |
| Use Case | | When preferring to output a PDF file with paper which size is defined by CropBox while the sizes of MediaBox and CropBox are different |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 1 0: MediaBox (Normal), 1: CropBox |
| Default Value | | 0 |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|----------------------------------|---|--|
| SFT-OUT | 2 | Setting of offset priority delivery |
| Detail | To set whether to deliver a job where offset and collate/offset group is set to the delivery destination with offset function. When 0 is set, a job is delivered to the delivery destination set in [Settings/Registration] even though the offset function is not available. When 1 is set, a job is delivered to the delivery destination with offset function even though a delivery destination without offset function is set in [Settings/Registration]. | |
| Use Case | When preferring to deliver a job to the delivery destination with offset function | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Based on Output Tray Settings, 1: Priority on job settings (deliver to a delivery destination where offset is possible) | |
| Default Value | 1 | |
| Additional Functions Mode | Function Settings> Common> Paper Output Settings> Output Tray Settings | |
| LGCY-SCP | 2 | Setting of PPA/secured print switch |
| Detail | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to use the PPA function or the conventional secured print function. Set 0 when using the PPA function. The conventional secured print function is disabled. Set 1 when using the conventional secured print function (when the EFI Controller is connected, etc.). The PPA function is disabled. When this item is set to 0, the setting of UI-PPA becomes 1. When this item is set to 1, the setting of UI-PPA becomes 0. | |
| Use Case | When using the conventional secured print function (when the EFI Controller is connected, etc.) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Caution | The PPA function cannot be used when the EFI Controller is connected. | |
| Display/Adj/Set Range | 0 to 1 0: Use the PPA function, 1: Use the conventional secured print function | |
| Default Value | 0 | |
| Related Service Mode | COPIER> OPTION> DSPLY-SW> UI-PPA | |
| Supplement/Memo | PPA (Personal Print Application): A function to hold print job. It contains the function of secured print. | |
| CNT-PRT | 2 | ON/OFF of parts counter report output |
| Detail | To set whether to print parts counter values on the counter report. | |
| Use Case | When grasping the estimated life of parts while the monitoring service function is not used | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: OFF (Not print), 1: ON (Print) | |
| Default Value | It differs according to the location. | |
| Additional Functions Mode | Check Counter> Print List | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|----------------------------------|----------|---|
| JA-WIFI | 2 | Setting of SAM Wi-Fi direct print |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to allow Wi-Fi direct print when iW SAM is enabled. Wi-Fi direct print cannot be used when iW SAM is enabled. However, when 1 is set, it can be used. |
| Use Case | | When the operation restriction is cleared at the time of iW SAM |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Disabled, 1: Enabled |
| Default Value | | 0 |
| C-P-SIZE | 2 | [For customization] |
| MF-FEED | 1 | Manual restart w/OK key: no ppr on MP Tr |
| Detail | | If the following three conditions are satisfied, pickup is not restarted automatically when placing paper on the Multi-purpose Tray. 1. The setting of "Preferences> Paper Settings> Multi-Purpose Tray Defaults" is "Fixed". 2. The job type is PDL. 3. The setting value of this service mode is 1. 4. Paper is placed at occurrence of no paper on the Multi-Purpose Tray. |
| Use Case | | Upon user's request. Use this item for customization for Aeon during application of service mode. |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 1 0: OFF, 1: ON |
| Default Value | | 0 |
| Additional Functions Mode | | Preferences> Paper Settings> Multi-Purpose Tray Defaults |
| TNRBEXGR | 2 | ON/OFF oprtn hold: Tonn Cont early rplce |
| Detail | | To set whether to hold the operation when the Toner Container is prematurely replaced although it can still be used. When a new Toner Container is inserted while 1 is set, a message is displayed and the operation is held. The message disappears by changing the Toner Container back to the one before replacement or by changing the setting value of this item to 0 and then restarting the machine. |
| Use Case | | When preventing from replacing the Toner Container prematurely |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | The message does not disappear unless the Toner Container is changed back to the one before the replacement. Be sure to get approval from the user by telling the above specifications before making the setting. |
| Display/Adj/Set Range | | 0 to 1 0: OFF, 1: ON |
| Default Value | | 0 |
| DUTL-SW | 2 | For R&D |
| INSTDT-Y | 1 | Register installation date info: year |
| Detail | | To set the information on the installation date (year). |
| Use Case | | - At installation - When replacing the HDD |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 2038 |
| Default Value | | 0 |
| Related Service Mode | | COPIER>FUNCTION>INSTALL>INSTDTST |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > USER

| | | |
|-------------------------------|----------|--|
| INSTDT-M | 1 | Register installation date info: month |
| Detail | | To set the information on the installation date (month). |
| Use Case | | - At installation - When replacing the HDD |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 12 |
| Default Value | | 0 |
| Related Service Mode | | COPIER>FUNCTION>INSTALL>INSTDTST |
| INSTDT-D | 1 | Register installation date info: day |
| Detail | | To set the information on the installation date (day). |
| Use Case | | - At installation - When replacing the HDD |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 31 |
| Default Value | | 0 |
| Related Service Mode | | COPIER>FUNCTION>INSTALL>INSTDTST |
| INSTDT-H | 1 | Register installation date info: hour |
| Detail | | To set the information on the installation date (hour). |
| Use Case | | - At installation - When replacing the HDD |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 23 |
| Default Value | | 0 |
| Related Service Mode | | COPIER>FUNCTION>INSTALL>INSTDTST |
| INSTDT-N | 1 | Register installation date info: minute |
| Detail | | To set the information on the installation date (minute). |
| Use Case | | - At installation - When replacing the HDD |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 59 |
| Default Value | | 0 |
| Related Service Mode | | COPIER>FUNCTION>INSTALL>INSTDTST |
| STOP-USE | 1 | ON/OFF of Stop key function |
| Detail | | To switch ON and OFF of the Stop key function. When Stop key is pressed, all print jobs are paused. |
| Use Case | | When switching to use/not use Stop key according to the customer |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | Be sure to explain to the customer in advance that all print jobs are paused when Stop key is pressed. |
| Display/Adj/Set Range | | 0 to 1 0: OFF, 1: ON |
| Default Value | | 1 |

■ ACC

COPIER (Service mode for printer) > OPTION (Specification setting mode) > ACC

| | | |
|----------------------------------|----------|--|
| COIN | 1 | Setting of charge management |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set charging management method. |
| Use Case | | At installation of Coin Manager |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | Following items are automatically specified when changing the value to 3 (from 0 to 2). The change will not be returned even if changing back the value to 0 to 2 (from 3) once the mode has been changed. - COPIER> OPTION> USER> CONTROL=1 - COPIER> OPTION> NETWORK> DA-CNCT=1 - COPIER> OPTION> DSPLY-SW> UI-BOX, UI-SEND, UI-FAX=0 - Function Settings> Send> E-Mail/I-Fax Settings> Communication Settings> SMTP Receive, POP=OFF - Preferences> Network> TCP/IP Settings> DNS Settings> FTP Print Settings> Use FTP Printing=OFF - Preferences> Network> TCP/IP Settings> DNS Settings> IPP Print Settings> Use IPP Printing=ON |
| Display/Adj/Set Range | | 0 to 7 0: No charge 1: Charge with Coin Manager 2: Charge with remote counter 3: Charge with DA (only in Japan) 4: Charge with this machine itself 5: Not used 6: External charge mode 6 7: External charge mode 7 |
| Default Value | | 0 |
| Related Service Mode | | COPIER> OPTION> USER> CONTROL COPIER> OPTION> FNC-SW> DA-CNCT COPIER> OPTION> DSPLY-SW> UI-BOX, UI-SEND, UI-FAX COPIER> OPTION> ACC> PDL-THR |
| Additional Functions Mode | | Function Settings> Send> E-Mail/I-Fax Settings> Communication Settings Preferences> Network> TCP/IP Settings> DNS Settings> FTP Print Settings, IPP Print Settings |
| Supplement/Memo | | Control card can be used with "No charge". DA: Digital Accessory |
| CARD-SW | 1 | Screen set when Coin Manager connected |
| Detail | | To set coin or card that the user is urged to insert on the Control Panel when the Coin Manager is connected. |
| Use Case | | Upon user's request |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 3 0: Card, 1: certification by external device, 2: Coin and card, 3: Card |
| CC-SPSW | 2 | Support setting of control card I/F |
| Detail | | To set support level for control card (CCIV/CCV) interface. |
| Use Case | | Upon user's request (when connecting to the external counter management system using the control card interface) |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: No support, 1: Support |
| Default Value | | 0 |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > ACC

| | | |
|-------------------------------|----------|---|
| UNIT-PRC | 2 | Setting of Coin Manager currency unit |
| Detail | | To set currency unit to be handled with Coin Manager |
| Use Case | | At installation of Coin Manager |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 6 0: Japanese yen, 1: Euro, 2: Pound, 3: Swiss Franc, 4: Dollar, 5: No currency unit (no fractional unit), 6: No currency unit (with fractional unit) |
| Default Value | | 0 |
| MIN-PRC | 1 | Set of Coin Manager minimum price |
| Detail | | To set the minimum amount to be handled with Coin Manager. Enter 10 when specifying 10 Japanese yen as the minimum amount to be handled with the Coin Manager that supports Japanese yen. In the case to specify 1 to 4 (Euro/Pound/Swiss Franc/Dollar) by going through the following: COPIER> OPTION> ACC> UNIT-PRC, entry is in fractional unit. Entry of 50 indicates 50 cents (\$ 0.50). |
| Use Case | | At installation of Coin Manager |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | This mode is enabled when selecting 4 for the following: COPIER> OPTION> ACC> COIN. |
| Display/Adj/Set Range | | 0 to 9999 |
| Default Value | | 10 |
| Related Service Mode | | COPIER> OPTION> ACC> COIN, UNIT-PRC |
| Supplement/Memo | | When a value smaller than the minimum amount is entered in Settings/Registration menu as the charging amount, it causes an error. |
| MAX-PRC | 1 | Set of Coin Manager maximum price |
| Detail | | To set the maximum amount to be handled with Coin Manager. Enter 8800 when specifying 8800 Japanese yen as the maximum amount to be handled with the Coin Manager that supports Japanese yen. |
| Use Case | | At installation of Coin Manager |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | This mode is enabled when selecting 4 for the following: COPIER> OPTION> ACC> COIN. |
| Display/Adj/Set Range | | 0 to 9999 |
| Default Value | | 8800 |
| Related Service Mode | | COPIER> OPTION> ACC> COIN, UNIT-PRC |
| Supplement/Memo | | When a value larger than the maximum amount is entered in Settings/Registration menu as the charging amount, it causes an error. |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > ACC

| | | |
|-------------------------------|----------|---|
| SRL-SPSW | 1 | Setting of Serial I/F Kit support |
| Detail | | To set the support level of the Serial Interface Kit. To keep processing performance of printer engine, select "1: Priority on speed". To correctly stop the output by the upper limit number of sheets, select "2: Priority on upper limit number of sheets". |
| Use Case | | At installation of Serial Interface Kit |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | With priority on speed, output cannot be correctly stopped by the upper limit number of sheets. With priority on the upper limit number of sheets, processing performance of the printer engine is decreased depending on pickup location. |
| Display/Adj/Set Range | | 0 to 2 0: No support, 1: Priority on speed, 2: Priority on upper limit number of sheets |
| Default Value | | 0 |
| CR-TYPE | 1 | Setting of Card Reader |
| Detail | | To set the model of the Card Reader. Set 1 in the case of connecting the Card Reader-C1. It operates even 0 is set, but recognition rate decreases. |
| Use Case | | When connecting the Card Reader-C1 |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Card Reader-F1, 1: Card Reader-C1 |
| Default Value | | 0 |
| MEAP-SRL | 1 | Set to allow serial comctn from MEAP app |
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to allow serial communication of MEAP application. When 1 is set, serial communication of the machine is stopped and only the serial communication with MEAP application is available. |
| Use Case | | When performing serial communication from MEAP application |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 0 to 1 0: Prohibited, 1: Allowed |
| Default Value | | 0 |
| CV-CSZ | 1 | [For customization] |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > ACC

| COIN-AUT | 1 | ON/OFF of charge/no charge mixed setting |
|----------------------------------|----------|--|
| Detail | | * Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set whether to switch charge/no charge according to the authentication setting in an environment where both charged and no charged users exist. When this item is set to 1 while the setting value of COIN is 4, the initial screen where the user can select charge/no charge can be set. Selecting "Charge" on the initial screen displays the copy screen, and selecting "No Charge" displays the main menu after authentication. |
| Use Case | | At installation of Coin Manager |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | When setting 1, be sure to set COIN to 4 in advance. If COIN-AUT is set first, it is necessary to make the settings in the following order again: COIN and then COIN-AUT. |
| Display/Adj/Set Range | | 0 to 1 0: OFF, 1: ON |
| Default Value | | 0 |
| Related Service Mode | | COPIER> OPTION> ACC> COIN COPIER> OPTION> DSPLY-SW> UI-BOX/SEND/FAX |
| Additional Functions Mode | | Preferences > Display Settings > Default Screen after Startup/Restoration |

■ INT-FACE

COPIER (Service mode for printer) > OPTION (Specification setting mode) > INT-FACE

| NWCT-TM | 2 | Timeout setting of network connection |
|-------------------------------|----------|---|
| Detail | | *Operation on this item is restricted by the setting of [Restrict Service Representation Access]. To set the time to keep network connection between this machine and the PC application (keep-alive setting). As the value is incremented by 1, the time is increased by 1 minute. |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Display/Adj/Set Range | | 1 to 5 |
| Unit | | min |
| Default Value | | 5 |
| Supplement/Memo | | Expected PC application: Network print application, E-mail function, cascade copy, MEAP network application, etc. |

■ LCNS-TR

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| ST-SEND | 2 | Installation state dspl of SEND function |
|-------------------------------|----------|--|
| Detail | | To display installation state of SEND function when disabling and then transferring the license. |
| Use Case | | When checking whether SEND function is installed |
| Adj/Set/Operate Method | | 1) Select ST-SEND. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-SEND. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | 1 |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|-------------------------------|----------|--|
| TR-SEND | 2 | Trns license key dspl of SEND function |
| Detail | | To display transfer license key to use SEND function when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-SEND. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-SEND. |
| Display/Adj/Set Range | | 24 digits |
| ST-ENPDF | 2 | Install state dspl of Encryption PDF |
| Detail | | To display installation state of encrypted PDF transmission function when disabling and then transferring the license. |
| Use Case | | When checking whether Encryption PDF is installed |
| Adj/Set/Operate Method | | 1) Select ST-ENPDF. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-ENPDF. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-ENPDF | 2 | Trns license key dspl of Encryption PDF |
| Detail | | To display transfer license key to use Encryption PDF when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-ENPDF. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-ENPDF. |
| Caution | | This mode is enabled when SEND function is installed. |
| Display/Adj/Set Range | | 24 digits |
| ST-SPDF | 2 | Install state dspl of Searchable PDF |
| Detail | | To display installation state of Searchable PDF when disabling and then transferring the license. |
| Use Case | | When checking whether Searchable PDF is installed |
| Adj/Set/Operate Method | | 1) Select ST-SPDF. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-SPDF. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-SPDF | 2 | Trns license key dspl of Searchable PDF |
| Detail | | To display transfer license key to use Searchable PDF when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-SPDF. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-SPDF. |
| Caution | | This mode is enabled when SEND function is installed. |
| Display/Adj/Set Range | | 24 digits |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|-------------------------------|----------|--|
| ST-EXPDF | 2 | Instal state of Encry PDF + Searchbl PDF |
| Detail | | To display installation state of encrypted PDF + searchable PDF when disabling and then transferring the license. |
| Use Case | | When checking whether Encryption PDF + Searchable PDF is installed |
| Adj/Set/Operate Method | | 1) Select ST-EXPDF. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-EXPDF. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-EXPDF | 2 | Trns lcns key of Encry PDF+Searchbl PDF |
| Detail | | To display transfer license key to use Encryption PDF + Searchable PDF when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-EXPDF. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-EXPDF. |
| Caution | | This mode is enabled when SEND function is installed for Japan. |
| Display/Adj/Set Range | | 24 digits |
| ST-PDFDR | 2 | Install state dspl of Direct Print PDF |
| Detail | | To display installation state of Direct Print PDF when disabling and then transferring the license. |
| Use Case | | When checking whether Direct Print PDF is installed |
| Adj/Set/Operate Method | | 1) Select ST-PDFDR. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-PDFDR. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-PDFDR | 2 | Trns lcns key dspl of Direct Print PDF |
| Detail | | To display transfer license key to use Direct Print PDF when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-PDFDR. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-PDFDR. |
| Display/Adj/Set Range | | 24 digits |
| ST-SCR | 2 | Install state dspl of Encry Secure Print |
| Detail | | To display installation state of Encrypted Secure Print when disabling and then transferring the license. |
| Use Case | | When checking whether Encrypted Secure Print is installed |
| Adj/Set/Operate Method | | 1) Select ST-SCR. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-SCR. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|-------------------------------|----------|--|
| TR-SCR | 2 | Trns license key dspl: Encry Secure Pnt |
| Detail | | To display transfer license key to use Encrypted Secure Print when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-SCR. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-SCR. |
| Caution | | This mode is enabled when there is "3DES+USH-H" Board. |
| Display/Adj/Set Range | | 24 digits |
| ST-BRDIM | 2 | Install state dspl: PCL Barcode Printing |
| Detail | | To display installation state of BarDIMM when disabling and then transferring the license. |
| Use Case | | When checking whether Barcode Printing for PCL is installed |
| Adj/Set/Operate Method | | 1) Select ST-BRDIM. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-BRDIM. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-BRDIM | 2 | Trns lcns key dspl: PCL Barcode Printing |
| Detail | | To display transfer license key to use Barcode Printing for PCL when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-BRDIM. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-BRDIM. |
| Display/Adj/Set Range | | 24 digits |
| ST-VNC | 2 | Install state dspl of Remote Oprtr Soft |
| Detail | | To display installation state of Remote Operators Software when disabling and then transferring the license. |
| Use Case | | When checking whether Remote Operators Software is installed |
| Adj/Set/Operate Method | | 1) Select ST-VNC. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-VNC. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-VNC | 2 | Trns lcns dspl of Remote Operators Soft |
| Detail | | To display transfer license key to use Remote Operators Software when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-VNC. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-VNC. |
| Display/Adj/Set Range | | 24 digits |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|-------------------------------|----------|--|
| ST-WEB | 2 | Install state dspl: Web Access Software |
| Detail | | To display installation state of Web Access Software when disabling and then transferring the license. |
| Use Case | | When checking whether Web Access Software is installed |
| Adj/Set/Operate Method | | 1) Select ST-WEB. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-WEB. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-WEB | 2 | Trns license key dspl of Web Access Soft |
| Detail | | To display transfer license key to use Web Access Software when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-WEB. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-WEB. |
| Display/Adj/Set Range | | 24 digits |
| ST-HRPDF | 2 | Install state dspl of High Compress PDF |
| Detail | | To display installation state of High Compression PDF when disabling and then transferring the license. |
| Use Case | | When checking whether High Compression PDF is installed |
| Adj/Set/Operate Method | | 1) Select ST-HRPDF. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-HRPDF. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-HRPDF | 2 | Trns lcns key dspl of High Compress PDF |
| Detail | | To display transfer license key to use High Compression PDF when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-HRPDF. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-HRPDF. |
| Display/Adj/Set Range | | 24 digits |
| ST-TRSND | 2 | Install state dspl: Trial SEND function |
| Detail | | To display installation state of Trial SEND function when disabling and then transferring the license. |
| Use Case | | When checking whether Trial SEND function is installed |
| Adj/Set/Operate Method | | 1) Select ST-TRSND. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-TRSND. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|-------------------------------|----------|--|
| TR-TRSND | 2 | Trns lcns key dspl: Trial SEND function |
| Detail | | To display transfer license key to use Trial SEND function when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-TRSND. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-TRSND. |
| Display/Adj/Set Range | | 24 digits |
| ST-WTMRK | 2 | Install state dspl of Secure Watermark |
| Detail | | To display installation state of Secure Watermark when disabling and then transferring the license. |
| Use Case | | When checking whether Secure Watermark is installed |
| Adj/Set/Operate Method | | 1) Select ST-WTMRK. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-WTMRK. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-WTMRK | 2 | Trns license key dspl: Secure Watermark |
| Detail | | To display transfer license key to use Secure Watermark when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-WTMRK. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-WTMRK. |
| Display/Adj/Set Range | | 24 digits |
| ST-TSPDF | 2 | Install state dspl of Time Stamp PDF: JP |
| Detail | | To display installation state of Time Stamp PDF (JP only) when disabling and then transferring the license. |
| Use Case | | When checking whether Time Stamp PDF (JP only) is installed |
| Adj/Set/Operate Method | | 1) Select ST-TSPDF. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-TSPDF. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-TSPDF | 2 | Trns lcns key dspl of Time Stamp PDF: JP |
| Detail | | To display transfer license key to use Time Stamp PDF (JP only) when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-TSPDF. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-TSPDF. |
| Caution | | This mode is enabled when SEND function is installed. |
| Display/Adj/Set Range | | 24 digits |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|-------------------------------|----------|--|
| ST-USPDF | 2 | Install state dspl of Dgtl User Sign PDF |
| Detail | | To display installation state of Digital User Signature PDF when disabling and then transferring the license. |
| Use Case | | When checking whether Digital User Signature PDF is installed |
| Adj/Set/Operate Method | | 1) Select ST-USPDF. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-USPDF. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | 0 |
| TR-USPDF | 2 | Trns lcns key dspl of Dgtl User Sign PDF |
| Detail | | To display transfer license key to use Digital User Signature PDF when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-USPDF. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-USPDF. |
| Caution | | This mode is enabled when SEND function is installed. |
| Display/Adj/Set Range | | 24 digits |
| ST-DVPDF | 2 | Install state dspl of Device Sign PDF |
| Detail | | To display installation state of device signature PDF transmission function when disabling and then transferring the license. |
| Use Case | | When checking whether Device Signature PDF is installed |
| Adj/Set/Operate Method | | 1) Select ST-DVPDF. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-DVPDF. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-DVPDF | 2 | Trns lcns key dspl of Device Sign PDF |
| Detail | | To display transfer license key to use Device Signature PDF when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-DVPDF. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-DVPDF. |
| Caution | | This mode is enabled when SEND function is installed. |
| Display/Adj/Set Range | | 24 digits |
| ST-SCPDF | 2 | Install state dspl of Trace & Smooth PDF |
| Detail | | To display installation state of Trace & Smooth PDF when disabling and then transferring the license. |
| Use Case | | When checking whether Trace & Smooth PDF is installed |
| Adj/Set/Operate Method | | 1) Select ST-SCPDF. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-SCPDF. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|-------------------------------|----------|--|
| TR-SCPFD | 2 | Trns lcns key dspl of Trace & Smooth PDF |
| Detail | | To display transfer license key to use Trace & Smooth PDF when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-SCPFD. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-SCPFD. |
| Caution | | This mode is enabled when SEND function is installed. |
| Display/Adj/Set Range | | 24 digits |
| ST-AMS | 2 | Install state dspl of Access Mngm System |
| Detail | | To display installation state of Access Management System when disabling and then transferring the license. |
| Use Case | | When checking whether Access Management System is installed |
| Adj/Set/Operate Method | | 1) Select ST-AMS. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-AMS. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-AMS | 2 | Trns lcns key dspl of Access Mngm System |
| Detail | | To display transfer license key to use Access Management System when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-AMS. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-AMS. |
| Display/Adj/Set Range | | 24 digits |
| ST-ERDS | 2 | Install state dspl: E-RDS 3rd Pty Expnsn |
| Detail | | To display installation state of monitoring service function when disabling and then transferring the license. |
| Use Case | | When checking whether E-RDS non-Canon-made extension function is installed |
| Adj/Set/Operate Method | | 1) Select ST-ERDS. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-ERDS. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| Supplement/Memo | | Monitoring service function: A function to send charge counter to the non-Canon-made charge server. |
| TR-ERDS | 2 | Trns lcns key dspl: E-RDS 3rd Pty Expnsn |
| Detail | | To display transfer license key to use E-RDS non-Canon-made extension function when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-ERDS. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-ERDS. |
| Display/Adj/Set Range | | 24 digits |
| Supplement/Memo | | Monitoring service function: A function to send charge counter to the non-Canon-made charge server. |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|-------------------------------|--|---|
| ST-PS | 2 | Install state display of PS function |
| Detail | To display installation state of PS function when disabling and then transferring the license. | |
| Use Case | When checking whether PS function is installed | |
| Adj/Set/Operate Method | 1) Select ST-PS. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-PS. | |
| Display/Adj/Set Range | When operation finished normally: OK! | |
| Default Value | According to the setting at shipment | |
| TR-PS | 2 | Transfer license key dspl of PS function |
| Detail | To display transfer license key to use PS function when disabling and then transferring the license. | |
| Use Case | - When replacing HDD - When replacing the device | |
| Adj/Set/Operate Method | 1) Select ST-PS. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-PS. | |
| Display/Adj/Set Range | 24 digits | |
| ST-PCL | 2 | Install state display of PCL function |
| Detail | To display installation state of PCL function when disabling and then transferring the license. | |
| Use Case | When checking whether PCL function is installed | |
| Adj/Set/Operate Method | 1) Select ST-PCL. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-PCL. | |
| Display/Adj/Set Range | When operation finished normally: OK! | |
| Default Value | According to the setting at shipment | |
| TR-PCL | 2 | Transfer license key dspl: PCL function |
| Detail | To display transfer license key to use PCL function when disabling and then transferring the license. | |
| Use Case | - When replacing HDD - When replacing the device | |
| Adj/Set/Operate Method | 1) Select ST-PCL. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-PCL. | |
| Display/Adj/Set Range | 24 digits | |
| ST-PSLI5 | 2 | Install state dspl: PS/LIPS4/LIPS LX: JP |
| Detail | To display installation state of PS/LIPS4/LIPS LX function (JP only) when disabling and then transferring the license. | |
| Use Case | When checking whether PS/LIPS4/LIPS LX function (JP only) is installed | |
| Adj/Set/Operate Method | 1) Select ST-PSLI5. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-PSLI5. | |
| Display/Adj/Set Range | When operation finished normally: OK! | |
| Default Value | 0 | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|-------------------------------|--|---|
| TR-PSLI5 | 2 | Trns lcns key dspl: PS/LIPS4/LIPS LX: JP |
| Detail | To display transfer license key to use PS/LIPS4/LIPS LX function (JP only) when disabling and then transferring the license. | |
| Use Case | - When replacing HDD - When replacing the device | |
| Adj/Set/Operate Method | 1) Select ST-PSLI5. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-PSLI5. | |
| Display/Adj/Set Range | 24 digits | |
| ST-LIPS5 | 2 | Install state dspl:LIPS LX/LIPS4 func:JP |
| Detail | To display installation state of LIPS LX/LIPS4 function (JP only) when disabling and then transferring the license. | |
| Use Case | When checking whether LIPS LX/LIPS4 function (JP only) is installed | |
| Adj/Set/Operate Method | 1) Select ST-LIPS5. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-LIPS5. | |
| Display/Adj/Set Range | When operation finished normally: OK! | |
| Default Value | According to the setting at shipment | |
| TR-LIPS5 | 2 | Trns lcns key dspl:LIPS LX/LIPS4 func:JP |
| Detail | To display transfer license key to use LIPS LX/LIPS4 function (JP only) when disabling and then transferring the license. | |
| Use Case | - When replacing HDD - When replacing the device | |
| Adj/Set/Operate Method | 1) Select ST-LIPS5. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-LIPS5. | |
| Display/Adj/Set Range | 24 digits | |
| ST-LIPS4 | 2 | Install state display of LIPS4 func: JP |
| Detail | To display installation state of LIPS4 function (JP only) when disabling and then transferring the license. | |
| Use Case | When checking whether LIPS4 function (JP only) is installed | |
| Adj/Set/Operate Method | 1) Select ST-LIPS4. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-LIPS4. | |
| Display/Adj/Set Range | When operation finished normally: OK! | |
| Default Value | According to the setting at shipment | |
| TR-LIPS4 | 2 | Trns license key dspl of LIPS4 func: JP |
| Detail | To display transfer license key to use LIPS4 function (JP only) when disabling and then transferring the license. | |
| Use Case | - When replacing HDD - When replacing the device | |
| Adj/Set/Operate Method | 1) Select ST-LIPS4. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-LIPS4. | |
| Display/Adj/Set Range | 24 digits | |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|-------------------------------|----------|--|
| ST-PSPCL | 2 | Install state dspl of PS/PCL function |
| Detail | | To display installation state of PS/PCL function when disabling and then transferring the license. |
| Use Case | | When checking whether PS/PCL function is installed |
| Adj/Set/Operate Method | | 1) Select ST-PSPCL. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-PSPCL. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-PSPCL | 2 | Transfer license key dspl of PS/PCL func |
| Detail | | To display transfer license key to use PS/PCL function when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-PSPCL. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-PSPCL. |
| Display/Adj/Set Range | | 24 digits |
| ST-PCLUF | 2 | Install state dspl: PCL/UFR II function |
| Detail | | To display installation state of PCL/UFR II function when disabling and then transferring the license. |
| Use Case | | When checking whether PCL/UFR II function is installed |
| Adj/Set/Operate Method | | 1) Select ST-PCLUF. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-PCLUF. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-PCLUF | 2 | Trns license key dspl of PCL/UFR II func |
| Detail | | To display transfer license key to use PCL/UFR II function when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-PCLUF. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-PCLUF. |
| Display/Adj/Set Range | | 24 digits |
| ST-PSLIP | 2 | Install state dspl of PS/LIPS4 func: JP |
| Detail | | To display installation state of PS/LIPS4 function (JP only) when disabling and then transferring the license. |
| Use Case | | When checking whether PS/LIPS4 function (JP only) is installed |
| Adj/Set/Operate Method | | 1) Select ST-PSLIP. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-PSLIP. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|-------------------------------|----------|--|
| TR-PSLIP | 2 | Trns license key dspl: PS/LIPS4 func:JP |
| Detail | | To display transfer license key to use PS/LIPS4 function (JP only) when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-PSLIP. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-PSLIP. |
| Display/Adj/Set Range | | 24 digits |
| ST-PSPCU | 2 | Install state dspl of PS/PCL/UFR II func |
| Detail | | To display installation state of PS/PCL/UFR II function when disabling and then transferring the license. |
| Use Case | | When checking whether PS/PCL/UFR II function is installed |
| Adj/Set/Operate Method | | 1) Select ST-PSPCU. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-PSPCU. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-PSPCU | 2 | Trns lcns key dspl of PS/PCL/UFR II func |
| Detail | | To display transfer license key to use PS/PCL/UFR II function when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-PSPCU. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-PSPCU. |
| Display/Adj/Set Range | | 24 digits |
| ST-LXUFR | 2 | Install state display of UFR II function |
| Detail | | To display installation state of UFR II function when disabling and then transferring the license. |
| Use Case | | When checking whether UFR II function is installed |
| Adj/Set/Operate Method | | 1) Select ST-LXUFR. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-LXUFR. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-LXUFR | 2 | Trns license key dspl of UFR II function |
| Detail | | To display transfer license key to use UFR II function when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-LXUFR. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-LXUFR. |
| Display/Adj/Set Range | | 24 digits |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|-------------------------------|----------|--|
| ST-HDCR2 | 2 | Install state dspl:HDD Init All Data/Set |
| Detail | | To display installation state of HDD Initialize All Data/Settings when disabling and then transferring the license. |
| Use Case | | When checking whether HDD Initialize All Data/Settings is installed |
| Adj/Set/Operate Method | | 1) Select ST-HDCR2. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-HDCR2. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | 0 |
| TR-HDCR2 | 2 | Trns lcns key dspl:HDD Init All Data/Set |
| Detail | | To display transfer license key to use HDD Initialize All Data/Settings when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-HDCR2. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-HDCR2. |
| Display/Adj/Set Range | | 24 digits |
| ST-JBLK | 2 | Install state dspl of Document Scan Lock |
| Detail | | To display installation state of Document Scan Lock when disabling and then transferring the license. |
| Use Case | | When checking whether Document Scan Lock is installed |
| Adj/Set/Operate Method | | 1) Select ST-JBLK. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-JBLK. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | 0 |
| TR-JBLK | 2 | Trns lcns key dspl of Document Scan Lock |
| Detail | | To display transfer license key to use Document Scan Lock when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-JBLK. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-JBLK. |
| Display/Adj/Set Range | | 24 digits |
| ST-AFAX | 2 | Installation state display of Remote Fax |
| Detail | | To display installation state of remote fax client function when disabling and then transferring the license. |
| Use Case | | When checking whether Remote Fax is installed |
| Adj/Set/Operate Method | | 1) Select ST-AFAX. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-AFAX. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|-------------------------------|----------|--|
| TR-AFAX | 2 | Transfer license key dspl of Remote Fax |
| Detail | | To display transfer license key to use Remote Fax when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-AFAX. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-AFAX. |
| Display/Adj/Set Range | | 24 digits |
| ST-REPDF | 2 | Install state dspl:Reader Extensions PDF |
| Detail | | To display installation state of Reader Extensions PDF when disabling and then transferring the license. |
| Use Case | | When checking whether Reader Extensions PDF is installed |
| Adj/Set/Operate Method | | 1) Select ST-REPDF. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-REPDF. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-REPDF | 2 | Trns lcns key dspl:Reader Extensions PDF |
| Detail | | To display transfer license key to use Reader Extensions PDF when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-REPDF. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-REPDF. |
| Display/Adj/Set Range | | 24 digits |
| ST-OOXML | 2 | Install state display of Office Open XML |
| Detail | | To display installation state of Office Open XML when disabling and then transferring the license. |
| Use Case | | When checking whether Office Open XML is installed |
| Adj/Set/Operate Method | | 1) Select ST-OOXML. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-OOXML. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-OOXML | 2 | Trns lcns key display of Office Open XML |
| Detail | | To display transfer license key to use Office Open XML when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-OOXML. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-OOXML. |
| Display/Adj/Set Range | | 24 digits |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|-------------------------------|----------|--|
| ST-XPS | 2 | Install state dspl of Direct Print XPS |
| Detail | | To display installation state of Direct Print XPS when disabling and then transferring the license. |
| Use Case | | When checking whether Direct Print XPS is installed |
| Adj/Set/Operate Method | | 1) Select ST-XPS. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-XPS. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-XPS | 2 | Trns lcns key dspl of Direct Print XPS |
| Detail | | To display transfer license key to use Direct Print XPS when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-XPS. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-XPS. |
| Display/Adj/Set Range | | 24 digits |
| ST-2600 | 2 | Instal state dspl: IEEEE2600.1 scrty func |
| Detail | | To display installation state of the IEEEE2600.1 security function when disabling and then transferring the license. |
| Use Case | | When checking whether the IEEEE2600.1 security function is installed |
| Adj/Set/Operate Method | | 1) Select ST-2600. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-2600. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-2600 | 2 | Trn lcns key dspl: IEEEE2600.1 scrty func |
| Detail | | To display transfer license key to use IEEEE2600.1 security function when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-2600. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-2600. |
| Display/Adj/Set Range | | 24 digits |
| ST-OPFNT | 2 | Install state display of PCL Font Set |
| Detail | | To display installation state of PCL Font Set when disabling and then transferring the license. |
| Use Case | | When checking whether PCL Font Set is installed |
| Adj/Set/Operate Method | | 1) Select ST-OPFNT. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-OPFNT. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|-------------------------------|----------|--|
| TR-OPFNT | 2 | Trns license key display of PCL Font Set |
| Detail | | To display transfer license key to use the PCL Font Set when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-OPFNT. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-OPFNT. |
| Display/Adj/Set Range | | 24 digits |
| ST-NCAPT | 2 | Install state display of NetCap function |
| Detail | | To display installation state of network packet capture function when disabling and then transferring the license. |
| Use Case | | When checking whether network packet capture function is installed |
| Adj/Set/Operate Method | | 1) Select ST-NCAPT. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-NCAPT. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | 0 |
| TR-NCAPT | 2 | Transfer license key dspl of NetCap func |
| Detail | | To display transfer license key to use the network packet capture function when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-NCAPT. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-NCAPT. |
| Display/Adj/Set Range | | 24 digits |
| ST-IPFAX | 2 | Installation state display of IPFAX |
| Detail | | To display installation state of IPFAX when disabling and then transferring the license. |
| Use Case | | When checking whether IPFAX is installed |
| Adj/Set/Operate Method | | 1) Select ST-IPFAX. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-IPFAX. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-IPFAX | 2 | Transfer license key dspl of IPFAX |
| Detail | | To display transfer license key to use IPFAX when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-IPFAX. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-IPFAX. |
| Display/Adj/Set Range | | 24 digits |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|----------------------------------|----------|---|
| ST-U-RDS | 2 | Install state display of E-RDS function |
| Detail | | To display installation state of Embedded-RDS function when disabling and then transferring the license. |
| Use Case | | When checking whether Embedded-RDS function is installed |
| Adj/Set/Operate Method | | 1) Select ST-U-RDS. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-U-RDS. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| Related Service Mode | | COPIER> FUNCTION> INSTALL> E-RDS |
| TR-U-RDS | 2 | Trns license key dspl of E-RDS function |
| Detail | | To display transfer license key to use Embedded-RDS function when disabling and then transferring the license. |
| Use Case | | - When replacing the HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-U-RDS. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-U-RDS. |
| Display/Adj/Set Range | | 24 digits |
| ST-SMLG | 2 | Install state dspl of picture login func |
| Detail | | To display installation state of picture login function when disabling and then transferring the license. |
| Use Case | | When checking whether picture login function is installed |
| Adj/Set/Operate Method | | 1) Select ST-SMLG. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-SMLG. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-SMLG | 2 | Trns lcns key dspl: picture login func |
| Detail | | To display transfer license key to use picture login function when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-SMLG. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-SMLG. |
| Display/Adj/Set Range | | 24 digits |
| ST-TCFNT | 2 | Inst state dspl:PCL Asian Font, trad CHI |
| Detail | | To display installation state of PCL Asian Font (traditional Chinese) when disabling and then transfer the license. |
| Use Case | | When checking whether PCL Asian Font (traditional Chinese) is installed |
| Adj/Set/Operate Method | | 1) Select ST-TCFNT. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-TCFNT. |
| Caution | | When replacing the HDD, check that "PCL Traditional Chinese Fonts" and "PCL Traditional Chinese Fonts (HKSCS)" are installed with [Font List] in [Settings/Registration]. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| Additional Functions Mode | | Function Settings> Printer> Output Report> PCL> Font List |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > LCNS-TR

| | | |
|----------------------------------|----------|--|
| TR-TCFNT | 2 | Trn lic key dspl:PCL Asian Font,trad CHI |
| Detail | | To display transfer license key to use PCL Asian Font (traditional Chinese) when disabling and then transferring the license. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-TCFNT. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-TCFNT. |
| Display/Adj/Set Range | | 24 digits |
| Additional Functions Mode | | Function Settings> Printer> Output Report> PCL> Font List |
| TR-FRWEB | 2 | Trn lcns key dspl:Web Access SW,free ver |
| Detail | | To display transfer license key to use the free version of Web Access Software when disabling and then transferring the license of it. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-FRWEB. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-FRWEB. |
| Display/Adj/Set Range | | 24 digits |
| ST-FRWEB | 2 | Instl state dspl:Web Access SW, free ver |
| Detail | | To display installation state of the free version of Web Access Software when disabling and then transferring the license of it. |
| Use Case | | When checking whether the free version of Web Access Software is installed |
| Adj/Set/Operate Method | | 1) Select ST-FRWEB. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-FRWEB. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| ST-HCD | 2 | Inst state dspl: IEEE2600 Security Kit |
| Detail | | To display installation state of Security Kit for IEEE2600 when disabling and then transferring the license. |
| Use Case | | When checking whether the Security Kit for IEEE2600 is installed |
| Adj/Set/Operate Method | | 1) Select ST-HCD. 2) Enter 0, and then press OK key. When installation has been completed, the transfer license key is displayed under TR-HCD. |
| Display/Adj/Set Range | | When operation finished normally: OK! |
| Default Value | | According to the setting at shipment |
| TR-HCD | 2 | Trn lcns key dspl: IEEE2600 Security Kit |
| Detail | | To display transfer license key to use the Security Kit for IEEE2600 when disabling and then transferring the license of it. |
| Use Case | | - When replacing HDD - When replacing the device |
| Adj/Set/Operate Method | | 1) Select ST-HCD. 2) Enter 0, and then press OK key. The transfer license key is displayed under TR-HCD. |
| Display/Adj/Set Range | | 24 digits |
| Default Value | | 0 |

■ CUSTOM2

COPIER (Service mode for printer) > OPTION (Specification setting mode) > CUSTOM2

| | | |
|--------|---|---------------------|
| SP-B01 | 2 | [For customization] |
| SP-B02 | 2 | [For customization] |
| SP-B03 | 2 | [For customization] |
| SP-B04 | 2 | [For customization] |
| SP-B05 | 2 | [For customization] |
| SP-B06 | 2 | [For customization] |
| SP-B07 | 2 | [For customization] |
| SP-B08 | 2 | [For customization] |
| SP-B09 | 2 | [For customization] |
| SP-B10 | 2 | [For customization] |
| SP-B11 | 2 | [For customization] |
| SP-B12 | 2 | [For customization] |
| SP-B13 | 2 | [For customization] |
| SP-B14 | 2 | [For customization] |
| SP-B15 | 2 | [For customization] |
| SP-B16 | 2 | [For customization] |
| SP-B17 | 2 | [For customization] |
| SP-B18 | 2 | [For customization] |
| SP-B19 | 2 | [For customization] |
| SP-B20 | 2 | [For customization] |
| SP-B21 | 2 | [For customization] |
| SP-B22 | 2 | [For customization] |
| SP-B23 | 2 | [For customization] |
| SP-B24 | 2 | [For customization] |
| SP-B25 | 2 | [For customization] |
| SP-B26 | 2 | [For customization] |
| SP-B27 | 2 | [For customization] |
| SP-B28 | 2 | [For customization] |
| SP-B29 | 2 | [For customization] |
| SP-B30 | 2 | [For customization] |
| SP-B31 | 2 | [For customization] |
| SP-B32 | 2 | [For customization] |
| SP-B33 | 2 | [For customization] |
| SP-B34 | 2 | [For customization] |
| SP-B35 | 2 | [For customization] |
| SP-B36 | 2 | [For customization] |
| SP-B37 | 2 | [For customization] |
| SP-B38 | 2 | [For customization] |
| SP-B39 | 2 | [For customization] |
| SP-B40 | 2 | [For customization] |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > CUSTOM2

| | | |
|--------|---|---------------------|
| SP-B41 | 2 | [For customization] |
| SP-B42 | 2 | [For customization] |
| SP-B43 | 2 | [For customization] |
| SP-B44 | 2 | [For customization] |
| SP-B45 | 2 | [For customization] |
| SP-B46 | 2 | [For customization] |
| SP-B47 | 2 | [For customization] |
| SP-B48 | 2 | [For customization] |
| SP-B49 | 2 | [For customization] |
| SP-B50 | 2 | [For customization] |
| SP-B51 | 2 | [For customization] |
| SP-B52 | 2 | [For customization] |
| SP-B53 | 2 | [For customization] |
| SP-B54 | 2 | [For customization] |
| SP-B55 | 2 | [For customization] |
| SP-B56 | 2 | [For customization] |
| SP-B57 | 2 | [For customization] |
| SP-B58 | 2 | [For customization] |
| SP-B59 | 2 | [For customization] |
| SP-B60 | 2 | [For customization] |
| SP-B61 | 2 | [For customization] |
| SP-B62 | 2 | [For customization] |
| SP-B63 | 2 | [For customization] |
| SP-B64 | 2 | [For customization] |
| SP-B65 | 2 | [For customization] |
| SP-B66 | 2 | [For customization] |
| SP-B67 | 2 | [For customization] |
| SP-B68 | 2 | [For customization] |
| SP-B69 | 2 | [For customization] |
| SP-B70 | 2 | [For customization] |
| SP-B71 | 2 | [For customization] |
| SP-B72 | 2 | [For customization] |
| SP-B73 | 2 | [For customization] |
| SP-B74 | 2 | [For customization] |
| SP-B75 | 2 | [For customization] |
| SP-B76 | 2 | [For customization] |
| SP-B77 | 2 | [For customization] |
| SP-B78 | 2 | [For customization] |
| SP-B79 | 2 | [For customization] |
| SP-B80 | 2 | [For customization] |
| SP-V01 | 2 | [For customization] |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > CUSTOM2

| | | |
|--------|---|---------------------|
| SP-V02 | 2 | [For customization] |
| SP-V03 | 2 | [For customization] |
| SP-V04 | 2 | [For customization] |
| SP-V05 | 2 | [For customization] |
| SP-V06 | 2 | [For customization] |
| SP-V07 | 2 | [For customization] |
| SP-V08 | 2 | [For customization] |
| SP-V09 | 2 | [For customization] |
| SP-V10 | 2 | [For customization] |
| SP-V11 | 2 | [For customization] |
| SP-V12 | 2 | [For customization] |
| SP-V13 | 2 | [For customization] |
| SP-V14 | 2 | [For customization] |
| SP-V15 | 2 | [For customization] |
| SP-V16 | 2 | [For customization] |
| SP-V17 | 2 | [For customization] |
| SP-V18 | 2 | [For customization] |
| SP-V19 | 2 | [For customization] |
| SP-V20 | 2 | [For customization] |
| SP-V21 | 2 | [For customization] |
| SP-V22 | 2 | [For customization] |
| SP-V23 | 2 | [For customization] |
| SP-V24 | 2 | [For customization] |
| SP-V25 | 2 | [For customization] |
| SP-V26 | 2 | [For customization] |
| SP-V27 | 2 | [For customization] |
| SP-V28 | 2 | [For customization] |
| SP-V29 | 2 | [For customization] |
| SP-V30 | 2 | [For customization] |
| SP-V31 | 2 | [For customization] |
| SP-V32 | 2 | [For customization] |
| SP-V33 | 2 | [For customization] |
| SP-V34 | 2 | [For customization] |
| SP-V35 | 2 | [For customization] |
| SP-V36 | 2 | [For customization] |
| SP-V37 | 2 | [For customization] |
| SP-V38 | 2 | [For customization] |
| SP-V39 | 2 | [For customization] |
| SP-V40 | 2 | [For customization] |
| SP-V41 | 2 | [For customization] |
| SP-V42 | 2 | [For customization] |

COPIER (Service mode for printer) > OPTION (Specification setting mode) > CUSTOM2

| | | |
|--------|---|---------------------|
| SP-V43 | 2 | [For customization] |
| SP-V44 | 2 | [For customization] |
| SP-V45 | 2 | [For customization] |
| SP-V46 | 2 | [For customization] |
| SP-V47 | 2 | [For customization] |
| SP-V48 | 2 | [For customization] |
| SP-V49 | 2 | [For customization] |
| SP-V50 | 2 | [For customization] |
| SP-V51 | 2 | [For customization] |
| SP-V52 | 2 | [For customization] |
| SP-V53 | 2 | [For customization] |
| SP-V54 | 2 | [For customization] |
| SP-V55 | 2 | [For customization] |
| SP-V56 | 2 | [For customization] |
| SP-V57 | 2 | [For customization] |
| SP-V58 | 2 | [For customization] |
| SP-V59 | 2 | [For customization] |
| SP-V60 | 2 | [For customization] |
| SP-V61 | 2 | [For customization] |
| SP-V62 | 2 | [For customization] |
| SP-V63 | 2 | [For customization] |
| SP-V64 | 2 | [For customization] |
| SP-V65 | 2 | [For customization] |
| SP-V66 | 2 | [For customization] |
| SP-V67 | 2 | [For customization] |
| SP-V68 | 2 | [For customization] |
| SP-V69 | 2 | [For customization] |
| SP-V70 | 2 | [For customization] |
| SP-V71 | 2 | [For customization] |
| SP-V72 | 2 | [For customization] |
| SP-V73 | 2 | [For customization] |
| SP-V74 | 2 | [For customization] |
| SP-V75 | 2 | [For customization] |
| SP-V76 | 2 | [For customization] |
| SP-V77 | 2 | [For customization] |
| SP-V78 | 2 | [For customization] |
| SP-V79 | 2 | [For customization] |
| SP-V80 | 2 | [For customization] |

TEST (Print test mode)

■ PG

COPIER (Service mode for printer) > TEST (Print test mode) > PG

| | | |
|-------------------------------|----------|--|
| TYPE | 1 | Test print |
| Detail | | To execute the test print. |
| Use Case | | At trouble analysis |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Press Start key. Test print is executed. |
| Caution | | Be sure to return the value to 0 after the test print output. |
| Display/Adj/Set Range | | 0 to 50 0: Normal print 1: Grid 2: 17 gradations Tbic rank 2 3: 17 gradations 600 dpi (134-line screen or 141-line screen) 4: Solid white 5: Halftone (density: 80H, Tbic rank 2, without image correction) 6: Halftone (density: 80H, 134-line screen or 141-line screen, without image correction) 7: Solid black 8: Horizontal line (4 dots, 27 spaces) 9: Horizontal line (6 dots, 50 spaces) 10: Horizontal line (2 dots, 3 spaces) 11: Halftone (density: 60H, Tbic rank 2, without image correction) 12: Halftone (density: 80H, 134-line screen or 141-line screen, without image correction) 13: Halftone (density: 30H, Tbic rank 2, without image correction) 14: Halftone (density: 30H, 134-line screen or 141-line screen, without image correction) 15 to 50: For development |
| Default Value | | 0 |
| TXPH | 1 | [Not used] |
| DENS-K | 1 | Adj of Bk-color density at test print |
| Detail | | To adjust Bk color density when performing test print (TYPE=5). As the greater value is set, the image gets darker. |
| Use Case | | At test print (TYPE=5) |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 1 to 25 |
| Default Value | | 1 |
| PG-PICK | 1 | Setting of test print Pickup Cassette |
| Detail | | To set the Pickup Cassette for test print output. |
| Use Case | | - At problem analysis - At test print output |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 1 to 8 1: Cassette 1, 2: Cassette 2, 3: Cassette 3, 4: Cassette 4, 5: Multi-purpose Tray, 6 to 8: Not used |
| Default Value | | 0 |
| 2-SIDE | 1 | Setting of PG 2-sided mode |
| Detail | | To set 1-sided/2-sided print for PG output. |
| Use Case | | At trouble analysis |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 1 0: 1-sided, 1: 2-sided |
| Default Value | | 0 |

COPIER (Service mode for printer) > TEST (Print test mode) > PG

| PG-QTY | 1 | Setting of PG output quantity |
|----------------------------------|----------|---|
| Detail | | To set the number of sheets for PG output. |
| Use Case | | At trouble analysis |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 1 to 999 |
| Unit | | sheet |
| Default Value | | 1 |
| Amount of Change per Unit | | 1 |
| FINISH | 1 | Accessory processing function test print |
| Detail | | To execute the test print relating to accessory processing function. |
| Use Case | | When checking operation of accessory processing function |
| Adj/Set/Operate Method | | 1) Enter the number of sheets for PG-QTY, and then press OK key. 2) Enter the setting value, and then press OK key. 3) Press Start button. The machine outputs a test print. |
| Display/Adj/Set Range | | 0 to 99 0: N/A 1: Staple (Finisher, front) Any values other than those mentioned above: Not used |
| Default Value | | 0 |
| Related Service Mode | | COPIER> TEST> PG> PG-QTY |

■ NETWORK

COPIER (Service mode for printer) > TEST (Print test mode) > NETWORK

| PING | 1 | Network connection check |
|-------------------------------|----------|--|
| Detail | | To check connection between this machine and TCP/IP network. |
| Use Case | | - When checking network connection at the time of installation - At network connection failure |
| Adj/Set/Operate Method | | 1) Turn OFF the main power switch. 2) Connect the network cable to this machine, and then turn ON the main power switch. 3) Inform the system administrator at user's site that installation of this machine is complete, and ask for network setting. 4) Ask the system administrator to check the network connection, and check the remote host address of PING transmission target. 5) Select the item and enter the remote host address, and then press OK key and Start key. OK: Connection is normal. Checking procedure is complete. NG: Connection failed. Go to step 6) if the cable connection is OK. In case of cable connection failure, connect again and then go to step 5). 6) Select the item and enter loopback address, and then press OK key and Start key. OK: TCP/IP setting of this machine is normal. Go to step 7) to check NIC. NG: TCP/IP setting of this machine has failure. Go to step 3) to check the setting again. 7) Select the item and enter the local host address, and then press OK key. OK: Network setting of this machine and NIC are normal. Inform the system administrator that the trouble is due to network environment and ask for countermeasure. NG: Connection failure/fault with NIC. Check connection of NIC/ replace NIC. |
| Display/Adj/Set Range | | 0.0.0.0 to 255.255.255.255 At normal state: OK, At failure occurrence: NG |
| Supplement/Memo | | - Remote host address: IP address of PC terminal in network. - Loopback address: 127.0.0.1. Checking TCP/IP of this machine is available because the signal is returned before NIC. - NIC: Network interface - Local host address: IP address of this machine |

COPIER (Service mode for printer) > TEST (Print test mode) > NETWORK

| | | |
|-------------------------------|----------|---|
| BML-DISP | 2 | Set System Monitor scrn: BMLinks support |
| Detail | | To set whether to display only the device configuration in the System Monitor screen when supporting BMLinks. When the setting is switched, the job status and logs are not displayed. |
| Use Case | | When supporting BMLinks |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 1 0: Ordinary System Monitor screen, 1: Screen in which only the device configuration is displayed |
| Default Value | | 0 |
| IPv6-ADR | 1 | Setting of PING send address (IPv6) |
| Detail | | To set the IPv6 address to send PING. When PING is sent to this address by COPIER> TEST> NETWORK> PING-IP6, the network connection condition in the IPv6 environment can be checked. |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Caution | | - Enter a consistent character string as an address of IPv6. - Enter an address within 39 characters including hexadecimal numbers (0-9, a-f) and a separator (:). |
| Related Service Mode | | COPIER> TEST> NETWORK> PING-IP6 |
| PING-IP6 | 1 | PING transmission to IPv6 address |
| Detail | | To send PING to the address specified by IPv6-ADR. The network connection condition in the IPv6 environment can be checked. |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Related Service Mode | | COPIER> TEST> NETWORK> IPv6-ADR |

■ NET-CAP

COPIER (Service mode for printer) > TEST (Print test mode) > NET-CAP

| | | |
|----------------------------------|----------|---|
| CAPOFFON | 2 | ON/OFF of NetCap function |
| Detail | | To set ON/OFF of network packet capture function. |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 1 0: OFF, 1: ON |
| Default Value | | 0 |
| Related Service Mode | | COPIER> TEST> NET-CAP |
| Additional Functions Mode | | Store Network Packet Log |
| STT-STP | 2 | Start and stop of network packet capture |
| Detail | | To start and stop network packet capture. |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 1 0: Stop, 1: Start |
| Default Value | | 0 |
| Related Service Mode | | COPIER> TEST> NET-CAP |
| Additional Functions Mode | | Store Network Packet Log |

COPIER (Service mode for printer) > TEST (Print test mode) > NET-CAP

| | | |
|----------------------------------|--|--|
| CAPSTATE | 2 | State display of network packet capture |
| Detail | To display the state of network packet capture. | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Related Service Mode | COPIER> TEST> NET-CAP | |
| Additional Functions Mode | Store Network Packet Log | |
| PONSTART | 2 | Set network packet capture start timing |
| Detail | To set whether to perform network packet capture from power-on. | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: OFF, 1: ON | |
| Default Value | 0 | |
| Related Service Mode | COPIER> TEST> NET-CAP | |
| Additional Functions Mode | Store Network Packet Log | |
| OVERWRIT | 2 | Setting of NetCap data overwriting |
| Detail | To set whether to finish network capturing or overwrite when HDD becomes full. | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: No overwriting (finish network packet capture), 1: Overwriting | |
| Default Value | 1 | |
| Related Service Mode | COPIER> TEST> NET-CAP | |
| Additional Functions Mode | Store Network Packet Log | |
| PAYLOAD | 2 | Set network packet capture data save |
| Detail | To set whether to discard payload when saving the captured packet data. | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Save captured packet data as is, 1: Discard payload and save the packet data | |
| Default Value | 0 | |
| Related Service Mode | COPIER> TEST> NET-CAP | |
| Additional Functions Mode | Store Network Packet Log | |
| FILE-CLR | 2 | Deletion of network packet capture data |
| Detail | To delete the captured packet data. | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| SIMPFLT | 2 | Settings of packet data filtering |
| Detail | To set whether to perform filtering when capturing packet data. When 0 is set, filtering is not performed (All the data are captured.) When 1 is set, packet data is captured only when the receiver's or sender's address coincides with the Mac address of this machine. | |
| Use Case | At problem analysis (at packet data analysis) | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Not filtered, 1: Filtered | |

COPIER (Service mode for printer) > TEST (Print test mode) > NET-CAP

| ENCDATA | 2 | Setting of packet data encryption |
|-------------------------------|---|---|
| Detail | | To set whether to encrypt the packet data when writing the captured packet data to the USB flash drive. |
| Use Case | | - At problem analysis (at packet data analysis) - When improving security of written packet data |
| Adj/Set/Operate Method | | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. |
| Caution | | This setting is enabled only when writing data to the USB flash drive. Even when the packet data is loaded using SST, the file is specified, therefore the setting is disabled. |
| Display/Adj/Set Range | | 0 to 2 0: Encrypted (encrypted file) 1: Not encrypted (plain text file) 2: Encrypted (encrypted file + plain text file) |
| Default Value | | 0 |
| CAPIF | 2 | Setting of network packet capture target |
| Detail | | To set the network interface to capture the packet data. Make this setting before starting network packet capture. |
| Use Case | | When changing the target of network packet capture |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 1 to 5 1: Local loopback, 2: Wired LAN, 3: Wireless LAN, 4: Wireless Soft AP mode, 5: Wi-Fi direct |
| Default Value | | 2 |
| Related Service Mode | | COPIER> TEST> NET-CAP |

COUNTER (Counter mode)

■ TOTAL

COPIER (Service mode for printer) > COUNTER (Counter mode) > TOTAL

| SERVICE1 | 1 | Service-purposed total counter 1 |
|-------------------------------|---|--|
| Detail | | To count up when the printout is delivered outside the machine. Large size: 1, Small size: 1 A blank sheet is not counted. |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 0 to 99999999 |
| SERVICE2 | 1 | Service-purposed total counter 2 |
| Detail | | To count up when the printout is delivered outside the machine. Large size: 2, Small size: 1 A blank sheet is not counted. |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 0 to 99999999 |
| COPY | 1 | Total copy counter |
| Detail | | To count up when the printout is delivered outside the machine. Large size: 1, Small size: 1 A blank sheet is not counted. |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 0 to 99999999 |

COPIER (Service mode for printer) > COUNTER (Counter mode) > TOTAL

| | | |
|------------------------------|----------|---|
| PDL-PRT | 1 | PDL print counter |
| Detail | | To count up when the printout is delivered outside the machine according to the charge counter at PDL print. Large size: 1, Small size: 1 A blank sheet is not counted. |
| Display/Adj/Set Range | | 0 to 99999999 |
| FAX-PRT | 1 | FAX reception print counter |
| Detail | | To count up when the printout is delivered outside the machine according to the charge counter at FAX reception. Large size: 1, Small size: 1 A blank sheet is not counted. |
| Display/Adj/Set Range | | 0 to 99999999 |
| RMT-PRT | 1 | Remote print counter |
| Detail | | To count up when the printout is delivered outside the machine and 2-sided print is stacked according to the charge counter at remote print. Large size: 1, Small size: 1 A blank sheet is not counted. |
| Display/Adj/Set Range | | 0 to 99999999 |
| BOX-PRT | 1 | Inbox print counter |
| Detail | | To count up when the printout is delivered outside the machine according to the charge counter at Inbox print. Large size: 1, Small size: 1 A blank sheet is not counted. |
| Display/Adj/Set Range | | 0 to 99999999 |
| RPT-PRT | 1 | Report print counter |
| Detail | | To count up when the printout is delivered outside the machine according to the charge counter at report print. Large size: 1, Small size: 1 A blank sheet is not counted. |
| Display/Adj/Set Range | | 0 to 99999999 |
| 2-SIDE | 1 | 2-sided copy/print counter |
| Detail | | To count up when the copy/printout is delivered outside the machine according to the charge counter at 2-sided copy/print. Large size: 1, Small size: 1 A blank sheet is not counted. |
| Display/Adj/Set Range | | 0 to 99999999 |
| SCAN | 1 | Scan counter |
| Detail | | To count the number of scan operations according to the charge counter when the scanning operation is complete. Large size: 1, Small size: 1 |
| Display/Adj/Set Range | | 0 to 99999999 |

■ PICK-UP

COPIER (Service mode for printer) > COUNTER (Counter mode) > PICK-UP

| | | |
|---------------|----------|--|
| C1 | 1 | Cassette 1 pickup total counter |
| Detail | | Small size: 1 |
| Unit | | sheet |
| C2 | 1 | Cassette 2 pickup total counter |
| Detail | | Small size: 1 |
| Unit | | sheet |

COPIER (Service mode for printer) > COUNTER (Counter mode) > PICK-UP

| | | |
|---------------|--|--|
| C3 | 1 | Cassette 3 pickup total counter |
| Detail | Total pickup counter value of the Cassette 3 Large size: 1, Small size: 1 | |
| Unit | sheet | |
| C4 | 1 | Cassette 4 pickup total counter |
| Detail | Total pickup counter value of the Cassette 4 Large size: 1, Small size: 1 | |
| Unit | sheet | |
| MF | 1 | Multi-purpose Tray pickup total counter |
| Detail | Total pickup counter value of the Multi-purpose Tray Large size: 1, Small size: 1 | |
| Unit | sheet | |
| 2-SIDE | 1 | 2-sided pickup total counter |
| Detail | Total pickup counter value of 2-sided print Large size: 1, Small size: 1 | |
| Unit | sheet | |

■ FEEDER

COPIER (Service mode for printer) > COUNTER (Counter mode) > FEEDER

| | | |
|----------------------------------|--|---|
| FEED | 1 | DADF original pickup total counter |
| Detail | DADF original pickup total counter | |
| Use Case | When checking the total counter of original pickup by DADF | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Default Value | 0 | |
| Amount of Change per Unit | 1 | |
| DFOP-CNT | 1 | DADF hinge open/close counter |
| Detail | DADF hinge open/close counter | |
| Use Case | When checking the DADF hinge open/close counter | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | time | |
| Default Value | 0 | |
| Amount of Change per Unit | 1 | |

■ JAM

COPIER (Service mode for printer) > COUNTER (Counter mode) > JAM

| | | |
|----------------------------------|--|---------------------------------------|
| TOTAL | 1 | Host machine total jam counter |
| Detail | Total number of jam occurrences in the host machine | |
| Use Case | When checking the total jam counter of the host machine | |
| Adj/Set/Operate Method | To clear the counter value: Select the item, and then press Clear key. | |
| Unit | time | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > COUNTER (Counter mode) > JAM

| | | |
|----------------------------------|----------|--|
| FEEDER | 1 | DADF total jam counter |
| Detail | | Total number of jam occurrences in the DADF |
| Use Case | | When checking the total jam counter of feeder |
| Adj/Set/Operate Method | | To clear the counter value: Select the item, and then press Clear key. |
| Unit | | time |
| Amount of Change per Unit | | 1 |
| SORTER | 1 | Finisher total jam counter |
| Detail | | Total number of jam occurrences in the Finisher |
| Use Case | | When checking the total jam counter of finisher |
| Adj/Set/Operate Method | | To clear the counter value: Select the item, and then press Clear key. |
| Unit | | time |
| Amount of Change per Unit | | 1 |
| MF | 1 | Multi-purpose Tray jam counter |
| Detail | | The number of pickup jam occurrences in the Multi-purpose Tray |
| Use Case | | When checking the jam counter of Multi-purpose Tray |
| Adj/Set/Operate Method | | To clear the counter value: Select the item, and then press Clear key. |
| Unit | | time |
| Amount of Change per Unit | | 1 |
| C1 | 1 | Cassette 1 pickup jam counter |
| Detail | | Cassette 1 pickup jam counter |
| Use Case | | When checking the jam counter of machine's Cassette 1 |
| Adj/Set/Operate Method | | To clear the counter value: Select the item, and then press Clear key. |
| Unit | | time |
| Amount of Change per Unit | | 1 |
| C2 | 1 | Cassette 2 pickup jam counter |
| Detail | | Cassette 2 pickup jam counter |
| Use Case | | When checking the jam counter of machine's Cassette 2 |
| Adj/Set/Operate Method | | To clear the counter value: Select the item, and then press Clear key. |
| Unit | | time |
| Amount of Change per Unit | | 1 |
| C3 | 1 | Cassette 3 pickup jam counter |
| Detail | | Cassette 3 pickup jam counter |
| Use Case | | When checking the jam counter of machine's Cassette 3 |
| Adj/Set/Operate Method | | To clear the counter value: Select the item, and then press Clear key. |
| Unit | | time |
| Amount of Change per Unit | | 1 |

COPIER (Service mode for printer) > COUNTER (Counter mode) > JAM

| | | |
|----------------------------------|----------|--|
| C4 | 1 | Cassette 4 pickup jam counter |
| Detail | | Cassette 4 pickup jam counter |
| Use Case | | When checking the jam counter of machine's Cassette 4 |
| Adj/Set/Operate Method | | To clear the counter value: Select the item, and then press Clear key. |
| Unit | | time |
| Amount of Change per Unit | | 1 |

■ MISC

COPIER (Service mode for printer) > COUNTER (Counter mode) > MISC

| | | |
|----------------------------------|----------|---|
| LSR-MTR | 1 | For R&D |
| ALLPW-ON | 1 | Number of DCON PCB power-on times |
| Detail | | Number of power-on times (Non-all-night Power Unit). To count up when power is turned ON (Non-all-night Power Unit). |
| Use Case | | When checking the usage status of the product |
| Unit | | time |
| Default Value | | 0 |
| Amount of Change per Unit | | 1 |
| HDD-ON | 1 | Number of hard disk start-up times |
| Detail | | To count up when power of the hard disk is turned ON. |
| Use Case | | When checking the usage status of the product |
| Unit | | time |
| Default Value | | 0 |
| Amount of Change per Unit | | 1 |
| FIN-PTH | 1 | For R&D |
| FR-STPL | 1 | For R&D |
| MSTP-B | 1 | For R&D |
| MSTPL | 1 | For R&D |
| STPL-2P | 1 | For R&D |
| STPL-F | 1 | For R&D |
| STPL-R | 1 | For R&D |
| SWG-RL | 1 | For R&D |
| FIN-RBLT | 1 | For R&D |

■ DRBL-1

COPIER (Service mode for printer) > COUNTER (Counter mode) > DRBL-1

| | | |
|----------------------------------|--|---|
| TR-ROLL | 1 | Transfer Roller parts counter |
| Detail | Transfer Roller 1st line: Total counter value from the previous replacement 2nd line: Estimated life | |
| Use Case | When checking the consumption level of parts/replacing the parts | |
| Adj/Set/Operate Method | To clear the counter value: Select the item, and then press Clear key. To change the estimated life: Select the item, enter the value, and then press OK key. | |
| Caution | Clear the counter value after replacement. | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Default Value | 0 | |
| Amount of Change per Unit | 1 | |
| C1-SP-RL | 1 | Cassette1 Separation Roller prts counter |
| Detail | 1st line: Total counter value from the previous replacement 2nd line: Estimated life | |
| Use Case | When checking the consumption level of parts/replacing the parts | |
| Adj/Set/Operate Method | To clear the counter value: Select the item, and then press Clear key. To change the estimated life value: Select the item, enter the value, and then press OK key. | |
| Caution | Clear the counter value after replacement. | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Default Value | 0 | |
| Amount of Change per Unit | 1 | |
| C1-FD-RL | 1 | Cassette 1 Feed Roller parts counter |
| Detail | 1st line: Total counter value from the previous replacement 2nd line: Estimated life | |
| Use Case | When checking the consumption level of parts/replacing the parts | |
| Adj/Set/Operate Method | To clear the counter value: Select the item, and then press Clear key. To change the estimated life value: Select the item, enter the value, and then press OK key. | |
| Caution | Clear the counter value after replacement. | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Default Value | 0 | |
| Amount of Change per Unit | 1 | |
| M-SP-RL | 1 | Multi-purpose Tray Sprtn Roll prts cntr |
| Detail | 1st line: Total counter value from the previous replacement 2nd line: Estimated life value | |
| Use Case | When checking the consumption level of parts/replacing the parts | |
| Adj/Set/Operate Method | To clear the counter value: Select the item, and then press Clear key. To change the estimated life value: Select the item, enter the value, and then press OK key. | |
| Caution | Clear the counter value after replacement. | |
| Display/Adj/Set Range | 0 to 99999999 | |

COPIER (Service mode for printer) > COUNTER (Counter mode) > DRBL-1

| M-FD-RL | 1 | Multi-purpose Tray Feed Roll prts cntr |
|----------------------------------|----------|--|
| Detail | | 1st line: Total counter value from the previous replacement 2nd line: Estimated life |
| Use Case | | When checking the consumption level of parts/replacing the parts |
| Adj/Set/Operate Method | | To clear the counter value: Select the item, and then press Clear key. To change the estimated life value: Select the item, enter the value, and then press OK key. |
| Caution | | Clear the counter value after replacement. |
| Display/Adj/Set Range | | 0 to 99999999 |
| Unit | | sheet |
| Default Value | | 0 |
| Amount of Change per Unit | | 1 |

| FX-UNIT | 1 | Fixing Main Unit parts counter |
|-------------------------------|----------|--|
| Detail | | Fixing Main Unit 1st line: Total counter value from the previous replacement 2nd line: Estimated life |
| Use Case | | When checking the consumption level of parts/replacing the parts |
| Adj/Set/Operate Method | | To clear the counter value: Select the item, and then press Clear key. To change the estimated life: Select the item, enter the value, and then press OK key. |
| Caution | | Clear the counter value after replacement. |
| Display/Adj/Set Range | | 0 to 99999999 |
| Unit | | sheet |
| Default Value | | 0 |

■ DRBL-2

COPIER (Service mode for printer) > COUNTER (Counter mode) > DRBL-2

| DF-PU-RL | 1 | ADF Pickup Unit parts counter: DADF |
|----------------------------------|----------|--|
| Detail | | 1st line: Total counter value from the previous replacement 2nd line: Estimated life |
| Use Case | | When checking the consumption level of parts/replacing the parts |
| Adj/Set/Operate Method | | To clear the counter value: Select the item, and then press Clear key. To change the estimated life value: Select the item, enter the value, and then press OK key. |
| Caution | | Clear the counter value after replacement. |
| Display/Adj/Set Range | | 0 to 99999999 |
| Unit | | sheet |
| Default Value | | 0 |
| Supplement/Memo | | Regardless of the read mode (1-sided/2-sided), the counter is advanced every time a sheet is fed. |
| Amount of Change per Unit | | 1 |

COPIER (Service mode for printer) > COUNTER (Counter mode) > DRBL-2

| | | |
|----------------------------------|--|---|
| DF-SP-RL | 1 | Separation Roller parts counter: DADF |
| Detail | Separation Roller (DADF) 1st line: Total counter value from the previous replacement 2nd line: Estimated life | |
| Use Case | When checking the consumption level of parts/replacing the parts | |
| Adj/Set/Operate Method | To clear the counter value: Select the item, and then press Clear key. To change the estimated life: Select the item, enter the value, and then press OK key. | |
| Caution | Clear the counter value after replacement. | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Default Value | 0 | |
| Supplement/Memo | Regardless of the read mode (1-sided/2-sided), the counter is advanced every time a sheet is fed. | |
| Amount of Change per Unit | 1 | |
| C3-SP-RL | 1 | Cassette3 Separation Roller prts counter |
| Detail | Cassette3 Separation Roller 1st line: Total counter value from the previous replacement 2nd line: Estimated life | |
| Use Case | When checking the consumption level of parts/replacing the parts | |
| Adj/Set/Operate Method | To clear the counter value: Select the item, and then press Clear key. To change the estimated life: Select the item, enter the value, and then press OK key. | |
| Caution | Clear the counter value after replacement. | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Default Value | 0 | |
| Amount of Change per Unit | 1 | |
| C3-FD-RL | 1 | Cassette 3 Feed Roller parts counter |
| Detail | Cassette 3 Feed Roller 1st line: Total counter value from the previous replacement 2nd line: Estimated life | |
| Use Case | When checking the consumption level of parts/replacing the parts | |
| Adj/Set/Operate Method | To clear the counter value: Select the item, and then press Clear key. To change the estimated life: Select the item, enter the value, and then press OK key. | |
| Caution | Clear the counter value after replacement. | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Default Value | 0 | |
| Amount of Change per Unit | 1 | |
| C4-SP-RL | 1 | Cassette4 Separation Roller prts counter |
| Detail | Cassette 4 Separation Roller 1st line: Total counter value from the previous replacement 2nd line: Estimated life | |
| Use Case | When checking the consumption level of parts/replacing the parts | |
| Adj/Set/Operate Method | To clear the counter value: Select the item, and then press Clear key. To change the estimated life: Select the item, enter the value, and then press OK key. | |
| Caution | Clear the counter value after replacement. | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Default Value | 0 | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > COUNTER (Counter mode) > DRBL-2

| | | |
|----------------------------------|----------|--|
| C4-FD-RL | 1 | Cassette 4 Feed Roller parts counter |
| Detail | | Cassette 4 Feed Roller 1st line: Total counter value from the previous replacement 2nd line: Estimated life |
| Use Case | | When checking the consumption level of parts/replacing the parts |
| Adj/Set/Operate Method | | To clear the counter value: Select the item, and then press Clear key. To change the estimated life: Select the item, enter the value, and then press OK key. |
| Caution | | Clear the counter value after replacement. |
| Display/Adj/Set Range | | 0 to 99999999 |
| Default Value | | 0 |
| Amount of Change per Unit | | 1 |
| C2-SP-RL | 1 | Cassette2 Separation Roller prts counter |
| Detail | | 1st line: Total counter value from the previous replacement 2nd line: Estimated life |
| Use Case | | When checking the consumption level of parts/replacing the parts |
| Adj/Set/Operate Method | | To clear the counter value: Select the item, and then press Clear key. To change the estimated life: Select the item, enter the value, and then press OK key. |
| Caution | | Clear the counter value after replacement. |
| Display/Adj/Set Range | | 0 to 99999999 |
| Unit | | sheet |
| Default Value | | 0 |
| Amount of Change per Unit | | 1 |
| C2-FD-RL | 1 | Cassette2 Feeding Roller prts counter |
| Detail | | 1st line: Total counter value from the previous replacement 2nd line: Estimated life |
| Use Case | | When checking the consumption level of parts/replacing the parts |
| Adj/Set/Operate Method | | To clear the counter value: Select the item, and then press Clear key. To change the estimated life: Select the item, enter the value, and then press OK key. |
| Caution | | Clear the counter value after replacement. |
| Display/Adj/Set Range | | 0 to 99999999 |
| Unit | | sheet |

■ LF

COPIER (Service mode for printer) > COUNTER (Counter mode) > LF

| | | |
|------------------------------|----------|--|
| FX-LF | 1 | Fixing Ass'y estimated life value |
| Detail | | To display how much the Transfer roller is close to the end of life in percentage (%). |
| Use Case | | When checking the consumption level of parts/replacing the parts |
| Display/Adj/Set Range | | 0 to 99999999 |
| TR-ROLL | 1 | Transfer roller estimated life value |
| Detail | | To display how much the Transfer roller is close to the end of life in percentage (%). |
| Use Case | | When checking the consumption level of parts/replacing the parts |
| Display/Adj/Set Range | | 0 to 99999999 |
| DF-PU-RL | 1 | ADF Pickup Unit estimated life value |
| Detail | | To display how much the ADF Pickup Unit is close to the end of life in percentage (%). |
| Use Case | | When checking the consumption level of parts/replacing the parts |
| Display/Adj/Set Range | | 0 to 99999999 |

COPIER (Service mode for printer) > COUNTER (Counter mode) > LF

| | | |
|------------------------------|----------|--|
| C1-FD-RL | 1 | CST1 Pickup / feed Roll estd life VL |
| Detail | | To display how much the Cassette 1 Pickup / Feed Roller is close to the end of life in percentage (%). |
| Use Case | | When checking the consumption level of parts/replacing the parts |
| Display/Adj/Set Range | | 0 to 99999999 |
| C2-FD-RL | 1 | CST2 Pickup / feed Roll estd life VL |
| Detail | | To display how much the Cassette 1 Pickup / Feed Roller is close to the end of life in percentage (%). |
| Use Case | | When checking the consumption level of parts/replacing the parts |
| Display/Adj/Set Range | | 0 to 99999999 |
| C3-FD-RL | 1 | CST3 Pickup / feed Roll estd life VL |
| Detail | | To display how much the Cassette 1 Pickup / Feed Roller is close to the end of life in percentage (%). |
| Use Case | | When checking the consumption level of parts/replacing the parts |
| Display/Adj/Set Range | | 0 to 99999999 |
| C4-FD-RL | 1 | CST4 Pickup / feed Roll estd life VL |
| Detail | | To display how much the Cassette 1 Pickup / Feed Roller is close to the end of life in percentage (%). |
| Use Case | | When checking the consumption level of parts/replacing the parts |
| Display/Adj/Set Range | | 0 to 99999999 |

■ MISC2

COPIER (Service mode for printer) > COUNTER (Counter mode) > MISC2

| | | |
|-----------------|----------|--------------------|
| APW-TIME | 2 | For R&D |
| CPW-TIME | 2 | For R&D |
| BAT-TIME | 2 | For R&D |
| FUSE-CNT | 2 | For R&D |
| SPW-TIME | 2 | For R&D |

■ PAPER

COPIER (Service mode for printer) > COUNTER (Counter mode) > PAPER

| | | |
|----------------------------------|----------|---|
| G52-59 | 1 | Delivered sheet counter: 52 to 59 g/m2 |
| Detail | | To count up the number of delivered sheets which weight is 52 to 59 g/m2. 1st line: The counter is advanced by 1 for both small size and large size. 2nd line: The counter is advanced by 1 for small size and by 2 for large size. |
| Use Case | | When checking the consumption level of parts based on the number of delivered sheets |
| Adj/Set/Operate Method | | N/A (Display only) |
| Display/Adj/Set Range | | 0 to 99999999 |
| Unit | | sheet |
| Amount of Change per Unit | | 1 |

COPIER (Service mode for printer) > COUNTER (Counter mode) > PAPER

| | | |
|----------------------------------|---|---|
| G60-63 | 1 | Delivered sheet counter: 60 to 63 g/m2 |
| Detail | To count up the number of delivered sheets which weight is 60 to 63 g/m2. 1st line: The counter is advanced by 1 for both small size and large size. 2nd line: The counter is advanced by 1 for small size and by 2 for large size. | |
| Use Case | When checking the consumption level of parts based on the number of delivered sheets | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Amount of Change per Unit | 1 | |
| G64-75 | 1 | Delivered sheet counter: 64 to 75 g/m2 |
| Detail | To count up the number of delivered sheets which weight is 64 to 75 g/m2. 1st line: The counter is advanced by 1 for both small size and large size. 2nd line: The counter is advanced by 1 for small size and by 2 for large size. | |
| Use Case | When checking the consumption level of parts based on the number of delivered sheets | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Amount of Change per Unit | 1 | |
| G76-90 | 1 | Delivered sheet counter: 76 to 90 g/m2 |
| Detail | To count up the number of delivered sheets which weight is 76 to 90 g/m2. 1st line: The counter is advanced by 1 for both small size and large size. 2nd line: The counter is advanced by 1 for small size and by 2 for large size. | |
| Use Case | When checking the consumption level of parts based on the number of delivered sheets | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Amount of Change per Unit | 1 | |
| G91-105 | 1 | Delivered sheet counter: 91 to 105 g/m2 |
| Detail | To count up the number of delivered sheets which weight is 91 to 105 g/m2. 1st line: The counter is advanced by 1 for both small size and large size. 2nd line: The counter is advanced by 1 for small size and by 2 for large size. | |
| Use Case | When checking the consumption level of parts based on the number of delivered sheets | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Amount of Change per Unit | 1 | |
| G106-128 | 1 | Delivered sheet counter: 106 to 128 g/m2 |
| Detail | To count up the number of delivered sheets which weight is 106 to 128 g/m2. 1st line: The counter is advanced by 1 for both small size and large size. 2nd line: The counter is advanced by 1 for small size and by 2 for large size. | |
| Use Case | When checking the consumption level of parts based on the number of delivered sheets | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > COUNTER (Counter mode) > PAPER

| | | |
|----------------------------------|---|---|
| G129-150 | 1 | Delivered sheet counter: 129 to 150 g/m2 |
| Detail | To count up the number of delivered sheets which weight is 129 to 150 g/m2. 1st line: The counter is advanced by 1 for both small size and large size. 2nd line: The counter is advanced by 1 for small size and by 2 for large size. | |
| Use Case | When checking the consumption level of parts based on the number of delivered sheets | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Amount of Change per Unit | 1 | |
| G151-163 | 1 | Delivered sheet counter: 151 to 163 g/m2 |
| Detail | To count up the number of delivered sheets which weight is 151 to 163 g/m2. 1st line: The counter is advanced by 1 for both small size and large size. 2nd line: The counter is advanced by 1 for small size and by 2 for large size. | |
| Use Case | When checking the consumption level of parts based on the number of delivered sheets | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Amount of Change per Unit | 1 | |
| G164-180 | 1 | Delivered sheet counter: 164 to 180 g/m2 |
| Detail | To count up the number of delivered sheets which weight is 164 to 180 g/m2. 1st line: The counter is advanced by 1 for both small size and large size. 2nd line: The counter is advanced by 1 for small size and by 2 for large size. | |
| Use Case | When checking the consumption level of parts based on the number of delivered sheets | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Amount of Change per Unit | 1 | |
| G181-220 | 1 | Delivered sheet counter: 181 to 220 g/m2 |
| Detail | To count up the number of delivered sheets which weight is 181 to 220 g/m2. 1st line: The counter is advanced by 1 for both small size and large size. 2nd line: The counter is advanced by 1 for small size and by 2 for large size. | |
| Use Case | When checking the consumption level of parts based on the number of delivered sheets | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Amount of Change per Unit | 1 | |
| G221-256 | 1 | Delivered sheet counter: 221 to 256 g/m2 |
| Detail | To count up the number of delivered sheets which weight is 221 to 256 g/m2. 1st line: The counter is advanced by 1 for both small size and large size. 2nd line: The counter is advanced by 1 for small size and by 2 for large size. | |
| Use Case | When checking the consumption level of parts based on the number of delivered sheets | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Amount of Change per Unit | 1 | |

COPIER (Service mode for printer) > COUNTER (Counter mode) > PAPER

| | | |
|----------------------------------|--|---|
| G257-300 | 1 | Delivered sheet counter: 257 to 300 g/m2 |
| Detail | To count up the number of delivered sheets which weight is 257 to 300 g/m2. 1st line: The counter is advanced by 1 for both small size and large size. 2nd line: The counter is advanced by 1 for small size and by 2 for large size. | |
| Use Case | When checking the consumption level of parts based on the number of delivered sheets | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Amount of Change per Unit | 1 | |
| G301-325 | 1 | Delivered sheet counter: 301 to 325 g/m2 |
| Detail | To count up the number of delivered sheets which weight is 301 to 325 g/m2. 1st line: The counter is advanced by 1 for both small size and large size. 2nd line: The counter is advanced by 1 for small size and by 2 for large size. | |
| Use Case | When checking the consumption level of parts based on the number of delivered sheets | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Amount of Change per Unit | 1 | |
| G326-350 | 1 | Delivered sheet counter: 326 to 350 g/m2 |
| Detail | To count up the number of delivered sheets which weight is 326 to 350 g/m2. 1st line: The counter is advanced by 1 for both small size and large size. 2nd line: The counter is advanced by 1 for small size and by 2 for large size. | |
| Use Case | When checking the consumption level of parts based on the number of delivered sheets | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Amount of Change per Unit | 1 | |
| G351OVER | 1 | Delivered sheet counter:351 g/m2 or more |
| Detail | To count up the number of delivered sheets which weight is 351 g/m2 or more. 1st line: The counter is advanced by 1 for both small size and large size. 2nd line: The counter is advanced by 1 for small size and by 2 for large size. | |
| Use Case | When checking the consumption level of parts based on the number of delivered sheets | |
| Adj/Set/Operate Method | N/A (Display only) | |
| Display/Adj/Set Range | 0 to 99999999 | |
| Unit | sheet | |
| Amount of Change per Unit | 1 | |

FEEDER (ADF service mode)

DISPLAY (State display mode)

FEEDER (ADF service mode) > DISPLAY (State display mode)

| | | |
|-------------------------------|----------|--|
| FEEDSIZE | 1 | Dspl orgnl size detected by DADF/Cpybrd |
| Detail | | To display the original size detected by the DADF/Copyboard. |
| Use Case | | When checking the paper size recognized by the device after scanning |
| Adj/Set/Operate Method | | N/A (Display only) |

ADJUST (Adjustment mode)

FEEDER (ADF service mode) > ADJUST (Adjustment mode)

| | | |
|----------------------------------|----------|--|
| DOCST | 1 | Adj of DADF img lead edge margin: front |
| Detail | | To adjust the leading edge margin on the front side at DADF reading. Execute this item when the output image after DADF installation is displaced. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of service label. As the value is incremented by 1, the margin is reduced by 0.1 mm. (The image moves upward.) |
| Use Case | | - When installing DADF - When clearing the Reader-related RAM data - When replacing the SATA Flash PCB |
| Adj/Set/Operate Method | | Enter the setting value (switch negative/positive by -/+ key) and press OK key. |
| Display/Adj/Set Range | | -30 to 30 |
| Unit | | mm |
| Default Value | | 0 |
| Amount of Change per Unit | | 0.1 |
| LA-SPEED | 1 | Fine adj img ratio: DADF,vert scan,front |
| Detail | | To make a fine adjustment of the front side image magnification ratio in vertical scanning direction at DADF reading. As the value is incremented by 1, the image is reduced by 0.01% in vertical scanning direction. (The feeding speed increases, and the image is reduced.) |
| Use Case | | - When installing DADF - When replacing the SATA Flash PCB - When replacing the clearing the Reader-related RAM data |
| Adj/Set/Operate Method | | Enter the setting value (switch negative/positive by -/+ key) and press OK key. |
| Display/Adj/Set Range | | -200 to 200 |
| Unit | | % |
| Default Value | | 0 |
| Amount of Change per Unit | | 0.01 |

FEEDER (ADF service mode) > ADJUST (Adjustment mode)

| | | |
|----------------------------------|---|---|
| DOCST2 | 1 | Adj of DADF img lead edge margin: back |
| Detail | To adjust the leading edge margin on the back side at DADF reading. Execute this item when the output image after DADF installation is displaced. When clearing the Reader-related RAM data/replacing the SATA Flash PCB, enter the value of service label. As the value is incremented by 1, the margin is reduced by 0.1 mm. (The image moves upward.) | |
| Use Case | <ul style="list-style-type: none"> - When installing DADF - When clearing the Reader-related RAM data - When replacing the SATA Flash PCB | |
| Adj/Set/Operate Method | Enter the setting value (switch negative/positive by -/+ key) and press OK key. | |
| Display/Adj/Set Range | -30 to 30 | |
| Unit | mm | |
| Default Value | 0 | |
| Amount of Change per Unit | 0.1 | |
| LA-SPD2 | 1 | Fine adj img ratio: DADF,vert scan,back |
| Detail | To make a fine adjustment of the back side image magnification ratio in vertical scanning direction at DADF reading. As the value is incremented by 1, the image is reduced by 0.01% in vertical scanning direction. (The feeding speed increases, and the image is reduced.) | |
| Use Case | <ul style="list-style-type: none"> - When installing DADF - When replacing the SATA Flash PCB - When replacing the clearing the Reader-related RAM data | |
| Adj/Set/Operate Method | Enter the setting value (switch negative/positive by -/+ key) and press OK key. | |
| Display/Adj/Set Range | -200 to 200 (-2.00 to 2.00%) | |
| Unit | % | |
| Default Value | 0 | |
| Amount of Change per Unit | 0.01 | |
| ADJMCSN1 | 1 | Fine adj img ratio:2-sided,horz scan,frt |
| Detail | To make a fine adjustment of the front side image magnification ratio in horizontal scanning direction at DADF 2-sided reading. As the value is incremented by 1, the image is enlarged by 0.1% in horizontal scanning direction. | |
| Use Case | When image magnification ratio on the front side and back side are different at 2-sided reading | |
| Adj/Set/Operate Method | Enter the setting value (switch negative/positive by -/+ key) and press OK key. | |
| Display/Adj/Set Range | -10 to 10 | |
| Unit | % | |
| Default Value | 0 | |
| Amount of Change per Unit | 0.1 | |
| ADJMCSN2 | 1 | Fine adj img ratio:2-sided,horz scan,bck |
| Detail | To make a fine adjustment of the back side image magnification ratio in horizontal scanning direction at DADF 2-sided reading. As the value is incremented by 1, the image is enlarged by 0.1% in horizontal scanning direction. | |
| Use Case | When image magnification ratio on the front side and back side are different at 2-sided reading | |
| Adj/Set/Operate Method | Enter the setting value (switch negative/positive by -/+ key) and press OK key. | |
| Display/Adj/Set Range | -10 to 10 | |
| Unit | % | |
| Default Value | 0 | |
| Amount of Change per Unit | 0.1 | |

FUNCTION (Operation / inspection mode)

FEEDER (ADF service mode) > FUNCTION (Operation / inspection mode)

| | | |
|-------------------------------|---|---|
| MTR-CHK | 1 | Specification of DADF operation motor |
| Detail | To specify the motor of DADF to operate. The motor is activated by MTR-ON. | |
| Use Case | At operation check | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0: ADF Motor (M4201) | |
| Related Service Mode | FEEDER> FUNCTION> MTR-ON | |
| FEED-CHK | 1 | Specify DADF individual feed operation |
| Detail | To specify the feed mode for DADF. Feed operation is activated by FEED-ON. | |
| Use Case | At operation check | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0: 1-sided pickup/delivery operation | |
| Related Service Mode | FEEDER> FUNCTION> FEED-ON | |
| CL-CHK | 1 | Specifying DADF Operation Clutch |
| Detail | To specify the DADF Clutch to be operated. The Clutch is activated by CL-ON. | |
| Use Case | At operation check | |
| Adj/Set/Operate Method | Enter the value, and then press OK key. | |
| Display/Adj/Set Range | 0 to 1 0: ADF Pickup Clutch (CL4200), 1: ADF Registration Clutch (CL4201) | |
| Related Service Mode | FEEDER> FUNCTION> CL-ON | |
| CL-ON | 1 | Operation check of DADF Clutch |
| Detail | To start operation check for the Clutch specified by CL-CHK. - When CL-CHK=0 The ADF Motor (M4201) and the ADF Pickup Clutch (CL4200) are turned ON => The ADF Pickup Roller rotates positively for approx. 1 second => The motor stops after 5 seconds from turning OFF the clutch. - When CL-CHK=1 The ADF Motor (M4201) and the ADF Registration Clutch (CL4201) are turned ON => The ADF Registration Roller rotates positively for approx. 5 seconds => The motor stops after 5 seconds from turning OFF the clutch. | |
| Use Case | At operation check | |
| Adj/Set/Operate Method | 1) Select the item, and then press OK key. The roller stops automatically after positive rotation. 2) Press OK key. The operation check is completed. | |
| Caution | Press OK key again after execution. It stops automatically after approx. 5 sec; however, it does not finish unless OK key is pressed (STOP screen does not appear.) | |
| Related Service Mode | FEEDER> FUNCTION> CL-CHK | |
| FAN-CHK | 1 | Specification of DADF operation fan |
| Detail | To specify the fan of DADF to operate. The fan is activated by FAN-ON. | |
| Use Case | At operation check | |
| Adj/Set/Operate Method | Enter the setting value, and then press OK key. | |
| Display/Adj/Set Range | 0: ADF Cooling Fan (FAN) | |
| Related Service Mode | FEEDER> FUNCTION> FAN-ON | |

FEEDER (ADF service mode) > FUNCTION (Operation / inspection mode)

| | | |
|-------------------------------|----------|--|
| FAN-ON | 1 | Operation check of DADF fan |
| Detail | | To start operation check of the fan specified by FAN-CHK. |
| Use Case | | At operation check |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. It is driven for approximately 5 seconds and is automatically stopped. 2) Press OK key. The operation check is completed. |
| Caution | | Be sure to press the OK key again after execution. The operation automatically stops after approximately 5 seconds, but is not completed unless the OK key is pressed (STOP is not displayed). |
| Related Service Mode | | FEEDER> FUNCTION> FAN-CHK |
| MTR-ON | 1 | Operation check of DADF Motor |
| Detail | | To drive the DADF Motor for approximately 5 seconds. |
| Use Case | | When checking the operation of the DADF Motor |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. It is driven for approximately 5 seconds and is automatically stopped. 2) Press OK key. The operation check is completed. |
| Caution | | Be sure to press the OK key again after execution. The operation automatically stops after approximately 5 seconds, but is not completed unless the OK key is pressed (STOP is not displayed). |
| Display/Adj/Set Range | | During operation: ACTIVE, When operation finished normally: OK! |
| Related Service Mode | | FEEDER> FUNCTION> MTR-CHK |
| ROLL-CLN | 1 | Rotation of DADF rollers |
| Detail | | To rotate the rollers of DADF for cleaning. Check the rollers with lint-free paper moistened with alcohol while they are rotating. |
| Use Case | | When cleaning the rollers |
| Adj/Set/Operate Method | | 1) Select the item, and then press OK key. 2) Clean the rotating rollers with lint-free paper moistened with alcohol. 3) Press OK key. The rollers stop. |
| FEED-ON | 1 | Operation check of DADF individual feed |
| Detail | | To start operation check of the feed mode specified by FEED-CHK. |
| Use Case | | At operation check |
| Adj/Set/Operate Method | | Select the item, and then press OK key. |
| Related Service Mode | | FEEDER> FUNCTION> FEED-CHK |

OPTION (Specification setting mode)

FEEDER (ADF service mode) > OPTION (Specification setting mode)

| | | |
|-------------------------------|----------|---|
| R-ATM | 1 | Set DADF double feed dtct highland mode |
| Detail | | To set the Double Feed Sensor of the DADF to the highland mode. Set 1 if the installation site is above the altitude of 2000 meters. |
| Use Case | | When the installation site is above the altitude of 2000 meters at installation |
| Adj/Set/Operate Method | | Enter the setting value, and then press OK key. |
| Display/Adj/Set Range | | 0 to 1 0: Normal, 1: Highland mode |
| Default Value | | 0 |

FEEDER (ADF service mode) > OPTION (Specification setting mode)

| R-OVLPLV | 2 Set DADF double feed dtct threshold VL |
|-------------------------------|--|
| Detail | To set the threshold value at which the Double Feed Sensor of the DADF judges whether papers are double fed. Decrease the value if single feed of paper is incorrectly detected as double feed. Increase the value if double feed of paper is incorrectly detected as single feed. |
| Use Case | When double feed is incorrectly detected with special paper not defined in the specifications |
| Adj/Set/Operate Method | Enter the setting value (switch negative/positive by +/- key) and press OK key. |
| Caution | In the case of highlands, be sure to set R-ATM in advance. |
| Display/Adj/Set Range | -3 to 3 |
| Default Value | 0 |
| Related Service Mode | FEEDER> OPTION> R-ATM |

BOARD (Option board setting mode)

OPTION (Specification setting mode)

BOARD (Option board setting mode) > OPTION (Specification setting mode)

| | | |
|-------------------------------|---|--|
| MENU-1 | 2 | Hide/dspl of printer set menu level 1 |
| Detail | To set whether to display or hide the level 1 of printer setting menu. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | 0 | |
| MENU-2 | 2 | Hide/dspl of printer set menu level 2 |
| Detail | To set whether to display or hide the level 2 of printer setting menu. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | 0 | |
| MENU-3 | 2 | Hide/dspl of printer set menu level 3 |
| Detail | To set whether to display or hide the level 3 of printer setting menu. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | 0 | |
| MENU-4 | 2 | Hide/dspl of printer set menu level 4 |
| Detail | To set whether to display or hide the level 4 of printer setting menu. | |
| Use Case | Upon user's request | |
| Adj/Set/Operate Method | 1) Enter the setting value, and then press OK key. 2) Turn OFF/ON the main power switch. | |
| Display/Adj/Set Range | 0 to 1 0: Hide, 1: Display | |
| Default Value | 0 | |

FAX (Service Mode for FAX)

Overview

■ Configuration of the Service Mode

Service mode is divided into the following 10 items (#1 to #10).

| Item | Name | Description |
|-------------------|---|---|
| #1 SSSW | Service software switch | This can be used to conduct the registration/settings relating to basic functions of the fax, such as error management, echo prevention and prevention of communication problems. |
| #2 MENU | Menu switch setting | This can be used to conduct the registration/settings relating to the required functions at installation, such as NL equalizer, transmission level. |
| #3 NUMERIC Param. | Setting of numeric parameters | This can be used to enter numeric parameters. |
| #4 NCU | (Adjustment by a service technician is not possible.) | The values of this item are collectively set based on the setting of #5 TYPE. |
| #5 TYPE | Country setting | If the item "STANDARD" displayed on the display is set, #4 NCU data is collectively set to comply with the communication standards in Japan. |
| #6 IPFAX | Communication settings of IPFAX | If the license option for IPFAX has been enabled, IPFAX is displayed. |
| #7 PRINT | Printer function setting | This can be used to conduct the registration/settings relating to the printer basic service functions, such as size reduction conditions for received images. |
| #8 CLEAR | Data initialization mode setting | This item is to initialize each data. |
| #9 TEST | Test Mode | To execute various tests. |
| #10 REPORT | Service Report | To execute report print. |


CAUTION:

If a 2nd line fax option is installed, IPFAX cannot be used.

■ Operation method

1. Enter service mode.

2. When the connected options (FEEDER, SORTER, FAX, BOARD) are displayed, select FAX and enter service mode of this board.




COPIER: Service mode of the connected equipment

FEEDER: Service mode of the ADF (*)

SORTER: Service mode of the Finisher (*)

FAX: Service mode of the fax (*)

The following explains the operation method using the #1 SSSW screen as an example. The meaning of the keys and operations are common for all screens.



- When changing the setting of the bit switch, directly press the bit (numeric value) you want to change.
- To enter a numeric value, use the numeric keypad.
- When confirming a change in a numeric value or when executing an item, press the [OK] key.
- To return to the previous layer, use the [Reset] key.

CAUTION:

When changing the service mode settings, turn OFF and then ON the power.

The details of settings in service mode are stored in the HDD of the host machine. The settings for this board are enabled by loading the settings stored in the HDD of the host machine to the G3 Fax Control PCB when the main power is turned ON. Therefore, be sure to turn OFF and then ON the power when the settings have been changed.

■ Menu List

| | | | |
|------------|--------------|---|-----------------------------------|
| #1 SSSW | SW01 | error management | |
| | SW02 | Not used | |
| | SW03 | set remedy against echo | |
| | SW04 | set remedy against communication error | |
| | SW05 | set standard function <DIS signal> | |
| | SW06 to SW08 | Not used | |
| | SW09 | set communication result display | |
| | SW10 to SW11 | Not used | |
| | SW12 | set page timer | |
| | SW13 | Display of the screen Settings | |
| | SW14 | Inch/mm resolution settings | |
| | SW15 | Not used | |
| | SW17 | Transmission level setting of modem | |
| | SW18 | The control of IP supported communication setting | |
| | SW19 to SW21 | Not used | |
| | SW22 | Settings of archive send function | |
| | SW23 to SW24 | Not used | |
| | SW25 | set report display function | |
| | SW26 | set transmission function | |
| | SW27 | Not used | |
| | SW28 | set V. 8/V. 34 | |
| | SW29 | Not used | |
| | SW30 | Dial tone detection method switching | |
| | SW31 to SW50 | Not used | |
| | #2 MENU | 001 to 004 | Not used |
| | | 005 | NL equalizer |
| | | 006 | line monitor |
| | | 007 | transmission level (ATT) |
| | | 008 | V.34 modulation speed upper limit |
| | | 009 | V.34 data speed upper limit |
| 010 to 020 | | Not used | |
| #3 NUM | 001 | not used | |
| | 002 | RTN transmission condition (1) | |
| | 003 | RTN transmission condition (2) | |
| | 004 | RTN transmission condition (3) | |
| | 005 | NCC pause time (before ID code) | |
| | 006 | NCC pause time (after ID code) | |
| | 007 | pre-pulse time at time of call | |
| | 008 | not used | |
| | 009 | number of characters in telephone numbers between transmitting and receiving parties. | |
| | 010 | line connection identification time | |
| | 011 | T.30 T1 timer (for reception) | |
| | 012 | not used | |
| | 013 | T.30 EOL timer | |
| | 014 | not used | |
| | 015 | hooking detection time | |
| | 016 | Time until a temporary response is obtained when switching FAX/TEL | |
| | 017 | Pseudo RBT signal pattern ON time | |
| | 018 | Pseudo RBT signal pattern ON time (short) | |
| | 019 | Pseudo RBT signal pattern OFF time (long) | |
| | 020 | Pseudo CI signal pattern ON time | |
| | 021 | Pseudo CI signal pattern OFF time (short) | |
| | 022 | Pseudo CI signal pattern OFF (long) | |
| | 023 | CNG detection level when switching FAX/TEL | |
| | 024 | Pseudo RBT transmission level when switching FAX/TEL | |
| | 025 | CNG monitoring time when the answering phone connection function is set | |
| | 026 | Silent detection level when the answering phone connection function is set | |
| | 027 | preamble detection time for V.21 low-speed flag | |
| | 028 | Off-hook PCB duty settings | |
| | 029-80 | not used | |

• SSSW-SW01

Functional Construction

| Bit | Function | 1 | 0 |
|-----|---|----------|-----------------|
| 0 | Error codes for service technician | Output | Do not output |
| 1 | Error dump list | Output | Do not output |
| 2 | Not used | - | - |
| 3 | Not used | - | - |
| 4 | Display service error codes in the ##300 series | Display | Do not display |
| 5 | Increase the capacity of SUBLOG for USBFAX2 | Increase | Do not increase |
| 6 | Not used | - | - |
| 7 | Cancel prohibition of user setting collectively | Cancel | Do not cancel |

Details of Bit 0

Select whether to output service error codes.

When "Output" is selected, service error codes will be on the display and on the report.

Detailed Discussions of Bit 1

Select whether to output error dump list.

When "Output" is selected, the error transmission report and the reception result report at the time of occurrence of an error are output with the error dump list attached.

Detailed Discussions of Bit 4

Select whether to display service error codes in the ##300 series.

Detailed Discussions of Bit 5

Select whether to increase the log storage area when firmware automatic update function of USBFAX2 (a modem with Silicone Labs modem mounted version) is used.

Detailed Discussions of Bit 7

Select whether to collectively cancel the prohibition of user settings.

• SSSW-SW02

Functional Construction

| Bit | Function | 1 | 0 |
|-----|---|-----------|-----------------|
| 0 | Not used | - | - |
| 1 | Not used | - | - |
| 2 | Not used | - | - |
| 3 | Not used | - | - |
| 4 | To prohibit control channel retrain during V.34 | Prohibit | Do not prohibit |
| 5 | Not used | - | - |
| 6 | Not used | - | - |
| 7 | F-NET service without ring tone | Supported | Not supported |

Detailed Discussions of Bit 4

Select whether to prohibit the control channel retrain during V.34.

Detailed Discussions of Bit 7

Select whether to support F-NET (fax communication network) service without a ring tone.

If "Supported" is selected, fax document will be automatically received without a ring tone when FC signal (1300 Hz tonal signal) from F-NET is detected.

• SSSW-SW03

Functional Construction

| Bit | Function | 1 | 0 |
|-----|--|------|-------------|
| 0 | Not used | - | - |
| 1 | Echo protect tone at high speed transmission | Send | Do not send |

| Bit | Function | 1 | 0 |
|-----|---|--------------------------------|--------------------------------|
| 2 | Not used | - | - |
| 3 | Not used | - | - |
| 4 | Transmission mode: International transmission (1) | Yes | No |
| 5 | Transmission mode: International transmission (3) | Yes | No |
| 6 | Send mode | International transmission (3) | International transmission (2) |
| 7 | Tonal signal before sending CED signal | Send | Do not send |

Detailed Discussions of Bit 1

Use it to enable/disable sending an echo protect tone for a high-speed transmission V.29 modem signal (transmission speed at 9600 or 7200 bps).

If errors occur frequently at time of sending fax because of the condition of the line, select "Send". Selecting "send" sends non-modulated carrier for about 200 ms as the synchronous signal before sending images.

NOTE:

Error codes caused by line condition when sending fax
##100, ##104, ##281, ##282, ##283, ##750, ##755, ##760, ##765

Detailed Discussions of Bits 4, 5 and 6

Transmission mode: Selected to use whether international transmission (1), international transmission (2) or international transmission (3).

Use these switches or the dial registration to select a transmission mode if errors occur frequently at time when sending fax overseas.

NOTE:

Error codes caused by echoes at time of sending fax
#005, ##100, ##101, ##102, ##104, ##201, ##280, ##281, ##283, ##284, ##750, ##760, ##765, ##774, ##779, ##784, ##794

Settings using the Dial Registration (user level):

Select "international transmission (1)" when making an entry in the address book. If errors persist, select "international transmission (2)" and then "international transmission (3)".

Transmission mode selected using One-Touch Dial function or the Speed Dial function will be given priority over the setting made by the service soft switch.

An international transmission mode may be selected using the keypad if a mode has been selected using this switch; for settings, see the following table:

| Transmission mode | Bit7 | Bit6 | Bit5 | Bit4 | Bit3 | Bit2 | Bit1 | Bit0 |
|--------------------------------|------|------|------|------|------|------|------|------|
| International transmission (1) | * | 0 | 0 | 1 | - | - | * | - |
| International transmission (2) | * | 0 | 1 | 0 | - | - | * | - |
| International transmission (3) | * | 1 | 1 | 0 | - | - | * | - |

International transmission (1): Selected to ignore the first DIS signal from the other party.

International transmission (2): Selected to transmit a 1850-Hz total signal when transmitting the DIS signal.

International transmission (3): Selected to transmit a 1650-Hz total signal when transmitting the DIS signal.

Detailed Discussions of Bit 7

Select whether to enable/disable sending of a 1080-Hz tonal signal before sending CED signal.

Select "Send" if errors occur frequently because of an echo when reception is from overseas.

NOTE:

Error codes caused by echoes at the time of reception
#005, ##101, ##106, ##107, ##114, ##200, ##201, ##790

• SSSW-SW04

Functional Construction

| Bit | Function | 1 | 0 |
|-----|---|------------|----------------------|
| 0 | LC monitoring | Monitor | Do not monitor |
| 1 | Check the CI signal frequency | Check | Do not checked |
| 2 | Final flag sequences of the procedure signal | 2 pcs | 1 piece |
| 3 | Reception mode after sending CFR signal | High speed | High speed/low speed |
| 4 | Time to ignore low-speed signals after sending CFR signal | 1500 msec | 700 msec |
| 5 | Check the CS signal frequency (when PBX is set) | Check | Do not check |
| 6 | CNG signal at the time of manual sending | Send | Do not send |
| 7 | CED signal at the time of manual reception | Send | Do not send |

Detailed Discussions of Bit 1

Select whether to check the CI signal frequency.

Detailed Discussions of Bit 2

Select the number of the final flag sequences with the procedure signal (300 bps transmission speed).

Select "2" when the other party's machine does not properly receive the procedure signal sent by this machine.

NOTE:

Error codes occurring at the time of sending fax

##100, ##280, ##281, ##750, ##753, ##754, ##755, ##758, ##759, ##760, ##763, ##764, ##765, ##768, ##769, ##770, ##773, ##775, ##778, ##780, ##783, ##785, ##788

Detailed Discussions of Bit 3

Select a reception mode after sending CFR signal.

Select "High speed" in the case of frequent errors caused by line condition at the time of reception. Simultaneously, turn "OFF" the "ECM reception" of the user data.

NOTE:

Error codes caused by line condition at the time of reception

##107, ##114, ##201

Be sure to change bit 4 before changing this bit; if errors still occur, change this bit.

When 'high speed' is selected, only high-speed signals (images) will be received after sending the CFR signal.

Detailed Discussions of Bit 4

Select the time length during which low-speed signals are ignored after sending the CFR signal.

Select "1500 msec" when reception of image signal is difficult because the line condition is not good.

Detailed Discussions of Bit 5

Select whether to check the CI signal frequency when PBX is set.

Detailed Discussions of Bit 6

Select whether to send CNG signal at the time of manual sending.

If error occurs frequently at manual sending when the destination device that has FAX/TEL switch mode does not change to the fax mode, select "Send".

Detailed Discussions of Bit 7

Select whether to send CED signal at the time of manual reception.

Select "Send" when the other party's machine does not start sending although manual reception is executed.

• SSSW-SW05

Functional Construction

| Bit | Function | 1 | 0 |
|-----|--|-----|----|
| 0 | Not used | - | - |
| 1 | To execute mm/inch conversion (text mode). | Yes | No |
| 2 | Not used | - | - |

| Bit | Function | 1 | 0 |
|-----|--|------------|-----------------|
| 3 | To send bit 33 or later of DIS signal. | Prohibit | Do not prohibit |
| 4 | Record paper length to be declared by DIS signal | A4/B4 size | Any size |
| 5 | Not used | - | - |
| 6 | Not used | - | - |
| 7 | Not used | - | - |

Detailed Discussions of Bit 1

Execute mm/inch conversion for the image scanned in text mode.

Detailed Discussions of Bit 3

Select whether to send bit 33 or later of DIS signal.

CAUTION:

If "Prohibit" is selected, the super-fine reception from other brand printers or memory box function will be disabled.

Detailed Discussions of Bit 4

Select whether the paper to be declared by DIS signal is a cut paper.

Select "A4/B4 size" if dividing the original at the sending machine side at the time of receiving a long original.

NOTE:

Depending on the model of sending machine, long originals may not be divided.

• SSSW-SW09

Functional Construction

| Bit | Function | 1 | 0 |
|-----|--|---------|----------------|
| 0 | Communication result at normal completion | Display | Do not display |
| 1 | Communication result at completion with an error | Display | Do not display |
| 2 | Not used | - | - |
| 3 | Not used | - | - |
| 4 | Not used | - | - |
| 5 | Not used | - | - |
| 6 | Not used | - | - |
| 7 | Not used | - | - |

Detailed Discussions of Bit 0 and 1

Select whether to continue displaying the communication result on the Control Panel at normal completion and/or at completion with an error.

• SSSW-SW12

Functional Construction

| Bit | Function | 1 | 0 |
|-----|--|-----|------------|
| 0 | Timeout period for sending 1 page (sending) | 1 | 0 |
| 1 | Timeout period for sending 1 page (sending) | 1 | 0 |
| 2 | Timeout period for sending 1 page (HT sending) | 1 | 0 |
| 3 | Timeout period for sending 1 page (HT sending) | 1 | 0 |
| 4 | Timeout period for sending 1 page (reception) | 1 | 0 |
| 5 | Timeout period for sending 1 page (reception) | 1 | 0 |
| 6 | Not used | - | - |
| 7 | Page timer settings for sending/receiving | Set | Do not set |

This machine stops communication when sending/receiving per original page takes 32 minutes or longer. When setting the timer different from the above, see the following to set the most appropriate time length.

When 'Do not set' is selected using bit 7, the timeout length per page for all modes will depend on the setting of bit 0 and bit 1.

Timeout period at the time of sending/receiving

| Timeout period | Bit7 | Bit6 | Bit5 | Bit4 | Bit3 | Bit2 | Bit1 | Bit0 |
|----------------|------|------|------|------|------|------|------|------|
| 8 min. | 0 | * | * | * | * | * | 0 | 0 |
| 16 min. | 0 | * | * | * | * | * | 0 | 1 |
| 32 min. | 0 | * | * | * | * | * | 1 | 0 |
| 64 min. | 0 | * | * | * | * | * | 1 | 1 |

Timeout period at the time of sending (in text mode)

| Timeout period | Bit7 | Bit6 | Bit5 | Bit4 | Bit3 | Bit2 | Bit1 | Bit0 |
|----------------|------|------|------|------|------|------|------|------|
| 8 min. | 1 | * | * | * | * | * | 0 | 0 |
| 16 min. | 1 | * | * | * | * | * | 0 | 1 |
| 32 min. | 1 | * | * | * | * | * | 1 | 0 |
| 64 min. | 1 | * | * | * | * | * | 1 | 1 |

Timeout period at the time of sending (in text mode)

| Timeout period | Bit7 | Bit6 | Bit5 | Bit4 | Bit3 | Bit2 | Bit1 | Bit0 |
|----------------|------|------|------|------|------|------|------|------|
| 8 min. | 1 | * | * | * | 0 | 0 | * | * |
| 16 min. | 1 | * | * | * | 0 | 1 | * | * |
| 32 min. | 1 | * | * | * | 1 | 0 | * | * |
| 64 min. | 1 | * | * | * | 1 | 1 | * | * |

Timeout period at the time of reception

| Timeout Period | Bit7 | Bit6 | Bit5 | Bit4 | Bit3 | Bit2 | Bit1 | Bit0 |
|----------------|------|------|------|------|------|------|------|------|
| 8 min. | 1 | * | 0 | 0 | * | * | * | * |
| 16 min. | 1 | * | 0 | 1 | * | * | * | * |
| 32 min. | 1 | * | 1 | 0 | * | * | * | * |
| 64 min. | 1 | * | 1 | 1 | * | * | * | * |

• SSSW-SW13

Functional Construction

| Bit | Function | 1 | 0 |
|-----|--|-----|----|
| 0 | Not used | - | - |
| 1 | Not used | - | - |
| 2 | Not used | - | - |
| 3 | Display Modem Dial-in/My Number Setting screen | Yes | No |
| 4 | Display Number Display Setting screen | Yes | No |
| 5 | Not used | - | - |
| 6 | Not used | - | - |
| 7 | Not used | - | - |

Detailed Discussions of Bit 3

To set whether to display Modem Dial-in Setting screen and My Number Setting screen.

NOTE:

Turn OFF and then ON the power of the host machine after the setting.

Detailed Discussions of Bit 4

To set whether to enable the display of Number Display Setting screen.

NOTE:

Turn OFF and then ON the power of the host machine after the setting.

• SSSW-SW14

Functional Construction

| Bit | Function | 1 | 0 |
|-----|---|-----|----|
| 0 | Not used | - | - |
| 1 | Not used | - | - |
| 2 | Not used | - | - |
| 3 | Not used | - | - |
| 4 | inch-configuration resolution declaration | Yes | No |
| 5 | Not used | - | - |
| 6 | Not used | - | - |
| 7 | Not used | - | - |

Detailed Discussions of Bit 4

At the time of G3 communication, select whether to declare inch-configuration resolution to the other party's machine. if 'declare' is selected, the machine will indicate that it reads and records at an inch-configuration resolution using the DIS, DCS, or DTC signal.

• SSSW-SW17

Functional Construction

| Bit | Function | 1 | 0 |
|-----|---|---------|---------|
| 0 | Not used | - | - |
| 1 | To select the transmission level of the modem | 0 to 15 | 8 to 15 |
| 2 | Not used | - | - |
| 3 | Not used | - | - |
| 4 | Not used | - | - |
| 5 | Not used | - | - |
| 6 | Not used | - | - |
| 7 | Not used | - | - |

Detailed Discussions of Bit 1

Select the transmission level of the modem.

• SSSW-SW18

Functional Construction

| Bit | Function | 1 | 0 |
|-----|---|---------|---------|
| 0 | Not used | - | - |
| 1 | Not used | - | - |
| 2 | Prohibition of the control of IP supported communication | Yes | No |
| 3 | Number of command retransmission (V1.7 or earlier) | 6 times | 3 times |
| 4 | Request retransmission of all frames after frame loss at JBIG reception | Yes | No |
| 5 | Not used | - | - |
| 6 | Not used | - | - |
| 7 | Not used | - | - |

Detailed Discussions of Bit 2

Set whether to prohibit the control of IP supported communication

1: Yes

0: No

Detailed Discussions of Bit 3

Number of command retransmission

1: 6 times

0: 3 times

Detailed Discussions of Bit 4

Set whether to request retransmission of all frames after frame loss at JBIG reception

1: Yes

0: No

• SSSW-SW22

Functional Construction

| Bit | Function | 1 | 0 |
|-----|--|---------|------------|
| 0 | Backup when an archive transmission error occurs | Use | Do not use |
| 1 | Not used | - | - |
| 2 | Not used | - | - |
| 3 | Prohibit manual polling operation | - | - |
| 4 | Not used | - | - |
| 5 | Not used | - | - |
| 6 | Archive transmission function | Enabled | Disabled |
| 7 | Not used | - | - |

Detailed Discussions of Bit0

Select whether to back up data when a communication error occurs during archive transmission.

This function is available on the Platform Version 3.6 or later.

Detailed Discussions of Bit3

Set whether to prohibit of manual polling operation

Detailed Discussions of Bit 6

Set whether to send the sent images to the destination specified by the forwarding function.

• SSSW-SW23

Functional Construction

| Bit | Function | 1 | 0 |
|-----|---|---|---|
| 0 | Not used | - | - |
| 1 | Not used | - | - |
| 2 | Prohibit to rotate A4 or larger paper in portrait position by 180 degrees | - | - |
| 3 | Not used | - | - |
| 4 | Not used | - | - |
| 5 | Not used | - | - |
| 6 | Not used | - | - |
| 7 | Not used | - | - |

Detailed Discussion of Bit 2

Set whether to add header with or without rotating the image by 180 degrees when A4 or larger paper is placed in the feeder in portrait position (R position).

1: Yes

0: No

• SSSW-SW25

Functional Construction

| Bit | Function | 1 | 0 |
|-----|---|-------------------|-----------------|
| 0 | Sender's phone number indicated in the report | Receiver's number | Caller's number |
| 1 | Not used | - | - |

| Bit | Function | 1 | 0 |
|-----|-------------------------------------|----------|-------------------|
| 2 | Not used | - | - |
| 3 | Not used | - | - |
| 4 | Not used | - | - |
| 5 | Firmware automatic update (USB Fax) | Prohibit | Do not prohibited |
| 6 | Not used | - | - |
| 7 | Not used | - | - |

Detailed Discussions of Bit 0

Select a phone number to be indicated on the report after transmission is completed.

Caller's number: To display the caller's phone number on the report

Receiver's number: To indicate the phone number (CSI signal data) sent from the other party's machine on the report

Detailed Discussions of Bit 5

Select whether to prohibit the firmware automatic update for USB Fax.

• SSSW-SW26

Functional Construction

| Bit | Function | 1 | 0 |
|-----|--|---------------|--------------|
| 0 | Not used | - | - |
| 1 | Not used | - | - |
| 2 | Check the sequential broadcast. | Check | Do not check |
| 3 | Not used | - | - |
| 4 | Not used | - | - |
| 5 | Redial function when transmission error occurs | Use | Do not use |
| 6 | Not used | - | - |
| 7 | Error report when sending process is canceled | Do not output | Output |

Detailed Discussions of Bit 2

Select whether to display a confirmation message when entering destination for the sequential broadcast in order to prevent the user from broadcasting by mistake.

Detailed Discussions of Bit 5

Select whether to use the redial function when outgoing transmission error occurs.

Detailed Discussions of Bit 7

Select whether to output an error report when the [Stop] key is pressed to cancel sending.

• SSSW-SW28

Functional Configuration

| Bit | Function | 1 | 0 |
|-----|--------------------------------------|----------|-----------------|
| 0 | V.8 procedure at the caller side | No | Yes |
| 1 | V.8 procedure at the receiver side | No | Yes |
| 2 | V.8 late start at the caller side | No | Yes |
| 3 | V.8 late start at the receiver side | No | Yes |
| 4 | Fallback from the V.34 receiver side | Prohibit | Do not prohibit |
| 5 | Not used | - | - |
| 6 | Not used | - | - |
| 7 | Not used | - | - |

Detailed Discussions of Bit 0

Select whether to execute V.8 procedure when making a call.

"No": V.8 procedure is not executed even if V.8 procedure is received from the receiver side, and the procedure starts from V.21.

Detailed Discussions of Bit 1

Select whether to execute V.8 procedure when receiving a call.

"No": V.8 procedure is not executed, and the procedure starts from V.21.

Detailed Discussions of Bit 2

Select whether to execute V.8 procedure when ANSam signal from the receiver side cannot be recognized at the time of making a call and V.8 procedure is declared by DIS signal from the receiver side.

"Yes": CI signal is sent in response to the DIS signal of the receiver side to execute the V.8 procedure.

"No": CI signal is not sent in response to the DIS signal of the receiver side, and the V.21 procedure is executed.

In the case of manual transmission, there will be no V.8 late start regardless of this setting.

Detailed Discussions of Bit 3

Select whether to declare the existence of the V.8 procedure with the DIS signal that is transmitted after the ANSam signal in case that the ANSam signal at the reception is not recognized at the caller side.

"Yes": V.8 procedure is declared by DIS signal and V.8 procedure is executed after CI signal is sent from the caller side.

"No": V.8 procedure is not declared by DIS signal, and V.21 procedure is executed.

In the case of manual transmission, there will be no V.8 late start regardless of this setting.

Detailed Discussions of Bit 4

Select whether to prohibit fallback from the V.34 receiver side.

"Prohibit": There will be no fallback from the receiver side.

• SSSW-SW30

Functional Construction

| Bit | Function | 1 | 0 |
|-----|--|---------|----------------------|
| 0 | Not used | - | - |
| 1 | Not used | - | - |
| 2 | Not used | - | - |
| 3 | Not used | - | - |
| 4 | Not used | - | - |
| 5 | Switching the dial tone detection method | - | New detection method |
| 6 | Flow control between pages | Control | Do not control |
| 7 | Not used | - | - |

Detailed Discussions of Bit 5

Switch the detection method when executing the dial tone detection at the time of calling.

0: New detection method (default)

1: Not used

Detailed Discussions of Bit 6

Select whether to execute flow control between pages.

• SSSW-SW50

Functional Construction

| Bit | Function | 1 | 0 |
|-----|--|------------------|---------------------|
| 0 | Transmission number restriction: Function to prevent no external access code *2 | ON: Enable | OFF: Disable |
| 1 | Transmission number restriction: Extension allowance, prohibition *2 | Prohibited | Allow |
| 2 | Transmission number restriction: Add "0" to the first digit of external access code *2 | Yes | No |
| 3 | Operate as the client of a fax server *1 *a | Yes | No |
| 4 | Display the send job stop confirmation screen when pressing Stop key *2 | No | Yes |
| 5 | Send jobs that are targeted to stop when pressing Stop key *2 | Ongoing send job | Incomplete send job |
| 6 | not used | - | - |
| 7 | not used | - | - |

*1: Supported by the platform version 306 or later

*2: Supported by the platform version 307 or later

*a: Enabled only for USA

Details of Bit 0

To prevent incorrectly sending fax due to forgetting to use the external access number, "0", this function displays a pop-up warning window and prevents sending and returns to the status before pressing Start button by pressing [OK] after setting the fax number in [Fax] or [Scan and Send] and pressing Start button if the set telephone number does not start with "00". This function is supported even if the machine is operating in the fax server mode.

- 0: ON: Disable
- 1: OFF: Enable

CAUTION:

- If using this function, enter the telephone number from the area code.
- This function applies to the fax destination telephone number of "Address List", "One-touch" and "Numeric Keypad input".
However, the warning is not displayed with "sending from Mail Box" and "manual sending".
- A warning is displayed when sending IP fax but it is not displayed when sending PC fax.
- A warning is not displayed when forwarding transmission.
- If any registered number matches to the condition for displaying a warning, the warning is displayed with "sequential broadcast" and "group sending".
- "*" and "#" are also processed as a number.

NOTE:

Example of sending fax to 03-1234-5678

- The machine accepts sending fax with "0 (external access code) + 03 1234 5678 (telephone number)".
- The machine displays a warning and stops sending with "(no external access code) + 03 1234 5678 (telephone number)".
- If the external access code is other than "0", it can be changed from the following service mode.

Service Mode > FAX > NUM > 080

Change the default setting of 080 from "0" to the external access code used in the installation environment.

Details of Bit 1

This is set to allow or prohibit transmission to the extension line.

This is enabled only if Bit 0 (function to prevent no external access code) is "1" (ON: Enable).

If transmission to the extension line is allowed, all telephone numbers not starting with the external access code are allowed. For example, if the external access code is "0", any number starting with "00" as starting 2 digits and number of the extension line are allowed. This means numbers starting with "01" to "09" are prohibited and other numbers are allowed.

If transmission to the extension line is prohibited, only allow the telephone number starting with the external access code + area code "0". For example, if the external access code is "0", allow only numbers starting with "00" as starting 2 digits.

Prohibit all extension numbers. This means only numbers starting with "00" are allowed and other numbers are prohibited.

- 0: Allow
- 1: Prohibit

Details of Bit 2

This is the switch to add "0" to the beginning of external access code (default "0") set by the NUM switch 080.

The NUM switch can be used to set "0" and "1" but not "00" and "01" as the external access code.

This switch is used to solve this issue. In the above example, set this setting to "add" and then set the NUM switch 080 to "0" and "1" to set the external access code of "00" and "01".

- 0: No
- 1: Yes

CAUTION:

- This automatically adds the external access number to the destination telephone number for sending fax registered by Address List, One-touch and entering by the Numeric Keypad excluding Direct Send and Send from Mail Box.
- This should be set only in the network environment that sends fax by adding the external access code.
- Do not add the external access code to the telephone number for fax send destination as the external access code is automatically added.

Details of Bit 3

This switch operates the machine as the client of fax server.

- 0: No
- 1: Yes

- 1:
To make monitoring tone of the phone line from the speaker from the start of communication until the completion.
- 2:
Not used
- 3 (OFF):
There will be no monitoring tone of the phone line from the speaker.

007: ATT transmission level

Set the transmission level (ATT).

Increase the transmission level (make it closer to 8) in the case of frequent errors caused by line status at the time of communication.

NOTE:

Error codes caused by line status at the time of transmission

##100, ##101, ##102, ##104, ##201, ##280, ##281, ##282, ##283, ##284, ##750, ##752, ##754, ##755, ##757, ##759, ##760, ##762, ##764, ##765, ##767, ##769, ##770, ##772, ##774, ##775, ##777, ##779, ##780, ##782, ##784, ##785, ##787, ##789

Error codes caused by line status at the time of reception

##103, ##106, ##107, ##201, ##793

008: Upper limit for V.34 modulation speed

Select the upper limit of the modulation speed (baud rate) in the V.34 primary channel.

When 4 (2743 baud) is selected, the communication is actually performed at 2400 baud.

009: Upper limit of V.34 data speed

Select an upper limit of data transmission speed in the V.34 primary channel in the range between 2.4k and 33.6kbps at 2400bps intervals (0: 2.4 kbps to 13: 33.6 kbps).


010: Pseudo CI signal frequency

Set pseudo CI signal frequency.

Depending on the type of external phones, there is no ring tone when the FAX/TEL switching function is working. Change the pseudo CI signal frequency when there is no ring tone.

Setting of Numeric Parameter (NUMERIC Param.)

Configuration of Numeric Parameters



| No. | Function | Setting range | Default value |
|-----|---|---------------------|---------------|
| 002 | RTN transmission condition (1) | 1 to 99% | 10 |
| 003 | RTN transmission condition (2) | 2 to 99 times | 15 |
| 004 | RTN transmission condition (3) | 1 to 99 lines | 12 |
| 005 | NCC pause time (before ID code) | 1 to 60 sec | 4 |
| 006 | NCC pause time (after ID code) | 1 to 60 sec | 4 |
| 007 | Prepose time at the time of making a call | 0 to 9999 (x 10 ms) | 0 |

| No. | Function | Setting range | Default value |
|-----|--|----------------------------|---------------|
| 009 | Comparing the number of digits between the sender's telephone number and the receiver's telephone number | 0 to 20 digits | 0 |
| 010 | Line connection identification time | 0 to 9999 (x 10 ms) | 5500 |
| 011 | T.30 T1 timer (for reception) | 0 to 9999 (x 10 ms) | 3500 |
| 013 | T.30 EOL timer | 500 to 3000 (x 10 ms) | 1300 |
| 015 | Hooking detection time | 0 to 999 | 120 |
| 016 | Time until a temporary response is obtained when switching FAX/TEL | 0 to 9 | 4 |
| 017 | Pseudo RBT signal pattern ON time | 0 to 999 | 100 |
| 018 | Pseudo RBT signal pattern OFF time (short) | 0 to 999 | 0 |
| 019 | Pseudo RBT signal pattern OFF time (long) | 0 to 999 | 200 |
| 020 | Pseudo CI signal pattern ON time | 0 to 999 | 100 |
| 021 | Pseudo CI signal pattern OFF time (short) | 0 to 999 | 0 |
| 022 | Pseudo CI signal pattern OFF time (long) | 0 to 999 | 200 |
| 023 | CNG detection level when switching FAX/TEL | 0 to 7 | 4 |
| 024 | Pseudo RBT transmission level when switching FAX/TEL | 10 to 20 (TYPE = STANDARD) | 20 |
| 025 | CNG monitoring time when the answering phone connection function is set | | |
| 026 | Silent detection level when the answering phone connection function is set | | |
| 027 | V.21 low-speed flag preamble detection time | 20 (-10 ms) | 0 |
| 028 | Off-hook PCB duty settings | 1 to 99% | 0 (50%) |
| 080 | Transmission number restriction: Outside line transmission number *1 | 0 to 9999 | 0 |

*1 : Supported on the platform version 307 or later

002: RTN transmission condition (1)/003: RTN transmission condition (2)/004: RTN transmission condition (3)

Set the RTN signal transmission condition.

In the case of frequent errors caused by RTN signal transmission at the time of reception, increase the parameters to loosen the RTN signal transmission condition.

NOTE:

Error codes caused by RTN signal transmission at the time of reception

##104, ##107, ##114, ##201

RTN signal transmission condition (1) is the ratio of error lines for the total number of lines per page of the received image.

RTN signal transmission condition (2) is the reference value (*2) of burst error (*1).

RTN signal transmission condition (3) is the number of errors that fail to meet the reference value of burst error.

*1: Burst error (transmission errors with several continued lines)

*2: Reference value (When "15" is set, transmission error with 15 consecutive lines is recognized as a burst error.)

When any of the above conditions is detected during reception of image signals, RTN signal is sent after reception of the procedure signal from the sending machine. Increasing such parameter sends less RTN signal.

005: NCC pause time (before ID code)

Set the pause time to be automatically entered between the access code and ID code when dialing on NCC (New Common Carrier) line.

006: NCC pause time (after ID code)

Set the pause time to be automatically entered between the ID code and the other party's telephone number when dialing on NCC (New Common Carrier) line.

007: Prepose time at the time of making a call

When automatically making a call, set the time from closing a line to making a call.

009: Comparing the number of digits between the sender's telephone number and the receiver's telephone number

Set the TSI comparing the number of digits (last XX digits) when matching telephone numbers.

010: Line connection identification time

Set the line connection identification time.

Increase this parameter in the case of frequent errors caused by line connection status at the time of communication.

NOTE:

Error codes caused by line connection status

##005, ##018

The line connection identification time is the duration from when the dial signal is transmitted until the line is disconnected at the sending side, or from when DIS signal is transmitted until the line is disconnected at the reception side.

011: T.30 T1 timer (for reception)

Set T1 timer at the time of reception (wait time until receiving the meaningful signal after DIS transmission).

013: T.30 EOL timer

Set the receivable 1 line transmission time.

In the case of a long line data length (e.g.: computer FAX), extend the transmission time to prevent reception errors.

015: Hooking detection time

Set the hooking detection time.

016: Time until the primary response is obtained when switching FAX/TEL

Set the time from when capturing the line until transmission of pseudo RBT at FAX/TEL switching function operation.

017: Pseudo RBT signal pattern ON time/ 018: Pseudo RBT signal pattern OFF time (short)/ 019: Pseudo RBT signal pattern OFF time (long)

Set the pattern of pseudo RBT signal to be sent at Fax/Tel switching function operation.

020: Pseudo CI signal pattern ON time/ 021: Pseudo CI signal pattern OFF time (short)/ 022: Pseudo CI signal pattern OFF time (long)

Set the pattern of pseudo CI signal to be sent at Fax/Tel switching function operation.

023: CNG detection level when switching FAX/TEL

Set the CNG detection level at Fax/Tel switching function operation.

024: Pseudo RBT transmission level when switching FAX/TEL

Set the transmission level of pseudo RBT at Fax/Tel switching function operation.

025: CNG monitoring time when the answering phone connection function is set**027: V21 low-speed flag preamble detection time**

Set the period of time for judge detection of V.21 low-speed command preamble.

Continuous detection for the fixed period of time leads to command analysis.

028: Off-hook PCB duty settings

Set the Off-hook PCB duty setting.

When 0 or a value that is 100 or more is entered, the duty becomes 50%.

080: Transmission number restriction: Outside line transmission number

This sets the number permitted to dial to the outside line.

Only the outside line transmission by the set number is permitted and other numbers are prohibited from transmission.

Setting of Destination (TYPE)

■ Overview

When the type shown on the display is set, all the service data is set to match each country domestic telecommunication standards.

Setting of Printer Functions (PRINTER)

■ Setting of Bit Switch (SSSW)

● SSSW-SW01

Functional Construction

| Bit | Function | 1 | 0 |
|-----|---|--------|---------------|
| 0 | Not used | - | - |
| 1 | Not used | - | - |
| 2 | Not used | - | - |
| 3 | Not used | - | - |
| 4 | Not used | - | - |
| 5 | Not used | - | - |
| 6 | Hold the line (when error code occurs) | Hold | Do not hold |
| 7 | Output a print log when DUMP report is output | Output | Do not output |

Detailed Discussions of Bit 6

Select whether to hold the line when an error code occurs.

However, in the case of vertical scanning prioritized recording, even when 0 is set for Bit 1 and Bit 0, the priority order will be Letter -> A4 -> Legal.

Detailed Discussions of Bit 7

Select whether to output a print log at the time of the DUMP report output.

● SSSW-SW05

Functional Construction

| Bit | Function | 1 | 0 |
|-----|---|------------|----------------|
| 0 | Letter priority | Set | Do not set |
| 1 | Legal priority | Set | Do not set |
| 2 | Not used | - | - |
| 3 | Not used | - | - |
| 4 | Not used | - | - |
| 5 | To prohibit reduced size printing (A4) | Prohibited | Not prohibited |
| 6 | To prohibit reduced size printing (A4) | Prohibited | Not prohibited |
| 7 | Vertical scanning prioritized recording | Set | Do not set |

Detailed Discussions of Bit 0 and 1

When an image which can be printed in 100% magnification and with the same number of divided pages on any of A4, letter and legal is received, set which paper is prioritized for printing.

With the settings of Bit 0 and Bit 1, the priority order of the recording paper is shown in the following table.

| Bit 1 | Bit 0 | Priority order of the recording paper |
|-------|-------|---------------------------------------|
| 0 | 0 | A4 -> Letter -> Legal |
| 0 | 1 | Letter -> A4 -> Legal |
| 1 | 0 | Legal -> Letter -> A4 |
| 1 | 1 | Letter -> Legal -> A4 |

However, in the case of vertical scanning prioritized recording, the priority order will be Letter -> A4 -> Legal even when 0 is set for Bit 1 and Bit 0.

Detailed Discussions of Bit 5 and 6

Select whether to enable reduced size printing for A4 or LTR.

Detailed Discussions of Bit 7

Set whether to set vertical scanning prioritized recording.

Set:

If B4 recording paper and A4 recording paper are set and an A4 extra-long image (*) is received, printing will be on the B4 recording paper.

Do not set:

If B5 horizontal recording paper and A4 recording paper are set and a B4 image is received, printing will be by division and on B5 horizontal recording paper.

*: Image B4 or shorter and that cannot be printed on A4 recording paper.

• SSSW-SW06

Functional Construction

| Bit | Function | 1 | 0 |
|-----|--------------------------------|--------|---------|
| 0 | Not used | - | - |
| 1 | Not used | - | - |
| 2 | Not used | - | - |
| 3 | Not used | - | - |
| 4 | Not used | - | - |
| 5 | Reduced printing from A4 to B5 | Enable | Disable |
| 6 | Not used | - | - |
| 7 | Not used | - | - |

Detailed Discussions of Bit 5

Set whether to execute the reduction print that forcibly reduces the received A4 size document into the B5 size. This function is invalid when outputting the report.

■ Setting of Numeric Parameter (NUMERIC Param.)

• Numerical Parameter Composition

| No. | Function | Setting range | Initial setting | Unit |
|-----|---|---------------|-----------------|------|
| 01 | Missing areas of printing image when receiving image with longer length than standard | 0 to 9999 | 12 | 1 mm |
| 04 | Leading edge blank area | 0 to 9999 | 3 | 1 mm |
| 05 | Trailing edge blank area | 0 to 9999 | 3 | 1 mm |

<001: printing upon reception of extra-length image>

Use it to set the range of the image to be removed from when printing an extra-length received image.

Lower the parameter to decrease the range if the trailing edge of the received image must be retained (as when it is longer than the effective recording length).

<004: leading edge margin>

Use it to set the leading-edge margin for the effective recording length.

<005: trailing edge margin>

Use it to set the trailing-edge margin for the effective recording length.

IPFAX Setting

■ IPFAX

● BASIC N

| Bit | Function | Setting range |
|-----|--|----------------|
| 2 | Session control reception timeout (sec.) | 0 to 9999 (0*) |
| 20 | Reception start delay time (sec.) | 0 to 9999 (0*) |
| 21 | BYE sending delay time at transmission (x10 msec.) | 0 to 9999 (0*) |
| 22 | BYE receiving delay time at transmission (x10 msec.) | 0 to 9999 (0*) |

● NETA NUM

| Bit | Function | Setting range |
|-----|-----------------------------------|-----------------|
| 1 | T0 timer(Timer C) for IPFAX(sec.) | 0 to 9999 (55*) |

● NETC NUM

| Bit | Function | Setting range |
|-----|---|---|
| 1 | SW for adjusting the speed at VoIPGW transmission [%] | 0 to 9999* However, the value is fixed in the case of ECM, and is corrected by adding 5 %. |
| 2 | VoIPGW buffer size [byte] | 0 to 9999* However, when the value is 0, it is internally interpreted as 200. |
| 3 | Packet division size [byte] | 0 to 9999* However, when the value is 0, it is internally interpreted as 66. |
| 4 | Number of VoIPGW buffer reset frames at ECM * At ECM transmission, when frames of the number of this NUM value have been transmitted, the next frames will be transmitted after the VoIPGW buffer becomes empty. | 0 to 9999* However, when the value is 0, it is internally interpreted as 16. |

● T.38 Bit Setting

SW01

| Bit | Function | Setting range | |
|-----|--|---------------|------------|
| | | 1 | 0 |
| 1 | German mode is effective during T.38 communication. | Effective | Invalid * |
| 2 | T.38 significant bit of DIS (bit123) is ignored. (When this SW is effective, the other party's machine is regarded as IPFAX even if DIS bit123 is 0.) | Ignore | Not ignore |
| 3 | Transmission ECM = OFF setting | Effective | Invalid * |
| 4 | Reception ECM = OFF setting | Effective | Invalid * |

● T.38 NUM Setting

| Bit | Function | Setting range |
|-----|---|----------------|
| 1 | High-speed flag sending time of ECM mode for IPFAX (x10 msec.). | 0 to 9999 (0*) |
| 2 | WAIT time from the close of T.38 to the close of SIP: Unit; second (However, the setting becomes 2 seconds even if the setting is changed to 2 or more.). | 0 to 9999 (1*) |

Using Test Mode

1. Press the desired item to highlight; then, press the OK key to bring up its screen.

The following table shows text mode items that are valid and invalid when a fax board is installed:

Yes: may be used

-: not used

| Level 1 | Level 2 | Fax Board present |
|----------|-----------|-------------------|
| MODEM | RELAY-1 | Yes |
| | RELAY-2 | - |
| | FREQ | Yes |
| | G3TX | Yes |
| | DTMFTX | Yes |
| | TONERX | - |
| | V34G3TX | Yes |
| FACULTY | G3 4800TX | Yes |
| | SPEAKER | - |
| | DETECT1 | - |
| | DETECT2 | - |
| | DETECT3 | - |
| | VOICETX | - |
| DATA SET | | - |
| ISDNMOD | | - |
| ISDNMOD2 | | - |

CAUTION:

Do not use items in the table identified as "-."

■ MODEM Test

● Relay Test (RELAY-1)


Use it to see if the individual relays on the NCU board go on and off as expected.







| Sssw | Menu | Num | Ncu | Type | IP FAX | Print | Clear | Test | Report |
|---------|-----------|-------|---------|------|--------|-------|-------|------|--------|
| <MODEM> | <RELAY-1> | <1/1> | <READY> | | | | | | |
| CML | OFF | | | | | | | | |
| P | OFF | | | | | | | | |
| S | OFF | | | | | | | | |
| H | OFF | | | | | | | | |
| D | OFF | | | | | | | | |
| R | OFF | | | | | | | | |

Using Text Mode

1. From the relays indicated on the screen, select the one you want to test; then, turn it off or on using the Up/Down key. (Some of the relays may not actually exist on the NCU board.)

• Frequency Test (FREQ)


Of the items indicated below, press one; in response, the DC circuit will be closed and the selected frequency will be transmitted using the tone transmission function of the modem. You can also monitor the transmission signal by listening to the sound generated by the speaker. To stop the operation and end test mode, press the  key.







| Ssw | Menu | Num | Ncu | Type | IP FAX | Print | Clear | Test | Report |
|---|---|---|---|---|--|-------|-------|------|--------|
| <MODEM> | <FREQ> | <1/1> | <READY> | | | | | | |
| RBT | | | | | | | | | |
| 462Hz | | | | | | | | | |
| 1100Hz | | | | | | | | | |
| 1300Hz | | | | | | | | | |
| 1500Hz | | | | | | | | | |
| 1650Hz | | | | | | | | | |
| 1850Hz | | | | | | | | | |
| 2100Hz | | | | | | | | | |
|  |  |  |  |  |  | | | | |

CAUTION:

'RBT' is not currently supported.

• G3 Signal Transmission Test (G3 Tx)

Of the items indicated below, press one. In response, the DC circuit will be closed and the selected frequency will be transmitted using the G3 signal transmission function of the modem. You can also monitor the transmission signal by listening to the sound generated by the speaker. To stop the operation and end test mode, press the  key.


| Ssw | Menu | Num | Ncu | Type | IP FAX | Print | Clear | Test | Report |
|---|---|---|---|---|--|-------|-------|------|--------|
| <MODEM> | <G3TX> | <1/2> | <READY> | | | | | | |
| 300bps | | | | | | | | | |
| 2400bps | | | | | | | | | |
| 4800bps | | | | | | | | | |
| 7200bps | | | | | | | | | |
| 9600bps | | | | | | | | | |
| TC7200 | | | | | | | | | |
| TC9600 | | | | | | | | | |
| 12000bps | | | | | | | | | |
|  |  |  |  |  |  | | | | |

| Sssw | Menu | Num | Ncu | Type | IP FAX | Print | Clear | Test | Report |
|------|--|-----|--------|------|--------|-------|-------|---------|--------|
| | <MODEM> | | <G3TX> | | <2/2> | | | <READY> | |
| | 14400bps | | | | | | | | |
| | 300-ALL0 | | | | | | | | |
| | 300-ALL1 | | | | | | | | |
| | 300-1:1 | | | | | | | | |
| | 300-1:4 | | | | | | | | |
| | 300-4:1 | | | | | | | | |
| | <div style="display: flex; justify-content: space-around; align-items: center;"> ← → ▽ △ ↵ OK ↵ </div> | | | | | | | | |

CAUTION:

'300-ALL0' through '300-4:1' are not currently supported.

• DTMF Transmission Test

Of the items indicated below, press one; in response, the DC circuit will be closed and the selected DTMF signal will be transmitted using the DTMF transmission function of the modem. You can also monitor the transmission signal by listening to the speaker. To stop the operation and to end test mode, press the  key.

| Sssw | Menu | Num | Ncu | Type | IP FAX | Print | Clear | Test | Report |
|------|--|-----|-------------------------|------|--------|-------|-------|---------|--------|
| | <MODEM> | | <DTMFTX> | | <1/1> | | | <READY> | |
| | LONG | | 0 1 2 3 4 5 6 7 8 9 * # | | | | | | |
| | <div style="display: flex; justify-content: space-around; align-items: center;"> ← → ▽ △ ↵ OK ↵ </div> | | | | | | | | |


Using Text Mode

1. From the items indicated on the screen, select the item you want to test; then, press the key on keypad that corresponds to the DTMF signal to test.

CAUTION:

'SHORT' is not currently supported.

• V.34 G3 Signal Transmission Test (V34G3Tx)

Select the transmission speed you want to test, and then select a modulation speed (baud rate); in response, the V.34 G3 transmission signal will be transmitted to the telephone line terminal and the speaker. To stop the operation and to end test mode, press the  key.


| Sssw | Menu | Num | Ncu | Type | IP FAX | Print | Clear | Test | Report |
|----------|------|-----------|-----|-------|--------|---------|-------|------|--------|
| <MODEM> | | <V34G3TX> | | <1/1> | | <READY> | | | |
| SPEED | | 33600bps | | | | | | | |
| 3429baud | | | | | | | | | |
| 3200baud | | | | | | | | | |
| 3000baud | | | | | | | | | |
| 2800baud | | | | | | | | | |
| 2743baud | | | | | | | | | |
| 2400baud | | | | | | | | | |
| ← | | → | | ▽ | | △ | | ↵ | |
| OK | | ↵ | | | | | | | |

Using Text Mode

1. Select 'SPEED', and then select the speed you want to test using the Up/Down key.
2. Select the baud rate you want to test.

■ Function Test

● 4800-bps Signal Transmission Test

The DC circuit will be closed, and a 4800-bps signal will be transmitted using the 4800-bps signal transmission function of the modem. You can also monitor the transmission signal by listening to the speaker. To stop the operation and end test mode, press the  key.

| Sssw | Menu | Num | Ncu | Type | IP FAX | Print | Clear | Test | Report |
|-----------|------|------------|-----|-------|--------|---------|-------|------|--------|
| <FACULTY> | | <G34800TX> | | <1/1> | | <READY> | | | |
| G34800TX | | | | | | | | | |
| ← | | → | | ▽ | | △ | | ↵ | |
| OK | | ↵ | | | | | | | |

● Service Report (REPORT)

■ System Data List

Use it to check the settings associated with the service soft switch and service parameters.


```

2003 09/02 TUE 12:00 FAX
*****
*** SYSTEM DATA LIST ***
*****
SERIAL NO      XXXXXXXX
#1 SSSW
SW01          ..... 00000000
SW02          ..... 10000000
SW03          ..... 00000000
SW04          ..... 10000000
SW05          ..... 00000000
SW06          ..... 10000000
SW07          ..... 00000000
SW08          ..... 00000000
SW09          ..... 00000000
SW10          ..... 00000000
SW11          ..... 00000000
SW12          ..... 00000011
SW13          ..... 00000000
SW14          ..... 00000000
SW15          ..... 00000000
SW16          ..... 00000000
SW17          ..... 00000000
SW18          ..... 00000000
SW19          ..... 00011000
SW20          ..... 00000000
SW21          ..... 00000000
SW22          ..... 00000000
SW23          ..... 00000000
SW24          ..... 00000000
SW25          ..... 00000000
SW26          ..... 00100000
SW27          ..... 00000000
SW28          ..... 00000000
SW29          ..... 00000000
SW30          ..... 00000000
SW31          ..... 00000000
SW32          ..... 00000000
SW33          ..... 00000000
SW34          ..... 00000000
SW35          ..... 00000000
SW36          ..... 00000000
SW37          ..... 00000000
SW38          ..... 00000000
SW39          ..... 00000000
SW40          ..... 00000000
SW41          ..... 00000000
SW42          ..... 00000000
SW43          ..... 00000000
SW44          ..... 00000000
SW45          ..... 00000000
SW46          ..... 00000000
SW47          ..... 00000000
SW48          ..... 00000000
SW49          ..... 00000000
SW50          ..... 00000000

#2 MENU
01:          ..... 0
02:          ..... 0
03:          ..... 0
04:          ..... 0
05:          ..... 0
06:          ..... 0
07:          ..... 10
08:          ..... 0
09:          ..... 0
10:          ..... 2

```

System Dump List

NOTE:

A system dump list is generated when you execute the following in service mode: FAX > Report > DUMP.

Use it to check the history of communications, both successful and error.

```

2013 04/05 FRI 12:00 FAX
*****
*** SYSTEM DUMP LIST ***
*****
SERIAL NO      XXXXXXXX
CLEAR DATE    2013 02/03 FRI 13:37
*1 TX = 1298
*2 A4 = 1302 B4 = 49 A3 = 27 LTR = 0 LGL = 0
*1 RX = 1572
*2 A4 = 1581 B4 = 59 A3 = 59 LTR = 0 LGL = 0
*3 NWSPD = 0
*3 33600 = 1 31200 = 0 28800 = 2986 26400 = 0 24000 = 0
21600 = 0 19200 = 0 16800 = 0 14400 = 0 12000 = 0
9600 = 0 7200 = 0 4800 = 0 2400 = 0
14400 = 83 12000 = 1 TC9600 = 0 TC7200 = 0
14400 = 0 14400 = 0
*4 9600 = 2 7200 = 0 4800 = 4 2400 = 0
STD = 60 FINE = 2839 SUPER = 107 ULTRA = 71
*5 MH = 7 MR = 32 MMR = 9 JBIG = 3029 JPEG = 0
*6 G3 = 37 ECM = 3040 G4 = 0 IPECM = 0 IPG3 = 0
*7 #000 0 0 0 0 0 0 0 0 0
0 0 0 0 0 0 0 0 0
0 0 0 2 0 0 0 0 0
0 0 0 0 0 0 0 0 0
0 0 0 0 0 0 0 0 0
0 0 0 0 0 0 0 0 0
0 0 0 0 0 0 0 0 0
0 0 0 0 0 0 0 0 0
0 0 0 0 0 0 0 0 0
0 0 0 0 0 0 0 0 0
0 0 0 0 0 0 0 0 0
0 0 0 0 22 0 0 0 0
0 0 0 0 0 0 0 0 0

```

- *1: RX, total reception number of times; TX, total transmission number of times.
- *2: number of pages sent/received according to original size.
- *3: number of pages sent/received in connection with different modem speeds (NWSPD : For IPFAX communication count).
- *4: number of communication pages by resolution(Standard, Fine, Super Fine, Ultra Fine).
- *5: number of pages sent/received in connection with different coding methods.
- *6: number of transmissions/receptions according to mode.
- *7: number of occurrences according to error code.

Indication sample



It provides error information on the 3 most recent communications.

```

2003 0902 TUE 12:00 FAX                               0001
*1----- #1 LATEST                                     #000
*2----- START TIME                                0902 10:00
*3----- OTHER PARTY                               12345678
*4----- MAKER CODE                                10001000
*5----- MACHINE CODE                              0100001 00000000
          RCV VS FRAME                               E0 81 85 D4 90 7E 00 00 <-Not displayed when IPFAX is enabled
          SYMBOL RATE                               3429 baud
          DATA RATE                               28800 bps [V.34]
          TX LVL REDUCTION                          0
          ERR ABCODE                                00
          ERR SECTXB                                00
          ERR SECRXB                                00
*6----- Rx : (bit 1)                               00000100 01110111 01011111 00100011 00000001 10101001 00000001 00000001 (bit 64)
          (bit 65)                               00000001 00000001 00000100 00000000 00000000 00000000 00000000 00000000 (bit 128)
*7----- Tx : (bit 1)                               00000000 01000010 00011111 00100001 00000001 00000001 00000001 00000001 (bit 64)
          (bit 65)                               00000001 00000001 00000100 00000000 00000000 00000000 00000000 00000000 (bit 128)

          Rx : NSF CSI DIS          CFR          MCF          MCF
          Tx :          NSS TSI DCS    PIX-288 PPS-NUL    PIX-288 PPS-NUL    PIX-288 PPS-NUL

#2                                     #000
          START TIME                                0902 09:30
          OTHER PARTY                               12345678
          MAKER CODE                                10001000
          MACHINE CODE                              0100001 00000000
          RCV VS FRAME                               E0 81 85 D4 90 7E 00 00 <-Not displayed when IPFAX is enabled
          SYMBOL RATE                               3429 baud
          DATA RATE                               28800 bps [V.34]
          TX LVL REDUCTION                          0
          ERR ABCODE                                00
          ERR SECTXB                                00
          ERR SECRXB                                00

          Rx : (bit 1)                               00000100 01110111 01011111 00100011 00000001 10101001 00000001 00000001 (bit 64)
          (bit 65)                               00000001 00000001 00000100 00000000 00000000 00000000 00000000 00000000 (bit 128)
          Tx : (bit 1)                               00000000 01000010 00011111 00100001 00000001 00000001 00000001 00000001 (bit 64)
          (bit 65)                               00000001 00000001 00000100 00000000 00000000 00000000 00000000 00000000 (bit 128)

          Rx : NSF CSI DIS          CFR          MCF          MCF
          Tx :          NSS TSI DCS    PIX-288 PPS-NUL    PIX-288 PPS-NUL    PIX-288 PPS-NUL

#3 OLDEST                               #000
          START TIME                                0902 09:00
          OTHER PARTY                               12345678
          MAKER CODE                                10001000
          MACHINE CODE                              0100001 00000000
          RCV VS FRAME                               E0 81 85 D4 90 7E 00 00
          SYMBOL RATE                               3429 baud
          DATA RATE                               28800 bps [V.34]
          TX LVL REDUCTION                          0
          ERR ABCODE                                00
          ERR SECTXB                                00
          ERR SECRXB                                00
    
```

- *1: service error code.
- *2: START TIME, date and time (in 24-hr notation).
- *3: OTHER PARTY, telephone number sent by the other party.
- *4: MAKER CODE, manufacturer code.
- *5: MACHINE CODE, model code.
- *6: bit 1 through bit 128 of DIS, DCS, or DTC that has been received.
- *7: bit 1 through bit 128 of DIS, DCS, or DTC that has been transmitted.
- *8: RX, procedural signal received; TX, procedural signal transmitted.

■ Error Transmission Report

An error transmission report is an error transmission report together to which a service error code and error dump list is attached.

2003 09/02 TUE 12:00 FAX

0001

```

*****
*** FAX ERROR TX REPORT ***
*****
TX FUNCTION WAS NOT COMPLETED

JOB NO.                1269
DESTINATION ADDRESS    12345678
PSWDSUBADDRESS
DESTINATION ID
ST. TIME              09/02 09:00
USAGE T               01'50
PGS.                  1
RESULT                NG
                      1          ##750
    
```

```

START TIME          09/02 09:00
OTHER PARTY        12345678
MAKER CODE         10001000
MACHINE CODE       0100001 00000000
RCV VS FRAME       E0 81 85 D4 90 7E 00 00
SYMBOL RATE        3429 baud
DATA RATE          28800 bps [V.34]
TX LVL REDUCTION   0
ERR ABCODE         92
ERR SECTXB         8A
ERR SECRXB         80
    
```

```

Rx : (bit 1) 00000100 01110111 01011111 00100011 00000001 10101001 00000001 (bit 56)
           (bit 57) 00000001 00000001 00000100 00000000 00000000 (bit 96)
Tx : (bit 1) 00000000 01000010 00011111 00100001 00000001 00000001 00000001 (bit 56)
           (bit 57) 00000001 00000001 00000100 00000000 00000000 (bit 96)
    
```

| | | | |
|------------------|-----------------|-----------------|---------------------------------|
| Rx : NSF CSI DIS | CFR | MCF | MCF |
| Tx : | NSS TSI DCS | PIX-288 PPS-NUL | PIX-288 PPS-NUL PIX-288 PPS-NUL |
| Rx : MCF | MCF | MCF | |
| Tx : | PIX-288 PPS-NUL | PIX-288 PPS-EOP | DCN |



Installation







| | |
|-------------------------------------|-----|
| How to Utilize This Installation | |
| Procedure..... | 584 |
| Host Mashine Installation..... | 585 |
| IC Card Reader Attachment-A1..... | 586 |
| NFC Kit-C1 | 591 |
| Copy Card Reader-F1/Copy Card | |
| Reader Attachment-B5..... | 601 |
| Copy Control Interface Kit-A1 | 612 |
| Connection Kit-A1 for Bluetooth LE | |
| | 616 |
| Super G3 FAX Board-AY1..... | 620 |

How to Utilize This Installation Procedure







Symbols

The frequently-performed operations are described with symbols in this procedure.








Screw

| | | | | | |
|---|---|---|---|---|---|
|  |  |  |  |  |  |
| Packaged Item | Unused Parts | Install | Remove | Tighten | Loosen |

Harness (Common for Guides and Clamps)

| | | | | | | | |
|---|---|---|---|------------------|------------|-------------------|------------|
|  | |  | | Connector | | Power Cord | |
|  |  |  |  | Connect | Disconnect | Connect | Disconnect |
| Install | Remove | Connect | Disconnect | Connect | Disconnect | Connect | Disconnect |

Power

| | | | | | | |
|--|--|--|--|---|--|--|
|  |  |  |  |  |  |  |
| ON | OFF | Check the sound | Check visually | Check | Push | Cleaning |

Host Machine Installation

Setting the Dehumidification Switch

If the installation environment is a high humidity environment, be sure to turn ON the Dehumidification Switch.

Operation when using uniFLOW Online

When using uniFLOW Online*, follow the setup procedures on the uniFLOW* Online First Steps Guide (http://www.nt-ware.com/uFO_FS).

* China version of "uniFLOW" is called "mdsFLOW".

IC Card Reader Attachment-A1

Points to Note at Installation


- When installing this equipment, the Card Reader (sales company's option) is required. Use the short cable for the Card Reader.
- Although pictures or illustrations used for explanation may differ from the actual things, the procedure is the same.
- Refer to "Table of Options Combination" when installing this equipment before operation.

Table of Options Combination

| | Copy Card Reader | Copy Control Interface Kit-A1 |
|------------------------------|------------------|-------------------------------|
| IC Card Reader Attachment-A1 | No | No |

Yes : Available, No : Unavailable

Installation Outline Drawing



Checking the Contents



< Others >

- Including guides

Essential Items to Be Performed Before Installation

- Turn OFF the main power of the host machine, and disconnect the power plug from the outlet.

WARNING:

- If performing work without disconnecting the power plug of the host machine, it may cause electrical shock.
- If disconnecting the power plug without turning OFF the main power, it may cause damage of the machine.


- When turning OFF the main power, follow the below procedure.
 1. Turn OFF the main power switch of the host machine.
 2. The display in the Control Panel and the lamp of the main power are turned off.

Installation Procedure


1.



2.



3.




NOTE:
The removed screw will be used in step 9.

4.

CAUTION:
Be careful not to get injured during removal.




5.




NOTE:
The removed rod will not be used.


□
6.



□
8.




□
7.




□
9.

NOTE:
Use the screw removed in steps 3.




10.

NOTE:
Be sure to coil it counterclockwise and set it in this location.






12.


CAUTION:
Be sure to align the corners with the indexes.



11.



□
13.



□
14. Connect the power plug of the host machine to the power outlet.


15. Turn the main power switch ON.

NFC Kit-C1


Points to Note when Installing

- Do not touch the sensor and PCB components of the Control Panel.
- The parts removed in "Removing the Control Panel" will be used in "Installing the Control Panel".
- Although pictures or illustrations used for explanation may differ from the actual things, the procedure is the same.

Installation Outline Drawing



Checking the Contents



<Others>

- Including guides

Essential Items to Be Performed Before Installation

- Turn OFF the main power of the host machine, and disconnect the power plug from the outlet.

WARNING:

- If performing work without disconnecting the power plug of the host machine, it may cause electrical shock.
- If disconnecting the power plug without turning OFF the main power, it may cause damage of the machine.

- When turning OFF the main power, follow the below procedure.
 1. Turn OFF the main power switch of the host machine.
 2. The display in the Control Panel and the lamp of the main power are turned off.

Installation procedure

■ Removing the Control Panel

□
1.





□
2.




□
4.



□
3.




5.





6.




7.





8.



9.




10.





■ Installing the NFC Kit



1.







□
2.



□
4.





□
3.




■ Installing the Control Panel



□
1.




□
2.




□
3.



□
4.



□
5.




□
6.




7.

CAUTION:

Do not tighten the screws into the X positions, as they are to be tightened in the later step.



8.



□
9.



□
10.





□
11. Connect the power plug of the host machine to the outlet.

12. Turn the main power switch ON.

■ Affixing the NFC Target

□ 1



Setting after Installation



1. In the following Service Mode, set the value to "1."

COPIER > FUNCTION > INSTALL > NFC-USE

NOTE:

When [System Manager Information Settings] is set, it is required to log in as a system manager in accordance with instructions of the user administrator.



2. Select [Settings/Registration] > [Management Settings] > [Device Management] > [Use NFC Card Emulation], and set the item to "ON".



3. Turn OFF and then ON the main power switch.



4. When a message prompting the version update is displayed, press [Update] and automatically update the version of this equipment.

CAUTION:

It may take time to display the update screen. (Approx. 1 to 2 min.) During this time, do not operate the screen.



5. Check the end of the following service mode.

COPIER > DISPLAY > VERSION > PANEL

If the end is an even number (e.g. 01.26): NFC is not installed.

If the end is an odd number (e.g. 01.27): NFC is installed.

Copy Card Reader-F1/Copy Card Reader Attachment-B5

Points to Note when Installing


- To install this equipment, the Copy Card Reader Attachment is required.
- Although the figure shows a model without the Finisher, the same procedure applies to the one with the Finisher.
- Refer to "Table of Options Combination" when installing this equipment before operation.

Table of Options Combination

| | IC Card Reader Attachment-A1 | Copy Control Interface Kit-A1 |
|------------------|------------------------------|-------------------------------|
| Copy Card Reader | No | No |


Yes : Available, No : Unavailable

Installation Outline Drawing




Checking the Contents

< Copy Card Reader-F1 >



< Copy Card Reader Attachment-B5 >



Essential Items to Be Performed Before Installation

- Turn OFF the main power of the host machine, and disconnect the power plug from the outlet.

⚠ WARNING:

- If performing work without disconnecting the power plug of the host machine, it may cause electrical shock.
 - If disconnecting the power plug without turning OFF the main power, it may cause damage of the machine.
- When turning OFF the main power, follow the below procedure.
 1. Turn OFF the main power switch of the host machine.
 2. The display in the Control Panel and the lamp of the main power are turned off.



Installation

□

1.


NOTE:

With a 120V machine, remove the cord retainer first.



□


2.



3.

CAUTION:

When handling the hard disc, be careful not to vibrate or drop it.




4.



NOTE:

The removed screw will be used in step 9.


5.






NOTE:

The removed screw will be used in step 9.



6.



7.





8.



9.



CAUTION:

Be careful not to let the junction cable come in contact with the metal part of the Controller Box. If the junction cable come in contact with the metal part of the Controller Box, malfunctions may occur.





NOTE:

Use the screws removed in step 4 and 5.




10.


CAUTION:
When handling the hard disc, be careful not to vibrate or drop it.





11.





12.





13.



14.






15.





16.

CAUTION:
Be sure that the core is inside the Edge Saddle.





17.

< Without the Finisher >





< With the Finisher >





18.

< Without the Finisher >




< With the Finisher >




19.

< Without the Finisher >





< With the Finisher >





20.

CAUTION:

To ensure that the connector does not become disconnected, be sure to place the tie-wrap of the Card Reader External Relay Harness on the inside of the Connector Cover.





□
21.





□
22.

< Without the Finisher >




< With the Finisher >




□
23.

< Without the Finisher >



< With the Finisher >




□
24.

Connect the power plug of the host machine to the outlet.

NOTE:

With a 120V machine, install the cord retainer.



25. Turn the main power switch ON.

● Checking after Installation

-
1. Check the model of the Card Reader in service mode.
COPIER > OPTION > ACC > CR-TYPE(Default: 0 "Card Reader-F1")
 -
 2. Set the number of card (number of department ID) that can be used with the Card Reader in service mode(Lv.2).
COPIER > OPTION > FNC-SW > CARD-RNG
 -
 3. Use Service Mode to enter the minimum card number to be used by a user (1 to 2001).
COPIER > FUNCTION > INSTALL > CARD

CAUTION:

- Starting from the entered card number, the number of cards set in step 2 can be used.

-
4. Turn OFF and then ON the main power switch to enable the setting values.



5. **Insert a card with a card number that has been registered, and check that the machine operates normally.**


NOTE:

Perform the following operations to change the number of cards (departments) after it has been set. In such a case, counter information for each department is reset.


1. COPIER > FUNCTION > CLEAR > CARD
2. Turn OFF and then ON the main power switch to enable the settings.
3. After that, perform from step 2.

Copy Control Interface Kit-A1

Installation Outline Drawing



Checking the Contents



Essential Items to Be Performed Before Installation

- Turn OFF the main power of the host machine, and disconnect the power plug from the outlet.



⚠ WARNING:

- If performing work without disconnecting the power plug of the host machine, it may cause electrical shock.
 - If disconnecting the power plug without turning OFF the main power, it may cause damage of the machine.
- When turning OFF the main power, follow the below procedure.
 1. Turn OFF the main power switch of the host machine.
 2. The display in the Control Panel and the lamp of the main power are turned off.


Installation Procedure

1.

NOTE:
With a 120V machine, remove the cord retainer first.





2.





3.

CAUTION:
Do not drop the HDD while handling it.





4.



5.

CAUTION:






Install the extruded side of the D-SUB Support Plate as shown in the figure.



6.


CAUTION:

- Be careful not to drop the screws and washers. Dropping a screw or washer may result in damage, so be sure to pick it up.
- Install the CC-VI Cable in the direction shown in the figure.




□
7.


CAUTION:
Do not drop the HDD while handling it.



□
8.




□
9.



□
10. Connect the Power Plug to the outlet.

NOTE:
With a 120V machine, install the cord retainer.




□
11. Turn ON the main power switch.

Connection Kit-A1 for Bluetooth LE

Points to Note at Installation

- Although pictures or illustrations used for explanation may differ from the actual things, the procedure is the same.

Installation Outline Drawing



Essential Items to Be Performed Before Installation


- Turn OFF the main power of the host machine, and disconnect the power plug from the outlet.

⚠ WARNING:

- If performing work without disconnecting the power plug of the host machine, it may cause electrical shock.
- If disconnecting the power plug without turning OFF the main power, it may cause damage of the machine.

- When turning OFF the main power, follow the below procedure.
 - Turn OFF the main power switch of the host machine.
 - The display in the Control Panel and the lamp of the main power are turned off.

Checking the Contents




Installation Procedure


□
1.



□
2.




□
3.



NOTE:
The removed screw will be used in a later step.

□
4.

NOTE:
Use the screw removed in the previous step.






□
5.



□
6.



7.






8.

NOTE:
In countries other than the following countries, it is not necessary to affix the Approval Label.


< For US >

Affix it over the number on the Wireless LAN Approval Label.



< For KR, and TW >

Affix it over the Wireless LAN Approval Label.



9. Connect the power plug of the host machine to the outlet.

10. Turn ON the main power switch.

Setting after Installation

1. In the following Service Mode, set the value to "1."
COPIER > FUNCTION > INSTALL > BLE-USE

NOTE:

When [System Manager Information Settings] is set, it is required to log in as a system manager in accordance with instructions of the user administrator.

2. Select [Settings/Registration] > [Preferences] > [Network] > [Confirm Network Connection Setting Changes], and set the item [ON].
3. Select [Settings/Registration] > [Preferences] > [Network] > [Bluetooth Settings] > [Use Bluetooth] > [ON].
4. The message "Perform Apply Setting Changes from Settings/Registration" appears in the Touch Panel Display.
5. Perform "Apply Setting Changes."
Press [Settings/Registration] > [Yes].


Super G3 FAX Board-AY1

Checking before Installation

Points to Note when Installing

- Although the figure shows a model without the Finisher, the same procedure applies to the one with the Finisher.

Installation Outline Drawing



Essential Items to Be Performed Before Installation


- Turn OFF the main power of the host machine, and disconnect the power plug from the outlet.

⚠ WARNING:

- If performing work without disconnecting the power plug of the host machine, it may cause electrical shock.
- If disconnecting the power plug without turning OFF the main power, it may cause damage of the machine.

- When turning OFF the main power, follow the below procedure.
 - Turn OFF the main power switch of the host machine.
 - The display in the Control Panel and the lamp of the main power are turned off.

Checking the Contents




<Others> Including guides

Installation Procedure


■ Removing the Covers

NOTE:


With a 120V machine, remove the cord retainer first.



1.




2.




3.

CAUTION:

Do not drop the HDD while handling it.



4.



■ Installing the Fax Unit



1.

NOTE:

Remove the packing tape if any.

CAUTION:


- When installing the FAX Unit, be careful not to trap the 2 Cables of the FAX Unit.
- Do not directly touch the speaker [A] of the FAX Unit.
- Be sure not to damage the speaker [A].




Binding
M3x6




2x



2.




1x



3.





1x






4.

CAUTION:


- Fix the tie-wrap between the wire saddles [A] and [B].
- Fix the tie-wrap on the right side of the wire saddle [C].



5.




6.



■ Installing the Covers



□
1.




□
2.

CAUTION:


When handling the hard disc, be careful not to vibrate or drop it.



□
3.



□
4.



■ Procedure after Work

1.

NOTE:


This step is only for Taiwan.




2.

CAUTION:

Do not insert the screwdriver into the hole when removing the cover.




3.



4.

NOTE:


- This step is only for Europe.
- Do not connect the Telephone Cord (2 contact type) with the PTT Plug.
- Connect the PTT Plug matched the area to the PTT Cable (6 contact type).



5.

NOTE:

Connect the end of the PTT Cable or Telephone Cord, appropriate to the location(country/region) , to the modular jack on the Host machine, and connect the other end to the modular jack on the wall.




6.

Connect the Power Plug to the outlet.

NOTE:

With a 120V machine, install the cord retainer.



7.

Turn ON the main power switch.

Checking the Operation

■ Type Setting



1. From the following service mode, check that the type setting of Fax board is set to the correct location (country/region) and press OK.

FAX > TYPE > TYPE

2. Check that the value of the following service mode is "0". If it is "1", change it to "0".

COPIER > OPTION > DSPLY-SW > SDTM-DSP

NOTE:

To change parameter to "0" makes no show below [Settings/Registration > Preferences > Time/Energy Settings > Auto Shutdown Time] and auto shut down is not available.

3. After setting the user telephone number, turn OFF and then ON the main power switch.

■ Basic Setting

NOTE:

When "System Manager Information Settings" is set, be sure to follow the direction of user administrator in order to log in as an administrator.

In this section, make only minimum settings required for FAX communication.



1. Set the user telephone number.

[Settings/Registration] > [Function Settings] > [Send] > [Fax Settings] > [Set Line] > [Line 1] > [Register Unit Telephone Number] > Enter the fax number > [OK]

2. After setting the user telephone number, turn OFF and then ON the main power switch.


■ FAX Communication Test

Perform communication test to check if FAX function works correctly.



1. Switch the control panel display to Send/Fax display.
2. Send the test document from this machine to another machine that can handle the communication test to check that this machine can send the data correctly.

3. Send the test document from the target to this machine to check if the machine can receive the document properly.



APPENDICES

| | |
|----------------------------------|-----|
| Service Tools..... | 629 |
| General Circuit Diagram..... | 630 |
| Soft counter specifications..... | 635 |
| Removal..... | 639 |


Service Tools


Special Tools


None.

Solvents and Oils

None.







Soft counter specifications

Software Counter Specifications

Software counter is classified according to the input number as follows:

| No. | Counter item | No. | Counter item |
|------------|--------------|------------|--|
| 000 to 099 | Toner Bottle | 500 to 599 | Scan |
| 100 to 199 | Total | 600 to 699 | Mail Box print, memory media print |
| 200 to 299 | Copy | 700 to 799 | Reception print, Advanced Box print, network print, mobile print |
| 300 to 399 | Print | 800 to 899 | Report print |
| 400 to 499 | Copy + Print | 900 to 999 | Transmission |

- Description of codes in the table -

- Large: Paper larger than B4 size
- Small size: Paper equal to or smaller than B4
- The number 1 and 2 in "Counter item": The count for large size paper
- The size as which "B4" should be counted (service mode: B4-L-CNT)
0: Small (default)
1: Large
- Total A: Total excluding local copy
- Total B: Total excluding local copy + Mail Box print
- Copy: Local copy
- Copy A: Local copy + Mail Box print
- Print: PDL print + Report print + Mail Box print
- Print A: PDL print + Report print
- Scan: Black scan + Color scan

Related Service Mode

COPIER > OPTION > USER > B4-L-CNT

000 to 099

| Number on the screen | Counter item | Number on the screen | Counter item |
|----------------------|---|----------------------|--|
| 064 | The number of premature replacements of the Toner Container (Black) | 071 | The number of installations of a new Toner Container (Black) |

100 to 199

| Number on the screen | Counter item | Number on the screen | Counter item |
|----------------------|---------------------|----------------------|-----------------------------------|
| 101 | Total 1 | 140 | Large A (2-sided) |
| 102 | Total 2 | 141 | Small A (2-sided) |
| 103 | Total (Large) | 150 | Total B1 |
| 104 | Total (Small) | 151 | Total B2 |
| 108 | Total (Black 1) | 152 | Total B (Large) |
| 109 | Total (Black 2) | 153 | Total B (Small) |
| 112 | Total (Black/Large) | 156 | Total B (Black 1) |
| 113 | Total (Black/Small) | 157 | Total B (Black 2) |
| 114 | Total 1 (2-sided) | 160 | Total B (Black/Large) |
| 115 | Total 2 (2-sided) | 161 | Total B (Black/Small) |
| 116 | Large (2-sided) | 162 | Total B1 (2-sided) |
| 117 | Small (2-sided) | 163 | Total B2 (2-sided) |
| 126 | Total A1 | 164 | Large B (2-sided) |
| 127 | Total A2 | 165 | Small B (2-sided) |
| 128 | Total A (Large) | 181 | Unidentified Toner Bottle (Black) |
| 129 | Total A (Small) | | |

| Number on the screen | Counter item | Number on the screen | Counter item |
|----------------------|-----------------------|----------------------|--------------|
| 132 | Total A (Black 1) | | |
| 133 | Total A (Black 2) | | |
| 136 | Total A (Black/Large) | | |
| 137 | Total A (Black/Small) | | |
| 138 | Total A1 (2-sided) | | |
| 139 | Total A2 (2-sided) | | |

200 to 299

| Number on the screen | Counter item | Number on the screen | Counter item |
|----------------------|----------------------------|----------------------|----------------------------------|
| 201 | Copy (Total 1) | 250 | Copy A (Black 2) |
| 202 | Copy (Total 2) | 255 | Copy A (Black/Large) |
| 203 | Copy (Large) | 256 | Copy A (Black/Small) |
| 204 | Copy (Small) | 265 | Copy A (Black/Large/2-sided) |
| 205 | Copy A (Total 1) | 266 | Copy A (Black/Small/2-sided) |
| 206 | Copy A (Total 2) | 277 | Local copy (Black 1) |
| 207 | Copy A (Large) | 278 | Local copy (Black 2) |
| 208 | Copy A (Small) | 283 | Local copy (Black/Large) |
| 209 | Local copy (Total 1) | 284 | Local copy (Black/Small) |
| 210 | Local copy (Total 2) | 293 | Local copy (Black/Large/2-sided) |
| 211 | Local copy (Large) | 294 | Local copy (Black/Small/2-sided) |
| 212 | Local copy (Small) | | |
| 221 | Copy (Black 1) | | |
| 222 | Copy (Black 2) | | |
| 227 | Copy (Black/Large) | | |
| 228 | Copy (Black/Small) | | |
| 237 | Copy (Black/Large/2-sided) | | |
| 238 | Copy (Black/Small/2-sided) | | |
| 249 | Copy A (Black 1) | | |

300 to 399

| Number on the screen | Counter item | Number on the screen | Counter item |
|----------------------|-----------------------------|----------------------|---------------------------------|
| 301 | Print (Total 1) | 332 | PDL print (Total 2) |
| 302 | Print (Total 2) | 333 | PDL print (Large) |
| 303 | Print (Large) | 334 | PDL print (Small) |
| 304 | Print (Small) | 339 | PDL print (Black 1) |
| 305 | Print A (Total 1) | 340 | PDL print (Black 2) |
| 306 | Print A (Total 2) | 345 | PDL print (Black/Large) |
| 307 | Print A (Large) | 346 | PDL print (Black/Small) |
| 308 | Print A (Small) | 355 | PDL print (Black/Large/2-sided) |
| 313 | Print (Black 1) | 356 | PDL print (Black/Small/2-sided) |
| 314 | Print (Black 2) | | |
| 319 | Print (Black/Large) | | |
| 320 | Print (Black/Small) | | |
| 329 | Print (Black/Large/2-sided) | | |
| 330 | Print (Black/Small/2-sided) | | |
| 331 | PDL print (Total 1) | | |

400 to 499

| Number on the screen | Counter item | Number on the screen | Counter item |
|----------------------|----------------------------|----------------------|------------------------------------|
| 403 | Copy + Print (Black/Large) | 412 | Copy + Print (Small) |
| 404 | Copy + Print (Black/Small) | 413 | Copy + Print (2) |
| 405 | Copy + Print (Black 2) | 414 | Copy + Print (1) |
| 406 | Copy + Print (Black 1) | 421 | Copy + Print (Black/Large/2-sided) |
| 411 | Copy + Print (Large) | 422 | Copy + Print (Black/Small/2-sided) |

500 to 599

| Number on the screen | Counter item | Number on the screen | Counter item |
|----------------------|----------------------|----------------------|----------------------|
| 501 | Scan (Total 1) | 507 | Black scan (Large) |
| 502 | Scan (Total 2) | 508 | Black scan (small) |
| 503 | Black scan (Large) | 509 | Color scan (Total 1) |
| 504 | Scan (Small) | 510 | Color scan (Total 2) |
| 505 | Black scan (Total 1) | 511 | Color scan (Large) |
| 506 | Black scan (Total 2) | 512 | Color scan (Small) |

600 to 699

| Number on the screen | Counter item | Number on the screen | Counter item |
|----------------------|--------------------------------------|----------------------|--|
| 601 | Mail Box print (Total 1) | 631 | Memory media print (Total 1) |
| 602 | Mail Box print (Total 2) | 632 | Memory media print (Total 2) |
| 603 | Mail Box print (Large) | 633 | Memory media print (Large) |
| 604 | Mail Box print (Small) | 634 | Memory media print (Small) |
| 609 | Mail Box print (Black 1) | 639 | Memory media print (Black 1) |
| 610 | Mail Box print (Black 2) | 640 | Memory media print (Black 2) |
| 615 | Mail Box print (Black/Large) | 645 | Memory media print (Black/Large) |
| 616 | Mail Box print (Black/Small) | 646 | Memory media print (Black/Small) |
| 625 | Mail Box print (Black/Large/2-sided) | 655 | Memory media print (Black/Large/2-sided) |
| 626 | Mail Box print (Black/Small/2-sided) | 656 | Memory media print (Black/Small/2-sided) |

700 to 799

| Number on the screen | Counter item | Number on the screen | Counter item |
|----------------------|---------------------------------------|----------------------|--|
| 701 | Reception print (Total 1) | 737 | Advanced Box print (Black/Large) |
| 702 | Reception print (Total 2) | 738 | Advanced Box print (Black/Small) |
| 703 | Reception print (Large) | 741 | Advanced Box print (Black/Large/2-sided) |
| 704 | Reception print (Small) | 742 | Advanced Box print (Black/Small/2-sided) |
| 709 | Reception print (Black 1) | 743 | Network print (Total 1) |
| 710 | Reception print (Black 2) | 744 | Network print (Total 2) |
| 715 | Reception Print (Black/Large) | 745 | Network print (Large) |
| 716 | Reception Print (Black/Small) | 746 | Network print (Small) |
| 725 | Reception Print (Black/Large/2-sided) | 749 | Network print (Black 1) |
| 726 | Reception Print (Black/Small/2-sided) | 750 | Network print (Black 2) |
| 727 | Advanced Box print (Total 1) | 753 | Network print (Black/Large) |
| 728 | Advanced Box print (Total 2) | 754 | Network print (Black/Small) |
| 729 | Advanced Box print (Large) | 757 | Network print (Black/Large/2-sided) |
| 730 | Advanced Box print (Small) | 758 | Network print (Black/Small/2-sided) |
| 733 | Advanced Box print (Black 1) | | |
| 734 | Advanced Box print (Black 2) | | |

800 to 899

| Number on the screen | Counter item | Number on the screen | Counter item |
|----------------------|------------------------|----------------------|------------------------------------|
| 801 | Report print (Total 1) | 815 | Report print (Black/Large) |
| 802 | Report print (Total 2) | 816 | Report print (Black/Small) |
| 803 | Report print (Large) | 825 | Report print (Black/Large/2-sided) |
| 804 | Report print (Small) | 826 | Report print (Black/Small/2-sided) |
| 809 | Report print (Black 1) | | |
| 810 | Report print (Black 2) | | |

900 to 999

| Number on the screen | Counter item | Number on the screen | Counter item |
|----------------------|-----------------------------------|----------------------|----------------------------------|
| 915 | Transmission scan total 2 (Color) | 945 | Transmission scan/E-mail (Color) |
| 916 | Transmission scan total 2 (Black) | 946 | Transmission scan/E-mail (Black) |
| 917 | Transmission scan total 3 (Color) | 959 | Memory media scan (Color) |
| 918 | Transmission scan total 3 (Black) | 960 | Memory media scan (Black) |
| 921 | Transmission scan total 5 (Color) | 961 | Application scan (Total 1) |
| 922 | Transmission scan total 5 (Black) | 962 | Application black scan (Total 1) |
| 929 | Transmission scan total 6 (Color) | 963 | Application color scan (Total 1) |
| 930 | Transmission scan total 6 (Black) | 964 | Advanced Box scan (Color) |
| 937 | Mail Box scan (Color) | 965 | Advanced Box scan (Black) |
| 938 | Mail Box scan (Black) | | |
| 939 | Remote scan (Color) | | |
| 940 | Remote scan (Black) | | |

Removal

Overview

- User data kept by the machine contains address books and inbox documents that users can recognize.
- By using the copy, print, or send function, there is also information left on the HDD of MFPs that is generally not recognizable but can be recovered as documents. (Refer to the illustration on the next page.)
- For security, the user mode is provided to delete data on FLASH PCB and perform overwrite deletion to render user data on HDD unrecoverable.

■ Cancelling the Device Registration

If Data Backup Service is used, it is required to perform the following steps in the order.

1. **Stop using the Data Backup Service. (Operation on CBIO side)**
2. **Delete all the backup data. (Operation on CBIO side)**
3. **Cancel the device registration. (Operation on the device side)**

NOTE:

For above procedure, see the User's Guide for Data Backup Service.

CAUTION:

Be sure to cancel the device registration before deleting the user, because the device registration cannot be cancelled after deleting the user data.

■ User data delete

- To delete user data, execute Settings/Registration > System Management > Initialize All Data/Settings in user mode. Performing Initialize All Data/Settings returns user mode setting values to their factory defaults.
- Deletion Mode can be changed. Normally, "Once with 0 (Null) Data" can sufficiently delete data. Note that increasing the number of overwrite increases the time required for the deletion operation.

NOTE:

- When you perform Initialize All Data/Settings, license and data of MEAP application are initialized to the state same as when the HDD is replaced. If MEAP application may be used by other users after the machine is removed, disable the MEAP application and uninstall it in advance.
- Performing Initialize All Data/Settings does not delete the license of the system option.

■ Deletion of Service Mode Settings

The user mode setting values may have been changed at the user's request. In that case, the service mode setting values should be changed back to the default values before removing the machine.

Work Procedure


If the user uses MEAP applications, ask the user to uninstall the MEAP applications if necessary.

■ User data delete procedure

1. Settings/Registration > Management Settings > Data Management > Initialize All Data/Settings
2. Select a deletion mode.

3. Press [Start].

If the user has not given any instruction on which item in the deletion mode should be used, select the default "Once with 0 (Null) Data".



NOTE:

- When all the data are initialized, the user data on the HDD and the user data on the Flash PCB are deleted. For the items to be deleted, refer to the backup list.
- Performing "Initialize All Data" turns auto gradation adjustment values and TPM settings to OFF. Therefore, to enable normal operation the next time, the operation performed at installation is necessary.
- Performing Initialize All Data/Settings does not delete the license of the system option.

Report output upon completion of Initialize All Data/Settings

A report is output after "Initialize All Data/Settings" is completed.

Consider using this report to provide to user as a material to inform of work details when executing Initialize All Data/Settings upon user's request.

Operation after Initialize All Data/Settings

The machine is started normally at restart after Initialize All Data/Settings without displaying the message (Turn OFF the main power supply on the right side of the machine) on the screen to prompt shutdown.

The report is output after startup.

```

*****
*** System Information ***
*****

<< Initialize All Data/Settings Report >>

Serial Number          ZZZ99999
Device Name            iR-ADV XXXX (iAXXXX)

Overwrite Method for Deletion Mode  Once with Random Data (*1)

The following data stored in the device has been completely erased.

- Data stored in the temporary data area
- User generated data
- Settings under Settings/Registration (restored to factory defaults)
    
```

*1 display following one.
 "Once with 0 (Null) Data"
 "Once with Random Data"
 "3 Times with Random Data"
 "9 Times with Random Data"
 "DoD Standard"

Limitations

- The language of the report is only English, and cannot be changed.
- The report is output without fail (a function to select ON/OFF of report output is not provided).
- There is no second output of report when the machine is turned ON without paper.
- Only the output of this report remains in the job log.

■ Deletion of Service Mode Setting Values

Service Mode Lev1 > Function> CLEAR > MN-CONT



NOTE:

- When MN-CON clear is executed, the address book on the HDD is not deleted. As for the user data, initialize all the data.
- When MN-CON clear is executed, the password for the security policies will be deleted.